

CYCLE 5 HELPFUL HINTS

This paper describes helpful hints on how to use Cycle 5 of NOS/VE. It is intended to supplement, rather than to replace, the standard NOS/VE documentation. If you have any questions or suggestions, please see Tom McGee or Bonnie Swierzbin. Appendix D lists background documents and how to obtain them.

To obtain additional copies of this document while running on SN101 at Arden Hills, please type:

```
SES,INT1.LISTHINTS C=<number of copies>
```

To obtain a copy with revision bars against the Helpful Hints of the previous build, one can type:

```
SES,INT1.LISTHINTS REVB C=<number of copies>
```

The C parameter is optional and defaults to one.

Update_History

Date	Changes
12/22/80	Revisions for NOS/VE Phase C
2/12/81	Additional Revisions for NOS/VE Phase C
6/09/81	Revisions for NOS/VE Build N
6/19/81	Additional Revisions for NOS/VE Build N
8/28/81	Revisions for NOS/VE Build O
11/06/81	Revisions for NOS/VE Build P
3/01/82	Revisions for NOS/VE Build Q
4/15/82	Revisions for NOS/VE Cycle 2
5/01/82	Revisions for NOS/VE Cycle 3
6/30/82	Revisions for NOS/VE Cycle 5

07/07/82

 1.0 MAJOR CHARACTERISTICS OF THIS BUILD

1.0 MAJOR_CHARACTERISTICS_OF_THIS_BUILD

- o The TAFNVE operator command (TAF control point) is no longer required or available. The capabilities that were provided by it have been packaged within the NVE subsystem control point. The impact of this change is as follows:
 - The K display is assigned to the same control point during both deadstart and normal system operation.
 - Output from the system core debugger will no longer appear at the NVE control point K-display. All system core debugger communication is via the MDD terminal.
 - The K.*BYEVE. command is no longer available.
 - The 2.OFFSW6. command before doing a 2.STOP. is not required to bring NVE down.
 - All capabilities are available via the N.NVExxxx. command. The NVE subsystem may be placed at any control point (like NAM is).
- o Cycle 5 (actually Cycle 4) of NDS/VE no longer supports the "old" command names for system commands. Both "old" and "new" names have been supported since Build Q. See DAP ARH4776 for details. As part of this change the abbreviations for the COPY_FILE and PRINT_FILE commands have been corrected to CCPF and PRIF (from COPYF and PRINTF).
- o The EXPLAIN command was implemented in Cycle 4 of NDS/VE. Don't get too excited about this, however, because as yet there are no "explain level" message templates for any of the system conditions. EXPLAIN will simply regurgitate the regular message.

While implementing the EXPLAIN command it was discovered that the specification of the command (i.e. that it have an optional "condition" parameter) was not nearly as useful as having the first parameter be a "status" value. So the implementation deviates from the ERS in that the first parameter to EXPLAIN is MESSAGE_STATUS or MS and is of kind STATUS. The \$STATUS function can be used to transform a "condition" into a "status". A DAP is being written to make

 1.0 MAJOR CHARACTERISTICS OF THIS BUILD

this change official. :

- o The implicit attach process has been modified to choose share mode to be the following function of access mode. If access mode includes shorten, append or modify then share mode is none, otherwise share mode is read and execute. This results in allowing sharing of implicitly attached files that are not being written but inhibiting sharing of implicitly attached files that are being written. :

The implicit attach process formerly chose share mode to be the share requirements established by the permit mechanism. The owner of files typically has no share requirements and hence would implicitly attach the files for exclusive access. This created a severe usability problem for code or command files that were to be executed by multiple jobs. :

It seems that many people are running into a problem on the system concerning the use of "path" references to files. Specifically, a job will "hang" if a CREATE_FILE (define) or ATTACH_FILE (attach) command for a file is followed by another reference to the file using the "path" notation. For example:

```
CREATE_FILE $USER.JUNK
.
.
COPY_FILE $USER.JUNK NEWJUNK
```

will result in the job begin hung. The reason is that there is a LOCAL_FILE_NAME parameter on the create_file command which defaults to the name of the permanent file (in the example: JUNK); but the "implicit" access to the file via the copy_file command uses an internally generated local name for the file. Thus, the effect is the same as the following command sequence on NOS:

```
DEFINE,JUNK.
.
.
ATTACH,zunique=JUNK.
COPY,zunique,NEWJUNK.
```

Here, the job will hang on the attach command because of conflicting access to file JUNK.

On NOS/VE, explicit use of the CREATE_FILE and ATTACH_FILE commands is not generally necessary. For example:

07/07/82

 1.0 MAJOR CHARACTERISTICS OF THIS BUILD

COPY_FILE .MY_FRIEND.SOME_FILE \$USER.SOME_FILE

will (implicitly) attach file SOME_FILE from user MY_FRIEND's master catalog, create file SOME_FILE in my master catalog and copy the former into the latter (if SOME_FILE already existed in my master catalog, it would be attached and overwritten).

DO NOT MIX "IMPLICIT" ATTACH/CREATE WITH "EXPLICIT" ATTACH/CREATE.

If you insist on explicitly attaching or creating files then USE THE LOCAL FILE NAME that you assigned via the ATTACH_FILE or CREATE_FILE command.

Sheldon Fewer is writing a DAP proposing to change the default for the LOCAL FILE NAME parameter on the CREATE_FILE and ATTACH_FILE commands. If sanity prevails, this DAP will be approved and the problem outlined above will be largely resolved. Until then PLEASE USE EITHER EXPLICIT ACCESS OR IMPLICIT ACCESS (preferably the latter) BUT NOT BOTH!!!

- o With the advent of NDS/VE Cycle 1.3.4 SCU command and parameter names were updated per DAP 4968. Only the new names are recognized now. Documentation for the current version of SCU can be found in the ERS, DCS number ARH3883 revision F. Command summaries can be obtained from Mike Perreten in Arden Hills or Stacy Buckley in Sunnyvale. The material accessed by the non-standard command display_command_information has been updated for SCU. The use of display_command_list with display_options equal to full while inside SCU may prove useful. :
- o An EDI problem exists with respect to a file shared between jobs. An existing file is opened with an access mode of append by job A. The same file is opened with an access mode of read by job B. Job A extends the file and either explicitly closes the file or terminates. Job B explicitly closes the file or terminates. In this case, since the job accessing the file in read mode terminated after the job which extended the file, EDI on the file will be reset to the original position and the result of the extend will be lost. :
- o The Interstate Communication Facility, which is described in Section 9 of the NDS/VE ERS - Program Interface (Rev. 8), has been implemented. The callable subroutines described in section 9.3 reside in User Library LINKLIB in the Integration catalogs INT1, DEV1, REL1, etc. NOS libraries SYSLIB and SRVLIB are also required to complete the loading process. LDSET loader commands must be used to select these libraries. :

 1.0 MAJOR CHARACTERISTICS OF THIS BUILD

o Interactive Usage Restrictions:

- When logging in to NDS/VE (i.e. HELLO,TAF etc.) do not enter a terminate break (CTRL t) or a pause break (CTRL p) before the 'welcome message' appears at the terminal. A pause or terminate break entered before the interactive NDS/VE job has completed it's initialization may crash the system.
- A REQUEST_TERMINAL command in a batch job will crash the system. This can happen accidentally through a REQUEST_TERMINAL command in a user prolog when the user runs a batch job since the prolog is executed for both interactive and batch jobs. The problem can be avoided by making the REQUEST_TERMINAL command in the prolog conditional on the job type as follows:

```
IF $JOB(MODE) <> 'BATCH' THEN
  REQUEST_TERMINAL
IFEND
```

- o Any product or utility that is placed in the \$SYSTEM catalog (or any frequently loaded program) should be bound using the CREATE_MODULE subcommand of the CREATE_OBJECT_LIBRARY utility. This will minimize overhead associated with loading the product or utility.
- o Debug responds to terminal breaks when a program is being debugged. However, entering a pause or terminate break when debug is active (i.e. the DB/ prompt has appeared and the user has not issued the RUN command) will cause the task to terminate.
- o When sharing executable files via permanent files (i.e. compilers, libraries, etc.) you should make the file an object library via the CREATE_OBJECT_LIBRARY utility. By sharing object libraries instead of object files, the code is actually shared among all tasks using the library; the library is not copied to another segment but is executed directly.

1.1 NDS/VE_USAGE_EXAMPLES

NOS/VE Cycle 5 Helpful Hints

07/07/82

```

*****
1.0 MAJOR CHARACTERISTICS OF THIS BUILD

```

```

1.1.1 EXECUTING PROGRAMS
*****

```

1.1.1 EXECUTING PROGRAMS

PROCESS

Create an object text file by compiling a program on NOS. Then perform the following steps on NOS/VE:

- Acquire any necessary libraries (which are not quoted in text embedded directives) by either:
 - o Attaching them from the system catalog, either explicitly or via prolog
 - o Creating the library file via the object library generator
 - o Staging the library file from NOS to NOS/VE using the GET_OBJECT_LIBRARY command.
- Get the file from NOS and convert the object text file from the CI data mapping to II data mapping by executing the CONVERT_OBJECT_FILE command.
- Load and execute the program via the EXECUTE_TASK command, specifying the necessary libraries with the LIBRARY parameter; alternatively SET_PROGRAM_ATTRIBUTES may be used to include the libraries in all subsequent EXECUTE_TASK commands.
- Stage the loadmap from NOS/VE to NOS for printing by using either:
 - o The REPLACE_FILE command with A6 conversion mode specified if running on the simulator.
 - o The PRINT_FILE command if running on the hardware.

EXAMPLES

The following is an example command sequence for executing a program not requiring any libraries for loading:

Assumptions: all modules to be loaded are contained on the NOS permanent file 'citxtrs'.

```

CONVERT_OBJECT_FILE CITXTRS
EXECUTE_TASK CITXTRS PARAMETER='program parameters'
PRINT_FILE LOADMAP

```

NOS/VE Cycle 5 Helpful Hints

07/07/82

 1.0 MAJOR CHARACTERISTICS OF THIS BUILD

1.1.1 EXECUTING PROGRAMS

The following is an example command sequence for executing a program requiring libraries for loading:

Assumptions: the NOS permanent file 'citxtrs' contains object text generated by the CYBIL CI compiler. The compiler modules reference procedures contained on the library 'mylib' and the CYBIL run-time library. These libraries have been generated on NOS/VE and saved on NOS.

```
GET_OBJECT_LIBRARY MYLIB
SET_PROGRAM_ATTRIBUTES LOAD_MAP_OPTIONS=(BLOCK,ENTRY_POINT,SEGMENT
CONVERT_OBJECT_FILE CITXTRS
EXECUTE_TASK CITXTRS 'program parameters' LIBRARY=MYLIB
PRINT_FILE LOADMAP
```

1.1.2 CREATE OBJECT LIBRARY ON NOS/VE AND SAVE IT ON NOS

Notes:

- o CLG0170 is NOS permanent file name for file containing CI object text for modules to be included in the library.
- o IITEXT180 is NOS/VE local file name for file containing II object text for modules to be included in the library.
- o LIBRARY180 is NOS/VE local file name for the library being created.
- o ILIB170 is NOS permanent file name for file containing the library.

NOS/VE Job Commands

```
CONVERT_OBJECT_FILE IITEXT180 CLG0170
CREATE_OBJECT_LIBRARY
ADD_MODULE LIBRARY=IITEXT180
GENERATE_LIBRARY LIBRARY=LIBRARY180
QUIT
REPLACE_FILE LIBRARY180 ILIB170 DC=B56
```

1.1.3 MODIFY A PREVIOUSLY SAVED OBJECT LIBRARY

Notes:

- o ILIB170 is NOS permanent file name for file containing the old

NDS/VE Cycle 5 Helpful Hints

07/07/82

1.0 MAJOR CHARACTERISTICS OF THIS BUILD1.1.3 MODIFY A PREVIOUSLY SAVED OBJECT LIBRARY

Library

- o LIBRARY180 is NDS/VE local file name for file containing the old library
- o CMOD170 is NOS permanent file name for file containing CI object text for the new module
- o NEWIIMODULE is NDS/VE local file name for file containing II object text for the new module
- o NEWLIBRARY is NDS/VE local file name for the library being created
- o NLIB170 is NOS local file name for new library

NDS/VE Job Commands

```

GET_OBJECT_LIBRARY LIBRARY180 ILIB170
CONVERT_OBJECT_FILE NEWIIMODULE CMOD170
CREATE_OBJECT_LIBRARY
ADD_MODULE LIBRARY=LIBRARY180
REPLACE_MODULE LIBRARY=NEWIIMODULE
GENERATE_LIBRARY LIBRARY=NEWLIBRARY
QUIT
REPLACE_FILE NEWLIBRARY NLIB170 DC=B56

```

1.1.4 ROUTE AN INPUT FILE FROM NOS TO NOS/VE

Running from an interactive terminal, enter:

```

GET,filename.
ROUTE,filename,DC=LP,FC=RH.

```

The input file which is sent to NDS/VE must be in 6/12 ASCII (or display code subset). The job file must be a single partition NDS record containing NDS/VE commands. The first statement must be a valid LOGIN command with user, password and family name specified. Multi partition input files are not supported by NDS/VE so NOS data files used by the program must be obtained through the GET_FILE command.

NOS/VE Cycle 5 Helpful Hints

07/07/82

1.0 MAJOR CHARACTERISTICS OF THIS BUILD1.1.5 PRINT A NOS/VE FILE

1.1.5 PRINT A NOS/VE FILE

At NOS/VE job termination the job log will be automatically returned to NOS. The job log will be appended to the NOS/VE output file OUTPUT. NOS/VE print files must be written by BAM as 8/8 ASCII RT=V. Print files will be converted from 8/8 ASCII RT=V to NOS 8/12 ASCII when they are sent to NOS and will be printed in upper/lower case.

All NOS/VE output files will appear in the NOS output queue (NOS H,0 display) with the name IRHFxxx as a banner. In order to print a NOS/VE file, the following command must be issued within your job or be entered from the system console via the operator facility:

PRINT_FILE filename

NOS/VE Cycle 5 Helpful Hints

07/07/82

 2.0 COMMAND INTERFACE STATUS

2.0 COMMAND_INTERFACE_STATUS2.1 ACCESS_ID_NOS/VE_IN_DUAL_STATE

2.1.1 LOGIN TO NOS/VE

To initially login to NOS/VE via TAF, you must cause the first login attempt to fail. This can be done by responding to the "FAMILY:" login prompt with something like: ",,, ". This must be done because the system will try to connect the terminal to IAF on the first login attempt no matter what is typed. To access TAF do the following on the second "FAMILY:" prompt:

```
,user,password,TAF
```

You can access TAF from IAF by doing "HELLO,TAF" or by answering TAF to the system prompt "APPLICATION:".

2.1.2 TERMINAL USAGE

- 1) The slant (/) is the prompt to enter a NOS/VE command. Any normal NOS/VE command can now be entered (continuation lines are prompted with ..). The full ASCII character set, lower or upper case and all special characters, can be used.
- 2) A LOGOUT command will cause the NOS/VE Interactive Job to terminate. A new NOS/VE Interactive Job can then be started by responding to the 'APPLICATION:' prompt with TAF.
- 3) Terminal breaks (control-t and control-p) can be used to terminate a task or command and suspend a task and enter a new task to process SCL commands. Control-t causes a terminate break and control-p causes a pause break. Terminate break will terminate a command or the most recently executed task. A pause break will suspend execution and allow commands to be entered. When a

NOS/VE Cycle 5 Helpful Hints

07/07/82

2.0 COMMAND INTERFACE STATUS

2.1.2 TERMINAL USAGE

terminal is in pause break state, two additional commands are available:

RESUME_COMMAND - resume execution at the point of interruption.

TERMINATE_COMMAND - cause a terminate break condition as a terminate break had been entered.

Both terminate break and pause break are available to programs as conditions via the program management condition mechanism.

2.1.3 NOS/VE PROGRAM ACCESS TO THE TERMINAL

- 1) Interactive NOS/VE jobs are able to obtain terminal input through the AMP\$GET_NEXT or AMP\$GET_PARTIAL program interface which can be used by both task services and user ring programs. Interactive programs which use this interface should be able to handle both upper and lower case input in order to make them more convenient to use in both 64 and 96 character set modes.

2.2 COMMAND_AND_PARAMETER_NAMES

During the next few months a command supported by the system may not be in sync with your command interface document. The parameter descriptor table gives an accurate, concise description of the command interface as currently supported.

PDI_Reader's_Guide

The definition of a command's parameter list is enclosed in parenthesis with a parameter description per line. Each description has the general form:

PARAMETER NAME: ALLOWED PARAMETER VALUES = PARAMETER DEFAULT VALUE

Parameter Names - describes the parameter name and any abbreviations.

ALLOWED PARAMETER VALUES - describes the kind of value allowed and whether a list of values is possible. The value kind can be

07/07/82

 2.0 COMMAND INTERFACE STATUS

2.2 COMMAND AND PARAMETER NAMES

further qualified. In some cases, the actual values allowed are described using the KEY notation. The value kinds include INTEGER, STRING, NAME, FILE, STATUS.

PARAMETER DEFAULT VALUES - describes the defaulting rules and/or values for the parameter. \$REQUIRED and \$OPTIONAL are obvious. Other values in this position will be treated as if they were entered by the user on command invocation.

See the PROC command in the Command Interface ERS for more details.

The PDTs for the commands currently in the system can be displayed using the DISPLAY_COMMAND_INFORMATION command. This is documented in the nonstandard command section of this document.

2.3 COMMAND_FUNCTIONS

Function	Status
\$MOD	unchanged
\$CHAR	unchanged
\$CLOCK	unchanged
\$DATE	unchanged
\$FILE	unchanged
\$FNAME	unchanged
\$INTEGER	unchanged
\$NAME	unchanged
\$ORD	unchanged
\$REAL	unchanged
\$STRING	unchanged
\$STRLEN	unchanged
\$STRREP	unchanged
\$SUBSTR	unchanged
\$UNIQUE	unchanged
\$TIME	unchanged
\$VAR	unchanged
\$SPECIFIED	unchanged
\$SET_COUNT	unchanged
\$VALUE_COUNT	unchanged
\$RANGE	unchanged
\$PARAMETER_LIST	unchanged
\$PARAMETER	unchanged
\$STATUS	unchanged
\$CONDITION	unchanged
\$SEVERITY	unchanged
\$PROCESSOR	unchanged

NDS/VE Cycle 5 Helpful Hints

07/07/82

 2.0 COMMAND INTERFACE STATUS

 2.3 COMMAND FUNCTIONS

\$JOB	unchanged
\$PROGRAM	unchanged

2.4 SYSTEM_ACCESS_COMMANDS

Commands	Status
SET_LINK_ATTRIBUTES	unchanged
LOGIN	unchanged - *1
LOGOUT	unchanged
SET_PASSWORD	unchanged

*1 The family name of the job doing the submit will be used as the default family name on batch jobs. The default for jobs submitted from NDS will be family \$SYSTEM. This effectively means that whenever NOS/VE jobs are submitted from NDS the family parameter is required.

2.5 RESOURCE_MANAGEMENT

Command	Status
REQUEST_TERMINAL	unchanged

2.6 FILE_MANAGEMENT

Command	Status
SET_FILE_ATTRIBUTES	unchanged
COPY_FILE	unchanged
DISPLAY_FILE	unchanged
COMPARE_FILE	unchanged
DISPLAY_FILE_ATTRIBUTES	unchanged
SKIP_TAPE	unchanged

2.7 PERMANENT_FILE_MANAGEMENT

Command	Status
GET_FILE	unchanged
REPLACE_FILE	unchanged
CREATE_FILE	unchanged

07/07/82

2.0 COMMAND INTERFACE STATUS
 2.7 PERMANENT FILE MANAGEMENT

ATTACH_FILE	unchanged
DELETE_FILE	unchanged
CHANGE_CATALOG_ENTRY	unchanged
CREATE_FILE_PERMIT	unchanged
DELETE_FILE_PERMIT	unchanged
CREATE_CATALOG	unchanged
DELETE_CATALOG	unchanged
DELETE_CATALOG_PERMIT	unchanged
CREATE_PERMIT_CATALOG	unchanged
DISPLAY_CATALOG	unchanged
DISPLAY_CATALOG_ENTRY	unchanged
SET_WORKING_CATALOG	unchanged

2.8 SQL STATEMENTS AND PROCEDURES

Command	Status
PROC/PROCEND	unchanged
SET_COMMAND_LIST	unchanged
DISPLAY_COMMAND_LIST	unchanged
REPEAT/UNTIL	unchanged
WHILE/WHILEND	unchanged
CREATE_VARIABLE	unchanged
DELETE_VARIABLE	unchanged
BLOCK/BLOCKEND	unchanged
LOOP/LOOPEND	unchanged
FOR/FOREND	unchanged
IF/ELSEIF/ELSE/IFEND	unchanged
CYCLE	unchanged
EXIT	unchanged
WHEN/WHENEND	unchanged
CONTINUE	unchanged
CANCEL	unchanged
INCLUDE_FILE	unchanged
COLLECT_TEXT	unchanged
DISPLAY_VALUE	unchanged
EXIT_PROC	unchanged
ACCEPT_LINE	unchanged
INCLUDE_LINE	unchanged
CREATE_FILE_CONNECTION	unchanged
DELETE_FILE_CONNECTION	unchanged
DISPLAY_FILE_CONNECTION	unchanged
change HCS variable	unchanged
display HCS variable	unchanged

2.0 COMMAND INTERFACE STATUS

2.9 INTERACTIVE COMMANDS

2.9 INTERACTIVE_COMMANDS

Command	Status
RESUME_COMMAND	unchanged
TERMINATE_COMMAND	unchanged
SET_TERMINAL_ATTRIBUTES	unchanged
DISPLAY_TERMINAL_ATTRIBUTES	unchanged
esc-e	new - 1*
esc-l	new - 1*
esc-j	new - 1*
esc-t	new - 1*
esc-x	new - 1*

*1 These commands are entered with the 3-key sequence: escape_key, character, carriage_return. The characters have the following meanings:

- e perform "display_job_status" command
- l perform "display_log 10" command
- j perform "display_job_status all" command
- t discard all unprocessed, typed-ahead input
- x terminate job, but do not disconnect

2.10 OBJECT_CODE_MAINTENANCE

Command	Status
CREATE_OBJECT_LIBRARY	unchanged
DISPLAY_NEW_LIBRARY	unchanged
SELECT_DISPLAY_OPTION	unchanged
ADD_MODULE	unchanged
REPLACE_MODULE	unchanged
COMBINE_MODULE	unchanged
CREATE_MODULE	unchanged
BIND_MODULE	unchanged
CREATE_PROGRAM_DESCRIPTION	unchanged
DELETE_MODULE	unchanged
CHANGE_MODULE_ATTRIBUTE	unchanged
SATISFY_EXTERNAL_REFERENCES	unchanged
REORDER_MODULE	unchanged
GENERATE_LIBRARY	unchanged
DISPLAY_OBJECT_LIBRARY	unchanged
COMPARE_OBJECT_LIBRARY	unchanged
QUIT	unchanged
CI to II Conversion	unchanged

2.0 COMMAND INTERFACE STATUS

2.11 USER SERVICES

2.11 USER_SERVICES

Command	Status
DISPLAY_LOG	unchanged
DISPLAY_MESSAGE	unchanged

2.12 FILE_ROUTING

Command	Status
HCS JMROUTE	removed

2.13 PROGRAM_EXECUTION

Command	Status
SET_PROGRAM_ATTRIBUTES	new - *3
DISPLAY_PROGRAM	unchanged
EXECUTE	unchanged
"name call"	unchanged - *1
TASK/TASKEND	unchanged
TERMINATE_TASK	unchanged
WAIT	unchanged
SET_DEBUG_RING	unchanged
DISPLAY_ACTIVE_TASKS	new - *2

*1 Warning - "name call" works only for SCL procedures unless a SETFA command has been issued to specify that the FILE_CONTENTS are OBJECT and the FILE_ORGANIZATION is DATA or LIBRARY. The SETFA command must be reissued every time the file is brought over from NOS. The CONVERT_OBJECT_FILE, GET_OBJECT_FILE, and GET_OBJECT_LIBRARY nonstandard commands issue the appropriate SET_FILE_ATTRIBUTES command and are therefore recommended.

*2 Replace HCS TSTATUS command.

*3 Replaces SET_OBJECT_LIST and SET_PROGRAM_OPTIONS commands.

2.14 JOB_MANAGEMENT

Command	Status
SUBMIT_JOB	unchanged
DISPLAY_JOB_STATUS	unchanged

NDS/VE Cycle 5 Helpful Hints

07/07/82

 2.0 COMMAND INTERFACE STATUS

2.14 JOB MANAGEMENT

TERMINATE_JOB	unchanged
PRINT_FILE	unchanged
TERMINATE_PRINT	unchanged
DISPLAY_PRINT_STATUS	unchanged

2.15 NDS/VE_COMMANDS_IMPLEMENTED_AS_PROCS

In this build, several NDS/VE commands have been implemented as SCL procedures in order to make the system look more like the final version. Users are urged to use these procedures rather than their interim counterparts since the interim commands will ultimately be withdrawn.

These procedures will be made available via the default system prolog.

2.16 NON-STANDARD_COMMANDS

The following commands provide a nonstandard means of performing various frequently performed functions. They will be superseded in subsequent builds by standard commands and capabilities.

2.16.1 DELETE_CATALOG_CONTENTS : DELCC :

The purpose of this command is to delete all entries from the specified catalog. This includes subcatalogs and the files they contain.

```
delete_catalog_contents [catalog=<catalog>]
                        [status=<status variable>]
```

catalog:c: This parameter specifies from which catalog all files are to be deleted. Omission will cause the current working catalog to be used.

status: See ERROR HANDLING.

07/07/82

2.0 COMMAND INTERFACE STATUS

2.16.2 DISPLAY_ACTIVE_TASK ; DISAT

2.16.2 DISPLAY_ACTIVE_TASK ; DISAT ;

The purpose of this command is to display task statistics for all currently active tasks in a job. The following information is displayed.

```

task name
execution time use
number of page faults

```

```

display_active_task [output=<file>]
                    [status=<status variable>]

```

output: This parameter specifies the file to which the task statistics is displayed. Omission will cause \$OUTPUT to be used.

2.16.3 DISPLAY_SYSTEM_DATA ; DISSD ;

The purpose of this command is to display system page fault statistics and system monitor request statistics.

```

display_system_data [display_option=page_faults!pf
                    ;monitor_requests!mri!all
                    [display_format=incremental!!!total!]
                    [output=<file>]
                    [status=<status variable>]

```

display_option!do: This parameter specifies which statistics are to be displayed. The following options are allowed :

page_faults - display the page fault statistics.

monitor_requests - display the system monitor request statistics.

Omission will cause ALL to be used.

display_format!df: This parameter specifies whether a display of the all statistics recorded so far (total) or only those statistics recorded since the last

.....

2.0 COMMAND INTERFACE STATUS

2.16.3 DISPLAY_SYSTEM_DATA ; DISSD

.....

display_system_data command
(incremental) should be displayed.
Omission will cause incremental to be used.

output: This parameter specifies the file to which the system data will be displayed. Omission will cause \$OUTPUT to be used.

status: See ERROR HANDLING.

2.16.4 DISPLAY_JOB_DATA ; DISJD

The purpose of this command is to display the following job related statistics:

- time in job mode
- time in monitor mode
- count of page in operations
- reclaimed pages
- new pages assigned
- working set size
- count of ready tasks

display_job_data [display_option=job_data]
[display_format=incremental|total]
[output=<file>]
[status=<status variable>]

display_option:do: This parameter specifies which statistics are to be displayed. The following options are allowed:

job_data - display job related data.

Omission will cause job_data to be used.

display_format:df: This parameter specifies whether a display of the all statistics recorded so far (total) or only those statistics recorded since the last display_job_data command (incremental) should be displayed. Omission will cause incremental to be used.

07/07/82

2.0 COMMAND INTERFACE STATUS
2.16.4 DISPLAY_JOB_DATA ! DISJD

output!o: This parameter specifies the file to which the job data will be displayed. Omission will cause \$OUTPUT to be used.
status: See ERROR HANDLING.

2.16.5 DISPLAY_COMMAND_INFORMATION ! DISCI

The purpose of this command is to display current information about a NDS/VE command. The parameter names, abbreviations, allowed values and known problems for a command, as supported in the current system, can be determined. This is a nonstandard command and will be replaced by the help utility sometime in the future.

display_command_information command_name=<name>!all
[utility_name=create_object_library!
col!source_code_utility!scu!system]
[display_option=parameter_description_table!
pdt!notes!names!help]
[output=<file reference>]
[status=<status variable>]

command_name!cn: This parameter specifies the name of the command about which information is to be displayed.

utility_name!un: This parameter specifies which utility the command belongs to. Omission will cause SYSTEM to be used.

display_option!do: This parameter specifies the type of display being requested. The options are:

parameter_description_table!pdt - selects a display of the parameter description table used by the command when executed.

notes - selects a display of any known problems with the command.

names - selects a display of the command names for a utility.

help - selects a display of the command interface description of the command.

2.0 COMMAND INTERFACE STATUS

2.16.5 DISPLAY_COMMAND_INFORMATION ; DISCI

Omission will cause PDT to be used.

outputio: This parameter specifies the file to which information will be displayed. Omission will cause \$OUTPUT to be used.

status: See ERROR HANDLING.

2.16.6 CONVERT_OBJECT_FILE ; CONOF

The purpose of this command is to get a NOS/VE object file produced on NOS and to convert it to an object file suitable for processing by the NOS/VE loader or object code maintenance commands.

```
convert_object_file to=<file reference>
                    [from=<name>]
                    [user=<name>]
                    [status=<status variable>]
```

to:t: This parameter specifies the NOS/VE file name on which the converted object file is to be written.

from:f: This parameter specifies the name of the NOS file to be converted. This is the permanent file name as defined in the NOS file system and can be up to seven characters in length.

Omission will cause the permanent file name of the TO parameter to be used.

user:u: This parameter specifies the NOS user identification of the owner of the file. This parameter is only necessary if the file is in a catalog other than the user who was specified by the most recently issued SET_LINK_ATTRIBUTES command.

status: See ERROR HANDLING.

2.16.7 GET_OBJECT_FILE ; GETOF

The purpose of this command is to get a previously converted NOS/VE object file from the NOS side and sets the appropriate file attributes that will allow the object file to be used by

2.0 COMMAND INTERFACE STATUS

2.16.7 GET_OBJECT_FILE : GETOF

NOS/VE.

```
get_object_file to=<file reference>
                [from=<name>]
                [user=<name>]
                [status=<status variable>]
```

to:t: This parameter specifies the NOS/VE file name of the object file.

from:f: This parameter specifies the NOS file name of the object file. This is the permanent file name as defined in NOS and can be up to seven characters in length.

Omission will cause the permanent file name of the TO parameter to be used.

user:u: This parameter specifies the NOS user identification of the owner of the file. This parameter is only necessary if the file is in a catalog other than the user who was specified by the most recently issued SET_LINK_ATTRIBUTES command.

status: See ERROR HANDLING.

2.16.8 GET_OBJECT_LIBRARY : GETDL

The purpose of this command is to get a previously created NOS/VE object library from the NOS side and set the appropriate file attributes that will allow the object library to be used on NOS/VE.

```
get_object_library to=<file reference>
                  [from=<name>]
                  [user=<name>]
                  [status=<status variable>]
```

to:t: This parameter specifies the NOS/VE file name of the object library.

from:f: This parameter specifies the NOS file name of the object file. This is the permanent file name as defined in NOS and can be up to seven characters in length.

Omission will cause the permanent file name of the

07/07/82

 2.0 COMMAND INTERFACE STATUS

2.16.8 GET_OBJECT_LIBRARY ; GETOL

TO parameter to be used.

user!u: This parameter specifies the NOS user identification of the owner of the file. This parameter is only necessary if the file is in a catalog other than the user who was specified on the most recently issued SET_LINK_ATTRIBUTES command.

status: See ERROR HANDLING.

2.16.9 DISPLAY_OBJECT_TEXT ; DISOT

The purpose of this command is to produce a formatted display of the object text contained in an object file or object library produced on NOS/VE.

display_object_text file=<file>
 [output=<file reference>]
 [status=<status variable>]

file!f: This parameter specifies the object file or object library containing the object text to be listed.

output!o: This parameter specifies the file to which the display is to be written.

Omission will cause the file \$OUTPUT to be used.

status: See ERROR HANDLING.

2.16.10 GET_SOURCE_LIBRARY ; GETSL

The purpose of this command is to get a previously created SCU source library from the NOS side and set the appropriate file attributes that will allow the source library to be used on NOS/VE.

get_source_library to=<file reference>
 [from=<name>]
 [user=<name>]
 [status=<status variable>]

to!t: This parameter specifies the NOS/VE file name of the source library.

2.0 COMMAND INTERFACE STATUS

2.16.10 GET_SOURCE_LIBRARY ; GETSL

from!f: This parameter specifies the NOS file name of the source library. This is the permanent file name as defined in NOS and can be up to seven characters in length.

Omission will cause the permanent file name of the TO parameter to be used.

user!u: This parameter specifies the NOS user identification of the owner of the file. This parameter is only necessary if the file is in a catalog other than the user who was specified on the most recently issued SET_LINK_ATTRIBUTES command.

status: See ERROR HANDLING.

2.16.11 EDIT_FILE ; EDIF

The purpose of EDIT_FILE is to initiate the execution of the SCU editor on a text file. (For details see ARH3883.)

edit_file ; edif - edit lines on a source file. (procedure file not necessarily in its final form)

parameters	defaults
file=file(source)	\$REQUIRED
[result=file(source)]	\$VALUE(FILE)
[input=file reference]	\$COMMAND
[output=file reference]	\$OUTPUT
[status]	--

2.16.12 JEDIT

The purpose of this command is to initiate execution of the JEDIT editor built by Jack Bohnhoff. Anyone wanting information about the editor should contact Jack.

Jedit from=<file>
[status=<status variable>]

from!f: This parameter specifies the file to be edited. This file is rewritten after the editor terminates.

NDS/VE Cycle 5 Helpful Hints

07/07/82

2.0 COMMAND INTERFACE STATUS

2.16.12 JEDIT

status: See ERROR HANDLING in the NOS/VE Command Interface.

2.16.13 DEBUG

The prototype R1 NOS/VE debugger is now available. Details on how to use the debugger can be found in the "CYBER 180 INTERACTIVE DEBUG External Reference Specification and User's Guide", Sunnyvale DCS number S4028.

2.16.14 SET_LINK_ATTRIBUTES ; SETLA

The SET_LINK_ATTRIBUTES command is the same as documented in the NOS/VE command interface with the exception that the CHARGE and PROJECT parameters are optional (and in fact not useful in the current environment since we disable that feature on the NOS side).

3.0 PROGRAM INTERFACE STATUS

3.0 PROGRAM_INTERFACE_STATUS

The 'status' column indicates whether the procedure is unchanged from the previous build, modified from the previous build or not available in this build. Footnotes are numbered within each section.

3.1 COMMAND_PROCESSING

Procedure	Status
CLP\$SCAN_PARAM_LIST	unchanged
CLP\$TEST_PARAMETER	unchanged
CLP\$GET_KEYWORD	unchanged
CLP\$GET_SET_COUNT	unchanged
CLP\$GET_VALUE_COUNT	unchanged
CLP\$TEST_RANGE	unchanged
CLP\$GET_VALUE	unchanged
CLP\$CREATE_VARIABLE	updated to ERS Rev. 8
CLP\$DELETE_VARIABLE	updated to ERS Rev. 8
CLP\$READ_VARIABLE	updated to ERS Rev. 8
CLP\$WRITE_VARIABLE	updated to ERS Rev. 8
CLP\$SCAN_COMMAND_FILE	unchanged
CLP\$END_SCAN_COMMAND_FILE	unchanged
CLP\$SCAN_COMMAND_LINE	unchanged
CLP\$CREATE_FILE_CONNECTION	unchanged
CLP\$DELETE_FILE_CONNECTION	unchanged
CLP\$PUSH/POP_UTILITY	unchanged
CLP\$GET_COMMAND_ORIGIN	unchanged
CLP\$GET_DATA_LINE	unchanged
CLP\$SCAN_PROC_DECLARATION	unchanged

3.2 MESSAGE_GENERATOR

Procedure	Status
DSP\$FORMAT_MESSAGE	unchanged
DSP\$SET_STATUS_ABNORMAL	unchanged
DSP\$APPEND_STATUS_PARAMETER	unchanged
DSP\$APPEND_STATUS_INTEGER	unchanged

07/07/82

3.0 PROGRAM INTERFACE STATUS

3.3 RESOURCE MANAGEMENT

3.3 RESOURCE MANAGEMENT

Procedure	Status
RMP\$REQUEST_MASS_STORAGE	unchanged
RMP\$REQUEST_TERMINAL	unchanged

All terminal attributes can be specified on the RMP\$REQUEST_TERMINAL call but only the following are operational:

- o auto_input
- o transparent_mode
- o prompt_file
- o prompt_string

Files assigned to a terminal device can be accessed via the following BAM requests:

- o AMP\$OPEN
- o AMP\$GET_NEXT
- o AMP\$GET_DIRECT
- o AMP\$GET_PARTIAL
- o AMP\$PUT_NEXT
- o AMP\$PUT_DIRECT
- o AMP\$PUT_PARTIAL
- o AMP\$CLOSE
- o AMP\$REWIND
- o AMP\$SKIP
- o AMP\$SEEK_DIRECT

3.4 PROGRAM EXECUTION

Procedure	Status
PMP\$EXIT	unchanged
PMP\$EXECUTE	unchanged
PMP\$TERMINATE	unchanged
PMP\$AWAIT_TASK_TERMINATION	unchanged
PMP\$MODULE_TABLE_ADDRESS	unchanged
PMP\$ENTRY_POINT_TABLE_ADDRESS	unchanged
PMP\$PUSH_TASK_DEBUG_MODE	unchanged
PMP\$SET_TASK_DEBUG_MODE	unchanged
PMP\$TASK_DEBUG_MODE_ON	unchanged
PMP\$SET_DEBUG_RING	unchanged
PMP\$DEBUG_RING	unchanged
PMP\$CHANGE_DEBUG_LIBRARY_LIST	unchanged
PMP\$POP_TASK_DEBUG_MODE	unchanged

07/07/82

.....

3.0 PROGRAM INTERFACE STATUS

3.5 PROGRAM COMMUNICATION

.....

3.5 PROGRAM_COMMUNICATION

<u>Procedure</u>	<u>Status</u>
OSP\$AWAIT_ACTIVITY_COMPLETION	unchanged
PMP\$DEFINE_QUEUE	unchanged
PMP\$REMOVE_QUEUE	unchanged
PMP\$CONNECT_QUEUE	unchanged
PMP\$DISCONNECT_QUEUE	unchanged
PMP\$SEND_TO_QUEUE	unchanged
PMP\$RECEIVE_FROM_QUEUE	unchanged
PMP\$STATUS_QUEUE	unchanged
PMP\$STATUS_QUEUES_DEFINED	unchanged
PMP\$GET_QUEUE_LIMITS	unchanged

3.6 CONDITION_PROCESSING

<u>Procedure</u>	<u>Status</u>
PMP\$ESTABLISH_CONDITION_HANDLER	Added support of detected uncorrected error
PMP\$DISESTABLISH_COND_HANDLER	unchanged
PMP\$CAUSE_CONDITION	unchanged
PMP\$CONTINUE_TO_CAUSE	unchanged
PMP\$TEST_CONDITION_HANDLER	unchanged
PMP\$VALIDATE_PREVIOUS_SAVE_AREA	unchanged
PMP\$ESTABLISH_DEBUG_OFF	unchanged
OSP\$SET_STATUS_FROM_CONDITION	unchanged

3.7 PROGRAM_SERVICES

<u>Procedure</u>	<u>Status</u>
PMP\$GENERATE_UNIQUE_NAME	unchanged
PMP\$GET_TIME	unchanged
PMP\$GET_MICROSECOND_CLOCK	unchanged
PMP\$GET_TASK_CP_TIME	unchanged
PMP\$GET_DATE	unchanged
PMP\$GET_USER_IDENTIFICATION	unchanged
PMP\$GET_ACCOUNT_PROJECT	unchanged
PMP\$GET_JOB_NAMES	unchanged
PMP\$GET_JOB_ID	unchanged
PMP\$GET_JOB_MODE	unchanged
PMP\$GET_PROGRAM	unchanged
PMP\$GET_TASK_ID	unchanged
PMP\$MANAGE_SENSE_SWITCHES	unchanged
PMP\$GET_OS_VERSION	unchanged

3.0 PROGRAM INTERFACE STATUS

3.7 PROGRAM SERVICES

```

PMP$GET_PROCESSOR_ATTRIBUTES      unchanged
PMP$DEFINE_DEBUG_ENTRY           unchanged
PMP$GET_DEBUG_ENTRY              unchanged
PMP$MODIFY_DEBUG_ENTRY           unchanged
PMP$REMOVE_DEBUG_ENTRY          unchanged
    
```

3.8 LOGGING

<u>Procedure</u>	<u>Status</u>
PMP\$LOG	unchanged
PMP\$LOG_ASCII	unchanged

3.9 FILE_MANAGEMENT

<u>Procedure</u>	<u>Status</u>
Sequential Access	unchanged
Byte_Addressable Access	unchanged
Record Access	unchanged
Segment Access	unchanged - *1
V_System Specified	unchanged
V_User Specified	unchanged
U_System Specified	unchanged
U_User Specified	unchanged
F_System Specified	unchanged
F_User Specified	unchanged
AMP\$DESCRIBE_NEW_FILE	deleted
AMP\$FILE	unchanged
AMP\$GET_FILE_ATTRIBUTES	unchanged
AMP\$FETCH	unchanged
AMP\$STORE	unchanged
AMP\$COPY_FILE	unchanged
AMP\$RENAME	unchanged
AMP\$RETURN_FILE	new name
AMP\$OPEN	unchanged
AMP\$CLOSE	unchanged
AMP\$FETCH_ACCESS_INFORMATION	unchanged
AMP\$SKIP	unchanged
AMP\$REWIND	*2
AMP\$WRITE_END_PARTITION	unchanged
AMP\$GET_NEXT	unchanged
AMP\$GET_DIRECT	unchanged
AMP\$GET_PARTIAL	unchanged
AMP\$PUT_NEXT	unchanged
AMP\$PUT_DIRECT	unchanged
AMP\$PUT_PARTIAL	unchanged - *3

NOS/VE Cycle 5 Helpful Hints

07/07/82

3.0 PROGRAM INTERFACE STATUS

3.9 FILE MANAGEMENT

AMP\$SEEK_DIRECT	unchanged
AMP\$GET_SEGMENT_POINTER	unchanged
AMP\$SET_SEGMENT_EOI	unchanged
AMP\$SET_SEGMENT_POSITION	unchanged
AMP\$SET_LOCAL_NAME_ABNORMAL	unchanged
AMP\$SET_FILE_INSTANCE_ABNORMAL	unchanged
AMP\$ACCESS_METHOD	unchanged
AMP\$FETCH_FAP_POINTER	unchanged
AMP\$STORE_FAP_POINTER	unchanged

- *1 Segment access If a segment access file is written and an AMP\$SET_SEGMENT_EOI is not issued to record the EOI, EOI remains zero. The highest page referenced is not yet used as the default EOI. This particularly affects those who wish to make heaps permanent because EOI is always zero for a heap.
- *2 AMP\$REWIND The WAIT parameter on the procedure call is not supported.
- *3 AMP\$PUT_PARTIAL PUT_PARTIAL with the TERM_OPTION = AMC\$TERMINATE does not act as a put_next if a preceding START was not issued.

3.10 PERMANENT_FILE_MANAGEMENT

Procedure	Status
PFP\$DEFINE	updated to ERS Rev. 9
PFP\$ATTACH	updated to ERS Rev. 9
PFP\$PURGE	updated to ERS Rev. 9
PFP\$CHANGE	updated to ERS Rev. 9
PFP\$PERMIT	updated to ERS Rev. 9
PFP\$DELETE_PERMIT	updated to ERS Rev. 9
PFP\$DEFINE_CATALOG	updated to ERS Rev. 9
PFP\$PURGE_CATALOG	updated to ERS Rev. 9
PFP\$PERMIT_CATALOG	updated to ERS Rev. 9
PFP\$DELETE_CATALOG_PERMIT	updated to ERS Rev. 9

3.11 MEMORY_MANAGEMENT

MMP\$ADVISE_IN	unchanged
MMP\$ADVISE_OUT	unchanged
MMP\$ADVISE_OUT_IN	unchanged
MMP\$WRITE_MODIFIED_PAGES	unchanged
MMP\$CREATE_SEGMENT	unchanged
MMP\$DELETE_SEGMENT	unchanged
MMP\$STORE_SEGMENT_ATTRIBUTES	unchanged
MMP\$FETCH_SEGMENT_ATTRIBUTES	unchanged

NDS/VE Cycle 5 Helpful Hints

07/07/82

3.0 PROGRAM INTERFACE STATUS

3.11 MEMORY MANAGEMENT

MMP\$VERIFY_ACCESS	unchanged
MMP\$FREE	unchanged
MMP\$LOCK_PAGES	number of locked pages per
MMP\$UNLOCK_PAGES	segment restricted to 32
MMP\$FETCH_PVA_UNWRITTEN_PAGES	unchanged

3.12 STATISTICS FACILITY

SFP\$ESTABLISH_STATISTIC	unchanged
SFP\$ENABLE_STATISTIC	unchanged
SFP\$DISABLE_STATISTIC	unchanged
SFP\$DISESTABLISH_STATISTIC	unchanged
SFP\$EMIT_STATISTIC	unchanged
SFP\$EMIT_SYSTEM_STATISTIC	unchanged

3.13 INTERACTIVE FACILITY

IFP\$TERMINAL	unchanged
IFP\$FETCH_TERMINAL	unchanged
IFP\$STORE_TERMINAL	unchanged
IFP\$GET_DEFLT_TERMINAL_ATTRIBUTES	unchanged
IFP\$GET_TERMINAL_ATTRIBUTES	unchanged
IFP\$ADVANCE	new - *1

*1 Only the option IFC\$ADVANCE_ALL_QUEUED_OUTPUT is supported.

3.14 NDS/VE EXCEPTIONS

The following summarizes the exception code ranges currently assigned to NDS/VE. These code ranges represent a finer breakdown than the one specified in the SIS for internal NDS/VE development purposes. However, it is important to remember that only the product identifiers documented in the SIS may appear in error messages.

Common Modules	9,000 - 9,999
Common Code Generator	8,000 - 8,999

Exception Code	Product Identifier	Product Name
1 - 158,999	Reserved	
159,000 - 159,999	SY	System Core
160,000 - 169,999	AM	Basic Access Methods
160,000 - 163,999	BA	Basic Access

NDS/VE Cycle 5 Helpful Hints

07/07/82

3.0 PROGRAM INTERFACE STATUS

3.14 NDS/VE EXCEPTIONS

164,000 - 164,999	LN	Local Name Mgr
165,000 - 165,999	JF	Job File Mgr
166,000 - 166,999	SR	Conversion Services
167,000 - 167,999	CM	Configuration Mgmt
170,000 - 179,999	CL	Command Language
180,000 - 189,999	JM	Job Management
190,000 - 199,999	LL	Loader
200,000 - 209,999	MM	Memory Management
200,000 - 204,999	MM	Monitor Level
205,000 - 205,999	MM	Task Level
210,000 - 219,999	OS	Operating System
210,000 - 210,999	OS	OS
211,000 - 211,999	MT	EXEC
212,000 - 212,999	ID	MS I/O
213,000 - 213,999	ID	Tape I/O
214,000 - 214,999	DM	Device Management
215,000 - 215,999	ML	Memory Link
216,000 - 216,999	IF	Interactive
217,000 - 217,999	TM	TM Monitor
218,000 - 218,999	TM	TM Task
219,000 - 219,999	JS	Job Swappers
220,000 - 229,999	PF	Permanent File Management
221,000 - 221,999	ST	Set Management
222,000 - 222,999	PU	Permanent File Utilities
230,000 - 239,999	PM	Program Management
240,000 - 249,999	RM	Resource Management
250,000 - 259,999	OF	Operator Facility
260,000 - 269,999	AV	User Administrator
270,000 - 279,999	IC	Interstate Communication
280,000 - 289,999	RH	Remote Host Facility
290,000 - 299,999	OC	Object Code Utilities
300,000 - 309,999	DB	Deadstart/Recovery
310,000 - 319,999	MS	Maintenance Services
320,000 - 329,999	Reserved	
340,000 - 349,999	SF	Statistics Fac.
330,000 - 339,999	US	User Errors
500,000 - 509,999	AA	Advanced Access Method
510,000 - 519,999	AG	ALGOL
520,000 - 529,999	AL	Assembly Language
530,000 - 539,999	AP	APL
540,000 - 549,999	BA	BASIC
550,000 - 559,999	CA	Conversion Aids System
560,000 - 569,999	CB	COBOL
570,000 - 579,999	CY	CYBIL
580,000 - 589,999	FT	FORTRAN
590,000 - 599,999	PA	PASCAL (Wirth)
600,000 - 609,999	PI	PL/1
610,000 - 619,999	SM	Sort Merge

NDS/VE Cycle 5 Helpful Hints

07/07/82

3.0 PROGRAM INTERFACE STATUS

3.14 NDS/VE EXCEPTIONS

620,000 - 629,999	SC	Source Code Utility
640,000 - 649,999	DB	Debug

λ

NOS/VE Cycle 5 Helpful Hints

07/07/82

4.0 DUAL STATE DEADSTART AND OPERATION

4.0 DUAL_STATE_DEADSTART_AND_OPERATION

4.1 CURRENT_DUAL_STATE_CONFIGURATION

The Arden Hills S2 development systems are configured to run with three FMD units.

o FMD Unit 43

This unit contains the following:

- A170 NOS (5.3 as released), CTI, MSL, EI binaries, NOS deadstart files
- Files associated with user name LIBRARY
- Files associated with user name SES
- Files associated with DEV1, DEV2, REL1, INT1.

o FMD Unit 41

This unit contains the following:

- Files required to deadstart dual state Cycle 3; A170 NOS (5.3 plus changes necessary for Cycle 3), CTI, MSL, EI binaries, and NOS Deadstart files.
- It is also used as a temp device.

o FMD Unit 42

This unit contains the following:

- NOS/VE Development Area PL's and Member PL's
- NOS/VE Deadstart Files to be tested (saved in individual user's catalogs)
- Files associated with user name INT2

o FMD Unit 44

This is another NOS PF device.

o FMD Unit 45

This is another NOS temp device.

07/07/82

 4.0 DUAL STATE DEADSTART AND OPERATION

4.2 USER NAMES AND PERMANENT FILES

4.2 USER_NAMES_AND_PERMANENT_FILES

- 1) The convention used for creating user names on NOS/VE is as follows:
 - o Your user name will be your initials.
 - o Your password will be these 3 letters followed by the letter 'x'.
 - o You must see COMSOURCE (R.K. Cooper - x3092) to be assigned a user index
- 2) PF dumping and loading

You may use "SES.DUMPPF" on SN/101 to dump your permanent files to tape, and then load them onto your user name on A170 NOS using "SES.LOADPF". Documentation on how to use these SES procedures and what their parameters are is included in the SES User's Guide, or they can be obtained by typing:

SES,HELP.DUMPPF and SES,HELP.LOADPF.

4.3 ID_RELOAD_CONTROLWARE_FOR_THE_NOS/VE_DISK_DRIVER

At deadstart time NOS will automatically load 7155-1x disk controlware on one channel with controller type=FM (LBC CMRdeck entry), and will automatically load 7155-4x disk controlware on any channel with controller type=HT (LBC CMRdeck entry). NOS/VE supports both of those types of controllers. NOTE: It is not possible to use 844 half-track controlware in this environment.

4.4 A170_NOS_DEADSTART

4.4.1 CTI AND CHECKING CENTRAL MEMORY

Deadstarting A170 NOS assumes some knowledge of CTI. CTI stands for Common Test and Initialization. It is software that places an 800 series machine in a state such that it is possible to deadstart an operating system. CTI is used somewhat ambiguously in the software community to imply CTI and MSL (Maintenance Software Library). The MSL is a collection of programs and data that includes such things as a subset of CMSE (Cyber Maintenance Software Executive) that enables one to load controlware to controllers, look at CYBER 180 maintenance

NDS/VE Cycle 5 Helpful Hints

07/07/82

4.0 DUAL STATE DEADSTART AND OPERATION

4.4.1 CTI AND CHECKING CENTRAL MEMORY

registers, look at microcode, etc. The MSL also contains microcode that can be loaded by CTI. The MSL is actually an operating system that runs independently of NDS. An important element of CTI/MSL is HIVS (Hardware Verification Sequence), which is a program that loads microcode, clears and checks central memory and tests all 170 opcodes. If you are not sure what the machine was used for (particularly the first hands on user each morning) then the HIVS program should be run. This is accomplished by:

- 1) deadstart to NDS/VE (unit 40 for S3, unit 41 for S2)
- 2) Enter O (operator intervention)
- 3) Enter P (deadstart panel, make sure level 0 deadstart)
- 4) <BKSP>
- 5) Enter H (assure yourself that CS=YES to reload microcode)
- 6) <BKSP>
- 7) Enter V (verification sequence)
- 8) Hit <CR> at 'parameter display' to test CM & CP

When you see text that tells you that verification is complete and a deadstart is required, you are now ready to deadstart NDS.

4.4.2 NDS DEADSTART

See Section 3.3 of the Integration Procedures Notebook for important NDS CMRDECK changes.

- o Set the D/S panel to deadstart from the primary system disk. This is Unit 41 for all Cycle 2 systems.
- o Push D/S button
- o Enter (CR)
- o Enter date/time

Wait for deadstart to complete.

Note: The deadstart tape DUAL34 (which is currently installed on unit 41) is found in the area in the northeast corner of the S2 lab where the tape cabinet is found.

NOS/VE Cycle 5 Helpful Hints

07/07/82

4.0 DUAL STATE DEADSTART AND OPERATION

4.4.3 INITIALIZING AN 855 (S3)

4.4.3 INITIALIZING AN 855 (S3)

If an 855 is powered down (processor) it may be impossible to deadstart or even run the HIVS program. The reason is that powering up does not master clear the maintenance channel. This is a known problem and is being addressed by CDED. The way to solve this problem currently is to use the CMSE equivalent of the HIVS program. That program can be executed by performing an alternate deadstart to the engineer's/CE's CMSE pack, entering M (to select maintenance), entering a CR at the menu screen, and then entering 'GO INIT39'. INIT39 is a CMSE command buffer and will require about 2 to 3 minutes to complete. When the display shows a 'TB' (terminate buffer) the initialization is complete. The 39 stands for a microcode cycle, i.e. the 855 is currently using cycle 39 microcode.

4.5 NOS/VE_DEADSTART_AND_INSTALLATION

- o Enter DOWN,CH2. so NOS/VE can use the channel.
- o Enter DOWN,CH32. so NOS/VE can use the channel.
- o The following file must be available in your catalog on the S2:

TPXXXK contains a NOS/VE deadstart image. This must be a copy of the dual state deadstart images available from the link procedures.

- o If you've never deadstarted NOS/VE from the user number from which you want to run or if you wish to change the current parameter settings for your particular user number, then do a SETVE. SETVE assumes the file TPXXXK is in your user number; you do not have to do another SETVE if TPXXXK has changed since the last time you ran. The general form of SETVE is:

X.SETVE(PN=ffff,UN=un,C=6)

where ffff is an identifier of up to 4 characters and un is the user number to search first for files. 6 is the number of the system core command deck for the Arden Hills configuration. In general ffff and un will be the same, e.g. X.SETVE(DAH,UN=DAH,C=6)

**Only ONE SETVE should be done for each user number and a SETVE should NOT be done for ANY Integration user number

NDS/VE Cycle 5 Helpful Hints

07/07/82

 4.0 DUAL STATE DEADSTART AND OPERATION

4.5 NDS/VE DEADSTART AND INSTALLATION

except by the Integration project.**

SEE SECTION 5.1 FOR MORE DETAILS.

- o Bring up dual state:

N.NVEffff.

where n is any control point number except 1,2 and the BATCHIO, MAGNET & SYSTEM control points and ffff is the Identifier specified in SETVE, e.g. 4.NVEINT1.

- o Bring up the Operator Facility

Enter k,n - where n is the control point of the NVE Job. ;

NDS/VE is currently generated and initialized on both NOS and NOS/VE. All source and object libraries that make up the NOS/VE system are produced on NOS and therefore must be converted from their CI to II counterparts. Other parts of installing and initializing the system (e.g. building the \$SYSTEM catalog) are performed by command language procedures on NOS/VE. Since the same system will many times in a closed shop environment, it is advantageous to only perform the conversion from CI to II a single time; save the results in the NOS file system and then simply bring the files back during deadstart.

The actual files that get installed and loaded on each deadstart are determined by a command language procedure (the system profile) interpreted on NOS/VE. This procedure can be modified by each site to initialize their NOS/VE environment in the most suitable fashion. The process of building the system profile and of performing the CI to II conversions is referred to as an installation deadstart and the process of executing the system profile and of fetching previously converted files from NOS and making them available in the NOS/VE file system is referred to as a deadstart. A single command is available to perform both an installation deadstart and a deadstart.

4.5.1 THE DS PROCEDURE

The purpose of this command is to perform an installation, normal or recovery deadstart of NOS/VE. The defaults for parameters are those most convenient for "closed shop" deadstarts.

07/07/82

4.0 DUAL STATE DEADSTART AND OPERATION

4.5.1 THE DS PROCEDURE

The procedure "brings up" the job log display on the left screen where the progress of the procedure may be watched, and the control point display on the right screen. Just before the procedure changes the left screen to display the system log and writes to that log the message:

```
'----- Deadstart Completed -----'
```

at which point the operator may enter commands.

```
ds [kind=install ; normal ; recover]
   [get_source_libraries=<boolean>]
   [get_products=<boolean>]
   [echo=<boolean>]
   [alternate_user=<NOS_user_name>]
   [save_install_files=<boolean>]
   [validate_users=<boolean>]
   [quick_validate=list of <name>]
   [debug=<boolean>]
   [help=<file reference>]
   [status=<status variable>]
```

kind ; k: This parameter specifies what kind of deadstart is to be performed. Valid specifications are:

install ; i - installation deadstart to be performed. The system libraries are built from CI object files.

normal ; n - normal deadstart to be performed. The system libraries are obtained from the results of a previous installation deadstart.

recover ; r - recovery deadstart. Just initiates system tasks. Permanent files are "recovered" from a previous run of the system.

Omission will cause a recovery deadstart to be performed.

get_source_libraries ; gsl: This parameter specifies whether SCU libraries are to be installed. Valid specifications are:

true ; yes ; on - libraries are to be installed

false ; no ; off - libraries are not to be installed

NDS/VE Cycle 5 Helpful Hints

07/07/82

4.0 DUAL STATE DEADSTART AND OPERATION

4.5.1 THE DS PROCEDURE

On the Arden Hills closed shop S2 system, the SCU libraries to be installed are:

DSFPIL -> DSF\$PROGRAM_INTERFACE_LIBRARY: operating system program interface

DSFSL -> DSF\$SOURCE_LIBRARY: subset of operating system source library

Omission will cause SCU libraries to be installed.

get_products ; gp: This parameter specifies whether the object libraries defining the current product set are to be installed. Valid specifications are:

true ; yes ; on - the products are to be installed

false ; no ; off - the products are not to be installed

On the Arden Hills closed shop S2 system, the product set to be installed consists of:

CYFIIC -> CYF\$COMPILER: cybil II compiler

CCFRTL -> CCF\$RUN_TIME_LIBRARY: common compiler modules run time library

MLFRTL -> MLF\$RUN_TIME_LIBRARY: math run time library

DBFDL -> DBF\$DEBUG_LIBRARY: symbolic debug library

SCFOL -> SCF\$OBJECT_LIBRARY: source code utility

SCFCL -> SCF\$COMMAND_LIBRARY: source code utility "stand-alone" command library

IFFEDIT -> IFF\$EDITOR: Jack Bohnhoff's editor (JEDIT)

Omission will cause the product set to be installed.

echo ; e: This parameter specifies whether the commands should be echoed to the console during execution. Valid specifications are:

true ; yes ; on - echo commands ;

false ; no ; off - do not echo commands

Omission will cause commands not to be echoed.

NOS/VE Cycle 5 Helpful Hints

07/07/82

 4.0 DUAL STATE DEADSTART AND OPERATION

4.5.1 THE DS PROCEDURE

alternate_user ; au: This parameter specifies what NOS user to check if the default NVE user does not have the needed file. Any NOS user name is allowed.

Omission will cause INT1 to be used.

save_install_files ; sif: This parameter specifies whether to save the system libraries created by an installation deadstart. This parameter is ignored for a normal or recovery deadstart. Valid specifications are:

true ; yes ; on - save the installed system libraries ;

false ; no ; off - do not save the installed system libraries

Omission will cause the files not to be saved.

validate_users ; vu: This parameter specifies whether to run the job that validates NOS/VE users. This parameter is ignored for a recovery deadstart. Valid specifications are:

true ; yes ; on - run the validation job ;

false ; no ; off - do not run the validation job

Omission will cause the validation job to be run.

quick_validate ; qv: This parameter determines which users will be validated by the validation job if it is run. When specified, this parameter gives a list of user names to be validated in addition to the users: INT1, INT2, DEV1, DEV2, REL1, EVAL and RKC.

Omission will cause all users to be validated.

debug ; d: This parameter specifies whether the procedure should abort if an error condition is detected. Valid specifications are:

true ; yes ; on - do not abort on an error. The user will be prompted for commands in the event of an error at which time entering "continue" will cause processing to resume. ; ; ; ;

false ; no ; off - abort on an error

Omission will cause the procedure to abort when an

NOS/VE Cycle 5 Helpful Hints

07/07/82

4.0 DUAL STATE DEADSTART AND OPERATION

4.5.1 THE DS PROCEDURE

error is encountered.

help : h: This parameter specifies whether help information is to be written. If this parameter is specified, the help information will be written to the specified file and the procedure will terminate.

Omission will cause the procedure to execute and the help information not to be written.

status: See ERROR HANDLING in the NOS/VE ERS.

If you change any of the following decks you MUST use the installation deadstart from your own catalog (with files CYBILGO, XLJOCM, XLJOSL, XLJLIB and XLJEC), or you must use the alternate_user parameter to specify a NOS catalog containing the files (e.g. DEV1).

```

AVMUTIL CLMDP  DMMDISA ICMCLOS ICMFAI  ICMFAPC ICMFLSH ICMGET
  ICMOPEN ICMPUT  ICMWEDP IFMEXEC IIMA72H IIMDC2S IIMRLE
IIMRSE  IIMRUM  IIMRUSM IIMTDEL OCMADD  OCMBIM  OCMBIM  OCMCDL
  OCMCOM  OCMCPY  OCMCRM  OCMDEF  OCMDEL  OCMDLB  OCMONL
OCMDOL  OCMEND  OCMGEN  OCMLCH  OCMLMG  OCMLP  OCMNUR
OCMNP  OCMOBJ  OCMOFH  OCMOMS  OCMRCH  OCMRED  OCMREP  OCMRMB
  OCMSAT  OCMSOL  OCMVEL  OCMVLU  OCMVOL  PFMDC  PFMTALL
PUMBCAT PUMBCYC PUMBFIL PUMBFO  PUMBLST PUMBPF  PUMBSET
PUMCDMN PUMCRAK PUMPURG PUMCRAK PUMIOBF PUMLIST PUMMISC
PUMPURG PUMRALL PUMRCAT PUMREC  PUMREF  PUMRFIL PUMRPF
PUMSTUB RHMLML RHMQAT RHMQOP  RHMQR  RHMSFM USORT  UTMDUR
  UTMPC1  UTMPC2  UTMPC3  UTMPC4  UTMPC5  UTMTSA  UUSER1

```

4.5.2 EXAMPLE OF NOS/VE INSTALLATION DEADSTART

Type

```

K,n.      where n is the NVE control point number.
K.SETLA (your_un,NVE) your_password
K.GETF DS U=scat
K.DS INSTALL GSL=NO GP=NO AU=scat

```

4.5.3 EXAMPLE OF NOS/VE "NORMAL" DEADSTART

The Integration system has had the installation deadstart run on it. Also the files produced by the installation deadstart have been made semi-private and are found on the catalog used in the NVExxxx call.

NDS/VE Cycle 5 Helpful Hints

07/07/82

4.0 DUAL STATE DEADSTART AND OPERATION

4.5.3 EXAMPLE OF NDS/VE "NORMAL" DEADSTART

Type (where DEV1 is the same as the xxxx in the NVExxxx call):

```
K,n.      where n is the NVE control point number.      ;
K.SETLA (DEV1,NVE) DEV1X
K.GETF DS
K.DS NORMAL
```

4.5.4 EXAMPLE OF NDS/VE RECOVERY DEADSTART

This is the kind of deadstart that should most frequently be done in a "closed shop" environment and consequently is the one for which all the parameter defaults are oriented. It presupposes that permanent file recovery has been successful.

Type (where DEV1 is the same as the xxxx in the NVExxxx call):

```
K,n.      where n is the NVE control point number.      ;
K.SETLA (DEV1,NVE) DEV1X
K.GETF DS
K.DS
```

4.5.5 EXAMPLE OF MINIMAL NDS/VE DEADSTART

The minimal deadstart shown below may be useful to DS developers who need to get the system up quickly and do not need the product set or all validated users.

Type

```
K,n.      where n is the NVE control point number.      ;
K.SETLA (your_un,NVE) your_password
K.GETF DS U=scat
K.DS NORMAL GSL=NO GP=NO QV=your_un AU=scat
```

4.5.6 USE OF THE QUICK_DEADSTART COMMAND

This command is intended as a development tool to facilitate 'fast' deadstarts where recovery is not needed; indeed, if this command is entered recovery_will_not_be_performed when the system is brought down for whatever reason. Specifying this command will cause an installation deadstart to take place. If the INITDD command is not specified then a default value of 'VSN001' is used for the system deadstart device. Use of INITDD will allow setting the

NOS/VE Cycle 5 Helpful Hints

07/07/82

4.0 DUAL STATE DEADSTART AND OPERATION

4.5.6 USE OF THE QUICK_DEADSTART COMMAND

deadstart devices identifier to any value. THIS COMMAND WILL NOT BE ACCEPTED FROM A DEADSTART COMMAND FILE.

Format: QUICKDS or QUICK_DEADSTART

Values: The default is false. Executing this command causes this initial value to be toggled, thus executing this command twice will cause the final value to be false.

Note: QUICK_TEMPLATE_LOAD does not exist now.

4.6 NOS/VE_INTERACTIVE_FACILITY_OPERATION

4.6.1 OPERATOR INITIATION

To bring up the NOS/VE interactive facility do the following:

- 1) Bring up NOS/VE.
- 2) Bring up NAM

At the system console enter:

3.NAMS2. for S2
3.NAMS3. for S3

- 3) If IAF is not up at control point 1, enter:

IAF. ;

4.6.2 OPERATOR TERMINATION

To terminate NOS/VE interactive any of the following may be done:

- 3.CFD.DI,AP=TAF. (3 is the NAM control point number)

This is the preferred method. To bring NOS/VE interactive back up, you must first do a 3.CFD.EN,AP=TAF.

- 3.CFD.DI,NE. (3 is the NAM control point number)

This terminates the entire network including IAF, RBF, etc.

NDS/VE Cycle 5 Helpful Hints

07/07/82

4.0 DUAL STATE DEADSTART AND OPERATION

4.6.3 OTHER OPERATOR CAPABILITIES

4.6.3 OTHER OPERATOR CAPABILITIES

- To logically turn the printer on, under DSD enter:
 - DN33.
 - FORM33, TM.
- To send a "shutdown warning" to all terminals logged on to TAF do:
 - 3.CFD.ID, AP=TAF. (3 is the NAM control point number)
- To send a message to all terminals do:
 - 3.CFD.MSG, ALL, message. (3 is the NAM control point number)
- PASSON has the ability to record various types of diagnostic information. This capability is controlled via the sense switches at the PASSON control point. To turn a sense switch on (off) at control point N do:
 - N.ONSWX. (N.OFFSWX.)

Where X is the desired sense switch (1 to 6). The PASSON default is all sense switches off. It will take a short period of time before PASSON detects a change in a sense switch and reacts to it. The sense switches currently used by PASSON are:

switch_#	use
1	Network Trace
2	PASSON Logic Trace To Dayfile
3	Memory Link Trace To Dayfile

4.7 NOS/VE_OPERATOR_FACILITY_AND_OPERATOR_COMMANDS

With the release of the Operator Facility Phase 1 several changes to the NOS/VE Operating System will occur that will effect the users of the NOS/VE Operators Console. The Operator Facility runs as part of the NVE control point. When the request for K display appears on the NOS B Display, assign the K Display to the NVE control point. The Operator Facility is capable of displaying both a left and a right screen area at the same time. If the operator wants both screens then

NOS/VE Cycle 5 Helpful Hints

07/07/82

 4.0 DUAL STATE DEADSTART AND OPERATION

 4.7 NOS/VE OPERATOR FACILITY AND OPERATOR COMMANDS

type in KK. The contents of these displays are determined by the commands entered by the operator.

The left screen is divided into four different areas. The top most area is the system header which contains the current date and time, memory statistics, and an operator action message if one is posted. The operator action will include the job sequence number of the owner of the message and 'message cancelled' if the message is cancelled because the task has terminated. The next line contains the first 64 characters of the operator action message (60 characters in stand alone).

The next area of the screen is the main output area. This area has the file name of OUTPUT. Any display command can have its output directed to this area as well as any system command.

The third area is towards the bottom of the screen. This area is two lines long and contains the response area. This will contain error messages from system commands. The area is cleared when the next operator typein is entered at the operator's console and received by NOS/VE.

The fourth area is the prompt area. This will contain the status of the keyboard. If NOS/VE is processing a command, then the keyboard is locked and all typeins will be ignored. When the keyboard is locked, the message 'data received by 180 - keyboard locked' will appear at the screen's bottom. When the keyboard is unlocked then any data in the keyboard buffer will be sent to NOS/VE. The bottom line is the last line that was processed by Operator Facility.

The right K Display has the file name OUTPUT_RIGHT. There is only one area on the right screen therefore the main display area is 10 lines longer than the left screen area. If a dayfile display or CP display is shown on the right screen you will get more lines of information than on the left screen.

There are no default displays that come up automatically on either output display area. It is up to the operator to decide the display the operator wishes to see. The only parts of the display that come up automatically is the system header

NDS/VE Cycle 5 Helpful Hints

07/07/82

4.0 DUAL STATE DEADSTART AND OPERATION

4.7 NDS/VE OPERATOR FACILITY AND OPERATOR COMMANDS

display and the prompt area for keyboard status.

The page width of the screen is 60 characters for standalone and 64 characters for dual state. The character set translation code is the same as that for the current NVE Subsystem control point. The escape code sequence for the special characters to be typed has not changed. There are a few differences in the processing of data by the Operator Facility and NVE Subsystem.

- 1) Do NOT end commands with a period. Periods are sent to NOS/VE.
- 2) The NVE subsystem commands that begin with an asterisk will not be supported from the Operator Facility control point. If these commands are entered from the Operator facility they will be passed on to SCL where an illegal command will be issued.
- 3) Routing of console job data to a specific job by the 'n=command' protocol will not be supported in dual state. This feature should work in standalone but will not be supported.
- 4) No type ahead - commands cannot be entered until the prompt area shows that they are requested.

There is one new command to replace the current display commands. The entry points for Zdis, Zdisb, and Sdis have been deleted. The new command is VEDISPLAY and has two parameters. The options are listed below. The values in paranthesis are the abbreviations. Note that this command does not begin with an asterisk (*). This command will be processed by SCL and create a new system control point task to display it's data. The user can have the same display type on each of the display areas, if the user so desires.

Command Name	Display Type	Screen Area
	Parameter Name	Parameter Name
	DISPLAY_OPTIONS	OUTPUT (O)
	DISPLAY_OPTION (OO)	

.....
 4.0 DUAL STATE DEADSTART AND OPERATION
 4.7 NDS/VE OPERATOR FACILITY AND OPERATOR COMMANDS

	Parameter Values	Parameter Values
VEDISPLAY (VED)	DISPLAY_SYSTEM_LOG JOB_LOG (JL) CONTROL_POINT (CP)	OUTPUT OUTPUT_RIGHT (OR)

The default file name for all displays is OUTPUT.

The following is a brief list of commands to bring up NOSVE with the Operator Facility installed.

- n.NVEffff. to bring up NDS/VE. (See Section 5)
- K,n. n = control point for NVE. :
- KK. to bring up the K display on both screens.
- K.VED JL to bring up the job log.
- or
- K.VED DISPLAY_OPTIONS=JL OUTPUT=OUTPUT
 to bring up the job log using key word
 identifiers.
- K.VED CP OUTPUT_RIGHT
 to bring up the control point display on
 the right screen.
- or
- K.VED DISPLAY_OPTIONS=CONTROL_POINT OUTPUT=OUTPUT_RIGHT
 to bring up the control point display using
 key word
 identifiers.
- K.xxx send any command to NOS/VE.
- .
- .
- .
- K.TERMINATE_SYSTEM_JOB to terminate NOS/VE.

Note: After the DS procedure has completed execution the command to enter to bring down the system is TERMINATE_SYSTEM_JOB, not TERMINATE_SYSTEM.

07/07/82

 4.0 DUAL STATE DEADSTART AND OPERATION

4.7.1 DELETE_JOB_QUEUE ; DELETE_JOB_QUEUES ; DELJQ (NEW)

4.7.1 DELETE_JOB_QUEUE ; DELETE_JOB_QUEUES ; DELJQ (NEW)

The purpose of this command is to delete all files from the job input subcatalog, the print subcatalog or both. This command is only allowed from jobs with operator and or system privileges.

```
delete_job_queue [queue_name=input|output|all]
                 [status=<status variable>]
```

queue_name ; qn: This parameter specifies from which subcatalogs files are to be deleted. Specifying INPUT will cause all files to be deleted from the job swap subcatalog and the job input subcatalog. Specifying OUTPUT will cause all files to be deleted from the job output subcatalog. Omission will cause all to be used.

status: See ERROR HANDLING.

4.7.2 REBUILD_INPUT_QUEUE ; REBIQ (NEW)

The purpose of this command is to rebuild an entry in the Known Job List (KJL) from information in the System Label of the file representing the job being processed. This command is to be used during the process of recovering the input queues during recovery deadstart.

```
rebuild_input_queue [name=<name>]
                   [status=<status variable>]
```

name ; n: This parameter specifies the file name of the file representing the job. An attempt is made to process the specified file within the catalog where job input queues are known to reside.

status: See ERROR HANDLING.

4.7.3 REBUILD_OUTPUT_QUEUE ; REBOQ (NEW)

The purpose of this command is to rebuild an entry in the Known Output List (KOL) from information retained in the System Label of the file representing the output being processed. This command is to be used during the process of

4.0 DUAL STATE DEADSTART AND OPERATION

4.7.3 REBUILD_OUTPUT_QUEUE ; REBOQ (NEW)

recovering the output queues during a recovery deadstart.

rebuild_output_queue [name=<name>]
[status=<status variable>]

name: This parameter specifies the file name of the file
representing the output. An attempt is made to
process the specified file within the catalog path
of where job output queues are known to reside.

status: See ERROR HANDLING.

4.8 ROUTE AN INPUT FILE FROM C170 IQ C180

Through the system console, enter:

Type

X.DIS.
USER,A,B.
GET,filename.
where filename identifies the input file to be routed.
ROUTE,filename,DC=LP,FC=RH.

4.9 K_DISPLAY_ASCII

Support of 6-12 ASCII from the console (K display) causes
the following changes:

Table with 3 columns: INPUT TRANSLATED_IQ, INPUT, TRANSLATED_IQ. It lists character mappings such as /1 for '(', /2 for '[', /3 for '>', /4 for '<', /5 for '.', /6 for '(single quote)', /7 for '/', /8 for ':', /9 for 'a-z (lower case)', and /0 for '(underscore)'. Note: The original image contains some typos in the table content.

NOS/VE Cycle 5 Helpful Hints

07/07/82

 4.0 DUAL STATE DEADSTART AND OPERATION
 4.10 DSDI INFORMATION

4.10 DSDI INFORMATION

To create an Express Deadstart Dump (EDD) tape:

- 1) Mount scratch tape (ring in) on a 9-track drive.
- 2) Push D/S button.
- 3) Select U (utilities) display.
- 4) Select E (EDD) display.
- 5) Set channel (S2=13).
- 6) Set ECUU (S2=01uu)

E = equipment

C = 1 for 67X drives
 2 for 66X drives

uu = unit number of the tape drive to be used.

- 7) Answer "dump number" with a CR. ;
- 8) Answer "non zero inhibits rewind" with a CR. ;
- 9) Answer "channel controlware" with a CR. ;

* - Warning if this step is omitted, DSDI cannot process the dump tape.

To create a listing of the EDD tape:

- 1) REQUEST,DUMP,NT,D=PE,F=S,LB=KU,PO=R,VSN=your choice.
- 2) GET,DSDI/UN=DEV1. (On S/N 101.)

or

GET,DSDI/UN=DEV1. (On S2.)

- 3) Create DSDI directives file:

A DSDI directive file should include the following:

IDUMR.
 PROMR.

NOS/VE Cycle 5 Helpful Hints

07/07/82

4.0 DUAL STATE DEADSTART AND OPERATION4.10 DSDI INFORMATION

MEMMR.

PRORF.

W,first_byte_address,last_byte_address,asid. (where
the first_byte_address and last_byte_address are hex
byte addresses and asid is the asid of the segment to
be dumped)

4) Execute DSDI:

RFL,60000.

DSDI,M,D,I="input directives file".

5) To run (after the first time):

DSDI,I=n.

(Does not read tape again.)

6) To run interactively:

Same as above, except to do W command must first do:

OUTPUT,LISTFIL.

7) C170 DSDI information can be found in Chapter 10 of
the NOS SYSTEM MAINTENANCE Manual.

A170 DSDI info can be found in document ARH3060 -- GID
for A170 NOS/S2.

4.11 NOS/VE_TERMINATION

o Bringing down dual state: ;

K,n - n is the NVEffff control point

K.TERMINATE_SYSTEM_JOB

o If not a normal termination

K,n - n is the NVEffff control point

K.*RUN.

K.*ENDLST.

K.*ENDRUN.

NOS/VE Cycle 5 Helpful Hints

07/07/82

4.0 DUAL STATE DEADSTART AND OPERATION

4.12 A170 NOS SHUTDOWN

4.12 A170_NOS_SHUTDOWN

Before leaving the machine, it is necessary to bring NOS down. If NOS has crashed, a level 3 deadstart must be attempted even if the only reason is to bring NOS down. To do a level 3 deadstart:

- 1) Push D/S button
- 2) Select "0" display
- 3) Select "P" display
- 4) Enter I=3
- 5) Enter (CR)
- 6) Enter date/time

If a dump is desired but a crash has not occurred STEP. should always be entered before pushing the deadstart button. After the dump has been taken a level 3 deadstart should be performed.

To bring NOS down, do the following:

- 1) Enter:

CHE
The screen will display:
CHECKPOINT SYSTEM.
Enter: carriage return
- 2) Make sure no mass storage device has a checkpoint requested. To do this, enter: E,M. If the display shows there are no "C"s in the status field, then all devices are checkpointed and you may continue.
- 3) Enter:

STEP.
- 4) Push deadstart button.

07/07/82

 5.0 RECOVERY OF NOS/VE PERMANENT FILES

5.0 RECOVERY_OF_NOS/VE_PERMANENT_FILES

5.1 SETVE_EORMAI

The general format of the SETVE command is

X.SETVE(PN=ffff,UN=un,VSN=vsN,D=d,P=p,B=b,C=c,CH=ch)

ffff is a string of no more than four characters. SETVE appends ffff to 'NVE' to construct the name of a procedure file which, when invoked, will deadstart NOS/VE. The default is TST.

un specifies the user number from which TPXXXK is attached. Un is the first catalog searched for other files used in deadstarting and terminating NOS/VE. The default is INT1.

c specifies the deadstart command deck to be used when deadstarting NOS/VE. The function served by the deadstart command deck is analogous to the function served by the CMRDECK of NOS. Currently supported values for c and their respective uses are:

1	Arden Hills S3 S/N 02 open shop/hands-on time	:
3	Arden Hills S3 S/N 02 closed shop	:
6	Arden Hills S2 S/N 104 open shop/hands-on time	:
10	Sunnyvale S2 closed shop installation	:
40	Sunnyvale S2 closed shop continuation	:

The default is set in the file CMDS1. Currently the default is 6.

b specifies an alternate catalog to be searched for the various files used in deadstarting and terminating NOS/VE. The default is INT1.

d is used to indicate that the system core command processor should accept commands from the console. Specifying D=T in the SETVE command allows the operator to enter commands from the console after processing the deadstart command deck. If the

NOS/VE Cycle 5 Helpful Hints

07/07/82

5.0 RECOVERY OF NOS/VE PERMANENT FILES5.1 SETVE FORMAT

operator wishes to initialize the system device and/or install a new version of NOS/VE, D=T must be specified. The default is set in the file CMDS1. Currently the default is D=F.

p specifies the password for the catalog indicated by the un parameter. If this parameter is omitted the password will be generated by appending an 'X' to the UN parameter.

ch specifies the octal channel to be used for NOS/VE disk I/O. The default is set in the file CMDS1. Currently the default is 2.

vsn specifies the vsn of a deadstart tape. If this parameter is used then NOS/VE will be deadstarted from the tape specified. If it is omitted, then NOS/VE will be deadstarted from the permanent file TPXXXK.

5.2 SEIVE_USAGE

Earlier versions of NOS/VE required that two SETVE commands be issued if the system was to be installed and subsequently recovered. The current system does not require this. The only reason for issuing two SETVE commands is to provide a deadstart procedure that does not require/permit operator intervention.

It should be noted that once the SETVE command has been issued, it need not be issued again unless...

- 1) There is a need to change one or more of the parameters specified in SETVE.
- 2) The command file, NVEffff, generated by the SETVE command is purged from the system.

Two examples of SETVE usage and subsequent NOS/VE deadstart are given below. The first example shows a "hands on" user working with recovery. The second illustrates these concepts for a typical NOS/VE closed shop. This writer hopes that the reader will find both examples useful and illuminating.

I. A "hands on" user

The command file NVERSD is built and installed in NOS

NOS/VE Cycle 5 Helpful Hints

07/07/82

5.0 RECOVERY OF NOS/VE PERMANENT FILES5.2 SETVE USAGE

by typing

```
X.SETVE(RSD,UN=RSD,VSN=TAPE,B=DEV1,C=6,D=T)
```

Several of the choices of parameters are worth noting.

- 1) By specifying the VSN parameter the user has built a command file that will deadstart the system directly from the tape produced by NVESYS.
- 2) The user in this example has specified deadstart command deck 6 (C parameter) and has allowed the NOS/VE disk I/O channel (ch parameter) to default to 2. One concludes that the user is running on the Arden Hills S2.
- 3) The user has specified D=T. This is important. The deadstart command which triggers installation of a recoverable system cannot be read from a deadstart command deck. It must be entered from the console at deadstart time. Specifying D=T allows the operator to enter commands from the console.

NOS/VE is deadstarted by typing

```
n.NVERSD.
```

at the console. (n is a control point which is NOT 1, 2 ;
or ordinarily occupied by MAGNET, BATCHID, or SYSTEM) ;

The user brings up the K display by typing

```
K,n.
```

(where n is the NVE control point.)

Presently, the deadstart command deck is displayed and the user is prompted for input. The deadstart command deck used in this example looks like this:

```
USECP      S2CFIG
USEIP      EMPTY
SETDCT     $7155_1
SETDD      $885_12 32
```

The user types

NOS/VE Cycle 5 Helpful Hints

07/07/82

5.0 RECOVERY OF NOS/VE PERMANENT FILES

5.2 SETVE USAGE

K.INITDD VSN001.

K.GO.

The system accepts the commands and installs and deadstarts NOS/VE.

After the system comes down, via either controlled termination or a crash, the system can be recovered (if necessary) and redeadstarted by typing

n.NVERSD. (where n is an appropriate control point.)

When the deadstart command deck is displayed, the user types

GO.

This will cause NOS/VE to be deadstarted without initializing the system device.

II. A typical "closed shop"

Two command files, NVECLSH and NVEINST, are created by typing

X.SETVE(CLSH,UN=CLSH,B=DEV1,C=40,CH=1) ;

X.SETVE(INST,UN=CLSH,B=DEV1,C=10,CH=1,D=T)

One notes that

1) Closed shop is deadstarted from a TPXXXK file in the CLSH catalog.

2) Specifying D=T, for NVEINST, causes deadstart to pause for operator intervention. ;

3) Using DCF deck 40 for continuation suppresses redundant (and possibly damaging) reexecution of the configuration prolog. ; ; ;

A normal deadstart is used when bringing up NOS/VE at the beginning of closed shop or following a system failure. The operator, in this example, types

n.NVECLSH.

NOS/VE will recover (if necessary) and deadstart. No operator intervention is required.

NOS/VE Cycle 5 Helpful Hints

07/07/82

5.0 RECOVERY OF NOS/VE PERMANENT FILES5.2 SETVE USAGE

If it is necessary to reinitialize the system device, or if the installation is upgrading to a new version of NOS/VE, the operator keys

n.NVEINST.

This causes deadstart to pause and wait for operator input when deadstart commands are being processed. There are two cases requiring discussion here. The first is the case of upgrading to a new and compatible version of NOS/VE. The second case is used only when it is necessary to reinitialize the system device.

The first case involves the installation of a new version of NOS/VE. In order to install a new version of the system, the old system must have been idled in an orderly way. A new system cannot be installed if, following a crash, the system being superceded was not recovered. Assuming everything in the old system is tidy, and the file systems are compatible, the operator keys

K.USECP EMPTY.

K.SETSA INSTALL_JOB_TEMPLATES 1.

K.GD.

when the system displays the deadstart command deck and prompts for input. The new system is installed, the file system is preserved, and deadstart proceeds.

The second case amounts to an installation deadstart. This should be used only with full knowledge that any files which may have existed on mass storage prior to this deadstart, will be blasted into oblivion by it.

An installation deadstart will be required if

- 1) This is the initial installation of a recoverable version of NOS/VE.
- 2) If the file systems of the system being installed and the system being superceded are not compatible.
- 3) If the file system has been damaged beyond the possibility of recovery.

An installation deadstart is effected by typing

NOS/VE Cycle 5 Helpful Hints

07/07/82

5.0 RECOVERY OF NOS/VE PERMANENT FILES5.2 SETVE USAGE

K.INITDD VSN001.

K.GD.

when the deadstart command deck is displayed and the operator is prompted for input.

NOTES:

1. The CMDS1 file used to deadstart NOS/VE must have the DEBUG2 flag set to TRUE. When NOS/VE is deadstarted, the catalog specified by the UN parameter is first in the search order for CMDS1, followed by the catalog specified by the B parameter.
2. See Section 3.3 of the Integration Procedures Notebook for other information about the CMDS1 file.
3. If NOS/VE crashes and a dump is desired (in the context of our second example)
 - i. Type du at the MDD console. The message "WRITING IMAGE FILE" should appear immediately. The message "IMAGE FILE COMPLETE" should appear a few moments later.
 - ii. Push the deadstart button.
 - iii. Take the EDD dump.
 - iv. Do a level 3 NOS deadstart.

Alternatively the operator can skip step i if she/he is sure to redeadstart NOS/VE after step iv. In this event the system will detect that the image file was never created, will create one, and will recover from it.

6.0 SYSTEM CORE DEBUGGER

6.0 SYSTEM_CORE_DEBUGGER

The System Core debugger provides a set of capabilities intended to assist in debugging the operating system. Services provided by the debugger are task oriented: selection of the tasks to be debugged must be made via debugger subcommands. No tasks will be under control of the debugger unless they are selected. The selection capability allows any number of tasks to be debugged simultaneously; from one task to all tasks in the system. Obviously a capability this powerful must be used with some care. The System Core debugger uses the debug hardware to provide these capabilities.

6.1 SYSDEBUG

The purpose of this command is to initiate execution of the system core debugger. This command can be issued from the deadstart command file or as a command in any job.

sysdebug

This command has no parameters; all information the debugger requires is provided via subcommands.

The system core debugger can also be invoked from the MDD console. The format of the command is:

DD n.sysdebug

where n is the job ordinal of the desired job. The debugger is brought up in the job monitor task of the job. All system core debugger subcommands are available, but must be prefixed by the MDD command DD.

The system core debugger can also be brought up (from the MDD console) by specifying a global task id. The format of the command is:

DD n.tdebug gggggg

The value of n is ignored, and the value gggggg specifies the

NDS/VE Cycle 5 Helpful Hints

07/07/82

6.0 SYSTEM CORE DEBUGGER

6.1 SYSDEBUG

```

NDS/VE global task id (3 hex bytes) of the task to bring the
debugger up in. If the task id is invalid, then the command
will be ignored.

```

6.2 SUBCOMMAND_PARAMETER_DEFINITIONS

```

<name> ::= 1-8 character breakpoint name
<condition> ::= READ!WRITE!RNI!BRANCH!CALL!DIVFLT!ARLOS!
               AROVFL!EXOVFL!EXUNFL!FPLOS!FPINDEF!INVBDP
<base> ::= process virtual address
<offset> ::= integer
<length> ::= integer
<frame> ::= 1..100
<count> ::= 1..10000
<regid> ::= X!A!P
<regno> ::= 0..15!0..OF(16)
<value> ::= integer
<time> ::= 1..(2**31)-1
<vstring> ::= 'charstring'
<datatype> ::= HEX!ASCII!ASC!DEC
<change_count> ::= 1..8
<selector> ::= FULL!AUTO!SAVE

```

6.3 SYSTEM_CORE_DEBUGGER_SUBCOMMANDS

Within the descriptions which follow, optional parameters are enclosed in brackets. Default values for optional parameters are also defined.

6.3.1 SELECT

The purpose of this subcommand is to select the tasks in which the system core debugger is to be active. When the debugger is first called, it is not active in any task. To use the debugger therefore, it is necessary to select the tasks in which it is to be active.

```

select <selection option> [<ring number> ; <active job list
ordinal>]

```

selection_option: This parameter specifies one of a series of selection options used to control the tasks in which the debugger will be active and some

NOS/VE Cycle 5 Helpful Hints

07/07/82

6.0 SYSTEM CORE DEBUGGER

6.3.1 SELECT

other debug options. The selections are remain in effect until they are explicitly changed with subsequent SELECT subcommands. Valid selection options are:

<right:left> - This selects the screen for the debug display. The display stays active when the screen is switched.

<jobmonitor:nojobmonitor> - This selects whether or not to debug job monitor tasks.

<user:nouser> - This selects whether or not to debug user tasks (i.e. those that are not job monitors).

<highring> - This specifies the highest ring in which debug traps will be recognized. Traps occurring in rings above this selection will be ignored.

<job:nojob> - This enables or disables debugging for the job at the specified active job list ordinal. The system job has an active job list ordinal of zero.

<alljobs:nojobs> - This activates or deactivates debugging in all jobs.

The initial selections are: RIGHT, NOSTEP, NOJOBMONITOR, NOUSER, HIGHRING=3, NOJOBS.

6.3.2 BREAKPOINT ; B

The purpose of this subcommand is to select a program interrupt which is to occur specified condition within a specified virtual address range.

breakpoint <name> <condition> [<base>] [<offset>] [<length>]

The <name> is any user supplied name for identifying the breakpoint. A maximum of thirty two breakpoints can be selected. When a trap occurs, the <name> of the breakpoint which caused the trap is displayed.

The base parameter is required when specifying a new breakpoint name; offset and length specifications are optional

07/07/82

 6.0 SYSTEM CORE DEBUGGER

6.3.2 BREAKPOINT ; B

In this case. When adding a new condition selection to an existing breakpoint, base, offset, and length parameters may not be specified.

Base, offset, and length parameters define the desired virtual address range: $\langle \text{base} \rangle + \langle \text{offset} \rangle$ yields a first-byte-address; $\text{first-byte-address} + \langle \text{length} \rangle - 1$ yields a last byte address.

Default parameter values:

$\langle \text{offset} \rangle$: 0
 $\langle \text{length} \rangle$: 1

6.3.3 REMOVE_BREAKPOINT ; RB

The purpose of this subcommand is to deselect a previously selected program inte

`remove_breakpoint <name> [<condition>]`

If only the name parameter is specified, all conditions associated with the breakpoint are deselected and all evidence of the breakpoint is removed. If the condition parameter is specified, only that condition is deselected; however, if the specified condition is the only condition selected, all evidence of the named breakpoint is removed.

6.3.4 LIST_BREAKPOINT ; LB

The purpose of this subcommand is to provide a list of currently selected breakp and associated conditions.

`list_breakpoint [<name>]`

If the name parameter is specified, information is displayed for the named breakpoint only. If the name parameter is not specified, information is displayed for all currently defined breakpoints.

07/07/82

6.0 SYSTEM CORE DEBUGGER

6.3.5 CHANGE_BREAKPOINT : CB

6.3.5 CHANGE_BREAKPOINT : CB

The purpose of this subcommand is to change the virtual address range of a previ specified breakpoint.

change_breakpoint <name> <base> [<offset>] [<length>]

Base, offset, and length parameters define the desired virtual address range: <base> + <offset> yields a first-byte-address; first-byte-address + <length> -1 yields a last byte address.

Default parameter values:

<offset>: 0
<length>: 1

6.3.6 TRACE_BACK : TB

The purpose of this subcommand is to provide information relevant to stack frame associated with an interrupted procedure and its predecessor procedures. Validation of PVA's is now performed.

Information displayed for each selected stack frame consists of:

- Stack frame number;
- Current P-address of the associated procedure;
- Virtual address of the start of the stack frame;
- Virtual address of the stack frame save area.

trace_back [<frame>] [<count>] [FULL|SHORT]

The frame parameter specifies the number of the first stack frame for which information is to be displayed. Stack frame number one is associated with the interrupted procedure, stack frame two is associated with the interrupted procedure's predecessor, etc.

The module name provided on the traceback is usually correct but not guaranteed.

The count parameter specifies the total number of stack frames for which information is to be displayed.

NOS/VE Cycle 5 Helpful Hints

07/07/82

6.0 SYSTEM CORE DEBUGGER

6.3.6 TRACE_BACK ; TB

Default parameter values:

<frame>: 1
<count>: 1

6.3.7 DISPLAY_STACK_FRAME ; DSF

The purpose of this subcommand is to display selected information from a specific stack frame.

display_stack_frame [<frame>] [<selector>]

The frame parameter specifies the number of the stack frame for which information is to be displayed. (Stack frame number one is associated with the interrupted procedure, stack frame two is associated with the interrupted procedure's predecessor, etc.)

The selector parameter identifies a region of the specified stack frame:

AUTO: Causes the automatic region of the stack frame to be displayed.

SAVE: Causes the save area of the stack frame to be displayed.

FULL: Causes both the automatic and save areas of the stack frame to be displayed.

Default parameter values:

<frame>: 1
<selector>: FULL

6.3.8 DISPLAY_REGISTER ; DR

The purpose of this subcommand is to display the contents of a specified register interrupted procedure.

display_register <regid> [<regno>] [<datatype>]

Default parameter values:

<regno>: 0

 6.0 SYSTEM CORE DEBUGGER

6.3.8 DISPLAY_REGISTER ; DR

<datatype>: HEX

6.3.9 DISPLAY_MEMORY ; DM

The purpose of this subcommand is to display the contents of a specified area of virtual memory. Validation of PVA's is now performed.

display_memory <base> [<length>]

Default parameter values:

<length>: 8

6.3.10 CHANGE_MEMORY ; CM

The purpose of this subcommand is to set a specified value into a specified loca of virtual memory for a specified number of bytes. Validation of PVA's is now performed.

change_memory <base> <value> <change_count>

Default parameter values:

<change_count>: 1

6.3.11 RUN

The purpose of this subcommand is to invoke program execution after a selected p interrupt has occurred.

run

6.3.12 SUPER_CHANGE_MEMORY ; SCM

The purpose of this subcommand is the same as the change memory subcommand, that is, to change the contents of virtual memory. It differs from change memory, however, in that it will change the attributes of the segment to allow memory to be written, and then change the attributes back to their original values.

NOS/VE Cycle 5 Helpful Hints

07/07/82

6.0 SYSTEM CORE DEBUGGER
 6.3.12 SUPER_CHANGE_MEMORY : SCM

The command format is the same as the change memory subcommand.

6.3.13 FORMAT : FMT

The purpose of this subcommand is to set the system core debugger into a mode where all subcommand output is sent to a permanent file. This is done by having the task running the debugger communicate with another task running in the system job. It is this other task that actually creates and writes the permanent file. The entry point of this task is QSP\$BROKEN_JOB_DUMP_TASK. It will normally be initiated by the DS procedure. If it is not running, a diagnostic will be issued. This task will create successive cycles of the permanent file 'DUMP' in the \$SYSTEM catalog. These files contain ASCII text data written in BAM variable records. The parameter to this command is a string which will be output as the first line of the file.

format string

6.3.14 UNFORMAT : UNFMT

The purpose of this subcommand is to leave the output mode established by the FORMAT command. Output will again be sent to the operator console. At this point the permanent file will be flushed to mass storage.

unformat

6.3.15 DISPLAY_MONITOR_FAULT : DISMF

The purpose of this subcommand is to display any monitor faults present in this task. See the section titled 'NOS/VE Processing of Job Mode Software Errors' for more information.

All monitor fault buffers are displayed in the hope they will show some task history. If a given fault buffer is invalid the message "following fault is not present" is displayed.

display_monitor_fault

NDS/VE Cycle 5 Helpful Hints

07/07/82

6.0 SYSTEM CORE DEBUGGER

6.3.16 DISPLAY_XCB ; DISXCB

6.3.16 DISPLAY_XCB ; DISXCB ;

The purpose of this subcommand is to display all of the fields of the current task's (i.e., the task running the debugger) execution control block. ;

6.3.17 DISPLAY_TASK_ENVIRONMENT ; DISTE ;

The purpose of this subcommand is to display the XCB of all tasks running within the current job (i.e., the job with the task running the debugger). If the command is entered while the debugger is in format mode, then a full XCB is displayed, otherwise just the task name, XCB address and global task id are displayed. ;

07/07/82

 7.0 NDS/VE PROCESSING OF JOB MODE SOFTWARE ERRORS

7.0 NDS/VE_PROCESSING_OF_JOB_MODE_SOFTWARE_ERRORS

7.1 INTRODUCTION

Tasks running in job mode will occasionally cause an error which is detected either by the hardware or NDS/VE monitor. The action taken when an error like this occurs is controlled by various system attributes. The purpose of this section is to discuss the types of errors and the effect a given system attribute will have upon the handling of the error.

7.2 TYPES_OF_ERRORS

- 1) BROKEN TASK: A broken task is a task in which the trap mechanism is not able to function correctly. NDS/VE monitor will attempt to repair the trap mechanism and send a broken task fault to the task. The specific cases of a broken task are:

system error	job mode software has declared the task to be broken. (This is a special case of broken task.)
monitor fault buffer full	job mode errors are occurring but are not being processed by job mode.
traps disabled	a job mode error has occurred while traps were disabled.
invalid A0	the task's A0 register was invalid.
UCR/MCR traps disabled	UCR/MCR error occurred with traps disabled.

- 2) MCR FAULT: This error signifies that job mode caused a hardware detected MCR fault. This may be caused by

NOS/VE Cycle 5 Helpful Hints

07/07/82

 7.0 NOS/VE PROCESSING OF JOB MODE SOFTWARE ERRORS

7.2 TYPES OF ERRORS

software or hardware detected uncorrectable error.

3) UNKNOWN SYSTEM REQUEST: This error signifies that job mode issued a monitor request that is either invalid or cannot be issued from the ring it was issued from.

4) SEGMENT ACCESS FAULTS: These errors signify that job mode encountered or caused one of the following errors:

- page fault for an address greater than EDI on a read-only file (segment)

- disk read error

These errors either originate in NOS/VE monitor or cause the hardware to exchange to monitor. Depending on the values of certain system attributes, monitor will halt or reflect the error back to job mode as a monitor default.

It is at this point that the system core debugger can be activated. (See the definition of SYSTEM_DEBUG_RING in the next section.)

The normal job mode OS actions for these faults are:

broken task	exit
MCR fault	cause condition
invalid system request	exit
segment access	cause condition

7.3 SYSTEM_ATTRIBUTES_EOB_ERROR_PROCESSING

The following system attributes can be set or displayed by the SETSA and DISSA commands.

7.3.1 HALTRING

If a broken task or MCR fault occurs at or below the value of HALTRING (P register ring number), NOS/VE monitor will halt the system. Broken tasks occurring above HALTRING will cause a monitor fault to be sent back to job mode.

.....

7.0 NOS/VE PROCESSING OF JOB MODE SOFTWARE ERRORS

7.3.2 SYSTEM_ERROR_HANG_COUNT

.....

7.3.2 SYSTEM_ERROR_HANG_COUNT

This is the number of broken task errors allowed to occur in any given task before that task is considered a hung task.

7.3.3 HALT_ON_HUNG_TASK

If this attribute is true, then an occurrence of a hung task will cause NOS/VE monitor to halt the system. If the attribute is false, the task will be sent a signal to 'hang' itself, i.e. to go into an infinite wait doing nothing. Jobs with hung tasks will have a *H in the status field on the operator CP display.

A hung task will also occur if any error happens in job mode ring 1.

7.3.4 SYSTEM_DEBUG_RING

If an error (broken task, MCR fault, unknown system request, or segment access fault) occurs at or below the value of this attribute (P register ring number), the system core debugger will be invoked within the task. At that point in time the task environment can be examined by using system core debugger commands.

If the RUN command is issued to the debugger, the system will take its normal action for the specific fault.

7.3.5 DUMP_WHEN_DEBUG

When the system core debugger is invoked by a fault at or below SYSTEM_DEBUG_RING and the DUMP_WHEN_DEBUG attribute is true, the debugger will automatically create a dump of the task (see system core debugger command FORMAT). When the dump is complete, normal fault action will take place. The following system core debugger commands are executed during an automatic dump:

FORMAT automatic dump data
TB 1 1000
DISMF

NDS/VE Cycle 5 Helpful Hints

07/07/82

7.0 NDS/VE PROCESSING OF JOB MODE SOFTWARE ERRORS

7.3.5 DUMP_WHEN_DEBUG

DISXCB
DM 00300000000 10000(16)
DM 00400000000 10000(16)
DM 00500000000 10000(16)
DM 00600000000 10000(16)
DM 00F00000000 10000(16)
DM 01000000000 10000(16)
DM 01100000000 10000(16)
DISTR
UNFORMAT

;
;
;
;
;
;
;
;
;
;
;
;
;
;

NDS/VE Cycle 5 Helpful Hints

07/07/82

8.0 STAND ALONE DEADSTART

8.0 SIAND_ALONE_DEADSIARI

Standalone deadstart does not work for Cycle 3. Code will be transmitted for Cycle 4 to repair this; this section will be rewritten then.

07/07/82

9.0 INTERACTIVE PROJECT DUMP ANALYSIS PROCEDURES

9.0 INTERACTIVE_PROJECT_DUMP_ANALYSIS_PROCEDURES

The following procedures were developed by the interactive project to assist them in interpreting dumps. They guarantee the procedures work if your user name is IFP; otherwise caveat emptor. For more information about these procedures, contact Fred Bischke.

The following dump analysis procedures are available in the IFP catalog:

9.1

EDDSIM

This is a CCL procedure which brings an EDD dump tape on a specified

VSN into the simulator. The procedure can be accessed from the IFP

catalog as follows:

```
get,eddsim/un=ifp
```

```
begin,,eddsim,vsn ( vsn is the vsn of the EDD dump tape )
```

9.2

ANALEXC

This is a Simulator INCLUDE file which does a preliminary analysis of

the current simulator exchange package (when the system crashes in task

NDS/VE Cycle 5 Helpful Hints

07/07/82

 9.0 INTERACTIVE PROJECT DUMP ANALYSIS PROCEDURES
 9.2

services, this will normally be JPS). A qr exc=mon or qr exc=rma can be

used to get into another exchange package before doing the include.

The include file is ANALEXC/UN=IFP. It can be called from the simulator

as follows:

```
'get,analexc/un=ifp' ; include analexc
```

(carriage return) a lone carriage return must be entered after an INCLUDE in order to start it up

9.3

SEGDUMP

This is a CCL procedure which calls DSDIV to dump a specified segment to a list file which can then be examined with an editor or printed.

The procedure can be accessed from within the Simulator as follows:

```
'get,segdump/un=ifp' ; 'begin,,segdump,seg,len,file,exc,cpf' <*
```

The segdump parameters are:

seg - segment number in hex (default is 1)

length - number of bytes to dump in hex (default is 10000)

list - name of the list file (default is LIST)

exc - reference exchange package (default is JPS)

cpf - name of checkpoint file (default is CPF)

NDS/VE Cycle 5 Helpful Hints

07/07/82

 9.0 INTERACTIVE PROJECT DUMP ANALYSIS PROCEDURES
 9.3

In most cases of task services debugging, only the seg parameter is

needed.

9.4

ANALJOB

This is a CCL procedure which uses DSDIV, XEDIT and the Simulator to

perform an analysis of all tasks in a specified job. The procedure can

be accessed from within the simulator as follows:

```
'get,analjob/un=ifp' ; 'begin,,analjob,seg,cpf'
```

The analjob parameters are:

seg - the monitor segment which contains the exchange packages of the job (14 is the system job, 15 is job 1 etc.) (default is 14)

cpf - the name of the simulator file (default is CPF)

After the procedure has completed, a list of the RMA's of the

job's exchange packages can be obtained by doing the following:

```
include tplist
```

```
(carriage return)
```

A traceback of all tasks in the job can be obtained by doing the

NDS/VE Cycle 5 Helpful Hints

07/07/82

9.0 INTERACTIVE PROJECT DUMP ANALYSIS PROCEDURES

9.4

following:

include tblist

(carriage return)

include tbrun

(carriage return)

10.0 ARDEN HILLS DEVELOPMENT LAB SUPPORT BY INTEGRATION

10.0 ARDEN_HILLS_DEVELOPMENT_LAB_SUPPORT_BY_INIEGRATION

What we have established in the lab so far is the following:

- A 600 tape capacity tape rack for general use. If your project would like to reserve a section of this tape rack, contact Tim McGibbon or Bonnie Swierzbin
- A tape and disk cabinet for storage of system support materials which this project will manage and keep up to date. (If you have been using this cabinet for unauthorized storage - beware. We have the key to the lock!) More will be published about the contents of this cabinet later, and a cabinet index will be posted in the lab to help locate where things are supposed to be placed within the cabinet. This cabinet is currently located in the southeast corner of the lab, is 6 ft. 8 in. tall, gray in color and with sliding door.
- A microfiche reader and a metal box containing the most recent microfiche of the system compilation listings and a link map. These items are kept on the table to the right of the console.
- A desk documentation rack for reference manuals and Tom McGee's collection of "how to" goodies. The objective is to have this reference information at arm's length of the console, but it is currently on top of the two-level unit by the West wall.
- At or near the console is a small notebook containing the NDS System Programmer's Instant, NDS Application Programmer's Instant, and the 180 Instruction codes.

Feel free to examine and use all of the above materials while in the lab.

Do not remove or abuse any of these materials. Please notify Tim McGibbon or Bonnie Swierzbin of any problems or deficiencies of these materials. Leave a note if we are not available.

07/07/82

- 1.0 Hardware Overview :

 - 1.1 An introduction to CYBER 180 :
 - 1.2 C180 Instant :
 - 1.3 Model Independent General Design Specification - :
ARH1700 :

- 2.0 NDS Reference Manuals :

 - 2.1 XEDIT V3.0 - 60455730 :
 - 2.2 IAF V1.0 User's Guide - 60455260 :
 - 2.3 NDS Reference Manual - Vol 1, 60435400 - Vol 2, :
60445300 :
 - 2.4 NDS Instant :
 - 2.5 NDS Operators Guide - 60435600 :
 - 2.6 NDS Diagnostic Handbook :
 - 2.7 NDS A170 ERS :
 - 2.8 NDS A170 GID - ARH3060 :

- 3.0 NDS/VE Reference Documents :

 - 3.1 Program Interface ERS - ARH3610 - obtained from :
Karen Rubey (482-3966) or via SES.TOOLDOC :
 - 3.2 Command Interface ERS - ARH3609 - obtained from :
Karen Rubey (482-3966) or via SES.TOOLDOC :
 - 3.3 NDS/VE Procedures and Conventions - SESD010 - :
obtained by SES.TOOLDOC :
 - 3.4 Listing of all NDS/VE Modules - obtained by :
SES,DEV1,LISTNVE. See Integration Procedures :
Notebook for details. :
 - 3.5 NDS/VE Internal Interface Maintenance Procedures :
Memo available from S.C. Wood. :
 - 3.6 Integration Procedures Notebook Obtained by: :
Acquire,IPNDOC/UN=DEV1. SES.PRINT,IPNDOC. :

07/07/82

- 4.0 Tools Reference Documents ;
- 4.1 CYBIL Interactive Debugger - ARH3142 ;
- 4.2 SES User's Guide - ARH1833 ;
- 4.3 CYBIL Specification - ARH2298 ;
- 4.4 C180 Assembler ERS - ARH1693 ;
- 4.5 Simulator ERS - ARH1729 ;
- 4.6 VEGEN ERS - ARH2591 ;
- 4.7 VELINK ERS - ARH2816 ;
- 4.8 Simulated I/O ERS - ARH3125 ;
- 4.9 Object Code Utilities ERS - ARH2922 ;
- 4.10 CYBIL Implementation Dependent Handbook - ARH3078 ;
- 4.11 CYBER 180 INTERACTIVE DEBUG External Reference ;
Specification and Users Guide - S4028 ;
- 4.12 CYBER 180 II Assembler ERS - ARH3945 ;
- 4.13 ERS for Source Code Utility - ARH3883 ;

Table of Contents

1.0 MAJOR CHARACTERISTICS OF THIS BUILD	1-1
1.1 NOS/VE USAGE EXAMPLES	1-4
1.1.1 EXECUTING PROGRAMS	1-5
1.1.2 CREATE OBJECT LIBRARY ON NOS/VE AND SAVE IT ON NOS	1-6
1.1.3 MODIFY A PREVIOUSLY SAVED OBJECT LIBRARY	1-6
1.1.4 ROUTE AN INPUT FILE FROM NOS TO NOS/VE	1-7
1.1.5 PRINT A NOS/VE FILE	1-8
2.0 COMMAND INTERFACE STATUS	2-1
2.1 ACCESS TO NOS/VE IN DUAL STATE	2-1
2.1.1 LOGIN TO NOS/VE	2-1
2.1.2 TERMINAL USAGE	2-1
2.1.3 NOS/VE PROGRAM ACCESS TO THE TERMINAL	2-2
2.2 COMMAND AND PARAMETER NAMES	2-2
2.3 COMMAND FUNCTIONS	2-3
2.4 SYSTEM ACCESS COMMANDS	2-4
2.5 RESOURCE MANAGEMENT	2-4
2.6 FILE MANAGEMENT	2-4
2.7 PERMANENT FILE MANAGEMENT	2-4
2.8 SCL STATEMENTS AND PROCEDURES	2-5
2.9 INTERACTIVE COMMANDS	2-6
2.10 OBJECT CODE MAINTENANCE	2-6
2.11 USER SERVICES	2-7
2.12 FILE ROUTING	2-7
2.13 PROGRAM EXECUTION	2-7
2.14 JOB MANAGEMENT	2-7
2.15 NOS/VE COMMANDS IMPLEMENTED AS PROCS	2-8
2.16 NON STANDARD COMMANDS	2-8
2.16.1 DELETE_CATALOG_CONTENTS ; DELCC	2-8
2.16.2 DISPLAY_ACTIVE_TASK ; DISAT	2-9
2.16.3 DISPLAY_SYSTEM_DATA ; DISSD	2-9
2.16.4 DISPLAY_JOB_DATA ; DISJD	2-10
2.16.5 DISPLAY_COMMAND_INFORMATION ; DISCI	2-11
2.16.6 CONVERT_OBJECT_FILE ; CONDF	2-12
2.16.7 GET_OBJECT_FILE ; GETOF	2-12
2.16.8 GET_OBJECT_LIBRARY ; GETOL	2-13
2.16.9 DISPLAY_OBJECT_TEXT ; DISOT	2-14
2.16.10 GET_SOURCE_LIBRARY ; GETSL	2-14
2.16.11 EDIT_FILE ; EDIF	2-15
2.16.12 JEDIT	2-15
2.16.13 DEBUG	2-16
2.16.14 SET_LINK_ATTRIBUTES ; SETLA	2-16
3.0 PROGRAM INTERFACE STATUS	3-1
3.1 COMMAND PROCESSING	3-1
3.2 MESSAGE GENERATOR	3-1
3.3 RESOURCE MANAGEMENT	3-2
3.4 PROGRAM EXECUTION	3-2
3.5 PROGRAM COMMUNICATION	3-3

3.6	CONDITION PROCESSING	3-3
3.7	PROGRAM SERVICES	3-3
3.8	LOGGING	3-4
3.9	FILE MANAGEMENT	3-4
3.10	PERMANENT FILE MANAGEMENT	3-5
3.11	MEMORY MANAGEMENT	3-5
3.12	STATISTICS FACILITY	3-6
3.13	INTERACTIVE FACILITY	3-6
3.14	NOS/VE EXCEPTIONS	3-6
4.0	DUAL STATE DEADSTART AND OPERATION	4-1
4.1	CURRENT DUAL STATE CONFIGURATION	4-1
4.2	USER NAMES AND PERMANENT FILES	4-2
4.3	TO RELOAD CONTROLWARE FOR THE NOS/VE DISK DRIVER	4-2
4.4	A170 NOS DEADSTART	4-2
4.4.1	CTI AND CHECKING CENTRAL MEMORY	4-2
4.4.2	NOS DEADSTART	4-3
4.4.3	INITIALIZING AN 855 (S3)	4-4
4.5	NOS/VE DEADSTART AND INSTALLATION	4-4
4.5.1	THE DS PROCEDURE	4-5
4.5.2	EXAMPLE OF NOS/VE INSTALLATION DEADSTART	4-9
4.5.3	EXAMPLE OF NOS/VE "NORMAL" DEADSTART	4-9
4.5.4	EXAMPLE OF NOS/VE RECOVERY DEADSTART	4-10
4.5.5	EXAMPLE OF MINIMAL NOS/VE DEADSTART	4-10
4.5.6	USE OF THE QUICK_DEADSTART COMMAND	4-10
4.6	NOS/VE INTERACTIVE FACILITY OPERATION	4-11
4.6.1	OPERATOR INITIATION	4-11
4.6.2	OPERATOR TERMINATION	4-11
4.6.3	OTHER OPERATOR CAPABILITIES	4-12
4.7	NOS/VE OPERATOR FACILITY AND OPERATOR COMMANDS	4-12
4.7.1	DELETE_JOB_QUEUE ; DELETE_JOB_QUEUES ; DELJQ (NEW)	4-16
4.7.2	REBUILD_INPUT_QUEUE ; REBIQ (NEW)	4-16
4.7.3	REBUILD_OUTPUT_QUEUE ; REBOQ (NEW)	4-16
4.8	ROUTE AN INPUT FILE FROM C170 TO C180	4-17
4.9	K DISPLAY ASCII	4-17
4.10	DSDI INFORMATION	4-18
4.11	NOS/VE TERMINATION	4-19
4.12	A170 NOS SHUTDOWN	4-20
5.0	RECOVERY OF NOS/VE PERMANENT FILES	5-1
5.1	SETVE FORMAT	5-1
5.2	SETVE USAGE	5-2
6.0	SYSTEM CORE DEBUGGER	6-1
6.1	SYSDEBUG	6-1
6.2	SUBCOMMAND PARAMETER DEFINITIONS	6-2
6.3	SYSTEM CORE DEBUGGER SUBCOMMANDS	6-2
6.3.1	SELECT	6-2
6.3.2	BREAKPOINT ; B	6-3
6.3.3	REMOVE_BREAKPOINT ; RB	6-4
6.3.4	LIST_BREAKPOINT ; LB	6-4
6.3.5	CHANGE_BREAKPOINT ; CB	6-5
6.3.6	TRACE_BACK ; TB	6-5
6.3.7	DISPLAY_STACK_FRAME ; DSF	6-6

6.3.8	DISPLAY_REGISTER ; DR	6-6
6.3.9	DISPLAY_MEMORY ; DM	6-7
6.3.10	CHANGE_MEMORY ; CM	6-7
6.3.11	RUN	6-7
6.3.12	SUPER_CHANGE_MEMORY ; SCM	6-7
6.3.13	FORMAT ; FMT	6-8
6.3.14	UNFORMAT ; UNFMT	6-8
6.3.15	DISPLAY_MONITOR_FAULT ; DISMF	6-8
6.3.16	DISPLAY_XCB ; DISXCB	6-9
6.3.17	DISPLAY_TASK_ENVIRONMENT ; DISTE	6-9
7.0	NOS/VE PROCESSING OF JOB MODE SOFTWARE ERRORS	7-1
7.1	INTRODUCTION	7-1
7.2	TYPES OF ERRORS	7-1
7.3	SYSTEM ATTRIBUTES FOR ERROR PROCESSING	7-2
7.3.1	HALTRING	7-2
7.3.2	SYSTEM_ERROR_HANG_COUNT	7-3
7.3.3	HALT_ON_HUNG_TASK	7-3
7.3.4	SYSTEM_DEBUG_RING	7-3
7.3.5	DUMP_WHEN_DEBUG	7-3
8.0	STAND ALONE DEADSTART	8-1
9.0	INTERACTIVE PROJECT DUMP ANALYSIS PROCEDURES	9-1
9.1		9-1
9.2		9-1
9.3		9-2
9.4		9-3
10.0	ARDEN HILLS DEVELOPMENT LAB SUPPORT BY INTEGRATION	10-1
	APPENDIX A NOS/VE BACKGROUND DOCUMENTS	A1