

This page contains a grid of 12 columns and 12 rows of technical diagrams and data tables. Each cell in the grid contains a small, detailed schematic or data set, likely representing a specific component or test point within the NI Exerciser system. The diagrams include various symbols, lines, and alphanumeric labels, typical of electronic or mechanical engineering drawings. The overall layout is organized and systematic, facilitating the identification and troubleshooting of system components.

1 000 1 000 1 000 1
 000 1 000 1 000 1
 000 1 000 1 000 1
 000 1 000 1 000 1

.REM 8

IDENTIFICATION

PRODUCT CODE: AC-T227B-MC
PRODUCT NAME: CZUACBO NI EXERCISER DIAGNOSTIC
PRODUCT DATE: 22-MAR-84
MAINTAINER: MERRIMACK DIAGNOSTIC ENGINEERING
AUTHOR: GARY MCCOY

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1983,1984 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL	PDP	UNIBUS	MASSBUS
DEC	DECUS	DECTAPE	

TABLE OF CONTENTS

1.0	GENERAL INFORMATION
1.1	PROGRAM ABSTRACT
1.2	SYSTEM REQUIREMENTS
1.3	RELATED DOCUMENTS AND STANDARDS
1.4	DIAGNOSTIC HIERARCHY PREREQUISITES
1.5	ASSUMPTIONS
1.6	HISTORY
2.0	OPERATING INSTRUCTIONS
2.1	COMMANDS
2.2	SWITCHES
2.3	FLAGS
2.4	HARDWARE QUESTIONS
2.5	SOFTWARE QUESTIONS
2.6	QUICK STARTUP PROCEDURE
3.0	ERROR INFORMATION
4.0	PERFORMANCE AND PROGRESS REPORTS
5.0	DEVICE INFORMATION TABLES
6.0	TEST SUMMARIES
6.1	DIRECT
6.2	LOOPPAIR
6.3	PATTERN
6.4	ALL

1.0 GENERAL INFORMATION

1.1 PROGRAM ABSTRACT

THE NETWORK INTERCONNECT EXERCISER (NIE) PROGRAM IS MEANT TO PROVIDE FIELD SERVICE WITH A TOOL FOR DETERMINING THE CONNECTIVITY OF NODES ON THE NETWORK INTERCONNECT (NI).

THE NIE PROGRAM WILL DETERMINE THE ABILITY OF NODES ON THE NI TO COMMUNICATE WITH EACH OTHER AND PROVIDE NODE INSTALLATION VERIFICATION AND PROBLEM ISOLATION. THE NIE USES THE LOW LEVEL MAINTENANCE FEATURES OF THE DEUNA TO PROVIDE TESTING WITHOUT INTERRUPTING NORMAL OPERATION OF THE NI. THE VAX VERSION OF THE NIE CAN ALSO BE RUN CONCURRENTLY ON ANOTHER NODE, WITH EACH VERSION RUNNING INDEPENDENTLY OF EACH OTHER.

THIS DIAGNOSTIC HAS BEEN WRITTEN FOR USE WITH THE DIAGNOSTIC RUNTIME SERVICES SOFTWARE (SUPERVISOR). THESE SERVICES PROVIDE THE INTERFACE TO THE OPERATOR AND TO THE SOFTWARE ENVIRONMENT. THIS PROGRAM CAN BE USED WITH XXDP+, ACT, APT, SLIDE AND PAPER TAPE. FOR A COMPLETE DESCRIPTION OF THE RUNTIME SERVICES, REFER TO THE XXDP+ USER'S MANUAL. THERE IS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES IN SECTION 2 OF THIS DOCUMENT.

1.2 SYSTEM REQUIREMENTS

IN ORDER TO RUN THE CZUAC NIE PROGRAM, THE FOLLOWING MINIMUM HARDWARE IS REQUIRED:

- A PDP-11 CPU
- MINIMUM OF 24K WORDS OF MEMORY
- A WORKING, LINE OR REAL-TIME CLOCK
- A CONSOLE TERMINAL
- ANY XXDP+ SUPPORTED LOAD MEDIA
- DEUNA-11 UNIBUS TO ETHERNET ADAPTER

1.3 RELATED DOCUMENTS AND STANDARDS

- DEUNA USER'S GUIDE EK-DEUNA-UG-001
- DEUNA TECHNICAL DESCRIPTION EK-DEUNA-TD-001
- XXDP+ USER'S MANUAL (CHQUS?.SEQ WHERE ? IS THE REV. LEVEL OF THE MANUAL - "C" IS THE CURRENT REV.)

1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

THE GOAL OF THE NIE IS TO TEST THE COMMUNICATIONS LINK AND THEREFORE ASSUMES THAT THE CPU'S, CLOCKS, AND DEUNA'S AT EACH END OF THE LINK HAVE ALREADY BEEN TESTED.

IF NO LINE OR REAL-TIME CLOCK IS FOUND, THE PROGRAM WILL CONTINUE BUT ANY OF THE PROGRAM THAT TIMES THE DEVICE WILL HANG IF THE DEVICE TIMES OUT.

IT IS NOT THE INTENTION OF THE NIE TO TEST THE DEVICE (DEUNA), BUT TO TEST THE COMMUNICATIONS LINK TO WHICH IT IS CONNECTED.

THE PREREQUISITE DIAGNOSTICS ARE:

- CZUAAA0 DEUNA REPAIR LEVEL DIAGNOSTIC
- CZUABAO DEUNA FUNCTIONAL LEVEL DIAGNOSTIC

ALSO AVAILABLE FOR TEST IS:

- CXUACAO DEUNA DEC/X-11 MODULE

1.5 ASSUMPTIONS

IT IS ASSUMED THAT THE COMMUNICATIONS DEVICE (DEUNA) HAS BEEN TESTED USING THE PREREQUISITE DIAGNOSTICS. THE OPERATOR SHOULD HAVE READ THE USER DOCUMENTATION PORTION OF THE LISTING TO FAMILIARIZE HIMSELF WITH THE COMMANDS AND CAPABILITIES AVAILABLE UNDER THE DIAGNOSTIC SUPERVISOR AND NIE.

1.6 HISTORY

22-MARCH-84 NICK MCCAMY

THE SECTION "ALL" AND "LOOPPAIR" TESTS HAVE BEEN MODIFIED. THESE SECTIONS WOULD NOT RUN CORRECTLY WHEN NODES WERE DELETED FROM THE NODE TABLE PRIOR TO RUNNING. THE PROGRAM WAS TRYING TO SET-UP THE BLANK SPACE (LEFT BY THE DELETED NODE) AS A TARGET OR ASSIST NODE. THIS PROBLEM HAS BEEN CORRECTED.

2.0 OPERATING INSTRUCTIONS

THIS SECTION CONTAINS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES. FOR DETAILED INFORMATION, REFER TO THE XXDP+ USER'S MANUAL (CHQUS).

2.1 COMMANDS

THERE ARE ELEVEN LEGAL COMMANDS FOR THE DIAGNOSTIC RUNTIME SERVICES (SUPERVISOR). THIS SECTION LISTS THE COMMANDS AND GIVES A VERY BRIEF DESCRIPTION OF THEM. THE XXDP+ USER'S MANUAL HAS MORE DETAILS.

COMMAND	EFFECT
-----	-----
START	START THE DIAGNOSTIC FROM AN INITIAL STATE
RESTART	START THE DIAGNOSTIC WITHOUT INITIALIZING
CONTINUE	CONTINUE AT TEST THAT WAS INTERRUPTED (AFTER +C)
PROCEED	CONTINUE FROM AN ERROR HALT
EXIT	RETURN TO XXDP+ MONITOR (XXDP+ OPERATION ONLY!)
ADD	ACTIVATE A UNIT FOR TESTING (ALL UNITS ARE CONSIDERED TO BE ACTIVE AT START TIME)
DROP	DEACTIVATE A UNIT
PRINT	PRINT STATISTICAL INFORMATION (IF IMPLEMENTED BY THE DIAGNOSTIC - SECTION 4.0)
DISPLAY	TYPE A LIST OF ALL DEVICE INFORMATION
FLAGS	TYPE THE STATE OF ALL FLAGS (SEE SECTION 2.3)
ZFLAGS	CLEAR ALL FLAGS (SEE SECTION 2.3)

A COMMAND CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. SO YOU MAY, FOR EXAMPLE, TYPE "STA" INSTEAD OF "START".

2.2 SWITCHES

THERE ARE SEVERAL SWITCHES WHICH ARE USED TO MODIFY SUPERVISOR OPERATION. THESE SWITCHES ARE APPENDED TO THE LEGAL COMMANDS. ALL OF THE LEGAL SWITCHES ARE TABULATED BELOW WITH A BRIEF DESCRIPTION OF EACH. IN THE DESCRIPTIONS BELOW, A DECIMAL NUMBER IS DESIGNATED BY "DDDDD".

SWITCH	EFFECT
/TESTS:LIST	EXECUTE ONLY THOSE TESTS SPECIFIED IN THE LIST. LIST IS A STRING OF TEST NUMBERS, FOR EXAMPLE - /TESTS:1:5:7-10. THIS LIST WILL CAUSE TESTS 1,5,7,8,9,10 TO BE RUN. ALL OTHER TESTS WILL NOT BE RUN.
/PASS:DDDDD	EXECUTE DDDDD PASSES (DDDDD = 1 TO 64000)
/FLAGS:FLGS	SET SPECIFIED FLAGS. FLAGS ARE DESCRIBED IN SECTION 2.3.
/EOP:DDDDD	REPORT END OF PASS MESSAGE AFTER EVERY DDDDD PASSES ONLY. (DDDDD = 1 TO 64000)
/UNITS:LIST	TEST/ADD/DROP ONLY THOSE UNITS SPECIFIED IN THE LIST. LIST EXAMPLE - /UNITS:0:5:10-12 USE UNITS 0,5,10,11,12 (UNIT NUMBERS = 0-63)

EXAMPLE OF SWITCH USAGE:

START/TESTS:1-5/PASS:1000/EOP:100

THE EFFECT OF THIS COMMAND WILL BE: 1) TESTS 1 THROUGH 5 WILL BE EXECUTED, 2) ALL UNITS WILL TESTED 1000 TIMES AND 3) THE END OF PASS MESSAGES WILL BE PRINTED AFTER EACH 100 PASSES ONLY. A SWITCH CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. YOU MAY, FOR EXAMPLE, TYPE "/TES:1-5" INSTEAD OF "/TESTS:1-5".

BELOW IS A TABLE THAT SPECIFIES WHICH SWITCHES CAN BE USED BY EACH COMMAND.

	TESTS	PASS	FLAGS	EOP	UNITS
START	X	X	X	X	X
RESTART	X	X	X	X	X
CONTINUE		X	X	X	
PROCEED			X		
DROP					X
ADD					X
PRINT					
DISPLAY					X
FLAGS					
ZFLAGS					
EXIT					

2.3 FLAGS

FLAGS ARE USED TO SET UP CERTAIN OPERATIONAL PARAMETERS SUCH AS LOOPING ON ERROR. ALL FLAGS ARE CLEARED AT STARTUP AND REMAIN CLEARED UNTIL EXPLICITLY SET USING THE FLAGS SWITCH. FLAGS ARE ALSO CLEARED AFTER A START COMMAND UNLESS SET USING THE FLAG SWITCH. THE ZFLAGS COMMAND MAY ALSO BE USED TO CLEAR

ALL FLAGS, WITH THE EXCEPTION OF THE START AND ZFLAGS COMMANDS, NO COMMANDS AFFECT THE STATE OF THE FLAGS; THEY REMAIN SET OR CLEARED AS SPECIFIED BY THE LAST FLAG SWITCH.

FLAG	EFFECT
-----	-----
MOE	HALT ON ERROR - CONTROL IS RETURNED TO RUNTIME SERVICES COMMAND MODE
LOE	LOOP ON ERROR
IER*	INHIBIT ALL ERROR REPORTS
IBE*	INHIBIT ALL ERROR REPORTS EXCEPT FIRST LEVEL (FIRST LEVEL CONTAINS ERROR TYPE, NUMBER, PC, TEST AND UNIT)
IXE*	INHIBIT EXTENDED ERROR REPORTS (THOSE CALLED BY PRINTX MACRO'S)
PRI	DIRECT MESSAGES TO LINE PRINTER
PNT	PRINT TEST NUMBER AS TEST EXECUTES
BOE	"BELL" ON ERROR
UAM	UNATTENDED MODE (NO MANUAL INTERVENTION)
ISR	INHIBIT STATISTICAL REPORTS (DOES NOT APPLY TO DIAGNOSTICS WHICH DO NOT SUPPORT STATISTICAL REPORTING)
IDR	INHIBIT PROGRAM DROPPING OF UNITS
ADR	EXECUTE AUTODROP CODE
LOT	LOOP ON TEST
EVL	EXECUTE EVALUATION (ON DIAGNOSTICS WHICH HAVE EVALUATION SUPPORT)

*ERROR MESSAGES ARE DESCRIBED IN SECTION 3.1

SEE THE XXDP* USER'S MANUAL FOR MORE DETAILS ON FLAGS. YOU MAY SPECIFY MORE THAN ONE FLAG WITH THE FLAG SWITCH. FOR EXAMPLE, TO CAUSE THE PROGRAM TO LOOP ON ERROR, INHIBIT ERROR REPORTS AND TYPE A "BELL" ON ERROR, YOU MAY USE THE FOLLOWING STRING:

```
/FLAGS:LOE:IER:BOE
```

2.4 HARDWARE QUESTIONS

WHEN A DIAGNOSTIC IS STARTED, THE RUNTIME SERVICES WILL PROMPT THE USER FOR HARDWARE INFORMATION BY TYPING "CHANGE HW (L) ?" YOU MUST ANSWER "Y" AFTER A START COMMAND UNLESS THE HARDWARE INFORMATION HAS BEEN "PRELOADED" USING THE SETUP UTILITY (SEE CHAPTER 6 OF THE XXDP* USER'S MANUAL). WHEN YOU ANSWER THIS QUESTION WITH A "Y", THE RUNTIME SERVICES WILL ASK FOR THE NUMBER OF UNITS (IN DECIMAL). YOU WILL THEN BE ASKED THE FOLLOWING QUESTIONS FOR EACH UNIT.

```
* UNITS (D) ? 1<CR>
```

```
UNIT 0
DEVICE CSR ADDRESS : (0) 164524 ?<CR>
INTERRUPT VECTOR ADDRESS : (0) 120 ?<CR>
INTERRUPT PRIORITY : (0) 5 ?<CR>
```


WHEN YOU COMPLETE THE ABOVE SEQUENCE YOU WILL BE AT THE NIE>
COMMAND LEVEL.

NIE> (A) ?

2.5 NETWORK INTERCONNECT EXERCISER COMMANDS

THE "NIE>" COMMAND LEVEL FOLLOWS THE ATTACHING OF THE DEVICE AND ISSUING THE START TO THE SUPERVISOR. THESE COMMANDS CAN BE TYPED WHEN THE "NIE>" PROMPT IS PRINTED.

YOU ONLY HAVE TO TYPE ENOUGH CHARACTERS TO UNIQUELY SPECIFY A COMMAND. THE COMMAND LINE IS INTERPRETED FROM LEFT TO RIGHT.

HELP OR ? PRINTS OUT A BRIEF DESCRIPTION OF NIE COMMANDS.

SHOW NODES PRINTS OUT THE CONTENTS OF THE NODE TABLE.

SHOW MESSAGE PRINTS OUT THE CURRENT MESSAGE PARAMETERS FOR SIZE, TYPE AND COPIES.

SHOW COUNTERS PRINTS OUT THE CONTENTS OF THE HOST NODE DEUNA INTERNAL COUNTERS.

NODE ADR/TYPE THE NODE COMMAND ALLOWS THE OPERATOR TO ENTER NODES INTO THE NODE TABLE. NODES ARE SPECIFIED USING THEIR 12 HEX DIGIT ETHERNET PHYSICAL ADDRESS AND CAN BE SPECIFIED AS EITHER TARGET OR ASSIST (A DEFAULT OF TARGET IS ASSUMED).

MESSAGE/TYPE=/SIZE=N/COPIES=M THE MESSAGE COMMAND ALLOWS THE OPERATOR TO SELECT THE CURRENT MESSAGE PARAMETERS AS FOLLOWS. ANY OR ALL OF THE PARAMETER CAN BE CHANGED WITH THE COMMAND. THE DEFAULT PARAMETERS ARE TYPE=ALPHA,SIZE=512,COPIES=1.

TYPE ONE OF THE FOLLOWING MESSAGE TYPES:

ALPHA -- !"#\$%&'()*+,-./0123456789;:=?ABCDEFGH ETC.

ONES -- MESSAGE OF ALL ONES (11111111....)

ZEROS -- MESSAGE OF ALL ZEROS (00000000....)

1ALT -- ALTERNATING 1'S AND 0'S (10101010....)

0ALT -- ALTERNATING 0'S AND 1'S (01010101....)

CCITT -- "CCITT" PSEUDO-RANDOM TEST PATTERN

OPERATOR SELECTED -- OPERATOR CHOSEN PATTERN OF LESS THAN 72 CHARACTERS USING 0-9, A-Z AND SPACES. (NOT USED IN PATTERN TEST)

SIZE THE SIZE OF THE MESSAGE BUFFER (DATA ONLY)MAY BE BETWEEN 32 AND 1466 BYTES.

COPIES THE NUMBER OF COPIES OF EACH MESSAGE SENT TO EACH NODE DURING A TEST MAY BE BETWEEN 1 AND 255.

RUN TEST/PASS=NN CAUSES EXECUTION OF THE SPECIFIED TEST FOR NN NUMBER OF PASSES. A DEFAULT VALUE OF 1 IS ASSUMED IF /PASS=NN IS

NOT INCLUDED IN THE COMMAND LINE. A VALUE OF NN=-1 WILL CAUSE THE TEST TO BE RUN INDEFINATELY. NODE ADDRESSES FOR THE TESTS ARE TAKEN FROM THE NODE TABLE AND SHOULD BE ENTERED PRIOR TO RUNNING THE TEST USING THE NODE COMMAND. IN THE CASE OF THE LOOPPAIR TEST, NODE PAIRS ARE REQUIRED AND MUST BE SPECIFIED AS TARGET AND ASSIST NODES. THE CURRENTLY SELECTED VALUES FOR MESSAGE TYPE, SIZE AND COPIES ARE USED BY EACH TEST.

THERE ARE FOUR TEST TO CHOSE FROM:

DIRECT

THE DIRECT TEST SENDS A LOOP DIRECT MESSAGE TO ALL OF THE NODES CONTAINED IN THE NODE TABLE AND WAITS FOR A RESPONSE. THE INTEGRITY OF THE RETURNED DATA IS CHECKED AND ANY ERRORS ARE REPORTED TO THE OPERATOR.

LOOPPAIR

THE LOOPPAIR TEST SENDS ASSISTED LOOPBACK MESSAGES TO THE NODE PAIRS CONTAINED IN THE NODE TABLE. THREE TYPE OF ASSISTED MESSAGES ARE SENT:

- 1) RECEIVE ASSIST -- HOST -> TARGET -> ASSIST -> HOST
- 2) TRANSMIT ASSIST -- HOST -> ASSIST -> TARGET -> HOST
- 3) FULL ASSIST -- HOST -> ASSIST -> TARGET -> ASSIST -> HOST

IN EACH CASE A RESPONSE IS WAITED FOR AND THE DATA IS CHECKED.

WHEN RUNNING THE LOOPPAIR TEST, BE VERY CAREFUL WHEN DELETING NODES. IT IS BETTER TO DELETE NODES IN PAIRS (ONE TARGET NODE AND ONE ASSIST NODE).

*** IMPORTANT!! *** ---> THE LOOPPAIR TEST EXPECTS THAT EACH TARGET NODE HAVE A CORRESPONDING ASSIST NODE, AND THAT THE ORDER OF THE NODES IN THE NODE TABLE BE THE FOLLOWING:

FIRST NODE IN TABLE: TARGET
 2ND NODE IN TABLE: ASSIST
 3RD NODE IN TABLE: TARGET
 4TH NODE IN TABLE: ASSIST
 ETC.

BE VERY CAREFUL WHEN DELETING NODES. IT IS BEST TO DELETE NODES IN PAIRS (ONE TARGET NODE AND ONE ASSIST NODE).

PATTERN

THE PATTERN TEST SENDS SIX DIFFERENT LOOP DIRECT MESSAGES TO EACH NODE CONTAINED IN THE NODE TABLE. EACH OF THE SIX PATTERN TYPES (ALPHA, ONES, ZEROS, 1ALT, 0ALT, CCITT) IS USED FOR EACH NODE. RETURNED DATA IS CHECKED FOR ERRORS.

ALL

THE ALL NODE TEST PERFORMS THE MOST EXTENSIVE CHECK OF THE NETWORK AND IS COMPOSED OF TWO PARTS. FIRST A LOOP DIRECT MESSAGE IS SENT TO EACH NODE IN THE TABLE. IF THIS IS SUCCESSFUL, THE EXERCISER BUILDS AN ARRAY OF NODE PAIRS FROM THE TABLE AND SENDS A FULL ASSISTED LOOPBACK MESSAGE TO EACH PAIR IN THE ARRAY. A SAMPLE ARRAY OF PAIRS FOR A TABLE WITH 7 NODES IS SHOWN BELOW.

1-2	2-3	3-4	4-5	5-6	6-7
1-3	2-4	3-5	4-6	5-7	
1-4	2-5	3-6	4-7		
1-5	2-6	3-7			
1-6	2-7				
1-7					

- IDENTIFY ADR A REQUEST ID MESSAGE IS SENT TO THE NODE SPECIFIED BY ADR AND THE RESPONDED SYSTEM ID PARAMETERS ARE PRINTED.

- BUILD THE BUILD COMMAND CAUSES THE EXERCISERS TO LISTEN FOR SYSTEM ID MESSAGES WHICH ARE BROADCAST BY ALL DEUNA NODES ONCE EVERY 10 MINUTES. ALL NODES IDENTIFYING THEMSELVES ARE ADDED TO THE NODE TABLE. THE BUILD COMMAND STOPS WHEN NO NEW NODES HAVE BEEN ADDED FOR 10 MINUTES OR WHEN 40 MINUTES HAVE ELAPSED. THE AVERAGE TIME FOR THIS COMMAND SHOULD BE 15-25 MINUTES.

- CLEAR NODE/ADR THE CLEAR NODE COMMAND CLEARS THE SPECIFIED NODE FROM THE NODE TABLE. THE NODE CAN BE SPECIFIED BY EITHER ITS 12 DIGIT PHYSICAL ADDRESS OF ITS LOGICAL NAME (AS ASSIGNED BY NODE TABLE).

- CLEAR NODE/ALL THIS COMMAND CLEARS THE NODE TABLE.

- CLEAR MESSAGE THIS COMMAND SETS THE MESSAGE PARAMETERS BACK TO THE DEFAULT VALUES.

- CLEAR SUMMARY THIS COMMAND CLEARS THE SUMMARY TABLE.

- SUMMARY THE SUMMARY COMMAND PRINTS OUT THE SUMMARY TABLE. THE NIE MAINTAINS THE FOLLOWING INFORMATION FOR NODES WHO HAVE BEEN SENT MESSAGES:

RECEIVES NOT COMPLETE	RECEIVES COMPLETE
LENGTH ERRORS	DATA COMPARE ERRORS
BYTES COMPARED	BYTES TRANSFERED

- SAVE THE SAVE COMMAND SAVES THE CONTENTS OF THE NODE TABLE. FOR THE VAX VERSION, THE TABLE IS SAVED IN A FILE CALLED NIE.TBL. THE PDP-11 VERSION CANNOT WRITE TO EXTERNAL MEDIA, SO THE CONTENTS ARE SAVE INTERNALLY.

- UNSAVE THE UNSAVE COMMAND RESTORES THE CONTENTS OF THE NODE TABLE. USED. THE PDP-11 VERSION USES THE CONTENTS OF ITS INTERNALLY SAVED TABLE.

- UNSAVE/FILE.EXT THE UNSAVE COMMAND WHEN USED WITH A FILE NAME WILL READ A NODE TABLE CREATED BY USING AN EDITOR FOR AN XXDP+ MEDIA.

- EXIT RETURNS CONTROL TO THE DIAGNOSTIC SUPERVISOR (EITHER VDS OR DRS).

NOTES: 1) ADR IS THE PHYSICAL ADDRESS OF A NODE ON THE NI.
 2) PASS COUNT IS A DECIMAL NUMBER BETWEEN 1 AND 65534.

A DEFAULT VALUE OF 1 IS ASSUMED. SPECIFYING -1 CAUSES THE TEST TO BE RUN INDEFINATELY.

2.5 SOFTWARE QUESTIONS

AFTER YOU HAVE ANSWERED THE HARDWARE QUESTIONS OR AFTER A RESTART OR CONTINUE COMMAND, THE RUNTIME SERVICES WILL ASK FOR SOFTWARE PARAMETERS. THESE PARAMETERS WILL GOVERN SOME DIAGNOSTIC SPECIFIC OPERATION MODES. YOU WILL BE PROMPTED BY "CHANGE SW (L) ?" IF YOU WISH TO CHANGE ANY PARAMETERS, ANSWER BY TYPING "Y". THE SOFTWARE QUESTIONS AND THE DEFAULT VALUES ARE DESCRIBED IN THE NEXT PARAGRAPH(S).

2.6 QUICK START-UP PROCEDURE (XXDP+)

TO START-UP THIS PROGRAM:

1. BOOT XXDP+
2. GIVE THE DATE AND ANSWER THE LSI AND 50HZ (IF THERE IS A CLOCK) QUESTIONS
3. TYPE "R NAME", WHERE NAME IS THE NAME OF THE BIN OR BIC FILE FOR THIS PROGRAM
4. TYPE "START"
5. ANSWER THE "CHANGE HW" QUESTION WITH "Y"
6. ANSWER ALL THE HARDWARE QUESTIONS
7. ANSWER THE "CHANGE SW" QUESTION WITH "N"

WHEN YOU FOLLOW THIS PROCEDURE YOU WILL BE USING ONLY THE DEFAULTS FOR FLAGS AND SOFTWARE PARAMETERS. THESE DEFAULTS ARE DESCRIBED IN SECTIONS 2.3 AND 2.5.

3.0 ERROR INFORMATION

3.1 TYPES OF ERROR MESSAGES

THERE ARE THREE LEVELS OF ERROR MESSAGES THAT MAY BE ISSUED BY A DIAGNOSTIC: GENERAL, BASIC AND EXTENDED. GENERAL ERROR MESSAGES ARE ALWAYS PRINTED UNLESS THE "IER" FLAG IS SET (SECTION 2.3). THE GENERAL ERROR MESSAGE IS OF THE FORM:

```
NAME TYPE NUMBER ON UNIT NUMBER TST NUMBER PC:XXXXXX
ERROR MESSAGE
```

,WHERE; NAME = DIAGNOSTIC NAME
 TYPE = ERROR TYPE (SYS FATAL, DEV FATAL, HARD OR SOFT)
 NUMBER = ERROR NUMBER
 UNIT NUMBER = 0 - N (N IS LAST UNIT IN PTABLE)
 TST NUMBER = TEST AND SUBTEST WHERE ERROR OCCURRED
 PC:XXXXXX = ADDRESS OF ERROR MESSAGE CALL

BASIC ERROR MESSAGES ARE MESSAGES THAT CONTAIN SOME ADDITIONAL INFORMATION ABOUT THE ERROR. THESE ARE ALWAYS PRINTED UNLESS THE "IER" OR "IBR" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL MESSAGE.

EXTENDED ERROR MESSAGES CONTAIN SUPPLEMENTARY ERROR INFORMATION SUCH AS REGISTER CONTENTS OR GOOD/BAD DATA. THESE ARE ALWAYS PRINTED UNLESS THE "IER", "IBR" OR "IXR" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL ERROR MESSAGE AND ANY ASSOCIATED BASIC ERROR MESSAGES.

3.2 SPECIFIC ERROR MESSAGES

ERROR MESSAGE: -----	MEANING -----
?ILL CMD-BAD SYNTAX	A COMMAND WITH AN ILLEGAL CHAR WAS TYPED - RETYPE THE COMMAND. THE VAILD COMMANDS AND THEIR SYNTAX ARE SHOWN IN SECTION 2.5
?INCOMPLETE	A REQUIRED PART OF A COMMAND WAS LEFT OUT.
?NUMBER TOO BIG	THE VALUE OF A NUMERIC STRING IN THE COMMAND LINE WAS LARGER THAN 65535 OR 177777 OCTAL. (>16 BITS).
?BAD RADIX	A "8" OR "9" WAS TYPED WHEN AN OCTAL STRING WAS EXPECTED. PROBABLY OCCURED WHEN TYPING A "DUMP" COMMAND WHERE OCTAL ADDRESSES ARE EXPECTED.

EXAMPLE OF A LOST PACKET ERROR DURING LOOPPAIR TESTING

CZUAC HRD ERR 00028 ON UNIT 00 TST 001 SUB 000 PC:064442

TIMEOUT OCCURED - LOOP MESSAGE TYPE - RECEIVE ASSIST
FAILING TARGET NODE ADDRESS: AA-00-03-00-00-00
FAILING ASSIST NODE ADDRESS: AA-00-03-00-00-02

EXAMPLE OF A LOST PACKET ERROR DURING PATTERN TESTING

CZUAC HRD ERR 00028 ON UNIT 00 TST 001 SUB 000 PC:63730

TIMEOUT OCCURED BEFORE LOOPBACK REPLY
FAILING NODE ADDRESS: AA-00-03-00-00-00
DATA PATTERN: ONES

4.0 PERFORMANCE AND PROGRESS REPORTS

AT THE END OF EACH PASS, THE PASS COUNT IS GIVEN ALONG WITH THE TOTAL NUMBER OF ERRORS REPORTED SINCE THE DIAGNOSTIC WAS STARTED. THE "EOP" SWITCH CAN BE USED TO CONTROL HOW OFTEN THE END OF PASS MESSAGE IS PRINTED. SECTION 2.2 DESCRIBES SWITCHES.

5.0 DEVICE INFORMATION TABLES

THIS IS THE DEFAULT HARDWARE P-TABLE. THE VALUES AND SIZE ARE USED AS A "TEMPLATE" FOR CREATING ACTUAL P-TABLE ENTRIES AND THE DEFAULT VALUES PROVIDED FOR THE OPERATOR. SEE SECTION 2.4 FOR AN EXAMPLE OF THE HARDWARE QUESTIONS.

THE NUMBERS IN BRACKETS (I.E. [6]) INDICATES THE OFFSET OF THE WORD INTO THE HARDWARE P-TABLE. THE OFFSETS MUST MATCH THE P-TABLE OFFSETS USED IN THE HARDWARE PARAMETER CODING SECTION WHERE THE "GET PARAMETER" CALLS ARE USED TO FILL THE P-TABLE.

```
.WORD 174510      ;[0] CSR ADDRESS
.WORD 120         ;[2] INTERRUPT VECTOR
.WORD 240         ;[6] INTERRUPT PRIORITY (5)
```

6.0 TEST SUMMARIES

6.1 DIRECT

THE DIRECT TEST SENDS A LOOP DIRECT MESSAGE TO ALL OF THE NODES CONTAINED IN THE NODE TABLE AND WAITS FOR A RESPONSE. THE INTEGRITY OF THE RETURNED DATA IS CHECKED AND ANY ERRORS ARE REPORTED TO THE OPERATOR.

6.2 LOOPPAIR

THE LOOPPAIR TEST SENDS ASSISTED LOOPBACK MESSAGES TO THE NODE PAIRS CONTAINED IN THE NODE TABLE. THREE TYPE OF ASSISTED MESSAGES ARE SENT:

- 1) RECEIVE ASSIST -- HOST -> TARGET -> ASSIST -> HOST
- 2) TRANSMIT ASSIST -- HOST -> ASSIST -> TARGET -> HOST
- 3) FULL ASSIST -- HOST -> ASSIST -> TARGET -> ASSIST -> HOST

IN EACH CASE A RESPONSE IS WAITED FOR AND THE DATA IS CHECKED.

6.3 PATTERN

THE PATTERN TEST SENDS SIX DIFFERENT LOOP DIRECT MESSAGES TO EACH NODE CONTAINED IN THE NODE TABLE. EACH OF THE SIX PATTERN TYPES (ALPHA, ONES, ZEROS, 1ALT, 0ALT, CCITT) IS USED FOR EACH NODE. RETURNED DATA IS CHECKED FOR ERRORS.

6.4 ALL

THE ALL NODE TEST PERFORMS THE MOST EXTENSIVE CHECK OF THE NETWORK AND IS COMPOSED OF TWO PARTS. FIRST A LOOP DIRECT MESSAGE IS SENT TO EACH NODE IN THE TABLE. IF THIS IS SUCCESSFUL, THE EXERCISER BUILDS AN ARRAY OF NODE PAIRS FROM THE TABLE AND SENDS A FULL ASSISTED LOOPBACK MESSAGE TO EACH PAIR IN THE ARRAY. A SAMPLE ARRAY OF PAIRS FOR A TABLE WITH 7 NODES IS SHOWN BELOW.

1-2	2-3	3-4	4-5	5-6	6-7
1-3	2-4	3-5	4-6	5-7	
1-4	2-5	3-6	4-7		
1-5	2-6	3-7			
1-6	2-7				
1-7					

&

683
709
710 000000
711 002000
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754

```

.SBTTL PROGRAM HEADER
      .ENABL ABS,AMA
      = 2000

.SBTTL PROGRAM MACROS

;I$STACK MACRO
;-----

;+++
;THE I$STACK MACRO FACILITATES INITIALIZING THE R6 (HARDWARE) STACK
;AND THE R5 (PARAMETER) STACK. R5 IS SET TO THE STACK LOW LIMIT
;(STAKLO) AND THE PARAMETER STACK GROWS UPWARD. R6 IS SET TO THE
;STACK HIGH LIMIT (STAKHI) AND THE HARDWARE STACK GROWS DOWNWARD.
;IF THERE IS A STACK OVER-RUN, IT WILL BE DETECTED BY THE PREG14
;ROUTINE.
;----

.MACRO I$STACK STAKLO,STAKHI
MOV STAKLO,R5 ;INITIALIZE THE PARAMETER STACK POINTER.
MOV STAKHI,SP ;INITIALIZE THE HARDWARE STACK POINTER.

.ENDM I$STACK

;PUSH MACRO
;-----

;+++
;THE "PUSH" MACRO FACILITATES PUSHING ITEMS ON THE HARDWARE STACK.
;UP TO SEVEN ITEMS MAY BE PLACED ON THE STACK WITH ONE MACRO.
;----

.MACRO PUSH A,B,C,D,E,F,G

  .IF NB G
  MOV G,-(SP)
  .ENDC

  .IF NB F
  MOV F,-(SP)
  .ENDC

  .IF NB E
  MOV E,-(SP)

```

```
755 .ENDC
756
757 .IF NB D
758 MOV D, -(SP)
759 .ENDC
760
761 .IF NB C
762 MOV C, -(SP)
763 .ENDC
764
765 .IF NB B
766 MOV B, -(SP)
767 .ENDC
768
769 .IF NB A
770 MOV A, -(SP)
771 .ENDC
772
773 .ENDM PUSH
774
775 ;POP MACRO
776 ;-----
777
778 ;+++
779 ;THE "POP" MACRO FACILITATES RETRIEVING ITEMS FROM THE HARDWARE STACK.
780 ;UP TO SEVEN ITEMS MAY BE RETRIEVED WITH ONE MACRO.
781 ;---
782
783 .MACRO POP A,B,C,D,E,F,G
784
785 .IF NB A
786 MOV (SP),A
787 .ENDC
788
789 .IF NB B
790 MOV (SP),B
791 .ENDC
792
793 .IF NB C
794 MOV (SP),C
795 .ENDC
796
797 .IF NB D
798 MOV (SP),D
799 .ENDC
800
801 .IF NB E
802 MOV (SP),E
803 .ENDC
804
805 .IF NB F
806 MOV (SP),F
807 .ENDC
808
809 .IF NB G
810 MOV (SP),G
811 .ENDC
```


812
 813
 814
 815
 816
 817
 818
 819
 820
 821
 822
 823
 824
 825
 826
 827
 828
 829
 830
 831
 832
 833
 834
 835
 836
 837
 838
 839
 840
 841
 842
 843
 844
 845
 846
 847
 848
 849
 850
 851
 852
 853
 854
 855
 856
 857
 858
 859
 860
 861
 862
 863
 864
 865
 866
 867
 868

```
.ENDM POP
;CALL MACRO
;-----
;***
;THE CALL MACRO FACILITATES CALLING A SUBROUTINE VIA THE REGISTER
;PRESERVE ROUTINE (PREG14). IT PLACES THE PARAMETERS TO BE PASSED ON
;THE PARAMETER STACK. UP TO 7 PARAMETERS MAY BE PASSED USING THIS
;MACRO.
;----
.MACRO CALL S A,B,C,D,E,F,G
    .IF NB G
    MOV G,(R5)
    .ENDC
    .IF NB F
    MOV F,(R5)
    .ENDC
    .IF NB E
    MOV E,(R5)
    .ENDC
    .IF NB D
    MOV D,(R5)
    .ENDC
    .IF NB C
    MOV C,(R5)
    .ENDC
    .IF NB B
    MOV B,(R5)
    .ENDC
    .IF NB A
    MOV A,(R5)
    .ENDC
    JSR R4,PREG14
    .WORD S-ANCHOR
.ENDM CALL
;RETURN MACRO
;-----
;***
;THE RETURN MACRO FACILITATES PASSING PARAMETERS BACK TO A CALLING
;ROUTINE. UP TO 7 PARAMETERS MAY BE PASSED BACK ON THE PARAMETER
;STACK.
;----
```

```

869      .MACRO RETURN A,B,C,D,E,F,G
870
871      .IF NB G
872      MOV     G,(R5)+
873      .ENDC
874
875      .IF NB F
876      MOV     F,(R5)+
877      .ENDC
878
879      .IF NB E
880      MOV     E,(R5)+
881      .ENDC
882
883      .IF NB D
884      MOV     D,(R5)+
885      .ENDC
886
887      .IF NB C
888      MOV     C,(R5)+
889      .ENDC
890
891      .IF NB B
892      MOV     B,(R5)+
893      .ENDC
894
895      .IF NB A
896      MOV     A,(R5)+
897      .ENDC
898
899      RTS     PC
900
901      .ENDM RETURN
902
903      ;P$PUSH MACRO
904      ;-----
905
906      ;***
907      ;THE P$PUSH MACRO FACILITATES PUSHING PARAMETERS ON THE PARAMETER
908      ;STACK. UP TO SEVEN ITEMS MAY BE PUSHED WITH ONE MACRO.
909      ;---
910
911      .MACRO P$PUSH A,B,C,D,E,F,G
912
913      .IF NB G
914      MOV     G,(R5)+
915      .ENDC
916
917      .IF NB F
918      MOV     F,(R5)+
919      .ENDC
920
921      .IF NB E
922      MOV     E,(R5)+
923      .ENDC
924
925      .IF NB D

```



```

926      MOV      D,(R5)+
927      .ENDC
928
929      .IF NB C
930      MOV      C,(R5)+
931      .ENDC
932
933      .IF NB B
934      MOV      B,(R5)+
935      .ENDC
936
937      .IF NB A
938      MOV      A,(R5)+
939      .ENDC
940
941      .ENDM    P$PUSH
942
943      ;P$POP MACRO
944      ;-----
945
946
947
948      ;***
949      ;THE P$POP MACRO FACILITATES RETRIEVING PARAMETERS FROM THE PARAMETER
950      ;STACK.  UP TO 7 PARAMETERS MAY BE RETRIEVED.
951      ;
952      ;THE ROUTINE THAT RECEIVES THE PARAMETERS HAS THE RESPONSIBILITY OF
953      ;CLEANING UP THE PARAMETER STACK.  THIS MACRO IS AN AID TO MAKING
954      ;A LOCAL COPY OF PASSED PARAMETERS AND CLEANING UP THE PARAMETER STACK.
955      ;---
956
957      .MACRO P$POP  A,B,C,D,E,F,G
958
959      .IF NB A
960      MOV      -(R5),A
961      .ENDC
962
963      .IF NB B
964      MOV      -(R5),B
965      .ENDC
966
967      .IF NB C
968      MOV      -(R5),C
969      .ENDC
970
971      .IF NB D
972      MOV      -(R5),D
973      .ENDC
974
975      .IF NB E
976      MOV      -(R5),E
977      .ENDC
978
979      .IF NB F
980      MOV      -(R5),F
981      .ENDC
982
983      .IF NB G

```

```

983          MOV      -(R5),G
984          .ENDC
985
986          .ENDM   P$POP
987
988
993
994          .MACRO  CLI      CHAR,HITVAL,MISADR,CMPSTR
995          NODCL   CHAR,HITVAL,\X$,MISADR,CMPSTR  ;;#### PARSE TREE ####
996          .ENDM
997
998
999          .MACRO  NODCL   CHAR,HITVAL,XY,MISADR,CMPSTR
1000 NOD'XY: .BYTE   CHAR,HITVAL                    ;SPECIAL CHAR. CODE OR COMPARE CHAR.
1001                                           ; AND ACTION (HIT) VALUE FOR ACTION
1002                                           ; ROUTINES.
1003
1004          .IF NB  MISADR   .WORD   MISADR-NOD'XY          ;DISPLACEMENT TO "MISS" NODE (BYTES)
1005          .ENDC
1006          .IF NB  CMPSTR   .WORD   1$-NOD'XY              ;DISPLACEMENT TO GET TO NEXT NODE
1007          .ASCIZ  CMPSTR   .EVEN                          ; (ONLY IF ITS A "CLISTR" NODE)
1008          .EVEN
1009
1010          .NLIST
1011          1$:
1012          .LIST
1013          .ENDC
1014          .NLIST
1015          X$=X$+1
1016          .LIST
1017          .ENDM
1018
1019          .MACRO  RNGFRM A,B,C
1020                                           ; MACRO TO FORM TRANSMIT AND RECIEVE
1021                                           ; DESCRIPTOR RINGS.
1022
1023          .LIST
1024          .WORD   RPKLEN
1025          .NLIST
1026          NEXT   A,\B
1027          B=B+1
1028          .LIST
1029          .WORD   C
1030          .WORD   0
1031          .WORD   0
1032          .NLIST
1033          .ENDM
1034
1035          .MACRO  NEXT A,B
1036          .LIST
1037          .WORD   A'B
1038          .NLIST
1039          .ENDM
1040
1041          ;**
1042          ; THE PROGRAM HEADER IS THE INTERFACE BETWEEN
1043          ; THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.

```



```

1044
1045
1046 002000          POINTER BGNRPT
1047
1064
1065 002000          HEADER CZUAC,A,0,0,1,PRI07
002000
002000          103
002001          132
002002          125
002003          101
002004          103
002005          000
002006          000
002007          000
002010
002010          101
002011
002011          060
002012
002012          000000
002014
002014          000000
002016
002016          112762
002020
002020          000000
002022
002022          002170
002024
002024          000000
002026
002026          113166
002030
002030          000000
002032
002032          000000
002034
002034          000001
002036
002036          000000
002040
002040          002164
002042
002042          000340
002044
002044          000000
002046
002046          000000
002050
002050          003
002051          003
002052
002052          000000
002054          000000
002056
002056          000000

```

```

L$NAME::
          .ASCII /C/
          .ASCII /Z/
          .ASCII /U/
          .ASCII /A/
          .ASCII /C/
          .BYTE 0
          .BYTE 0
          .BYTE 0
L$REV::
          .ASCII /A/
L$DEPO::
          .ASCII /O/
L$UNIT::
          .WORD 0
L$TIML::
          .WORD 0
L$HPCP::
          .WORD L$HARD
L$SPCP::
          .WORD 0
L$HPTP::
          .WORD L$HW
L$SPTP::
          .WORD 0
L$LADP::
          .WORD L$LAST
L$STA::
          .WORD 0
L$CO::
          .WORD 0
L$DTYP::
          .WORD 1
L$APT::
          .WORD 0
L$DTP::
          .WORD L$DISPATCH
L$PRIO::
          .WORD PRI07
L$ENVI::
          .WORD 0
L$EXP1::
          .WORD 0
L$MREV::
          .BYTE C$REVISION
          .BYTE C$EDIT
L$EF::
          .WORD 0
          .WORD 0
L$SPC::
          .WORD 0

```

002060
 002060 002122
 002062
 002062 076560
 002064
 002064 000000
 002066
 002066 000000
 002070
 002070 000000
 002072
 002072 000000
 002074
 002074 000000
 002076
 002076 002130
 002100
 002100 104035
 002102
 002102 000000
 002104
 002104 076600
 002106
 002106 100142
 002110
 002110 100140
 002112
 002112 076572
 002114
 002114 000000
 002116
 002116 000000
 002120
 002120 000000

L\$DEVP:: .WORD L\$DVTYP
 L\$REPP:: .WORD L\$RPT
 L\$EXP4:: .WORD 0
 L\$EXP5:: .WORD 0
 L\$AUT:: .WORD 0
 L\$DUT:: .WORD 0
 L\$LUN:: .WORD 0
 L\$DESP:: .WORD L\$DESC
 L\$LOAD:: EMT E\$LOAD
 L\$ETP:: .WORD 0
 L\$ICP:: .WORD L\$INIT
 L\$CCP:: .WORD L\$CLEAN
 L\$ACP:: .WORD L\$AUTO
 L\$PRT:: .WORD L\$PROT
 L\$TEST:: .WORD 0
 L\$DLY:: .WORD 0
 L\$HIME:: .WORD 0

1066
 1077
 1078
 1079
 1080

```

:
: NAMES OF DEVICES SUPPORTED BY PROGRAM
:
:
  
```

1081 002122
 002122
 002122 104 105 125
 002125 116 101 000

L\$DVTYP:: .ASCIZ /DEUNA/
 .EVEN

1082
 1088
 1089
 1090

```

: TEST DESCRIPTION
:
:
  
```

1091 002130
 002130
 002130 103 132 125
 CISER/ 002133 101 103 040
 002136 104 105 125
 002141 116 101 040
 002144 116 111 040
 002147 105 130 105
 002152 122 103 111

L\$DESC:: .ASCIZ /CZUAC DEUNA NI EXER

002155 123 105 122
002160 000

1092
1093
1100
1101
1102
1103
1104
1115
1116

.EVEN

.EVEN

;
; FORMAT STATEMENTS USED IN PRINT CALLS
;

1125
 1126
 1127
 1128
 1129
 1130
 1131
 1132 002162
 002162 000001
 002164
 002164 100274
 1133

.SBTTL DISPATCH TABLE

; **
 ; THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.
 ; IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.
 ; --

DISPATCH 1

.WORD 1
 L\$DISPATCH: :
 .WORD T1

1141
1142
1143
1144
1145
1146
1147
1148
1149
1150 002166
002166 000003
002170
002170
1151
1152 002170 174510
1153 002172 000120
1154 002174 000240
1155
1165
1166 002176
002176

.SBTTL DEFAULT HARDWARE P-TABLE

; **
; THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
; THE TEST-DEVICE PARAMETERS. THE STRUCTURE OF THIS TABLE
; IS IDENTICAL TO THE STRUCTURE OF THE HARDWARE P-TABLES,
; AND IS USED AS A "TEMPLATE" FOR BUILDING THE P-TABLES.
; --

BGNHW DFPTBL

.WORD L10000-L\$HW/2
L\$HW::
DFPTBL::

.WORD 174510 ; CSR
.WORD 120 ; VECTOR
.WORD PRI05 ; PRIORITY

ENDHW

L10000:

1169
 1170
 1171
 1172
 1173
 1174
 1175
 1176
 1177
 1178
 1179 002176
 002176 000000
 002200
 002200
 1180
 1188
 1189 002200
 002200
 1190
 1191
 1192
 1202
 1203
 1204
 1205
 1206
 1207
 1208
 1223
 1224 002200

.SBTTL SOFTWARE P-TABLE

```

; **
; THE SOFTWARE TABLE CONTAINS VARIOUS DATA USED BY THE
; PROGRAM AS OPERATIONAL PARAMETERS. THESE PARAMETERS ARE
; SET UP AT ASSEMBLY TIME AND MAY BE VARIED BY THE OPERATOR
; AT RUN TIME.
; --

```

BGNSW SFPTBL

```

.LWORD L10001-L$SW/2
L$SW::
SFPTBL::

```

ENDSW

L10001:

.SBTTL GLOBAL EQUATES SECTION

```

; **
; THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT
; ARE USED IN MORE THAN ONE TEST.
; --

```

EQUALS

; BIT DIFINITIONS

```

100000 BIT15== 100000
040000 BIT14== 40000
020000 BIT13== 20000
010000 BIT12== 10000
004000 BIT11== 4000
002000 BIT10== 2000
001000 BIT09== 1000
000400 BIT08== 400
000200 BIT07== 200
000100 BIT06== 100
000040 BIT05== 40
000020 BIT04== 20
000010 BIT03== 10
000004 BIT02== 4
000002 BIT01== 2
000001 BIT00== 1

001000 BIT9== BIT09
000400 BIT8== BIT08
000200 BIT7== BIT07
000100 BIT6== BIT06
000040 BIT5== BIT05
000020 BIT4== BIT04
000010 BIT3== BIT03

```



```

000004      BIT2== BIT02
000002      BIT1== BIT01
000001      BIT0== BIT00
;
; EVENT FLAG DEFINITIONS
; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
;
000040      EF.START==      32.      ; START COMMAND WAS ISSUED
000037      EF.RESTART==    31.      ; RESTART COMMAND WAS ISSUED
000036      EF.CONTINUE==   30.      ; CONTINUE COMMAND WAS ISSUED
000035      EF.NEW==        29.      ; A NEW PASS HAS BEEN STARTED
000034      EF.PWR==         28.      ; A POWER-FAIL/POWER-UP OCCURRED
;
; PRIORITY LEVEL DEFINITIONS
;
000340      PRI07== 340
000300      PRI06== 300
000240      PRI05== 240
000200      PRI04== 200
000140      PRI03== 140
000100      PRI02== 100
000040      PRI01== 40
000000      PRI00== 0
;
; OPERATOR FLAG BITS
;
000004      EVL==          4
000010      LOT==         10
000020      ADR==         20
000040      IDU==         40
000100      ISR==        100
000200      UAM==        200
000400      BOE==        400
001000      PNT==       1000
002000      PRI==       2000
004000      IXE==       4000
010000      IBE==      10000
020000      IER==      20000
040000      LOE==      40000
100000      HOE==     100000

```

1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282

000000
000001
000002
000004
000010
000020

000100
000111
001600

000000
000001
000002
000003
000004
000005
000006
000007
000010
000011
000012

000000
000001
000002
000003
000004
000005
000006
000007
000010
000011
000012
000013
000014
000015
000016
000017
000020
000021
000022
000023
000024
000025
000026
000027
000030

:::EQUATES FOR FLAG WORD:::::

CTARGT==0
CASIST==1
CSHCTR==2
CCLNAD==4
CCLNAL==8.
CEXIT==16.

;ARG TYPE FOR 'SHOW COUNTERS' CMD
;ARG TYPE FOR 'CLEAR NODE/ADR' CMD
;ARG TYPE FOR 'CLEAR NODE/ALL' CMD

:::CLOCK ENABLE VALUES TO BE LOADED IN CLK'S CSR:::

LCLKEN==100
PCLKEN==111
PCLKCT==1600

; L-CLOCK CSR VALUE TO ENABLE THE CLOCK
; P-CLOCK CSR VALUE TO ENABLE THE CLOCK
; P-CLOCK COUNT SET REGISTER FOR COUNTER

: SPECIAL CLI CODES FOR "CHAR" ARGUMENT IN CLI CALLS
: (COMMAND LINE INTERPRETER DEFINITIONS)

CLIERR= 0
CLIEXI= 1
CLIBR = 2
CLIBIF= 3
CLISPA= 4
CLINUM= 5
CLIALP= 6
CLIALN= 7
CLIOCT= 8.
CLIDEC= 9.
CLISTR= 10.

:DEFS FOR COMMAND LINE INTERPRETATION ACTION VALUES

NULL=0
HELP=1
NODE=2
BUILD=3
CRUN=4
CPATRN=5
CSAVE=6
SUMMRY=7
IDENT=10
EXIT=11
NOTNUF=12
CEXADR=13
CSAVR4=14
CNODE=15
CALPHA=16
CONES=17
CZEROS=20
C1ALT=21
COALT=22
CCCITT=23
COPRSL=24
CTYPE=25
CSIZE=26
CCPYS=27
CNDADR=30

```

1283      000031      CNODAL=31
1284      000032      CRNALL=32
1285      000033      CLUPPR=33
1286      000034      CSHMSG=34
1287      000035      CCLMSG=35
1288      000036      CCNTR=36
1289      000037      CNDLOG=37
1290      000040      CFUNCT=40
1291      000041      CUNSAV=41
1292      000042      CCLSUM=42
1293      000043      CDIR=43
1294      000044      CDEFLT=44
1295      000045      CUNSVF=45
1296
1297      000000
1298      000001
1299      000002
1300      000003
1301      000004
1302      000005
1303      000006
1304
1305
1306      ;
1307      ;       GLOBAL EQUATES FOR THE DEUNA DRIVER
1308      ;
1309      ; PORT CONTROL AND STATUS REGISTER 0
1310
1311      100000      SERI      ..      BIT15      ; STATUS ERROR INTERRUPT
1312      040000      PCEI      ..      BIT14      ; PORT COMMAND ERROR INTERRUPT
1313      020000      RXI       ..      BIT13      ; RECEIVE RING INTERRUPT
1314      010000      TXI       ..      BIT12      ; TRANSMIT RING INTERRUPT
1315      004000      DNI       ..      BIT11      ; DONE INTERRUPT
1316      002000      RCBI      ..      BIT10      ; RECEIVE BUFFER UNAVAILABLE
1317
1318      000400      ;
1319      000200      FATI      ..      BIT08      ; FATAL ERROR INTERERUPT
1320      000100      INTR      ..      BIT07      ; INTERRUPT SUMMARY <15:08>
1321      000040      INTE      ..      BIT06      ; INTERRUPT ENABLE
1322      RSET      ..      BIT05      ; UNA RESET
1323
1324      ; PORT COMMANDS IN BIT 3 TO BIT 0
1325      ; -----
1326      000001      GETPCB  .. BIT00      ; GET ADDRESS OF PORT CONTROL BLOCK
1327      000002      GETFNT  .. BIT01      ; GET COMMAND IN PORT CONTROL BLOCK
1328      000003      PNOP   .. BIT00!BIT01 ; NO OPERATION PERFORMED
1329      000004      STRT   .. BIT02      ; ENABLE XMIT AND RCVR
1330      000005      BOOT   .. BIT02!BIT00 ; BOOT , -> PRIM LOAD STATE,
1331      ; INITATE DOWNLINE LOAD
1332
1333      000010      PDMD   .. BIT03      ; POLLING DEMAND/WAKE UP BIT
1334      000011      TMRO   .. BIT03!BIT00 ; SANITY TIMER ENABLE ( -1 ITS ON)
1335      000012      TMRF   .. BIT03!BIT01 ; SANITY TIMER OFF
1336      000015      RSTT   .. BIT03!BIT02!BIT00 ; RESET SANITY TIMER
1337      000017      STOP   .. BIT03!BIT02!BIT01!BIT00 ; SUSPEND UNA OPERATION
1338
1339

```

;MESSAGE TYPE VALUES

; GLOBAL EQUATES FOR THE DEUNA DRIVER

; PORT CONTROL AND STATUS REGISTER 0

```

SERI      ..      BIT15      ; STATUS ERROR INTERRUPT
PCEI      ..      BIT14      ; PORT COMMAND ERROR INTERRUPT
RXI       ..      BIT13      ; RECEIVE RING INTERRUPT
TXI       ..      BIT12      ; TRANSMIT RING INTERRUPT
DNI       ..      BIT11      ; DONE INTERRUPT
RCBI      ..      BIT10      ; RECEIVE BUFFER UNAVAILABLE
;
FATI      ..      BIT08      ; FATAL ERROR INTERERUPT
INTR      ..      BIT07      ; INTERRUPT SUMMARY <15:08>
INTE      ..      BIT06      ; INTERRUPT ENABLE
RSET      ..      BIT05      ; UNA RESET

```

; PORT COMMANDS IN BIT 3 TO BIT 0
; -----

```

GETPCB  .. BIT00      ; GET ADDRESS OF PORT CONTROL BLOCK
GETFNT  .. BIT01      ; GET COMMAND IN PORT CONTROL BLOCK
PNOP   .. BIT00!BIT01 ; NO OPERATION PERFORMED
STRT   .. BIT02      ; ENABLE XMIT AND RCVR
BOOT   .. BIT02!BIT00 ; BOOT , -> PRIM LOAD STATE,
; INITATE DOWNLINE LOAD
;
PDMD   .. BIT03      ; POLLING DEMAND/WAKE UP BIT
TMRO   .. BIT03!BIT00 ; SANITY TIMER ENABLE ( -1 ITS ON)
TMRF   .. BIT03!BIT01 ; SANITY TIMER OFF
RSTT   .. BIT03!BIT02!BIT00 ; RESET SANITY TIMER
STOP   .. BIT03!BIT02!BIT01!BIT00 ; SUSPEND UNA OPERATION

```



```

1340
1341
1342
1343
1344      100000      XPWR == BIT15      ; TRANSCEIVER POWER OK
1345      040000      ICAB == BIT14      ; PORT TO LINK CABLE OK
1346
1347      ; SELF TEST ERROR CODE IN BIT 13 TO BIT 08
1348      000200      PCTO == BIT07      ; PORT COMMAND TIMEOUT
1349
1350      000010      RMTC == BIT03      ; REMOTE CONSOLE RESERVED (-1)
1351
1352      ; PORT STATE IN BIT 2 TO BIT 0
1353
1354      000000      RESET == 0      ; 000 RESET STATE
1355      000001      PRIMLD == BIT00      ; 001 PRIMARY LOAD STATE
1356      000002      READY == BIT01      ; 010 READY STATE
1357      000003      RUN == BIT01!BIT00      ; 011 RUNNING STATE
1358
1359      000005      UNIMLT == BIT02!BIT00      ; 101 UNIBUS HALTED STATE
1360      000006      NIMLT == BIT02!BIT01      ; 110 NI HALTED STATE
1361      000007      NIUNI == BIT02!BIT01!BIT00      ; 111 NI AND UNIBUS HALTED STATE
1362
1363
1364
1365      ;PORT CONTROL AND STATUS REGISTER 2
1366
1367      ; LOWER 16 ADDRESS BITS OF THE PORT CONTROL BLOCK BASE
1368      ; ADDRESS POINTER IN BIT 15 TO BIT 0
1369
1370      ;PORT CONTROL AND STATUS REGISTER 3
1371
1372      ; UPPER 2 ADDRESS BITS OF THE PORT CONTROL BLOCK BASE
1373      ; ADDRESS POINTER IN BIT 1 TO BIT 0
1374
1375      ;PORT FUNCTIONS
1376
1377      ; FUNCTION CODES ARE AS FOLLOWS
1378
1379      000000      PFNOP == 0      ; NO OPERATION PERFORMED
1380      000002      RDDEFA == BIT01      ; READ DEFAULT PHYSICAL ADDRESS
1381
1382      000004      RDPHYA == BIT02      ; READ PHYSICAL ADDRESS
1383      000005      WDPHYA == BIT02!BIT00      ; WRITE PHYSICAL ADDRESS
1384
1385      000006      RDMULA == BIT02!BIT01      ; READ LIST OF MULTICAST ADDRESSES
1386      000007      WDMULA == BIT02!BIT01!BIT00      ; WRITE LIST OF MULTICAST ADDRESSES
1387
1388      000010      RDRNGS == BIT03      ; READ BOTH THE RCVR AND XMIT RINGS
1389      000011      WDRNGS == BIT03!BIT00      ; WRITE BOTH THE RCVR AND XMIT RINGS
1390
1391      000012      RDCNTS == BIT03!BIT01      ; READ COUNTERS
1392      000013      CLRCNTS == BIT03!BIT01!BIT00      ; READ AND CLEAR COUNTERS
1393
1394      000014      RDMODE == BIT03!BIT02      ; READ INTERNAL LINK MODE REGISTER
1395      000015      WDMODE == BIT03!BIT02!BIT00      ; WRITE INTERNAL LINK MODE REGISTER
1396

```

```

1397      000016      RDSTA  == BIT03!BIT02!BIT01 ; READ PORT STATUS
1398      000017      CLRSTA == BIT03!BIT02!BIT01!BIT00 ; READ AND CLEAR PORT STATUS
1399
1400
1401      000020      DMPMEM == BIT04 ; DUMP INTERNAL MEMORY
1402      000021      LDMEM  == BIT04!BIT00 ; LOAD INTERNAL MEMORY
1403
1404      000022      RDSYS  == BIT04!BIT01 ; READ SYSTEM ID PARAMETERS
1405      000023      WDSYS  == BIT04!BIT01!BIT00 ; WRITE SYSTEM ID PARAMETERS
1406
1407      ;
1408      ; ETHERNET PACKET OFFSETS
1409      ;
1410
1411
1412      000016      HEADER == 14. ; OFFSET (SIZE) TO END OF HEADER IN BYTES
1413
1414      000000      DESTIN == 0 ; DESTINATION ADDRESS
1415      000006      SOURCC == 6 ; SOURCE ADDRESS
1416      000014      PROTOT == 12. ; PROTOCOL TYPE FIELD
1417
1418      ; -----
1419      ; ! DESTINATION ADDRESS !
1420      ; -----
1421      ; ! (6 BYTES) !
1422      ; -----
1423      ; !
1424      ; !
1425      ; +6 ! SOURCE ADDRESS !
1426      ; -----
1427      ; ! (6 BYTES) !
1428      ; -----
1429      ; !
1430      ; !
1431      ; +12. ! PROTOCOL TYPE !
1432      ; -----
1433      ; +14. ! DATA !
1434      ; -----
1435      ; ! MORE DATA !
1436      ; -----
1437      ;
1438      ;
1439      ; XMIT RING DESCRIPTOR DEFINITIONS
1440      ;
1441      ;
1442      ; TDRB*0
1443      ;
1444      ; NOTHING NEEDED
1445      ;
1446      ; TDRB*2
1447      ;
1448      ; NOTHING NEEDED
1449      ;
1450      ;
1451      ; TDRB*4
1452      ;
1453      ;
    
```

```

1454      000400      ENP      **      BIT08      ; END OF PACKET FLAG
1455      001000      STP      **      BIT09      ; STOP OF PACKET FLAG
1456      002000      DEF      **      BIT10      ; DEFFERRING PACKET FLAG
1457      004000      ONE      **      BIT11      ; XMIT SUCCESSFUL AFTER ONE RETRY
1458      010000      MORE     **      BIT12      ; XMIT SUCCESSFUL AFTER MORE THAN
1459                                     ; ONE RETRY
1460      040000      ERRS     **      BIT14      ; ERROR SUMMARY BIT
1461      100000      OWN      **      BIT15      ; OWNERSHIP BIT (=1 UNA, =0 HOST)
1462
1463      ; TDRB+6
1464
1465      002000      RTRY     **      BIT10      ; RETRY ERROR BIT
1466      004000      LCAR     **      BIT11      ; LOST CARRIER ERROR BIT
1467      010000      LCOL     **      BIT12      ; LATE COLLISION ERROR BIT
1468
1469      040000      UBTO     **      BIT14      ; UNIBUS TIMEOUT ERROR BIT
1470      100000      BUFL     **      BIT15      ; BUFFER LENGTH ERROR BIT
1471
1472      ;+
1473      ; RCVR RING DESCRIPTOR DEFINITIONS
1474      ;-
1475
1476      ; RDRB+0
1477      ;
1478      ; NOTHING NEEDED
1479
1480      ; RDRB+2
1481      ;
1482      ; NOTHING NEEDED
1483
1484
1485      ; RDRB+4
1486      ;
1487
1488      ; <- INDICATES SAME AS DEFINED FOR XMIT RING
1489
1490      ;ENP      **      BIT08      ; END OF PACKET FLAG
1491      ;STP      **      BIT09      ; STOP OF PACKET FLAG
1492
1493      004000      CRC       **      BIT11      ; CRC ERROR IN RECEIVED PACKET
1494      010000      OFLO     **      BIT12      ; MESSAGE OVERFLOW
1495      020000      FRAM     **      BIT13      ; FRAMING ERROR
1496
1497      ;ERRS     **      BIT14      ; ERROR SUMMARY BIT
1498      ;OWN      **      BIT15      ; OWNERSHIP BIT (=1 UNA, =0 HOST)
1499
1500      ; RDRB+6
1501
1502      020000      NCHN     **      BIT13      ; SET TO INDICATE UNA IN NO
1503                                     ; BUFFER CHAIN ON RCVR MODE
1504
1505      ;UBTO     **      BIT14      ; UNIBUS TIMEOUT ERROR BIT
1506      ;BUFL     **      BIT15      ; BUFFER LENGTH ERROR BIT
1507
1508      002756      XPKLEN   ** 1518.      ; TRANSMIT PACKET LENGTH
1509      002756      RPKLEN   ** 1518.      ; RECIEVE PACKET LENGHT
1510      000006      NO.NTR   ** 6          ; NUMBER OF ENTRIES IN DESCRIPTOR RINGS

```



```

1511      000050      TBLLEN  == 40.      ; NODE TABLE LENGTH (CHANGE STBLEN IF
1512                                     ; THIS IS CHANGED, OR ELSE!)
1513      000132      STBLEN  == 90.      ; SUMMARY TABLE LENGTH (= 2.25 X TBLLEN)
1514      000004      FRDADR  == 4        ; OFFSET FOR MESSAGE HEADERS
1515
1516                                     ;
1517                                     ; SYSTEM ID REPLY MESSAGE OFFSETS
1518                                     ;
1519      000022      SIRCPT  == 22
1520      000027      SIVERS  == 27
1521      000030      SIECO   == 30
1522      000031      SIUECO  == 31
1523      000035      SIFNCT  == 35
1524      000042      SIADDR  == 42
1525      000053      SIDEV   == 53
1526
1527                                     ;
1528                                     ; LOOP DIRECT OFFSETS
1529                                     ;
1530      000016      LDSKIP  == 16
1531      000020      LDFCT1  == 20
1532      000022      LDADR1  == 22
1533      000030      LDFCT2  == 30
1534      000032      LDADR2  == 32
1535
1536                                     ;
1537                                     ; FULL ASSIST OFFSETS
1538                                     ;
1539      000016      FASKIP  == 16
1540      000020      FAFCT1  == 20
1541      000022      FAADR1  == 22
1542      000030      FAFCT2  == 30
1543      000032      FAADR2  == 32
1544      000040      FAFCT3  == 40
1545      000042      FAADR3  == 42
1546      000050      FAFCT4  == 50
1547      000052      FAADR4  == 52
1548
1549                                     ;
1550                                     ; COUNTER OFFSETS
1551                                     ;
1551      000002      C. SECS  == 2
1552      000004      C. PREC  == 4
1553      000010      C. MREC  == 10
1554      000014      C. RERB  == 14
1555      000016      C. RERR  == 16
1556      000020      C. RDAT  == 20
1557      000024      C. RMDB  == 24
1558      000030      C. RLIN  == 30
1559      000032      C. RLEX  == 32
1560      000034      C. PXMT  == 34
1561      000040      C. MXMT  == 40
1562      000044      C. PXM3  == 44
1563      000050      C. PXM2  == 50
1564      000054      C. PXMD  == 54
1565      000060      C. XDAT  == 60
1566      000064      C. XMDB  == 64
1567      000066      C. XABB  == 66
    
```

```

1568          000070          C.XABT == 70
1569          000074          C.COLL == 74
1570
1571          .SBTTL GLOBAL DATA SECTION
1572
1573          ;**
1574          ; THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
1575          ; IN MORE THAN ONE TEST.
1576          ;--
1577          ;COMMAND LINE BUFFER, DATA LOCATIONS AND MESSAGES FOR ACTION ROUTINES
1578
1579 002200      CMDBUF: .BLKB 72.          ;BUFFER FOR OPERATOR COMMANDS
1580 002310      000000      KEYWD1: .WORD 0          ;
1581 002312      000000      KEYWD2: .WORD 0
1582 002314      000000      ADRBUF: .WORD 0          ;BUFFER FOR NODE ADDRESS
1583 002316      000000      .WORD 0
1584 002320      000000      .WORD 0
1585 002322      STRBUF: .BLKB 18.        ;BUFFER FOR ALPHANUM. ADDRESS STRING
1586 002344      STRBU1: .BLKB 18.
1587 002366      000000      CBOADR: .WORD 0          ;POINTER FOR BEGINING OF ADDRESS STRING
1588 002370      000000      P$TYPE: .WORD 0          ;LOC. TO HOLD MESSAGE TYPE
1589 002372      000000      P$SIZE: .WORD 0          ;LOC. TO HOLD MESSAGE SIZE
1590 002374      000000      P$CPYS: .WORD 0          ;LOC. TO HOLD NO. OF MESSAGE COPIES
1591 002376      000000      P$PASS: .WORD 0          ;LOC. TO HOLD NO. OF PASSES
1592 002400      000000      NODTY: .WORD 0          ;LOC. TO HOLD NODE TYPE FOR NODE TABLE SETUP
1593 002402      000000      SLOT:: .WORD 0          ;USED BY NODE TABLE SUBROUTINES
1594 002404      NODTBL: .BLKW TBLLEN      ; SPACE FOR NODE TABLE
1595 002524      177777      .WORD 177777          ;FILL LAST FOUR BYTES OF TABLE WITH ONES
1596 002526      177777      .WORD 177777
1597 002530      SAVTBL: .BLKW TBLLEN      ;SPACE FOR SAVE TABLE
1598 002650      177777      ILLADR: .WORD 177777      ;ILLEGAL ADDRESS FOR COMPARISON
1599 002652      177777      .WORD 177777          ; (MUST NOT BE PHYSICALLY SEPARATED FROM
1600 002654      177777      .WORD 177777          ; END OF SAVTBL)
1601 002656      STATBL: .BLKW STBLEN      ;SPACE FOR SUMMARY TABLE
1602 003142      177777      .WORD 177777
1603
1604          ;COMMAND LINE TRAVERSE LOCATIONS (USED BY "P$TRV")
1605
1606 003144      000000      P$BUFA: .WORD 0          ;LOC. TO HOLD ADDR. OF CMD LINE BUFFER
1607 003146      000000      P$TREE: .WORD 0          ;LOC. TO HOLD ADDR. OF PARSING TREE
1608 003150      000000      P$ACT: .WORD 0          ;LOC. TO HOLD ADDR. OF ACTION ROUTINE
1609 003152      000000      P$CNT: .WORD 0          ;LOC. TO BE A COUNTER LOCATION
1610 003154      000000      P$NUM: .WORD 0          ;LOC. TO HOLD NUMERIC VALUE FROM PARSE
1611 003156      000000      P$RADX: .WORD 0          ;LOC. TO HOLD RADIX(LO) & +/- (HI BYTE)
1612 003160      000          P$NNUF: .BYTE 0          ;RETURN =0 IF ENOUGH OF COMMAND FOUND
1613 003161      000          P$GDBD: .BYTE 0          ;RETURN CODE 0 IF NO ERROR FOUND
1614 003162      000          P$AERR: .BYTE 0          ;RETURN 0 IF 12 DIGIT ADDRESS ENTERED
1615 003163      000          P$MERR: .BYTE 0          ;RETURN -1 IF ERROR IN OPERATOR SELECTED
1616          ;MESSAGE INPUT OCCURED, 0 FOR GOOD INPUT
1617 003164      056060      HLPTAB: .WORD HELP1
1618 003166      056161      .WORD HELP2
1619 003170      056254      .WORD HELP3
1620 003172      056325      .WORD HELP4
1621 003174      056376      .WORD HELP5
1622 003176      056476      .WORD HELP6
1623 003200      056611      .WORD HELP7
1624 003202      056722      .WORD HELP8

```

1625 003204 057012
 1626 003206 057101
 1627 003210 057172
 1628 003212 057270
 1629 003214 057375
 1630 003216 057474
 1631 003220 057573
 1632 003222 057676
 1633 003224 057765
 1634 003226 060070
 1635 003230 060140
 1636 003232 060243
 1637 003234 060321
 1638 003236 060404
 1639 003240 060505
 1640 003242 060605
 1641 003244 060735
 1642 003246 061021
 1643 003250 061125
 1644 003252 061227
 1645 003254 061346
 1646 003256 061416
 1647 003260 000000
 1648 003262 062372
 1649 003264 062400
 1650 003266 062405
 1651 003270 062413
 1652 003272 062420
 1653 003274 062425
 1654 003276 062433
 1655
 1656
 1657
 1658 003300
 1659 003300 000130
 1660 003302 000001
 1661 003304 000001
 1662 003306 000001
 1663 003310 000001
 1664 003312 000100
 1665 003314 000000
 1666
 1667 003316
 1668 003316 003334
 1669 003320 003464
 1670 003322 003465
 1671 003324 003466
 1672 003326 003467
 1673 003330 003470
 1674 003332 003570
 1675
 1676 003334 04? 041 042
 003337 04j 044 045
 003342 046 047 050
 003345 051 052 053
 003350 054 055 057
 003353 060 061 062

.WORD HELP9
 .WORD HELP10
 .WORD HELP11
 .WORD HELP12
 .WORD HELP13
 .WORD HELP14
 .WORD HELP15
 .WORD HELP16
 .WORD HELP17
 .WORD HELP18
 .WORD HELP19
 .WORD HELP20
 .WORD HELP21
 .WORD HELP22
 .WORD HELP23
 .WORD HELP24
 .WORD HELP25
 .WORD HELP26
 .WORD HELP27
 .WORD HELP28
 .WORD HELP29
 .WORD HELP30
 HLPEND: .WORD 0
 MSGTAB: .WORD MSGTY0
 .WORD MSGTY1
 .WORD MSGTY2
 .WORD MSGTY3
 .WORD MSGTY4
 .WORD MSGTY5
 .WORD MSGTY6

;MESSAGE TYPE ASCII ADDRESS TABLE

; THIS SECTION DEFINES THE DATA PATTERNS USED BY THE EXERCISER

MSGCNT::
 MSG0C: .WORD EMSG0-MSG00
 MSG1C: .WORD EMSG1-MSG01
 MSG2C: .WORD EMSG2-MSG02
 MSG3C: .WORD EMSG3-MSG03
 MSG4C: .WORD EMSG4-MSG04
 MSG5C: .WORD EMSG5-MSG05
 MSG6C: .WORD 0

; THE NUMBER OF BYTES IN EACH MESSAGE

MSGAD::
 .WORD MSG00
 .WORD MSG01
 .WORD MSG02
 .WORD MSG03
 .WORD MSG04
 .WORD MSG05
 .WORD OPSLBF

MSG00:: .ASCII \ !"#%&'()*+,-./0123456789:;<=>?@ABCDEFGHIJKLMN OPQRSTUVWXYZ\

	003356	063	064	065		
	003361	066	067	070		
	003364	071	072	073		
	003367	074	075	076		
	003372	077	100	101		
	003375	102	103	104		
	003400	105	106	107		
	003403	110	111	112		
	003406	113	114	115		
	003411	116	117	120		
	003414	121	122	123		
	003417	124	125	126		
	003422	127	130	131		
	003425	132				
1677	003426	133	135	136	.ASCII \[]+-ABCDEFGHIJKLMN	OPQRSTUVWXYZ\ ; ALPHANUMERIC
	003431	055	101	102		
	003434	103	104	105		
	003437	106	107	110		
	003442	111	112	113		
	003445	114	115	116		
	003450	117	120	121		
	003453	122	123	124		
	003456	125	126	127		
	003461	130	131	132		
1678	003464				EMSG0::	
1679	003464	377			MSG01:: .BYTE 377	; MESSAGE OF ALL ONES
1680	003465				EMSG1::	
1681	003465	000			MSG02:: .BYTE 0	; MESSAGE OF ALL ZEROS
1682	003466				EMSG2::	
1683	003466	252			MSG03:: .BYTE 252	; MESSAGE OF ALTERNATING ONES
1684	003467				EMSG3::	
1685	003467	125			MSG04:: .BYTE 125	; MESSAGE OF ALTERNATING ZEROS
1686	003470				EMSG4::	
1687	003470				MSG05::	; CCITT 511 BIT TEST PATTERN
1688	003470	177603	157427	031011	.WORD 177603,157427,031011,047321,163715,105221	
	003476	047321	163715	105221		
1689	003504	143325	142304	040041	.WORD 143325,142304,040041,104116,052606,172334	
	003512	104116	052606	172334		
1690	003520	105025	123754	111337	.WORD 105025,123754,111337,111523,030030,145064	
	003526	111523	030030	145064		
1691	003534	137642	143531	063617	.WORD 137642,143531,063617,135075,066730,026575	
	003542	135075	066730	026575		
1692	003550	052012	053627	070071	.WORD 052012,053627,070071,151172,165044,031605	
	003556	151172	165044	031605		
1693	003564	166632	016147		.WORD 166632,016147	
1694	003570				EMSG5::	
1695	003570				OPSLBF: .BLKB 66.	;BUFFER FOR OPERATOR SELECTED MESSAGE TYPE
1696						
1697						
1698	003672	000000			CFLAG: .WORD 0	;ACTION ROUTINE CMD ARGUMENT FLAG
1699						
1700					;;CLOCK TABLES, EVENT LOG AND POINTERS	
1701	003674	000000			CLKCSR: .WORD 0	; CLOCK CSR ADDRESS
1702	003676	000000			CLKBR: .WORD 0	; CLOCK INTERRUPT LEVEL
1703	003700	000000			CLKVEC: .WORD 0	; CLOCK INTERRUPT VECTOR
1704	003702	000074			CLKHZ: .WORD 60.	; CLOCK'S FREQUENCY IN HERTZ
1705	003704	000000			CLKEN: .WORD 0	; CLOCK'S CSR VALUE TO INTRPT. ENABLE IT

```

1706
1707 003706 000000      TIMMIN: .WORD 0           ; PLACE TO KEEP TIME-SINCE-START
1708 003710 000000      TIMSEC: .WORD 0           ;
1709 003712 000000      TIMTCK: .WORD 0           ; PLACE TO KEEP NO. OF TICKS/SEC.
1710
1711 003714 000000      TIMER1: .WORD 0          ; EVENT TIMER #1 (TICKS)
1712 003716 000000      TIMER2: .WORD 0          ; EVENT TIMER #2 (TICKS)
1713 003720 000000      TIMERS: .WORD 0          ; EVENT TIMER #3 (SECONDS)
1714                      .EVEN
1715
1716
1717
1718                      ;
1719                      ;     TABLE OF START ADDRESS OF RECIEVE RING BUFFERS
1720                      ;
1721 003722      RRNGTB::
1722
1723 003722 026006      .WORD RRG001
1724 003724 030764      .WORD RRG002
1725 003726 033742      .WORD RRG003
1726 003730 036720      .WORD RRG004
1727 003732 041676      .WORD RRG005
1728 003734 044654      .WORD RRG006
1729
1730                      ;
1731                      ;     TABLE OF START ADDRESS OF TRANSMIT RING BUFFERS
1732                      ;
1733
1734 003736      XRNGTB::
1735
1736 003736 004162      .WORD XRG001
1737 003740 007140      .WORD XRG002
1738 003742 012116      .WORD XRG003
1739 003744 015074      .WORD XRG004
1740 003746 020052      .WORD XRG005
1741 003750 023030      .WORD XRG006
1742
1743                      ;
1744                      ;     POINTERS TO DESCRIPTOR RING ENTRIES
1745 003752 003772      XRSRT:: .WORD XRING           ; FIRST ENTRY IN TRANSMIT RING
1746 003754 004066      RRSRT:: .WORD RRING           ; FIRST ENTRY IN RECIEVE RING
1747 003756 003772      XRGCUR:: .WORD XRING          ; CURRENT ENTRY IN TRANSMIT RING
1748 003760 004066      RRGCUR:: .WORD RRING          ; CURRENT ENTRY IN RECIEVE RING
1749 003762 003772      XRGNXT:: .WORD XRING          ; NEXT ENTRY IN TRANSMIT RING
1750 003764 004066      RRGNXT:: .WORD RRING          ; NEXT ENTRY IN RECIEVE RING
1751 003766 004054      XRGLST:: .WORD XRING+50.        ; LAST ENTRY IN TRANSMIT RING
1752 003770 004150      RRGLST:: .WORD RRING+50.        ; LAST ENTRY IN RECEIVE RING
1753                      ;     VALUE = NO.NTR X 10.
1754
1759
1760 003772 000006      XRING:: .REPT 6
1761                      .NLIST
1762                      RNGFRM XRG00,B,0
1763                      .LIST
1764                      .ENDR
1765 003772 002756      .WORD RPKLEN           ; SEGMENT LENGTH
1766 003774 004162      .WORD XRG001           ; SEGMENT BUFFER ADDRESS

```

```

003776 000000 .WORD 0 ; OWNERSHIP AND STATUS BITS
004000 000000 .WORD 0 ; STATUS
004002 000000 .WORD 0 ; SEQUENCE NUMBER

004004 002756 .WORD RPKLEN ; SEGMENT LENGTH
004006 007140 .WORD XRG002 ; SEGMENT BUFFER ADDRESS
004010 000000 .WORD 0 ; OWNERSHIP AND STATUS BITS
004012 000000 .WORD 0 ; STATUS
004014 000000 .WORD 0 ; SEQUENCE NUMBER

004016 002756 .WORD RPKLEN ; SEGMENT LENGTH
004020 012116 .WORD XRG003 ; SEGMENT BUFFER ADDRESS
004022 000000 .WORD 0 ; OWNERSHIP AND STATUS BITS
004024 000000 .WORD 0 ; STATUS
004026 000000 .WORD 0 ; SEQUENCE NUMBER

004030 002756 .WORD RPKLEN ; SEGMENT LENGTH
004032 015074 .WORD XRG004 ; SEGMENT BUFFER ADDRESS
004034 000000 .WORD 0 ; OWNERSHIP AND STATUS BITS
004036 000000 .WORD 0 ; STATUS
004040 000000 .WORD 0 ; SEQUENCE NUMBER

004042 002756 .WORD RPKLEN ; SEGMENT LENGTH
004044 020052 .WORD XRG005 ; SEGMENT BUFFER ADDRESS
004046 000000 .WORD 0 ; OWNERSHIP AND STATUS BITS
004050 000000 .WORD 0 ; STATUS
004052 000000 .WORD 0 ; SEQUENCE NUMBER

004054 002756 .WORD RPKLEN ; SEGMENT LENGTH
004056 023030 .WORD XRG006 ; SEGMENT BUFFER ADDRESS
004060 000000 .WORD 0 ; OWNERSHIP AND STATUS BITS
004062 000000 .WORD 0 ; STATUS
004064 000000 .WORD 0 ; SEQUENCE NUMBER

```

```

1765
1769
1770
1771
1772
1773
1774

```

```

RRING:: .REPT 6
        .NLIST
        RNGFRM RRG00,B,100000
        .LIST
        .ENDR

```

```

004066 002756 .WORD RPKLEN ; SEGMENT LENGTH
004070 026006 .WORD RRG001 ; SEGMENT BUFFER ADDRESS
004072 100000 .WORD 100000 ; OWNERSHIP AND STATUS BITS
004074 000000 .WORD 0 ; STATUS
004076 000000 .WORD 0 ; SEQUENCE NUMBER

004100 002756 .WORD RPKLEN ; SEGMENT LENGTH
004102 030764 .WORD RRG002 ; SEGMENT BUFFER ADDRESS
004104 100000 .WORD 100000 ; OWNERSHIP AND STATUS BITS
004106 000000 .WORD 0 ; STATUS
004110 000000 .WORD 0 ; SEQUENCE NUMBER

004112 002756 .WORD RPKLEN ; SEGMENT LENGTH
004114 033742 .WORD RRG003 ; SEGMENT BUFFER ADDRESS
004116 100000 .WORD 100000 ; OWNERSHIP AND STATUS BITS
004120 000000 .WORD 0 ; STATUS

```



```

004122 000000 .WORD 0 ; SEQUENCE NUMBER
004124 002756 .WORD RPKLEN ; SEGMENT LENGTH
004126 036720 .WORD RRG004 ; SEGMENT BUFFER ADDRESS
004130 100000 .WORD 100000 ; OWNERSHIP AND STATUS BITS
004132 000000 .WORD 0 ; STATUS
004134 000000 .WORD 0 ; SEQUENCE NUMBER

004136 002756 .WORD RPKLEN ; SEGMENT LENGTH
004140 041676 .WORD RRG005 ; SEGMENT BUFFER ADDRESS
004142 100000 .WORD 100000 ; OWNERSHIP AND STATUS BITS
004144 000000 .WORD 0 ; STATUS
004146 000000 .WORD 0 ; SEQUENCE NUMBER

004150 002756 .WORD RPKLEN ; SEGMENT LENGTH
004152 044654 .WORD RRG006 ; SEGMENT BUFFER ADDRESS
004154 100000 .WORD 100000 ; OWNERSHIP AND STATUS BITS
004156 000000 .WORD 0 ; STATUS
004160 000000 .WORD 0 ; SEQUENCE NUMBER

```

```

1775
1779
1780 004162
1781 007140
1782 012116
1783 015074
1784 020052
1785 023030
1786
1787 026006
1788 030764
1789 033742
1790 036720
1791 041676
1792 044654
1793
1794
1795
1796
1797
1798
1799
1800

```

```

XRG001::.BLKB XPKLEN ; XMIT RING BUFFERS
XRG002::.BLKB XPKLEN
XRG003::.BLKB XPKLEN
XRG004::.BLKB XPKLEN
XRG005::.BLKB XPKLEN
XRG006::.BLKB XPKLEN

```

```

RRG001::.BLKB RPKLEN ; RECIEVE RING BUFFERS
RRG002::.BLKB RPKLEN
RRG003::.BLKB RPKLEN
RRG004::.BLKB RPKLEN
RRG005::.BLKB RPKLEN
RRG006::.BLKB RPKLEN

```

```

;*****8
; INFORMATION ABOUT THE CURRENT UNIT AS OBTAINED FROM THE HARDWARE P-TABLE
;*****

```

```

1801
1802
1803 047632 000000 PCSRO:: .WORD ;PCSR0 OF CURRENT SLOT
1804 047634 000000 PCSR1:: .WORD ; ADDRESS OF PCSRO (PORT COMMAND FIELD
1805 047636 000000 PCSR2:: .WORD ; 1 (STATE & SELF TEST FIELDS
1806 047640 000000 PCSR3:: .WORD ; 2 (PCB ADDRESS LO 15 BITS
1807 ; 3 (PCB ADDRESS HI 2 BITS
1808 047642 000000 PCSROC::.WORD 0 ;PCSR0 CONTENTS
1809 047644 000000 PCSR1C::.WORD 0 ;PCSR1 CONTENTS
1810 047646 000000 PCSR2C::.WORD 0 ;PCSR2 CONTENTS
1811 047650 000000 PCSR3C::.WORD 0 ;PCSR3 CONTENTS
1812
1813
1814 047652 000000 UNACSR::.WORD 0 ;CSR

```

```

1815 047654 000000 UNAVEC::.WORD 0 ;VECTOR
1816 047656 000000 UNAPRI::.WORD 0 ;PRIORITY
1817
1818 047660 000000 FRESIZ::.WORD 0 ;POINTER TO WORD CONTAINING SIZE OF FREE MEMORY
1819 047662 000000 FREMEM::.WORD 0 ;POINTER TO FREE MEMORY SPACE
1820
1821 047664 000000 UNIT:: .WORD 0 ;CURRENT UNIT NUMBER BEING TESTED
1822
1823 ; PORT CONTROL BLOCK FUNCTION STRUCTURES
1824
1825 ;PORT CONTROL BLOCK
1826 047666 000000 PCBB0:: .WORD 0 ; PORT FUNCTION
1827 047670 000000 PCBB2:: .WORD 0 ; PORT FUNCTION DEPENDENT PARAMETERS
1828 047672 000000 PCBB4:: .WORD 0 ; PORT FUNCTION DEPENDENT PARAMETERS
1829 047674 000000 PCBB6:: .WORD 0 ; PORT FUNCTION DEPENDENT PARAMETERS
1830
1831 ; FUNCTION TABLE
1832
1833 047676 047746 FUNTAB:: .WORD $PNOP ; NO OP
1834 047700 000000 .WORD 0 ; FILL IN THE HOLE
1835 047702 047750 .WORD $RDDE ; READ DEFAULT PHYSICAL ADDRESS
1836 047704 000000 .WORD 0 ; FILL IN ANOTHER HOLE
1837 047706 047760 .WORD $RDPH ; READ PHYSICAL ADDRESS
1838 047710 047770 .WORD $WDPH ; WRITE PHYSICAL ADDRESS
1839 047712 050000 .WORD $RDMC ; READ MULTICAST ADDRESS LIST
1840 047714 050040 .WORD $WDMC ; WRITE MULTICAST ADDRESS LIST
1841 047716 050100 .WORD $RDRN ; READ DESCRIPTOR RINGS
1842 047720 050124 .WORD $WDRN ; WRITE DESCRIPTOR RINGS
1843 047722 050150 .WORD $RDCN ; READ COUNTERS
1844 047724 050260 .WORD $CLRC ; READ AND CLEAR COUNTERS
1845 047726 050270 .WORD $RDMO ; READ MODE
1846 047730 050300 .WORD $WDMO ; WRITE MODE
1847 047732 050310 .WORD $RDST ; READ STATUS
1848 047734 050320 .WORD $CLRS ; READ AND CLEAR STATUS
1849 047736 050330 .WORD $DMEM ; DUMP INTERNAL MEMORY
1850 047740 050350 .WORD $LMEM ; LOAD INTERNAL MEMORY
1851 047742 050360 .WORD $RDSY ; READ SYS ID PARAMETERS
1852 047744 050370 .WORD $WTSY ; WRITE SYS ID PARAMETERS
1853
1854 ;=
1855 ; PNOP == 0 ; PORT NO-OPERATION
1856 ;-
1857 .EVEN
1858 047746 000000 $PNOP:: .WORD 0 ; NO-OP
1859
1860 ;+
1861 ; RDDEFA == BIT01 ; READ DEFAULT PHYSICAL ADDRESS
1862 ;-
1863 .EVEN
1864
1865 047750 000002 $RDDE:: .WORD 2 ; PCBB+0 FUNCTION READ DEFAULT
1866 047752 000000 DEPADR:: .WORD 0 ; PCBB+2 PHYSICAL ADDRESS
1867 047754 000000 .WORD 0 ; PCBB+4
1868 047756 000000 .WORD 0 ; PCBB+6
1869
1870 ;+
1871 ; RDPHYA == BIT02 ; READ PHYSICAL ADDRESS

```

```

1872
1873      :-
1874      .EVEN
1875 047760 000004      $RDPH::      .WORD 4      ; PCBB+0 READ CURRENT (ACTIVE)
1876 047762 000000      PHYADR::      .WORD 0      ; PCBB+2      PHYSICAL ADDRESS
1877 047764 000000      .WORD 0      ; PCBB+4
1878 047766 000000      .WORD 0      ; PCBB+6
1879
1880      :+
1881      :      WDPHYA == BIT02!BIT00      ; WRITE PHYSICAL ADDRESS
1882      :-
1883      .EVEN
1884 047770 000005      $WDPH::      .WORD 5      ; PCBB+0 WRITE PHYSICAL ADDRESS
1885 047772 000000      .WORD 0      ; PCBB+2
1886 047774 000000      .WORD 0      ; PCBB+4
1887 047776 000000      .WORD 0      ; PCBB+6
1888
1889      :+
1890      :      RDMULA == BIT02!BIT01      ; READ MULTICAST ADDRESS LIST
1891      :-
1892
1893      .EVEN
1894 050000 000006      $RDMC::      .WORD 6      ; FUNCTION CODE
1895 050002 050010      .WORD UCBB6 ; UCBB ADDRESS
1896 050004 000000      .WORD 0      ; PCBB+4
1897 050006 000000      .WORD 0      ; PCBB+6
1898
1899 050010      UCB6::      .BLKW 12.    ; ENOUGH ROOM FOR 4 ADDRESSES
1900
1901      :+
1902      :      WDMULA == BIT02!BIT01!BIT00 ; WRITE MULTICAST ADDRESS LIST
1903      :-
1904
1905      .EVEN
1906 050040 000007      $WDMC::      .WORD 7      ; FUNCTION CODE
1907 050042 050050      .WORD UCBB7 ; UCBB ADDRESS
1908 050044 000400      .WORD 400   ; LENGTH OF LIST = 1
1909 050046 000000      .WORD 0      ; PCBB+6
1910
1911 050050 000253      UCB7::      .WORD 253   ; MULTICAST ADDRESS FOR LOOPBACK
1912 050052 001000      .WORD 1000  ;
1913 050054 000000      .WORD 0      ;
1914 050056      .BLKW 9.    ; ROOM FOR THREE MORE ADDRESSES
1915
1916      :+
1917      :      RDRNGS == BIT03      ; READ BOTH THE RCVR AND XMIT RINGS
1918      :-
1919
1920      .EVEN
1921 050100 000010      $RDRN::      .WORD 10     ; FUNCTION CODE
1922 050102 050110      .WORD UCBB10; UCBB ADDRESS
1923 050104 000000      .WORD 0      ; NULL
1924 050106 000000      .WORD 0      ; NULL
1925
1926      .EVEN
1927
1928 050110 003772      UCB10::      .WORD XRING  ; UCBB

```



```

1929 050112 002000          .WORD 2000      ; UCBB+2
1930 050114 000000          .WORD 0        ; UCBB+4
1931 050116 004066          .WORD RRING    ; UCBB+6
1932 050120 002000          .WORD 2000    ; UCBB+10
1933 050122 000000          .WORD 0        ; UCBB+12
1934
1935
1936
1937          ;*
1938          ;          WDRNGS  == BIT03!BIT00      ; WRITE BOTH THE RCVR AND XMIT RINGS
1939          ;-
1940          .EVEN
1941
1942          $WDRN::          .WORD 11          ; FUNCTION CODE
1943          050126 050134          .WORD UCB11    ; UCBB ADDRESS
1944          050130 000000          .WORD 0        ; NULL
1945          050132 000000          .WORD 0        ; NULL
1946
1947          .EVEN
1948
1949          UCB11::
1950          050134 003772          .WORD XRING    ; TRANSMIT RING BASE ADDRESS
1951          050136 000          .BYTE 0        ; HI BITS OF TRANSMIT RING BASE ADDRESS
1952          050137 005          .BYTE 5        ; FIVE WORDS PER RING ENTRY (1 FOR PORT DRIVER
)
1953          050140 000006          .WORD NO.NTR   ; EIGHT TRANSMIT DESCRIPTORS IN THE RING
1954
1955          050142 004066          .WORD RRING    ; RECEIVE RING BASE ADDRESS
1956          050144 000          .BYTE 0        ; HI BITS OF RECEIVE RING BASE ADDRESS
1957          050145 005          .BYTE 5        ; FIVE WORDS PER RING ENTRY (1 FOR PORT DRIVER
)
1958          050146 000006          .WORD NO.NTR   ; EIGHT RECEIVE DESCRIPTORS IN THE RING
1959
1960
1961
1962          ;*
1963          ;          RDCNTS  == BIT03!BIT01      ; READ COUNTERS
1964          ;-
1965          .EVEN
1966
1967          $RDCN::          .WORD 12          ; FUNCTION
1968          050152 050160          .WORD UCB12    ; UCBB ADDRESS
1969
1970          ;          ;          ;          ;          ;          ;          ;          ;          ;          ;          ;
1971          ;          ;          ;          ;          ;          ;          ;          ;          ;          ;          ;
1972          050154 000000          .WORD 0        ; NULL
1973
1974          050156 000100          .WORD 100     ; (# OF WORDS IN LIST = UPPER BYTE)
1975          ;          ;          ;          ;          ;          ;          ;          ;          ;          ;          ;
1976          ;          ;          ;          ;          ;          ;          ;          ;          ;          ;          ;
1977          .EVEN
1978
1979          UCB13::
1980          050160 000000          UCB12::          .WORD 0        ; UCBB
1981          050162 000000          .WORD 0        ; UCBB+2
1982          050164 000000          .WORD 0        ; UCBB+4
1983          050166 000000          .WORD 0        ; UCBB+6
1984          050170 000000          .WORD 0        ; UCBB+10
1985          050172 000000          .WORD 0        ; UCBB+12

```

```

1986 050174 000000 .WORD 0 ; UCBB.14
1987 050176 000000 .WORD 0 ; UCBB.16
1988 050200 000000 .WORD 0 ; UCBB.20
1989 050202 000000 .WORD 0 ; UCBB.22
1990 050204 000000 .WORD 0 ; UCBB.24
1991 050206 000000 .WORD 0 ; UCBB.26
1992 050210 000000 .WORD 0 ; UCBB.30
1993 050212 000000 .WORD 0 ; UCBB.32
1994 050214 000000 .WORD 0 ; UCBB.34
1995 050216 000000 .WORD 0 ; UCBB.36
1996 050220 000000 .WORD 0 ; UCBB.40
1997 050222 000000 .WORD 0 ; UCBB.42
1998 050224 000000 .WORD 0 ; UCBB.44
1999 050226 000000 .WORD 0 ; UCBB.46
2000 050230 000000 .WORD 0 ; UCBB.50
2001 050232 000000 .WORD 0 ; UCBB.52
2002 050234 000000 .WORD 0 ; UCBB.54
2003 050236 000000 .WORD 0 ; UCBB.56
2004 050240 000000 .WORD 0 ; UCBB.60
2005 050242 000000 .WORD 0 ; UCBB.62
2006 050244 000000 .WORD 0 ; UCBB.64
2007 050246 000000 .WORD 0 ; UCBB.66
2008 050250 000000 .WORD 0 ; UCBB.70
2009 050252 000000 .WORD 0 ; UCBB.72
2010 050254 000000 .WORD 0 ; UCBB.74
2011 050256 000000 .WORD 0 ; UCBB.76
2012
2013
2014 ;*
2015 ; CLRCNTS == BIT03!BIT01!BIT00 ; READ AND CLEAR COUNTERS
2016 ;-
2017 .EVEN
2018
2019 050260 000013 $CLRC:: .WORD 13 ; FUNCTION
2020 050262 050160 .WORD UCBB13 ; UCBB ADDRESS
2021 ; DEFAULT COUNT OF COUNTER LIST
2022 050264 000000 .WORD 0 ; NULL
2023 050266 000040 .WORD 40 ; (# OF WORDS IN LIST = UPPER BYTE)
2024 ; MAX NUMBER VALUE = 32 (DECIMAL) =
2025 ; 40 (OCTAL)
2026
2027
2028 ;( FOR UCBB13:: SEE UCB 12 ABOVE)
2029
2030
2031 ;*
2032 ; RDMODE == BIT03!BIT02 ; READ INTERNAL LINK MODE REGISTER
2033 ;-
2034
2035 .EVEN
2036 050270 000014 $RDMO:: .WORD 14 ; FUNCTION CODE
2037 050272 000000 .WORD 0 ; A 16 BIT COPY OF THE
2038 ; BITS TO READ THE UNA INTERNAL
2039 ; MODE REGISTER
2040 050274 000000 .WORD 0 ; NULL
2041 050276 000000 .WORD 0 ; NULL
2042

```

GLOBAL DATA SECTION

```

2043      ;+
2044      ;          WDMODE == BIT03!BIT02!BIT00 ; WRITE INTERNAL LINK MODE REGISTER
2045      ; -
2046
2047      .EVEN
2048      050300 000015      $WDMO::          .WORD 15      ; FUNCTION CODE
2049      050302 000000      .WORD 0          ; A 16 BIT COPY OF THE
2050      .WORD 0          ; BITS TO WRITE THE UNA INTERNAL
2051      .WORD 0          ; MODE REGISTER
2052      050304 000000      .WORD 0          ; NULL
2053      050306 000000      .WORD 0          ; NULL
2054
2055
2056      ;+
2057      ;          RDSTA  == BIT03!BIT02!BIT01 ; READ PORT STATUS
2058      ; -
2059
2060      .EVEN
2061      050310 000016      $RDST::          .WORD 16      ; FUNCTION CODE
2062      050312 000000      STATUS::         .WORD 0          ; A LIST OF ERRORS AND STATUS
2063      050314 000000      .WORD 0          ; LOWER BYTE = # OF MULTICAST ADRS
2064      .WORD 0          ; MAXIMUM SUPPORTED BY UNA
2065      .WORD 0          ; UPPER BYTE = # OF MULTICAST ADRS
2066      .WORD 0          ; CURRENTLY SUPPORTED BY UNA
2067      050316 000000      .WORD 0          ; WORD = MAXIMUM # OF WORDS IN
2068      .WORD 0          ; UCB FOR COUNTERS
2069      .WORD 0          ; AS CURRENTLY PERCEIVED
2070      .WORD 0          ; BY THE UNA
2071
2072      ;+
2073      ;          CLRSTA == BIT03!BIT02!BIT01!BIT0
2074      ; -
2075      ;          ; READ AND CLEAR WRITE PORT STATUS
2076
2077      .EVEN
2078      050320 000017      $CLRS::          .WORD 17      ; FUNCTION CODE
2079      050322 000000      .WORD 0          ; A LIST OF ERRORS AND STATUS
2080      050324 000000      .WORD 0          ; LOWER BYTE = # OF MULTICAST ADRS
2081      .WORD 0          ; MAXIMUM SUPPORTED BY UNA
2082      .WORD 0          ; UPPER BYTE = # OF MULTICAST ADRS
2083      050326 000000      .WORD 0          ; CURRENTLY SUPPORTED BY UNA
2084      .WORD 0          ; WORD = MAXIMUM # OF WORDS IN
2085      .WORD 0          ; UCB FOR COUNTERS
2086      .WORD 0          ; AS CURRENTLY PERCEIVED
2087      .WORD 0          ; BY THE UNA
2088
2089      ;+
2090      ;          DMPMEM == BIT04          ; DUMP INTERNAL MEMORY
2091      ; -
2092
2093      .EVEN
2094      050330 000020      $DMEM::          .WORD 20      ; FUNCTION CODE
2095      050332 050340      .WORD UCB20    ; UCBB ADDRESS
2096      050334 000000      .WORD 0
2097      050336 000000      .WORD 0
2098      050340      UCB20::
2099      050340 000000      UCB21::          .WORD 0          ; FUNCTION LENGTH (NO OF WORDS TO XFER)

```



```

2100 050342 000000          .WORD 0      ; HDBB - HOST MEMORY DATA BLOCK ADDRESS
2101 050344 000000          .WORD 0      ; MUST BE ZERO
2102 050346 000000          .WORD 0      ; IDBB - INTERNAL DATA BLOCK BASE ADDRESS
2103
2104          ;+
2105          ;      LD MEM  == BIT04!BIT00      ; LOAD UNA INTERNAL MEMORY
2106          ;-
2107
2108          .EVEN
2109 050350 000021          $LMEM::      .WORD 21      ; FUNCTION CODE
2110 050352 050340          .WORD UCB21  ; UCBB ADDRESS
2111 050354 000000          .WORD 0
2112 050356 000000          .WORD 0
2113
2114          ;+
2115          ;      RDSYS  == BIT04!BIT01      ; READ SYSTEM ID
2116          ;-
2117
2118          .EVEN
2119 050360 000022          $RDSY::      .WORD 22      ; FUNCTION CODE
2120 050362 050400          .WORD UCB22  ; UCBB ADDRESS
2121 050364 000000          .WORD 0
2122 050366 000033          .WORD 27.    ; LENGTH OF ID MESSAGE
2123
2124          ;+
2125          ;      WTSYS  == BIT04!BIT01!BIT00 ; WRITE SYSTEM ID
2126          ;-
2127          .EVEN
2128 050370 000023          $WTSY::      .WORD 23      ; FUNCTION CODE
2129 050372 050400          .WORD UCB23  ; UCBB ADDRESS
2130 050374 000000          .WORD 0
2131 050376 000033          .WORD 27.    ; LENGTH OF ID MESSAGE
2132
2133          UCB22:
2134 050400 000000          .WORD 0      ; UDBB+0
2135 050402 000000          .WORD 0      ; UDBB+2
2136 050404 000000          .WORD 0      ; UDBB+4
2137 050406 000000          .WORD 0      ; UDBB+6
2138 050410 000000          .WORD 0      ; UDBB+10
2139 050412 000000         .WORD 0      ; UDBB+12
2140 050414 000000         .WORD 0      ; UDBB+14
2141 050416 000000         .WORD 0      ; UDBB+16
2142 050420 000000         .WORD 0      ; UDBB+20
2143 050422 000000         .WORD 0      ; UDBB+22
2144 050424 000000         .WORD 0      ; UDBB+24
2145 050426 000000         .WORD 0      ; UDBB+26
2146 050430 000000         .WORD 0      ; UDBB+30
2147 050432 000000         .WORD 0      ; UDBB+32
2148 050434 000000         .WORD 0      ; UDBB+34
2149 050436 000000         .WORD 0      ; UDBB+36
2150 050440 000000         .WORD 0      ; UDBB+40
2151 050442 000000         .WORD 0      ; UDBB+42
2152 050444 000000         .WORD 0      ; UDBB+44
2153 050446 000000         .WORD 0      ; UDBB+46
2154 050450 000000         .WORD 0      ; UDBB+50
2155 050452 000000         .WORD 0      ; UDBB+52
2156 050454 000000         .WORD 0      ; UDBB+54

```

```

2157 050456 000000          .WORD 0          ;UDBB+56
2158 050460 000000          .WORD 0          ;UDBB+60
2159 050462 000000          .WORD 0          ;UDBB+62
2160 050464 000000          .WORD 0          ;UDBB+64
2161
2162 050466 000000          UDBB:: .WORD 0          ;UNIBUS DATA BLOCK BASE
2163 050470 000000          .WORD 0          ;+2
2164 050472 000000          .WORD 0          ;+4
2165 050474 000000          .WORD 0          ;+6
2166
2167
2168
2169
2170
2171 050476 000000          S.REC:: .WORD 0          ; MESSAGES RECEIVED
2172 050500 000000          S.NREC:: .WORD 0          ; MESSAGES NOT RECEIVED
2173 050502 000000          S.LEN:: .WORD 0          ; LENGTH ERRORS
2174 050504 000000          S.COMP:: .WORD 0          ; COMPARE ERRORS
2175 050506 000000          S.BYTE:: .WORD 0          ; BYTES COMPARED
2176 050510 000000          S.XFER:: .WORD 0          ; BYTES TRANSFERED
2177
2178
2179
2180
2181
2182 050512 000000          FATFLG:: .WORD 0          ; FATAL ERROR FLAG
2183 050514 000000          PCEFLG:: .WORD 0          ; PORT COMMAND ERROR FLAG
2184 050516 000000          NIRCNT:: .WORD 0          ; UNA RECIEVE MESSAGE COUNTER
2185 050520 000000          XFLAG:: .WORD 0          ; FRAME TRANSMITTED FLAG
2186 050522 000000          DNIFLG:: .WORD 0          ; DONE INTERRUPT FLAG
2187 050524 000000          RBFCNT:: .WORD 0          ; RECIEVE BUFFERS LOST COUNTER
2188 050526 000000          BCOUNT:: .WORD 0          ; UNEXPLAINED INTERRUPTS COUNTER
2189 050530 000000          ERRFLG:: .WORD 0          ; ERROR FLAG
2190 050532 000000          TIMEOUT:: .WORD 0          ; TIME OUT COUNTER
2191 050534 000000          RETRYS:: .WORD 0          ; COUNTER FOR FRAMES FAILING DUE TO RTRY ERROR
2192 050536 000000          RCVERR:: .WORD 0          ; COUNTS NO. OF BUFFERS RECEIVED WITH ERRORS
2193 050540 000000          RCVBUF:: .WORD 0          ; COUNTS NO. OF GOOD BUFFERS RECEIVED
2194 050542 000000          COUNT:: .WORD 0          ; USED IN BLDBUF SUBROUTINE AS COUNTER
2195 050544 000220          PROTO0:: .WORD 000220    ; PROTOCALL TYPE FOR LOOPBACK MESSAGES
2196 050546 001140          PROTO2:: .WORD 001140    ; PROTOCALL TYPE FOR REMOTE CONSOLE
2197 050550 000000          TEMP:: .WORD 0          ; USED IN XMIT AS TEMPORARY STORAGE
2198 050552 000000          TEMP1:: .WORD 0          ; USED FOR TEMPORARY STORAGE
2199 050554 000000          TEMP2:: .WORD 0          ; USED FOR TEMPORARY STORAGE
2200 050556 000000          TEMP3:: .WORD 0          ; USED FOR TEMPORARY STORAGE
2201 050560 000000          XFER:: .WORD 0          ; STORES 'BYTES TRANSFERED'
2202 050562 000000          CPYCNT:: .WORD 0          ; 'NO. OF COPIES' COUNTER FOR LOOPING
2203 050564 000000          PCCALL:: .WORD 0          ; STORES PC OF CALLING ROUTINE FOR ERROR REPORTS
2204 050566 000000          BUFLN:: .WORD 0          ; STORES TRANSMIT BUFFER LENGTH
2205 050570 000000          CMPBUF:: .WORD 0          ; STORES LOCATION OF DATA BUFFER TO BE COMPARED
2206 050572          PATCH:: .BLKW 40.      ; 40 WORDS FOR PROGRAM PATCH
2207
2208
2209
2210
2211
2212 050712          REQID::
2213 050712 000003          .WORD 3          ; BYTE COUNT (=3 FOR REQUEST ID)

```

```

2214 050714 000005          .WORD 5          ; FUNCTION CODE FOR REQUEST ID
2215 050716 051115          .WORD "MR       ; RECIPT NUMBER
2216
2217
2218          ; LOOP DIRECT MESSAGE
2219          ;
2220
2221          .EVEN
2222
2223 050720          LOPDIR::
2224 050720 000000          .WORD 0          ; SKIP COUNT
2225 050722 000002          .WORD 2          ; FUNCTION = FORWARD DATA
2226 050724 000000 000000 000000 .WORD 0,0,0     ; LOCAL NODE ADDRESS
2227 050732 000001          .WORD 1          ; FUNCTION = REPLY
2228 050734 000000 000000 000000 .WORD 0,0,0     ; LOCAL NODE ADDRESS
2229
2230          ;
2231          ; TRANSMIT ASSIST MESSAGE
2232          ;
2233
2234 050742          TASIST::
2235 050742 000000          .WORD 0          ; SKIP COUNT
2236 050744 000002          .WORD 2          ; FUNCTION = FORWARD DATA
2237 050746 000000 000000 000000 .WORD 0,0,0     ; TRANSMIT ASSIST ADDRESS
2238 050754 000002          .WORD 2          ; FUNCTION = FORWARD DATA
2239 050756 000000 000000 000000 .WORD 0,0,0     ; LOCAL NODE ADDRESS
2240 050764 000001          .WORD 1          ; FUNCTION = REPLY
2241 050766 000000 000000 000000 .WORD 0,0,0     ; LOCAL NODE ADDRESS
2242
2243          ;
2244          ; RECIEVE ASSIST MESSAGE
2245          ;
2246
2247 050774          RASIST::
2248 050774 000000          .WORD 0          ; SKIP COUNT
2249 050776 000002          .WORD 2          ; FUNCTION = FORWARD DATA
2250 051000 000000 000000 000000 .WORD 0,0,0     ; TRANSMIT ASSIST ADDRESS
2251 051006 000002          .WORD 2          ; FUNCTION = FORWARD DATA
2252 051010 000000 000000 000000 .WORD 0,0,0     ; LOCAL NODE ADDRESS
2253 051016 000001          .WORD 1          ; FUNCTION = REPLY
2254 051020 000000 000000 000000 .WORD 0,0,0     ; LOCAL NODE ADDRESS
2255
2256          ;
2257          ; FULL ASSIST MESSAGE
2258          ;
2259
2260 051026          FASIST::
2261 051026 000000          .WORD 0          ; SKIP COUNT
2262 051030 000002          .WORD 2          ; FUNCTION = FORWARD DATA
2263 051032 000000 000000 000000 .WORD 0,0,0     ; TARGET NODE ADDRESS
2264 051040 000002          .WORD 2          ; FUNCTION = FORWARD DATA
2265 051042 000000 000000 000000 .WORD 0,0,0     ; ASSIST NODE ADDRESS
2266 051050 000002          .WORD 2          ; FUNCTION = FORWARD DATA
2267 051052 000000 000000 000000 .WORD 0,0,0     ; LOCAL NODE ADDRESS
2268 051060 000001          .WORD 1          ; FUNCTION = REPLY
2269 051062 000000 000000 000000 .WORD 0,0,0     ; LOCAL NODE ADDRESS
2270

```


2271
2272
2273
2274
2275
2276
2277
2278
2279
2280
2281
2282
2283
2284
2285
2286
2287 051070
2288
2289
2290 051070
2291 051074
2292 051100
2293 051102
2294 051116
2295 051120
2296 051134
2297 051140
2298 051154
2299 051156
2300 051170
2301 051174
2302 051200
2303 051212
2304 051216
2305 051234
2306 051236
2307 051250
2308 051252
2309 051254
2310 051256
2311 051272
2312 051276
2313 051316
2314 051322
2315 051340
2316 051344
2317 051362
2318 051366
2319 051402
2320 051404
2321 051424
2322 051430
2323 051432
2324
2325
2326
2327 051434

.SBTTL COMMAND LINE ACTION TREE

;SAMPLE CLI TREE NODE (ALWAYS AT LEAST 1 WORD)

```

; -----
; ! ACTION ! CHAR CODE !
; -----
; ! MISS DISPLACEMENT !           ONLY IF "MISS" ARGUMENT DEFINED
; -----
; ! NEXT MODE DISPLMNT !           ONLY IF "ASCII" ARGUMENT DEFINED
; -----
; ! ASCIZ MATCH STRING !           ONLY IF "ASCII" ARGUMENT DEFINED
; !           (.EVEN) !
; -----

```

CLITRE:

;FIRST KEYWORD

```

N10$: CLI CLISPA,0,N10$ ;SKIP ANY LEADING SPACES
N10$: CLI <'?'>,HELP,N12$ ;IS THE FIRST NON-SP CHAR. A "?"
N10$: CLI CLIEXI,0 ; IF YES DO "HLP" AND EXIT
N12$: CLI CLISTR,HELP,N14$, <'HELP'> ;ELSE IS FIRST WORD A "HELP"
N12$: CLI CLIEXI,0 ; IF YES DO "HLP" AND EXIT
N14$: CLI CLISTR,NOTNUF,N16$, <'NODE'> ;ELSE IS FIRST WORD A "NODE"
N14$: CLI CLIBR,0,N80$ ; IF YES, BR N80$
N16$: CLI CLISTR,BUILD,N18$, <'BUILD'> ;ELSE IS FIRST WORD A "BUILD"
N16$: CLI CLIEXI,0 ; IF YES DO "BUILD" AND EXIT
N18$: CLI CLISTR,NOTNUF,N20$, <'RUN'> ;ELSE IS FIRST WORD A "RUN"
N18$: CLI CLIBR,0,N180$ ; IF YES, BR N180$
N20$: CLI <'S'>,NOTNUF,N25$ ;ELSE IS FIRST CHAR. A "S"
N20$: CLI CLISTR,0,N22$, <'HOW'> ; IF YES IS REST OF WORD "HOW"
N20$: CLI CLIBR,0,N100$ ; IF YES, BR N100$
N22$: CLI CLISTR,SUMMARY,N23$, <'UMMARY'> ; ELSE IS REST OF WORD "UMMARY"
N22$: CLI CLIEXI,0 ; IF YES, DO "SUMM" AND EXIT
N23$: CLI CLISTR,CSAVE,N24$, <'AVE'> ; ELSE IS REST OF WORD "AVE"
N23$: CLI CLIEXI,0 ; IF YES, DO "SAVE" AND EXIT
N24$: CLI CLIERR,0 ; ELSE "ILL COMMAND"
N24$: CLI CLIEXI,0 ; EXIT
N25$: CLI CLISTR,NOTNUF,N26$, <'CLEAR'> ;ELSE IS FIRST WORD A "CLEAR"
N25$: CLI CLIBR,0,N120$ ; IF YES, BR N120$
N26$: CLI CLISTR,NOTNUF,N28$, <'IDENTIFY'> ;ELSE IS FIRST WORD "IDENTIFY"
N26$: CLI CLIBR,0,N140$ ; IF YES, GET ADDR, BR N140$
N28$: CLI CLISTR,NOTNUF,N29$, <'MESSAGE'> ;ELSE IS FIRST WORD "MESSAGE"
N28$: CLI CLIBR,0,N160$ ; IF YES, BR N160$
N29$: CLI CLISTR,CUNSAV,N30$, <'UNSAVE'> ;ELSE IS FIRST WORD "UNSAVE"
N29$: CLI CLIBR,0,N210$ ; IF YES, BR TO N210$
N30$: CLI CLISTR,EXIT,N31$, <'EXIT'> ;ELSE IS FIRST WORD "EXIT"
N30$: CLI CLIEXI,0 ; IF YES EXIT
N31$: CLI CLISTR,NOTNUF,N32$, <'FUNCTION'> ;ELSE IS FIRST WORD "FUNCTION"
N31$: CLI CLIBR,0,N200$ ; IF YES, BR N200$
N32$: CLI CLIERR,0 ;OTHERWISE "ILL CMD".
N32$: CLI CLIEXI,0 ; EXIT

```

;SECOND KEYWORD (ADR/TYPE) FOR NODE COMMAND

```

N80$: CLI CLISPA,0,N81$ ;SKIP ANY LEADING SPACES

```

```

2328 051440      N81$:  CLI      CLIBR,CSAVR4,N82$      ;SAVE STRING POINTER LOCATION
2329 051444      N82$:  CLI      CLIBR,NODE,N90$      ;PARSE THROUGH ADDRESS,CHECK
2330              ;FOR TARGET OR ASSIST, DO NODE
2331 051450      N90$:  CLI      CLIBIF,0,N32$      ;TAKE ERROR BRANCH IF ERROR EXISTS
2332 051454      N95$:  CLI      CLIEXI,0      ;EXIT
2333
2334              ;SECOND KEYWORD FOR SHOW COMMAND
2335
2336 051456      N100$: CLI      CLISPA,0,N101$      ;SKIP LEADING SPACES
2337 051462      N101$: CLI      CLISTR,CNODE,N102$,<'NODES'> ;IS NEXT WORD "NODES"
2338 051476              CLI      CLIBR,0,N110$      ; IF YES, SET FLAG, BR N110$
2339 051502      N102$: CLI      CLISTR,CSHMSG,N104$,<'MESSAGE'> ;ELSE IS NEXT WORD "MESSAGE"
2340 051520              CLI      CLIBR,0,N110$      ; IF YES, SET FLAG, BR N110$
2341 051524      N104$: CLI      CLISTR,CCNTR,N106$,<'COUNTERS'> ;ELSE IS NEXT WORD "COUNTERS"
2342 051544              CLI      CLIBR,0,N110$      ; GO TO COUNTERS ROUTINE
2343 051550      N106$: CLI      CLIBR,0,N32$      ;ELSE "ILL COMMAND"
2344 051554      N110$: CLI      CLIEXI,0      ;EXIT
2345
2346              ;SECOND KEYWORD FOR CLEAR COMMAND
2347
2348 051556      N120$: CLI      CLISPA,0,N121$      ;SKIP LEADING SPACES
2349 051562      N121$: CLI      CLISTR,0,N130$,<'NODE'> ;IS NEXT WORD "NODE"
2350 051576              CLI      CLISPA,0,N122$      ; IF YES SKIP SPACES
2351 051602      N122$: CLI      <'/'>,CSAVR4,N32$      ; LOOK FOR DELIMITER, ELSE "ILL COM"
2352 051606              CLI      <'A'>,0,N123$      ; IS NEXT CHAR. AN "A"
2353 051612              CLI      CLISTR,CNODAL,N124$,<'LL'> ; IF YES, IS WORD "ALL"
2354 051624              CLI      CLIBR,0,N135$      ; IF YES, SET FLAG,BR N135$
2355 051630      N123$: CLI      <'N'>,0,N124$      ; ELSE IS NEXT CHAR. AN "N"
2356 051634              CLI      CLIDEC,0,N32$      ; IF YES, STORE NODE LOGICAL NAME
2357 051640              CLI      CLIBR,CNDLOG,N135$      ; BR TO CLR. NODE LOGICAL ROUTINE
2358 051644      N124$: CLI      CLIBR,CEXADR,N126$      ; ELSE, EXTRACT ADDRESS
2359 051650      N126$: CLI      CLIBR,CNDADR,N135$      ; SET FLAG, BR N135$
2360 051654      N130$: CLI      CLISTR,CCLMSG,N132$,<'MESSAGE'> ;ELSE IS NEXT WORD "MESSAGE"
2361 051672              CLI      CLIBR,0,N135$      ; IF YES, SET FLAG, BR N135$
2362 051676      N132$: CLI      CLISTR,CCLSUM,N134$,<'SUMMARY'> ;ELSE IS NEXT WORD "SUMMARY"
2363 051714              CLI      CLIBR,0,N135$      ; IF YES, CLEAR TABLE AND EXIT
2364 051720      N134$: CLI      CLIERR,0      ;ELSE, "ILL COMMAND".
2365 051722      N135$: CLI      CLIEXI,0      ;EXIT
2366
2367              ;ADDRESS FOR IDENTIFY COMMAND
2368
2369 051724      N140$: CLI      CLISPA,0,N141$      ;SKIP LEADING SPACES
2370 051730      N141$: CLI      CLIBR,CSAVR4,N142$      ;SAVE POINTER TO FIRST CHAR. OF ADDRESS
2371 051734      N142$: CLI      CLIALN,0,N32$      ;CHECK THAT ADDRESS HAS LEGAL CHAR.S
2372 051740              CLI      CLIBR,CEXADR,N143$      ;GET ADDRESS
2373 051744      N143$: CLI      CLIEXI,IDENT      ;DO "IDENTIFY". EXIT
2374
2375              ;REMAINING COMMAND LINE FOR MESSAGE COMMAND
2376
2377 051746      N160$: CLI      CLISPA,0,N161$      ;SKIP LEADING SPACES
2378 051752      N161$: CLI      <'/'>,0,N178$      ;IF CHAR. "/", CONT., ELSE BR N178$
2379 051756              CLI      CLISTR,0,N170$,<'TYPE'> ;IS NEXT WORD "TYPE"
2380 051772              CLI      <'='>,0,N32$      ; IF YES, FOLLOWED BY "="?
2381 051776              CLI      CLISTR,CALPHA,N162$,<'ALPHA'> ; IF "ALPHA", SET FLAG
2382 052012              CLI      CLIBR,0,N168$      ; CONTINUE AT N168$
2383 052016      N162$: CLI      CLISTR,CONES,N163$,<'ONES'> ; IF "ONES", SET FLAG
2384 052032              CLI      CLIBR,0,N168$      ; CONTINUE AT N168$

```



```

2385 052036 N163$: CLI CLISTR,CZEROS,N164$,<'ZEROS'> ; IF "ZEROS", SET FLAG
2386 052052 CLI CLIBR,0,N168$ ; CONTINUE AT N168$
2387 052056 N164$: CLI CLISTR,C1ALT,N165$,<'1ALT'> ; IF "1ALT", SET FLAG
2388 052072 CLI CLIBR,0,N168$ ; CONTINUE AT N168$
2389 052076 N165$: CLI CLISTR,COALT,N166$,<'OALT'> ; IF "OALT", SET FLAG
2390 052112 CLI CLIBR,0,N168$ ; CONTINUE AT N168$
2391 052116 N166$: CLI CLISTR,CCITT,N167$,<'CCITT'> ; IF "CCITT", SET FLAG
2392 052132 CLI CLIBR,0,N168$ ; CONTINUE AT N168$
2393 052136 N167$: CLI <' ">,CSAVR4,N32$ ; IF "OPERATOR", SET FLAG
2394 052142 CLI CLIBR,COPRSL,N168$ ; AND INPUT SPECIFIED STRING
2395 052146 N168$: CLI CLIBR,CTYPE,N160$ ; DO "TYPE", CHECK FOR MORE INPUT
2396 052152 N170$: CLI CLISTR,0,N175$,<'SIZE'> ;ELSE IS WORD "SIZE"
2397 052166 CLI <'=>,0,N32$ ; IF YES, FOLLOWED BY "="?
2398 052172 CLI CLIDEC,CSIZE,N32$ ; STORE NUMBER IN M$SIZE
2399 052176 CLI CLIBR,0,N160$ ; CHECK FOR MORE INFO
2400 052202 N175$: CLI CLISTR,0,N32$,<'COPIES'> ;ELSE IS WORD "COPIES"
2401 052220 CLI <'=>,0,N32$ ; IF YES, FOLLOWED BY "="?
2402 052224 CLI CLIDEC,CCPYS,N32$ ; STORE NUMBER IN M$CPYS
2403 052230 CLI CLIBR,0,N160$ ; CHECK FOR MORE INFO
2404 052234 N178$: CLI CLIBR,0,N32$ ;ELSE "ILL COMMAND"

```

;SECOND KEYWORD FOR RUN COMMAND

```

2408 052240 N180$: CLI CLISPA,0,N181$ ;SKIP LEADING SPACES
2409 052244 N181$: CLI CLISTR,CLUPPR,N182$,<'LOOPPAIR'> ; IS NEXT WORD "LOOPPAIR"
2410 052264 CLI CLIBR,0,N185$ ; IF YES, SET "LOOPPAIR" FLAG
2411 052270 N182$: CLI CLISTR,CRNALL,N183$,<'ALL'> ;ELSE IS NEXT WORD "ALL"
2412 052302 CLI CLIBR,0,N185$ ; IF YES, SET "ALL" FLAG
2413 052306 N183$: CLI CLISTR,CDIR,N184$,<'DIRECT'> ;ELSE IS NEXT WORD "DIRECT"
2414 052324 CLI CLIBR,0,N185$ ; IF YES, SET "DIRECT" FLAG
2415 052330 N184$: CLI CLISTR,CPATRN,N32$,<'PATTERN'> ;ELSE IS NEXT WORD "PATTERN"
2416 052346 N185$: CLI CLIBR,CDEFLT,N186$ ;SEE IF DEFAULT OF 1 PASS
2417 052352 N186$: CLI CLISTR,0,N32$,<' /PASS'> ;PARSE THROUGH SWITCH
2418 052366 CLI <'=>,0,N32$ ;PARSE THROUGH "="
2419 052372 CLI CLIDEC,0,N32$ ;GET PASS COUNT
2420 052376 N190$: CLI CLIEXI,CRUN ;RUN TEST AND EXIT

```

;REMAINING COMMAND LINE FOR FUNCTION COMMAND

```

2424 052400 N200$: CLI CLISPA,0,N201$ ; SKIP SPACES
2425 052404 N201$: CLI CLIOCT,CFUNCT,N32$ ; GET OCTAL NUMBER AND DO FUNCT
2426 052410 CLI CLIEXI,0 ; EXIT

```

;REMAINING COMMAND LINE FOR UNSAVE COMMAND

```

2430 052412 N210$: CLI CLISPA,0,N212$ ;SKIP SPACES
2431 052416 N212$: CLI <' />,0,N215$ ;PARSE THROUGH '/'
2432 052422 CLI CLIEXI,CUNSVF ;SAVE POINTER TO FILE NAME
2433 052424 N215$: CLI CLIEXI,0

```

```

2434
2436 ;*****
2437 ; THE ERRTBL MACRO IS REQUIRED IF YOU INTEND TO REPORT ERRORS USING
2438 ; THE "ERROR" MACRO. THE ERRTBL MACRO EXPANDS INTO FOUR WORDS THAT
2439 ; ARE USED BY THE RUNTIME SERVICES DURING AN ERROR CALL: ERROR TYPE,
2440 ; ERROR NUMBER, ADDRESS OF ERROR MESSAGE AND ADDRESS OF MESSAGE
2441 ; BLOCK. THERE MUST BE ONLY ONE ERRTBL IN ANY PROGRAM. THIS SECTION
2442 ; IS OPTIONAL. REMOVE IF IT IF YOU ARE NOT GOING TO USE THE ERROR

```



```

2443      :      MACRO. CHANGE THE POINTER MACRO TO REFLECT THIS SECTION'S DEL-
2444      :      ETION IF YOU REMOVE IT.
2445      :      ~~~~~
2447
2448 052426      ERRTBL
052426      L$ERRTBL::
052426 000000      ERRTYP::      .WORD      0
052430 000000      ERRNBR::      .WORD      0
052432 000000      ERRMSG::      .WORD      0
052434 000000      ERRBLK::      .WORD      0

```

```

2450 .SBTTL GLOBAL TEXT SECTION
2451
2452 ;**
2453 ; THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
2454 ; MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
2455 ; MORE THAN ONE TEST.
2456 ;--
2457 052436 012 015 116 CLI$PM: .ASCIZ <12><15>/NIE>/ ;NIE PROMPT
      052441 111 105 076
      052444 000
2458 052445 045 116 045 CLIERM: .ASCIZ /%N%A?ILL CMD-BAD SYNTAX?/
      052450 101 077 111
      052453 114 114 040
      052456 103 115 104
      052461 055 102 101
      052464 104 040 123
      052467 131 116 124
      052472 101 130 077
      052475 000
2459 052476 045 116 045 CLINUF: .ASCIZ /%N%A?INCOMPLETE COMMAND?/
      052501 101 077 111
      052504 116 103 117
      052507 115 120 114
      052512 105 124 105
      052515 040 103 117
      052520 115 115 101
      052523 116 104 077
      052526 000
2460 052527 045 116 045 CLINBG: .ASCIZ /%N%A?NUMBER TOO BIG?/
      052532 101 077 116
      052535 125 115 102
      052540 105 122 040
      052543 124 117 117
      052546 040 102 111
      052551 107 077 000
2461 052554 045 116 045 CLIBRX: .ASCIZ /%N%A?BAD RADIX?/
      052557 101 077 102
      052562 101 104 040
      052565 122 101 104
      052570 111 130 077
      052573 000
2462 052574 045 116 045 LDRESP: .ASCIZ /%N%ANODE %T%A HAS RESPONDED./
      052577 101 116 117
      052602 104 105 040
      052605 045 124 045
      052610 101 040 110
      052613 101 123 040
      052616 122 105 123
      052621 120 117 116
      052624 104 105 104
      052627 056 000
2463 052631 045 116 045 RECERR: .ASCIZ /%N%APACKET RECEIVED WITH UNA ERROR./
      052634 101 120 101
      052637 103 113 105
      052642 124 040 122
      052645 105 103 105
      052650 111 126 105

```

	052653	104	040	127
	052656	111	124	110
	052661	040	125	116
	052664	101	040	105
	052667	122	122	117
	052672	122	056	000
2464	052675	045	116	045
	052700	101	124	122
	052703	101	116	123
	052706	115	111	123
	052711	123	111	117
	052714	116	040	101
	052717	102	117	122
	052722	124	105	104
	052725	040	055	055
	052730	040	105	130
	052733	103	105	123
	052736	123	111	126
	052741	105	040	103
	052744	117	114	114
	052747	111	123	111
	052752	117	116	123
	052755	056	000	
2465	052757	045	116	045
	052762	104	062	045
	052765	101	040	116
	052770	117	104	105
	052773	040	101	104
	052776	104	122	105
	053001	123	123	105
	053004	123	040	101
	053007	104	104	105
	053012	104	054	040
	053015	105	114	101
	053020	120	123	105
	053023	104	040	124
	053026	111	115	105
	053031	072	040	045
	053034	104	062	045
	053037	101	040	115
	053042	111	116	125
	053045	124	105	056
	053050	000		
2466	053051	045	116	045
	053054	101	103	101
	053057	116	116	117
	053062	124	040	125
	053065	123	105	040
	053070	102	122	117
	053073	101	104	103
	053076	101	123	124
	053101	040	101	104
	053104	104	122	105
	053107	123	123	040
	053112	050	106	106
	053115	055	106	106
	053120	055	106	106

RTRYER: .ASCIZ /%N%ATRANSMISSION ABORTED -- EXCESSIVE COLLISIONS./

BLDMSG: .ASCIZ /%N%D2%A NODE ADDRESSES ADDED, ELAPSED TIME: %D2%A MINUTE./

ILADMS: .ASCII /%N%ACANNOT USE BROADCAST ADDRESS (FF-FF-FF-FF-FF-FF)/

	053123	055	106	106	
	053126	055	106	106	
	053131	055	106	106	
	053134	051			
2467	053135	045	116	045	ILADM1: .ASCIZ /#N#AFOR LOOP TESTING. ADDRESS WAS NOT ADDED TO NODE TABLE.#N/
	053140	101	106	117	
	053143	122	040	114	
	053146	117	117	120	
	053151	040	124	105	
	053154	123	124	111	
	053157	116	107	056	
	053162	040	101	104	
	053165	104	122	105	
	053170	123	123	040	
	053173	127	101	123	
	053176	040	116	117	
	053201	124	040	101	
	053204	104	104	105	
	053207	104	040	124	
	053212	117	040	116	
	053215	117	104	105	
	053220	040	124	101	
	053223	102	114	105	
	053226	056	045	116	
	053231	000			
2468	053232	045	116	045	CADRER: .ASCIZ /#N#PLEASE ENTER TWELVE HEXADECIMAL DIGITS./
	053235	101	120	114	
	053240	105	101	123	
	053243	105	040	105	
	053246	116	124	105	
	053251	122	040	124	
	053254	127	105	114	
	053257	126	105	040	
	053262	110	105	130	
	053265	101	104	105	
	053270	103	111	115	
	053273	101	114	040	
	053276	104	111	107	
	053301	111	124	123	
	053304	056	000		
2469	053306	045	116	045	CADERR: .ASCIZ /#N#ATWELVE HEX-DIGITS REQUIRED FOR ADDRESS./
	053311	101	124	127	
	053314	105	114	126	
	053317	105	040	110	
	053322	105	130	055	
	053325	104	111	107	
	053330	111	124	123	
	053333	040	122	105	
	053336	121	125	111	
	053341	122	105	104	
	053344	040	106	117	
	053347	122	040	101	
	053352	104	104	122	
	053355	105	123	123	
	053360	056	000		
2470	053362	045	116	045	NULSTR: .ASCIZ /#N#AA ZERO LENGTH STRING WAS ENTERED./
	053365	101	101	040	

	053370	132	105	122	
	053373	117	040	114	
	053376	105	116	107	
	053401	124	110	040	
	053404	123	124	122	
	053407	111	116	107	
	053412	040	127	101	
	053415	123	040	105	
	053420	116	124	105	
	053423	122	105	104	
	053426	056	000		
2471	053430	045	116	045	NODADR: .ASCIZ /#N#S2#T/
	053433	123	062	045	
	053436	124	000		
2472	053440	045	123	061	LOGNAM: .ASCIZ /#S14#AN#D2/
	053443	064	045	101	
	053446	116	045	104	
	053451	062	000		
2473	053453	045	123	061	NODTYP: .ASCIZ /#S14#T/
	053456	064	045	124	
	053461	000			
2474	053462	045	116	045	NTBHDR: .ASCIZ \#N#ANODE PHYSICAL ADDRESS NODE LOGICAL NAME TYPE(A/T)\
	053465	101	116	117	
	053470	104	105	040	
	053473	120	110	131	
	053476	123	111	103	
	053501	101	114	040	
	053504	101	104	104	
	053507	122	105	123	
	053512	123	040	040	
	053515	040	040	040	
	053520	116	117	104	
	053523	105	040	114	
	053526	117	107	111	
	053531	103	101	114	
	053534	040	116	101	
	053537	115	105	040	
	053542	040	040	040	
	053545	040	124	131	
	053550	120	105	050	
	053553	101	057	124	
	053556	051	000		
2475	053560	045	116	045	TABFUL: .ASCIZ /#N#ATHE #T#A TABLE IS FILLED TO CAPACITY!/#
	053563	101	124	110	
	053566	105	040	045	
	053571	124	045	101	
	053574	040	124	101	
	053577	102	114	105	
	053602	040	111	123	
	053605	040	106	111	
	053610	114	114	105	
	053613	104	040	124	
	053616	117	040	103	
	053621	101	120	101	
	053624	103	111	124	
	053627	131	041	000	
2476	053632	045	116	045	TABEMT: .ASCIZ /#N#ATHE #T#A TABLE IS CURRENTLY EMPTY!/#

	053635	101	124	110	
	053640	105	040	045	
	053643	124	045	101	
	053646	040	124	101	
	053651	102	114	105	
	053654	040	111	123	
	053657	040	103	125	
	053662	122	122	105	
	053665	116	124	114	
	053670	131	040	105	
	053673	115	120	124	
	053676	131	041	000	
2477	053701	116	117	104	NOD: .ASCIZ /NODE/
	053704	105	000		
2478	053706	123	125	115	SUMM: .ASCIZ /SUMMARY/
	053711	115	101	122	
	053714	131	000		
2479	053716	045	116	045	CLRMSG: .ASCIZ /%N%ATHE MESSAGE PARAMETERS HAVE BEEN RESET TO: /
	053721	101	124	110	
	053724	105	040	115	
	053727	105	123	123	
	053732	101	107	105	
	053735	040	120	101	
	053740	122	101	115	
	053743	105	124	105	
	053746	122	123	040	
	053751	110	101	126	
	053754	105	040	102	
	053757	105	105	116	
	053762	040	122	105	
	053765	123	105	124	
	053770	040	124	117	
	053773	072	000		
2480	053775	045	116	045	CPYLMT: .ASCIZ /%N%ATHE NUMBER OF COPIES MUST BE BETWEEN 1 AND 255. /
	054000	101	124	110	
	054003	105	040	116	
	054006	125	115	102	
	054011	105	122	040	
	054014	117	106	040	
	054017	103	117	120	
	054022	111	105	123	
	054025	040	115	125	
	054030	123	124	040	
	054033	102	105	040	
	054036	102	105	124	
	054041	127	105	105	
	054044	116	040	061	
	054047	040	101	116	
	054052	104	040	062	
	054055	065	065	056	
	054060	000			
2481	054061	045	116	045	SIZLMT: .ASCIZ /%N%ATHE MESSAGE SIZE [DATA] MUST BE BETWEEN 32 AND 1466 BYTES. /
	054064	101	124	110	
	054067	105	040	115	
	054072	105	123	123	
	054075	101	107	105	
	054100	040	123	111	

	054103	132	105	040	
	054106	133	104	101	
	054111	124	101	135	
	054114	040	115	125	
	054117	123	124	040	
	054122	102	105	040	
	054125	102	105	124	
	054130	127	105	105	
	054133	116	040	063	
	054136	062	040	101	
	054141	116	104	040	
	054144	061	064	066	
	054147	066	040	102	
	054152	131	124	105	
	054155	123	056	000	
2482	054160	045	116	045	NOCMPR: .ASCIZ /#N#ATHE ADDRESS MARKED FOR DELETION WAS NOT IN THE TABLE./
	054163	101	124	110	
	054166	105	040	101	
	054171	104	104	122	
	054174	105	123	123	
	054177	040	115	101	
	054202	122	113	105	
	054205	104	040	106	
	054210	117	122	040	
	054213	104	105	114	
	054216	105	124	111	
	054221	117	116	040	
	054224	127	101	123	
	054227	040	116	117	
	054232	124	040	111	
	054235	116	040	124	
	054240	110	105	040	
	054243	124	101	102	
	054246	114	105	056	
	054251	000			
2483	054252	045	116	045	UNBOND: .ASCIZ /#N#AAN UNBOUNDED "OPERATOR INPUT" STRING WAS ENTERED./
	054255	101	101	116	
	054260	040	125	116	
	054263	102	117	125	
	054266	116	104	105	
	054271	104	040	042	
	054274	117	120	105	
	054277	122	101	124	
	054302	117	122	040	
	054305	111	116	120	
	054310	125	124	042	
	054313	040	123	124	
	054316	122	111	116	
	054321	107	040	127	
	054324	101	123	040	
	054327	105	116	124	
	054332	105	122	105	
	054335	104	056	000	
2484	054340	045	116	045	ADRDEL: .ASCIZ /#N#ATHE ADDRESS HAS BEEN DELETED FROM THE NODE TABLE./
	054343	101	124	110	
	054346	105	040	101	
	054351	104	104	122	

	054354	105	123	123	
	054357	040	110	101	
	054362	123	040	102	
	054365	105	105	116	
	054370	040	104	105	
	054373	114	105	124	
	054376	105	104	040	
	054401	106	122	117	
	054404	115	040	124	
	054407	110	105	040	
	054412	116	117	104	
	054415	105	040	124	
	054420	101	102	114	
	054423	105	056	000	
2485	054426	045	116	045	LOGDEL: .ASCIZ /#N#ANODE N#D1#A HAS BEEN DELETED FROM THE NODE TABLE./
	054431	101	116	117	
	054434	104	105	040	
	054437	116	045	104	
	054442	061	045	101	
	054445	040	110	101	
	054450	123	040	102	
	054453	105	105	116	
	054456	040	104	105	
	054461	114	105	124	
	054464	105	104	040	
	054467	106	122	117	
	054472	115	040	124	
	054475	110	105	040	
	054500	116	117	104	
	054503	105	040	124	
	054506	101	102	114	
	054511	105	056	000	
2486	054514	045	116	045	TABCLR: .ASCIZ /#N#ATHE #T#A TABLE HAS BEEN CLEARED./
	054517	101	124	110	
	054522	105	040	045	
	054525	124	045	101	
	054530	040	124	101	
	054533	102	114	105	
	054536	040	110	101	
	054541	123	040	102	
	054544	105	105	116	
	054547	040	103	114	
	054552	105	101	122	
	054555	105	104	056	
	054560	000			
2487	054561	045	116	045	UNMSG: .ASCIZ /#N#ATHE NODE TABLE HAS BEEN #T/
	054564	101	124	110	
	054567	105	040	116	
	054572	117	104	105	
	054575	040	124	101	
	054600	102	114	105	
	054603	040	110	101	
	054606	123	040	102	
	054611	105	105	116	
	054614	040	045	124	
	054617	000			
2488	054620	123	101	126	SAVED: .ASCIZ /SAVED./

	054623	105	104	056	
	054626	000			
2489	054627	122	105	123	RESTOR: .ASCIZ /RESTORED./
	054632	124	117	122	
	054635	105	104	056	
	054640	000			
2490	054641	045	116	045	MSGPRM: .ASCIZ /%N%ATHE CURRENT MESSAGE PARAMETERS ARE: /
	054644	101	124	110	
	054647	105	040	103	
	054652	125	122	122	
	054655	105	116	124	
	054660	040	115	105	
	054663	123	123	101	
	054666	107	105	040	
	054671	120	101	122	
	054674	101	115	105	
	054677	124	105	122	
	054702	123	040	101	
	054705	122	105	072	
	054710	000			
2491	054711	045	116	045	MSG1: .ASCIZ /%N%ATHE COLLECTION OF ALL NODE ADDRESSES COULD TAKE AS LONG AS 40 MINUTES. /
	054714	101	124	110	
	054717	105	040	103	
	054722	117	114	114	
	054725	105	103	124	
	054730	111	117	116	
	054733	040	117	106	
	054736	040	101	114	
	054741	114	040	116	
	054744	117	104	105	
	054747	040	101	104	
	054752	104	122	105	
	054755	123	123	105	
	054760	123	040	103	
	054763	117	125	114	
	054766	104	040	124	
	054771	101	113	105	
	054774	040	101	123	
	054777	040	114	117	
	055002	116	107	040	
	055005	101	123	040	
	055010	064	060	040	
	055013	115	111	116	
	055016	125	124	105	
	055021	123	054	000	
2492	055024	045	116	045	MSG11: .ASCIZ /%N%AHOWEVER, IF NO NEW NODES ARE ADDED TO THE TABLE FOR A 10 MINUTE PERIOD /
	055027	101	110	117	
	055032	127	105	126	
	055035	105	122	054	
	055040	040	111	106	
	055043	040	116	117	
	055046	040	116	105	
	055051	127	040	116	
	055054	117	104	105	
	055057	123	040	101	
	055062	122	105	040	
	055065	101	104	104	

	055070	105	104	040	
	055073	124	117	040	
	055076	124	110	105	
	055101	040	124	101	
	055104	102	114	105	
	055107	040	106	117	
	055112	122	040	101	
	055115	040	061	060	
	055120	040	115	111	
	055123	116	125	124	
	055126	105	040	120	
	055131	105	122	111	
	055134	117	104	000	
2493	055137	045	116	045	MSG12: .ASCIZ /#N#ATHE COLLECTION WILL STOP.#N/
	055142	101	124	110	
	055145	105	040	103	
	055150	117	114	114	
	055153	105	103	124	
	055156	111	117	116	
	055161	040	127	111	
	055164	114	114	040	
	055167	123	124	117	
	055172	120	056	045	
	055175	116	000		
2494	055177	045	116	045	MSG2: .ASCIZ /#N#AYOU ENTERED #T#A NODE: #T/
	055202	101	131	117	
	055205	125	040	105	
	055210	116	124	105	
	055213	122	105	104	
	055216	040	045	124	
	055221	045	101	040	
	055224	116	117	104	
	055227	105	072	040	
	055232	045	124	000	
2495	055235	045	116	045	MSG3: .ASCIZ /#N#ATHE SPECIFIED ADDRESS IS: #T/
	055240	101	124	110	
	055243	105	040	123	
	055246	120	105	103	
	055251	111	106	111	
	055254	105	104	040	
	055257	101	104	104	
	055262	122	105	123	
	055265	123	040	111	
	055270	123	072	040	
	055273	045	124	000	
2496	055276	045	116	045	MSG4: .ASCIZ /#N#ATYPE=#T#A,SIZE=#D4#A,COPIES=#D3/
	055301	101	124	131	
	055304	120	105	075	
	055307	045	124	045	
	055312	101	054	123	
	055315	111	132	105	
	055320	075	045	104	
	055323	064	045	101	
	055326	054	103	117	
	055331	120	111	105	
	055334	123	075	045	
	055337	104	063	000	

2497					
2498	055342	045	116	045	.EVEN
	055345	101	040	045	HDMSG1: .ASCIZ /%N%A ETHERNET DEFAULT ADDRESS (HEX): %T/
	055350	124	110	105	
	055353	122	116	105	
	055356	124	040	104	
	055361	105	106	101	
	055364	125	114	124	
	055367	040	101	104	
	055372	104	122	105	
	055375	123	123	040	
	055400	050	110	105	
	055403	130	051	072	
	055406	040	040	045	
	055411	124	000		
2499	055413	045	116	062	HDMSG2: .ASCIZ /%N2%A ROM MICROCODE VERSION (DECIMAL): %D3/
	055416	045	101	040	
	055421	122	117	115	
	055424	040	115	111	
	055427	103	122	117	
	055432	103	117	104	
	055435	105	040	126	
	055440	105	122	123	
	055443	111	117	116	
	055446	040	050	104	
	055451	105	103	111	
	055454	115	101	114	
	055457	051	072	040	
	055462	045	104	063	
	055465	000			
2500	055466	045	116	062	HDMSG3: .ASCIZ /%N2%A SWITCH PACK SET FOR :/
	055471	045	101	040	
	055474	123	127	111	
	055477	124	103	110	
	055502	040	120	101	
	055505	103	113	040	
	055510	123	105	124	
	055513	040	106	117	
	055516	122	040	072	
	055521	000			
2501	055522	045	116	045	HDMSG4: .ASCIZ /%N%A
	055525	101	040	040	REMOTE AND POWER UP BOOT ENABLED/
	055530	040	040	040	
	055533	040	040	040	
	055536	122	105	115	
	055541	117	124	105	
	055544	040	101	116	
	055547	104	040	120	
	055552	117	127	105	
	055555	122	040	125	
	055560	120	040	102	
	055563	117	117	124	
	055566	040	105	116	
	055571	101	102	114	
	055574	105	104	000	
2502	055577	045	116	045	HDMSG5: .ASCIZ /%N%A
	055602	101	040	040	REMOTE BOOT ENABLED WITH ROM/

GLOBAL TEXT SECTION

	055605	040	040	040		
	055610	040	040	040		
	055613	122	105	115		
	055616	117	124	105		
	055621	040	102	117		
	055624	117	124	040		
	055627	105	116	101		
	055632	102	114	105		
	055635	104	040	127		
	055640	111	124	110		
	055643	040	122	117		
	055646	115	000			
2503	055650	045	116	045	HDMSG6: .ASCIZ /%N%A	REMOTE BOOT ENABLED/
	055653	101	040	040		
	055656	040	040	040		
	055661	040	040	040		
	055664	122	105	115		
	055667	117	124	105		
	055672	040	102	117		
	055675	117	124	040		
	055700	105	116	101		
	055703	102	114	105		
	055706	104	000			
2504	055710	045	116	045	HDMSG7: .ASCIZ /%N%A	REMOTE BOOT DISABLED/
	055713	101	040	040		
	055716	040	040	040		
	055721	040	040	040		
	055724	122	105	115		
	055727	117	124	105		
	055732	040	102	117		
	055735	117	124	040		
	055740	104	111	123		
	055743	101	102	114		
	055746	105	104	000		
2505	055751	045	116	045	HDMSG8: .ASCIZ /%N%A	SELF TEST LOOP ENABLED/
	055754	101	040	040		
	055757	040	040	040		
	055762	040	040	040		
	055765	123	105	114		
	055770	106	040	124		
	055773	105	123	124		
	055776	040	114	117		
	056001	117	120	040		
	056004	105	116	101		
	056007	102	114	105		
	056012	104	000			
2506	056014	045	116	045	HDMSG9: .ASCIZ /%N%A	SELF TEST LOOP DISABLED/
	056017	101	040	040		
	056022	040	040	040		
	056025	040	040	040		
	056030	123	105	114		
	056033	106	040	124		
	056036	105	123	124		
	056041	040	114	117		
	056044	117	120	040		
	056047	104	111	123		
	056052	101	102	114		

	056055	105	104	000
2507				
2508	056060	045	116	045
	056063	101	103	117
	056066	115	115	101
	056071	116	104	040
	056074	123	125	115
	056077	115	101	122
	056102	131	040	106
	056105	117	122	040
	056110	124	110	105
	056113	040	116	105
	056116	124	127	117
	056121	122	113	040
	056124	111	116	124
	056127	105	122	103
	056132	117	116	116
	056135	105	103	124
	056140	040	105	130
	056143	105	122	103
	056146	111	123	105
	056151	122	040	050
	056154	116	111	105
	056157	051	000	
2509	056161	045	116	045
	056164	101	050	111
	056167	124	040	111
	056172	123	040	117
	056175	116	114	131
	056200	040	116	105
	056203	103	105	123
	056206	123	101	122
	056211	131	040	124
	056214	117	040	124
	056217	131	120	105
	056222	040	124	110
	056225	105	040	114
	056230	105	124	124
	056233	105	122	123
	056236	040	111	116
	056241	040	102	122
	056244	101	103	113
	056247	105	124	123
	056252	051	000	
2510	056254	045	116	062
	056257	045	101	133
	056262	110	135	105
	056265	114	120	040
	056270	117	122	040
	056273	077	011	055
	056276	040	124	131
	056301	120	105	123
	056304	040	124	110
	056307	111	123	040
	056312	110	105	114
	056315	120	040	124
	056320	105	130	124

HELP1: .EVEN .ASCIZ \#N#ACOMMAND SUMMARY FOR THE NETWORK INTERCONNECT EXERCISER (NIE)\

HELP2: .ASCIZ \#N#A(IT IS ONLY NECESSARY TO TYPE THE LETTERS IN BRACKETS)\

HELP3: .ASCIZ \#N2#A[H]ELP OR ? - TYPES THIS HELP TEXT.\

2511	056323	056	000	062	HELP4: .ASCIZ \N2A[E]XIT	- RETURN TO THE SUPERVISOR.\
	056325	045	116			
	056330	045	101			
	056333	105	135			
	056336	111	124			
	056341	011	055			
	056344	122	105			
	056347	125	122			
	056352	040	124			
	056355	040	124			
	056360	105	040			
	056363	125	120			
	056366	122	126			
	056371	123	117			
	056374	056	000			
2512	056376	045	116	062	HELP5: .ASCIZ \N2A[SH]OW [N]ODES	- PRINTS INFORMATION IN CURRENT NODE TABLE.\
	056401	045	101			
	056404	123	110			
	056407	117	127			
	056412	133	116			
	056415	117	104			
	056420	123	011			
	056423	040	120			
	056426	111	116			
	056431	123	040			
	056434	116	106			
	056437	122	115			
	056442	124	111			
	056445	116	040			
	056450	116	040			
	056453	125	122			
	056456	105	116			
	056461	040	116			
	056464	104	105			
	056467	124	101			
	056472	114	105			
	056475	000				
2513	056476	045	116	062	HELP6: .ASCIZ \N2A[SH]OW [M]ESSAGE	- PRINTS THE SELECTED MESSAGE TYPE, SIZE AND COPIES.
	056501	045	101			
	056504	123	110			
	056507	117	127			
	056512	133	115			
	056515	105	123			
	056520	101	107			
	056523	011	055			
	056526	120	122			
	056531	116	124			
	056534	040	124			
	056537	105	040			
	056542	105	114			
	056545	103	124			
	056550	104	040			
	056553	105	123			
	056556	101	107			
	056561	040	124			
	056564	120	105			
	056567	040	123			

GLOBAL TEXT SECTION

	056572	132	105	040	
	056575	101	116	104	
	056600	040	103	117	
	056603	120	111	105	
	056606	123	056	000	
2514	056611	045	116	062	HELP7: .ASCIZ \N2%A[SHOW [C]OUNTERS - PRINTS THE LOW LEVEL COUNTERS OF THE HOST NODE.\
	056614	045	101	133	
	056617	123	110	135	
	056622	117	127	040	
	056625	133	103	135	
	056630	117	125	116	
	056633	124	105	122	
	056636	123	040	055	
	056641	040	120	122	
	056644	111	116	124	
	056647	123	040	124	
	056652	110	105	040	
	056655	114	117	127	
	056660	040	114	105	
	056663	126	105	114	
	056666	040	103	117	
	056671	125	116	124	
	056674	105	122	123	
	056677	040	117	106	
	056702	040	124	110	
	056705	105	040	110	
	056710	117	123	124	
	056713	040	116	117	
	056716	104	105	056	
	056721	000			
2515	056722	045	116	062	HELP8: .ASCIZ \N2%A[R]UN [L]OOPPAIR/PASS=NN - RUNS THE LOOPPAIR TEST.\
	056725	045	101	133	
	056730	122	135	125	
	056733	116	040	133	
	056736	114	135	117	
	056741	117	120	120	
	056744	101	111	122	
	056747	057	120	101	
	056752	123	123	075	
	056755	116	116	040	
	056760	055	040	122	
	056763	125	116	123	
	056766	040	124	110	
	056771	105	040	114	
	056774	117	117	120	
	056777	120	101	111	
	057002	122	040	124	
	057005	105	123	124	
	057010	056	000		
2516	057012	045	116	062	HELP9: .ASCIZ \N2%A[R]UN [A]LL/PASS=NN - RUNS THE NODE-TO-NODE TEST.\
	057015	045	101	133	
	057020	122	135	125	
	057023	116	040	133	
	057026	101	135	114	
	057031	114	057	120	
	057034	101	123	123	
	057037	075	116	116	

	057042	040	055	040	
	057045	122	125	116	
	057050	123	040	124	
	057053	110	105	040	
	057056	116	117	104	
	057061	105	055	124	
	057064	117	055	116	
	057067	117	104	105	
	057072	040	124	105	
	057075	123	124	056	
	057100	000			
2517	057101	045	116	062	HELP10: .ASCIZ \N2A[R]UN [D]IRECT/PASS=NN - RUNS THE LOOP DIRECT TEST.\
	057104	045	101	133	
	057107	122	135	125	
	057112	116	040	133	
	057115	104	135	111	
	057120	122	105	103	
	057123	124	057	120	
	057126	101	123	123	
	057131	075	116	116	
	057134	040	055	040	
	057137	122	125	116	
	057142	123	040	124	
	057145	110	105	040	
	057150	114	117	117	
	057153	120	040	104	
	057156	111	122	105	
	057161	103	124	040	
	057164	124	105	123	
	057167	124	056	000	
2518	057172	045	116	062	HELP11: .ASCIZ \N2A[R]UN [P]ATTERN/PASS=NN - RUNS THE MESSAGE PATTERN TEST.\
	057175	045	101	133	
	057200	122	135	125	
	057203	116	040	133	
	057206	120	135	101	
	057211	124	124	105	
	057214	122	116	057	
	057217	120	101	123	
	057222	123	075	116	
	057225	116	040	055	
	057230	040	122	125	
	057233	116	123	040	
	057236	124	110	105	
	057241	040	115	105	
	057244	123	123	101	
	057247	107	105	040	
	057252	120	101	124	
	057255	124	105	122	
	057260	116	040	124	
	057263	105	123	124	
	057266	056	000		
2519	057270	045	116	062	HELP12: .ASCIZ \N2A[M]ESSAGE/[T]YPE=A/[S]IZE=N/[C]OPIES=M - ALLOWS THE OPERATOR TO\
	057273	045	101	133	
	057276	115	135	105	
	057301	123	123	101	
	057304	107	105	057	
	057307	133	124	135	

GLOBAL TEXT SECTION

	057312	131	120	105	
	057315	075	101	057	
	057320	133	123	135	
	057323	111	132	105	
	057326	075	116	057	
	057331	133	103	135	
	057334	117	120	111	
	057337	105	123	075	
	057342	115	040	055	
	057345	040	101	114	
	057350	114	117	127	
	057353	123	040	124	
	057356	110	105	040	
	057361	117	120	105	
	057364	122	101	124	
	057367	117	122	040	
	057372	124	117	000	
2520	057375	045	116	045	HELP13: .ASCIZ \#N#AMODIFY THE DEFAULT MESSAGE TYPE, SIZE AND COPY PARAMETERS.\
	057400	101	115	117	
	057403	104	111	106	
	057406	131	040	124	
	057411	110	105	040	
	057414	104	105	106	
	057417	101	125	114	
	057422	124	040	115	
	057425	105	123	123	
	057430	101	107	105	
	057433	040	124	131	
	057436	120	105	054	
	057441	040	123	111	
	057444	132	105	040	
	057447	101	116	104	
	057452	040	103	117	
	057455	120	131	040	
	057460	120	101	122	
	057463	101	115	105	
	057466	124	105	122	
	057471	123	056	000	
2521	057474	045	116	062	HELP14: .ASCIZ \#N2#A[N]ODE ADR/TYPE - ENTERS A PHYSICAL ADDRESS INTO THE NODE\
	057477	045	101	133	
	057502	116	135	117	
	057505	104	105	040	
	057510	101	104	122	
	057513	057	124	131	
	057516	120	105	040	
	057521	055	040	105	
	057524	116	124	105	
	057527	122	123	040	
	057532	101	040	120	
	057535	110	131	123	
	057540	111	103	101	
	057543	114	040	101	
	057546	104	104	122	
	057551	105	123	123	
	057554	040	111	116	
	057557	124	117	040	
	057562	124	110	105	

	057565	040	116	117	
	057570	104	105	000	
2522	057573	045	116	045	HELP15: .ASCIZ \N#ATABLE. THE TYPE CAN BE EITHER [T]ARGET (DEFAULT) OR [A]SSIST.\
	057576	101	124	101	
	057601	102	114	105	
	057604	056	040	040	
	057607	124	110	105	
	057612	040	124	131	
	057615	120	105	040	
	057620	103	101	116	
	057623	040	102	105	
	057626	040	105	111	
	057631	124	110	105	
	057634	122	040	133	
	057637	124	135	101	
	057642	122	107	105	
	057645	124	040	050	
	057650	104	105	106	
	057653	101	125	114	
	057656	124	051	040	
	057661	117	122	040	
	057664	133	101	135	
	057667	123	123	111	
	057672	123	124	056	
	057675	000			
2523	057676	045	116	062	HELP16: .ASCIZ \N2#A[SU]MMARY - PRINTS A SUMMARY OF THE TEST RESULTS.\
	057701	045	101	133	
	057704	123	125	135	
	057707	115	115	101	
	057712	122	131	040	
	057715	055	040	120	
	057720	122	111	116	
	057723	124	123	040	
	057726	101	040	123	
	057731	125	115	115	
	057734	101	122	131	
	057737	040	117	106	
	057742	040	124	110	
	057745	105	040	124	
	057750	105	123	124	
	057753	040	122	105	
	057756	123	125	114	
	057761	124	123	056	
	057764	000			
2524	057765	045	116	062	HELP17: .ASCIZ \N2#A[B]UILD - BUILDS A TABLE OF REMOTE NODE PHYSICAL ADDRESSES BY\
	057770	045	101	133	
	057773	102	135	125	
	057776	111	114	104	
	060001	040	055	040	
	060004	102	125	111	
	060007	114	104	123	
	060012	040	101	040	
	060015	124	101	102	
	060020	114	105	040	
	060023	117	106	040	
	060026	122	105	115	
	060031	117	124	105	

GLOBAL TEXT SECTION

	060034	040	116	117	
	060037	104	105	040	
	060042	120	110	131	
	060045	123	111	103	
	060050	101	114	040	
	060053	101	104	104	
	060056	122	105	123	
	060061	123	105	123	
	060064	040	102	131	
	060067	000			
2525	060070	045	116	045	HELP18: .ASCIZ \#N#ALISTENING TO ID MESSAGES ON THE NI.\
	060073	101	114	111	
	060076	123	124	105	
	060101	116	111	116	
	060104	107	040	124	
	060107	117	040	111	
	060112	104	040	115	
	060115	105	123	123	
	060120	101	107	105	
	060123	123	040	117	
	060126	116	040	124	
	060131	110	105	040	
	060134	116	111	056	
	060137	000			
2526	060140	045	116	062	HELP19: .ASCIZ \#N2#A[C]LEAR [N]ODE/ADR - REMOVES THE NODE SPECIFIED BY EITHER ADR\
	060143	045	101	133	
	060146	103	135	114	
	060151	105	101	122	
	060154	040	133	116	
	060157	135	117	104	
	060162	105	057	101	
	060165	104	122	040	
	060170	055	040	122	
	060173	105	115	117	
	060176	126	105	123	
	060201	040	124	110	
	060204	105	040	116	
	060207	117	104	105	
	060212	040	123	120	
	060215	105	103	111	
	060220	106	111	105	
	060223	104	040	102	
	060226	131	040	105	
	060231	111	124	110	
	060234	105	122	040	
	060237	101	104	122	
	060242	000			
2527	060243	045	116	045	HELP20: .ASCIZ \#N#AOR NODE LOGICAL NAME FROM THE NODE TABLE.\
	060246	101	117	122	
	060251	040	116	117	
	060254	104	105	040	
	060257	114	117	107	
	060262	111	103	101	
	060265	114	040	116	
	060270	101	115	105	
	060273	040	106	122	
	060276	117	115	040	

	060301	124	110	105	
	060304	040	116	117	
	060307	104	105	040	
	060312	124	101	102	
	060315	114	105	056	
	060320	000			
2528	060321	045	116	062	HELP21: .ASCIZ \N2A[C]LEAR [N]ODE/[AL]L - CLEARS THE NODE TABLE.\
	060324	045	101	133	
	060327	103	135	114	
	060332	105	101	122	
	060335	040	133	116	
	060340	135	117	104	
	060343	105	057	133	
	060346	101	114	135	
	060351	114	040	055	
	060354	040	103	114	
	060357	105	101	122	
	060362	123	040	124	
	060365	110	105	040	
	060370	116	117	104	
	060373	105	040	124	
	060376	101	102	114	
	060401	105	056	000	
2529	060404	045	116	062	HELP22: .ASCIZ \N2A[C]LEAR [M]ESSAGE - SETS ALL MESSAGE PARAMETERS TO DEFAULT.\
	060407	045	101	133	
	060412	103	135	114	
	060415	105	101	122	
	060420	040	133	115	
	060423	135	105	123	
	060426	123	101	107	
	060431	105	040	055	
	060434	040	123	105	
	060437	124	123	040	
	060442	101	114	114	
	060445	040	115	105	
	060450	123	123	101	
	060453	107	105	040	
	060456	120	101	122	
	060461	101	115	105	
	060464	124	105	122	
	060467	123	040	124	
	060472	117	040	104	
	060475	105	106	101	
	060500	125	114	124	
	060503	056	000		
2530	060505	045	116	062	HELP23: .ASCIZ \N2A[C]LEAR [S]UMMARY - CLEARS THE TABLE OF SUMMARY TEST DATA.\
	060510	045	101	133	
	060513	103	135	114	
	060516	105	101	122	
	060521	040	133	123	
	060524	135	125	115	
	060527	115	101	122	
	060532	131	040	055	
	060535	040	103	114	
	060540	105	101	122	
	060543	123	040	124	
	060546	110	105	040	

	060551	124	101	102	
	060554	114	105	040	
	060557	117	106	040	
	060562	123	125	115	
	060565	115	101	122	
	060570	131	040	124	
	060573	105	123	124	
	060576	040	104	101	
	060601	124	101	056	
	060604	000			
E	2531 060605	045	116	062	HELP24: .ASCIZ \#N2#A[I]IDENTIFY ADR - USES THE REQUEST ID FUNCTION TO IDENTIFY A REMOTE NOD
	060610	045	101	133	
	060613	111	135	104	
	060616	105	116	124	
	060621	111	106	131	
	060624	040	101	104	
	060627	122	040	055	
	060632	040	125	123	
	060635	105	123	040	
	060640	124	110	105	
	060643	040	122	105	
	060646	121	125	105	
	060651	123	124	040	
	060654	111	104	040	
	060657	106	125	116	
	060662	103	124	111	
	060665	117	116	040	
	060670	124	117	040	
	060673	111	104	105	
	060676	116	124	111	
	060701	106	131	040	
	060704	101	040	122	
	060707	105	115	117	
	060712	124	105	040	
	060715	116	117	104	
	060720	105	040	117	
	060723	116	040	124	
	060726	110	105	040	
	060731	116	111	056	
	060734	000			
	2532 060735	045	116	062	HELP25: .ASCIZ \#N2#A[SA]VE - SAVES THE CONTENTS OF THE NODE TABLE.\
	060740	045	101	133	
	060743	123	101	135	
	060746	126	105	040	
	060751	055	040	123	
	060754	101	126	105	
	060757	123	040	124	
	060762	110	105	040	
	060765	103	117	116	
	060770	124	105	116	
	060773	124	123	040	
	060776	117	106	040	
	061001	124	110	105	
	061004	040	116	117	
	061007	104	105	040	
	061012	124	101	102	
	061015	114	105	056	

2533	061020	000			
	061021	045	116	062	HELP26: .ASCIZ \#N2#A[U]NSAVE - REPLACES THE CURRENT NODE TABLE WITH THE SAVED ONE.\
	061024	045	101		
	061027	125	135		
	061032	123	101		
	061035	105	040		
	061040	040	122		
	061043	120	114		
	061046	103	105		
	061051	040	124		
	061054	105	040		
	061057	125	122		
	061062	105	116		
	061065	040	116		
	061070	104	105		
	061073	124	101		
	061076	114	105		
	061101	127	111		
	061104	110	040		
	061107	110	105		
	061112	123	101		
	061115	105	104		
	061120	117	116		
	061123	056	000		

2534	061125	045	116	045	HELP27: .ASCIZ \#N#S8#ANOTES: 1) ADR IS THE PHYSICAL ADDRESS OF A NODE ON THE NI.\
	061130	123	070	045	
	061133	101	116	117	
	061136	124	105	123	
	061141	072	040	061	
	061144	051	040	101	
	061147	104	122	040	
	061152	111	123	040	
	061155	124	110	105	
	061160	040	120	110	
	061163	131	123	111	
	061166	103	101	114	
	061171	040	101	104	
	061174	104	122	105	
	061177	123	123	040	
	061202	117	106	040	
	061205	101	040	116	
	061210	117	104	105	
	061213	040	117	116	
	061216	040	124	110	
	061221	105	040	116	
	061224	111	056	000	
2535	061227	045	116	045	HELP28: .ASCIZ \#N#S8#A 2) PASS COUNT IS A DECIMAL NUMBER BETWEEN 1 AND 65534. A DEFA

UL

	061232	123	070	045
	061235	101	040	040
	061240	040	040	040
	061243	040	040	062
	061246	051	040	120
	061251	101	123	123
	061254	040	103	117
	061257	125	116	124
	061262	040	111	123
	061265	040	101	040

	061270	104	105	103
	061273	111	115	101
	061276	114	040	116
	061301	125	115	102
	061304	105	122	040
	061307	102	105	124
	061312	127	105	105
	061315	116	040	061
	061320	040	101	116
	061323	104	040	066
	061326	065	065	063
	061331	064	056	040
	061334	101	040	104
	061337	105	106	101
	061342	125	114	124
	061345	000		
2536	061346	045	116	045
	061351	123	070	045
	061354	101	040	040
	061357	040	040	040
	061362	040	040	040
	061365	040	040	126
	061370	101	114	125
	061373	105	040	117
	061376	106	040	061
	061401	040	111	123
	061404	040	101	123
	061407	123	125	115
	061412	105	104	056
	061415	000		
2537	061416	045	116	045
	061421	123	070	045
	061424	101	040	040
	061427	040	040	040
	061432	040	040	040
	061435	040	040	123
	061440	120	105	103
	061443	111	106	131
	061446	111	116	107
	061451	040	055	061
	061454	040	103	101
	061457	125	123	105
	061462	123	040	124
	061465	110	105	040
	061470	124	105	123
	061473	124	040	124
	061476	117	040	102
	061501	105	040	122
	061504	125	116	040
	061507	111	116	104
	061512	105	106	111
	061515	116	101	124
	061520	105	114	131
	061523	056	000	

HELP29: .ASCIZ \#N#S8#A

VALUE OF 1 IS ASSUMED.\

HELP30: .ASCIZ \#N#S8#A

SPECIFYING -1 CAUSES THE TEST TO BE RUN INDEFINATELY.\

2538
2539
2540

;
; .EVEN
; TEST MESSAGES AND ARGUMENTS

```

2541
2542
2543 061526 045 116 045 PASABT: .ASCIZ /#N#A PASS ABORTED!/
      061531 101 040 120
      061534 101 123 123
      061537 040 101 102
      061542 117 122 124
      061545 105 104 041
      061550 000
2544 061551 045 116 045 TSTMS1: .ASCIZ /#N#T#A TEST -- /
      061554 124 045 101
      061557 040 124 105
      061562 123 124 040
      061565 055 055 040
      061570 000
2545 061571 045 116 045 TSTMS2: .ASCIZ /#N#T#A NODE: #T/
      061574 124 045 101
      061577 040 116 117
      061602 104 105 072
      061605 040 045 124
      061610 000
2546 061611 045 124 045 TSTMS3: .ASCIZ /#T#A ERROR/
      061614 101 040 105
      061617 122 122 117
      061622 122 000
2547 061624 045 116 045 TSTMS4: .ASCIZ /#N#T#A NODE: #T#T#A NODE: #T/
      061627 124 045 101
      061632 040 116 117
      061635 104 105 072
      061640 040 045 124
      061643 045 124 045
      061646 101 040 116
      061651 117 104 105
      061654 072 040 045
      061657 124 000
2548 061661 045 101 040 OK: .ASCIZ /#A - RESPONSE OK/
      061664 055 040 122
      061667 105 123 120
      061672 117 116 123
      061675 105 040 117
      061700 113 000
2549 061702 045 116 045 OKRE: .ASCIZ /#N#A - RECEIVE ASSIST - RESPONSE OK/
      061705 101 040 055
      061710 040 122 105
      061713 103 105 111
      061716 126 105 040
      061721 101 123 123
      061724 111 123 124
      061727 040 055 040
      061732 122 105 123
      061735 120 117 116
      061740 123 105 040
      061743 117 113 000
2550 061746 045 116 045 OKTR: .ASCIZ /#N#A - TRANSMIT ASSIST - RESPONSE OK/
      061751 101 040 055
      061754 040 124 122
      061757 101 116 123

```


	061762	115	111	124	
	061765	040	101	123	
	061770	123	111	123	
	061773	124	040	055	
	061776	040	122	105	
	062001	123	120	117	
	062004	116	123	105	
	062007	040	117	113	
	062012	000			
2551	062013	045	116	045	OKFU: .ASCIZ /NNA - FULL ASSIST - RESPONSE OK/
	062016	101	040	055	
	062021	040	106	125	
	062024	114	114	040	
	062027	101	123	123	
	062032	111	123	124	
	062035	040	055	040	
	062040	122	105	123	
	062043	120	117	116	
	062046	123	105	040	
	062051	117	113	000	
2552	062054	045	116	045	MESPAT: .ASCIZ /NNAERROR OCCURED WITH TNA MESSAGE TYPE/
	062057	101	105	122	
	062062	122	117	122	
	062065	040	117	103	
	062070	103	125	122	
	062073	105	104	040	
	062076	127	111	124	
	062101	110	040	045	
	062104	124	045	101	
	062107	040	115	105	
	062112	123	123	101	
	062115	107	105	040	
	062120	124	131	120	
	062123	105	000		
2553	062125	045	101	040	MESPA1: .ASCIZ /NA DATA PATTERN: T/
	062130	104	101	124	
	062133	101	040	120	
	062136	101	124	124	
	062141	105	122	116	
	062144	072	040	045	
	062147	124	000		
2554	062151	101	114	114	ALLNOD: .ASCIZ /ALL NODE/
	062154	040	116	117	
	062157	104	105	000	
2555	062162	114	117	117	LUPAIR: .ASCIZ /LOPPAIR/
	062165	120	120	101	
	062170	111	122	000	
2556	062173	114	117	117	DIRECT: .ASCIZ /LOOP DIRECT/
	062176	120	040	104	
	062201	111	122	105	
	062204	103	124	000	
2557	062207	106	125	114	FULAST: .ASCIZ /FULL ASSIST/
	062212	114	040	101	
	062215	123	123	111	
	062220	123	124	000	
2558	062223	124	122	101	TRAST: .ASCIZ /TRANSMIT ASSIST/
	062226	116	123	115	

	062231	111	124	040		
	062234	101	123	123		
	062237	111	123	124		
	062242	000				
2559	062243	122	105	103	RECAST: .ASCIZ /RECEIVE ASSIST/	
	062246	105	111	126		
	062251	105	040	101		
	062254	123	123	111		
	062257	123	124	000		
2560	062262	115	105	123	PATTRN: .ASCIZ /MESSAGE PATTERN/	
	062265	123	101	107		
	062270	105	040	120		
	062273	101	124	124		
	062276	105	122	116		
	062301	000				
2561	062302	116	117	040	NORESP: .ASCIZ /NO RESPONSE/	
	062305	122	105	123		
	062310	120	117	116		
	062313	123	105	000		
2562	062316	105	130	103	RETRY: .ASCIZ /EXCESSIVE COLLISION/	
	062321	105	123	123		
	062324	111	126	105		
	062327	040	103	117		
	062332	114	114	111		
	062335	123	111	117		
	062340	116	000			
2563	062342	114	105	116	LENGTH: .ASCIZ /LENGTH/	
	062345	107	124	110		
	062350	000				
2564	062351	104	101	124	COMPAR: .ASCIZ /DATA COMPARISON/	
	062354	101	040	103		
	062357	117	115	120		
	062362	101	122	111		
	062365	123	117	116		
	062370	000				
2565					.EVEN	
2566						
2567	062372	101	114	120	MSGTY0: .ASCIZ /ALPHA/	;MESSAGE TYPES
	062375	110	101	000		
2568	062400	117	116	105	MSGTY1: .ASCIZ /ONES/	
	062403	123	000			
2569	062405	132	105	122	MSGTY2: .ASCIZ /ZEROS/	
	062410	117	123	000		
2570	062413	061	101	114	MSGTY3: .ASCIZ /1ALT/	
	062416	124	000			
2571	062420	060	101	114	MSGTY4: .ASCIZ /0ALT/	
	062423	124	000			
2572	062425	103	103	111	MSGTY5: .ASCIZ /CCITT/	
	062430	124	124	000		
2573	062433	117	120	105	MSGTY6: .ASCIZ /OPER SEL/	
	062436	122	040	123		
	062441	105	114	000		
2574	062444	105	130	111	CMDTY1: .ASCIZ /EXIT/	;COMMAND TYPES
	062447	124	000			
2575	062451	123	125	115	CMDTY2: .ASCIZ /SUMMARY/	
	062454	115	101	122		
	062457	131	000			

```

2576 062461      102      125      111  CMDTY3: .ASCIZ  /BUILD/
      062464      114      104      000
2577 062467      123      110      117  CMDTY4: .ASCIZ  /SHOW/
      062472      127      000
2578 062474      122      125      116  CMDTY5: .ASCIZ  /RUN/
      062477      000
2579 062500      115      105      123  CMDTY6: .ASCIZ  /MESSAGE/
      062503      123      101      107
      062506      105      000
2580 062510      116      117      104  CMDTY7: .ASCIZ  /NODE/
      062513      105      000
2581 062515      103      114      105  CMDTY8: .ASCIZ  /CLEAR/
      062520      101      122      000
2582 062523      122      105      121  CMDTY9: .ASCIZ  /REQUEST ID/
      062526      125      105      123
      062531      124      040      111
      062534      104      000
2583 062536      116      117      104  ARGTY1: .ASCIZ  /NODES/                ; ARGUMENT TYPES
      062541      105      123      000
2584 062544      115      105      123  ARGTY2: .ASCIZ  /MESSAGES/
      062547      123      101      107
      062552      105      123      000
2585 062555      103      117      125  ARGTY3: .ASCIZ  /COUNTERS/
      062560      116      124      105
      062563      122      123      000
2586 062566      114      117      117  ARGTY4: .ASCIZ  /LOOPPAIR/
      062571      120      120      101
      062574      111      122      000
2587 062577      101      114      114  ARGTY5: .ASCIZ  /ALL/
      062602      000
2588 062603      040      101      123  ARGTY6: .ASCIZ  / ASSIST/
      062606      123      111      123
      062611      124      000
2589 062613      124      101      122  ARGTY7: .ASCIZ  /TARGET/
      062616      107      105      124
      062621      000
2590
2591 062622      045      116      045  NOCLK: .ASCIZ  /%N%ABAD CLOCK - PROGRAM WILL HANG ON "TIMEOUT"!!!/
      062625      101      102      101
      062630      104      040      103
      062633      114      117      103
      062636      113      040      055
      062641      040      120      122
      062644      117      107      122
      062647      101      115      040
      062652      127      111      114
      062655      114      040      110
      062660      101      116      107
      062663      040      117      116
      062666      040      042      124
      062671      111      115      105
      062674      117      125      124
      062677      042      041      041
      062702      000

```

2592
2593
2594

;
; UNA COUNTER INFORMATION MESSAGES


```

2595
2596
2597 062703      045      116      045  CNTR00: .ASCIZ  /#N#S5#ACONTENTS OF NODE #T#A INTERNAL COUNTERS:/
      062706      123      065      045
      062711      101      103      117
      062714      116      124      105
      062717      116      124      123
      062722      040      117      106
      062725      040      116      117
      062730      104      105      040
      062733      045      124      045
      062736      101      040      111
      062741      116      124      105
      062744      122      116      101
      062747      114      040      103
      062752      117      125      116
      062755      124      105      122
      062760      123      072      000
2598 062763      045      116      062  CNTR01: .ASCIZ  /#N#ASECONDS SINCE LAST ZEROED:#S15#Z5/
      062766      045      101      123
      062771      105      103      117
      062774      116      104      123
      062777      040      123      111
      063002      116      103      105
      063005      040      114      101
      063010      123      124      040
      063013      132      105      122
      063016      117      105      104
      063021      072      045      123
      063024      061      065      045
      063027      132      065      000
2599 063032      045      116      045  CNTR02: .ASCIZ  /#N#APACKETS RECEIVED:#S19#T/
      063035      101      120      101
      063040      103      113      105
      063043      124      123      040
      063046      122      105      103
      063051      105      111      126
      063054      105      104      072
      063057      045      123      061
      063062      071      045      124
      063065      000
2600 063066      045      116      045  CNTR03: .ASCIZ  /#N#AMULTICAST PACKETS RECEIVED:#S9#T/
      063071      101      115      125
      063074      114      124      111
      063077      103      101      123
      063102      124      040      120
      063105      101      103      113
      063110      105      124      123
      063113      040      122      105
      063116      103      105      111
      063121      126      105      104
      063124      072      045      123
      063127      071      045      124
      063132      000
2601 063133      045      116      045  CNTR04: .ASCTZ  /#N#APACKETS REC'D WITH ERROR - BITMAP:#S9#B3/
      063136      101      120      101
      063141      103      113      105

```

	063144	124	123	040	
	063147	122	105	103	
	063152	047	104	040	
	063155	127	111	124	
	063160	110	040	105	
	063163	122	122	117	
	063166	122	040	055	
	063171	040	102	111	
	063174	124	115	101	
	063177	120	072	045	
	063202	123	071	045	
	063205	102	063	000	
2602	063210	045	116	045	CNTR05: .ASCIZ /%N%APACKETS RECEIVED WITH ERROR:%S13%Z5/
	063213	101	120	101	
	063216	103	113	105	
	063221	124	123	040	
	063224	122	105	103	
	063227	105	111	126	
	063232	105	104	040	
	063235	127	111	124	
	063240	110	040	105	
	063243	122	122	117	
	063246	122	072	045	
	063251	123	061	063	
	063254	045	132	065	
	063257	000			
2603	063260	045	116	045	CNTR06: .ASCIZ /%N%ADATA BYTES RECEIVED:%S16%T/
	063263	101	104	101	
	063266	124	101	040	
	063271	102	131	124	
	063274	105	123	040	
	063277	122	105	103	
	063302	105	111	126	
	063305	105	104	072	
	063310	045	123	061	
	063313	066	045	124	
	063316	000			
2604	063317	045	116	045	CNTR07: .ASCIZ /%N%AMULTICAST DATA BYTES RECEIVED:%S6%T/
	063322	101	115	125	
	063325	114	124	111	
	063330	103	101	123	
	063333	124	040	104	
	063336	101	124	101	
	063341	040	102	131	
	063344	124	105	123	
	063347	040	122	105	
	063352	103	105	111	
	063355	126	105	104	
	063360	072	045	123	
	063363	066	045	124	
	063366	000			
2605	063367	045	116	045	CNTR08: .ASCIZ /%N%ARECEIVED PACKETS LOST-INTERNAL:%S10%Z5/
	063372	101	122	105	
	063375	103	105	111	
	063400	126	105	104	
	063403	040	120	101	
	063406	103	113	105	

	063411	124	123	040	
	063414	114	117	123	
	063417	124	055	111	
	063422	116	124	105	
	063425	122	116	101	
	063430	114	072	045	
	063433	123	061	060	
	063436	045	132	065	
	063441	000			
2606	063442	045	116	045	CNTR09: .ASCIZ /#N#ARECEIVED PACKETS LOST -LOCAL:#S12#Z5/
	063445	101	122	105	
	063450	103	105	111	
	063453	126	105	104	
	063456	040	120	101	
	063461	103	113	105	
	063464	124	123	040	
	063467	114	117	123	
	063472	124	040	055	
	063475	114	117	103	
	063500	101	114	072	
	063503	045	123	061	
	063506	062	045	132	
	063511	065	000		
2607	063513	045	116	045	CNTR10: .ASCIZ /#N#APACKETS TRANSMITTED:#S16#T/
	063516	101	120	101	
	063521	103	113	105	
	063524	124	123	040	
	063527	124	122	101	
	063532	116	123	115	
	063535	111	124	124	
	063540	105	104	072	
	063543	045	123	061	
	063546	066	045	124	
	063551	000			
2608	063552	045	116	045	CNTR11: .ASCIZ /#N#AMULTICAST PACKETS TRANSMITTED:#S6#T/
	063555	101	115	125	
	063560	114	124	111	
	063563	103	101	123	
	063566	124	040	120	
	063571	101	103	113	
	063574	105	124	123	
	063577	040	124	122	
	063602	101	116	123	
	063605	115	111	124	
	063610	124	105	104	
	063613	072	045	123	
	063616	066	045	124	
	063621	000			
2609	063622	045	116	045	CNTR12: .ASCIZ /#N#APACKETS TRANSMITTED 3+ TRYS:#S8#T/
	063625	101	120	101	
	063630	103	113	105	
	063633	124	123	040	
	063636	124	122	101	
	063641	116	123	115	
	063644	111	124	124	
	063647	105	104	040	
	063652	063	053	040	

	063655	124	122	131	
	063660	123	072	045	
	063663	123	070	045	
	063666	124	000		
2610	063670	045	116	045	CNTR13: .ASCIZ /#N#APACKETS TRANSMITTED 2 TRYS:#S9#T/
	063673	101	120	101	
	063676	103	113	105	
	063701	124	123	040	
	063704	124	122	101	
	063707	116	123	115	
	063712	111	124	124	
	063715	105	104	040	
	063720	062	040	124	
	063723	122	131	123	
	063726	072	045	123	
	063731	071	045	124	
	063734	000			
2611	063735	045	116	045	CNTR14: .ASCIZ /#N#APACKETS DEFFERED:#S19#T/
	063740	101	120	101	
	063743	103	113	105	
	063746	124	123	040	
	063751	104	105	106	
	063754	106	105	122	
	063757	105	104	072	
	063762	045	123	061	
	063765	071	045	124	
	063770	000			
2612	063771	045	116	045	CNTR15: .ASCIZ /#N#ADATA BYTES TRANSMITTED:#S13#T/
	063774	101	104	101	
	063777	124	101	040	
	064002	102	131	124	
	064005	105	123	040	
	064010	124	122	101	
	064013	116	123	115	
	064016	111	124	124	
	064021	105	104	072	
	064024	045	123	061	
	064027	063	045	124	
	064032	000			
2613	064033	045	116	045	CNTR16: .ASCIZ /#N#AMULTICAST BYTES TRANSMITTED:#S8#T/
	064036	101	115	125	
	064041	114	124	111	
	064044	103	101	123	
	064047	124	040	102	
	064052	131	124	105	
	064055	123	040	124	
	064060	122	101	116	
	064063	123	115	111	
	064066	124	124	105	
	064071	104	072	045	
	064074	123	070	045	
	064077	124	000		
2614	064101	045	116	045	CNTR17: .ASCIZ /#N#ATRANSMIT PACKETS ABORTED-BITMAP:#S8#B6/
	064104	101	124	122	
	064107	101	116	123	
	064112	115	111	124	
	064115	040	120	101	

	064120	103	113	105	
	064123	124	123	040	
	064126	101	102	117	
	064131	122	124	105	
	064134	104	055	102	
	064137	111	124	115	
	064142	101	120	072	
	064145	045	123	070	
	064150	045	102	066	
	064153	000			
2615	064154	045	116	045	CNTR18: .ASCIZ /#N#ATRANSMIT PACKETS ABORTED:#S16#Z5/
	064157	101	124	122	
	064162	101	116	123	
	064165	115	111	124	
	064170	040	120	101	
	064173	103	113	105	
	064176	124	123	040	
	064201	101	102	117	
	064204	122	124	105	
	064207	104	072	045	
	064212	123	061	066	
	064215	045	132	065	
	064220	000			
2616	064221	045	116	045	CNTR19: .ASCIZ /#N#AXMIT COLLISION CHECK FAILURE:#S12#Z5/
	064224	101	130	115	
	064227	111	124	040	
	064232	103	117	114	
	064235	114	111	123	
	064240	111	117	116	
	064243	040	103	110	
	064246	105	103	113	
	064251	040	106	101	
	064254	111	114	125	
	064257	122	105	072	
	064262	045	123	061	
	064265	062	045	132	
	064270	065	000		
2617					
2618					
2619					
2620					
2621					
2622	064272	125	116	101	EMSG01: .ASCIZ /UNA PORT COMMAND ERROR/
	064275	040	120	117	
	064300	122	124	040	
	064303	103	117	115	
	064306	115	101	116	
	064311	104	040	105	
	064314	122	122	117	
	064317	122	000		
2623	064321	125	116	101	EMSG02: .ASCIZ /UNA FATAL ERROR/
	064324	040	106	101	
	064327	124	101	114	
	064332	040	105	122	
	064335	122	117	122	
	064340	000			
2624	064341	125	116	105	EMSG03: .ASCIZ /UNEXPLAINED UNA INTERRUPT/

;
; ERROR MESSAGES FOR DEUNA DRIVER
;

	064344	130	120	114	
	064347	101	111	116	
	064352	105	104	040	
	064355	125	116	101	
	064360	040	111	116	
	064363	124	105	122	
	064366	122	125	120	
	064371	124	000		
2625	064373	125	116	113	EMSG04: .ASCIZ /UNKNOWN UNA ERROR/
	064376	116	117	127	
	064401	116	040	125	
	064404	116	101	040	
	064407	105	122	122	
	064412	117	122	000	
2626	064415	125	116	101	EMSG05: .ASCIZ /UNA WON'T READ PCB ADDRESS/
	064420	040	127	117	
	064423	116	047	124	
	064426	040	122	105	
	064431	101	104	040	
	064434	120	103	102	
	064437	040	101	104	
	064442	104	122	105	
	064445	123	123	000	
2627	064450	125	116	101	EMSG06: .ASCIZ /UNABLE TO READ PHYSICAL ADDRESS/
	064453	102	114	105	
	064456	040	124	117	
	064461	040	122	105	
	064464	101	104	040	
	064467	120	110	131	
	064472	123	111	103	
	064475	101	114	040	
	064500	101	104	104	
	064503	122	105	123	
	064506	123	000		
2628	064510	125	116	101	EMSG07: .ASCIZ /UNA WILL NOT GO INTO RUNNING STATE/
	064513	040	127	111	
	064516	114	114	040	
	064521	116	117	124	
	064524	040	107	117	
	064527	040	111	116	
	064532	124	117	040	
	064535	122	125	116	
	064540	116	111	116	
	064543	107	040	123	
	064546	124	101	124	
	064551	105	000		
2629	064553	124	111	115	EMSG08: .ASCIZ /TIMEOUT!--TRANSMIT FLAG NOT SET/
	064556	105	117	125	
	064561	124	041	055	
	064564	055	124	122	
	064567	101	116	123	
	064572	115	111	124	
	064575	040	106	114	
	064600	101	107	040	
	064603	116	117	124	
	064606	040	123	105	
	064611	124	000		

2630	064613	105	122	122	MSG09: .ASCIZ /ERROR DURING TRANSMIT PDMD COMMAND/
	064616	117	122	040	
	064621	104	125	122	
	064624	111	116	107	
	064627	040	124	122	
	064632	101	116	123	
	064635	115	111	124	
	064640	040	120	104	
	064643	115	104	040	
	064646	103	117	115	
	064651	115	101	116	
	064654	104	000		
2631	064656	124	122	101	MSG10: .ASCIZ /TRANSMIT RING BOOKKEEPING ERROR/
	064661	116	123	115	
	064664	111	124	040	
	064667	122	111	116	
	064672	107	040	102	
	064675	117	117	113	
	064700	113	105	105	
	064703	120	111	116	
	064706	107	040	105	
	064711	122	122	117	
	064714	122	000		
2632	064716	122	105	103	MSG11: .ASCIZ /RECEIVE RING BOOKKEEPING ERROR/
	064721	105	111	126	
	064724	105	040	122	
	064727	111	116	107	
	064732	040	102	117	
	064735	117	113	113	
	064740	105	105	120	
	064743	111	116	107	
	064746	040	105	122	
	064751	122	117	122	
	064754	000			
2633	064755	115	105	123	MSG14: .ASCIZ /MESSAGE SIZE TOO BIG FOR MAX. PACKET LENGTH/
	064760	123	101	107	
	064763	105	040	123	
	064766	111	132	105	
	064771	040	124	117	
	064774	117	040	102	
	064777	111	107	040	
	065002	106	117	122	
	065005	040	115	101	
	065010	130	056	040	
	065013	120	101	103	
	065016	113	105	124	
	065021	040	114	105	
	065024	116	107	124	
	065027	110	000		
2634	065031	104	116	111	MSG15: .ASCIZ /DNI DID NOT SET FROM RESET/
	065034	040	104	111	
	065037	104	040	116	
	065042	117	124	040	
	065045	123	105	124	
	065050	040	106	122	
	065053	117	115	040	
	065056	122	105	123	

GLOBAL TEXT SECTION

	065061	105	124	000	
2635	065064	125	116	101	EMSG16: .ASCIZ /UNA WILL NOT READ DESCRIPTOR RINGS/
	065067	040	127	111	
	065072	114	114	040	
	065075	116	117	124	
	065100	040	122	105	
	065103	101	104	040	
	065106	104	105	123	
	065111	103	122	111	
	065114	120	124	117	
	065117	122	040	122	
	065122	111	116	107	
	065125	123	000		
2636	065127	103	101	116	EMSG18: .ASCIZ /CAN'T GET INITIAL STATUS INFO FROM UNA/
	065132	047	124	040	
	065135	107	105	124	
	065140	040	111	116	
	065143	111	124	111	
	065146	101	114	040	
	065151	123	124	101	
	065154	124	125	123	
	065157	040	111	116	
	065162	106	117	040	
	065165	106	122	117	
	065170	115	040	125	
	065173	116	101	000	
2637	065176	115	105	123	EMSG19: .ASCIZ /MESSAGE DATA COMPARISON ERROR/
	065201	123	101	107	
	065204	105	040	104	
	065207	101	124	101	
	065212	040	103	117	
	065215	115	120	101	
	065220	122	111	123	
	065223	117	116	040	
	065226	105	122	122	
	065231	117	122	000	
2638	065234	124	117	124	EMSG20: .ASCIZ /TOTAL DATA COMPARE ERRORS/
	065237	101	114	040	
	065242	104	101	124	
	065245	101	040	103	
	065250	117	115	120	
	065253	101	122	105	
	065256	040	105	122	
	065261	122	117	122	
	065264	123	000		
2639	065266	045	116	045	EMSG22: .ASCIZ /NANO RESPONSE FROM NODE./
	065271	101	116	117	
	065274	040	122	105	
	065277	123	120	117	
	065302	116	123	105	
	065305	040	106	122	
	065310	117	115	040	
	065313	116	117	104	
	065316	105	056	000	
2640	065321	105	122	122	EMSG23: .ASCIZ /ERROR WHILE ATTEMPTING TO WRITE MODE/
	065324	117	122	040	
	065327	127	110	111	

	065332	114	105	040	
	065335	101	124	124	
	065340	105	115	120	
	065343	124	111	116	
	065346	107	040	124	
	065351	117	040	127	
	065354	122	111	124	
	065357	105	040	115	
	065362	117	104	105	
	065365	000			
2641	065366	124	122	101	MSG24: .ASCIZ /TRANSMIT ERROR, ALL PACKETS NOT TRANSMITTED/
	065371	116	123	115	
	065374	111	124	040	
	065377	105	122	122	
	065402	117	122	054	
	065405	040	101	114	
	065410	114	040	120	
	065413	101	103	113	
	065416	105	124	123	
	065421	040	116	117	
	065424	124	040	124	
	065427	122	101	116	
	065432	123	115	111	
	065435	124	124	105	
	065440	104	000		
2642	065442	105	122	122	MSG25: .ASCIZ /ERROR WHILE ATTEMPTING TO WRITE MULTICAST ADDRESS LIST/
	065445	117	122	040	
	065450	127	110	111	
	065453	114	105	040	
	065456	101	124	124	
	065461	105	115	120	
	065464	124	111	116	
	065467	107	040	124	
	065472	117	040	127	
	065475	122	111	124	
	065500	105	040	115	
	065503	125	114	124	
	065506	111	103	101	
	065511	123	124	040	
	065514	101	104	104	
	065517	122	105	123	
	065522	123	040	114	
	065525	111	123	124	
	065530	000			
2643	065531	105	122	122	MSG30: .ASCIZ /ERROR WHILE ATTEMPTING PORT FUNCTION/
	065534	117	122	040	
	065537	127	110	111	
	065542	114	105	040	
	065545	101	124	124	
	065550	105	115	120	
	065553	124	111	116	
	065556	107	040	120	
	065561	117	122	124	
	065564	040	106	125	
	065567	116	103	124	
	065572	111	117	116	
	065575	000			

GLOBAL TEXT SECTION

2644	065576	125	116	101	EMSG31: .ASCIZ /UNABLE TO READ INTERNAL COUNTERS/
	065601	102	114	105	
	065604	040	124	117	
	065607	040	122	105	
	065612	101	104	040	
	065615	111	116	124	
	065620	105	122	116	
	065623	101	114	040	
	065626	103	117	125	
	065631	116	124	105	
	065634	122	123	000	
2645	065637	045	116	045	EMSG32: .ASCIZ \N#AILLEGAL TARGET/ASSIST PAIR IN NODE TABLE\
	065642	101	111	114	
	065645	114	105	107	
	065650	101	114	040	
	065653	124	101	122	
	065656	107	105	124	
	065661	057	101	123	
	065664	123	111	123	
	065667	124	040	120	
	065672	101	111	122	
	065675	040	111	116	
	065700	040	116	117	
	065703	104	105	040	
	065706	124	101	102	
	065711	114	105	000	
2646	065714	124	111	115	EMSG33: .ASCIZ /TIMEOUT ERROR/
	065717	105	117	125	
	065722	124	040	105	
	065725	122	122	117	
	065730	122	000		
2647	065732	015	012	124	EMSG34: .ASCIZ <15><12>/TIMEOUT OCCURED BEFORE LOOPBACK REPLY/
	065735	111	115	105	
	065740	117	125	124	
	065743	040	117	103	
	065746	103	125	122	
	065751	105	104	040	
	065754	102	105	106	
	065757	117	122	105	
	065762	040	114	117	
	065765	117	120	102	
	065770	101	103	113	
	065773	040	122	105	
	065776	120	114	131	
	066001	000			
2648	066002	045	101	106	EMSG35: .ASCIZ /#AFAILING NODE ADDRESS: #T#N/
	066005	101	111	114	
	066010	111	116	107	
	066013	040	116	117	
	066016	104	105	040	
	066021	101	104	104	
	066024	122	105	123	
	066027	123	072	040	
	066032	045	124	045	
	066035	116	000		
2649	066037	045	101	104	EMSG36: .ASCIZ /#ADATA PATTERN: #T#N/
	066042	101	124	101	

	066045	040	120	101	
	066050	124	124	105	
	066053	122	116	072	
	066056	040	045	124	
	066061	045	116	000	
2650	066064	045	101	106	EMSG37: .ASCIZ /#AFAILING TARGET NODE ADDRESS: #T#N/
	066067	101	111	114	
	066072	111	116	107	
	066075	040	124	101	
	066100	122	107	105	
	066103	124	040	116	
	066106	117	104	105	
	066111	040	101	104	
	066114	104	122	105	
	066117	123	123	072	
	066122	040	045	124	
	066125	045	116	000	
2651	066130	045	101	106	EMSG38: .ASCIZ /#AFAILING ASSIST NODE ADDRESS: #T#N/
	066133	101	111	114	
	066136	111	116	107	
	066141	040	101	123	
	066144	123	111	123	
	066147	124	040	116	
	066152	117	104	105	
	066155	040	101	104	
	066160	104	122	105	
	066163	123	123	072	
	066166	040	045	124	
	066171	045	116	000	
2652	066174	015	012	124	EMSG40: .ASCIZ <15><12>/TIMEOUT OCCURED - LOOP MESSAGE TYPE - RECEIVE ASSIST/
	066177	111	115	105	
	066202	117	125	124	
	066205	040	117	103	
	066210	103	125	122	
	066213	105	104	040	
	066216	055	040	114	
	066221	117	117	120	
	066224	040	115	105	
	066227	123	123	101	
	066232	107	105	040	
	066235	124	131	120	
	066240	105	040	055	
	066243	040	122	105	
	066246	103	105	111	
	066251	126	105	040	
	066254	101	123	123	
	066257	111	123	124	
	066262	000			
2653	066263	015	012	124	EMSG41: .ASCIZ <15><12>/TIMEOUT OCCURED - LOOP MESSAGE TYPE - TRANSMIT ASSIST/
	066266	111	115	105	
	066271	117	125	124	
	066274	040	117	103	
	066277	103	125	122	
	066302	105	104	040	
	066305	055	040	114	
	066310	117	117	120	
	066313	040	115	105	

	066316	123	123	101	
	066321	107	105	040	
	066324	124	131	120	
	066327	105	040	055	
	066332	040	124	122	
	066335	101	116	123	
	066340	115	111	124	
	066343	040	101	123	
	066346	123	111	123	
	066351	124	000		
2654	066353	015	012	124	EMSG42: .ASCIZ <15><12>/TIMEOUT OCCURED - LOOP MESSAGE TYPE - FULL ASSIST/
	066356	111	115	105	
	066361	117	125	124	
	066364	040	117	103	
	066367	103	125	122	
	066372	105	104	040	
	066375	055	040	114	
	066400	117	117	120	
	066403	040	115	105	
	066406	123	123	101	
	066411	107	105	040	
	066414	124	131	120	
	066417	105	040	055	
	066422	040	106	125	
	066425	114	114	040	
	066430	101	123	123	
	066433	111	123	124	
	066436	000			
2655					
2656					.EVEN
2657	066440	045	116	045	SIMSG1: .ASCIZ /#N#A NODE DEFAULT ADDRESS: #T/
	066443	101	040	040	
	066446	116	117	104	
	066451	105	040	104	
	066454	105	106	101	
	066457	125	114	124	
	066462	040	101	104	
	066465	104	122	105	
	066470	123	123	072	
	066473	040	045	124	
	066476	000			
2658	066477	045	116	045	SIMSG2: .ASCIZ /#N#S#ARECEIPT NUMBER: #06/
	066502	123	070	045	
	066505	101	122	105	
	066510	103	105	111	
	066513	120	124	040	
	066516	116	125	115	
	066521	102	105	122	
	066524	072	040	045	
	066527	117	066	000	
2659	066532	045	116	045	SIMSG3: .ASCIZ /#N#A MAINTENANCE VERSION: #Z2/
	066535	101	040	040	
	066540	040	115	101	
	066543	111	116	124	
	066546	105	116	101	
	066551	116	103	105	
	066554	040	126	105	

	066557	122	123	111	
	066562	117	116	072	
	066565	040	045	132	
	066570	062	000		
2660	066572	045	116	045	SIMSG4: .ASCIZ /#N#S19#AECO: #Z2/
	066575	123	061	071	
	066600	045	101	105	
	066603	103	117	072	
	066606	040	045	132	
	066611	062	000		
2661	066613	045	116	045	SIMSG5: .ASCIZ /#N#S14#AUSER ECO: #Z2/
	066616	123	061	064	
	066621	045	101	125	
	066624	123	105	122	
	066627	040	105	103	
	066632	117	072	040	
	066635	045	132	062	
	066640	000			
2662	066641	045	116	045	SIMSG6: .ASCIZ /#N#S14#AFUNCTION: #02/
	066644	123	061	064	
	066647	045	101	106	
	066652	125	116	103	
	066655	124	111	117	
	066660	116	072	040	
	066663	045	117	062	
	066666	000			
2663	066667	045	116	045	SIMSG7: .ASCIZ /#N#S16#ADEVICE: #02/
	066672	123	061	066	
	066675	045	101	104	
	066700	105	126	111	
	066703	103	105	072	
	066706	040	045	117	
	066711	062	000		
2664					
2665					.EVEN
2666	066714	045	116	045	PCMSG:: .ASCIZ /#N#APC OF CALLING ROUTINE = #06/
	066717	101	120	103	
	066722	040	117	106	
	066725	040	103	101	
	066730	114	114	111	
	066733	116	107	040	
	066736	122	117	125	
	066741	124	111	116	
	066744	105	040	075	
	066747	040	045	117	
	066752	066	000		
2667					.EVEN
2668	066754	045	116	045	CMPER1: .ASCIZ /#N#ABYTE NUMBER:#D4#A(D) EXPECTED=#06#A(O) RECIEVED=#06#A(O)/
	066757	101	102	131	
	066762	124	105	040	
	066765	116	125	115	
	066770	102	105	122	
	066773	072	045	104	
	066776	064	045	101	
	067001	050	104	051	
	067004	040	105	130	
	067007	120	105	103	

	067012	124	105	104	
	067015	075	045	117	
	067020	066	045	101	
	067023	050	117	051	
	067026	040	122	105	
	067031	103	111	105	
	067034	126	105	104	
	067037	075	045	117	
	067042	066	045	101	
	067045	050	117	051	
	067050	000			
2669	067051	045	116	045	CMPER2: .ASCIZ /#N#ATOTAL MISMATCHES IN MESSAGE = #D4/
	067054	101	124	117	
	067057	124	101	114	
	067062	040	115	111	
	067065	123	115	101	
	067070	124	103	110	
	067073	105	123	040	
	067076	111	116	040	
	067101	115	105	123	
	067104	123	101	107	
	067107	105	040	075	
	067112	040	045	104	
	067115	064	000		
2670	067117	045	116	045	LGERMS: .ASCIZ /#N#ALENGTH ERROR -- BYTES EXPECTED: #06#A BYTES RECEIVED: #06/
	067122	101	114	105	
	067125	116	107	124	
	067130	110	040	105	
	067133	122	122	117	
	067136	122	040	055	
	067141	055	040	102	
	067144	131	124	105	
	067147	123	040	105	
	067152	130	120	105	
	067155	103	124	105	
	067160	104	072	040	
	067163	045	117	066	
	067166	045	101	040	
	067171	102	131	124	
	067174	105	123	040	
	067177	122	105	103	
	067202	105	111	126	
	067205	105	104	072	
	067210	040	045	117	
	067213	066	000		
2671	067215	045	116	062	SUMMS1: .ASCIZ /#N2#S8#ANODE: #T/
	067220	045	123	070	
	067223	045	101	116	
	067226	117	104	105	
	067231	072	040	045	
	067234	124	000		
2672	067236	045	116	045	SUMMS2: .ASCIZ /#N#ARX NOT COMPLETE RX COMPLETE LENGTH ERRORS/
	067241	101	122	130	
	067244	040	116	117	
	067247	124	040	103	
	067252	117	115	120	
	067255	114	105	124	

	067260	105	040	040	
	067263	040	040	122	
	067266	130	040	103	
	067271	117	115	120	
	067274	114	105	124	
	067277	105	040	040	
	067302	040	040	114	
	067305	105	116	107	
	067310	124	110	040	
	067313	105	122	122	
	067316	117	122	123	
	067321	000			
2673	067322	045	116	045	SUMMS3: .ASCIZ /#N#S6#Z5#S12#Z5#S10#Z5/
	067325	123	066	045	
	067330	132	065	045	
	067333	123	061	062	
	067336	045	132	065	
	067341	045	123	061	
	067344	060	045	132	
	067347	065	000		
2674	067351	045	116	045	SUMMS4: .ASCIZ /#N#ACOMPARE ERRORS BYTES COMPARED BYTES XFER/
	067354	101	103	117	
	067357	115	120	101	
	067362	122	105	040	
	067365	105	122	122	
	067370	117	122	123	
	067373	040	040	040	
	067376	040	102	131	
	067401	124	105	123	
	067404	040	103	117	
	067407	115	120	101	
	067412	122	105	104	
	067415	040	040	040	
	067420	040	102	131	
	067423	124	105	123	
	067426	040	130	106	
	067431	105	122	000	
2675	067434	045	116	045	SUMMS5: .ASCIZ /#N#S6#Z5#S8#T/
	067437	123	066	045	
	067442	132	065	045	
	067445	123	070	045	
	067450	124	000		
2676	067452	045	123	065	SUMMS6: .ASCIZ /#S5#T/
	067455	045	124	000	
2677					.EVEN
2678					
2679					


```

2681          .SBTTL GLOBAL ERROR REPORT SECTION
2682
2683          ;**
2684          ; THE GLOBAL ERROR REPORT SECTION CONTAINS MESSAGE PRINTING AREAS
2685          ; USED BY MORE THAN TEST TO OUTPUT ADDITIONAL ERROR INFORMATION. PRINTB
2686          ; (BASIC) AND PRINTX (EXTENDED) CALLS ARE USED TO CALL PRINT SERVICES.
2687          ;--
2688
2689
2690          BGNMSG ERR1
2691          067460 012737 000020 003672          MOV      #CEXIT,CFLAG          ERR1::
2692          067466          PRINTX  #PCMSG,PCCALL
2693          067466 013746 050564          MOV      PCCALL,-(SP)
2694          067472 012746 066714          MOV      #PCMSG,-(SP)
2695          067476 012746 000002          MOV      #2,-(SP)
2696          067502 010600          MOV      SP,R0
2697          067504 104415          TRAP    C$PNTX
2698          067506 062706 000006          ADD     #6,SP
2699          067512          DOCLN          TRAP    C$DCLN
2700          067512 104444          ENDMSG
2701          067514          L10002: TRAP    C$MSG
2702          067514 104423
2703
2704          BGNMSG ERR2
2705          067516          ERR2::
2706          067516 010146          MOV      R1,-(SP)
2707          067520 013701 002370          MOV      P$TYPE,R1
2708          067524 006301          ASL     R1
2709          067526 062701 003262          ADD     #MSGTAB,R1
2710          067532          PRINTX  #EMSG35,#STRBUF
2711          067532 012746 002322          MOV      #STRBUF,-(SP)
2712          067536 012746 066002          MOV      #EMSG35,-(SP)
2713          067542 012746 000002          MOV      #2,-(SP)
2714          067546 010600          MOV      SP,R0
2715          067550 104415          TRAP    C$PNTX
2716          067552 062706 000006          ADD     #6,SP
2717          067556          PRINTX  #EMSG36,(R1)
2718          067556 011146          MOV      (R1),-(SP)
2719          067560 012746 066037          MOV      #EMSG36,-(SP)
2720          067564 012746 000002          MOV      #2,-(SP)
2721          067570 010600          MOV      SP,R0
2722          067572 104415          TRAP    C$PNTX
2723          067574 062706 000006          ADD     #6,SP
2724          067600 012601          MOV      (SP)+,R1
2725          067602          ENDMSG
2726          067602          L10003: TRAP    C$MSG
2727          067602 104423
2728
2729          BGNMSG ERR3
2730          067604          ERR3::
2731          067604          PRINIX  #EMSG37,#STRBUF
2732          067604 012746 002322          MOV      #STRBUF,-(SP)
2733          067610 012746 066064          MOV      #EMSG37,-(SP)
2734          067614 012746 000002          MOV      #2,-(SP)
2735          067620 010600          MOV      SP,R0
    
```

```

067622 104415
067624 062706 000006
2708 067630
067630 012746 002344
067634 012746 066130
067640 012746 000002
067644 010600
067646 104415
067650 062706 000006
2709 067654
067654 104423

```

PRINTX @EMSG38,@STRBU1

```

TRAP C#PNTX
ADD @6,SP
MOV @STRBU1,-(SP)
MOV @EMSG38,-(SP)
MOV @2,-(SP)
MOV SP,RO
TRAP C#PNTX
ADD @6,SP

```

ENDMSG

L10004:

TRAP C#MSG

```

2710
2712
2713
2714
2715
2716
2717
2718
2719
2720
2721
2722
2723
2724
2726
2727

```

```

:*****
: THESE MESSAGE AREAS ARE USED TO OUTPUT SUPPLEMENTARY INFORMATION
: AFTER AN ERROR CALL. THEY ARE INVOKED BY APPENDING THE NAME
: OF THE AREA TO AN ERROR CALL: ERRXXX 1,ERRORMESSAGE,AREANAME.
: THE CORRESPONDING MESSAGE AREA IS SET UP IN THIS SECTION:
:     BGNMSG AREANAME
:     [CODE]
:     ENDMSG
:
: THE AREAS IN THIS SECTION ARE FOR MESSAGES USED IN MORE THAN ONE
: TEST. USE THE PRINTB (PRINT BASIC) AND PRINTX (PRINT EXTENDED)
: MACROS.
:*****

```

2729
2730
2731
2732
2733
2734
2735
2736
2737
2738
2739
2741
2742
2743
2744
2746
2747
2748
2750
2751
2752
2754
2755
2756
2758
2759
2760
2761
2763
2764
2765
2767
2768
2769
2771
2772
2773
2775
2776
2777
2778
2780
2781
2782
2784
2785
2786
2788
2789
2790
2792
2793
2794
2795
2796
2798
2799

```

.SBTTL GLOBAL SUBROUTINES SECTION

; **
; THE GLOBAL SUBROUTINES SECTION CONTAINS THE SUBROUTINES
; THAT ARE USED IN MORE THAN ONE TEST.
; --

; **
; FUNCTIONAL DESCRIPTION:
; SUBROUTINE TO....

; *****
; COMPLETE THE "SUBROUTINE TO...." STATEMENT WITH A FUNCTIONAL
; DESCRIPTION OF THIS SUBROUTINE.
; *****

; INPUTS:

; *****
; LIST THE INPUT DATA THAT ARE EXPLICITLY PASSED TO THIS SUBROUTINE.
; *****

; IMPLICIT INPUTS:

; *****
; LIST THE INPUT DATA THAT ARE IMPLICITLY USED BY THIS SUBROUTINE;
; FOR EXAMPLE, DATA READ FROM COMMON AREAS.
; *****

; OUTPUTS:

; *****
; LIST THE OUTPUT DATA THAT ARE EXPLICITLY GIVEN BY THIS SUBROUTINE
; *****

; IMPLICIT OUTPUTS:

; *****
; LIST THE OUTPUT DATA THAT ARE IMPLICITLY GIVEN BY THIS SUBROUTINE;
; FOR EXAMPLE, DATA STORED IN COMMON AREAS.
; *****

; SUBORDINATE ROUTINES USED:

; *****
; LIST THE SUBROUTINES CALLED BY THIS SUBROUTINE.
; *****

; FUNCTIONAL SIDE EFFECTS:

; *****
; DESCRIBE ANY EFFECTS THIS SUBROUTINE MAY HAVE UPON OTHER
; MODULES OF THE DIAGNOSTIC PROGRAM. AN EXAMPLE OF THIS IS
; THE SUBROUTINE INHIBITS ALL INTERRUPTS WITH PRIORITY 7.
; *****

; CALLING SEQUENCE:

```


GLOBAL SUBROUTINES SECTION

2800
2802
2803
2804
2805
2806
2807
2809
2810
2812
2813
2814
2815
2817
2819
2820
2821
2823
2824
2825
2826
2827
2828
2829
2830
2831
2832
2833
2834
2835
2836
2837
2838
2839
2840
2841
2842
2843
2844
2845
2846
2847
2848
2849
2850
2851
2852
2853
2854
2855
2856

```

;*****
;   GIVE THE EXACT CALLING SEQUENCE USED TO ACCESS THIS SUBROUTINE.
;   FOR EXAMPLE:   MOV COUNT,R1   ;MOVE INPUT TO R1
;                  JSR   PC,ROUTINE ;GO TO ROUTINE
;                  BCS   ERROR     ;CARRY SET IF ROUTINE HAD ERROR
;*****
;--
;*****
;   INSERT THE CODE FOR THIS SUBROUTINE.  THE NAME OF THE SUBROUTINE SHOULD
;   BE DEFINED WITH A DOUBLE-COLON (::); THIS WILL MAKE THE SUBROUTINE GLOBAL.
;*****
;*****
;   BEGIN EACH SUBROUTINE AT THE TOP OF A NEW PAGE.
;*****
.SBTTL CLKSET  CLOCK SETUP SUBROUTINE

;--*
; FUNCTIONAL DESCRIPTION:
;   THIS SUBROUTINE SETS UP THE CLOCK INFORMATION TABLE FOLLOWING
;   A "CLOCK" CALL EXECUTED IN THE INITIALIZATION CODE.  BUT SINCE
;   THE "CLOCK" CALL SAYS NOTHING ABOUT AN LSI-11'S CLOCK, THE
;   ROUTINE IS ONLY USED IF A LINE OR P-CLOCK IS FOUND.
;
; INPUTS -   R1 - POINTS TO SUPERVISOR SPACE WHERE CLOCK INFO WAS RETURNED
;            R2 - POINTS TO "CLK" TABLE WHERE CLOCK INFO WILL BE KEPT
;
; OUTPUTS -  "CLKCSR" GETS LOADED WITH THE CLOCK'D CSR ADDRESS
;            "CLKBR" GETS LOADED WITH THE CLOCK'S INTERRUPT LEVEL
;            "CLKVEC" GETS LOADED WITH THE CLOCK'S INTERRUPT VECTOR
;            "CLKHZ" GETS LOADED WITH THE LINE FREQ. (IN HERTZ)
;
; CALLING PROCEDURE:
;           JSR   PC,CLKSET   ; CALL CLOCK SETUP WITH R1 AND R2 SETUP
;
;--*
CLKSET:
MOV   (R1)+,(R2)+   ; LOAD CLOCK'S CSR ADDR. INTO "CLKCSR"
MOV   (R1)+,(R2)    ; LOAD CLOCK'S INTR. LEVEL INTO "CLKBR"
ASL   (R2)          ; ADJUST THE INTR. LEVEL FOR LOADING
; INTO THE PSW WITH A "SETVEC" CALL
ASL   (R2)
ASL   (R2)
ASL   (R2)+
MOV   (R1)+,(R2)+   ; LOAD CLOCK'S INTR. VECTOR INTO "CLKVEC"
MOV   (R1)+,(R2)+   ; LOAD CLOCK'S FREQ. INTO "CLKHZ"
RTS   PC

```

067656 012122
067660 012112
067662 006312
067664 006312
067666 006312
067670 006312
067672 006322
067674 012122
067676 012122
067700 000207

```

2858
2859 .SBTTL CLKINT CLOCK INTERRUPT SERVICE ROUTINE
2860
2861 ;---+
2862 ; FUNCTIONAL DESCRIPTION:
2863 ; THIS IS THE CLOCK INTERRUPT SERVICE ROUTINE WHICH TAKES CARE
2864 ; OF KEEPING THE "TIME-SINCE-START" AND COUNTING DOWN ANY OF THE
2865 ; "EVENT" TIMERS. THE TIMERS ARE USED TO TIME COMPLETION OF
2866 ; DEVICE REQUESTS. THE "TIME-SINCE-START" IS USED TO BE LOGGED
2867 ; WITH EACH ENTRY INTO THE EVENT LOG.
2868 ;
2869 ; IMPLICIT INPUTS - TIMTCK - THE CURRENT NO. OF TICKS LEFT TO BE COUNTED UNTIL
2870 ; A SECOND HAS BEEN COUNTED OFF
2871 ; CLKHZ - THE NO. OF TICKS IN A SECOND, DETERMINED BY THE
2872 ; SYS. LINE FREQ.
2873 ; TIMMIN & TIMSEC - CURRENT VALUE OF "TIME-SINCE-START" IN
2874 ; MINUTES AND SECONDS
2875 ; TIMER 1,2 AND S - CURRENT VALUES OF "EVENT TIMERS"
2876 ;
2877 ; IMPLICIT OUTPUTS - NEW VALUE OF EVENT TIMER "1" & "2" DECREMENTED BY 1 TICK
2878 ; IF IT WAS NON-ZERO
2879 ; NEW VALUE OF EVENT TIMER "S" DECREMENTED BY 1 SECOND IF IT
2880 ; WAS NON-ZERO
2881 ;
2882 ; SIDE EFFECTS - THE CLOCK IS DISABLED UPON ENTRY AND REENABLED WHEN LEAVING
2883 ;
2884 ; CALLING PROCEDURE - THIS ROUTINE IS CALLED WHEN THE CLOCK INTERRUPTS THRU
2885 ; "CLKVEC". THE ADDRESS OF THIS ROUTINE WAS LOADED
2886 ; INTO THE CLOCK'S INTERRUPT VECTOR WITH A "SETVEC" CALL
2887 ;
2888 ;---+
2889
2890 067702 BGNSRV CLKINT
2891 067702 CLKINT::
2892 067702 005077 113766 CLR @CLKCSR ; DISABLE THE CLOCK FROM INTERRUPTING
2893 067706 005337 003712 DEC TIMTCK ; DECREMENT THE NO. OF TICKS/SEC
2894 067712 001015 BNE 1$ ; GO CHECK TIMERS
2895 067714 013737 003702 003712 MOV CLKHZ,TIMTCK ; RESET THE NO. OF TICKS/SEC.
2896 067722 005237 003710 INC TIMSEC ; INC. NO OF SECS-SINCE-START
2897 067726 022737 000074 003710 CMP #60.,TIMSEC ; SEE IF WE'VE COUNTED 60 SEC.S YET
2898 067734 001004 BNE 1$ ; IF NOT, GO CHECK TIMERS
2899 067736 005237 003706 INC TIMMIN ; ELSE, INC. MINUTES-SINCE-START
2900 067742 005037 003710 CLR TIMSEC ; AND RESTART SECOND COUNTER
2901
2902 067746 005737 003714 1$: TST TIMER1 ; SEE IF TIMER1 TIMING ANYTHING
2903 067752 001402 BEQ 2$ ; IF=0, NO, CHECK NEXT TIMER
2904 067754 005337 003714 DEC TIMER1 ; ELSE DECREMENT THE TIMER VALUE (BY 1 TICK)
2905 067760 005737 003716 2$: TST TIMER2 ; SEE IF TIMER2 TIMING ANYTHING
2906 067764 001402 BEQ 3$ ; IF=0, NO, CHECK NEXT TIMER
2907 067766 005337 003716 DEC TIMER2 ; ELSE DECREMENT TIMER VALUE (BY 1 TICK)
2908 067772 005737 003720 3$: TST TIMERS ; SEE IF TIMERS TIMING ANYTHING
2909 067776 001406 BEQ 4$ ; IF=0, NOTHING BE TIMED, LEAVE
2910 070000 023737 003702 003712 CMP CLKHZ,TIMTCK ; SEE IF A SECOND HAS BEEN COUNTED OFF
2911 070006 001002 BNE 4$ ; BR IF NO
2912 070010 005337 003720 DEC TIMERS ; ELSE, DECREMENT TIMER VALUE (BY 1 SEC.)
2913 070014 013777 003704 113652 4$: MOV CLKEN,@CLKCSR ; REENABLE THE CLOCK TO INTERRUPT

```

2914 070022
 070022
 070022 000002

ENDSRV

L10005:
 RTI

2915
 2916
 2917
 2918
 2919
 2920
 2921
 2922
 2923
 2924
 2925
 2926
 2927
 2928
 2929
 2930
 2931
 2932
 2933
 2934
 2935
 2936
 2937
 2938
 2939
 2940
 2941
 2942
 2943
 2944
 2945
 2946
 2947
 2948
 2949
 2950
 2951
 2952
 2953
 2954
 2955
 2956
 2957
 2958
 2959
 2960
 2961
 2962

```
.SBTTL PREG14 PRESERVE REGISTERS 1 THROUGH 4 ACROSS SUBROUTINE CALLS
;*****
;INPUTS: THE RELATIVE ADDRESS OF THE CALLED ROUTINE MUST FOLLOW THE
; CALL TO THIS ROUTINE (SEE CALLING SEQUENCE).
;
;OUTPUTS: -REGISTERS 1 THROUGH 4 ARE PRESERVED ACROSS THE CALLED ROUTINE.
; -A CHECK IS MADE TO ENSURE THE HARDWARE STACK HASN'T OVER-RUN
; THE PARAMETER STACK.
;
;CALLING SEQUENCE: THIS IS BEST HANDLED BY THE "CALL" MACRO. THE ACTUAL
; CALL IS:
; JSR R4,PREG14
; .WORD [SUBROUTINE NAME]-ANCHOR
;
;COMMENTS: THIS ROUTINE IS RE-ENTRANT AND RELOCATABLE.
; THIS ROUTINE IS DRS COMPATIBLE.
;
;SUBORDINATE ROUTINES CALLED: THE ROUTINE SPECIFIED IN THE CALL.
;*****
```

```
PREG14: MOV R3,-(SP) ;R4 IS ALREADY ON THE R6 STACK.
; PUSH R3, R2, R1
;
; MOV R2,-(SP)
; MOV R1,-(SP)
;
; MOV R4, PCCALL
; MOV (R4)+,R1 ;GET THE RELATIVE ADDRESS OF THE CALLED
; ROUTINE.
; ADD PC,R1 ;MAKE IT AN ABSOLUTE ADDRESS.
ANCHOR: MOV R4,-(SP) ;SAVE THE RETURN TO THE CALLING ROUTINE.
;
; CMP R5,SP ;CHECK FOR STACK OVER-RUN.
; BLO 1$ ;
; HALT ;HANDLE STACK OVER-RUN CONDITION.
1$: JSR PC,(R1) ;CALL THE SPECIFIED ROUTINE.
;
; MOV (SP)+,R4 ;RESTORE THE RETURN TO THE CALLING ROUTINE.
;
; MOV (SP)+,R1 ;RESTORE THE REGISTERS.
; MOV (SP)+,R2
; MOV (SP)+,R3
; RTS R4 ;BACK TO THE CALLING ROUTINE.
```

050564


```

2964
2965      .SBTTL  WAIT      WAIT FOR DEUNA INTERRUPT WITH TIMEOUT
2966
2967      ;**
2968      ; FUNCTIONAL DESCRIPTION:
2969      ;       THIS SUBROUTINE WAITS FOR DNI INTERRUPTS FROM THE DEUNA
2970      ;       OR REPORTS A TIMEOUT.  IF A UNA INTERRUPT HAS OCCURED,
2971      ;       THE SUBROUTINE ERROR IS CALLED TO HANDLE IT.
2972      ;
2973      ;       SUCCESS OR FAILURE IS REPORTED VIA P1.
2974      ;
2975      ; INPUTS -
2976      ;       NONE
2977      ;
2978      ; OUTPUTS-
2979      ;       P1:      SUCCESS/FAILURE      0=SUCCESS/-1=FAILURE
2980      ;
2981      ; CALLING SEQUENCE:
2982      ;       CALL      WAIT
2983      ;       P$POP     P1
2984      ;--
2985
2986 070066 012703 000012 WAIT::  MOV      #10.,R3      ; MOVE NO. OF COUNTS TO R3
2987 070072 012704 003714      MOV      #TIMER1,R4     ; AND TIMER TO BE USED TO R4
2988 070076 005002      CLR      R2             ; LOCAL STATUS PARAMETER
2989 070100 010314      MOV      R3,(R4)        ; SET NUMBER OF TICKS. (GLOBAL)
2990 070102 005737 050530 1$:   TST      ERRFLG        ; CHECK IF ERROR OCCURED
2991 070106 001011      BNE      3$            ; BR IF YES
2992 070110 005737 050522      TST      DNIFLG        ; CHECK FOR DNI INTERRUPT
2993 070114 001403      BEQ      2$            ; BR IF INTERRUPT RECEIVED
2994 070116 005037 050522      CLR      DNIFLG
2995 070122 000410      BR      6$
2996 070124 005714 2$:   TST      (R4)          ; HAS TIMER EXPIRED?
2997 070126 001365      BNE      1$            ; BR IF NO TO WAIT FOR INTERRUPT
2998 070130 000403      BR      5$            ; BR TO 5$
2999 070132 3$:   CALL      ERROR        ; CALL ERROR ROUTINE
3000 070140 012702 177777 5$:   MOV      #-1,R2        ; INDICATE FAILURE
3001 070144 6$:   RETURN   R2          ; RETURN WITH SUCCESS/FAILURE INDICATION
3002
3003      .SBTTL  ERROR      HANDLE UNA INTERRUPT ERRORS
3004
3005      ;--*
3006      ; FUNCTIONAL DESCRIPTION:
3007      ;       THIS SUBROUTINE CHECKS THE ERROR FLAGS SET BY
3008      ;       UNAI SR THE INTERRUPT SERVICE ROUTINE AND PRINTS
3009      ;       OUT THE APPROPRIATE ERROR MESSAGES.
3010      ;
3011      ; INPUTS -
3012      ;   IMPLICIT:  ERROR FLAGS SHOULD BE SET BY UNAI SR ROUTINES.
3013      ; OUTPUTS -
3014      ;   IMPLICIT:  ERROR MESSAGES ARE PRINTED OUT TO THE OPERATOR CONSOLE.
3015      ;
3016      ; CALLING SEQUENCE:
3017      ;       CALL      ERROR
3018      ;
3019      ;--*
3020

```

```

3021 070150 005337 050530      ERROR:: DEC      ERRFLG      ;DECREDIT ERROR COUNTER TO SHOW
3022                                ;THAT IT HAS BEEN HANDLED
3023 070154 005737 050514      TST      PCEFLG      ;SEE IF PORT COMMAND ERROR
3024 070160 001013              BNE      5$          ; IF YES, BRANCH
3025 070162 005737 050512      TST      FATFLG      ;SEE IF UNA FATAL ERROR
3026 070166 001017              BNE      10$         ; IF YES, BRANCH
3027 070170 005737 050526      TST      BCOUNT     ;SEE IF UNEXPLAINED INTERRUPT
3028 070174 001023              BNE      15$         ; IF YES, BRANCH
3029 070176              ERRDF      4,EMSG04,ERR1 ;ELSE UNKNOWN ERROR
                                TRAP      C$ERDF
                                .WORD      4
                                .WORD      EMSG04
                                .WORD      ERR1
3030 070206 000424              BR        20$
3031 070210 5$:              ERRDF      1,EMSG01,ERR1 ; EXIT
                                ;PORT COMMAND ERROR
                                TRAP      C$ERDF
                                .WORD      1
                                .WORD      EMSG01
                                .WORD      ERR1
3032 070220 005337 050514      DEC      PCEFLG      ; INDICATE THAT IT WAS HANDLED
3033 070224 000415              BR        20$
3034 070226 10$:              ERRDF      2,EMSG02,ERR1 ; EXIT
                                ;UNA FATAL ERROR
                                TRAP      C$ERDF
                                .WORD      2
                                .WORD      EMSG02
                                .WORD      ERR1
3035 070236 005337 050512      DEC      FATFLG      ; KEEP UP ON BOOK KEEPING
3036 070242 000406              BR        20$
3037 070244 15$:              ERRDF      3,EMSG03,ERR1 ; EXIT
                                ;UNEXPLAINED INTERRUPT
                                TRAP      C$ERDF
                                .WORD      3
                                .WORD      EMSG03
                                .WORD      ERR1
3038 070254 005337 050526      DEC      BCOUNT     ; BOOK KEEPING
3039 070260              RETURN      ;RETURN

```

.SBTTL UNAINI INITIALIZE THE UNA

```

3040
3041
3042
3043
3044
3045 ;*****
3046 ;
3047 ; SUBROUTINE TO
3048 ;           1) SETS UNA IN THE READY STATE
3049 ;           2) INITIALIZES ALL UNA GLOBAL DATA LOCATIONS
3050 ;           TO DEFAULT VALUES.
3051 ;
3052 ; CALLED BY:
3053 ;           CALL UNAINI
3054 ;
3055 ; INPUTS:
3056 ;           NONE
3057 ;
3058 ; OUTPUTS:
3059 ;           NONE
3060 ;
3061 ; SIDEEFFECTS: ALL GLOBAL LOCATIONS ARE ZEROED
3062 ;*****

```

```

3062
3063
3064 ;*****;
3065 ; RESET AND STOP UNA HARDWARE ;
3066 ;*****;
3067
3068 UNAINI: MOV PCSRO, R3 ; MOVE ADDRESS OF PCSRO TO R3
3069 070262 013703 047632 MOV #RSET, (R3) ; HARDWARE RESET UNA
3070
3071 070272 005002 CLR R2 ; LOOP COUNTER INIT
3072 070274 011301 7#: MOV (R3), R1 ; READ PCSRO
3073 070276 032701 004000 BIT #DNI, R1 ; WAIT FOR COMMAND TO FINISH
3074 070302 001006 BNE 9# ; BACK TIL DNI =1
3075 070304 005302 DEC R2 ; COUNT DOWN DELAY
3076 070306 001372 BNE 7# ; BACK UNTIL TIMEOUT
3077 070310 ERRDF 15,MSG15,ERR1 ; PRINT " DNI DID NOT SET FROM"
; TRAP C#ERDF
; .WORD 15
; .WORD MSG15
; .WORD ERR1
3078 ; " A RESET"
3079
3080 070320 012713 004000 9#: MOV #DNI, (R3) ; WRITE ONE TO CLEAR DNI
3081
3082 ;*****;
3083 ; NOW ENABLE INTERRUPTS FOR THE ALL ;
3084 ; PORT COMMANDS ET AL ;
3085 ;*****;
3086
3087 070324 112713 000100 MOVB #INTE, (R3) ; ENABLE INTERRUPTS
3088
3089 ;*****;
3090 ; LOAD ADDRESS OF PCBB ;
3091 ;*****;
3092
3093 070330 012763 047666 000004 MOV #PCBB0,4(R3) ; LOWER 16 BITS OF ADRS
3094 070336 005063 000006 CLR 6(R3) ; UPPER 2
3095
3096 070342 CALL COMAND #GETPCB ; LOAD ADDRESS
3097 070354 P#POP R2 ; GET SUCCESS/FAILURE REPORT
3098 070356 001404 BEQ 10# ; CONTINUE IF OK
3099 070360 ERRDF 5,MSG05,ERR1 ; ELSE REPORT ERROR
; TRAP C#ERDF
; .WORD 5
; .WORD MSG05
; .WORD ERR1
3100
3101
3102 070370 10#: ;*****;
3103 ; INIT GLOBAL DATA ;
3104 070370 005037 047642 CLR PCSROC ; INIT CONTENTS OF CUR PCSRO
3105 070374 005037 047644 CLR PCSR1C ; PCSR1
3106 070400 005037 047646 CLR PCSR2C ; PCSR2
3107 070404 005037 047650 CLR PCSR3C ; PCSR3
3108
3109 ;*****;
3110 ; INIT RING POINTERS AND ;

```



```

3111                                     ; RING ENTRIES ;
3112                                     ;*****;
3113                                     ;*****;
3114 070410 012737 003772 003756      MOV  #XRING,XRGCUR      ; SET POINTERS TO BEGINING OF RING
3115 070416 012737 003772 003762      MOV  #XRING,XRGNXT
3116 070424 012737 004066 003760      MOV  #RRING,RRGCUR
3117 070432 012737 004066 003764      MOV  #RRING,RRGNXT
3118
3119 070440 012702 000006                MOV  #NO.NTR,2          ; RESET OWNERSHIP AND STATUS OF
3120 070444 013701 003756                MOV  XRGCUR            ; RING ENTRIES
3121 070450 012761 000000 000004 12$:  MOV  #0,4(R1)          ; FOR TRANSMIT RING...
3122 070456                                CALL GETXNX,XRGCUR
3123 070470 005302                                DEC  R2
3124 070472 001364                                BNE  12$
3125
3126 070474 012702 000006                MOV  #NO.NTR,R2        ; ...AND RECIEVE RING
3127 070500 013701 003760                MOV  RRGCUR,R1
3128 070504 012761 100000 000004 13$:  MOV  #100000,4(R1)
3129 070512                                CALL GETRXN,RRGCUR
3130 070524 005302                                DEC  R2
3131 070526 001364                                BNE  13$
3132
3133                                     ;*****;
3134                                     ; CLEAR UP ALL PCB AND UCB, ;
3135                                     ; SET BACK TO DEFAULT VALUES ;
3136                                     ;*****;
3137
3138
3139 070530 012701 047750                MOV  #RDDE,R1          ; READ DEF PHY ADDR PCB
3140 070534 005061 000002                CLR  2(R1)
3141 070540 005061 000004                CLR  4(R1)
3142 070544 005061 000006                CLR  6(R1)
3143
3144 070550 012701 047760                MOV  #RDPH,R1          ; READ CURRENT PHY ADDR PCB
3145 070554 005061 000002                CLR  2(R1)
3146 070560 005061 000004                CLR  4(R1)
3147 070564 005061 000006                CLR  6(R1)
3148
3149 070570 012701 047770                MOV  #WDPH,R1          ; WRITE CURRENT PHY ADDR PCB
3150 070574 005061 000002                CLR  2(R1)
3151 070600 005061 000004                CLR  4(R1)
3152 070604 005061 000006                CLR  6(R1)
3153
3154 070610 012701 050100                MOV  #RDRN,R1          ; READ RING FORMAT
3155 070614 005061 000004                CLR  4(R1)
3156 070620 005061 000006                CLR  6(R1)
3157
3158 070624 012701 050110                MOV  #UCB10,R1         ; RING ENTRIES:
3159 000006                                .REPT 6                ; INIT TO 0
3160                                CLR  (R1)+
3161                                .ENDR
3162
3163 070644 012701 050124                MOV  #WDRN,R1          ; WRITE RING FORMAT
3164 070650 005061 000004                CLR  4(R1)
3165 070654 005061 000006                CLR  6(R1)
3166
3167 070660 012701 050150                MOV  #RDCN,R1          ; READ COUNTERS

```

```

3168 070664 005061 000004      CLR      4(R1)
3169
3170 070670 012701 050160      MOV      #UCB12, R1      ; COUNTER ENTRIES
3171 070674 012702 000040      MOV      #40, R2
3172 070700 005021      14$:    CLR      (R1)+
3173 070702 005302      DEC      R2
3174 070704 001375      BNE     14$
3175
3176 070706 012701 050260      MOV      #CLRC, R1      ; CLEAR COUNTERS
3177 070712 005061 000004      CLR      4(R1)
3178
3179 070716 012701 050270      MOV      #RDMO, R1      ; READ MODE
3180 070722 005061 000002      CLR      2(R1)
3181 070726 005061 000004      CLR      4(R1)
3182 070732 005061 000006      CLR      6(R1)
3183
3184 070736 012701 050300      MOV      #WDMO, R1      ; WRITE MODE
3185 070742 005061 000002      CLR      2(R1)
3186 070746 005061 000004      CLR      4(R1)
3187 070752 005061 000006      CLR      6(R1)
3188
3189 070756 012701 050310      MOV      #RDST, R1      ; READ STATUS
3190 070762 005061 000002      CLR      2(R1)
3191 070766 005061 000004      CLR      4(R1)
3192 070772 005061 000006      CLR      6(R1)
3193
3194 070776 012701 050320      MOV      #CLRS, R1      ; READ AND CLEAR STATUS
3195 071002 005061 000002      CLR      2(R1)
3196 071006 005061 000004      CLR      4(R1)
3197 071012 005061 000006      CLR      6(R1)
3198
3199 071016 005037 050516      CLR      NIRCNT      ; CLEAR BUFFERS RECEIVED COUNTER
3200 071022      CALL     FUNCT #WDRNGS ; WRITE DESCRIPTOR RINGS
3201 071034      P$POP   R2           ; CHECK FOR ERROR
3202 071036 001404      BEQ     15$         ; IF OK, CONTINUE
3203 071040      ERRDF  16,EMSG16,ERR1 ; ELSE REPORT ERROR
3204      071040 104455      TRAP   C$ERDF
3205      071042 000020      .WORD 16
3206      071044 065064      .WORD MSG16
3207      071046 067460      .WORD ERR1
3208
3205 071050      15$:    CALL     COMAND #STRT ; PUT UNA IN RUNNING STATE
3206 071062      P$POP   R2           ; CHECK FOR ERROR
3207 071064 001404      BEQ     20$         ; IF OK, CONTINUE
3208 071066      ERRDF  7,EMSG07,ERR1 ; ELSE REPORT ERROR
3209      071066 104455      TRAP   C$ERDF
3210      071070 000007      .WORD 7
3211      071072 064510      .WORD MSG07
3212      071074 067460      .WORD ERR1
3213
3210 071076      20$:    CALL     FUNCT #RDPHYA ; READ UNA PHYSICAL ADDRESS
3211 071110      P$POP   R2           ; CHECK FOR ERROR
3212 071112 001404      BEQ     25$         ; IF OK, CONTINUE
3213 071114      ERRDF  6,EMSG06,ERR1 ; ELSE, REPORT ERROR
3214      071114 104455      TRAP   C$ERDF
3215      071116 000006      .WORD 6
3216      071120 064450      .WORD MSG06
  
```

```

071122 067460 .WORD ERR1
3214
3215 071124 012701 047670 25$: MOV #PCBB2, R1 ; STORE PHYSICAL ADDRESS
3216 071130 012704 047762 MOV #PHYADR, R4
3217 071134 012124 MOV (R1)+, (R4)+ ; MOVE FIRST TWO BYTES
3218 071136 012124 MOV (R1)+, (R4)+ ; AND SECOND TWO
3219 071140 011114 MOV (R1), (R4) ; AND DONE
3220
3221 071142 RETURN
3222
3223 .SBTTL UNAIISR UNA INTERRUPT SERVICE ROUTINE
3224 ;+
3225 ; THIS INTERRUPT ROUTINE WILL BE THE ONLY INTERRUPT ROUTINE
3226 ; WHICH THE UNA HARDWARE WILL VECTOR TO UPON HARDWARE INTERRUPT.
3227 ;
3228 ; THE REASON FOR SUCH INTERRUPTS ARE TO BE DETERMINED
3229 ; FROM THE APPROPRIATE BITS IN THE PCSRO.
3230 ;
3231 ; IN ADDITION ALL WRITE ONE TO CLEAR BITS OF THE PCSRO
3232 ; ARE CLEARED FROM THIS ROUTINE.
3233 ;-
3234
3235 071144 UNAIISR::
3236 071144 010146 MOV R1, -(SP) ;SAVE R1
3237 071146 010246 MOV R2, -(SP) ;...
3238 071150 010346 MOV R3, -(SP) ;...
3239
3240 071152 005003 CLR R3 ;SETUP WRITE 1 TO CLR MASK
3241 071154 013701 047632 MOV PCSRO, R1 ;GET PCSRO ADDRESS
3242
3243 071160 011103 MOV (R1), R3 ;AND ITS CONTENTS
3244
3245 071162 012137 047642 MOV (R1)+, PCSROC ;SAVE PCSR'S FOR DEBUG
3246 071166 012137 047644 MOV (R1)+, PCSR1C
3247 071172 012137 047646 MOV (R1)+, PCSR2C
3248 071176 011137 047650 MOV (R1), PCSR3C
3249 071202 013701 047632 MOV PCSRO, R1
3250
3251 071206 000303 SWAB R3 ;REORIENT CONTENTS OF PCSRO
3252 071210 110361 000001 MOVB R3, 1(R1) ;WRITE ONE TO CLEAR
3253 ; ONLY CLEAR UPPER BYTE
3254 071214 000303 SWAB R3 ;REORIENT CONTENTS OF PCSRO
3255
3256
3257 071216 032703 100400 BIT #SERI!FATI, R3 ;ANY FATAL STATUS ??
3258 071222 001403 BEQ 10$
3259
3260 071224 005237 050512 INC FATFLG ;SET FLAG
3261 071230 000443 BR 90$ ;EXIT
3262
3263 071232 032703 040000 10$: BIT #PCEI, R3 ;PORT COMMAND ERROR INTERRUPT?
3264 071236 001402 BEQ 20$ ;NO
3265
3266 071240 005237 050514 INC PCEFLG ;YES, INCREMENT FLAG
3267
3268 071244 032703 020000 20$: BIT #RXI, R3 ;RECV INTERRUPT ??
3269 071250 001402 BEQ 30$ ;NO

```



```

3270 071252 005237 050516          INC      NIRCNT          ;YES, SET FLAG
3271                                     ;
3272 071256 032703 010000          30$:    BIT      #TXI,R3      ;TRANSMIT INTERRUPT ??
3273 071262 001402                   BEQ      40$                ;NO
3274 071264 005037 050520          CLR      XFLAG           ;YES, SET FLAG
3275                                     ;
3276 071270 032703 004000          40$:    BIT      #DNI,R3      ;COMMAND DONE ??
3277 071274 001402                   BEQ      45$                ;NO
3278 071276 005237 050522          INC      DNIFLG          ;YES, COUNT EACH DNI
3279                                     ;
3280 071302 032703 002000          45$:    BIT      #RCBI,R3     ;RECIEVE BUFFER UNAVAILABLE?
3281 071306 001402                   BEQ      50$                ;NO
3282 071310 005237 050524          INC      RBFCNT          ; COUNT THEM
3283                                     ;
3284 071314 032703 034000          50$:    BIT      #RXI!TXI!DNI,R3 ;CHECK FOR NON-ERROR INTERRUPT
3285 071320 001007                   BNE      90$                ;EXIT IF ONE OCCURED
3286 071322 032703 142000          BIT      #SERI!PCEI!RCBI,R3 ;CHECK FOR ERROR INTERRUPT
3287 071326 001002                   BNE      80$                ;IF ONE OCCURED, INCR. ERRFLG
3288 071330 005237 050526          INC      BCOUNT          ;ELSE, NONSENSE INTERRUPT
3289 071334 005237 050530          80$:    INC      ERRFLG
3290 071340 012603          90$:    MOV      (SP)+,R3     ;RESTORE REGISTERS
3291 071342 012602          MOV      (SP)+,R2     ;RESTORE REGISTERS
3292 071344 012601          MOV      (SP)+,R1     ;RESTORE REGISTERS
3293 071346 000002          RTI                    ;AUF WIEDERSEHEN
3294
3295
3296
3297
3298
3299
3300
3301
3302
3303
3304
3305
3306
3307
3308
3309
3310
3311
3312
3313
3314
3315
3316
3317
3318
3319
3320
3321
3322
3323
3324
3325
3326

```

```

.SBTTL  COMAND  SUBR TO ISSUE A UNA PORT COMMAND

```

```

;---+
; FUNCTIONAL DESCRIPTION
; THIS SUBROUTINE ISSUES A UNA PORT COMMAND.  ERRORS
; ARE HANDLED BY THE SUBROUTINE ERROR AND REPORTED IN
; P2 IF ONE OCCURED.
;
; INPUTS -      P1 - THE UNA PORT COMMAND MNEMONIC OF THE
;                DESIRED COMMAND.
; OUTPUTS -     P2 - SUCCESS REPORT.  CONTAINS 0 FOR SUCCESS
;                -1 IF A UNA ERROR OCCURED.  THIS PARAMETER
;                IS PASSED DIRECTLY FROM THE WAIT
;                ROUTINE AND IS UNTOUCHED BY COMAND.
;
; CALLING PROCEDURE - CALL  COMAND #<COMMAND TYPE>
; SIDE EFFECTS - IF AN ERROR HAS OCCURED, THE ROUTINE ERROR WILL
;                BE CALLED.
; REGISTER USAGE - R1 CONTAINS THE COMMAND TYPE.
;
;---+

```

```

COMAND::
          P$POP      R1          ;MOVE COMMAND TYPE TO R1
          BIS        #INTE,R1   ;ADD INTERRUPT TO COMMAND
          MOV        R1,@PCSRO  ;MOV COMMAND TO PCSRO
          CALL      WAIT        ;WAIT FOR DONE INTERRUPT
10$:     RETURN              ;RETURN - ERROR INFO STILL ON
          ; PARAMETER STACK FROM WAIT SUB.

```

```

3327 .SBTTL FUNCT SUBR TO PERFORM A UNA PORT FUNCTION
3328
3329
3330 :--*
3331 ; FUNCTIONAL DESCRIPTION:
3332 ; THIS SUBROUTINE PERFORMS A UNA PORT FUNCTION. THE
3333 ; FUNCTION SPECIFIC PCB IS MOVED INTO THE UNA PCB.
3334 ;
3335 ; INPUTS - P1 - THE UNA PORT FUNCTION MNEMONIC OF THE
3336 ; DESIRED FUNCTION.
3337 ; OUTPUTS - P2 - SUCCESS REPORT. CONTAINS 0 FOR SUCCESS
3338 ; -1 IF A UNA ERROR OCCURED.
3339 ; THIS PARAMETERIS PASSED DIRECTLY FROM THE
3340 ; COMAND SUB AND IS NOT AFFECTED BY FUNCT.
3341 ;
3342 ; CALLING PROCEDURE - CALL FUNCT #<FUNCTION TYPE>
3343 ; SIDE EFFECTS - IF AN ERROR HAS OCCURED, THE ROUTINE ERROR WILL
3344 ; BE CALLED.
3345 ; REGISTER USAGE - R1 CONTAINS THE FUNCTION TYPE, WHICH IS TRANSFORMED
3346 ; TO THE ADDRESS OF THE FUNCTION SPECIFIC PCB.
3347 ; R2 CONTAINS THE ADDRESS OF THE UNA PCB.
3348 ;
3349 :--*
3350
3351 071372 FUNCT:: P$POP R1 ; GET FUNCTION TYPE INTO R1
3352 071374 006301 ASL R1 ; MULTIPLY BY TWO
3353 071376 062701 047676 ADD #FUNTAB,R1 ; ADD FUNCTION TABLE OFFSET
3354 ; R1 NOW CONTAINS ADDRESS OF ADDRESS
3355 ; OF FUNCTION SPECIFIC PCB
3356 071402 012702 047666 MOV #PCB80, R2 ; PUT UNA PCB INTO R2
3357 071406 011101 MOV (R1),R1 ; PUT ADDRESS OF PCB INTO R1
3358 071410 012122 MOV (R1)+,(R2)+ ; MOV PCB'S
3359 071412 012122 MOV (R1)+,(R2)+ ; MOV PCB'S
3360 071414 012122 MOV (R1)+,(R2)+ ; MOV PCB'S
3361 071416 012122 MOV (R1)+,(R2)+ ; MOV PCB'S
3362 071420 CALL COMAND #GETFNT ; ISSUE GET PORT FUNCTION COMMAND
3363 071432 RETURN ; SUCCESS INFO FROM COMAND SUBROUTINE
3364 ; IS STILL ON PARAMETER STACK
3365
3366 .SBTTL XMIT TRANSMIT UNA PACKETS
3367
3368 :--*
3369 ; FUNCTIONAL DESCRIPTION:
3370 ; THIS SUBROUTINE SETS UP THE TRANSMIT DESCRIPTOR
3371 ; RING ENTRIES AND ISSUES A POLL DEMAND COMMAND TO
3372 ; THE UNA.
3373 ;
3374 ; INPUTS - NONE
3375 ;
3376 ; OUTPUTS - P1 - SUCCESS REPORT. 0 FOR SUCCESS, -1 FOR FAILURE
3377 ;
3378 ; CALL PROCEDURE - CALL XMIT
3379 ; P$POP P1
3380 ;
3381 ; SIDE EFFECTS - THE RING POINTER XRGNT WILL BE UPDATED TO POINT THE NEXT
3382 ; AVAILABLE ENTRY AFTER THE TRANSMIT OPERATION.
3383 ;

```

```

3384 ; REGISTER USAGE - R1 POINTS TO TIMEOUT TIMER LOCATION
3385 ;
3386 ; R2 IS USED AS A POINTER IF RETRYS IS SET
3387 ; R3 IS USED TO PASS THE SUCCESS/FAILURE MESSAGE BACK
3388 ; R4 IS USED AS A POINTER TO RING ENTRIES OR STATUS INFO.
3389 ;---
3390 071434 005037 050534 XMIT:: CLR RETRYS
3391 071440 013704 003756 19: MOV XRGCUR,R4 ; MOVE RING ENTRY LOCATION INTO R4
3392 071444 032764 100000 000004 BIT @OWN,4(R4) ; MAKE SURE WE OWN THIS
3393 071452 001125 BNE 40$ ; ELSE, BOOKKEEPING ERROR
3394 071454 013714 050566 MOV BUFLN,(R4) ; MOVE BUFFER LENGTH INTO FIRST WORD OF
3395 ; NEXT AVAILABLE RING ENTRY
3396 071460 052764 101400 000004 BIS @OWN!STP!ENP,4(R4) ; SET OWNERSHIP, START AND END OF PACKET BITS
3397 071466 012737 000001 050520 20$: MOV @1,XFLAG ; SET TRANSMIT FLAG
3398 071474 CALL COMAND @PDM ; ISSUE PDM COMMAND
3399 071506 P$POP R3 ; CHECK FOR ERRORS
3400 071510 001126 BNE 50$ ; IF YES, EXIT
3401 071512 012701 003716 22$: MOV @TIMER2,R1 ; SET UP TO WAIT FOR TRANSMIT TO COMPLETE
3402 071516 012711 000100 MOV @100,(R1)
3403 071522 005737 050520 23$: TST XFLAG ; SEE IF TRANSMIT DONE BIT SET
3404 071526 001403 BEQ 24$ ; IF SET, SKIP WAIT LOOP
3405 071530 005711 TST (R1) ; ELSE, SEE IF TIMEOUT YET
3406 071532 001373 BNE 23$ ; NO, WAIT
3407 071534 000506 BR 45$ ; YES, EXIT
3408 071536 032764 100000 000004 24$: BIT @OWN,4(R4) ; SEE WHO OWNS THIS ENTRY
3409 071544 001070 BNE 40$ ; IF UNA STILL OWNS THIS, SOMETHINGS WRONG
3410 071546 032764 040000 000004 BIT @ERRS,4(R4) ; SEE IF ANY ERRORS
3411 071554 001013 BNE 30$ ; IF YES, BRANCH AND TAKE CARE OF THEM
3412 071556 26$: CALL GETXNX @XRGCUR ; UPDATE "TRANSMIT RING CURRENT" POINTER
3413 071570 005003 CLR R3 ; INDICATE SUCCESS
3414 071572 023737 003756 003762 CMP XRGCUR,XRGNXT ; SEE IF CURRENT POINTER = NEXT POINTER
3415 071600 001057 BNE 42$ ; IF NO, ERROR
3416 071602 000473 BR 55$ ; RETURN
3417 071604 032764 016000 000004 30$: BIT @DEF!ONE!MORE,4(R4) ; WAS MESSAGE STILL SENT?
3418 071612 001361 BNE 26$ ; IF YES, GO TO NEXT ONE
3419 071614 032764 002000 000006 BIT @RTRY,6(R4) ; ELSE, DID UNA GIVE UP AFTER 16 TRIES
3420 071622 001434 BEQ 32$ ; IF NOT, FATAL DEVICE ERROR, EXIT
3421 071624 005237 050534 INC RETRYS ; IF YES, KEEP COUNT OF THEM
3422 071630 022737 000003 050534 CMP @3,RETRYS ; GIVE UP AFTER 3 TIMES
3423 071636 100747 BMI 26$ ; ELSE, SET UP TO RETRANSMIT
3424 071640 CALL GETXNX @XRGCUR ; UPDATE POINTERS
3425 071652 CALL GETXNX @XRGNXT ;
3426 071664 016402 000002 MOV 2(R4),R2 ; SET UP TO COPY DATA BUFFER
3427 071670 013704 003756 MOV XRGCUR,R4 ; R2 POINTS TO OLD BUFFER
3428 071674 016403 000002 MOV 2(R4),R3 ; R3 POINTS TO NEW BUFFER
3429 071700 013704 050566 MOV BUFLN,R4 ; R4 COUNTS NUMBER OF BYTES TO COPY
3430 071704 112223 31$: MOVB (R2),(R3) ; COPY DATA
3431 071706 005304 DEC R4
3432 071710 001375 BNE 31$ ; HAVE WE COPIED ALL OF IT
3433 071712 000652 BR 1$ ; IF YES, TRY AGAIN
3434 071714 32$: ERRDF 9,MSG09,ERR1 ; ELSE, FATAL DEVICE ERROR
; TRAP C$ERDF
; .WORD 9
; .WORD MSG09
; .WORD ERR1
3435 071724 000420 BR 50$ ; EXIT
3436 071726 40$: ERRDF 10,MSG10,ERR1 ; TRANSMIT RING BOOKKEEPING ERROR

```



```

071726 104455
071730 000012
071732 064656
071734 067460
3437 071736 000413
3438 071740 42: BR 50:
ERRDF 12,EMSG10,ERR1 ; BOOKKEEPING ERROR, XRGXNT SHOULD = XRGCUR
071740 104455 TRAP C1ERDF
071742 000014 .WORD 10
071744 064656 .WORD EMSG10
071746 067460 .WORD ERR1
3439 071750 000406
3440 071752 005237 050532 45: BR 50:
INC TIMEOUT
ERRHRD 8,EMSG08,ERR1 ; REPORT ERROR
071756 104456 TRAP C1ERHRD
071760 000010 .WORD 8
071762 064553 .WORD EMSG08
071764 067460 .WORD ERR1
3442 071766 012703 177777 50: MOV 0-1,R3 ; ERROR INDICATOR
3443 071772 55: RETURN R3 ; RETURN
3444
3445 .SBTTL RECEVE RECEIVE UNA RING BUFFERS
3446
3447
3448 ; ---
3449 ; FUNCTIONAL DESCRIPTION
3450 ; THIS SUBROUTINE TAKES INCOMING DATA BUFFERS FROM
3451 ; THE UNA AND CHECKS FOR ERRORS. THIS PROCESS CONTINUES
3452 ; FOR ALL PENDING BUFFERS.
3453 ;
3454 ; INPUTS - NONE
3455 ; OUTPUTS - P1 - THE NUMBER OF PACKETS HANDLED BY THIS CALL TO RECEVE
3456 ;
3457 ; CALLING PROCEDURE - CALL RECEVE
3458 ; P1POP P1
3459 ;
3460 ; SIDE EFFECTS - THE POINTERS RRGCUR AND RRGXNT ARE UPDATED.
3461 ;
3462 ; REGISTER USAGE - R1 IS USED TO HOLD CURRENT PACKET STATUS INFORMATION
3463 ; R2 COUNTS THE NUMBER OF PACKETS HANDLED
3464 ; R4 POINTS TO THE RING DESCRIPTOR ENTRY
3465 ; ---
3466
3467 071776 RECEVE::
3468 071776 005002 CLR R2 ; CLEAR PACKETS HANDLED COUNTER
3469 072000 005737 050516 1: TST NIRCNT ; SEE IF ANY PACKETS TO RECEIVE
3470 072004 001476 BEQ 60: ; IF NO, EXIT
3471 072006 013704 003760 MOV RRGCUR,R4 ; MOVE CURRENT RECEIVE RING POINTER TO R4
3472 072012 016401 000004 MOV 4(R4),R1 ; MOVE STATUS OF PACKET TO R1
3473 072016 012764 100000 000004 MOV 0100000,4(R4) ; RESET RING DESCRIPTOR
3474 072024 032701 100000 BIT 0OWN,R1 ; SEE WHO OWNS THIS BUFFER
3475 072030 001060 BNE 45: ; IF STILL OWNED BY UNA, ERROR
3476 072032 016403 000002 MOV 2(R4),R3 ; MOVE BUFFER ADDRESS INTO R3
3477 072036 016303 000014 MOV PROT0(R3),R3 ; MOVE PROTOTYPE INTO R3
3478 072042 020337 050544 CMP R3,PROT00 ; SEE IF IT IS AN ACCEPTABLE PROTOCOL TYPE
3479 072046 001420 BEQ 10: ; IF YES, CONT.
3480 072050 020337 050546 CMP R3,PROT02 ; ELSE CHECK OTHER GOOD TYPE
3481 072054 001415 BEQ 10: ; IF OK, CONT.

```

```

RECEIVE RECEIVE UNA RING BUFFERS
3482 072056          5$:  CALL  GETRNX  @RRGCR
3483 072070          CALL  GETRNX  @RRGNXT
3484 072102 005337 050516  DEC  NIRCNT
3485 072106 000435          BR   60$
3486 072110 032701 040000 10$:  BIT   @ERRS,R1
3487 072114 001413          BEQ  20$
3488 072116 005237 050536  INC  RCVERR
3489 072122          PRINTF @RECERR
          072122 012746 052631          MOV  @RECERR,-(SP)
          072126 012746 000001          MOV  @1,-(SP)
          072132 010600          MOV  SP,R0
          072134 104417          TRAP C$PNTF
          072136 062706 000004          ADD  @4,SP
3490 072142 000745          BR   5$
3491 072144 005237 050540 20$:  INC  RCVBUF
3492 072150 005202          INC  R2
3493 072152 005337 050516 25$:  DEC  NIRCNT
3494 072156          CALL  GETRNX  @RRGCR
3495 072170 000404          BR   60$
3496 072172          ERRDF 11,MSG11,ERR1
          072172 104455          ; RECEIVE RING BOOKKEEPING ERROR
          072174 000013          TRAP C$ERDF
          072176 064716          .WORD 11
          072200 067460          .WORD MSG11
          072202          .WORD ERR1
3497 072202          60$:  RETURN R2
3498
3499
; ELSE, THROW OUT AND UPDATE
; CURRENT AND NEXT POINTERS
; DECREMENT RECEIVE COUNTER
; EXIT
; SEE IF ANY ERRORS
; FOR NO ERRORS BR TO 20$
; ELSE, INCREMENT RECEIVE ERROR COUNTER
; PRINT ERROR MESSAGE
; UPDATE POINTERS AND RETURN
; INCREMENT GOOD BUFFERS RECEIVED COUNTER
; KEEP COUNT OF HOW MANY BUFFERS RECEIVED
; KEEP BOOKKEEPING IN ORDER
; UPDATE "RECEIVE RING CURRENT" POINTER
; RETURN WITH NUMBER OF ENTRIES HANDLED

```

```

3504      :---+
3505      :
3506      : EDPACK
3507      :
3508      :
3509      :
3510      :
3511      :
3512      :
3513      :
3514      :
3515      :
3516      :
3517      :
3518      :
3519      :
3520      :
3521      :
3522      :
3523      :
3524      :
3525      :
3526      :
3527      :
3528      :
3529      :
3530      :
3531      :---+
3532 072206      :
3533 072320 000000      :
3534      :
3535 072322      :
3536      :
3537 072332 005002      :
3538 072334 006303      :
3539 072336      :
3540 072356      :
3541      :
3542 072362 005702      :
3543 072364 001010      :
3544      :
3545 072366 006203      :
3546 072370      :
3547      :
3548 072406      :
3549      :

```

ETHERNET DATA PACK

THIS ROUTINE WILL CONVERT A STRING OF HEX CHARACTERS INTO A RIGHT JUSTIFIED BINARY STREAM (WITH LEADING ZEROS), COMPATIBLE WITH ETHERNET CONVENTIONS. THE SOURCE STRING MUST BE FORMATTED USING EITHER A WORD BY WORD HEX DESCRIPTION OR A BYTE BY BYTE HEX DESCRIPTION. THE RETURNED STRING WILL BE BYTE ORIENTED AS REQUIRED BY THE ETHERNET:
LO-BYTE-WORD0 HI-BYTE-WORD0 LO-BYTE-WORD1 HI-BYTE-WORD1, ETC.

INPUT ARGUMENTS P1 - ADDRESS OF THE SOURCE (HEX) STRING TO BE CONVERTED TO A BINARY STREAM.
 P2 - ADDRESS OF THE DESIRED DESTINATION BUFFER WHICH WILL ACCEPT BINARY DATA
 P3 - LENGTH (IN BYTES) OF THE DESTINATION BUFFER

EXPLICIT OUTPUTS P4 - ZERO IF SUCCESSFUL, -1 IF BUFFER TOO LONG OR ODD NUMBER OF HEX CHARACTERS

IMPLIED OUTPUTS THE BUFFER AT P2 WILL CONTAIN A RIGHT JUSTIFIED BINARY STREAM W/ LEADING ZEROS AND CORRESPONDING TO HEX STRING AT R5.

SUBORDINATE PROCEDURES HXFORM. (STRIP NONHEX CHARACTERS)
 HEXBIN. (HEX TO BINARY CONVERSION)

CALLING PROCEDURE CALL EDPACK P1,P2,P3 ;INPUT P1-P3 PARAMETERS
 P\$POP P4 ;OUTPUT P4 PARAMETER

LOCDST: .BLKB 74. ;MAX NUMBER OF CHARACTERS THAT MAY BE ENTERED
SOURCE: .WORD ;SOURCE ADDRESS

EDPACK: P\$POP SOURCE,R4,R3 ;R4-DESTINATION, R3-NUMBER OF CHARS RQD
 ;SOURCE-SRC ADDRESS, ORIENT-WORD/BYTE?
CLR R2 ;ASSUME NO ERRORS, VALUE RETURNED
ASL R3 ;NUMBER OF CHARACTERS REQUIRED W/ "0"S
CALL HXFORM SOURCE,@LOCDST,R3
P\$POP R1,R2 ;R1=ADDRESS OF LAST CHAR
 ;R2=SUCCESS/FAIL CODE (0/-1)
TST R2 ;R1 WILL POINT TO RIGHTMOST CHARACTER
BNE 9\$;RIGHT JUSTIFY BUFFER
 ;CONVERT HEX AT LOCDST TO BINARY
ASR R3 ;R3 BYTES IN OUTPUT BIT STREAM
CALL HEXBIN @LOCDST,R4,R3

9\$: RETURN R2 ;RETURN WITH SUCCESS/FAILURE INDICATION

3607 072510 005302
3608 072512 020402
3609 072514 001372
3610 072516 005004
3611 072520
3612
3613

9\$: DEC R2
CMP R4,R2
BNE 7\$
CLR R4
11\$: RETURN R2,R4

;POINT TO THE LAST ACTUAL CHARACTER AT DEST BFR
;CHECK FOR MINIMUM OF 12 CHARACTERS.
;BRANCH IF LESS THAN 12, ERROR.
;INDICATE SUCESS
;ADDRESS OF LAST CHARACTER (R2) IS P4
;ERROR INDICATOR (R4) IS P5

```

3618
3619
3620
3621
3622
3623
3624
3625
3626
3627
3628
3629
3630
3631
3632
3633
3634
3635
3636
3637 072526 000000
3638 072530 060 061 062
      072533 063 064 065
      072536 066 067 070
      072541 071 101 102
      072544 103 104 105
      072547 106 000
3639
3640
3641 072552
3642
3643
3644
3645 072562 060237 072526
3646
3647 072566 012704 072530
3648 072572 121124
3649 072574 001376
3650 072576 005201
3651 072600 162704 072531
3652
3653
3654 072604 006304
3655 072606 006304
3656 072610 006304
3657 072612 006304
3658 072614 010403
3659
3660 072616 012704 072530
3661 072622 121124
3662 072624 001376
3663 072626 005201
3664 072630 162704 072531
3665
3666
3667 072634 050403
3668
3669 072636 110322

```

```

:---*
:
:      HEXBIN
:
:      THIS PROCEDURE WILL CONVERT A STRING OF HEX (ASCII) CHARACTERS
:      DIRECTLY TO A BINARY STREAM.  THE DESTINATION BINARY STREAM WILL
:      REQUIRE ONLY HALF AS MANY BYTES AS THE HEX STRING BECAUSE TWO
:      HEX CHARACTERS ARE REQUIRED TO REPRESENT A SINGLE BINARY BYTE.
:
:      INPUTS      P1 - SOURCE STRING ADDRESS (DELIMITED BY A NULL)
:                  P2 - DESTINATION ADDRESS FOR THE BINARY DATA.
:                  P3 - THE NUMBER OF BINARY BYTES REQUIRED (HALF THE
:                       NUMBER OF CHARACTERS AT P1.
:
:      OUTPUTS     NO EXPLICIT OUTPUTS
:      IMPLIED OUTPUTS  THE BUFFER AT P2 WILL CONTAIN THE BINARY
:                       STREAM, CONVERTED DIRECTLY FROM THE BUFFER
:                       AT P1.
:
:      SUBORDINATE PROCEDURES  NONE
:      CALLING PROCEDURE      CALL  HEXBIN P1,P2,P3
:
:---*
:
:      .WORD
:      CMPSTR: .ASCIZ /0123456789ABCDEF/
:
:      .EVEN
:
:      HEXBIN: P$POP  R1,R2,HN  ;R1=SOURCE STRING ADDRESS
:                               ;R2=DESTINATION STRING ADDRESS
:                               ;HN=NUMBER OF BYTES REQUIRED
:
:      ADD  R2,HN  ;HN NOW POINTS TO THE LAST_BYTE_POSITION+1
:
:      1$:  MOV  @CMPSTR,R4  ;POINTER IN THE COMPARE STRING
:      2$:  CMPB (R1),(R4)+  ;COMPARE CURRENT CHAR WITH A CHAR IN CMPSTR
:          BNE 2$          ;REPEAT UNTIL CHARACTER FOUND IN LIST
:          INC R1          ;POINT TO THE NEXT ASCII BYTE
:          SUB @CMPSTR+1,R4 ;R4 NOW CONTAINS THE ACTUAL BINARY VALUE FOR
:                               ;THE NIBBLE DESCRIBED BY THE CURRENT BYTE.
:                               ;NOTE: NIBBLE IS THE HI PORTION OF THE BYTE
:                               ;MOVE NIBBLE TO THE HI END OF THE BYTE
:
:      ASL  R4
:      ASL  R4
:      ASL  R4
:      ASL  R4
:      MOV  R4,R3  ;SAVE THE HI NIBBLE
:
:      3$:  MOV  @CMPSTR,R4  ;POINTER INTO COMPARE STRING
:          CMPB (R1),(R4)+  ;COMPARE CURRENT CHAR WITH A CHAR IN CMPSTR
:          BNE 3$          ;REPEAT UNTIL MATCH FOUND IN CMPSTR LIST
:          INC R1          ;POINT TO THE NEXT ASCII BYTE
:          SUB @CMPSTR+1,R4 ;R4 NOW CONTAINS THE ACTUAL BINARY VALUE FOR
:                               ;THE NIBBLE DESCRIBED BY THE CURRENT BYTE.
:                               ;NOTE: NIBBLE IS THE HI PORTION OF THE BYTE
:                               ;NOW THE TWO CHARACTERS HAVE MADE A SINGLE BYTE
:                               ;NOW PLACE THE COMPLETE BYTE IN THE DESTINATION
:                               ;AND POINT TO THE NEXT DESTINATION BYTE

```


3670 072640 020237 072526
3671 072644 100750
3672 072646
3673
3674
3675

CMP R2,HN
BMI 1\$
RETURN

;IF THE DESTINATION POINTER [R2] REACHES THE
;LAST CHARACTER POSITION+1 [HN] THEN DONE.
;RETURN TO CALLER

```

3680
3681
3682      ;---+
3683      ;          BINHEX                      BINARY TO HEX CONVERSION PROCEDURE
3684      ;
3685      ;          THIS PROCEDURE WILL CONVERT A BINARY DATA STREAM INTO A HEX STRING.
3686      ;
3687      ;          INPUTS  - P1- BINARY DATA BUFFER ADDRESS
3688      ;                   P2- NUMBER OF BYTES IN THE BUFFER
3689      ;                   P3- ADDRESS OF OUTPUT BUFFER FOR HEX STRING.
3690      ;                   HEX CHARACTER PAIRS SEPERATED BY "-"'S
3691      ;                   (NOTE: THIS BUFFER MUST BE AT LEAST 3*P2 BYTES LONG)
3692      ;
3693      ;          OUTPUTS - NONE
3694      ;          IMPLICIT OUTPUTS          THE BUFFER AT P3 WILL CONTAIN THE HEX STRING
3695      ;                                     FOLLOWED BY A NULL CHARACTER.
3696      ;
3697      ;          SUBORDINATE ROUTINES      NONE
3698      ;          CALLING PROCEDURE        CALL BINHEX P1,P2,P3
3699      ;---+
3700      ;          HEXC:  .ASCII /0123456789ABCDEF/
3701
3702      ;          LST:   .WORD
3703
3704      ;          BINHEX: P$POP  R1,LST,R2      ;R1 HAS THE INPUT BUFFER ADDRESS
3705      ;                                     ;LST: HAS THE NUMBER OF BYTES IN INPUT BUFFER
3706      ;                                     ;R2 HAS THE OUTPUT BUFFER ADDRESS
3707      ;                                     ;LST IS NOW ADDRESS OF LAST SOURCE BYTE + 1
3708      ;                                     ;GET THE CURRENT BYTE AND POINT TO NEXT BYTE
3709      ;                                     ;SEPARATE NIBBLES AND GET CHARACTERS SEPARATELY
3710      ;                                     ;ONLY RIGHT BINARY NIBBLE REMAINS IN R3
3711      ;                                     ;SHIFT OVER FOR LEFT BINARY NIBBLE IN R4
3712
3713      ;          ADD      R1,LST
3714      ;          MOV     (R1)+,R3
3715      ;          MOV     R3,R4
3716      ;          BIC     @177760,R3
3717      ;          ASR     R4
3718      ;          ASR     R4
3719      ;          ASR     R4
3720      ;          BIC     @177760,R4
3721      ;                                     ;ONLY LEFT BINARY NIBBLE REMAINS IN R4
3722      ;                                     ;R4 IS THE MOST SIGNIFICANT NIBBLE (FIRST)
3723      ;                                     ;R3 IS THE LEAST SIGNIFICANT NIBBLE (SECOND)
3724      ;          MOV     HEXC(R4),(R2)+
3725      ;          MOV     HEXC(R3),(R2)+
3726      ;          MOV     @'-,(R2)+
3727      ;          CMP     R1,LST
3728      ;          BLO     1$
3729      ;          CLRB   -(R2)
3730      ;          RETURN
3731
3732      ;          .SBTTL  BLDLD  BUILD LOOP DIRECT DATA BUFFERS FOR TRANSMIT.
3733
3734      ;          ;---+
3735      ;          ; FUNCTIONAL DESCRIPTION:
3736      ;          ; THIS SUBROUTINE BUILDS LOOP DIRECT PACKETS FOR TRANSMISSION
3737      ;          ; FROM THE UNA. SOURCE ADDRESS, DESTINATION ADDRESS,
3738      ;          ; PROT. TYPE, AND LOOP DIRECT HEADER INFO ARE ADDED
3739      ;          ; TO THE MESSAGE BUFFER. THE MESSAGE BUFFER IS BUILT
3740      ;          ; BY A CALL TO ELDBUF.
  
```

3732
3733
3734
3735
3736
3737
3738
3739
3740
3741
3742
3743
3744
3745
3746
3747
3748
3749
3750
3751
3752

:
: INPUTS - P1 - THE ADDRESS OF THE DESTINATION ADDRESS (FROM NODE TABLE)
: IMPLICIT - P\$SIZE CONTAINS THE SIZE OF THE MESSAGE BUFFER DATA
: XRG NXT POINTS TO THE NEXT AVAILABLE RING ENTRY
: PHYADR HOLDS THE CURRENT LOCAL UNA PHYSICAL ADDRESS
:
: OUTPUTS - BUILT MESSAGE PACKET.
:
: CALLING PROCEDURE - CALL BLDLD P1
:
: SIDE EFFECTS - THE MESSAGE PACKET IS BUILT AND CONTAINED IN THE
: BUFFER POINTED TO BY XRG NXT WHEN THE ROUTINE WAS ENTERED.
: XRG NXT IS UPDATED TO POINT TO THE NEXT RING ENTRY
:
: REGISTER USAGE - R1 HOLDS ADDRESS OF DESTINATION ADDRESS
: R2 IS A POINTER FOR THE LOOP DIRECT HEADER INFO
: R3 HOLDS THE PACKET LENGTH
: R4 HOLDS ADDRESS OF NEXT RING ENTRY DATA BUFFER
:
: ---+

3753 072760
3754 072760
3755 072762 013704 003762
3756 072766 032764 100000 000004
3757 072774 001110
3758 072776 016404 000002
3759 073002 013703 002372
3760 073006 062703 000040
3761 073012 010337 050560
3762 073016 162737 000016 050560
3763 073024 022703 002756
3764 073030 002477
3765 073032 010337 050566
3766 073036 012164 000000
3767 073042 012164 000002
3768 073046 011164 000004
3769 073052 005064 000006
3770 073056 005064 000010
3771 073062 005064 000012
3772 073066 013764 050544 000014
3773 073074 012702 050720
3774 073100 012264 000016
3775 073104 011264 000020
3776 073110 013764 047762 000022
3777 073116 013764 047764 000024
3778 073124 013764 047766 000026
3779 073132 016264 000010 000030
3780 073140 013764 047762 000032
3781 073146 013764 047764 000034
3782 073154 013764 047766 000036
3783 073162 062704 000040
3784 073166 010437 050570
3785 073172
3786 073202
3787 073214 000411
3788 073216

BLDLD: :
P\$POP R1 ; PUT ADDRESS OF DEST. ADDRESS IN R1
MOV XRG NXT,R4 ; MOVE NEXT PACKET ADDRESS TO R4
BIT @OWN,4(R4) ; CHECK OWNERSHIP BIT
BNE 40\$; IF DON'T OWN, BOOKKEEPING ERROR,
MOV 2(R4),R4 ; POINT R4 TO DATA BLOCK
MOV P\$SIZE,R3 ; PUT MESSAGE SIZE INTO R3
ADD #40,R3 ; ADD HEADER AND LOOP DIRECT INFO TO LENGTH
MOV R3,XFER ; PUT BYTES TRANSFERED INTO WORD
SUB #16,XFER ; AND CORRECT FOR HEADER
CMP #XPKLEN,R3 ; SEE IF LONGER THAN ONE PACKET
BLT 45\$; IF YES, ERROR
MOV R3,BUFLEN ; PUT PACKET LENGTH IN BUFLEN
MOV (R1)+,DESTIN(R4) ; MOVE FIRST TWO BYTES OF ADDRESS
MOV (R1)+,DESTIN+2(R4) ; MOVE BYTES THREE AND FOUR
MOV (R1),DESTIN+4(R4) ; MOVE BYTES FIVE AND SIX
CLR SOURCC(R4) ; LEAVE BLANK SPACE FOR SOURCE ADDRESS
CLR SOURCC+2(R4) ; SIX BYTES WORTH
CLR SOURCC+4(R4)
MOV PROTOO,PROTOT(R4) ; MOVE PROTOCALL TYPE INTO HEADER
MOV #LOPDIR,R2 ; MOVE LOOPDIRECT FORMAT HEADER LOC. TO R2
MOV (R2)+,LDSKIP(R4) ; SKIP COUNT
MOV (R2),LDFCT1(R4) ; FUNCTION CODE (FORWARD)
MOV PHYADR,LDADR1(R4) ; LOCAL NODE ADDRESS
MOV PHYADR+2,LDADR1+2(R4) ; SIX BYTES
MOV PHYADR+4,LDADR1+4(R4)
MOV 10(R2),LDFCT2(R4) ; FUNCTION CODE (REPLY)
MOV PHYADR,LDADR2(R4) ; LOCAL NODE ADDRESS
MOV PHYADR+2,LDADR2+2(R4) ; SIX BYTES
MOV PHYADR+4,LDADR2+4(R4)
ADD #LDADR2+6,R4 ; POINT R4 TO FIRST DATA BYTE
MOV R4,CMPBUF ; STORE BUFFER LOCATION FOR DATA COMPARE
CALL BLDBUF R4 ; BUILD DATA BUFFER
CALL GETXNX #XRG NXT ; UPDATE POINTER TO NEXT RING ENTRY
BR 60\$; EXIT
40\$: ERRDF 13,MSG10,ERR1 ; TRANSMIT RING BOOKKEEPING ERROR

073216 104455
 073220 000015
 073222 064656
 073224 067460
 3789 073226 000404
 3790 073230
 073230 104455
 073232 000016
 073234 064755
 073236 067460
 3791 073240
 3792

45\$: BR 60\$
 ERRDF 14,MSG14,ERR1

 60\$: RETURN

; EXIT
 ; MESSAGE SIZE TOO BIG

TRAP C\$ERDF
 .WORD 13
 .WORD MSG10
 .WORD ERR1

 TRAP C\$ERDF
 .WORD 14
 .WORD MSG14
 .WORD ERR1

```

3794 .SBTTL BLDFAS BUILD PACKET FOR FULL ASSIST TRANSMISSION.
3795
3796 ; --+
3797 ; FUNCTIONAL DESCRIPTION:
3798 ; THIS SUBROUTINE BUILDS FULL ASSIST PACKETS FOR TRANSMISSION
3799 ; FROM THE UNA. SOURCE ADDRESS, DESTINATION ADDRESS, PROT. TYPE
3800 ; AND FULL ASSIST HEADER INFO ARE ADDED TO THE MESSAGE BUFFER.
3801 ; THE MESSAGE BUFFER IS BUILT BY A CALL TO BLDUF.
3802 ;
3803 ; INPUTS - P1 - THE ADDRESS OF THE DESTINATION ADDRESS (FROM NODE TABLE)
3804 ; IMPLICIT - P#SIZE CONTAINS THE SIZE OF THE MESSAGE BUFFER DATA
3805 ; XRGXNT POINTS TO THE NEXT AVAILABLE RING ENTRY
3806 ; PHYADR HOLDS THE CURRENT LOCAL NODE ADDRESS
3807 ;
3808 ; OUTPUTS - THE BUILT BUFFER
3809 ;
3810 ; CALLING PROCEDURE - CALL BLDFAS P1
3811 ;
3812 ; SIDE EFFECTS - XRGXNT SI UPDATED TO POINT TO THE NEXT RING ENTRY
3813 ;
3814 ; REGISTER USAGE - R1 HOLDS ADDRESS OF TARGET NODE ADDRESS
3815 ; R2 HOLDS ADDRESS OF ASSIST NODE ADDRESS
3816 ; R3 HOLDS THE PACKET LENGTH
3817 ; R4 HOLDS ADDRESS OF NEXT RING ENTRY DATA BUFFER
3818 ;
3819 ; --+
3820

```

```

3821 073242 BLDFAS::
3822 073242 P#POP R1,R2 ; PUT ADDRESS OF TARGET ADDRESS INTO R1
3823 ; AND ADDRESS OF ASSIST ADDRESS INTO R2
3824 073246 013704 003762 MOV XRGXNT,R4 ; MOVE NEXT PACKET ADDRESS TO R4
3825 073252 032764 100000 000004 BIT #OWN,4(R4) ; CHECK OWNERSHIP BIT
3826 073260 001140 BNE 40$ ; IF DON'T OWN, BOOKKEEPING ERROR,
3827 073262 016404 000002 MOV 2(R4),R4 ; POINT R4 TO DATA BLOCK
3828 073266 013703 002372 MOV P#SIZE,R3 ; PUT MESSAGE SIZE INTO R3
3829 073272 062703 000060 ADD #60,R3 ; ADD HEADER INFO TO LENGTH
3830 073276 010337 050560 MOV R3,XFER ; PUT 'BYTES TRANSFERED' INTO WORD
3831 073302 162737 000016 050560 SUB #16,XFER ; AND CORRECT FOR HEADER
3832 073310 022703 002756 CMP #XPLEN,R3 ; SEE IF LONGER THAN ONE PACKET
3833 073314 002527 BLT 45$ ; IF YES, ERROR
3834 073316 010337 050566 MOV R3,BUFLEN ; PUT PACKET LENGTH IN BUFLEN
3835 073322 011264 000000 MOV (R2),DESTIN(R4) ; MOVE FIRST TWO BYTES OF ADDRESS
3836 073326 016264 000002 000002 MOV 2(R2),DESTIN+2(R4) ; MOVE BYTES THREE AND FOUR
3837 073334 016264 000004 000004 MOV 4(R2),DESTIN+4(R4) ; MOVE BYTES FIVE AND SIX
3838 073342 005064 000006 CLR SOURCC(R4) ; LEAVE BLANK SPACE FOR SOURCE ADDRESS
3839 073346 005064 000010 CLR SOURCC+2(R4) ; SIX BYTES WORTH
3840 073352 005064 000012 CLR SOURCC+4(R4)
3841 073356 013764 050544 000014 MOV PROTOO,PROTOT(R4) ; MOVE PROTOCOL TYPE INTO HEADER
3842 073364 012764 000000 000016 MOV #0,FASKIP(R4) ; SKIP COUNT
3843 073372 012764 000002 000020 MOV #2,FAFCT1(R4) ; FUNCTION CODE (FORWARD)
3844 073400 011164 000022 MOV (R1),FAADR1(R4) ; TARGET NODE ADDRESS
3845 073404 016164 000002 000024 MOV 2(R1),FAADR1+2(R4) ; SIX BYTES
3846 073412 016164 000004 000026 MOV 4(R1),FAADR1+4(R4)
3847 073420 012764 000002 000030 MOV #2,FAFCT2(R4) ; FUNCTION CODE (FORWARD)
3848 073426 011264 000032 MOV (R2),FAADR2(R4) ; ASSIST NODE ADDRESS
3849 073432 016264 000002 000034 MOV 2(R2),FAADR2+2(R4) ; SIX BYTES
3850 073440 016264 000004 000036 MOV 4(R2),FAADR2+4(R4)

```

3851	073446	012764	000002	000040	MOV	#2,FAFCT3(R4)	;	FUNCTION CODE (FORWARD)
3852	073454	013764	047762	000042	MOV	PHYADR,FAADR3(R4)	;	LOCAL NODE ADDRESS
3853	073462	013764	047764	000044	MOV	PHYADR+2,FAADR3+2(R4)	;	SIX BYTES
3854	073470	013764	047766	000046	MOV	PHYADR+4,FAADR3+4(R4)	;	
3855	073476	012764	000001	000050	MOV	#1,FAFCT4(R4)	;	FUNCTION CODE (REPLY)
3856	073504	013764	047762	000052	MOV	PHYADR,FAADR4(R4)	;	LOCAL NODE ADDRESS
3857	073512	013764	047764	000054	MOV	PHYADR+2,FAADR4+2(R4)	;	SIX BYTES
3858	073520	013764	047766	000056	MOV	PHYADR+4,FAADR4+4(R4)	;	
3859	073526	062704	000060		ADD	#FAADR4+6,R4	;	POINT R4 TO FIRST DATA BYTE
3860	073532	010437	050570		MOV	R4,CMPBUF	;	STORE BUFFER LOCATION FOR DATA COMPARE
3861	073536				CALL	BLDBUF R4	;	BUILD DATA BUFFER
3862	073546				CALL	GETXNX #XRGXNT	;	UPDATE POINTER TO NEXT RING ENTRY
3863	073560	000411			BR	50\$;	EXIT
3864	073562			40\$:	ERRDF	28,EMSG10,ERR1	;	TRANSMIT RING BOOKKEEPING ERROR
	073562	104455					TRAP	C\$ERDF
	073564	000034					.WORD	28
	073566	064656					.WORD	EMSG10
	073570	067460					.WORD	ERR1
3865	073572	000404			BR	50\$;	EXIT
3866	073574			45\$:	ERRDF	29,EMSG14,ERR1	;	MESSAGE SIZE TOO BIG
	073574	104455					TRAP	C\$ERDF
	073576	000035					.WORD	29
	073600	064755					.WORD	EMSG14
	073602	067460					.WORD	ERR1
3867	073604			50\$:	RETURN			
3868								


```

3870 .SBTTL BLDAST BUILD TRANSMIT AND RECEIVE ASSIST PACKETS
3871
3872
3873 073606
3874 073606
3875
3876 073612 013704 003762
3877 073616 032764 100000 000004
3878 073624 001125
3879 073626 016404 000002
3880 073632 013703 002372
3881 073636 062703 000050
3882 073642 010337 050560
3883 073646 162737 000016 050560
3884 073654 022703 002756
3885 073660 002514
3886 073662 010337 050566
3887 073666 011164 000000
3888 073672 016164 000002 000002
3889 073700 016164 000004 000004
3890 073706 005064 000006
3891 073712 005064 000010
3892 073716 005064 000012
3893 073722 013764 050544 000014
3894 073730 012764 000000 000016
3895 073736 012764 000002 000020
3896 073744 011264 000022
3897 073750 016264 000002 000024
3898 073756 016264 000004 000026
3899 073764 012764 000002 000030
3900 073772 013764 047762 000032
3901 074000 013764 047764 000034
3902 074006 013764 047766 000036
3903 074014 012764 000001 000040
3904 074022 013764 047762 000042
3905 074030 013764 047764 000044
3906 074036 013764 047766 000046
3907 074044 062704 000050
3908 074050 010437 050570
3909 074054
3910 074064
3911 074076 000411
3912 074100
3913 074110 000404
3914 074112
3915 074122
3916
3917

      BLDAST::
      P:POP R1,R2
      MOV XRG NXT,R4 ; PUT DESTINATION ADDRESS INTO R1
      BIT @OWN,4(R4) ; ASSIST ADDRESS INTO R2
      BNE 40: ; MOVE NEXT PACKET ADDRESS TO R4
      MOV 2(R4),R4 ; CHECK OWNERSHIP BIT
      MOV P:SIZE,R3 ; IF DON'T OWN, BOOKKEEPING ERROR
      ADD @50,R3 ; POINT R4 TO DATA BLOCK
      MOV R3,XFER ; PUT MESSAGE SIZE INTO R3
      SUB @16,XFER ; ADD HEADER INFO INTO LENGTH
      CMP @XP KLEN,R3 ; PUT 'BYTES TRANSFERED' INTO WORD
      BLT 45: ; AND CORRECT FOR HEADER
      MOV R3,BUFLEN ; SEE IF LONGER THAN ONE PACKET
      MOV (R1),DESTIN(R4) ; IF YES, ERROR
      MOV 2(R1),DESTIN+2(R4) ; PUT PACKET LENGTH INTO BUFLEN
      MOV 4(R1),DESTIN+4(R4) ; MOVE DESTINATION ADDRESS INTO HEADER
      CLR SOURCC(R4) ; SIX BYTES WORTH
      CLR SOURCC+2(R4) ; LEAVE BLANK SPACE FOR SOURCE ADDRESS
      CLR SOURCC+4(R4) ; SIX BYTES WORTH
      MOV PROT00,PROT0T(R4) ; MOVE PROTOCOL TYPE INTO HEADER
      MOV @0,FAKIP(R4) ; SKIP COUNT
      MOV @2,FAFCT1(R4) ; FUNCTION CODE (FORWARD)
      MOV (R2),FAADR1(R4) ; TARGET NODE ADDRESS
      MOV 2(R2),FAADR1+2(R4) ; SIX BYTES
      MOV 4(R2),FAADR1+4(R4)
      MOV @2,FAFCT2(R4) ; FUNCTION CODE (FORWARD)
      MOV PHYADR,FAADR2(R4) ; LOCAL NODE ADDRESS
      MOV PHYADR+2,FAADR2+2(R4) ; SIX BYTES WORTH
      MOV PHYADR+4,FAADR2+4(R4)
      MOV @1,FAFCT3(R4) ; FUNCTION CODE (REPLY)
      MOV PHYADR,FAADR3(R4) ; LOCAL NODE ADDRESS
      MOV PHYADR+2,FAADR3+2(R4)
      MOV PHYADR+4,FAADR3+4(R4)
      ADD @FAADR3+6,R4 ; POINT R4 TO FIRST DATA BYTE
      MOV R4,CMPBUF ; STORE BUFFER LOCATION FOR DATA COMPARE
      CALL BLDBUF R4 ; BUILD DATA BUFFER
      CALL GETXNX @XRG NXT ; UPDATE RING POINTER
      BR 50:
      ERRDF 40: 35,MSG10,ERR1 ; TRANSMIT RING BOOKKEEPING ERROR
      TRAP C:ERDF
      .WORD 35
      .WORD MSG10
      .WORD ERR1
      BR 50:
      ERRDF 45: 36,MSG14,ERR1 ; MESSAGE SIZE TOO BIG ERROR
      TRAP C:ERDF
      .WORD 36
      .WORD MSG14
      .WORD ERR1
      RETURN 50:
    
```

3919
3920
3921
3922
3923
3924
3925
3926
3927
3928
3929
3930
3931
3932
3933
3934
3935
3936
3937
3938
3939
3940
3941
3942
3943
3944
3945
3946
3947
3948
3949
3950
3951
3952
3953
3954
3955
3956
3957
3958
3959
3960
3961
3962
3963
3964
3965
3966
3967
3968
3969
3970
3971

.SBTTL BLDREQ BUILD REQUEST ID PACKETS FOR TRANSMIT.

;-*-
; FUNCTIONAL DESCRIPTION:
; THIS SUBROUTINE BUILDS REQUEST ID PACKETS FOR TRANSMISSION
; FROM THE UNA. SOURCE ADDRESS, DESTINATION ADDRESS,
; PROTOCOL TYPE, SEQUENCE NUMBER AND REQUEST ID
; HEADER INFO ARE BUILT IN THIS SUBROUTINE.
; INPUTS - IMPLICIT - THE DESTINATION ADDRESS IS CONTAINED IN ADRBUF.
; OUTPUTS - BUILT MESSAGE PACKET
; CALLING PROCEDURE - CALL BLDREQ
; SIDE EFFECTS - THE MESSAGE PACKET IS BUILT AND CONTAINED IN THE
; BUFFER POINTED TO BY XRGXNT WHEN THE ROUTINE WAS
; ENTERED. XRGXNT IS UPDATED TO POINT TO THE NEXT ENTRY.
; REGISTER USAGE - R1 HOLDS ADDRESS OF DESTINATION ADDRESS.
; R2 IS A POINTER FOR REQUEST ID HEADER INFO.
; R4 HOLDS ADDRESS OF NEXT RING ENTRY DATA BUFFER.
;-*-

BLDREQ::

MOV XRGXNT,R4 ; MOVE NEXT PACKET ADDRESS TO R4
BIT @OWN,4(R4) ; CHECK OWNERSHIP BIT
BNE 40\$; IF DON'T OWN, BOOKKEEPING ERROR
MOV 2(R4),R4 ; POINT R4 TO DATA BLOCK
MOV @100,BUFLEN ; MOVE BUFFER SIZE TO BUFLEN
MOV @ADRBUF,R1 ; MOVE ADDRESS OF DEST. ADR. TO R1
MOV (R1)+,DESTIN(R4) ; MOVE FIRST TWO BYTE OF DEST. ADR.
MOV (R1)+,DESTIN+2(R4) ; AND BYTES THREE AND FOUR
MOV (R1),DESTIN+4(R4) ; AND LAST TWO BYTES
CLR SOURCC(R4) ; LEAVE BLANK SPACE FOR SOURCE ADDR.
CLR SOURCC+2(R4) ; SIX BYTES WORTH
CLR SOURCC+4(R4)
MOV PROT02,PROTOT(R4) ; MOVE PROTOCOL TYPE INTO HEADER
MOV @REQID,R2 ; MOVE REQUEST ID HEADER LOC. TO R2
MOV (R2)+,HEADER(R4) ; BYTE COUNT
MOV (R2)+,HEADER+2(R4) ; FUNCTION CODE (REQUEST ID)
MOV (R2),HEADER+4(R4) ; RECEIPT NO.
CALL GETXNX @XRGXNT ; UPDATE POINTER TO NEXT RING ENTRY
BR 50\$; EXIT
40\$: ERDF 21,MSG10,ERR1 ; TRANSMIT RING BOOKKEEPING ERROR
TRAP C\$ERDF
.WORD 21
.WORD MSG10
.WORD ERR1
50\$: RETURN

.SBTTL GET?NX GET NEXT TRANSMIT OR RECIEVE RING ENTRY

;-*-
; FUNCTIONAL DESCRIPTION

```

3972      ;
3973      ;
3974      ;
3975      ;
3976      ; INPUTS - P1 - THE ADDRESS OF THE RING POINTER TO BE UPDATED.
3977      ;
3978      ; OUTPUTS - THE RING POINTER IS UPDATED TO POINT TO THE NEXT AVAILABLE
3979      ; ENTRY.
3980      ;
3981      ; CALLING PROCEDURE - CALL GETXNX #P1 ; FOR TRANSMIT UPDATES
3982      ; CALL GETRXN #P1 ; FOR RECIEVE UPDATES
3983      ;
3984      ; SIDE EFFECTS - NONE
3985      ;
3986      ; REGISTER USAGE - R1 POINTS TO THE FIRST ENTRY IN THE RING
3987      ; R2 POINTS TO THE LAST ENTRY IN THE RING
3988      ; R3 IS THE ADDRESS OF THE RING POINTER TO BE UPDATED
3989      ;
3990      ;---*
3991
3992 074262 GETRXN::
3993 074262 013701 003754      MOV RRGSR,R1 ; MOVE FIRST RING ENTRY TO R1
3994 074266 013702 003770      MOV RRGLST,R2 ; MOVE LAST RING ENTRY TO R2
3995 074272 000404      BR GETCOM ; GO TO COMMON CODE
3996
3997 074274 GETXNX::
3998 074274 013701 003752      MOV XRGSR,R1 ; MOVE FIRST RING ENTRY TO R1
3999 074300 013702 003766      MOV XRGLST,R2 ; MOVE LAST RING ENTRY TO R2
4000 074304      GETCOM: P#POP R3 ; GET ADDRESS OF RING POINTER IN R3
4001 074306 021302      CMP (R3),R2 ; SEE IF POINTER POINTS TO LAST RING
4002 074310 001403      BEQ 15# ; IF YES, BRANCH
4003 074312 062713 000012      ADD #10.,(R3) ; ELSE, ADD ENTRY LENGTH TO POINTER
4004 074316 000401      BR 25# ; EXIT
4005 074320 010113      15#: MOV R1,(R3) ; POINT POINTER TO FIRST ENTRY IN RING
4006 074322      25#: RETURN
4007
4008
4009
4010      .SBTTL BLDBUF BUILD MESSAGE BUFFERS
4011
4012      ;---*
4013      ; FUNCTIONAL DESCRIPTION
4014      ; THIS SUBROUTINE CREATES A MESSAGE BUFFER TO BE USED
4015      ; FOR TRANSMISSION.
4016      ;
4017      ; INPUTS - P1 - BUFFER LOCATION TO PUT BUILT MESSAGE
4018      ; IMPLICIT - P#SIZE CONTAINS THE SIZE THE BUFFER IS TO BE
4019      ; P#TYPE CONTAINS THE MESSAGE TYPE
4020      ; OUTPUTS - IMPLICIT - BUFFER STARTING AT LOCATION P1 CONTAINS A
4021      ; MESSAGE P#SIZE BYTES LONG USING THE MESSAGE
4022      ; TYPE SPECIFIED BY P#TYPE.
4023      ;
4024      ; CALLING PROCEDURE - CALL BLDBUF P1
4025      ;
4026      ; SIDE EFFECTS - NONE
4027      ;
4028      ; REGISTER USAGE - R1 POINTS TO THE NEXT BYTE OF STORED MESSAGE TO BE BUILT

```



```

4029      ;
4030      ;
4031      ;
4032      ;
4033      ;
4034      ;
4035      ;
4036 074324      ;
4037 074324      ;
4038 074326 013702 002370      ;
4039 074332 006302      ;
4040 074334 013704 002372      ;
4041 074340 060304      ;
4042 074342 016201 003316      ;
4043 074346 005037 050542      ;
4044 074352 005237 050542      ;
4045 074356 112123      ;
4046 074360 026237 003300 050542      ;
4047 074366 001004      ;
4048 074370 016201 003316      ;
4049 074374 005037 050542      ;
4050 074400 020304      ;
4051 074402 001363      ;
4052 074404      ;
4053      ;

```

IN THE MESSAGE BUFFER.
R2 = (MESSAGE TYPE X 2), USED AS OFFSET FOR POINTERS
R3 POINTS TO THE NEXT BYTE OF THE BUFFER UNDER CONSTRUCTION
R4 POINTS TO THE LAST BYTE OF THE BUFFER UNDER CONSTRUCTION

```

BLDBUF::
      P#POP      R3      ; PUT BUFFER ADDRESS INTO R3
      MOV      P#TYPE,R2      ; PUT MESSAGE TYPE INTO R2
      ASL      R2      ; MULTIPLY BY 2
      MOV      P#SIZE,R4      ; PUT SIZE INTO R4
      ADD      R3,R4      ; MAKE R4 = LAST BYTE OF BUFFER
      MOV      MSGAD(R2),R1      ; POINT R1 TO FIRST BYTE OF STORED MESSAGE
      CLR      COUNT      ; CLEAR BYTE COUNTER
10$:   INC      COUNT      ; COUNT NO. OF BYTES COPIED
      MOVB     (R1)+,(R3)+      ; PUT BYTE IN BUFFER
      CMP      MSGCNT(R2),COUNT      ; ARE WE AT END OF STORED MESSAGE
      BNE     20$      ; IF NO, CHECK IF DONE
      MOV      MSGAD(R2),R1      ; ELSE, POINT R1 TO BEGINING
      CLR      COUNT      ; AND CLEAR COUNTER
20$:   CMP      R3,R4      ; IS BUFFER FILLED?
      BNE     10$      ; IF NO, LOOP
      RETURN      ; ELSE, RETURN

```

4055
 4056
 4057
 4058
 4059
 4060
 4061
 4062
 4063
 4064
 4065
 4066
 4067
 4068
 4069
 4070
 4071
 4072
 4073
 4074
 4075
 4076
 4077
 4078
 4079
 4080
 4081
 4082
 4083 074406
 4084 074406
 4085
 4086
 4087 074414 005004
 4088 074416 005037 050550
 4089
 4090 074422 005204
 4091 074424 121213
 4092 074426 001421
 4093 074430 005237 050550
 4094 074434 022737 000005 050550
 4095 074442 002413
 4096 074444
 074444 011346
 074446 011246
 074450 010446
 074452 012746 066754
 074456 012746 000004
 074462 010600
 074464 104415
 074466 062706 000012
 4097 074472 005202
 4098 074474 005203
 4099 074476 005301
 4100 074500 001350
 4101 074502 022737 000000 050550
 4102 074510 001412
 4103 074512

.SBTTL DATCMP COMPARE DATA BUFFERS

```

:--+
: FUNCTIONAL DESCRIPTION
:     THIS SUBROUTINE COMPARES TWO DATA BUFFERS BYTE BY BYTE.
:     IF COMPARISON ERRORS OCCURED, LOCATION, EXPECTED DATA
:     AND RECIEVED DATA ARE PRINTED OUT FOR THE FIRST FIVE
:     ERRORS.  THE TOTAL NUMBER OF ERRORS IS ALSO PRINTED.
:
: INPUTS -   P1 - THE SIZE (IN BYTES) OF THE BUFFER TO BE COMPARED.
:            P2 - THE ADDRESS OF BUFFER TO COMPARE OTHER BUFFER AGAINST.
:            P3 - THE ADDRESS OF THE SECOND BUFFER.
:
: OUTPUTS -  P4 - THE NUMBER OF COMPARISON ERRORS.
:
: CALLING PROCEDURE - CALL DATCMP P1,P2,P3
:                   P$POP P4
:
: SIDE EFFECTS - NONE.
:
: REGISTER USAGE - R1 CONTAINS THE COMPARE SIZE
:                  R2 CONTAINS THE ADDRESS OF THE BYTE BEING COMPARED IN BUFFER 1
:                  R3 CONTAINS THE ADDRESS OF THE BYTE BEING COMPARED IN BUFFER 2
:                  R4 CONTAINS THE BYTE OFFSET (BYTES FROM BEGINING OF BUFFER)
:--+
```

```

DATCMP::
    P$POP    R1,R2,R3      ; PUT COMPARE SIZE IN R1
                                ; BUFFER 1 ADDRESS IN R2 AND
                                ; BUFFER 2 ADDRESS IN R3
                                ; INITIALIZE BYTE OFFSET
                                ; AND ERROR COUNTER
    CLR     R4
    CLR     TEMP
10$:      INC     R4      ; INCREMENT OFFSET COUNTER
          CMPB   (R2),(R3) ; COMPARE BUFFERS
          BEQ   20$      ; IF SAME, BRANCH
          INC   TEMP     ; INCREMENT ERROR COUNTER
          CMP   #5,TEMP  ; IF MORE THAN 5 ERRORS,
          BLT  20$      ; DON'T PRINT MESSAGE
          PFINTX @CMPE1,R4,(R2),(R3) ; PRINT ERROR MESSAGE
                                MOV   (R3),-(SP)
                                MOV   (R2),-(SP)
                                MOV   R4,-(SP)
                                MOV   @CMPE1,-(SP)
                                MOV   #4,-(SP)
                                MOV   SP,R0
                                TRAP  C$PNTX
                                ADD   #12,SP
20$:      INC   R2      ; INCREMENT BUFFER 1 POINTER
          INC   R3      ; INCREMENT BUFFER 2 POINTER
          DEC   R1      ; DECREMENT COMPARE SIZE
          BNE  10$      ; IF NOT FINISHED, GO BACK FOR MORE
          CMP   #0,TEMP ; WERE THERE ANY ERRORS?
          BEQ  30$      ; IF NO, EXIT
          PRINTX @CMPE2,TEMP
```

```

074512 013746 050550
074516 012746 067051
074522 012746 000002
074526 010600
074530 104415
074532 062706 000006
4104 074536 30$: RETURN TEMP ; RETURN WITH ERROR COUNT ON STACK
4105
4106
4107
4108
4109
4110
4111
4112
4113
4114
4115
4116
4117
4118
4119
4120
4121
4122
4123
4124
4125
4126
4127
4128
4129
4130
4131
4132
4133
4134
4135
4136
4137
4138 074544
4139 074550 023727 050550 000001
4140 074556 001002
4141 074560
4142 074562 000402
4143 074564
4144 074570 012701 002656
4145 074574 005711
4146 074576 001415
4147 074600 021127 177777
4148 074604 001454
4149 074606
4150 074620
4151 074622 001412
4152 074624 062701 000026
4153 074630 000761
4154 074632 011211

MOV TEMP, -(SP)
MOV @CMPER2, -(SP)
MOV @2, -(SP)
MOV SP, R0
TRAP C$PNTX
ADD @6, SP

.SBTTL WRITES WRITE DATA ONTO SUMMARY TABLE

;--*
; FUNCTIONAL DESCRIPTION:
; THIS SUBROUTINE UPDATES THE SUMMARY TABLE DATA FOR
; THE NODES SPECIFIED IN THE CALL STATEMENT. EITHER ONE
; OR TWO NODES CAN UPDATED PER CALL. AFTER THE CALL,
; THE SUMMARY DATA COUNTERS ARE CLEARED. THE SUMMARY TABLE
; IS CHECKED FOR A MATCHING NODE ADDRESS AND UPDATES THE
; DATE FOR THAT NODE, OR ADDS THE NODE TO THE TABLE IF IT
; DOESN'T EXIT. AN ERROR IS REPORTED IF THE END OF THE TABLE
; IS REACHED.
;
; INPUTS - P1 - THE NUMBER OF NODES TO UPDATE (1 OR 2).
; P2 - THE ADDRESS OF THE FIRST NODE ADDRESS.
; P3 - THE ADDRESS OF THE SECOND NODE ADDRESS IF P1 = 2 OR
; BLANK IF P1 = 1.
;
; OUTPUTS - THE SUMMARY TABLE IS UPDATED.
;
; CALLING PROCEDURE - CALL WRITES P1,P2(,P3)
;
; SIDE EFFECTS - THE SUMMARY COUNTERS ARE CLEARED.
;
; REGISTER USAGE - R1 POINTS TO THE CURRENT LOCATION IN THE SUMMARY TABLE.
; R2 POINTS TO THE NODE TO BE UPDATED'S ADDRESS.
; R3 IS SCRATCH
; R4 HOLDS THE SECOND NODE TO BE UPDATED ADDRESS.
;--*

WRITES: P$POP TEMP ; SEE HOW MANY NODES TO WRITE
CMP TEMP, #1 ; IF ONLY ONE, GET ADDRESS
BNE 5$
P$POP R2
BR 6$
5$: P$POP R2,R4 ; IF TWO, GET BOTH ADDRESSES
6$: MOV @STATBL,R1 ; MOVE STATISTICAL TABLE ADDRESS INTO R1
7$: TST (R1) ; SEE IF SLOT IS EMPTY
BEQ 15$ ; IF YES, BR
CMP (R1), #-1 ; SEE IF TABLE FULL
BEQ 25$ ; IF YES, ERROR
CALL CMPADR R1,R2 ; LOOK FOR MATCHING ADDRESS
P$POP R3
BEQ 20$ ; IF YES, BR
ADD @26,R1 ; ELSE, POINT R1 TO NEXT ENTRY
BR 7$ ; AND CHECK AGAIN
15$: MOV (R2),(R1) ; ADD NEW ADDRESS TO TABLE

```



```

4155 074634 016261 000002 000002      MOV      2(R2),2(R1)      ; SIX BYTES WORTH
4156 074642 016261 000004 000004      MOV      4(R2),4(R1)      ;
4157 074650 062701 000006      20$:    ADD      #6,R1        ; POINT R1 TO DATA
4158 074654 063721 050500      ADD      S.NREC,(R1)+    ; UPDATE SUMMARY DATA, RECEIVES NOT COMPLETE
4159 074660 063721 050476      ADD      S.REC,(R1)+    ; RECEIVES COMPLETE
4160 074664 063721 050502      ADD      S.LEN,(R1)+    ; LENGTH ERRORS
4161 074670 063721 050504      ADD      S.COMP,(R1)+   ; COMPARE ERRORS
4162 074674 063721 050506      ADD      S.BYTE,(R1)+   ; BYTES COMPARED
4163 074700 103001      BCC      22$            ; IF OVERFLOW, INCREMENT NEXT WORD
4164 074702 005511      ADC      (R1)
4165 074704 062701 000002      22$:    ADD      #2,R1        ; POINT R1 TO NEXT DATA
4166 074710 063721 050510      ADD      S.XFER,(R1)+   ; BYTES TRANSFERED
4167 074714 103001      BCC      23$            ; IF OVERFLOW, INCREMENT NEXT WORD
4168 074716 005511      ADC      (R1)
4169 074720 062701 000002      23$:    ADD      #2,R1        ; POINT R1 TO NEXT DATA
4170 074724 005337 050550      DEC      TEMP           ; DECR NO OF NODES COUNTER
4171 074730 001414      BEQ      30$           ; IF NO MORE, EXIT
4172 074732 010402      MOV      R4,R2         ; POINT R2 TO NEXT NODE
4173 074734 000715      BR       6$            ; AND UPDATE SUMMARY DATA
4174 074736      25$:    PRINTF   #TABFUL,#SUMM ; PRINT TABLE FULL MESSAGE
      074736 012746 053706      MOV      #SUMM,-(SP)
      074742 012746 053560      MOV      #TABFUL,-(SP)
      074746 012746 000002      MOV      #2,-(SP)
      074752 010600      MOV      SP,RO
      074754 104417      TRAP    C$PNTF
      074756 062706 000006      ADD     #6,SP
4175 074762 005037 050500      30$:    CLR      S.NREC        ; CLEAR SUMMARY DATA COUNTERS
4176 074766 005037 050476      CLR      S.REC
4177 074772 005037 050502      CLR      S.LEN
4178 074776 005037 050504      CLR      S.COMP
4179 075002 005037 050506      CLR      S.BYTE
4180 075006 005037 050510      CLR      S.XFER
4181 075012      RETURN
4182

```

4184
4185
4186
4187
4188
4189
4190
4191
4192
4193
4194
4195
4196
4197
4198
4199
4200
4201
4202
4203
4204
4205
4206
4207 075014
4208 075014
4209 075016 010546
4210 075020 010102
4211 075022 062702 000002
4212 075026 012703 075200
4213 075032 012704 075130
4214 075036 012705 075132
4215 075042 012737 000012 075116
4216 075050 005037 075214
4217 075054 161411
4218 075056 005612
4219 075060 161512
4220 075062 002403
4221 075064 005237 075214
4222 075070 000771
4223 075072 062411
4224 075074 005512
4225 075076 062412
4226 075100 022525
4227 075102 052737 000060 075214
4228 075110 113723 075214
4229 075114 005327
4230 075116 000000
4231 075120 001353
4232 075122 105023
4233 075124 012605
4234 075126
4235
4236 075130 145000
4237 075132 035632
4238 075134 160400
4239 075136 002765
4240 075140 113200

.SBTTL BINDEC CONVERT A 32 BIT BINARY NUMBER TO DECIMAL

```

:--*
: FUNCTIONAL DESCRIPTION:
:   THIS SUBROUTINE CONVERTS A 32 BIT BINARY NUMBER TO
:   A DECIMAL NUMBER REPRESENTED AS AN ASCIZ STRING.
:
: INPUTS -   P1 - THE ADDRESS OF THE FIRST WORD OF BINARY DATA
:             BITS 0-15. THE SECOND WORD, BITS 16-31, IS
:             EXPECTED TO IMMEDIATELY FOLLOW THE FIRST WORD.
:
: OUTPUTS -  THE ASCII STRING WILL BE LOCATED STARTING AT DECSTR
:
: SIDE EFFECTS - NONE
:
: REGISTER USAGE - R1 POINTS TO BITS 0-15 OF BINARY DATA
:                  R2 POINTS TO BITS 16-31 OF BINARY DATA
:                  R3 POINTS TO THE OUTPUT STRING
:                  R4 POINTS TO THE POWERS OF 10 TABLE
:---*
    
```

```

BINDEC::
    P:POP R1 ; PUT ADDRESS OF BINARY WORD INTO R1
    MOV R5, -(SP)
    MOV R1, R2 ; PUT ADDRESS OF SECOND WORD INTO R2
    ADD #2, R2
    MOV #DECSTR, R3 ; PUT ADDRESS OF OUPUT STRING INTO R3
    MOV #TENPWR, R4 ; ADDRESS OF TEN POWER TABLE
    MOV #TENPWR+2, R5
    MOV #10, #4#
    1#: CLR PART ; CLEAR PARTIAL COUNTER
    2#: SUB (R4), (R1) ; SUBTRACT 10 POWER
        SBC (R2)
        SUB (R5), (R2)
    BLT 3# ; BRANCH IF 10 POWER TOO LARGE
    INC PART ; ELSE ADD 1 TO PARTIAL
    BR 2# ; LOOP
    3#: ADD (R4)+, (R1) ; RESTORE BINARY WORDS
        ADC (R2) ; AND POINT R4 TO NEXT TABLE ENTRIES
        ADD (R4)+, (R2)
    CMP (R5)+, (R5)+
    BIS #'0, PART ; CHANGE PARTIAL TO ASCII
    MOVB PART, (R3)+ ; AND PUT INTO OUTPUT STRING
    DEC (PC)+ ; HAVE WE DONE ALL 10 DIGITS
    4#: .WORD 0
        BNE 1# ; IF NO, BRANCH
        CLRB (R3)+ ; IF YES, TERMINATE WITH ZERO
    MOV (SP)+, R5
    RETURN

TENPWR: 145000 ; 1.0 E09
        35632
        160400 ; 1.0 E08
        2765
        113200 ; 1.0 E07
    
```

4241	075142	000230	230	
4242	075144	041100	041100	: 1.0 E06
4243	075146	000017	17	
4244	075150	103240	103240	: 1.0 E05
4245	075152	000001	1	
4246	075154	023420	23420	: 1.0 E04
4247	075156	000000	0	
4248	075160	001750	1750	: 1.0 E03
4249	075162	000000	0	
4250	075164	000144	144	: 1.0 E02
4251	075166	000000	0	
4252	075170	000012	12	: 1.0 E01
4253	075172	000000	0	
4254	075174	000001	1	: 1.0 E00
4255	075176	000000	0	
4256				
4257	075200		DECSTR:: .BLKB 12.	: 12 BYTES FOR ASCIZ OUTPUT STRING
4258	075214	000000	PART:: .WORD 0	: PARTIAL COUNTER
4259				


```

4261
4262          .SBTTL  COMMAND LINE TRAVERSE ROUTINES
4263
4264          ;++
4265          ;      P$TRV SUBROUTINE
4266          ;
4267          ;PARSE THE COMMAND LINE SUBROUTINE
4268          ;TAKE ACTIONS (VIA ACTION TREE) AS PARSING LINE
4269          ;PARSING DIRECTIONS FROM "CLI PARSING NODES"
4270          ;   REGS USED:
4271          ;
4272          ;       R1,R5=SCRATCH                                P$NUM=NUMERIC CODE FROM DATA
4273          ;       R2=ACTION CODE PARAMETER FROM TREE
4274          ;       R3=PARSE TREE POINTER
4275          ;       R4=INPUT STRING POINTER
4276          ; CALLING SEQUENCE:
4277          ;       JSR      PC,P$TRV
4278          ;--
4279
4280 075216      P$TRV:
4281 075216      013704  003144      MOV      P$BUFA,R4
4282 075222      013703  003146      MOV      P$TREE,R3
4283 075226      121327  000003      P$TR5:  CMPB   (R3),#3          ;SEE IF ONE OF FIRST THREE SPECIAL CODES
4284 075232      003405          BLE     5$                ;IF YES, DON'T CHECK INPUT STRING
4285 075234      105714          TSTB   (R4)              ;SEE IF ANY CHARS LEFT IN INPUT STRING
4286 075236      001441          BEQ    P$EXIT            ;BR IF NO
4287 075240      121327  000013      CMPB   (R3),#11.        ;SEE IF SPECIAL CLI CHAR CODE OR ASCII
4288 075244      003023          BGT    20$              ;BR IF REGULAR ASCII CHAR.
4289 075246      111301          5$:   MOVB   (R3),R1        ;GET SPECIAL CHAR CODE INTO R5
4290 075250      006301          ASL    R1
4291 075252      016101  075266      MOV    10$(R1),R1       ;BUILD TRAVERSE ROUTINE ADDRESS
4292 075256      062701  075266      ADD    #10$,R1
4293 075262      004711          JSR    PC,(R1)          ;JSR TO SPECIAL CLI TRAVERSE ROUTINE
4294 075264      000760          BR     P$TR5           ;GO SEE IF MORE OF STRING LEFT
4295
4296
4297 075266      000114          10$:  .WORD   TRVERR-10$    ;TRAVERSE TABLE FOR "CLI FUNCTIONS"
4298 075270      000134          .WORD   TRVEXI-10$     ;1
4299 075272      000152          .WORD   TRVBR-10$      ;2
4300 075274      000162          .WORD   TRVBIF-10$     ;3
4301 075276      000204          .WORD   TRVSPA-10$     ;4
4302 075300      000270          .WORD   TRVNUM-10$     ;5
4303 075302      000612          .WORD   TRVALP-10$     ;6
4304 075304      000656          .WORD   TRVALN-10$     ;7
4305 075306      000270          .WORD   TRVOCT-10$    ;8
4306 075310      000256          .WORD   TRVDEC-10$    ;9
4307 075312      000744          .WORD   TRVSTR-10$    ;10
4308
4309          ;NOT A SPECIAL CODE
4310
4311 075314      121314          20$:  CMPB   (R3),(R4)      ;SEE IF FIRST CHAR OF STRING IS A MATCH
4312 075316      001403          BEQ    22$              ;BR IF A MATCH
4313 075320      004737  075364      JSR    PC,TRVBRC        ;IF NOT A MATCH, GO TAKE MISS BRANCH
4314 075324      000740          BR     P$TR5           ; THEN GO BACK PT'G TO MISS NODE
4315 075326      005204          22$:  INC    R4              ;IF A MATCH, INCR. CHAR POINTER
4316 075330      004737  075344      JSR    PC,TRVACT        ; GO DO ACTION DEFINED BY
4317 075334      062703  000004      ADD    #4,R3           ; ACTION CODE IN CLI NODE, THEN

```

```

4318                                     ; ADJUST PTR TO NEXT CLI NODE
4319 075340 000732                       BR      P$TR5
4320
4321 075342 000207                       P$EXIT: RTS      PC      ;RETURN FROM PARSER
4322
4323                                     ;-----
4324
4325                                     ;GOTO USER ACTION ROUTINE
4326 075344 116302 000001                 TRVACT: MOV      1(R3),R2      ;GET ACTION CODE FROM CLI NODE
4327 075350 042702 177400                 BIC      #177400,R2      ;CLEAR ANY SIGN EXTENSION
4328 075354 013701 003150                 MOV      P$ACT,R1      ;GET ADDRESS OF CLI ACTION ROUTINE
4329 075360 004711                         JSR      PC,(R1)      ;GO DO ACTION DEFINED BY CODE
4330 075362 000207                         RTS      PC      ;RETURN TO CALLING CODE
4331
4332                                     ;TAKE BRANCH IN TREE
4333 075364 016301 000002                 TRVBRC: MOV     2(R3),R1      ;GET BRANCH DISPLACEMENT FROM TREE
4334 075370 060103                         ADD      R1,R3      ; AND POINT R3 TO THE "MISS" NODE
4335 075372 000207                         RTS      PC      ; RETURN TO P$TRV
4336
4337                                     ;NO BRANCH TAKEN
4338 075374 062703 000004                 TRVNOB: ADD     #4,R3      ;THINGS OK, UPDATE R3 TO POINT TO NEXT
4339 075400 000207                         RTS      PC      ; NODE AND RETURN TO P$TRV
4340
4341                                     ;-----
4342                                     ;ERROR HANDLING
4343 075402 004737 075344                 TRVERR: JSR     PC,TRVACT      ;TAKE ERROR ACTION
4344 075406 112737 177777 003161         MOV      #-1,P$GDBD      ;SET ERROR RETURN FLAG
4345 075414 005726                         TST     (SP)+      ;GET RID OF "JSR PUSH TO TRVERR"
4346 075416 000137 075342                 JMP      P$EXIT      ;RETURN DIRECT TO EXIT OF P$TRV ROUTINE
4347
4348                                     ;EXIT ACTION CODE
4349 075422 004737 075344                 TRVEXI: JSR     PC,TRVACT      ;TAKE EXIT ACTION
4350 075426 105037 003161                 CLRB    P$GDBD      ;SET GOOD/BAD FLAG TO "SUCCESS (0)"
4351 075432 005726                         TST     (SP)+      ;GET RID OF "JSR PUSH TO TRVEXI"
4352 075434 000137 075342                 JMP      P$EXIT      ;RETURN DIRECT TO EXIT OF P$TRV ROUTINE
4353
4354                                     ;BRANCH ACTION CODE
4355 075440 004737 075344                 TRVBR: JSR     PC,TRVACT      ;GO TAKE BRANCH ACTION
4356 075444 000137 075364                 JMP      TRVBRC
4357
4358                                     ;BRANCH-IF ACTION CODE
4359 075450 004737 075344                 TRVBIF: JSR     PC,TRVACT
4360 075454 105737 003161                 TSTB   P$GDBD      ;SEE IF P$GDBD SET OR CLEARED BY ACTION
4361 075460 001402                         BEQ     1$      ;IF CLEAR FALL THRU TO NEXT NODE
4362 075462 000137 075364                 JMP     TRVBRC      ;ELSE TAKE THE "MISS" BRANCH
4363 075466 000137 075374                 1$: JMP     TRVNOB      ;JUST UPDATE TO NEXT NODE IF THINGS OK
4364
4365                                     ;SPACE ACTION CODE
4366 075472 005001                         TRVSPA: CLR     R1      ;CLEAR "SPACE OR TAB FOUND" FLAG
4367 075474 121427 000011                 1$: CMPB   (R4),#11      ;SEE IF CHAR. IN CMD LINE= TAB
4368 075500 001003                         BNE     2$      ;BR IF NO, NOT A TAB
4369 075502 005204                         INC     R4      ;INC INPUT STRING POINTER
4370 075504 005201                         INC     R1      ;INDICATE A TAB FOUND
4371 075506 000772                         BR      1$      ;GO CHECK NEXT CHAR
4372
4373 075510 121427 000040                 2$: CMPB   (R4),#40      ;SEE IF CHAR. IN CMD LINE= SPACE
4374 075514 001003                         BNE     10$      ;BR IF NO, NON-SPACE OR NON-TAB CHAR.

```

4375	075516	005204			INC	R4		;INC INPUT STRING POINTER
4376	075520	005201			INC	R1		;INDICATE A SPACE FOUND
4377	075522	000764			BR	1\$;GO CHECK NEXT CHAR
4378	075524	005701		10\$:	TST	R1		;SEE IF ANY SPACES OR TABS FOUND
4379	075526	001404			BEQ	15\$;BR IF NO, TAKE NO ACTION
4380	075530	004737	075344		JSR	PC,TRVACT		;GO TAKE ACTION IF ANY FOUND
4381	075534	000137	075374		JMP	TRVNOB		;JUST GO UPDATE R3 TO NEXT NODE IF OK
4382	075540	000137	075364		JMP	TRVBRC		;TAKE BRANCH (MISS) IF NONE FOUND
4383								
4384								
4385	075544	012737	000012	003156	TRVDEC:	MOV	#10.,P\$RADX	;USE DECIMAL AS RADIX AND ASSUME +
4386	075552	000137	075564		JMP	TRVNMA		
4387	075556				TRVOCT:		;(SAME AS TRVNUM SINCE DEFAULT RADIX IS OCTAL)	
4388	075556	012737	000010	003156	TRVNUM:	MOV	#8.,P\$RADX	;USE OCTAL AS RADIX AND ASSUME +
4389	075564				TRVNMA:	PUSH	R5	
4390	075566	005001			CLR	R1		;CLEAR DIGIT COUNTER
4391	075570	121427	000053		CMPB	(R4),#'		;SEE IF THERE'S A + SIGN THERE
4392	075574	001001			BNE	10\$; BR IF NO
4393	075576	000406			BR	11\$; ELSE P\$RADX ALREADY SAYS +, JUST BR
4394	075600	121427	000055		10\$:	CMPB	(R4),#'-	;SEE IF THERE'S A - SIGN THERE
4395	075604	001004			BNE	1\$; BR IF NO
4396	075606	112737	177777	003157	MOVB	#-1,P\$RADX+1		;SET "MINUS FLAG" (HI BYTE OF P\$RADX)
4397	075614	005204			11\$:	INC	R4	;BUMP R4 TO POINT TO FIRST CHAR
4398								
4399	075616	121427	000060		1\$:	CMPB	(R4),#60	;SEE IF CHAR. LESS THAN A "0"
4400	075622	002434			BLT	2\$;BR IF YES (NOT NUMERIC)
4401	075624	121427	000067		CMPB	(R4),#67		;SEE IF CHAR. GREATER THAN A "7"
4402	075630	003426			BLE	13\$; BR IF YES
4403	075632	123727	003156	000012	CMPB	P\$RADX,#10.		;SEE IF IN DECIMAL MODE
4404	075640	001417			BEQ	12\$; BR IF YES (CAN USE HIGHER LIMIT)
4405	075642	121427	000071		CMPB	(R4),#71		;SEE IF DIGIT WAS A 8 OR 9
4406	075646	003022			BGT	2\$;BR IF NON-NUMERIC
4407	075650				PRINTF	#CLIBRX		;ELSE WAS A 8 OR 9 WHEN IN OCTAL RADIX
	075650	012746	052554				MOV	#CLIBRX,-(SP)
	075654	012746	000001				MOV	#1,-(SP)
	075660	010600					MOV	SP,R0
	075662	104417					TRAP	C\$PNTF
	075664	062706	000004				ADD	#4,SP
4408	075670	112737	177777	003161	MOVB	#-1,P\$GDBD		;SET ERROR RETURN FLAG
4409	075676	000475			BR	5\$; PRINT ERROR AND TAKE MISS
4410								
4411	075700	121427	000071		12\$:	CMPB	(R4),#71	;SEE IF CHAR. GREATER THAN A "9"
4412	075704	003003			BGT	2\$;BR IF YES (NOT NUMERIC)
4413	075706	005204			13\$:	INC	R4	;UPDATE CMD LINE PTR TO NEXT CHAR.
4414	075710	005201			INC	R1		;INDICATE A NUMERIC FOUND
4415	075712	000741			BR	1\$;GO LOOK AT NEXT CHAR.
4416								
4417	075714	005701			2\$:	TST	R1	;SEE IF FOUND ANY NUMERICS
4418	075716	001465			BEQ	5\$;BR IF NO, TAKE "MISS" BRANCH
4419	075720	010405			MOV	R4,R5		;GET POINTER TO START OF NUMERIC STRING
4420	075722	160105			SUB	R1,R5		
4421	075724	005037	003154		CLR	P\$NUM		;CLEAR LOC. WHERE VALUE WILL BE STORED
4422	075730	112502			3\$:	MOVB	(R5)+,R2	;GET ASCII CHAR AND CONVERT IT TO A #
4423	075732	162702	000060		SUB	#60,R2		
4424	075736	006337	003154		ASL	P\$NUM		;SHIFT CURRENT VALUE TO MAKE ROOM
4425	075742	103440			BCS	7\$;ERROR IF NUMBER TOO BIG
4426	075744	013737	003154	003152	MOV	P\$NUM,P\$CNT		;SAVE FOR LATER IN CASE DECIMAL RADIX

4427	075752	006337	003154		ASL	P\$NUM		
4428	075756	103432			BCS	7\$;ERROR IF NUMBER TOO BIG
4429	075760	006337	003154		ASL	P\$NUM		
4430	075764	103427			BCS	7\$;ERROR IF NUMBER TOO BIG
4431	075766	123727	003156	000012	CMPB	P\$RADX,#10.		;SEE IF DECIMAL RADIX
4432	075774	001004			BNE	4\$;BR IF NOT EQUAL
4433	075776	063737	003152	003154	ADD	P\$CNT,P\$NUM		
4434	076004	103417			BCS	7\$;ERROR IF NUMBER TOO BIG
4435	076006	060237	003154		4\$: ADD	R2,P\$NUM		
4436	076012	103414			BCS	7\$;ERROR IF NUMBER TOO BIG
4437	076014	005301			DEC	R1		
4438	076016	001344			BNE	3\$		
4439	076020	105737	003157		TSTB	P\$RADX+1		;SEE IF NUM WAS PRECEDED BY A - SIGN
4440	076024	001402			BEQ	15\$; BR IF NO
4441	076026	005437	003154		NEG	P\$NUM		; ELSE NEGATE THE NUMBER BEFORE LEAVING
4442	076032				15\$: POP	R5		;RESTORE R5
4443	076034	004737	075344		JSR	PC,TRVACT		;SINCE NUMERIC FOUND, GO TAKE ACTION
4444	076040	000137	075374		JMP	TRVNOB		;GO POINT R3 TO NEXT NODE
4445								
4446	076044				7\$: PRINTF	#CLINBG		;PRINT NUMBER TOO BIG ERROR
	076044	012746	052527				MOV	#CLINBG,-(SP)
	076050	012746	000001				MOV	#1,-(SP)
	076054	010600					MOV	SP,R0
	076056	104417					TRAP	C\$PNTF
	076060	062706	000004				ADD	#4,SP
4447	076064	112737	177777	003161	5\$: MOVB	#-1,P\$GDBD		;SET ERROR RETURN FLAG
4448	076072				POP	R5		;RESTORE R5
4449	076074	000137	075364		JMP	TRVBRC		;TAKE "MISS" BRANCH
4450								
4451								
4452	076100	005001			TRVALP: CLR	R1		;CLEAR ALPHA FOUND FLAG
4453	076102	121427	000101		1\$: CMPB	(R4),#101		;SEE IF CHAR. LESS THAN A "A"
4454	076106	002406			BLT	2\$;BR IF YES (NOT ALPHA)
4455	076110	121427	000132		CMPB	(R4),#132		;SEE IF CHAR. GREATER THAN A "Z"
4456	076114	003003			BGT	2\$;BR IF YES (NOT ALPHA)
4457	076116	005204			INC	R4		;UPDATE CMD LINE PTR TO NEXT CHAR
4458	076120	005201			INC	R1		;INDICATE AN ALPHA WAS FOUND
4459	076122	000767			BR	1\$;GO LOOK AT NEXT CHAR.
4460	076124	005701			2\$: TST	R1		;SEE IF ANY ALPHA'S WERE FOUND
4461	076126	001404			BEQ	3\$;BR IF NO
4462	076130	004737	075344		JSR	PC,TRVACT		;IF ANY FOUND TAKE ACTION
4463	076134	000137	075374		JMP	TRVNOB		;THEN UPDATE R3 TO NEXT NODE -NO BRANCH
4464	076140	000137	075364		3\$: JMP	TRVBRC		;NONE FOUND, TAKE MISS BRANCH
4465								
4466	076144	005001			TRVALN: CLR	R1		;CLEAR ALPHANUM FOUND FLAG
4467	076146	121427	000060		10\$: CMPB	(R4),#60		;SEE IF CHAR. LESS THAN A "0"
4468	076152	002417			BLT	2\$;BR IF YES (NOT NUMERIC OR ALPHA)
4469	076154	121427	000072		CMPB	(R4),#72		;SEE IF CHAR. GREATER THAN A "9"
4470	076160	003003			BGT	1\$;BR IF YES (NOT NUMERIC)
4471	076162	005204			INC	R4		;UPDATE CMD LINE PTR TO NEXT CHAR.
4472	076164	005201			INC	R1		;INDICATE A NUMERIC FOUND
4473	076166	000767			BR	10\$;GO LOOK AT NEXT CHAR.
4474	076170	121427	000101		1\$: CMPB	(R4),#101		;SEE IF CHAR. LESS THAN A "A"
4475	076174	002406			BLT	2\$;BR IF YES (NOT ALPHA)
4476	076176	121427	000132		CMPB	(R4),#132		;SEE IF CHAR. GREATER THAN A "Z"
4477	076202	003003			BGT	2\$;BR IF YES (NOT ALPHA)
4478	076204	005204			INC	R4		;UPDATE CMD LINE PTR TO NEXT CHAR

```

4479 076206 005201           INC      R1           ;INDICATE AN ALPHA FOUND
4480 076210 000756           BR       10$         ;GO LOOK AT NEXT CHAR.
4481 076212 005701           2$:   TST      R1           ;SEE IF ANY ALPHANUM'S WERE FOUND
4482 076214 001404           BEQ     3$           ;BR IF NO
4483 076216 004737 075344   JSR     PC,TRVACT   ;IF ANY FOUND TAKE ACTION
4484 076222 000137 075374   JMP     TRVNOB      ;THEN UPDATE R3 TO NEXT NODE -NO BRANCH
4485 076226 000137 075364   3$:   JMP     TRVBRC      ;NONE FOUND, TAKE MISS BRANCH
4486
4487
4488
4489 076232           TRVSTR: PUSH     R5           ;SAVE R5
4490 076234 010401           MOV     R4,R1       ;POINT R1 TO CMD STRING
4491 076236 010305           MOV     R3,R5
4492 076240 062705 000006   ADD     #6,R5       ;POINT R5 TO MATCH STRING FROM CLI NODE
4493 076244 005037 003152   CLR     P%CNT       ;CLEAR CHAR MATCH COUNT
4494 076250 105715           2$:   TSTB    (R5)        ;SEE IF END OF MATCH STRING YET
4495 076252 001411           BEQ     10$         ;BR IF YES
4496 076254 105711           TSTB    (R1)        ;SEE IF END OF CMD LINE YET
4497 076256 001407           BEQ     10$         ;BR IF YES
4498 076260 121115           CMPB    (R1),(R5)   ;SEE IF CHARACTERS MATCH
4499 076262 001005           BNE     10$         ;BR IF NO
4500 076264 005237 003152   INC     P%CNT       ;MATCH -INCREMENT MATCH COUNT
4501 076270 005201           INC     R1           ;UPDATE STRING POINTERS
4502 076272 005205           INC     R5
4503 076274 000765           BR      2$           ;BR TO CONTINUE CHECKING CHARS.
4504
4505 076276 005737 003152   10$:  TST     P%CNT       ;WHEN DONE SEE IF ANY MATCHES FOUND
4506 076302 001407           BEQ     15$         ;BR IF NO, GO TAKE THE MISS BRANCH
4507 076304 010104           MOV     R1,R4       ;POINT CMD POINTER TO END OF STRING &
4508 076306           POP     R5           ;RESTORE R5
4509 076310 004737 075344   JSR     PC,TRVACT   ;IF A MATCH FOUND, GO DO MATCH ACTION
4510 076314 066303 000004   ADD     4(R3),R3    ;UPDATE R3 TO NEXT NODE (NO BRANCH)
4511 076320 000207           RTS     PC           ; (NO RETURN THRU TRVNOB SINCE DIFFERENT
4512                                     ; DISPLACEMENT DUE TO MATCH STRING)
4513 076322           15$:  POP     R5           ;RESTORE R5
4514 076324 000137 075364   JMP     TRVBRC      ; GO TAKE BRANCH
4515                                     ; (PARSED OK), -1 IF ILL CMD.....
4516
4517
4518           ;---+
4519           ; TRVADR TRAVSE COMMAND LINE INPUT ADDRESS
4520           ;
4521           ; THIS ROUTINE IS CALLED BY TWO DIFFERENT ACTION ROUTINES. THE
4522           ; NODE ACTION ROUTINE CALLS IT TO PARSE THROUGH THE NODE
4523           ; ADDRESS INPUT BY THE OPERATOR. THE OPRSEL ACTION ROUTINE
4524           ; CALLS TRVADR TO PARSE THROUGH THE "OPERATOR SELECTED" MESSAGE
4525           ; WHICH HAS BEEN INPUT IN THE COMMAND LINE. FOR A NODE ADDRESS,
4526           ; THE ROUTINE LOOKS FOR A '/' AS A DELIMETER FOR THE ADDRESS,
4527           ; AND REPLACES THE / WITH A NULL BYTE FOR USE BY THE ADDRESS
4528           ; PACKING ROUTINE. WHEN CALLED BY THE OPRSEL ROUTINE, A '/'
4529           ; IS EXPECTED AS THE DELIMETER FOR THE OPERATOR SELECTED MESSAGE.
4530           ; IF A NULL STRING IS ENTERED, AN ERROR MESSAGE IS PRINTED.
4531           ;
4532           ; INPUTS - R4 - POINTS TO THE BEGINING OF THE ADDRESS
4533           ; OR MESSAGE IN THE COMMAND LINE
4534           ; OUTPUTS - SUMMARIZED IN TABLE BELOW
4535           ;
4536           ; COMMAND LINE OUTPUTS
    
```


4536	:	INPUT CONDITION :	P%GDBD	R4 POINTS TO	CFLAG CONTAINS	P%MERR
4537	:	ILLEGAL CHAR.	-1	ILL. CHAR.		N/A
4538	:	ADR./ASSIST	0	END OF LINE	CASIST	N/A
4539	:	ADR./TARGET				
4540	:	ADR./	0	END OF LINE	CTARGET	N/A
4541	:	ADR.				
4542	:	ADR./CHAR. OR				
4543	:	"OPR SEL/CHAR.				
4544	:	OTHER THAN "A"	-1	/	CTARGET	N/A
4545	:	"T" OR BLANK				
4546	:	" "	0	CHAR. AFTER "		-1
4547	:	"OPR SEL"	0	CHAR. AFTER "	OPRSEL	0
4548	:					
4549	:					
4550	:	CALLING PROCEDURE -	JSR	PC,TRVADR		
4551	:	REGISTER USAGE -				
4552	:					
4553	:					
4554	:					
4555	:					
4556	:					

R1 IS USED AS A COUNTER TO REPORT ERROR MESSAGES
IF NULL STRINGS ARE ENTERED.
R4 POINTS TO THE NEXT CHAR. IN THE COMMAND LINE

```

4557 076330 005001 TRVADR: CLR R1 ;CLEAR HEX DIGIT FOUND FLAG
4558 076332 121427 000000 1$: CMPB (R4),#0 ;SEE IF NUL CHAR.
4559 076336 001423 BEQ 20$ ; IF YES, RETURN
4560 076340 121427 000040 CMPB (R4),#40 ;SEE IF ILLEGAL CHARACTER
4561 076344 002414 BLT 10$ ;IF YES, BRANCH TO ERROR ROUTINE
4562 076346 121427 000042 CMPB (R4),#42 ;SEE IF CHAR. IS A ' "'
4563 076352 001454 BEQ 40$ ;IF YES ,BRANCH TO 40$
4564 076354 121427 000057 CMPB (R4),#57 ;SEE IF CHAR. IS A "/"
4565 076360 001420 BEQ 30$ ;BRANCH IF YES
4566 076362 121427 000132 CMPB (R4),#132 ;SEE IF CHAR. GREATER THAN "F"
4567 076366 003003 BGT 10$ ; IF YES, ILLEGAL CHAR.
4568 076370 005204 INC R4 ;UPDATE CMD LINE POINTER TO NEXT CHAR.
4569 076372 005201 INC R1 ;INCIDATE A VALID CHAR. FOUND
4570 076374 000756 BR 1$ ;LOOK AT NEXT CHAR.
4571 076376 112737 177777 003161 10$: MOVB #-1,P%GDBD ;SET ERROR FLAG
4572 076404 000464 BR 50$ ;RETURN
4573 076406 005701 20$: TST R1 ;SEE IF VALID CHARACTERS FOUND
4574 076410 001772 BEQ 10$ ; IF NO, ILLEGAL CHAR.
4575 076412 012737 000000 003672 25$: MOV #CTARGET,CFLAG ;SET TARGET FLAG
4576 076420 000456 BR 50$ ;RETURN
4577 076422 005701 30$: TST R1 ;SEE IF VALID CHARACTERS FOUND
4578 076424 001764 BEQ 10$ ; IF NO, ILLEGAL CHAR.
4579 076426 112714 000000 MOVB #0,(R4) ; IF YES, REPLACE "/" WITH NULL CHAR.
4580 076432 005204 INC R4 ;UPDATE CMD. LINE POINTER TO NEXT CHAR.
4581 076434 121427 000000 CMPB (R4),#0 ;IS NEXT CHAR. NULL
4582 076440 001764 BEQ 25$ ; IF YES, TAKE DEFAULT OF TARGET
4583 076442 121427 000101 CMPB (R4),#'A ;IS NEXT CHAR. "A"
4584 076446 001412 BEQ 35$ ; IF YES, BR 35$
4585 076450 121427 000124 CMPB (R4),#'T ;IS NEXT CHAR. "T"
4586 076454 001756 BEQ 25$ ; IF YES, SET TARGET FLAG
4587 076456 112737 177777 003161 MOVB #-1,P%GDBD ; ELSE, SET ERROR FLAG.
4588 076464 005304 DEC R4 ; READJUST COMMAND LINE POINTER
4589 076466 112714 000057 MOVB #/, (R4) ; AND REPLACE / IN CMD LINE TO FIX ERROR
4590 076472 000747 BR 25$ ; SET TARGET FLAG AND RETURN
4591 076474 012737 000001 003672 35$: MOV #CASIST,CFLAG ;SET ASSIST FLAG
4592 076502 000425 BR 50$
    
```



```

COMMAND LINE TRAVERSE ROUTINES
4593 076504 005701          40$:  TST      R1          ;SEE IF ANY CHARACTERS TYPED
4594 076506 001407          BEQ      45$          ;IF NO, BRANCH TO 45$
4595 076510 112714 000000    MOVB     #0,(R4)      ;ELSE, REPLACE ' ' WITH NULL
4596 076514 012737 000006 003672  MOV     #OPRSEL,CFLAG ;SET OPERATOR SELECTED FLAG
4597 076522 005204          INC      R4
4598 076524 000414          BR       50$
4599 076526          45$:  PRINTF   #NULSTR    ;RETURN
                                ;PRINT NULL STRING ERROR MESSAGE
                                MOV     #NULSTR,-(SP)
                                MOV     #1,-(SP)
                                MOV     SP,R0
                                TRAP    C$PNTF
                                ADD     #4,SP
                                076526 012746 053362
                                076532 012746 000001
                                076536 010600
                                076540 104417
                                076542 062706 000004
4600 076546 112737 177777 003163  MOVB     #-1,P$MERR    ;SET OPER. SELECTED MSG. ERROR FLAG
4601 076554 005204          INC      R4          ;MOVE CMD. LINE POINTER TO NEXT CHAR.
4602 076556 000207          50$:  RTS       PC          ;RETURN
4603
4604
4605
4606
4607
4608
4609
4610
4611
4612
4613
4614 076560          .SBTTL  REPORT CODING SECTION
4615 076560
4616
4617
4618
4619
4620
4621
4622
4623
4624
4625
4626
4627
4628 076560 004737 101710          JSR      PC,ACTSUM
4629 076564          EXIT     RPT
                                .WORD   J$JMP
                                .WORD   L10006-2-.
                                076564 000167
                                076566 000000
4630
4631
4632
4633
4634
4635
4636

```

; THE REPORT CODING SECTION CONTAINS THE
; "PRINTS" CALLS THAT GENERATE STATISTICAL REPORTS.
;--

; THIS SECTION, WHICH IS OPTIONAL, CONTAINS THE CODE FOR PRINTING
; STATISTICAL INFORMATION GATHERED BY THE DIAGNOSTIC. IT IS
; EXECUTED BY THE OPERATOR COMMAND "PRINT" OR BY THE MACRO CALL
; "DORPT". USE THE PRINTS MACRO TO PRINT THE INFORMATION.
; USE FORMAT STATEMENTS AS IN THE PRINTB/PRINTX MACROS. IT IS
; THE PROGRAMMER'S RESPONSIBILITY TO DEVISE AND IMPLEMENT THE
; FORM AND CONTENT OF THE STATISTICS.

; INSERT LOCAL STORAGE THAT IS USED ONLY
; DURING THE REPORT SECTION.

4637
4638
4639
4640
4642
4643
4644
4645

076570
076570
076570 104425

: INSERT MESSAGES THAT ARE USED ONLY
: DURING THE REPORT SECTION.

.EVEN

ENDRPT

L10006: TRAP C\$RPT

4647
4648
4649
4650
4651
4652
4653
4654
4655
4656
4657
4658
4659
4660
4661
4663
4664
4665
4666
4667
4668
4669
4670
4671
4672
4673

076572
076572
076572 177777
076574 177777
076576 177777

```
.SBTTL PROTECTION TABLE
;***
; THIS TABLE IS USED BY THE RUNTIME SERVICES
; TO PROTECT THE LOAD MEDIA.
;---
                                BGNPROT
                                L#PROT::
                                -1      ;OFFSET INTO P-TABLE FOR CSR ADDRESS
                                -1      ;OFFSET INTO P-TABLE FOR MASSBUS ADDRESS
                                -1      ;OFFSET INTO P-TABLE FOR DRIVE NUMBER
                                ENDPROT
;*****
; INSERT BYTE OFFSET FOR DATA NOTED IN COMMENTS ABOVE. (OFFSET
; REFERS TO THE NUMBER OF BYTES FROM THE BEGINNING OF A PTABLE
; ENTRY TO THE ITEM IN QUESTION.) IF THE PARTICULAR
; ITEM DOES NOT APPLY, LEAVE ENTRY AS -1. WHEN THE RUNTIME
; SERVICES EXECUTES A GPHARD, IT USES THESE OFFSETS (IF NOT
; SET TO -1) TO GET THE ITEMS AND COMPARE WITH THOSE SAVED
; IN THE XXDP+ MONITOR. IF THE UNIT BEING REQUESTED MATCHES THE
; LOAD DEVICE, THE RUNTIME SERVICES RETURN AN INCOMPLETE FLAG ON
; THE GPHARD.
;*****
```


4676
4677
4678
4679
4680
4681
4682
4683 076600
076600
4684
4686
4687
4688
4689
4690
4691
4692
4693
4694
4695
4696
4697
4698
4699
4700
4701
4702
4703
4704
4705
4706
4708
4709 076600 022737 000020 003672
4710 076606 001004
4711 076610 005037 003672
4712 076614 000137 100130
4713 076620
076620 012700 000040
076624 104447
4714 076626
076626 103424
4715 076630
076630 012700 000037
076634 104447
4716 076636
076636 103002
4717 076640 000137 100046
4718 076644
076644 012700 000036
076650 104447
4719 076652
076652 103002
4720 076654 000137 100046
4721 076660
076660 012700 000035
076664 104447
4722 076666

```
.SBTTL INITIALIZE SECTION
;***
; THE INITIALIZE SECTION CONTAINS THE CODING THAT IS PERFORMED
; AT THE BEGINNING OF EACH PASS.
;--

      BGNINIT

                                L$INIT::

;*****
; THE INITIALIZE CODE IS EXECUTED UNDER FIVE CONDITIONS.  THERE
; ARE SUPERVISOR EVENT FLAGS THAT ARE USED TO LET THE
; DIAGNOSTIC KNOW UNDER WHICH CONDITION THE EXECUTION IS TAKING
; PLACE.  THE EVENT FLAGS ARE READ USING THE "READEF" MACRO.
; THE CONDITIONS UNDER WHICH THE INIT CODE IS EXECUTED AND THE
; CORRESPONDING EVENT FLAGS ARE:
; START COMMAND          EF.START
; RESTART COMMAND       EF.RESTART
; CONTINUE COMMAND      EF.CONTINUE
; POWERDOWN/POWERUP    EF.PWR
; NEW PASS              EF.NEW
;
; EXAMPLE OF EVENT FLAG USE:
; READEF #EF.START
; BCOMPLETE             STARTCODE
;
; DURING THE INIT CODE, USE THE "GPHARD" MACRO TO OBTAIN P-TABLE
; INFORMATION FOR DEVICE TESTING.  GET ONE UNIT'S INFORMATION IF
; THIS IS A SEQUENTIAL DIAGNOSTIC.  GET INFORMATION ON ALL
; UNITS AVAILABLE FOR TESTING IF THIS IS AN EXERCISER.  THE NUMBER
; OF UNITS AVAILABLE IS IN A HEADER LOCATION: "L$UNIT".
;*****

INIT:  CMP    #CEXIT,CFLAG          ;SEE IF EXIT COMMAND TYPED
      BNE    INIT1                 ; IF NO, DO INIT CODE
      CLR    CFLAG                 ; ELSE, CLEAR EXIT FLAG
      JMP    INICLN                ; AND DO CLEANUP
INIT1: READEF #EF.START            ;IF HERE BECAUSE OF "START", DO INIT
                                MOV    #EF.START,RO
                                TRAP   C$REFG
      BCOMPLETE             START
      READEF #EF.RESTART          ;IF HERE BECAUSE OF "RESTART", DO SOME INIT
                                MOV    #EF.RESTART,RO
                                TRAP   C$REFG
      BNCOMPLETE             5$
      JMP    RESTRT
      READEF #EF.CONTINUE        ;IF HERE BECAUSE OF "CONTINUE", EXIT
                                MOV    #EF.CONTINUE,RO
                                TRAP   C$REFG
      BNCOMPLETE             10$
      JMP    RESTRT
      READEF #EF.NEW             ;IF HERE ON NEW PASS, SKIP SOME INIT
                                MOV    #EF.NEW,RO
                                TRAP   C$REFG
      BNCOMPLETE             15$
```

```

076666 103002
4723 076670 000137 100112
4724 076674 000137 100132
4725 076700
4726 076706
076706 104431
076710 010037 047660
4727 076714 013737 047660 047662
4728 076722 062737 000002 047662
4729 076730 012702 003674
4730 076734
076734 012700 000114
076740 104462
076742 010001
4731 076744
076744 103006
4732 076746 004737 067656
4733 076752 012737 000100 003704
4734 076760 000436
4735 076762
076762 012700 000120
076766 104462
076770 010001
4736 076772
076772 103017
4737 076774 004737 067656
4738 077000 062737 000002 003674
4739 077006 012777 001600 104660
4740 077014 162737 000002 003674
4741 077022 012737 000111 003704
4742 077030 000412
4743 077032
077032 012746 062622
077036 012746 000001
077042 010600
077044 104417
077046 062706 000004
4744 077052 000137 100130
4745 077056
077056 012700 000000
077062 104442
077064 010001
4746 077066
077066 103402
4747 077070 000137 100130
4748 077074 012137 047652
4749 077100 012137 047654
4750 077104 012137 047656
4751 077110
077110 013746 047656
077114 012746 071144
077120 013746 047654
077124 012746 000003
077130 104437
077132 062706 000010
4752 077136 013737 047652 047632
4753 077144 013737 047632 047634

```

```

15$:
START:
JMP NEW
JMP INIEXI
I$STACK #1000,SP
MEMORY FRESIZ
MOV FRESIZ,FREMEM
ADD #2,FREMEM
MOV #CLKCSR,R2
CLOCK L,R1
BNCOMPLETE 1$
JSR PC,CLKSET
MOV #LCLKEN,CLKEN
BR 3$
CLOCK P,R1
BNCOMPLETE 2$
JSR PC,CLKSET
ADD #2,CLKCSR
MOV #PCLKCT,#CLKCSR
SUB #2,CLKCSR
MOV #PCLKEN,CLKEN
BR 3$
PRINTF #NOCLK
BNCOMPLETE 4$
JMP INICLN
GPHARD #0,R1
BCOMPLETE 4$
JMP INICLN
MOV (R1)+,UNACSR
MOV (R1)+,UNAVEC
MOV (R1)+,UNAPRI
SETVEC UNAVEC,#UNAIISR,UNAPRI
MOV UNACSR,PCSRO
MOV PCSRO,PCSR1

```

```

BCC 15$
;IF DON'T KNOW WHY WE'RE HERE, EXIT
;SET PARAMETER STACK POINTER
;GET FREE MEMORY INFO
TRAP C$MEM
MOV RO,FRESIZ
;SIZE OF FREE MEMORY IN FRESIZ
;START OF FREE MEMORY IN FREMEM
;SETUP R2 AS A PRT. TO CLOCK INFO. BLOCK
;GET LINE CLOCK INFO
MOV #L,R0
TRAP C$CLK
MOV RO,R1
;IF NONE, SEE IF P CLOCK PRESENT
BCC 1$
;SET UP CLOCK INFO TABLE AND VECTOR
;SET UP THE ENABLE LINE CLOCK DATA
MOV #P,R0
TRAP C$CLK
MOV RO,R1
;IF NO CLOCK, ERROR
BCC 2$
; ELSE SET UP CLOCK INFO AND VECTOR
; POINT CLKCSR TO P-CLK COUNT SET REG.
;LOAD CLK SET REG. WITH COUNT VALUE
;POINT CLKCSR BACK TO P-CLK CSR
;SETUP TO ENABLE P-CLK DATA
MOV #NOCLK,-(SP)
MOV #1,-(SP)
MOV SP,R0
TRAP C$PNTF
ADD #4,SP
;CANNOT CONTINUE, DO CLEANUP
;GET P-TAB POINTER FOR THIS UNIT
MOV #0,R0
TRAP C$GPHRD
MOV RO,R1
;THIS ONE IS NOT AVAILABLE
BCS 4$
MOV UNAPRI,-(SP)
MOV #UNAIISR,-(SP)
MOV UNAVEC,-(SP)
MOV #3,-(SP)
TRAP C$SVEC
ADD #10,SP

```

```

4754 077152 062737 000002 047634      ADD      #2,PCSR1      ;PCSR1
4755 077160 013737 047634 047636      MOV      PCSR1,PCSR2
4756 077166 062737 000002 047636      ADD      #2,PCSR2      ;PCSR2
4757 077174 013737 047636 047640      MOV      PCSR2,PCSR3
4758 077202 062737 000002 047640      ADD      #2,PCSR3      ;PCSR3
4759 077210 012703 000050      MOV      #TBLEN,R3      ;CLEAR NODE TABLE
4760 077214 012702 002404      MOV      #NODTBL,R2
4761 077220 005022          5$:      CLR      (R2)+
4762 077222 005303          DEC      R3
4763 077224 001375          BNE      5$
4764 077226 012703 000132      MOV      #STBLEN,R3      ;CLEAR SUMMARY TABLE
4765 077232 012702 002656      MOV      #STATBL,R2
4766 077236 005022          6$:      CLR      (R2)+
4767 077240 005303          DEC      R3
4768 077242 001375          BNE      6$
4769 077244 005037 050500      CLR      S.NREC          ; CLEAR SUMMARY DATA COUNTERS
4770 077250 005037 050476      CLR      S.REC
4771 077254 005037 050502      CLR      S.LEN
4772 077260 005037 050504      CLR      S.COMP
4773 077264 005037 050506      CLR      S.BYTE
4774 077270 005037 050510      CLR      S.XFER
4775 077274 005037 003706      CLR      TIMMIN          ;CLEAR TIME SINCE-START-LOCATIONS
4776 077300 005037 003710      CLR      TIMSEC
4777 077304 013737 003702 003712      MOV      CLKHZ,TIMTCK    ;LOAD TICKS/SEC
4778 077312          SETVEC   CLKVEC,#CLKINT,CLKBR ;SETUP CLOCK INTERRUPT VECTOR
      077312 013746 003676          MOV      CLKBR,-(SP)
      077316 012746 067702          MOV      #CLKINT,-(SP)
      077322 013746 003700          MOV      CLKVEC,-(SP)
      077326 012746 000003          MOV      #3,-(SP)
      077332 104437          TRAP    C#SVEC
      077334 062706 000010          ADD      #10,SP
4779 077340 013777 003704 104326      MOV      CLKEN,#CLKCSR  ;SET ENABLE BITS IN THE CLOCK TO START
4780 077346          SETPRI  #PRIO0        ;SET PRIORITY=0 SO CLOCK CAN INTERRUPT
      077346 012700 000000          MOV      #PRIO0,R0
      077352 104441          TRAP    C#SPRI
4781 077354          CALL    UNAINI          ;INITIALIZE THE UNA
4782 077362          CALL    FUNCT #RDDEFA  ;READ UNA DEFAULT PHYSICAL ADDRESS
4783 077374          P#POP  R2              ;CHECK FOR ERROR
4784 077376 001402          BEQ     8$
4785 077400 000137 100034          JMP     20$
4786 077404          8$:      CALL    BINHEX #PCBB2,#6,#STRBUF ;PUT ADDRESS INTO HEX FORMAT
4787 077426          PRINTS #HDMSG1,#STRBUF ;PRINT ADDRESS
      077426 012746 002322          MOV      #STRBUF,-(SP)
      077432 012746 055342          MOV      #HDMSG1,-(SP)
      077436 012746 000002          MOV      #2,-(SP)
      077442 010600          MOV      SP,R0
      077444 104416          TRAP    C#PNTS
      077446 062706 000006          ADD      #6,SP
4788 077452          CALL    FUNCT #RDSTA   ;READ STATUS TO GET ROM VERSION
4789 077464          P#POP  R2              ;CHECK FOR ERROR
4790 077466 001162          BNE     20$
4791 077470 113702 047670      MOV     PCBB2,R2        ;ONLY WANT LOWEST 6 BITS
4792 077474 142702 000300      BIC     #300,R2
4793 077500          PRINTS #HDMSG2,R2    ;PRINT ROM VERSION
      077500 010246          MOV     R2,-(SP)
      077502 012746 055413          MOV     #HDMSG2,-(SP)
      077506 012746 000002          MOV     #2,-(SP)

```



```

077760 104416
077762 062706 000004
4820 077766 000410
4821 077770 16$: BR PRINTS 17$ #HDMSG9 ; SELF TEST DISABLED
077770 012746 056014
077774 012746 000001
100000 010600
100002 104416
100004 062706 000004
4822 100010 012737 000000 002370 17$: MOV #ALPHA,P#TYPE ;SET MESSAGE DEFAULT VALUES
4823 100016 012737 001000 002372
4824 100024 012737 000001 002374
4825 100032 000405
4826 100034 20$: BR ERRDF 18,MSG18,ERR1
100034 104455
100036 000022
100040 065127
100042 067460
4827 100044 000431
4828 100046 005037 003706 RESTRT: BR INICLN ;CLEAR TIME SINCE-START-LOCATIONS
4829 100052 005037 003710 CLR TIMMIN
4830 100056 013737 003702 003712 MOV CLKHZ,TIMTCK ;LOAD TICKS/SEC
4831 100064 SETVEC CLKVEC,#CLKINT,CLKBR ;SETUP CLOCK INTERRUPT VECTOR
100064 013746 003676
100070 012746 067702
100074 013746 003700
100100 012746 000003
100104 104437
100106 062706 000010
4832 100112 013777 003704 103554 NEW: MOV CLKEN,@CLKCSR ;SET ENABLE BITS IN THE CLOCK TO START
4833 100120 SETPRI #PRI0 ;SET PRIORITY=0 SO CLOCK CAN INTERRUPT
100120 012700 000000
100124 104441
4834 100126 000401
4835 100130 INICLN: BR INIEXI ;EXIT
100130 104444 INICLN: DOCLN ;ABORT PASS
4836 100132 INIEXI: EXIT INIT ;EXIT INIT SECTION
100132 104432
100134 000002 TRAP C$PNTS #4,SP
TRAP ADD #HDMSG9,-(SP)
MOV #1,-(SP)
MOV SP,RO
TRAP C$PNTS #4,SP
ADD #4,SP
TRAP C$ERDF 18
.WORD MSG18
.WORD ERR1
MOV CLKBR,-(SP)
MOV #CLKINT,-(SP)
MOV CLKVEC,-(SP)
MOV #3,-(SP)
TRAP C$SVEC #10,SP
ADD #10,SP
MOV #PRI0,RO
TRAP C$SPRI
TRAP C$DCLN
TRAP C$EXIT
.WORD L10010-
;*****
; INSERT LOCAL STORAGE THAT IS USED ONLY
; DURING THE INITIALIZE SECTION.
;*****
;*****
; INSERT MESSAGES THAT ARE USED ONLY
; DURING THE INITIALIZE SECTION.
;*****
.EVEN
ENDINIT
L10010: TRAP C$INIT
100136 104411

```

4854
4855
4856
4857
4858
4859
4860
4861
4862
4863 100140
100140
4864
4866
4867
4868
4869
4871
4872 100140
100140
100140 104461

.SBTTL AUTODROP SECTION

: THIS CODE IS EXECUTED IMMEDIATELY AFTER THE INITIALIZE CODE IF
: THE "ADR" FLAG WAS SET. THE UNIT(S) UNDER TEST ARE CHECKED TO
: SEE IF THEY WILL RESPOND. THOSE THAT DON'T ARE IMMEDIATELY
: DROPPED FROM TESTING.
:--

BGNAUTO

L\$AUTO::

: INSERT CODE HERE TO CHECK DEVICE(S) TO SEE IF THEY RESPOND.
: ISSUE A "DODU" FOR THOSE THAT DON'T.

ENDAUTO

L10011:

TRAP C\$AUTO

DROP UNIT SECTION

4925
4926
4927
4928
4929
4930
4931
4932 100260
100260
4933
4935
4936
4937
4938
4939
4940
4942
4943 100260
100260 000167
100262 000000
4944
4946
4947
4948
4949
4950
4951
4952
4953
4954
4956
4957
4958
4959 100264
100264
100264 104453

.SBTTL DROP UNIT SECTION

;+
; THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
; TO NO LONGER BE TESTED.
;--

BGNDU

L\$DU: :

```

;*****
; INSERT DROP CODE HERE. THIS CODE WILL BE EXECUTED AFTER
; A "DROP" COMMAND OR A "DODU" MACRO EXECUTION. THE PURPOSE
; OF THIS CODE IS TO DO ANY NECESSARY HOUSEKEEPING AFTER A
; UNIT HAS BEEN DROPPED. THIS SECTION IS OPTIONAL.
;*****

```

EXIT DU

.WORD J\$JMP
.WORD L10013-2-.

```

;*****
; INSERT LOCAL STORAGE THAT IS USED ONLY
; DURING THE DROP-UNIT SECTION.
;*****

```

```

;*****
; INSERT MESSAGES THAT ARE USED ONLY
; DURING THE DROP-UNIT SECTION.
;*****

```

.EVEN

ENDDU

L10013: TRAP C\$DU


```

TEST 1:
5022      ;      INSERT PROGRAM EQUATES THAT ARE USED ONLY IN THIS TEST.
5023      ;*****
5025
5026 100274      BGNTST
100274
5027
5029      ;*****
5030      ;      INSERT THE CODING FOR THIS HARDWARE TEST.
5031      ;*****
5033      .SBTTL GETCL  COMMAND LINE FETCH & INTERPRETATION SECTION
5034
5035 100274 105037 003161      GETCL:  CLRB  P%GDBD      ;CLEAR CMD LINE PARSING ERROR FLAG
5036 100300 105037 003160      CLRB  P%NNUF
5037 100304      GMANID  CLI$PM,CMDBUF,A,0,1,72.,NO      ;GET CMD LINE FROM OPERATOR
100304      TRAP  C$GMAN
100306      BR  10000$
100310      .WORD  CMDBUF
100312      .WORD  T%CODE
100314      .WORD  CLI$PM
100316      .WORD  0
100320      .WORD  T$LOLIM
100322      .WORD  T$MILIM
100324      10000$:
5038 100324 012737 002200 003144      MOV  @CMDBUF,P%BUFA
5039 100332 012737 051070 003146      MOV  @CLITRE,P%TREE
5040 100340 012737 100456 003150      MOV  @CLIACT,P%ACT
5041 100346 005037 003672      CLR  CFLAG      ;CLEAR QUALIFIER FLAG
5042 100352 004737 075216      JSR  PC,P%TRV    ;GO PARSE COMMAND TREE
5043 100356 105737 003161      TSTB P%GDBD     ;SEE IF PARSED OK, OR AN ERROR
5044 100362 001412      BEQ  1$
5045 100364      PRINTF @CLIERM      ;IF NOT PRINT ERROR MESSAGE
100364      MOV  @CLIERM,-(SP)
100370      MOV  @1,-(SP)
100374      MOV  SP,RO
100376      TRAP  C$PNTF
100400      ADD  @4,SP
5046 100404 000137 100274      JMP  GETCL
5047 100410 105737 003160      1$:  TSTB P%NNUF      ;SEE IF INCOMPLETE COMMAND TYPED
5048 100414 001412      BEQ  10$
5049 100416      PRINTF @CLINUF     ;IF NOT PRINT ERROR MESSAGE
100416      MOV  @CLINUF,-(SP)
100422      MOV  @1,-(SP)
100426      MOV  SP,RO
100430      TRAP  C$PNTF
100432      ADD  @4,SP
5050 100436 000137 100274      JMP  GETCL
5051 100442 022737 000020 003672 10$:  CMP  @CEXIT,CFLAG  ;WAS EXIT COMMAND TYPED?
5052 100450 001311      BNE  GETCL      ; IF NOT GET NEW COMMAND LINE
5053 100452      EXIT  TST      ; ELSE EXIT
100452      TRAP  C$EXIT
100454      .WORD  L10015-.
5054
5055      .SBTTL CLI ACTION TABLE AND ROUTINES
5056      ;      USER MUST CLEAR/SET P%GDBD IF USE "CLIBIF" IN CONNECTION WITH ACTION
5057      ;      R2 WILL HOLD ACTION CODE FROM PARSING (CLI) NODE
5058 100456      CLIACT:
5059 100456 006302      ASL  R2      ;MULTIPLY ACTION CODE BY 2

```

Address	Offset	Code	Label	Operation	Comment
5060	100460	016202	100474	MOV	10(R2),R2 ;OFFSET VALUE
5061	100464	062702	100474	ADD	#10,R2 ;ADD BASE VALUE
5062	100470	004712		JSR	PC,(R2) ;GO DO ACTION
5063	100472	000207		RTS	PC ;RETURN TO TRVACT
5064					
5065					;BRIEF DESCRIPTION OF ACTION TAKEN
5066	100474	000122	10:	.WORD	ACTNUL-10 ;0-NULL
5067	100476	000124		.WORD	ACTHLP-10 ;1-HELP
5068	100500	000162		.WORD	ACTNOD-10 ;2-NODE
5069	100502	000472		.WORD	ACTBLD-10 ;3-BUILD
5070	100504	003542		.WORD	ACTRUN-10 ;4-RUN SPECIFIED TEST
5071	100506	006336		.WORD	ACTPAT-10 ;5-SET 'MESSAGE PATTERN' TEST FLAG
5072	100510	010174		.WORD	ACTSAV-10 ;6-SAVE NODE TABLE
5073	100512	001214		.WORD	ACTSUM-10 ;7-PRINT SUMMARY TABLE
5074	100514	001570		.WORD	ACTIDT-10 ;10-REQUEST ID
5075	100516	002654		.WORD	ACTEXT-10 ;11-EXIT
5076	100520	000114		.WORD	ACTNUF-10 ;12-NOT ENOUGH INFO
5077	100522	002664		.WORD	ACTXAD-10 ;13-EXTRACT NI NODE ADDRESS FROM INPUT LINE
5078	100524	002746		.WORD	ACTSR4-10 ;14-SAVE POINTER TO BEGINING OF ADDRESS STRING
5079	100526	007700		.WORD	ACTSND-10 ;15-SET 'NODE' FLAG FOR SHOW COMMAND
5080	100530	002754		.WORD	ACTALP-10 ;16-SET 'ALPHA' FLAG
5081	100532	002764		.WORD	ACTONE-10 ;17-SET 'ONES' FLAG
5082	100534	002774		.WORD	ACTZRO-10 ;20-SET 'ZEROS' FLAG
5083	100536	003004		.WORD	ACTIAL-10 ;21-SET 'IALT' FLAG
5084	100540	003014		.WORD	ACTOAL-10 ;22-SET 'OALT' FLAG
5085	100542	003024		.WORD	ACTCCT-10 ;27-SET 'CCITT' FLAG
5086	100544	003034		.WORD	ACTOPR-10 ;24-SET 'OPER SEL' FLAG
5087	100546	003162		.WORD	ACTTYP-10 ;25-DETERMINE MESSAGE TYPE
5088	100550	003170		.WORD	ACTSZE-10 ;26-DETERMINE MESSAGE SIZE
5089	100552	003246		.WORD	ACTCPY-10 ;27-DETERMINE MESSAGE COPIES
5090	100554	003324		.WORD	ACTNAD-10 ;30-SET 'NODE/ADDRESS' FLAG
5091	100556	003462		.WORD	ACTNAL-10 ;31-SET 'NODE/ALL' FLAG
5092	100560	003662		.WORD	ACTRNA-10 ;32-SET 'ALL' FLAG FOR RUN COMMAND
5093	100562	004730		.WORD	ACTRNL-10 ;33-SET 'LOOPAIR' FLAG FOR RUN CMD
5094	100564	006420		.WORD	ACTSMS-10 ;34-SHOW CURRENT MESSAGE PARAMETERS
5095	100566	006512		.WORD	ACTCMS-10 ;35-RESET MESSAGE PARAMETERS TO DEFAULT
5096	100570	006616		.WORD	ACTCNT-10 ;36-SET 'COUNTER' FLAG FOR SHOW COMMAND
5097	100572	010054		.WORD	ACTCNL-10 ;37-CLEAR LOGICAL NODE NAMED FROM TABLE
5098	100574	010140		.WORD	ACTFCT-10 ;40-INITIATE UNA PORT COMMAND FUNCTION
5099	100576	010240		.WORD	ACTUNS-10 ;41-UNSAVE NODE TABLE
5100	100600	010342		.WORD	ACTCSU-10 ;42-CLEAR SUMMARY TABLE
5101	100602	004302		.WORD	ACTDIR-10 ;43-SET 'LOOP DIRECT' FLAG FOR RUN COMMAND
5102	100604	010416		.WORD	ACTDFT-10 ;44-LOOK FOR PASS COUNT DEFAULT
5103	100606	010464		.WORD	ACTUSF-10 ;45-UNSAVE NODE TABLE FROM A FILE
5104					

```

5106
5107
5108 ;ACTION ROUTINE TO INDICATE THAT NOT ENOUGH COMMAND
5109 ;INFORMATION HAS BEEN ENTERED
5110 ;
5111
5112 100610 112737 177777 003160 ACTNUF: MOVB    #-1,P$NNUF          ;SET FLAG TO SAY NEED MORE OF COMMAND
5113
5114 ;
5115 ;ACTION ROUTINE TO DO NOTHING
5116 ;
5117
5118 100616 000207 ACTNUL: RTS      PC          ;RETURN TO PARSER
5119
5120
5121 ;
5122 ;ACTION ROUTINE TO PRINT OUT HELP FILE
5123 ;
5124
5125 100620 ACTHLP: P$PUSH R2          ;SAVE R2
5126 100622 012702 003164      MOV    #HLPTAB,R2        ;MOVE POINTER TO BEGINING OF HELP FILE
5127 100626      10$: PRINTF (R2)+ ;PRINT LINE AND INCREMENT POINTER
                    MOV    (R2)+,-(SP)
                    MOV    #1,-(SP)
                    MOV    SP,R0
                    TRAP   C$PNTF
                    ADD    #4,SP
100626 012246
100630 012746 000001
100634 010600
100636 104417
100640 062706 000004
5128 100644 020227 003260      CMP    R2,#HLPEND        ;SEE IF ENTIRE FILE PRINTED
5129 100650 001366      BNE    10$              ;IF NOT, PRINT MORE
5130 100652      P$POP R2          ;ELSE, RESTORE R2 AND RETURN
5131 100654 000207      RTS    PC
5132
5133
5134 ;
5135 ;ACTION ROUTINE TO READ IN NODE PHY. ADDRESS, STORE IT IN ADRBUF
5136 ;AND ENTER IT INTO THE NODE TABLE
5137 ;
5138
5139 100656 105037 003160 ACTNOD: CLRB    P$NNUF          ;CLEAR NOTNUF FLAG
5140 100662 004737 076330      JSR    PC,TRVADR        ;TRAVERSE ADDRESS, CHECK IF TARGET OR ASSIST
5141 100666 105737 003161      TSTB  P$G0BD          ;CHECK IF RESULTS OK
5142 100672 001134      BNE    50$              ;IF NOT, RETURN WITH -1 IN P$G0BD
5143 100674      10$: CALL  EDPACK CBOADR,#ADRBUF,#6 ;GET ADDRESS INTO BUFFER
5144 100716      P$POP R1          ;CHECK RESULTS FOR NUMBER OF CHAR.S
5145 100720 001411      BEQ   15$              ;IF OK, BRANCH TO 15$
5146 100722      PRINTF #CADRER ;ELSE PRINT ERROR MESSAGE
                    MOV    #CADRER,-(SP)
                    MOV    #1,-(SP)
                    MOV    SP,R0
                    TRAP   C$PNTF
                    ADD    #4,SP
100722 012746 053232
100726 012746 000001
100732 010600
100734 104417
100736 062706 000004
5147 100742 000510      BR    50$              ;AND RETURN
5148 100744      15$: CALL  CMPADR #ADRBUF,#ILLADR ;SEE IF ILLEGAL ADDRESS
5149 100762      P$POP R1
5150 100764 001021      BNE   17$              ;IF YES, PRINT ERROR MESSAGE
5151 100766      PRINTF #ILADMS
                    MOV    #ILADMS,-(SP)
100766 012746 053051

```


	100772	012746	000001					MOV	#1,-(SP)
	100776	010600						MOV	SP,RO
	101000	104417						TRAP	C\$PNTF
	101002	062706	000004					ADD	#4,SP
5152	101006				PRINTF	#ILADM1			
	101006	012746	053135					MOV	#ILADM1,-(SP)
	101012	012746	000001					MOV	#1,-(SP)
	101016	010600						MOV	SP,RO
	101020	104417						TRAP	C\$PNTF
	101022	062706	000004					ADD	#4,SP
5153	101026	000456			BR	50\$			
5154	101030			17\$:	CALL	BINHEX #ADRBUF,#6,#STRBUF			;CONVERT BINARY ADDRESS
5155									;INTO ASCII STRING
5156	101052	022737	000001	003672	CMP	#CASIST,CFLAG			;SEE IF TARGET OR ASSIST
5157	101060	001407			BEQ	20\$			
5158	101062	012737	062613	002312	MOV	#ARGTY7,KEYWD2			;MOVE 'TARGET' INTO KEYWD2
5159	101070	012737	000000	002400	MOV	#CTARGET,NODTY			;MOVE TARGET INTO NODE TYPE
5160	101076	000406			BR	25\$			
5161	101100	012737	062603	002312	20\$:	MOV	#ARGTY6,KEYWD2		;MOVE 'ASSIST' INTO KEYWD2
5162	101106	012737	000001	002400	MOV	#CASIST,NODTY			
5163	101114				25\$:	CALL	ENTRND		;CALL ROUTINE TO ENTER NODE ON TABLE
5164	101122				P\$POP	R1			;CHECK RESULTS
5165	101124	001017			BNE	50\$;IF NODE TABLE FULL, RETURN
5166	101126	012737	062510	002310	MOV	#CMDTY7,KEYWD1			;ELSE, MOVE "NODE" INTO KEYWD1
5167	101134				PRINTS	#MSG2,KEYWD2,#STRBUF			;INDICATE IF TARGET OR ASSIST
	101134	012746	002322					MOV	#STRBUF,-(SP)
	101140	013746	002312					MOV	KEYWD2,-(SP)
	101144	012746	055177					MOV	#MSG2,-(SP)
	101150	012746	000003					MOV	#3,-(SP)
	101154	010600						MOV	SP,RO
	101156	104416						TRAP	C\$PNTS
	101160	062706	000010					ADD	#10,SP
5168	101164	000207			50\$:	RTS	PC		
5169									
5170									
5171									
5172									
5173									
5174									
5175									
5176	101166				ACTBLD:	PRINTS	#MSG1		; PRINT 'BUILD' COMMAND MESSAGE
	101166	012746	054711					MOV	#MSG1,-(SP)
	101172	012746	000001					MOV	#1,-(SP)
	101176	010600						MOV	SP,RO
	101200	104416						TRAP	C\$PNTS
	101202	062706	000004					ADD	#4,SP
5177	101206				PRINTS	#MSG11			
	101206	012746	055024					MOV	#MSG11,-(SP)
	101212	012746	000001					MOV	#1,-(SP)
	101216	010600						MOV	SP,RO
	101220	104416						TRAP	C\$PNTS
	101222	062706	000004					ADD	#4,SP
5178	101226				PRINTS	#MSG12			
	101226	012746	055137					MOV	#MSG12,-(SP)
	101232	012746	000001					MOV	#1,-(SP)
	101236	010600						MOV	SP,RO
	101240	104416						TRAP	C\$PNTS

```

101242 062706 000004
5179 101246 P$PUSH R2,R3,R4 ; SAVE REGISTERS
5180 101254 CALL FUNCT #WDMULA ; WRITE MULTICAST ADDRESS LIST
5181 101266 P$POP R2 ; CHECK FOR ERROR
5182 101270 001404 BEQ 10$ ; IF OK, CONTINUE
5183 101272 ERRHRD 25,MSG25 ; ELSE REPORT ERROR
101272 104456 TRAP C$ERHRD
101274 000031 .WORD 25
101276 065442 .WORD MSG25
101300 000000 .WORD 0
5184 101302 005037 050550 10$: CLR TEMP ; CLEAR 'NO. NODES IN LAST MIN.' COUNTER
5185 101306 005037 050552 CLR TEMP1 ; CLEAR NODE TYPE ARGUMENT (SET TO TARGET)
5186 101312 005037 050554 CLR TEMP2 ; SET INTERVAL COUNTER
5187 101316 012737 000012 050556 MOV #12,TEMP3 ; SET 'MINS. SINCE LAST NEW NODE' COUNTER
5188 101324 012737 002404 002402 MOV #NODTBL,SLOT ; SET SLOT TO BEGINING OF NODE TABLE
5189 101332 012704 003720 MOV #TIMERS,R4 ; SET UP FOR 1 MINUTE LOOP
5190 101336 012714 000074 19$: MOV #60.,(R4)
5191 101342 20$: BREAK ; ALLOW FOR CONTROL C INTERRUPTION
101342 104422 TRAP C$BRK
5192 101344 005714 TST (R4) ; SEE IF INTERVAL IS UP
5193 101346 001501 BEQ 40$ ; IF YES, BRANCH
5194 101350 CALL RECEVE ; ELSE, CHECK FOR RECEPTION OF ID MESSAGE
5195 101356 P$POP R2 ; R2 HOLDS NO OF MESSAGES RECEIVED
5196 101360 001770 BEQ 20$ ; IF NONE, KEEP LOOKING
5197 101362 013703 003764 MOV RRGNXT,R3 ; IF ONE, GET RECEIVE RING POINTER
5198 101366 CALL GETRNX #RRGNXT ; UPDATE POINTER
5199 101400 016303 000002 MOV 2(R3),R3 ; POINT R3 TO MESSAGE BUFFER
5200 101404 062703 000006 ADD #SOURCC,R3 ; POINT R3 TO NODE ADDRESS
5201 101410 012702 002404 MOV #NODTBL,R2 ; POINT R2 TO NODE TABLE
5202 101414 21$: CALL CMPADR R2,R3 ; SEE IF NODE ALREADY ON TABLE
5203 101426 P$POP R1
5204 101430 001744 BEQ 20$ ; IF SAME, DON'T ADD TO TABLE
5205 101432 062702 000010 22$: ADD #10,R2 ; ELSE CHECK NEXT TABLE ENTRY
5206 101436 022712 177777 CMP #-1,(R2) ; SEE IF AT END OF TABLE
5207 101442 001364 BNE 21$ ; IF NO, COMPARE NEXT ENTRY
5208 101444 CALL FINDSL ; IF YES, GET NEXT TABLE SLOT
5209 101452 P$POP R2 ; SEE IF TABLE FULL
5210 101454 001023 BNE 35$ ; IF YES, BRANCH
5211 101456 013702 002402 MOV SLOT,R2 ; IF NO, ADD NODE TO TABLE
5212 101462 012322 MOV (R3)+,(R2)+ ;
5213 101464 012322 MOV (R3)+,(R2)+ ;
5214 101466 011312 MOV (R3),(R2) ; SIX BYTES WORTH
5215 101470 113762 050552 000003 MOVB TEMP1,3(R2) ; SET NODE TYPE (TARGET OR ASSIST)
5216 101476 105137 050552 COMB TEMP1 ; SWITCH TYPE FOR NEXT TIME
5217 101502 142737 000376 050552 BICB #376,TEMP1 ;
5218 101510 005237 050550 INC TEMP ; INCREMENT 'NODES IN LAST MIN.' COUNTER
5219 101514 012737 000013 050556 MOV #13,TEMP3 ; RESET 'MINS. SINCE LAST NODE' COUNTER
5220 101522 000707 BR 20$ ; CHECK FOR MORE INPUT
5221 101524 35$: PRINTB #TABFUL,#NOD ; PRINT "TABLE FULL" MESSAGE
101524 012746 053701 MOV #NOD,-(SP)
101530 012746 053560 MOV #TABFUL,-(SP)
101534 012746 000002 MOV #2,-(SP)
101540 010600 MOV SP,R0
101542 104414 TRAP C$PNTB
101544 062706 000006 ADD #6,SP
5222 101550 000430 BR 50$
5223 101552 005337 050556 40$: DEC TEMP3 ; SEE IF 10 MINS SINCE LAST NODE

```

```

5224 101556 001425          BEQ      50$          ; IF YES, EXIT
5225 101560 005237 050554  INC      TEMP2       ; SEE IF TIME IS UP
5226 101564 023727 050554 000050  CMP      TEMP2, #40.
5227 101572 001417          BEQ      50$          ; IF YES, EXIT
5228 101574          PRINTS  #BLDMSG,TEMP,TEMP2 ; ELSE, PRINT "STILL WORKING" MESSAGE
                                MOV      TEMP2,-(SP)
                                MOV      TEMP,-(SP)
                                MOV      #BLDMSG,-(SP)
                                MOV      #3,-(SP)
                                MOV      SP,RO
                                TRAP    C#PNTS
                                ADD     #10,SP
101574 013746 050554
101600 013746 050550
101604 012746 052757
101610 012746 000003
101614 010600
101616 104416
101620 062706 000010
5229 101624 005037 050550  CLR      TEMP
5230 101630 000642          BR       19$
5231 101632 012737 000000 050044 50$:  MOV      #0,$WDMC+4   ; CLEAR MULTICAST ADDRESS LIST
5232 101640          CALL    FUNCT #WDMULA ; WRITE 0 INTO LIST LENGTH
5233 101652          P#POP   R2           ; CHECK FOR ERROR
5234 101654 001404          BEQ      54$          ; IF OK CONTINUE
5235 101656          ERRHRD 34,MSG25 ; ELSE, REPORT ERROR
                                TRAP    C#ERHRD
                                .WORD   34
                                .WORD   MSG25
                                .WORD   0
101656 104456
101660 000042
101662 065442
101664 000000
5236 101666 004737 110374 050044 54$:  JSR      PC,ACTSND    ; PRINT NODE TABLE
5237 101672 012737 000400          MOV      #400,$WDMC+4 ; RESET MULTICAST LIST FOR 1 ENTRY
5238 101700          P#POP   R2,R3,R4 ; RESTORE REGISTERS
5239 101706 000207          RTS      PC
5240
5241
5242
5243 ; ACTION ROUTINE TO PRINT OUT THE SUMMARY DATA
5244 ;
5245
5246 101710 105037 003160  ACTSUM: CLRB   P#NNUF   ; CLEAR NOTNUF FLAG
5247 101714          P#PUSH  R2,R3,R4
5248 101722 012701 002656  MOV      #STATBL,R1  ; MOVE ADDRESS OF TABLE TO R1
5249 101726 005711          TST     (R1)         ; SEE IF TABLE EMPTY
5250 101730 001013          BNE    5$           ; IF NOT, CONT.
5251 101732          PRINTF #TABEMT,#SUMM ; ELSE PRINT 'TABLE EMPTY' MESSAGE
                                MOV      #SUMM,-(SP)
                                MOV      #TABEMT,-(SP)
                                MOV      #2,-(SP)
                                MOV      SP,RO
                                TRAP    C#PNTF
                                ADD     #6,SP
101732 012746 053706
101736 012746 053632
101742 012746 000002
101746 010600
101750 104417
101752 062706 000006
5252 101756 000536          BR       30$          ; EXIT
5253 101760 021127 177777 5$:  CMP      (R1),#-1    ; SEE IF AT END OF TABLE
5254 101764 001533          BEQ     30$          ; IF YES, EXIT
5255 101766 005711          TST     (R1)         ; SEE IF REST OF TABLE EMPTY
5256 101770 001531          BEQ     30$          ; IF YES, EXIT
5257 101772          CALL   BINHEX R1,#6,#STRBUF ; PRINT SUMMARY DATA
5258 102012          PRINTF #SUMMS1,#STRBUF ; NODE ADDRESS
                                MOV      #STRBUF,-(SP)
                                MOV      #SUMMS1,-(SP)
                                MOV      #2,-(SP)
                                MOV      SP,RO
                                TRAP    C#PNTF
102012 012746 002322
102016 012746 067215
102022 012746 000002
102026 010600
102030 104417

```



```

5259 102032 062706 000006
      102036          PRINTF  #SUMMS2          ; FIRST HEADER          ADD      #6,SP
      102036 012746 067236          MOV      #SUMMS2,-(SP)
      102042 012746 000001          MOV      #1,-(SP)
      102046 010600          MOV      SP,RO
      102050 104417          TRAP     C$PNTF
      102052 062706 000004          ADD      #4,SP
5260 102056 016102 000006          MOV      6(R1),R2          ; RX NOT COMPLETE
5261 102062 016103 000010          MOV      10(R1),R3         ; RX COMPLETE
5262 102066 016104 000012          MOV      12(R1),R4         ; LENGTH ERRORS
5263 102072          PRINTF  #SUMMS3,R2,R3,R4          ; PRINT THEM OUT
      102072 010446          MOV      R4,-(SP)
      102074 010346          MOV      R3,-(SP)
      102076 010246          MOV      R2,-(SP)
      102100 012746 067322          MOV      #SUMMS3,-(SP)
      102104 012746 000004          MOV      #4,-(SP)
      102110 010600          MOV      SP,RO
      102112 104417          TRAP     C$PNTF
      102114 062706 000012          ADD      #12,SP
5264 102120          PRINTF  #SUMMS4          ; SECOND HEADER
      102120 012746 067351          MOV      #SUMMS4,-(SP)
      102124 012746 000001          MOV      #1,-(SP)
      102130 010600          MOV      SP,RO
      102132 104417          TRAP     C$PNTF
      102134 062706 000004          ADD      #4,SP
5265 102140 016102 000014          MOV      14(R1),R2         ; COMPARE ERRORS
5266 102144 062701 000016          ADD      #16,R1            ; BYTES COMPARED
5267 102150          CALL    BINDEC R1          ; PUT INTO ASCII STRING
5268 102160          PRINTF  #SUMMS5,R2,#DECSTR ; PRINT THEM OUT
      102160 012746 075200          MOV      #DECSTR,-(SP)
      102164 010246          MOV      R2,-(SP)
      102166 012746 067434          MOV      #SUMMS5,-(SP)
      102172 012746 000003          MOV      #3,-(SP)
      102176 010600          MOV      SP,RO
      102200 104417          TRAP     C$PNTF
      102202 062706 000010          ADD      #10,SP
5269 102206 062701 000004          ADD      #4,R1              ; BYTES TRANSFERED
5270 102212          CALL    BINDEC R1          ; PUT INTO ASCII STRING
5271 102222          PRINTF  #SUMMS6,#DECSTR   ; PRINT
      102222 012746 075200          MOV      #DECSTR,-(SP)
      102226 012746 067452          MOV      #SUMMS6,-(SP)
      102232 012746 000002          MOV      #2,-(SP)
      102236 010600          MOV      SP,RO
      102240 104417          TRAP     C$PNTF
      102242 062706 000006          ADD      #6,SP
5272 102246 062701 000004          ADD      #4,R1              ; POINT R1 TO NEXT TABLE ENTRY
5273 102252 000642          BR      5$                  ; DO IT ALL AGAIN
5274 102254          30$: P$POP R2,R3,R4
5275 102262 000207          RTS      PC
5276
5277
5278
5279          ; ACTION ROUTINE TO INITIATE THE REQUEST ID TEST TO THE SPECIFIED NODE
5280
5281
5282          ; ---
5283          ; FUNCTIONAL DESCRIPTION
  
```

```

5284      ;
5285      ;
5286      ;
5287      ;
5288      ;
5289      ;
5290      ; INPUTS -      IMPLICIT - THE SPECIFIED NODE ADDRESS IS LOCATED IN ADRBUF.
5291      ;
5292      ; OUTPUTS -     SYSTEM ID INFO OR ERROR MESSAGE PRINTED TO OPERATOR.
5293      ;
5294      ; CALLING PROCEDURE - JSR PC, ACTIDT
5295      ;
5296      ; SIDE EFFECTS - XRG NXT POINTER IS UPDATED BY A CALL TO BLDREQ SUB.
5297      ;
5298      ; REGISTER USAGE - R1 POINTS TO $WDMO FOR WRITE MODE OPERATIONS.
5299      ;
5300      ;
5301      ;
5302      ;
5303      ;
5304      ;---+
5305 102264 105737 003162 ACTIDT: TSTB    P$AERR      ;SEE IF ADDRESS ENTERED WAS VALID
5306 102270 001402      BEQ      1$          ; IF NOT, EXIT ACTION ROUTINE
5307 102272 000137 103240      JMP      55$
5308 102276 105037 003160 1$:  CLRB    P$NNUF      ;CLEAR NOTNUF FLAG
5309 102302      CALL    CMPADR  @ADRBUF,@ILLADR ; SEE IF ILLEGAL ADDRESS
5310 102320      P$POP    R1
5311 102322 001012      BNE     2$          ; IF NO, CONTINUE
5312 102324      PRINTF  @ILADMS      ; ELSE PRINT ILLEGAL ADDRESS MESSAGE
                    MOV     @ILADMS,-(SP)
                    MOV     @1,-(SP)
                    MOV     SP,R0
                    TRAP    C$PNTF
                    ADD     @4,SP
102324 012746 053051
102330 012746 000001
102334 010600
102336 104417
102340 062706 000004
5313 102344 000137 103240      JMP      55$
5314 102350      P$PUSH  R1,R2,R3,R4 ; SAVE REGISTERS
5315 102360      CALL    CMPADR  @ADRBUF,@PHYADR ; SEE IF ADDRESS IS OWN (HOST NODE)
5316 102376      P$POP    R1
5317 102400 001535      BEQ     27$
5318 102402 012737 177776 050554  MOV     @-2,TEMP2 ; SET COUNTER FOR NO. OF TIMES TRIED
5319 102410 012701 050300      MOV     @$WDMO,R1 ; SET UP TO WRITE MODE
5320 102414 012761 010000 000002  MOV     @10000,2(R1) ; 10000: TPAD =1 (PAD TRANSMIT BUFFERS)
5321 102422      CALL    FUNCT  @WDMODE ; WRITE MODE
5322 102434      P$POP    R2 ; CHECK FOR ERROR
5323 102436 001402      BEQ     3$          ; BR IF ERROR
5324 102440 000137 103146      JMP     40$
5325 102444      CALL    BLDREQ ; BUILD REQUEST ID MESSAGE PACKET
5326 102452      CALL    XMIT   ; TRANSMIT REQUEST
5327 102460      P$POP    R2 ; GET RESULTS, R2 = SUCCESS/FAILURE
5328 102462 001402      BEQ     4$          ; IF OK BRANCH
5329 102464 000137 103160      JMP     45$ ; ELSE JUMP TO 45$
5330 102470 005737 050534 4$:  TST     RETRYS ; SEE IF FAILED DUE TO EXCESSIVE COLLISIONS
5331 102474 001412      BEQ     5$          ; IF NO, CONT.
5332 102476      PRINTF  @RTRYER ; YES, PRINT 'EXCESSIVE COLLISIONS' MESSAGE
                    MOV     @RTRYER,-(SP)
                    MOV     @1,-(SP)
                    MOV     SP,R0
102476 012746 052675
102502 012746 000001
102506 010600

```



```

5389 103240 000207      55$:   RTS      PC
5390
5391
5392
5393      ; ACTION ROUTINE TO CHECK FOR ADDITION PARAMETER CHANGE INPUTS
5394      ; AND PRINT OUT NEW PARAMETER INFO WHEN ALL INPUT ARE PROCESSED
5395      ;
5396
5397 103242 105714      ACTMSG: TSTB     (R4)          ;CHECK FOR ADDITIONAL INPUT
5398 103244 001401      BEQ      12$          ;BR IF NO
5399 103246 000437      BR       50$          ;IF YES RETURN
5400 103250 012737 062500 002310 12$:   MOV      #CMDTY6,KEYWD1
5401 103256 013701 002370      MOV      P$TYPE,R1      ;GET MESSAGE TYPE ASCII STRING ADDRESS
5402 103262 006301      ASL      R1          ;INTO R1
5403 103264 062701 003262      ADD      #MSGTAB,R1
5404 103270      PRINTF   #MSGPRM      ;PRINT 'MESSAGE' COMMAND MESSAGE
      103270 012746 054641      MOV      #MSGPRM,-(SP)
      103274 012746 000001      MOV      #1,-(SP)
      103300 010600      MOV      SP,R0
      103302 104417      TRAP    C$PNTF
      103304 062706 000004      ADD      #4,SP
5405 103310      PRINTF   #MSG4,(R1),P$SIZE,P$CPYS      ;PRINT MSG PARAMETERS
      103310 013746 002374      MOV      P$CPYS,-(SP)
      103314 013746 002372      MOV      P$SIZE,-(SP)
      103320 011146      MOV      (R1),-(SP)
      103322 012746 055276      MOV      #MSG4,-(SP)
      103326 012746 000004      MOV      #4,-(SP)
      103332 010600      MOV      SP,R0
      103334 104417      TRAP    C$PNTF
      103336 062706 000012      ADD      #12,SP
5406 103342 105037 003160      50$:   CLRB     P$NNUF      ;CLEAR NOTNUF FLAG
5407 103346 000207      RTS      PC
5408
5409
5410
5411      ; ACTION ROUTINE TO RETURN CONTROL TO THE SUPERVISOR
5412      ;
5413
5414 103350 012737 000020 003672 ACTEXT: MOV      #CEXIT,CFLAG      ;SET EXIT FLAG
5415 103356 000207      RTS      PC
5416
5417
5418
5419      ; ACTION ROUTINE TO TAKE NI NODE ADDRESS FROM INPUT STRING BUFFER
5420      ; AND STORE IT IN THE BUFFER CALLED ADRBUF
5421      ;
5422
5423 103360      ACTXAD: CALL    EDPACK CBOADR,#ADRBUF,#6      ;PUT NODE ADDRESS INTO ADRBUF
5424 103402      P$POP    P$AERR      ;SET ADDRESS=12 CHAR. GOOD/BAD FLAG
5425 103406 105737 003162      TSTB     P$AERR      ;IF GOOD, RETURN
5426 103412 001412      BEQ      10$
5427 103414      PRINTF   #CADRER      ;ELSE, PRINT ERROR MESSAGE
      103414 012746 053232      MOV      #CADRER,-(SP)
      103420 012746 000001      MOV      #1,-(SP)
      103424 010600      MOV      SP,R0
      103426 104417      TRAP    C$PNTF
      103430 062706 000004      ADD      #4,SP

```

```

5428 103434 105037 003160          CLRB   P$NNUF          ; AND CLEAR 'NOT ENOUGH' FLAG
5429 103440 000207          10$:   RTS   PC
5430
5431
5432          ; ACTION ROUTINE TO STORE POINTER TO BEGINING OF OPERATOR INPUT ADDRESS
5433          ; IN COMMAND INPUT BUFFER
5434          ;
5435
5436 103442 010437 002366   ACTSR4: MOV   R4,CBOADR          ; SAVE STRING POINTER
5437 103446 000207          10$:   RTS   PC
5438
5439
5440          ;
5441          ; ACTION ROUTINE TO SET MESSAGE TYPE = ALPHA FLAG
5442          ;
5443
5444 103450 012737 000000 002370   ACTALP: MOV   #ALPHA,P$TYPE          ; SET MESSAGE TYPE
5445 103456 000207          RTS   PC
5446
5447
5448          ;
5449          ; ACTION ROUTINE TO SET MESSAGE TYPE = ALL ONES FLAG
5450          ;
5451
5452 103460 012737 000001 002370   ACTONE: MOV   #ONES,P$TYPE          ; SET MESSAGE TYPE
5453 103466 000207          RTS   PC
5454
5455
5456          ;
5457          ; ACTION ROUTINE TO SET MESSAGE TYPE = ALL ZEROS FLAG
5458          ;
5459
5460
5461 103470 012737 000002 002370   ACTZRO: MOV   #ZEROS,P$TYPE          ; SET MESSAGE TYPE
5462 103476 000207          RTS   PC
5463
5464
5465          ;
5466          ; ACTION ROUTINE TO SET MESSAGE TYPE = ALTERNATING ONES FLAG
5467          ;
5468
5469 103500 012737 000003 002370   ACT1AL: MOV   #ONEALT,P$TYPE          ; SET MESSAGE TYPE
5470 103506 000207          RTS   PC
5471
5472
5473          ;
5474          ; ACTION ROUTINE TO SET MESSAGE TYPE = ALTERNATING ZEROS FLAG
5475          ;
5476
5477 103510 012737 000004 002370   ACTOAL: MOV   #ZROALT,P$TYPE          ; SET MESSAGE TYPE
5478 103516 000207          RTS   PC
5479
5480
5481          ;
5482          ; ACTION ROUTINE TO SET MESSAGE TYPE = CCITT FLAG
5483          ;
5484

```



```

5485 103520 012737 000005 002370 ACTCTT: MOV    #ACCITT,P#TYPE      ;SET MESSAGE TYPE
5486 103526 000207                                RTS      PC
5487
5488
5489
5490                                     ; ACTION ROUTINE TO SET MESSAGE TYPE - OPERATOR SELECTED INPUT
5491                                     ;
5492
5493 103530 105037 003163 ACTOPP: CLRB   P#MERR                                ;CLEAR MESSAGE ERROR FLAG
5494 103534 004737 076330        JSR    PC,TRVADR                            ;PARSE THROUGH INPUT STRING
5495 103540 105737 003161        TSTB   P#GDBD                                ;TEST GOOD/BAD FLAG
5496 103544 001403                BEQ    10#                                    ;IF GOOD, BR 10#
5497 103546 105037 003161        CLRB   P#GDBD                                ;CLEAR FLAG
5498 103552 000415                BR     20#                                    ;SET CTARGET FLAG AND RETURN
5499 103554 022737 000006 003672 10#: CMP    #OPRSEL,CFLAG                            ;CHECK TO SEE IF STRING VALID
5500 103562 001011                BNE   20#                                    ;IF NOT OK, RETURN WITH ERROR FLAG SET
5501 103564 012737 000006 002370        MOV    #OPRSEL,P#TYPE                        ;SET MESSAGE TYPE
5502 103572                                CALL   SELMSG,CBOADR                        ;PUT OPERATOR SELECTED STRING INTO BUFFER
5503 103604 000423                BR     50#                                    ;RETURN
5504 103606 022737 000000 003672 20#: CMP    #CTARGET,CFLAG                            ;SEE IF CTARGET FLAG SET, IF YES ERROR
5505 103614 001011                BNE   30#                                    ;IF NOT SET, BR 30#
5506 103616                                PRINTF #UNBOND                                ;ELSE PRINT UNBOUNDED INPUT STRING ERR. MSG.
                                           MOV    #UNBOND,-(SP)
                                           MOV    #1,-(SP)
                                           MOV    SP,RO
                                           TRAP  C#PNTF
                                           ADD    #4,SP
5507 103636 000406                BR     50#                                    ;RETURN
5508 103640 105737 003163        30#: TSTB   P#MERR                                ;IF P#MERR FLAG SET, UNBOUNDED STRING
5509 103644 001003                BNE   50#                                    ;WAS ENTERED, ERROR ALREADY HANDLED
5510 103646 112737 177777 003161        MOVB  #-1,P#GDBD                            ;SET ERROR FLAG AND RETURN
5511 103654 000207                                RTS      PC                                    ;RETURN
5512
5513
5514                                     ; ACTION ROUTINE TO CHECK FOR MORE INPUT AFTER MESSAGE TYPE HAS BEEN
5515                                     ;ALTERED
5516                                     ;
5517                                     ;
5518
5519 103656 004737 103242 ACTTYP: JSR    PC,ACTMSG                            ;CHECK FOR ADDITIONAL COMMANDS
5520 103662 000207                                RTS      PC
5521
5522
5523                                     ; ACTION ROUTINE TO INPUT MESSAGE SIZE PARAMETER, CHECK TO SEE IF
5524                                     ;IT IS WITHIN LEGAL LIMITS, CHANGE PARAMETER AND THEN RETURN TO
5525                                     ;SEE IF MORE INPUT EXISTA
5526                                     ;
5527                                     ;
5528
5529 103664 023727 003154 000037 ACTSIZE: CMP    P#NUM,#31.                            ;CHECK FOR VALID SIZE RANGE
5530 103672 003410                BLE   10#
5531 103674 022737 002673 003154        CMP    #1467.,P#NUM
5532 103702 003404                BLE   10#                                    ;IF VALID CONTINUE
5533 103704 013737 003154 002372        MOV    P#NUM,P#SIZE                        ;SET MESSAGE SIZE
5534 103712 000410                BR     20#
5535 103714 103714 012746 054061        10#: PRINTF #SIZLMT                            ;PRINT SIZE LIMITS EXCEEDED MESSAGE
                                           MOV    #SIZLMT,-(SP)

```

```

103720 012746 000001
103724 010600
103726 104417
103730 062706 000004
5536 103734 004737 103242      20$: JSR PC,ACTMSG      ;CHECK FOR ADDITIONAL COMMANDS
5537 103740 000207
5538
5539
5540
5541      ;
5542      ;ACTION ROUTINE TO INPUT COPIES PARAMETER, CHECK TO SEE IF IT IS
5543      ;WITHIN LEGAL LIMITS, CHANGE PARAMETER AND THEN RETURN TO SEE IF
5544      ;MORE INPUT PARAMETERS EXIST
5545      ;
5546 103742 023727 003154 000000 ACTCPY: CMP P#NUM,#0      ;CHECK FOR VALID COPIES RANGE
5547 103750 003410      BLE 10$
5548 103752 022737 000400 003154      CMP #256.,P#NUM
5549 103760 003404      BLE 10$      ;IF VALID, CONTINUE
5550 103762 013737 003154 002374      MOV P#NUM,P#CPYS      ;SET MESSAGE COPIES
5551 103770 000410
5552 103772      10$: PRINTF #CPYLMT      ;PRINT COPY LIMIT EXCEEDED MESSAGE
103772 012746 053775      MOV #CPYLMT,-(SP)
103776 012746 000001      MOV #1,-(SP)
104002 010600      MOV SP,RO
104004 104417      TRAP C#PNTF
104006 062706 000004      ADD #4,SP
5553 104012 004737 103242      20$: JSR PC,ACTMSG      ;CHECK FOR ADDITIONAL COMMANDS
5554 104016 000207
5555
5556
5557      ;
5558      ;ACTION ROUTINE TO CLEAR NODE SPECIFIED BY PHYSICAL ADDRESS FROM NODE TABLE
5559      ;
5560
5561 104020 105037 003160 ACTNAD: CLR P#NNUF      ;CLEAR NOTNUF FLAG
5562 104024 105737 003162      TST P#AERR      ;SEE IF ADDRESS ENTERED WAS VALID
5563 104030 001051      BNE 35$      ;IF NOT, EXIT ACTION ROUTINE
5564 104032      P#PUSH R2,R3      ;SAVE R2 AND R3
5565 104036 012702 002314      MOV #ADRBUF,R2      ;MOVE ADDRESS OF ADDRESS INTO R2
5566 104042 012703 002404      MOV #NODTBL,R3      ;MOVE ADDRESS OF NODE TABLE INTO R3
5567 104046      21$: CALL CMPADR R2,R3      ;SEE IF ADDRESSES MATCH
5568 104060      P#POP R1
5569 104062 001416      BEQ 25$      ;IF YES, BR 25$
5570 104064 062703 000010      ADD #10,R3      ;ELSE POINT R3 TO NEXT ENTRY
5571 104070 022713 177777      CMP #-1,(R3)      ;SEE IF END OF TABLE
5572 104074 001364      BNE 21$      ;IF NOT, COMPARE NEXT ENTRY
5573 104076      PRINTF #NOCMPR      ;ELSE, PRINT ADDRESS DOESN'T COMPARE MSG.
104076 012746 054160      MOV #NOCMPR,-(SP)
104102 012746 000001      MOV #1,-(SP)
104106 010600      MOV SP,RO
104110 104417      TRAP C#PNTF
104112 062706 000004      ADD #4,SP
5574 104116 000414
5575 104120 005023      25$: BR 30$      ;RETURN
5576 104122 005023      CLR (R3).      ;ELSE, CLEAR NODE FROM TABLE
5577 104124 005023      CLR (R3).
5578 104126 005013      CLR (R3)

```

```

5579 104130          PRINTF  #ADRDEL          ;PRINT NODE DELETED FROM TABLE MESSAGE
      104130 012746 054340          MOV      #ADRDEL,-(SP)
      104134 012746 000001          MOV      #1,-(SP)
      104140 010600          MOV      SP,R0
      104142 104417          TRAP    C$PNTF
      104144 062706 000004          ADD      #4,SP
5580 104150          30$: P$POP  R2,R3          ;RESTORE R2 AND R3
5581 104154 000207          35$: RTS    PC          ;RETURN
5582
5583
5584
5585 ;ACTION ROUTINE TO CLEAR NODE TABLE
5586 ;
5587
5588 104156          ACTNAL: P$PUSH R2,R3          ;SAVE R2,R3
5589 104162 012703 000050          MOV      #TBLEN,R3          ;SET INCR. COUNTER TO 40
5590 104166 012702 002404          MOV      #NODTBL,R2        ;MOVE NODE TABLE ADDRESS INTO R2
5591 104172 005022          10$: CLR      (R2)+          ;CLEAR BYTE IN NODE TABLE
5592 104174 005303          DEC      R3                ;DECRIMENT COUNTER
5593 104176 001375          BNE     10$                ;CONTINUE UNTIL DONE
5594 104200          PRINTF  #TABCLR,#NOD        ;PRINT NODE TABLE CLEARED MESSAGE
      104200 012746 053701          MOV      #NOD,-(SP)
      104204 012746 054514          MOV      #TABCLR,-(SP)
      104210 012746 000002          MOV      #2,-(SP)
      104214 010600          MOV      SP,R0
      104216 104417          TRAP    C$PNTF
      104220 062706 000006          ADD      #6,SP
5595 104224 105037 003160          CLRB   P$NNUF          ;CLEAR NOTNUF FLAG
5596 104230          P$POP  R2,R3          ;RESTORE R2 AND R3
5597 104234 000207          RTS    PC
5598
5599
5600
5601 ;ACTION ROUTINE TO RUN SPECIFIED TEST
5602 ;
5603
5604 104236 105037 003160          ACTRUN: CLRB   P$NNUF          ; CLEAR 'NOT ENOUGH' FLAG
5605 104242 013737 003154 002376          MOV      P$NUM,P$PASS
5606 104250 022737 000032 002310          5$: CMP      #CRNALL,KEYWD1        ; SEE IF 'ALL' TEST
5607 104256 001004          BNE     10$                ; IF NO, CONTINUE
5608 104260          CALL   RUNALL              ; IF YES, DO ALLNODE
5609 104266 000423          BR     30$
5610 104270 022737 000033 002310          10$: CMP      #CLUPPR,KEYWD1       ; IS IT 'LOOPPA'R' TEST
5611 104276 001004          BNE     15$                ; IF NO, CONTINUE
5612 104300          CALL   RUNLUP              ; IF YES, DO LOOPPAIR
5613 104306 000413          BR     30$
5614 104310 022737 000043 002310          15$: CMP      #CDIR,KEYWD1        ; IS IT 'DIRECT' TEST
5615 104316 001004          BNE     20$                ; IF NO, CONTINUE
5616 104320          CALL   RUNDIR              ; IF YES, DO DIRECT
5617 104326 000403          BR     30$
5618 104330          CALL   RUNPAT              ; ELSE, ITS 'PATTERN' TEST
5619 104336 023727 002376 177777          30$: CMP      P$PASS,#-1          ; SEE IF PASS SET FOR INDEFINATE
5620 104344 001741          BEQ     5$                ; IF YES, LOOP
5621 104346 005337 002376          DEC     P$PASS              ; HAVE WE DONE ALL PASSES?
5622 104352 001336          BNE     5$                ; IF NO, LOOP
5623 104354 000207          RTS    PC
5624

```



```

5625
5626 ; ACTION ROUTINE TO SET 'RUN ALL' FLAG
5627 ;
5628
5629 104356 012737 000032 002310 ACTRNA: MOV @CRNALL,KEYWD1 ; SET FLAG
5630 104364 000207 RTS PC
5631
5632 104366 RUNALL: CALL DIRCOM ; RUN LOOPDIRECT TEST
5633 104374 P$POP R1 ; CHECK RESULTS
5634 104376 001415 BEQ 5$ ; IF OK, BRANCH
5635 104400 022701 000001 CMP @1,R1 ; ELSE, WAS TABLE EMPTY?
5636 104404 001410 BEQ 3$ ; IF YES, DON'T PRINT ABORT MESSAGE
5637 104406 PRINTS @PASABT ; ELSE ABORT TEST AND PRINT MESSAGE
104406 012746 061526 MOV @PASABT,-(SP)
104412 012746 000001 MOV @1,-(SP)
104416 010600 MOV SP,R0
104420 104416 TRAP C$PNTS
104422 062706 000004 ADD @4,SP
5638 104426 000137 104774 3$: JMP 32$
5639 104432 012737 002404 002402 5$: MOV @NODTBL,SLOT ; MOVE NODE TABLE ADDRESS TO SLOT
5640 104440 CALL FULSLT ; FIND FIRST ENTRY
5641 104446 013701 002402 MOV SLOT,R1 ; AND PUT TARGET ADDRESS INTO R1
5642 104452 013737 002374 050562 10$: MOV P$CPYS,CPYCNT ; SET UP LOOP FOR NO. OF COPIES
5643 104460 062737 000010 002402 ADD @10,SLOT ; UPDATE SLOT
5644 104466 CALL FULSLT ; GET NEXT ASSIST NODE FROM TABLE
5645 104474 013702 002402 MOV SLOT,R2
5646 104500 022737 177777 002402 CMP @-1,SLOT ; SEE IF AT END OF TABLE
5647 104506 001515 BEQ 25$ ; IF YES, BR
5648 104510 15$: CALL BLDFA$ R1,SLOT ; BUILD FULL ASSIST MESSAGE
5649 104524 CALL XMIT ; TRANSMIT MESSAGE
5650 104532 P$POP R3 ; CHECK RESULTS
5651 104534 001404 BEQ 17$ ; IF OK, CONTINUE
5652 104536 ERRHRD 37,EMSG24 ; PRINT ERROR MESSAGE
104536 104456 TRAP C$ERHRD
104540 000045 .WORD 37
104542 065366 .WORD EMSG24
104544 000000 .WORD 0
5653 104546 17$: CALL BINHEX R1,@6,@STRBUF ; PRINT ERROR MESSAGE
5654 104566 CALL BINHEX R2,@6,@STRBU1 ;
5655 104606 PRINTB @TSTMS4,@ARGTY7,@STRBUF,@ARGTY6,@STRBU1 ; ASSIST NODE =
104606 012746 002344 MOV @STRBU1,-(SP)
104612 012746 062603 MOV @ARGTY6,-(SP)
104616 012746 002322 MOV @STRBUF,-(SP)
104622 012746 062613 MOV @ARGTY7,-(SP)
104626 012746 061624 MOV @TSTMS4,-(SP)
104632 012746 000005 MOV @5,-(SP)
104636 010600 MOV SP,R0
104640 104414 TRAP C$PNTB
104642 062706 000014 ADD @14,SP
5656 104646 CALL RUNCOM ; DO RECEIVE LOOP
5657 104654 P$POP R4 ; CHECK RESULTS
5658 104656 001405 BEQ 21$ ; IF OK, LOOP SOME MORE
5659 104660 20$: ERRHRD 28,EMSG42,ERR3 ; ELSE PRINT ERROR MESSAGE
104660 104456 TRAP C$ERHRD
104662 000034 .WORD 28
104664 066353 .WORD EMSG42
104666 067604 .WORD ERR3

```

```

5660 104670 000410
5661 104672          21$: BR      101$
      104672 012746 062013          PRINTB #OKFU
      104676 012746 000001
      104702 010600
      104704 104414
      104706 062706 000004
5662 104712 005337 050562          101$: DEC      CPYCNT      ; DECREMENT 'COPIES' COUNTER
5663 104716 001274          BNE      15$          ; IF MORE TO DO, LOOP
5664 104720          CALL     WRITES #2,R1,SLOT ; ELSE, UPDATE SUMMARY TABLE
5665 104740 000644          BR      10$
5666 104742 062701 000010          25$: ADD      #10,R1      ; POINT R1 TO NEXT TARGET NODE
5667 104746 010137 002402          MOV      R1,SLOT      ; UPDATE SLOT
5668 104752          CALL     FULSLT     ; GET ADDRESS FROM TABLE
5669 104760 013701 002402          MOV      SLOT,R1
5670 104764 022737 177777 002402          CMP      #-1,SLOT     ; SEE IF END OF TABLE
5671 104772 001227          BNE      10$          ; IF NO, CONTINUE ELSE, FINISHED
5672 104774          32$: RETURN
5673
5674
5675          ; ACTION ROUTINE TO SET 'RUN LOOP DIRECT' FLAG
5676          ;
5677
5678 104776 012737 000043 002310 ACTDIR: MOV      #CDIR,KEYWD1 ; SET FLAG
5679 105004 000207          RTS      PC
5680
5681 105006          RUNDIR: CALL     DIRCOM      ; CALL COMMON CODE
5682 105014          P$POP     R1
5683 105016 022701 000001          CMP      #1,R1      ; WAS TABLE EMPTY?
5684 105022 001400          BEQ      10$          ; IF YES, DON'T PRINT
5685 105024          10$: RETURN
5686
5687 105026 005001          DIRCOM: CLR      R1      ; CLEAR RESULTS REGISTER
5688 105030 012737 002404 002402          MOV      #NODTBL,SLOT ; MOVE NODE TABLE ADDRESS TO SLOT
5689 105036          CALL     FULSLT     ; SEE IF TABLE EMPTY
5690 105044 022737 177777 002402          CMP      #-1,SLOT     ;
5691 105052 001015          BNE      9$          ; IF NO CONTINUE
5692 105054          PRINTF  #TABEMT,#NOD ; ELSE, PRINT "TABLE EMPTY" MESSAGE
      105054 012746 053701          MOV      #NOD,-(SP)
      105060 012746 053632          MOV      #TABEMT,-(SP)
      105064 012746 000002          MOV      #2,-(SP)
      105070 010600          MOV      SP,RO
      105072 104417          TRAP     C$PNTF
      105074 062706 000006          ADD      #6,SP
5693 105100 012701 000001          MOV      #1,R1      ; PUT 'TABLE EMPTY' INDICATOR IN R1
5694 105104 000545          BR      32$
5695 105106 012737 002404 002402 9$: MOV      #NODTBL,SLOT
5696 105114 013737 002374 050562 10$: MOV      P$CPYS,CPYCNT ; SET UP FOR NO. OF COPIES
5697 105122          CALL     FULSLT     ; GET NEXT NODE IN TABLE
5698 105130 022737 177777 002402          CMP      #-1,SLOT     ; SEE IF AT END OF TABLE
5699 105136 001530          BEQ      32$          ; IF YES, EXIT
5700 105140          CALL     BINHEX  SLOT,#6,#STRBUF ; PRINT ADDRESS BEING TESTED
5701 105162          15$: PRINTB #TSTMS2,#DIRECT,#STRBUF ; NODE ADDRESS
      105162 012746 002322          MOV      #STRBUF,-(SP)
      105166 012746 062173          MOV      #DIRECT,-(SP)
      105172 012746 061571          MOV      #TSTMS2,-(SP)
      105176 012746 000003          MOV      #3,-(SP)
  
```

	105202	010600							MOV	SP,RO
	105204	104414							TRAP	C\$PNTB
	105206	062706	000010						ADD	#10,SP
5702	105212	022737	000005	002310		CMP	#CPATRN,KEYWD1			
5703	105220	001016				BNE	16\$			
5704	105222	013701	002370			MOV	P\$TYPE,R1			
5705	105226	006301				ASL	R1			
5706	105230	062701	003262			ADD	#MSGTAB,R1			
5707	105234					PRINTB	#MESPA1,(R1)			
	105234	011146							MOV	(R1),-(SP)
	105236	012746	062125						MOV	#MESPA1, -(SP)
	105242	012746	000002						MOV	#2, -(SP)
	105246	010600							MOV	SP,RO
	105250	104414							TRAP	C\$PNTB
	105252	062706	000006						ADD	#6,SP
5708	105256				16\$:	CALL	BLDLD SLOT			; CALL BUILD LOOPDIRECT SUBROUTINE
5709	105270					CALL	XMIT			; TRANSMIT LOOPDIRECT MESSAGES
5710	105276					P\$POP	R2			; GET RESULTS, R2 = SUCCESS/FAILURE
5711	105300	001405				BEQ	26\$; IF OK, EXIT
5712	105302				25\$:	ERRHRD	26,MSG24			; ELSE PRINT ERROR MESSAGE
	105302	104456							TRAP	C\$ERHRD
	105304	000032							.WORD	26
	105306	065366							.WORD	MSG24
	105310	000000							.WORD	0
5713	105312	000700				BR	10\$			
5714	105314				26\$:	CALL	RUNCOM			; DO RECIEVE LOOP
5715	105322					P\$POP	R4			; GET RESULTS
5716	105324	001407				BEQ	29\$; IF NO ERRORS, CONTINUE
5717	105326					ERRHRD	27,MSG34,ERR2			
	105326	104456							TRAP	C\$ERHRD
	105330	000033							.WORD	27
	105332	065732							.WORD	MSG34
	105334	067516							.WORD	ERR2
5718	105336	012701	177777			MOV	#-1,R1			; PUT ERROR INDICATOR INTO R1
5719	105342	000410				BR	101\$			
5720	105344				29\$:	PRINTB	#OK			; RESPONSE OK
	105344	012746	061661						MOV	#OK, -(SP)
	105350	012746	000001						MOV	#1, -(SP)
	105354	010600							MOV	SP,RO
	105356	104414							TRAP	C\$PNTB
	105360	062706	000004						ADD	#4,SP
5721	105364	005337	050562		101\$:	DEC	CPYCNT			; DECREMENT 'COPIES' COUNTER
5722	105370	001274				BNE	15\$; IF MORE TO DO, LOOP
5723	105372					CALL	WRITES #1,SLOT			; ELSE,UPDATE SUMMARY TABLE
5724	105410	062737	000010	002402	30\$:	ADD	#10,SLOT			; INCREMENT TO NEXT NODE TABLE ENTRY
5725	105416	000636				BR	10\$			
5726	105420				32\$:	RETURN	R1			
5727										
5728										
5729										
5730										
5731										
5732										
5733	105424	012737	000033	002310	ACTRNL:	MOV	#CLUPPR,KEYWD1			; SET FLAG
5734	105432	000207				RTS	PC			
5735										
5736	105434	005037	050552		RUNLUP:	CLR	TEMP1			; CLEAR 'HEADER PRINTED' FLAG


```

5737 105440 012737 002404 002402      MOV      #NODTBL,SLOT      ; MOVE NODE TABLE ADDRESS TO SLOT
5738 105446                                CALL     FULSLT           ; SEE IF TABLE EMPTY
5739 105454 022737 177777 002402      CMP      #-1,SLOT        ;
5740 105462 001014                                BNE      9$              ; IF NO, CONTINUE
5741 105464                                PRINTF   #TABEMT,#NOD    ; ELSE, PRINT "TABLE EMPTY" MESSAGE
105464 012746 053701                                MOV      #NOD,-(SP)
105470 012746 053632                                MOV      #TABEMT,-(SP)
105474 012746 000002                                MOV      #2,-(SP)
105500 010600                                MOV      SP,RO
105502 104417                                TRAP     C$PNTF
105504 062706 000006                                ADD      #6,SP
5742 105510 000137 106524                                JMP      30$
5743 105514 012737 002404 002402 9$:      MOV      #NODTBL,SLOT    ; MOVE NODE TABLE ADDRESS TO SLOT
5744 105522 013737 002374 050562 10$:      MOV      P$CPYS,CPYCNT  ; SET UP FOR NO. OF COPIES
5745 105530                                CALL     FULSLT         ; GET NEXT NODE IN TABLE
5746 105536 022737 177777 002402      CMP      #-1,SLOT        ; SEE IF AT END OF TABLE
5747 105544 001002                                BNE      11$           ; IF YES, EXIT
5748 105546 000137 106524                                JMP      30$
5749 105552 013701 002402 11$:      MOV      SLOT,R1        ; MOVE SLOT TO R1
5750 105556 126127 000007 000000      CMPB    7(R1),#CTARGT   ; SEE IF TARGET NODE
5751 105564 001422                                BEQ      18$           ; IF YES, BRANCH
5752 105566 012746 065637 17$:      PRINTF   #EMSG32        ; ELSE PRINT ERROR MESSAGE
105566 012746 065637                                MOV      #EMSG32,-(SP)
105572 012746 000001                                MOV      #1,-(SP)
105576 010600                                MOV      SP,RO
105600 104417                                TRAP     C$PNTF
105602 062706 000004                                ADD      #4,SP
5753 105606                                PRINTF   #PASABT
105606 012746 061526                                MOV      #PASABT,-(SP)
105612 012746 000001                                MOV      #1,-(SP)
105616 010600                                MOV      SP,RO
105620 104417                                TRAP     C$PNTF
105622 062706 000004                                ADD      #4,SP
5754 105626 000137 106524                                JMP      30$           ; EXIT
5755 105632 010102 18$:      MOV      R1,R2          ; POINT R1 TO TARGET NODE
5756 105634 062702 000010 112$:      ADD      #10,R2        ; AND R2 TO ASSIST NODE
5757 105640 021227 000000      CMP      (R2),#0
5758 105644 001773      BEQ      112$
5759 105646 022712 177777      CMP      #-1,(R2)
5760 105652 001002      BNE      110$
5761 105654 000137 106524      JMP      30$
5762 105660 126227 000007 000001 110$:      CMPB    7(R2),#CASIST  ; IS R2 POINTING TO AN ASSIST NODE?
5763 105666 001337      BNE      17$           ; IF NOT, ERROR, ELSE CONTINUE
5764 105670 20$:      CALL     BLDAST R2,R1  ; BUILD TRANSMIT ASSIST MESSAGE
5765 105702      CALL     XMIT         ; TRANSMIT MESSAGE
5766 105710      P$POP    R4          ; GET RESULTS, R2 = SUCCESS/FAILURE
5767 105712 001406      BEQ      22$           ; IF OK, EXIT
5768 105714 21$:      ERRHRD  26,EMSG24    ; ELSE PRINT ERROR MESSAGE
105714 104456                                TRAP     C$ERHRD
105716 000032                                .WORD   26
105720 065366                                .WORD   EMSG24
105722 000000                                .WORD   0
5769 105724 000137 106440      JMP      28$
5770 105730 22$:      CALL     BINHEX R1,#6,#STRBUF ; PRINT ERROR MESSAGE
5771 105750      CALL     BINHEX R2,#6,#STRBU1 ;
5772 105770      PRINTB  #TSTMS4,#ARGTY7,#STRBUF,#ARGTY6,#STRBU1 ; ASSIST NODE =
105770 012746 002344                                MOV      #STRBU1,-(SP)

```

105774	012746	062603				MOV	#ARGTY6,-(SP)
106000	012746	002322				MOV	#STRBUF,-(SP)
106004	012746	062613				MOV	#ARGTY7,-(SP)
106010	012746	061624				MOV	#TSTMS4,-(SP)
106014	012746	000005				MOV	#5,-(SP)
106020	010600					MOV	SP,RO
106022	104414					TRAP	C\$PNTB
106024	062706	000014				ADD	#14,SP
5773	106030			CALL	RUNCCM		; DO RECIEVE LOOP
5774	106036			P\$POP	R3		; CHECK RESULTS
5775	106040	001405		BEQ	23\$; IF OK, CONT.
5776	106042			ERRHRD	28,MSG40,ERR3		
	106042	104456				TRAP	C\$ERHRD
	106044	000034				.WORD	28
	106046	066174				.WORD	MSG40
	106050	067604				.WORD	ERR3
5777	106052	000410		BR	101\$		
5778	106054		23\$:	PRINTB	#OKRE		
	106054	012746	061702			MOV	#OKRE,-(SP)
	106060	012746	000001			MOV	#1,-(SP)
	106064	010600				MOV	SP,RO
	106066	104414				TRAP	C\$PNTB
	106070	062706	000004			ADD	#4,SP
5779	106074			101\$:	CALL	BLDAST R1,R2	; BUILD RECEIVE ASSIST MESSAGE
5780	106106				CALL	XMIT	; TRANSMIT MESSAGE
5781	106114				P\$POP	R4	; CHECK RESULTS
5782	106116	001276			BNE	21\$; IF OK CONTINUE, ELSE REPORT ERROR
5783	106120				CALL	BINHEX R1,#6,#STRBUF	; PRINT ERROR MESSAGE
5784	106140				CALL	BINHEX R2,#6,#STRBU1	
5785	106160				PRINTB	#TSTMS4,#ARGTY7,#STRBUF,#ARGTY6,#STRBU1	; ASSIST NODE =
	106160	012746	002344			MOV	#STRBU1,-(SP)
	106164	012746	062603			MOV	#ARGTY6,-(SP)
	106170	012746	002322			MOV	#STRBUF,-(SP)
	106174	012746	062613			MOV	#ARGTY7,-(SP)
	106200	012746	061624			MOV	#TSTMS4,-(SP)
	106204	012746	000005			MOV	#5,-(SP)
	106210	010600				MOV	SP,RO
	106212	104414				TRAP	C\$PNTB
	106214	062706	000014			ADD	#14,SP
5786	106220			CALL	RUNCOM		; DO RECEIVE LOOP
5787	106226			P\$POP	R3		; GET RESULTS
5788	106230	001405		BEQ	25\$; IF OK, CONT.
5789	106232			ERRHRD	28,MSG41,ERR3		
	106232	104456				TRAP	C\$ERHRD
	106234	000034				.WORD	28
	106236	066263				.WORD	MSG41
	106240	067604				.WORD	ERR3
5790	106242	000410		BR	102\$		
5791	106244			25\$:	PRINTB	#OKTR	
	106244	012746	061746			MOV	#OKTR,-(SP)
	106250	012746	000001			MOV	#1,-(SP)
	106254	010600				MOV	SP,RO
	106256	104414				TRAP	C\$PNTB
	106260	062706	000004			ADD	#4,SP
5792	106264			102\$:	CALL	BLDFAS R1,R2	; BUILD FULL ASSIST MESSAGE
5793	106276				CALL	XMIT	; TRANSMIT MESSAGE
5794	106304				P\$POP	R4	; CHECK RESULTS

5795	106306	001402		BEG	26\$; IF OK CONTINUE, ELSE REPORT ERROR
5796	106310	000137	105714	JMP	21\$		
5797	106314			26\$: CALL	BINHEX R1,#6,#STRBUF		; PRINT ERROR MESSAGE
5798	106334			CALL	BINHEX R2,#6,#STRBU1		
5799	106354			PRINTB	#TSTMS4,#ARGTY7,#STRBUF,#ARGTY6,#STRBU1		; ASSIST NODE =
	106354	012746	002344			MOV	#STRBU1,-(SP)
	106360	012746	062603			MOV	#ARGTY6,-(SP)
	106364	012746	002322			MOV	#STRBUF,-(SP)
	106370	012746	062613			MOV	#ARGTY7,-(SP)
	106374	012746	061624			MOV	#TSTMS4,-(SP)
	106400	012746	000005			MOV	#5,-(SP)
	106404	010600				MOV	SP,R0
	106406	104414				TRAP	C#PNTB
	106410	062706	000014			ADD	#14,SP
5800	106414			CALL	RUNCOM		; DO RECEIVE LOOP
5801	106422			P#POP	R3		; CHECK RESULTS
5802	106424	001405		BEG	28\$; IF NO ERRORS, CONT
5803	106426			ERRHRD	28,MSG42,ERR3		
	106426	104456				TRAP	C#ERHRD
	106430	000034				.WORD	28
	106432	066353				.WORD	MSG42
	106434	067604				.WORD	ERR3
5804	106436	000410		BR	103\$		
5805	106440			28\$: PRINTB	#OKFU		
	106440	012746	062013			MOV	#OKFU,-(SP)
	106444	012746	000001			MOV	#1,-(SP)
	106450	010600				MOV	SP,R0
	106452	104414				TRAP	C#PNTB
	106454	062706	000004			ADD	#4,SP
5806	106460	005337	050562	103\$: DEC	CPYCNT		; DECREMENT 'COPIES' COUNTER
5807	106464	001402		BEG	29\$; IF MORE TO DO, LOOP
5808	106466	000137	105670	JMP	20\$		
5809	106472			29\$: CALL	WRITES #2,R1,R2		; ELSE,UPDATE SUMMARY TABLE
5810	106510	062702	000010	ADD	#10,R2		
5811	106514	010237	002402	MOV	R2,SLOT		; INCREMENT TO NEXT NODE TABLE ENTRY
5812	106520	000137	105522	JMP	10\$		
5813	106524			30\$: RETURN			
5814							
5815	106526	005737	050534	RUNCOM: TST	RETRYS		; SEE IF FAILED DUE TO EXCESSIVE COLLISIONS
5816	106532	001120		BNE	38\$; IF YES, BR, ELSE CONT.
5817	106534	012704	003720	MOV	#TIMERS,R4		; SET UP FOR 10 SECOND TIMEOUT
5818	106540	012714	000012	MOV	#10.,(R4)		
5819	106544	005002		CLR	R2		; CLEAR RESULTS REGISTER
5820	106546			35\$: BREAK			
	106546	104422				TRAP	C#BRK
5821	106550	005714		TST	(R4)		; SEE IF TIME HAS EXPIRED
5822	106552	001516		BEG	40\$; IF YES, BRANCH
5823	106554			CALL	RECEVE		; CHECK FOR ANSWER
5824	106562			P#POP	R1		; R2 HOLDS NO. OF BUFFERS RECEIVED
5825	106564	001770		BEG	35\$; IF NO BUFFERS RECIEVED, LOOP
5826	106566	063737	050560 050510	ADD	XFER,S.XFER		; UPDATE BYTES TRANSFERED SUM. COUNTER
5827	106574	005237	050476	INC	S.REC		; UPDATE PACKETS RECEIVED SUM. COUNTER
5828	106600	013703	003764	MOV	RRGNXT,R3		; GET RECEIVE RING POINTER
5829	106604			CALL	GETRNX #RRGNXT		; UPDATE POINTER
5830	106616	016301	000006	MOV	6(R3),R1		; GET PACKET LENGTH FROM DISCRIPTOR
5831	106622	042701	170000	BIC	#170000,R1		; ZERO OUT EXCESS INFOR
5832	106626	162701	000004	SUB	#4,R1		; SUBTRACT CRC BYTES


```

5833 106632 020137 050566          CMP      R1,BUFLEN          ; CHECK FOR LENGTH ERROR
5834 106636 001423                   BEQ      37$                ; IF OK, BR
5835 106640 005237 050502          INC      S.LEN              ; ELSE, UPDATE LENGTH ERRORS COUNTER
5836 106644 012737 062342 002312    MOV      @LENGTH,KEYWD2     ; MOVE 'LENGTH' TO ERROR INDICATOR
5837 106652 012702 177777          MOV      @-1,R2             ; INDICATE ERROR TO R2
5838 106656                   PRINTX   @LGERMS,BUFLEN,R1  ; PRINT LENGTH ERROR MESSAGE
                                MOV      R1,-(SP)
                                MOV      BUFLN,-(SP)
                                MOV      @LGERMS,-(SP)
                                MOV      @3,-(SP)
                                MOV      SP,R0
                                TRAP    C$PNTX
                                ADD     @10,SP
5839 106704 000450                   BR       50$                ; AND EXIT
5840 106706 016303 000002 37$:     MOV      2(R3),R3           ; POINT R3 TO MESSAGE BUFFER
5841 106712 066303 000016          ADD     16(R3),R3          ; POINT R3 TO DATA AFTER SKIP COUNT
5842 106716 062703 000030          ADD     @30,R3            ; POINT R3 TO FIRST DATA BYTE
5843 106722 063737 002372 050506    ADD     P$SIZE,S.BYTE      ; UPDATE BYTES COMPARED SUMMARY COUNTER
5844 106730                   CALL    DATCMP P$SIZE,CMPBUF,R3 ; CHECK FOR DATA COMPARE ERRORS
5845 106750                   P$POP   R3                  ; CHECK RESULTS
5846 106752 001425                   BEQ     50$                 ; IF ERRORS,
5847 106754 060337 050504          ADD     R3,S.COMP          ; UPDATE COMPARE ERRORS SUMMARY COUNTER
5848 106760 012737 062351 002312    MOV     @COMPAR,KEYWD2     ; MOVE 'COMPARE' TO ERROR INDICATOR
5849 106766 012702 177777          MOV     @-1,R2             ; INDICATE ERROR TO R2
5850 106772 000415                   BR      50$
5851
5852 106774 012737 062316 002312 38$:     MOV     @RETRY,KEYWD2      ; MOVE 'EXCESSIVE COLLISIONS' TO ERROR INCICATOR
5853 107002 012702 177777          MOV     @-1,R2             ; INDICATE ERROR IN R2
5854 107006 000407                   BR      50$
5855
5856 107010 005237 050500          INC     S.NREC             ; UPDATE MESSAGES NOT RECEIVED COUNTER
5857 107014 012737 062302 002312    MOV     @NORESP,KEYWD2    ; MOVE 'NO RESPONCE' TO ERROR INDICATOR
5858 107022 012702 177777          MOV     @-1,R2             ; INDICATE ERROR TO R2
5859
5860 107026                   50$:     RETURN  R2                ; RETURN
5861
5862
5863
5864 ; ACTION ROUTINE TO SET 'RUN PATTERN' FLAG
5865 ;
5866
5867 107032 012737 000005 002310 ACTPAT: MOV     @CPATRN,KEYWD1    ; SET FLAG
5868 107040 000207                   RTS      PC
5869
5870
5871 107042                   RUNPAT: P$PUSH  P$TYPE      ; SAVE TYPE PARAMETER
5872 107046 005037 002370          CLR     P$TYPE            ; SET TYPE TO FIRST TYPE
5873 107052                   5$:     CALL    DIRCOM          ; SEND MESSAGES
5874 107060                   P$POP   R1                  ; GET RESULTS TO KEEP STACK IN ORDER
5875 107062 001403                   BEQ     10$                 ; IF OK, CONT
5876 107064 022701 000001          CMP     @1,R1              ; ELSE, WAS TABLE EMPTY
5877 107070 001406                   BEQ     15$                 ; IF YES, RETURN
5878 107072 005237 002370          INC     P$TYPE            ; SET TO NEXT TYPE
5879 107076 022737 000005 002370    CMP     @5,P$TYPE          ; SEE IF DONE ALL OF THEM
5880 107104 002362                   BGE     5$                  ; IF NOT, DO MORE
5881 107106                   15$:    P$POP   P$TYPE          ; RESTORE MESSAGE TYPE
5882 107112                   RETURN

```

```

5883
5884
5885 ; ACTION ROUTINE TO SHOW THE CURRENT MESSAGE PARAMETERS
5886 ;
5887
5888 107114 013701 002370 ACTSMS: MOV P$TYPE,R1 ;GET MESSAGE TYPE INTO R1
5889 107120 006301 ASL R1 ;MULTIPLY BY 2
5890 107122 062701 003262 ADD #MSGTAB,R1 ;ADD MESSAGE TABLE OFFSET
5891 107126 PRINTF #MSGPRM ;PRINT MESSAGE PARAMETER MESSAGE
107126 012746 054641 MOV #MSGPRM,-(SP)
107132 012746 000001 MOV #1,-(SP)
107136 010600 MOV SP,R0
107140 104417 TRAP C$PNTF
107142 062706 000004 ADD #4,SP
5892 107146 PRINTF #MSG4,(R1),P$SIZE,P$CPYS ;PRINT PARAMETERS
107146 013746 002374 MOV P$CPYS,-(SP)
107152 013746 002372 MOV P$SIZE,-(SP)
107156 011146 MOV (R1),-(SP)
107160 012746 055276 MOV #MSG4,-(SP)
107164 012746 000004 MOV #4,-(SP)
107170 010600 MOV SP,R0
107172 104417 TRAP C$PNTF
107174 062706 000012 ADD #12,SP
5893 107200 105037 003160 CLR B P$NNUF
5894 107204 000207 RTS PC
5895
5896
5897
5898 ; ACTION ROUTINE TO CLEAR THE CURRENT MESSAGE PARAMETERS AND
5899 ; RESET THEM TO THE DEFAULT VALUE
5900 ;
5901
5902 107206 012737 000000 002370 ACTCMS: MOV #ALPHA,P$TYPE ;RESET TYPE
5903 107214 012737 001000 002372 MOV #512.,P$SIZE ;RESET SIZE
5904 107222 012737 000001 002374 MOV #1,P$CPYS ;RESET COPIES
5905 107230 PRINTF #CLRMSG ;PRINT MESSAGE PARAMETERS RESET MESSAGE
107230 012746 053716 MOV #CLRMSG,-(SP)
107234 012746 000001 MOV #1,-(SP)
107240 010600 MOV SP,R0
107242 104417 TRAP C$PNTF
107244 062706 000004 ADD #4,SP
5906 107250 PRINTF #MSG4,MSGTAB,P$SIZE,P$CPYS ;PRINT PARAMETERS
107250 013746 002374 MOV P$CPYS,-(SP)
107254 013746 002372 MOV P$SIZE,-(SP)
107260 013746 003262 MOV MSGTAB,-(SP)
107264 012746 055276 MOV #MSG4,-(SP)
107270 012746 000004 MOV #4,-(SP)
107274 010600 MOV SP,R0
107276 104417 TRAP C$PNTF
107300 062706 000012 ADD #12,SP
5907 107304 105037 003160 CLR B P$NNUF ;CLEAR NOTNUF FLAG
5908 107310 000207 RTS PC
5909
5910
5911 ; ACTION ROUTINE TO SET SHOW COUNTERS FLAG
5912 ;
5913

```

5914									
5915	107312			ACTCNT: CALL	FUNCT #RDCNTS				;READ COUNTERS
5916	107324			P\$POP	R1				;CHECK RESULT
5917	107326	001402		BEQ	21\$;BRANCH IF ERROR
5918	107330	000137	110356	JMP	40\$				
5919									;PRINT COUNTER INFO
5920									
5921	107334			21\$: CALL	BINHEX #PHYADR,#6,#STRBUF				;GET ADDRESS INTO ASCII
5922	107356			PRINTF	#CNTR00,#STRBUF				
	107356	012746	002322					MOV	#STRBUF,-(SP)
	107362	012746	062703					MOV	#CNTR00,-(SP)
	107366	012746	000002					MOV	#2,-(SP)
	107372	010600						MOV	SP,RO
	107374	104417						TRAP	C\$PNTF
	107376	062706	000006					ADD	#6,SP
5923	107402			PRINTF	#CNTR01,UCB12+2				
	107402	013746	050162					MOV	UCB12+2,-(SP)
	107406	012746	062763					MOV	#CNTR01,-(SP)
	107412	012746	000002					MOV	#2,-(SP)
	107416	010600						MOV	SP,RO
	107420	104417						TRAP	C\$PNTF
	107422	062706	000006					ADD	#6,SP
5924	107426			CALL	BINDEC #UCB12+4				
5925	107440			PRINTF	#CNTR02,#DECSTR				
	107440	012746	075200					MOV	#DECSTR,-(SP)
	107444	012746	063032					MOV	#CNTR02,-(SP)
	107450	012746	000002					MOV	#2,-(SP)
	107454	010600						MOV	SP,RO
	107456	104417						TRAP	C\$PNTF
	107460	062706	000006					ADD	#6,SP
5926	107464			CALL	BINDEC #UCB12+10				
5927	107476			PRINTF	#CNTR03,#DECSTR				
	107476	012746	075200					MOV	#DECSTR,-(SP)
	107502	012746	063066					MOV	#CNTR03,-(SP)
	107506	012746	000002					MOV	#2,-(SP)
	107512	010600						MOV	SP,RO
	107514	104417						TRAP	C\$PNTF
	107516	062706	000006					ADD	#6,SP
5928	107522			PRINTF	#CNTR04,UCB12+14				
	107522	013746	050174					MOV	UCB12+14,-(SP)
	107526	012746	063133					MOV	#CNTR04,-(SP)
	107532	012746	000002					MOV	#2,-(SP)
	107536	010600						MOV	SP,RO
	107540	104417						TRAP	C\$PNTF
	107542	062706	000006					ADD	#6,SP
5929	107546			PRINTF	#CNTR05,UCB12+16				
	107546	013746	050176					MOV	UCB12+16,-(SP)
	107552	012746	063210					MOV	#CNTR05,-(SP)
	107556	012746	000002					MOV	#2,-(SP)
	107562	010600						MOV	SP,RO
	107564	104417						TRAP	C\$PNTF
	107566	062706	000006					ADD	#6,SP
5930	107572			CALL	BINDEC #UCB12+20				
5931	107604			PRINTF	#CNTR06,#DECSTR				
	107604	012746	075200					MOV	#DECSTR,-(SP)
	107610	012746	063260					MOV	#CNTR06,-(SP)
	107614	012746	000002					MOV	#2,-(SP)

5944	110126			CALL	BINDEC	#UCB12.54			
5945	110140			PRINTF	#CNTR14,	#DECSTR			
	110140	012746	075200					MOV	#DECSTR,-(SP)
	110144	012746	063735					MOV	#CNTR14,-(SP)
	110150	012746	000002					MOV	#2,-(SP)
	110154	010600						MOV	SP,RO
	110156	104417						TRAP	C#PNTF
	110160	062706	000006					ADD	#6,SP
5946	110164			CALL	BINDEC	#UCB12.60			
5947	110176			PRINTF	#CNTR15,	#DECSTR			
	110176	012746	075200					MOV	#DECSTR,-(SP)
	110202	012746	063771					MOV	#CNTR15,-(SP)
	110206	012746	000002					MOV	#2,-(SP)
	110212	010600						MOV	SP,RO
	110214	104417						TRAP	C#PNTF
	110216	062706	000006					ADD	#6,SP
5948	110222			CALL	BINDEC	#UCB12.64			
5949	110234			PRINTF	#CNTR16,	#DECSTR			
	110234	012746	075200					MOV	#DECSTR,-(SP)
	110240	012746	064033					MOV	#CNTR16,-(SP)
	110244	012746	000002					MOV	#2,-(SP)
	110250	010600						MOV	SP,RO
	110252	104417						TRAP	C#PNTF
	110254	062706	000006					ADD	#6,SP
5950	110260			PRINTF	#CNTR17,UCB12.70				
	110260	013746	050250					MOV	UCB12.70,-(SP)
	110264	012746	064101					MOV	#CNTR17,-(SP)
	110270	012746	000002					MOV	#2,-(SP)
	110274	010600						MOV	SP,RO
	110276	104417						TRAP	C#PNTF
	110300	062706	000006					ADD	#6,SP
5951	110304			PRINTF	#CNTR18,UCB12.72				
	110304	013746	050252					MOV	UCB12.72,-(SP)
	110310	012746	064154					MOV	#CNTR18,-(SP)
	110314	012746	000002					MOV	#2,-(SP)
	110320	010600						MOV	SP,RO
	110322	104417						TRAP	C#PNTF
	110324	062706	000006					ADD	#6,SP
5952	110330			PRINTF	#CNTR19,UCB12.74				
	110330	013746	050254					MOV	UCB12.74,-(SP)
	110334	012746	064221					MOV	#CNTR19,-(SP)
	110340	012746	000002					MOV	#2,-(SP)
	110344	010600						MOV	SP,RO
	110346	104417						TRAP	C#PNTF
	110350	062706	000006					ADD	#6,SP
5953	110354	000404		BR	50\$				
5954									
5955	110356			40\$:	ERRHRD	31,EMSG31			
	110356	104456						TRAP	C#ERRHRD
	110360	000037						.WORD	31
	110362	065576						.WORD	EMSG31
	110364	000000						.WORD	0
5956									
5957	110366	105037	003160	50\$:	CLRR	P#NNUF			
5958	110372	000207			RTS	PC			
5959									
5960									

```

5961
5962      ; ACTION ROUTINE TO PRINT OUT THE NODE TABLE
5963      ;
5964
5965 110374 105037 003160 ACTSND: CLRB   P#NNUF
5966 110400 012737 002404 002402      MOV   #NODTBL,SLOT      ; MOVE NODE TABLE ADDRESS INTO SLOT
5967 110406      CALL  FULSLT      ; SEE IF TABLE EMPTY
5968 110414 022737 177777 002402      CMP   #-1,SLOT        ; IF YES, DON'T PRINT HEADER
5969 110422 001437      BEQ   15$
5970 110424      PRINTF #NTBHDR      ; PRINT NODE TABLE HEADER
      MOV   #NTBHDR,-(SP)
      MOV   #1,-(SP)
      MOV   SP,R0
      TRAP  C#PNTF
      ADD   #4,SP
5971 110444 104444 000000 10$: CALL  FULSLT      ; FIND LOCATION IN TABLE WITH AN ADDRESS
5972 110452 022737 177777 002402      CMP   #-1,SLOT        ; CHECK IF AT END OF TABLE
5973 110460 001432      BEQ   20$            ; IF YES, RETURN
5974 110462      CALL  BINHEX SLOT,#6,#STRBUF ; ELSE, PUT ASCII ADDRESS INTO BUFFER
5975 110504      CALL  PRNOD      ; PRINT NODE TABLE ENTRY
5976 110512 062737 000010 002402      ADD   #8.,SLOT        ; INCR. SLOT TO POINT TO NEXT TABLE ENTRY
5977 110520 000751      BR    10$            ; CONTINUE UNTIL ALL ENTRIES PRINTED
5978 110522      PRINTF #TABEMT,#NOD
      MOV   #NOD,-(SP)
      MOV   #TABEMT,-(SP)
      MOV   #2,-(SP)
      MOV   SP,R0
      TRAP  C#PNTF
      ADD   #6,SP
      110522 012746 053701
      110526 012746 053632
      110532 012746 000002
      110536 010600
      110540 104417
      110542 062706 000006
5979 110546 000207      20$: RTS    PC      ; RETURN
5980
5981
5982      ; ACTION ROUTINE TO CLEAR A NODE SPECIFIED BY NODE LOGICAL NAME
5983      ; FROM THE NODE TABLE
5984      ;
5985      ;
5986
5987 110550 ACTCNL: P#PUSH R2      ; SAVE R2
5988 110552 013702 003154      MOV   P#NUM,R2        ; PUT NODE LOGICAL NUMBER INTO R2
5989 110556 006302      ASL  R2              ; MULTIPLY BY 8
5990 110560 006302      ASL  R2              ; NODE TABLE ADDRESS =
5991 110562 006302      ASL  R2              ; (LOG. NO. X 8) + #NODTBL
5992 110564 062702 002404      ADD  #NODTBL,R2      ; ADD OFFSET
5993 110570 005022      CLR  (R2).           ; CLEAR ENTRY (8 BYTES)
5994 110572 005022      CLR  (R2).
5995 110574 005022      CLR  (R2).
5996 110576 005012      CLR  (R2)
5997 110600      P#POP R2            ; RESTORE R2
5998 110602 105037 003160      CLRB P#NNUF          ; CLEAR NOTNUF FLAG
5999 110606      PRINTF #LOGDEL,P#NUM ; PRINT MESSAGE INDICATING DELETION
      MOV   P#NUM,-(SP)
      MOV   #LOGDEL,-(SP)
      MOV   #2,-(SP)
      MOV   SP,R0
      TRAP  C#PNTF
      ADD   #6,SP
      110606 013746 003154
      110612 012746 054426
      110616 012746 000002
      110622 010600
      110624 104417
      110626 062706 000006
6000 110632 000207      RTS    PC      ; RETURN

```



```

6001
6002
6003      ; ACTION ROUTINE TO INITIATE A UNA PORT COMMAND
6004      ;
6005
6006 110634 105037 003160 ACTFCT: CLRB      P$NNUF      ; CLEAR NOTNUF FLAG
6007 110640          CALL      FUNCT P$NUM  ; CALL FUNCTION ROUTINE WITH FUNCTION CODE
6008 110652          P$POP      R1      ; CHECK RESULTS
6009 110654 001404      BEQ       1$      ; IF OK EXIT
6010 110656          ERRHRD    30,MSG30 ; ELSE REPORT ERROR
        110656 104456          TRAP      C$ERHRD
        110660 000036          .WORD    30
        110662 065531          .WORD    MSG30
        110664 000000          .WORD    0
6011 110666 000207      1$:      RTS      PC
6012
6013      ; ACTION ROUTINE TO SAVE NODE TABLE
6014      ;
6015
6016
6017 110670          ACTSAV: P$PUSH  R2,R3      ; SAVE R2 AND R3
6018 110674 012702 002404      MOV      @NODTBL,R2  ; SET REGISTERS FOR COPYING
6019 110700 012703 002530      MOV      @SAVTBL,R3  ; R2 = FROM, R3 = TO
6020 110704          PRINTF    @UNMSG,@SAVED ; PRINT 'TABLE SAVED' MESSAGE
        110704 012746 054620          MOV      @SAVED,-(SP)
        110710 012746 054561          MOV      @UNMSG,-(SP)
        110714 012746 000002          MOV      @2,-(SP)
        110720 010600          MOV      SP,R0
        110722 104417          TRAP      C$PNTF
        110724 062706 000006          ADD      @6,SP
6021 110730 000137 111012          JMP      SAVCOM
6022
6023      ; ACTION ROUTINE TO UNSAVE NODE TABLE
6024      ;
6025
6026
6027 110734 105037 003160 ACTUNS: CLRB      P$NNUF      ; CLEAR 'NOT ENOUGH' FLAG
6028 110740          P$PUSH  R2,R3      ; SAVE R2 AND R3
6029 110744 121427 000057      CMPB     (R4),#57
6030 110750 001002          BNE      5$
6031 110752 000137 111024          JMP      QUIT
6032 110756 012703 002404      5$:      MOV      @NODTBL,R3  ; SET REGISTERS FOR COPYING
6033 110762 012702 002530      MOV      @SAVTBL,R2  ; R2 = FROM, R3 = TO
6034 110766          PRINTF    @UNMSG,@RESTOR ; PRINT 'TABLE RESTORED' MESSAGE
        110766 012746 054627          MOV      @RESTOR,-(SP)
        110772 012746 054561          MOV      @UNMSG,-(SP)
        110776 012746 000002          MOV      @2,-(SP)
        111002 010600          MOV      SP,R0
        111004 104417          TRAP      C$PNTF
        111006 062706 000006          ADD      @6,SP
6035 111012 012701 000050      SAVCOM: MOV      @TBLEN,R1  ; MOVE TABLE LENGTH TO R1
6036 111016 012223      10$:      MOV      (R2)+,(R3)+ ; MOVE WORD
6037 111020 005301          DEC      R1      ; DECREMENT COUNTER
6038 111022 001375          BNE     10$      ; IF MORE, LOOP
6039 111024          QUIT:   P$POP      R2,R3  ; ELSE, RESTORE COUNTERS
6040 111030 105037 003160      CLRB     P$NNUF      ; CLEAR 'NOT ENOUGH' FLAG
6041 111034 000207      RTS      PC

```

```

6042
6043
6044      ; ACTION ROUTINE TO CLEAR SUMMARY TABLE
6045      ;
6046
6047 111036 105037 003160 ACTCSU: CLRB   P$NNUF      ; CLEAR 'NOT ENOUGH' COUNTER
6048 111042      P$PUSH  R2        ; SAVE R2
6049 111044 012701 000132      MOV   #STBLN,R1    ; MOVE TABLE LENGTH TO R1
6050 111050 012702 002656      MOV   #STATBL,R2   ; MOVE SUMMARY TABLE ADDRESS TO R2
6051 111054 005022      5$:   CLR   (R2)+      ; CLEAR FIRST WORD
6052 111056 005301      DEC   R1           ; SEE IF FINISHED
6053 111060 001375      BNE   5$          ; IF NO, DO MORE
6054 111062      PRINTF  #TABCLR,#SUMM ; ELSE, PRINT 'TABLE CLEARED' MESSAGE
        MOV   #SUMM,-(SP)
        MOV   #TABCLR,-(SP)
        MOV   #2,-(SP)
        MOV   SP,R0
        TRAP  C$PNTF
        ADD   #6,SP
        111062 012746 053706
        111066 012746 054514
        111072 012746 000002
        111076 010600
        111100 104417
        111102 062706 000006
6055 111106      P$POP  R2        ; AND RESTORE R2
6056 111110 000207      RTS   PC
6057
6058      ; ACTION ROUTINE TO CHECK FOR PASS DEFAULT VALUE
6059      ;
6060
6061
6062 111112 ACTDFT:
6063 111112 121427 000040 1$:   CMPB  (R4),#40    ; SEE IF SPACES
6064 111116 001002      BNE   2$          ; IF NO, CONT.
6065 111120 005204      INC   R4          ; ELSE, POINT TO NEXT CHAR
6066 111122 000773      BR   1$          ; AND CHECK AGAIN
6067 111124 121427 000000 2$:   CMPB  (R4),#0     ; SEE IF DEFAULT VALUE
6068 111130 001007      BNE   10$         ; IF NO, BR
6069 111132 012763 000030 000002  MOV   #30,2(R3)   ; IF YES, POINT R3 TO SKIP CHECK PASS COUNT
6070 111140 012737 000001 003154  MOV   #1,P$NUM    ; SET DEFAULT TO 1
6071 111146 000403      BR   15$         ; RETURN
6072 111150 012763 000004 000002 10$:  MOV   #4,2(R3)   ; POINT R3 TO CHECK FOR PASS COUNT
6073 111156 000207      15$:  RTS   PC
6074
6075      ; ACTION ROUTINE TO READ A FILE FROM EXTERNAL MEDIA ONTO THE NODE TABLE
6076      ;
6077
6078
6079 111160 ACTUSF:
6080 111160      P$PUSH R2        ; SAVE R2
6081 111162 005002      CLR   R2          ; INITIALIZE R2 TO NODE TYPE 'TARGET'
6082 111164      OPEN  CBOADR    ; OPEN FILE, NAME=ASCIZ STRING
        MOV   CBOADR,R0
        TRAP  C$OPEN
        111164 013700 002366
        111170 104434
6083 111172      BCOMPLETE 1$      ; RETURN IF SUCCESSFUL
        111172 103413
6084 111174      PRINTF #OPNERR,CBOADR ; ELSE PRINT "OPEN ERROR"
        MOV   CBOADR,-(SP)
        MOV   #OPNERR,-(SP)
        MOV   #2,-(SP)
        MOV   SP,R0
        TRAP  C$PNTF
        111174 013746 002366
        111200 012746 112120
        111204 012746 000002
        111210 010600
        111212 104417

```

```

6085 111214 062706 000006
      111220
      111220 104435
6086 111222
6087 111230 005737 112114
6088 111234 001064
6089 111236 005737 112116
6090 111242 001411
6091 111244
      111244 012746 112233
      111250 012746 000001
      111254 010600
      111256 104417
      111260 062706 000004
6092 111264 000450
6093 111266
      111266 012746 111570
      111272 012746 112202
      111276 012746 000002
      111302 010600
      111304 104417
      111306 062706 000006
6094 111312
6095 111334
6096 111336 001411
6097 111340
      111340 012746 053306
      111344 012746 000001
      111350 010600
      111352 104417
      111354 062706 000004
6098 111360 000412
6099 111362 110237 002400
6100 111366 105102
6101 111370 142702 000376
6102 111374
6103 111402
6104 111404 000706
6105 111406
6106 111410 105037 003160
6107 111414
      111414 012746 054627
      111420 012746 054561
      111424 012746 000002
      111430 010600
      111432 104417
      111434 062706 000006
6108 111440
6109
6110
6111
6112
6113
6114
6115
6116
6117

      CLOSE
      ; CLOSE FILE
      ADD #6,SP
      TRAP C#CLOS
1$: CALL RDLIN ;READ A LINE AT A TIME
     TST BAD ;SEE IF AN ERROR DURING READ
     BNE 25$ ; BR ON ERROR TO LEAVE
     TST EOFF ;SEE IF EOF BEFORE PROCESS
     BEQ 10$ ;IF VALID, PROCESS
     PRINTF #EOFFND ; ELSE SAY 'END OF FILE' AND LEAVE
      MOV #EOFFND,-(SP)
      MOV #1,-(SP)
      MOV SP,RO
      TRAP C#PNTF
      ADD #4,SP
10$: BR 25$
     PRINTF #PLINE,#FILLIN ;PRINT LINE READ FROM FILE
      MOV #FILLIN,-(SP)
      MOV #PLINE,-(SP)
      MOV #2,-(SP)
      MOV SP,RO
      TRAP C#PNTF
      ADD #6,SP
     CALL EDPACK #FILLIN,#ADRFUF,#6 ;PUT ADDRESS INTO BINARY
     P$POP R1 ;CHECK RESULTS
     BEQ 12$ ; IF OK, BR
     PRINTF #CADERR ; ELSE PRINT ERROR MESSAGE
      MOV #CADERR,-(SP)
      MOV #1,-(SP)
      MOV SP,RO
      TRAP C#PNTF
      ADD #4,SP
12$: BR 25$
     MOV R2,NODTY ; AND EXIT
     COMB R2 ;SET UP NODE TYPE
     BICB #376,R2 ;SWITCH TYPE FOR NEXT TIME
     CALL ENTRND ;ENTER IN NODE TABLE
     P$POP R1 ;GET RESULTS
     BR 1$ ;READ MORE ADDRESS
25$: P$POP R2 ;RESTORE R2
     CLRB #NNUF ;CLEAR 'NOT ENOUGH' FLAG
     PRINTF #UNSMMSG,#RESTOR ;PRINT 'TALBE RESTORED' MESSAGE
      MOV #RESTOR,-(SP)
      MOV #UNSMMSG,-(SP)
      MOV #2,-(SP)
      MOV SP,RO
      TRAP C#PNTF
      ADD #6,SP
RETURN

.SBTTL READ LINE OF OPENED FILE
;
; THIS ROUTINE GETS BYTES FROM AN OPENED FILE UNTIL A CR IS ENCOUNTERED
; "EOF" AND "BAD" FLAGS ARE SET IF END-OF-FILE OR ERRORS ARE ENCOUNTERED
;
; NOTE: ASSUMING A ASCII TEXT FILE IS BEING READ, FOR EXAMPLE:

```



```

6118      ;      AA-00-03-00-01-AB<CR><LF>
6119      ;      "
6120      ;      AA-00-03-00-01-AB<CR><LF>
6121      ;
6122      ;      WHAT YOU SEE READ BYTE-BY-BYTE IS:
6123      ;      "A..-AB<CR><LF>A..-AB<CR><LF>...<0><0><0>.....???"
6124      ;      SO I MADE ASSUMPTION THAT SINCE SEE "O-PADDING" AFTER LAST CHAR TO
6125      ;      END-OF-FILEBLOCK, ANY CHARACTER THAT IS NOT "SPACE OR GREATER" OR A
6126      ;      <CR> OR <LF> THEN I'LL TAKE THAT AS END-OF-FILE(TEXT), SET EOF-FLAG
6127      ;      AND LEAVE.
6128      ;
6129      ;      INPUTS:
6130      ;      FILLIN  BUFFER TO HOLD LINE OF BYTES READ FROM OPENED FILE
6131      ;      (CR NOT INCLUDED, 0-BYTE TERMINATED)
6132      ;
6133      ;      OUTPUTS:
6134      ;      BAD      IF NON-ZERO, ERROR IN READING A BYTE FROM FILE
6135      ;      EOFF     IF NON-ZERO, END OF FILE WAS ENCOUNTERED
6136      ;      FILLIN  ASCIZ STRING THAT WAS READ AS CHAR-CR-LF STRING
6137      ;      (CR-LF REMOVED)
6138 111442 012702 111570      RDLIN:  MOV      #FILLIN,R2      ;POINT R2 TO A LINE BUFFER
6139 111446 005037 112114      CLR      BAD              ;CLEAR FLAGS
6140 111452 005037 112116      CLR      EOFF
6141 111456      1$:      GETBYT  (R2)          ;GO GET A BYTE FROM INPUT FILE
6142      111456 104426      TRAP    C$GETB
6143      111460 110012      MOV     RO,(R2)
6144 111462      BCOMPLETE 2$      ;BR IF READ-BYTE SUCESSFUL
6145 111462 103414      BCS    2$
6146 111464 4$:      PRINTF  #RDERR        ; ELSE PRINT "READ-ERROR"
6147      111464 012746 112154      MOV     #RDERR,-(SP)
6148      111470 012746 000001      MOV     #1,-(SP)
6149      111474 010600      MOV     SP,RO
6150      111476 104417      TRAP   C$PNTF
6151      111500 062706 000004      ADD    #4,SP
6152 111504 012737 177777 112114      MOV     #-1,BAD
6153 111512 000416      BR      5$              ; SET BAD-TRY FLAG AND LEAVE
6154 111514 122712 000015      2$:      CMPB    #15,(R2)
6155 111520 001756      BEQ    1$
6156 111522 122712 000012      CMPB    #12,(R2)
6157 111526 001410      BEQ    5$
6158 111530 122712 000040      CMPB    #40,(R2)
6159      BHI    6$
6160      INC    R2
6161      BR    1$
6162 111534 101002      ; IS THE CHARACTER A <CR>
6163 111536 005202      ; BR IF YES (GO BACK TO GET <LF>)
6164 111540 000746      ; IS THE CHARACTER A <LF>
6165      ; BR IF YES (TERMINATE AND LEAVE)
6166 111542 012737 177777 112116 6$:      MOV     #-1,EOFF
6167      ; IS IT A "EOF" (END-OF-FILE(TEXT))
6168      ; (EOF=ANY NON-CHAR>37 EXCEPT CR,LF)
6169      ; BR IF YES
6170      ; IF NO, LEAVE CHAR IN BUFFER
6171      ; AND GO GET MORE CHARS
6172 111550 105012      5$:      CLRB   (R2)
6173      RETURN
6174 111554      FILENM: .BLKB 12.      ;BUFFER FOR FILE NAME
6175 111570      FILLIN: .BLKB 132.    ;BUFFER FOR SINGLE LINE READ FROM FILE
6176 111774      MATCH:  .BLKB 80.    ;BUFFER FOR WORD TO MATCH FROM FILE
6177 112114 000000      BAD:    .WORD 0       ;ERROR/NOT-FOUND FLAG WORD
6178 112116 000000      EOFF:   .WORD 0       ;END-OF-FILE FLAG (<>0 = EOF)

```

```

6167
6168 112120      045      116      045  OPNERR: .ASCIZ  /%N%?UNABLE TO OPEN "%T%A"?/
      112123      101      077      125
      112126      116      101      102
      112131      114      105      040
      112134      124      117      040
      112137      117      120      105
      112142      116      040      042
      112145      045      124      045
      112150      101      042      077
      112153      000
6169 112154      045      116      045  RDERR: .ASCIZ  /%N%?FILE READ ERROR?/
      112157      101      077      106
      112162      111      114      105
      112165      040      122      105
      112170      101      104      040
      112173      105      122      122
      112176      117      122      077
      112201      000
6170 112202      045      116      045  PLINE: .ASCIZ  /%N%?FILE LINE WAS:%N%T%N/
      112205      101      106      111
      112210      114      105      040
      112213      114      111      116
      112216      105      040      127
      112221      101      123      072
      112224      045      116      045
      112227      124      045      116
      112232      000
6171 112233      045      116      045  EOFFND: .ASCIZ  /%N%?AEND-OF-FILE FOUND, FILE READ/
      112236      101      105      116
      112241      104      055      117
      112244      106      055      106
      112247      111      114      105
      112252      040      106      117
      112255      125      116      104
      112260      054      040      106
      112263      111      114      105
      112266      040      122      105
      112271      101      104      000

```

```

6172
6173
6174
6175
6176
6177
6178
6179
6180
6181
6182
6183
6184
6185
6186
6187
6188
6189

```

```

:---*
:
: SELMSG                                OPERATOR SELECTED MESSAGE STORAGE
:
: THIS ROUTINE WILL TAKE THE OPERATOR SELECTED MESSAGE FROM THE COMMAND
: LINE INPUT STRING BUFFER AND PUT IT INTO A BUFFER AT LOCATION OPSLBF.
:
: INPUTS -                               P1 - ADDRESS OF OPERATOR SELECTED MESSAGE IN
:                                       INPUT STRING
:
: EXPLICIT OUTPUTS -                     NONE
: IMPLICIT OUTPUTS -                     THE BUFFER AT OPSLBF WILL CONTAIN THE ASCII
:                                       OPERATOR SELECTED INPUT STRING FOLLOWED BY
:                                       A NULL CHARACTER
:
: SUBORDINATE ROUTINES -                 NONE
: CALLING PROCEEDURE -                   CALL SELMSG P1 ;INPUT ADDRESS OF ASCII STRING
: REGISTER USAGE -                       R1 CONTAINS ADDRESS OF INPUT STRING
:                                       R2 CONTAINS ADDRESS OF OUTPUT STRING
:
:

```

```

6190 ;--*
6191
6192 112274 SELMSG: P$POP R1 ;PUT ADDRESS OF OPR. SEL ASCII STRING INTO R1
6193 112276 012702 003570 MOV #OPSLBF,R2 ;PUT ADDRESS OF OUTPUT BUFFER INTO R2
6194 112302 005003 CLR R3 ;CLEAR CHARACTER COUNTER
6195 112304 105711 5$: TSTB (R1) ;CHECK FOR END OF STRING
6196 112306 001404 BEQ 10$ ;GO TO 10$ IF END
6197 112310 112122 MOVB (R1)+,(R2)+ ;ELSE, MOVE BYTE TO OUTPUT BUFFER
6198 112312 005203 INC R3 ;COUNT NUMBER OF CHARACTERS IN INPUT BUFFER
6199 112314 000137 112304 JMP 5$ ;GO DO MORE CHARACTERS
6200 112320 112712 000000 10$: MOVB #0,(R2) ;PUT ZERO AT END OF OUTPUT BUFFER
6201 112324 010337 003314 MOV R3,MSG6C ;STORE NUMBER OF CHARACTERS FOR USE IN BUF. BUILDING
6202 112330 RETURN
6203
6204 ;--*
6205 ; ENTRND ENTER NODE IN TABLE
6206 ;
6207 ; THIS ROUTINE ENTERS A NODE INTO THE NODE TABLE
6208 ;
6209 ; INPUTS NONE
6210 ; EXPLICIT OUTPUTS P1 - ZERO IF SUCCESSFUL, -1 IF TABLE FULL
6211 ; IMPLICIT OUTPUTS THE ADDRESS CONTAINED IN ADRBUF WILL BE
6212 ; ADDED TO THE NODE TABLE IN THE FIRST
6213 ; AVAILABLE SLOT WITH THE NODE TYPE CONTAINED
6214 ; IN NODTY (TARGET OR ASSIST)
6215 ; SUBORDINATE ROUTINES FINDSL - FIND EMPTY SLOT IN TABLE
6216 ; CALLING PROCEDURE CALL ENTRND
6217 ; P$POP P1 ;OUTPUT GOOD/BAD RESULT
6218 ;
6219 ;--*
6220
6221 112332 ENTRND: CALL FINDSL ;FIND AVAILABLE SLOT IN TABLE
6222 112340 P$POP R1 ;CHECK IF TABLE FULL
6223 112342 001403 BEQ 5$ ;IF NOT FULL BR TO 5$
6224 112344 P$PUSH #-1 ;ELSE PUT FULL INDICATION ON STACK
6225 112350 000416 BR 20$ ;RETURN
6226 112352 012703 000006 5$: MOV #6,R3 ;SET INCR. COUNTER TO 6 (BYTES)
6227 112356 013701 002402 MOV SLOT,R1 ;MOV ADDRESS OF AVAILABLE SLOT TO R1
6228 112362 012702 002314 MOV #ADRBUF,R2 ;MOV ADDRESS OF NODE ADDRESS TO R2
6229 112366 112221 10$: MOVB (R2)+,(R1)+ ;MOV BYTE OF ADDRESS
6230 112370 005303 DEC R3 ;DECR. COUNTER
6231 112372 001375 BNE 10$ ;CONTINUE UNTIL 6 BYTES TRANSFERED
6232 112374 005201 INC R1 ;SET POINTER TO NODE TYPE LOCATION
6233 112376 113711 002400 MOVB NODTY,(R1) ;MOVE NODE TYPE INTO TABLE
6234 112402 P$PUSH #0 ;PUT ADDRESS ADDED INDICATION ON STACK
6235 112406 20$: RETURN ;RETURN
6236
6237 ;--*
6238 ; FINDSL FIND EMPTY SLOT IN NODE TABLE
6239 ;
6240 ; INPUTS NONE
6241 ; EXPLICIT OUTPUTS NONE
6242 ; IMPLICIT OUTPUTS THE ADDRESS OF THE FIRST AVAILABLE SLOT IN THE
6243 ; NODE TABLE WILL BE LOCATED IN SLOT. THE
6244 ; PARAMETER STACK WILL CONTAIN -1 IF THE NODE
6245 ; TABLE IS FULL AND 0 IF AN EMPTY SLOT WAS FOUND
6246 ; SUBORDINATE ROUTINES NONE

```



```

6298      ;      THIS ROUTINE COMPAIRS TWO SIX BYTE STRINGS
6299      ;
6300      ;      INPUTS      P1 - ADDRESS OF FIRST STRING
6301      ;      P2 - ADDRESS OF SECOND STRING
6302      ;      OUTPUTS    P3 - 0 = COMPARISON/-1 = NO COMPARISON
6303      ;
6304      ;      CALLING PROCEDURE  CALL  CMPADR P1,P2
6305      ;      P$POP      P3
6306      ;
6307      ;---+
6308
6309 112546  CMPADR: P$POP  R2,R3      ;PUT ADDRESS OF STRING TO BE COMPARED IN R2 AND R3
6310 112552 022223  CMP      (R2)+,(R3)+    ;DO FIRST TWO BYTES COMPARE
6311 112554 001006  BNE      10$           ; IF NO, EXIT
6312 112556 022223  CMP      (R2)+,(R3)+    ;DO SECOND TWO BYTES COMPARE
6313 112560 001004  BNE      10$           ; IF NO, EXIT
6314 112562 021213  CMP      (R2),(R3)     ;DO LAST TWO BYTES COMPARE
6315 112564 001002  BNE      10$           ; IF NO, EXIT
6316 112566 005001  CLR      R1            ;PUT COMPARISON OK INDICATOR IN R1
6317 112570 000402  BR       15$           ;
6318 112572 012701 177777 10$:  MOV     #-1,R1     ;PUT NO COMPARISON INDICATOR IN R1
6319 112576      15$:  RETURN  R1
6320
6321      ;---+
6322      ;      PRTNOD      PRINT NODE TABLE
6323      ;
6324      ;      INPUTS      NONE
6325      ;      EXPLICIT OUTPUTS  NONE
6326      ;      IMPLICIT OUTPUTS  ONE ENTRY IN THE NODE TABLE WILL BE PRINTED
6327      ;      SUBORDINATE ROUTINES  NONE
6328      ;      CALLING SEQUENCE  CALL PRTNOD
6329      ;
6330 112602  PRTNOD: PRINTF  #NODADR,#STRBUF      ;PRINT NODE ADDRESS
6331 112602 012746 002322      MOV     #STRBUF,-(SP)
6332 112606 012746 053430      MOV     #NODADR,-(SP)
6333 112612 012746 000002      MOV     #2,-(SP)
6334 112616 010600      MOV     SP,R0
6335 112620 104417      TRAP   C$PNTF
6336 112622 062706 000006      ADD     #6,SP
6337 112626 013702 002402      MOV     SLOT,R2      ;MOVE SLOT ADDRESS INTO R2
6338 112632 162702 002404      SUB     #NODTAB,R2   ;CALCULATE NODE LOGICAL NAME
6339 112636 006202      ASR     R2           ;USING: LOG. NO. =
6340 112640 006202      ASR     R2           ;(SLOT-#NODTAB)/8
6341 112642 006202      ASR     R2
6342 112644      PRINTF  #LOGNAM,R2      ;PRINT LOGICAL NAME
6343 112644 010246      MOV     R2,-(SP)
6344 112646 012746 053440      MOV     #LOGNAM,-(SP)
6345 112652 012746 000002      MOV     #2,-(SP)
6346 112656 010600      MOV     SP,R0
6347 112660 104417      TRAP   C$PNTF
6348 112662 062706 000006      ADD     #6,SP
6349 112666 013702 002402      MOV     SLOT,R2      ;SEE IF TARGET OR ASSIST NODE
6350 112672 062702 000007      ADD     #7,R2        ; INFO CONTAINED IN 7TH BYTE OF ENTRY
6351 112676 111203      MOV     (R2),R3      ;MOVE INTO R3
6352 112700 020327 000001      CMP     R3,#CASIST   ;SEE IF ASSIST NODE
6353 112704 001404      BEQ     10$         ; IF YES, BR 10$
6354 112706 012737 062613 002312      MOV     #ARGTY7,KEYWD2 ; ELSE MOVE 'TARGET' INTO KEYWD2

```

```

6343 112714 000403          BR      20$          ; CONTINUE
6344 112716 012737 062603 002312 10$:  MOV     #ARGTY6,KEYWD2 ; MOVE 'ASSIST' INTO KEYWD2
6345 112724          20$:  PRINTF  #NODTYP,KEYWD2 ; PRINT NODE TYPE
      112724 013746 002312          MOV     KEYWD2,-(SP)
      112730 012746 053453          MOV     #NODTYP,-(SP)
      112734 012746 000002          MOV     #2,-(SP)
      112740 010600          MOV     SP,R0
      112742 104417          TRAP   C$PNTF
      112744 062706 000006          ADD     #6,SP
6346 112750          RETURN          ;RETURN
6347 112752          EXIT   TST
      112752 104432          TRAP   C$EXIT
      112754 000002          .WORD  L10015-.
6348
6350          ;*****
6351          ;   INSERT LOCAL STORAGE THAT IS USED ONLY
6352          ;   DURING THIS TEST.
6353          ;*****
6354
6355          ;*****
6356          ;   INSERT MESSAGES THAT ARE USED ONLY
6357          ;   DURING THIS TEST.
6358          ;*****
6360
6361          .EVEN
6362
6363 112756          ENDTST
      112756          L10015:
      112756 104401          TRAP   C$ETST
6364
6366          ;*****
6367          ;   BEGIN THE REMAINING TESTS ON NEW PAGES.
6368          ;*****

```


6371
6372
6373
6374
6375
6376
6377
6378
6379
6380
6381
6382
6383

112760
112760 000015
112762

.SBTTL HARDWARE PARAMETER CODING SECTION

;;
; THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
; WITH THE OPERATOR.
;--

BGNHRD

.WORD L10016-L\$HARD/2
L\$HARD:;

6384
6386
6387
6388
6389
6390
6391
6392
6394

; INSERT HARDWARE PARAMETER INTERPRETIVE CODE HERE. THIS CODE
; IS USED BY THE SUPERVISOR TO INTERROGATE THE OPERATOR FOR
; DEVICE INFORMATION TO PUT IN THE P-TABLE. THIS CODE IS USED
; IN CONJUNCTION WITH THE DEFAULT P-TABLE TEMPLATE. THE MACROS
; USED IN THIS SECTION ARE "GPRMD", "GPRMA" AND "GPRML".

6395 112762
112762 000031
112764 113014
112766 160000
112770 177776
6396 112772
112772 001031
112774 113047
112776 000000
113000 000776
6397 113002
113002 002032
113004 113103
113006 000340
113010 000000
113012 000007

GPRMA ASKCSR,0,0,160000,177776,YES ; GET CSR ADDRESS
.WORD T\$CODE
.WORD ASKCSR
.WORD T\$LLOLM
.WORD T\$HILIM
GPRMA ASKVEC,2,0,0,776,YES ; GET VECTOR ADDRESS
.WORD T\$CODE
.WORD ASKVEC
.WORD T\$LLOLM
.WORD T\$HILIM
GPRMD ASKPRI,4,0,340,0,7,YES ; GET PRIORITY LEVEL
.WORD T\$CODE
.WORD ASKPRI
.WORD 340
.WORD T\$LLOLM
.WORD T\$HILIM

6398
6399 113014
113014

ENDHRD

.EVEN
L10016:

6400
6402
6403
6404
6405
6407

; INSERT MESSAGES THAT ARE USED ONLY
; DURING THE HARDWARE PARAMETER CODING SECTION.

6408 113014 127 110 101
113017 124 040 111
113022 123 040 124
113025 110 105 040
113030 120 103 123
113033 122 117 040
113036 101 104 104

ASKCSR: .ASCIZ /WHAT IS THE PCSRO ADDRESS?/

	113041	122	105	123	
	113044	123	077	000	
6409	113047	127	110	101	ASKVEC: .ASCIZ /WHAT IS THE VECTOR ADDRESS?/
	113052	124	040	111	
	113055	123	040	124	
	113060	110	105	040	
	113063	126	105	103	
	113066	124	117	122	
	113071	040	101	104	
	113074	104	122	105	
	113077	123	123	077	
	113102	000			
6410	113103	127	110	101	ASKPRI: .ASCIZ /WHAT IS THE PRIORITY LEVEL?/
	113106	124	040	111	
	113111	123	040	124	
	113114	110	105	040	
	113117	120	122	111	
	113122	117	122	111	
	113125	124	131	040	
	113130	114	105	126	
	113133	105	114	077	
	113136	000			
6411					.EVEN
6412					

```

6414 .SBTTL SOFTWARE PARAMETER CODING SECTION
6415
6416 ;**
6417 ; THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
6418 ; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
6419 ; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
6420 ; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
6421 ; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
6422 ; WITH THE OPERATOR.
6423 ;--
6424
6425 113140 BGNSFT
113140 000000 .WORD L10017-L$SOFT/2
113142 L$SOFT::

6426 ;*****
6428 ; INSERT SOFTWARE PARAMETER INTERPRETIVE CODING HERE. THIS CODE
6429 ; IS USED BY THE SUPERVISOR TO INTERROGATE THE OPERATOR FOR
6430 ; SOFTWARE INFORMATION WHICH WILL BE PLACED IN THE SOFTWARE
6431 ; TABLE. THIS SECTION IS OPTIONAL.
6432 ;*****
6433
6435 .EVEN
6436
6437 ENDSFT
6438 113142
113142 .EVEN
L10017:

6439 ;*****
6440 ; INSERT MESSAGES THAT ARE USED ONLY
6441 ; DURING THE SOFTWARE PARAMETER CODING SECTION.
6442 ;*****
6443
6444 $PATCH::
6445 .BLKW 10
6446
6447 ;*****
6448 ; THIS IS A PATCH AREA THAT SHOULD BE INCLUDED IN ALL DIAGNOSTICS.
6449 ; ADJUST THE SIZE TO FIT YOUR OWN PREFERENCES.
6450 ;*****
6451
6452 LASTAD
6453
6454 .EVEN
6455 .WORD 0
6456 .WORD 0
6457
6458 113162
113162 000000
113164 000000
113166 L$LAST::

```


6460
6461
6463
6464
6465
6466
6467
6468
6469
6470
6471
6472
6474
6475
6476
6477
6478
6479
6480
6481

000001

```

;*****
;   HARDCODED P-TABLES MAY BE PLACED HERE BY USING THE SETUP MACROS.
;   THIS SECTION IS OPTIONAL AND SHOULD BE REMOVED IF IT IS NOT BEING
;   USED.  CHANGE THE POINTER MACRO ARGUMENT TO REFLECT THE REMOVAL.
;
;   THE P-TABLES ARE DELIMITED BY THE "BGNSETUP" AND "ENDSETUP" MACROS.
;   THE "BGNSETUP" MACRO HAS ONE ARGUMENT WHICH IS THE NUMBER OF
;   P-TABLE ENTRIES.  EACH ENTRY IS DELIMITED BY THE "BGNPTAB" AND
;   "ENDPTAB" MACROS.  NEITHER OF THESE MACROS REQUIRE AN ARGUMENT.
;*****
;   BGNSETUP      1
;   BGNPTAB
;   .WORD      0
;   ENDPTAB
;   ENDSETUP
;
000001 .END

```

ACTALP	103450	BAD	112114	CEXIT =	000020 G	CNTR06	063260	C#ESEG=	000005
ACTBLD	101166	BCOUNT	050526 G	CFLAG	003672	CNTR07	063317	C#ESUB=	000003
ACTCMS	107206	BINDEC	075014 G	CFUNCT=	000040	CNTR08	063367	C#ETST=	000001
ACTCNL	110550	BINMEX	072672	CLIACT	100456	CNTR09	063442	C#EXIT=	000032
ACTCNT	107312	BIT0 =	000001 G	CLIALN=	000007	CNTR10	063513	C#GETB=	000026
ACTCPY	103742	BIT00 =	000001 G	CLIALP=	000006	CNTR11	063552	C#GETW=	000027
ACTCSU	111036	BIT01 =	000002 G	CLIBIF=	000003	CNTR12	063622	C#GMAN=	000043
ACTCTT	103520	BIT02 =	000004 G	CLIBR =	000002	CNTR13	063670	C#GPHR=	000042
ACTDFT	111112	BIT03 =	000010 G	CLIBRX	052554	CNTR14	063735	C#GPLO=	000030
ACTDIR	104776	BIT04 =	000020 G	CLIDEC=	000011	CNTR15	063771	C#GPRI=	000040
ACTEXT	103350	BIT05 =	000040 G	CLIERM	052445	CNTR16	064033	C#INIT=	000011
ACTFCT	110634	BIT06 =	000100 G	CLIERR=	000000	CNTR17	064101	C#INLP=	000020
ACTHLP	100620	BIT07 =	000200 G	CLIEXI=	000001	CNTR18	064154	C#MANI=	000050
ACTIDT	102264	BIT08 =	000400 G	CLINBG	052527	CNTR19	064221	C#MEM =	000031
ACTMSG	103242	BIT09 =	001000 G	CLINUF	052476	COMAND	071350 G	C#MSG =	000023
ACTNAD	104020	BIT1 =	000002 G	CLINUM=	000005	COMPAR	062351	C#OPEN=	000034
ACTNAL	104156	BIT10 =	002000 G	CLIOCT=	000010	CONES =	000017	C#PNTB=	000014
ACTNOD	100656	BIT11 =	004000 G	CLISFA=	000004	COPRSL =	000024	C#PNTF=	000017
ACTNUF	100610	BIT12 =	010000 G	CLISTR=	000012	COUNT	050542 G	C#PNTS=	000016
ACTNUL	100616	BIT13 =	020000 G	CLITRE	051070	CPATRN=	000005	C#PNTX=	000015
ACTONE	103460	BIT14 =	040000 G	CLI#PM	052436	CPYCNT	050562 G	C#QIO =	000377
ACTOPR	103530	BIT15 =	100000 G	CLKBR	003676	CPYLMT	053775	C#RDBU=	000007
ACTPAT	107032	BIT2 =	000004 G	CLKCSR	003674	CRC =	004000 G	C#REFG=	000047
ACTRNA	104356	BIT3 =	000010 G	CLKEN	003704	CRNALL=	000032	C#RESE=	000033
ACTRNL	105424	BIT4 =	000020 G	CLKHZ	003702	CRUN =	000004	C#REVI=	000003
ACTRUN	104236	BIT5 =	000040 G	CLKINT	067702 G	CSAVE =	000006	C#RFLA=	000021
ACTSAV	110670	BIT6 =	000100 G	CLKSET	067656	CSAVR4=	000014	C#RPT =	000025
ACTSMS	107114	BIT7 =	000200 G	CLKVEC	003700	CSHCTR=	000002 G	C#SEFG=	000046
ACTSND	110374	BIT8 =	000400 G	CLRCNT=	000013 G	CSHMSG=	000034	C#SPRI=	000041
ACTSR4	103442	BIT9 =	001000 G	CLRMST	053716	CSIZE =	000026	C#SVEC=	000037
ACTSUM	101710	BLDAST	073606 G	CLRSTA=	000017 G	CTARGT=	000000 G	C#TPRI=	000013
ACTSZE	103664	BLDBUF	074324 G	CLUPPR=	000033	CTYPE =	000025	C#COLL=	000074 G
ACTTYP	103656	BLDFAS	073242 G	CMDBUF	002200	CUNSAV=	000041	C#MREC=	000010 G
ACTUNS	110734	BLDLD	072760 G	CMDTY1	062444	CUNSVF=	000045	C#MXMT=	000040 G
ACTUSF	111160	BLDMSG	052757	CMDTY2	062451	CZEROS=	000020	C#PREC=	000004 G
ACTXAD	103360	BLDREQ	074124 G	CMDTY3	062461	C#AU =	000052	C#PXM0=	000054 G
ACTZRO	103470	BOE =	000400 G	CMDTY4	062467	C#AUTO=	000061	C#PXM1=	000034 G
ACTOAL	103510	BOOT =	000005 G	CMDTY5	062474	C#BRK =	000022	C#PXM2=	000050 G
ACTIAL	103500	BUFL =	100000 G	CMDTY6	062500	C#BSEG=	000004	C#PXM3=	000044 G
ADR =	000020 G	BUFLEN	050566 G	CMDTY7	062510	C#BSUB=	000002	C#RDAT=	000020 G
ADRBUF	002314	BUILD =	000003	CMDTY8	062515	C#CEFG=	000045	C#RERB=	000014 G
ADRDEL	054340	CADERR	053306	CMDTY9	062523	C#CLCK=	000062	C#RERR=	000016 G
ALLNOD	062151	CADRER	053232	CMPADR	112546	C#CLEA=	000012	C#RLEX=	000032 G
ALPHA =	000000 G	CALPHA=	000016	CMPBUF	050570 G	C#CLOS=	000035	C#RLIN=	000030 G
ANCHOR	070042	CASIST=	000001 G	CMPER1	066754	C#CLP1=	000006	C#RMDB=	000024 G
ARGTY1	062536	CBOADR	002366	CMPER2	067051	C#CVEC =	000036	C#SECS=	000002 G
ARGTY2	062544	CCCITT=	000023	CMPSTR	072530	C#DCLN=	000044	C#XABB=	000066 G
ARGTY3	062555	CCITT =	000005 G	CNDADR=	000030	C#DODU=	000051	C#XABT=	000070 G
ARGTY4	062566	CCLMSG=	000035	CNDLOG=	000037	C#DRPT=	000024	C#XDAT=	000060 G
ARGTY5	062577	CCLNAD=	000004 G	CNODE =	000031	C#DU =	000053	C#XMDB=	000064 G
ARGTY6	062603	CCLNAL=	000010 G	CNODE =	000015	C#EDIT=	000003	COALT =	000022
ARGTY7	062613	CCLSUM=	000042	CNTR00	062703	C#ERDF=	000055	C1ALT =	000021
ASKCSR	113014	CCNTR =	000036	CNTR01	062763	C#ERHR=	000056	DATCMP	074406 G
ASKPRI	113103	CCPYS =	000027	CNTR02	063032	C#ERRO=	000060	DECSTR	075200 G
ASKVEC	113047	CDEFLT=	000044	CNTR03	063066	C#ERSF=	000054	DEF =	002000 G
ASSEMB=	000010	CDIR =	000043	CNTR04	063133	C#ERSO=	000057	DEPADR	047752 G
B =	000007	CEXADR=	000013	CNTR05	063210	C#ESCA=	000010	DESTIN=	000000 G

DFPTBL	002170	G	ERRFLG	050530	G	GETCL	100274	HELP29	061346	LDADR1=	000022	G	
DIAGMC=	000000		ERRMSG	052432	G	GETCOM	074304	HELP3	056254	LDADR2=	000032	G	
DIRCOM	105026		ERRNBR	052430	G	GETFNT=	000002	G	HELP30	061416	LDFCT1=	000020	G
DIRECT	062173		ERROR	070150	G	GETPCB=	000001	G	HELP4	056325	LDFCT2=	000030	G
DMPMEM=	000020	G	ERRS =	040000	G	GETRNX	074262	G	HELP5	056376	LDMEM =	000021	G
DNI =	004000	G	ERRTYP	052426	G	GETXNX	074274	G	HELP6	056476	LDRESP	052574	
DNIFLG	050522	G	ERR1	067460	G	G#CNT0=	000200		HELP7	056611	LDSKIP=	000016	G
EDPACK	072322		ERR2	067516	G	G#DELM=	000372		HELP8	056722	LENGTH	062342	
EF.CON=	000036	G	ERR3	067604	G	G#DISP=	000003		HELP9	057012	LGERMS	067117	
EF.NEW=	000035	G	EVL =	000004	G	G#EXCP=	000400		HEXBIN	072552	LOC DST	072206	
EF.PWR=	000034	G	EXIT =	000011		G#HILI=	000002		HEXC	072650	LOE =	040000	G
EF.RES=	000037	G	E#END =	002100		G#LOLI=	000001		HLPEND	003260	LOGDEL	054426	
EF.STA=	000040	G	E#LOAD=	000035		G#NO =	000000		HLPTAB	003164	LOGNAM	053440	
EMSG0	003464	G	FAADR1=	000022	G	G#OFFS=	000400		HN	072526	LOPDIR	050720	G
EMSG01	064272		FAADR2=	000032	G	G#OFSI=	000376		HOE =	100000	LOT =	000010	G
EMSG02	064321		FAADR3=	000042	G	G#PRMA=	000001		HXFORM	072414	LST	072670	
EMSG03	064341		FAADR4=	000052	G	G#PRMD=	000002		HXN	072412	LUPAIR	062162	
EMSG04	064373		FAFCT1=	000020	G	G#PRML=	000000		IBE =	010000	L#ACP	002110	G
EMSG05	064415		FAFCT2=	000030	G	G#RADA=	000140		ICAB =	040000	L#APT	002036	G
EMSG06	064450		FAFCT3=	000040	G	G#RADB=	000000		IDENT =	000010	L#AU	100266	G
EMSG07	064510		FAFCT4=	000050	G	G#RADD=	000040		IDU =	000040	L#AUT	002070	G
EMSG08	064553		FASIST	051026	G	G#RADL=	000120		IER =	020000	L#AUTO	100140	G
EMSG09	064613		FASKIP=	000016	G	G#RADO=	000020		ILADMS	053051	L#CCP	002106	G
EMSG1	003465	G	FATFLG	050512	G	G#XFER=	000004		ILADM1	053135	L#CLEA	100142	G
EMSG10	064656		FATI =	000400	G	G#YES =	000010		ILLADR	002650	L#CO	002032	G
EMSG11	064716		FILENM	111554		HDMSG1	055342		INICLN	100130	L#DEPO	002011	G
EMSG14	064755		FILLIN	111570		HDMSG2	055413		INIEXI	100132	L#DESC	002130	G
EMSG15	065031		FINDSL	112410		HDMSG3	055466		INIT	076600	L#DESP	002076	G
EMSG16	065064		FRAM =	020000	G	HDMSG4	055522		INIT1	076620	L#DEVP	002060	G
EMSG18	065127		FRDADR=	000004	G	HDMSG5	055577		INTE =	000100	L#DISP	002164	G
EMSG19	065176		FREMEM	047662	G	HDMSG6	055650		INTR =	000200	L#DLY	002116	G
EMSG2	003466	G	FRESIZ	047660	G	HDMSG7	055710		ISR =	000100	L#DTP	002040	G
EMSG20	065234		FULAST	062207		HDMSG8	055751		IXE =	004000	L#DTYP	002034	G
EMSG22	065266		FULSLT	112500		HDMSG9	056014		I#AU =	000041	L#DU	100260	G
EMSG23	065321		FUNCT	071372	G	HEADER=	000016	G	I#AUTO=	000041	L#DUT	002072	G
EMSG24	065366		FUNTAB	047676	G	HELP =	000001		I#CLN =	000041	L#DVTY	002122	G
EMSG25	065442		F#AU =	000015		HELP1	056060		I#DU =	000041	L#EF	002052	G
EMSG3	003467	G	F#AUTO=	000020		HELP10	057101		I#HRD =	000041	L#ENVI	002044	G
EMSG30	065531		F#BGN =	000040		HELP11	057172		I#INIT=	000041	L#ERRT	052426	G
EMSG31	065576		F#CLEA=	000007		HELP12	057270		I#MOD =	000041	L#ETP	002102	G
EMSG32	065637		F#DU =	000016		HELP13	057375		I#MSG =	000041	L#EXP1	002046	G
EMSG33	065714		F#END =	000041		HELP14	057474		I#PROT=	000040	L#EXP4	002064	G
EMSG34	065732		F#HARD=	000004		HELP15	057573		I#PTAB=	000041	L#EXP5	002066	G
EMSG35	066002		F#HW =	000013		HELP16	057676		I#PWR =	000041	L#HARD	112762	G
EMSG36	066037		F#INIT=	000006		HELP17	057765		I#RPT =	000041	L#HIME	002120	G
EMSG37	066064		F#JMP =	000050		HELP18	060070		I#SEG =	000041	L#HPCP	002016	G
EMSG38	066130		F#MOD =	000000		HELP19	060140		I#SETU=	000041	L#HPTP	002022	G
EMSG4	003470	G	F#MSG =	000011		HELP2	056161		I#SFT =	000041	L#HW	002170	G
EMSG40	066174		F#PROT=	000021		HELP20	060243		I#SRV =	000041	L#ICP	002104	G
EMSG41	066263		F#PWR =	000017		HELP21	060321		I#SUB =	000041	L#INIT	076600	G
EMSG42	066353		F#RPT =	000012		HELP22	060404		I#TST =	000041	L#LADP	002026	G
EMSG5	003570	G	F#SEG =	000003		HELP23	060505		J#JMP =	000167	L#LAST	113166	G
ENP =	000400	G	F#SOFT=	000005		HELP24	060605		KEYWD1	002310	L#LOAD	002100	G
ENTRND	112332		F#SRV =	000010		HELP25	060735		KEYWD2	002312	L#LUN	002074	G
EOFF	112116		F#SUB =	000002		HELP26	061021		LCAR =	004000	L#MREV	002050	G
EOFFND	112233		F#SW =	000014		HELP27	061125		LCLKEN=	000100	L#NAME	002000	G
ERRBLK	052434	G	F#TEST=	000001		HELP28	061227		LCOL =	010000	L#PRIO	002042	G

SYMBOL TABLE	
L\$PROT	076572 G
L\$PRT	002112 G
L\$REPP	002062 G
L\$REV	002010 G
L\$RPT	076560 G
L\$SOFT	113142 G
L\$SPC	002056 G
L\$SPCP	002020 G
L\$SPTP	002024 G
L\$STA	002030 G
L\$SW	002200 G
L\$TEST	002114 G
L\$TIML	002014 G
L\$UNIT	002012 G
L10000	002176
L10001	002200
L10002	067514
L10003	067602
L10004	067654
L10005	070022
L10006	076570
L10010	100136
L10011	100140
L10012	100256
L10013	100264
L10014	100272
L10015	112756
L10016	113014
L10017	113142
MATCH	111774
MESPAT	062054
MESPA1	062125
MORE	010000 G
MSGAD	003316 G
MSGCNT	003300 G
MSGPRM	054641
MSGTAB	003262
MSGTY0	062372
MSGTY1	062400
MSGTY2	062405
MSGTY3	062413
MSGTY4	062420
MSGTY5	062425
MSGTY6	062433
MSGOC	003300
MSG00	003334 G
MSG01	003464 G
MSG02	003465 G
MSG03	003466 G
MSG04	003467 G
MSG05	003470 G
MSG1	054711
MSG1C	003302
MSG11	055024
MSG12	055137
MSG2	055177
MSG2C	003304
MSG3	055235
MSG3C	003306
MSG4	055276
MSG4C	003310
MSG5C	003312
MSG6C	003314
NCHN	= 020000 G
NEW	100112
NIHLT	= 000006 G
NIRCNT	050516 G
NIUNI	= 000007 G
NOCLK	062622
NOCMPR	054160
NOD	053701
NODADR	053430
NODE	= 000002
NODTBL	002404
NODTY	002400
NODTYP	053453
NOD0	051070
NOD1	051074
NOD10	051154
NOD100	051720
NOD101	051722
NOD102	051724
NOD103	051730
NOD104	051734
NOD105	051740
NOD106	051744
NOD107	051746
NOD11	051156
NOD110	051752
NOD111	051756
NOD112	051772
NOD113	051776
NOC114	052012
NOD115	052016
NOD116	052032
NOD117	052036
NOD12	051170
NOD120	052052
NOD121	052056
NOD122	052072
NOD123	052076
NOD124	052112
NOD125	052116
NOD126	052132
NOD127	052136
NOD13	051174
NOD130	052142
NOD131	052146
NOD132	052152
NOD133	052166
NOD134	052172
NOD135	052176
NOD136	052202
NOD137	052220
NOD14	051200
NOD140	052224
NOD141	052230
NOD142	052234
NOD143	052240
NOD144	052244
NOD145	052264
NOD146	052270
NOD147	052302
NOD15	051212
NOD150	052306
NOD151	052324
NOD152	052330
NOD153	052346
NOD154	052352
NOD155	052366
NOD156	052372
NOD157	052376
NOD16	051216
NOD160	052400
NOD161	052404
NOD162	052410
NOD163	052412
NOD164	052416
NOD165	052422
NOD166	052424
NOD17	051234
NOD2	051100
NOD20	051236
NOD21	051250
NOD22	051252
NOD23	051254
NOD24	051256
NOD25	051272
NOD26	051276
NOD27	051316
NOD3	051102
NOD30	051322
NOD31	051340
NOD32	051344
NOD33	051362
NOD34	051366
NOD35	051402
NOD36	051404
NOD37	051424
NOD4	051116
NOD40	051430
NOD41	051432
NOD42	051434
NOD43	051440
NOD44	051444
NOD45	051450
NOD46	051454
NOD47	051456
NOD5	051120
NOD50	051462
NOD51	051476
NOD52	051502
NOD53	051520
NOD54	051524
NOD55	051544
NOD56	051550
NOD57	051554
NOD6	051134
NOD60	051556
NOD61	051562
NOD62	051576
NOD63	051602
NOD64	051606
NOD65	051612
NOD66	051624
NOD67	051630
NOD7	051140
NOD70	051634
NOD71	051640
NOD72	051644
NOD73	051650
NOD74	051654
NOD75	051672
NOD76	051676
NOD77	051714
NORESP	062302
NOTNUF	= 000012
NO.NTR	= 000006 G
NTBHDR	053462
NULL	= 000000
NULSTR	053362
N10\$	051074
N100\$	051456
N101\$	051462
N102\$	051502
N104\$	051524
N106\$	051550
N110\$	051554
N12\$	051102
N120\$	051556
N121\$	051562
N122\$	051602
N123\$	051630
N124\$	051644
N126\$	051650
N130\$	051654
N132\$	051676
N134\$	051720
N135\$	051722
N14\$	051120
N140\$	051724
N141\$	051730
N142\$	051734
N143\$	051744
N16\$	051140
N160\$	051746
N161\$	051752
N162\$	052016
N163\$	052036
N164\$	052056
N165\$	052076
N166\$	052116
N167\$	052136
N168\$	052146
N170\$	052152
N175\$	052202
N178\$	052234
N18\$	051156
N180\$	052240
N181\$	052244
N182\$	052270
N183\$	052306
N184\$	052330
N185\$	052346
N186\$	052352
N190\$	052376
N20\$	051174
N200\$	052400
N201\$	052404
N210\$	052412
N212\$	052416
N215\$	052424
N22\$	051216
N23\$	051236
N24\$	051252
N25\$	051256
N26\$	051276
N28\$	051322
N29\$	051344
N30\$	051366
N31\$	051404
N32\$	051430
N80\$	051434
N81\$	051440
N82\$	051444
N90\$	051450
N95\$	051454
OFLO	= 010000 G
OK	061661
OKFU	062013
OKRE	061702
OKTR	061746
ONE	= 004000 G
ONEALT	= 000003 G
ONES	= 000001 G
OPNERR	112120
OPRSEL	= 000006 G
OPSLBF	003570
OWN	= 100000 G
O\$APTS	= 000000
O\$AU	= 000000
O\$BGNR	= 000001
O\$BGNS	= 000000
O\$DU	= 000000
O\$ERRT	= 000000

O\$GNSW= 000000	P\$PASS 002376	RXI = 020000 G	TASIST 050742 G	T\$TEMP= 000005
O\$POIN= 000001	P\$RADX 003156	SAVCOM 111012	TBLEN= 000050 G	T\$TEST= 000001
O\$SETU= 000000	P\$SIZE 002372	SAVED 054620	TEMP C50550 G	T\$TSTM= 177777
PART 075214 G	P\$TREE 003146	SAVTBL 002530	TEMP1 050552 G	T\$TSTS= 000001
PASABT 061526	P\$TRV 075216	SEMSG 112274	TEMP2 050554 G	T\$\$AU = 010014
PATCH 050572 G	P\$TRS 075226	SERI = 100000 G	TEMP3 050556 G	T\$\$AUT= 010011
PATTRN 062262	P\$TYPE 002370	SFPTBL 002200 G	TENPWR 075130	T\$\$CLE= 010012
PCBBO 047666 G	QUIT 111024	SIADDR= 000042 G	TIMERS 003720	T\$\$DU = 010013
PCBB2 047670 G	RASIST 050774 G	SIDEV = 000053 G	TIMER1 003714	T\$\$HAR= 010016
PCBB4 047672 G	RBFCNT 050524 G	SIECO = 000030 G	TIMER2 003716	T\$\$HW = 010000
PCBB6 047674 G	RCBI = 002000 G	SIFNCT= 000035 G	TIMMIN 003706	T\$\$INI= 010010
PCCALL 050564 G	RCVBUF 050540 G	SIMSG1 066440	TIMOUT 050532 G	T\$\$MSG= 010004
PCEFLG 050514 G	RDCVRR 050536 G	SIMSG2 066477	TIMSEC 003710	T\$\$PRO= 010007
PCEI = 040000 G	RDCNTS= 000012 G	SIMSG3 066532	TIMTCK 003712	T\$\$RPT= 010006
PCLKCT= 001600 G	RDDEFA= 000002 G	SIMSG4 066572	TMRF = 000012 G	T\$\$SOF= 010017
PCLKEN= 000111 G	RDERR 112154	SIMSG5 066613	TMRO = 000011 G	T\$\$SRV= 010005
PCMSG 066714 G	RDLIN 111442	SIMSG6 066641	TRAST 062223	T\$\$SW = 010001
PCSR0 047632 G	RDMODE= 000014 G	SIMSG7 066667	TRVACT 075344	T\$\$TES= 010015
PCSR0C 047642 G	RDMULA= 000006 G	SIRCPT= 000022 G	TRVADR 076330	T1 100274 G
PCSR1 047634 G	RDPHYA= 000004 G	SIUECO= 000031 G	TRVALN 076144	UAM = 000200 G
PCSR1C 047644 G	RDRNGS= 000010 G	SIVERS= 000027 G	TRVALP 076100	UBTO = 040000 G
PCSR2 047636 G	RDSTA = 000016 G	SIZLMT 054061	TRVBIF 075450	UCB10 050110 G
PCSR2C 047646 G	RDSYS = 000022 G	SLOT 002402 G	TRVBR 075440	UCB11 050134 G
PCSR3 047640 G	READY = 000002 G	SOURCC= 000006 G	TRVBRC 075364	UCB12 050160 G
PCSR3C 047650 G	RECAST 062243	SOURCE 072320	TRVDEC 075544	UCB13 050160 G
PCTO = 000200 G	RECERR 052631	START 076700	TRVERR 075402	UCB20 050340 G
PDMD = 000010 G	RECEVE 071776 G	STATBL 002656	TRVEXI 075422	UCB21 050340 G
PFNOP = 000000 G	REQID 050712 G	STATUS 050312 G	TRVNMA 075564	UCB22 050400
PHYADR 047762 G	RESET = 000000 G	STBLN= 000132 G	TRVNOB 075374	UCB23 050400
PLINE 112202	RESTOR 054627	STOP = 000017 G	TRVNUM 075556	UCB6 050010 G
PNOP = 000003 G	RESTRY 100046	STP = 001000 G	TRVOCT 075556	UCB7 050050 G
PNT = 001000 G	RETRY 062316	STRBUF 002322	TRVSPA 075472	UDBB 050466 G
PREG14 070024	RETRYS 050534 G	STRBU1 002344	TRVSTR 076232	UNACSR 047652 G
PRI = 002000 G	RMTC = 000010 G	STRT = 000004 G	TSTMS1 061551	UNAINI 070262 G
PRIMLD= 000001 G	RPKLEN= 002756 G	SUMM 053706	TSTMS2 061571	UNAI SR 071144 G
PRI00 = 000000 G	RRGCR 003760 G	SUMRY= 000007	TSTMS3 061611	UNAPRI 047656 G
PRI01 = 000040 G	RRGLST 003770 G	SUMMS1 067215	TSTMS4 061624	UNAVEC 047654 G
PRI02 = 000100 G	RRGNXT 003764 G	SUMMS2 067236	TXI = 010000 G	UNBOND 054252
PRI03 = 000140 G	RRGSRT 003754 G	SUMMS3 067322	T\$ARGC= 000002	UNIHLT= 000005 G
PRI04 = 000200 G	RRG001 026006 G	SUMMS4 067351	T\$CODE= 002032	UNIT 047664 G
PRI05 = 000240 G	RRG002 030764 G	SUMMS5 067434	T\$ERRN= 000036	UNMSG 054561
PRI06 = 000300 G	RRG003 033742 G	SUMMS6 067452	T\$EXCP= 000000	WAIT 070066 G
PRI07 = 000340 G	RRG004 036720 G	SVCGBL= 000000	T\$FLAG= 000040	WDMODE= 000015 G
PROTOT= 000014 G	RRG005 041676 G	SVCINS= 000001	T\$GMAN= 000000	WDMULA= 000007 G
PROT00 050544 G	RRG006 044654 G	SVCSUB= 000001	T\$HILI= 000007	WDPHYA= 000005 G
PROT02 050546 G	RRING 004066 G	SVCTAG= 000001	T\$LAST= 000001	WDRNGS= 000011 G
PRTNOD 112602	RRNGTB 003722 G	SVCTST= 000001	T\$LOLI= 000000	WDSYS = 000023 G
P\$ACT 003150	RSET = 000040 G	S\$LSYM= 010000	T\$LSYM= 010000	WRITES 074544
P\$AERR 003162	RSTT = 000015 G	S.BYTE 050506 G	T\$LTNO= 000001	XFER 050560 G
P\$BUFA 003144	RTRY = 002000 G	S.COMP 050504 G	T\$NEST= 177777	XFLAG 050520 G
P\$CNT 003152	RTRYER 052675	S.LEN 050502 G	T\$NSO = 000005	XMIT 071434 G
P\$CPYS 002374	RUN = 000003 G	S.NREC 050500 G	T\$PTNU= 000000	XPKLEN= 002756 G
P\$EXIT 075342	RUNALL 104366	S.REC 050476 G	T\$SAVL = 177777	XPWR = 100000 G
P\$GDBD 003161	RUNCOM 106526	S.XFER 050510 G	T\$SEGL = 177777	XRGCR 003756 G
P\$MERR 003163	RUNDIR 105006	TABCLR 054514	T\$SUBN= 000000	XRGLST 003766 G
P\$NNUF 003160	RUNLUP 105434	TABEMT 053632	T\$TAGL = 177777	XRGNT 003762 G
P\$NUM 003154	RUNPAT 107042	TABFUL 053560	T\$TAGN= 010020	XRGSRT 003752 G

XRG001	004162 G	XRNGTB	003736 G	ZROALT=	000004 G	\$RDCN	050150 G	\$RDSY	050360 G
XRG002	007140 G	X\$	= 000167	\$CLRC	050260 G	\$RDDE	047750 G	\$WDMC	050040 G
XRG003	012116 G	X\$ALWA=	000000	\$CLRS	050320 G	\$RDMC	050000 G	\$WDMO	050300 G
XRG004	015074 G	X\$FALS=	000040	\$DMEM	050330 G	\$RDMO	050270 G	\$WDPH	047770 G
XRG005	020052 G	X\$OFFS=	000400	\$LMEM	050350 G	\$RDPH	047760 G	\$WDRN	050124 G
XRG006	023030 G	X\$TRUE=	000020	\$PATCH	113142 G	\$RDRN	050100 G	\$WTSY	050370 G
XRING	003772 G	ZEROS =	000002 G	\$PNOP	047746 G				

. ABS. 113166 000
 000000 001

ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 31328 WORDS (123 PAGES)
 DYNAMIC MEMORY: 20060 WORDS (77 PAGES)
 ELAPSED TIME: 00:12:07
 CZUACB.BIN,CZUACB.LST/-SP=SVC34R.MLB,CZUACB.P11