

Micro Fiche Scan

Name of device(s) tested:

UDA50,KDA50,RA60/80/81/82

Test description:

UDA/KDA SUBSYS EXER

MAINDEC Number or Package Identifier (after SEP 1977):

CZUDJA0

Fiche Document Part Number:

AH-T937A-MC

Fiche preparation date unknown, using copyright year:

1985

Image resolution:

8-bit gray levels, max. quality for archiving

COPYRIGHT (C) 1985 by d|i|g|i|t|a|l

e w
A O;

IDENTIFICATION

PRODUCT CODE: AC-T936A-MC
PRODUCT NAME: CZUDJAO UDA/KDA SUBSYS EXER
PRODUCT DATE: 2-OCT-1985
MAINTAINER: RON BOWSER
AUTHOR: JOHN MERTZ

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1985 BY DIGITAL EQUIPMENT CORPORATION

1
2
3

.REM @

CONTENTS

1	GENERAL INFORMATION	4
1.1	PROGRAM ABSTRACT	4
1.2	SYSTEM REQUIREMENTS	5
2	PRODUCT GOALS	7
2.1	PERFORMANCE GOALS	7
2.2	FAILSOFT GOALS	7
2.3	RESTRICTIONS	7
2.4	NON-GOALS	8
3	PROGRAM DESCRIPTION	9
3.1	CONTROLLER VERIFICATION TEST (TEST 1)	10
3.2	SUBSYSTEM VERIFICATION TEST (TEST 2)	11
3.3	SUBSYSTEM EXERCISER (TEST 3)	12
4	OPERATING INSTRUCTIONS	14

4.1	COMMANDS	14
4.2	SWITCHES	14
4.3	FLAGS	16
4.4	EXTENDED P-TABLE DIALOGUE	16
4.5	TEST QUESTIONS	18
4.5.1	HARDWARE QUESTIONS	18
4.5.2	SOFTWARE QUESTIONS	19
4.5.3	MANUAL INTERVENTION QUESTIONS	23
4.6	START-UP PROCEDURE	24
5	ERROR INFORMATION	27
5.1	ERROR REPORT FORMAT	27
5.2	SPECIFIC ERROR MESSAGES	30
5.2.1	00002 - TWO UNITS SELECT THE SAME DRIVE	30
5.2.2	00003 MORE THAN 4 DRIVES SELECTED ON THIS CONTROLLER	30
5.2.3	00004 NOT ENOUGH MEMORY TO TEST THE UNITS SELECTED	31
5.2.4	00005 INVALID BEGIN/END SET SPECIFIED	31
5.2.5	00006 - DATA STRUCTURE CORRUPT	31
5.2.6	00014 - CONTROLLER IS NOT SUPPORTED BY THIS DIAGNOSTIC PROGRAM	32
5.2.7	00021 - FATAL ERROR REPORTED BY CONTROLLER	32
5.2.8	00022 - STEP BIT DID NOT SET IN SA REGISTER DURING INITIALIZATION	32
5.2.9	00023 - CONTROLLER DID NOT CLEAR RING STRUCTURE IN HOST MEMORY	34
5.2.10	00024 - SA REGISTER DID NOT GO TO ZERO AFTER STEP 3	34
5.2.11	00025 - INCORRECT DATA RETURNED IN SA REGISTER	34
5.2.12	00026 - DATA COMPARISON ERROR DURING WRAP MODE TEST	36
5.2.13	00027 - SA REGISTER DID NOT CHANGE AFTER WRITING TO IT	36
5.2.14	00030 - FATAL ERROR REPORTED BY CONTROLLER	36
5.2.15	00031 - CONTROLLER TIMED OUT BY HOST	37
5.2.16	00032 - PACKET RECEIVED FROM CONTROLLER WITH UNKNOWN ENDCODE	37
5.2.17	00033 - PACKET RECEIVED FROM CONTROLLER WITH UNKNOWN STATUS	37
5.2.18	00034 - CONTROLLER DETECTED AN INVALID COMMAND PACKET	39
5.2.19	00035 - PACKET RECEIVED FROM CONTROLLER SPECIFIES UNKNOWN DRIVE	39
5.2.20	00037 - MEMORY ERROR TRYING TO READ CONTROLLER REGISTERS	40
5.2.21	00038 - DATA COMPARE ERROR DURING DATA PATTERN VERIFICATION	41

5.2.22	00039 - DATA COMPARE ERROR DURING CONTROLLER MEMORY TEST	41
5.2.23	00041 - MSCP OPERATION FAILED	41
5.2.24	00042 - PREVIOUS FATAL CONTROLLER ERROR	43
5.2.25	00043 - PREVIOUS FATAL DRIVE ERROR	43
5.2.26	00050 - ERROR LOG RECEIVED - CONTROLLER ERROR	43
5.2.27	00051 - ERROR LOG RECEIVED - HOST MEMORY ACCESS ERROR	45
5.2.28	00052 - ERROR LOG RECEIVED - DISK TRANSFER ERROR	45
5.2.29	00053 - ERROR LOG RECEIVED - SDI ERROR	46
5.2.30	00054 - ERROR LOG RECEIVED - SMALL DISK ERROR	47
5.2.31	00060 - AVAILABLE ATTENTION MESSAGE RECEIVED	47
5.2.32	00061 - DUPLICATE UNIT ATTENTION MESSAGE RECEIVED	47
6	PERFORMANCE AND PROGRESS REPORTS	49
7	GLOSSARY	51

APPENDIX A DRS COMMAND SUMMARY

APPENDIX B SA REGISTER ERROR CODE SUMMARY (OCTAL)

APPENDIX C TEST DATA PATTERNS

1 GENERAL INFORMATION

1.1 PROGRAM ABSTRACT

The PDP-11 UDA50-A/KDA50-Q SUBSYSTEM EXERCISER is a standalone diagnostic written in MACRO-11 that runs under the control of version 2.1 of the PDP-11 Diagnostic Supervisor (XXDP+). This diagnostic exercises UDA50-A or KDA50-Q disk subsystems and verifies that the subsystems function properly. Though it will provide the operator all relevant information returned in the MSCP (Mass Storage Control Protocol) response packet when a failure occurs, the operator may be required to use other diagnostics to isolate the FRU (Field Replaceable Unit) that failed.

The UDA50-A/KDA50-Q SUBSYSTEM EXERCISER uses the MSCP interface to the KDA50-Q or UDA50-A disk controller to perform extensive input/output operations on all selected SDI (Standard Disk Interface) compatible disk drives and selected controllers.

The UDA50-A/KDA50-Q SUBSYSTEM EXERCISER consists of three tests: a controller verification test (TEST 1), a subsystem verification test (TEST 2), and a subsystem exerciser (TEST 3). TEST 1 will support at least two controllers. TESTS 2 and 3 are multi-drive tests that will support at least two controllers with a maximum of four drives on each controller. The only test parameters applicable to TEST 1 and TEST 2 are the hardware test parameters. Both the software and hardware test parameters are applicable to TEST 3. The default operation of this diagnostic program is to run TEST 1, then run TEST 2, and then run TEST 3. Since this diagnostic can only access the customer data area on the drives under test, any operations requiring a write to the drive should only be used if the customer data has been adequately backed up or, on drives with removable media, a scratch pack is put in the drive.

TEST 1 (the controller verification test) tests each of the controllers' ability to initialize correctly and pass their self tests. The memory in the controller and the data path is verified by performing extensive maintenance read and write operations to each controller. The test will also verify the ability of the host to set each controller's characteristics using MSCP. This test does not perform any operations that use the disk drives.

TEST 2 (the subsystem verification test) initializes all of the controllers and drives under test. It verifies the host's ability to use MSCP to set the drives ONLINE, and AVAILABLE. It also verifies the subsystem's ability to perform read, seek, and data compare operations. On any drive that is writeable, this test verifies the

drive's ability to write and performs data pattern verification on the data written.

TEST 3 (the subsystem exerciser) initializes the controllers and brings the drives ONLINE. The exerciser consists of two phases, a deterministic phase and an operator modifiable phase. The deterministic phase exercises the subsystem in a manner fixed in the diagnostic program. The operator modifiable phase exercises the subsystem in a manner determined by the operator. Each phase will perform extensive simultaneous I/O operations to all of the drives under test. The amount of data transferred and the number of outstanding I/O operations will be limited by the amount of available memory on the system.

This program is designed to handle all future disk drives that are attached to the UDA50-A or KDA50-Q without modifying or rereleasing the program. This is possible because the disk drives are programmed to tell this diagnostic about all their characteristics that make them different from other drives, such as number of cylinders, sectors per cylinder, etc.

The following PDP-11 diagnostic programs are also provided for the UDA50-A or KDA50-Q disk subsystem:

- CZUDH - UDA50-A/KDA50-Q Basic Subsystem Diagnostic.
- CZUDI - UDA50-A/KDA50-Q Disk Drive Exerciser.
- CZUDK - UDA50-A/KDA50-Q Disk Drive Formatter.
- CZUDL - UDA50-A/KDA50-Q Bad Block Replacement Utility
- CXDUB - UDA50-A/KDA50-Q DEC/X11 Module.

This diagnostic has been written for use with the Diagnostic Runtime Services software (DRS supervisor). DRS provides the interface to the operator and to the software environment. For a complete description of the Diagnostic Runtime Services, refer to the XXDP+ User's Manual. There is a brief description of the Diagnostic Runtime Services in the OPERATING INSTRUCTIONS section of this document.

1.2 SYSTEM REQUIREMENTS

This program was designed using the XXDP version 2.1. The program requires version 2.1 or later of XXDP. Run time environments are

determined by the Diagnostic Runtime Services and may change as new versions of DRS are developed. This program requires the following:

- PDP-11 processor
- 28K words of memory (minimum)
- Console terminal
- XXDP+ load media containing this program
- One or more UDA50-A or KDA50-Q subsystems. The subsystem controller must be at the latest hardware and microcode revision level.
- Line clock - either Type L or P

The line clock is used for all timed loops in the program. If a clock exists on the system it should be enabled so it can interrupt the processor. The diagnostic will run on a system with no clock or with the clock disabled, but will hang whenever an event for which the program is waiting does not happen (i.e., a time-out error message will not result).

The XXDP+ load device does not need to remain on-line during the execution of this diagnostic.

2 PRODUCT GOALS

2.1 PERFORMANCE GOALS

The UDA50-A/KDA50-Q SUBSYSTEM EXERCISER will exercise any SDI compatible drive. The exerciser will build all MSCP packets needed to perform I/O operations to the drives under test. All error recovery and retries are performed by the controller automatically. ECC correction and retries can be disabled by the operator. All error reporting is based on information provided by the MSCP response packet. TEST 3 will allow the operator to change the parameters of the exercise, thereby isolating a possible problem to a specific region of a drive's media. It is the goal of the subsystem exerciser to generate as heavy an I/O load on the controller(s) and drive(s) as possible.

2.2 FAILSOFT GOALS

When a read, write, or access operation fails, the exerciser will display the following information: the elapsed time to failure, the controller and drive that the failure occurred on, the LBN of the failing sector, and the reason for the failure.

When the hard error limit for a drive has been reached, the drive is dropped from testing and a message will be printed notifying the operator that the drive has been dropped. If a device fatal error occurs, the drive is immediately dropped. The error limit has no effect on device fatal errors.

Unexpected traps will require the operator to restart the diagnostic. The diagnostic will restart automatically after a power failure as long as the contents of memory or the hardware configuration are unchanged. Otherwise, the operator must re-boot the system.

2.3 RESTRICTIONS

The UDA50-A/KDA50-Q SUBSYSTEM EXERCISER will test at least two controllers at a time, with a maximum of four drives per controller. The number of sectors that can be transferred at a time and the number of drives and controllers that can be simultaneously tested will be limited by the available memory in the system.

2.4 NON-GOALS

This diagnostic will not replace bad blocks.

This diagnostic will not isolate failing FRUs.

This diagnostic is not intended to be perform disk media verification.

3 PROGRAM DESCRIPTION

The UDA50-A/KDA50-Q SUBSYSTEM EXERCISER consists of three tests: the controller verification test (TEST 1), the subsystem verification test (TEST 2), and the subsystem exerciser (TEST 3). TEST 1 will support at least two controllers. TESTS 2 and 3 are multi-drive tests that will support at least two controllers with a maximum of four drives on each controller. TEST 3 will exercise all of the drives under test in parallel unless restricted by memory. In all of the tests, the size of the data transfers, the number of devices simultaneously tested, and the number of outstanding MSCP commands will be limited by the amount of host memory available. The default operation of this diagnostic program is to run TEST 1, then run TEST 2, and then run TEST 3. All hardware, software, and manual intervention questions are asked prior to running the tests. The diagnostic fully supports all of the diagnostic supervisor (DRS) commands, switches, and flags (except LOE) which are listed in Appendix A of this document. Since this diagnostic can only access the customer data area on the drives under test, any operations requiring a write to the drive should only be used if the customer data has been adequately backed up or, on drives with removable media, a scratch pack is put in the drive.

To run the complete exerciser, the operator loads XXDP+, then types:

```
R ZUDJAO
  or
L ZUDJAO
S
```

and then at the diagnostic supervisor prompt (DR>), types:

```
START
```

If any of the drives are designated as writeable, the following warning message will be printed when the exerciser is started:

```
CUSTOMER DATA WILL BE DESTROYED ON:
  UNIT      CONTROLLER  DRIVE
  xx        xxxxxxx   xxx
```

Unless this diagnostic program is running in unattended mode, the warning message will be followed with the following question.

```
ARE YOU SURE CUSTOMER DATA CAN BE DESTROYED (L) N ?
```

An answer of 'N', the default, will halt the diagnostic and allow the

operator to change the hardware and software parameters. An answer of 'Y' will allow the diagnostic program to continue.

3.1 CONTROLLER VERIFICATION TEST (TEST 1)

TEST 1 is designed to verify that the controllers to be exercised are functional. This test does not perform any operations that use the disk drives. If any errors occur, the controller on which the error occurred and all associated drives will be dropped from further testing. Only the hardware test parameter questions are applicable to this test.

First, TEST 1 initializes all of the controllers to be tested and causes all internal controller diagnostics to be run. During STEP 1 of the initialization, the wrap mode bit will be set in the SA register and wrap mode testing will be performed. The wrap mode testing will use a shifting inversions data pattern. At the end of the wrap mode testing, the controllers will be re-initialized. In STEP 3 of the initialization, both the PURGE/POLL test and the HOST MEMORY test will be performed by the controllers. In STEP 4 of the initialization, the LAST FAIL bit will be cleared and the GO bit will be set in the SA register. The model number and microcode version number will be obtained from the SA register in STEP 4.

After initialization, TEST 1 performs extensive maintenance write and read operations to the controller to verify the integrity of the controller's memory and the data path to the controller. The test will write the entire controller memory 34 times using a shifting inversions data pattern then read back the contents of memory and perform a data compare on the data read. The test will transfer 512 bytes of data in each write or read operation.

Finally, TEST 1 will re-initialize the controllers and issue a MSCP SET CONTROLLER CHARACTERISTICS command to each of them. This command will enable "attention messages", "miscellaneous error log messages", and "this host's error log messages". The host access timeout will be set to 0. The controller identifier, hardware revision number, and software revision number will be obtained from the end packet.

To run only TEST 1 of the diagnostic program, the operator loads XXDP+ and runs ZUDJAO, as described in the PROGRAM DESCRIPTION section. At the diagnostic supervisor prompt (DR>), the operator types:

STA/TEST:1

This will cause the diagnostic program to ask the hardware and software questions. Once the questions have been asked, TEST 1 is run.

3.2 SUBSYSTEM VERIFICATION TEST (TEST 2)

TEST 2 is designed to verify that the disk subsystems to be exercised are functional. If any device fatal errors occur, the drive on which the error occurred will be dropped from further testing. Controller errors will result in the controller and associated drives being dropped from testing. Only the hardware test parameter questions are applicable to this test.

First, TEST 2 initializes the controllers without performing the wrap mode test. After initialization, a MSCP SET CONTROLLER CHARACTERISTICS command is issued to each of the controllers. This command will enable "attention messages", "miscellaneous error log messages", and "this host's error log messages". The host access timeout will be set to 0. The controller identifier, hardware revision number, and software revision number will be obtained from the end packet.

TEST 2 then sets all of the drives under test online with the MSCP ONLINE command with the ENABLE SET WRITE PROTECT modifier. For each drive a MSCP SET UNIT CHARACTERISTICS command is issued to suppress caching. Drives that are not to be written are also software write protected.

TEST 2 will then test the data path to and from the drive. The test will first use a MSCP READ with DATA COMPARE command to read the first logical block on each disk. It will then issue a MSCP ACCESS command to access 20 blocks on each disk. While the ACCESS command is outstanding, a MSCP GETCOMMAND STATUS command will be issued to check the status of the ACCESS command.

On any drive that is writable, a MSCP ERASE command is issued for the first LBN on each disk. When this completes, MSCP WRITE with DATA COMPARE commands are used to write one block of each of the 16 standard data patterns to each drive under test. After performing the write operations, TEST 2 will perform a MSCP COMPARE HOST DATA command on the last block written.

Once the I/O operations have completed, this test will issue the MSCP AVAILABLE command for each drive. When the test completes, all drives will be available, but not spun down.

To run only TEST 2 of the diagnostic program, the operator loads XXDP, and runs ZUDJAO, as described in the PROGRAM DESCRIPTION section. At the diagnostic supervisor prompt (DR>), the operator types:

STA/TES:2

This will cause the diagnostic program to ask the hardware and software questions. Once the questions have been asked, TEST 2 is run.

3.3 SUBSYSTEM EXERCISER (TEST 3)

TEST 3 is designed to extensively exercise the disk subsystem. To the extent possible, TEST 3 will perform input and output operations to all of the drives under test simultaneously. This test will always attempt to maintain as high an input/output load on the drives and controllers as possible. If any errors occur, the action of this test will be determined by the setting of the software test parameters. All hardware, software, and manual intervention questions apply to this test.

First, TEST 3 initializes the controllers without performing the wrap mode test. This test will use command and response rings with 4 entries each. After initialization, a MSCP SET CONTROLLER CHARACTERISTICS command is issued to each of the controllers. This command will enable "attention messages", "miscellaneous error log messages", and "this host's error log messages". The host access timeout will be set to 0. The controller identifier, hardware revision number, and software revision number will be obtained from the end packet.

TEST 3 then sets all of the drives under test online with the MSCP ONLINE command with the ENABLE SET WRITE PROTECT modifier. The unit identifier, media type, and unit size will be obtained for each drive from the end message. For each drive a MSCP SET UNIT CHARACTERISTICS command is issued. Drives that are not to be written are also software write protected.

TEST 3 then enters the exerciser section of the test which consists of two phases, a deterministic phase and an operator modifiable phase. The deterministic phase exercises the subsystem in a manner fixed in the diagnostic program. The operator modifiable phase exercises the subsystem in a manner determined by the operator.

On drives that are writeable, the deterministic phase will

sequentially write 128 block segments containing each of the 16 standard data patterns to the drive.

On all drives, the deterministic phase will then sequentially read the first 512 blocks of data from the disk. Data compare operations will randomly be performed on the data read. The MSCP ACCESS command will be used to read the remaining blocks of data on the disk.

The operator configurable phase of TEST 3 consists of alternating read and (if enabled) write operations until the test limits are reached. Controller data compare operations are randomly performed on read and write operations. The characteristics of the read and write operations, and the test limits can be modified by the operator by using the software parameters and manual intervention questions. TEST 3 performs the operator configurable phase until the maximum run time expires, the error limit is reached on all selected drives, or the operator types CONTROL-C. When the exerciser completes, a summary message will be printed indicating any errors that occurred.

To run only TEST 3 of the diagnostic program, the operator loads XXDP, and runs ZUDJAO, as described in the PROGRAM DESCRIPTION section. At the diagnostic supervisor prompt (DR>), the operator types:

STA/TEST:3

This will cause the diagnostic program to ask the hardware, software, and, if selected, the manual intervention questions. Once the questions have been asked, TEST 3 is run.

4 OPERATING INSTRUCTIONS

This section contains a brief description of the Diagnostic Runtime Services. For detailed information, refer to the XXDP User's Manual.

4.1 COMMANDS

This section lists the Diagnostic Runtime Services commands and gives a very brief description of them. The XXDP User's Manual has more details.

COMMAND	EFFECT
START	Start the diagnostic from an initial state
RESTART	Start the diagnostic without initializing
CONTINUE	Continue a test that was interrupted (after ↑C)
PROCEED	Continue from an error halt
EXIT	Return to XXDP Monitor
REDIRECT	Redirect program output to a disk file or line printer.
TIME	Set the time of day or display current time
ADD	Activate a unit for testing (all units are considered to be active at start time)
UNROP	Deactivate a unit
PRINT	Print statistical information
DISPLAY	Type a list of all device information
FLAGS	Type the state of all flags
ZFLAGS	Clear all flags

A command can be recognized by the first three characters. So you may, for example, type "STA" instead of "START".

4.2 SWITCHES

There are several switches which can be used to modify supervisor operation. These switches are appended to the DRS commands. All of the available switches are listed below with a brief description of each. In the descriptions below, a decimal number is designated by "DDDD".

SWITCH	EFFECT
/TESTS:LIST	Execute only those tests specified in

<p>/PASS:DDDDD /FLAGS:FLGS /EOP:DDDDD /UNITS:LIST /DEV:DEVICE /LPT</p>	<p>the list. List is a string of test numbers, for example - /TESTS:1:5:7-10. This list will cause tests 1,5,7,8,9,10 to be run. All other tests will not be run. Execute DDDDD passes (DDDDD = 1 to 64000) Set specified flags. Report end of pass message after every DDDDD passes only. (DDDDD = 1 to 64000) TEST/ADD/DROP only those units specified in the list. List example - /UNITS:0:5:10-12 use units 0,5,10,11,12 (unit numbers = 0-63). Specify the device to which program output will be redirected. Output will be placed in a file called COLECT.DAT. Redirect program output to the lineprinter.</p>
---	---

Example of switch usage:

START/TESTS:1-5/PASS:1000/EOP:100

The effect of this command will be: 1) tests 1 through 5 will be executed, 2) all units will tested 1000 times and 3) the end of pass messages will be printed after each 100 passes only. A switch can be recognized by the first three characters. You may, for example, type "/TES:1-5" instead of "/TESTS:1-5".

Below is a table that specifies which switches can be used by each command.

	TESTS	PASS	FLAGS	EOP	UNITS	DEV	LPT
START	X	X	X	X	X		
RESTART	X	X	X	X	X		
CONTINUE		X	X	X			
PROCEED			X				
DROP					X		
ADD					X		
REDIRECT						X	X
TIME							
PRINT							
DISPLAY					X		
FLAGS							
ZFLAGS							
EXIT							

4.3 FLAGS

Flags are used to set up certain operational parameters such as halting on error. Flags are cleared after a START or RESTART command unless set using the /FLAG switch. The ZFLAGS command may also be used to clear all flags. With the exception of the START, the RESTART and ZFLAGS commands, no commands affect the state of the flags; they remain set or cleared as specified by the last /FLAG switch.

FLAG	EFFECT
HOE	Halt on error - control is returned to runtime services command mode
LOE	Loop on error (causes program to loop on test)
IER	Inhibit all error reports
IBE	Inhibit all error reports except first level (first level contains error type, number, PC, test and unit)
IXE	Inhibit extended error reports (those called by PRINTX macro's)
PRI	Direct messages to line printer
PNT	Print test number as test executes
BOE	"BELL" on error
UAM	Unattended mode (no manual intervention)
ISR	Inhibit statistical reports
IDU	Inhibit program dropping of units
LOT	Loop on test
EVL	Execute diagnostic evaluation code

See the XXDP+ User's Manual for more details on flags. You may specify more than one flag with the /FLAG switch. For example, to cause the program to loop on error, inhibit error reports and type a "BELL" on error, you may use the following string:

```
/FLAG:LOE:IER:BOE
```

4.4 EXTENDED P-TABLE DIALOGUE

When you answer the hardware questions, you are building entries in a table that describes the devices under test. The simplest way to build this table is to answer all questions for each unit to be tested. If you are testing multiple drives on the same controller, this becomes tedious since most of the answers are repetitious.

To illustrate a more efficient method, suppose you are testing a UDA50-A with 4 disk drives attached to it. These units are numbered 0 through 3. There is one hardware parameter that can vary among units, the drive number. This drive number may be 0 through 254. Below is a simple way to build a table for one UDA50-A with four units.

```
# UNITS (D) ? 4<CR>
```

```
UNIT 1  
CSR ADDRESS OF CONTROLLER (O) 172150 ? <CR>  
DRIVE # (D) 0 ? <CR>  
WRITE ON CUSTOMER DATA AREA (L) N ? Y<CR>
```

```
UNIT 2  
CSR ADDRESS OF CONTROLLER (O) 172150 ? <CR>  
DRIVE # (D) 0 ? 1<CR>  
WRITE ON CUSTOMER DATA AREA (L) Y ? Y<CR>
```

```
UNIT 3  
CSR ADDRESS OF CONTROLLER (O) 172150 ? <CR>  
DRIVE # (D) 1 ? 2<CR>  
WRITE ON CUSTOMER DATA AREA (L) Y ? Y<CR>
```

```
UNIT 4  
CSR ADDRESS OF CONTROLLER (O) 172150 ? <CR>  
DRIVE # (D) 2 ? 3<CR>  
WRITE ON CUSTOMER DATA AREA (L) Y ? Y<CR>
```

As you can see from the above example, the hardware parameters do not vary significantly from unit to unit. The procedure shown is not very efficient. Also, notice that the default values change when a non-default response is given.

The Runtime Services can take multiple unit specifications however. Let's build the same table using the multiple specification feature.

Example 1:

```
# UNITS (D) ? 4<CR>
```

```
UNIT 1  
CSR ADDRESS (O) 172150 ? <CR>  
DRIVE # (D) 0 ? 0-3<CR>  
WRITE ON CUSTOMER DATA AREA (L) N ? Y<CR>
```

Example 2:

```
# UNITS (D) ? 4<CR>
```

```
UNIT 1  
CSR ADDRESS (O) 172150 ? <CR>  
DRIVE # (D) 0 ? 0,1,2,3<CR>  
WRITE ON CUSTOMER DATA AREA (L) N ? Y<CR>
```

As you can see in the above dialogue, the supervisor will build as many entries as it can with the information given in any one pass through the questions. In each example, four entries are built since four drive numbers were specified. The supervisor assumes that the CSR address is 172150 for each entry since it was specified only once. In the first example, the "-" construct tells the supervisor to increment the data from the first number to the second. In this case, drive numbers 0, 1, 2, and 3 were specified.

4.5 TEST QUESTIONS

The following questions are asked by this diagnostic program in order to set up the parameters for the tests. The symbol in the parenthesis will indicate to the operator the type of response required.

D - Decimal number
O - Octal number
L - logical (Y/N)

The value following the response type indication will indicate the default value. The default value may be chosen by entering a carriage return <CR> to the question. The defaults given here are the defaults that would appear if the program was just loaded. Should any answer be changed, the new value will become the default until the diagnostic is re-loaded. In the SOFTWARE and MANUAL INTERVENTION questions, the new value will be displayed as the default in any subsequent passes through the test questions.

4.5.1 HARDWARE QUESTIONS -

When the diagnostic is started, hardware description tables must be created for each drive under test. In order to do this the supervisor will ask the following hardware questions.

CHANGE HW (L) ?

This question is always asked. If the answer is 'Y' then the other HARDWARE QUESTIONS will be asked. If the answer is 'N', the previously defined hardware tables will be used. The hardware tables can be pre-defined with the SETUP utility of XXDP+. If the SETUP utility has not been run, the default values listed below can be used to create the hardware table.

OF UNITS (D) ?

If only TEST 1 is selected, enter the number of controllers to be tested. If TEST 2, TEST 3 or all of the tests (the default) are selected, enter the number of drives to be tested. There is no default for this question.

The next 3 questions are asked for each unit selected:

CSR ADDRESS OF CONTROLLER (O) 172150 ?

Enter the CSR address for controller as addressed by the processor with memory management turned off (i.e. an even 16-bit address in the range 160000 to 177774). The default CSR used is 172150.

DRIVE # (D) 0 ?

Enter the unit number of the drive to be tested. The answer must be in the range of 0 through 254. The default unit number is 0. If only TEST 1 is being used, the default should be taken for this question.

WRITE ON CUSTOMER DATA AREA (L) N ?

This question is asked to minimize the risk of destroying customer data. The default answer of 'N' to this question causes the drive to be write-protected and no write operations will be performed on the drive. An answer of 'Y' will designate the drive as writeable. The default should be selected when only TEST 1 is selected.

4.5.2 SOFTWARE QUESTIONS -

The software questions allow the operator to tailor the operation of

the diagnostic. The software questions only apply to TEST 3.

CHANGE SW (L) ?

This question is always asked. If the answer is 'Y' then the other software questions will be asked. If the answer is 'N' then all of the default values for the test parameters will be used and the test will begin. If the SETUP utility is used to pre-define the test parameters, the pre-defined parameters will be used instead of the normal defaults.

The following message will be printed if the operator chooses to change the software parameters:

THE FOLLOWING QUESTIONS APPLY ONLY TO TEST 3:

ENTER MANUAL INTERVENTION MODE (L) N ?

An answer of 'Y' causes the manual intervention questions to be asked for TEST 3. An answer of 'N', the default, causes the manual intervention questions to be skipped. See the MANUAL INTERVENTION QUESTIONS section for more information on these questions.

HARD ERROR LIMIT (D) 1 ?

Enter the number of hard errors that will cause a drive to be dropped. Responding to this question with a zero requests that a drive never be dropped from testing due to exceeding the hard error limit. This parameter has no effect on device fatal errors. One device fatal error will cause a drive to be dropped. By default, a drive is dropped from testing after 1 hard error. A number in the range 0 to 65535 will be accepted.

EXERCISER TIME LIMIT IN MINUTES (D) 60 ?

Enter the time in minutes to run the exerciser. Responding to this question with a zero indicates that the test will only complete if the error limit is exceeded on all drives, or the operator types a CONTROL-C. A number in the range 0 to 65535 will be accepted. The default is 60 minutes.

MINUTES BETWEEN STATISTICAL REPORTS (D) 15 ?

Enter the time in minutes that will elapse between statistical reports. Responding to this question with a zero indicates that the statistical reports are not printed except when the operator types CONTROL-C and types PRINT or the test completes. A number in the range 0 to 65535 will be accepted. the default is 15 minutes. See the EXERCISE SUMMARY section for a description of the statistical reports.

PRINT SOFT ERROR MESSAGES (L) N ?

Enter 'Y' if a message should be printed whenever a soft error occurs. Soft errors include reporting of MSCP Error Log messages. An answer of 'N' will cause only messages for hard errors, data compare errors and device errors to be printed.

DO DATA PATTERN VERIFICATION ON READS (L) Y ?

An answer of 'Y' will cause the diagnostic to compare data read from the disk with data in host memory. The data is first read into host memory. Using the number in the first word of the block read, the host builds a block containing the expected data pattern and compares that with what was read. This pattern verification will fail if the drive has not been previously written with the standard diagnostic data patterns listed in the TEST DATA PATTERNS section. If selected, this data comparison will be randomly performed on read operations. By default data pattern verification on read operations is performed.

DO DATA PATTERN VERIFICATION ON WRITES (L) N ?

An answer of 'Y' will cause the diagnostic to compare data written to the disk with data in host memory. The data is first written to the disk and then read back by the controller and compared to the host memory buffer. If selected, this data comparison will be randomly performed on write operations. By default no data pattern verification on write operations is performed since selecting this option degrades the data transfer rate.

USE VARIABLE LENGTH TRANSFERS (L) Y ?

Answer 'Y' if the buffers written and/or read from the drives should be a variable length. Answer 'N' if the buffers should be fixed in

size. The default is variable length buffers.

MAXIMUM TRANSFER SIZE IN BLOCKS (D) 8 ?

Enter the maximum number of sectors to be read/written on one I/O operation. If fixed length transfers are selected, the number of sectors written and read will be equal to the buffer size except when a read or write of that length is impossible -- such as doing the last read or write to the end of data area. If variable length transfers are selected, the buffer size is a maximum, so the actual number of sectors will vary from 1 to the buffer size randomly. The maximum value for the buffer size is limited by the amount of available memory in the system. The default maximum transfer size is 8 blocks. A number in the range 1 to 128 will be accepted.

ENABLE ERROR RETRIES (L) Y ?

An answer of 'Y', the default, will allow retries of I/O operations that result in data errors. An answer of 'N' will disable retries and log the error as an uncorrectable data error.

ENABLE ECC DATA CORRECTION (L) Y ?

Enter 'Y' if ECC should be used to correct data errors during the test. An answer of 'N' will cause ECC errors to be treated as hard errors and retries will be attempted if enabled. By default, ECC is used for data correction.

RANDOMLY ACCESS DRIVE (L) Y ?

Enter 'N' to sequentially transfer data to or from the disk. Sequential access begins I/O at the lowest LBN in the first BEGIN/END set and continues sequentially to the highest LBN in the last BEGIN/END set. Enter 'Y' to transfer data randomly throughout the BEGIN/END sets. By default I/O is performed randomly.

DO DETERMINISTIC PHASE (L) Y ?

The deterministic phase writes the standard data patterns to the entire disk and then reads back the first 256 KB from the disk. The remainder of the disk is then ACCESSED. The deterministic phase is only executed in the first pass through TEST 3. By default the

deterministic phase of TEST 3 is performed.

4.5.3 MANUAL INTERVENTION QUESTIONS -

If MANUAL INTERVENTION FOR TEST 3 is selected, the following set of questions will be asked when TEST 3 begins. These questions determine the parameters that must be set up on a per-drive basis and are not applicable to the normal operation of this diagnostic program. The answers to these questions cannot be supplied using the SETUP utility. If this diagnostic program is run in unattended mode, the defaults will be used.

At the beginning of the questions the following message will be printed:

TEST 3 MANUAL INTERVENTION QUESTIONS:

DATA PATTERN TO USE (D) 0 ?

This question only applies to drives that are writeable. Enter the pattern, 0 through 15, to be used for testing. If pattern number zero is selected, the test will randomly write each of the sixteen data patterns. See the TEST DATA PATTERNS section for a description of data patterns 1 through 15 and default pattern 16. An operator defined pattern can be specified for pattern 16. The default data pattern is 0, all patterns randomly selected.

If PATTERN 0 or PATTERN 16 is selected for the drives under test, the following questions are asked:

MODIFY DATA PATTERN 16 (L) N?

Enter 'Y' to modify data pattern 16. If data pattern 16 is modified, the deterministic phase of TEST 3 should be run so pattern verification errors don't occur. By default the standard pattern is used.

HOW MANY WORDS IN PATTERN 16 (D) 1?

This question and the questions pertaining to the data words in pattern 16 will only be asked if the user desires to modify pattern 16. Enter the number of words in the pattern. The pattern may not consist of more than 16 words. The following questions will be asked

until all of the words in the pattern are defined:

DATA WORD (0) 000000 ?
DATA WORD (0) 000000 ?
DATA WORD (0) 000000 ?

⋮

For each drive selected, the following questions will be asked:

THESE QUESTIONS REFER TO UNIT xx CONTROLLER AT xxxxxx DRIVE xxx

TEST OVER THE ENTIRE DISK (L) Y ?

Enter 'Y', the default, if the test is to be run over the entire customer data section of the drives under test or 'N' if testing should be limited to specific BEGIN/END sets. The following questions will be asked if the answer is 'N':

NUMBER OF BEGIN/END SETS TO USE (D) 1 ?

Enter the number of BEGIN/END sets to be used in the test. All testing will be done within the bounds of the BEGIN/END sets. The default is 1 BEGIN/END set consisting of the entire customer data area. The maximum number of BEGIN/END sets that can be specified for each drive is four. For each BEGIN/END set selected, the following question will be asked:

STARTING LBN (D) 0 ?

ENDING LBN (D) 0 ?

The valid LBN range is 0 to the maximum LBN in the customer data area of the disk. Since the number of LBNs on the disk is not known to the program until the drive is brought online, bounds checking is not done until the drive is brought online. The ending LBN must be greater than or equal to the starting LBN.

4.6 START-UP PROCEDURE

To run this program:

1. Boot XXDP+
2. Type "R ZUDJAO"
3. Type "STA"
4. If the hardware parameters need to be changed, answer the "CHANGE HW" question with "Y" and answer all of the hardware questions. Otherwise, answer the "CHANGE HW" question with "N".
5. If the software parameters need to be changed, answer the "CHANGE SW" question with "Y" and answer all of the software questions. Otherwise, answer the "CHANGE SW" question with "N".

Below is a sample of terminal dialogue to test two disks on one controller.

DR>STA/FLA:PNT/PAS:1

CHANGE HW (L) ? Y

UNITS (D) ? 2

UNIT 0

CSR ADDRESS OF CONTROLLER (O) 172150 ?

DRIVE # (D) 0? 0,1

WRITE ON CUSTOMER DATA AREA (L) N ? Y<CR>

CHANGE SW (L) ? Y

THE FOLLOWING QUESTIONS APPLY ONLY TO TEST 3:

ENTER MANUAL INTERVENTION MODE (L) N ?

HARD ERROR LIMIT (D) 1 ?

EXERCISER TIME LIMIT IN MINUTES (D) 60 ?

MINUTES BETWEEN STATISTICAL REPORTS (D) 15 ?

PRINT SOFT ERROR MESSAGES (L) N ?

ENABLE ERROR LOG (L) N ?

DO DATA PATTERN VERIFICATION ON READS (L) Y ?

DO DATA PATTERN VERIFICATION ON WRITES (L) N ?

USE VARIABLE LENGTH TRANSFERS (L) Y ?

MAXIMUM TRANSFER SIZE IN BLOCKS (D) 16 ?

ENABLE ERROR RETRIES (L) Y ?

ENABLE ECC DATA CORRECTION (L) Y ?

RANDOMLY ACCESS DRIVE (L) Y ?

UDA50-A/KDA50-Q Subsystem Exerciser User Guide

Page 26

DO DETERMINISTIC PHASE (L) Y ?

TST: 001
TST: 002
TST: 003

CZUDJ end of pass 1
number of errors 0

DR>

5 ERROR INFORMATION

5.1 ERROR REPORT FORMAT

The general error format is shown below. Note that informational messages do not follow this general format, because they are not errors. In the example below, all words in lower case letters indicate values that are generated at run time.

```
CZUDJO severity err_num ON UNIT unit TST test SUB subtest PC: pc
test_descr CONTROLLER AT csr DRIVE drive RUNTIME hh:mm:ss
error_text
additional_information
```

severity:

Identifies the severity of error. The four levels of severity are: 'SFT ERR' for soft errors, 'HRD ERR' for hard errors, 'DEV FTL' for device fatal errors, and 'SYS FTL' for system fatal errors.

System fatal errors (SYS FTL ERR) are used to report errors that are fatal to the entire diagnostic program. The diagnostic stops and the supervisor prompt is printed.

Device fatal errors (DVC FTL ERR) are used to report errors that are fatal to the device (may be either a UDA50-A or KDA50-Q or disk drive). Testing stops on that device for the remainder of the current pass.

Hard errors (HRD ERR) are unrecoverable non-fatal errors. Testing will normally continue after the printing of the error unless the hard error limit has been reached.

Soft errors (SFT ERR) indicate a problem was encountered that was resolved by re-trying the operation or by using ECC.

errnum:

This is the number (decimal) of the error that occurred.

unit:

This is the number assigned to each unit under test by the diagnostic supervisor. Any adds or drops of units should refer to this number.

test:

This is the test number of the currently running test.

subtest:

This is the number of the currently running subtest.

pc:

This is the diagnostic program's program counter at the time of the error.

testdescr:

This is a brief description of the test being performed when the error occurred. The description will be one of the following: TEST INITIALIZATION, CONTROLLER VERIFICATION, SUBSYSTEM VERIFICATION, or SUBSYSTEM EXERCISER.

csr:

This is the bus address of the controller's IP register. This is only printed if the error involves the controller.

drive:

This is the drive's unit plug number which is on the front panel of the drive. This is only printed if the error involves a disk drive.

hh:mm:ss:

This is how long the diagnostic program has been running.

errortext:

This is the error (in english) that occurred.

additionalinformation:

This is information to help the operator diagnose the cause of the problem. The additional information reported depends on the type of error.

There are three levels of error messages that may be issued by a diagnostic: general, basic and extended. General messages consist of the first line of the error. They indicate the name of the diagnostic, the error type and number, the failing unit, the test and subtest being executed, and the memory address of the error call in the diagnostic. General error messages are always printed unless the "IER" flag is set.

Basic error messages consist of at least two lines of text describing the error. The first line reports the name of the test, the controller (if any) currently being tested, the drive (if any) being tested, and the elapsed time since the program was started. The other

lines report the nature of the error. These are always printed unless the "IER" or "IBE" flags are set. These messages are printed after the associated general message.

Extended error messages contain supplementary error information such as register contents or good/bad data. These are always printed unless the "IER", "IBE" or "IXE" flags are set (section 2.3). These messages are printed after the associated general error message and basic error messages.

Sample error message:

```
CZUDJ HRD ERR 00038 ON UNIT 00 TST 003 SUB 000 PC: 045416
SUBSYSTEM EXERCISER - CONTROLLER AT 172150, DRIVE 5 - RUNTIME 0:20:12
DATA COMPARE ERROR DURING DATA PATTERN VERIFICATION
LBN: 000123, BYTE OFFSET: 123
DATA EXPECTED: 000000, DATA READ: 121212
```

Some informational messages are also printed by this program. They are one or two lines in length and consist of a time stamp and the message text. These messages are for informational purposes only and their contents should be self explanatory.

5.2 SPECIFIC ERROR MESSAGES

Following is a list of the error messages that can be printed by the diagnostic program. In the list, some of the numbers that may vary with execution or program version are shown as lower case words. These include program counters and runtime. Other numbers, such as unit number, drive number, UDA50-A or KDA50-Q address and data in registers are filled with sample numbers. Additional information about the error follows the error message.

5.2.1 00002 - TWO UNITS SELECT THE SAME DRIVE -

```
CZUDJ SYS FTL ERR 00002 ON UNIT unit TST tst SUB sub PC: hostpc
TEST INITIALIZATION - CONTROLLER AT csr, DRIVE drive - RUNTIME hh:mm:ss
INVALID ANSWERS GIVEN TO THE HARDWARE QUESTIONS
TWO UNITS SELECT THE SAME DRIVE
```

The hardware questions for two units specify the same disk drive. The program is aborted and returns to the Runtime Services prompt so that you can change the hardware questions.

5.2.2 00003 MORE THAN 4 DRIVES SELECTED ON THIS CONTROLLER -

```
CZUDJ SYS FTL ERR 00003 ON UNIT unit TST tst SUB sub PC: hostpc
TEST INITIALIZATION - CONTROLLER AT csr - RUNTIME hh:mm:ss
INVALID ANSWERS GIVEN TO THE HARDWARE QUESTIONS
MORE THAN 4 DRIVES SELECTED ON THIS CONTROLLER
```

Up to four physical disk drives can be attached to a UDA50-A or KDA50-Q at one time. The program is aborted and returns to the supervisor prompt so that you can change the hardware questions.

5.2.3 00004 NOT ENOUGH MEMORY TO TEST THE UNITS SELECTED -

CZUDJ SYS FTL ERR 00004 ON UNIT unit TST tst SUB sub PC: hostpc
TEST INITIALIZATION - RUNTIME hh:mm:ss
NOT ENOUGH MEMORY TO TEST THE UNITS SELECTED
RESTART PROGRAM AND TEST FEWER UNITS AT A TIME

This program does not limit the number of units that can be tested by specifying a maximum number. What limits the number is the amount of memory used to store data on each unit. The amount of memory available to the program is inadequate for the the number of units selected. Start program over and select fewer units.

5.2.4 00005 INVALID BEGIN/END SET SPECIFIED -

CZUDJ SYS FTL ERR 00005 ON UNIT unit TST tst SUB sub PC: hostpc
SUBSYSTEM EXERCISER - CONTROLLER AT csr , DRIVE drive - RUNTIME hh:mm:ss
INVALID BEGIN/END SET SPECIFIED
BEGIN/END SET SPECIFIES OUT-OF-RANGE LBN.
MAXIMUM LBN: xxxxxx

A begin/end set specified in the manual intervention questions of test 3 specifies a LBN that does not exist on the drive under test. Re-start the program and specify a valid LBN range.

5.2.5 00006 - DATA STRUCTURE CORRUPT -

CZUDJ SYS FTL ERR 00006 ON UNIT unit TST tst SUB sub PC: hostpc
test_descr - RUNTIME hh:mm:ss
DATA STRUCTURE CORRUPT AT LOCATION xxxxxx. RE-LOAD PROGRAM

A number of data structures are created by the diagnostic program. If the program detects a corruption of one of these data structures, this error will be printed. Please report this error to the maintaining group since this usually indicates a program bug. Often, the program will run without error once it has been re-loaded.

5.2.6 00014 - CONTROLLER IS NOT SUPPORTED BY THIS DIAGNOSTIC PROGRAM

CZUDJ SYS FTL ERR 00014 ON UNIT unit TST tst SUB sub PC: hostpc
TEST INITIALIZATION - CONTROLLER AT csr - RUNTIME hh:mm:ss
CONTROLLER IS NOT SUPPORTED BY THIS DIAGNOSTIC PROGRAM.
THIS PROGRAM REQUIRES A UQSSP DISK TYPE CONTROLLER
CONTROLLER REPORTED MODEL CODE xx

This diagnostic program was designed to test any UQSSP disk type controller though due to the differences in the controllers, only the UDA50-A (modules M7435-6) and KDA50-Q (modules M7164-5) controllers are fully supported. The diagnostic will attempt to test the RC25 and RQDX1, but the results are not guaranteed to be 100% correct. No other controllers can be tested by this diagnostic.

5.2.7 00021 - FATAL ERROR REPORTED BY CONTROLLER -

CZUDJ DVC FTL ERR 00021 ON UNIT unit TST tst SUB sub PC: hostpc
test_descr - CONTROLLER AT csr - RUNTIME hh:mm:ss
FATAL ERROR REPORTED BY CONTROLLER
SA REGISTER CONTAINS: xxxxxx
REPLACE CONTROLLER module MODULE

The controller resident diagnostic detected a failure. The error is displayed in the SA register. The program will attempt to determine which of the controller boards failed and report it in the last line of the error message. A list of the possible error codes and their meaning are contained in an appendix to this document.

5.2.8 00022 - STEP BIT DTD NOT SET IN SA REGISTER DURING
INITIALIZATION -

CZUDJ DVC FTL ERR 00022 ON UNIT unit TST tst SUB sub PC: hostpc
test_descr - CONTROLLER AT csr - RUNTIME hh:mm:ss
STEP BIT DID NOT SET IN SA REGISTER DURING INITIALIZATION
STEP BIT EXPECTED: xxxxxx
SA REGISTER CONTAINS: xxxxxx
REPLACE CONTROLLER PROCESSOR MODULE

The controller did not respond as expected during the initialization sequence which communicates using data in the SA register. A normal response from the controller contains either a STEP bit or an ERROR bit defined as follows:

UDA50-A/KDA50-Q Subsystem Exerciser User Guide

Page 33

Bit 15 (100000)	Error bit
Bit 14 (040000)	Step 4 bit
Bit 13 (020000)	Step 3 bit
Bit 12 (010000)	Step 2 bit
Bit 11 (004000)	Step 1 bit

The expected step bit nor the error bit set within the expected time.

5.2.9 00023 - CONTROLLER DID NOT CLEAR RING STRUCTURE IN HOST MEMORY

CZUDJ DVC FTL ERR 00023 ON UNIT unit TST tst SUB sub PC: hostpc
test_descr - CONTROLLER AT car - RUNTIME hh:mm:ss
CONTROLLER DID NOT CLEAR PORT COMMUNICATIONS AREA DURING INITIALIZATION
x WORDS WERE TO BE CLEARED STARTING AT ADDRESS xxxxxx
THE FOLLOWING WORDS NOT CLEARED:

ADDRESS	CONTENTS
xxxxxx	xxxxxx
xxxxxx	xxxxxx
xxxxxx	xxxxxx

REPLACE CONTROLLER PROCESSOR MODULE

The controller is to clear the ring structure (a communications area used by the controller to talk to the host) in host memory before Step 4 of initialization. If the controller diagnostics did not clear memory and did not flag an error, then error message 00023 is displayed. The contents of each word in memory is set to 17777 before the test. Failure of the controller to clear each word indicates a fault in the address interface to the bus.

5.2.10 00024 - SA REGISTER DID NOT GO TO ZERO AFTER STEP 3 -

CZUDJ DVC FTL ERR 00024 ON UNIT unit TST tst SUB sub PC: hostpc
test_descr - CONTROLLER AT car - RUNTIME hh:mm:ss
SA REGISTER DID NOT GO TO ZERO AFTER STEP 3 WRITE OF INITIALIZATION
PURGE/POLL DIAGNOSTICS WERE REQUESTED
SA REGISTER CONTAINS: xxxxxx

During step 3 of the controller initialization, the host can test the PURGE and POLL mechanism of the controller. To do so the host sets bit15 of the step 3 data and sends the data to the controller. The controller must go to zero and wait for the adapter purge completion and polling to begin. If the controller never goes to zero, then error message 00024 is displayed. The controller may have a bad processor module or the bus maybe broken.

5.2.11 00025 - INCORRECT DATA RETURNED IN SA REGISTER -

CZUDJ DVC FTL ERR 00025 ON UNIT unit TST tst SUB sub PC: hostpc
test_descr - CONTROLLER AT car - RUNTIME hh:mm:ss
INCORRECT DATA RETURNED IN SA REGISTER DURING INITIALIZATION
DATA EXPECTED: xxxxxx

SA REGISTER CONTAINS: xxxxxx
REPLACE CONTROLLER PROCESSOR MODULE

For each step of initialization, specific data is expected to be displayed in the SA register. If the contents of the SA register does not match the expected data, then error message 00025 is displayed. Replace controller processor module.

5.2.12 00026 - DATA COMPARISON ERROR DURING WRAP MODE TEST -

CZUDJ DVC FTL ERR 00026 ON UNIT unit TST tst SUB sub PC: hostpc
CONTROLLER VERIFICATION - CONTROLLER AT ccr - RUNTIME hh:mm:ss
DATA COMPARISON ERROR DURING WRAP MODE TEST
DATA EXPECTED: xxxxxx
SA REGISTER CONTAINS: xxxxxx
REPLACE CONTROLLER PROCESSOR MODULE

The controller can be put into a mode where the SA register acts as a wrap port. While the controller is in this mode, any data being sent to the SA register will be displayed in the SA register within a small period of time. If the data in the SA register does not match the data that was sent to the SA register, then error message 00026 is displayed. Replace controller processor module.

5.2.13 00027 - SA REGISTER DID NOT CHANGE AFTER WRITING TO IT -

CZUDJ DVC FTL ERR 00027 ON UNIT unit TST tst SUB sub PC: hostpc
CONTROLLER VERIFICATION - CONTROLLER AT ccr - RUNTIME hh:mm:ss
SA REGISTER DID NOT CHANGE AFTER WRITING TO IT IN WRAP MODE TEST
SA REGISTER CONTAINS: xxxxxx
REPLACE CONTROLLER PROCESSOR MODULE

The controller can be put into a mode where the SA register acts as a wrap port. While the controller is in this mode, any data being sent to the SA register will be displayed in the SA register within a small period of time. If, after the host program sends data to it while it was in diagnostic wrap mode, the controller does not change the contents of the SA register, error message 00027 is displayed. Replace controller processor module.

5.2.14 00030 - FATAL ERROR REPORTED BY CONTROLLER -

CZUDJ DVC FTL ERR 00030 ON UNIT unit TST tst SUB sub PC: hostpc
test descr - CONTROLLER AT ccr - RUNTIME hh:mm:ss
FATAL ERROR REPORTED BY CONTROLLER
SA REGISTER CONTAINS: xxxxxx

A message from the controller firmware reports an unexpected failure. An error code is presented in the SA register. See the appendix for a list of codes and their meaning.

5.2.15 00031 - CONTROLLER TIMED OUT BY HOST -

CZUDJ DVC FTL ERR 00031 ON UNIT unit TST tst SUB sub PC: hostpc
test_descr - CONTROLLER AT ccr - RUNTIME hh:mm:ss
CONTROLLER TIMED OUT BY HOST, NO PROGRESS MADE ON COMMAND

The controller is required to either complete a command or make progress on the command within a controller specified timeout interval. If progress has not been made on the oldest outstanding command, the host assumes the controller has failed and drops it from testing.

5.2.16 00032 - PACKET RECEIVED FROM CONTROLLER WITH UNKNOWN ENDCODE -

CZUDJ DVC FTL ERR 00032 ON UNIT unit TST tst SUB sub PC: hostpc
test_descr - CONTROLLER AT ccr - RUNTIME hh:mm:ss
PACKET RECEIVED FROM CONTROLLER WITH UNKNOWN ENDCODE
ENDCODE: xxx
MESSAGE BUFFER CONTAINS:

000001 000002 000003 000004 000005 000006 000007
000008 000009 000010 000011 000012 000013 000014
000015 000016 000017 000018 000019 000020 000021
000022 000023 000024 000025 000026 000027 000028
000029 000030 000031 000032 000033 000034 000035

A message packet was received from the controller with an endcode unknown to the diagnostic program. The endcode is contained in byte 8 of the packet. If the endcode is valid, a problem report should be submitted to the diagnostic maintenance group.

5.2.17 00033 - PACKET RECEIVED FROM CONTROLLER WITH UNKNOWN STATUS -

CZUDJ DVC FTL ERR 00033 ON UNIT unit TST tst SUB sub PC: hostpc
test_descr - CONTROLLER AT ccr - RUNTIME hh:mm:ss
PACKET RECEIVED FROM CONTROLLER WITH UNKNOWN STATUS
STATUS: status
MESSAGE BUFFER CONTAINS:

000001 000002 000003 000004 000005 000006 000007
000008 000009 000010 000011 000012 000013 000014
000015 000016 000017 000018 000019 000020 000021
000022 000023 000024 000025 000026 000027 000028
000029 000030 000031 000032 000033 000034 000035

A message packet was received from the controller with status code unknown to the diagnostic program. If the status code is valid, a problem report should be submitted to the diagnostic maintenance group.

5.2.18 00034 - CONTROLLER DETECTED AN INVALID COMMAND PACKET -

```
CZUDJ DVC FTL ERR 00034 ON UNIT unit TST tst SUB sub PC: hostpc
test descr - CONTROLLER AT csr - RUNTIME hh:mm:ss
CONTROLLER DETECTED AN INVALID COMMAND PACKET
FIELD AT OFFSET xx IS BAD
MESSAGE BUFFER CONTAINS:
000001 000002 000003 000004 000005 000006 000007
000008 000009 000010 000011 000012 000013 000014
000015 000016 000017 000018 000019 000020 000021
000022 000023 000024 000025 000026 000027 000028
000029 000030 000031 000032 000033 000034 000035
```

The controller has detected invalid data in a command packet received from the host. The byte offset of the invalid field is included in the message. This error could be caused either by a program error or a system hardware error. If the program appears to be generating an invalid command packet, send a problem report to the diagnostic maintenance group.

5.2.19 00035 - PACKET RECEIVED FROM CONTROLLER SPECIFIES UNKNOWN DRIVE -

```
CZUDJ DVC FTL ERR 00035 ON UNIT unit TST tst SUB sub PC: hostpc
test descr - CONTROLLER AT csr - RUNTIME hh:mm:ss
PACKET RECEIVED FROM CONTROLLER SPECIFIES UNKNOWN DRIVE
DRIVE UNIT NUMBER: xx
MESSAGE BUFFER CONTAINS:
000001 000002 000003 000004 000005 000006 000007
000008 000009 000010 000011 000012 000013 000014
000015 000016 000017 000018 000019 000020 000021
000022 000023 000024 000025 000026 000027 000028
000029 000030 000031 000032 000033 000034 000035
```

The controller sent a message to the host referencing a drive which doesn't have an entry in the host program's drive data tables. The message sent to the host program is also included in the error message. The word at byte offset 4 contains the drive number specified. This error can indicate either a software or hardware error.

5.2.20 00037 - MEMORY ERROR TRYING TO READ CONTROLLER REGISTERS -

CZUDJ DVC FTL ERR 00037 ON UNIT unit TST tst SUB sub PC: hostpc
test_descr - CONTROLLER AT csr - RUNTIME hh:mm:ss
MEMORY ERROR TRYING TO READ CONTROLLER REGISTERS
EITHER THE CONTROLLER CSR ADDRESS WAS INCORRECTLY SPECIFIED
OR THERE IS A BUS OR CONTROLLER PROBLEM

A non-existent memory error occurred when the host program tried to access the controller IP or SA registers. The controller is at another CSR address (check the bus selection switches) or the processor module is broken or the bus is broken.

5.2.21 00038 - DATA COMPARE ERROR DURING DATA PATTERN VERIFICATION -

CZUDJ HRD ERR 00038 ON UNIT unit TST tst SUB sub PC: hostpc
test_descr - CONTROLLER AT csr - RUNTIME hh:mm:ss
DATA COMPARE ERROR DURING DATA PATTERN VERIFICATION
LBN: xxxxxx, BYTE OFFSET: xxxxxx
DATA EXPECTED: xxxxxx, DATA READ: xxxxxx

If selected by the operator, data pattern verification is randomly performed by the program during read operations. The first word of the block read is checked for a pattern number. The pattern indicated by the pattern number is generated by the program and the block read is checked to make sure it contains the correct pattern. If the data read is not the same as the data pattern generated by the host, this error will occur. This usually indicates a problem transferring data between the host and the controller. If the standard diagnostic data patterns have not been written to the disk by this program or another RA series disk diagnostic, this test will fail. The standard diagnostic data patterns are listed later in this document.

5.2.22 00039 - DATA COMPARE ERROR DURING CONTROLLER MEMORY TEST -

CZUDJ DVC FTL ERR 00039 ON UNIT unit TST tst SUB sub PC: hostpc
CONTROLLER VERIFICATION - CONTROLLER AT csr - RUNTIME hh:mm:ss
DATA COMPARE ERROR DURING CONTROLLER MEMORY TEST
CONTROLLER MEMORY ADDRESS: xxxxxx
DATA WRITTEN: xxxxxx DATA READ: xxxxxx

The controller verification test performs a controller memory test by writing known data patterns to the controller memory and then reading the data back. If the data read is not the same as the data written this error will occur. The data pattern used is a floating inversion pattern. This usually indicates a bad memory location in the controller, a controller memory addressing problem, or a data transfer problem.

5.2.23 00041 - MSCP OPERATION FAILED -

CZUDJ DVC FTL ERR 00041 ON UNIT unit TST tst SUB sub PC: hostpc
test_descr - CONTROLLER AT csr, DRIVE drive - RUNTIME hh:mm:ss
operation MSCP OPERATION FAILED
STATUS/EVENT CODE: status
BAD BLOCK REPORTED. LBN: xxxxxx

ADDITIONAL BAD BLOCKS UNREPORTED
ERROR LOG GENERATED
MESSAGE BUFFER CONTAINS:

000001 000002 000003 000004 000005 000006 000007
000008 000009 000010 000011 000012 000013 000014
000015 000016 000017 000018 000019 000020 000021
000022 000023 000024 000025 000026 000027 000028
000029 000030 000031 000032 000033 000034 000035

This error message indicates a MSCP operation has failed. The operation that failed is indicated in the error message. The status returned by the controller and the response packet are also displayed. If bad blocks are detected or an error log message is generated, these will also be reported to the user. For more information on the information returned by the controller, see the MSCP architectural specification and the device service manuals.

5.2.24 00042 - PREVIOUS FATAL CONTROLLER ERROR -

CZUDJ DVC FTL ERR 00042 ON UNIT unit TST tst SUB sub PC: hostpc
test_descr - CONTROLLER AT csr - RUNTIME hh:mm:ss
PREVIOUS FATAL CONTROLLER ERROR CAUSED THE CONTROLLER AND
THE FOLLOWING DRIVES TO BE DROPPED: x, x, x, x,

This error message will be printed after a fatal controller error has occurred to inform the operator that all of the drives have been dropped from testing.

5.2.25 00043 - PREVIOUS FATAL DRIVE ERROR -

CZUDJ DVC FTL ERR 00043 ON UNIT unit TST tst SUB sub PC: hostpc
test_descr - CONTROLLER AT csr, DRIVE drive - RUNTIME hh:mm:ss
PREVIOUS FATAL DRIVE ERROR CAUSED THIS DRIVE TO BE DROPPED

This error message will be printed after a fatal drive error has occurred to inform the operator that the drive has been dropped from testing.

5.2.26 00050 - ERROR LOG RECEIVED - CONTROLLER ERROR -

CZUDJ SFT ERR 00050 ON UNIT unit TST tst SUB sub PC: hostpc
test_descr - CONTROLLER AT csr - RUNTIME hh:mm:ss
ERROR LOG RECEIVED - CONTROLLER ERROR
OPERATION status
STATUS/EVENT CODE: status
MESSAGE BUFFER CONTAINS:
000001 000002 000003 000004 000005 000006 000007
000008 000009 000010 000011 000012 000013 000014
000015 000016 000017 000018 000019 000020 000021
000022 000023 000024 000025 000026 000027 000028
000029 000030 000031 000032 000033 000034 000035

This error message indicates that a error log message was received from the controller indicating a controller error has occurred. The 'OPERATION status' line of the message will tell whether the MSCP operation that caused the error is continuing, was successful, or failed. The event code for the message and the error log message are reported to the operator. If the operation failed, a error message of type 00041 will also be printed. Error log messages will only be reported to the operator if the printing of soft error messages is

enabled in the software questions. More information on the contents of the error log message can be found in the device's service manual and in the MSCP architectural specification.

5.2.27 00051 - ERROR LOG RECEIVED - HOST MEMORY ACCESS ERROR -

```
CZUDJ SFT ERR 00051 ON UNIT unit TST tst SUB sub PC: hostpc
test descr - CONTROLLER AT csr - RUNTIME hh:mm:ss
ERROR LOG RECEIVED - HOST MEMORY ACCESS ERROR
HOST MEMORY ADDRESS: xxxxxx
OPERATION status
STATUS/EVENT CODE: status
MESSAGE BUFFER CONTAINS:
000001 000002 000003 000004 000005 000006 000007
000008 000009 000010 000011 000012 000013 000014
000015 000016 000017 000018 000019 000020 000021
000022 000023 000024 000025 000026 000027 000028
000029 000030 000031 000032 000033 000034 000035
```

This error message indicates that a error log message was received from the controller indicating a host memory access error has occurred. The memory location being accessed is reported in decimal. The 'OPERATION status' line of the message will tell whether the MSCP operation that caused the error is continuing, was successful, or failed. The event code for the message and the error log message are reported to the operator. If the operation failed, a error message of type 00041 will also be printed. Error log messages will only be reported to the operator if the printing of soft error messages is enabled in the software questions. More information on the contents of the error log message can be found in the device's service manual and in the MSCP architectural specification.

5.2.28 00052 - ERROR LOG RECEIVED - DISK TRANSFER ERROR -

```
CZUDJ SFT ERR 00052 ON UNIT unit TST tst SUB sub PC: hostpc
test descr - CONTROLLER AT csr, DRIVE drive - RUNTIME hh:mm:ss
ERROR LOG RECEIVED - DISK TRANSFER ERROR
RETRY COUNT: xx RECOVERY LEVEL: xx
OPERATION status
STATUS/EVENT CODE: status
MESSAGE BUFFER CONTAINS:
000001 000002 000003 000004 000005 000006 000007
000008 000009 000010 000011 000012 000013 000014
000015 000016 000017 000018 000019 000020 000021
000022 000023 000024 000025 000026 000027 000028
000029 000030 000031 000032 000033 000034 000035
```

This error message indicates that a error log message was received from the controller indicating a disk transfer error has occurred.

The retry count and the recovery level are reported in decimal. The 'OPERATION status' line of the message will tell whether the MSCP operation that caused the error is continuing, was successful, or failed. The event code for the message and the error log message are reported to the operator. If the operation failed, a error message of type 00041 will also be printed. Error log messages will only be reported to the operator if the printing of soft error messages is enabled in the software questions. More information on the contents of the error log message can be found in the device's service manual and in the MSCP architectural specification.

5.2.29 00053 - ERROR LOG RECEIVED - SDI ERROR -

```
CZUDJ SFT ERR 00053 ON UNIT unit TST tst SUB sub PC: hostpc
test descr - CONTRLLER AT csp, DRIVE drive - RUNTIME hh:mm:ss
ERROR LOG RECEIVED - SDI ERROR
SDI STATUS (R TO L): xxxxxx xxxxxx xxxxxx xxxxxx xxxxxx xxxxxx
OPERATION status
STATUS/EVENT CODE: status
MESSAGE BUFFER CONTAINS:
000001 000002 000003 000004 000005 000006 000007
000008 000009 000010 000011 000012 000013 000014
000015 000016 000017 000018 000019 000020 000021
000022 000023 000024 000025 000026 000027 000028
000029 000030 000031 000032 000033 000034 000035
```

This error message indicates that a error log message was received from the controller indicating a SDI error has occurred. The 12 byte SDI status is reported as 6 octal words. The low order byte is on the right and the high order byte is on the left. The 'OPERATION status' line of the message will tell whether the MSCP operation that caused the error is continuing, was successful, or failed. The event code for the message and the error log message are reported to the operator. If the operation failed, a error message of type 00041 will also be printed. Error log messages will only be reported to the operator if the printing of soft error messages is enabled in the software questions. More information on the contents of the error log message can be found in the device's service manual and in the MSCP architectural specification.

5.2.30 00054 - ERROR LOG RECEIVED - SMALL DISK ERROR -

```
CZUDJ SFT ERR 00054 ON UNIT unit TST tst SUB sub PC: hostpc
test_descr - CONTROLLER AT ccr, DRIVE drive - RUNTIME hh:mm:ss
ERROR LOG RECEIVED - SMALL DISK ERROR
CYLINDER: xxxxxx
OPERATION status
STATUS/EVENT CODE: status
MESSAGE BUFFER CONTAINS:
000001 000002 000003 000004 000005 000006 000007
000008 000009 000010 000011 000012 000013 000014
000015 000016 000017 000018 000019 000020 000021
000022 000023 000024 000025 000026 000027 000028
000029 000030 000031 000032 000033 000034 000035
```

This error message indicates that a error log message was received from the controller indicating a small disk error has occurred. The cylinder being accessed when the error occurred is reported in decimal. The 'OPERATION status' line of the message will tell whether the MSCP operation that caused the error is continuing, was successful, or failed. The event code for the message and the error log message are reported to the operator. If the operation failed, a error message of type 00041 will also be printed. Error log messages will only be reported to the operator if the printing of soft error messages is enabled in the software questions. More information on the contents of the error log message can be found in the device's service manual and in the MSCP architectural specification.

5.2.31 00060 - AVAILABLE ATTENTION MESSAGE RECEIVED -

```
CZUDJ DVC FTL ERR 00060 ON UNIT unit TST tst SUB sub PC: hostpc
test_descr - CONTROLLER AT ccr, DRIVE drive - RUNTIME hh:mm:ss
AVAILABLE ATTENTION MESSAGE RECEIVED
DRIVE UNDER TEST BECAME UNIT-AVAILABLE
```

This error message indicates that a drive that was selected for testing unexpectedly became 'UNIT-AVAILABLE'. This indicates an unexpected fault in either the controller or the disk drive. This error will result in the drive being dropped from testing.

5.2.32 00061 - DUPLICATE UNIT ATTENTION MESSAGE RECEIVED -

```
CZUDJ DVC FTL ERR 00061 ON UNIT unit TST tst SUB sub PC: hostpc
```

test descr - CONTROLLER AT csr, DRIVE drive - RUNTIME hh:mm:ss
DUPLICATE UNIT ATTENTION MESSAGE RECEIVED
DUPLICATE UNIT NUMBER DETECTED BY CONTROLLER

This error message indicates that the controller detected two or more drives with the same unit number. The controller will disable both drives and the unit will be dropped from testing.

6 PERFORMANCE AND PROGRESS REPORTS

A summary will be printed out whenever one of three conditions are met: the operator CONTROL-C's, then types 'PRINT', a test completes or the time limit between summaries expires.

The exercise summary will consist of a header and two tables, a SUBSYSTEM I/O SUMMARY and a DRIVE ERROR SUMMARY. The header will contain the time and date of the report, and the the elapsed time since the diagnostic was started.

The SUBSYSTEM I/O SUMMARY will contain the following information:

- Controller CSR
- Controller unique identifier
- Drive name
- Drive unique identifier
- Number of bytes written (controller and drive)
- Number of bytes read (controller and drive)
- Number of bytes accessed (drive only)
- Number of bytes that have completed data compares (drive only)
- Number of blocks containing ECC correctable data (drive only)

The DRIVE ERROR SUMMARY consists of the following information:

- Unit number
- Drive name
- Drive media serial number
- Drive status
- Number of hard/device fatal errors
- Number of data check errors
- Number of soft errors

The format for the exercise summary is as follows:

TEST x IN PROGRESS - RUNTIME: hhhh:mm:ss

SUBSYSTEM I/O SUMMARY:

CTRLR CSR	DRIVE NAME	UNIQUE IDENTIFIER	BYTES WRITTEN	BYTES READ	BYTES ACCESSED	BYTES COMPARED	ECC DATA
172150	01 13	1234567890123456	950K	923K			
	DUO 05 02	5678901234567890	456K	26M	456M	258K	0
	DU252 05 02	6543210987654321	456M	28M	456M	128K	1

DRIVE ERROR SUMMARY:

UNIT #	DRIVE NAME	VOLUME SERIAL #	HARD/FATAL ERRORS	DATA CHECK ERRORS	SOFT ERRORS
0	DUO		0	0	0
1	DU252	0000123456 (DROPPED)	1	8	0

Note drive DU252 which has been dropped -- when a drive has been dropped, the operator will always be notified in the summary that the drive has been dropped.

In the "BYTES" fields, if the byte count is from 0 through 999, the field contains the actual number of bytes. If the byte count is from 1000 to 999,999, the byte count indicates the number of kilobytes, which will be designated by a trailing "K". If the byte count is 1,000,000 or higher, the byte count indicates the number of megabytes, which will be designated by a trailing "M".

If the operator requested an interval between summaries, the interval is measured from the last summary. For example, if a 15 minute interval is selected between summaries, and at 14 minutes the operator CONTROL-C's then types SUMMARY, the next summary will not occur for 15 more minutes.

7 GLOSSARY

"CIS"

Commercial Instruction Set. An extension to the standard PDP-11 instruction set designed to increase string manipulation performance.

"EIS"

Extended Integer Instructions. An extension to the standard PDP-11 instruction set designed to improve the performance of certain integer math functions. The instructions are ASH, ASHC, DIV, and MUL.

"FRU"

Field Replaceable Unit. The smallest element of a device under test that can be replaced in the field to resolve a device problem.

"IP Register"

The IP register is one of two I/O page registers used for communication between the host and the controller. The IP register allows the host to initiate a controller initialization and allows the host to initiate polling by the controller.

"LBN"

Logical Block Number. Address of a sector on a disk drive where the LBN can be in the range 0 - (number_of_sectors_on_drive - 1).

"MSCP"

Mass Storage and Control Protocol. This is a protocol that is used by a host processor to communicate with a disk controller to perform disk I/O operations and I/O control functions.

"Revectored Sector"

A sector that was found to be bad by either the surface checker in manufacturing, the SDI formatter during formatting, or a disk drive controller during normal use. The sector is marked as bad, and a good sector assigned to replace it.

"SA Register"

One of two I/O page registers used for communication between the controller and the host. The SA register is used by the controller to provide data, status, and error information to the host. It is also used by the host to provide parameter information and bus adaptor purge status to the controller.

"SDI"

Standard Disk Interface. The interface between the disk controller and the disk drive. The SDI defines the physical connection (SI), protocol and functions that can be performed using the connection.

"SI"

Storage Interconnect. One of four physical connections from a disk controller to a disk drive.

"Targeted Unit Under Test"

The smallest unit farthest away from the processor to which a diagnostic can be directed.

"UQSSP"

UNIBUS/QBUS Storage Systems Port. UQSSP defines the initialization sequence for the controller and the transport mechanism for the MSCP and DUP messages passed between the host and the controller over the UNIBUS or Q-BUS.

APPENDIX A
DRS COMMAND SUMMARY

DRS COMMANDS

Only the first three letters are needed for each command, the rest of the letters are ignored. This is shown above by lower case letters. The description above is intended to be an introduction only, for a detailed description of these commands, see the XXDP+/SUPR USERS MANUAL CHQUS??.

StArt	start the diagnostic and initialize
REStArt	start the diagnostic and do not initialize
CONtinue	continue diagnostic at test that was interrupted by a tC
PRoceed	continue from an error halt
ADD	activate a unit for testing
DRoP	deactivate a unit
DISplay	print a list of device information
rLAGs	print status of all flags
ZFLags	reset all flags
PRInt	print statistical information
EXIt	return to XXDP+ runtime monitor
REDirect	redirect output to specified device

DRS COMMAND SWITCHES

/TES:test-list	execute only the tests specified
/PAS:dddd	execute dddd passes (dddd = 1 to 64000)
/FLA:flag-list	set specified flags
/EOP:dddd	report end of pass after each dddd passes (dddd = 1 to 64000)
- /UNI:unit-list	command will affect only specified units

DRS COMMAND SUMMARY

Page A-2

/DEV:device device to which output is re-directed
/LPT redirect output to lineprinter

DRS FLAGS

HOE	halt on error - control is returned to DRS
LOE	loop on error
IER	inhibit all error reports
IBE	inhibit all error reports except first level (first level contains error type, number, PC, test and unit)
IXE	inhibit extended error reports (those called by PRINTX)
PRI	direct messages to line printer
PNT	print test number as test executes
BOE	"bell" on error
UAM	unattended mode (no manual intervention)
ISR	inhibit statistical reports
IDR	inhibit program dropping of units
ADR	execute autodrop code
LOT	loop on test
EVL	execute evaluation on error

APPENDIX B

SA REGISTER ERROR CODE SUMMARY (OCTAL)

- 100001 - Envelope/Packet read error (parity or timeout)
- 100002 - Envelope/Packet write error (parity or timeout)
- 100003 - Controller ROM and RAM parity error
- 100004 - Controller RAM parity error
- 100005 - Controller ROM parity error
- 100006 - Ring read error (parity or timeout)
- 100007 - Ring write error (parity or timeout)
- 100010 - Interrupt master failure
- 100011 - Host access timeout
- 100012 - Credit limit exceeded
- 100013 - Q-bus master error
- 100014 - Diagnostic controller fatal error
- 100015 - Instruction Loop timeout
- 100016 - Illegal virtual circuit ID
- 100017 - Interrupt write error
- 100020 - Maintenance read/write invalid region identifier
- 100021 - Maintenance write load to non-loadable controller
- 100022 - Controller RAM error (non-parity)
- 100023 - INIT sequence error
- 100024 - High-level protocol incompatibility error
- 100025 - Purge/poll hardware failure
- 100026 - Mapping register read error (parity or timeout)
- 100027 - Mapping option unsupported
- 104000 - Fatal sequencer error
- 104040 - D PROC ALU test error
- 104041 - D PROC ROM parity test error / Timeout test error
- 105102 - D PROC no board 2 error / D PROC control reg test error /
D PROC RAM parity error
- 105105 - D PROC RAM buffer error
- 105152 - D PROC SDI error
- 105153 - D PROC write mode, wrap SERDES 16 error
- 105154 - D PROC read mode, SERDES 16, 10 RSGEN and ECC circuitry error

SA REGISTER ERROR CODE SUMMARY (OCTAL)

Page B-2

106040 - U PROC ALU test error / DFAIL test error / Unexpected trap error
106041 - U PROC control reg test error
106042 - U PROC parity error set erroneously / CROM parity test error
106055 - Unexpected trap - abnormal termination of diagnostics
106071 - U PROC Log/Antilog RAM checksum error
106072 - U PROC ROM parity test error
106200 - STEP 1 data error (MSB wasn't set)
107103 - U PROC RAM parity error
107107 - U PROC RAM buffer error
112300 - STEP 2 INIT error
122300 - STEP 3 INIT error
122240 - DMA test error
142300 - STEP 4 INIT error

APPENDIX C
TEST DATA PATTERNS

In order for CZUDJO to be able to perform a data compare on a sector read, it must be able to determine the pattern that was written in the sector. If the sector was not previously written by CZUDJO, the standard diagnostic data patterns must have been written to the disk by a previously run diagnostic.

Following is a list of the data patterns used by CZUDJO in the read and write subtests. Each of the data patterns is preceded by one word that contains the pattern number replicated four times. The data patterns will be replicated throughout remaining words in the sector.

- PATTERN 0 This pattern number is used to indicate any pattern number 1 to 16 chosen at random.
- PATTERN 1 Words in pattern sequence - 1
Sequence (octal) 105613
Sequence (binary) 1000101110001011
- PATTERN 2 Words in pattern sequence - 1
Sequence (octal) 31463
Sequence (binary) 0011001100110011
- PATTERN 3 Words in pattern sequence - 1
Sequence (octal) 30221
Sequence (binary) 0011000010010001

TEST DATA PATTERNS

PATTERN 4 Words in pattern sequence - 16 (shifting ones)

Sequence (octal) 000001, 000003, 000007, 000017,
000037, 000077, 000177, 000377,
000777, 001777, 003777, 007777,
017777, 037777, 077777, 177777

Sequence (binary) 0000000000000001
0000000000000011
0000000000000111
0000000000001111
0000000000011111
0000000000111111
0000000001111111
0000000011111111
0000000111111111
0000001111111111
0000011111111111
0000111111111111
0001111111111111
0011111111111111
0111111111111111
1111111111111111

PATTERN 5 Words in pattern sequence - 16 (shifting zeros)

Sequence (octal) 177776, 177774, 177770, 177760,
177740, 177700, 177600, 177400,
177000, 176000, 174000, 170000,
160000, 140000, 100000, 000000

Sequence (binary) 1111111111111110
1111111111111100
1111111111111000
1111111111110000
1111111111100000
1111111111000000
1111111110000000
1111111100000000
1111110000000000
1111100000000000
1111000000000000
1110000000000000
1100000000000000
1000000000000000

TEST DATA PATTERNS

Page C-3

0000000000000000

PATTERN 6 Words in pattern sequence - 16 (3-2-1-1-1)

Sequence (octal) 000000, 000000, 000000, 177777,
177777, 177777, 000000, 000000,
177777, 177777, 000000, 177777,
000000, 177777, 000000, 177777

Sequence (binary) 0000000000000000
0000000000000000
0000000000000000
1111111111111111
1111111111111111
1111111111111111
1111111111111111
0000000000000000
0000000000000000
1111111111111111
1111111111111111
0000000000000000
1111111111111111
0000000000000000
1111111111111111
0000000000000000
1111111111111111

PATTERN 7 Words in pattern sequence - 1

Sequence (octal) 133331
Sequence (binary) 1011011011011001

PATTERN 8 Words in pattern sequence - 16 (3-2-1-1-1)

Sequence (octal) 052525, 052525, 052525, 125252,
125252, 125252, 052525, 052525,
125252, 125252, 052525, 125252,
052525, 125252, 052525, 125252

Sequence (binary) 0101010101010101
0101010101010101
0101010101010101
1010101010101010
1010101010101010
1010101010101010
0101010101010101
0101010101010101

TEST DATA PATTERNS

Page C-4

1010101010101010
1010101010101010
0101010101010101
1010101010101010
0101010101010101
1010101010101010
0101010101010101
1010101010101010

PATTERN 9 Words in pattern sequence - 1

Sequence (octal) 155554

Sequence (binary) 1101101101101100

PATTERN 10 Words in pattern sequence - 16 (3-2-1-1-1)

Sequence (octal) 026455, 026455, 026455, 151322,
151322, 151322, 026455, 026455,
151322, 151322, 026455, 151322,
026455, 151322, 026455, 151322

Sequence (binary) 0010110100101101
0010110100101101
0010110100101101
1101001011010010
1101001011010010
1101001011010010
0010110100101101
0010110100101101
1101001011010010
1101001011010010
0010110100101101
1101001011010010
0010110100101101
1101001011010010
0010110100101101
1101001011010010

PATTERN 11 Words in pattern sequence - 1

Sequence (octal) 066666

Sequence (binary) 0110110110110110

PATTERN 12 Words in pattern sequence - 16 (ripple one)

TEST DATA PATTERNS

Page C-6

Sequence (octal) 155555,133333,155555

Sequence (binary) 1101101101101101
1011011011011011
1101101101101101

PATTERN 15 Words in pattern sequence - 3

Sequence (octal) 155555,133333,066666

Sequence (binary) 1101101101101101
1011011011011011
0110110110110110

PATTERN 16 This is the operator selectable data pattern.
See the TEST 2 SOFTWARE QUESTIONS section for more
information. As a default, when the program is
started pattern 16 is defined at 1 word of zeroes.

Words in default pattern sequence - 1 (zeroes)

Sequence (octal) 000000

Sequence (binary) 0000000000000000

8

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21

.NLIST BEX,CND
.SBTTL REVISION HISTORY

;++
: REVISION HISTORY:
: REV. A0 - JFM - 2-OCT-85
: THIS PROGRAM IS A PDP-11 DISK SUBSYSTEM EXERCISER DESIGNED TO
: EXERCISE ANY KDA50-Q OR UDA50-A DISK SUBSYSTEM RESIDING ON A
: PDP-11 SYSTEM. THIS IS THE ORIGINAL VERSION OF THIS PROGRAM.
:--

;++
: CONDITIONAL ASSEMBLY FLAGS
:--

000001
000000
000000
002000

DEBUG=1 ; 1-DEBUG MODE
: .ASECT
: .ENABL AMA ; THIS IS USED WITH LINKER
: .ENABL ABS,AMA ; USE THIS WITHOUT LINKER
: = 2000
:

23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77

```
.SBTTL MACRO DEFINITION SECTION

:++
:   PUSH - PUT DATA ON THE STACK
:
:   ARGUMENTS:
:       A - DATA TO BE PUT ON THE STACK
:--

.MACRO PUSH A
.IRP B,<A>
MOV B,-(SP) ; PUSH B ON STACK
.ENDM
.ENDM PUSH

:++
:   POP - REMOVE DATA FROM THE STACK
:
:   ARGUMENTS:
:       A - LOCATION TO PUT THE DATA REMOVED FROM THE STACK
:--

.MACRO POP A
.IRP B,<A>
MOV (SP)+,B ; POP STACK INTO B
.ENDM
.ENDM POP

:++
:   ASSUME - CHECK VALIDITY OF PROGRAM ASSUMPTIONS
:--
.MACRO ASSUME FIRST,CONDITION,SECOND
.IF CONDITION <FIRST>--<SECOND>
.IFF
.ERROR ;BAD ASSUME OF <FIRST> CONDITION <SECOND>
.ENDC
.ENDM ASSUME

:++
:   MACRO DEFINITIONS FOR GLOBAL EQUATES
:
:   THESE MACROS ARE USED TO DEFINE INDICES INTO A TABLE
:
:   CALLING SEQUENCE MUST BE
:
:       TABLE
:       ITEM NAME BYTES COMMENT
:       ITEM NAME BYTES COMMENT
:       ITEM NAME BYTES COMMENT
:       END SIZE
:
:   TABLE - DESIGNATES THAT A TABLE IS ABOUT TO BE DEFINED.
:   END - TERMINATES THE DEFINITION.
:   ITEM - ENTRY IN THE TABLE. ANY NUMBER OF ITEM LINES CAN APPEAR.
:   NAME - THE NAME OF THE SYMBOL BEING EQUATED TO THE INDEX. THE INDEX
```

```
78      :
79      : ALWAYS STARTS AT ZERO.
80      : BYTES - THE SIZE OF THE VALUE TO BE STORED AT THAT INDEX IN BYTES.
81      : SIZE - (OPTIONAL) THE SIZE OF THE TABLE IN BYTES.
82      : TINDEX - KEEPS TRACK OF THE INDEX VALUE AND WILL BE EQUAL TO THE SIZE
83      : OF THE TABLE AFTER THE END STATEMENT.
84      :--
85      .MACRO TABLE
86      TINDEX = 0
87      .ENDM TABLE
88
89      .MACRO ITEM NAME BYTES COMMENT
90      NAME=TINDEX ;COMMENT
91      TINDEX=TINDEX+BYTES
92      .ENDM ITEM
93
94      .MACRO END SIZE COMMENT
95      .IF NB SIZE
96      SIZE=TINDEX ;COMMENT
97      .ENDC
98      .ENDM END
99
```

```

101          .SBTTL PROGRAM HEADER
102
103          .MCALL SVC
104 002000          SVC          ; INITIALIZE SUPERVISOR MACROS
105
106          ;++
107          ; IF STRUCTURED MACROS ARE TO BE USED, ".MCALL STRUCT" AND "STRUCT"
108          ; MUST BE ADDED TO INITIALIZE THE STRUCTURED MACROS.
109
110          000000          SVCINS= 0          ; LIST INSTRUCTIONS, SHIFTED RIGHT
111          000000          SVCTST= 0         ; LIST TEST TAGS, SHIFTED RIGHT
112          000000          SVCSUB= 0        ; LIST SUBTEST TAGS, SHIFTED RIGHT
113          000000          SVCGBL= 0        ; LIST GLOBAL TAGS, SHIFTED RIGHT
114          000000          SVCTAG= 0        ; LIST OTHER TAGS, SHIFTED RIGHT
115
116          ; THE VALUES OF THE SVC... SYMBOLS ARE ZERO TO ALIGN THE MACRO CALLS
117          ; AND THEIR EXPANSIONS. SETTING THE SYMBOLS TO BE MINUS-ONE WILL CAUSE
118          ; THE EXPANSIONS TO NOT BE LISTED. THE SYMBOLS MAY BE CHANGED AT ANY
119          ; POINT IN THE PROGRAM.
120          ;--
121
122          ;++
123          ; THE PROGRAM HEADER IS THE INTERFACE BETWEEN
124          ; THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
125          ;
126          ; THE FOLLOWING ARE THE OPTIONAL 'HEADER' ARGUMENTS:
127          ;
128          ; ARGUMENT          OPTION
129          ; -----          -----
130          ; BGNRPT          REPORT CODE
131          ; BGNSW          SOFTWARE TABLE
132          ; BGNSFT          SOFTWARE TABLE QUESTIONS
133          ; BGNAU          ADD UNIT CODE
134          ; BGNDU          DROP UNIT CODE
135          ; ERRTABL        ERROR TABLE
136          ; BGNSETUP       ASSEMBLED P-TABLES
137          ; ALL            ALL OF THE ABOVE
138          ; NONE           NONE OF THE ABOVE
139          ;--
140
141 002000          POINTER ALL
142
143          ;++
144          ; THE "HEADER" ARGUMENTS ARE: NAME, REV, PATCH, LONGEST TEST
145          ; TIME, TYPE, PRIORITY, RESTORE, AND XM.
146          ; "TYPE" = 0 FOR SEQUENTIAL DIAGNOSTIC AND = 1 FOR EXERCISER.
147          ; "PRIORITY" INITIAL PROCESSOR PRIORITY OF THE DIAGNOSTIC (DEFAULT IS 0).
148          ; "RESTORE" = 0 TO RESTORE XM AND = 1 NOT TO RESTORE XM.
149          ; "XM" = 0 FOR SMALL MONITOR AND = 1 FOR EXTENDED MONITOR.
150          ;--
151
152 002000          L$NAME: HEADER CZUDJ,A,0,0,1,PRI07,1,1          ; TEST 5
          002000          ;DIAGNOSTIC NAME
          002000          .ASCII /C/
          002001          .ASCII /Z/
          103
          132

```

002002	125	.ASCII	/U/	
002003	104	.ASCII	/D/	
002004	112	.ASCII	/J/	
002005	000	.BYTE	0	
002006	000	.BYTE	0	
002007	000	.BYTE	0	
002010		L\$REV::		;REVISION LEVEL
002010	101	.ASCII	/A/	
002011		L\$DEPO::		;0
002011	060	.ASCII	/O/	
002012		L\$UNIT::		;NUMBER OF UNITS
002012	000001	.WORD	T\$PTHV	
002014		L\$TIML::		;LONGEST TEST TIME
002014	000000	.WORD	0	
002016		L\$HPCP::		;POINTER TO H.W. QUES.
002016	065214	.WORD	L\$HARD	
002020		L\$SPCP::		;POINTER TO S.W. QUES.
002020	065344	.WORD	L\$SOFT	
002022		L\$HPTP::		;PTR. TO DEF. H.W. PTABLE
002022	002134	.WORD	L\$HW	
002024		L\$SPTP::		;PTR. TO S.W. PTABLE
002024	002144	.WORD	L\$SW	
002026		L\$LADP::		;DIAG. END ADDRESS
002026	066462	.WORD	L\$LAST	
002030		L\$STA::		;RESERVED FOR APT STATS
002030	000000	.WORD	0	
002032		L\$CO::		
002032	000000	.WORD	0	
002034		L\$DTYP::		;DIAGNOSTIC TYPE
002034	000001	.WORD	1	
002036		L\$APT::		;APT EXPANSION
002036	000000	.WORD	0	
002040		L\$DTP::		;PTR. TO DISPATCH TABLE
002040	002124	.WORD	L\$DISPATCH	
002042		L\$PRIO::		;DIAGNOSTIC RUN PRIORITY
002042	000340	.WORD	PRI07	
002044		L\$ENVI::		;FLAGS DESCRIBE HOW IT WAS SETUP
002044	000000	.WORD	0	
002046		L\$EXP1::		;EXPANSION WORD
002046	000000	.WORD	0	
002050		L\$MREV::		;SVC REV AND EDIT
002050	004	.BYTE	C\$REVISION	
002051	001	.BYTE	C\$EDIT	
002052		L\$EF::		;DIAG. EVENT FLAGS
002052	000000	.WORD	0	
002054	000000	.WORD	0	
002056		L\$SPC::		
002056	000000	.WORD	0	
002060		L\$DEVP::		; POINTER TO DEVICE TYPE LIST
002060	007142	.WORD	L\$DVTYP	
002062		L\$REPP::		;PTR. TO REPORT CODE
002062	054534	.WORD	L\$RPT	
002064		L\$EXP4::		
002064	000000	.WORD	0	
002066		L\$EXP5::		

002066	000000				
002070	062634	L\$AUT::	.WORD	0	;PTR. TO ADD UNIT CODE
002072		L\$DUT::	.WORD	L\$AU	;PTR. TO DROP UNIT CODE
002072	062632	L\$DUT::	.WORD	L\$DU	;PTR. TO DROP UNIT CODE
002074		L\$LUN::	.WORD	0	;LUN FOR EXERCISERS TO FILL
002074	000000	L\$DESP::	.WORD	0	;PTR. TO DIAG. DESCRIPTION
002076		L\$DESP::	.WORD	L\$DESC	;PTR. TO DIAG. DESCRIPTION
002076	007162	L\$LOAD::	.WORD	L\$DESC	;GENERATE SPECIAL AUTOLOAD EMT
002100		L\$LOAD::	EMT	E\$LOAD	;GENERATE SPECIAL AUTOLOAD EMT
002100	104035	L\$ETP::			;PTR. TO ERRRTBL
002102		L\$ETP::	.WORD	L\$ERRTBL	;PTR. TO ERRRTBL
002102	002156	L\$ICP::	.WORD	L\$INIT	;PTR. TO INIT CODE
002104		L\$ICP::	.WORD	L\$INIT	;PTR. TO INIT CODE
002104	060364	L\$CCP::	.WORD	L\$INIT	;PTR. TO CLEAN-UP CODE
002106		L\$CCP::	.WORD	L\$CLEAN	;PTR. TO CLEAN-UP CODE
002106	062612	L\$ACP::	.WORD	L\$CLEAN	;PTR. TO CLEAN-UP CODE
002110		L\$ACP::	.WORD	L\$AUTO	;PTR. TO AUTO CODE
002110	062610	L\$PRT::	.WORD	L\$AUTO	;PTR. TO AUTO CODE
002112		L\$PRT::	.WORD	L\$PROT	;PTR. TO PROTECT TABLE
002112	060356	L\$TEST::	.WORD	L\$PROT	;PTR. TO PROTECT TABLE
002114		L\$TEST::	.WORD	3	; TEST NUMBER
002114	000003	L\$DLY::	.WORD	3	; TEST NUMBER
002116		L\$DLY::	.WORD	0	;DELAY COUNT
002116	000000	L\$HIME::	.WORD	0	;DELAY COUNT
002120		L\$HIME::	.WORD	0	;PTR. TO HIGH MEM
002120	000000	L\$HIME::	.WORD	0	;PTR. TO HIGH MEM

155
156
157
158
159
160
161
162
163
164
165

.SBTTL DISPATCH TABLE

;++
;
; THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.
; IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST. THE
; ARGUMENT OF 'DISPATCH' INDICATES THE NUMBER OF HARDWARE TESTS
; IN THE DIAGNOSTIC.
;--

002122
002122 000003
002124
002124 062636
002126 063212
002130 063304

DISPATCH 3
.WORD 3
L\$DISPATCH::
.WORD T1
.WORD T2
.WORD T3


```
167 .SBTTL DEFAULT HARDWARE P-TABLE
168
169 :++
170 : THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
171 : THE TEST-DEVICE PARAMETERS. THE STRUCTURE OF THIS TABLE
172 : IS IDENTICAL TO THE STRUCTURE OF THE HARDWARE P-TABLES,
173 : AND IS USED AS A "TEMPLATE" FOR BUILDING THE P-TABLES.
174 : THE ACTUAL P-TABLE BUILT AT RUN TIME IS STORED IN SUPERVISOR
175 : SPACE.
176 :--
177
178 002132 BGNHW DFPTBL
    002132 .WORD L10000-L$HW/2
    002134 L$HW::
    002134 DFPTBL::

179
180 002134 172150 .WORD 172150 ; CONTROLLER CSR ADDRESS
181 002136 000000 .WORD 0. ; DRIVE PLUG NUMBER
182 002140 000000 .WORD 0. ; WRITE ON DRIVE (0=NO)
183
184 002142 ENDHW
    002142 L10000:
```

```
186 .SBTTL SOFTWARE P-TABLE
187
188 :++
189 : THE SOFTWARE TABLE CONTAINS VARIOUS DATA USED BY THE
190 : PROGRAM AS OPERATIONAL PARAMETERS. THESE PARAMETERS ARE
191 : SET UP AT ASSEMBLY TIME AND MAY BE VARIED BY THE OPERATOR
192 : AT RUN TIME. THIS TABLE, UNLIKE THE HARDWARE TABLE, WILL CONTAIN
193 : THE ACTUAL VALUES ENTERED BY THE OPERATOR.
194 :--
195
196 002142 BGNSW SFPTBL
002142 000005 .WORD L10001-L$SW/2
002144 L$SW::
002144 SFPTBL::

197
198 002144 000001 .WORD 1. ; HARD ERROR LIMIT
199 002146 000074 .WORD 60. ; EXERCISER TIME LIMIT
200 002150 000017 .WORD 15. ; MINUTES BETWEEN REPORTS
201 002152 000010 .WORD 8. ; MAXIMUM TRANSFER SIZE IN BLOCKS
202 002154 000764 .WORD †80000000111110100 ; SINGLE BIT QUESTIONS
203
204 002156 ENDSW
002156 L10001:
205
```

207
208
209
210
211
212
213
214 002156

.SBTTL GLOBAL EQUATES SECTION

;++
: THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT
: ARE USED IN MORE THAN ONE TEST.
:--

EQUALS

:
: BIT DIFINITIONS

100000	BIT15== 100000
040000	BIT14== 40000
020000	BIT13== 20000
010000	BIT12== 10000
004000	BIT11== 4000
002000	BIT10== 2000
001000	BIT09== 1000
000400	BIT08== 400
000200	BIT07== 200
000100	BIT06== 100
000040	BIT05== 40
000020	BIT04== 20
000010	BIT03== 10
000004	BIT02== 4
000002	BIT01== 2
000001	BIT00== 1

001000	BIT9== BIT09
000400	BIT8== BIT08
000200	BIT7== BIT07
000100	BIT6== BIT06
000040	BIT5== BIT05
000020	BIT4== BIT04
000010	BIT3== BIT03
000004	BIT2== BIT02
000002	BIT1== BIT01
000001	BIT0== BIT00

:
: EVENT FLAG DEFINITIONS
: EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION

000040	EF.START== 32.	: BIT POSITION IN SECOND STATUS WORD
000037	EF.RESTART== 31.	: (100000) START COMMAND WAS ISSUED
000036	EF.CONTINUE== 30.	: (040000) RESTART COMMAND WAS ISSUED
000035	EF.NEW== 29.	: (020000) CONTINUE COMMAND WAS ISSUED
000034	EF.PWR== 28.	: (010000) A NEW PASS HAS BEEN STARTED
000033	EF.XM== 27.	: (004000) A POWER-FAIL/POWER-UP OCCURRED
		: (002000) DIAG IS GOOD OF EXTENDED ENVIROMENT

:
: PRIORITY LEVEL DEFINITIONS

000340	PRI07== 340
000300	PRI06== 300

000240	PRI05== 240
000200	PRI04== 200
000140	PRI03== 140
000100	PRI02== 100
000040	PRI01== 40
000000	PRI00== 0
	;
	OPERATOR FLAG BITS
	;
000004	EVL== 4
000010	LOT== 10
000020	ADR== 20
000040	IDU== 40
000100	ISR== 100
000200	UAM== 200
000400	BOE== 400
001000	PNT== 1000
002000	PRI== 2000
004000	IXE== 4000
010000	IBE== 10000
020000	IER== 20000
040000	LOE== 40000
100000	HOE== 100000

220

```

222      .SBTTL  CONTROLLER BIT DEFINITIONS
223
224      ;
225      ;      SA REGISTER UNIVERSAL READ BITS
226      ;
227      100000  SA.ERR  = 100000      ; ERROR INDICATOR
228      040000  SA.S4   = 040000      ; STEP 4 STATUS BIT
229      020000  SA.S3   = 020000      ; STEP 3 STATUS BIT
230      010000  SA.S2   = 010000      ; STEP 2 STATUS BIT
231      004000  SA.S1   = 004000      ; STEP 1 STATUS BIT
232      ;
233      ;      SA REGISTER ERROR STATUS BITS
234      ;
235      003777  SA.ERC  = 003777      ; ERROR CODE
236      ;
237      ;      SA REGISTER STEP 1 SEND BITS
238      ;
239      000177  SA.VEC  = 000177      ; INTERRUPT VECTOR (DIVIDED BY 4)
240      000200  SA.INT  = 000200      ; INTERRUPT ENABLE DURING INIT
241      003400  SA.MSG  = 003400      ; MESSAGE RING LENGTH
242      034000  SA.CMD  = 034000      ; COMMAND RING LENGTH
243      040000  SA.WRP  = 040000      ; WRAP BIT
244      100000  SA.STP  = 100000      ; STEP - MUST ALWAYS BE WRITTEN A ONE
245      ;
246      000400  SA.MS1  = 000400      ; LSB OF MESSAGE RING LENGTH
247      004000  SA.CM1  = 004000      ; LSB OF COMMAND RING LENGTH
248      ;
249      ;      SA REGISTER STEP 1 RESPONSE BITS
250      ;
251      002000  SA.NV   = 002000      ; NON SETTABLE INTERRUPT VECTOR
252      001000  SA.QB   = 001000      ; 22 BIT ADDRESS BUS
253      000400  SA.JI   = 000400      ; ENHANCED DIAGNOSTICS
254      000100  SA.MP   = 000100      ; MAPPING BIT
255      000040  SA.SM   = 000040      ; SPECIAL MODE BIT FOR KDA50-Q
256      ;      000377      ; THESE BITS RESERVED
257      ;
258      ;      SA REGISTER STEP 2 SEND BITS
259      ;
260      000001  SA.PRG  = 000001      ; ENABLE VAX UBA PURGE INTERRUPT
261      ;      177776      ; LOW ORDER MESSAGE RING BYTE ADDRESS
262      ;
263      ;      SA REGISTER STEP 2 RESPONSE BITS
264      ;
265      000007  SA.MSE  = 000007      ; MESSAGE RING LENGTH ECHO
266      000070  SA.CME  = 000070      ; COMMAND RING LENGTH ECHO
267      ;      000100      ; RESERVED
268      000200  SA.STE  = 000200      ; STEP ECHO
269      003400  SA.CTP  = 003400      ; CONTROLLER TYPE
270      ;
271      ;      SA REGISTER STEP 3 SEND BITS
272      ;
273      ;      077777      ; HIGH ORDER MESSAGE RING BYTE ADDRESS
274      100000  SA.TST  = 100000      ; PURGE POLL TEST ENABLE
275      ;
276      ;      SA REGISTER STEP 3 RESPONSE BITS
    
```

```
277
278      000177      ; SA.VCE = 000177      ; INTERRUPT VECTOR ECHO
279      000200      ; SA.INE = 000200      ; INTERRUPT ENABLE ECHO
280      000400      ; SA.NVE = 000400      ; VECTOR NOT PROGRAMMABLE
281      ;           ;           003000      ; RESERVED
282      ;
283      ;           SA REGISTER STEP 4 SEND BITS
284      ;
285      000001      ; SA.GO  = 000001      ; GO BIT TO START CONTROLLER FIRMWARE
286      000002      ; SA.LFC = 000002      ; LAST FAILURE CODE REQUEST
287      000374      ; SA.BST = 000374      ; BURST LEVEL
288      ;
289      ;           SA REGISTER STEP 4 RESPONSE BITS
290      ;
291      000017      ; SA.MCV = 000017      ; CONTROLLER MICROCODE VERSION
292      000360      ; SA.CNT = 000360      ; CONTROLLER TYPE
293      ;           ;           003400      ; RESERVED
```

```
295          .SBITL  HOST COMMUNICATION AREA DEFINIIONS
296
297          :
298          :      COMMAND/MESSAGE RING BIT DEFINITIONS
299          :
300          100000  RG.OWN  = 100000          ; SET WHEN CONTROLLER OWNS RING
301          040000  RG.FLG  = 040000          ; FLAG BIT
302          :
303          :      CONNECTION ID & MESSAGE TYPE NUMBERS
304          :
305          000000  DISK    = 0              ; 0 - DISK CIRCUIT, SEQUENTIAL MSG
306          000400  TAPE    = 400           ; 1 - TAPE CIRCUIT, SEQUENTIAL MSG
307          001000  DUP     = 1000          ; 2 - DUP CIRCUIT, SEQUENTIAL MSG
308          177760  MAINT   = 177760       ; 177760 - MAINT. CIRCUIT, MAINT. MSG
```

```

310 .SBTTL COMMAND PACKET OPCODES DEFINITIONS
311
312 ;**
313 ; NOTE: END PACKET OPCODES (ALSO CALLED ENDCODES) ARE FORMED BY ADDING
314 ; THE END PACKET FLAG TO THE COMMAND OPCODE. FOR EXAMPLE, A READ
315 ; COMMAND'S END PACKET CONTAINS THE VALUE OP.RD+OP.END IN ITS OPCODE
316 ; FIELD. THE INVALID COMMAND END PACKET CONTAINS JUST THE END PACKET
317 ; FLAG (I.E., OP.END) IN ITS OPCODE FIELD. THE SERIOUS EXCEPTION END
318 ; PACKET CONTAINS THE SUM OF THE END PACKET FLAG PLUS THE SERIOUS
319 ; EXCEPTION OPCODE SHOWN ABOVE (I.E., OP.SEX+OP.END) IN ITS OPCODE FIELD.
320 ;
321 ; COMMAND OPCODE BITS 3 THROUGH 5 INDICATE THE COMMAND CLASS, WHICH IS
322 ; ENCODED AS FOLLOWS:
323 ; 000 IMMEDIATE COMMANDS
324 ; 001 SEQUENTIAL COMMANDS
325 ; 010 NON-SEQUENTIAL COMMANDS THAT DO NOT INCLUDE A BUFFER DESCRIPTOR
326 ; 100 NON-SEQUENTIAL COMMANDS THAT DO INCLUDE A BUFFER DESCRIPTOR
327 ;--
328
329 000001 OP.ABO = 01 ; ABORT COMMAND
330 000020 OP.ACC = 20 ; ACCESS COMMAND
331 000010 OP.AVL = 10 ; AVAILABLE COMMAND
332 000021 OP.CCD = 21 ; COMPARE CONTROLLER DATA COMMAND
333 000040 OP.CMP = 40 ; COMPARE HOST DATA COMMAND
334 000013 OP.DAP = 13 ; DETERMINE ACCESS PATHS COMMAND
335 000022 OP.ERS = 22 ; ERASE COMMAND
336 000023 OP.FLU = 23 ; FLUSH COMMAND
337 000002 OP.GCS = 02 ; GET COMMAND STATUS COMMAND
338 000003 OP.GUS = 03 ; GET UNIT STATUS COMMAND
339 000011 OP.ONL = 11 ; ONLINE COMMAND
340 000041 OP.RD = 41 ; READ COMMAND
341 000024 OP.RPL = 24 ; REPLACE COMMAND
342 000004 OP.SCC = 04 ; SET CONTROLLER CHARACTERISTICS COMMAND
343 000012 OP.SUC = 12 ; SET UNIT CHARACTERISTICS COMMAND
344 000042 OP.WR = 42 ; WRITE COMMAND
345 000030 OP.MRD = 30 ; MAINTENANCE READ COMMAND
346 000031 OP.MWR = 31 ; MAINTENANCE WRITE COMMAND
347 000200 OP.END = 200 ; END PACKET FLAG
348 000007 OP.SEX = 7 ; SERIOUS EXCEPTION END PACKET
349 000100 OP.AVA = 100 ; AVAILABLE ATTENTION MESSAGE
350 000101 OP.DUP = 101 ; DUPLICATE UNIT NUMBER ATTENTION MESSAGE
351 000102 OP.SHC = 102 ; SHADOW COPY COMPLETE ATTENTION MESSAGE
352 ;
353 ; COMMAND MODIFIERS
354 ;
355 020000 MD.CSE = 020000 ; CLEAR SERIOUS EXCEPTION
356 040000 MD.CMP = 040000 ; COMPARE
357 100000 MD.EXP = 100000 ; EXPRESS REQUEST
358 010000 MD.ERR = 010000 ; FORCE ERROR
359 004000 MD.SCH = 004000 ; SUPPRESS CACHING (HIGH SPEED)
360 002000 MD.SCL = 002000 ; SUPPRESS CACHING (LOW SPEED)
361 000100 MD.SEC = 000100 ; SUPPRESS ERROR CORRECTION
362 000400 MD.SER = 000400 ; SUPPRESS ERROR RECOVERY
363 000200 MD.SSH = 000200 ; SUPPRESS SHADOWING
364 000100 MD.WBN = 000100 ; WRITE-BACK (NON-VOLATILE)
  
```


365	000040	MD.WBV = 000040	: WRITE BACK (VOLATILE)
366	000020	MD.SEQ = 000020	: WRITE SHADOW SET ONE UNIT AT A TIME
367	000002	MD.ALL = 000002	: ALL CLASS DRIVERS
368	000001	MD.SPD = 000001	: SPIN-DOWN
369	000001	MD.FEU = 000001	: FLUSH ENTIRE UNIT
370	000002	MD.VOL = 000002	: VOLATILE ONLY
371	000001	MD.NXU = 000001	: NEXT UNIT
372	000001	MD.RIP = 000001	: ALLOW SELF DESTRUCTION
373	000002	MD.IMF = 000002	: IGNORE MEDIA FORMAT ERROR
374	000010	MD.CWB = 000010	: CLEAR WRITE-BACK DATA LOST
375	000004	MD.SWP = 000004	: SET WRITE PROTECT
376	000020	MD.SHU = 000020	: SHADOW UNIT SPECIFIED
377	000001	MD.PRI = 000001	: PRIMARY REPLACEMENT BLOCK
378		:	
379		:	
380		END PACKET FLAGS	
381	000200	EF.BBR = 000200	: BAD BLOCK REPORTED
382	000100	EF.BBU = 000100	: BAD BLOCK UNREPORTED
383	000040	EF.LOG = 000040	: ERROR LOG GENERATED
384	000020	EF.SEX = 000020	: SERIOUS EXCEPTION
385		:	
386		:	
387		CONTROLLER FLAGS	
388	000200	CF.ATN = 000200	: ENABLE ATTENTION MESSAGES
389	000100	CF.MSC = 000100	: ENABLE MISC. ERROR LOG MESSAGES
390	000040	CF.OTH = 000040	: ENABLE OTHER HOST'S ERROR LOG MESSAGES
391	000020	CF.THS = 000020	: ENABLE THIS HOST'S ERROR LOG MESSAGES
392	100000	CF.RPL = 100000	: CNTRLR INITIATED BAD BLOCK REPLACEMENT
393	000002	CF.SHU = 000002	: SHADOWING
394	000001	CF.576 = 000001	: 576 BYTE SECTORS
395		:	
396		:	
397		UNIT FLAGS	
398	000001	UF.CMR = 000001	: COMPARE READS
399	000002	UF.CMW = 000002	: COMPARE WRITES
400	100000	UF.RPL = 100000	: CNTRLR INITIATED BAD BLOCK REPLACEMENT
401	040000	UF.INA = 040000	: INACTIVE SHADOW SET UNIT
402	000200	UF.RMV = 000200	: REMOVABLE MEDIA
403	004000	UF.SCH = 004000	: SUPPRESS CACHING (HIGH SPEED)
404	002000	UF.SCL = 002000	: SUPPRESS CACHING (LOW SPEED)
405	000100	UF.WBN = 000100	: WRITE-BACK (NON-VOLATILE)
406	020000	UF.WPH = 020000	: WRITE PROTECT (HARDWARE)
407	010000	UF.WPS = 010000	: WRITE PROTECT (SOFTWARE OR VOLUME)
408	000004	UF.576 = 000004	: 576 BYTE SECTORS

```

410          .SBTTL  COMMAND PACKET OFFSETS
411
412          ;
413          ;      GENERIC COMMAND PACKET OFFSETS
414          ;
415          000000  P.CRF      = 0.          ; COMMAND REFERENCE NUMBER
416          000004  P.UNIT     = 4.          ; UNIT NUMBER
417          000008  P.OPCD     = 8.          ; OPCODE
418          000012  P.MOD      = 10.         ; MODIFIERS
419          000014  P.BCNT     = 12.         ; BYTE COUNT
420          000020  P.BUFF     = 16.         ; BUFFER DESCRIPTOR
421          000020  P.ADBA     = 16.         ; BASE ADDRESS
422          000022  P.ADEA     = 18.         ; EXTENDED ADDRESS
423          000034  P.LBN      = 28.         ; LOGICAL BLOCK NUMBER
424          ;
425          ;      ABORT AND GET COMMAND STATUS COMMAND PACKET OFFSETS
426          ;
427          000014  P.OTRF     = 12.         ; OUTSTANDING REFERENCE NUMBER
428          ;
429          ;      ONLINE AND SET UNIT CHARACTERISTICS COMMAND PACKET OFFSETS
430          ;
431          000016  P.UNFL     = 14.         ; UNIT FLAGS
432          000034  P.DVPM     = 28.         ; DEVICE DEPENDENT PARAMETERS
433          000040  P.SHUN     = 32.         ; SHADOW UNIT
434          000042  P.CPSP     = 34.         ; COPY SPEED
435          ;
436          ;      REPLACE COMMAND PACKET OFFSETS
437          ;
438          000014  P.RBN      = 12.         ; REPLACEMENT BLOCK NUMBER
439          ;
440          ;      SET CONTROLLER CHARACTERISTICS COMMAND PACKET OFFSETS
441          ;
442          000014  P.VRSN     = 12.         ; MSCP VERSION
443          000016  P.CNTF     = 14.         ; CONTROLLER FLAGS
444          000020  P.HTMO     = 16.         ; HOST TIMEOUT
445          000024  P.TIME     = 20.         ; QUAD-WORD TIME AND DATE
446          ;
447          ;      MAINTENANCE READ AND MAINTENANCE WRITE COMMAND PACKET OFFSETS
448          ;
449          000034  P.RGID     =      28.    ; REGION ID
450          000040  P.RGOF     =      32.    ; REGION OFFSET
  
```

```

452          .SBTTL END PACKET OFFSETS
453
454          ;
455          ;   GENERIC END PACKET OFFSETS
456          ;
457          000000 P.CRF      = 0.          ; COMMAND REFERENCE NUMBER
458          000004 P.UNIT    = 4.          ; UNIT NUMBER
459          000010 P.OPCD    = 8.          ; OPCODE (ALSO CALLED ENDCODE)
460          000011 P.FLGS    = 9.          ; END PACKET FLAGS
461          000012 P.STS     = 10.         ; STATUS
462          000014 P.BCNT    = 12.         ; BYTE COUNT
463          000034 P.FBBK    = 28.         ; FIRST BAD BLOCK
464          ;
465          ;   ABORT AND GET COMMAND STATUS END PACKET OFFSETS
466          ;
467          000014 P.OTHR    = 12.         ; OUTSTANDING REFERENCE NUMBER
468          000020 P.CMST    = 16.         ; COMMAND STATUS
469          ;
470          ;   GET UNIT STATUS END PACKET OFFSETS
471          ;
472          000014 P.MLUN    = 12.         ; MULTI-UNIT CODE
473          000016 P.UNFL    = 14.         ; UNIT FLAGS
474          000024 P.UNTI    = 20.         ; UNIT IDENTIFIER
475          000034 P.MEDI    = 28.         ; MEDIA TYPE IDENTIFIER
476          000040 P.SHUN    = 32.         ; SHADOW UNIT
477          000042 P.SHST    = 34.         ; SHADOW STATUS
478          000044 P.TRKS    = 36.         ; TRACK SIZE
479          000046 P.GRPS    = 38.         ; GROUP SIZE
480          000050 P.CYLS    = 40.         ; CYLINDER SIZE
481          000052 P.USVR    = 42.         ; UNIT SOFTWARE VERSION
482          000053 P.UHVR    = 43.         ; UNIT HARDWARE VERSION
483          000054 P.RCTS    = 44.         ; RCT TABLE SIZE
484          000056 P.RBNS    = 46.         ; RBNS / TRACK
485          000057 P.RCTC    = 47.         ; RCT COPIES
486          ;
487          ;   ONLINE AND SET UNIT CHARACTERISTICS END PACKET AND AVAILABLE
488          ;   ATTENTION MESSAGE OFFSETS
489          ;
490          000014 P.MLUN    = 12.         ; MULTI-UNIT CODE
491          000016 P.UNFL    = 14.         ; UNIT FLAGS
492          000024 P.UNTI    = 20.         ; UNIT IDENTIFIER
493          000034 P.MEDI    = 28.         ; MEDIA TYPE IDENTIFIER
494          000040 P.SHUN    = 32.         ; SHADOW UNIT
495          000042 P.SHST    = 34.         ; SHADOW STATUS
496          000044 P.UNSZ    = 36.         ; UNIT SIZE
497          000050 P.VSER    = 40.         ; VOLUME SERIAL NUMBER
498          ;
499          ;   SET CONTROLLER CHARACTERISTICS END PACKET OFFSETS
500          ;
501          000014 P.VRSN    = 12.         ; MSCP VERSION
502          000016 P.CNTF    = 14.         ; CONTROLLER FLAGS
503          000020 P.CTMO    = 16.         ; CONTROLLER TIMEOUT
504          000022 P.CSVR    = 18.         ; CONTROLLER SOFTWARE VERSION
505          000023 P.CHVR    = 19.         ; CONTROLLER HARDWARE VERSION
506          000024 P.CNTI    = 20.         ; CONTROLLER ID
  
```

```
507
508
509
510      000037
511      000040
512      000000
513      000001
514      000002
515      000003
516      000004
517      000005
518      000006
519      000007
520      000010
521      000011
522      000012
523      000013
524      000037
```

;

;

STATUS AND EVENT CODE DEFINITIONS

;

ST.MSK = 37 ; STATUS / EVENT CODE MASK

ST.SUB = 40 ; SUB-CODE MULTIPLIER

ST.SUC = 0 ; SUCCESS

ST.CMD = 1 ; INVALID COMMAND

ST.ABO = 2 ; COMMAND ABORTED

ST.OFL = 3 ; UNIT-OFFLINE

ST.AVL = 4 ; UNIT-AVAILABLE

ST.MFE = 5 ; MEDIA FORMAT ERROR

ST.WPR = 6 ; WRITE PROTECTED

ST.CMP = 7 ; COMPARE ERROR

ST.DAT = 10 ; DATA ERROR

ST.HST = 11 ; HOST BUFFER ACCESS ERROR

ST.CNT = 12 ; CONTROLLER ERROR

ST.DRV = 13 ; DRIVE ERROR

ST.DIA = 37 ; MESSAGE FROM AN INTERNAL DIAGNOSTIC

```

526          .SBTTL ERROR LOG MESSAGE OFFSETS
527
528          ;
529          ;      ERROR LOG MESSAGE OFFSETS
530          ;
531          000000      L.CRF      =      0.      ; COMMAND REFERENCE NUMBER
532          000004      L.UNIT     =      4.      ; UNIT NUMBER
533          000006      L.SEQ      =      6.      ; SEQUENCE NUMBER
534          000010      L.FMT      =      8.      ; FORMAT
535          000011      L.FLGS     =      9.      ; ERROR LOG MESSAGE FLAGS
536          000012      L.EVNT     =     10.     ; EVENT CODE
537          000014      L.CNTI     =     12.     ; CONTROLLER ID
538          000024      L.CSVR     =     20.     ; CONTROLLER SOFTWARE VERSION
539          000025      L.CHVR     =     21.     ; CONTROLLER HARDWARE VERSION
540          000026      L.MLUN     =     22.     ; MULTI-UNIT CODE
541          000030      L.UNTI     =     24.     ; UNIT ID
542          000030      L.BADR     =     24.     ; BUS ADDRESS
543          000040      L.USVR     =     32.     ; UNIT SOFTWARE VERSION
544          000041      L.UHVR     =     33.     ; UNIT HARDWARE VERSION
545          000042      L.LVL      =     34.     ; LEVEL
546          000042      L.SCYL     =     34.     ; CYLINDER
547          000043      L.RTRY     =     35.     ; RETRY
548          000044      L.VSER     =     36.     ; VOLUME SERIAL NUMBER
549          000050      L.HDCD     =     40.     ; HEADER CODE
550          000054      L.SDI      =     44.     ; SDI INFORMATION
551          ;
552          ;      ERROR LOG FLAGS
553          ;
554          000200      LF.SUC      =     000200   ; OPERATION SUCCESSFUL
555          000100      LF.CON      =     000100   ; OPERATION CONTINUING
556          000001      LF.SNR      =     000001   ; SEQUENCE NUMBER RESET
557          ;
558          ;      SUBCODES FOR ST.SUC
559          ;
560          000040      SC.SPI      =      40      ; SPIN-DOWN IGNORED
561          000100      SC.STC      =     100     ; STILL CONNECTED
562          000200      SC.DUP      =     200     ; DUPLICATE UNIT NUMBER
563          000400      SC.AOL      =     400     ; ALREADY ONLINE
564          001000      SC.SOL      =    1000    ; STILL ONLINE
565          010000      SC.ROV      =   10000    ; READ ONLY (VOLUME FORMAT)
566          ;
567          ;      SUBCODES FOR ST.OFL
568          ;
569          000000      SC.UNK      =      0      ; UNIT UNKNOWN OR ONLINE OTHER CTRLR
570          000040      SC.NVL      =     40     ; NO VOLUME MOUNTED OR DRIVE DISABLED
571          000100      SC.IOP      =    100     ; UNIT INOPERATIVE
572          000400      SC.DIS      =     400     ; UNIT DISABLED BY FIELD SERVICE
573          000200      SC.DUP      =     200     ; DUPLICATE UNIT NUMBER
574          ;
575          ;      SUBCODES FOR ST.MFE
576          ;
577          000240      SC.576      =     240     ; DISK FORMATTED WITH 576 BYTE SECTORS
578          000300      SC.FCT      =     300     ; FCT CORRUPT
579          000400      SC.RCT      =     400     ; RCT CORRUPT
580          000440      SC.RBN      =     440     ; NO RBN AVAILABLE
    
```

```

581
582          ;          SUBCODES FOR ST.WPR
583
584          020000    SC.HWP =          20000      ; UNIT IS HARDWARE WRITE PROTECTED
585          010000    SC.SWP =          10000      ; UNIT IS SOFTWARE WRITE PROTECTED
586
587          ;          SUBCODES FOR ST.DAT
588
589          000000    SC.FOR =           0          ; FORCED ERROR
590          000100    SC.HDR =          100         ; INVALID HEADER
591          000140    SC.DSY =          140         ; DATA SYNC NOT FOUND
592          000200    SC.CEC =          200         ; CORRECTABLE ECC ERROR
593          000340    SC.UEC =          340         ; UNCORRECTABLE ECC ERROR
594          000400    SC.1EC =          400         ; 1 SYMBOL ECC ERROR
595          000440    SC.2EC =          440         ; 2 SYMBOL ECC ERROR
596          000500    SC.3EC =          500         ; 3 SYMBOL ECC ERROR
597          000540    SC.4EC =          540         ; 4 SYMBOL ECC ERROR
598          000600    SC.5EC =          600         ; 5 SYMBOL ECC ERROR
599          000640    SC.6EC =          640         ; 6 SYMBOL ECC ERROR
600          000700    SC.7EC =          700         ; 7 SYMBOL ECC ERROR
601          000740    SC.8EC =          740         ; 8 SYMBOL ECC ERROR
602
603          ;          SUBCODES FOR ST.HST
604
605          000040    SC.OTA =           40         ; ODD TRANSFER ADDRESS
606          000100    SC.OBC =          100         ; ODD BYTE COUNT
607          000140    SC.NXM =          140         ; NON-EXISTANT MEMORY
608          000200    SC.HMP =          200         ; HOST MEMORY PARITY ERROR
609          000240    SC.IPT =          240         ; INVALID PAGE TABLE ENTRY
610
611          ;          SUBCODES FOR ST.CNT
612
613          000040    SC.SDS =           40         ; SERDES OVERRUN OR UNDERRUN
614          000100    SC.EDC =          100         ; EDC ERROR
615          000140    SC.IIC =          140         ; INCONSISTANT INTERNAL CONTROL
616          000200    SC.IEE =          200         ; INTERNAL EDC ERROR
617          000240    SC.LPI =          240         ; LESI ADAPTOR CARD PARITY ERROR INPUT
618          000300    SC.LPO =          300         ; LESI ADAPTOR CARD PARITY ERROR,OUTPUT
619          000340    SC.CIP =          340         ; "CABLE IN PLACE" NOT ASSERTED
620          000400    SC.COU =          400         ; CONTROLLER OVERRUN OR UNDERRUN
621          000440    SC.CME =          440         ; CONTROLLER MEMORY ERROR
622
623          ;          SUBCODES FOR ST.DRV
624
625          000040    SC.CTO =           40         ; DRIVE COMMAND TIME OUT
626          000100    SC.XME =          100         ; CONTROLLER DETECTED XMISSION ERROR
627          000140    SC.POE =          140         ; POSITIONER ERROR
628          000200    SC.LRW =          200         ; LOST RESD/WRITE READY
629          000240    SC.DCD =          240         ; DRIVE CLOCK DROPOUT
630          000300    SC.LRR =          300         ; LOST RECEIVER READY
631          000340    SC.DDE =          340         ; DRIVE DETECTED ERROR
632          000400    SC.PSE =          400         ; PULSE OR STATE PARITY ERROR
633          000500    SC.PRO =          500         ; CONTROLLER DETECTED PROTOCOL ERROR
634          000550    SC.DFI =          550         ; DRIVE FAILED INITIALIZATION
635          000600    SC.DII =          600         ; DRIVE IGNORED INITIALIZATION
    
```

636

000640

SC.RRC = 640

; RECEIVER READY COLLISION

638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692

.SBTTL CONTROLLER TABLE DEFINITIONS

++
CONTROLLER TABLE DEFINITIONS

ONE TABLE WILL BE SET UP BY INITIALIZATION SECTION FOR EACH CONTROLLER
 SELECTED FOR TESTING. TABLES ARE CONTIGUOUS. THE END OF THE TABLES IS
 MARKED BY A WORD OF ZEROS.

THE FIRST TABLE IS POINTED TO BY THE CONTENTS OF CTABS.
 THE NUMBER OF TABLES IS CONTAINED IN CTRLRS.

BELOW IS A DESCRIPTION OF THE HOST COMMUNICATIONS AREA WITH ONE
 DESCRIPTOR IN EACH RING. THE DESCRIPTION OF THE COMMAND PACKETS
 IS CONTAINED IN THE MESSAGE ENVELOPE BUFFER DESCRIPTION LATER
 IN THIS PROGRAM.

C.CINT	}	COMMAND INTERRUPT INDICATOR	}	2 BYTES
C.RINT	}	RESPONSE INTERRUPT INDICATOR	}	2 BYTES
C.RRNG	}	MESSAGE (RESPONSE) RING	}	16 BYTES
C.CRNG	}	COMMAND RING	}	16 BYTES

NOTE: BYTES ARE GIVEN IN DECIMAL

000077
000777
007000
100000
040000
020000
010000
004000
002000
000400

CT.UNT = 000077 ; LOGICAL UNIT NUMBER MASK
 CT.VEC = 000777 ; VECTOR ADDRESS MASK
 CT.BRL = 007000 ; BR LEVEL MASK
 CT.AVL = BIT15 ; SET WHEN NOT AVAILABLE FOR TESTING
 CT.DUN = BIT14 ; SET IF DONE GENERATING PACKETS
 CT.MSG = BIT13 ; SET IF INTERRUPT RECEIVED
 CT.IOC = BIT12 ; SET IF TESTING I/O COMPLETED
 CT.DI = BIT11 ; SET IF CONTROLLER HAS UQSSP DIAGS
 CT.DET = BIT10 ; SET IF DETERMINISTIC PHASE NOT DONE
 CT.MRW = BIT08 ; MAINTENANCE OPERATIONS IN PROGRESS

TABLE ; START A TABLE DEFINITION
 ITEM C.IPR 2 <BUS ADDRESS OF IP REGISTER>
 ITEM C.UNIT 2 <UNIT NUMBER TO TEST>
 ITEM C.VEC 2 <VECTOR ADDRESS>
 ITEM C.CTO 2 <CONTROLLER TIMEOUT PERIOD>
 ITEM C.JSR 2 <INTERRUPT SERVICE ROUTINE FOR CONTROLLER>
 ITEM C.JAD 2 <THESE TWO WORDS LOADED WITH [JSR RO CNTSRV]>
 ITEM C.FLG 2 <FLAGS>
 ITEM C.DRO 2 <POINTER TO DRIVE TABLES>
 ITEM C.DR1 2 <IF ZERO, NO DRIVE TABLE EXISTS>
 ITEM C.DR2 2

693	002156	ITEM C.DR3	2	<CONTROLLER MODEL NUMBER>
694	002156	ITEM C.TYPE	2	<CURRENT TEST STEP>
695	002156	ITEM C.STEP	2	<COUNT OF DRIVES UNDER TEST>
696	002156	ITEM C.UCNT	2	<CONTROLLER MEMORY SIZE>
697	002156	ITEM C.MSIZ	2	<REGION OFFSET OF LAST I/O>
698	002156	ITEM C.ROFF	2	<DATA PATTERN CURRENTLY USED>
699	002156	ITEM C.TPAT	2	<NEXT DRIVE TO TEST>
700	002156	ITEM C.NEXT	2	<BYTES WRITTEN COUNT - LOW WORD>
701	002156	ITEM C.XFLW	2	<BYTES WRITTEN COUNT - MID WORD>
702	002156	ITEM C.XFMW	2	<BYTES WRITTEN COUNT - HIGH WORD>
703	002156	ITEM C.XFHW	2	<BYTES READ COUNT - LOW WORD>
704	002156	ITEM C.XFLR	2	<BYTES READ COUNT - MID WORD>
705	002156	ITEM C.XFMR	2	<BYTES READ COUNT - HIGH WORD>
706	002156	ITEM C.XFHR	2	<UNIT IDENTIFIER>
707	002156	ITEM C.UID	8.	<COMMAND RING POINTER>
708	002156	ITEM C.CPTR	2	<BASE ADDRESS OF COMMAND RING>
709	002156	ITEM C.CBAS	2	<FIRST ADDRESS AFTER THE COMMAND RING>
710	002156	ITEM C.CEND	2	<RESPONSE RING POINTER>
711	002156	ITEM C.RPTR	2	<BASE ADDRESS OF RESPONSE RING>
712	002156	ITEM C.RBAS	2	<FIRST ADDRESS AFTER THE REPOSE RING>
713	002156	ITEM C.REND	2	<PTR TO RESPONSE ENVELOPE RING>
714	002156	ITEM C.RHDR	2	<COMMAND INTERRUPT INDICATOR>
715	002156	ITEM C.CINT	2	<RESPONSE INTERRUPT INDICATOR>
716	002156	ITEM C.RINT	2	<RESPONSE RING>
717	002156	ITEM C.RRNG	16.	<COMMAND RING>
718	002156	ITEM C.CRNG	16.	<NUMBER OF AVAILABLE CREDITS>
719	002156	ITEM C.CRED	2	<CONTROLLER TIMEOUT COUNTER>
720	002156	ITEM C.TO	2	< (TWO WORDS)>
721	002156	ITEM C.TOH	2	<COMMAND LIST FORWARD LINK>
722	002156	ITEM C.CMFL	2	<COMMAND LIST BACK LINK>
723	002156	ITEM C.CMBL	2	<TO BE SENT LIST FORWARD LINK>
724	002156	ITEM C.TBSF	2	<TO BE SENT LIST BACK LINK>
725	002156	ITEM C.TBSB	2	
726				
727	002156	END C.SIZE		<SIZE OF CONTROLLER TABLE IN BYTES>
728				

```

730      .SBTTL  DRIVE TABLE DEFINITIONS
731
732      :++
733      :      DRIVE TABLE DEFINITIONS
734      :
735      :      ONE DRIVE TABLE WILL BE SET UP BY THE INITIALIZE SECTION FOR EACH
736      :      DRIVE SELECTED FOR TESTING.  EACH TABLE IS POINTED TO BY A
737      :      WORD IN THE CONTROLLER TABLE ON WHICH THE DRIVE EXISTS.
738      :
739      :      THE FIRST TABLE IS POINTED TO BY THE CONTENTS OF DTABS.
740      :--
741
742      000077      DT.UNT      = 000077      ; LOGICAL UNIT NUMBER OF DRIVE
743
744      100000      DT.AVL      = BIT15      ; SET WHEN NOT AVAILABLE FOR TESTING
745      040000      DT.DUN      = BIT14      ; SET IF DONE SUBTEST
746      020000      DT.BES      = BIT13      ; SET IF TESTING ENTIRE DISK
747      010000      DT.WRT      = BIT12      ; SET IF DRIVE IS WRITEABLE
748      004000      DT.CMP      = BIT11      ; SET IF COMPARE HOST DATA PENDING
749      002000      DT.EOM      = BIT10      ; SET IF END OF MEDIA REACHED
750      001000      DT.ONL      = BIT09      ; SET IF DRIVE IS ONLINE
751
752      147000      DT.CLR      = DT.AVL!DT.DUN!DT.CMP!DT.EOM!DT.ONL ; FLAGS TO CLEAR AT EOP
753      020000      DT.PRM      = DT.BES      ; DEFAULT TEST PARAMETERS
754
755      002156      TABLE      ; START A TABLE DEFINITION
756      002156      ITEM D.DRV      2      <DRIVE NUMBER>
757      002156      ITEM D.UNIT     2      <LOGICAL UNIT NUMBER>
758      002156      ITEM D.BEC      2      <BEGIN/END SET COUNT>
759      002156      ITEM D.BGN1     4      <BEGIN BLOCK 1>
760      002156      ITEM D.END1     4      <END>
761      002156      ITEM D.BGN2     4      <BEGIN BLOCK 2>
762      002156      ITEM D.END2     4      <END>
763      002156      ITEM D.BGN3     4      <BEGIN BLOCK 3>
764      002156      ITEM D.END3     4      <END>
765      002156      ITEM D.BGN4     4      <BEGIN BLOCK 4>
766      002156      ITEM D.END4     4      <END>
767      002156      ITEM D.BES      2      <CURRENT BEGIN/END SET>
768      002156      ITEM D.BLKS     2      <BLOCKS LEFT IN TEST SEGMENT>
769      002156      ITEM D.LBN      4      <NEXT LBN TO ACCESS>
770      002156      ITEM D.WCNT     2      <# OF OUTSTANDING WRITES>
771      002156      ITEM D.CCNT     2      <# OF OUTSTANDING COMPARE HOST DATAS>
772      002156      ITEM D.XFLW     2      <BYTES WRITTEN COUNT - LOW WORD>
773      002156      ITEM D.XFMW     2      <BYTES WRITTEN COUNT - MID WORD>
774      002156      ITEM D.XFHW     2      <BYTES WRITTEN COUNT - HIGH WORD>
775      002156      ITEM D.XFLR     2      <BYTES READ COUNT - LOW WORD>
776      002156      ITEM D.XFMR     2      <BYTES READ COUNT - MID WORD>
777      002156      ITEM D.XFHR     2      <BYTES READ COUNT - HIGH WORD>
778      002156      ITEM D.XFLA     2      <BYTES ACCESSED COUNT - LOW WORD>
779      002156      ITEM D.XFMA     2      <BYTES ACCESSED COUNT - MID WORD>
780      002156      ITEM D.XFHA     2      <BYTES ACCESSED COUNT - HIGH WORD>
781      002156      ITEM D.XFLC     2      <BYTES COMPARED COUNT - LOW WORD>
782      002156      ITEM D.XFMC     2      <BYTES COMPARED COUNT - MID WORD>
783      002156      ITEM D.XFHC     2      <BYTES COMPARED COUNT - HIGH WORD>
784      002156      ITEM D.HERR     2      <HARD ERROR COUNTER>
    
```

785 002156	ITEM D.SERR	2	<SOFT ERROR COUNTER>
786 002156	ITEM D.CERR	2	<COMPARE ERROR COUNTER>
787 002156	ITEM D.ECCC	2	<ECC COUNTER>
788 002156	ITEM D.UID	8.	<UNIT IDENTIFIER>
789 002156	ITEM D.VSN	4	<VOLUME SERIAL NUMBER>
790			
791 002156	END D.SIZE		<SIZE OF DRIVE TABLE IN BYTES>
792			

```

794      .SBTTL  GLOBAL DATA SECTION
795
796      :++
797      :     THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
798      :     IN MORE THAN ONE TEST.
799      :--
800
801 002156      ERRTBL
      002156      L$ERRTBL::
      002156      ERRTP::          .WORD  0
      002160      ERRNBR::         .WORD  0
      002162      ERRMSG::         .WORD  0
      002164      ERRBLK::         .WORD  0
802
803 002166      FFREE:  .BLKW  1      ; FIRST FREE WORD IN MEMORY
804 002170      FSIZE:  .BLKW  1      ; SIZE OF FREE MEMORY IN WORDS
805 002172      FMADR:  .BLKW  1      ; PERMANENT FREE MEM ADDR STORAGE
806 002174      FMSIZ:  .BLKW  1      ; PERMANENT FREE MEM SIZE STORAGE
807 002176      DTABS:  .BLKW  1      ; START OF DRIVE TABLE STORAGE
808 002200      CTABS:  .BLKW  1      ; START OF CONTROLLER TABLE STORAGE
809 002202      CTRLRS: .BLKW  1      ; COUNT OF CONTROLLERS IN PTABLES
810
811 002204      000000      IFLAGS: .WORD  0      ; FLAGS FROM INIT CODE
812
813      100000      IMMJ      =      BIT15      ; MEMORY MANAGEMENT FLAG
814      040000      IDIE      =      BIT14      ; ABORT PROGRAM FLAG
815      020000      IERL      =      BIT13      ; ERROR LOG FLAG
816      010000      IDUN      =      BIT12      ; TEST DONE FLAG
817      000100      IPAT16   =      BIT6       ; PATTERN 16 MODIFIED FLAG
818      000040      ITEMP     =      BITS5     ; TEMPORARY FLAG
819      000010      ISTRT     =      BITS3     ; START FLAG
820      000004      IREST     =      BIT2      ; RESTART FLAG
821      000002      ICONT     =      BIT1      ; CONTINUE EVENT FLAG
822
823 002206      000000      TNUM:  .WORD  0      ; NUMBER OF CURRENT TEST
824 002210      UTEST:  .BLKW  1      ; NUMBER OF UNITS STILL RUNNING TEST
825
826 002212      TEMP:  .BLKW  12.      ; TEMPORY STORAGE FOR GMANI RESPONSES
827 002242      TSTOFF: .BLKW  1      ; MEMORY OFFSET OF BUFFER
828 002244      TSTOPC: .BLKW  1      ; OPCODE FOR CURRENT PACKET
829 002246      TSPGEN: .BLKW  1      ; ADDRESS OF PACKET GENERATION ROUTINE
830 002250      STIME:  .BLKW  2      ; STATISTICAL REPORT TIMER
831 002254      TSTIM:  .BLKW  2      ; TEST TIMER
832 002260      TS.PAT: .BLKW  1      ; TEST PATTERN TO USE
833
834 002262      VECSAV: .BLKW  1      ; STORAGE FOR COMPUTED VECTOR
835
836 002264      NXMAD:  .BLKW  1      ; SET TO -1 BY NON-EXISTANT ADDRESS
837
838 002266      000000      RNTMH: .WORD  0      ; STORAGE FOR ELAPSED HOURS
839 002270      000000      RNTMM: .WORD  0      ; STORAGE FOR ELAPSED MINUTES
840 002272      000000      RNTSS: .WORD  0      ; STORAGE FOR ELAPSED SECONDS
841 002274      RPTLUN: .BLKW  0      ; STORAGE FOR LOGICAL UNIT NUMBER
842 002274      RPTMV:  .BLKW  1      ; STORAGE FOR BYTES WRITTEN
843 002276      RPTMF:  .BLKW  1      ; STORAGE FOR M/K FLAG
    
```

844	002300		RPTRV:	.BLKW	1	:	STORAGE FOR BYTES READ
845	002302		RPTRF:	.BLKW	1	:	STORAGE FOR M/K FLAG
846	002304		RPTAV:	.BLKW	1	:	STORAGE FOR BYTES ACCESSED
847	002306		RPTAF:	.BLKW	1	:	STORAGE FOR M/K FLAG
848	002310		RPTCV:	.BLKW	1	:	STORAGE FOR BYTES COMPARED
849	002312		RPTCF:	.BLKW	1	:	STORAGE FOR M/K FLAG
850							
851	002314		MSCPOP:	.BLKW	1	:	POINTER TO MSCP OPCODE MESSAGE
852	002316		STAMSO:	.BLKW	1	:	POINTER TO MSCP ERROR
853	002320		STAMS1:	.BLKW	1	:	MESSAGE STRING
854			:				
855			:				
856			:				
			:				
857	002322	000000	KW.CSR:	.WORD	0	:	CSR OF CLOCK
858	002324		KW.BRL:	.BLKW	1	:	BR LEVEL
859	002326		KW.VEC:	.BLKW	1	:	VECTOR
860	002330		KW.HZ:	.BLKW	1	:	HERTZ (50. OR 60.)
861	002332		KW.EL:	.BLKW	2	:	ELAPSED TIME
862	002336		KW.60:	.BLKW	1	:	HERTZ * 60
863			:				
864			:				
865			:				
866			:				
			:				
867	002340	053122	INI1BL:	.WORD	RSP.S1	:	1ST WORD RESPONSE CHECK ROUTINE
868	002342	000000	SND.S1:	.WORD	0	:	1ST WORD TO SEND TO SA REGISTER
869	002344	053160		.WORD	RSP.S2	:	2ND WORD RESPONSE CHECK ROUTINE
870	002346	000000	SND.S2:	.WORD	0	:	2ND WORD TO SEND TO SA REGISTER
871	002350	053204		.WORD	RSP.S3	:	3RD WORD RESPONSE CHECK ROUTINE
872							
873	002352	000000	SSTEP4:	.WORD	0	:	LOCATION TO SAVE STEP 4 VALUE
874	002354	000000	CNTRSD:	.WORD	0	:	LOCATION FOR STEP BIT MASK
875	002356		WCHNGD:	.BLKW	1	:	SAVED LOOPBACK DATA
876	002360	034245	LOSEED:	.WORD	34245	:	LO ORDER RANDOM NUMBER SEED
877	002362	061453	HISEED:	.WORD	61453	:	HI ORDER RANDOM NUMBER SEED
878							
879		032413	Q50MSZ =		32413	:	KDA50-Q MEMORY SIZE
880		036413	U50MSZ =		36413	:	UDA50-A MEMORY SIZE
881		000000	QDXMSZ =		0	:	RQDX1 MEMORY SIZE
882		000000	C25MSZ =		0	:	RUC25 MEMORY SIZE
883							
884		000004	RNGLEN =		4	:	# OF ENTRIES IN CMD/RSP RINGS
885		011000	RNGPWR =		011000	:	RING LENGTH FOR STEP 1
886							
887	002364		OBUF:	.BLKW	256.	:	LOW MEMORY DATA BUFFER
888	003364		CBUF:	.BLKW	256.	:	DATA COMPARE BUFFER
889	004364		PCGOOD:	.BLKW	1	:	TEMPORARY STORAGE FOR
890	004366		PCBAD:	.BLKW	1	:	DATA COMPARE ERROR MESSAGE
891	004370		BUFBA:	.BLKW	1	:	BUFFER DESCRIPTOR (LOW WORD)
892	004372		BUFEA:	.BLKW	1	:	BUFFER DESCRIPTOR (HIGH WORD)
893	004374		BUFBLK:	.BLKW	1	:	BUFFER SIZE IN BLOCKS
894	004376		BUFSIZ:	.BLKW	1	:	BUFFER SIZE IN WORDS
895	004400		MMBUF:	.BLKW	1	:	ADDRESS OF LOW MEMORY BUFFER
896	004402		MMSIZ:	.BLKW	1	:	SIZE OF LOW MEMORY BUFFER
897	004404		MMOFF:	.BLKW	1	:	MAPPED MEMORY OFFSET
898	004406		BCLO:	.BLKW	1	:	BYTE COUNT (LOW WORD)

899 004410

BCHI: .BLKW 1

; BYTE COUNT (HIGH WORD)


```

956      : RE.RP      } RESPONSE PACKET      } 128 BYTES
957      :           }
958      :           }
959      :           }
960      :           }
961      :           }
962      :           }
963      :           }
964      :           }
965      :           }
966      :           }
967      :           }
968      :           }
969      :           }
970      :           }
971      :           }
972      :           }
973      :           }
974      :           }
975      :           }
976      :           }
977      :           }
978      :           }
979      :           }
980      :           }
981      :           }
982      :           }
983      :           }
984      :           }
985      :           }
986      :           }
987      :           }
988      :           }
989      :           }
990      :           }
991      :           }
992      :           }
993      :           }
994      :           }
995      :           }
996      :           }
997      :           }
998      :           }
999      :           }
1000     :           }
1001     :           }
1002     :           }
1003     :           }
1004     :           }
1005     :           }
1006     :           }
1007     :           }
1008     :           }
1009     :           }
1010     :           }
    
```

NOTE: BYTES ARE GIVEN IN DECIMAL

```

963      000000 RE.RFL = 0. ; R.E. BUFFER FORWARD LINK
964      000002 RE.RL  = 2. ; RESPONSE PACKET LENGTH
965      000004 RE.RV  = 4. ; CIRCUIT ID, MSG TYPE, CREDITS
966      000006 RE.RP  = 6. ; RESPONSE PACKET (128. BYTE)
968      000103 RSPSIZ = 67. ; SIZE IN WORDS OF A RSP ENVELOPE
969      006226 RSPCNT: .BLKW 1 ; NUMBER OF R.E. BUFFERS
970      006230 RSPSTR: .BLKW 1 ; START OF R.E. BUFFER LIST
    
```

THE MESSAGE ENVELOPE BUFFER CONTAINS DATA ON EACH COMMAND THAT IS SENT TO THE CONTROLLER. THE BUFFERS ARE KEPT IN A "TO BE SENT" LIST UNTIL THE COMMAND RING ENTRY BECOMES AVAILABLE. AT THAT POINT THE ADDRESS OF THE FIRST COMMAND PACKET (OFFSET ME.CP) IN THE TBS LIST IS LOADED INTO THE COMMAND RING. THE BUFFER IS THEN PLACED IN THE OUTSTANDING COMMAND LIST.

THE MESSAGE ENVELOPE BUFFER FORMAT IS AS FOLLOWS:

```

983      : ME.CFL  } ----- } 2 BYTES
984      :           } COMMAND FLINK }
985      : ME.CBL  } ----- } 2 BYTES
986      :           } COMMAND BLINK }
987      : ME.CRF  } ----- } 2 BYTES
988      :           } COMMAND REFERENCE NUMBER }
989      : ME.CTO  } ----- } 2 BYTES
990      :           } COMMAND TIMEOUT INTERVAL (LOW WORD) }
991      : ME.CTH  } ----- } 2 BYTES
992      :           } COMMAND TIMEOUT INTERVAL (HIGH WORD) }
993      : ME.ST1  } ----- } 2 BYTES
994      :           } COMMAND STATUS (LOW WORD) }
995      : ME.ST2  } ----- } 2 BYTES
996      :           } COMMAND STATUS (HIGH WORD) }
997      : ME.CFG  } ----- } 2 BYTES
998      :           } COMMAND FLAGS }
999      : ME.OFF  } ----- } 2 BYTES
1000     :           } MAPPED MEMORY BYTE OFFSET TO I/O BUFFER }
1001     : ME.PKT,ME.CL } ----- } 2 BYTES
1002     :           } COMMAND PACKET LENGTH }
1003     : ME.CV   } ----- } 2 BYTES
1004     :           } CONNECTION ID } MSG TYPE } CREDITS }
1005     : ME.CP   } ----- } 60 BYTES
1006     :           } COMMAND PACKET }
1007     :           }
    
```

NOTE: BYTES ARE GIVEN IN DECIMAL

1011					
1012	100000	CF.FAIL =	BIT15		; CMD FAILED FLAG
1013	040000	CF.CTO =	BIT14		; GCS ISSUED FLAG
1014	020000	CF.ERL =	BIT13		; ERROR LOG GENERATED
1015					
1016	000000	ME.CFL =	0.		; CMD LIST FORWARD LINK
1017	000002	ME.CBL =	2.		; CMD LIST BACK LINK
1018	000004	ME.CRF =	4.		; CMD REFERENCE NUMBER
1019	000006	ME.CTO =	6.		; COMMAND TIMER (LOW WORD)
1020	000010	ME.CTH =	8.		; COMMAND TIMER (HIGH WORD)
1021	000012	ME.ST1 =	10.		; COMMAND STATUS (LOW WORD)
1022	000014	ME.ST2 =	12.		; COMMAND STATUS (HIGH WORD)
1023	000016	ME.CFG =	14.		; COMMAND FLAGS
1024	000020	ME.OFF =	16.		; MAPPED MEMORY OFFSET OF DATA BUFFER
1025	000022	ME.PKT =	18.		; START ADDRESS OF COMMAND PACKET
1026	000022	ME.CL =	18.		; COMMAND PACKET LENGTH
1027	000024	ME.CV =	20.		; CIRCUIT ID, MSG TYPE, CREDITS
1028	000026	ME.CP =	22.		; COMMAND PACKET (60 BYTE)
1029					
1030	000051	CMDSIZ =	41.		; SIZE IN WORDS OF A ME BUFFER
1031	006232	MEMIN: .BLKW	1		; MINIMUM SIZE ALLOCATION
1032	006234	TBSMIN: .BLKW	1		; MINIMUM NUMBER OF H.E.
1033	006236	TBSSIZ: .BLKW	1		; NUMBER OF AVAILABLE ME BUFFERS
1034	006240	TBSTRT: .BLKW	1		; START OF ME BUFFER LIST
1035	006242	T.HDR: .BLKW	2		; FREE ME BUFFER LIST HEADER

1092	006412	177760	.WORD	177760	; DATA PATTERN
1093	006414	177740	.WORD	177740	; DATA PATTERN
1094	006416	177700	.WORD	177700	; DATA PATTERN
1095	006420	177600	.WORD	177600	; DATA PATTERN
1096	006422	177400	.WORD	177400	; DATA PATTERN
1097	006424	177000	.WORD	177000	; DATA PATTERN
1098	006426	176000	.WORD	176000	; DATA PATTERN
1099	006430	174000	.WORD	174000	; DATA PATTERN
1100	006432	170000	.WORD	170000	; DATA PATTERN
1101	006434	160000	.WORD	160000	; DATA PATTERN
1102	006436	140000	.WORD	140000	; DATA PATTERN
1103	006440	100000	.WORD	100000	; DATA PATTERN
1104	006442	000000	.WORD	000000	; DATA PATTERN
1105	006444	063146	PAT06: .WORD	063146	; PATTERN 6 ID WORD
1106	006446	000020	.WORD	16.	; PATTERN SIZE
1107	006450	000000	.WORD	000000	; DATA PATTERN
1108	006452	000000	.WORD	000000	; DATA PATTERN
1109	006454	000000	.WORD	000000	; DATA PATTERN
1110	006456	177777	.WORD	177777	; DATA PATTERN
1111	006460	177777	.WORD	177777	; DATA PATTERN
1112	006462	177777	.WORD	177777	; DATA PATTERN
1113	006464	000000	.WORD	000000	; DATA PATTERN
1114	006466	000000	.WORD	000000	; DATA PATTERN
1115	006470	177777	.WORD	177777	; DATA PATTERN
1116	006472	177777	.WORD	177777	; DATA PATTERN
1117	006474	000000	.WORD	000000	; DATA PATTERN
1118	006476	177777	.WORD	177777	; DATA PATTERN
1119	006500	000000	.WORD	000000	; DATA PATTERN
1120	006502	177777	.WORD	177777	; DATA PATTERN
1121	006504	000000	.WORD	000000	; DATA PATTERN
1122	006506	177777	.WORD	177777	; DATA PATTERN
1123	006510	073567	PAT07: .WORD	073567	; PATTERN 7 ID WORD
1124	006512	000001	.WORD	1	; PATTERN SIZE
1125	006514	133331	PAT08: .WORD	133331	; DATA PATTERN
1126	006516	104210	.WORD	104210	; PATTERN 8 ID WORD
1127	006520	000020	.WORD	16.	; PATTERN SIZE
1128	006522	052525	.WORD	052525	; DATA PATTERN
1129	006524	052525	.WORD	052525	; DATA PATTERN
1130	006526	052525	.WORD	052525	; DATA PATTERN
1131	006530	125252	.WORD	125252	; DATA PATTERN
1132	006532	125252	.WORD	125252	; DATA PATTERN
1133	006534	125252	.WORD	125252	; DATA PATTERN
1134	006536	052525	.WORD	052525	; DATA PATTERN
1135	006540	052525	.WORD	052525	; DATA PATTERN
1136	006542	125252	.WORD	125252	; DATA PATTERN
1137	006544	125252	.WORD	125252	; DATA PATTERN
1138	006546	052525	.WORD	052525	; DATA PATTERN
1139	006550	125252	.WORD	125252	; DATA PATTERN
1140	006552	052525	.WORD	052525	; DATA PATTERN
1141	006554	125252	.WORD	125252	; DATA PATTERN
1142	006556	052525	.WORD	052525	; DATA PATTERN
1143	006560	125252	.WORD	125252	; DATA PATTERN
1144	006562	114631	PAT09: .WORD	114631	; PATTERN 9 ID WORD
1145	006564	000001	.WORD	1	; PATTERN SIZE
1146	006566	155554	.WORD	155554	; DATA PATTERN

1147	006570	125252	PAT10:	.WORD	125252	; PATTERN 10 ID WORD
1148	006572	000020		.WORD	16.	; PATTERN SIZE
1149	006574	026455		.WORD	026455	; DATA PATTERN
1150	006576	026455		.WORD	026455	; DATA PATTERN
1151	006600	026455		.WORD	026455	; DATA PATTERN
1152	006602	151322		.WORD	151322	; DATA PATTERN
1153	006604	151322		.WORD	151322	; DATA PATTERN
1154	006606	151322		.WORD	151322	; DATA PATTERN
1155	006610	026455		.WORD	026455	; DATA PATTERN
1156	006612	026455		.WORD	026455	; DATA PATTERN
1157	006614	151322		.WORD	151322	; DATA PATTERN
1158	006616	151322		.WORD	151322	; DATA PATTERN
1159	006620	026455		.WORD	026455	; DATA PATTERN
1160	006622	151322		.WORD	151322	; DATA PATTERN
1161	006624	026455		.WORD	026455	; DATA PATTERN
1162	006626	151322		.WORD	151322	; DATA PATTERN
1163	006630	026455		.WORD	026455	; DATA PATTERN
1164	006632	151322		.WORD	151322	; DATA PATTERN
1165	006634	135673	PAT11:	.WORD	135673	; PATTERN 11 ID WORD
1166	006636	000001		.WORD	1	; PATTERN SIZE
1167	006640	066666	PAT12:	.WORD	066666	; DATA PATTERN
1168	006642	146314		.WORD	146314	; PATTERN 12 ID WORD
1169	006644	000020		.WORD	16.	; PATTERN SIZE
1170	006646	000001		.WORD	000001	; DATA PATTERN
1171	006650	000002		.WORD	000002	; DATA PATTERN
1172	006652	000004		.WORD	000004	; DATA PATTERN
1173	006654	000010		.WORD	000010	; DATA PATTERN
1174	006656	000020		.WORD	000020	; DATA PATTERN
1175	006660	000040		.WORD	000040	; DATA PATTERN
1176	006662	000100		.WORD	000100	; DATA PATTERN
1177	006664	000200		.WORD	000200	; DATA PATTERN
1178	006666	000400		.WORD	000400	; DATA PATTERN
1179	006670	001000		.WORD	001000	; DATA PATTERN
1180	006672	002000		.WORD	002000	; DATA PATTERN
1181	006674	004000		.WORD	004000	; DATA PATTERN
1182	006676	010000		.WORD	010000	; DATA PATTERN
1183	006700	020000		.WORD	020000	; DATA PATTERN
1184	006702	040000		.WORD	040000	; DATA PATTERN
1185	006704	100000		.WORD	100000	; DATA PATTERN
1186	006706	156735	PAT13:	.WORD	156735	; PATTERN 13 ID WORD
1187	006710	000020		.WORD	16.	; PATTERN SIZE
1188	006712	177776		.WORD	177776	; DATA PATTERN
1189	006714	177775		.WORD	177775	; DATA PATTERN
1190	006716	177773		.WORD	177773	; DATA PATTERN
1191	006720	177767		.WORD	177767	; DATA PATTERN
1192	006722	177757		.WORD	177757	; DATA PATTERN
1193	006724	177737		.WORD	177737	; DATA PATTERN
1194	006726	177677		.WORD	177677	; DATA PATTERN
1195	006730	177577		.WORD	177577	; DATA PATTERN
1196	006732	177377		.WORD	177377	; DATA PATTERN
1197	006734	176777		.WORD	176777	; DATA PATTERN
1198	006736	175777		.WORD	175777	; DATA PATTERN
1199	006740	173777		.WORD	173777	; DATA PATTERN
1200	006742	167777		.WORD	167777	; DATA PATTERN
1201	006744	157777		.WORD	157777	; DATA PATTERN

1202	006746	137777	.WORD	137777	:	DATA PATTERN
1203	006750	077777	.WORD	077777	:	DATA PATTERN
1204	006752	167356	PAT14: .WORD	167356	:	PATTERN 14 ID WORD
1205	006754	000003	.WORD	3	:	PATTERN SIZE
1206	006756	155555	.WORD	155555	:	DATA PATTERN
1207	006760	133333	.WORD	133333	:	DATA PATTERN
1208	006762	155555	.WORD	155555	:	DATA PATTERN
1209	006764	177777	PAT15: .WORD	177777	:	PATTERN 15 ID WORD
1210	006766	000003	.WORD	3	:	PATTERN SIZE
1211	006770	155555	.WORD	155555	:	DATA PATTERN
1212	006772	133333	.WORD	133333	:	DATA PATTERN
1213	006774	060000	.WORD	066666	:	DATA PATTERN
1214						
1215	006776	006246	PATDSP: .WORD	PAT00	:	POINTERS
1216	007000	006312	.WORD	PAT01	:	TO
1217	007002	006320	.WORD	PAT02	:	DATA
1218	007004	006326	.WORD	PAT03	:	PATTERNS
1219	007006	006334	.WORD	PAT04	:	
1220	007010	006400	.WORD	PAT05	:	
1221	007012	006444	.WORD	PAT06	:	
1222	007014	006510	.WORD	PAT07	:	
1223	007016	006516	.WORD	PAT08	:	
1224	007020	006562	.WORD	PAT09	:	
1225	007022	006570	.WORD	PAT10	:	
1226	007024	006634	.WORD	PAT11	:	
1227	007026	006642	.WORD	PAT12	:	
1228	007030	006706	.WORD	PAT13	:	
1229	007032	006752	.WORD	PAT14	:	
1230	007034	006764	.WORD	PAT15	:	
1231						
1232	007036	000000	MNTPAT: .WORD	000000	:	POINTERS
1233	007040	177777	.WORD	177777	:	TO
1234	007042	000001	.WORD	000001	:	DATA
1235	007044	177776	.WORD	177776	:	PATTERNS
1236	007046	000002	.WORD	000002	:	
1237	007050	177775	.WORD	177775	:	
1238	007052	000004	.WORD	000004	:	
1239	007054	177773	.WORD	177773	:	
1240	007056	000010	.WORD	000010	:	
1241	007060	177767	.WORD	177767	:	
1242	007062	000020	.WORD	000020	:	
1243	007064	177757	.WORD	177757	:	
1244	007066	000040	.WORD	000040	:	
1245	007070	177737	.WORD	177737	:	
1246	007072	000100	.WORD	000100	:	
1247	007074	177677	.WORD	177677	:	
1248	007076	000200	.WORD	000200	:	
1249	007100	177577	.WORD	177577	:	
1250	007102	000400	.WORD	000400	:	
1251	007104	177377	.WORD	177377	:	
1252	007106	001000	.WORD	001000	:	
1253	007110	176777	.WORD	176777	:	
1254	007112	002000	.WORD	002000	:	
1255	007114	175777	.WORD	175777	:	
1256	007116	004000	.WORD	004000	:	

1257	007120	173777	.WORD	173777	:
1258	007122	010000	.WORD	010000	:
1259	007124	167777	.WORD	167777	:
1260	007126	020000	.WORD	020000	:
1261	007130	157777	.WORD	157777	:
1262	007132	040000	.WORD	040000	:
1263	007134	137777	.WORD	137777	:
1264	007136	100000	.WORD	100000	:
1265	007140	077777	.WORD	077777	:

```

1267      .SBTTL  GLOBAL TEXT SECTION
1268
1269      :
1270      :
1271      :
1272      :
1273      :
1274      :
1275      :
1276      :
1277      :
1278      :
1278      007142      104      123      101      L$DVTYP:
1278      007142
1278      007142
1279      :
1280      :
1281      :
1282      :
1282      007162      103      132      125      L$DESC:
1282      007162
1282      007162
1283      :
1284      :
1285      :
1286      :
1287      007244      007254      TNAMES:
1288      007246      007300      .WORD  BASNO
1289      007250      007330      .WORD  BASN1
1290      007252      007357      .WORD  BASN2
1291      .WORD  BASN3
1292      007254      124      105      123      BASNO:
1293      007300      103      117      116      BASN1:
1294      007330      123      125      102      BASN2:
1295      007357      123      125      102      BASN3:
1296      .ASCIZ  \TEST INITIALIZATION\
1297      007403      045      124      000      BASLO:
1298      007406      045      124      045      BASL1:
1299      007437      045      124      045      BASL2:
1300      .ASCIZ  \BT\
1301      007505      042      101      126      AMAV:
1302      007521      042      104      125      AMDU:
1303      007544      042      101      103      AMAP:
1304      .ASCIZ  \AVAILABLE\
1305      007562      042      101      102      OPCABO:
1306      007572      042      101      103      OPCACC:
1307      007603      042      101      126      OPCAVL:
1308      007617      042      103      117      OPCCCD:
1309      007651      042      103      117      OPCCMP:
1310      007675      042      104      105      OPCDAP:
1311      007725      042      105      122      OPCERS:
1312      007735      042      106      114      OPCFLU:
1313      007745      042      107      105      OPCGCS:
1314      007772      042      107      105      OPCGUS:
1315      010014      042      117      116      OPCONL:
1315      .ASCIZ  \ACCESS PATH\
1315      .ASCIZ  \ABORT\
1315      .ASCIZ  \ACCESS\
1315      .ASCIZ  \AVAILABLE\
1315      .ASCIZ  \COMPARE CONTROLLER DATA\
1315      .ASCIZ  \COMPARE HOST DATA\
1315      .ASCIZ  \DETERMINE ACCESS PATH\
1315      .ASCIZ  \ERASE\
1315      .ASCIZ  \FLUSH\
1315      .ASCIZ  \GET COMMAND STATUS\
1315      .ASCIZ  \GET UNIT STATUS\
1315      .ASCIZ  \ONLINE\
1315      .ASCIZ  \CONTROLLER AT #06\
1315      .ASCIZ  \CONTROLLER AT #06#A, DRIVE #03\
1315      ; ABORT COMMAND
1315      ; ACCESS COMMAND
1315      ; AVAILABLE COMMAND
1315      ; COMPARE CONTROLLER DATA COMMAND
1315      ; COMPARE HOST DATA COMMAND
1315      ; DETERMINE ACCESS PATHS COMMAND
1315      ; ERASE COMMAND
1315      ; FLUSH COMMAND
1315      ; GET COMMAND STATUS COMMAND
1315      ; GET UNIT STATUS COMMAND
1315      ; ONLINE COMMAND
    
```

1316	010025	042	122	105	OPCRD: .ASCIZ \ "READ" \ ; READ COMMAND
1317	010034	042	122	105	OPCRPL: .ASCIZ \ "REPLACE" \ ; REPLACE COMMAND
1318	010046	042	123	105	OPSCC: .ASCIZ \ "SET CONTROLLER CHARACTERISTICS" \ ; SET CONTROLLER CHARACTERISTICS COMMAND
1319	010107	042	123	105	OPCSUC: .ASCIZ \ "SET UNIT CHARACTERISTICS" \ ; SET UNIT CHARACTERISTICS COMMAND
1320	010142	042	127	122	OPCWR: .ASCIZ \ "WRITE" \ ; WRITE COMMAND
1321	010152	042	115	101	OPCMDR: .ASCIZ \ "MAINTENANCE READ" \ ; MAINTENANCE READ COMMAND
1322	010175	042	115	101	OPCMWR: .ASCIZ \ "MAINTENANCE WRITE" \ ; MAINTENANCE WRITE COMMAND
1323					
1324	010221	040	040	000	BLANK: .ASCIZ \ \
1325	010224	101	122	105	INITWD: .ASCIZ \ ARE YOU SURE CUSTOMER DATA CAN BE DESTROYED \
1326					
1327	010300	045	116	000	CRLF: .ASCIZ \ \ \
1328	010303	045	101	040	RNTIN: .ASCIZ \ \ #A - RUN TIME #D6#A; #Z2#A; #Z2 \
1329	010341	045	116	045	DETHDR: .ASCIZ \ \ #ASUBSYSTEM EXERCISER - CONTROLLER AT #06 \
1330	010415	045	101	104	DETDUN: .ASCIZ \ \ #ADETERMINISTIC PHASE DONE. #N \
1331	010453	045	116	045	TIMLIM: .ASCIZ \ \ #ATEST TIME LIMIT REACHED - TEST STOPPING \
1332	010527	045	116	045	ERRLIM: .ASCIZ \ \ #AUNIT #D3#A REACHED ERROR LIMIT - UNIT DROPPED FROM TEST #N \
1333	010625	045	116	045	T3WARN: .ASCIZ \ \ #AMANUAL INTERVENTION NOT ALLOWED. USING DEFAULT PARAMETERS #N \
1334	010725	045	116	045	INITWA: .ASCIZ \ \ #ACUSTOMER DATA WILL BE DESTROYED ON: #N \
1335	010777	045	123	065	INITWB: .ASCIZ \ \ #S#AUNIT#S3#ACONTROLLER#S3#ADRIVE#N \
1336	011044	045	123	066	INITWC: .ASCIZ \ \ #S6#D2#S6#D6#S6#D3#N \
1337	011071	045	101	116	NOCLOCK: .ASCIZ \ \ #AND LINE CLOCK AVAILABLE FOR TIMING EVENTS #N \
1338	011147	045	124	045	ATNMSG: .ASCIZ \ \ #ATA ATTENTION MESSAGE RECEIVED #N \
1339	011211	045	101	124	X2: .ASCIZ \ \ #ATWO UNITS SELECT THE SAME DRIVE #N \
1340	011255	045	101	115	X3: .ASCIZ \ \ #AMORE THAN 4 DRIVES SELECTED ON THIS CONTROLLER #N \
1341	011340	045	101	116	X4A: .ASCIZ \ \ #ANDOT ENOUGH MEMORY TO TEST THE UNITS SELECTED #N \
1342	011421	045	101	122	X4B: .ASCIZ \ \ #ARESTART PROGRAM AND TEST FEWER UNITS AT A TIME #N \
1343	011504	045	101	111	X5A: .ASCIZ \ \ #AINVALID BEGIN/END SET SPECIFIED #N \
1344	011550	045	101	102	X5B: .ASCIZ \ \ #ABEGIN/END SET SPECIFIES OUT-OF-RANGE LBN. #N \
1345	011626	045	101	115	X5C: .ASCIZ \ \ #AMAXIMUM LBN: #T #N \
1346	011652	045	101	104	X6: .ASCIZ \ \ #ADATA STRUCTURE CORRUPT AT LOCATION #06#A. RE-LOAD PROGRAM #N \
1347	011750	045	101	103	X14A: .ASCIZ \ \ #ACONTROLLER IS NOT SUPPORTED BY THIS DIAGNOSTIC PROGRAM. #N \
1348	012044	045	101	120	X14B: .ASCIZ \ \ #APROGRAM REQUIRES A UOSSP DISK TYPE CONTROLLER #N \
1349	012126	045	101	103	X14C: .ASCIZ \ \ #ACONTROLLER REPORTED MODEL CODE #C2 #N \
1350	012175	045	101	123	X22A: .ASCIZ \ \ #ASTEP BIT DID NOT SET IN SA REGISTER DURING INITIALIZATION #N \
1351	012273	045	101	123	X22B: .ASCIZ \ \ #ASTEP BIT EXPECTED #06 #N \
1352	012325	045	101	103	X23A: .ASCIZ \ \ #ACONTROLLER DID NOT CLEAR PORT COMMUNICATIONS AREA DURING INITIALIZATION #N \
1353	012441	045	101	066	X23C: .ASCIZ \ \ #A6 WORDS WERE TO BE CLEARED STARTING AT ADDRESS #06 #N \
1354	012530	045	101	124	X23D: .ASCIZ \ \ #ATHE FOLLOWING WORDS WERE NOT CLEARED: #N \
1355	012602	045	123	066	X23E: .ASCIZ \ \ #S6#ADDRESS#S4#ACONTENTS#N \
1356	012636	045	123	067	X23F: .ASCIZ \ \ #S7#06#SS#06#N \
1357	012655	045	101	123	X24A: .ASCIZ \ \ #ASAREGISTER DID NOT GO TO 0 AFTER STEP 3 WRITE OF INITIALIZATION #N \
1358	012762	045	101	120	X24B: .ASCIZ \ \ #APURGE/POLE DIAGNOSTICS WERE REQUESTED #N \
1359	013034	045	101	111	X25: .ASCIZ \ \ #AINCORRECT DATA RETURNED IN SA REGISTER DURING INITIALIZATION #N \
1360	013135	045	101	104	X26: .ASCIZ \ \ #ADATA COMPARISON ERROR DURING WRAP MODE TEST #N \
1361	013215	045	101	123	X27: .ASCIZ \ \ #ASAREGISTER DID NOT CHANGE AFTER WRITING IT IN WRAP MODE TEST #N \
1362	013317	045	101	103	X31: .ASCIZ \ \ #ACONTROLLER TIMED OUT BY HOST, NO PROGRESS MADE ON COMMAND #N \
1363	013415	045	101	120	X32: .ASCIZ \ \ #APACKET RECEIVED FROM CONTROLLER WITH UNKNOWN ENDCODE #N \
1364	013505	045	101	105	.ASCIZ \ \ #AENDCODE: #D3 #N \
1365	013526	045	101	120	X33: .ASCIZ \ \ #APACKET RECEIVED FROM CONTROLLER WITH UNKNOWN STATUS #N \
1366	013615	045	101	123	.ASCIZ \ \ #ASTATUS: #D3 #N \
1367	013635	045	101	103	X34: .ASCIZ \ \ #ACONTROLLER DETECTED INVALID COMMAND PACKET #N \
1368	013713	045	101	106	.ASCIZ \ \ #AFIELD AT OFFSET #D3#A IS BAD #N \
1369	013754	045	101	120	X35: .ASCIZ \ \ #APACKET RECEIVED FROM CONTROLLER SPECIFIES UNKNOWN DRIVE #N \
1370	014047	045	101	104	.ASCIZ \ \ #ADRIVE UNIT NUMBER: #D3 #N \

1371	014102	045	101	115	X37A:	.ASCIZ \MEMORY ERROR TRYING TO READ CONTROLLER REGISTERS#N\
1372	014167	045	101	105	X37B:	.ASCIZ \AEITHER THE CONTROLLER CSR ADDRESS WAS INCORRECTLY SPECIFIED#N\
1373	014267	045	101	117	X37C:	.ASCIZ \AOR THERE IS A BUS OR CONTROLLER PROBLEM#N\
1374	014343	045	101	104	X38A:	.ASCIZ \ADATA COMPARE ERROR DURING DATA PATTERN VERIFICATION#N\
1375	014433	045	101	114	X38B:	.ASCIZ \ALBN: #T#A, BYTE OFFSET: #06#N\
1376	014474	045	101	104	X38C:	.ASCIZ \ADATA EXPECTED: #06#A DATA READ: #06#N\
1377	014545	045	101	104	X39A:	.ASCIZ \ADATA COMPARE ERROR DURING CONTROLLER MEMORY TEST#N\
1378	014632	045	101	103	X39B:	.ASCIZ \ACONTROLLER MEMORY ADDRESS: #06#N\
1379	014675	045	101	104	X39C:	.ASCIZ \ADATA WRITTEN: #06#A DATA READ: #06#N\
1380	014744	045	124	045	X41:	.ASCIZ \T#A MSCP OPERATION FAILED#N\
1381	015001	045	101	120	X42A:	.ASCIZ \APREVIOUS FATAL CONTROLLER ERROR CAUSED THE CONTROLLER AND#N\
1382	015077	045	101	124	X42B:	.ASCIZ \ATHE FOLLOWING DRIVES TO BE DROPPED:\
1383	015145	045	123	063	X42C:	.ASCIZ \S#03\
1384	015154	045	101	120	X43:	.ASCIZ \APREVIOUS FATAL DRIVE ERROR CAUSED THIS DRIVE TO BE DROPPED#N\
1385	015253	045	101	105	X50A:	.ASCIZ \AERROR LOG RECEIVED - CONTROLLER ERROR#N\
1386	015325	045	101	105	X51A:	.ASCIZ \AERROR LOG RECEIVED - HOST MEMORY ACCESS ERROR#N\
1387	015407	045	101	110	X51B:	.ASCIZ \AMOST MEMORY ADDRESS: #T#N\
1388	015443	045	101	105	X52A:	.ASCIZ \AERROR LOG RECEIVED - DISK TRANSFER ERROR#N\
1389	015520	045	101	122	X52B:	.ASCIZ \AMETRY COUNT: #03#A RECOVERY LEVEL: #03#N\
1390	015573	045	101	105	X53A:	.ASCIZ \AERROR LOG RECEIVED - SDI ERROR#N\
1391	015636	045	101	123	X53B:	.ASCIZ \ASDI STATUS (R TO L): #06#S1#06#S1#06#S1#06#S1#06#S1#06#S1#06#N\
1392	015731	045	101	105	X54A:	.ASCIZ \AERROR LOG RECEIVED - SMALL DISK ERROR#N\
1393	016003	045	101	103	X54B:	.ASCIZ \ACYLINDER: #T#N\
1394	016024	045	101	104	X60:	.ASCIZ \ADRIVE UNDER TEST BECAME UNIT-AVAILABLE#N\
1395	016077	045	101	104	X61:	.ASCIZ \ADUPLICATE UNIT NUMBER DETECTED BY CONTROLLER#N\
1396	016160	045	101	117	MSG:AI:	.ASCIZ \AOPERATION FAILED#N\
1397	016205	045	101	117	MSG:UC:	.ASCIZ \AOPERATION SUCCESSFUL#N\
1398	016236	045	101	117	MSG:ON:	.ASCIZ \AOPERATION CONTINUING#N\
1399	016267	045	101	102	MSG:BR:	.ASCIZ \ABAD BLOCK REPORTED, LBN:#T#N\
1400	016326	045	101	101	MSG:BU:	.ASCIZ \AADDITIONAL BAD BLOCKS UNREPORTED#N\
1401	016373	045	101	105	MSG:LG:	.ASCIZ \AERROR LOG GENERATED#N\
1402	016423	045	101	123	XSTA:	.ASCIZ \ASTATUS/EVENT CODE: #T#T#N\
1403	016457	045	101	111	XBN:	.ASCIZ \AINVALID NUMBERS GIVEN TO THE HARDWARE QUESTIONS#N\
1404	016543	045	101	106	XFC:	.ASCIZ \AFATAL ERROR REPORTED BY CONTROLLER#N\
1405	016612	045	101	115	XMSG1:	.ASCIZ \AMESSAGE BUFFER CONTAINS:#N\
1406	016647	045	123	062	XMSG2:	.ASCIZ \S#06\
1407	016656	045	101	104	XSAE:	.ASCIZ \ADATA EXPECTED: #06#N\
1408	016705	045	101	123	XSA:	.ASCIZ \ASAS REGISTER CONTAINS: #06#N\
1409	016743	045	101	122	XFRU:	.ASCIZ \AREPLACE CONTROLLER PROCESSOR MODULE#N\
1410	017013	045	101	122	XFRUA:	.ASCIZ \AREPLACE CONTROLLER SDI MODULE#N\
1411						
1412						.EVEN
1413						

```

1415
1416
1417
1418
1419
1420
1421
1422
1423 017056
      017056
1424 017056 004737 054270
1425 017062
      017062 012746 016457
      017066 012746 000001
      017072 010600
      017074 104414
      017076 062706 000004
1426 017102
      017102 012746 011211
      017106 012746 000001
      017112 010600
      017114 104414
      017116 062706 000004
1427 017122
      017122
      017122 104423
1428
1429 017124
      017124
1430 017124 004737 054136
1431 017130
      017130 012746 016457
      017134 012746 000001
      017140 010600
      017142 104414
      017144 062706 000004
1432 017150
      017150 012746 011255
      017154 012746 000001
      017160 010600
      017162 104414
      017164 062706 000004
1433 017170
      017170
      017170 104423
1434
1435 017172
      017172
1436 017172 004737 054006
1437 017176
      017176 012746 011340
      017202 012746 000001
      017206 010600
      017210 104414
      017212 062706 000004
    
```

```

.SBTTL GLOBAL ERROR REPORT SECTION
; **
; THE GLOBAL ERROR REPORT SECTION CONTAINS MESSAGE PRINTING AREAS USED
; BY MORE THAN ONE TEST TO OUTPUT ADDITIONAL ERROR INFORMATION. PRINTB
; (BASIC) AND PRINTX (EXTENDED) CALLS ARE USED TO CALL PRINT SERVICES.
; --

BGNMSG ERR002
ERR002::
CALL CALR6 ; PRINT HEADER INFO
PRINTB @XBHW ; PRINT FIRST LINE
MOV @XBHW, -(SP)
MOV @1, -(SP)
MOV SP, R0
TRAP C#PNTB
ADD @4, SP
PRINTB @X2 ; PRINT NEXT LINE
MOV @X2, -(SP)
MOV @1, -(SP)
MOV SP, R0
TRAP C#PNTB
ADD @4, SP

ENDMSG
L10002: TRAP C#MSG

BGNMSG ERR003
ERR003::
CALL CALR5 ; PRINT HEADER INFO
PRINTB @XBHW ; PRINT FIRST LINE
MOV @XBHW, -(SP)
MOV @1, -(SP)
MOV SP, R0
TRAP C#PNTB
ADD @4, SP
PRINTB @X3 ; PRINT NEXT LINE
MOV @X3, -(SP)
MOV @1, -(SP)
MOV SP, R0
TRAP C#PNTB
ADD @4, SP

ENDMSG
L10003: TRAP C#MSG

BGNMSG ERR004
ERR004::
CALL CALR4 ; PRINT HEADER INFO
PRINTB @X4A
MOV @X4A, -(SP)
MOV @1, -(SP)
MOV SP, R0
TRAP C#PNTB
ADD @4, SP
    
```

1438	017216			PRINTB	#X4B	
	017216	012746	011421	MOV	#X4B, -(SP)	
	017222	012746	000001	MOV	#1, -(SP)	
	017226	010600		MOV	SP, R0	
	017230	104414		TRAP	C#PNTB	
	017232	062706	000004	ADD	#4, SP	
1439	017236			ENDMSG		
	017236			L10004:		
	017236	104423		TRAP	C#MSG	
1440						
1441	017240			BGNMSG	ERR005	
	017240			ERR005::		
1442	017240	004737	054270	CALL	CALR6	; PRINT HEADER INFO
1443	017244			PRINTB	#X5A	; PRINT FIRST LINE
	017244	012746	011504	MOV	#X5A, -(SP)	
	017250	012746	000001	MOV	#1, -(SP)	
	017254	010600		MOV	SP, R0	
	017256	104414		TRAP	C#PNTB	
	017260	062706	000004	ADD	#4, SP	
1444	017264			PRINTX	#X5B	; PRINT NEXT LINE
	017264	012746	011550	MOV	#X5B, -(SP)	
	017270	012746	000001	MOV	#1, -(SP)	
	017274	010600		MOV	SP, R0	
	017276	104415		TRAP	C#PNTX	
	017300	062706	000004	ADD	#4, SP	
1445	017304			PRINTX	#X5C, #TEMP	; PRINT NEXT LINE
	017304	012746	002212	MOV	#TEMP, -(SP)	
	017310	012746	011626	MOV	#X5C, -(SP)	
	017314	012746	000002	MOV	#2, -(SP)	
	017320	010600		MOV	SP, R0	
	017322	104415		TRAP	C#PNTX	
	017324	062706	000006	ADD	#6, SP	
1446	017330			ENDMSG		
	017330			L10005:		
	017330	104423		TRAP	C#MSG	
1447						
1448	017332			BGNMSG	ERR006	
	017332			ERR006::		
1449	017332	004737	054006	CALL	CALR4	; PRINT HEADER INFO
1450	017336			PRINTB	#X6, R1	
	017336	010146		MOV	R1, -(SP)	
	017340	012746	011652	MOV	#X6, -(SP)	
	017344	012746	000002	MOV	#2, -(SP)	
	017350	010600		MOV	SP, R0	
	017352	104414		TRAP	C#PNTB	
	017354	062706	000006	ADD	#6, SP	
1451	017360			ENDMSG		
	017360			L10006:		
	017360	104423		TRAP	C#MSG	
1452						
1453	017362			BGNMSG	ERR014	; INVALID CONTROLLER TYPE
	017362			ERR014::		
1454	017362	004737	054136	CALL	CALR5	; PRINT HEADER INFO
1455	017366			PRINTB	#X14A	
	017366	012746	011750	MOV	#X14A, -(SP)	

	017372	012746	000001	MOV	#1,-(SP)	
	017376	010600		MOV	SP,R0	
	017400	104414		TRAP	C#PNTB	
	017402	062706	000004	ADD	#4,SP	
1456	017406			PRINTX	#X14B	
	017406	012746	012044	MOV	#X14B,-(SP)	
	017412	012746	000001	MOV	#1,-(SP)	
	017416	010600		MOV	SP,R0	
	017420	104415		TRAP	C#PNTX	
	017422	062706	000004	ADD	#4,SP	
1457	017426			PRINTX	#X14C,R3	
	017426	010346		MOV	R3,-(SP)	
	017430	012746	012126	MOV	#X14C,-(SP)	
	017434	012746	000002	MOV	#2,-(SP)	
	017440	010600		MOV	SP,R0	
	017442	104415		TRAP	C#PNTX	
	017444	062706	000006	ADD	#6,SP	
1458	017450			ENDMSG		
	017450			L10007:		
	017450	104423		TRAP	C#MSG	
1459	017452			BGNMSG	ERR021	
1460	017452			ERR021::		
	017452	004737	054136	CALL	CALR5	; PRINT HEADER INFO
1461	017452	004737	053762	CALL	CALR3	; PRINT FATAL CONTROLLER ERROR
1462	017456	004737	054446	CALL	CALR8	; PRINT SA CONTENTS
1463	017462	004737	054446	CALL	CALR8	
1464	017466	032702	001000	BIT	#1000,R2	
1465	017472	001411		BEQ	ERR21A	
1466	017474			PRINTB	#XFRUA	
	017474	012746	017013	MOV	#XFRUA,-(SP)	
	017500	012746	000001	MOV	#1,-(SP)	
	017504	010600		MOV	SP,R0	
	017506	104414		TRAP	C#PNTB	
	017510	062706	000004	ADD	#4,SP	
1467	017514	000402		BR	ERR21E	
1468	017516			ERR21A:		
1469	017516	004737	054424	CALL	CALR7	; PRINT REPLACE FRU
1470	017522			ERR21E:		
1471	017522			ENDMSG		
	017522			L10010:		
	017522	104423		TRAP	C#MSG	
1472	017524			BGNMSG	ERR022	
1473	017524			ERR022::		
	017524	004737	054136	CALL	CALR5	; PRINT HEADER INFO
1474	017524	004737	054136	PRINTB	#X22A	; PRINT ERROR MESSAGE
1475	017530			MOV	#X22A,-(SP)	
	017530	012746	012175	MOV	#1,-(SP)	
	017534	012746	000001	MOV	SP,R0	
	017540	010600		TRAP	C#PNTB	
	017542	104414		ADD	#4,SP	
	017544	062706	000004	PRINTX	#X22B,CNTRSD	
1476	017550			MOV	CNTRSD,-(SP)	
	017550	013746	002354	MOV	#X22B,-(SP)	
	017554	012746	012273	MOV	#2,-(SP)	
	017560	012746	000002	MOV	#2,-(SP)	

	017564	010600		MOV	SP,R0	
	017566	104415		TRAP	C#PNTX	
	017570	062706	000006	ADD	#6,SP	
1477	017574	004737	054446	CALL	CALR8	; PRINT SA CONTENTS
1478	017600	004737	054424	CALL	CALR7	; PRINT REPLACE FRU
1479	017604			ENDMSG		
	017604			L10011:		
	017604	104423		TRAP	C#MSG	
1480						
1481	017606			BGNMSG	ERR023	
	017606			ERR023::		
1482	017606	004737	054136	CALL	CALR5	; PRINT HEADER INFO
1483	017612			PRINTB	#X23A	
	017612	012746	012325	MOV	#X23A,-(SP)	
	017616	012746	000001	MOV	#1,-(SP)	
	017622	010600		MOV	SP,R0	
	017624	104414		TRAP	C#PNTB	
	017626	062706	000004	ADD	#4,SP	
1484	017632	010500		MOV	R5,R0	
1485	017634	062700	000106	ADD	#C.CINT,R0	
1486	017640			PRINTX	#X23C,R0	
	017640	010046		MOV	R0,-(SP)	
	017642	012746	012441	MOV	#X23C,-(SP)	
	017646	012746	000002	MOV	#2,-(SP)	
	017652	010600		MOV	SP,R0	
	017654	104415		TRAP	C#PNTX	
	017656	062706	000006	ADD	#6,SP	
1487	017662			PRINTX	#X23D	
	017662	012746	012530	MOV	#X23D,-(SP)	
	017666	012746	000001	MOV	#1,-(SP)	
	017672	010600		MOV	SP,R0	
	017674	104415		TRAP	C#PNTX	
	017676	062706	000004	ADD	#4,SP	
1488	017702			PRINTX	#X23E	
	017702	012746	012602	MOV	#X23E,-(SP)	
	017706	012746	000001	MOV	#1,-(SP)	
	017712	010600		MOV	SP,R0	
	017714	104415		TRAP	C#PNTX	
	017716	062706	000004	ADD	#4,SP	
1489	017722	005742		TST	-(R2)	
1490	017724	005712		ERR23A: TST	(R2)	
1491	017726	001412		BEQ	ERR23B	
1492	017730			PRINTX	#X23F,R2,(R2)	
	017730	011246		MOV	(R2)-,(SP)	
	017732	010246		MOV	R2,-(SP)	
	017734	012746	012636	MOV	#X23F,-(SP)	
	017740	012746	000003	MOV	#3,-(SP)	
	017744	010600		MOV	SP,R0	
	017746	104415		TRAP	C#PNTX	
	017750	062706	000010	ADD	#10,SP	
1493	017754	005722		ERR23B: TST	(R2)+	
1494	017756	005303		DEC	R3	
1495	017760	001361		BNE	ERR23A	
1496	017762	004737	054424	CALL	CALR7	; PRINT REPLACE FRU
1497	017766			ENDMSG		

	017766			L10012:	TRAP	C4MSG	
1498	017766	104423					
1499	017770			BGNMSG	ERR024		
1500	017770	004737	054136	ERR024::	CALL	CALR5	; PRINT HEADER INFO
1501	017774				PRINTB	#X24A	; PRINT ERROR MESSAGE
	017774	012746	012655		MOV	#X24A, -(SP)	
	020000	012746	000001		MOV	#1, -(SP)	
	020004	010600			MOV	SP, R0	
	020006	104414			TRAP	C4PNTB	
	020010	062706	000004		ADD	#4, SP	
1502	020014				PRINTB	#X24B	;
	020014	012746	012762		MOV	#X24B, -(SP)	
	020020	012746	000001		MOV	#1, -(SP)	
	020024	010600			MOV	SP, R0	
	020026	104414			TRAP	C4PNTB	
	020030	062706	000004		ADD	#4, SP	
1503	020034	004737	054446		CALL	CALR8	; PRINT SA CONTENTS
1504	020040	004737	054424		CALL	CALR7	; PRINT REPLACE FRU
1505	020044			ENDMSG			
	020044			L10013:	TRAP	C4MSG	
	020044	104423					
1506	020046			BGNMSG	ERR025		
1507	020046			ERR025::	CALL	CALR5	; PRINT HEADER INFO
1508	020046	004737	054136		PRINTB	#X25	; PRINT ERROR MESSAGE
1509	020052				MOV	#X25, -(SP)	
	020052	012746	013034		MOV	#1, -(SP)	
	020056	012746	000001		MOV	SP, R0	
	020062	010600			TRAP	C4PNTB	
	020064	104414			ADD	#4, SP	
	020066	062706	000004		PRINTX	#XSAE, R1	; PRINT EXPECTED DATA
1510	020072				MOV	R1, -(SP)	
	020072	010146			MOV	#XSAE, -(SP)	
	020074	012746	016656		MOV	#2, -(SP)	
	020100	012746	000002		MOV	SP, R0	
	020104	010600			TRAP	C4PNTX	
	020106	104415			ADD	#6, SP	
	020110	062706	000006		CALL	CALR8	; PRINT SA CONTENTS
1511	020114	004737	054446		CALL	CALR7	; PRINT REPLACE FRU
1512	020120	004737	054424	ENDMSG			
1513	020124			L10014:	TRAP	C4MSG	
	020124						
	020124	104423					
1514	020126			BGNMSG	ERR026		
1515	020126			ERR026::	CALL	CALR5	; PRINT HEADER INFO
1516	020126	004737	054136		PRINTB	#X26	; PRINT ERROR MESSAGE
1517	020132				MOV	#X26, -(SP)	
	020132	012746	013135		MOV	#1, -(SP)	
	020136	012746	000001		MOV	SP, R0	
	020142	010600			TRAP	C4PNTB	
	020144	104414			ADD	#4, SP	
	020146	062706	000004				

1518	020152			PRINTX	#XSAE,WCHNGD	; PRINT EXPECTED DATA
	020152	013746	002356	MOV	WCHNGD,-(SP)	
	020156	012746	016656	MOV	#XSAE,-(SP)	
	020162	012746	000002	MOV	#2,-(SP)	
	020166	010600		MOV	SP,R0	
	020170	104415		TRAP	C#PNTX	
	020172	062706	000006	ADD	#6,SP	
1519	020176	004737	054446	CALL	CALR8	; PRINT SA CONTENTS
1520	020202	004737	054424	CALL	CALR7	; PRINT REPLACE FRU
1521	020206			ENDMSG		
	020206			L10015:		
	020206	104423		TRAP	C#MSG	
1522						
1523	020210			BGNMSG	ERR027	
	020210			ERR027::		
1524	020210	004737	054136	CALL	CALR5	; PRINT HEADER INFO
1525	020214			PRINTB	#X27	; PRINT ERROR MESSAGE
	020214	012746	013215	MOV	#X27,-(SP)	
	020220	012746	000001	MOV	#1,-(SP)	
	020224	010600		MOV	SP,R0	
	020226	104414		TRAP	C#PNTB	
	020230	062706	000004	ADD	#4,SP	
1526	020234	004737	054446	CALL	CALR8	; PRINT SA CONTENTS
1527	020240	004737	054424	CALL	CALR7	; PRINT REPLACE FRU
1528	020244			ENDMSG		
	020244			L10016:		
	020244	104423		TRAP	C#MSG	
1529						
1530	020246			BGNMSG	ERR030	
	020246			ERR030::		
1531	020246	004737	054136	CALL	CALR5	; PRINT HEADER INFO
1532	020252	004737	053762	CALL	CALR3	; PRINT FATAL CONTROLLER ERROR
1533	020256	004737	054446	CALL	CALR8	; PRINT SA CONTENTS
1534	020262			ENDMSG		
	020262			L10017:		
	020262	104423		TRAP	C#MSG	
1535						
1536	020264			BGNMSG	ERR031	
	020264			ERR031::		
1537	020264	004737	054136	CALL	CALR5	; PRINT HEADER INFO
1538	020270			PRINTB	#X31	
	020270	012746	013317	MOV	#X31,-(SP)	
	020274	012746	000001	MOV	#1,-(SP)	
	020300	010600		MOV	SP,R0	
	020302	104414		TRAP	C#PNTB	
	020304	062706	000004	ADD	#4,SP	
1539	020310			ENDMSG		
	020310			L10020:		
	020310	104423		TRAP	C#MSG	
1540						
1541	020312			BGNMSG	ERR032	; UNKNOWN ENCODE ERROR
	020312			ERR032::		
1542	020312	004737	054136	CALL	CALR5	; PRINT HEADER INFO
1543	020316			PRINTB	#X32,R3	; PRINT MESSAGE
	020316	010346		MOV	R3,-(SP)	

	020320	012746	013415	MOV	#X32, -(SP)	
	020324	012746	000002	MOV	#2, -(SP)	
	020330	010600		MOV	SP, R0	
	020332	104414		TRAP	C#PNTB	
	020334	062706	000006	ADD	#6, SP	
1544	020340	004737	022616	CALL	MSGPKT	; DUMP PACKET CONTENTS
1545	020344			ENDMSG		
	020344			L10021:		
	020344	104423		TRAP	C#MSG	
1546						
1547	020346			BGNMSG	ERR033	; UNKNOWN COMMAND STATUS ERROR
	020346			ERR033::		
1548	020346	004737	054136	CALL	CALR5	; PRINT HEADER INFO
1549	020352			PRINTX	#X33, R2	; PRINT MESSAGE
	020352	010246		MOV	R2, -(SP)	
	020354	012746	013526	MOV	#X33, -(SP)	
	020360	012746	000002	MOV	#2, -(SP)	
	020364	010600		MOV	SP, R0	
	020366	104415		TRAP	C#PNTX	
	020370	062706	000006	ADD	#6, SP	
1550	020374	004737	022616	CALL	MSGPKT	; DUMP END MESSAGE CONTENTS
1551	020400			ENDMSG		
	020400			L10022:		
	020400	104423		TRAP	C#MSG	
1552						
1553	020402			BGNMSG	ERR034	; INVALID COMMAND PACKET ERROR
	020402			ERR034::		
1554	020402	004737	054136	CALL	CALR5	; PRINT HEADER INFO
1555	020406	016504	000104	MOV	C.RHDR(R5), R4	; GET POINTER TO R.E.
1556	020412	016403	000020	MOV	P.STS+RE.RP(R4), R3	; GET STATUS WORD
1557	020416	000303		SWAB	R3	; GET HIGH
1558	020420	042703	177400	BIC	#C<377>, R3	; BYTE
1559	020424			PRINTX	#X34, R3	; PRINT MESSAGE
	020424	010346		MOV	R3, -(SP)	
	020426	012746	013635	MOV	#X34, -(SP)	
	020432	012746	000002	MOV	#2, -(SP)	
	020436	010600		MOV	SP, R0	
	020440	104415		TRAP	C#PNTX	
	020442	062706	000006	ADD	#6, SP	
1560	020446	004737	022616	CALL	MSGPKT	; DUMP END MESSAGE CONTENTS
1561	020452			ENDMSG		
	020452			L10023:		
	020452	104423		TRAP	C#MSG	
1562						
1563	020454			BGNMSG	ERR035	; UNKNOWN DRIVE ERROR
	020454			ERR035::		
1564	020454	004737	054136	CALL	CALR5	; PRINT HEADER INFO
1565	020460			PRINTB	#X35, R1	; PRINT ERROR MESSAGE
	020460	010146		MOV	R1, -(SP)	
	020462	012746	013754	MOV	#X35, -(SP)	
	020466	012746	000002	MOV	#2, -(SP)	
	020472	010600		MOV	SP, R0	
	020474	104414		TRAP	C#PNTB	
	020476	062706	000006	ADD	#6, SP	
1566	020502	004737	022616	CALL	MSGPKT	; DUMP PACKET CONTENTS

1567	020506			ENDMSG			
	020506			L10024:			
	020506	104423			TRAP	C#MSG	
1568							
1569	020510			BGNMSG	ERR037		; NXM ERROR
	020510			ERR037::			
1570	020510	004737	054136		CALL	CALR5	; PRINT HEADER INFO
1571	020514				PRINTB	#X37A	; PRINT
	020514	012746	014102		MOV	#X37A,-(SP)	
	020520	012746	000001		MOV	#1,-(SP)	
	020524	010600			MOV	SP,RO	
	020526	104414			TRAP	C#PNTB	
	020530	062706	000004		ADD	#4,SP	
1572	020534				PRINTX	#X37B	; ERROR
	020534	012746	014167		MOV	#X37B,-(SP)	
	020540	012746	000001		MOV	#1,-(SP)	
	020544	010600			MOV	SP,RO	
	020546	104415			TRAP	C#PNTX	
	020550	062706	000004		ADD	#4,SP	
1573	020554				PRINTX	#X37C	; MESSAGE
	020554	012746	014267		MOV	#X37C,-(SP)	
	020560	012746	000001		MOV	#1,-(SP)	
	020564	010600			MOV	SP,RO	
	020566	104415			TRAP	C#PNTX	
	020570	062706	000004		ADD	#4,SP	
1574	020574			ENDMSG			
	020574			L10025:			
	020574	104423			TRAP	C#MSG	
1575							
1576	020576			BGNMSG	ERR038		; MSCP PATTERN CHECK ERROR
	020576			ERR038::			
1577	020576	012704	004370		MOV	#8UFBA,R4	; CREATE CHARACTER STRING
1578	020602	004737	047552		CALL	BLDSTR	; CONTAINING LBN
1579	020606	004737	054270		CALL	CALR6	; PRINT HEADER INFO
1580	020612				PRINTB	#X38A	; PRINT
	020612	012746	014343		MOV	#X38A,-(SP)	
	020616	012746	000001		MOV	#1,-(SP)	
	020622	010600			MOV	SP,RO	
	020624	104414			TRAP	C#PNTB	
	020626	062706	000004		ADD	#4,SP	
1581	020632				PRINTX	#X38B,#TEMP,BCLO	; ERROR
	020632	013746	004406		MOV	BCLO,-(SP)	
	020636	012746	002212		MOV	#TEMP,-(SP)	
	020642	012746	014433		MOV	#X38B,-(SP)	
	020646	012746	000003		MOV	#3,-(SP)	
	020652	010600			MOV	SP,RO	
	020654	104415			TRAP	C#PNTX	
	020656	062706	000010		ADD	#10,SP	
1582	020662				PRINTX	#X38C,PCGOOD,PCBAD	; MESSAGE
	020662	013746	004366		MOV	PCBAD,-(SP)	
	020666	013746	004364		MOV	PCGOOD,-(SP)	
	020672	012746	014474		MOV	#X38C,-(SP)	
	020676	012746	000003		MOV	#3,-(SP)	
	020702	010600			MOV	SP,RO	
	020704	104415			TRAP	C#PNTX	

1583	020706	062706	000010		ADD	#10,SP	
	020712			ENDMSG			
	020712			L10026:			
	020712	104423			TRAP	C#MSG	
1584							
1585	020714			BGNMSG	ERR039		; MAINT PATTERN CHECK ERROR
	020714			ERR039::			
1586	020714	004737	054136		CALL	CALR5	; PRINT HEADER INFO
1587	020720				PRINTB	#X39A	; PRINT
	020720	012746	014545		MOV	#X39A,-(SP)	
	020724	012746	000001		MOV	#1,-(SP)	
	020730	010600			MOV	SP,RO	
	020732	104414			TRAP	C#PNTB	
	020734	062706	000004		ADD	#4,SP	
1588	020740				PRINTX	#X39B,BCLO	; ERROR
	020740	013746	004406		MOV	BCLO,-(SP)	
	020744	012746	014632		MOV	#X39B,-(SP)	
	020750	012746	000002		MOV	#2,-(SP)	
	020754	010600			MOV	SP,RO	
	020756	104415			TRAP	C#PNTX	
	020760	062706	000006		ADD	#6,SP	
1589	020764				PRINTX	#X39C,PCGOOD,PCBAD	; MESSAGE
	020764	013746	004366		MOV	PCBAD,-(SP)	
	020770	013746	004364		MOV	PCGOOD,-(SP)	
	020774	012746	014675		MOV	#X39C,-(SP)	
	021000	012746	000003		MOV	#3,-(SP)	
	021004	010600			MOV	SP,RO	
	021006	104415			TRAP	C#PNTX	
	021010	062706	000010		ADD	#10,SP	
1590	021014			ENDMSG			
	021014			L10027:			
	021014	104423			TRAP	C#MSG	
1591							
1592	021016			BGNMSG	ERR040		
	021016			ERR040::			
1593	021016	004737	054136		CALL	CALR5	; PRINT HEADER INFO
1594	021022				PRINTB	#X41,MSCPOP	; MSCP OPERATION FAILED
	021022	013746	002314		MOV	MSCPOP,-(SP)	
	021026	012746	014744		MOV	#X41,-(SP)	
	021032	012746	000002		MOV	#2,-(SP)	
	021036	010600			MOV	SP,RO	
	021040	104414			TRAP	C#PNTB	
	021042	062706	000006		ADD	#6,SP	
1595	021046				PRINTB	#XSTA,STAMSO,STAMS1	; PRINT STATUS
	021046	013746	002320		MOV	STAMS1,-(SP)	
	021052	013746	002316		MOV	STAMSO,-(SP)	
	021056	012746	016423		MOV	#XSTA,-(SP)	
	021062	012746	000003		MOV	#3,-(SP)	
	021066	010600			MOV	SP,RO	
	021070	104414			TRAP	C#PNTB	
	021072	062706	000010		ADD	#10,SP	
1596	021076	132764	000200	000017	BITB	#EF.BBR,P.FLGS+RE.RP(R4);	
1597	021104	001422			BEQ	1#	
1598	021106				PUSH	R4	; CONVERT
1599	021110	016504	000104		MOV	C.RHDR(R5),R4	; LBN TO

1600	021114	062704	000042		ADD	⊕<RE.RP+P.FBBK>,R4	:	ASCII
1601	021120	004737	047552		CALL	BLDSTR	:	STRING
1602	021124				POP	R4	:	
1603	021126				PRINTX	⊕MSGBBR,⊕TEMP	:	"BAD BLOCK REPORTED"
	021126	012746	002212		MOV	⊕TEMP,-(SP)		
	021132	012746	016267		MOV	⊕MSGBBR,-(SP)		
	021136	012746	000002		MOV	⊕2,-(SP)		
	021142	010600			MOV	SP,R0		
	021144	104415			TRAP	C⊕PNTX		
	021146	062706	000006		ADD	⊕6,SP		
1604	021152	132764	000100	000017	1⊕:	BITB	⊕EF.BBU,P.FLGS+RE.RP(R4);	
1605	021160	001410				BEQ	2⊕	
1606	021162				PRINTX	⊕MSGBBU	:	"BAD BLOCK UNREPORTED"
	021162	012746	016326		MOV	⊕MSGBBU,-(SP)		
	021166	012746	000001		MOV	⊕1,-(SP)		
	021172	010600			MOV	SP,R0		
	021174	104415			TRAP	C⊕PNTX		
	021176	062706	000004		ADD	⊕4,SP		
1607	021202	132764	000040	000017	2⊕:	BITB	⊕EF.LOG,P.FLGS+RE.RP(R4);	
1608	021210	001410				BEQ	3⊕	
1609	021212				PRINTX	⊕MSGLOG	:	"ERROR LOG GENERATED"
	021212	012746	016373		MOV	⊕MSGLOG,-(SP)		
	021216	012746	000001		MOV	⊕1,-(SP)		
	021222	010600			MOV	SP,R0		
	021224	104415			TRAP	C⊕PNTX		
	021226	062706	000004		ADD	⊕4,SP		
1610	021232	004737	022616		3⊕:	CALL	MSGPKT	
1611	021236				ENDMSG			
	021236				L10030:			
	021236	104423			TRAP	C⊕MSG		
1612								
1613	021240				BGNMSG	ERR041		
	021240				ERR041::			
1614	021240	004737	054270		CALL	CALR6	:	PRINT HEADER INFO
1615	021244				PRINTB	⊕X41,MSCP0P	:	MSCP OPERATION FAILED
	021244	013746	002314		MOV	MSCP0P,-(SP)		
	021250	012746	014744		MOV	⊕X41,-(SP)		
	021254	012746	000002		MOV	⊕2,-(SP)		
	021260	010600			MOV	SP,R0		
	021262	104414			TRAP	C⊕PNTB		
	021264	062706	000006		ADD	⊕6,SP		
1616	021270				PRINTB	⊕XSTA,STAMSO,STAMS1	:	PRINT STATUS
	021270	013746	002320		MOV	STAMS1,-(SP)		
	021274	013746	002316		MOV	STAMSO,-(SP)		
	021300	012746	016423		MOV	⊕XSTA,-(SP)		
	021304	012746	000003		MOV	⊕3,-(SP)		
	021310	010600			MOV	SP,R0		
	021312	104414			TRAP	C⊕PNTB		
	021314	062706	000010		ADD	⊕10,SP		
1617	021320	132764	000200	000017		BITB	⊕EF.BBR,P.FLGS+RE.RP(R4);	
1618	021326	001422				BEQ	1⊕	
1619	021330				PUSH	R4	:	CONVERT
1620	021332	016504	000104		MOV	C.RHDR(R5),R4	:	LBN TO
1621	021336	062704	000042		ADD	⊕<RE.RP+P.FBBK>,R4	:	ASCII
1622	021342	004737	047552		CALL	BLDSTR	:	STRING

```

1623 021346      POP      R4
1624 021350      PRINTX  #MSGBBR,#TEMP      ; "BAD BLOCK REPORTED"
      021350 012746 002212      MOV      #TEMP,-(SP)
      021354 012746 016267      MOV      #MSGBBR,-(SP)
      021360 012746 000002      MOV      #2,-(SP)
      021364 010600      MOV      SP,R0
      021366 104415      TRAP    C#PNTX
      021370 062706 000006      ADD      #6,SP
1625 021374 132764 000100 000017 1$: BITB    #EF.BBU,P.FLGS+RE.RP(R4);
1626 021402 001410      BEQ      2$
1627 021404      PRINTX  #MSGBBU      ; "BAD BLOCK UNREPORTED"
      021404 012746 016326      MOV      #MSGBBU,-(SP)
      021410 012746 000001      MOV      #1,-(SP)
      021414 010600      MOV      SP,R0
      021416 104415      TRAP    C#PNTX
      021420 062706 000004      ADD      #4,SP
1628 021424 132764 000040 000017 2$: BITB    #EF.LOG,P.FLGS+RE.RP(R4);
1629 021432 001410      BEQ      3$
1630 021434      PRINTX  #MSGLOG      ; "ERROR LOG GENERATED"
      021434 012746 016373      MOV      #MSGLOG,-(SP)
      021440 012746 000001      MOV      #1,-(SP)
      021444 010600      MOV      SP,R0
      021446 104415      TRAP    C#PNTX
      021450 062706 000004      ADD      #4,SP
1631 021454 004737 022616      3$: CALL   MSGPKT
1632 021460      ENDMSG
      021460      L10031: TRAP   C#MSG
1633 021462      BGNMSG ERR042
1634 021462      ERR042:: ; CONTROLLER DROPPED ERROR
1635 021462 004737 054136      CALL   CALR5      ; PRINT HEADER INFO
1636 021466      PRINTB #X42A      ;
      021466 012746 015001      MOV      #X42A,-(SP)
      021472 012746 000001      MOV      #1,-(SP)
      021476 010600      MOV      SP,R0
      021500 104414      TRAP    C#PNTB
      021502 062706 000004      ADD      #4,SP
1637 021506      PRINTB #X42B      ;
      021506 012746 015077      MOV      #X42B,-(SP)
      021512 012746 000001      MOV      #1,-(SP)
      021516 010600      MOV      SP,R0
      021520 104414      TRAP    C#PNTB
      021522 062706 000004      ADD      #4,SP
1638 021526 005065 000042      CLR     C.NEXT(R5)      ; INIT DRIVE COUNT
1639 021532 004737 045526      1$: CALL   GTNXTD      ; GET POINTER TO NEXT DRIVE TABLE
1640 021536 001422      BEQ      10$      ; IF NO MORE DRIVES, EXIT
1641 021540 052760 100000 000002      BIS     #DT.AVL,D.UNIT(R0) ; DISABLE DRIVE
1642 021546      PRINTB #X42C,(R0)      ; PRINT DRIVE NUMBER
      021546 011046      MOV      (R0),-(SP)
      021550 012746 015145      MOV      #X42C,-(SP)
      021554 012746 000002      MOV      #2,-(SP)
      021560 010600      MOV      SP,R0
      021562 104414      TRAP    C#PNTB
      021564 062706 000006      ADD      #6,SP
    
```

```

1643 021570 005265 000042          INC      C.NEXT(R5)          ; POINT TO NEXT DRIVE
1644 021574 022765 000003 000042  CMP      #3..C.NEXT(R5)    ; IF DRIVE COUNT <= 3,
1645 021602 002353                    BGE      1#                ; GET NEXT DRIVE
1646 021604                    10# : PRINTB  #CRLF          ; TERMINATE LINE
      021604 012746 010300          MOV      #CRLF, -(SP)
      021610 012746 000001          MOV      #1, -(SP)
      021614 010600          MOV      SP, R0
      021616 104414          TRAP    C#PNTB
      021620 062706 000004          ADD      #4, SP
1647 021624                    ENDMSG
      021624                    L10032:
      021624 104423          TRAP    C#MSG
1648
1649 021626                    BGNMSG ERR043
      021626                    ERR043:
      1650 021626 004737 054270          CALL    CALR6              ; DRIVE DROPPED ERROR
1651 021632                    PRINTB  #X43          ; PRINT HEADER INFO
      021632 012746 015154          MOV      #X43, -(SP)      ; PRINT ERROR MESSAGE
      021636 012746 000001          MOV      #1, -(SP)
      021642 010600          MOV      SP, R0
      021644 104414          TRAP    C#PNTB
      021646 062706 000004          ADD      #4, SP
1652 021652                    ENDMSG
      021652                    L10033:
      021652 104423          TRAP    C#MSG
1653
1654 021654                    BGNMSG ERR050
      021654                    ERR050:
      1655 021654 004737 054136          CALL    CALR5              ; PRINT HEADER INFO
1656 021660                    PRINTB  #X50A          ; PRINT ERROR LOG RECEIVED
      021660 012746 015253          MOV      #X50A, -(SP)
      021664 012746 000001          MOV      #1, -(SP)
      021670 010600          MOV      SP, R0
      021672 104414          TRAP    C#PNTB
      021674 062706 000004          ADD      #4, SP
1657 021700 004737 022334          CALL    ERLSTA            ; DO COMMON STUFF
1658 021704                    ENDMSG
      021704                    L10034:
      021704 104423          TRAP    C#MSG
1659
1660 021706                    BGNMSG ERR051
      021706                    ERR051:
      1661 021706 004737 054136          CALL    CALR5              ; PRINT HEADER INFO
1662 021712                    PRINTB  #X51A          ; PRINT ERROR LOG RECEIVED
      021712 012746 015325          MOV      #X51A, -(SP)
      021716 012746 000001          MOV      #1, -(SP)
      021722 010600          MOV      SP, R0
      021724 104414          TRAP    C#PNTB
      021726 062706 000004          ADD      #4, SP
1663 021732                    PUSH    R4
      1664 021734 016504 000104          MOV      C.RHDR(R5), R4    ; CONVERT
      1665 021740 062704 000036          ADD      #<RE.RP+L.BADR>, R4 ; ADDRESS
      1666 021744 004737 047552          CALL    BLDSTR            ; TO
      1667 021750                    POP     R4                ; ASCII
1668 021752                    PRINTB  #X51B, #TEMP      ; STRING
    
```

	021752	012746	002212	MOV	#TEMP, -(SP)	
	021756	012746	015407	MOV	#X51B, -(SP)	
	021762	012746	000002	MOV	#2, -(SP)	
	021766	010600		MOV	SP, R0	
	021770	104414		TRAP	C#PNTB	
	021772	062706	000006	ADD	#6, SP	
1669	021776	004737	022334	CALL	ERLSTA	; DO COMMON STUFF
1670	022002			ENDMSG		
	022002			L10035:		
	022002	104423		TRAP	C#MSG	
1671						
1672	022004			BGNMSG	ERR052	
	022004			ERR052::		
1673	022004	004737	054270	CALL	CALR6	; PRINT HEADER INFO
1674	022010			PRINTB	#X52A	; PRINT ERROR LOG RECEIVED
	022010	012746	015443	MOV	#X52A, -(SP)	
	022014	012746	000001	MOV	#1, -(SP)	
	022020	010600		MOV	SP, R0	
	022022	104414		TRAP	C#PNTB	
	022024	062706	000004	ADD	#4, SP	
1675	022030			PUSH	<R3, R4>	; GET
1676	022034	016504	000104	MOV	C.RHDR(R5), R4	LEVEL &
1677	022040	062704	000050	ADD	#<RE.RP+L.LVL>, R4	RETRIES
1678	022044	010403		MOV	R4, R3	
1679	022046	005203		INC	R3	
1680	022050	111404		MOVB	(R4), R4	
1681	022052	042704	177400	BIC	#C<377>, R4	
1682	022056	111303		MOVB	(R3), R3	
1683	022060	042703	177400	BIC	#C<377>, R3	
1684	022064			PRINTB	#X52B, R3, R4	
	022064	010446		MOV	R4, -(SP)	
	022066	010346		MOV	R3, -(SP)	
	022070	012746	015520	MOV	#X52B, -(SP)	
	022074	012746	000003	MOV	#3, -(SP)	
	022100	010600		MOV	SP, R0	
	022102	104414		TRAP	C#PNTB	
	022104	062706	000010	ADD	#10, SP	
1685	022110			POP	<R4, R3>	
1686	022114	004737	022334	CALL	ERLSTA	; DO COMMON STUFF
1687	022120			ENDMSG		
	022120			L10036:		
	022120	104423		TRAP	C#MSG	
1688						
1689	022122			BGNMSG	ERR053	
	022122			ERR053::		
1690	022122	004737	054270	CALL	CALR6	; PRINT HEADER INFO
1691	022126			PRINTB	#X53A	; PRINT ERROR LOG RECEIVED
	022126	012746	015573	MOV	#X53A, -(SP)	
	022132	012746	000001	MOV	#1, -(SP)	
	022136	010600		MOV	SP, R0	
	022140	104414		TRAP	C#PNTB	
	022142	062706	000004	ADD	#4, SP	
1692	022146			PUSH	R4	; GET
1693	022150	016504	000104	MOV	C.RHDR(R5), R4	SDI
1694	022154	062704	000062	ADD	#<RE.RP+L.SDI>, R4	STATUS

```

1693 022160          PRINTB  @X53B,10.(R4),8.(R4),6(R4),4(R4),2(R4),(R4);
      022160 011446          MOV      (R4),-(SP)
      022162 016446 000002          MOV      2(R4),-(SP)
      022166 016446 000004          MOV      4(R4),-(SP)
      022172 016446 000006          MOV      6(R4),-(SP)
      022176 016446 000010          MOV      8.(R4),-(SP)
      022202 016446 000012          MOV      10.(R4),-(SP)
      022206 012746 015636          MOV      @X53B, -(SP)
      022212 012746 000007          MOV      @7, -(SP)
      022216 010600          MOV      SP, R0
      022220 104414          TRAP     C#PNTB
      022222 062706 000020          ADD      @20, SP
1696 022226          POP      R4
1697 022230 004737 022334          CALL     ERLSTA ; DO COMMON STUFF
1698 022234          ENDMSG
      022234          L10037:
      022234 104423          TRAP     C#MSG
1699
1700 022236          BGNMSG ERR054
      022236          ERR054:
1701 022236 004737 054270          CALL     CALR6 ; PRINT HEADER INFO
1702 022242          PRINTB  @X54A ; PRINT ERROR LOG RECEIVED
      022242 012746 015731          MOV      @X54A, -(SP)
      022246 012746 000001          MOV      @1, -(SP)
      022252 010600          MOV      SP, R0
      022254 104414          TRAP     C#PNTB
      022256 062706 000004          ADD      @4, SP
1703 022262          PUSH     R4 ; CONVERT
1704 022264 016504 000104          MOV      C.RHDR(R5), R4 ; CYLINDER
1705 022270 062704 000050          ADD      @<RE.RP+L.SCYL>, R4 ; TO
1706 022274 004737 047552          CALL     BLDSTR ; ASCII
1707 022300          POP      R4 ; STRING
1708 022302          PRINTB  @X54B, @TEMP ;
      022302 012746 002212          MOV      @TEMP, -(SP)
      022306 012746 016C03          MOV      @X54B, -(SP)
      022312 012746 000002          MOV      @2, -(SP)
      022316 010600          MOV      SP, R0
      022320 104414          TRAP     C#PNTB
      022322 062706 000006          ADD      @6, SP
1709 022326 004737 022334          CALL     ERLSTA ; DO COMMON STUFF
1710 022332          ENDMSG
      022332          L10040:
      022332 104423          TRAP     C#MSG
1711
1712 022334 032704 000200          ERLSTA: BIT      @LF.SUC, R4 ; SUCCESS?
1713 022340 001014          BNE     2$ ;
1714 022342 032704 000100          1$: BIT      @LF.CON, R4 ;
1715 022346 001022          BNE     3$ ;
1716 022350          PRINTX  @MSGFAI ; "OPERATION FAILED"
      022350 012746 016160          MOV      @MSGFAI, -(SP)
      022354 012746 000001          MOV      @1, -(SP)
      022360 010600          MOV      SP, R0
      022362 104415          TRAP     C#PNTX
      022364 062706 000004          ADD      @4, SP
1717 022370 000421          BR      4$ ;
    
```

1718	022372			2#:	PRINTX	@MSG SUC		: "OPERATION SUCCESSFUL"
	022372	012746	016205		MOV	@MSG SUC, -(SP)		
	022376	012746	000001		MOV	#1, -(SP)		
	022402	010600			MOV	SP, R0		
	022404	104415			TRAP	C#PNTX		
	022406	062706	000004		ADD	#4, SP		
1719	022412	000410			BR	#4		
1720	022414			3#:	PRINTX	@MSG CON		: "OPERATION CONTINUING"
	022414	012746	016236		MOV	@MSG CON, -(SP)		
	022420	012746	000001		MOV	#1, -(SP)		
	022424	010600			MOV	SP, R0		
	022426	104415			TRAP	C#PNTX		
	022430	062706	000004		ADD	#4, SP		
1721	022434			4#:	PRINTB	@XSTA, STAMSO, STAMS1		: PRINT STATUS
	022434	013746	002320		MOV	STAMS1, -(SP)		
	022440	013746	002316		MOV	STAMSO, -(SP)		
	022444	012746	016423		MOV	@XSTA, -(SP)		
	022450	012746	000003		MOV	#3, -(SP)		
	022454	010600			MOV	SP, R0		
	022456	104414			TRAP	C#PNTB		
	022460	062706	000010		ADD	#10, SP		
1722	022464	004737	022616		CALL	MSGPKT		: DUMP MESSAGE PACKET
1723	022470	000207			RETURN			:
1724								
1725	022472				BGNMSG	ERR060		
	022472				ERR060::			
1726	022472	004737	054270		CALL	CALR6		: PRINT HEADER INFO
1727	022476				PRINTB	@ATNMSG, @AMAV		:
	022476	012746	007505		MOV	@AMAV, -(SP)		
	022502	012746	011147		MOV	@ATNMSG, -(SP)		
	022506	012746	000002		MOV	#2, -(SP)		
	022512	010600			MOV	SP, R0		
	022514	104414			TRAP	C#PNTB		
	022516	062706	000006		ADD	#6, SP		
1728	022522				PRINTB	@X60		: PRINT ERROR LOG RECEIVED
	022522	012746	016024		MOV	@X60, -(SP)		
	022526	012746	000001		MOV	#1, -(SP)		
	022532	010600			MOV	SP, R0		
	022534	104414			TRAP	C#PNTB		
	022536	062706	000004		ADD	#4, SP		
1729	022542				ENDMSG			
	022542				L10041:			
	022542	104423			TRAP	C#MSG		
1730								
1731	022544				BGNMSG	ERR061		
	022544				ERR061::			
1732	022544	004737	054270		CALL	CALR6		: PRINT HEADER INFO
1733	022550				PRINTB	@ATNMSG, @AMDU		:
	022550	012746	007521		MOV	@AMDU, -(SP)		
	022554	012746	011147		MOV	@ATNMSG, -(SP)		
	022560	012746	000002		MOV	#2, -(SP)		
	022564	010600			MOV	SP, R0		
	022566	104414			TRAP	C#PNTB		
	022570	062706	000006		ADD	#6, SP		
1734	022574				PRINTB	@X61		: PRINT ERROR LOG RECEIVED

022574	012746	016077		MOV	#X61,-(SP)	
022600	012746	000001		MOV	#1,-(SP)	
022604	010600			MOV	SP,R0	
022606	104414			TRAP	C#PNTB	
022610	062706	000004		ADD	#4,SP	
1735	022614			ENDMSG		
	022614			L10042:		
	022614	104423		TRAP	C#MSG	
1736						
1737				;++		
1738				;	MSGPKT - PRINT CONTENTS OF MESSAGE BUFFER FOR ERROR MESSAGES	
1739				;-		
1740						
1741	022616			MSGPKT:	PUSH <R2>	; SAVE REGISTERS
	022616	010246			MOV R2,-(SP)	; PUSH R2 ON STACK
1742	022620			PRINTX	#XMSG1	
	022620	012746	016612	MOV	#XMSG1,-(SP)	
	022624	012746	000001	MOV	#1,-(SP)	
	022630	010600		MOV	SP,R0	
	022632	104415		TRAP	C#PNTX	
	022634	062706	000004	ADD	#4,SP	
1743	022640	016504	000104	MOV	C,RHDR(R5),R4	
1744	022644	016402	000002	MOV	2(R4),R2	; GET MESSAGE LENGTH IN BYTES
1745	022650	062704	000006	ADD	#RE,RP,R4	; POINT TO MESSAGE
1746	022654	012703	000006	MOV	#6,R3	; GET COUNT OF WORDS / LINE
1747	022660			1\$: PRINTX	#XMSG2,(R4)+	
	022660	012446		2\$: MOV	(R4)+,-(SP)	
	022662	012746	016647	MOV	#XMSG2,-(SP)	
	022666	012746	000002	MOV	#2,-(SP)	
	022672	010600		MOV	SP,R0	
	022674	104415		TRAP	C#PNTX	
	022676	062706	000006	ADD	#6,SP	
1748	022702	162702	000002	SUB	#2,R2	; IF NOT POSITIVE,
1749	022706	003413		BLE	5\$; DONE PRINTING.
1750	022710	005303		DEC	R3	; IF NOT ZERO,
1751	022712	001362		BNE	2\$; PRINT NEXT WORD
1752	022714			PRINTX	#CRLF	; ELSE, TERMINATE LINE
	022714	012746	010300	MOV	#CRLF,-(SP)	
	022720	012746	000001	MOV	#1,-(SP)	
	022724	010600		MOV	SP,R0	
	022726	104415		TRAP	C#PNTX	
	022730	062706	000004	ADD	#4,SP	
1753	022734	000747		BR	1\$; PRINT REMAINDER OF PACKET
1754	022736			5\$: PRINTX	#CRLF	; MAKE SURE LINE IS TERMINATED.
	022736	012746	010300	MOV	#CRLF,-(SP)	
	022742	012746	000001	MOV	#1,-(SP)	
	022746	010600		MOV	SP,R0	
	022750	104415		TRAP	C#PNTX	
	022752	062706	000004	ADD	#4,SP	
1755	022756			POP	<R2>	; RESTORE SAVED REGISTERS
1756	022760	000207		RETURN		
1757						
1759	022762	000000		DBGFLG:	.WORD 0	; FLAGS FOR DEBUG
1760						; BIT0 - DUMP CMD PKT
1761						; BIT1 - DUMP RSP PKT

```

1762
1763
1764 022764 045 101 103 DBGSND: .ASCIZ /%ACOMMAND SENT#N/ ; BIT2 - CMD SENT MSG
1765 023005 045 101 101 DBGATN: .ASCIZ /%AATTENTION MESSAGE#N/ ; BIT3 - RSP RCVD MSG
1766 023033 045 101 111 DBGINV: .ASCIZ /%AINVALID COMMAND#N/
1767 023057 045 101 062 DBGGCS: .ASCIZ /%A202 - GET COMMAND STATUS END PACKET#N/
1768 023127 045 101 062 DBGGUS: .ASCIZ /%A203 - GET UNIT STATUS END PACKET#N/
1769 023174 045 101 062 DBGSCC: .ASCIZ /%A204 - SET CONTROLLER CHARACTERISTICS#N/
1770 023245 045 101 062 DBGAVL: .ASCIZ /%A210 - AVAILABLE END PACKET#N/
1771 023304 045 101 062 DBGONL: .ASCIZ /%A211 - ONLINE END PACKET#N/
1772 023340 045 101 062 DBGSUC: .ASCIZ /%A212 - SET UNIT CHARACTERISTICS #N/
1773 023404 045 101 062 DBGACC: .ASCIZ /%A220 - ACCESS END PACKET#N/
1774 023440 045 101 062 DBGERS: .ASCIZ /%A222 - ERASE END PACKET#N/
1775 023473 045 101 062 DBGMRD: .ASCIZ /%A230 - MAINTENANCE READ#N/
1776 023526 045 101 062 DBGMWR: .ASCIZ /%A231 - MAINTENANCE WRITE#N/
1777 023562 045 101 062 DBGCMP: .ASCIZ /%A240 - COMPARE HOST DATA#N/
1778 023616 045 101 062 DBGRD: .ASCIZ /%A241 - READ END PACKET#N/
1779 023650 045 101 062 DBGWR: .ASCIZ /%A242 - WRITE END PACKET#N/
1780
1781
1782 ;++
1783 ; DBGCMD - DUMP COMMAND PACKET FOR DEBUG PURPOSES
1784 ;--
1785 023704 DBGCMD: PUSH <R3,R4>
1786 023710 032737 000004 022762 BIT #BIT2,DBGFLG
1787 023716 001502 BEQ 90$
1788 023720 PRINTF #DBGSND
023720 012746 022764 MOV #DBGSND,-(SP)
023724 012746 000001 MOV #1,-(SP)
023730 010600 MOV SP,R0
023732 104417 TRAP C#PNTF
023734 062706 000004 ADD #4,SP
1789 023740 032737 000001 022762 BIT #BIT0,DBGFLG
1790 023746 001466 BEQ 90$
1791 023750 PRINTF #XMSG1
023750 012746 016612 MOV #XMSG1,-(SP)
023754 012746 000001 MOV #1,-(SP)
023760 010600 MOV SP,R0
023762 104417 TRAP C#PNTF
023764 062706 000004 ADD #4,SP
1792 023770 PRINTF #XMSG2,(R4),2(R4),4(R4),14.(R4),16.(R4),18.(R4)
023770 016446 000022 MOV 18.(R4),-(SP)
023774 016446 000020 MOV 16.(R4),-(SP)
024000 016446 000016 MOV 14.(R4),-(SP)
024004 016446 000004 MOV 4(R4),-(SP)
024010 016446 000002 MOV 2(R4),-(SP)
024014 011446 MOV (R4),-(SP)
024016 012746 016647 MOV #XMSG2,-(SP)
024022 012746 000007 MOV #7,-(SP)
024026 010600 MOV SP,R0
024030 104417 TRAP C#PNTF
024032 062706 000020 ADD #20,SP
1793 024036 062704 000026 ADD #ME,CP,R4
1794 024042 012703 000005 MOV #5,R3
1795 024046 ; PRINTF #XMSG2,(R4),2(R4),4(R4),6(R4),8.(R4),10.(R4)
    
```

	024046	016446	000012		MOV	10.(R4),-(SP)
	024052	016446	000010		MOV	8.(R4),-(SP)
	024056	016446	000006		MOV	6(R4),-(SP)
	024062	016446	000004		MOV	4(R4),-(SP)
	024066	016446	000002		MOV	2(R4),-(SP)
	024072	011446			MOV	(R4),-(SP)
	024074	012746	016647		MOV	#XMSG2, -(SP)
	024100	012746	000007		MOV	#7, -(SP)
	024104	010600			MOV	SP, R0
	024106	104417			TRAP	C#PNTF
	024110	062706	000020		ADD	#20, SP
1796	024114	062704	000014		ADD	#12., R4
1797	024120	005303			DEC	R3
1798	024122	001351			BNE	1#
1799	024124			90#:	POP	<R4, R3>
1800	024130	000207			RETURN	
1801						
1802				;++		
1803				:	DBGRSP - DUMP RESPONSE PACKET FOR DEBUG PURPOSES	
1804				!--		
1805						
1806	024132	032737	000010	022762	DBGRSP: BIT	#BIT3, DBGFLG
1807	024140	001462			BEQ	90#
1808	024142				PRINTF	R0
	024142	010046			MOV	R0, -(SP)
	024144	012746	000001		MOV	#1, -(SP)
	024150	010600			MOV	SP, R0
	024152	104417			TRAP	C#PNTF
	024154	062706	000004		ADD	#4, SP
1809	024160	032737	000002	022762	BIT	#BIT1, DBGFLG
1810	024166	001447			BEQ	90#
1811	024170				PUSH	<R3, R4>
1812	024174				PRINTF	#XMSG1
	024174	012746	016612		MOV	#XMSG1, -(SP)
	024200	012746	000001		MOV	#1, -(SP)
	024204	010600			MOV	SP, R0
	024206	104417			TRAP	C#PNTF
	024210	062706	000004		ADD	#4, SP
1813	024214	016504	000104		MOV	C, RHDR(R5), R4
1814	024220	012703	000005		MOV	#5, R3
1815	024224			1#:	PRINTF	#XMSG2 (R4), 2(R4), 4(R4), 6(R4), 8.(R4), 10.(R4)
	024224	016446	000012		MOV	10.(R4), -(SP)
	024230	016446	000010		MOV	8.(R4), -(SP)
	024234	016446	000006		MOV	6(R4), -(SP)
	024240	016446	000004		MOV	4(R4), -(SP)
	024244	016446	000002		MOV	2(R4), -(SP)
	024250	011446			MOV	(R4), -(SP)
	024252	012746	016647		MOV	#XMSG2, -(SP)
	024256	012746	000007		MOV	#7, -(SP)
	024262	010600			MOV	SP, R0
	024264	104417			TRAP	C#PNTF
	024266	062706	000020		ADD	#20, SP
1816	024272	062704	000014		ADD	#12., R4
1817	024276	005303			DEC	R3
1818	024300	001351			BNE	1#

1819 024302
1820 024306 000207

90\$: POP <R4,R3>
RETURN

```
1823      .SBTTL  GLOBAL SUBROUTINES SECTION
1824
1825      :++
1826      :      BADMEM - PROGRAM DATA STRUCTURES HAVE BEEN CORRUPTED.
1827      :
1828      :      THIS ROUTINE PRINTS A SYSTEM FATAL ERROR AND EXITS THE TEST
1829      :--
1830
1831 024310  BADMEM: ERRSF 6, ERR006          ; SYSTEM FATAL MEMORY CORRUPTION ERROR
      024310  TRAP  C$ERSF
      024312  .WORD 6
      024314  .WORD 0
      024316  .WORD ERR006
1832 024320  DOCLN          ; DO CLEAN-UP TRAP
      024320  TRAP  C$DCLN
```

1834
 1835
 1836
 1837
 1838
 1839
 1840
 1841
 1842
 1843
 1844
 1845
 1846
 1847
 1848
 1849
 1850
 1851
 1852
 1853
 1854
 1855
 1856
 1857
 1858
 1859
 1860
 1861

024322 013746 002166
 024322 160137 002170
 024326 002002
 024334 000137 062574
 024340 060101
 024342 060137 002166
 024346 012601
 024350 000240
 024352 000207

```

:++
: ALOCM - ALLOCATE A BLOCK OF FREE MEMORY. REPORT ERROR IF MEMORY
: EXHAUSTED.
:
: INPUTS:
: R1 - NUMBER OF WORDS TO ALLOCATE
: FFREE - FIRST FREE WORD IN MEMORY
: FSIZE - SIZE OF FREE MEMORY AVAILABLE IN WORDS
:
: OUTPUTS:
: R1 - ADDRESS OF FIRST WORD OF ALLOCATED MEMORY
: FFREE - NEW FIRST FREE WORD IN MEMORY
: FSIZE - SIZE OF FREE MEMORY LEFT AFTER ALLOCATION
:
: SYSTEM FATAL ERROR WILL BE REPORTED IF NOT ENOUGH MEMORY AVAILABLE
: AND ENTIRE PROGRAM WILL BE STOPPED.
:--
:
: ALOCM: PUSH <FFREE> ; SAVE FFREE AT ENTRY
: MOV FFREE, -(SP) ; PUSH FFREE ON STACK
: SUB R1, FSIZE ; REDUCE SIZE OF FREE MEMORY
: BGE 1$ ;
: JMP NOMEM ; REPORT ERROR IF NOT ENOUGH MEMORY
1$: ADD R1, R1 ; CHANGE WORDS TO BYTES
: ADD R1, FFREE ; CALCULATE NEW START OF FREE MEMORY
: POP <R1> ; GET START OF ALLOCATED MEMORY
: MOV (SP)+, R1 ; POP STACK INTO R1
:
: NOP ; [DBG] INSERT HALT HERE FOR DEBUG
:
: RETURN
    
```

```

1863
1864
1865      ;++
1866      ; GETBUF - GET A BUFFER FROM THE FREE BUFFER POOL
1867      ;
1868      ; INPUTS:
1869      ; R1 - REQUESTED PACKET SIZE (BLOCKS)
1870      ;
1871      ; OUTPUTS:
1872      ; R1 - ALLOCATED PACKET SIZE (BLOCKS)
1873      ; R3 - BYTE OFFSET INTO MAPPED MEMORY
1874      ; BCLO,BCHI - BYTE COUNT OF BUFFER
1875      ; BUFBA,BUFEA - STARTING ADDRESS OF BUFFER
1876      ;--
1876      024354 010046 GETBUF: PUSH <R0,R2,R4,R5> ; SAVE REGISTER CONTENTS
1877      024354 010246 MOV R0,-(SP) ; PUSH R0 ON STACK
1878      024356 010446 MOV R2,-(SP) ; PUSH R2 ON STACK
1879      024360 010446 MOV R4,-(SP) ; PUSH R4 ON STACK
1880      024362 010546 MOV R5,-(SP) ; PUSH R5 ON STACK
1881      024364 004737 024570 CALL BESFIT ; FIND A BUFFER
1882      024370 005705 TST R5 ; IF ZERO, NO BUFFER
1883      024372 001463 BEQ 80$ ; AVAILABLE
1884      024374 020501 CMP R5,R1 ; COMPARE GOT W/ NEEDED
1885      024376 001452 BEQ 40$ ; IF EQUAL, USE THE BUFFER
1886      024400 003006 BGT 11$ ; IF GREATER, ONLY GET WHAT'S NEEDED
1887      024402 004737 024702 CALL BUFMRG ; MERGE ADJACENT FREE BLOCKS
1888      024406 004737 024570 CALL BESFIT ; FIND A BUFFER
1889      024412 020501 10$: CMP R5,R1 ; COMPARE GOT W/ NEEDED
1890      024414 101443 BLOS 40$ ; IF LE, USE ENTIRE BUFFER
1891      024416 013703 004624 11$: MOV F.HDR,R3 ; GET FREE PACKET
1892      024422 001004 BNE 12$ ; IF NOT ZERO, CONTINUE
1893      024424 012701 024422 MOV #.-2,R1 ; SAVE CURRENT LOCATION
1894      024430 000137 024310 JMP BADMEM ; PRINT SYSTEM FATAL ERROR
1895      024434 011337 004624 12$: MOV (R3),F.HDR ; ADJUST
1896      024440 011413 MOV (R4),(R3) ; ALL OF THE
1897      024442 010314 MOV R3,(R4) ; FORWARD LINKS
1898      024444 160105 SUB R1,R5 ; SUBTRACT SIZE NEEDED
1899      024446 042764 000377 000002 BIC #377,2(R4) ; SAVE REMAINING
1900      024454 050564 000002 BIS R5,2(R4) ; BUFFER SIZE
1901      024460 PUSH <R4,R3,R1> ; SAVE REGISTERS
1902      024460 010446 MOV R4,-(SP) ; PUSH R4 ON STACK
1903      024462 010346 MOV R3,-(SP) ; PUSH R3 ON STACK
1904      024464 010146 MOV R1,-(SP) ; PUSH R1 ON STACK
1905      024466 010501 MOV R5,R1 ; CONVERT BLOCKS
1906      024470 004737 045502 CALL GETBC ; TO BYTES
1907      024474 POP <R1,R3,R4> ; RESTORE REGISTERS
1908      024474 012601 MOV (SP)+,R1 ; POP STACK INTO R1
1909      024476 012603 MOV (SP)+,R3 ; POP STACK INTO R3
1910      024500 012604 MOV (SP)+,R4 ; POP STACK INTO R4
1911      024502 066437 000004 004406 ADD 4(R4),BCLO ; CALCULATE NEW OFFSET
1912      024510 013763 004406 000004 MOV BCLO,4(R3) ; SAVE OFFSET TO NEW BUFFER
1913      024516 010163 000002 MOV R1,2(R3) ; SAVE NEW BUFFER SIZE
1914      024522 000402 BR 50$ ;
1915      024524 010403 40$: MOV R4,R3 ; POINT TO NEEDED PACKET
1916      024526 010501 MOV R5,R1 ; GET ALLOCATED PACKET SIZE
1917      024530 105263 000003 50$: INCB 3(R3) ; INCREMENT # OF USERS COUNTER
    
```

```

1908 024534 016303 000004      MOV    4(R3),R3      ; GET OFFSET
1909 024540 000403              BR     90$          ;
1910                          ;
1911 024542 012703 177777      80$:  MOV    #-1,R3   ; NO MEMORY LEFT, GENERATE OFFSET
1912 024546 005001              CLR    R1           ; SET SIZE TO ZERO
1913                          ;
1914 024550 004737 025006      90$:  CALL   MAPMEM   ; GET PHYSICAL ADDRESS & BYTE COUNT
1915 024554 000240              NOP                ; [DBG] INSERT HALT FOR DEBUG
1916 024556              POP    <R5,R4,R2,R0> ; RESTORE SAVED REGISTERS
1917 024556 012605              MOV    (SP)+,R5    ; POP STACK INTO R5
1918 024560 012604              MOV    (SP)+,R4    ; POP STACK INTO R4
1919 024562 012602              MOV    (SP)+,R2    ; POP STACK INTO R2
1920 024564 012600              MOV    (SP)+,R0    ; POP STACK INTO R0
1921 024566 000207              RETURN            ;
1922                          ;
1923                          ;++
1924                          ;
1925                          ;
1926                          ;
1927                          ;
1928                          ;++
1929 024570 005005      BESFIT: CLR    R5      ; INITIALIZE TEMPORARY
1930 024572 005004      CLR    R4      ; POINTERS
1931 024574 013703 004622      MOV    M.HDR,R3 ; GET POINTER TO AVAILABLE LIST
1932 024600 001004              BNE    10$      ; IF NOT END OF LIST, CONTINUE
1933 024602 012701 024600      MOV    #-2,R1   ; SAVE CURRENT LOCATION
1934 024606 000137 024310      JMP    BADMEM   ; PRINT SYSTEM FATAL ERROR
1935 024612 105763 000003      10$:  TSTB   3(R3)  ; IF NUMBER OF USERS IS NOT 0
1936 024616 001025              BNE    30$      ; GET NEXT PACKET
1937 024620 116300 000002      MOVB   2(R3),R0 ; GET BUFFER SIZE
1938 024624 001004              BNE    20$      ; IF NOT ZERO, CONTINUE
1939 024626 012701 024624      MOV    #-2,R1   ; SAVE CURRENT LOCATION
1940 024632 000137 024310      JMP    BADMEM   ; PRINT SYSTEM FATAL ERROR
1941                          ;
1942 024636 120005      20$:  CMPB   R0,R5    ; COMPARE CURRENT SIZE W/ GOT
1943 024640 001414              BEQ    30$      ; IF SAME, GET NEXT BUFFER
1944 024642 103403              BLO    23$      ; IF LT, COMPARE W/ NEEDED
1945 024644 120105      CMPB   R1,R5    ; COMPARE NEEDED W/ GOT
1946 024646 101411              BLOS   30$      ; IF LE, GET NEXT BUFFER
1947 024650 000402              BR     25$      ; ELSE THIS IS BEST FIT
1948 024652 120001      23$:  CMPB   R0,R1    ; COMPARE CURRENT W/ NEEDED
1949 024654 103406              BLO    30$      ; IF LE, GET NEXT BUFFER
1950 024656 010304      25$:  MOV    R3,R4    ; ELSE, USE CURRENT BUFFER
1951 024660 010005      MOV    R0,R5    ; SAVE SIZE OF CURRENT BUFFER
1952 024662 042705 177400      BIC    #C<377>,R5 ; CLEAR EXTRANEIOUS BITS
1953 024666 020501      CMP    R5,R1    ; IF GOT = NEED
1954 024670 001402              BEQ    31$      ;
1955 024672 011303      30$:  MOV    (R3),R3  ; POINT TO NEXT PACKET
1956 024674 001346              BNE    10$      ; IF NZ, LOOK AT NEXT PACKET
1957 024676              31$:
1958 024676 000240      NOP                ; [DBG] INSERT HALT FOR DEBUG
    
```


1959 024700 000207

RETURN

;

```

1961
1962
1963
1964
1965
1966
1967
1968
1969
1970
1971 024702 013703 004622
1972 024706 001433
1973 024710 011304
1974 024712 001427
1975 024714 105763 000003
1976 024720 001022
1977 024722 105764 000003
1978 024726 001017
1979 024730 116300 000002
1980 024734 001420
1981 024736 116405 000002
1982 024742 001415
1983 024744 060005
1984 024746 010563 000002
1985 024752 011413
1986 024754 013714 004624
1987 024760 010437 004624
1988 024764 000750
1989
1990 024766 010403
1991 024770 000746
1992
1993 024772
1994 024772 000240
1995 024774 000207
1996
1997 024776 012701 024774
1998 025002 000137 024310

; **
;
; BUFMRG - MERGE ADJACENT FREE BLOCKS IN FREE MEMORY LIST
;
; INPUTS:
;
; OUTPUTS: NONE
;
; ---
BUFMRG: MOV M.HDR,R3 ; GET POINTER TO AVAILABLE LIST
10$: BEQ 41$ ; IF END OF LIST, MEMORY ERROR
MOV (R3),R4 ; GET POINTER TO NEXT PACKET
BEQ 40$ ; IF END OF LIST, EXIT
TSTB 3(R3) ; CHECK IF INUSE
BNE 30$ ; IF SO, GET NEXT PACKET
TSTB 3(R4) ; CHECK IF INUSE
BNE 30$ ; IF SO, GET NEXT PACKET
MOVB 2(R3),R0 ; GET BUFFER SIZE OF FIRST PACKET
BEQ 41$ ; IF ZERO, SYSTEM FATAL ERROR
MOVB 2(R4),R5 ; GET SIZE OF ADJACENT BUFFER
BEQ 41$ ; IF ZERO, SYSTEM FATAL ERROR
ADD R0,R5 ; CALCULATE TOTAL SIZE
MOV R5,2(R3) ; INSERT NEW SIZE
MOV (R4),(R3) ; ADJUST POINTERS
MOV F.HDR,(R4) ; PUT UNUSED PACKET POINTER
MOV R4,F.HDR ; INTO TOP OF FREE LIST
BR 10$ ; LOOP

30$: MOV R4,R3 ; POINT TO NEXT PACKET
BR 10$ ; LOOP

40$:
NOP ; [DBG] INSERT HALT FOR DEBUG
RETURN ; DONE MERGING PACKETS

41$: MOV @.-2,R1 ; SAVE CURRENT LOCATION
JMP BADMEM ; PRINT SYSTEM FATAL ERROR
    
```

```

2000
2001
2002      ;**
2003      ; MAPMEM - MAP MEMORY OFFSET TO PHYSICAL MEMORY AND CALCULATE
2004      ; BYTE COUNT OF SEGMENT
2005      ;
2006      ; INPUTS:
2007      ; R1 - BLOCK COUNT OF SEGMENT
2008      ; R3 - MEMORY OFFSET (BYTES)
2009      ;
2010      ; OUTPUTS:
2011      ; REGISTERS UNCHANGED
2012      ; BCLO,BCHI - BYTE COUNT OF SEGMENT
2013      ; BUFBA,BUFEA - PHYSICAL ADDRESS OF SEGMENT
2014      ; TSTOFF - MAPPED MEMORY OFFSET TO BUFFER, OR -1
2015      ;--
2015 025006 005701 MAPMEM: TST R1 ; IF NOT ZERO,
2016 025010 001014 BNE 10 ; CONTINUE
2017 025012 005037 CLR 9CLO ; ELSE
2018 025016 005037 CLR BCHI ; CLEAR
2019 025022 005037 CLR BUFBA ; EVERYTHING
2020 025026 005037 CLR BUFEA ;
2021 025032 012737 177777 002242 MOV 0-1,TSTOFF ; FLAG AS NO BUFFER USED
2022 025040 000207 RETURN ;
2023
2024 025042 10: PUSH <R2,R3,R4> ; SAVE REGISTERS
2025 025042 010246 MOV R2,-(SP) ; PUSH R2 ON STACK
2026 025044 010346 MOV R3,-(SP) ; PUSH R3 ON STACK
2027 025046 010446 MOV R4,-(SP) ; PUSH R4 ON STACK
2028 025050 010337 002242 MOV R3,TSTOFF ; SAVE MEMORY OFFSET
2029 025054 004737 045502 CALL GETBC ; GET BYTE COUNT
2030 025060 032737 100000 002204 BIT 0,IMW,IFLAGS ; CHECK FOR MEMORY MAPPING
2031 025066 001411 BEQ 101 ; IF CLEAR, USE MEMORY MAPPING
2032 025070 013702 002166 MOV FFREE,R2 ; ELSE USE
2033 025074 063702 002242 ADD TSTOFF,R2 ; FREE MEMORY
2034 025100 010237 004370 MOV R2,BUFBA ;
2035 025104 005037 004372 CLR BUFEA ;
2036 025110 000414 BR 201 ;
2037 025112 101: MAP TSTOFF,BUFBA,BUFEA ; USE MAPPED MEMORY
2038 025112 000403 BR 100001 ;
2039 025114 002242 .WORD TSTOFF ;
2040 025116 004370 .WORD BUFBA ;
2041 025120 004372 .WORD BUFEA ;
2042 025122 100001: MOV 0-6,R0 ;
2043 025126 104502 TRAP CMAP ;
2044 025130 000403 BERROR 201 ; IF NOT COMPLETE,
2045 025130 103004 BCC 201 ;
2046 025132 010701 025130 MOV 0-2,R1 ; DATA STRUCTURES
2047 025136 000137 024310 JMP BADMEM ; ARE CORRUPT
2048 025142 201: POP <R4,R3,R2> ; RESTORE REGISTERS
2049 025142 012604 MOV (SP)+,R4 ; POP STACK INTO R4
2050 025144 012603 MOV (SP)+,R3 ; POP STACK INTO R3
2051 025146 012602 MOV (SP)+,R2 ; POP STACK INTO R2
2052 025150 000240 NOP ; [DBG] INSERT HALT FOR DEBUG
2053 025152 000207 RETURN ;
    
```

```

2042
2043
2044      ;**
2045      ; MMT0BF - COPY A BLOCK OF MAPPED MEMORY TO A BUFFER IN LOW MEMORY.
2046      ;
2047      ; INPUTS:
2048      ; R1 - ADDRESS OF LOW MEMORY BUFFER
2049      ; R3 - MEMORY OFFSET (BYTES)
2050      ; OUTPUTS:
2051      ; LOW MEMORY BUFFER CONTAINS 1 BLOCK OF DATA
2052      ; REGISTERS UNCHANGED
2053      ;--
2054 MMT0BF: PUSH    <R2,R3,R4>      ; SAVE REGISTERS
          MOV     R2,-(SP)        ; PUSH R2 ON STACK
          MOV     R3,-(SP)        ; PUSH R3 ON STACK
          MOV     R4,-(SP)        ; PUSH R4 ON STACK
2055 025154 010246 100000 002204 BIT     @IMMU,IFLAGS          ; CHECK FOR MEMORY MAPPING
2056 025170 001412          SEQ     10$                          ; IF CLEAR, USE MEMORY MAPPING
2057 025172 013702 002166          MOV     FFREE,R2                ; ELSE, USE
2058 025176 060302          ADD     R3,R2                    ; FREE MEMORY
2059 025200 010104          MOV     R1,R4
2060 025202 012700 000400          MOV     @256.,R0
2061 025206 012224 1$:          MOV     (R2)+,(R4)+
2062 025210 005300          DEC     R0
2063 025212 001375          BNE     1$
2064 025214 000423          BR     20$
2065 025216 010337 004404 10$:          MOV     R3,MMOFF
2066 025222 010137 004400          MOV     R1,MMBUF
2067 025226 012737 001000 004402          MOV     @512.,MMSIZ
2068 025234          BFTOME MMOFF,MMBUF,MMSIZ
          BR     10001$
          .WORD MMOFF
          .WORD MMBUF
          .WORD MMSIZ
2069 025244 012700 025236 10001$:          MOV     @.-6,R0
          TRAP C#TOME
          BCOMPLETE 20$          ; IF NOT COMPLETE.
2070 025254 012701 025252          MOV     @.-2,R1
2071 025260 000137 024310          JMP     BADMEM          ; DATA STRUCTURES
2072 025264          ; ARE CORRUPT
2073 025264 000240 20$:          NOP
2074 025266          ; [DBG] INSERT HALT FOR DEBUG
          POP     <R4,R3,R2>      ; RESTORE REGISTERS
          MOV     (SP)+,R4        ; POP STACK INTO R4
          MOV     (SP)+,R3        ; POP STACK INTO R3
          MOV     (SP)+,R2        ; POP STACK INTO R2
2075 025274 000207          RETURN
    
```

```

2077
2078
2079      ;**
2080      ; BFTOMM - COPY THE CONTENTS OF A BUFFER IN LOW MEMORY TO MAPPED
2081      ; MEMORY.
2082      ;
2083      ; INPUTS:
2084      ; R1 - ADDRESS OF LOW MEMORY BUFFER
2085      ; R3 - MEMORY OFFSET (BYTES)
2086      ;
2087      ; OUTPUTS:
2088      ; LOW MEMORY BUFFER COPIED TO MAPPED MEMORY
2089      ; REGISTERS UNCHANGED
2090      ;--
2090      BFTOMM: PUSH    <R2,R3,R4>          ; SAVE REGISTERS
                MOV     R2,-(SP)           ; PUSH R2 ON STACK
                MOV     R3,-(SP)           ; PUSH R3 ON STACK
                MOV     R4,-(SP)           ; PUSH R4 ON STACK
2091      025276 010246 100000 002204      BIT     @IMMU,IFLAGS      ; CHECK FOR MEMORY MAPPING
2092      025300 010346                    BEQ     10$               ; IF CLEAR, USE MEMORY MAPPING
2093      025302 010446                    MOV     FFREE,R2          ; ELSE, USE
2094      025304 032737                    ADD     R3,R2             ; FREE MEMORY
2095      025320 060302                    MOV     R1,R4             ;
2096      025322 010104                    MOV     @256.,R0          ;
2097      025324 012700 000400            1$:   MOV     (R4)+,(R2)+   ;
2098      025326 005300                    DEC     R0                 ;
2099      025332 001375                    BNE     1$                 ;
2100      025334 000423                    BR      20$                ;
2101      025336 004404                    10$:  MOV     R3,MHOFF        ; COPY LOW
2102      025338 010337 004404            MOV     R1,MMBUF          ; MEMORY TO
2103      025340 010137 004400            MOV     @512.,MMSIZ      ; MAPPED
2104      025342 012737 001000 004402      BFFRME MHOFF,MMBUF,MMSIZ ; MEMORY
                BR      10002$
                .WORD  MHOFF
                .WORD  MMBUF
                .WORD  MMSIZ
2105      025356 000403                    10002$: MOV    @-6,R0             ;
                BR      104500
                TRAP   C$FRME
                BCOMPLETE 20$ ; IF NOT COMPLETE.
2106      025360 004404                    MOV     @-2,R1           ; DATA STRUCTURES
2107      025362 004400                    JMP     BADMEM           ; ARE CORRUPT
2108      025364 004402                    20$:  NOP
                20$:  [DBG] INSERT HALT FOR DEBUG
2109      025366 012700 025360            POP     <R4,R3,R2>       ; RESTORE REGISTERS
2110      025368 104500                    MOV     (SP)+,R4         ; POP STACK INTO R4
                MOV     (SP)+,R3         ; POP STACK INTO R3
                MOV     (SP)+,R2         ; POP STACK INTO R2
2111      025372 012604                    RETURN
                025410 012603
                025412 012602
                025414 012602
                000240
                000207
    
```

```

2113
2114
2115      ;**
2116      ;
2117      ;
2118      ;
2119      ;
2120      ;
2121      ;
2122      ;--
2123      RETBUF: PUSH    <R0,R4>          ; SAVE ALL REGISTERS
                MOV     R0,-(SP)        ; PUSH R0 ON STACK
                MOV     R4,-(SP)        ; PUSH R4 ON STACK
2124      025420 010046      004622      MOV     M.HDR,R4          ; GET POINTER TO FIRST PACKET
2125      025422 010446      002242      1$:    BEQ     3$              ; IF END OF LIST, MEMORY ERROR
2126      025424 013704      000004      CMP     4(R4),TSTOFF      ; CHECK CURRENT OFFSET
2127      025426 026437      000004      BHI    3$              ; IF GT, FATAL MEMORY ERROR
2128      025428 101003      000004      BEQ    10$             ; IF SAME, EXIT LOOP
2129      025430 001407      000004      MOV     (R4),R4          ; GET NEXT PACKET
2130      025432 001404      000770      BR     1$              ; LOOP
2131      025434 012701      025446      3$:    MOV     #-2,R1          ; SAVE CURRENT LOCATION
2132      025436 000137      024310      JMP     BADMEM           ; PRINT SYSTEM FATAL ERROR
2133      025438 105764      000003      10$:   TSTB   3(R4)           ; IF ZERO,
2134      025440 001771      000003      BEQ    3$              ; PROGRAM ERROR
2135      025442 105364      000003      DECB   3(R4)           ; DECREMENT USE COUNT
2136      025444 001017      000003      BNE    30$            ; IF USE COUNT NOT ZERO, EXIT
2137      025446 012700      000102      MOV     #66,R0          ; ELSE,
2138      025448 026460      000004      20$:   CMP     4(R4),MUTOFF(R0) ; REMOVE
2139      025450 001006      000004      BNE    22$            ; BUFFER
2140      025452 012760      177777      21$:   MOV     #-1,MUTOFF(R0) ; FROM
2141      025454 005060      004516      CLR    MUTSIZ(R0)      ; MULTI-USE
2142      025456 000403      000004      BR     30$            ; LIST
2143      025458 005300      000004      22$:   DEC     R0              ;
2144      025460 005300      000004      DEC     R0              ;
2145      025462 002363      000004      BGE    20$            ;
2146
2147      025532 012737      177777      30$:   MOV     #-1,TSTOFF      ; FLAG AS NO BUFFER IN USE
2148      025534 012604      000004      POP    <R4,R0>         ; RESTORE SAVED REGISTERS
                MOV     (SP)+,R4        ; POP STACK INTO R4
                MOV     (SP)+,R0        ; POP STACK INTO R0
2149      025544 000240      000004      NOP
2150      025546 000207      000004      RETURN ; [DBG] INSERT HALT FOR DEBUG
    
```

```

2152
2153      ;++
2154      ; GETME - GET POINTER TO THE REQUESTED MESSAGE ENVELOPE
2155      ;
2156      ; INPUTS:
2157      ; R1 - DESIRED COMMAND REFERENCE NUMBER
2158      ; R5 - ADDRESS OF CONTROLLER TABLE
2159      ;
2160      ; OUTPUTS:
2161      ; R4 - POINTER TO MESSAGE ENVELOPE
2162      ;--
2163 025550 016504 000162 GETME: MOV C.CMBL(R5),R4 ; GET TOP OF COMMAND LIST
2164 025554 001406 1$: BEQ 3$ ; IF ZERO, ME NOT FOUND
2165 025556 026401 000026 CMP P.CRF+ME.CP(R4),R1 ; IF CMD REF # IS SAME,
2166 025562 001407 BEQ 4$ ; EXIT
2167 025564 016404 000002 MOV ME.CBL(R4),R4 ; ELSE,
2168 025570 000771 BR 1$ ; GET NEXT PACKET
2169 025572 012701 025570 3$: MOV #,-2,R1 ; SAVE CURRENT LOCATION
2170 025576 000137 024310 JMP BADMEM ; PRINT SYSTEM FATAL ERROR
2171 025602 4$:
2172 025602 000240 NOP ; [DBG] INSERT HALT FOR DEBUG
2173 025604 000207 RETURN ;
2174
2175      ;++
2176      ; RTNALL - RETURN ALL MESSAGE ENVELOPES TO FREE LIST.
2177      ;
2178      ; INPUTS:
2179      ; R5 - ADDRESS OF CONTROLLER TABLE
2180      ;
2181      ; OUTPUTS:
2182      ; T.HDR - POINTS TO RETURNED ENVELOPE
2183      ;--
2184 025606 016504 000160 RTNALL: MOV C.CMFL(R5),R4 ; GET POINTER TO FIRST M.E.
2185 025612 001434 BEQ 10$ ; IF LIST EMPTY, EXIT
2186 025614 022764 177777 000020 CMP #-1,ME.OFF(R4) ; IF MEMORY OFFSET
2187 025622 001405 BEQ 1$ ; IS NOT -1,
2188 025624 016437 000020 002242 MOV ME.OFF(R4),TSTOFF ; FREE MEMORY
2189 025632 004737 025420 CALL RETBUF ; BUFFER
2190 025636 010502 1$: MOV R5,R2 ; GET HEADER
2191 025640 062702 000160 ADD #C.CMFL,R2 ;
2192 025644 016412 000000 MOV ME.CFL(R4),(R2) ; ADJUST FORWARD LINK OF LAST PACKET
2193 025650 001003 BNE 2$ ;
2194 025652 010502 MOV R5,R2 ; IF ZERO, END OF LIST
2195 025654 062702 000162 ADD #C.CMBL,R2 ; R2 POINTS TO LIST HEADER
2196 025660 016412 000002 2$: MOV ME.CBL(R4),(R2) ; ADJUST BACK LINK OF NEXT PACKET
2197
2198 025664 013764 006242 000000 MOV T.HDR,ME.CFL(R4) ; ADD ENVELOPE TO
2199 025672 005064 000002 CLR ME.CBL(R4) ; TOP OF FREE LIST
2200 025676 010437 006242 MOV R4,T.HDR ;
2201 025702 000741 BR RTNALL ;
2202
2203 025704 016504 000164 10$: MOV C.TBSF(R5),R4 ; GET POINTER TO FIRST M.E.
2204 025710 001434 BEQ 20$ ; IF LIST EMPTY, EXIT
2205 025712 022764 177777 000020 CMP #-1,ME.OFF(R4) ; IF MEMORY OFFSET
2206 025720 001405 BEQ 11$ ; IS NOT -1,
    
```



```

2260
2261
2262      ;++
2263      ; CLRRSP - PUT AN EMPTY RESPONSE BUFFER IN THE RESPONSE RING.
2264      ;
2265      ; INPUTS:
2266      ;         R5 - ADDRESS OF CONTROLLER TABLE
2267      ;
2268      ; OUTPUTS:
2269      ;         C.RPTR(R5) - CONTAINS POINTER TO RESPONSE BUFFER
2270      ;--
2270 026132 016502 000104      CLRRSP: MOV      C.RHDR(R5),R2      ; POINT TO FREE R.E.
2271 026136 016265 000000 000104      MOV      RE.RFL(R2),C.RHDR(R5) ; POINT TO NEXT R.E.
2272 026144 012762 000200 000002      MOV      #128,RE.RL(R2)      ; SET RESPONSE PACKET LENGTH
2273 026152 005062 000004      CLR      RE.RV(R2)          ; SET CIRCUIT TYPE, ETC
2274 026156 062702 000006      ADD      #RE.RP,R2          ; POINT TO TOP OF RESPONSE PACKET
2275 026162 016500 000076      MOV      C.RPTR(R5),R0      ; GET RING ENTRY ADDRESS
2276 026166 010210      MOV      R2,(R0)           ; PUT ADDRESS OF FREE PACKET IN RING
2277 026170 012760 140000 000002      MOV      #<RG.OWN+RG.FLG>,2(R0) ; RETURN BUFFER TO CONTROLLER
2278 026176 062765 000004 000076      ADD      #4,C.RPTR(R5)      ; UPDATE RESPONSE POINTER
2279 026204 026565 000076 000102      CMP      C.RPTR(R5),C.REND(R5) ; IF NOT AT END OF RESPONSE RING,
2280 026212 001003      BNE     15$                ; EXIT.
2281 026214 016565 000100 000076      MOV      C.RBAS(R5),C.RPTR(R5) ; ELSE, POINT TO FIRST ENTRY.
2282 026222 016500 000076      15$:  MOV      C.RPTR(R5),R0      ; GET RING ENTRY ADDRESS
2283 026226 032760 100000 000002      BIT      #RG.OWN,2(R0)      ; IF HOST OWNS ENTRY
2284 026234 001403      BEQ     20$                ; DON'T CLEAR MESSAGE RECEIVED FLAG
2285 026236 042765 020000 000014      BIC     #CT.MSG,C.FLG(R5)  ; CLEAR MESSAGE RECEIVED FLAG
2286 026244      20$:
2287 026244 000240      NOP
2288 026246 000207      RETURN
    
```

; [DBG] INSERT HALT FOR DEBUG

```

2290
2291
2292      :++
2293      :
2294      :
2295      :
2296      :
2297      :
2298      :
2299      :
2300      :
2301      :
2302      :
2303      :
2304      :--
2305 026250 010046  RANDOM: PUSH <R0,R3,R4> ; SAVE REGISTERS
      026250 010046  MOV R0,-(SP) ; PUSH R0 ON STACK
      026252 010346  MOV R3,-(SP) ; PUSH R3 ON STACK
      026254 010446  MOV R4,-(SP) ; PUSH R4 ON STACK
2306 026256 010246  PUSH <R2,R1> ; SAVE MAX VALUE
      026256 010246  MOV R2,-(SP) ; PUSH R2 ON STACK
      026260 010146  MOV R1,-(SP) ; PUSH R1 ON STACK
2307 026262 005003  CLR R3 ; INITIALIZE
2308 026264 005004  CLR R4 ; MASK WORDS
2309
2310      :
2311      :
2312 026266 006303  :
2313 026270 006104  1$: ASL R3 ; SHIFT MASK
2314 026272 005203  ROL R4 ; ONE BIT LEFT
2315 026274 020402  INC R3 ; TURN ON BIT 0
2316 026276 103773  CMP R4,R2 ; SEE IF
2317 026300 101002  BLO 1$ ; MASK IS
2318 026302 020301  BHI 2$ ; GREATER THAN
2319 026304 103770  CMP R3,R1 ; MAXIMUM VALUE
2320 026306 005103  BLO 1$ ; IF NOT, LOOP
2321 026310 005104  2$: COM R3 ; ELSE, COMPLIMENT MASK
2322      :
2323      :
2324      :
2325 026312 013701 002360  :
2326 026316 013702 002362  10$: MOV LOSEED,R1 ; GET LOW ORDER SEED
2327 026322 012700 000007  MOV HISEED,R2 ; GET HIGH WORD OF SEED
2328 026326 060101  :
2329 026330 006102  11$: ADD #7,R0 ; INIT LOOP COUNT
2330 026332 005300  ROL R1,R1 ; ROTATE LO ORDER NUMBER BY 1
2331 026334 001374  DEC R2 ; ROTATE HI ORDER NUMBER BY 1 (PROPOGATE CARRY)
2332 026336 063701 002360  BNE 11$ ; DECREMENT COUNT
2333 026342 005502  ADD LOSEED,R1 ; IF COUNT INCOMPLETE, BRANCH
2334 026344 063702 002362  ADC R2 ; ADD ORIGINAL SEED (X129)
2335 026350 062701 001057  ADD #1057,R1 ; PROPOGATE CARRY
2336 026354 005502  ADC R2 ; ADD HISEED
2337 026356 062702 047401  ADD #47401,R2 ; ADD LO CONSTANT
2338 026362 010137 002360  MOV R1,LOSEED ; PROPOGATE CARRY
2339 026366 010237 002362  MOV R2,HISEED ; ADD HI CONSTANT
                ; SAVE LO ORDER SEED
                ; SAVE HI ORDER SEED
    
```

```
2340  
2341 ;  
2342 ; MAKE SURE NUMBER IS IN RANGE  
2343 026372 040301 BIC R3,R1 ; GET ONLY  
2344 026374 040402 BIC R4,R2 ; NEEDED BITS  
2345 026376 020266 000002 CMP R2,2(SP) ; CHECK  
2346 026402 101343 BHI 10$ ; IF NUMBER  
2347 026404 103402 BLO 20$ ; IS IN RANGE  
2348 026406 020116 CMP R1,(SP) ;  
2349 026410 101340 BHI 10$ ; IF NOT, GET ANOTHER NUMBER  
2350 026412 022626 CMP (SP)+,(SP)+ ; THROW AWAY MAX VALUE  
2351 026414 000240 NOP ; [DBG] INSERT HALT FOR DEBUG  
2352 026416 POP <R4,R3,R0> ; RESTORE SAVED REGISTERS  
026416 012604 MOV (SP)+,R4 ; POP STACK INTO R4  
026420 012603 MOV (SP)+,R3 ; POP STACK INTO R3  
026422 012600 MOV (SP)+,R0 ; POP STACK INTO R0  
2353 026424 000207 RETURN
```

```

2355
2356      ;++
2357      ; DRIVER - THIS ROUTINE IS THE DRIVER FOR THE TESTS. IT CAUSES THE
2358      ; COMMAND PACKETS TO BE GENERATED AND PROCESSES THE RESPONSES.
2359      ;
2360      ; INPUTS:
2361      ; R5 - CONTROLLER TABLE ADDRESS
2362      ;--
2363
2364 026426 013705 002200 DRIVER: MOV CTABS,R5 ; GET CONTROLLER TABLE ADDRESS
2365 026432 032765 110000 000014 1$: BIT #<CT.AVL!CT.IOC>,C.FLG(R5); IF NOT AVAILABLE FOR TEST,
2366 026440 001072 BNE 31$ ; LOOK AT NEXT CONTROLLER
2367 026442 116537 000002 002074 MOVB C.UNIT(R5),L$LUN ; STORE UNIT NUMBER UNDER TEST
2368
2369      ; SEND COMMAND TO CONTROLLER
2370      ;
2371 026450 032765 040000 000014 BIT #CT.DUN,C.FLG(R5) ; IF DONE TESTING THIS CONTROLLER,
2372 026456 001012 BNE 10$ ; DON'T GENERATE ANY MORE PACKETS
2373 026460 032737 010000 002204 BIT #IDUN,IFLAGS ; IF TEST TIMED OUT,
2374 026466 001006 BNE 10$ ; DON'T GENERATE ANYMORE PACKETS
2375 026470 004777 153552 CALL @TSPGEN ; BUILD TEST PACKETS
2376 026474 032765 110000 000014 BIT #<CT.AVL!CT.IOC>,C.FLG(R5); IF NOT AVAILABLE FOR TEST,
2377 026502 001051 BNE 31$ ; LOOK AT NEXT CONTROLLER
2378 026504 004737 051504 10$: CALL SNDMSG ; SEND NEXT COMMAND TO CONTROLLER
2379
2380      ; GET RESPONSE FROM CONTROLLER
2381      ;
2382 026510 032765 020000 000014 BIT #CT.MSG,C.FLG(R5) ; IF MESSAGE FLAG SET,
2383 026516 001020 BNE 20$ ; PROCESS RESPONSE PACKET.
2384 026520 004737 027140 CALL CTLCHK ; ELSE, IF CONTROLLER NOT RUNNING,
2385 026524 103440 BCS 31$ ; EXIT LOOP
2386 026526 005765 000164 TST C.TBSF(R5) ; IF TBS LIST IS NOT EMPTY,
2387 026532 001014 BNE 30$ ; CONTINUE
2388 026534 005765 000160 TST C.CMFL(R5) ; IF COMMAND LIST IS NOT EMPTY,
2389 026540 001011 BNE 30$ ; CONTINUE
2390 026542 032765 000400 000014 BIT #CT.MRW,C.FLG(R5) ; IF MAINTENANCE OPERATION IN
2391 026550 001005 BNE 30$ ; PROGRESS, DON'T DO GUS
2392 026552 004737 050114 CALL GUSTAT ; ISSUE GET UNIT STATUS TO KEEP
2393 026556 000402 BR 30$ ; CONTROLLER ALIVE
2394
2395 026560 004737 027500 20$: CALL RSPIN ; ELSE, LOOK AT PACKET
2396
2397      ; IF TEST NOT DONE, SWITCH TO NEXT CONTROLLER
2398      ; ELSE, EXIT TEST ROUTINE
2399
2400 026564 032765 040000 000014 30$: BIT #CT.DUN,C.FLG(R5) ; IF TEST NOT DONE ON CONTROLLER,
2401 026572 001421 BEQ 35$ ; CONTINUE
2402 026574 005765 000164 TST C.TBSF(R5) ; IF TBS LIST IS NOT EMPTY,
2403 026600 001016 BNE 35$ ; CONTINUE
2404 026602 005765 000160 TST C.CMFL(R5) ; IF COMMAND LIST IS NOT EMPTY,
2405 026606 001013 BNE 35$ ; CONTINUE
2406 026610 004737 053452 CALL RESET ; RESET CONTROLLER & RE-INIT TABLE
2407 026614 052765 010000 000014 BIS #CT.IOC,C.FLG(R5) ; DISABLE CONTROLLER
2408 026622 005337 002210 DEC UTEST ; DECREMENT CONTROLLER UNDER TEST COUNT
2409 026626 005737 002210 31$: TST UTEST ; IF UNITS UNDER TEST ZERO,
    
```

```

2410 026632 003001      BGT      35$      ; EXIT ROUTINE
2411 026634 000207      RETURN      ;
2412
2413 026636 062705 000170 35$:  ADD      #C.SIZE,R5      ; MOVE TO NEXT TABLE
2414 026642 005715      TST      (R5)          ; IF NOT END OF CONTROLLER LIST,
2415 026644 001272      BNE      1$           ; LOOK AT NEXT CONTROLLER
2416
2417      ;
2418      ; CHECK FOR TEST TIMEOUT
2419 026646 022737 000003 002206 40$:  CMP      #3.,TNUM      ; IF THIS IS NOT TEST 3,
2420 026654 001125      BNE      60$          ; DON'T TIMEOUT TEST OR PRINT REPORT
2421 026656 032737 010000 002204      BIT      #IDUN,IFLAGS  ; IF WE'RE WAITING FOR CONTROLLERS
2422 026664 001101      BNE      50$          ; TO FINISH, DON'T CHECK TIMEOUT
2423 026666 005737 002146      TST      SFPTBL+SO.TL  ; IF TEST TIMEOUT IS ZERO,
2424 026672 001476      BEQ      50$          ; DON'T TIMEOUT TEST
2425 026674 005737 002322      TST      KW.CSR        ; SEE IF A CLOCK ON SYSTEM
2426 026700 001473      BEQ      50$          ; DON'T TIME OUT IF NO CLOCK
2427 026702 023737 002334 002256      CMP      KW.EL+2,TSTIM+2 ; CHECK HIGH WORD OF ELAPSED TIME
2428 026710 101005      BHI      41$          ; IF GREATER, TEST DONE
2429 026712 001066      BNE      50$          ; IF NOT SAME, KEEP TESTING
2430 026714 023737 002332 002254      CMP      KW.EL,TSTIM   ; CHECK LOW WORD OF ELAPSED TIME
2431 026722 103462      BLO      50$          ; IF LESS, KEEP TESTING
2432 026724 052737 010000 002204 41$:  BIS      #IDUN,IFLAGS  ; SET TEST DONE BIT
2433 026732      PRINTF  #TIMLIM      ; PRINT TIMEOUT MESSAGE
      MOV      #TIMLIM,-(SP)
      MOV      #1,-(SP)
      MOV      SP,R0
      TRAP    C#PNTF
      ADD      #4,SP
2434 026752 004737 053550      CALL     RNTIME      ; GET RUN TIME
2435 026756      PRINTF  #RNTIM,RNTHH,RNTMM,RTSS; PRINT RUN TIME
      MOV      RNTSS,-(SP)
      MOV      RNTMM,-(SP)
      MOV      RNTHH,-(SP)
      MOV      #RNTIM,-(SP)
      MOV      #4,-(SP)
      MOV      SP,R0
      TRAP    C#PNTF
      ADD      #12,SP
2436 027012      PRINTF  #CRLF      ; TERMINATE LINE
      MOV      #CRLF,-(SP)
      MOV      #1,-(SP)
      MOV      SP,R0
      TRAP    C#PNTF
      ADD      #4,SP
2437 027032 013705 002200      MOV      CTABS,R5      ; GET CONTROLLER TABLE ADDRESS
2438 027036 052765 040000 000014 42$:  BIS      #CT.DUN,C.FLG(R5) ; MARK CONTROLLER DONE
2439 027044 005065 000030      CLR      C.STEP(R5)   ; RESET TEST STEP COUNTER
2440 027050 005065 000042      CLR      C.NEXT(R5)   ; RESET NEXT UNIT INDEX
2441 027054 005065 000032      CLR      C.UCNT(R5)   ; RESET UNIT UNDER TEST COUNT
2442 027060 062705 000170      ADD      #C.SIZE,R5   ; GET NEXT CONTROLLER TABLE ADDRESS
2443 027064 005715      TST      (R5)          ; CHECK IF ANOTHER CONTROLLER TABLE
2444 027066 001363      BNE      42$          ; DO NEXT CONTROLLER
2445
2446      ; CHECK FOR TIME TO PRINT STATISTICAL REPORT
    
```



```

2463      ;++
2464      ; CTLCHK - VERIFY CONTROLLER IS STILL FUNCTIONING BY MAKING
2465      ; SURE SA REGISTER IS ZERO AND OLDEST OUTSTANDING COMMAND IS
2466      ; MAKING PROGRESS.
2467      ;
2468      ;
2469      ; INPUTS:
2470      ; R5 - POINTER TO CONTROLLER TABLE
2471      ;--
2472 027140 011504 CTLCHK: MOV      (R5),R4      ; GET ADDRESS OF IP REGISTER
2473 027142 016402 000002 MOV      2(R4),R2      ; LOOK AT SA REGISTER
2474 027146 001407 BEQ      20$          ; IF ZERO, CONTROLLER STILL RUNNING
2475 027150 ERRDF 30,ERR030 ; ELSE, REPORT FATAL CONTROLLER ERROR
      027150 104455 TRAP   C+ERRDF
      027152 000036 .WORD  30
      027154 000000 .WORD  0
      027156 020246 .WORD  ERR030
2476 027160 004737 027350 CALL   DRPCNT      ; DROP CONTROLLER FROM TESTING
2477 027164 000207 RETURN
2478
2479 027166 016504 000162 20$:  MOV      C,CMBL(R5),R4 ; GET POINTER TO OLDEST COMMAND
2480 027172 001463 BEQ      30$          ; IF LIST EMPTY, DON'T TIME OUT
2481 027174 005737 002322 TST     KW.CSR      ; IF NO CLOCK ON SYSTEM,
2482 027200 001460 BEQ      30$          ; DON'T TIME OUT COMMAND
2483 027202 023764 002334 000010 CMP     KW.EL+2,ME.CTH(R4) ; CHECK HIGH WORD OF ELAPSED TIME
2484 027210 101005 BHI     23$          ; IF GREATER, RESPONSE TIMED OUT
2485 027212 103453 BLO     30$          ; IF LOWER, ITS OK
2486 027214 023764 002332 000006 CMP     KW.EL,ME.CTO(R4) ; CHECK LOW WORD OF ELAPSED TIME
2487 027222 103447 BLO     30$          ; IF LESS, PLENTY OF TIME LEFT
2488 027224 032765 000400 000014 23$: BIT     @CT.MRW,C.FLG(R5) ; IF MAINTENANCE OPERATION IN
2489 027232 001004 BNE     24$          ; PROGRESS, TIMEOUT CONTROLLER
2490 027234 032764 000070 000036 BIT     @70,P.OPCD+ME.CP(R4) ; IF NOT IMMEDIATE COMMAND
2491 027242 001007 BNE     25$          ; SEND GCS PACKET
2492 027244 ERRDF 31,ERR031 ; REPORT TIMEOUT ERROR
      027244 104455 TRAP   C+ERRDF
      027246 000037 .WORD  31
      027250 000000 .WORD  0
      027252 020264 .WORD  ERR031
2493 027254 004737 027350 CALL   DRPCNT      ; DROP CONTROLLER FROM TESTING
2494 027260 000207 RETURN
2495
2496 027262 032764 040060 000016 25$: BIT     @CF.CTO,ME.CFG(R4) ; IF GCS COMMAND ALREADY ISSUED,
2497 027270 001365 BNE     24$          ; CONTROLLER MUST BE HUNG
2498 027272 016501 000006 MOV     C,CTO(R5),R1 ; RE-INIT
2499 027276 010400 MOV     R4,R0      ; COMMAND
2500 027300 062700 000006 ADD     @ME.CTO,R0 ; TIMER
2501 027304 004737 052070 CALL   SETTO
2502 027310 052764 040000 000016 BIS     @CF.CTO,ME.CFG(R4) ; SET GCS ISSUED FLAG
2503 027316 016401 000004 MOV     ME.CRF(R4),R1 ; GET CMD REF # OF OUTSTANDING COMMAND
2504 027322 005002 CLR     R2      ; CLEAR HIGH WORD
2505 027324 004737 050056 CALL   GCSTAT      ; SEND GCS COMMAND
2506 027330 103004 BCC     30$          ; IF NOT SUCCESSFUL
2507 027332 012701 027330 MOV     @-2,R1      ; SAVE CURRENT LOCATION
2508 027336 000137 024310 JMP     BADMEM      ; PRINT SYSTEM FATAL ERROR
2509
    
```

2510 027342 000241
2511 027344 000240
2512 027346 000207
2513

30\$: CLC
NOP ; [DBG] INSERT HALT FOR DEBUG
RETURN ;


```

2515
2516      ;**      DRPCNT - DROP A CONTROLLER AFTER FATAL ERROR REPORTED BY MSCP
2517      ;
2518      ;--
2519 027350 032765 100000 000014 DRPCNT: BIT      @CT.AVL,C.FLG(R5)      ; IF CONTROLLER ALREADY DISABLED,
2520 027356 001017                BNE      2$                ; EXIT ROUTINE
2521 027360 004737 053452                CALL     RESET              ; RESET THE CONTROLLER
2522 027364 052765 100000 000014      BIS      @CT.AVL,C.FLG(R5)      ; DISABLE CONTROLLER
2523 027372 004737 025606                CALL     RTNALL             ; RETURN BUFFERS TO FREE LIST
2524 027376                ERRDF   42,ERR042          ; PRINT CONTROLLER DROPPED ERROR
                027376 104455                TRAP    C$ERRDF
                027400 000052                .WORD   42
                027402 000000                .WORD   0
                027404 021462                .WORD   ERR042
2525 027406 005337 002210                DEC     UTEST              ; REDUCE CONTROLLERS UNDER TEST COUNT
2526 027412 001401                BEQ     2$                ; IF MORE CONTROLLERS TO TEST,
2527 027414                DORPT   C$DRPT              ; PRINT STATISTICAL REPORT
                027414 104424                TRAP    C$DRPT
2528 027416 000261                SEC                      ; INDICATE ERROR STATUS
2529 027420 000240                NOP                      ; [DBG] INSERT HALT FOR DEBUG
2530 027422 000207                RETURN
2531
2532      ;**
2533      ;
2534      ;
2535      ;
2536      ;
2537      ;
2538      ;
2539      ;
2540      ;
2541      ;--
2542
2543 027424 032761 100000 000002 DRPUNT: BIT      @DT.AVL,D.UNIT(R1)      ; IF DRIVE ALREADY DROPPED,
2544 027432 001017                BNE     1$                ; SKIP ERROR REPORT
2545 027434 042761 147000 000002      BIC     @DT.CLR,D.UNIT(R1)      ; CLEAR TEMPORARY DRIVE FLAGS
2546 027442 005061 000060                CLR     D.CCNT(R1)          ; ZERO "COMPARE HOST DATA" COUNT
2547 027446 005061 000056                CLR     D.WCNT(R1)          ; ZERO OUTSTANDING WRITE COUNT
2548 027452 052761 100000 000002      BIS     @DT.AVL,D.UNIT(R1)      ; DISABLE DRIVE
2549 027460                ERRDF   43,ERR043          ; PRINT UNIT DROPPED ERROR
                027460 104455                TRAP    C$ERRDF
                027462 000053                .WORD   43
                027464 000000                .WORD   0
                027466 021626                .WORD   ERR043
2550 027470                DORPT   C$DRPT              ; PRINT STATISTICAL REPORT
                027470 104424                TRAP    C$DRPT
2551 027472 000261                SEC                      ; INDICATE ERROR STATUS
2552 027474 000240                NOP                      ; [DBG] INSERT HALT FOR DEBUG
2553 027476 000207                RETURN
    
```

```

2555      ;**
2556      ;
2557      ; RSPIN - CONTROLLER HAS RESPONDED. REMOVE FULL RESPONSE
2558      ; PACKET FROM RESPONSE RING. INSERT A NEW RESPONSE PACKET AND
2559      ; RETURN THE RING TO THE CONTROLLER. PROCESS THE RESPONSE
2560      ; PACKET.
2561      ;
2562      ; INPUTS:
2563      ; R5 - POINTER TO CONTROLLER TABLE
2564      ;--
2565 027500 004737 026132 RSPIN: CALL CLRRSP          ; RE-INIT RESPONSE RING
2566 027504 016504 000104      MOV C.RHDR(R5),R4      ; POINT TO FULL R.E.
2567 027510 016401 000012      MOV P.UNIT.RE.RP(R4),R1 ; GET UNIT NUMBER
2568 027514 016402 000020      MOV P.STS.RE.RP(R4),R2  ; GET STATUS/EVENT CODE
2569 027520 116403 000016      MOVB P.OPCD.RE.RP(R4),R3 ; GET
2570 027524 042703 177400      BIC #177400,R3         ; ENDCODE
2571 027530 032703 000200      BIT #200,R3           ; IF END MESSAGE,
2572 027534 001007              BNE RSPEND             ; RESPOND TO END MSG
2573 027536 032703 000100      BIT #100,R3           ; IF ATTENTION MESSAGE,
2574 027542 001002              BNE 20$                  ; RESPOND TO ATTENTION MESSAGE
2575 027544 000137 040036      JMP RSPERL             ; ELSE, RESPOND TO ERROR LOG MESSAGE
2576 027550 000137 037704      20$: JMP RSPATN          ;
    
```

```

2578
2579
2580
2581
2582
2583
2584
2585
2586
2587
2588
2589
2590
2591
2592
2593
2594 027554 032765 000400 000014 RSPEND: BIT      #CT.MRW,C.FLG(R5)      ; IF MAINTENANCE OPERATION IN
2595 027562 001006                                BNE      1#              ; PROGRESS, DON'T ADJUST CREDITS
2596 027564 016400 000004                                MOV      RE,RV(R4),R0   ; SAVE
2597 027570 042700 177760                                BIC      #C<17>,R0     ; CREDIT
2598 027574 060065 000152                                ADD      R0,C.CRED(R5) ; COUNT
2599 027600 005000                                1#: CLR      R0         ; CALCULATE
2600 027602 026003 027630                                2#: CMP      ENDNUM(R0),R3 ; DISPATCH
2601 027606 001002                                BNE      3#              ; TABLE
2602 027610 000170 027676                                JMP      @ENDADR(R0)   ; OFFSET
2603 027614 062700 000002                                3#: ADD      #2,R0      ;
2604 027620 020027 000044                                CMP      R0,#ENDSIZ   ;
2605 027624 003766                                BLE      2#              ;
2606 027626 000446                                BR       INVCMD        ; ENDCODE NOT IN LIST
2607
2608
2609
2610
2611
2612 027630 000242                                ;
2613 027632 000241                                ; END MESSAGE RESPONSE DISPATCH TABLE
2614 027634 000222                                ;
2615 027636 000220                                ;
2616 027640 000231                                ;
2617 027642 000230                                ;
2618 027644 000240                                ;
2619 027646 000202                                ;
2620 027650 000203                                ;
2621 027652 000204                                ;
2622 027654 000210                                ;
2623 027656 000211                                ;
2624 027660 000212                                ;
2625 027662 000201                                ;
2626 027664 000205                                ;
2627 027666 000213                                ;
2628 027670 000221                                ;
2629 027672 000223                                ;
2630 027674 000224                                ;
2631
2632                                000044
                                ENDSIZ = <.-ENDNUM-2> ; LEGAL NUMBERS ARE LOWER THAN THIS
    
```

```

2633
2634 027676 032166          ENDADR: .WORD  ENDWR      ; 242 - WRITE END PACKET
2635 027700 031720          .WORD  ENDRD      ; 241 - READ END PACKET
2636 027702 031120          .WORD  ENDERS      ; 222 - ERASE END PACKET
2637 027704 031004          .WORD  ENDACC      ; 220 - ACCESS END PACKET
2638 027706 031510          .WORD  ENDMWR      ; 231 - MAINTENANCE WRITE
2639 027710 031240          .WORD  ENDMRD      ; 230 - MAINTENANCE READ
2640 027712 031600          .WORD  ENDCMP      ; 240 - COMPARE HOST DATA
2641 027714 027774          .WORD  ENDGCS      ; 202 - GET COMMAND STATUS END PACKET
2642 027716 030152          .WORD  ENDGUS      ; 203 - GET UNIT STATUS END PACKET
2643 027720 030200          .WORD  ENDSCC      ; 204 - SET CONTROLLER CHARACTERISTICS
2644 027722 030274          .WORD  ENDAVL      ; 210 - AVAILABLE END PACKET
2645 027724 030364          .WORD  ENDONL      ; 211 - ONLINE END PACKET
2646 027726 030714          .WORD  ENDSUC      ; 212 - SET UNIT CHARACTERISTICS
2647 027730 027744          .WORD  INVCMD      ; 201 - ABORT END PACKET
2648 027732 027744          .WORD  INVCMD      ; 207 - SERIOUS EXCEPTION
2649 027734 027744          .WORD  INVCMD      ; 213 - DETERMINE ACCESS PATH
2650 027736 027744          .WORD  INVCMD      ; 221 - COMPARE CONTROLLER DATA
2651 027740 027744          .WORD  INVCMD      ; 223 - FLUSH END PACKET
2652 027742 027744          .WORD  INVCMD      ; 224 - REPLACE END PACKET
2653
2654          ;++
2655          ; INVCMD - REPORT INVALID END MESSAGE RECEIVED AND DROP CONTROLLER
2656          ;
2657          ;--
2658
2659 027744          INVCMD:
2661 027744 012700 023033      MOV     #DBGINV,R0      ; [DEBUG] PRINT RECEIVED MSG TYPE
2662 027750 004737 024132      CALL   DBGRSP          ; [DEBUG] & BUFFER CONTENTS
2664 027754          ERRDF  32,ERR032      ; PRINT BAD ENCODE ERROR
          027754 104455      TRAP   C$ERRDF
          027756 000040      .WORD  32
          027760 000000      .WORD  0
          027762 020312      .WORD  ERR032
2665 027764 004737 027350      CALL   DRPCNT          ; DROP CONTROLLER FROM TEST
2666 027770 000240          NOP      ; [DBG] INSERT HALT FOR DEBUG
2667 027772 000207          RETURN
2668
2669          ;++
2670          ; ENDGCS - "GET COMMAND STATUS" END MESSAGE RECEIVED
2671          ;
2672          ; IF NO CHANGE IN STATUS, COMMAND HAS TIMED OUT.
2673          ; ELSE, SAVE NEW STATUS AND RE-INIT COMMAND TIMER.
2674          ;--
2675
2676 027774          ENDGCS:
2678 027774 012700 023057      MOV     #DBGGCS,R0      ; [DEBUG] PRINT RECEIVED MSG TYPE
2679 030000 004737 024132      CALL   DBGRSP          ; [DEBUG] & BUFFER CONTENTS
2681 030004 012737 007745 002314  MOV     #OPCGCS,MSCP0P  ; POINT TO OPCODE MESSAGE STRING
2682 030012 005764 000026      TST    P.CMST+RE.RP(R4) ; IF COMMAND
2683 030016 001003          BNE    1$              ; STATUS IS ZERO
2684 030020 005764 000030      TST    P.CMST+2+RE.RP(R4) ; COMMAND IS DONE SO
2685 030024 001446          BEQ    22$             ; EXIT
2686 030026 016401 000022 1$:  MOV     P.OTRF+RE.RP(R4),R1 ; GET MESSAGE ENVELOPE
2687 030032 010400          MOV     R4,R0
    
```

```

2688 030034 004737 025550          CALL GETME          ; FOR OUTSTANDING COMMAND
2689 030040 026064 000030 000014  CMP P.CMST+2+RE.RP(R0),ME.ST2(R4); CHECK
2690 030046 103415          BLO 20$           ; IF PROGRESS
2691 030050 101004          BHI 10$           ; HAS BEEN
2692 030052 026064 000026 000012  CMP P.CMST+RE.RP(R0),ME.ST1(R4); MADE ON
2693 030060 103410          BLO 20$           ; COMMAND
2694 030062          10$: ERRDF 31,ERR031          ; REPORT TIMEOUT ERROR
      030062 104455          TRAP C$ERRDF
      030064 000037          .WORD 31
      030066 000000          .WORD 0
      030070 020264          .WORD ERR031
2695 030072 004737 027350          CALL DRPCNT          ; DROP CONTROLLER FROM TEST
2696 030076 000240          NOP                ; [DBG] INSERT HALT FOR DEBUG
2697 030100 000207          RETURN              ;
2698
2699 030102 016064 000026 000012 20$: MOV P.CMST+RE.RP(R0),ME.ST1(R4); SAVE LATEST
2700 030110 016064 000030 000014  MOV P.CMST+2+RE.RP(R0),ME.ST2(R4); COMMAND STATUS
2701 030116 042764 040000 000016  BIC #CF.CTO,ME.CFG(R4)      ; CLEAR GCS COMMAND ISSUED FLAG
2702 030124 016501 000006          MOV C.CTO(R5),R1          ; RE-INIT
2703 030130 010400          MOV R4,R0                ; COMMAND
2704 030132 062700 000006          ADD #ME.CTO,R0           ; TIMER
2705 030136 004737 052070          CALL SETTO              ;
2706 030142 004737 026006          22$: CALL RTNME          ; RETURN M.E.
2707 030146 000240          NOP                ; [DBG] INSERT HALT FOR DEBUG
2708 030150 000207          RETURN              ;
2709
2710          ;++
2711          ;
2712          ;
2713          ;
2714          ;--
2715
2716 030152          ENDGUS:
2718 030152 012700 023127          MOV #DBGGUS,R0          ; [DEBUG] PRINT RECEIVED MSG TYPE
2719 030156 004737 024132          CALL DBGRSP            ; [DEBUG] & BUFFER CONTENTS
2721 030162 012737 007772 002314  MOV #OPCGUS,MSCPOP      ; POINT TO OPCODE MESSAGE STRING
2722 030170 004737 026006          CALL RTNME             ; RETURN M.E. & CLEAR RESPONSE RING
2723 030174          10$:
2724 030174 000240          NOP                ; [DBG] INSERT HALT FOR DEBUG
2725 030176 000207          RETURN              ;
2726
2727          ;++
2728          ;
2729          ;
2730          ;--
2731
2732          ENDSCC:
2734 030200 012700 023174          MOV #DBGSCC,R0          ; [DEBUG] PRINT RECEIVED MSG TYPE
2735 030204 004737 024132          CALL DBGRSP            ; [DEBUG] & BUFFER CONTENTS
2737 030210 012737 010046 002314  MOV #OPCSCC,MSCPOP      ; POINT TO OPCODE MESSAGE STRING
2738 030216 005001          CLR R1                 ; TABLE POINTER SANITY CHECK ON CHKSTA
2739 030220 004737 032332          CALL CHKSTA            ; CHECK END MESSAGE STATUS
2740 030224 103421          BCS 20$              ; IF ERROR, EXIT
2741 030226 016465 000026 000006  MOV P.CTMO+RE.RP(R4),C.CTO(R5); GET CONTROLLER TIME OUT INTERVAL
2742 030234 016465 000032 000060  MOV P.CNTI+RE.RP(R4),C.UID(R5) ; GET
    
```

```

2743 030242 016465 000034 000062      MOV     P.CNTI+2+RE.RP(R4),C.UID+2(R5) ; CONTROLLER
2744 030250 016465 000036 000064      MOV     P.CNTI+4+RE.RP(R4),C.UID+4(R5) ; ID
2745 030256 016465 000040 000066      MOV     P.CNTI+6+RE.RP(R4),C.UID+6(R5) ;
2746 030264 004737 026006              CALL    RTNME                          ; RETURN M.E. & CLEAR RESPONSE RING
2747 030270                                20$:
2748 030270 000240                                NOP                                ; [DBG] INSERT HALT FOR DEBUG
2749 030272 000207                                RETURN                               ;
2750
2751                                ;++
2752                                ;
2753                                ;
2754                                ;
2755                                ;--
2756 030274                                ENDAVL:
2758 030274 012700 023245      MOV     #DBGAVL,R0                    ; [DEBUG] PRINT RECEIVED MSG TYPE
2759 030300 004737 024132      CALL    DBGRSP                        ; [DEBUG] & BUFFER CONTENTS
2761 030304 012737 007603 002314      MOV     #OPCAVL,MSCPOP                ; POINT TO OPCODE MESSAGE STRING
2762 030312 004737 047164      CALL    GTDRVT                        ; GET DRIVE TABLE
2763 030316 103007      BCC     1$                            ; IF TABLE NOT FOUND, PRINT ERROR
2764 030320      ERRDF  35,ERR035                    ; UNKNOWN DRIVE ERROR
                                TRAP   C$ERRDF
                                .WORD  35
                                .WORD  0
                                .WORD  ERR035
2765 030330 004737 027350      CALL    DRPCNT                        ; DROP CONTROLLER FROM TEST
2766 030334 000411      BR      20$                            ; EXIT
2767 030336 032761 100000 000002 1$:    BIT     #DT.AVL,D.UNIT(R1)            ; IF DRIVE DROPPED,
2768 030344 001003      BNE     10$                            ; IGNORE RESPONSE PACKET
2769 030346 004737 032332      CALL    CHKSTA                        ; CHECK RETURN STATUS
2770 030352 103402      BCS     20$                            ; IF ERROR, EXIT
2771 030354 004737 026006      CALL    RTNME                          ; RETURN M.E. & CLEAR RESPONSE RING
2772 030360                                10$:
2773 030360 000240                                20$:
2774 030362 000207                                NOP                                ; [DBG] INSERT HALT FOR DEBUG
2775                                RETURN                               ;
2776                                ;++
2777                                ;
2778                                ;
2779                                ;
2780                                ;
2781                                ;
2782                                ;
2783                                ;
2784                                ;
2785                                ;
2786                                ;--
2787 030364                                ENDONL:
2789 030364 012700 023304      MOV     #DBGONL,R0                    ; [DEBUG] PRINT RECEIVED MSG TYPE
2790 030370 004737 024132      CALL    DBGRSP                        ; [DEBUG] & BUFFER CONTENTS
2792 030374 012737 010014 002314      MOV     #OPCONL,MSCPOP                ; POINT TO OPCODE MESSAGE STRING
2793 030402 004737 047164      CALL    GTDRVT                        ; GET DRIVE TABLE
2794 030406 103007      BCC     1$                            ; IF TABLE NOT FOUND, PRINT ERROR
2795 030410      ERRDF  35,ERR035                    ; UNKNOWN DRIVE ERROR
                                TRAP   C$ERRDF
                                .WORD  35
    
```

030414	000000				.WORD	0	
030416	020454				.WORD	ERR035	
2796	030420	004737	027350		CALL	DRPCNT	; DROP CONTROLLER FROM TEST
2797	030424	000514			BR	20\$; EXIT
2798	030426	032761	100000	000002	1\$: BIT	#DT.AVL,D.UNIT(R1)	; IF DRIVE DROPPED,
2799	030434	001106			BNE	10\$; IGNORE RESPONSE PACKET
2800	030436	004737	032332		CALL	CHKSTA	; CHECK END MESSAGE STATUS
2801	030442	103505			BCS	20\$; IF ERROR, EXIT
2802	030444	052761	001000	000002	BIS	#DT.ONL,D.UNIT(R1)	; SET DRIVE ONLINE FLAG
2803	030452	016461	000032	000122	MOV	P.UNTI+RE.RP(R4),D.UID(R1);	SET
2804	030460	016461	000034	000124	MOV	P.UNTI+2+RE.RP(R4),D.UID+2(R1);	UNIQUE
2805	030466	016461	000036	000126	MOV	P.UNTI+4+RE.RP(R4),D.UID+4(R1);	IDENTIFIER
2806	030474	016461	000040	000130	MOV	P.UNTI+6+RE.RP(R4),D.UID+6(R1);	
2807	030502	016461	000056	000132	MOV	P.VSER+RE.RP(R4),D.VSN(R1);	SET VOLUME
2808	030510	016461	000060	000134	MOV	P.VSER+2+RE.RP(R4),D.VSN+2(R1);	SERIAL NUMBER
2809							
2810	030516	032761	020000	000002	BIT	#DT.BES,D.UNIT(R1)	; IF TESTING ENTIRE DISK,
2811	030524	001413			BEQ	2\$; SKIP
2812	030526	016461	000052	000012	MOV	P.UNSZ+RE.RP(R4),D.END1(R1);	ELSE,
2813	030534	016461	000054	000014	MOV	P.UNSZ+2+RE.RP(R4),D.END1+2(R1);	SAVE
2814	030542	162761	000001	000012	SUB	#1,D.END1(R1)	; LAST
2815	030550	005661	000014		SBC	D.END1+2(R1)	; LBN
2816	030554	016161	000006	000052	2\$: MOV	D.BGN1(R1),D.LBN(R1)	; SET NEXT LBN TO ACCESS TO
2817	030562	016161	000010	000054	MOV	D.BGN1+2(R1),D.LBN+2(R1);	FIRST BLOCK IN FIRST BEGIN/END SET
2818	030570	042761	042000	000002	BIC	#<DT.EOM+DT.DUN>,D.UNIT(R1);	CLEAR DONE TESTING & EOM FLAG
2819	030576	032761	020000	000002	BIT	#DT.BES,D.UNIT(R1)	; IF NOT USING ENTIRE DISK,
2820	030604	001022			BNE	10\$; VERIFY THEY ARE IN RANGE
2821	030606	010102			MOV	R1,R2	; GET POINTER
2822	030610	062702	000006		ADD	#D.BGN1,R2	; TO FIRST BEGIN/END SET
2823	030614	016103	000004		MOV	D.BEC(R1),R3	; GET COUNT OF BEGIN/END SETS
2824	030620	026264	000006	000054	5\$: CMP	6(R2),P.UNSZ+RE.RP+2(R4);	CHECK
2825	030626	103405			BLO	6\$; LAST
2826	030630	101014			BHI	22\$; LBN
2827	030632	026264	000004	000052	CMP	4(R2),P.UNSZ+RE.RP(R4)	; IN
2828	030640	103010			BHIS	22\$; BEGIN/END SET
2829	030642	062702	000010		6\$: ADD	#8.,R2	; GET NEXT
2830	030646	005303			DEC	R3	; BEGIN/END
2831	030650	003363			BGT	5\$; SET
2832	030652	004737	026006		10\$: CALL	RTNME	; RETURN M.E. & CLEAR RESPONSE RING
2833	030656				20\$: NOP		
2834	030656	000240					; [DBG] INSERT HALT FOR DEBUG
2835	030660	000207			RETURN		
2836							
2837	030662	062704	000052		22\$: ADD	#P.UNSZ+RE.RP,R4	; BUILD STRING CONTAINING
2838	030666	162714	000001		SUB	#1,(R4)	
2839	030672	005664	000002		SBC	2(R4)	
2840	030676	004737	047552		CALL	BLDSTR	; MAX LBN
2841	030702				ERRSF	5,ERR005	
	030702	104454			TRAP	C#ERSF	
	030704	000005			.WORD	5	
	030706	000000			.WORD	0	
	030710	017240			.WORD	ERR005	
2842	030712				DOCLN		
	030712	104444			TRAP	C#DCLN	
2843							

```

2844      ;++
2845      ;      ENDSUC - "SET UNIT CHARACTERISTICS" END MESSAGE RECEIVED
2846      ;
2847      ;--
2848
2849      ENDSUC:
2851 030714 012700 023340      MOV      #DBGSUC,R0      ; [DEBUG] PRINT RECEIVED MSG TYPE
2852 030720 004737 024132      CALL     DBGRSP          ; [DEBUG] & BUFFER CONTENTS
2854 030724 012737 010107 002314  MOV      #CPCSUC,MSCPOP ; POINT TO OPCODE MESSAGE STRING
2855 030732 004737 047164      CALL     GTDRV          ; GET DRIVE TABLE
2856 030736 103007      BCC     1$              ; IF TABLE NOT FOUND, PRINT ERROR
2857 030740      ERRDF 35,ERR035 ; UNKNOWN DRIVE ERROR
      030740 104455      TRAP   C$ERRDF
      030742 000043      .WORD  35
      030744 000000      .WORD  0
      030746 020454      .WORD  ERR035
2858 030750 004737 027350      CALL     DRPCNT         ; DROP CONTROLLER FROM TEST
2859 030754 000411      BR      20$            ; EXIT
2860 030756 032761 100000 000002 1$: BIT     #DT.AVL,D.UNIT(R1) ; IF DRIVE DROPPED,
2861 030764 001003      BNE     10$            ; IGNORE RESPONSE PACKET
2862 030766 004737 032332      CALL     CHKSTA        ; CHECK END MESSAGE STATUS
2863 030772 103402      BCS     20$            ; IF ERROR, EXIT
2864 030774 004737 026006      10$: CALL     RTNME          ; RETURN M.E. & CLEAR RESPONSE RING
2865 031000      20$:
2866 031000 000240      NOP
2867 031002 000207      RETURN                ; [DBG] INSERT HALT FOR DEBUG
2868
2869      ;++
2870      ;      ENDACC - "ACCESS" END MESSAGE RECEIVED
2871      ;
2872      ;--
2873
2874      ENDACC:
2876 031004 012700 023404      MOV      #DBGACC,R0      ; [DEBUG] PRINT RECEIVED MSG TYPE
2877 031010 004737 024132      CALL     DBGRSP          ; [DEBUG] & BUFFER CONTENTS
2879 031014 012737 007572 002314  MOV      #OPCACC,MSCPOP ; POINT TO OPCODE MESSAGE STRING
2880 031022 004737 047164      CALL     GTDRV          ; GET DRIVE TABLE
2881 031026 103007      BCC     1$              ; IF TABLE NOT FOUND, PRINT ERROR
2882 031030      ERRDF 35,ERR035 ; UNKNOWN DRIVE ERROR
      031030 104455      TRAP   C$ERRDF
      031032 000043      .WORD  35
      031034 000000      .WORD  0
      031036 020454      .WORD  ERR035
2883 031040 004737 027350      CALL     DRPCNT         ; DROP CONTROLLER FROM TEST
2884 031044 000423      BR      20$            ; EXIT
2885 031046 032761 100000 000002 1$: BIT     #DT.AVL,D.UNIT(R1) ; IF DRIVE DROPPED,
2886 031054 001015      BNE     10$            ; IGNORE RESPONSE PACKET
2887 031056 004737 032332      CALL     CHKSTA        ; CHECK END MESSAGE STATUS
2888 031062 103414      BCS     20$            ; IF ERROR, EXIT
2889 031064 066461 000022 000076  ADD     P.BCNT+RE.RP(R4),D.XFLA(R1); GET RETURNED BYTECOUNT
2890 031072 005561 000100      ADC     D.XFMA(R1)
2891 031076 066461 000024 000100  ADD     P.BCNT+RE.RP+2(R4),D.XFMA(R1);
2892 031104 005561 000102      ADC     D.XFHA(R1)
2893 031110 004737 026006      10$: CALL     RTNME          ; RETURN M.E. & CLEAR RESPONSE RING
2894 031114      20$:
    
```



```

2895 031114 000240      NOP
2896 031116 000207      RETURN          ; [DBG] INSERT HALT FOR DEBUG
2897
2898
2899      ;++
2900      ;
2901      ;--
2902
2903 031120      ENDERS:
2905 031120 012700 023440      MOV     #DBGERS,R0          ; [DEBUG] PRINT RECEIVED MSG TYPE
2906 031124 004737 024132      CALL   DBGRSP              ; [DEBUG] & BUFFER CONTENTS
2908 031130 012737 007725 002314  MOV     #OPCERS,MSCP0P      ; POINT TO OPCODE MESSAGE STRING
2909 031136 004737 047164      CALL   GTDRV0              ; GET DRIVE TABLE
2910 031142 103007      BCC    1$                  ; IF TABLE NOT FOUND, PRINT ERROR
2911 031144      ERRDF 35,ERR035          ; UNKNOWN DRIVE ERROR
      031144 104455      TRAP  C$ERRDF
      031146 000043      .WORD 35
      031150 000000      .WORD 0
      031152 020454      .WORD ERR035
2912 031154 004737 027350      CALL   DRPCNT              ; DROP CONTROLLER FROM TEST
2913 031160 000425      BR     20$                  ; EXIT
2914 031162 032761 100000 000002 1$: BIT     #DT.AVL,D.UNIT(R1)  ; IF DRIVE DROPPED,
2915 031170 001017      BNE    10$                  ; IGNORE RESPONSE PACKET
2916 031172 005361 000056      DEC    D.WCNT(R1)          ; DECREMENT OUTSTANDING WRITES
2917 031176 004737 032332      CALL   CHKSTA              ; CHECK END MESSAGE STATUS
2918 031202 103414      BCS    20$                  ; IF ERROR, EXIT
2919 031204 066461 000022 000062  ADD    P.BCNT+RE,RP(R4),D.XFLW(R1); GET RETURNED BYTECOUNT
2920 031212 005561 000064      ADC    D.XFMW(R1)
2921 031216 066461 000024 000064  ADD    P.BCNT+RE,RP+2(R4),D.XFMW(R1);
2922 031224 005561 000066      ADC    D.XFMW(R1)
2923 031230 004737 026006      10$: CALL   RTNME              ; RETURN M.E. & CLEAR RESPONSE RING
2924 031234      20$:
2925 031234 000240      NOP
2926 031236 000207      RETURN          ; [DBG] INSERT HALT FOR DEBUG
2927
2928
2929      ;++
2930      ;
2931      ;
2932      ;--
2933
2934 031240      ENDMRD:
2936 031240 012700 023473      MOV     #DBGMRD,R0          ; [DEBUG] PRINT RECEIVED MSG TYPE
2937 031244 004737 024132      CALL   DBGRSP              ; [DEBUG] & BUFFER CONTENTS
2939 031250 012737 010152 002314  MOV     #OPCMRD,MSCP0P      ; POINT TO OPCODE MESSAGE STRING
2940 031256 012765 000001 000152  MOV     #1,C.CRED(R5)        ; SET CREDITS TO 1
2941 031264 005001      CLR    R1                  ; TABLE POINTER SANITY CHECK ON CHKSTA
2942 031266 004737 032332      CALL   CHKSTA              ; CHECK END MESSAGE STATUS
2943 031272 103477      BCS    40$                  ; IF ERROR, EXIT
2944 031274 066465 000022 000052  ADD    P.BCNT+RE,RP(R4),C.XFLR(R5); GET RETURNED BYTECOUNT
2945 031302 005565 000054      ADC    C.XFMR(R5)
2946 031306 066465 000024 000054  ADD    P.BCNT+RE,RP+2(R4),C.XFMR(R5);
2947 031314 005565 000056      ADC    C.XFMR(R5)
2948
2949 031320      PUSH  <R0,R1,R2,R3,R4>    ; SAVE REGISTERS
    
```

```

031320 010046      MOV      R0,-(SP)      ; PUSH R0 ON STACK
031322 010146      MOV      R1,-(SP)      ; PUSH R1 ON STACK
031324 010246      MOV      R2,-(SP)      ; PUSH R2 ON STACK
031326 010346      MOV      R3,-(SP)      ; PUSH R3 ON STACK
031330 010446      MOV      R4,-(SP)      ; PUSH R4 ON STACK
2950 031332 016504 000104      MOV      C.RHDR(R5),R4 ; GET
2951 031336 016401 000006      MOV      P.CRF+RE.RP(R4),R1 ; POINTER TO
2952 031342 004737 025550      CALL     GETME          ; MESSAGE ENVELOPE
2953 031346 016437 000020 002242      MOV      ME.OFF(R4),TSTOFF ; GET POINTER TO DATA BUFFER
2954 031354 013703 002242      MOV      TSTOFF,R3      ; GET OFFSET TO DATA BUFFER
2955 031360 012701 002364      MOV      #OBUF,R1      ; GET POINTER TO LOW MEMORY BUFFER
2956 031364 004737 025154      CALL     MMT0BF        ; COPY INPUT BUFFER TO LOW MEMORY
2957 031370 016502 000040      MOV      C.TPAT(R5),R2 ; GET DATA PATTERN INDEX
2958 031374 006302      ASL      R2            ;
2959 031376 016400 000042      MOV      P.BCNT+ME.CP(R4),R0 ; GET
2960 031402 000241      CLC      ; WORD
2961 031404 006000      ROR      R0           ; COUNT
2962 031406 016403 000066      MOV      P.RGOFF+ME.CP(R4),R3 ; GET MEMORY OFFSET (WORD)
2963
2964 031412 022162 007036      15$:    CMP      (R1)+,MNTPAT(R2) ; CHECK BUFFER CONTENTS
2965 031416 001007      BNE      30$          ; IF NOT SAME, GO TO ERROR ROUTINE
2966 031420 005203      INC      R3          ; CHECK
2967 031422 005300      DEC      R0          ; NEXT
2968 031424 003372      BGT      15$         ; WORD
2969 031426 004737 026006      CALL     RTNME        ; RETURN M.E. & CLEAR RESPONSE RING
2970 031432 000241      CLC      ; CLEAR CARRY TO INDICATE SUCCESS
2971 031434 000416      BR       40$         ;
2972
2973 031436 010337 004406      30$:    MOV      R3,BCLO      ; OF BAD DATA
2974 031442 016237 007036 004364      MOV      MNTPAT(R2),PCGOOD ; POINT TO
2975 031450 016137 177776 004366      MOV      -2(R1),PCBAD   ; FAILING DATA
2976 031456      ERRDF  39,ERR039     ; PRINT DATA COMPARE ERROR
031456 104455      TRAP    C+ERDF
031460 000047      .WORD  39
031462 000000      .WORD  0
031464 020714      .WORD  ERR039
2977 031466 004737 027350      CALL     DRPCNT       ; DROP CONTROLLER
2978
2979      40$:    POP      <R4,R3,R2,R1,R0> ; RESTORE SAVED REGISTERS
031472 012604      MOV      (SP)+,R4     ; POP STACK INTO R4
031474 012603      MOV      (SP)+,R3     ; POP STACK INTO R3
031476 012602      MOV      (SP)+,R2     ; POP STACK INTO R2
031500 012601      MOV      (SP)+,R1     ; POP STACK INTO R1
031502 012600      MOV      (SP)+,R0     ; POP STACK INTO R0
2980 031504 000240      NOP      ; [DBG] INSERT HALT FOR DEBUG
2981 031506 000207      RETURN ;
2982
2983      ;++
2984      ;
2985      ;
2986      ;--
2987
2988 031510      ENDMWR:
2990 031510 012700 023526      MOV      #DBGMWR,R0   ; [DEBUG] PRINT RECEIVED MSG TYPE
2991 031514 004737 024132      CALL     DBGRSP       ; [DEBUG] & BUFFER CONTENTS
    
```

```

2993 031520 012737 010175 002314      MOV      #OPCMWR, MSCPOP          ; POINT TO OPCODE MESSAGE STRING
2994 031526 012765 000001 000152      MOV      #1, C.CRED(R5)          ; SET CREDITS TO 1
2995 031534 005001                    CLR      R1                      ; TABLE POINTER SANITY CHECK ON CHKSTA
2996 031536 004737 032332      CALL     CHKSTA                  ; CHECK END MESSAGE STATUS
2997 031542 103414                    BCS     10$                      ; IF ERROR, EXIT
2998 031544 066465 000022 000044      ADD     P.B'NT+RE, RP(R4), C.XFLW(R5); GET RETURNED BYTECOUNT
2999 031552 005565 000046                    ADC     C.XFMW(R5)
3000 031556 066465 000024 000046      ADD     P.B'NT+RE, RP+2(R4), C.XFMW(R5);
3001 031564 005565 000050                    ADC     C.XFMW(R5)
3002 031570 004737 026006      CALL     RTNME                   ; RETURN M.E. & CLEAR RESPONSE RING
3003 031574                    10$:
3004 031574 000240                    NOP                               ; [DBG] INSERT HALT FOR DEBUG
3005 031576 000207      RETURN
3006
3007
3008
3009
3010
3011
3012 031600      ENDCMP:
3014 031600 012700 023562      MOV      #DBGCMP, R0             ; [DEBUG] PRINT RECEIVED MSG TYPE
3015 031604 004737 024132      CALL     DBGRSP                  ; [DEBUG] & BUFFER CONTENTS
3017 031610 012737 007651 002314      MOV      #OPCCMP, MSCPOP        ; POINT TO OPCODE MESSAGE STRING
3018 031616 004737 047164      CALL     GTDRV                  ; GET DRIVE TABLE
3019 031622 103007      BCC     1$                      ; IF TABLE NOT FOUND, PRINT ERROR
3020 031624      ERROF 35, ERRO35              ; UNKNOWN DRIVE ERROR
      031624 104455      TRAP   C:ERDF
      031626 000043      .WORD 35
      031630 000000      .WORD 0
      031632 020454      .WORD ERRO35
3021 031634 004737 027350      CALL     DRPCNT                 ; DROP CONTROLLER FROM TEST
3022 031640 000425                    BR      20$                      ; EXIT
3023 031642 032761 100000 000002 1$:   BIT      #DT.AVL, D.UNIT(R1)     ; IF DRIVE DROPPED,
3024 031650 001017                    BNE     10$                      ; IGNORE RESPONSE PACKET
3025 031652 005361 000060      DEC     D.CCNT(R1)              ; DECREMENT OUTSTANDING CMP COUNT
3026 031656 004737 032332      CALL     CHKSTA                  ; CHECK END MESSAGE STATUS
3027 031662 103414                    BCS     20$                      ; IF ERROR, EXIT
3028 031664 066461 000022 000104      ADD     P.BCNT+RE, RP(R4), D.XFLC(R1); GET RETURNED BYTECOUNT
3029 031672 005561 000106                    ADC     D.XFMC(R1)
3030 031676 066461 000024 000106      ADD     P.BCNT+RE, RP+2(R4), D.XFMC(R1);
3031 031704 005561 000110                    ADC     D.XFMC(R1)
3032 031710 004737 026006      CALL     RTNME                   ; RETURN M.E. & CLEAR RESPONSE RING
3033 031714                    10$:
3034 031714 000240                    20$:
3035 031716 000207      NOP                               ; [DBG] INSERT HALT FOR DEBUG
3036      RETURN
3037
3038
3039
3040
3041
3042 031720      ENDRD:
3044 031720 012700 023616      MOV      #DBGDRD, R0            ; [DEBUG] PRINT RECEIVED MSG TYPE
3045 031724 004737 024132      CALL     DBGRSP                  ; [DEBUG] & BUFFER CONTENTS
3047 031730 012737 010025 002314      MOV      #OPCRD, MSCPOP        ; POINT TO OPCODE MESSAGE STRING
    
```

```

3048 031736 004737 047164      CALL  GTDRV      ; GET DRIVE TABLE
3049 031742 103007              BCC   10        ; IF TABLE NOT FOUND, PRINT ERROR
3050 031744              ERRDF  35,ERR035 ; UNKNOWN DRIVE ERROR
      031744 104455              TRAP  C,ERRDF
      031746 000043              .WORD 35
      031750 000000              .WORD 0
      031752 020454              .WORD ERRO35
3051 031754 004737 027350      CALL  DRPCNT     ; DROP CONTROLLER FROM TEST
3052 031760 000500              BR    20        ; EXIT
3053 031762 032761 100000 000002 10: BIT  #0T.AVL,D.UNIT(R1) ; IF DRIVE DROPPED,
3054 031770 001072              BNE   11        ; IGNORE RESPONSE PACKET
3055 031772 004737 032332      CALL  CHKSTA     ; CHECK END MESSAGE STATUS
3056 031776 103471              BCS   20        ; IF ERROR, EXIT
3057 032000 066461 000022 000070  ADD  P.BCNT+RE,RP(R4),D.XFLR(R1); GET RETURNED BYTECOUNT
3058 032006 005561 000072      ADC  D.XFMR(R1)
3059 032012 066461 000024 000072  ADD  P.BCNT+RE,RP+2(R4),D.XFMR(R1);
3060 032020 005561 000074      ADC  D.XFMR(R1)
3061
3062 032024 032765 002000 000014  BIT  #CT.DET,C.FLG(R5) ; IF DETERMINISTIC PHASE,
3063 032032 001051              BNE   11        ; DON'T DO PATTERN CHECK
3064 032034 032737 000004 002154  BIT  #SM.PCK,SO.BIT+SFPTBL ; IF PATTERN CHECK NOT SELECTED,
3065 032042 001445              BEQ   11        ; DON'T DO PATTERN CHECKS
3066 032044              PUSH <R1>      ; SAVE REGISTER
      032044 010146              MOV  R1,-(SP)   ; PUSH R1 ON STACK
3067 032046 012701 000017              MOV  #15.,R1   ; DO
3068 032052 005002              CLR  R2        ; DATA
3069 032054 004737 026250      CALL  RANDOM     ; PATTERN
3070 032060 005701              TST  R1        ; VERIFICATION?
3071 032062 001034              BNE   10        ;
3072 032064              POP  <R1>      ; RESTORE REGISTER
      032064 012601              MOV  (SP)+,R1  ; POP STACK INTO R1
3073 032066 066461 000022 000104  ADD  P.BCNT+RE,RP(R4),D.XFLC(R1); GET RETURNED BYTECOUNT
3074 032074 005561 000106      ADC  D.XFMC(R1)
3075 032100 066461 000024 000106  ADD  P.BCNT+RE,RP+2(R4),D.XFMC(R1);
3076 032106 005561 000110      ADC  D.XFMC(R1)
3077 032112 004737 046100      CALL  PATCHK    ; DO PATTERN CHECK
3078 032116 103017              BCC   11        ; CARRY CLEAR ON SUCCESS
3079 032120 005261 000116      INC  D.CERR(R1) ; INCREMENT COMPARE ERROR COUNT
3080 032124 005261 000112      INC  D.HERR(R1) ; INCREMENT HARD ERROR COUNT
3081 032130 005737 002144      TST  SO.EL+SFPTBL ; IF HARD ERROR LIMIT ZERO,
3082 032134 001412              BEQ   20        ; DON'T DROP DRIVE
3083 032136 026137 000112 002144  CMP  D.HERR(R1),SO.EL+SFPTBL ; EXCEEDED
3084 032144 103406              BLO  20        ; HARD ERROR LIMIT?
3085 032146 004737 027424      CALL  DRPUNT    ; DROP DRIVE
3086 032152 000403              BR    20        ;
3087 032154              POP  <R1>      ; RESTORE SAVED REGISTER
      032154 012601              MOV  (SP)+,R1  ; POP STACK INTO R1
3088 032156 004737 026006      CALL  RTNME     ; RETURN M.E. & CLEAR RESPONSE RING
3089 032162              NOP
3090 032162 000240              NOP
3091 032164 000207      RETURN ; [DBG] INSERT HALT FOR DEBUG
3092
3093 ;++
3094 ;
3095 ;
    
```

```

3096      :      IF DT.CMP SET & D.WCNT = 0, ISSUE COMPARE HOST DATA COMMAND USING
3097      :      MESSAGE ENVELOPE FROM LAST WRITE COMMAND.
3098      :      ;--
3099
3100      :      ENDWR:
3101 032166      012700      023650      MOV      #DBGWR,R0      ; [DEBUG] PRINT RECEIVED MSG TYPE
3102 032166      004737      024132      CALL     DBGRSP      ; [DEBUG] & BUFFER CONTENTS
3103 032172      004737      024132      MOV      #OPCWR,MSCPOP ; POINT TO OPCODE MESSAGE STRING
3104 032176      012737      010142      002314      CALL     GTDRVT      ; GET DRIVE TABLE
3105 032204      004737      047164      BCC     1#           ; IF TABLE NOT FOUND, PRINT ERROR
3106 032210      103007      ERRDF   35,ERR035    ; UNKNOWN DRIVE ERROR
3107 032212      104455      TRAP   C+ERRDF
3108 032212      000043      .WORD  35
3109 032216      000000      .WORD  0
3110 032220      020454      .WORD  ERR035
3111 032222      004737      027350      CALL     DRPCNT      ; DROP CONTROLLER FROM TEST
3112 032226      000437      BR      20#         ; EXIT
3113 032230      032761      100000      000002      1# : BIT      #DT.AVL,D.UNIT(R1) ; IF DRIVE DROPPED
3114 032236      001031      BNE     10#         ; IGNORE RESPONSE PACKET
3115 032240      005361      000056      DEC     D.WCNT(R1)  ; ANY OUTSTANDING WRITES?
3116 032244      004737      032332      CALL     CHKSTA     ; CHECK END MESSAGE STATUS
3117 032250      103426      BCS     20#         ; IF ERROR, EXIT
3118 032252      066461      000022      000062      ADD     P.BCNT+RE,RP(R4),D.XFLW(R1); GET RETURNED BYTECOUNT
3119 032260      005561      000064      ADC     D.XFM(R1)
3120 032264      066461      000024      000064      ADD     P.BCNT+RE,RP+2(R4),D.XFM(R1);
3121 032272      005561      000066      ADC     D.XFM(R1)
3122 032276      005761      000056      TST     D.WCNT(R1)  ; IF OUTSTANDING WRITES <> 0,
3123 032302      001007      BNE     10#         ; EXIT
3124 032304      032761      004000      000002      BIT      #DT.CMP,D.UNIT(R1) ; DO COMPARE HOST DATA?
3125 032312      001403      BEQ     10#         ;
3126 032314      004737      050360      CALL     CMPND      ; DO IT
3127 032320      000402      BR      20#         ;
3128 032322      004737      026006      10# : CALL     RTIME     ; RETURN M.E. & CLEAR RESPONSE RING
3129 032326      000240      20# :
3130 032330      000207      NOP
3131      :      RETURN      ; [DBG] INSERT HALT FOR DEBUG
3132      :
    
```

3132
 3133
 3134
 3135
 3136
 3137
 3138
 3139
 3140
 3141
 3142
 3143
 3144
 3145
 3146
 3147
 3148
 3149
 3150
 3151
 3152
 3153
 3154
 3155
 3156
 3157
 3158
 3159
 3160
 3161
 3162
 3163
 3164
 3165
 3166
 3167
 3168
 3169
 3170
 3171
 3172
 3173
 3174
 3175
 3176
 3177
 3178
 3179
 3180
 3181
 3182
 3183
 3184
 3185

032332
 032332 010246
 032334 042702 177740
 032340 005000
 032342 026002 032372
 032346 001002
 032350 000170 032422
 032354 005200
 032356 005200
 032360 020027 000026
 032364 003766
 032366 000137 033114
 032372 000000
 032374 000001
 032376 000002
 032400 000003
 032402 000004
 032404 000005
 032406 000006
 032410 000007
 032412 000010
 032414 000011
 032416 000012
 032420 000013
 000026
 032422 032452
 032424 033024
 032426 033220
 032430 033250
 032432 033700
 032434 034000
 032436 034320
 032440 034562
 032442 034702

```

: **
:
:   CHKSTA - OBTAIN STATUS/EVENT CODE OF END MESSAGE, TRANSLATE IT TO
:   ASCII, AND PRINT AN ERROR MESSAGE IF AN ERROR STATUS IS RETURNED.
:
: INPUTS:
:   R1 - DRIVE TABLE POINTER
:   R2 - STATUS/EVENT CODE
:   R3 - ENDCODE
:   R4 - POINTER TO RESPONSE PACKET
:   R5 - CONTROLLER TABLE ADDRESS
:
: OUTPUTS:
:   STAMSO - STATUS MESSAGE
:   STAMS1 - SUBCODE MESSAGE
:   CARRY CLEAR ON "SUCCESS"
:   CARRY SET ON "ERROR"
:
: --
CHKSTA: PUSH    <R2>                ; SAVE REGISTERS
        MOV     R2, -(SP)          ; PUSH R2 ON STACK
        BIC     @†CST.MSK,R2      ; GET STATUS CODE
        CLR     R0                 ; CALCULATE
        1$:    CMP     STACOD(R0),R2 ; DISPATCH
        BNE     2$                ; TABLE
        JMP     @STAADR(R0)       ; OFFSET
        2$:    INC     R0          ;
        INC     R0                ;
        CMP     R0, @STASIZ       ;
        BLE     1$                ;
        JMP     STAUNK            ; STATUS CODE NOT IN LIST

STACOD: .WORD   0                ; 00 - SUCCESS
        .WORD   1                ; 01 - INVALID COMMAND
        .WORD   2                ; 02 - COMMAND ABORTED
        .WORD   3                ; 03 - UNIT OFFLINE
        .WORD   4                ; 04 - UNIT AVAILABLE
        .WORD   5                ; 05 - MEDIA FORMAT ERROR
        .WORD   6                ; 06 - WRITE PROTECTED
        .WORD   7                ; 07 - COMPARE ERROR
        .WORD   8                ; 08 - DATA ERROR
        .WORD   9                ; 09 - HOST BUFFER ACCESS ERROR
        .WORD  10                ; 10 - CONTROLLER ERROR
        .WORD  11                ; 11 - DRIVE ERROR

STASIZ =    <.-STACOD-2>        ; LEGAL NUMBERS ARE LOWER THAN THIS

STAADR: .WORD   STASUC           ; 00 - SUCCESS
        .WORD   STAINV          ; 01 - INVALID COMMAND
        .WORD   STAABO          ; 02 - COMMAND ABORTED
        .WORD   STAOFI         ; 03 - UNIT OFFLINE
        .WORD   STAAVA          ; 04 - UNIT AVAILABLE
        .WORD   STAMFE          ; 05 - MEDIA FORMAT ERROR
        .WORD   STAWPR          ; 06 - WRITE PROTECTED
        .WORD   STACMP          ; 07 - COMPARE ERROR
        .WORD   STADAT          ; 08 - DATA ERROR
    
```

```

3186 032444 035630 .WORD STAHST ; 09 - HOST BUFFER ACCESS ERROR
3187 032446 036220 .WORD STACNT ; 10 - CONTROLLER ERROR
3188 032450 037004 .WORD STADRV ; 11 - DRIVE ERROR
3189
3190
3191 ;++
3192 ; STASUC - "SUCCESS" STATUS RETURNED
3193 ;
3194 ;--
3195 032452 STASUC: POP <R2> ; RESTORE REGISTERS
032452 012602 MOV (SP)+,R2 ; POP STACK INTO R2
3196 032454 032737 020000 002204 BIT @IERL,IFLAGS ; IF NOT ERROR LOG,
3197 032462 001460 BEQ 99$ ; DON'T NEED SUCCESS MESSAGE
3198 032464 022702 000040 CMP @SC.SPI,R2 ; SPIN-DOWN IGNORED?
3199 032470 001004 BNE 2$
3200 032472 012737 032645 002320 MOV @MSSUC1,STAMS1
3201 032500 000446 BR 20$
3202 032502 022702 000100 2$: CMP @SC.STC,R2 ; STILL CONNECTED?
3203 032506 001004 BNE 3$
3204 032510 012737 032667 002320 MOV @MSSUC2,STAMS1
3205 032516 000437 BR 20$
3206 032520 022702 000200 3$: CMP @SC.DUP,R2 ; DUPLICATE UNIT NUMBER?
3207 032524 001004 BNE 4$
3208 032526 012737 032707 002320 MOV @MSSUC3,STAMS1
3209 032534 000430 BR 20$
3210 032536 022702 000400 4$: CMP @SC.AOL,R2 ; ALREADY ONLINE?
3211 032542 001004 BNE 5$
3212 032544 012737 032735 002320 MOV @MSSUC4,STAMS1
3213 032552 000421 BR 20$
3214 032554 022702 001000 5$: CMP @SC.SOL,R2 ; STILL ONLINE?
3215 032560 001004 BNE 6$
3216 032562 012737 032754 002320 MOV @MSSUC5,STAMS1
3217 032570 000412 BR 20$
3218 032572 022702 010000 6$: CMP @SC.ROV,R2 ; READ ONLY (VOLUME FORMAT)?
3219 032576 001004 BNE 7$
3220 032600 012737 032771 002320 MOV @MSSUC6,STAMS1
3221 032606 000403 BR 20$
3222 032610 012737 010221 002320 7$: MOV @BLANK,STAMS1 ; SUBCODE NOT IN LIST
3223 032616 012737 032632 002316 20$: MOV @MSSUC0,STAMSO ; INDICATE SUCCESS
3224 032624 000241 99$: CLC ; [DBG] INSERT HALT FOR DEBUG
3225 032626 000240 NOP
3226 032630 000207 RETURN
3227
3228 032632 123 125 103 MSSUC0: .ASCIZ /SUCCESS - /
3229 032645 123 120 111 MSSUC1: .ASCIZ /SPIN-DOWN IGNORED/
3230 032667 123 124 111 MSSUC2: .ASCIZ /STILL CONNECTED/
3231 032707 104 125 120 MSSUC3: .ASCIZ /DUPLICATE UNIT NUMBER/
3232 032735 101 114 122 MSSUC4: .ASCIZ /ALREADY ONLINE/
3233 032754 123 124 111 MSSUC5: .ASCIZ /STILL ONLINE/
3234 032771 122 105 101 MSSUC6: .ASCIZ /READ ONLY (VOLUME FORMAT)/
3235 .EVEN
3236
3237 ;++
3238 ; STAINV - "INVALID COMMAND" STATUS RETURNED
3239 ;--
    
```

```

3240
3241 033024          STAINV: POP      <R2>                ; RESTORE REGISTERS
      033024 012602  MOV      (SP)+,R2                ; POP STACK INTO R2
3242 033026 012737 010221 002320  MOV      #BLANK,STAMS1          ; NO SUBCODES AVAILABLE
3243 033034 012737 033074 002316  MOV      #MSINV0,STAMSO         ;
3244 033042 032737 020000 002204  BIT      #IERL,IFLAGS          ; IF ERROR LOG
3245 033050 001006          BNE      99$                ; DON'T PRINT ERROR
3246 033052          ERRSF   34,,ERR034              ; REPORT ERROR STATUS
      033052 104454  TRAP     C$ERSF
      033054 000042  .WORD   34
      033056 000000  .WORD   0
      033060 020402  .WORD   ERR034
3247 033062 004737 027350          CALL   DRPCNT                ; DROP CONTROLLER FROM TEST
3248 033066 000261          SEC                        ; SET CARRY FOR ERROR
3249 033070 000240          NOP                        ; [DBG] INSERT HALT FOR DEBUG
3250 033072 000207          RETURN
3251
3252 033074 111 116 126 MSINV0: .ASCIZ  /INVALID COMMAND/
3253          .EVEN
3254
3255          ;++
3256          ; STAUNK - UNKNOWN STATUS RETURNED
3257          ;--
3258
3259 033114          STAUNK: POP      <R2>                ; RESTORE REGISTERS
      033114 012602  MOV      (SP)+,R2                ; POP STACK INTO R2
3260 033116 012737 010221 002320  MOV      #BLANK,STAMS1          ; NO SUBCODES AVAILABLE
3261 033124 012737 033164 002316  MOV      #MSUNK0,STAMSO         ;
3262 033132 032737 020000 002204  BIT      #IERL,IFLAGS          ; IF ERROR LOG
3263 033140 001006          BNE      99$                ; DON'T PRINT ERROR
3264 033142          ERRDF   33,,ERR033              ; REPORT ERROR STATUS
      033142 104455  TRAP     C$ERDF
      033144 000041  .WORD   33
      033146 000000  .WORD   0
      033150 020346  .WORD   ERR033
3265 033152 004737 027350          CALL   DRPCNT                ; DROP CONTROLLER FROM TEST
3266 033156 000261          SEC                        ; SET CARRY FOR ERROR
3267 033160 000240          NOP                        ; [DBG] INSERT HALT FOR DEBUG
3268 033162 000207          RETURN
3269
3270 033164 125 116 113 MSUNK0: .ASCIZ  /UNKNOWN COMMAND STATUS CODE/
3271          .EVEN
3272
3273          ;++
3274          ; STAABO - "COMMAND ABORTED" STATUS RETURNED
3275          ; DON'T PRINT AN ERROR MESSAGE.
3276          ; SET CARRY SO THE END MESSAGE WILL BE PUT IN THE BIT BUCKET.
3277          ;--
3278
3279 033220          STAABO: POP      <R2>                ; RESTORE REGISTERS
      033220 012602  MOV      (SP)+,R2                ; POP STACK INTO R2
3280 033222 012737 010221 002320  MOV      #BLANK,STAMS1          ; SO ERROR LOGS
3281 033230 012737 010221 002316  MOV      #BLANK,STAMSO         ; PRINT PROPERLY
3282 033236 004737 026006          CALL   RTNME                ; RETURN M.E. & CLEAR RESPONSE RING
3283 033242 000261          SEC                        ; INDICATE ERROR STATUS
    
```



```

3284 033244 000240      NOP      ; [DBG] INSERT HALT FOR DEBUG
3285 033246 000207      RETURN
3286
3287      ;++
3288      ;
3289      ;--
3290
3291 033250      STAOF1: POP      <R2>      ; RESTORE REGISTERS
      033250 012602      MOV      (SP)+,R2      ; POP STACK INTO R2
3292 033252 042702 000037      BIC      #ST.MSK,R2      ; GET SUBCODE
3293 033256 022702 000040      CMP      #SC.NVL,R2      ; NO VOLUME MOUNTED OR DRIVE DISABLED?
3294 033262 001004      BNE
3295 033264 012737 033460 002320      MOV      #MSOFL1,STAMS1
3296 033272 000436      BR      2$
3297 033274 022702 000100      2$:      CMP      #SC.IOP,R2      ; UNIT INOPERATIVE?
3298 033300 001004      BNE      3$
3299 033302 012737 033524 002320      MOV      #MSOFL2,STAMS1
3300 033310 000427      BR      20$
3301 033312 022702 000400      3$:      CMP      #SC.DIS,R2      ; UNIT DISABLED BY FIELD SERVICE?
3302 033316 001004      BNE      4$
3303 033320 012737 033545 002320      MOV      #MSOFL3,STAMS1
3304 033326 000420      BR      20$
3305 033330 022702 000200      4$:      CMP      #SC.DUP,R2      ; DUPLICATE UNIT NUMBER?
3306 033334 001004      BNE      5$
3307 033336 012737 033604 002320      MOV      #MSOFL4,STAMS1
3308 033344 000411      BR      20$
3309 033346 005702      5$:      TST      R2      ; UNIT UNKNOWN OR ONLINE OTHER CTRLR
3310 033350 001004      BNE      6$
3311 033352 012737 033632 002320      MOV      #MSOFL5,STAMS1
3312 033360 000403      BR      20$
3313 033362 012737 010221 002320      6$:      MOV      #BLANK,STAMS1      ; SUBCODE NOT IN LIST
3314 033370 012737 033440 002316      20$:      MOV      #MSOFL0,STAMS0
3315 033376 032737 020000 002204      BIT      #IERL,IFLAGS      ; IF ERROR LOG,
3316 033404 001012      BNE      99$      ; DON'T PRINT ERROR
3317 033406 005261 000112      INC      D.HERR(R1)      ; INCREMENT HARD ERROR COUNT
3318 033412      ERRDF 41,ERR041      ; REPORT ERROR STATUS
      033412 104455      TRAP  C$ERRDF
      033414 000051      .WORD 41
      033416 000000      .WORD 0
      033420 021240      .WORD ERR041
3319 033422 004737 027424      CALL  DRPUNT      ; DROP DRIVE
3320 033426 004737 026006      CALL  RTNME      ; RETURN M.E. & CLEAR RESPONSE RING
3321 033432 000261      99$:      SEC      ; INDICATE ERROR STATUS
3322 033434 000240      NOP
3323 033436 000207      RETURN      ; [DBG] INSERT HALT FOR DEBUG
3324
3325 033440      125      116      111  MSOFL0: .ASCIZ /UNIT OFFLINE - /
3326 033460      116      117      040  MSOFL1: .ASCIZ /NO VOLUME MOUNTED OR DRIVE DISABLED/
3327 033524      125      116      111  MSOFL2: .ASCIZ /UNIT INOPERATIVE/
3328 033545      125      116      111  MSOFL3: .ASCIZ /UNIT DISABLED BY FIELD SERVICE/
3329 033604      104      125      120  MSOFL4: .ASCIZ /DUPLICATE UNIT NUMBER/
3330 033632      125      116      111  MSOFL5: .ASCIZ /UNIT UNKNOWN OR ONLINE TO OTHER CTRLR/
3331      .EVEN
3332
3333      ;++
    
```

```

3334      ;      STAAVA - "UNIT AVAILABLE" STATUS RETURNED
3335      ;--
3336
3337      STAAVA: POP      <R2>      ; RESTORE REGISTERS
              MOV      (SP)+,R2    ; POP STACK INTO R2
3338      033700 012602      ; NO SUBCODES AVAILABLE
              MOV      #BLANK,STAMS1
3339      033702 012737 010221 002320
              MOV      #MSAVAO,STAMSO
3340      033710 012737 033760 002316
              BIT      #IERL,IFLAGS
3341      033716 032737 020000 002204
              BNE     99$          ; IF ERROR LOG
3342      033724 001012      ; DON'T PRINT ERROR
              INC     D.HERR(R1)   ; INCREMENT HARD ERROR COUNT
3343      033726 005261 000112
              ERRDF  41,ERR041    ; REPORT ERROR STATUS
              TRAP   C$ERDF
              .WORD  41
              .WORD  0
              .WORD  ERRO41
3344      033732 104455
              .WORD  0
              .WORD  ERRO41
3345      033734 000051
              .WORD  0
              .WORD  ERRO41
3346      033736 000000
              .WORD  0
              .WORD  ERRO41
3347      033740 021240
              .WORD  0
              .WORD  ERRO41
3348      033742 004737 027424
              CALL   DRPUNT        ; DROP DRIVE
3349      033744 004737 026006
              CALL   RTNME         ; RETURN M.E. & CLEAR RESPONSE RING
3350      033752 000261
              SEC                  ; INDICATE ERROR STATUS
3351      033754 000240
              NOP                  ; [DBG] INSERT HALT FOR DEBUG
3352      033756 000207
              RETURN
3353
3354      MSAAVA: .ASCIZ /UNIT AVAILABLE/
3355      033760      125      116      111
              .EVEN
3356
3357      ;++
3358      ;      STAMFE - "MEDIA FORMAT ERROR" STATUS RETURNED
3359      ;--
3360
3361      STAMFE: POP      <R2>      ; RESTORE REGISTERS
              MOV      (SP)+,R2    ; POP STACK INTO R2
3362      034000 012602      ; GET SUBCODE
              BIC      #ST.MSK,R2   ; DISK FORMATTED WITH 576 BYTE SECTORS?
3363      034002 042702 000037
              CMP      #SC.576,R2
3364      034006 022702 000240
              BNE     2$          ;
3365      034012 001004
              MOV      #MSMFE1,STAMS1
3366      034014 012737 034202 002320
              BR     20$         ;
3367      034022 000430
              CMP      #SC.FCT,R2  ; FCT CORRUPT?
3368      034024 022702 000300 2$:
              BNE     3$          ;
3369      034030 001004
              MOV      #MSMFE2,STAMS1
3370      034032 012737 034247 002320
              BR     20$         ;
3371      034040 000421
              CMP      #SC.RCT,R2  ; RCT CORRUPT?
3372      034042 022702 000400 3$:
              BNE     4$          ;
3373      034046 001004
              MOV      #MSMFE3,STAMS1
3374      034050 012737 034263 002320
              BR     20$         ;
3375      034056 000412
              CMP      #SC.RBN,R2  ; NO RBN AVAILABLE
3376      034060 022702 000440 4$:
              BNE     5$          ;
3377      034064 001004
              MOV      #MSMFE4,STAMS1
3378      034066 012737 034277 002320
              BR     20$         ;
3379      034074 000403
              MOV      #BLANK,STAMS1
3380      034076 012737 010221 002320 5$:
              MOV      #MSMFE0,STAMSO
3381      034104 012737 034154 002316 20$:
              BIT      #IERL,IFLAGS
3382      034112 032737 020000 002204
              BNE     99$          ; IF ERROR LOG
3383      034120 001012      ; DON'T PRINT ERROR
              INC     D.HERR(R1)   ; INCREMENT HARD ERROR COUNT
3384      034122 005261 000112
              ERRDF  41,ERR041    ; REPORT ERROR STATUS
              TRAP   C$ERDF
              .WORD  41
3385      034126 104455
              .WORD  41
3386      034130 000051
    
```

```

034132 000000 .WORD 0
034134 021240 .WORD ERRO41
3381 034136 004737 027424 CALL DRPUNT ; DROP DRIVE
3382 034142 004737 026006 CALL RTNME ; RETURN M.E. & CLEAR RESPONSE RING
3383 034146 000261 99$: SEC ; INDICATE ERROR STATUS
3384 034150 000240 NOP ; [DBG] INSERT HALT FOR DEBUG
3385 034152 000207 RETURN ;
3386
3387 034154 115 105 104 MSMFEO: .ASCIZ /MEDIA FORMAT ERROR - /
3388 034202 104 111 123 MSMFE1: .ASCIZ /DISK FORMATTED WITH 576 BYTE SECTORS/
3389 034247 106 103 124 MSMFE2: .ASCIZ /FCT CORRUPT/
3390 034263 122 103 124 MSMFE3: .ASCIZ /RCT CORRUPT/
3391 034277 116 117 040 MSMFE4: .ASCIZ /NO RBN AVAILABLE/
3392 .EVEN
3393
3394 ;++
3395 ; STAWPR - "WRITE PROTECTED" STATUS RETURNED
3396 ;--
3397
3398 STAWPR: POP <R2> ; RESTORE REGISTERS
034320 012602 MOV (SP)+,R2 ; POP STACK INTO R2
3399 034322 042702 000037 BIC #ST.MSK,R2 ; GET SUBCODE
3400 034326 022702 020000 CMP #SC.HWP,R2 ; HARDWARE WRITE PROTECT?
3401 034332 001004 BNE 2$ ;
3402 034334 012737 034457 002320 MOV #MSWPR1,STAMS1 ;
3403 034342 000412 BR 20$ ;
3404 034344 022702 010000 2$: CMP #SC.SWP,R2 ; SOFTWARE WRITE PROTECT?
3405 034350 001004 BNE 3$ ;
3406 034352 012737 034520 002320 MOV #MSWPR2,STAMS1 ;
3407 034360 000403 BR 20$ ;
3408 034362 012737 010221 002320 3$: MOV #BLANK,STAMS1 ; SUBCODE NOT IN LIST
3409 034370 012737 034434 002316 20$: MOV #MSWPRO,STAMSO ;
3410 034376 032737 020000 002204 BIT #IERL,IFLAGS ; IF ERROR LOG
3411 034404 001010 BNE 99$ ; DON'T PRINT ERROR
3412 034406 005261 000114 INC D.SERR(R1) ; INCREMENT SOFT ERROR COUNT
3413 034412 ERRSOFT 41, ERRO41 ; REPORT ERROR STATUS
034412 104457 TRAP C$ERSOFT
034414 000051 .WORD 41
034416 000000 .WORD 0
034420 021240 .WORD ERRO41
3414 034422 004737 026006 CALL RTNME ; RETURN M.E. & CLEAR RESPONSE RING
3415 034426 000261 99$: SEC ; INDICATE ERROR STATUS
3416 034430 000240 NOP ; [DBG] INSERT HALT FOR DEBUG
3417 034432 000207 RETURN ;
3418
3419 034434 127 122 111 MSWPRO: .ASCIZ /WRITE PROTECTED - /
3420 034457 125 116 111 MSWPR1: .ASCIZ /UNIT IS HARDWARE WRITE PROTECTED/
3421 034520 125 116 111 MSWPR2: .ASCIZ /UNIT IS SOFTWARE WRITE PROTECTED/
3422 .EVEN
3423
3424 ;++
3425 ; STACMP - "COMPARE ERROR" STATUS RETURNED
3426 ;--
3427
3428 034562 STACMP: POP <R2> ; RESTORE REGISTERS
    
```

```

3429 034562 012602          MOV      (SP)+,R2          ; POP STACK INTO R2
3430 034564 012737 010221 002320  MOV      #BLANK,STAMS1    ; NO SUBCODES AVAILABLE
3431 034572 012737 034664 002316  MOV      #MSCMPO,STAMSO   ;
3432 034600 032737 020000 002204  BIT      #IERL,IFLAGS     ; IF ERROR LOG,
3433 034606 001023          BNE      99$              ; DON'T PRINT ERROR
3434 034610 005261 000116  INC      D.CERR(R1)       ; INCREMENT COMPARE ERROR COUNT
3435 034614 005261 000112  INC      D.HERR(R1)       ; INCREMENT HARD ERROR COUNT
3435 034620          ERRHRD  41,,ERR041    ; REPORT ERROR STATUS
3435 034620          TRAP     C$ERHRD
3435 034622          .WORD   41
3435 034624          .WORD   0
3435 034626          .WORD   ERR041
3436 034630 005737 002144  TST      SO.EL+SFPTBL     ; IF HARD ERROR LIMIT ZERO,
3437 034634 001406          BEQ      98$              ; DON'T DROP DRIVE
3438 034636 026137 000112 002144  CMP      D.HERR(R1),SO.EL+SFPTBL ; EXCEEDED
3439 034644 103402          BLO      98$              ; HARD ERROR LIMIT?
3440 034646 004737 027424  CALL     DRPUNT           ; DROP DRIVE
3441 034652 004737 026006 98$:    CALL     RTNME           ; RETURN M.E. & CLEAR RESPONSE RING
3442 034656 000261          SEC                      ; INDICATE ERROR STATUS
3443 034660 000240          NOP                      ; [DBG] INSERT HALT FOR DEBUG
3444 034662 000207          RETURN
3445
3446 034664 103 117 115 MSCMPO: .ASCIZ /COMPARE ERROR/
3447 .EVEN
3448
3449 ;++
3450 ; STADAT - "DATA ERROR" STATUS RETURNED
3451 ;--
3452
3453 STADAT: POP      <R2>          ; RESTORE REGISTERS
3453 034702 012602          MOV      (SP)+,R2          ; POP STACK INTO R2
3454 034704 042702 000037  BIC      #ST.MSK,R2       ; GET SUBCODE
3455 034710 005000          CLR      R0               ; INITIALIZE INDEX
3456 034712 026002 035126 4$:    CMP      NUMDAT(R0),R2    ; IS THIS THE SUBCODE?
3457 034716 001411          BEQ      5$               ;
3458 034720 062700 000002  ADD      #2,R0            ; GET NEXT SUBCODE
3459 034724 022700 000030  CMP      #SIZDAT,R0       ; ANY SUBCODES LEFT?
3460 034730 002370          BGE      4$               ;
3461 034732 012737 010221 002320  MOV      #BLANK,STAMS1    ; SUBCODE NOT IN LIST
3462 034740 000403          BR      6$               ;
3463 034742 016037 035160 002320 5$:    MOV      ADDRAT(R0),STAMS1 ; GET ADDRESS OF MESSAGE STRING
3464 034750 022702 000400 6$:    CMP      #SC.1EC,R2       ; DON'T
3465 034754 003403          BLE      14$            ; COUNT ECC
3466 034756 022702 000200  CMP      #SC.CEC,R2       ; CORRECTABLE DATA
3467 034762 001026          BNE      20$            ; AS A DATA ERROR
3468 034764 005261 000120 14$:    INC      D.ECCC(R1)       ; COUNT ECC CORRECTED DATA
3469 034770 012737 035230 002316  MOV      #MSDATZ,STAMSO   ;
3470 034776 032737 020000 002204  BIT      #IERL,IFLAGS     ; IF ERROR LOG,
3471 035004 001045          BNE      99$              ; DON'T PRINT ERROR
3472 035006 005261 000114  INC      D.SERR(R1)       ; INCREMENT SOFT ERROR COUNT
3473 035012 032737 000002 002154  BIT      #SM.PSE,SO.BIT+SFPTBL ; PRINT SOFT
3474 035020 001404          BEQ      15$              ; ERRORS?
3475 035022          ERRSOFT 41,,ERR041    ; REPORT ERROR STATUS
3475 035022          TRAP     C$ERSOFT
3475 035024          .WORD   41
    
```

```

035026 000000 .WORD 0
035030 021240 .WORD ERR041
3476 035032 000241 15$: CLC ; NO ERROR OCCURRED
3477 035034 000240 NOP ; [DBG] INSERT HALT FOR DEBUG
3478 035036 000207 RETURN ;
3479
3480 035040 012737 035212 002316 20$: MOV #MSDAT0,STAMSO ;
3481 035046 032737 020000 002204 BIT #IERL,IFLAGS ; IF ERROR LOG
3482 035054 001021 BNE 99$ ; DON'T PRINT ERROR
3483 035056 005261 000112 INC D.HERR(R1) ; INCREMENT HARD ERROR COUNT
3484 035062 ERRHRD 41,ERR041 ; REPORT ERROR STATUS
035062 104456 TRAP C$ERHRD
035064 000051 .WORD 41
035066 000000 .WORD 0
035070 021240 .WORD ERR041
3485 035072 005737 002144 TST SO.EL+SFPTBL ; IF HARD ERROR LIMIT ZERO,
3486 035076 001406 BEQ 98$ ; DON'T DROP DRIVE
3487 035100 026137 000112 002144 CMP D.HERR(R1),SO.EL+SFPTBL ; EXCEEDED
3488 035106 103402 BLO 98$ ; HARD ERROR LIMIT?
3489 035110 004737 027424 CALL DRPUNT ; DROP DRIVE
3490 035114 004737 026006 98$: CALL RTNME ; RETURN M.E. & CLEAR RESPONSE RING
3491 035120 000261 99$: SEC ; INDICATE ERROR STATUS
3492 035122 000240 NOP ; [DBG] INSERT HALT FOR DEBUG
3493 035124 000207 RETURN ;
3494
3495 035126 000000 NUMDAT: .WORD SC.FOR ; FORCED ERROR
3496 035130 000100 .WORD SC.HDR ; INVALID HEADER
3497 035132 000140 .WORD SC.DSY ; DATA SYNC NOT FOUND
3498 035134 000200 .WORD SC.CEC ; CORRECTABLE ECC ERROR
3499 035136 000340 .WORD SC.UEC ; UNCORRECTABLE ECC ERROR
3500 035140 000400 .WORD SC.1EC ; 1 SYMBOL ECC ERROR
3501 035142 000440 .WORD SC.2EC ; 2 SYMBOL ECC ERROR
3502 035144 000500 .WORD SC.3EC ; 3 SYMBOL ECC ERROR
3503 035146 000540 .WORD SC.4EC ; 4 SYMBOL ECC ERROR
3504 035150 000600 .WORD SC.5EC ; 5 SYMBOL ECC ERROR
3505 035152 000640 .WORD SC.6EC ; 6 SYMBOL ECC ERROR
3506 035154 000700 .WORD SC.7EC ; 7 SYMBOL ECC ERROR
3507 035156 000740 .WORD SC.8EC ; 8 SYMBOL ECC ERROR
3508
3509 000030 SIZDAT = <.-NUMDAT-2> ; LEGAL NUMBERS ARE LOWER THAN THIS
3510
3511 035160 035612 ADRDAT: .WORD MSDAT0 ; FORCED ERROR
3512 035162 035260 .WORD MSDAT1 ; INVALID HEADER
3513 035164 035277 .WORD MSDAT2 ; DATA SYNC NOT FOUND
3514 035166 010221 .WORD BLANK ; CORRECTABLE ECC ERROR
3515 035170 035323 .WORD MSDAT4 ; UNCORRECTABLE ECC ERROR
3516 035172 035353 .WORD MSDAT5 ; 1 SYMBOL ECC ERROR
3517 035174 035376 .WORD MSDAT6 ; 2 SYMBOL ECC ERROR
3518 035176 035422 .WORD MSDAT7 ; 3 SYMBOL ECC ERROR
3519 035200 035446 .WORD MSDAT8 ; 4 SYMBOL ECC ERROR
3520 035202 035472 .WORD MSDAT9 ; 5 SYMBOL ECC ERROR
3521 035204 035516 .WORD MSDATA ; 6 SYMBOL ECC ERROR
3522 035206 035542 .WORD MSDATB ; 7 SYMBOL ECC ERROR
3523 035210 035566 .WORD MSDATC ; 8 SYMBOL ECC ERROR
3524
    
```

```

3525 035212      104      101      124  MSDATO: .ASCIZ  /DATA ERROR - /
3526 035230      105      103      103  MSDATZ: .ASCIZ  /ECC CORRECTABLE DATA - /
3527 035260      111      116      126  MSDAT1: .ASCIZ  /INVALID HEADER/
3528 035277      104      101      124  MSDAT2: .ASCIZ  /DATA SYNC NOT FOUND/
3529 035323      125      116      103  MSDAT4: .ASCIZ  /UNCORRECTABLE ECC ERROR/
3530 035353      061      040      123  MSDAT5: .ASCIZ  /1 SYMBOL CORRECTED/
3531 035376      062      040      123  MSDAT6: .ASCIZ  /2 SYMBOLS CORRECTED/
3532 035422      063      040      123  MSDAT7: .ASCIZ  /3 SYMBOLS CORRECTED/
3533 035446      064      040      123  MSDAT8: .ASCIZ  /4 SYMBOLS CORRECTED/
3534 035472      065      040      123  MSDAT9: .ASCIZ  /5 SYMBOLS CORRECTED/
3535 035516      066      040      123  MSDATA: .ASCIZ  /6 SYMBOLS CORRECTED/
3536 035542      067      040      123  MSDATB: .ASCIZ  /7 SYMBOLS CORRECTED/
3537 035566      070      040      123  MSDATC: .ASCIZ  /8 SYMBOLS CORRECTED/
3538 035612      106      117      122  MSDATD: .ASCIZ  /FORCED ERROR/
3539
3540
3541
3542          ;++
3543          ;      STAHS - "HOST BUFFER ACCESS ERROR" STATUS RETURNED
3544          ;--
3545          STAHS: POP      <R2>          ; RESTORE REGISTERS
                 MOV      (SP)+,R2      ; POP STACK INTO R2
                 BIC      #ST.MSK,R2    ; GET SUBCODE
                 CMP      #SC.OTA,R2    ; ODD TRANSFER ADDRESS?
                 BNE      1$
                 MOV      #MSHS1,STAMS1 ;
                 BR       20$
3546 035630      012602  000037          1$:  CMP      #SC.OBC,R2    ; ODD BYTE COUNT?
3547 035632      042702  000040          2$:  BNE      2$
3548 035636      022702  000040          3$:  MOV      #MSHS2,STAMS1 ;
3549 035642      001004          4$:  BR       20$
3550 035644      012737  036046  002320          5$:  CMP      #SC.NXM,R2    ; NON-EXISTANT MEMORY?
3551 035652      000437          6$:  BNE      3$
3552 035654      022702  000100          7$:  MOV      #MSHS3,STAMS1 ;
3553 035660      001004          8$:  BR       20$
3554 035662      012737  036073  002320          9$:  CMP      #SC.HMP,R2    ; HOST MEMORY PARITY ERROR?
3555 035670      000430          0$:  BNE      4$
3556 035672      022702  000140          1$:  MOV      #MSHS4,STAMS1 ;
3557 035676      001004          2$:  BR       20$
3558 035700      012737  036112  002320          3$:  CMP      #SC.IPT,R2    ; INVALID PAGE TABLE ENTRY?
3559 035706      000421          4$:  BNE      5$
3560 035710      022702  000200          5$:  MOV      #MSHS5,STAMS1 ;
3561 035714      001004          6$:  BR       20$
3562 035716      012737  036136  002320          7$:  CMP      #BLANK,STAMS1 ; SUBCODE NOT IN LIST
3563 035722      000412          8$:  MOV      #MSHS0,STAMS0 ;
3564 035726      022702  000240          9$:  BIT      #IERL,IFLAGS  ; IF ERROR LOG
3565 035732      001004          0$:  BNE      99$          ; DON'T PRINT ERROR
3566 035734      012737  036167  002320          1$:  ERDF    40,ERR040     ; REPORT ERROR STATUS
3567 035742      000403          2$:  TRAP   C+ERDF
3568 035744      012737  010221  002320          3$:  .WORD  40
3569 035752      012737  036012  002316          4$:  .WORD  0
3570 035760      032737  020000  002204          5$:  .WORD  0
3571 035766      001006          6$:  .WORD  ERR040
3572 035770      035770  104455          7$:  CALL   DRPCNT        ; DROP CONTROLLER FROM TEST
3573 035772      000050          8$:  SEC
3574 035774      000000          9$:  SEC
3575 035776      021016          0$:  SEC
3576 036000      004737  027350          1$:  SEC
3577 036004      000261          2$:  SEC
3578 036006      000240          3$:  NOP
    
```

; [DBG] INSERT HALT FOR DEBUG

```

3575 036010 000207          RETURN          ;
3576
3577 036012      110      117      123  MSHST0: .ASCIZ  /HOST BUFFER ACCESS ERROR - /
3578 036046      117      104      104  MSHST1: .ASCIZ  /ODD TRANSFER ADDRESS/
3579 036073      117      104      104  MSHST2: .ASCIZ  /ODD BYTE COUNT/
3580 036112      116      117      116  MSHST3: .ASCIZ  /NON-EXISTANT MEMORY/
3581 036136      110      117      123  MSHST4: .ASCIZ  /HOST MEMORY PARITY ERROR/
3582 036167      111      116      126  MSHST5: .ASCIZ  /INVALID PAGE TABLE ENTRY/
3583          .EVEN
3584
3585          ;++
3586          ; STACNT - "CONTROLLER ERROR" STATUS RETURNED
3587          ;--
3588
3589 036220          STACNT: POP      <R2>          ; RESTORE REGISTERS
          036220 012602      MOV      (SP),R2          ; POP STACK INTO R2
3590 036222 042702 000037      BIC      #ST.MSK,R2          ; GET SUBCODE
3591 036226 005000          CLR      R0          ; INITIALIZE INDEX
3592 036230 026002 036326      1$:  CMP      NUMCNT(R0),R2          ; IS THIS THE SUBCODE?
3593 036234 001411          BEQ      10$          ;
3594 036236 062700 000002      ADD      #2,R0          ; GET NEXT SUBCODE
3595 036242 022700 000020      CMP      #SIZCNT,R0          ; ANY SUBCODES LEFT?
3596 036246 002370          BGE      1$          ;
3597 036250 012737 010221 002320      MOV      #BLANK,STAMS1          ; SUBCODE NOT IN LIST
3598 036256 000403          BR      11$          ;
3599 036260 016037 036350 002320 10$:  MOV      ADRCNT(R0),STAMS1          ; GET ADDRESS OF MESSAGE STRING
3600 036266 012737 036372 002316 11$:  MOV      #MSCNT0,STAMSO          ;
3601 036274 032737 020000 002204      BIT      #IERL,IFLAGS          ; IF ERROR LOG
3602 036302 001006          BNE      99$          ; DON'T PRINT ERROR
3603 036304          ERDF  40,ERR040          ; REPORT ERROR STATUS
          036304 104455      TRAP   C$ERDF
          036306 000050          .WORD  40
          036310 000000          .WORD  0
          036312 021016          .WORD  ERR040
3604 036314 004737 027350      98$:  CALL   DRPCNT          ; DROP CONTROLLER FROM TEST
3605 036320 000261          99$:  SEC          ; INDICATE ERROR STATUS
3606 036322 000240          NOP          ; [DBG] INSERT HALT FOR DEBUG
3607 036324 000207          RETURN          ;
3608
3609 036326 000040          NUMCNT: .WORD  SC.SDS          ; SERDES OVERRUN OR UNDERRUN
3610 036330 000100          .WORD  SC.EDC          ; EDC ERROR
3611 036332 000140          .WORD  SC.IIC          ; INCONSISTANT INTERNAL CONTROL
3612 036334 000200          .WORD  SC.IEE          ; INTERNAL EDC ERROR
3613 036336 000240          .WORD  SC.LPI          ; LESI ADAPTOR CARD PARITY ERROR INPUT
3614 036340 000300          .WORD  SC.LPO          ; LESI ADAPTOR CARD PARITY ERROR,OUTPUT
3615 036342 000340          .WORD  SC.CIP          ; "CABLE IN PLACE" NOT ASSERTED
3616 036344 000400          .WORD  SC.COUI          ; CONTROLLER OVERRUN OR UNDERRUN
3617 036346 000440          .WORD  SC.CME          ; CONTROLLER MEMORY ERROR
3618
3619          000020          SIZCNT  =      <.-NUMCNT-2>          ; LEGAL NUMBERS ARE LOWER THAN THIS
3620
3621 036350 036416          ADRCNT: .WORD  MSCNT1          ; SERDES OVERRUN OR UNDERRUN
3622 036352 036451          .WORD  MSCNT2          ; EDC ERROR
3623 036354 036463          .WORD  MSCNT3          ; INCONSISTANT INTERNAL CONTRGL
3624 036356 036521          .WORD  MSCNT4          ; INTERNAL EDC ERROR
    
```

```

3625 036360 036544          .WORD  MSCNT5          ; LESI ADAPTOR CARD PARITY ERROR INPUT
3626 036362 036611          .WORD  MSCNT6          ; LESI ADAPTOR CARD PARITY ERROR,OUTPUT
3627 036364 036657          .WORD  MSCNT7          ; "CABLE IN PLACE" NOT ASSERTED
3628 036366 036715          .WORD  MSCNT8          ; CONTROLLER OVERRUN OR UNDERRUN
3629 036370 036754          .WORD  MSCNT9          ; CONTROLLER MEMORY ERROR
3630
3631 036372      103      117      116  MSCNT0: .ASCIZ  /CONTROLLER ERROR - /
3632 036416      123      105      122  MSCNT1: .ASCIZ  /SERDES OVERRUN OR UNDERRUN/
3633 036451      105      104      103  MSCNT2: .ASCIZ  /EDC ERROR/
3634 036463      111      116      103  MSCNT3: .ASCIZ  /INCONSISTANT INTERNAL CONTROL/
3635 036521      111      116      124  MSCNT4: .ASCIZ  /INTERNAL EDC ERROR/
3636 036544      114      105      123  MSCNT5: .ASCIZ  /LESI ADAPTOR CARD PARITY ERROR INPUT/
3637 036611      114      105      123  MSCNT6: .ASCIZ  /LESI ADAPTOR CARD PARITY ERROR,OUTPUT/
3638 036657      042      103      101  MSCNT7: .ASCIZ  /"CABLE IN PLACE" NOT ASSERTED/
3639 036715      103      117      116  MSCNT8: .ASCIZ  /CONTROLLER OVERRUN OR UNDERRUN/
3640 036754      103      117      116  MSCNT9: .ASCIZ  /CONTROLLER MEMORY ERROR/
3641
3642
3643
3644          ;++
3645          ; STDRV - "DRIVE ERROR" STATUS RETURNED
3646          ;--
3647 037004          STDRV: POP      <R2>          ; RESTORE REGISTERS
          037004 012602      MOV      (SP),R2          ; POP STACK INTO R2
3648 037006 042702 000037      BIC      #ST.MSK,R2          ; GET SUBCODE
3649 037012 005000          CLR      R0          ; INITIALIZE INDEX
3650 037014 026002 037122      2#:    CMP      NUMDRV(R0),R2          ; IS THIS THE SUBCODE?
3651 037020 001411          BEQ      10#          ;
3652 037022 062700 000002      ADD      #2,R0          ; GET NEXT SUBCODE
3653 037026 022700 000026      CMP      #SIZDRV,R0          ; ANY SUBCODES LEFT?
3654 037032 002370          BGE      2#          ;
3655 037034 012737 010221 002320      MOV      #BLANK,STAMS1          ; SUBCODE NOT IN LIST
3656 037042 000403          BR       11#          ;
3657 037044 016037 037152 002320 10#:    MOV      ADDRVR(R0),STAMS1          ; GET ADDRESS OF MESSAGE STRING
3658 037052 012737 037202 002316 11#:    MOV      #MSDRVO,STAMS0          ;
3659 037060 032737 020000 002204      BIT      #IERL,IFLAGS          ; IF ERROR LOG
3660 037066 001012          BNE      99#          ; DON'T PRINT ERROR
3661 037070 005261 000112      INC      D.HERR(R1)          ; INCREMENT HARD ERROR COUNT
3662 037074          ERROF  41,ERR041          ; REPORT ERROR STATUS
          037074 104455      TRAP    C#EROF
          037076 000051          .WORD  41
          037100 000000          .WORD  0
          037102 021240          .WORD  ERR041
3663 037104 004737 027424      CALL    DRPUNT          ; DROP DRIVE
3664 037110 004737 026006      98#:   CALL    RTNME          ; RETURN H.E. & CLEAR RESPONSE RING
3665 037114 000261          99#:   SEC          ; INDICATE ERROR STATUS
3666 037116 000240      NOP          ; [DBG] INSERT HALT FOR DEBUG
3667 037120 000207          RETURN
3668
3669 037122 000040      NUMDRV: .WORD  SC.CTO          ; DRIVE COMMAND TIME OUT
3670 037124 000100          .WORD  SC.XME          ; CONTROLLER DETECTED XMISSION ERROR
3671 037126 000140          .WORD  SC.POE          ; POSITIONER ERROR
3672 037130 000200          .WORD  SC.LRW          ; LOST RESD/WRITE READY
3673 037132 000240          .WORD  SC.DCD          ; DRIVE CLOCK DROPOUT
3674 037134 000300          .WORD  SC.LRR          ; LOST RECEIVER READY
    
```



```

3675 037136 000340          .WORD  SC.DDE          ; DRIVE DETECTED ERROR
3676 037140 000400          .WORD  SC.PSE          ; PULSE OR STATE PARITY ERROR
3677 037142 000500          .WORD  SC.PRO          ; CONTROLLER DETECTED PROTOCOL ERROR
3678 037144 000550          .WORD  SC.DFI          ; DRIVE FAILED INITIALIZATION
3679 037146 000600          .WORD  SC.DII          ; DRIVE IGNORED INITIALIZATION
3680 037150 000640          .WORD  SC.RRC          ; RECEIVER READY COLLISION
3681
3682          000026          SIZDRV =          <.-NUMDRV-2>          ; LEGAL NUMBERS ARE LOWER THAN THIS
3683
3684 037152 037221          ADRDRV: .WORD  MSDRV1          ; DRIVE COMMAND TIME OUT
3685 037154 037250          .WORD  MSDRV2          ; CONTROLLER DETECTED XMISSION ERROR
3686 037156 037317          .WORD  MSDRV3          ; POSITIONER ERROR
3687 037160 037340          .WORD  MSDRV4          ; LOST RESD/WRITE READY
3688 037162 037366          .WORD  MSDRV5          ; DRIVE CLOCK DROPOUT
3689 037164 037412          .WORD  MSDRV6          ; LOST RECEIVER READY
3690 037166 037436          .WORD  MSDRV7          ; DRIVE DETECTED ERROR
3691 037170 037463          .WORD  MSDRV8          ; PULSE OR STATE PARITY ERROR
3692 037172 037517          .WORD  MSDRV9          ; CONTROLLER DETECTED PROTOCOL ERROR
3693 037174 037562          .WORD  MSDRVA          ; DRIVE FAILED INITIALIZATION
3694 037176 037616          .WORD  MSDRVB          ; DRIVE IGNORED INITIALIZATION
3695 037200 037653          .WORD  MSDRVC          ; RECEIVER READY COLLISION
3696
3697 037202          104          122          111  MSDRV0: .ASCIZ  /DRIVE ERROR - /
3698 037221          104          122          111  MSDRV1: .ASCIZ  /DRIVE COMMAND TIME OUT/
3699 037250          103          117          116  MSDRV2: .ASCIZ  /CONTROLLER DETECTED TRANSMISSION ERROR/
3700 037317          120          117          123  MSDRV3: .ASCIZ  /POSITIONER ERROR/
3701 037340          114          117          123  MSDRV4: .ASCIZ  \LOST READ/WRITE READY\
3702 037366          104          122          111  MSDRV5: .ASCIZ  /DRIVE CLOCK DROPOUT/
3703 037412          114          117          123  MSDRV6: .ASCIZ  /LOST RECEIVER READY/
3704 037436          104          122          111  MSDRV7: .ASCIZ  /DRIVE DETECTED ERROR/
3705 037463          120          125          114  MSDRV8: .ASCIZ  /PULSE OR STATE PARITY ERROR/
3706 037517          103          117          116  MSDRV9: .ASCIZ  /CONTROLLER DETECTED PROTOCOL ERROR/
3707 037562          104          122          111  MSDRVA: .ASCIZ  /DRIVE FAILED INITIALIZATION/
3708 037616          104          122          111  MSDRVB: .ASCIZ  /DRIVE IGNORED INITIALIZATION/
3709 037653          122          105          103  MSDRVC: .ASCIZ  /RECEIVER READY COLLISION/
3710          .EVEN
    
```

3712
 3713
 3714
 3715
 3716
 3717
 3718
 3719
 3720
 3721
 3722
 3723
 3724
 3725
 3726
 3727 037704
 3729 037704 012700 023005
 3730 037710 004737 024132
 3732 037714 022703 000100
 3733 037720 001410
 3734 037722 022703 000101
 3735 037726 001425
 3736 037730 022703 000102
 3737 037734 001436
 3738 037736 000137 027744
 3739
 3740
 3741
 3742
 3743
 3744
 3745
 3746
 3747 037742 004737 047164
 3748 037746 103413
 3749 037750 032761 001000 000002
 3750 037756 001407
 3751 037760
 037760 104455
 037762 000074
 037764 000000
 037766 022472
 3752 037770 004737 027424
 3753 037774 000207
 3754 037776
 3755 037776 000240
 3756 040000 000207
 3757
 3758
 3759
 3760
 3761
 3762
 3763
 3764

```

:++
:
: RSPATN - RESPOND TO ATTENTION MESSAGE.
: INPUTS:
:   R1 - DRIVE UNIT NUMBER
:   R2 - STATUS/EVENT CODE
:   R3 - ENDCODE
:   R4 - POINTER TO RESPONSE PACKET
:   R5 - CONTROLLER TABLE ADDRESS
:
: OUTPUTS:
:   RESPONSE PACKET CLEARED, REPOSE RING OWNED BY CONTROLLER,
:   CONTENTS OF REGISTERS R1,R2,R3,R4 UNDEFINED
:   R5 UNCHANGED
:--

RSPATN:
MOV     #DBGATN,R0
CALL   DBGRSP           ; [DEBUG] PRINT RECEIVED MSG TYPE
CMP    #100,R3         ; [DEBUG] & BUFFER CONTENTS
BEQ    ATNAVA          ; 100 - AVAILABLE ATTENTION MESSAGE
CMP    #101,R3         ;
BEQ    ATNDUP          ; 101 - DUPLICATE UNIT NUMBER
CMP    #102,R3         ;
BEQ    ATNACC          ; 102 - ACCESS PATH ATTENTION MESSAGE
JMP    INVCHD         ; INVALID END MESSAGE RECEIVED

:++
:
: ATNAVA - "AVAILABLE" ATTENTION MESSAGE RECEIVED.
:
: IF UNIT SPECIFIED IN THE ATTENTION MESSAGE IS TO BE TESTED,
:   PRINT A DEVICE FATAL ERROR AND DROP UNIT FROM TEST
: ELSE, IGNORE THE ATTENTION MESSAGE
:--

ATNAVA: CALL   GDRVT           ; GET DRIVE TABLE
BCS    300             ; IF TABLE NOT FOUND, IGNORE MESSAGE
BIT    @OT.ONL.,D.UNIT(R1) ; IF DRIVE SHOULDN'T BE ONLINE,
BEQ    300             ; IGNORE MESSAGE
ERRDF  60,ERR060      ; DRIVE UNDER TEST WENT AVAILABLE ERROR
TRAP   C+ENDF
.WORD  60
.WORD  0
.WORD  ERR060
CALL   DRPUNT           ; DROP UNIT FROM TEST
RETURN

300:
NOP           ; [DBG] INSERT HALT FOR DEBUG
RETURN

:++
:
: ATNDUP - "DUPLICATE UNIT NUMBER" ATTENTION MESSAGE RECEIVED
:
: IF UNIT SPECIFIED IN THE ATTENTION MESSAGE IS TO BE TESTED,
:   PRINT A DEVICE FATAL ERROR AND DROP UNIT FROM TEST
: ELSE, IGNORE THE ATTENTION MESSAGE
:--
    
```

```
3765
3766 040002 004737 047164      ATNUP: CALL  GTRVT      : GET DRIVE TABLE
3767 040006 103407              BCS      30$      : IF TABLE NOT FOUND, IGNORE MESSAGE
3768 040010 104455      ERRDF  61, ERR061 : DRIVE UNDER TEST DUPLICATE UNIT *
      040010 104455      TRAP   C$ERRDF
      040012 000075      .WORD  61
      040014 000000      .WORD  0
      040016 022544      .WORD  ERR061
3769 040020 004737 027424      CALL  DRPUNT      : DROP CONTROLLER FROM TEST
3770 040024 000207              RETURN
3771 040026 30$:
3772 040026 000240      NOP              : [DBG] INSERT HALT FOR DEBUG
3773 040030 000207      RETURN
3774
3775      ;**
3776      ; ATNACC - "ACCESS PATH" ATTENTION MESSAGE RECEIVED
3777      ;
3778      ; THIS ATTENTION MESSAGE IS ALWAYS IGNORED
3779      ;--
3780
3781 040032 000240      ATNACC:
3782 040032 000240      NOP              : [DBG] INSERT HALT FOR DEBUG
3783 040034 000207      RETURN
3784
```

```

3786
3787
3788
3789
3790
3791
3792
3793
3794
3795
3796
3797
3798
3799
3800
3801
3802 040036 116404 000017
3803 040042 042704 177400
3804 040046 005703
3805 040050 001420
3806 040052 022703 000001
3807 040056 001457
3808 040060 022703 000002
3809 040064 001516
3810 040066 022703 000003
3811 040072 001565
3812 040074 022703 000004
3813 040100 001002
3814 040102 000137 040572
3815 040106 000137 027744
3816
3817
3818
3819
3820
3821
3822 040112 052737 020000 002204
3823 040120 005001
3824 040122 004737 032332
3825 040126 042737 020000 002204
3826 040134 032704 000300
3827 040140 001004
3828 040142 012737 000002 002156
3829 040150 000407
3830 040152 032737 000002 002154 1#:
3831 040160 001414
3832 040162 012737 000003 002156
3833 040170 012737 000062 002160 2#:
3834 040176 005037 002162
3835 040202 012737 021654 002164
3836 040210 104460
3837 040212
3838 040212 000240
3839 040214 000207

; **
;
; RSPERL - RESPOND TO ERROR LOG MESSAGE.
;
; INPUTS:
; R1 - DRIVE UNIT NUMBER
; R2 - STATUS/EVENT CODE
; R3 - ENDCODE
; R4 - POINTER TO RESPONSE PACKET
; R5 - CONTROLLER TABLE ADDRESS
;
; OUTPUTS:
; RESPONSE PACKET CLEARED, REPOSE RING OWNED BY CONTROLLER,
; CONTENTS OF REGISTERS R1,R2,R3,R4 UNDEFINED
; R5 UNCHANGED
; --

RSPERL: MOVB P.FLGS+RE.RP(R4),R4 ; GET END
        BIC #177400,R4 ; MESSAGE FLAGS
        TST R3 ;
        BEQ ERRCNT ; 000 - CONTROLLER ERROR
        CMP #1,R3 ;
        BEQ ERRHMA ; 001 - HOST MEMORY ACCESS ERROR
        CMP #2,R3 ;
        BEQ ERRDTE ; 002 - DISK TRANSFER ERROR
        CMP #3,R3 ;
        BEQ ERRSDI ; 003 - SDI ERROR
        CMP #4,R3 ;
        BNE 2# ;
        JMP ERRSDE ; 004 - SMALL DISK ERROR
        JMP INVCMD ; INVALID END MESSAGE RECEIVED

; **
;
; ERRCNT - "CONTROLLER" ERROR ERROR LOG MESSAGE RECEIVED
;
; --

ERRCNT: BIS #IERL,IFLAGS ; INDICATE THIS IS AN ERROR LOG
        CLR R1 ; TABLE POINTER SANITY CHECK ON CHKSTA
        CALL CHKSTA ; CHECK RETURN STATUS
        BIC #IERL,IFLAGS ; CLEAR ERROR LOG FLAG
        BIT #<LF.CON+LF.SUC>,R4 ; IF OPERATION
        BNE 1# ; FAILED,
        MOV #2,ERRTYP ; PRINT HARD ERROR
        BR 2# ; ELSE,
        BIT #SM.PSE,SO.BIT+SFPTBL ; IF SOFT ERRORS ARE SUPPRESSED,
        BEQ 4# ; SKIP ERROR REPORT.
        MOV #3,ERRTYP ; ELSE, PRINT SOFT ERROR
        MOV #50,ERRNBR ; SAVE ERROR NUMBER
        CLR ERRMSG ; CLEAR ERROR MESSAGE ADDRESS
        MOV #ERRO50,ERRBLK ; SAVE ERROR SUBROUTINE ADDRESS
        ERROR ; PRINT MESSAGE
        TRAP C#ERROR

;
;
; [DBG] INSERT HALT FOR DEBUG
;
RETURN
```

```

3840
3841
3842      ;++
3843      ;
3844      ;
3845      ;--
3846 040216 052737 020000 002204 ERRHMA: BIS      #IERL,IFLAGS      ; INDICATE THIS IS AN ERROR LOG
3847 040224 005001          CLR      R1          ; TABLE POINTER SANITY CHECK ON CHKSTA
3848 040226 004737 032332          CALL     CHKSTA      ; CHECK RETURN STATUS
3849 040232 042737 020000 002204 BIC      #IERL,IFLAGS      ; CLEAR ERROR LOG FLAG
3850 040240 032704 000300          BIT      #<LF.CON+LF.SUC>,R4 ; IF OPERATION
3851 040244 001004          BNE      1$          ; FAILED,
3852 040246 012737 000002 002156 MOV      #2,ERRTYP      ; PRINT HARD ERROR
3853 040254 000407          BR       2$          ; ELSE,
3854 040256 032737 000002 002154 1$: BIT      #SM.PSE,SO.BIT+SFPTBL ; IF SOFT ERRORS ARE SUPPRESSED,
3855 040264 001414          BEQ      4$          ; SKIP ERROR REPORT.
3856 040266 012737 000003 002156 MOV      #3,ERRTYP      ; ELSE, PRINT SOFT ERROR
3857 040274 012737 000063 002160 2$: MOV      #51,ERRNBR      ; SAVE ERROR NUMBER
3858 040302 005037 002162          CLR      ERRMSG      ; CLEAR ERROR MESSAGE ADDRESS
3859 040306 012737 021706 002164 MOV      #ERRO51,ERRBLK ; SAVE ERROR SUBROUTINE ADDRESS
3860 040314          ERROR          ; PRINT MESSAGE
      040314 104460          TRAP     C$ERROR
3861 040316          4$:
3862 040316 C00240          NOP
3863 040320 000207          RETURN      ; [DBG] INSERT HALT FOR DEBUG
3864
3865      ;++
3866      ;
3867      ;
3868      ;--
3869
3870 040322 004737 047164          ERRDTE: CALL     GTDRV      ; ELSE, GET DRIVE TABLE
3871 040326 103445          BCS      4$          ; IF TABLE NOT FOUND, PRINT ERROR
3872 040330 032761 100000 000002 BIT      #DT.AVL,D.UNIT(R1) ; IF DRIVE DROPPED,
3873 040336 001041          BNE      4$          ; IGNORE RESPONSE PACKET
3874 040340 052737 020000 002204 BIS      #IERL,IFLAGS      ; INDICATE THIS IS AN ERROR LOG
3875 040346 004737 032332          CALL     CHKSTA      ; CHECK RETURN STATUS
3876 040352 042737 020000 002204 BIC      #IERL,IFLAGS      ; CLEAR ERROR LOG FLAG
3877 040360 032704 000300          BIT      #<LF.CON+LF.SUC>,R4 ; IF OPERATION
3878 040364 001004          BNE      2$          ; FAILED,
3879 040366 012737 000002 002156 MOV      #2,ERRTYP      ; PRINT HARD ERROR
3880 040374 000411          BR       3$          ; ELSE,
3881 040376 005261 000114          INC      D.SERR(R1)    ; INCREMENT SOFT ERROR COUNT
3882 040402 032737 000002 002154 2$: BIT      #SM.PSE,SO.BIT+SFPTBL ; IF SOFT ERRORS ARE SUPPRESSED,
3883 040410 001414          BEQ      4$          ; SKIP ERROR REPORT.
3884 040412 012737 000003 002156 MOV      #3,ERRTYP      ; ELSE, PRINT SOFT ERROR
3885 040420 012737 000064 002160 3$: MOV      #52,ERRNBR      ; SAVE ERROR NUMBER
3886 040426 005037 002162          CLR      ERRMSG      ; CLEAR ERROR MESSAGE ADDRESS
3887 040432 012737 022004 002164 MOV      #ERRO52,ERRBLK ; SAVE ERROR SUBROUTINE ADDRESS
3888 040440          ERROR          ; PRINT MESSAGE
      040440 104460          TRAP     C$ERROR
3889 040442          4$:
3890 040442 000240          NOP
3891 040444 000207          RETURN      ; [DBG] INSERT HALT FOR DEBUG
3892
    
```

```

3893
3894      ;++
3895      ;      ERRSDI - "SDI ERROR" ERROR LOG MESSAGE RECEIVED
3896      ;
3897      ;--
3898 040446 004737 047164      ERRSDI: CALL      GTDRV      ; ELSE, GET DRIVE TABLE
3899 040452 103445              BCS        4$      ; IF TABLE NOT FOUND, PRINT ERROR
3900 040454 032761 100000 000002      BIT      #DT.AVL,D.UNIT(R1) ; IF DRIVE DROPPED,
3901 040462 001041              BNE        4$      ; IGNORE RESPONSE PACKET
3902 040464 052737 020000 002204      BIS      #IERL,IFLAGS ; INDICATE THIS IS AN ERROR LOG
3903 040472 004737 032332      CALL     CHKSTA   ; CHECK RETURN STATUS
3904 040476 042737 020000 002204      BIC      #IERL,IFLAGS ; CLEAR ERROR LOG FLAG
3905 040504 032704 000300      BIT      #<LF.CON+LF.SUC>,R4 ; IF OPERATION
3906 040510 001004              BNE        2$      ; FAILED,
3907 040512 012737 000002 002156      MOV      #2,ERRTYP ; PRINT HARD ERROR
3908 040520 000411              BR        3$      ; ELSE,
3909 040522 005261 000114      2$: INC      D.SERR(R1) ; INCREMENT SOFT ERROR COUNT
3910 040526 032737 000002 002154      BIT      #SM.PSE,SO.BIT+SFPTBL ; IF SOFT ERRORS ARE SUPPRESSED,
3911 040534 001414              BEQ        4$      ; SKIP ERROR REPORT.
3912 040536 012737 000003 002156      MOV      #3,ERRTYP ; ELSE, PRINT SOFT ERROR
3913 040544 012737 000065 002160      3$: MOV      #53,ERRNBR ; SAVE ERROR NUMBER
3914 040552 005037 002162      CLR      ERRMSG   ; CLEAR ERROR MESSAGE ADDRESS
3915 040556 012737 022122 002164      MOV      #ERR053,ERRBLK ; SAVE ERROR SUBROUTINE ADDRESS
3916 040564 104460      ERROR   TRAP     C$ERROR ; PRINT MESSAGE
3917 040566      4$:
3918 040566 000240      NOP
3919 040570 000207      RETURN      ; [DBG] INSERT HALT FOR DEBUG
3920
3921      ;++
3922      ;      ERRSDE - "SMALL DESK ERROR" ERROR LOG MESSAGE RECEIVED
3923      ;
3924      ;--
3925
3926 040572 004737 047164      ERRSDE: CALL      GTDRV      ; ELSE, GET DRIVE TABLE
3927 040576 103445              BCS        4$      ; IF TABLE NOT FOUND, PRINT ERROR
3928 040600 032761 100000 000002      BIT      #DT.AVL,D.UNIT(R1) ; IF DRIVE DROPPED,
3929 040606 001041              BNE        4$      ; IGNORE RESPONSE PACKET
3930 040610 052737 020000 002204      BIS      #IERL,IFLAGS ; INDICATE THIS IS AN ERROR LOG
3931 040616 004737 032332      CALL     CHKSTA   ; CHECK RETURN STATUS
3932 040622 042737 020000 002204      BIC      #IERL,IFLAGS ; CLEAR ERROR LOG FLAG
3933 040630 032704 000300      BIT      #<LF.CON+LF.SUC>,R4 ; IF OPERATION
3934 040634 001004              BNE        2$      ; FAILED,
3935 040636 012737 000002 002156      MOV      #2,ERRTYP ; PRINT HARD ERROR
3936 040644 000411              BR        3$      ; ELSE,
3937 040646 005261 000114      2$: INC      D.SERR(R1) ; INCREMENT SOFT ERROR COUNT
3938 040652 032737 000002 002154      BIT      #SM.PSE,SO.BIT+SFPTBL ; IF SOFT ERRORS ARE SUPPRESSED,
3939 040660 001414              BEQ        4$      ; SKIP ERROR REPORT.
3940 040662 012737 000003 002156      MOV      #3,ERRTYP ; ELSE, PRINT SOFT ERROR
3941 040670 012737 000066 002160      3$: MOV      #54,ERRNBR ; SAVE ERROR NUMBER
3942 040676 005037 002162      CLR      ERRMSG   ; CLEAR ERROR MESSAGE ADDRESS
3943 040702 012737 022236 002164      MOV      #ERR054,ERRBLK ; SAVE ERROR SUBROUTINE ADDRESS
3944 040710 104460      ERROR   TRAP     C$ERROR ; PRINT MESSAGE
3945 040712      4$:
    
```

3946 040712 000240
3947 040714 000207
3948

NOP

RETURN

; [DBG] INSERT HALT FOR DEBUG
;

```

3950
3951
3952      ;++
3953      ; TIPGEN - GENERATE TEST PACKETS FOR TEST 1 (CONTROLLER VERIFICATION
3954      ; TEST). THE FOLLOWING STEPS ARE PERFORMED:
3955      ; 1. INITIALIZE EACH CONTROLLER
3956      ; 2. FOR EACH OF THE 16 STANDARD DATA PATTERNS, WRITE ALL
3957      ; LOCATIONS IN CONTROLLER RAM, READ BACK THE DATA, AND DO
3958      ; A DATA COMPARE.
3959      ; 3. RE-INITIALIZE CONTROLLER
3960      ; 4. ISSUE A SET CONTROLLER CHARACTERISTICS COMMAND
3961      ;--
3962 040716 040764      T1DSP: .WORD T1S0      ; STEP 0 ROUTINE
3963 040720 041052      .WORD T1S1      ; STEP 1 ROUTINE
3964 040722 041170      .WORD T1W1      ; WAIT 1
3965 040724 041212      .WORD T1S2      ; STEP 2 ROUTINE
3966 040726 041300      .WORD T1S3      ; STEP 3 ROUTINE
3967 040730 041416      .WORD T1W2      ; WAIT 2
3968 040732 041500      .WORD T1S4      ; STEP 4 ROUTINE
3969
3970 040734 016500 000030      T1PGEN: MOV C.STEP(R5),R0      ; DISPATCH
3971 040740 022700 000006      CMP #6,R0      ; TO
3972 040744 103403      BLO 3$      ; CURRENT
3973 040746 006300      ASL R0      ; STEP
3974 040750 000170 040716      JMP @T1DSP(R0)      ; ROUTINE
3975 040754 012701 040752      3$: MOV # -2,R1      ; SAVE CURRENT LOCATION
3976 040760 000137 024310      JMP BADMEM      ; PRINT SYSTEM FATAL ERROR
3977
3978      ; STEP 0 - INITIALIZE THE CONTROLLER
3979
3980 040764 004737 052220      T1S0: CALL CNTINT      ; INITIALIZE CONTROLLER
3981 040770 103475      BCS T1LOE      ; IF ERROR, EXIT
3982 040772 005765 000034      TST C.MSIZ(R5)      ; IF RAM SIZE = 0,
3983 040776 001005      BNE 2$      ;
3984 041000 012765 000006 000030      MOV #6,C.STEP(R5)      ; DO STEP
3985 041006 000137 041500      JMP T1S4      ; 4 ONLY
3986 041012 052765 000400 000014      2$: BIS #CT.MRW,C.FLG(R5)      ; SET MAINTENANCE OPERATION BIT
3987 041020 012765 000001 000152      MOV #1,C.CRED(R5)      ; CREDITS SET TO 1 FOR MAINT MODE
3988 041026 012765 000041 000040      MOV #33,C.TPAT(R5)      ; INIT TEST PATTERN
3989 041034 012765 000040 WJ0042      MOV #32,C.NEXT(R5)      ;
3990 041042 005265 000030      INC C.STEP(R5)      ; SET STEP COUNT
3991 041046 005065 000036      CLR C.ROFF(R5)      ; INIT REGION OFFSET
3992
3993      ; STEP 1 - WRITE DATA PATTERN TO CONTROLLER MEMORY
3994
3995 041052 012701 000001      T1S1: MOV #1,R1      ; GET 1 BLOCK
3996 041056 016503 000040      MOV C.TPAT(R5),R3      ; GET PATTERN NUMBER
3997 041062 004737 046474      CALL PATBLD      ; GET BUFFER CONTAINING DATA PATTERN
3998 041066 005701      TST R1      ; IF BUFFER SIZE = 0,
3999 041070 001435      BEQ T1LOE      ; EXIT TEST
4000 041072 016501 000036      MOV C.ROFF(R5),R1      ; GET REGION OFFSET
4001 041076 016503 000034      MOV C.MSIZ(R5),R3      ; CALCULATE
4002 041102 160103      SUB R1,R3      ; BYTES
4003 041104 006303      ASL R3      ; TO
4004 041106 023703 004406      CMP BCLO,R3      ; SEND
    
```



```

4005 041112 103402          BLO      11$
4006 041114 010337 004406 11$:   MOV      R3,BCLO          ; SET BYTE COUNT
4007 041120 005003          CLR      R3              ; CLEAR RESERVED
4008 041122 005004          CLR      R4              ; FIELDS
4009 041124 004737 051122  CALL     MNTWR           ; BUILD MAINTENANCE WRITE PACKET
4010 041130 103415          BCS      T1LOE          ; IF ERROR, EXIT
4011
4012 041132 006037 004406  ROR      BCLO           ; CONVERT TO WORDS
4013 041136 063701 004406  ADD      BCLO,R1         ; ADJUST
4014 041142 010165 000036  MOV      R1,C.ROFF(R5)   ; REGION OFFSET
4015 041146 020165 000034  CMP      R1,C.MSIZ(R5)   ; DONE WRITING?
4016 041152 103404          BLO      T1LOE
4017 041154 005265 000030  INC      C.STEP(R5)      ; NEXT STEP
4018 041160 005065 000036  CLR      C.ROFF(R5)     ; RESET REGION OFFSET
4019 041164
4020 041164 000240  T1LOE:  NOP
4021 041166 000207          RETURN          ; [DBG] INSERT HALT FOR DEBUG
4022
4023
4024
4025 041170 005765 000164  T1W1:  TST      C.TBSF(R5)   ; IF TBS LIST ISN'T EMPTY,
4026 041174 001003          BNE      1$            ; KEEP WAITING
4027 041176 005765 000160  TST      C.CMFL(R5)     ; IF CMD LIST IS EMPTY,
4028 041202 001401          BEQ      2$            ; START NEXT STEP
4029 041204 000207 1$:   RETURN
4030 041206 005265 000030 2$:   INC      C.STEP(R5)   ; START NEXT STEP
4031
4032
4033
4034 041212 012701 000001  T1S2:  MOV      #1,R1          ; GET INPUT
4035 041216 004737 024354  CALL     GETBUF         ; BUFFER
4036 041222 005701          TST      R1             ; IF ZERO,
4037 041224 001523          BEQ      T1L1E         ; WAIT FOR FREE BUFFER
4038 041226 016501 000036  MOV      C.ROFF(R5),R1  ; GET REGION OFFSET
4039 041232 016503 000034  MOV      C.MSIZ(R5),R3 ; CALCULATE
4040 041236 160103          SUB      R1,R3          ; BYTES
4041 041240 006303          ASL      R3             ; TO
4042 041242 023703 004406  CMP      BCLO,R3        ; SEND
4043 041246 103402          BLO      11$
4044 041250 010337 004406  MOV      R3,BCLO
4045 041254 005003 11$:   CLR      R3              ; SET BYTE COUNT
4046 041256 005004          CLR      R4              ; CLEAR RESERVED
4047 041260 004737 051112  CALL     MNTRD           ; FIELDS
4048 041264 103003          BCC      22$           ; BUILD MAINTENANCE READ PACKET
4049 041266 004737 025420  CALL     RETBUF         ; IF ERROR,
4050 041272 000500          BR       T1L1E         ; RETURN BUFFER AND
4051 041274 005265 000030 22$:   INC      C.STEP(R5)   ; EXIT
4052
4053
4054
4055 041300 012701 000001  T1S3:  MOV      #1,R1          ; NEXT STEP
4056 041304 016503 000042  MOV      C.NEXT(R5),R3  ; GET 1 BLOCK
4057 041310 004737 046474  CALL     PATBLD         ; GET PATTERN NUMBER
4058 041314 005701          TST      R1             ; GET BUFFER CONTAINING DATA PATTERN
4059 041316 001466          BEQ      T1L1E         ; IF BUFFER SIZE = 0,

```

```

4060 041320 016501 000036      MOV      C.ROFF(R5),R1      ; GET REGION OFFSET
4061 041324 016503 000034      MOV      C.MSIZ(R5),R3    ; CALCULATE
4062 041330 160103              SUB      R1,R3            ; BYTES
4063 041332 006303              ASL      R3                ; TO
4064 041334 023703 004406      CMP      BCLO,R3          ; SEND
4065 041340 103402              BLO     11$               ;
4066 041342 010337 004406      MOV      R3,BCLO         ; SET BYTE COUNT
4067 041346 005003              CLR      R3                ; CLEAR RESERVED
4068 041350 005004              CLR      R4                ; FIELDS
4069 041352 004737 051122      CALL    MNTWR            ; BUILD "MAINTENANCE WRITE" PACKET
4070 041356 103446              BCS     T1L1E            ; IF ERROR, EXIT
4071
4072 041360 012765 000003 000030      MOV      #3,C.STEP(R5)    ; NEXT STEP
4073 041366 006037 004406      ROR      BCLO            ; CONVERT TO WORDS
4074 041372 063701 004406      ADD      BCLO,R1         ; ADJUST
4075 041376 010165 000036      MOV      R1,C.ROFF(R5)   ; REGION OFFSET
4076 041402 020165 000034      CMP      R1,C.MSIZ(R5)   ; DONE WRITING?
4077 041406 103432              BLO     T1L1E            ;
4078 041410 012765 000005 000030      MOV      #5,C.STEP(R5)   ; SET NEXT STEP
4079
4080 ;
4081 ;
4082 041416 005765 000164      11W2:  TST      C.TBSF(R5)     ; IF TBS LIST ISN'T EMPTY,
4083 041422 001024              BNE     T1L1E            ; KEEP WAITING
4084 041424 005765 000160      TST      C.CMFL(R5)     ; IF CMD LIST ISN'T EMPTY,
4085 041430 001021              SNE     T1L1E            ; KEEP WAITING
4086 041432 012765 000003 000030      MOV      #3,C.STEP(R5)   ; SET NEXT STEP
4087 041440 005065 000036      CLR      C.ROFF(R5)     ; RESET REGION OFFSET
4088 041444 005365 000042      DEC      C.NEXT(R5)     ; SAVE LAST PATTERN WRITTEN
4089 041450 002003              BGE     21$               ;
4090 041452 012765 000041 000042      MOV      #3,C.NEXT(R5)   ;
4091 041460 005365 000040      21$:   DEC      C.TPAT(R5)   ;
4092 041464 002003              BGE     T1L1E            ; IF NOT NEGATIVE, EXIT LOOP
4093 041466 012765 000006 000030      MOV      #6,C.STEP(R5)   ; SET NEXT STEP
4094 041474
4095 041474 000240      T1L1E: NOP
4096 041476 000207      RETURN ; [DBG] INSERT HALT FOR DEBUG
4097 ;
4098 ;
4099 ;
4100 ;
4101 041500 005765 000164      11S4:  TST      C.TBSF(R5)     ; DON'T START UNTIL
4102 041504 001025              BNE     T1L2E            ; TBS LIST IS EMPTY
4103 041506 005765 000160      TST      C.CMFL(R5)     ; DON'T START UNTIL
4104 041512 001022              BNE     T1L2E            ; COMMAND LIST IS EMPTY
4105 041514 042765 000400 000014      BIC      #CT.MRW,C.FLG(R5) ; CLEAR MAINTENANCE OPERATION BIT
4106 041522 004737 052220      CALL    CNTINT          ; INITIALIZE CONTROLLER
4107 041526 103414              BCS     T1L2E            ; IF ERROR, EXIT
4108 041530 012701 000360      MOV      #<CF.ATN+CF.MSC+CF.OTH+CF.THS>,R1 ; SET CONTROLLER FLAGS
4109 041534 004737 050210      CALL    SCC             ; BUILD SCC COMMAND
4110 041540 103407              BCS     T1L2E            ; IF NO PACKETS, EXIT
4111 ;
4112 ;
4113 ;
4114 041542 052765 040000 000014      BIS      #CT.DUN,C.FLG(R5) ; SET TEST DONE FLAG
    
```

GLOBAL SUBROUTINES SECTION

```
4115 041550 005065 000030          CLR      C.STEP(R5)          ; RESET STEP COUNTER
4116 041554 005065 000042          CLR      C.NEXT(R5)         ; RESET NEXT UNIT COUNTER
4117 041560                                     T1L2E:
4118 041560 000240          NOP                                     ; [DBG] INSERT HALT FOR DEBUG
4119 041562 000207          RETURN                                ;
```

```

4121
4122
4123
4124
4125
4126
4127
4128
4129
4130
4131
4132
4133
4134
4135
4136
4137
4138
4139
4140 041564 041646
4141 041566 041666
4142 041570 041720
4143 041572 042026
4144 041574 042050
4145 041576 042122
4146 041600 042216
4147 041602 042264
4148 041604 042306
4149 041606 042416
4150 041610 042440
4151 041612 042570
4152 041614 042612
4153
4154 041616 016500 000030
4155 041622 022700 000014
4156 041626 002403
4157 041630 006300
4158 041632 000170 041564
4159 041636 012701 041634
4160 041642 000137 024310
4161
4162
4163
4164
4165 041646 004737 052220
4166 041652 103463
4167 041654 012701 000360
4168 041660 004737 050210
4169 041664 103456
4170
4171
4172
4173 041666 004737 045526
4174 041672 001446
4175 041674 032760 100000 000002

:++
T2PGEN - GENERATE TEST PACKETS FOR TEST 2 (SUBSYSTEM VERIFICATION
TEST). THE FOLLOWING STEPS ARE PERFORMED:
0. INIT CONTROLLER & "SET CONTROLLER CHARACTERISTICS"
1. ISSUE AN "ONLINE" COMMAND FOR EACH DRIVE
2. ISSUE A "SET UNIT CHARACTERISTICS" COMMAND FOR EACH DRIVE
   WRITE PROTECT ANY DRIVE THAT IS NOT TO BE WRITTEN
3. ISSUE A "READ" COMMAND WITH THE DATA COMPARE FLAG SET
4. ISSUE AN "ACCESS" COMMAND
5. ISSUE A "GET COMMAND STATUS" COMMAND
6. IF WRITABLE, WRITE 1 BLOCK WITH DATA COMPARE.
7. COMPARE THE BLOCK WRITTEN WITH THE PATTERN WRITTEN
8. COMPARE THE BLOCK WRITTEN WITH A DIFFERENT DATA PATTERN
9. SET DRIVES AVAILABLE WITH SPIN DOWN
10. ISSUE AND "ONLINE" COMMAND FOR EACH DRIVE
11. SET ALL DRIVES AVAILABLE
:--

T2DSP: .WORD T2S0 ; 1 STEP 0 ROUTINE
        .WORD T2S1 ; 2 STEP 1 ROUTINE
        .WORD T2S2 ; 3 STEP 2 ROUTINE
        .WORD T2W1 ; 4 WAIT 1
        .WORD T2S3 ; 5 STEP 3 ROUTINE
        .WORD T2S4 ; 6 STEP 4 ROUTINE
        .WORD T2S5 ; 7 STEP 5 ROUTINE
        .WORD T2W2 ; 8 WAIT 2
        .WORD T2S6 ; 9 STEP 6 ROUTINE
        .WORD T2W3 ; 10 WAIT 3
        .WORD T2S7 ; 11 STEP 7 ROUTINE
        .WORD T2W4 ; 12 WAIT 4
        .WORD T2S8 ; 13 STEP 8 ROUTINE

T2PGEN: MOV C,STEP(R5),R0 ; DISPATCH
        CMP #12.,R0 ; TO
        BLT 3$ ; CURRENT
        ASL R0 ; STEP
        JMP @T2DSP(R0) ; ROUTINE
3$: MOV #.-2,R1 ; SAVE CURRENT LOCATION
    JMP BADHEM ; PRINT SYSTEM FATAL ERROR

;
; STEP 0 - INITIALIZE THE CONTROLLER AND
; ISSUE A SET CONTROLLER CHARACTERISTICS COMMAND
;
T2S0: CALL CNTINT ; INITIALIZE CONTROLLER
      BCS T2L1E ; IF ERROR, EXIT
      MOV #<CF.ATN+CF.MSC+CF.OTH+CF.THS>,R1 ; SET CONTROLLER FLAGS
      CALL SCC ; BUILD SCC COMMAND
      BCS T2L1E ; IF NO PACKETS, EXIT

;
; STEP 1 - ISSUE AN "ONLINE" COMMAND FOR EACH DRIVE
;
T2S1: CALL GTNXTD ; GET POINTER TO DRIVE TABLE
      BEQ T2S2E ; IF ZERO, DONE
      BIT @DT.AVL,D.UNIT(R0) ; CHECK IF DRIVE AVAILABLE
    
```

```

4176 041702 001030      BNE      T2S2N      ; IF NOT, SKIP SUBTEST
4177 041704 005001      CLR      R1         ; SET UNIT FLAGS
4178 041706 004737 050150 CALL     ONLINE     ; BUILD ONLINE COMMAND
4179 041712 103443      BCS     T2L1E     ; IF NO PACKETS, EXIT
4180 041714 005265 000030 INC      C.STEP(R5) ; GO TO STEP 2
4181
4182      ;
4183      ; STEP 2 - ISSUE A "SET UNIT CHARACTERISTICS" COMMAND FOR EACH DRIVE
4184      ; WRITE PROTECT ANY DRIVE THAT IS NOT TO BE WRITTEN
4185 041720 004737 045526  T2S2:  CALL     GTNXTD     ; GET POINTER TO DRIVE TABLE
4186 041724 001431      BEQ     T2S2E     ; IF ZERO, DONE
4187 041726 032760 100000 000002 BIT     @DT.AVL,D.UNIT(R0) ; CHECK IF DRIVE AVAILABLE
4188 041734 001013      BNE     T2S2N     ; IF NOT, SKIP SUBTEST
4189 041736 032760 010000 000002 BIT     @DT.WRT,D.UNIT(R0) ; CHECK IF DRIVE WRITEABLE
4190 041744 001003      BNE     21$      ; IF NOT
4191 041746 012701 010000      MOV     @UF.WPS,R1   ; SET SOFTWARE WRITE PROTECT
4192 041752 000401      BR      22$
4193 041754 005001      21$:  CLR      R1         ; ELSE, SET UNIT FLAGS
4194 041756 004737 050246  22$:  CALL     SUCHAR     ; BUILD "SUC" COMMAND
4195 041762 103417      BCS     T2L1E     ; IF NO PACKETS, EXIT
4196 041764 022765 000003 000042 T2S2N: CMP     @3,C.NEXT(R5) ; CHECK FOR END OF LIST
4197 041772 001406      BEQ     T2S2E     ; IF SO, GO TO NEXT SECTION
4198 041774 005265 000042      INC     C.NEXT(R5) ; ELSE,
4199 042000 012765 000001 000030 MOV     @1,C.STEP(R5) ; DO NEXT
4200 042006 000727      BR      T2S1     ; DRIVE
4201
4202 042010 012765 000003 000030 T2S2E: MOV     @3,C.STEP(R5) ; SET STEP
4203 042016 005065 000042      CLR     C.NEXT(R5) ; NEXT DRIVE IS 1ST IN LIST
4204 042022
4205 042022 000240      T2L1E: NOP
4206 042024 000207      RETURN      ; [DBG] INSERT HALT FOR DEBUG
4207      ;
4208      ;
4209      ; WAIT FOR LAST STEP TO COMPLETE
4210 042026 005765 000164  T2W1:  TST     C.TBSF(R5) ; IF TBS LIST ISN'T EMPTY,
4211 042032 001003      BNE     1$         ; KEEP WAITING
4212 042034 005765 000160      TST     C.CMFL(R5) ; IF CMD LIST IS EMPTY,
4213 042040 001401      BEQ     2$         ; START NEXT STEP
4214 042042 000207      1$:  RETURN
4215 042044 005265 000030  2$:  INC     C.STEP(R5) ; START NEXT STEP
4216
4217      ;
4218      ; STEP 3 - ISSUE A "READ" COMMAND WITH THE DATA COMPARE FLAG SET
4219 042050 004737 045526  T2S3:  CALL     GTNXTD     ; GET POINTER TO DRIVE TABLE
4220 042054 001453      BEQ     T2S4E     ; IF ZERO, DONE
4221 042056 032760 100000 000002 BIT     @DT.AVL,D.UNIT(R0) ; CHECK IF DRIVE AVAILABLE
4222 042064 001035      BNE     T2S4N     ; IF NOT, SKIP SUBTEST
4223 042066 012701 000001      MOV     @1,R1     ; GET A 1 BLOCK
4224 042072 004737 024354      CALL     GETBUF    ; DATA BUFFER
4225 042076 005701      TST     R1         ; IF ZERO,
4226 042100 001467      BEQ     T2L2E     ; EXIT
4227 042102 004737 050556      CALL     READ     ; BUILD READ COMMAND
4228 042106 103003      BCC     22$      ; IF ERROR,
4229 042110 004737 025420      CALL     RETBUF   ; RETURN BUFFER AND
4230 042114 000461      BR      T2L2E     ; EXIT
    
```

```

4231 042116 005265 000030      22:  INC      C.STEP(R5)          ; GOTO NEXT STEP
4232                          ;
4233                          ; STEP 4 - ISSUE AN "ACCESS" COMMAND
4234                          ;
4235 042122 004737 045526      †2S4: CALL     GTNXTD          ; GET POINTER TO DRIVE TABLE
4236 042126 001426                          ; IF ZERO, DONE
4237 042130 032760 100000 000002 BIT     #DT.AVL,D.UNIT(R0) ; CHECK IF DRIVE AVAILABLE
4238 042136 001010                          ; IF NOT, SKIP SUBTEST
4239 042140 012737 024000 004406 MOV     #10240.,BCLO      ; SET BYTECOUNT
4240 042146 005037 004410                          ; TO 20 BLOCKS
4241 042152 004737 050306 CALL    ACCESS          ; BUILD "ACCESS" COMMAND
4242 042156 103440 BCS     T2L2E          ; IF NO PACKETS, EXIT
4243                          ;
4244 042160 022765 000003 000042 T2S4N: CMP     #3.,C.NEXT(R5) ; CHECK FOR END OF LIST
4245 042166 001406                          ; IF SO, GO TO NEXT SECTION
4246 042170 005265 000042                          ; ELSE,
4247 042174 012765 000004 000030 MOV     #4.,C.STEP(R5)   ; DO NEXT
4248 042202 000722 BR      T2S3          ; DRIVE
4249                          ;
4250 042204 012765 000006 000030 T2S4E: MOV     #6.,C.STEP(R5) ; DO NEXT STEP
4251 042212 005065 000042                          ; NEXT DRIVE IS 1ST IN LIST
4252                          ;
4253                          ; STEP 5 - ISSUE A "GET COMMAND STATUS" COMMAND
4254                          ;
4255 042216 005765 000160      †2S5: TST     C.CMFL(R5)      ; IF CMD LIST NOT EMPTY,
4256 042222 001004                          ; DO GCS COMMAND
4257 042224 005765 000164 TST     C.TBSF(R5)      ; IF TBS & CMD LIST EMPTY,
4258 042230 001013                          ; SKIP GCS COMMAND
4259 042232 000410 BR      2#          ;
4260 042234 016504 000160      1#:  MOV     C.CMFL(R5),R4    ; GET COMMAND REFERENCE NUMBER
4261 042240 016401 000004      MOV     ME.CRF(R4),R1    ; OF NEMEST COMMAND
4262 042244 005002                          ; CLEAR HIGH WORD
4263 042246 004737 050056 CALL    GCSTAT          ; BUILD "GCS" COMMAND
4264 042252 103402 BCS     T2L2E          ; IF NO PACKETS, EXIT
4265 042254 005265 000030      2#:  INC     C.STEP(R5)      ; DO NEXT STEP
4266                          ;
4267 042260 T2L2E:                          ;
4268 042260 000240 NOP                          ; [DBG] INSERT HALT FOR DEBUG
4269 042262 000207 RETURN          ; EXIT TEST
4270                          ;
4271                          ; WAIT FOR LAST STEP TO COMPLETE
4272                          ;
4273 042264 005765 000164      †2W2: TST     C.TBSF(R5)      ; IF TBS LIST ISN'T EMPTY,
4274 042270 001003                          ; KEEP WAITING
4275 042272 005765 000160 TST     C.CMFL(R5)      ; IF CMD LIST IS EMPTY,
4276 042276 001401 BEQ     2#          ; START NEXT STEP
4277 042300 000207 RETURN          ;
4278 042302 005265 000030      2#:  INC     C.STEP(R5)      ; START NEXT STEP
4279                          ;
4280                          ; STEP 6 - IF WRITEABLE, ISSUE AN "ERASE" COMMAND
4281                          ;
4282 042306 032737 000100 002204 †2S6: BIT     #IPAT16,IFLAGS ; IF PATTERN 16 CHANGED,
4283 042314 001032 BNE     T2S6E          ; SKIP THIS TEST
4284 042316 004737 045526 CALL    GTNXTD          ; GET POINTER TO DRIVE TABLE
4285 042322 001427 BEQ     T2S6E          ; IF ZERO, DONE
    
```

```

4286 042324 032760 100000 000002      BIT      #DT.AVL,D.UNIT(R0)      ; CHECK IF DRIVE AVAILABLE
4287 042332 001014                      BNE      T2S6N                  ; IF NOT, SKIP SUBTEST
4288 042334 032760 010000 000002      BIT      #DT.WRT,D.UNIT(R0)    ; CHECK IF DRIVE WRITEABLE
4289 042342 001410                      BEQ      T2S6N                  ; IF NOT, SKIP WRITE/COMPARE TEST
4290 042344 012737 001000 004406      MOV      #512,,BCLO            ; SET BYTECOUNT
4291 042352 005037 004410                      CLR      BCHI                    ; TO 1 BLOCK
4292 042356 004737 050532                      CALL     ERASE                    ; BUILD "ERASE" COMMAND
4293 042362 103413                      BCS      T2S6R                  ; IF NO PACKETS, EXIT
4294
4295 042364 022765 000003 000042 T2S6N:  CMP      #3,,C.NEXT(R5)        ; CHECK FOR END OF LIST
4296 042372 001403                      BEQ      T2S6E                  ; IF SO, GO TO NEXT SECTION
4297 042374 005265 000042                      INC      C.NEXT(R5)              ; ELSE,
4298 042400 000742                      BR       T2S6                    ; NEXT DRIVE
4299
4300 042402 005265 000030 T2S6E:  INC      C.STEP(R5)            ; SET STEP
4301 042406 005065 000042                      CLR      C.NEXT(R5)            ; NEXT DRIVE IS 1ST IN LIST
4302
4303 042412 000240 T2S6R:  NOP
4304 042414 000207                      RETURN      ; [DBG] INSERT HALT FOR DEBUG
4305                      ;                               ; EXIT TEST
4306                      ;
4307                      ; WAIT FOR LAST STEP TO COMPLETE
4308 042416 005765 000164 T2M3:   TST      C.TBSF(R5)            ; IF TBS LIST ISN'T EMPTY,
4309 042422 001003                      BNE      1#                      ; KEEP WAITING
4310 042424 005765 000160                      TST      C.CMFL(R5)            ; IF CMD LIST IS EMPTY,
4311 042430 001401                      BEQ      2#                      ; START NEXT STEP
4312 042432 000207                      1#:   RETURN
4313 042434 005265 000030                      2#:   INC      C.STEP(R5)        ; START NEXT STEP
4314
4315                      ;
4316                      ; STEP 7 - IF WRITABLE, WRITE 16 BLOCKS WITH DATA COMPARE. ALSO
4317                      ; DO "COMPARE HOST DATA" ON BLOCKS WRITTEN
4318 042440 004737 045526 T2S7:   CALL     GTNXTD                  ; GET POINTER TO DRIVE TABLE
4319 042444 001443                      BEQ      T2S7E                  ; IF ZERO, DONE
4320 042446 032760 100000 000002      BIT      #DT.AVL,D.UNIT(R0)    ; CHECK IF DRIVE AVAILABLE
4321 042454 001030                      BNE      T2S7N                  ; IF NOT, SKIP SUBTEST
4322 042456 032760 010000 000002      BIT      #DT.WRT,D.UNIT(R0)    ; CHECK IF DRIVE WRITEABLE
4323 042464 001424                      BEQ      T2S7N                  ; IF NOT, SKIP WRITE/COMPARE TEST
4324 042466 012701 000020                      MOV      #16,,R1                ; GET A 16 BLOCK
4325 042472 012703 000021                      MOV      #17,,R3                ; DATA BUFFER
4326 042476 004737 046474                      CALL     PATBLD                  ; CONTAINING ALL PATTERNS
4327 042502 005701                      TST      R1                      ; IF ZERO,
4328 042504 001427                      BEQ      T2S7R                  ; EXIT
4329 042506 032760 004000 000002      BIS      #DT.CMP,D.UNIT(R0)    ; SET COMPARE PENDING BIT
4330 042514 004737 050646                      CALL     WRITE                    ; BUILD "WRITE" COMMAND
4331 042520 103006                      BCC      T2S7N                  ; IF ERROR,
4332 042522 042760 004000 000002      BIC      #DT.CMP,D.UNIT(R0)    ; CLEAR DATA CHECK FLAG,
4333 042530 004737 025420                      CALL     RETBUF                  ; RETURN BUFFER, &
4334 042534 000413                      BR       T2S7R                  ; EXIT
4335
4336 042536 022765 000003 000042 T2S7N:  CMP      #3,,C.NEXT(R5)        ; CHECK FOR END OF LIST
4337 042544 001403                      BEQ      T2S7E                  ; IF SO, GO TO NEXT SECTION
4338 042546 005265 000042                      INC      C.NEXT(R5)              ; ELSE,
4339 042552 000732                      BR       T2S7                    ; NEXT DRIVE
4340
    
```

```

4341 042554 005265 000030      T257E: INC      C.STEP(R5)          ; SET STEP
4342 042560 005065 000042      CLR      C.NEXT(R5)         ; NEXT DRIVE IS 1ST IN LIST
4343 042564                                T257R:
4344 042564 000240      NOP                                ; [DBG] INSERT HALT FOR DEBUG
4345 042566 000207      RETURN                               ; EXIT TEST
4346 ;
4347 ;
4348 ;
4349 042570 005765 000164      T258: TST      C.TBSF(R5)         ; IF TBS LIST ISN'T EMPTY,
4350 042574 001003      BNE      1$                  ; KEEP WAITING
4351 042576 005765 000160      TST      C.CMFL(R5)         ; IF CMD LIST IS EMPTY,
4352 042602 001401      BEQ      2$                  ; START NEXT STEP
4353 042604 000207      1$: RETURN                               ;
4354 042606 005265 000030      2$: INC      C.STEP(R5)         ; START NEXT STEP
4355 ;
4356 ;
4357 ;
4358 042612 004737 045526      T258: CALL      GTNXD           ; GET POINTER TO DRIVE TABLE
4359 042616 001422      BEQ      T258E              ; IF ZERO, DONE
4360 042620 032750 100000 000002 BIT      @DT.AVL.D.UNIT(R0)   ; CHECK IF DRIVE AVAILABLE
4361 042626 001404      BNE      10$                ; IF NOT, SKIP SUBTEST
4362 042630 005003      CLR      R3                  ; CLEAR COMMAND MODIFIERS
4363 042632 004737 050020      CALL      AVAIL             ; BUILD "AVAILABLE" COMMAND
4364 042636 103421      BCS      T258R              ; IF NO PACKETS, EXIT
4365 042640 022765 000003 000042 10$: CMP      @3.,C.NEXT(R5)     ; CHECK FOR END OF LIST
4366 042646 001406      BEQ      T258E              ; IF SO, GO TO NEXT SECTION
4367 042650 005265 000042      INC      C.NEXT(R5)         ; ELSE,
4368 042654 012765 000013 000030 MOV      @11.,C.STEP(R5)     ; DO NEXT
4369 042662 000753      BR       T258               ; DRIVE
4370 ;
4371 ;
4372 ;
4373 042664 005065 000030      T258E: CLR      C.STEP(R5)         ; RESET TEST STEP COUNTER
4374 042670 005065 000042      CLR      C.NEXT(R5)         ; NEXT DRIVE IS 1ST IN LIST
4375 042674 052765 040000 000014 BIS      @CT.DUN.C.FLG(R5)    ; SET TEST DONE FLAG
4376 042702                                T258R:
4377 042702 000240      NOP                                ; [DBG] INSERT HALT FOR DEBUG
4378 042704 000207      RETURN                               ;
    
```



```

4380
4381
4382
4383
4384
4385
4386
4387
4388
4389
4390
4391
4392
4393
4394
4395 042706 042766
4396 042710 043026
4397 042712 043060
4398 042714 043166
4399 042716 043350
4400 042720 043634
4401 042722 043656
4402 042724 044140
4403 042726 044352
4404 042730 044524
4405 042732 045366
4406 042734 045410
4407
4408 042736 016500 000030
4409 042742 022700 000013
4410 042746 103403
4411 042750 006300
4412 042752 000170 042706
4413 042756 012701 042754
4414 042762 000137 024310
4415
4416
4417
4418
4419 042766 004737 052220
4420 042772 103473
4421 042774 012701 000360
4422 043000 005003
4423 043002 005004
4424 043004 004737 050210
4425 043010 103464
4426 043012 005265 000030
4427 043016 005065 000042
4428 043022 005065 000032
4429
4430
4431
4432 043026 004737 045526
4433 043032 001446
4434 043034 032760 100000 000002

***
T3PGEN - GENERATE TEST PACKETS FOR TEST 3 (SUBSYSTEM EXERCISER
TEST). THE FOLLOWING STEPS ARE PERFORMED:
0. INIT EACH CONTROLLER & "SET CONTROLLER CHARACTERISTICS"
1. SET EACH DRIVE "ONLINE"
2. "SET UNIT CHARACTERISTICS" FOR EACH DRIVE
WRITE PROTECT ANY DRIVE THAT IS NOT TO BE WRITTEN
3. "WRITE" EACH DISK USING ALL DATA PATTERNS IF WRITABLE
4. "READ" FIRST 512 BLOCKS ON EACH DISK
5. "ACCESS" REMAINDER OF DISK
6. "READ" & "WRITE" DISK AS PER SOFTWARE QUESTIONS
7. SET EACH DRIVE "AVAILABLE"
---

T3DSP: .WORD T3S0 ; STEP 0 ROUTINE
        .WORD T3S1 ; STEP 1 ROUTINE
        .WORD T3S2 ; STEP 2 ROUTINE
        .WORD T3W1 ; WAIT 1
        .WORD T3S3 ; STEP 3 ROUTINE
        .WORD T3W2 ; WAIT 2
        .WORD T3S4 ; STEP 4 ROUTINE
        .WORD T3S5 ; STEP 5 ROUTINE
        .WORD T3W4 ; WAIT 4
        .WORD T3S6 ; STEP 6 ROUTINE
        .WORD T3W5 ; WAIT 5
        .WORD T3S7 ; STEP 7 ROUTINE

T3PGEN: MOV C,STEP(R5),R0 ; DISPATCH
        CMP #11.,R0 ; TO
        BLO 3# ; CURRENT
        ASL R0 ; STEP
        JMP @T3DSP(R0) ; ROUTINE
3#: MOV #.-2,R1 ; SAVE CURRENT LOCATION
     JMP @ADMEM ; PRINT SYSTEM FATAL ERROR

;
; STEP 0 - INITIALIZE THE CONTROLLER AND
; ISSUE A SET CONTROLLER CHARACTERISTICS COMMAND
T3S0: CALL CNTINT ; INITIALIZE THE CONTROLLER
        BCS T3L1E ; IF ERROR, EXIT
        MOV #<CF.ATN+CF.MSC+CF.OTH+CF.THS>,R1 ; SET CONTROLLER FLAGS
        CLR R3 ; NO MODIFIERS ALLOWED
        CLR R4 ; UNIT MUST BE ZERO
        CALL SCC ; BUILD SCC COMMAND
        BCS T3L1E ; IF NO PACKETS, EXIT
        INC C,STEP(R5) ; SET STEP COUNT
        CLR C,NEXT(R5) ; INIT NEXT DRIVE INDEX
        CLR C,UCNT(R5) ; INIT DRIVE UNDER TEST COUNT

;
; STEP 1 - ISSUE AN "ONLINE" COMMAND FOR EACH DRIVE
T3S1: CALL G7NXTD ; GET POINTER TO DRIVE TABLE
        BEQ T3S2E ; IF ZERO, DONE
        BIT @DT.AVL,D,UNIT(R0) ; CHECK IF DRIVE AVAILABLE
    
```

```

4435 043042 001030      BNE      T3S2N      ; IF NOT, SKIP SUBTEST
4436 043044 005001      CLR      R1         ; SET UNIT FLAGS
4437 043046 004737 050150 CALL     ONLINE     ; BUILD ONLINE COMMAND
4438 043052 103443      BCS     T3L1E     ; IF NO PACKETS, EXIT
4439 043054 005265 000030 INC      C.STEP(R5) ; GO TO STEP 2
4440
4441 ;
4442 ; STEP 2 - ISSUE A "SET UNIT CHARACTERISTICS" COMMAND FOR EACH DRIVE
4443 ; WRITE PROTECT ANY DRIVE THAT IS NOT TO BE WRITTEN
4444 043060 004737 045526 T3S2:  CALL     GTNXTD    ; GET POINTER TO DRIVE TABLE
4445 043064 001431      BEQ     T3S2E     ; IF ZERO, DONE
4446 043066 032760 100000 000002 BIT     @DT.AVL,D.UNIT(R0) ; CHECK IF DRIVE AVAILABLE
4447 043074 001013      BNE     T3S2N     ; IF NOT, SKIP SUBTEST
4448 043076 032760 010000 000002 BIT     @DT.WRT,D.UNIT(R0) ; CHECK IF DRIVE WRITEABLE
4449 043104 001003      BNE     21$      ; IF NOT
4450 043106 012701 010000 MOV     @UF.WPS,R1  ; SET SOFTWARE WRITE PROTECT
4451 043112 000401      BR      22$      ;
4452 043114 005001      21$:  CLR      R1         ; ELSE, SET UNIT FLAGS
4453 043116 004737 050246 22$:  CALL     SUCHAR    ; BUILD "SUC" COMMAND
4454 043122 103417      BCS     T3L1E     ; IF NO PACKETS, EXIT
4455 043124 022765 000003 000042 T3S2N: CMP     @3.C.NEXT(R5) ; CHECK FOR END OF LIST
4456 043132 001406      BEQ     T3S2E     ; IF SO, GO TO NEXT SECTION
4457 043134 005265 000042 INC     C.NEXT(R5)  ; ELSE,
4458 043140 012765 000001 000030 MOV     @1.C.STEP(R5) ; NEXT
4459 043146 000727      BR      T3S1     ; DRIVE
4460
4461 043150 012765 000003 000030 T3S2E: MOV     @3.C.STEP(R5) ; SET NEXT STEP
4462 043156 005065 000042 CLR     C.NEXT(R5)  ; RESET NEXT DRIVE POINTER
4463 043162
4464 043162 000240      T3L1E: NOP
4465 043164 000207      NOP             ; [DBG] INSERT HALT FOR DEBUG
4466 ; RETURN ; EXIT TEST
4467 ;
4468 ; WAIT FOR LAST STEP TO COMPLETE
4469 043166 005765 000164 T3W1:  TST     C.TBSF(R5) ; IF TBS LIST ISN'T EMPTY,
4470 043172 001003      BNE     1$       ; KEEP WAITING
4471 043174 005765 000160 TST     C.CMFL(R5) ; IF CMD LIST IS EMPTY,
4472 043200 001401      BEQ     2$       ; START NEXT STEP
4473 043202 000207      RETURN
4474 043204 032765 002000 000014 1$:  BIT     @CT.DET,C.FLG(R5) ; IF DETERMINISTIC PHASE NOT DONE,
4475 043212 001005      BNE     3$       ; DO DETERMINISTIC PHASE
4476 043214 012765 000011 000030 MOV     @9.C.STEP(R5) ; ELSE,
4477 043222 000137 044524 JMP     T3S6     ; DO USER DEFINED PHASE
4478 043226 005265 000030 3$:  INC     C.STEP(R5) ; DO NEXT STEP
4479 043232 005065 000042 CLR     C.NEXT(R5) ; POINT TO FIRST DRIVE
4480 043236 004737 045526 10$:  CALL     GTNXTD    ; GET POINTER TO NEXT DRIVE TABLE
4481 043242 001435      BEQ     15$     ; IF ZERO, DONE
4482 043244 042760 040000 000002 BIC     @DT.DUN,D.UNIT(R0) ; CLEAR SUBTEST DONE FLAG
4483 043252 022737 000001 002202 CMP     @1.CTRLRS  ; IF MORE THAN 1 CONTROLLER
4484 043260 001004      BNE     11$     ; CAN'T HOG ALL THE BUFFERS FOR WRITE
4485 043262 012760 000200 000050 MOV     @128.,D.BLKS(R0) ; SET BLOCK SIZE TO ENTIRE BUFFER
4486 043270 000403      BR      12$     ;
4487 043272 012760 000140 000050 11$:  MOV     @96.,D.BLKS(R0) ; LEAVE 32 BLOCKS FOR INITIAL READ
4488 043300 016060 000006 000052 12$:  MOV     D.BGN1(R0),D.LBN(R0) ; SET NEXT LBN TO ACCESS TO
4489 043306 016060 000010 000054 MOV     D.BGN1+2(R0),D.LBN+2(R0); FIRST BLOCK IN FIRST BEGIN/END SET
    
```

```

4490 043314 005265 000032      INC      C.UCNT(R5)          ; INCREMENT UNIT UNDER TEST COUNT
4491 043320 022765 000003 000042  CMP      #3.,C.NEXT(R5)    ; CHECK FOR END OF LIST
4492 043326 001403          BEQ      15$              ; IF SO, GET NEXT PATTERN
4493 043330 005265 000042      INC      C.NEXT(R5)        ; ELSE
4494 043334 000740          BR       10$              ; NEXT DRIVE
4495 043336 005065 000042 15$:  CLR      C.NEXT(R5)        ; INIT DRIVE POINTER
4496 043342 005765 000032  TST      C.UCNT(R5)        ; IF NO DRIVES AVAILABLE,
4497 043346 001472          BEQ      T3S3E           ; EXIT STEP
4498
4499
4500
4501
4502 043350 004737 045526      T3S3:  CALL      GTNXTD          ; GET POINTER TO DRIVE TABLE
4503 043354 001455          BEQ      50$              ; IF ZERO, DONE
4504 043356 032760 140000 000002  BIT      #DT.AVL!DT.DUN,D.UNIT(R0); CHECK IF DRIVE AVAILABLE
4505 043364 001037          BNE      40$              ; IF NOT, SKIP WRITE TEST
4506 043366 032760 010000 000002  BIT      #DT.WRT,D.UNIT(R0) ; CHECK IF DRIVE WRITEABLE
4507 043374 001433          BEQ      40$              ; IF NOT, SKIP WRITE TEST
4508
4509
4510
4511 043376 004737 045550 32$:  CALL      GETLBN          ; GENERATE NEXT LBN TO ACCESS
4512 043402 032760 002000 000002  BIT      #DT.EOM,D.UNIT(R0) ; IF END OF MEDIA,
4513 043410 001025          BNE      40$              ; EXIT SUBTEST
4514
4515
4516
4517 043412 016001 000050 37$:  MOV      D.BLKS(R0),R1    ; GET BUFFER SIZE
4518 043416 012703 000021      MOV      #17.,R3         ; SET PATTERN NUMBER (ALL PATTERNS)
4519 043422 004737 046474      CALL     PATBLD          ; BUILD DATA PATTERN
4520 043426 005701          TST      R1               ; IF PATTERN LENGTH ZERO,
4521 043430 001477          BEQ      T3L2E           ; EXIT
4522 043432          PUSH     <R1>           ; SAVE BLOCK COUNT
4523 043434 004737 050646      MOV      R1,-(SP)        ; PUSH R1 ON STACK
4524 043440          CALL     WRITE          ; BUILD "WRITE" COMMAND
4525 043440 012601          POP      <R1>           ; RESTORE BLOCK COUNT
4526 043442 103003          MOV      (SP)+,R1       ; POP STACK INTO R1
4527 043444 004737 025420      BCC      39$             ; IF ERROR,
4528 043450 000467          CALL     RETBUF         ; RETURN BUFFER AND
4529 043452 060160 000052 39$:  BR       T3L2E           ; EXIT
4530 043456 005560 000054      ADD      R1,D.LBN(R0)    ; SET NEXT LBN
4531 043462 000412          ADC      D.LBN+2(R0)    ; TO ACCESS
4532
4533
4534
4535 043464 032760 040000 000002 39$:  BR       50$             ; DO NEXT DRIVE
4536 043472 001006          ; PATTERN DONE ON THIS DRIVE, DROP IT FROM LOOP
4537 043474 052760 040000 000002 40$:  BIT      #DT.DUN,D.UNIT(R0); IF ALREADY MARKED DONE,
4538 043502 005365 000032  BNE      50$             ; FINISH OTHER DRIVES
4539 043506 001412          BIS      #DT.DUN,D.UNIT(R0); SET DONE BIT
4540
4541
4542          DEC      C.UCNT(R5) ; DECREMENT UNIT UNDER TEST COUNT
          BEQ      T3S3E           ; IF ZERO, EXIT
          ; GET NEXT DRIVE IN SEQUENCE
    
```

```

4543 043510 022765 000003 000042 50$: CMP #3.,C.NEXT(R5) ; IF NOT END
4544 043516 001403 BEQ 51$ ; OF DRIVE LIST,
4545 043520 005265 000042 INC C.NEXT(R5) ; THEN, GET NEXT DRIVE &
4546 043524 000711 BR T3S3 ; BUILD MORE PACKETS
4547 043526 005065 000042 51$: CLR C.NEXT(R5) ; ELSE, RESET NEXT DRIVE POINTER &
4548 043532 000436 BR T3L2E ; GO SEND WHAT WE HAVE BUILT
4549 ;
4550 ;
4551 ; END OF STEP. CLEANUP AND GO TO NEXT STEP
4552 043534 005065 000042 T3S3E: CLR C.NEXT(R5) ; POINT TO FIRST DRIVE
4553 043540 004737 045526 10$: CALL GTNXTD ; GET POINTER TO NEXT DRIVE TABLE
4554 043544 001425 BEQ 15$ ; IF ZERO, DONE
4555 043546 042760 042000 000002 BIC #<DT.EOM+DT.DUN>,D.UNIT(R0); CLEAR "END OF MEDIA" & "DONE"
4556 043554 012760 001000 000050 MOV #512.,D.BLKS(R0) ; GET LENGTH OF I/O
4557 043562 016060 000006 000052 MOV D.BGN1(R0),D.LBN(R0) ; SET NEXT LBN TO ACCESS TO
4558 043570 016060 000010 000054 MOV D.BGN1+2(R0),D.LBN+2(R0); FIRST BLOCK IN FIRST BEGIN/END SET
4559 043576 005265 000032 INC C.UCNT(R5) ; INCREMENT UNIT UNDER TEST COUNT
4560 043602 022765 000003 000042 CMP #3.,C.NEXT(R5) ; CHECK FOR END OF LIST
4561 043610 001403 BEQ 15$ ; IF SO, END CLEANUP
4562 043612 005265 000042 INC C.NEXT(R5) ; ELSE,
4563 043616 000750 BR 10$ ; NEXT DRIVE
4564 043620 005065 000042 15$: CLR C.NEXT(R5) ; RESET NEXT DRIVE POINTER
4565 043624 005265 000030 INC C.STEP(R5) ; SET STEP
4566 043630 T3L2E:
4567 043630 000240 NOP ; [DBG] INSERT HALT FOR DEBUG
4568 043632 000207 RETURN ; EXIT TEST
4569 ;
4570 ;
4571 ; WAIT FOR LAST STEP TO COMPLETE
4572 043634 005765 000164 T3W2: TST C.TBSF(R5) ; IF TBS LIST ISN'T EMPTY,
4573 043640 001003 BNE 1$ ; KEEP WAITING
4574 043642 005765 000160 TST C.CMFL(R5) ; IF CMD LIST IS EMPTY,
4575 043646 001401 BEQ 2$ ; START NEXT STEP
4576 043650 000207 1$: RETURN ;
4577 043652 005265 000030 2$: INC C.STEP(R5) ; DO NEXT STEP
4578 ;
4579 ;
4580 ; STEP 4 - "READ" THE FIRST 512 BLOCKS OF EACH DISK. PERFORM
4581 ; DATA VERIFICATION ON THE DATA READ.
4582 043656 004737 045526 T3S4: CALL GTNXTD ; GET POINTER TO DRIVE TABLE
4583 043662 001456 BEQ 50$ ; IF ZERO, DONE
4584 043664 032760 140000 000002 BIT #DT.AVL!DT.DUN,D.UNIT(R0); CHECK IF DRIVE AVAILABLE FOR TEST
4585 043672 001040 BNE 40$ ; IF NOT, SKIP SUBTEST
4586 ;
4587 ; GET LBN TO ACCESS
4588 ;
4589 043674 004737 045550 32$: CALL GETLBN ; GENERATE NEXT LBN TO ACCESS
4590 043700 032760 002000 000002 BIT #DT.EOM,D.UNIT(R0) ; IF END OF MEDIA,
4591 043706 001032 BNE 40$ ; EXIT SUBTEST
4592 ;
4593 ; GET INPUT BUFFER, DO I/O AND UPDATE COUNTERS
4594 ;
4595 043710 012701 000010 MOV #8.,R1 ; GET AN
4596 043714 020160 000050 CMP R1,D.BLKS(R0) ; INPUT
4597 043720 101402 BLOS 33$ ; DATA
    
```

```

4598 043722 016001 000050      MOV     D.BLKS(R0),R1      :      BUFFER
4599 043726 004737 024354      33$:  CALL     GETBUF          :
4600 043732 005701              TST     R1                :      IF ZERO,
4601 043734 001477              BEQ     T3L3E             :      EXIT
4602 043736              PUSH    <R1>              :      SAVE BLOCK COUNT
4603 043740 004737 050556      MOV     R1,-(SP)          :      PUSH R1 ON STACK
4604 043744              CALL    READ              :      BUILD "READ" COMMAND
4605 043746 012601              POP     <R1>              :      RESTORE SAVED REGISTERS
4606 043750 004737 025420      MOV     (SP)+,R1          :      POP STACK INTO R1
4607 043754 000467              BCC     34$              :      IF ERROR,
4608 043756 060160 000052      34$:  CALL    RETBUF          :      RETURN BUFFER AND
4609 043762 005560 000054      BR      T3L3E             :      EXIT
4610 043766 160160 000050      ADD     R1,D.LBN(R0)      :      SET NEXT LBN
4611 043772 001012              ADC     D.LBN+2(R0)       :      TO ACCESS
4612              SUB     R1,D.BLKS(R0)    :      DECREMENT BLOCKS REMAINING
4613              BNE     50$              :      IF NOT ZERO, KEEP GOING
4614              ;
4615              ;      SUBTEST DONE ON THIS DRIVE, DROP IT FROM LOOP
4615 043774 032760 040000 000002 40$:  BIT     #DT.DUN,D.UNIT(R0) :      IF ALREADY MARKED DONE,
4616 044002 001006              BNE     50$              :      FINISH OTHER DRIVES
4617 044004 052760 040000 000002  BIS     #DT.DUN,D.UNIT(R0) :      SET DONE BIT
4618 044012 005365 000032      DEC     C.UCNT(R5)        :      DECREMENT UNIT UNDER TEST COUNT
4619 044016 001412              BEQ     T3S4E             :      IF UNITS LEFT, DO NEXT UNIT
4620              ;
4621              ;      GET NEXT DRIVE IN SEQUENCE
4622              ;
4623 044020 022765 000003 000042 50$:  CMP     #3.,C.NEXT(R5)    :      IF NOT END
4624 044026 001403              BEQ     51$              :      OF DRIVE LIST,
4625 044030 005265 000042      INC     C.NEXT(R5)        :      THEN, GET NEXT DRIVE &
4626 044034 000710              BR      T3S4             :      BUILD MORE PACKETS
4627 044036 005065 000042 51$:  CLR     C.NEXT(R5)        :      ELSE, RESET NEXT DRIVE POINTER &
4628 044042 000434              BR      T3L3E             :      GO SEND WHAT WE HAVE BUILT
4629              ;
4630              ;      END OF STEP. CLEANUP AND GO TO NEXT STEP
4631              ;
4632 044044 005065 000042      T3S4E: CLR     C.NEXT(R5)      :      POINT TO FIRST DRIVE
4633 044050 004737 045526      10$:  CALL    GTNXTD           :      GET POINTER TO NEXT DRIVE TABLE
4634 044054 001423              BEQ     15$              :      IF ZERO, DONE
4635 044056 032760 002000 000002  BIT     #DT.EOM,D.UNIT(R0) :      IF END OF MEDIA,
4636 044064 001010              BNE     11$              :      DON'T COUNT THIS UNIT
4637 044066 042760 040000 000002  BIC     #DT.DUN,D.UNIT(R0) :      CLEAR "END OF MEDIA" & "DONE"
4638 044074 012760 004000 000050  MOV     #2048.,D.BLKS(R0) :      SET BLOCKS TO ACCESS
4639 044102 005265 000032      INC     C.UCNT(R5)        :      INCREMENT UNIT UNDER TEST COUNT
4640 044106 022765 000003 000042 11$:  CMP     #3.,C.NEXT(R5)    :      CHECK FOR END OF LIST
4641 044114 001403              BEQ     15$              :      IF SO, END CLEANUP
4642 044116 005265 000042      INC     C.NEXT(R5)        :      ELSE,
4643 044122 000752              BR      10$              :      NEXT DRIVE
4644 044124 005065 000042 15$:  CLR     C.NEXT(R5)        :      RESET NEXT DRIVE POINTER
4645 044130 005265 000030      INC     C.STEP(R5)        :      SET STEP
4646 044134      T3L3E:
4647 044134 000240      NOP                      :      [DBG] INSERT HALT FOR DEBUG
4648 044136 000207      RETURN                   :      EXIT TEST
4649              ;
4650              ;      STEP 5 - "ACCESS" THE REMAINDER OF EACH DISK.
    
```

```

4651
4652 044140 004737 045526      T3S5: CALL   GTNXD           ; GET POINTER TO DRIVE TABLE
4653 044144 001441              BEQ     50$           ; IF ZERO, DONE
4654 044146 032760 140000 000002 BIT     #DT.AVL!DT.DUN,D.UNIT(R0); CHECK IF DRIVE AVAILABLE FOR TEST
4655 044154 001023              BNE     40$           ; IF NOT, SKIP SUBTEST
4656
4657 ;
4658 ; GET NUMBER OF BLOCKS TO ACCESS AND BYTE COUNT
4659 044156 004737 045550      CALL   GETLBN        ; GENERATE NEXT LBN TO ACCESS
4660 044162 032760 002000 000002 BIT     #DT.EOM,D.UNIT(R0)      ; IF END OF MEDIA,
4661 044170 001015              BNE     40$           ; EXIT SUBTEST
4662 044172 016001 000050      MOV    D.BLKS(R0),R1 ; CALCULATE
4663 044176 004737 045502      CALL   GETBC         ; BYTE COUNT
4664
4665 ; DO "ACCESS" COMMAND
4666 ;
4667 044202 004737 050306      CALL   ACCESS        ; BUILD "ACCESS" COMMAND
4668 044206 103457              BCS    T3L4E        ; IF NO PACKETS, EXIT
4669 044210 066060 000050 000052 ADD    D.BLKS(R0),D.LBN(R0)      ; SET NEXT LBN
4670 044216 005560 000054      ADC    D.LBN+2(R0)   ; TO ACCESS
4671 044222 000412              BR     50$           ; GET NEXT DRIVE
4672
4673 ; SUBTEST DONE ON DRIVE, DROP IT FROM SUBTEST
4674 ;
4675 044224 032760 040000 000002 40$: BIT     #DT.DUN,D.UNIT(R0)      ; IF ALREADY MARKED DONE,
4676 044232 001006              BNE     50$           ; FINISH OTHER DRIVES
4677 044234 052760 040000 000002 BIS     #DT.DUN,D.UNIT(R0)      ; SET DONE BIT
4678 044242 005365 000032      DEC    C.UCNT(R5)   ; DECREMENT UNIT UNDER TEST COUNT
4679 044246 001412              BEQ    T3S5E        ; IF NO UNITS LEFT, EXIT
4680
4681 ; GET NEXT DRIVE IN SEQUENCE
4682 ;
4683 044250 022765 000003 000042 50$: CMP     #3.,C.NEXT(R5)      ; IF NOT END
4684 044256 001403              BEQ    51$           ; OF DRIVE LIST,
4685 044260 005265 000042      INC    C.NEXT(R5)   ; THEN, GET NEXT DRIVE &
4686 044264 000725              BR     T3S5         ; BUILD MORE PACKETS
4687 044266 005065 000042      CLR    C.NEXT(R5)   ; ELSE, RESET NEXT DRIVE POINTER &
4688 044272 000425              BR     T3L4E        ; GO SEND WHAT WE HAVE BUILT
4689
4690 ; END OF STEP. CLEANUP AND GO TO NEXT STEP
4691 ;
4692 044274 005065 000042      T3S5E: CLR    C.NEXT(R5)      ; POINT TO FIRST DRIVE
4693 044300 004737 045526      10$: CALL   GTNXD           ; GET POINTER TO NEXT DRIVE TABLE
4694 044304 001412              BEQ    15$           ; IF ZERO, DONE
4695 044306 042760 042000 000002 BIC     #<DT.EOM+DT.DUN>,D.UNIT(R0); CLEAR "END OF MEDIA" & "DONE"
4696 044314 022765 000003 000042 CMP     #3.,C.NEXT(R5)      ; CHECK FOR END OF LIST
4697 044322 001403              BEQ    15$           ; IF SO, END CLEANUP
4698 044324 005265 000042      INC    C.NEXT(R5)   ; ELSE,
4699 044330 000763              BR     10$          ; NEXT DRIVE
4700 044332 005065 000032      15$: CLR    C.UCNT(R5)      ; RESET UNIT COUNT
4701 044336 005065 000042      CLR    C.NEXT(R5)   ; RESET NEXT DRIVE POINTER
4702 044342 005265 000030      INC    C.STEP(R5)   ; SET STEP
4703 044346
4704 044346 000240      T3L4E: NOP
4705 044350 000207      RETURN              ; [DBG] INSERT HALT FOR DEBUG
                                ; EXIT TEST
    
```

```

4706 ;
4707 ; WAIT FOR LAST STEP TO COMPLETE
4708 ;
4709 044352 005765 000164 ;3W4: TST C.TBSF(R5) ; IF TBS LIST ISN'T EMPTY,
4710 044356 001003 BNE 1$ ; KEEP WAITING
4711 044360 005765 000160 TST C.CMFL(R5) ; IF CMD LIST IS EMPTY,
4712 044364 001401 BEQ 2$ ; START NEXT STEP
4713 044366 000207 1$: RETURN ;
4714 044370 005265 000030 2$: INC C.STEP(R5) ; DO NEXT STEP
4715 044374 042765 002000 000014 BIC #CT.DET,C.FLG(R5) ; INDICATE DETERMINISTIC PHASE DONE
4716 044402 PRINTF #DETHDR,(R5) ; PRINT CONTROLLER INFO MESSAGE
      044402 011546 MOV (R5),-(SP)
      044404 012746 010341 MOV #DETHDR,-(SP)
      044410 012746 000002 MOV #2,-(SP)
      044414 010600 MOV SP,RO
      044416 104417 TRAP C#PNTF
      044420 062706 000006 ADD #6,SP
4717 044424 004737 053550 CALL RNTIME ; GET RUN TIME
4718 044430 PRINTF #RNTIM,RNTHH,RNTMM,RTSS; PRINT RUN TIME
      044430 013746 002272 MOV RTSS,-(SP)
      044434 013746 002270 MOV RNTMM,-(SP)
      044440 013746 002266 MOV RNTHH,-(SP)
      044444 012746 010303 MOV #RNTIM,-(SP)
      044450 012746 000004 MOV #4,-(SP)
      044454 010600 MOV SP,RO
      044456 104417 TRAP C#PNTF
      044460 062706 000012 ADD #12,SP
4719 044464 PRINTF #CRLF ; TERMINATE LINE
      044464 012746 010300 MOV #CRLF,-(SP)
      044470 012746 000001 MOV #1,-(SP)
      044474 010600 MOV SP,RO
      044476 104417 TRAP C#PNTF
      044500 062706 000004 ADD #4,SP
4720 044504 PRINTF #DETDUN ; PRINT "DETERMINISTIC PHASE DONE"
      044504 012746 010415 MOV #DETDUN,-(SP)
      044510 012746 000001 MOV #1,-(SP)
      044514 010600 MOV SP,RO
      044516 104417 TRAP C#PNTF
      044520 062706 000004 ADD #4,SP
4721 ;
4722 ; STEP 6 - GENERATE I/O TO THE DRIVES AS PER THE SOFTWARE AND
4723 ; MANUAL INTERVENTION QUESTIONS.
4724 ;
4725 044524 005765 000164 ;3S6: TST C.TBSF(R5) ; IF TBS LIST IS EMPTY,
4726 044530 001401 BEQ 2$ ; BUILD MORE PACKETS
4727 044532 000207 RETURN ;
4728 044534 005765 000032 2$: TST C.UCNT(R5) ; IF MORE DRIVES AVAILABLE,
4729 044540 001035 BNE 20$ ; GET NEXT DRIVE
4730 ;
4731 ; DO STEP SETUP
4732 ;
4733 044542 005065 000042 10$: CLR C.NEXT(R5) ; POINT TO FIRST DRIVE
4734 044546 004737 045526 CALL GTNXTD ; GET POINTER TO NEXT DRIVE TABLE
4735 044552 001421 BEQ 15$ ; IF ZERO, DONE
4736 044554 005060 000050 CLR D.BLKS(RO) ; CLEAR BLOCK SIZE
    
```

```

4737 044560 016060 000006 000052      MOV      D.BGN1(R0),D.LBN(R0)      ; SET NEXT LBN TO ACCESS TO
4738 044566 016060 000010 000054      MOV      D.BGN1+2(R0),D.LBN+2(R0); FIRST BLOCK IN FIRST BEGIN/END SET
4739 044574 005265 000032                INC      C.UCNT(R5)                ; INCREMENT UNIT UNDER TEST COUNT
4740 044600 022765 000003 000042 11$:    CMP      #3.,C.NEXT(R5)            ; CHECK FOR END OF LIST
4741 044606 001403                BEQ      15$                        ; IF SO, GET NEXT PATTERN
4742 044610 005265 000042                INC      C.NEXT(R5)                ; ELSE,
4743 044614 000754                BR       10$                        ; NEXT DRIVE
4744 044616 005065 000042 15$:    CLR      C.NEXT(R5)                ; INIT DRIVE POINTER
4745 044622 005765 000032                TST      C.UCNT(R5)                ; IF MORE DRIVES AVAILABLE,
4746 044626 001002                BNE      20$                        ; GET NEXT DRIVE
4747 044630 000137 045310                JMP      T3S6E                      ; ELSE, EXIT STEP
4748
4749 044634 004737 045526 20$:    CALL     GTNXTD                    ; GET POINTER TO DRIVE TABLE
4750 044640 001002                BNE      24$                        ; IF NOT ZERO, CONTINUE
4751 044642 000137 045262                JMP      50$                        ; ELSE, NO MORE DRIVES
4752 044646 032760 140000 000002 24$:    BIT      #DT.AVL!DT.DUN,D.UNIT(R0); CHECK IF DRIVE AVAILABLE
4753 044654 001170                BNE      40$                        ; IF NOT AVAILABLE, SKIP TEST
4754
4755      ;
4756      ; GET SIZE OF TRANSFER
4757 044656 013701 002152 30$:    MOV      SFPTBL+SO.MTS,R1           ; GENERATE
4758 044662 032737 000020 002154      BIT      #SM.VLT,SFPTBL+SO.BIT     ; TRANSFER
4759 044670 001405                BEQ      31$                        ; LENGTH
4760 044672 005301                DEC      R1                          ; IN
4761 044674 005002                CLR      R2                          ; BLOCKS
4762 044676 004737 026250                CALL     RANDOM
4763 044702 005201                INC      R1
4764 044704 010160 000050 31$:    MOV      R1,D.BLKS(R0)
4765
4766      ;
4767      ; GET NEXT LBN TO ACCESS AND DETERMINE I/O OPERATION TYPE
4768 044710 004737 045550                CALL     GETLBN                    ; GENERATE NEXT LBN TO ACCESS
4769 044714 032760 010000 000002      BIT      #DT.WRT,D.UNIT(R0)        ; CHECK IF DRIVE WRITEABLE
4770 044722 001513                BEQ      37$                        ; IF NOT, DO READS ONLY
4771 044724 012701 177777                MOV      #-1.,R1                    ; DO
4772 044730 005002                CLR      R2                          ; READ
4773 044732 004737 026250                CALL     RANDOM                    ; OR
4774 044736 032701 000010                BIT      #10,R1                     ; WRITE?
4775 044742 001503                BEQ      37$                        ;
4776 044744 005760 000060                TST      D.CCNT(R0)                ; IF "COMPARE HOST DATA" OUTSTANDING,
4777 044750 001100                BNE      37$                        ; DO "READ"
4778
4779      ;
4780      ; GET DATA PATTERN TO WRITE
4781 044752 013701 002260                MOV      TS.PAT,R1                  ; GENERATE
4782 044756 001006                BNE      33$                        ; PATTERN
4783 044760 012701 000017                MOV      #15.,R1                    ; TO
4784 044764 005002                CLR      R2                          ; USE
4785 044766 004737 026250                CALL     RANDOM
4786 044772 000404                BR       34$                        ;
4787 044774 022701 000020 33$:    CMP      #16.,R1                    ; IF PATTERN = 16,
4788 045000 001001                BNE      34$                        ; USE PATTERN 0
4789 045002 005001                CLR      R1                          ;
4790 045004 010165 000040 34$:    MOV      R1,C.TPAT(R5)
4791

```



```

4792      ;      CHECK WHETHER TO DO "WRITE" OR "ERASE" OPERATION
4793      ;
4794 045010 016001 000050      MOV      D.BLKS(R0),R1      ; GET NUMBER OF BLOCKS TO WRITE
4795 045014 016503 000040      MOV      C.TPAT(R5),R3      ; GET DATA PATTERN
4796 045020 005760 000056      TST      D.WCNT(R0)      ; IF NO WRITES OUTSTANDING,
4797 045024 001420      BEQ      35$      ; DO "WRITE"
4798 045026 032760 004000 000002  BIT      @DT.CMP,D.UNIT(R0)      ; IF "COMPARE HOST DATA" PENDING,
4799 045034 001046      BNE      37$      ; DO "READ"
4800 045036 005703      TST      R3      ; IF DATA PATTERN IS NOT ZERO,
4801 045040 001012      BNE      35$      ; WRITE NEEDED PATTERN
4802 045042 032737 000100 002204  BIT      @IPAT16,IFLAGS      ; IF SET
4803 045050 001006      BNE      35$      ; DON'T USE ERASE FOR PATTERN 0
4804 045052 004737 045502      CALL     GETBC      ; CALCULATE BYTE COUNT
4805 045056 004737 050532      CALL     ERASE      ; BUILD "ERASE" COMMAND
4806 045062 103537      BCS      T3L5E      ; IF NO PACKETS, EXIT
4807 045064 000456      BR      39$      ; ELSE, DO NEXT COMMAND
4808
4809 045066 004737 046474      35$:    CALL     PATBLD      ; BUILD DATA PATTERN
4810 045072 005701      TST      R1      ; IF PATTERN SIZE ZERO,
4811 045074 001444      BEQ      38$      ; DO "ACCESS"
4812 045076 010160 000050      MOV      R1,D.BLKS(R0)      ; SAVE ACTUAL BLOCK COUNT
4813 045102 032737 000010 002154  BIT      @SM.CMP,SFPTBL+50.BIT      ; IF NOT SET
4814 045110 001412      BEQ      36$      ; DON'T DO PATTERN VERIFICATION
4815 045112 012701 000037      MOV      @31.,R1      ; GIVE PATTERN
4816 045116 005002      CLR      R2      ; VERIFICATION A
4817 045120 004737 026250      CALL     RANDOM      ; 1 IN 8 CHANCE
4818 045124 005701      TST      R1      ; IF ZERO,
4819 045126 001003      BNE      36$      ; DO PATTERN VERIFICATION
4820 045130 052760 004000 000002  BIS      @DT.CMP,D.UNIT(R0)      ;
4821 045136 004737 050646      36$:    CALL     WRITE      ; BUILD WRITE COMMAND
4822 045142 103027      BCC      39$      ; IF ERROR,
4823 045144 004737 025420      CALL     RETBUF      ; RETURN BUFFER &
4824 045150 000504      BR      T3L5E      ; EXIT
4825
4826      ;
4827      ;      DO "READ" OPERATION
4828 045152 016001 000050      37$:    MOV      D.BLKS(R0),R1      ; GET INPUT
4829 045156 004737 024354      CALL     GETBUF      ; BUFFER
4830 045162 005701      TST      R1      ; IF ZERO,
4831 045164 001410      BEQ      38$      ; DO "ACCESS"
4832 045166 010160 000050      MOV      R1,D.BLKS(R0)      ; SAVE ACTUAL BLOCK COUNT
4833 045172 004737 050556      CALL     READ      ; BUILD READ COMMAND
4834 045176 103011      BCC      39$      ; IF ERROR,
4835 045200 004737 025420      CALL     RETBUF      ; RETURN BUFFER AND
4836 045204 000466      BR      T3L5E      ; EXIT
4837
4838      ;
4839      ;      DO "ACCESS" IF NO BUFFERS AVAILABLE
4840 045206 016001 000050      38$:    MOV      D.BLKS(R0),R1      ; CALCULATE
4841 045212 004737 045502      CALL     GETBC      ; BYTE COUNT
4842 045216 004737 050306      CALL     ACCESS      ; BUILD ACCESS COMMAND
4843
4844 045222 066060 000050 000052  39$:    ADD      D.BLKS(R0),D.LBN(R0)      ; SET NEXT LBN
4845 045230 005560 000054      ADC      D.LBN+2(R0)      ; TO ACCESS
4846 045234 000412      BR      50$
    
```

```

4847 ;
4848 ; DRIVE NOT AVAILABLE, DROP IT FROM SUBTEST
4849 ;
4850 045236 032760 040000 000002 40$: BIT #DT.DUN,D.UNIT(R0) ; IF ALREADY MARKED DONE,
4851 045244 001006 BNE 50$ ; FINISH OTHER DRIVES
4852 045246 052760 040000 000002 BIS #DT.DUN,D.UNIT(R0) ; SET DONE BIT
4853 045254 005365 000032 DEC C.UCNT(R5) ; DECREMENT UNIT UNDER TEST COUNT
4854 045250 001413 BEQ T3S6E ; IF NO UNITS LEFT, EXIT
4855 ;
4856 ; GET NEXT DRIVE IN SEQUENCE
4857 ;
4858 045262 022765 000003 000042 50$: CMP #3.,C.NEXT(R5) ; IF NOT END
4859 045270 001404 BEQ 51$ ; OF DRIVE LIST,
4860 045272 005265 000042 INC C.NEXT(R5) ; THEN, GET NEXT DRIVE &
4861 045276 000137 044634 JMP 20$ ; BUILD MORE PACKETS
4862 045302 005065 000042 51$: CLR C.NEXT(R5) ; ELSE, RESET NEXT DRIVE POINTER &
4863 045306 000425 BR T3L5E ; GO SEND WHAT WE HAVE BUILT
4864 ;
4865 ; END OF STEP. CLEANUP AND GO TO NEXT STEP
4866 ;
4867 045310 005065 000042 T3S6E: CLR C.NEXT(R5) ; POINT TO FIRST DRIVE
4868 045314 004737 045526 10$: CALL GTNXTD ; GET POINTER TO NEXT DRIVE TABLE
4869 045320 001412 BEQ 15$ ; IF ZERO, DONE
4870 045322 042760 040000 000002 BIC #DT.DUN,D.UNIT(R0) ; CLEAR "END OF MEDIA" & "DONE"
4871 045330 022765 000003 000042 CMP #3.,C.NEXT(R5) ; CHECK FOR END OF LIST
4872 045336 001403 BEQ 15$ ; IF SO, END CLEANUP
4873 045340 005265 000042 INC C.NEXT(R5) ; ELSE,
4874 045344 000763 BR 10$ ; NEXT DRIVE
4875 045346 005065 000032 15$: CLR C.UCNT(R5) ; RESET UNIT COUNT
4876 045352 005065 000042 CLR C.NEXT(R5) ; RESET NEXT DRIVE POINTER
4877 045356 005265 000030 INC C.STEP(R5) ; SET STEP
4878 045362 T3L5E:
4879 045362 000240 NOP ; [DBG] INSERT HALT FOR DEBUG
4880 045364 000207 RETURN ; EXIT TEST
4881 ;
4882 ; WAIT FOR LAST STEP TO COMPLETE
4883 ;
4884 045366 005765 000164 T3W5: TST C.TBSF(R5) ; IF TBS LIST ISN'T EMPTY,
4885 045372 001003 BNE 1$ ; KEEP WAITING
4886 045374 005765 000160 TST C.CMFL(R5) ; IF CMD LIST IS EMPTY,
4887 045400 001401 BEQ 2$ ; START NEXT STEP
4888 045402 000207 1$: RETURN ;
4889 045404 005265 000030 2$: INC C.STEP(R5) ; DO NEXT STEP
4890 ;
4891 ; STEP 7 - SET ALL DRIVES AVAILABLE
4892 ;
4893 045410 004737 045526 T3S7: CALL GTNXTD ; GET POINTER TO DRIVE TABLE
4894 045414 001417 BEQ 79$ ; IF ZERO, DONE
4895 045416 032760 100000 000002 BIT #DT.AVL,D.UNIT(R0) ; CHECK IF DRIVE AVAILABLE
4896 045424 001004 BNE 75$ ; IF NOT, SKIP SUBTEST
4897 045426 005003 CLR R3 ; CLEAR COMMAND MODIFIERS
4898 045430 004737 050020 CALL AVAIL ; BUILD "AVAILABLE" COMMAND
4899 045434 103420 BCS T3L6E ; IF NO PACKETS, EXIT
4900 045436 022765 000003 000042 75$: CMP #3.,C.NEXT(R5) ; CHECK FOR END OF LIST
4901 045444 001403 BEQ 79$ ; IF SO, GO TO NEXT SECTION
    
```

```
4902 045446 005265 000042          INC    C.NEXT(R5)          ; ELSE,  
4903 045452 000756                   BR     T3S7                ; NEXT DRIVE  
4904                                     ;  
4905                                     ;  
4906                                     ;  
4907 045454 005065 000032          79$: CLR    C.UCNT(R5)          ; RESET UNIT UNDER TEST COUNT  
4908 045460 005065 000030          CLR    C.STEP(R5)         ; RESET TEST STEP COUNTER  
4909 045464 005065 000042          CLR    C.NEXT(R5)         ; NEXT DRIVE IS 1ST IN LIST  
4910 045470 052765 040000 000014  BIS    @CT.DUN,C.FLG(R5)   ; SET TEST DONE FLAG  
4911 045476                                     ;  
4912 045476 000240          T3L6E: ; [DBG] INSERT HALT FOR DEBUG  
4913 045500 000207          NOP                    ; EXIT TEST  
                                     RETURN
```

```

4915
4916
4917      :++
4918      :
4919      :   GETBC - CONVERT FROM BLOCKS TO BYTES
4920      :
4921      :   INPUTS:
4922      :         R1 - NUMBER OF BLOCKS
4923      :
4924      :   OUTPUTS:
4925      :         BCLO, BCHI - BYTE COUNT
4926      :
4927      :---
4928
4929      GETBC:  MOV     #512,,R2           ; CALCULATE
4930      :         CALL    MULT             ; COUNT
4931      :         MOV     R3,BCLO           ; FOR
4932      :         MOV     R4,BCHI           ; I/O
4933      :
4934      :         NOP                       ; [DBG] INSERT HALT FOR DEBUG
4935      :         RETURN                    ;
4936
4937      :++
4938      :
4939      :   GTNXTD - GET POINTER TO NEXT DRIVE TABLE
4940      :
4941      :   INPUTS:
4942      :         R5 - ADDRESS OF CONTROLLER TABLE
4943      :
4944      :   OUTPUTS:
4945      :         R0 - POINTER TO DRIVE TABLE
4946      :
4947      :---
4948
4949      GTNXTD: MOV     C.NEXT(R5),R0      ; GET
4950      :         ASL     R0                 ; POINTER
4951      :         ADD     R5,R0               ; TO DRIVE
4952      :         ADD     @C.DRO,R0          ; TABLE
4953      :         MOV     (R0),R0            ; GET START OF TABLE
4954      :
4955      :         NOP                       ; [DBG] INSERT HALT FOR DEBUG
4956      :         RETURN                    ;
    
```



```

5004 045746 001404      BEQ      28$      : GET FIRST LBN IN FIRST B/E SET
5005 045750 052760 002000 000002      BIS      @DT.EDM,D.(R0) : SET END OF MEDIA FLAG
5006 045756 000434      BR       120$     :
5007
5008 045760 016004 000046      28$:      MOV      D.BES(R0),R4      : GET POINTER
5009 045764 004737 046060      CALL    GETBES      : TO BEGIN/END SET
5010 045770 011460 000052      MOV      (R4),D.LBN(R0) : SAVE NEXT LBN
5011 045774 016460 000002 000054      MOV      2(R4),D.LBN+2(R0) : TO ACCESS
5012
5013 046002 016401 000004      30$:      MOV      4(R4),R1      : GET
5014 046006 016402 000006      MOV      6(R4),R2      : REMAINING
5015 046012 062701 000001      ADD      @1,R1         : BEGIN/END
5016 046016 005502      ADC      R2           : SET
5017 046020 166001 000052      SUB      D.LBN(R0),R1  : LENGTH
5018 046024 005602      SBC      R2           : IN
5019 046026 166002 000054      SUB      D.LBN+2(R0),R2 : BLOCKS
5020 046032 005702      TST      R2           : MAKE SURE
5021 046034 001005      BNE      120$        : D.BLKS(R0)
5022 046036 026001 000050      CMP      D.BLKS(R0),R1 : IS NOT GREATER
5023 046042 101402      BLOS     120$        : THAN REMAINING
5024 046044 010160 000050      MOV      R1,D.BLKS(R0) : BEGIN/END SET
5025
5026 046050      120$:      POP      <R2,R1>     :
5027 046054 000240      NOP      ; [DBG] INSERT HALT FOR DEBUG
5028 046056 000207      RETURN  ;
5029
5030      ;**
5031      ; GETBES - GENERATE POINTER TO CURRENT BEGIN/END SET
5032      ;
5033      ; INPUT:
5034      ; R4 - BEGIN/END SET INDEX
5035      ; OUTPUT:
5036      ; R4 - POINTER TO BEGIN/END SET IN DISK TABLE
5037      ;--
5038
5039 046060 006304      GETBES: ASL      R4           : GET
5040 046062 006304      ASL      R4           : OFFSET
5041 046064 006304      ASL      R4           : TO FIRST
5042 046066 060004      ADD      R0,R4        : LBN IN
5043 046070 0627C4 000006      ADD      @D.BGM1,R4   : BEGIN/END SET
5044 046074 000240      NOP      ; [DBG] INSERT HALT FOR DEBUG
5045 046076 000207      RETURN  ;
    
```



```

5102 046310 101402          BLOS      15$          :      OF WORDS
5103 046312 013700 004406   MOV      BCLO,R0      :      TO CHECK
5104 046316 022122          15$:    CMP      (R1)*,(R2)* :      COMPARE
5105 046320 001024          BNE      30$          :      BUFFER
5106 046322 005203          INC      R3           :      CONTENTS
5107 046324 020003          CMP      R0,R3       :      IF NOT AT END,
5108 046326 003373          BGT      15$          :      CHECK NEXT WORD
5109 046330 005237 004374   INC      BUFBLK      :      COUNT BLOCKS CHECKED
5110 046334 006303          ASL      R3           :      CALCULATE NEXT
5111 046336 060337 002242   ADD      R3,TSTOFF   :      MEMORY OFFSET
5112 046342 160037 004406   SUB      R0,BCLO     :      IF NOT ZERO,
5113 046346 001310          BNE      10$          :      GET NEXT BUFFER
5114 046350          POP      <R4>        :      RESTORE SAVED REGISTERS
5115 046352 000241          CLC           :      CLEAR CARRY TO INDICATE SUCCESS
5116 046354          20$:    POP      <R4,R3,R2,R1,R0> :      RESTORE SAVED REGISTERS
5117 046366 000240          NOP          :      ; [DBG] INSERT HALT FOR DEBUG
5118 046370 000207          RETURN      :
5119
5120 046372          30$:    POP      <R4>        :      RESTORE POINTER TO M.E.
5121 046374 016437 000062 004370   MOV      P.LBN+ME.CP(R4),BUFBA :      GET
5122 046402 016437 000064 004372   MOV      P.LBN+2+ME.CP(R4),BUFEA :      LBN
5123 046410 063737 004374 004370   ADD      BUFBLK,BUFEA :      CONTAINING BAD
5124 046416 005537 004372          ADC      BUFEA       :      DATA WORD
5125 046422 006303          ASL      R3           :      CONVERT TO BYTE OFFSET
5126 046424 010337 004406          MOV      R3,BCLO     :
5127 046430 016237 177776 004364   MOV      -2(R2),PCGOOD :      POINT TO
5128 046436 016137 177776 004366   MOV      -2(R1),PCBAD  :      FAILING DATA
5129 046444 016501 000104          MOV      C.RHDR(R5),R1 :      CALCULATE ADDRESS
5130 046450 062701 000012          ADD      @<P.UNIT+RE.RP>,R1 :      CONTAINING UNIT NUMBER
5131 046454          ERRHRD 38,ERRO38 :      PRINT DATA COMPARE ERROR
5131 046454          TRAP  C$ERRHRD
5131 046456          .WORD 38
5131 046460          .WORD 0
5131 046462          .WORD ERRO38
5132 046464 004737 026006   CALL    RTNME        :      RETURN M.E. & CLEAR RESPONSE RING
5133 046470 000261          SEC           :      SET CARRY TO INDICATE ERROR
5134 046472 000730          BR      20$
    
```



```

5136
5137
5138
5139
5140
5141
5142
5143
5144
5145
5146
5147
5148
5149
5150
5151
5152
5153
5154 046474 010046
      046474 010246
      046476 010446
      046500 010546
      046502 010546
5155 046504 042737 000040 002204
5156 046512 032765 000400 000014
5157 046520 001403
5158 046522 052737 000040 002204
5159 046530 006303
5160 046532 010305
5161 046534 026501 004516
5162 046540 103423
5163 046542 016503 004412
5164 046546 013704 004622
5165 046552 001004
5166 046554 012701 046552
5167 046560 000137 024310
5168 046564 026403 000004
5169 046570 001402
5170 046572 011404
5171 046574 000766
5172 046576 105264 000003
5173 046602 004737 025006
5174 046606 000556
5175
5176 046610 004737 024354
5177 046614 005701
5178 046616 001407
5179 046620 026501 004516
5180 046624 103410
5181 046626 010337 002242
5182 046632 004737 025420
5183 046636 016501 004516
5184 046642 001337
5185 046644 000537
5186
    ;**
    ; PATBLD - BUILD A MEMORY BUFFER CONTAINING A SPECIFIED DATA
    ; PATTERN. IF A MEMORY SEGMENT CONTAINING THE NEEDED PATTERN
    ; EXISTS IN THE MULTI-USE TABLE AND ITS SIZE IS BIG ENOUGH, USE
    ; IT. OTHERWISE ALLOCATE A NEW MEMORY SEGMENT.
    ;
    ; INPUTS:
    ; R1 - NUMBER OF BLOCKS NEEDED
    ; R3 - THE PATTERN NUMBER
    ;
    ; OUTPUTS:
    ; R1 - BLOCKS ALLOCATED
    ; R3 - MAPPED MEMORY OFFSET
    ; BCLO,BCHI - BYTE COUNT
    ; BUFBA,BUFEA - PHYSICAL ADDRESS OF BUFFER
    ; TSTOFF - MEMORY OFFSET TO BUFFER
    ;--
PATBLD: PUSH <R0,R2,R4,R5> ; SAVE REGISTERS
        MOV R0,-(SP) ; PUSH R0 ON STACK
        MOV R2,-(SP) ; PUSH R2 ON STACK
        MOV R4,-(SP) ; PUSH R4 ON STACK
        MOV R5,-(SP) ; PUSH R5 ON STACK
        BIC #ITEMP,IFLAGS ; CLEAR TEMPORARY FLAG BIT
        BIT #CT.MRW,C.FLG(R5) ; IF MAINTENANCE OPERATION IN
        BEQ 1$ ; SET TEMPORARY BIT TO
        BIS #ITEMP,IFLAGS ; INDICATE MAINTENANCE MODE
        ASL R3 ; CONVERT TO WORD OFFSET
        MOV R3,R5 ; SAVE PATTERN OFFSET
        CMP MUTSIZ(R5),R1 ; IF SIZE NEEDED > EXISTING SIZE
        BLO 10$ ; ALLOCATE A NEW SEGMENT
        MOV MUTOFF(R5),R3 ; ELSE, USE CURRENT SEGMENT
        MOV M.HDR,R4 ; FIND PACKET IN MEMORY LIST
        BNE 6$ ; IF NOT END OF LIST, KEEP LOOKING
        MOV #.-2,R1 ; ELSE, THE PACKET WASN'T FOUND
        JMP BADMEM ; PRINT SYSTEM FATAL ERROR
        CMP 4(R4),R3 ; IF MEMORY OFFSETS ARE SAME,
        BEQ 8$ ; SEARCH DONE
        MOV (R4),R4 ; ELSE,
        BR 4$ ; POINT TO NEXT PACKET
        INCB 3(R4) ; INCREMENT NUMBER OF USERS
        CALL MAPMEM ; GET BYTE COUNT & PHYSICAL ADDRESS
        BR 50$ ; EXIT
        CALL GETBUF ; GET NEEDED MEMORY
        TST R1 ; IF RETURNED SIZE ZERO,
        BEQ 11$ ; USE EXISTING BUFFER
        CMP MUTSIZ(R5),R1 ; IF EXISTING SIZE < PACKET RETURNED
        BLO 20$ ; BUILD NEW PACKET
        MOV R3,TSTOFF ; ELSE,
        CALL RETBUF ; RETURN UNEEDED BUFFER
        MOV MUTSIZ(R5),R1 ; IF EXISTING BUFFER SIZE NOT ZERO,
        BNE 2$ ; USE EXISTING BUFFER
        BR 50$ ; ELSE, EXIT ROUTINE
    
```

5187	046646			20:	PUSH	<R3,R1>		: SAVE BLOCK COUNT & MEMORY OFFSET
	046646	010346			MOV	R3,-(SP)		: PUSH R3 ON STACK
	046650	010146			MOV	P1,-(SP)		: PUSH R1 ON STACK
5188	046652	010165	004516		MOV	R1,MUTSIZ(R5)		: PUT NEW BUFFER IN
5189	046656	010365	004412		MOV	R3,MUTOFF(R5)		: MULTI-USE LIST
5190	046662	032737	000040	002204	BIT	#ITEMP,IFLAGS		: IF MAINTENANCE OPERATION IN
5191	046670	001101			BNE	40\$: PROGRESS, USE SPECIAL PATTERNS
5192	046672	022705	000042		CMP	#<17.*2>,R5		: IF PATTERN = 17,
5193	046676	001433			BEQ	30\$: PUT ALL PATTERNS IN BUFFER
5194	046700	016500	006776		MOV	PATDSP(R5),R0		: GET POINTER TO DATA PATTERN
5195	046704	012702	002364		MOV	#OBUF,R2		: POINT TO OUTPUT BUFFER AREA
5196	046710	012022			MOV	(R0)+,(R2)+		: PUT PATTERN NUMBER IN BUFFER
5197	046712	012704	000377		MOV	#255.,R4		: GET BUFFER SIZE - 1
5198	046716	010001		22:	MOV	R0,R1		: GET POINTER TO FIRST WORD IN PATTERN
5199	046720	012105			MOV	(R1)+,R5		: GET COUNT OF WORDS IN PATTERN
5200	046722	012122		23:	MOV	(R1)+,(R2)+		: WRITE NEXT WORD TO BUFFER
5201	046724	005304			DEC	R4		: DECREMENT BUFFER SIZE COUNT
5202	046726	001403			BEQ	24\$: IF ZERO, GET OUT OF LOOP
5203	046730	005305			DEC	R5		: DECREMENT PATTERN SIZE COUNT
5204	046732	001771			BEQ	22\$: IF ZERO, GO TO TOP OF PATTERN
5205	046734	000772			BR	23\$: ELSE CONTINUE LOOP
5206	046736	011602		24:	MOV	(SP),R2		: CREATE LOOP COUNTER
5207	046740	012701	002364		MOV	#OBUF,R1		: WRITE OUTPUT BUFFER TO
5208	046744	004737	025276	25:	CALL	BFTOMM		: MAPPED MEMORY BUFFER
5209	046750	062703	001000		ADD	#512.,R3		: INCREMENT OFFSET
5210	046754	005302			DEC	R2		: DECREMENT LOOP COUNT
5211	046756	001372			BNE	25\$: IF NOT ZERO, LOOP
5212	046760				POP	<R1,R3>		: RESTORE REGISTERS
	046760	012601			MOV	(SP)+,R1		: POP STACK INTO R1
	046762	012603			MOV	(SP)+,R3		: POP STACK INTO R3
5213	046764	000467			BR	50\$: EXIT ROUTINE
5214								
5215	046766	010102		30:	MOV	R1,R2		: CREATE LOOP COUNTER
5216	046770	012705	000036	31:	MOV	#<15.*2>,R5		: POINT TO DATA PATTERN 15
5217	046774			32:	PUSH	<R2>		: SAVE LOOP COUNTER
	046774	010246			MOV	R2,-(SP)		: PUSH R2 ON STACK
5218	046776	016500	006776		MOV	PATDSP(R5),R0		: GET POINTER TO DATA PATTERN
5219	047002	012702	002364		MOV	#OBUF,R2		: POINT TO OUTPUT BUFFER AREA
5220	047006	012022			MOV	(R0)+,(R2)+		: PUT PATTERN NUMBER IN BUFFER
5221	047010	012704	000377		MOV	#255.,R4		: GET BUFFER SIZE - 1
5222	047014	010001		33:	MOV	R0,R1		: GET POINTER TO FIRST WORD IN PATTERN
5223	047016	012105			MOV	(R1)+,R5		: GET COUNT OF WORDS IN PATTERN
5224	047020	012122		34:	MOV	(R1)+,(R2)+		: WRITE NEXT WORD TO BUFFER
5225	047022	005304			DEC	R4		: DECREMENT BUFFER SIZE COUNT
5226	047024	001403			BEQ	35\$: IF ZERO, GET OUT OF LOOP
5227	047026	005305			DEC	R5		: DECREMENT PATTERN SIZE COUNT
5228	047030	001771			BEQ	33\$: IF ZERO, GO TO TOP OF PATTERN
5229	047032	000772			BR	34\$: ELSE CONTINUE LOOP
5230	047034	012701	002364	35:	MOV	#OBUF,R1		: WRITE OUTPUT BUFFER TO
5231	047040	004737	025276		CALL	BFTOMM		: MAPPED MEMORY BUFFER
5232	047044	062703	001000		ADD	#512.,R3		: INCREMENT OFFSET
5233	047050				POP	<R2>		: RESTORE LOOP COUNT
	047050	012602			MOV	(SP)+,R2		: POP STACK INTO R2
5234	047052	005302			DEC	R2		: DECREMENT LOOP COUNT
5235	047054	001404			BEQ	39\$: IF ZERO, EXIT LOOP

```

5236 047056 005305          DEC      R5          ; ELSE
5237 047060 005305          DEC      R5          ;   POINT TO NEXT PATTERN
5238 047062 002344          BGE     32$         ;   IF LESS THAN ZERO,
5239 047064 000741          BR      31$         ;   START WITH PATTERN 15 AGAIN
5240 047066          39$:  POP     <R1,R3>      ; RESTORE REGISTERS
          047066 012601      MOV     (SP)+,R1    ; POP STACK INTO R1
          047070 012603      MOV     (SP)+,R3    ; POP STACK INTO R3
5241 047072 000424          BR      50$         ;
5242
5243 047074 016500 007036    40$:  MOV     MNTPAT(R5),R0 ; GET DATA PATTERN
5244 047100 012702 002364    MOV     #0BUFF,R2    ; POINT TO OUTPUT BUFFER AREA
5245 047104 012704 0C04C0    MOV     #256.,R4     ; GET BUFFER SIZE
5246 047110 010022          43$:  MOV     R0,(R2)+   ; WRITE NEXT WORD TO BUFFER
5247 047112 005304          DEC     R4           ; DECREMENT BUFFER SIZE COUNT
5248 047114 001375          BNE    43$         ; IF ZERO, GET OUT OF LOOP
5249 047116 011602          MOV     (SP),R2     ; CREATE LOOP COUNTER
5250 047120 012701 002364    MOV     #0BUFF,R1    ; WRITE OUTPUT BUFFER TO
5251 047124 004737 025276    45$:  CALL    BFTOMM     ; MAPPED MEMORY BUFFER
5252 047130 062703 001000    ADD     #512.,R3     ; INCREMENT OFFSET
5253 047134 005302          DEC     R2           ; DECREMENT LOOP COUNT
5254 047136 001372          BNE    45$         ; IF NOT ZERO, LOOP
5255 047140          POP     <R1,R3>      ; RESTORE REGISTERS
          047140 012601      MOV     (SP)+,R1    ; POP STACK INTO R1
          047142 012603      MOV     (SP)+,R3    ; POP STACK INTO R3
5256
5257 047144          50$:  POP     <R5,R4,R2,R0> ; REGISTERS
          047144 012605      MOV     (SP)+,R5    ; POP STACK INTO R5
          047146 012604      MOV     (SP)+,R4    ; POP STACK INTO R4
          047150 012602      MOV     (SP)+,R2    ; POP STACK INTO R2
          047152 012600      MOV     (SP)+,R0    ; POP STACK INTO R0
5258 047154 010337 002242    MOV     R3,TSTOFF   ; SAVE MEMORY OFFSET
5259 047160 000240          NOP                    ; [DBG] INSERT HALT FOR DEBUG
5260 047162 000207          RETURN
5261
    
```

```

5263
5264
5265      ;**
5266      ;      GTDRV - GET DRIVE TABLE POINTER
5267      ;
5268      ;      INPUTS:
5269      ;      R1 - DRIVE NUMBER
5270      ;      R5 - CONTROLLER TABLE ADDRESS
5271      ;
5272      ;      OUTPUTS:
5273      ;      R1 - DRIVE TABLE ADDRESS
5274      ;      L$LUN - LOADED WITH UNIT NUMBER OF DRIVE
5275      ;      CARRY CLEAR IF DRIVE TABLE NOT FOUND AFTER ERROR PRINTED
5276      ;--
5276 047164 010246      GTDRV: PUSH    <R2,R4>      ; SAVE CONTENTS OF REGISTERS
      047164 010446      MOV     R2,-(SP)      ; PUSH R2 ON STACK
      047166 010504      MOV     R4,-(SP)      ; PUSH R4 ON STACK
5277 047170 010504      MOV     R5,R4        ; GET CONTROLLER TABLE ADDRESS
5278 047172 062704 000016      ADD     @C.DRO,R4    ; ADD OFFSET TO DRIVE TABLE ADDRESS
5279 047176 012702 000004      MOV     #4,R2        ; GET COUNT OF DRIVES
5280 047202 005714      1$:   TST     (R4)      ; CHECK IF AN ADDRESS HERE
5281 047204 001406      BEQ     3$           ; IF NO ADDRESS, ERROR EXIT
5282 047206 027401 000000      CMP     @C(R4),R1    ; COMPARE DRIVE NUMBERS
5283 047212 001410      BEQ     4$           ; BRANCH IF A MATCH
5284 047214 005724      2$:   TST     (R4)+    ; BUMP ADDRESS
5285 047216 005302      DEC     R2           ; DECREMENT DRIVE COUNTER
5286 047220 001370      BNE     1$           ; LOOK AT NEXT TABLE
5287 047222      3$:   POP     <R4,R2>    ; RESTORE REGISTERS
      047222 012604      MOV     (SP)+,R4     ; POP STACK INTO R4
      047224 012602      MOV     (SP)+,R2     ; POP STACK INTO R2
5288 047226 000261      SEC           ; SET CARRY AS ERROR FLAG
5289 047230 000240      NOP
5290 047232 000207      RETURN      ; [DBG] INSERT HALT FOR DEBUG
5291
5292 047234 011401      4$:   MOV     (R4),R1     ; GET ADDRESS OF TABLE
5293 047236 116137 000002 002074      MOVB    D.UNIT(R1),L$LUN ; GET LOGICAL UNIT NUMBER
5294 047244      POP     <R4,R2>    ; RESTORE REGISTERS
      047244 012604      MOV     (SP)+,R4     ; POP STACK INTO R4
      047246 012602      MOV     (SP)+,R2     ; POP STACK INTO R2
5295 047250 000241      CLC           ; CLEAR CARRY FLAG
5296 047252 000240      NOP
5297 047254 000207      RETURN      ; [DBG] INSERT HALT FOR DEBUG
    
```

5299
 5300
 5301
 5302
 5303
 5304
 5305
 5306
 5307
 5308
 5309
 5310
 5311
 5312
 5313
 5314
 5315
 5316
 5317 047256
 047256 010046
 047260 010546
 5318 047262 010405
 5319 047264 012700 000060
 5320 047270 005004
 5321 047272 006301
 5322 047274 006102
 5323 047276 006103
 5324 047300 006104
 5325 047302 020504
 5326 047304 101002
 5327 047306 160504
 5328 047310 005201
 5329 047312 005300
 5330 047314 001366
 5331 047316
 047316 012605
 047320 012600
 5332 047322 000240
 5333 047324 000207

```

; **
;
; DIVIDE - DIVIDE A 48 BIT UNSIGNED NUMBER BY A 16 BIT NUMBER.
; REPLACE DIVIDEND WITH QUOTIENT AND RETURN REMAINDER.
; WILL NOT CHECK FOR DIVIDE BY ZERO.
;
; INPUTS:
; R1 - LOW 16 BITS OF DIVIDEND
; R2 - NEXT 16 BITS OF DIVIDEND
; R3 - HIGH 16 BITS OF DIVIDEND
; R4 - DIVISOR
;
; OUTPUTS:
; R1 - LOW 16 BITS OF QUOTIENT
; R2 - NEXT 16 BITS OF QUOTIENT
; R3 - HIGH 16 BITS OF QUOTIENT
; R4 - REMAINDER
;
; --
DIVIDE: PUSH <R0,R5> ; DIVIDEND IS IN <R3,R2,R1>
MOV R0,-(SP) ; PUSH R0 ON STACK
MOV R5,-(SP) ; PUSH R5 ON STACK
MOV R4,R5 ; SAVE DIVISOR
MOV #48,,R0 ; SET UP SHIFT COUNT
CLR R4 ; START WITH ZERO REMAINDER
1$: ASL R1 ;
ROL R2 ; SHIFT LEFT INTO REMAINDER
ROL R3 ;
ROL R4 ;
CMP R5,R4 ; WILL DIVISOR GO INTO REMAINDER?
BHI 2$ ; ONLY SUBTRACT IF IT WILL
SUB R5,R4 ; SUBTRACT DIVISOR
INC R1 ; PUT A ONE INTO QUOTIENT
2$: DEC R0 ; COUNT THE SHIFTS
BNE 1$ ;
POP <R5,R0> ; RESTORE SAVED REGISTERS
MOV (SP)+,R5 ; POP STACK INTO R5
MOV (SP)+,R0 ; POP STACK INTO R0
NOP ; [DBG] INSERT HALT FOR DEBUG
RETURN ;
    
```

```

5335
5336
5337      ;++
5338      ;
5339      ;
5340      ;
5341      ;
5342      ;
5343      ;
5344      ;
5345      ;
5346      ;
5347      ;
5348      ;
5349      ;
5350      ;
5351      ;
5352      ;
5353      ;
5354      ;--
5355      047326      010046      DIV48:  PUSH    <R0>          ; SAVE REGISTERS
5356      047330      010546      MOV     R0,-(SP)       ; PUSH R0 ON STACK
5357      047332      010446      PUSH   <R5,R4>        ; SAVE DIVISOR
5358      047334      012700      MOV     R5,-(SP)       ; PUSH R5 ON STACK
5359      047340      005004      MOV     R4,-(SP)       ; PUSH R4 ON STACK
5360      047342      005005      MOV     #48.,R0        ; SET UP SHIFT COUNT
5361      047344      006301      CLR     R4             ; START WITH
5362      047346      006102      CLR     R5             ; ZERO REMAINDER
5363      047348      006103      1$:   ASL     R1         ;
5364      047350      006104      ROL     R2             ; SHIFT LEFT INTO REMAINDER
5365      047352      006105      ROL     R3             ;
5366      047354      006106      ROL     R4             ;
5367      047356      026605      ROL     R5             ;
5368      047360      101010      CMP     2(SP),R5       ; IS
5369      047362      103402      BHI     10$           ; DIVISOR
5370      047364      021604      BLO     2$           ; LESS THAN
5371      047366      101005      CMP     (SP),R4       ; OR EQUAL TO
5372      047368      161604      BHI     10$           ; REMAINDER?
5373      047370      005605      SUB     (SP),R4       ; IF SO,
5374      047372      166605      SBC     R5             ; SUBTRACT DIVISOR
5375      047374      005201      SUB     2(SP),R5     ; FROM REMAINDER
5376      047376      005300      INC     R1             ; & INCREMENT QUOTIENT
5377      047378      001356      DEC     R0             ; COUNT THE SHIFTS
5378      047380      022626      BNE     1$           ;
5379      047382      012600      CMP     (SP)+,(SP)+  ; THROW OUT SAVED DIVISOR
5379      047384      000240      POP     <R0>          ; RESTORE SAVED REGISTERS
5379      047386      000207      MOV     (SP)+,R0     ; POP STACK INTO R0
5379      047388      000207      NOP                    ; [DBG] INSERT HALT FOR DEBUG
5379      047390      000207      RETURN                ;
    
```

```

5381
5382
5383      ;**
5384      ;
5385      ;
5386      ;
5387      ;
5388      ;
5389      ;
5390      ;
5391      ;
5392      ;
5393      ;
5394      ;
5395      ;
5396      ;--
5397      047420 010046 MULT:  PUSH  <R0,R1,R2>      ; SAVE REGISTERS
          047421 010146      MOV   R0,-(SP)      ; PUSH R0 ON STACK
          047422 010146      MOV   R1,-(SP)      ; PUSH R1 ON STACK
          047423 010246      MOV   R2,-(SP)      ; PUSH R2 ON STACK
5398      047426 005000      CLR   R0           ;
5399      047430 005003      CLR   R3           ; CLEAR
5400      047432 005004      CLR   R4           ; PRODUCT
5401      047434 000241      1$:  CLC           ;
5402      047436 006001      ROR   R1           ; SHIFT MULTIPLIER TO RIGHT
5403      047440 103003      BCC  2$           ; IF A ONE BIT SHIFTED OUT
5404      047442 060203      ADD  R2,R3       ; ADD MULTIPLICAND
5405      047444 005504      ADC  R4          ; TO PRODUCT
5406      047446 060004      ADD  R0,R4       ;
5407      047450 006302      2$:  ASL  R2       ; DOUBLE THE
5408      047452 006100      ROL  R0          ; MULTIPLICAND
5409      047454 005701      TST  R1          ;
5410      047456 001366      BNE  1$         ; CONTINUE UNTIL MULTIPLIER IS ZERO
5411      047460 012602      POP  <R2,R1,R0>  ; RESTORE REGISTERS
          047461 012601      MOV  (SP)+,R2   ; POP STACK INTO R2
          047462 012601      MOV  (SP)+,R1   ; POP STACK INTO R1
          047463 012600      MOV  (SP)+,R0   ; POP STACK INTO R0
5412      047466 000240      NOP
5413      047470 000207      RETURN          ; [DBG] INSERT HALT FOR DEBUG
5414
    
```

```

5416
5417
5418
5419
5420
5421
5422
5423
5424
5425
5426
5427
5428
5429
5430
5431
5432 047472 010046
      047472 010446
      047474 010446
5433 047476 012700 002212
5434 047502 112720 000060
5435 047506 005304
5436 047510 001374
5437 047512 105010
5438 047514 012704 000012
5439 047520 004737 047256
5440 047524 062704 000060
5441 047530 110440
5442 047532 010146
5443 047534 050216
5444 047536 050326
5445 047540 001365
5446 047542 012604
      047542 012600
      047544 012600
5447 047546 000240
5448 047550 000207
5449

; **
; ITOA - CONVERT A 48 BIT OR SMALLER BINARY NUMBER INTO A DECIMAL
; ASCII STRING.
;
; INPUTS:
; R1 - LOW 16 BITS OF NUMBER
; R2 - NEXT 16 BITS OF NUMBER
; R3 - HIGH 16 BITS OF NUMBER
; R4 - CHARACTER COUNT
;
; OUTPUTS:
; TEMP - FIRST CHARACTER IN A ASCII OUTPUT STRING
; R1,R2,R3 - DESTROYED
; --
ITOA:  PUSH <R0,R4>           ; SAVE REGISTERS
      MOV R0,-(SP)         ; PUSH R0 ON STACK
      MOV R4,-(SP)         ; PUSH R4 ON STACK
      MOV #TEMP,R0        ; GET POINTER TO STRING
1$:    MOVB #'0,(R0)+      ; FILL ENTIRE
      DEC R4              ; STRING WITH
      BNE 1$              ; SPACES
      CLRB (R0)           ; TERMINATE STRING
2$:    MOV #10,R4         ; GET DIVISOR
      CALL DIVIDE         ; DIVIDE NUMBER BY 10
      ADD #'0,R4          ; CONVERT REMAINDER TO ASCII
      MOVB R4,-(R0)       ; STORE CHARACTER IN STRING
      MOV R1,-(SP)        ; CHECK
      BIS R2,(SP)         ; IF QUOTIENT
      BIS R3,(SP)+       ; IS ZERO
      BNE 2$             ; IF NOT, GET NEXT CHARACTER
      POP <R4,R0>        ; RESTORE SAVED REGISTERS
      MOV (SP)+,R4        ; POP STACK INTO R4
      MOV (SP)+,R0        ; POP STACK INTO R0
      NOP                 ; [DBG] INSERT HALT FOR DEBUG
      RETURN
    
```


5451
5452
5453
5454
5455
5456
5457
5458
5459
5460
5461

5462
5463
5464
5465
5466
5467

5468
5469

047552 010146
047552 010246
047554 010346
047556 010446
047560 011401
047562 016402 000002
047564 005003
047570 000012
047572 047472
047602 012604
047602 012603
047604 012602
047606 012601
047610 000240
047612 000207
047614

```

:++
:      BLDSTR - CONVERT 32 BIT NUMBER TO 10 CHARACTER ASCIZ STRING
:
:      INPUT:
:            R4 - POINTER TO 2 WORD DEFAULT NUMBER
:
:      OUTPUT:
:            TEMP - ASCIZ STRING REPRESENTING DEFAULT NUMBER
:--

BLDSTR: PUSH    <R1,R2,R3,R4>      ; SAVE REGISTERS
        MOV     R1,-(SP)          ; PUSH R1 ON STACK
        MOV     R2,-(SP)          ; PUSH R2 ON STACK
        MOV     R3,-(SP)          ; PUSH R3 ON STACK
        MOV     R4,-(SP)          ; PUSH R4 ON STACK
        MOV     (R4),R1           ; GET LOW WORD OF NUMBER
        MOV     2(R4),R2          ; GET NEXT WORD OF NUMBER
        CLR     R3                ; CLEAR HIGH WORD
        MOV     #10,R4           ; GET CHARACTER COUNT
        CALL    ITOA             ; CONVERT INTEGER TO ASCII
        POP     <R4,R3,R2,R1>     ; RESTORE SAVED REGISTERS
        MOV     (SP)+,R4          ; POP STACK INTO R4
        MOV     (SP)+,R3          ; POP STACK INTO R3
        MOV     (SP)+,R2          ; POP STACK INTO R2
        MOV     (SP)+,R1          ; POP STACK INTO R1
NOP      ; [DBG] INSERT HALT FOR DEBUG
        RETURN

```



```

047740 104417
047742 062706 000004
5517 047746 000261
5518 047750 000415
5519
5520 047752          20$: PRINTF #INP28B          ; PRINT ILLEGAL CHARACTER
    047752 012746 065054 MOV #INP28B, -(SP)
    047756 012746 000001 MOV #1, -(SP)
    047762 010600 MOV SP, R0
    047764 104417 TRAP C$PNTF
    047766 062706 000004 ADD #4, SP
5521 047772 000261
5522 047774 000403
5523
5524 047776 010024          30$: MOV R0, (R4)+          ; MOVE NUMBER TO STORAGE AREA
5525 050000 010124 MOV R1, (R4)+          ;
5526 050002 000241          CLC          ; CLEAR CARRY TO INDICATE ALL IS WELL
5527 050004          40$: POP <R3,R2,R1,R0>          ; RESTORE SAVED REGISTERS
5528 050014 000240 NOP          ; [DBG] INSERT HALT FOR DEBUG
5529 050016 000207 RETURN
    
```

```

5531
5532      ;++
5533      :
5534      : AVAIL - SEND MSCP AVAILABLE COMMAND PACKET
5535      : THIS COMMAND WILL CAUSE A DISK TO STOP SPINNING AND TO UNLOAD
5536      : ITS HEADS.
5537      :
5538      : INPUTS:
5539      :         R0 - POINTER TO DRIVE TABLE
5540      :         R3 - COMMAND MODIFIERS
5541      :         R5 - ADDRESS OF CONTROLLER TABLE
5542      :
5543      : OUTPUTS:
5544      :         R4 - UNIT NUMBER
5545      :         "TO BE SENT" LIST CONTAINS COMMAND PACKET
5546      :
5547      :--
5548 050020 011004 AVAIL: MOV      (R0),R4          ; GET DRIVE UNIT NUMBER
5549 050022 042760      BIC      #DT.ONL,D.UNIT(R0) ; CLEAR UNIT ONLINE FLAG
5550 050030 012737 001000 000002      MOV      #OP.AVL,TSTOPC ; SAVE OPCODE
5551 050036 004737 051214      CALL    BLDME          ; BUILD MESSAGE ENVELOPE
5552 050042 103403      BCS     1$             ; IF SET, NO BUFFER AVAILABLE
5553 050044 012764 000014 000022      MOV      #12.,ME.CL(R4) ; LENGTHS
5554 050052      1$:
5555 050052 000240      NOP
5556 050054 000207      RETURN
5557
5558      ;++
5559      : GCSTAT - SEND MSCP GET COMMAND STATUS COMMAND
5560      :
5561      : THIS COMMAND WILL CAUSE THE CONTROLLER TO RETURN STATUS ON THE
5562      : SPECIFIED MSCP COMMAND
5563      :
5564      : INPUTS:
5565      :         R1 - COMMAND REFERENCE NUMBER OF OUTSTANDING COMMAND
5566      :         R5 - ADDRESS OF CONTROLLER TABLE
5567      :
5568      : OUTPUTS:
5569      :         R3 - CLEARED (NO COMMAND MODIFIERS)
5570      :         R4 - CLEARED (NO UNIT SPECIFIED)
5571      :         "TO BE SENT" LIST CONTAINS COMMAND PACKET
5572      :
5573      :--
5574 050056 005003 GCSTAT: CLR      R3          ; NO MODIFIERS ALLOWED
5575 050060 005004      CLR      R4          ; UNIT MUST BE ZERO
5576 050062 012737 000002 002244      MOV      #OP.GCS,TSTOPC ; SAVE OPCODE
5577 050070 004737 051214      CALL    BLDME          ; BUILD MESSAGE ENVELOPE
5578 050074 103405      BCS     1$             ; IF SET, NO BUFFER AVAILABLE
5579 050076 010164 000042      MOV      R1,P.OTRF+ME.CP(R4) ; SET OUTSTANDING REF #
5580 050102 012764 000020 000022      MOV      #16.,ME.CL(R4) ;
5581 050110      1$:
5582 050110 000240      NOP
5583 050112 000207      RETURN
5584
5585      ;++

```

```

5586      ;      GUSTAT - SEND MSCP GET UNIT STATUS COMMAND
5587      ;
5588      ;      THIS COMMAND WILL CAUSE THE CONTROLLER TO RETURN UNIT STATUS ON THE
5589      ;      SPECIFIED UNIT
5590      ;
5591      ;      INPUTS:
5592      ;      R5 - ADDRESS OF CONTROLLER TABLE
5593      ;
5594      ;      OUTPUTS:
5595      ;      "TO BE SENT" LIST CONTAINS COMMAND PACKET
5596      ;--
5597
5598 050114 012703 000001      GUSTAT: MOV      #MD.NXU,R3      ; GET NEXT UNIT STATUS
5599 050120 005004              CLR      R4              ; SET UNIT TO ZERO
5600 050122 012737 000003 002244  MOV      #OP.GUS,TSTOPC  ; SAVE OPCODE
5601 050130 004737 051214      CALL     BLDME           ; BUILD MESSAGE ENVELOPE
5602 050134 103403              BCS     1$              ; IF SET, NO BUFFER AVAILABLE
5603 050136 012764 000014 000022  MOV      #12.,ME.CL(R4)  ; SET COMMAND PACKET LENGTH
5604 050144              1$:
5605 050144 000240      NOP              ; [DBG] INSERT HALT FOR DEBUG
5606 050146 000207      RETURN              ;
5607
5608      ;++
5609      ;      ONLINE - SEND MSCP ONLINE COMMAND
5610      ;
5611      ;      THIS COMMAND WILL CAUSE THE CONTROLLER TO SET THE SPECIFIED DRIVE
5612      ;      ONLINE AND RETURN DRIVE STATUS INFORMATION.
5613      ;
5614      ;      INPUTS:
5615      ;      R0 - POINTER TO DRIVE TABLE
5616      ;      R1 - UNIT FLAGS
5617      ;      R5 - ADDRESS OF CONTROLLER TABLE
5618      ;
5619      ;      OUTPUTS:
5620      ;      R3 - "SET WRITE PROTECT" CAMMAND MODIFIER SET
5621      ;      R4 - DRIVE UNIT NUMBER
5622      ;      "TO BE SENT" LIST CONTAINS COMMAND PACKET
5623      ;--
5624
5625 050150 012703 000004      ONLINE: MOV      #<MD.SWP>,R3  ; SET COMMAND MODIFIERS
5626 050154 011004              MOV      (R0),R4        ; GET DRIVE UNIT NUMBER
5627 050156 012737 000011 002244  MOV      #OP.ONL,TSTOPC  ; SAVE OPCODE
5628 050164 004737 051214      CALL     BLDME           ; BUILD MESSAGE ENVELOPE
5629 050170 103405              BCS     1$              ; IF SET, NO BUFFER AVAILABLE
5630 050172 010164 000044      MOV      R1,P.UNFL+ME.CP(R4) ; SET THE UNIT FLAGS
5631 050176 012764 000044 000022  MOV      #36.,ME.CL(R4)  ; SET COMMAND PACKET LENGTH
5632 050204              1$:
5633 050204 000240      NOP              ; [DBG] INSERT HALT FOR DEBUG
5634 050206 000207      RETURN              ;
5635
5636      ;++
5637      ;      SCC - SEND MSCP SET CONTROLLER CHARACTERISTICS COMMAND
5638      ;
5639      ;      THIS COMMAND WILL SET THE SPECIFIED CHARACTERISTICS OF THE
5640      ;      CONTROLLER

```

```

5641      :
5642      :
5643      :
5644      :
5645      :
5646      :
5647      :
5648      :
5649      :
5650      :--
5651      :
5652      :
5653      :
5654      :
5655      :
5656      :
5657      :
5658      :
5659      :
5660      :
5661      :
5662      :
5663      :++
5664      :
5665      :
5666      :
5667      :
5668      :
5669      :
5670      :
5671      :
5672      :
5673      :
5674      :
5675      :
5676      :
5677      :
5678      :--
5679      :
5680      :
5681      :
5682      :
5683      :
5684      :
5685      :
5686      :
5687      :
5688      :
5689      :

```

```

INPUTS:
R1 - CONTROLLER FLAGS
R5 - ADDRESS OF CONTROLLER TABLE

OUTPUTS:
R3 - CLEARED (NO COMMAND MODIFIERS)
R4 - CLEARED (NO UNIT SPECIFIED)
"TO BE SENT" LIST CONTAINS COMMAND PACKET

SCC:
CLR R3 ; NO MODIFIERS ALLOWED
CLR R4 ; UNIT MUST BE ZERO
MOV #OP.SCC,TSTOPC ; SAVE OPCODE
CALL BLDME ; BUILD MESSAGE ENVELOPE
BCS 1$ ; IF SET, NO BUFFER AVAILABLE
MOV R1,P.CNTF+ME.CP(R4) ; SET THE CONTROLLER FLAGS
MOV #32.,ME.CL(R4) ; SET UP COMMAND PACKET LENGTH

1$:
NOP ; [DBG] INSERT HALT FOR DEBUG
RETURN ;

SUCHAR - SEND MSCP SET UNIT CHARACTERISTICS COMMAND
THIS COMMAND WILL CAUSE THE CONTROLLER TO SET THE APPROPRIATE
CHARACTERISTICS IN THE SPECIFIED DRIVE.

INPUTS:
R0 - POINTER TO DRIVE TABLE
R1 - UNIT FLAGS
R5 - ADDRESS OF CONTROLLER TABLE

OUTPUTS:
R3 - "SET WRITE PROTECT" CAMMAND MODIFIER SET
R4 - DRIVE UNIT NUMBER
"TO BE SENT" LIST CONTAINS COMMAND PACKET

SUCHAR:
MOV #<MD.SWP>,R3 ; SET COMMAND MODIFIERS
MOV (R0),R4 ; GET DRIVE UNIT NUMBER
MOV #OP.SUC,TSTOPC ; SAVE OPCODE
CALL BLDME ; BUILD MESSAGE ENVELOPE
BCS 1$ ; IF SET, NO BUFFER AVAILABLE
MOV R1,P.UNFL+ME.CP(R4) ; SET THE UNIT FLAGS
MOV #36.,ME.CL(R4) ; SET COMMAND PACKET LENGTH

1$:
NOP ; [DBG] INSERT HALT FOR DEBUG
RETURN ;

```

```

5691
5692      ;++
5693      ; ACCESS - SEND MSCP ACCESS COMMAND PACKET
5694      ;
5695      ; THIS COMMAND WILL CAUSE THE CONTROLLER TO READ DATA FROM A DRIVE,
5696      ; CHECK FOR ERRORS AND DISCARD THE DATA.
5697      ; THIS ROUTINE SETS THE OPCODE AND TRANSFERS CONTROL TO XFERPK TO
5698      ; BUILD THE TRANSFER COMMAND PACKET.
5699      ;
5700      ; INPUTS:
5701      ; R0 - POINTER TO DRIVE TABLE
5702      ; R5 - ADDRESS OF CONTROLLER TABLE
5703      ;
5704      ; OUTPUTS:
5705      ; R3 - COMMAND MODIFIERS
5706      ; R4 - UNIT NUMBER
5707      ; BUFBA,BUFEA - BUFFER DESCRIPTOR CLEARED
5708      ;--
5709 050306 005037 004370      ACCESS: CLR      BUFBA      ; CLEAR BUFFER
5710 050312 005037 004372      CLR      BUFEA      ; DESCRIPTOR
5711 050316 005003              CLR      R3          ; SET COMMAND MODIFIERS
5712 050320 011004              MOV      (R0),R4     ; GET DRIVE UNIT NUMBER
5713 050322 012737 000020 002244  MOV      #OP.ACC,TSTOPC ; SAVE OPCODE
5714 050330 022737 000003 002206  CMP      #3,TNUM     ; IF NOT TEST 3
5715 050336 001006              BNE      2$         ; ALWAYS DO ECC
5716 050340 032737 000100 002154  BIT      #SM.ECC,SO.BIT+SFPTBL ; ENABLE
5717 050346 001002              BNE      2$         ; ECC?
5718 050350 052703 000100              BIS      #MD.SEC,R3  ; NO!
5719 050354 000137 050744      2$: JMP      XFERPK     ; BUILD TRANSFER PACKET
5720
5721      ;++
5722      ; CMPHD - SEND MSCP COMPARE HOST DATA COMMAND PACKET
5723      ;
5724      ; THIS COMMAND WILL CAUSE THE CONTROLLER TO COMPARE THE DATA WRITTEN
5725      ; TO A DISK TO DATA IN A HOST MEMORY BUFFER.
5726      ; THIS ROUTINE REUSES THE MESSAGE ENVELOPE FROM A PREVIOUS
5727      ; WRITE OPERATION.
5728      ;
5729      ; INPUTS:
5730      ; R1 - DRIVE TABLE ADDRESS
5731      ; C.RHDR(R5) - POINTER TO RESPONSE PACKET
5732      ; R5 - ADDRESS OF CONTROLLER TABLE
5733      ;
5734      ; OUTPUTS:
5735      ; MESSAGE ENVELOPE HAS BEEN ADDED TO THE TOP OF THE TBS LIST.
5736      ; RESPONSE RING HAS BEEN CLEARED.
5737      ;--
5738 050360 005261 000060      CMPHD: INC      D.CCNT(R1) ; "COMPARE HOST DATA" OUTSTANDING COUNT
5739 050364 042761 004000 000002  BIC      #DT.CMP,D.UNIT(R1) ; CLEAR "COMPARE HOST DATA" PENDING
5740 050372 016504 000104              MOV      C.RHDR(R5),R4 ; GET OLD COMMAND PACKET
5741 050376 016401 000006              MOV      P.CRF+RE.RP(R4),R1 ; MESSAGE
5742 050402 004737 025550              CALL     GETME        ; ENVELOPE
5743 050406 016401 000002              MOV      ME.CBL(R4),R1 ; REMOVE
5744 050412 001004              BNE      10$         ; MESSAGE
5745 050414 016465 000000 000160  MOV      ME.CFL(R4),C.CMFL(R5) ; ENVELOPE

```

```

5746 050422 000403          BR      11$
5747 050424 016461 000000 000000 10$: MOV  ME.CFL(R4),ME.CFL(R1) ;
5748 050432 016401 000000          11$: MOV  ME.CFL(R4),R1 ;
5749 050436 001404          BEQ  13$
5750 050440 016461 000002 000002          MOV  ME.CBL(R4),ME.CBL(R1) ;
5751 050446 000403          BR      14$
5752 050450 016465 000002 000162 13$: MOV  ME.CBL(R4),C.CMBL(R5) ;
5753 050456 016564 000164 000000 14$: MOV  C.TBSF(R5),ME.CFL(R4) ;
5754 050464 010465 000164          MOV  R4,C.TBSF(R5) ;
5755 050470 005064 000002          CLR  ME.CBL(R4) ;
5756 050474 016401 000000          MOV  ME.CFL(R4),R1 ;
5757 050500 001403          BEQ  15$
5758 050502 010461 000002          MOV  R4,ME.CBL(R1) ;
5759 050506 000402          BR      20$
5760 050510 010465 000166          15$: MOV  R4,C.TBSB(R5) ;
5761
5762 050514 012764 000040 000036 20$: MOV  #OP.CMP,P.OPCD+ME.CP(R4); SET OPCODE
5763 050522 005064 000016          CLR  ME.CFG(R4) ; CLEAR M.E. FLAG FIELD
5764 050526 000240          NOP ; [DBG] INSERT HALT FOR DEBUG
5765 050530 000207          RETURN ;
5766
5767
5768
5769
5770
5771
5772
5773
5774
5775
5776
5777
5778
5779
5780
5781
5782
5783
5784

```

FROM
 COMMAND
 LIST

ADD
 MESSAGE
 ENVELOPE
 TO
 TOP
 OF
 TBS
 LIST

ERASE - SEND MSCP ERASE COMMAND PACKET

THIS COMMAND WILL CAUSE THE CONTROLLER TO ERASE DATA FROM THE
 SELECTED LBNS ON A DREIVE. THE PATTERN WRITTEN IS THE SAME AS
 THE DEFAULT FOR PATTERN 0.
 THIS ROUTINE SETS THE OPCODE AND TRANSFERS CONTROL TO XFERPK TO
 BUILD THE TRANSFER COMMAND PACKET.

INPUTS:
 R0 - POINTER TO DRIVE TABLE
 R5 - ADDRESS OF CONTROLLER TABLE

OUTPUTS:
 R3 - COMMAND MODIFIERS
 R4 - UNIT NUMBER
 BUFBA,BUFEA - BUFFER DESCRIPTOR CLEARED

```

5785 050532 005037 004370 ERASE: CLR  BUFBA ; CLEAR BUFFER
5786 050536 005037 004372 CLR  BUFEA ; DESCRIPTOR
5787 050542 005003 CLR  R3 ; SET COMMAND MODIFIERS
5788 050544 011004 MOV  (R0),R4 ; GET DRIVE UNIT NUMBER
5789 050546 012737 000022 002244 MOV  #OP.ERS,TSTOPC ; SAVE OPCODE
5790 050554 000473 BR      XFERPK ; BUILD TRANSFER PACKET
5791
5792
5793
5794
5795
5796
5797
5798
5799
5800

```

READ - SEND MSCP READ COMMAND

THIS COMMAND WILL CAUSE THE CONTROLLER TO READ DATA FROM A DRIVE
 INTO HOST MEMORY AND CHECK FOR ERRORS.
 THIS ROUTINE SETS THE OPCODE AND TRANSFERS CONTROL TO XFERPK TO
 BUILD THE TRANSFER COMMAND PACKET.

INPUTS:


```

5801      ;
5802      ;
5803      ;
5804      ;
5805      ;
5806      ;
5807      ;
5808 050556 005003      READ:  CLR      R3      ; SET COMMAND MODIFIERS
5809 050560 011004      MOV      (R0),R4    ; GET DRIVE UNIT NUMBER
5810 050562 012737 000041 002244  MOV      #OP.RD,TSTOPC ; SAVE OPCODE
5811 050570 022737 000003 002206  CMP      #3,TNUM      ; IF NOT TEST 3,
5812 050576 001403      BEQ      2$          ; ALWAYS DO
5813 050600 052703 040000      BIS      #MD.CMP,R3    ; ECC AND
5814 050604 000417      BR       10$         ; DATA COMPARE
5815
5816 050606 012701 000003      2$:  MOV      #3.,R1      ; DO DATA
5817 050612 005002      CLR      R2          ; COMPARES?
5818 050614 004737 026250      CALL     RANDOM      ;
5819 050620 005701      TST     R1          ;
5820 050622 001002      BNE     5$          ;
5821 050624 052703 040000      BIS      #MD.CMP,R3    ;
5822 050630 032737 000100 002154  5$:  BIT      #SM.ECC,S0.BIT+SFPTBL ; ENABLE
5823 050636 001002      BNE     10$         ; ECC?
5824 050640 052703 000100      BIS      #MD.SEC,R3    ; NO!
5825 050644 000437      BR       10$         ; BUILD THE TRANSFER PACKET
5826
5827      ;
5828      ;
5829      ;
5830      ;
5831      ;
5832      ;
5833      ;
5834      ;
5835      ;
5836      ;
5837      ;
5838      ;
5839      ;
5840      ;
5841      ;
5842 050646 005003      WRITE: CLR      R3      ; SET COMMAND MODIFIERS
5843 050650 011004      MOV      (R0),R4    ; GET DRIVE UNIT NUMBER
5844 050652 012737 000042 002244  MOV      #OP.WR,TSTOPC ; SAVE OPCODE
5845 050660 022737 000003 002206  CMP      #3,TNUM      ; IF NOT TEST 3,
5846 050666 001403      BEQ      2$          ; ALWAYS DO
5847 050670 052703 040000      BIS      #MD.CMP,R3    ; ECC AND
5848 050674 000423      BR       10$         ; DATA COMPARE
5849
5850 050676 032765 002000 000014  2$:  BIT      #CT.DET,C.FLG(R5) ; IF DETERMINISTIC PHASE
5851 050704 001017      BNE     10$         ; DON'T DO DATA COMPARES
5852 050706 012701 000003      MOV      #3.,R1      ; DO
5853 050712 005002      CLR      R2          ; DATA
5854 050714 004737 026250      CALL     RANDOM      ; COMPARES?
5855 050720 005701      TST     R1          ;
    
```

```

5856 050722 001002          BNE      4$          ;
5857 050724 052703 040000  BIS      #MD.CMP,R3    ;
5858 050730 032737 000100 002154 4$:  BIT      #SM.ECC,SO.BIT+SFPTBL ; ENABLE
5859 050736 001002          BNE      10$         ; ECC?
5860 050740 052703 000100 10$:  BIS      #MD.SEC,R3    ; NO!
5861 050744          ;
5862          ;
5863          ;++
5864          ; XFERPK - BUILD TRANSFER COMMAND PACKET
5865          ; THIS ROUTINE BUILDS A TRANSFER COMMAND PACKET.
5866          ;
5867          ; INPUTS:
5868          ; BUFEA - BUFFER DESCRIPTOR (LOW WORD)
5869          ; BUFBA - BUFFER DESCRIPTOR (HIGH WORD)
5870          ; BCLO - BYTE COUNT (LOW WORD)
5871          ; BCHI - BYTE COUNT (HIGH WORD)
5872          ; TSTOPC - OPCODE
5873          ; R3 - COMMAND MODIFIERS
5874          ; R4 - UNIT NUMBER
5875          ; R5 - ADDRESS OF CONTROLLER TABLE
5876          ;
5877          ; OUTPUTS:
5878          ; "TO BE SENT" LIST CONTAINS COMMAND PACKET
5879          ;
5880          ;--
5881          ;
5882 050744 004737 051214  XFERPK: CALL    BLDME      ; BUILD MESSAGE ENVELOPE
5883 050750 103456          BCS      20$         ; IF SET, NO BUFFER AVAILABLE
5884 050752 022737 000042 002244  CMP      #OP.WR,TSTOPC ; IF COMMAND
5885 050750 001404          BEQ      1$           ; IS WRITE OR ERASE,
5886 050762 022737 000022 002244  CMP      #OP.ERS,TSTOPC ; INCREMENT
5887 050770 001002          BNE      2$           ; OUTSTANDING
5888 050772 005260 000056 1$:  INC      D.WCNT(R0)   ; WRITE COUNT
5889 050776 022737 000003 002206 2$:  CMP      #3,TNUM      ; IF NOT TEST 3,
5890 051004 001012          BNE      10$         ; ALWAYS DO ERROR RECOVERY
5891 051006 032765 002000 000014  BIT      #CT.DET,C.FLG(R5) ; IF DETERMINISTIC PHASE,
5892 051014 001006          BNE      10$         ; DO ERROR RECOVERY
5893 051016 032737 000040 002154  BIT      #SM.EER,SO.BIT+SFPTBL ; DO
5894 051024 001002          BNE      10$         ; ERROR RECOVERY?
5895 051026 052703 000400          BIS      #MD.SER,R3    ; NO!
5896 051032 012764 000040 000022 10$:  MOV      #32,ME.CL(R4) ; SET COMMAND PACKET LENGTH
5897 051040 013764 004406 000042  MOV      BCLO,P.BCNT+ME.CP(R4) ; STORE THE BUFFER SIZE IN WORDS
5898 051046 013764 004410 000044  MOV      BCHI,P.BCNT+2*ME.CP(R4) ; SET READ BUFFER SIZE
5899 051054 013764 004372 000050  MOV      BUFEA,P.ADEA+ME.CP(R4) ; SET THE BUFFER DESCRIPTOR
5900 051062 013764 004370 000046  MOV      BUFBA,P.ADBA+ME.CP(R4) ;
5901 051070 016064 000052 000062  MOV      D.LBN(R0),P.LBN+ME.CP(R4) ; SET LBN (LOW WORD)
5902 051076 016064 000054 000064  MOV      D.LBN+2(R0),P.LBN+2*ME.CP(R4) ; SET LBN (HIGH WORD)
5903 051104 000241          CLC          ; CLEAR CARRY TO INDICATE SUCCESS
5904 051106          20$:  NOP
5905 051106 000240          ; [DBG] INSERT HALT FOR DEBUG
5906 051110 000207          RETURN      ;
5907          ;
5908          ;++
5909          ;
5910          ; MNTRD - SEND UQSSP MAINTENANCE READ COMMAND
    
```

```

5911 : THIS COMMAND WILL CAUSE DATA TO BE READ FROM THE SPECIFIED
5912 : LOCATIONS IN CONTROLLER MEMORY.
5913 : THIS ROUTINE SETS THE OPCODE AND TRANSFERS CONTROL TO MAINTP TO
5914 : BUILD THE MAINTENANCE COMMAND PACKET.
5915 :--
5916 :
5917 051112 012737 000030 002244 MNTRD: MOV #OP.MRD,TSTOPC ; SAVE OPCODE
5918 051120 000403 BR MAINTP ; BUILD THE TRANSFER PACKET
5919 :
5920 :++
5921 : MNTWR - SEND UQSSP MAINTENANCE WRITE COMMAND
5922 :
5923 : THIS COMMAND WILL CAUSE A BUFFER OF HOST DATA TO BE WRITTEN TO
5924 : THE SPECIFIED LOCATIONS IN CONTROLLER MEMORY.
5925 : THIS ROUTINE SETS THE OPCODE AND TRANSFERS CONTROL TO MAINTP TO
5926 : BUILD THE MAINTENANCE COMMAND PACKET.
5927 :--
5928 :
5929 051122 012737 000031 002244 MNTWR: MOV #OP.MWR,TSTOPC ; SAVE OPCODE
5930 :
5931 :++
5932 : MAINTP - BUILD MAINTENANCE COMMAND PACKET
5933 :
5934 : THIS ROUTINE BUILDS A MAINTENANCE COMMAND PACKET.
5935 :
5936 : INPUTS:
5937 : BUFEA - BUFFER DESCRIPTOR (LOW WORD)
5938 : BCLO - BYTE COUNT
5939 : R1 - REGION OFFSET
5940 : R3 - COMMAND MODIFIERS
5941 : R4 - UNIT NUMBER
5942 : R5 - ADDRESS OF CONTROLLER TABLE
5943 :
5944 : OUTPUTS:
5945 : "TO BE SENT" LIST CONTAINS COMMAND PACKET
5946 :--
5947 :
5948 051130 005003 MAINTP: CLR R3 ; COMMAND MODIFIERS NOT ALLOWED
5949 051132 004737 051214 CALL BLDME ; BUILD MESSAGE ENVELOPE
5950 051136 103424 BCS 1$ ; IF SET, NO BUFFER AVAILABLE
5951 051140 012764 000044 000022 MOV #36,ME.CL(R4) ; SET COMMAND PACKET LENGTH
5952 051146 013764 004406 000042 MOV BCLO,P.BCNT+ME.CP(R4) ; STORE THE BUFFER SIZE IN BYTES
5953 051154 013764 004372 000050 MOV BUFEA,P.ADEA+ME.CP(R4) ; SET THE BUFFER DESCRIPTOR
5954 051162 013764 004370 000046 MOV BUFBA,P.ADBA+ME.CP(R4) ;
5955 051170 012764 000001 000062 MOV #1,P.RGID+ME.CP(R4) ; SET REGION ID (HIGH WORD 0)
5956 051176 010164 000066 MOV R1,P.RGOF+ME.CP(R4) ; SET REGION OFFSET (HIGH WORD 0)
5957 051202 012764 177760 000024 MOV #MAINT,ME.CV(R4) ; CIRCUIT ID = 17740C FOR MAINTENANCE
5958 051210 1$:
5959 051210 000240 NOP ; [DBG] INSERT HALT FOR DEBUG
5960 051212 000207 RETURN ;

```

```

5962
5963
5964
5965
5966
5967
5968
5969
5970
5971
5972
5973
5974
5975
5976
5977
5978
5979
5980
5981 051214
5982 051216 005737 006236
5983 051222 001526
5984 051224 032737 000070 002244
5985 051232 001404
5986 051234 023737 002202 006236
5987 051242 002116
5988 051244
5989 051246 013704 006242
5990 051252 016400 000000
5991 051256 010037 006242
5992 051262 005060 000002
5993 051266 005337 006236
5994
5995 051272 032737 000070 002244
5996 051300 001414
5997 051302 016500 000166
5998 051306 001425
5999 051310 010460 000000
6000 051314 010064 000002
6001 051320 005064 000000
6002 051324 010465 000166
6003 051330 000424
6004
6005 051332 016500 000164
6006 051336 001411
6007 051340 010460 000002
6008 051344 010064 000000
6009 051350 005064 000002
6010 051354 010465 000164
6011 051360 000410
6012
6013 051362 005064 000000
6014 051366 005064 000002
6015 051372 010465 000164
6016 051376 010465 000166

:++
BLDME - BUILD MESSAGE ENVELOPE AND DATA STRUCTURES FOR COMMAND
PACKET
:
:
INPUTS:
:
R3 - COMMAND MODIFIERS
R4 - UNIT NUMBER
R5 - ADDRESS OF CONTROLLER TABLE
TSTOPC - OPCODE
:
OUTPUT:
:
COMMAND AND RESPONSE PACKETS HAVE BEEN CLEARED
COMMAND PACKET CONTAINS UNIT NUMBER, COMMAND REFERENCE
NUMBER, OPCODE, AND COMMAND MODIFIERS
R4 - ADDRESS OF COMMAND PACKET BUFFER
CARRY CLEAR ON SUCCESS
CARRY SET ON ERROR (NO BUFFERS AVAILABLE)
:--

BLDME: PUSH <R0> ; SAVE REGISTERS
TST TBSSIZ ; IF NO PACKETS LEFT,
BEQ 10$ ; EXIT
BIT #70,TSTOPC ; IF IMMEDIATE COMMAND
BEQ 1$ ; BUILD IT
CMP CTRLRS,TBSSIZ ; ALWAYS SAVE 1 PACKET
BGE 10$ ; PER CONTROLLER FOR IMMED. CMD
1$: PUSH <R4> ; SAVE COMMAND UNIT NUMBER
MOV T.HDR,R4 ; R4 POINTS TO PACKET
MOV ME.CFL(R4),R0 ; GET POINTER TO NEXT PACKET
MOV R0,T.HDR ; HEADER POINTS TO NEXT PACKET
CLR ME.CBL(R0) ; FIX BACK LINK OF NEXT PACKET
DEC TBSSIZ ; DECREMENT AVAILABLE COUNT

BIT #70,TSTOPC ; IF IMMEDIATE, PUT AT TOP OF LIST
BEQ 2$ ; ELSE, PUT AT END OF LIST
MOV C.TBSB(R5),R0 ; GET BACK LINK TO TBS LIST
BEQ 3$ ; CHECK FOR EMPTY LIST
MOV R4,ME.CFL(R0) ; LAST PACKET POINTS TO NEW PACKET
MOV R0,ME.CBL(R4) ; NEW PACKET POINTS BACK TO LIST
CLR ME.CFL(R4) ; NEW PACKET POINTS FORWARD TO HEADER
MOV R4,C.TBSB(R5) ; HEADER POINTS TO NEW PACKET
BR 4$ ; PUT NEW BUFFER IN MAPPED MEMORY

2$: MOV C.TBSF(R5),R0 ; GET FORWARD LINK TO CMD LIST
BEQ 3$ ; CHECK FOR EMPTY LIST
MOV R4,ME.CBL(R0) ; FIRST PACKET POINTS TO NEW PACKET
MOV R0,ME.CFL(R4) ; NEW PACKET POINTS FORWARD TO LIST
CLR ME.CBL(R4) ; NEW PACKET POINTS BACK TO HEADER
MOV R4,C.TBSF(R5) ; HEADER POINTS TO NEW PACKET
BR 4$ ; PUT NEW BUFFER IN MAPPED MEMORY

3$: CLR ME.CFL(R4) ; LIST WAS
CLR ME.CBL(R4) ; EMPTY
MOV R4,C.TBSF(R5) ; HEADER POINTS TO
MOV R4,C.TBSB(R5) ; NEXT PACKET
    
```

```

6017
6018 051402 012700 000046      4$:  MOV    #<CMDSIZ-3>,R0      ; RO = # OF WORDS TO CLEAR
6019 051406                                PUSH  <R4>                ; SAVE ADDRESS OF TOP
6020 051410 062704 000006      ADD    #ME.CTO,R4        ; R4 -> 1ST WORD TO CLEAR
6021 051414 005024      5$:  CLR    (R4)+            ; CLEAR WORD
6022 051416 005300      DEC    R0                ; DECREMENT WORD COUNT
6023 051420 001375      BNE   5$                ; IF NOT ZERO, LOOP
6024 051422                                POP    <R4>              ; RESTORE POINTER TO TOP
6025 051424 013764 002242 000020  MOV    TSTOFF,ME.OFF(R4)  ; SET MEMORY PACKET OFFSET
6026 051432 012737 177777 002242  MOV    #-1,TSTOFF        ; -1 INDICATES NO BUFFER USED
6027 051440 005064 000016      CLR    ME.CFG(R4)        ; SET M. E. FLAGS
6028 051444 016464 000004 000026  MOV    ME.CHF(R4),P.CRF+ME.CP(R4); SET COMMAND REF NUMBER
6029 051452 012664 000032      MOV    (SP)+,P.UNIT+ME.CP(R4); SET UNIT NUMBER
6030 051456 013764 002244 000036  MOV    TSTOPC,P.OPCD+ME.CP(R4); SET OPCODE
6031 051464 010364 000040      MOV    R3,P.MOD+ME.CP(R4); SET COMMAND MODIFIERS
6032 051470 000241      CLC                    ; SUCCESS RETURN
6033 051472 000240      NOP                    ; [JBG] INSERT HALT FOR DEBUG
6034 051474      9$:  POP    <R0>            ; RESTORE SAVED REGISTERS
6035 051476 000207      RETURN                ; RETURN
6036
6037 051500 000261      10$: SEC                    ; INDICATE ERROR
6038 051502 000774      BR    9$                ;

```

```

6040
6041      ;++
6042      ;
6043      ;
6044      ;
6045      ;
6046      ;
6047      ;
6048      ;
6049      ;
6050      ;
6051      ;
6052      ;--
6053
6054 051504      SNDMSG: PUSH    <R1,R3,R4>      ; SAVE REGISTERS
6055 051512 016503 000070      1$: MOV     C.CPTR(R5),R3      ; POINT TO COMMAND RING ENTRY
6056 051516 032763 100000 000002  BIT     #RG.OWN,2(R3)      ; IF CONTROLLER OWNS
6057 051524 001154      BNE     40$              ; COMMAND RING, EXIT
6058 051526 016504 000164      MOV     C.TBSF(R5),R4      ; GET FORWARD LINK TO TBS LIST
6059 051532 001551      BEQ     40$              ; IF LIST EMPTY, EXIT
6060 051534 032764 000070 000036  BIT     #70,P.OPCD+ME.CP(R4) ; IF IMMEDIATE COMMAND
6061 051542 001441      BEQ     10$              ; USE SPECIAL CASE CODE
6062
6063      ;
6064      ;
6065 051544 005765 000152      TST     C.CRED(R5)        ; IF CREDIT LIMIT NOT POSITIVE,
6066 051550 003542      BLE     40$              ; EXIT
6067 051552 005365 000152      DEC     C.CRED(R5)        ; DECREMENT CREDITS
6068 051556 012764 177777 000012  MOV     #1,ME.ST1(R4)     ; INITIALIZE
6069 051564 012764 177777 000014  MOV     #1,ME.ST2(R4)     ; COMMAND STATUS
6070 051572 016401 000000      MOV     ME.CFL(R4),R1     ; GET POINTER TO NEXT PACKET
6071 051576 001403      BEQ     2$                ; IF END OF LIST, SKIP
6072 051600 005061 000002      CLR     ME.CBL(R1)        ; POINT TO HEADER
6073 051604 000402      BR      3$                ; CONTINUE
6074 051606 005065 000166      2$: CLR     C.TBSB(R5)     ; BLINK HEADER ZERO, TBS LIST IS EMPTY
6075 051612 010165 000164      3$: MOV     R1,C.TBSF(R5)   ; FLINK HEADER POINTS TO NEXT PACKET
6076 051616 016501 000160      MOV     C.CMFL(R5),R1    ; GET FORWARD LINK TO CMD LIST
6077 051622 001451      BEQ     20$              ; CHECK FOR EMPTY LIST
6078 051624 010461 000002      MOV     R4,ME.CBL(R1)    ; FIRST PACKET POINTS TO NEW PACKET
6079 051630 010164 000000      MOV     R1,ME.CFL(R4)    ; NEW PACKET POINTS FORWARD TO LIST
6080 051634 005064 000002      CLR     ME.CBL(R4)        ; NEW PACKET POINTS BACK TO HEADER
6081 051640 010465 000160      MOV     R4,C.CMFL(R5)    ; HEADER POINTS TO NEW PACKET
6082 051644 000450      BR      30$              ; SEND PACKET
6083
6084 051646 005765 000152      10$: TST     C.CRED(R5)     ; IF CREDIT LIMIT NEGATIVE,
6085 051652 002501      BLT     40$              ; EXIT
6086 051654 005365 000152      DEC     C.CRED(R5)        ; DECREMENT CREDITS
6087 051660 012764 000001 000012  MOV     #1,ME.ST1(R4)     ; INITIALIZE
6088 051666 005064 000014      CLR     ME.ST2(R4)        ; COMMAND STATUS
6089 051672 016401 000000      MOV     ME.CFL(R4),R1    ; GET POINTER TO NEXT PACKET
6090 051676 001403      BEQ     12$              ; IF END OF LIST, SKIP
6091 051700 005061 000002      CLR     ME.CBL(R1)        ; POINT TO HEADER
6092 051704 000402      BR      13$              ; CONTINUE
6093 051706 005065 000166      12$: CLR     C.TBSB(R5)     ; BLINK HEADER ZERO, TBS LIST IS EMPTY
6094 051712 010165 000164      13$: MOV     R1,C.TBSF(R5)   ; FLINK HEADER POINTS TO NEXT PACKET
    
```

```

6095 051716 016501 000162      MOV      C.CMBL(R5),R1      ; GET BACK LINK TO CMD LIST
6096 051722 001411              BEQ      20$                ; CHECK FOR EMPTY LIST
6097 051724 010461 000000      MOV      R4,ME.CFL(R1)     ; LAST PACKET POINTS TO NEW PACKET
6098 051730 010164 000002      MOV      R1,ME.CBL(R4)     ; NEW PACKET POINTS BACK TO LIST
6099 051734 005064 000000      CLR      ME.CFL(R4)        ; NEW PACKET POINTS FORWARD TO HEADER
6100 051740 010465 000162      MOV      R4,C.CMBL(R5)     ; HEADER POINTS TO NEW PACKET
6101 051744 000410              BR       30$                ; MAP BUFFER TO HI MEM
6102
6103 051746 005064 000000      20$:    CLR      ME.CFL(R4)     ; CMD LIST WAS
6104 051752 005064 000002      CLR      ME.CBL(R4)        ; EMPTY
6105 051756 010465 000160      MOV      R4,C.CMFL(R5)     ; HEADER POINTS TO
6106 051762 010465 000162      MOV      R4,C.CMBL(R5)     ; NEXT PACKET
6107 051766
6109 051766 004737 023704      30$:    CALL     DBGCMD           ; DUMP COMMAND PACKET
6111 051772 010413              MOV      R4,(R3)           ; GET PHYSICAL ADDRESSES
6112 051774 062713 000026      ADD      #ME.CP,(R3)       ; OF COMMAND PACKET
6113 052000 012763 100000 000002      MOV      #RG.OWN,2(R3)     ; SET OWNERSHIP IN COMMAND RING
6114 052006 005775 000000      TST     B(R5)              ; READ IP REG TO START POLLING
6115 052012 016501 000006      MOV      C.CTO(R5),R1      ; TIMEOUT = CONTROLLER TIMEOUT
6116 052016 010400              MOV      R4,R0             ; POINT TO TIME OUT COUNTER
6117 052020 062700 000006      ADD      #ME.CTO,R0        ; POINTER TO TIMER FIELD
6118 052024 004737 052070      CALL     SETTO             ; START TIMER
6119 052030 062765 000004 000070      ADD      #4,C.CPTR(R5)     ; ADJUST COMMAND RING POINTER
6120 052036 026565 000070 000074      CMP      C.CPTR(R5),C.CEND(R5) ; IF POINTER IS NOT AT END,
6121 052044 002622              BLT     1$                 ; SEND ANOTHER COMMAND.
6122 052046 016565 000072 000070      MOV      C.CBAS(R5),C.CPTR(R5) ; ELSE
6123 052054 000616              BR       1$                 ; RE-INIT POINTER & CONTINUE.
6124 052056              40$:    POP      <R4,R3,R1>     ; RESTORE SAVED REGISTERS
6125 052064 000240      NOP                    ; [DBG] INSERT HALT FOR DEBUG
6126 052066 000207      RETURN                  ; RETURN

```

```

6128
6129
6130      ;++
6131      ;
6132      ;
6133      ;
6134      ;
6135      ;
6136      ;
6137      ;
6138      ;
6139      ;
6140      ;--
6141 052070 005737 002322      SETTO: TST      KW.CSR      ; IF NO CLOCK,
6142 052074 001421              BEQ      1$          ; EXIT
6143 052076              PUSH     <R2,R3,R4> ; SAVE REGISTERS
6144
6145 052104 013702 002330      MOV      KW.HZ,R2   ; GET MULTIPLICAND
6146 052110 004737 047420      CALL     MULT       ; PERFORM MULTIPLICATION
6147
6148 052114 063703 002332      ADD      KW.EL,R3   ; GET CURRENT TIME (LOW WORD)
6149 052120 005504              ADC      R4          ; INCREMENT HIGH WORD IF CARRY
6150 052122 063704 002334      ADD      KW.EL+2,R4 ; GET CURRENT TIME (HIGH WORD)
6151
6152 052126 010320              MOV      R3,(R0)+   ; SAVE LOW WORD OF TIMEOUT
6153 052130 010410              MOV      R4,(R0)   ; SAVE HIGH WORD OF TIMEOUT
6154
6155 052132              POP      <R4,R3,R2>
6156 052140      1$:
6157 052140 000240      NOP
6158 052142 000207      RETURN      ; [DBG] INSERT HALT FOR DEBUG
6159
6160      ;++
6161      ;
6162      ;
6163      ;
6164      ;
6165      ;
6166      ;
6167      ;
6168      ;
6169      ;
6170      ;--
6171
6172 052144 005737 002322      SETMIN: TST      KW.CSR      ; IF NO CLOCK,
6173 052150 001421              BEQ      1$          ; EXIT
6174 052152              PUSH     <R2,R3,R4> ; SAVE REGISTERS
6175
6176 052160 013702 002336      MOV      KW.60,R2   ; GET MULTIPLICAND
6177 052164 004737 047420      CALL     MULT       ; PERFORM MULTIPLICATION
6178
6179 052170 063703 002332      ADD      KW.EL,R3   ; GET CURRENT TIME (LOW WORD)
6180 052174 005504              ADC      R4          ; INCREMENT HIGH WORD IF CARRY
6181 052176 063704 002334      ADD      KW.EL+2,R4 ; GET CURRENT TIME (HIGH WORD)
6182
    
```


CZUDJAO UDA50-A/KDA50-Q SUBSY E MACRO V05.03 Wednesday 02-Oct-85 16:03 Page 121-1
GLOBAL SUBROUTINES SECTION

```
6183 052202 010320      MOV      R3,(R0)+      ; SAVE LOW WORD OF TIMEOUT
6184 052204 010410      MOV      R4,(R0)      ; SAVE HIGH WORD OF TIMEOUT
6185
6186 052206              POP      <R4,R3,R2>
6187 052214              1$:
6188 052214 000240      NOP
6189 052216 000207      RETURN
6190
```

```

6192
6193
6194
6195
6196
6197
6198
6199
6200
6201
6202
6203
6204
6205 052220
6206
6207
6208
6209 052224 016504 000004
6210 052230 042704 177000
6211 052234 010501
6212 052236 062701 000010
6213 052242
        052242 012746 000340
        052246 010146
        052250 010446
        052252 012746 000003
        052256 104437
        052260 062706 000010
6214 052264 006204
6215 052266 006204
6216 052270 052704 011000
6217 052274 052704 100000
6218 052300 010437 002342
6219 052304 016537 000100 002346
6220
6221
6222
6223 052312 010502
6224 052314 062702 000106
6225 052320 012700 000006
6226 052324 012722 177777
6227 052330 005300
6228 052332 003374
6229
6230
6231
6232
6233 052334 016504 000000
6234 052340 005037 002264
6235 052344
        052344 012746 000340
        052350 012746 054472
        052354 012746 000004
        052360 012746 000003
        052364 104437

```

```

:++
:
: CNTINT - INITIALIZE A CONTROLLER AND BRING IT ON-LINE. ALL STEPS
: ARE CHECKED. AN ERROR MESSAGE IS REPORTED IF ANY ERROR IS DETECTED.
:
: INPUTS:
: R5 - ADDRESS OF CONTROLLER TABLE.
:
: OUTPUTS:
: R4 - ADDRESS OF IP REGISTER IN CONTROLLER
: R5 - UNCHANGED
: CARRY CLEAR IF NO ERROR, SET IF ANY ERROR REPORTED
:--
:
CNTINT: PUSH <R2,R3> ; SAVE REGISTERS ON STACK
:
: SET UP INTERRUPT VECTOR & SET UP DATA TO SEND TO SA REGISTER
:
1$: MOV C.VEC(R5),R4 ; GET VECTOR OF CONTROLLER
BIC #C<CT.VEC>,R4 ; MASK OTHER BITS
MOV R5,R1 ; GET INTERRUPT SERVICE LINK
ADD #C.JSR,R1
SETVEC R4,R1,#PRI07 ; SET UP INTERRUPT VECTOR
MOV #PRI07,-(SP)
MOV R1,-(SP)
MOV R4,-(SP)
MOV #3,-(SP)
TRAP C+SVEC
ADD #10,SP
ASR R4 ; DIVIDE VECTOR
ASR R4 ; BY 4
BIS #RNGPWR,R4 ; INSERT CMD/RSP QUE LENGTH
BIS #SA.STP,R4 ; SET BIT 15 IN DATA WORD
MOV R4,SND.S1 ; LOAD LEN, IE FLAG & VECTOR FOR STEP 1
MOV C.RBAS(R5),SND.S2 ; GET RING BASE
:
: WRITE -1 TO ALL WORDS IN HOST COMMUNICATIONS AREA FOR STEP 3
:
:
MOV R5,R2 ; GET FIRST ADDRESS
ADD #C.CINT,R2 ; OF RING BUFFER
MOV #6,R0 ; GET SIZE OF RING BUFFER
5$: MOV #-1,(R2)+ ; WRITE ONES TO EACH WORD IN BUFFER
DEC R0 ; IF NOT END OF BUFFER,
BGT 5$ ; LOOP
:
: VERIFY THE ADDRESS OF THE SA AND IP REGISTERS ARE VALID AND
: START THE INITIALIZATION
:
MOV C.IPR(R5),R4 ; GET ADDRESS OF IP REGISTER
CLR NXMAD ; CLEAR MEMORY ERROR FLAG
SETVEC #ERRVEC,#NXMI,#PRI07 ; SETUP TIMEOUT ERROR VECTOR
MOV #PRI07,-(SP)
MOV #NXMI,-(SP)
MOV #ERRVEC,-(SP)
MOV #3,-(SP)
TRAP C+SVEC

```

CZUDJAO UDA50-A/KDA50-Q SUBSY E MACRO V05.03 Wednesday 02-Oct-85 16:03 Page 122-1
 GLOBAL SUBROUTINES SECTION

```

6236 052366 062706 000010      ADD    #10,SP
6237 052372 005764 000002      TST   2(R4)           ; ACCESS SA REGISTER
6238 052376 005014              CLR   (R4)           ; WRITE TO IP
052400 012700 000004      CLRVEC #ERRVEC      ; RETURN TIMEOUT ERROR VECTOR
052404 104436              MOV   #ERRVEC,R0
6239 052406 005737 002264      TRAP C#CVEC
052412 001406              TST   NXMAD          ; SEE IF A MEMORY ERROR OCCURRED
6240 052414              BEQ   11$            ; IF NO ERROR, CONTINUE
052416 104455              ERRDF 37,ERR037     ; PRINT ERROR MESSAGE
052420 000045              TRAP C#ERRDF
052422 020510              .WORD 37
052424 000137 053066              .WORD 0
052424 000137 053066              .WORD ERR037
6242 052424 000137 053066              JMP   41$            ; EXIT
6243
6244
6245
6246
6247 052430 012737 004000 002354 11$:  MOV   #SA.S1,CNTRSD  ; STORE RESPONSE MASK
6248 052436 012703 002340              MOV   #INITBL,R3    ; GET INDEX TO SEND/REPOOND INIT TABLE
6249 052442 004737 053252              CALL  CNTRSP         ; WAIT FOR STEP OR ERROR BITS
6250 052446 103002              BCC   13$            ; EXIT IF ERROR
6251 052450 000137 053066              JMP   41$            ;
6252 052454 004733              CALL  8(R3)+         ; CALL RESPONSE CHECKER FOR STEP
6253 052456 103002              BCC   14$            ;
6254 052460 000137 053066              JMP   41$            ; EXIT IF ERROR
6255 052464 006337 002354              ASL   CNTRSD         ; SHIFT TO NEXT STEP BIT
6256 052470 032737 040000 002354 14$:  BIT   #SA.S4,CNTRSD  ; IF NOW AT STEP 4,
6257 052476 071003              BNE   20$            ; EXIT LOOP
6258 052500 012364 000002              MOV   (R3)+,2(R4)   ; WRITE DATA TO SA REGISTER
6259 052504 000756              BR    12$            ; STAY IN LOOP
6260
6261
6262
6263
6264 052506 032765 004000 000014 20$:  BIT   #CT.DI.C.FLG(R5) ; IF ENHANCED DIAGS NOT SUPPORTED,
6265 052514 001423              BEQ   25$            ; DON'T DO PURGE/POLL
6266 052516 012700 000310              MOV   #200,R0        ; GET LOOP COUNTER
6267 052522 012764 100000 000002 23$:  MOV   #SA.TST,2(R4)  ; WRITE STEP 3 RESPONSE TO SA REGISTER
6268 052530 016402 000002              MOV   2(R4),R2       ; IF SA REGISTER IS ZERO,
6269 052534 001407              BEQ   24$            ; EXIT LOOP
6270 052536 005300              DEC   R0              ; IF LOOP COUNTER NOT ZERO,
6271 052540 001373              BNE   23$            ; KEEP LOOPING
6272 052542              ERRDF 24,ERR024     ; FATAL ERROR, SA REG NOT ZERO
052542 104455              TRAP C#ERRDF
052544 000030              .WORD 24
052546 000000              .WORD 0
052550 017770              .WORD ERR024
6273 052552 000545              BR    41$            ;
6274
6275 052554 005064 000002 24$:  CLR   2(R4)           ; WRITE 0 TO SA REGISTER (PURGE)
6276 052560 005714              TST   (R4)           ; READ FROM IP REGISTER (POLL)
6277 052562 000402              BR    26$            ;
6278
6279 052564 005064 000002 25$:  CLR   2(R4)           ; WRITE STEP 3 RESPONSE TO SA REG

```

CZUDJAO UDA50-A/KDA50-Q SUBSY E MACRO V05.03 Wednesday 02-Oct-85 16:03 Page 122-2
GLOBAL SUBROUTINES SECTION

```

6280 052570 004737 053252      26$: CALL CNTRSP          ; WAIT FOR STEP OR ERROR BIT
6281 052574 103534             BCS 41$             ; EXIT IF MICROCODE REPORTED FAILURE
6282 052576 010237 002352      MOV R2,SSTEP4      ; SAVE STEP 4 RESPONSE VALUE.
6283                                     ;
6284                                     ; CHECK HOST COMMUNICATION AREA FOR ALL ZEROS
6285                                     ;
6286 052602 010502             MOV R5,R2          ; GET FIRST ADDRESS
6287 052604 062702 000106      ADD #C.CINT,R2     ; OF RING BUFFER
6288 052610 012703 000006      MOV #6,R3         ; GET SIZE OF RING BUFFER
6289 052614 005722             TST (R2)+         ; CHECK WORD IN BUFFER
6290 052616 001003             BNE 29$          ; GO TO ERROR REPORTER IF NOT ZERO
6291 052620 005303             DEC R3            ; COUNT THE WORDS IN BUFFER
6292 052622 003374             BGT 28$          ; LOOP UNTIL ALL WORDS CHECKED
6293 052624 000405             BR 30$           ; START CONTROLLER AND EXIT
6294
6295 052626             29$: ERRDF 23,ERR023      ; REPORT BUFFER NOT CLEARED
        052626 104455      TRAP C$ERRDF
        052630 000027      .WORD 23
        052632 000000      .WORD 0
        052634 017606      .WORD ERR023
6296 052636 000513      BR 41$             ; ERROR EXIT
6297
6298                                     ; INITIALIZE RESPONSE RING, CHECK IF THE CONTROLLER TYPE IS VALID.
6299                                     ; SET CONTROLLER DEPENDENT PARAMETERS, AND START MSCP OPERATIONS.
6300
6301 052640 005065 000152      30$: CLR C.CRED(R5)      ; INIT CREDITS COUNT
6302 052644 042765 020000 000014 BIC #CT.MSG,C.FLG(R5) ; CLEAR MESSAGE RECEIVED FLAG
6303 052652 016565 000072 000070 MOV C.CBAS(R5),C.CPTR(R5) ; INITIALIZE COMMAND AND
6304 052660 016565 000100 000076 MOV C.RBAS(R5),C.RPTR(R5) ; RESPONSE RING POINTERS
6305 052666 012703 000004      MOV #4,R3
6306 052672 004737 026132      32$: CALL CLRSP
6307 052676 005303             DEC R3
6308 052700 001374             BNE 32$
6309 052702 013703 002352      MOV SSTEP4,R3
6310 052706 006003             ROR R3
6311 052710 006003             ROR R3
6312 052712 006003             ROR R3
6313 052714 006003             ROR R3
6314 052716 042703 177760      BIC #C<SA.CNT/16.>,R3 ; R3 = CONTROLLER MODEL NUMBER
6315 052722 010365 000026      MOV R3,C.TYPE(R5) ; SAVE CONTROLLER TYPE
6316 052726 022703 000006      CMP #6.,R3        ; CHECK IF UDA50-A
6317 052732 001006             BNE 34$          ; IF NOT, BRANCH
6318 052734 012765 036413 000034 MOV #U50MSZ,C.MSIZ(R5) ; ELSE GET MEMORY SIZE
6319 052742 012700 000375      MOV #<374+SA.GO>,R0 ; SET THE BURST RATE AND GO BIT
6320 052746 000440             BR 40$
6321 052750 022703 000015      34$: CMP #13.,R3
6322 052754 001006             BNE 36$
6323 052756 012765 032413 000034 MOV #Q50MSZ,C.MSIZ(R5) ; ELSE GET MEMORY SIZE
6324 052764 012700 000035      MOV #<34+SA.GO>,R0 ; SET THE BURST RATE AND GO BIT
6325 052770 000427             BR 40$
6326 052772 022703 000007      36$: CMP #7.,R3
6327 052776 001006             BNE 37$
6328 053000 012765 000000 000034 MOV #QDXMSZ,C.MSIZ(R5) ; ELSE GET MEMORY SIZE
6329 053006 012700 000001      MOV #<SA.GO>,R0 ; SET THE BURST RATE AND GO BIT
6330 053012 000416             BR 40$

```

CZUDJAO UDA50-A/KDA50-Q SUBSY E MACRO V05.03 Wednesday 02-Oct-85 16:03 Page 122-3
GLOBAL SUBROUTINES SECTION

```

6331 053014 022703 000001      37$:  CMP      #1.,R3          ; CHECK IF RUC25
6332 053020 001006                BNE      39$          ; IF NOT, BRANCH
6333 053022 012765 000000 000034  MOV      #C25MSZ,C.MSIZ(R5) ; ELSE,GET MEMORY SIZE
6334 053030 012700 000001                MOV      #<SA.GO>,R0   ; SET THE BURST RATE AND GO BIT
6335 053034 000405                BR       40$          ; EXIT
6336 053036                39$:  ERRDF   14,,ERR014   ; REPORT ERROR
        053036 104455                TRAP    C$ERDF
        053040 000016                .WORD  14
        053042 000000                .WORD  0
        053044 017362                .WORD  ERR014
6337 053046 000407                BR       41$          ; EXIT
6338
6339 053050 010064 000002      40$:  MOV      R0,2(R4)     ; WRITE TO SA REGISTER
6340 053054                POP      <R3,R2>      ; RESTORE REGISTERS FROM STACK
        053054 012603                MOV      (SP)+,R3    ; POP STACK INTO R3
        053056 012602                MOV      (SP)+,R2    ; POP STACK INTO R2
6341 053060 000241                CLC                          ; CLEAR Z TO INDICATE NO ERROR
6342 053062 000240                NOP                          ; [DBG] INSERT HALT FOR DEBUG
6343 053064 000207                RETURN
6344
6345                ;
6346                ;
6347 053066 010502                41$:  MOV      R5,R2          ; GET FIRST ADDRESS
6348 053070 062702 000106                ADD      #C.CINT,R2   ; OF RING BUFFER
6349 053074 012703 000006                MOV      #6.,R3      ; GET SIZE OF RING BUFFER
6350 053100 005022                42$:  CLR      (R2)+      ; CLEAR BUFFER
6351 053102 005303                DEC      R3           ; COUNT THE WORDS IN BUFFER
6352 053104 003375                BGT     42$          ; LOOP UNTIL ENTIRE BUFFER CLEARED
6353 053106                POP      <R3,R2>      ; RESTORE REGISTERS FROM STACK
        053106 012603                MOV      (SP)+,R3    ; POP STACK INTO R3
        053110 012602                MOV      (SP)+,R2    ; POP STACK INTO R2
6354 053112 004737 027350                CALL   DRPCNT        ; DROP CONTROLLER FROM TEST
6355 053116 000240                NOP                          ; [DBG] INSERT HALT FOR DEBUG
6356 053120 000207                RETURN
6357
6358                ;
6359                ;
6360                ;
6361 053122 012701 004000      RSP.S1: MOV      #SA.S1,R1   ; SET STEP ONE BIT
6362 053126 042765 004000 000014  BIC      #CT.DI,C.FLG(R5) ; CLEAR DI FLAG
6363 053134 032702 000400                BIT      #SA.DI,R2   ; IF DI BIT NOT SET,
6364 053140 001403                BEQ     1$           ; SKIP
6365 053142 052765 004000 000014  BIS      #CT.DI,C.FLG(R5) ; ELSE, SET DI BIT
6366 053150 032702 004000      1$:  BIT      #SA.S1,R2   ; IF STEP 1 BIT SET,
6367 053154 001033                BNE     RSP.SU      ; SUCCESS
6368 053156 000423                BR       RSP.ER     ; ELSE, ERROR
6369
6370                ;
6371                ;
6372                ;
6373 053160 013701 002342      RSP.S2: MOV      SND.S1,R1 ; GET WORD SENT TO SA REGISTER
6374 053164 000301                SWAB   R1           ; GET HIGH 8 BITS
6375 053166 042701 177400                BIC      #177400,R1  ;
6376 053172 052701 010000                BIS      #SA.S2,R1  ; SET STEP 2 BIT
6377 053176 020102                CMP     R1,R2       ; IF DATA RECEIVED IS CORRECT.

```

```

6378 053200 001421          BEQ   RSP.SU          ; DO SUCCESSFUL EXIT.
6379 053202 000411          BR    RSP.ER          ; ELSE, DO ERROR EXIT
6380                          ;
6381                          ; RESPONSE CHECK FOR THIRD WORD (STEP 3) FROM SA REGISTER
6382                          ; CHECK FOR ECHO OF MESSAGE AND COMMAND RING LENGTHS
6383                          ;
6384 053204 013701 002342    RSP.S3: MOV   SND.S1,R1      ; GET WORD SENT TO SA REGISTER
6385 053210 042701 177400    BIC   #177400,R1        ; JUST LOW 8 BITS
6386 053214 052701 020000    BIS   #SA.S3,R1        ; SET STEP 3 BIT
6387 053220 020102          CMP   R1,R2            ; IF DATA RECEIVED IS CORRECT,
6388 053222 001410          BEQ   RSP.SU          ; DO SUCCESSFUL EXIT.
6389 053224 000400          BR    RSP.ER          ; ELSE, DO ERROR EXIT
6390                          ;
6391                          ; EXIT RESPONSE CHECK ROUTINES
6392                          ;
6393 053226          RSP.ER: ERRDF 25,ERR025      ; ERROR - WRONG DATA IN SA REGISTER
        053226 104455    TRAP  C#ERRDF
        053230 000031    .WORD 25
        053232 000000    .WORD 0
        053234 020046    .WORD ERR025
6394 053236 000261          SEC                          ; SET CARRY TO INDICATE ERROR
6395 053240 000240          NOP                          ; [DBG] INSERT HALT FOR DEBUG
6396 053242 000207          RETURN
6397                          ;
6398 053244 000241          RSP.SU: CLC          ; CLEAR CARRY TO INDICATE SUCCESS
6399 053246 000240          NOP                          ; [DBG] INSERT HALT FOR DEBUG
6400 053250 000207          RETURN

```

```

6402
6403      :++
6404      :
6405      :
6406      :
6407      :
6408      :
6409      :
6410      :
6411      :
6412      :
6413      :
6414      :
6415      :
6416      :
6417      :
6418      :
6419      :--
6420      053252      010146      100000      002354      CNTRSP: PUSH      R1
6421      053252      052737      000012      :
6422      053262      012701      000154      :
6423      053266      010500      :
6424      053270      062700      000154      :
6425      053274      004737      052070      :
6426      053300      :
6427      053300      012601      002354      000002      1$:
6428      053310      001026      :
6429      053312      005737      002322      :
6430      053316      001771      :
6431      053320      023765      002334      000156      :
6432      053326      101005      :
6433      053330      001364      :
6434      053332      023765      002332      000154      :
6435      053340      103760      :
6436      053342      016402      000002      002354      2$:
6437      053346      042737      100000      :
6438      053354      104455      :
6439      053354      000026      :
6440      053356      000000      :
6441      053362      017524      :
6442      053364      000407      :
6443      053366      016402      000002      3$:
6444      053372      100007      :
6445      053374      104455      :
6446      053376      000025      :
6447      053400      000000      :
6448      053402      017452      :
6449      053404      000261      4$:

```

CNTRSP - WAIT FOR CONTROLLER TO RESPOND WITH DATA IN SA REGISTER.
 EITHER STEP BIT FROM MASK IN LOCATION CNTRSD OR ERROR BIT
 WILL CAUSE A TERMINATION.
 AN ERROR MESSAGE WILL BE PRINTED IF THE CONTROLLER DOES NOT RESPOND
 IN 10 SECONDS OR IF ERROR SETS.

INPUTS:
 CNTRSD - MASK OF STEP BIT TO LOOK FOR
 R4 - ADDRESS OF IP REGISTER
 R5 - ADDRESS OF CONTROLLER TABLE

OUTPUTS:
 ERROR MESSAGE IF TIME OUT ON RESPONSE OR ERROR BIT SETS
 R2 - DATA FROM SA REGISTER
 CARRY SET IF ERROR BIT SETS OR TIME OUT

```

; PUSH R1 ON STACK
; SET ERROR BIT IN MASK WORD
; SET UP FOR 10 SECOND TIMEOUT
; POINT TO COUNTER IN CONTROLLER TABLE
;
; POP STACK INTO R1
; LOOK AT ERROR AND STEP BIT
; BRANCH IF EITHER SET
; SEE IF CLOCK ON SYSTEM
; CHECK IF TIME OUT OCCURRED
;
; GET REGISTER CONTENTS
; CLEAR ERROR BIT IN MASK WORD
; REPORT TIME OUT ERROR
;
;
;
;
; GET REGISTER CONTENTS
; EXIT IF ERROR NOT SET
; REPORT ERROR INFO
;
; SET CARRY TO INDICATE ERROR

```

CZUDJAO UDA50-A/KDA50-Q SUBSY E MACRO V05.03 Wednesday 02-Oct-85 16:03 Page 123-1
GLOBAL SUBROUTINES SECTION

6447	053406	000240	NOP		; [DBG] INSERT HALT FOR DEBUG
6448	053410	000207		RETURN	;
6449			;		
6450			;	NORMAL EXIT	
6451			;		
6452	053412	000241	S#;	CLC	; CLEAR CARRY AS NO ERROR INDICATION
6453	053414	000240	NOP		; [DBG] INSERT HALT FOR DEBUG
6454	053416	000207		RETURN	;


```

6456
6457      ;++
6458      ;      REINIT - RE-INITIALIZE ALL CONTROLLERS
6459      ;
6460      ;      INPUTS:
6461      ;      CTABS - ADDRESS OF FIRST CONTROLLER TABLE
6462      ;
6463      ;      OUTPUTS:
6464      ;      NONE
6465      ;--
6466 053420 013705 002200      REINIT: MOV      CTABS,R5          ; GET CONTROLLER TABLE ADDRESS
6467 053424 004737 053452      1$: CALL     RESET          ; RE-INIT THE CONTROLLER
6468 053430 042765 050000 000014 BIC     #CT.IOC!CT.DUN,C.FLG(R5); CLEAR CONTROLLER FLAGS
6469 053436 062705 000170      ADD     #C.SIZE,R5          ; POINT TO NEXT TABLE
6470 053442 005715      TST     (R5)                ; IF NOT ZERO,
6471 053444 001367      BNE     1$                  ; LOOK AT NEXT CONTROLLER
6472 053446 000240      NOP
6473 053450 000207      RETURN
    
```

```

6475
6476
6477      :++
6478      :
6479      :
6480      :
6481      :
6482      :
6483      :
6484      :--
6485      053452  005037  002264
6486      053456
        053456  012746  000340
        053462  012746  054472
        053466  012746  000004
        053472  012746  000003
        053476  104437
        053500  062706  000010
6487      053504  005075  000000
6488      053510
        053510  012700  000004
        053514  104436
6489      053516  005037  002264
6490      053522  005065  000032
6491      053526  005065  000030
6492      053532  005065  000042
6493      053536  042765  024400  000014
6494      053544  000240
6495      053546  000207

      RESET:  CLR      NXMAD      ; CLEAR NON-EXISTANT MEMORY ADDRESS
              SETVEC  @ERRVEC, @NXMI, @PRI07 ; SETUP TIMEOUT ERROR VECTOR
              MOV      @PRI07, -(SP)
              MOV      @NXMI, -(SP)
              MOV      @ERRVEC, -(SP)
              MOV      #3, -(SP)
              TRAP     C+SVEC
              ADD      #10, SP
              CLR      @C.IPR(R5)      ; RESET CONTROLLER (CLEAR IP)
              CLRVEC  @ERRVEC      ; RETURN TIMEOUT ERROR VECTOR
              MOV      @ERRVEC, R0
              TRAP     C+CVEC
              CLR      NXMAD      ; CLEAR MEMORY ERROR FLAG
              CLR      C.UCNT(R5)    ; RESET UNIT UNDER TEST COUNT
              CLR      C.STEP(R5)   ; RESET TEST STEP COUNTER
              CLR      C.NEXT(R5)   ; RESET NEXT DRIVE POINTER
              BIC      @<CT.MSG!CT.DI!CT.MRW>, C.FLG(R5); CLEAR FLAGS
              ; [DBG] INSERT HALT FOR DEBUG
              RETURN
    
```



```

6527
6528
6529      :++      WCHNG - WAIT UNTIL WRAPPED DATA APPEARS IN SA REGISTER
6530      :
6531      :      INPUTS:
6532      :      R4 - IP REGISTER
6533      :      R5 - ADDRESS OF CONTROLLER TABLE
6534      :--
6535
6536      WCHNG:  PUSH    <R1>           ; SAVE REGISTERS
                MOV     R1,-(SP)      ; PUSH R1 ON STACK
6537      053652  010146  000012      MOV     #10,R1          ; SET TIMEOUT FOR 10 SECONDS
6538      053654  012701  000012      MOV     R5,R0          ; POINT TO CONTROLLER TABLE
6539      053660  010500  000154      ADD     #C.TO,R0
6540      053662  062700  000154      CALL   SETTO
6541      053666  004737  052070      1$:    MOV     2(R4),R2      ; GET SA CONTENTS
6542      053672  016402  000002      CMP     R2,WCHNGD     ; IS LOOPED DATA IN SA REGISTER?
6543      053676  020237  002356      BEQ     3$
6544      053702  001423  002322      TST     KW.CSR        ; SEE IF CLOCK ON SYSTEM
6545      053704  005737  002322      BEQ     1$
6546      053710  001770  000156      CMP     KW.EL+2,C.TO(R5) ; CHECK IF TIME OUT OCCURRED
6547      053712  023765  000156      BHI     2$
6548      053720  101005  000154      BNE     1$
6549      053722  001363  002332  000154      CMP     KW.EL,C.TO(R5)
6550      053724  023765  002332  000154      BLO     1$
6551      053732  103757  002332  000154      2$:    ERDF   27,ERR027    ; REPORT ERROR
                TRAP   C$ERDF
                .WORD  27
                .WORD  0
                .WORD  ERR027
6552      053734  104455  027350      CALL   DRPCNT        ; DROP CONTROLLER FROM TESTING
6553      053736  000033  027350      BR     4$
6554      053740  000060  027350      3$:    CLC
6555      053742  020210  027350      4$:    POP     <R1>        ; SUCCESSFUL EXIT
                POP   (SP)+,R1      ; RESTORE SAVED REGISTER
                MOV     (SP)+,R1    ; POP STACK INTO R1
6556      053744  004737  027350      NOP
6557      053750  000401  027350      ; [DBG] INSERT HALT FOR DEBUG
6558      053752  000241  027350      RETURN              ; RETURN TO CALLING PROGRAM
                053754  012601  027350
                053756  000240
                053760  000207

```

```

6560
6561
6562
6563
6564
6565
6566
6567
6568 053762
      053762 012746 016543
      053766 012746 000001
      053772 010600
      053774 104414
      053776 062706 000004
6569 054002 000240
6570 054004 000207
6571
6572
6573
6574
6575
6576
6577
6578
6579 054006
6580 054010 013703 002206
6581 054014 006303
6582 054016
      054016 016346 007244
      054022 012746 007403
      054026 012746 000002
      054032 010600
      054034 104414
      054036 062706 000006
6583 054042 005737 002322
6584 054046 001420
6585 054050 004737 053550
6586 054054
      054054 013746 002272
      054060 013746 002270
      054064 013746 002266
      054070 012746 010303
      054074 012746 000004
      054100 010600
      054102 104414
      054104 062706 000012
6587 054110
      054110 012746 010300
      054114 012746 000001
      054120 010600
      054122 104414
      054124 062706 000004
6588 054130
6589 054132 000240
6590 054134 000207

```

```

.SBTTL PRE-PROGRAMMED MESSAGE SUBROUTINES

:++
: CALR3 - PRE-PROGRAMMED PRINT ROUTINE 3
:
: PRINT "FATAL CONTROLLER ERROR"
:--

CALR3: PRINTB  #XFCE          ; PRINT MESSAGE
      MOV     #XFCE, -(SP)
      MOV     #1, -(SP)
      MOV     SP, R0
      TRAP   C#PNTB
      ADD     #4, SP

NOP          ; [DBG] INSERT HALT FOR DEBUG
      RETURN

:++
: CALR4 - PRE-PROGRAMMED PRINT ROUTINE 4
:
: PRINT BASIC LINE FOR HOST PROGRAM ERROR WITHOUT CONTROLLER ADDRESS
: OR DRIVE NUMBER.
:--

CALR4: PUSH   <R3>          ; SAVE REGISTERS
      MOV     TNUM, R3      ; GET TEST NUMBER
      ASL     R3           ; CONVERT TO WORD OFFSET
      PRINTB #BASLO, TNAME(R3) ; PRINT MESSAGE
      MOV     #BASLO, -(SP)
      MOV     #2, -(SP)
      MOV     SP, R0
      TRAP   C#PNTB
      ADD     #6, SP
      TST    KW.CSR       ; CHECK FOR CLOCK ON SYSTE
      BEQ    1$          ; IF ZERO, SKIP
      CALL   RNTIME      ; GET RUN TIME
      PRINTB #RNTIM, RNTMH, RNTMM, RNTSS; PRINT RUN TIME
      MOV     RNTSS, -(SP)
      MOV     RNTMM, -(SP)
      MOV     RNTMH, -(SP)
      MOV     #RNTIM, -(SP)
      MOV     #4, -(SP)
      MOV     SP, R0
      TRAP   C#PNTB
      ADD     #12, SP
      PRINTB #CRLF          ; TERMINATE LINE
      MOV     #CRLF, -(SP)
      MOV     #1, -(SP)
      MOV     SP, R0
      TRAP   C#PNTB
      ADD     #4, SP
      POP    <R3>        ; RESTORE SAVED REGISTER

NOP          ; [DBG] INSERT HALT FOR DEBUG
      RETURN

```

6591
 6592
 6593
 6594
 6595
 6596
 6597
 6598
 6599
 6600
 6601
 6602
 6603
 6604
 6605
 6606
 6607
 6608
 6609
 6610
 6611
 6612
 6613
 6614
 6615
 6616
 6617
 6618
 6619
 6620
 6621
 6622
 6623
 6624
 6625

054136			
054140	013703	002206	
054144	006303		
054146			
054146	011546		
054150	016346	007244	
054154	012746	007406	
054160	012746	000003	
054164	010600		
054166	104414		
054170	062706	000010	
054174	005737	002322	
054200	001420		
054202	004737	053550	
054206			
054206	013746	002272	
054212	013746	002270	
054216	013746	002266	
054222	012746	010303	
054226	012746	000004	
054232	010600		
054234	104414		
054236	062706	000012	
054242			
054242	012746	010300	
054246	012746	000001	
054252	010600		
054254	104414		
054256	062706	000004	
054262			
054264	000240		
054266	000207		

```

:++
:
: CALR5 - PRE-PROGRAMMED PRINT ROUTINE 5
:
: PRINT BASIC LINE FOR HOST PROGRAM ERROR WITH CONTROLLER ADDRESS
: AND NO DRIVE NUMBER
:
: INPUTS:
:         R5 - CONTROLLER CSR
:--
    
```

```

CALR5:  PUSH    <R3>                ; SAVE REGISTERS
        MOV     TNUM,R3            ; GET TEST NUMBER
        ASL    R3                  ; CONVERT TO WORD OFFSET
        PRINTB #BASL1,TNAMES(R3),(R5) ; PRINT MESSAGE
        MOV     (R5),-(SP)
        MOV     TNAMES(R3),-(SP)
        MOV     #BASL1, -(SP)
        MOV     #3, -(SP)
        MOV     SP,R0
        TRAP   C#PNTB
        ADD    #10,SP
        TST   KW.CSR              ; CHECK FOR CLOCK ON SYSTE
        BEQ   1#                  ; IF ZERO, SKIP
        CALL  RNTIME              ; GET RUN TIME
        PRINTB #RNTIM,RNTHH,RNTMM,RNTSS; PRINT RUN TIME
        MOV     RNTSS, -(SP)
        MOV     RNTMM, -(SP)
        MOV     RNTHH, -(SP)
        MOV     #RNTIM, -(SP)
        MOV     #4, -(SP)
        MOV     SP,R0
        TRAP   C#PNTB
        ADD    #12,SP
        PRINTB #CRLF                ; TERMINATE LINE
        MOV     #CRLF, -(SP)
        MOV     #1, -(SP)
        MOV     SP,R0
        TRAP   C#PNTB
        ADD    #4,SP
        POP    <R3>                ; RESTORE SAVED REGISTER
        NOP    ; [DBG] INSERT HALT FOR DEBUG
        RETURN
    
```

```

:++
:
: CALR6 - PRE-PROGRAMMED PRINT ROUTINE 6
:
: PRINT BASIC LINE FOR HOST PROGRAM ERROR WITH CONTROLLER ADDRESS
: AND DRIVE NUMBER
:
: INPUTS:
:         (R1) - DRIVE NUMBER
:         (R5) - CONTROLLER CSR
:--
    
```

```

6626 054270          CALR6: PUSH    <R3>          ; SAVE REGISTERS
6627 054272 013703 002206      MOV    TNUM,R3          ; GET TEST NUMBER
6628 054276 006303          ASL    R3              ; CONVERT TO WORD OFFSET
6629 054300          PRINTB  #BASL2,TNAMES(R3),(R5),(R1); PRINT MESSAGE
        054300 011146      MOV    (R1),-(SP)
        054302 011546      MOV    (R5),-(SP)
        054304 016346 007244      MOV    TNAMES(R3),-(SP)
        054310 012746 007437      MOV    #BASL2, -(SP)
        054314 012746 000004      MOV    #4, -(SP)
        054320 010600      MOV    SP,R0
        054322 104414      TRAP  C#PNTB
        054324 062706 000012      ADD    #12,SP
6630 054330 005737 002322      TST    KW.CSR          ; CHECK FOR CLOCK ON SYSTE
6631 054334 001420          BEQ    1$              ; IF ZERO, SKIP
6632 054336 004737 053550      CALL  RNTIME          ; GET RUN TIME
6633 054342          PRINTB  #RNTIM,RNTHH,RNTMM,RNTSS; PRINT RUN TIME
        054342 013746 002272      MOV    RNTSS, -(SP)
        054346 013746 002270      MOV    RNTMM, -(SP)
        054352 013746 002266      MOV    RNTHH, -(SP)
        054356 012746 010303      MOV    #RNTIM, -(SP)
        054362 012746 000004      MOV    #4, -(SP)
        054366 010600      MOV    SP,R0
        054370 104414      TRAP  C#PNTB
        054372 062706 000012      ADD    #12,SP
6634 054376          1$: PRINTB  #CRLF          ; TERMINATE LINE
        054376 012746 010300      MOV    #CRLF, -(SP)
        054402 012746 000001      MOV    #1, -(SP)
        054406 010600      MOV    SP,R0
        054410 104414      TRAP  C#PNTB
        054412 062706 000004      ADD    #4,SP
6635 054416          NOP          ; RESTORE SAVED REGISTER
6636 054420 000240          RETURN          ; [DBG] INSERT HALT FOR DEBUG
6637 054422 000207
6638
6639          ;++
6640          ; CALR7 - PRE-PROGRAMMED PRINT ROUTINE 7
6641          ;
6642          ; PRINT "REPLACE CONTROLLER PROCESSOR MODULE"
6643          ;--
6644
6645 054424          CALR7: PRINTX  #XFRU          ; PRINT MESSAGE
        054424 012746 016743      MOV    #XFRU, -(SP)
        054430 012746 000001      MOV    #1, -(SP)
        054434 010600      MOV    SP,R0
        054436 104415      TRAP  C#PNTX
        054440 062706 000004      ADD    #4,SP
6646 054444 000207      RETURN          ;
6647
6648          ;++
6649          ; CALR8 - PRE-PROGRAMMED PRINT ROUTINE 8
6650          ;
6651          ; PRINT "SA REGISTER CONTAINS XXXXXX"
6652          ;--
6653
6654 054446          CALR8: PRINTX  #XSA,R2          ; PRINT MESSAGE
    
```

CZUDJAO UDA50-A/KDA50-Q SUBSY E MACRO V05.03 Wednesday 02-Oct-85 16:03 Page 128-3
PRE-PROGRAMMED MESSAGE SUBROUTINES

054446	010246		MOV	R2,-(SP)	
054450	012746	016705	MOV	#XSA,-(SP)	
054454	012746	000002	MOV	#2,-(SP)	
054460	010600		MOV	SP,R0	
054462	104415		TRAP	C\$PNTX	
054464	062706	000006	ADD	#6,SP	
6655	054470	000207	RETURN		;
6656					


```

6658      .SBTTL INTERRUPT SERVICE ROUTINES
6659
6660      ;++
6661      ; NXMI - NON-EXISTANT MEMORY SERVICE ROUTINE
6662      ;
6663      ; INPUTS:
6664      ; NXMAD SET TO ZERO
6665      ; OUTPUTS:
6666      ; NXMAD SET TO ONES IF NON-EXISTANT TRAP OCCURED
6667      ;--
6668
6669      054472      BGNSRV NXMI
6670      054472      012737 177777 002264      NXMI::
6671      054500      MOV      #-1,NXMAD
6672      054500      ENDSRV
6673      054500      L10043:
6674      054500      RTI
6675
6676      ;++
6677      ; CNTSRV - CONTROLLER INTERRUPT SERVICE ROUTINE. MARKS CONTROLLER TABLE
6678      ; THAT AN INTERRUPT HAS BEEN RECEIVED.
6679      ;
6680      ; THIS ROUTINE IS CALLED BY A [JSR RO,CNTSRV] INSTRUCTION FROM WITHIN
6681      ; THE CONTROLLER TABLE. THE PC STORED IN RO IS THE ADDRESS OF THE C.FLG
6682      ; WORD IN THE CONTROLLER TABLE. THE STACK CONTAINS THE SAVED CONTENTS
6683      ; OF RO FOLLOWED BY THE INTERRUPTED PC AND PS.
6684      ;
6685      ; INPUTS:
6686      ; RO - ADDRESS OF C.FLG WORD IN CONTROLLER TABLE
6687      ; STACK - SAVED CONTENTS OF RO
6688      ; OUTPUTS:
6689      ; CT.MSG SET IN C.FLG WORD OF CONTROLLER TABLE
6690      ; RO - RESTORED FROM STACK
6691      ;--
6692
6693      054502      BGNSRV CNTSRV
6694      054502      CNTSRV::
6695      054502      052710 020000      BIS      #CT.MSG,(RO)      ; SET CT.MSG
6696      054506      POP      RO      ; RESTORE RO
6697      054506      012600      MOV      (SP)+,RO      ; POP STACK INTO RO
6698      054510      ENDSRV
6699      054510      L10044:
6700      054510      RTI
6701
6702      ;++
6703      ; KW11I - CLOCK INTERRUPT SERVICE ROUTINE
6704      ;
6705      ;--
6706
6707      054512      BGNSRV KW11I
6708      054512      KW11I::
6709      054512      062737 000001 002332      ADD      #1,KW.EL      ; COUNT THE INTERRUPT
6710      054520      005537 002334      ADC      KW.EL+2      ; PUT CARRY IN HIGH WORD
6711      054524      012777 000105 125570      MOV      #KW.OUT,#KW.CSR      ; RESTART THE CLOCK
6712      054532      ENDSRV
6713      054532      L10045:
6714      054532      RTI
    
```

6703

```

6705      .SBTTL  REPORT CODING SECTION
6706
6707      ;++
6708      ;      THE REPORT CODING SECTION CONTAINS THE CODE FOR PRINTING
6709      ;      STATISTICAL INFORMATION GATHERED BY THE DIAGNOSTIC. IT IS
6710      ;      EXECUTED BY THE OPERATOR COMMAND "PRINT" OR BY THE MACRO CALL
6711      ;      "DORPT".
6712      ;--
6713      BGNRPT
        L$RPT::
6714
6715      054534      PUSH      <R1,R2,R3,R4,R5>
        054534      010146      MOV      R1,-(SP)      ; PUSH R1 ON STACK
        054536      010246      MOV      R2,-(SP)      ; PUSH R2 ON STACK
        054540      010346      MOV      R3,-(SP)      ; PUSH R3 ON STACK
        054542      010446      MOV      R4,-(SP)      ; PUSH R4 ON STACK
        054544      010546      MOV      R5,-(SP)      ; PUSH R5 ON STACK
6716      054546      PRINTS   #RPTHDR,TNUM      ; PRINT TEST NUMBER
        054546      013746      002206      MOV      TNUM,-(SP)
        054552      012746      057300      MOV      #RPTHDR,-(SP)
        054556      012746      000002      MOV      #2,-(SP)
        054562      010600      MOV      SP,R0
        054564      104416      TRAP    C$PNTS
        054566      062706      000006      ADD      #6,SP
6717      054572      005737      002322      TST     KW.CSR      ; CHECK FOR CLOCK ON SYSTE
6718      054576      001420      BEQ     10$         ; IF ZERO, SKIP
6719      054600      004737      053550      CALL    RNTIME      ; GET RUN TIME
6720      054604      PRINTS   #RNTIM,RNTHH,RNTMM,RNTSS; PRINT RUN TIME
        054604      013746      002272      MOV      RNTSS,-(SP)
        054610      013746      002270      MOV      RNTMM,-(SP)
        054614      013746      002266      MOV      RNTHH,-(SP)
        054620      012746      010303      MOV      #RNTIM,-(SP)
        054624      012746      000004      MOV      #4,-(SP)
        054630      010600      MOV      SP,R0
        054632      104416      TRAP    C$PNTS
        054634      062706      000012      ADD      #12,SP
6721      054640      10$:      PRINTS   #CRLF      ; TERMINATE LINE
        054640      012746      010300      MOV      #CRLF,-(SP)
        054644      012746      000001      MOV      #1,-(SP)
        054650      010600      MOV      SP,R0
        054652      104416      TRAP    C$PNTS
        054654      062706      000004      ADD      #4,SP
6722      054660      012700      002250      MOV      #STIME,R0      ; GET REPORT TIMER STORAGE
6723      054664      013701      002150      MOV      SFPTBL+SO.SRI,R1 ; GET REPORT INTERVAL
6724      054670      004737      052144      CALL    SETMIN      ; SET TIME FOR NEXT REPORT
6725
6726      054674      PRINTS   #RPTI01      ; PRINT
        054674      012746      057333      MOV      #RPTI01,-(SP)
        054700      012746      000001      MOV      #1,-(SP)
        054704      010600      MOV      SP,R0
        054706      104416      TRAP    C$PNTS
        054710      062706      000004      ADD      #4,SP
6727      054714      PRINTS   #RPTI02      ; SUBSYSTEM I/O
        054714      012746      057370      MOV      #RPTI02,-(SP)
        054720      012746      000001      MOV      #1,-(SP)
  
```

	054724	010600			MOV	SP,R0			
	054726	104416			TRAP	C:PNTS			
	054730	062706	000004		ADD	#4,SP			
6728	054734				PRINTS	#RPTI03			; SUMMARY HEADING
	054734	012746	057505		MOV	#RPTI03,-(SP)			
	054740	012746	000001		MOV	#1,-(SP)			
	054744	010600			MOV	SP,R0			
	054746	104416			TRAP	C:PNTS			
	054750	062706	000004		ADD	#4,SP			
6729	054754	013705	002200		MOV	CTABS,R5			; GET ADDRESS OF 1ST CONTROLLER TABLE
6730									
6731	054760	005765	000056	20#:	TST	C.XFHR(R5)			; IF NON ZERO,
6732	054764	001011			BNE	21#			; CALCULATE MEGA BYTES
6733	054766	022765	000017	000054	CMP	#17,C.XFMR(R5)			; IF BYTE COUNT < 1 MB,
6734	054774	101033			BHI	22#			; CALCULATE KILOBYTES
6735	054776	103404			BLO	21#			
6736	055000	022765	041100	000052	CMP	#41100,C.XFLR(R5)			
6737	055006	101026			BHI	22#			
6738	055010			21#:	PUSH	<R1,R5>			; SAVE REGISTERS
6739	055014	016503	000056		MOV	C.XFHR(R5),R3			
6740	055020	016502	000054		MOV	C.XFMR(R5),R2			; CALCULATE
6741	055024	016501	000052		MOV	C.XFLR(R5),R1			; MEGA
6742	055030	012704	041100		MOV	#41100,R4			; BYTE
6743	055034	012705	000017		MOV	#17,R5			; COUNT
6744	055040	004737	047326		CALL	DIV48			
6745	055044	012737	060005	002302	MOV	#RPTMB,RPTRF			; SET M BYTE FLAG
6746	055052	010137	002300		MOV	R1,RPTRV			; SAVE REMAINING
6747	055056				POP	<R5,R1>			; RESTORE REGISTERS
6748	055062	000442			BR	25#			
6749	055064	005765	000054	22#:	TST	C.XFMR(R5)			; IF NON ZERO,
6750	055070	001004			BNE	23#			; CALCULATE KILO BYTES
6751	055072	022765	001750	000052	CMP	#1000.,C.XFLR(R5)			; IF BYTE COUNT < 1 KB,
6752	055100	101025			BHI	24#			; CALCULATE BYTES
6753	055102			23#:	PUSH	<R1,R5>			; SAVE REGISTERS
6754	055106	016503	000056		MOV	C.XFHR(R5),R3			
6755	055112	016502	000054		MOV	C.XFMR(R5),R2			; CALCULATE
6756	055116	016501	000052		MOV	C.XFLR(R5),R1			; KILO
6757	055122	012704	001750		MOV	#1000.,R4			; BYTE
6758	055126	005005			CLR	R5			; COUNT
6759	055130	004737	047326		CALL	DIV48			
6760	055134	012737	060003	002302	MOV	#RPTKB,RPTRF			; SET M BYTE FLAG
6761	055142	010137	002300		MOV	R1,RPTRV			; SAVE REMAINING
6762	055146				POP	<R5,R1>			; RESTORE REGISTERS
6763	055152	000406			BR	25#			
6764	055154	012737	060001	002302	MOV	#RPTB,RPTRF			; SET BYTE FLAG
6765	055162	016537	000052	002300	MOV	C.XFLR(R5),RPTRV			
6766	055170	005765	000050	25#:	TST	C.XFMR(R5)			; IF NON ZERO,
6767	055174	001011			BNE	26#			; CALCULATE MEGA BYTES
6768	055176	022765	000017	000046	CMP	#17,C.XFMW(R5)			; IF BYTE COUNT < 1 MB,
6769	055204	101033			BHI	27#			; CALCULATE KILOBYTES
6770	055206	103404			BLO	26#			
6771	055210	022765	041100	000044	CMP	#41100,C.XFLW(R5)			
6772	055216	101026			BHI	27#			
6773	055220			26#:	PUSH	<R1,R5>			; SAVE REGISTERS
6774	055224	016503	000050		MOV	C.XFMW(R5),R3			

```

6775 055230 016502 000046      MOV      C.XFMW(R5),R2      ; CALCULATE
6776 055234 016501 000044      MOV      C.XFLW(R5),R1      ; MEGA
6777 055240 012704 041100      MOV      #41100,R4          ; BYTE
6778 055244 012705 000017      MOV      #17,R5             ; COUNT
6779 055250 004737 047326      CALL     DIV48              ;
6780 055254 012737 060005 002276  MOV      #RPTMB,RPTWF      ; SET M BYTE FLAG
6781 055262 010137 002274      MOV      R1,RPTWV          ; SAVE REMAINING
6782 055266      POP      <R5,R1>          ; RESTORE REGISTERS
6783 055272 000442      BR       29$               ;
6784 055274 005765 000046 27$:  TST      C.XFMW(R5)        ; IF NON ZERO,
6785 055300 001004      BNE     271$              ; CALCULATE KILO BYTES
6786 055302 022765 001750 000044  CMP      #1000.,C.XFLW(R5) ; IF BYTE COUNT < 1 KB,
6787 055310 101025      BHI     28$               ; CALCULATE BYTES
6788 055312      PUSH    <R1,R5>          ; SAVE REGISTERS
6789 055316 016503 000050      MOV      C.XFMW(R5),R3      ;
6790 055322 016502 000046      MOV      C.XFMW(R5),R2      ; CALCULATE
6791 055326 016501 000044      MOV      C.XFLW(R5),R1      ; KILO
6792 055332 012704 001750      MOV      #1000.,R4          ; BYTE
6793 055336 005005      CLR     R5                 ; COUNT
6794 055340 004737 047326      CALL     DIV48              ;
6795 055344 012737 060003 002276  MOV      #RPTKB,RPTWF      ; SET M BYTE FLAG
6796 055352 010137 002274      MOV      R1,RPTWV          ; SAVE REMAINING
6797 055356      POP      <R5,R1>          ; RESTORE REGISTERS
6798 055362 000406      BR       29$               ;
6799 055364 012737 060001 002276 28$:  MOV      #RPTB,RPTWF      ;
6800 055372 016537 000052 002274  MOV      C.XFLR(R5),RPTWV   ;
6801      BR       29$               ;
6802 055400 016502 000062 29$:  MOV      C.UID+2(R5),R2     ; GET
6803 055404 016503 000064      MOV      C.UID+4(R5),R3     ; UNIT
6804 055410 016501 000060      MOV      C.UID(R5),R1       ; ID
6805 055414 012704 000017      MOV      #15.,R4           ; GET CHARACTER COUNT FOR STRING
6806 055420 004737 047472      CALL     ITOA               ; CONVERT BINARY TO ASCII
6807 055424 116503 000066      MOVB    C.UID+6(R5),R3     ; GET MODEL TYPE BYTE
6808 055430 116504 000067      MOVB    C.UID+7.(R5),R4    ; GET CLASS TYPE BYTE
6809
6810 055434      PRINTS #RPTIOC.(R5),R3,R4,#TEMP,RPTWV,RPTWF,RPTRV,RPTRF
6811 055434 013746 002302      MOV      RPTRF,-(SP)
6812 055440 013746 002300      MOV      RPTRV,-(SP)
6813 055444 013746 002276      MOV      RPTWF,-(SP)
6814 055450 013746 002274      MOV      RPTWV,-(SP)
6815 055454 012746 002212      MOV      #TEMP,-(SP)
6816 055460 010446      MOV      R4,-(SP)
6817 055462 010346      MOV      R3,-(SP)
6818 055464 011546      MOV      (R5),-(SP)
6819 055466 012746 057623      MOV      #RPTIOC,-(SP)
6820 055472 012746 000011      MOV      #11,-(SP)
6821 055476 010600      MOV      SP,R0
6822 055500 104416      TRAP    C#PNTS
6823 055502 062706 000024      ADD     #24,SP
6824
6811      MOV      R5,R4           ; GET ADDRESS OF CONTROLLER TABLE
6812      ADD     #C.DRO,R4      ; POINT TO DRIVE TABLE POINTERS
6813      MOV      #4.,R3       ; GET COUNT OF DRIVES
6814      MOV      (R4)+,R1    ; LOOK AT POINTER
6815 30$:
6816      BNE     40$

```

6817	055524	000137	056734		JMP	90\$; GO TO NEXT CONTROLLER IF NO TABLE
6818	055530			40\$:	PUSH	<R3,R4,R5>				; SAVE REGISTERS
	055530	010346			MOV	R3,-(SP)				; PUSH R3 ON STACK
	055532	010446			MOV	R4,-(SP)				; PUSH R4 ON STACK
	055534	010546			MOV	R5,-(SP)				; PUSH R5 ON STACK
6819	055536	005761	000074		TST	D.XFHR(R1)				; IF NON ZERO,
6820	055542	001011			BNE	42\$; CALCULATE MEGA BYTES
6821	055544	022761	000017	000072	CMP	#17,D.XFMR(R1)				; IF BYTE COUNT < 1 MB,
6822	055552	101031			BHI	43\$; CALCULATE KILOBYTES
6823	055554	103404			BLO	42\$				
6824	055556	022761	041100	000070	CMP	#41100,D.XFLR(R1)				
6825	055564	101024			BHI	43\$				
6826	055566			42\$:	PUSH	<R1>				; SAVE REGISTERS
	055566	010146			MOV	R1,-(SP)				; PUSH R1 ON STACK
6827	055570	016103	000074		MOV	D.XFHR(R1),R3				
6828	055574	016102	000072		MOV	D.XFMR(R1),R2				; CALCULATE
6829	055600	016101	000070		MOV	D.XFLR(R1),R1				; MEGA
6830	055604	012704	041100		MOV	#41100,R4				; BYTE
6831	055610	012705	000017		MOV	#17,R5				; COUNT
6832	055614	004737	047326		CALL	DIV48				
6833	055620	012737	060005	002302	MOV	#RPTMB,RPTRF				; SET M BYTE FLAG
6834	055626	010137	002300		MOV	R1,RPTRV				; SAVE REMAINING
6835	055632				POP	<R1>				; RESTORE REGISTERS
	055632	012601			MOV	(SP)+,R1				; POP STACK INTO R1
6836	055634	000440			BR	50\$				
6837	055636	005761	000072	43\$:	TST	D.XFMR(R1)				; IF NON ZERO,
6838	055642	001004			BNE	44\$; CALCULATE KILO BYTES
6839	055644	022761	001750	000070	CMP	#1000.,D.XFLR(R1)				; IF BYTE COUNT < 1 KB,
6840	055652	101023			BHI	45\$; CALCULATE BYTES
6841	055654			44\$:	PUSH	<R1>				; SAVE REGISTERS
	055654	010146			MOV	R1,-(SP)				; PUSH R1 ON STACK
6842	055656	016103	000074		MOV	D.XFHR(R1),R3				
6843	055662	016102	000072		MOV	D.XFMR(R1),R2				; CALCULATE
6844	055666	016101	000070		MOV	D.XFLR(R1),R1				; KILO
6845	055672	012704	001750		MOV	#1000.,R4				; BYTE
6846	055676	005005			CLR	R5				; COUNT
6847	055700	004737	047326		CALL	DIV48				
6848	055704	012737	060003	002302	MOV	#RPTKB,RPTRF				; SET M BYTE FLAG
6849	055712	010137	002300		MOV	R1,RPTRV				; SAVE REMAINING
6850	055716				POP	<R1>				; RESTORE REGISTERS
	055716	012601			MOV	(SP)+,R1				; POP STACK INTO R1
6851	055720	000406			BR	50\$				
6852	055722	012737	060001	002302	MOV	#RPTB,RPTRF				
6853	055730	016137	000070	002300	MOV	D.XFLR(R1),RPTRV				
6854	055736	005761	000066	50\$:	TST	D.XFMW(R1)				; IF NON ZERO,
6855	055742	001011			BNE	52\$; CALCULATE MEGA BYTES
6856	055744	022761	000017	000064	CMP	#17,D.XFMW(R1)				; IF BYTE COUNT < 1 MB,
6857	055752	101031			BHI	53\$; CALCULATE KILOBYTES
6858	055754	103404			BLO	52\$				
6859	055756	022761	041100	000062	CMP	#41100,D.XFLW(R1)				
6860	055764	101024			BHI	53\$				
6861	055766			52\$:	PUSH	<R1>				; SAVE REGISTERS
	055766	010146			MOV	R1,-(SP)				; PUSH R1 ON STACK
6862	055770	016103	000066		MOV	D.XFMW(R1),R3				
6863	055774	016102	000064		MOV	D.XFMW(R1),R2				; CALCULATE

6864	056000	016101	000062		MOV	D.XFLW(R1),R1	:	MEGA
6865	056004	012704	041100		MOV	#41100,R4	:	BYTE
6866	056010	012705	000017		MOV	#17,R5	:	COUNT
6867	056014	004737	047326		CALL	DIV48	:	
6868	056020	012737	060005	002276	MOV	#RPTMB,RPTWF	:	SET M BYTE FLAG
6869	056026	010137	002274		MOV	R1,RPTWV	:	SAVE REMAINING
6870	056032				POP	<R1>	:	RESTORE REGISTERS
	056032	012601			MOV	(SP)+,R1	:	POP STACK INTO R1
6871	056034	000440			BR	60#	:	
6872	056036	005761	000064	53#:	TST	D.XFMW(R1)	:	IF NON ZERO,
6873	056042	001004			BNE	54#	:	CALCULATE KILO BYTES
6874	056044	022761	001750	000062	CMP	#1000.,D.XFLW(R1)	:	IF BYTE COUNT < 1 KB,
6875	056052	101023			BHI	55#	:	CALCULATE BYTES
6876	056054			54#:	PUSH	<R1>	:	SAVE REGISTERS
	056054	010146			MOV	R1,-(SP)	:	PUSH R1 ON STACK
6877	056056	016103	000066		MOV	D.XFMW(R1),R3	:	
6878	056062	016102	000064		MOV	D.XFMW(R1),R2	:	CALCULATE
6879	056066	016101	000062		MOV	D.XFLW(R1),R1	:	KILO
6880	056072	012704	001750		MOV	#1000.,R4	:	BYTE
6881	056076	005005			CLR	R5	:	COUNT
6882	056100	004737	047326		CALL	DIV48	:	
6883	056104	012737	060003	002276	MOV	#RPTKB,RPTWF	:	SET M BYTE FLAG
6884	056112	010137	002274		MOV	R1,RPTWV	:	SAVE REMAINING
6885	056116				POP	<R1>	:	RESTORE REGISTERS
	056116	012601			MOV	(SP)+,R1	:	POP STACK INTO R1
6886	056120	000406			BR	60#	:	
6887	056122	012737	060001	002276	MOV	#RPTB,RPTWF	:	
6888	056130	016137	000062	002274	MOV	D.XFLW(R1),RPTWV	:	
6889	056136	005761	000102	60#:	TST	D.XFHA(R1)	:	IF NON ZERO,
6890	056142	001011			BNE	62#	:	CALCULATE MEGA BYTES
6891	056144	022761	000017	000100	CMP	#17,D.XFMA(R1)	:	IF BYTE COUNT < 1 MB,
6892	056152	101031			BHI	63#	:	CALCULATE KILOBYTES
6893	056154	103404			BLO	62#	:	
6894	056156	022761	041100	000076	CMP	#41100,D.XFLA(R1)	:	
6895	056164	101024			BHI	63#	:	
6896	056166			62#:	PUSH	<R1>	:	SAVE REGISTERS
	056166	010146			MOV	R1,-(SP)	:	PUSH R1 ON STACK
6897	056170	016103	000102		MOV	D.XFHA(R1),R3	:	
6898	056174	016102	000100		MOV	D.XFMA(R1),R2	:	CALCULATE
6899	056200	016101	000076		MOV	D.XFLA(R1),R1	:	MEGA
6900	056204	012704	041100		MOV	#41100,R4	:	BYTE
6901	056210	012705	000017		MOV	#17,R5	:	COUNT
6902	056214	004737	047326		CALL	DIV48	:	
6903	056220	012737	060005	002306	MOV	#RPTMB,RPTAF	:	SET M BYTE FLAG
6904	056226	010137	002304		MOV	R1,RPTAV	:	SAVE REMAINING
6905	056232				POP	<R1>	:	RESTORE REGISTERS
	056232	012601			MOV	(SP)+,R1	:	POP STACK INTO R1
6906	056234	000440			BR	70#	:	
6907	056236	005761	000100	63#:	TST	D.XFMA(R1)	:	IF NON ZERO,
6908	056242	001004			BNE	64#	:	CALCULATE KILO BYTES
6909	056244	022761	001750	000076	CMP	#1000.,D.XFLA(R1)	:	IF BYTE COUNT < 1 KB,
6910	056252	101023			BHI	65#	:	CALCULATE BYTES
6911	056254			64#:	PUSH	<R1>	:	SAVE REGISTERS
	056254	010146			MOV	R1,-(SP)	:	PUSH R1 ON STACK
6912	056256	016103	000102		MOV	D.XFHA(R1),R3	:	

CZUDJAO UDA50-A/KDA50-Q SUBSY E MACRO V05.03 Wednesday 02-Oct-85 16:03 Page 130-5
 REPORT CODING SECTION

6913	056262	016102	000100		MOV	D.XFMA(R1),R2	:	CALCULATE
6914	056266	016101	000076		MOV	D.XFLA(R1),R1	:	KILO
6915	056272	012704	001750		MOV	#1000.,R4	:	BYTE
6916	056276	005005			CLR	R5	:	COUNT
6917	056300	004737	047326		CALL	DIV48	:	
6918	056304	012737	060003	002306	MOV	#RPTKB,RPTAF	:	SET M BYTE FLAG
6919	056312	010137	002304		MOV	R1,RPTAV	:	SAVE REMAINING
6920	056316				POP	<R1>	:	RESTORE REGISTERS
	056316	012601			MOV	(SP)+,R1	:	POP STACK INTO R1
6921	056320	000406			BR	70\$:	
6922	056322	012737	060001	002306	MOV	#RPTB,RPTAF	:	
6923	056330	016137	000076	002304	MOV	D.XFLA(R1),RPTAV	:	
6924	056336	005761	000110		TST	D.XFHC(R1)	:	IF NON ZERO,
6925	056342	001011			BNE	72\$:	CALCULATE MEGA BYTES
6926	056344	022761	000017	000106	CMP	#17,D.XFMC(R1)	:	IF BYTE COUNT < 1 MB,
6927	056352	101031			BHI	73\$:	CALCULATE KILOBYTES
6928	056354	103404			BLO	72\$:	
6929	056356	022761	041100	000104	CMP	#41100,D.XFLC(R1)	:	
6930	056364	101024			BHI	73\$:	
6931	056366				PUSH	<R1>	:	SAVE REGISTERS
	056366	010146			MOV	R1,-(SP)	:	PUSH R1 ON STACK
6932	056370	016103	000110		MOV	D.XFHC(R1),R3	:	
6933	056374	016102	000106		MOV	D.XFMC(R1),R2	:	CALCULATE
6934	056400	016101	000104		MOV	D.XFLC(R1),R1	:	MEGA
6935	056404	012704	041100		MOV	#41100,R4	:	BYTE
6936	056410	012705	000017		MOV	#17,R5	:	COUNT
6937	056414	004737	047326		CALL	DIV48	:	
6938	056420	012737	060005	002312	MOV	#RPTMB,RPTCF	:	SET M BYTE FLAG
6939	056426	010137	002310		MOV	R1,RPTCV	:	SAVE REMAINING
6940	056432				POP	<R1>	:	RESTORE REGISTERS
	056432	012601			MOV	(SP)+,R1	:	POP STACK INTO R1
6941	056434	000440			BR	80\$:	
6942	056436	005761	000106		TST	D.XFMC(R1)	:	IF NON ZERO,
6943	056442	001004			BNE	74\$:	CALCULATE KILO BYTES
6944	056444	022761	001750	000104	CMP	#1000.,D.XFLC(R1)	:	IF BYTE COUNT < 1 KB,
6945	056452	101023			BHI	75\$:	CALCULATE BYTES
6946	056454				PUSH	<R1>	:	SAVE REGISTERS
	056454	010146			MOV	R1,-(SP)	:	PUSH R1 ON STACK
6947	056456	016103	000110		MOV	D.XFHC(R1),R3	:	
6948	056462	016102	000106		MOV	D.XFMC(R1),R2	:	CALCULATE
6949	056466	016101	000104		MOV	D.XFLC(R1),R1	:	KILO
6950	056472	012704	001750		MOV	#1000.,R4	:	BYTE
6951	056476	005005			CLR	R5	:	COUNT
6952	056500	004737	047326		CALL	DIV48	:	
6953	056504	012737	060003	002312	MOV	#RPTKB,RPTCF	:	SET M BYTE FLAG
6954	056512	010137	002310		MOV	R1,RPTCV	:	SAVE REMAINING
6955	056516				POP	<R1>	:	RESTORE REGISTERS
	056516	012601			MOV	(SP)+,R1	:	POP STACK INTO R1
6956	056520	000406			BR	80\$:	
6957	056522	012737	060001	002312	MOV	#RPTB,RPTCF	:	
6958	056530	016137	000104	002310	MOV	D.XFLC(R1),RPTCV	:	
6959							:	
6960	056536				PUSH	<R1>	:	
	056536	010146			MOV	R1,-(SP)	:	PUSH R1 ON STACK
6961	056540	016102	000124		MOV	D.UID*2(R1),R2	:	GET


```

6962 056544 016103 000126      MOV      D.UID+4(R1),R3      ; UNIT
6963 056550 016101 000122      MOV      D.UID(R1),R1      ; ID
6964 056554 012704 000017      MOV      #15,R4           ; GET CHARACTER COUNT FOR STRING
6965 056560 004737 047472      CALL     ITOA             ; CONVERT BINARY TO ASCII
6966 056564      POP      <R1>             ; RESTORE SAVED REGISTERS
        056564 012601      MOV      (SP)+,R1         ; POP STACK INTO R1
6967 056566 116103 000130      MOV      D.UID+6(R1),R3    ; GET MODEL TYPE BYTE
6968 056572 116104 000131      MOV      D.UID+7.(R1),R4   ; GET CLASS TYPE BYTE
6969
6970 056576      PRINTS  #RPTIOD,D.DRV(R1),R3,R4,#TEMP,RPTWV,RPTWF
        056576 013746 002276      MOV      RPTWF,-(SP)
        056602 013746 002274      MOV      RPTWV,-(SP)
        056606 012746 002212      MOV      #TEMP,-(SP)
        056612 010446      MOV      R4,-(SP)
        056614 010346      MOV      R3,-(SP)
        056616 016146 000000      MOV      D.DRV(R1),-(SP)
        056622 012746 057674      MOV      #RPTIOD,-(SP)
        056626 012746 000007      MOV      #7,-(SP)
        056632 010600      MOV      SP,R0
        056634 104416      TRAP    C#PNTS
        056636 062706 000020      ADD     #20,SP
6971 056642      PRINTS  #RPTIOE,RPTRV,RPTRF,RPTAV,RPTAF,RPTCV,RPTCF,D.ECCC(R1)
        056642 016146 000120      MOV      D.ECCC(R1),-(SP)
        056646 013746 002312      MOV      RPTCF,-(SP)
        056652 013746 002310      MOV      RPTCV,-(SP)
        056656 013746 002306      MOV      RPTAF,-(SP)
        056662 013746 002304      MOV      RPTAV,-(SP)
        056666 013746 002302      MOV      RPTRF,-(SP)
        056672 013746 002300      MOV      RPTRV,-(SP)
        056676 012746 057743      MOV      #RPTIOE,-(SP)
        056702 012746 000010      MOV      #10,-(SP)
        056706 010600      MOV      SP,R0
        056710 104416      TRAP    C#PNTS
        056712 062706 000022      ADD     #22,SP
6972 056716      POP     <R5,R4,R3>       ; RESTORE SAVED REGISTERS
6973 056724 005303      DEC     R3                ; COUNT THE DRIVE TABLES
6974 056726 003402      BLE    90$               ;
6975 056730 000137 055520      JMP     30$               ; REPEAT FOR ALL DRIVE TABLES
6976 056734 062705 000170      90$:  ADD     #C.SIZE,R5   ; GO TO
6977 056740 005715      TST    (R5)              ; NEXT
6978 056742 001402      BEQ    RPTDES            ; CONTROLLER
6979 056744 000137 054760      JMP     20$               ; TABLE
6980
6981 056750      PRINTS  #RPTDE1          ; PRINT
        056750 012746 060007      MOV      #RPTDE1,-(SP)
        056754 012746 000001      MOV      #1,-(SP)
        056760 010600      MOV      SP,R0
        056762 104416      TRAP    C#PNTS
        056764 062706 000004      ADD     #4,SP
6982 056770      PRINTS  #RPTDE2          ; DRIVE ERROR
        056770 012746 060042      MOV      #RPTDE2,-(SP)
        056774 012746 000001      MOV      #1,-(SP)
        057000 010600      MOV      SP,R0
        057002 104416      TRAP    C#PNTS
        057004 062706 000004      ADD     #4,SP
    
```

				PRINTS	#RPTDE3	:	SUMMARY HEADINGS
6983	057010			MOV	#RPTDE3, -(SP)		
	057010	012746	060145	MOV	#1, -(SP)		
	057014	012746	000001	MOV	SP, R0		
	057020	010600		TRAP	C:PNTS		
	057022	104416		ADD	#4, SP		
	057024	062706	000004	MOV	CTABS, R5		: GET ADDRESS OF 1ST CONTROLLER TABLE
6984	057030	013705	002200				
6985							
6986	057034	010504		1\$: MOV	R5, R4		: GET ADDRESS OF CONTROLLER TABLE
6987							
6988	057036	062704	000016	ADD	#C.DRO, R4		: POINT TO DRIVE TABLE POINTERS
6989	057042	012703	000004	MOV	#4, R3		: GET COUNT OF DRIVES
6990	057046	012401		2\$: MOV	(R4)+, R1		: LOOK AT POINTER
6991	057050	001477		BEQ	7\$: GO TO NEXT IF NO TABLE
6992	057052			PUSH	<R4>		: SAVE REGISTERS
6993	057054	010104		MOV	R1, R4		: GET POINTER TO VOLUME
6994	057056	062704	000132	ADD	#D.VSN, R4		: SERIAL NUMBER
6995	057062	004737	047552	CALL	BLDSTR		: CONVERT INTEGER TO DECIMAL ASCII
6996	057066			POP	<R4>		: RESTORE SAVED REGISTERS
6997	057070	016137	000002	MOV	D.UNIT(R1), RPTLUN		: GET LOGICAL
6998	057076	042737	177700	BIC	#C<DT.UNIT>, RPTLUN		: UNIT NUMBER OF DEVICE
6999	057104	005761	000002	TST	D.UNIT(R1)		: SEE IF DRIVE AVAILABLE
7000	057110	100027		BPL	5\$: IF SO, SKIP (BIT 15 = 0)
7001	057112				ASSUME DT.AVL EQ BIT15		
7002	057112			PRINTS	#RPTDED, RPTLUN, D.DRV(R1), #TEMP, #RPTSTA, D.HERR(R1), D.CERR(R1), D.SERR(R1)		
	057112	016146	000114	MOV	D.SERR(R1), -(SP)		
	057116	016146	000116	MOV	D.CERR(R1), -(SP)		
	057122	016146	000112	MOV	D.HERR(R1), -(SP)		
	057126	012746	060327	MOV	#RPTSTA, -(SP)		
	057132	012746	002212	MOV	#TEMP, -(SP)		
	057136	016146	000000	MOV	D.DRV(R1), -(SP)		
	057142	013746	002274	MOV	RPTLUN, -(SP)		
	057146	012746	060253	MOV	#RPTDED, -(SP)		
	057152	012746	000010	MOV	#10, -(SP)		
	057156	010600		MOV	SP, R0		
	057160	104416		TRAP	C:PNTS		
	057162	062706	000022	ADD	#22, SP		
7003	057166	000426		BR	6\$		
7004	057170			5\$: PRINTS	#RPTDED, RPTLUN, D.DRV(R1), #TEMP, #RPTSTB, D.HERR(R1), D.CERR(R1), D.SERR(R1)		
	057170	016146	000114	MOV	D.SERR(R1), -(SP)		
	057174	016146	000116	MOV	D.CERR(R1), -(SP)		
	057200	016146	000112	MOV	D.HERR(R1), -(SP)		
	057204	012746	060341	MOV	#RPTSTB, -(SP)		
	057210	012746	002212	MOV	#TEMP, -(SP)		
	057214	016146	000000	MOV	D.DRV(R1), -(SP)		
	057220	013746	002274	MOV	RPTLUN, -(SP)		
	057224	012746	060253	MOV	#RPTDED, -(SP)		
	057230	012746	000010	MOV	#10, -(SP)		
	057234	010600		MOV	SP, R0		
	057236	104416		TRAP	C:PNTS		
	057240	062706	000022	ADD	#22, SP		
7005							
7006	057244	005303		6\$: DEC	R3		: COUNT THE DRIVE TABLES
7007	057246	003277		BGT	2\$: REPEAT FOR ALL DRIVE TABLES
7008	057250	062705	000170	7\$: ADD	#C.SIZE, R5		: GO TO

```

7009 057254 005715          TST      (R5)          ; NEXT
7010 057256 001266          BNE      1$          ; CONTROLLER TABLE
7011 057260                POP      <R5,R4,R3,R2,R1> ; RESTORE SAVED REGISTERS
7012 057272 000240          NOP                    ; [DBG] INSERT HALT FOR DEBUG
7013
7014 057274                EXIT     RPT
       057274 000167          .WORD   J$JMP
       057276 001054          .WORD   L10046-2-.
7015
7016 057300          045    116    045  RPTHDR: .ASCIZ \N%A TEST #D1%A IN PROGRESS\
7017 057333          045    116    045  RPTIO1: .ASCIZ \N%ASUBSYSTEM I/O SUMMARY:#N\
7018 057370          045    101    103  RPTIO2: .ASCIZ \ACTRLR DRIVE          UNIQUE          BYTES  BYTES  BYTES  BYTES  ECC#N
\
7019 057505          045    101    040  RPTIO3: .ASCIZ \A CSR NAME          IDENTIFIER          WRITTEN READ  ACCESSED COMPARED DATA#
N
7020 057623          045    116    045  RPTIOC: .ASCIZ \N#06#S6#Z2#S1#Z2#S1#T#S2#D5#T#S2#D5#T#N\
7021 057674          045    123    066  RPTIOD: .ASCIZ \S6#ADU#Z3#S1#Z2#S1#Z2#S1#T#S2#D5#T#S2\
7022 057743          045    104    065  RPTIOE: .ASCIZ \D5#T#S2#D5#T#S2#D5#T#S2#D5#N\
7023
7024 060001          040    000          RPTB: .ASCIZ \ \
7025 060003          113    000          RPTKB: .ASCIZ \K\
7026 060005          115    000          RPTMB: .ASCIZ \M\
7027
7028 060007          045    116    045  RPTDE1: .ASCIZ \N#ADRIVE ERROR SUMMARY:#N\
7029 060042          045    101    125  RPTDE2: .ASCIZ \AUNIT DRIVE VOLUME          HARD/FATAL DATA CHECK
7030 060145          045    101    040  RPTDE3: .ASCIZ \A # NAME SERIAL #          ERRORS          ERRORS          ERRORS#N\
7031 060253          045    104    063  RPTDED: .ASCIZ \D3#S2#ADU#Z3#S2#T#S2#T#S4#D5#S6#D5#S6#D5#N\
7032 060327          050    104    122  RPTSTA: .ASCIZ \ (DROPPED) \
7033 060341          040    040    040  RPTSTB: .ASCIZ \
7034
7035
7036 060354                ENDRPT
       060354                L10046: TRAP  C#RPT
       060354 104425
    
```

CZUDJAO UDA50-A/KDA50-Q SUBSY E MACRO V05.03 Wednesday 02-Oct-85 16:03 Page 131
PROTECTION TABLE

```
7038      .SBTTL  PROTECTION TABLE
7039
7040      ;++
7041      ;      THIS TABLE IS USED BY THE RUN TIME SERVICES
7042      ;      TO PROTECT THE LOAD MEDIA.
7043      ;--
7044
7045      BGNPROT
060356    L$PROT::
060356
7046
7047      060356    000000      .WORD  0      ; P-TABLE OFFSET FOR CSR ADDRESS
7048      060360    177777      .WORD  -1     ; P-TABLE OFFSET FOR MASSBUS ADDRESS
7049      060362    000002      .WCRD  2     ; P-TABLE OFFSET FOR DRIVE NUMBER
7050
7051      060364
7052      ENDPROT
```



```

060410 012700 000037      MOV    #EF.RES,R0
060414 104447      TRAP   C$REFG
7105 060416      BNCOMplete    2$      ; BRANCH TO 2$ IF NOT, ELSE
060416 103004      BCC    2$
7106 060420 012737 000004 002204      MOV    #IREST,IFLAGS ; SET RESTART BIT IN FLAG.
7107 060426 000511      BR     INIT1
7108
7109 060430      2$:  REAFEF #EF.CON      ; HERE FROM CONTINUE COMMAND?
060430 012700 000036      MOV    #EF.CON,R0
060434 104447      TRAP   C$REFG
7110 060436      BNCOMplete    4$      ; IF NOT, DO END OF PASS CODE
060436 103003      BCC    4$
7111 060440 052737 000002 002204      BIS    #ICONT,IFLAGS ; SET CONTINUE BIT IN FLAG.
7112
7113      ;
7114      ;
7115      ;
7116      ;
7117 060446 013705 002200      4$:  MOV    CTABS,R5      ; GET ADDRESS OF 1ST CONTROLLER TABLE
7118 060452 052765 100000 000014 5$:  BIS    #CT.AVL,C.FLG(R5) ; SET CONTROLLER TABLE NOT AVAILABLE
7119 060460 005065 000160      CLR    C.CMFL(R5)      ; RESET COMMAND
7120 060464 005065 000162      CLR    C.CMBL(R5)      ; LIST POINTERS
7121 060470 005065 000164      CLR    C.TBSF(R5)      ; RESET TBS LIST
7122 060474 005065 000166      CLR    C.TBSB(R5)      ; POINTERS
7123 060500 010502      MOV    R5,R2      ; GET POINTER TO DRIVE TABLES
7124 060502 062702 000016      ADD    #C.DRO,R2      ;
7125 060506 012703 000004      MOV    #4,R3      ; GET NUMBER OF DRIVES PER CONTROLLER
7126 060512 012200      6$:  MOV    (R2)+,R0      ; SEE IF THIS DRIVE HAS A TABLE,
7127 060514 001403      BEQ    7$      ; BRANCH IF NOT, ELSE
7128 060516 052760 100000 000002      BIS    #DT.AVL,D.UNIT(R0) ; SET DRIVE TABLE NOT AVAILABLE.
7129 060524 005303      7$:  DEC    R3      ; GET NEXT DRIVE IN CONTROLLER TABLE.
7130 060526 001371      BNE    6$      ; BRANCH IF NO DRIVES, ELSE
7131 060530 062705 000170      ADD    #C.SIZE,R5      ; MOVE TO NEXT CONTROLLER TABLE
7132 060534 005715      TST    (R5)      ; IS THERE A NEXT ONE?
7133 060536 001345      BNE    5$      ; IF SO, CLEAR THE BITS THERE
7134
7135      ;
7136      ;
7137      ;
7138 060540 005003      CLR    R3      ; START WITH LOGICAL UNIT 0
7139 060542      8$:  GPHARD R3,R0      ; GET POINTER TO IT'S P-TABLE
060542 010300      MOV    R3,R0
060544 104442      TRAP   C$GPHRD
7140 060546      BNCOMplete    12$     ; BRANCH TO 12$ IF NOT AVAILABLE
060546 103033      BCC    12$
7141 060550 013705 002200      9$:  MOV    CTABS,R5      ; GET ADDRESS OF 1ST CONTROLLER TABLE
7142 060554 021015      CMP    (R0),(R5)      ; SEE IF CSR ADDRESSES ARE THE SAME,
7143 060556 001410      BEQ    11$      ; BRANCH IF SO, ELSE
7144 060560 062705 000170      ADD    #C.SIZE,R5      ; LOOK AT NEXT CONTROLLER TABLE.
7145 060564 005715      TST    (R5)      ; ANY MORE CONTROLLER TABLES?
7146 060566 001372      BNE    9$      ; BRANCH IF SO, ELSE
7147 060570 012701 060566 10$:  MOV    #-2,R1      ; SAVE CURRENT LOCATION
7148 060574 000137 024310      JMP    BADMEM      ; PRINT SYSTEM FATAL ERROR
7149
7150 060600 016001 000002      11$: MOV    H.DRV(R0),R1 ; GET DRIVE NUMBER FROM P-TABLE

```

CZUDJAO UDA50-A/KDA50-Q SUBSY E MACRO V05.03 Wednesday 02-Oct-85 16:03 Page 132-2
INITIALIZE SECTION

```

7151 060604 004737 047164          CALL  GTDRV      ; FIND THE DRIVE TABLE ADDRESS
7152 060610 103767                   BCS   10$        ; BRANCH IF NOT FOUND, ELSE
7153 060612 042765 100000 000014    BIC   #CT.AVL,C.FLG(R5) ; CLEAR NOT AVAILABLE FLAG
7154 060620 042761 147000 000002    BIC   #DT.CLR,D.UNIT(R1) ; CLEAR TEMPORARY DRIVE FLAGS
7155 060626 005061 000060           CLR   D.CCNT(R1)   ; ZERO "COMPARE HOST DATA" COUNT
7156 060632 005061 000056           CLR   D.WCNT(R1)   ; ZERO OUTSTANDING WRITE COUNT
7157 060636 005203                   INC   R3          ; INCREMENT TO NEXT UNIT IN P-TABLE
7158 060640 020337 002012           CMP   R3,L$UNIT   ; SEE IF ALL P-TABLES CHECKED,
7159 060644 002736                   BLT   8$          ; BRANCH IF NOT, ELSE
7160 060646 000137 062062           JMP   INIT7       ; RE-INIT DATA STRUCTURES
7161                                     ;
7162                                     ; INITIALIZE KW11 CLOCK, FREE MEMORY AND IP ADDRESS TABLE
7163                                     ; DURING START OR RESTART COMMAND ONLY
7164                                     ;
7165 060652 005037 002332           INIT1: CLR  KW.EL      ; CLEAR ELAPSED TIME
7166 060656 005037 002334           CLR  KW.EL+2     ;
7167 060662                   CLOCK L,RO          ; SEE IF L-CLOCK PRESENT
7168 060662 012700 000114           MOV  #L,RO
7169 060666 104462                   TRAP C$CLCK
7170 060670                   BCOMPLETE 2$      ;
7171 060670 103417                   BCS   2$          ;
7172 060672                   CLOCK P,RO          ; SEE IF P-CLOCK PRESENT
7173 060672 012700 000120           MOV  #P,RO
7174 060676 104462                   TRAP C$CLCK
7175 060700                   BCOMPLETE 2$      ;
7176 060700 103413                   BCS   2$          ;
7177 060702 005037 002322           CLR  KW.CSR      ; IF NEITHER, CLEAR CSR STORAGE WORD
7178 060706                   PRINTF #NOCLOCK   ; PRINT "NO CLOCK" MESSAGE
7179 060706 012746 011071           MOV  #NOCLOCK,-(SP)
7180 060712 012746 000001           MOV  #1,-(SP)
7181 060716 010600                   MOV  SP,RO
7182 060720 104417                   TRAP C$PNTF
7183 060722 062706 000004           ADD  #4,SP
7184 060726 000435                   BR   3$          ;
7185 060730 012037 002322           2$:  MOV  (RO)+,KW.CSR ; STORE DATA RETURNED
7186 060734 012037 002324           MOV  (RO)+,KW.BRL ;
7187 060740 012037 002326           MOV  (RO)+,KW.VEC ;
7188 060744 011037 002330           MOV  (RO),KW.HZ  ;
7189 060750 011001                   MOV  (RO),R1     ; CALCULATE
7190 060752 012702 000074           MOV  #60,R2     ; TICKS PER
7191 060756 004737 047420           CALL MULT        ; MINUTE
7192 060762 010337 002336           MOV  R3,KW.60   ;
7193 060766                   SETVEC KW.VEC,#KW11I,#PRI07 ; SETUP KW11 VECTOR ADDRESS
7194 060766 012746 000340           MOV  #PRI07,-(SP)
7195 060772 012746 054512           MOV  #KW11I,-(SP)
7196 060776 013746 002326           MOV  KW.VEC,-(SP)
7197 061002 012746 000003           MOV  #3,-(SP)
7198 061006 104437                   TRAP C$SVEC
7199 061010 062706 000010           ADD  #10,SP
7200 061014 012777 000105 121300     MOV  #KW.OUT,&KW.CSR ; START THE CLOCK
7201 061022                   MEMORY FFREE      ; RESET START OF FREE MEMORY
7202 061022 104431                   TRAP C$MEM
7203 061024 010037 002166           MOV  RC,FFREE
7204 061030 017737 121132 002170     MOV  &FFREE,FSIZE ; RESET SIZE OF FREE MEMORY

```

```

7187 061036 005037 002260          CLR    TS.PAT          ; RESET TEST PATTERN SELECTION
7188 061042 012701 006250          MOV    #PAT00+2,R1    ; RE-INIT
7189 061046 012721 000001          MOV    #1,(R1)+      ; DEFAULT
7190 061052 012700 000020          MOV    #16.,R0       ; PATTERN
7191 061056 005021          4$:   CLR    (R1)+        ; 16
7192 061060 005300          DEC    R0             ;
7193 061062 001375          BNE    4$             ;
7194          ;
7195          ; ALLOCATE DRIVE TABLES TO MEMORY
7196          ;
7197 061064 013737 002166 002176  INIT2: MOV    FFREE,DTABS    ; STORE START OF DRIVE TABLES AND
7198 061072 005077 121100          CLR    @DTABS        ; MARK ZERO END.
7199 061076 013700 002012          MOV    L$UNIT,R0     ; GET NUMBER OF LOGICAL UNITS TO RUN,
7200 061102 012701 000001          MOV    #1,R1         ; GET INITIAL SIZE OF DRIVE TABLE AND
7201 061106 062701 000057          1$:   ADD    #<D.SIZE>/2,R1 ; ACCUMULATE DRIVE TABLE SIZE.
7202 061112 005300          DEC    R0             ; SEE IF ANY MORE LOGICAL UNITS,
7203 061114 001374          BNE    1$             ; BRANCH IF NOT, ELSE
7204 061116 004737 024322          CALL   ALOCM         ; ALLOCATE ALL DRIVE TABLES TO MEMORY.
7205          ; R1 POINTS TO 1ST WORD IN DRIVE TABLE
7206          ;
7207          ; INITIALIZE CONTROLLER TABLE STORAGE WITH A WORD OF ZEROS
7208          ;
7209 061122 013737 002166 002200  INIT3: MOV    FFREE,CTABS    ; STORE START OF CONTROLLER TABLES AND
7210 061130 005077 121044          CLR    @CTABS        ; MARK ZEROS END.
7211 061134 005037 002202          CLR    CTRLRS        ; CLEAR CONTROLLER COUNT
7212          ;
7213          ; BUILD CONTROLLER TABLES
7214          ;
7215 061140 005002          INIT4: CLR    R2         ; START WITH LOGICAL UNIT 0
7216 061142 005003          CLR    R3         ; CLEAR FLAG FOR WARNING MESSAGE
7217 061144 012737 000160 002262  1$:   MOV    #160,VECSAV  ; SAVE DEFAULT FOR VECTOR
7218 061152          GPHARD R2,R0      ; GET POINTER TO IT'S P-TABLE
7219 061152 010200          MOV    R2,R0
7219 061154 104442          TRAP  C$GPHRD
7219 061156          BNCOMplete 26$    ; BRANCH TO 26$ IF NOT AVAILABLE
7220 061160 103142          BCC 26$
7220 061160 013705 002200          MOV    CTABS,R5     ; GET ADDRESS OF 1ST CONTROLLER TABLE
7221 061164 005715          2$:   TST    (R5)         ; CHECK IF ANY MORE TABLES
7222 061166 001405          BEQ 10$             ; BUILD NEW TABLE IF FOUND ZERO WORD
7223 061170 021015          CMP    (R0),(R5)    ; CHECK IF SAME CSR ADDRESS.
7224 061172          ASSUME C.IPR EQ 0
7225 061172          ASSUME H.IPR EQ 0
7226 061172 001446          BEQ 21$             ; BRANCH IF SO
7227          ;
7228 061174 062705 000170          5$:   ADD    #C.SIZE,R5  ; POINT TO BEGINNING OF NEXT CONTROLLER
7229 061200 000771          BR    2$             ; TABLE IN MEMORY.
7230          ;
7231          ; BUILD NEW CONTROLLER TABLE
7232          ;
7233 061202 012701 000074          10$:  MOV    #<C.SIZE>/2,R1 ; GET # OF ENTRIES IN CONTROLLER TABLE
7234 061206 004737 024322          CALL   ALOCM        ; AND ALLOCATE A TABLE TO MEMORY.
7235          ; R0 => 1ST WORD P-TABLE
7236          ; R1 => 1ST WORD IN CONTROLLER TABLE
7237 061212          PUSH   R1           ; SAVE ADDRESS OF TABLE
7237 061212 010146          MOV    R1,-(SP)     ; PUSH R1 ON STACK

```



```

7238 061214 011021      MOV      (R0),(R1)+      ; STORE CSR ADDRESS AND
7239 061216 010221      MOV      R2,(R1)+      ; UNIT NUMBER IN THE CONTROLLER TABLE.
7240 061220 013704 002262  MOV      VECSAV,R4      ; GET DEFAULT VECTOR & BR LEVEL
7241 061224 162704 000004  SUB      #4,R4          ; GET NEXT VECTOR
7242 061230 010437 002262  MOV      R4,VECSAV      ; SAVE NEXT VECTOR
7243 061234 010421      MOV      R4,(R1)+      ; STORE IT IN THE CONTROLLER TABLE.
7244 061236 012721 000074  MOV      #60,(R1)+     ; SET DEFAULT CONTROLLER TIMEOUT
7245 061242 012721 004037  MOV      #4037,(R1)+   ; THE 'JSR R0' INSTRUCTION AND
7246 061246 012721 054502  MOV      #CNTSRV,(R1)+ ; THE ADDRESS OF THE INTERRUPT SERVICE
7247                                ; ROUTINE IN THE CONTROLLER TABLE.
7248 061252 032737 000400 002154  BIT      #SM.DET,SO.BIT+SFPTBL ; DO
7249 061260 001403      BEQ      12$           ; DETERMINISTIC PHASE?
7250 061262 012721 002000  MOV      #CT.DET,(R1)+ ; SET DETERMINISTIC PHASE FLAG
7251 061266 000401      BR      13$           ;
7252 061270 005021      CLR      (R1)+        ; CLEAR FLAG WORD
7253 061272 012704 000065 12$: MOV      #<C.SIZE-C.DRO>/2,R4 ; GET # OF ENTRIES TO END OF TABLE.
7254 061276 005021      CLR      (R1)+        ; CLEAR REST OF TABLE AND
7255 061300 005304      DEC      R4           ; ADD ZERO WORD AT END.
7256 061302 002375      BGE      14$         ; LOOP TIL ALL CLEARED
7257 061304 005237 002202  INC      CTRLRS       ; KEEP TRACK OF CONTROLLER COUNT
7258                                ;
7259                                ; BUILD DRIVE TABLES
7260                                ;
7261 061310 010546 002176 21$: PUSH      <R5>         ; SAVE CONTROLLER TABLE POINTER
7262 061312 013701 000016  MOV      R5,-(SP)      ; PUSH R5 ON STACK
7263 061316 062705 000004  MOV      DTABS,R1     ; GET ADDRESS OF CURRENT DRIVE TABLE
7264 061322 012704 000004  ADD      #C.DRO,R5    ; INDEX TO 1ST DRIVE IN TABLE
7265 061326 005715 22$: MOV      #4,R4         ; GET # OF DRIVES PER CONTROLLER
7266 061330 001422      TST      (R5)         ; ANY ENTRY TO DRIVE TABLE.
7267 061332 026035 000002  BEQ      24$         ; BRANCH IF NOT, ELSE
7268 061336 001007      CMP      H.DRV(R0),#(R5)+ ; COMPARE DRIVE NUMBER IN DRIVE TABLE.
7269 061340 014501      BNE      23$         ; IF DIFFERENT, BUILD NEW TABLE
7270 061342 012605      MOV      -(R5),R1    ; ELSE, GET ADDRESS OF DRIVE TABLE
7271 061344 104454      POP      <R5>        ; GET CONTROLLER ADDRESS
7272 061344 000002      MOV      (SP)+,R5   ; POP STACK INTO R5
7273 061346 000002      ERRSF 2,ERR002     ; PRINT 'MULTIPLE P-TABLE' ERROR
7274 061346 000002      TRAP   C$ERSF      ;
7275 061350 000000      .WORD  2           ;
7276 061352 017056      .WORD  0           ;
7277 061354 104444      .WORD  ERR002      ;
7278 061354 104444      DOCLN  C$DCLN     ; DO CLEAN-UP TRAP
7279 061354 104444      TRAP   C$DCLN     ;
7280                                ;
7281 061356 005304 23$: DEC      R4           ; COUNT DRIVES
7282 061360 001362      BNE      22$         ; IF LESS THAN 4 DRIVES, BUILD NEW TABLE
7283 061362 012605      POP      <R5>        ; ELSE, GET CONTROLLER ADDRESS
7284 061362 012605      MOV      (SP)+,R5   ; POP STACK INTO R5
7285 061364 104454      ERRSF 3,ERR003     ; PRINT 'TOO MANY DRIVES' ERROR
7286 061364 104454      TRAP   C$ERSF      ;
7287 061366 000003      .WORD  3           ;
7288 061370 000000      .WORD  0           ;
7289 061372 017124      .WORD  ERR003      ;
7290 061374 104444      DOCLN  C$DCLN     ; DO CLEAN-UP TRAP
7291 061374 104444      TRAP   C$DCLN     ;
7292                                ;

```

```

7280 061376 010115      24$:  MOV      R1,(R5)          ; STORE ADDRESS OF DRIVE TABLE IN
7281                                ; CONTROLLER TABLE.
7282 061400 016021 000002  MOV      H.DRV(R0),(R1)+    ; STORE DRIVE NUMBER AND
7283 061404 010211      MOV      R2,(R1)          ; LOGICAL UNIT NUMBER IN DRIVE TABLE.
7284 061406 056011 000004  BIS      H.PRM(R0),(R1)    ; SET HARDWARE PARAMETER BITS
7285 061412 052711 020000  BIS      #DT.PRM,(R1)      ; SET DEFAULT TEST PARAMETERS
7286 061416 052103      BIS      (R1)+,R3          ; SAVE FOR WARNING MESSAGE
7287                                ;
7288 061420 012721 000001  MOV      #1,(R1)+          ; LOAD 1 INTO B/E SET COUNT
7289 061424 005021      CLR      (R1)+            ; INIT
7290 061426 005021      CLR      (R1)+            ; BEGIN/END
7291 061430 012721 177777  MOV      #-1.,(R1)+        ; SET
7292 061434 012721 177777  MOV      #-1.,(R1)+        ; LIMITS
7293                                ;
7294 061440 012704 000050      MOV      #<D.SIZE-D.BGN2>/2,R4 ; GET # OF ENTRIES TO END OF TABLE.
7295 061444 005021      CLR      (R1)+            ; CLEAR REST OF TABLE
7296 061446 005304      DEC      R4                ;
7297 061450 002375      BGE     25$                ; LOOP TIL ALL CLEARED
7298                                ;
7299 061452 062737 000136 002176  ADD      #D.SIZE,DTABS     ; NEXT DRIVE TABLE ADDRESS AND
7300 061460 005077 120512      CLR      #DTABS           ; MARK ZERO END.
7301 061464      26$:  POP      <R5>              ; RESTORE STACK
7302 061466 012605      MOV      (SP)+,R5         ; POP STACK INTO R5
7303 061470 005202      INC      R2                ; INCREMENT LOGICAL UNIT NUMBER
7304 061474 020237 002012  CMP      R2,L#UNIT        ; CHECK IF GOT ALL TABLES
7305 061476 012701 000001  BLT     1$                ; IF NOT, GO BACK FOR NEXT, ELSE
7306 061502 004737 024322  MOV      #1,R1            ; GET 1 WORD TO TERMINATE ALL CONTROLLER
7307                                ; TABLES AND ALLOCATE IT TO MEMORY.
7308                                ;
7309                                ; CHECK FOR CUSTOMER WARNING MESSAGE
7310 061506 032703 010000  INITS:  BIT      #HM.WRT,R3   ; CHECK IF BIT EVER SET
7311 061512 001475      BEQ     INIT6             ; BYPASS IF NOT
7312 061514      PRINTF #INITWA ; PRINT WARNING
7313 061514 012746 010725      MOV      #INITWA,-(SP)
7314 061520 012746 000001  MOV      #1,-(SP)
7315 061524 010600      MOV      SP,R0
7316 061526 104417      TRAP   C#PNTF
7317 061530 062706 000004  ADD      #4,SP
7318 061534      PRINTF #INITWB ;
7319 061534 012746 010777      MOV      #INITWB,-(SP) ; HEADER
7320 061540 012746 000001  MOV      #1,-(SP)
7321 061544 010600      MOV      SP,R0
7322 061546 104417      TRAP   C#PNTF
7323 061550 062706 000004  ADD      #4,SP
7324 061554 013705 002200  MOV      CTABS,R5          ; GET ADDRESS 1ST CONTROLLER TABLE
7325 061560 010504      MOV      R5,R4            ; GET ADDRESS OF POINTER TO DRIVE TABLE
7326 061562 062704 000016  ADD      #C.DRO,R4
7327 061566 012701 000004  MOV      #4,R1            ; GET COUNT OF DRIVE TABLES
7328 061572 012403      MOV      (R4)+,R3         ; GET ADDRESS OF DRIVE TABLE
7329 061574 001423      BEQ     4$                ;
7330 061576 032763 010000 000002  BIT      #DT.WRT,D.UNIT(R3) ; CHECK IF CUSTOMER DATA SELECTED
7331 061604 001415      BEQ     3$                ;
7332 061606 116300 000002  MOV      D.UNIT(R3),R0    ; GET LOGICAL UNIT NUMBER
7333 061612      PRINTF #INITWC,R0,(R5),(R3) ; PRINT NUMBERS

```

```

061612 011346      MOV      (R3),-(SP)
061614 011546      MOV      (R5),-(SP)
061616 010046      MOV      R0,-(SP)
061620 012746 011044  MOV      #INITWC,-(SP)
061624 012746 000004  MOV      #4,-(SP)
061630 010600      MOV      SP,R0
061632 104417      TRAP     C#PNTF
061634 062706 000012  ADD      #12,SP
7324 061640 005301 3$:      DEC      R1
7325 061642 001353      BNE     2$
7326 061644 062705 000170 4$:      ADD      #C.SIZE,R5
7327 061650 005715      TST     (R5)
7328 061652 001342      BNE     1$
7329
7330
7331
7332 061654          :
061654 104450          :      GET CONFIRMATION TO PROCEED
7333 061656 104450      MANUAL
061656 103013      TRAP     C#MANI
061660 104443      BNCOMPL 6
061662 000404      BCC     INIT6
061664 002212      GMANIL  INITWD,TEMP,1,NO
061666 000120      TRAP     C#GMAN
061670 010224      BR      10000$
061672 000001      .WORD   TEMP
061674 032737 000001 002212 10000$: .WORD   T#CODE
7335 061702 001001      .WORD   INITWD
7336 061704 104444      .WORD   1
7337 061704 104444      BIT     #1,TEMP
7338
7339
7340          :
7341 061706 013705 002200      BNE     INIT6
7342 061712 012701 000517      BNE     INIT6
7343 061716 004737 024322      DOCLN
7344 061722 010165 000104      TRAP     C#DCLN
7345 061726 012700 000004
7346 061732 010161 000000
7347 061736 062761 000206 000000
7348 061744 016101 000000
7349 061750 005300
7350 061752 001367
7351 061754 016561 000104 000000
7352 061762 010565 000072
7353 061766 062765 000132 000072
7354 061774 016565 000072 000074
7355 062002 062765 000020 000074
7356 062010 010565 000100
7357 062014 062765 000112 000100
7358 062022 016565 000100 000102
7359 062030 062765 000020 000102
7360 062036 062705 000170

```

```

; COUNT THE DRIVE TABLES
; LOOK AT ALL OF THEM
; MOVE TO NEXT CONTROLLER TABLE
; SEE IF ANOTHER TABLE AND
; LOOK AT IT

; CHECK IF MANUAL INTERVENTION ALLOWED
; BRANCH IF NOT ALLOWED
; ASK OPERATOR

; LOOK AT RESPONSE
; BRANCH IF YES WAS ANSWER
; DO CLEAN-UP TRAP

; GET POINTER TO FIRST TABLE
; ALLOCATE
; RESPONSE ENVELOPES
; R.E. LIST HEADER POINTS TO TOP
; SET UP LINKS
; TO ALL
; OF THE
; R.E. BUFFERS
; IF NOT ZERO,
; GET NEXT R.E. BUFFER
; MAKE IT A RING
; CALCULATE
; COMMAND RING
; ADDRESSES

; CALCULATE
; RESPONSE RING
; ADDRESSES

; MOVE TO NEXT CONTROLLER TABLE

```

```

7361 062042 005715          TST      (R5)          ; IF ANOTHER TABLE
7362 062044 001322          BNE     11$           ; SET UP POINTERS.
7363 062046 013737 002166 002172  MOV     FFREE,FMADR  ; SAVE FFREE &
7364 062054 013737 002170 002174  MOV     FSIZE,FMSIZ ; FSIZE FOR NEXT PASS
7365                                     ;
7366                                     ; INITIALIZE FREE MEMORY BUFFERS
7367                                     ;
7368 062062 013737 002172 002166  INIT7:  MOV     FMADR,FFREE ; RESTORE FFREE &
7369 062070 013737 002174 002170  MOV     FMSIZ,FSIZE ; FSIZE
7370                                     ;
7371 062076 013701 002202          MOV     CTRLRS,R1   ; NEED A MINIMUM
7372 062102 006301          ASL     R1           ; OF 4 MESSAGE ENVELOPES
7373 062104 006301          ASL     R1           ; PER CONTROLLER
7374 062106 010137 006234          MOV     R1,TBSMIN  ; CALCULATE
7375 062112 012702 000051          MOV     #CMSIZ,R2  ; MINIMUM MEMORY (WORDS)
7376 062116 004737 047420          CALL    MULT        ; NEEDED FOR
7377 062122 010337 006232          MOV     R3,MEMIN  ; MESSAGE ENVELOPES
7378 062126 012700 000001          MMU    ON          ; TURN ON MEMORY MANAGEMENT UNIT
7379 062132 104503          TRAP   C#MMU
7380 062134 103023          BNCOMPLETE 3$     ; IF NOT SUCCESSFUL, USE FREE MEMORY
7381 062136 042737 100000 002204  BCC    3$
7382 062144 005037 004370          BIC     #IMMU,IFLAGS ; FLAG MMU IS AVAILABLE
7383 062150 012737 000001 004372  CLR     BUFBA       ; GET BASE ADDRESS OF BUFFER
7384 062156 012737 000010 004376  MOV     #1,BUFEA    ; GET EXTENDED ADDRESS FOR BUFFER
7385 062164 000403          BUFREQ  BUFSIZ,BUFBA,BUFEA ; GET BUFFER SIZE IN 4KW
7386 062166 004376          BR     10001$
7387 062170 004372          .WORD  BUFSIZ
7388 062172 004370          .WORD  BUFEA
7389 062174          .WORD  BUFBA
7390 062174 012700 062166          10001$: MOV     #-6,R0
7391 062200 104501          TRAP   C#FREQ
7392 062202 103433          BCOMPLETE 10$
7393 062204 013737 006234 006236 3$:  BCS    10$
7394 062212 013701 006232          MOV     TBSMIN,TBSSIZ ; ALLOCATE MINIMUM
7395 062216 004737 024322          MOV     MEMIN,R1    ; SIZE
7396 062222 010137 006240          CALL    ALOCH       ; MESSAGE ENVELOPE
7397 062226 013701 002170          MOV     R1,TBSTRT  ; LINKED LIST
7398 062232 005002          MOV     FSIZE,R1   ; CONVERT
7399 062234 005003          CLR    R2          ; BUFFER
7400 062236 012704 000400          CLR    R3          ; SIZE TO
7401 062242 004737 047256          MOV     #256,R4    ; 512 BYTE
7402 062246 010137 004374          CALL    DIVIDE     ; BLOCKS
7403 062252 001002          MOV     R1,BUFBK   ; SAVE NUMBER OF 512 BYTE BLOCKS
7404 062254 000137 062574          BNE    4$         ; IF ZERO,
7405 062260 010103          JMP     NOMEM      ; FATAL SYSTEM ERROR
7406 062262 052737 100000 002204 4$:  MOV     R1,R3      ; GET BLOCK COUNT
7407 062270 000440          BIS     #IMMU,IFLAGS ; MMU IS NOT AVAILABLE
7408 062272 005737 004376          BR     20$        ; BUILD LINKED LIST
7409 062274 001742          TST     BUFSIZ     ; IF ZERO,
7410 062276 002170          BEQ    3$         ; USE FREE MEMORY
7411 062300 013701 002170          MOV     FSIZE,R1   ; GET REMAINING FREE MEM

```

7405	062304	023701	006232		CMP	MEMIN,R1		: IS MEMORY BIG ENOUGH FOR M.E.?
7406	062310	003131			BGT	NOMEM		: IF TOO SMALL, EXIT WITH ERROR
7407	062312	005002			CLR	R2		: ALLOCATE
7408	062314	005003			CLR	R3		: TBS
7409	062316	012704	000051		MOV	#CMDSIZ,R4		: PACKET
7410	062322	004737	047256		CALL	DIVIDE		: QUEUE
7411	062326	022701	000377		CMP	#255.,R1		: DON'T USE
7412	062332	002002			BGE	11\$: MORE THAN
7413	062334	012701	000377		MOV	#255.,R1		: 255 PACKETS
7414	062340	013737	002166	006240	11\$:	MOV	FFREE,TBSTRT	: GET TBS LIST START
7415	062346	010137	006236		MOV	R1,TBSSIZ		: AND LENGTH (PACKETS)
7416	062352	012701	000020		MOV	#16.,R1		: CONVERT
7417	062356	013702	004376		MOV	BUFSIZ,R2		: BUFFER SIZE
7418	062362	004737	047420		CALL	MULT		: FROM PAGES
7419	062366	010337	004374		MOV	R3,BUFBK		: BLOCKS
7420								
7421	062372	012701	004626		20\$:	MOV	#MMPKTS,R1	: POINT TO MAPPED MEMORY PACKET AREA
7422	062376	010137	004622		MOV	R1,M.HDR		: INITIALIZE AVAILABLE
7423	062402	005021			CLR	(R1)+		: TERMINATE AVAILABLE MEMORY LIST
7424	062404	013721	004374		MOV	BUFBK,(R1)+		: SET LENGTH TO ENTIRE AREA
7425	062410	005021			CLR	(R1)+		: MAPPED MEMORY OFFSET = 0
7426	062412	010137	004624		21\$:	MOV	R1,F.HDR	: INITIALIZE FREE MEMORY
7427	062416	005303			DEC	R3		: SET BLOCK COUNT TO REMAINING PACKETS
7428	062420	001407			BEQ	30\$: EXIT WHEN DONE
7429	062422	010102			MOV	R1,R2		: PUT CURRENT ADDRESS IN PACKET
7430	062424	062702	000006		ADD	#PKTSIZ,R2		: POINT TO NEXT PACKET
7431	062430	010221			MOV	R2,(R1)+		: STORE POINTER TO NEXT PACKET
7432	062432	005021			CLR	(R1)+		: CLEAR REMAINDER
7433	062434	005021			CLR	(R1)+		: OF PACKET
7434	062436	000767			BR	21\$: DO NEXT PACKET
7435								
7436	062440	162701	000006		30\$:	SUB	#PKTSIZ,R1	: MOVE BACK TO PREVIOUS PACKET
7437	062444	005011			CLR	(R1)		: CLEAR POINTER TO END LIST
7438								
7439	062446	013704	006240		50\$:	MOV	TBSTRT,R4	: INIT TBS FREE PACKET LIST
7440	062452	013702	006236		MOV	TBSSIZ,R2		: GET SIZE IN PACKETS
7441	062456	020237	002202		CMP	R2,CTRLRS		: TBS LIST MUST CONTAIN MORE
7442	062462	003444			BLE	NOMEM		: PACKETS THAN CONTROLLERS UNDER TEST
7443	062464	012703	006242		MOV	#T.HDR,R3		: POINT TO HEADER FORWARD LINK
7444	062470	005001			CLR	R1		: 0 INDICATES HEADER
7445	062472	010164	000002		51\$:	MOV	R1,ME.CBL(R4)	: INIT PACKET BACK LINK
7446	062476	010463	000000		MOV	R4,ME.CFL(R3)		: INIT PREVIOUS FORWARD LINK
7447	062502	010264	000004		MOV	R2,ME.CRF(R4)		: INIT COMMAND REFERENCE NUMBER
7448	062506	010403			MOV	R4,R3		: POINT TO LAST PACKET
7449	062510	010401			MOV	R4,R1		: GET ADDRESS OF LAST PACKET
7450	062512	062704	000122		ADD	#<2*CMDSIZ>,R4		: POINT TO NEXT PACKET
7451	062516	005302			DEC	R2		: IF MORE PACKETS,
7452	062520	001364			BNE	51\$: LOOP
7453	062522	005063	000000		CLR	ME.CFL(R3)		: 0 INDICATES HEADER
7454								
7455	062526	012700	000042		60\$:	MOV	#34.,R0	: CLEAR
7456	062532	012703	004516		MOV	#MUTSIZ,R3		: OUTPUT
7457	062536	012701	004412		MOV	#MUTOFF,R1		: BUFFER
7458	062542	005023			61\$:	CLR	(R3)+	: MULTI-USE
7459	062544	012721	177777		MOV	#-1,(R1)+		: TABLE

INITIALIZE SECTION

```

7460 062550 005300          DEC      R0          ;
7461 062552 001373          BNE     61$          ;
7462                          ;
7463                          ; EXIT INITIALIZE SECTION
7464                          ;
7465 062554 042737 070000 002204 INITXX: BIC     #IDIE!IERL!IDUN,IFLAGS ; CLEAR LEFTOVER FLAGS
7466 062562 012700 000000      SETPRI  #PRIO0          ; SET RUNNING PRIORITY TO ZERO
      062562 012700 000000      MOV     #PRIO0,R0
      062566 104441          TRAP   C$SPRI
7467
7468 062570          EXIT     INIT
      062570 104432          TRAP   C$EXIT
      062572 000014          .WORD  L10050-.
7469
7470                          ;
7471                          ; INSUFFICIENT MEMORY ERROR
7472                          ;
7473
7474 062574          NOMEM:  ERRSF  4,  ERR004
      062574 104454          TRAP   C$ERSF
      062576 000004          .WORD  4
      062600 000000          .WORD  0
      062602 017172          .WORD  ERR004
7475 062604          DOCLN          ; DO CLEAN-UP TRAP
      062604 104444          TRAP   C$DCLN
7476
7477 062606          ENDINIT
      062606          L10050:
      062606 104411          TRAP   C$INIT
7478

```

CZUDJAO UDA50-A/KDA50-Q SUBSY E MACRO V05.03 Wednesday 02-Oct-85 16:03 Page 133
AUTODROP SECTION

```
7480          .SBTTL  AUTODROP SECTION
7481
7482          ;++
7483          ;      THIS CODE IS EXECUTED IMMEDIATELY AFTER THE INITIALIZE CODE IF
7484          ;      THE "ADR" FLAG WAS SET.  THE UNIT(S) UNDER TEST ARE CHECKED TO
7485          ;      SEE IF THEY WILL RESPOND.  THOSE THAT DON'T ARE IMMEDIATELY
7486          ;      DROPPED FROM TESTING.
7487          ;--
7488
7489 062610      BGNAUTO
062610      L$AUTO::
7490
7491 062610      ENDAUTO
062610      L10051:
062610      TRAP  C$AUTO
104461
```

7493
 7494
 7495
 7496
 7497
 7498
 7499
 7500
 7501
 7502
 7503
 7504
 7505
 7506
 7507
 7508

062612
 062612
 062612 004737 053420
 062616 032737 100000 002204
 062624 001001
 062626 104477
 062630
 062630
 062630 104412

.SBTTL CLEANUP CODING SECTION

```

;
;+++
; THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS PERFORMED
; AFTER EACH PASS AND AFTER THE PROGRAM IS INTERRUPTED BY "+C".
;
;---
```

BGNCLN
 L\$CLEAN::

```

CALL REINIT ; RESET ALL CONTROLLERS
BIT #IMMU,IFLAGS ; IF IMMU SET,
BNE 10$ ; MEMORY MAPPING NOT ON
BUFREL ; RELEASE MAPPED HIGH MEMORY
TRAP C$REL

10$:
ENDCLN
L10052:
TRAP C$CLEAN
```


7510
7511
7512
7513
7514
7515
7516
7517 062632
062632
7518
7519 062632
062632
062632 104453
7520

```
.SBTTL DROP UNIT SECTION  
;+  
; THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE  
; TO NO LONGER BE TESTED.  
;--  
BGNDU  
L$DU::  
ENDDU  
L10053: TRAP C$DU
```

CZUDJAO UDA50-A/KDA50-Q SUBSY E MACRO V05.03 Wednesday 02-Oct-85 16:03 Page 136
ADD UNIT SECTION

```
7522          .SBTTL  ADD      UNIT SECTION
7523
7524          ;++
7525          ;          THE ADD-UNIT SECTION CONTAINS ANY CODE THE PROGRAMMER WISHES
7526          ;          TO BE EXECUTED IN CONJUNCTION WITH THE ADDING OF A UNIT BACK
7527          ;          TO THE TEST CYCLE.
7528          ;--
7529
7530 062634     BGNAU
062634     L$AU::
7531
7532 062634     ENDAU
062634     L10054:
062634 104452  TRAP      C$AU
7533
```

```

7535 .SBTTL HARDWARE TESTS
7536
7537 .SBTTL TEST 1 - CONTROLLER VERIFICATION TEST
7538
7539 :++
7540 : TEST 1 - CONTROLLER VERIFICATION TEST
7541 :
7542 : THIS TEST WILL VERIFY THAT ALL OF THE CONTROLLERS SPECIFIED IN
7543 : THE HARDWARE QUESTIONS ARE REACHABLE, WILL PASS THEIR SELF
7544 : DIAGNOSTICS, AND CAN SUCCESSFULLY COMMUNICATE WITH THE HOST.
7545 : EACH CONTROLLER IS TESTED SEPERATELY. NO DRIVES ARE ACCESSED IN
7546 : THIS TEST.
7547 :--
7548
7549 062636 BGNTST
062636 T1::
7550
7551 062636 012737 000001 002206 MOV #1,TNUM ; SAVE TEST NUMBER
7552 062644 012737 040734 002246 MOV #T1PGEN,TSPGEN ; GET ADDRESS OF PKT GEN ROUTINE
7553
7554 :++
7555 : TEST 1, SUBTEST 1
7556 : HOST MEMORY I/O PAGE ADDRESSING AND CONTROLLER DIAGNOSTIC WRAP
7557 : MODE TEST
7558 :--
7559
7560 062652 BGNSUB; 1
062652 T1.1:
062652 104402 TRAP C#BSUB
7561
7562 062654 013705 002200 MOV CTABS,R5 ; GET CONTROLLER TABLE ADDRESS
7563 062660 005037 002210 CLR UTEST ; CLEAR DRIVE TO TEST COUNT
7564 062664 116537 000002 002074 T1NEXT: MOV C.UNIT(R5),L$LUN ; CHECK IF UNIT AVAILABLE FOR TESTING
7565 062672 032765 100000 000014 BIT #CT.AVL,C.FLG(R5) ;
7566 062700 001106 BNE T1SKIP ; SKIP IF NOT AVAILABLE
7567 062702 005237 002210 INC UTEST ; COUNT NUMBER OF CONTROLLERS TO TEST
7568
7569 :
7570 : VERIFY THE ADDRESS OF THE SA AND IP REGISTERS ARE VALID AND
7571 : START THE INITIALIZATION BY WRITING ZEROS TO IP REGISTER
7572 062706 016504 000000 MOV C.IPR(R5),R4 ; GET ADDRESS OF IP REGISTER
7573 062712 005037 002264 CLR NXMAD ; CLEAR MEMORY ERROR FLAG
7574 062716 SETVEC #ERRVEC,#NXMI,#PRIO7 ; SETUP TIMEOUT ERROR VECTOR
062716 012746 000340 MOV #PRIO7,-(SP)
062722 012746 054472 MOV #NXMI,-(SP)
062726 012746 000004 MOV #ERRVEC,-(SP)
062732 012746 000003 MOV #3,-(SP)
062736 104437 TRAP C#SVEC
062740 062706 000010 ADD #10,SP
7575 062744 005764 000002 TST 2(R4) ; ACCESS SA REGISTER
7576 062750 005014 CLR (R4) ; WRITE TO IP
7577 062752 CLRVEC #ERRVEC ; RETURN TIMEOUT ERROR VECTOR
062752 012700 000004 MOV #ERRVEC,RO
062756 104436 TRAP C#VEC
7578 062760 005737 002264 TST NXMAD ; SEE IF A MEMORY ERROR OCCURRED

```

```

7579 062764 001407          BEQ      1$          ; IF NO ERROR, CONTINUE
7580 062766          ERRDF   37,ERR037 ; PRINT ERROR MESSAGE
      062766 104455      TRAP    C$ERRDF
      062770 000045      .WORD   37
      062772 000000      .WORD   0
      062774 020510      .WORD   ERRO37
7581 062776 004737 027350  CALL    DRPCNT      ; DROP CONTROLLER FROM TEST
7582 063002 000445      BR      T1SKIP     ; END TEST NOW
7583
7584          ;
7585          ;
7586          ;
7587          ;
7588
7589 063004 012737 004000 002354 1$:  MOV     #SA.S1,CNTRSC ; SET STEP 1 BIT
7590 063012 004737 053252          CALL    CNTRSP      ; WAIT FOR RESPONSE FROM STEP 1
7591 063016 103437          BCS     T1SKIP     ; IF ERROR, BRANCH
7592 063020 032702 000400          BIT     #SA.DI,R2  ; IF CTRLR DOESN'T HAVE DIAGNOSTICS,
7593 063024 001434          BEQ     T1SKIP     ; TRY NEXT CONTROLLER
7594 063026 012737 140000 002356  MOV     #<SA.STP+SA.WRP>,WCHNGD ; SAVE NEW PORT CONTENTS
7595 063034 012703 000104          MOV     #68.,R3    ; INITIALIZE PATTERN POINTER
7596 063040 000403          BR      5$
7597 063042 016337 007036 002356 4$:  MOV     MNTPAT(R3),WCHNGD ; SAVE NEW PORT CONTENTS
7598 063050 013764 002356 000002 5$:  MOV     WCHNGD,2(R4) ; INITIALIZE FOR PORT WRAP
7599 063056 004737 053652          CALL    WCHNG      ; WAIT FOR THE PORT TO CHANGE
7600 063062 103415          BCS     T1SKIP     ; IF ERROR, BRANCH
7601 063064 023702 002356          CMP     WCHNGD,R2  ; COMPARE WITH DATA WRITTEN
7602 063070 001407          BEQ     7$
7603 063072          6$:  ERRDF   26,ERR026 ; REPORT ERROR
      063072 104455      TRAP    C$ERRDF
      063074 000032      .WORD   26
      063076 000000      .WORD   0
      063100 020126      .WORD   ERRO26
7604 063102 004737 027350          CALL    DRPCNT      ; DROP CONTROLLER FROM TEST
7605 063106 000403          BR      T1SKIP     ; BRANCH
7606 063110 162703 000002 7$:  SUB     #2,R3      ; POINT TO NEXT DATA PATTERN
7607 063114 002352          BGE     4$         ; IF NOT NEGATIVE, KEEP LOOPING
7608
7609 063116 062705 000170  T1SKIP: ADD     #C.SIZE,R5 ; MOVE TO NEXT CONTROLLER TABLE
7610 063122 005715          TST     (R5)       ; SEE IF ANOTHER TABLE AND
7611 063124 001257          BNE     T1NEXT    ; IF NOT ZERO, LOOK AT NEXT CONTROLLER
7612
7613 063126          ENDSUB
      063126          L10056:
      063126 104403      TRAP    C$ESUB
7614

```

```

7616
7617      ;++
7618      ;      TEST 1, SUBTEST 2
7619      ;      INITIALIZE CONTROLLER THEN PERFORM LARGE BUFFER MAINTENANCE
7620      ;      READ AND WRITE OPERATIONS TO ALL LOCATIONS IN CONTROLLER MEMORY
7621      ;      TO TEST CONTROLLER ADDRESSING ABILITY AND MEMORY INTEGRITY
7622      ;--
7623
7624      063130      BGNSUB; 2
          063130      T1.2:
          063130      104402      TRAP      C$BSUB
7625
7626      063132      004737      053420      CALL      REINIT          ; RESET ALL CONTROLLERS
7627
7628      063136      013705      002200      MOV       CTABS,R5          ; GET CONTROLLER TABLE ADDRESS
7629      063142      005037      002210      CLR       UTEST          ; CLEAR DRIVE TO TEST COUNT
7630      063146      032765      100000      000014      41$:      BIT       #CT.AVL,C.FLG(R5) ; IF NOT AVAILABLE OR DONE,
7631      063154      001002          ;      DON'T COUNT CONTROLLER
7632      063156      005237      002210      INC       UTEST          ; COUNT NUMBER OF CONTROLLERS TO TEST
7633      063162      062705      000170      42$:      ADD       #C.SIZE,R5      ; MOVE TO NEXT CONTROLLER TABLE
7634      063166      005715          ;      TST       (R5)          ; SEE IF ANOTHER TABLE AND
7635      063170      001366          ;      BNE      41$          ; IF NOT ZERO, LOOK AT NEXT CONTROLLER
7636      063172      012737      177777      002242      MOV       #-1,TSTOFF      ; -1 INDICATES NO BUFFER IN USE
7637      063200      004737      026426          CALL      DRIVER          ; PERFORM SUBTEST
7638
7639      063204          ENDSUB
          063204          L10057:
          063204      104403      TRAP      C$ESUB
7640
7641      063206          DORPT          ; PRINT A STATISTICAL REPORT
          063206      104424      TRAP      C$DRPT
7642
7643      063210          ENDTST
          063210          L10055:
          063210      104401      TRAP      C$ETST

```

CZUDJAO UDA50-A/KDA50-Q SUBSY E MACRO V05.03 Wednesday 02-Oct-85 16:03 Page 139
 TEST 2 - SUBSYSTEM VERIFICATION TEST

```

7645          .SBTTL TEST 2 - SUBSYSTEM VERIFICATION TEST
7646
7647          ;++
7648          ; TEST 2 - SUBSYSTEM VERIFICATION TEST
7649          ; THIS TEST VERIFIES THE ABILITY OF THE SUBSYSTEM TO BRING THE
7650          ; DRIVES ONLINE AND TO PERFORM I/O OPERATIONS TO THE DRIVES.
7651          ;--
7652
7653          BGNTST
7654          T2::
7655          063212 012737 000002 002206          MOV      #2,TNUM          ; SAVE TEST NUMBER
7656          063220 012737 041616 002246          MOV      #T2PGEN,TSPGEN ; GET ADDRESS OF PKT GEN ROUTINE
7657
7658          063226 004737 053420          CALL     REINIT          ; RESET ALL CONTROLLERS
7659
7660          063232 013705 002200          MOV      CTABS,R5        ; GET CONTROLLER TABLE ADDRESS
7661          063236 005037 002210          CLR      UTEST          ; CLEAR DRIVE TO TEST COUNT
7662          063242 032765 100000 000014 41$:      BIT      #CT.AVL,C.FLG(R5) ; IF NOT AVAILABLE OR DONE,
7663          063250 001002          BNE     42$             ; DON'T COUNT CONTROLLER
7664          063252 005237 002210          INC      UTEST          ; COUNT NUMBER OF CONTROLLERS TO TEST
7665          063256 062705 000170 42$:      ADD      #C.SIZE,R5     ; MOVE TO NEXT CONTROLLER TABLE
7666          063262 005715          TST     (R5)           ; SEE IF ANOTHER TABLE AND
7667          063264 001366          BNE     41$             ; IF NOT ZERO, LOOK AT NEXT CONTROLLER
7668          063266 012737 177777 002242          MOV      #-1,TSTOFF     ; -1 INDICATES NO BUFFER USED
7669          063274 004737 026426          CALL     DRIVER         ; PERFORM THE TEST
7670          063300          DORPT          ; PRINT A STATISTICAL REPORT
7670          063300 104424          TRAP    C$DRPT
7671
7672          063302          ENDTST
7672          063302          L10060:
7672          063302 104401          TRAP    C$ETST
7673
  
```

```

7675          .SBTTL TEST 3 - SUBSYSTEM EXERCISER
7676
7677          :++
7678          : TEST 3 - SUBSYSTEM EXERCISER
7679          : THIS TEST EXERCISES THE COMPLETE SUBSYSTEM. THE TEST WILL MAINTAIN
7680          : AS HEAVY AN I/O LOAD AS POSSIBLE ON THE SUBSYSTEM
7681          :--
7682
7683          BGNTST
7684          T3::
7685          063304 012737 000003 002206      MOV      #3,TNUM          ; SAVE TEST NUMBER
7686          063312 012737 042736 002246      MOV      #T3PGEN,TSPGEN  ; GET ADDRESS OF PKT GEN ROUTINE
7687
7688          063320 032737 000002 002204      BIT      #ICONT,IFLAGS   ; IF HERE FROM CONTINUE COMMAND,
7689          063326 001014                    BNE     10$              ; DON'T RE-INIT TIMERS
7690          063330 012700 002250              MOV      #STIME,RO       ; GET REPORT TIMER
7691          063334 013701 002150              MOV      SFPTBL+SO.SRI,R1 ; GET REPORT INTERVAL
7692          063340 004737 052144              CALL     SETMIN          ; SET TIME FOR NEXT REPORT
7693          063344 012700 002254              MOV      #TSTIM,RO      ; GET TEST TIMER
7694          063350 013701 002146              MOV      SFPTBL+SO.TL,R1 ; GET TIME OUT INTERVAL
7695          063354 004737 052144              CALL     SETMIN          ; SET TIME FOR NEXT REPORT
7696
7697          :
7698          : ASK MANUAL INTERVENTION QUESTIONS
7699          063360 032737 000016 002204      10$: BIT      #ICONT!ISTR!IREST,IFLAGS ; IF NOT HERE FROM OPERATOR COMMAND,
7700          063366 001424                    BEQ     30$              ; USE PREVIOUS PARAMETERS
7701          063370 042737 000016 002204      BIC     #ICONT!ISTR!IREST,IFLAGS ; CLEAR FLAGS FOR NEXT TIME HERE
7702          063376 032737 000001 002154      BIT      #SM.MAN,SFPTBL+SO.BIT ; IF MANUAL INTERVENTION NOT SELECTED,
7703          063404 001415                    BEQ     30$              ; USE DEFAULT PARAMETERS
7704          063406                                MANUAL                  ; IF MANUAL INTERVENTION NOT ALLOWED,
7705          063406 104450                                TRAP    C#MANI          ;
7706          063410 103003                                BNCOMPLETE 24$         ; GIVE WARNING & USE DEFAULTS
7707          063410                                BCC     24$
7708
7709          :
7710          063412 004737 063520              CALL     T3QUES         ; ASK MANUAL INTERVENTION QUESTIONS
7711          063416 000410              BR      30$            ; AND START TEST
7712
7713          :
7714          063420                                24$: PRINTF #T3WARN          ; MANUAL INTERVENTION NOT ALLOWED
7715          063420 012746 010625              MOV      #T3WARN,-(SP)
7716          063424 012746 000001              MOV      #1,-(SP)
7717          063430 010600              MOV      SP,RO
7718          063432 104417              TRAP    C#PNTF
7719          063434 062706 000004              ADD     #4,SP
7720
7721          :
7722          : START TEST
7723          063440 004737 053420              30$: CALL     REINIT          ; RESET ALL CONTROLLERS
7724          063444 013705 002200              MOV      CTABS,R5       ; GET CONTROLLER TABLE ADDRESS
7725          063450 005037 002210              CLR     UTEST          ; CLEAR DRIVE TO TEST COUNT
7726          063454 032765 100000 000014      41$: BIT      #CT.AVL,C.FLG(R5) ; IF NOT AVAILABLE,
7727          063462 001002                    BNE     42$            ; DON'T COUNT CONTROLLER
7728          063464 005237 002210              INC     UTEST          ; COUNT NUMBER OF CONTROLLERS TO TEST
7729          063470 062705 000170              42$: ADD     #C.SIZE,R5  ; MOVE TO NEXT CONTROLLER TABLE
7730          063474 005715              TST     (R5)           ; SEE IF ANOTHER TABLE AND

```

CZUDJAO UDA50-A/KDA50-Q SUBSY E MACRO V05.03 Wednesday 02-Oct-85 16:03 Page 140-1
TEST 3 - SUBSYSTEM EXERCISER

7722	063476	001366		BNE	41\$; IF NOT ZERO, LOOK AT NEXT CONTROLLER
7723	063500	012737	177777 002242	MOV	#-1,TSTOFF	; -1 INDICATES NO BUFFER IN USE
7724						
7725	063506	004737	026426	CALL	DRIVER	; PERFORM TEST
7726	063512			DORPT		; PRINT A STATISTICAL REPORT
	063512	104424		TRAP	C\$DRPT	
7727						
7728	063514			EXIT	TST	
	063514	104432		TRAP	C\$EXIT	
	063516	001472		.WORD	L10061-	
7729						


```

7731 .SBTTL TEST 3 MANUAL INTERVENTION QUESTIONS
7732
7733 :++
7734 : T3QUES - ASK TEST 3 MANUAL INTERVENTION QUESTIONS
7735 :
7736 : INPUTS:
7737 : NONE
7738 :
7739 : OUTPUTS:
7740 : DRIVE TABLES CONTAIN NEW PARAMETERS
7741 : DATA PATTERN 0 CHANGED, IF REQUESTED
7742 :--
7743 T3QUES: PRINTF #T3QHDR ; PRINT HEADER
063520 MOV #T3QHDR, -(SP)
063520 012746 064625 000001 MOV #1, -(SP)
063524 012746 000001 MOV SP, R0
063530 010600 TRAP C#PNTF
063532 104417 ADD #4, SP
063534 062706 000004 GMANID T3PAT, TS.PAT, D, -1, 0, .16, .YES; DATA PATTERN TO USE?
7744 063540 TRAP C#GMAN
063540 104443 BR 10000#
063542 000406 .WORD TS.PAT
063544 002260 .WORD T#CODE
063546 000052 .WORD T3PAT
063550 064502 .WORD -1
063552 177777 .WORD T#LOLIM
063554 000000 .WORD T#HILIM
063556 000020
10000#:
7745 063560 005737 002260 TST TS.PAT ; IF ZERO
7746 063564 001404 BEQ 10# ; ASK ABOUT PATTERN 16
7747 063566 022737 000020 002260 CMP #16, TS.PAT ; IF NOT PATTERN 16
7748 063574 001050 BNE 20# ; SKIP PATTERN 16 QUESTIONS
7749
7750 10#: GMANIL T3P16, IFLAGS, IPAT16, YES ; CHANGE PATTERN 16?
063576 TRAP C#GMAN
063576 104443 BR 10001#
063600 000404 .WORD IFLAGS
063602 002204 .WORD T#CODE
063604 000130 .WORD T3P16
063606 064526 .WORD IPAT16
063610 000100
10001#:
7751 063612 032737 000100 002204 BIT #IPAT16, IFLAGS ; IF NOT SET
7752 063620 001436 BEQ 20# ; USE DEFAULT 16
7753
7754 MOV #PAT00+2, R3 ; GET POINTER TO PATTERN 16 SIZE
7755 063622 012703 006250 MOV (R3), TEMP ; GET PATTERN SIZE
7755 063626 011337 002212 GMANID T3NWD, TEMP, D, -1, 1, .16, .YES; NUMBER OF DATA WORDS?
7756 063632 TRAP C#GMAN
063632 104443 BR 10002#
063634 000406 .WORD TEMP
063636 002212 .WORD T#CODE
063640 000052 .WORD T3NWD
063642 064555 .WORD -1
063644 177777 .WORD T#LOLIM
063646 000001 .WORD T#HILIM
063650 000020
  
```

CZUDJAO UDA50-A/KDA50-Q SUBSY E MACRO V05.03 Wednesday 02-Oct-85 16:03 Page 141-1
 TEST 3 MANUAL INTERVENTION QUESTIONS

```

10002$:
7757 063652 013723 002212      MOV      TEMP,(R3)+          ; SAVE PATTERN SIZE
7758 063656 013702 002212      MOV      TEMP,R2            ; GET COUNT OF DATA WORDS
7759 063662 011337 002212      MOV      (R3),TEMP          ; GET LAST PATTERN
7760 063666      104443      12$:  GMANID T3WRD,TEMP,0,-1,0,-1,YES; DATA WORD?
      063666      000406      TRAP     C$GMAN
      063670      002212      BR       10003$
      063672      000032      .WORD   TEMP
      063674      064612      .WORD   T$CODE
      063676      177777      .WORD   T3WRD
      063700      000000      .WORD   -1
      063702      177777      .WORD   T$LOLIM
      063704      000000      .WORD   T$HILIM
10003$:
7761 063706 013723 002212      MOV      TEMP,(R3)+          ; SAVE DATA WORD
7762 063712 005302      DEC      R2                  ; DECREMENT WORD COUNTER
7763 063714 001364      BNE     12$                  ; IF NOT ZERO, GET NEXT WORD
7764
7765 063716 013705 002200      20$:  MOV      CTABS,R5          ; GET ADDRESS OF 1ST CONTROLLER TABLE
7766 063722 012702 000004      21$:  MOV      #4,R2              ; GET COUNT OF DRIVE TABLES
7767 063726 010504      MOV      R5,R4              ; GET FIRST DRIVE TABLE POINTER
7768 063730 062704 000016      ADD     #C.DRO,R4
7769 063734 012403      22$:  MOV      (R4)+,R3          ; IF NO MORE DRIVES,
7770 063736 001002      BNE     23$                  ; GET NEXT
7771 063740 000137 064340      JMP     41$                  ; CONTROLLER TABLE
7772 063744 032763 100000 000002 23$:  BIT      #DT.AVL,D.UNIT(R3) ; IF DRIVE IS TO BE TESTED,
7773 063752 001402      BEQ     30$                  ; ASK DRIVE QUESTIONS
7774 063754 000137 064330      JMP     40$
7775
7776 063760      010446      30$:  PUSH     <R4>                ; SAVE REGISTERS
      063760      016337 000002 002212      MOV      R4,-(SP)            ; PUSH R4 ON STACK
7777 063762 042737 177700 002212      MOV      D.UNIT(R3),TEMP    ; GET DRIVE
7778 063770      011346      BIC     #+CDT.UNIT,TEMP     ; UNIT NUMBER
7779 063776      011546      PRINTF #T3QHED,TEMP,(R5),(R3) ; PRINT HEADER
      064000      013746 002212      MOV      (R3),-(SP)
      064002      012746 064701      MOV      (R5),-(SP)
      064006      010600      MOV     TEMP,-(SP)
      064012      062706 000012 002212      MOV     #T3QHED,-(SP)
      064016      012746 000004      MOV     #4,-(SP)
      064020      010600      MOV     SP,R0
      064022      104417      TRAP   C$PNTF
      064026      016337 000002 002212      ADD     #12,SP
7780 064026      016337 000002 002212      MOV     D.UNIT(R3),TEMP     ; GET DRIVE FLAGS
7781 064034      104443      GMANIL T3TED,TEMP,DT.BES,YES ; TEST OVER ENTIRE DISK?
      064034      000404      TRAP   C$GMAN
      064036      002212      BR     10004$
      064040      000130      .WORD  TEMP
      064042      064360      .WORD  T$CODE
      064044      020000      .WORD  T3TED
      064046      000000      .WORD  DT.BES
10004$:
7782 064050      013763 002212 000002      MOV     TEMP,D.UNIT(R3)    ; CHECK FOR BIT 15 SET
7783 064056      032763 020000 000002      BIT     #DT.BES,D.UNIT(R3) ; IF USING ENTIRE DISK,
7784 064064      001103      BNE     38$                  ; SKIP B/E SET QUESTIONS
7785 064066      016337 000004 002212      MOV     D.BEC(R3),TEMP     ; GET PREVIOUS B/E SET COUNT

```

```

7786 064074          GMANID T3BES,TEMP,D,-1,1,4,YES ; NUMBER OF B/E SETS?
      064074 104443   TRAP    C$GMAN
      064076 000406   BR      10005$
      064100 002212   .WORD  TEMP
      064102 000052   .WORD  T$CODE
      064104 064412   .WORD  T3BES
      064106 177777   .WORD  -1
      064110 000001   .WORD  T$LOLIM
      064112 000004   .WORD  T$HILIM
      064114          10005$:
7787 064114 013701 002212   MOV    TEMP,R1 ; INIT LOOP COUNTER
7788 064120 010163 000004   MOV    R1,D.BEC(R3) ; SAVE NEW B/E SET COUNT
7789 064124 010304          MOV    R3,R4 ; GET POINTER TO STORAGE AREA
7790 064126 062704 000006   ADD    #D.BGN1,R4 ; POINT TO START OF 1ST B/E SET
7791 064132 004737 047552   33$: CALL  BLDSTR ; BUILD DEFAULT VALUE
7792 064136          GMANID T3BEG,TEMP,A,-1,0,9.,YES; BEGIN BLOCK?
      064136 104443   TRAP    C$GMAN
      064140 000406   BR      10006$
      064142 002212   .WORD  TEMP
      064144 000152   .WORD  T$CODE
      064146 064452   .WORD  T3BEG
      064150 177777   .WORD  -1
      064152 000000   .WORD  T$LOLIM
      064154 000011   .WORD  T$HILIM
      064156          10006$:
7793 064156 004737 047616   CALL  BLDLWD ; CHECK RESPONSE & SAVE IN TABLE
7794 064162 103763          BCS    33$ ; BRANCH ON ERROR
7795 064164 004737 047552   34$: CALL  BLDSTR ; BUILD DEFAULT VALUE
7796 064170          GMANID T3END,TEMP,A,-1,0,9.,YES; END BLOCK?
      064170 104443   TRAP    C$GMAN
      064172 000406   BR      10007$
      064174 002212   .WORD  TEMP
      064176 000152   .WORD  T$CODE
      064200 064467   .WORD  T3END
      064202 177777   .WORD  -1
      064204 000000   .WORD  T$LOLIM
      064206 000011   .WORD  T$HILIM
      064210          10007$:
7797 064210 004737 047616   CALL  BLDLWD ; CHECK RESPONSE & SAVE IN TABLE
7798 064214 103763          BCS    34$ ; BRANCH ON ERROR
7799 064216 026464 177776 177772   CMP    -2(R4),-6(R4) ; IF ENDING LBN
7800 064224 101020          BHI    37$ ; LESS THAN
7801 064226 103404          BLO    35$ ; STARTING LBN
7802 064230 026464 177774 177770   CMP    -4(R4),-8.(R4) ; PRINT ERROR
7803 064236 103013          BHIS  37$ ; AND RE-PROMPT
7804 064240          35$: PRINTF #INP28C
      064240 012746 065123   MOV    #INP28C,-(SP)
      064244 012746 000001   MOV    #1,-(SP)
      064250 010600          MOV    SP,R0
      064252 104417          TRAP  C$PNTF
      064254 062706 000004   ADD    #4,SP
7805 064260 162704 000010   SUB    #8.,R4
7806 064264 000722          BR     33$
7807 064266 005301          37$: DEC    R1
7808 064270 001320          BNE   33$ ; DECREMENT LOOP COUNT
           ; IF NOT DONE, LOOP
    
```

```

7809 064272 000415
7810 064274 012763 000001 000004 38$: BR 39$ ;
7811 064302 005063 000006 MOV #1,D.BEC(R3) ; USE
7812 064306 005063 000010 CLR D.BGN1(R3) ; DEFAULT
7813 064312 012763 177777 000012 CLR D.BGN1+2(R3) ; BEGIN/END
7814 064320 012763 177777 000014 MOV #-1,D.END1(R3) ; SET
7815 064326 POP #-1,D.END1+2(R3) ; (ENTIRE DISK)
7816 39$: POP <R4> ; RESTORE DRIVE TABLE POINTER
7817 064330 005302 40$: DEC R2 ; IF MORE DRIVE TABLES,
7818 064332 001402 BEQ 41$ ; ASK QUESTIONS FOR
7819 064334 000137 063734 JMP 22$ ; NEXT DRIVE
7820 064340 062705 000170 41$: ADD #C.SIZE,R5 ; POINT TO NEXT CONTROLLER TABLE
7821 064344 005715 TST (R5) ; IF MORE CONTROLLER TABLES,
7822 064346 001402 BEQ 42$ ; ASK QUESTIONS FOR
7823 064350 000137 063722 JMP 21$ ; NEXT CONTROLLER
7824 064354 42$: NOP ;
7825 064354 000240 RETURN ; [DBG] INSERT HALT FOR DEBUG
7826 064356 000207
7827 ;
7828 ; UNFORMATTED QUESTIONS
7829 ;
7830 ;
7831 064360 124 105 123 T3TED: .ASCIZ \TEST OVER THE ENTIRE DISK\
7832 064412 116 125 115 T3BES: .ASCIZ \NUMBER OF BEGIN/END SETS TO USE\
7833 064452 123 124 101 T3BEG: .ASCIZ \STARTING LBN\
7834 064467 105 116 104 T3END: .ASCIZ \ENDING LBN\
7835 064502 104 101 124 T3PAT: .ASCIZ \DATA PATTERN TO USE\
7836 064526 115 117 104 T3P16: .ASCIZ \MODIFY DATA PATTERN 16\
7837 064555 110 117 127 T3NWD: .ASCIZ \HOW MANY WORDS IN PATTERN 16\
7838 064612 104 101 124 T3WRD: .ASCIZ \DATA WORD \
7839 ;
7840 ; FORMATTED QUESTIONS
7841 ;
7842 064625 045 116 045 T3QHDR: .ASCIZ \#N#ATEST 3 MANUAL INTERVENTION QUESTIONS:#N\
7843 064701 045 116 045 T3QHED: .ASCIZ \#N#ATHESE QUESTIONS REFER TO UNIT #D2#A CONTROLLER AT #06#A DRIVE #D3#N\
7844 065011 045 101 114 INP28A: .ASCIZ \#ALIMITS - LO= 0, HI= 4294967295#N\
7845 065054 045 101 111 INP28B: .ASCIZ \#AINVALID INPUT, TYPE DECIMAL NUMBER#N\
7846 065123 045 101 111 INP28C: .ASCIZ \#AINVALID INPUT, ENDING LBN LESS THAN STARTING LBN#N\
7847 .EVEN
7848
7849 065210 ENDTST
065210 L10061:
065210 104401 TRAP C#ETST
7850
    
```

```

7852          .SBTTL  HARDWARE PARAMETER CODING SECTION
7853
7854          ;++
7855          ;      THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
7856          ;      THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES.  THE
7857          ;      MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
7858          ;      INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
7859          ;      MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
7860          ;      WITH THE OPERATOR.
7861          ;--
7862 065212      BGNHRD
          065212      .WORD L10062-L$HARD/2
          065214      000014
          L$HARD::
7863          TABLE                                ;START A TABLE DEFINITION
7864 065214      ITEM H.IPR          2          <CSR ADDRESS>
7865 065214      ITEM H.DRV          2          <DRIVE NUMBER>
7866 065214      ITEM H.PRM          2          <PROGRAM PARAMETERS>
7867 065214
7868
7869          HM.WRT  == BIT12                        ; WRITE ON CUSTOMER DATA AREA
7870 065214      END
7871
7872 065214      GPRMA  MSGIPR,H.IPR,0,160000,177774,YES; CSR ADDRESS OF CONTROLLER?
          065214      .WORD  T$CODE
          065216      065244      .WORD  MSGIPR
          065220      160000      .WORD  T$LOLIM
          065222      177774      .WORD  T$HILIM
7873
7874 065224      GPRMD  MSGLDR,H.DRV,D,-1,0.,254.,YES; DRIVE #?
          065224      001052      .WORD  T$CODE
          065226      065276      .WORD  MSGLDR
          065230      177777      .WORD  -1
          065232      000000      .WORD  T$LOLIM
          065234      000376      .WORD  T$HILIM
7875
7876 065236      GPRML  MSGCST,H.PRM,HM.WRT,YES ; WRITE ON CUSTOMER DATA AREA?
          065236      002130      .WORD  T$CODE
          065240      065306      .WORD  MSGCST
          065242      010000      .WORD  HM.WRT
7877
7878 065244      ENDHRD
          065244      .EVEN
          L10062:
7879
7880 065244      103      123      122  MSGIPR: .ASCIZ  \CSR ADDRESS OF CONTROLLER\
7881 065276      104      122      111  MSGLDR: .ASCIZ  \DRIVE #\
7882 065306      127      122      111  MSGCST: .ASCIZ  \WRITE ON CUSTOMER DATA AREA\
7883          .EVEN
7884

```

```

7886          .SBTTL SOFTWARE PARAMETER CODING SECTION
7887
7888          ;++
7889          ; THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
7890          ; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
7891          ; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
7892          ; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
7893          ; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
7894          ; WITH THE OPERATOR.
7895          ;--
7896
7897          BGNSFT
7898          .WORD L10063-L$SOFT/2
7899          L$SOFT::
7900          TABLE ; START A TABLE DEFINITION
7901          ITEM SO.EL      2      <HARD ERROR LIMIT>
7902          ITEM SO.TL      2      <TIME LIMIT (MINUTES)>
7903          ITEM SO.SRI     2      <STATISTICAL REPORT INTERVAL>
7904          ITEM SO.MTS     2      <MAXIMUM TRANSFER SIZE>
7905          ITEM SO.BIT     2      <SINGLE BIT ANSWERS>
7906
7907          SM.MAN == BIT00 ; MANUAL INTERVENTION MODE
7908          SM.PSE == BIT01 ; PRINT SOFT ERRORS
7909          SM.PCK == BIT02 ; PATTERN VERIFICATION ON READS
7910          SM.CMP == BIT03 ; PATTERN VERIFICATION ON WRITES
7911          SM.VLT == BIT04 ; VARIABLE LENGTH TRANSFERS
7912          SM.EER == BIT05 ; ENABLE ERROR RETRIES
7913          SM.ECC == BIT06 ; ENABLE ECC
7914          SM.RAN == BIT07 ; RANDOMLY ACCESS DRIVE
7915          SM.DET == BIT08 ; DO DETERMINISTIC PHASE
7916          END
7917
7918          DISPLAY S.HDR ; PRINT HEADER
7919          .WORD T$CODE
7920          .WORD S.HDR
7921
7922          GPRML S.MAN,SO.BIT,SM.MAN,YES ; ENTER MANUAL INTERVENTION MODE?
7923          .WORD T$CODE
7924          .WORD S.MAN
7925          .WORD SM.MAN
7926
7927          GPRMD S.EL,SO.EL,D,-1,1,-1..YES; ERROR LIMIT?
7928          .WORD T$CODE
7929          .WORD S.EL
7930          .WORD -1
7931          .WORD T$LOLIM
7932          .WORD T$HILIM
7933
7934          GPRMD S.TL,SO.TL,D,-1,0.,65535..YES; EXERCISER TIME LIMIT?
7935          .WORD T$CODE
7936          .WORD S.TL
7937          .WORD -1
7938          .WORD T$LOLIM
7939          .WORD T$HILIM
7940
7941          7886
7942          7887
7943          7888
7944          7889
7945          7890
7946          7891
7947          7892
7948          7893
7949          7894
7950          7895
7951          7896
7952          7897 065342 000061
7953          065342
7954          065344
7955          7898 065344
7956          7899 065344
7957          7900 065344
7958          7901 065344
7959          7902 065344
7960          7903 065344
7961          7904
7962          7905 000001
7963          7906 000002
7964          7907 000004
7965          7908 000010
7966          7909 000020
7967          7910 000040
7968          7911 000100
7969          7912 000200
7970          7913 000400
7971          7914 065344
7972          7915
7973          7916 065344
7974          065344 000003
7975          065346 065506
7976
7977          7917
7978          7918 065350
7979          065350 004130
7980          065352 065567
7981          065354 000001
7982
7983          7919
7984          7920 065356
7985          065356 000052
7986          065360 065626
7987          065362 177777
7988          065364 000001
7989          065366 177777
7990
7991          7921
7992          7922 065370
7993          065370 001052
7994          065372 065647
7995          065374 177777
7996          065376 000000
7997          065400 177777
7998
7999          7923

```

7924	065402		GPRMD	S.SRI,SO.SRI,D,-1,0.,65535.,YES; STATISTICAL REPORT INTERVAL?
	065402	002052	.WORD	T\$CODE
	065404	065707	.WORD	S.SRI
	065406	177777	.WORD	-1
	065410	000000	.WORD	T\$LOLIM
	065412	177777	.WORD	T\$HILIM
7925				
7926	065414		GPRML	S.SSF,SO.BIT,SM.PSE,YES ; PRINT SOFT ERRORS?
	065414	004130	.WORD	T\$CODE
	065416	065753	.WORD	S.SSF
	065420	000002	.WORD	SM.PSE
7927				
7928	065422		GPRML	S.PCK,SO.BIT,SM.PCK,YES ; PATTERN VERIFICATION ON READS?
	065422	004130	.WORD	T\$CODE
	065424	066005	.WORD	S.PCK
	065426	000004	.WORD	SM.PCK
7929				
7930	065430		GPRML	S.CMP,SO.BIT,SM.CMP,YES ; PATTERN VERIFICATION ON WRITES?
	065430	004130	.WORD	T\$CODE
	065432	066053	.WORD	S.CMP
	065434	000010	.WORD	SM.CMP
7931				
7932	065436		GPRML	S.VLT,SO.BIT,SM.VLT,YES ; VARIABLE LENGTH TRANSFERS?
	065436	004130	.WORD	T\$CODE
	065440	066122	.WORD	S.VLT
	065442	000020	.WORD	SM.VLT
7933				
7934	065444		GPRMD	S.MTS,SO.MTS,D,-1,1.,128.,YES; MAXIMUM TRANSFER SIZE?
	065444	003052	.WORD	T\$CODE
	065446	066160	.WORD	S.MTS
	065450	177777	.WORD	-1
	065452	000001	.WORD	T\$LOLIM
	065454	000200	.WORD	T\$HILIM
7935				
7936	065456		GPRML	S.EER,SO.BIT,SM.EER,YES ; ENABLE ERROR RETRIES?
	065456	004130	.WORD	T\$CODE
	065460	066220	.WORD	S.EER
	065462	000040	.WORD	SM.EER
7937				
7938	065464		GPRML	S.ECC,SO.BIT,SM.ECC,YES ; USE ECC?
	065464	004130	.WORD	T\$CODE
	065466	066245	.WORD	S.ECC
	065470	000100	.WORD	SM.ECC
7939				
7940	065472		GPRML	S.RAN,SO.BIT,SM.RAN,YES ; RANDOMLY ACCESS DRIVE?
	065472	004130	.WORD	T\$CODE
	065474	066300	.WORD	S.RAN
	065476	000200	.WORD	SM.RAN
7941				
7942	065500		GPRML	S.DET,SO.BIT,SM.DET,YES ; DO DETERMINISTIC PHASE?
	065500	004130	.WORD	T\$CODE
	065502	066326	.WORD	S.DET
	065504	000400	.WORD	SM.DET
7943				
7944	065506		ENDSFT	

				L10063:		.EVEN
7945	065506					
7946	065506	124	110	105	S.HDR:	.ASCIZ \THE FOLLOWING QUESTIONS APPLY ONLY TO TEST 3:\
7947	065564	040	000			.ASCIZ \ \
7948	065566	000				.BYTE 0
7949	065567	105	116	124	S.MAN:	.ASCIZ \ENTER MANUAL INTERVENTION MODE\
7950	065626	110	101	122	S.EL:	.ASCIZ \HARD ERROR LIMIT\
7951	065647	105	130	105	S.TL:	.ASCIZ \EXERCISER TIME LIMIT IN MINUTES\
7952	065707	115	111	116	S.SRI:	.ASCIZ \MINUTES BETWEEN STATISTICAL REPORTS\
7953	065753	120	122	111	S.SSF:	.ASCIZ \PRINT SOFT ERROR MESSAGES\
7954	066005	104	117	040	S.PCK:	.ASCIZ \DO DATA PATTERN VERIFICATION ON READS\
7955	066053	104	117	040	S.CMP:	.ASCIZ \DO DATA PATTERN VERIFICATION ON WRITES\
7956	066122	125	123	105	S.VLT:	.ASCIZ \USE VARIABLE LENGTH TRANSFERS\
7957	066160	115	101	130	S.MTS:	.ASCIZ \MAXIMUM TRANSFER SIZE IN BLOCKS\
7958	066220	105	116	101	S.EER:	.ASCIZ \ENABLE ERROR RETRIES\
7959	066245	105	116	101	S.ECC:	.ASCIZ \ENABLE ECC DATA CORRECTION\
7960	066300	122	101	116	S.RAN:	.ASCIZ \RANDOMLY ACCESS DRIVE\
7961	066326	104	117	040	S.DET:	.ASCIZ \DO DETERMINISTIC PHASE\
7962						.EVEN
7963						

CZUDJAO UDA50-A/KDA50-Q SUBSY E MACRO V05.03 Wednesday 02-Oct-85 16:03 Page 144
SOFTWARE PARAMETER CODING SECTION

```
7965      ;++
7966      ;      THIS IS A PATCH AREA THAT SHOULD BE INCLUDED IN ALL DIAGNOSTICS.
7967      ;      THE SIZE IS ADJUSTED AS NEEDED.
7968      ;--
7969
7970 066356 $PATCH::
7971 066356      .BLKW  32.
7972
7973 066456      LASTAD
              .EVEN
              .WORD T$FREE
              .WORD T$SIZE
              L$LAST::
066456 066474
066460 000005
7974
```

```

7976
7977
7978
7979
7980
7981
7982
7983
7984
7985
7986
7987
7988 066462
7989 066462
      066462 000000
      066464 000003
7990 066466 172150
7991 066470 000000
7992 066472 000000
7993 066474
      066474
7994 066474
7995
7996      000001
    
```

```

:++
:
:   HARDCODED P-TABLES MAY BE PLACED HERE BY USING THE SETUP MACROS.
:   THIS SECTION IS OPTIONAL AND SHOULD BE REMOVED IF IT IS NOT BEING
:   USED.  CHANGE THE POINTER MACRO ARGUMENT TO REFLECT THE REMOVAL.
:
:   THE P-TABLES ARE DELIMITED BY THE "BGNSETUP" AND "ENDSETUP" MACROS.
:   THE "BGNSETUP" MACRO HAS ONE ARGUMENT WHICH IS THE NUMBER OF
:   P-TABLE ENTRIES.  EACH ENTRY IS DELIMITED BY THE "BGNPTAB" AND
:   "ENDPTAB" MACROS.  NEITHER OF THESE MACROS REQUIRE AN ARGUMENT.
:--
      BGNSETUP      1
      BGNPTAB
      .WORD      0
      .WORD      L10066-./2-1
L10064: .WORD      172150
      .WORD      0.
      .WORD      0.
      ENDPTAB
L10066:
      ENDSETUP
      .END
; CSR ADDRESS
; DRIVE NUMBER
; WRITE COSTUMER DATA AREA
    
```

ACCESS 050306
 ADR = 000020 G
 ADRCNT 036350
 ADRDAT 035160
 ADRDRV 037152
 ALOCM 024322
 AMAP 007544
 AMAV 007505
 AMDU 007521
 ASSEMB= 000010
 ATNACC 040032
 ATNAVA 037742
 ATNDUP 040002
 ATN1SG 011147
 AVAIL 050020
 BADMEM 024310
 BASLO 007403
 BASL1 007406
 BASL2 007437
 BASNO 007254
 BASN1 007300
 BASN2 007330
 BASN3 007357
 BCHI 004410
 BCLO 004406
 BELL = 000007 G
 BESFIT 024570
 BFTOMM 025276
 BIT0 = 000001 G
 BIT00 = 000001 G G
 BIT01 = 000002 G G
 BIT02 = 000004 G G
 BIT03 = 000010 G G
 BIT04 = 000020 G G
 BIT05 = 000040 G G
 BIT06 = 000100 G G
 BIT07 = 000200 G G
 BIT08 = 000400 G G
 BIT09 = 001000 G G
 BIT1 = 000002 G G
 BIT10 = 002000 G G
 BIT11 = 004000 G G
 BIT12 = 010000 G G
 BIT13 = 020000 G G
 BIT14 = 040000 G G
 BIT15 = 100000 G G
 BIT2 = 000004 G G
 BIT3 = 000010 G G
 BIT4 = 000020 G G
 BIT5 = 000040 G G
 BIT6 = 000100 G G
 BIT7 = 000200 G G
 BIT8 = 000400 G G
 BIT9 = 001000 G G
 BLANK 010221

BLDLWD 047616
 BLDME 051214
 BLDSTR 047552
 BOE = 000400 G
 BUFBA 004370
 BUFBLK 004374
 BUFEA 004372
 BUFMRG 024702
 BUFSIZ 004376
 CALR3 053762
 CALR4 054006
 CALR5 054136
 CALR6 054270
 CALR7 054424
 CALR8 054446
 CBUFF 003364
 CF.ATN= 000200
 CF.CTO= 040000
 CF.ERL= 020000
 CF.FAI= 100000
 CF.MSC= 000100
 CF.OTH= 000040
 CF.RPL= 100000
 CF.SMD= 000002
 CF.T.S= 000020
 CF.576= 000001
 CHKSTA 032332
 CLRRSP 026132
 CMDSIZ= 000051
 CMPHD 050360
 CNTINT 052220
 CNTRSD 002354
 CNTRSP 053252 G
 CNTSRV 054502 G
 CR = 000015 G
 CRLF 010300
 CTABS 002200
 CTLCHK 027140
 CTRLRS 002202
 CT.AVL= 100000
 CT.BRL= 007000
 CT.DET= 002000
 CT.DI = 004000
 CT.DUN= 040000
 CT.IOC= 010000
 CT.MRW= 000400
 CT.MSG= 020000
 CT.UNT= 000077
 CT.VEC= 000777
 C\$AU = 000052
 C\$AUTO= 000061
 C\$BRK = 000022
 C\$BSEG= 000004
 C\$BSUB= 000002
 C\$CLCK= 000062

C\$CLEA= 000012
 C\$CLOS= 000035
 C\$CLP1= 000006
 C\$CPBF= 000074
 C\$CPME= 000075
 C\$CVEC= 000036
 C\$DCLN= 000044
 C\$DODU= 000051
 C\$DRPT= 000024
 C\$DU = 000053
 C\$EDIT= 000001
 C\$ERDF= 000055
 C\$ERHR= 000056
 C\$ERRO= 000060
 C\$ERSF= 000054
 C\$ERSQ= 000057
 C\$ESCA= 000010
 C\$ESEG= 000005
 C\$ESUB= 000003
 C\$ETST= 000001
 C\$EXIT= 000032
 C\$FREQ= 000101
 C\$FRME= 000100
 C\$GETB= 000026
 C\$GETW= 000027
 C\$GMAN= 000043
 C\$GPHR= 000042
 C\$GPRI= 000040
 C\$INIT= 000011
 C\$INLP= 000020
 C\$MANI= 000050
 C\$MAP = 000102
 C\$MEM = 000031
 C\$MTU = 000103
 C\$MSG = 000023
 C\$OPNR= 000034
 C\$OPNW= 000104
 C\$PNTB= 000014
 C\$PNTF= 000017
 C\$PNTS= 000016
 C\$PNTX= 000015
 C\$PUTB= 000072
 C\$PUTW= 000073
 C\$QIO = 000377
 C\$RDBU= 000007
 C\$REFG= 000047
 C\$REL = 000077
 C\$RESE= 000033
 C\$REVI= 000004
 C\$RFLA= 000021
 C\$RPT = 000025
 C\$SEFG= 000046
 C\$SPRI= 000041
 C\$SVEC= 000037
 C\$TOME= 000076

C.CBAS= 000072
 C.CEND= 000074
 C.CINT= 000106
 C.CMBL= 000162
 C.CMFL= 000160
 C.CPTR= 000070
 C.CRED= 000152
 C.CRNG= 000132
 C.CTO = 000006
 C.DRO = 000016
 C.DR1 = 000020
 C.DR2 = 000022
 C.DR3 = 000024
 C.FLG = 000014
 C.IPR = 000000
 C.JAD = 000012
 C.JSR = 000010
 C.MSIZ= 000034
 C.NEXT= 000042
 C.RBAS= 000100
 C.REND= 000102
 C.RHDR= 000104
 C.RINT= 000110
 C.ROFF= 000036
 C.RPTR= 000076
 C.RRNG= 000112
 C.SIZE= 000170
 C.STEP= 000030
 C.TBSB= 000166
 C.TBSF= 000164
 C.TO = 000154
 C.TOH = 000156
 C.TPAT= 000040
 C.TYPE= 000026
 C.UCNT= 000032
 C.UID = 000060
 C.UNIT= 000002
 C.VEC = 000004
 C.XFHR= 000056
 C.XFHW= 000050
 C.XFLR= 000052
 C.XFLW= 000044
 C.XFMR= 000054
 C.XFMW= 000046
 C25MSZ= 000000
 DBGACC 023404
 DBGATN 023005
 DBGAVL 023245
 DBGCMD 023704
 DBGCHP 023562
 DBGERS 023440
 DBGFLG 022762
 DBGGCS 023057
 DBGGUS 023127
 DBGINV 023033

DBGMRD 023473
 DBGMRW 023526
 DBGONL 023304
 DBGRD 023616
 DBGRSP 024132
 DBGSCC 023174
 DBGSDN 022764
 DBGSDUC 023340
 DBGWR 023650
 DEBUG = 000001
 DETDUN 010415
 DETHDR 010341
 DFPTBL 002134 G
 DIAGMC= 000000
 DISK = 000000
 DIVIDE 047256
 DIV48 047326
 DRIVER 026426
 DRPCNT 027350
 DRPUNT 027424
 DTABS 002176
 DT.AVL= 100000
 DT.BES= 020000
 DT.CLR= 147000
 DT.CHP= 004000
 DT.DUN= 040000
 DT.EOM= 002000
 DT.ONL= 001000
 DT.PRM= 020000
 DT.UNT= 000077
 DT.WRT= 010000
 DUP = 001000
 D.BEC = 000004
 D.BES = 000046
 D.BGN1= 000006
 D.BGN2= 000016
 D.BGN3= 000026
 D.BGN4= 000036
 D.BLKS= 000050
 D.CCNT= 000060
 D.CERR= 000116
 D.DRV = 000000
 D.ECCC= 000120
 D.END1= 000012
 D.END2= 000022
 D.END3= 000032
 D.END4= 000042
 D.HERR= 000112
 D.LBN = 000052
 D.SERR= 000114
 D.SIZE= 000136
 D.UID = 000122
 D.UNIT= 000002
 D.VSN = 000132
 D.WCNT= 000056

Symbol table

D.XFHA=	000102	ERR006	017332	G	F\$SEG =	000003	INITXX	062554	L\$AU	062634	G
D.XFHC=	000110	ERR014	017362	G	F\$SOFT=	000005	INIT1	060652	L\$AUT	002070	G
D.XFHR=	000074	ERR021	017452	G	F\$SRV =	000010	INIT2	061064	L\$AUTO	062610	G
D.XFHW=	000066	ERR022	017524	G	F\$SUB =	000002	INIT3	061122	L\$CCP	002106	G
D.XFLA=	000076	ERR023	017606	G	F\$SW =	000014	INIT4	061140	L\$CLEA	062612	G
D.XFLC=	000104	ERR024	017770	G	F\$TEST=	000001	INIT5	061506	L\$CO	002032	G
D.XFLR=	000070	ERR025	020046	G	F.HDR	004624	INIT6	061706	L\$DEPO	002011	G
D.XFLW=	000062	ERR026	020126	G	GCSTAT	050056	INIT7	062062	L\$DESC	007162	G
D.XFMA=	000100	ERR027	020210	G	GETBC	045502	INP28A	065011	L\$DESP	002076	G
D.XFMC=	000106	ERR030	020246	G	GETBES	046060	INP28B	065054	L\$DEVP	002060	G
D.XFMR=	000072	ERR031	020264	G	GETBUF	024354	INP28C	065123	L\$DISP	002124	G
D.XFMW=	000064	ERR032	020312	G	GETLBN	045550	INVCMO	027744	L\$DLY	002116	G
EF.BBR=	000200	ERR033	020346	G	GETME	025550	IPAT16=	000100	L\$DTP	002040	G
EF.BBU=	000100	ERR034	020402	G	GDRVT	047164	IREST =	000004	L\$DTYP	002034	G
EF.CON=	000036	ERR035	020454	G	GTNXTD	045526	ISR =	000100	L\$DU	062632	G
EF.LOG=	000040	ERR037	020510	G	GUSTAT	050114	ISTRT =	000010	L\$DUT	002072	G
EF.NEW=	000035	ERR038	020576	G	G+CNTD=	000200	ITEMP =	000040	L\$DVTY	007142	G
EF.PWR=	000034	ERR039	020714	G	G+DELM=	000372	ITOA	047472	L\$EF	002052	G
EF.RES=	000037	ERR040	021016	G	G+DISP=	000003	IXE =	004000	L\$ENVI	002044	G
EF.SEX=	000020	ERR041	021240	G	G+EXCP=	000400	I\$AU =	000041	L\$ERRT	002156	G
EF.STA=	000040	ERR042	021462	G	G+HILI=	000002	I\$AUTO=	000041	L\$ETP	002102	G
EF.XM =	000033	ERR043	021626	G	G+LOLI=	000001	I\$CLN =	000041	L\$EXP1	002046	G
ENDACC	031004	ERR050	021654	G	G+NO =	000000	I\$DU =	000041	L\$EXP4	002064	G
ENDADR	027676	ERR051	021706	G	G+OFFS=	000400	I\$HRD =	000041	L\$EXP5	002066	G
ENDAVL	030274	ERR052	022004	G	G+OFST=	000376	I\$INIT=	000041	L\$HARD	065214	C
ENDCMP	031600	ERR053	022122	G	G+PRMA=	000001	I\$MOD =	000041	L\$HIME	002120	G
ENDERS	031120	ERR054	022236	G	G+PRMD=	000002	I\$MSG =	000041	L\$HPCP	002016	G
ENDGCS	027774	ERR060	022472	G	G+PRML=	000000	I\$PROT=	000040	L\$HPTP	002022	G
ENDGUS	030152	ERR061	022544	G	G+RADA=	000140	I\$PTAB=	000041	L\$HW	002134	G
ENDMRD	031240	ERR21A	017516		G+RADB=	000000	I\$PWR =	000041	L\$ICP	002104	G
ENDMWR	031510	ERR21E	017522		G+RADD=	000040	I\$RPT =	000041	L\$INIT	060364	G
ENDNUM	027630	ERR23A	017724		G+RADL=	000120	I\$SEG =	000041	L\$LADP	002026	G
ENDONL	030364	ERR23B	017754		G+RADO=	000020	I\$SETU=	000041	L\$LAST	066462	G
ENDRD	031720	EVL =	000004	G	G+XFER=	000004	I\$SFT =	000041	L\$LOAD	002100	G
ENDSCC	030200	E\$END =	002100		G\$YES =	000010	I\$SRV =	000041	L\$LUN	002074	G
ENDSIZ=	000044	E\$LOAD=	000035		HISEED	002362	I\$SUB =	000041	L\$MREV	002050	G
ENDSUC	030714	FFREE	002166		HM.WRT=	010000	I\$TST =	000041	L\$NAME	002000	G
ENDWR	032166	FMADR	002172		HOE =	100000	J\$JMP =	000167	L\$PRIO	002042	G
ERASE	050532	FMSIZ	002174		H.DRV =	000002	KW.BRL	002324	L\$PROT	060356	G
ERLSTA	022334	F\$SIZE	002170		H.IPR =	000000	KW.CSR	002322	L\$PRT	002112	G
ERRBLK	002164	F\$AU =	000015		H.PRM =	000004	KW.EL	002332	L\$REPP	002062	G
ERRCNT	040112	F\$AUTO=	000020		IBE =	010000	KW.HZ	002330	L\$REV	002010	G
ERRDTE	040322	F\$BGN =	000040		ICONT =	000002	KW.OUT=	000105	L\$RPT	054534	G
ERRHMA	040216	F\$CLEA=	000007		IDIE =	040000	KW.VEC	002326	L\$SOFT	065344	G
ERRLIH	010527	F\$DU =	000016		IDU =	000040	KW.60	002336	L\$SPC	002056	G
ERRMSG	002162	F\$END =	000041		IDUN =	010000	KW11I	054512	L\$SPCP	002020	G
ERRNBR	002160	F\$HARD=	000004		IER =	020000	LF	000012	L\$SPTP	002024	G
ERRSDE	040572	F\$HW =	000013		IERL =	020000	LF.CON=	000100	L\$STA	002030	G
ERRSDI	040446	F\$INIT=	000006		IFLAGS	002204	LF.SNR=	000001	L\$SW	002144	G
ERRTYP	002156	F\$JMP =	000050		IMMU =	100000	LF.SUC=	000200	L\$TEST	002114	G
ERRVEC=	000004	F\$MOD =	000000		INITBL	002340	LOE =	040000	L\$TIML	002014	G
ERR002	017056	F\$MSG =	000011		INITWA	010725	LOSEED	002360	L\$UNIT	002012	G
ERR003	017124	F\$PROT=	000021		INITWB	010777	LOT =	000010	L.BADR=	000030	G
ERR004	017172	F\$PWR =	000017		INITWC	011044	L\$ACP	002110	L.CHVR=	000025	G
ERR005	017240	F\$RPT =	000012		INITWD	010224	L\$APT	002036	L.CNTI=	000014	G

CZUDJAO UDA50-A/KDA50-Q SUBSY E MACRO V05.03 Wednesday 02-Oct-85 16:03 Page 145-3
Symbol table

L.CRF = 000000	L10046 060354	MMBUF 004400	MSGLOG 016373	OPCGCS 007745
L.CSVR= 000024	L10050 062606	MMOFF 004404	MSGPKT 022616	OPCGUS 007772
L.EVNT= 000012	L10051 062610	MMPKTS 004626	MSGSUC 016205	OPCMRD 010152
L.FLGS= 000011	L10052 062630	MMSIZ 004402	MSHST0 036012	OPCMWR 010175
L.FMT = 000010	L10053 062632	MMT0BF 025154	MSHST1 036046	OPCONL 010014
L.HDCD= 000050	L10054 062634	MNTPAT 007036	MSHST2 036073	OPCRD 010025
L.LVL = 000042	L10055 063210	MNTRD 051112	MSHST3 036112	OPCRPL 010034
L.MLUN= 000026	L10056 063126	MNTWR 051122	MSHST4 036136	OPSCCC 010046
L.RTRY= 000043	L10057 063204	MSAVAO 033760	MSHST5 036167	OPCSUC 010107
L.SCYL= 000042	L10060 063302	MSCMPO 034664	MSINVO 033074	OPCWR 010142
L.SDI = 000054	L10061 065210	MSCNTO 036372	MSMFE0 034154	OP.ABO= 000001
L.SEQ = 000006	L10062 065244	MSCNT0 036416	MSMFE1 034202	OP.ACC= 000020
L.UHVR= 000041	L10063 065506	MSCNT1 036451	MSMFE2 034247	OP.AVA= 000100
L.UNIT= 000004	L10064 066466	MSCNT2 036451	MSMFE3 034263	OP.AVL= 000010
L.UNTI= 000030	L10066 066474	MSCNT3 036463	MSMFE4 034277	OP.CCD= 000021
L.USVR= 000040	MAINT = 177760	MSCNT4 036521	MSOFL0 033440	OP.CMP= 000040
L.VSER= 000044	MAINTP 051130	MSCNT5 036544	MSOFL1 033460	OP.DAP= 000013
L10000 002142	MAPMEM 025006	MSCNT6 036611	MSOFL2 033524	OP.DUP= 000101
L10001 002156	MD.ALL= 000002	MSCNT7 036657	MSOFL3 033545	OP.END= 000200
L10002 017122	MD.CMP= 040000	MSCNT8 036715	MSOFL4 033604	OP.ERS= 000022
L10003 017170	MD.CSE= 020000	MSCNT9 036754	MSOFL5 033632	OP.FLU= 000023
L10004 017236	MD.CWB= 000010	MSCPOP 002314	MSSUC0 032632	OP.GCS= 000002
L10005 017330	MD.ERR= 010000	MSDATA 035516	MSSUC1 032645	OP.GUS= 000003
L10006 017360	MD.EXP= 100000	MSDATB 035542	MSSUC2 032667	OP.MRD= 000030
L10007 017450	MD.FEU= 000001	MSDATC 035566	MSSUC3 032707	OP.MWR= 000031
L10010 017522	MD.IMF= 000002	MSDATD 035612	MSSUC4 032735	OP.ONL= 000011
L10011 017604	MD.NXU= 000001	MSDATZ 035230	MSSUC5 032754	OP.RD = 000041
L10012 017766	MD.PRI= 000001	MSDAT0 035212	MSSUC6 032771	OP.RPL= 000024
L10013 020044	MD.RIP= 000001	MSDAT1 035260	MSUNK0 033164	OP.SCC= 000004
L10014 020124	MD.SCH= 004000	MSDAT2 035277	MSWPRO 034434	OP.SEX= 000007
L10015 020206	MD.SCL= 002000	MSDAT4 035323	MSWPR1 034457	OP.SHC= 000102
L10016 020244	MD.SEC= 000100	MSDAT5 035353	MSWPR2 034520	OP.SUC= 000012
L10017 020262	MD.SEQ= 000020	MSDAT6 035376	MULT 047420	OP.WR = 000042
L10020 020310	MD.SER= 000400	MSDAT7 035422	MUTOFF 004412	O#APTS= 000001
L10021 020344	MD.SHD= 000020	MSDAT8 035446	MUTSIZ 004516	O#AU = 000001
L10022 020400	MD.SPD= 000001	MSDAT9 035472	M.HDR 004622	O#BGNR= 000001
L10023 020452	MD.SSH= 000200	MSDRVA 037562	NOCL0C 011071	O#BGNS= 000001
L10024 020506	MD.SWP= 000004	MSDRVB 037616	NOMEH 062574	O#DU = 000001
L10025 020574	MD.VOL= 000002	MSDRVC 037653	NUMCNT 036326	O#ERRT= 000001
L10026 020712	MD.WBN= 000100	MSDRV0 037202	NUMDAT 035126	O#GNSW= 000001
L10027 021014	MD.WBV= 000040	MSDRV1 037221	NUMDRV 037122	O#POIN= 000001
L10030 021236	MEMIN 006232	MSDRV2 037250	NXHAD 002264	O#SETU= 000001
L10031 021460	ME.CBL= 000002	MSDRV3 037317	NXMI 054472	PATBLD 046474
L10032 021624	ME.CFG= 000016	MSDRV4 037340	OBUFF 002364	PATCHK 046100
L10033 021652	ME.CFL= 000000	MSDRV5 037366	OFF = 000000	PATDSP 006776
L10034 021704	ME.CL = 000022	MSDRV6 037412	ON = 000001	PAT00 006246
L10035 022002	ME.CP = 000026	MSDRV7 037436	ONLINE 050150	PAT01 006312
L10036 022120	ME.CRF= 000004	MSDRV8 037463	OPCABO 007562	PAT02 006320
L10037 022234	ME.CTH= 000010	MSDRV9 037517	OPCACC 007572	PAT03 006326
L10040 022332	ME.CTO= 000006	MSGBBR 016267	OPCAVL 007603	PAT04 006334
L10041 022542	ME.CV = 000024	MSGBBU 016326	OPCCCD 007617	PAT05 006400
L10042 022614	ME.OFF= 000020	MSGCON 016236	OPCCMP 007651	PAT06 006444
L10043 054500	ME.PKT= 000022	MSGCST 065306	OPCDAP 007675	PAT07 006510
L10044 054510	ME.ST1= 000012	MSGFAI 016160	OPCERS 007725	PAT08 006516
L10045 054532	ME.ST2= 000014	MSGIPR 065244	OPCFLU 007735	PAT09 006562
		MSGLDR 065276		

PAT10	006570	P.UNFL =	000016	RSPEND	027554	SC.DII =	000600	SM.EER =	000040	G
PAT11	006634	P.UNIT =	000004	RSPERL	040036	SC.DIS =	000400	SM.MAN =	000001	G
PAT12	006642	P.UNSZ =	000044	RSPIN	027500	SC.DSY =	000140	SM.PCK =	000004	G
PAT13	006706	P.UNTI =	000024	RSPSIZ =	000103	SC.DUP =	000200	SM.PSE =	000002	G
PAT14	006752	P.USVR =	000052	RSPSTR	006230	SC.EDC =	000100	SM.RAN =	000200	G
PAT15	006764	P.VRSN =	000014	RSP.ER	053226	SC.FCT =	000300	SM.VLT =	000020	G
PCBAD	004366	P.VSER =	000050	RSP.SU	053244	SC.FOR =	000000	SNDMSG	051504	
PCGOOD	004364	QDXMSZ =	000000	RSP.S1	053122	SC.HDR =	000100	SND.S1	002342	
PKTSIZ =	000006	Q50MSZ =	032413	RSP.S2	053160	SC.HMP =	000200	SND.S2	002346	
PNT	= 001000	RANDOM	026250	RSP.S3	053204	SC.HMP =	020000	SO.BIT =	000010	
PRI	= 002000	READ	050556	RTNALL	025606	SC.IEE =	000200	SO.EL =	000000	
PRI00	= 000000	REINIT	053420	RTNME	026006	SC.IIC =	000140	SO.MTS =	000006	
PRI01	= 000040	RESET	053452	SA.BST =	000374	SC.IOP =	000100	SO.SRI =	000004	
PRI02	= 000100	REBUF	025420	SA.CMD =	034000	SC.IPT =	000240	SO.TL =	000002	
PRI03	= 000140	RE.RFL =	000000	SA.CME =	000070	SC.LPI =	000240	SSSTEP4	002352	
PRI04	= 000200	RE.RL =	000002	SA.CMI =	004000	SC.LPO =	000300	STAABO	033220	
PRI05	= 000240	RE.RP =	000006	SA.CNT =	000360	SC.LRR =	000300	STAADR	032422	
PRI06	= 000300	RE.RV =	000004	SA.CTP =	003400	SC.LRW =	000200	STAABA	033700	
PRI07	= 000340	RG.FLG =	040000	SA.CTQ =	003400	SC.NVL =	000040	STACMP	034562	
P.ADBA	000020	RG.OMN =	100000	SA.DI =	000400	SC.NXM =	000140	STACNT	036220	
P.ADEA	000022	RNGLEN =	000004	SA.ERC =	003777	SC.OBC =	000100	STACOD	032372	
P.BCNT	000014	RNGPMR =	011000	SA.ERR =	100000	SC.OTA =	000040	STADAT	034702	
P.BUFF	000020	RNTMH	002266	SA.GO =	000001	SC.POE =	000140	STADRV	037004	
P.CHVR	000023	RNTIM	010303	SA.INE =	000200	SC.PRO =	000500	STAHST	035630	
P.CHST	000020	RNTIM	053550	SA.INT =	000200	SC.PSE =	000400	STAINV	033024	
P.CNTF	000016	RNTIME	002270	SA.LFC =	000002	SC.RBN =	000440	STAMFE	034000	
P.CNTI	000024	RNTSS	002272	SA.MCV =	000017	SC.RCT =	000400	STAMSO	002316	
P.CPSP	000042	RPTAF	002306	SA.MP =	000100	SC.RCV =	010000	STAMS1	002320	
P.CRF	000000	RPTAV	002304	SA.MSE =	000007	SC.RRC =	000640	STAOFL	033250	
P.CSVR	000022	RPTB	060001	SA.MSG =	003400	SC.SDS =	000040	STASIZ =	000026	
P.CTMO	000020	RPTCF	002312	SA.MS1 =	000400	SC.SOL =	001000	STASUC	032452	
P.CYLS	000050	RPTCV	002310	SA.NV =	002000	SC.SPI =	000040	STANUK	033114	
P.DVPM	000034	RPTDED	060253	SA.NVE =	000400	SC.STC =	000100	STAMPR	034320	
P.FBBK	000034	RPTDES	056750	SA.PRG =	000001	SC.SMP =	010000	STIME	002250	
P.FLGS	000011	RPTDE1	060007	SA.QB =	001000	SC.UEC =	000340	ST.ABO =	000002	
P.GRPS	000046	RPTDE2	060042	SA.SM =	000040	SC.UNK =	000000	ST.AVL =	000004	
P.HTMO	000020	RPTDE3	060145	SA.STE =	000200	SC.XME =	000100	ST.CMD =	000001	
P.LBN	000034	RPTHOR	057300	SA.STP =	100000	SC.1EC =	000400	ST.CMP =	000007	
P.MEDI	000034	RPTIOC	057623	SA.S1 =	004000	SC.2EC =	000440	ST.CNT =	000012	
P.MLUN	000014	RPTIOD	057674	SA.S2 =	010000	SC.3EC =	000500	ST.DAT =	000010	
P.MOD	000012	RPTIOE	057743	SA.S3 =	020000	SC.4EC =	000540	ST.DIA =	000037	
P.OPCD	000010	RPTIO1	057333	SA.S4 =	040000	SC.5EC =	000600	ST.DRV =	000013	
P.OTRF	000014	RPTIO2	057370	SA.TST =	100000	SC.576 =	000240	ST.HST =	000011	
P.RBN	000014	RPTIO3	057505	SA.VCE =	000177	SC.6EC =	000640	ST.HFE =	000005	
P.RBNS	000056	RPTKB	060003	SA.VEC =	000177	SC.7EC =	000700	ST.HSK =	000037	
P.RCTC	000057	RPTLUN	002274	SA.WRP =	040000	SC.8EC =	000740	ST.OFL =	000003	
P.RCTS	000054	RPTMB	060005	SCC	050210	SETMIN	052144	ST.SUB =	000040	
P.RGID	000034	RPTRF	002302	SC.AQL =	000400	SETTO	052070	ST.SUC =	000000	
P.RGDF	000040	RPTRV	002300	SC.CEC =	000200	SFPTBL	002144	ST.WPR =	000006	G
P.SHST	000042	RPTSTA	060327	SC.CIP =	000340	SIZCNT =	000020	SUCHAR	050246	
P.SHLN	000040	RPTSTB	060341	SC.CME =	000440	SIZDAT =	000030	SVCGBL =	000000	
P.STS	000012	RPTTF	002276	SC.COU =	000400	SIZDRV =	000026	SVCINS =	000000	
P.TIME	000024	RPTWV	002274	SC.CTO =	000040	SM.CMP =	000010	SVCSUB =	000000	
P.TRKS	000044	RSPATN	037704	SC.DCD =	000240	SM.DET =	000400	SVCTAG =	000000	G
P.UHVR	000053	RSPCNT	006226	SC.DDE =	000340	SM.ECC =	000100	SVCTST =	000000	G
				SC.DFI =	000550					

Symbol table

S\$LSYM=	010000	T\$SIZE=	000005	T2S1	041666	T3S4E	044044	X22B	012273
S.CMP	066053	T\$SUBN=	000000	T2S2	041720	T3S5	044140	X23A	012325
S.DET	066326	T\$TAGL=	177777	T2S2E	042010	T3S5E	044274	X23C	012441
S.ECC	066245	T\$TAGN=	010067	T2S2N	041764	T3S6	044524	X23D	012530
S.EER	066220	T\$TEMP=	000005	T2S3	042050	T3S6E	045310	X23E	012602
S.EL	065626	T\$TEST=	000003	T2S4	042122	T3S7	045410	X23F	012636
S.HDR	065506	T\$TSTM=	177777	T2S4E	042204	T3TED	064360	X24A	012655
S.MAN	065567	T\$TSTS=	000001	T2S4N	042160	T3WARN	010625	X24B	012762
S.MTS	066160	T\$#AU =	010054	T2S5	042216	T3WRD	064612	X25	013034
S.PCK	066005	T\$#AUT=	010051	T2S6	042306	T3W1	043166	X26	013135
S.RAN	066300	T\$#CLE=	010052	T2S6E	042402	T3W2	043634	X27	013215
S.SRI	065707	T\$#DAT=	010066	T2S6N	042364	T3W4	044352	X3	011255
S.SSF	065753	T\$#DU =	010053	T2S6R	042412	T3W5	045366	X31	013317
S.TL	065647	T\$#HAR=	010062	T2S7	042440	UAM	= 000200 G	X32	013415
S.VLT	066122	T\$#HW =	010000	T2S7E	042554	UF.CMR=	000001	X33	013526
TAPE	= 000400	T\$#INI=	010050	T2S7N	042536	UF.CM=	000002	X34	013635
TBSMIN	006234	T\$#MSG=	010042	T2S7R	042564	UF.INA=	040000	X35	013754
TBSSIZ	006236	T\$#PC =	000001	T2S8	042612	UF.IMV=	000200	X37A	014102
TBSTRT	006240	T\$#PRO=	010047	T2S8E	042664	UF.RPL=	100000	X37B	014167
TEMP	002212	T\$#PTA=	010065	T2S8R	042702	UF.SCH=	004000	X37C	014267
TIMLIM	010453	T\$#RPT=	010046	T2W1	042026	UF.SCL=	002000	X38A	014343
TINDEX=	000012	T\$#SOF=	010063	T2W2	042264	UF.WBN=	000100	X38B	014433
TNAMES	007244	T\$#SRV=	010045	T2W3	042416	UF.WPH=	020000	X38C	014474
TNUM	002206	T\$#SUB=	010057	T2W4	042570	UF.WPS=	010000	X39A	014545
TSPGEN	002246	T\$#SW =	010001	T3	063304 G	UF.576=	000004	X39B	014632
TSTIM	002254	T\$#TES=	010061	T38EG	064452	UTEST	002210	X39C	014675
TSTOFF	002242	T.HDR	006242	T38ES	064412	U50MSZ=	036413	X4A	011340
TSTOPC	002244	T1	062636 G	T3DSP	042706	VECSAV	002262	X4B	011421
TS.PAT	002260	T1DSP	040716	T3END	064467	WCHNG	053652	X41	014744
T\$ARGC=	000001	T1LOE	041164	T3L1E	043162	WCHNGD	002356	X42A	015001
T\$CODE=	004130	T1L1E	041474	T3L2E	043630	WRITE	050646	X42B	015077
T\$ERRN=	000032	T1L2E	041560	T3L3E	044134	XBHW	016457	X42C	015145
T\$EXCP=	000000	T1NEXT	062664	T3L4E	044346	XFCE	016543	X43	015154
T\$FLAG=	000040	T1PGEN	040734	T3L5E	045362	XFERPK	050744	X5A	011504
T\$FREE=	066474	T1SKIP	063116	T3L6E	045476	XFRU	016743	X5B	011550
T\$GHAN=	000000	T1S0	040764	T3NMD	064555	XFRUA	017013	X5C	011626
T\$HILI=	000200	T1S1	041052	T3PAT	064502	XMSG1	016612	X50A	015253
T\$LAST=	000001	T1S2	041212	T3PGEN	042736	XMSG2	016647	X51A	015325
T\$LOLI=	000001	T1S3	041300	T3P16	064526	XSA	016705	X51B	015407
T\$LSYM=	010000	T1S4	041500	T3QHDR	064625	XSAE	016656	X52A	015443
T\$LTNO=	000003	T1W1	041170	T3QHED	064701	XSTA	016423	X52B	015520
T\$NEST=	177777	T1W2	041416	T3QUES	063520	X\$ALWA=	000000	X53A	015573
T\$NSO =	000005	T1.1	062652	T3S0	042766	X\$FALS=	000040	X53B	015636
T\$NS1 =	000032	T1.2	063130	T3S1	043026	X\$OFFS=	000400	X54A	015731
T\$PCNT=	000000	T2	063212 G	T3S2	043060	X\$TRUE=	000020	X54B	016003
T\$PTAB=	010065	T2DSP	041564	T3S2E	043150	X14A	011750	X6	011652
T\$PTHV=	000001	T2L1E	042022	T3S2N	043124	X14B	012044	X60	016024
T\$PTNU=	000001	T2L2E	042260	T3S3	043350	X14C	012126	X61	016077
T\$SAVL=	177777	T2PGEN	041616	T3S3E	043534	X2	011211	\$PATCH	066356 G
T\$SEGL=	177777	T2S0	041646	T3S4	043656	X22A	012175		

. ABS. 066474 000 (RW,I,GBL,ABS,OVR)
 000000 001 (RW,I,LCL,REL,CON)
 Errors detected: 0

CZUDJAO UDA50-A/KDA50-Q SUBSY E MACRO V05.03 Wednesday 02-Oct-85 16:03 Page 145-6
Symbol table

*** Assembler statistics

Work file reads: 407
Work file writes: 396
Size of work file: 37386 Words (147 Pages)
Size of core pool: 19372 Words (74 Pages)
Operating system: RSX-11M/PLUS (Under VAX/VMS)

Elapsed time: 00:10:16.25
ZUDJAO.BIC,ZUDJAO/CR/-SP=SVC41R.MLB/ML,ZUDJAO.MEM,ZUDJAO.MAC