

Maintenance Library

3274

**Control Unit
Models 51C and 52C
Maintenance Concepts**

Third Edition (February 1981)

This edition is a revision of and supersedes SY27-2528-1. The new information concerns the X.21 Switched Feature. In addition to technical changes throughout this manual, the 31SD Diskette Drive Parts Catalog has been removed. The 31SD parts catalog is now included in Appendix F of *3274 Control Unit Models 51C and 52C Maintenance Information, SY27-2513*.

IBM has prepared this maintenance manual for the use of IBM customer engineers in the installation, maintenance, or repair of the specific machines indicated. IBM makes no representations that it is suitable for any other purpose.

The drawings and specifications contained herein shall not be reproduced in whole or in part without written permission.

Information contained in this manual is subject to change from time to time. Any such change will be reported in subsequent revisions or Technical Newsletters.

It is possible that this material may contain references to, or information about, IBM products (machines and programs), programming, or services that are not announced in your country. Such references or information must not be construed to mean that IBM intends to announce such IBM products, programming, or services in your country.

Requests for copies of IBM publications should be made to your IBM representative or to the IBM branch office serving your locality.

A form for readers' comments is provided at the back of this publication. If the form has been removed, address comments to IBM Corporation, Department 52Q, Neighborhood Road, Kingston, N.Y. 12401. IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation whatever. You may, of course, continue to use the information you supply.

Preface

This manual contains the information needed by the support field engineering (FE) customer engineer to maintain the IBM 3274 Control Unit Models 51C and 52C.

The maintenance procedures described in this manual and performed by the support FE customer engineer represent a part of the overall support structure for the 3274 Control Unit. This support structure begins at the 3274 operator level and is briefly described as follows:

- **3274 Operator** – Performs initial problem isolation and recording of 3274 status indications by following the procedure in the *3274 Problem Determination Guide*, GA27-2854. If the problem is other than a customer operating procedure or customer-supplied power, the operator completes the *3274 Problem Report Form* and requests IBM service.
- **Product Customer Engineer** – Performs the maintenance procedures contained in the *3274 Maintenance Information* manual (MIM) to isolate the problem to a field replaceable unit (FRU). The *3274 Problem Report Form* prepared by the operator gives the 3274 indications necessary for performing these procedures. If the problem cannot be isolated and corrected, the product customer engineer requests assistance from the next level of the support structure.
- **Support Customer Engineer** – Verifies the results obtained by the product customer engineer and performs an in-depth analysis of the problem by means of the following:
 - Tests
 - Log Information
 - Error Code Definitions
 - Result of Host Test Routines
 - Special Tools and Test Equipment

If the problem cannot be isolated and resolved with the use of these service aids, the support customer engineer records the problem indications and supporting information on the 3274 Problem Checklist and requests assistance from the next level of the support structure.

Organization

This manual is organized as follows:

- Chapter 1 – Maintenance Approach and System Overview
- Chapter 2 – Subsystem Indicators, Symbols, and Messages
- Chapter 3 – Subsystem Error Logs and Test Formats
- Chapter 4 – Subsystem Tests, External Tests, and Subsystem Service Aids
- Chapter 5 – Reference Data
- Chapter 6 – Tools and Test Equipment
- Appendix A – Support Structure Information Form
- Appendix B – 3274 Models 51C and 52C Error Codes
- Appendix C – Structured Field and Attribute Processing (SFAP) Data Stream Error Extensions
- Appendix D – IBM 31SD Diskette Drive Maintenance
- Appendix E – IBM 31SD Diskette Drive Maintenance Analysis Procedures (MAPs)
- Appendix F – X.21 Switched Feature F-1
- Appendix G – Abbreviations

Contents

Chapter 1. Maintenance Approach and System Overview	1-1
1.1	Maintenance Approach 1-1
1.2	Subsystem Data Flow 1-3
1.2.1	IML Test Data Path 1-4
1.2.2	IML of Unit Code 1-4
1.2.3	Message Data Flow between 3274 Control Unit and Attached Devices 1-5
1.2.4	Message Data Flow between 3274 Control Unit and Host System 1-6
1.2.5	Logic Data Flow 1-7
1.3	Subsystem Functions 1-8
1.3.1	Control Unit Power On Reset 1-9
1.3.2	Keystroke Handling 1-9
1.3.3	Sending to Host 1-11
1.3.4	Receiving from Host 1-11
1.3.5	Error Handling and Logging 1-11
1.3.6	Internal Testing 1-11
1.3.7	Function Priority 1-12
1.3.8	Type A Adapter Coax Data Path 1-13
1.4	Supporting Publications 1-14
Chapter 2. Subsystem Indicators, Symbols, and Messages	2-1
2.1	Introduction 2-1
2.2	8 4 2 1 Indicators 2-1
2.3	Power ON/OFF Indicator 2-1
2.4	Operator Information Area Layout 2-2
2.4.1	Readiness and System Connection Symbols 2-2
2.4.2	Do Not Enter (Input Inhibited) Symbols 2-2
2.4.3	Communication Reminder Symbol 2-5
2.4.4	Shifts and Modes Symbols 2-5
2.4.5	Printer Status Messages 2-6
2.4.6	Machine Check Numbers 2-6
2.4.7	Program Check Numbers 2-6
2.4.8	Communication Check Numbers 2-6
Chapter 3. Subsystem Error Logs and Test Formats	3-1
3.1	Introduction 3-1
3.2	Test 0: Communication Path Test and 3278 Display Test 3-1
3.2.1	Description 3-1
3.2.2	Procedure for Requesting Test 0 3-2
3.3	Test 1: Overview 3-2
3.3.1	Test 1 Device Logs 3-3
3.3.2	Test 1 Host Adapter Logs 3-5
3.3.3	Test 1 Common Communications Adapter (CCA) Log for BSC 3-5
3.3.4	Test 1 Common Communications Adapter (CCA) Log and High-Performance Communications Adapter (HPCA) Log for SDLC 3-11
3.3.5	Test 1 Storage Card Isolation (Model 52C Only) 3-16
3.3.6	Test 1 Device Adapter Logs 3-16
3.3.7	Test 1 Type A Adapter Log 3-16
3.3.8	Test 1 Type B Adapter Log 3-17
3.3.9	Control Logic Error Log 3-17
3.3.10	X.21 Switched Log 3-18
3.3.11	Test 1 Extension for X.21 Switched 3-20
3.4	Test 2: Display Configuration Information 3-21
3.5	Test 3: Display the Status of All Configured Terminals and Display the Control Unit Summary Counters 3-23
3.6	Test 4: Reset Any Test 1 Log 3-24
3.7	Test 6: Device Control Block Display 3-24
3.7.1	Test 6 Byte Identification 3-24
3.7.2	DCB Bit Definitions 3-25
3.8	Test 7: Dynamic Convergence (Color) 3-27
3.9	Test 8: PSs, Highlighting, and Color 3-27
3.10	Kanji/Chinese Character Display 3-27
3.11	3277 Path Test and Test Request Key 3-27
3.11.1	BSC or Local Host Attached 3-27
3.11.2	SNA Attached 3-27
Chapter 4. Subsystem Tests, External Tests, and Subsystem Service Aids	4-1
4.1	Introduction 4-1
4.2	Initial Machine Load (IML) Tests 4-1
4.2.1	ALT 1 IML Mode 4-1
4.2.2	ALT 2 IML Mode, Models 51C and 52C with Wrappable Modem (Test/Operate Switch in Operate Position) 4-2
4.2.3	ALT 2 IML Mode, Models 51C and 52C without Wrappable Modem (Test/Operate Switch in Test Position) 4-2
4.2.4	ALT 2 IML Mode, Modem Self-Test for Model C with Greater than 1200-bps Integrated Modem 4-3
4.3	3274 Model 51C Display System Online Tests 4-3
4.3.1	Purpose 4-3
4.3.2	Applicable Executive Control Programs 4-3
4.3.3	3274 Models 51C and 52C Online Tests 4-3
4.4	Serviceability Aids 4-4
4.4.1	Diskette Patching Procedure 4-4
4.4.2	3274 Subsystem Dump Procedure 4-6
4.4.3	Coax Cables 4-6
4.4.3.1	Cable h (Indoor) 4-6
4.4.3.2	Cable l (Outdoor) 4-6
4.4.3.3	Coaxial Cable Splicing 4-7
4.4.4	Coax Testing with Scope 4-7
4.4.4.1	Testing for Discontinuities 4-7
4.4.4.2	Setup and Test Procedures 4-8
Chapter 5. Reference Data	5-1
5.1	Introduction 5-1
5.2	Control Unit Command Summary 5-1
5.2.1	Write 5-1
5.2.2	Erase/Write 5-1
5.2.3	Erase/Write Alternate 5-1
5.2.4	Erase All Unprotected 5-1
5.2.5	Read Buffer 5-1
5.2.6	Read Modified 5-1
5.2.6.1	Read Modified Read 5-2
5.2.6.2	Short Read Read 5-2
5.2.6.3	Test Request Read (Model 51C, BSC) 5-2
5.2.7	Read Modified All (3274 SNA Only) 5-2
5.2.8	Copy (3274 Model 51C, BSC) 5-2
5.3	Control Unit Order Summary 5-2
5.3.1	Set Buffer Address (SBA) 5-2
5.3.2	Start Field (SF) 5-2
5.3.3	Insert Cursor (IC) 5-2
5.3.4	Repeat to Address (RA) 5-2
5.3.5	Erase Unprotected to Address (EUA) 5-2
5.3.6	Program Tab (PT) 5-3
5.3.7	New Line (NL) 5-3
5.3.8	End of Message (EM) 5-3
5.3.9	Duplicate (DUP) 5-3
5.3.10	Field Mark (FM) 5-4
5.3.11	Forms Feed (FF) (3287, 3288, and 3289 Printers) 5-4
5.3.12	Suppress Index (SI) (3288) 5-4
5.3.13	Carriage Return (CR) (3287 with 3274 Attachment and 3289 Printers) 5-4
5.4	I/O Interface Codes 5-4
5.5	Examining 3279 Attributes and Modified Data Tags 5-12

5.6	Sequence/Response Diagrams, BSC	5-12
5.7	Remote Status and Sense Byte Definitions, BSC	5-22
5.7.1	Error Recovery Procedures	5-26
5.7.2	Supplementary Procedures	5-27
5.8	SDLC Sequence Response Descriptions	5-27
5.8.1	SDLC Transmission Frames	5-27
5.8.1.1	Response Modes	5-28
5.8.1.2	Control Field	5-28
5.8.2	Sequence Error Recovery Procedures	5-29
5.8.2.1	Abort Function	5-29
5.8.2.2	Timeout Control	5-29
5.8.3	Hexadecimal Notation and Frame Summary	5-29
5.9	SNA Information	5-30
5.9.1	Session Control	5-30
5.9.2	Data Flow Control	5-30
5.9.3	Transmission Header	5-30
5.9.4	Request/Response Header	5-31
5.9.5	SNA Definitions	5-32
5.9.6	SDLC/SNA Command to Start a Session	5-32
5.10	SDLC/SNA Error Information	5-33
5.10.1	Exception Response with Sense Data Included	5-33
5.10.2	SNA Sense Codes	5-34
5.10.3	Logical Unit Status (LUSTAT)	5-36
5.10.4	Command Reject	5-38
5.10.5	Request Maintenance Statistics (REQMS) Command	5-38
5.10.5.1	Record Formatted Maintenance Statistics (REFMS)	5-39
5.10.5.2	REFMS Formats	5-39
5.11	Switches and Controls	5-41
5.12	BSC and SNA Readiness Symbols	5-42
5.13	Digital Data Service (DDS) Adapter	5-44

Chapter 6. Tools and Test Equipment 6-1

6.1	Introduction	6-1
6.2	Buffered Teleprocessing Diagnostic Analyzer and Tester (BTDAT)	6-1
6.3	NU Data Tester	6-1
6.4	PT-2 Attachment to Non-EIA Interfaces	6-1

Appendix A. Support Structure Information Form A-1

Appendix B. 3274 Models 51C and 52C Error Codes B-1

**Appendix C. Structured Field and Attribute Processing (SFAP)
Data Stream Error Extensions C-1**

Appendix D. IBM 31SD Diskette Drive Maintenance D-1

D.1	Introduction	D-7
D.2	Device Theory of Operation	D-17
D.3	Maintenance	D-26

**Appendix E. IBM 31SD Diskette Drive Maintenance
Analysis Procedures (MAPs) E-1**

Appendix F. X.21 Switched Feature F-1

F.1	Introduction	F-1
F.2	Functional Description	F-1
F.2.1	X.21 Switched CAC Function	F-2
F.2.1.1	Function Requests	F-2
F.2.1.2	Call Collision	F-2
F.2.1.3	Call Progress (CP) Signals	F-3
F.2.2	Data Link Control Function	F-3
F.2.2.1	Call Ready	F-3
F.2.2.2	Incoming Call In Process	F-3
F.2.2.3	Dialing	F-3
F.2.2.4	Direct Call	F-3
F.2.2.5	Outgoing Call In Process	F-3
F.2.2.6	Local Mode	F-3
F.2.2.7	Disconnection	F-4
F.2.3	X.21 Switched Adapter (X.21 SA) Card	F-4
F.3	Extension Key and Modifier Keys	F-4
F.3.1	Locations	F-4
F.3.2	Extension Mode	F-4
F.4	Status and Key Operation	F-5
F.5	Error Codes and Recovery	F-6
F.6	Call Progress Signal Code	F-6

Appendix G. Abbreviations G-1

Figures

1-1	Support Customer Engineer Maintenance Approach	1-2	5-1	Command Codes	5-1
1-2	3274 Subsystem Overview	1-3	5-2	Buffer Control Orders and Order Codes	5-3
1-3	Initial Machine Load (IML) Data Flow	1-4	5-3	United States EBCDIC I/O Interface Code for 3274 Control Unit and Attached 3277 Display Stations	5-5
1-4	Message Data Flow between 3274 Control Unit and Attached Devices	1-5	5-4	United States EBCDIC I/O Interface Code for 3274 Control Unit and Attached 3278, 3279, 3287, and 3289 Terminals	5-6
1-5	Message Data Flow between 3274 Control Unit and Host System	1-6	5-5	United States ASCII I/O Interface Code for 3274 Control Unit and Attached 3278, 3279, 3287, and 3289 Terminals	5-7
1-6	Logic Data Flow	1-7	5-6	Format of Write Control Character (WCC) Byte	5-8
1-7	3274 Subsystem Functions	1-8	5-7	Function of Write Control Character (WCC) Bits	5-8
1-8	Keystroke Handling, Type A Adapter	1-10	5-8	Attribute Character Bit Assignments for 3278s	5-9
1-9	Inbound Messages	1-11	5-9	3278 Top-Card Connector CE Jumper (Three Base Cards)	5-9
1-10	Outbound Messages	1-12	5-10	3278 Top-Card Connector CE Jumper (Two Base Cards)	5-9
1-11	3274 Subsystem Functional Priorities	1-13	5-11	Attribute Character Bit Assignments for 3277s	5-10
1-12	Coax to Type A Adapter Data Flow	2-1	5-12	Control Character I/O Codes	5-11
1-13	Supporting Publications	2-2	5-13	3279 Top-Card Connector CE Jumper	5-12
2-1	8 4 2 1 Indicator Control Logic	2-3	5-14	3279 Base Field Attributes	5-12
2-2	Operator Information Area Layout	2-4	5-15	3274 Message Response to Polling or Read Modified Command	5-13
2-3	Readiness and System Connection Symbols (Locations 1 through 6) (2 parts)	2-5	5-16	General Poll and Specific Poll, Sequence/Response Diagram (2 parts)	5-14
2-4	Do not Enter Symbols (Locations 9 through 17) (2 parts)	2-6	5-17	Selection Addressing, Sequence/Response Diagram (2 parts)	5-16
2-5	Reminders (Locations 21 through 27)	2-7	5-18	Write-Type and Control-Type Commands, Sequence/Response Diagram (2 parts)	5-18
2-6	Shifts and Modes (Locations 37 through 41)	3-1	5-19	Read-Type Command, Sequence/Response Diagram (2 parts)	5-20
2-7	Printer Status (Locations 60 through 64)	3-2	5-20	Remote Status and Sense Byte Definitions, BSC	5-23
3-1	Summary of Counter Definitions by Log Type	3-3	5-21	Remote Error Status and Sense Responses, BSC (2 parts)	5-24
3-2	CCA BSC Operation Attempted Chart (Code FF)	3-4	5-22	Remote 3270 BSC Status and Sense Conditions	5-26
3-3	CCA BSC Operation Ending Chart (Code CCCC) (4 parts)	3-5	5-23	Nonsequenced Commands and Responses Supported by 3274	5-28
3-4	Sense Byte Breakdown Chart for CCA BSC (Code SSSS)	3-6	5-24	SDLC Commands and Responses in Hexadecimal Notation	5-29
3-5	CCA/HPCA SDLC Operation Attempted Chart (Code FF)	3-7	5-25	Session Control Functions Supported by 3274	5-30
3-6	CCA/HPCA SDLC Operation Ending Chart (Code CCCC) (2 parts)	3-8	5-26	Data Flow Control Requests Supported by 3274	5-30
3-7	Sense Byte Breakdown Chart for CCA/HPCA SDLC (Code SSSS) (2 parts)	3-9	5-27	Transmission Header Format	5-30
3-8	Sense (SS) Byte Definitions	3-10	5-28	Request/Response Header Format	5-31
3-9	Type B Adapter Operation Attempted Chart (Code FF)	3-11	5-29	SDLC/SNA Commands Required to Start Session with LU1	5-32
3-10	Type B Adapter Operation Ending Chart (Code CCCC)	3-12	5-30	SDLC/SNA Exception Responses	5-33
3-11	X.21 Switched Log Settings	3-13	5-31	Summary Table of LUSTATs	5-37
3-12	Subsystem Configuration (2 parts)	3-14	5-32	Command Reject (CMDR) Message Format	5-39
3-13	Test 6 Byte ID Chart	4-1	5-33	Switches and Controls	5-41
3-14	DCB Bit Definition Chart (3 parts)	4-2	5-34	BSC Readiness Symbols	5-42
4-1	IML Test Error Indications	4-3	5-35	SNA Readiness Symbols	5-43
4-2	ALT 1 IML Sequence	4-4	5-36	Connection of 3274 Control Unit Models 51C and 52C with DDS Adapter Feature	5-44
4-3	ALT 2 IML Sequence, Models 51C and 52C with Wrappable Modem	4-5	5-37	Digital Data Waveshapes	5-45
4-4	ALT 2 IML Sequence, Models 51C and 52C without Wrappable Modem	4-6	6-1	TPLM Tab Pin Locations	6-1
4-5	A1D2 Card Indicator for 2400-bps Integrated Modem	4-7	C-1	SFAP Error Relationships	C-1
4-6	A1D2 Card Indicator for 4800-bps Integrated Modem	4-8	D-1	IBM 31SD Diskette Drive	D-7
4-7	A1D2 Card Indicator for 9600-bps Integrated Modem	4-9	D-2	31SD Diskette	D-8
4-8	3274 Models 51C and 52C Online Tests	4-10	D-3	Diskette Insertion	D-9
4-9	Operator Codes	4-11	D-4	31SD Special Tools	D-10
4-10	Incident and Reflected Waves	4-12	D-5	31SD Physical Characteristics	D-11
4-11	Scope Setup	4-13	D-6	Environmental Characteristics	D-12
4-12	Measurement Points		D-7	Data Formats	D-12
4-13	Display Examples (3 parts)		D-8	Maximum Number of Formatted Data Bytes	D-12

D-9	Diskette Drive Parts (4 parts)	D-14	D-29	Head Gap Adjustment	D-41
D-10	Cylinder Access	D-17	D-30	Bail Removal	D-43
D-11	Control Lines at Connector A1	D-18	D-31	Solenoid and Idler Removal	D-44
D-12	Diskette Insertion and Head Load Operation	D-20	D-32	AC Drive Motor Removal	D-46
D-13	Diskette Operation Sequence	D-21	D-33	Stepper Motor	D-48
D-14	Write Operation	D-22	D-34	Stepper Motor Pulley and Clamp Removal and Replacement	D-50
D-15	Record Update—Write Operation	D-23	D-35	Drive Band Adjustment (2 parts)	D-51
D-16	Read Data Signals	D-23	D-36	Diskette Speed	D-53
D-17	File Data Signals	D-24	D-37	LED Output Check	D-54
D-18	31SD Test Pins	D-24	D-38	LED Removal and Replacement	D-55
D-19	31SD Control Card	D-25	D-39	PTX Amplifier Service Check	D-56
D-20	31SD Control Card Cable	D-25	D-40	PTX Removal and Replacement	D-58
D-21	Collet/Flat Spring Removal (2 parts)	D-26	D-41	Diskette Drive Control Card	D-59
D-22	Head/Carriage Pressure Pad Removal and Replacement	D-28	D-42	31SD Control Card and Cable Pins	D-60
D-23	Head/Carriage Service Check	D-30	F-1	Data Link Control Function	F-1
D-24	31SD Control Card	D-31	F-2	Keyboard Layout with X.21 Switched Feature	F-4
D-25	Head/Carriage Adjustment (2 parts)	D-32	F-3	3278/3279 Key Operation (During X.21 Switched States)	F-5
D-26	Head/Carriage Removal	D-35	F-4	3278/3279 Key Operation in Dial-In Mode	F-6
D-27	Head/Carriage Replacement (2 parts)	D-36	F-5	Call Progress Signal Code	F-6
D-28	Solenoid and Bail Service Check	D-39			

CE SAFETY PRACTICES

All Customer Engineers are expected to take every safety precaution possible and observe the following safety practices while maintaining IBM equipment:

1. You should not work alone under hazardous conditions or around equipment with dangerous voltage. Always advise your manager if you MUST work alone.
2. Remove all power AC and DC when removing or assembling major components, working in immediate area of power supplies, performing mechanical inspection of power supplies and installing changes in machine circuitry. Pull the power plug from the receptacle to remove power source.
3. Wall box power switch, when used to disconnect power, should be locked or tagged in off position. "Do not Operate" tags, form 229-1266, should be securely attached to power switch or to outside of power box.
4. When it is absolutely necessary to work on equipment having exposed operating mechanical parts or exposed live electrical circuitry anywhere in the machine, the following precautions must be followed:
 - a. At least one other person familiar with power off controls, emergency power off procedures, and the location of the wall box power switch, must be in the immediate vicinity at all times.
 - b. Rings, wrist watches, chains, bracelets, metal cuff links, shall not be worn.
 - c. Only insulated pliers and screwdrivers shall be used.
 - d. Keep one hand in pocket.
 - e. When using test instruments be certain they are of proper capacity and controls are set correctly. Only insulated probes are used.
 - f. Avoid contacting ground potential (metal floor strips, machine frames, etc. — use suitable rubber mats purchased locally if necessary).
5. Safety Glasses must be worn when:
 - a. Using a hammer to drive pins, riveting, staking, etc.
 - b. Power hand drilling, reaming, grinding, etc.
 - c. Using spring hooks, attaching springs.
 - d. Soldering, wire cutting, removing steel bands.
 - e. Parts cleaning, using solvents, sprays, cleaners, chemicals, etc.
 - f. All other conditions that may be hazardous to your eyes. REMEMBER, THEY ARE YOUR EYES.
6. Special safety instructions such as handling Cathode Ray Tubes and extreme high voltages, must be followed as outlined in CEM's and Safety Section of the Maintenance Manuals.
7. Do not use solvents, chemicals, greases or oils that have not been approved by IBM.
8. Avoid using tools or test equipment that have not been approved by IBM.
9. Replace worn or broken tools and test equipment.
10. The maximum load to be lifted is that which in the opinion of you and management does not jeopardize your own health or well-being or that of other employees.
11. All safety devices such as guards, shields, signs, ground wires, etc., shall be restored after maintenance.
12. Each Customer Engineer is responsible to be certain that no action on his part renders product unsafe or exposes hazards to customer personnel.
13. Place removed machine covers in a safe out-of-the-way place where no one can trip over them.
14. All machine covers must be in place before machine is returned to customer.
15. Always place CE tool kit away from walk areas where no one can trip over it (i.e., under desk or table).
16. Avoid touching mechanical moving parts (i.e., when lubricating, checking for play, etc.).
17. When using stroboscope — do not touch ANYTHING — it may be moving.
18. Avoid wearing loose clothing that may be caught in machinery. Shirt sleeves must be left buttoned or rolled above the elbow.
19. Ties must be tucked in shirt or have a tie clasp (preferably nonconductive) approximately 3 inches from end. Tie chains are not recommended.
20. Before powering up or starting equipment, make certain other CEs and customer personnel are not in a hazardous position.
21. Maintain good housekeeping in area of machines while performing and after completing maintenance.
22. Even though preventive measures are taken, accidents do occur. CEs and support personnel should be prepared to follow emergency first aid procedures as outlined below.

First Aid — General

1. If accidental electrocution occurs:
 - a. Remove power source before touching victim.
 - b. If power cannot be removed, pull victim away from equipment by using non-conductive material such as a broom handle, leather belt, or necktie.
 - c. Immediately begin rescue breathing; see below.
 - d. Begin CPR if necessary and only if trained person is available.
 - e. Call a doctor.
Have someone summon medical aid.
 - f. Remain in position.
After victim revives, be ready to resume respiration if necessary.
2. For serious injury:
 - a. Summon medical aid.
 - b. Do not move victim unless absolutely necessary to remove from danger.
 - c. Attempt to stop serious bleeding by using pressure points or a pressure bandage.
 - d. Loosen clothing and keep victim warm.

Artificial Respiration

General Considerations

1. Start Immediately, Seconds Count
Do not wait or look for help or stop to loosen clothing, warm the victim or apply stimulants.
2. Check Mouth for Obstructions
Remove foreign objects — Pull tongue forward.

Rescue Breathing for Adults — Place Victim on His Back Immediately

1. Clear throat of water, food, or foreign matter.
2. Tilt head back to open air passage.
3. Lift jaw up to keep tongue out of air passage.
4. Pinch nostrils to prevent air leakage when you blow.
5. Blow until you see chest rise.
6. Remove your lips and allow lungs to empty.
7. Listen for snoring and gurglings, signs of throat obstruction.
8. Repeat mouth to mouth breathings 10-20 times a minute. Continue rescue breathing until he breathes for himself, or medical aid arrives.



Thumb and
finger positions



Final mouth-
to-mouth
position

Reprint Courtesy Mine Safety Appliances Co.

Safety Notices

Personal Safety

The Danger and Caution notices that appear in this manual refer mainly to the 31SD Diskette Drive. Before using this manual, review all the Danger and Caution notices that are listed in the front of the *3274 Control Unit Maintenance Information* manual, SY27-2513.

General Personal Safety Information

AC voltages are present on the 31SD drive motor connector and capacitor terminals when the drive motor is running. The motor and the solenoid become hot after continuous use; let the parts cool before attempting servicing. The following Danger and Caution notices appear in this manual:

DANGER

Input AC voltage is present in the Prime Power Box when the 3274 I/O (on/off) switch is in the O (off) position.

DANGER

Voltage is still present at the socket when the power cable is disconnected.

DANGER

High voltage may be present at the capacitor terminals.

CAUTION: The solenoid case becomes hot after continuous use.

Machine Safety

The notices that appear in this manual refer mainly to the 31SD Diskette Drive. Before using this manual, review all the Warning notices that appear in the *3274 Control Unit Maintenance Information* manual, SY27-2513.

General Machine Safety Information

The 31SD Diskette Drive can be damaged if it is not operated or serviced correctly. Do not use IBM cleaning fluid or other chemical cleaning fluids near plastic parts. Never use damaged diskettes in a 31SD Diskette Drive. Diskettes that are damaged physically (creased or bent) or contaminated by pencil marks, finger marks, or cleaning fluids can cause data errors, equipment errors, or head damage. The following Warning notices appear in this manual:

Warning: Do not attempt to remove the collet/flat spring before removing the bail. Too much pressure or binding can damage the spring.

Warning: Damage to the head can occur if the pressure pad is permitted to hit the head.

Warning: Too much pressure or binding of the flat spring will damage the spring.

Warning: The head/carriage assembly is adjusted and tested at the factory. Do not attempt to adjust or repair any part of this assembly.

Warning: The head area can be easily damaged or contaminated. Read the following before exchanging a pressure pad:

- Ensure that your tools are clean; use isopropyl alcohol (part 2200200) and a clean tissue (part 2162567), or use an alcohol pad (part 9900679).
- Do not touch the pressure pad with your fingers.
- Be careful not to damage the new pressure pad or loosen any of the pad's surface. The layer of adhesive on the new pad is very thin; do not damage the adhesive. Do not let the adhesive touch the surface of the pad that will touch the diskette. Do not use damaged pads.
- Do not scratch the head load arm.
- Do not let the head load arm hit the read/write head.
- Move the head load arm as little as possible. The tension spring can come out.

Warning: The head/carriage service check must be performed with the diskette drive installed (or with the diskette drive in the same position as when installed), or the adjustment might not be accurate.

Warning: The head/carriage assembly adjustment must be performed with the diskette drive installed (or in the same position as when installed), or the adjustment might not be accurate.

Warning: The band must not be bent or damaged in any way.

Warning: When you install the head/carriage assembly, ensure that the bail is under the head load arm. Ensure that the bail return spring is correctly installed. Ensure that the band is not damaged in any way.

Warning: The band is easily damaged. Do not bend, crease, or scratch the band. Do NOT use a damaged band.

Chapter 1. Maintenance Approach and System Overview

This chapter contains information to assist the support customer engineer in isolating and correcting 3274 sub-system problems that cannot be attributed to a failing field replaceable unit (FRU). The information supplements existing documentation covering problem isolation, use of serviceability aids, specialized tools, and test equipment. The topics presented include the following:

- **Overall Maintenance Approach:** The maintenance approach is outlined to provide flexibility both in the type of approach taken and in the selection of supporting serviceability aids. The maintenance approach identifies and refers to procedures, tests, specialized tools, and test equipment that will most likely help isolate various types of 3274 problems. Detailed descriptions of these serviceability aids and their use are contained in other chapters in this publication. In addition, examples using these serviceability aids are given for typical 3274 problems.
- **Subsystem Operation Overview:** This overview gives a general description of 3274 operations and functions.
- **Serviceability Aids:** A general description of serviceability aids and their use is given. These aids include the operational indicators, display symbols, error suffix codes, logouts, tests, test equipment, and host error recording.
- **Reference Material:** All supporting reference material in this publication is identified and described. This reference material provides detailed descriptions of error recording and indications, tests, error recovery procedures, 3270/3274 operational differences, error suffix code action chart, and tools and test equipment.
- **Supporting Publications:** Supporting IBM publications are identified and their contents briefly described.
- **Procedure for Requesting Assistance:** A procedure for requesting assistance from the next level of the support structure is outlined. This procedure includes 3274 problem recording which will aid the support structure in problem determination.

1.1 MAINTENANCE APPROACH

This maintenance approach is outlined to provide flexibility both in the type of approach taken and in the selection of supporting service aids. The approach used to isolate a specific 3274 problem may vary because of multiple error

indications and the type of operation being performed at the time the error occurred. Therefore, the maintenance approach to typical problems described in the following is not necessarily the only effective approach that could be used.

The suggested maintenance approach identifies and refers to various procedures, tests, tools, and test equipment that will most likely aid in isolation of the problem. This approach has four basic steps, which are performed in sequence:

Step 1

Review and verify the results obtained by the product customer engineer by using the following reference material:

- *3274 Problem Report Form*
- *3274 Control Unit Maintenance Information*

Step 2

Analyze operational indicators (8 4 2 1), display symbols, and error suffix codes (nnn codes).

Step 3

Analyze logouts, hang conditions, and failing operation sequences.

Step 4

Record all problem symptoms, and complete the Support Structure Information Form in preparation for requesting assistance. The effectiveness of the assistance will depend largely on the information that you provide.

These four steps are illustrated in Figure 1-1.




Figure 1-1. Support Customer Engineer Maintenance Approach

1.2 SUBSYSTEM DATA FLOW

The 3274 subsystem data flow consists of test data, control data (unit code); status, error, and log data; and message data between the components of the subsystem. Figure 1-2 illustrates the 3274 subsystem configuration. The data flow is described as follows:

- Initial Machine Load (IML) of Test Data – Loading the IML test data residing on the system diskette into control storage (paragraph 1.2.1 and Figure 1-3).
- Initial Machine Load (IML) of Unit Code – Loading the unit code residing on the system diskette into control storage (paragraph 1.2.2 and Figure 1-3).

- Message Data Flow between 3274 Control Unit and Attached Devices – The flow of message data between the 3274 Control Unit and attached devices (paragraph 1.2.3 and Figure 1-4).
- Message Data Flow between 3274 Control Unit and Host System – The flow of message data between the 3274 Control Unit and the host system (paragraph 1.2.4 and Figure 1-5).
- Status, Error, and Log Data Flow – The flow of data from the 3274 Control Unit, the host system, and attached devices to the data control block area of control storage (paragraph 1.2.5 and Figure 1-6).




Figure 1-2. 3274 Subsystem Overview

1.2.1 IML Test Data Path

The IML test data path is shown in Figure 1-3. IML test data is retrieved from the 31SD after IML tests 0000, 0001, and 0002 have been successfully completed. IML test 0002 verifies that the 31SD and the 31SD adapter are functionally operational. The data path, from origin to destination, is identified as follows:

- 31SD
- 31SD Adapter
- Bus
- Control logic
- Control storage

1.2.2 IML of Unit Code

The data path of IML (loading of unit code) is the same as the IML test data path. Unit code is normally loaded after the IML tests are successfully completed. Placing the ALT switch in the ALT 1 position and pressing the IML push-button will cause the IML test to be bypassed and initiate loading of the unit code.




Figure 1-3. Initial Machine Load (IML) Data Flow

1.2.3 Message Data Flow between 3274 Control Unit and Attached Devices

Message data flow between the 3274 Control Unit and attached devices is shown in Figure 1-4. The message data paths, from origin to destination, are identified as follows:

3274 Control Unit to Device

- Control storage (message buffer area)
- Control logic
- Bus
- Type A or B adapter
- Category A or B device

Device to 3274 Control Unit

- Category A or B device
- Type A or B adapter
- Bus
- Control logic
- Control storage (message buffer area)




Figure 1-4. Message Data Flow between 3274 Control Unit and Attached Devices

1.2.4 Message Data Flow between 3274 Control Unit and Host System

Message data flow between the 3274 Control Unit and the host system is shown in Figure 1-5. The message data paths, from origin to destination, are identified as follows:

3274 Control Unit to Host

- Control storage (message buffer area)
- Control logic
- Bus
- Remote host adapter/local channel attachment or local host attachment
- Host system

Host to 3274 Control Unit

- Host system
- Remote host adapter/local channel attachment or local host attachment
- Bus
- Control logic
- Control storage (message buffer area)




Figure 1-5. Message Data Flow between 3274 Control Unit and Host System

1.2.5 Logic Data Flow

Status, error, and log data flow is shown in Figure 1-6. The data paths, from origin to destination, are identified as follows:





Figure 1-6. Logic Data Flow


1.3 SUBSYSTEM FUNCTIONS

The following functions are provided by the 3274 subsystem:

Function	Description
0	Machine check/program check activity
1	I/O operations to and from the host CPU
2	31SD Operations
3	I/O operations to and from Category A and Category B devices
4	Device feature functions
5	Messages sent to the host CPU
6	Messages received from the host CPU
7	Initialization (POR and IML)

The 3274 subsystem functions are illustrated in Figure 1-7.

The functions of the 3274 may be grouped into six basic categories: (1) Power On Reset (POR) operations, (2) key-tracking (moving data from the keyboard to the display screen), (3) receiving from the host, (4) sending to the host, (5) error handling and logging, and (6) internal testing.



Note: The functions shown in this diagram are provided by the control logic.

Figure 1-7. 3274 Subsystem Functions

1.3.1 Control Unit Power On Reset

When the 3274 is powered on, the Power On Reset (POR) signal is generated in the TSR power supply. The POR to the A1 board generates a restart to the control logic and, subsequently, starts a normal IML sequence. If two TSR power supplies are installed, the POR from each supply is connected to the other in the logic board. (See Figure B-3 in the *3274 Control Unit Models 51C and 52C Maintenance Information* manual, SY27-2513.)

1.3.2 Keystroke Handling

The requests and status from the attached devices are handled by the Keystroke control function. When an operator presses a key, the keyed data is read by the display base card 1, which, if it receives a poll, sends the data to the terminal adapter (Category A devices only). The terminal adapter then loads the status and scan code of the actuated key into a queue. The terminal adapter control retrieves this information from the buffer queue.

Keystroke control converts the scan code and distributes the data to the appropriate functions. See Figure 1-8 for an illustration of Type A adapter keystroke handling.

As an example of keystroke handling, when a graphic character key is pressed, the graphic key scan code is converted into internal code and then into regen code by means of a language code conversion table. The converted regen code is moved into the device regen buffer, after which the graphic character keyed may be seen displayed on the screen.

When a device is polled, if it has an error condition or request from a feature (selector pen, MSR), it sends status to the terminal adapter, and keytracking control handles the status as it does a status preceding keyed data.

An error condition detected by the device is signaled to the terminal adapter when the device is polled. Error conditions are (1) device check (a parity error was detected in the regen buffer), (2) keyboard overrun (keystrokes too close together), and (3) feature timeout (no response from the feature card within the expected time).

Special keyboard scan codes are used for the device POR signal and keyboard overrun conditions. Selector-pen data is sent to the terminal adapter by read commands. The row count is sent on the first read, and the field count is sent on the second.

To Control Logic

I/O Tags - 8 4 2 1 Indicators




Figure 1-8. Keystroke Handling, Type A Adapter

1.3.3 Sending to Host

Data from Category A devices is queued via function 3 into various buffer formats, depending on the type of host attachment used, by the device control code. The data is then handled, again in queued buffer formats, by the data stream control code. The host processing control code then forwards the appropriate data from another queued buffer to the host. (See Figure 1-9.)




Figure 1-9. Inbound Messages

1.3.4 Receiving from Host

Data from the host is queued via function 1 into common transmit/receive buffers of various formats, depending on the type of host attachment used, by the host processing control code. The data is then handled in queued buffer formats by the data stream control code. The device control code then forwards the data to the device. (See Figure 1-10.)




Figure 1-10. Outbound Messages

1.3.5 Error Handling and Logging

Error handling and logging is performed by the control logic and storage. Log statistics and information are available for each device and host adapter by means of test procedures.

1.3.6 Internal Testing

All internal tests are performed by the control logic, and indicators are provided for test results. Host support is not required for internal testing.

1.3.7 Function Priority

The priority scheme used by the 3274 subsystem is illustrated in Figure 1-11. Function 0 has the highest priority, and function 7 has the lowest priority. For example, if a machine check (function 0) and a 31SD operation (function 2) are both pending, the 3274 control logic performs function 0 followed by function 2.




Figure 1-11. 3274 Subsystem Functional Priorities

1.3.8 Type A Adapter Coax Data Path

Figure 1-12 illustrates the bit path from the coax to the Type A adapter.




Figure 1-12. Coax to Type A Adapter Data Flow

1.4 SUPPORTING PUBLICATIONS

The publications identified in Figure 1-13 should be available for reference.




Figure 1-13. Supporting Publications

Chapter 2. Subsystem Indicators, Symbols, and Messages

2.1 INTRODUCTION

This chapter provides information concerning the operator panel indicators and the 3278 display symbols and messages used to convey error and subsystem status conditions to the user and the customer engineer. The operator panel indicators include the 8 4 2 1 indicators and the Power On/Off indicator.

The subsystem symbols and messages displayed on the 3278 status line include the Readiness and System Connection symbols, Do Not Enter messages, Communication Reminders, Shifts and Modes symbols, Printer Status messages, and Machine, Program, and Communication Check numbers. The functional details of each item are described.

2.2 8 4 2 1 INDICATORS

The four indicators labeled 8 4 2 1 (Figure 2-1) are located on the operator panel. They are activated by the control logic to serve as prompting, progress, and/or success/failure indicators during the following operations:

- *IML Bus Test:* All four indicators are turned on by the IML pushbutton via the control logic and the Type A adapter card No. 12 if there is no activity on the internal logic bus.
- *IML Tests:* As the test routines are run, the control logic turns on and turns off each of the four indicators. A failure condition is indicated by a constant or flashing code displayed in the 8 4 2 1 indicators. The success of a given test is indicated by the 8 4 2 1 indicators progressing on the next hexadecimal value.

- *Operational Mode:* During online operations with the host CPU, the 8 4 2 1 indicators are turned on by the control logic when an error condition is detected by the control logic. Hexadecimal values are used to indicate the most likely failing component. If additional errors are detected the control logic writes over the prior indication with the new hexadecimal value. The indicators turned on by the control logic may represent recoverable errors or nonrecoverable errors. The error remains displayed in the 8 4 2 1 indicators until the machine is powered off or until the IML pushbutton is pressed.
- *Customizing Mode:* During customizing, the 8 4 2 1 indicators display the type of customizing operation in progress, as well as serving as progress and procedural-failure indicators. They also prompt the user to change diskettes during customizing and notify the user when customizing is completed.

2.3 POWER ON/OFF INDICATOR

The Power On/Off indicator is located on the operator panel PC board. It is turned on by +5 Vdc from the logic board. When the machine has two TSR power supplies, approximately half of the card sockets receive voltage from a particular supply. The Power On indicator will not light unless both supplies are active.




Figure 2-1. 8 4 2 1 Indicator Control Logic



2.4 OPERATOR INFORMATION AREA LAYOUT

The operator information area consists of five key fields located below the 3278/3279 status line. These five fields are not displayed on any Category B device (3277). The fields are (1) Readiness and System Connection, (2) Do Not Enter, (3) Reminders, (4) Shifts and Modes, and (5) Printer Status. The field lengths are shown in Figure 2-2.

2.4.1 Readiness and System Connection Symbols

The first six positions of the status line are allocated to Subsystem Ready, Host Ready, Application Ready, and Test. See Figure 2-3.

2.4.2 Do Not Enter (Input Inhibited) Symbols

The symbols shown in Figure 2-4 appear in positions 9 through 17 of the operator information area. Most of these symbols indicate an operator error. However, there are three categories of Do Not Enter symbols that are directly related to hardware or program failures: machine checks (X ) , program checks (X PRDG), and communication checks (X ). Each of these symbols is accompanied by a 3-digit code that further defines the error. The codes are defined in paragraphs 2.4.6, 2.4.7, and 2.4.8.

All the Do Not Enter symbols are shown in Figure 2-4. All the symbols contain an X in position 9 (do not enter), combined with other symbols in positions 11 through 17, which define why input is disabled. The keyboard does not lock, but a change in state of the keyboard clicker (on-to-off or off-to-on) indicates that the keyboard is disabled. The symbols are arranged in descending order of assigned priority. In case of multiple conditions, the higher-priority symbol is displayed.

Readiness and System Connection		Do Not Enter (Input Inhibited)		Reminders		Shifts and Modes		Printer Status	
1	6	9	17	21	27	37	41	60	64

Figure 2-2. Operator Information Area Layout




Symbol	Name	Explanation
	3274 Ready	1 of the operator information area when the 3274  Control Unit to which the display is attached is ready (functional) and the display is ready.
<u>A</u> <u>B</u>	Online A Online B	<p>The Online <u>A</u> and Online <u>B</u> symbols govern transactions with the host system. Certain keyboard functions and the meaning of some operator information area symbols differ depending upon which set of rules is applicable.</p> <p><u>Online A.</u> The control unit is connected to the system under A rules. The <u>A</u> symbol appears in remote systems using BSC protocol. It is turned on by receipt of the following commands: Write, Erase/Write, Erase All Unprotected, Copy, Read Modified, and Read Buffer.</p> <p>The <u>A</u> symbol is turned off when</p> <ol style="list-style-type: none"> 1. An operator action causes host communication. 2. The display station is turned off. 3. The Normal/Test switch is placed in Test, or the TEST key is pressed to place the 3274 in Test mode. <p><u>Online B.</u> The control unit is connected to the system under B rules. The <u>B</u> symbol appears in systems that use SNA protocol. It is turned on by completion of an ACTPU/ACTLU command sequence, and is turned off by execution of DACTPU or DACTLU, including an internal DACTPU sequence, and when the Normal/Test switch is placed in Test or the TEST key is pressed.</p>
	My Job	The display station is connected to the operator's application program. This symbol is displayed in position 3. This symbol appears in systems that use BSC or SNA protocol. In systems using BSC, it is turned on with the A symbol, and is turned off when power is removed, and when the Normal/Test switch is placed in Test. When using SNA protocol, it is turned on when the operator's application session owns the screen.

Figure 2-3 (Part 1 of 2). Readiness and System Connection Symbols (Locations 1 through 6)

Symbol	Name	Explanation
	System Operator	This symbol is used with SNA protocol and indicates that the system operator (SSCP Control Program) session owns the display screen. Except for the ENTER key, the Program Attention keys are not functional when this symbol is displayed.
	Unowned	The display station is connected to the system (using SNA only), but not to the operator's application program or to the system operator (control program). The SYS REQ key is used if LOGON is required. This symbol is displayed in position 3.
TEST	Test	The display station is in Test mode. Test mode is initiated or terminated by pressing the TEST key while holding the ALT key. TEST is displayed in positions 3 through 6. Test procedures are described in the <i>IBM 3270 Information Display System: 3278 Display Station Problem Determination Guide</i> , GA27-2839.

Figure 2-3 (Part 2 of 2). Readiness and System Connection Symbols (Locations 1 through 6)

Symbol	Name	Explanation
	Security Key	The security key is turned off, and no operator input can be accepted. When the key is turned on, this symbol disappears, but any other preexisting "do not enter" condition may then be displayed.
		The display station is not working properly. The symbol is accompanied by up to three digits, nnn (3278), which define the probable cause of the problem. Recovery procedures depend upon the type of error.
	Unavailable	The control unit is not equipped to handle a feature that has been invoked. RESET should be pressed and another action initiated. (See Appendix B.)
	Communication Check	A communication link error was detected and data cannot be sent. The RESET key should be pressed. This symbol is accompanied by up to three digits, nnn (3278), which define the probable cause of the problem. The communication reminder symbol is displayed as long as the condition exists.
	Program Check	A programming error was detected in the data received by the control unit. RESET should be pressed, and the operation should be retried. This symbol is accompanied by up to three digits which define the probable cause of the problem.
	Questionable Card	The wrong magnetic stripe card was used with the MSR. RESET should be pressed, and the correct MSR card should be used.
	Operator Unauthorized	The operator has attempted to perform an unauthorized function. RESET should be pressed to restore the keyboard. The printer status area (location 60 through 64) should be checked for printer assignment. If the Operator Unauthorized symbol was displayed after the print key or IDENT key was pressed, a printer is not assigned. (If the Printer Assignment symbol is displayed in the printer status area, there is an error in the authorization matrix.) If the Operator Unauthorized symbol was displayed after the IDENT key was pressed and two numbers were entered, the operator is not authorized to use the printer.
	Accent Plus What	These symbols indicate that an invalid dead key/character combination was entered (Canadian French keyboard only). RESET should be pressed to restore the keyboard, and a valid dead key/character combination should be entered. Valid combinations are as follows:
	Go Elsewhere	An action has been attempted that is invalid for the display screen location. RESET should be pressed, and either the cursor should be moved or some other action should be taken.

Figure 2-4 (Part 1 of 2). Do Not Enter Symbols (Locations 9 through 17)






Symbol	Name	Explanation
X 	Message Received	A message from the control operator was received and rejected. RESET should be pressed to restore the keyboard. The operator may view the message by pressing SYS REQ or may defer viewing of the message until a later time.
X SYSTEM	System Lock	The system has disabled the keyboard following an entry. The operator should look for a message and then press RESET to restore the keyboard.
X ?+	What (Try Again)	The last input was not accepted. The screen should be rechecked, and the operation should be retried as follows: <ol style="list-style-type: none"> 1. Do not key while the X is displayed. 2. If ALT, or a shift key, was used, press the key again; then press RESET and retry the operation. 3. If ALT, or a shift key, was not used, press RESET and retry the operation.
X 	Printer Not Working	The printer assigned to the display station is not functioning. If this symbol appears after the Print key has been pressed, the print request is canceled, and the DEV CNCL key should be pressed to restore the keyboard. If the Printer Failure symbol is displayed in the printer status areas, the printer stopped during the last print operation. DEV CNCL should be pressed to restore the keyboard and to instruct the control unit to stop monitoring the operations of the printer that stopped.
X 	Printer Busy	The printer assigned to the display station is busy. If the Printer Printing symbol is displayed in the printer status area, the printer is printing. The operator may wait for the printer operation to complete, or he may press the DEV CNCL key. If the print key was used, it may be possible to select another printer.
X 	Printer Very Busy	This symbol means the same as Device Busy, except that more time than usual is anticipated before the print request is accepted.
X 	Time	Time is required for the system to perform a function.
X -S	Minus Symbol	The symbol you keyed is not available. The RESET key should be pressed to restore the keyboard.
X -f	Minus Function	A currently unavailable function was requested. RESET should be pressed to restore the keyboard.
X -f X	Minus Function Operator Unauthorized.	
X >	More Than	An attempt was made to enter more information into a field than can be entered. RESET should be pressed to restore the keyboard, and the operation should be retried and the entry corrected.
X #?	What Number	A numeral was entered that is unacceptable at the display screen location. RESET should be pressed to restore the keyboard, and the correct entry should be made.
X NUM	Numeric	A nonnumeric entry was made at a display screen location reserved for numeric information. RESET should be pressed to restore the keyboard, and the operation should be retried.

Figure 2-4 (Part 2 of 2). Do Not Enter Symbols (Locations 9 through 17)

2.4.3 Communication Reminder Symbol

The communication reminder (Figure 2-5) is turned on and broadcast to all active Category A displays when the 3274 detects a failure in the local or remote communication path to the host system. The reminder will remain on until the failure condition has been cleared and the 3274 detects the cleared condition. When the reminder is broadcast to all displays, all retry activity has stopped. When a bisynchronous line error has been detected, the original contents of the screen are restored. The reminder then remains on the screen of the display affected until cleared by host-system recovery activity.

2.4.4 Shifts and Modes Symbols

There are three Shifts and Modes symbols (Figure 2-6). The Upshift key may be used to determine if the Type A adapter is still polling a display internally when the remainder of the keyboard may be locked up. (The adapter is disabled if the arrow (↑) will not display.)

Symbol	Name	Explanation
	Communication Reminder	The communication link connecting the control unit to the system is not functioning. This symbol is displayed with the Communication Check symbol.
	Reserved	This symbol is reserved for future use and should be ignored if it is displayed.

Figure 2-5. Reminders (Locations 21 through 27)


Symbol	Name	Explanation
APL	APL Mode	
TEXT	Text Mode	
NUM	Numeric	The keyboard is in numeric shifts, which allows use of the 0 through 9 keys and the (.), (—), and DUP keys only.
↑	Upshift	The keyboard is in Upshift.
^	Insert	The keyboard is in Insert mode. A character may be inserted at the cursor location. Characters beyond the cursor position move to make room for the inserted characters.
PSA through PSF	Symbol set A through Symbol set F	The EBCDIC code for characters entered at the keyboard will be used to address the indicated symbol set for a displayable character.
S0	Base Character	The base character set is addressed for a displayable character when the operator presses a character key.
	Extended Color	The color of the symbol is the color that will be used to display the next character at the keyboard.
	Default Color	Green or white
	Underlined	Character highlighting by underscore.
	Blinking	Character highlighting by blinking on and off at regular intervals.
	Reversed	Character highlighting by reversing the light intensity between the character and its background.
+	Operator Select	The current extended color attribute was selected by the operator.
⇒	Field Inherit	The current extended color is determined by the extended field attribute (either (1) operator selection is allowed, but no selection has been made, or (2) the operator has selected field inherit).
▶	Keyboard Extension	The keyboard is in an extended mode.

Figure 2-6. Shifts and Modes (Locations 37 through 41)

2.4.5 Printer Status Messages

Printer status (Figure 2-7) messages are displayed in the operator information area layout whenever a printer has been assigned to a display requiring the use of a printer. Refer to the *3270 Information Display System: 3274 Description and Programming Guide, GA23-0061*, for detailed information regarding printer assignments, classes, and matrix structures.


2.4.6 Machine Check Numbers

Machine check numbers follow immediately after the machine check symbol (). They are divided into the following categories: Category A device and adapter errors, Category B device and adapter errors, host attachment and adapter errors, and control logic errors. The 200 series nnn machine check numbers are used for the devices and their respective adapter failures, and the 300 series nnn machine check numbers are used for host and control logic failures. For a summary of all machine check numbers, see Appendix B.

2.4.7 Program Check Numbers

Program check numbers follow immediately after the program check symbol (P R O G). Program checks are divided into three categories: SNA protocol errors, print matrix definition errors, and data stream errors. Some program check numbers are not displayed at the device, but are logged in the event log for that device. See Appendix B for a summary of the program check numbers.

2.4.8 Communication Check Numbers

Communication check numbers follow immediately after the communication check symbol (). A communication check number may represent an interruption of the communication path to a remote attached 3274. The communication check number may also represent a normal communication path condition and not a hardware failure (for example, 532 = BSC line idle). The communication check numbers are directly related to the type of host adapter being used. The meaning of the nnn number may change from adapter to adapter. See Appendix B for a summary of the communication check numbers.






Symbol	Name	Explanation
	Assign Printer	When changing the printer IDENT, the two numbers entered (X X) appear in the printer authorization matrix.
	Printer Assignment	The display station is authorized to use printer number nn. Individual printers may be assigned 01 through 31. Printer "class" is designated by 70 through 80.
	Printer Printing	The printer identified by nn is printing.
	Printer Failure	The printer identified by nn has stopped while printing.
	What Printer	The printer IDENT has changed. Pressing the IDENT key causes display of a new printer assignment.
(Nothing Displayed)		If the display is attached to a 3274 (4 displayed in location 1), printing cannot take place.

Figure 2-7. Printer Status (Locations 60 through 64)

Chapter 3. Subsystem Error Logs and Test Formats

3.1 INTRODUCTION

There are six basic formats for entry into the subsystem log and test facility. This concurrent test facility provides path tests between the control unit and attached devices, device error statistics, device adapter error statistics, host adapter error logs and statistics, control logic error statistics, configuration and EC data, display of the status of all configured devices, reset capability of statistical error counters, and device control block displays for all configured devices. The use of the ALT and TEST keys is necessary to enter Test mode. The concurrent test facility is available only after Test mode is entered. Following are the concurrent test and log facilities:

- Test 0 – Checks the communication path between the 3274 and its attached devices. Also provides functional testing of Category A devices (displays 3278 and 3279) and 4-color override switch function on a 3279.
 - /0 – Transmits a test pattern from the control unit to the display from which you requested Test 0.
 - 00 to 31/0 – Transmits a test pattern from the control unit to another 3278 as specified by you when you entered the Test 0 format message.
- Test 1 – Displays error statistics for displays, printers, adapters, and control logic.
 - 00 to 31/1 – Displays log of any device from 00 to 31.
 - A0/1 – Displays the host adapter/attachment log formats: CCA BSC, CCA SDLC, HPCA, LCA attachment, and LHA attachment. Only the format for the host adapter installed in your machine is displayed in response to this request.
 - A1/1 – Displays log of the Type A adapters.
 - A2/1 – Displays log of the Type B adapters, encrypt/decrypt adapter, and Model 52C volume 3 storage errors.
 - A3/1 – Displays log of the configured terminal and summary counters.
- Test 2 – Displays configuration information.
 - /2 – For first (hex) 40 bytes.
 - – Enter only – second 40 bytes.
- Test 3 – Displays the status (off, on, disabled) of all configured devices and summary errors.
 - /3 – Status of ports and summary error counters.
- Test 4 – Reset logs.
 - XX/4 – Resets specified log counter (except summary).
- Test 6 – Displays key information in device control blocks.
 - 00 to 31/6 – For first (hex) 40 bytes. You may page from one page to the next by pressing the ENTER key. Paging beyond display 1C will result in a locked keyboard and X-f displayed on the status line.
- Test 7 – Color Convergence.
- Test 8 – Programmed Symbols, Highlighting, and Color Test.
- Test 9 – Kanji/Chinese Character Display.

3.2 TEST 0: COMMUNICATION PATH TEST AND 3278 DISPLAY TEST

3.2.1 Description

Test 0 performs the following functions:

- Transmits a test pattern from the control unit to the display from which you requested Test 0.
 - Transmits a test pattern from the control unit to another 3278 as specified by you when you entered the Test 0 format message.
 - Functionally tests the following using the test pattern transmitted by the control unit to the 3278 display specified by you: (1) high-intensity function, (2) non-display function, (3) various key functions, (4) selector-open function, (5) MSR function, and (6) audible-alarm function.
 - Executes communication path test to Category B display (3277).
 - Executes communication path test to Category A or B printers.
- A request for Test 0 will be executed to any Category A display (3278) except under the following conditions:
- If the device requested is in an SNA session, the test pattern function is not performed. Do Not Enter minus function indication is returned.
 - If the device has the Wait indicator on and is attached to a Model 1B or is busy executing a command that requires asynchronous ending status (Op Complete), Do Not Enter minus function indication is returned.

This test, if requested for a Category B display (3277) or Type A or B printer, only checks the continuity of the coax communication path. Success or failure of this test is displayed on the requesting 3278 display as follows:

- The test message you entered followed by a: +, -, or 0.
+ = Test successful or path OK.
- = Test failed, device disabled because of error
0 = Test not run, device powered off

If no device is specified when the test is requested, an automatic default to the requesting device occurs.

3.2.2 Procedure for Requesting Test 0

- Press and hold ALT, and then press TEST to enter Test mode.
- Ensure the cursor is at location zero (0). Enter the following: (1) the device number you wish to test, using any two-digit number from 00 to 16 for Model 51C or 00 to 08 for Model 52C, (2) a slash, and (3) a zero. Press the ENTER key.
- If you are testing a 3278 display, the following pattern will appear on the screen if the test is successful:

```
TEST: 3274;NN
?SEL PEN      SEL PEN
  &SEL PEN    > SEL PEN
    DISPLAY  INSERT CK
```

NN = The port number of the terminal that requested the test

- Use the *IBM 3278 Display Station Maintenance Information* manual, SY27-2510, to run the 3278 functional tests with the above test pattern.
- To exit Test mode, press and hold ALT and then press TEST.
- An entry of slash (/) only automatically defaults to Test 0 on the requesting display.

3.3 TEST 1: OVERVIEW

Test 1 is a variety of device and adapter error log and statistical counter information that can be displayed on any working 3278 while that 3278 is in Test mode. By using a two-digit prefix to the entry slash (/)1, specific device log or adapter log information can be retrieved. The formats for entering a Test 1 request are as follows:

- 00 to 16/1 (Model 51C) or 00 to 08/1 (Model 52C) — Displays log of any attached device from 00 to 16 for Model 51C or 00 to 08 for Model 52C.
- A0/1 — Displays three host adapter/attachment log formats: CCA BSC, CCA SDLC, and HPCA.

Only the format for the host adapter installed in your machine is displayed in response to this request.

- A1/1 — Displays log of the Type A adapters.
- A2/1 — Displays log of the Type B adapters. For Model 52C, this test is used to isolate the Op code error of 0111.
- A3/1 — Displays control logic error log.

The error information contained in the above logs resides in the 3274 storage. The general format of all logs reflects: (1) the most recent error *event* information and (2) statistical counters that reflect the type of errors occurring. The event log may be a combination of significant information that will differ in content from adapter to adapter as well as format. The statistical counters record errors using hexadecimal values. The maximum value for any counter is hex 'ff'.

The terms used in the log descriptions are defined as follows:

Machine Check — The CCA hardware has detected an error and the failing operation is retried. If the retry is successful, the error is transparent. If the retry fails, the CCA is disabled and the machine check is logged. See nnn code 310 in Appendix B.

Invalid Status — The control logic has detected an unexpected or invalid combination of bit settings in the CCA Status Register. See nnn code 311 in Appendix B.

DCE — The control logic has detected the loss of Data Set Ready (DSR) from the modem. See nnn code 501 in Appendix B.

Timeout

Read Operation — This bit indicates that 3 seconds has elapsed without receipt of an Syn, ETX, or ETB.

Write Operation — See nnn code 530 in Appendix B.

Overrun

CCA — The 3274 was not ready to receive a byte of data from the device.

HPCA — Either the cycle-share buffers were full or the 3274 did not allow the adapter to cycle-share.

Underrun — The 3274 was not ready to transmit a byte of data at the time the transmission line was ready to receive it.

Enq Received — An inquiry character has been received by the 3274.

NAK Sent — A Negative Acknowledgment has been sent.

NAK Received — A Negative Acknowledgment has been received.

15 NAKs Received — 15 Negative Acknowledgments have been received.

15 NAKs Sent – 15 Negative Acknowledgments have been sent.

N Timeouts Invalid – N = number of invalid timeouts that have occurred.

15 Timeouts Invalid – 15 invalid timeouts have occurred.

Count Exceeded – The byte count has been exceeded.

RI – Ring Indicator (not used)

RVI RCVD – A reverse interrupt was received instead of ACK 0/ACK 1.

ITB ATTN – An ITB character was received.

EOH ATTN – An STX character was received signifying the End of Header.

XPRNCY – The receive operation has entered the transparent mode.

Poll/Select – This bit, when 1, indicates that this station has been polled. When this bit is 0, this station has to be selected.

3.3.1 Test 1 Device Logs

Perform the following steps before consulting the log:

1. If any 8 4 2 1 indicators are set, refer to the *MIM* for the failing FRU.
2. If a 3nn or 5nn code is displayed, refer to Appendix B for problem determination information. These codes can be found in the device logs.

If the above steps do not provide sufficient information for problem determination, then the log may be of assistance. The log statistical counters indicate the state of the interface (how many errors of a certain classification), and the event data provides error status on the interface for certain error events. For example, in BSC operation when an NAK is received (associated with a severe error condition), it is logged with associated event data and counted. This event data should be the last error information examined. The control logic normally examines the appropriate error data and sets the nnn code to the appropriate value.

The device logs should be accessed whenever a specific device is suspected of experiencing intermittent or difficult-to-define errors. These errors may or may not be generating nnn numbers on the failing device. (Not all nnn numbers are displayed.) Since four types of device logs are available when using Test 1, it is necessary to determine what type of device (3278, 3277, Category A printer, Category B printer) is attached to the device port number (00-16 for Model 51C or 00-08 for Model 52C) for which you are requesting log information. The format for all device logs requested using Test 1 is as follows:

- Line 1 –

01/1

This line is returned exactly as you entered your request. Example: You entered 01/1, and the first line of the display sent back to you should be 01/1.

- Line 2 –

0000 0000

This line displays the most current low-order digits of 200, 300, 400, and 500 series nnn numbers. If there are no errors generating nnn numbers, the second line of this display will appear as follows:

0000 0000

If error information had been recorded, the second line of this display could appear as follows:

0400 0032

04 = The most current 200 series error, in this example, 204, which is a device check*.

00 = No 300 series errors are recorded.

00 = No 400 series errors are recorded.

32 = The most current 500 series error, in this example, 532, which is BSC line idle.

The 200 numbers appear in the leftmost position and progress to the 500 numbers in the rightmost position.

*A 2%% nnn code will appear as EEN in the error log.

- Line 3 –

0000 0000 0000 0000

This line displays the statistical counter information associated with this device. If no errors are recorded for this device, the counters will display as follows:

0000 0000 0000 0000

The counters are not numbered when they are displayed.

They are, however, assigned counter position numbers.

The leftmost two-digit position is counter number 01, and the rightmost counter position used is counter number 06. The value in each counter is given in hexadecimal.

If errors were being recorded for this device, the display for line 3 would appear as follows:

02FF 1A00 0013 0000

Counter number 01 = 02 hex = 02 errors total

Counter number 02 = FF hex = 255 errors (maximum)

Counter number 03 = 1A hex = 26 power off total

Counter number 04 = 00 hex = no errors

Counter number 05 = 00 hex = no errors

Counter number 06 = 13 hex = 19 errors total

Counter number 07 = Reserved

Counter number 08 = Reserved

All counters for line 3 function in this manner. The counter numbers are assigned specific meanings according to the type of device log being requested. (See Figure 3-1.)

3278/3279 Log

Counter	Meaning
01	Coax timeouts
02	Coax parity errors
03	Power Off
04	Device checks
05	Error status base machine
06	Error status features

Type A Printer Log

Counter	Meaning
01	Coax timeouts
02	Coax parity errors
03	Power Off
04	Device checks
05	Error status
06	Equipment checks

Counter Meaning

04	Device checks — The device has detected an error and has returned device check statuses to the 3274. See nnn code 204.
05	Error status base machine — Error status has been returned that indicates a device failure.
06	Error status features — An invalid response or error response has been received from a feature device.

3277 Log

Counter	Meaning
01	Coax timeouts
02	Coax parity errors
03	Power Off
04	Device checks
05	Not applicable
06	Not applicable

Type B Printer Log

Counter	Meaning
01	Coax timeouts
02	Coax parity errors
03	Power Off
04	Device checks
05	Sync or equipment checks
06	Disabled or equipment checks

Type A Printer Detail

Counter	Meaning
01	Coax timeouts — See 3278/3279 log detail.
02	Coax parity error — See 3278/3279 log detail.
03	Normal power off — See 3278/3279 log detail.
04	Device checks — See 3278/3279 log detail.
05	Error status — An error condition has been detected by the 3274, or error status has been received indicating a device failure.
06	Equipment check — The printer has reported an unrecoverable error to the 3274.

3278/3279 Log Detail

Counter	Meaning
01	Coax timeouts—This counter is incremented when the 3274 sends data or commands to the device and does not receive a response in a predetermined period of time. <i>Note: Use the nnn code logged for the device for further analysis.</i>
02	Coax parity error — This counter is incremented when the 3274 detects a parity error in a 12-bit received from the device.
03	Normal power off — This counter indicates the number of times the device failed to respond to a poll retry sequence (device powered off). Counter 1 or 2 is incremented on the first failure to receive a poll sequence response; 32 successive poll sequence retries by the DCA then follow. If all retries are unsuccessful, the control logic assumes that the device is powered off and then increments counter 3.

Type B Printer Log

Counter	Meaning
01	Coax timeouts — See 3278/3279 log detail.
02	Coax parity error — See 3278/3279 log detail.
03	Normal power off — See 3278/3279 log detail.
04	Device checks — See 3278/3279 log detail.
05	Sync or equipment check — The printer has returned sense information that indicates an equipment check while printing. See nnn code 276 in Appendix B.
06	Disabled and equipment check — The printer has posted an equipment check and is in a not-ready condition. See nnn code 275 in Appendix B.

Figure 3-1. Summary of Counter Definitions by Log Type

Following is a device log as it would appear for an intermittently failing 3278 display on control unit port A07.

```
07/1
1200 0000
0000 001C 0000
```

If the log for this device is broken down, there is a record in the nnn number field showing that a 212 (invalid scan code received) error is the most recent 200 series error and that no other nnn errors are recorded. Counter number 04 has a value of 1C recorded, indicating that 28 device checks were pointing to this display as the source of failure. Repair activity can now be attempted at the display level. Control-unit failure is not suspected.

3.3.2 Test 1 Host Adapter Logs

The host adapter logs should be accessed whenever a problem is suspected to be intermittently causing host communication failures, host adapter failures, or other spurious or difficult-to-define failures. When a host adapter log is requested, the format will always be A0/1. The display sent from the control unit in response to this request will depend on the type of host adapter installed in your 3274. The display for each host adapter is slightly different. The display returned in response to an A0/1 request is covered in detail in subsequent sections; in general, however, all displays appear as follows:

- Line 1 – A0/1
- Line 2 – Event data is displayed
- Line 3 – This line displays the statistical counters associated with each host adapter

The host adapter logs can provide detailed information pertaining to the following questions: (1) What was the nnn number at the time of the last failure? (2) What was the operation being attempted at the time of the last failure? (3) How was that operation completed? (4) Why was that operation completed that way? (5) What is the frequency of this type of failure? If these questions are answered with the use of the information stored in the host adapter logs, remedial or repair activity can be attempted.

3.3.3 Test 1 Common Communications Adapter (CCA) Log for BSC

This host attachment log format is returned to the requesting 3278 in response to an A0/1 entry. The format detail is as follows:

- Line 1 – Returned the same as input, A0/1.

- Line 2 – Twenty-four bytes are displayed on this line, but only ten are used. The individual bytes are not labeled when displayed. Each byte is assigned a specific meaning. See the following example for byte identification:

Byte 1																				Byte 24	
0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
NNFF	CCCC	SSSS	SSSS	SSXX	SSXX	SSXX	SSXX	SSXX	SSXX	SSXX	SSXX	SSXX	SSXX	SSXX	SSXX	SSXX	SSXX	SSXX	SSXX	SSXX	SSXX

The leftmost byte is labeled NN. This code represents the two low-order digits of any 500 series nnn number in almost all cases. However, if NN equals zero (00) and the bytes labeled FF and CCCC are *not* zeros, then the entire log information does not pertain to a 500 series communication check and is to be considered machine-check data.

The next byte to the right of NN is FF. This byte represents the type of operation being attempted at the time of the failure. Refer to the CCA BSC Operation Attempted Chart (Figure 3-2) when FF is to be used.

The next two bytes to the right of FF are labeled CCCC. These two bytes indicate how the attempted operation ended. See the CCA BSC Operation Ending Chart (Figure 3-3) to determine if the operation was completed (1) normally, (2) with exception, or (3) with error.

The next five bytes to the right of CCCC are labeled SSSS. These five bytes contain sense information recorded at the time of the failure. After you have examined NN, FF, and CCCC, the SSSS bytes should give you some indication as to why the nnn code was generated and why the operation attempted was not completed normally.

All bytes labeled XXXX are not used.

- Line 3 – This line displays the statistical counter information associated with this adapter. If no errors are recorded for this adapter, the counters display as follows:

```
0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
```

The counters are not numbered when they are displayed. They are, however, assigned counter position numbers. The leftmost two-digit position is counter number 01, and the rightmost counter position *used* is counter number 11. The remaining positions are not used. The value in each counter is given in hexadecimal. The maximum value for any counter is FF.

Each counter is assigned a specific meaning, as follows:

Counter	Meaning
01	NAK sent
02	NAK received
03	Enq received
04	Timeout invalid
05	15 NAKs received
06	15 Wrong ACKs (ACK 0 instead of ACK 1, etc.)
07	Underruns/overruns
08	Write timeout
09	DCE error
10	Number of Available Buffers Exceeded

A complete log display for this adapter would appear as follows:

```

AO/1
0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
  
```


FF		FF	
Code	Operation Attempted	Code	Operation Attempted
00	Enable/Set Mode	14	Disable
01	Hardware Sense	16	STX/ETX Nonconversational
02	SOH/ETX Conversational Resp	18	Write WACK
03	Read Normal	1A	STX/ETB Conv Response
06	SOH/ETX Nonconversational	1E	STX/ETB Nonconversational
07	Read-Respond RVI	40	Monitor Line
0A	SOH/ETB Conv Response	46	SOH/ETX Expect Conv Resp
0E	SOH/ETB Nonconversational	56	STX/ETX Expect Conv Resp
10	Write EOT	58	Monitor Line-Respond WACK
12	STX/ETX Conv Response		

Figure 3-2. CCA BSC Operation Attempted Chart (Code FF)


Bits shown as 0 are not used unless specified otherwise.

Operation Attempted

00 Enable/Set Mode



01 Hardware Sense



02 SOH/ETX Conversational Response

03 Read Normal

06 SOH/ETX Nonconversational

07 Read and Respond RVI





Figure 3-3 (Part 1 of 4). CCA BSC Operation Ending Chart (Code CCCC)


Operation Attempted



0A SOH/ETB Conversational Response

0E SOH/ETB Nonconversational


10 Write EOT



(Exception completion not valid for Write EOT)

12 STX/ETX Conversational Response

14 Disable



(Exception completion not valid for Disable)

16 STX/ETX Nonconversational

18 Write WACK





Figure 3-3 (Part 2 of 4). CCA BSC Operation Ending Chart (Code CCCC)


Operation Attempted



1A STX/ETB Conversational Response

1E STX/ETB Nonconversational

40 Monitor Line



46 SOH/ETX Expect Conversational Response

56 STX/ETX Expect Conversational Response

FF codes 02 through 56 listed above use the following completion/detail.





Figure 3-3 (Part 3 of 4). CCA BSC Operation Ending Chart (Code CCCC)

Operation Attempted



58 Monitor Line Respond WACK

FF Codes 44 through 58 use the following completion detail.




Figure 3-3 (Part 4 of 4). CCA BSC Operation Ending Chart (Code CCCC)

Figure 3-4 explains the sense-byte breakdown for CCA BSC. These conditions are logged only for nnn codes 311, 501, 530, 535, and 536, and the last error condition of that type.

Line 2 – NNFF CCCC SSSS SSSS SSSS
 0102 0304 0506
 SS bytes are labeled from left to right SS01, SS02, SS03, etc.

Location	Bit	Meaning If Bit Is Turned On (1)
Byte SS01		Ignore
Byte SS02	0	Input Request
	1	Output Request
	2	DCE Interrupt
	3	Timer Interrupt
	4	Exception
	5	Machine Check/Prog Check
	6	Enable/Disable
Byte SS03	7	Interrupt Request
	0	Data Set Ready
	1	Clear to Send
	2	Recv Line Signal Det
	3	Ring Ind
	4	DSR Transition
	5	Reserved
Byte SS04	6	RLSD Transition
	7	CTS Transition
	0	DTR/CDSTL
	1	Request to Send
	2	Wrap
	3	Test
	4	Select Standby
Byte SS05	5	Select Half Speed
	6	New Sync
	7	DCE Interrupt Disable
	0	Overrun
	1	Underrun
	2	Receive Clk Running**
	3	SDLC Invalid Seq
Byte SS06	4	SDLC Frame
	5	Invalid Character**
	6	Break Byte Detected**
	7	Adapter in Sync
	0	Receive Mode
	1	Transmit Mode
	2	Inhibit Zero Insertion
	3	Mode Select*
	4	Mode Select*
	5	+Code Length
	6	+ Code Length
	7	NRZI

* 00 = Auto + 00 = 8 bit
 01 = EBCDIC 01 = 6 bit
 10 = ASCII 10 = 7 bit
 11 = SDLC 11 = 5 bit

**Should always be zero

Figure 3-4. Sense Byte Breakdown Chart for CCA BSC (Code SSSS)

3.3.4 Test 1 Common Communications Adapter (CCA) Log and High-Performance Communications Adapter (HPCA) Log for SDLC

This host adapter log format is identical for both adapters and is returned to the requesting 3278 in response to an A0/1 entry. The format detail is as follows:

- Line 1 – Returned the same as input, A0/1.
- Line 2 – Twenty-four bytes are displayed on this line, but only 11 are used. Information is stored and displayed only in Line 2 on specific error conditions. These conditions are associated with nnn codes 501, 502, 529, 530, or 321 (see Appendix B for details). Code 321 will be indicated in this line as NN=00 and the remainder of Line 2 will be not equal to 0. Each byte is assigned a specific meaning. See the following example for byte identification:

```

Byte 1                                     Byte 24
0000 0000 0000 0000 0000 0000 0000 0000 } } 0000
NNFF CCCC SSSS SSSS SSSS SSXX XXXX } } XXXX
  
```

NN – This code represents the two low-order digits of any 500 series nnn number in almost all cases.

FF – This byte represents the type of operation being attempted at the time of the failure. Refer to the CCA/HPCA Operation Attempted Chart (Figure 3-5) when FF is to be used.

FF Code	Operation Attempted
00	Open
01	Sense
02	Write/Read
04	Close
05	Adapter Prewrap (Test)
09	Adapter Wrap (Test)
10	Beacon
0D	Model Wrap (Test)
20	Logical Open
40	Fast Close
82	Halt Write

Figure 3-5. CCA/HPCA SDLC Operation Attempted Chart (Code FF)

CCCC – These two bytes indicate how the attempted operation ended. See the CCA/HPCA Operation Ending Chart (Figure 3-6) to determine if the operation was completed (1) normally, (2) with error, or (3) with exception.

SSSS – These seven bytes contain sense information recorded at the time of the failure. After examining NN, FF, and CCCC, the SSSS bytes should give you some indication as to why the nnn code was generated and why the operation attempted was not completed normally.

XXXX — All bytes labeled XXXX are not used in the CCA and should be ignored for the HPCA, since these bytes contain secondary levels of information, which are not associated with the problem.

- Line 3 — This line displays the statistical counter information associated with these adapters. If no errors are recorded for these adapters, the counters will display as follows:

0000 0000 0000 0000 0000 0000 0000 0000 0000 0000

The counters are not numbered when they are displayed. They are, however, assigned counter position numbers. The leftmost two-digit position is counter number 01, and the rightmost counter position *used* is counter number 12. The remaining positions are not used. The value in each counter is given in hexadecimal. The maximum value for any counter is FF.

Each counter is assigned a specific meaning, as follows:

Counter	Meaning	nnn Code (App B)
01	Nonproductive Timeout	520
02	Idle Timeout	521
03	Write Retry	
04	Overrun	
05	Underrun	
06	Connection Problem	525
07	FCS Error	
08	Primary Abort	
09	Command Reject	528
10	DCE Error	529
11	Write Timeout	530
12	Count Exceeded	519
13	Secondary Busy	
14	RLSD Error	507

The error to nnn code and counter relationship is shown below:

Error	nnn Code (See App B)	Counter
DCE Error	529	10
Machine Check		
CCA	320	—
HPCA	330	—
Invalid Status		
CCA	321	—
HPCA	331	—
Write Timeout	530	11
Nonproductive Timeout		01
Idle Timeout	521	02
Overrun	—	04

Error	nnn Code (See App B)	Counter
Underrun	—	04
Connect Problem	525	06
Secondary Busy	—	13
Write Retry	—	03
FCS Error	—	07
Primary Abort	—	08
Command Reject	528	09
Lost Data	519	11
No RLSD	507	14
Format Error	555	2
X.21 Timeout	556	3
Not Ready	557	5
Lost Data	558	6
DCE Cleared	559	7
Not +/-Bel	560	11
Clear Timeout	561	18
CMR Error	562	1
Invalid Sequence	565	4

The following descriptions of conditions will help you analyze the logs:

Read Message Available — Indicates that an I-frame has been received and is destined to a physical or logical unit.

Link Test — Used in conjunction with the Read Message Available bit. When both bits are on (1), it indicates that the I-frame received is a test message.

Poll Request — This bit indicates that a valid poll has been received from the host.

SNRM Received — A Set Normal Response Mode sequence has been received from the host. An existing session will be terminated, and a new session may be established.

Underrun — The 3274 controller was not ready to transmit a byte of data at the time the transmission line was ready to receive.

Connection Problem — 20 consecutive occurrences of any of the following: ROL, FRMR, XID, NSA.

FCS Error — The 3274 controller detected an SDLC frame with an invalid block check character (BCC) or a frame-check sequence.

Primary Abort — The 3274 detected an abort message from the primary station.

Lost Data — An I-frame received by the 3274 was larger than the allocated buffer.

Write Timeout – A transmission of data took longer than expected and is suspected to be a result of a hardware function.

Dump Message – Addition status is contained in the register space that will indicate one of the following:

- FCS Error
- Primary Abort
- N (r) Sequence Error
- Wrong Length Message (same as lost data)
- Data with a command
- Invalid SDLC command

Secondary Busy – An RNR response has been sent to the primary station because the 3274 does not have sufficient buffers (receive).

Nonproductive Timeout – No valid SDLC frames have been received by the 3274 that contains either a valid FCS or a valid address for a period of 20 seconds.

XID Received – A valid XID was received from the primary station. The 3274 will go to normal disconnected mode (NDM) of operation.

Disconnect Received – A valid SDLC frame containing a Disconnect command was received from the primary station. The 3274 will go to normal disconnect (NDM) mode of operation.

Write Retry – A previously transmitted I-frame was not received by the host. The 3274 will transmit the same I-frame again.

Bits shown in the chart as 0 are not used unless specified otherwise.

Idle Line Timeout – No valid flag characters have been detected on the host link for 20 seconds.

Ring Indicate Timeout – A switched connection has not been detected in a 3-second period.

Ring Indicate – A switched connection has been made.

Invalid Basic Status – An adapter hardware register contains data that was not meaningful.

DCE Error – A modem problem has been detected.

CNFG – A valid Configure command was received and the appropriate action is being taken by the adapter microcode.

No RLSD – RLSD has been inoperative for at least 4 seconds.


Overrun

- CCA – The 3274 was not ready to receive a byte of data from the device.
- HPCA – Either the cycle share buffers were full or the 3274 did not allow the adapter to cycle share.

A complete log display for this adapter would appear as shown below:

```
A0/1
0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
```

Operation Attempted



Read/Write






Figure 3-6 (Part 1 of 2). CCA/HPCA SDLC Operation Ending Chart (Code CCCC)

Operation Attempted



04 Close




(Exception completion condition not allowed)

05 Adapter Prewrap

09 Adapter Wrap

10 Beacon (Loop Attachment)



0D Modem Wrap

FF Codes 05 through 0D are not logged.

Note: Bits 0-3 of left cc byte are ignored except during Loop attachment. Bit 0 of left cc on indicates a valid SDLC Frame has been received.

Figure 3-6 (Part 2 of 2). CCA/HPCA SDLC Operation Ending Chart (Code CCCC)

Figure 3-7 explains the sense-byte breakdown for CCA/HPCA SDLC.

Line 2 – NNFF CCCC SSSS SSSS SSSS SS
 0102 0304 0506 07
 SS bytes are labeled from left to right SS01, SS02, SS03, etc.

Location	Bit	Meaning If Bit Is Turned On (1)		Location	Bit	Meaning If Bit Is Turned On (1)	
		CCA	HPCA			CCA	HPCA
SS01	0	See Figure 3-4	Cycle Share Halt	SS07	0	Not used	Timer
	1	See Figure 3-4	Transmit EOL		1	Not used	Timer
	2	See Figure 3-4	Receive Control Entry		2	Not used	DSR
	3	See Figure 3-4	Modem/Timer		3	Not used	CTS
	4	See Figure 3-4	Exception		4	Not used	DSR Transition
	5	See Figure 3-4	Machine Check		5	Not used	Ring Transition
	6	See Figure 3-4	Enabled		6	Not used	RLSD Transition
SS02	0	See Figure 3-4	Receive Mode	SS08	0	Not used	Wrap
	1	See Figure 3-4	Ping Valid		1	Not used	T3/T4 Test
	2	See Figure 3-4	Pong Valid		2	Not used	New Sync
	3	See Figure 3-4	Not used		3	Not used	Tx New Sync
	4	See Figure 3-4	Specific Address Valid		4	Not used	Diagnostic Clock
	5	See Figure 3-4	Group Address Valid		5	Not used	Diagnostic Timer Control
	6	See Figure 3-4	Interrupt on Cont Flags		6	Not used	RLSD
SS03	0	See Figure 3-4	Invalid Seq/Address	SS09	0	Not used	Not used
	1	See Figure 3-4	Byte Overrun		1	Not used	Not used
	2	See Figure 3-4	Receive Control Entry		2	Not used	Ptr Reg 0
	3	See Figure 3-4	15 Ones		3	Not used	Ptr Reg 1
	4	See Figure 3-4	Control Overrun		4	Not used	Ptr Reg 2
	5	See Figure 3-4	Traffic		5	Not used	Ptr Reg 3
	6	See Figure 3-4	Receive Cycle Share Halt		6	Not used	Not used
SS04	0	See Figure 3-4	Invalid Seq/Address	SS10	0	Not used	Not used
	1	See Figure 3-4	Byte Overrun		1	Not used	Not used
	2	See Figure 3-4	Receive Control Entry		2	Not used	Ptr Reg 0
	3	See Figure 3-4	15 Ones		3	Not used	Ptr Reg 1
	4	See Figure 3-4	Control Overrun		4	Not used	Ptr Reg 2
	5	See Figure 3-4	Traffic		5	Not used	Ptr Reg 3
	6	See Figure 3-4	Receive Cycle Share Halt		6	Not used	Ptr Reg 4
SS05	0	See Figure 3-4	Invalid Seq/Address	SS11	0	Not used	Not used
	1	See Figure 3-4	Byte Overrun		1	Not used	0
	2	See Figure 3-4	Receive Control Entry		2	Not used	Data Chain
	3	See Figure 3-4	15 Ones		3	Not used	Frame Chain
	4	See Figure 3-4	Control Overrun		4	Not used	Pad Insert
	5	See Figure 3-4	Traffic		5	Not used	FTA
	6	See Figure 3-4	Receive Cycle Share Halt		6	Not used	Xmit Turnoff
SS06	0	See Figure 3-4	Invalid Seq/Address	SS12	0	Not used	Count 128
	1	See Figure 3-4	Byte Overrun		1	Not used	Count 64
	2	See Figure 3-4	Receive Control Entry		2	Not used	Count 32
	3	See Figure 3-4	15 Ones		3	Not used	Count 16
	4	See Figure 3-4	Control Overrun		4	Not used	Count 8
	5	See Figure 3-4	Traffic		5	Not used	Count 4
	6	See Figure 3-4	Receive Cycle Share Halt		6	Not used	Count 2
SS07	0	See Figure 3-4	Invalid Seq/Address	SS13	0	Not used	Count 1
	1	See Figure 3-4	Byte Overrun		1	Not used	1
	2	See Figure 3-4	Receive Control Entry		2	Not used	0
	3	See Figure 3-4	15 Ones		3	Not used	Ptr Reg
	4	See Figure 3-4	Control Overrun		4	Not used	Ptr Reg
	5	See Figure 3-4	Traffic		5	Not used	Ptr Reg
	6	See Figure 3-4	Receive Cycle Share Halt		6	Not used	Ptr Reg
SS08	0	See Figure 3-4	Invalid Seq/Address	SS13	0	Not used	1
	1	See Figure 3-4	Byte Overrun		1	Not used	0
	2	See Figure 3-4	Receive Control Entry		2	Not used	Ptr Reg
	3	See Figure 3-4	15 Ones		3	Not used	Ptr Reg
	4	See Figure 3-4	Control Overrun		4	Not used	Ptr Reg
	5	See Figure 3-4	Traffic		5	Not used	Ptr Reg
	6	See Figure 3-4	Receive Cycle Share Halt		6	Not used	Ptr Reg
SS09	0	See Figure 3-4	Invalid Seq/Address	SS13	0	Not used	1
	1	See Figure 3-4	Byte Overrun		1	Not used	0
	2	See Figure 3-4	Receive Control Entry		2	Not used	Ptr Reg
	3	See Figure 3-4	15 Ones		3	Not used	Ptr Reg
	4	See Figure 3-4	Control Overrun		4	Not used	Ptr Reg
	5	See Figure 3-4	Traffic		5	Not used	Ptr Reg
	6	See Figure 3-4	Receive Cycle Share Halt		6	Not used	Ptr Reg
SS10	0	See Figure 3-4	Invalid Seq/Address	SS13	0	Not used	1
	1	See Figure 3-4	Byte Overrun		1	Not used	0
	2	See Figure 3-4	Receive Control Entry		2	Not used	Ptr Reg
	3	See Figure 3-4	15 Ones		3	Not used	Ptr Reg
	4	See Figure 3-4	Control Overrun		4	Not used	Ptr Reg
	5	See Figure 3-4	Traffic		5	Not used	Ptr Reg
	6	See Figure 3-4	Receive Cycle Share Halt		6	Not used	Ptr Reg
SS11	0	See Figure 3-4	Invalid Seq/Address	SS13	0	Not used	1
	1	See Figure 3-4	Byte Overrun		1	Not used	0
	2	See Figure 3-4	Receive Control Entry		2	Not used	Ptr Reg
	3	See Figure 3-4	15 Ones		3	Not used	Ptr Reg
	4	See Figure 3-4	Control Overrun		4	Not used	Ptr Reg
	5	See Figure 3-4	Traffic		5	Not used	Ptr Reg
	6	See Figure 3-4	Receive Cycle Share Halt		6	Not used	Ptr Reg
SS12	0	See Figure 3-4	Invalid Seq/Address	SS13	0	Not used	1
	1	See Figure 3-4	Byte Overrun		1	Not used	0
	2	See Figure 3-4	Receive Control Entry		2	Not used	Ptr Reg
	3	See Figure 3-4	15 Ones		3	Not used	Ptr Reg
	4	See Figure 3-4	Control Overrun		4	Not used	Ptr Reg
	5	See Figure 3-4	Traffic		5	Not used	Ptr Reg
	6	See Figure 3-4	Receive Cycle Share Halt		6	Not used	Ptr Reg
SS13	0	See Figure 3-4	Invalid Seq/Address	SS13	0	Not used	1
	1	See Figure 3-4	Byte Overrun		1	Not used	0
	2	See Figure 3-4	Receive Control Entry		2	Not used	Ptr Reg
	3	See Figure 3-4	15 Ones		3	Not used	Ptr Reg
	4	See Figure 3-4	Control Overrun		4	Not used	Ptr Reg
	5	See Figure 3-4	Traffic		5	Not used	Ptr Reg
	6	See Figure 3-4	Receive Cycle Share Halt		6	Not used	Ptr Reg

Figure 3-7 (Part 1 of 2). Sense Byte Breakdown Chart for CCA/HPCA SDLC (Code SSSS)

Location	Bit	Meaning If Bit Is Turned On (1)		Location	Bit	Meaning If Bit Is Turned On (1)	
		CCA	HPCA			CCA	HPCA
SS14	0	Not used	1	SS16	0	Not used	Count 128
	1	Not used	0		1	Not used	Count 64
	2	Not used	Ptr Reg 0		2	Not used	Count 32
	3	Not used	Ptr Reg 1		3	Not used	Count 16
	4	Not used	Ptr Reg 2		4	Not used	Count 8
	5	Not used	Ptr Reg 3		5	Not used	Count 4
	6	Not used	Ptr Reg 4		6	Not used	Count 2
	7	Not used	0		7	Not used	Count 1
SS15	0	Not used	Valid Entry	SS17	0	Not used	Count 256
	1	Not used	Invalid Sequence		1	Not used	Count 128
	2	Not used	FCS Valid		2	Not used	Count 64
	3	Not used	Pong Entry		3	Not used	Count 32
	4	Not used	Byte Overrun		4	Not used	Count 16
	5	Not used	Buffer Overrun		5	Not used	Count 8
	6	Not used	Flag Received		6	Not used	Count 4
	7	Not used	Count 256		7	Not used	Count 2

Figure 3-7 (Part 2 of 2). Sense Byte Breakdown Chart for CCA/HPCA SDLC (Code SSSS)


3.3.5 Test 1 Storage Card Isolation (Model 52C Only)

To isolate one of the four possible storage cards, perform the A2/1 variation of Test 1 from any Type A display. If bytes 5 through 8 are nonzero, the failing card is identified as follows:

Nonzero Byte	Failing Card	nnn Code Displayed
5	S2	392
6	T2	393
7	U2	394
8	V2	395

Display Example:

```
1122 3344 5566 7788 9900
XXXX XXXX 0000 0048 XXXX
```

Failing Card V2 

3.3.6 Test 1 Device Adapter Logs

There are two types of device adapter log. The log for Category A devices is accessed by using an A1/1 format. The information returned in the log consists of the last nnn number recorded, some basic adapter status information at the time of the failure, and statistical counters similar to the device error log counters. The log for Category B devices is accessed by using an A2/1 format. The information returned in the log consists of the last nnn number recorded, the operation being attempted at the time of the failure, and information in byte form as to how the operation ended. There are also statistical counters similar to the device error log counters. The above log information should be used to determine the

type of error condition that is disabling either of these device adapters. The logs can be used in the same manner as the host adapter logs to determine (1) the frequency of error, (2) what the adapter was doing at the time of error, (3) how the operation ended, etc.

3.3.7 Test 1 Type A Adapter Log

This device adapter log format is returned to the requesting 3278 in response to an A1/1 entry. The format detail is as follows:

- Line 1 – Returned the same as input, A1/1.
- Line 2 – Ten bytes are displayed on this line, but only three are currently used. The individual bytes are not labeled when displayed. Each byte is assigned a specific meaning. See the following example for byte identification:

```
0000 0000 0000 0000 0000
NNXX SSSS XXXX XXXX XXXX
```

The leftmost byte is labeled NN. This code represents the two low-order digits of any 200 series nnn number. The nnn number may or may not be displayed on a 3278.

The next byte to the right of NN is XX and is not used.

The next two bytes to the right of XX are labeled SSSS and represent the adapter status associated with the last failure. See Figure 3-8 for SS byte meanings.

- Line 3 – This line displays the statistical counter information associated with this adapter. If no errors are recorded for this adapter, the counters will display as follows:

```
0000 0000 0000 0000 0000
```

The counters are not numbered when they are displayed. They are, however, assigned counter position numbers. The leftmost two-digit position is counter number 08. The rightmost counter position *used* is counter number 08. The remaining positions are not used. The value in each counter is given in hexadecimal. The maximum value for any counter is FF.

Each counter is assigned a specific meaning, as follows:

Counter	Meaning
01	Status Q Entry Placed in Error Q
02	Unconfigured Device
03	Cycle Share Ended in Error
04	Invalid Adapter Status
05	Lost Status
06	Adapter stopped and was restarted
07	Cycle Share Machine Check
08	Non Command Cycle Share Machine Check

Bit	Meaning If Bit Is Turned On	Description
0	Counter Overflow	See nnn code 202, Appendix B.
1	Read Timeout	The DCA expected data or a response from the device while executing a command sequence and did not receive it in a pre-determined amount of time.
2	Turnaround Error or Read Line Parity	The DCA detected a coax turnaround sequence error or a coax parity error while executing a command sequence.
3	Read Data Byte Parity Error	The DCA detected a parity error in the data transmitted by the device.
4	Stop Poll	The DCA is not polling.
5	Timer	The DCA "timer" has fired. The timer is of 1 to 4 seconds' duration and is used primarily to check for a hung device.
6	Error Q Entry	The DCA has detected error status while communicating with or from an attached device and has stored this information in the Error Q in the 3274.
7	Not Used	
0	Extended Status Data	The DCA has set information in extension (left SS byte) status.
1	Command Completed	The DCA has completed a command sequence with a device.
2	Adapter Active	The DCA is active performing an operation.
3	Keystroke or Status Q Entry	The DCA has polled a device, has received a keystroke or status, and has placed the data in a Q in the 3274.
4	Not Used	
5	Machine Check	The DCA has detected an error in itself or on the UC I/O bus.
6	Enable/Disable	The DCA is enabled for operation.
7	Interrupt Request	The DCA has caused an interrupt request.

Figure 3-8. Sense (SS) Byte Definitions

3.3.8 Test 1 Type B Adapter Log

This device adapter log format is returned to the requesting 3278 in response to an A2/1 entry. The format detail is as follows:

- Line 1 – Returned the same as input, A2/1.
- Line 2 – Ten bytes are displayed on this line, but only four are currently used. The individual bytes are not labeled when displayed. Each byte is assigned a specific meaning. See the following example for byte identification:

```
0000 0000 0000 0000 0000
NNFF CCCC XXXX XXXX XXXX
```

The leftmost byte is labeled NN. This code represents the two low-order digits of any 200 or 300 series nnn number. The nnn number may or may not be displayed on a 3278.

The next byte to the right of NN is labeled FF. This represents the operation being attempted at the time of the failure. Refer to the Type B Adapter Operation Attempted Chart (Figure 3-9) to determine the type of operation in progress at the time of failure.

FF Code	Operation Attempted
00	Initialize (Enable and Start Idle Poll)
1F	Read Full Buffer without Start Idle Poll
21	Specific Poll without Start Idle Poll
23	Start Idle Poll
26	Write Full Buffer without Start Idle Poll

Figure 3-9. Type B Adapter Operation Attempted Chart (Code FF)

The next two bytes to the right of FF are labeled CCCC. These two bytes indicate how the operation attempted ended. Refer to the Type B Adapter Operation Ending Chart (Figure 3-10) to obtain this information.

3.3.9 Control Logic Error Log

The control logic error log format is returned to the requesting 3278 in response to an A3/1 entry. The format detail is as follows:

- Line 1 – Returned the same as input, A3/1.
- Line 2 – Eight bytes are displayed on this line, but only seven are currently used. The individual bytes are not labeled when displayed. Each byte is assigned a specific meaning. See the following example for byte identification:

```
0000 0000 1010 1000
CCPP MMRR HHDD AAXX
```


Receive Overrun – Insufficient buffers were allocated for the current task.

CP (2x or 6x) – A Call Progress Signal was received that can be retried (Category 2x or 6x).

Unexpected Condition/Overrun/Underrun – Same as TP leased.

Not +/BEL – An unexpected character was received from the network while awaiting a “Proceed to Select” or “Incoming Call”.

Invalid Status/Write Timeout/MC – Same as TP leased.

Selector Signal – An invalid character was detected in the selection signals.

X.21 Timeout – A network timeout has occurred.

Extension – Additional status can be found in Register 13 in Control Space.

DCE Not Ready – The controller detected that the network is not ready.

DCE Cleared – The controller has responded to a clearing sequence from the network.

CP Available – The controller has received a Call Progress Signal from an X.21 Switched Network as a result of issuing an outgoing call to the network.

Format Error – The Call Progress Signal or Line Identification or DCE Provide Information did not end with the proper delimiter (IA5+).

Note: *These functions are not supported by the 3274 Model 51C.*

ID/DP Available – The controller received either a Line Identification or DCE Provide Information from the network.

Retry Timeout – The controller has been monitoring the network for an incoming call for 3 seconds.

+/BEL Received –

BEL – The controller has detected an incoming call.

+ Received – The network has signaled to the controller to transmit the selection signals (dial number) as a result of a request to process an outgoing call.

Lost Data – Insufficient buffer allocation has been detected during receipt of either a Call Progress Signal or DCE Provide Information.

Comparator Error – The hardware has detected a mismatch between the signals on the input and output of the drivers and/or receivers.

Last Retry – The specifiable limit on retries has been exceeded.

Clear Timeout – During execution of a close function request, the clearing sequence did not terminate properly.

Receive Overrun – Insufficient buffers were allocated for the current task.

CP (2x or 6x) – A Call Progress Signal was received that can be retried (category 2x or 6x).

Invalid Status/Write Timeout/MC – Same as TP leased.

Clear Timeout – During execution of a close function request, the clearing sequence did not terminate properly.

3.3.11 Test 1 Extension for X.21 Switched

The following version of Test A0/1 is used for the X.21 Switched attachment. Line 4 is used for an X.21 Switched specific event. Line 5 contains X.21 Switched counters.

Line 1 A0/1
 Line 2 EEEE EEEE (same as HPCA)
 Line 3 XXXX XXXX (same as HPCA)
 Line 4 0022 4455 6678 KKMM LLII PPRR RRRR RRRR RRRR RRRR
 Line 5 CCCC CCCC CCCC CCCC CCCC CCCC CCCC CCCC CCCC CCCC

- Where: 00 = Last CP indicator of class 0X, 1X
 22 = Last CP indicator of class 2X, 3X
 44 = Last CP indicator of class 4X
 55 = Last CP indicator of class 5X
 66 = Last CP indicator of class 6X
 78 = Last CP indicator of classes 7X, 8X and 9X
 KK = Error Completion Flag Bits
 MM = Extended Error Completion Modifier Bits
 LL = Retry Modifiers
 II = Intermediate Status Flag Bits
 PP = Intermediate Status Modifiers
 RR = Reserved
 CC = X.21 Switched Error Counters

FIELD	BITS (NNN) IS NNN# ASSIGNED							
	0	1	2	3	4	5	6	7
KK	INV STAT (326)	SEL SIG (326)	0	WRTE T.O. (530)	X.21 T.O. (556)	MC (330)	CMPR ERR (562)	EXT
MM if X.21 T.O. set in KK*	0	0	T1 T.O.	T2 T.O.	T5 or T6 T.O. (CLR T.O.) (561)	T3A or T3B T.O.	T4 T.O.	
MM if EXT set in KK	0	0	NOT READY (557)	0	0	0	DCE CLR (559)	LAST RETRY
LL if LAST RETRY set in MM	0	RCV OVRN (326)	CP (2X or 6X)	UNEX COND (326)	OVER RUN (326)	UNDER RUN (326)	NOT +/BEL (560)	
II	CP AVAIL	FORM ERR (555)	ID/DP AVAIL	RETRY T.O.	+/BEL RCVD	LOST DATA (558)	CMPR ERR (562)	RETRY
PP if RETRY set in II	0	RCV OVRN	CP	UNEX COND	OVER RUN	UNDER RUN	NOT +/BEL	0

Note: The modifier fields will be zero if the specified conditions are not met.
 If both Ext and X.21 T.O. are set, Ext will be shown.

X.21 Switched Error/Exception Counts:

- | | | | |
|---------------------|--------------------------|-------------------------|-----------------------------|
| 1. Comparator Error | 6. Lost Data | 11. Not + BEL | 16. CP available 6X |
| 2. Format Error | 7. DCE Cleared | 12. CP available 0X, 1X | 17. CP available 7X, 8X, 9X |
| 3. X.21 Timeout | 8. Last Retry | 13. CP available 2X, 3X | 18. Clear Timeout |
| 4. Invalid Status | 9. CP | 14. CP available 4X | 19. Spare |
| 5. Not Ready | 10. Unexpected Condition | 15. CP available 5X | 20. Spare |

3.4 TEST 2: DISPLAY CONFIGURATION INFORMATION

Test 2 displays the configuration table residing on the system diskette. The configuration table data is the result of the user customizing the feature diskette and writing the configuration data from storage to the system diskette. Test 2 is displayed by entering Test mode by means of the ALT and TEST keys and then keying in slash (/), two (2), and ENTER. You may page from one display to another by pressing the ENTER key.

The bytes displayed are labeled by position number. The following format shows the configuration bytes labeled.

```
0001 0203 0405 0607 0809 0A0B 0C0D 0E0F
0000 0000 0000 0000 0000 0000 0000 0000
```

```
1011 1213 1415 1617 1819 1A1B 1C1D 1E1F
0000 0000 0000 0000 0000 0000 0000 0000
```

```
2021 2223 2425 2627 2829 2A2B 2C2D 2E2F
0000 0000 0000 0000 0000 0000 0000 0000
```

```
3031 3233 3435 3637 3839 3A3B 3C3D 3E3F
0000 0000 0000 0000 0000 0000 0000 0000
```

```
4041 4243 4445 4647 4849 4A4B 4C4D 4E4F
0000 0000 0000 0000 0000 0000 0000 0000
```

```
5051 5253 5455 5657 5859 5A5B 5C5D 5E5F
0000 0000 0000 0000 0000 0000 0000 0000
```

```
6061 6263 6465 6667 6869 6A6B 6C6D 6E6F
0000 0000 0000 0000 0000 0000 0000 0000
```

```
7071 7273 7475 7677 7879 7A7B 7C7D 7E7F
0000 0000 0000 0000 0000 0000 0000 0000
```

The subsystem configuration for your machine can be determined from Figure 3-12.

Byte ID	Description
00	Disk Type Identifier D4 = Feature Diskette E2 = System Diskette D3 = Language Diskette (WT) D9 = RPQ Diskette
01	Feature Disk Level ID
02	System Disk Level ID
03	Language Disk Level ID
04	3274 Model Number 84 = 51C/52C CCA/HPCA
05	Channel Address If an A Model
06	Internal Flag 00 = Not an A Model 01 = An A Model
07	Line Code (Model 51C/52C) 01 = EBCDIC 02 = ASCII
08	Communication Line Control (Model 51C/52C) 01 = BSC 02 = SDLC
09	BSC Poll Address (Model 51C/52C)
0A	BSC/SDLC Selection Address (Model 51C/52C)
0B	Communication Adapter Type (Model 51C/52C) 01 = CCA 02 = HPCA 04 = Encrypt/Decrypt 10 = Printer Polled by Host
0C	Model 51C/52C 01 = Wrappable Modem 02 = DDSA 04 = X.21 Leased 10 = X.21 Switched

Byte ID	Description
	20 = Loop Adapter 40 = EMI Switched 80 = 1200-bps IM Nonswitched (Model 51C only) AO = 1200-bps IM Switched
0D	Teleprocessing Options 01 = Omit Ans Tone 02 = Point-to-Point 04 = Half-Speed 08 = Select Standby 10 = Special RTS* 20 = Nonswitched Line 40 = NRZI 80 = WT DCE Sw Network
0E	Card R2 Specification 00 = Not Installed 01 = Not Applicable 02 = Not Applicable 04 = 3 Control Storage 08 = 51C/52C Storage
0F	Card S2 Specification 00 = Not Installed 01 = Not Applicable 02 = 2 Control Storage 04 = 4 Control Storage 08 = 51C/52C Storage
10	Card T2 Specification 00 = Not Installed 04 = 51C Storage
11	Card C2 Specification 00 = Not Installed 01 = Not Applicable 02 = Not Applicable 04 = 4 Control Storage

*Active from STX to EOT for BSC, 4-wire, multipoint, and modem without New Sync.

Figure 3-12 (Part 1 of 2). Subsystem Configuration

Byte ID	Description	Byte ID	Description
12	Card B2 Specification 00 = Not Installed 10 = Model 52C only; 128K 20 = Model 52C only; 256K	'25'	Attribute Select Typewriter Keyboard 01 3279 heads installed (convergence feature) 02 Programmed Symbol feature installed
13	Storage Expansion Feature 01 = Not Installed 02 = Installed 80 = Reserved 82 = Mass migrator IML	'26'	Attribute Select Control Unit Options 01 3270 SFAP Extended Data Stream installed 02 PS Decompression installed
14	Reserved	27	Reserved
15	Selector Pen '01' 3289 Text Print Control '02' Between Bracket Sharing 40 Alphameric MSR/MHS with Auto Enter 80 Alphameric MSR/MHS	28	Validation Number
16	Optional Code Select 01 SCS Printer support not installed 02 Host Loadable PAM not installed 04 Local Copy not installed 10 MSR/MHS not installed	29	Validation Number
17	Type B Dr/Rcvr Cards Installed 00 = None 01 = 1st Card 02 = 2nd Card 03 = 3rd Card 04 = 4th Card	'3D'	X.21 Switched — Key Top Definition 80 Direct key support on all terminals 40 Dial key support on all terminals 20 Local/Comm key support 10 Disconnect key support all terminals 08 Ext key support on all terminals 04 — 02 DCE support direct call 01 DCE support address call
18	Type A Dr/Rcvr Cards Installed 00 = None 02 = 1st Card 04 = 2nd Card 06 = 3rd Card 08 = 4th Card	'3E'	Number of automatic redial attempts allowed
19	Total Category B Terminals (Value given in hex)	'3F'	Ring time (see Note) 80 12.8 seconds 40 6.4 seconds 20 3.2 seconds 10 1.6 seconds 08 0.8 seconds 04 0.4 seconds 02 0.2 seconds 01 0.1 seconds
1A	Total Category A Terminals (Value given in hex)	'41'	38LS Responses 80 5500 feature 40 5501 20 5502 10 5507 08 5508
1B	Total All Terminals (Value given in hex)	42-51	Patch ID Values
1C	Attached Ptrs 01 = High-Speed Loop	52	Number of RPO Diskettes Installed
1D	EBCDIC Control Unit ID (Value given in hex)	54-58	Part Number and EC Level of First RPO Installed (7-digit PN, 3-digit EC level)
1E	Language Code 01 = (US) English 02 = (US) ASCII For others, see Appendix C in <i>IBM 3270 Information Display System: 3274 Planning, Setup, and Customizing Guide, GA27-2827</i> .	59-5D	Part Number and EC Level of Second RPO Installed (7-digit PN, 3-digit EC Level)
1F	Reserved	5E-62	Part Number and EC Level of Third RPO Installed (7-digit PN, 3-digit EC Level)
20	Total Type A DCB Count (Value given in hex)	63-6F	Reserved
21	Total DCB Count (Value given in hex)	70	Feature Diskette Level
22	Print Authorization Matrix Entry Count	71	Feature Diskette Suffix
23	Keyboard Types Specified 01 = Typewriter 02 = Data Entry 04 = Data Entry II 08 = APL 10 = Text	72	System Diskette Level
'24'	Total Type A Extended DCB Count (value given in hex)	73	System Diskette Suffix
		74	Language Diskette Level
		75	Language Diskette Suffix
		76, 77	EC Level and Suffix Level of First RPO Installed
		78, 79	EC Level and Suffix Level of Second RPO Installed
		7A, 7B	EC Level and Suffix Level of Third RPO Installed
		7C	Reserved
		'7D'	01 - Attribute Select Typewriter Keyboards 02 - Numeric Lock feature on above

Note: Time between automatic redial attempts (X.21).

Figure 3-12 (Part 2 of 2). Subsystem Configuration

3.6 TEST 4: RESET ANY TEST 1 LOG

Test 4 provides the capability of resetting any device adapter, device, host adapter, or control logic log. By using the ALT and TEST keys, you may enter Test mode. Test 4 may now be used as shown below:

- 00 to 16/4 (51C) – Resets the device log for the device 00 to 08/4 (52C) specified to all zeros (0).
- A0/4 – Resets the host adapter log to all zeros (0).
- A1/4 – Resets the Type A adapter log to all zeros (0).
- A2/4 – Resets the Type B adapter log to all zeros (0).
- A3/4 – Resets the control logic log to its initial values.

Test 4 may be used to track intermittent failures without re-IML or powering off the machine to clear the error logs.


3.7 TEST 6: DEVICE CONTROL BLOCK DISPLAY

The device control block (DCB) contains common subsystem information pertaining to all terminals, device and host adapter information, and limited device-feature information. The Test 6 display represents the most current information regarding a specific device. The DCB should be checked when it is necessary to determine specific device parameters such as: (1) Is the device configured as a display or printer? (2) Is the display screen size correctly specified? (3) Is an MDT bit set? (4) The status of keyboard for this device, etc.

To invoke Test 6, you must first enter Test mode by means of the ALT and TEST keys. The DCB for any device from 00 to 16 (for 51C) or 00 to 08 (for 52C) may be displayed by keying the device number followed by a slash (/), the number 6, followed by an ENTER key. Each DCB consists of four displays of 64 bytes each. The individual bytes are not labeled. There are six lines to each display. The first line is always returned the same as input 00 to 16/6 or 00 - 08/6 for each display. The second line of each display will indicate the beginning byte ID of that display. See Figure 3-13 for details. You may page from one display to the next by pressing the ENTER key. Paging beyond display 1C will result in a locked keyboard and X-f displayed on the status line. See Figure 3-14 for DCB interpretation.

3.7.1 Test 6 Byte Identification

Figure 3-13 identifies the bytes of the DCB displays.



Note: See Appendix C for extended data stream configuration.

Figure 3-13. Test 6 Byte ID Chart

3.7.2 DCB Bit Definitions

Bytes not defined in Figure 3-14 are not used. Bits defined as "Reserved for engineering use" may contain zeros or ones. They should be disregarded unless otherwise directed by the next level of the support structure.

Location	Bit	Meaning If Bit Is Turned On
Byte 02	0	See figure A
	1	
	2	
	3	See figure B
	4	
	5	Keyboard is attached
	6	This is a Type B device
7	Numeric Lock feature is present	

Display Model	1	2	3	4	5
Bit 0	0	0	0	1	1
1	0	1	1	1	1
2	1	0	1	1	0

figure A

Bit	Data Entry KB	Printer	Typewriter, APL, Text-Keyboard
3	0	1	0
4	1	1	0

figure B

Byte 03	0	Katakana keyboard is attached
	1	SCS Feature on Type A Adapter Printer
	2	Text Keyboard
	3	3289 Text Feature
	4	APL Keyboard
5-7	Reserved	

Byte 04 (Category A Devices)	0	Not used
	1	Security keylock present
	2	Selector pen attached
	3	Reserved for engineering use
	4	MSR/MHS attached
	5	Reserved for engineering use
	6	Reserved for engineering use
7	ECS (APL/Test)	

Byte 04 (Category B Devices)	0	Device busy
	1	Buffer parity
	2	Indeterminate write errors
	3	Inhibit start idle poll
	4	Buffer size (0=480, 1=1920)
	5	DAU issued
	6	Start print
7	Format bits	

Byte 06	0	DCB busy
	1	Subsystem ready (DCB initialized)
	2	Nondisplay
	3	Op Complete pending from device
	4	Linkage Stacked
	5	Stacked status/keystroke/error present
	6	Numeric Lock field
7	Reserved for engineering use	

Figure 3-14 (Part 1 of 3). DCB Bit Definition Chart

Location	Bit	Meaning If Bit Is Turned On	Location	Bit	Meaning If Bit Is Turned On	
Byte 07	0	Protected field or attribute character	Byte 0E	0	Invalid dead key (language 06 only)	
	1	ECS Buffer Updated		1	2NN machine check	
	2	Print ID entry mode		2	Communication check	
	3	Reserved for engineering use		3	Program check	
	4	MDT bit not set		4	Security key off	
	5	Do not enter		5	3NN machine check	
	6	Reserved for engineering use		6	Too much (keystroke-MSR)	
Byte 08	7	Insert mode	7	Operator not authorized		
	0	No indicators to write or erase (Category B displays and printers, Category A printers)	Byte 0F	0	Not enough	
	1	Test mode		1	Wrong number	
	2	Alpha shift (not Katakana shift)		2	Numeric shift	
	3	Reserved for engineering use		3	Operator retry	
	4	Text indicator		4	Local-copy failure while printer printing (printer failure)	
	5	Upshift indicator		5	Device busy doing local copy	
6	Katakana shift	6		Reserved for engineering use		
Byte 09	7	APL indicator	7	System lock		
	0	Online indicator	Byte 10	0	Communication check reminder	
	1	System-wait condition		1	My Job indicator	
	2	Hard-lock condition		2	System Operator indicator	
	3	Keyboard in use by operator		3	Unowned indicator	
	4	DCB scheduled for function 6 – waiting (BSC)		4	Not enabled (not online)	
	5	DCB scheduled for function 5 – waiting (BSC)		5	Reserved for engineering use	
6	Reserved for engineering use	6		Reserved for engineering use		
Byte A0 (52C only)	7	OK for function to be suspended	7	Minus Symbol indicator (WT only)		
	0	Keyboard mode – Kanji/Chinese (multishift input mode)	Bytes 14, 15	Cursor position (3278 only) ¹		
	1	Keyboard mode – (10-key input mode)	Bytes 1A, 1B	First character position on display ¹		
	2	Two-byte code character attempted	Bytes 1C, 1D	Last character position on display ¹		
Byte 0B	3-7	Reserved for engineering use	Byte 24 (Category A devices)	0	Model 5 Wide Screen	
	0	Reserved for engineering use		1	Model 5 Wide Screen	
	1	Reserved for engineering use		2	480-character format	
	2	Reserved for engineering use		3	Reserved for engineering use	
	3	Local copy (display to printer) in progress		4	Inhibit display video	
	4	Alternate Screen Size		5	Blank cursor	
	5	Attributes not valid		6	Cursor reverse	
6	Monocase switch active in device	7	Cursor blink			
Byte 0C	7	Reserved for engineering use	Byte 25	4	APL/Text Feature 3278	
	0	Printer messages queued – local copy		Byte 34	0	SNA – printer allocated to local copy
	1	Reserved for engineering use			1	SNA – local copy printer allocated for host use
	2	Local copy malfunction has occurred			2	SNA – host request for local copy allocated printer
	3	Wrong place			3	Alternate row length indication
	4	Minus Function			4	Default row length indication
	5	MSR – wrong card MSR/MHS			5	Reserved for engineering use
6	Message pending	6	SNA – LU in ERP state			
Byte 0D	7	Message reminder	7	SNA – host communications disabled (LU active)		
	0	Printer printing – local copy	Byte 35	0	Local copy printing (host initiated)	
	1	If display has printer assigned for local copy		2	Local copy (printer available for next message) SNA	
2	Printer matrix changed (associated with this display)	3-7		Reserved for engineering use		

¹When using this byte on Category A devices, subtract hex 50 from the cursor position. This will give you the current I/O interface code. (If Model = 1, subtract X"40".)

Figure 3-14 (Part 2 of 3). DCB Bit Definition Chart

Location	Bit	Meaning If Bit Is Turned On
Byte 37 (52C only)	0	Kanji/Chinese terminals attached
	1	Kanji/Chinese keyboards attached
	2	Current field attribute is known
	3	Current field is Kanji/Chinese
	4-7	Reserved for engineering use
Byte 46	0	Other function request
	1	Select pen for immediate detect field
	2	Required for Select Pen field
	3	Dup Key switch (Auto Tab)
	4	Reserved for Engineering
	5	Clicker disabled
	6	Reserved for engineering use
Byte 47	0	Disable cursor display
	5	Dead key sequence in process
	6	Local copy received IR
Byte 4E (Category A devices)	0-7	Attribute affecting field cursor (3278 only)
Byte 4E (Category B devices)	0	Device check
	1	Transmit check
	2	Information pending
	3	Not ready (printer only)
	5	Equipment check (printer only)
Byte 4F (Category B devices)	0	Device busy
	1	Buffer size (0=480, 1=1920)
	2	0 = display, 1 = printer
	3-7	Device address (type B adapter port number) Byte B6 (Mod BSC) Pending Device Status
Bytes 50, 51		Present attribute address (3278 only) ¹
Bytes 52, 53		Next attribute address (3278 only) ¹
Byte 68	0	Printer equipment check/display disabled due to error
	1	Intervention required/Security Key Off
	2	Printer busy processor abort
	3	Reserved for engineering use
	4	Print in process

¹When using this byte on Category A devices, subtract hex 50 from the cursor position. This will give you the current I/O interface code. (If Model = 1, subtract X"40".)

Figure 3-14 (Part 3 of 3). DCB Bit Definition Chart

3.8 TEST 7: DYNAMIC CONVERGENCE (COLOR)

For a description of this test, see the *IBM 3279 Color Display Station Maintenance Information* manual, SY33-0069.

3.9 TEST 8: PSs, HIGHLIGHTING, AND COLOR

For a description of this test, see the *IBM 3279 Color Display Station Maintenance Information* manual, SY33-0069.

3.10 KANJI/CHINESE CHARACTER DISPLAY

For a description of this test, see the *IBM 3278 Model 52 Display Station Maintenance Information* manual, SY18-2032.

3.11 3277 PATH TEST AND TEST REQUEST KEY

3.11.1 BSC or Local Host Attached

On 3277s attached to a BSC or local host attached 3274, the coax path from the device to the control unit can be verified by means of the Test Request key. Pressing the Test Request key will cause the control unit to attempt to turn on the System Available indicator on the 3277. A Test Request message will also be generated if the control unit is online to the host.

3.11.2 SNA Attached

On 3277s attached to an SNA-configured 3274, the coax path from the device to the control unit can be verified by means of the Test Request key twice. The first pressing of the key will cause the control unit to attempt to turn off the Do Not Enter indicator; the second will cause the control unit to attempt to turn on the System Available indicator. Operationally, this sequence is used to enter and exit 2-key sequence mode. Test Request followed by Clear is functionally equivalent to the Systems Request key on 3278s in SNA mode. Test Request followed by PA1 is the equivalent in function to the ATTN key on 3278s in SNA mode. Test Request followed by Test Request returns the 3277 to normal operation.

Chapter 4. Subsystem Tests, External Tests, and Subsystem Service Aids

4.1 INTRODUCTION

Subsystem tests consist of the Bus and Lamp test and the IML tests.

4.2 INITIAL MACHINE LOAD (IML) TESTS

Initiating a normal IML (ALT switch not pressed and system diskette installed) invokes a sequence of hardware tests before operational code is loaded. When the IML pushbutton is pressed, a hardware Bus and Lamp test is performed. When the IML pushbutton is released, the diagnostic sequence begins and the error indications described in Figure 4-1 may be displayed.

Code	Description
0000	Control Logic failure — All four indicators not lit indicates a control logic failure. The test sequence will not proceed. The failure of any adapter can also cause this failure. Parity problems can also appear to be control-logic failures.
0001	Low Storage failure — A steady display of this code in the 8 4 2 1 indicators indicates a failure in low storage.
0010	31SD failure — A flashing display of this code indicates the 31SD Diskette drive failed. A steady display of this code may be caused by any of the following: <ul style="list-style-type: none">● Failure of the 31SD Diskette drive to come "ready."● A hung sequence (did not start) because of another adapter failure.● Loss of ground to the 31SD Diskette drive (check A1Z2 cable).● Defective diskette.
0011	Type A Adapter failure — A flashing display of this code indicates the test for this adapter not requiring a 3278 attached failed. A steady indication may indicate the sequence is hung (did not start). Any activity from a device that would normally disable the adapter will also cause this test to fail.
0100	Type A Adapter Failure — A flashing display of this code indicates the tests for this adapter that require a 3278 attached failed. If a POR response was not detected from Port A0, this test will automatically be bypassed. A failing display can also cause this test to fail.
0101	Storage Card Failure — A flashing display of this code indicates the storage test failed. The failure could be caused by a defective storage card, failure of a component interfacing with storage (Extended Function Store feature), or incorrect customizing parameters. If a 3278 display is powered on at port A0, additional failure information will be displayed on the screen.

Figure 4-1. IML Test Error Indications

4.2.1 ALT 1 IML Mode

Pressing the IML pushbutton while holding the ALT switch in the ALT 1 position bypasses the normal IML test sequences and causes the unit code to be directly loaded. This will enable the user to bypass a failing test sequence (for example, a defective Type B adapter). In this case, the control unit is operational except for the Type B adapter. The Bus and Lamp test functions the same as during a normal IML. See Figure 4-2 for an ALT 1 IML sequence.

Code	Description
0110	Host Adapter Failure — A flashing display of this code indicates the host adapter/attachment test failed. Failure could be caused by the following, in addition to defective cards: (1) model specified wrong when customized, (2) system diskette not for this machine, or (3) problem on the host interface has disabled the adapter.
0111	Modem Wrap failure — A flashing display of this code indicates the Modem Wrap/DDSA test failed. The wrap test is run only if a wrappable modem was specified at customizing time. If a 3278 is powered on at port A0, additional information concerning the failure is available on the screen. Data displayed is as follows: 0111 016 — Modem failed to set Clear to Send 0111 013 — General modem failure
1000	Type B Adapter failure — A flashing display of this code indicates the Type B Adapter test has failed. The test looks for the first Type B display powered on and attempts to do an Erase-Write-Erase operation. The cursor is left in the lower right portion of the screen. Any Type B device failure that would disable the adapter would cause this test to fail.
1001	Encrypt/Decrypt Adapter Failure — A flashing display of this code indicates that the Encrypt/Decrypt Adapter test has failed.
1010	31SD Error — This flashing code is displayed whenever a 31SD problem has been detected after the initial 33FD test. This failure can also be caused by invalid tracks or data on the diskette.

Note: At least one complete IML test sequence is required to initialize control storage. Bypassing IML by using either ALT 1 or ALT 2 mode does not perform this initialization function; therefore it is possible that invalid parity may exist after initial power on if normal IML has been bypassed.

Step	Code	Meaning
1. ALT 1 and IML pressed	1111	Bus and Lamp test OK
2. ALT 1 and IML released	0000	Initiate Unit Code loading
3. Wait	1111	Unit Code loading
4. Begin normal operation	0000	Unit Code loaded

A hang condition at either step 3 or step 4 usually indicates a defective system diskette or a configuration error.

Figure 4-2. ALT 1 IML Sequence

4.2.2 ALT 2 IML Mode, Models 51C and 52C with Wrappable Modem (Test/Operate Switch in Operate Position)

Pressing the IML pushbutton while holding the ALT switch in the ALT 2 position invokes an extended Modem Wrap test. Some types of modems require manual intervention to set up for wrap testing. The test checks the transmission path (Transmit and Receive Data lines) to and from the modem. Modem clocking is required to run this test successfully, and a missing or defective modem clock will result in a failure indication (flashing 0111). The intent of this test is *NOT* to test the modem. The Bus and Lamp test functions the same as during a normal IML. See Figure 4-3 for this ALT 2 sequence.

Step	Code	Meaning
1. ALT 2 and IML pressed	1111	Bus and Lamp test OK
2. ALT 2 and IML released	0000	Begin Modem Wrap test
3. Wait	0110	Communication Adapter Test running
	0110	Flashing — Communication Adapter Test failure
4. Wait	0111	Prewrap, Adapter Wrap, and Modem Wrap tests are running
5. End Test — A normal IML required to begin normal operation	0111	Flashing — Modem wrap test has failed.
	1000	Successful test — Carrier not present after completion of test.
	1111	Successful test — Carrier is present after completion of test.
	0111	Flashing — Modem wrap test has failed.

When this test is run in ALT 2 mode, the 3278 does not display the 8 4 2 1 indications.

Figure 4-3. ALT 2 IML Sequence, Models 51C and 52C with Wrappable Modem

4.2.3 ALT 2 IML Mode, Models 51C and 52C without Wrappable Modem (Test/Operate Switch in Test Position)

Pressing the IML pushbutton while holding the ALT switch in the ALT 2 position invokes an extended Modem Wrap test. When a nonwrappable modem is being used, the EIA test cable Test/Operate switch should be in the TEST position. This test checks the transmission path (Transmit and Receive Data lines) to and from the Test/Operate switch at the end of the cable. The test cable must be attached to the modem, and the modem must provide clocking or a failure indication of 0111 (flashing) will result. The Bus and Lamp test functions the same as during a normal IML. See Figure 4-4 for this ALT 2 sequence.

Step	Code	Meaning
1. ALT 2 and IML pressed	1111	Bus and Lamp test OK
2. ALT 2 and IML released	0000	Begin Modem Wrap test
3. Wait	0110	Communication Adapter Test running
	0110	Flashing — Communication Adapter Test failure
4. Wait	0111	Prewrap, Adapter Wrap, and Modem Wrap tests are running.
5. End Test	0111	Flashing — Modem Wrap test has failed.
	1000	Successful test.
6. Return TEST/OPERATE switch to Operate position.	1000	Carrier not present.
	1111	Carrier is present.

Figure 4-4. ALT 2 IML Sequence, Models 51C and 52C without Wrappable Modem

A normal IML is required to begin normal operation. When this test is run in ALT 2 mode, there is no 3278 display of failing indications (0111 013, etc.). See paragraphs 5.4.3 and 5.4.4 of the 3274 MIM, for additional information on the Wrap Test without Modem, and DDS Adapter Wrap Test.

4.2.4 ALT 2 IML Mode, Modem Self Test for Model C with Greater than 1200-bps Integrated Modem

Pressing and holding the ALT IML Address switch in position 2 will cause the modem self-test to be initiated and repeated about every 4 seconds until the switch is released. Releasing the switch should return the modem to Operate mode, regardless of the test results.

While the test is being run, the TEST light on the operator panel is lit. If the test is successful, the Data Quality—Good indicator on the operator panel will flash each time the test is run. The indicators on the A1D2 card will also flash each time the test is run successfully.

If the test fails, the failing card is indicated in the A1D2 card indicators. Figures 4-5 through 4-7 show the meanings of the indicators. Cards indicated as failing are replaced in order of probability. If multiple A1D2 card indicators are displayed, replace all cards indicated.

Flashing Indicator	Steady Indicator	Operator Panel Poor Indicator	Failing Card
1111		Off	Test successful No failure
111		On or flashing	D2, G2, C4
	000	On or flashing	D2, G2, C4
	111	On or flashing	D2, G2, C4
	100	On	C2, G2, D2
	010	On	G2, D2
	001	On	D2, G2, C4
1 = On 0 = Off			

Figure 4-5. A1D2 Card Indicator for 2400-bps Integrated Modem

Flashing Indicator	Steady Indicator	Operator Panel Poor Indicator	Failing Card
1111		Off	Test successful No failure
1111		On or flashing	D2, G2, F2, C4
	0000	On or flashing	D2, G2, C4
	1111	On or flashing	D2, F2, G2, C4
	1000	On	C2, G2, D2
	0100	On	F2, D2, G2
	0010	On	G2, F2, D2
	0001	On	D2, F2, G2, C4
1 = On 0 = Off			

Figure 4-6. A1D2 Card Indicator for 4800-bps Integrated Modem

Flashing Indicator	Steady Indicator	Operator Panel Poor Indicator	Failing Card
1111		Off	Test successful No failure
1111		On or flashing	E2, G2, F2, D2, C4
	0000	On or flashing	E2, G2, C2, C4
	1111	On or flashing	E2, D2, F2, G2, C4
	1000	On	D2, F2, E2
	0100	On	F2, D2, E2, G2
	0010	On	G2, E2, F2, D2
	0001	On	E2, F2, G2, D2
	0000	On	C2, G2, E2, D2
1 = On 0 = Off			

Figure 4-7. A1D2 Card Indicator for 9600-bps Integrated Modem

4.3 3274 MODEL 51C DISPLAY SYSTEM ONLINE TESTS

4.3.1 Purpose

These Online Tests (OLTs) provide path testing for the 3274 Model 51C display system host attachment downline from a 270X or a 370X.

Prior to invocation of the OLT, the 3274 must complete its IML sequence; that is, the 3274 operational resident code is in control and ready for I/O operations with the host.

4.3.2 Applicable Executive Control Programs

These OLTs are compatible with the following control programs at the levels indicated or higher:

DOS/VS OLTEP	33
OS/VS1 OLTEP	6
OS/VS2 SVS OLTEP	1.7
OS/VS2 MVS OLTEP	3.7
TCAM TOTE	10
OLTSEP	9.0
OS OLTEP	21.8
DOS OLTEP	26

4.3.3 3274 Models 51C and 52C Online Tests

See Figure 4-8 to determine the OLT to be used for a specific configuration.

Configuration	OLT User's Guide	OLT
3274 Models 51C and 52C BSC operating with a 270X, or a 370X with the Emulator Program (EP).	D99-3274B	R3274A
3274 Models 51C and 52C BSC operating with a 270X, 370X EP, or a 370X NCP. R3274B requires that the 3700 Series Diagnostics be cataloged at the host. It is suggested that R3274A be used when operating with a 270X, or 370X EP.	D99-3274C D99-3700A	R3274B
3274 Models 51C and 52C SDLC operating with a 370X NCP. Use the following Link Level Tests:		
Link Level 1	D99-3700C	T3700LTE
Link Level 0	D99-3705A	T3705

Figure 4-8. 3274 Models 51C and 52C Online Tests

4.4 SERVICEABILITY AIDS

The following procedures are intended to supplement problem determination and troubleshooting techniques. Monitoring procedures for interface lines, coax checking procedures, and patching procedures are some of the aids provided.

4.4.1 Diskette Patching Procedure

This procedure is to be used by the Support Customer Engineer, at the direction of the next level of the support structure.

Note: *Diskette patching is an emergency procedure only. It should be used only when time will not permit waiting for an update diskette from the plant of manufacture.*

Before the patching procedure can be performed, the patch header information and the patch coding must be obtained from the next level of the support structure.

Use the steps listed below to perform the diskette patching procedure. If, while performing steps 4 and 5, you want to cancel what you have done and start again, enter FF and press the ENTER key. This will bring you back to step 3. If you enter an unacceptable response, the operator code in the upper center of the display will alert you to the problem. Figure 4-9 gives the meanings of the operator codes.

The 8 4 2 1 codes also provide a guide to your progress in the patching procedure.

1. Insert the feature diskette. While holding the ALT IML Address switch in position 1, momentarily press and release the IML button; then release the ALT IML Address switch. Within 2 minutes, the 8 4 2 1 indicator code will be flashing 1011.
2. Replace the feature diskette with the customized system diskette. DO NOT PRESS IML. Within 1 minute, the 8 4 2 1 indicator code will be flashing 1110.
3. Replace the system diskette with the feature diskette used in step 1. DO NOT PRESS IML. Within 1 minute, the 8 4 2 1 indicator code will be a steady 0001. If you are using a 3279, the color convergence pattern will be displayed on the display screen. To bypass this pattern, hold down the ALT key, momentarily press the TEST key, and release the ALT key. Sequence number 001 will be displayed on the display screen. Continue with step 4.

If you want to converge the 3279, follow the instructions in the "Color Convergence Procedure" in the *IBM 3270 Information Display System 3274 Control Unit Customizing Guide*, GA23-0065.

4. When sequence number 001 appears in the upper-left corner of the display screen,
 - Key in the following characters:
1234567890ABCDEF
 - Press the spacebar once.
 - Key in the two-digit Validation Number shown on the system diskette label.
 - Press ENTER.
5. When sequence number 011 appears, key a 1 and press ENTER.
6. When sequence number 012 appears, key in the patch header information and press ENTER.
7. When sequence number 013 appears, key in the patch information one line at a time. Press ENTER after each line. After all lines of the patch have been keyed in, type 49 and press ENTER.
8. Sequence number 011 will appear again. If you have another patch to enter, type 1, press ENTER, and go to step 7.

If you do not have another patch to enter, key a 0, press ENTER, and go to step 9.

9. At this time, either sequence number 021 is displayed (meaning that no printer authorization matrix has been defined), or the defined matrix is displayed.
If sequence number 021 is displayed, type 0 and press ENTER.
If a matrix is displayed, move the cursor to the entry for 901, change it to a 1, and press ENTER.
10. When sequence number 031 appears, enter the number of RPQ diskettes being used (0, 1, 2, or 3), and press ENTER.
11. When sequence number 999 appears, move the cursor to the entry for 900, change it to a 1, and press ENTER.
12. Within 2 minutes, the 8 4 2 1 indicator code on the 3274 Control Unit will be flashing one of the following:
 - 1100 — Replace the feature diskette with the RPQ diskette. DO NOT PRESS IML. After the RPQ diskette is inserted, the code will change to 0111 within 30 seconds. If additional RPQ diskettes are required, the indicator code will again flash 1100. Repeat the procedure for each additional RPQ diskette. AT NO TIME SHOULD YOU PRESS IML. When the RPQ diskette procedure is completed, the indicator code will be flashing 1110. Reinsert the feature diskette. DO NOT PRESS IML. Within 2 minutes, the 8 4 2 1 indicator code will flash 1011 or 1101.
 - 1011 — Replace the feature diskette with the system diskette. DO NOT PRESS IML. Within 20 minutes, the indicator code will change to 1111. The patch procedure is now complete, and a normal startup can be initiated.
 - 1101 — Replace the feature diskette with the language diskette. DO NOT PRESS IML. Within 30 seconds, the indicator code will change to 0111 and then to flashing 1011 within 1 minute. When the indicator code is flashing 1011, replace the language diskette with the system diskette. DO NOT PRESS IML. Within 20 minutes, the indicator code will change to 1111. The patch procedure is now complete, and a normal startup can be initiated.

Code	Meaning
1	One or more of the first 10 characters is incorrect; reenter response.
2	One or more of the 11th to 17th characters, including the space, is incorrect; reenter response.
3	The diskette level is wrong; use the correct diskette.
11	An invalid response has been entered (too many characters, value too high or too low, wrong character, etc.); reenter response.
12	An entry other than A, B, or C was entered in response to sequence 151; reenter response.
13	The response has too few characters; reenter response.
14	The numerical sum of the responses to sequence numbers 111 and 112 is greater than 32; verify, and reenter response(s).
21	An unacceptable change was made during modification (sequence 999); recheck entries, and correct.
22	If the response to sequence number 321 is 1, the responses to sequence numbers 121 and 131 must be 02 and 1, respectively. If the response to sequence number 321 is 0, the response to sequence number 121 must not be 02.
23	One or more responses are not compatible with the response to sequence number 331; verify, and correct response(s).
24	The responses to sequence numbers 131, 132, and 133 are 0's (at least one must be a 1); verify, and correct response(s).
80	Invalid characters were entered; reenter response.
81	All patch areas are in use.
82	The patch ID number (header) already exists; use a new header.
83	The update number does not match the number in the configuration table; verify, and reenter response.
84	An attempt was made to delete a patch that does not exist.
86	The call line did not contain the correct data length.
87	Patch information was not entered. Sequence number 013 must have at least one patch before 48 is entered.
89	The number of lines entered does not agree with the count specified in the header line.
99	All entries are acceptable, but the entry for sequence number 900 has not been changed to 1.

Figure 4-9. Operator Codes

4.4.2 3274 Subsystem Dump Procedure

The 3274 Dump Diskette is to be used when the System Support Center requests a 3274 subsystem dump. The 3274 Subsystem Dump Procedure should be performed by the customer engineer, but, for intermittent problems, it can be performed by the customer.

1. Replace the system diskette with the dump diskette.
2. While holding the Alt IML Address switch in position 1, momentarily press and release the IML switch; then release the Alt IML Address switch.
3. After a few minutes of operation, the 8 4 2 1 indicator lights will change to a flashing 1011 code. When this condition occurs, replace the dump diskette with the system diskette. Do *not* press IML.
4. After the system diskette is inserted, the 8 4 2 1 indicator lights will first change to a steady 0000 code; after approximately 10 seconds, they will change to a flashing 1001 code. When this condition occurs, replace the system diskette with the dump diskette. Do *not* press IML.
5. When the 8 4 2 1 indicator lights change to a steady 1111 code, the dump procedure is completed. When this condition occurs, replace the dump diskette with the system diskette and perform a normal IML to restore the subsystem for customer operation.

Note: *Follow this procedure exactly, using only the dump and system diskettes at the specified steps. If the wrong diskette was used, retry the procedure, starting at step 1.*

4.4.3 Coax Cables

Cables must be procured, installed, and maintained by the customer. Cable h is for indoor installation only; cable l is for outdoor installation, although it is approved for indoor use as well.

4.4.3.1 Cable h (Indoor)

Presently, the only approved cable bears the commercial designation RG62A/U. Cables may be purchased from IBM or from a customer-selected source. Bulk cables may be ordered from IBM by specifying IBM part 323921 and the length on a Miscellaneous Equipment Specification (MES) form. Preassembled cables may be purchased from IBM by specifying IBM part 2577672 and the length on the MES form.

For fabricating cables, two BNC-type connectors are needed: IBM part 1836444 or equivalent. These two connectors can be ordered in a kit from IBM by specifying "Connector Group (indoor type), IBM part 1836418" on the MES form. Instructions for assembling BNC-type connectors on bulk cable are given in *Assembly of Coaxial Cable and Accessories for Attachment to IBM Products*, GA27-2805.

4.4.3.2 Cable l (Outdoor)

Cable l is a RG62A/U modified for outdoor/underground installation. This cable is suitable for indoor and outdoor installation and for direct burial. Cable may be purchased from IBM or from a source selected by the customer.

Bulk cable may be ordered from IBM by specifying IBM part 5252750 and the length on a Miscellaneous Equipment Specification (MES) form. Preassembled cables may be purchased from IBM by specifying IBM part 1833108 and the length on the MES form.

For fabricating cables, two BNC-type connectors are needed, IBM part 1836447 or equivalent outdoor type. These two connectors may be obtained in a kit from IBM by specifying "Connector Group (outdoor type); IBM part 1836419" in the MES form. Instructions for assembling BNC-type connectors on bulk cable are given in *Assembly of Coaxial Cable and Accessories for Attachment to IBM Products*, GA27-2805.

4.4.3.3 Coaxial Cable Splicing

Do not cut and splice cables; instead, use a quick-disconnect adapter, IBM part 5252643, or commercial adapter, Amphenol Corp. part UG-914/U. A maximum of 13 connections is allowed in any given cable run. The adapter and the attached cable connectors must be covered with 127 mm (5 inches) of shrink tubing, 19.05 mm (0.75 inch) expanded diameter, to prevent accidental grounding of splice. This adapter and connecting jacks should be water-proofed for applications requiring this type of installation.

4.4.4 Coax Testing with Scope

This procedure describes how to test any length of coax cable—in segments of up to 1500 m (5000 ft)—with a Tektronix 453 oscilloscope, or equivalent. For additional information on coax testing, refer to the *Oscilloscope Measurement Procedure for Twisted and Coax Cables*, S226-3913.

Note: *Since the communication lines are the customer's responsibility, the following practice should be observed:*

1. *Use this procedure only after (1) all product maintenance procedures have been followed, (2) a communication line problem is suspected, and (3) the customer indicates he cannot locate the line problem.*
2. *Do not use the procedure for the purpose of checking the quality of the wiring work done by customer personnel or by a contractor.*

4.4.4.1 Testing for Discontinuities

This test consists of looking for impedances attached to the communication line that are different from the characteristic impedance of the line, Z_0 (93Ω). This is done by sending a wave front (leading edge of square wave) down the line and looking for energy that is reflected by any point that differs from the characteristic impedance.

The "B gate" out pulse is the square wave that is applied to the coax; it travels down the line at about 80% of the speed of light, depending upon the isolation material used in the cable. If no impedance impairment is present on the line, the wave front travels down the line until the termination is reached, and all the energy contained in the wave front is absorbed in the termination.

Z_0 of the cables and the termination can vary, in which case not all the energy contained in the wavefront is absorbed. The energy not absorbed is reflected back toward the sending end. Viewing the sending end with the oscilloscope allows display of both the transmitted wave (incident wave) and the reflected wave. Figure 4-10 shows examples of possible reflections for different terminations.




Figure 4-10. Incident and Reflected Waves

The reflected wave is delayed by the time it takes for the incident wave to travel to and return from the termination. The delay is called "propagation delay" and is expressed as a percentage of the speed electronic waves travel in a specific type of cable (usually 60-80%) as compared with the speed they travel in open air—the speed of light (100%).

If the propagation delay of the cable is known, the scope can be calibrated to meters or feet per division, and the distance to a mismatch—shorts, opens, etc.—in the cable can thus be determined:

The speed of light is 300,000 km/sec, or 30 cm/nanosec, or 0.984 ft/nanosec. Propagation delay in a coax cable is about 1.25 nanosec/ft. The DC resistance is $44\Omega/1000$ ft.

4.4.4.2 Setup and Test Procedures

Parts

X1 probe (or short piece of coax with BNC connector on each end):

1 resistor equal to Z_0 of cable (93 ohms)

1 BNC-T (PN 1650789)

1 probe tip to BNC adapter PN 453199 (not needed if short coax is used as input from T-connector to scope input)

Scope Hookup: Make the connections shown in Figure 4-11.

Initial Scope Settings

Mode:	ch 1
Volt/div:	0.2 V (initial)
Input:	ac
A triggering level:	fully counterclockwise
A sweep length:	full
Horiz. display:	delayed sweep B
B sweep mode:	B starts after delay time
A sweep mode:	auto trigger
Delay time multiplier dial:	fully clockwise (9.5)
A and B time division initial setting:	
A:	10 μ sec
B:	0.1 μ sec (pull to unlock)




Figure 4-11. Scope Setup

Test Procedures

1. Consider the cable length:

- Up to 100 m (300 ft)—use the initial scope setup.
- Up to 1500 m (5000 ft)—use B time division up to 2.0 μsec .
- Longer than 1500 m (5000 ft)—measure in segments not exceeding 1500 m.
- Shorter than 20 m (60 ft)—use the X10 time base. This distance represents only about two horizontal divisions to the center of the screen. Switch to X10 magnifier. B time can now be set to .2 or .5, and speed can be considered 0.02 and 0.05.

2. Use the following conversion table to determine distances.

B-sweep setting (μsec)

B-sweep setting (μsec)	(Meter/Div)	(Feet/Div)
0.1	12.2	40
0.2	24.4	80
0.5	61	200
1.0	122	400
2.0	244	800

3. Use the following measurement techniques and become familiar with Figure 4-13 to gain understanding of what you may see displayed:

- Measure from the point where the reflected pulse starts to change (Figure 4-12). (Rise time degrades with cable-length increase.)

- Lower the volts/div, and use Vertical Position knob to position waveform on screen.
- Identify the end of a cable by opening and shorting the cable end.
- After finding mismatches, measure as closely as possible to the fault. Measuring from both ends of the cable enhances fault location; because of cable loss, major faults at long distances can appear as minor faults close to the test point.





Figure 4-12. Measurement Points




A

This waveform is an indication of a good coax cable — 190 m (624 ft). A gradual sloping and overshoot of rise time is normal.

Impedance Z_0 Checking

This 93-ohm cable is terminated at the end with a 93-ohm resistor. The straight line after 7.8 divisions proves that this cable's characteristic impedance is close to 93 ohms.




B

101 m (332 ft) of good coax cable, 8.3 div long. (This is an effective method to measure the length of the cable.)

$$8.3 \times 40 = 332 \text{ ft} \quad \text{or}$$

$$8.3 \times 12.2 = 101 \text{ meter}$$

Rising slope is normal.



C


The same cable as A now shorted at end to show downward reflection and length.

Length of sweep is 7.8 divisions (see arrows).

$$B \text{ setting} = 0.2 \mu\text{sec or } 80 \text{ ft/div}$$

$$7.8 \times 80 = 190 \text{ m (624 ft)}$$

Figure 4-13 (Part 1 of 3). Display Examples




D

Same as C, now with higher vertical gain (0.2V/div).

Arrow points to start. At 1.3 and 2.5 divisions from start, very small mismatches from BNC connection occur. These are at 9.78 m (32 ft), 18.6 m (61 ft), 31.7 m (104 ft) and 61.0 m (200 ft) from start.

A reflection deviation of greater than 10% of the incident wave, usually indicates an undesirable impedance change and should be corrected.




E

This 731.5 m (2400 ft) cable has a 100-ohm short to shield at the 121.9 m (400 ft) point (see arrow).

Total cable length
 $6 \times 400 = 2400 \text{ ft (731.5 m)}$

Fault point
 $1 \times 400 = 400 \text{ ft (121.9 m)}$



F

Improper setup of scope.


Multiple reflections. 26 m (100 ft) of good cable with open end.

Improper scope display due to wrong vertical gain setting, .5V/div.

Only the first reflection is significant and should be magnified.


See G.

Figure 4-13 (Part 2 of 3). Display Examples



G

Same as F now with scope set to higher vertical gain, 0.2V.




H

Same as G but magnified with X10.

This is the first reflection section of picture G.

A smooth cable 5.2 divisions long (as opposed to 2.6 div on A) with overshoot.

$$5.2 \times 20 \text{ ft (6.2 m)} = 104 \text{ ft (31.7 m)}$$



J

Improper Setup of Scope.

Multiple reflections due to wrong, slow B group setting.

Same 28 m (100 ft) as in F, G, and H.

Only the first reflection is significant; the normal, multiple reflections of the test pulse should be cancelled out on the display by using a B time that will display the first reflection only, using the whole screen or as great a portion of the screen as possible. See H.

Figure 4-13 (Part 3 of 3). Display Examples

Chapter 5. Reference Data

5.1 INTRODUCTION

This chapter provides the following information as an aid to maintenance:

- Command summary
- Order summary
- Various codes
- Sequence/response diagrams
- Status and sense byte descriptions
- Switches and controls

5.2 CONTROL UNIT COMMAND SUMMARY

See Figure 5-1 for control unit command codes.

Command	3274 Model 51C	
	EBCDIC Hex	Graphic
Copy ¹	F7	7
Erase All Unprotected	6F	?
Erase/Write	F5	5
Erase/Write Alternate ²	7E	=
Read Buffer	F2	2
Read Modified	F6	6
Read Modified All ³	6E	:
Write	F1	1
No Operation	NA	NA
Select	NA	NA
Sense	NA	NA

¹ Applicable to 3271, 3274 Model 51C (BSC).

² Applicable to 3274.

³ Applicable to 3274 Models 51C and 52C (SNA/SDLC).

Figure 5-1. Command Codes

5.2.1 Write

The Write command:

1. Transfers the contents of the addressed device buffer to the control unit (CU) storage buffer.
2. Performs the operation specified by the write control character (WCC).
3. Enters data in any portion of the CU storage buffer (without erasing or modifying portions of the buffer in which a change is not required).

4. Allows execution of various order sequences within the data stream.
5. Transfers the updated CU buffer to the device buffer.

5.2.2 Erase/Write

The Erase/Write command:

1. Clears the CU buffer to nulls.
2. Performs operations specified by the WCC.
3. Stores new data characters provided by the program.
4. Allows execution of various order sequences within the data stream.
5. Transfers the updated CU buffer to the device buffer.

5.2.3 Erase/Write Alternate

1. Switches the device to alternate character capacity.
2. Performs normal erase/write operation.

5.2.4 Erase All Unprotected

The Erase All Unprotected command:

1. Clears all unprotected alphameric characters to nulls, resets modified data tag (MDT) bits of all unprotected fields to 0, restores the keyboard, resets the attention identifier (AID), and repositions the cursor to the first character location in the first unprotected field in the buffer.
2. Is performed at the device and has no data stream.

5.2.5 Read Buffer

The Read Buffer command:

1. Transfers the contents of the addressed device buffer to the CU buffer.
2. Data stream transferred to the host includes the AID character, the cursor address, and the contents of all device buffer locations (both protected and unprotected). These include attribute and alphameric characters (including nulls), starting at a specific location and continuing to the end of the buffer, unless the channel byte count goes to zero before the last location is reached.

5.2.6 Read Modified

Receipt of a Read Modified command (or a Poll when an AID is pending) generates one of three different data streams, depending on the AID code present. Their descriptions follow.

5.2.6.1 Read Modified Read

The Read Modified Read command:

1. Transfers the contents of the addressed device buffer to the CU buffer.
2. Data stream transferred to the host includes the AID character, the cursor address, and all fields in which the MDT bit has been set. The data stream for each modified field contains the SBA order, the buffer address of the attribute character plus 1, and all alphameric characters (with nulls suppressed).
3. The command is issued by the program or as a result of an ENTER, PF key, selector-pen attention, or operator identification card read-in operation.

5.2.6.2 Short Read Read

The Short Read Read command:

1. Permits the display operator to communicate with the host program without sending modified data characters. This action is initiated when the display operator presses CLEAR, CANCEL, or a PA key.
2. A read-modified operation is performed, but only the unique AID character, to identify the key pressed, is sent to the host program.

5.2.6.3 Test Request Read (Model 51C, BSC)

1. A read-modified operation is performed if the TEST REQ or the SYS REQ (BSC only) key has been pressed at a device.
2. A Test Request Read heading is generated by the control unit. The sequence is: SOH % / STX.
3. If the device buffer is unformatted, all alphameric data in the buffer is included in the data stream (nulls are suppressed). If the device buffer is formatted, only fields that have the MDT bit set will be included in the data stream following the Test Request Read heading.

5.2.7 Read Modified All (3274 SNA Only)

1. The Read Modified All command is sent only by the primary logical unit (host application).
2. A read-modified operation is performed, and all modified fields in the selected device are sent to the host, regardless of the AID byte generated.

5.2.8 Copy (3274 Model 51C, BSC)

The Copy command:

1. Transfers the contents of one device buffer to another device buffer via the CU buffer.
2. The device whose contents are transferred is called the *from* device.
3. The receiving device is called the *to* device.
4. The *to* device is selected in the addressing sequence.

5. Two bytes always follow the command byte: (1) the copy control character (CCC) and (2) the address of the *from* device.
6. The CCC performs a function similar to that of the WCC in the Write and Erase/Write commands.
7. The *from* device buffer can be *locked* (incapable of being copied) by storing a protected alphameric attribute character in buffer address 0.
8. The addressed device (that is, the *to* device) may also be specified as the *from* device. This permits troubleshooting the Copy command with a single device.

5.3 CONTROL UNIT ORDER SUMMARY

See Figure 5-2 for control unit order codes.

5.3.1 Set Buffer Address (SBA)

The Set Buffer Address (SBA) order loads data, starting at the address immediately following the SBA character. The format is: SBA, address, address.

5.3.2 Start Field (SF)

The Start Field (SF) order specifies the next character as an attribute character. The format is: SF, attribute character.

5.3.3 Insert Cursor (IC)

The Insert Cursor (IC) order changes the address in the CU buffer and thus repositions the cursor on the display screen. Because the CU buffer address is not advanced when the IC order is loaded in the CU buffer, the next byte is stored at the cursor address. The format is: IC.

5.3.4 Repeat to Address (RA)

The Repeat to Address (RA) order loads a single character repeatedly, starting at the current CU buffer address and continuing to, *but not including*, the address specified in the order sequence. The cursor is not affected. The format is: RA, address, address, character.

5.3.5 Erase Unprotected to Address (EUA)

The Erase Unprotected to Address (EUA) order deletes all unprotected-field characters beginning with the character at the current address to, *but not including*, the character at the address specified in the order sequence. If the address specified in the order sequence equals the *current address*, wraparound occurs, and all unprotected characters are deleted. The attribute characters defining the unprotected fields are not deleted. The format is: EUA, address, address.

Order Sequence	Byte 1 (Order Code)		Byte 2	Byte 3	Byte 4
	EBCDIC (Hex)	ASCII (Hex)			
Start Field (SF)	1D	1D	Attribute Character ¹		
Set Buffer Address (SBA)	11	11	1st Address Byte	2nd Address Byte	
Insert Cursor (IC)	13	13			
Program Tab (PT)	05	09			
Repeat to Address (RA)	3C	14	1st Address Byte	2nd Address Byte	Character to Be Repeated ²
Erase Unprotected to Address (EUA)	12	12	1st Address Byte	2nd Address Byte	

¹ Figure 5-17 shows coding of this byte.

² Figures 5-3, 5-4, and 5-12 show coding of this byte.

Figure 5-2. Buffer Control Orders and Order Codes

5.3.6 Program Tab (PT)

The Program Tab (PT) order advances the CU buffer address to that of the character position immediately following the next attribute character that defines an unprotected field. The cursor is unaffected, and no wraparound occurs. The search begins at the current buffer address. The final result depends on one of three conditions:

1. When PT immediately follows a data character within an unprotected field, all remaining characters within that field are replaced by nulls.
2. When PT immediately follows a WCC or an order sequence, no nulls are inserted.
3. When the current buffer address contains an attribute character that defines an unprotected field, the CU buffer address is simply advanced one character location.

The format is: PT.

5.3.7 New Line (NL)

When included in the data stream addressed to a printer, the New Line (NL) order initiates a carriage return/line feed (CR/LF) operation by the printer. That is, the platen is advanced one line and the print mechanism is returned to the first print position of the new line. If this order is included in the data stream addressed to a display, the NL order is displayed as the number 5 (space 5 for Katakana), but does not cause action in the CU or display. In any case,

it is stored in the CU buffer as the number 5 (space 5 for Katakana).

The format is: NL.

5.3.8 End of Message (EM)

The End of Message (EM) order must be included at the end of a message addressed to a printer to notify it when to stop printing. If the EM order is not included at the end of the printer message, the printer will print out the contents of the complete printer buffer (either 480 or 1920 characters). If this order is included in the data stream addressed to a display, the EM order is displayed as the number 9 (space 9 for Katakana), but does not cause action in the CU or display. In any case, it is stored in the CU buffer as the number 9 (space 9 for Katakana).

The format is: EM.

5.3.9 Duplicate (DUP)

The Duplicate (DUP) order informs the program that the DUP key was pressed by the display station operator. Its actual function is determined by the CPU program. The DUP order is displayed as an asterisk (*) with overscore. It is stored in the CU buffer, but does not cause action in the CU.

The format is: DUP.

5.3.10 Field Mark (FM)

The Field Mark (FM) order informs the CPU program that the FM key was pressed by the display operator. It indicates the end of a field to the program. The FM order is displayed as a semicolon (;) with overscore. It is stored in the CU buffer, but does not cause action in the CU.

The format is: FM.

5.3.11 Forms Feed (FF) (3287, 3288, and 3289 Printers)

Valid Forms Feed (FF) orders are executed by the 3287, 3288, and 3289 Printers during printouts, both with and without a line-length format specified. (The FF order is described in the section "Page Length Control/VFC Operations," in the *IBM 3270 Information Display System Component Description*, GA27-2749-7.) When a valid FF order is encountered in the first print position of a line, with the Page Length Control/VFC feature installed, the print form indexes to a predetermined print line on the next form.

5.3.12 Suppress Index (SI) (3288)

The 3288 Printer, when equipped with the Text Print special feature, honors the Suppress Index (SI) order code.

The SI order causes printing of two or more lines of data at the same paper position. The SI order is transferred as part of the data stream from the application program and is stored in the printer buffer as data.

5.3.13 Carriage Return (CR) (3287 with 3274 Attachment and 3289 Printers)

When the Carriage Return (CR) order code is found in the data stream, the next print position will be the leftmost character position on the current print line. CR orders are not executed when they occur in nonprint fields, and when the printer format bits in the WCC indicate a line length (40, 64, or 80 characters). In both cases, the CR order is printed as a space character.

5.4 I/O INTERFACE CODES

The I/O interface codes for the 3274 Control Unit are illustrated in Figures 5-3 through 5-12. For information concerning Buffer Address I/O Interface Codes, refer to *3270 Information Display System Reference Summary*, GX20-1878.

		00				01				10				11				Bits 0,1
		00	01	10	11	00	01	10	11	00	01	10	11	00	01	10	11	Bits 2,3
		0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	Hex 0
0000	0	NUL			SP	&	-						()	AA	0		
0001	1					/		a	j	-			A	J		1		
0010	2							b	k	s			B	K	S	2		
0011	3							c	l	t			C	L	T	3		
0100	4							d	m	u			D	M	U	4		
0101	5		NL					e	n	v			E	N	V	5		
0110	6							f	o	w			F	O	W	6		
0111	7							g	p	x			G	P	X	7		
1000	8							h	q	y			H	Q	Y	8		
1001	9		EM					i	r	z			I	R	Z	9		
1010	A				ç	!	6A	:										
1011	B				.	\$.	#										
1100	C	FF	DUP		<	*	%	@										
1101	D				()	-	'										
1110	E		FM		+	;	>	=										
1111	F					⌋	?	"										

Notes:

- Character code assignments other than those shown within all outlined areas of this chart are undefined. If an undefined character code is programmed, the character that will be displayed is not specified. The character displayed by the 3277 for a given undefined character code may be different for other devices. IBM reserves the right to change at any time the character displayed for an undefined character code.
- Lowercase alphabetic characters (shown within the dotted outlined area) are converted to uppercase by the display station or printer and displayed or printed as uppercase characters, unless the terminal has Dual Case capability.

Legend:




-  = Stored as a lowercase symbol. Displayed on Mono Case display only. Blank on Dual Case display. Cannot be entered from keyboard.
-  or  = Stored as Hex code shown. Nondisplayed on Mono and Dual Case displays.

Figure 5-3. United States EBCDIC I/O Interface Code for 3274 Control Unit and Attached 3277 Display Stations

		00				01				10				11				Bits 0,1
Hex 1		00	01	10	11	00	01	10	11	00	01	10	11	00	01	10	11	Bits 2,3
Bits 4567		0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	Hex 0
0000	0	NUL				SP	&	-					{	}	\	0		
0001	1						/			a	j	~		A	J		1	
0010	2									b	k	s		B	K	S	2	
0011	3									c	l	t		C	L	T	3	
0100	4									d	m	u		D	M	U	4	
0101	5		NL							e	n	v		E	N	V	5	
0110	6									f	o	w		F	O	W	6	
0111	7									g	p	x		G	P	X	7	
1000	8									h	q	y		H	Q	Y	8	
1001	9		EM							i	r	z		I	R	Z	9	
1010	A					¢	!		:									
1011	B					.	\$,	#									
1100	C	FF	DUP			<	*	%	@									
1101	D	CR				()	_	'									
1110	E		FM			+	;	>	=									
1111	F						⌋	?	"				SI					

Notes:

1. Character code assignments other than those shown within all outlined areas of this chart are undefined. If an undefined character code is programmed, the character that will be displayed or printed is a hyphen. The character displayed by the 3276 or 3278 for a given undefined character code may be different for other devices. IBM reserves the right to change at any time the character displayed for an undefined character code.
2. NL (hex 15), EM (hex 19), FF (hex 0C), and NUL (hex 00) are not displayed or printed. The DUP (hex 1C) and FM (hex 1E) control characters on Dual Case featured terminals are displayed as * and ; respectively, and are printed as * and ;.
3. DUP (hex 1C) and FM (hex 1E) control characters on Mono Case terminals are displayed as * and ; respectively, and are printed as * and ;.

Figure 5-4. United States EBCDIC I/O Interface Code for 3274 Control Unit and Attached 3278, 3279, 3287, and 3289 Terminals

		Hex 1								Bits
		000	001	010	011	100	101	110	111	← 7, 6, 5
Bits	4321	0	1	2	3	4	5	6	7	← Hex 0
0000	0	NUL		SP	0	@	P	·	p	
0001	1			!	1	A	Q	a	q	
0010	2			"	2	B	R	b	r	
0011	3			#	3	C	S	c	s	
0100	4			\$	4	D	T	d	t	
0101	5		NL	%	5	E	U	e	u	
0110	6			&	6	F	V	f	v	
0111	7			'	7	G	W	g	w	
1000	8			(8	H	X	h	x	
1001	9		EM)	9	I	Y	i	y	
1010	A			*	:	J	Z	j	z	
1011	B			+	;	K	[k	}	
1100	C	FF	DUP	,	<	L	\	l		
1101	D	CR		-	=	M]	m	}	
1110	E		FM	.	>	N	^	n	~	
1111	F			/	?	O	_	o		

Notes:

1. Character code assignments other than those shown within all outlined areas of this chart are undefined. If an undefined character code is programmed, the character that will be displayed is not specified. The character displayed by the 3277 or 3275 for a given undefined character code may be different for other devices. IBM reserves the right to change at any time the character displayed for an undefined character code.
2. Lowercase alphabetic characters (shown within the dotted outlined area) are converted to uppercase by the display station or printer and displayed or printed as uppercase characters, unless the terminal has Dual Case capability.

Figure 5-5. United States ASCII I/O Interface Code for 3274 Control Unit and Attached 3278, 3279, 3287, and 3289 Terminals

*	1	Printout Format	Start Print	Sound Alarm	Kbd Restore	Reset MDT Bits	
0	1	2	3	4	5	6	7

*Determined by the configuration of bits 2-7. See Figure 5-12.

Figure 5-6. Format of Write Control Character (WCC) Byte

Bit	Explanation
0	Determined by the contents of bits 2-7 as shown in Figure 5-12.
1	Reserved (must be a 1).
2,3	Define the printout format, as follows: = 00 – The NL, EM, and CR* orders in the data stream determine print line length. Provides a 132-print position line when the orders are not present. = 01 – Specifies 40-character print line. = 10 – Specifies 64-character print line. = 11 – Specifies 80-character print line.
4	Start Printer bit. When set to 1, initiates a printout operation at completion of the write operation.
5	The Sound Alarm bit. When set to 1, sounds the audible alarm at the selected device at the end of the operation if that device has an audible alarm.
6	The Keyboard Restore bit. When set to 1, restores operation of the keyboard by resetting the INPUT INHIBITED indicator on 3275 and 3277 displays, and the System Lock or Wait symbol on 3276 and 3278 displays. It also resets the AID byte at the termination of the I/O command.
7	Reset MDT bits. When set to 1, all MDT bits in the selected devices' existing buffer data are reset before any data is written or orders are executed.

*The CR order is applicable to the 3287 and 3289 Printers only.

Figure 5-7. Function of Write Control Character (WCC) Bits

Attribute	X	X	U/P	A/N	I/SPD	0	MDT	
EBCDIC Bits	0	1	2	3	4	5	6	7

EBCDIC

- Bit 0,1 = XX Determined by contents of bits 2-7.
- Bit 2 = 0 Unprotected data.
- Bit 2 = 1 Protected data – Autolock.
- Bit 2,3 = 1,1 Autoskip.
- Bit 3 = 0 Alphameric data.
- Bit 3 = 1 Numeric data – Autoshift
- Bit 4,5 = 0,0 Normal Intensity/Nondetectable.
- Bit 4,5 = 0,1 Normal Intensity/Selector Pen Detectable.
- Bit 4,5 = 1,0 High Intensity/Selector Pen Detectable.
- Bit 4,5 = 1,1 Nondisplay/Nonprint/Nondetectable.
- Bit 6 = 0 Reserved. Must be zero.
- Bit 7 = 0 Field data not tagged as modified.
- Bit 7 = 1 Field data tagged as modified.

ATTRIBUTE						Bits		Hex	Graphic Display
Prot	A/N	MDT ON	High Intens	Sel Pen Det	Non Disp PRT	23	4567		
U						00	0000	40	E
U		Y				00	0001	C1	
U				Y		00	0100	C4	
U		Y		Y		00	0101	C5	
U			H	Y		00	1000	C8	E
U		Y	H	Y		00	1001	C9	
U			-	-	Y	00	1100	4C	
U		Y	-	-	Y	00	1101	4D	
U	N					01	0000	50	P
U	N	Y				01	0001	D1	
U	N			Y		01	0100	D4	
U	N	Y		Y		01	0101	D5	
U	N		H	Y		01	1000	D8	P
U	N	Y	H	Y		01	1001	D9	
U	N		-	-	Y	01	1100	5C	
U	N	Y	-	-	Y	01	1101	5D	
P						10	0000	60	C
P		Y				10	0001	61	
P				Y		10	0100	E4	
P		Y		Y		10	0101	E5	
P			H	Y		10	1000	E8	E
P		Y	H	Y		10	1001	E9	
P			-	-		10	1100	6C	
P		Y	-	-	Y	10	1101	6D	
P	S					11	0000	F0	X
P	S	Y				11	0001	F1	
P	S			Y		11	0100	F4	
P	S	Y		Y		11	0101	F5	
P	S		H	Y		11	1000	F8	E
P	S	Y	H	Y		11	1001	F9	
P	S		-	-	Y	11	1100	7C	
P	S	Y	-	-	Y	11	1101	7D	

H = High
 N = Numeric
 P = Protected
 S = Special
 U = Unprotected
 Y = Yes

Figure 5-8. Attribute Character Bit Assignments for 3278s

To examine data for proper attributes and the setting or resetting of modified data tags (MDTs), use the following procedure:

1. Place the CE jumper, as shown in Figure 5-9, on the A-gate top-card connector that connects card F2 to card G2 on the A-gate with three base cards (Figure 5-9), or card F4 to card G4 on the A-gate with two base cards (Figure 5-10).
2. Attribute and nondisplay fields will now be displayed and can be compared with the graphic display in this figure.
3. Remove the jumper when completed.




Figure 5-9. 3278 Top-Card Connector CE Jumper (Three Base Cards)




Figure 5-10. 3278 Top-Card Connector CE Jumper (Two Base Cards)

X	1	U/P	A/N	D/SPD	Reserved	MDT	
0	1	2	3	4	5	6	7

EBCDIC Bit	Field Description
0	- Value determined by contents of bits 2–7.
1	- Must be a 1.
2	- 0 = Unprotected - 1 = Protected
3	- 0 = Alphameric 1 = Numeric (causes automatic upshift of data entry keyboard)
	Note: Bits 2 and 3 equal to 11 causes an automatic skip. See text.
4 & 5	- 00 = Display/not selector-pen-detectable 01 = Display/selector-pen-detectable 10 = Intensified display/selector-pen-detectable 11 = Nondisplay, noprint, nondetectable
6	- Reserved. Must always be 0.
7	- Modified Data Tag (MDT); identifies modified fields during Read Modified command operations. 0 = Field has not been modified 1 = Field has been modified by the operator. Can also be set by program in data stream.

Notes:

1. Bits 0 and 1 are not decoded when received by the 3270. When characters are being transferred to the CPU, bit 1 is a 1 and bit 0 is set, depending upon the character being transferred. All attribute characters are part of the defined character set. The default option (bits 2 through 7 all set to 0) results in an unprotected, alphameric, displayed, nondetectable field.
2. To examine data for proper attributes and the setting or resetting of modified data tags (MDTs), use the following procedure:
 - a. Jumper J2M13 or H2D07 to Gnd (D08). 3277s with APL Text should also jumper K2B07 to Gnd (attribute byte of "6D" will not be displayed).
 - b. Attribute and nondisplay fields will now be displayed and can be compared with Figure 5-12.
 - c. Remove the jumpers when completed.

Figure 5-11. Attribute Character Bit Assignments for 3277s

Bits 2-7	Graphic	EBCDIC	ASCII	Bits 2-7	Graphic	EBCDIC	ASCII
00 0000	SP	40	20	10 0000	-	60	2D
00 0001	A	C1	41	10 0001	/	61	2F
00 0010	B	C2	42	10 0010	S	E2	53
00 0011	C	C3	43	10 0011	T	E3	54
00 0100	D	C4	44	10 0100	U	E4	55
00 0101	E	C5	45	10 0101	V	E5	56
00 0110	F	C6	46	10 0110	W	E6	57
00 0111	G	C7	47	10 0111	X	E7	58
00 1000	H	C8	48	10 1000	Y	E8	59
00 1001	I	C9	49	10 1001	Z	E9	5A
00 1010	¢, [4A	5B	10 1010	¡ (EBCDIC)	6A	C
00 1011	.	4B	2E	10 1011	,	6B	2C
00 1100	<	4C	3C	10 1100	%	6C	25
00 1101	(4D	28	10 1101	-	6D	5F
00 1110	+	4E	2B	10 1110	>	6E	3E
00 1111	!, !	4F	21	10 1111	?	6F	3F
01 0000	&	50	26	11 0000	0	F0	30
01 0001	J	D1	4A	11 0001	1	F1	31
01 0010	K	D2	4B	11 0010	2	F2	32
01 0011	L	D3	4C	11 0011	3	F3	33
01 0100	M	D4	4D	11 0100	4	F4	34
01 0101	N	D5	4E	11 0101	5	F5	35
01 0110	O	D6	4F	11 0110	6	F6	36
01 0111	P	D7	50	11 0111	7	F7	37
01 1000	Q	D8	51	11 1000	8	F8	38
01 1001	R	D9	52	11 1001	9	F9	39
01 1010	!,]	5A	5D	11 1010	:	7A	3A
01 1011	\$	5B	24	11 1011	#	7B	23
01 1100	*	5C	2A	11 1100	@	7C	40
01 1101)	5D	29	11 1101	'	7D	27
01 1110	;	5E	3B	11 1110	=	7E	3D
01 1111	¬, ^	5F	5E	11 1111	"	7F	22

Note: The following characters are used as attribute, AID, write control (WCC), copy control (CCC), CU and device address, and buffer address. They are also used as status and sense, except by the 3274 when operating in BSC. When any character is received by the CU, only the low-order 6 bits are used. When any of these characters is transmitted to the program, the CU assigns the appropriate EBCDIC code. If transmission is in ASCII, the CU translates the EBCDIC code to ASCII code prior to transmission.

For example, to use this table to determine the hex code transmitted for an attribute character, first determine the values of bits 2-7. Select this bit configuration in the table under "Bits 2-7". The hex code that will be transmitted (either in EBCDIC or ASCII) is to the right of the bit configuration.


Use this table also to determine equivalent EBCDIC and ASCII hex codes and their associated graphic characters.

Graphic characters for the United States I/O interface codes are shown. If a World Trade I/O interface code is used, refer to the *IBM 3270 Information Display System: Character Set Reference* manual, GA27-2837, for possible graphic character differences.

Figure 5-12. Control Character I/O Codes

5.5 EXAMINING 3279 ATTRIBUTES AND MODIFIED DATA TAGS

To examine data in the 3279 refresh buffer (not the ECS buffer) for proper attributes and the setting or resetting of modified data tags (MDTs), use the following procedure:

1. Place the CE jumper as shown in Figure 5-13.
2. Position the cursor at the location where the attribute is to be displayed.
3. Place the Normal/Test switch in the Test position. Nulls will display as  and attributes are blank. Note that base white and red change to red and white, respectively.
4. Press CONTROL D. The character, or attribute, at the cursor position is copied into the first position of the operator information area and the cursor advances.
5. Refer to Figure 5-14 to determine if the attributes are being correctly interpreted by the hardware.





Figure 5-13. 3279 Top-Card Connector CE Jumper

0	1	2	3	4	5	6	7
1	1	Protected	Alpha-numeric			Reserved	Modified Data Tag
2	4	5	Color of Field	Sel Pen Detectable			
0	0	0	GREEN	NO			
1	0	0	BLUE	NO			
0	0	1	GREEN	YES			
1	0	1	BLUE	YES			
0	1	0	RED	YES			
1	1	0	WHITE	YES			
0	1	1	Non Display	NO			
1	1	1	Non Display	NO			

Figure 5-14. 3279 Base Field Attributes

5.6 SEQUENCE/RESPONSE DIAGRAMS, BSC

Figures 5-15 through 5-20 provide the sequences and responses that occur during online BSC operation of the 3274 Models 51C and 52C.



Notes:

- 1** A status message response is issued to a General or Specific Poll if (1) the 3274 has pending status (General Poll ignores Device Busy and device "unavailable" and, if the 3274 continues polling of next device), or (2) if error status develops during execution of the poll.
- 2** A Test Request Message response is issued to a General or Specific Poll if a TEST REQ key is pressed at the keyboard of a polled 3275 or 3277, or if a SYS REQ key is pressed at a 3278 or 3279 attached to a 3274.
- 3** This address is included only in the first block of a blocked text message.
- 4** The text portion of this message is the result of either a read-modified or short-read operation by the 3274.
- 5** The text portion of this message is the result of a Read Partition (Query) structured field function.

Legend:

(Interrupt) = TCU-generated interrupt.

*Response to General Poll or Specific Poll only (not program generated Read Modified command)

Figure 5-15. 3274 Message Response to Polling or Read Modified Command




Figure 5-16 (Part 1 of 2). General Poll and Specific Poll, Sequence/Response Diagram

Notes:

- 1** The 3274 will fail to respond to the addressing or polling sequence, causing a TCU timeout, for any of the following reasons:
 - The 3274 is "unavailable" (has power off, is "offline", or is not attached).
 - Any character in the polling sequence is invalid.
 - The characters in the polling sequence are out of order.
 - The polling sequence is incomplete (less than seven characters).
 - The 3274 address is incorrect in the write data stream.
 - The addressed 3274 was left selected from the previous transmission.
- 2** There is no I/O pending nor pending status. For General Poll, the CU sends EOT only after polling all devices.
- 3** The device response is a function of the kind of device and its status. Types of responses include: Text, Status, and Test Request messages.

3274: For General Poll, the search for a response starts at some random device address and continues sequentially (as long as ACKs are received in response to text transmissions) until all devices are given the opportunity to respond.
- 4** Upon detection of an internal parity check or a cursor check, the 3274 (1) substitutes the SUB character for the character in error, (2) records Data Check status, and (3) transmits an ENQ in place of ETX (or ETB) and BCC at the end of the text block. The general poll process is stopped.
- 5** Mandatory program response to a text block terminated in ENQ.
- 6** Terminates the operation. The nature of the error (parity or cursor check) does not warrant a retry. This response indicates that status and sense information is stored and that internal 3271/device polling is stopped.
- 7** ETB is used to frame each block of a blocked text message, except the last block. ETX is used to frame the last block of a blocked text message.
- 8** BCC error has been detected. The program issues NAK to cause the 3274 to repeat its last transmission.
- 9** Response issued by the program to terminate the operation if the TCU is unsuccessful in receiving a valid BCC following "n" attempts by the 3274 to transmit the message. This response does not cause the 3274 to reset its sense/status information. Therefore, the same status message will be transmitted if a Specific Poll is immediately issued to the same device.
- 10** This transmission must be a write or control-type command sequence. A read-type command would violate BSC standards on Limited Conversational mode.

3274: For General Poll, this transmission stops the polling operation. The General Poll must be reinitiated to ensure receipt of all pending device messages.
- 11** Positive acknowledgment. The text block has been successfully received by the TCU. The program issues ACK 1 in response to the first and all odd-numbered text blocks and issues ACK 0 in response to the second and all even-numbered text blocks.
- 12** Normal termination of a Specific Poll.

3274: Normal termination of a General Poll.
- 13** The second and all succeeding text blocks are framed as the first except they do not include the 3274/device address sequence.
- 14** RVI to terminate polling sequence.
- 15** Termination of polling sequence on receipt of RVI.


LEGEND:

(CC) = Chain Command (CC) Flag in CCW is set to 1.

(Interrupt) = TCU-generated interrupt (CE = Channel End, DE = Device End, UE = Unit Exception, UC = Unit Check).

*Only the critical framing characters (sync pattern and pad) are shown. All other framing characters are also hardware-generated as required. See *SL General Information - Binary Synchronous Communications, GA27-3004*, for a complete description.

Figure 5-16 (Part 2 of 2). General Poll and Specific Poll, Sequence/Response Diagram



*Only the critical framing characters (sync pattern and pad) are shown. All other framing characters are also hardware-generated as required. See *SL General Information – Binary Synchronous Communications, GA27-3004*, for a complete description.

Figure 5-17 (Part 1 of 2). Selection Addressing, Sequence/Response Diagram

Notes:

- 1** The 3274 will fail to respond to the addressing or polling sequence causing a TCU timeout, for any of the following reasons:
 - The 3274 is "unavailable" (has power off, is "offline", or is not attached).
 - Any character in the polling sequence is invalid.
 - The characters in the polling sequence are out of order.
 - The polling sequence is incomplete (less than seven characters).
 - The 3274 address is incorrect in the write data stream.
 - The addressed 3274 was left selected from the previous transmission.
- 2** 3274: The addressed device has pending status (excluding Device, Busy or Device End).
- 3** The addressed 3274 device, including the 3284-3 Printer is busy. No S/S information is stored. An RVI response takes precedence over a WACK response.
- 4** The address has been successfully received, and no status is pending.
- 5** Termination of attempted addressing sequence:

3274: Availability of valid status and sense information cannot be ensured unless a Specific Poll is issued to the responding device as the next addressing sequence issued to this 3274.
- 6** Termination of attempted addressing sequence.

LEGEND:

(CC) = Chain Command (CC) Flag in CCW is set to 1.

(Interrupt) = TCU-Generated interrupt (CE = Channel End, DE = Device End, and UC = Unit Check)

Figure 5-17 (Part 2 of 2). Selection Addressing, Sequence/Response Diagram




Figure 5-18 (Part 1 of 2). Write-Type and Control-Type Commands, Sequence/Response Diagram

Notes:

- 1** No text is transmitted on an EAU command transmission.
- 2** Command transmission was not successfully received because of invalid framing (STX missing). Causes a timeout at TCU.
- 3** 3274: The control unit is unable to perform the operation indicated in the command transmission because of a busy/unavailable/not ready device.
 - a. receipt of an illegal command/order sequence,
 - b. failure to decode a valid command,
 - c. an I/O interface "overrun",
 - d. a parity/cursor check,
 - e. an illegal buffer address, or
 - f. a locked buffer.

In the case of the Copy command: the "from" device is busy or has locked buffer, or CCC is missing.

The EOT response to a command transmission indicates that status information is stored in the control unit. To ensure retrieval of valid status, the program must issue a Specific Poll (addressing the device that was selected when EOT was generated) as the next addressing sequence to this control unit. Successful completion of a Specific Poll addressed to the responding device, a device selection addressed to any other device on the same control unit, or a General Poll addressed to the same control unit, is required to restart the internal control unit device polling operation.
- 4** 3274: If a transmission problem causes both a 3274 detected check condition and a BCC error, the BCC error takes precedence over all other check conditions, and a NAK is transmitted to the TCU.
- 5** 3274: BCC error or missing ETX has been detected. The NAK response requests the program to repeat its last transmission.
- 6** Response issued by the program to terminate the operation if the 3274 is unsuccessful in receiving a valid BCC following "n" attempts by the program to transmit the message.
- 7** If the Start Printer bit is set in the WCC or CCC, a WACK response indicates that the text transmission was successfully received, but that the printer is now busy and an additional chained command cannot be accepted.

If any of the conditions cited in Note 3 prevail, the EOT response takes precedence over the WACK response.
- 8** Normal termination of the operation by the program.
- 9** Command execution has been successfully completed.
- 10** Repeat the operation shown in this figure for the next command sequence.
- 11** Example of a Temporary Text Delay (TTD) sequence.
- 12** Example of terminating an operation using TTD (a forward abort sequence).

Legend:

(CC) = Chain Command (CC) Flag in CCW is set to 1.

(Interrupt) = TCU-generated interruption (CE = Channel End, DE = Device End, UE = Unit Exception, UC = Unit Check).

Figure 5-18 (Part 2 of 2). Write-Type and Control-Type Commands, Sequence/Response Diagram




Figure 5-19 (Part 1 of 2). Read-Type Command, Sequence/Response Diagram

Notes:

- 1** Command transmission was not successfully received because of invalid framing (STX missing). Causes timeout at TCU.
- 2** 3274: The 3274 is unable to perform the operation indicated in the command transmission because of a busy/unavailable/not ready device or a 3274-detected check condition (receipt of an illegal command/order sequence, failure to decode a valid command, or an I/O interface "overrun"). The EOT response to a command transmission indicates that status information is stored in the 3274. To ensure a retrieval of valid status, a Specific Poll must be issued to the device-responding EOT as the next addressing sequence issued to this 3274.
- 3** 3274: If a transmission problem causes both a 3274-detected check condition and a BCC error, the BCC error takes precedence over all other check conditions, and a NAK is transmitted to the TCU.
- 4** Response issued by the program to terminate the operation if the 3274 is unsuccessful in receiving a valid BCC following "n" attempts by the program to transmit the message.
- 5** This address sequence is included only in the first block of a blocked text message.
- 6** ETB is used to frame each block of a blocked text message, except for the last block. ETX is used to frame the last block of a blocked text message.
- 7** Upon detection of an internal parity check, the 3274 automatically substitutes the SUB character for the character in error. If a parity or cursor check is detected, ENQ is transmitted in place of ETX (or ETB) and BCC at the end of the text block and appropriate status and sense information is stored. This is used by the 3274 after transmitting the first block, the transmission cannot be completed because of power's being off at the terminal.
- 8** Mandatory program response to a text block terminated in ENQ.
- 9** Response to terminate the operation. The nature of the error (parity or cursor check) does not warrant a retry. This response indicates that appropriate status and sense information is stored. Retrieval information included in Note 2 applies.
- 10** BCC error has been detected. The program issues NAK to cause the 3274 to repeat its last transmission.
- 11** Positive acknowledgment. The text block has been successfully received by the TCU. The program issues ACK 1 in response to the first and all odd-numbered text blocks and issues ACK 0 in response to the second and all even-numbered text blocks. This response to a text block terminated in ETX turns on the device SYSTEM AVAILABLE indicator.
- 12** The second and all succeeding text blocks are framed as the first except that they do not include the 3274/device address sequence.
- 13** Normal termination of the operation following transmission of the last text block.

LEGEND:

(CC) = Chain Command (CC) Flag in CCW is set to 1.

(Interrupt) = TCU-generated interrupt (CE = Channel End, DE = Device End, UE = Unit Exception, UC = Unit Check).

Figure 5-19 (Part 2 of 2). Read-Type Command, Sequence/Response Diagram

5.7 REMOTE STATUS AND SENSE BYTE DEFINITIONS, BSC

Figures 5-20 through 5-22 provide status and sense byte definitions, responses, conditions, and error recovery procedures for the 3274 Models 51C and 52C.

Bit No.	Bit Definition
	S/S Byte 0:
0	Dependent upon setting of bits 2-7.
1	Always a 1.
2	Reserved.
3	Reserved.
4	<p>Device Busy (DB) – This bit indicates that the addressed device (except the 3278) is busy executing an operation or that a busy detection was previously made by a command or Specific Poll. The device is busy when it is executing an Erase All Unprotected command or a print operation, accepting data from the Operator Identification Card Reader, or performing various keyboard operations (Erase Input, Backtab, and Clear).</p> <p>This bit is set with Operation Check when a Copy command is received which specifies a “busy” device with its “from” address.</p> <p>This bit is set with Unit Specify when a command is addressed to a busy device. This can occur by chaining a command to a Write, Erase/Write, Erase/Write Alternate, or Copy command which started a Printer or by chaining a command to a Specific Poll addressed to a busy device.</p> <p>Note: DB is not returned for the 3278 when executing an Erase All Unprotected command, accepting data from the MSR, or performing Erase Input, Backtab, or Clear keyboard operations.</p>
5	<p>Unit Specify (US) – This bit is set if any S/S bit is set as a result of a device-detected error or if a command is addressed to a busy device.</p>
6	<p>Device End (DE) – This bit indicates that the addressed device has changed from unavailable to available and not ready to ready, or busy to not busy. This bit is included during a Specific or General Poll but is not considered pending status by a Selection Addressing sequence.</p> <p>If a Selection Addressing sequence detects that the addressed device has pending status and also detects one of the above status changes that warrants a Device End, then the Device End bit is set and preserved along with the other pending status, and an RVI response is made.</p>
7	<p>Transmission Check (TC) – Not used by the 3274. TCU transmission.</p>
	S/S Byte 1:
0	Dependent upon setting of bits 2-7.
1	Always a 1.
2	<p>Command Reject (CR) – This bit is set upon receipt of an invalid 3270 command.</p>
3	<p>Intervention Required (IR) – This bit is set if:</p> <ul style="list-style-type: none"> ● A Copy command contains a “from” address in its data stream which specifies an unavailable device. ● A command attempted to start a printer but found it not ready. The printout is suppressed. ● The 3274 receives a Selection Addressing sequence or a Specific Poll sequence for a device which is unavailable or which became not ready during a printout. A General Poll sequence does not respond to the unavailable/not ready indication and proceeds to determine the state of the next device. ● The 3274 receives a command for a device which has been logged as unavailable or not ready.
4	<p>Equipment Check (EC) – This bit indicates a printer character generator or sync check error occurred, the printer became mechanically disabled, or a 3274 detected bad parity from the device.</p>
5	<p>Data Check (DC) – This bit indicates the detection of a parity check in a device buffer or a 3274 operation to a device was unsuccessful (i.e., the device was disabled with DC returned to the host. IR will be returned on subsequent retry by the host).</p>
6	<p>Control Check (CC) – This bit is not used by the 3274.</p>
7	<p>Operation Check (OC) – This bit, when set alone, indicates one of the following:</p> <ul style="list-style-type: none"> ● Receipt of an illegal buffer address or of an incomplete order sequence on a Write, Erase/Write, or Erase/Write Alternate command. ● The device did not receive a CCC or a “from” address on a Copy command. ● Receipt of an invalid command sequence. (ESC is not received in the second data character position of the sequence.) ● This occurs if the internal buffering capability is exceeded. <p>This bit is set with Control Check, Intervention Required, Data Check, Device Busy, or Data Check with Unit Specify to indicate that the errors that set these sense bits were detected while the 3271 was executing an operation with the “from” device during a Copy command. This bit is set with Unit Specify to indicate that the “from” address on a Copy command specified a device with a “locked” buffer (the device data is secure).</p>

Figure 5-20. Remote Status and Sense Byte Definitions, BSC

Device Response	Command	S/S Explanation
RVI	Selection	<p>Outstanding Status – Pending information from a previous operation with the same device. (If the addressed device is busy, WACK is sent to the TCU instead of RVI, and no S/S bit is set.) Note: A Selection Addressing sequence does not recognize a Device End as pending status. If there is no other pending status, it resets this bit and proceeds with the selection. If the addressed device has other pending status. Device End remains set with it, and the RVI response is made as usual.</p> <p>CC is not used for the 3274.</p> <p>IR – The addressed device is unavailable.</p> <p>DC, EC (either or both) – Not used for the 3274.</p> <p>DE, EC, US – A character generator or syn check error has occurred, or the printer was mechanically disabled but the condition has been corrected. DE, EC, US is not sent by the 3287 or 3289.</p> <p>DE, IR – The addressed printer is out of paper, its power has been turned off, or its cover is open.</p> <p>DE, IR, EC, US – The addressed printer is mechanically disabled and cannot recover.</p> <p>DE, DC, US – A parity error is detected at the printer.</p> <p>DC, US – An operation to a terminal was unsuccessful. The terminal was disabled and DC US returned to the host. On subsequent retry by the host, IR will be returned to the host.</p>
EOT	Read Commands	<p>CR – Invalid 3270 command is received.</p> <p>OC – Invalid command sequence (ESC is not in the second data character position), or data follows the command in the data stream received at the device.</p> <p>DB, US – The addressed device is busy. The command was chained to a Write, Erase/Write, Erase/Write Alternate, or Copy command which started a print, or it was chained to a Specific Poll.</p> <p>DB, US, DE – Not used for the 3274.</p> <p>IR – A command is addressed to an unavailable device.</p> <p>DC – The 3274 is unable to complete a Read command operation after the first block has been sent to the host, because either there was an error in the terminal or the terminal was powered off after the first block was sent. A SUB character and an ENQ character are placed in the buffer. When the TCU responds NAK, the 3274 responds EOT.</p> <p>DC, US – For a 3274, an operation to a terminal was unsuccessful. The terminal was disabled and DC US returned to the host. On subsequent retry by the host, IR will be returned to the host.</p>
EOT	Write Commands	<p>CR – An invalid or illegal 3270 command is received.</p> <p>OC – An invalid command sequence (ESC is not in the second data position), an illegal buffer address or an incomplete order sequence is received, or a data byte was sent to the device during the Write command before the operation required by the previous data byte was completed.</p> <p>(Not used for the 3274 or 3276.)</p> <p>DC, US – An operation to a terminal was unsuccessful. The terminal was disabled and DC US returned to the host. On subsequent retry by the host, IR will be returned to the host.</p> <p>CC – (Not used for the 3274.)</p> <p>DB, US – The addressed device is busy. The message is accepted but not stored in the 3274 buffer. The command is aborted.</p> <p>DE, DB, US – Not used for the 3274.</p>
EOT	Copy Command	<p>CC, OC – Not used for the 3274.</p> <p>DB, OC – The "from" device is busy. (The device is busy executing an operation, a printout, reading data from the Operator Identification Card Reader, or performing a keyboard operation.) The Copy command is aborted.</p> <p>IR, OC – The "from" device is not available.</p> <p>OC, US – The "from" device has a locked buffer.</p> <p>OC – The data stream contains other than two bytes (the CCC and the "from" address). The command is aborted.</p> <p>DC, OC – Not used for the 3274.</p>

Figure 5-21 (Part 1 of 2). Remote Error Status and Sense Responses, BSC

Device Response	Command	S/S Explanation
EOT	Copy Command	DC, OC, US – Set when “from” device detects an internal parity or cursor check. An operation to a terminal was unsuccessful. The terminal was disabled and DC US returned to the host. On subsequent retry by the host, IR will be returned to the host. DB, US – The addressed “to” device is busy. DB, US, OC – The addressed “to” device is also specified at the “from” device and is busy. DB, US, OC, DE – The addressed device becomes not busy before a specific poll is issued to retrieve the DB, US, OC status (described above).
EOT	Write, Erase/Write, Erase/Write Alternate, Copy Commands	IR – Addressed device is not available, or addressed printer is not ready. IR, EC, US – Not used for the 3274.
EOT	Erase All Unprotected Command Specific and General Poll	OC – One or more data bytes followed the command (buffer overrun). DE, IR, EC, US – An unrecoverable mechanical failure is detected at the printer. DE, EC, US – A character generator or sync check error or a mechanical failure is detected at a 3284/3286/3288 printer but then recovered from. DC, US – An operation to a terminal was unsuccessful. The terminal was disabled and DC US returned to the host. On subsequent retry by the host, IR will be returned to the host. DC – The 3274 is unable to complete a Read command operation after the first block has been sent to the host, because either there was an error in the terminal or the terminal was powered off after the first block was sent. A SUB character and an ENQ character are placed in the buffer. When the TCU responds NAK, the 3274 responds EOT. DC, EC (either or both) – Not used by the 3274. DE – The poll finds a device (1), previously recorded as busy, now not busy or, (2) previously recorded as unavailable <i>or</i> not ready, now available <i>and</i> ready. IR, DE – The poll finds a device, previously recorded as ready, available, and busy, now not ready and not busy, or the printer went not ready during a printout. DC, US, DE – A parity error is detected at printer. CC (Specific Poll only) – Not used by the 3274.
	Specific Poll	CC – The poll finds a device, previously recorded as available and ready, now unavailable (timeout check). (The 3271 record is updated.) (Not used by the 3274.) DB – The addressed device is busy.
NAK	Read and Write Commands	NAK is transmitted by the 3274 when it detects a Block Control Character (BCC) error on the TCU transmission. A BCC error has priority over all other detectable error conditions. If, for example, a BCC error and a parity error are detected during the same command transmission, the parity error condition is reset, and a NAK response is set by the 3274.

Figure 5-21 (Part 2 of 2). Remote Error Status and Sense Responses, BSC

Sense/ Status Bits	Detected during 3270 Operation						Transmitted in Response to:		Error Recovery Procedure
	Hex		Selection Addressing Sequence	Specific Poll Sequence	General Poll Sequence	A 3270 Command	Specific Poll	General Poll	3274
	EBCDIC	ASCII							
CR	40	60	20 2D				D, P		6
OC	40	C1	20 41				D, P		6
OC, US	C4	C1	44 41				D, P		13
IR	40	50	20 26	D, P	D, P		D, P		4
IR, OC	40	D1	20 4A				D, P		5
DC	40	C4	20 44	D, P	D, P	D, P	D, P	D, P	1
DC, US	C4	C4	44 44	D, P	D, P	D, P	D, P	D, P	2
DC, OC, US	C4	C5	44 45				D, P		3
DC, US, DE	C6	C4	46 44		P	P	P	P	8
EC, US, DE	C6	C8	46 48		P	P	P	P	7†
IR, EC, US, DE	C6	D8	46 51		P	P	P	P	7
DB	C8	40	48 20	D, P	D, P		D, P		9
DB, US*	4C	40	3C 20				D, P		10
OC, DB*	C8	C1	48 41				D, P		11
IR, EC, US	C4	D8	44 51				P		NA

Note: The attached device errors that are detected asynchronously do not cause a Sense bit to set until the device is polled for status during a Selection Addressing, Specific Poll, or General Poll sequence. Those error S/S bit combinations that contain DE were detected during a printout.

*The DB, US, and OC S/S bits will be combined if a Copy command is addressed to a busy "to" device and the command also specifies the "from" device the same as the "to" device.

†Occurs only if 3284, 3286, 3288 Printers are attached.

Legend:

- NA — Not Applicable
- D — Display (3277, 3278)
- P — Printer

Figure 5-22. Remote 3270 BSC Status and Sense Conditions

5.7.1 Error Recovery Procedures

1. Execute a new address selection addressing sequence and retransmit the message, starting with the command sequence that was being executed when the error occurred. If, after two retries, the operation is not successful, this should be considered as a nonrecoverable error. Follow supplementary procedure B after two retries.
2. Reconstruct the entire device buffer if possible, and retry the failing chain of commands (within the BSC sequence of operations). The sequence of commands used to reconstruct the buffer should start with an Erase/Write or Erase/Write Alternate command. If the information in the screen buffer is such that it cannot, or need not, be reconstructed, the operation may still be retried. If an unrecoverable 3278 buffer error or an error occurring on a transfer between the 3276 and 3278 is detected, the entire buffer is cleared and the host system is informed of the error by receiving DC, US status but is not informed of the clear operation. If, after three retries, the operation is not successful, this should be considered as a nonrecoverable error. Follow supplementary procedure A.

from a second selection to a 3277 with a cursor check. A selection addressing sequence or poll sequence to another device on the same control unit should be attempted before flagging the control unit as inoperative. A successful sequence indicates that the CU is probably satisfactory, and the device requires manual intervention to reset it (for example, a 3277 with a nonrecoverable data check). An unsuccessful sequence indicates that the CU may be at fault and requires manual intervention to reset it.

3. The error occurred during execution of a Copy command. Execute procedure 2, except that it is the buffer of the "from" device specified by the Copy command that should be reconstructed. After three retries, follow supplementary procedure B.
4. The error indicates that the printer is out of paper, has its cover open, or has a disabled print mechanism; or it indicates that the device is unavailable. Request (or wait for) either the display or system operator to ready the device. Then, retry the printout by issuing a Write command with the proper WCC and no data stream. (There is no data error, and the data is still intact in the device buffer and can be reused.) Or, follow procedure 2.

Programming Note: A cursor check in the 3284 is indistinguishable from a data check that occurred in the 3271 or

5. The error indicates that the "from" device specified by a Copy command is unavailable. Note that the device address associated with the error status and sense information does not indicate the device that actually required "readying." The device that requires the corrective action is the device specified by the "from" address in the Copy command. When the device is determined and made "ready," follow procedure 1.
6. The operation should be tried up to six times. Continued failure implies an application programming problem, which can be detected by analyzing the failing write data stream.
7. The error occurred during a printout operation and indicates either a character-generator error or a disabled print mechanism. There is no data error. The proper error recovery procedure is application-dependent since the user may or may not want a new printout. If a new printout is required, follow procedure 4.
8. A data error occurred in the device buffer during a printout, and procedure 2 should be followed.
9. A Specific Poll detected that the addressed device is busy. Periodically issue a Specific Poll to pick up the Device End sense/status bit sent by the device when it becomes not-ready (unless this status change is detected on a selection addressing sequence).
10. Indicates that a command was erroneously addressed to a busy device. Periodically issue a General or Specific Poll to pick up the Device End sense/status bit sent by the device when it becomes not busy. Then follow procedure 1.
11. Indicates that, in attempting to execute a Copy command, the "from" device was found to be busy. Follow procedure 1 when the "from" device becomes not busy. Note that the device address associated with the status and sense message is the address of the "to" device and not that of the busy "from" device. The "from" device will transmit Device End via a Specific or General Poll when it becomes not busy.
12. Indicates that the 3275 detected a BCC error during text transmission from the TCU. Follow procedure 2 if the failing command is a Write command with a data stream of more than one byte or if it is in a chain of commands and one of the previous commands in the chain is a Write command without an SBA order immediately following the WCC character. In all other cases, follow supplementary procedure D. If, after the recommended procedure has been tried six times, the problem is not corrected, follow supplementary procedure A.
13. An attempt was made to execute a Copy command, but access to the "from" device data was not authorized. The device address associated with the error sense/status bits is that of the Copy "to" device.

5.7.2 Supplementary Procedures

- A. Request maintenance for the device that is giving trouble. After repair, reconstruct the screen buffer image. The sequence of commands used to reconstruct this image should start with an Erase/Write command. Retry the failing chain of commands according to the procedure that referred you to this supplementary procedure.
- B. The "from" device specified by the Copy command in the failing chain of commands (CCWs) is malfunctioning. The "from" device should be determined from the data-stream information, and maintenance should be requested for the device. After the repair, reconstruct the buffer image. The sequence of commands used to reconstruct this image should start with an Erase/Write command. Retry the failing chain of commands according to the procedure that referred you to this supplementary procedure.
- C. Same as procedure 1, except a new selection addressing sequence is not performed, and this message is transmitted as part of the present device selection.
- D. Same as procedure 1, except retransmit the entire failing chain of commands.

5.8 SDLC SEQUENCE RESPONSE DESCRIPTIONS

5.8.1 SLDC Transmission Frames

SDLC transmission frames are composed of a series of eight-bit binary-coded bytes which contain addressing, data, control, and checking information. Transmission between the controller and the 3274 unit takes place according to a predefined frame format which consists of the following sequence of bytes:

- Flag (F) Sequence — 1 byte
- Secondary Station Address (A) — 1 byte
- Control (C) Field — 1 byte
- Information (I) Field — up to 256 bytes of message data, preceded by header information
- Frame Check Sequence (FCS) — 2 bytes
- Flag (F) Sequence — 1 byte

Bit synchronization preceding transmission of an initial flag and following a line turnaround is achieved by transmission of 16 zero bits, after the clear-to-send signal is turned on and the NRZI encoder (when used) is enabled.

For a detailed description of the SDLC frame format, refer to *IBM Synchronous Data Link Control General Information*, GA27-3093. Support of the frame sequence, flag byte, Address byte, and Frame Check Sequence bytes conforms to the referenced document.

5.8.1.1 Response Modes

The 3274 unit functions in two link operating modes: normal response mode (NRM) and normal disconnect mode (NDM). In NRM, the 3274 can initiate transmission and raise the request-to-send signal only as a result of receiving a frame from the communications controller which contains the P bit set to 1. Single or multiple frames may be sent by the 3274. The last frame (or a single frame) transmitted by the 3274 in response to a command received with the P bit set to 1 must have the F bit set to 1. When the 3274 has completed a transmission, a new transmission cannot be initiated until a subsequent frame is received from the communications controller which contains the P bit set to 1. A response transmission initiated by the 3274 which requires acknowledgment from the communications controller, is repeated each time the communications controller polls until the acknowledgment is received. There is no limit to the number of transmissions. Responses that require acknowledgment from the communications controller are I-frames, CMDR and RR when transmitted with the F bit set to 0, to report clearing of a busy condition.

When in NDM, the 3274 cannot accept or transmit I or supervisory (S) frames. Nonsequenced responses are not transmitted unless the 3274 is solicited to reply. Invalid or nonimplemented commands received in NDM cause the 3274 to transmit an ROL response at the next response opportunity. ROL can be retransmitted until an SNRM or DISC command is received. Command reject conditions are not present in NDM.

The following paragraphs describe the 3274 port of the Control and Information fields.

5.8.1.2 Control Field

The Control field designates the frames as Supervisory (S), Nonsequenced (NS), or Information (I).

Supervisory Commands: The 3274 supports only the Supervisory commands Receive Ready (RR) and Receive Not Ready (RNR).

The C-field formats are as follows:

RR	Nr	P/F	00	01
	012	3	45	67
RNR	Nr	P/F	00	01
	012	3	45	67

The 3274 will transmit RNR when the control unit cannot accept further data from the link.

When the reported RNR condition is cleared, the control unit will transmit an I-frame or RR with the F bit on after a frame with the P bit on is received.

If the 3274 has received an RNR, an I-frame will not be transmitted until an RR or I-frame with the poll bit on is received.

The transmission or receipt of an NS frame does not indicate the RNR condition has cleared.

Nonsequenced Commands and Responses: The Nonsequenced commands and responses listed in Figure 5-23 are supported by the 3274.

Command/Response	C-Field	Hex Code
Set Normal Response Mode (SNRM) Command	1 0 0 P 0 0 1 1 0 1 2 3 4 5 6 7	93
Disconnect (DISC) Command	0 1 0 P 0 0 1 1 0 1 2 3 4 5 6 7	53
Nonsequenced Acknowledgment (NSA) Response	0 1 1 F 0 0 1 1 0 1 2 3 4 5 6 7	73
Request Online (ROL) Response	0 0 0 F 1 1 1 1 0 1 2 3 4 5 6 7	1F
Command Reject (CMDR) Response	1 0 0 F 0 1 1 1 0 1 2 3 4 5 6 7	97
Test Command/Response	1 1 1 P/F 0 0 1 1 0 1 2 3 4 5 6 7	F3
Exchange Station ID Command/Response	1 0 1 P/F 1 1 1 1 0 1 2 3 4 5 6 7	

Figure 5-23. Nonsequenced Commands and Responses Supported by 3274

The SNRM command sets the 3274 in NRM. Receipt of SNRM causes the 3274 to deactivate the physical unit if it is in active state. The On-Line and Ownership symbols are turned off.

The DISC command sets the 3274 in NDM.

The NSA response is sent by the 3274 to acknowledge receipt and acceptance of the SNRM and DISC commands.

The Test command is used to initiate one round-trip transmission of test data in both NRM and NDM. The 3274 station will return the Test response without data if buffering is not available to hold the complete test data, or with data if buffering is available.

The Request on Line (ROL) response is sent by the 3274 in normal disconnect mode (NDM) to request online status. ROL is sent in response to any command except Test and XID. ROL is sent in response to the SNRM command when the 3274 cannot enter NRM.

The CMDR response is implemented by the 3274 as described in GA27-3093. The CMDR will be sent in response to any poll until an SNRM or DISC is received to reset the control unit.

The Exchange Station Identification (XID) command and response contains additional data beyond the C byte. The 3274 responds to the XID command in NRM or NDM, except when a CMDR condition exists, in which case the CMDR response takes precedence over XID. The request/response unit (RU) of the XID response consists of 48 bits, defined as follows:

Bits	Meaning
0–3	ID format B "0000"
4–7	PU type B "0010"
8–15	Self-description X "00"
16–27	X'017' (3274) and X'018' (3276)
28–47	ID number

Information (I) Frame: The Information frame is used to transmit message data. When transmitted, the I-frame contains a maximum of 256 bytes of RU message data preceded by six bytes of transmission header (RH).

5.8.2 Sequence Error Recovery Procedures

A sequence error occurs when the 3274 receives an I-frame with an incorrect Ns sequence count and valid FCS bytes. The 3274 does not accept the I-frame that caused the sequence error and rejects all following I-frames, until an I-frame is received which contains the correct Ns value, at which time the sequence error condition is reset.

The 3274 transmits I-frames in the sequence indicated by the last Nr count received, which may include retransmission of previously transmitted I-frames that have not been acknowledged.

All I-frames are transmitted in contiguous sequence according to the Ns value within the constraints of the modulo count.

5.8.2.1 Abort Function

The abort function is used by the communications controller or by 3274 when a frame being transmitted is to be discarded. The abort function is performed by transmitting eight contiguous one bits without zero insertion at the earliest possible time following recognition of an abort situation. No FCS is transmitted. When, for example, the 3274 receives seven contiguous one bits, it discards the aborted frame. The 3274 employs the abort function when an equipment malfunction occurs that causes an erroneous transmission.

5.8.2.2 Timeout Control

When the 3274 is attached point-to-point or multipoint and does not recognize any valid outbound frame for 20 to 25 seconds, a nonproductive timeout occurs. This timeout causes the 3274 to set the Communication Check symbol on all attached 3278s. The timer is reset to zero every time the 3274 detects a valid outbound frame. The Communication Check symbol is turned off when a valid frame is received by the station.

If a condition of no line activity is detected by the 3274 for 20 to 25 seconds, the Communication Check symbol is set on all attached 3278s. The indicator will be turned off when a valid frame is received.

5.8.3 Hexadecimal Notation and Frame Summary

Figure 5-24 shows the hexadecimal notation for SDLC commands and responses.

Nonsequenced Commands

	P	\bar{P}
SNRM	'93'	'83'
DISC	'53'	'43'
SIM	'17'	'07'
NSI	'13'	'03'
NSP	'33'	'23'
XID	'BF'	
TEST	'F3'	'E3'

Nonsequenced Responses

	F	\bar{F}
NSA	'73'	'63'
ROL	'1F'	'0F'
CMDR	'97'	'87'
RQI	'17'	'07'
NSI	'13'	'03'
XID	'BF'	
TEST	'F3'	'E3'

Supervisory Commands/Responses (See Legend)

RR	'_1'
RNR	'_5'
REJ	'_9'

Information Commands/Responses (See Legend)

I	'_*'
---	------

Legend

Hexadecimal digit for "--"		
Nr=	P/F	\bar{P}/\bar{F}
0	1	0
1	3	2
2	5	4
3	7	6
4	9	8
5	B	A
6	D	C
7	F	E
Hexadecimal digit for "***"		
Ns=	Hex	
0	0	
1	2	
2	4	
3	6	
4	8	
5	A	
6	C	
7	E	

Figure 5-24. SDLC Commands and Responses in Hexadecimal Notation

5.9 SNA INFORMATION

5.9.1 Session Control

Session Control (SC) requests are sent from the host to establish and maintain a session with 3274. Session Control also provides facilities to clear data flowing within a session after a catastrophic error occurs and then to resynchronize the data flow after such an error. All Session Control commands supported by 3274 are transmitted on the expedited flow. The specific SC function is identified by the first byte of the Request Unit (RU). The SC functions supported by 3274 are listed in Figure 5-25.

Function	BU Byte	Support
Activate Physical Unit (ACTPU)	X'11'	Outbound
Deactivate Physical Unit (DACTPU)	X'12'	Outbound
Activate Logical Unit (ACTLU)	X'0D'	Outbound
Deactivate Logical Unit (DACTLU)	X'0E'	Outbound
Bind	X'31'	Outbound
Unbind	X'32'	Outbound
Clear	X'A1'	Outbound
Start Data Traffic (SDT)	X'A0'	Outbound

Figure 5-25. Session Control Functions Supported by 3274

5.9.2 Data Flow Control

Data Flow Control (DFC) requests are passed between the application program and 3274 to provide control over session data flow. Data Flow Control functions are identified by the setting of the RU type bit to B'1' and the Subsystem Control bit to B'0'. The DFC requests listed in Figure 5-26 are supported by 3274.


Function	Flow	RU Byte	Support
Cancel	Normal	X'83'	Inbound/Outbound
Bid	Normal	X'C8'	Outbound
Chase	Normal	X'84'	Outbound
Signal	Expedited	X'C9'	Inbound/Outbound
SHUTD	Expedited	X'C0'	Outbound
SHUTC	Expedited	X'C1'	Inbound
LUSTAT	Normal	X'04'	Inbound
RTR	Normal	X'05'	Inbound

(LU types 1, 3)

Figure 5-26. Data Flow Control Requests Supported by 3274

5.9.3 Transmission Header

The format of the transmission header is shown in Figure 5-27.




Note: Mapping Fields

Bits	4	5	
0	0	0	Middle of segment
0	1	1	Last of segment
1	0	0	First of segment
1	1	1	Whole segment

Figure 5-27. Transmission Header Format

5.9.4 Request/Response Header

The format of the request/response header is shown in Figure 5-28.



Note: *RU0 Bits 1 and 2 – RU Type/Subsystem Control Indicator*

1	1	<i>Session Control</i>
1	0	<i>Data Flow Control</i>
0	1	<i>Network Control (not implemented)</i>
0	0	<i>FM Data</i>

Figure 5-28. Request/Response Header Format

5.9.5 SNA Definitions

3274 – PU.T2

For all PIUs sent and received, the transmission header (TH) format is a FID2. (See Figure 5-27) for the layout for FID2 TH.)

3274 – FM Profile 3

Primary LU half-session and secondary LU half-session use delayed control mode and immediate-response mode. These half-sessions support the following DFC functions:

- Cancel
- Signal
- LUSTAT (allowed secondary to primary only)
- Chase
- SHUTD
- SHUTC
- RSHUTD
- Bid and RTR (allowed only if brackets are used)

The FM usage fields defining the options for Profile 3 are:

- Chaining use (primary and secondary)
- Request mode selection (primary and secondary)
- Chain response protocol (primary and secondary)
- Compression indicator (primary and secondary)
- Send EB indicator (primary and secondary)

- FM header usage
- Brackets
- Bracket termination rule
- Alternate Code Set Allowed indicator
- Normal-flow send/receive mode
- Recovery responsibility
- First speaker (for bracket protocol)
- Contention resolution

3274 – TS Profile 3

Profile 3 specifies the following session rules:

- Primary – secondary normal flow is paced.
- Sequence numbers are used on normal flows.
- Clear and SDT are required.
- RQR and STSN may be used.

LU Types

- LU1 – Printer 3289 (LYNX), 3287 (BAHIA-Feature only)
- LU2 – Display 3278 (D), 3279
- LU3 – Printers ANR – 3284, 3286, 3288
NDS – 3289, 3287

5.9.6 SDLC/SNA Command to Start a Session

Figure 5-29 shows the SDLC/SNA commands required to initialize a session with LU1 (DAF of 2). Only the requests are shown, but the SDLC receive count has been updated whenever a line direction change occurs to account for a positive response from the secondary station.

It should be noted the requests/responses do not carry the SDLC poll/final bit. The lines, in all cases, are turned around by the RR (SDLC) cmd after every response/request.


	Frame	Address	Control	TH	RH	RU	BCC	Frame
SNRM	7E	C1	93				277A	7E
RR	7E	C1	11				3DDD	7E
ACTPU	7E	C1	00	2F0000000001	6B8000	110101050000000001	02B9	7E
RR	7E	C1	11				3DDD	7E
ACTLU	7E	C1	22	2F0002000001	6B8000	0D0101	126B	7E
RR	7E	C1	31				3FFC	7E
Bind	7E	C1	44	2F0002010001	6B8000	31010303B1A03080 0001858700000200 0000000018501850 02000006F3C5B2B3 C5D900	94FF	7E
RR	7E	C1	51				399F	7E
Clear	7E	C1	66	2F0002010002	6B8000	A1	062E	7E
RR	7E	C1	71				3BBE	7E
SDT	7E	C1	88	2F0001010001	6B8000	A0		
RR	7E	C1	91				3559	7E

Figure 5-29. SDLC/SNA Commands Required to Start Session with LU1

5.10 SDLC/SNA ERROR INFORMATION

5.10.1 Exception Response with Sense Data Included

The exception responses for SDLC/SNA are shown in Figure 5-30.



Note: SDI and EXR/FRR bits are on for sense information.

Figure 5-30. SDLC/SNA Exception Responses

5.10.2 SNA Sense Codes

Each major error code has modifiers for further description in sense byte 1. Following are the modifier codes supported and the controller or terminal condition causing the negative response to be returned.

Sense Byte One	Description
Path Error X'80'	
X'04'	Unrecognized DAF' Controller does not have a terminal adapter for the DAF address.
X'05' – NO SESSION	<ul style="list-style-type: none">• A Bind has not been received or accepted by the 3274.• A request other than Bind is sent to an SLU which has already accepted a Bind, and the OAF' is not X'00' or the OAF in the accepted Bind.
X'08' – PU NOT Active	The 3274 has not received or accepted an ACTPU, or a control condition caused an internally generated DACTPU.
X'09' – LU NOT Active	The 3274 has not received or accepted an ACTLU, or a control condition caused an internally generated DACTLU.
X'0F' – Invalid Address Combination	A request was addressed to the PU (DAF'=X'00'), and the OAF was not SSCP (OAF'=X'00').
RH Error X'40'	
X'06' – Exception Response Not Allowed	LIC carried exception response when Bind specified definite response.
X'07' – Definite Response Not Allowed	LIC carried definite response when Bind specified exception response or LIC carried definite response.
X'0A' – No-Response Not Allowed	A chain element did not have DR1, DR2, or the exception bit set to 1.
X'0F' – Format Indicator Not Allowed	An FM request received by the 3274 indicated formatted header included.
State Error X'20'	
X'01' – Sequence Number Error	The sequence number of the normal flow request did not match the number expected by the 3274.
X'02' – Chaining Error	Chain elements were out of protocol sequence.
X'03' – Bracket State Error	A Bracket state error occurred.
X'04' – Direction Error	A normal flow without begin bracket was received while the 3274 was in Send state.
X'05' – Data Traffic Reset	An FM or DC request was received before an SDT was received or accepted.

Sense**Byte****One Description****X'03' – Function Not Supported.**

- Unsupported Session Control Request
- Unsupported Data Flow Control Request
- SIGNAL Code is not X'00010000'
- Network Control Request
- FM Data Stream
- Invalid Command
 - Data Following a Read, RM, RMA, or EAU command
 - For LU type 3, any Read, RM or RMA command.

X'05' – Parameter Error

Invalid address following SBA, RA, or EUA order (SBA, RA, or EUA order without parameters), or SCS parameter error.

X'07' – Category Not Supported

- An FMD request from the SSCP was received by a SLU which has an attached device without a keyboard.
- An unsupported network service message received.

Request Reject X'08'**X'01' – Resource Not Available**

- LU type 2, A printer is not allowed by the Authorization Matrix
- For LU type 1 or 3, Bind reject because printer is authorized for Local mode only.

X'02' – Intervention Required (on principal device).

- For LU type 2, security key is tuned off
- For LU type 1 or 3, printer condition such as end of form, paper jam, printer cover up, or hold time out.

X'05' – Session Limit Exceeded

A Bind was received whose OAF' differs from the PLU already bound.

X'0A' – Permission Rejected

Display or printer power is off. The SSCP will not be notified when the device powers on.

X'11' – Break

Sent on LU type 1 when the operator depresses the printer Hold Print key followed by Cancel key, if a chain has not completed printing.

X'13' – Bracket Bid Reject – (No RTR)

Returned by LU type 2 to a BID or BID with Begin Bracket if the display has won contention and started a bracket.

X'15' – Function Active

Bind reject if the same OAF' already has an accepted Bind to the SLU.

X'1B' – Receiver in Transmit Mode

- The SLU is Between Bracket but a data key has been depressed.
- An FM message was received from the SSCP while the display was owned by the PLU-SLU session or is in Test mode.
- An SSCP FM message is rejected if local copy is taking place while the SSCP-SLU session owns the display.

**Sense
Byte
One**

Description

- X'1C' – Request Not Executable
The 3274 or 3276 has a nonrecoverable error.
- X'21' – Invalid Session Parameters
- Bind parameters do not match the 3274 Bind checks.
- X'29' – Change Direction Required
A 3270 read-type command was received without a Change Direction, or with an End Bracket.
- X'2A' – Presentation Space Altered, Request Executed
An LU type 2 3277 attached to a 3274 has a reset keyboard, and tried to enter while in receive state.
- X'2B' – Presentation Space Integrity Lost
- A temporary error has occurred; for example, parity check in device,
 - An operator has cleared the display by switching to SSCP-SLU session or Test mode and returned to PLU-SLU session.
- X'2D' – SLU Busy
- LU type 2 Display is owned by SSCP-SLU session or Test mode.
 - LU type 2 Display is busy doing an operator-initiated local copy.
 - LU type 2 3277 attached to 3274 is busy with a Back Tab.
- X'2E' – Intervention Required at Subsidiary Device.
For LU type 2, a printer being copied to from a host-initiated print has intervention-required type error. Refer X'0802'. Printer power off or not attached to the controller is included in this category.
- X'2F' – Request Not Executable Because of LU Subsidiary Device.
For LU type 2, a printer being copied to has a nonrecoverable error.
- X'4A' – Presentation Space Altered, Request Not Executed
Refer to X'2A'.
- X'31' – LU Component Disconnected
This response is returned if the device attached to the 3274 cannot be contacted by a device poll. This is due to device power off, cable detached from the controller port, or connecting cable broken.
- X'43' – Required Function Manager Synchronization Not Supplied
For LU type 2 or 3 chains having the print bit on, must be definite response or exception response chain must carry CD.

5.10.3 Logical Unit Status (LUSTAT)

LUSTAT provides a means for the SLU to report exception conditions or status when the SLU is not in Receive state (a negative response is used when the SLU is in Receive state). Following are the CD settings that accompany LUSTAT and the state changes, if any, that occur:

SLU State When LUSTAT Sent	CD Setting	State Change
BETB	CD may be set	None
ERP1	CD not set	None
Send	CD set for principal device	to Receive
	CD not set for subsidiary device	None

Inbound LUSTATs are sent with exception response by the 3274.

Programming Note: An LUSTAT showing power off sent while in Send state carries CD. An LUSTAT that shows power on cannot be sent until the PLU causes an SLU state change to (S, *R).

The following status codes will be used by 3274 to send information to the PLU, on the PLU-SLU session.

Value	Explanation
X'0001Z000'*	Device now available; presentation space not destroyed.
X'00020000'	Device has received CD, but has no input mechanism.
X'081CZ000'*	Component Failure; Permanent Error.
X'082B0000'	Device available; presentation space integrity lost.
X'08310000'	Principal device is powered off or disconnected.
X'0801Z000'*	Printer has been removed from configured status.

*Where Z specifies whether the status refers to the principal or subsidiary device. (Refer to "SNA Printer Sessions" for a description of principal and subsidiary devices.) The value of Z is defined as follows:

LU type 1 Principal (printer)	Z = 0
LU type 2 Principal (display)	Z = D
LU type 2 Subsidiary (printer)	Z = B
LU type 3 Principal (printer)	Z = 0

The priority of these status codes, in low to high order, is assigned as:

X'0002', X'0001', X'082B', X'0831', X'0801', X'081C'

3274 or 3276 will send the highest level of priority status when an opportunity allows its transmission.

Definition: (S, *R) = Send state, ERP1 state, or BETB state.

The upper section of Figure 5-31 shows the LUSTAT codes that are returned to clear the negative response condition listed in the left column. The lower section lists the LUSTAT codes that are used to report an SLU error condition instead of a negative response. The X's show the sessions that use the code points.

The usages of LUSTAT are as follows:

For all LU types, when the 3274 has sent -RSP with X'0802' or X'082E' and this condition is reset, LUSTAT with X'0001P000' will be sent: where the value P is X'0' for LU type 1 or 3, X'D' for LU type 2 principal (display), and X'B' for LU type 2 subsidiary device (printer).

LUSTAT Returned

Negative Response Code	LU TYPE			
	T1	T2	T3	SSCP
0802	00010000	0001D000	00010000	NA
	082B0000	082B0000	082B0000	
	081C0000	081CD000	081C0000	
	08310000	08310000	08310000	
0807	NA	0001B000	NA	NA
		0801B000		
		081CB000		
		081CD000		
082D	NA	0001D000	NA	NA
		082B0000		
		081CD000		
082E	NA	0001B000	NA	NA
		0801B000		
		081CB000		
		081CD000		
0831	082B0000	082B0000	082B0000	NA
	081C0000	081CD000	081C0000	NA

Sent By

LUSTAT	LU TYPE		
	T1	T2	T3
<i>SEND</i>			
<i>BETB</i>			
<i>ERP.1</i>			
00020000	X	X	X
081C0000	X		X
081CB000		X	
081CD000		X	
082B0000	X	X	X
08310000	X	X	X
0801B000		X	

Figure 5-31. Summary Table of LUSTATs

If the presentation integrity is lost while an X'0802' condition exists, LUSTAT with X'082B0000' will be sent instead of X'0001P000' when the X'0802' condition is reset.

For LU type 2, when the 3274 SLU has sent -RSP with Secondary component not available (X'0807') and this condition is reset, LUSTAT with X'0001B000' will be sent.

For all LU types supported, the LUSTAT X'00020000' will be sent when the 3274 accepts a Normal flow request carrying CD, but no input components (keyboard, light-pen, MSR, etc.) are attached to the device.

For all LU types, LUSTAT with X'082B0000' will be sent to the PLU when the 3274 SLU detects presentation integrity lost (for example, regeneration buffer parity error), and is in (S *R) state for the 3274.

For LU type 2, when the 3274 has sent -RSP (Device Busy) (X'082D') to a PLU request because of session ownership change from PLU to SSCP or TEST, LUSTAT with X'082B0000' will be sent to the PLU when returning to PLU-SLU session.

For LU type 2, when the -RSP (Device Busy) (X'082D') has been returned from the 3274 for a Back Tab busy condition, the LUSTAT X'0001D000' component now available to the PLU will be sent when the busy condition clears.

For LU type 2, when 3274 has sent -RSP (Device Busy) (X'082D') to a PLU because the SLU is busy executing a local copy, the 3274 sends LUSTAT X'0001D000' component now available to the PLU when the busy condition clears.

For all LU types, if a principal device is powered off or unplugged from the controller port and a session exists which is in (S, *R) state, LUSTAT X'08310000' will be sent to the PLU.

For all LU types, when a principal device has sent -RSP or LUSTAT X'08310000' and then power is restored, LUSTAT with X'082B0000' will be sent to the PLU.

For all LU types, if 3274 finds a permanent error in the principal device and is in (S, *R) state, LUSTAT with X'081CP000' will be sent to the PLU. The value of P is the same as defined in item 1.

For LU type 2, if the 3274 finds a permanent error in the subsidiary device and is in (S, *R) state, the worsening of the previous condition will not be reported. Instead, LUSTAT X'0001B000' will be sent, and the next outbound requests will be rejected with the proper sense code.

For LU type 2, if the 3274 finds the subsidiary device has been configured from Local or Shared mode to System mode, LUSTAT X'0001B000' will be sent if an LUSTAT is owed. The next outbound request will be rejected with the proper sense code.


Note: An LUSTAT showing power off during send state carries CD. An LUSTAT showing power on cannot be sent until the PLU causes an SLU state change to (S, *R).

5.10.4 Command Reject

The Command Reject (CMDR) response is sent by the 3274 control unit to report the following error conditions:

1. Receipt of a command code with valid BCC but which is an invalid command or a command not implemented for the 3274.
2. Receipt of a frame with valid BCC that contains an I-field and a command which should not be sent with an I-field.

3. Receipt of an I-format frame with valid BCC which contains an illegal Nr count in the C-field.
4. Receipt of an I-format frame in which the information field is too large to be accommodated by the available buffer space in the 3274.



Byte 1 is the C-field that caused the CMDR response. Byte 2 contains the Ns and Nr sequence counts that existed immediately prior to establishing the CMDR response. Byte 3 indicates the reason for the CMDR.

Bit W is set to 1 when the C-field returned in byte 1 represents an invalid or nonimplemented command.

Bit X is set to 1 when the C-field returned in byte 1 is considered invalid because the frame contained an information field not allowed with the command sent.

Bit Y is set to 1 when the information field associated with the valid and implemented C-field contained in byte 1 was too long for the available buffer space in the 3274 control unit. This condition never occurs when bit X is set.

Bit Z is set when the receive Nr sequence count contained in the C-field in byte 1 is out of range.

Figure 5-32 shows the CMDR message format.

5.10.5 Request Maintenance Statistics (REQMS) Command

The Request Maintenance Statistics (REQMS) command is sent by the SSCP to a 3274 when the Network Determination Aid Processor (NDAP) requests PU performance statistics. Four types of requests can be made, as follows:

- Type 1 – Link Test Statistics
- Type 2 – Summary Counters
- Type 3 – Communication Adapter Data Error Counts
- Type 5 – 3274 Configuration Information/3276 Machine Level Information

The state of the RESET/NO-RESET indicator in the REQMS request determines whether the log area where the transmitted maintenance statistics are stored is cleared.

An REQMS request that cannot be executed by the 3274 is rejected with a negative response; an accepted REQMS request receives a positive response and the requested statistics (formatted as RECFS) as an inbound message.




Figure 5-32. Command Reject (CMDR) Message Format

5.10.5.1 Record Formatted Maintenance Statistics (RECFMS)

Record Formatted Maintenance Statistics (RECFMS) is sent by the 3274 to the SSCP in response to an REQMS command. (The 3274 will not send unsolicited RECFMS requests to the host.) The RECFMS maintenance statistics are recorded at the host by the Network Communications Control Facility (NCCF).

When the 3274 accepts an REQMS request, it transmits the maintenance statistics requested. If the REQMS specified "RESET," the error log area referenced by the REQMS is reset by the 3274 after the RECFMS is transmitted.

A description of RECFMS responses follows.

5.10.5.2 RECFMS Formats

The 3274 Control Unit can send the host system four types of RECFMS responses to an REQMS command.

Counters in type 1, 2, and 3 responses do not wrap when they exceed their maximum value, they maintain the maximum value.

The log areas are reset when:

- The 3274 is turned off (types 1, 2, and 3).
- The concurrent test, Error Log Erase, is executed for the 3274 CCA/HPCA Adapter (type 3 only).
- The execution of RECFMS is completed normally as the response to an REQMS with a "RESET" request (types 1, 2, and 3).

The formats of the four RECFMS responses are as follows:

- REQMS Request Type 1 – Link Test Statistics

Bytes 14, 15 = Number of times the Test Command was received.

Bytes 16, 17 = Number of times the Test response was transmitted.

- REQMS Request Type 2 – Summary Counters

Byte 14 = Mask bits of the summary counters supported. All supported counters, including those containing zero count, are sent to the host by RECFMS.

Bit 0 = 1 = Machine Check.

Bit 1 = 1 = Communication Check.

Bit 2 = 1 = Program Check.

Bits 3–7 = Reserved.

Bytes 15, 16 = Reserved.

Bytes 17, 18 = Machine Check Summary Counter.

Bytes 19, 20 = Communication Check Summary Counter.

Bytes 21, 22 = Program Check Summary Counter.

- REQMS Request Type 3 – Communication Adapter Data Error Counts

Byte 14 = Adapter Type.
 = X'01' = CCA Link Adapter.
 = X'02' = HPCA Link Adapter
 = X'03' – X'FF' = Reserved.

Byte 15 = Mask bits of the Communication Adapter Error Counters supported. All supported counters, including those containing zero count, are sent to the host by RECFMS.

Bit 0 = 1 = Nonproductive Timeout.

Bit 1 = 1 = Idle Timeout.

Bit 2 = 1 = Write Retry.

Bit 3 = 1 = Overrun.

Bit 4 = 1 = Underrun.

Bit 5 = 1 = Connection Problem.

Bit 6 = 1 = FCS Error.

Bit 7 = 1 = Primary Abort.

Byte 16 = Mask bits of the Communication Adapter Error Counters supported. All supported counters, including those containing zero count, are sent to the host by RECFMS.

Bit 0 = 1 = Command Reject.

Bit 1 = 1 = DCE Error.

Bit 2 = 1 = Write Timeout.

Bits 3–7 = Reserved.

Byte 17 = Reserved.

Byte 18 = Nonproductive Timeout Counter.

Byte 19 = Idle Timeout Counter.

Byte 20 = Write Retry Counter.

Byte 21 = Overrun Counter.

Byte 22 = Underrun Counter.

Byte 23 = Connection Problem Counter.

Byte 24 = FCS Error Counter.

Byte 25 = Primary Abort Counter.

Byte 26 = Command Reject Counter.

Byte 27 = DCE Error Counter.

Byte 28 = Write Timeout Counter.

- REQMS Request Type 5 – 3274 Configuration Information

Byte 14 = Always X'00'.

Bytes 15–30 = Installed Patch ID Values.

Byte 31 = Number of RPOs Installed on the 3274.

Byte 32 = Reserved.

Bytes 33–37 = RPO 1 ID.

Bytes 38–42 = RPO 2 ID.

Bytes 43–47 = RPO 3 ID.

Bytes 48–50 = Control Values for Suffix Numbers.

Bytes 51–60 = Reserved.

Byte 61 = Feature Disk Level.

Byte 62 = Feature Disk Suffix.

Byte 63 = System Disk Level.

Byte 64 = System Disk Suffix.

Byte 65 = Language Disk Level.

Byte 66 = Language Disk Suffix.

Byte 67 = RPO 1 Disk Level.

Byte 68 = RPO 1 Disk Suffix.

Byte 69 = RPO 2 Disk Level.

Byte 70 = RPO 2 Disk Suffix.

Byte 71 = RPO 3 Disk Level.

Byte 72 = RPO 3 Disk Suffix.

5-11 SWITCHES AND CONTROLS

Figure 5-33 explains the switches and controls.

Indicator/Control	Explanation
Power/Interface switch and On/Off switch (I = on; O = off) On Indicator	<p>When locally attached to a host system, power for the 3274 can be applied and removed from the host processor (remote power control) or at the 3274 (local power control) by using the Power/Interface switch as follows:</p> <ol style="list-style-type: none"> 1. Remote power control. When the Power/Interface switch is placed in the Remote/Online position and the On/Off switch to On, power can be turned on or off at the host processor. 2. Local power control. To apply power, the Power/Interface switch is placed in the Local/Online position and the On/Off switch is placed in the On position. The On indicator lights. To remove power, the Power/Interface switch is placed in the Local/Offline position and the On/Off switch is set to Off, after the Local/Offline indicator lights. <p>When remotely attached to a host system, power is applied and removed at the 3274 by using the On/Off switch. (The Power/Interface switch is not installed.)</p>
IML and Alt IML Address 1/2	<p>The Initial Machine Load (IML) pushbutton and the Alternate (Alt) IML rocker switch are used to initiate manual IML operations at the 3274.</p> <p>Warning: The Power/Interface switch must be in the Local/Offline position and the Local/Offline indicator must be on.</p> <p>Pressing and holding the IML pushbutton causes a basic test to be run. Releasing IML allows execution of the IML tests, followed by loading of the machine. (Total operation time is approximately 50 seconds.)</p>
IML and Alt IML Address 1/2	<p>Warning: Pressing the IML pushbutton causes an interruption and temporarily disables all terminals attached to the 3274. If any attached terminals are in use, all terminal operators should be notified before proceeding.</p> <p>Holding the Alt IML Address switch in position 1, while pressing and holding the IML pushbutton, loads the machine directly. This procedure should be followed only when the normal loading procedure fails and useful work can still be done.</p> <p>Holding the Alt IML Address switch in position 2 while pressing the IML pushbutton causes a communication link test to be run. The test is operable only when the Power/Interface switch is in the Remote position.</p>

Figure 5-33. Switches and Controls

5.12 BSC AND SNA READINESS SYMBOLS

Figures 5-34 and 5-35 show the readiness symbols associated with the BSC and SNA selection sequences, respectively.






Figure 5-34. BSC Readiness Symbols



Note: The TEST key with ALT will set TEST. The second depression will return to the state prior to the entry to Test mode.

Note:

505 = SNRM Required


510 = PU Not Active

Figure 5-35. SNA Readiness Symbols

5.13 DIGITAL DATA SERVICE (DDS) ADAPTER

The Digital Data Service (DDS) Adapter provides for the connection of the 3274 Control Unit Model 51C to the AT&T nonswitched Dataphone¹ digital data service network. The DDS Adapter is an integrated adapter for BSC or SDLC data transmission at speeds of 2400, 4800 or 9600 bps. Access to the Digital Data Service (DDS) network is provided by the AT&T Channel Service Unit, which is the DDS network termination point at the customer site. See Figure 5-36.

The 3274 must have either the Common Communications Adapter (CCA) or the High-Performance Communications Adapter (HPCA) installed. The DDS Adapter can be used in point-to-point or multipoint configurations. Wrap test capability of the DDS Adapter allows testing of the adapter only, or the adapter and the communications cable. Figure 5-37 illustrates the digital data waveshapes.




¹Trademark of American Telephone and Telegraph Co.


²Or equivalent

Figure 5-36. Connection of 3274 Control Unit Models 51C and 52C with DDS Adapter Feature

DDSA Output to Channel Service Unit



Channel Service Unit Input to DDSA



¹ V_{out} is a differential ac voltage across a 135-ohm resistive termination

² Bit interval = $\frac{1}{\text{bit rate (bps)}}$

Figure 5-37. Digital Data Waveshapes

Chapter 6. Tools and Test Equipment

6.1 INTRODUCTION

This chapter identifies and describes the specialized tools and test equipment that may be required for 3274 problem isolation.

These specialized pieces of test equipment are presently used with the 3274 Control Unit:

- Buffered Teleprocessing Diagnostic Analyzer and Tester (BTDAT)
- NU Data Tester, IBM PN 453637
- PT-2

6.2 BUFFERED TELEPROCESSING DIAGNOSTIC ANALYZER AND TESTER (BTDAT)

The Buffered Teleprocessing Diagnostic Analyzer and Tester (BTDAT) was designed as a branch office teleprocessing (TP) specialist's tool. The purpose of this tool is to trap transmit data and/or receive data for analysis and to further use this data to exercise local or downline TP devices.

The BTDAT consists of two 32K bit memories and various registers and controls to allow data in and out of these buffers.

6.3 NU DATA TESTER

The NU Data Tester (IBM PN 453637) is used to monitor and isolate problems between data terminal equipment and data transmission equipment that follow the standards outlined in EIA Standard RS-232-c.

Seven EIA leads are displayed for continuous monitoring: transmit and receive data, data terminal ready, data set ready, request to send, clear to send, and carrier detected.

This tester connects in series with the EIA/CCITT data set cable and the 25-pin data set connector. The CE may then monitor, measure, or control the leads on the data set interface.

6.4 PT-2 ATTACHMENT TO NON-EIA INTERFACES

This procedure will allow attachment of a PT-2 to the 3274 Models 51C and 52C in such a way as to allow monitoring of transmit and receive data when a Non-EIA Interface is present.

1. Assemble PT-2 using TP Line Monitor (TPLM) Adapter.
2. Set Optional Probe Switches on TPLM Adapter to the SLT/VTL (UP) position.
3. Attach optional probes as follows:

TPLM	Line Name
#2	Xmit Data
3	Req to Send
4	Clear to Send
5	Xmit Clock
6	Rec. Data
7	Carrier Detect
8	Receive Clock
#9	Data Set Ready

The appropriate tab pins are shown in Figure 6-1.

4. Load TP Tool Program and enter appropriate responses to questions displayed.
 - a. Specify Product Clock
 - b. When running above 9600 bps (via V.35, X.21 or DDSA features) it is necessary to use the High-Speed Monitor Function of the PT-2. Refer to PT-2 Line Monitor Manual, Section 6.

CCA/HPCA Location A1Q2		EIA/*DDSA/V.35/*X.21/**Greater than Location A2P2	1200-bps Integrated Modem
U04	Xmit Data	D04	*Can run only up to 9600 bps unless High-Speed Monitor Function
S10	Req to Send	D02	
S12	Clear to Send	D13	
U11	Xmit Clock	B07	
U13	Rec Data	B10	
S04	Carrier Detect	B12	
U10	Receive Clock	B08	
S13	Data Set Ready	B13	**For Greater than 1200-bps Integrated Modem location is A2E2
U12	Data Terminal Rdy	B02	

Figure 6-1. TPLM Tab Pin Locations

Appendix A. Support Structure Information Form

CE Name _____ CE Telephone Number _____

Customer Name _____ Customer Telephone Number _____

Customer Number _____ Branch Office Number _____

Host System Type _____ Subsystem Type/Model _____

Incident Machine Type/Model _____

Serial Number _____ EC Level _____

Installed Microcode _____

Part Number _____ EC Level _____

REAs 1 _____ 2 _____ 3 _____ 4 _____

 5 _____ 6 _____ 7 _____ 8 _____

If your subsystem is a local configuration, include the following information:

Control unit type/model _____

Channel type: Selector _____ Byte _____ Block _____

Channel cable length (max 200 ft) _____

Control unit position on channel (1-8) _____

Last unit on channel? Yes _____ No _____

If your subsystem is a remote configuration, include the following information:

Multiplexer type: 270x _____ 370x _____ OEM _____

Line type: Point to point _____ Multipoint _____ Switched _____

Number of wires: 2 _____ 4 _____

Modem type: IBM _____ OEM _____

Line speed (baud): 1200 _____ 2000 _____ 2400 _____ 4800 _____

 7200 _____ 9600 _____ Other _____

Communications adapter type: CCA _____ HPCA _____ EIA _____

 SLA _____ Other (specify) _____

Channel type: Selector _____ Byte _____ Block _____

Channel cable length (max 200 ft): _____

Control unit position on channel (1-8) _____

Control unit priority: High _____ Low _____

Multichannel switch: Yes _____ No _____

Number and type of attached devices.

Number of ports _____ Total number of displays _____

Number by IBM machine type:

3277-1 _____	3278-1 _____
3277-2 _____	3278-2 _____
	3278-3 _____
	3278-4 _____

Total number of printers _____

Number by IBM type:

3284-1 _____	3286-1 _____	3287-1 _____	3288-2 _____
3284-2 _____	3286-2 _____	3287-2 _____	3289-1 _____
3284-3 _____			3289-2 _____

Subsystem features.

Subsystem machine type/model _____

List appropriate features _____

Does subsystem machine have any RPQs? Yes _____ No _____

If yes, list RPQs _____

If the incident machine and the subsystem machine are not the same, list the appropriate features and/or RPQs for the incident machine.

Incident machine type/model _____

Features _____

Does the incident machine have RPQs? Yes _____ No _____

If yes, list the RPQs _____

Host system program support information.

SCP type: OS _____ DOS _____ VS1 (SVS) _____ VS2 (MVS) _____ VM _____
APL _____ Other (specify) _____ Release level _____

Access method: BTAM _____ TCAM _____ TCAM-E _____ VTAM _____
GAM _____ Other (specify) _____ Version number _____

Application type: APLSV _____ CICS _____ CMS _____ TSO _____ IMS _____
MIS _____ Other (specify) _____ Version number _____

NCP type (370x only) _____ Release level _____

PEP type (270x only) _____ Release level _____

EP type (270x only) _____ Release level _____

General description of problem and the maintenance aids used.

Incident machine type/model _____

Brief description of problem: _____

Tools used: _____

Appendix B. 3274 Models 51C and 52C Error Codes

The three-digit error codes (nnn) are displayed in the operator information area on the display and follow the Machine Check (X), Program Check (X PROG), and Communication Check (X) symbols. These codes further define the error conditions indicated by the error symbols.

The first digit of the nnn code indicates the type of error that occurred, as follows:

nnn Code	Type of Error
2XX, 3XX	Machine check
4XX	Program check
5XX	Communication check

For example, a Communication Check symbol followed by an nnn code of 532 (X 532) indicates that the BSC line is idle.

This appendix lists the nnn in numeric order with the following information to assist you in problem determination:

- Error description
- 8 4 2 1 indicator setting
- Test number used to retrieve the logout
- The error statistic counter that is incremented
- Where the code is displayed (one/all displays)
- Indication displayed in the operator information area on the display (X 203)
- Probable cause and action to be performed
- Sense information
- Application features associated with the error condition

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
202	Interrupt Threshold Exceeded <ul style="list-style-type: none"> Terminal with 202 error display caused keystroke/status buffer overflow. The terminal is disabled. 	—	nn/1	—	—	—	X	—	<ul style="list-style-type: none"> POR device 	<ul style="list-style-type: none"> Internal terminal error (see device MIM) 	081C	DC/US	Category A Terminal
203	Feature Bus Error <ul style="list-style-type: none"> Feature-bus error at terminal. 	—	nn/1	6	—	—	X	X $\&$ 203	<ul style="list-style-type: none"> Reset key Retry operation 	<ul style="list-style-type: none"> Terminal Feature circuitry failure (see device MIM) 	—	—	Features
204	Device Check <ul style="list-style-type: none"> Terminal-buffer parity error was detected. Control unit clears buffer. If recovery not successful, terminal is disabled. 	—	nn/1	4	—	—	X	X $\&$ 204	<ul style="list-style-type: none"> Reset key Host recovery POR device If disabled 	<ul style="list-style-type: none"> Terminal buffer parity error (see device MIM) 	028B 081C	DC/US DC/US	Category A Terminal
205	Unsupported Feature Address Attached <ul style="list-style-type: none"> Feature is not supported with configuration selected at customizing time, <i>or</i> Feature did not respond when the terminal was initialized. 	—	nn/1	—	—	—	X	X $\&$ 205	<ul style="list-style-type: none"> Reset key Retry operation 	<ul style="list-style-type: none"> Verify customizing selected feature Reminder is on if display can be used 	—	—	Feature
206	Invalid Feature Response on Initialization <ul style="list-style-type: none"> Invalid response from feature during initialization. Terminal remains enabled, <i>but</i> all features are disabled. 	—	nn/1	6	—	—	X	X $\&$ 206	<ul style="list-style-type: none"> Reset key Retry operation 	<ul style="list-style-type: none"> Feature did not initialize properly (see device MIM) 	—	—	Feature

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
207	Lost Operation Completed <ul style="list-style-type: none"> Control unit started on operation to terminal that required deferred ending status (Op Complete). Over 1 second elapsed, and Op Complete not received. The terminal is disabled. 	—	nn/1	5	—	—	X	✗ 207	<ul style="list-style-type: none"> POR device 	<ul style="list-style-type: none"> Terminal failure (see device MIM) Loss of communication with device (Coax) 	081C	DC/US	Category A Terminal
208	Invalid Operation Completed <ul style="list-style-type: none"> Asynchronous Ending Status received when no operation. 	—	nn/1	5	—		X	✗ 208	<ul style="list-style-type: none"> Reset key Retry operation 	<ul style="list-style-type: none"> Terminal error (see device MIM) 	—	—	Category A Terminal
209	Command Queue Failed <ul style="list-style-type: none"> A Cycle Sharing command or data queue failed in transmission. Operation is retried, and counter is incremented. If retry fails, terminal is disabled. 		nn/1	1 or 2	—		X	✗ 209	<ul style="list-style-type: none"> POR device 	<ul style="list-style-type: none"> CU to terminal communication failure (Coax) 	081C	DC/US	Category A Terminal
210	Invalid Keyboard Attached <ul style="list-style-type: none"> The ID of the terminal's keyboard does not match the types selected during customizing. No table is available for this keyboard type. 		nn/1	—	—		X	✗ 210	<ul style="list-style-type: none"> Reset key Retry operation 	<ul style="list-style-type: none"> Verify keyboard type selected in customizing 	—	—	Type A Adapter
211	Invalid Status Received <ul style="list-style-type: none"> Invalid combination of status bits received from terminal. Keyboard is locked. If Reset key fails, terminal is disabled. 		nn/1	5	—		X	✗ 211	<ul style="list-style-type: none"> Reset key Retry operation POR device 	<ul style="list-style-type: none"> Terminal error (see device MIM) 	081C	DC/US	Category A Terminal

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
212	Invalid Scan Code Received <ul style="list-style-type: none"> Invalid scan code was received from this terminal. Keyboard is locked. 		nn/1	—	—		X	✘ 212	<ul style="list-style-type: none"> Reset key Retry operation 	<ul style="list-style-type: none"> Terminal keyboard error Customization error (see device MIM) 	—	—	Category A Terminal Keyboard
222	Invalid Selector Pen Status or Command Queue Failure <ul style="list-style-type: none"> Illegal status received from selector pen or Selector pen I/O operation failed after retry. 		nn/1	6	—		X	✘ 222	<ul style="list-style-type: none"> Reset key Retry operation 	<ul style="list-style-type: none"> Selector lightpen error (see device MIM) 	—	—	Category A Terminal Light Pen
223	ECS Adapter Buffer Parity Error <ul style="list-style-type: none"> Control unit clears buffer and notifies host. If clear does not eliminate parity check, the terminal is disabled. 		nn/1	6	—		X	✘ 223	<ul style="list-style-type: none"> Host recovery Retry operation POR device if disabled 	<ul style="list-style-type: none"> ECS adapter buffer (see device MIM) 	082B	DC/US	ECS Feature
224	Invalid MSR or MHS Status or Command Queue Failure <ul style="list-style-type: none"> Illegal status received from Mag Strip Reader or MHS. MSR or MHS I/O operation failed after retry. 		nn/1	6	—		X	✘ 224	<ul style="list-style-type: none"> Reset key Retry operation 	<ul style="list-style-type: none"> MSR MHS (see device MIM) 			Category A Terminal MSR or MHS
225	ECS Adapter Status/ Initialization Error <ul style="list-style-type: none"> Device is disabled if not recoverable. 		nn/1	6	—		X	✘ 225	<ul style="list-style-type: none"> Reset key POR device if disabled 	<ul style="list-style-type: none"> ECS adapter error (see device MIM) 	081C	DC/US	Category A Terminal

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
226/ 227	ECSA Feature Command Queue Failure <ul style="list-style-type: none"> ● A cycle-sharing command/ data operation failed in transmission. ● Operation is retried, and counter is incremented. ● If retry fails, the terminal is disabled. 		nn/1	1 or 2	—		X	X 226 or X 227	● Device POR	● Transmission error while communicating with ECS Feature	081C	DC/US	Category A Terminal ECS Feature
228	Convergence Backup Store Failure		nn/1	6				X 228	● Reset key ● Retry operation	● Battery failure (see device MIM)			3279 Color
229	Convergence Feature Memory Failure		nn/1	6				X 229	● Reset key ● Retry operation	● Convergence logic (see device MIM)			3279 Color
231	Printer Equipment Check <ul style="list-style-type: none"> ● Printer reported an unrecoverable error to the control unit. 		nn/1	6		—	X	—	● See Printer PDG	● Printer error	081C	EC/IR/US	Category A Printer
234	ECS without ROS	—	nn/1	—	—	—	X	X 234	● POR device ● At 3278 terminal, activate test switch from Normal to Test and back again	● The ECS adapter does not have the required ROS	—	—	Category A Adapter
270	Unrecoverable Machine Check <ul style="list-style-type: none"> ● The control unit detected an unrecoverable error from the Type B adapter. ● Type B adapter is disabled. ● Type A terminals are not affected. 	1010	A2/1	6	X	—	—	—	● IML	● Type B adapter logic	—	—	Type B Adapter

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
271	Adapter Disabled – Interrupt Threshold Exceeded <ul style="list-style-type: none">● Category B device exceeded interrupt threshold value within 1 second.● Type B adapter disabled.● Type A terminals are not affected.	1010	A2/1	–	X	–	–	–	● IML	● Type B device ● Use /3 test – bad device indicated by ‘–’ ● Device log for failing device should indicate 279			Category B Terminal
272	Unrecoverable Overrun <ul style="list-style-type: none">● Type B adapter requested data, the request was not serviced within control unit cycle steal I/O time, and recovery attempts were unsuccessful.	1010	A2/1	2	X	–	–	–	● Host recovery	● Type B adapter logic	082B	DC/US	Type B Adapter
273	Adapter Timeout <ul style="list-style-type: none">● Type B adapter did not return I/O operation ending status within 2 seconds.● Type B adapter is disabled.● Type A adapter is unaffected.	1010	A2/1	–	X	–	–	–	● IML	● Type B adapter logic	–	–	Category B Terminal
274	Solid Busy <ul style="list-style-type: none">● An EAU command sent to the terminal, and Busy condition does not clear.● Terminal is disabled because of error.		nn/1	–	X	–	–	–	● POR device	● Type B device error	081C	DC/US	Category B Terminal
275	Equipment Check and Printer Not Ready <ul style="list-style-type: none">● Printer has returned Sense of Equipment Check and Not Ready.		nn/1	6	X	–	–	–	● See Printer PDG	● Printer error	081C	EC/IR/US	Category B Printer
276	Equipment Check – Printer <ul style="list-style-type: none">● Printer has returned Sense of malfunction while printing.● Print-buffer contents not affected.		nn/1	5	X	–	–	–	● See Printer PDG	● Printer error	082B	EC/US	Category B Printer

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
277	Device Check <ul style="list-style-type: none"> Device buffer parity error. Host error recovery should clear error. Device disabled if recovery is unsuccessful. 		nn/1	4	X	-	-	-	<ul style="list-style-type: none"> Host recovery POR device 	<ul style="list-style-type: none"> Type B device buffer 	082B	DC/US	Category B Terminal
278	Coax Parity <ul style="list-style-type: none"> Parity error while communicating with device via coax. Device disabled if retry fails. 		nn/1	2	X	-	-	-	<ul style="list-style-type: none"> Host recovery POR device 	<ul style="list-style-type: none"> Coax Device error Type B Dr/Rcwr 	081C	DC/US	Type B Adapter
279	Interrupt Threshold Exceeded <ul style="list-style-type: none"> Device exceeded interrupt threshold value. Type B adapter disabled. 	1010	nn/1	-	X	-	-	-	<ul style="list-style-type: none"> IML 	<ul style="list-style-type: none"> Device with nnn = 279 in log caused adapter to be disabled Type B device Search device error log to determine failing device. Use /3 test also. 	081C	DC/US	Category B Terminal
292	Illegal Entry in Error Queue <ul style="list-style-type: none"> Illegal combination of status in error queue for Type A adapter. 		A1/1	1	-	X	-	X 292	<ul style="list-style-type: none"> Reset key Retry operation 	<ul style="list-style-type: none"> Type A adapter 	-	-	Type A Adapter
293	Unconfigured Device <ul style="list-style-type: none"> Input received from a device address not in configuration table. 		A1/1	2	-	X	-	X 293	<ul style="list-style-type: none"> Reset key Retry operation 	<ul style="list-style-type: none"> Ensure that port address is included in customizing 	-	-	Type A Adapter
294	Unexpected End Cycle Share <ul style="list-style-type: none"> Control unit received End of Cycle Share when none was initiated. 		A1/1	3	-	X	-	X 294	<ul style="list-style-type: none"> Reset key Retry operation 	<ul style="list-style-type: none"> Type A adapter 	-	-	Type A Adapter
295	Invalid DCA Status <ul style="list-style-type: none"> Undefined combination of status bits received from Type A adapter. 		A1/1	4	-	X	-	X 295	<ul style="list-style-type: none"> Reset key Retry operation 	<ul style="list-style-type: none"> Type A adapter 	-	-	Type A Adapter

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
296	Lost Status <ul style="list-style-type: none"> Type A adapter keystroke/status buffers reached threshold (64CTR overflow). Status was lost during an attempted restart. 		A1/1	5	—	X	—	✗ 296	<ul style="list-style-type: none"> Reset key Retry operation 	<ul style="list-style-type: none"> Type A adapter 	—	—	Type A Adapter
297	Adapter Stopped and Was Restarted <ul style="list-style-type: none"> The DCA was detected to be stopped with active set for longer than allowed. The DCA was reset and successfully restarted. 		A1/1	6	—	X	—	✗ 297	<ul style="list-style-type: none"> Reset key Retry operation 	<ul style="list-style-type: none"> Type A adapter Type A device 	—	—	Type A Adapter
298	Command Queue Cycle Share Machine Check <ul style="list-style-type: none"> Machine check during command queue cycle share operation. Operation is retried. If unsuccessful, coax port disabled. Device status may have been lost. 		A1/1	7	—	X	—	✗ 298	<ul style="list-style-type: none"> POR device 	<ul style="list-style-type: none"> Type A adapter Type A device Use device logs and/3 test to isolate 	—	—	Type A Adapter
299	Non-Command Queue Cycle Share Machine Check <ul style="list-style-type: none"> Cycle Share machine check when no command queue operation was in progress. CU cannot isolate failing port. Device status may have been lost. 		A1/1	8	—	X	—	✗ 299	<ul style="list-style-type: none"> Reset key Retry operation 	<ul style="list-style-type: none"> Type A adapter 			Type A Adapter
2%% (2EE)	Unsupported Feature Attached <ul style="list-style-type: none"> Feature is not supported with configuration selected during customizing. Feature did not respond when terminal was initialized. Keyboard ID does not match control unit keyboard table. 		nn/1 displays as NNN of 2EE in error log display	—	—		X	✗ 2%%	<ul style="list-style-type: none"> Reset key Retry operation 	<ul style="list-style-type: none"> Machine features do not match configuration Feature logic error 	—	—	Features

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
310	CCA Machine Check <ul style="list-style-type: none"> Control logic to CCA adapter operation error; if retry OK, is transparent to adapter control code. If recovery attempts are unsuccessful, the error is posted and the adapter is disabled. 	1001	—	—	—	X	—	X 310	● IML	● CCA adapter	—	—	CCA-BSC
311	CCA Invalid Status <ul style="list-style-type: none"> Invalid basic status bit combination has been received from the CCA adapter. Adapter disabled. 	1001		—	—	X	—	X 311	● IML	● CCA adapter	—	—	CCA-BSC
320	CCA Machine Check (SDLC) <ul style="list-style-type: none"> Recovery attempts have failed. Adapter is disabled. 	1001	—	—	—	X		X 320	● IML	● CCA adapter	—	—	CCA-SDLC
321	CCA Invalid Status (SDLC) <ul style="list-style-type: none"> Invalid status has been received from the CCA. Adapter is disabled. 	1001		—	—	X		X 321	● IML	● CCA adapter	—	—	CCA-SDLC
326	X.21 HPCA Machine Check	1001	A0/1	4, 5 or 10	—	X		X 326	● IML	HPCA Failure: <ul style="list-style-type: none"> Invalid status from HPCA (X.21 – Ctr 4) Unexpected status condition from HPCA (X.21 – Ctr 10) Overrun – Receive overrun (Ctr 4) Underrun (Ctr 5) was received and recovery was unsuccessful 	—	—	X.21

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
330	HPCA Machine Check ● Recovery attempts have failed. ● Adapter is disabled.	1001 1001	—	—	—	X		X 330	● IML	● HPCA adapter	—	—	HPCA-SDLC
331	HPCA Invalid Status ● Invalid status has been received from the HPCA. ● Adapter is disabled.	1001	—	—	—	X		X 331	● IML	● HPCA adapter	—	—	HPCA-SDLC
332	HPCA Machine Check	1001	—	—	—	X	—	X 332	● IML	● HPCA adapter wrap failed. ● Adapter is disabled	—	—	Loop
333	LSA Failure	—	—	—	—	X	—	X 333	● IML	● LSA failure (Wrap Test) ● Adapter is disabled	—	—	Loop
334	CTS Transition or Shutoff	—	—	—	—	X		X 334 X 334	● IML	● LSA failure ● Three shutoffs rec'd from the host ● Adapter is disabled	—	—	Loop
335	DCE Error	—	—	—	—	X		X 335	● IML	● LSA failure ● Adapter is disabled	—	—	Loop
336	LSC Error	—	—	—	—	X		X 336	● IML	● LSC failure (wrap test) ● Connecting cable ● Adapter is disabled	—	—	Loop
381	Unrecoverable Control Logic Error ● Host communications disabled.	0010	A3/1	—	—	X		X 381	● IML	● Control logic ● Storage ● Microcode	—	—	All
390	Storage Parity Error ● Unrecoverable storage parity error. ● Host communications disabled.	0001 or 0011 through 0111	—	—		X		X 390	● IML	● Storage ● Control logic ● See Figure 2-8, of MIM, for storage card.	—	—	All

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
391	Control Logic Machine Check ● Unrecoverable control logic error. ● Host communications disabled.	0010 or 1101	—	—		X		✘ 391	● IML	● Control logic ● Storage ● Microcode	—	—	
392	Control Storage Error (Model 52C)	0111	A2/1	—	—		X	✘ 392	● Reset key ● Retry operation	Replace card S2**	—	—	Model 52C
393	Control Storage Error (Model 52C)	0111	A2/1	—	—		X	✘ 393	● Reset key ● Retry operation	Replace card T2**			Model 52C
394	Control Storage Error (Model 52C)	0111	A2/1	—	—		X	✘ 394	● Reset key ● Retry operation	Replace card U2**	—	—	Model 52C
395	Control Storage Error (Model 52C)	0111	A2/1	—	—		X	✘ 395	● Reset key ● Retry operation	Replace card V2**	—	—	Model 52C
397	Encrypt/Decrypt Adapter Permanent Error ● All attempts for recovery have been exhausted. ● Adapter disabled. ● Non-Encrypt/Decrypt operations may be run.	1110	A3/1	3	—		X	✘ 397	● IML	● Encrypt/Decrypt logic	0848	—	Encrypt/Decrypt
398	Encrypt/Decrypt Parity Error ● Master key parity error. ● Retry attempts failed. ● Adapter is disabled. ● Non-Encrypt/Decrypt operations may be run.		A2/1	9	—		X	✘ 398	● IML ● Enter master key	● Weak or defective battery ● Refer to master key entry and verification procedure.	0848	—	Encrypt/Decrypt
399	Encrypt/Decrypt Adapter Failure ● Retry attempts failed. ● Adapter is disabled. ● Non-Encrypt/Decrypt operations may still be run.		A2/1	10	—		X	✘ 399	● IML	● Encrypt/Decrypt logic	0848		Encrypt/Decrypt

*Where nn = port ID = 00-11

**See MIM, Figure 2-8, code 0111.

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
401	Command Reject ● Invalid command received from host. ● See Note 1.	—	A0/1	—	—	—	X	— X PROG 401	● Host recovery ● Reset key ● Retry operation	● Host has sent invalid command.	1003	Com Rej	All Models
402	Invalid ID Address ● Or out-of-range buffer. ● SNA generates X'1005', parameter error. ● See Note 2.	—	—	—	—		X	— X PROG 402	● Host recovery ● Reset key ● Retry operation	● Host has sent invalid order parameters.	1005	Op Ck	BSC SDLC
403	Data After Read/Read Modified/Equ Invalid or Out of Range ● Invalid or out-of-range data. ● SNA generates X'1003', Function Not Supported (see Note 1)		nn/1	—	—	—	X	— X PROG 403	● Host recovery ● Reset key ● Retry operation	● Host has sent data after RD, Rd mod, EAU command.	1003	Op Ck	BSC SDLC
404	SBA/RA/EAU or SF Order Without Valid Parameters. ● BSC generates a Sense Operation Check; SNA generates X'1005', Parameter Error (see Note 2)		nn/1	—	—	—	X	— X PROG 404	● Host recovery ● Reset key ● Retry operation	● Host has sent an order (SBA, RA, EAU, or SF) without required data bytes.	1005	Op Ck	BSC SDLC
405	Invalid Copy Command ● BSC generates an operation check.		nn/1	—	—	—	X	— X PROG 405	● Host recovery ● Reset key ● Retry operation	● Host has sent a copy command with invalid parameters.	—	Op Ck	CCA-BSC
406	Invalid Command Sequence ● Invalid command sequence was detected.		nn/1	—	—	—	X	X PROG 406	● Reset key ● Retry operation	● A CCW was chained to a write CCW that had the start print bit set in the WCC.	—	Op Ck	BSC

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
408	(BSC) Count Exceeded <ul style="list-style-type: none"> Adapter read buffer unavailable. Sense/status set to OPCHECK and EOT sent to host. 		A0/1	10	—	—	X	✗ PROG 408	<ul style="list-style-type: none"> Reset key Retry operation 	<ul style="list-style-type: none"> 3274 unable to handle host data stream Data stream has excessive program tab orders 	—	Op Ck	BSC
411	RU Length Error <ul style="list-style-type: none"> LU1 RU is greater than BIND specification. 		nn/1	—	—	—	X	✗ PROG 411	<ul style="list-style-type: none"> Reset key Retry operation 	<ul style="list-style-type: none"> Host software 	1002	—	SDLC
412	Short Record <ul style="list-style-type: none"> Program check. A 'short' record was detected. Control unit sends SNA a negative response of X'1002', RU length error. 		nn/1	—	—	—	X	✗ PROG 412	<ul style="list-style-type: none"> Reset key Retry operation 	<ul style="list-style-type: none"> Host software 	1002		SDLC
413	Function Not Supported <ul style="list-style-type: none"> Crypto verification (CRV) received, but no crypto session has been established. See Note 1. 	—	nn/1	—			X	✗ PROG 413	<ul style="list-style-type: none"> Reset key Retry operation 	<ul style="list-style-type: none"> Host software Procedural error 	1003	—	SDLC Encrypt/ Decrypt
414	Encrypt/Decrypt Data Error <ul style="list-style-type: none"> SNA program check. Invalid pad count or non-modulo-8 RU has been received during an Encrypt/Decrypt session. 		nn/1	—	—	—	X	✗ PROG 414	<ul style="list-style-type: none"> Reset key Retry operation Inform Host support program Non-Encrypt/Decrypt operations may be run 	<ul style="list-style-type: none"> Host software Procedural error 	1001	—	SDLC Encrypt/ Decrypt

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
420	Exception Response Not Allowed ● SNA program check	—	nn/1	—			X	✗ PRG 420	<ul style="list-style-type: none"> Reset key Retry operation Inform Host support program 	<ul style="list-style-type: none"> Host has sent invalid or incorrect data LIC carried exception response when BIND specified definite response 	4006	—	SDLC
421	Definite Response Not Allowed ● SNA program check	—	nn/1	—			X	✗ PRG 421	<ul style="list-style-type: none"> Reset key Retry operation Inform Host support program 	<ul style="list-style-type: none"> Host has sent invalid or incorrect data LIC carried definite response when BIND specified exception response 	4007	—	SDLC
422	No Response Not Allowed ● Program check	—	nn/1	—			X	✗ PRG 422	<ul style="list-style-type: none"> Reset key Retry operation Inform Host support program 	<ul style="list-style-type: none"> Host software 	400A	—	SDLC
423	FI (Format Indicator) Bit Not Allowed ● Program check	—	nn/1	—			X	✗ PRG 423	<ul style="list-style-type: none"> Reset key Retry operation Inform Host support program 	<ul style="list-style-type: none"> Host software 	400F	—	SDLC
430	Sequence Number Error ● SNA program check	—	nn/1	—			X	✗ PRG 430	<ul style="list-style-type: none"> Reset key Retry operation Inform Host support program 	<ul style="list-style-type: none"> Host software 	2001	—	SDLC
431	Chaining Error ● SNA program check	—	nn/1	—	—		X	✗ PRG 431	<ul style="list-style-type: none"> Reset key Retry operation Inform Host support program 	<ul style="list-style-type: none"> Host software Brackets incorrectly used 	2002	—	SDLC

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
432	Bracket Error ● SNA program check	—	nn/1	—	—		X	✗ PROG 432	<ul style="list-style-type: none"> ● Reset key ● Retry operation ● Inform Host support program 	<ul style="list-style-type: none"> ● Host software ● Brackets incorrectly used 	2003	—	SDLC
433	Data Traffic Reset ● SNA program check	—	nn/1	—	—		X	✗ PROG 433	<ul style="list-style-type: none"> ● Reset key ● Retry operation ● Inform Host support program 	<ul style="list-style-type: none"> ● Host software 	2005	—	SDLC
434	Half-Duplex Error (Direction Error) ● SNA program check	—	nn/1	—	—		X	✗ PROG 434	<ul style="list-style-type: none"> ● Reset key ● Retry operation ● Inform Host support program 	<ul style="list-style-type: none"> ● Host software ● Normal Flow request was received by SNA while in half-duplex Send state. 	2004	—	SDLC
439	Encrypt/Decrypt Protocol Violation ● SNA program check	—	nn/1	—	—		X	✗ PROG 439	<ul style="list-style-type: none"> ● Reset key ● Retry operation ● Inform Host support program ● Non-Encrypt/Decrypt operations may be run 	<ul style="list-style-type: none"> ● Host software ● An invalid CRU has been received. 	2009	—	SDLC Encrypt/Decrypt
440	Session Limit Exceeded ● SNA program check	—	nn/1	—	—			none	<ul style="list-style-type: none"> ● Reset key ● Retry operation ● Inform Host support program ● Non-Encrypt/Decrypt operations may be run 	<ul style="list-style-type: none"> ● Host software 	0805	—	SDLC

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
441	Bracket Bid Reject No Ready to Receive (RTR) Returned or Receiver in Transmit ● SNA program check	—	nn/1	—	—			none	● Reset key ● Retry operation ● Inform Host support program ● Non-Encrypt/Decrypt operations may be run	● Host software	0813 or 081B	—	SDLC
442	Request Not Executable ● SNA program check ● Function request cannot be executed because of a permanent hardware error.	—	nn/1	—	—			✗ PROG 442	● Device POR	● Terminal error - refer to 2nn portion of /1 test.	081C	—	SDLC
443	Change Direction Required ● SNA program check	—	nn/1	—	—		X	✗ PROG 443	● Device POR	● Host software ● Request required a Normal Flow reply, but SNA in Receive state.	0829	—	SDLC
444	Session Already Bound ● SNA Program Check	—	nn/1	—	—			—	● Device POR	● Host software	0815	—	SDLC
445	ACTLU not supported	—	xx/1	3	—		X	✗ PROG 445	● Press Reset	● Invalid ACTLU parameters	081C	—	SNA
450	Bind Reject-Profile Error ● SNA program check: invalid session parameter.	—	nn/1	—	—		X	✗ PROG 450	● Reset key ● Retry operation ● Inform Host support program	● Host software	0821	—	SDLC
451	Bind Reject-Primary Protocol Error ● SNA program check: invalid session parameter.	—	nn/1	—	—		X	✗ PROG 451	● Reset key ● Retry operation ● Inform Host support program	● Host software	0821	—	SDLC
452	Bind Reject-Secondary Protocol Error ● SNA program check: invalid session parameter.	—	nn/1	—	—		X	✗ PROG 452	● Reset key ● Retry operation ● Inform Host support program	● Host software	0821	—	SDLC

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
453	Bind Reject-Common Protocol Error ● SNA program check: invalid session parameter	—	nn/1	—	—		X	✗ PROG 453	● Reset key ● Retry operation ● Inform Host support program	● Host software	0821	—	SDLC
454	Bind Reject-Screen Size Spec. Error ● SNA program check: invalid session parameter	—	nn/1	—	—		X	✗ PROG 454	● Reset key ● Retry operation ● Inform Host support program	● Host software	0821	—	SDLC
455	Bind Reject-LU Profile Error ● SNA program check: invalid session parameter	—	nn/1	—	—		X	✗ PROG 455	● Reset key ● Retry operation ● Inform Host support program	● Host software	0821	—	SDLC
456	Bind Reject-LU1 Error ● SNA program check: invalid session parameter	—	nn/1	—	—		X	✗ PROG 456	● Reset key ● Retry operation ● Inform Host support program	● Host software	0821	—	SDLC
457	Bind Reject-Encrypt/Decrypt Parameter Error ● SNA program check		nn/1	—	—	—	X	✗ PROG 457	● Reset key ● Retry operation ● Inform Host support program ● Non-Encrypt/Decrypt operations may be run	● Host software ● Bind specification for Encrypt/Decrypt had an error in byte 26 or 27, Encrypt/Decrypt was specified, and the Encrypt/Decrypt feature is not present, or a CRV was specified in CRV invalid.	0821	—	SDLC Encrypt/ Decrypt

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
458	Bind Reject-Encrypt/Decrypt Test	—	nn/1	—	—		X	X PROG 458	<ul style="list-style-type: none"> Host recovery or Control Unit key must be changed (the customer's security administrator should be notified) Non-Encrypt/Decrypt operations may be run 	<ul style="list-style-type: none"> The test value (N) from the host does not match the one sent by the 3274. There is a master key mismatch between the host and the 3274. See <i>Planning and Setup Guide</i>. 	0821	—	SDLC Encrypt/ Decrypt
460	Printer Authorization Matrix Error	—		—	—		X	X PROG 460	<ul style="list-style-type: none"> Reset key Retry operation 	<ul style="list-style-type: none"> An invalid print matrix was sent from the host, or the Load key was hit at a time when the matrix was not on the screen. 			SNA BSC
470	Unsupported Order	—	—	—	—		X	X PROG 470	<ul style="list-style-type: none"> Reset key Retry operation Fix application program 	<ul style="list-style-type: none"> Host software error. An unsupported order was decoded in the SFAP data stream. 	100C	Op Ck	SNA BSC
471	SFAP (Structured Field and Attribute Processing) Data Stream Error	—	—	—	—		X	X PROG 471	<ul style="list-style-type: none"> Reset key Retry operation Fix application program 	<ul style="list-style-type: none"> Host software error. Refer to App C. 	1003 or 1005	Op Ck	SNA BSC
472	Read Partition Structured Field State Error	—	—	—	—		X	X PROG 472	<ul style="list-style-type: none"> Reset key Retry operation Fix application program 	<ul style="list-style-type: none"> Host software error. See Appendix C. 	0871	Op Ck	SNA BSC

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
473	PS Addressing Error	—	—	—	—		X	X PROG 473	<ul style="list-style-type: none"> Reset key Retry operation Fix application program 	<ul style="list-style-type: none"> Host software error. 	084C	Op Ck	SNA BSC
474	No Extended DCB Configured for This Device	—	—	—	—		X	X PROG 474	<ul style="list-style-type: none"> SFAP data stream should not be sent to this device 	<ul style="list-style-type: none"> SFAP data stream send — no extended DCB available. 	1003	Op Ck	SNA BSC
488	Invalid Data Stream in Kanji/Chinese field	—	nn/1	—	—		X	X PROG 488	<ul style="list-style-type: none"> Reset key Retry operation Inform Host support program 	<ul style="list-style-type: none"> Host software 	1003	—	Model 52C
489	Invalid Data Stream in Kanji/Chinese field	—	nn/1	—	—		X	X PROG 489	<ul style="list-style-type: none"> Reset key Retry operation Inform Host support program 	<ul style="list-style-type: none"> Host software 	1005	—	Model 52C
498	Negative Response Received <ul style="list-style-type: none"> SNA program check No SNA sense returned 	—	nn/1	—	—		X	X PROG 498	<ul style="list-style-type: none"> Reset key Retry operation Inform Host support program 	<ul style="list-style-type: none"> Host software 	—	—	SDLC
499	Exception Request <ul style="list-style-type: none"> SNA program check No SNA sense returned 	—	nn/1	—	—		X	X PROG 499	<ul style="list-style-type: none"> Reset key Retry operation Inform Host support program 	<ul style="list-style-type: none"> Host software 	—	—	SDLC
501	<ul style="list-style-type: none"> 3274 Data Set Ready Line Dropped 	—	A0/1	— (SDLC) 9 (SDLC)	—	X		X 501	<ul style="list-style-type: none"> Indicator is reset when DSR is restored Reset keyboard Retry operation 	<ul style="list-style-type: none"> Missing DSR Check data set Check modem cable wrap switch 	—	—	SDLC, BSC
	<ul style="list-style-type: none"> 3274 Loop LOCAL/COMMUNICATE Switch in LOCAL 	—	—	—	—	X		X 501	<ul style="list-style-type: none"> Set LOCAL/COMM Switch to COMM 	<ul style="list-style-type: none"> LOCAL COMM Switch in LOCAL 	—	—	Loop

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
502	Clear to Send Not Present <ul style="list-style-type: none"> ● Clear to Send not present while request to send was on ● Adapter indicates DCE error or write timeout ● DSR is up 	—	A0/1	—	—	X	—	X 502	<ul style="list-style-type: none"> ● Reset key ● Retry operation 	<ul style="list-style-type: none"> ● Check data set ● Run wrap test ● Check -8.5 V,F4 	—	—	BSC SDLC
504	Switched Network Connection Required	—	—	—	—	X	—	X 504	<ul style="list-style-type: none"> ● A connection should be initiated from the control unit or host. 	<ul style="list-style-type: none"> ● Initial status of Control Unit at IML. ● Operator Disconnected. ● DISC received from network. ● Three idle time-outs in succession. 	—	—	Switched Network
505	3274 Disconnected from Network.	—	—	—	—	X	—	X 505	<ul style="list-style-type: none"> ● SNRM required from network 	<ul style="list-style-type: none"> ● Normal state after IML or disconnect has been received 	—	—	SNA
507	No Carrier	—	A0/1	14	—	X	—	X 507	<ul style="list-style-type: none"> ● Refer to nnn code 515,332, 333, or 336. 	<ul style="list-style-type: none"> ● Carrier down (no RLSD) for the last 4 seconds. ● Wrap tests are performed if IML tests are successful. Beaconing is initiated. See nnn code 515. ● If wrap tests fail, 332, 333, or 336 is displayed. 	—	—	Loop
508	CNFG RCVD —Monitor Mode	—	—	—	—	X	—	X 508	<ul style="list-style-type: none"> ● CNFG command or Reset or Clear required from host to return to online. 	<ul style="list-style-type: none"> ● CNFG command from host indicated to enter Monitor mode. 	—	—	Loop

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
509	CNFG RCVD Suppress Carrier Mode	-	-	-	-	X	-	X 509	<ul style="list-style-type: none"> • CNFG command or Reset or Clear required from host to return to online. 	<ul style="list-style-type: none"> • CNFG command from host indicated to suppress carrier. • Station suppresses carrier. 	-	-	Loop
510	Physical Unit Not Active	-	-	-	-	X	-	X 510	<ul style="list-style-type: none"> • Host issue ACTPU • Retry operation 	<ul style="list-style-type: none"> • ACTPU is required from host 	-	-	BSC SDLC
515	Beaconing	-	-	-	-	X	-	X 515	<ul style="list-style-type: none"> • Carrier from the loop is required. 	<ul style="list-style-type: none"> • A "no carrier" condition was detected on the loop. See nnn code 507. • Loop tests were successfully run. • Beacon commands were transmitted, and carrier is monitored. • The loop is performing problem determination. 	-	-	Loop
518	Segmenting Error <ul style="list-style-type: none"> • The terminal is closed and reopened. • All physical and logical units are deactivated. 	-	-	-	-	X	-	X 518	<ul style="list-style-type: none"> • An SNRM is required from the host 	<ul style="list-style-type: none"> • An SNA segment was received with improper sequencing in the TH MPF bits. 	-	-	SDLC

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
519	Count Exceeded/Wrong Length Message	—	A0/1	12	—	X	—	X → 519	● Host recovery	<ul style="list-style-type: none"> ● CCA: Host sent a message larger than the control unit buffer. ● HPCA: Host sent a message larger than the CU buffer. Receive count will not be updated, causing retransmission by host. ● Improper buffer size specified in NCP. 	Com Rej	—	SDLC
520	Nonproductive Timeout	—	A0/1	1	—	X	—	X → 520	● Reset by receipt of a valid frame or a frame containing a poll.	<ul style="list-style-type: none"> ● No valid SDLC frames received in last 20-25 seconds. ● Line may be inoperable at "space" or valid data character. ● Communication network problem. 	—	—	SDLC Loop
521	Idle Timeout ● No activity on line for last 20 seconds (no flags received)	—	A0/1	2	—	X	—	X → 521	● Reset by receipt of a valid frame or a frame containing a poll.	<ul style="list-style-type: none"> ● No host activity ● Verify operational status of communication network. 	—	—	SDLC
522	Receive Overrun	—	A0/1	4	—	X	—	X → 522	● Receipt of a valid frame.	<ul style="list-style-type: none"> ● Control Unit Read-control buffer overflows. ● Line may be hung at space or invalid data character. 	—	—	Loop

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
525	Connection Problem <ul style="list-style-type: none"> Condition exists on lines that prevent establishing or reestablishing communication with host. Status is posted after 20 ROLs, 20 CRs, 20 XIDs, or 20 NSAs 	—	A0/1	6	—	X	—	X → 525	<ul style="list-style-type: none"> Host recovery 	<ul style="list-style-type: none"> Communication problem between host and control unit. 	—	—	SDLC
527	Write Timeout	—	A0/1	3	—	X	—	X → 527	<ul style="list-style-type: none"> IML 	<ul style="list-style-type: none"> Write timeout condition occurred. Wrap tests were run. If wrap fails, 332, 333, or 336 is displayed. Station is closed. 	—	—	Loop
528	Command Reject <ul style="list-style-type: none"> ALL PUs and LUs are deactivated. 		A0/1	9	—	X	—	X → 528	<ul style="list-style-type: none"> Host recovery SNRM required Inform Host support programmer 	<ul style="list-style-type: none"> Adapter received invalid NR sequence count in an information or supervisory frame with good FCS. Received command with data that has no data field defined. Received an undefined or non-implemented command field in a frame with good FCS. 	—	—	SDLC

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
529	DCE Error <ul style="list-style-type: none"> ● Unexpected communication error has occurred. ● Host adapter is disabled, and an attempt is made to enable it again. 		A0/1	10	—	X	—	✕ → 529	<ul style="list-style-type: none"> ● Host recovery ● SNRM required 	<ul style="list-style-type: none"> ● DCE error other than the loss of DSR (nnn 501) or of CTS (nnn 502). ● Run wrap test. ● Check modem. 	—	—	SDLC
530	Write Timeout <ul style="list-style-type: none"> ● Microcode has issued a command to the CCA, and, after 1 second, no acknowledgment has been received. ● In SDLC, host adapter is disabled and an attempt is made to enable it again. ● All PUs and LUs are deactivated. 		A0/1	11-HPCA CCA-SDLC 8-CCA-BSC	—	X	—	✕ → 530	<ul style="list-style-type: none"> ● Host recovery ● SNRM required 	<ul style="list-style-type: none"> ● DSR is OK. ● CTS may have dropped during transmission, or clocking signal is not available from modem. ● Run wrap test. ● Check modem. 	—	—	SDLC BSC
531	NAK Sent <ul style="list-style-type: none"> ● The contents of the screen are restored to their initial state on detection of the error. 		A0/1	1	—	—	X	✕ → 531	<ul style="list-style-type: none"> ● Host recovery ● Retransmit data ● The Communication Reminder will be turned off upon successful retry from the host. 	<ul style="list-style-type: none"> ● Adapter detected BCC error on a received message block. ● During a read operation, 3 seconds elapsed without receipt of SYN, ETX, or ETB. ● A forward abort (ENQ in text) or TTD (STX ENQ) is received. ● Verify proper operation of the communication network. 	—	—	BSC







*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
532	<p>BSC Line Idle</p> <ul style="list-style-type: none"> ● Adapter detected seven successive 3-second intervals without SYN characters on the line while in ADPREP mode (monitor line for poll or selection sequence) 		A0/1	—	—	X	—	X ↘ 532	<ul style="list-style-type: none"> ● Host recovery ● Reset by valid poll or selection sequence 	<ul style="list-style-type: none"> ● No host data being received. ● Run wrap test. ● Verify communication network operation. 	—	—	BSC
533	<p>ENQ Received</p> <ul style="list-style-type: none"> ● CCA was overrun during a read operation, and data was lost when the ENQ was received. The control unit will retransmit its last response. The host should retransmit the message that was lost, <i>or</i> ● ENQ character received while adapter was waiting for STX or SOH (entire message lost) ● Retransmit last response ● Host will retransmit last message 		A0/1	3	—	—	X	X ↘ 533	<ul style="list-style-type: none"> ● Host recovery ● Retransmit last message 	<ul style="list-style-type: none"> ● Communication error. ● CCA adapter. ● Run wrap test. 	—	—	BSC
534	<p>Control Unit Sent Is ENQ</p> <ul style="list-style-type: none"> ● Host did not return an ACK for last transmitted text block. ● Adapter sent 15 ENQs to attempt to solicit an ACK with no response ● EOT sent to host, <i>or</i> ● The control unit has acknowledged a selection sequence and has not seen a syn (pad syn) for 45 seconds. ● Adapter continues to monitor for a synchronization. 		A0/1	4	—	X	—	X ↘ 534	<ul style="list-style-type: none"> ● Host recovery ● A valid poll or selection will reset symbol ● Retry operation 	<ul style="list-style-type: none"> ● Host failed to respond. ● Communication failure. ● Run wrap test. 	—	—	BSC

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
535	15 NAKs Received <ul style="list-style-type: none"> Text block failed to reach host after 15 attempts. EOT is sent to host. Control unit enters ADPREP mode (line monitor for poll or selection). 	—	A0/1	5	—	X	—	X → 535	<ul style="list-style-type: none"> Host recovery Valid poll or selection will reset symbol Retry operation 	<ul style="list-style-type: none"> Communication failure between host and control unit. Verify communication network operation. Run wrap test. 	—	—	BSC
536	Error Description 15 Wrong Acknowledge <ul style="list-style-type: none"> Adapter received wrong ACK in response to text block transmission (ACK0 for ACK1 or vice versa), sent ENQ for repeat of ACK, and received wrong ACK 15 times. EOT is sent to host. Control unit enters ADPREP mode (line monitor for poll or selection). 	—	A0/1	6	—	X	—	X → 536	<ul style="list-style-type: none"> Host recovery A valid poll or selection will reset symbol Retry operation 	<ul style="list-style-type: none"> Host to control unit communication error (dropped a complete record during transmission). Host returns wrong ACK. 	—	—	BSC
555	Format Error	—	A0/1	2 (X.21)	—	X		X → 555	<ul style="list-style-type: none"> Reminder can be reset with COMM key to indicate X.21 state. 	<ul style="list-style-type: none"> CP (Call Progress) or line ID did not end with an IA +5 delimiter. 	—	—	X.21 Switched 51C
556	X.21 Timeout	—	A0/1	3 (X.21)	—	X		X → 556	<ul style="list-style-type: none"> Reminder can be reset with COMM key to indicate X.21 state. 	<ul style="list-style-type: none"> X.21 Network Timeout has occurred. 	—	—	X.21 Switched 51C

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
557	Not Ready	—	A0/1	5 (X.21)	—	X		X  557	<ul style="list-style-type: none"> Monitor Mode is entered waiting for DCE to become ready 	<ul style="list-style-type: none"> X.21 Network is not ready. Monitor Mode X  559 is entered. 	—	—	X.21 Switched 51C
558	Lost Data	—	A0/1	6 (X.21)	—	X		X  558	<ul style="list-style-type: none"> Reminder can be reset with COMM key to indicate X.21 state. 	<ul style="list-style-type: none"> Insufficient buffer space was available in the control unit for Call in Progress signals or Line ID from the network. 	—	—	X.21 Switched 51C
559	DCE Cleared	—	A0/1	7 (X.21)	—	X		X  559	<ul style="list-style-type: none"> Reminder can be reset with COMM key to indicate X.21 state. 	<ul style="list-style-type: none"> Clearing sequence has been executed in response to a network Clear request. 	—	—	X.21 Switched 51C
560	Not +/Bell	—	A0/1	11 (X.21)	—	X		X  560	<ul style="list-style-type: none"> Reminder can be reset with COMM key to indicate X.21 state. 	<ul style="list-style-type: none"> Abnormal condition detected while waiting for proceed or Select Incoming Call: <ul style="list-style-type: none"> More characters than expected were received. Character was other than expected. 	—	—	X.21 Switched 51C
561	Clear Timeout	—	A0/1	18 (X.21)	—	X		X  561	<ul style="list-style-type: none"> Reminder can be reset with COMM key to indicate X.21 state. 	<ul style="list-style-type: none"> Network Clearing Sequence did not terminate properly (T5 or T6 timeout). Monitor mode is entered — waiting for the DCE to become ready. 	—	—	X.21 Switched 51C

*Where nn = port ID = 00-11

nnn Code	Error Description	Operational Indicator	Test No. for Log*	Counter Incremented	Log Only	Displayed On		Indicator Displayed	Recovery	Probable Cause/Action	Sense Codes		Applicable Feature
						All	One				SNA	Non-SNA	
562	Compare Error	—	A0/1	1 (X.21)	—	X		X → 562	● Reminder can be reset with COMM key to indicate X.21 state.	● Control unit detected a mismatch between the signals on the input and output sides of the drivers/receivers	—	—	X.21 Switched 51C
565	Invalid Operation	—	A0/1	4	—	X	—	X PROG 565	● Press COMM key (goes to Call Ready State)	● Unknown network failure	—	—	X.21 Switched 51C
595	Monitor Mode	—	—	—	—	X		X → 595	● Control unit is waiting for DCE ready.	● Monitor mode was entered as a result of a Network Not Ready or a Compare error.	—	—	X.21 Switched 51C
599	Local Mode	—	—	—	—	—		X → 599	● Put control unit in Call Ready state with COMM key sequence.	● Control unit has entered local mode state as a result of a Local sequence.	—	—	X.21 Switched 51C

*Where nn = port ID = 00-11

Notes:

1. SNA generates code X'1003', function not supported:
 - Unsupported session control request
 - Unsupported data control request
 - Signal code not X'00010000'
 - Network control request
 - FM data stream
 - Invalid command: data after Read, RM, RMA, EAU
2. Parameter error — invalid address after SBA, RA, or EAU order (SBA, RA, EAU without parameters) or SCS parameter error.

Appendix C. Structured Field and Attribute Processing (SFAP) Data Stream Error Extensions

Bytes 170-174 of the extended device control block (DCB) are used as a log area for additional information. This complements the PROG 4nn numbers displayed when the error is detected. Bytes X'170, 171' contain the displacement in hexadecimal to the byte in the Write Structured Field that was found to be in error. (The WSF command equals byte 1.) Bytes X'172, 173' contain the displacement into the particular structured field where the error was detected. Byte X'174' contains the SF type of the SF that contained the error.

Figure C-1 correlates the extended data stream 4nn numbers, the values found in XDCB X'172-174', the SNA sense code, and a description of the error. OP check is the sense set for BSC in all cases.

Bytes 170-174 may be displayed in the following manner. Enter Test mode by pressing the ALT and TEST keys. Select the DCB in question by typing in AA/6 (four characters); AA is the coax port number in question (00-31). (If the device being used for the test is the port in question, /6 (two characters) will suffice.) Press the ENTER key. The display should now contain:

```
Line 1 AA/6 (same as input)
Line 2 00
Line 3 XXXX XXXX XXXX XXXX XXXX XXXX XXXX XXXX
Line 4 XXXX XXXX XXXX XXXX XXXX XXXX XXXX XXXX
Line 5 XXXX XXXX XXXX XXXX XXXX XXXX XXXX XXXX
Line 6 XXXX XXXX XXXX XXXX XXXX XXXX XXXX XXXX
```

where:

00 = The displacement from the start of the control block (in hexadecimal).

XXXX = The hexadecimal representation of the portion of the control block currently being displayed.

Press the PA1 key five times; line 2 should change to 40, 80, C0, 10, and then to 14. (The last two values drop the low-order digit and really represent X'100' and X'140'.) X'170'-174' are the first five bytes on line 6.

4nn	DCB-'X'		Sense	Error Description
	172	174		
470	----	--	1003	An unsupported order was decoded in the data stream.
471	0003	XX	1003	Unsupported structured field type.
471	----	--	1003	Advanced Data Stream (WSF) sent to a device without an ECSA feature.
471	0004	06	1003	Invalid Load Format addresses to PSS.
471	0007	06	1005	Out-of-range access to PSS (RAM out of range).
471	000A	06	1005	Invalid X-value for Load PSS.
	000B	06	1005	Invalid Y-value for Load PSS.
471	000C	06	1005	Section ID not supported (byte 11 not equal to 0).
471	0001	XX	1005	Invalid-length structured field.
471	XXXX	XX	1005	Invalid-partition ID.
471	0005	09	1003	Invalid mode in Set Reply mode.
471	0005	01	1003	Invalid operation in read partition (not query).
471	0005	06	1003	Alias out of legal range.
471	0006	06	1005	Invalid EBCDIC code point.
471	000D	06	1003	Byte 12, bits 0-4, 7 = 0
471	XXXX	XX	1005	Invalid reserved Bits.
472	----	--	0871	Read partition structured field state error. Improper sequence from host.
473	0007	06	084C	ECSA present, but PSS RAM addressed not physically present.
473	000D	06	084C	Color plane—invalid.
474	----	--	1003	No extended DCB configured for this device.
475	----	--	1001	WCC has Start Print bit set, but not last structured field.

Note: As part of overall extended-data-stream problem determination, the usage of the following functions should be kept in mind. If the device in question does not have an extended DCB (not enough allocated during customizing) the DCB display procedure (described above) will inhibit the keyboard with the minus function indicator on the fourth depression of the PA1 or ENTER key. If the device does not have an ECSA feature, Test 8 (Enter test mode, type in /8, hit enter) will inhibit the keyboard with a wrong number indicator. This is also true if Extended Data Stream microcode is not configured. If Extended Data Stream microcode is not configured, the above nnn numbers will not appear.

Figure C-1. SFAP Error Relationships

Appendix D. IBM 31SD Diskette Drive Maintenance

Safety Information

The CE Safety Practices, located at the front of this manual, should be reviewed before you service the 31SD Diskette Drive. To prevent personal injury and machine damage, observe all Danger and Caution notices, making sure you fully understand them.

AC voltages are present on the 31SD drive motor connector and capacitor terminals when the drive motor is running. The motor and the solenoid become hot after continuous use; let the parts cool before attempting servicing. The following Danger and Caution notices appear in this appendix in the sequence shown:

DANGER

Input AC voltage is present in the prime power box when the 3274 I/O (on/off) switch is in the O (off) position.

DANGER

Voltage is still present at the socket when the power cable is disconnected.

DANGER

High voltage may be present at the capacitor terminals.

CAUTION: The motor case becomes hot after continuous use.

This appendix contains the maintenance information needed to service the IBM 31SD Diskette Drive. It includes the service check, adjustment, removal, and replacement procedures for all field replaceable units (FRUs). It also includes information to help the customer engineer diagnose difficult and intermittent failures not found by the maintenance analysis procedures (MAPs).

A paragraph number precedes each paragraph title. These numbers are used as follows:

- The table of contents lists the paragraph numbers and titles.
- The MAPs (Appendix E) direct the customer engineer to maintenance procedures by paragraph number (for example, D.3.7.3, D.3.3.6, D.3.6.1).
- Steps in a procedure direct the customer engineer to another procedure by paragraph number.

Other information about the diskette drives is found in:

- Appendix E, IBM 31SD Diskette Drive Maintenance Analysis Procedures (MAPs)
- *The IBM Diskette General Information Manual, GA21-9182*

Note: *Tektronix, as used in this appendix, is a trademark of Tektronix, Inc.*










Contents

D.1 Introduction	D-7
D.1.1 General Description	D-7
D.1.1.1 Diskette Description	D-8
D.1.1.2 Diskette Insertion and Removal	D-9
D.1.1.3 Maintenance	D-10
D.1.1.4 Special Tools	D-10
D.1.2 Machine Characteristics	D-11
D.1.2.1 Physical Characteristics	D-11
D.1.2.2 Electrical Characteristics	D-11
D.1.2.3 Environmental Characteristics	D-12
D.1.2.4 Functional Characteristics	D-12
D.1.3 Safety	D-12
D.1.3.1 Personal Safety	D-12
D.1.3.2 Machine Safety	D-12
D.1.3.3 Diskette Safety	D-13
D.1.4 Diskette Drive Parts	D-14
D.2 Device Theory of Operation	D-17
D.2.1 Control Card Interface	D-17
D.2.2 Mechanical Operation	D-19
D.2.3 Typical Device Operation	D-19
D.2.4 Read/Write Principles	D-21
D.2.4.1 Write Data	D-21
D.2.4.2 Write Operation	D-22
D.2.4.3 Read Data	D-23
D.3 Maintenance	D-26
D.3.1 Collet/Flat Spring Assembly	D-26
D.3.1.1 Collet/Flat Spring Removal	D-26
D.3.1.2 Collet/Flat Spring Replacement	D-27
D.3.2 Head/Carriage Assembly	D-28
D.3.2.1 Head/Carriage Pressure Pad Removal and Replacement	D-28
D.3.2.2 Head/Carriage Service Check	D-29
D.3.2.3 Head/Carriage Adjustment	D-32
D.3.2.4 Head/Carriage Removal	D-34
D.3.2.5 Head/Carriage Replacement	D-34
D.3.3 Head Load Solenoid and Bail	D-38
D.3.3.1 Solenoid and Bail Service Check	D-38
D.3.3.2 Head Gap Service Check	D-40
D.3.3.3 Head Gap Adjustment	D-40
D.3.3.4 Bail Adjustment	D-40
D.3.3.5 Bail Removal	D-42
D.3.3.6 Bail Replacement	D-42
D.3.3.7 Solenoid and Idler Removal	D-42
D.3.3.8 Solenoid and Idler Replacement	D-42
D.3.4 AC Drive Parts	D-45
D.3.4.1 Drive Motor Removal	D-45
D.3.4.2 Drive Motor Replacement	D-45
D.3.4.3 Capacitor Removal	D-45
D.3.4.4 Capacitor Replacement	D-45
D.3.4.5 Drive Fan and Pulley Assembly Removal	D-47
D.3.4.6 Drive Fan and Pulley Assembly Replacement	D-47
D.3.5 Stepper Drive Parts	D-47
D.3.5.1 Stepper Motor Removal	D-47
D.3.5.2 Stepper Motor Replacement	D-47
D.3.5.3 Stepper Pulley and Clamp Removal	D-49
D.3.5.4 Stepper Pulley and Clamp Replacement	D-49
D.3.5.5 Drive Band Service Check	D-49
D.3.5.6 Drive Band Adjustment	D-49
D.3.5.7 Drive Band Removal	D-49
D.3.5.8 Drive Band Replacement	D-50
D.3.6 LED and PTX Assemblies	D-52
D.3.6.1 Diskette Speed Service Check	D-52
D.3.6.2 LED Output Service Check	D-54
D.3.6.3 LED Removal	D-54
D.3.6.4 LED Replacement	D-55
D.3.6.5 PTX Amplifier Service Check	D-55
D.3.6.6 PTX Removal	D-57
D.3.6.7 PTX Replacement	D-57
D.3.7 Diskette Drive Control Card	D-57
D.3.7.1 Control Card Removal	D-57
D.3.7.2 Control Card Replacement	D-57
D.3.7.3 Control Card Test Pins and Connector Pins	D-57

Abbreviations

A. ampere	LEDCP. light-emitting diode connector pin
A. symbol for AND logic (see legend)	MAP. maintenance analysis procedure
AC. alternating current	MFM. modified frequency modulation
AR. amplifier (see legend)	MIM. maintenance information manual
AR-DIFF. differentiator-amplifier (see legend)	μs. microsecond
B/M. bill of materials	mm. millimeter
C. Celsius	ms. millisecond
CE. customer engineer	mV. millivolt
DC. direct current	N. inverter
DET. detector (see legend)	ns. nanosecond
DR. driver (see legend)	PTX. phototransistor (see legend)
D1. diskette 1	PTXCP. phototransistor connector pin
D2. diskette 2 and 2D	R/W. read/write
F. Fahrenheit	rpm. revolutions per minute
FM. frequency modulation	SCP. solenoid connector pin
FRU. field replaceable unit	SMCP. stepper motor connector pin
HCP. head connector pin	TCP. test connector pin
Hz. hertz	V. volt
I/O CP. I/O connector pin	Vac. volts, alternating current
kg. kilogram	Vdc. volts, direct current
kHz. kilohertz	VFO. variable frequency oscillator
LED. light-emitting diode (see legend)	

Legend



Glossary

A. The logic block symbol for the AND function (see legend).

access lines. The pulses on these lines turn the stepper motor.

alcohol pad. A pad soaked with isopropyl alcohol.

alternative cylinders. Cylinders that can be assigned in place of primary cylinders that have failed.

alternative tracks. Tracks that can be assigned in place of primary tracks that have failed.

amplifier (AR). An electronic device that is used to increase voltage.

AR. See *amplifier*.

AR-DIFF. See *differentiator-amplifier*.

bail assembly. A mechanical arm that operates under control of the head load solenoid to load or release the read/write head load arm.

band. See *drive band*.

belt clearance slots. Grooves in the fan enclosure that permit the ac motor drive belt to turn without rubbing against the fan enclosure.

carriage. The part that carries the read/write head under control of the stepper motor drive.

CE. See *customer engineer*.

characteristics. Statements about the electrical, physical, or functional features of a machine that are not specifications.

clamp. A part used to lock another part.

clamped. Held tightly.

collet. The part that centers and holds the diskette to the drive hub.

cooling fan. A fan that makes the stepper motor cool.

crosstalk. Data bits sensed from one track while the read/write head is reading another track.

customer engineer (CE). A person who services IBM products in the field.

DET. See *detector*.

detector (DET). An electronic device that is used to recognize valid data in an electronic circuit.

differentiator-amplifier (AR-DIFF). An electronic circuit whose output signal is a function of the time rate of change of the input signal.

diskette 1. A diskette used for storing data on only one surface.

diskette 2. A diskette used for storing data on both surfaces.

diskette 2D. A diskette used for storing data on both surfaces with twice the bit density used on a diskette 2.

DR. See *driver*.

drive band. A metal band connected to the stepper motor pulley and the head/carriage assembly.

drive hub. A continuously running part that turns the diskette at 360 rpm.

driver (DR). An electronic circuit that converts a low-level logic voltage to the level needed to operate a stepper motor or a solenoid.

enclosure. The diskette drive motor cooling fan safety cover.

environmental. Pertaining to the environment.

eyelet. A small diameter ring at the end of a cable that makes it possible for the cable to be connected to a fixed bolt.

field replaceable unit. A part or an assembly that can be exchanged by the CE.

FM (frequency modulation). See *modulation*.

FRU. See *field replaceable unit*.

gain. The ratio of increase of output over input in an amplifier.

head/carriage. The unit that contains the read/write head.

hub. See *drive hub*.

ID. See *identifier*.

identifier (ID). A character or group of characters used to identify or name an item of data and possibly used to indicate some properties of that data.

inverter (N). An electronic circuit that inverts a signal (+ to -, or - to +).

isopropyl alcohol. A fluid used to clean some IBM parts.

jacket. A permanently attached cover that protects the diskette surface.

LED. See *light-emitting diode*.

light-emitting diode. An electronic part used as a source of light for a phototransistor.

MFM (modified frequency modulation). See *modulation*.

millivolt (mV). 0.001 volt.

modulation. The process of changing the amplitude and frequency of the read and write signals.

mV. See *millivolt*.

N. See *inverter*.

oscillator. A logic circuit that generates alternating current.

phototransistor (PTX). An electronic part used to sense the light of an LED.

preamp. See *preamplifier*.

preamplifier (preamp). A device that, by enabling a received wave to control a local source of power, can supply a larger copy of the necessary characteristics of the wave. Usually, a preamp is followed in the circuit by an amplifier.

PTX. See *phototransistor*.

read/write. Pertains to the function of reading data from and writing data to a diskette.

replaceable part. A part that can be reinstalled.

solenoid plunger. A moving part of the solenoid that operates the bail assembly to load and release the read/write head load arm.

stepper motor. The motor that steps the head/carriage assembly from track to track.

theory. Information that teaches how a device works.

tunnel erase circuit. An electronic circuit that is used to erase the edge of the track just recorded during a write operation. This erasing prevents crosstalk between tracks during later read operations.

unclamped. Released.

unloaded. Not loaded.

variable frequency oscillator. An electronic circuit that is used to synchronize the using system's reading circuits with the disk drive when it is performing a read operation.

VFO. See *variable frequency oscillator*.

welded. Connected together using heat (as in metal parts, such as adapter welded to band).

write/erase. Pertains to the function of writing data to and erasing data from a diskette.

D.1 INTRODUCTION

D.1.1 General Description

The IBM 31SD Diskette Drive is a direct-access, read/write, data storage device. This drive uses the flexible magnetic diskette for data entry, data exchange, and data storage.

The 31SD Diskette Drive, shown in Figure D-1, can read from and write to a diskette 1. The diskette drive reads and writes in frequency modulation (FM) only. If a diskette 2 or a diskette 2D is inserted into a 31SD Diskette Drive, the drive will never come ready.





Figure D-1. IBM 31SD Diskette Drive


D.1.1.1 Diskette Description

The IBM 31SD Diskette, shown in Figure D-2, is a thin, flexible disk, permanently protected in a jacket. Information is stored magnetically on the diskette surface, which is covered with magnetic recording material. The diskette is free to turn inside the jacket. As the diskette turns, the inner surface of the jacket cleans the diskette.

The diskette jacket has three holes. The first hole permits the diskette drive to turn the diskette, the second hole permits the read/write head to make contact with the diskette, and the third hole permits the phototransistor light to go through the index hole to sense the type of diskette. For storage, the diskette, which is permanently protected in a thin jacket, can be placed in an envelope. Data can be read from or written on only one side of the diskette.



Information is written on the diskette in tracks. A track is a circular path on the diskette surface. Information is magnetically written to or read from a track by a read/write head as the diskette turns. See Figure D-2.



Diskette




Figure D-2. 31SD Diskette

There are 77 tracks on each side of a diskette. Track 00, which is the outside track, is reserved as a label track and cannot be used for data. Tracks 75 and 76, the two tracks nearest the hub, are reserved as alternative tracks and can be used for data only if another track becomes damaged. There is a total of 74 tracks on one side of a diskette 1 available for recording data.

A sector is that part of a track used for one record of information.

A cylinder is defined as the tracks of a diskette that can be read from or written on without moving the read/write heads.

D.1.1.2 Diskette Insertion and Removal

To insert or remove a diskette, proceed as follows:

A. Diskette Insertion (See Figure D-3)

1. Turn the operator knob to the open position.
2. Remove the diskette from its envelope.
3. Place the diskette squarely into the diskette drive (with the label facing the knob).
4. Turn the operator knob to the closed position.

B. Diskette Removal (See Figure D-3)

1. Turn the operator knob to the open position.
2. Remove the diskette.
3. Insert the diskette into its envelope.




Figure D-3. Diskette Insertion

D.1.1.3 Maintenance

The diskette drive needs no planned maintenance. The MAPs guide the CE in diagnosing diskette drive failures; the MAPs also send the CE to maintenance procedures in this appendix when an adjustment, service check, or FRU replacement is needed.

The CE should verify a repair online using the system or device diagnostic programs.

The head/carriage assembly and the drive hub and pulley assembly are adjusted and tested at the factory. The head/carriage assembly can be exchanged in the field; the drive hub and pulley assembly cannot be exchanged in the field. If the track 40 adjustment surface or the drive hub and pulley assembly is damaged, the diskette drive should be exchanged.

D.1.1.4 Special Tools

The CE must use the following special tools (shown in Figure D-4):

- Timing pin **B** (part 5562019) to adjust or service the read/write head/carriage stepper motor pulley. (This part is supplied with each drive.)
- Force gauge (part 460870), **A**, to adjust or service-check the drive band tension.
- Spring (part 4240631), **D**, to keep the head/carriage in place against the thickness gauge when performing the head/carriage adjustments. (This part is supplied with each drive.)

Note: Spring must match view, **E**.

- Clip (part 4240632), **C**, to keep the thickness gauge in contact with the track 40 adjustment surface.




Figure D-4. 31SD Special Tools

D.1.2 Machine Characteristics

D.1.2.1 Physical Characteristics

The 31SD diskette weighs 5.0 kg (11.0 pounds) and has a speed of 360 rpm. See Figure D-5 for other physical characteristics.

D.1.2.2 Electrical Characteristics

The system supplies all the power needed to operate the diskette drive, which includes:

- All the following:

Logic Voltage (dc)	Maximum Operating Current (A)	Tolerance (%)
-5	0.08	±10
+5	0.50	±10
+24	0.50	±12

- A selection of the needed ac power from the following lists:

-60 Hz, single-phase, ac power

Input Voltage (V)	Input Voltage Range	Average Operating Current (A)
100	90-110	0.30
110	96.5-119	0.30
120	104-127	0.30
127	111-137	0.30
200	180-220	0.20
208	180-220	0.20
220	193-238	0.20
240	208-254	0.20

-50 Hz, single-phase, ac power

Input Voltage (V)	Input Voltage Range	Average Operating Current (A)
100	90-110	0.30
110	96.5-119	0.30
200	180-220	0.25
220	193-238	0.20
230	202-249	0.20
240	210-259	0.20




Figure D-5. 31SD Physical Characteristics

D.1.2.3 Environmental Characteristics

IBM diskette drives can be operated or stored in the following temperature and humidity ranges, shown in Figure D-6.

D.1.2.4 Functional Characteristics

The format of the data on a diskette is changed when the number of bytes written in a sector is changed. Diskettes are used with the formats shown in Figure D-7.

- The maximum number of formatted data bytes per diskette is shown in Figure D-8.
- Data rate: 250,000 bits (31,250 bytes) per second (FM).
- Cylinder-to-cylinder seek time: 5 ms, plus 35 ms for the head/carriage assembly to stop. (The total seek time is the number of cylinders the heads moved across multiplied by 5 ms, plus 35 ms.)
- Tracks per diskette side: 77 (cylinder 00 is the label cylinder; cylinders 01 through 74 are for data; cylinders 75 and 76 are reserved as alternative cylinders).

D.1.3 Safety

D.1.3.1 Personal Safety

The system or device supplies ac and dc power. Ac voltages are present on the drive motor connector and capacitor terminals in the diskette drive when the drive motor is turning.

Motor and solenoid cases become hot after continuous use; let the parts cool before servicing them.

The Danger and Caution notices throughout this appendix are personal safety precautions.

D.1.3.2 Machine Safety

Diskette drives can be damaged if they are not operated or serviced correctly. The Warning notices in this appendix are machine safety precautions.

Do not use IBM cleaning fluid or other cleaning fluids near plastic parts.

Never use damaged diskettes in a diskette drive. Diskettes that are physically damaged (creased or bent) or contaminated (by pencil marks, finger marks, or cleaning fluid) can cause data errors, equipment errors, or head damage.

	Temperature		Relative Humidity
	Celsius	Fahrenheit	
Operate (Powered On)	10° to 40.6°	50° to 105°	8% to 80%
Store (Powered Off)	10° to 51.7°	50° to 125°	8% to 80%

Figure D-6. Environmental Characteristics




Figure D-7. Data Formats

	Diskette 1
128 Bytes per Sector	246,272 ¹
256 Bytes per Sector	284,160
512 Bytes per Sector	303,104

¹ The total number of data bytes that can be stored on the diskette. The Basic Data Exchange Standards for exchanging information from one system to another using diskette 1 are:


- Use 128 bytes per sector.
- Do not use track 74.
- Use 26 sectors per track.

The total number of usable data bytes then becomes 242944.


Figure D-8. Maximum Number of Formatted Data Bytes

D.1.3.3 Diskette Safety


Return a diskette to its envelope when it is removed from the diskette drive.




Do not touch or attempt to clean diskette surfaces: contaminated diskettes will not work correctly.




Do not lay diskettes near smoke or other sources that can contaminate the disk.




Do not place diskettes near magnetic materials: data can be lost from a diskette exposed to a magnetic field.




Do not expose diskettes to heat greater than 51.7°C (125°F) or to direct sunlight.




Do not use clips or rubber bands on a diskette.



Do not write outside the label area on diskettes.



Do not place heavy books on diskettes.



D.1.4 Diskette Drive Parts

Diskette drive parts are shown in Figure D-9.




Figure D-9 (Part 1 of 4). Diskette Drive Parts





Figure D-9 (Part 2 of 4). Diskette Drive Parts



31SD Control Card




Figure D-9 (Part 3 of 4). Diskette Drive Parts

31SD Control Card Cable

Test Points	Line Names	Test Points	Line Names	Test Points	Line Names
TH01	Diff Read B	TPA01	+5 Vdc	TPG01	+File Data
TH02	No Pin	TPB01	-5 Vdc	TPG02	+Erase Gate
TH03	Diff Read A	TPC01	+Access 1	TPH01	MC-3
TH04	Not Assigned	TPC02	D1 PTX	TPH02	MC-2
TH05	-Disable Stepper Motor	TPC03	Write Data	TPH03	MC-1
TH06	+18V	TPC04	Ground	TPH04	MC-0
		TPD01	+Inner Tracks	TPH05	+Write Gate
		TPE01	+Access 0	TPAMP1	Preamp TP1
		TPE02	+Head Engage	TPAMP2	Preamp TP2
		TPE03	+Index	TPHLD	-Head Load
		TPF01	Ground	TP24V	+24 Vdc
		TPF02	+Write/Erase Enabled	TPLED	31SD LED Voltage

- PTXCP – PTX Connector Pins
- I/O CP – I/O Connector Pins
- LEDCP – LED Connector Pins
- SCP – Solenoid Connector Pins
- HCP – Head Connector Pins
- SMCP – Stepper Motor Connector Pins

Figure D-9 (Part 4 of 4). Diskette Drive Parts

D.2 DEVICE THEORY OF OPERATION

The 31SD Diskette Drive is an I/O device that relies on the using system for power, commands, and control. The drive can read from, and write to one side of, a diskette. This section contains theory information about the device interface, data flow, and operation of the diskette drive.

D.2.1 Control Card Interface

Cylinder access is shown in Figure D-10; the interface lines at connector A1 are shown in Figure D-11.

Following is a description of the interface lines at connector A1:

Write Data: For each change of this signal, the current switches in the read/write head. This process records the data on the diskette surface.





Figure D-10. Cylinder Access



Notes:

1. A jumper from ground to disable stepper motor overrides any input access lines. This is used in making head/stepper motor adjustments.
2. The variable frequency oscillator is packaged in the using system logic. The function of the variable frequency oscillator is to separate and clock pulses.

Figure D-11. Control Lines at Connector A1

+Inner Tracks: This line is active from track 43 through track 76. When this line is active, the write current through the data head is decreased, because the bit density increases toward the center tracks and, therefore, less write current is needed.

+Write Gate: This line activates the write circuits and deactivates the read circuits for a write operation.

+Erase Gate: This line activates the tunnel erase circuits during a write operation to erase the edges of the track just recorded. This erasing prevents crosstalk between tracks during later read operations.

+Write/Erase Enabled: When this line is active, either write or erase current has been enabled on the card.

File Data: This line is a series of clock and data pulses that represent the data read from the diskette surface. The VFO circuits supplied by the using system separate the clock pulses from the data pulses.

+Index: This line indicates the start of a track. This 1.5 to 3.0 ms pulse occurs every 166.7 ms.

Diskette Sense: This line is tied to ground to always indicate a diskette 1.

Access Lines 0 and 1: Sequentially activating the access signal lines causes the read/write head to move from one cylinder to the next. Note, in Figure D-10, that the sequence is repeated every four cylinders.

These two access signal lines, 0 and 1, are sequentially activated to cause the head to move in (toward the drive hub) or out (away from the drive hub).

+Head Engage: When it is active, this line loads the read/write head.

D.2.2 Mechanical Operation

Figure D-12 shows the operation of the read/write head on the 31SD Diskette Drive.

The operation of the 31SD is similar to that shown in Figure D-12, but has only one head.

- The diskette is ready to be inserted, **1**.
- The diskette is inserted into the diskette guide, **2**;

the operator closes the knob, which clamps the collet (R/W heads are now much nearer to the diskette).

- The head is loaded (touching the diskette), **3**. The solenoid is activated, the cable pulls the bail, and the bail lowers the head to the diskette.
- Read/Write operation takes place. The heads are moved to the desired cylinder on the disk when the system activates the two stepper motor access lines in a specific sequence.
- The head is released (deactivate the solenoid), **4**.
- The operator turns the knob to the open position; the diskette is released and then removed from the drive, **5**.

D.2.3 Typical Device Operation

Figure D-13 shows the sequence of diskette operation.

1. The host system starts the diskette drive motor.
2. The operator inserts a diskette and turns the operator knob to the closed position. With the operator knob in the closed position, the diskette starts turning, and the read/write heads move into position on the diskette surface (see paragraph D.2.2 for mechanical operation).
3. Index pulses are sensed every revolution (166.7 ms).
4. The using system sequentially activates the two access lines to move the head/carriage assembly in (toward the hub) or out (away from the hub) to select the desired cylinder. Then the system sequentially activates the access lines to turn the stepper motor a distance equal to one cylinder. The two access lines last used to move the head/carriage to the desired cylinder remain active, **B**. Data from the selected cylinder is valid after 40 ms (minimum time for the head and carriage assembly to stop).
5. A head load command can be given before or during a seek to activate the head load solenoid. Data is valid 80 ms after the head is loaded. Address bytes of the first available ID (identifier) field are read, which locates the head in the correct position.
6. Reading or writing can occur 40 ms after seeking to the last cylinder, **A**, or 80 ms after the heads are loaded.
7. The read/write head is unloaded after the read or write operation.





Figure D-12. Diskette Insertion and Head Load Operation




Note: Seeking and head loading are not to the index.

Figure D-13. Diskette Operation Sequence

D.2.4 Read/Write Principles

D.2.4.1 Write Data


For each change of the write data signal, the current switches in the read/write head. This process records the data on the diskette surface.



FM Encoding: Writes data bits 4 μ s apart. They are recorded on the diskette as follows:

Data Bit to Be Recorded	Recorded As: Clock Bit	Data Bit
1	1	1
0	1	0

Data bits 0101 appear as follows:



D.2.4.2 Write Operation

For a write operation (Figure D-14), the write-gate signal activates the write circuits and deactivates the read circuits, **E**

during a write operation to erase the edge of the data track, **F**, just recorded. This erasing process prevents crosstalk between tracks during later read operations.

The erase-gate signal activates the tunnel erase circuits





Figure D-14. Write Operation

Format Write Operation: Writes a full track exchanging all the identifier (ID) fields, data fields, and gaps. The index to the first ID field gap is 79 eight-bit bytes.



The write-gate signal is activated any time between the leading edge of the index pulse, **G**, and 50 bytes after the leading edge of the index pulse. The write-gate signal is deactivated approximately 51 bytes after the leading edge of the next index pulse, **H**.

The erase-gate signal is activated at the same time as the write-gate signal, but is deactivated 537 μ s after the write-gate signal is deactivated **J**.

Record (Update) Write Operation: Performed on a data field and its VFO sync field only. ID fields and gaps are not written. See Figure D-15.

The write-gate line is activated 316 μ s after the last ID character is read, **K**. The line is deactivated 5 μ s after the last clock of the 2-bit pad is written, **L**.

The erase-gate line is activated, **M**, 221 μ s after the write-gate line and is deactivated, **N**, 537 μ s after the fall of the write-gate line.

The writing of the new VFO sync field starts when the write-gate line is activated, **P**.




Figure D-15. Record Update – Write Operation

D.2.4.3 Read Data

Read data is the FM encoded read head signal that can be observed at TPAMP1 and TPAMP2. See Figures D-16 through D-20.

Typical measurements for FM encoding are:

- 125 kHz: 120 to 300 mV (all 0's)
- 250 kHz: 100 to 250 mV (all 1's)

The voltage is higher at the outer tracks because of the higher track speeds and lower bit density.

READ DATA : MFM ENCODED (51TD ONLY)




Figure D-16. Read Data Signals

SCOPE SETUP

Note: Use Tektronix 453, 454, or similar oscilloscope with x10 probes.


Channel A sweep mode	Normal
Channel A level	+
Channel A coupling	DC
Channel A slope	+
Channel A source	External
Trigger	Normal
Mode	Add
Channel 1 volts/ division	5 mV/cm
Channel 2 volts/division	5 mV/cm
Channel 1 input	AC
Channel 2 input	AC
Invert	Pull out
Times per division	2 ms/cm
Connect channel 1 to	TPAMP1
Connect channel 2 to	TPAMP2
Connect trigger to	+Index test pin

Observe: The amplitude of the read signal should be between 6.5 to 560 mV.

MFM FILE DATA

Bit Pattern: Hex E5E5

Example; 0101111001



SCOPE SETUP

Note: Use Tektronix 453, 454, or similar oscilloscope with x10 probes.

Channel A sweep mode	Normal
Channel A level	+
Channel A coupling	DC
Channel A slope	+
Channel A source	External
Trigger Mode	Normal
Channel 1 volts/division	1.0V/cm
Channel 1 input	DC
Times per division	2 μs/cm
Connect channel 1 to	+File data
Connect trigger to	+Index test pin

Observe: Clock or data pulses every 2 to 4 μs. Pulse duration should be between 100 and 500 ns. Pulse amplitude should be between 2.4 and 4.2 volts.

Figure D-17. File Data Signals




Figure D-18. 31SD Test Pins




Figure D-19. 31SD Control Card

PTXCP – PTX Connector Pins
 I/O CP – I/O Connector Pins
 LEDCP – LED Connector Pins
 SCP – Solenoid Connector Pins
 HCP – Head Connector Pins
 SMCP – Stepper Motor Connector Pins

Test Points	Line Names	Test Points	Line Names	Test Points	Line Names
TH01	Diff Read B	TPA01	+5 Vdc	TPG01	+File Data
TH02	No Pin	TPB01	-5 Vdc	TPG02	+Erase Gate
TH03	Diff Read A	TPC01	+Access 1	TPH01	MC-3
TH04	Not Assigned	TPC02	D1 PTX	TPH02	MC-2
TH05	-Disable Stepper Motor	TPC03	Write Data	TPH03	MC-1
TH06	+18V	TPC04	Ground	TPH04	MC-0
		TPD01	+Inner Tracks	TPH05	+Write Gate
		TPE01	+Access 0	TPAMP1	Preamp TP1
		TPE02	+Head Engage	TPAMP2	Preamp TP2
		TPE03	+Index	TPHLD	-Head Load
		TPF01	Ground	TP24V	+24 Vdc
		TPF02	+Write/Erase Enabled	TPLED	31SD LED Voltage

Figure D-20. 31SD Control Card Cable

D.3 MAINTENANCE

D.3.1 Collet/Flat Spring Assembly

D.3.1.1 Collet/Flat Spring Removal

See Figure D-21 (2 parts).

1. Power down.
2. Turn the operator knob, **F**, to the closed position.

Warning: Do not attempt to remove the collet/flat spring, **E**, before removing the bail, **L**. Too much pressure or binding can damage the spring.




Figure D-21 (Part 1 of 2). Collet/Flat Spring Removal

3. Loosen the lever screw, **K**.
4. Push the bail, **L**, inward slightly, and disconnect the bail actuator cable eyelet, **N**, from the lever, **J**.
5. Turn the operator knob, **F**, to the open position.
6. Loosen the bail mounting screw, **M**.
7. Observe the position of the bail return spring, **R**; then remove the bail pivot rod, **P**, the bail return spring, **R**, and the bail, **L**, by sliding the bail, **L**, out from under the head load arm, **C**.

Warning: Damage to the head, **B**, can occur if the pressure pad, **A**, is permitted to hit the head.

8. Remove the screw and nut, **T**, from the collet actuator rod, **S**.
9. Remove the operator knob, **F**.
10. Remove the collet actuator roll, **H**, and the pressure roll, **G**.
11. Turn the collet actuator rod, **S**, up and out of the way. Then remove the collet/flat spring assembly, **E**.

D.3.1.2 Collet/Flat Spring Replacement

See Figure D-21 (2 parts).

Warning: Too much pressure or binding of the flat spring, **E**, will damage the spring.

1. Reinstall the collet/flat spring assembly, **E**.
2. Reinstall the collet pressure roll, **G**, and actuator roll, **H**.
3. Turn the collet actuator rod, **S**, down against the spring.
4. Reinstall the operator knob, **F**, in the open position.
5. Reinstall the screw and nut, **T**, that attach the operator knob to the collet actuator rod, **S**. Push the operator knob and the collet actuator rod, **S**, together until there is a maximum of 0.1-mm (0.004-inch) end play, **W**, between the operator knob, **F**, and the diskette guide, **D**. (See Part 2 of Figure D-21.) Tighten the screw.
6. Reinstall the bail return spring, **R**, the bail, **L**, and the bail pivot rod, **P**. Place the bail, **L**, on the collet actuator rod, **S**. Ensure that the spring, **R**, is in the correct position. Place the bail, **L**, under the head load arm. Place the bail pivot rod, **P**, in the groove, and tighten the bail mounting screw, **M**.




Figure D-21 (Part 2 of 2). Collet/Flat Spring Removal

7. Turn the operator knob, **F**, to the closed position.
8. Push the bail, **L**, inward slightly, and connect the cable to the lever, **J**. Ensure that the eyelet crimp, **V**, is facing outward, that the cable remains on the pulley, and that the cable is not twisted. (See Part 2 of Figure D-21.) Turn the solenoid plunger, **U**, if necessary.
9. Turn the operator knob, **F**, to the open position.
10. Ensure that the diskette moves in and out of the drive smoothly without hitting the collet. If the diskette will not move in and out smoothly, the flat spring, **E**, has been damaged, and a new flat spring should be installed.
11. Perform the Head Gap Adjustment (paragraph D.3.3.3).

D.3.2 Head/Carriage Assembly

Warning: The head/carriage assembly is adjusted and tested at the factory. Do not attempt to adjust or repair any part of this assembly.

Do not attempt to clean the head/carriage assembly. If the assembly is not clean, exchange it.

D.3.2.1 Head/Carriage Pressure Pad Removal and Replacement

See Figure D-22.




Figure D-22. Head/Carriage Pressure Pad Removal and Replacement

If the pressure pad is worn to a point nearly even with the surface of the head load arm, exchange the pad. Use pad B/M (part 2200751).

Warning: The head area can be easily damaged or contaminated. Read the following before exchanging a pressure pad:

- Ensure that your tools are clean; use isopropyl alcohol (part 2200200) and a clean tissue (part 2162567), or use an alcohol pad (part 9900679).
- Do not touch the pressure pad with your fingers.
- Be careful not to damage the new pressure pad or loosen any of the pad's surface. The layer of adhesive on the new pad is very thin; do not damage the adhesive. Do not let the adhesive touch the surface of the pad that will touch the diskette. Do not use damaged pads.
- Do not scratch the head load arm.
- Do not let the head load arm hit the read/write head.
- Move the head load arm as little as possible. The tension spring, **A**, can come out.

1. Move the head load arm away from the read/write head.
2. Using your scissor clamp (part 9900233), pull the worn pad off the arm.
3. Carefully remove any adhesive that remains on the arm.
4. Ensure that the pressure pad mounting surface is lint-free; use tissue (part 2162567) moistened with isopropyl alcohol (part 2200200) or an alcohol pad (part 9900679). If the surface is not completely clean, the new pad may not seat correctly.
5. Using a knife (or similar thin blade), lift off the paper cover that protects the adhesive layer on the new pad.
6. Using your scissor clamp, carefully remove the new pressure pad from the other new pads.
7. Place the new pad in the center of its location on the head load arm.
8. Lightly press on the new pad with a clean screwdriver.
9. Using the small end of the pressure pad tool, **B**, press at 90 degrees to the head load arm.
10. Use your other hand to turn the tool at least one revolution *in one direction only*.
11. Carefully move the head load arm back to its operational position.
12. Test the read/write head output. See Read/Write Principles (paragraph D.2.4).

D.3.2.2 Head/Carriage Service Check

See Figures D-23 and D-24.

Warning: The head/carriage service check must be performed with the diskette drive installed (or with the diskette drive in the same position as when installed) or the adjustment might not be accurate.

1. Power down.

DANGER

Voltage is still present at the socket when the power cable is disconnected.

2. Disconnect the ac drive motor power cable, **J**.
3. Remove the head cable guide, **A**.
4. Turn the stepper motor pulley by hand to track 40, and insert a timing pin, **C**. (Ensure that the pin goes into the casting.)
5. Power up.
6. To disable the stepper motor, install a jumper, **L**, from TCP04 (ground) to TH05 (-'disable stepper motor').
7. To locate the stepper motor at track 40, install a jumper, **M**, between TPF01 (ground) and TPH04 (MC-0).
8. Put the timing pin, **C**, through the stepper motor pulley into the timing hole in the casting. Does the timing pin pass freely through the hole?

Y N

- Remove the timing pin, **C**.
 - Remove the jumpers, **L** and **M**.
 - Power down.
 - Go to the Head/Carriage Adjustment (paragraph D.3.2.3), step 3.
9. Remove the timing pin, **C**.
 10. To move the stepper motor to track 39, remove the jumper connected to TPH04 and install the jumper end on TPH01 (MC-3).
 11. Verify that this is track 39 by visually checking for no gap, **D**, between the timing pointer, **E**, and the timing block, **G**.




Figure D-23. Head/Carriage Service Check




Figure D-24. 31SD Control Card

12. To move the stepper motor from track 39 back to track 40, remove the jumper connected to TPH01 and install the jumper end on TPH04 (MC-0).
13. Verify that this is track 40 by visually checking that the timing hole in the pulley lines up with the timing hole in the casting. (Use the dental mirror to verify; do not use a timing pin.)
14. Insert the thickness gauges from the end of the timing pointer, **E**, and timing block, **G**, to verify the indicated gap, **F**:
 - 0.483 mm (0.019 inch). Go.
 - 0.533 mm (0.021 inch). No go.
15. If the adjustment is not correct, go to step 12 of paragraph D.3.2.3.
16. Remove the jumpers, **L** and **M**.
17. Reinstall the head cable guide, **A**. (Ensure that the read/write head can move freely.)
18. Was the head/carriage assembly exchanged?

Y	N
	– Power down.
	– Reconnect the ac drive motor power cable.
	– Power up.
	– End of procedure.
19. Go to the Head Gap Service Check (paragraph D.3.3.2).

Note: *Because of the torque characteristics of the stepper motor, this step can be performed only once. If it is necessary to perform this step again, go back to step 10 of this service check.*

D.3.2.3 Head/Carriage Adjustment

See Figure D-25.

Warning: The head/carriage assembly adjustment must be performed with the diskette drive installed (or in the same position as when installed), or the adjustment might not be accurate.

1. Power down.
2. Remove the cable guide, **A**.

3. Measure and record the gap, **K**, between the stepper motor pulley, **L**, and the casting.

Gap is: _____.
4. Loosen the clamp screw, **H**, so the stepper motor drive shaft, **N**, can turn inside the pulley, **L**.
5. Turn the stepper pulley, **L**, by hand to track 40, and insert the timing pin, **J**. (Ensure that the pin goes into the casting.)





Figure D-25 (Part 1 of 2). Head/Carriage Adjustment



31SD Control Card




Figure D-25 (Part 2 of 2). Head/Carriage Adjustment

DANGER

Voltage is still present at the socket when the power cable is disconnected.

6. Disconnect the ac drive motor power cable, **F**.
7. Power up.
8. To disable the stepper motor, install a jumper **P** from TPC04 (ground) to TH05 (-'disable stepper motor).
9. To locate the stepper motor at track 40, connect a jumper **P** from TPF01 (ground) to TPH04 (MC-0).
10. Make the gap, **K**, the same size as the gap recorded in step 3, and tighten the clamp screw, **H**. (Ensure that the timing pin passes freely through the stepper motor pulley into the hole in the casting.) The clamp, **M**, should be placed even with the end of the stepper motor drive shaft, **N**.
11. Remove the timing pin, **J**.
12. Loosen the two bracket-to-carriage clamping screws, **G**.
13. Remove the jumper end from TPH04, and install the jumper end on TPH01 (MC-3).
14. Remove the jumper end from TPH01, and connect the jumper end on TPH04 (MC-0).
15. Verify that this is track 40 by visually checking that the timing hole in the pulley lines up with the timing hole in the casting. (Use the dental mirror to check; do not use a timing pin.)
16. Insert a 0.508 mm (0.020 inch) thickness gauge, **E**, between the timing pointer on the carriage and the track 40 adjustment surface on the casting. Use the clip (part 4240632), **D**, to attach the thickness gauge to the casting. The clip is attached to the diskette guide (see Figure D-4).
17. Slide the head/carriage, **C**, against the thickness gauge so it just touches but is not forced against the thickness gauge. Install the carriage pressure spring (part 4240631), **B**, between the casting and the carriage to hold the head/carriage assembly against the thickness gauge. The pressure spring is attached to the diskette guide (see Figure D-4).
18. Tighten the two screws, **G**, that fasten the bracket to the carriage.
19. Remove the clip, **D**, and the carriage pressure spring, **B**.
20. Go to step 10 of paragraph D.3.2.2.

D.3.2.4 Head/Carriage Removal

See Figure D-26.

1. Power down.
2. Carefully remove the head/carriage cable connector, **A**, from the control card. (Note the cable path for easier replacement.)
3. Remove the cable guide, **B**.

Warning: Band **C** must not be bent or damaged in any way.

4. Remove the band, **C**, by removing the three screws, **E** and **M**, that attach the band to the stepper pulley, **L**, and the carriage bracket, **D**. (Note the position of the band and clamps; they must be in the same position for replacement.)
5. Remove the carriage bracket, **D**, from the carriage.
6. Remove the two screws, **J**, and remove the guide rod, **F**.
7. Carefully lift and turn the head/carriage assembly, **H**, to remove it from the guide rod, **G**.

D.3.2.5 Head/Carriage Replacement

See Figure D-27.

Warning: When you install the head/carriage assembly, **S**, ensure that the bail, **E**, is under the head load arm, **D**. Ensure that the bail return spring, **G**, is correctly installed. Ensure that the band, **L**, is not damaged in any way.

1. Carefully install the head/carriage assembly, **S**, on the guide rod, **Q**. Then place the head/carriage assembly at track 00.
2. Reinstall the guide rod, **P**, and tighten the two screws, **R**. (Ensure that the guide rod notch, **U**, is aligned with the screw, **T**.)
3. Place the head/carriage assembly at track 40.
4. Reinstall the carriage bracket, **M**, on the carriage with the screws and washers, **R**, installed in the center of the hole.
5. Reconnect the band, **L**, as follows: Install the adapter welded to band **V** to the slotted end, **B**, of the carriage bracket, **M**. Leave the screw loose. Install band **L** to the stepper motor pulley, **W**, with clamp **J**. Install the end of band **L** to the carriage bracket with clamp **K**. Ensure that the band is parallel to the carriage bracket, **M**, and the edge of the pulley, **H**, during installation.





Figure D-26. Head/Carriage Removal








Figure D-27 (Part 1 of 2). Head/Carriage Replacement



31SD Control Card




Figure D-27 (Part 2 of 2). Head/Carriage Replacement

6. Block the head/carriage about 25 mm (1 inch) from the casting, **F**.
7. Pull on the adapter welded to band **V** with 2.5 ± 0.25 pounds' force, and tighten the band clamping screw, **C**. Ensure that the band is parallel to the pulley edge, **H**.
8. Move the carriage to track 00 and then to track 76. Ensure that the band track is straight and that the drive band is parallel to the pulley edge, **H**.
9. Carefully connect the head/carriage cable to the control card connector, **AA**.
10. Turn the stepper motor pulley, **W**, by hand to track 40, and check with the timing pin, **X**. Ensure that the pin goes into the casting.

DANGER

Voltage is still present at the socket when the power cable is disconnected.

11. Disconnect the ac drive motor power cable, **A**.
12. Power up.
13. To disable the stepper motor, install a jumper, **Y**, from TPC04 (ground) to TH05 (-'disable stepper motor').
14. Install a jumper, **Z**, from TPF01 (ground) to TPH04 (MC-0).
15. Put the timing pin through the stepper motor pulley, **W**, into the timing hole in the casting. Does the timing pin pass through the timing hole freely?

Y N

- Remove the timing pin, **X**.
- Remove the jumpers, **Y** and **Z**.
- Power down.
- Go to step 3 of paragraph D.3.2.3.

Remove the timing pin **X**.

16. Go to step 12 of paragraph D.3.2.3.

D.3.3 Head Load Solenoid and Bail

D.3.3.1 Solenoid and Bail Service Check

See Figure D-28.




1. Power down.

DANGER



Voltage is still present at the socket when the power cable is disconnected.

2. Disconnect the ac drive motor power cable, **G**.
3. Insert a diskette, and turn the operator knob, **B**, to the closed position.
4. Power up.
5. To activate the head load solenoid, install a jumper, **E**, from TPC04 (ground) to the head load TPHLD (-'head load').
6. To deactivate the stepper motor, install a jumper, **F**, from TPC04 (ground) to TH05 (-'disable stepper motor').
7. Verify a 0.3 to 0.7 mm (0.012 to 0.028 inch) gap, **D**, between the bail and the head load arm at each end of the head movement.
8. Is the gap OK? If not, go to Bail Adjustment (paragraph D.3.3.4, step 5).
9. Remove the jumpers **E** and **F**.
10. Turn the operator knob, **B**, to the open position, and remove the diskette.
11. Turn the operator knob, **B**, to the closed position.
12. Power down.
13. Reconnect the ac drive motor power cable, **G**.
14. Power up.

Head Load Solenoid Activated



Head Load Solenoid Deactivated



31SD Control Card




Figure D-28. Solenoid and Bail Service Check

D.3.3.2 Head Gap Service Check

See Figure D-29.

1. Power down.
2. Turn the operator knob, **B**, to the closed position.
3. Visually check for a gap of 3 to 4 mm (0.118 to 0.157 inch) between the bail assembly and the head load arm.
4. Is the gap OK? If not, go to step 3 of paragraph D.3.3.3.
5. Turn the operator knob, **B**, to the open position.
6. Power up.
7. If the head/carriage assembly was exchanged, go to the Solenoid and Bail Service Check (paragraph D.3.3.1).

D.3.3.3 Head Gap Adjustment

See Figure D-29.

1. Power down.
2. Turn the operator knob to the closed position.
3. Tighten the lever screw, **K**, just enough so that the lever, **J**, can still be adjusted.
4. While looking into the diskette opening, move the lever until the load arm, **F**, just touches the head.
5. Note the lever marks, **H**, on the lever relative to the bail alignment edge, **G**.
6. Turn the lever 1-1/2 spaces clockwise.
7. Tighten screw **K**.
8. The gap, **B**, between the head load arm and the head should now be 3 to 4 mm (0.118 to 0.157 inch).
9. Is the gap OK?

Y N

- Go to Solenoid and Bail Service Check (paragraph D.3.3.1).
- Go back to step 3.

D.3.3.4 Bail Adjustment

See Figure D-29.

1. Power down.
 - DANGER**
Voltage is still present at the socket when the power cable is disconnected.
2. Disconnect the ac drive motor power cable, **L**.
3. Power up.
4. Insert a diskette, and turn the operator knob to the closed position.
5. To activate the head load solenoid, install a jumper, **C** from TPC04 (ground) to the head load TPLD (-'head load').
6. To deactivate the stepper motor, install a jumper, **D**, from TPC04 (ground) to TH05 (-'disable stepper motor').

CAUTION: The solenoid case becomes hot after continuous use.

7. Loosen the solenoid locking screw, **A**.


Warning: Do not let the solenoid plunger and cable turn while you make this adjustment.

8. Turn the solenoid in the mounting bracket to obtain a 0.3 to 0.7 mm (0.012 to 0.028 inch) gap, **E**, between the head load arm and the bail.
9. Tighten screw **A**.
10. Is the gap OK at each end of the head movement (step 8)?


Y N

- Go back to step 7.


11. Remove the jumpers, **C** and **D**.
12. Turn the operator knob to the open position, and remove the diskette.
13. Power down.
14. Reconnect the ac drive motor power cable, **L**.
15. Power up.





Head Load Solenoid Activated



Head Load Solenoid Deactivated



31SD Control Card



Push in on the bail to release the cable eyelet from the stud.

Figure D-29. Head Gap Adjustment

D.3.3.5 Bail Removal

See Figure D-30.

1. Power down.

DANGER

Voltage is still present at the socket when the power cable is disconnected.

2. Disconnect the ac drive motor power cable, **A**.
3. Turn the operator knob to the closed position.
4. Loosen the lever screw, **C**.
5. Push the bail, **J**, inward slightly, and disconnect the bail cable eyelet, **G**, from the lever, **D**.
6. Turn the operator knob to the open position.
7. Loosen the bail mounting screw, **E**.

Warning: Permitting the pressure pad to hit the head can damage the head.

8. Observe the position of the bail return spring, **K**. Now remove the pivot rod, **H**, the bail return spring, **K**, and the bail, **J** by lifting the bail out from under the head load arm, **B**.

D.3.3.6 Bail Replacement

See Figure D-30.

1. Reinstall the bail return spring, **K**, the bail, **J**, and the pivot rod, **H**. Place the bail, **J**, on the collet actuator rod, **L**. Ensure that the bail return spring, **K**, is in the correct position. Place the bail, **J**, under the head load arm, **B**, place the bail pivot rod, **H**, in the groove, and tighten the screw, **E**.
2. Turn the operator knob to the closed position.
3. Push the bail, **J**, inward slightly, and connect the cable eyelet, **G**, to the bail lever with the crimp, **N**, facing outward. (Ensure that the cable remains on the pulley and is not twisted; turn the solenoid plunger, **M**, if necessary.)
4. Turn the operator knob to the open position.
5. Perform the Head Gap Adjustment (paragraph D.3.3.3).

D.3.3.7 Solenoid and Idler Removal

See Figure D-31.

1. Power down.

DANGER

Voltage is still present at the socket when the power cable is disconnected.

2. Disconnect the ac drive motor power cable, **B**.
3. Turn the operator knob, **F**, to the closed position.
4. Loosen the lever screw, **K**.
5. Push the bail, **L**, inward slightly, and disconnect the cable eyelet, **M**, from the bail lever, **N**.
6. Turn the operator knob, **F**, to the open position.
7. Remove the ac motor drive belt, **A**.
8. Remove the solenoid cable connector, **E**, from the control card.
9. Remove the solenoid, the bracket, and the cable as a unit, **D**.
10. Loosen the solenoid locking setscrew, **G**, and unscrew the solenoid from the bracket. (The solenoid and the bail actuator cable are exchanged as a unit.)

D.3.3.8 Solenoid and Idler Replacement

See Figure D-31.

1. Reinstall the solenoid, **D**, on the bracket.
2. Reinstall the solenoid, bracket, and cable as a unit.
3. Reconnect the head load solenoid cable connector, **E**, to the control card.
4. Reinstall the ac motor drive belt, **A**.
5. Turn the operator knob, **F**, to the closed position.
6. Push the bail, **L**, inward slightly, and connect the cable eyelet, **M**, to the bail lever, **N**, with the eyelet crimp, **P**, facing outward. (Ensure that the cable remains on the pulley and is not twisted; turn the solenoid plunger, **H**, if necessary.)
7. Turn the operator knob, **F**, to the open position.
8. Perform the Head Gap Adjustment (see paragraph D.3.3.3).




Figure D-30. Bail Removal





Figure D-31. Solenoid and Idler Removal

D.3.4 AC Drive Parts

D.3.4.1 Drive Motor Removal

See Figure D-32.

1. Power down.

DANGER

Voltage is still present at the socket when the power cable is disconnected.

2. Disconnect the ac drive motor power cable, **B**.
3. Remove the ac motor drive belt, **A**.

CAUTION: The motor case becomes hot after continuous use.

4. Remove the two enclosure mounting screws, **P**, and remove the fan enclosure.
5. Loosen the drive pulley/fan locking setscrew, **M**; then remove the ac drive motor pulley/fan assembly, **K**.

DANGER

High voltage may be present at the capacitor terminals, **F.**

6. Remove the two capacitor insulator caps, **H**, from the capacitor terminals.
7. Discharge the capacitor by jumpering its terminals, **F**, with the large blade screwdriver.
8. Remove the motor capacitor leads, **G**, from the capacitor terminals.
9. Remove the motor capacitor leads, **G**, from the cable guide, **J**, on the casting.
10. Remove the insulator caps, **H**, from the motor capacitor leads, **G**.
11. Remove the remaining two motor mounting screws, **L**, and remove the motor, **A**.

D.3.4.2 Drive Motor Replacement

See Figure D-32.

1. Install the ac drive motor, **A**, with the two mounting screws, **L**. Note in Figure D-31 that the cable, **B**, and the motor capacitor leads, **J**, should extend toward the rear of the machine.
2. Install the ac drive motor pulley/fan, **K**, on the new motor. Ensure that the setscrew, **M**, is centered in the flat surface of the motor shaft. (Leave the setscrew loose.)

3. Position the fan and pulley on the motor shaft with a gap of 0.5 mm \pm 0.1 mm (0.020 \pm 0.004 inch) between the motor face and the fan hub. Tighten the setscrew.
4. Reinstall the fan enclosure, **N**, with the belt clearance slots toward the drive hub, **R**.
5. Reinstall the drive belt, **O**.
6. Reinstall the two capacitor insulator caps, **H**, on the motor capacitor leads, **G** (one on leads 2 and 3, and one on lead 1).
7. Reconnect the motor capacitor leads, **G**, in the guide, **J**, on the casting.
8. Reinstall the motor capacitor leads, **G**, on the capacitor terminals, **F** (leads 2 and 3 on the top terminal and lead 1 on the bottom terminal).
9. Reinstall the two insulator caps, **H**, on the capacitor terminals, **F**.
10. Reconnect the ac drive motor power cable, **B**.

D.3.4.3 Capacitor Removal

See Figure D-32.

1. Power down.

DANGER

Voltage is still present at the socket when the power cable is disconnected.

2. Disconnect the ac drive motor power cable, **B**.
3. Remove the two insulator caps, **H**, from the capacitor terminals, **F**.
4. Discharge the capacitor by jumpering the capacitor terminals, **F**, with a large blade screwdriver.
5. Remove the motor capacitor leads, **G**, from the capacitor terminals.
6. Remove the screw, **C**, and remove the capacitor bracket assembly, **D**.

D.3.4.4 Capacitor Replacement

See Figure D-32.

1. Reinstall the capacitor assembly, **D**, with the screw, **C**, and tighten the screw.
2. Reinstall the motor capacitor leads, **G**, on the capacitor terminals, **F** (leads 2 and 3 on the top terminal and lead 1 on the bottom terminal).
3. Reinstall the two insulator caps, **H**, on the capacitor terminals.




Figure D-32. AC Drive Motor Removal

D.3.4.5 Drive Fan and Pulley Assembly Removal

See Figure D-32.

1. Power down.

DANGER

Voltage is still present at the socket when the power cable, **B**, is disconnected.

2. Remove the ac drive belt, **Q**.
3. Remove the fan enclosure mounting screws, **P**, and remove the fan enclosure, **N**.
4. Loosen the setscrew, **M**; then remove the ac drive motor pulley/fan, **K**.

D.3.4.6 Drive Fan and Pulley Assembly Replacement

See Figure D-32.

1. Reinstall the ac drive motor pulley, **K**, on the motor shaft so that the setscrew, **M**, is centered in the flat surface of the shaft. (Leave the setscrew loose.)
2. Position the fan and pulley on the motor shaft with a gap of $0.5 \text{ mm} \pm 0.1 \text{ mm}$ ($0.020 \pm 0.004 \text{ inch}$) between the motor face and the fan hub. Tighten the setscrew.
3. With the mounting screws, **P**, reinstall the fan enclosure, **N**, with the belt clearance slots toward the drive hub, **R**.
4. Reinstall the drive belt, **Q**.
5. Reconnect the ac drive motor power cable, **B**.
6. Power up.

D.3.5 Stepper Drive Parts

D.3.5.1 Stepper Motor Removal

See Figure D-33.

1. Power down.
2. Remove the head cable connector, **L**, from the control card.

3. Remove the head cable guide, **P**.

Warning: The stepper drive band, **J**, assembly can be easily damaged. Do not bend, crease, or scratch the band.

4. Remove the three mounting screws, **A**, **F**, and **G**, and clamp, **B**, that attach the stepper drive band, **J**, to the stepper motor drive pulley, **C**, and carriage bracket, **E**. (Note the position of the band, **J**, and clamp, **B**, for easier replacement.)
5. Remove the band assembly.
6. Measure and record the gap, **U**, between the stepper motor pulley, **C**, and the casting for later use.

Gap is _____.

7. Loosen the stepper pulley clamp screw, **Q**, and remove the stepper pulley, **C**, and the clamp, **H**.
8. Remove the stepper motor cable connector, **K**, from the control card.
9. Remove the four stepper motor mounting screws, **N**.
10. Remove the stepper motor, **M**.

D.3.5.2 Stepper Motor Replacement

See Figure D-33.

1. Reinstall the stepper motor, **M**, using the four mounting screws, **N**. (Locate the motor cable toward the control card.)
2. Reinstall the stepper motor cable connector, **K**, on the control card.
3. Reinstall the stepper motor pulley, **C**, and the clamp, **H**. (Adjust the gap, **U**, between the pulley and the casting to the measurement recorded in step 6 of paragraph D.3.5.1.) The clamp, **H**, should be placed even with the end of the stepper motor drive shaft, **D**.
4. Reinstall the drive band, **J**. Go to Head/Carriage Replacement (paragraph D.3.2.5, step 5).







Figure D-33. Stepper Motor

D.3.5.3 Stepper Pulley and Clamp Removal

See Figure D-34.

1. Power down.
2. Remove the drive band (see paragraph D.3.5.7).
3. Measure and record the gap, **C**, between the stepper motor pulley and the casting.

Gap is: _____ .

4. Loosen the clamp screw, **B**; then remove the pulley, **D**, and the clamp, **A**.

D.3.5.4 Stepper Pulley and Clamp Replacement

See Figure D-34.

1. Reinstall the pulley, **D**, the clamp, **A**, and the clamp screw, **B**. The gap should be the same as in step 3 of paragraph D.3.5.3. Ensure that the clamp is even with the end of the stepper motor drive shaft.
2. Reinstall the drive band. Go to Head/Carriage Replacement (paragraph D.3.2.5, step 5).

D.3.5.5 Drive Band Service Check

See Figure D-34.

1. Power down.
2. Turn the stepper motor pulley by hand between tracks 00 and 76.
3. If the drive band does not track parallel to the pulley edge, **F**, go to Drive Band Adjustment (paragraph D.3.5.6, step 2).

If the band shows signs of physical damage, **F**, exchange the band (see paragraphs D.3.5.7 and D.3.5.8).

D.3.5.6 Drive Band Adjustment

See Figure D-35, Parts 1 and 2.

1. Power down.
2. Remove the head connector, **M**, from the control card.
3. Remove the head cable guide, **N**.
4. Place the head/carriage assembly, **G**, at track 40. (Insert the timing pin, **R**, into the timing hole in the casting to align the head/carriage assembly, **G**, at track 40.)
5. Loosen the three mounting screws, **A**, **F**, and **H**, that attach the band to the pulley, **C**, and the carriage bracket, **E**.
6. Tighten screw **F**. (Ensure that the band, **L**, remains parallel to the carriage bracket, **E**.)
7. Tighten screw **A**. (Ensure that the band remains parallel to the pulley edge, **U**.)

8. Block the head/carriage assembly, **G**, about 25 mm (1 inch) from the end of the casting, **Q**.
9. Pull on the loose end of the band with 2.5 ± 0.25 pounds' force, **P**, and tighten the screw, **H**. (Ensure that the band remains parallel to the pulley edge, **U**. If it does not, repeat the adjustment, starting at step 5.)
10. Move the carriage to track 00 and then to track 76, and ensure that the band, **L**, tracks parallel to the pulley edge, **U**.
11. Adjust the head/carriage assembly, **G** (go to paragraph D.3.2.3, step 12).

D.3.5.7 Drive Band Removal

See Figure D-35, Parts 1 and 2.

1. Power down.
2. Remove the head connector, **M**, from the control card.
3. Remove the head cable guide, **N**.

Observe the position of the band, **L**, and clamp, **S**, before performing the next step.

Warning: The band, **L**, is easily damaged, **T**. Do not bend, crease, or scratch the band.

4. Remove the three mounting screws, **A**, **F**, and **H**, and the clamp, **B**, that attach the band, **L**, to the stepper motor pulley, **C**, and the carriage bracket, **E**.
5. Remove the band assembly.
6. If you have entered this procedure from Stepper Pulley and Clamp Removal (paragraph D.3.5.3), return to step 3 of paragraph D.3.5.3.





Figure D-34. Stepper Motor Pulley and Clamp Removal and Replacement

D.3.5.8 Drive Band Replacement

See Figure D-35, Parts 1 and 2.

Warning: The band, **L**, is easily damaged, **T**. Do not bend, crease, or scratch the band. Do NOT use a damaged band.

1. Attach the end of the band, **L**, with the welded adapter, **K**, to the slotted end, **J**, of the carriage bracket. Leave the clamp screw, **H**, loose.
2. Attach the band to the stepper motor pulley, **C**, with the clamp screw, **A**, and the clamp, **B**.

Ensure that the band is parallel to the pulley edge, **U**.

3. Attach the other end of the band to the carriage bracket with the screw, **F**, and the drive band clamp, **D**. Ensure that the band is parallel to the carriage bracket.
4. Adjust the drive band. (Go to step 8 of paragraph D.3.5.6.)






Figure D-35 (Part 1 of 2). Drive Band Adjustments




Figure D-35 (Part 2 of 2). Drive Band Adjustments

D.3.6 LED and PTX Assemblies

D.3.6.1 Diskette Speed Service Check



See Figure D-36.

1. Insert a diskette 1, and close the operator knob. See Diskette Use (paragraph D.1.1.2).
2. To activate the head load solenoid, install a jumper, **A**, from TPF01 (ground) to TPHLD (-'head load').
3. Set up an oscilloscope as shown in the chart, **E**.

Note: Use a Tektronix 453, 454, or a similar oscilloscope with x10 probes.

4. Observe an index pulse width of 1.5 to 3.0 ms, **C**, occurring every 166.7 ± 4.2 ms, **B**. Pulse amplitude should be between 2.4 and 4.2 Vdc, **D**.
5. Remove the jumper.
6. Remove the diskette. See Diskette Use (paragraph D.1.1.2).

Control Card



E Oscilloscope Settings

Channel A sweep mode	Normal
Channel A level	+
Channel A coupling	DC
Channel A slope	+
Channel A source	Internal
Trigger Mode	Normal
Channel 1 volts/division	1.0 V/cm
Channel 1 input	DC
Times per division	20 ms
Channel 1 probe to	+Index Test Pin





Figure D-36. Diskette Speed

D.3.6.2 LED Output Service Check

See Figure D-37.

1. Connect the negative probe, **C**, of the multimeter to the TPF01 (ground) on the control card, **A**.
2. Set the multimeter scale to 5 Vdc, and connect the positive probe, **B**, to the LED voltage test pin TPLED.
3. Check for a voltage level of 1 Vdc to 2 Vdc, **D**.

D.3.6.3 LED Removal

See Figure D-38.

1. Power down.
2. Remove the LED connector, **B**, from the control card.
3. Remove the LED cable. (Note the cable path for future replacement.)
4. Remove the LED mounting screw, **D**; then remove the LED assembly, **C**.




Figure D-37. LED Output Check

D.3.6.4 LED Replacement

See Figure D-38.

1. Reinstall the LED cable, the LED assembly, **C**, and the mounting screw, **D**, on the diskette guide, **A**.
2. Reconnect the LED connector, **B**, to the control card.

D.3.6.5 PTX Amplifier Service Check

See Figure D-39.

1. Power down.

DANGER

Voltage is still present at the socket when the power cable is disconnected.

2. Disconnect the ac drive motor power cable, **A**.
3. Remove the PTX connector, **B**, from the control card.
4. Power up.
5. Connect the positive probe, **E**, of a multimeter, **D**, (15 Vdc scale) to the index test pin (TPE03) on the control card.
6. Connect the negative probe, **F**, of the multimeter of TPF 01 (ground).
7. Check the multimeter, **D**, for a reading of less than 1 Vdc.





Figure D-38. LED Removal and Replacement



31SD Control Card





Figure D-39. PTX Amplifier Service Check

8. Install one end of a jumper, **C**, to pin A03 of the PTXCP socket on the control card.
9. Observe the multimeter, and touch the other end of the jumper several times to pin A01 of the PTXCP socket on the control card. The multimeter should read 2.5 Vdc or more when the test pin is touched. (A wrong measurement can occur the first time the test pin is touched.)
10. Power down.
11. Remove the jumper.
12. Reinstall the PTX connector on the control card.
13. Reconnect the drive motor power cable.
14. Power up.

D.3.6.6 PTX Removal

See Figure D-40

1. Power down.
2. Remove the LED connector, **F**, from the control card. (Note the cable path for easier replacement.) Pull the cable and the connector through the casting.
3. Turn the operator knob, **A**, to the closed position.
4. Loosen the lever screw, **R**.
5. Push the bail, **Q**, inward slightly, and disconnect the bail actuator cable eyelet, **I**, from the hook, **N**, on the bail lever, **S**.
6. Turn the operator knob, **A**, to the open position.

Warning: Damage to the head, **H**, can occur if the pressure pad, **J**, is permitted to hit the head.

7. Remove the four diskette guide mounting screws, **P**.
8. Remove the diskette guide, **M**, by lifting it up and carefully sliding the bail, **Q**, from under the head load arm, **G**.
9. Remove the five remaining connectors, **B**, from the control card. (Note the connector locations and cable paths for easier replacement.)
10. Loosen the control card retainer screw, **E**.

Warning: Be careful not to damage the control card.

11. Turn the two control card retainers, **D**, out of the control card path, and remove the control card, **C**. (Note the position of the control card for easier replacement.)
12. Remove the PTX mounting screw, **L**, and the PTX assembly, **K**. (Note the cable path for future replacement.)

D.3.6.7 PTX Replacement

See Figure D-40.

1. Reinstall the PTX assembly, **K**, and the PTX mounting screw, **L**.
2. Reinstall the control card, **C**, and turn the two retainers, **D**, inward until they prevent the control card from moving.
3. Tighten the two retainer screws, **E**.
4. Reinstall the five connectors, **B**, on the control card.
5. Reinstall the diskette guide, **M**. Place the bail below the head load arm, **G**.
6. Reinstall the four diskette guide mounting screws, **P**.
7. Reinstall the LED connector, **F**, on the control card. Go to Bail Replacement (paragraph D.3.3.6, step 2).

D.3.7 Diskette Drive Control Card

D.3.7.1 Control Card Removal

See Figure D-41.

1. Power down.
2. Remove the six connectors, **A**, from the control card.
3. Loosen the two retainer screws, **D**, and turn the two retainers, **C**, outward until they are no longer in the path of the control card, **B**.
4. Remove the control card.

D.3.7.2 Control Card Replacement

See Figure D-41.

1. Reinstall the control card, **B**.
2. Turn the two retainers, **C**, inward slightly until they prevent the card from moving.
3. Tighten the two retainer screws, **D**.
4. Reinstall the six connectors, **A**, on the control card.
5. Power up.

D.3.7.3 Control Card Test Pins and Connector Pins

See Figure D-42.





Figure D-40. PTX Removal and Replacement





Figure D-41. Diskette Drive Control Card

31SD Control Card



PTXCP – PTX Connector Pins
 I/O CP – I/O Connector Pins
 LEDCP – LED Connector Pins
 SCP – Solenoid Connector Pins
 HCP – Head Connector Pins
 SMCP – Stepper Motor Connector Pins

31SD Control Card Cable

Test Points	Line Names	Test Points	Line Names	Test Points	Line Names
TH01	Diff Read B	TPA01	+5 Vdc	TPG01	+File Data
TH02	No Pin	TPB01	-5 Vdc	TPG02	+Erase Gate
TH03	Diff Read A	TPC01	+Access 1	TPH01	MC-3
TH04	Not Assigned	TPC02	D1 PTX	TPH02	MC-2
TH05	-Disable Stepper Motor	TPC03	Write Data	TPH03	MC-1
TH06	+18V	TPC04	Ground	TPH04	MC-0
		TPD01	+Inner Tracks	TPH05	+Write Gate
		TPE01	+Access 0	TPAMP1	Preamp TP1
		TPE02	+Head Engage	TPAMP2	Preamp TP2
		TPE03	+Index	TPHLD	-Head Load
		TPF01	Ground	TP24V	+24 Vdc
		TPF02	+Write/Erase Enabled	TPLED	31SD LED Voltage

Figure D-42. 31SD Control Card and Cable Pins

Appendix E. IBM 31SD Diskette Drive Maintenance Analysis Procedures (MAPs)

31SD

A

MAP 0230-1

OPERATIONAL TEST PROCEDURE

PAGE 1 OF 2

001
THIS TEST CAN BE USED AS PART OF A 'GOOD MACHINE PATH' IN A HOST SYSTEM DIAGNOSTIC OPERATION. IF A SPECIFIC ERROR HAS ALREADY BEEN OBSERVED, THE 31SD MAP 0240 CAN BE USED FOR THE ENTRY POINT INTO THE CORRECT MAP.

TO PERFORM THIS TEST THE CE WILL NEED A DISKETTE 1 DISKETTE. THIS DISKETTE SHOULD BE A KNOWN GOOD DISKETTE THAT IS WITHOUT FAILURES AND WHICH HAS BEEN INITIALIZED TO THE FORMAT NEEDED BY THE USING HOST SYSTEM. THE DISKETTE WILL BE WRITTEN ON DURING THIS TEST PROCEDURE, SO DISKETTES THAT HAVE CUSTOMER DATA ON THEM SHOULD NOT BE USED.

INSERT DISKETTE 1 IN DRIVE AND ENGAGE COLLET. CHECK FOR INDEX PULSES. SEE PAR. D.3.7.3 (SHOWING TEST PIN ARRANGEMENT).

ARE THERE PULSES ON '+INDEX' LINE?

Y N

002
GO TO 31SD NOT READY MAP 0270.

003
ENGAGE HEAD AND CHECK INDEX PULSE WIDTH.
IS WIDTH BETWEEN 1.5 AND 3.0 MILLISECONDS?

Y N

004
GO TO 31SD NOT READY MAP 0270.

005
CHECK INDEX PULSE PERIOD FROM LEADING EDGE TO LEADING EDGE.
IS PERIOD BETWEEN 162.5 AND 170.9 MILLISECONDS?

Y N

006
GO TO 31SD NOT READY MAP 0270.

007
SEEK HOME POSITION BY TAKING AT LEAST 80 REVERSE ACCESS OPERATIONS AND THEN CONDITION ALL ACCESS LINES FOR TRACK 0 LOCATION. READ TRACK 0 ID FIELDS AND COMPARE WITH EXPECTED.

CAN ALL ID FIELDS BE READ CORRECTLY?

Y N

008
GO TO 31SD ACCESS ERROR MAP 0280.

009
ACCESS TO AND READ ID FIELDS AND DATA FIELDS ON TRACKS
1,2,3,44,45,46,47,73,74,75,76,75,74,73,
47,46,45,44,3,2,1, AND 0.

CAN ALL ID FIELDS BE READ CORRECTLY?

Y N

010
GO TO 31SD ACCESS ERROR MAP 0280.

011
CAN DATA FIELDS BE READ CORRECTLY?

Y N

012
GO TO 31SD READ ERROR MAP 0260.

A

2
B

B
1

31SD
TEST
PAGE 2 OF 2

013
WHILE DOING THE ACCESS IN THE
PRECEDING STATEMENT, CHECK TO SEE
THAT '+WRITE/ERASE ENABLED' LINE IS
ALWAYS DOWN DURING ACCESS AND
READING.
IS '+WRITE/ERASE ENABLED' LINE
ALWAYS DOWN?
Y N

014
GO TO 31SD WRITE/ERASE UNSAFE MAP
0290.

015
ACCESS TO AND WRITE DATA FIELDS WITH
DATA PATTERN A5A5 ON TRACKS
4,5,6,7,48,49,
50,51,69,70,71,72,71,70,69,51,50,49,48,7,
6,5, AND 4. PERFORM A READ CHECK AFTER
EACH WRITE.
DOES DATA AND CRC READ BACK
COMPARE WITH EXPECTED?
Y N

016
GO TO 31SD WRITE ERROR MAP 0250.

017
WHILE DOING THE WRITING IN THE
PRECEDING STATEMENT CHECK TO SEE
THAT THE '+WRITE/ERASE ENABLED' LINE IS
UP DURING THE TIME THAT '+WRITE GATE' IS
UP AND BEFORE '+ERASE GATE' HAS COME
UP.
IS '+WRITE/ERASE ENABLED' LINE AT AN
UP LEVEL?
Y N

018
GO TO 31SD WRITE/ERASE UNSAFE MAP
0290.

C

MAP 0230-2

019
WHILE DOING THE WRITING IN THE
PRECEDING STATEMENT CHECK TO SEE
THAT THE '+WRITE/ERASE ENABLED' LINE IS
UP DURING THE TIME THAT '+ERASE
GATE' IS UP AFTER THE FALL OF '+WRITE
GATE'.
IS '+WRITE/ERASE ENABLED' LINE AT AN
UP LEVEL?
Y N

020
GO TO 31SD WRITE/ERASE UNSAFE MAP
0290.

021
31SD PASSES OPERATIONAL TEST
PROCEDURE. REMOVE DISKETTE AND
RETURN TO NORMAL OPERATIONS.

C

ENTRY POINT MAP

PAGE 1 OF 2

BEFORE USING THESE MAPS, ENSURE THAT THE DISKETTE IS NOT DAMAGED, AND THE PROBLEM OCCURS ON MORE THAN ONE DISKETTE.

THE FOLLOWING DEFINITIONS ARE USED WHEN MAPS REQUEST PROBING LINES.

----- LINE UP ----- UP LIGHT ON, DOWN LIGHT OFF.
 ----- LINE DOWN ----- DOWN LIGHT ON, UP LIGHT OFF.
 ----- LINE PULSING -- BOTH LIGHTS ON OR PULSING.

IF IT IS DIFFICULT TO REMOVE OR INSERT A DISKETTE IN THE DRIVE, CHECK THE HEAD LOAD BAIL RETURN SPRING AND THE PRESSURE PAD. SEE PAR.D.3.3.1.

AFTER ANY ADJUSTMENT OR PART REPLACEMENT, THE 31SD MUST BE TESTED. IF THE PROBLEM HAS NOT BEEN CORRECTED, START THE DIAGNOSTIC PROCEDURE AGAIN.

BEFORE STARTING THE PROCEDURES, REMOVE POWER AND CHECK FOR THE FOLLOWING FAILURES:

- FOREIGN MATERIAL IN DISKETTE OR DISKETTE DRIVE.
- BELT OFF OR DAMAGED.
- UNSEATED CABLES (ON CARD OR AT HOST SYSTEM END).
- AC MOTOR BINDING OR NOT TURNING.
- AC MOTOR CAPACITOR HOUSING HAVING A CRACK OR BEING DISTORTED.
- HUB BINDING OR NOT TURNING.
- LOOSE PULLEYS.
- ACCESS BAND BROKEN OR DAMAGED.
- RED FELT PAD ON LOAD ARM OF HEAD ASSEMBLY MISSING OR CONTAMINATED.

WITH POWER ON, PERFORM THE VOLTAGE SERVICE CHECK. SEE PAR.D.3.7.3 FOR TEST POINTS. POWER SPECIFICATIONS ARE DESCRIBED IN PAR.D.1.2.3. IF VOLTAGES ARE NOT CORRECT, CHECK FOR UNSEATED I/O CABLE AND GO TO HOST SYSTEM MAP ENTRY POINT.

IF ANY FAILURES OR PROBLEMS ARE FOUND, SEE THE CONTENTS TABLE IN APPENDIX D FOR REPAIR PROCEDURES.

31SD ERROR INDICATING MIGHT DIFFER FROM HOST SYSTEM TO HOST SYSTEM. IN GENERAL, ERRORS ARE COVERED BY THE FOLLOWING FIVE CLASSES:

1. 31SD WRITE ERRORS

ERRORS OCCUR WHILE DOING A READ AFTER WRITE BUT DO NOT OCCUR WHEN READING CORRECT DATA.
 GO TO MAP 0250, 31SD WRITE ERROR MAP.

2. 31SD READ ERRORS

31SD

MAP 0240-2

ENTRY POINT MAP

PAGE 2 OF 2

NO DATA RECEIVED OR DATA RECEIVED WITH CRC ERRORS.
GO TO MAP 0260, 31SD READ ERROR MAP.

3. 31SD NOT READY

WRONG INDEX PULSES OBSERVED.
GO TO MAP 0270, 31SD NOT READY MAP.

4. 31SD ACCESS ERRORS

FAILED TO READ EXPECTED TRACK ADDRESS BECAUSE OF AN ACCESS TO WRONG TRACK, OR
READ ID ERROR OCCURRED AFTER AN ACCESS TO CORRECT TRACK.
GO TO MAP 0280, 31SD ACCESS ERROR MAP.

5. 31SD WRITE/ERASE UNSAFE

FAILED BECAUSE ERASE CURRENT IS ON WHEN ERASE GATE IS OFF, OR ERASE CURRENT IS OFF
WHEN ERASE GATE IS ON.
OR,
FAILED BECAUSE WRITE CURRENT IS ON WHEN WRITE GATE IS OFF, OR WRITE CURRENT IS OFF
WHEN WRITE GATE IS ON.
GO TO MAP 0290, 31SD WRITE/ERASE UNSAFE MAP.

WRITE ERROR MAP

PAGE 1 OF 1

001
 USE THIS MAP ONLY WHEN THERE ARE
 ERRORS WHILE DOING A READ AFTER WRITE.
 IF ERRORS OCCUR WHILE READING CORRECT
 DATA, GO TO MAP 0260.

PERFORM A WRITE OPERATION.
 PROBE 'WRITE DATA' AND '+WRITE GATE'
 WHILE WRITING.
 SEE PAR. D.3.7.3.
 BOTH LINES HAVE PULSES?
 Y N

002
 CHECK I/O TEST PINS FOR SIGNALS, SEE
 PAR. D.3.7.3, THEN GO TO HOST
 SYSTEM MAP ENTRY POINT.

003
 PROBE '+INNER TRACKS' WHILE DOING AN
 ACCESS FROM LOW TO HIGH TRACKS (MUST
 GO ACROSS TRACKS 40-44).
 SEE PAR. D.3.7.3.
 DID LINE LEVEL CHANGE FROM DOWN TO
 UP?
 Y N

004
 CHECK I/O TEST PINS FOR SIGNALS, SEE
 PAR. D.3.7.3, THEN GO TO HOST
 SYSTEM MAP ENTRY POINT.

005
 EXCHANGE DISKETTE DRIVE CONTROL CARD
 AND WRITE DATA.
 ANY MORE ERRORS?
 Y N

006
 PROBLEM IS CORRECTED.

007
 EXCHANGE HEAD/CARRIAGE ASSEMBLY
 AND WRITE DATA.
 SEE D.3.2.4.
 ANY MORE ERRORS?
 Y N

008
 PROBLEM IS CORRECTED.

009
 GO TO HOST SYSTEM MAP ENTRY POINT.

31SD

READ ERROR MAP

PAGE 1 OF 4

ENTRY POINTS

FROM	ENTER THIS MAP		
MAP NUMBER	ENTRY POINT	PAGE NUMBER	STEP NUMBER
0280	A	1	003

EXIT POINTS

MAP 0260-1

EXIT THIS MAP		TO	
PAGE NUMBER	STEP NUMBER	MAP NUMBER	ENTRY POINT
1	004	0270	B
1	002	0280	A

001
 NO DATA RECEIVED OR DATA RECEIVED
 WITH CRC ERROR.

VISUALLY CHECK CARRIAGE MOVEMENT BY
 DOING AN ACCESS ELECTRICALLY SEVERAL
 TRACKS IN EACH DIRECTION.
 IS IT DOING AN ACCESS CORRECTLY?

Y N

002
 GO TO MAP 0280, ENTRY POINT A.

003
 (ENTRY POINT A)

IF AN OSCILLOSCOPE IS AVAILABLE, SEE
 PAR. D.3.6.1 AND PERFORM THE DISKETTE
 SPEED SERVICE CHECK. IF NO
 OSCILLOSCOPE IS AVAILABLE AN ESTIMATE
 MUST BE MADE.
 IS DISK SPEED CORRECT?

Y N

004
 GO TO MAP 0270, ENTRY POINT B.

2
A

A
1

31SD

READ ERROR MAP

PAGE 2 OF 4

005

PROBE '+ INNER TRACKS' WHILE DOING AN
ACCESS FROM LOW TO HIGH TRACKS (MUST
GO ACROSS TRACKS 40-44). SEE PAR. D.3.7.3
DID LINE LEVEL CHANGE FROM DOWN TO
UP?

Y N

006

CHECK I/O TEST PINS FOR SIGNALS, SEE
PAR. D.3.7.3, THEN GO TO HOST
SYSTEM MAP ENTRY POINT.

007

CHECK INPUT VOLTAGES '+5VDC', '-5VDC',
AND '+24VDC'.

SEE PAR. D.3.7.3 FOR TEST POINTS AND
PAR. D.1.2.2 FOR POWER
SPECIFICATIONS.

ARE VOLTAGES CORRECT?

Y N

008

CHECK I/O TEST PINS FOR SIGNALS, SEE
PAR. D.3.7.3, THEN GO TO HOST
SYSTEM MAP ENTRY POINT.

009

JUMPER '-HEAD LOAD' TEST POINT ON
DISKETTE DRIVE CONTROL CARD TO DC
GROUND. SOLENOID IS ACTIVATED
CAUSING BAIL TO LOAD HEADS.

SEE PAR. D.3.7.3.

DOES THE HEAD LOAD BAIL MOVE?

Y N

3
B C

C

MAP 0260-2

010

CHECK FOR THE CORRECT PATH OF BAIL
ACTUATOR CABLE.

SEE PAR. D.3.3.8.

IS PATH CORRECT AND IS CABLE
COMPLETE?

Y N

011

EXCHANGE OR CORRECT THE CABLE
PATH.

PERFORM SOLENOID BAIL SERVICE
CHECK. SEE PAR. D.3.3.1.

012

REMOVE BAIL. SEE PAR. D.3.3.5.

IS THE BAIL RETURN SPRING IN ITS
CORRECT POSITION AND COMPLETE?

Y N

013

EXCHANGE BAIL RETURN SPRING.
SEE PAR. D.3.3.6.

014

PROBE '+HEAD ENGAGE'.

SEE PAR. D.3.7.3.

IS LINE DOWN?

Y N

015

CHECK I/O TEST PINS FOR SIGNALS, SEE
PAR. D.3.7.3, THEN GO TO HOST
SYSTEM MAP ENTRY POINT.

3
D

B D
2 2

31SD

READ ERROR MAP

PAGE 3 OF 4

016

CHECK HEAD LOAD SOLENOID
RESISTANCE.

SEE THE FIGURES ASSOCIATED WITH
PAR. D.3.3.5.

RESISTANCE IS MEASURED 140 TO 210
OHMS AT NORMAL ROOM TEMPERATURE.
IF SOLENOID HAS BEEN ACTIVATED AND
CASE IS HOT, RESISTANCE CAN MEASURE
UP TO 400 OHMS.

IS SOLENOID RESISTANCE INSIDE
LIMITS?

Y N

017

REPAIR OR EXCHANGE WHEN NEEDED.

018

OPERATE BAIL BY HAND.

CHECK TO SEE THAT SOLENOID AND BAIL
ARE FREE OF BINDS.

CHECK TO SEE THAT BAIL RETURN SPRING
RETURNS BAIL TO ITS STOP.

ANY BINDS OBSERVED?

Y N

019

EXCHANGE DISKETTE DRIVE CONTROL
CARD AND CHECK FOR GOOD
OPERATION.

SEE PAR. D.3.7.1.

020

REPAIR OR EXCHANGE THE BINDING PART.

SEE PAR. D.3.3.5.

021

CHECK IDLER PULLEY BRACKET SCREW.

SEE PAR. D.3.3.8.

IS IT TIGHT?

Y N

E F

E F

MAP 0260-3

022

TIGHTEN BRACKET SCREW.
PERFORM SOLENOID BAIL SERVICE
CHECK. SEE PAR. D.3.3.1.

023

PERFORM HEAD LOAD SOLENOID SERVICE
CHECK

SEE PAR. D.3.3.1.

IS SERVICE CHECK CORRECT?

Y N

024

ADJUST OR EXCHANGE WHEN NEEDED.

025

CHECK ADJUSTMENT OF HEAD/CARRIAGE
ASSEMBLY.

SEE PAR. D.3.2.2.

IS ADJUSTMENT CORRECT?

Y N

026

ADJUST HEAD/CARRIAGE ASSEMBLY.

SEE PAR. D.3.2.3.

027

EXCHANGE DISKETTE DRIVE CONTROL CARD
AND CHECK FOR GOOD OPERATION.

SEE PAR. D.3.7.1.

ANY MORE ERRORS?

Y N

028

PROBLEM IS CORRECTED.

029

IS AN OSCILLOSCOPE AVAILABLE?

Y N

4 4
G H

G H
3 3

31SD

MAP 0260-4

READ ERROR MAP

PAGE 4 OF 4

030
EXCHANGE HEAD/CARRIAGE ASSEMBLY
AND CHECK FOR GOOD OPERATION.

SEE PAR. D.3.2.4
ANY MORE ERRORS?
Y N

031
PROBLEM IS CORRECTED.

032
GO TO HOST SYSTEM MAP ENTRY POINT.

033
CHECK READ SIGNAL AT 'TPAMP1' AND
'TPAMP2'. COMPARE TO SCREEN IMAGE IN
PAR. D.2.3

DOES THE READ SIGNAL APPEAR
DIFFERENT THAN SCREEN IMAGE?
Y N

034
PROBE '+FILE DATA'. COMPARE TO
SCREEN IMAGE IN PAR. D.2.3
DOES SIGNAL APPEAR DIFFERENT THAN
SCREEN IMAGE?
Y N

035
GO TO HOST SYSTEM MAP ENTRY
POINT.

036
EXCHANGE HEAD/CARRIAGE ASSEMBLY
AND CHECK FOR GOOD OPERATION.

SEE PAR. D.3.2.4

037
EXCHANGE HEAD/CARRIAGE ASSEMBLY
AND CHECK FOR GOOD OPERATION.

SEE PAR. D.3.2.4

NOT READY MAP

PAGE 1 OF 4

ENTRY POINTS

FROM ENTER THIS MAP			
MAP NUMBER	ENTRY POINT	PAGE NUMBER	STEP NUMBER
0260	B	4	046

001
 USE THIS MAP WHEN WRONG INDEX PULSES ARE OBSERVED.
 SEE PAR. D.1.1.1 ABOUT DISKETTE HOLDING.

DO YOU HAVE THE CORRECT DISKETTE?
 Y N

002
 USE THE CORRECT DISKETTE.

003
 IS DISKETTE FREE FROM DAMAGE?
 Y N

004
 EXCHANGE DISKETTE.

005
 IS DISKETTE INSERTED CORRECTLY?
 SEE PAR. D.1.1.1 ABOUT DISKETTE INSERTING.
 Y N

006
 RESEAT DISKETTE CORRECTLY.

007
 JUMPER '- HEAD LOAD' TEST POINT ON DISKETTE DRIVE CONTROL CARD TO DC GROUND. SEE PAR. D.3.7.3. SOLENOID IS ACTIVATED CAUSING BAIL TO LOAD HEADS, AND PUT MAXIMUM LOAD ON DRIVE PARTS.
 IS HUB PULLEY TURNING?
 Y N

008
 (ENTRY POINT A)
 SEE PAR. D.3.3.7.
 IS BELT INSTALLED AND FOLLOWING A CORRECT PATH?
 Y N

009
 INSTALL OR EXCHANGE BELT.

010
 KEEP HEAD LOADED.
 IS AC MOTOR PULLEY TURNING?
 Y N

011
 IS AC MOTOR SHAFT TURNING?
 Y N

012
 MEASURE AC VOLTAGE AT AC MOTOR CONNECTOR.
 SEE PAR. D.1.2.2 FOR POWER SPECIFICATIONS.
 IS AC VOLTAGE CORRECT AT AC MOTOR CONNECTOR?
 Y N

013
 CHECK I/O TEST PINS FOR SIGNALS, SEE PAR. D.3.7.3.
 THEN GO TO HOST SYSTEM MAP ENTRY POINT.

2 2 2 2
 B C D E

A

E
1

31SD
NOT READY MAP
PAGE 2 OF 4

014
SWITCH OFF AC POWER, REMOVE BELT, LET IT COOL 5 MINUTES, THEN SWITCH ON AC POWER.
DOES AC MOTOR START?
Y N

015
EXCHANGE AC MOTOR STARTING CAPACITOR. SEE PAR. D.3.4.1.
DOES AC MOTOR START?
Y N

016
EXCHANGE AC MOTOR. SEE PAR. D.3.4.1.

017
PROBLEM IS CORRECTED.

018
CHECK HUB ASSEMBLY FOR BINDS WITH COLLET ENGAGED.
IS HUB FREE OF BINDS?
Y N

019
DISENGAGE COLLET AND CHECK FOR BINDS AND NOISE.
IS HUB FREE OF BINDS AND NOISE?
Y N

020
COMPLETELY EXCHANGE 31SD ASSEMBLY.

021
EXCHANGE COLLET ASSEMBLY WHEN NEEDED.
SEE PAR. D.3.1.

022
REINSTALL BELT. IF A PROBLEM IS STILL PRESENT, EXCHANGE AC MOTOR.
SEE PAR. D.3.4.1.

B C D
1 1 1

MAP 0270-2

023
AC MOTOR PULLEY IS LOOSE. ADJUST AND TIGHTEN.
SEE PAR. D.3.4.6.

024
CHECK HUB ASSEMBLY FOR BINDS WITH COLLET ENGAGED.
IS HUB FREE OF BINDS?
Y N

025
DISENGAGE COLLET AND CHECK FOR BINDS AND NOISE.
IS HUB FREE OF BINDS AND NOISE?
Y N

026
COMPLETELY EXCHANGE 31SD ASSEMBLY.

027
EXCHANGE COLLET ASSEMBLY WHEN NEEDED.
SEE PAR. D.3.1.

028
EXCHANGE BELT.
SEE PAR. D.3.4.

029
IS COLLET TURNING?
Y N

030
DISENGAGE COLLET AND REMOVE DISKETTE. THE HUB SHOULD BE TURNING.
IS THE HUB TURNING?
Y N

031
COMPLETELY EXCHANGE 31SD ASSEMBLY.

3 3
F G

F G
2 2

31SD

NOT READY MAP

PAGE 3 OF 4

032
EXCHANGE 31SD COLLET ASSEMBLY.
SEE PAR. D.3.1.

033
PROBE '+ INDEX' WITH A FAILING DISKETTE
INSERTED.
SEE PAR. D.3.7.3.
IS LINE PULSING?
Y N

034
CHECK '+5VDC', '-5VDC', AND '+24VDC'
INPUT VOLTAGES TO DISKETTE DRIVE
CONTROL CARD.
SEE PAR. D.3.7.3 FOR TEST POINTS.
POWER SPECIFICATIONS ARE DESCRIBED
IN PAR. D.1.2.3.2.
ARE VOLTAGES CORRECT?
Y N

035
CHECK I/O TEST PINS FOR SIGNALS,
SEE PAR. D.3.7.3, THEN GO TO HOST
SYSTEM MAP ENTRY POINT.

036
PERFORM LED OUTPUT SERVICE CHECK
FOR FAILING DISKETTE.
SEE PAR. D.3.6.2.
IS LED VOLTAGE CORRECT?
Y N

037
REMOVE/EXCHANGE THE LED. SEE
PAR. D.3.6.3.
ANY MORE ERRORS?
Y N

038
PROBLEM IS CORRECTED.

H J K

MAP 0270-3

039
EXCHANGE DISKETTE DRIVE CONTROL
CARD AND CHECK FOR GOOD
OPERATION.
SEE PAR. D.3.7.1.

040
PERFORM PTX SERVICE CHECK.
SEE PAR. D.3.6.5.
IS OUTPUT CORRECT FOR DISKETTE
BEING USED?
Y N

041
EXCHANGE DISKETTE DRIVE CONTROL
CARD AND CHECK FOR GOOD
OPERATION.
SEE PAR. D.3.7.1.
ANY MORE ERRORS?
Y N

042
PROBLEM IS CORRECTED.

043
EXCHANGE PTX ASSEMBLY.
SEE PAR. D.3.6.6.

044
EXCHANGE PTX ASSEMBLY.
SEE PAR. D.3.6.6.

045
USE HOST SYSTEM INDICATOR, OR, IF AN
OSCILLOSCOPE IS AVAILABLE, PERFORM
DISKETTE SPEED SERVICE CHECK.
SEE PAR. D.3.6.1.
HEAD MUST BE LOADED DURING DISKETTE
SPEED CHECK.
IF HOST SYSTEM INDICATOR OR
OSCILLOSCOPE IS NOT AVAILABLE, AN
ESTIMATE MUST BE MADE OF THE DISK
SPEED.
IS DISK SPEED CORRECT?
Y N

4 4
L M

H J K

L M
3 3

31SD

MAP 0270-4

NOT READY MAP

PAGE 4 OF 4

046

(ENTRY POINT B)

CHECK LEVER, SPRING, AND COLLET.
ARE LEVER, SPRING, AND COLLET OK?

Y N

047

EXCHANGE WHEN NEEDED.
SEE PAR. D.3.1.

048

PERFORM HEAD LOAD SOLENOID SERVICE

CHECK.

SEE PAR. D.3.3.

IS ADJUSTMENT CORRECT?

Y N

049

ADJUST SOLENOID.

050

GO TO PAGE 1, STEP 008, ENTRY POINT A.

051

CHECK I/O TEST PINS FOR SIGNALS, SEE
PAR. D.3.7.3, THEN GO TO HOST SYSTEM
MAP ENTRY POINT.

31SD

SEEK ERROR MAP

PAGE 1 OF 4

ENTRY POINTS

FROM	ENTER THIS MAP		
MAP NUMBER	ENTRY POINT	PAGE NUMBER	STEP NUMBER
0260	A	2	005

EXIT POINTS

MAP 0280-1

EXIT THIS MAP		TO	
PAGE NUMBER	STEP NUMBER	MAP NUMBER	ENTRY POINT
1	004	0260	A

001
 FAILED TO READ DESIRED TRACK ADDRESS
 BECAUSE OF AN ACCESS TO WRONG TRACK,
 OR READ ID ERROR OCCURRED AFTER AN
 ACCESS TO CORRECT TRACK.

CHECK HEAD/CARRIAGE ASSEMBLY
 ADJUSTMENT.
 SEE PAR. D.3.2.2.
 NOTE - IF STEPPER MOTOR WILL NOT
 DETENT DURING THIS ADJUSTMENT, GO TO
 ENTRY POINT 'A' OF THIS MAP.
 HEAD ADJUSTMENT CORRECT?

Y N

002
 PERFORM HEAD/CARRIAGE
 ADJUSTMENT.
 SEE PAR. D.3.2.3.
 CHECK FOR GOOD OPERATION.

003
 CHECK CARRIAGE MOVEMENT BY DOING AN
 ACCESS AT LEAST FOUR TRACKS IN EACH
 DIRECTION. ALSO DO A SEEK FROM TRACK 4
 TO TRACK 0 BY 4 TRACKS SEVERAL TIMES.
 DOES CARRIAGE MOVEMENT LOOK
 UNUSUAL OR DOES NOT MOVE?

Y N

004
 READ PROBLEM.
 GO TO MAP 0260, ENTRY POINT A.

2
A

A
1

31SD

MAP 0280-2

SEEK ERROR MAP

PAGE 2 OF 4

005

(ENTRY POINT A)
CHECK '+24 V DC' FROM THE HOST SYSTEM.
SEE PAR. D.3.7.3 FOR TEST POINTS, AND
PAR. D.1.2.2 FOR POWER
SPECIFICATIONS.
IS VOLTAGE CORRECT?

Y N

006

CHECK I/O TEST PINS FOR SIGNALS, SEE
PAR. D.3.7.3, THEN GO TO HOST
SYSTEM MAP ENTRY POINT.

007

PROBE '+ ACCESS 0' AND '+ ACCESS 1' WHILE
DOING AN ACCESS FOUR TRACKS.
SEE PAR. D.3.7.3.
DO BOTH LINES HAVE PULSES?

Y N

008

CHECK I/O TEST PINS FOR SIGNALS, SEE
PAR. D.3.7.3, THEN GO TO HOST
SYSTEM MAP ENTRY POINT.

009

DO A SEEK TO TRACK 00. USE THE
VOLTMETER TO MEASURE VOLTAGE ON
DISKETTE DRIVE CONTROL CARD TEST
POINTS 'MC-0', 'MC-1', 'MC-2', AND 'MC-3'
SEE PAR. D.3.7.3.
CHECK EACH TEST POINT AND COMPARE
RESULTS TO TABLE AT RIGHT. DOWN LEVEL
IS 0 TO 2.0 V DC AND UP LEVEL IS 21.6 TO
26.4 V DC. SINGLE CYCLE STEP TO TRACK 01
AND REPEAT MEASUREMENTS. REPEAT FOR
TRACKS 02 AND 03.

STEPPER MOTOR
TEST PINS

	MC 0	MC 1	MC 2	MC 3
TRACK 00	DOWN	UP	UP	UP
TRACK 01	UP	DOWN	UP	UP
TRACK 02	UP	UP	DOWN	UP
TRACK 03	UP	UP	UP	DOWN

ARE RESULTS THE SAME AS TABLE AT
RIGHT?

Y N

3 3
B C

C
2

31SD
SEEK ERROR MAP
PAGE 3 OF 4

010
MEASURE RESISTANCES OF EACH STEPPER
MOTOR COIL AT PINS IN STEPPER MOTOR
CONNECTOR. RESISTANCE ACROSS EACH
COIL TO COMMON IS 115-141 OHMS. (SEE
PAR. D.3.7.3 FOR PIN LOCATIONS.)
ARE RESISTANCES OF ALL FOUR COILS
CORRECT?
Y N

011
EXCHANGE STEPPER MOTOR.
SEE PARS. D.3.5.1 AND D.3.5.2.
ANY MORE FAILURES?
Y N

012
PROBLEM IS CORRECTED.

013
CHECK '+ 5 V DC' AND '+ 24 V DC' INPUT
VOLTAGES TO DISKETTE DRIVE CONTROL
CARD.
SEE PAR. D.3.7.3 FOR TEST POINTS AND
PAR. D.1.2.2 FOR POWER
SPECIFICATIONS.
ARE VOLTAGES CORRECT?
Y N

014
CHECK I/O TEST PINS FOR SIGNALS,
SEE PAR. D.3.7.3, THEN GO TO HOST
SYSTEM MAP ENTRY POINT.

015
EXCHANGE DISKETTE DRIVE CONTROL
CARD AND CHECK FOR GOOD OPERATION.
SEE PAR. D.3.7.1.

B D
2

MAP 0280-3

016
CHECK '+ 5 V DC' AND '+ 24 V DC' INPUT
VOLTAGES TO DISKETTE DRIVE CONTROL
CARD.
SEE PAR. D.3.7.3 FOR TEST POINTS
AND PAR. D.1.2.2 FOR POWER
SPECIFICATIONS.
ARE VOLTAGES CORRECT?
Y N

017
CHECK I/O TEST PINS FOR SIGNALS,
SEE PAR. D.3.7.3, THEN GO TO HOST
SYSTEM MAP ENTRY POINT.

018
EXCHANGE DISKETTE DRIVE CONTROL
CARD AND CHECK FOR GOOD OPERATION.
SEE PAR. D.3.7.1.

019
MEASURE RESISTANCE OF EACH STEPPER
MOTOR COIL AT PINS IN STEPPER MOTOR
CONNECTOR. RESISTANCE ACROSS EACH
COIL TO COMMON IS 115-141 OHMS. (SEE
PAR. D.3.7.3 FOR PIN LOCATIONS)
ARE RESISTANCES OF ALL FOUR COILS
CORRECT?
Y N

020
EXCHANGE STEPPER MOTOR.
SEE PAR. D.3.5.1.

021
CHECK THAT STEPPER MOTOR PULLEY
CLAMP IS TIGHT AND PULLEY IS TIGHT ON
STEPPER MOTOR SHAFT.
SEE PAR. D.3.5.4.
IS IT TIGHT?
Y N

022
ADJUST AND TIGHTEN STEPPER MOTOR
PULLEY.

D

4
E

E
3

31SD
SEEK ERROR MAP
PAGE 4 OF 4

023
CHECK STEPPER MOTOR DRIVE BAND TO SEE
THAT IT IS NOT DAMAGED.
SEE PAR. D.3.5.5.
IS STEPPER MOTOR DRIVE BAND NOT
DAMAGED?

Y N

024
EXCHANGE BAND

025
REMOVE SCREWS THAT CLAMP DRIVE BAND
TO CARRIAGE.
SEE PAR. D.3.5.6.
CAREFUL NOT TO DAMAGE BAND, CHECK TO
SEE THAT CARRIAGE MOVES FREELY ON ITS
GUIDE RODS AT CENTER AND BOTH LIMITS
OF CARRIAGE MOVEMENT.
DOES CARRIAGE MOVE FREELY?

Y N

026
CLEAN OR EXCHANGE WHEN NECESSARY.

027
REMOVE DRIVE BAND FROM STEPPER
MOTOR PULLEY.
SEE PAR. D.3.5.7.
DOES STEPPER MOTOR BIND WITH
PULLEY ATTACHED?

Y N

028
INSTALL NEW DRIVE BAND AND ADJUST.

029
IS THERE A GAP BETWEEN STEPPER
MOTOR PULLEY AND CASTING?
SEE PAR. D.3.5.1 FOR FIGURE OF
WHERE TO OBSERVE GAP.

Y N

F G

F G

MAP 0280-4

030
ADJUST PULLEY SO THAT THERE IS A GAP
AND THE DRIVE BAND TRACKS
CORRECTLY.
SEE PAR. D.3.5.6.

031
EXCHANGE STEPPER MOTOR.
SEE PAR. D.3.5.1.

WRITE/ERASE UNSAFE MAP

PAGE 1 OF 2

001 FAILED BECAUSE ERASE CURRENT IS ON WHEN ERASE GATE IS OFF, OR ERASE CURRENT IS OFF WHEN ERASE GATE IS ON.

OR,

FAILED BECAUSE WRITE CURRENT IS ON WHEN WRITE GATE IS OFF, OR WRITE CURRENT IS OFF WHEN WRITE GATE IS ON.

PROBE '+ WRITE/ERASE ENABLED' WHILE GIVING A COMMAND TO WRITE DATA. SEE PAR. D.3.7.3.

THIS LINE IS PULSING DURING THE COMMAND. IS LINE PULSING FOR WRITE COMMAND?

Y N

002 IS LINE AT A DOWN LEVEL FOR WRITE COMMAND?

Y N

003 PROBE '+ERASE GATE' AND '+WRITE GATE' WHILE WRITING. SEE PAR. D.3.7.3.

THESE LINES ARE PULSING DURING A WRITE OPERATION. ARE LINES PULSING DURING WRITE OPERATION?

Y N

004 CHECK I/O TEST PINS FOR SIGNALS. SEE PAR. D.3.7.3, THEN GO TO HOST SYSTEM MAP ENTRY POINT.

005 EXCHANGE DISKETTE DRIVE CONTROL CARD AND CHECK FOR GOOD OPERATION. SEE PAR. D.3.7.1.

IS OPERATION ACCEPTABLE?

Y N

006 EXCHANGE HEAD CARRIAGE ASSEMBLY AND CHECK FOR GOOD OPERATION. SEE PAR. D.3.3.

IS OPERATION ACCEPTABLE?

Y N

007 FAILING HEAD/CARRIAGE ASSEMBLY THAT WAS EXCHANGED MAY HAVE DAMAGED DISKETTE DRIVE CONTROL CARD. EXCHANGE DISKETTE DRIVE CONTROL CARD AND CHECK FOR GOOD OPERATION. SEE PAR. D.3.7.1.

008 PROBLEM IS CORRECTED.

009 PROBLEM IS CORRECTED.

010 PROBE '+ERASE GATE' AND '+WRITE GATE' WHILE WRITING. SEE PAR. D.3.7.3.

THESE LINES ARE PULSING DURING A WRITE OPERATION. ARE LINES PULSING FOR WRITE COMMAND?

Y N

011 CHECK I/O TEST PINS FOR SIGNALS, SEE PAR. D.3.7.3, THEN GO TO HOST SYSTEM MAP ENTRY POINT.

2 A B C

2 D

A D
1 1

31SD

MAP 0290-2

WRITE/ERASE UNSAFE

PAGE 2 OF 2

012

EXCHANGE DISKETTE DRIVE CONTROL
CARD.
SEE PAR. D.3.7.1.

013

PROBE '+WRITE/ERASE ENABLED' WHILE
GIVING A COMMAND TO READ DATA.
SEE PAR. D.3.7.3.
THIS LINE IS AT A DOWN LEVEL DURING
READ A OPERATION.
IS LINE DOWN DURING A READ
OPERATION?

Y N

014

PROBE '+ERASE GATE' AND '+WRITE GATE'
WHILE GIVING A COMMAND TO READ
DATA.
SEE PAR. D.3.7.3.
THESE LINES ARE DOWN DURING A READ
OPERATION.
ARE LINES DOWN DURING A READ
OPERATION?

Y N

015

CHECK I/O TEST PINS FOR SIGNALS,
SEE PAR. D.3.7.3, THEN GO TO HOST
SYSTEM MAP ENTRY POINT.

016

EXCHANGE DISKETTE DRIVE CONTROL
CARD.
SEE PAR. D.3.7.1.

017

CHECK I/O TEST PINS FOR SIGNALS, SEE
PAR. D.3.7.3, THEN GO TO HOST SYSTEM
MAP ENTRY POINT.

GLOSSARY

- BAIL - IT ALLOWS THE HEADS OR HEAD AND PAD TO COME TOGETHER OR TO BRING THEM APART AND HOLDS THE MEDIA FIRMLY IN THE PLANE OF THE HEAD(S) ON DISKETTE STORAGE DEVICES.
- BAND - SOMETHING THAT CONFINES OR CONSTRICTS WHILE ALLOWING A DEGREE OF MOVEMENT.
- COLLET - A MECHANISM THAT CENTERS AND CLAMPS THE DISK.
- CRC - CYCLIC REDUNDANCY CHECK.
- DETENT - THE ACT OR FACT OF DETAINING OR HOLDING IN PLACE BY A FORCE.
- HUB - PROVIDES A REGISTRATION SURFACE AND IMPARTS ROTATIONAL MOTION OF THE DISK.
- ID - IDENTIFICATION
- I/O - INPUT/OUTPUT
- MC - MOTOR CONTROL
- MIM - MAINTENANCE INFORMATION MANUAL
- PAR - PARAGRAPH
- PTX - PHOTOTRANSISTOR
- STEPPER MOTOR - MOTOR THAT IS USED TO MOVE THE ACCESS MECHANISM OF A DIRECT-ACCESS STORAGE DEVICE TO A SPECIFIED LOCATION.

Appendix F. X.21 Switched Feature

F.1 INTRODUCTION

The 3274 X.21 Switched feature allows the 3274 Model 51C to be attached to the DCE that electrically matches CCITT Recommendation X.27, and that operates as specified in CCITT Recommendation X.21 at speeds of 2400, 4800, 9600 and 48,000 bps.

To use the X.21 Switched feature, the 3274 must have either a 3278 Display Station or 3279 Color Display Station attached.

F.2 FUNCTIONAL DESCRIPTION

The 3274 supports the following for the X.21 Switched feature:

- SDLC CAC to support X.21 Switched protocol.
- Data Link Control, which is an interface to the SDLC CAC.
- X.21 Switched Adapter card.

This section defines the function of the Data Link Control, which issues function requests to the CAC and handles completion codes from the CAC. Figure F-1 outlines the Data Link Control function.




Figure F-1. Data Link Control Function

F.2.1 X.21 Switched CAC Function

F.2.1.1 Function Requests

1. OPEN for outgoing call

By this request, the HPCA and the X.21 hardware are reset, enabled, and, after passing through the ready state, proceed with the outgoing call establishment.

The CAC signals the X.21 hardware to enter the call-request state and awaits the reception of an IA5 plus (+) character from the network.

When the request contains selection signals, the CAC/X.21 hardware sends two IA5 sync characters and the selection signals (including dial digits) that were set up by the Data Link Control in the selection signal buffer.

The X.21 hardware monitors the network interface; if Call Progress signals and/or called line identification are received, they are passed on to the CAC. After translation, the CAC will pass the first Call Progress signal (normally two digits) or line ID to the Data Link Control's buffer and post an intermediate completion status.

When the CAC detects that the network is ready for data, the CAC will enter the data-transfer phase after housekeeping and preparing the X.21 hardware and CAC to receive the first SDLC frame. The Data Link Control is notified that the Open is completed.

The process is similar when the outgoing call is direct. A direct call by the Data Link Control identifies a direct call by specifying no dial digits. When the IA5 plus (+) character is received, signifying select from the network, the CAC enters the DTE waiting state for the reception of Call Progress signals, called line identification, or the indication that the network is ready for data.

2. OPEN for incoming call

When the Data Link Control issues the X.21 Open function request for an incoming call, the action of the CAC/X.21 hardware differs slightly from that for an outgoing call.

- The CAC/X.21 hardware determines that the network is ready, then enters the ready state to await an interrupt from the X.21 hardware signifying activity on the network.
- Receipt of one IA5 BEL character identifies the incoming call state. The CAC posts an intermediate completion status (BEL RCVD) and, when it regains control, prompts the X.21 hardware to turn on the control lead that signifies the call-accepted state.

- The CAC now waits for an interrupt to indicate either that the calling line identification has been received, or that the network is ready for data. If line identification is received, the CAC moves it to the Data Link Control's buffer, and the completion status is passed on the same way as for an outgoing call.

When Ready-for-Data is detected, the data-transfer phase is entered after the CAC completes appropriate housekeeping and prepares the X.21 hardware for the first SDLC frame. A normal completion to the Open function request is posted by the CAC.

3. OPEN for monitoring

The CAC checks the X.21 interface periodically. If the DCE's status coincides with the condition specified by the Data Link Control, that is, DCE ready or DCE not ready, the CAC reports normal completion.

4. Close

If the clearing sequence has already completed, the CAC merely executes the final housekeeping requirements; otherwise, the CAC starts a clearing sequence. When the clearing ends properly, and no comparator error is indicated by the X.21 hardware, a normal completion is posted. When the clearing sequence does not end properly within its time limit, or if a comparator error exists, appropriate error status is posted. The HPCA and X.21 hardware are always reset prior to posting any completion code to the Close FR. The CAC/X.21 hardware will be in the controlled-not-ready state when this FR ends.

5. HALT

The Data Link Control aborts an OPEN function request by issuing a HALT request. The CAC executes a clearing sequence to the network.

F.2.1.2 Call Collision

A call-collision condition can exist when a call request is made to the network at the same time the network is making an incoming call. The network will resolve the collision in favor of the call request.

Note: *The X.21 recommendation does not permit deliberate call collisions; that is, the DTE entering the call-request state after becoming aware of the incoming-call state.*

Therefore, the Data Link Control avoids deliberate situations by issuing the proper sequence of function requests; for example, by issuing a HALT request to the Open-for-Incoming request before issuing the Open-for-Outgoing request.

F.2.1.3 Call Progress (CP) Signals

The only time the CAC is affected by a particular call progress (CP) signal is if the first digit of a received CP signal is an IA5 "0," "2," or "6."

The IA5 "0" identifies the call-wait class (terminal called or waiting connection). The action of the CAC upon detecting the IA5 "0" is to initiate a 60-second timeout instead of the 2-second timeout, while waiting for the network to become ready for data. Upon detecting the IA5 "2" or "6" (short-term condition when clearing), the CAC prepares for the retry by initiating a clearing sequence. CP signals already received will be moved to the Data Link Control's buffer.

When reacting to a IA5 "0" CP, the CAC will post the intermediate completion status, indicating that CP signals are available in the buffer. When reacting to the IA5 "2" or "6" CPs, the retry intermediate status is posted, indicating that the retry is due to receipt of a retry type CP signal.

F.2.2 Data Link Control Function

F.2.2.1 Call Ready

The Call-Ready indicator is displayed in the Operator Information Area of the 3278 or 3279 and the use of either the DIAL key, DIRECT key, or LOCAL key is accepted, as is an incoming call.

This state is the X.21-Ready state and is entered by the Open-for-Incoming request to the CAC under the following conditions:

1. Immediately after POR of the 3274 by the Uncontrolled-Not-Ready state.
2. When the COMM key is pressed while operating in the local mode.
3. When the Dial-In mode is ended by the DISC key.
4. After the line is disconnected normally by the DISC key on the DISC command.
5. When the Open Outgoing request is rejected by CP signals.
6. After the line is disconnected by an error, or after the X.21 open request is completed erroneously, except if condition 7 exists. However, the Call-Ready indicator is overridden by the Comm Error Reminder. This reminder can be reset by the COMM key, and the Call-Ready indicator will appear.
7. If the DCE is not ready, the Comm Error Reminder is displayed, and the Open-Monitor request is issued. When this request is completed, the Call-Ready indicator is displayed in the Operator Information Area.

F.2.2.2 Incoming Call In Process

When an incoming call comes to the 3274 while in the X.21 Ready state, the CAC returns the intermediate completion code with 'BEL RCVD'. The Data Link Control will display the Incoming-Call-In-Process indicator and returns control to the CAC. When the Ready-for-Data is sent from the DCE, the CAC will return a normal completion code. The Data Link Control turns off the Incoming-Call-In-Process indicator, turns on the In-Use indicator, and prepares for normal data exchange.

F.2.2.3 Dialing

When the DIAL key is pressed in the Call-Ready state, the Data Link Control issues the HALT request to the CAC to inhibit an incoming call, clears the screen, and puts the cursor at the home position. The Wait indicator is displayed until the HALT request is completed. Then the Dial-In indicator is displayed.

The operator enters dial digits, or any facility request allowed by the network, and presses the Enter key.

The Data Link Control issues an Open-for-Outgoing request to the CAC with parameters that include selection signals entered by the operator, and displays the Outgoing-Call-In-Process indicator.

F.2.2.4 Direct Call

When the DIRECT key is pressed in the Call-Ready state, the Data Link Control issues the HALT request, the Open-for-Outgoing request, with no selection signal, and displays the Outgoing-Call-In-Process indicator.

F.2.2.5 Outgoing Call In Process

The CAC processes the Open-for-Outgoing request, as described under section F.2.1.1 and returns a normal-completion code to the Data Link Control when the X.21 Ready-for-Data signal is sent from the DCE. The Data Link Control turns off the Outgoing-Call-In-Process indicator, turns on the In-Use indicator, and prepares for normal data exchange.

F.2.2.6 Local Mode

When the LOCAL key is pressed in the Call-Ready state, the Data Link Control issues the HALT request and displays the Local Mode indicator.

The Local mode is the X.21 Controlled-Not-Ready state and inhibits incoming and outgoing calls.

When the COMM key is pressed in the Local mode, the Data Link Control issues an Open-for-Incoming request to the CAC and displays the Call-Ready indicator.

F.2.2.7 Disconnection

When the DISC key is pressed in the Ready-for-Data state or Outgoing/Incoming Call-In-Process state, the Data Link Control issues a CLOSE request in the Ready-for-Data state, or issues a HALT request in the Outgoing/Incoming-Call-In-Process state to the CAC, and displays the Disconnect-In-Process indicator. When the close-completion code is returned from the CAC, the Data Link Control turns off the In-Use indicator, issues an Open-for-Incoming request to the CAC, enters the Call-Ready state, and displays the Call-Ready indicator. When the halt-competition code is returned, the Data Link Control issues an Open-for-Incoming request to the CAC, enters the Call-Ready state, and displays the Call-Ready indicator.

The line is also disconnected automatically by a timeout condition or by the SDLC DISC command.

F.2.3 X.21 Switched Adapter (X.21SA) Card

The X.21SA card is a 2W by 3H and is pin-compatible with the integrated modem, the EIA/CCITT interface, the Loop I/F, the DDSA, or the X.21NA. Its location is 01A-A1G2. The X.21SA card has the two interfaces: the HPCA interface and the DCE interface. The HPCA interface connects the X.21SA to the HPCA adapter in the 3274. The DCE interface connects the X.21SA card through X.27 (V.11) level of the X.21 interface, appropriate board wiring, and a communication cable to the external DCE.

F.3 EXTENSION KEY AND MODIFIER KEYS


F.3.1 Locations

Figure F-2 defines the positions for the Extension key and the Modifier keys, such as DIAL, DIRECT, DISC, LOCAL, and COMM keys for the X.21 Switched feature operation on the 3278 or 3279. The X.21 Switched feature operation is executed by pressing the Extension key, and then one of the modifier keys.

Note: A decal and labels are provided to the customer to place on the keyboard to indicate the key positions.

F.3.2 Extension Mode

- The Extension mode is entered by pressing the Extension key except during the no-security-key condition or in the Test mode.
- All keyboard status indicators, such as KANA, ALPHA, APL, Text, NUM, UPSHIFT, and INSERT, are cleared when entering the Extension mode. The indication ' ▶ ' is displayed in column 30 of the information area when in the Extension mode.
- If a modifier key is pressed when in the Extension mode, the Extension mode is reset, and the function defined for the key is executed. The Extension key resets the Extension mode if pressed when in the Extension mode.



▶ is Extension key (ALT position of the ERASE EOF key).

Figure F-2. Keyboard Layout with X.21 Switched Feature

- The Reset key and the ALT key operate normally in the Extension mode and do not reset the Extension mode.
- If any key other than a modifier key and the Reset key is pressed, the Retry indicator is displayed, and the Extension mode is reset.
- Use of the DIAL key will be rejected in the Extension mode. The Retry indicator will be displayed when the device is busy, very busy, or not functional.
- The Extension key aborts the print ID mode and dead-key sequence.

F.4 STATUS AND KEY OPERATION

Figures F-3 and F-4 show how keys are treated when pressed in the X.21 Switched states and when in the Dial-In mode.

Status	Operation					
	DIAL Key Pressed	DIRECT Key Pressed	DISC Key Pressed	LOCAL Key Pressed	COMM Key Pressed	AID Key Pressed
Call Ready	Accept Z #? (##)	Accept Z	Ignore Z	Accept Z 599	Ignore Z	X-f Z
Call Ready with Call Progress Signal	Accept Z #? (##)	Accept* Z	Accept* Z	Accept Z 599	Accept* Z	X-f Z Nnn
Outgoing Call In Process	X Z Z	X Z Z	Accept Z	X Z Z	Ignore Z	X-f Z
Outgoing Call In Process with Call Progress Signal	X Z Z Nnn	X Z Z Nnn	Accept Z	X Z Z Nnn	Ignore Z Nnn	X-f Z Nnn
Incoming Call In Process	X Z Z	X Z Z	Accept Z	X Z Z	Ignore Z	X-f Z
Data Ready	X Z Z	X Z Z	Accept Z	X Z Z	Ignore Z	Same as the base machine
Disconnect In Process	X Z Z	X Z Z	Ignore Z	X Z Z	Ignore Z	X-f Z
Local	X Z Z 599	X Z Z 599	X Z Z 599	Ignore Z 599	Accept Z	X-f Z 599

* Reset Call Progress Signals.

Note: In each box under "Operation", the upper row shows an indicator from column 8 and the lower row shows an indicator from column 20.

Figure F-3. 3278/3279 Key Operation (During X.21 Switched States)

Key Pressed	Reaction	
	Dial Originating Terminal	Other Terminals
DIAL	Clear Screen Z #?	X-f Z Z ##
DIRECT	Z	X-f Z Z ##
LOCAL	Z 599	X-f Z Z ##
COMM	Ignore Z #?	Ignore Z ##
DISC	Z	Z
AID	X-f Z #?	X-f Z ##
CLEAR	Clear Screen* Z #?	Clear Screen Z ##
TEST	Test Abort Dial	Test Z ##
ENTER	Z	X-f Z ##

* Clear only the dial-in area

Note: In each box under "Reaction", the upper row shows an indicator from column 8 and the lower row shows an indicator from column 20.

Figure F-4. 3278/3279 Key Operation in Dial-In Mode

F.5 ERROR CODES AND RECOVERY

The X.21 Switched Adapter feature error codes and recovery are shown in Appendix B.

F.6 CALL PROGRESS SIGNAL CODE

The Call Progress Signal (CPS) is sent by the network to advise a calling terminal/host about the progress of a call or about the circumstances that have prevented a connection from being established. It is transmitted by the network after receiving end-of-dialing and is not repeated. The CPS codes and meanings are shown in Figure F-5.

Note: Meaning of the codes is different in each country. Ask a specialist for details about code meaning.

CPS Code	CPS Meaning
00	Wait
01	Terminal Called
02	Redirected Call
03	Connect When free
20	No connection
21	Number busy
22	Selection signal procedure error
23	Selection signal transmission error
41	Access barred
42	Changed number
43	Not obtainable
44	Out of order
45	Controlled not ready
46	Uncontrolled not ready
47	DCE power off
48	Invalid facility request
49	Network fault in local loop
51	Call information service
52	Incompatible user class of service
61	Network congestion
71	Long-term network congestion
72	RPOA out of order
81	Registration/Cancellation confirmed

Figure F-5. Call Progress Signal Code

Appendix G. Abbreviations

ACK. Positive acknowledgment.	DE. Device end.
ACTLU. Activate logical unit.	DFC. Data flow control.
ACTPU. Activate physical unit.	DISC. Disconnect.
AID. Attention identification.	DLE. Data link escape.
APL. A programming language.	DSR. Data Set Ready (CCITT 107).
ASCII. American Standard Code for Information Interchange.	DUP. Duplicate.
B. Busy	EAU. Erase all unprotected.
BB. Begin bracket.	EB. End brackets.
BCC. Block check character.	EC. Equipment check.
BOC. Bus out check.	EM. End of message.
BSC. Binary synchronous communications.	ENQ. Enquiry.
BTDAT. Buffered Teleprocessing Diagnostic Analyzer and Tester.	EOF. End of field.
C. Control field.	EOI. End of inquiry.
CAW. Channel address word.	EOR. End of record.
CC. Control check; chain command.	EOT. End of transmission.
CCA. Common communications adapter.	EP. Emulator program.
CCITT. Consultative Committee on International Telephone and Telegraph.	ESC. Escape.
CCW. Channel control word.	ETB. End of transmission block.
CE. Channel end.	ETX. End of text.
CMDR. Command reject.	EUA. Erase unprotected to address.
CPS. Call progress signal.	EX. Exception (response).
CPU. Central processing unit.	F. SDLC flag sequence.
CR. Command reject; carriage return.	FCS. Frame check sequence.
CRC. Cyclic redundancy check.	FF. Forms feed.
CSU. Channel service unit; customer setup.	FI. Format indicator.
CSW. Channel status word.	FM. Field mark; function management.
CTS. Clear to Send (CCITT 106).	FRU. Field replaceable unit.
CU. Control unit.	GP. General poll.
CUE. Control unit end.	HEX. Hexadecimal.
DACTLU. Deactivate logical unit.	HPCA. High-performance communications adapter.
DACTPU. Deactivate physical unit.	HVPS. High-voltage power supply.
DB. Device busy.	I. Information (format).
DC. Device check; data check.	IC. Insert cursor.
DCB. Device control block.	I/O. Input/output.
DCE. Data communication equipment.	IML. Initial machine load.
DDSA. Digital Data Service Adapter.	Ind. Indicator.
	IR. Intervention required.
	ITB. End of intermediate transmission block.

LCA. Local channel attachment (Model 1A).
LED. Light-emitting diode.
LHA. Local host attachment (Model 1B).
LRC. Longitudinal redundancy check.
LU. Logical unit.
LUSTAT. Logical unit status.
LVPS. Low-voltage power supply.
MAP. Maintenance analysis procedure.
MCM. Maintenance Concepts Manual.
MDT. Modified data tag.
MEM. Memory.
MIM. Maintenance Information Manual.
MSR. Magnetic slot reader.
NAK. Negative acknowledgement.
NCCF. Network communications control facility.
NCP. Network control program.
NDM. Normal disconnect mode.
NL. New line.
Nr. Next sequence number expected to arrive.
NRM. Normal response mode.
NRZI. Zero-complemented differential coding (non-return-to-zero inverted).
Ns. Transmitter's sequence number.
NS. Nonsequenced format (C-field).
NSA. Nonsequenced acknowledgment.
NSI. Nonsequenced information.
NUL. Null.
OC. Operation check.
OLT. Online test.
P. Printer; protected.
P/F. Poll/final bit.
PCM. Plug-compatible mode.
POR. Power on reset.
PT. Program tab.
PU. Physical unit.
RA. Repeat to address.
Rd Mod. Read modified.
Req. Request.
RH. Request/response header.
RI. Ring indicator.
RLSD. Received Line Signal Detector (CCITT 109).
RNR. Receive not ready.
ROL. Request online status.
RQI. Request initialization.
RR. Receive ready.
RTS. Request to send.
RU. Request/response unit.
RVI. Reverse interruption.
S. Sequenced (format).
SA. Switched adapter.
SBA. Set buffer address.
SC. Session control
SDLC. Synchronous data link control.
SDT. Start data traffic.
SF. Start field.
SI. Suppress index.
SIM. Set initialization mode.
SLHA. Simplified local host attachment.
SNA. Systems network architecture.
SNRM. Set normal response mode.
SOH. Start of heading.
SFAP. Structured field and attribute processing.
SP. Space; specific poll.
STX. Start of text.
SYN. Synchronous idle.
TC. Transmission check.
TH. Transmission header.
TP. Teleprocessing.
TPLM. TP line monitor.
TTD. Temporary text delay.
UC. Unit check.
UCW. Unit control word.
UE. Unit exception.
US. Unit specify.
WACK. Wait before transmit.
WCC. Write control character.
XID. Exchange station identification.

3274 Control Unit
Models 51C and 52C
Maintenance Concepts
Order No. SY27-2528-2

READER'S
COMMENT
FORM

This manual is part of a library that serves as a reference source for systems analysts, programmers, and operators of IBM systems. This form may be used to communicate your views about this publication. They will be sent to the author's department for whatever review and action, if any, are deemed appropriate. Comments may be written in your own language; use of English is not required.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation whatever. You may, of course, continue to use the information you supply.

Note: Copies of IBM publications are not stocked at the location to which this form is addressed. Please direct any requests for copies of publications, or for assistance in using your IBM system, to your IBM representative or to the IBM branch office serving your locality.

How did you use this publication?

- | | | | |
|--------------------------|-------------------------------------|--------------------------|------------------------|
| <input type="checkbox"/> | As an introduction | <input type="checkbox"/> | As a text (student) |
| <input type="checkbox"/> | As a reference manual | <input type="checkbox"/> | As a text (instructor) |
| <input type="checkbox"/> | For another purpose (explain) _____ | | |

Is there anything you especially like or dislike about the organization, presentation, or writing in this manual? Helpful comments include general usefulness of the book; possible additions, deletions, and clarifications; specific errors and omissions.

Page Number: _____

Comment: _____

What is your occupation? _____

Newsletter number of latest Technical Newsletter (if any) concerning this publication: _____

If you want a reply, give your name and address: _____

IBM branch office serving you _____

Thank you for your cooperation. No postage stamp necessary if mailed in the U.S.A. (Elsewhere, an IBM office or representative will be happy to forward your comments or you may mail directly to the address in the Edition Notice on the back of the title page.)

Please use pressure sensitive or other gummed tape to seal this form.

Reader's Comment Form

Cut or Fold Along Line

Fold and tape


Please Do Not Staple

Fold and tape



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY MAIL
FIRST CLASS PERMIT NO. 40 ARMONK, N.Y.



POSTAGE WILL BE PAID BY ADDRESSEE:

**International Business Machines Corporation
Department 52Q
Neighborhood Road
Kingston, New York 12401**

Fold and tape

Please Do Not Staple

Fold and tape



**International Business Machines Corporation
Data Processing Division
1133 Westchester Avenue, White Plains, N.Y. 10604**

**IBM World Trade Americas/Far East Corporation
Town of Mount Pleasant, Route 9, North Tarrytown, N.Y., U.S.A. 10591**

**IBM World Trade Europe/Middle East/Africa Corporation
360 Hamilton Avenue, White Plains, N.Y., U.S.A. 10601**



International Business Machines Corporation
Data Processing Division
1133 Westchester Avenue, White Plains, N.Y. 10604

IBM World Trade Americas/Far East Corporation
Town of Mount Pleasant, Route 9, North Tarrytown, N.Y., U.S.A. 10591

IBM World Trade Europe/Middle East/Africa Corporation
360 Hamilton Avenue, White Plains, N.Y., U.S.A. 10601