

001
(ENTRY POINT A)
THIS MAP SHOULD NOT BE ENTERED UNLESS AN
ERROR HAS OCCURRED WHILE EXECUTING
SYSTEM TEST, AND THEN ONLY WHEN THE
DEVICE TYPE FIELD IS EQUAL TO HEXADECIMAL'64'.

DOES RTN = 0001 ?
Y N

002
DOES RTN = 0002 ?
Y N

003
DOES RTN = 0003 ?
Y N

004
DOES RTN = 0004 ?
Y N

005
DOES RTN = 0005 ?
Y N

006
DOES RTN = 0006 ?
Y N

007
DOES RTN = 0007 ?
Y N

008
DOES CKPT = 0000 ?
Y N

009
DOES CKPT = 0001 ?
Y N

010
DOES IO = 07 ?
Y N

011
COMMAND REJECT FROM ATTACHMENT CARD
START INPUT/OUTPUT (WRITE)

012
WRITE ERROR (INCREASING LINE LENGTH)
CHECK DCB, FLAGS AND ISB

013
DOES IO = 07 ?
Y N

014
COMMAND REJECT FROM ATTACHMENT CARD
START INPUT/OUTPUT (WRITE)

015
WRITE ERROR (DECREASING LINE LENGTH)
CHECK DCB, FLAGS AND ISB

016
DOES IO = 07 ?
Y N

017
COMMAND REJECT FROM ATTACHMENT CARD
PREPARE - LEVEL = 1
START INPUT/OUTPUT (SKIP TO ONE)

018
SKIP TO ONE ERROR
CHECK DCB, FLAGS AND ISB

019
DOES CKPT = 0000 ?
Y N

020
DOES CKPT = 0001 ?
Y N

021
DOES IO = 07 ?
Y N

022
COMMAND REJECT FROM ATTACHMENT CARD
START INPUT/OUTPUT (READ)

023
DOES IN = 03 ?
Y N

024
READ ROM ERROR
CHECK DCB, FLAGS AND ISB

025
READ ROM DATA ERROR
RECEIVED DATA IN DEV1 TO DEV4
EXPECTED DATA
HEXADECIMAL'23456789ABCF001'

026
DOES IO = 07 ?
Y N

027
COMMAND REJECT FROM ATTACHMENT CARD
START INPUT/OUTPUT (WRITE)

028
WRITE ERROR
CHECK DCB, FLAGS AND ISB

029
DOES IO = 07 ?
Y N

030
COMMAND REJECT FROM ATTACHMENT CARD
PREPARE - LEVEL = 1
START INPUT/OUTPUT (SKIP TO ONE)

031
SKIP TO ONE ERROR
CHECK DCB, FLAGS AND ISB

032
DOES CKPT = 0000 ?
Y N

033
DOES IO = 07 ?
Y N

034
COMMAND REJECT FROM ATTACHMENT CARD
START INPUT/OUTPUT (WRITE)

035
WRITE ERROR (ERROR EXPECTED - GOOD
RECEIVED)
CHECK DCB, FLAGS AND ISB

036
DOES IO = 07 ?
Y N

037
COMMAND REJECT FROM ATTACHMENT CARD
PREPARE - LEVEL = 1
START INPUT/OUTPUT (SKIP TO ONE)

038
SKIP TO ONE ERROR
CHECK DCB, FLAGS AND ISB

039
DOES CKPT = 0000 ?
Y N

040
DOES CKPT = 0001 ?
Y N

041
DOES CKPT = 0002 ?
Y N

042
DOES IO = 07 ?
Y N

043
COMMAND REJECT FROM ATTACHMENT CARD
SECOND READ OF THE CYCLE STEAL STATUS

044
DOES IN = 03 ?
Y N

045
READ CYCLE STEAL STATUS ERROR
CHECK DCB, FLAGS AND ISB

046
RESIDUAL ADDRESS ERROR
DEV4 = EXPECTED ADDRESS
RSAD = RECEIVED ADDRESS

047
DOES IO = 07 ?
Y N

048
COMMAND REJECT FROM ATTACHMENT CARD
FIRST READ OF THE CYCLE STEAL STATUS

049
DOES IN = 03 ?
Y N

050
READ CYCLE STEAL STATUS ERROR
CHECK DCB, FLAGS AND ISB

051
RESIDUAL ADDRESS ERROR
DEV4 = EXPECTED ADDRESS
RSAD = RECEIVED ADDRESS

052
DOES IO = 07 ?
Y N

053
COMMAND REJECT FROM ATTACHMENT CARD
START INPUT/OUTPUT (WRITE)

054
WRITE ERROR
CHECK DCB, FLAGS AND ISB

055
DOES IO = 07 ?
Y N

056
COMMAND REJECT FROM ATTACHMENT CARD
PREPARE - LEVEL = 1
START INPUT/OUTPUT (SKIP TO ONE)

057
SKIP TO ONE ERROR
CHECK DCB, FLAGS AND ISB

058
DOES CKPT = 0000 ?
Y N

059
DOES IO = 07 ?
Y N

060
COMMAND REJECT FROM ATTACHMENT CARD
START INPUT/OUTPUT WRITE (LINE SKIP TEST)

061
WRITE FAILED (LINE SKIP TEST)
CHECK DCB, FLAGS AND ISB

062
DOES IO = 07 ?
Y N

063
COMMAND REJECT FROM ATTACHMENT CARD
PREPARE - LEVEL = 1
START INPUT/OUTPUT (SKIP TO ONE)

064
SKIP TO ONE ERROR
CHECK DCB, FLAGS AND ISB

065
DOES CKPT = 0000 ?
Y N

066
DOES IO = 07 ?
Y N

067
COMMAND REJECT FROM ATTACHMENT CARD
START INPUT/OUTPUT (WRITE)

068
WRITE ERROR
CHECK DCB, FLAGS AND ISB

069
DOES IO = 07 ?
Y N

070
COMMAND REJECT FROM ATTACHMENT CARD
PREPARE - LEVEL = 1
START INPUT/OUTPUT (SKIP TO ONE)

071
SKIP TO ONE ERROR
CHECK DCB, FLAGS AND ISB

072
DOES CKPT = 0000 ?
Y N

073
DOES CKPT = 0001 ?
Y N

074
DOES IO = 07 ?
Y N

075
COMMAND REJECT FROM ATTACHMENT CARD
START INPUT/OUTPUT (WRITE)

076
WRITE FAILED
CHECK DCB, FLAGS AND ISB
DEV1 AND DEV2 CONTAIN DATA TO WRITE

077
DOES IO = 07 ?
Y N

078
COMMAND REJECT FROM ATTACHMENT CARD
START INPUT/OUTPUT (WRITE)

079
WRITE FAILED
CHECK DCB, FLAGS AND ISB
DEV1 AND DEV2 CONTAIN DATA TO WRITE

080
DOES IO = 07 ?
Y N

081
COMMAND REJECT FROM ATTACHMENT CARD
PREPARE - LEVEL = 1
START INPUT/OUTPUT (SKIP TO ONE)
START INPUT/OUTPUT (LOAD 8 LINE / INCH
CODE

082
SKIP TO ONE ERROR
LOAD 8 LINE CODE ERROR
CHECK DCB, FLAGS AND ISB

083
DOES CKPT = 0000 ?
Y N

084
DOES CKPT = 0001 ?
Y N

085
DOES CKPT = 0002 ?
Y N

086
DOES IO = 07 ?
Y N

087
COMMAND REJECT FROM ATTACHMENT CARD
PREPARE - LEVEL = 1
START INPUT/OUTPUT (DIAGNOSTIC READ)

088
DOES IN = 03 ?
Y N

089
DIAGNOSTIC READ ERROR
CHECK DCB, FLAGS AND ISB

090
CHECKSUM VALUE ERROR
VALUE IN ERROR STORE
IN DEV3 AND DEV4

091
DOES IO = 07 ?
Y N

092
COMMAND REJECT FROM ATTACHMENT CARD
PREPARE - LEVEL = 2
RESET
READ ID
START INPUT/OUTPUT (WRITE)

093
DOES IN = 03 ?
Y N

094
WRITE FAILED
CHECK DCB, FLAGS AND ISB
LEVEL = 2

095
WRONG ID RECEIVED ON LEVEL - 2
DEV3 = RECEIVED ID
DEV4 = EXPECTED ID

096
DOES IO = 07 ?
Y N

097
COMMAND REJECT FROM ATTACHMENT CARD
PREPARE - LEVEL = 1
RESET
READ ID
START INPUT/OUTPUT (WRITE)

098
DOES IN = 03 ?
Y N

099
WRITE FAILED
CHECK DCB, FLAGS AND ISB
LEVEL = 1

100
WRONG ID RECEIVED ON LEVEL - 1
DEV3 = RECEIVED ID
DEV4 = EXPECTED ID

101
DOES IO = 07 ?
Y N

R S
6 6

4974 PRINTER (MATRIX)

MAP 64E0-7

SYSTEM TEST ERROR MAP

PAGE 7 OF 7

102
COMMAND REJECT FROM ATTACHMENT CARD
PREPARE - LEVEL = 0
RESET
READ ID
START INPUT/OUTPUT (WRITE)

103
DOES IN = 03 ?
Y N

104
WRITE FAILED
CHECK DCB, FLAGS AND ISB
LEVEL = 0

105
WRONG ID RECEIVED ON LEVEL - 0
DEV3 = RECEIVED ID
DEV4 = EXPECTED ID

21SEP79 PN1635466
EC375482 PEC755104
MAP 64E0-7