

DIP 42

Before you begin...

1. Confirm your target matches this MEMORY FOOTPRINT


A18	1	42	A19
A17	2	41	A8
A7	3	40	A9
A6	4	39	A10
A5	5	38	A11
A4	6	37	A12
A3	7	36	A13
A2	8	35	A14
A1	9	34	A15
A0	10	33	A16
CE#	11	32	BYTE#
GND	12	31	GND
OE#	13	30	D15
D0	14	29	D7
D8	15	28	D14
D1	16	27	D6
D9	17	26	D13
D2	18	25	D5
D10	19	24	D12
D3	20	23	D4
D11	21	22	VCC

DIP 42

- ☐ 42 pin DIP cable, 16 bit memories
- ☐ Maximum memory size 2M Bytes
- ☐ Organized as 1M x 16 bit
- ☐ Maximum PromICE: P2080
- ☐ To emulate 3 Volt memories, 3 Volt adapter (GEI Part # 3VA16DC) is required.

Note: Maximum memory size is shown in footprint. For smaller memories, unused lines must be connected to V_{cc} to ensure proper PromICE operation.

2. Confirm that you have received all parts of the Complete Cable Assembly



Memories Supported

- ☐ Emulates 42 pin DIP devices like 27C400, 27C800, and others.
- ☐ www.promice.com/memories.htm contains a listing of all memories supported by Grammar Engine target cables. **Note:** This cable supports both ROM and flash memories.

Notes and Precautions

Always turn target power OFF when connecting or disconnect PromICE target cables.

Always leave Dip cable on the foam pad when not in use.

If your target has capacitors, allow sufficient discharge time. Connecting with the power on can damage cables or the PromICE.

The dip cable should have come with a foam pad already on it.

**For Technical Support, contact Grammar Engine at 614-899-7878 or support@gei.com
For Sales, contact Grammar Engine Inc. www.gei.com or 1.800.PROMICE.**

Installation Instructions	Step	Action	Notes
	1.	Verify that you have the correct cable for the memory you are emulating.	If you have the wrong cable, contact Grammar Engine or your distributor for a replacement.
	2.	Connect PromICE.	With the power off to your PromICE, connect the shielded ground plane cables to your PromICE.
	3.	Locate pin 1 on cable and socket.	Align pin 1 on the cable to pin 1 on the socket.
	4.	Connect Dip cable to socket.	Inspect to confirm that each pin is fully seated in the socket. Do not insert the probe at an angle, since this can damage individual pins.

You are now ready to power up your target and PromICE. Please consult your PromICE manual for further setup information.


Contact your Grammar Engine Sales Representative to order these parts and accessories:

Cable Parts	DIP 42B 34FFEXT 34FF6.7EXT Dip 42 cbl.	Adapter Board 6" Shielded Ground Plane Cable 6.75" Shielded Ground Plane Cable 42 pin DIP cable
Accessories	3VA16DC	3 Volt Adapter

DIP42B

16-bit

IN FROM TARGET, OUT TO PromICE
WRITE SIGNAL CONDITIONING



1	A17	A8	40	1	A18	A19	42
2	A7	A9	39	2	A17	A8	41
3	A6	A10	38	3	A7	A9	40
4	A5	A11	37	4	A6	A10	39
5	A4	A12	36	5	A5	A11	38
6	A3	A13	35	6	A4	A12	37
7	A2	A14	34	7	A3	A13	36
8	A1	A15	33	8	A2	A14	35
9	A0	A16	32	9	A1	A15	34
10	CE#	BYT#	31	10	A0	A16	33
11	GND	GND	30	11	CE#	BYT#	32
12	OE#	D15	29	12	GND	GND	31
13	D0	D7	28	13	OE#	D15	30
14	D8	D14	27	14	D0	D7	28
15	D1	D6	26	15	D8	D14	27
16	D9	D13	25	16	D1	D6	26
17	D2	D5	24	17	D9	D13	25
18	D10	D12	23	18	D2	D5	24
19	D3	D4	22	19	D10	D12	23
20	D11	VCC	21	20	D3	D4	22
					D11	VCC	21

DIP40S DIP 42

NOTES:

MAX SIZE: 512KB (256K x 16/40 pin (P2020), 2MB (1M x 16) /42 pin (P2080)
SUPPORTS: DIP 40 and 42 pin ROMs with address on one top of chip and data on the bottom.
PROMICE JUMPER SETTING: 32

Grammar Engine Inc. 921 Eastwind Drive Suite 122 Westerville OH 43081		
Title	DIP42	
Size	Document Number	Rev
B	497-0015	
Date:	Monday, July 12, 1999	Sheet 1 of 1