



E27	INTA OPTION	NC
E32	E31 NMI OPTION	NC
	E30 NMI OPTION	NC
E33	E34 INT 0 OPTION	NC
E35	HALT OPTION	NC
E36	INTA OPTION	NC
E38	BUS PIN 18	NC
E39	BUS PIN 9	NC
E40	REFRESH OPTION	NC
E41	INT 20 OPTION	NC
E42	EXTERNAL DISABLE	NC
E43	INT 0 OPTION	NC
E44	BUS PIN 8	NC
E45	INT 10 OPTION	NC
E46	SIDE SELECT OPTION	NC
E47	NMI OPTION	NC
E48	E50 NORMAL WRITE	NC
E49	E51 EARLY WRITE	●

SCHEMATIC OF THE Z80 CPU BOARD Model HA-8-6

NOTES:

1. ALL RESISTORS ARE 1/4-WATT AND HAVE A TOLERANCE OF 5%. VALUES SHOWN ARE IN OHMS.
2. ALL CAPACITOR VALUES ARE IN MICROFARADS.

3. SYMBOLS:

- THIS SYMBOL INDICATES A LETTERED CIRCUIT BOARD HOLE.
- ▽ THIS SYMBOL INDICATES A CIRCUIT BOARD GROUND.
- ◁ THIS SYMBOL INDICATES A SYSTEM BUS CONNECTION.