

TeleVideo® TS 800A Satellite User Station

OPERATOR'S QUICK REFERENCE GUIDE

Function	Command	Function	Command
MONITOR		VISUAL ATTRIBUTES	
Monitor mode on (transmitted)	ESC U	Normal video (green on black)	ESC G 0
Monitor mode off (transmitted)	ESC X	Invisible normal	ESC G 1
	ESC u	Blink	ESC G 2
		Invisible blink	ESC G 3
	ESC g	Reverse video (black on green)	ESC G 4
	ESC f (text) CR	Invisible reverse	ESC G 5
	ESC h	Reverse blink	ESC G 6
		Invisible reverse blink	ESC G 7
	ESC ! 1	Underline	ESC G 8
	ESC ! 2	Invisible underline	ESC G 9
		Underline blink	ESC G :
	ESC #	Invisible underline blink	ESC G ;
	ESC "	Reverse blink underline	ESC G <
	^^	Invisible reverse underline	ESC G =
	^_	Reverse blink underline	ESC G >
	^M	Invisible reverse blink underline	ESC G ?
	^J or ^V	Reverse screen background	ESC b
	^K or ESC j	Normal screen background	ESC d
	^H		
	^L	SPECIAL GRAPHICS	
	ESC . 0	Special graphics on	ESC \$
	ESC . 1	Special graphics off	ESC %
	ESC . 2		
	ESC . 3	SCREEN MEMORY	
	ESC . 4	Set lines per page	ESC \ n
		Advance page of memory	ESC K
		View previous page	ESC J
		AUTO PAGE	
	ESC >	Auto page on	ESC v
	ESC <	Auto page off	ESC w
	^G		
		PROTECT MODE	
	ESC 8	Half intensity (protected writing) on	ESC)
	ESC 9	Half intensity (protected writing) off	ESC (
		Protect on	ESC &
		Protect off	ESC '
	ESC n		
	ESC o	FUNCTION KEYS	
		Program function key	ESC p1 p2 (text) ^Y

OPERATOR'S QUICK REFERENCE GUIDE

Function	Command	Function	Command
ADDRESS/READ CURSOR			
Address cursor (row, column)	ESC = r c	Erase screen to nulls	ESC y
Address cursor (page, row, column)	ESC - p r c	Insert on	ESC q
Read cursor (row, column)	ESC ?	Edit on	ESC r
Read cursor (page, row, column)	ESC /	Page on	ESC N
		Line on	ESC O
INSERT CHARACTER			
Program insert character	ESC e n	CLEAR	
		Clear unprotected to insert characters	ESC + ^Z
TAB			
Set typewriter (column) tab	ESC 1		ESC ;
Typewriter tab	^I	Clear all data to nulls	ESC *
Field tab	ESC i	Clear unprotected to nulls	ESC :
Back tab	ESC I	Clear page to half-intensity insert characters	ESC ,
Clear typewriter tab	ESC 2	X-ON/X-OFF	
Clear all tabs	ESC 3	Enable X-On/X-Off	^O
		Disable X-On/X-Off	^N
COMMUNICATION			
Local on	ESC c	DATA TERMINAL READY	
Block on	ESC B	Enable DTR	^N
Half duplex on	ESC D H	Disable DTR	^O
Full duplex on	ESC D F	SEND KEY	
Return to previous conversational mode	ESC C	Load SEND key	ESC 0 x y
		Set send delimiters	ESC x n p1 p2
EDIT KEYS			
Local edit keys	ESC k	Send unprotected line to cursor	ESC 4
Duplex edit keys	ESC l	Send unprotected page to cursor	ESC 5
		Send line to cursor	ESC 6
EDITING TEXT			
Character insert	ESC Q	Send page to cursor	ESC 7
Character delete	ESC W	Send unprotected message	ESC S
Line insert	ESC E	Send entire message	ESC s
Line delete	ESC R	Send terminal identification	ESC M
Erase line to spaces	ESC T	Send status line	ESC Z 1
Erase line to nulls	ESC t	Send user line	ESC Z 0
Erase screen to spaces	ESC Y		