
ROM Errata (Rev. A)

to the Micro Annex ROM Revision 0509

- 1) A five-part address (IP, Subnet, etc.) causes the Micro Annex to *panic*.
Workaround: Five-part addresses are not valid. Issue four-part addresses only.
- 2) Output displayed by the erase command does not match the description in the *Micro Annex Hardware Installation Guide*.
- 3) ROMs are unable to accept a Class A subnet mask (255.0.0.0); claim the mask is invalid or uninitialized.
Workaround: Set subnet mask to default (0); it will then default to Class A subnet if you have a Class A address.
- 4) Quitting out of SLIP boot causes garbage characters to be output to the screen.
- 5) Typing q and then pressing the RETURN key multiple times during a boot timeout situation causes the Micro Annex to hang (also in 0506).
Workaround: Power unit down and reboot.
- 6) CONTROL-C does not abort all executing monitor commands as stated in the *Micro Annex Hardware Installation Guide*.
- 7) While aborting a boot (or SLIP boot) in remote-diaq command, using q causes the Micro Annex to hang.