



- Notes:
- S1-1 - S1-2 Band selector switch in "FM" position.
  - S2 Clock selector switch in "OFF" position.
  - S3 Call switch in "OFF" position.
  - S4 Hour service switch in "ON" position.
  - S5-1 Hour service switch in "OFF" position.

- S5-2 Motor switch in "OFF" position.
- S5-3 Sure awake switch in "OFF" position.
- S5-4 Motor switch in "OFF" position.
- S5-5 Amplifier switch in "OFF" position.
- S5-6 AF signal oscillator switch in "OFF" position.

- DC voltage measurements are taken with circuit tester 10 K $\Omega$ /V from chassis.
- FM position ( ) AM position
- Tape position

Fig. 4-9. Panasonic Model RC-690 time announcing AM-FM clock radio.