11/24

# 11/24 CP CLUSTER DIAG
CJKDEBO

AH-F608B-MC
FICHE 1 OF 3

JAN 1983
COPYRIGHT© 81-82
MADE IN USA

d0301080

11/24

11/24 CP CLUSTER DIAG
CJKDEBO

AH-F608B-MC
FICHE 2 OF 3

JAN 1983
COPYRIGHT© 81-82
MADE IN USA



11/24

11/24 CP CLUSTER DIAG
CJKDEBO

AH-F608B-MC
FICHE 3 OF 3

JAN 1983
COPYRIGHT@ 81-82
MADE IN USA



```
.REM_
```

## IDENTIFICATION

PRODUCT CODE:  AC-F605B-MC

PRODUCT NAME:  CJKDEB0 11/24 CP CLUSTER DIAG

PRODUCT DATE:  AUGUST 1982

MAINTAINER:  DIAGNOSTIC ENGINEERING

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C):  1981,1982 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

| | | | |
|---|---|---|---|
| DIGITAL | PDP | UNIBUS | MASSBUS |
| DEC | DECUS | DECTAPE | DEC/X11 |

```
                                                HISTORY
                                                -------

                        REVISION A              FIRST RELEASE OF DIAGNOSTIC
                        REVISION B              UPDATED FOR VOLTAGE MONITOR BIT CHECK,AND
                                                FOR KNOWN BUGS REPORTED BY MANUFACTURING.
```

## TABLE OF CONTENTS

1.0 GENERAL PROGRAM INFORMATION
1.1 ABSTRACT
1.2 SYSTEM REQUIREMENTS
1.3 RELATED DOCUMENTS AND STANDARDS
1.4 DIAGNOSTIC HIERARCHY PREREQUISITES
1.5 ASSUMPTIONS

2.0 OPERATING INSTRUCTIONS
2.1 LOADING AND STARTING PROCEDURE
2.2 PROGRAM OPTIONS
2.3 EXECUTION TIMES

3.0 ERROR INFORMATION
3.1 ERROR REPORTING PROCEDURES
3.2 ERROR HALTS

4.0 PERFORMANCE AND PROGESS REPORTS
4.1 PERFORMANCE REPORTS
4.2 PROGRESS REPORTS

5.0 DEVICE INFORMATION TABLES

6.0 PROGRAM DESCRIPTION
6.1 PROGRAM EXECUTION CHARACTERISTICS
6.2 SUBTEST SUMMARIES
6.3 SPECIAL SUBROUTINE DESCRIPTION

7.0 LISTING

## 1.0 ABSTRACT

THIS PROGRAM IS A GO-NOGO TEST FOR THE 11/24 CPU BOARD. IT TESTS THE CPU INCLUDING EIS, THE MMU, THE FPP, THE LTC AND BOTH SLU'S. IT DOES NOT CONTAIN THE CAPABILITIES OF SCOPE LOOPING, ERROR RECOVERY OR PRINTING OF ERROR INFORMATION. ERROR HALTS DO INDICATE WHICH DEVICE FAILED TO ALLOW THE TECHNICIAN TO DETERMINE WHICH DIAGNOSTIC TO USE TO FIX THE BOARD OR WHAT FIELD REPLACEABLE UNIT (FRU) MAY FIX THE BOARD. THE PROGRAM WILL RUN UNDER THE ACT AND APT MANUFACTURING SYSTEMS AND IS CHAINABLE UNDER XXDP.

## 1.1 SYSTEM REQUIREMENTS

### A. HARDWARE REQUIREMENTS

- CPU BASED ON DCF11-AA CHIP SET WITH KTF11-AA AND KEF11-AA CHIPS PRESENT.
- LTC
- 2 SLU'S COMPATIBLE WITH 11/24 SLU SPECIFICATION.
- 28K OF MEMORY
- THE SECOND SLU MUST HAVE TURN AROUND CONNECTOR.

### B. SOFTWARE ENVIRONMENTS

- APT (MULTI-CPU TESTER)
- ACT
- XXDP (SLIDE)
- STAND-ALONE

## 1.2 RELATED DOCUMENTS AND STANDARDS

- ASSEMBLED WITH SYSMAC; SEE FIRST PAGE OF LISTING FOR REVISION NUMBER.
- M7133 MODULE SPECIFICATION
- DIAGNOSTIC ENGINEERING FUNCTIONAL SPECIFICATION FOR SPECIAL MANUFACTURING TEST BGI-79-003-00-U.
- DIAGNOSTIC ENGINEERING PROJECT PLAN FOR 11/24) BGI-78-002-02-U.

- DIAGNOSTIC ENGINEERING STANDARDS AND CONVENTIONS
  175-003-009-02.

## 1.3 PREREQUISITE DIAGNOSTICS

NONE

## 1.4 ASSUMPTIONS

THIS PROGRAM ASSUMES THE MACHINE IS UP SUFFICIENTLY TO ALLOW PROPER OPERATION OF THE MICRO-ODT OF THE DCF11-AA CHIP SET.

## 2.0 OPERATING INSTRUCTIONS

## 2.1 LOADING AND STARTING PROCEDURES

TO LOAD AND START THIS PROGRAM USE THE STANDARD PROCEDURES FOR THE DIAGNOSTIC SOFTWARE ENVIRONMENT THAT IS BEING USED.

## 2.2 PROGRAM OPTIONS

THIS PROGRAM USES THE SOFTWARE SWITCH LOCATION 176 IF PROGRAM IS NOT BEING RUN UNDER APT MODE (BIT 0 SET OF LOCATION $ENV). IF PROGRAM IS BEING RUN IN APT MODE THE LOCATION $SWREG IN THE APT ETABLE IS USED TO STORE OPERATING SWITCHES.

| BIT # | DEFINITION |
|---|---|
| 15-6 | NOT USED |
| 5 | 0 - PROGRAM RESERVED -- PROGRAM WILL CLEAR IF CIS CHIP SET NOT ON BOARD |
| | 1 - PROGRAM RESERVED -- PROGRAM WILL SET IF CIS CHIP SET IS ON BOARD |
| 4 | 0 - TEST SLU2 OF 11/24 |
| | 1 - INHIBIT TESTING OF SLU2 |
| 3 | 0 - TEST LTC OF 11/24 |
| | 1 - INHIBIT TESTING OF LTC |
| 2 | 0 - TEST SLU1 OF 11/24 |
| | 1 - INHIBIT TESTING OF SLU1 |
| 1 | 0 - TEST FPP INSTRUCTION SET |
| | 1 - INHIBIT TESTING OF FPP |
| 0 | 0 - TEST MEMORY MANAGEMENT UNIT |
| | 1 - INHIBIT TESTING OF MMEMORY MANAGEMENT UNIT |

## 2.3 EXECUTION TIMES

FIRST PASS RUNTIME (WORST CASE).....45 SEC
LONGEST TEST TIME.....30 SEC
ADDITIONAL RUNTIME (EXTRA UNITS).....NONE
LONGEST PASS TIME.....45 SEC

# 3.0 ERROR INFORMATION

## 3.1 ERROR REPORTING PROCEDURES

THE PROGRAM DOES NOT TYPE OUT ANY ERROR REPORTS OF ITS OWN BUT TAKES ADVANTAGE OF THE HARDWARE FEATURE THAT TYPES THE PC WHEN A HALT OCCURS. WHEN AN ERROR IS DETECTED THE PROGRAM JUMPS TO ONE OF SEVEN HALT ROUTINES. THE ROUTINES SIMPLY MOVE A FATAL ERROR NUMBER INTO LOCATION $FATAL, SET THE FATAL ERROR FLAG IN LOCATION $MSGTY AND EITHER HALT OR IF ON APT DO A BRANCH DOT. THE OPERATOR HAS THREE WAYS TO DETERMINE THE FAILING DEVICE; 1) BY EXAMINING LOCATION $FATAL, 2) BY DETERMINING THE HALT ADDRESS AND LOOKING UP THE ADDRESS IN THE LISTING AND 3) BY EXAMINING LOCATION $TESTN WHICH WILL CONTAIN THE TEST NUMBER BEING EXECUTED.

## 3.2 ERROR HALTS

FOR DISCUSSION SEE SECTION 3.1. THE LABELS FOR THE HALTS AND THE DEVICE THEY INDICATE HAVING FAILED ARE:

| | |
|---|---|
| CPUHLT: | CPU |
| MMUHLT: | MMU |
| FPPHLT: | FPP |
| LTCHLT: | LTC |
| SL1HLT: | SLU1 |
| SL2HLT: | SLU2 |
| COMHLT: | SYSTEM INTERACTION |

*** IF THE LOCATION $FATAL = 177 THEN THE POWER FAILED ***

UPON RECEIVING THE ERROR HALT ADDRESS (PC) FROM THE MICRO-ODT THE OPERATOR CAN LOOK UP THESE TAGS IN THE SYMBOL TABLE AT THE END OF THE LISTING TO DETERMINE WHICH HALT WAS EXECUTED. NOTE: THE PC SUPPLIED BY THE MICRO-ODT WILL BE THE HALT ADDRESS PLUS 2.

THE OPERATOR CAN DETERMINE WHICH TEST THE ERROR OCCURRED IN BY EXAMINING LOCATION "$TESTN". THE TEST NUMBERS EQUATE TO FAILING DEVICES AS FOLLOWS:

| DEVICE | CONTENTS OF $TESTN |
|---|---|

```
                                        CPU             000001
                                        MMU             000002
                                        FPP             000003
                                        SLU1            000004
                                        LTC             000005
                                        SLU2            000006
                                        SYSTEM
                                        INTERACTION     000007


4.0  PERFORMANCE AND PROGRESS REPORTS

     THE ONLY REPORT TYPED BY THIS PROGRAM IS  THE  END  PASS  MESSAGE
     WHICH IS:

               CJKDEB END OF PASS #XXX

     WHERE XXX IS THE DECIMAL NUMBER OF PASSES COMPLETED.
```

## 5.0 DEVICE INFORMATION TABLES

SLU1 RCSR




SLU1 RBUF




SLU1 XCSR

```
                SLU1 XBUF

                      15  14  13  12  11  10  9   8   7   6   5   4   3   2   1   0
                     ------------------------------------------------------------------
                    I                                 I   I   I   I   I   I   I   I   I
                     ------------------------------------------------------------------
                                                      I
                                                      I
                TRANSMITTER DATA BITS (8) ------------------

                LTC CSR

                      15  14  13  12  11  10  9   8   7   6   5   4   3   2   1   0
                     ------------------------------------------------------------------
                    I                           I   I   I                           I
                     ------------------------------------------------------------------
                                                I   I
                                                I   I
                LINE CLOCK MONITOR ------------     I
                INTERRUPT ENABLE ------------------

                SLU2 RCSR

                      15  14  13  12  11  10  9   8   7   6   5   4   3   2   1   0
                     ------------------------------------------------------------------
                    I                           I   I   I                           I
                     ------------------------------------------------------------------
                                                I   I
                                                I   I
                RECEIVER DONE ------------------    I
                INTERRUPT ENABLE ------------------

                SLU2 RBUF

                      15  14  13  12  11  10  9   8   7   6   5   4   3   2   1   0
                     ------------------------------------------------------------------
                    I   I   I   I   I               I   I   I   I   I   I   I   I   I
                     ------------------------------------------------------------------
                      I   I   I   I                                   I
                      I   I   I   I                                   I
                ERROR -   I   I   I                                   I
                OVERRUN ---   I   I                                   I
                FRAME ERROR ---   I                                   I
                RECEIVER PARITY ---                                   I
                ERROR                                                 I
                RECEIVER DATA BITS (8) ----------------------------------
```

SLU2 XCSR




SLU2 XBUF




## 6.0 PROGRAM DESCRIPTION

### 6.1 PROGRAM EXECUTION CHARACTERISTICS

THIS PROGRAM RUNS THE SAME UNDER ALL DIAGNOSTIC MONITORS. WHEN THE TEST IS STARTED AT ADDRESS 200 OCTAL THE TESTING IS DONE AND ON COMPLETION THE TITLE IS TYPED AS PART OF THE END OF PASS MESSAGE.

### 6.2 SUB-TEST SUMMARIES

#### 6.2.1 CENTRAL PROCESSING UNIT SUBTEST -

THESE TESTS CHECK THE BASIC INSTRUCTION SET AND ADDRESSING MODES, THE EXTENDED ELEVEN INSTRUCTION SET (EIS) AND TRAPS TESTING. IT IS EQUIVALENT TO CJKDB.

### 6.2.2 MEMORY MANAGEMENT UNIT SUBTEST -

THESE TESTS ARE THE SAME AS IN CJKDA, THE KEF11-AA TEST. THE PROGRAM BEGINS BY TESTING SOME OF THE INTERNAL CPU DATA AND ADDRESS PATHS AND ADDRESS DETECTION LOGIC. NEXT THE MEMORY MANAGEMENT REGISTERS ARE CHECKED FOR DATA RELIABILITY, THEN RELOCATION CAPABILITIES (FORMATION OF A PHYSICAL ADDRESS FROM A VIRTUAL ADDRESS AND ASSOCIATED PAGE DESCRIBTOR (PDR) INFORMATION). FINALLY THE ABORT AND STATUS SEGMENTS OF THE LOGIC ARE CHECKED.

### 6.2.3 FLOATING POINT PROCESSOR SUBTEST -

THE FLOATING POINT PROCESSOR SUBTEST CHECKS FLOATING POINT REGISTERS FIRST USING A LIMITED NUMBER OF FLOATING POINT INSTRUCTIONS. IT THEN VERIFIES THE REST OF THE FLOATING POINT INSTRUCTION SET USING A NUMBER OF DATA PATTERNS FOR EACH INSTRUCTION.

### 6.2.4 SERIAL LINE UNIT (SLU1) SUBTEST -

THESE TEST FIRST CHECK THE SLU'S REGISTERS FOR ADDRESSING AND DATA CAPABILITIES. THEN USING THE MAINTENANCE MODE OF THE SLU THEY CHECK THE DATA PATHS AND INTERRUPT LOGIC.

### 6.2.5 LINE TIME CLOCK (LTC) SUBTEST -

FIRST THE REGISTER IS CHECKED FOR ADDRESSING AND BIT SETTING CAPABILITIES THEN THE INTERRUPT LOGIC IS CHECKED. THERE IS ALSO A REPEATABILITY TEST FOR THE CLOCK.

### 6.2.6 SERIAL LINE UNIT 2 SUBTEST -

THE TESTING DONE HERE IS THE SAME AS FOR SLU1 (SEE SECTION 6.2.4). THE ONLY DIFFERENCE IS THAT SINCE SLU2 DOES NOT HAVE A MAINTENANCE WRAP-AROUND LIKE SLU1 THE TESTING REQUIRES AN EXTERNAL JUMPER TO BE PRESENT.

### 6.2.7 BLAST SUBTEST

THIS TEST CHECKS THE ABILITY OF THE 11/24 TO HANDLE SYSTEM INTERACTION. THE CPU HAS TO HANDLE DEVICES AT DIFFERENT PRIORITY LEVELS AND ARBITRATE BETWEEN THEM AND ITS OWN PRIORITY. THE TEST SETS UP ALL DEVICES TO INTERRUPT THEN ENABLES THEM ALL AT ONCE. THE SLU'S TRANSFER DATA UNTIL THEY TRANSFER 400(8) BYTES OR UNTIL ONE SECOND (60 TICKS) OF THE LINE CLOCK HAS BEEN RECEIVED. THE PROGRAM THEN VERIFIES THE NUMBER OF TRANSMTTER INTERRUPTS IS EQUAL TO THE NUMBER OF RECEIVER INTERRUPTS. FINALLY THE DATA TRANSFERRED BY EACH DEVICE IS CHECKED.

## 6.3 SPECIAL SUBROUTINE DESCRIPTIONS

THE ONLY SPECIAL SUBROUTINES ARE THE ERROR ROUTINES EACH SUBTEST HAS IS OWN. THE ROUTINES SIMPLY SET THE FATAL ERROR FLAG IN THE APT MAILBOX AND EITHER "BRANCH SELF" OR "HALT". THIS CHOICE IS DETERMINED IN THE INITIALIZE PORTION OF THE PROGRAM AND IS A "BRANCH SELF" IF RUNNING UNDER APT OR A "HALT" IF RUNNING UNDER ANY OTHER MONITOR.

# 7.0 LISTING

```
                                .TITLE  CJKDE-B  11/24 CPU CLUSTER DIAG.
                                .ENABLE ABS
                                .NLIST  CND,MC,MD
                                .LIST   ME
000240                          SCOPE=NOP
000007                          R7=%7
000006                          R6=%6
177776                          PS=177776
177564                          TPS=177564
177566                          TPB=177566
140000                          USRM=140000
030000                          PUSRM=30000
000006                          SP=%6
000006                          R6=%6
000003                          TAB=%3
000001                          LAST=%1
000005                          FIRST=%5
000002                          R2=%2
000000                          HLT=HALT
000003                          TRT=3
000004                          ITRAP5=4
000004                          RTRAP5=4                ;RESERVED INST AND ILLEGAL ADDRESSES
000014                          RTRAP4=14               ;FOR TRACE TRAP
000030                          RTRAP3=30               ;FOR EMULATOR TRAP
000020                          RTRAP2=20               ;FOR IOT TRAP
000034                          RTRAP1=34               ;FOR TRAP INST
177564                          TTCSR=177564
177560                          TRCSR=177560
177562                          TKB=177562
177566                          TPB=177566
000240                          BELL=240
000240                          NOP=240
177776                          STATUS=177776
000077                          TRAPA=77
000010                          RTRAP=10
004700                          ILLA=004700
000100                          ILLB=100
177776                          CC=177775
001000                          KERSTK=STBOT
000600                          USESTK=STBOT-200
104377                          EMTA=104377
104777                          TRAPC=104777
000001                          APTENV=1
                        .SBTTL  ACT11 HOOKS

                        ;*******************************************************************************************
                        ;HOOKS REQUIRED BY ACT11
000400                          $SVPC=.                 ;SAVE PC
000046                          .=46
000046  131522                  $ENDAD                  ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .$EOP
000052                          .=52
000052  000000                  .WORD   0               ;;2)SET LOC.52 TO ZERO
000400                          .=$SVPC                 ;; RESTORE PC
001000                          .=1000
```

```
                                .SBTTL  APT MAILBOX-ETABLE

                                ;*****************************************************************************************
                                .EVEN
001000                          $MAIL:                          ;;APT MAILBOX
001000  000000                  $MSGTY: .WORD   AMSGTY   ;;MESSAGE TYPE CODE
001002  000000                  $FATAL: .WORD   AFATAL   ;;FATAL ERROR NUMBER
001004  000000                  $TESTN: .WORD   ATESTN   ;;TEST NUMBER
001006  000000                  $PASS:  .WORD   APASS    ;;PASS COUNT
001010  000000                  $DEVCT: .WORD   ADEVCT   ;;DEVICE COUNT
001012  000000                  $UNIT:  .WORD   AUNIT    ;;I/O UNIT NUMBER
001014  000000                  $MSGAD: .WORD   AMSGAD   ;;MESSAGE ADDRESS
001016  000000                  $MSGLG: .WORD   AMSGLG   ;;MESSAGE LENGTH
001020                          $ETABLE:                        ;;APT ENVIRONMENT TABLE
001020     000                  $ENV:   .BYTE   AENV     ;;ENVIRONMENT BYTE
001021     000                  $ENVM:  .BYTE   AENVM    ;;ENVIRONMENT MODE BITS
001022  000000                  $SWREG: .WORD   ASWREG   ;;APT SWITCH REGISTER
001024  000000                  $USWR:  .WORD   AUSWR    ;;USER SWITCHES
001026  000000                  $CPUOP: .WORD   ACPUOP   ;;CPU TYPE,OPTIONS
                                ;*                              BITS 15-11=CPU TYPE
                                ;*                                      11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
                                ;*                                      11/70=06,PDQ=07,Q=10
                                ;*                              BIT 10=REAL TIME CLOCK
                                ;*                              BIT  9=FLOATING POINT PROCESSOR
                                ;*                              BIT  8=MEMORY MANAGEMENT
001030                          $ETEND:
                                .MEXIT
                                .SBTTL  APT PARAMETER BLOCK

                                ;*****************************************************************************************
                                ;*****************************************************************************************
                                ;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
                                ;*****************************************************************************************
                                        .$X=.   ;;SAVE CURRENT LOCATION
001030                                  .=24    ;;SET POWER FAIL TO POINT TO START OF PROGRAM
000024  000200                  200     ;;FOR APT START UP
000044                                  .=44    ;;POINT TO APT INDIRECT ADDRESS PNTR.
000044  001030                  $APTHDR ;;POINT TO APT HEADER BLOCK
001030                                  .=.$X   ;;RESET LOCATION COUNTER
                                ;*****************************************************************************************
                                ;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
                                ;INTERFACE SPEC.

001030                          $APTHD:
001030  000000                  $HIBTS: .WORD   0        ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
001032  001000                  $MBADR: .WORD   $MAIL    ;;ADDRESS OF APT MAILBOX (BITS 0-15)
001034  000010                  $TSTM:  .WORD   10       ;;RUN TIM OF LONGEST TEST
001036  000025                  $PASTM: .WORD   25       ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
001040  000000                  $UNITM: .WORD   0        ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
001042  000014                          .WORD   $ETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)
                                ;*****************************************************************************************
                                ;SOME POINTERS TO CPU TRAP HANDLERS
                                ;*****************************************************************************************
000004                                  .=4
000004  021256                          T04
000006  000000                          0
000010  021260                          T010
```

```
                                        0
                                        TO14
                                        0
                                        TO20
                                        0
                                        .=30
                                        TO30
                                        0
                                        TO34
                                        0
                                        .=114
                                        TO114
                                        0
                                        .=244
                                        TO244
                                        0
                                        TO250
                                        0

                        .=172
MTFLAG:                 0               ;MULTI-TESTER ACTIVE BIT
DISPREG:                0               ;SOFTWARE DISPLAY REGISTER
SWREG:                  0               ;SOFTWARE SWITCH REGISTER

;*****************************************************************************************
;DATA TABLE FOR USE IN ADDRESSING MODE TESTS
;*****************************************************************************************
                        .=370
                        0,0,0,0,0,0

                        1,1,-1
;*****************************************************************************************
;SET UP STARTING ADDRESS
                        .=1000
STBOT:  .WORD 0                                 ;STACK POINTER

                        .=200
                JMP     START
                MOV     #STBOT,R6               ;SET STACK POINTER
                MOV     #$TESTN,R2              ;SET MAILBOX POINTER
                JMP     @(PC)+                  ;JUMP TO SUBTEST
                0                               ;ADDR. OF SUBTEST GOES HERE

                        .=1200
                .SBTTL **STARTING OF CPU TEST **
START:  MOV     #0,@#$PASS      ;CLEAR PASS COUNT
RESTRT: MOV     #PWRDN,@#24             ;SET UP FOR POWER FAIL
        MOV     #STBOT,R6       ;SET UP STACK
        MOV     #1$,@#4         ;SET UP FOR TIMEOUT IF NO MULTI TESTER
        MOV     #340,@#6
        MOV     #2,@#164000     ;SET BIT1 FOR MULTI TESTER
        MOV     #1,@#MTFLAG     ;SET FLAG TO INDICATE MULTI-TESTER
1$:     MOV     #TO4,@#4                ;SET TRAP CATCHER
        MOV     #0,@#6          ;SET HALT BACK IN LOCATION 6
        MOV     #STBOT,R6       ;INITIALIZE STACK POINTER
        MOV     #1,@#$TESTN     ;SET TEST NUMBER TO 1
```

```
                                        MOV     #0,@#$FATAL     ;CLEAR ERROR INDICATOR
                                        MOV     #0,@#$MSGTY     ;CLEAR MESSAGE TYPE(FOR APT)
                                        TSTB    @#$ENV          ;RUNNING ON APT
                                        BNE     TS1             ;IF YES DO BRANCH SELF ON ERROR
                                        MOV     #0,@#CPUHLT     ;IF NOT THEN PUT A HALT IN ON ERROR
                                        MOV     #0,@#MMUHLT
                                        MOV     #0,@#FPHLT
                                        MOV     #0,@#LTCHLT
                                        MOV     #0,@#SL1HLT
                                        MOV     #0,@#SL2HLT
                                        MOV     #0,@#COMHLT

;*******************************************************************************************
;
;       THIS TEST EXECUTES EVERY POSSIBLE BRANCH WITH EVERY POSSIBLE
;CONDITION CODE COMBINATION.
;       THE ROUTINE USES TWO TABLES.  THE BRANCH TABLE HOLDS ALL THE
;POSSIBLE BRANCH INSTRUCTIONS, THE OTHER TABLE (YNTAB) HOLDS BIT MAPS FOR
;EACH BRANCH.  A ONE IN THE BIT MAP INDICATES THAT THE CORRESPONDING
;BRANCH INSTRUCTION SHOULD BRANCH FOR THE CONDITION CODE SETTING WHICH
;CORRESPONDS TO THE BIT POSITION WITHIN THE MAP.  FOR EXAMPLE IF THE LEFT
;MOST BIT IS A ONE THEN THE CORRESPONDING BRANCH INSTRUCTION SHOULD BRANCH
;WHEN THE CONDITION CODES ARE 0.
;       THE ROUTINE CONSISTS OF NESTED LOOPS; THE OUTER LOOP SETS UP
;ALL THE POSSIBLE BRANCH INSTRUCTIONS.  THE INNER LOOP SETS UP EVERY POSSIBLE
;CONDITION CODE FOR EACH BRANCH.
;       THE BIT MAP IS USED TO SET THE ADDRESS LOCATION IN TWO
;JUMP MODE 3 INSTRUCTIONS.  THE ADDRESSES ARE CHANGED TO ALLOW THE
;PROGRAM TO CONTINUE OR JUMP TO AN ERROR ROUTINE DEPENDING UPON
;WHETHER IT HANDLED THE BRANCH INSTRUCTION CORRECTLY.
;       AT ANY ERROR HALT, LOCATION, BRH, HOLDS THE BRANCH INSTRUCTION
;UNDER TEST AND LOCATION, CC, HOLDS THE VALUE OF THE CONDITION CODES
;AT THE TIME THE BRANCH WAS EXECUTED.
;
;*******************************************************************************************
;TEST 1 TEST THE BRANCH ROM
;*******************************************************************************************
TS1:
SETUP:  MOV     #BRTAB,R0       ;INITIALIZE BRANCH TABLE POINTER
        MOV     #YNTAB,R4       ;INITIALIZE YES/NO BRANCH MAP POINTER
        MOV     #15.,BRCT       ;INITIALIZE BRANCH TABLE COUNT
SETBR:  MOV     (R0)+,BRH       ;GET NEXT BRANCH INST.
        MOV     (R4)+,R1        ;GET NEXT BRANCH MAP
        MOV     #-1,CC1         ;INITIALIZE CONDITION CODE VALUE
        MOV     #16.,R3         ;INITIALIZE CONDITION CODE COUNT
SETCC:  INC     CC1             ;SET FOR NEXT CC VALUE
        BIT     #100000,R1      ;SEE IF SHOULD BR W/ THESE CC'S
        MOV     @#177776,R5     ;SIMULATE A JNE
        BIC     #177773,R5      ;       (JUMP NOT EQUAL)
        JMP     .+4(R5)         ;       TO SET2BR
        JMP     SET2BR
        MOV     #CONT,NBR       ;SET TO CONTINUE IF NO BRANCH
        MOV     #ER,YBR         ;SET TO REPORT ERROR IF BRANCH
        JMP     AROUN           ;GO AROUND OPPOSITE CONDITION
SET2BR: MOV     #ER,NBR         ;SET TO REPORT ERROR IF NO BRANCH
        MOV     #CONT,YBR       ;SET TO CONTINUE IF BRANCH
```

```
001514  006101                  AROUN:  ROL     R1              ;UPDATE BIT MAP

001516  012737                          MOV     (PC)+,@(PC)+    ;SET CONDITION CODE
001520  000000                  CC1:    0                       ;NEW CC VALUE GOES HERE
001522  177776                          177776
001524  000000                  BRH:    0                       ;BRANCH INST. GOES HERE
001526  000137                          JMP     @(PC)+          ;THIS JUMP IF NO BRANCH
001530  000000                  NBR:    0                       ;WHERE TO GO IF NO BRANCH OCCURS
001532  000137                          JMP     @(PC)+          ;THIS JUMP IF BRANCH OCCURS
001534  000000                  YBR:    0                       ;WHERE TO GO IF BRANCH OCCURS
001536                          ER:
001536  000551                          BR      ERROR1          ;
001540  000000                  BRCT:   0
001542  005303                  CONT:   DEC     R3              ;CC'S DONE?
001544  013705  177776                  MOV     @#177776,R5     ;SIMULATE A JNE
001550  042705  177773                  BIC     #177773,R5      ;       (JUMP NOT EQUAL)
001554  000165  001560                  JMP     .+4(R5)         ;       TO SETCC
001560  000167  177644                  JMP     SETCC
001564  005367  177750                  DEC     BRCT            ;BR'S DONE?
001570  013705  177776                  MOV     @#177776,R5     ;SIMULATE A JNE
001574  042705  177773                  BIC     #177773,R5      ;       (JUMP NOT EQUAL)
001600  000165  001604                  JMP     .+4(R5)         ;       TO SETBR
001604  000167  177600                  JMP     SETBR
001610  012700  000357                  MOV     #357,R0         ;IF THIS TEST IS DONE SET UP R0 FOR THE NEXT
                                                                ;SEVEN TESTS. THIS IS SAVING 4 LOCATIONS PER
                                                                ;TEST WHICH I NEED BECAUSE BRANCHES WERE OUT
                                                                ;OF BOUNDS.


                                ;*******************************************************************************
                                ;TEST 2 TEST TRAP OF RESERVED INSTRUCTION
                                ;*******************************************************************************
001614                          TS2:
001614  012706  001000                    MOV     #STBOT,SP       ;INITIALIZE THE STACK POINTER
001620  012767  001642  176162            MOV     #1$,RTRAP               ;SET UP NEW PC IN VECTOR
001626  010067  176160                    MOV     R0,RTRAP+2              ;SET UP NEW PSW IN VECTOR
001632  005067  176140                    CLR     STATUS          ;CLEAR PRESENT (OLD) STATUS
001636  000077                            TRAPA                   ;DO TRAP
001640                          8$:
001640  000510                            BR      ERROR1          ;INSTRUCTION FAILED TO TRAP
001642  020067  176130          1$:       CMP     R0,STATUS       ;IS NEW STATUS CORRECT
001646  001105                            BNE     ERROR1          ;NEW STATUS WRONG
001650  020627  000774          2$:       CMP     SP,#STBOT-4     ;DID STACK DECREMENT CORRECTLY
001654  001102                            BNE     ERROR1          ;STACK DID NOT DECREMENT CORRECTLY
001656  022767  001640  177110  3$:       CMP     #8$,STBOT-4     ;WAS PROPER PC SAVED
001664  001076                            BNE     ERROR1          ;PROPER PC WAS NOT SAVED
001666  005767  177104          4$:       TST     STBOT-2         ;WAS OLD PSW SAVED
001672  001073                            BNE     ERROR1          ;WRONG PSW SAVED
001674  062706  000004          5$:       ADD     #4,SP           ;RESET STACK POINTER
001700  012767  001722  176102            MOV     #6$,RTRAP               ;SET UP NEW PC IN VECTOR
001706  005067  176100                    CLR     RTRAP+2         ;SET UP NEW PSW IN VECTOR
001712  010037  177776                    MOV     R0,@#STATUS     ;SET UP OLD STATUS FOR COMPARISON AFTER TRAP
001716  000077                            TRAPA                   ;DO TRAP
001720  000460                            BR      ERROR1          ;INSTRUCTION FAILED TO TRAP
001722  005767  176050          6$:       TST     STATUS          ;IS NEW PSW CORRECT
001726  001055                            BNE     ERROR1          ;NEW PSW WRONG
```

```
                                7$:     CMP     R0,STBOT-2      ;WAS OLD STATUS STORED
                                        BNE     ERROR1          ;OLD STATUS WRONG
                                ;*************************************************************************************
                                ;TEST 3 TEST TRAP OF TRAP INSTRUCTION
                                ;*************************************************************************************
                                TS3:
                                        MOV     #STBOT,SP       ;INITIALIZE THE STACK POINTER
                                        MOV     #1$,RTRAP1              ;SET UP NEW PC IN VECTOR
                                        MOV     R0,RTRAP1+2             ;SET UP NEW PSW IN VECTOR
                                        CLR     STATUS          ;CLEAR PRESENT (OLD) STATUS
                                        TRAP                    ;DO TRAP
                                8$:
                                        BR      ERROR1          ;INSTRUCTION FAILED TO TRAP
                                1$:     CMP     R0,STATUS       ;IS NEW STATUS CORRECT
                                        BNE     ERROR1          ;NEW STATUS WRONG
                                2$:     CMP     SP,#STBOT-4     ;DID STACK DECREMENT CORRECTLY
                                        BNE     ERROR1          ;STACK DID NOT DECREMENT CORRECTLY
                                3$:     CMP     #8$,STBOT-4     ;WAS PROPER PC SAVED
                                        BNE     ERROR1          ;PROPER PC WAS NOT SAVED
                                4$:     TST     STBOT-2         ;WAS OLD PSW SAVED
                                        BNE     ERROR1          ;WRONG PSW SAVED
                                5$:     ADD     #4,SP           ;RESET STACK POINTER
                                        MOV     #6$,RTRAP1              ;SET UP NEW PC IN VECTOR
                                        CLR     RTRAP1+2                ;SET UP NEW PSW IN VECTOR
                                        MOV     R0,@#STATUS     ;SET UP OLD STATUS FOR COMPARISON AFTER TRAP
                                        TRAPC                   ;DO TRAP WITH LOWER BYTE ALL ONES
                                        BR      ERROR1          ;INSTRUCTION FAILED TO TRAP
                                6$:     TST     STATUS          ;IS NEW PSW CORRECT
                                        BNE     ERROR1          ;NEW PSW WRONG
                                7$:     CMP     R0,STBOT-2      ;WAS OLD STATUS STORED
                                        BNE     ERROR1          ;OLD STATUS WRONG
                                        BR      CPUHLT+2        ;GET OVER ERROR CALL TO NEXT TEST IF NO ERROR
                                ;*************************************************************************************
                                ;THIS ERROR IS USED FOR THE ENTIRE CPU,TRAPS AND EIS PORTION OF
                                ;THIS TEST
                                ;*************************************************************************************
                                ERROR1: MOV     #1$,@#4         ;SET UP THE TIMEOUT VECTOR
                                        MOV     #340,@#6
                                        TST     @#177766        ;CHECK TO SEE IF THE POWER FAILED,WILL TRAP
                                                                ;TO 1$ IF UNIBUS MAP BOARD IS NOT PRESENT
                                                                ;SINCE THE CPUERR(177766)IS ON THE UNIBUS
                                                                ;MAP BOARD
                                        BEQ     1$              ;NO,GO REPORT THE ERROR
                                        MOV     #177,@#$FATAL   ;YES,FLAG THAT THE POWER FAILED
                                        BR      2$              ; AND GO SET FATAL ERROR FLAG
                                1$:     MOV     #1,@#$FATAL             ;SET UP FATAL ERROR NUMBER
                                2$:     MOV     #1,$MSGTY               ;SET FATAL ERROR FLAG
                                CPUHLT: BR      .
                                ;*************************************************************************************
                                ;TEST 4 TEST TRAP OF IOT INSTRUCTION
                                ;*************************************************************************************
                                TS4:
                                        MOV     #STBOT,SP       ;INITIALIZE THE STACK POINTER
                                        MOV     #1$,RTRAP2              ;SET UP NEW PC IN VECTOR
                                        MOV     R0,RTRAP2+2             ;SET UP NEW PSW IN VECTOR
                                        CLR     STATUS          ;CLEAR PRESENT (OLD) STATUS
```

```
                                        IOT                     ;DO TRAP
                                8$:
                                        BR      ERROR1          ;INSTRUCTION FAILED TO TRAP
                                1$:     CMP     R0,STATUS       ;IS NEW STATUS CORRECT
                                        BNE     ERROR1          ;NEW STATUS WRONG
                                2$:     CMP     SP,#STBOT-4     ;DID STACK DECREMENT CORRECTLY
                                        BNE     ERROR1          ;STACK DID NOT DECREMENT CORRECTLY
                                3$:     CMP     #8$,STBOT-4     ;WAS PROPER PC SAVED
                                        BNE     ERROR1          ;PROPER PC WAS NOT SAVED
                                4$:     TST     STBOT-2         ;WAS OLD PSW SAVED
                                        BNE     ERROR1          ;WRONG PSW SAVED
                                5$:     ADD     #4,SP           ;RESET STACK POINTER
                                        MOV     #6$,RTRAP2              ;SET UP NEW PC IN VECTOR
                                        CLR     RTRAP2+2                ;SET UP NEW PSW IN VECTOR
                                        MOV     R0,@#STATUS     ;SET UP OLD STATUS FOR COMPARISON AFTER TRAP
                                        IOT                     ;DO TRAP
                                        BR      ERROR1          ;INSTRUCTION FAILED TO TRAP
                                6$:     TST     STATUS          ;IS NEW PSW CORRECT
                                        BNE     ERROR1          ;NEW PSW WRONG
                                7$:     CMP     R0,STBOT-2      ;WAS OLD STATUS STORED
                                        BNE     ERROR1          ;OLD STATUS WRONG
                                ;*******************************************************************************
                                ;TEST 5 TEST TRAP OF EMT INSTRUCTION
                                ;*******************************************************************************
                                TS5:
                                        MOV     #STBOT,SP       ;INITIALIZE THE STACK POINTER
                                        MOV     #1$,RTRAP3              ;SET UP NEW PC IN VECTOR
                                        MOV     R0,RTRAP3+2             ;SET UP NEW PSW IN VECTOR
                                        CLR     STATUS          ;CLEAR PRESENT (OLD) STATUS
                                        EMT                     ;DO TRAP
                                8$:
                                        BR      ERROR1          ;INSTRUCTION FAILED TO TRAP
                                1$:     CMP     R0,STATUS       ;IS NEW STATUS CORRECT
                                        BNE     ERROR1          ;NEW STATUS WRONG
                                2$:     CMP     SP,#STBOT-4     ;DID STACK DECREMENT CORRECTLY
                                        BNE     ERROR1          ;STACK DID NOT DECREMENT CORRECTLY
                                3$:     CMP     #8$,STBOT-4     ;WAS PROPER PC SAVED
                                        BNE     ERROR1          ;PROPER PC WAS NOT SAVED
                                4$:     TST     STBOT-2         ;WAS OLD PSW SAVED
                                        BNE     ERROR1          ;WRONG PSW SAVED
                                5$:     ADD     #4,SP           ;RESET STACK POINTER
                                        MOV     #6$,RTRAP3              ;SET UP NEW PC IN VECTOR
                                        CLR     RTRAP3+2                ;SET UP NEW PSW IN VECTOR
                                        MOV     R0,@#STATUS     ;SET UP OLD STATUS FOR COMPARISON AFTER TRAP
                                        EMTA                    ;DO TRAP WITH LOWER BYTE ALL ONES
                                        BR      ERROR1          ;INSTRUCTION FAILED TO TRAP
                                6$:     TST     STATUS          ;IS NEW PSW CORRECT
                                        BNE     ERROR1          ;NEW PSW WRONG
                                7$:     CMP     R0,STBOT-2      ;WAS OLD STATUS STORED
                                        BNE     ERROR1          ;OLD STATUS WRONG
                                        BR      ERROR2+2        ;WE MUST GET OVER ERROR CALL AT END OF THIS TEST
                                ;*******************************************************************************
                                ;THIS ERROR IS NEEDED BECAUSE BRANCHES IN TRAP TESTS BEYOND HERE CAN NOT
                                ;REACH ERROR1.
                                ;*******************************************************************************
                                ERROR2: BR      ERROR1
```

```
                                ;*****************************************************************************************
                                ;TEST 6 TEST TRAP OF TRACE-TRAP INSTRUCTION
                                ;*****************************************************************************************
002402                          TS6:
002402  012706  001000                MOV     #STBOT,SP       ;INITIALIZE THE STACK POINTER
002406  012767  002430  175400        MOV     #1$,RTRAP4              ;SET UP NEW PC IN VECTOR
002414  010067  175376                MOV     R0,RTRAP4+2             ;SET UP NEW PSW IN VECTOR
002420  005067  175352                CLR     STATUS          ;CLEAR PRESENT (OLD) STATUS
002424  000003                        TRT                     ;DO TRAP
002426                          8$:
002426  000764                        BR      ERROR2          ;INSTRUCTION FAILED TO TRAP
002430  020067  175342          1$:   CMP     R0,STATUS       ;IS NEW STATUS CORRECT
002434  001361                        BNE     ERROR2          ;NEW STATUS WRONG
002436  020627  000774          2$:   CMP     SP,#STBOT-4     ;DID STACK DECREMENT CORRECTLY
002442  001356                        BNE     ERROR2          ;STACK DID NOT DECREMENT CORRECTLY
002444  022767  002426  176322  3$:   CMP     #8$,STBOT-4     ;WAS PROPER PC SAVED
002452  001352                        BNE     ERROR2          ;PROPER PC WAS NOT SAVED
002454  005767  176316          4$:   TST     STBOT-2         ;WAS OLD PSW SAVED
002460  001347                        BNE     ERROR2          ;WRONG PSW SAVED
002462  062706  000004          5$:   ADD     #4,SP           ;RESET STACK POINTER
002466  012767  002510  175320        MOV     #6$,RTRAP4              ;SET UP NEW PC IN VECTOR
002474  005067  175316                CLR     RTRAP4+2                ;SET UP NEW PSW IN VECTOR
002500  010037  177776                MOV     R0,@#STATUS     ;SET UP OLD STATUS FOR COMPARISON AFTER TRAP
002504  000003                        TRT                     ;DO TRAP
002506  000734                        BR      ERROR2          ;INSTRUCTION FAILED TO TRAP
002510  005767  175262          6$:   TST     STATUS          ;IS NEW PSW CORRECT
002514  001331                        BNE     ERROR2          ;NEW PSW WRONG
002516  020067  176254          7$:   CMP     R0,STBOT-2      ;WAS OLD STATUS STORED
002522  001326                        BNE     ERROR2          ;OLD STATUS WRONG
                                ;PDP-11 ILLEGAL AND ADDRESS INSTRUCTION TEST
                                ;ALL INSTRUCTIONS THAT ARE RESERVED
                                ;SHOULD TRAP TO LOCATION 4, AND THE
                                ;PC THAT POINTS TO THE TRAPPING INSTRUCTION
                                ;SHOULD BE PLACED ON THE STACK

                                ;*****************************************************************************************
                                ;TEST 7 TEST TRAP OF ILLEGAL INSTRUCTION
                                ;*****************************************************************************************
002524                          TS7:
002524  012706  001000                MOV     #STBOT,SP       ;INITIALIZE THE STACK POINTER
002530  012767  002552  175246        MOV     #1$,RTRAP5              ;SET UP NEW PC IN VECTOR
002536  010067  175244                MOV     R0,RTRAP5+2             ;SET UP NEW PSW IN VECTOR
002542  005067  175230                CLR     STATUS          ;CLEAR PRESENT (OLD) STATUS
002546  000100                        JMP     %0                      ;DO TRAP
002550                          8$:
002550  000713                        BR      ERROR2          ;INSTRUCTION FAILED TO TRAP
002552  020067  175220          1$:   CMP     R0,STATUS       ;IS NEW STATUS CORRECT
002556  001310                        BNE     ERROR2          ;NEW STATUS WRONG
002560  020627  000774          2$:   CMP     SP,#STBOT-4     ;DID STACK DECREMENT CORRECTLY
002564  001305                        BNE     ERROR2          ;STACK DID NOT DECREMENT CORRECTLY
002566  022767  002550  176200  3$:   CMP     #8$,STBOT-4     ;WAS PROPER PC SAVED
002574  001301                        BNE     ERROR2          ;PROPER PC WAS NOT SAVED
002576  005767  176174          4$:   TST     STBOT-2         ;WAS OLD PSW SAVED
002602  001276                        BNE     ERROR2          ;WRONG PSW SAVED
```

```
 953  002604  062706  000004          5$:     ADD     #4,SP           ;RESET STACK POINTER
 954  002610  012767  002632  175166          MOV     #6$,RTRAP5              ;SET UP NEW PC IN VECTOR
 955  002616  005067  175164                  CLR     RTRAP5+2                ;SET UP NEW PSW IN VECTOR
 956  002622  010037  177776                  MOV     R0,@#STATUS     ;SET UP OLD STATUS FOR COMPARISON AFTER TRAP
 957  002626  000100                          JMP     %0                      ;DO TRAP
 958  002630  000663                          BR      ERROR2          ;INSTRUCTION FAILED TO TRAP
 959  002632  005767  175140          6$:     TST     STATUS          ;IS NEW PSW CORRECT
 960  002636  001260                          BNE     ERROR2          ;NEW PSW WRONG
 961  002640  020067  176132          7$:     CMP     R0,STBOT-2      ;WAS OLD STATUS STORED
 962  002644  001255                          BNE     ERROR2          ;OLD STATUS WRONG
 963                                  ;*******************************************************************************
 964                                  ;TEST 10        TEST TRAP OF ALL ILLEGAL INSTRUCTION
 965                                  ;*******************************************************************************
 966  002646                          TS10:
 967  002646  012706  001000                  MOV     #STBOT,SP       ;INITIALIZE THE STACK POINTER
 968  002652  012767  002674  175124          MOV     #1$,RTRAP5              ;SET UP NEW PC IN VECTOR
 969  002660  010067  175122                  MOV     R0,RTRAP5+2             ;SET UP NEW PSW IN VECTOR
 970  002664  005067  175106                  CLR     STATUS          ;CLEAR PRESENT (OLD) STATUS
 971  002670  004000                          JSR     %0,%0                   ;DO TRAP
 972  002672                          8$:
 973  002672  000642                          BR      ERROR2          ;INSTRUCTION FAILED TO TRAP
 974  002674  020067  175076          1$:     CMP     R0,STATUS       ;IS NEW STATUS CORRECT
 975  002700  001237                          BNE     ERROR2          ;NEW STATUS WRONG
 976  002702  020627  000774          2$:     CMP     SP,#STBOT-4     ;DID STACK DECREMENT CORRECTLY
 977  002706  001234                          BNE     ERROR2          ;STACK DID NOT DECREMENT CORRECTLY
 978  002710  022767  002672  176056  3$:     CMP     #8$,STBOT-4     ;WAS PROPER PC SAVED
 979  002716  001230                          BNE     ERROR2          ;PROPER PC WAS NOT SAVED
 980  002720  005767  176052          4$:     TST     STBOT-2         ;WAS OLD PSW SAVED
 981  002724  001225                          BNE     ERROR2          ;WRONG PSW SAVED
 982  002726  062706  000004          5$:     ADD     #4,SP           ;RESET STACK POINTER
 983  002732  012767  002754  175044          MOV     #6$,RTRAP5              ;SET UP NEW PC IN VECTOR
 984  002740  005067  175042                  CLR     RTRAP5+2                ;SET UP NEW PSW IN VECTOR
 985  002744  010037  177776                  MOV     R0,@#STATUS     ;SET UP OLD STATUS FOR COMPARISON AFTER TRAP
 986  002750  004000                          JSR     %0,%0                   ;DO TRAP
 987  002752  000612                          BR      ERROR2          ;INSTRUCTION FAILED TO TRAP
 988  002754  005767  175016          6$:     TST     STATUS          ;IS NEW PSW CORRECT
 989  002760  001207                          BNE     ERROR2          ;NEW PSW WRONG
 990  002762  020067  176010          7$:     CMP     R0,STBOT-2      ;WAS OLD STATUS STORED
 991  002766  001204                          BNE     ERROR2          ;OLD STATUS WRONG
 992
 993                                  ;*******************************************************************************
 994                                  .SBTTL  DATA PATH TESTS
 995                                  ;
 996                                  ;       THE DATA PATH TESTS ARE USED TO VERIFY THAT VARIOUS
 997                                  ;DATA PATTERNS CAN BE SUCCESSFULLY MOVED THROUGH THE DATA PATHS
 998                                  ;MOVE AND COMPARE MODE 2,3 INSTRUCTIONS ARE USED TO PASS AND
 999                                  ;TEST VARIOUS DATA PATTERNS IN THE DATA PATHS.
1000                                  ;       THE TEST EXERCISES THE INTERNAL DATA PATHS,  AND THE UNIBUS
1001                                  ;DATA TRANSCIEVERS.
1002                                  ;       IF THESE TESTS FAIL, EXAMINE THE TARGET LOCATION (LOC. 0)
1003                                  ;TO SEE WHICH BITS OF THE DATA PATH ARE FAILING.
1004  002770  012737  002062  000030          MOV     #ERROR1,@#30    ;SET UP VECTOR FOR ERROR CALLS
1005  002776  012737  000340  000032          MOV     #340,@#32       ;SET UP NEW PSW
1006  003004  012737  021256  000004          MOV     #T04,@#4        ;SET UP FOR UNEXPECTED TRAP TO 4
1007  003012  012737  021260  000010          MOV     #T010,@#10      ;SET UP FOR UNEXPECTED TRAP TO 10
1008  003020  012737  021262  000014          MOV     #T014,@#14      ;SET UP FOR UNEXPECTED TRAP TO 14
```

```
1009  003026  012737  021270  000034          MOV     #T034,@#34      ;SET UP FOR UNEXPECTED TRAP TO 34
1010  003034  012737  021264  000020          MOV     #T020,@#20      ;SET UP FOR UNEXPECTED TRAP TO 20
1011
1012
1013                                  ;*************************************************************************
1014                                  ;TEST 11        TEST OF ZEROES IN THE DATA PATH
1015                                  ;*************************************************************************
1016  003042                          TS11:
1017  003042  012737  000000  000000          MOV     #0,@#0          ;MOVE ZEROES THRU ADDRESS LINES, DATA
1018                                                                  ;LINES AND INTERNAL PATHS
1019  003050  005737  000000                  TST     @#0             ;SUCCESSFUL?
1020  003054  001401                          BEQ     TS12
1021  003056  104000                          EMT                     ;DATA INCORRECT
1022
1023                                  ;*************************************************************************
1024                                  ;TEST 12        TEST OF PATTERN 125252 IN DATA PATH
1025                                  ;*************************************************************************
1026  003060                          TS12:
1027  003060  012737  125252  000000          MOV     #125252,@#0     ;MOVE ALTERNATING ONES AND ZEROES
1028                                                                  ;THRU DATA PATHS
1029  003066  022737  125252  000000          CMP     #125252,@#0     ;SUCCESSFUL
1030  003074  001401                          BEQ     TS13
1031  003076  104000                          EMT                     ;DATA INCORRECT
1032
1033                                  ;*************************************************************************
1034                                  ;TEST 13        TEST OF PATTERN 052525 IN DATA PATH
1035                                  ;*************************************************************************
1036  003100                          TS13:
1037  003100  012737  052525  000000          MOV     #052525,@#0     ;MOVE ALTERNATING ZEROES AND ONES
1038                                                                  ;THRU DATA PATH
1039  003106  022737  052525  000000          CMP     #052525,@#0     ;SUCCESSFUL?
1040  003114  001401                          BEQ     TS14
1041  003116  104000                          EMT                     ;DATA INCORRECT
1042
1043                                  ;*************************************************************************
1044                                  ;TEST 14        TEST OF ALL ONES IN DATA PATH
1045                                  ;*************************************************************************
1046  003120                          TS14:
1047  003120  012737  177777  000000          MOV     #177777,@#0     ;MOVE ONES THRU DATA PATH
1048  003126  022737  177777  000000          CMP     #177777,@#0     ;SUCCESSFUL
1049  003134  001401                          BEQ     TS15
1050  003136  104000                          EMT                     ;DATA INCORRECT
1051
1052                                  ;*************************************************************************
1053                                  .SBTTL  B-REGISTER TEST
1054                                  ;
1055                                  ;       THE B-REGISTER (LOCATION 0) SHIFTING LOGIC TESTS ARE USED
1056                                  ;TO TEST THAT THE B-REGISTER CAN HOLD VARIOUS DATA PATTERNS AND THAT
1057                                  ;THE ASSOCIATED LOGIC SUPPORTS THE SHIFTING FUNCTIONS WITHIN THE
1058                                  ;B-REGISTER AND C-BIT.
1059                                  ;A ONE IS SHIFTED THROUGH EVERY BIT IN THE B-REGISTER AND C-BIT IN
1060                                  ;BOTH DIRECTIONS.
1061                                  ;       THE B-REGISTER ITSELF IS TESTED IN ITS ABILITY AS A BUFFER AND AS
1062                                  ;A SHIFT REGISTER.  DATA IS ALSO PASSED THROUGH THE DATA PATH AND ALU.
1063                                  ;       IF THESE TESTS FAIL, EXAMINE THE TARGET LOCATION (LOC. 0) TO SEE
1064                                  ;WHICH BITS OF THE B-REGISTER MAY BE FAILING.
```

```
                                        ;
                                        ;*****************************************************************************************
                                        ;TEST 15        SHIFT BIT 0 TO BIT 1
                                        ;*****************************************************************************************
003140                                  TS15:
003140  000241                                  CLC                             ;CLEAR CARRY BIT
003142  012737  000001  000000                  MOV     #1,@#0                  ;LOAD A 1
003150  006137  000000                          ROL     @#0                     ;SHIFT LEFT
003154  022737  000002  000000                  CMP     #2,@#0                  ;SUCCESSFUL
003162  001401                                  BEQ     TS16
003164  104000                                  EMT                             ;BIT 1 NOT SET

                                        ;*****************************************************************************************
                                        ;TEST 16        SHIFT CARRY INTO BIT 0
                                        ;*****************************************************************************************
003166                                  TS16:
003166  012737  000000  000000                  MOV     #0,@#0                  ;CLEAR LOCATION
003174  000261                                  SEC                             ;SET CARRY
003176  006137  000000                          ROL     @#0                     ;ROTATE CARRY BIT TO BIT 0
003202  103001                                  BCC     CARRY1
003204  104000                                  EMT                             ;CARRY CLEAR
003206  022737  000001  000000  CARRY1: CMP     #1,@#0                  ;BIT 0 SET
003214  001401                                  BEQ     TS17
003216  104000                                  EMT                             ;BIT 0 NOT SET

                                        ;*****************************************************************************************
                                        ;TEST 17        LEFT SHIFT FROM BIT 0 TO C-BIT
                                        ;*****************************************************************************************
003220                                  TS17:
003220  012737  000001  000000                  MOV     #1,@#0                  ;SET BIT 0
003226  012700  177757                          MOV     #-21,R0                 ;SET BIT COUNTER
003232  000241                                  CLC                             ;CLEAR C-BIT
003234  005200                          SHL:    INC     R0                      ;INCREMENT BIT COUNTER
003236  001404                                  BEQ     SHLE                    ;BR TO ERROR HALT IF BIT IS LOST
003240  006137  000000                          ROL     @#0                     ;SHIFT LEFT ONE POSITION
003244  103373                                  BCC     SHL                     ;BRANCH IF C-BIT NOT SET
003246  001401                                  BEQ     TS20
003250                                  SHLE:
003250  104000                                  EMT                             ;LEFT SHIFTING LOGIC FAILED

                                        ;*****************************************************************************************
                                        ;TEST 20        SHIFT BIT 15 TO BIT 14
                                        ;*****************************************************************************************
003252                                  TS20:
003252  012737  100000  000000                  MOV     #100000,@#0             ;SET BIT 15
003260  000241                                  CLC                             ;CLEAR CARRY
003262  006037  000000                          ROR     @#0                     ;SHIFT BIT 15 TO BIT 14
003266  022737  040000  000000                  CMP     #40000,@#0              ;SUCCESSFUL
003274  001401                                  BEQ     TS21
003276  104000                                  EMT                             ;BIT 14 NOT SET

                                        ;*****************************************************************************************
                                        ;TEST 21        RIGHT SHIFT FROM BIT 15 TO C-BIT
                                        ;*****************************************************************************************
003300                                  TS21:
003300  012737  100000  000000                  MOV     #100000,@#0             ;SET BIT 15
```

```
                        MOV     #-21,R0         ;SET BIT COUNTER
                        CLC                     ;CLEAR C-BIT
                SHR:    INC     R0              ;INCREMENT BIT COUNTER
                        BEQ     SHRE            ;BR TO ERROR HALT IF BIT IS LOST
                        ROR     @#0             ;ROTATE RIGHT ONE POSITION
                        BCC     SHR             ;BRANCH IF C-BIT CLEAR
                        BEQ     TS22
                SHRE:
                        EMT                     ;RIGHT SHIFT LOGIC FAILED

                ;*******************************************************************************
                .SBTTL  SCRATCH PAD TESTS
                ;
                ;       THE SCRATCH PAD TESTS ARE USED TO VERIFY THAT VARIOUS
                ;DATA PATTERNS CAN BE SUCCESSFULLY HELD IN THE SCRATCH PAD
                ;CIRCUITRY.  MOVE AND COMPARE INSTRUCTIONS ARE USED TO TEST THAT
                ;R0 CAN HOLD VARIOUS DATA PATTERNS.  EACH DATA PATTERN IS
                ;MOVED AND TESTED IN A SMALL LOOP CONVENIENT FOR SCOPING.  THE
                ;SUCCESSFUL COMPLETION OF THESE TESTS SHOULD VERIFY THE CIRCUITRY EXTERNAL
                ;TO THE SCRATCH PAD ITSELF.
                ;       THE REMAINDER OF THE GENERAL REGISTERS ARE TESTED BY MOVING
                ;A BIT INTO BIT 0 OF THE REGISTER AND SHIFTING IT LEFT ONE
                ;BIT AT A TIME INTO THE CARRY BIT.  THE RESULT IS THEN CHECKED TO INSURE THAT
                ;NO BITS WERE PICKED. THE PROCEDURE IS THEN REPEATED UNDER OPPOSITE
                ;CONDITIONS. THE GENERAL REGISTER AND THE CARRY BIT ARE SET TO
                ;ALL ONES, AND A ZERO IS SHIFTED LEFT FROM BIT 0 INTO THE CARRY BIT.
                ;THE RESULT IS THEN CHECKED TO INSURE THAT NO ZEROES WERE PICKED.
                ;       AT THIS POINT ALL OF THE GENERAL REGISTERS HAVE BEEN EXERCISED
                ;AS WELL AS REGISTER 11.
                ;
                ;*******************************************************************************
                ;TEST 22        TEST IF R0 CAN HOLD ALL ZEROES
                ;*******************************************************************************
                TS22:

                        MOV     #0,R0           ;MOVE ZEROES TO R0
                        TST     R0              ;SUCCESSFUL?
                        BEQ     TS23
                        EMT                     ;R0 NOT 0

                ;*******************************************************************************
                ;TEST 23        TEST IF R0 CAN HOLD ONES AND ZEROES
                ;*******************************************************************************
                TS23:
                        MOV     #125252,R0      ;MOVE ALTERNATING ONES AND ZEROES TO R0
                        CMP     R0,#125252      ;SUCCESSFUL?
                        BEQ     TS24
                        EMT                     ;R0 NOT 125252

                ;*******************************************************************************
                ;TEST 24        TEST IF R0 CAN HOLD ZEROES AND ONES
                ;*******************************************************************************
                TS24:
                        MOV     #052525,R0      ;MOVE ALTERNATING ZEROES AND ONES TO R0
                        CMP     R0,#052525      ;SUCCESSFUL?
                        BEQ     TS25
```

```
1177  003372  104000                    EMT                     ;R0 NOT 52525
1178
1179                                    ;*************************************************************************************
1180                                    ;TEST 25        TEST IF R0 CAN HOLD ALL ONES
1181                                    ;*************************************************************************************
1182  003374                            TS25:
1183  003374  012700  177777                   MOV     #177777,R0      ;MOVE ALL ONES TO R0
1184  003400  020027  177777                   CMP     R0,#177777      ;SUCCESSFUL?
1185  003404  001401                           BEQ     TS26
1186  003406  104000                           EMT                     ;R0 NOT 177777
1187
1188                                    ;*************************************************************************************
1189                                    ;TEST 26        TEST IF R1 CAN HOLD A ONE IN ALL BITS
1190                                    ;*************************************************************************************
1191  003410                            TS26:
1192  003410  012701  000001                   MOV     #1,R1           ;SET BIT 0
1193  003414  012700  177757                   MOV     #-21,R0         ;SET BIT COUNTER
1194  003420  000241                           CLC                     ;CLEAR C-BIT
1195  003422  005200                    REG1:  INC     R0              ;INCREMENT BIT COUNTER
1196  003424  001403                           BEQ     REG1E           ;BR TO ERROR HALT IF BIT IS LOST
1197  003426  006101                           ROL     R1              ;ROTATE 1 POSITION
1198  003430  103374                           BCC     REG1            ;ALL DONE
1199  003432  001401                           BEQ     TS27
1200  003434                            REG1E:
1201  003434  104000                           EMT                     ;FAILURE WITH R1
1202
1203                                    ;*************************************************************************************
1204                                    ;TEST 27        TEST IF R1 CAN HOLD A ZERO IN ALL BITS
1205                                    ;*************************************************************************************
1206  003436                            TS27:
1207  003436  012701  177776                   MOV     #-2,R1          ;SET ALL ONES IN R1 EXCEPT FOR BIT 0
1208  003442  012700  177757                   MOV     #-21,R0         ;SET BIT COUNTER
1209  003446  000261                           SEC                     ;SET C-BIT
1210  003450  005200                    REG1A: INC     R0              ;INCREMENT COUNTER
1211  003452  001405                           BEQ     R1ERR           ;BR TO ERROR HALT IF COUNTER=0
1212  003454  006101                           ROL     R1              ;ROTATE 1 POSITION
1213  003456  103774                           BCS     REG1A           ;CONTINUE UNTIL C-BIT IS CLEAR
1214  003460  022701  177777                   CMP     #-1,R1          ;CHECK DATA IN R1
1215  003464  001401                           BEQ     TS30
1216  003466                            R1ERR:
1217  003466  104000                           EMT                     ;FAILURE WITH R1
1218                                    ;*************************************************************************************
1219                                    ;TEST 30        TEST IF R2 CAN HOLD A ONE IN ALL BITS
1220                                    ;*************************************************************************************
1221  003470                            TS30:
1222  003470  012702  000001                   MOV     #1,R2           ;SET BIT 0
1223  003474  012700  177757                   MOV     #-21,R0         ;SET BIT COUNTER
1224  003500  000241                           CLC                     ;CLEAR C-BIT
1225  003502  005200                    REG2:  INC     R0              ;INCREMENT BIT COUNTER
1226  003504  001403                           BEQ     REG2E           ;BR TO ERROR HALT IF BIT IS LOST
1227  003506  006102                           ROL     R2              ;ROTATE 1 POSITION
1228  003510  103374                           BCC     REG2            ;ALL DONE
1229  003512  001401                           BEQ     TS31
1230  003514                            REG2E:
1231  003514  104000                           EMT                     ;FAILURE WITH R2
1232
```

```
                                ;*****************************************************************************
                                ;TEST 31        TEST IF R2 CAN HOLD A ZERO IN ALL BITS
                                ;*****************************************************************************
003516                          TS31:
003516  012702  177776                  MOV     #-2,R2          ;SET ALL ONES IN R2 EXCEPT FOR BIT 0
003522  012700  177757                  MOV     #-21,R0         ;SET BIT COUNTER
003526  000261                          SEC                     ;SET C-BIT
003530  005200                  REG2B:  INC     R0              ;INCREMENT BIT COUNTER
003532  001405                          BEQ     R2ERR           ;BR TO ERROR HALT IF COUNTER=0
003534  006102                          ROL     R2              ;ROTATE 1 POSITION
003536  103774                          BCS     REG2B           ;CONTINUE UNTIL C-BIT IS CLEAR
003540  022702  177777                  CMP     #-1,R2          ;CHECK DATA IN R2
003544  001401                          BEQ     TS32
003546                          R2ERR:
003546  104000                          EMT                     ;FAILURE WITH R2

                                ;*****************************************************************************
                                ;TEST 32        TEST IF R3 CAN HOLD A ONE IN ALL BITS
                                ;*****************************************************************************
003550                          TS32:
003550  012703  000001                  MOV     #1,R3           ;SET BIT 0
003554  012700  177757                  MOV     #-21,R0         ;SET BIT COUNTER
003560  000241                          CLC                     ;CLEAR C-BIT
003562  005200                  REG3:   INC     R0              ;INCREMENT BIT COUNTER
003564  001403                          BEQ     REG3E           ;BR TO ERROR HALT IF BIT IS LOST
003566  006103                          ROL     R3              ;ROTATE 1 POSITION
003570  103374                          BCC     REG3            ;ALL DONE
003572  001401                          BEQ     TS33
003574                          REG3E:
003574  104000                          EMT                     ;FAILURE WITH R3

                                ;*****************************************************************************
                                ;TEST 33        TEST IF R3 CAN HOLD A ZERO IN ALL BITS
                                ;*****************************************************************************
003576                          TS33:
003576  012703  177776                  MOV     #-2,R3          ;SET ALL ONES IN R3 EXCEPT FOR BIT 0
003602  012700  177757                  MOV     #-21,R0         ;SET BIT COUNTER
003606  000261                          SEC                     ;SET C-BIT
003610  005200                  REG3A:  INC     R0              ;INCREMENT BIT COUNTER
003612  001405                          BEQ     R3ERR           ;BR TO ERROR HALT IF COUNTER=0
003614  006103                          ROL     R3              ;ROTATE 1 POSITION
003616  103774                          BCS     REG3A           ;CONTINUE UNTIL C-BIT IS CLEAR
003620  022703  177777                  CMP     #-1,R3          ;CHECK DATA
003624  001401                          BEQ     TS34
003626                          R3ERR:
003626  104000                          EMT                     ;FAILURE WITH R3

                                ;*****************************************************************************
                                ;TEST 34        TEST IF R4 CAN HOLD A ONE IN ALL BITS
                                ;*****************************************************************************
003630                          TS34:
003630  012704  000001                  MOV     #1,R4           ;SET BIT 0
003634  012700  177757                  MOV     #-21,R0         ;SET BIT COUNTER
003640  000241                          CLC                     ;CLEAR C-BIT
003642  005200                  REG4:   INC     R0              ;INCREMENT BIT COUNTER
003644  001403                          BEQ     REG4E           ;BR TO ERROR HALT IF BIT IS LOST
```

```
                        T34     TEST IF R4 CAN HOLD A ONE IN ALL BITS

1289  003646  006104                ROL     R4              ;ROTATE 1 POSITION
1290  003650  103374                BCC     REG4            ;ALL DONE
1291  003652  001401                BEQ     TS35
1292  003654                  REG4E:
1293  003654  104000                EMT                     ;FAILURE WITH R4
1294
1295                          ;*************************************************************************
1296                          ;TEST 35        TEST IF R4 CAN HOLD A ZERO IN ALL BITS
1297                          ;*************************************************************************
1298  003656                  TS35:
1299  003656  012704  177776        MOV     #-2,R4          ;SET ALL ONES IN R4 EXCEPT FOR BIT 0
1300  003662  012700  177757        MOV     #-21,R0         ;SET BIT COUNTER
1301  003666  000261                SEC                     ;SET C-BIT
1302  003670  005200          REG4A: INC     R0              ;INCREMENT BIT COUNTER
1303  003672  001405                BEQ     R4ERR           ;BR TO ERROR HALT IF COUNTER=0
1304  003674  006104                ROL     R4              ;ROTATE 1 POSITION
1305  003676  103774                BCS     REG4A           ;CONTINUE UNTIL C-BIT IS CLEAR
1306  003700  022704  177777        CMP     #-1,R4          ;CHECK DATA
1307  003704  001401                BEQ     TS36
1308  003706                  R4ERR:
1309  003706  104000                EMT                     ;FAILURE WITH R4
1310
1311
1312                          ;*************************************************************************
1313                          ;TEST 36        TEST IF R5 CAN HOLD A ONE IN ALL BITS
1314                          ;*************************************************************************
1315  003710                  TS36:
1316  003710  012705  000001        MOV     #1,R5           ;SET BIT 0
1317  003714  012700  177757        MOV     #-21,R0         ;SET BIT COUNTER
1318  003720  000241                CLC                     ;CLEAR C-BIT
1319  003722  005200          REG5:  INC     R0              ;INCREMENT BIT COUNTER
1320  003724  001403                BEQ     REG5E           ;BR TO ERROR HALT IF BIT IS LOST
1321  003726  006105                ROL     R5              ;ROTATE 1 POSITION
1322  003730  103374                BCC     REG5            ;ALL DONE
1323  003732  001401                BEQ     TS37
1324  003734                  REC5E:
1325  003734  104000                EMT                     ;FAILURE WITH R5
1326
1327                          ;*************************************************************************
1328                          ;TEST 37        TEST IF R5 CAN HOLD A ZERO IN ALL BITS
1329                          ;*************************************************************************
1330  003736                  TS37:
1331  003736  012705  177776        MOV     #-2,R5          ;SET ALL ONES IN R5 EXCEPT FOR BIT 0
1332  003742  012700  177757        MOV     #-21,R0         ;SET BIT COUNTER
1333  003746  000261                SEC                     ;SET C-BIT
1334  003750  005200          REG5A: INC     R0              ;INCREMENT BIT COUNTER
1335  003752  001405                BEQ     R5ERR           ;BR TO ERROR HALT IF COUNTER=0
1336  003754  006105                ROL     R5              ;ROTATE 1 POSITION
1337  003756  103774                BCS     REG5A           ;CONTINUE UNTIL C-BIT IS C;EAR
1338  003760  022705  177777        CMP     #-1,R5          ;CHECK DATA
1339  003764  001401                BEQ     TS40
1340  003766                  R5ERR:
1341  003766  104000                EMT                     ;FAILURE WITH R5
1342
1343
1344                          ;TEST 40        TEST IF R6 CAN HOLD A ONE IN ALL BITS
```

```
1345
1346   003770
1347   003770  012706  000001          ;*****************************************************************************
1348   003774  012700  177757  TS40:
1349   004000  000241                  MOV     #1,R6           ;SET BIT 0
1350   004002  005200                  MOV     #-21,R0         ;SET BIT COUNTER
1351   004004  001403                  CLC                     ;CLEAR C-BIT
1352   004006  006106          REG6:   INC     R0              ;INCREMENT BIT COUNTER
1353   004010  103374                  BEQ     REG6E           ;BR TO ERROR HALT IF BIT IS LOST
1354   004012  001401                  ROL     R6              ;ROTATE 1 POSITION
1355   004014                          BCC     REG6            ;ALL DONE
1356   004014  104000                  BEQ     TS41
1357                           REG6E:
1358                                   EMT                     ;FAILURE WITH R6
1359
1360                           ;*****************************************************************************
1361   004016                  ;TEST 41        TEST IF R6 CAN HOLD A ZERO IN ALL BITS
1362   004016  012706  177776  ;*****************************************************************************
1363   004022  012700  177757  TS41:
1364   004026  000261                  MOV     #-2,R6          ;SET ALL ONES IN R6 EXCEPT FOR BIT 0
1365   004030  005200                  MOV     #-21,R0         ;SET BIT COUNTER
1366   004032  001405                  SEC                     ;SET C-BIT
1367   004034  006106          REG6A:  INC     R0              ;INCREMENT BIT COUNT
1368   004036  103774                  BEQ     R6ERR           ;BR TO ERROR HALT IF COUNTER=0
1369   004040  022706  177777          ROL     R6              ;ROTATE 1 POSITION
1370   004044  001401                  BCS     REG6A           ;CONTINUE UNTIL C-BIT IS CLEAR
1371   004046                          CMP     #-1,R6          ;CHECK DATA
1372   004046  104000                  BEQ     TS42
1373                           R6ERR:
1374                                   EMT                     ;FAILURE WITH R6
1375
1376                           ;*****************************************************************************
1377                           .SBTTL  PSW TESTS
1378                           ;
1379                           ;       THE PSW TESTS ARE USED TO VERIFY THAT VARIOUS DATA
1380                           ;PATTERNS CAN BE SUCCESSFULLY HELD IN THE PSW AND THAT THE
1381                           ;PSW ADDRESSING LOGIC IS FUNCTIONING.  MOVE AND COMPARE INSTRUCTIONS
1382                           ;ARE USED TO TEST THAT THE PSW CAN HOLD VARIOUS DATA PATTERNS.
1383                           ;EACH DATA PATTERN IS MOVED AND TESTED IN A SMALL LOOP CONVENIENT FOR
1384                           ;SCOPING.
1385                           ;       THE PSW REGISTER IS TESTED, THE CC INPUTS ARE TESTED
1386                           ;LATER IN THE MICROCODE TESTS.  SETTING OF THE T-BIT BY THE
1387                           ;TEST PATTERNS IS PURPOSELY AVOIDED. TESTING OF THE
1388                           ;T-BIT TRAP CIRCUITRY IS LEFT FOR THE TRAP TEST.
1389                           ;
1390                           ;*****************************************************************************
1391   004050                  ;TEST 42        TEST IF PSW WILL HOLD ZEROES
1392   004050  012706  001000  ;*****************************************************************************
1393   004054  012737  000000  177776  TS42:
1394   004062  005737  177776          MOV     #STBOT,R6
1395   004066  001401          MOV     #0,@#PS         ;SET PSW TO ZERO
1396   004070  104000          TST     @#PS            ;SUCCESSFUL
                                BEQ     TS43
                                EMT                     ;PSW NOT 0

                        ;*****************************************************************************
                        ;TEST 43        TEST IF PSW WILL HOLD ONES AND ZEROES
                        ;*****************************************************************************
```

```
1401   004072
1402   004072  012737  000252  177776          TS43:
1403   004100  023727  177776  000252                  MOV     #252,@#PS       ;MOVE ALT. ONES AND ZEROES TO PSW
1404   004106  001401                                  CMP     @#PS,#252       ;SUCCESSFUL?
1405   004110  104000                                  BEQ     TS44
1406                                                   EMT                     ;PSW NOT 252
1407
1408                                           ;*****************************************************************************************
1409                                           ;TEST 44        TEST IF PSW (EXCEPT T-BIT) WILL HOLD ZEROES AND ONES
1410   004112                                  ;*****************************************************************************************
1411   004112  012737  000105  177776          TS44:
1412   004120  023727  177776  000105                  MOV     #105,@#PS       ;MOVE ALT. ONES AND ZEROES TO PSW
1413   004126  001401                                  CMP     @#PS,#105       ;SUCCESSFUL?
1414   004130  104000                                  BEQ     TS45
1415                                                   EMT                     ;PSW NOT 105
1416
1417                                           ;*****************************************************************************************
1418                                           ;TEST 45        TEST IF PSW (EXCEPT T-BIT) WILL HOLD ALL ONES
1419   004132                                  ;*****************************************************************************************
1420   004132  012737  000357  177776          TS45:
1421   004140  023727  177776  000357                  MOV     #357,@#PS       ;MOVE ONES TO PSW
1422   004146  001401                                  CMP     @#PS,#357       ;SUCCESSFUL
1423   004150  104000                                  BEQ     TS46
1424                                                   EMT                     ;PSW NOT 357
1425                                           ;*****************************************************************************************
1426                                           .SBTTL  MICROCODE TESTS
1427                                           ;
1428                                           ;       THE TEST EXERCISES  BRANCHES IN THE MICROCODE BY
1429                                           ;TESTING AT LEAST ONE INSTRUCTION FROM EVERY CLASS OF INSTRUCTION IN
1430                                           ;ALL POSSIBLE MODES.  FOR EXAMPLE, TO TEST THE SINGLE OPERAND INSTRUCTIONS,
1431                                           ;AT LEAST ONE SINGLE OPERAND INSTRUCTION IS VERIFIED IN ALL UNIQUE
1432                                           ;ADDRESSING MODES.  BYTE MODES ARE ALSO TESTED.  AS EACH NEW
1433                                           ;MODE IS INTRODUCED THE SAME INSTRUCTION IS TRIED AND TESTED IN
1434                                           ;A SMALL LOOP CONVENIENT FOR SCOPING.  THE TEST IS SET UP USING
1435                                           ;ONLY INSTRUCTIONS AND ADDRESSING MODES WHICH HAVE BEEN PREVIOUSLY
1436                                           ;VERIFIED.
1437                                           ;       IF THESE TESTS FAIL, CHECK THE RESULTS FOR A CLUE TO THE
1438                                           ;FAULT.
1439                                           ;
1440                                           ;*****************************************************************************************
1441
1442
1443                                           ;*****************************************************************************************
1444                                           ;
1445                                           ;       THE CLR INSTRUCTION IS USED TO INTRODUCE EACH ADDRESSING
1446                                           ;MODE WITH THE SINGLE OPERAND INSTRUCTION.  FOLLOWING THE SEQUENCE CHECK,
1447                                           ;THE CLR INSTRUCTION IS EXECUTED AND A BRANCH TEST IS EXECUTED WHICH
1448                                           ;CHECKS THAT THE Z-BIT WAS PROPERLY SET.  THIS TEST CAN CHECK IR DECODE
1449                                           ;AND MICROCODE FOR SOP INSTRUCTIONS WITH MODE 0.  FOLLOWING THIS TEST
1450                                           ;SEVERAL OTHER SOP INSTRUCTIONS ARE INTRODUCED WITH MODE 0.  THESE
1451                                           ;INSTRUCTIONS MAINPULATE DATA AND SERVE TO CHECK THE DATA RESULTS
1452                                           ;OF THE SOP INSTRUCTIONS IN THIS TEST.  THE DATA IN THIS TEST IS
1453                                           ;OPERATED ON BY EACH INSTRUCTION WITHOUT REINITIALIZING.
1454                                           ;
1455                                           ;*****************************************************************************************
1456                                           ;TEST 46        TEST MODE 0 USING SOP INST.
```

```
1457
1458  004152
1459  004152  005000          ;*****************************************************************************************
1460  004154  001401          TS46:
1461  004156  104000                CLR     R0              ;TRY THE CLEAR INST.
1462  004160  005200                BEQ     SOP0A
1463  004162  005100                EMT                     ;CLR DID NOT SET Z-BIT
1464  004164  005200          SOP0A: INC     R0              ;TRY THE INCREMENT INST.
1465  004166  100401                COM     R0              ;TRY COMPLEMENT
1466  004170  104000                INC     R0
1467  004172  005100                BMI     SOP0B
1468  004174  001401                EMT                     ;NEGATE DID NOT SET N-BIT
1469  004176  104000          SOP0B: COM     R0              ;TRY COMPLEMENT INST.
1470                                BEQ     TS47
1471                                EMT                     ;CUMMULATIVE RESULT OF CLR,INC,NEG AND COM INSTS. FAILED
1472
1473                          ;*****************************************************************************************
1474                          ;
1475                          ;       THIS TEST INTRODUCES THE REMAINING SOP INSTRUCIONS AND TESTS
1476                          ;THEM IN MODE 0.  THE PURPOSE IS TO PROVIDE A BASELINE OF
1477                          ;INSTRUCTIONS FOR USE IN THE SUBSEQUENT TESTS.  SINCE THE MICROCODE FOR
1478                          ;THESE INSTRUCTIONS IS IDENTICAL TO THAT ALREADY TESTED, ANY TROUBLE
1479                          ;SHOOTING EFFORTS SHOULD BE AIMED AT THE ACTUAL IR DECODE AND ALU
1480                          ;FUNCTIONING.
1481                          ;
1482                          ;*****************************************************************************************
1483                          ;TEST 47        TEST REMAINDER OF SOP INSTS IN MODE 0
1484  004200                  ;*****************************************************************************************
1485  004200  005000          TS47:
1486  004202  005300                CLR     R0              ;INITIALIZE
1487  004204  100401                DEC     R0              ;TRY DECREMENT INST.
1488  004206  104000                BMI     SOP0C
1489  004210  000261                EMT                     ;N-BIT NOT SET ON DEC
1490  004212  005500          SOP0C: SEC                     ;INITIALIZE CARRY
1491  004214  001007                ADC     R0              ;TRY ADD CARRY INST
1492  004216  000261                BNE     SOP0D
1493  004220  005600                SEC                     ;INITIALIZE CARRY
1494  004222  100004                SBC     R0              ;TRY SUBTRACT-CARRY INST
1495  004224  005100                BPL     SOP0D
1496  004226  005200                COM     R0
1497  004230  005300                INC     R0
1498  004232  001401                DEC     R0
1499  004234                        BEQ     TS50
1500  004234  104000          SOP0D:
1501                                EMT                     ; CUMMULATIVE RESULT OF ADC,SBC,COM,INC AND DEC INSTS. F
1502
1503                          ;*****************************************************************************************
1504                          ;
1505                          ;       THIS TEST INTRODUCES THE BYTE CONTROL LOGIC OF THE PROCESSOR.
1506                          ;THE MODE 0 BYTE MICROCODE IS TESTED.  THE METHOD AND SEQUENCE
1507                          ;OF TESTING IS THE SAME AS THAT USED IN THE SOP MODE 0 TESTS.
1508                          ;
1509                          ;*****************************************************************************************
1510                          ;TEST 50        TEST MODE 0 EVEN BYTE USING SOP INST
1511  004236                  ;*****************************************************************************************
1512  004236  105000          TS50:
                                CLRB    R0              ;TRY CLEARING EVEN BYTE OF REGISTER
```

```
                        BEQ     SOPB0A
                        EMT                     ;CLRB DID NOT SET Z-BIT
SOPB0A:                 COMB    R0              ;TRY SETTING EVEN BYTE OF REGISTER
                        BPL     SOPB0B
                        INCB    R0              ;TRY INCREMENTING EVEN BYTE OF REGISTER>>
                        BEQ     TS51
SOPB0B:
                        EMT                     ;TEST CUMMULATIVE RESULT OF ABOVE BYTE INST.

                ;*******************************************************************************
                ;
                ;       THIS TEST USES THE CLR INSTRUCTION TO INTRODUCE AND TEST
                ;SINGLE OPERAND MODE 1 INSTRUCTIONS.  AGAIN, THE CLR INSTRUCTION
                ;IS USED TO INTRODUCE THE MICROCODE AND TO TEST THAT THE PROPER
                ;CONDITION CODES ARE SET.  OTHER SOP INSTRUCTIONS ARE USED TO MANIPULATE
                ;COMMON DATA TO VERIFY THAT THE CORRECT DATA IS PRODUCED.
                ;
                ;*******************************************************************************
                ;TEST 51         TEST MODE 1 USING SOP INST.
                ;*******************************************************************************
                TS51:
                        CLR     R0              ;INITIALIZE R0
                        CLR     (R0)            ;TRY CLEAR INST W/MODE 1
                        BEQ     SOP1A
                        EMT                     ;CLR DID NOT SET Z-BIT
                SOP1A:  DEC     (R0)            ;TRY DECREMENT INST W/MODE 1
                        BPL     SOP1B
                        SEC                     ;INITIALIZE CARRY
                        ADC     (R0)            ;TRY ADD-CARRY W/MODE 1
                        BEQ     TS52
                SOP1B:
                        EMT                     ;TEST CUMMULATIVE RESULT OF ABOVE INST

                ;*******************************************************************************
                ;
                ;       THIS TEST VERIFIES THE BYTE INSTRUCTION MICROCODE FOR MODE 1
                ;SINGLE OPERAND INSTRUCTIONS.
                ;       THIS IS THE FIRST PLACE THE SIGN EXTEND LOGIC IS EXERCISED
                ;AND VERIFIED.
                ;
                ;*******************************************************************************
                ;TEST 52         TEST MODE 1 EVEN BYTE USING SOP INST
                ;*******************************************************************************
                TS52:
                        CLR     R0              ;INITIALIZE R0
                        CLR     (R0)            ;INITIALIZE LOC. 0
                        COM     (R0)
                        CLRB    (R0)            ;TRY TO CLEAR BYTE 0
                        BEQ     SOPB1A
                        EMT                     ;CLRB DID NOT SET Z-BIT
                SOPB1A: INC     (R0)            ;INCREMENT TO TEST WORD
                        BPL     SOPB1B
                        COMB    (R0)            ;COMPLEMENT:  ODD BYTE = 376
                        INCB    (R0)            ;INC:  ODD BYTE = 377
                        BPL     SOPB1B
                        INCB    (R0)            ;INCREMENT ODD BYTE=0
```

```
                        BEQ     TS53
SOPB1B:
                        EMT                     ;CHECK CUMMULATIVE RESULT OF ABOVE INST


;*******************************************************************************************
;
;       THIS TEST VERIFIES THAT SINGLE OPERAND BYTE INSTRUCTIONS WILL
;FUNCTION CORRECTLY FOR ODD BYTES.
;       THIS IS THE FIRST TIME THAT ADDRESS LINE 0 HAS BEEN
;EXERCISED.  CHECKS ARE MADE THAT THE PROPER BYTE IS MODIFIED AND
;THE CONDITION CODES ARE CHECKED.  IT IS ALSO VERIFIED THAT THE UNADDRESSED
;BYTE IS NOT ALTERED BY THE INSTRUCTION.
;
;*******************************************************************************************
;TEST 53        TEST MODE 1 ODD BYTE USING SOP INST
;*******************************************************************************************
TS53:
004336                  CLR     R0              ;INITIALIZE R0
004336  005000          CLR     (R0)            ;INITIALIZE LOC. 0
004340  005010          COM     (R0)
004342  005110          INC     R0              ;R0=ODD BYTE
004344  005200          CLRB    (R0)            ;TRY TO CLEAR BYTE 1
004346  105010          BEQ     SOPB1C
004350  001401          EMT                     ;CLRB DID NOT SET Z-BIT
004352  104000  SOPB1C: DEC     R0              ;R0=WORD ADDR.
004354  005300          INC     (R0)            ;INCREMENT TO TEST WORD
004356  005210          INC     R0              ;R0=ODD BYTE
004360  005200          COMB    (R0)            ;TRY TO COMPLEMENT BYTE 1
004362  105110          INCB    (R0)
004364  105210          BPL     SOPB1D
004366  100002          INCB    (R0)            ;TRY TO INCREMENT BYTE 1
004370  105210          BEQ     TS54
004372  001401  SOPB1D:
004374                  EMT                     ;TEST CUMMULATIVE RESULT OF ABOVE INST.
004374  104000


;*******************************************************************************************
;
;       THIS TEST VERIFIES MODE 2 SINGLE-OPERAND INSTRUCTIONS.  PREVIOUSLY
;TESTED INSTRUCTIONS ARE USED TO SET A POINTER IN R0 TO LOC. 400.
;LOC. 400 IS INITIALIZED TO -1 BEFORE A CLR MODE 2 IS EXECUTED.
;       THEN R0 IS DECREMENTED BY TWO TO AGAIN POINT TO 400 BEFORE EACH
;OF SEVERAL MODE 2 INSTRUCTIONS ARE USED TO VERIFY THE DATA RESULTS OF
;THE TEST.  THIS PROCEDURE ALSO VERIFIES THE PROPER INCREMENTING OF THE
;REGISTER.
;
;*******************************************************************************************
;TEST 54        TEST MODE 2 USING SOP INST.
;*******************************************************************************************
TS54:
004376                  CLR     R0              ;SET R0=400
004376  005000          COMB    R0
004400  105100          INC     R0
004402  005200          CLR     (R0)            ;CLEAR 400
004404  005010          COM     (R0)            ;INITIALIZE: 400=-1
004406  005110          CLR     (R0)+           ;TRY CLEARING WITH MODE 2
004410  005020
```

```
1625  004412  001401                BEQ     SOPZA
1626  004414  104000                EMT                     ;CLR INST DID NOT SET Z-BIT
1627  004416  005300        SOPZA:  DEC     R0              ;RESET R0
1628  004420  005300                DEC     R0
1629  004422  005120                COM     (R0)+           ;TRY COMPLEMENTING WITH MODE 2
1630  004424  100004                BPL     SOP2B
1631  004426  005300                DEC     R0              ;RESET R0
1632  004430  005300                DEC     R0
1633  004432  005220                INC     (R0)+           ;TRY INCREMENTING WITH MODE 2
1634  004434  001401                BEQ     TS55
1635  004436                SOP2B:
1636  004436  104000                EMT                     ;CHECK CUMMULATIVE RESULT OF ABOVE INST
1637
1638                        ;*****************************************************************************
1639                        ;
1640                        ;       THIS TEST VERIFIES MODE 2 SINGLE OPERAND INSTRUCTIONS WHICH
1641                        ;ADDRESS EVEN BYTES.  R0 IS SET TO 400 AND USED TO INITIALIZE LOCATION
1642                        ;400 TO -1.  CLRB INSTRUCTION IS THEN EXECUTED ON BYTE 400 WITH
1643                        ;MODE 2.
1644                        ;       R0 IS THEN DECREMENTED BEFORE EACH OF SEVERAL MODE 2 INSTRUCTIONS
1645                        ;WHICH ARE USED TO VERIFY THE DATA RESULTS OF THE TEST.  THIS PROCEDURE ALSO
1646                        ;VERIFIES THE PROPER INCREMENTING OF THE REGISTER.
1647                        ;
1648                        ;*****************************************************************************
1649                        ;TEST 55        TEST MODE 2 EVEN BYTE USING SOP INST.
1650                        ;*****************************************************************************
1651  004440                TS55:
1652  004440  005000                CLR     R0              ;SET R0=400
1653  004442  105100                COMB    R0
1654  004444  005200                INC     R0
1655  004446  005010                CLR     (R0)            ;CLEAR 400
1656  004450  005110                COM     (R0)            ;INITIALIZE: 400=-1
1657  004452  105020                CLRB    (R0)+           ;TRY TO CLEAT 400 W/MODE 2
1658  004454  001401                BEQ     SOPB2A
1659  004456  104000                EMT                     ;CLR DID NOT SET Z-BIT
1660  004460  005300        SOPB2A: DEC     R0              ;RESULT R0=400
1661  004462  005210                INC     (R0)            ;INC 400 TO TEST WORD
1662  004464  105110                COMB    (R0)
1663  004466  105220                INCB    (R0)+           ;TRY TO INC EVEN BYTE
1664  004470  100003                BPL     SOPB2B
1665  004472  005300                DEC     R0              ;RESET R0=400
1666  004474  105220                INCB    (R0)+           ;TRY INCREMENT OF EVEN BYTE
1667  004476  001401                BEQ     TS56
1668  004500                SOPB2B:
1669  004500  104000                EMT                     ;TEST CUMMULATIVE RESULT OF ABOVE INST.
1670
1671                        ;*****************************************************************************
1672                        ;
1673                        ;       THIS TEST FOLLOWS THE SAME PROCEDURE DESCRIBED IN THE PREVIOUS
1674                        ;TEST.  HERE, THE BYTE INSTRUCTION IS USED TO ADDRESS AN ODD BYTE.
1675                        ;
1676                        ;*****************************************************************************
1677                        ;TEST 56        TEST MODE 2 ODD BYTE USING SOP INST.
1678                        ;*****************************************************************************
1679  004502                TS56:
1680  004502  005000                CLR     R0              ;SET R0=400
```

```
1681  004504  105100                COMB    R0
1682  004506  005200                INC     R0
1683  004510  005010                CLR     (R0)            ;CLEAR LOC 400
1684  004512  005110                COM     (R0)            ;INITIALIZE: 400=-1
1685  004514  005200                INC     R0              ;R0=ODD BYTE
1686  004516  105020                CLRB    (R0)+           ;TRY TO CLEAR ODD BYTE
1687  004520  001401                BEQ     SOPB2C
1688  004522  104000                EMT                     ;CLRB DID NOT SET Z-BIT
1689  004524  005300      SOPB2C:   DEC     R0              ;R0=WORD ADDR.
1690  004526  005300                DEC     R0
1691  004530  005220                INC     (R0)+           ;INCREMENT WORD
1692  004532  005300                DEC     R0              ;POINT TO ODD BYTE
1693  004534  105110                COMB    (R0)            ;COMPLEMENT ODD BYTE
1694  004536  105220                INCB    (R0)+           ;TRY TO INCREMENT ODD BYTE
1695  004540  100003                BPL     SOPB2D
1696  004542  005300                DEC     R0              ;RESET R0 TO ODD BYTE
1697  004544  105220                INCB    (R0)+           ;TRY TO INCREMENT ODD BYTE
1698  004546  001401                BEQ     TS57
1699  004550               SOPB2D:
1700  004550  104000                EMT                     ;TEST CUMMULATIVE RESULT OF ABOVE INST.
1701
1702                      ;*****************************************************************************
1703                      ;
1704                      ;       THESE TESTS CHECK THE NEGATE INSTRUCTION IN ALL MODES.  PREVIOUSLY
1705                      ;TESTED SINGLE-OPERAND INSTRUCTIONS ARE USED TO TEST THE NEGATE INSTRUCTION.
1706                      ;
1707                      ;*****************************************************************************
1708                      ;TEST 57        TEST MODE 0 USING NEGATE INSTRUCTION
1709                      ;*****************************************************************************
1710  004552              TS57:
1711  004552  005000                CLR     R0              ;SET R0=0
1712  004554  005200                INC     R0              ;     R0=1
1713  004556  005400                NEG     R0              ;TRY NEGATE MODE 0:  R0=-1
1714  004560  100003                BPL     NEG00           ;CC=1001?
1715  004562  001402                BEQ     NEG00
1716  004564  102401                BVS     NEG00
1717  004566  103401                BCS     NEG01
1718  004570              NEG00:
1719  004570  104000                EMT                     ;NEGATE DID NOT SET CC'S CORRECTLY
1720
1721  004572  005200      NEG01:    INC     R0              ;TEST DATA RESULT
1722  004574  001401                BEQ     NEG02
1723  004576  104000                EMT                     ;DATA RESULT OF NEGATE INCORRECT
1724
1725  004600  105100      NEG02:    COMB    R0              ;R0=377
1726  004602  105400                NEGB    R0              ;R0=1
1727  004604  100403                BMI     NEG03           ;CC=0001?
1728  004606  001402                BEQ     NEG03
1729  004610  102401                BVS     NEG03
1730  004612  103401                BCS     NEG04
1731  004614              NEG03:
1732  004614  104000                EMT                     ;NEGB DID NOT SET CC'S CORRECTLY
1733  004616  005300      NEG04:    DEC     R0              ;TEST DATA RESULT
1734  004620  001401                BEQ     TS60
1735  004622  104000                EMT                     ;DATA RESULT OF NEGB INCORRECT
1736                      ;*****************************************************************************
```

```
1737                                    ;TEST 60        TEST MODE 1 USING NEGATE INST.
1738                                    ;*****************************************************************************
1739   004624                           TS60:
1740   004624  005000                          CLR     R0              ;POINT TO LOC. 0
1741   004626  005010                          CLR     (R0)            ;CLEAR LOC. 0
1742   004630  005210                          INC     (R0)            ;LOC. 0=1
1743   004632  005410                          NEG     (R0)            ;TRY NEG. LOC. 0=-1
1744   004634  100003                          BPL     NEG10           ;CC=1001
1745   004636  001402                          BEQ     NEG10
1746   004640  102401                          BVS     NEG10
1747   004642  103401                          BCS     NEG11
1748   004644                           NEG10:
1749   004644  104000                          EMT                     ;NEGATE DID NOT SET CC'S CORRECTLY
1750
1751   004646  005237  000000          NEG11:  INC     @#0             ;TEST DATA RESULT
1752   004652  001401                          BEQ     NEG12
1753   004654  104000                          EMT                     ;DATA RESULT OF NEGATE INCORRECT
1754   004656  105110                  NEG12:  COMB    (R0)            ;LOC. 0=377
1755   004660  105410                          NEGB    (R0)            ;TRY NEGB LOC. 0=1
1756   004662  100403                          BMI     NEG13           ;CC=0001?
1757   004664  001402                          BEQ     NEG13
1758   004666  102401                          BVS     NEG13
1759   004670  103401                          BCS     NEG14
1760   004672                           NEG13:
1761   004672  104000                          EMT                     ;NEGB DID NOT SET CC'S CORRECTLY
1762   004674  005337  000000          NEG14:  DEC     @#0             ;TEST DATA RESULT
1763   004700  001401                          BEQ     TS61
1764   004702  104000                          EMT                     ;DATA RESULT OF NEGB INCORRECT
1765                                    ;*****************************************************************************
1766                                    ;TEST 61        TEST MODE 2 USING NEGATE INSTRUCTION
1767                                    ;*****************************************************************************
1768   004704                           TS61:
1769   004704  005000                          CLR     R0              ;POINT TO LOC. 0
1770   004706  005010                          CLR     (R0)            ;CLEAR LOC. 0
1771   004710  005210                          INC     (R0)            ;LOC. 0=1
1772   004712  005420                          NEG     (R0)+           ;TRY NEG.: LOC. 0=-1
1773   004714  100003                          BPL     NEG20           ;CC=1001?
1774   004716  001402                          BEQ     NEG20
1775   004720  102401                          BVS     NEG20
1776   004722  103401                          BCS     NEG21
1777   004724                           NEG20:
1778   004724  104000                          EMT                     ;NEGATE DID NOT SET CC'S CORRECTLY
1779   004726  105300                  NEG21:  DECB    R0              ;R0=LOC. 0
1780   004730  105300                          DECB    R0
1781   004732  105420                          NEGB    (R0)+           ;BYTE 0=1   R0=1
1782   004734  105420                          NEGB    (R0)+           ;BYTE 1=1   R0=2
1783   004736  105340                          DECB    -(R0)           ;R0=1  LOC. 0=01
1784   004740  005300                          DEC     R0              ;R0=0
1785   004742  001401                          BEQ     NEG22
1786   004744  104000                          EMT                     ;REGISTER NOT INCREMENTED CORRECTLY
1787   004746  005337  000000          NEG22:  DEC     @#0             ;LOC. 0=0
1788   004752  001401                          BEQ     TS62
1789   004754  104000                          EMT                     ;NEG BYTE INSTRUCTIONS FAILED
1790
1791                                    ;*****************************************************************************
1792                                    ;
```

```
1793                                    ;       THIS TEST VERIFIES MODE 3 SINGLE OPERAND INSTRUCTIONS.  IT
1794                                    ;USES LOCATION 0 AS ITS TARGET DATA.  A TABLE LOCATED AT LOC. 400
1795                                    ;THRU 402 IS USED TO SUPPLY THE ADDRESS OF LOCATION 0 TO THE
1796                                    ;INSTRUCTIONS UNDER TEST.
1797                                    ;       R0 IS SET TO 400, THE START OF THE ADDRESS TABLE, AND A CLR
1798                                    ;INSTRUCTION IS EXECUTED WITH MODE 3 TO CLEAR LOC. 0.  THEN R0
1799                                    ;IS DECREMENTED BY TWO AND TWO OTHER MODE 3 INSTRUCTIONS OPERATE ON
1800                                    ;LOC. 0 TO VERIFY THE DATA RESULTS OF THE TEST.  THE PROPER INCREMENTING
1801                                    ;OF THE REGISTER IS ALSO VERIFIED IN THIS MANNER.
1802                                    ;       IF A FAILURE IS DETECTED BE SURE TO VERIFY THAT THE TABLE
1803                                    ;(LOC. 400-402) HAS THE PROPER VALUES (0).
1804                                    ;
1805                                    ;*****************************************************************************
1806                                    ;TEST 62        TEST MODE 3 USING SOP INST.
1807                                    ;*****************************************************************************
1808  004756                            TS62:
1809  004756  005000                           CLR     R0              ;SET R0=400
1810  004760  105100                           COMB    R0
1811  004762  005200                           INC     R0
1812  004764  005010                           CLR     (R0)            ;CLEAR LOC 400
1813  004766  005030                           CLR     @(R0)+          ;TRY TO CLEAR LOC 0 USING MODE 3 ;R0=402
1814  004770  001401                           BEQ     SOP3A
1815  004772  104000                           EMT                     ;CLR DID NOT SET Z-BIT
1816  004774  005300                   SOP3A:  DEC     R0              ;RESET R0=400
1817  004776  005300                           DEC     R0
1818  005000  005130                           COM     @(R0)+          ;TRY TO COMPLEMENT LOC 0 OF MODE 3  ;R0=402
1819  005002  100002                           BPL     SOP3B
1820  005004  005230                           INC     @(R0)+          ;TRY TO INCREMENT LOC 0 W/MODE 3  ;R0=404
1821  005006  001401                           BEQ     TS63
1822  005010                           SOP3B:
1823  005010  104000                           EMT                     ;CUMMULATIVE RESULT OF ABOVE INST FAILED
1824
1825                                    ;*****************************************************************************
1826                                    ;
1827                                    ;       THIS TEST VERIFIES MODE 3 SINGLE OPERAND BYTE INSTRUCTIONS
1828                                    ;WHICH ADDRESS EVEN BYTES.  AGAIN, THE TARGET LOCATION 0 IS USED
1829                                    ;AND THE SAME TABLE AT 400 IS EMPLOYED.
1830                                    ;       AFTER POINTING R4 TO THE TABLE (400) AND SETTING LOCATION
1831                                    ;0 TO -1, A CLRB INSTRUCTION IS USED TO CLEAR BYTE 0.
1832                                    ;       SEVERAL OTHER MODE 3 INSTRUCTIONS ARE THEN USED WITH THE TABLE
1833                                    ;TO VERIFY THE DATA RESULTS AND THE PROPER INCREMENTING OF THE REGISTER.
1834                                    ;IF A FAILURE IS DETECTED, BE SURE THAT THE TABLE (LOCATION 400-402) HAS
1835                                    ;THE PROPER VALUES (0).
1836                                    ;
1837                                    ;*****************************************************************************
1838                                    ;TEST 63        TEST MODE 3 EVEN BYTE USING SOP INST.
1839                                    ;*****************************************************************************
1840  005012                            TS63:
1841  005012  005004                           CLR     R4              ;SET R4=400
1842  005014  105104                           COMB    R4
1843  005016  005204                           INC     R4
1844  005020  005000                           CLR     R0              ;INITIALIZE LOC. 0=-1
1845  005022  005010                           CLR     (R0)
1846  005024  005110                           COM     (R0)            ;LOC. 0=-1
1847  005026  105034                           CLRB    @(R4)+          ;TRY TO CLEAR EVEN BYTE ;LOC. 0=177400  R4=402
1848  005030  001401                           BEQ     SOPB3A
```

```
 1849  005032  104000                 EMT                     ;CLRB DID NOT SET Z-BIT
 1850  005034  005304 SOPB3A:  DEC     R4                      ;RESET POINTER  R4=400
 1851  005036  005304          DEC     R4
 1852  005040  005234          INC     @(R4)+                  ;TRY INCREMENTING WORD  LOC.0=177401  R4=402
 1853  005042  100006          BPL     SOPB3B
 1854  005044  105434          NEGB    @(R4)+                  ;TRY TO NEGATE EVEN BYTE ;LOC.0=-1 R4=404
 1855  005046  100004          BPL     SOPB3B
 1856  005050  005304          DEC     R4                      ;R4=402
 1857  005052  005304          DEC     R4
 1858  005054  105234          INCB    @(R4)+                  ;TRY TO INCREMENT EVEN BYTE ;LOC. 0=17400
 1859  005056  001401          BEQ     TS64
 1860  005060             SOPB3B:
 1861  005060  104000          EMT                             ;CUMMULATIVE RESULT OF ABOVE INST FAILED
 1862
 1863                     ;*****************************************************************************
 1864                     ;
 1865                     ;       THIS TEST VERIFIES MODE 3 SINGLE OPERAND BYTE INSTRUCTIONS
 1866                     ;WHICH ADDRESS ODD BYTES.  THE TARGET IS BYTE 1.  A TABLE AT
 1867                     ;LOC. 400-406 IS USED.  R0 SERVES AS THE TABLE POINTER.
 1868                     ;       R0 IS INITIALIZED TO 400.  LOC. 0 IS SET TO -1 USING THE
 1869                     ;FIRST TWO TABLE ENTRIES.  A CLRB MODE 3 IS EXECUTED ON BYTE 1 USING
 1870                     ;TABLE ADDRESS AT 404.  R0 IS DECREMENTED TO 402 AND SEVERAL SOP
 1871                     ;MODE 3 INSTRUCTIONS ARE USED TO VERIFY DATA RESULTS AND PROPER
 1872                     ;REGISTER INCREMENTING.
 1873                     ;       THE TABLE (400-406) SHOULD CONTAIN 0,0,1,1 BEFORE AND
 1874                     ;AFTER THE TEST IS RUN.
 1875                     ;
 1876                     ;*****************************************************************************
 1877                     ;TEST 64        TEST MODE 3 ODD BYTE USING SOP INST.
 1878                     ;*****************************************************************************
 1879  005062             TS64:
 1880  005062  005000          CLR     R0                      ;SET R0=400
 1881  005064  105100          COMB    R0
 1882  005066  005200          INC     R0
 1883  005070  005030          CLR     @(R0)+                  ;INITIALIZE
 1884  005072  005130          COM     @(R0)+                  ;LOC 0=-1 R0=404
 1885  005074  105030          CLRB    @(R0)+                  ;TRY TO CLEAR ODD BYTE LOC. 0=377 R0=406
 1886  005076  001401          BEQ     SOPB3C
 1887  005100  104000          EMT                             ;CLRB DID NOT SET Z-BIT
 1888  005102  005300 SOPB3C:  DEC     R0                      ;RESET R0=402
 1889  005104  005300          DEC     R0
 1890  005106  005300          DEC     R0                      ;POINT TO EVEN BYTE ADDR.
 1891  005110  005300          DEC     R0
 1892  005112  005230          INC     @(R0)+                  ;INCREMENT WORD LOC. 0=400 R0=404
 1893  005114  105430          NEGB    @(R0)+                  ;TRY TO NEGATE ODD BYTE LOC. 0=177400 R0=406
 1894  005116  100002          BPL     SOPB3D
 1895  005120  105230          INCB    @(R0)+                  ;TRY TO INCREMENT ODD BYTE LOC.0=0 R0=410
 1896  005122  001401          BEQ     TS65
 1897  005124             SOPB3D:
 1898  005124  104000          EMT                             ;CUMMULATIVE RESULT OF ABOVE INSTS FAILED
 1899                     ;*****************************************************************************
 1900                     ;TEST 65        TEST MODE 3 USING NEGATE INSTRUCTION
 1901                     ;*****************************************************************************
 1902  005126             TS65:
 1903  005126  005000          CLR     R0                      ;R0=400
 1904  005130  105100          COMB    R0
```

```
1905  005132  005200                  INC     R0
1906  005134  005010                  CLR     (R0)            ;LOC. 400=0
1907  005136  005004                  CLR     R4              ;R4=0
1908  005140  005014                  CLR     (R4)            ;LOC. 0=0
1909  005142  005214                  INC     (R4)            ;LOC. 0=1
1910  005144  005430                  NEG     @(R0)+          ;TRY NEGATE   LOC. 0=-1  R0=402
1911  005146  100003                  BPL     NEG30           ;CC=1001?
1912  005150  001402                  BEQ     NEG30
1913  005152  102401                  BVS     NEG30
1914  005154  103401                  BCS     NEG31
1915  005156                  NEG30:
1916  005156  104000                  EMT                     ;NEG DID NOT SET CC'S CORRECTLY
1917  005160  005214          NEG31:  INC     (R4)            ;LOC. 0=0
1918  005162  001401                  BEQ     NEG32
1919  005164  104000                  EMT                     ;DATA RESULT OF NEG INCORRECT
1920  005166  105137  000001  NEG32:  COMB    @#1             ;LOC 0=177400
1921  005172  005237  000000          INC     @#0             ;LOC. 0=177401
1922  005176  105430                  NEGB    @(R0)+          ;TRY NEGB LOC. 0=177777  R0=404
1923  005200  100401                  BMI     NEG33
1924  005202  104000                  EMT                     ;NEGB FAILED WITH EVEN BYTE
1925  005204  105430          NEG33:  NEGB    @(R0)+          ;TRY NEGB  LOC.0=777  R0=406
1926  005206  100001                  BPL     NEG34
1927  005210  104000                  EMT                     ;NEGB FAILED WITH ODD BYTE
1928  005212  105137  000001  NEG34:  COMB    @#1             ;LOC. 0=177377
1929  005216  105237  000001          INCB    @#1             ;LOC. 0=177777
1930  005222  005214                  INC     (R4)            ;LOC. 0=0
1931  005224  001401                  BEQ     TS66
1932  005226  104000                  EMT                     ;DATA RESULT OF NEGB'S INCORRECT
1933
1934          ;*****************************************************************************************
1935          ;
1936          ;       THIS TEST VERIFIES MODE 4 SINGLE OPERAND INSTRUCTIONS.
1937          ;R0 IS SET TO 400. A CLR INSTRUCTION IS EXECUTED IN MODE 4 TO CLEAR
1938          ;LOC. 376. R0 IS RESET TO 400 AND A COM INSTRUCTION USING MODE 4
1939          ;COMPLEMENTS LOC.376.
1940          ;       TWO INC INSTRUCTIONS AND A MODE 4 INSTRUCTION ARE EXECUTED
1941          ;TO COMPLETE THE TEST.
1942          ;*****************************************************************************************
1943          ;TEST 66        TEST MODE 4 USING SOP INSTS
1944          ;*****************************************************************************************
1945  005230  TS66:
1946  005230  005000                  CLR     R0              ;SET R0=400
1947  005232  105100                  COMB    R0
1948  005234  005200                  INC     R0
1949  005236  005040                  CLR     -(R0)           ;TRY TO CLEAR USING MODE 4
1950  005240  001401                  BEQ     SOP4A
1951  005242  104000                  EMT                     ;CLR DID NOT SET Z-BIT
1952  005244  005200          SOP4A:  INC     R0              ;RESET R0
1953  005246  005200                  INC     R0
1954  005250  005140                  COM     -(R0)           ;TRY TO COMPLEMENT USING MODE 4
1955  005252  100004                  BPL     SOP4B
1956  005254  005200                  INC     R0              ;MOVE POINTER
1957  005256  005200                  INC     R0
1958  005260  005240                  INC     -(R0)
1959  005262  001401                  BEQ     TS67
1960  005264                  SOP4B:
```

```
1961  005264  104000                  EMT                     ;CHECK CUMMULATIVE RESULT OF ABOVE INST.
1962
1963                                  ;*************************************************************************************
1964                                  ;
1965                                  ;       THIS TEST VERIFIES MODE 5 SINGLE OPERAND INSTRUCTIONS.  IT
1966                                  ;USES LOCATION 0 AS ITS TARGET DATA.  A TABLE LOCATED AT LOC. 372
1967                                  ;THRU 374 IS USED TO SUPPLY THE ADDRESS OF LOCATION 0 TO THE
1968                                  ;INSTRUCTIONS UNDER TEST.
1969                                  ;       R0 IS SET TO 376, (THE START OF THE ADDRESS TABLE) +2,
1970                                  ;AND A CLR INSTRUCTION IS EXECUTED WITH MODE 3 TO CLEAR
1971                                  ;LOC. 0.  THEN R0 IS INCREMENTED BY TWO AND TWO OTHER MODE 3
1972                                  ;INSTRUCTIONS OPERATE ON LOC. 0 TO VERIFY THE DATA RESULTS OF
1973                                  ;THE TEST.  THE PROPER DECREMENTING OF THE REGISTER IS ALSO
1974                                  ;VERIFIED IN THIS MANNER.
1975                                  ;       IF A FAILURE IS DETECTED BE SURE TO VERIFY THAT THE TABLE
1976                                  ;(LOC. 372 THRU 374) HAS THE PROPER VALUES (0).
1977                                  ;
1978                                  ;*************************************************************************************
1979                                  ;TEST 67        TEST MODE 5 USING SOP INSTS
1980                                  ;*************************************************************************************
1981  005266                          TS67:
1982  005266  012700  000370                 MOV     #370,R0         ;CLEAR LOCATION 370-376
1983  005272  005020                          CLR     (R0)+           ;370
1984  005274  005020                          CLR     (R0)+           ;372
1985  005276  005020                          CLR     (R0)+           ;374
1986  005300  005010                          CLR     (R0)            ;376
1987  005302  005000                          CLR     R0              ;SET R0=376 (LOW BYTE)
1988  005304  005020                          CLR     (R0)+
1989  005306  105400                          NEGB    R0
1990  005310  005050                          CLR     @-(R0)          ;TRY TO CLEAR LOC 0 W/MODE 5
1991  005312  001401                          BEQ     SOP5A
1992  005314  104000                          EMT                     ;CLR DID NOT SET Z-BIT
1993  005316  005200                  SOP5A:  INC     R0              ;RESET R0
1994  005320  005200                          INC     R0
1995  005322  005150                          COM     @-(R0)          ;TRY TO COMPLEMENT LOC. 0 W/MODE 5
1996  005324  100002                          BPL     SOP5B
1997  005326  005250                          INC     @-(R0)          ;TRY TO INCREMENT LOC. 0 W/MODE 5
1998  005330  001401                          BEQ     TS70
1999  005332                          SOP5B:
2000  005332  104000                          EMT                     ;TEST CUMMULATIVE RESULT OF ABOVE INSTS
2001
2002                                  ;*************************************************************************************
2003                                  ;
2004                                  ;       THIS TEST VERIFIES MODE 6 SINGLE OPERAND INSTRUCTIONS.  IT
2005                                  ;USES LOCATION 0 AS ITS TARGET DATA.  R0 IS SET TO 400 USING
2006                                  ;PREVIOUSLY TESTED INSTRUCTIONS AND A MODE 6 CLR INSTRUCTION IS
2007                                  ;EXECUTED ON LOC. 0 USING R0 AND A -400 OFFSET.  COM AND INC
2008                                  ;INSTRUCTIONS ARE THEN USED TO VERIFY THE DATA.
2009                                  ;
2010                                  ;*************************************************************************************
2011                                  ;TEST 70        TEST MODE 6 USING SOP INSTS
2012                                  ;*************************************************************************************
2013  005334                          TS70:
2014  005334  005000                          CLR     R0              ;SET R0=400
2015  005336  105100                          COMB    R0
2016  005340  005200                          INC     R0
```

```
2017  005342  005060  177400          CLR     -400(R0)        ;TRY TO CLEAR LOCATION 0 W/MODE 6
2018  005346  001401                  BEQ     SOP6A
2019  005350  104000                  EMT                     ;CLR DID NOT SET Z-BIT
2020  005352  005160  177400  SOP6A:  COM     -400(R0)        ;TRY TO COMPLEMENT LOCATION 0 W/MODE 6
2021  005356  100003                  BPL     SOP6B
2022  005360  005260  177400          INC     -400(R0)        ;TRY TO INCREMENT LOCATION 0 W/MODE 6
2023  005364  001401                  BEQ     TS71
2024  005366                  SOP6B:
2025  005366  104000                  EMT                     ;TEST CUMMULATIVE RESULT OF ABOVE INSTS
2026
2027                          ;*****************************************************************************
2028                          ;
2029                          ;       THIS TEST VERIFIES MODE 7 SINGLE OPERAND INSTRUCTIONS.  IT USES
2030                          ;THE POINTER TO LOC. 0 WHICH IS STORED AT LOC. 402.
2031                          ;       R0 IS SET TO 400 AND A MODE 7 CLR INSTRUCTION IS
2032                          ;EXECUTED WITH A +2 OFFSET TO CLEAR LOC. 0.
2033                          ;       SEVERAL OTHER MODE 7 INSTRUCTIONS ARE THEN USED ON THE COMMON
2034                          ;LOCATION TO VERIFY THE DATA RESULTS.
2035                          ;
2036                          ;*****************************************************************************
2037                          ;TEST 71        TEST MODE 7 USING SOP INST.
2038                          ;*****************************************************************************
2039  005370                  TS71:
2040  005370  005000                  CLR     R0              ;SET R0=400
2041  005372  105100                  COMB    R0
2042  005374  005200                  INC     R0
2043  005376  005210                  INC     (R0)            ;R0=1
2044  005400  005070  000002          CLR     @2(R0)          ;TRY TO CLEAR LOC. 0 W/MODE 7
2045  005404  001401                  BEQ     SOP7A
2046  005406  104000                  EMT                     ;CLR DID NOT SET Z-BIT
2047  005410  005170  000002  SOP7A:  COM     @2(R0)          ;TRY TO COMPLEMENT LOC. 0 W/MODE 7
2048  005414  100003                  BPL     SOP7B
2049  005416  005270  000002          INC     @2(R0)          ;TRY TO INCREMENT LOC. 0 W/MODE 7
2050  005422  001401                  BEQ     TS72
2051  005424                  SOP7B:
2052  005424  104000                  EMT                     ;TEST CUMMULATIVE RESULT OF ABOVE INSTS.
2053
2054                          ;*****************************************************************************
2055                          ;TEST 72        TEST MODE 4 WITH NEGATE INSTRUCTION
2056                          ;*****************************************************************************
2057  005426                  TS72:
2058  005426  005000                  CLR     R0
2059  005430  005010                  CLR     (R0)
2060  005432  005120                  COM     (R0)+           ;LOC. 0=177777,  R0=2
2061  005434  005440                  NEG     -(R0)           ;TRY NEGATE, LOC. 0=1
2062  005436  100403                  BMI     NEG40           ;CC=0001?
2063  005440  001402                  BEQ     NEG40
2064  005442  102401                  BVS     NEG40
2065  005444  103401                  BCS     NEG41
2066  005446                  NEG40:
2067  005446  104000                  EMT                     ;NEG DID NOT SET CC'S CORRECTLY
2068  005450  005400          NEG41:  NEG     R0              ;TST R0 WITH A NEG.
2069  005452  001401                  BEQ     NEG42
2070  005454  104000                  EMT                     ;R0 NOT DECREMENTED PROPERLY
2071  005456  005310          NEG42:  DEC     (R0)            ;TEST DTA RESULT OF NEG
2072  005460  001401                  BEQ     TS73
```

```
2073  005462  104000                  EMT                     ;DATA RESULT OF NEG INCORRECT
2074                          ;*************************************************************************
2075                          ;TEST 73        TEST MODE 5 WITH NEGATE INSTRUCTION
2076                          ;*************************************************************************
2077  005464                  TS73:
2078  005464  005000                  CLR     R0              ;R0=0
2079  005466  005010                  CLR     (R0)            ;LOC. 0=0
2080  005470  105100                  COMB    R0              ;R0=377
2081  005472  005200                  INC     R0              ;R0=400
2082  005474  005010                  CLR     (R0)            ;SET 400 = 0
2083  005476  005004                  CLR     R4              ;R4=0
2084  005500  005314                  DEC     (R4)            ;LOC. 0=177777
2085  005502  005450                  NEG     @-(R0)          ;TRY NEGATE:  LOC. 0=1
2086  005504  100403                  BMI     NEG50           ;CC=0001?
2087  005506  001402                  BEQ     NEG50
2088  005510  102401                  BVS     NEG50
2089  005512  103401                  BCS     NEG51
2090  005514                  NEG50:
2091  005514  104000                  EMT                     ;NEG DID NOT SET CC'S CORRECTLY
2092  005516  005314          NEG51:  DEC     (R4)
2093  005520  001401                  BEQ     NEG52
2094  005522  104000                  EMT                     ;DATA RESULT OF NEG INCORRECT
2095  005524  105100          NEG52:  COMB    R0
2096  005526  005300                  DEC     R0
2097  005530  001401                  BEQ     TS74
2098  005532  104000                  EMT                     ;REGISTER NOT DECREMENTED PROPERLY
2099                          ;*************************************************************************
2100                          ;TEST 74        TEST MODE 6 WITH NEGATE
2101                          ;*************************************************************************
2102  005534                  TS74:
2103  005534  005000                  CLR     R0              ;R0=0
2104  005536  005004                  CLR     R4              ;R4=0
2105  005540  105100                  COMB    R0              ;R0=377
2106  005542  005014                  CLR     (R4)            ;LOC. 0=0
2107  005544  105024                  CLRB    (R4)+           ;LOC. 0=177777,  R4=1
2108  005546  105114                  COMB    (R4)            ;LOC. 0=177400
2109  005550  005460  177401          NEG     -377(R0)        ;LOC. 0=400
2110  005554  100403                  BMI     NEG60           ;CC=0001
2111  005556  001402                  BEQ     NEG60
2112  005560  102401                  BVS     NEG60
2113  005562  103401                  BCS     NEG61
2114  005564                  NEG60:
2115  005564  104000                  EMT                     ;NEG DID NOT SET CC'S CORRECTLY
2116  005566  105314          NEG61:  DECB    (R4)
2117  005570  001401                  BEQ     TS75
2118  005572  104000                  EMT                     ;DATA RESULT OF NEG INCORRECT
2119                          ;*************************************************************************
2120                          ;TEST 75        TEST MODE 7 W/ NEGATE
2121                          ;*************************************************************************
2122  005574                  TS75:
2123  005574  005000                  CLR     R0              ;R0=0
2124  005576  005010                  CLR     (R0)            ;LOC. 0=0
2125  005600  005110                  COM     (R0)            ;LOC. 0=177777
2126  005602  105100                  COMB    R0              ;R0=377
2127  005604  105470  000005          NEGB    @5(R0)          ;R0+5=404,  404=1,  LOC. 0=777
2128  005610  100403                  BMI     NEG70           ;CC=0001?
```

```
2129  005612  001402                  BEQ     NEG70
2130  005614  102401                  BVS     NEG70
2131  005616  103401                  BCS     NEG71
2132  005620                  NEG70:
2133  005620  104000                  EMT                     ;NEG DID NOT SET CC'S CORRECTLY
2134  005622  105100          NEG71:  COMB    R0              ;R0=0
2135  005624  105120                  COMB    (R0)+           ;LOC. 0=400,  R0=1
2136  005626  105310                  DECB    (R0)            ;LOC. 0=0
2137  005630  005467  172144          NEG     0               ;USE NEG MODE 67 TO TST FOR ZERO
2138  005634  001401                  BEQ     TS76
2139  005636  104000                  EMT                     ;DATA RESULT OF NEG WAS INCORRECT
2140
2141                                  ;*******************************************************************************
2142                                  ;
2143                                  ;       THIS TEST VERIFIES PROGRAM COUNTER ADDRESSING WITH SOP
2144                                  ;INSTRUCTIONS.  CLR MODE 77 IS USED TO CLEAR THE LOCATION FOLLOWING THE
2145                                  ;INSTRUCTION (SOPX).  THEN SINGLE OPERAND INSTRUCTIONS WITH MODES 37, 67, AND
2146                                  ;77, USING INDIRECT POINTER SOPXAD ARE USED TO VERIFY THE DATA RESULTS
2147                                  ;OF THESE INSTRUCTIONS.
2148                                  ;
2149                                  ;*******************************************************************************
2150                                  ;TEST 76        TEST SOP INSTRUCTIONS MODES 2,3,6,7 WITH REGISTER 7
2151                                  ;*******************************************************************************
2152  005640                  TS76:
2153  005640  005027                  CLR     (R7)+           ;CLEAR NEXT LOCATION: (SOPX)
2154  005642  177777          SOPX:   -1                      ;USE MODE 27
2155  005644  001401                  BEQ     SOPA
2156  005646  104000                  EMT                     ;CLR DID NOT SET Z-BIT
2157  005650  005237  005642  SOPA:   INC     @#SOPX          ;INC SOPX W/MODE 37
2158  005654  005467  177762          NEG     SOPX            ;NEGATE SOPX W/MODE 67
2159  005660  100003                  BPL     SOPB
2160  005662  005277  000004          INC     @SOPXAD         ;INC SOPX W/MODE 77
2161  005666  001402                  BEQ     TS77
2162  005670                  SOPB:
2163  005670  104000                  EMT                     ;INC DID NOT SET Z-BIT
2164  005672  005642          SOPXAD: SOPX                    ;INDIRECT ADDRESS OF SOPX
2165
2166                                  ;*******************************************************************************
2167                                  ;
2168                                  ;       THIS TEST VERIFIES SINGLE OPERAND NON-MODIFYING INSTRUCTIONS
2169                                  ;USING MODE 0.  R0 IS SET TO ZERO AND THE CONDITION CODES ARE SET
2170                                  ;TO THE COMPLEMENT OF THAT EXPECTED BY THE INSTRUCTION.  A TST INSTRUCTION
2171                                  ;IS EXECUTED AND CONDITIONAL BRANCHES ARE USED TO TEST THE CONDITION
2172                                  ;CODES.
2173                                  ;
2174                                  ;*******************************************************************************
2175                                  ;TEST 77        TEST MODE 0 SOP NON-MODIFYING
2176                                  ;*******************************************************************************
2177  005674                  TS77:
2178  005674  005000                  CLR     R0              ;INITIALIZE R0=0
2179  005676  000277                  SCC                     ;SET CC=1011
2180  005700  000244                  CLZ
2181  005702  005700                  TST     R0              ;TRY TST W/ MODE 0
2182  005704  102403                  BVS     SNM0A           ;CHECK THAT CC=0100
2183  005706  100402                  BMI     SNM0A
2184  005710  103401                  BCS     SNM0A
```

```
                        BEQ     TS100
                SNM0A:
                        EMT                     ;CONDITION CODES NOT SET PROPERLY

                ;*******************************************************************************
                ;
                ;       THIS TEST VERIFIES SINGLE OPERAND NON-MODIFYING BYTE INSTRUCTIONS WITH MODE 0.
                ;R0 IS SET TO 377 AND COMPLEMENT OF THE EXPECTED CONDITION CODES
                ;IS LOADED IN PSW.  A TSTB INSTRUCTION IS EXECUTED AND THE RESULTS
                ;ARE CHECKED WITH SEVERAL CONDITIONAL BRANCH INSTRUCTIONS.
                ;       THIS VERIFIES THAT THE PROPER BYTE WAS TESTED.
                ;
                ;*******************************************************************************
                ;TEST 100       TEST MODE 0 EVEN BYTE W/ SOP NON-MODIFYING
                ;*******************************************************************************
                TS100:
005716                  CLR     R0              ;INITIALIZE
005716  005000          COMB    R0              ;R0=377
005720  105100          SCC                     ;SET CC=0111
005722  000277          CLN
005724  000250          TSTB    R0              ;TRY TST EVEN BYTE
005726  105700          BVS     SNMB0A          ;CHECK CC=1000
005730  102402          BLOS    SNMB0A
005732  101401          BMI     TS101
005734  100401  SNMB0A:
005736                  EMT                     ;CONDITION CODES NOT SET PROPERLY
005736  104000
                ;*******************************************************************************
                ;
                ;       THIS TEST VERIFIES SINGLE OPERAND INSTRUCTIONS WITH MODE 1.
                ;R0 IS USED TO POINT TO AND CLEAR LOC. 0.  THE COMPLEMENT OF THE
                ;EXPECTED CONDITION CODES ARE LOADED IN THE PSW.  A TST INSTRUCTION
                ;IS THEN EXECUTED ON LOC. 0 USING R0 AND CONDITIONAL BRANCHES TEST
                ;THE RESULTS.
                ;
                ;*******************************************************************************
                ;TEST 101       TEST MODE 1 SOP NON-MODIFYING
                ;*******************************************************************************
                TS101:
005740                  CLR     R0              ;POINT TO LOC 0
005740  005000          CLR     (R0)            ;CLEAR LOC 0
005742  005010          SCC                     ;INITIALIZE
005744  000277          CLZ                     ;CC=1011
005746  000244          TST     (R0)            ;TRY TST W/ MODE 1
005750  005710          BVS     SNM1A           ;CHECK CC=0100
005752  102403          BCS     SNM1A
005754  103402          BMI     SNM1A
005756  100401          BEQ     TS102
005760  001401  SNM1A:
005762                  EMT                     ;CC'S NOT SET PROPERLY
005762  104000
                ;*******************************************************************************
                ;
                ;       THIS TEST SETS LOCATION 0 TO 377 AND THEN USES R0 TO TEST
                ;THE EVEN BYTE AND THE ODD BYTE USING SOP BYTE INSTRUCTIONS WITH MODE 1.
                ;AGAIN, CONDITIONAL BRANCHES ARE USED TO VERIFY THE SETTING OF THE
```

```
                                ;PROPER CONDITION CODE BITS.
                                ;
                                ;*****************************************************************************
                                ;TEST 102       TEST MODE 1 BYTE INST. NON-MODIFYING
                                ;*****************************************************************************
005764                          TS102:
005764  005000                          CLR     R0              ;POINT TO LOC 0
005766  005010                          CLR     (R0)            ;CLEAR LOC 0
005770  105110                          COMB    (R0)            ;COMPLEMENT BYTE 0
005772  000277                          SCC                     ;SET CC=0111
005774  000250                          CLN
005776  105710                          TSTB    (R0)            ;TRY TST ON EVEN BYTE
006000  102402                          BVS     SNMB1A
006002  101401                          BLOS    SNMB1A
006004  100401                          BMI     SNMB1B
006006                          SNMB1A:
006006  104000                          EMT                     ;CC'S NOT CORRECT
006010  005000                  SNMB1B: CLR     R0
006012  005200                          INC     R0
006014  000277                          SCC                     ;SET CC=1011
006016  000244                          CLZ
006020  105710                          TSTB    (R0)            ;TRY TO TST AN ODD BYTE
006022  102403                          BVS     SNMB1C          ;CHECK CC=0100
006024  103402                          BCS     SNMB1C
006026  100401                          BMI     SNMB1C
006030  001401                          BEQ     TS103
006032                          SNMB1C:
006032  104000                          EMT                     ;CC'S NOT CORRECT

                                ;*****************************************************************************
                                ;
                                ;       THIS TEST VERIFIES THE SINGLE-OPERAND NON-MODIFYING INSTRUCTIONS
                                ;USING MODE 2.  IT USES THE IDENTICAL PROCEDURE EMPLOYED IN THE
                                ;MODE 1 TESTS.  ADDITIONALLY, THE REGISTER IS CHECKED TO ASSURE THAT
                                ;IT IS INCREMENTED PROPERLY.
                                ;
                                ;*****************************************************************************
                                ;TEST 103       TEST MODE 2 WITH SOP NON-MODIFYING
                                ;*****************************************************************************
006034                          TS103:
006034  005000                          CLR     R0              ;INITIALIZE R0=0
006036  005010                          CLR     (R0)            ;CLEAR LOC 0
006040  000277                          SCC                     ;SET CC=1011
006042  000244                          CLZ
006044  005720                          TST     (R0)+           ;TRY TST W/ MODE 2
006046  102403                          BVS     SNM2A           ;CHECK CC=0100
006050  103402                          BCS     SNM2A
006052  100401                          BMI     SNM2A
006054  001401                          BEQ     SNM2B
00605C                          SNM2A:
006056  104000                          EMT                     ;CC'S NOT CORRECT
006060  005300                  SNM2B:  DEC     R0              ;RESET R0
006062  005300                          DEC     R0
006064  001401                          BEQ     TS104
006066  104000                          EMT                     ;MODE 2 DID NOT INC REG CORRECTLY
```

```
                                ;*****************************************************************************
                                ;
                                ;       THIS TEST VERIFIES MODE 2 SINGLE OPERAND NON-MODIFYING BYTE
                                ;INSTRUCTIONS IT USES R0 TO POINT TO LOC. 0.  WITH LOCATION 0
                                ;SET TO 377, THE EVEN AND ODD BYTE IS TESTED WITH TSTB INSTRUCTIONS
                                ;TO VERIFY THE CORRECT CC ARE SET.  THE REGISTER IS CHECKED FOR
                                ;PROPER INCREMENTING.
                                ;
                                ;*****************************************************************************
                                ;TEST 104        TEST MODE 2 - BYTE W/ SOP NON-MODIFYING
                                ;*****************************************************************************
006070                          TS104:
006070  005000                          CLR     R0              ;CLEAR R0
006072  005010                          CLR     (R0)            ;CLEAR LOC 0
006074  105110                          COMB    (R0)            ;SET LOC 0=377
006076  000277                          SCC                     ;SET CC=0111
006100  000250                          CLN
006102  105720                          TSTB    (R0)+           ;TRY TST OF EVEN BYTE
006104  102402                          BVS     SNMB2A
006106  101401                          BLOS    SNMB2A
006110  100401                          BMI     SNMB2B
006112                          SNMB2A:
006112  104000                          EMT                     ;CC'S NOT SET CORRECTLY
006114  005300                  SNMB2B: DEC     R0              ;DECREMENT R0
006116  001401                          BEQ     SNMB2C
006120  104000                          EMT                     ;MODE 2 DID NOT INC REG CORRECTLY
006122  005200                  SNMB2C: INC     R0              ;POINT TO ODD BYTE
006124  000277                          SCC                     ;SET CC=1011
006126  000244                          CLZ
006130  105720                          TSTB    (R0)+           ;TRY TST OF ODD BYTE
006132  102403                          BVS     SNMB2D          ;CHECK CC'S=0100
006134  103402                          BCS     SNMB2D
006136  100401                          BMI     SNMB2D
006140  001401                          BEQ     SNMB2E
006142                          SNMB2D:
006142  104000                          EMT                     ;CC'S NOT CORRECT
006144  005300                  SNMB2E: DEC     R0
006146  005300                          DEC     R0
006150  001401                          BEQ     TS105
006152  104000                          EMT                     ;R0 DID NOT INCREMENT PROPERLY

                                ;*****************************************************************************
                                ;
                                ;       THIS TEST VERIFIES MODE 3 SINGLE OPERAND NON-MODIFYING INSTRUCTIONS.
                                ;A POINTER IN A TABLE AT LOC. 376 IS USED TO TEST LOCATION 0.
                                ;THE CC'S AND THE REGISTER ARE CHECKED FOLLOWING THE
                                ;TST MODE 3 INSTRUCTION.
                                ;
                                ;*****************************************************************************
                                ;TEST 105        TEST MODE 3 W/ SOP NON-MODIFYING INSTS
                                ;*****************************************************************************
006154                          TS105:
006154  005000                          CLR     R0              ;R0=0
006156  005010                          CLR     (R0)            ;CLEAR LOC 0
006160  105100                          COMB    R0              ;R0=376
006162  005300                          DEC     R0
```

```
                        SCC                     ;SET CC=1011
                        CLZ
                        TST     @(R0)+          ;TRY TST W/ MODE 3
                        BVS     SNM3A           ;CHECK CC=0100
                        BCS     SNM3A
                        BMI     SNM3A
                        BEQ     SNM3B
                SNM3A:
                        EMT                     ;CC'S NOT CORRECT
                SNM3B:  DEC     R0              ;R0=377
                        COMB    R0              ;R0=0
                        BEQ     TS106
                        EMT                     ;MODE 3 DID NOT INC REG CORRECTLY

                ;*******************************************************************************
                ;
                ;       THIS TEST VERIFIES SOP NON-MODIFYING BYTE INSTRUCTIONS MODE 3
                ;LOC. 0 IS SET TO 377.  TABLE AT LOC. 402-404 IS USED TO TEST
                ;BYTE 0 AND BYTE 1.  THE REGISTER IS CHECKED FOR PROPER INCREMENTING AND
                ;THE CC'S ARE VERIFIED.
                ;       THE TABLE AT LOC. 402-404 SHOULD CONTAIN 0 AND 1 BEFORE AND
                ;AFTER THE TEST IS RUN.
                ;
                ;*******************************************************************************
                ;TEST 106       TEST MODE 3 - BYTES W/ SOP NON-MODIFYING INSTS.
                ;*******************************************************************************
006214          TS106:
006214  005000          CLR     R0              ;R0=0
006216  005010          CLR     (R0)            ;CLEAR LOC 0
006220  105110          COMB    (R0)            ;LOC. 0 =377
006222  105100          COMB    R0
006224  005200          INC     R0
006226  005720          TST     (R0)+           ;R0=402
006230  000277          SCC                     ;CC=0111
006232  000250          CLN
006234  105730          TSTB    @(R0)+          ;TRY TST OF EVEN BYTE
006236  102402          BVS     SNMB3A          ;CHECK CC=1000
006240  101401          BLOS    SNMB3A
006242  100401          BMI     SNMB3B
006244          SNMB3A:
006244  104000          EMT                     ;CC'S NOT CORRECT
006246  000277  SNMB3B: SCC                     ;SET CC=1011
006250  000244          CLZ
006252  105730          TSTB    @(R0)+          ;TRY TST OF ODD BYTE
006254  102403          BVS     SNMB3C          ;CHECK CC=0100
006256  103402          BCS     SNMB3C
006260  100401          BMI     SNMB3C
006262  001401          BEQ     SNMB3D
006264          SNMB3C:
006264  104000          EMT                     ;CC'S NOT CORRECT
006266  005720  SNMB3D: TST     (R0)+           ;R0=410
006270  005710          TST     (R0)
006272  100401          BMI     TS107
006274  104000          EMT                     ;TSTB DID NOT INCREMENT R0 CORRETCLY
                ;*******************************************************************************
                ;
```

```
                        ;       THIS TEST VERIFIES MODE 4 SOP NON-MODIFYING INSTRUCTIONS.
                        ;LOC. 0 IS SET TO -1 AND THE CC'S ARE SET TO THE COMPLEMENT OF THE
                        ;EXPECTED RESULTS.  R0 AND SET TO 2 AND A TST MODE 4 IS EXECUTED.
                        ;THE CC'S ARE CHECKED WITH CONDITIONAL BRANCH INSTRUCTIONS AND THE REGISTER
                        ;IS CHECKED FOR PROPER DECREMENTING.
                        ;
                        ;*****************************************************************************
                        ;TEST 107       TEST MODE 4 W/ SOP NON-MODIFYING INSTS
                        ;*****************************************************************************
006276                  TS107:
006276  005000                  CLR     R0              ;R0=0
006300  005010                  CLR     (R0)            ;LOC 0=0
006302  005120                  COM     (R0)+           ;LOC 0=-1
006304  000277                  SCC                     ;SET CC=1011
006306  000244                  CLZ
006310  005740                  TST     -(R0)           ;TRY TST W/ MODE 4
006312  102402                  BVS     SNM4A           ;CHECK CC=0100
006314  101401                  BLOS    SNM4A
006316  100401                  BMI     SNM4B
006320                  SNM4A:
006320  104000                  EMT                     ;CC'S NOT CORRECT
006322  005700          SNM4B:  TST     R0
006324  001401                  BEQ     TS110
006326  104000                  EMT                     ;TST MODE 4 DID NOT DEC R0 CORRECTLY
                        ;*****************************************************************************
                        ;
                        ;       THIS TEST VERIFIES MODE 5 SOP NON-MODIFYING INSTRUCTIONS.
                        ;IT USES A POINTER AT LOC. 376 TO TEST LOC. 0.  R0 IS SET
                        ;TO 400, A TST MODE 5 INSTRUCTION IS EXECUTED AND THE CC'S CHECKED.
                        ;R0 IS CHECKED TO INSURE PROPER DECREMENTING.
                        ;
                        ;*****************************************************************************
                        ;TEST 110       TEST MODE 5 W/ SOP NON-MODIFYING INSTS
                        ;*****************************************************************************
006330                  TS110:
006330  005000                  CLR     R0              ;R0=0
006332  005010                  CLR     (R0)            ;LOC 0=0
006334  005110                  COM     (R0)            ;LOC 0=-1
006336  105100                  COMB    R0              ;R0=377
006340  005200                  INC     R0              ;R0=400
006342  000277                  SCC                     ;SET CC=0111
006344  000250                  CLN
006346  005750                  TST     @-(R0)          ;TRY TST W/ MODE 5
006350  102402                  BVS     SNM5A           ;CHECK CC=1000
006352  101401                  BLOS    SNM5A
006354  100401                  BMI     SNM5B
006356                  SNM5A:
006356  104000                  EMT                     ;CC'S NOT SET PROPERLY
006360  005200          SNM5B:  INC     R0              ;R0=377
006362  105100                  COMB    R0              ;R0=0
006364  001401                  BEQ     TS111
006366  104000                  EMT                     ;MODE 5 DID NOT DEC R0 CORRECTLY
                        ;*****************************************************************************
                        ;
```

```
                                        ;       THIS TEST VERIFIES MODE 6 SOP NON-MODIFYING INSTRUCTIONS.
                                        ;R0 IS SET TO 377 AND A MODE 6 TST INSTRUCTION IS EXECUTED
                                        ;USING R0 AND AN OFFSET OF -377.  THE CC'S ARE CHECKED AS WELL
                                        ;AS R0 TO INSURE IT WAS NOT ALTERED.
                                        ;
                                        ;*****************************************************************************
                                        ;TEST 111       TEST MODE 6 W/ SOP NON-MODIFYING INSTS
                                        ;*****************************************************************************
006370                                  TS111:
006370  005000                                  CLR     R0              ;R0=0
006372  005010                                  CLR     (R0)            ;LOC 0=0
006374  005110                                  COM     (R0)            ;LOC 0=-1
006376  105100                                  COMB    R0              ;R0=377
006400  000277                                  SCC                     ;SET CC=0111
006402  000250                                  CLN
006404  005760  177401                          TST     -377(R0)        ;TRY TST W/ MODE 6
006410  102402                                  BVS     SNM6A           ;CHECK CC=1000
006412  101401                                  BLOS    SNM6A
006414  100401                                  BMI     SNM6B
006416                                  SNM6A:
006416  104000                                  EMT                     ;CC'S INCORRECT
006420  105100                          SNM6B:  COMB    R0              ;R0=0
006422  001401                                  BEQ     TS112
006424  104000                                  EMT                     ;TST MODE 6 INCORRECTLY CHANGED R0
```

```
                        ;*****************************************************************************
                        ;
                        ;       THIS TEST VERIFIES MODE 7 SOP NON-MODIFYING INSTRUCTIONS.
                        ;IT USES A POINTER TO LOC. 0 STORED AT LOC. 400 TO TST LOC. 0.
                        ;R0 IS SET TO 377 AND LOC. 0 IS TESTED THRU THE POINTER AT 400 USING
                        ;R0 AND AN OFFSET OF 1.
                        ;
                        ;*****************************************************************************
                        ;TEST 112       TEST MODE 7 W/ SOP NON-MODIFYING INSTS.
                        ;*****************************************************************************
006426                  TS112:
006426  005000                  CLR     R0              ;R0=0
006430  005010                  CLR     (R0)            ;LOC 0=0
006432  005110                  COM     (R0)            ;LOC 0=-1
006434  105100                  COMB    R0              ;R0=377
006436  000277                  SCC                     ;CC=0111
006440  000250                  CLN
006442  005770  000001          TST     @1(R0)          ;TRY TST W/ MODE 7
006446  102402                  BVS     SNM7A           ;CHECK CC=1000
006450  101401                  BLOS    SNM7A
006452  100401                  BMI     SNM7B
006454                  SNM7A:
006454  104000                  EMT                     ;CC'S NOT CORRECT
006456  105100          SNM7B:  COMB    R0              ;R0=0
006460  001401                  BEQ     TS113
006462  104000                  EMT                     ;TST MODE 7 INCORRECTLY CHANGED R0

                        ;*****************************************************************************
                        ;
                        ;       THIS TEST VERIFIES MODE 0 DOUBLE OPERAND INSTRUCTIONS.  IT SETS
                        ;DATA IN R0 AND R4 AND USES THE ADD INSTRUCTION TO TEST THE DOP
                        ;MICROCODE.
                        ;
                        ;*****************************************************************************
                        ;TEST 113       TEST MODE 0 DOUBLE-OPERAND (DOP) INSTS.
                        ;*****************************************************************************
006464                  TS113:
006464  005000                  CLR     R0              ;R0=0
006466  005100                  COM     R0              ;R0=-1
006470  005004                  CLR     R4              ;R4=0
006472  060004                  ADD     R0,R4           ;TRY ADD: R4=-1
006474  005204                  INC     R4              ;R4=0
006476  001401                  BEQ     TS114
006500  104000                  EMT                     ;ADD INST. FAILED W/ MODE 0

                        ;*****************************************************************************
                        ;
                        ;       THIS TEST VERIFIES THE MOVE INSTRUCTION WITH MODE 0 TO MODE 0.
                        ;
                        ;*****************************************************************************
                        ;TEST 114       MOV MODE 0 TO MODE 0
                        ;*****************************************************************************
006502                  TS114:
006502  005000                  CLR     R0              ;R0=0
006504  005004                  CLR     R4              ;R4=0
```

```
                        COM     R0              ;R0=-1
                        MOV     R0,R4           ;TRY MOVE -1 TO R4
                        INC     R4              ;INC R4
                        BEQ     TS115
                        EMT                     ;MOVE FAILED MODE 0 TO MODE 0

;*******************************************************************************
;
;       THIS TEST VERIFIES THE SUBTRACT INSTRUCTION WITH MODE 0,0.
;
;*******************************************************************************
;TEST 115       TEST SUB MODE 0,0
;*******************************************************************************
TS115:
                        CLR     R0              ;R0=0
                        CLR     R4              ;R4=0
                        INC     R4              ;R4=1
                        SUB     R4,R0           ;TRY SUB 0,0   R0=-1
                        BPL     SUB0            ;CC=1001
                        BEQ     SUB0
                        BVS     SUB0
                        BCS     SUB0A
SUB0:
                        EMT                     ;CONDITION CODE FAILED ON SUB
SUB0A:  INC     R0
                        BEQ     TS116
                        EMT                     ;DATA RESULT OF SUB FAILED

;*******************************************************************************
;
;       THIS TEST QUICKLY VERIFIES THE REMAINING DOP MODIFYING INSTRUCTIONS
;WITH MODE 0,0 TO PROVIDE A BASELINE FOR SUBSEQUENT TESTS.
;SINGLE OPERAND INSTRUCTIONS ARE USED TO SET UP DATA IN R0 AND R4
;BEFORE EACH OF THE SEVERAL DOP MODIFYING INSTRUCTIONS ARE USED AND
;VERIFIED.
;
;*******************************************************************************
;TEST 116       TEST ALL THE DOP INSTRUCTIONS W/ SOURCE MODE 0,0
;*******************************************************************************
TS116:
                        CLR     R0              ;R0=0
                        MOV     R0,R4           ;TRY MOVE MODE 0,0
                        BEQ     DOP0A
                        EMT                     ;Z-BIT NOT SET
DOP0A:  INC     R0              ;R0=1
                        COM     R0              ;R0=177776
                        COM     R4              ;R4=177777
                        BIC     R0,R4           ;TRY BIC: R4=1
                        DEC     R4              ;R4=0
                        BEQ     DOP0B
                        EMT                     ;BIC CLEAR RESULT INCORRECT
DOP0B:  BIS     R0,R4           ;TRY BIS: R4=177777
                        INC     R4
                        INC     R4              ;R4=0
                        BEQ     DOP0C
                        EMT                     ;RESULT OF BIS INCORRECT
```

```
 2601  006610  005000                DOP0C:  CLR     R0              ;R0=0
 2602  006612  105100                        COMB    R0              ;R0=377
 2603  006614  005004                        CLR     R4              ;R4=0
 2604  006616  005104                        COM     R4              ;R4=177777
 2605  006620  040004                        BIC     R0,R4           ;R4=177400
 2606  006622  060004                        ADD     R0,R4           ;TRY ADD: R4=177777
 2607  006624  005204                        INC     R4              ;R4=0
 2608  006626  001401                        BEQ     DOP0D
 2609  006630  104000                        EMT                     ;RESULT OF ADD INCORRECT
 2610  006632  160004                DOP0D:  SUB     R0,R4           ;177401=R4
 2611  006634  105404                        NEGB    R4              ;R4=177777
 2612  006636  005204                        INC     R4              ;RD=0
 2613  006640  001401                        BEQ     TS117
 2614  006642  104000                        EMT                     ;RESULT OF SUB INCORRECT
 2615
 2616                                ;*******************************************************************************
 2617                                ;
 2618                                ;       THIS TEST VERIFIES MODE 0,X DOUBLE OPERAND INSTRUCTIONS.  IT SETS
 2619                                ;DATA IN R0 AND LOCATION 0 AND OPERATES UPON IT USING DOP INSTRUCTIONS.
 2620                                ;
 2621                                ;*******************************************************************************
 2622                                ;TEST 117       TEST MODE 0,X DOUBLE-OPERAND INSTRUCTIONS
 2623                                ;*******************************************************************************
 2624  006644                        TS117:
 2625  006644  005000                        CLR     R0              ;R0=0
 2626  006646  005010                        CLR     (R0)            ;LOC. 0=0
 2627  006650  105110                        COMB    (R0)            ;LOC. 0=377
 2628  006652  005220                        INC     (R0)+           ;LOC. 0=400   R0=2
 2629  006654  005400                        NEG     R0              ;R0=-2
 2630  006656  060037  000000                ADD     R0,@#0          ;TRY ADD 0,3;  LOC. 0=376
 2631  006662  100403                        BMI     DOP03A          ;CC=0001?
 2632  006664  001402                        BEQ     DOP03A
 2633  006666  102401                        BVS     DOP03A
 2634  006670  103401                        BCS     DOP03B
 2635  006672                        DOP03A:
 2636  006672  104000                        EMT                     ;CC'S NOT SET CORRECTLY
 2637  006674  105137  000000        DOP03B: COMB    @#0             ;LOC. 0=1
 2638  006700  005337  000000                DEC     @#0             ;LOC. 0=0
 2639  006704  001401                        BEQ     TS120
 2640  006706  104000                        EMT                     ;DATA RESULT INCORRECT
 2641                                ;*******************************************************************************
 2642                                ;
 2643                                ;       THIS TEST VERIFIES MODE 0,0 DOP NON-MODIFYING INSTRUCTIONS.
 2644                                ;R0 AND R4 ARE PRESET TO 0 AND 1 RESPECTIVELY.  COMPARE INSTRUCTIONS ARE
 2645                                ;THEN EXECUTED AND CHECKED.  FIRST R4 IS COMPARED TO R0 THEN R0 TO R4.
 2646                                ;
 2647                                ;*******************************************************************************
 2648                                ;TEST 120       TEST DOP NON-MODIFYING INST. W/ SOURCE MODE 0,0
 2649                                ;*******************************************************************************
 2650  006710                        TS120:
 2651  006710  005000                        CLR     R0              ;R0=0
 2652  006712  005004                        CLR     R4              ;R4=0
 2653  006714  005204                        INC     R4              ;R4=1
 2654  006716  020400                        CMP     R4,R0           ;TRY COMPARE R4 TO R0
 2655  006720  003001                        BGT     DNM1
 2656  006722  104000                        EMT                     ;CC'S NOT CORRECT FOR CMP
```

```
                                DNM1:   CMP     R0,R4           ;TRY COMPARE R0 TO R4
                                        BLT     DNM2
                                        EMT                     ;CC'S NOT CORRECT FOR CMP
                                DNM2:   INC     R0              ;R0=1
                                        CMP     R4,R0           ;TRY COMPARE R4=1 TO R0=1
                                        BEQ     DNM3
                                        EMT                     ;CC'S NOT CORRECT (Z=1) FOR CMP
                                DNM3:   CLR     R0              ;R0=0
                                        COM     R0              ;R0=177777
                                        CLR     R4              ;R4=0
                                        BIT     R0,R4           ;TRY BIT R0 TO R4
                                        BEQ     DNM4
                                        EMT                     ;CC'S NOT CORRECT FOR BIT
                                DNM4:   DEC     R4              ;R4=177777
                                        BIT     R0,R4           ;TRY BIT AGAIN
                                        BMI     TS121
                                        EMT                     ;CC'S NOT CORRECT FOR BIT
                                ;*******************************************************************************
                                ;
                                ;       THIS TEST VERIFIES MODE 0,X DOUBLE OPERAND NON-MODIFYING INSTRUCTIONS.
                                ;IT SETS DATA IN R0 AND LOCATION 0 AND COMPARES THEM USING DOPNM INSTRUCTIONS.
                                ;
                                ;*******************************************************************************
                                ;TEST 121       TEST MODE 0,X DOUBLE-OPERAND NON-MODIFYING INSTS.
                                ;*******************************************************************************
006766                          TS121:
006766  005000                          CLR     R0              ;R0=0
006770  005010                          CLR     (R0)            ;LOC. 0=0
006772  005110                          COM     (R0)            ;LOC. 0=177777
006774  005200                          INC     R0              ;R0=1
006776  020037  000000                  CMP     R0,@#0          ;TRY CMP MODE 0,3
007002  100403                          BMI     DNM03A          ;CC=0001
007004  001402                          BEQ     DNM03A
007006  102401                          BVS     DNM03A
007010  103401                          BCS     DNM03B
007012                          DNM03A:
007012  104000                          EMT                     ;CC'S NOT SET CORRECTLY
007014  005300                  DNM03B: DEC     R0
007016  001002                          BNE     DNM03C
007020  005210                          INC     (R0)
007022  001401                          BEQ     TS122
007024                          DNM03C:
007024  104000                          EMT                     ;DATA INCORRECTLY MODIFIED BY CMP
                                ;*******************************************************************************
                                ;
                                ;       THIS TEST VERIFIES MODE 1 DOP INSTRUCTIONS.  R0 IS SET TO -1
                                ;AND LOC 0 TO 1.  R4 IS THEN CLEARED AND USED TO POINT TO LOC 0.
                                ;IN THE ADD MODE 1 INSTRUCTION, LOC 0 IS ADDED TO R0 AND THE
                                ;RESULTS VERIFIED.
                                ;
                                ;*******************************************************************************
                                ;TEST 122       TEST MODE 1 W/ DOP INST.
                                ;*******************************************************************************
007026                          TS122:
007026  005000                          CLR     R0              ;R0=0
007030  005100                          COM     R0              ;R0=177777
```

```
2713  007032  005004                CLR     R4              ;R4=0
2714  007034  005014                CLR     (R4)            ;LOC 0=0
2715  007036  005214                INC     (R4)            ;LOC 0=1
2716  007040  061400                ADD     (R4),R0         ;TRY ADD SOURCE MODE 1
2717  007042  001401                BEQ     TS123
2718  007044  104000                EMT                     ;RESULT OF ADD INCORRECT
2719
2720                        ;*****************************************************************************
2721                        ;
2722                        ;       THIS TEST VERIFIES MODE 1 DOP BYTE INSTRUCTIONS WHICH ADDRESS
2723                        ;EVEN BYTES.  LOC. 0 IS SET TO -1 AND R4 IS CLEARED.  THEN R4 IS
2724                        ;SET TO -1 USING A BISB THRU R0 WITH MODE 1.
2725                        ;
2726                        ;*****************************************************************************
2727                        ;TEST 123       TEST MODE 1 - EVEN BYTE W/ DOP INSTS.
2728                        ;*****************************************************************************
2729  007046                TS123:
2730  007046  005000                CLR     R0              ;R0=0
2731  007050  005010                CLR     (R0)            ;LOC. 0=0
2732  007052  005110                COM     (R0)            ;LOC. 0=177777
2733  007054  005004                CLR     R4              ;R4=0
2734  007056  151004                BISB    (R0),R4         ;TRY MODE 1- EVEN BYTE W/ DOP
2735  007060  105104                COMB    R4              ;R4=0
2736  007062  001401                BEQ     TS124
2737  007064  104000                EMT                     ;RESULT OF BISB IS INCORRECT
2738
2739                        ;*****************************************************************************
2740                        ;
2741                        ;       THIS TEST VERIFIES MODE 1 DOP NON-MODIFYING INSTRUCTIONS
2742                        ;WHICH ADDRESS EVEN BYTES.  LOC. 0 IS SET TO -1 AND R0 IS CLEARED
2743                        ;AND USED AS THE ADDRESSING REGISTER.  R4 IS SET TO 377 AND A
2744                        ;MODE 1,0 CMPB INSTRUCTION IS USED THE RESULTS VERIFIED.
2745                        ;
2746                        ;*****************************************************************************
2747                        ;TEST 124       TEST MODE 1 - EVEN BYTE W/ DOP NON-MODIFYING INST.
2748                        ;*****************************************************************************
2749  007066                TS124:
2750  007066  005000                CLR     R0              ;R0=0
2751  007070  005010                CLR     (R0)            ;LOC 0=0
2752  007072  005110                COM     (R0)            ;LOC 0=177777
2753  007074  005004                CLR     R4              ;R4=0
2754  007076  105104                COMB    R4              ;R4=377
2755  007100  121004                CMPB    (R0),R4         ;TRY MODE 1 - EVEN BYTE W/ DOP NON-MODIFYING
2756  007102  001401                BEQ     TS125
2757  007104  104000                EMT                     ;RESULT OF CMPB INCORRECT
2758
2759                        ;*****************************************************************************
2760                        ;
2761                        ;       THIS TEST VERIFIES MODE 1,0 MOVB INSTRUCTIONS
2762                        ;WHICH ADDRESS EVEN BYTES.  LOC. 0 IS SET TO 177400, R0 IS CLEARED AND
2763                        ;R4 IS SET TO -1.  MOVB ARE USED TO MOVE BYTE 0 TO R4.  THIS
2764                        ;VERIFIES THAT THE PROPER BYTE WAS SELECTED AND THAT THE SIGN-X-TEND
2765                        ;FUNCTION WITH MODE 0.
2766                        ;       THEN LOC. 0 IS COMPLEMENTED AND THE SAME PROCEDURE EXERCISES
2767                        ;THE LOGIC FOR COMPLEMENTARY DATA.
2768                        ;       THIS TEST EXERCISES UNIQUE MICROCODE.
```

```
                                ;
                                ;*******************************************************************************
                                ;TEST 125       TEST MOV INSTRUCTION MODE 1,0 EVEN BYTE
                                ;*******************************************************************************
007106                          TS125:
007106  005000                          CLR     R0              ;R0=0
007110  005010                          CLR     (R0)            ;LOC 0=0
007112  105110                          COMB    (R0)            ;LOC 0=177400
007114  005110                          COM     (R0)
007116  005004                          CLR     R4              ;R4=0
007120  005104                          COM     R4              ;R4=177777
007122  111004                          MOVB    (R0),R4         ;R4=0
007124  005704                          TST     R4              ;CHECK SIGN OF WORD
007126  001401                          BEQ     DOP1
007130  104000                          EMT                     ;MOVB SHOULD SIGN X-TEND
007132  005110                  DOP1:   COM     (R0)            ;LOC 0=177777
007134  111004                          MOVB    (R0),R4         ;DO MOVB W/ EVEN BYTE
007136  100401                          BMI     TS126
007140  104000                          EMT                     ;MOVB SHOULD SIGN X-TEND
                                ;
                                ;*******************************************************************************
                                ;
                                ;       THIS TEST VERIFIES MODE 1 DOP INSTRUCTIONS WHICH REFERENCE
                                ;ODD BYTES.  LOC. 0 IS SET TO 177400.  R0 IS SET TO 0 AND R4 IS
                                ;SET TO 1.  THE BISB INSTRUCTION USES THE DATA IN BYTE 1 TO SET BYTE 0.
                                ;THE RESULT IS CHECKED BY INCREMENTING THE WORD (LOC. 0) TO ZERO.
                                ;
                                ;*******************************************************************************
                                ;TEST 126       TEST MODE 1-ODD BYTE W/ DOP INSTS.
                                ;*******************************************************************************
007142                          TS126:
007142  005000                          CLR     R0              ;R0=0
007144  005010                          CLR     (R0)            ;LOC. 0=0
007146  005004                          CLR     R4              ;R4=0
007150  005204                          INC     R4              ;R4=1
007152  105114                          COMB    (R4)            ;LOC. 0=177400
007154  151410                          BISB    (R4),(R0)       ;TRY TO BIS LOW ORDER BITS W/ MODE 1
007156  005210                          INC     (R0)            ;CHECK RESULT
007160  001401                          BEQ     TS127
007162  104000                          EMT                     ;RESULT OF BISB INCORRECT
                                ;
                                ;*******************************************************************************
                                ;
                                ;       THIS TEST VERIFIES MODE 2 DOP INSTRUCTIONS.  LOC. 0 IS SET TO -1.
                                ;R0 IS CLEARED AND USED AS THE MODE 2 ADDRESSING REGISTER TO MOVE LOC. 0
                                ;TO R7.  THE DATA RESULTS ARE VERIFIED AND THE INCREMENTING OF THE REGISTER
                                ;IS CHECKED.
                                ;
                                ;*******************************************************************************
                                ;TEST 127       TEST MODE 2 W/ DOP INSTS.
                                ;*******************************************************************************
007164                          TS127:
007164  005000                          CLR     R0              ;R0=0
007166  005010                          CLR     (R0)            ;LOC. 0=0
007170  005110                          COM     (R0)            ;LOC. 0=177777
007172  012004                          MOV     (R0)+,R4        ;TRY MOVE MODE 2,0
```

```
2825  007174  005204                  INC     R4              ;CHECK R4
2826  007176  001401                  BEQ     DOP2
2827  007200  104000                  EMT                     ;RESULT OF MOV INST INCORRECT
2828  007202  005300          DOP2:   DEC     R0              ;TEST R0 AFTER MODE 2
2829  007204  005300                  DEC     R0
2830  007206  001401                  BEQ     TS130
2831  007210  104000                  EMT                     ;REGISTER NOT INCREMENTED IN MODE 2
2832
2833                          ;*****************************************************************************
2834                          ;
2835                          ;       THIS TEST VERIFIES MODE 2 DOP BYTE INSTRUCTIONS WHICH ADDRESS
2836                          ;EVEN BYTES.  LOC. 0 IS SET TO -1.  R0 IS CLEARED AND USED AS THE
2837                          ;ADDRESSING REGISTER IN A TEST WHICH TRIES TO CLEAR BYTE 1 USING
2838                          ;BYTE 0 DATA AND A BICB.  UNIQUE IN THIS TEST IS USE OF THE
2839                          ;SAME ADDRESSING REGISTER FOR BOTH SOURCE AND DESTINATION.  THE SOURCE AND
2840                          ;DESTINATION IS CHECKED TO INSURE PROPER FUNCTIONING.
2841                          ;
2842                          ;*****************************************************************************
2843                          ;TEST 130       TEST MODE 2 - EVEN BYTE W/ DOP INST.
2844                          ;*****************************************************************************
2845  007212                  TS130:
2846  007212  005000                  CLR     R0              ;R0=0
2847  007214  010010                  MOV     R0,(R0)         ;LOC. 0=0
2848  007216  005110                  COM     (R0)            ;LOC. 0=177777
2849  007220  142010                  BICB    (R0)+,(R0)      ;TRY TO CLEAR BYTE 1 FROM BYTE 0 W/ BICB
2850  007222  105737  000001          TSTB    @#1             ;CHECK RESULT
2851  007226  001401                  BEQ     DOPB2A
2852  007230  104000                  EMT                     ;BICB DESTINATION INCORRECT
2853  007232  105137  000000  DOPB2A: COMB    @#0             ;CHECK BICB SOURCE
2854  007236  001401                  BEQ     TS131
2855  007240  104000                  EMT                     ;BICB SOURCE INCORRECTLY CHANGED
2856                          ;*****************************************************************************
2857                          ;
2858                          ;       THIS TEST VERIFIES MODE 2 DOP BYTE INSTRUCTIONS WHICH RFFERENCE
2859                          ;ODD BYTES.  R0 IS SET TO 1, LOC. 0 IS SET TO 177400, AND R4 IS CLEARED.
2860                          ;A MODE 2 MOVB USES R0 TO MOVE BYTE 1 TO R4.  AN INCREMENT
2861                          ;IS USED TO CHECK THAT THE PROPER BYTE WAS MOVED AND SIGN X-TENDED.
2862                          ;
2863                          ;*****************************************************************************
2864                          ;TEST 131       TEST MODE 2 - ODD BYTE W/ DOP INST.
2865                          ;*****************************************************************************
2866  007242                  TS131:
2867  007242  005000                  CLR     R0              ;R0=0
2868  007244  005004                  CLR     R4              ;R4=0
2869  007246  005010                  CLR     (R0)            ;LOC. 0=0
2870  007250  005110                  COM     (R0)            ;LOC. 0=177777
2871  007252  105120                  COMB    (R0)+           ;LOC 0=177400; R0=1
2872  007254  112004                  MOVB    (R0)+,R4        ;TRY DOP MODE 2 W/ ODD BYTE
2873  007256  005204                  INC     R4              ;CHECK RESULT OF MOVB
2874  007260  001401                  BEQ     DOPB2B
2875  007262  104000                  EMT                     ;RESULT OF MOVB INCORRECT
2876  007264  005740          DOPB2B: TST     -(R0)           ;BUMP R0 DOWN BY 2
2877  007266  005700                  TST     R0              ;CHECK R0
2878  007270  001401                  BEQ     TS132
2879  007272  104000                  EMT                     ;MODE 2 BYTE DID NOT INCREMENT REG. CORRECTLY
2880                          ;*****************************************************************************
```

```
                                ;
                                ;       THIS TEST VERIFIES MODE 3 DOUBLE-OPERAND INSTRUCTIONS.
                                ;LOC. 0 IS LOADED WITH ALTERNATING ZEROES AND ONES; AND R0 IS LOADED
                                ;WITH ALTERNATING ONES AND ZEROES.  A MODE 3 BIS IS USED TO SET R0
                                ;TO -1 BY USING LOC. 0 AS THE SOURCE TO BIS THE ZEROES IN R0.  THE
                                ;RESULT IS TESTED BY INCREMENTING R0 AND CHECKING FOR ZERO.
                                ;
                                ;*****************************************************************************
                                ;TEST 132       TEST MODE 3 W/ DOP INSTS.
                                ;*****************************************************************************
007274                          TS132:
007274  012737  052525  000000          MOV     #052525,@#0     ;MOVE 52525 TO LOC. 0
007302  012700  125252                  MOV     #125252,R0      ;SET ALT. ONE AND ZERO IN R0
007306  053700  000000                  BIS     @#0,R0          ;TRY TO SET ALL OTHER BITS W/ MODE 3
007312  005200                          INC     R0              ;TEST RESULT
007314  001401                          BEQ     TS133
007316  104000                          EMT                     ;BIS W/ MODE 3 INCORRECT RESULT
                                ;*****************************************************************************
                                ;
                                ;       THIS TEST VERIFIES MODE 3 DOUBLE OPERAND BYTE INSTRUCTIONS WHICH
                                ;ADDRESS EVEN BYTES.  BYTE 0 IS SET TO ALTERNATING 1'S AND 0'S; BYTE 1,
                                ;ALTERNATING 0'S AND 1'S.  R0 IS CLEARED AND A BISB IS USED TO
                                ;SET THE LOW BYTE OF R0 TO 252.
                                ;
                                ;*****************************************************************************
                                ;TEST 133       TEST MODE 3 - EVEN BYTE W/ DOP INSTS.
                                ;*****************************************************************************
007320                          TS133:
007320  012737  052652  000000          MOV     #52652,@#0      ;NOVE 1'S AND 0' PATTERN TO LOC. 0
007326  005000                          CLR     R0              ;R0=0
007330  153700  000000                  BISB    @#0,R0          ;TRY R0=252 W/ MODE 3 - EVEN BYTE
007334  022700  000252                  CMP     #252,R0         ;BISB W/ EVEN BYTE SUCCESSFUL?
007340  001401                          BEQ     TS134
007342  104000                          EMT                     ;BISB W/ MODE 3 - EVEN BYTE FAILED
                                ;*****************************************************************************
                                ;
                                ;       THIS TEST VERIFIES MODE 3 DOUBLE OPERAND BYTE INSTRUCTIONS
                                ;WHICH ADDRESS ODD BYTES.  THE SAME PROCEDURE USED IN PREVIOUS
                                ;TEST IS USED HERE.  THIS TIME BYTE 1 IS USED AS THE SOURCE BYTE.
                                ;THE EXPECTED RESULT IS:  R0 = 125.
                                ;
                                ;*****************************************************************************
                                ;TEST 134       TEST MODE 3 - ODD BYTE W/ DOP INSTS.
                                ;*****************************************************************************
007344                          TS134:
007344  012737  052652  000000          MOV     #52652,@#0      ;MOVE 1'S AND 0'S PATTERN TO LOC 0
007352  005000                          CLR     R0              ;R0=0
007354  153700  000001                  BISB    @#1,R0          ;TRY R0=152 W/ MODE 3 - ODD BYTE
007360  022700  000125                  CMP     #125,R0         ;R0=125?
007364  001401                          BEQ     TS135
007366  104000                          EMT                     ;BISB W/ MODE 3 - ODD BYTE FAILED

                                ;*****************************************************************************
                                ;TEST 135       TEST DEST. MODE 0-BYTE W/ DOP NON-MODIFYING MST
                                ;*****************************************************************************
007370                          TS135:
```

```
2937  007370  005000                  CLR     R0              ;R0=0
2938  007372  105100                  COMB    R0              ;R0=377
2939  007374  000263                  +SEC!SEV                ;SET C AND V BITS
2940  007376  132700  000200          BITB    #200,R0         ;TRY DOPNM DEST. MODE 0-BYTE
2941  007402  001403                  BEQ     DNMB0A          ;BR TO ERROR IF Z BIT SET
2942  007404  102402                  BVS     DNMB0A          ;BR TO ERROR IF V BIT SET
2943  007406  103001                  BCC     DNMB0A          ;BR TO ERROR IF C BIT CLEAR.
2944  007410  100401                  BMI     DNMB0B
2945  007412                  DNMB0A:
2946  007412  104000                  EMT                     ;CC'S INCORRECT
2947  007414  105100          DNMB0B: COMB    R0              ;CHECK DESTINATION DATA
2948  007416  001401                  BEQ     TS136
2949  007420  104000                  EMT                     ;DEST. DATA MODIFIED
2950
2951                          ;*****************************************************************************************
2952                          ;TEST 136       TEST DEST. MODE 1 W/ DOP NON-MODIFYING INST
2953                          ;*****************************************************************************************
2954  007422                  TS136:
2955  007422  005000                  CLR     R0              ;R0=0
2956  007424  005010                  CLR     (R0)            ;LOC. 0=0
2957  007426  000241                  CLC                     ;CLEAR C BIT
2958  007430  032710  177777          BIT     #177777,(R0)    ;TRY DOPNM DEST. MODE 1
2959  007434  100403                  BMI     DNM1A           ;BR TO ERROR IF N BIT SET
2960  007436  102402                  BVS     DNM1A           ;BR TO ERROR IF V BIT SET
2961  007440  103401                  BCS     DNM1A           ;BR TO ERROR IF C BIT SET
2962  007442  001401                  BEQ     DNM1B
2963  007444                  DNM1A:
2964  007444  104000                  EMT                     ;COND. CODES INCORRECT
2965  007446  005710          DNM1B:  TST     (R0)            ;CHECK TEST DATA
2966  007450  001401                  BEQ     TS137
2967  007452  104000                  EMT                     ;DESTINATION DATA MODIFIED
2968
2969                          ;*****************************************************************************************
2970                          ;TEST 137       TEST DEST, MODE 2 W/ DOP NON-MODIFYING INST.
2971                          ;*****************************************************************************************
2972  007454                  TS137:
2973  007454  005000                  CLR     R0              ;R0=0
2974  007456  005010                  CLR     (R0)            ;LOC. 0=0
2975  007460  052710  125252          BIS     #125252,(R0)    ;LOC. 0=125252
2976  007464  032720  077777          BIT     #77777,(R0)+    ;TRY DOPNM INST W/ MODE 2
2977  007470  102402                  BVS     DNM2A           ;BR TO ERROR IF V BIT SET
2978  007472  001401                  BEQ     DNM2A           ;BR TO ERROR IF Z-BIT SET
2979  007474  100001                  BPL     DNM2B
2980  007476                  DNM2A:
2981  007476  104000                  EMT                     ;COND. CODES INCORRECT
2982  007500  005300          DNM2B:  DEC     R0              ;DECREMENT R0 TO CHECK IT.
2983  007502  005300                  DEC     R0
2984  007504  001401                  BEQ     DNM2D
2985  007506                  DNM2C:
2986  007506  104000                  EMT                     ;MODE 2 REGISTER NOT INCREMENTED BY 2
2987  007510  022710  125252  DNM2D:  CMP     #125252,(R0)    ;CHECK DEST. DATA
2988  007514  001401                  BEQ     TS140
2989  007516  104000                  EMT                     ;DEST. DATA MODIFIED
2990
2991                          ;*****************************************************************************************
2992                          ;TEST 140       TEST DEST. MODE 2-BYTE, W/DOP NON-MODIFYING INST
```

```
 2993
 2994  007520
 2995  007520  005000                  TS140:
 2996  007522  005010                          CLR     R0                  ;R0=0
 2997  007524  052710  052652                  CLR     (R0)                ;LOC. 0=0
 2998  007530  000263                          BIS     #52652,(R0)         ;LOC. 0=52652
 2999  007532  132720  000201                  +SEC!SEV                    ;SET C AND V BITS
 3000  007536  001403                          BITB    #201,(R0)+          ;TRY DOPNM INST. W/ MODE 2 EVEN BYTE
 3001  007540  103002                          BEQ     DNMB2A              ;BR TO ERROR IF Z-BIT SET
 3002  007542  102401                          BCC     DNMB2A              ;BR TO ERROR IF C-BIT CLEAR
 3003  007544  100401                          BVS     DNMB2A              ;BR TO ERROR IF V-BIT SET
 3004  007546                                  BMI     DNMB2B
 3005  007546  104000                  DNMB2A:
 3006  007550  005300                          EMT                         ;COND. CODES INCORRECT
 3007  007552  001401                  DNMB2B: DEC     R0                  ;CHECK DEST. REGISTER.
 3008  007554  104000                          BEQ     DNMB2C
 3009  007556  005200                          EMT                         ;DEST. REGISTER NOT INCREMENTED BY 1
 3010  007560  132720  000201          DNMB2C: INC     R0                  ;R0=1
 3011  007564  001402                          BITB    #201,(R0)+          ;TRY DOPNM INST. W/MODE 2-ODD BYTE
 3012  007566  102401                          BEQ     DNMB2D  ;BR TO ERROR IF Z-BIT SET
 3013  007570  100001                          BVS     DNMB2D              ;BR TO ERROR IF V-BIT SET
 3014  007572                                  BPL     DNMB2E
 3015  007572  104000                  DNMB2D:
 3016  007574  005300                          EMT                         ;COND. CODES INCORRECT
 3017  007576  005300                  DNMB2E: DEC     R0                  ;DEC R0 TO CHECK IT.
 3018  007600  001401                          DEC     R0
 3019  007602  104000                          BEQ     DNMB2F
 3020  007604  022710  052652                  EMT                         ;DEST. REGISTER NOT INCREMENTED BY 1
 3021  007610  001401                  DNMB2F: CMP     #52652,(R0)         ;CHECK DEST. DATA IS UNMODIFIED
 3022  007612  104000                          BEQ     TS141
 3023                                          EMT                         ;DEST. DATA WAS MODIFIED.
 3024
 3025                                  ;*********************************************************************************************
 3026                                  ;TEST 141       TEST DEST. MODE 3-BYTES W/DOP NON-MODIFYING INST.
 3027                                  ;*********************************************************************************************
 3028  007614                          TS141:
 3029  007614  005000                          CLR     R0                  ;R0=0
 3030  007616  005010                          CLR     (R0)                ;LOC. 0=0
 3031  007620  052710  125125                  BIS     #125125,(R0)        ;LOC. 0=125125
 3032  007624  105100                          COMB    R0                  ;R0=377
 3033  007626  005200                          INC     R0                  ;R0=400
 3034  007630  005010                          CLR     (R0)                ;LOC. 400=0
 3035  007632  000263                          +SEC!SEV                    ;C-BIT=V-BIT=1
 3036  007634  132730  000201                  BITB    #201,@(R0)+         ;TRY DOPNM W/MODE 3-EVEN BYTE
 3037  007640  001403                          BEQ     DNMB3A              ;BR TO ERROR IF Z BIT SET
 3038  007642  102402                          BVS     DNMB3A              ;BR TO ERROR IF V BIT SET
 3039  007644  103001                          BCC     DNMB3A              ;BR TO ERROR IF C BIT CLEAR
 3040  007646  100001                          BPL     DNMB3B
 3041  007650                          DNMB3A:
 3042  007650  104000                          EMT                         ;COND. CODES INCORRECT
 3043  007652  022700  000402          DNMB3B: CMP     #402,R0             ;CHECK DEST. REGISTER INC. BY 2 AND INC BY 2 AGAIN
 3044  007656  001401                          BEQ     DNMB3C
 3045  007660  104000                          EMT                         ;DEST. REGISTER NOT INCREMENTED BY 2
 3046  007662  005200                  DNMB3C: INC     R0                  ;R0=404
 3047  007664  005200                          INC     R0
 3048  007666  132730  000201                  BITB    #201,@(R0)+         ;TRY DOPNM DEST MODE 3-BYTE(ODD)
```

```
3049  007672  001402                        BEQ     DNMB3D          ;BR TO ERROR IF Z BIT SET
3050  007674  102401                        BVS     DNMB3D          ;BR TO ERROR IF V BIT SET
3051  007676  100401                        BMI     DNMB3E
3052  007700                        DNMB3D:
3053  007700  104000                        EMT                     ;COND. CODES INCORRECT
3054  007702  005004                DNMB3E: CLR     R4              ;R4=0
3055  007704  022714  125125                CMP     #125125,(R4)    ;CHECK DEST. DATA
3056  007710  001401                        BEQ     TS142
3057  007712  104000                        EMT                     ;DEST. DATA MODIFIED
3058
3059                                ;*******************************************************************************
3060                                ;TEST 142       TEST DEST. MODE 4 W/DOP NON-MODIFYING INST.
3061                                ;*******************************************************************************
3062  007714                        TS142:
3063  007714  005000                        CLR     R0              ;R0=0
3064  007716  005010                        CLR     (R0)            ;LOC. 0=0
3065  007720  052710  125252                BIS     #125252,(R0)    ;LOC. 0=125125
3066  007724  052700  000002                BIS     #2,R0           ;R0=2
3067  007730  000277                        SCC                     ;SET ALL COND. CODE BITS
3068  007732  032740  020000                BIT     #20000,-(R0)    ;TRY DOPNM W/ MODE 4
3069  007736  100403                        BMI     DNM4A           ;BR TO ERROR IF N-BIT SET
3070  007740  102402                        BVS     DNM4A           ;BR TO ERROR IF V-BIT SET
3071  007742  103001                        BCC     DNM4A           ;BR TO ERROR IF C-BIT CHAR
3072  007744  001001                        BNE     DNM4B
3073  007746                        DNM4A:
3074  007746  104000                        EMT                     ;COND. CODES INCORRECT
3075  007750  005700                DNM4B:  TST     R0              ;CHECK DEST. REGISTER
3076  007752  001401                        BEQ     DNM4C
3077  007754  104000                        EMT                     ;DEST. REGISTER NOT DECREMENTED BY 2
3078  007756  022737  125252  000000 DNM4C: CMP     #125252,@#0     ;CHECK DEST. DATA
3079  007764  001401                        BEQ     TS143
3080  007766  104000                        EMT                     ;DEST. DATA MODIFIED
3081
3082                                ;*******************************************************************************
3083                                ;TEST 143       TEST DEST. MODE 4-BYTE W/ DOP NON-MODIFYING INST.
3084                                ;*******************************************************************************
3085  007770                        TS143:
3086  007770  005000                        CLR     R0              ;R0=0
3087  007772  005010                        CLR     (R0)            ;LOC. 0=0
3088  007774  052710  052652                BIS     #52652,(R0)     ;LOC. 0=52652
3089  010000  052700  000002                BIS     #2,R0           ;R0=2
3090  010004  000257                        CCC                     ;COND. CODES=0
3091  010006  132740  000201                BITB    #201,-(R0)      ;TRY DOPNM INST W/MODE 4 ODD BYTE
3092  010012  102403                        BVS     DNMB4A          ;BR TO ERROR IF V BIT SET
3093  010014  001402                        BEQ     DNMB4A  ;BR TO ERROR IF Z BIT SET
3094  010016  103401                        BCS     DNMB4A          ;BR TO ERROR IF C BIT SET
3095  010020  001001                        BNE     DNMB4B
3096  010022                        DNMB4A:
3097  010022  104000                        EMT                     ;COND. CODES INCORRECT
3098  010024  022700  000001        DNMB4B: CMP     #1,R0           ;CHECK DEST. REGISTER
3099  010030  001401                        BEQ     DNMB4C
3100  010032  104000                        EMT                     ;DEST REG. NOT DECREMENTED BY 1
3101  010034  132740  000201        DNMB4C: BITB    #201,-(R0)      ;TRY DOPNM INST. W/MODE 4 EVEN BYTE
3102  010040  001401                        BEQ     DNMB4D          ;BR TO ERROR IF Z-BIT SET
3103  010042  100401                        BMI     DNMB4E
3104  010044                        DNMB4D:
```

```
                        EMT                     ;COND. CODES INCORRECT
DNMB4E: TST     R0      ;CHECK DEST. REGISTER
        BEQ     DNMB4F
        EMT                     ;DEST. REG. NOT DECREMENTED BY 1
DNMB4F: CMP     #52652,(R0)     ;CHECK DESTINATION DATA
        BEQ     TS144
        EMT                     ;DEST. DATA MODIFIED

;*****************************************************************************************
;TEST 144       TEST DEST MODE 5 W/DOP NON-MODIFYING INST.
;*****************************************************************************************
TS144:
        CLR     R0              ;R0=0
        CLR     (R0)            ;LOC 0=0
        BIS     #100000,(R0)    ;LOC. 0=100000
        BIS     #402,R0         ;R0=2
        SCC                     ;SET ALL COND. CODE BITS
        BIT     #100000,@-(R0)  ;TRY DOPNM W/MODE 5
        BVS     DNM5A           ;BR TO ERROR IF V-BIT SET
        BCC     DNM5A           ;BR TO ERROR IF C-BIT CLEAR
        BEQ     DNM5A           ;BR TO ERROR IF Z-BIT SET
        BMI     DNM5B
DNM5A:
        EMT                     ;COND, CODES INCORRECT
DNM5B:  CMP #400,R0             ;CHECK DEST. REGISTER
        BEQ     DNM5C
        EMT                     ;DEST. REGISTER NOT DECREMENTED BY 2
DNM5C:  CMP     #100000,@#0     ;CHECK DESTINATION DATA
        BEQ     TS145
        EMT                     ;DEST. DATA INCORRECTLY MODIFIED

;*****************************************************************************************
;TEST 145       TEST DEST. MODE 6 W/DOP NON-MODIFYING INST.
;*****************************************************************************************
TS145:
        CLR     R0              ;R0=0
        CLR     (R0)            ;LOC> 0=0
        BIS     #1,(R0)         ;LOC. 0=1
        COM     R0              ;R0=-1 C-BIT=1
        BIT     #1,1(R0)        ;TRY DOPNM W/MODE 6
        BEQ     DNM6A           ;BR TO ERROR IF Z-BIT SET
        BVS     DNM6A           ;BR TO ERROR IF V-BIT SET
        BCC     DNM6A           ;BR TO ERROR IF C-BIT CLEAR
        BPL     DNM6B
DNM6A:
        EMT                     ;COND CODES INCORRECT
DNM6B:  CMP     #-1,R0          ;CHECK DEST. REGISTER
        BEQ     DNM6C
        EMT                     ;DEST. REGISTER MODIFIED
DNM6C:  CMP     #1,@#0          ;CHECK DEST. DATA
        BEQ     TS146
        EMT                     ;DEST. DATA MODIFIED

;*****************************************************************************************
;TEST 146       TEST DEST MODE 7 W/DOP NON-MODIFYING INST.
;*****************************************************************************************
```

```
3161  010216                          TS146:
3162  010216  005000                          CLR     R0              ;R0=0
3163  010220  005010                          CLR     (R0)            ;LOC. 0=0 C-BIT=0
3164  010222  052710  125125                BIS     #125125,(R0)    ;LOC. 0=125125
3165  010226  052700  000001                BIS     #1,R0           ;R0=1
3166  010232  132770  000125  000403        BITB    #125,@403(R0)   ;TRY DOPNM W/MODE 7
3167  010240  102403                          BVS     DNM7A           ;BR TO ERROR IF V-BIT SET
3168  010242  100402                          BMI     DNM7A           ;BR TO ERROR IF N-BIT SET
3169  010244  103401                          BCS     DNM7A           ;BR TO ERROR IF C-BIT SET
3170  010246  001401                          BEQ     DNM7B
3171  010250                          DNM7A:
3172  010250  104000                          EMT                     ;COND. CODES INCORRECT
3173  010252  022700  000001          DNM7B:  CMP     #1,R0           ;CHECK DEST. REGISTER
3174  010256  001401                          BEQ     DNM7C
3175  010260  104000                          EMT                     ;DESTINATION REGISTER MODIFIED
3176  010262  022737  125125  000000  DNM7C:  CMP     #125125,@#0     ;CHECK DEST. DATA
3177  010270  001401                          BEQ     TS147
3178  010272  104000                          EMT                     ;DEST. DATA INCORRECT
3179
3180                                  ;*****************************************************************************
3181                                  ;
3182                                  ;       THIS TEST VERIFIES THE MOV DESTINATION MODE 1 INSTRUCTION.
3183                                  ;DATA IS SET IN R0 USING SOP INSTRUCTIONS AND THEN MOVED TO LOC. 0
3184                                  ;USING MOV SRC MODE 0, DEST. MODE 1.
3185                                  ;
3186                                  ;*****************************************************************************
3187                                  ;TEST 147       TEST MOV DESTINATION MODE 1
3188                                  ;*****************************************************************************
3189  010274                          TS147:
3190  010274  005000                          CLR     R0              ;R0=0
3191  010276  005010                          CLR     (R0)            ;LOC. 0=0
3192  010300  005100                          COM     R0              ;R0=-1
3193  010302  005004                          CLR     R4              ;R4 POINTS TO LOC. 0
3194  010304  010014                          MOV     R0,(R4)         ;TRY MOVE MODE 0,1
3195  010306  102402                          BVS     MDM1A           ;BR TO ERROR IF V SET
3196  010310  001401                          BEQ     MDM1A           ;BR TO ERROR IF Z SET
3197  010312  100401                          BMI     MDM1B
3198  010314                          MDM1A:
3199  010314  104000                          EMT                     ;CONDITION CODE NOT CORRECT
3200  010316  005704                  MDM1B:  TST     R4
3201  010320  001401                          BEQ     TS150
3202  010322  104000                          EMT                     ;DESTINATION REGISTER INCORRECTLY ALTERED
3203
3204                                  ;*****************************************************************************
3205                                  ;
3206                                  ;       THIS TEST VERIFIES THE MOV DESTINATION MODE 2 INSTRUCTION.
3207                                  ;       DATA IS SET IN R0 USING SOP INSTRUCTIONS AND THEN MOVED
3208                                  ;       TO LOCATION 0 USING MOV SRC MODE 0, DEST. MODE 1.
3209                                  ;
3210                                  ;*****************************************************************************
3211                                  ;TEST 150       TEST MOV DESTINATION MODE 2
3212                                  ;*****************************************************************************
3213  010324                          TS150:
3214  010324  005000                          CLR     R0              ;R0=0
3215  010326  005001                          CLR     R1              ;R1=0
3216  010330  005010                          CLR     (R0)            ;LOC.0=0
```

```
3217  010332  005110                  COM     (R0)            ;LOC. 0= 1
3218  010334  010120                  MOV     R1,(R0)+        ;TRY MOVE MODE 0,2
3219  010336  100404                  BMI     MDM2A           ;BR TO ERROR IF N SET
3220  010340  102401                  BVS     MDM2A           ;BR TO ERROR IF V SET
3221  010342  001401                  BEQ     MDM2B
3222  010344                  MDM2A:
3223  010344  104000                  EMT                     ;CC'S INCORRECT
3224  010346  005300          MDM2B:  DEC     R0
3225  010350  005300                  DEC     R0
3226  010352  001401                  BEQ     MDM2D
3227  010354                  MDM2C:
3228  010354  104000                  EMT                     ;DESTINATION REGISTER NOT INCREMENTED PROPERLY
3229  010356  005737  000000  MDM2D:  TST     @#0
3230  010362  001401                  BEQ     TS151
3231  010364  104000                  EMT                     ;DESTINATION DATA INCORRECT
3232
3233                          ;*******************************************************************************
3234                          ;
3235                          ;       THIS TEST VERIFIES DESTINATION MODE 2 W/MOVB INSTS. TWO DIFFERENT MOVB
3236                          ;INSTRUCTIONS ARE USED TO MOVE A TEST PATTERN FIRST TO BYTE 0 THEN TO BYTE 1.
3237                          ;
3238                          ;*******************************************************************************
3239                          ;TEST 151       TEST MOV-BYTE DESTINATION MODE 2
3240                          ;*******************************************************************************
3241  010366                  TS151:
3242  010366  005000                  CLR     R0              ;R0=0
3243  010370  005010                  CLR     (R0)            ;LOC. 0=0
3244  010372  112720  000125          MOVB    #125,(R0)+      ;TRY DESTINATION MODE 2 W/EVEN BYTE
3245  010376  102402                  BVS     MBDM2A          ;BR TO ERROR IF V SET
3246  010400  001401                  BEQ     MBDM2A          ;BR TO ERROR IF Z SET
3247  010402  100001                  BPL     MBDM2B
3248  010404                  MBDM2A:
3249  010404  104000                  EMT                     ;CC'S INCORRECT
3250  010406  022700  000001  MBDM2B: CMP     #1,R0
3251  010412  001401                  BEQ     MBDM2C
3252  010414  104000                  EMT                     ;REGISTER NOT INCREMENTED BY ONE
3253  010416  112720  000252  MBDM2C: MOVB    #252,(R0)+      ;TRY DESTINATION MODE 2 W/ODD BYTE
3254  010422  102402                  BVS     MBDM2D
3255  010424  001401                  BEQ     MBDM2D
3256  010426  100401                  BMI     MBDM2E
3257  010430                  MBDM2D:
3258  010430  104000                  EMT                     ;CC'S NOT SET CORRECT
3259  010432  022700  000002  MBDM2E: CMP     #2,R0
3260  010436  001401                  BEQ     MBDM2F
3261  010440  104000                  EMT                     ;REGISTER NOT INCREMENTED BY ONE
3262  010442  022737  125125  000000 MBDM2F: CMP     #125125,@#0     ;CHECK DATA
3263  010450  001401                  BEQ     TS152
3264  010452  104000                  EMT                     ;DESTINATION DATA INCORRECT
3265
3266                          ;*******************************************************************************
3267                          ;
3268                          ;       THIS TEST VERIFIES MOV DESTINATION MODE 3. R0 IS USED TO PICK UP
3269                          ;AN ADDRESS AT LOC. 400. LOC 400 POINTS TO LOC. 0 THE EFFECTIVE DEST. ADDR.. ALSO, MOVB
3270                          ;INST. ARE USED W/ EVEN AND ODD BYTES TO CHECK MOV BYTES INST AND MODE 37 DESTINATIONS.
3271                          ;*******************************************************************************
3272                          ;TEST 152       TEST MOV(B) DESTINATION MODE 3
```

```
3273
3274  010454                          ;*****************************************************************************
3275  010454  012700  000400          TS152:  MOV     #400,R0         ;R0=400
3276  010460  005010                  CLR     (R0)            ;LOC. 400 POINTS TO LOC. 0
3277  010462  005037  000000          CLR     @#0             ;LOC. 0=0
3278  010466  012730  125252          MOV     #125252,@(R0)+  ;TRY MOV DESTINATION MODE 2
3279  010472  102402                  BVS     MDM3A           ;BR TO ERROR IF V SET
3280  010474  001401                  BEQ     MDM3A           ;BR TO ERROR IF Z SET
3281  010476  100401                  BMI     MDM3B
3282  010500                  MDM3A:
3283  010500  104000                  EMT                     ;CC'S INCORRECT
3284  010502  022700  000402  MDM3B:  CMP     #402,R0         ;CHECK DEST. MODE REGISTER
3285  010506  001401                  BEQ     MDM3C
3286  010510  104000                  EMT                     ;REGISTER NOT INCREMENTED BY 2
3287  010512  022737  125252  000000  MDM3C:  CMP     #125252,@#0     ;CHECK DESTINATION DATA
3288  010520  001401                  BEQ     MDM3D
3289  010522  104000                  EMT                     ;DESTINATION DATA INCORRECT
3290  010524  112737  000125  000000  MDM3D:  MOVB    #125,@#0        ;TRY MOVB DESTINATION MODE 2 EVEN BYTE
3291  010532  022737  125125  000000          CMP     #125125,@#0     ;CHECK DATA
3292  010540  001401                  BEQ     MDM3E
3293  010542  104000                  EMT                     ;DESTINATION DATA INCORRECT
3294  010544  112737  000525  000001  MDM3E:  MOVB    #525,@#1        ;TRY MOVB DESTINATION MODE 2 ODD BYTE
3295  010552  022737  052525  000000          CMP     #52525,@#0      ;CHECK DATA
3296  010560  001401                  BEQ     TS153
3297  010562  104000                  EMT                     ;
3298
3299                                  ;*****************************************************************************
3300                                  ;
3301                                  ;       THIS TEST VERIFIES THE MOV DESTINATION MODE 4 INSTRUCTION.
3302                                  ;SOP INSTRUCTIONS ON R0 ARE USED TO CLEAR TARGET LOCATION 0.
3303                                  ;R4 IS USED AS THE MODE 4 ADDRESSING REGISTER, AND
3304                                  ;CONDITIONAL BRANCHES ARE USED TO VERIFY THE DATA.
3305                                  ;
3306                                  ;*****************************************************************************
3307                                  ;TEST 153       TEST MOV DESTINATION MODE 4
3308                                  ;*****************************************************************************
3309  010564                  TS153:
3310  010564  005000                  CLR     R0              ;R0=0
3311  010566  005010                  CLR     (R0)            ;LOC 0=0
3312  010570  012704  000002          MOV     #2,R4           ;R4=2
3313  010574  012744  012345          MOV     #12345,-(R4)    ;TRY MOV DEST. MODE 4
3314  010600  102402                  BVS     MDM4A           ;BR TO ERROR IF V-BIT SET
3315  010602  001401                  BEQ     MDM4A           ;BR TO ERROR IF Z-BIT SET
3316  010604  100001                  BPL     MDM4B
3317  010606                  MDM4A:
3318  010606  104000                  EMT                     ;CC'S NOT CORRECT
3319  010610  005704          MDM4B:  TST     R4              ;CHECK DECREMENTING OF MODE 4 REG.
3320  010612  001401                  BEQ     MDM4C
3321  010614  104000                  EMT                     ;DESTINATION MODE REGISTER NOT DECREMENTED BY 2
3322  010616  022710  012345  MDM4C:  CMP     #12345,(R0)     ;CHECK DESTINATION DATA
3323  010622  001401                  BEQ     TS154
3324  010624  104000                  EMT                     ;DESTINATION DATA INCORRECT
3325
3326                                  ;*****************************************************************************
3327                                  ;
3328                                  ;       THIS TEST VERIFIES THE MOVB DESTINATION MODE 4 INSTRUCTION
```

```
                                ;       ON BOTH ODD AND EVEN BYTES. SOP INSTRUCTIONS ON R4 ARE
                                ;       USED TO CLEAR TARGET LOCATION 0. R0 IS USED AS THE MODE 4
                                ;       ADDRESSING REGISTER, AND CMP AND CONDITIONAL BRANCH
                                ;       INSTRUCTIONS ARE USED TO VERIFY THE DATA.
                                ;
                                ;*************************************************************************************
                                ;TEST 154       TEST MOVB DESTINATION MODE 4
                                ;*************************************************************************************
010626                          TS154:
010626  005004                          CLR     R4              ;R4=0
010630  005014                          CLR     (R4)            ;LOC. 0=0
010632  012700  000002                  MOV     #2,R0           ;R0 = 2
010636  112740  125125                  MOVB    #125125,-(R0)   ;TRY MOVB DEST. MODE 4-ODD BYTE
010642  020027  000001                  CMP     R0,#1           ;CHECK THAT DEST. REG. WAS DECREMENTED
010646  001401                          BEQ     MBDM4A
010650  104000                          EMT                     ;DESTINATION REG. NOT DECREMENTED BY 1
010652  021427  052400          MBDM4A: CMP     (R4),#52400     ;CHECK DEST. DATA
010656  001401                          BEQ     MBDM4B
010660  104000                          EMT                     ;DEST. DATA NOT CORRECT
010662  112740  125125          MBDM4B: MOVB    #125125,-(R0)   ;TRY MOVB DEST. MODE 4--EVEN BYTE
010666  102402                          BVS     MBDM4C          ;BR. TO ERROR IF V-BIT SET
010670  001401                          BEQ     MBDM4C          ;BR TO ERROR IF Z-BIT SET
010672  100001                          BPL     MBDM4D
010674                          MBDM4C:
010674  104000                          EMT                     ;COND. CODES INCORRECT
010676  005700                  MBDM4D: TST     R0              ;CHECK MODE 4 DEST. REGISTER
010700  001401                          BEQ     MBDM4E
010702  104000                          EMT                     ;DESTINATION REG NOT DECREMENTED BY 1
010704  021427  052525          MBDM4E: CMP     (R4),#52525     ;CHECK DEST. DAT^A
010710  001401                          BEQ     TS155
010712  104000                          EMT                     ;DESTINATION DATA INCORRECT

                                ;*************************************************************************************
                                ;
                                ;       THIS TEST VERIFIES THE MOV DESTINATION MODE 5 AND THE MOVB
                                ;DESTINATION MODE 5 - EVEN BYTE INSTRUCTIONS. R4 IS A
                                ;POINTER TO TARGET LOCATION 0 AND R0 IS SETUP TO
                                ;POINT TO LOCATION 376 FOR THE MOV, AND LOCATION 404 FOR
                                ;THE MOVB INSTRUCTIONS. CMP INSTRUCTIONS ARE USED TO VERIFY
                                ;PROPER ADDRESSING AND DATA.
                                ;
                                ;*************************************************************************************
                                ;TEST 155       TEST MOV DESTINATION MODE 5
                                ;*************************************************************************************
010714                          TS155:
010714  005004                          CLR     R4              ;R4=0
010716  005014                          CLR     (R4)            ;LOC. 0 = 0
010720  012700  000400                  MOV     #400,R0         ;R0=400
010724  012750  004321                  MOV     #4321,@-(R0)    ;TRY MOV DEST. MODE 5
010730  102402                          BVS     MDM5A           ;BR TO ERROR IF V-BIT SET
010732  001401                          BEQ     MDM5A           ;BR TO ERROR IF Z-BIT SET
010734  100001                          BPL     MDM5B
010736                          MDM5A:
010736  104000                          EMT                     ;COND. CODES INCORRECT
010740  022700  000376          MDM5B:  CMP     #376,R0         ;CHECK MODE 5 REG. WAS DECREMENTED
010744  001401                          BEQ     MDM5C
```

```
3385  010746  104000                        EMT                     ;MODE 5 REGISTER NOT DECREMENTED BY 2
3386  010750  022714  004321        MDM5C:  CMP     #4321,(R4)      ;CHECK DEST. DATA
3387  010754  001401                        BEQ     MDM5D
3388  010756  104000                        EMT                     ;DEST. DATA INCORRECT
3389  010760  012700  000406        MDM5D:  MOV     #406,R0         ;R0=406
3390  010764  112750  000377                MOVB    #377,@-(R0)     ;TRY MOV DEST. MODE 5 --EVEN BYTE
3391  010770  022700  000404                CMP     #404,R0         ;CHECK MODE 5 REG.
3392  010774  001401                        BEQ     MDM5E
3393  010776  104000                        EMT                     ;MODE 5 REGISTER NOT DECREMENTED BY 2
3394  011000  022714  177721        MDM5E:  CMP     #177721,(R4)    ;CHECK DEST. DATA
3395  011004  001401                        BEQ     TS156
3396  011006  104000                        EMT                     ;DEST. DATA INCORRECT
3397
3398                                ;*******************************************************************************
3399                                ;
3400                                ;       THIS TEST VERIFIES THE MOV DESTINATION MODE 6 AND MOVB - EVEN BYTE
3401                                ;DESTINATION MODE 6 INDTRUCTIONS. R0 IS USED TO SETUP TARGET LOC.0
3402                                ;FOR BOTH TESTS. PATTERNS OF ONES AND ZEROES ARE MOVED INTO LOC.0
3403                                ;BY MODE 6 INSTRUCTIONS, AND CMP INSTRUCTIONS ARE USED TO VERIFY
3404                                ;PROPER ADDRESSING AND DATA.
3405                                ;
3406                                ;*******************************************************************************
3407                                ;TEST 156       TEST MOV DESTINATION MODE 6
3408                                ;*******************************************************************************
3409  011010                        TS156:
3410  011010  005000                        CLR     R0              ;R0=0
3411  011012  005010                        CLR     (R0)            ;LOC. 0=0
3412  011014  005200                        INC     R0              ;R0=1
3413  011016  012760  052525  177777        MOV     #052525,-1(R0)  ;TRY MOV DEST. MODE 6
3414  011024  102402                        BVS     MDM6A           ;BR TO ERROR IF V-BIT SET
3415  011026  001401                        BEQ     MDM6A           ;BR TO ERROR IF Z-BIT SET
3416  011030  100001                        BPL     MDM6B
3417  011032                        MDM6A:
3418  011032  104000                        EMT                     ;COND. CODES INCORRECT
3419  011034  022700  000001        MDM6B:  CMP     #1,R0           ;CHECK DEST. REGISTER UNALTERED
3420  011040  001401                        BEQ     MDM6C
3421  011042  104000                        EMT                     ;DEST. REGISTER INCORRECTLY ALTERED
3422  011044  022737  052525  000000  MDM6C:  CMP     #52525,@#0      ;CHECK DEST. DATA
3423  011052  001401                        BEQ     MDM6D
3424  011054  104000                        EMT                     ;DEST. DATA INCORRECT
3425  011056  012700  000002        MDM6D:  MOV     #2,R0           ;R0=2
3426  011062  112760  000377  177777        MOVB    #377,-1(R0)     ;TRY MOVB DEST. MODE 6
3427  011070  022700  000002                CMP     #2,R0           ;CHECK DEST. REGISTER UNALTERED
3428  011074  001401                        BEQ     MDM6E
3429  011076  104000                        EMT                     ;DEST. REGISTER INCORRECTLY ALTERED
3430  011100  022737  177525  000000  MDM6E:  CMP     #177525,@#0     ;CHECK DEST. DATA
3431  011106  001401                        BEQ     TS157
3432  011110  104000                        EMT                     ;DEST. DATA INCORRECT
3433
3434                                ;*******************************************************************************
3435                                ;
3436                                ;       THIS TEST VERIFIES THE MOV DESTINATION MODE 7 AND MOVB - ODD BYTE
3437                                ;DESTINATION MODE 7 INSTRUCTIONS. R4 POINTS TO TARGET LOC.0 AND R0
3438                                ;IS USED AS THE MODE 7 ADDRESSING REGISTER. CMP INSTRUCTIONS ARE
3439                                ;USED TO VERIFY PROPER ADDRESSING AND DATA.
3440                                ;
```

```
                                ;*****************************************************************************************
                                ;TEST 157       TEST MOV DESTINATION MODE 7
                                ;*****************************************************************************************
011112                          TS157:
011112  005004                         CLR     R4              ;R4=0
011114  005014                         CLR     (R4)            ;LOC.0=0
011116  012700  000403                 MOV     #403,R0         ;R0=403
011122  012770  070707  177777         MOV     #70707,@-1(R0)  ;TRY MOV W/DEST MODE 7
011130  102402                         BVS     MDM7A           ;BR. TO ERROR IF V-BIT SET
011132  001401                         BEQ     MDM7A           ;BR TO ERROR IF Z-BIT SET
011134  100001                         BPL     MDM7B
011136                          MDM7A:
011136  104000                         EMT                     ;COND. CODES INCORRECT
011140  022700  000403         MDM7B:  CMP     #403,R0         ;CHECK DEST. REGISTER
011144  001401                         BEQ     MDM7C
011146  104000                         EMT                     ;DEST. REGISTER INCORRECTLY ALTERED
011150  022737  070707  000000 MDM7C:  CMP     #70707,@#0      ;CHECK DEST. DATA
011156  001401                         BEQ     MDM7D
011160  104000                         EMT                     ;DEST. DATA INCORRECT
011162  112770  107070  000001 MDM7D:  MOVB    #107070,@1(R0)  ;TRY MOVB W/DEST MODE 7--ODD BYTE
011170  022700  000403                 CMP     #403,R0         ;CHECK MODE 7 DEST. REG.
011174  001401                         BEQ     MDM7E
011176  104000                         EMT                     ;DEST. DATA INCORRECT
011200  022737  034307  000000 MDM7E:  CMP     #34307,@#0      ;CHECK DEST. DATA
011206  001401                         BEQ     TS160
011210  104000                         EMT                     ;DESTINATION DATA INCORRECT

                                ;*****************************************************************************************
                                ;
                                ;       THIS TEST VERIFIES MODE 4 DOUBLE OPERAND INSTRUCTIONS.
                                ;THE TEST USES MODE 4 ADDRESSING WITH REGISTER 0 TO MOVE THRU A
                                ;TABLE OF OPERANDS.  THE TABLE OF OPERANDS AND THE WORK LOCATION IS
                                ;STORED FOLLOWING THE TEST CODE.  A SERIES OF 5 DOP INSTRUCTIONS UTILIZES
                                ;THE DATA IN THE TABLE TO CYCLE THE WORK LOCATION THRU A SET OF
                                ;VALUE.  THE DATA HAS BEEN CHOSEN TO INSURE THAT NO SINGLE ERROR WILL
                                ;GO UNDETECTED.  WORD AND BYTE INSTRUCTION ACCESSING BOTH EVEN AND
                                ;ODD ADDRESSES ARE USED IN THE TEST.  THE LISTING SHOWS THE
                                ;EXPECTED INTERMEDIATE RESULT AS EACH INSTRUCTION IS EXECUTED.
                                ;
                                ;*****************************************************************************************
                                ;TEST 160       TEST MODE 4 W/ DOP INSTS.
                                ;*****************************************************************************************
011212                          TS160:
011212  012700  011256                 MOV     #TBL1,R0        ;INITIALIZE R0
011216  014037  011256                 MOV     -(R0),@#TBL1    ;TBL1=125252
011222  064037  011256                 ADD     -(R0),@#TBL1    ;TBL1=000377
011226  144037  011256                 BICB    -(R0),@#TBL1    ;TBL1=000252
011232  154037  011257                 BISB    -(R0),@#TBL1+1  ;TBL1=125252
011236  024037  011256                 CMP     -(R0),@#TBL1    ;CHECK RESULT
011242  001406                         BEQ     TS161
011244                          DOP4:
011244  104000                         EMT                     ;RESULT OF MODE 4 INSTS. INCORRECT

011246  125252                         125252
01125C  052652                         52652
011252  053125                         53125
```

```
                                        125252
011256  000000                  TBL1:   0
                        ;*****************************************************************************
                        ;
                        ;       THIS TEST VERIFIES MODE 5 DOUBLE OPERAND INSTRUCTIONS.
                        ;THE TEST USES AN ADDRESS TABLE STORED FOLLOWING THE TEST CODE.
                        ;THIS TABLE IS SIMPLY A TABLE OF ADDRESS POINTERS WHICH ADDRESS
                        ;THE DATA TABLE USED IN THE PREVIOUS TEST.  THE TEST IS IDENTICAL TO
                        ;THE PREVIOUS TEST EXCEPT THE DATA IS REFERENCED USING THIS ADDRESS
                        ;TABLE AND MODE 5 ADDRESSING.  (SEE PREVIOUS TEST).
                        ;
                        ;*****************************************************************************
                        ;TEST 161       TEST MODE 5 W/ DOP INSTS.
                        ;*****************************************************************************
011260                  TS161:
011260  012700  011326          MOV     #TBL2+2,R0      ;INITIALIZE R0
011264  015037  011256          MOV     @-(R0),@#TBL1   ;TBL1=125252
011270  065037  011256          ADD     @-(R0),@#TBL1   ;TBL1=000377
011274  145037  011256          BICB    @-(R0),@#TBL1   ;TBL1=000252
011300  155037  011257          BISB    @-(R0),@#TBL1+1 ;TBL1=125252
011304  025037  011256          CMP     @-(R0),@#TBL1   ;CHECK RESULT
011310  001406                  BEQ     TS162
011312                  DOP5:
011312  104000                  EMT                     ;RESULT OF MODE 5 INSTS. INCORRECT
011314  011246                  TBL1-10
011316  011250                  TBL1-6
011320  011251                  TBL1-5
011322  011252                  TBL1-4
011324  011254          TBL2:   TBL1-2
                        ;*****************************************************************************
                        ;
                        ;       THIS TEST VERIFIES MODE 6 DOUBLE OPERAND INSTRUCTIONS.
                        ;IT USES THE SAME DATA AS THAT USED IN THE MODE 4 TESTS.
                        ;THIS TIME THE DATA IS ACCESSED USING MODE 6.  R0 IS SET
                        ;TC POINT TO THE MIDDLE OF THE TABLE.  THE TABLE IS ACCESSED FROM
                        ;BOTTOM TO TOP BY VARYING THE OFFSET IN THE MODE 6 INSTRUCTIONS.
                        ;THE DATA RESULTS ARE IDENTICAL TO THOSE EXPECTED IN THE MODE 4
                        ;TESTS.
                        ;
                        ;*****************************************************************************
                        ;TEST 162       TEST MODE 6 W/ DOP INSTS.
                        ;*****************************************************************************
011326                  TS162:
011326  012700  011252          MOV     #TBL1-4,R0      ;INITIALIZE R0
011332  016037  000002  011256  MOV     2(R0),@#TBL1    ;TBL1=125252
011340  066037  000000  011256  ADD     0(R0),@#TBL1    ;TBL1=000377
011346  146037  177777  011256  BICB    -1(R0),@#TBL1   ;TBL1=000252
011354  156037  177776  011257  BISB    -2(R0),@#TBL1+1 ;TBL1=125252
011362  026037  177774  011256  CMP     -4(R0),@#TBL1   ;CHECK RESULT
011370  001401                  BEQ     TS163
011372  104000                  EMT                     ;RESULT OF MODE 6 INSTS. INCORRECT
                        ;*****************************************************************************
                        ;
                        ;       THIS TEST VERIFIES MODE 7 DOUBLE OPERAND INSTRUCTIONS.
                        ;THIS TEST USES THE SAME ADDRESS TABLE AND DATA TABLE USED BY
```

```
                                ;THE MODE 5 TESTS.  THIS TIME THE DATA IS ACCESSED USING MODE 7.
                                ;R0 IS SET TO POINT TO THE MIDDLE OF THE ADDRESS TABLE IN THE MODE 5
                                ;TEST.  THE TABLE IS ACCESSED FROM BOTTOM TO TOP BY VARYING THE OFFSET
                                ;IN THE MODE 7 INSTRUCTIONS.  THE DATA RESULTS ARE IDENTICAL TO
                                ;THOSE EXPECTED IN THE MODE 5 TESTS.
                                ;
                                ;*****************************************************************************
                                ;TEST 163       TEST MODE 7 W/ DOP INSTS.
                                ;*****************************************************************************
011374                          TS163:
011374  012700  011320                  MOV     #TBL2-4,R0      ;INITIALIZE R0
011400  017037  000004  011256          MOV     @4(R0),@#TBL1   ;TBL1=125252
011406  067037  000002  011256          ADD     @2(R0),@#TBL1   ;TBL1=000377
011414  147037  000000  011256          BICB    @0(R0),@#TBL1   ;TBL1=000252
011422  157037  177776  011257          BISB    @-2(R0),@#TBL1+1                ;TBL1=125252
011430  027037  177774  011256          CMP     @-4(R0),@#TBL1          ;CHECK RESULT
011436  001401                          BEQ     TS164
011440  104000                          EMT                             ;RESULT OF MODE 7 INSTS INCORRECT
                                ;*****************************************************************************
                                ;
                                ;       THIS TEST VERIFIES THE ROTATE MODE 0 INSTRUCTIONS.
                                ;R0 IS LOADED WITH A DATA PATTERN, THE C-BIT IS LOADED, AND
                                ;AN ROL INSTRUCTION IS EXECUTED WITH MODE 0.  THE OPERATION IS CHECKED
                                ;BY TESTING THE RESULTING DATA AND THE STATE OF THE C AND V BITS.
                                ;NEXT, THE SAME PROCEDURE IS EXECUTED TO TEST MODE 0 BYTE INSTRUCTIONS.
                                ;
                                ;*****************************************************************************
                                ;TEST 164       TEST ROTATE INSTRUCTIONS OF MODE 0
                                ;*****************************************************************************
011442                          TS164:
011442  012700  125252                  MOV     #125252,R0      ;INITIALIZE DATA
011446  000261                          SEC                     ;SET C-BIT
011450  006100                          ROL     R0              ;TRY ROL W/ MODE 0
011452  102004                          BVC     ROT0A           ;CC=0011
011454  103003                          BCC     ROT0A
011456  022700  052525                  CMP     #052525,R0      ;CHECK DATA
011462  001401                          BEQ     ROT0B
011464                          ROT0A:
011464  104000                          EMT                     ;ROL MODE 0 FAILED
011466  012700  125252          ROT0B:  MOV     #125252,R0      ;INITIALIZE DATA
011472  000261                          SEC                     ;SET C-BIT
011474  106100                          ROLB    R0              ;TRY ROL W/ MODE 0 EVEN BYTE
011476  102004                          BVC     ROT0C           ;CC=0011
011500  103003                          BCC     ROT0C
011502  022700  125125                  CMP     #125125,R0      ;CHECK DATA
011506  001401                          BEQ     TS165
011510                          ROT0C:
011510  104000                          EMT                     ;ROLB MODE 0 FAILED

                                ;*****************************************************************************
                                ;
                                ;       THIS TEST VERIFIES THE ROTATE MODE 1 INSTRUCTIONS.
                                ;THE DATA TO BE ROTATED IS IN LOC 0.  R0 IS USED AS THE
                                ;ADDRESSING REGISTER.  THE C-BIT IS LOADED AND AN ROL IS EXECUTED.
                                ;THE RESULTS ARE CHECKED BY COMPARING THE DATA RESULTS AND TESTING
                                ;THE C AND V BITS.  THIS PROCEDURE IS THEN REPEATED TWICE MORE
```

```
                                ;TO TEST THE BYTE ROTATES.  FIRST ON BYTE 0, THEN ON BYTE 1.
                                ;
                                ;*****************************************************************************
                                ;TEST 165       TEST ROTATE INSTRUCTIONS W/ MODE 1
                                ;*****************************************************************************
011512                          TS165:
011512  005000                          CLR     R0                      ;POINT TO LOC. 0
011514  012710  052525                  MOV     #52525,(R0)             ;INITIALIZE DATA
011520  000241                          CLC                             ;CLEAR C-BIT
011522  006110                          ROL     (R0)                    ;TRY ROL W/ MODE 1
011524  102005                          BVC     ROT1A                   ;CC=1010
011526  103404                          BCS     ROT1A
011530  022727  000000  125252          CMP     @#0,#125252             ;CHECK RESULT
011536  001401                          BEQ     ROT1B
011540                          ROT1A:
011540  104000                          EMT                             ;ROL MODE 1 FAILED
011542  000261                  ROT1B:  SEC
011544  012710  125252                  MOV     #125252,(R0)            ;INITIALIZE DATA
011550  106110                          ROLB    (R0)                    ;TRY ROLB W/ MODE 1 EVEN BYTE
011552  102005                          BVC     ROT1C                   ;CC=1011
011554  103004                          BCC     ROT1C
011556  022737  125125  000000          CMP     #125125,@#0             ;TEST RESULT
011564  001401                          BEQ     ROT1D
011566                          ROT1C:
011566  104000                          EMT                             ;ROLB W/ MODE 1 EVEN BYTE FAILED
011570  012710  125252          ROT1D:  MOV     #125252,(R0)
011574  005000                          CLR     R0                      ;POINT TO ODD BYTE
011576  005200                          INC     R0
011600  000261                          SEC                             ;SET C-BIT
011602  106110                          ROLB    (R0)                    ;TRY ROLB W/ MODE 1 ODD BYTE
011604  102005                          BVC     ROT1E                   ;CC=0011
011606  103004                          BCC     ROT1E
011610  022737  052652  000000          CMP     #052652,@#0             ;CHECK DATA
011616  001401                          BEQ     TS166
011620                          ROT1E:
011620  104000                          EMT                             ;ROLB W/ MODE 1 ODD BYTE FAILED
                                ;*****************************************************************************
                                ;
                                ;       THIS TEST VERIFIES MODE 2 ROTATE INSTRUCTIONS.
                                ;THE SAME PROCEDURE AS IN THE OTHER ROTATE TESTS ARE USED.  R0
                                ;IS USED AS THE ADDRESSING REGISTER AND IS CHECKED FOR PROPER
                                ;INCREMENTING.  BYTE INSTRUCTIONS ARE ALSO CHECKED.
                                ;
                                ;*****************************************************************************
                                ;TEST 166       TEST ROTATE INSTRUCTIONS W/ MODE 2
                                ;*****************************************************************************
011622                          TS166:
011622  005000                          CLR     R0                      ;POINT TO LOC 0
011624  012710  173737                  MOV     #173737,(R0)            ;INITIALIZE DATA
011630  000241                          CLC                             ;CLEAR C-BIT
011632  006120                          ROL     (R0)+                   ;TRY ROL W/ MODE 2
011634  103007                          BCC     ROT2A                   ;CHECK C-BIT
011636  022737  167676  000000          CMP     #167676,@#0             ;CHECK DATA
011644  001003                          BNE     ROT2A                   ;BRANCH IF RESULT INCORRECT
011646  005300                          DEC     R0                      ;TEST R0
```

```
3665  011650  005300                          DEC     R0
3666  011652  001401                          BEQ     ROT2B
3667  011654                          ROT2A:
3668  011654  104000                          EMT                     ;ROL W/ MODE 2 FAILED
3669  011656  005000                  ROT2B:  CLR     R0              ;POINT TO LOC 0
3670  011660  012710  004040                  MOV     #4040,(R0)      ;INITIALIZE DATA
3671  011664  000241                          CLC                     ;CLEAR C-BIT
3672  011666  106120                          ROLB    (R0)+           ;TRY ROLB W/ MODE 2 EVEN BYTE
3673  011670  103406                          BCS     ROT2C           ;CHECK C-BIT
3674  011672  022737  004100  000000          CMP     #4100,@#0       ;CHECK DATA
3675  011700  001002                          BNE     ROT2C           ;BRANCH IF DATA INCORRECT
3676  011702  005300                          DEC     R0              ;CHECK R0
3677  011704  001401                          BEQ     ROT2D
3678  011706                          ROT2C:
3679  011706  104000                          EMT                     ;ROLB W/ MODE 2 EVEN BYTE FAILED
3680  011710  005000                  ROT2D:  CLR     R0              ;POINT TO LOC 0
3681  011712  012710  004040                  MOV     #4040,(R0)      ;INITIALIZE DATA
3682  011716  005200                          INC     R0              ;POINT TO ODD BYTE OF DATA
3683  011720  000261                          SEC                     ;SET C-BIT
3684  011722  106120                          ROLB    (R0)+           ;TRY ROL W/ MODE 2 ODD BYTE
3685  011724  103407                          BCS     ROT2E           ;CHECK C-BIT
3686  011726  022737  010440  000000          CMP     #10440,@#0      ;CHECK DATA
3687  011734  001003                          BNE     ROT2E           ;BRANCH IF DATA INCORRECT
3688  011736  005300                          DEC     R0              ;CHECK R0
3689  011740  005300                          DEC     R0
3690  011742  001401                          BEQ     TS167
3691  011744                          ROT2E:
3692  011744  104000                          EMT                     ;ROLB W/ MODE 2 ODD BYTE FAILED
3693
3694                                  ;*******************************************************************************************
3695                                  ;
3696                                  ;       THIS TEST VERIFIES MODE 3 ROTATE INSTRUCTIONS.
3697                                  ;THIS TEST USES THE SAME PROCEDURES AS IN THE OTHER ROTATE
3698                                  ;TESTS.  THE DATA IS STORED IN LOC. 0 AND IS ADDRESSED USING
3699                                  ;MODE 37.  BYTE ADDRESSING IS ALSO CHECKED FOR EVEN AND ODD BYTES.
3700                                  ;
3701                                  ;*******************************************************************************************
3702                                  ;TEST 167       TEST ROTATE INSTRUCTIONS /W MODE 3
3703                                  ;*******************************************************************************************
3704  011746                          TS167:
3705  011746  012737  052525  000000          MOV     #52525,@#0      ;INITIALIZE DATA IN LOC 0
3706  011754  000261                          SEC                     ;SET C-BIT
3707  011756  006137  000000                  ROL     @#0             ;TRO ROL W/ MODE 3
3708  011762  103404                          BCS     ROT3A           ;CHECK C-BIT
3709  011764  022737  125253  000000          CMP     #125253,@#0     ;CHECK DATA
3710  011772  001401                          BEQ     ROT3B
3711  011774                          ROT3A:
3712  011774  104000                          EMT                     ;ROL W/ MODE 3 FAILED
3713  011776  012737  125252  000000  ROT3B:  MOV     #125252,@#0     ;INITIALIZE DATA
3714  012004  000241                          CLC                     ;CLEAR C-BIT
3715  012006  106137  000000                  ROLB    @#0             ;TRY ROL W/ MODE 3 EVEN BYTE
3716  012012  103004                          BCC     ROT3C           ;CHECK C-BIT
3717  012014  023727  000000  125124  4$:     CMP     @#0,#125124     ;CHECK DATA
3718  012022  001401                          BEQ     ROT3D
3719  012024                          ROT3C:
3720  012024  104000                          EMT                     ;ROL W/ MODE 3 EVEN BYTE FAILED
```

```
3721  012026  012737  125252  000000  ROT3D:  MOV     #125252,@#0     ;INITIALIZE DATA IN LOC. 0
3722  012034  000261                          SEC                     ;SET C-BIT
3723  012036  106137  000001                  ROLB    @#1             ;TRY ROL W/ MODE 3 ODD BYTE
3724  012042  103004                          BCC     ROT3E           ;CHECK C-BIT
3725  012044  022737  052652  000000          CMP     #052652,@#0     ;CHECK DATA
3726  012052  001401                          BEQ     TS170
3727  012054                          ROT3E:
3728  012054  104000                          EMT                     ;ROL W/ MODE 3 ODD BYTE FAILED
3729
3730                                  ;*****************************************************************************
3731                                  ;
3732                                  ;       THIS TEST VERIFIES MODE 4 ROTATE INSTRUCTIONS.  THE DATA IS
3733                                  ;STORED IN LOC. 0.  R0 IS SET TO 2 AND THE CARRY IS SET.  AN ROL MODE 4
3734                                  ;IS USED TO ROTATE LOCATION 0 USING R0.  THE DATA IS CHECKED
3735                                  ;AND THE C AND V BITS ARE TESTED.  THE PROPER DECREMENTING OF
3736                                  ;R0 IS VERIFIED.
3737                                  ;
3738                                  ;*****************************************************************************
3739                                  ;TEST 170       TEST MODE 4 W/ ROTATE INSTRUCTIONS
3740                                  ;*****************************************************************************
3741  012056                          TS170:
3742  012056  012737  070707  000000          MOV     #070707,@#0     ;INITIALIZE DATA IN LOC. 0
3743  012064  012700  000002                  MOV     #2,R0           ;INITIALIZE R0 AS POINTER
3744  012070  000261                          SEC                     ;SET C-BIT
3745  012072  006140                          ROL     -(R0)           ;TRY ROL W/ MODE 4
3746  012074  103406                          BCS     ROT4            ;CHECK C-BIT
3747  012076  022737  161617  000000          CMP     #161617,@#0     ;CHECK DATA
3748  012104  001002                          BNE     ROT4            ;BRANCH IF DATA INCORRECT
3749  012106  005700                          TST     R0              ;CHECK MODE 4 REGISTER
3750  012110  001401                          BEQ     TS171
3751  012112                          ROT4:
3752  012112  104000                          EMT                     ;ROL MODE 4 FAILED
3753
3754                                  ;*****************************************************************************
3755                                  ;
3756                                  ;       THIS TEST VERIFIES MODE 5 ROTATE INSTRUCTIONS.
3757                                  ;THE DATA IS STORED IN A WORK LOCATION (ROTX) AT THE END OF THE
3758                                  ;TEST CODE.  LOC. 0 IS LOADED WITH THE ADDRESS OF THE DATA (ROTX).
3759                                  ;R0 IS SET TO 2.  THE CARRY IS CLEARED AND A MODE 5 ROL
3760                                  ;IS EXECUTED USING R0 AS AN ADDRESSING REGISTER.  THE DATA IS
3761                                  ;CHECKED, THE C AND V BITS TESTED, AND R0 CHECKED FOR PROPER
3762                                  ;DECREMENTING.
3763                                  ;
3764                                  ;*****************************************************************************
3765                                  ;TEST 171       TEST MODE 5 W/ ROTATE INSTRUCTIONS
3766                                  ;*****************************************************************************
3767  012114                          TS171:
3768  012114  012737  012160  000000          MOV     #ROTX,@#0       ;MOVE POINTER TO LOC. 0
3769  012122  012700  000002                  MOV     #2,R0           ;SET MODE 5 REG. TO LOC. 0
3770  012126  012767  107070  000024          MOV     #107070,ROTX    ;INITIALIZE DATA
3771  012134  000241                          CLC                     ;CLEAR C-BIT
3772  012136  006150                          ROL     @-(R0)          ;TRY ROL W/ MODE 5
3773  012140  103006                          BCC     ROT5            ;CHECK C-BIT
3774  012142  022737  016160  012160          CMP     #016160,@#ROTX  ;CHECK DATA
3775  012150  001002                          BNE     ROT5            ;BRANCH IF DATA INCORRECT
3776  012152  005700                          TST     R0              ;CHECK MODE 5 REGISTER
```

```
                        BEQ     TS172
                ROT5:
                        EMT                     ;ROL MODE 5 FAILED
                ROTX:   0

                ;*****************************************************************************
                ;
                ;       THIS TEST VERIFIES MODE 6 ROTATE INSTRUCTIONS.
                ;IT USES THE SAME PROCEDURE AS THE ABOVE TEST EXCEPT THE
                ;ROTATE INSTRUCTION USES MODE 6 ADDRESSING WITH REGISTER 7.
                ;THE DATA IS STILL OPERATED ON IN LOC. ROTX (SEE PREVIOUS TEST).
                ;
                ;*****************************************************************************
                ;TEST 172       TEST MODE 6 W/ ROTATE INSTRUCTIONS
                ;*****************************************************************************
                TS172:
                        MOV     #125252,@#ROTX  ;INITIALIZE DATA
                        SEC                     ;SET C-BIT
                        ROL     ROTX            ;TRY ROL W/ MODE 6
                        BCC     ROT6            ;CHECK C-BIT
                        CMP     #52525,@#ROTX   ;CHECK DATA
                        BEQ     TS173
                ROT6:
                        EMT                     ;ROL W/ MODE 6 FAILED

                ;*****************************************************************************
                ;
                ;THIS TEST VERIFIES MODE 7 ROTATE INSTRUCTIONS.
                ;THE DATA IS SET IN LOC. ROTX, (SEE PREVIOUS TEST).  THE ROL INSTRUCTION
                ;ADDRESSES IT INDIRECTLY USING MODE 7 AND INDIRECT ADDRESS LOCATION
                ;(ROTXAD) FOLLOWING THE TEST CODE.
                ;
                ;*****************************************************************************
                ;TEST 173       TEST MODE 7 W/ ROTATE INSTRUCTIONS
                ;*****************************************************************************
                TS173:
                        MOV     #52525,@#ROTX   ;INITIALIZE DATA
                        MOV     #ROTX,@#ROTXAD  ;INITIALIZE ADDRESS POINTER
                        CLC                     ;CLEAR C-BIT
                        ROL     @ROTXAD         ;TRY ROL W/ MODE 7
                        BCS     ROT7            ;CHECK C-BIT
                        CMP     @#ROTX,#125252  ;CHECK DATA
                        BEQ     TS174
                ROT7:
                        EMT                     ;ROL W/ MODE 7 FAILED
                ROTXAD: 0


                ;*****************************************************************************
                ;
                ;       THIS TEST VERIFIES MODE 0 SWAB INSTRUCTION.  R0 IS SET TO
                ;177400.  A SWAB MODE 0 IS EXECUTED AND THE CONDITIONAL BRANCH
                ;IS USED TO CHECK THE SIGN OF THE RESULT.  ALSO, A COMPARISON
                ;IS MADE TO CHECK THE DATA RESULTS.
                ;
                ;*****************************************************************************
```

```
                                ;TEST 174       TEST MODE 0 W/ SWAB INST.
                                ;*****************************************************************************
012252                          TS174:
012252  012700  177400                  MOV     #177400,R0      ;MOVE TEST PATTERN TO R0
012256  000300                          SWAB    R0              ;TRY SWAB MODE 0
012260  100401                          BMI     SB0
012262  104000                          EMT                     ;SWAB DID NOT SET CC'S CORRECT
012264  022700  000377        SB0:      CMP     #377,R0         ;CHECK RESULT
012270  001401                          BEQ     TS175
012272  104000                          EMT                     ;RESULT OF SWAB MODE 0 FAILED

                                ;*****************************************************************************
                                ;
                                ;       THIS TEST VERIFIES MODE 1 SWAB INSTRUCTION.  THE TEST
                                ;PATTERN IS MOVED TO LOC 0.  R0 IS CLEARED AND USED AS THE ADDRESSING
                                ;REGISTER IN THE MODE 1 SWAB.  THE DATA RESULTS ARE CHECKED WITH
                                ;A COMPARE.
                                ;
                                ;*****************************************************************************
                                ;TEST 175       TEST MODE 1 W/ SWAB INST
                                ;*****************************************************************************
012274                          TS175:
012274  012737  125652  000000          MOV     #125652,@#0     ;MOVE TEST PATTERN TO LOC. 0
012302  005000                          CLR     R0              ;R0=0
012304  000310                          SWAB    (R0)            ;TRY SWAB MODE 1
012306  022737  125253  000000          CMP     #125253,@#0     ;CHECK RESULT
012314  001401                          BEQ     TS176
012316  104000                          EMT                     ;RESULT OF SWAB MODE 1 FAILED


                                ;*****************************************************************************
                                ;
                                ;       THIS TEST VERIFIES MODE 2 SWAB INSTRUCTION.  THE TEST
                                ;PATTERN IS MOVED TO LOC 0.  R0 IS CLEARED AND USED AS THE MODE
                                ;2 ADDRESSING REGISTER.  THE RESULTS ARE CHECKED WITH A COMPARE.
                                ;RC IS CHECKED FOR PROPER DECREMENTING.
                                ;
                                ;*****************************************************************************
                                ;TEST 176       TEST MODE 2 W/ SWAB INST
                                ;*****************************************************************************
012320                          TS176:
012320  012737  125152  000000          MOV     #125152,@#0     ;MOVE TEST PATTERN TO LOC. 0
012326  005000                          CLR     R0              ;R0=0
012330  000320                          SWAB    (R0)+           ;TRY SWAB MODE 2
012332  022737  065252  000000          CMP     #65252,@#0      ;CHECK RESULT
012340  001401                          BEQ     SB2
012342  104000                          EMT                     ;RESULT OF SWAB MODE 0 FAILED
012344  162700  000002        SB2:      SUB     #2,R0           ;CHECK EFFECT OF REG.
012350  001401                          BEQ     TS177
012352  104000                          EMT                     ;REGISTER VALUE INCORRECT


                                ;*****************************************************************************
                                ;
                                ;       THIS TEST VERIFIES MODE 3 SWAB INSTRUCTION.  THE TEST
                                ;PATTERN IS MOVED TO LOC 0.  A MODE 3 SWAB INSTRUCTION IS EXECUTED
```

```
                                ;USING R7 AS THE ADDRESSING REGISTER.  A COMPARE VERIFIES THE
                                ;DATA RESULTS.
                                ;
                                ;*****************************************************************************
                                ;TEST 177       TEST MODE 3 W/SWAB INST.
                                ;*****************************************************************************
012354                          TS177:
012354  012737  000377  000000          MOV     #377,@#0        ;MOVE TEST PATTERN TO LOC. 0
012362  000337  000000                  SWAB    @#0             ;TRY SWAB W/ MODE 3
012366  022737  177400  000000          CMP     #177400,@#0     ;CHECK RESULT
012374  001401                          BEQ     TS200
012376  104000                          EMT                     ;RESULT OF SWAB INCORRECT
                                ;
                                ;*****************************************************************************
                                ;
                                ;       THIS TEST VERIFIES MODE 4 SWAB INSTRUCTIONS.  THE DATA
                                ;IS MOVED TO LOC 0.  R0 IS SET TO 2 AND USED AS THE MODE 4 ADDRESSING
                                ;REGISTER.  THE DATA IS CHECKED WITH A COMPARE AND R0 IS CHECKED
                                ;FOR PROPER DECREMENTING.
                                ;
                                ;*****************************************************************************
                                ;TEST 200       TEST MODE 4 W/ SWAB INST
                                ;*****************************************************************************
012400                          TS200:
012400  012737  125652  000000          MOV     #125652,@#0     ;MOVE TEST PATTERN TO LOC. 0
012406  012700  000002                  MOV     #2,R0           ;SET UP REGISTER POINTER
012412  000340                          SWAB    -(R0)           ;TRY SWAB MODE 4
012414  022737  125253  000000          CMP     #125253,@#0     ;CHECK RESULT
012422  001401                          BEQ     SB4
012424  104000                          EMT                     ;RESULT OF SWAB INCORRECT
012426  005700                  SB4:    TST     R0              ;CHECK EFFECT ON REG.
012430  001401                          BEQ     TS201
012432  104000                          EMT                     ;REGISTER VALUE INCORRECT
                                ;
                                ;*****************************************************************************
                                ;
                                ;       THIS TEST VERIFIES MODE 5 SWAB INSTRUCTION.  THE TEST USES
                                ;TWO LOCATIONS FOLLOWING THE TEST CODE.  SB5X HOLDS THE DATA;
                                ;SB5XAD IS A POINTER TO THE DATA LOCATION.  THE DATA IS MOVED TO
                                ;SB5X AND R0 IS SET TO TWO PLUS THE ADDRESS OF SB5XAD.  FOLLOWING
                                ;THE MODE 5 SWAB SB5X IS CHECKED FOR THE PROPER DATA.  R0 IS
                                ;CHECKED TO SEE THAT IT WAS DECREMENTED PROPERLY.
                                ;
                                ;*****************************************************************************
                                ;TEST 201       TEST MODE 5 W/ SWAB INST.
                                ;*****************************************************************************
012434                          TS201:
012434  012700  012476                  MOV     #SB5XAD+2,R0    ;SET UP POINTER TO WORK LOCATION
012440  012767  125125  000024          MOV     #125125,SB5X    ;MOVE PATTERN TO WORK LOCATION
012446  000350                          SWAB    @-(R0)          ;TRY SWAB MODE 5
012450  022767  052652  000014          CMP     #52652,SB5X     ;CHECK RESULT
012456  001401                          BEQ     SB5A
012460  104000                          EMT                     ;RESULT OF SWAB INCORRECT
012462  020027  012474          SB5A:   CMP     R0,#SB5XAD      ;CHECK RESULT OF REG.
```

```
3945  012466  001403                        BEQ     TS202
3946  012470                        SB5:
3947  012470  104000                        EMT                     ;REGISTER VALUE INCORRECT
3948  012472  000000                SB5X:   0                       ;WORK LOCATION
3949  012474  012472                SB5XAD: SB5X
3950
3951
3952                                ;*******************************************************************************
3953                                ;
3954                                ;       THIS TEST VERIFIES MODE 6 SWAB INSTRUCTION.  THIS TEST
3955                                ;USES A WORK LOCATION (SB6X) FOLLOWING THE TEST CODE.  TEST DATA
3956                                ;IS LOADED INTO THE WORK LOCATION.  R0, THE ADDRESSING REGISTER
3957                                ;IS LOADED WITH 6 LESS THEN THE ADDRESS OF THE WORK LOCATION.
3958                                ;THE MODE 6 SWAB IS EXECUTED WITH A +6 OFFSET.  THE DATA IS
3959                                ;VERIFIED WITH A COMPARE.
3960                                ;
3961                                ;*******************************************************************************
3962                                ;TEST 202       TEST MODE 6 W/ SWAB INST.
3963                                ;*******************************************************************************
3964  012476                        TS202:
3965  012476  012767  125125  000022        MOV     #125125,SB6X    ;MOVE PATTERN TO WORK LOCATION
3966  012504  012700  012520                MOV     #SB6X-6,R0      ;MOVE OFFSET POINTER TO R0
3967  012510  000360  000006                SWAB    6(R0)           ;TRY SWAB W/ MODE 6
3968  012514  022760  052652  000006        CMP     #52652,6(R0)    ;CHECK RESULT
3969  012522  001402                        BEQ     TS203
3970  012524                        SB6:
3971  012524  104000                        EMT                     ;RESULT OF SWAB INCORRECT
3972  012526  000000                SB6X:   0                       ;WORK LOCATION
3973
3974
3975                                ;*******************************************************************************
3976                                ;
3977                                ;       THIS TEST VERIFIES MODE 7 SWAB INSTRUCTION.  THIS TEST
3978                                ;USES TWO LOCATIONS FOLLOWING THE TEST CODE:  A WORK LOCATION
3979                                ;(SB.X) AND A POINTER TO THE WORK LOCATION (SB7XAD).  DATA IS MOVED
3980                                ;TO THE WORK LOCATION.  R0 IS LOADED WITH 72 LESS THAN THE ADDRESS
3981                                ;OF THE ADDRESS POINTER.  THE DATA IS SWAB'ED USING A MODE 7
3982                                ;INSTRUCTION WITH AN OFFSET OF +72.  THE DATA IS VERIFIED WITH A
3983                                ;COMPARE.
3984                                ;
3985                                ;*******************************************************************************
3986                                ;TEST 203       TEST MODE 7 W/ SWAB INST.
3987                                ;*******************************************************************************
3988  012530                        TS203:
3989  012530  012767  177400  000022        MOV     #177400,SB7X    ;MOVE PATTERN TO WORK LOCATION
3990  012536  012700  012470                MOV     #SB7XAD-72,R0   ;MOVE OFFSET POINTER TO R0
3991  012542  000370  000072                SWAB    @72(R0)         ;TRY SWAB MODE 7
3992  012546  027027  000072  000377        CMP     @72(R0),#377    ;CHECK RESULTS
3993  012554  001403                        BEQ     TS204
3994  012556                        SB7:
3995  012556  104000                        EMT                     ;RESULT OF SWAB INCORRECT
3996  012560  000000                SB7X:   0                       ;WORK LOCATION
3997  012562  012560                SB7XAD: SB7X                    ;POINTER TO WORK LOCATION
3998
3999
4000                                ;*******************************************************************************
```

```
4001                                    ;
4002                                    ;       THIS TEST VERIFIES ALL LEGAL MODES OF THE JMP INSTRUCTION.
4003                                    ;BECAUSE OF THE NATURE OF THE INSTRUCTION UNDER TEST, THIS TEST
4004                                    ;UTILIZES SEVERAL DIFFERENT TECHNIQUES.  THE CODE IS NOT EXECUTED
4005                                    ;IN A LINEAR FASHION.  THE DIFFERENT MODES ARE EXECUTED IN ORDER
4006                                    ;FROM 1-7; HOWEVER, THE CODE IS ARRANGED SO THAT CONTROL LEAP
4007                                    ;FROGS THRU THE TEST CODE.  THE ORDER OF APPEARANCE OF THE CODE
4008                                    ;IS:
4009                                    ;       JMP MODE 1
4010                                    ;       JMP MODE 3
4011                                    ;       JMP MODE 2
4012                                    ;       JMP MODE 4
4013                                    ;       JMP MODE 6
4014                                    ;       JMP MODE 5
4015                                    ;       JMP MODE 7
4016                                    ;AN INTERNAL SEQUENCE TEST (JMPSEQ) IS USED TO INSURE THAT THE
4017                                    ;JUMPS ARE OCCURRING IN THE PROGRAMMED SEQUENCE.
4018                                    ;       THE TEST IS MADE UP OF SEVERAL BLOCKS OF CODE.  EACH CODE
4019                                    ;BEGINS WITH A LABEL WHICH INDICATES THE MODE BEING EXECUTED IN
4020                                    ;THAT BLOCK.  A SIMPLE PROCEDURE IS FOLLOWED IN EACH BLOCK.  FOR
4021                                    ;EXAMPLE THE CODE BEGINNING AT JMP3 WILL FIRST COMPARE THE RESULTS
4022                                    ;OF THE PREVIOUS MODE 2 JUMP.  (ANY REGISTER CHANGES ARE VERIFIED
4023                                    ;AND THE SEQUENCE CHECK IS MADE).  THEN THE REGISTERS ARE SETUP
4024                                    ;FOR A MODE 3 JUMP TO THE NEXT TEST BLOCK (HERE, JMP4), THE SEQUENCE
4025                                    ;CHECKER IS UPDATED AND THE JUMP IS EXECUTED.
4026                                    ;       IF A FAILURE OCCURS, THE SEQUENCE CHECKER WILL ASSIST IN
4027                                    ;DETERMINING JUST WHICH MODE FAILED.  IF THE SEQUENCE IS CORRECT
4028                                    ;THEN THE ERROR DETECTED WAS A MODE FAILURE (E.G. FAILURE OF THE
4029                                    ;REGISTER TO BE INCREMENTED IN MODE 2 JUMP.)
4030                                    ;
4031                                    ;*****************************************************************************************
4032                                    ;TEST 204       TEST THE JMP INSTRUCTION IN ALL MODES
4033                                    ;*****************************************************************************************
4034  012564                            TS204:
4035  012564  005067  000240                   CLR     JMPSEQ          ;ESTABLISH A SEQUENCE CHECKER
4036  012570  012700  012634                   MOV     #JMP2,R0        ;SET R0=JUMP TARGET
4037  012574  000110                           JMP     (R0)            ;TRY JMP MODE 1
4038  012576  022700  012600           JMP3:   CMP     #.+2,R0         ;CHECK RESULT OF MODE 2 JUMP
4039  012602  001401                           BEQ     JMP3A
4040  012604  104000                           EMT                     ;REGISTER VALUE AFTER JMP MODE 2 INCORRECT
4041  012606  026727  000216  000001  JMP3A:  CMP     JMPSEQ,#1       ;MAKE SURE JMPS ARE IN SEQUENCE: JMPSEQ=1?
4042  012614  001401                           BEQ     JMP3B
4043  012616  104000                           EMT                     ;SHOULD BE HERE FROM JMP MODE 2 ONLY
4044  012620  012700  012632           JMP3B:  MOV     #IJMP4,R0       ;POINT R0 TO INDIRECT JMP ADDR.
4045  012624  005267  000200                   INC     JMPSEQ          ;UPDATE SEQUENCE CHECKER
4046  012630  000130                           JMP     @(R0)+          ;TRY JMP MODE 3
4047  012632  012656                   IJMP4:  JMP4                    ;ADDRESS INDIRECT JUMP
4048
4049  012634  005767  000170           JMP2:   TST     JMPSEQ          ;CHECK THAT JMPS ARE IN SEQUENCE: JMPSEQ=0?
4050  012640  001401                           BEQ     JMP2A
4051  012642  104000                           EMT                     ;SHOULD BE HERE FROM JMP MODE 1 ONLY
4052  012644  005267  000160           JMP2A:  INC     JMPSEQ          ;UPDATE SEQUENCE CHECKER
4053  012650  012700  012576                   MOV     #JMP3,R0        ;SET R0=JUMP TARGET
4054  012654  000120                           JMP     (R0)+           ;TRY A JUMP MODE 2 TO "JMP3"
4055  012656  022700  012634           JMP4:   CMP     #IJMP4+2,R0     ;CHECK RESULT OF REGISTER IN MODE 3 JUMP
4056  012662  001401                           BEQ     JMP4A
```

```
4057  012654  104000                        EMT                     ;REGISTER VALUE AFTER MODE 3 JUMP INCORRECT
4058  012656  022767  000002  000134  JMP4A: CMP     #2,JMPSEQ       ;CHECK JUMP SEQUENCE: JMPSEQ=2?
4059  012664  001401                        BEQ     JMP4B
4060  012666  104000                        EMT                     ;SHOULD BE ONLY FROM MODE 3 JUMP
4061  012700  012700  012742        JMP4B: MOV     #JMP5+2,R0      ;SET UP POINTER TO JUMP TARGET
4062  012704  005267  000120              INC     JMPSEQ          ;UPDATE SEQUENCE CHECKER
4063  012710  000140                      JMP     -(R0)           ;TRY JUMP MODE 4 TO "JMP4"
4064
4065  012712  022767  000004  000110  JMP6:  CMP     #4,JMPSEQ       ;CHECK THAT JUMPS ARE IN SEQUENCE: JMPSEQ=4?
4066  012720  001401                        BEQ     JMP6A
4067  012722  104000                        EMT                     ;SHOULD BE HERE ONLY FROM MODE 5 JUMP
4068  012724  012700  013364        JMP6A: MOV     #JMP7+376,R0    ;SET UP OFFSET POINTER TO JUMP TARGET
4069  012730  005267  000074              INC     JMPSEQ          ;UPDATE JUMP SEQUENCE
4070  012734  000160  177402              JMP     -376(R0)        ;TRY MODE 6 JUMP
4071
4072  012740  022767  000003  000062  JMP5:  CMP     #3,JMPSEQ       ;CHECK THAT JUMPS ARE IN SEQUENCE: JMPSEQ=3?
4073  012746  001401                        BEQ     JMP5A
4074  012750  104000                        EMT                     ;SHOULD ONLY BE HERE FROM MODE 4 JUMP
4075  012752  012700  012766        JMP5A: MOV     #IJMP5+2,R0     ;SET UP POINTER TO INDIRECT JUMP ADDR.
4076  012756  005267  000046              INC     JMPSEQ          ;UPDATE JUMP SEQUENCE
4077  012762  000150                      JMP     @-(R0)          ;TRY JUMP MODE 5 TO "JMP6"
4078  012764  012712              IJMP5:  JMP6                    ;INDIRECT ADDRESS POINTER
4079
4080  012766  022767  000005  000034  JMP7:  CMP     #5,JMPSEQ       ;CHECK JUMPS IN SEQUENCE: JMPSEQ=5?
4081  012774  001401                        BEQ     JMP7A
4082  012776  104000                        EMT                     ;SHOULD ONLY BE HERE FROM MODE 6 JUMP
4083  013000  012700  013024        JMP7A: MOV     #IJMP+10,R0     ;SET UP OFFSET POINTER TO INDIRECT ADDR.
4084  013004  005267  000020              INC     JMPSEQ          ;UPDATE JUMP SEQUENCE
4085  013010  000170  177770              JMP     @-10(R0)        ;TRY MODE 7 JUMP
4086  013014  013016              IJMP:   JMPCK                   ;INDIRECT ADDRESS
4087
4088  013016  026727  000006  000006  JMPCK: CMP     JMPSEQ,#6       ;CHECK JUMPS IN SEQUENCE: JMPSEQ
4089  013024  001402                        BEQ     TS205
4090  013026  104000                        EMT                     ;SHOULD ONLY BE HERE FROM MODE 6 JUMP
4091  013030  000000              JMPSEQ: 0
4092
4093                                ;*******************************************************************************
4094                                ;
4095                                ;       THIS TEST VERIFIES ALL LEGAL MODES OF THE JSR INSTRUCTION.
4096                                ;THE CONCEPT OF LEAP FROGGING AND SEQUENCE CHECKING (JSRSEQ) IS
4097                                ;IDENTICAL TO THAT USED IN JMP TEST (SEE PREVIOUS TEST).  EACH
4098                                ;BLOCK OF CODE VERIFIES THE PREVIOUS JSR BY CHECKING THE SEQUENCE,
4099                                ;CHECKING THAT THE PC WAS SAVED IN THE SPECIFIED REGISTER, CHECKING
4100                                ;THAT THE SP WAS DECREMENTED, CHECKING THAT THE REGISTER WAS
4101                                ;SAVED ON THE STACK, AND FINALLY CHECKING THAT ANY MODE ADDRESS
4102                                ;REGISTER ALTERATIONS (E.G. INCREMENT REGISTER IN MODE 2) WERE
4103                                ;SUCCESSFUL.  R1 IS USED AS THE REGISTER IN ALL JSR INSTRUCTIONS.
4104                                ;       IF A FAILURE OCCURS, THE SEQUENCE CHECKER WILL ASSIST IN
4105                                ;DETERMINING JUST WHICH MODE FAILED.  IF THE SEQUENCE IS CORRECT
4106                                ;THEN THE ERROR DETECTED WAS A FUNCTIONAL FAILURE (E.G., INCORRECT
4107                                ;REGISTER SAVED).
4108                                ;
4109                                ;*******************************************************************************
4110                                ;TEST 205       TEST JSR INSTRUCTION W/ ALL MODES
4111                                ;*******************************************************************************
4112  013032                        TS205:
```

```
 4113  013032  000402                    BR      JSR1
 4114  013034  000137  013416    JSR0:   JMP     @#JSRCK1
 4115
 4116  013040  012706  001000    JSR1:   MOV     #STBOT,R6       ;SET STACK POINTER
 4117  013044  012700  013136            MOV     #JSR2,R0        ;SET TARGET ADDRESS
 4118  013050  005037  013376            CLR     @#JSRSEQ        ;INITIALIZE SEQUENCE CHECKER
 4119  013054  005001                    CLR     R1              ;INITIALIZE R1
 4120  013056  005101                    COM     R1
 4121  013060  004110                    JSR     R1,(R0)         ;TRY JSR MODE 1
 4122                                                            ; TO SCOPE: REPLACE THE MOVE INSTRUCTION   <====
 4123                                                            ;           FOLLOWING W/ 774               <====
 4124  013062                    JSR1A:
 4125  013062  104000                    EMT                     ;JSR MODE 1 FAILED
 4126
 4127  013064  022737  000001  013376 JSR3:   CMP     #1,@# JSRSEQ    ;CHECK SEQUENCE: JSRSEQ=1?
 4128  013072  001014                    BNE     JSR3A           ;BRANCH IF OUT OF SEQUENCE
 4129  013074  020127  013212            CMP     R1,#JSR4        ;PROPER PC SAVED?
 4130  013100  001011                    BNE     JSR3A           ;BRANCH IF PC WRONG
 4131  013102  022706  000776            CMP     #STBOT-2,R6     ;STACK POINTER DECREMENTED?
 4132  013106  001006                    BNE     JSR3A           ;BRANCH IF SP WRONG
 4133  013110  022716  125252            CMP     #125252,(R6)    ;REG SAVED ON STACK?
 4134  013114  001003                    BNE     JSR3A           ;BRANCH IF REG. NOT SAVED
 4135  013116  022700  013066            CMP     #JSR3+2,R0      ;MODE 2 INCREMENT CORRECT?
 4136  013122  001401                    BEQ     JSR3B
 4137  013124                    JSR3A:
 4138  013124  104000                    EMT                     ;JSR MODE 3 MALFUNCTIONED
 4139  013126  005237  013376    JSR3B:  INC     @#JSRSEQ        ;UPDATE SEQUENCE CHECKER
 4140  013132  004137  013212            JSR     R1,@#JSR4       ;TRY JSR MODE 4
 4141
 4142  013136  005737  013376    JSR2:   TST     @#JSRSEQ        ;CHECK SEQUENCE: JSRSEQ=0?
 4143  013142  001011                    BNE     JSR2A           ;BRANCH IF OUT OF SEQUENCE
 4144  013144  020127  013062            CMP     R1,#JSR1A       ;PROPER PC SAVED?
 4145  013150  001006                    BNE     JSR2A           ;BRANCH IF PC WRONG
 4146  013152  022706  000776            CMP     #STBOT-2,R6     ;R6 DECREMENT?
 4147  013156  001003                    BNE     JSR2A           ;BRANCH IF R6 IS INCORRECT
 4148  013160  021627  177777            CMP     (R6),#-1        ;REGISTER SAVED?
 4149  013164  001401                    BEQ     JSR2B
 4150  013166                    JSR2A:
 4151  013166  104000                    EMT                     ;JSR MODE 1 MALFUNCTIONED
 4152  013170  012706  001000    JSR2B:  MOV     #STBOT,R6       ;INITIALIZE R6
 4153  013174  012701  125252            MOV     #125252,R1      ;INITIALIZE R1
 4154  013200  005237  013376            INC     @#JSRSEQ        ;UPDATE SEQUENCE CHECKER
 4155  013204  012700  013064            MOV     #JSR3,R0        ;SET TARGET ADDRESS
 4156  013210  004120                    JSR     R1,(R0)+        ;TRY JSR MODE 2
 4157
 4158  013212  022737  000002  013376 JSR4:   CMP     #2,@#JSRSEQ     ;CHECK SEQUENCE: JSRSEQ=2?
 4159  013220  001003                    BNE     JSR4A           ;BRANCH IF OUT OF SEQUENCE
 4160  013222  022701  013136            CMP     #JSR2,R1        ;PROPER PC SAVED?
 4161  013226  001401                    BEQ     JSR4B
 4162  013230                    JSR4A:
 4163  013230  104000                    EMT                     ;JSR MODE 3 MALFUNCTIONED
 4164  013232  005237  013376    JSR4B:  INC     @#JSRSEQ        ;UPDATE SEQUENCE CHECKER
 4165  013236  012700  013304            MOV     #JSR5+2,R0      ;SET TARGET ADDRESS
 4166  013242  004140                    JSR     R1,-(R0)        ;TRY JSR MODE 4
 4167
 4168  013244  022767  000004  000124 JSR6:   CMP     #4,JSRSEQ       ;CHECK SEQUENCE: JSRSEQ=4?
```

```
4169  013252  001006                        BNE     JSR6A           ;BRANCH IF OUT OF SEQUENCE
4170  013254  022701  013342                CMP     #JSR7,R1        ;PROPER PC SAVED?
4171  013260  001003                        BNE     JSR6A           ;BRANCH IF PC WRONG
4172  013262  022700  013372                CMP     #JSR6AD,R0      ;MODE 5 REGISTER CORRECT?
4173  013266  001401                        BEQ     JSR6B
4174  013270                        JSR6A:
4175  013270  104000                        EMT                     ;JSR MODE 5 FAILED
4176  013272  005237  013376        JSR6B:  INC     @#JSRSEQ        ;UPDATE SEQUENCE CHECKER
4177  013276  004167  000040                JSR     R1,JSR7         ;TRY JSR MODE 6
4178  013302  022767  000003  000066 JSR5:  CMP     #3,JSRSEQ       ;CHECK SEQUENCE: JSRSEQ=3?
4179  013310  001006                        BNE     JSR5A           ;BRANCH IF OUT OF SEQUENCE
4180  013312  022701  013244                CMP     #JSR6,R1        ;PROPER PC SAVED?
4181  013316  001003                        BNE     JSR5A           ;BRANCH IF PC WRONG
4182  013320  022700  013302                CMP     #JSR5,R0        ;CHECK MODE 4 REGISTER
4183  013324  001401                        BEQ     JSR5B
4184  013326                        JSR5A:
4185  013326  104000                        EMT                     ;JSR MODE 4 MALFUNCTIONED
4186  013330  005237  013376        JSR5B:  INC     @#JSRSEQ        ;UPDATE SEQUENCE CHECKER
4187  013334  012700  013374                MOV     #JSR6AD+2,R0    ;POINT R0 TO TARGET ADDRESS
4188  013340  004150                        JSR     R1,@-(R0)       ;TRY JSR MODE 5
4189
4190  013342  022737  000005  013376 JSR7:  CMP     #5,@#JSRSEQ     ;CHECK SEQUENCE: JSRSEQ=5?
4191  013350  001003                        BNE     JSR7A           ;BRANCH IF OUT OF SEQUENCE
4192  013352  022701  013302                CMP     #JSR5,R1        ;PROPER PC SAVED?
4193  013356  001401                        BEQ     JSR7B
4194  013360                        JSR7A:
4195  013360  104000                        EMT                     ;JSR MODE 6 FAILED
4196  013362  005237  013376        JSR7B:  INC     @#JSRSEQ        ;UPDATE SEQUENCE CHECKER
4197  013366  004177  000002                JSR     R1,@JSRCKAD     ;TRY JSR MODE 7
4198
4199  013372  013244                JSR6AD: JSR6                    ;MODE 5 TARGET ADDRESS
4200  013374  013400                JSRCKAD:JSRCK                   ;MODE 7 TARGET ADDRESS
4201  013376  000000                JSRSEQ: 0                       ;SEQUENCE CHECKER
4202
4203  013400  022767  000006  177770 JSRCK:  CMP     #6,JSRSEQ       ;CHECK SEQUENCE: JSRSEQ=6?
4204  013406  001003                        BNE     JSRCK1          ;BRANCH IF OUT OF SEQUENCE
4205  013410  022701  013372                CMP     #JSR6AD,R1      ;PROPER PC SAVED?
4206  013414  001401                        BEQ     TS206
4207  013416                        JSRCK1:
4208  013416  104000                        EMT                     ;JSR MODE 7 MALFUNCTIONED
4209
4210
4211                                ;*******************************************************************************
4212                                ;
4213                                ;       THIS TEST VERIFIES THE RTS INSTRUCTION.  THE STACK POINTER
4214                                ;IS INITIALIZED AND A TEST PATTERN STORED ON STACK.  R0 IS LOADED
4215                                ;WITH RETURN ADDRESS.  AN RTS IS EXECUTED, AND, AT THE TARGET
4216                                ;ADDRESS, A CHECK IS MADE THAT R0 WAS PROPERLY RESTORED FROM THE
4217                                ;STACK.
4218                                ;*******************************************************************************
4219                                ;TEST 206       TEST RTS INSTRUCTION
4220                                ;*******************************************************************************
4221  013420                        TS206:
4222  013420  012706  001000                MOV     #STBOT,R6       ;INITIALIZE STACK POINTER
4223  013424  012746  052525                MOV     #52525,-(R6)    ;INITIALIZE TOP OF STACK
4224  013430  012700  013440                MOV     #RTS1,R0        ;INITIALIZE RETURN REGISTER
```

```
4225  013434  000200                  RTS     R0              ;TRY RTS THROUGH R0
4226                                                          ; TO SCOPE: REPLACE THE MOVE INSTRUCTION   <====
4227                                                          ;           FOLLOWING W/ 770               <====
4228  013436  104000                  EMT                     ;RTS FAILED
4229  013440  022700  052525  RTS1:   CMP     #52525,R0       ;CHECK THAT R0 RESTORED FROM STACK
4230  013444  001401                  BEQ     TS207
4231  013446  104000                  EMT                     ;RTS MALFUNCTIONED
4232                                ;*************************************************************************************
4233                                ;
4234                                ;       THESE NEXT FOUR TESTS VERIFY THE FUNCTIONING OF A GROUP
4235                                ;OF FOUR INSTRUCTIONS.  THE GROUP CONSISTS OF THE INSTRUCTIONS:
4236                                ;MOV, BIC, BIT, AND BIS.  THESE INSTRUCTIONS ARE SIMILAR IN THE
4237                                ;WAY THEY EFFECT THE C AND V BITS.  THEY ALL LEAVE THE V-BIT
4238                                ;CLEAR AND THE C-BIT UNAFFECTED.
4239                                ;       THE TEST PROCEDURE IS AS FOLLOWS:  THE N, Z, AND V BITS
4240                                ;ARE LOADED WITH THE COMPLEMENT OF THE EXPECTED RESULTS, THE C-BIT
4241                                ;IS LOADED WITH THE DESIRED RESULT.  THE INSTRUCTION IS EXECUTED
4242                                ;WITH DIFFERENT DATA PATTERNS AND THE RESULTS ARE VERIFIED WITH
4243                                ;A SERIES OF CONDITIONAL BRANCH INSTRUCTIONS.  THE DATA IS CHOSEN
4244                                ;TO PRODUCT ALL POSSIBLE COMBINATIONS OF THE C AND V BITS.
4245                                ;
4246                                ;*************************************************************************************
4247                                ;TEST 207       TEST MOV INSTRUCTION
4248                                ;*************************************************************************************
4249  013450                        TS207:
4250  013450  000277                  SCC                     ;CC=0110
4251  013452  000251                  +CLN!CLC
4252  013454  012700  100000          MOV     #100000,R0      ;CC=1000
4253  013460  101402                  BLOS    MOV1
4254  013462  102401                  BVS     MOV1
4255  013464  100401                  BMI     MOV2
4256  013466                        MOV1:
4257  013466  104000                  EMT                     ;MOV DID NOT SET CC'S CORRECTLY
4258
4259  013470  000277                MOV2:   SCC                     ;CC=1011
4260  013472  000244                  CLZ
4261  013474  012700  000000          MOV     #0,R0           ;CC=0101
4262  013500  101002                  BHI     MOV3            ;C OR Z = 0?
4263  013502  102401                  BVS     MOV3            ;V=1?
4264  013504  100001                  BPL     TS210
4265  013506                        MOV3:
4266  013506  104000                  EMT                     ;MOV DID NOT SET CC'S CORRECTLY
4267                                ;*************************************************************************************
4268                                ;TEST 210       TEST BIT INSTRUCTION
4269                                ;*************************************************************************************
4270  013510                        TS210:
4271  013510  012700  100001          MOV     #100001,R0
4272  013514  000277                  SCC                     ;CC=0110
4273  013516  000251                  +CLN!CLC
4274  013520  032700  100000          BIT     #100000,R0      ;CC=1000
4275  013524  101402                  BLOS    BITST1
4276  013526  102401                  BVS     BITST1
4277  013530  100401                  BMI     BITST2
4278  013532                        BITST1:
4279  013532  104000                  EMT                     ;BIT DID NOT SET CC'S CORRECTLY
4280
```

```
 4281  013534  000277                BITST2: SCC                     ;CC=1011
 4282  013536  000244                        CLZ
 4283  013540  032700  077776              BIT     #77776,R0       ;CC=0101
 4284  013544  101002                      BHI     BITST3
 4285  013546  102401                      BVS     BITST3
 4286  013550  100001                      BPL     TS211
 4287  013552                        BITST3:
 4288  013552  104000                      EMT                     ;BIT DID NOT SET CC'S CORRECTLY
 4289                                ;******************************************************************************
 4290                                ;TEST 211       TEST BIC INSTRUCTION
 4291                                ;******************************************************************************
 4292  013554                        TS211:
 4293  013554  012700  177777              MOV     #177777,R0
 4294  013560  000277                      SCC                     ;CC=0110
 4295  013562  000251                      +CLN!CLC
 4296  013564  042700  077777              BIC     #77777,R0       ;CC=1000
 4297  013570  101402                      BLOS    BIC1
 4298  013572  102401                      BVS     BIC1
 4299  013574  100401                      BMI     BIC2
 4300  013576                        BIC1:
 4301  013576  104000                      EMT                     ;BIC DID NOT SET CC'S CORRECTLY
 4302  013600  000277                BIC2: SCC                     ;CC=1011
 4303  013602  000244                      CLZ
 4304  013604  042700  100000              BIC     #100000,R0      ;CC=0101
 4305  013610  101002                      BHI     BIC3
 4306  013612  102401                      BVS     BIC3
 4307  013614  100001                      BPL     TS212
 4308  013616                        BIC3:
 4309  013616  104000                      EMT                     ;BIC DID NOT SET CC'S CORRECTLY
 4310                                ;******************************************************************************
 4311                                ;TEST 212       TEST BIS INSTRUCTION
 4312                                ;******************************************************************************
 4313  013620                        TS212:
 4314  013620  005000                      CLR     R0              ;R0=0
 4315  013622  000277                      SCC                     ;CC=1010
 4316  013624  000251                      +CLN!CLC
 4317  013626  052700  000000              BIS     #0,R0           ;CC=0100  R0=0
 4318  013632  103403                      BCS     BIS1
 4319  013634  102402                      BVS     BIS1
 4320  013636  100401                      BMI     BIS1
 4321  013640  001401                      BEQ     BIS2
 4322  013642                        BIS1:
 4323  013642  104000                      EMT                     ;BIS DID NOT SET CC'S CORRECTLY
 4324  013644  000277                BIS2: SCC                     ;CC=0111
 4325  013646  000250                      CLN
 4326  013650  052700  177777              BIS     #177777,R0      ;CC=1001
 4327  013654  103003                      BCC     BIS3
 4328  013656  102402                      BVS     BIS3
 4329  013660  001401                      BEQ     BIS3
 4330  013662  100401                      BMI     TS213
 4331  013664                        BIS3:
 4332  013664  104000                      EMT                     ;BIS DID NOT SET CC'S CORRECTLY
 4333
 4334                                ;******************************************************************************
 4335                                ;
 4336                                ;       THESE NEXT TWO TESTS VERIFY THE FUNCTIONING OF THE INC AND
```

```
                                ;DEC INSTRUCTIONS.  THESE INSTRUCTIONS BOTH EFFECT THE C AND V
                                ;BITS THE SAME; THE C-BIT IS LEFT UNCHANGED AND THE V-BIT IS DEPENDENT
                                ;UPON THE DATA RESULTS.  THE SAME PROCEDURE IS USED.  THE CONDITION
                                ;CODE BITS ARE INITIALIZED, THE INSTRUCTION IS EXECUTED AND THE
                                ;RESULTS ARE VERIFIED WITH A SERIES OF CONDITIONAL BRANCH INSTRUCTIONS.
                                ;THIS PROCEDURE IS REPEATED WITH SEVERAL DATA PATTERNS TO PRODUCE
                                ;DIFFERENT COMBINATIONS OF THE C AND V BITS.
                                ;
                                ;*****************************************************************************
                                ;TEST 213        TEST INC INSTRUCTION
                                ;*****************************************************************************
013666                          TS213:
013666  012700  077777                  MOV     #077777,R0      ;R0=077777
013672  000257                          CCC                     ;CC=0100
013674  000264                          SEZ
013676  005200                          INC     R0              ;CC=1010   R0=10000
013700  101402                          BLOS    INC1
013702  100001                          BPL     INC1
013704  102401                          BVS     INC2
013706                          INC1:
013706  104000                          EMT                     ;INC DID NOT SET CC'S CORRECTLY
013710  052700  077777          INC2:   BIS     #77777,R0       ;R0=177777
013714  000261                          SEC                     ;CC=1011
013716  000244                          CLZ
013720  005200                          INC     R0              ;CC=0101   R0=0
013722  100403                          BMI     INC3
013724  102402                          BVS     INC3
013726  103001                          BCC     INC3
013730  001401                          BEQ     INC4
013732                          INC3:
013732  104000                          EMT                     ;INC DID NOT SET CC'S CORRECTLY
                                
013734  000277                  INC4:   SCC                     ;CC=1110
013736  000241                          CLC
013740  005200                          INC     R0              ;CC=0000   R0=1
013742  101402                          BLOS    INC5
013744  100401                          BMI     INC5
013746  100001                          BPL     TS214
013750                          INC5:
013750  104000                          EMT                     ;INC DID NOT SET CC'S CORRECTLY
                                
                                ;*****************************************************************************
                                ;TEST 214        TEST DEC INSTRUCTION
                                ;*****************************************************************************
013752                          TS214:
013752  012700  000002                  MOV     #2,R0           ;R0=2
013756  000277                          SCC                     ;CC=1111
013760  005300                          DEC     R0              ;CC=0001   R0=1
013762  100403                          BMI     DEC1
013764  001402                          BEQ     DEC1
013766  102401                          BVS     DEC1
013770  103401                          BCS     DEC2
013772                          DEC1:
013772  104000                          EMT                     ;DEC DID NOT SET CC'S CORRECTLY
013774  000261                  DEC2:   SEC                     ;CC=1011
013776  000244                          CLZ
```

```
 4393  014000  005300                    DEC     R0              ;CC=0101   R0=0
 4394  014002  101002                    BHI     DEC3
 4395  014004  100401                    BMI     DEC3
 4396  014006  102001                    BVC     DEC4
 4397  014010                    DEC3:
 4398  014010  104000                    EMT                     ;DEC DID NOT SET CC'S CORRECTLY
 4399  014012  000277            DEC4:   SCC                     ;CC=0110
 4400  014014  000251                    +CLN!CLC
 4401  014016  005300                    DEC     R0              ;CC=1000   R0=177777
 4402  014020  101402                    BLOS    DEC5
 4403  014022  102401                    BVS     DEC5
 4404  014024  100401                    BMI     DEC6
 4405  014026                    DEC5:
 4406  014026  104000                    EMT                     ;DEC DID NOT SET CC'S CORRECTLY
 4407  014030  042700  077777    DEC6:   BIC     #77777,R0       ;R0=100000
 4408  014034  000277                    SCC                     ;CC=0101
 4409  014036  000252                    +CLN!CLV
 4410  014040  005300                    DEC     R0              ;CC=1011   R0=77777
 4411  014042  100403                    BMI     DEC7            ;CC=0011
 4412  014044  001402                    BEQ     DEC7
 4413  014046  102001                    BVC     DEC7
 4414  014050  103401                    BCS     TS215
 4415  014052                    DEC7:
 4416  014052  104000                    EMT                     ;DEC DID NOT SET CC'S CORRECTLY
 4417
 4418
 4419                            ;*****************************************************************************************
 4420                            ;
 4421                            ;       THESE NEXT THREE TESTS VERIFY THE FUNCTIONING OF THE CLR,
 4422                            ;TST, AND SWAB INSTRUCTIONS.  THESE THREE INSTRUCTIONS ALL LEAVE
 4423                            ;THE C AND V BITS CLEARED.  AGAIN, THE CONDITION CODES ARE PRESET,
 4424                            ;THE INSTRUCTION EXECUTED AND THE RESULTS CHECKED WITH CONDITIONAL
 4425                            ;BRANCH INSTRUCTIONS.  THE PROCEDURE IS REPEATED TO PRODUCE OTHER
 4426                            ;COMBINATIONS OF CONDITION CODES.
 4427                            ;
 4428                            ;*****************************************************************************************
 4429                            ;TEST 215       TEST CLR INSTRUCTION
 4430                            ;*****************************************************************************************
 4431  014054                    TS215:
 4432  014054  000277                    SCC                     ;CC=1011
 4433  014056  000244                    CLZ
 4434  014060  005000                    CLR     R0              ;CC=0100   R0=0
 4435  014062  100403                    BMI     CLR1
 4436  014064  102402                    BVS     CLR1
 4437  014066  103401                    BCS     CLR1
 4438  014070  001401                    BEQ     TS216
 4439  014072                    CLR1:
 4440  014072  104000                    EMT                     ;CLR DID NOT SET CC'S CORRECTLY
 4441
 4442                            ;*****************************************************************************************
 4443                            ;TEST 216       TEST TST INSTRUCTION
 4444                            ;*****************************************************************************************
 4445  014074                    TS216:
 4446  014074  000277                    SCC                     ;CC=1011
 4447  014076  000244                    CLZ
 4448  014100  005700                    TST     R0              ;CC=0100
```

```
4449  014102  100403                  BMI     TEST1
4450  014104  102402                  BVS     TEST1
4451  014106  103401                  BCS     TEST1
4452  014110  001401                  BEQ     TEST2
4453  014112                  TEST1:
4454  014112  104000                  EMT                     ;TEST DID NOT SET CC'S CORRECTLY
4455  014114  005300          TEST2:  DEC     R0              ;MAKE R0 NEGATIVE
4456  014116  000277                  SCC                     ;CC=0111
4457  014120  000250                  CLN
4458  014122  005700                  TST     R0              ;CC=1000
4459  014124  101402                  BLOS    TEST3
4460  014126  102401                  BVS     TEST3
4461  014130  100401                  BMI     TS217
4462  014132                  TEST3:
4463  014132  104000                  EMT                     ;TEST DID NOT SET CC'S CORRECTLY
4464                          ;*****************************************************************************
4465                          ;TEST 217       TEST SWAB INSTRUCTION
4466                          ;*****************************************************************************
4467  014134                  TS217:
4468  014134  012700  170000          MOV     #170000,R0      ;R0=170000
4469  014140  000277                  SCC                     ;CC=0111
4470  014142  000250                  CLN
4471  014144  000300                  SWAB    R0              ;CC=1000   R0=360
4472  014146  101402                  BLOS    SWB1
4473  014150  102401                  BVS     SWB1
4474  014152  100401                  BMI     SWB2
4475  014154                  SWB1:
4476  014154  104000                  EMT                     ;SWAB DID NOT SET CC'S CORRECTLY
4477  014156  000277          SWB2:   SCC                     ;CC=1011
4478  014160  000244                  CLZ
4479  014162  000300                  SWAB    R0              ;CC=0100   R0=170000
4480  014164  102403                  BVS     SWB3
4481  014166  103402                  BCS     SWB3
4482  014170  100401                  BMI     SWB3
4483  014172  001401                  BEQ     TS220
4484  014174                  SWB3:
4485  014174  104000                  EMT                     ;
4486
4487                          ;*****************************************************************************
4488                          ;
4489                          ;       THESE NEXT TWO TESTS VERIFY THE FUNCTIONING OF THE ADD AND
4490                          ;ADC INSTRUCTIONS.  BOTH OF THESE INSTRUCTIONS HANDLE THE C AND
4491                          ;V BITS IDENTICALLY.  THE PROCEDURE IS TO PRESET THE CONDITION
4492                          ;CODES, EXECUTE THE INSTRUCTION WITH A PARTICULAR SET OF DATA, AND
4493                          ;THEN CHECK THE RESULTS BY EXECUTING A SERIES OF CONDITIONAL
4494                          ;BRANCHES.  THES PROCEDURE IS REPEATED SEVERAL TIMES WITH DIFFERENT
4495                          ;DATA TO PRODUCE EVERY COMBINATION OF C AND V BITS.
4496                          ;
4497                          ;*****************************************************************************
4498                          ;TEST 220       TEST ADD INSTRUCTION
4499                          ;*****************************************************************************
4500  014176                  TS220:
4501  014176  012700  040000          MOV     #40000,R0       ;R0=40000
4502  014202  000277                  SCC                     ;CC=1111
4503  014204  062700  030000          ADD     #30000,R0       ;CC=0000   R0=70000
4504  014210  101402                  BLOS    ADD1
```

```
4505  014212  102401                  BVS     ADD1
4506  014214  100001                  BPL     ADD2
4507  014216                  ADD1:
4508  014216  104000                  EMT                     ;ADD DID NOT SET CC'S CORRECTLY
4509  014220  000264          ADD2:   SEZ                     ;CC=0100
4510
4511  014222  062700  010000          ADD     #10000,R0       ;CC=1010   40=100000
4512  014226  101402                  BLOS    ADD3
4513  014230  102001                  BVC     ADD3
4514  014232  100401                  BMI     ADD4
4515  014234                  ADD3:
4516  014234  104000                  EMT                     ;ADD DID NOT SET CC'S CORRECTLY
4517  014236  000257          ADD4:   CCC                     ;CC=1000
4518  014240  000270                  SEN
4519  014242  062700  100000          ADD     #100000,R0      ;CC=0111   R0=0
4520  014246  101002                  BHI     ADD5
4521  014250  102001                  BVC     ADD5
4522  014252  100001                  BPL     ADD6
4523  014254                  ADD5:
4524  014254  104000                  EMT                     ;ADD DID NOT SET CC'S CORRECTLY
4525  014256  062700  177777  ADD6:   ADD     #177777,R0      ;CC=1000   R0=177777
4526  014262  101402                  BLOS    ADD7
4527  014264  102401                  BVS     ADD7
4528  014266  100401                  BMI     ADD8
4529  014270                  ADD7:
4530  014270  104000                  EMT                     ;ADD DID NOT SET CC'S CORRECTLY
4531  014272  000277          ADD8:   SCC                     ;CC=1010
4532  014274  000245                  +CLC!CLZ
4533  014276  062700  000001          ADD     #1,R0           ;CC=0101   R=0
4534  014302  102403                  BVS     ADD9
4535  014304  103002                  BCC     ADD9
4536  014306  100401                  BMI     ADD9
4537  014310  001401                  BEQ     TS221
4538  014312                  ADD9:
4539  014312  104000                  EMT                     ;ADD DID NOT SET CC'S CORRECTLY
4540
4541                          ;*****************************************************************************
4542                          ;TEST 221       TEST ADC INSTRUCTION
4543                          ;*****************************************************************************
4544  014314                  TS221:
4545  014314  012700  077777          MOV     #077777,R0
4546  014320  000277                  SCC                     ;CC=0101
4547  014322  000252                  +CLN!CLV
4548  014324  005500                  ADC     R0              ;CC=1010
4549  014326  101402                  BLOS    ADC1
4550  014330  102001                  BVC     ADC1
4551  014332  100401                  BMI     ADC2
4552  014334                  ADC1:
4553  014334  104000                  EMT                     ;ADC DID NOT SET CC'S CORRECTLY
4554  014336  052700  077777  ADC2:   BIS     #77777,R0
4555  014342  000277                  SCC                     ;CC=1011
4556  014344  000244                  CLZ
4557  014346  005500                  ADC     R0              ;CC=0101   R0=0
4558  014350  101002                  BHI     ADC3
4559  014352  102401                  BVS     ADC3
4560  014354  100001                  BPL     ADC4
```

```
                                ADC3:
                                        EMT                     ;ADC DID NOT SET CC'S CORRECTLY
                                ADC4:   SCC
                                        +CLZ!CLC                        ;CC=1010
                                        ADC     R0              ;CC=0100
                                        BVS     ADC5
                                        BCS     ADC5
                                        BMI     ADC5
                                        BEQ     TS222
                                ADC5:
                                        EMT                     ;ADC DID NOT SET CC'S CORRECTLY

                                ;*******************************************************************************
                                ;
                                ;       THESE NEXT THREE TESTS VERIFY THE FUNCTIONING OF THE NEG,
                                ;CMP, AND COM INSTRUCTIONS.  EACH OF THESE INSTRUCTIONS GENERATE
                                ;THE C AND V BITS IDENTICALLY.  THE CONDITION CODES ARE PRESET,
                                ;THE INSTRUCTIONS EXECUTED, AND THE RESULTS CHECKED WITH A SERIES
                                ;OF CONDITIONAL BRANCH INSTRUCTIONS.  THIS PROCEDURE IS REPEATED
                                ;SEVERAL TIMES WITH DIFFERENT DATA IN ORDER TO GENERATE DIFFERENT
                                ;COMBINATIONS OF THE C AND V BITS.
                                ;
                                ;*******************************************************************************
                                ;TEST 222        TEST NEG INSTRUCTION
                                ;*******************************************************************************
                                TS222:
                                        MOV     #1,R0
                                        SCC                     ;CC=0110
                                        +CLN!CLC
                                        NEG     R0              ;CC=1001   R0=177777
                                        BCC     NEG1
                                        BVS     NEG1
                                        BEQ     NEG1
                                        BMI     NEG2
                                NEG1:
                                        EMT                     ;NEG DID NOT SET CC'S CORRECTLY
                                NEG2:   BIC     #77777,R0
                                        CCC                     ;CC=0100
                                        SEZ
                                        NEG     R0              ;CC=1011   R0=100000
                                        BVC     NEG3
                                        BCC     NEG3
                                        BEQ     NEG3
                                        BMI     NEG4
                                NEG3:
                                        EMT                     ;NEG DID NOT SET CC'S CORRECTLY
                                NEG4:   CLR     R0
                                        SCC                     ;CC=1011
                                        CLZ
                                        NEG     R0              ;CC=0100   R0=0
                                        BVS     NEG5
                                        BCS     NEG5
                                        BNE     NEG5
                                        BPL     TS223
                                NEG5:
                                        EMT                     ;NEG DID NOT SET CC'S CORRECTLY
```

```
 4617
 4618                                ;*****************************************************************************************
 4619                                ;TEST 223       TEST CMP INSTRUCTION
 4620                                ;*****************************************************************************************
 4621  014472                        TS223:
 4622  014472  012700  000005               MOV     #5,R0
 4623  014476  000257                       CCC                             ;CC=1010
 4624  014500  000271                       +SEN!SEC
 4625  014502  022700  000005               CMP     #5,R0                   ;CC=0101
 4626  014506  101002                       BHI     CMP1
 4627  014510  102401                       BVS     CMP1
 4628  014512  100001                       BPL     CMP2
 4629  014514                        CMP1:
 4630  014514  104000                       EMT                             ;CMP DID NOT SET CC'S CORRECTLY
 4631  014516  012700  100000        CMP2:  MOV     #100000,R0
 4632  014522  000277                       SCC                             ;CC=1101
 4633  014524  000242                       CLV
 4634  014526  020027  077777               CMP     R0,#77777               ;CC=0010
 4635  014532  101402                       BLOS    CMP3
 4636  014534  102001                       BVC     CMP3
 4637  014536  100001                       BPL     CMP4
 4638  014540                        CMP3:
 4639  014540  104000                       EMT                             ;CMP DID NOT SET CC'S CORRECTLY
 4640  014542  052700  040000        CMP4:  BIS     #40000,R0               ;R0=140000
 4641  014546  000257                       CCC                             ;CC=0100
 4642  014550  000264                       SEZ
 4643  014552  022700  040000               CMP     #40000,R0               ;CC=1011
 4644  014556  102003                       BVC     CMP5
 4645  014560  103002                       BCC     CMP5
 4646  014562  001401                       BEQ     CMP5
 4647  014564  100401                       BMI     CMP6
 4648  014566                        CMP5:
 4649  014566  104000                       EMT                             ;CMP DID NOT SET CC'S CORRECTLY
 4650  014570  042700  040000        CMP6:  BIC     #40000,R0
 4651  014574  000277                       SCC                             ;CC=1111
 4652  014576  022700  177777               CMP     #-1,R0                  ;CC=0000
 4653  014602  101402                       BLOS    CMP7
 4654  014604  102401                       BVS     CMP7
 4655  014606  100001                       BPL     TS224
 4656  014610                        CMP7:
 4657  014610  104000                       EMT                             ;CMP DID NOT SET CC'S CORRECTLY
 4658
 4659                                ;*****************************************************************************************
 4660                                ;TEST 224       TEST COM INSTRUCTION
 4661                                ;*****************************************************************************************
 4662  014612                        TS224:
 4663  014612  012700  177777               MOV     #-1,R0
 4664  014616  000257                       CCC                             ;CC=1010
 4665  014620  000265                       +SEC!SEZ
 4666  014622  005100                       COM     R0                      ;CC=0101
 4667  014624  101002                       BHI     COM1
 4668  014626  102401                       BVS     COM1
 4669  014630  100001                       BPL     TS225
 4670  014632                        COM1:
 4671  014632  104000                       EMT                             ;COM DID NOT SET CC'S CORRECTLY
 4672
```

```
                                ;*****************************************************************************************
                                ;
                                ;       THESE NEXT TWO TESTS VERIFY THE FUNCTIONING OF THE SUB
                                ;AND SBC INSTRUCTIONS.  BOTH OF THESE INSTRUCTIONS HANDLE THE
                                ;C AND V BITS IDENTICALLY.  THE PROCEDURE IS TO PRESET THE CONDITION
                                ;CODES, EXECUTE THE INSTRUCTION WITH A PARTICULAR SET OF DATA, AND
                                ;THEN CHECK THE RESULTS BY EXECUTING A SERIES OF CONDITIONAL
                                ;BRANCHES.  THIS PROCEDURE IS REPEATED SEVERAL TIMES WITH DIFFERENT
                                ;DATA PATTERNS TO PROVIDE EVERY COMBINATION OF THE C AND V BITS.
                                ;
                                ;*****************************************************************************************
                                ;TEST 225       TEST SUB INSTRUCTION
                                ;*****************************************************************************************
014634                          TS225:
014634  012700  125252                MOV     #125252,R0
014640  000257                        CCC                             ;CC=1010
014642  000271                        +SEN!SEC
014644  162700  125252                SUB     #125252,R0              ;CC=0101   R0=0
014650  101002                        BHI     SUB1
014652  102401                        BVS     SUB1
014654  100001                        BPL     SUB2
014656                          SUB1:
014656  104000                        EMT                             ;SUB DID NOT SET CC'S CORRECTLY
014660  052700  100000        SUB2:   BIS     #100000,R0
014664  000277                        SCC                             ;CC=1101
014666  000242                        CLV
014670  162700  077777                SUB     #77777,R0               ;CC=0010   R0=1
014674  101402                        BLOS    SUB3
014676  102001                        BVC     SUB3
014700  100001                        BPL     SUB4
014702                          SUB3:
014702  104000                        EMT                             ;
014704  005100                SUB4:   COM     R0                      ;R0=177777
014706  000277                        SCC                             ;CC=11111
                                
014710  162700  100000                SUB     #100000,R0              ;CC=0000   R0=77777
014714  101402                        BLOS    SUB5
014716  102401                        BVS     SUB5
014720  100001                        BPL     SUB6
014722                          SUB5:
014722  104000                        EMT                             ;SUB DID NOT SET CC'S CORRECTLY
014724  000257                SUB6:   CCC                             ;CC=0100
014726  000264                        SEZ
014730  162700  140000                SUB     #140000,R0              ;CC=1011
014734  102003                        BVC     SUB7
014736  103002                        BCC     SUB7
014740  001401                        BEQ     SUB7
014742  100401                        BMI     TS226
014744                          SUB7:
014744  104000                        EMT                             ;
                                
                                ;*****************************************************************************************
                                ;TEST 226       TEST SBC INSTRUCTION
                                ;*****************************************************************************************
014746                          TS226:
```

```
 4729  014746  012700  000001          MOV     #1,R0
 4730  014752  000277                  SCC                             ;CC=1011
 4731  014754  000244                  CLZ
 4732  014756  005600                  SBC     R0                      ;CC=0100   R=0
 4733  014760  103403                  BCS     SBC1
 4734  014762  102402                  BVS     SBC1
 4735  014764  100401                  BMI     SBC1
 4736  014766  001401                  BEQ     SBC2
 4737  014770                  SBC1:
 4738  014770  104000                  EMT                             ;SBC DID NOT SET CC'S CORRECTLY
 4739  014772  000277          SBC2:   SCC                             ;CC=1010
 4740  014774  000245                  +CLZ!CLC
 4741  014776  005600                  SBC     R0                      ;CC=0100   R=0
 4742  015000  103403                  BCS     SBC3
 4743  015002  102402                  BVS     SBC3
 4744  015004  100401                  BMI     SBC3
 4745  015006  001401                  BEQ     SBC4
 4746  015010                  SBC3:
 4747  015010  104000                  EMT                             ;SBC DID NOT SET CC'S CORRECTLY
 4748  015012  000277          SBC4:   SCC                             ;CC=0111
 4749  015014  000250                  CLN
 4750  015016  005600                  SBC     R0                      ;CC=1001   R0=177777
 4751  015020  103003                  BCC     SBC5
 4752  015022  102402                  BVS     SBC5
 4753  015024  001401                  BEQ     SBC5
 4754  015026  100401                  BMI     SBC6
 4755  015030                  SBC5:
 4756  015030  104000                  EMT                             ;SBC DID NOT SET CC'S CORRECTLY
 4757  015032  042700  077777  SBC6:   BIC     #77777,R0               ;R0=100000
 4758  015036  000277                  SCC                             ;CC=1101
 4759  015040  000242                  CLV
 4760  015042  005600                  SBC     R0                      ;CC=0010
 4761  015044  101402                  BLOS    SBC7
 4762  015046  102001                  BVC     SBC7
 4763  015050  100001                  BPL     TS227
 4764  015052                  SBC7:
 4765  015052  104000                  EMT                             ;SBC DID NOT SET CC'S CORRECTLY
 4766
 4767                          ;*********************************************************************************
 4768                          ;
 4769                          ;       THESE NEXT FOUR TESTS VERIFY THE FUNCTIONING OF THE ROL,
 4770                          ;ROR, ASL AND ASR INSTRUCTIONS.  SPECIAL DATA PATTERNS ARE LOADED
 4771                          ;AND ROTATED SEVERAL TIMES FOR EACH TEST.  THE CONDITION CODES
 4772                          ;ARE PRESET BEFORE EACH ROTATION AND THE CONDITION CODES ARE
 4773                          ;CHECKED AFTER EACH ROTATION.  THE FINAL CHECK IN EACH TEST IS
 4774                          ;TO VERIFY THE COMMULATIVE DATA RESULT.  THE DATA PATTERNS HAVE
 4775                          ;BEEN SELECTED TO PRODUCE ALL COMBINATIONS OF THE C AND V BITS.
 4776                          ;
 4777                          ;*********************************************************************************
 4778                          ;TEST 227       TEST ROL INSTRUCTION
 4779                          ;*********************************************************************************
 4780  015054                  TS227:
 4781  015054  012700  144000          MOV     #144000,R0              ;R0=144000
 4782  015060  000257                  CCC                             ;CC=0110
 4783  015062  000266                  +SEZ!SEV
 4784  015064  006100                  ROL     R0                      ;CC=1001   R0=110000
```

```
 4785  015066  103003                        BCC     ROL1
 4786  015070  102402                        BVS     ROL1
 4787  015072  001401                        BEQ     ROL1
 4788  015074  100401                        BMI     ROL2
 4789  015076                          ROL1:
 4790  015076  104000                        EMT                             ;
 4791  015100  000277                  ROL2:  SCC                             ;CC=1100
 4792  015102  000243                        +CLV!CLC
 4793  015104  006100                        ROL     R0                      ;CC=0011   R0=020000
 4794  015106  103003                        BCC     ROL3
 4795  015110  102002                        BVC     ROL3
 4796  015112  001401                        BEQ     ROL3
 4797  015114  100001                        BPL     ROL4
 4798  015116                          ROL3:
 4799  015116  104000                        EMT                             ;ROL DID NOT SET CC'S CORRECTLY
 4800  015120  000277                  ROL4:  SCC                             ;CC=0111
 4801  015122  000250                        CLN
 4802  015124  006100                        ROL     R0                      ;CC=0000   R0=040001
 4803  015126  101402                        BLOS    ROL5
 4804  015130  102401                        BVS     ROL5
 4805  015132  100001                        BPL     ROL6
 4806  015134                          ROL5:
 4807  015134  104000                        EMT                             ;ROL DID NOT SET CC'S CORRECTLY
 4808  015136  000257                  ROL6:  CCC                             ;CC=0101
 4809  015140  000265                        +SEZ!SEC
 4810  015142  006100                        ROL     R0                      ;CC=1010   R0=100003
 4811  015144  101405                        BLOS    ROL7
 4812  015146  102004                        BVC     ROL7
 4813  015150  100003                        BPL     ROL7
 4814  015152  022700  100003                CMP     #100003,R0
 4815  015156  001401                        BEQ     TS230
 4816  015160                          ROL7:
 4817  015160  104000                        EMT                             ;ROL MALFUNCTIONED
 4818                                  ;*******************************************************************************
 4819                                  ;TEST 230       TEST ROR INSTRUCTION
 4820                                  ;*******************************************************************************
 4821  015162                          TS230:
 4822  015162  012700  000023                MOV     #23,R0                  ;R0=23
 4823  015166  000277                        SCC                             ;CC=0111
 4824  015170  000250                        CLN
 4825  015172  006000                        ROR     R0                      ;CC=1001   R0=100011
 4826  015174  102403                        BVS     ROR1
 4827  015176  103002                        BCC     ROR1
 4828  015200  001401                        BEQ     ROR1
 4829  015202  100401                        BMI     ROR2
 4830  015204                          ROR1:
 4831  015204  104000                        EMT                             ;ROR DID NOT SET CC'S CORRECTLY
 4832  015206  000257                  ROR2:  CCC                             ;CC=1100
 4833  015210  000274                        +SEN!SEZ
 4834  015212  006000                        ROR     R0                      ;CC=0011   R0=040004
 4835  015214  102003                        BVC     ROR3
 4836  015216  103002                        BCC     ROR3
 4837  015220  001401                        BEQ     ROR3
 4838  015222  100001                        BPL     ROR4
 4839  015224                          ROR3:
 4840  015224  104000                        EMT                             ;ROR DID NOT SET CC'S CORRECTLY
```

```
 4841  015226  000277                ROR4:   SCC                     ;CC=1110
 4842  015230  000241                        CLC
 4843  015232  006000                        ROR     R0              ;CC=0000   R0=020002
 4844  015234  101403                        BLOS    ROR5
 4845  015236  102402                        BVS     ROR5
 4846  015240  001401                        BEQ     ROR5
 4847  015242  100001                        BPL     ROR6
 4848  015244                        ROR5:
 4849  015244  104000                        EMT                     ;ROR DID NOT SET CC'S CORRECTLY
 4850  015246  000257                ROR6:   CCC                     ;CC=0101
 4851  015250  000265                        +SEC!SEZ
 4852  015252  006000                        ROR     R0              ;CC=1010   R0=110001
 4853  015254  101402                        BLOS    ROR7
 4854  015256  102001                        BVC     ROR7
 4855  015260  100401                        BMI     TS231
 4856  015262                        ROR7:
 4857  015262  104000                        EMT                     ;ROR DID NOT PRODUCE CORRECT RESULTS
 4858                                ;*****************************************************************************
 4859                                ;TEST 231       TEST ASL INSTRUCTION
 4860                                ;*****************************************************************************
 4861  015264                        TS231:
 4862  015264  012700  144000                MOV     #144000,R0      ;R0=14000
 4863  015270  000257                        CCC                     ;CC=0110
 4864  015272  000271                        +SEN!SEC
 4865  015274  006300                        ASL     R0              ;CC=1001   R0=110000
 4866  015276  103003                        BCC     ASL1
 4867  015300  102402                        BVS     ASL1
 4868  015302  001401                        BEQ     ASL1
 4869  015304  100401                        BMI     ASL2
 4870  015306                        ASL1:
 4871  015306  104000                        EMT                     ;
 4872  015310  000277                ASL2:   SCC                     ;CC=1100
 4873  015312  000243                        +CLV!CLC
 4874  015314  006300                        ASL     R0              ;CC=0011   R0=020000
 4875  015316  103003                        BCC     ASL3
 4876  015320  102002                        BVC     ASL3
 4877  015322  001401                        BEQ     ASL3
 4878  015324  100001                        BPL     ASL4
 4879  015326                        ASL3:
 4880  015326  104000                        EMT                     ;ASL DID NOT SET CC'S CORRECTLY
 4881  015330  000277                ASL4:   SCC                     ;CC=0111
 4882  015332  000250                        CLN
 4883  015334  006300                        ASL     R0              ;CC=0000   R0=040000
 4884  015336  101402                        BLOS    ASL5
 4885  015340  102401                        BVS     ASL5
 4886  015342  100001                        BPL     ASL6
 4887  015344                        ASL5:
 4888  015344  104000                        EMT                     ;ASL DID NOT SET CC'S CORRECTLY
 4889  015346  000257                ASL6:   CCC                     ;CC=0101
 4890  015350  000265                        +SEZ!SEC
 4891  015352  006300                        ASL     R0              ;CC=1010   R0=100000
 4892  015354  103406                        BCS     ASL7
 4893  015356  001405                        BEQ     ASL7
 4894  015360  102004                        BVC     ASL7
 4895  015362  100003                        BPL     ASL7
 4896  015364  022700  100000                CMP     #100000,R0
```

```
                        BEQ     TS232
                ASL7:
                        EMT                     ;ASL MALFUNCTIONED
                ;*******************************************************************************
                ;TEST 232       TEST ASR INSTRUCTION
                ;*******************************************************************************
                TS232:
                        MOV     #100023,R0      ;R0=100023
                        SCC                     ;CC=0110
                        CLN
                        ASR     R0              ;CC=1001   RP=140011
                        BVS     ASR1
                        BCC     ASR1
                        BEQ     ASR1
                        BMI     ASR2
                ASR1:
                        EMT                     ;ASR DID NOT SET CC'S CORRECTLY
                ASR2:   BIC     #100000,R0      ;R0=40011
                        SCC                     ;CC=1100
                        +CLV!CLC
                        ASR     R0              ;CC=0011   R0=020004
                        BVC     ASR3
                        BCC     ASR3
                        BEQ     ASR3
                        BPL     ASR4
                ASR3:
                        EMT                     ;ASR DID NOT SET CC'S CORRECTLY
                ASR4:   SCC                     ;CC=1111

                        ASR     R0              ;CC=0000   R0=010002
                        BLOS    ASR5
                        BVS     ASR5
                        BEQ     ASR5
                        BPL     ASR6
                ASR5:
                        EMT                     ;ASR DID NOT SET CC'S CORRECTLY
                ASR6:   BIS     #100000,R0      ;R0=110002
                        CCC                     ;CC=0101
                        +SEZ!SEC
                        ASR     R0              ;C=1010   R0=144001
                        BLOS    ASR7
                        BVC     ASR7
                        BPL     ASR7
                        BEQ     ASR7
                        CMP     #144001,R0      ;CHECK RESULT OF ASR'S
                        BEQ     TS233
                ASR7:
                        EMT                     ;ASR DID NOT FUNCTION CORRECTLY


                ;*******************************************************************************
                ;TEST 233       TEST RORB INSTRUCTION
                ;*******************************************************************************
                TS233:
                        MOVB    #4,R1   ;LOAD REGISTER
                        CCC                     ;CLEAR ALL FLAGS
```

```
 4953  015522  106001                          RORB    R1              ;SHIFT  BYTE RIGHT
 4954  015524  106001                          RORB    R1              ;SHIFT BYTE RIGHT
 4955  015526  122701  000001                  CMPB    #1,R1           ;CHECK RESULT
 4956  015532  001401                          BEQ     RORB1
 4957  015534  104000                          EMT                     ;RORB DID NOT FUNCTION CORRECTLY
 4958  015536  106001                  RORB1:  RORB    R1              ;SHIFT BYTE RIGHT
 4959  015540  100403                          BMI     RORB2           ;CC=7?
 4960  015542  001002                          BNE     RORB2
 4961  015544  102001                          BVC     RORB2
 4962  015546  103401                          BCS     RORB3
 4963  015550                          RORB2:
 4964  015550  104000                          EMT                     ;RORB DID NOT SET CC'S CORRECTLY
 4965  015552  106001                  RORB3:  RORB    R1              ;SHIFT BYTE RIGHT
 4966  015554  100002                          BPL     RORB4           ;CC=12
 4967  015556  101401                          BLOS    RORB4
 4968  015560  102401                          BVS     RORB5
 4969  015562                          RORB4:
 4970  015562  104000                          EMT                     ;RORB DID NOT SET CC CORRECTLY
 4971  015564  122701  000200          RORB5:  CMPB    #200,R1         ;CHECK RESULT
 4972  015570  001401                          BEQ     RORB7
 4973  015572  104000                          EMT                     ;RORB DID NOT FUNCTION CORRECTLY
 4974  015574                          RORB7:
 4975                                  ;ROTATE ODD BYTE
 4976  015574  005000                          CLR     R0              ;MAKE R0 ZERO
 4977  015576  012710  025125                  MOV     #025125,(R0)    ;PUT STARTING VALUE IN LOC. 0
 4978  015602  005200                          INC     R0              ;MAKE R0 POINT TO ODD BYTE
 4979  015604  000257                          CCC                     ;CLEAR ALL CC
 4980  015606  000261                          SEC                     ;SEC CARRY BIT
 4981  015610  106010                          RORB    (R0)            ;SHIFT BYTE RIGHT
 4982  015612  100002                          BPL     RORB10          ;CC=12?
 4983  015614  101401                          BLOS    RORB10
 4984  015616  102401                          BVS     RORB11
 4985  015620                          RORB10:
 4986  015620  104000                          EMT                     ;RORB DID NOT SET CC'S CORRECTLY
 4987  015622  022737  112525  000000  RORB11: CMP     #112525,@#0     ;CHECK RESULT
 4988  015630  001401                          BEQ     RORB12
 4989  015632  104000                          EMT                     ;RORB DID NOT FUNCTION CORRECTLY
 4990  015634  106010                  RORB12: RORB    (R0)            ;SHIFT BYTE RIGHT
 4991  015636  100403                          BMI     RORB13          ;CC=3?
 4992  015640  001402                          BEQ     RORB13
 4993  015642  102001                          BVC     RORB13
 4994  015644  103401                          BCS     RORB14
 4995  015646                          RORB13:
 4996  015646  104000                          EMT                     ;RORB DID NOT SET CC CORRECTLY
 4997  015650  022737  045125  000000  RORB14: CMP     #045125,@#0     ;CHECK RESULT
 4998  015656  001401                          BEQ     TS234
 4999  015660  104000                          EMT                     ;RORB DID NOT FUNCTION CORRECTLY
 5000
 5001
 5002                                  ;*****************************************************************************************
 5003                                  ;TEST 234       TEST ASLB INSTRUCTION
 5004                                  ;*****************************************************************************************
 5005  015662                          TS234:
 5006  015662  112701  000040                  MOVB    #40,R1          ;LOAD REGISTER
 5007  015666  000257                          CCC                     ;CLEAR ALL CONDITION CODES
 5008  015670  106301                          ASLB    R1              ;SHIFT BYTE LEFT
```

```
 5009  015672  106301                  ASLB    R1              ;SHIFT BYTE LEFT
 5010  015674  100002                  BPL     ASLB2           ;CHECK CC=12
 5011  015676  101401                  BLOS    ASLB2
 5012  015700  102401                  BVS     ASLB3
 5013  015702                  ASLB2:
 5014  015702  104000                  EMT                     ;ASLB DID NOT SET CONDITION CODE CORRECTLY
 5015  015704  022701  000200  ASLB3:  CMP     #200,R1         ;CHECK RESULT
 5016  015710  001401                  BEQ     ASLB1
 5017  015712  104000                  EMT                     ;ASLB DID NOT FUNCTION CORRECTLY
 5018  015714  106301          ASLB1:  ASLB    R1              ;SHIFT BYTE LEFT
 5019  015716  100403                  BMI     ASLB4           ;CHECK CC=7?
 5020  015720  001002                  BNE     ASLB4
 5021  015722  102001                  BVC     ASLB4
 5022  015724  103401                  BCS     TS235
 5023  015726                  ASLB4:
 5024  015726  104000                  EMT                     ;ASLB   DID NOT SET CC'S CORRECTLY
 5025
 5026
 5027                          ;*******************************************************************************
 5028                          ;TEST 235       TEST ASRB INSTRUCTION
 5029                          ;*******************************************************************************
 5030  015730                  TS235:
 5031  015730  112701  000004          MOVB    #4,R1           ;SET UP STARTING DATA
 5032  015734  000257                  CCC                     ;CLEAR ALL CONDITION CODES
 5033  015736  106201                  ASRB    R1              ;SKIFT BYTE RIGHT
 5034  015740  106201                  ASRB    R1              ;SHIFT BYTE RIGHT
 5035  015742  122701  000001          CMPB    #1,R1           ;CHECK DATA
 5036  015746  001401                  BEQ     ASRB1
 5037  015750  104000                  EMT                     ;ASRB DID NOT SHIFT DATA CORRECTLY
 5038  015752  106201          ASRB1:  ASRB    R1              ;SHIFT BYTE RIGHT
 5039  015754  100403                  BMI     ASRB2           ;CHECK CONDITION CODE = 7?
 5040  015756  001002                  BNE     ASRB2
 5041  015760  102001                  BVC     ASRB2
 5042  015762  103401                  BCS     ASRB3
 5043  015764                  ASRB2:
 5044  015764  104000                  EMT                     ;ASRB DID NOT SET CC'S CORRECTLY
 5045  015766  106201          ASRB3:  ASRB    R1              ;SHIFT BYTE RIGHT
 5046  015770  103401                  BCS     ASRB4           ;CHECK CC=4
 5047  015772  001401                  BEQ     ASRB5
 5048  015774                  ASRB4:
 5049  015774  104000                  EMT                     ;ASRB DID NOT SET CC'S CORRECTLY
 5050  015776  112701  000202  ASRB5:  MOVB    #202,R1         ;PUT STARTING DATA IN REGISTER
 5051  016002  106201                  ASRB    R1              ;SHIFT BYTE RIGHT
 5052  016004  106201                  ASRB    R1              ;SHIFT BYTE RIGHT
 5053  016006  100003                  BPL     ASRB6           ;CHECK CC'S =11?
 5054  016010  001402                  BEQ     ASRB6
 5055  016012  102401                  BVS     ASRB6
 5056  016014  103401                  BCS     ASRB7
 5057  016016                  ASRB6:
 5058  016016  104000                  EMT                     ;ASRB DID NOT SET CC'S CORRECTLY
 5059  016020  122701  000340  ASRB7:  CMPB    #340,R1         ;CHECK RESULT
 5060  016024  001401                  BEQ     TS236
 5061  016026  104000                  EMT                     ;ASRB DID NOT SHIFT DATA CORRECTLY
 5062
 5063                          ;*******************************************************************************
 5064                          ;
```

```
                        ;       THIS TEST VERIFIES THE SXT INSTRUCTION. CONDITION  CODES
                        ;ARE PRESET IN EACH OF THE TWO POSSIBLE CASES. WITH THE N-BIT SET,
                        ;THE TEST CHECKS FOR ALL ONES IN THE DESTINATION. WITH THE N-BIT
                        ;CLEAR, THE DESTINATION SHOULD CONTAIN ALL ZEROES. THE DATA
                        ;IS VERIFIED BY CONDITIONAL BRANCHES.
                        ;
                        ;*****************************************************************************
                        ;TEST 236       TEST THE SXT INSTRUCTION
                        ;*****************************************************************************
016030                  TS236:
016030  005000                  CLR     R0
016032  000277                  SCC                             ;SET CC=1011
016034  000244                  CLZ
016036  006700                  SXT     R0                      ;TRY SXT
016040  100006                  BPL     SXT0                    ;TEST CC=1001
016042  001405                  BEQ     SXT0
016044  102404                  BVS     SXT0
016046  103003                  BCC     SXT0
016050  022700  177777          CMP     #-1,R0                  ;CHECK DATA RESULT
016054  001401                  BEQ     SXT1
016056                  SXT0:
016056  104000                  EMT                             ;RESULTS OF SXT INCORRECT
016060  005000          SXT1:   CLR     R0                      ;R0=0
016062  005010                  CLR     (R0)                    ;LOC. 0=0
016064  005110                  COM     (R0)                    ;LOC. 0=177777
016066  000257                  CCC                             ;SET CC=0110
016070  000266                  +SEZ!SEV
016072  006710                  SXT     (R0)
016074  001005                  BNE     SXT2                    ;TEST CC=0100
016076  103404                  BCS     SXT2
016100  102403                  BVS     SXT2
016102  100402                  BMI     SXT2
016104  005710                  TST     (R0)
016106  001401                  BEQ     TS237
016110                  SXT2:
016110  104000                  EMT                             ;RESULTS OF SXT INCORRECT
                        ;*****************************************************************************
                        ;
                        ;       THIS TEST VERIFIES THE XOR INSTRUCTION. UNIQUE PATTERNS
                        ;OF ONES AND ZEROES ARE MOVED TO DATA REGISTERS R0 AND R1.
                        ;AFTER THE FIRST XOR INSTRUCTION R0=36146. AN XOR IS THEN
                        ;EXECUTED WITH THIS NEW VALUE AND THE CONTENTS OF R1 TO
                        ;REPRODUCE THE ORIGINAL VALUE IF R0=31525.
                        ;
                        ;*****************************************************************************
                        ;TEST 237       TEST THE XOR INSTRUCTION
                        ;*****************************************************************************
016112                  TS237:
016112  012700  007463          MOV     #7463,R0                ;SET UP R0
016116  012701  031525          MOV     #31525,R1               ;SET UP R1
016122  000277                  SCC                             ;SET CC=1110
016124  000241                  CLC
016126  074100                  XOR     R1,R0                   ;TRY XOR
016130  101406                  BLOS    XOR1                    ;CC=0000?
016132  102405                  BVS     XOR1
016134  001404                  BEQ     XOR1
```

```
5121  016136  100403                  BMI     XOR1
5122  016140  022700  036146          CMP     #36146,R0       ;DATA RESULT CORRECT?
5123  016144  001401                  BEQ     XOR2
5124  016146                  XOR1:
5125  016146  104000                  EMT                     ;
5126  016150  010104          XOR2:   MOV     R1,R4
5127  016152  000261                  SEC                     ;CC=1110
5128  016154  000241                  CLC
5129  016156  074400                  XOR     R4,R0           ;TRY XOR MODE 0,0
5130  016160  101406                  BLOS    XOR3            ;CC=0000?
5131  016162  102405                  BVS     XOR3
5132  016164  001404                  BEQ     XOR3
5133  016166  100403                  BMI     XOR3
5134  016170  022700  007463          CMP     #7463,R0
5135  016174  001401                  BEQ     TS240
5136  016176                  XOR3:
5137  016176  104000                  EMT                     ;RESULT OF XOR INCORRECT
5138                          ;*****************************************************************************
5139                          ;
5140                          ;       THIS TEST VERIFIES THE SOB INSTRUCTION. R4 IS USED AS A
5141                          ;COUNTER WHILE R0 IS THE ADDRESS REGISTER. CONDITIONAL
5142                          ;BRANCHES ARE USED TO VERIFY PROPER TRANSFER OF CONTROL
5143                          ;WHILE R4 IS CHECKED TO INSURE PROPER DECREMENTING OF R0.
5144                          ;
5145                          ;*****************************************************************************
5146                          ;TEST 240       TEST SOB INSTRUCTION
5147                          ;*****************************************************************************
5148  016200                  TS240:
5149  016200  012700  000525          MOV     #525,R0
5150  016204  010004                  MOV     R0,R4
5151  016206  000277                  SCC                     ;SET CC=1111
5152  016210  101002          SOB1:   BHI     SOB2            ;CC=1111?
5153  016212  100001                  BPL     SOB2
5154  016214  102401                  BVS     SOB3
5155  016216                  SOB2:
5156  016216  104000                  EMT                     ;
5157  016220  005304          SOB3:   DEC     R4              ;COUNT ITERATIONS
5158  016222  000277                  SCC                     ;CC=1111
5159  016224  077007                  SOB     R0,SOB1         ;DO SOB W/ R0
5160  016226  101004                  BHI     SOB4            ;CHECK CC=1111
5161  016230  100003                  BPL     SOB4
5162  016232  102002                  BVC     SOB4
5163  016234  005704                  TST     R4              ;ITERATION COUNT OK?
5164  016236  001401                  BEQ     TS241
5165  016240                  SOB4:
5166  016240  104000                  EMT                     ;INCORRECT # OF BRANCHES OR CC'S CHANGED
5167                          ;*****************************************************************************
5168                          ;
5169                          ;       THIS TEST VERIFIES THE MARK INSTRUCTION. THE EFFECTS
5170                          ;OF THE MARK INSTRUCTION ARE SIMULATED BY THE PROGRAM INSTRUCTIONS.
5171                          ;THE CONTENTS OF R5 AND THE STACK POINTER ARE CHECKED AFTER EACH
5172                          ;OF THE TWO ROUTINES IN THE TEST.
5173                          ;
5174                          ;*****************************************************************************
5175                          ;TEST 241       TEST MARK INSTRUCTION
5176                          ;*****************************************************************************
```

```
5177  016242
5178  016242  012706  001000          TS241:  MOV     #STBOT,SP
5179  016246  012746  125252                  MOV     #125252,-(SP)   ;PUT R5 VALUE ON STACK
5180  016252  162706  000074                  SUB     #74,SP          ;EFFECTIVELY PUT 36 ARGUMENTS ON STACK
5181  016256  012705  016274                  MOV     #MRK1,R5        ;SET NEW PC IN R5
5182  016262  012746  006436                  MOV     #6436,-(SP)     ;PUT MARK 36 INST. ON STACK
5183  016266  000277                          SCC                     ;SET CC=1111
5184  016270  000116                          JMP     (SP)            ;XFER CONTL TO MARK 36 INST. ON STACK
5185  016272  104000                          EMT                     ;MARK INST. SHOULD HAVE JUMPED TO MRK1
5186  016274  101010          MRK1:   BHI     MRK2            ;TEST CC UNAFFECTED
5187  016276  100007                  BPL     MRK2            ;IE. CC=1111
5188  016300  102006                  BVC     MRK2
5189  016302  020527  125252          CMP     R5,#125252      ;CHECK R5 RESTORED FROM STACK
5190  016306  001003                  BNE     MRK2
5191  016310  022706  001000          CMP     #STBOT,R6       ;CHECK STACK POINTER READJUSTED CORRECTLY.
5192  016314  001401                  BEQ     MRK3
5193  016316                  MRK2:
5194  016316  104000                  EMT                     ;RESULTS OF MARK INCORRECT
5195  016320  012746  052525  MRK3:   MOV     #52525,-(SP)
5196  016324  012746  006400          MOV     #6400,-(SP)     ;PUT MARK 0 INST. ON STACK
5197  016330  010605                  MOV     SP,R5           ;SET ADDR. OF MARK INST. IN R5
5198  016332  004737  016342          JSR     PC,@#MRK4       ;DO JSR
5199  016336  000137  016346          JMP     @#MRK5          ;
5200  016342  000205  MRK4:   RTS     R5              ;DO RTS WITH R5 TO MARK INST ON STACK
5201  016344  104000                  EMT                     ;RTS,MARK SEQUENCE FAILED
5202  016346  022706  001000  MRK5:   CMP     #STBOT,R6       ;STACK ADJUSTED CORRECTLY
5203  016352  001003                  BNE     MRK6            ;IF NOT:  BR
5204  016354  022705  052525          CMP     #52525,R5       ;CHECK IF R5 RESTORED FROM STACK
5205  016360  001401                  BEQ     TS242
5206  016362                  MRK6:
5207  016362  104000                  EMT                     ;RESULTS OF MARK INCORRECT
5208           177776                 PS=177776
5209                           ;*****************************************************************************
5210                           ;
5211                           ;       THESE NEXT SEVEN TESTS VERIFY THE MTPS INSTRUCTION IN ALL
5212                           ;       MODES. THE PSW IS DEFINED BY AN EQUATE STATEMENT BEFORE THE
5213                           ;       FIRST MTPS TEST. IN EACH TEST A PATTERN OF ONES AND
5214                           ;       ZEROES IS SET IN A DATA REGISTER AND MOVED TO THE PSW.
5215                           ;       THE DATA IN THE PSW, AND THE DATA REGISTER ADDRESS,
5216                           ;       ARE CHECKED TO VERIFY PROPER EXECUTION OF THE INSTRUCTION.
5217                           ;
5218                           ;*****************************************************************************
5219                           ;TEST 242       TEST MTPS INSTRUCTION
5220                           ;*****************************************************************************
5221  016364                   TS242:
5222  016364  012700  000377          MOV     #377,R0
5223  016370  000257                  CCC
5224  016372  106400                  MTPS    R0
5225  016374  022767  000357  161374  CMP     #357,PS
5226  016402  001401                  BEQ     MTPS1
5227  016404  104000                  EMT                     ;MTPS FAILED
5228  016406  005000          MTPS1:  CLR     R0
5229  016410  005010                  CLR     (R0)
5230  016412  000277                  SCC                     ;CC=1111
5231  016414  106410                  MTPS    (R0)            ;TRY MTPS MODE 1
5232  016416  100403                  BMI     MTPS1A          ;CHECK PS
```

```
                        BVS     MTPS1A
                        BCS     MTPS1A
                        BNE     TS243
                MTPS1A:
                        EMT                     ;MTPS FAILED

                ;*******************************************************************************
                ;TEST 243       TEST MTPS MODE 2
                ;*******************************************************************************
                TS243:
                        CLR     R0              ;R0=0
                        MOV     #-1,(R0)        ;LOC. 0=-1
                        CLR     @#PS            ;PS=0
                        MTPS    (R0)+           ;TRY MTPS W/MODE 2
                        CMP     #357,@#PS       ;CHECK DATA
                        BEQ     MTPS2
                        EMT                     ;DEST. DATA INCORRECT
                MTPS2:  CMP     #1,R0           ;CHECK DEST. REGISTER.
                        BEQ     TS244
                        EMT                     ;DEST REGISTER NOT INCREMENTED BY 1

                ;*******************************************************************************
                ;TEST 244       TEST MTPS MODE 3
                ;*******************************************************************************
                TS244:
                        MOV     #402,R0         ;R0=402
                        CLR     (R0)            ;LOC. 402=0
                        MOV     #52652,@#0      ;LOC. 0=52652
                        CLR     @#PS            ;PS=0
                        MTPS    @(R0)+          ;TRY MTPS W/MODE 3
                        CMP     #252,@#PS       ;CHECK DEST. DATA
                        BEQ     MTPS3
                        EMT                     ;DEST. DATA INCORRECT
                MTPS3:  CMP     #404,R0         ;CHECK MODE 3 REGISTER.
                        BEQ     TS245
                        EMT                     ;MODE 3 REGISTER INCORRECT

                ;*******************************************************************************
                ;TEST 245       TEST MTPS MODE 4
                ;*******************************************************************************
                TS245:
                        MOV     #1,R0           ;R0=1
                        MOV     #125125,@#0     ;LOC. 0 = 125125
                        CLR     @#PS            ;PS=0
                        MTPS    -(R0)           ;TRY MTPS W/MODE 4
                        CMP     #105,@#PS       ;CHECK DEST. DATA
                        BEQ     MTPS4
                        EMT                     ;DEST. DATA INCORRECT
                MTPS4:  TST     R0              ;CHECK MODE 4 REGISTER
                        BEQ     TS246
                        EMT                     ;MODE 4 REGISTER NOT DECREMENTED BY 1

                ;*******************************************************************************
                ;TEST 246       TEST MTPS MODE 5
                ;*******************************************************************************
                TS246:
```

```
5289  016572  012700  000404              MOV     #404,R0         ;R0=404
5290  016576  012737  177400  000000      MOV     #177400,@#0     ;LOC. 0=177400
5291  016604  000277                      SCC                     ;SET ALL COND. CODES
5292  016606  106450                      MTPS    @-(R0)          ;TRY MTPS W/MODE 5
5293  016610  005737  177776              TST     @#PS            ;CHECK DEST. DATA.
5294  016614  001401                      BEQ     MTPS5
5295  016616  104000                      EMT                     ;DESTINATION DATA INCORRECT
5296  016620  022700  000402      MTPS5:  CMP     #402,R0         ;CHECK MODE 5 REGISTER
5297  016624  001401                      BEQ     TS247
5298  016626  104000                      EMT                     ;MODE 5 REGISTER NOT DECREMENTED BY 2
5299
5300                              ;*******************************************************************************
5301                              ;TEST 247       TEST MTPS MODE 6
5302                              ;*******************************************************************************
5303  016630                      TS247:
5304  016630  012737  052652  000000      MOV     #52652,@#0      ;LOC. 0=52652
5305  016636  012700  000406              MOV     #406,R0         ;R0=406
5306  016642  005037  177776              CLR     @#PS            ;PS=0
5307  016646  106460  177372              MTPS    -406(R0)        ;TRY MTPS W/MODE 6
5308  016652  022737  000252  177776      CMP     #252,@#PS       ;CHECK DEST. DATA
5309  016660  001401                      BEQ     MTPS6
5310  016662  104000                      EMT                     ;DEST. DATA INCORRECT
5311  016664  022700  000406      MTPS6:  CMP     #406,R0         ;CHECK MODE 6 REGISTER
5312  016670  001401                      BEQ     TS250
5313  016672  104000                      EMT                     ;MODE 6 REGISTER MODIFIED
5314
5315                              ;*******************************************************************************
5316                              ;TEST 250       TEST MTPS MODE 7
5317                              ;*******************************************************************************
5318  016674                      TS250:
5319  016674  012737  052652  000000      MOV     #52652,@#0      ;LOC. 0=52652
5320  016702  012700  000410              MOV     #410,R0         ;R0=410
5321  016706  005037  177776              CLR     @#PS            ;PS=0
5322  016712  106470  177776              MTPS    @-2(R0)         ;TRY MTPS W/MODE 7
5323  016716  022737  000105  177776      CMP     #105,@#PS       ;CHECK DEST. DATA
5324  016724  001401                      BEQ     MTPS7
5325  016726  104000                      EMT                     ;DESTINATION DATA INCORRECT
5326  016730  022700  000410      MTPS7:  CMP     #410,R0         ;CHECK MODE 7 REGISTER
5327  016734  001401                      BEQ     TS251
5328  016736  104000                      EMT                     ;MODE 7 REGISTER MODIFIED
5329
5330                              ;*******************************************************************************
5331                              ;
5332                              ;       THESE NEXT SEVEN TESTS VERIFY THE MFPS INSTRUCTION IN ALL
5333                              ;MODES. IN EACH TEST, A PATTERN OF ONES AND ZEROES IS MOVED TO THE
5334                              ;PSW, AND AN MFPS INSTRUCTION MOVES THE DATA TO A LOCATION SETUP
5335                              ;BY R0, EITHER DIRECTLY OR INDIRECTLY. CONDITIONAL BRANCHES ARE
5336                              ;USED TO CHECK PROPER ADDRESSING AND DATA.
5337                              ;
5338                              ;*******************************************************************************
5339                              ;TEST 251       TEST MFPS INSTRUCTION
5340                              ;*******************************************************************************
5341  016740                      TS251:
5342  016740  012737  000377  177776      MOV     #377,@#PS
5343  016746  106700                      MFPS    R0
5344  016750  022700  177757              CMP     #177757,R0
```

```
5345  016754  001401                        BEQ     MFPS1
5346  016756  104000                        EMT                             ;MFPS FAILED
5347
5348  016760  005000                MFPS1:  CLR     R0
5349  016762  012737  177777  000000        MOV     #-1,@#0
5350  016770  005037  177776                CLR     @#PS
5351  016774  106710                        MFPS    (R0)
5352  016776  105737  000000                TSTB    @#0
5353  017002  001401                        BEQ     TS252
5354  017004  104000                        EMT                             ;MFPS FAILED
5355
5356                                ;*******************************************************************************
5357                                ;TEST 252       TEST MFPS MODE 2
5358                                ;*******************************************************************************
5359  017006                        TS252:
5360  017006  005000                        CLR     R0                      ;R0=0
5361  017010  005010                        CLR     (R0)                    ;LOC. 0=0
5362  017012  012737  000377  177776        MOV     #377,@#PS               ;SET PS=357
5363  017020  106720                        MFPS    (R0)+                   ;TRY MFPS W/MODE 2
5364  017022  103003                        BCC     MFPS2A                  ;BR TO ERROR IF C BIT CLEAR
5365  017024  102402                        BVS     MFPS2A                  ;BR TO ERROR IF V BIT SET
5366  017026  001401                        BEQ     MFPS2A                  ;BR TO ERROR IF Z BIT SET
5367  017030  100401                        BMI     MFPS2B
5368  017032                        MFPS2A:
5369  017032  104000                        EMT                             ;COND. CODES INCORRECT
5370  017034  022737  000357  000000  MFPS2B: CMP     #357,@#0                ;CHECK DEST. DATA
5371  017042  001401                        BEQ     MFPS2C
5372  017044  104000                        EMT                             ;DEST. DATA INCORRECT
5373  017046  022700  000001        MFPS2C: CMP     #1,R0                   ;CHECK MODE 2 REGISTER
5374  017052  001401                        BEQ     TS253
5375  017054  104000                        EMT                             ;MODE 2 REGISTER NOT INCREMENTED 1
5376
5377                                ;*******************************************************************************
5378                                ;TEST 253       TEST MFPS MODE 3
5379                                ;*******************************************************************************
5380  017056                        TS253:
5381  017056  012700  000406                MOV     #406,R0                 ;R0=406
5382  017062  005037  000000                CLR     @#0                     ;LOC. 0=0
5383  017066  012737  000252  177776        MOV     #252,@#PS               ;PS=252
5384  017074  106730                        MFPS    @(R0)+                  ;TRY MFPS WITH MODE 3
5385  017076  103403                        BCS     MFPS3A                  ;BR TO ERROR IF C-BIT SET
5386  017100  102402                        BVS     MFPS3A                  ;BR TO ERROR IF V-BIT SET
5387  017102  001401                        BEQ     MFPS3A                  ;BR TO ERROR IF Z-BIT SET
5388  017104  100401                        BMI     MFPS3B
5389  017106                        MFPS3A:
5390  017106  104000                        EMT                             ;CONDITION CODES INCORRECT
5391  017110  022737  125000  000000  MFPS3B: CMP     #125000,@#0             ;CHECK DEST. DATA
5392  017116  001401                        BEQ     MFPS3C
5393  017120  104000                        EMT                             ;DEST DATA INCORRECT
5394  017122  020027  000410        MFPS3C: CMP     R0,#410                 ;CHECK MODE 3 REGISTER.
5395  017126  001401                        BEQ     TS254
5396  017130  104000                        EMT                             ;MODE 3 REGISTER NOT INCREMENTED BY 2
5397
5398                                ;*******************************************************************************
5399                                ;TEST 254       TEST MFPS MODE 4
5400                                ;*******************************************************************************
```

```
 5401  017132                          TS254:
 5402  017132  012700  000002                  MOV     #2,R0           ;R0=2
 5403  017136  005037  000000                  CLR     @#0             ;LOC. 0=0
 5404  017142  012737  000125  177776          MOV     #125,@#PS       ;PS=125
 5405  017150  106740                          MFPS    -(R0)           ;TRY MFPS W/MODE 4
 5406  017152  103003                          BCC     MFPS4A          ;BR TO ERROR IF C-BIT CLEAR
 5407  017154  102402                          BVS     MFPS4A          ;BR TO ERROR IF V-BIT SET
 5408  017156  001401                          BEQ     MFPS4A          ;BR TO ERROR IF Z-BIT SET
 5409  017160  100001                          BPL     MFPS4B
 5410  017162                          MFPS4A:
 5411  017162  104000                          EMT                     ;COND. CODES INCORRECT
 5412  017164  022737  042400  000000  MFPS4B: CMP     #42400,@#0      ;CHECK DEST. DATA
 5413  017172  001401                          BEQ     MFPS4C
 5414  017174  104000                          EMT                     ;DEST. DATA INCORRECT
 5415  017176  020027  000001          MFPS4C: CMP     R0,#1           ;CHECK MODE 4 REGISTER
 5416  017202  001401                          BEQ     TS255
 5417  017204  104000                          EMT                     ;MODE 4 REGISTER NOT DECREMENTED BY 1
 5418
 5419                                  ;*****************************************************************************
 5420                                  ;TEST 255       TEST MFPS MODE 5
 5421                                  ;*****************************************************************************
 5422  017206                          TS255:
 5423  017206  012700  000410                  MOV     #410,R0         ;R0=410
 5424  017212  012737  177777  000000          MOV     #-1,@#0         ;LOC. 0=-1
 5425  017220  005037  177776                  CLR     @#PS            ;PS=0
 5426  017224  106750                          MFPS    @-(R0)          ;TRY MFPS W/MODE 5
 5427  017226  103403                          BCS     MFPS5A          ;BR TO ERROR IF C-BIT SET
 5428  017230  102402                          BVS     MFPS5A          ;BR TO ERROR IF V-BIT SET
 5429  017232  100401                          BMI     MFPS5A          ;BR TO ERROR IF N-BIT SET
 5430  017234  001401                          BEQ     MFPS5B
 5431  017236                          MFPS5A:
 5432  017236  104000                          EMT                     ;COND. CODES INCORRECT
 5433  017240  022737  000377  000000  MFPS5B: CMP     #377,@#0        ;CHECK DEST. DATA
 5434  017246  001401                          BEQ     MFPS5C
 5435  017250  104000                          EMT                     ;DEST DATA INCORRECT
 5436  017252  020027  000406          MFPS5C: CMP     R0,#406         ;CHECK MODE 5 REGISTER
 5437  017256  001401                          BEQ     TS256
 5438  017260  104000                          EMT                     ;MODE 5 REGISTER NOT DECREMENTED BY 2
 5439
 5440                                  ;*****************************************************************************
 5441                                  ;TEST 256       TEST MFPS MODE 6
 5442                                  ;*****************************************************************************
 5443  017262                          TS256:
 5444  017262  012700  000401                  MOV     #401,R0         ;R0=410
 5445  017266  005037  000000                  CLR     @#0             ;LOC. 0=0
 5446  017272  012737  000252  177776          MOV     #252,@#PS       ;PS=252
 5447  017300  106760  177377                  MFPS    -401(R0)        ;TRY MFPS W/MODE 6
 5448  017304  102403                          BVS     MFPS6A          ;BR TO ERROR IF V-BIT SET
 5449  017306  103402                          BCS     MFPS6A          ;BR TO ERROR IF C-BIT SET
 5450  017310  001401                          BEQ     MFPS6A          ;BR TO ERROR IF Z-BIT SET
 5451  017312  100401                          BMI     MFPS6B
 5452  017314                          MFPS6A:
 5453  017314  104000                          EMT                     ;COND. CODES INCORRECT
 5454  017316  022737  000252  000000  MFPS6B: CMP     #252,@#0        ;CHECK DEST. DATA
 5455  017324  001401                          BEQ     MFPS6C
 5456  017326  104000                          EMT                     ;DEST. DATA INCORRECT
```

```
 5457  017330  022700  000401          MFPS6C: CMP     #401,R0         ;CHECK DEST. REGISTER
 5458  017334  001401                          BEQ     TS257
 5459  017336  104000                          EMT                     ;DEST. DATA INCORRECT
 5460
 5461                                  ;*****************************************************************************
 5462                                  ;TEST 257       TEST MFPS MODE 7
 5463                                  ;*****************************************************************************
 5464  017340                          TS257:
 5465  017340  012700  000777                  MOV     #777,R0         ;R0=777
 5466  017344  005037  000000                  CLR     @#0             ;LOC. 0=0
 5467  017350  012737  000125  177776          MOV     #125,@#PS       ;PS=125
 5468  017356  106770  177407                  MFPS    @-371(R0)       ;TRY MFPS W/MODE 7
 5469  017362  102403                          BVS     MFPS7A          ;BR TO ERROR IF V-BIT SET
 5470  017364  103002                          BCC     MFPS7A          ;BR TO ERROR IF C-BIT SET
 5471  017366  001401                          BEQ     MFPS7A          ;BR TO ERROR IF Z-BIT SET
 5472  017370  100001                          BPL     MFPS7B
 5473  017372                          MFPS7A:
 5474  017372  104000                          EMT                     ;CONDITION CODE INCOPRECT
 5475  017374  022737  042400  000000  MFPS7B: CMP     #42400,@#0      ;CHECK DESTINATION DATA
 5476  017402  001401                          BEQ     MFPS7C
 5477  017404  104000                          EMT                     ;DEST. DATA INCORRECT
 5478  017406  022700  000777          MFPS7C: CMP     #777,R0         ;CHECK MODE 7 REGISTER
 5479  017412  001401                          BEQ     TS260
 5480  017414  104000                          EMT                     ;MODE 7 REGISTER MODIFIED
 5481
 5482                                  ;*****************************************************************************
 5483                                  ;
 5484                                  ;       THIS TEST VERIFIES THAT RESET DOES NOT CLEAR THE PSW.
 5485                                  ;THE PSW IS LOADED WITH ONES, A RESET IS ISSUED, AND THE
 5486                                  ;CONTENTS OF THE PSW ARE CHECKED TO VERIFY THAT THEY HAVE NOT
 5487                                  ;CHANGED. THIS TEST IS EXECUTED ONLY ONCE EVERY 240 (DECIMAL)
 5488                                  ;ITERATIONS OF PROGRAM.
 5489                                  ;
 5490                                  ;*****************************************************************************
 5491                                  ;TEST 260       TEST THAT RESET DOES NOT CLEAR PSW
 5492                                  ;*****************************************************************************
 5493  017416                          TS260:
 5494  017416  032737  000001  001020          BIT     #1, @#$ENV      ;ARE WE RUNNING UNDER APT
 5495  017424  001403                          BEQ     70$             ;IF NO THEN DO TEST
 5496  017426  005737  001006                  TST     @#$PASS         ;IS THIS FIRST PASS
 5497  017432  001011                          BNE     TS261           ;IF NO THEN SHIP TO NEXT TEST
 5498  017434                          70$:
 5499  017434  012737  000357  177776          MOV     #357,@#PS               ;MOV ONES TO PSW
 5500  017442  000005                          RESET                   ;
 5501  017444  022737  000357  177776          CMP     #357,@#PS               ;PSW CORRECT?
 5502  017452  001401                          BEQ     TS261
 5503  017454  104000                          EMT                     ;RESET ALTERED PSW
 5504  017456                          REST:
 5505
 5506                                  ;*****************************************************************************
 5507                                  ;
 5508                                  ;       THE FOLLOWING TEST CHECKS THE INDEPENDENT FUNCTIONING OF BASIC
 5509                                  ;DATA PATH COMPONENTS WITH USER MODE SET.
 5510                                  ;
 5511                                  ;*****************************************************************************
 5512                                  ;TEST 261       TEST USER MODE R6 CAN HOLD A ONE IN EVERY POSITION
```

```
                                ;*****************************************************************************************
017456                          TS261:
017456  052767  140000  160312          BIS     #USRM,PS                ;SET USER MODE
017464  012706  000001                  MOV     #1,R6                   ;SET BIT0
017470  000241                          CLC                             ;CLEAR C-BIT
017472  006106                  USP1:   ROL     R6                      ;ROTATE 1 POSITION
017474  103376                          BCC     USP1                    ;BR IF NOT ALL DONE
017476  001404                          BEQ     USP1A                   ;BR IF NO BITS PICKED
017500  042767  140000  160270          BIC     #USRM,PS                ;CLEAR USER MODE
017506  104000                          EMT                     ;USER MODE R6 PICKED A BIT
017510  042767  140000  160260  USP1A:  BIC     #USRM,PS                ;CLEAR USER MODE

                                ;*****************************************************************************************
                                ;
                                ;       THIS TEST CHECKS THE INDEPENDENT FUNCTIONING OF THE USER
                                ;AND KERNEL MODE R6'S. R6 IS SETUP AND ADDRESSED IN EACH
                                ;OF THE TWO MODES TO VERIFY THAT THE TWO R6'S ARE INDEPENDENT
                                ;OF EACH OTHER.
                                ;
                                ;*****************************************************************************************
                                ;TEST 262       TEST INDEPENDENCE OF USER AND KERNEL MODE R6'S
                                ;*****************************************************************************************
017516                          TS262:
017516  052767  140000  160252          BIS     #USRM,PS                ;SET USER MODE
017524  012706  177777                  MOV     #-1,R6                  ;SET USER R6 TO ALL ONES
017530  022706  177777                  CMP     #-1,R6                  ;READ AND CHECK USER R6
017534  001404                          BEQ     USP2                    ;BR IF NO ERROR
017536  042767  140000  160232          BIC     #USRM,PS                ;CLEAR USER MODE
017544  104000                          EMT                     ;USER R6 WILL NOT HOLD ALL ONES
017546  042767  140000  160222  USP2:   BIC     #USRM,PS                ;SET KERNEL MODE
017554  022706  177777                  CMP     #-1,R6                  ;KERNEL MODE R6 ADDR. FROM USER MODE?>>
017560  001001                          BNE     USP3
017562  104000                          EMT                     ;DUAL ADDRESSING ERROR USER/KERNEL R6
017564  005006                  USP3:   CLR     R6                      ;CLEAR KERNEL MODE SP
017566  052767  140000  160202          BIS     #USRM,PS                ;SET USER MODE
017574  022706  177777                  CMP     #-1,R6                  ;CHECK USER R6 NOT ADDR. FROM KERNEL MODE
017600  042767  140000  160170          BIC     #USRM,PS                ;CLEAR USER MODE
017606  001401                          BEQ     USP4                    ;BR IF NO ERROR
017610  104000                          EMT                     ;DUAL ADDRESSING ERROR OR SEQUENCE ERROR
017612  012706  001000          USP4:   MOV     #STBOT,R6               ;RESTORE SP USER
017616  042767  140000  160152          BIC     #USRM,PS                ;SET KERNEL MODE
017624  012706  001000                  MOV     #STBOT,R6               ;RESTORE SP KERNEL

                                ;*****************************************************************************************
                                ;
                                ;       THESE NEXT TWO TESTS VERIFY MFPI AND MTPI INSTRUCTIONS
                                ;WITH R6 IN MODE 0.
                                ;
                                ;*****************************************************************************************
                                ;TEST 263       TEST MFPI WITH R6 IN MODE 0
                                ;*****************************************************************************************
017630                          TS263:
017630  012706  001000                  MOV     #STBOT,R6               ;INITIALIZE KERNEL STACK POINTER
017634  012767  140000  160134          MOV     #USRM,PS                ;SET USER MODE.PREVIOUS KERNEL
017642  012706  000600                  MOV     #USESTK,R6              ;INITIALIZE USER STACK POINTER
```

```
5569  017646  006506                    MFPI    R6                      ;TRY MFPI WITH MODE 0
5570  017650  022767  140000  160120    CMP     #140000,PS              ;CHECK PSW
5571  017656  001404                    BEQ     MFPIO                   ;BR IF NO ERROR
5572  017660  042767  140000  160110    BIC     #USRM,PS                ;CLEAR USER MODE
5573  017666  104000                    EMT                     ;INCORRECT PSW FROM MFPI
5574  017670  042767  140000  160100  MFPIO:  BIC     #USRM,PS                ;CLEAR USER MODE
5575  017676  022767  001000  160672    CMP     #STBOT,USESTK-2         ;CHECK DATA ON STACK
5576  017704  001401                    BEQ     MFPIOA                  ;BR IF NO ERROR
5577  017706  104000                    EMT                     ;INCORRECT DATA FROM MFPI
5578  017710                          MFPIOA:
5579
5580                                  ;*******************************************************************************
5581                                  ;TEST 264       TEST MTPI WITH R6 IN MODE 0
5582                                  ;*******************************************************************************
5583  017710                          TS264:
5584  017710  005067  160062            CLR     PS                      ;SET KERNEL MODE
5585  017714  005006                    CLR     R6                      ;INITIALIZE KERNEL R6
5586  017716  012767  140000  160052    MOV     #USRM,PS                ;SET USER MODE/PREVIOUS KERNEL
5587  017724  012706  000600            MOV     #USESTK,R6              ;INITIALIZE USER STACK POINTER
5588  017730  012746  001000            MOV     #STBOT,-(R6)            ;SET UP TARGET DATA
5589  017734  006606                    MTPI    R6                      ;TRY MODE 0 MTPI
5590  017736  022767  140000  160032    CMP     #USRM,PS                ;CHECK PSW
5591  017744  001404                    BEQ     MTPIO                   ;BR IF NO ERROR
5592  017746  042767  140000  160022    BIC     #USRM,PS                ;CLEAR USER MODE
5593  017754  104000                    EMT                     ;PS INCORRECT FOLLOWING MTPI
5594  017756  005067  160014          MTPIO:  CLR     PS                      ;SET KERNEL MODE
5595  017762  020627  001000            CMP     R6,#STBOT               ;CHECK TARGET DATA
5596  017766  001401                    BEQ     TS265
5597  017770  104000                    EMT                     ;DATA INCORRECT FOLLOWING MTPI
5598
5599
5600
5601                                  ;*******************************************************************************
5602                                  ;
5603                                  ;THE FOLLOWING TEST VERIFIES THAT NO DUAL ADDRESSING OF THE GENERAL
5604                                  ;REGISTERS OCCURS. ALL REGISTERS ARE CLEARED, AND A UNIQUE BIT IS SET
5605                                  ;IN EACH. CMP INSTRUCTIONS CHECK THAT ONLY ONE BIT IS SET IN EACH
5606                                  ;REGISTER.
5607                                  ;
5608                                  ;*******************************************************************************
5609                                  ;TEST 265       DUAL REGISTER ADDRESSING TEST
5610                                  ;*******************************************************************************
5611  017772                          TS265:
5612  017772  005000                BITCLR: CLR     R0                      ;INITIALIZE ALL REGISTERS
5613  017774  005001                        CLR     R1
5614  017776  005002                        CLR     R2
5615  020000  005003                        CLR     R3
5616  020002  005004                        CLR     R4
5617  020004  005005                        CLR     R5
5618  020006  005006                        CLR     R6
5619  020010  052700  000001        BITSET: BIS     #1,R0                   ;SET R0=1
5620  020014  052701  000002                BIS     #2,R1                   ;R1=2
5621  020020  052702  000004                BIS     #4,R2                   ;R2=4
5622  020024  052703  000010                BIS     #10,R3                  ;R3=10
5623  020030  052704  000020                BIS     #20,R4                  ;R4=20
5624  020034  052705  000040                BIS     #40,R5                  ;R5=40
```

```
5625  020040  052706  000100          BIS     #100,R6         ;R6=100
5626  020044  022706  000100  BITCHK: CMP     #100,R6         ;TEST THAT NO DUAL ADDRESSING OCCURRED
5627  020050  001022                  BNE     DAERR           ;BR TO ERROR HALT IF ANY OTHER BITS ARE SET
5628  020052  022705  000040          CMP     #40,R5
5629  020056  001017                  BNE     DAERR
5630  020060  022704  000020          CMP     #20,R4
5631  020064  001014                  BNE     DAERR
5632  020066  022703  000010          CMP     #10,R3
5633  020072  001011                  BNE     DAERR
5634  020074  022702  000004          CMP     #4,R2
5635  020100  001006                  BNE     DAERR
5636  020102  022701  000002          CMP     #2,R1
5637  020106  001003                  BNE     DAERR
5638  020110  022700  000001          CMP     #1,R0
5639  020114  001401                  BEQ     BITCON
5640  020116                  DAERR:
5641  020116  104000                  EMT                     ;DUAL ADDRESSING ERROR
5642  020120  012702  001004  BITCON: MOV     #$TESTN,R2      ;RESTORE POINTER
5643
5644                          ;*****************************************************************************
5645                          ;       THIS TEST VERIFIES THAT THE UPPER BYTE OF THE PSW IS NOT AFFECTED
5646                          ;WHEN THE PRIORITY LEVEL OR CC'S ARE CHANGED. ALL BITS ARE
5647                          ;INITIALLY SET IN THE PSW, AND THE LOW BYTE IS CLEARED. A BIT
5648                          ;INSTRUCTION VERIFIES THE DATA.
5649                          ;
5650                          ;*****************************************************************************
5651                          ;TEST 266       TEST BYTE INSTRUCTION ON PSW
5652                          ;*****************************************************************************
5653  020124                  TS266:
5654  020124  052737  170357  177776          BIS     #170357,@#PS    ;SET ALL POSSIBLE BITS IN PSW
5655  020132  105037  177776                  CLRB    @#PS            ;CLR PR LEVEL AND CC'S
5656  020136  013700  177776                  MOV     @#PS,R0         ;COPY CONTENTS OF PSW
5657  020142  032700  170000                  BIT     #170000,R0      ;TEST THAT UPPER BYTE IS UNAFFECTED
5658  020146  001003                          BNE     BTCON           ;CONTINUE IF OK
5659  020150  005037  177776          BTERR:  CLR     @#PS            ;RETURN TO KERNEL MODE
5660  020154  104000                          EMT                     ;BYTE INSTRUCTION ALTERED PSW
5661  020156  005037  177776          BTCON:  CLR     @#PS            ;RETURN TO KERNEL MODE
5662
5663                          ;*****************************************************************************
5664                          ;
5665                          ;       THIS TEST VERIFIES THAT A JMP INSTRUCTION DOES NOT ALTER THE
5666                          ;CONDITION CODES IN THE PSW. THE CC'S ARE PRESET,THE JMP IS
5667                          ;EXECUTED, AND CONDITIONAL BRANCHES VERIFY THE STATE OF THE CC'S.
5668                          ;
5669                          ;*****************************************************************************
5670                          ;TEST 267       TEST THAT JMP INSTRUCTION DOES NOT AFFECT CONDITION CODES
5671                          ;*****************************************************************************
5672  020162                  TS267:
5673  020162  000277                  SCC
5674  020164  000252                  +CLN!CLV                ;CC=0101
5675  020166  000167  000000          JMP     JMPT            ;JUMP TO TEST PSW
5676  020172  100403          JMPT:   BMI     JMPERR          ;BR TO ERROR HALT IF N-BIT IS SET
5677  020174  001002                  BNE     JMPERR          ;BR TO ERROR HALT IF Z-BIT IS CLEAR
5678  020176  102401                  BVS     JMPERR          ;BR TO ERROR HALT IF V-BIT IF SET
5679  020200  103401                  BCS     TS270
5680  020202                  JMPERR:
```

```
5681  020202  104000                          EMT                     ;JMP INSTRUCTION AFFECTED CC'S
5682                                ;*************************************************************************
5683                                ;
5684                                ;       THIS TEST VERIFIES THE SET AND CLEAR CONDITION CODE INSTRUCTIONS.
5685                                ;THE TEST CONSISTS OF TWO ROUTINES, ONE TO TEST ALL CLEAR CC
5686                                ;INSTRUCTIONS, AND THE SECOND TO TEST ALL SET CC INSTRUCTIONS. ALL
5687                                ;POSSIBLE COMBINATIONS OF CONDITION CODES ARE TESTED, INCLUDING NOP'S.
5688                                ;       TO TEST THE CLEAR CC INSTRUCTIONS, ALL CONDITION CODES ARE
5689                                ;INITIALLY SET. THE INSTRUCTION IS EXECUTED, AND THE PSW IS CHECKED
5690                                ;TO VERIFY THE PROPER COMBINATION OF CONDITION CODES.
5691                                ;       TO TEST THE SET CC INSTRUCTIONS, THE CONDITION CODES ARE
5692                                ;INITIALLY CLEARED, AND ONLY THE REQUIRED BITS ARE SET BY THE SET CC
5693                                ;INSTRUCTION. THE CONTENTS OF THE PSW ARE CHECKED TO VERIFY THAT
5694                                ;ONLY THE REQUIRED BITS WERE SET.
5695                                ;
5696                                ;*************************************************************************
5697                                ;TEST 270       TEST SET CC AND CLEAR CC INSTRUCTIONS
5698                                ;*************************************************************************
5699  020204                        TS270:
5700  020204  012767  000240  000024          MOV     #240,CC3        ;INITIALIZE CLR CC INSTRUCTION CODES
5701  020212  012767  000017  000032          MOV     #17,CC2         ;INITIALIZE OCTAL MAP
5702  020220  012767  000261  000074          MOV     #261,SC3        ;INITIALIZE SET CC INSTRUCTION CODES
5703  020226  012767  000001  000102          MOV     #1,SC4          ;INITIALIZE OCTAL MAP
5704  020234  000277                  CLRCD:  SCC                     ;SET ALL CONDITION CODES
5705  020236  000000                  CC3:    0                       ;CONDITION CODE INSTRUCTION
5706  020240  013704  177776                  MOV     @#PS,R4         ;COPY THE PSW
5707  020244  042704  177760                  BIC     #177760,R4      ;ISOLATE CONDITION CODES
5708  020250  022704                          CMP     (PC)+,R4        ;CHECK THAT PROPER CC'S WERE CLEARED
5709  020252  000000                  CC2:    0                       ;OCTAL REPRESENTATION OF CC'S
5710  020254  001401                          BEQ     CON1
5711  020256  104000                          EMT                     ;CLEAR CC INSTRUCTION FAILED
5712  020260  005367  177766          CON1:   DEC     CC2             ;SET NEXT OCTAL MAP OF CC'S
5713  020264  005267  177746                  INC     CC3             ;GET NEXT CLEAR CC INSTRUCTION
5714  020270  026727  177742  000257          CMP     CC3,#257        ;TEST FOR CCC INSTRUCTION
5715  020276  003756                          BLE     CLRCD           ;GO TEST NEXT INSTRUCTION IF NOT FOUND
5716  020300  026727  177732  000260          CMP     CC3,#260        ;CHECK FOR NOP=260
5717  020306  001004                          BNE     SETCD           ;GO TEST SET CC INSTRUCTIONS
5718  020310  012767  000017  177734          MOV     #17,CC2         ;SET OCTAL MAP TO TEST NOP
5719  020316  000746                          BR      CLRCD           ;GO TEST NOP
5720  020320  000257                  SETCD:  CCC                     ;CLEAR ALL CONDITION CODES
5721  020322  000000                  SC3:    0                       ;CONDITION CODE INSTRUCTION
5722  020324  013704  177776                  MOV     @#PS,R4         ;COY PSW
5723  020330  042704  177760                  BIC     #177760,R4      ;CLEAR AWAY UNWANTED BITS
5724  020334  022704                          CMP     (PC)+,R4        ;CHECK THAT PROPER CC'S WERE SET
5725  020336  000000                  SC4:    0                       ;OCTAL REPRESENTATION OF CC'S
5726  020340  001401                          BEQ     CON2
5727  020342                          CCERR:
5728  020342  104000                          EMT                     ;SET CC FAILED OR SEQUENCE ERROR
5729  020344  005267  177766          CON2:   INC     SC4             ;SET NEXT OCTAL MAP
5730  020350  005267  177746                  INC     SC3             ;PREPARE NEXT SET CC INSTRUCTION
5731  020354  026727  177742  000277          CMP     SC3,#277        ;FINISHED?
5732  020362  003756                          BLE     SETCD           ;BR IF NO
5733  020364  000167  000006                  JMP     MORO            ;JUMP TO NEXT TESTS
5734
5735                                ;*************************************************************************
5736                                .SBTTL  TEST INSTRUCTIONS USING SAME REGISTER FOR SOURCE & DESTINATION
```

```
                                        ;
                                        ;IN AUTO INCREMENT (DECREMENT) MODES AND
                                        ;AUTO INCREMENT (DECREMENT) DEFERRED MODES,
                                        ;CONTENTS OF THE REGISTER IN USED ARE
                                        ;INCREMENTED (DECREMENTED) BY 2
                                        ;BEFORE USED AS THE SOURCE OPERAND.
                                        ;
020370  000000  000000  000000  A:      .WORD 0,0,0
020376                          MOR0:
                                        ;*****************************************************************************
                                        ;TEST 271       TEST AUTO-INCREMENT MODE, USING R0
                                        ;*****************************************************************************
020376                          TS271:
020376  005037  020370                  CLR     @#A             ;CLEAR LOC A
020402  012700  020370                  MOV     #A,R0           ;R0 STORES ADDR OF A
020406  060020                          ADD     R0,(R0)+        ;CHECK THAT R0 IS INCR BY 2 BEFORE
                                                                ;BEING USED AS THE SOURCE OPERAND
020410  022700  020372                  CMP     #A+2,R0         ;R0 INCR BY 2?
020414  001401                          BEQ     MOR1
020416  104000                          EMT                     ;R0 WAS NOT INCREMENTED BY 2
                                                                ;
020420  022737  020372  020370  MOR1:   CMP     #A+2,@#A        ;CHECK CONTENT OF R0 WAS INCR BY 2 BEFORE
                                                                ;BEING USED IN THE "ADD" INSTR
                                                                ;LOC A CONTAINS (A+2)?
020426  001401                          BEQ     TS272
020430  104000                          EMT                     ;WRONG SUM IN LOC A

                                        ;*****************************************************************************
                                        ;TEST 272       AUTO-DECREMENT MODE, USING R0
                                        ;*****************************************************************************
020432                          TS272:
020432  005037  020370                  CLR     @#A             ;CLEAR LOC A
020436  012700  020372                  MOV     #A+2,R0         ;R0 STORES ADDR OF A+2
020442  060040                          ADD     R0,-(R0)        ;CHECK THAT R0 IS DECR BY 2 BEFORE
                                                                ;BEING USED AS THE SOURCE OPERAND
020444  022700  020370                  CMP     #A,R0           ;R0 DECR BY 2?
020450  001401                          BEQ     MOR2
020452  104000                          EMT                     ;R0 WAS NOT DECREMENTED BY 2
                                                                ;
020454  022737  020370  020370  MOR2:   CMP     #A,@#A          ;CONTENT OF R0 WAS DECR BY 2 BEFORE
                                                                ;BEING USED IN THE "ADD" INSTR
                                                                ;LOC A CONTAINS (R0)
020462  001401                          BEQ     TS273
020464  104000                          EMT                     ;WRONG SUM IN LOC A
                                                                ;

                                        ;*****************************************************************************
                                        ;TEST 273       TEST AUTO-INCREMENT DEFERRED MODE, USING R0
                                        ;*****************************************************************************
020466                          TS273:
020466  005037  020370                  CLR     @#A             ;CLEAR LOC A
020472  005037  020374                  CLR     @#A+4           ;CLEAR LOC A+4
020476  012737  020370  020372          MOV     #A,@#A+2        ;STORE ADDR A IN LOC A+2
020504  012700  020372                  MOV     #A+2,R0         ;R0 STORES ADDR A+2
020510  060030                          ADD     R0,@(R0)+       ;CHECK THAT R0 IS INCR BY 2 BEFORE
                                                                ;BEING USED AS THE SOURCE OPERAND
020512  022700  020374                  CMP     #A+4,R0         ;R0 INCR BY 2?
```

```
5793  020516  001401                        BEQ     MOR3
5794  020520  104000                        EMT                             ;R0 WAS NOT INCREMENTED BY 2
5795                                                                        ;
5796  020522  022737  020370  020372  MOR3: CMP     #A,@#A+2                ;LOC A+2 STILL STORES ADDR A?
5797  020530  001401                        BEQ     MOR4
5798  020532  104000                        EMT                             ;LOC A+2 STORES WRONG DATA
5799                                                                        ;
5800  020534  022737  020374  020370  MOR4: CMP     #A+4,@#A                ;CHECK CONTENT OF R0 WAS INCR BY 2 BEFORE
5801                                                                        ;BEING USED IN THE "ADD" INSTR
5802  020542  001401                        BEQ     MOR5
5803  020544  104000                        EMT                             ;LOC A STORES WRONG DATA
5804                                                                        ;
5805  020546  005737  020374          MOR5: TST     @#A+4                   ;LOC A+4 STILL STORES 0?
5806  020552  001401                        BEQ     TS274
5807  020554  104000                        EMT                             ;LOC A+4 DID NOT STAY CLEAR
5808
5809                                  ;*******************************************************************************
5810                                  ;TEST 274       TEST AUTO-DECREMENT DEFERRED, USING P0
5811                                  ;*******************************************************************************
5812  020556                          TS274:
5813  020556  005037  020370                CLR     @#A                     ;CLEAR LOC A
5814  020562  005037  020374                CLR     @#A+4                   ;CLEAR LOC A+4
5815  020566  012700  020374                MOV     #A+4,R0                 ;R0 STORES ADDR A+4
5816  020572  012737  020370  020372        MOV     #A,@#A+2                ;STORE ADDR A IN LOC A+2
5817  020600  060050                        ADD     R0,@-(R0)               ;CHECK THAT R0 IS DECR BY 2 BEFORE
5818                                                                        ;BEING USED AS THE SOURCE OPERAND
5819  020602  022700  020372                CMP     #A+2,R0                 ;R0 DECREMENTED BY 2?
5820  020606  001401                        BEQ     MOR6
5821  020610  104000                        EMT                             ;R0 WAS NOT DECREMENTED BY 2
5822                                                                        ;
5823  020612  022737  020372  020370  MOR6: CMP     #A+2,@#A                ;CHECK CONTENT OF R0 WAS DECR BY 2 BEFORE
5824                                                                        ;BEING USED IN THE "ADD" INSTR
5825  020620  001401                        BEQ     MOR7
5826  020622  104000                        EMT                             ;LOC A STORES WRONG DATA
5827
5828                                                                        ;
5829  020624  022737  020370  020372  MOR7: CMP     #A,@#A+2                ;LOC A+2 STILL STORES A?
5830  020632  001401                        BEQ     MOR8
5831  020634  104000                        EMT                             ;LOC A+2 STORES WRONG DATA
5832                                                                        ;
5833  020636  005737  020374          MOR8: TST     @#A+4                   ;LOC A+4 STILL STORES 0?
5834  020642  001401                        BEQ     TS275
5835  020644  104000                        EMT                             ;LOC A+4 DID NOT STAY CLEAR
5836                                                                        ;
5837
5838                                  ;*******************************************************************************
5839                                  .SBTTL  INSTRUCTION USING PC AS SOURCE REGISTER
5840                                  ;
5841                                  ;IN INDEX, INDEX DEFERRED, RELATIVE, AND
5842                                  ;RELATIVE DEFERRED MODES, DESTINATION WILL CONTAIN
5843                                  ;THE PC COUNT OF THE CURRENT INSTRUCTION +4.
5844                                  ;
5845                                  ;*******************************************************************************
5846                                  ;TEST 275       TEST PC AS SOURCE IN MODE 0, USING R0
5847                                  ;*******************************************************************************
5848  020646                          TS275:
```

```
                                        MOV     #-1,R0          ;SET ALL 1 IN R0
                                PCN01:  MOV     PC,R0           ;STORES PC IN R0
                                        CMP     #PCN01+2,R0     ;R0 STORES PC+2?
                                        BEQ     TS276
                                        EMT                     ;R0 STORED WRONG VALUE

                                ;*****************************************************************************
                                ;TEST 276       TEST PC AS SOURCE IN MODE 6, USING R0
                                ;*****************************************************************************
                                TS276:
                                        MOV #A,R0               ;R0 STORES ADDR A
                                PCN2:   MOV PC,4(R0)            ;EFFECTIVE ADDR IS A+4
                                        CMP     #PCN2+4,@#A+4   ;LOC A+4 STORES PC+4?
                                        BEQ     TS277
                                        EMT                     ;LOC A+4 STORED WRONG VALUE

                                ;*****************************************************************************
                                ;TEST 277       TEST PC AS SOURCE IN MODE 7, USING R0
                                ;*****************************************************************************
                                TS277:
                                        MOV     #A,@#A+4        ;LOC A+4 STORES ADDR A
                                        MOV     #A,R0           ;R0 STORES ADDR A
                                PCN3:   MOV     PC,@4(R0)       ;EFFECTIVE ADDR IS A
                                        CMP     #PCN3+4,@#A     ;LOC A STORES PC+4?
                                        BEQ     TS300
                                        EMT                     ;LOC A STORED WRONG VALUE

                                ;*****************************************************************************
                                ;TEST 300       TEST PC AS SOURCE IN RELATIVE DEFERRED MODE ,USING R0
                                ;*****************************************************************************
                                TS300:
                                        MOV     #A+2,@#A        ;LOC A STORES ADDR A+2
                                PCN4:   MOV     PC,@A           ;EFFECTIVE ADDR IS A+2
                                        CMP     #PCN4+4,@#A+2   ;LOC A+2 STORES PC+4?
                                        BEQ     TS301
                                        EMT                     ;LOC A+2 STORED WRONG VALUE

                                ;*****************************************************************************
                                ;TEST 301       TEST PC AS SOURCE IN RELATIVE MODE ,USING R0
                                ;*****************************************************************************
                                TS301:
                                        CLR     @#A             ;CLEAR A
                                PCN5:   MOV     PC,A            ;EFFECTIVE ADDR IS A
                                        CMP     #PCN5+4,@#A     ;LOC A STORES PC+4?
                                        BEQ     TS302
                                        EMT                     ;LOCATION A STORED WRONG VALUE
                                ;*****************************************************************************
                                ;THIS TESTS THE MOVE FROM PROCESSOR TYPE INSTRUCTION(MFPT)
                                ;UPON EXECUTION R0 WILL RECIEVE THE PROCESSOR MODEL CODE
                                ;WHICH IS "000003" FOR THE DCF11-AA
                                ;*****************************************************************************
                                ;*****************************************************************************
                                ;TEST 302       TEST MFPT
                                ;*****************************************************************************
                                TS302:
                                MFPT=000007
```

```
5905  021004  012706  001000          MOV     #STBOT,SP       ;INITIALIZE STACK POINT IN CASE OF TRAP
5906  021010  000007                  MFPT                    ;GET MODEL CODE.IF THIS TRAPS AN ERROR WILL BE REPORTED
5907  021012  022700  000003          CMP     #3,R0           ;CHECK IF CORRECT CODE RETURNED
5908  021016  001401                  BEQ     TS303
5909  021020  104000                  EMT                     ;WRONG CODE RETURNED
5910
5911
5912
5913                                  ;*************************************************************************************
5914                                  .SBTTL  THE NEXT THREE TESTS EXERCISE MASKING ACTION OF MICROCODES.
5915                                  ;*************************************************************************************
5916                                  ;TEST 303       TEST SUB INSTRUCTION, SM=0, DM=2
5917                                  ;*************************************************************************************
5918  021022                          TS303:
5919  021022  012737  052525  000000          MOV     #052525,@#0     ;SET UP LOC 0
5920  021030  012701  050505                  MOV     #050505,R1      ;SET UP R1
5921  021034  005000                          CLR     R0              ;CLEAR R0
5922  021036  160120                          SUB     R1,(R0)+        ;SUBTRACTION, SM=0,DM=2
5923  021040  022737  002020  000000          CMP     #2020,@#0       ;CHECK DIFFERENCE AT LOC 0
5924  021046  001401                          BEQ     TS304
5925  021050  104000                          EMT                     ;WRONG RESULT FROM SUBTRACTION
5926
5927                                  ;*************************************************************************************
5928                                  ;TEST 304       TEST MFPD WITH R0, IN MODE 2
5929                                  ;*************************************************************************************
5930  021052                          TS304:
5931  021052  012737  052525  000000          MOV     #052525,@#0     ;SET UP LOC 0
5932  021060  005000                          CLR     R0              ;CLEAR R0
5933  021062  012767  170000  156706          MOV     #170000,PS      ;SET USER MODE ON, CURRENT & PREVIOUS
5934  021070  012706  000600                  MOV     #USESTK,R6      ;SET USER STACK POINTER
5935  021074  106520                          MFPD    (R0)+           ;MODE 2, MFPD
5936  021076  005067  156674                  CLR     PS              ;SET KERNEL MODE
5937  021102  022767  052525  157466          CMP     #052525,USESTK-2        ;CHECK DATA ON STACK
5938  021110  001401                          BEQ     TS305
5939  021112  104000                          EMT                     ;INCORRECT DATA FROM MFPD
5940
5941                                  ;*************************************************************************************
5942                                  ;TEST 305       TEST MTPD WITH R0, IN MODE 2
5943                                  ;*************************************************************************************
5944  021114                          TS305:
5945  021114  012767  170000  156654          MOV     #170000,PS      ;SET USER MODE ON, CURRENT & PREVIOUS
5946  021122  012706  000600                  MOV     #USESTK,R6      ;SET USER STACK POINTER
5947  021126  012746  125252                  MOV     #125252,-(R6)   ;PUSH DATA IN USER STACK
5948  021132  012737  000000  000000          MOV     #0,@#0          ;CLEAR LOC 0
5949  021140  005000                          CLR     R0              ;CLEAR R0
5950  021142  106620                          MTPD    (R0)+           ;MODE 2, MTPD
5951  021144  005067  156626                  CLR     PS              ;SET KERNEL MODE
5952  021150  022737  125252  000000          CMP     #125252,@#0     ;CHECK DATA ON LOC 0
5953  021156  001463                          BEQ     TESTN1
5954  021160  104000                          EMT                     ;INCORRECT DATA FROM MTPD
5955
5956  021162  000402          BRTAB:  BR      .+6
5957  021164  001002                  BNE     .+6
5958  021166  001402                  BEQ     .+6
5959  021170  002002                  BGE     .+6
5960  021172  002402                  BLT     .+6
```

```
5961  021174  003002                  BGT     .+6
5962  021176  003402                  BLE     .+6
5963  021200  100002                  BPL     .+6
5964  021202  100402                  BMI     .+6
5965  021204  101002                  BHI     .+6
5966  021206  101402                  BLOS    .+6
5967  021210  102002                  BVC     .+6
5968  021212  102402                  BVS     .+6
5969  021214  103002                  BCC     .+6             ;SAME AS BHIS
5970  021216  103402                  BCS     .+6             ;SAME AS BLO
5971
5972          000002          .RADIX  2
5973  021220  177777          YNTAB:  1111111111111111        ;BR
5974  021222  170360                  1111000011110000        ;BNE:  Z=0
5975  021224  007417                  0000111100001111        ;BEQ:  Z=1
5976  021226  146063                  1100110000110011        ;BGE:  N XOR V =0
5977  021230  031714                  0011001111001100        ;BLT:  N XOR V =1
5978  021232  140060                  1100000000110000        ;BGT:  Z+(N XOR V) =0
5979  021234  037717                  0011111111001111        ;BLE:  Z+(N XOR V) =1
5980
5981  021236  177400                  1111111100000000        ;BPL:  N=0
5982  021240  000377                  0000000011111111        ;BMI:  N=1
5983  021242  120240                  1010000010100000        ;BHI:  C+Z=0
5984  021244  057537                  0101111101011111        ;BLOS: C+Z=1
5985  021246  146314                  1100110011001100        ;BVC:  V=0
5986  021250  031463                  0011001100110011        ;BVS:  V=1
5987  021252  125252                  1010101010101010        ;BCC:  C=0
5988  021254  052525                  0101010101010101        ;BCS:  C=1
5989          000010          .RADIX  8
5990
5991                          ;*****************************************************************************************
5992                          ; THE FOLLOWING ARE SPECIAL CPU TRAP
5993                          ;HANDLERS TO TRAP AND REPORT SPECIAL TRAPS.
5994                          ;
5995                          ;*****************************************************************************************
5996
5997  021256                  T04:
5998  021256  104000                  EMT                     ;TRAPPED THRU LOC. 4
5999  021260                  T010:
6000  021260  104000                  EMT                     ;TRAPPED THRU LOC. 10
6001  021262                  T014:
6002  021262  104000                  EMT                     ;TRAPPED THRU LOC. 14
6003  021264                  T020:
6004  021264  104000                  EMT                     ;TRAPPED THRU LOC. 20
6005  021266                  T030:
6006  021266  104000                  EMT                     ;TRAPPED THRU LOC. 30
6007  021270                  T034:
6008  021270  104000                  EMT                     ;TRAPPED THRU LOC. 34
6009  021272                  T0114:
6010  021272  104000                  EMT                     ;TRAPPED THRU LOC. 114
6011  021274                  T0244:
6012  021274  104000                  EMT                     ;TRAPPED THRU LOC. 244
6013  021276                  T0250:
6014  021276  104000                  EMT                     ;TRAPPED THRU LOC. 250
6015                          .SBTTL ** STARTING OF TRAP TEST **
6016
```

```
6017
6018                000000                  ;SPECIAL CASE OF ODD;.EVEN .BYTE AND REGISTER 6
                                            HERE=0
6019
6020  021300       000000                  K1:     0
6021  021302       000000                  K2:     0
6022  021304       000000                  K3:     0
6023  021306       000000                  K4:     0
6024  021310       000000                  K5:     0
6025  021312       000000                  K6:     0
6026  021314       052525                  K7:     052525
6027  021316       052400                  K10:    052400
6028  021320       000000                  K11:    0
6029  021322       000000                  K12:    0
6030  021324       000176                  SWR:    176
6031
6032  021326  032737  000001  001020        TESTN1: BIT     #1,@#$ENV
6033  021334  001403                                BEQ     1$
6034  021336  012767  001022  177760                MOV     #$SWREG,SWR
6035  021344                                1$:
6036                                        ;*****************************************************************************************
6037                                        ;TEST 306       TEST AUTO INCREMENT AND DECREMENT OF R6 FOR WORD AND BYTES
6038                                        ;*****************************************************************************************
6039  021344                                TS306:
6040  021344  005006                                CLR     %6
6041  021346  112667  156426                      MOVB    (6)+,HERE       ;SIX SHOULD INCREMENT BY TWO
6042  021352  020627  000002                      CMP     %6,#2
6043  021356  001401                               BEQ     BR1
6044  021360  104000                               EMT                     ;R6 DID NOT AUTO INCREMENT BY TWO
6045
6046  021362  012706  001000                BR1:    MOV     #1000,%6
6047  021366  114627  000000                      MOVB    -(6),#HERE      ;SHOULD DECREMENT BY TWO
6048  021372  020627  000776                      CMP     %6,#776
6049  021376  001401                               BEQ     BR2
6050  021400  104000                               EMT                     ;R6 DID NOT AUTO DECREMENT BY 2
6051
6052  021402  005006                        BR2:    CLR     %6
6053  021404  112626                               MOVB    (6)+,(6)+       ;DOUBLES AUTO INCREMENT OF R6
6054  021406  020627  000004                      CMP     %6,#4
6055  021412  001401                               BEQ     BR3
6056  021414  104000                               EMT                     ;WRONG AUTO INCREMENT OF R6
6057
6058  021416  005006                        BR3:    CLR     %6
6059  021420  005004                               CLR     %4
6060  021422  122624                               CMPB    (6)+,(4)+       ;TEST INCREMENT OF R6
6061  021424  020627  000002                      CMP     %6,#2
6062  021430  001401                               BEQ     BR4
6063  021432  104000                               EMT                     ;WRONG INCREMENT OF R6
6064
6065  021434  005006                        BR4:    CLR     %6
6066  021436  005004                               CLR     %4
6067  021440  122426                               CMPB    (4)+,(6)+       ;TEST INCREMENT OF R6
6068  021442  020627  000002                      CMP     %6,#2
6069  021446  001401                               BEQ     BR5
6070  021450  104000                               EMT                     ;WRONG INCREMENT OF R6
6071
6072  021452  005006                        BR5:    CLR     %6
```

```
 6073  021454  005004                        CLR     %4
 6074  021456  122624                        CMPB    (6)+,(4)+       ;TEST INCREMENT OF R4
 6075  021460  020427  000001                CMP     %4,#1
 6076  021464  001401                        BEQ     BR6
 6077  021466  104000                        EMT                     ;WRONG INCREMENT OF R4
 6078  021470  005006              BR6:      CLR     %6
 6079  021472  005004                        CLR     %4
 6080  021474  122426                        CMPB    (4)+,(6)+       ;TEST INCREMENT OF R6
 6081  021476  020627  000002                CMP     %6,#2
 6082  021502  001401                        BEQ     BR7
 6083  021504  104000                        EMT                     ;WRONG INCREMENT OF R6
 6084
 6085  021506  005006              BR7:      CLR     %6
 6086  021510  005004                        CLR     %4
 6087  021512  122426                        CMPB    (4)+,(6)+       ;TEST INCREMENT OF R4
 6088  021514  020427  000001                CMP     %4,#1
 6089  021520  001401                        BEQ     BR10
 6090  021522  104000                        EMT                     ;WRONG INCREMENT OF P4
 6091
 6092  021524  012706  001000      BR10:     MOV     #1000,%6
 6093  021530  124627  000000                CMPB    -(6),#HERE      ;TEST DECREMENT OF R6
 6094  021534  022706  000776                CMP     #776,%6
 6095  021540  001401                        BEQ     TS307
 6096  021542  104000                        EMT                     ;WRONG DECREMENT OF R6,OR WRONG $TSTNM
 6097                          ;*****************************************************************************
 6098                          ;TEST 307       TEST TRANSFER OF .BYTE USING R6
 6099                          ;*****************************************************************************
 6100  021544                  TS307:
 6101  021544  012767  123456  177536          MOV     #123456,K5
 6102  021552  012767  050505  177520          MOV     #050505,K1
 6103  021560  012705  021300                  MOV     #K1,%5          ;%5=(050505)K1
 6104  021564  012706  021310                  MOV     #K5,%6          ;%6=(123456)K5
 6105  021570  112625                          MOVB    (6)+,(5)+       ;LOW .BYTE OF R6 TO R5
 6106  021572  022767  050456  177500          CMP     #050456,K1
 6107  021600  001401                          BEQ     BR11
 6108  021602  104000                          EMT                     ;FALSE TRANSFER OF .BYTE
 6109
 6110  021604  012767  123456  177476  BR11:   MOV     #123456,K5
 6111  021612  012767  050505  177460          MOV     #050505,K1
 6112  021620  012705  021300                  MOV     #K1,%5          ;%5(050505)K1
 6113  021624  012706  021312                  MOV     #K6,%6          ;%6(123456)K5
 6114  021630  114625                          MOVB    -(6),(5)+       ;LOW .BYTE OF R6 TO R5 (DECREMENT)
 6115  021632  026727  177442  050456          CMP     K1,#050456
 6116  021640  001401                          BEQ     BR12
 6117  021642  104000                          EMT                     ;FALSE R6 .BYTE TRANSFER
 6118
 6119  021644  012767  123456  177426  BR12:   MOV     #123456,K1
 6120  021652  012767  050505  177430          MOV     #050505,K5
 6121  021660  012705  021300                  MOV     #K1,%5          ;(123456)
 6122  021664  012706  021310                  MOV     #K5,%6          ;(050505)
 6123  021670  112526                          MOVB    (5)+,(6)+       ;LOW OF R5 TO LOW OF R6
 6124  021672  022767  050456  177410          CMP     #050456,K5
 6125  021700  001401                          BEQ     BR13
 6126  021702  104000                          EMT                     ;FALSE R6 .BYTE TRANSFER
 6127
 6128  021704  012767  123456  177366  BR13:   MOV     #123456,K1
```

```
 6129  021712  012767  050505  177370          MOV     #050505,K5
 6130  021720  012705  021301                  MOV     #K1+1,%5        ;123456
 6131  021724  012706  021310                  MOV     #K5,%6          ;050505
 6132  021730  112526                          MOVB    (5)+,(6)+       ;HIGH OF R5 TO LOW OF R6
 6133  021732  026727  177352  050647          CMP     K5,#050647
 6134  021740  001401                          BEQ     BR14
 6135  021742  104000                          EMT                     ;FALSE R6 .BYTE TRANSFER
 6136
 6137  021744  012767  123456  177326  BR14:   MOV     #123456,K1
 6138  021752  012767  050505  177330          MOV     #050505,K5
 6139  021760  012705  021301                  MOV     #K1+1,%5        ;R5-123456-ODD ADDRESS
 6140  021764  012706  021310                  MOV     #K5,%6          ;R6-050505--.EVEN ADDRESS
 6141  021770  112625                          MOVB    (6)+,(5)+       ;LOW OF R6 TO HIGH OF R5
 6142  021772  022767  042456  177300          CMP     #042456,K1
 6143  022000  001401                          BEQ     TS310
 6144  022002  104000                          EMT                     ;FAILED LOW OF 6 TO HIGH OF 5,OR WRONG $TSTNM
 6145                          ;*****************************************************************************
 6146                          ;TEST 310       TEST BYTE OPERATION WITH SEQUENTIAL ODD-EVEN ADDRESS
 6147                          ;*****************************************************************************
 6148  022004                  TS310:
 6149  022004  012706  001000                  MOV     #STBOT,R6       ;RESET THE STACK POINTER
 6150  022010  126767  177300  177277          CMPB    K7,K7+1         ;SAME .WORD LOW TO HIGH
 6151  022016  001401                          BEQ     BR15
 6152  022020  104000                          EMT                     ;SHOULD COMPARE LOW TO HIGH
 6153
 6154  022022  126767  177267  177264  BR15:   CMPB    K7+1,K7         ;COMPARE ODD TO .EVEN SAME .WORD
 6155  022030  001401                          BEQ     BR16
 6156  022032  104000                          EMT                     ;ODD TO .EVEN .BYTE FAILURE
 6157
 6158  022034  126767  177257  177252  BR16:   CMPB    K10+1,K7        ;SEQUENTIAL .BYTES
 6159  022042  001401                          BEQ     BR17
 6160  022044  104000                          EMT                     ;ODD TO .EVEN FAILED
 6161
 6162  022046  126767  177244  177236  BR17:   CMPB    K10,K6
 6163  022054  001401                          BEQ     BR20
 6164  022056  104000                          EMT                     ;.EVEN TO EVEN FAILED
 6165  022060  126767  177231  177231  BR20:   CMPB    K7+1,K10+1
 6166  022066  001401                          BEQ     BR21
 6167  022070  104000                          EMT                     ;ODD TO ODD FAILED
 6168
 6169  022072  126767  177220  177217  BR21:   CMPB    K10,K10+1
 6170  022100  001001                          BNE     BR22
 6171  022102  104000                          EMT                     ;LOW TO HIGH IN SAME .WORD FAILED
 6172
 6173  022104  126767  177207  177205  BR22:   CMPB    K10+1,K10+1
 6174  022112  001401                          BEQ     BR23
 6175  022114  104000                          EMT                     ;HIGH TO LOW IN SAME .WORD FAILED
 6176
 6177  022116  126767  177174  177171  BR23:   CMPB    K10,K7+1
 6178  022124  001001                          BNE     TS311
 6179  022126  104000                          EMT                     ;.EVEN TO ODD FAILED,OR WRONG $TSTNM
 6180
 6181
 6182                          ;*****************************************************************************
 6183                          ;TEST 311       TEST THAT DECREMENT R6 TO A VALUE LESS THAN 400 TRAPS
 6184                          ;*****************************************************************************
```

```
 6185  022130
 6186  022130  013700  000142          TS311:  MOV     @#142,R0        ;SAVE LOCATIONS 142-146 FOR WHEN THE
 6187  022134  013701  000144                  MOV     @#144,R1        ;TRAP OCCURS
 6188  022140  013702  000146                  MOV     @#146,R2        ;
 6189  022144  012706  000150                  MOV     #150,%6         ;R6 = 150
 6190  022150  012767  022162  155626          MOV     #TDEC1,4        ;STACK OVERFLOW TRAP POINTER
 6191  022156  005746                          TST     -(6)            ;WITH R6 = 150 SHOULD TRAP
 6192  022160  104000                          EMT                     ;SHOULD HAVE TRAPPED,OR WRONG $TSTNM
 6193  022162                          TDEC1:
 6194
 6195                                  ;*****************************************************************************
 6196                                  ;TEST 312       TEST FOR DECREMENT OF R6 ON OVERFLOW TRAP
 6197                                  ;*****************************************************************************
 6198  022162                          TS312:
 6199  022162  012706  000150                  MOV     #150,%6         ;R6 = 150
 6200  022166  012767  022176  155610          MOV     #TDEC2,4        ;TRAP POINTER
 6201  022174  005746                          TST     -(6)            ;WITH R6 = 150 SHOULD TRAP
 6202  022176  020627  000142          TDEC2:  CMP     %6,#142         ;DID R6 DECREMENT
 6203  022202  001401                          BEQ     TS313
 6204  022204  104000                          EMT                     ;R6 NOT = 142,OR WRONG $TSTNM
 6205
 6206                                  ;*****************************************************************************
 6207                                  ;TEST 313       TEST DIFFERENT TYPES OF OVERFLOW
 6208                                  ;*****************************************************************************
 6209  022206                          TS313:
 6210  022206  010237  000146                  MOV     R2,@#146        ;RESTORE LOCATIONS 142-6
 6211  022212  010137  000144                  MOV     R1,@#144        ;
 6212  022216  010037  000142                  MOV     R0,@#142        ;
 6213  022222  012706  000150                  MOV     #150,%6
 6214  022226  005067  155714                  CLR     146             ;STATUS WORD OF LOC 10
 6215  022232  012767  022242  155544          MOV     #TDEC3,4        ;RETURN TO LOC 4
 6216  022240  005246                          INC     -(6)
 6217  022242  005767  155700          TDEC3:  TST     146
 6218  022246  001001                          BNE     1$
 6219  022250  104000                          EMT                     ;INCREMENT OPERATION NOT INHIBITED
 6220  022252  012705  001000          1$:     MOV     #1000,%5
 6221  022256  012706  000400                  MOV     #400,%6
 6222  022262  012767  022274  155514          MOV     #TDEC4,4
 6223  022270  124645                          CMPB    -(6),-(5)
 6224  022272  104000                          EMT                     ;STACK = 400 AND DECREMENTED, SHOULD TRAP
 6225  022274  012706  000400          TDEC4:  MOV     #400,%6
 6226  022300  012767  022312  155476          MOV     #TDEC7,4
 6227  022306  134546                          BITB    -(5),-(6)
 6228  022310                          TDEC6:
 6229  022310  104000                          EMT                     ;NO STACK OVERFLOW,OR WRONG $TSTNM
 6230  022312                          TDEC7:
 6231
 6232                                  ;*****************************************************************************
 6233                                  ;TEST 314       TEST THAT AN EMT CAUSES AN OVERFLOW TRAP
 6234                                  ;*****************************************************************************
 6235  022312                          TS314:
 6236  022312  012706  000400                  MOV     #400,%6         ;SET UP STACK TO OVERFLOW
 6237  022316  012767  022334  155464          MOV     #VDEC2,10       ;SET UP 77 VECTOR
 6238  022324  012767  022340  155452          MOV     #VDEC,4 ;SET UP OVERFLOW VECTOR
 6239  022332  104000                          EMT                     ;THIS TRAP SHOULD CAUSE OVERFLOW
 6240  022334  000167  157522          VDEC2:  JMP     ERROR1          ;USE JUMP TO GET TO ERROR BECAUSE UNSURE WHAT EMT WILL D
```

```
6241  022340  012767  021260  155442  VDEC:   MOV     #TO10,10        ;RESTORE VECTOR
6242                                  ;*****************************************************************************
6243                                  ;TEST 315       TEST THAT AN EMT CAUSES AN OVERFLOW TRAP
6244                                  ;*****************************************************************************
6245  022346                          TS315:
6246  022346  012706  000400                  MOV     #400,%6         ;SET UP STACK TO OVERFLOW
6247  022352  012767  022370  155440          MOV     #VDEC4,20       ;SET UP IOT VECTOR
6248  022360  012767  022374  155416          MOV     #VDEC3,4        ;SET UP OVERFLOW VECTOR
6249  022366  104000                          EMT                     ;THIS TRAP SHOULD CAUSE OVERFLOW
6250  022370  000167  157466          VDEC4:  JMP     ERROR1          ;USE JUMP TO GET TO ERROR BECAUSE UNSURE WHAT EMT WILL D
6251  022374  012767  021264  155416  VDEC3:  MOV     #TO20,20        ;RESTORE VECTOR
6252
6253                                  ;*****************************************************************************
6254                                  ;TEST 316       TEST THAT AN EMT CAUSES AN OVERFLOW TRAP (CHECK OF YELLOW ZONE)
6255                                  ;*****************************************************************************
6256  022402                          TS316:
6257  022402  012706  000400                  MOV     #400,%6         ;SET UP STACK TO OVERFLOW
6258  022406  012767  022424  155414          MOV     #VDEC6,30       ;SET UP INST VECTOR
6259  022414  012767  022430  155362          MOV     #VDEC5,4        ;SET UP OVERFLOW BECTOR
6260  022422  104000                          EMT                     ;THIS TRAP SHOULD CAUSE OVERFLOW
6261  022424  000167  157432          VDEC6:  JMP     ERROR1          ;USE JUMP TO GET TO ERROR BECAUSE UNSURE WHAT EMT WILL D
6262  022430  012767  002062  155372  VDEC5:  MOV     #ERROR1,30      ;RESTORE VECTOR
6263
6264                                  ;*****************************************************************************
6265                                  ;TEST 317       TEST THAT AN EMT CAUSES AN OVERFLOW TRAP
6266                                  ;*****************************************************************************
6267  022436                          TS317:
6268  022436  012706  000400                  MOV     #400,%6         ;SET UP STACK TO OVERFLOW
6269  022442  012767  022460  155364          MOV     #VDEC8,34       ;SET UP TRAP VECTOR
6270  022450  012767  022464  155326          MOV     #VDEC7,4        ;SET UP OVERFLOW VECTOR
6271  022456  104000                          EMT                     ;THIS TRAP SHOULD CAUSE OVERFLOW
6272  022460  000167  157376          VDEC8:  JMP     ERROR1          ;USE JUMP TO GET TO ERROR BECAUSE UNSURE WHAT EMT WILL D
6273  022464  012767  021270  155342  VDEC7:  MOV     #TO34,34        ;RESTORE VECTOR
6274                                  ;*****************************************************************************
6275                                  ;TEST 320       TEST THAT AN EMT CAUSES AN OVERFLOW TRAP
6276                                  ;*****************************************************************************
6277  022472                          TS320:
6278  022472  012706  000400                  MOV     #400,%6         ;SET UP STACK TO OVERFLOW
6279  022476  012767  022514  155310          MOV     #VDEC10,14      ;SET UP TRT VECTOR
6280  022504  012767  022520  155272          MOV     #VDEC9,4        ;SET UP OVERFLOW VECTOR
6281  022512  104000                          EMT                     ;THIS TRAP SHOULD CAUSE OVERFLOW
6282  022514  000167  157342          VDEC10: JMP     ERROR1          ;USE JUMP TO GET TO ERROR BECAUSE UNSURE WHAT EMT WILL D
6283  022520  012767  021262  155266  VDEC9:  MOV     #TO14,14        ;RESTORE VECTOR
6284                                  ;*****************************************************************************
6285                                  ;TEST 321       TEST THAT AN EMT CAUSES AN OVERFLOW TRAP
6286                                  ;*****************************************************************************
6287  022526                          TS321:
6288  022526  012706  000400                  MOV     #400,%6         ;SET UP STACK TO OVERFLOW
6289  022532  012767  022550  155244          MOV     #VDEC11,4       ;SET UP ILLA VECTOR
6290  022540  012767  022554  155236          MOV     #VDEC12,4       ;SET UP OVERFLOW VECTOR
6291  022546  104000                          EMT                     ;THIS TRAP SHOULD CAUSE OVERFLOW
6292  022550  000167  157306          VDEC11: JMP     ERROR1          ;USE JUMP TO GET TO ERROR BECAUSE UNSURE WHAT EMT WILL D
6293  022554  012767  021256  155222  VDEC12: MOV     #TO4,4  ;RESTORE VECTOR
6294  022562  020627  000370                  CMP     %6,#370         ;STACK PUSHED FOUR WORDS?
6295  022566  001401                          BEQ     TS322
6296  022570  104000                          EMT                     ;TRAP OVERFLOW DID NOT OCCUR
```

```
                        ;*****************************************************************************************
                        ;TEST 322       TEST THAT AN EMT CAUSES AN OVERFLOW TRAP
                        ;*****************************************************************************************
022572                  TS322:
022572  012706  000400          MOV     #400,%6         ;SET UP STACK TO OVERFLOW
022576  012767  022614  155200  MOV     #VDEC13,4       ;SET UP ILLB VECTOR
022604  012767  022620  155172  MOV     #VDEC14,4       ;SET UP OVERFLOW VECTOR
022612  104000                  EMT                     ;THIS TRAP SHOULD CAUSE OVERFLOW
022614  000167  157242  VDEC13: JMP     ERROR1          ;USE JUMP TO GET TO ERROR BECAUSE UNSURE WHAT EMT WILL D
022620  012767  021256  155156  VDEC14: MOV     #TO4,4  ;RESTORE VECTOR

                        ;*****************************************************************************************
                        ;TEST 323       TEST FOR FALSE OVERFLOW TRAP
                        ;*****************************************************************************************
022626                  TS323:

022626  012706  001000          MOV     #STBOT,SP       ;INITIALIZE STACK
022632  012767  022700  155144  MOV     #FOVER,4        ;SET UP OVERFLOW POINTER
022640  012706  001002          MOV     #1002,%6
022644  005746                  TST     -(6)            ;SHOULD NOT OVERFLOW
022646  012706  002002          MOV     #2002,%6
022652  005746                  TST     -(6)            ;SHOULD NOT OVERFLOW
022654  012706  004002          MOV     #4002,%6
022660  005746                  TST     -(6)            ;SHOULD NOT OVERFLOW
022662  012706  010002          MOV     #10002,%6
022666  005746                  TST     -(6)
022670  012706  020000          MOV     #20000,%6       ;SHOULD NOT OVERFLOW
022674  005746                  TST     -(6)
022676  000401                  BR      STP
022700                  FOVER:
022700  104000                  EMT                     ;IT OVERFLOWED,OR WRONG $TSTNM
022702  012767  021256  155074  STP:    MOV     #TO4,4
022710  005067  155072          CLR     6
                        ;*****************************************************************************************
                        ;TEST 324       TEST THAT BIT 4 PSW WILL CAUSE A TRAP TO 14
                        ;*****************************************************************************************
022714                  TS324:
022714  012706  001000          MOV     #STBOT,SP
022720  012767  022744  155066  MOV     #RETAT,RTRAP4   ;SET UP TO TRAP TO 14
022726  012746  000020          MOV     #20,-(SP)       ;PUSH T BIT
022732  012746  022740          MOV     #.+6,-(SP)      ;PUSH PC
022736  000002                  RTI                     ;SET T BIT
022740  000240                  NOP                     ;TRAP HERE
022742  104000                  EMT                     ;TRACE BIT DID NOT TRAP!,OR WRONG $TESTN
022744                  RETAT:
                        ;*****************************************************************************************
                        ;TEST 325       TEST  STACK POINTER DECREMENTS
                        ;*****************************************************************************************
022744                  TS325:
022744  012706  001000          MOV     #STBOT,SP
022750  012767  022774  155036  MOV     #RETBT,RTRAP4
022756  012746  000020          MOV     #20,-(SP)       ;PUSH T BIT
022762  012746  022770          MOV     #.+6,-(SP)      ;PUSH PC
022766  000002                  RTI                     ;SET T BIT
022770  000240                  NOP                     ;TRAP HERE
022772  104000                  EMT                     ;TRACE BIT DID NOT TRAP!
```

```
6353  022774  020627  000774          RETBT:  CMP     SP,#STBOT-4
6354  023000  001401                          BEQ     TS326
6355  023002  104000                          EMT                     ;STACK POINTER WAS NOT PUSHED BY TRAP,OR WRONG $TESTN
6356                                  ;*****************************************************************************************
6357                                  ;TEST 326       TEST  FOR PROPER PC ON STACK
6358                                  ;*****************************************************************************************
6359  023004                          TS326:
6360  023004  012706  001000                  MOV     #STBOT,SP
6361  023010  012767  023030  154776          MOV     #RETCT,RTRAP4
6362  023016  012746  000020                  MOV     #20,-(SP)       ;PUSH T BIT
6363  023022  012746  023030                  MOV     #.+6,-(SP)      ;PUSH PC
6364  023026  000002                          RTI                     ;SET T BIT
6365                                                                  ;TRAP HERE
6366  023030  022767  023030  155736  RETCT:  CMP     #.,STBOT-4
6367  023036  001401                          BEQ     TS327
6368  023040  104000                          EMT                     ;CORRECT PC WAS NOT SAVED ON STACK,OR WRONG $TESTN
6369
6370
6371                                  ;*****************************************************************************************
6372                                  ;TEST 327       TEST  THAT RTT POPS T- BIT
6373                                  ;*****************************************************************************************
6374  023042                          TS327:
6375
6376  023042  012706  001000                  MOV     #STBOT,SP
6377  023046  005001                          CLR     R1              ;CLEAR R1
6378  023050  012746  000020                  MOV     #20,-(SP)
6379  023054  012746  023070                  MOV     #RTT1,-(SP)
6380  023060  012767  023076  154726          MOV     #RTT2,14
6381  023066  000006                          RTT
6382  023070  000240          RTT1:   NOP
6383  023072  001401                          BEQ     TS330
6384  023074  104000                          EMT                     ;T-BIT DID NOT TRAP,OR WRONG $TESTN
6385
6386  023076                  RTT2:
6387                                  ;*****************************************************************************************
6388                                  ;TEST 330       TEST  THAT RTT ALLOWS ONE INST. BEFORE TRAP
6389                                  ;*****************************************************************************************
6390  023076                          TS330:
6391  023076  012705  177777                  MOV     #177777,%5
6392  023102  012706  001000          RTT5:   MOV     #STBOT,SP
6393  023106  012746  000020                  MOV     #20,-(SP)
6394  023112  012746  023130                  MOV     #RTT3,-(SP)
6395  023116  012767  023140  154670          MOV     #RTT4,14
6396  023124  005001                          CLR     R1              ;CLEAR R0
6397  023126  000006                          RTT                     ;SET T-BIT
6398  023130  005201          RTT3:   INC     R1
6399  023132  005205                  INC     %5
6400  023134  001762                  BEQ     RTT5            ;DO THIS TEST NO MORE THAN 2 TIMES
6401  023136  104000                  EMT                     ;DID NOT TRAP
6402  023140  005301          RTT4:   DEC     R1              ;SEE IF RTT ALLOWS 1 INST.
6403  023142  001403                  BEQ     RTT6
6404  023144  005205                  INC     %5              ;DO THIS TEST NO MORE THAN TWO TIMES
6405  023146  001755                  BEQ     RTT5
6406  023150  104000                  EMT                     ;RTT DID NOT ALLOW 1 INST.,OR WRONG $TESTN
6407  023152                  RTT6:
6408                                  ;*****************************************************************************************
```

```
                                        ;TEST 331       TEST  THAT RTI DOES NOT ALLOW 1 INST.
                                        ;*****************************************************************************
 023152                                 TS331:
 023152  012706  001000                         MOV     #STBOT,SP
 023156  012746  000020                         MOV     #20,-(SP)
 023162  012746  023200                         MOV     #RTI1,-(SP)
 023166  012767  023204  154620                 MOV     #RTI2,14
 023174  005001                                 CLR     R1
 023176  000002                                 RTI                     ;SET T-BIT
 023200  005201                         RTI1:   INC     R1              ;RTI SHOULD NOT ALLOW THIS
 023202  104000                                 EMT                     ;T- BIT DID NOT CAUSE TRAP
 023204  005701                         RTI2:   TST     R1
                                                                        ;RTI SHOULD NOT ALLOW 1 INST. BEFORE TRAP
 023206  001401                                 BEQ     TS332
 023210  104000                                 EMT                     ;RTI DID ALLOW 1 INST. BEFORE TRAP,OR WRONG $TESTN

                                        ;*****************************************************************************
                                        ;TEST 332       TEST TRAP ON TRAP THAT TRACE BIT TRAPS ARE INHIBITED ON TRAP INST
                                        ;*****************************************************************************
 023212                                 TS332:

 023212  012706  001000                         MOV     #STBOT,%6
 023216  012767  023256  154570                 MOV     #TRACE,14       ;TRACE TRAP
 023224  005027  000016                         CLR     #16
 023230  005027  000022                         CLR     #22
 023234  012767  023262  154556                 MOV     #TONT1,20       ;IOT TRAP
 023242  012746  000020                         MOV     #20,-(SP)       ;PUSH T BIT
 023246  012746  023254                         MOV     #.+6,-(SP)      ;PUSH PC
 023252  000006                                 RTT
 023254  000004                                 IOT                     ;TRAP, NEW CC HAVE TRACE RESET
 023256                                 TRACE:
 023256  104000                                 EMT                     ;TRACE TRAP WAS NOT INHIBITED
 023260                                 BR70:
 023260  104000                                 EMT                     ;WRONG TSTNM,OR WRONG $TSTNM
 023262  012767  021262  154524        TONT1:  MOV     #TO14,14        ;RESTORE BPT INSTRUCTION TRAP
 023270  012767  021264  154522                 MOV     #TO20,20        ;RESTORE IOT INSTRUCTION TRAP
                                        ;*****************************************************************************
                                        ;TEST 333       TEST THAT THE TRACE BIT IS SAVED IN THE STACK
                                        ;*****************************************************************************
 023276                                 TS333:
 023276  012706  001000                         MOV     #STBOT,%6       ;SET UP STACK POINTER
 023302  012767  023326  154504                 MOV     #TRC1,14        ;TRACE TRAP RETURN
 023310  005067  154502                         CLR     16
 023314  012746  000020                         MOV     #20,-(SP)       ;SET THE T BIT
 023320  012746  023326                         MOV     #TRC1,-(SP)
 023324  000002                                 RTI
 023326  036727  155444  000020  TRC1:   BIT     STBOT-2,#20     ;CHECK FOR T BIT ON STACK
 023334  001001                                 BNE     STP3D
 023336                                 STP3:
 023336  104000                                 EMT                     ;T BIT NOT SAVED ON THE STACK,OR WRONG $TSTNM
 023340  012767  021262  154446        STP3D:  MOV     #TO14,14

                                        ;*****************************************************************************
                                        ;THIS ROUTINE TESTS THAT NO LEGAL ADDRESS TRAPS AND THAT AN ILLEGAL
                                        ;ADDRESS TRAPS TO LOCATION 4.  THIS WILL RUN ON 30K SYSTEM.  BUT IF
                                        ;SWITCH REGISTER BIT 1=0, THEN THE MEMORY FROM 28K-30K IS NOT LOOKED
```

```
                                ;AT, SINCE IT MAY HAVE I/O DEVICES.  IF SWR BIT 1=1, THEN THAT AREA IS
                                ;CHECKED.  (IT SHOULD EITHER ALL TRAP OR ALL NOT TRAP).  LOC 160000
                                ;IS NO LONGER GUARANTEED TO TRAP, SINCE IT MAY CONTAIN MEMORY. LOCATION
                                ;177700 (THE UNIBUS ADDRESS FOR R0 ON OLDER SYSTEMS) IS USED FOR FORCING
                                ;A TIMEOUT IN THE EVENT THAT THERE WAS NO TIMEOUT FROM 0K-28K OR 30K.
                                ;THIS ROUTINE TESTS MEMORY UNTIL IT DOES A NXM STOP
                                ;*************************************************************************
                                ;TEST 334       TEST NON-EXISTENT ADDRESS TRAPS
                                ;*************************************************************************
023346                          TS334:
023346  005000                  1$:     CLR     R0              ;
023350  005067  154432                  CLR     6               ;
023354  012767  023440  154422          MOV     #ATRAP,4        ;SET UP ADDRESS TRAP ENTRANCE
023362  012706  001000                  MOV     #STBOT,SP       ;SET STACK POINTER
023366  105720                  NOR:    TSTB    (0)+            ;IF OUTSIDE OF CORE, TRAP TO 4
023370  020027                          CMP     R0,(PC)+        ;IS POINTER INSIDE 28K (30K) CORE
023372  160000                  HICORE: .WORD   160000          ;MAY BE CHANGED TO 170000 IF 30K
023374  103774                          BLO     NOR             ;TEST THE REST OF CORE
023376  012737  023412  000004          MOV     #R0TRAP,@#4     ;SET UP NEW VECTOR POINTER
023404  105737  177700                  TSTB    @#177700        ;SHOULD CAUSE A TRAP
023410                          TRPADR:
023410  104000                          EMT                     ;SHOULD HAVE TRAPED
                                ;TRAP TO HERE IF FORCING TRAP BY TESTING 177700
023412  106767  154360          R0TRAP: MFPS    STATUS
023416  105767  154354                  TSTB    STATUS          ;TEST PSW
023422  001401                          BEQ     1$
023424  104000                          EMT                     ;NEW PSW SHOULD HAVE BEEN ZERO
023426  026727  155342  023410  1$:     CMP     STBOT-4,#TRPADR ;TEST OLD PC AT STACK
023434  001437                          BEQ     TRAPB
023436  104000                          EMT                     ;OLD PC WAS NOT SAVED
                                ;RETURN HERE ON AN ADDRESS TRAP FROM MEMORY BELOW 28K (OR 30K)
023440  005300                  ATRAP:  DEC     R0              ;
023442  010067  000032                  MOV     R0,CORH         ;MOVE THE FIRST NXM LOCATION IN CORH
                                ;THIS ROUTINE DOES NXM TRAPS UNTIL IT FINDS AN EXISTENT MEMORY LOCATION
023446  013700  023372                  MOV     @#HICORE,R0     ;SET UP THE HIGHEST MEM LOCATION
023452  005300                          DEC     R0              ;MAKE 1 LESS THAN THE HIGHEST CORE BOUNDARY
023454  000402                          BR      NOSUB           ;DON'T SUBTRACT 1K FIRST TIME
023456  162700  001000          CTRAP:  SUB     #1000,R0        ;SUBTRACT 1K OCTAL BYTE FROM ADDRESS
                                                                ;TO SPEED UP TESTING
023462  012767  023506  154314  NOSUB:  MOV     #BTRAP,4        ;SET UP THE VECTOR
023470  012706  001000                  MOV     #STBOT,SP
023474  005710                          TST     (R0)            ;DOES THIS MEMORY EXIST?
                                                                ;IF NXM, TRAP TO BTRAP
023476  020027                  DTRAP1: CMP     R0,(PC)+        ;IF EXISTS, IS THIS THE SAME TRAP THAT CAUSED
                                                                ;TRAP TO ATRAP
023500  000000                  CORH:   .WORD   0
023502  101414                          BLOS    TRAPB
023504  104000                          EMT                     ;CONTENTS OF R0 SHOULD BE LESS THAN OR EQUAL  TO CORH
                                                                ;IF THIS COMPARISON FAILS IT MEANS
                                                                ;THAT SOME LEGAL ADDRESS TRAPPED, OR
                                                                ;THAT AN ILLEGAL ADDRESS DID NOT TRAP
023506  106767  154264          BTRAP:  MFPS    STATUS
023512  105767  154260                  TSTB    STATUS
023516  001401                          BEQ     1$
023520  104000                          EMT                     ;NEW PSW SHOULD HAVE BEEN ZERO
023522  026727  155246  023476  1$:     CMP     STBOT-4,#DTRAP1 ;CHECK IF TRAP PC IS OK
```

```
6521  023530  001752                        BEQ     CTRAP
6522  023532                        AUTO1:
6523  023532  104000                        EMT                     ;OLD PC WAS NOT SAVED OR WRONG $TESTN
6524  023534  012767  021256  154242  TRAPB: MOV     #TO4,4          ;RESET TRAP CATCHER
6525  023542  005067  154240                CLR     6               ;RESET TRAP CATCHER
6526
6527
6528                                  ;THIS ROUTINE WILL FIGURE OUT IF YOU HAVE A DL11W
6529  023546  012706  001000                MOV     #STBOT,SP       ;SET UP THE STACK POINTER
6530  023552  012767  023566  154224        MOV     #NODL,4         ;SET UP THE TRAP VECTOR
6531  023560  005767  154000                TST     TTCSR           ;TEST THE PUNCH STATUS REGISTER
6532  023564  000405                        BR      DL11W
6533  023566  012767  021256  154210  NODL:  MOV     #TO4,4
6534  023574  000167  074760                JMP     SLU1ST          ;IF NO SLU FIND OUT WHY IN SLU TEST
6535  023600  012767  021256  154176  DL11W: MOV     #TO4,4
6536
6537                                  ;******************************************************************************
6538                                  ;TEST 335       TEST THAT A TTY INTERRUPT CAUSES AN OVERFLOW TRAP
6539                                  ;******************************************************************************
6540  023606                          TS335:
6541  023606  032737  000001  001020        BIT     #1,@#$ENV       ;ARE WE RUNNING UNDER APT?
6542  023614  001405                        BEQ     1$              ;IF NO THEN GO DO THE TEST
6543  023616  005737  001006                TST     @#$PASS         ;IS THIS THE FIRST PASS?
6544  023622  001402                        BEQ     1$              ;YES,GO DO THE TEST
6545  023624  000167  000406                JMP     TS341           ;NO SKIP THE NEXT FOUR TESTS
6546                                                                ;BECAUSE APT USES SLU1 TO COMMUNICATE
6547  023630  012767  000340  154140  1$:    MOV     #340,STATUS     ;LOCK OUT INTERRUPT
6548  023636  012706  000400                MOV     #400,%6         ;SET UP STACK TO OVERFLOW
6549  023642  012767  023704  154134        MOV     #TDEC77,4       ;SET UP OVERFLOW TRAP
6550  023650  016767  154210  001542        MOV     64,     TEMP1   ;SAVE CONTENTS OF INTERRUPT VECTOR
6551  023656  012767  023702  154200        MOV     #TDEC8,64       ;SET UP INTERRUPT VECTOR
6552  023664  012767  000100  153672        MOV     #100,TTCSR      ;SET INTERRUPT ENABLE
6553  023672  005067  154100                CLR     STATUS          ;ALLOW INTERRUPT TO OCCUR
6554  023676  000167  074656                JMP     SLU1ST          ;NO INTERRUPT OCCURRED SO GO TO SLU TEST
6555                                                                ;TO FIND OUT WHY ADD REPORT PROPER ERROR
6556  023702                          TDEC8:
6557  023702  104000                        EMT                     ;OVERFLOW TRAP DID NOT OCCUR
6558  023704  005067  153654        TDEC77: CLR     TTCSR           ;CLEAR INTERRUPT ENABLE
6559  023710  012767  021256  154066        MOV     #TO4,4
6560  023716  005067  154064                CLR     6
6561  023722  016767  001472  154134        MOV     TEMP1,  64      ;RESTORE CONTENTS OF INTERRUPT VECTOR
6562                                  ;******************************************************************************
6563                                  ;TEST 336       TEST THAT A PENDING INTERRUPT OCCURS BEFORE TRAP
6564                                  ;******************************************************************************
6565  023730                          TS336:
6566  023730  012706  001000                MOV     #STBOT,%6
6567  023734  012767  000340  154034        MOV     #340,STATUS     ;SET TO A HIGH PRIORITY LEVEL
6568  023742  016767  154116  001450        MOV     64,     TEMP1   ;SAVE CONTENTS OF INTERRUPT VECTOR
6569  023750  012767  024014  154106        MOV     #TR0,64
6570  023756  012767  000100  153600        MOV     #100,TTCSR      ;INTERRUPT FOR TTY PUNCH/PRINTER
6571  023764  012767  024016  154042        MOV     #BR7!1,34       ;TRAP VECTOR
6572  023772  012767  024020  154064        MOV     #TR2,64         ;TTY VECTOR
6573  024000  012767  000340  154030        MOV     #340,36         ;IF TRAP TRAPS, MOVE 340 TO PRIORITY
6574  024006  005067  153764                CLR     STATUS          ;SHOULD INTERRUPT AT END OF CLR INST
6575  024012  104400                        TRAP                    ;TTY INTERRUPT SHOULD OVERRIDE TRAP
6576  024014                          TR0:
```

```
6577  024014  104000                          EMT                     ;TTY SHOULDN'T HAVE INTERRUPTED
6578  024016                          BR71:
6579  024016  104000                          EMT                     ;TRAP OCCURRED FIRST
6580  024020  005067  154012          TR2:    CLR     36
6581  024024  016767  001370  154032          MOV     TEMP1,  64      ;RESTORE CONTENTS OF INTERRUPT VECTOR
6582  024032  042767  000100  153524          BIC     #100,TTCSR
6583                                  ;*************************************************************************************
6584                                  ;TEST 337       TEST THAT A PENDING INTERRUPT, INTERRUPTS BETWEEN TRAPS
6585                                  ;*************************************************************************************
6586  024040                          TS337:
6587  024040  012706  001000                  MOV     #STBOT,%6
6588  024044  012767  000340  153724          MOV     #340,STATUS
6589  024052  012767  000100  153504          MOV     #100,TTCSR
6590  024060  012767  024126  153746          MOV     #TR3,34                 ;TRAP
6591  024066  016767  153772  001324          MOV     64,     TEMP1   ;SAVE CONTENTS OF INTERRUPT VECTOR
6592  024074  012767  024132  153762          MOV     #TR4,64                 ;TTY OUTPUT
6593  024102  012767  000340  153756          MOV     #340,66                 ;TTY OUTPUT PRIORITY
6594  024110  012767  024130  153702          MOV     #TR5,20                 ;IOT
6595  024116  012767  000340  153676          MOV     #340,22                 ;IOT PRIORITY
6596  024124  104400                          TRAP                    ;THE ACT OF TRAPPING LOWER PRIORITY
6597  024126  000004                  TR3:    IOT                     ;INTERRUPT SHOULD OCCUR IN PLACE OF IOT TRAP
6598  024130                          TR5:
6599  024130  104000                          EMT                     ;NO INTERRUPT BETWEEN TRAPS,OR WRONG $TSTNM
6600  024132  005067  153664          TR4:    CLR     22              ;CLR IOT PRIORITY
6601  024136  005067  153724                  CLR     66
6602  024142  012767  021270  153664          MOV     #TO34,34
6603  024150  016767  001244  153706          MOV     TEMP1,  64      ;RESTORE CONTENTS OF INTERRUPT VECTOR
6604  024156  012767  000022  153634          MOV     #22,20
6605  024164  042767  000100  153372          BIC     #100,TTCSR      ;CLEAR IE BIT IN SLU1 XMIT CSR
6606
6607                                  ;*************************************************************************************
6608                                  ;TEST 340       TEST THAT "RESET" GOES TO OUTSIDE WORLD
6609                                  ;*************************************************************************************
6610  024172                          TS340:
6611  024172  032737  000001  001020          BIT     #1, @#$ENV      ;ARE WE RUNNING UNDER APT
6612  024200  001403                          BEQ     70$             ;IF NO THEN DO TEST
6613  024202  005737  001006                  TST     @#$PASS         ;IS THIS FIRST PASS
6614  024206  001013                          BNE     TS341           ;IF NO THEN SHIP TO NEXT TEST
6615  024210                          70$:
6616  024210  016700  153346                  MOV     TKB,R0          ;MAKE SURE RECEIVER DONE IS CLEAR
6617  024214  012767  000100  153336          MOV     #100,TRCSR      ;SET INTERRUPT ENABLE
6618  024222  000005                          RESET                   ;SHOULD CLEAR INTERRUPT ENABLE
6619  024224  032767  000100  153326          BIT     #100,TRCSR      ;TEST FOR CLEAR
6620  024232  001401                          BEQ     TS341
6621  024234  104000                          EMT                     ;RESET FAILED TO CLEAR TRCSR,OR WRONG $TSTNM
6622  024236                          NODL2:
6623                                  ;*************************************************************************************
6624                                  ;TEST 341       TEST THAT RESET HAS NO EFFECT ON THE TRACE TRAP
6625                                  ;*************************************************************************************
6626  024236                          TS341:
6627  024236  032737  000001  001020          BIT     #1, @#$ENV      ;ARE WE RUNNING UNDER APT
6628  024244  001403                          BEQ     70$             ;IF NO THEN DO TEST
6629  024246  005737  001006                  TST     @#.PASS         ;IS THIS FIRST PASS
6630  024252  001024                          BNE     TS342           ;IF NO THEN SHIP TO NEXT TEST
6631  024254                          70$:
6632  024254  012706  001000                  MOV     #STBOT,%6       ;SET STACK
```

```
6633  024260  012767  024306  153526          MOV     #RESET2,14      ;SET UP TRACE VECTOR
6634  024266  012746  000020                  MOV     #20,-(R6)       ;SET THE T-BIT ON STACK
6635  024272  012746  024300                  MOV     #1$,-(R6)       ;MOVE NEW PC ON STACK
6636  024276  000006                          RTT
6637  024300  000005                  1$:     RESET                   ;SHOULD HAVE NO EFFECT
6638  024302  000005                          RESET                   ;NO EFFECT
6639  024304                           RESET3:
6640  024304  104000                          EMT                     ;TRACE TRAP FAILED,OR WRONG $TSTNM
6641  024306  005067  153464          RESET2: CLR     STATUS          ;CLEAR TRACK
6642  024312  005067  153500                  CLR     16              ;TRACE STATUS
6643  024316  012767  021262  153470          MOV     #TO14,14
6644  024324                           SKTST2:
6645
6646                                   ;*****************************************************************************
6647                                   ;TEST 342       TEST THE 'WAIT' INSTRUCTION
6648                                   ;*****************************************************************************
6649  024324                           TS342:
6650  024324  122767  000001  154466          CMPB    #APTENV,$ENV            ;RUNING IN APT MODE?
6651  024332  001003                          BNE     1$                      ;IF NOT, DO THIS TEST
6652  024334  005767  154446                  TST     $PASS                   ;IS THIS THE FIRST PASS?
6653  024340  001051                          BNE     STP4E                   ;IF NOT FIRST PASS, SKIP TEST
6654  024342                           1$:
6655  024342  042767  000100  153214          BIC     #100,TTCSR      ;CLEAR INTERRUPT ENABLE
6656  024350  012706  001000                  MOV     #STBOT,SP       ;SET UP THE STACK
6657  024354  016767  153504  001036          MOV     64,     TEMP1   ;SAVE CONTENTS OF INTERRUPT VECTOR
6658  024362  012767  024442  153474          MOV     #WATE,64        ;SET UP THE INTERRUPT VECTOR
6659  024370  005067  153472                  CLR     66
6660  024374  105767  153164          WATE1:  TSTB    TTCSR           ;WAIT FOR READY
6661  024400  100375                          BPL     WATE1           ;TO BE UP
6662  024402  012767  000015  153156          MOV     #15,TPB         ;DO A CARRIAGE RETURN
6663  024410  105767  153150          WATE2:  TSTB    TTCSR           ;WAIT FOR READY TO COME UP
6664  024414  100375                          BPL     WATE2
6665  024416  012767  000015  153142          MOV     #15,TPB         ;DO ANOTHER CARRIAGE RETURN
6666  024424  052767  000100  153132          BIS     #100,TTCSR      ;SET THE INTERRUPT ENABLE
6667  024432  005067  153340                  CLR     STATUS          ;CLEAR THE PSW
6668  024436  000001                  WATE3:  WAIT                    ;WAIT FOR THE INTERRUPT
6669  024440  104000                          EMT                     ;WAIT INSTRUCTION DID NOT LOOP
6670  024442  005767  153330          WATE:   TST     STATUS  ;IS THE PSW CORRECT?
6671  024446  001401                          BEQ     1$
6672  024450  104000                          EMT                     ;NEW PSW SHOULD HAVE BEEN ZERO
6673  024452  026727  154316  024440  1$:     CMP     STBOT-4,#WATE3+2        ;IS THE OLD PC SAVED
6674  024460  001401                          BEQ     STP4E
6675  024462                           STP4:
6676  024462  104000                          EMT                     ;OLD PC WAS NOT SAVED OR WRONG $TESTN
6677  024464  016767  000730  153372  STP4E:  MOV     TEMP1,  64      ;RESTORE CONTENTS OF INTERRUPT VECTOR
6678  024472  042767  000100  153064          BIC     #100,TTCSR      ;CLEAR IE BIT IN SLU1 XMIT CSR
6679                                   ;*****************************************************************************
6680                                   ;TEST 343       TEST THAT USING REGISTER ADDR (177700) CAUSES TIME OUT.
6681                                   ;*****************************************************************************
6682  024500                           TS343:
6683                                           ;
6684                                           ;REGISTER ADDRESS (177700-177717) CAUSE TIME OUT WHEN USED
6685                                           ;AS PROGRAM ADDRESS BY THE CPU.
6686                                           ;
6687  024500  012706  001000                  MOV     #STBOT,SP       ;SET  STACK POINTER
6688  024504  012767  024520  153272          MOV     #RETR1,RTRAP5   ;SET TRAP RETURN ADDR
```

```
6689  024512  005237  177700          PCN1:   INC     @#177700        ;BAD ADDR REFERENCE, TRAP TO 4
6690  024516  104000                          EMT                     ;REFERENCING 177700 DID NOT CAUSE TIME OUT
6691  024520  022767  024516  154246  RETR1:  CMP     #PCN1+4,STBOT-4 ;PROPER PC STORED ON STACK?
6692  024526  001401                          BEQ     TS344
6693  024530  104000                          EMT                     ;OLD PC WAS NOT SAVED IN STACK
6694
6695                                          ;*************************************************************************
6696                                          ;ODD ADDRESS USED BY A "WORD" INSTRUCTION SHOULD NOT
6697                                          ;CAUSE A TRAP, BUT THE LOW ORDER ADDRESS BIT WOULD BE IGNORED.
6698                                  ;*****************************************************************************************
6699                                  ;TEST 344       TEST ODD ADDRESS TRAP IS NOT IMPLEMENTED.
6700                                  ;*****************************************************************************************
6701  024532                          TS344:
6702                                          ;
6703  024532  012737  024556  000004          MOV     #RETR2,@#RTRAP5 ;SET TRAP RETURN ADDR
6704  024540  005037  000000                  CLR     @#0             ;PUT ALL 0 IN LOC 0
6705  024544  005337  000001                  DEC     @#1             ;DECREMENT ODD ADDRESS, SHOULD NOT TRAP
6706  024550  022737  177777  000000        CMP     #-1,@#0         ;WORD LOC 0 HAS ALL ONES?
6707  024556                          RETR2:
6708  024556  001401                          BEQ     TS345
6709  024560  104000                          EMT                     ;LOC 0 DID NOT STORE -1,OR ODD ADDR REFERENCE CAUSE TRAP
6710
6711                                          ;*************************************************************
6712                                          ;
6713                                          ;USING ADDRESS 177700 IN MODE 2, CAUSES BUS ERROR, BUT
6714                                          ;THE REGISTER IN USE WILL BE INCREMENTED.
6715                                          ;
6716                                  ;*****************************************************************************************
6717                                  ;TEST 345       TEST THAT IN MODE 2, BAD ADDRESS REFERENCE CAUSES BUS ERROR.
6718                                  ;*****************************************************************************************
6719  024562                          TS345:
6720  024562  012737  024602  000004          MOV     #RETR3,@#RTRAP5 ;SET TRAP RETURN ADDR
6721  024570  012700  177700                  MOV     #177700,R0      ;STORES BAD MEMORY REFERENCE
6722  024574  012720  001234                  MOV     #1234,(R0)+     ;BAD ADDR REFERENCE, TRAP TO LOC 4
6723  024600  104000                          EMT                     ;ADDRESSING 177700 DID NOT CAUSE TRAP
6724  024602  022700  177702          RETR3:  CMP     #177702,R0      ;WAS R0 INCREMENTED?
6725  024606  001401                          BEQ     TS346
6726  024610  104000                          EMT                     ;R0 WAS NOT INCREMENTED
6727                                          ;*************************************************************
6728                                          ;
6729                                          ;AFTER THE FIRST BUS ERROR WAS ENCOUNTERED, AN ATTEMPT WAS MADE
6730                                          ;TO PUSH PC AND PS INTO THE STACK. HOWEVER, IF THE STACK POINTER
6731                                          ;WAS BAD, A BOUBLE BUS ERROR OCCURED.  THE STACK POINTER WOULD
6732                                          ;THEN BE SET TO LOCATION 4, OLD PC AND PS WERE PUSHED INTO
6733                                          ;LOCATIONS 0 AND 2. THE PROCESSOR WOULD TRAP TO 4 AND CONTINUE
6734                                          ;EXECUTION.
6735                                          ;
6736                                  ;*****************************************************************************************
6737                                  ;TEST 346       TEST FOR DOUBLE BUS ERROR.
6738                                  ;*****************************************************************************************
6739  024612                          TS346:
6740  024612  012767  024654  153164          MOV     #DBE1,RTRAP5    ;SET TRAP RETURN ADDR
6741  024620  012737  000340  000006          MOV     #340,@#6        ;SET UP PS
6742  024626  012767  024652  153154          MOV     #DBE2,RTRAP     ;SET TRAP RETURN ADDR
6743  024634  012737  000340  000012          MOV     #340,@#12       ;SET UP PS
6744  024642  012706  177700                  MOV     #177700,SP      ;SET ILLEGAL SP
```

```
 6745  024646  000077                    DBE:    TRAPA                   ;ILLEGAL INSTRUCTION
 6746  024650  104000                            EMT                     ;DOUBLE BUS ERROR DID NOT CAUSE TRAP
 6747  024652                            DBE2:
 6748  024652  104000                            EMT                     ;TRAP TO WRONG LOCATION
 6749  024654  022737  024650  000000    DBE1:   CMP     #DBE+2,@#0      ;OLD PC GOT SAVED?
 6750  024662  001401                            BEQ     DBE3
 6751  024664  104000                            EMT                     ;OLD PC DID NOT GET SAVEDD
 6752  024666  022737  000340  000002    DBE3:   CMP     #340,@#2        ;CORRECT PS SAVED?
 6753  024674  001401                            BEQ     DBE4
 6754  024676  104000                            EMT                     ;CORRECT PS DID NOT GET SAVE
 6755  024700  022706  000000            DBE4:   CMP     #0,SP           ;SP POINTS TO LOC 0?
 6756  024704  001401                            BEQ     DBE5
 6757  024706  104000                            EMT                     ;SP IS NOT POINTING TO LOC 0
 6758  024710  012706  001000            DBE5:   MOV     #STBOT,SP       ;RESET SP
 6759  024714  012767  021256  153062            MOV     #TO4,4          ;RESET VECTOR 4
 6760  024722  012767  021260  153060            MOV     #TO10,10        ;RESET VECTOR 10
 6761
 6762                                            ;*****************************************************************
 6763                                            ;THIS TEST WILL CHECK THE SERVICE ROUTINE FOR A CONTROL CHIP ERROR.
 6764                                            ;THIS IS DONE BY EXECUTING INSTRUCTIONS WHICH JUMP TO NON-EXISTENT
 6765                                            ;CONTROL-CHIP. THE TEST EXECUTES AN FIS INSTRUCTION WHICH
 6766                                            ;IS ILLEGAL ON ALL PROCESSORS USING THE DCF11-A CHIP SET.
 6767                                            ;A CTLERR TRAPS TO LOCATION 10.
 6768                                            ;THE RESET LINE IS ALSO ASSERTED FOR 1 CYCLE.
 6769                                    ;*************************************************************************
 6770                                    ;TEST 347       TEST CTLERR SERVICE ROUTINE
 6771                                    ;*************************************************************************
 6772  024730                            TS347:
 6773
 6774  024730  012706  001000                    MOV     #STBOT,R6       ;INIT STACK POINTER
 6775  024734  012737  024754  000010            MOV     #1$,@#10                ;SET UP RETURN ADDR FROM TRAP
 6776  024742  012737  000340  000012            MOV     #340,@#12       ;SET TRAP PRIORITY=7
 6777  024750  075006                            FADD    R6              ;EXECUTE FIS INSTR..SHOULD CAUSE CTLERR
 6778  024752  000000                            HALT                    ;DID NOT TRAP..CHECK CSEL LINE
 6779  024754  012706  001000            1$:     MOV     #STBOT,R6       ;RE-INIT STACK POINTER
 6780  024760  012767  021260  153022            MOV     #TO10,10        ;RESET VECTOR 10
 6781
 6782                                    ;*************************************************************************
 6783                                    ;TEST 350       TEST THAT ALL RESERVED INSTRUCTIONS TRAP
 6784                                    ;*************************************************************************
 6785  024766                            TS350:
 6786  024766  042767  000100  152570            BIC     #100,TTCSR
 6787                                                                    ; SET UP TO SEE IF
 6788  024774  013767  000010  000042            MOV     @#10,TENSAVE    ;  THIS PROCESSOR HAS THE
 6789  025002  012737  025046  000010            MOV     #TRAP10,@#10    ;  FLOATING POINT OPTION
 6790  025010  170127  000000                    LDFPS   #0              ;DO A FPP INSTRUCTION
 6791                                                                    ;IF NO TRAP FPP INSTALLED
 6792  025014  013767  025370  000356            MOV     @#FPP,FINISH    ;SO RESET END OF TABLE POINTER
 6793  025022  000411                            BR      AROUND          ; THE FOLLOWING
 6794
 6795                                    ;* IF NO CIS OPTION TRAP TO HERE
 6796  025024  042777  000040  174272    CISTRP: BIC     #40,@SWR        ;CLEAR CIS OPTION IN SWR
 6797  025032  012716  025100                    MOV     #CONCIS,(SP)    ;CHANGE RETURN ADDRESS TO CONCIS LOCATION
 6798  025036  000002                            RTI                     ;RETURN
 6799  025040  000000                    CISADR: .WORD   0               ;DATA FOR CIS
 6800  025042  000000                            .WORD   0               ;               INSTRUCTION
```

```
6801  025044  000000                    TENSAVE:.WORD   0               ; A PLACE TO STORE CONTENTS OF 10
6802  025046                            TRAP10:                         ; LEAVE THE TABLE ALONE
6803
6804  025046                            AROUND:                         ;  CONTINUATION POINT
6805  025046  012737  000246  000244            MOV     #246,@#244      ;  RESTORE THE TRAP VECTOR
6806  025054  012737  025024  000010            MOV     #CISTRP,@#10    ;SET UP TO SEE IF THIS HAS THE CIS OPTION
6807  025062  076144                            .WORD   076144          ;EXECUTE A CMPCI INSTRUCTION
6808  025064  025040                            .WORD   CISADR          ;OPERANDS
6809  025066  025040                            .WORD   CISADR          ;          FOR CIS
6810  025070  000000                            .WORD   0               ;                INSTRUCTION
6811  025072  052777  000040  174224            BIS     #40,@SWR        ;SET CIS PRESENT BIT
6812  025100  016737  177740  000010  CONCIS:   MOV     TENSAVE,@#10    ; RESTORE THE ILLEGAL INST. VECTOR
6813  025106  012703  025260                    MOV     #TABLE,TAB      ;TABLE POINTER
6814  025112  012305                    GIN1:   MOV     (TAB)+,FIRST    ;FIRST OR CURRENT INSTRUCTION
6815  025114  012301                            MOV     (TAB)+,LAST     ;LAST INSTRUCTION OR GROUP
6816  025116  020537  025334                    CMP     FIRST,@#CIS
6817  025122  001007                            BNE     1$
6818  025124  032777  000040  174172            BIT     #40,@SWR
6819  025132  001403                            BEQ     1$
6820  025134  012703  025370                    MOV     #FPP,TAB
6821  025140  000764                            BR      GIN1
6822  025142  020567  000232            1$:     CMP     FIRST,FINISH    ;TESTED ALL
6823  025146  001415                            BEQ     GIN3            ;YES BRANCH
6824  025150  010567  000226                    MOV     FIRST,INST      ;SET UP INST
6825  025154  005267  000222            GIN2:   INC     INST
6826  025160  012767  025214  152622            MOV     #RET,10         ;SET UP RETURN FROM TRAP
6827  025166  012706  001000                    MOV     #STBOT,SP       ;SET UP STACK POINTER
6828  025172  005067  152600                    CLR     CC              ;CLEAR PRIORITY
6829  025176  000167  000200                    JMP     INST            ;EXECUTE RESERVED INSTRUCTION
6830  025202  012767  021260  152600  GIN3:     MOV     #TO10,10        ;RESET VECTOR 10
6831  025210  000167  000252                    JMP     THRPRT          ;JUMP TO EIS TEST
6832
6833                                    ;TRAPPING SHOULD SEND YOU HERE
6834  025214  020627  000774            RET:    CMP     SP,#STBOT-4     ;TEST DECREMENT OF SP
6835  025220  001401                            BEQ     RET1
6836  025222  104000                            EMT                     ;WRONG DECREMENT
6837  025224  026727  153544  025404    RET1:   CMP     STBOT-4,#INST+2 ;LOC OF INST UNINCREMENTED
6838  025232  001401                            BEQ     RET2
6839  025234  104000                            EMT                     ;INST INC ON TRAP
6840  025236  005767  153534            RET2:   TST     STBOT-2
6841  025242  001401                            BEQ     RET3
6842  025244                            RET4:
6843  025244  104000                            EMT                     ;CONDITION CODES SET ON TRAP OR WRONG $TSTNM
6844  025246  026701  000130            RET3:   CMP     INST,LAST
6845  025252  001717                            BEQ     GIN1            ;SET UP NEW GROUP
6846  025254  000167  177674                    JMP     GIN2            ;FINISH OLD GROUP
6847                                                                    ;END OF INSTRUCTION GROUP
6848  025260  000007                    TABLE:  7                       ;END OF OPERATE
6849  025262  000077                            77
6850  025264  000207                            207                     ;RTS,RT1,JMP
6851  025266  000227                            227
6852  025270  006777                            6777
6853  025272  007777                            7777
6854  025274  075037                            075037
6855  025276  076017                            76017
6856  025300  076032                            76032
```

```
 6857  025302  076037                    76037
 6858  025304  076045                    76045
 6859  025306  076047                    76047
 6860  025310  076077                    76077
 6861  025312  076127                    76127
 6862  025314  076132                    76132
 6863  025316  076137                    76137
 6864  025320  076145                    76145
 6865  025322  076147                    76147
 6866  025324  076157                    76157
 6867  025326  076167                    76167
 6868  025330  076177                    76177
 6869  025332  076777                    76777
 6870  025334  076017            CIS:    76017
 6871  025336  076032                    76032
 6872  025340  076037                    76037
 6873  025342  076045                    76045
 6874  025344  076047                    76047
 6875  025346  076077                    76077
 6876  025350  076127                    76127
 6877  025352  076132                    76132
 6878  025354  076137                    76137
 6879  025356  076145                    76145
 6880  025360  076147                    76147
 6881  025362  076157                    76157
 6882  025364  076167                    76167
 6883  025366  076177                    76177
 6884  025370  167777            FPP:    167777                  ;  START OF THE FPP INSTRUCTIONS
 6885  025372  177700                    177700
 6886  025374  177716                    177716
 6887  025376  177777                    177777
 6888  025400  025400            FINISH: .                       ;END FLAG
 6889  025402  000000            INST:   HALT                    ;WILL CONTINUE RESERVED INST
 6890  025404  000000                    HALT                    ;SHOULD TRAP TO LOC 10
 6891  025406  000000                    HALT                    ;LOC 10 SHOULD SEND YOU TO
 6892  025410  000000                    HALT                    ;RET
 6893  025412  000000                    HALT
 6894                            .SBTTL ** STARTING OF EIS TEST **
 6895
 6896
 6897          000000            DUMMY=  0
 6898          000051            F=      51
 6899          000176            N=      176
 6900
 6901  025414                    COUNT:
 6902          025416                    .=COUNT+2
 6903  025416                    PSWORD:
 6904          025420                    .=PSWORD+2
 6905  025420                    TEMP1:
 6906          025422                    .=TEMP1+2
 6907  025422                    TEMP2:
 6908          025424                    .=TEMP2+2
 6909  025424                    TEMP3:
 6910          025426                    .=TEMP3+2
 6911  025426                    TEMP4:
 6912          025430                    .=TEMP4+2
```

```
 6913  025430  000000                  TEMP5:  .WORD
 6914  025432  000000                  TEMP6:  .WORD
 6915  025434  177771                  S1:     -7
 6916  025436  025434                  S2:     S1
 6917  025440  177772                  S3:     -6
 6918  025442  177777                  S4:     -1
 6919  025444  040000                  S5:     40000
 6920  025446  025444                  S6:     S5
 6921  025450  040000                  S7:     40000
 6922  025452  177776                  S8:     -2
 6923  025454  000002                  S9:     2
 6924  025456  025454                  S10:    S9
 6925  025460  000002                  S11:    2
 6926  025462  177566                  $TPB:   177566
 6927  025464  177564                  $TPS:   177564
 6928
 6929
 6930
 6931
 6932
 6933
 6934
 6935  025466                          THRPRT:
 6936
 6937  025466  012705  001004                  MOV     #$TESTN,R5      ;MAKE R5 POINT TO WHERE TEST # IS SAVED
 6938  025472  005037  025414                  CLR     @#COUNT         ;CLEAR THE COUNTER
 6939  025476  012715  000001                  MOV     #1,(R5)         ;INITIALIZE TEST NUMBER
 6940  025502  012706  001000                  MOV     #STBOT,SP       ;** STACK AT STBOT **
 6941  025506  012737  000001  025420  2$:     MOV     #1,@#TEMP1      ;TEMP1=1
 6942  025514  005037  025422                  CLR     @#TEMP2         ;TEMP2=0
 6943  025520  012737  000001  025424          MOV     #1,@#TEMP3      ;TEMP3=1
 6944  025526  005037  025426                  CLR     @#TEMP4         ;TEMP4=0
 6945  025532  106427  000000                  MTPS    #0
 6946
 6947
```

```
                                        ;**********************************
                                        ;     ASH INSTRUCTION TESTS
                                        ;**********************************



                                                ;*************
                                                ; TESTS 1-36
                                                ;*************

025536  013700  025420          ASTART: MOV     @#TEMP1,%0      ;LOAD R0 WITH THE CONTENTS OF TEMP1
025542  032737  000001  001006          BIT     #1,@#$PASS      ;IS IT AN EVEN PASS ?
025550  001004                        BNE     2$              ;IF NOT THEN GO TO 2$
025552  013701  025422                MOV     @#TEMP2,R1      ;OTHERWISE EXECUTE THE INSTRUCTION
                                                                ;IN MODE 0 USING R1
025556  072001                        ASH     R1,R0
025560  000402                        BR      4$
025562  072067  177634          2$:     ASH     TEMP2,%0        ;SHIFT R0 BY THE NUMBER SPECIFIED BY TEMP2
025566  106737  025416          4$:     MFPS    @#PSWORD        ;SAVE PS
025572  123737  025426  025416          CMPB    @#TEMP4,@#PSWORD;IS THE PS = TEMP4 ?
025600  001401                        BEQ     11$
025602  104000                        EMT                     ;THE PS IS NOT EQUAL TO 0
025604  005237  025414          11$:    INC     @#COUNT         ;INCREMENT THE COUNTER
025610  023700  025424                CMP     @#TEMP3,%0      ;IS THE RESULT IN R0 EQUAL TO TEMP3?
025614  001401                        BEQ     12$
025616                          6$:
025616  104000                        EMT                     ;EITHER INCORRECT R0 OR INCORRECT SEQUENCE
025620  021537  025414          12$:    CMP     (R5),@#COUNT    ;IS THE TEST NUMBER EQUAL TO THE
                                                                ;COUNTER?
025624  001374                        BNE     6$              ;IF NOT GO TO THE HLT ABOVE
025626  005215                        INC     (R5)
025630  021527  000037                CMP     (R5),#37        ;HAS THE CONTENTS OF REGISTERS BEEN SHIFTED LEFT
                                                                ;BY 14. AND RIGHT BY 14.?
025634  002011                        BGE     8$
025636  005237  025422                INC     @#TEMP2
025642  006367  177556                ASL     TEMP3           ;SHIFT TEMP3 LEFT.
025646  021527  000020                CMP     (R5),#20        ;HAS THE CONTENTS OF REGISTERS BEEN SHIFTED LEFT BY 14.?
025652  001004                        BNE     REGR1
025654  000167  000670                JMP     NEGAT           ;IF SO GO TO NEGAT AND INITIATE RIGHT SHIFT
025660  004767  000712          8$:     JSR     PC,TST37        ;IF SO GO AND CONTINUE THE REST OF THE PROGRAM
025664  013701  025420          REGR1:  MOV     @#TEMP1,%1      ;LOAD R1 WITH THE CONTENTS OF TEMP1
025670  032737  000001  001006          BIT     #1,@#$PASS      ;IS IT AN EVEN PASS ?
025676  001004                        BNE     2$              ;IF NOT THEN GO TO 2$
025700  013702  025422                MOV     @#TEMP2,R2      ;OTHERWISE EXECUTE ASH INSTRUCTION IN MODE 0
025704  072102                        ASH     R2,R1           ;USING R1
025706  000402                        BR      4$
025710  072167  177506          2$:     ASH     TEMP2,%1        ;SHIFT R1 BY THE NUMBER SPECIFIED BY TEMP2
025714  106737  025416          4$:     MFPS    @#PSWORD        ;SAVE PS
025720  123737  025426  025416          CMPB    @#TEMP4,@#PSWORD;IS THE PS = TEMP4 ?
025726  001401                        BEQ     11$
025730  104000                        EMT                     ;THE PS IS NOT EQUAL TO 0
025732  005237  025414          11$:    INC     @#COUNT         ;INCREMENT THE COUNTER
025736  023701  025424                CMP     @#TEMP3,%1      ;IS THE RESULT IN R1 EQUAL TO TEMP3?
```

```
7004  025742  001401                        BEQ     12$
7005  025744                          6$:
7006  025744  104000                        EMT                     ;EITHER INCORRECT R1 OR INCORRECT SEQUENCE
7007  025746  021537  025414        12$:    CMP     (R5),@#COUNT    ;IS THE TEST NUMBER EQUAL TO THE COUNTER?
7008  025752  001374                        BNE     6$              ;IF NOT GO TO THE HLT ABOVE
7009  025754  005215                        INC     (R5)
7010  025756  021527  000037                CMP     (R5),#37        ;HAS THE CONTENTS OF REGISTERS BEEN SHIFTED LEFT
7011                                                                ;BY 14. AND RIGHT BY 14.?
7012  025762  002011                        BGE     8$
7013  025764  005237  025422                INC     @#TEMP2
7014  025770  006367  177430                ASL     TEMP3           ;SHIFT TEMP3 LEFT
7015  025774  021527  000020                CMP     (R5),#20        ;HAS THE CONTENTS OF REGISTERS BEEN SHIFTED LEFT BY 14.?
7016  026000  001004                        BNE     REGR2
7017  026002  000167  000542                JMP     NEGAT           ;IF SO GO TO NEGAT AND INITIATE RIGHT SHIFT
7018  026006  004767  000564        8$:     JSR     PC,TST37        ;IF SO GO AND CONTINUE THE REST OF THE PROGRAM
7019  026012  013702  025420        REGR2:  MOV     @#TEMP1,%2      ;LOAD R2 WITH THE CONTENTS OF TEMP1
7020  026016  032737  000001  001006        BIT     #1,@#$PASS      ;IS IT AN EVEN PASS ?
7021  026024  001004                        BNE     2$              ;IF NOT THEN GO TO 2$
7022  026026  013703  025422                MOV     @#TEMP2,R3      ;OTHERWISE EXECUTE ASH INSTRUCTION IN MODE 0
7023  026032  072203                        ASH     R3,R2           ;USING R2
7024  026034  000402                        BR      4$
7025  026036  072267  177360        2$:     ASH     TEMP2,%2        ;SHIFT R2 BY THE NUMBER SPECIFIED BY TEMP2
7026  026042  106737  025416        4$:     MFPS    @#PSWORD        ;SAVE PS
7027  026046  123737  025426  025416        CMPB    @#TEMP4,@#PSWORD;IS THE PS = TEMP4 ?
7028  026054  001401                        BEQ     11$
7029  026056  104000                        EMT                     ;THE PS IS NOT EQUAL TO 0
7030  026060  005237  025414        11$:    INC     @#COUNT
7031  026064  023702  025424                CMP     @#TEMP3,%2      ;IS THE RESULT IN R2 EQUAL TO TEMP3?
7032  026070  001401                        BEQ     12$
7033  026072                          6$:
7034  026072  104000                        EMT                     ;EITHER INCORRECT R2 OR INCORRECT SEQUENCE
7035  026074  021537  025414        12$:    CMP     (R5),@#COUNT    ;IS THE TEST NUMBER EQUAL TO THE COUNTER?
7036  026100  001374                        BNE     6$              ;IF NOT GO TO THE HLT ABOVE
7037  026102  005215                        INC     (R5)
7038  026104  021527  000037                CMP     (R5),#37        ;HAS THE CONTENTS OF REGISTERS BEEN SHIFTED
7039                                                                ;LEFT BY 14, AND RIGHT BY 14.?
7040  026110  002011                        BGE     8$
7041  026112  005237  025422                INC     @#TEMP2
7042  026116  006367  177302                ASL     TEMP3           ;SHIFTED TEMP3 LEFT
7043  026122  021527  000020                CMP     (R5),#20        ;HAS THE CONTENTS OF REGISTERS BEEN SHIFTED LEFT BY 14.?
7044  026126  001004                        BNE     REGR3
7045  026130  000167  000414                JMP     NEGAT           ;IF SO GO TO NEGAT AND INITIATE RIGHT SHIFT
7046  026134  004767  000436        8$:     JSR     PC,TST37        ;IF SO GO AND CONTINUE THE REST OF THE PROGRAM
7047  026140  013703  025420        REGR3:  MOV     @#TEMP1,%3      ;LOAD R3 WITH THE CONTENTS OF TEMP1
7048  026144  032737  000001  001006        BIT     #1,@#$PASS      ;IS IT AN EVEN PASS ?
7049  026152  001004                        BNE     2$              ;IF NOT THEN GO TO 2$
7050  026154  013704  025422                MOV     @#TEMP2,R4      ;OTHERWISE EXECUTE ASH INSTRUCTION IN MODE 0
7051  026160  072304                        ASH     R4,R3           ;USING R3
7052  026162  000402                        BR      4$
7053  026164  072367  177232        2$:     ASH     TEMP2,%3        ;SHIFT R3 BY THE NUMBER SPECIFIED BY TEMP2
7054  026170  106737  025416        4$:     MFPS    @#PSWORD        ;SAVE PS
7055  026174  123737  025426  025416        CMPB    @#TEMP4,@#PSWORD;IS THE PS = TEMP4 ?
7056  026202  001401                        BEQ     11$
7057  026204  104000                        EMT                     ;THE PS IS NOT EQUAL TO 0.
7058  026206  005237  025414        11$:    INC     @#COUNT
7059  026212  023703  025424                CMP     @#TEMP3,%3      ;IS THE RESULT IN R3 EQUAL TO TEMP3?
```

```
7060  026216  001401                        BEQ     12$
7061  026220                        6$:
7062  026220  104000                        EMT                     ;EITHER INCORRECT R3 OR INCORRECT SEQUENCE
7063  026222  021537  025414        12$:    CMP     (R5),@#COUNT    ;IS THE TEST NUMBER EQUAL TO THE COUNTER?
7064  026226  001374                        BNE     6$              ;IF NOT GO TO THE HLT ABOVE
7065  026230  005215                        INC     (R5)
7066  026232  021527  000037                CMP     (R5),#37        ;HAS THE CONTENTS OF REGISTERS BEEN SHIFTED
7067                                                                ;LEFT BY 14, AND RIGHT BY 14.?
7068  026236  002010                        BGE     8$
7069  026240  005237  025422                INC     @#TEMP2
7070  026244  006367  177154                ASL     TEMP3           ;SHIFT TEMP3 LEFT?
7071  026250  021527  000020                CMP     (R5),#20        ;HAS THE CONTENTS OF REGISTERS BEEN SHIFTED LEFT BY 14.?
7072  026254  001003                        BNE     REGR4
7073  026256  000534                        BR      NEGAT           ;IF SO GO TO NEGAT AND INITIATE RIGHT SHIFT
7074  026260  004767  000312        8$:     JSR     PC,TST37        ;IF SO GO AND CONTINUE THE REST OF THE PROGRAM
7075  026264  013704  025420        REGR4:  MOV     @#TEMP1,%4      ;LOAD R4 WITH THE CONTENTS OF TEMP1
7076  026270  010501                        MOV     R5,R1           ;SAVE R5
7077  026272  032737  000001  001006        BIT     #1,@#$PASS      ;IS IT AN EVEN PASS ?
7078  026300  001004                        BNE     2$              ;IF NOT THEN GO TO 2$
7079  026302  013705  025422                MOV     @#TEMP2,R5      ;OTHERWISE EXECUTE ASH INSTRUCTION IN MODE 0
7080  026306  072405                        ASH     R5,R4           ;USING R4
7081  026310  000402                        BR      4$
7082  026312  072467  177104        2$:     ASH     TEMP2,%4        ;SHIFT R4 BY THE NUMBER SPECIFIED BY TEMP2
7083  026316  106737  025416        4$:     MFPS    @#PSWORD        ;SAVE PS
7084  026322  123737  025426  025416        CMPB    @#TEMP4,@#PSWORD;IS PS = TEMP4 ?
7085  026330  001401                        BEQ     11$
7086  026332  104000                        EMT                     ;THE PS IS NOT EQUAL TO 0
7087  026334  005237  025414        11$:    INC     @#COUNT
7088  026340  023704  025424                CMP     @#TEMP3,%4      ;IS THE RESULT IN R4 EQUAL TO TEMP3?
7089  026344  001401                        BEQ     12$
7090  026346                        6$:
7091  026346  104000                        EMT                     ;EITHER INCORRECT R4 OR INCORRECT SEQUENCE
7092  026350  010105                12$:    MOV     R1,R5           ;RESTORE R5
7093  026352  021537  025414                CMP     (R5),@#COUNT    ;IS THE TEST NUMBER EQUAL TO THE COUNTER?
7094  026356  001373                        BNE     6$              ;IF NOT GO TO THE HLT ABOVE
7095  026360  005215                        INC     (R5)
7096  026362  021527  000037                CMP     (R5),#37        ;HAS THE CONTENTS OF REGISTERS BEEN
7097                                                                ;SHIFTED LEFT BY 14. AND RIGHT BY 14.?
7098  026366  002010                        BGE     8$
7099  026370  005237  025422                INC     @#TEMP2
7100  026374  006367  177024                ASL     TEMP3           ;SHIFT TEMP3 LEFT
7101  026400  021527  000020                CMP     (R5),#20        ;HAS THE CONTENTS OF REGISTER BEEN SHIFTED BY 14.?
7102  026404  001003                        BNE     REGR5
7103  026406  000460                        BR      NEGAT           ;IF SO GO TO NEGAT AND INITIATE RIGHT SHIFT
7104  026410  004767  000162        8$:     JSR     PC,TST37        ;IF SO GO AND CONTINUE THE REST OF THE PROGRAM
7105  026414  010501                REGR5:  MOV     R5,R1           ;SAVE R5
7106  026416  013705  025420                MOV     @#TEMP1,%5      ;LOAD R5 WITH THE CONTENTS OF TEMP1
7107  026422  032737  000001  001006        BIT     #1,@#$PASS      ;IS IT AN EVEN PASS ?
7108  026430  001004                        BNE     2$              ;IF NOT THEN GO TO 2$
7109  026432  013700  025422                MOV     @#TEMP2,R0      ;OTHERWISE EXECUTE ASH INSTRUCTION IN MODE 0
7110  026436  072500                        ASH     R0,R5           ;USING R5
7111  026440  000402                        BR      4$
7112  026442  072567  176754        2$:     ASH     TEMP2,%5        ;SHIFT R5 BY THE NUMBER SPECIFIED BY TEMP2
7113  026446  106737  025416        4$:     MFPS    @#PSWORD        ;SAVE PS
7114  026452  123737  025426  025416        CMPB    @#TEMP4,@#PSWORD;IS PS = TEMP4 ?
7115  026460  001401                        BEQ     11$
```

```
7116  026462  104000                  EMT                     ;THE PS IS NOT EQUAL TO 0.
7117  026464  005237  025414    11$:  INC     @#COUNT
7118  026470  023705  025424          CMP     @#TEMP3,%5      ;IS THE RESULT IN R5 EQUAL TO TEMP3?
7119  026474  001401                  BEQ     12$
7120  026476                    6$:
7121  026476  104000                  EMT                     ;EITHER INCORRECT R5 OR INCORRECT SEQUENCE
7122  026500  021137  025414    12$:  CMP     (R1),@#COUNT    ;IS THE TEST NUMBER EQUAL TO THE COUNTER?
7123  026504  001374                  BNE     6$              ;IF NOT GO TO THE HLT ABOVE
7124  026506  010105                  MOV     R1,R5           ;RESTORE R5
7125  026510  005215                  INC     (R5)
7126  026512  021527  000037          CMP     (R5),#37        ;HAS THE CONTENTS OF REGISTERS BEEN SHIFTED
7127                                                          ;LEFT BY 14. AND RIGHT BY 14.?
7128  026516  002010                  BGE     8$              ;IF SO GO AND CONTINUE THE REST OF THE PROGRAM
7129  026520  005237  025422          INC     @#TEMP2
7130  026524  006367  176674          ASL     TEMP3           ;SHIFT TEMP3 LEFT
7131  026530  021527  000020          CMP     (R5),#20        ;HAS THE CONTENTS OF REGISTERS BEEN SHIFTED LEFT BY 14.?
7132  026534  001405                  BEQ     NEGAT           ;IF SO GO TO NEGAT AND INITIATE RIGHT SHIFT
7133  026536  000402                  BR      10$
7134  026540  004767  000032    8$:   JSR     PC,TST37
7135  026544  000167  176766    10$:  JMP     ASTART          ;GO BACK TO START
7136  026550  012737  040000  025420 NEGAT:  MOV     #40000,@#TEMP1  ;TEMP1=40000
7137  026556  012737  177762  025422        MOV     #177762,@#TEMP2 ;TEMP2=177762
7138  026564  012737  000001  025424        MOV     #1,@#TEMP3      ;TEMP3=1
7139  026572  000167  176740                JMP     ASTART
7140  026576  021527  000037    TST37:CMP     (R5),#37        ;IS IT TEST 37?
7141  026602  001013                  BNE     TST40           ;IF NOT THEN TRY TEST 40
7142  026604  005037  025420          CLR     @#TEMP1         ;0
7143  026610  012737  000020  025422  MOV     #16.,@#TEMP2    ;SHIFTED BY 16
7144  026616  005037  025424          CLR     @#TEMP3         ;IS=0
7145  026622  012737  000004  025426  MOV     #4,@#TEMP4      ;AND PS=4
7146  026630  000207                  RTS     PC
7147  026632  021527  000040    TST40:CMP     (R5),#40        ;IS IT TEST 40?
7148  026636  001003                  BNE     TST41           ;IF NOT THEN TRY TEST 41
7149  026640  005037  025422          CLR     @#TEMP2         ;0 SHIFTED BY 0=0 AND PS=4
7150  026644  000207                  RTS     PC
7151  026646  021527  000041    TST41:CMP     (R5),#41        ;IS IT TEST 41?
7152  026652  001004                  BNE     TST42           ;IF NOT THEN TRY TEST 42
7153  026654  012737  177760  025422  MOV     #-16.,@#TEMP2   ;0 SHIFTED BY -16.=0 AND PS=4
7154  026662  000207                  RTS     PC
7155  026664  021527  000042    TST42:CMP     (R5),#42        ;IS IT TEST 42?
7156  026670  001013                  BNE     TST43           ;IF NOT THEN TRY TEST 43
7157  026672  012737  100000  025420  MOV     #100000,@#TEMP1 ;100000
7158  026700  005237  025422          INC     @#TEMP2         ;SHIFTED BY -15
7159  026704  005337  025424          DEC     @#TEMP3         ;IS=-1
7160  026710  012737  000010  025426  MOV     #10,@#TEMP4             ;AND PS=10
7161  026716  000207                  RTS     PC
7162  026720  021527  000043    TST43:CMP     (R5),#43        ;IS IT TEST 43?
7163  026724  001012                  BNE     TST44           ;IF NOT THEN IF NOT THEN TRY TEST 44
7164  026726  012737  125252  025420  MOV     #125252,@#TEMP1 ;125252
7165  026734  012737  177777  025422  MOV     #-1,@#TEMP2     ;SHIFTED BY -1
7166  026742  012737  152525  025424  MOV     #152525,@#TEMP3 ;IS=152525 AND PS=10
7167  026750  000207                  RTS     PC
7168  026752  021527  000044    TST44:CMP     (R5),#44        ;IS IT TEST 44?
7169  026756  001012                  BNE     TST45           ;IF NOT THEN TRY TEST 45
7170  026760  012737  000001  025422  MOV     #1,@#TEMP2      ;125252 SHIFTED BY 1
7171  026766  012737  052524  025424  MOV     #52524,@#TEMP3  ;IS=52524
```

```
7172  026774  012737  000003  025426          MOV     #3,@#TEMP4      ;AND PS=3
7173  027002  000207                          RTS     PC
7174  027004  021527  000045          TST45:  CMP     (R5),#45        ;IS IT TEST 45?
7175  027010  001012                          BNE     TST46           ;IF NOT THEN TRY TEST 46
7176  027012  012737  177776  025422          MOV     #-2,@#TEMP2     ;125252 SHIFTED BY -2
7177  027020  012737  165252  025424          MOV     #165252,@#TEMP3 ;IS=165252
7178  027026  012737  000011  025426          MOV     #11,@#TEMP4     ;AND PS=11
7179  027034  000207                          RTS     PC
7180  027036  021527  000046          TST46:  CMP     (R5),#46        ;IS IT TEST 46?
7181  027042  001014                          BNE     TST47           ;IF NOT THEN TRY TEST 47
7182  027044  012737  177777  025420          MOV     #-1,@#TEMP1     ;-1
7183  027052  012737  000020  025422          MOV     #16.,@#TEMP2    ;SHIFTED BY 15.
7184  027060  005037  025424                  CLR     @#TEMP3         ;IS=0
7185  027064  012737  000007  025426          MOV     #7,@#TEMP4      ;AND PS=7
7186  027072  000207                          RTS     PC
7187  027074  021527  000047          TST47:  CMP     (R5),#47        ;IS IT TEST 47?
7188  027100  001011                          BNE     TST50           ;IF NOT THEN TRY TEST 50
7189  027102  005337  025422                  DEC     @#TEMP2         ;-1 SHIFTED BY 15
7190  027106  012737  100000  025424          MOV     #100000,@#TEMP3 ;IS=100000
7191  027114  012737  000011  025426          MOV     #11,@#TEMP4     ;AND PS=11
7192  027122  000207                          RTS     PC
7193  027124  021527  000050          TST50:  CMP     (R5),#50        ;IS IT TEST 50
7194  027130  001007                          BNE     ENT51           ;IF NOT THEN TRY TEST 51
7195  027132  012737  137777  025420          MOV     #137777,@#TEMP1 ;137777 SHIFTED BY 15. IS=100000
7196  027140  012737  000013  025426          MOV     #13,@#TEMP4     ;AND PS=13
7197  027146  000207                          RTS     PC
7198  027150  021527  000051          ENT51:  CMP     (R5),#51        ;IS IT ENTERING TEST 51?
7199  027154  001401                          BEQ     1$
7200  027156  104000                          EMT                     ;TEST NUMBER GOOFED
7201
7202  027160  005726                  1$:     TST     (SP)+           ;RESTORE STACK POINTER
7203  027162  012704  177771                  MOV     #-7,%4
7204  027166  012702  025434                  MOV     #S1,%2
7205  027172  012703  025436                  MOV     #S2,%3
7206                                  ;*****************************************************************
7207                                  ;TEST:51   11/34   ASH     125252 SHIFTED BY #5 = 52500  PS = 3
7208                                  ;*****************************************************************
7209
7210  027176  012701  125252          TST51:  MOV     #125252,%1      ;LOAD R1 WITH 125252
7211  027202  072127  000005                  ASH     #5,%1           ;SHIFT R1 BY #5
7212  027206  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
7213  027212  122737  000003  025416          CMPB    #3,@#PSWORD     ;IS THE PS 3?
7214  027220  001401                          BEQ     11$
7215  027222  104000                          EMT                     ;THE PS IS NOT EQUAL TO 3
7216  027224  022701  052500          11$:    CMP     #52500,%1       ;IS THE RESULT 52500?
7217  027230  001401                          BEQ     12$
7218  027232  104000                          EMT                     ;R1 IS NOT EQUAL TO 52500 OR INCORRECT SEQUENCE
7219  027234  005215                  12$:    INC     (R5)
7220
7221
7222
7223                                  ;*****************************************************************
7224                                  ;TEST:52   11/34   ASH     125252 SHIFTED BY @S2 = 177525  PS = 10
7225                                  ;*****************************************************************
7226
7227  027236  012700  125252          TST52:  MOV     #125252,%0      ;LOAD R0 WITH 125252
```

```
7228  027242  072077  176170                  ASH     @S2,%0          ;SHIFT R0 BY @S2
7229  027246  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
7230  027252  122737  000010  025416          CMPB    #10,@#PSWORD    ;IS THE PS 10?
7231  027260  001401                          BEQ     11$
7232  027262  104000                          EMT                     ;THE PS IS NOT EQUAL TO 10
7233  027264  022700  177525          11$:    CMP     #177525,%0      ;IS THE RESULT 177525?
7234  027270  001401                          BEQ     12$
7235  027272  104000                          EMT                     ;R0 IS NOT EQUAL TO 177525 OR INCORRECT SEQUENCE
7236  027274  005215                  12$:    INC     (R5)
7237
7238
7239
7240                                  ;*****************************************************************************
7241                                  ;TEST:53   11/34   ASH     125252 SHIFTED BY @#S1 = 177525  PS = 10
7242                                  ;*****************************************************************************
7243
7244  027276  012700  125252          TST53:  MOV     #125252,%0      ;LOAD R0 WITH 125252
7245  027302  072037  025434                  ASH     @#S1,%0         ;SHIFT R0 BY @#S1
7246  027306  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
7247  027312  122737  000010  025416          CMPB    #10,@#PSWORD    ;IS THE PS 10?
7248  027320  001401                          BEQ     11$
7249  027322  104000                          EMT                     ;THE PS IS NOT EQUAL TO 10
7250  027324  022700  177525          11$:    CMP     #177525,%0      ;IS THE RESULT 177525?
7251  027330  001401                          BEQ     12$
7252  027332  104000                          EMT                     ;R0 IS NOT EQUAL TO 177525 OR INCORRECT SEQUENCE
7253  027334  005215                  12$:    INC     (R5)
7254
7255
7256
7257                                  ;*****************************************************************************
7258                                  ;TEST:54   11/34   ASH     125252 SHIFTED BY (2) = 177525  PS = 10
7259                                  ;*****************************************************************************
7260
7261  027336  012700  125252          TST54:  MOV     #125252,%0      ;LOAD R0 WITH 125252
7262  027342  072012                          ASH     (2),%0          ;SHIFT R0 BY (2)
7263  027344  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
7264  027350  122737  000010  025416          CMPB    #10,@#PSWORD    ;IS THE PS 10?
7265  027356  001401                          BEQ     11$
7266  027360  104000                          EMT                     ;THE PS IS NOT EQUAL TO 10
7267  027362  022700  177525          11$:    CMP     #177525,%0      ;IS THE RESULT 177525?
7268  027366  001401                          BEQ     12$
7269  027370  104000                          EMT                     ;R0 IS NOT EQUAL TO 177525 OR INCORRECT SEQUENCE
7270  027372  005215                  12$:    INC     (R5)
7271
7272
7273
7274                                  ;*****************************************************************************
7275                                  ;TEST:55   11/34   ASH     125252 SHIFTED BY (2)+ = 177525  PS = 10
7276                                  ;*****************************************************************************
7277
7278  027374  012700  125252          TST55:  MOV     #125252,%0      ;LOAD R0 WITH 125252
7279  027400  072022                          ASH     (2)+,%0         ;SHIFT R0 BY (2)+
7280  027402  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
7281  027406  122737  000010  025416          CMPB    #10,@#PSWORD    ;IS THE PS 10?
7282  027414  001401                          BEQ     11$
7283  027416  104000                          EMT                     ;THE PS IS NOT EQUAL TO 10
```

```
7284  027420  022700  177525          11$:    CMP     #177525,%0      ;IS THE RESULT 177525?
7285  027424  001401                          BEQ     12$
7286  027426  104000                          EMT                     ;R0 IS NOT EQUAL TO 177525 OR INCORRECT SEQUENCE
7287  027430  005215                  12$:    INC     (R5)
7288
7289
7290
7291                                  ;*************************************************************************
7292                                  ;TEST:56   11/34   ASH     125252 SHIFTED BY -(2) = 177525  PS = 10
7293                                  ;*************************************************************************
7294
7295  027432  012700  125252          TST56:  MOV     #125252,%0      ;LOAD R0 WITH 125252
7296  027436  072042                          ASH     -(2),%0         ;SHIFT R0 BY -(2)
7297  027440  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
7298  027444  122737  000010  025416          CMPB    #10,@#PSWORD    ;IS THE PS 10?
7299  027452  001401                          BEQ     11$
7300  027454  104000                          EMT                     ;THE PS IS NOT EQUAL TO 10
7301  027456  022700  177525          11$:    CMP     #177525,%0      ;IS THE RESULT 177525?
7302  027462  001401                          BEQ     12$
7303  027464  104000                          EMT                     ;R0 IS NOT EQUAL TO 177525 OR INCORRECT SEQUENCE
7304  027466  005215                  12$:    INC     (R5)
7305
7306
7307
7308                                  ;*************************************************************************
7309                                  ;TEST:57   11/34   ASH     125252 SHIFTED BY 2(3) = 177252  PS = 11
7310                                  ;*************************************************************************
7311
7312  027470  012700  125252          TST57:  MOV     #125252,%0      ;LOAD R0 WITH 125252
7313  027474  072063  000002                  ASH     2(3),%0         ;SHIFT R0 BY 2(3)
7314  027500  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
7315  027504  122737  000011  025416          CMPB    #11,@#PSWORD    ;IS THE PS 11?
7316  027512  001401                          BEQ     11$
7317  027514  104000                          EMT                     ;THE PS IS NOT EQUAL TO 11
7318  027516  022700  177252          11$:    CMP     #177252,%0      ;IS THE RESULT 177252?
7319  027522  001401                          BEQ     12$
7320  027524  104000                          EMT                     ;R0 IS NOT EQUAL TO 177252 OR INCORRECT SEQUENCE
7321  027526  005215                  12$:    INC     (R5)
7322
7323
7324
7325                                  ;*************************************************************************
7326                                  ;TEST:60   11/34   ASH     125252 SHIFTED BY @(3) = 177525  PS = 10
7327                                  ;*************************************************************************
7328
7329  027530  012700  125252          TST60:  MOV     #125252,%0      ;LOAD R0 WITH 125252
7330  027534  072073  000000                  ASH     @(3),%0         ;SHIFT R0 BY @(3)
7331  027540  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
7332  027544  122737  000010  025416          CMPB    #10,@#PSWORD    ;IS THE PS 10?
7333  027552  001401                          BEQ     11$
7334  027554  104000                          EMT                     ;THE PS IS NOT EQUAL TO 10
7335  027556  022700  177525          11$:    CMP     #177525,%0      ;IS THE RESULT 177525?
7336  027562  001401                          BEQ     12$
7337  027564  104000                          EMT                     ;R0 IS NOT EQUAL TO 177525 OR INCORRECT SEQUENCE
7338  027566  005215                  12$:    INC     (R5)
7339
```

```
7340
7341
7342                                    ;*****************************************************************************
7343                                    ;TEST:61   11/34   ASH     125252 SHIFTED BY @(3)+ = 177525  PS = 10
7344                                    ;*****************************************************************************
7345
7346  027570  012700  125252          TST61:  MOV     #125252,%0      ;LOAD R0 WITH 125252
7347  027574  072033                          ASH     @(3)+,%0        ;SHIFT R0 BY @(3)+
7348  027576  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
7349  027602  122737  000010  025416          CMPB    #10,@#PSWORD    ;IS THE PS 10?
7350  027610  001401                          BEQ     11$
7351  027612  104000                          EMT                     ;THE PS IS NOT EQUAL TO 10
7352  027614  022700  177525          11$:    CMP     #177525,%0      ;IS THE RESULT 177525?
7353  027620  001401                          BEQ     12$
7354  027622  104000                          EMT                     ;R0 IS NOT EQUAL TO 177525 OR INCORRECT SEQUENCE
7355  027624  005215                  12$:    INC     (R5)
7356
7357
7358
7359                                    ;*****************************************************************************
7360                                    ;TEST:62   11/34   ASH     125252 SHIFTED BY @-(3) = 177525  PS = 10
7361                                    ;*****************************************************************************
7362
7363  027626  012700  125252          TST62:  MOV     #125252,%0      ;LOAD R0 WITH 125252
7364  027632  072053                          ASH     @-(3),%0        ;SHIFT R0 BY @-(3)
7365  027634  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
7366  027640  122737  000010  025416          CMPB    #10,@#PSWORD    ;IS THE PS 10?
7367  027646  001401                          BEQ     11$
7368  027650  104000                          EMT                     ;THE PS IS NOT EQUAL TO 10
7369  027652  022700  177525          11$:    CMP     #177525,%0      ;IS THE RESULT 177525?
7370  027656  001401                          BEQ     12$
7371  027660  104000                          EMT                     ;R0 IS NOT EQUAL TO 177525 OR INCORRECT SEQUENCE
7372  027662  005215                  12$:    INC     (R5)
7373
7374
7375
```

```
                                        ;**********************************
                                        ;     ASHC INSTRUCTION TESTS
                                        ;**********************************



                                                ;*************
                                                ;TESTS 63-157
                                                ;*************


027664  012737  000062  025414          MOV     #62,@#COUNT
027672  005037  025420                  CLR     @#TEMP1         ;TEMP1=0
027676  012737  000001  025422          MOV     #1,@#TEMP2      ;TEMP2=1
027704  005037  025424                  CLR     @#TEMP3         ;TEMP3=0
027710  005037  025426                  CLR     @#TEMP4         ;TEMP4=0
027714  012737  000001  025430          MOV     #1,@#TEMP5      ;TEMP5=1
027722  005037  025432                  CLR     @#TEMP6         ;0 1 SHIFTED BY 0=0 1, PS=0

027726  010502                  REG01:  MOV     R5,R2           ;SAVE R5
027730  013700  025420                  MOV     @#TEMP1,%0      ;PLACE THE CONTENTS OF TEMP1 IN REGISTER 0
027734  013701  025422                  MOV     @#TEMP2,%0!1    ;PLACE THE CONTENTS OF TEMP2 IN REGISTER 1
027740  000241                          CLC
027742  032737  000001  001006          BIT     #1,@#$PASS      ;IS IT AN EVEN PASS ?
027750  001004                          BNE     2$              ;IF NOT THEN GO TO 2$
027752  013705  025424                  MOV     @#TEMP3,R5      ;OTHERWISE EXECUTE ASHC INSTRUCTION IN MODE 0
027756  073005                          ASHC    R5,R0           ;USING R0
027760  000402                          BR      4$
027762  073067  175436          2$:     ASHC    TEMP3,%0        ;ASHC REGISTER 0 BY THE CONTENTS OF TEMP3
027766  106737  025416          4$:     MFPS    @#PSWORD        ;SAVE PS
027772  123737  025432  025416          CMPB    @#TEMP6,@#PSWORD;COMPARE PS WITH THE CONTENTS OF TEMP6
030000  001401                          BEQ     11$
030002  104000                          EMT                     ;WRONG PS
030004  005237  025414          11$:    INC     @#COUNT
030010  023700  025426                  CMP     @#TEMP4,%0      ;IS THE RESULT IN R0 SAME AS TEMP4?
030014  001401                          BEQ     12$
030016  104000                          EMT                     ;WRONG RESULT IN R0
030020  023701  025430          12$:    CMP     @#TEMP5,%1      ;IS THE RESULT IN R1 SAME AS TEMP5?
                                                                ;TEMP1 TEMP2 SHIFTED BY TEMP3=TEMP4 TEMP5
                                                                ;AND PS=TEMP6
030024  001401                          BEQ     13$
030026  104000                          EMT                     ;WRONG RESULT IN R1
030030  010205                  13$:    MOV     R2,R5           ;RESTORE R5
030032  021537  025414                  CMP     (R5),@#COUNT    ;IS TEST NUMBER=COUNTER?
030036  001401                          BEQ     14$
030040  104000                          EMT                     ;NO
030042  005215                  14$:    INC     (R5)
030044  021527  000160                  CMP     (R5),#160       ;HAVE THE FIRST 159 TEST BEEN EXECUTED?
030050  002014                          BGE     6$              ;YES
030052  005237  025424                  INC     @#TEMP3
030056  000241                          CLC
030060  006137  025430                  ROL     @#TEMP5         ;ROTATE TEMP5 LEFT BY 1 PLACE
030064  006137  025426                  ROL     @#TEMP4         ;INTRODUCE CARRY FROM TEMP4 IN TEMP5
030070  021527  000121                  CMP     (R5),#121       ;IS IT TEST 121?
030074  001004                          BNE     REGR23
```

```
7432  030076  004467  000344              JSR     R4,RITSH        ;IF SO THEN GO AND INITIATE RIGHT SHIFT
7433  030102  004767  000374      6$:     JSR     %7,TST160
7434  030106  013702  025420      REGR23: MOV     @#TEMP1,%2      ;PLACE THE CONTENTS OF TEMP1 IN REGISTER 2
7435  030112  013703  025422              MOV     @#TEMP2,%2!1    ;PLACE THE CONTENTS OF TEMP2 IN REGISTER 3
7436  030116  000241                      CLC
7437  030120  032737  000001  001006      BIT     #1,@#$PASS      ;IS IT AN EVEN PASS ?
7438  030126  001004                      BNE     2$              ;IF NOT THEN GO TO 2$
7439  030130  013704  025424              MOV     @#TEMP3,R4      ;OTHERWISE EXECUTE ASHC INSTRUCTION IN MODE 0
7440  030134  073204                      ASHC    R4,R2           ;USING R2
7441  030136  000402                      BR      4$
7442  030140  073267  175260      2$:     ASHC    TEMP3,%2        ;ASHC REGISTER 2 BY THE CONTETNS OF TEMP3
7443  030144  106737  025416      4$:     MFPS    @#PSWORD        ;SAVE PS
7444  030150  123737  025432  025416      CMPB    @#TEMP6,@#PSWORD;COMPARE PS WITH THE CONTENTS OF TEMP6
7445  030156  001401                      BEQ     11$
7446  030160  104000                      EMT                     ;WRONG PS
7447  030162  005237  025414      11$:    INC     @#COUNT
7448  030166  023702  025426              CMP     @#TEMP4,%2      ;IS THE RESULT IN R2 SAME AS TEMP4?
7449  030172  001401                      BEQ     12$
7450  030174  104000                      EMT                     ;WRONG RESULT IN R2
7451  030176  023703  025430      12$:    CMP     @#TEMP5,%3      ;IS THE RESULT IN R3 SAME AS TEMP5?
7452                                                              ;TEMP1 TEMP2 SHIFTED BY TEMP3=TEMP4 TEMP5
7453                                                              ;AND PS=TEMP6
7454  030202  001401                      BEQ     13$
7455  030204  104000                      EMT                     ;WRONG RESULT IN R1
7456  030206  021537  025414      13$:    CMP     (R5),@#COUNT    ;IS TEST NUMBER=COUNTER?
7457  030212  001401                      BEQ     14$
7458  030214  104000                      EMT                     ;NO
7459  030216  005215              14$:    INC     (R5)
7460  030220  021527  000160              CMP     (R5),#160       ;HAVE THE FIRST 159 TEST BEEN EXECUTED?
7461  030224  002014                      BGE     6$              ;YES
7462  030226  005237  025424              INC     @#TEMP3
7463  030232  000241                      CLC
7464  030234  006137  025430              ROL     @#TEMP5         ;ROTATE TEMP5 LEFT BY 1 PLACE
7465  030240  006137  025426              ROL     @#TEMP4         ;INTRODUCE CARRY FROM TEMP5 IN TEMP4
7466  030244  021527  000121              CMP     (R5),#121       ;IS IT TEST 121?
7467  030250  001004                      BNE     REG45
7468  030252  004467  000170              JSR     R4,RITSH        ;IF SO THEN GO AND INITIATE RIGHT SHIFT
7469  030256  004767  000220      6$:     JSR     %7,TST160
7470  030262  010501              REG45:  MOV     R5,R1           ;SAVE R5
7471  030264  013704  025420              MOV     @#TEMP1,%4      ;PLACE THE CONTENTS OF TEMP1 IN REGISTER 4
7472  030270  013705  025422              MOV     @#TEMP2,%4!1    ;PLACE THE CONTENTS OF TEMP2 IN REGISTER 5
7473  030274  000241                      CLC
7474  030276  032737  000001  001006      BIT     #1,@#$PASS      ;IS IT AN EVEN PASS ?
7475  030304  001004                      BNE     2$              ;IF NOT THEN GO TO 2$
7476  030306  013700  025424              MOV     @#TEMP3,R0      ;OTHERWISE EXECUTE ASHC INSTRUCTION IN MODE 0
7477  030312  073400                      ASHC    R0,R4           ;USING R4
7478  030314  000402                      BR      4$
7479  030316  073467  175102      2$:     ASHC    TEMP3,%4        ;ASHC REGISTER 4 BY THE CONTENTS OF TEMP3
7480  030322  106737  025416      4$:     MFPS    @#PSWORD        ;SAVE PS
7481  030326  123737  025432  025416      CMPB    @#TEMP6,@#PSWORD;COMPARE PS WITH THE CONTENTS OF TEMP6
7482  030334  001401                      BEQ     11$
7483  030336  104000                      EMT                     ;WRONG PS
7484  030340  005237  025414      11$:    INC     @#COUNT
7485  030344  023704  025426              CMP     @#TEMP4,%4      ;IS THE RESULT IN R4 SAME AS TEMP4?
7486  030350  001401                      BEQ     12$
7487  030352  104000                      EMT                     ;WRONG RESULT IN R4
```

```
 7488  030354  023705  025430          12$:    CMP     @#TEMP5,%5      ;IS THE RESULT IN R5 SAME AS TEMP5?
 7489                                                                    ;TEMP1 TEMP2 SHIFTED BY TEMP3=TEMP4 TEMP5
 7490                                                                    ;AND PS=TEMP6
 7491  030360  001401                          BEQ     13$
 7492  030362  104000                          EMT                     ;WRONG RESULT IN R5
 7493  030364  021137  025414          13$:    CMP     (R1),@#COUNT    ;IS TEST NUMBER=COUNTER?
 7494  030370  001401                          BEQ     14$
 7495  030372  104000                          EMT                     ;NO
 7496  030374  010105                  14$:    MOV     R1,R5           ;RESTORE R5
 7497  030376  005215                          INC     (R5)
 7498  030400  021527  000160                  CMP     (R5),#160       ;HAVE THE FIRST 159 TEST BEEN EXECUTED?
 7499  030404  002014                          BGE     6$              ;YES
 7500  030406  005237  025424                  INC     @#TEMP3
 7501  030412  000241                          CLC
 7502  030414  006137  025430                  ROL     @#TEMP5         ;ROTATE TEMP5 LEFT BY 1 PLACE
 7503  030420  006137  025426                  ROL     @#TEMP4         ;INTRODUCE CARRY FROM TEMP5 IN TEMP4
 7504  030424  021527  000121                  CMP     (R5),#121       ;IS IT TEST 121?
 7505  030430  001004                          BNE     8$
 7506  030432  004467  000010                  JSR     R4,RITSH        ;IF SO THEN GO AND INITIATE RIGHT SHIFT
 7507  030436  004767  000040          6$:     JSR     %7,TST160
 7508  030442  000167  177260          8$:     JMP     REG01
 7509  030446  022424                  RITSH:  CMP     (R4)+,(R4)+     ;MAKE R4 POINT TO THE NEXT REG TAG
 7510  030450  012737  040000  025420          MOV     #40000,@#TEMP1  ;TEMP1=4000
 7511  030456  005037  025422                  CLR     @#TEMP2         ;TEMP2=0
 7512  030462  012737  177742  025424          MOV     #-30.,@#TEMP3   ;TEMP3=-30
 7513  030470  005037  025426                  CLR     @#TEMP4         ;TEMP4=0
 7514  030474  005237  025430                  INC     @#TEMP5         ;TEMP5=1
 7515  030500  000204                          RTS     R4
 7516  030502  021527  000160          TST160: CMP     (R5),#160       ;IS IT TEST 160
 7517  030506  001010                          BNE     TST161          ;IF NOT THEN TRY TEST 161
 7518  030510  005037  025420                  CLR     @#TEMP1         ;0 0 SHIFTED BY 0
 7519  030514  005037  025426                  CLR     @#TEMP4         ;IS EQUAL TO 0 0
 7520  030520  012737  000004  025432          MOV     #4,@#TEMP6      ;AND PS=4
 7521  030526  000207                          RTS     %7
 7522  030530  021527  000161          TST161: CMP     (R5),#161       ;IS IT TEST 161
 7523  030534  001004                          BNE     TST162
 7524  030536  012737  177746  025424          MOV     #-32,@#TEMP3    ;0 0 SHIFTED BY -32=0 0, PS=4
 7525  030544  000207                          RTS     %7
 7526  030546  021527  000162          TST162: CMP     (R5),#162       ;IS IT TEST 162
 7527  030552  001004                          BNE     TST163          ;IF NOT THEN TRY TEST 163
 7528  030554  012737  000032  025424          MOV     #32,@#TEMP3     ;0 0 SHIFTED BY 32=0 0, PS=4
 7529  030562  000207                          RTS     %7
 7530  030564  021527  000163          TST163: CMP     (R5),#163       ;IS IT TEST 163?
 7531  030570  001016                          BNE     TST164          ;IF NOT THEN TRY TEST 164
 7532  030572  012737  052525  025420          MOV     #52525,@#TEMP1  ;52525 0
 7533  030600  012737  177760  025424          MOV     #-16.,@#TEMP3   ;SHIFTED BY -16.
 7534  030606  005037  025426                  CLR     @#TEMP4
 7535  030612  012737  052525  025430          MOV     #52525,@#TEMP5  ;IS EQUAL TO 0 52525
 7536  030620  005037  025432                  CLR     @#TEMP6         ;AND PS = 0
 7537  030624  000207                          RTS     %7
 7538  030626  021527  000164          TST164: CMP     (R5),#164       ;IS IT TEST 164?
 7539  030632  001014                          BNE     TST165          ;IF NOT THEN TRY TEST 165
 7540  030634  012737  125252  025420          MOV     #125252,@#TEMP1 ;125252 0 SHIFTED BY -16.
 7541  030642  005337  025426                  DEC     @#TEMP4
 7542  030646  012737  125252  025430          MOV     #125252,@#TEMP5 ;IS EQUAL TO -1 125252
 7543  030654  012737  000010  025432          MOV     #10,@#TEMP6     ;AND PS=10
```

```
7544  030662  000207                        RTS     %7
7545  030664  021527  000165        TST165: CMP     (R5),#165       ;IS IT TEST 165?
7546  030670  001007                        BNE     TST166          ;IF NOT THEN TRY TEST 166
7547  030672  012737  177777  025420        MOV     #-1,@#TEMP1     ;-1 0 SHIFTED BY -16
7548  030700  012737  177777  025430        MOV     #-1,@#TEMP5     ;IS EQUAL TO -1 -1, AND PS=10
7549  030706  000207                        RTS     %7
7550  030710  021527  000166        TST166: CMP     (R5),#166       ;IS IT TEST 166?
7551  030714  001011                        BNE     TST167          ;IF NOT THEN TRY TEST 167
7552  030716  012737  100000  025420        MOV     #100000,@#TEMP1 ;100000 0
7553  030724  012737  177740  025424        MOV     #-32.,@#TEMP3   ;SHIFTED BY -32 IS EQUAL TO -1 -1
7554  030732  005237  025432                INC     @#TEMP6         ;AND PS=11
7555  030736  000207                        RTS     %7
7556  030740  021527  000167        TST167: CMP     (R5),#167       ;IS IT TEST 167?
7557  030744  001014                        BNE     TST170          ;IF NOT THEN TRY TEST 170
7558  030746  005037  025420                CLR     @#TEMP1
7559  030752  005337  025422                DEC     @#TEMP2         ;0 -1
7560  030756  012737  000020  025424        MOV     #16.,@#TEMP3    ;SHIFTED BY 16.
7561  030764  005037  025430                CLR     @#TEMP5         ;IS EQUAL TO -1 0
7562  030770  005237  025432                INC     @#TEMP6         ;AND PS=12
7563  030774  000207                        RTS     %7
7564  030776  021527  000170        TST170: CMP     (R5),#170       ;IS IT TEST 170?
7565  031002  001007                        BNE     TST171          ;IF NOT THEN TRY TEST 171
7566  031004  012737  125252  025422        MOV     #125252,@#TEMP2 ;0 125252 SHIFTED BY 16
7567  031012  012737  125252  025426        MOV     #125252,@#TEMP4 ;IS EQUAL TO 125252 0, AND PS=12
7568  031020  000207                        RTS     %7
7569  031022  021527  000171        TST171: CMP     (R5),#171       ;IS IT TEST 171?
7570  031026  001010                        BNE     TST172          ;IF NOT THEN TRY TEST 172
7571  031030  005337  025424                DEC     @#TEMP3         ;0 125252 SHIFTED BY 15
7572  031034  012737  052525  025426        MOV     #52525,@#TEMP4  ;IS EQUAL TO 52525 0
7573  031042  005037  025432                CLR     @#TEMP6         ;AND PS=0
7574  031046  000207                        RTS     %7
7575  031050  021527  000172        TST172: CMP     (R5),#172       ;IS IT TEST 172?
7576  031054  001006                        BNE     TST173          ;IF NOT THEN TRY TEST 173
7577  031056  012737  052525  025422        MOV     #52525,@#TEMP2  ;0 52525
7578  031064  005237  025424                INC     @#TEMP3         ;SHIFTED BY 16. IS EQUAL TO 52525 0, AND PS=0
7579  031070  000207                        RTS     %7
7580  031072  021527  000173        TST173: CMP     (R5),#173       ;IS IT TEST 173?
7581  031076  001014                        BNE     TST174          ;IF NOT THEN TRY TEST 174
7582  031100  012737  177777  025422        MOV     #-1,@#TEMP2     ;0 -1
7583  031106  005337  025424                DEC     @#TEMP3         ;SHIFTED BY 15.
7584  031112  012737  077777  025426        MOV     #77777,@#TEMP4
7585  031120  012737  100000  025430        MOV     #100000,@#TEMP5 ;IS EQUAL TO 77777 100000, AND PS=0
7586  031126  000207                        RTS     %7
7587  031130  021527  000174        TST174: CMP     (R5),#174       ;IS IT TEST 174?
7588  031134  001013                        BNE     TST175          ;IF NOT THEN TRY TEST 175
7589  031136  012737  100000  025420        MOV     #100000,@#TEMP1
7590  031144  005337  025422                DEC     @#TEMP2         ;100000 -2 SHIFTED BY 15.
7591  031150  005037  025430                CLR     @#TEMP5         ;IS EQUAL TO 77777 0
7592  031154  012737  000002  025432        MOV     #2,@#TEMP6      ;AND PS=2
7593  031162  000207                        RTS     %7
7594  031164  021527  000175        TST175: CMP     (R5),#175       ;IS IT TEST 175?
7595  031170  001015                        BNE     ENT176          ;IF NOT THEN TRY TEST 176
7596  031172  012737  177777  025420        MOV     #-1,@#TEMP1
7597  031200  005037  025422                CLR     @#TEMP2         ;-1 0
7598  031204  005237  025424                INC     @#TEMP3         ;SHIFTED BY 16.
7599  031210  005037  025426                CLR     @#TEMP4         ;IS EQUAL TO 0 0
```

```
 7600  031214  012737  000007  025432          MOV     #7,@#TEMP6      ;AND PS=7
 7601  031222  000207                          RTS     %7
 7602  031224  021527  000176          ENT176: CMP     (R5),#176       ;IS THE PROGRM ENTERING TEST 176?
 7603  031230  001401                          BEQ     1$
 7604  031232  104000                          EMT                     ;TEST NUMBER GOOFED
 7605
 7606  031234  005726                  1$:     TST     (SP)+           ;RESTORE STACK POINTER
 7607
 7608                                  ;*****************************************************************
 7609                                  ;TEST:176       1 SHIFTED BY 8. = 400  PS = 0
 7610                                  ;*****************************************************************
 7611
 7612  031236                          TST176:
 7613  031236  012701  000000                  MOV     #DUMMY,%1       ;LOAD R1 WITH DUMMY
 7614  031242  012701  000001                  MOV     #1,%1!1         ;LOAD R1!1 WITH 1
 7615  031246  000241                          CLC
 7616  031250  073127  000010                  ASHC    #8.,%1          ;SHIFT R1,R1!1 BY 8.
 7617  031254  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
 7618  031260  122737  000000  025416          CMPB    #0,@#PSWORD     ;IS THE PS 0?
 7619  031266  001401                          BEQ     11$
 7620  031270  104000                          EMT                     ;THE PS IS NOT EQUAL TO 0
 7621  031272  022701  000400          11$:    CMP     #400,%1         ;IS THE RESULT 400?
 7622  031276  001401                          BEQ     13$
 7623  031300  104000                          EMT                     ;R1 IS NOT EQUAL TO 400
 7624  031302                          13$:
 7625  031302  005215                          INC     (R5)
 7626
 7627
 7628                                  ;*****************************************************************
 7629                                  ;TEST:177       -1 SHIFTED BY 15. = 100000  PS = 11
 7630                                  ;*****************************************************************
 7631
 7632  031304                          TST177:
 7633  031304  012703  000000                  MOV     #DUMMY,%3       ;LOAD R3 WITH DUMMY
 7634  031310  012703  177777                  MOV     #-1,%3!1        ;LOAD R3!1 WITH -1
 7635  031314  000241                          CLC
 7636  031316  073327  000017                  ASHC    #15.,%3         ;SHIFT R3,R3!1 BY 15.
 7637  031322  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
 7638  031326  122737  000011  025416          CMPB    #11,@#PSWORD    ;IS THE PS 11?
 7639  031334  001401                          BEQ     11$
 7640  031336  104000                          EMT                     ;THE PS IS NOT EQUAL TO 11
 7641  031340  022703  100000          11$:    CMP     #100000,%3      ;IS THE RESULT 100000?
 7642  031344  001401                          BEQ     13$
 7643  031346  104000                          EMT                     ;R3 IS NOT EQUAL TO 100000
 7644  031350                          13$:
 7645  031350  005215                          INC     (R5)
 7646
 7647
 7648                                  ;*****************************************************************
 7649                                  ;TEST:200       52525 SHIFTED BY 0 = 52525  PS = 0
 7650                                  ;*****************************************************************
 7651
 7652  031352                          TST200:
 7653  031352  010501                          MOV     R5,R1           ;SAVE R5
 7654  031354  012705  000000                  MOV     #DUMMY,%5       ;LOAD R5 WITH DUMMY
 7655  031360  012705  052525                  MOV     #52525,%5!1     ;LOAD R5!1 WITH 52525
```

```
 7656  031364  000241                          CLC
 7657  031366  073527  000000                  ASHC    #0,%5           ;SHIFT R5,R5!1 BY 0
 7658  031372  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
 7659  031376  122737  000000  025416          CMPB    #0,@#PSWORD     ;IS THE PS 0?
 7660  031404  001401                          BEQ     11$
 7661  031406  104000                          EMT                     ;THE PS IS NOT EQUAL TO 0
 7662  031410  022705  052525          11$:    CMP     #52525,%5       ;IS THE RESULT 52525?
 7663  031414  001401                          BEQ     13$
 7664  031416  104000                          EMT                     ;R5 IS NOT EQUAL TO 52525
 7665  031420                          13$:
 7666  031420  010105                          MOV     R1,R5           ;RESTORE R5
 7667  031422  005215                          INC     (R5)
 7668
 7669
 7670                                  ;*****************************************************************************
 7671                                  ;TEST:201       20010 SHIFTED BY -13. = 101  PS = 0
 7672                                  ;*****************************************************************************
 7673
 7674  031424                          TST201:
 7675  031424  012701  000000                  MOV     #DUMMY,%1       ;LOAD R1 WITH DUMMY
 7676  031430  012701  020010                  MOV     #20010,%1!1     ;LOAD R1!1 WITH 20010
 7677  031434  000241                          CLC
 7678  031436  073127  177763                  ASHC    #-13.,%1        ;SHIFT R1,R1!1 BY -13.
 7679  031442  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
 7680  031446  122737  000000  025416          CMPB    #0,@#PSWORD     ;IS THE PS 0?
 7681  031454  001401                          BEQ     11$
 7682  031456  104000                          EMT                     ;THE PS IS NOT EQUAL TO 0
 7683  031460  022701  000101          11$:    CMP     #101,%1         ;IS THE RESULT 101?
 7684  031464  001401                          BEQ     13$
 7685  031466  104000                          EMT                     ;R1 IS NOT EQUAL TO 101
 7686  031470                          13$:
 7687  031470  005215                          INC     (R5)
 7688
 7689
 7690                                  ;*****************************************************************************
 7691                                  ;TEST:202       -1 SHIFTED BY 16. = 0  PS = 11
 7692                                  ;*****************************************************************************
 7693
 7694  031472                          TST202:
 7695  031472  012703  000000                  MOV     #DUMMY,%3       ;LOAD R3 WITH DUMMY
 7696  031476  012703  177777                  MOV     #-1,%3!1        ;LOAD R3!1 WITH -1
 7697  031502  000241                          CLC
 7698  031504  073327  000020                  ASHC    #16.,%3         ;SHIFT R3,R3!1 BY 16.
 7699  031510  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
 7700  031514  122737  000011  025416          CMPB    #11,@#PSWORD    ;IS THE PS 11?
 7701  031522  001401                          BEQ     11$
 7702  031524  104000                          EMT                     ;THE PS IS NOT EQUAL TO 11
 7703  031526  022703  000000          11$:    CMP     #0,%3           ;IS THE RESULT 0?
 7704  031532  001401                          BEQ     13$
 7705  031534  104000                          EMT                     ;R3 IS NOT EQUAL TO 0
 7706  031536                          13$:
 7707  031536  005215                          INC     (R5)
 7708
 7709
 7710                                  ;*****************************************************************************
 7711                                  ;TEST:203       1 SHIFTED BY -1 = 100000  PS = 1
```

```
                                ;*****************************************************************************
                                TST203:
                                        MOV     R5,R1           ;SAVE R5
                                        MOV     #DUMMY,%5       ;LOAD R5 WITH DUMMY
                                        MOV     #1,%5!1         ;LOAD R5!1 WITH 1
                                        CLC
                                        ASHC    #-1,%5          ;SHIFT R5,R5!1 BY -1
                                        MFPS    @#PSWORD        ;SAVE PS
                                        CMPB    #1,@#PSWORD     ;IS THE PS 1?
                                        BEQ     11$
                                        EMT                     ;THE PS IS NOT EQUAL TO 1
                                11$:    CMP     #100000,%5      ;IS THE RESULT 100000?
                                        BEQ     13$
                                        EMT                     ;R5 IS NOT EQUAL TO 100000
                                13$:
                                        MOV     R1,R5           ;RESTORE R5
                                        INC     (R5)

                                ;*****************************************************************************
                                ;TEST:204       125252 SHIFTED BY -16. = 125252  PS = 11
                                ;*****************************************************************************
                                TST204:
                                        MOV     #DUMMY,%1       ;LOAD R1 WITH DUMMY
                                        MOV     #125252,%1!1    ;LOAD R1!1 WITH 125252
                                        CLC
                                        ASHC    #-16.,%1        ;SHIFT R1,R1!1 BY -16.
                                        MFPS    @#PSWORD        ;SAVE PS
                                        CMPB    #11,@#PSWORD    ;IS THE PS 11?
                                        BEQ     11$
                                        EMT                     ;THE PS IS NOT EQUAL TO 11
                                11$:    CMP     #125252,%1      ;IS THE RESULT 125252?
                                        BEQ     13$
                                        EMT                     ;R1 IS NOT EQUAL TO 125252
                                13$:
                                        INC     (R5)

                                ;*****************************************************************************
                                ;TEST:205       125252 125252 SHIFTED BY 21. = 52500 000000  PS = 3
                                ;*****************************************************************************
                                TST205:
                                        MOV     #125252,%2      ;LOAD R2 WITH 125252
                                        MOV     #125252,%2!1    ;LOAD R2!1 WITH 125252
                                        CLC
                                        ASHC    #21.,%2         ;SHIFT R2,R2!1 BY 21.
                                        MFPS    @#PSWORD        ;SAVE PS
                                        CMPB    #3,@#PSWORD     ;IS THE PS 3?
                                        BEQ     11$
                                        EMT                     ;THE PS IS NOT EQUAL TO 3
                                11$:    CMP     #52500,%2       ;IS THE RESULT 52500?
                                        BEQ     12$
                                        EMT                     ;R2 IS NOT EQUAL TO 52500
```

```
 7768  031724  022703  000000          12$:    CMP     #000000.%2!1    ;IS THE RESULT 000000?
 7769  031730  001401                          BEQ     13$
 7770  031732  104000                          EMT                     ;R2!1 IS NOT EQUAL TO 000000
 7771  031734                          13$:
 7772  031734  005215                          INC     (R5)
 7773
 7774
 7775
 7776  031736  012702  177771                  MOV     #-7,%2
 7777  031742  012703  025434                  MOV     #S1,%3
 7778  031746  012704  025436                  MOV     #S2,%4
 7779
 7780                                  ;*************************************************************************
 7781                                  ;TEST:206       125252 125252 SHIFTED BY S1 = 177525 52525  PS = 10
 7782                                  ;*************************************************************************
 7783
 7784  031752                          TST206:
 7785  031752  012700  125252                  MOV     #125252,%0              ;LOAD R0 WITH 125252
 7786  031756  012701  125252                  MOV     #125252,%0!1    ;LOAD R0!1 WITH 125252
 7787  031762  000241                          CLC
 7788  031764  073067  173444                  ASHC    S1,%0           ;SHIFT R0,R0!1 BY S1
 7789  031770  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
 7790  031774  122737  000010  025416          CMPB    #10,@#PSWORD    ;IS THE PS 10?
 7791  032002  001401                          BEQ     11$
 7792  032004  104000                          EMT                     ;THE PS IS NOT EQUAL TO 10
 7793  032006  022700  177525          11$:    CMP     #177525,%0      ;IS THE RESULT 177525?
 7794  032012  001401                          BEQ     12$
 7795  032014  104000                          EMT                     ;R0 IS NOT EQUAL TO 177525
 7796  032016  022701  052525          12$:    CMP     #52525,%0!1     ;IS THE RESULT 52525?
 7797  032022  001401                          BEQ     13$
 7798  032024  104000                          EMT                     ;R0!1 IS NOT EQUAL TO 52525 OR INCORRECT SEQUENCE
 7799  032026                          13$:
 7800  032026  005215                          INC     (R5)
 7801
 7802
 7803                                  ;*************************************************************************
 7804                                  ;TEST:207       125252 125252 SHIFTED BY @S2 = 177525 52525  PS = 10
 7805                                  ;*************************************************************************
 7806
 7807  032030                          TST207:
 7808  032030  012700  125252                  MOV     #125252,%0              ;LOAD R0 WITH 125252
 7809  032034  012701  125252                  MOV     #125252,%0!1    ;LOAD R0!1 WITH 125252
 7810  032040  000241                          CLC
 7811  032042  073077  173370                  ASHC    @S2,%0          ;SHIFT R0,R0!1 BY @S2
 7812  032046  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
 7813  032052  122737  000010  025416          CMPB    #10,@#PSWORD    ;IS THE PS 10?
 7814  032060  001401                          BEQ     11$
 7815  032062  104000                          EMT                     ;THE PS IS NOT EQUAL TO 10
 7816  032064  022700  177525          11$:    CMP     #177525,%0      ;IS THE RESULT 177525?
 7817  032070  001401                          BEQ     12$
 7818  032072  104000                          EMT                     ;R0 IS NOT EQUAL TO 177525
 7819  032074  022701  052525          12$:    CMP     #52525,%0!1     ;IS THE RESULT 52525?
 7820  032100  001401                          BEQ     13$
 7821  032102  104000                          EMT                     ;R0!1 IS NOT EQUAL TO 52525 OR INCORRECT SEQUENCE
 7822  032104                          13$:
 7823  032104  005215                          INC     (R5)
```

```
                                ;*****************************************************************************
                                ;TEST:210       125252 125252 SHIFTED BY @#S1 = 177525 52525  PS = 10
                                ;*****************************************************************************

032106                          TST210:
032106  012700  125252                  MOV     #125252,%0              ;LOAD R0 WITH 125252
032112  012701  125252                  MOV     #125252,%0!1    ;LOAD R0!1 WITH 125252
032116  000241                          CLC
032120  073037  025434                  ASHC    @#S1,%0         ;SHIFT R0,R0!1 BY @#S1
032124  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
032130  122737  000010  025416          CMPB    #10,@#PSWORD    ;IS THE PS 10?
032136  001401                          BEQ     11$
032140  104000                          EMT                     ;THE PS IS NOT EQUAL TO 10
032142  022700  177525          11$:    CMP     #177525,%0      ;IS THE RESULT 177525?
032146  001401                          BEQ     12$
032150  104000                          EMT                     ;R0 IS NOT EQUAL TO 177525
032152  022701  052525          12$:    CMP     #52525,%0!1     ;IS THE RESULT 52525?
032156  001401                          BEQ     13$
032160  104000                          EMT                     ;R0!1 IS NOT EQUAL TO 52525 OR INCORRECT SEQUENCE
032162                          13$:
032162  005215                          INC     (R5)


                                ;*****************************************************************************
                                ;TEST:211       125252 125252 SHIFTED BY (3) = 177525 52525  PS = 10
                                ;*****************************************************************************

032164                          TST211:
032164  012700  125252                  MOV     #125252,%0              ;LOAD R0 WITH 125252
032170  012701  125252                  MOV     #125252,%0!1    ;LOAD R0!1 WITH 125252
032174  000241                          CLC
032176  073013                          ASHC    (3),%0          ;SHIFT R0,R0!1 BY (3)
032200  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
032204  122737  000010  025416          CMPB    #10,@#PSWORD    ;IS THE PS 10?
032212  001401                          BEQ     11$
032214  104000                          EMT                     ;THE PS IS NOT EQUAL TO 10
032216  022700  177525          11$:    CMP     #177525,%0      ;IS THE RESULT 177525?
032222  001401                          BEQ     12$
032224  104000                          EMT                     ;R0 IS NOT EQUAL TO 177525
032226  022701  052525          12$:    CMP     #52525,%0!1     ;IS THE RESULT 52525?
032232  001401                          BEQ     13$
032234  104000                          EMT                     ;R0!1 IS NOT EQUAL TO 52525 OR INCORRECT SEQUENCE
032236                          13$:
032236  005215                          INC     (R5)


                                ;*****************************************************************************
                                ;TEST:212       125252 125252 SHIFTED BY (3)+ = 177525 52525  PS = 10
                                ;*****************************************************************************

032240                          TST212:
032240  012700  125252                  MOV     #125252,%0              ;LOAD R0 WITH 125252
032244  012701  125252                  MOV     #125252,%0!1    ;LOAD R0!1 WITH 125252
032250  000241                          CLC
```

```
                                        ASHC    (3)+,%0         ;SHIFT R0,R0!1 BY (3)+
                                        MFPS    @#PSWORD        ;SAVE PS
                                        CMPB    #10,@#PSWORD    ;IS THE PS 10?
                                        BEQ     11$
                                        EMT                     ;THE PS IS NOT EQUAL TO 10
                                11$:    CMP     #177525,%0      ;IS THE RESULT 177525?
                                        BEQ     12$
                                        EMT                     ;R0 IS NOT EQUAL TO 177525
                                12$:    CMP     #52525,%0!1     ;IS THE RESULT 52525?
                                        BEQ     13$
                                        EMT                     ;R0!1 IS NOT EQUAL TO 52525 OR INCORRECT SEQUENCE
                                13$:
                                        INC     (R5)

                                ;*******************************************************************************
                                ;TEST:213       125252 125252 SHIFTED BY -(3) = 177525 52525  PS = 10
                                ;*******************************************************************************

                                TST213:
                                        MOV     #125252,%0              ;LOAD R0 WITH 125252
                                        MOV     #125252,%0!1    ;LOAD R0!1 WITH 125252
                                        CLC
                                        ASHC    -(3),%0         ;SHIFT R0,R0!1 BY -(3)
                                        MFPS    @#PSWORD        ;SAVE PS
                                        CMPB    #10,@#PSWORD    ;IS THE PS 10?
                                        BEQ     11$
                                        EMT                     ;THE PS IS NOT EQUAL TO 10
                                11$:    CMP     #177525,%0      ;IS THE RESULT 177525?
                                        BEQ     12$
                                        EMT                     ;R0 IS NOT EQUAL TO 177525
                                12$:    CMP     #52525,%0!1     ;IS THE RESULT 52525?
                                        BEQ     13$
                                        EMT                     ;R0!1 IS NOT EQUAL TO 52525 OR INCORRECT SEQUENCE
                                13$:
                                        INC     (R5)

                                ;*******************************************************************************
                                ;TEST:214       125252 125252 SHIFTED BY 2(4) = 177252 125252  PS = 11
                                ;*******************************************************************************

                                TST214:
                                        MOV     #125252,%0              ;LOAD R0 WITH 125252
                                        MOV     #125252,%0!1    ;LOAD R0!1 WITH 125252
                                        CLC
                                        ASHC    2(4),%0         ;SHIFT R0,R0!1 BY 2(4)
                                        MFPS    @#PSWORD        ;SAVE PS
                                        CMPB    #11,@#PSWORD    ;IS THE PS 11?
                                        BEQ     11$
                                        EMT                     ;THE PS IS NOT EQUAL TO 11
                                11$:    CMP     #177252,%0      ;IS THE RESULT 177252?
                                        BEQ     12$
                                        EMT                     ;R0 IS NOT EQUAL TO 177252
                                12$:    CMP     #125252,%0!1    ;IS THE RESULT 125252?
                                        BEQ     13$
```

```
7936  032442  104000                  EMT                     ;R0!1 IS NOT EQUAL TO 125252 OR INCORRECT SEQUENCE
7937  032444                  13$:
7938  032444  005215                  INC     (R5)
7939
7940
7941                          ;*************************************************************************
7942                          ;TEST:215       125252 125252 SHIFTED BY @(4) = 177525 52525  PS = 10
7943                          ;*************************************************************************
7944
7945  032446                  TST215:
7946  032446  012700  125252,2        MOV     #125252,%0              ;LOAD R0 WITH 125252
7947  032452  012701  125252          MOV     #125252,%0!1    ;LOAD R0!1 WITH 125252
7948  032456  000241                  CLC
7949  032460  073074  000000          ASHC    @(4),%0         ;SHIFT R0,R0!1 BY @(4)
7950  032464  106737  025416          MFPS    @#PSWORD        ;SAVE PS
7951  032470  122737  000010  025416  CMPB    #10,@#PSWORD    ;IS THE PS 10?
7952  032476  001401                  BEQ     11$
7953  032500  104000                  EMT                     ;THE PS IS NOT EQUAL TO 10
7954  032502  022700  177525  11$:    CMP     #177525,%0      ;IS THE RESULT 177525?
7955  032506  001401                  BEQ     12$
7956  032510  104000                  EMT                     ;R0 IS NOT EQUAL TO 177525
7957  032512  022701  052525  12$:    CMP     #52525,%0!1     ;IS THE RESULT 52525?
7958  032516  001401                  BEQ     13$
7959  032520  104000                  EMT                     ;R0!1 IS NOT EQUAL TO 52525 OR INCORRECT SEQUENCE
7960  032522                  13$:
7961  032522  005215                  INC     (R5)
7962
7963
7964                          ;*************************************************************************
7965                          ;TEST:216       125252 125252 SHIFTED BY @(4)+ = 177525 52525  PS = 10
7966                          ;*************************************************************************
7967
7968  032524                  TST216:
7969  032524  012700  125252          MOV     #125252,%0              ;LOAD R0 WITH 125252
7970  032530  012701  125252          MOV     #125252,%0!1    ;LOAD R0!1 WITH 125252
7971  032534  000241                  CLC
7972  032536  073034                  ASHC    @(4)+,%0                ;SHIFT R0,R0!1 BY @(4)+
7973  032540  106737  025416          MFPS    @#PSWORD        ;SAVE PS
7974  032544  122737  000010  025416  CMPB    #10,@#PSWORD    ;IS THE PS 10?
7975  032552  001401                  BEQ     11$
7976  032554  104000                  EMT                     ;THE PS IS NOT EQUAL TO 10
7977  032556  022700  177525  11$:    CMP     #177525,%0      ;IS THE RESULT 177525?
7978  032562  001401                  BEQ     12$
7979  032564  104000                  EMT                     ;R0 IS NOT EQUAL TO 177525
7980  032566  022701  052525  12$:    CMP     #52525,%0!1     ;IS THE RESULT 52525?
7981  032572  001401                  BEQ     13$
7982  032574  104000                  EMT                     ;R0!1 IS NOT EQUAL TO 52525 OR INCORRECT SEQUENCE
7983  032576                  13$:
7984  032576  005215                  INC     (R5)
7985
7986
7987                          ;*************************************************************************
7988                          ;TEST:217       125252 125252 SHIFTED BY @-(4) = 177525 52525  PS = 10
7989                          ;*************************************************************************
7990
7991  032600                  TST217:
```

```
 7992  032600  012700  125252              MOV     #125252,%0              ;LOAD R0 WITH 125252
 7993  032604  012701  125252              MOV     #125252,%0!1    ;LOAD R0!1 WITH 125252
 7994  032610  000241                      CLC
 7995  032612  073054                      ASHC    @-(4),%0                ;SHIFT R0,R0!1 BY @-(4)
 7996  032614  106737  025416              MFPS    @#PSWORD        ;SAVE PS
 7997  032620  122737  000010  025416      CMPB    #10,@#PSWORD    ;IS THE PS 10?
 7998  032626  001401                      BEQ     11$
 7999  032630  104000                      EMT                             ;THE PS IS NOT EQUAL TO 10
 8000  032632  022700  177525      11$:    CMP     #177525,%0      ;IS THE RESULT 177525?
 8001  032636  001401                      BEQ     12$
 8002  032640  104000                      EMT                             ;R0 IS NOT EQUAL TO 177525
 8003  032642  022701  052525      12$:    CMP     #52525,%0!1     ;IS THE RESULT 52525?
 8004  032646  001401                      BEQ     13$
 8005  032650  104000                      EMT                             ;R0!1 IS NOT EQUAL TO 52525 OR INCORRECT SEQUENCE
 8006  032652                      13$:
 8007  032652  005215                      INC     (R5)
 8008
 8009
 8010
 8011
 8012
 8013
 8014
 8015
 8016
```

```
                                        ;*********************************
                                        ;     MUL INSTRUCTION TESTS
                                        ;*********************************



                                        ;*************************************************************************
                                        ;TEST:220       MUL      1 * #0 = 0 0        PS = 4
                                        ;*************************************************************************

032654                                  TST220:
032654  012700  000001                          MOV     #1,%0           ;LOAD MULTIPLICAND WITH 1
032660  070027  000000                          MUL     #0,%0           ;MULTIPLY 1 * #0
032664  106737  025416                          MFPS    @#PSWORD        ;SAVE PS
032670  122737  000004  025416                  CMPB    #4,@#PSWORD     ;IS PS = 4
032676  001401                                  BEQ     11$
032700  104000                                  EMT                     ;PS IS WRONG
032702  022700  000000              11$:        CMP     #0,%0           ;IS HIGH ORDER = 0
032706  001401                                  BEQ     12$
032710  104000                                  EMT                     ;HIGH ORDER IS WRONG
032712  022701  000000              12$:        CMP     #0,%0!1         ;IS LOW ORDER = 0
032716  001401                                  BEQ     13$
032720  104000                                  EMT                     ;LOW ORDER IS WRONG OR WRONG SEQUENCE
032722                                  13$:
032722  005215                                  INC     (R5)



                                        ;*************************************************************************
                                        ;TEST:221       MUL      -1 * #1 = -1 -1        PS = 10
                                        ;*************************************************************************

032724                                  TST221:
032724  012700  177777                          MOV     #-1,%0          ;LOAD MULTIPLICAND WITH -1
032730  070027  000001                          MUL     #1,%0           ;MULTIPLY -1 * #1
032734  106737  025416                          MFPS    @#PSWORD        ;SAVE PS
032740  122737  000010  025416                  CMPB    #10,@#PSWORD    ;IS PS = 10
032746  001401                                  BEQ     11$
032750  104000                                  EMT                     ;PS IS WRONG
032752  022700  177777              11$:        CMP     #-1,%0          ;IS HIGH ORDER = -1
032756  001401                                  BEQ     12$
032760  104000                                  EMT                     ;HIGH ORDER IS WRONG
032762  022701  177777              12$:        CMP     #-1,%0!1        ;IS LOW ORDER = -1
032766  001401                                  BEQ     13$
032770  104000                                  EMT                     ;LOW ORDER IS WRONG OR WRONG SEQUENCE
032772                                  13$:
032772  005215                                  INC     (R5)



                                        ;*************************************************************************
                                        ;TEST:222       MUL      2 * #2 = 0 4        PS = 0
                                        ;*************************************************************************

032774                                  TST222:
032774  012702  000002                          MOV     #2,%2           ;LOAD MULTIPLICAND WITH 2
033000  070227  000002                          MUL     #2,%2           ;MULTIPLY 2 * #2
```

```
 8073  033004  106737  025416                MFPS    @#PSWORD        ;SAVE PS
 8074  033010  122737  000000  025416        CMPB    #0,@#PSWORD     ;IS PS = 0
 8075  033016  001401                        BEQ     11$
 8076  033020  104000                        EMT                     ;PS IS WRONG
 8077  033022  022702  000000        11$:    CMP     #0,%2           ;IS HIGH ORDER = 0
 8078  033026  001401                        BEQ     12$
 8079  033030  104000                        EMT                     ;HIGH ORDER IS WRONG
 8080  033032  022703  000004        12$:    CMP     #4,%2!1         ;IS LOW ORDER = 4
 8081  033036  001401                        BEQ     13$
 8082  033040  104000                        EMT                     ;LOW ORDER IS WRONG OR WRONG SEQUENCE
 8083  033042                        13$:
 8084  033042  005215                        INC     (R5)
 8085
 8086
 8087                                  ;*************************************************************************
 8088                                  ;TEST:223       MUL     1000 * #200 = 1 0       PS = 1
 8089                                  ;*************************************************************************
 8090
 8091  033044                        TST223:
 8092  033044  010501                        MOV     R5,R1           ;SAVE R5
 8093  033046  012704  001000                MOV     #1000,%4        ;LOAD MULTIPLICAND WITH 1000
 8094  033052  070427  000200                MUL     #200,%4         ;MULTIPLY 1000 * #200
 8095  033056  106737  025416                MFPS    @#PSWORD        ;SAVE PS
 8096  033062  122737  000001  025416        CMPB    #1,@#PSWORD     ;IS PS = 1
 8097  033070  001401                        BEQ     11$
 8098  033072  104000                        EMT                     ;PS IS WRONG
 8099  033074  022704  000001        11$:    CMP     #1,%4           ;IS HIGH ORDER = 1
 8100  033100  001401                        BEQ     12$
 8101  033102  104000                        EMT                     ;HIGH ORDER IS WRONG
 8102  033104  022705  000000        12$:    CMP     #0,%4!1         ;IS LOW ORDER = 0
 8103  033110  001401                        BEQ     13$
 8104  033112  104000                        EMT                     ;LOW ORDER IS WRONG OR WRONG SEQUENCE
 8105  033114                        13$:
 8106  033114  010105                        MOV     R1,R5           ;RESTORE R5
 8107  033116  005215                        INC     (R5)
 8108
 8109
 8110                                  ;*************************************************************************
 8111                                  ;TEST:224       MUL     2 * #77777 = 0 177776       PS = 1
 8112                                  ;*************************************************************************
 8113
 8114  033120                        TST224:
 8115  033120  012700  000002                MOV     #2,%0           ;LOAD MULTIPLICAND WITH 2
 8116  033124  070027  077777                MUL     #77777,%0       ;MULTIPLY 2 * #77777
 8117  033130  106737  025416                MFPS    @#PSWORD        ;SAVE PS
 8118  033134  122737  000001  025416        CMPB    #1,@#PSWORD     ;IS PS = 1
 8119  033142  001401                        BEQ     11$
 8120  033144  104000                        EMT                     ;PS IS WRONG
 8121  033146  022700  000000        11$:    CMP     #0,%0           ;IS HIGH ORDER = 0
 8122  033152  001401                        BEQ     12$
 8123  033154  104000                        EMT                     ;HIGH ORDER IS WRONG
 8124  033156  022701  177776        12$:    CMP     #177776,%0!1    ;IS LOW ORDER = 177776
 8125  033162  001401                        BEQ     13$
 8126  033164  104000                        EMT                     ;LOW ORDER IS WRONG OR WRONG SEQUENCE
 8127  033166                        13$:
 8128  033166  005215                        INC     (R5)
```

```
                                ;*****************************************************************************
                                ;TEST:225       MUL      7777 * #10 = 0 77770        PS = 0
                                ;*****************************************************************************

033170                          TST225:
033170  012702  007777                  MOV     #7777,%2        ;LOAD MULTIPLICAND WITH 7777
033174  070227  000010                  MUL     #10,%2          ;MULTIPLY 7777 * #10
033200  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
033204  122737  000000  025416          CMPB    #0,@#PSWORD     ;IS PS = 0
033212  001401                          BEQ     11$
033214  104000                          EMT                     ;PS IS WRONG
033216  022702  000000          11$:    CMP     #0,%2           ;IS HIGH ORDER = 0
033222  001401                          BEQ     12$
033224  104000                          EMT                     ;HIGH ORDER IS WRONG
033226  022703  077770          12$:    CMP     #77770,%2!1     ;IS LOW ORDER = 77770
033232  001401                          BEQ     13$
033234  104000                          EMT                     ;LOW ORDER IS WRONG OR WRONG SEQUENCE
033236                          13$:
033236  005215                          INC     (R5)

                                ;*****************************************************************************
                                ;TEST:226       MUL      77777 * #77777 = 37777 1        PS = 1
                                ;*****************************************************************************

033240                          TST226:
033240  010501                          MOV     R5,R1           ;SAVE R5
033242  012704  077777                  MOV     #77777,%4       ;LOAD MULTIPLICAND WITH 77777
033246  070427  077777                  MUL     #77777,%4       ;MULTIPLY 77777 * #77777
033252  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
033256  122737  000001  025416          CMPB    #1,@#PSWORD     ;IS PS = 1
033264  001401                          BEQ     11$
033266  104000                          EMT                     ;PS IS WRONG
033270  022704  037777          11$:    CMP     #37777,%4       ;IS HIGH ORDER = 37777
033274  001401                          BEQ     12$
033276  104000                          EMT                     ;HIGH ORDER IS WRONG
033300  022705  000001          12$:    CMP     #1,%4!1         ;IS LOW ORDER = 1
033304  001401                          BEQ     13$
033306  104000                          EMT                     ;LOW ORDER IS WRONG OR WRONG SEQUENCE
033310                          13$:
033310  010105                          MOV     R1,R5           ;RESTORE R5
033312  005215                          INC     (R5)

                                ;*****************************************************************************
                                ;TEST:227       MUL      -1 * #77777 = -1 100001        PS = 10
                                ;*****************************************************************************

033314                          TST227:
033314  012702  177777                  MOV     #-1,%2          ;LOAD MULTIPLICAND WITH -1
033320  070227  077777                  MUL     #77777,%2       ;MULTIPLY -1 * #77777
033324  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
033330  122737  000010  025416          CMPB    #10,@#PSWORD    ;IS PS = 10
033336  001401                          BEQ     11$
```

```
8185  033340  104000                  EMT                             ;PS IS WRONG
8186  033342  022702  177777  11$:    CMP     #-1,%2                  ;IS HIGH ORDER = -1
8187  033346  001401                  BEQ     12$
8188  033350  104000                  EMT                             ;HIGH ORDER IS WRONG
8189  033352  022703  100001  12$:    CMP     #100001,%2!1            ;IS LOW ORDER = 100001
8190  033356  001401                  BEQ     13$
8191  033360  104000                  EMT                             ;LOW ORDER IS WRONG OR WRONG SEQUENCE
8192  033362                  13$:
8193  033362  005215                  INC     (R5)
8194
8195
8196                          ;*****************************************************************************
8197                          ;TEST:230       MUL     -2 * #77777 = -1 2      PS = 11
8198                          ;*****************************************************************************
8199
8200  033364                  TST230:
8201  033364  012700  177776          MOV     #-2,%0                  ;LOAD MULTIPLICAND WITH -2
8202  033370  070027  077777          MUL     #77777,%0               ;MULTIPLY -2 * #77777
8203  033374  106737  025416          MFPS    @#PSWORD                ;SAVE PS
8204  033400  122737  000011  025416  CMPB    #11,@#PSWORD            ;IS PS = 11
8205  033406  001401                  BEQ     11$
8206  033410  104000                  EMT                             ;PS IS WRONG
8207  033412  022700  177777  11$:    CMP     #-1,%0                  ;IS HIGH ORDER = -1
8208  033416  001401                  BEQ     12$
8209  033420  104000                  EMT                             ;HIGH ORDER IS WRONG
8210  033422  022701  000002  12$:    CMP     #2,%0!1                 ;IS LOW ORDER = 2
8211  033426  001401                  BEQ     13$
8212  033430  104000                  EMT                             ;LOW ORDER IS WRONG OR WRONG SEQUENCE
8213  033432                  13$:
8214  033432  005215                  INC     (R5)
8215
8216
8217                          ;*****************************************************************************
8218                          ;TEST:231       MUL     125252 * #2 = -1 52524      PS = 11
8219                          ;*****************************************************************************
8220
8221  033434                  TST231:
8222  033434  012702  125252          MOV     #125252,%2              ;LOAD MULTIPLICAND WITH 125252
8223  033440  070227  000002          MUL     #2,%2                   ;MULTIPLY 125252 * #2
8224  033444  106737  025416          MFPS    @#PSWORD                ;SAVE PS
8225  033450  122737  000011  025416  CMPB    #11,@#PSWORD            ;IS PS = 11
8226  033456  001401                  BEQ     11$
8227  033460  104000                  EMT                             ;PS IS WRONG
8228  033462  022702  177777  11$:    CMP     #-1,%2                  ;IS HIGH ORDER = -1
8229  033466  001401                  BEQ     12$
8230  033470  104000                  EMT                             ;HIGH ORDER IS WRONG
8231  033472  022703  052524  12$:    CMP     #52524,%2!1             ;IS LOW ORDER = 52524
8232  033476  001401                  BEQ     13$
8233  033500  104000                  EMT                             ;LOW ORDER IS WRONG OR WRONG SEQUENCE
8234  033502                  13$:
8235  033502  005215                  INC     (R5)
8236
8237
8238                          ;*****************************************************************************
8239                          ;TEST:232       MUL     125252 * #40000 = 165252 100000     PS = 11
8240                          ;*****************************************************************************
```

```
8241
8242  033504                          TST232:
8243  033504  010501                          MOV     R5,R1           ;SAVE R5
8244  033506  012704  125252                  MOV     #125252,%4      ;LOAD MULTIPLICAND WITH 125252
8245  033512  070427  040000                  MUL     #40000,%4       ;MULTIPLY 125252 * #40000
8246  033516  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
8247  033522  122737  000011  025416          CMPB    #11,@#PSWORD    ;IS PS = 11
8248  033530  001401                          BEQ     11$
8249  033532  104000                          EMT                     ;PS IS WRONG
8250  033534  022704  165252          11$:    CMP     #165252,%4      ;IS HIGH ORDER = 165252
8251  033540  001401                          BEQ     12$
8252  033542  104000                          EMT                     ;HIGH ORDER IS WRONG
8253  033544  022705  100000          12$:    CMP     #100000,%4!1    ;IS LOW ORDER = 100000
8254  033550  001401                          BEQ     13$
8255  033552  104000                          EMT                     ;LOW ORDER IS WRONG OR WRONG SEQUENCE
8256  033554                          13$:
8257  033554  010105                          MOV     R1,R5           ;RESTORE R5
8258  033556  005215                          INC     (R5)
8259
8260
8261                                  ;*************************************************************************
8262                                  ;TEST:233       MUL     107070 * #107070 = 31222 26100          PS = 1
8263                                  ;*************************************************************************
8264
8265  033560                          TST233:
8266  033560  012700  107070                  MOV     #107070,%0      ;LOAD MULTIPLICAND WITH 107070
8267  033564  070027  107070                  MUL     #107070,%0      ;MULTIPLY 107070 * #107070
8268  033570  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
8269  033574  122737  000001  025416          CMPB    #1,@#PSWORD     ;IS PS = 1
8270  033602  001401                          BEQ     11$
8271  033604  104000                          EMT                     ;PS IS WRONG
8272  033606  022700  031222          11$:    CMP     #31222,%0       ;IS HIGH ORDER = 31222
8273  033612  001401                          BEQ     12$
8274  033614  104000                          EMT                     ;HIGH ORDER IS WRONG
8275  033616  022701  026100          12$:    CMP     #26100,%0!1     ;IS LOW ORDER = 26100
8276  033622  001401                          BEQ     13$
8277  033624  104000                          EMT                     ;LOW ORDER IS WRONG OR WRONG SEQUENCE
8278  033626                          13$:
8279  033626  005215                          INC     (R5)
8280
8281
8282                                  ;*************************************************************************
8283                                  ;TEST:234       MUL     -1 * #1 = -1 -1         PS = 10
8284                                  ;*************************************************************************
8285
8286  033630                          TST234:
8287  033630  012701  177777                  MOV     #-1,%1          ;LOAD MULTIPLICAND WITH -1
8288  033634  070127  000001                  MUL     #1,%1           ;MULTIPLY -1 * #1
8289  033640  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
8290  033644  122737  000010  025416          CMPB    #10,@#PSWORD    ;IS PS = 10
8291  033652  001401                          BEQ     11$
8292  033654  104000                          EMT                     ;PS IS WRONG
8293  033656  022701  177777          11$:    CMP     #-1,%1          ;IS HIGH ORDER = -1
8294  033662  001401                          BEQ     12$
8295  033664  104000                          EMT                     ;HIGH ORDER IS WRONG
8296  033666  022701  177777          12$:    CMP     #-1,%1!1        ;IS LOW ORDER = -1
```

```
                                        BEQ     13$
                                        EMT                             ;LOW ORDER IS WRONG OR WRONG SEQUENCE
                                13$:
                                        INC     (R5)


                                ;*****************************************************************************
                                ;TEST:235       MUL     -1 * #0 = 0 0           PS = 4
                                ;*****************************************************************************

                                TST235:
                                        MOV     #-1,%3                  ;LOAD MULTIPLICAND WITH -1
                                        MUL     #0,%3                   ;MULTIPLY -1 * #0
                                        MFPS    @#PSWORD                ;SAVE PS
                                        CMPB    #4,@#PSWORD             ;IS PS = 4
                                        BEQ     11$
                                        EMT                             ;PS IS WRONG
                                11$:    CMP     #0,%3                   ;IS HIGH ORDER = 0
                                        BEQ     12$
                                        EMT                             ;HIGH ORDER IS WRONG
                                12$:    CMP     #0,%3!1                 ;IS LOW ORDER = 0
                                        BEQ     13$
                                        EMT                             ;LOW ORDER IS WRONG OR WRONG SEQUENCE
                                13$:
                                        INC     (R5)


                                ;*****************************************************************************
                                ;TEST:236       MUL     77777 * #100000 = 100000 100000         PS = 11
                                ;*****************************************************************************

                                TST236:
                                        MOV     R5,R1                   ;SAVE R5
                                        MOV     #77777,%5               ;LOAD MULTIPLICAND WITH 77777
                                        MUL     #100000,%5              ;MULTIPLY 77777 * #100000
                                        MFPS    @#PSWORD                ;SAVE PS
                                        CMPB    #11,@#PSWORD            ;IS PS = 11
                                        BEQ     11$
                                        EMT                             ;PS IS WRONG
                                11$:    CMP     #100000,%5              ;IS HIGH ORDER = 100000
                                        BEQ     12$
                                        EMT                             ;HIGH ORDER IS WRONG
                                12$:    CMP     #100000,%5!1            ;IS LOW ORDER = 100000
                                        BEQ     13$
                                        EMT                             ;LOW ORDER IS WRONG OR WRONG SEQUENCE
                                13$:
                                        MOV     R1,R5                   ;RESTORE R5
                                        INC     (R5)


                                ;*****************************************************************************
                                ;TEST:237       MUL     -1 * #77777 = 100001 100001         PS = 10
                                ;*****************************************************************************

                                TST237:
                                        MOV     #-1,%1                  ;LOAD MULTIPLICAND WITH -1
```

```
 8353  034030  070127  077777              MUL     #77777,%1       ;MULTIPLY -1 * #77777
 8354  034034  106737  025416              MFPS    @#PSWORD        ;SAVE PS
 8355  034040  122737  000010  025416      CMPB    #10,@#PSWORD    ;IS PS = 10
 8356  034046  001401                      BEQ     11$
 8357  034050  104000                      EMT                     ;PS IS WRONG
 8358  034052  022701  100001          11$: CMP    #100001,%1      ;IS HIGH ORDER = 100001
 8359  034056  001401                      BEQ     12$
 8360  034060  104000                      EMT                     ;HIGH ORDER IS WRONG
 8361  034062  022701  100001          12$: CMP    #100001,%1!1    ;IS LOW ORDER = 100001
 8362  034066  001401                      BEQ     13$
 8363  034070  104000                      EMT                     ;LOW ORDER IS WRONG OR WRONG SEQUENCE
 8364  034072                          13$:
 8365  034072  005215                      INC     (R5)
 8366
 8367
 8368                                  ;*************************************************************************
 8369                                  ;TEST:240       MUL      77777 * #77777 = 1 1        PS = 1
 8370                                  ;*************************************************************************
 8371
 8372  034074                          TST240:
 8373  034074  012703  077777              MOV     #77777,%3       ;LOAD MULTIPLICAND WITH 77777
 8374  034100  070327  077777              MUL     #77777,%3       ;MULTIPLY 77777 * #77777
 8375  034104  106737  025416              MFPS    @#PSWORD        ;SAVE PS
 8376  034110  122737  000001  025416      CMPB    #1,@#PSWORD     ;IS PS = 1
 8377  034116  001401                      BEQ     11$
 8378  034120  104000                      EMT                     ;PS IS WRONG
 8379  034122  022703  000001          11$: CMP    #1,%3           ;IS HIGH ORDER = 1
 8380  034126  001401                      BEQ     12$
 8381  034130  104000                      EMT                     ;HIGH ORDER IS WRONG
 8382  034132  022703  000001          12$: CMP    #1,%3!1         ;IS LOW ORDER = 1
 8383  034136  001401                      BEQ     13$
 8384  034140  104000                      EMT                     ;LOW ORDER IS WRONG OR WRONG SEQUENCE
 8385  034142                          13$:
 8386  034142  005215                      INC     (R5)
 8387
 8388
 8389                                  ;*************************************************************************
 8390                                  ;TEST:241       MUL      2 * #2 = 4 4        PS = 0
 8391                                  ;*************************************************************************
 8392
 8393  034144                          TST241:
 8394  034144  010501                      MOV     R5,R1           ;SAVE R5
 8395  034146  012705  000002              MOV     #2,%5           ;LOAD MULTIPLICAND WITH 2
 8396  034152  070527  000002              MUL     #2,%5           ;MULTIPLY 2 * #2
 8397  034156  106737  025416              MFPS    @#PSWORD        ;SAVE PS
 8398  034162  122737  000000  025416      CMPB    #0,@#PSWORD     ;IS PS = 0
 8399  034170  001401                      BEQ     11$
 8400  034172  104000                      EMT                     ;PS IS WRONG
 8401  034174  022705  000004          11$: CMP    #4,%5           ;IS HIGH ORDER = 4
 8402  034200  001401                      BEQ     12$
 8403  034202  104000                      EMT                     ;HIGH ORDER IS WRONG
 8404  034204  022705  000004          12$: CMP    #4,%5!1         ;IS LOW ORDER = 4
 8405  034210  001401                      BEQ     13$
 8406  034212  104000                      EMT                     ;LOW ORDER IS WRONG OR WRONG SEQUENCE
 8407  034214                          13$:
 8408  034214  010105                      MOV     R1,R5           ;RESTORE R5
```

```
8409  034216  005215                          INC     (R5)
8410
8411
8412  034220  012702  040000                  MOV     #40000,%2
8413  034224  012703  025444                  MOV     #S5,%3
8414  034230  012704  025446                  MOV     #S6,%4
8415
8416                                  ;*************************************************************************
8417                                  ;TEST:242       MUL     125252 * S5 = 165252 100000     PS = 11
8418                                  ;*************************************************************************
8419
8420  034234                          TST242:
8421  034234  012700  125252                  MOV     #125252,%0      ;LOAD MULTIPLICAND WITH 125252
8422  034240  070067  171200                  MUL     S5,%0           ;MULTIPLY 125252 * S5
8423  034244  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
8424  034250  122737  000011  025416          CMPB    #11,@#PSWORD    ;IS PS = 11
8425  034256  001401                          BEQ     11$
8426  034260  104000                          EMT                     ;PS IS WRONG
8427  034262  022700  165252          11$:    CMP     #165252,%0      ;IS HIGH ORDER = 165252
8428  034266  001401                          BEQ     12$
8429  034270  104000                          EMT                     ;HIGH ORDER IS WRONG
8430  034272  022701  100000          12$:    CMP     #100000,%0!1    ;IS LOW ORDER = 100000
8431  034276  001401                          BEQ     13$
8432  034300  104000                          EMT                     ;LOW ORDER IS WRONG OR WRONG SEQUENCE
8433  034302                          13$:
8434  034302  005215                          INC     (R5)
8435
8436
8437                                  ;*************************************************************************
8438                                  ;TEST:243       MUL     125252 * @S6 = 165252 100000     PS = 11
8439                                  ;*************************************************************************
8440
8441  034304                          TST243:
8442  034304  012700  125252                  MOV     #125252,%0      ;LOAD MULTIPLICAND WITH 125252
8443  034310  070077  171132                  MUL     @S6,%0          ;MULTIPLY 125252 * @S6
8444  034314  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
8445  034320  122737  000011  025416          CMPB    #11,@#PSWORD    ;IS PS = 11
8446  034326  001401                          BEQ     11$
8447  034330  104000                          EMT                     ;PS IS WRONG
8448  034332  022700  165252          11$:    CMP     #165252,%0      ;IS HIGH ORDER = 165252
8449  034336  001401                          BEQ     12$
8450  034340  104000                          EMT                     ;HIGH ORDER IS WRONG
8451  034342  022701  100000          12$:    CMP     #100000,%0!1    ;IS LOW ORDER = 100000
8452  034346  001401                          BEQ     13$
8453  034350  104000                          EMT                     ;LOW ORDER IS WRONG OR WRONG SEQUENCE
8454  034352                          13$:
8455  034352  005215                          INC     (R5)
8456
8457
8458                                  ;*************************************************************************
8459                                  ;TEST:244       MUL     125252 * @#S5 = 165252 100000     PS = 11
8460                                  ;*************************************************************************
8461
8462  034354                          TST244:
8463  034354  012700  125252                  MOV     #125252,%0      ;LOAD MULTIPLICAND WITH 125252
8464  034360  070037  025444                  MUL     @#S5,%0         ;MULTIPLY 125252 * @#S5
```

```
 8465  034364  106737  025416                 MFPS    @#PSWORD          ;SAVE PS
 8466  034370  122737  000011  025416         CMPB    #11,@#PSWORD      ;IS PS = 11
 8467  034376  001401                         BEQ     11$
 8468  034400  104000                         EMT                       ;PS IS WRONG
 8469  034402  022700  165252          11$:   CMP     #165252,%0        ;IS HIGH ORDER = 165252
 8470  034406  001401                         BEQ     12$
 8471  034410  104000                         EMT                       ;HIGH ORDER IS WRONG
 8472  034412  022701  100000          12$:   CMP     #100000,%0!1      ;IS LOW ORDER = 100000
 8473  034416  001401                         BEQ     13$
 8474  034420  104000                         EMT                       ;LOW ORDER IS WRONG OR WRONG SEQUENCE
 8475  034422                         13$:
 8476  034422  005215                         INC     (R5)
 8477
 8478
 8479                                 ;*************************************************************************
 8480                                 ;TEST:245       MUL     125252 * %2 = 165252 100000        PS = 11
 8481                                 ;*************************************************************************
 8482
 8483  034424                         TST245:
 8484  034424  012700  125252                 MOV     #125252,%0        ;LOAD MULTIPLICAND WITH 125252
 8485  034430  070002                         MUL     %2,%0             ;MULTIPLY 125252 * %2
 8486  034432  106737  025416                 MFPS    @#PSWORD          ;SAVE PS
 8487  034436  122737  000011  025416         CMPB    #11,@#PSWORD      ;IS PS = 11
 8488  034444  001401                         BEQ     11$
 8489  034446  104000                         EMT                       ;PS IS WRONG
 8490  034450  022700  165252          11$:   CMP     #165252,%0        ;IS HIGH ORDER = 165252
 8491  034454  001401                         BEQ     12$
 8492  034456  104000                         EMT                       ;HIGH ORDER IS WRONG
 8493  034460  022701  100000          12$:   CMP     #100000,%0!1      ;IS LOW ORDER = 100000
 8494  034464  001401                         BEQ     13$
 8495  034466  104000                         EMT                       ;LOW ORDER IS WRONG OR WRONG SEQUENCE
 8496  034470                         13$:
 8497  034470  005215                         INC     (R5)
 8498
 8499
 8500                                 ;*************************************************************************
 8501                                 ;TEST:246       MUL     125252 * (3)+ = 165252 100000      PS = 11
 8502                                 ;*************************************************************************
 8503
 8504  034472                         TST246:
 8505  034472  012700  125252                 MOV     #125252,%0        ;LOAD MULTIPLICAND WITH 125252
 8506  034476  070023                         MUL     (3)+,%0           ;MULTIPLY 125252 * (3)+
 8507  034500  106737  025416                 MFPS    @#PSWORD          ;SAVE PS
 8508  034504  122737  000011  025416         CMPB    #11,@#PSWORD      ;IS PS = 11
 8509  034512  001401                         BEQ     11$
 8510  034514  104000                         EMT                       ;PS IS WRONG
 8511  034516  022700  165252          11$:   CMP     #165252,%0        ;IS HIGH ORDER = 165252
 8512  034522  001401                         BEQ     12$
 8513  034524  104000                         EMT                       ;HIGH ORDER IS WRONG
 8514  034526  022701  100000          12$:   CMP     #100000,%0!1      ;IS LOW ORDER = 100000
 8515  034532  001401                         BEQ     13$
 8516  034534  104000                         EMT                       ;LOW ORDER IS WRONG OR WRONG SEQUENCE
 8517  034536                         13$:
 8518  034536  005215                         INC     (R5)
 8519
 8520
```

```
                        ;*****************************************************************************
                        ;TEST:247       MUL     125252 * -(3) = 165252 100000        PS = 11
                        ;*****************************************************************************

034540                  TST247:
034540  012700  125252          MOV     #125252,%0      ;LOAD MULTIPLICAND WITH 125252
034544  070043          MUL     -(3),%0         ;MULTIPLY 125252 * -(3)
034546  106737  025416          MFPS    @#PSWORD        ;SAVE PS
034552  122737  000011  025416  CMPB    #11,@#PSWORD    ;IS PS = 11
034560  001401          BEQ     11$
034562  104000          EMT                     ;PS IS WRONG
034564  022700  165252  11$:    CMP     #165252,%0      ;IS HIGH ORDER = 165252
034570  001401          BEQ     12$
034572  104000          EMT                     ;HIGH ORDER IS WRONG
034574  022701  100000  12$:    CMP     #100000,%0!1    ;IS LOW ORDER = 100000
034600  001401          BEQ     13$
034602  104000          EMT                     ;LOW ORDER IS WRONG OR WRONG SEQUENCE
034604                  13$:
034604  005215          INC     (R5)


                        ;*****************************************************************************
                        ;TEST:250       MUL     125252 * 2(4) = 165252 100000        PS = 11
                        ;*****************************************************************************

034606                  TST250:
034606  012700  125252          MOV     #125252,%0      ;LOAD MULTIPLICAND WITH 125252
034612  070064  000002          MUL     2(4),%0         ;MULTIPLY 125252 * 2(4)
034616  106737  025416          MFPS    @#PSWORD        ;SAVE PS
034622  122737  000011  025416  CMPB    #11,@#PSWORD    ;IS PS = 11
034630  001401          BEQ     11$
034632  104000          EMT                     ;PS IS WRONG
034634  022700  165252  11$:    CMP     #165252,%0      ;IS HIGH ORDER = 165252
034640  001401          BEQ     12$
034642  104000          EMT                     ;HIGH ORDER IS WRONG
034644  022701  100000  12$:    CMP     #100000,%0!1    ;IS LOW ORDER = 100000
034650  001401          BEQ     13$
034652  104000          EMT                     ;LOW ORDER IS WRONG OR WRONG SEQUENCE
034654                  13$:
034654  005215          INC     (R5)


                        ;*****************************************************************************
                        ;TEST:251       MUL     125252 * @(4) = 165252 100000        PS = 11
                        ;*****************************************************************************

034656                  TST251:
034656  012700  125252          MOV     #125252,%0      ;LOAD MULTIPLICAND WITH 125252
034662  070074  000000          MUL     @(4),%0         ;MULTIPLY 125252 * @(4)
034666  106737  025416          MFPS    @#PSWORD        ;SAVE PS
034672  122737  000011  025416  CMPB    #11,@#PSWORD    ;IS PS = 11
034700  001401          BEQ     11$
034702  104000          EMT                     ;PS IS WRONG
034704  022700  165252  11$:    CMP     #165252,%0      ;IS HIGH ORDER = 165252
034710  001401          BEQ     12$
034712  104000          EMT                     ;HIGH ORDER IS WRONG
```

```
8577  034714  022701  100000          12$:    CMP     #100000,%0!1    ;IS LOW ORDER = 100000
8578  034720  001401                          BEQ     13$
8579  034722  104000                          EMT                     ;LOW ORDER IS WRONG OR WRONG SEQUENCE
8580  034724                          13$:
8581  034724  005215                          INC     (R5)
8582
8583
8584                                  ;*************************************************************************
8585                                  ;TEST:252       MUL     125252 * @(4)+ = 165252 100000          PS = 11
8586                                  ;*************************************************************************
8587
8588  034726                          TST252:
8589  034726  012700  125252                  MOV     #125252,%0      ;LOAD MULTIPLICAND WITH 125252
8590  034732  070034                          MUL     @(4)+,%0        ;MULTIPLY 125252 * @(4)+
8591  034734  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
8592  034740  122737  000011  025416          CMPB    #11,@#PSWORD    ;IS PS = 11
8593  034746  001401                          BEQ     11$
8594  034750  104000                          EMT                     ;PS IS WRONG
8595  034752  022700  165252          11$:    CMP     #165252,%0      ;IS HIGH ORDER = 165252
8596  034756  001401                          BEQ     12$
8597  034760  104000                          EMT                     ;HIGH ORDER IS WRONG
8598  034762  022701  100000          12$:    CMP     #100000,%0!1    ;IS LOW ORDER = 100000
8599  034766  001401                          BEQ     13$
8600  034770  104000                          EMT                     ;LOW ORDER IS WRONG OR WRONG SEQUENCE
8601  034772                          13$:
8602  034772  005215                          INC     (R5)
8603
8604
8605                                  ;*************************************************************************
8606                                  ;TEST:253       MUL     125252 * @-(4) = 165252 100000          PS = 11
8607                                  ;*************************************************************************
8608
8609  034774                          TST253:
8610  034774  012700  125252                  MOV     #125252,%0      ;LOAD MULTIPLICAND WITH 125252
8611  035000  070054                          MUL     @-(4),%0        ;MULTIPLY 125252 * @-(4)
8612  035002  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
8613  035006  122737  000011  025416          CMPB    #11,@#PSWORD    ;IS PS = 11
8614  035014  001401                          BEQ     11$
8615  035016  104000                          EMT                     ;PS IS WRONG
8616  035020  022700  165252          11$:    CMP     #165252,%0      ;IS HIGH ORDER = 165252
8617  035024  001401                          BEQ     12$
8618  035026  104000                          EMT                     ;HIGH ORDER IS WRONG
8619  035030  022701  100000          12$:    CMP     #100000,%0!1    ;IS LOW ORDER = 100000
8620  035034  001401                          BEQ     13$
8621  035036  104000                          EMT                     ;LOW ORDER IS WRONG OR WRONG SEQUENCE
8622  035040                          13$:
8623  035040  005215                          INC     (R5)
8624
8625
```

```
                                        ;*********************************
                                        ;     DIV INSTRUCTION TESTS
                                        ;*********************************



                                        ;*************************************************************************
                                        ;TEST:254      DIV     0 4 / #2 = 2       REM = 0      PS = 0
                                        ;*************************************************************************

035042                                  TST254:
035042  012700  000000                          MOV     #0,%0           ;LOAD HIGH ORDER WITH 0
035046  012701  000004                          MOV     #4,%0+1         ;LOAD LOW ORDER WITH 4
035052  071027  000002                          DIV     #2,%0           ;DIVIDE BY #2
035056  106737  025416                          MFPS    @#PSWORD        ;SAVE PS
035062  122737  000000  025416                  CMPB    #0,@#PSWORD     ;IS PS = 0
035070  001401                                  BEQ     11$
035072  104000                                  EMT                     ;PS IS WRONG
035074  022700  000002          11$:    CMP     #2,%0           ;IS QUOTIENT = 2
035100  001401                                  BEQ     12$
035102  104000                                  EMT                     ;QUOTIENT IS WRONG
035104  022701  000000          12$:    CMP     #0,%0+1         ;IS REMAINDER = 0
035110  001401                                  BEQ     13$
035112  104000                                  EMT                     ;WRONG REMAINDER
035114                          13$:
035114  005215                          INC     (R5)

                                        ;*************************************************************************
                                        ;TEST:255      DIV     -1 -9. / #3 = -3       REM = 0      PS = 10
                                        ;*************************************************************************

035116                                  TST255:
035116  012702  177777                          MOV     #-1,%2          ;LOAD HIGH ORDER WITH -1
035122  012703  177767                          MOV     #-9.,%2+1       ;LOAD LOW ORDER WITH -9.
035126  071227  000003                          DIV     #3,%2           ;DIVIDE BY #3
035132  106737  025416                          MFPS    @#PSWORD        ;SAVE PS
035136  122737  000010  025416                  CMPB    #10,@#PSWORD    ;IS PS = 10
035144  001401                                  BEQ     11$
035146  104000                                  EMT                     ;PS IS WRONG
035150  022702  177775          11$:    CMP     #-3,%2          ;IS QUOTIENT = -3
035154  001401                                  BEQ     12$
035156  104000                                  EMT                     ;QUOTIENT IS WRONG
035160  022703  000000          12$:    CMP     #0,%2+1         ;IS REMAINDER = 0
035164  001401                                  BEQ     13$
035166  104000                                  EMT                     ;WRONG REMAINDER
035170                          13$:
035170  005215                          INC     (R5)

                                        ;*************************************************************************
                                        ;TEST:256      DIV     0 9. / #2 = 4       REM = 1      PS = 0
                                        ;*************************************************************************

035172                                  TST256:
035172  010501                                  MOV     R5,R1           ;SAVE R5
035174  012704  000000                          MOV     #0,%4           ;LOAD HIGH ORDER WITH 0
035200  012705  000011                          MOV     #9.,%4+1        ;LOAD LOW ORDER WITH 9.
```

```
 8682  035204  071427  000002                  DIV     #2,%4           ;DIVIDE BY #2
 8683  035210  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
 8684  035214  122737  000000  025416          CMPB    #0,@#PSWORD     ;IS PS = 0
 8685  035222  001401                          BEQ     11$
 8686  035224  104000                          EMT                     ;PS IS WRONG
 8687  035226  022704  000004          11$:    CMP     #4,%4           ;IS QUOTIENT = 4
 8688  035232  001401                          BEQ     12$
 8689  035234  104000                          EMT                     ;QUOTIENT IS WRONG
 8690  035236  022705  000001          12$:    CMP     #1,%4+1         ;IS REMAINDER = 1
 8691  035242  001401                          BEQ     13$
 8692  035244  104000                          EMT                     ;WRONG REMAINDER
 8693  035246                          13$:
 8694  035246  010105                          MOV     R1,R5           ;RESTORE R5
 8695  035250  005215                          INC     (R5)
 8696
 8697                                  ;*************************************************************************
 8698                                  ;TEST:257      DIV     -1 -9. / #2 = -4       REM = -1       PS = 10
 8699                                  ;*************************************************************************
 8700
 8701  035252                          TST257:
 8702  035252  012700  177777                  MOV     #-1,%0          ;LOAD HIGH ORDER WITH -1
 8703  035256  012701  177767                  MOV     #-9.,%0+1       ;LOAD LOW ORDER WITH -9.
 8704  035262  071027  000002                  DIV     #2,%0           ;DIVIDE BY #2
 8705  035266  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
 8706  035272  122737  000010  025416          CMPB    #10,@#PSWORD    ;IS PS = 10
 8707  035300  001401                          BEQ     11$
 8708  035302  104000                          EMT                     ;PS IS WRONG
 8709  035304  022700  177774          11$:    CMP     #-4,%0          ;IS QUOTIENT = -4
 8710  035310  001401                          BEQ     12$
 8711  035312  104000                          EMT                     ;QUOTIENT IS WRONG
 8712  035314  022701  177777          12$:    CMP     #-1,%0+1        ;IS REMAINDER = -1
 8713  035320  001401                          BEQ     13$
 8714  035322  104000                          EMT                     ;WRONG REMAINDER
 8715  035324                          13$:
 8716  035324  005215                          INC     (R5)
 8717
 8718                                  ;*************************************************************************
 8719                                  ;TEST:260      DIV     0 2 / #-3 = 0       REM = 2       PS = 4
 8720                                  ;*************************************************************************
 8721
 8722  035326                          TST260:
 8723  035326  012702  000000                  MOV     #0,%2           ;LOAD HIGH ORDER WITH 0
 8724  035332  012703  000002                  MOV     #2,%2+1         ;LOAD LOW ORDER WITH 2
 8725  035336  071227  177775                  DIV     #-3,%2          ;DIVIDE BY #-3
 8726  035342  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
 8727  035346  122737  000004  025416          CMPB    #4,@#PSWORD     ;IS PS = 4
 8728  035354  001401                          BEQ     11$
 8729  035356  104000                          EMT                     ;PS IS WRONG
 8730  035360  022702  000000          11$:    CMP     #0,%2           ;IS QUOTIENT = 0
 8731  035364  001401                          BEQ     12$
 8732  035366  104000                          EMT                     ;QUOTIENT IS WRONG
 8733  035370  022703  000002          12$:    CMP     #2,%2+1         ;IS REMAINDER = 2
 8734  035374  001401                          BEQ     13$
 8735  035376  104000                          EMT                     ;WRONG REMAINDER
 8736  035400                          13$:
 8737  035400  005215                          INC     (R5)
```

```
                                ;*****************************************************************************
                                ;TEST:261      DIV     -1 -2 / #3 = 0       REM = -2      PS = 4
                                ;*****************************************************************************

035402                          TST261:
035402  010501                          MOV     R5,R1           ;SAVE R5
035404  012704  177777                  MOV     #-1,%4          ;LOAD HIGH ORDER WITH -1
035410  012705  177776                  MOV     #-2,%4+1        ;LOAD LOW ORDER WITH -2
035414  071427  000003                  DIV     #3,%4           ;DIVIDE BY #3
035420  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
035424  122737  000004  025416          CMPB    #4,@#PSWORD     ;IS PS = 4
035432  001401                          BEQ     11$
035434  104000                          EMT                     ;PS IS WRONG
035436  022704  000000          11$:    CMP     #0,%4           ;IS QUOTIENT = 0
035442  001401                          BEQ     12$
035444  104000                          EMT                     ;QUOTIENT IS WRONG
035446  022705  177776          12$:    CMP     #-2,%4+1        ;IS REMAINDER = -2
035452  001401                          BEQ     13$
035454  104000                          EMT                     ;WRONG REMAINDER
035456                          13$:
035456  010105                          MOV     R1,R5           ;RESTORE R5
035460  005215                          INC     (R5)

                                ;*****************************************************************************
                                ;TEST:262      DIV     -1 -1 / #1 = -1       REM = 0       PS = 10
                                ;*****************************************************************************

035462                          TST262:
035462  012700  177777                  MOV     #-1,%0          ;LOAD HIGH ORDER WITH -1
035466  012701  177777                  MOV     #-1,%0+1        ;LOAD LOW ORDER WITH -1
035472  071027  000001                  DIV     #1,%0           ;DIVIDE BY #1
035476  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
035502  122737  000010  025416          CMPB    #10,@#PSWORD    ;IS PS = 10
035510  001401                          BEQ     11$
035512  104000                          EMT                     ;PS IS WRONG
035514  022700  177777          11$:    CMP     #-1,%0          ;IS QUOTIENT = -1
035520  001401                          BEQ     12$
035522  104000                          EMT                     ;QUOTIENT IS WRONG
035524  022701  000000          12$:    CMP     #0,%0+1         ;IS REMAINDER = 0
035530  001401                          BEQ     13$
035532  104000                          EMT                     ;WRONG REMAINDER
035534                          13$:
035534  005215                          INC     (R5)

                                ;*****************************************************************************
                                ;TEST:263      DIV     0 0 / #1 = 0       REM = 0       PS = 4
                                ;*****************************************************************************

035536                          TST263:
035536  012700  000000                  MOV     #0,%0           ;LOAD HIGH ORDER WITH 0
035542  012701  000000                  MOV     #0,%0+1         ;LOAD LOW ORDER WITH 0
035546  071027  000001                  DIV     #1,%0           ;DIVIDE BY #1
035552  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
035556  122737  000004  025416          CMPB    #4,@#PSWORD     ;IS PS = 4
035564  001401                          BEQ     11$
```

```
8794  035566  104000                          EMT                     ;PS IS WRONG
8795  035570  022700  000000          11$:    CMP     #0,%0           ;IS QUOTIENT = 0
8796  035574  001401                          BEQ     12$
8797  035576  104000                          EMT                     ;QUOTIENT IS WRONG
8798  035600  022701  000000          12$:    CMP     #0,%0+1         ;IS REMAINDER = 0
8799  035604  001401                          BEQ     13$
8800  035606  104000                          EMT                     ;WRONG REMAINDER
8801  035610                          13$:
8802  035610  005215                          INC     (R5)
8803
8804                                  ;*******************************************************************************
8805                                  ;TEST:264       DIV     -1 125252 / #2 = 152525         REM = 0       PS = 10
8806                                  ;*******************************************************************************
8807
8808  035612                          TST264:
8809  035612  012702  177777                  MOV     #-1,%2          ;LOAD HIGH ORDER WITH -1
8810  035616  012703  125252                  MOV     #125252,%2+1    ;LOAD LOW ORDER WITH 125252
8811  035622  071227  000002                  DIV     #2,%2           ;DIVIDE BY #2
8812  035626  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
8813  035632  122737  000010  025416         CMPB    #10,@#PSWORD    ;IS PS = 10
8814  035640  001401                          BEQ     11$
8815  035642  104000                          EMT                     ;PS IS WRONG
8816  035644  022702  152525          11$:    CMP     #152525,%2      ;IS QUOTIENT = 152525
8817  035650  001401                          BEQ     12$
8818  035652  104000                          EMT                     ;QUOTIENT IS WRONG
8819  035654  022703  000000          12$:    CMP     #0,%2+1         ;IS REMAINDER = 0
8820  035660  001401                          BEQ     13$
8821  035662  104000                          EMT                     ;WRONG REMAINDER
8822  035664                          13$:
8823  035664  005215                          INC     (R5)
8824
8825                                  ;*******************************************************************************
8826                                  ;TEST:265       DIV     -1 -1 / #-1 = 1         REM = 0       PS = 0
8827                                  ;*******************************************************************************
8828
8829  035666                          TST265:
8830  035666  010501                          MOV     R5,R1           ;SAVE R5
8831  035670  012704  177777                  MOV     #-1,%4          ;LOAD HIGH ORDER WITH -1
8832  035674  012705  177777                  MOV     #-1,%4+1        ;LOAD LOW ORDER WITH -1
8833  035700  071427  177777                  DIV     #-1,%4          ;DIVIDE BY #-1
8834  035704  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
8835  035710  122737  000000  025416         CMPB    #0,@#PSWORD     ;IS PS = 0
8836  035716  001401                          BEQ     11$
8837  035720  104000                          EMT                     ;PS IS WRONG
8838  035722  022704  000001          11$:    CMP     #1,%4           ;IS QUOTIENT = 1
8839  035726  001401                          BEQ     12$
8840  035730  104000                          EMT                     ;QUOTIENT IS WRONG
8841  035732  022705  000000          12$:    CMP     #0,%4+1         ;IS REMAINDER = 0
8842  035736  001401                          BEQ     13$
8843  035740  104000                          EMT                     ;WRONG REMAINDER
8844  035742                          13$:
8845  035742  010105                          MOV     R1,R5           ;RESTORE R5
8846  035744  005215                          INC     (R5)
8847
8848                                  ;*******************************************************************************
8849                                  ;TEST:266       DIV     25253 1 / #125252 = 100000      REM = 1       PS = 10
```

```
                                ;*****************************************************************************

035746                          TST266:
035746  012700  025253                  MOV     #25253,%0       ;LOAD HIGH ORDER WITH 25253
035752  012701  000001                  MOV     #1,%0+1         ;LOAD LOW ORDER WITH 1
035756  071027  125252                  DIV     #125252,%0      ;DIVIDE BY #125252
035762  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
035766  122737  000010  025416          CMPB    #10,@#PSWORD    ;IS PS = 10
035774  001401                          BEQ     11$
035776  104000                          EMT                     ;PS IS WRONG
036000  022700  100000          11$:    CMP     #100000,%0      ;IS QUOTIENT = 100000
036004  001401                          BEQ     12$
036006  104000                          EMT                     ;QUOTIENT IS WRONG
036010  022701  000001          12$:    CMP     #1,%0+1         ;IS REMAINDER = 1
036014  001401                          BEQ     13$
036016  104000                          EMT                     ;WRONG REMAINDER
036020                          13$:
036020  005215                          INC     (R5)

                                ;*****************************************************************************
                                ;TEST:267       DIV     37777 77777 / #77777 = 77777       REM = 77776      PS = 0
                                ;*****************************************************************************

036022                          TST267:
036022  012702  037777                  MOV     #37777,%2       ;LOAD HIGH ORDER WITH 37777
036026  012703  077777                  MOV     #77777,%2+1     ;LOAD LOW ORDER WITH 77777
036032  071227  077777                  DIV     #77777,%2       ;DIVIDE BY #77777
036036  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
036042  122737  000000  025416          CMPB    #0,@#PSWORD     ;IS PS = 0
036050  001401                          BEQ     11$
036052  104000                          EMT                     ;PS IS WRONG
036054  022702  077777          11$:    CMP     #77777,%2       ;IS QUOTIENT = 77777
036060  001401                          BEQ     12$
036062  104000                          EMT                     ;QUOTIENT IS WRONG
036064  022703  077776          12$:    CMP     #77776,%2+1     ;IS REMAINDER = 77776
036070  001401                          BEQ     13$
036072  104000                          EMT                     ;WRONG REMAINDER
036074                          13$:
036074  005215                          INC     (R5)

                                ;*****************************************************************************
                                ;TEST:270       DIV     0 100000 / #2 = 40000       REM = 0      PS = 0
                                ;*****************************************************************************

036076                          TST270:
036076  010501                          MOV     R5,R1           ;SAVE R5
036100  012704  000000                  MOV     #0,%4           ;LOAD HIGH ORDER WITH 0
036104  012705  100000                  MOV     #100000,%4+1    ;LOAD LOW ORDER WITH 100000
036110  071427  000002                  DIV     #2,%4           ;DIVIDE BY #2
036114  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
036120  122737  000000  025416          CMPB    #0,@#PSWORD     ;IS PS = 0
036126  001401                          BEQ     11$
036130  104000                          EMT                     ;PS IS WRONG
036132  022704  040000          11$:    CMP     #40000,%4       ;IS QUOTIENT = 40000
036136  001401                          BEQ     12$
036140  104000                          EMT                     ;QUOTIENT IS WRONG
```

```
8906  036142  022705  000000          12$:    CMP     #0,%4+1         ;IS REMAINDER = 0
8907  036146  001401                          BEQ     13$
8908  036150  104000                          EMT                     ;WRONG REMAINDER
8909  036152                          13$:
8910  036152  010105                          MOV     R1,R5           ;RESTORE R5
8911  036154  005215                          INC     (R5)
8912
8913                                  ;*************************************************************************
8914                                  ;TEST:271       DIV     177777 77777 / #177776 = 40000       REM = 177777       PS = 0
8915                                  ;*************************************************************************
8916
8917  036156                          TST271:
8918  036156  012700  177777                 MOV     #177777,%0      ;LOAD HIGH ORDER WITH 177777
8919  036162  012701  077777                 MOV     #77777,%0+1     ;LOAD LOW ORDER WITH 77777
8920  036166  071027  177776                 DIV     #177776,%0      ;DIVIDE BY #177776
8921  036172  106737  025416                 MFPS    @#PSWORD        ;SAVE PS
8922  036176  122737  000000  025416        CMPB    #0,@#PSWORD     ;IS PS = 0
8923  036204  001401                          BEQ     11$
8924  036206  104000                          EMT                     ;PS IS WRONG
8925  036210  022700  040000          11$:    CMP     #40000,%0       ;IS QUOTIENT = 40000
8926  036214  001401                          BEQ     12$
8927  036216  104000                          EMT                     ;QUOTIENT IS WRONG
8928  036220  022701  177777          12$:    CMP     #177777,%0+1    ;IS REMAINDER = 177777
8929  036224  001401                          BEQ     13$
8930  036226  104000                          EMT                     ;WRONG REMAINDER
8931  036230                          13$:
8932  036230  005215                          INC     (R5)
8933
8934                                  ;*************************************************************************
8935                                  ;TEST:272       DIV     0 52525 / #52525 = 1        REM = 0       PS = 0
8936                                  ;*************************************************************************
8937
8938  036232                          TST272:
8939  036232  012702  000000                 MOV     #0,%2           ;LOAD HIGH ORDER WITH 0
8940  036236  012703  052525                 MOV     #52525,%2+1     ;LOAD LOW ORDER WITH 52525
8941  036242  071227  052525                 DIV     #52525,%2       ;DIVIDE BY #52525
8942  036246  106737  025416                 MFPS    @#PSWORD        ;SAVE PS
8943  036252  122737  000000  025416        CMPB    #0,@#PSWORD     ;IS PS = 0
8944  036260  001401                          BEQ     11$
8945  036262  104000                          EMT                     ;PS IS WRONG
8946  036264  022702  000001          11$:    CMP     #1,%2           ;IS QUOTIENT = 1
8947  036270  001401                          BEQ     12$
8948  036272  104000                          EMT                     ;QUOTIENT IS WRONG
8949  036274  022703  000000          12$:    CMP     #0,%2+1         ;IS REMAINDER = 0
8950  036300  001401                          BEQ     13$
8951  036302  104000                          EMT                     ;WRONG REMAINDER
8952  036304                          13$:
8953  036304  005215                          INC     (R5)
8954
8955                                  ;*************************************************************************
8956                                  ;TEST:273       DIV     0 77777 / #0 = DUMMY        REM = DUMMY       PS = 3
8957                                  ;*************************************************************************
8958
8959  036306                          TST273:
8960  036306  010501                          MOV     R5,R1           ;SAVE R5
8961  036310  012704  000000                  MOV     #0,%4           ;LOAD HIGH ORDER WITH 0
```

```
 8962  036314  012705  077777                 MOV     #77777,%4+1     ;LOAD LOW ORDER WITH 77777
 8963  036320  071427  000000                 DIV     #0,%4           ;DIVIDE BY #0
 8964  036324  106737  025416                 MFPS    @#PSWORD        ;SAVE PS
 8965  036330  042737  000014  025416         BIC     #14,@#PSWORD
 8966  036336  122737  000003  025416         CMPB    #3,@#PSWORD     ;IS PS = 3
 8967  036344  001401                         BEQ     13$
 8968  036346  104000                         EMT                     ;PS IS WRONG
 8969  036350                               13$:
 8970  036350  010105                         MOV     R1,R5           ;RESTORE R5
 8971  036352  005215                         INC     (R5)
 8972
 8973                                       ;*************************************************************************
 8974                                       ;TEST:274       DIV     77777 177777 / #2 = DUMMY       REM = DUMMY     PS = 2
 8975                                       ;*************************************************************************
 8976
 8977  036354                               TST274:
 8978  036354  012700  077777                 MOV     #77777,%0       ;LOAD HIGH ORDER WITH 77777
 8979  036360  012701  177777                 MOV     #177777,%0+1    ;LOAD LOW ORDER WITH 177777
 8980  036364  071027  000002                 DIV     #2,%0           ;DIVIDE BY #2
 8981  036370  106737  025416                 MFPS    @#PSWORD        ;SAVE PS
 8982  036374  042737  000014  025416         BIC     #14,@#PSWORD
 8983  036402  122737  000002  025416         CMPB    #2,@#PSWORD     ;IS PS = 2
 8984  036410  001401                         BEQ     13$
 8985  036412  104000                         EMT                     ;PS IS WRONG
 8986  036414                               13$:
 8987  036414  005215                         INC     (R5)
 8988
 8989  036416  012702  000002                 MOV     #2,%2
 8990  036422  012703  025454                 MOV     #S9,%3
 8991  036426  012704  025456                 MOV     #S10,%4
 8992
 8993                                       ;*************************************************************************
 8994                                       ;TEST:275       DIV     0 52525 / S9 = 25252        REM = 1     PS = 0
 8995                                       ;*************************************************************************
 8996
 8997  036432                               TST275:
 8998  036432  012700  000000                 MOV     #0,%0           ;LOAD HIGH ORDER WITH 0
 8999  036436  012701  052525                 MOV     #52525,%0+1     ;LOAD LOW ORDER WITH 52525
 9000  036442  071067  167006                 DIV     S9,%0           ;DIVIDE BY S9
 9001  036446  106737  025416                 MFPS    @#PSWORD        ;SAVE PS
 9002  036452  122737  000000  025416         CMPB    #0,@#PSWORD     ;IS PS = 0
 9003  036460  001401                         BEQ     11$
 9004  036462  104000                         EMT                     ;PS IS WRONG
 9005  036464  022700  025252               11$:  CMP     #25252,%0       ;IS QUOTIENT = 25252
 9006  036470  001401                         BEQ     12$
 9007  036472  104000                         EMT                     ;QUOTIENT IS WRONG
 9008  036474  022701  000001               12$:  CMP     #1,%0+1         ;IS REMAINDER = 1
 9009  036500  001401                         BEQ     13$
 9010  036502  104000                         EMT                     ;WRONG REMAINDER
 9011  036504                               13$:
 9012  036504  005215                         INC     (R5)
 9013
 9014                                       ;*************************************************************************
 9015                                       ;TEST:276       DIV     0 52525 / @S10 = 25252      REM = 1     PS = 0
 9016                                       ;*************************************************************************
 9017
```

```
 9018  036506                          TST276:
 9019  036506  012700  000000                  MOV     #0,%0           ;LOAD HIGH ORDER WITH 0
 9020  036512  012701  052525                  MOV     #52525,%0+1     ;LOAD LOW ORDER WITH 52525
 9021  036516  071077  166734                  DIV     @S10,%0         ;DIVIDE BY @S10
 9022  036522  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
 9023  036526  122737  000000  025416          CMPB    #0,@#PSWORD     ;IS PS = 0
 9024  036534  001401                          BEQ     11$
 9025  036536  104000                          EMT                     ;PS IS WRONG
 9026  036540  022700  025252          11$:    CMP     #25252,%0       ;IS QUOTIENT = 25252
 9027  036544  001401                          BEQ     12$
 9028  036546  104000                          EMT                     ;QUOTIENT IS WRONG
 9029  036550  022701  000001          12$:    CMP     #1,%0+1         ;IS REMAINDER = 1
 9030  036554  001401                          BEQ     13$
 9031  036556  104000                          EMT                     ;WRONG REMAINDER
 9032  036560                          13$:
 9033  036560  005215                          INC     (R5)
 9034
 9035                                  ;*************************************************************************
 9036                                  ;TEST:277      DIV     0 52525 / @#S9 = 25252       REM = 1      PS = 0
 9037                                  ;*************************************************************************
 9038
 9039  036562                          TST277:
 9040  036562  012700  000000                  MOV     #0,%0           ;LOAD HIGH ORDER WITH 0
 9041  036566  012701  052525                  MOV     #52525,%0+1     ;LOAD LOW ORDER WITH 52525
 9042  036572  071037  025454                  DIV     @#S9,%0         ;DIVIDE BY @#S9
 9043  036576  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
 9044  036602  122737  000000  025416          CMPB    #0,@#PSWORD     ;IS PS = 0
 9045  036610  001401                          BEQ     11$
 9046  036612  104000                          EMT                     ;PS IS WRONG
 9047  036614  022700  025252          11$:    CMP     #25252,%0       ;IS QUOTIENT = 25252
 9048  036620  001401                          BEQ     12$
 9049  036622  104000                          EMT                     ;QUOTIENT IS WRONG
 9050  036624  022701  000001          12$:    CMP     #1,%0+1         ;IS REMAINDER = 1
 9051  036630  001401                          BEQ     13$
 9052  036632  104000                          EMT                     ;WRONG REMAINDER
 9053  036634                          13$:
 9054  036634  005215                          INC     (R5)
 9055
 9056                                  ;*************************************************************************
 9057                                  ;TEST:300      DIV     0 52525 / %2 = 25252       REM = 1      PS = 0
 9058                                  ;*************************************************************************
 9059
 9060  036636                          TST300:
 9061  036636  012700  000000                  MOV     #0,%0           ;LOAD HIGH ORDER WITH 0
 9062  036642  012701  052525                  MOV     #52525,%0+1     ;LOAD LOW ORDER WITH 52525
 9063  036646  071002                          DIV     %2,%0           ;DIVIDE BY %2
 9064  036650  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
 9065  036654  122737  000000  025416          CMPB    #0,@#PSWORD     ;IS PS = 0
 9066  036662  001401                          BEQ     11$
 9067  036664  104000                          EMT                     ;PS IS WRONG
 9068  036666  022700  025252          11$:    CMP     #25252,%0       ;IS QUOTIENT = 25252
 9069  036672  001401                          BEQ     12$
 9070  036674  104000                          EMT                     ;QUOTIENT IS WRONG
 9071  036676  022701  000001          12$:    CMP     #1,%0+1         ;IS REMAINDER = 1
 9072  036702  001401                          BEQ     13$
 9073  036704  104000                          EMT                     ;WRONG REMAINDER
```

```
 9074  036706
 9075  036706  005215                    13$:    INC     (R5)
 9076
 9077                                    ;*************************************************************************
 9078                                    ;TEST:301      DIV     0 52525 / (3)+ = 25252       REM = 1      PS = 0
 9079                                    ;*************************************************************************
 9080
 9081  036710                            TST301:
 9082  036710  012700  000000                    MOV     #0,%0           ;LOAD HIGH ORDER WITH 0
 9083  036714  012701  052525                    MOV     #52525,%0+1     ;LOAD LOW ORDER WITH 52525
 9084  036720  071023                            DIV     (3)+,%0         ;DIVIDE BY (3)+
 9085  036722  106737  025416                    MFPS    @#PSWORD        ;SAVE PS
 9086  036726  122737  000000  025416            CMPB    #0,@#PSWORD     ;IS PS = 0
 9087  036734  001401                            BEQ     11$
 9088  036736  104000                            EMT                     ;PS IS WRONG
 9089  036740  022700  025252          11$:      CMP     #25252,%0       ;IS QUOTIENT = 25252
 9090  036744  001401                            BEQ     12$
 9091  036746  104000                            EMT                     ;QUOTIENT IS WRONG
 9092  036750  022701  000001          12$:      CMP     #1,%0+1         ;IS REMAINDER = 1
 9093  036754  001401                            BEQ     13$
 9094  036756  104000                            EMT                     ;WRONG REMAINDER
 9095  036760                          13$:
 9096  036760  005215                            INC     (R5)
 9097
 9098                                    ;*************************************************************************
 9099                                    ;TEST:302      DIV     0 52525 / -(3) = 25252       REM = 1      PS = 0
 9100                                    ;*************************************************************************
 9101
 9102  036762                            TST302:
 9103  036762  012700  000000                    MOV     #0,%0           ;LOAD HIGH ORDER WITH 0
 9104  036766  012701  052525                    MOV     #52525,%0+1     ;LOAD LOW ORDER WITH 52525
 9105  036772  071043                            DIV     -(3),%0         ;DIVIDE BY -(3)
 9106  036774  106737  025416                    MFPS    @#PSWORD        ;SAVE PS
 9107  037000  122737  000000  025416            CMPB    #0,@#PSWORD     ;IS PS = 0
 9108  037006  001401                            BEQ     11$
 9109  037010  104000                            EMT                     ;PS IS WRONG
 9110  037012  022700  025252          11$:      CMP     #25252,%0       ;IS QUOTIENT = 25252
 9111  037016  001401                            BEQ     12$
 9112  037020  104000                            EMT                     ;QUOTIENT IS WRONG
 9113  037022  022701  000001          12$:      CMP     #1,%0+1         ;IS REMAINDER = 1
 9114  037026  001401                            BEQ     13$
 9115  037030  104000                            EMT                     ;WRONG REMAINDER
 9116  037032                          13$:
 9117  037032  005215                            INC     (R5)
 9118
 9119                                    ;*************************************************************************
 9120                                    ;TEST:303      DIV     0 52525 / 2(4) = 25252       REM = 1      PS = 0
 9121                                    ;*************************************************************************
 9122
 9123  037034                            TST303:
 9124  037034  012700  000000                    MOV     #0,%0           ;LOAD HIGH ORDER WITH 0
 9125  037040  012701  052525                    MOV     #52525,%0+1     ;LOAD LOW ORDER WITH 52525
 9126  037044  071064  000002                    DIV     2(4),%0         ;DIVIDE BY 2(4)
 9127  037050  106737  025416                    MFPS    @#PSWORD        ;SAVE PS
 9128  037054  122737  000000  025416            CMPB    #0,@#PSWORD     ;IS PS = 0
 9129  037062  001401                            BEQ     11$
```

```
 9130  037064  104000                          EMT                     ;PS IS WRONG
 9131  037066  022700  025252          11$:    CMP     #25252,%0       ;IS QUOTIENT = 25252
 9132  037072  001401                          BEQ     12$
 9133  037074  104000                          EMT                     ;QUOTIENT IS WRONG
 9134  037076  022701  000001          12$:    CMP     #1,%0+1         ;IS REMAINDER = 1
 9135  037102  001401                          BEQ     13$
 9136  037104  104000                          EMT                     ;WRONG REMAINDER
 9137  037106                          13$:
 9138  037106  005215                          INC     (R5)
 9139
 9140                                  ;*****************************************************************************
 9141                                  ;TEST:304      DIV     0 52525 / @(4) = 25252       REM = 1      PS = 0
 9142                                  ;*****************************************************************************
 9143
 9144  037110                          TST304:
 9145  037110  012700  000000                  MOV     #0,%0           ;LOAD HIGH ORDER WITH 0
 9146  037114  012701  052525                  MOV     #52525,%0+1     ;LOAD LOW ORDER WITH 52525
 9147  037120  071074  000000                  DIV     @(4),%0         ;DIVIDE BY @(4)
 9148  037124  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
 9149  037130  122737  000000  025416          CMPB    #0,@#PSWORD     ;IS PS = 0
 9150  037136  001401                          BEQ     11$
 9151  037140  104000                          EMT                     ;PS IS WRONG
 9152  037142  022700  025252          11$:    CMP     #25252,%0       ;IS QUOTIENT = 25252
 9153  037146  001401                          BEQ     12$
 9154  037150  104000                          EMT                     ;QUOTIENT IS WRONG
 9155  037152  022701  000001          12$:    CMP     #1,%0+1         ;IS REMAINDER = 1
 9156  037156  001401                          BEQ     13$
 9157  037160  104000                          EMT                     ;WRONG REMAINDER
 9158  037162                          13$:
 9159  037162  005215                          INC     (R5)
 9160
 9161                                  ;*****************************************************************************
 9162                                  ;TEST:305      DIV     0 52525 / @(4)+ = 25252      REM = 1      PS = 0
 9163                                  ;*****************************************************************************
 9164
 9165  037164                          TST305:
 9166  037164  012700  000000                  MOV     #0,%0           ;LOAD HIGH ORDER WITH 0
 9167  037170  012701  052525                  MOV     #52525,%0+1     ;LOAD LOW ORDER WITH 52525
 9168  037174  071034                          DIV     @(4)+,%0        ;DIVIDE BY @(4)+
 9169  037176  106737  025416                  MFPS    @#PSWORD        ;SAVE PS
 9170  037202  122737  000000  025416          CMPB    #0,@#PSWORD     ;IS PS = 0
 9171  037210  001401                          BEQ     11$
 9172  037212  104000                          EMT                     ;PS IS WRONG
 9173  037214  022700  025252          11$:    CMP     #25252,%0       ;IS QUOTIENT = 25252
 9174  037220  001401                          BEQ     12$
 9175  037222  104000                          EMT                     ;QUOTIENT IS WRONG
 9176  037224  022701  000001          12$:    CMP     #1,%0+1         ;IS REMAINDER = 1
 9177  037230  001401                          BEQ     13$
 9178  037232  104000                          EMT                     ;WRONG REMAINDER
 9179  037234                          13$:
 9180  037234  005215                          INC     (R5)
 9181
 9182                                  ;*****************************************************************************
 9183                                  ;TEST:306      DIV     0 52525 / @-(4) = 25252      REM = 1      PS = 0
 9184                                  ;*****************************************************************************
 9185
```

```
 9186  037236
 9187  037236  012700  000000            TST306:
 9188  037242  012701  052525                    MOV     #0,%0           ;LOAD HIGH ORDER WITH 0
 9189  037246  071054                            MOV     #52525,%0+1     ;LOAD LOW ORDER WITH 52525
 9190  037250  106737  025416                    DIV     @-(4),%0        ;DIVIDE BY @-(4)
 9191  037254  122737  000000  025416          MFPS    @#PSWORD        ;SAVE PS
 9192  037262  001401                            CMPB    #0,@#PSWORD     ;IS PS = 0
 9193  037264  104000                            BEQ     11$
 9194  037266  022700  025252                    EMT                     ;PS IS WRONG
 9195  037272  001401                    11$:    CMP     #25252,%0       ;IS QUOTIENT = 25252
 9196  037274  104000                            BEQ     12$
 9197  037276  022701  000001                    EMT                     ;QUOTIENT IS WRONG
 9198  037302  001401                    12$:    CMP     #1,%0+1         ;IS REMAINDER = 1
 9199  037304  104000                            BEQ     13$
 9200  037306                                    EMT                     ;WRONG REMAINDER
 9201  037306  005215                    13$:
 9202                                            INC     (R5)
 9203
 9204
 9205                                    ;SPECIAL MULTIPLY DATA PATTERN TEST
 9206
 9207  037310  012701  177777            TSTSPC: MOV     #-1,R1          ;MAKE R1 -1 SO WE KNOW INSTR. WAS MODIFIER
 9208  037314  012700  077700                    MOV     #77700,R0       ;SET UP TEST DATA
 9209  037320  070027  000001                    MUL     #1,R0           ;DO MULTIPLY INSTRUCTION
 9210  037324  022701  077700                    CMP     #77700,R1       ;CHECK LOW ORDER WORD
 9211  037330  001401                            BEQ     1$
 9212  037332  104000                            EMT                     ;LOW ORDER PRODUCT ERROR
 9213  037334  005700                    1$:     TST     R0              ;CHECK HIGH ORDER WORD
 9214  037336  001401                            BEQ     EISEND
 9215  037340  104000                            EMT                     ;HIGH ORDER PRODUCT ERROR
 9216  037342  000167  000026            EISEND: JMP     MMUTST          ;JMP OVER GARBAGE AND GET TO MMU TEST
```

```
                                .SBTTL  MEMORY MANAGEMENT DEFINITIONS

                                ;*KT11 VECTOR ADDRESS

000250                          MMVEC=  250

                                ;*KT11 STATUS REGISTER ADDRESSES

177572                          SR0=    177572
177574                          SR1=    177574
177576                          SR2=    177576
172516                          SR3=    172516

                                ;*USER "I" PAGE DESCRIPTOR REGISTERS

177600                          UIPDR0= 177600
177602                          UIPDR1= 177602
177604                          UIPDR2= 177604
177606                          UIPDR3= 177606
177610                          UIPDR4= 177610
177612                          UIPDR5= 177612
177614                          UIPDR6= 177614
177616                          UIPDR7= 177616

                                ;*USER "I" PAGE ADDRESS REGISTERS

177640                          UIPAR0= 177640
177642                          UIPAR1= 177642
177644                          UIPAR2= 177644
177646                          UIPAR3= 177646
177650                          UIPAR4= 177650
177652                          UIPAR5= 177652
177654                          UIPAR6= 177654
177656                          UIPAR7= 177656

                                ;*KERNEL "I" PAGE DESCRIPTOR REGISTERS

172300                          KIPDR0= 172300
172302                          KIPDR1= 172302
172304                          KIPDR2= 172304
172306                          KIPDR3= 172306
172310                          KIPDR4= 172310
172312                          KIPDR5= 172312
172314                          KIPDR6= 172314
172316                          KIPDR7= 172316

                                ;*KERNEL "I" PAGE ADDRESS REGISTERS

172340                          KIPAR0= 172340
172342                          KIPAR1= 172342
172344                          KIPAR2= 172344
172346                          KIPAR3= 172346
172350                          KIPAR4= 172350
172352                          KIPAR5= 172352
172354                          KIPAR6= 172354
```

```
 9273            172356          KIPAR7= 172356
 9274
 9275            000006          KSP=    SP
 9276            000006          USP=    SP
 9277            177776          PSW=    PS
 9278            000020          TBIT=   20
 9279            000100          WPIT=   100
 9280            000001          BIT0=   1
 9281            000004          ERRVEC= 4
 9282
 9283                            ;*ADDITIONAL DEFINITIONS
 9284                            ;*
 9285
 9286
 9287
 9288  037346    000000          WASR6:  .WORD   0       ;USED TO STORE THE STACK POINTER AFTER A TRAP
 9289  037350    000000          TRAPPC: .WORD   0       ;USED TO STORE THE PC OF A TRAP OR ABORT
 9290  037352    000000          TRAPPS: .WORD   0       ;USED TO STORE THE PS OF A TRAP OR ABORT
 9291  037354    000000          WASSR0: .WORD   0       ;USED TO STORE CONTENTS OF SR0
 9292  037356    000000          WASSR2: .WORD   0       ;USED TO STORE CONTENTS OR SR2
 9293  037360    000000          TBITPS: .WORD   0       ;SAVES THE PSW THAT MAY HAVE ITS T-BIT ON
 9294  037362    000000          $TMP0:  .WORD   0       ;TEMPORARY STORAGE LOCATION
 9295  037364    000000          $TMP1:  .WORD   0       ;TEMPORARY STORAGE LOCATION
 9296  037366    000000          $TMP2:  .WORD   0       ;TEMPORARY STORAGE LOCATION
 9297  037370    000000          $TMP3:  .WORD   0       ;TEMPORARY STORAGE LOCATION
 9298  037372    000000          $TMP4:  .WORD   0       ;TEMPORARY STORAGE LOCATION
 9299
 9300
```

```
 9301
 9302  037374  012706  001000          MMUTST: MOV     #STBOT,KSP      ;INITIALIZE THE STACK POINTER
 9303  037400  012767  021276  140642          MOV     #TO250,MMVEC    ;LOAD MEMORY MANAGENT ROUTINE INTO VECTOR
 9304  037406  012767  000340  140636          MOV     #340,MMVEC+2    ;SET NEW PS TO PRIORITY LEVEL 7-KERNEL
 9305  037414  012767  000340  177736          MOV     #340,TBITPS     ;INITIALIZE LOG THAT HOLDS T-BIT PSW
 9306  037422  005067  140144                  CLR     SR0             ;BE SURE MEM. MGMT IS OFF TO START WITH
 9307  037426  032777  000001  161670          BIT     #1,@SWR
 9308  037434  001402                          BEQ     1$
 9309  037436  000167  011060                  JMP     FPSTRT
 9310  037442  012737  050452  000030  1$:     MOV     #ERROR3,@#30    ;SET UP EMT VECTOR TO GO TO RIGHT ERROR CALL
 9311  037450  012737  000002  001004          MOV     #2,@#$TESTN     ;INCREMENT TEST NUMBER
 9312
```

```
 9313
 9314
 9315                    ;*****************************************************************************************
 9316                    ;TEST 351       PSW PRIORITY BIT TEST
 9317                    ;*****************************************************************************************
 9318  037456            TS351:
 9319  037456  005000            CLR     R0              ;INITIALIZE R0 WITH PRIORITY=0 DATA
 9320  037460  005001    2$:     CLR     R1              ;PREPARE R1 TO ACCEPT DATA READ
 9321  037462  106400            MTPS    R0              ;WRITE PRIORITY BITS IN THE PSW
 9322  037464  106701            MFPS    R1              ;READ BACK THE LOW BYTE OF PSW
 9323  037466  042701  177437    BIC     #177437,R1      ;MASK OFF EVERYTHING EXCEPT PRIORITY BITS
 9324  037472  020001            CMP     R0,R1           ;WAS CORRECT PRIORITY SET IN THE PSW?
 9325  037474  001401            BEQ     3$
 9326  037476  104000            EMT                     ;PRIORITY BITS SET WRONG IN PSW
 9327                                                    ;FOR TIGHTER SCOPE LOOP
 9328                                                    ;REPLACE ERROR CALL WITH
 9329                                                    ;"BR 2$" = 000770
 9330  037500  062700  000040    3$:     ADD     #40,R0          ;CHANGE DATA TO NEXT PRIORITY
 9331  037504  022700  000400            CMP     #400,R0         ;HAVE PRIORITIES 0-7 ALL BEEN CHECKED?
 9332  037510  001363            BNE     2$              ;BRANCH IF NO
 9333
 9334                    ;*****************************************************************************************
 9335                    ;TEST 352       PSW MODE BIT TEST
 9336                    ;*****************************************************************************************
 9337  037512            TS352:
 9338  037512  005000            CLR     R0              ;INITIALIZE R0 WITH MODE BITS = 0000
 9339  037514  005067  140256    2$:     CLR     PSW             ;INITIALIZE PSW
 9340  037520  050067  140252            BIS     R0,PSW          ;BIT SET THE PSW MODE BITS WITH R0
 9341  037524  016701  140246            MOV     PSW,R1          ;READ BACK THE CONTENTS OF THE PSW
 9342  037530  042701  007777            BIC     #007777,R1      ;MASK OFF EVERYTHING EXCEPT THE MODE BITS
 9343  037534  020001            CMP     R0,R1           ;WERE THE MODE BITS SET CORRECTLY?
 9344  037536  001401            BEQ     3$
 9345  037540  104000            EMT                     ;MODE BITS SET WRONG IN PSW
 9346                                                    ;FOR TIGHTER SCOPE LOOP
 9347                                                    ;REPLACE ERROR CALL WITH
 9348                                                    ;"BR 2$" = 000763
 9349  037542  062700  010000    3$:     ADD     #10000,R0       ;CHANGE MODE BIT DATA
 9350  037546  001362            BNE     2$              ;BRANCH IF STILL MORE COMBINATIONS
 9351  037550  005067  140222            CLR     PSW             ;RESET PSW BEFORE LEAVING
 9352
 9353                    ;*****************************************************************************************
 9354                    ;TEST 353       BYTE ADDRESSING TEST FOR PSW
 9355                    ;*****************************************************************************************
 9356  037554            TS353:
 9357  037554  005067  140216    2$:     CLR     PSW             ;CLEAR THE PSW
 9358  037560  012700  000360            MOV     #360,R0         ;PUT THE HIGH BYTE DATA INTO R0
 9359  037564  110067  140207            MOVB    R0,PSW+1        ;WRITE THE HIGH BYTE OF THE PSW
 9360  037570  016701  140202            MOV     PSW,R1          ;READ BACK THE ENTIRE PSW
 9361  037574  042701  007437            BIC     #007437,R1      ;MASK OFF THE T & CC BITS
 9362  037600  000300            SWAB    R0              ;GET DATA WRITTEN IN HIGH BYTE OF R0
 9363  037602  020001            CMP     R0,R1           ;WAS THE PSW WRITTEN TO CORRECTLY
 9364  037604  001401            BEQ     4$
 9365  037606  104000            EMT                     ;LOW BYTE EFFECTED BY WRITE TO HIGH BYTE OF PSW
 9366                                                    ;FOR TIGHTER SCOPE LOOP
 9367                                                    ;REPLACE ERROR CALL WITH
 9368                                                    ;"BR 2$" = 000760
```

```
 9369  037610  005067  140162          4$:     CLR     PSW             ;CLEAR THE PSW
 9370  037614  012700  000340                  MOV     #340,R0         ;PUT THE LOW BYTE DATA INTO R0
 9371  037620  110067  140152                  MOVB    R0,PSW          ;WRITE THE LOW BYTE OF THE PSW
 9372  037624  016701  140146                  MOV     PSW,R1          ;READ BACK THE ENTIRE PSW
 9373  037630  042701  007437                  BIC     #007437,R1      ;MASK OFF THE T&CC BITS
 9374  037634  020001                          CMP     R0,R1           ;WAS PSW WRITTEN TO CORRECTLY
 9375  037636  001401                          BEQ     TS354
 9376  037640  104000                          EMT                     ;HIGH BYTE EFFECTED BY WRITE TO LOW BYTE OF PSW
 9377                                                                  ;FOR TIGHTER SCOPE LOOP
 9378                                                                  ;REPLACE ERROR CALL WITH
 9379                                                                  ;''BR 2$'' = 000736
 9380
 9381                                  ;*****************************************************************************
 9382                                  ;TEST 354       TEST AND SETUP OF STACK POINTERS
 9383                                  ;*****************************************************************************
 9384  037642                          TS354:
 9385  037642  005067  140130                  CLR     PSW             ;GO TO KERNEL MODE
 9386  037646  012706  001000                  MOV     #KERSTK,KSP     ;SET KERNEL STACK POINTER TO 1100
 9387  037652  012767  140000  140116          MOV     #140000,PSW     ;GO TO USER MODE
 9388  037660  012706  000600                  MOV     #USESTK,USP     ;SET USER STACK POINTER TO 700
 9389  037664  005067  140106                  CLR     PSW             ;BACK TO KERNEL MODE
 9390  037670  022706  001000                  CMP     #KERSTK,KSP     ;IS KERNEL R6 STILL 1100?
 9391  037674  001401                          BEQ     TS355
 9392  037676  104000                          EMT                     ;KERNEL R6 CHANGED BY WRITING USER R6
 9393                                                                  ;FOR TIGHTER SCOPE LOOP
 9394                                                                  ;REPLACE ERROR CALL WITH
 9395                                                                  ;000756
 9396
 9397                                  ;*****************************************************************************
 9398                                  ;*
 9399                                  ;*      THE NEXT FIVE (5) TESTS WILL TRY TO ADDRESS ALL OF THE
 9400                                  ;*      MEMORY MANAGEMENT REGISTERS (SR0,SR1,SR2,KERNEL & USER PAR/PDR'S).
 9401                                  ;*      EVERY TIME A REGISTER TIMES OUT ITS ADDRESS WILL BE REPORTED.
 9402                                  ;*      AT THE END OF EACH TEST A SUMMARY OF THE ADDRESSES THAT TIMED
 9403                                  ;*      OUT DURING THAT TEST IS GIVEN.  THE RESULTS OF ''AND-ING'' AND ''OR-ING''
 9404                                  ;*      THEIR ADDRESSES IS GIVEN TO SHOW WHICH ADDRESS LINES MAY BE
 9405                                  ;*      STUCK AT 0 OR 1.  THE PAR/PDR ADDRESS AND KT MUX'S ARE THE
 9406                                  ;*      THINGS BEING CHECKED.
 9407                                  ;*
 9408                                  ;*****************************************************************************
 9409
 9410
 9411                                  ;*****************************************************************************
 9412                                  ;TEST 355       SR0,SR1,SR2,SR3 TIMEOUT TEST
 9413                                  ;*****************************************************************************
 9414  037700                          TS355:
 9415  037700  012700  177572                  MOV     #SR0,R0         ;LOAD R0 WITH ADDRESS OF FIRST REG.
 9416  037704  012701  000003                  MOV     #3,R1           ;LOAD R1 WITH THE LOOP COUNT
 9417  037710  005710                  2$:     TST     (R0)            ;TRY ADDRESSING A STATUS REGISTER
 9418                                                                  ;IF IT TIMES OUT GO TO 5$
 9419  037712  062700  000002          3$:     ADD     #2,R0           ;PUT NEXT ADDRESS IN R0
 9420  037716  077104                          SOB     R1,2$           ;LOOP BACK TO 2$ UNTIL ALL TESTED
 9421  037720  005737  172516                  TST     @#172516        ;CHECK SR3 FOR RESPONSE
 9422
 9423                                  ;*****************************************************************************
 9424                                  ;TEST 356       KERNEL PAR'S TIMEOUT TEST
```

```
                                ;*****************************************************************************
037724                          TS356:
                                
037724  012700  172340                MOV     #KIPAR0,R0      ;LOAD R0 WITH ADDRESS OF FIRST REG.
037730  012701  000010                MOV     #10,R1          ;LOAD R1 WITH LOOP COUNT (8)
037734  005710          2$:           TST     (R0)            ;TRY ADDRESSING A KIPAR
                                                              ;IF IT TIMES OUT, WILL GO TO 5$
037736  062700  000002          3$:   ADD     #2,R0           ;PUT NEXT KIPAR ADDRESS IN R0
037742  077104                        SOB     R1,2$           ;LOOP BACK TO 2$ UNTIL ALL TESTED
                                
                                ;*****************************************************************************
                                ;TEST 357       KERNEL PDR'S TIMEOUT TEST
                                ;*****************************************************************************
037744                          TS357:
                                
037744  012700  172300                MOV     #KIPDR0,R0      ;LOAD R0 WITH ADDRESS OF FIRST REG.
037750  012701  000010                MOV     #10,R1          ;LOAD R1 WITH LOOP COUNT (8)
037754  005710          2$:           TST     (R0)            ;TRY ADDRESSING A KIPDR
                                                              ;IF IT TIMES OUT, WILL GO TO 5$
037756  062700  000002          3$:   ADD     #2,R0           ;PUT NEXT KIPDR ADDRESS IN R0
037762  077104                        SOB     R1,2$           ;LOOP BACK TO 2$ UNTIL ALL TESTED
                                
                                ;*****************************************************************************
                                ;TEST 360       USER PAR'S TIMEOUT TEST
                                ;*****************************************************************************
037764                          TS360:
                                
037764  012700  177640                MOV     #UIPAR0,R0      ;LOAD R0 WITH ADDRESS OF FIRST REG.
037770  012701  000010                MOV     #10,R1          ;LOAD R1 WITH LOOP COUNT (8)
037774  005710          2$:           TST     (R0)            ;TRY ADDRESSING A UIPAR
                                                              ;IF IT TIMES OUT, WILL GO TO 5$
037776  062700  000002          3$:   ADD     #2,R0           ;PUT NEXT UIPAR ADDRESS IN R0
040002  077104                        SOB     R1,2$           ;LOOP BACK TO 2$ UNTIL ALL TESTED
                                
                                ;*****************************************************************************
                                ;TEST 361       USER PDR'S TIMEOUT TEST
                                ;*****************************************************************************
040004                          TS361:
                                
040004  012700  177600                MOV     #UIPDR0,R0      ;LOAD R0 WITH ADDRESS OF FIRST REG.
040010  012701  000010                MOV     #10,R1          ;LOAD R1 WITH LOOP COUNT (8)
040014  005710          2$:           TST     (R0)            ;TRY ADDRESSING A UIPDR
                                                              ;IF IT TIMES OUT, WILL GO TO 5$
040016  062700  000002          3$:   ADD     #2,R0           ;PUT NEXT UIPDR ADDRESS IN R0
040022  077104                        SOB     R1,2$           ;LOOP BACK TO 2$ UNTIL ALL TESTED
                                
                                ;*****************************************************************************
                                ;TEST 362       SR0(15:13) BIT TEST & SR2 TEST
                                ;*****************************************************************************
040024                          TS362:
                                
040024  012700  177572  1$:           MOV     #SR0,R0         ;LOAD ADDRESS OF SR0 INTO R0
040030  012710  160000                MOV     #160000,(R0)    ;SET BITS <15:13> IN SR0 (ERROR BITS)
040034  000005                        RESET                   ;ISSUE AND "INIT" SIGNAL
040036  011001                        MOV     (R0),R1         ;READ SR0 INTO R1 TO SEE IF CLEAR
040040  001401                        BEQ     2$
```

```
                                        EMT                     ;SR0<15:13> NOT CLEARED BY A "RESET"
                                                                ;FOR TIGHTER SCOPE LOOP
                                                                ;REPLACE ERROR CALL WITH
                                                                ;"BR 1$" = 000770
040044  016767  137526  177304  2$:   MOV     SR2,WASSR2        ;READ CONTENTS OF SR2
040052  012701  040044            MOV     #2$,R1            ;LOAD EXPECTED CONTENTS INTO R1
040056  020167  177274            CMP     R1,WASSR2         ;IS SR2 TRACKING?
040062  001401                    BEQ     3$
040064  104000                    EMT                       ;SR2 NOT "TRACKING" VIRTUAL ADDRESSES
                                                          ;FOR TIGHTER SCOPE LOOP
                                                          ;REPLACE ERROR CALL WITH
                                                          ;"BR 2$" = 000767
040066  012701  100000    3$:     MOV     #100000,R1        ;PUT DATA TO BE WRITTEN IN R1
040072  012703  000003            MOV     #3,R3             ;SETUP R3 AS A LOOP COUNTER
040076  005010            4$:     CLR     (R0)              ;CLEAR SR0
040100  050110            5$:     BIS     R1,(R0)           ;SET ONE OF THE ERROR BITS IN SR0
040102  011002                    MOV     (R0),R2           ;READ SR0 INTO R2
040104  020102                    CMP     R1,R2             ;DID RIGHT ERROR BIT GET SET?
040106  001401                    BEQ     6$
040110  104000                    EMT                       ;BITS WERE SET WRONG IN SR0
                                                          ;FOR TIGHTER SCOPE LOOP
                                                          ;REPLACE ERROR CALL WITH
                                                          ;"BR 4$" = 000772
040112  012704  040100    6$:     MOV     #5$,R4            ;LOAD EXPECTED CONTENTS OF SR2 IN R4
040116  016767  137454  177232    MOV     SR2,WASSR2        ;READ SR2
040124  020467  177226            CMP     R4,WASSR2         ;DID SR2 LOCK UP WHEN ERROR
                                                          ;BIT SET IN SR1?
040130  001401                    BEQ     7$
040132  104000                    EMT                       ;SR2 DID NOT LOCK UP
                                                          ;FOR TIGHTER SCOPE LOOP
                                                          ;REPLACE ERROR CALL WITH
                                                          ;"BR 4$" = 000761
040134  006001            7$:     ROR     R1                ;CHANGE DATA TO CHECK NEXT ERROR BIT
040136  077321                    SOB     R3,4$             ;LOOP BACK UNTIL <15:13> ALL TESTED
040140  005010                    CLR     (R0)              ;CLEAR SR0 BEFORE LEAVING

                        ;*****************************************************************************
                        ;TEST 363       SR0 & PSW DUAL ADDRESSING TEST
                        ;*****************************************************************************
040142                  TS363:

040142  005067  137630    1$:     CLR     PSW               ;CLEAR THE PSW
040146  005067  137420            CLR     SR0               ;CLEAR STATUS REGISTER 0
040152  106427  000340            MTPS    #340              ;SET PRIORITY 7 IN LOW BYTE OF PSW
040156  016700  137410            MOV     SR0,R0            ;READ STATUS REGISTER 0
040162  001401                    BEQ     2$
040164  104000                    EMT                       ;SR0 EFFECTED BY A WRITE TO THE PSW
                                                          ;FOR TIGHTER SCOPE LOOP
                                                          ;REPLACE ERROR CALL WITH
                                                          ;"BR 1$" = 000767
040166  005067  137400    2$:     CLR     SR0               ;BE SURE SR0 IS 0 BEFORE LEAVING
040172  005067  137600            CLR     PSW               ;BE SURE PSW IS 0 BEFORE LEAVING

                        ;*****************************************************************************
                        ;TEST 364       TEST THAT SR1 READS ALL ZEROS
                        ;*****************************************************************************
```

```
                                TS364:
040176                          1$:     MOV     #-1,R0          ;FILL R0 WITH ALL ONES
040176  012700  177777          
040202  016700  137366                  MOV     SR1,R0          ;READ SR1 INTO R0
040206  001401                          BEQ     2$
040210  104000                          EMT                     ;SR1 DID NOT READ ALL ZEROS
                                                                ;FOR TIGHTER SCOPE LOOP
                                                                ;REPLACE ERROR CALL WITH
                                                                ;000772
040212  012767  177777  132276  2$:     MOV     #-1,SR3         ;TRY TO WRITE ONES TO SR3
040220  022767  000060  132270          CMP     #60,SR3         ;ONLY BITS <5:4> SHOULD BE ONES
040226  001401                          BEQ     3$
040230  104000                          EMT                     ;DIDN'T READ BACK A "60"
040232  004567  010170          3$:     JSR     R5,CHKAPT
040236  000402                          BR      90$
040240  000005                          RESET                   ;CLEARS SR3
040242  000402                          BR      91$
040244  005067  132246          90$:    CLR     SR3
040250  005767  132242          91$:    TST     SR3             ;VERIFY THAT IT WAS CLEARED
040254                          4$:
040254  001401                          BEQ     TS365
040256  104000                          EMT                     ;SR3 DIDN'T READ ALL ZEROS


                                ;NOTE   F11 CHANGES INCLUDED CHECKING ALL BITS<15:0> OF PARS
                                ;       INSTEAD OF ONLY BITS<11:0>.

                                ;*******************************************************************************
                                ;TEST 365       BIT TEST OF KERNEL & USER PAR'S
                                ;*******************************************************************************
040260                          TS365:

040260  012700  172340          1$:     MOV     #KIPAR0,R0      ;LOAD ADDRESS OF FIRST PAR IN R0
040264  012703  000010          2$:     MOV     #10,R3          ;SETUP R3 TO COUNT 8 PAR'S
040270  005010                  3$:     CLR     (R0)            ;CLEAR THE PAR
040272  011001                          MOV     (R0),R1         ;READ THE PAR INTO R1
040274  001401                          BEQ     4$
040276  104000                          EMT                     ;PAR WOULD NOT CLEAR
                                                                ;FOR TIGHTER SCOPE LOOP
                                                                ;REPLACE ERROR CALL WITH
                                                                ;"BR 3$" = 000774
040300  012704  077777          4$:     MOV     #077777,R4      ;LOAD "WALKING 0" TEST PATTERN IN R4
040304  005010                  5$:     CLR     (R0)            ;CLEAR THE PAR BEFORE LOADING DATA
040306  050410                          BIS     R4,(R0)         ;BIT SET THE TEST PATTERN INTO THE PAR
040310  011002                          MOV     (R0),R2         ;READ THE PAR INTO R2
040312  020402                          CMP     R4,R2           ;DOES DATA WRITTEN=DATA READ?
040314  001401                          BEQ     6$
040316  104000                          EMT                     ;PAR BITS DID NOT SET CORRECTLY
                                                                ;FOR TIGHTER SCOPE LOOP
                                                                ;REPLACE ERROR CALL WITH
                                                                ;"BR 5$" = 000767
040320  000261                  6$:     SEC                     ;SET THE C-BIT FOR THE ROTATE INST.
040322  006004                          ROR     R4              ;ROTATE THE TEST PATTERN IN R4
040324  103767                          BCS     5$              ;BRANCH BACK IF MORE BITS TO TEST
040326  062700  000002                  ADD     #2,R0           ;GET NEXT PAR ADDRESS IN R0
040332  077322                          SOB     R3,3$           ;BRANCH BACK UNTIL ALL PAR'S TESTED
040334  022700  177660                  CMP     #UIPAR7+2,R0    ;HAVE USER PAR'S BEEN TESTED
```

```
                        BHIS    TS366           ;GET TO NEXT TEST
                        MOV     #UIPAR0,R0      ;LOAD FIRST USER PAR ADDR. IN R0
                        BR      2$              ;BRANCH BACK TO TEST USER PAR'S
                                                ;LEAVE TEST WITH BITS <11:1>=1 IN ALL PAR'S
                ;*****************************************************************************
                ;TEST 366       BIT TEST OF KERNEL & USER PDR'S
                ;*****************************************************************************
                TS366:

                1$:     MOV     #KIPDR0,R0      ;LOAD ADDRESS OF FIRST PDR IN R0
                2$:     MOV     #10,R3          ;SETUP R3 TO COUNT 8 PDR'S
                3$:     CLR     (R0)            ;CLEAR THE PDR
                        MOV     (R0),R1         ;READ THE PDR INTO R1
                        BEQ     4$
                        EMT                     ;PDR WOULD NOT CLEAR
                                                ;FOR TIGHTER SCOPE LOOP
                                                ;REPLACE ERROR CALL WITH
                                                ;"BR 3$" = 000774
                4$:     MOV     #077777,R4      ;LOAD "WALKING "0" TEST PATTERN IN R4
                5$:     CLR     (R0)            ;CLEAR THE PDR BEFORE LOADING DATA
                        MOV     R4,R1           ;LOAD DATA INTO R1
                        BIC     #100361,R1      ;MASK UNUSED BITS OUT OF THE DATA
                        BIS     R1,(R0)         ;BIT SET THE TEST PATTERN INTO THE PDR
                        MOV     (R0),R2         ;READ THE PDR INTO R2
                        CMP     R1,R2           ;DOES DATA WRITTEN=DATA READ?
                        BEQ     6$
                        EMT                     ;PDR BITS DID NOT SET CORRECTLY
                                                ;FOR TIGHTER SCOPE LOOP
                                                ;REPLACE ERROR CALL WITH
                                                ;"BR 5$" = 000767
                6$:     SEC                     ;SET THE C-BIT FOR THE ROTATE INST.
                        ROR     R4              ;ROTATE THE TEST PATTERN IN R4
                        BCS     5$              ;BRANCH BACK IF MORE BITS TO TEST
                        ADD     #2,R0           ;GET NEXT PDR ADDRESS IN R0
                        SOB     R3,3$           ;BRANCH BACK UNTIL ALL PDR'S TESTED
                        CMP     #UIPDR7+2,R0    ;HAVE USER PDR'S BEEN TESTED?
                        BHIS    TS367           ;GET TO NEXT TEST
                        MOV     #UIPDR0,R0      ;LOAD FIRST USER PDR ADDR. IN R0
                        BR      2$              ;BRANCH BACK TO TEST USER PDR'S
                                                ;LEAVE TEST WITH ALL WRITEABLE BITS IN
                                                ;ALL PDR'S = 1


                ;*****************************************************************************
                ;TEST 367       TEST FOR DUAL BYTE ADDRESSING OF KERNEL & USER PAR'S
                ;*****************************************************************************
                TS367:

                1$:     MOV     #KIPAR0,R0      ;LOAD ADDRESS OF FIRST PAR INTO R0
                        MOV     #10,R3          ;LOAD LOOP COUNTER TO DO 8 PAR'S
                3$:     MOV     #-1,R1          ;LOAD TEST PATTERN INTO R1
                        CLR     (R0)            ;CLEAR THE PAR
                        MOVB    R1,(R0)         ;WRITE 1'S TO THE LOW BYTE OF THE PAR
                        MOV     (R0),R2         ;READ THE ENTIRE PAR INTO R2
                        BIC     #177400,R1      ;MASK HIGH BYTE & UNUSED BITS OUT OF THE DATA
                        CMP     R1,R2           ;WAS ONLY THE LOW BYTE WRITTEN TO
                        BEQ     5$
```

```
9649  040500  104000                    EMT                     ;HIGH BYTE EFFECTED BY WRITING LOW BYTE IN PAR
9650                                                              ;FOR TIGHTER SCOPE LOOP
9651                                                              ;REPLACE ERROR CALL WITH
9652                                                              ;"BR 3$" = 000766
9653  040502  005010            5$:     CLR     (R0)            ;CLEAR THE PAR
9654  040504  012701  177777            MOV     #-1,R1          ;LOAD TEST, PATTERN INTO R1
9655  040510  110160  000001            MOVB    R1,1(R0)        ;WRITE 1'S TO THE HIGH BYTE OF THE PAR
9656  040514  011002                    MOV     (R0),R2         ;READ THE ENTIRE PAR INTO R2
9657                                                              ;F11 CHANGE     WAS #170377
9658  040516  042701  000377            BIC     #000377,R1      ;MASK LOW BYTE & UNUSED BITS OUT OF DATA
9659  040522  020102                    CMP     R1,R2           ;WAS ONLY THE HIGH BYTE WRITTEN TO?
9660  040524  001401                    BEQ     6$
9661  040526  104000                    EMT                     ;LOW BYTE EFFECTED BY WRITING HIGH BYTE IN PAR
9662                                                              ;FOR TIGHTER SCOPE LOOP
9663                                                              ;REPLACE ERROR CALL WITH
9664                                                              ;"BR 5" = 000765
9665  040530  062700  000002    6$:     ADD     #2,R0           ;PUT ADDRESS OF NEXT PAR IN R0
9666  040534  077330                    SOB     R3,3$           ;BRANCH BACK UNTIL 8 PAR'S TESTED
9667  040536  022700  177660            CMP     #UIPAR7+2,R0    ;HAVE USER PAR'S BEEN TESTED
9668  040542  103003                    BHIS    TS370           ;GET TO NEXT TEST
9669  040544  012700  177640            MOV     #UIPAR0,R0      ;LOAD ADDRESS OF FIRST USER PAR IN R0
9670  040550  000742                    BR      3$              ;BRANCH BACK TO TEST USER PAR'S
9671
9672                                    ;*************************************************************************
9673                                    ;TEST 370       TEST FOR DUAL BYTE ADDRESSING OF KERNEL & USER PDR'S
9674                                    ;*************************************************************************
9675  040552                    TS370:
9676
9677  040552  012700  172300    1$:     MOV     #KIPDR0,R0      ;LOAD ADDRESS OF FIRST PDR INTO R0
9678  040556  012703  000010            MOV     #10,R3          ;LOAD LOOP COUNTER TO DO 8 PDR'S
9679  040562  012701  177777    3$:     MOV     #-1,R1          ;LOAD TEST PATTERN INTO R1
9680  040566  005010                    CLR     (R0)            ;CLEAR THE PDR
9681  040570  110110                    MOVB    R1,(R0)         ;WRITE 1'S TO THE LOW BYTE OF THE PDR
9682  040572  011002                    MOV     (R0),R2         ;READ THE ENTIRE PDR INTO R2
9683  040574  042701  177761            BIC     #177761,R1      ;MASK HIGH BYTE & UNUSED BITS OUT OF DATA
9684  040600  020102                    CMP     R1,R2           ;WAS ONLY THE LOW BYTE WRITTEN TO?
9685  040602  001401                    BEQ     5$
9686  040604  104000                    EMT                     ;HIGH BYTE EFFECTED BY WRITING LOW BYTE IN PDR
9687                                                              ;FOR TIGHTER SCOPE LOOP
9688                                                              ;REPLACE ERROR CALL WITH
9689                                                              ;"BR 3$" = 000766
9690  040606  005010            5$:     CLR     (R0)            ;CLEAR THE PDR
9691  040610  012701  177777            MOV     #-1,R1          ;LOAD TEST PATTERN INTO R1
9692  040614  110160  000001            MOVB    R1,1(R0)        ;WRITE 1'S TO THE HIGH BYTE OF THE PDR
9693  040620  011002                    MOV     (R0),R2         ;READ THE ENTIRE PDR INTO R2
9694  040622  042701  100377            BIC     #100377,R1      ;MASK LOW BYTE & UNUSED BITS OUT OF DATA
9695  040626  020102                    CMP     R1,R2           ;WAS ONLY THE HIGH BYTE WRITTEN TO?
9696  040630  001401                    BEQ     6$
9697  040632  104000                    EMT                     ;LOW BYTE EFFECTED BY WRITING HIGH BYTE IN PDR
9698                                                              ;FOR TIGHTER SCOPE LOOP
9699                                                              ;REPLACE ERROR CALL WITH
9700                                                              ;"BR 5$" = 000765
9701  040634  062700  000002    6$:     ADD     #2,R0           ;PUT ADDRESS OF NEXT PDR IN R0
9702  040640  077330                    SOB     R3,3$           ;BRANCH BACK UNTIL 8 PDR'S TESTED
9703  040642  022700  177620            CMP     #UIPDR7+2,R0    ;HAVE USER PDR'S BEEN TESTED?
9704  040646  103003                    BHIS    TS371           ;GET TO NEXT TEST
```

```
                        MOV     #UIPDR0,R0      ;LOAD ADDRESS OF FIRST USER PDR IN R0
                        BR      3$              ;BRANCH BACK TO TEST USER PDR'S

;*****************************************************************************************
;TEST 371       PAR-PDR DUAL ADDRESSING TEST
;*****************************************************************************************
TS371:

                        MOV     #10,R3          ;LOAD LOOP COUNTER WITH AN 8
                        MOV     #KIPDR0,R0      ;LOAD ADDRESS OF FIRST KERNEL PDR AND R0
                        JSR     PC,SETREG       ;SET ALL BITS IN ALL PAR'S IN PDR'S
2$:                     MOV     #KERSTK,KSP     ;SETUP STACK POINTER
                        CLR     (R0)            ;CLEAR ONE OF THE KERNEL PDR'S
                        JSR     PC,CMPREG       ;SEE IF OTHER PAR/PDR'S WERE EFFECTED
                        MOV     #-1,(R0)+       ;RESTORE ALL ONES, AND SETUP FOR NEXT PDR
                        SOB     R3,2$           ;LOOP TO 2$ UNTIL ALL KERNEL PDR'S CHECKED
                        MOV     #10,R3          ;LOAD LOOP COUNTER WITH AN 8
                        MOV     #KIPAR0,R0      ;LOAD ADDRESS OF FIRST KERNEL PAR IN R0
3$:                     MOV     #KERSTK,KSP     ;SETUP STACK POINTER
                        CLR     (R0)            ;CLEAR ONE OF THE KERNEL PAR'S
                        JSR     PC,CMPREG       ;SEE IF OTHER PAR/PDR'S WERE EFFECTED
                        MOV     #-1,(R0)+       ;RESTORE ALL ONES, AND SETUP FOR NEXT PAR
                        SOB     R3,3$           ;LOOP TO 3$ UNTIL ALL KERNEL PAR'S CHECKED
                        MOV     #10,R3          ;LOAD LOOP COUNTER WITH AN 8
                        MOV     #UIPDR0,R0      ;LOAD ADDRESS OF FIRST USER PDR IN R0
4$:                     MOV     #KERSTK,KSP     ;SETUP STACK POINTER
                        CLR     (R0)            ;CLEAR ONE OF THE USER PDR'S
                        JSR     PC,CMPREG       ;SEE IF OTHER PAR/PDR'S WERE EFFECTED
                        MOV     #-1,(R0)+       ;RESTORE ALL ONES, AND SETUP FOR NEXT UPDR
                        SOB     R3,4$           ;LOOP TO 4$ UNTIL ALL USER PDR'S CHECKED
                        MOV     #10,R3          ;LOAD LOOP COUNTER WITH AN 8
                        MOV     #UIPAR0,R0      ;LOAD ADDRESS OF FIRST USER PAR IN R0
5$:                     MOV     #KERSTK,KSP     ;SETUP STACK POINTER
                        CLR     (R0)            ;CLEAR ONE OF THE USER PAR'S
                        JSR     PC,CMPREG       ;SEE IF OTHER PAR/PDR'S WERE EFFECTED
                        MOV     #-1,(R0)+       ;RESTORE ALL ONES, AND SETUP FOR NEXT UPAR
                        SOB     R3,5$           ;LOOP TO 5$ UNTIL ALL USER PAR'S CHECKED

;*****************************************************************************************
;TEST 372       TEST THAT PAR-PDR'S NOT AFFECTED BY RESET
;*****************************************************************************************
TS372:

                        BIT     #1, @#$ENV      ;ARE WE RUNNING UNDER APT
                        BEQ     70$             ;IF NO THEN DO TEST
                        TST     @#$PASS         ;IS THIS FIRST PASS
                        BNE     TS373           ;IF NO THEN SHIP TO NEXT TEST
70$:
1$:     JSR     PC,SETREG       ;SET ALL BITS IN ALL PAR'S AND PDR'S
        RESET                   ;ISSUE AN "INIT" BY EXECUTING A RESET
10$:    MOV     #KIPDR0,R0      ;LOAD ADDRESS OF FIRST KERNEL PDR IN R0
        MOV     #10,R4          ;LOAD LOOP COUNTER WITH AN 8
2$:     MOV     (R0),R1         ;READ A KERNEL PDR INTO R1
        CMP     #77416,R1       ;ARE ALL THE BITS STILL SET?
        BEQ     3$
```

```
 9761  041066  104000                      EMT                     ;KERNEL PDR AFFECTED BY A RESET
 9762                                                                ;FOR TIGHTER SCOPE LOOP
 9763                                                                ;REPLACE ERROR CALL WITH
 9764                                                                ;"BR 2$" = 000773
 9765  041070  062700  000002    3$:     ADD     #2,R0               ;FORM ADDRESS OF NEXT KERNEL PDR
 9766  041074  077410                    SOB     R4,2$               ;LOOP TO 2$ UNTIL ALL KERNEL PDR'S CHECKED
 9767  041076  012700  172340            MOV     #KIPAR0,R0          ;LOAD ADDRESS OF FIRST KERNEL PAR IN R0
 9768  041102  012704  000010            MOV     #10,R4              ;LOAD LOOP COUNTER WITH AN 8
 9769  041106  011001            4$:     MOV     (R0),R1             ;READ A KERNEL PAR INTO R1
 9770                                                                ;****F11 CHANGE****     WAS #7777
 9771  041110  022701  177777            CMP     #177777,R1          ;ARE ALL THE BITS STILL SET?
 9772  041114  001401                    BEQ     5$
 9773  041116  104000                    EMT                         ;KERNEL PAR AFFECTED BY A RESET
 9774                                                                ;FOR TIGHTER SCOPE LOOP
 9775                                                                ;REPLACE ERROR CALL WITH
 9776                                                                ;"BR 4$" = 000773
 9777  041120  062700  000002    5$:     ADD     #2,R0               ;FORM ADDRESS OF NEXT KERNEL PAR
 9778  041124  077410                    SOB     R4,4$               ;LOOP TO 4$ UNTIL ALL KERNEL PAR'S CHECKED
 9779  041126  012700  177600            MOV     #UIPDR0,R0          ;LOAD ADDRESS OF FIRST USER PDR IN R0
 9780  041132  012704  000010            MOV     #10,R4              ;LOAD LOOP COUNTER WITH AN 8
 9781  041136  011001            6$:     MOV     (R0),R1             ;READ A USER PDR INTO R1
 9782  041140  022701  077416            CMP     #77416,R1           ;ARE ALL THE BITS STILL SET?
 9783  041144  001401                    BEQ     7$
 9784  041146  104000                    EMT                         ;USER PDR AFFECTED BY A RESET
 9785                                                                ;FOR TIGHTER SCOPE LOOP
 9786                                                                ;REPLACE ERROR CALL WITH
 9787                                                                ;"BR 6$" = 000773
 9788  041150  062700  000002    7$:     ADD     #2,R0               ;FORM ADDRESS OF NEXT USER PDR
 9789  041154  077410                    SOB     R4,6$               ;LOOP TO 6$ UNTIL ALL USER PDR'S CHECKED
 9790
 9791  041156  012700  177640            MOV     #UIPAR0,R0          ;LOAD ADDRESS OF FIRST USER PAR IN R0
 9792  041162  012704  000010            MOV     #10,R4              ;LOAD LOOP COUNTER WITH AN 8
 9793  041166  011001            8$:     MOV     (R0),R1             ;READ A USER PAR INTO R1
 9794                                                                ;****F11 CHANGE****     WAS #7777
 9795  041170  022701  177777            CMP     #177777,R1          ;ARE ALL THE BITS STILL SET?
 9796  041174  001401                    BEQ     9$
 9797  041176  104000                    EMT                         ;USER PAR AFFECTED BY A RESET
 9798                                                                ;FOR TIGHTER SCOPE LOOP
 9799                                                                ;REPLACE ERROR CALL WITH
 9800                                                                ;"BR 8$" = 000773
 9801  041200  062700  000002    9$:     ADD     #2,R0               ;FORM ADDRESS OF NEXT USER PAR
 9802  041204  077410                    SOB     R4,8$               ;LOOP TO 8$ UNTIL ALL USER PAR'S CHECKED
 9803
 9804
 9805
 9806
 9807
 9808
 9809
 9810
 9811
 9812
 9813
 9814
 9815
 9816
```

```
                                ;*****************************************************************************
                                ;TEST 373       RELOCATION & ADDER TEST (NO CARRIES)
                                ;*****************************************************************************
041206                          TS373:

041206  012700  172340          1$:     MOV     #KIPAR0,R0      ;LOAD ADDRESS OF FIRST KERNEL PAR IN R0
041212  005001                          CLR     R1              ;CLEAR R1
041214  012702  000007                  MOV     #7,R2           ;LOAD LOOP COUNTER WITH A 7
041220  010120                  2$:     MOV     R1,(R0)+        ;MAP KERNEL PAR'S TO PAGES 0-6 (4K EACH)
041222  062701  000200                  ADD     #200,R1
041226  077204                          SOB     R2,2$           ;LOOP UNTIL KIPAR0 - KIPAR6 ARE LOADED
041230  012710  177600                  MOV     #177600,(R0)    ;MAP KIPAR7 TO THE I/O PAGE
041234  012700  172300                  MOV     #KIPDR0,R0      ;LOAD ADDRESS OF FIRST KERNEL PDR IN R0
041240  012701  077406                  MOV     #77406,R1       ;LOAD PDR DATA INTO R1
041244  012702  000010                  MOV     #10,R2          ;LOAD LOOP COUNTER WITH AN 8
041250  010120                  3$:     MOV     R1,(R0)+        ;MAP ALL 8 PAGES 128 BLOCKS, UPWARD
041252  077202                          SOB     R2,3$           ;       EXPANDABLE, READ/WRITE

041254  012700  067776          4$:     MOV     #67776,R0       ;LOAD PHYSICAL ADDR. PBA INTO R0
041260  012701  107776                  MOV     #107776,R1      ;LOAD VIRTUAL ADDR. VBA INTO R1
041264  012702  125250                  MOV     #125250,R2      ;LOAD TEST PATTERN INTO R2
041270  012704  000600                  MOV     #600,R4 ;LOAD R4 WITH PAR VALUE
041274  010467  131050                  MOV     R4,KIPAR4       ;LOAD KERNEL PAR 4 BITS <11:00>
041300  011067  176056                  MOV     (R0),$TMP0      ;SAVE CONTENTS AT TEST LOCATION
041304  005067  131206                  CLR     SR3             ;SET UP FOR 18-BIT ADDRESSING
041310  052767  000001  136254          BIS     #BIT0,SR0       ;TURN ON "RELOCATION"
041316  010211                          MOV     R2,(R1)         ;LOAD 125250 USING ADDER  (PAR4 + VIRT ADDR.)
041320  005067  136246                  CLR     SR0             ;TURN OFF MEMORY MGMT.
041324  011003                          MOV     (R0),R3         ;READ 125250 BACK WITHOUT USING MEM. MGMT.
041326  016710  176030                  MOV     $TMP0,(R0)      ;RESTORE ORIGINAL CONTENTS TO TEST LOC.
041332  020203                          CMP     R2,R3           ;WAS SAME PATTERN READ BACK THAT WAS
                                                                ;WRITTEN USING "DEST-ONLY-RELOC."?
041334  001401                          BEQ     5$
041336  104000                          EMT                     ;TEST LOCATION DID NOT HAVE PATTERN
                                                                ;THAT SHOULD HAVE BEEN WRITTEN TO IT.
                                                                ;APPARENTLY PHYSICAL ADDR. WAS
                                                                ;FORMED WRONG BY ADDERS USING
                                                                ;THE VIRTUAL ADDR. AND KIPAR4
                                                                ;FOR TIGHTER SCOPE LOOP
                                                                ;REPLACE ERROR CALL WITH
                                                                ;"BR 4$" = 000742
041340                          5$:
041340  012700  067776          6$:     MOV     #67776,R0       ;LOAD PHYSICAL ADDR. PBA INTO R0
041344  012701  102576                  MOV     #102576,R1      ;LOAD VIRTUAL ADDR. VBA INTO R1
041350  012702  125251                  MOV     #125251,R2      ;LOAD TEST PATTERN INTO R2
041354  012704  000652                  MOV     #652,R4 ;LOAD R4 WITH PAR VALUE
041360  010467  130764                  MOV     R4,KIPAR4       ;LOAD KERNEL PAR 4 BITS <11:00>
```

```
 9873  041364  011067  175772          MOV     (R0),$TMP0      ;SAVE CONTENTS AT TEST LOCATION
 9874  041370  005067  131122          CLR     SR3             ;SET UP FOR 18-BIT ADDRESSING
 9875  041374  052767  000001  136170  BIS     #BIT0,SR0       ;TURN ON "RELOCATION"
 9876  041402  010211                  MOV     R2,(R1)         ;LOAD 125251 USING ADDER  (PAR4 + VIRT ADDR.)
 9877  041404  005067  136162          CLR     SR0             ;TURN OFF MEMORY MGMT.
 9878  041410  011003                  MOV     (R0),R3         ;READ 125251 BACK WITHOUT USING MEM. MGMT.
 9879  041412  016710  175744          MOV     $TMP0,(R0)      ;RESTORE ORIGINAL CONTENTS TO TEST LOC.
 9880  041416  020203                  CMP     R2,R3           ;WAS SAME PATTERN READ BACK THAT WAS
 9881                                                          ;WRITTEN USING "DEST-ONLY-RELOC."?
 9882  041420  001401                  BEQ     7$
 9883  041422  104000                  EMT                     ;TEST LOCATION DID NOT HAVE PATTERN
 9884                                                          ;THAT SHOULD HAVE BEEN WRITTEN TO IT.
 9885                                                          ;APPARENTLY PHYSICAL ADDR. WAS
 9886                                                          ;FORMED WRONG BY ADDERS USING
 9887                                                          ;THE VIRTUAL ADDR. AND KIPAR4
 9888                                                          ;FOR TIGHTER SCOPE LOOP
 9889                                                          ;REPLACE ERROR CALL WITH
 9890                                                          ;"BR 6$" = 000742
 9891  041424                  7$:
 9892  041424  012700  067776  8$:     MOV     #67776,R0       ;LOAD PHYSICAL ADDR. PBA INTO R0
 9893  041430  012701  105276          MOV     #105276,R1      ;LOAD VIRTUAL ADDR. VBA INTO R1
 9894  041434  012702  125252          MOV     #125252,R2      ;LOAD TEST PATTERN INTO R2
 9895  041440  012704  000625          MOV     #625,R4 ;LOAD R4 WITH PAR VALUE
 9896  041444  010467  130700          MOV     R4,KIPAR4       ;LOAD KERNEL PAR 4 BITS <11:00>
 9897  041450  011067  175706          MOV     (R0),$TMP0      ;SAVE CONTENTS AT TEST LOCATION
 9898  041454  052767  000020  131034  BIS     #BIT4,SR3       ;SET UP FOR 22-BIT ADDRESSING
 9899  041462  052767  000001  136102  BIS     #BIT0,SR0       ;TURN ON "RELOCATION"
 9900  041470  010211                  MOV     R2,(R1)         ;LOAD 125252 USING ADDER  (PAR4 + VIRT ADDR.)
 9901  041472  005067  136074          CLR     SR0             ;TURN OFF MEMORY MGMT.
 9902  041476  011003                  MOV     (R0),R3         ;READ 125252 BACK WITHOUT USING MEM. MGMT.
 9903  041500  016710  175656          MOV     $TMP0,(R0)      ;RESTORE ORIGINAL CONTENTS TO TEST LOC.
 9904  041504  020203                  CMP     R2,R3           ;WAS SAME PATTERN READ BACK THAT WAS
 9905                                                          ;WRITTEN USING "DEST-ONLY-RELOC."?
 9906  041506  001401                  BEQ     9$
 9907  041510  104000                  EMT                     ;TEST LOCATION DID NOT HAVE PATTERN
 9908                                                          ;THAT SHOULD HAVE BEEN WRITTEN TO IT.
 9909                                                          ;APPARENTLY PHYSICAL ADDR. WAS
 9910                                                          ;FORMED WRONG BY ADDERS USING
 9911                                                          ;THE VIRTUAL ADDR. AND KIPAR4
 9912                                                          ;FOR TIGHTER SCOPE LOOP
 9913                                                          ;REPLACE ERROR CALL WITH
 9914                                                          ;"BR 8$" = 000742
 9915  041512                  9$:
 9916
 9917  041512  012700  177776          MOV     #PSW,R0         ;LOAD PHYS. ADDR. OF PSW INTO R0
 9918  041516  012701  100076          MOV     #100076,R1      ;LOAD VIRTUAL ADDR. FOR PSW INTO R1
 9919  041522  012702  030340          MOV     #030340,R2      ;LOAD DATA FOR PSW IN R2
 9920  041526  012704  007777          MOV     #7777,R4        ;LOAD R4 WITH PAR VALUE
 9921  041532  010467  130612          MOV     R4,KIPAR4       ;LOAD KERNEL PAR 4 BITS <11:00>
 9922  041536  005010                  CLR     (R0)            ;CLEAR THE PSW
 9923  041540  005067  130752          CLR     SR3             ;SET UP FOR 18-BIT ADDRESSING
 9924  041544  052767  000001  136020  BIS     #BIT0,SR0       ;TURN ON "MEMORY MANAGEMENT"
 9925  041552  010211                  MOV     R2,(R1)         ;LOAD PSW USING ADDER (PAR4 + VIRT ADDR.)
 9926  041554  005067  136012          CLR     SR0             ;TURN OFF MEM. MGMT (SR0=0)
 9927  041560  011003                  MOV     (R0),R3         ;READ PSW BACK WITHOUT USING MEM. MGMT.
 9928  041562  005010                  CLR     (R0)            ;CLEAR THE PSW
```

```
 9929  041564  042703  000037          BIC     #37,R3          ;MASK T-BIT & CC BITS OUT OF DATA READ
 9930  041570  020203                  CMP     R2,R3           ;WAS PSW WRITTEN?
 9931  041572  001401                  BEQ     11$
 9932  041574  104000                  EMT                     ;PSW DID NOT HAVE DATA THAT IT SHOULD HAVE,
 9933                                                          ;APPARENTLY PHYS. ADDR. OF PSW WAS
 9934                                                          ;NOT FORMED BY ADDERS USING THE
 9935                                                          ;VIRTUAL ADDR. AND KIPAR4
 9936                                                          ;FOR TIGHTER SCOPE LOOP
 9937                                                          ;REPLACE ERROR CALL WITH
 9938                                                          ;'BR 10$'' = 000742
 9939  041576  012700  177776      11$:    MOV     #PSW,R0         ;LOAD PHYS. ADDR. OF PSW INTO R0
 9940  041602  012701  117776              MOV     #117776,R1      ;LOAD VIRTUAL ADDR. FOR PSW INTO R1
 9941  041606  012702  030240              MOV     #030240,R2      ;LOAD DATA FOR PSW IN R2
 9942  041612  012704  177600              MOV     #177600,R4      ;LOAD R4 WITH PAR VALUE
 9943  041616  010467  130526              MOV     R4,KIPAR4       ;LOAD KERNEL PAR 4 BITS <11:00>
 9944  041622  052767  000020  130666      BIS     #BIT4,SR3       ;SET UP FOR 22-BIT ADDRESSING
 9945  041630  052767  000001  135734      BIS     #BIT0,SR0       ;TURN ON 'MEMORY MANAGEMENT''
 9946  041636  010211                      MOV     R2,(R1)         ;LOAD PSW USING ADDER (PAR4 + VIRT. ADDR.)
 9947  041640  005067  135726              CLR     SR0             ;TURN OFF MEM. MGMT (SR0=0)
 9948  041644  011003                      MOV     (R0),R3         ;READ PSW BACK WITHOUT USING MEM. MGMT.
 9949  041646  005010                      CLR     (R0)            ;CLEAR THE PSW
 9950  041650  042703  000037              BIC     #37,R3          ;MASK T-BIT & CC BITS OUT OF DATA READ
 9951  041654  020203                      CMP     R2,R3           ;WAS PSW WRITTEN WHILE IN MAINT. MODE?
 9952  041656  001401                      BEQ     TS374
 9953  041660  104000                      EMT                     ;PSW DID NOT HAVE DATA THAT IT SHOULD
 9954                                                          ;HAVE, APPARENTLY PHYS. ADDR. OF PSW WAS
 9955                                                          ;NOT FORMED BY ADDERS USING THE
 9956                                                          ;VIRTUAL ADDR. AND KIPAR4
 9957                                                          ;FOR TIGHTER SCOPE LOOP
 9958                                                          ;REPLACE ERROR CALL WITH
 9959                                                          ;'BR 11$'' = 000743
 9960
 9961                          ;*****************************************************************************************
 9962                          ;TEST 374       RELOCATION & ADDER TEST (WITH CARRIES)
 9963                          ;*****************************************************************************************
 9964  041662                  TS374:
 9965
 9966  041662                  1$:                             ;KERNEL PAR'S AND PDR'S HAVE BEEN
 9967                                                          ;SETUP BY THE PREVIOUS TEST
 9968  041662  012700  066476      2$:     MOV     #66476,R0       ;LOAD PHYSICAL ADDR. PBA INTO R0
 9969  041666  012701  114376              MOV     #114376,R1      ;LOAD VIRTUAL ADDR. VBA INTO R1
 9970  041672  012702  125253              MOV     #125253,R2      ;LOAD TEST PATTERN INTO R2
 9971  041676  012704  000521              MOV     #521,R4 ;LOAD R4 WITH PAR VALUE
 9972  041702  010467  130442              MOV     R4,KIPAR4       ;LOAD KERNEL PAR 4 BITS <11:00>
 9973  041706  011067  175450              MOV     (R0),$TMP0      ;SAVE CONTENTS AT TEST LOCATION
 9974  041712  052767  000020  130576      BIS     #BIT4,SR3       ;SET UP FOR 22-BIT ADDRESSING
 9975  041720  052767  000001  135644      BIS     #BIT0,SR0       ;TURN ON ''RELOCATION''
 9976  041726  010211                      MOV     R2,(R1)         ;LOAD 125253 USING ADDER  (PAR4 + VIRT ADDR.)
 9977  041730  005067  135636              CLR     SR0             ;TURN OFF MEMORY MGMT.
 9978  041734  011003                      MOV     (R0),R3         ;READ 125253 BACK WITHOUT USING MEM. MGMT.
 9979  041736  016710  175420              MOV     $TMP0,(R0)      ;RESTORE ORIGINAL CONTENTS TO TEST LOC.
 9980  041742  020203                      CMP     R2,R3           ;WAS SAME PATTERN READ BACK THAT WAS
 9981                                                          ;WRITTEN USING 'DEST-ONLY-RELOC.''?
 9982  041744  001401                      BEQ     3$
 9983  041746  104000                      EMT                     ;TEST LOCATION DID NOT HAVE PATTERN
 9984                                                          ;THAT SHOULD HAVE BEEN WRITTEN TO IT.
```

```
 9985                                                   ;APPARENTLY PHYSICAL ADDR. WAS
 9986                                                   ;FORMED WRONG BY ADDERS USING
 9987                                                   ;THE VIRTUAL ADDR. AND KIPAR4
 9988                                                   ;FOR TIGHTER SCOPE LOOP
 9989                                                   ;REPLACE ERROR CALL WITH
 9990                                                   ;'BR 2$" = 000742
 9991  041750                            3$:
 9992  041750  012700  062276           4$:     MOV     #62276,R0       ;LOAD PHYSICAL ADDR. PBA INTO R0
 9993  041754  012701  107376                   MOV     #107376,R1      ;LOAD VIRTUAL ADDR. VBA INTO R1
 9994  041760  012702  125254                   MOV     #125254,R2      ;LOAD TEST PATTERN INTO R2
 9995  041764  012704  000527                   MOV     #527,R4 ;LOAD R4 WITH PAR VALUE
 9996  041770  010467  130354                   MOV     R4,KIPAR4       ;LOAD KERNEL PAR 4 BITS <11:00>
 9997  041774  011067  175362                   MOV     (R0),$TMP0      ;SAVE CONTENTS AT TEST LOCATION
 9998  042000  052767  000020  130510           BIS     #BIT4,SR3       ;SET UP FOR 22-BIT ADDRESSING
 9999  042006  052767  000001  135556           BIS     #BIT0,SR0       ;TURN ON "RELOCATION"
10000  042014  010211                           MOV     R2,(R1)         ;LOAD 125254 USING ADDER  (PAR4 + VIRT ADDR.)
10001  042016  005067  135550                   CLR     SR0             ;TURN OFF MEMORY MGMT.
10002  042022  011003                           MOV     (R0),R3         ;READ 125254 BACK WITHOUT USING MEM. MGMT.
10003  042024  016710  175332                   MOV     $TMP0,(R0)      ;RESTORE ORIGINAL CONTENTS TO TEST LOC.
10004  042030  020203                           CMP     R2,R3           ;WAS SAME PATTERN READ BACK THAT WAS
10005                                                                  ;WRITTEN USING "DEST-ONLY-RELOC."?
10006  042032  001401                           BEQ     5$
10007  042034  104000                           EMT                     ;TEST LOCATION DID NOT HAVE PATTERN
10008                                                                  ;THAT SHOULD HAVE BEEN WRITTEN TO IT.
10009                                                                  ;APPARENTLY PHYSICAL ADDR. WAS
10010                                                                  ;FORMED WRONG BY ADDERS USING
10011                                                                  ;THE VIRTUAL ADDR. AND KIPAR4
10012                                                                  ;FOR TIGHTER SCOPE LOOP
10013                                                                  ;REPLACE ERROR CALL WITH
10014                                                                  ;'BR 4$" = 000742
10015  042036                            5$:
10016  042036  012700  062076           6$:     MOV     #62076,R0       ;LOAD PHYSICAL ADDR. PBA INTO R0
10017  042042  012701  104576                   MOV     #104576,R1      ;LOAD VIRTUAL ADDR. VBA INTO R1
10018  042046  012702  125255                   MOV     #125255,R2      ;LOAD TEST PATTERN INTO R2
10019  042052  012704  000553                   MOV     #553,R4 ;LOAD R4 WITH PAR VALUE
10020  042056  010467  130266                   MOV     R4,KIPAR4       ;LOAD KERNEL PAR 4 BITS <11:00>
10021  042062  011067  175274                   MOV     (R0),$TMP0      ;SAVE CONTENTS AT TEST LOCATION
10022  042066  052767  000020  130422           BIS     #BIT4,SR3       ;SET UP FOR 22-BIT ADDRESSING
10023  042074  052767  000001  135470           BIS     #BIT0,SR0       ;TURN ON "RELOCATION"
10024  042102  010211                           MOV     R2,(R1)         ;LOAD 125255 USING ADDER  (PAR4 + VIRT ADDR.)
10025  042104  005067  135462                   CLR     SR0             ;TURN OFF MEMORY MGMT.
10026  042110  011003                           MOV     (R0),R3         ;READ 125255 BACK WITHOUT USING MEM. MGMT.
10027  042112  016710  175244                   MOV     $TMP0,(R0)      ;RESTORE ORIGINAL CONTENTS TO TEST LOC.
10028  042116  020203                           CMP     R2,R3           ;WAS SAME PATTERN READ BACK THAT WAS
10029                                                                  ;WRITTEN USING "DEST-ONLY-RELOC."?
10030  042120  001401                           BEQ     7$
10031  042122  104000                           EMT                     ;TEST LOCATION DID NOT HAVE PATTERN
10032                                                                  ;THAT SHOULD HAVE BEEN WRITTEN TO IT.
10033                                                                  ;APPARENTLY PHYSICAL ADDR. WAS
10034                                                                  ;FORMED WRONG BY ADDERS USING
10035                                                                  ;THE VIRTUAL ADDR. AND KIPAR4
10036                                                                  ;FOR TIGHTER SCOPE LOOP
10037                                                                  ;REPLACE ERROR CALL WITH
10038                                                                  ;'BR 6$" = 000742
10039  042124                            7$:
10040  042124  012700  000000           8$:     MOV     #000000,R0      ;LOAD PHYSICAL ADDR. PBA INTO R0
```

```
10041  042130  012701  111400                 MOV     #111400,R1      ;LOAD VIRTUAL ADDR. VBA INTO R1
10042  042134  012702  125256                 MOV     #125256,R2      ;LOAD TEST PATTERN INTO R2
10043  042140  012704  177664                 MOV     #177664,R4      ;LOAD R4 WITH PAR VALUE
10044  042144  010467  130200                 MOV     R4,KIPAR4       ;LOAD KERNEL PAR 4 BITS <11:00>
10045  042150  011067  175206                 MOV     (R0),$TMP0      ;SAVE CONTENTS AT TEST LOCATION
10046  042154  052767  000020  130334         BIS     #BIT4,SR3       ;SET UP FOR 22-BIT ADDRESSING
10047  042162  052767  000001  135402         BIS     #BIT0,SR0       ;TURN ON "RELOCATION"
10048  042170  010211                         MOV     R2,(R1)         ;LOAD 125256 USING ADDER  (PAR4 + VIRT ADDR.)
10049  042172  005067  135374                 CLR     SR0             ;TURN OFF MEMORY MGMT.
10050  042176  011003                         MOV     (R0),R3         ;READ 125256 BACK WITHOUT USING MEM. MGMT.
10051  042200  016710  175156                 MOV     $TMP0,(R0)      ;RESTORE ORIGINAL CONTENTS TO TEST LOC.
10052  042204  020203                         CMP     R2,R3           ;WAS SAME PATTERN READ BACK THAT WAS
10053                                                                  ;WRITTEN USING "DEST-ONLY-RELOC."?
10054  042206  001401                         BEQ     9$
10055  042210  104000                         EMT                     ;TEST LOCATION DID NOT HAVE PATTERN
10056                                                                  ;THAT SHOULD HAVE BEEN WRITTEN TO IT.
10057                                                                  ;APPARENTLY PHYSICAL ADDR. WAS
10058                                                                  ;FORMED WRONG BY ADDERS USING
10059                                                                  ;THE VIRTUAL ADDR. AND KIPAR4
10060                                                                  ;FOR TIGHTER SCOPE LOOP
10061                                                                  ;REPLACE ERROR CALL WITH
10062                                                                  ;"BR 8$" = 000742
10063  042212                          9$:
10064
10065                          ;*****************************************************************************
10066                          ;TEST 375       READ AND WRITE WHILE IN RELOCATE MODE
10067                          ;*****************************************************************************
10068  042212                  TS375:
10069
10070  042212  005067  135560         1$:     CLR     PSW             ;START IN KERNEL MODE
10071  042216  012704  001377                 MOV     #1377,R4        ;LOAD R4 WITH VALUE FOR PAR4
10072  042222  012705  001400                 MOV     #1400,R5        ;LOAD R5 WITH VALUE FOR PAR5
10073  042226  010467  130116                 MOV     R4,KIPAR4       ;LOAD KERNEL PAR4
10074  042232  010567  130114                 MOV     R5,KIPAR5       ;LOAD KERNEL PAR5
10075  042236  012700  177640                 MOV     #UIPAR0,R0      ;LOAD ADDRESS OF FIRST USER PAR IN R0
10076  042242  005001                         CLR     R1              ;CLEAR R1
10077  042244  012702  000007                 MOV     #7,R2           ;LOAD LOOP COUNTER WITH A 7
10078  042250  010120                 2$:     MOV     R1,(R0)+        ;MAP USER PAR'S TO PAGES 0-6 (4K EACH)
10079  042252  062701  000200                 ADD     #200,R1
10080  042256  077204                         SOB     R2,2$           ;LOOP UNTIL UIPAR0-UIPAR6 ARE LOADED
10081  042260  012710  177600                 MOV     #177600,(R0)    ;MAP USER PAR7 TO THE I/O PAGE
10082  042264  012700  177600                 MOV     #UIPDR0,R0      ;LOAD ADDRESS OF FIRST USER PDR IN R0
10083  042270  012701  077406                 MOV     #77406,R1       ;LOAD PDR DATA INTO R1
10084  042274  012702  000010                 MOV     #10,R2          ;LOAD LOOP COUNTER WITH AN 8
10085  042300  010120                 3$:     MOV     R1,(R0)+        ;MAP ALL 8 PAGES 128 BLOCKS, UPWARD
10086  042302  077202                         SOB     R2,3$           ;       EXPANDABLE, READ/WRITE
10087  042304  012767  042550  135736         MOV     #8$,MMVEC       ;SET M. M. TRAP VECTOR TO 8$
10088  042312  052767  000020  130176         BIS     #BIT4,SR3       ;SET UP FOR 22-BIT ADDRESSING
10089  042320  012767  000001  135244         MOV     #BIT0,SR0       ;TURN ON MEMORY MANAGEMENT
10090  042326  105067  135256                 CLRB    UIPDR4          ;MAP USER SPACE NON-RESIDENT WHILE
10091  042332  105067  135254                 CLRB    UIPDR5          ;       TESTING KERNEL SPACE
10092  042336  010567  135306                 MOV     R5,UIPAR4       ;MAP USER PAR'S OPPOSITE OF KIPAR'S
10093  042342  010467  135304                 MOV     R4,UIPAR5
10094  042346  016767  135424  175006 4$:     MOV     PSW,$TMP0       ;SAVE PSW IN CASE OF ERROR
10095  042354  012700  100100                 MOV     #100100,R0      ;PUT VIRTUAL ADDR. THAT USES PAR4 IN R0
10096  042360  012701  120000                 MOV     #120000,R1      ;PUT VIRTUAL ADDR. THAT USES PAR5 IN R1
```

```
10097  042364  010010                  5$:     MOV     R0,(R0)         ;WRITE TO TEST LOC. USING PAR4
10098  042366  011102                          MOV     (R1),R2         ;READ THE SAME LOC., BUT USING PAR5
10099  042370  020002                          CMP     R0,R2           ;DID WE READ WHAT WE WROTE?
10100  042372  001401                          BEQ     6$
10101  042374  104000                          EMT                     ;READING LOC. USING PAR5 AND A VIRT.
10102                                                                   ;ADDR. DID NOT FIND DATA WRITTEN WHEN USING
10103                                                                   ;PAR4 AND VIRT. ADDRESS.
10104                                                                   ;FOR TIGHTER SCOPE LOOP
10105                                                                   ;REPLACE ERROR CALL WITH
10106                                                                   ;'BR 5$" = 000765
10107  042376  062700  000100          6$:     ADD     #100,R0         ;CHANGE VIRTUAL ADDRS. TO POINT TO NEXT BLOCK
10108  042402  062701  000100                  ADD     #100,R1
10109  042406  020127  127700                  CMP     R1,#127700      ;WERE BLOCKS FROM 60000-676000 ALL TRIED?
10110  042412  001364                          BNE     5$              ;BRANCH IF NO
10111  042414  032767  140000  135354          BIT     #140000,PSW     ;HAVE WE DONE TEST IN USER MODE YET?
10112  042422  001026                          BNE     7$              ;BRANCH IF YES
10113  042424  010467  135220                  MOV     R4,UIPAR4       ;LOAD USER PAR4
10114  042430  010567  135216                  MOV     R5,UIPAR5       ;LOAD USER PAR5
10115  042434  112767  000006  135146          MOVB    #6,UIPDR4       ;MAP USER SPACE R/W TO TEST IT
10116  042442  112767  000006  135142          MOVB    #6,UIPDR5
10117  042450  105067  127634                  CLRB    KIPDR4          ;MAP  KERNEL SPACE NON-RESIDENT WHILE
10118  042454  105067  127632                  CLRB    KIPDR5          ;       TESTING USER SPACE
10119  042460  010567  127664                  MOV     R5,KIPAR4       ;MAP KERNEL PAR'S OPPOSITE UIPAR'S
10120  042464  010467  127662                  MOV     R4,KIPAR5
10121  042470  012767  140000  135300          MOV     #140000,PSW     ;GO TO USER MODE
10122  042476  000723                          BR      4$              ;GO BACK AND READ/WRITE IN USER MODE
10123  042500  005067  135272          7$:     CLR     PSW             ;GO BACK TO KERNEL MODE BEFORE LEAVING
10124  042504  012767  077406  127576          MOV     #77406,KIPDR4   ;REMAP KERNEL PAGES READ/WRITE
10125  042512  012767  077406  127572          MOV     #77406,KIPDR5
10126  042520  010567  127624                  MOV     R5,KIPAR4       ;MAP KERNEL  AND USER PAR'S 4 & 5
10127  042524  010567  127622                  MOV     R5,KIPAR5       ;  BACK TO 12-16K
10128  042530  010567  135114                  MOV     R5,UIPAR4
10129  042534  010567  135112                  MOV     R5,UIPAR5
10130  042540  012767  021276  135502          MOV     #T0250,MMVEC    ;RESTORE ADDR. OF NORMAL M.M. TRAP ROUTINE
10131  042546  000404                          BR      TS376           ;GET TO NEXT TEST
10132  042550  042767  160000  135014  8$:     BIC     #160000,SR0     ;CLEAR ERROR BITS IN SR0
10133  042556  104000                          EMT                     ;M.M. TRAP WHILE IN RELOCATE MODE -
10134                                                                   ;REFERENCED WRONG SET OF PDR'S
10135                                                                   ;FOR TIGHTER SCOPE LOOP
10136                                                                   ;REPLACE ERROR CALL WITH
10137                                                                   ;A "NOP" = 000240
10138
10139                                   ;*************************************************************************************
10140                                   ;TEST 376       W-BIT LOGIC TEST, KERNEL PDR'S
10141                                   ;*************************************************************************************
10142  042560                           TS376:
10143  042560                           1$:
10144  042560  004767  005300                  JSR     PC,TOFF         ;TURN T-BIT TRAPPING OFF FOR THIS TEST
10145  042564  012702  000004                  MOV     #4,R2           ;SET LOOP COUNTER TO 4
10146  042570  012700  172346                  MOV     #KIPAR3,R0      ;LOAD ADDRESS OF PAR3 INTO R0
10147  042574  012701  001400                  MOV     #1400,R1        ;LOAD "24-28K" PAR VALUE INTO R1
10148  042600  010120                  2$:     MOV     R1,(R0)+        ;MAP PARS 3-6 TO 12-16K
10149  042602  077202                          SOB     R2,2$           ;LOOP TIL ALL 4 OF THEM LOADED
10150  042604  012705  172300                  MOV     #KIPDR0,R5      ;LOAD ADDRESS OF FIRST PDR TO BE TESTED IN R5
10151  042610  012704  000010                  MOV     #10,R4          ;SET LOOP COUNTER TO 8
10152  042614  012703  017776                  MOV     #17776,R3       ;INITIALIZE VIRTUAL ADDRESS TO BE IN R3
```

```
10153  042620  012700  172300          3$:     MOV     #KIPDR0,R0      ;LOAD ADDR. OF FIRST PDR TO BE SETUP IN R0
10154  042624  012702  000010                  MOV     #10,R2          ;SET LOOP COUNTER TO 8
10155  042630  012701  077406                  MOV     #77406,R1       ;PUT "W-BIT OFF DATA" INTO R1
10156  042634  010120                  4$:     MOV     R1,(R0)+        ;CLEAR ALL W-BITS BY WRITING TO ALL PDRS
10157  042636  077202                          SOB     R2,4$           ;LOOP UNTIL ALL OF THEM SETUP
10158  042640  011313                          MOV     (R3),(R3)       ;DO "DATO" TO VIRTUAL ADDR.-SETTING A W-BIT
10159  042642  031527  000100                  BIT     (R5),#WBIT      ;DID THAT CAUSE W-BIT TO BE SET?
10160  042646  001001                          BNE     5$
10161  042650  104000                          EMT                     ;W-BIT DID NOT GET SET IN PDR
10162                                                                  ;FOR TIGHTER SCOPE LOOP
10163                                                                  ;REPLACE ERROR CALL WITH
10164                                                                  ;"BR 3$" = 000763
10165  042652  012702  000010          5$:     MOV     #10,R2          ;SET LOOP COUNTER TO 8
10166  042656  012700  172300                  MOV     #KIPDR0,R0      ;LOAD ADDR. OF FIRST PDR TO BE CHECKED IN R0
10167  042662  031027  000100          6$:     BIT     (R0),#WBIT      ;DID W-BIT IN OTHER PDRS REMAIN CLEAR?
10168  042666  001403                          BEQ     7$              ;BRANCH IF YES
10169  042670  020500                          CMP     R5,R0           ;IF W-BIT SET, THEN WAS IT PDR UNDER TEST?
10170  042672  001401                          BEQ     7$
10171  042674  104000                          EMT                     ;W-BIT GOT SET IN MORE THAN ONE PDR
10172                                                                  ;FOR TIGHTER SCOPE LOOP
10173                                                                  ;REPLACE ERROR CALL WITH
10174                                                                  ;"BR 3$" = 000750
10175  042676  062700  000002          7$:     ADD     #2,R0           ;POINT R0 TO NEXT PDR TO BE CHECKED
10176  042702  077211                          SOB     R2,6$           ;LOOP UNTIL ALL 8 CHECKED FOR CLEAR W-BIT
10177  042704  010115                          MOV     R1,(R5)         ;WRITE TO THE PDR TESTED TO CLEAR W-BIT
10178  042706  031527  000100                  BIT     (R5),#WBIT      ;DID WRITING PDR CLEAR THE W-BIT?
10179  042712  001401                          BEQ     8$
10180  042714  104000                          EMT                     ;W-BIT DID NOT CLEAR BY WRITING THE PDR
10181                                                                  ;FOR TIGHTER SCOPE LOOP
10182                                                                  ;REPLACE ERROR CALL WITH
10183                                                                  ;"BR 3$" = 000740
10184  042716  062705  000002          8$:     ADD     #2,R5           ;POINT R5 TO THE NEXT PDR TO BE TESTED
10185  042722  062703  020000                  ADD     #20000,R3       ;CHANGE VIRT. ADDR TO REF. NEXT PDR
10186  042726  077444                          SOB     R4,3$           ;LOOP BACK TO 3$ UNTIL ALL 8 PDR'S TESTED
10187  042730  004767  005164                  JSR     PC,TON          ;TURN T-BIT BACK ON FOR NEXT TEST
10188
10189                                  ;*****************************************************************************
10190                                  ;TEST 377       W-BIT LOGIC TEST, USER PDR'S
10191                                  ;*****************************************************************************
10192  042734                          TS377:
10193  042734  012767  140000  135034  1$:     MOV     #140000,PSW     ;GO TO USER MODE FOR THIS TEST
10194  042742  004767  005116                  JSR     PC,TOFF         ;TURN T-BIT TRAPPING OFF FOR THIS TEST
10195  042746  012702  000004                  MOV     #4,R2           ;SET LOOP COUNTER TO 4
10196  042752  012700  177646                  MOV     #UIPAR3,R0      ;LOAD ADDRESS OF PAR3 INTO R0
10197  042756  012701  001400                  MOV     #1400,R1        ;LOAD "24-28K" PAR VALUE INTO R1
10198  042762  010120                  2$:     MOV     R1,(R0)+        ;MAP PARS 3-6 TO 12-16K
10199  042764  077202                          SOB     R2,2$           ;LOOP TIL ALL 4 OF THEM LOADED
10200  042766  012705  177600                  MOV     #UIPDR0,R5      ;LOAD ADDRESS OF FIRST PDR TO BE TESTED IN R5
10201  042772  012704  000010                  MOV     #10,R4          ;SET LOOP COUNTER TO 8
10202  042776  012703  017776                  MOV     #17776,R3       ;INITIALIZE VIRTUAL ADDRESS TO BE IN R3
10203  043002  012700  177600          3$:     MOV     #UIPDR0,R0      ;LOAD ADDR. OF FIRST PDR TO BE SETUP IN R0
10204  043006  012702  000010                  MOV     #10,R2          ;SET LOOP COUNTER TO 8
10205  043012  012701  077406                  MOV     #77406,R1       ;PUT "W-BIT OFF DATA" INTO R1
10206  043016  010120                  4$:     MOV     R1,(R0)+        ;CLEAR ALL W-BITS BY WRITING TO ALL PDRS
10207  043020  077202                          SOB     R2,4$           ;LOOP UNTIL ALL OF THEM SETUP
10208  043022  011313                          MOV     (R3),(R3)       ;DO "DATO" TO VIRTUAL ADDR.-SETTING A W-BIT
```

```
 10209  043024  031527  000100            BIT     (R5),#WBIT      ;DID THAT CAUSE W-BIT TO BE SET?
 10210  043030  001001                    BNE     5$
 10211  043032  104000                    EMT                     ;W-BIT DID NOT GET SET IN PDR
 10212                                                             ;FOR TIGHTER SCOPE LOOP
 10213                                                             ;REPLACE ERROR CALL WITH
 10214                                                             ;"BR 3$" = 000763
 10215  043034  012702  000010    5$:     MOV     #10,R2          ;SET LOOP COUNTER TO 8
 10216  043040  012700  177600            MOV     #UIPDR0,R0      ;LOAD ADDR. OF FIRST PDR TO BE CHECKED IN R0
 10217  043044  031027  000100    6$:     BIT     (R0),#WBIT      ;DID W-BIT IN OTHER PDRS REMAIN CLEAR?
 10218  043050  001403                    BEQ     7$              ;BRANCH IF YES
 10219  043052  020500                    CMP     R5,R0           ;IF W-BIT SET, THEN WAS IT PDR UNDER TEST?
 10220  043054  001401                    BEQ     7$
 10221  043056  104000                    EMT                     ;W-BIT GOT SET IN MORE THAN ONE PDR
 10222                                                             ;FOR TIGHTER SCOPE LOOP
 10223                                                             ;REPLACE ERROR CALL WITH
 10224                                                             ;"BR 3$" = 000750
 10225  043060  062700  000002    7$:     ADD     #2,R0           ;POINT R0 TO NEXT PDR TO BE CHECKED
 10226  043064  077211                    SOB     R2,6$           ;LOOP UNTIL ALL 8 CHECKED FOR CLEAR W-BIT
 10227  043066  010115                    MOV     R1,(R5)         ;WRITE TO THE PDR TESTED TO CLEAR W-BIT
 10228  043070  031527  000100            BIT     (R5),#WBIT      ;DID WRITING PDR CLEAR THE W-BIT?
 10229  043074  001401                    BEQ     8$
 10230  043076  104000                    EMT                     ;W-BIT DID NOT CLEAR BY WRITING THE PDR
 10231                                                             ;FOR TIGHTER SCOPE LOOP
 10232                                                             ;REPLACE ERROR CALL WITH
 10233                                                             ;"BR 3$" = 000740
 10234  043100  062705  000002    8$:     ADD     #2,R5           ;POINT R5 TO THE NEXT PDR TO BE TESTED
 10235  043104  062703  020000            ADD     #20000,R3       ;CHANGE VIRT. ADDR TO REF. NEXT PDR
 10236  043110  077444                    SOB     R4,3$           ;LOOP BACK TO 3$ UNTIL ALL 8 PDR'S TESTED
 10237  043112  004767  005002            JSR     PC,TON          ;TURN T-BIT BACK ON FOR NEXT TEST
 10238  043116  005067  134654            CLR     PSW             ;BACK TO KERNEL MODE BEFORE LEAVING
 10239
 10240          ;*****************************************************************************************
 10241          ;TEST 400       TEST "W-BIT" SPECIAL CASES
 10242          ;*****************************************************************************************
 10243  043122                    TS400:
 10244
 10245  043122  004767  004736    1$:     JSR     PC,TOFF         ;TURN OFF T-BIT TRAPPING FOR THIS TEST
 10246  043126  012701  077406            MOV     #77406,R1       ;PUT "W-BIT OFF" VALUE FOR PDR IN R1
 10247  043132  010167  127160    2$:     MOV     R1,KIPDR7       ;LOAD KERNEL PDR 7 TO CLEAR W-BIT
 10248  043136  016700  134430            MOV     SR0,R0          ;READ PRESENT CONTENTS OF STATUS REG. 0
 10249  043142  010067  134424            MOV     R0,SR0          ;WRITE PRESENT CONTENTS OF SR0 BACK TO ITSELF
 10250  043146  016702  127144            MOV     KIPDR7,R2       ;READ CONTENTS OF KIPDR7 INTO R2
 10251  043152  020102                    CMP     R1,R2           ;WAS W-BIT LEFT CLEARED?
 10252  043154  001401                    BEQ     3$
 10253  043156  104000                    EMT                     ;W-BIT IN KIPDR7 SET WHEN SR0 WAS WRITTEN TO
 10254                                                             ;FOR TIGHTER SCOPE LOOP
 10255                                                             ;REPLACE ERROR CALL WITH
 10256                                                             ;"BR 2$" = 000765
 10257  043160  010167  127130    3$:     MOV     R1,KIPDR6       ;LOAD KERNEL PDR6 WITH 77406 TO CLEAR W-BIT
 10258  043164  012767  043176  134612    MOV     #4$,ERRVEC      ;SET UP LOC. 4 TO 4$ FOR ODD ADDR. ABORT
 10259  043172  005037  140000            CLR     @#140000        ;CAUSE TIMEOUT ABORT THRU LOC. 4
 10260  043176  012706  001000    4$:     MOV     #KERSTK,KSP     ;RESTORE THE STACK POINTER
 10261  043202  016702  127106            MOV     KIPDR6,R2       ;READ KIPDR6 INTO R2
 10262  043206  052701  000100            BIS     #100,R1         ;R1-77506
 10263  043212  020102                    CMP     R1,R2           ;WAS W-BIT SET?
 10264  043214  001401                    BEQ     5$
```

```
10265  043216  104000                          EMT                     ;W-BIT WAS NOT SET DURING A TIMEOUT ABORT
10266                                                                   ;FOR TIGHTER SCOPE LOOP
10267                                                                   ;REPLACE ERROR CALL WITH
10268                                                                   ;"BR 3$" = 000757
10269  043220  010167  127070                  5$:     MOV     R1,KIPDR6       ;RESTORE KIPDR6 TO 77406
10270  043224  012767  001400  127122                  MOV     #1400,KIPAR6    ;RESTORE KIPAR6 TO 1400
10271  043232  012767  021256  134544                  MOV     #TO4,ERRVEC     ;RESTORE NORMAL CPU TRAP ROUTINE TO LOC.4
10272  043240  004767  004654                          JSR     PC,TON          ;TURN T-BIT TRAPPING BACK ON
10273
10274                                  ;*****************************************************************************
10275                                  ;*
10276                                  ;*      THE NEXT THREE (3) TESTS CAUSE MEMORY MANAGEMENT ERRORS
10277                                  ;*      TO CHECK THE ABILITY OF STATUS REGISTER 0 TO RECORD KT
10278                                  ;*      ERRORS AND THE ABILITY OF STATUS REGISTER 2 TO LOCK UP THE
10279                                  ;*      VIRTUAL ADDR. OF THE INSTRUCTION THAT CAUSED THE ERROR.
10280                                  ;*      THE BITS OF SR2 ARE CHECKED AND BITS <15:13>, <6:5>, AND <3:0>
10281                                  ;*      ARE CHECKED IN SRO.  SO THE SRO AND SR2 LOGIC AND THE
10282                                  ;*      KT ERROR LOGIC ARE CHECKED.
10283                                  ;*
10284                                  ;*****************************************************************************
10285
10286                                  ;*****************************************************************************
10287                                  ;TEST 401       NON-RESIDENT ABORT TEST (ACF=0&4)
10288                                  ;*****************************************************************************
10289  043244                          TS401:
10290
10291  043244  012700  001400          1$:     MOV     #1400,R0        ;LOAD DATA FOR PAR'S INTO R0
10292  043250  010067  127072                  MOV     R0,KIPAR3       ;MAP KERNEL PAR'S 3&4 TO 24-28K
10293  043254  010067  127070                  MOV     R0,KIPAR4
10294  043260  010067  134362                  MOV     R0,UIPAR3       ;MAP USER PAR'S 3&4 TO 24-28K
10295  043264  010067  134360                  MOV     R0,UIPAR4
10296  043270  012767  077406  127010          MOV     #77406,KIPDR3   ;MAP KERNEL PDR 3  128 BLKS, READ-WRITE
10297  043276  012767  077406  134302          MOV     #77406,UIPDR3   ;MAP USER PDR 3  128 BLKS, READ-WRITE
10298  043304  012700  060000                  MOV     #60000,R0       ;LOAD VIRTUAL ADDR. TO REFERENCE PDR3 INTO R0
10299  043310  012701  100000                  MOV     #100000,R1      ;LOAD VIRTUAL ADDR. TO REFERENCE PDR4 INTO R1
10300  043314  012703  100011                  MOV     #100011,R3      ;LOAD R3 WITH WHAT SRO SHOULD READ - N.R., KERNEL, PG.4
10301  043320  012702  077400                  MOV     #77400,R2       ;LOAD ACF=0 (NON-RESIDENT) PDR VALUE IN R2
10302  043324  012767  043360  134716  2$:     MOV     #5$,MMVEC       ;POINT MEM. MGMT. TRAP VECTOR TO 5$ BELOW
10303  043332  010267  126752                  MOV     R2,KIPDR4       ;LOAD ACF TEST VALUE INTO KIPDR4
10304  043336  010267  134246                  MOV     R2,UIPDR4       ;LOAD ACF TEST VALUE INTO UIPDR4
10305  043342  005010                  3$:     CLR     (R0)            ;CLEAR PHYS. LOC. 140000 USING PDR3
10306  043344  016767  134426  174010          MOV     PSW,$TMP0       ;SAVE PSW IN CASE OF ERROR
10307  043352  005211                  4$:     INC     (R1)            ;TRY TO REF. IT USING PDR4 - SHOULD TRAP TO 5$
10308  043354  001462                          BEQ     TS402
10309  043356  104000                          EMT                     ;MEM. MGMT. ABORT DID NOT OCCUR
10310                                                                   ;FOR TIGHTER SCOPE LOOP
10311                                                                   ;REPLACE ERROR CALL WITH
10312                                                                   ;"BR 3$" = 000772
10313  043360  062706  000004          5$:     ADD     #4,SP           ;RESTORE STACK POINTER
10314  043364  005710                          TST     (R0)            ;DID INSTRUCTION GET ABORTED & NOT EXECUTE
10315  043366  001401                          BEQ     6$
10316  043370  104000                          EMT                     ;INSTRUCTION WAS NOT ABORTED, LOC. GOT CHANGED
10317                                                                   ;FOR TIGHTER SCOPE LOOP
10318                                                                   ;REPLACE ERROR CALL WITH
10319                                                                   ;"BR 3$" = 000764
10320  043372  016767  134174  173754  6$:     MOV     SR0,WASSR0      ;READ STATUS REGISTER 0
```

```
10321  043400  016767  134172  173750          MOV     SR2,WASSR2      ;READ STATUS REGISTER 2
10322  043406  020367  173742                  CMP     R3,WASSR0       ;DID SR0 REPORT NON-RESIDENT ERROR CORRECTLY?
10323  043412  001401                          BEQ     7$
10324  043414  104000                          EMT                     ;SR0 DID NOT REPORT NON-RES. ERROR CORRECTLY
10325                                                                   ;FOR TIGHTER SCOPE LOOP
10326                                                                   ;REPLACE ERROR CALL WITH
10327                                                                   ;"BR 3$" = 000752
10328  043416  012704  043352          7$:     MOV     #4$,R4          ;LOAD R4 WITH WHAT SR2 SHOULD READ
10329  043422  020467  173730                  CMP     R4,WASSR2       ;DID SR2 LOCKUP RIGHT VIRTUAL ADDR. (=4$)?
10330  043426  001401                          BEQ     8$
10331  043430  104000                          EMT                     ;SR2 DID NOT LOCK VIRTUAL ADDR. OF NON-RES. ERROR
10332                                                                   ;FOR TIGHTER SCOPE LOOP
10333                                                                   ;REPLACE ERROR CALL WITH
10334                                                                   ;"BR 3$" = 000744
10335  043432  042767  160000  134132  8$:     BIC     #160000,SR0     ;CLEAR THE ERROR BITS IN SR0
10336  043440  032767  140000  173714          BIT     #140000,$TMP0   ;HAS ACF=0&4 BEEN TESTED IN USER YET
10337  043446  001006                          BNE     9$              ;BRANCH IF YES
10338  043450  012703  100151                  MOV     #100151,R3      ;LOAD R3 WITH WHAT SP0 SHOULD READ - N.R., USER, PG.4
10339  043454  012767  140000  134314          MOV     #140000,PSW     ;GO TO USER MODE
10340  043462  000720                          BR      2$              ;REPEAT TEST IN USER MODE
10341  043464  022702  077404          9$:     CMP     #77404,R2       ;HAS ACF=4 BEEN TESTED YET?
10342  043470  001407                          BEQ     10$             ;BRANCH IF YES
10343  043472  012702  077404                  MOV     #77404,R2       ;THEN LOAD ACF=4 (NON-RES) PDR VALUE IN R2
10344  043476  012703  10001                   MOV     #100011,R3      ;LOAD R3 WITH WHAT SR0 SHOULD READ-N.R.,KERNEL,PG. 4
10345  043502  005067  134270                  CLR     PSW             ;GO BACK TO KERNEL MODE
10346  043506  000706                          BR      2$              ;GO BACK & TEST ACF=4 IN SAME MODE
10347  043510  005067  134262          10$:    CLR     PSW             ;GO BACK TO KERNEL MODE BEFORE LEAVING
10348  043514  012767  021276  134526          MOV     #T0250,MMVEC    ;RESTORE ADDRESS OF NORMAL MEMORY
10349                                                                   ;MANAGEMENT ERROR ROUTINE TO MMVEC
10350
10351                  ;*********************************************************************************
10352                  ;TEST 402       READ-ONLY ABORT TEST (ACF=2)
10353                  ;*********************************************************************************
10354  043522          TS402:
10355  043522          1$:                                             ;KERNEL & USER PAR'S 3 & 4 AND PDR 3
10356                                                                   ;ARE SETUP FROM LAST TEST
10357  043522  012700  060000                  MOV     #60000,R0       ;LOAD VIRTUAL ADDR. TO REFERENCE PDR3 INTO R0
10358  043526  012701  100000                  MOV     #100000,R1      ;LOAD VIRTUAL ADDR. TO REFERENCE PDR4 INTO R1
10359  043532  012703  020011                  MOV     #20011,R3       ;LOAD R3 WITH WHAT SR0 SHOULD READ - R/O, KERNEL, PG.4
10360  043536  012702  077402                  MOV     #77402,R2       ;LOAD ACF=2 (READ-ONLY) PDR VALUE IN R2
10361  043542  012767  043574  134500  2$:     MOV     #5$,MMVEC       ;POINT MEM. MGMT. TRAP VECTOR TO 5$ BELOW
10362  043550  010267  126534                  MOV     R2,KIPDR4       ;LOAD ACF=2 INTO KIPDR4
10363  043554  010267  134030                  MOV     R2,UIPDR4       ;LOAD ACF=2 INTO UIPDR4
10364  043560  005010                  3$:     CLR     (R0)            ;CLEAR PHYS. LOC. 140000 USING PDR3
10365  043562  016767  134210  173572          MOV     PSW,$TMP0       ;SAVE PSW IN CASE OF ERROR
10366  043570  005211                  4$:     INC     (R1)            ;TRY TO WRITE USING PDR4 - SHOULD TRAP TO 5$
10367  043572  104000                          EMT                     ;MEM. MGMT. ABORT DID NOT OCCUR
10368                                                                   ;FOR TIGHTER SCOPE LOOP
10369                                                                   ;REPLACE ERROR CALL WITH
10370                                                                   ;"BR 3$" = 000772
10371  043574  062706  000004          5$:     ADD     #4,SP           ;RESTORE STACK POINTER
10372  043600  005710                          TST     (R0)            ;DID INSTRUCTION GET ABORTED & NOT EXECUTE
10373  043602  001401                          BEQ     6$
10374  043604  104000                          EMT                     ;INSTRUCTION WAS NOT ABORTED, LOC. GOT CHANGED
10375                                                                   ;FOR TIGHTER SCOPE LOOP
10376                                                                   ;REPLACE ERROR CALL WITH
```

```
10377                                                   ;"BR 3$" = 000764
10378  043606  016767  133760  173540  6$:     MOV     SR0,WASSR0      ;READ STATUS REG. 0
10379  043614  016767  133756  173534          MOV     SR2,WASSR2      ;READ STATUS REG. 2
10380  043622  020367  173526                  CMP     R3,WASSR0       ;DID SR0 REPORT READ-ONLY ERROR CORRECTLY?
10381  043626  001401                          BEQ     7$
10382  043630  104000                          EMT                     ;SR0 DID NOT REPORT R/O ERROR CORRECTLY
10383                                                   ;FOR TIGHTER SCOPE LOOP
10384                                                   ;REPLACE ERROR CALL WITH
10385                                                   ;"BR 3$" = 000752
10386  043632  012704  043570          7$:     MOV     #4$,R4          ;LOAD R4 WITH WHAT SR2 SHOULD READ
10387  043636  020467  173514                  CMP     R4,WASSR2       ;DID SR2 LOCKUP RIGHT VIRTUAL ADDR. (=4$)?
10388  043642  001401                          BEQ     8$
10389  043644  104000                          EMT                     ;SR2 DID NOT LOCKUP VIRTUAL ADDR. OF R/O ERROR
10390                                                   ;FOR TIGHTER SCOPE LOOP
10391                                                   ;REPLACE ERROR CALL WITH
10392                                                   ;"BR 3$" = 000744
10393  043646  042767  160000  133716  8$:     BIC     #160000,SR0     ;CLEAR THE ERROR BITS IN SR0
10394  043654  032767  140000  173500          BIT     #140000,$TMP0   ;HAS ACF=2 BEEN TESTED IN USER MODE?
10395  043662  001006                          BNE     9$              ;BRANCH IF YES
10396  043664  012703  020151                  MOV     #20151,R3       ;LOAD R3 WITH WHAT SR0 SHOULD READ-R/O, USER, PG.4
10397  043670  012767  140000  134100          MOV     #140000,PSW     ;GO TO USER MODE
10398  043676  000721                          BR      2$              ;REPEAT TEST IN USER MODE
10399  043700  005067  134072          9$:     CLR     PSW             ;GO BACK TO KERNEL MODE BEFORE LEAVING
10400  043704  012767  021276  134336          MOV     #T0250,MMVEC    ;RESTORE ADDRESS OF NORMAL MEMORY
10401                                                   ;MANAGEMENT ERROR ROUTINE TO MMVEC.
10402
10403
10404
10405                   ;NOTE:  MACRO MSG31A WAS DELETED AS IT DIDN'T APPLY TO F11.
10406
10407
10408
10409
10410
10411
10412
10413
10414  ;*****************************************************************************************
10415  ;*
10416  ;*      THE NEXT TWO (2) TESTS WILL BE CHECKING THE PAGE LENGTH
10417  ;*      COMPARATORS AND SOME MORE OF THE KT ERROR DETECTION
10418  ;*      AND STATUS LOGIC.  THE PAGE LENGTH FIELD (PLF) IN KERNEL
10419  ;*      PDR 4 IS VARIED AND FOR EVERY PLF, THREE (3) VIRTUAL
10420  ;*      ADDRESSES ARE READ.  WHILE USING BOTH UPWARD & DOWNWARD PAGE
10421  ;*      EXPANSION, ONE OF THOSE THREE VIRTUAL ADDRESSES WILL CAUSE A
10422  ;*      "PAGE LENGTH ABORT" WHILE THE OTHER TWO WON'T.
10423  ;*
10424  ;*      STATUS REGISTER 0 & 2 ARE CHECKED WHEN THE PAGE LENGTH
10425  ;*      ABORT DOES OCCUR TO SEE THAT THE ABORT IS REPORTED AND THAT
10426  ;*      THE VIRTUAL ADDRESS OF THE INSTRUCTION THAT CAUSED THE ABORT
10427  ;*      IS LOCKED UP.
10428  ;*
10429  ;*****************************************************************************************
10430
10431
10432
```

```
10433                                   ;*****************************************************************************
10434                                   ;TEST 403       PAGE LENGTH FAULTS-UPWARD EXPANSION
10435                                   ;*****************************************************************************
10436  043712                           TS403:
10437  043712  012767  077406  126366   1$:     MOV     #77406,KIPDR3   ;MAKE SURE PDR3 IS DESCRIBED AS R/W
10438  043720  012767  077406  126364           MOV     #77406,KIPDR5   ;MAKE SURE PDR5 IS DESCRIBED AS R/W
10439  043726  012700  044126                   MOV     #DALTB1,R0      ;DAL TABLE FOR VIRTUAL ADDR'S. TO SELECT PDR4.
10440  043732  012704  044144                   MOV     #PDRTB1,R4      ;PDR TABLE FOR PDR4 (COINCIDES WITH DAL TABLE).
10441  043736  012701  000006                   MOV     #6,R1           ;SET UP LOOP COUNTER.
10442  043742  012767  044104  134300           MOV     #9$,MMVEC       ;SETUP M.M. TRAP VECTOR FOR UNEXPECTED ABORTS
10443  043750  012706  001000                   MOV     #KERSTK,KSP     ;MAKE SURE STACK POINTER IS ALL SET UP
10444
10445                                   ;TEST NON-ABORT CASES (VBA < OR = PLF)
10446  043754  012467  126330           2$:     MOV     (R4)+,KIPDR4    ;LOAD KIPDR4 WITH PAGE LENGTH VALUE
10447  043760  005730                           TST     @(R0)+          ;ACCESS VIRTUAL ADDR. (VBA < OR = PLF)
10448                                           ;NO ABORT SHOULD OCCUR!!!
10449  043762  077104                           SOB     R1,2$           ;DONE?...NO- TEST NEXT COMBINATION OF DAL & PDR.
10450
10451                                   ;TEST ABORT CASES (VBA > PLF)
10452  043764  012701  000005           3$:     MOV     #5,R1           ;SET UP LOOP COUNTER.
10453  043770  012700  044162                   MOV     #DALTB2,R0      ;DAL TABLE
10454  043774  012704  044176                   MOV     #PDRTB2,R4      ;PDR TABLE
10455  044000  012767  044020  134242           MOV     #6$,MMVEC       ;SETUP M.M. TRAP VECTOR FOR EXPECTED ABORT
10456
10457  044006  012467  126276           4$:     MOV     (R4)+,KIPDR4    ;LOAD KIPDR4 WITH PAGE LENGHT VALUE
10458  044012  005730                   5$:     TST     @(R0)+          ;ACCESS VIRTUAL ADDR. (VBA > PLF - ABORT TO 6$)
10459  044014  001476                           BEQ     TS404
10460  044016  104000                           EMT                     ;EXPECTED PAGE LENGTH ABORT DID NOT OCCUR
10461                                           ;FOR TIGHTER SCOPE LOOP
10462                                           ;REPLACE ERROR CALL WITH
10463                                           ;"BR 5$" = 000776
10464  044020  012706  001000           6$:     MOV     #KERSTK,KSP     ;RESTORE STACK POINTER FOLLOWING ABORT
10465  044024  016767  133542  173322           MOV     SR0,WASSR0      ;READ M.M. STATUS REG. 0
10466  044032  016767  133540  173316           MOV     SR2,WASSR2      ;READ M.M. STATUS REG. 2
10467  044040  012702  040011                   MOV     #40011,R2       ;PUT EXPECTED SR0 CONTENTS IN R2
10468  044044  020267  173304                   CMP     R2,WASSR0       ;DID SR0 REPORT PG. LENGTH ABORT, PAGE 4, KERNEL?
10469  044050  001401                           BEQ     7$
10470  044052  104000                           EMT                     ;SR0 DID NOT REPORT PG. LENGTH ABORT CORRECTLY
10471                                           ;FOR TIGHTER SCOPE LOOP
10472                                           ;REPLACE ERROR CALL WITH
10473                                           ;"BR 5$" = 000757
10474  044054  012703  044012           7$:     MOV     #5$,R3          ;PUT EXPECTED SR2 CONTENTS IN R3
10475  044060  020367  173272                   CMP     R3,WASSR2       ;DID SR2 LOCKUP VIRT. ADDR. OF ABORTED INSTRUCTION?
10476  044064  001401                           BEQ     8$
10477  044066  104000                           EMT                     ;SR2 DID NOT LOCKUP VIRT. ADDR. OF ABORT CORRECTLY
10478                                           ;FOR TIGHTER SCOPE LOOP
10479                                           ;REPLACE ERROR CALL WITH
10480                                           ;"BR 5$" = 000751
10481  044070  042767  160000  133474   8$:     BIC     #160000,SR0     ;CLEAR ERROR BITS IN SR0
10482  044076  077135                           SOB     R1,4$           ;DONE?..NO - GET NEXT DAL & PDR PAIR
10483  044100  000167  000010                   JMP     10$             ;YES...
10484  044104  042767  160000  133460   9$:     BIC     #160000,SR0     ;CLEAR ERROR BITS IN SR0
10485  044112  104000                           EMT                     ;GOT PG. LENGTH ABORT BEFORE IT WAS EXPECTED
10486                                           ;FOR TIGHTER SCOPE LOOP
10487                                           ;REPLACE ERROR CALL WITH
10488                                           ;A "NOP" = 240
```

```
10489
10490  044114  012767  021276  134126  10$:    MOV     #T0250,MMVEC    ;RESTORE NORMAL M.M. TRAP HANDLER
10491                                                                   ;ADDRESS TO M.M. TRAP VECTOR
10492  044122  000167  000064                  JMP     TS404           ;GET TO NEXT TEST
10493
10494                                          ;DAL TABLE FOR UPWARD EXPANSION (NON-ABORT CASES)
10495  044126  100000                          DALTB1: 100000
10496  044130  106100                                  106100
10497  044132  102300                                  102300
10498  044134  102500                                  102500
10499  044136  113700                                  113700
10500  044140  104600                                  104600
10501  044142  117700                                  117700
10502
10503                                          ;PDR TABLE FOR KPDR4 (NON-ABORT CASES)
10504  044144  000006                          PDRTB1: 000006
10505  044146  052006                                  052006
10506  044150  045006                                  045006
10507  044152  052006                                  052006
10508  044154  074406                                  074406
10509  044156  025006                                  025006
10510  044160  077406                                  077406
10511
10512                                          ;DAL TABLE (ABORT CASES)
10513  044162  100100                          DALTB2: 100100
10514  044164  110100                                  110100
10515  044166  116600                                  116600
10516  044170  112700                                  112700
10517  044172  117000                                  117000
10518  044174  117700                                  117700
10519
10520                                          ;PDR TABLE (ABORT CASES)
10521  044176  000006                          PDRTB2: 000006
10522  044200  030406                                  030406
10523  044202  046406                                  046406
10524  044204  042006                                  042006
10525  044206  073406                                  073406
10526  044210  077006                                  077006
10527
10528
10529                                          ;*****************************************************************************
10530                                          ;TEST 404       PAGE LENGTH FAULTS-DOWNWARD EXPANSION
10531                                          ;*****************************************************************************
10532  044212                                  TS404:
10533  044212  012700  044412                  1$:     MOV     #DALTB3,R0      ;DAL TABLE FOR VIRTUAL ADDR'S. TO SELECT PDR4.
10534  044216  012704  044430                          MOV     #PDRTB3,R4      ;PDR TABLE FOR PDR4 (COINCIDES WITH DAL TABLE).
10535  044222  012701  000006                          MOV     #6,R1           ;SET UP LOOP COUNTER.
10536  044226  012767  044370  134014              MOV     #9$,MMVEC       ;SETUP M.M. TRAP VECTOR FOR UNEXPECTED ABORTS
10537  044234  012706  001000                          MOV     #KERSTK,KSP     ;MAKE SURE STACK POINTER IS ALL SET UP
10538
10539                                          ;TEST NON-ABORT CASES (VBA > OR = PLF)
10540  044240  012467  126044                  2$:     MOV     (R4)+,KIPDR4    ;LOAD KIPDR4 WITH PAGE LENGTH VALUE
10541  044244  005730                          TST     @(R0)+          ;ACCESS VIRTUAL ADDR. (VBA > OR = PLF)
10542                                                                   ;NO ABORT SHOULD OCCUR!!!
10543  044246  077104                          SOB     R1,2$           ;DONE?...NO- TEST NEXT COMBINATION OF DAL & PDR.
10544
```

```
10545                                          ;TEST ABORT CASES (VBA < PLF)
10546  044250  012701  000005                3$:     MOV     #5,R1           ;SET UP LOOP COUNTER.
10547  044254  012700  044446                        MOV     #DALTB4,R0      ;DAL TABLE
10548  044260  012704  044462                        MOV     #PDRTB4,R4      ;PDR TABLE
10549  044264  012767  044304  133756              MOV     #6$,MMVEC       ;SETUP M.M. TRAP VECTOR FOR EXPECTED ABORT
10550
10551  044272  012467  126012                4$:     MOV     (R4)+,KIPDR4    ;LOAD KIPDR4 WITH PAGE LENGHT VALUE
10552  044276  005730                        5$:     TST     @(R0)+          ;ACCESS VIRTUAL ADDR. (VBA < PLF - ABORT TO 6$)
10553  044300  001476                              BEQ     TS405
10554  044302  104000                              EMT                     ;EXPECTED PAGE LENGTH ABORT DID NOT OCCUR
10555                                                                         ;FOR TIGHTER SCOPE LOOP
10556                                                                         ;REPLACE ERROR CALL WITH
10557                                                                         ;"BR 5$" = 000776
10558  044304  012706  001000                6$:     MOV     #KERSTK,KSP     ;RESTORE STACK POINTER FOLLOWING ABORT
10559  044310  016767  133256  173036              MOV     SR0,WASSR0      ;READ M.M. STATUS REG. 0
10560  044316  016767  133254  173032              MOV     SR2,WASSR2      ;READ M.M. STATUS REG. 2
10561  044324  012702  040011                      MOV     #40011,R2       ;PUT EXPECTED SR0 CONTENTS IN R2
10562  044330  020267  173020                      CMP     R2,WASSR0       ;DID SR0 REPORT PG. LENGTH ABORT, PAGE 4, KERNEL?
10563  044334  001401                              BEQ     7$
10564  044336  104000                              EMT                     ;SR0 DID NOT REPORT PG. LENGTH ABORT CORRECTLY
10565                                                                       ;FOR TIGHTER SCOPE LOOP
10566                                                                       ;REPLACE ERROR CALL WITH
10567                                                                       ;"BR 5$" = 000757
10568  044340  012703  044276                7$:     MOV     #5$,R3          ;PUT EXPECTED SR2 CONTENTS IN R3
10569  044344  020367  173006                      CMP     R3,WASSR2       ;DID SR2 LOCKUP VIRT. ADDR. OF ABORTED INSTRUCTION?
10570  044350  001401                              BEQ     8$
10571  044352  104000                              EMT                     ;SR2 DID NOT LOCKUP VIRT. ADDR. OF ABORT CORRECTLY
10572                                                                       ;FOR TIGHTER SCOPE LOOP
10573                                                                       ;REPLACE ERROR CALL WITH
10574                                                                       ;"BR 5$" = 000751
10575  044354  042767  160000  133210  8$:     BIC     #160000,SR0     ;CLEAR ERROR BITS IN SR0
10576  044362  077135                              SOB     R1,4$           ;DONE?..NO - GET NEXT DAL & PDR PAIR
10577  044364  000167  000010                      JMP     10$             ;YES...
10578  044370  042767  160000  133174  9$:     BIC     #160000,SR0     ;CLEAR ERROR BITS IN SR0
10579  044376  104000                              EMT                     ;GOT PG. LENGTH ABORT BEFORE IT WAS EXPECTED
10580                                                                       ;FOR TIGHTER SCOPE LOOP
10581                                                                       ;REPLACE ERROR CALL WITH
10582                                                                       ;A "NOP" = 000240
10583
10584  044400  012767  021276  133642  10$:     MOV     #T0250,MMVEC    ;RESTORE NORMAL M.M. TRAP HANDLER
10585                                                                       ;ADDRESS TO M.M. TRAP VECTOR
10586  044406  000167  000064                      JMP     TS405           ;GET TO NEXT TEST
10587
10588                                          ;DAL TABLE FOR DOWNWARD EXPANSION (NON-ABORT CASES)
10589  044412  117700                        DALTB3: 117700
10590  044414  111600                                111600
10591  044416  115400                                115400
10592  044420  115200                                115200
10593  044422  104000                                104000
10594  044424  113100                                113100
10595  044426  100000                                100000
10596
10597                                          ;PDR TABLE (NON-ABORT CASES)
10598  044430  077416                        PDRTB3: 77416
10599  044432  025416                                25416
10600  044434  032416                                32416
```

```
10601  044436  025416                          25416
10602  044440  003016                          03016
10603  044442  052416                          52416
10604  044444  000016                          00016
10605
10606                                  ;DAL TABLE (ABORT CASES)
10607  044446  117600                  DALTB4: 117600
10608  044450  107600                          107600
10609  044452  101100                          101100
10610  044454  105000                          105000
10611  044456  100700                          100700
10612  044460  100000                          100000
10613
10614                                  ;PDR TABLE (ABORT CASES)
10615  044462  077416                  PDRTB4: 77416
10616  044464  047016                          47016
10617  044466  031016                          31016
10618  044470  035416                          35416
10619  044472  004016                          04016
10620  044474  000416                          00416
10621
10622
10623
10624                                  ;*****************************************************************************************
10625                                  ;TEST 405       SR2 BIT TEST
10626                                  ;*****************************************************************************************
10627  044476                          TS405:
10628  044476  012767  001400  125642  1$:     MOV     #1400,KIPAR3    ;BE SURE PAR3 IS MAPPED TO 24-28K
10629  044504  012767  001400  125636          MOV     #1400,KIPAR4    ;BE SURE PAR4 IS MAPPED TO 24-28K
10630  044512  012767  077406  125566          MOV     #77406,KIPDR3   ;MAP PAGE 3  128 BLOCKS, R/W
10631  044520  012767  077402  125562          MOV     #77402,KIPDR4   ;MAP PAGE 4  128 BLOCKS, READ-ONLY
10632  044526  012700  060002                  MOV     #60002,R0       ;LOAD R0 WITH VIRTUAL ADDR. WHICH USES PDR3
10633  044532  012701  100002                  MOV     #100002,R1      ;LOAD R1 WITH VIRTUAL ADDR. WHICH USES PDR4
10634  044536  012767  044564  133504          MOV     #3$,MMVEC       ;SET M.M. TRAP VECTOR TO 3$
10635  044544  012720  010727          2$:     MOV     #010727,(R0)+   ;LOAD "MOV PC,(PC)+" INSTRUCTION AT ADDR.
10636  044550  005020                  CLR     (R0)+           ;       REACHED THRU PDR/PAR 4.
10637  044552  012720  000137                  MOV     #000137,(R0)+   ;LOAD "JMP @#3$" INSTRUCTION AT VIRT. ADDR.
10638  044556  012710  044564                  MOV     #3$,(R0)        ;       IN CASE R/O VIOL. DOES NOT ABORT
10639  044562  010107                  MOV     R1,PC           ;TRANSFER PROGRAM EXECUTION TO "PAGE 4 INSTRUCTIONS"
10640  044564  012706  001000          3$:     MOV     #KERSTK,KSP     ;RESTORE STACK POINTER
10641  044570  016767  133002  172560          MOV     SR2,WASSR2      ;READ CONTENTS OF STATUS REG 2
10642  044576  020167  172554                  CMP     R1,WASSR2       ;WAS ADDR. OF "RELOCATED - R/O ABORT" LOCKED UP?
10643  044602  001401                  BEQ     4$
10644  044604  104000                  EMT                             ;SR2 DID NOT LOCK UP VIRTUAL ADDR. OF R/O VIOL.
10645                                                                  ;FOR TIGHTER SCOPE LOOP
10646                                                                  ;REPLACE ERROR CALL WITH
10647                                                                  ;"BR 2$" = 000757
10648  044606  042767  160000  132756  4$:     BIC     #160000,SR0     ;CLEAR THE ERROR BITS IN SR0
10649  044614  060101                  ADD     R1,R1           ;SETUP TO FORM NEXT VIRTUAL ADDRESS
10650  044616  010100                  MOV     R1,R0           ;SETUP R0 TO FORM NEXT VIRT. ADDR. TO LOAD
10651  044620  052701  100000                  BIS     #100000,R1      ;FORM VIRTUAL ADDR. THAT SHOULD BE LOCKED UP NEXT
10652  044624  052700  060000                  BIS     #60000,R0       ;POINT R0 TO NEXT VIRT. ADDR. TO LOAD
10653  044630  020127  110000                  CMP     R1,#110000      ;HAVE ALL VBA'S 100000-110000 BEEN TESTED?
10654  044634  101743                  BLOS    2$              ;BRANCH IF NO
10655
10656  044636  012767  077406  125444          MOV     #77406,KIPDR4   ;RESTORE PDR4 TO R/W ACCESS
```

```
10657  044644  012767  021276  133376          MOV     #TO250,MMVEC    ;RESTORE ADDRESS OF NORMAL M.M.
10658                                                                   ;TRAP HANDLER TO M.M. VECTOR
10659
10660
10661                                  ;*************************************************************************************
10662                                  ;TEST 406       MORE CHECKS OF SR0 & SR2
10663                                  ;*************************************************************************************
10664  044652                          TS406:
10665  044652                          1$:
10666  044652  032737  000001  001020          BIT     #1, @#$ENV      ;ARE WE RUNNING UNDER APT
10667  044660  001403                          BEQ     70$             ;IF NO THEN DO TEST
10668  044662  005737  001006                  TST     @#$PASS         ;IS THIS FIRST PASS
10669  044666  001166                          BNE     TS407           ;IF NO THEN SHIP TO NEXT TEST
10670  044670                          70$:
10671  044670  012767  001400  125454          MOV     #1400,KIPAR5    ;MAP KERNEL PAGE 5 TO 24-28K
10672  044676  012767  000406  125404          MOV     #406,KIPDR4     ;SETUP PDR4 FOR PAGE LENGTH ABORT
10673  044704  012767  077402  125400          MOV     #77402,KIPDR5   ;SETUP PDR5 FOR R/O ABORT
10674  044712  016767  132660  172436  2$:     MOV     SR2,WASSR2      ;READ SR2 TO SEE IF ITS TRACKING
10675  044720  012701  044712                  MOV     #2$,R1          ;PUT EXPECTED VIRTUAL PC IN R1
10676  044724  020167  172426                  CMP     R1,WASSR2       ;DID SR2 CONTAIN VIRTUAL PC AT 2$?
10677  044730  001401                          BEQ     4$
10678  044732  104000                          EMT                     ;SR2 NOT TRACKING CORRECTLY
10679                                                                   ;FOR TIGHTER SCOPE LOOP
10680                                                                   ;REPLACE ERROR CALL WITH
10681                                                                   ;"BR 2$" = 000767
10682  044734  016767  132636  172414  4$:     MOV     SR2,WASSR2      ;READ SR2 TO SEE IF ITS TRACKING
10683  044742  012701  044734                  MOV     #4$,R1          ;PUT EXPECTED VIRTUAL PC IN R1
10684  044746  020167  172404                  CMP     R1,WASSR2       ;DID SR2 CONTAIN VIRTUAL PC AT 4$
10685  044752  001401                          BEQ     6$
10686  044754  104000                          EMT                     ;SR2 NOT TRACKING CORRECTLY
10687                                                                   ;FOR TIGHTER SCOPE LOOP
10688                                                                   ;REPLACE ERROR CALL WITH
10689                                                                   ;"BR 4$" = 000767
10690  044756  012767  044774  133264  6$:     MOV     #7$,MMVEC       ;PUT ADDRESS OF 7$ IN M.M. TRAP VECTOR
10691  044764  005067  172374                  CLR     $TMP1           ;CLEAR ERROR INDICATOR
10692  044770  005237  100500                  INC     @#100500        ;CAUSE PAGE LENGTH ABORT - TRAP TO 7$
10693  044774  012706  001000          7$:     MOV     #KERSTK,KSP     ;RESTORE STACK POINTER AFTER ABORT
10694  045000  016767  132566  172354          MOV     SR0,$TMP0       ;SAVE SR0'S INFORMATION ON PG. LGTH. ABORT
10695  045006  016767  132564  172352          MOV     SR2,$TMP2       ;SAVE SR2'S INFORMATION ON PG. LGTH. ABORT
10696  045014  012767  045026  133226          MOV     #8$,MMVEC       ;PUT ADDRESS OF 8$ IN M.M. TRAP VECTOR
10697  045022  005237  120000                  INC     @#120000        ;CAUSE R/O ABORT - TRAP TO 8$
10698  045026  012706  001000          8$:     MOV     #KERSTK,KSP     ;RESTORE STACK POINTER AFTER ABORT
10699  045032  016767  132534  172314          MOV     SR0,WASSR0      ;READ SR0 FOLLWOING SECOND KT ABORT
10700  045040  016767  132532  172310          MOV     SR2,WASSR2      ;READ SR2 FOLLOWING SECOND KT ABORT
10701  045046  026767  172310  172300          CMP     $TMP0,WASSR0    ;IS SR0 STILL HOLDING INFO ON FIRST ABORT?
10702  045054  001402                          BEQ     9$              ;BRANCH IF YES
10703  045056  005267  172302                  INC     $TMP1           ;SET ERROR INDICATOR
10704  045062  026767  172300  172266  9$:     CMP     $TMP2,WASSR2    ;DOES SR2 STILL HOLD PC OF FIRST ABORT?
10705  045070  001402                          BEQ     10$             ;BRANCH IF YES
10706  045072  005267  172266                  INC     $TMP1           ;SET ERROR INDICATOR
10707  045076  005767  172262          10$:    TST     $TMP1           ;WERE SR0 OR SR2 CHANGED BY A SECOND ABORT?
10708  045102  001401                          BEQ     11$
10709  045104  104000                          EMT                     ;ONE OF STATUS REGS. CHANGED BY SECOND ABORT
10710                                                                   ;FOR TIGHTER SCOPE LOOP
10711                                                                   ;REPLACE ERROR CALL WITH
10712                                                                   ;"BR 6$" = 000726
```

```
10713  045106  005067  172252          11$:    CLR     $TMP1           ;CLEAR ERROR INDICATOR
10714  045112  000005                  RESET                           ;EXECUTE A RESET, APPLYING AN "INIT"
10715  045114  005067  132452          CLR     SR0
10716  045120  016767  132446  172226  MOV     SR0,WASSR0      ;READ SR0
10717  045126  005767  172222          TST     WASSR0          ;WAS SR0 CLEARED BY THE RESET?
10718  045132  001402                  BEQ     12$             ;BRANCH IF YES
10719  045134  005267  172224          INC     $TMP1           ;SR0 NOT CLEARED BY A RESET
10720  045140  016767  132432  172210  12$:    MOV     SR2,WASSR2      ;READ SR2
10721  045146  022767  045140  172202          CMP     #12$,WASSR2     ;WAS SR2 UNLOCKED BY A RESET?
10722  045154  001402                  BEQ     13$             ;BRANCH IF YES
10723  045156  005267  172202          INC     $TMP1           ;SR2 NOT UNLOCKED BY A RESET
10724  045162  005767  172176          13$:    TST     $TMP1           ;WERE SR0 & SR2 BOTH "RESET" BY A RESET?
10725  045166  001401                  BEQ     14$
10726  045170  104000                  EMT                             ;SR0 OR SR2 NOT "RESET" BY A RESET
10727                                                                   ;FOR TIGHTER SCOPE LOOP
10728                                                                   ;REPLACE ERROR CALL WITH
10729                                                                   ;"BR 6$" = 000676
10730  045172  012767  000001  132372  14$:    MOV     #1,SR0          ;TURN MEMORY MANAGEMENT BACK ON
10731  045200  016767  132372  172150  15$:    MOV     SR2,WASSR2      ;READ SR2 TO SEE IF ITS TRACKING AGAIN
10732  045206  012701  045200          MOV     #15$,R1         ;PUT EXPECTED VIRTUAL PC IN R1
10733  045212  020167  172140          CMP     R1,WASSR2       ;DID SR2 CONTAIN VIRTUAL PC AT 15$
10734  045216  001401                  BEQ     16$
10735  045220  104000                  EMT                             ;SR2 NOT TRACKING CORRECTLY
10736                                                                   ;FOR TIGHTER SCOPE LOOP
10737                                                                   ;REPLACE ERROR CALL WITH
10738                                                                   ;"BR 6$" = 000663
10739  045222  012767  077406  125060  16$:    MOV     #77406,KIPDR4   ;RESET PDR4 TO 128 BLKS, R/W
10740  045230  012767  077406  125054          MOV     #77406,KIPDR5   ;RESET PDR5 TO 128 BLKS, R/W
10741  045236  012767  021276  133004          MOV     #TO250,MMVEC    ;RESTORE ADDRESS OF NORMAL MEMORY
10742                                                                   ;MANAGEMENT TRAP ROUTINE TO M.M. VECTOR
10743
10744
10745                          ;*****************************************************************************************
10746                          ;TEST 407       USER ABORT PICKS UP KERNEL SPACE VECTOR
10747                          ;*****************************************************************************************
10748  045244                  TS407:
10749  045244  004767  002614  1$:     JSR     PC,TOFF         ;TURN OFF T-BIT TRAPPING FOR THIS TEST
10750  045250  005067  132522  2$:     CLR     PSW             ;GO TO KERNEL MODE
10751  045254  012706  001000          MOV     #KERSTK,KSP     ;SETUP KERNEL STACK PTR.
10752  045260  012767  001400  132352  MOV     #1400,UIPAR0    ;MAP USER PAGE 0 TO 24K
10753  045266  012737  045336  000004  MOV     #4$,@#4         ;LOAD KERNEL VECTOR 4 (LOC.4) WITH 4$
10754  045274  012737  000340  000006  MOV     #340,@#6        ;LOAD VECTOR+2 WITH NEW PSW
10755  045302  012767  140000  132466  MOV     #140000,PSW     ;GO TO USER MODE
10756  045310  012706  000600          MOV     #USESTK,USP     ;SETUP USER STACK PTR.
10757  045314  012737  045334  000004  MOV     #3$,@#4         ;LOAD USER VECTOR 4 (LOC. 60004) WITH 3$
10758  045322  012737  000340  000006  MOV     #340,@#6        ;LOAD VECTOR+2 WITH NEW PSW
10759  045330  005767  112444          TST     160000          ;CAUSE TIMEOUT ERROR TRAP TO "4"
10760                                                          ;SHOULD PICK UP NEW PC-4$ FROM KERNEL
10761                                                          ;LOC. 4, NOT PC=3$ FROM USER LOC. 4 (=60004)
10762  045334                  3$:
10763  045334  104000          EMT                             ;DID NOT TRAP THRU KERNEL SPACE
10764                                                          ;FOR TIGHTER SCOPE LOOP
10765                                                          ;REPLACE ERROR CALL WITH
10766                                                          ;"BR 2$" = 000740
10767  045336  005067  132434  4$:     CLR     PSW             ;BE SURE BACK IN KERNEL MODE
10768  045342  012706  001000          MOV     #KERSTK,KSP     ;RESTORE KERNEL S.P. IN CASE IT CHANGED
```

```
10769  045346  005067  132266          CLR     UIPAR0          ;REMAP USER PAGE 0 TO 0-4K
10770  045352  012767  140000  132416  MOV     #140000,PSW     ;GO TO USER MODE
10771  045360  012706  000600          MOV     #USESTK,USP     ;RESTORE USER STACK POINTER
10772  045364  005067  132406          CLR     PSW             ;GO BACK TO KERNEL MODE
10773  045370  012737  021256  000004  MOV     #TO4,@#4        ;RESTORE ADDR. OF NORMAL CPU TRAP HANDLER TO 4
10774  045376  004767  002516          JSR     PC,TON          ;TURN T-BIT TRAPPING BACK ON
10775
10776                                  ;*****************************************************************************
10777                                  ;TEST 410       RTI IN USER MODE DOES NOT CHANGE PSW
10778                                  ;*****************************************************************************
10779  045402                          TS410:
10780
10781  045402  012702  170000          MOV     #170000,R2      ;LOAD "PRESENT & EXPECTED" PSW VALUE INTO R2
10782  045406  010267  132364  2$:     MOV     R2,PSW          ;GO TO USER MODE-PRIORITY 0
10783  045412  012746  000340          MOV     #340,-(SP)      ;PUT A NEW PSW (PRIORITY=7) ON STACK
10784  045416  012746  045424          MOV     #3$,-(SP)       ;PUT NEW PC ON THE STACK
10785  045422  000002                  RTI                     ;DO AN RTI FROM USER MODE
10786  045424  016701  132346  3$:     MOV     PSW,R1          ;READ NEW PSW INTO R1
10787  045430  042701  007437          BIC     #7437,R1        ;MASK OFF COND. CODE, T-BIT, AND UNUSED BITS
10788  045434  005067  132336          CLR     PSW             ;GO BACK TO KERNEL MODE
10789  045440  020201                  CMP     R2,R1           ;DID PSW STAY IN USER, PRIORITY=0?
10790  045442  001401                  BEQ     TS411
10791  045444  104000                  EMT                     ;PSW CHANGED BY AN RTI FROM USER
10792                                                          ;FOR A TIGHTER SCOPE LOOP
10793                                                          ;REPLACE ERROR CALL WITH
10794                                                          ;"BR=2$" = 000760
10795
10796
10797                                  ;*****************************************************************************
10798                                  ;TEST 411       KT ERROR SERVICED BEFORE TIMEOUT ERROR
10799                                  ;*****************************************************************************
10800  045446                          TS411:
10801  045446  012705  077006  1$:     MOV     #77006,R5       ;LOAD PDR7 DATA INTO R5
10802  045452  010567  124640          MOV     R5,KIPDR7       ;MAP PAGE 7 R/W  PLF=176
10803  045456  012737  045476  000004  MOV     #3$,@#4         ;SET CPU TRAP VECTOR TO ADDRESS OF 3$
10804  045464  012737  045500  000250  MOV     #4$,@#250       ;SET M.M. TRAP VECTOR TO ADDRESS OF 4$
10805  045472  005237  177700  2$:     INC     @#177700        ;CAUSE PLF ABORT AND POTENTIAL TIMEOUT
10806  045476                  3$:
10807  045476  104000                  EMT                     ;TRAPPED THRU CPU TRAP VECTOR BUT SHOULDN'T HAVE
10808                                                          ;FOR TIGHTER SCOPE LOOP
10809                                                          ;REPLACE ERROR CALL WITH
10810                                                          ;"BR 2$" = 000776
10811  045500  012706  001000  4$:     MOV     #KERSTK,KSP     ;RESTORE STACK POINTER AFTER TRAPPING
10812  045504  016767  132062  171642  MOV     SR0,WASSR0      ;READ STATUS REG.0
10813  045512  016767  132060  171636  5$:     MOV     SR2,WASSR2      ;READ STATUS REG. 2
10814  045520  012700  040017          MOV     #40017,R0       ;LOAD EXPECTED SR0 CONTENTS INTO R0
10815  045524  020067  171624          CMP     R0,WASSR0       ;SR0 PLF ERROR BIT SET?
10816  045530  001401                  BEQ     6$
10817  045532  104000                  EMT                     ;SR0 DIDN'T REPORT PLF ERROR
10818                                                          ;FOR TIGHTER SCOPE LOOP
10819                                                          ;REPLACE ERROR CALL WITH
10820                                                          ;"BR 2$" = 000741
10821  045534  012701  045472  6$:     MOV     #2$,R1          ;LOAD EXPECTED SR2 CONTENTS INTO R1
10822  045540  020167  171612          CMP     R1,WASSR2       ;WAS SR2 LOCKED BY PLF ABORT?
10823  045544  001401                  BEQ     7$
10824  045546  104000                  EMT                     ;SR2 DIDN'T LOCK UP VIRTUAL ADDRESS
```

```
10825                                                           ;FOR TIGHTER SCOPE LOOP
10826                                                           ;REPLACE ERROR CALL WITH
10827                                                           ;"BR 2$" = 000741
10828  045550  042767  160000  132014  7$:     BIC     #160000,SR0     ;CLEAR ERROR BITS THAT WERE SET IN SR0
10829  045556  012737  021256  000004          MOV     #T04,@#4        ;RESTORE ADDRESS OF NORMAL CPU TRAP HANDLER
10830  045564  012737  021276  000250          MOV     #T0250,@#250    ;RESTORE ADDRESS OF NORMAL M.M. TRAP HANDLER
10831  045572  012767  077406  124516          MOV     #77406,KIPDR7   ;REMAP PAGE 7 TO READ/WRITE PLF=177
10832
10833
10834                                   ;*************************************************************************************
10835                                   ;TEST 412       PC & PSW SAVED FOR KT ERROR DURING SERVICE OF TIMEOUT ERROR
10836                                   ;*************************************************************************************
10837  045600
10838  045600  004767  002260          1$:     JSR     PC,TOFF         ;TURN T-BIT TRAPPING OFF FOR THIS TEST
10839  045604  012767  001400  132034          MOV     #1400,UIPAR3    ;MAP USER PAGE 3 TO 24-28K
10840  045612  012767  001400  132030          MOV     #1400,UIPAR4    ;MAP USER PAGE 4 TO 24-28K
10841  045620  012767  077402  131760          MOV     #77402,UIPDR3   ;MAP USER PAGE 3 READ-ONLY
10842  045626  012767  077406  131754          MOV     #77406,UIPDR4   ;MAP USER PAGE 4 READ/WRITE
10843  045634  012737  045702  000004          MOV     #4$,@#4         ;LOAD ADDRESS OF 4$ IN CPU (TIMEOUT) VECTOR
10844  045642  012737  140017  000006          MOV     #140017,@#6     ;LOAD PSW THAT SHOULD BE PUT ON STACK IN VECTOR+2
10845  045650  012737  045702  000250          MOV     #4$,@#250       ;LOAD ADDRESS OF 4$ IN M.M. TRAP VECTOR
10846  045656  012737  000340  000252          MOV     #340,@#252      ;LOAD A KERNEL PSW IN MMVEC+2
10847  045664  012767  140000  132104  2$:     MOV     #140000,PSW     ;GO TO USER MODE
10848  045672  012706  100002                  MOV     #100002,USP     ;SET USER STACK PTR. SO SECOND PUSH IS IN PG. 3
10849  045676  005737  177700          3$:     TST     @#177700        ;CAUSE TIMEOUT ERROR THAT WILL CAUSE
10850                                                                  ;R/O ERROR WHEN TRY TO SAVE OLD PC
10851  045702  016601  000002          4$:     MOV     2(KSP),R1       ;PUT PSW SAVED ON KERNEL STACK INTO R1
10852  045706  011603                          MOV     (KSP),R3        ;PUT PC SAVED ON KERNEL STACK INTO R3
10853  045710  016767  131656  171436          MOV     SR0,WASSR0      ;READ THE CONTENTS OF M.M. STATUS REG. 0
10854  045716  016767  131654  171432          MOV     SR2,WASSR2      ;READ THE CONTENTS OF M.M. STATUS REG. 2
10855  045724  042767  160000  131640          BIC     #160000,SR0     ;CLEAR THE ERROR BITS IN SR0
10856  045732  005067  132040                  CLR     PSW             ;BE SURE IN KERNEL MODE
10857  045736  012706  001000                  MOV     #KERSTK,KSP     ;RESTORE KERNEL STACK POINTER
10858  045742  012767  140000  132026          MOV     #140000,PSW     ;GO TO USER MODE
10859  045750  012706  000600                  MOV     #USESTK,USP     ;RESTORE USER STACK POINTER
10860  045754  005067  132016                  CLR     PSW             ;GO BACK TO KERNEL MODE
10861  045760  005067  171376                  CLR     $TMP0           ;CLEAR ERROR INDICATOR
10862  045764  020127  170017                  CMP     R1,#170017      ;WAS THE PSW SAVED THE ONE PICKED UP BY THE
10863                                                                  ;TIMEOUT TRAP FROM ERRVEC+2?
10864                                                                  ;VALUE 170017 = PSW FROM LOC. 6 WITH
10865                                                                  ;PREVIOUS MODE BITS = USER
10866  045770  001402                          BEQ     5$              ;BRANCH IF YES
10867  045772  005267  171364                  INC     $TMP0           ;WRONG PSW SAVED DURING "DOUBLE ERROR" SEQUENCE
10868  045776  020327  045702          5$:     CMP     R3,#3$+4        ;WAS THE PC AT THE TIME OF THE TIMEOUT ERROR
10869                                                                  ;SAVED ON THE STACK?
10870  046002  001402                          BEQ     6$              ;BRANCH IF YES
10871  046004  005267  171352                  INC     $TMP0           ;WRONG PC SAVED DURING TRAP SEQUENCE
10872  046010  026727  171340  020147  6$:     CMP     WASSR0,#20147   ;DID SR0 REPORT - USER, PAGE 3, R/O ABORT?
10873  046016  001402                          BEQ     7$              ;BRANCH IF YES
10874  046020  005267  171336                  INC     $TMP0           ;SR0 DID NOT REPORT R/O ABORT
10875  046024  026727  171326  045676  7$:     CMP     WASSR2,#3$      ;DID SR2 LOCK UP VIRTUAL ADDR. OF LAST
10876                                                                  ;INSTRUCTION SUCCESSFULLY FETCHED?
10877  046032  001402                          BEQ     8$              ;BRANCH IF YES
10878  046034  005267  171322                  INC     $TMP0           ;SR2 DID NOT LOCK UP ADDR. OF TIMEOUT INST.
10879  046040  005767  171316          8$:     TST     $TMP0           ;ANY "ERRORS" DURING TRAP SEQUENCE?
10880  046044  001401                          BEQ     9$
```

```
10881  046046  104000                          EMT                     ;THE WRONG PC OR PSW WERE SAVED
10882                                                                   ;OR SR0 OR SR2 DID NOT REPORT R/O
10883                                                                   ;ERROR DURING TIMEOUT - KT TRAP
10884                                                                   ;SEQUENCE
10885                                                                   ;FOR TIGHTER SCOPE LOOP
10886                                                                   ;REPLACE ERROR CALL WITH
10887                                                                   ;'BR 2$" = 000710
10888  046050  012737  021256  000004  9$:     MOV     #T04,@#4        ;RESTORE ADDRESS OF NORMAL CPU TRAP HANDLER
10889  046056  012737  000340  000006          MOV     #340,@#6        ;RELOAD ERRVEC+2 WITH KERNEL PSW
10890  046064  012737  021276  000250          MOV     #T0250,@#250    ;RESTORE ADDRESS OF NORMAL M.M. TRAP HANDLER
10891  046072  012767  077406  131506          MOV     #77406,UIPDR3   ;REMAP USER PAGE 3 READ/WRITE
10892  046100  004767  002014                  JSR     PC,TON          ;TURN T-BIT TRAPPING BACK ON
10893                                  ;*******************************************************************************
10894                                  ;*
10895                                  ;*      THIS GROUP OF TESTS WILL TEST ALL THE LOGIC ASSOCIATED WITH
10896                                  ;*      THE "MOVE FROM PREVIOUS" AND MOVE TO PREVIOUS" INSTRUCTIONS.
10897                                  ;*
10898                                  ;*******************************************************************************
10899
10900
10901                                  ;*******************************************************************************
10902                                  ;TEST 413       MOVE FROM PREVIOUS (USER) I-SPACE
10903                                  ;*******************************************************************************
10904  046104                          TS413:
10905  046104  005067  124230          1$:     CLR     KIPAR0          ;MAP KERNEL PAGE 0 TO 0-4K
10906  046110  012767  000200  124224          MOV     #200,KIPAR1     ;MAP KERNEL PAGE 1 TO 4-8K
10907  046116  012767  000400  124220          MOV     #400,KIPAR2     ;MAP KERNEL PAGE 2 TO 8-12K
10908  046124  012767  000600  124214          MOV     #600,KIPAR3     ;MAP KERNEL PAGE 3 TO 12-16K
10909  046132  012767  001400  124210          MOV     #1400,KIPAR4    ;MAP KERNEL PAGE 4 TO 24-28K
10910  046140  012767  007600  124210          MOV     #7600,KIPAR7    ;MAP KERNEL PAGE 7 TO THE I/O PAGE
10911  046146  012700  077406                  MOV     #77406,R0       ;MAKE ALL KERNEL I-SPACE PAGES RESIDENT
10912                                                                   ;READ/WRITE, LENGTH 200 BLOCKS
10913  046152  012702  000010                  MOV     #10,R2          ;SET LOOP COUNTER TO 8
10914  046156  012701  172300                  MOV     #KIPDR0,R1      ;PUT ADDRESS OF FIRST PDR IN R1
10915  046162  010021                  2$:     MOV     R0,(R1)+        ;LOAD PDR WITH 77406
10916  046164  077202                          SOB     R2,2$           ;LOOP TO 2$ UNTIL ALL PDRS LOADED
10917  046166  012702  000010                  MOV     #10,R2          ;SET LOOP COUNTER TO 8
10918  046172  012701  177600                  MOV     #UIPDR0,R1      ;PUT ADDRESS OF FIRST PDR IN R1
10919  046176  010021                  3$:     MOV     R0,(R1)+        ;LOAD PDR WITH 77406
10920  046200  077202                          SOB     R2,3$           ;LOOP TO 3$ UNTIL ALL PDRS LOADED
10921  046202  012767  000000  131430          MOV     #000,UIPAR0     ;MAP USER I PAGE 0 TO 0-4K
10922  046210  012767  000200  131424          MOV     #200,UIPAR1     ;MAP USER I PAGE 1 TO 4-8K
10923  046216  012767  000400  131420          MOV     #400,UIPAR2     ;MAP USER I PAGE 2 TO 8-12K
10924  046224  012767  000600  131414          MOV     #600,UIPAR3     ;MAP USER I PAGE 3 TO 12-16K
10925  046232  012767  007600  131416          MOV     #7600,UIPAR7    ;MAP USER I PAGE 7 TO THE I/O PAGE
10926  046240                          4$:
10927  046240  012767  077406  124042          MOV     #77406,KIPDR4   ;KERNEL I-SPACE PAGE 4 READ/WRITE
10928  046246  012767  001400  124074          MOV     #1400,KIPAR4    ;MAP KERNEL I PAGE 4 TO 24K
10929  046254  012767  001400  131366          MOV     #1400,UIPAR4    ;MAP USER I PAGE 4 TO 24K
10930  046262  012700  036514                  MOV     #36514,R0       ;LOAD DATA PATTERN INTO R0
10931  046266  010037  100000                  MOV     R0,@#100000     ;LOAD DATA PATTERN INTO PHY 140000
10932  046272  012767  046570  131750          MOV     #23$,MMVEC      ;SET M.M. VECTOR TO 23$
10933  046300  105067  124004                  CLRB    KIPDR4          ;MAKE KERNEL I-SPACE PAGE 4 NON-RESIDENT
10934                                          ;THE FOLLOWING WILL TEST DSTM=0 MFPI
10935                                          ;
10936  046304  012767  030340  131464  5$:     MOV     #030340,PSW     ;MAKE PREVIOUS MODE USER
```

```
10937  046312  006506                  6$:     MFPI    USP             ;PUT USER STACK POINTER ON KERNEL
10938                                                                   ;STACK
10939  046314  022706  001000                  CMP     #KERSTK,KSP     ;WAS SOMETHING PUSHED ON STACK AT 6$
10940  046320  001405                         BEQ     7$              ;BRANCH IF NOTHING WAS PUSHED
10941  046322  012600                         MOV     (KSP)+,R0       ;POP KERNEL STACK INTO R0
10942  046324  012701  000600                 MOV     #USESTK,R1      ;EXPECTING TO GET 700 AS USP
10943  046330  020001                         CMP     R0,R1           ;DID YOU GET THE RIGHT POINTER?
10944  046332  001401                         BEQ     8$
10945  046334                           7$:
10946  046334  104000                         EMT                     ;WRONG THING WAS PUSHED ON STACK
10947                                                                   ;FOR TIGHTER SCOPE LOOP
10948                                                                   ;REPLACE ERROR CALL WITH
10949                                                                   ;"BR 5$" = 000763
10950  046336                           8$:     ;THE FOLLOWING WILL TEST DSTM=1 MFPI.
10951  046336  012700  036514                 MOV     #36514,R0       ;RELOAD DATA PATTERN IN R0
10952  046342  012767  030340  131426  9$:     MOV     #030340,PSW     ;MAKE PREVIOUS MODE USER
10953  046350  012702  100000                 MOV     #100000,R2      ;LOAD VIRTUAL ADDRESS INTO R2
10954  046354  006512                         MFPI    (R2)            ;READ FROM PHYSICAL 140000
10955  046356  012601                         MOV     (KSP)+,R1       ;POP KERNEL STACK INTO R1
10956  046360  020001                         CMP     R0,R1           ;WAS DATA FETCHED SAME AS STORED
10957  046362  001401                         BEQ     10$
10958  046364  104000                         EMT                     ;WRONG DATA WAS FETCHED
10959                                                                   ;FOR TIGHTER SCOPE LOOP
10960                                                                   ;REPLACE ERROR CALL WITH
10961                                                                   ;"BR 9$" = 000766
10962  046366                           10$:    ;THE FOLLOWING WILL TEST DSTM=2 MFPI.
10963  046366  012767  030340  131402  11$:    MOV     #030340,PSW     ;MAKE PREVIOUS MODE USER
10964  046374  012702  100000                 MOV     #100000,R2      ;LOAD VIRTUAL ADDRESS INTO R2
10965  046400  006522                         MFPI    (R2)+           ;READ FROM PHYSICAL 140000
10966  046402  012601                         MOV     (KSP)+,R1       ;POP KERNEL STACK INTO R1
10967  046404  020001                         CMP     R0,R1           ;WAS DATA FETCHED SAME AS STORED
10968  046406  001401                         BEQ     12$
10969  046410  104000                         EMT                     ;WRONG DATA WAS FETCHED
10970                                                                   ;FOR TIGHTER SCOPE LOOP
10971                                                                   ;REPLACE ERROR CALL WITH
10972                                                                   ;"BR 11$" = 000766
10973  046412                           12$:    ;THE FOLLOWING WILL TEST DSTM=3 MFPI.
10974  046412  012767  030340  131356  13$:    MOV     #030340,PSW     ;MAKE PREVIOUS MODE USER
10975  046420  006537  100000                 MFPI    @#100000        ;READ FROM PHYSICAL 140000
10976  046424  012601                         MOV     (KSP)+,R1       ;POP KERNEL STACK INTO R1
10977  046426  020001                         CMP     R0,R1           ;WAS DATA FETCHED SAME AS STORED
10978  046430  001401                         BEQ     14$
10979  046432  104000                         EMT                     ;WRONG DATA WAS FETCHED
10980                                                                   ;FOR TIGHTER SCOPE LOOP
10981                                                                   ;REPLACE ERROR CALL WITH
10982                                                                   ;"BR 13$" = 000767
10983  046434                           14$:    ;THE FOLLOWING WILL TEST DSTM=4 MFPI.
10984  046434  012767  030340  131334  15$:    MOV     #030340,PSW     ;MAKE PREVIOUS MODE USER
10985  046442  012702  100002                 MOV     #100002,R2      ;LOAD VIRTUAL ADDRESS INTO R2
10986  046446  006542                         MFPI    -(R2)           ;READ FROM PHYSICAL 140000
10987  046450  012601                         MOV     (KSP)+,R1       ;POP KERNEL STACK INTO R1
10988  046452  020001                         CMP     R0,R1           ;WAS DATA FETCHED SAME AS STORED
10989  046454  001401                         BEQ     16$
10990  046456  104000                         EMT                     ;WRONG DATA WAS FETCHED
10991                                                                   ;FOR TIGHTER SCOPE LOOP
10992                                                                   ;REPLACE ERROR CALL WITH
```

```
10993                                                          ;'BR 15$'' = 000766
10994  046460                                  16$:
10995                                          ;THE FOLLOWING WILL TEST DSTM=5 MFPI.
10996                                          ;
10997  046460  012767  030340  131310  17$:    MOV     #030340,PSW     ;MAKE PREVIOUS MODE USER
10998  046466  012767  100000  170672          MOV     #100000,$TMP2   ;LOAD TEST LOC. VIRT. ADDR INTO LOC. $TMP2
10999  046474  012702  037370                  MOV     #<$TMP2+2>,R2   ;LOAD ADDR. OF $TMP2+2 INTO R2
11000  046500  006552                          MFPI    @-(R2)          ;READ FROM PHYSICAL 140000
11001  046502  012601                          MOV     (KSP)+,R1       ;POP KERNEL STACK INTO R1
11002  046504  020001                          CMP     R0,R1           ;WAS DATA FETCHED SAME AS STORED
11003  046506  001401                          BEQ     18$
11004  046510  104000                          EMT                     ;WRONG DATA WAS FETCHED
11005                                                                  ;FOR TIGHTER SCOPE LOOP
11006                                                                  ;REPLACE ERROR CALL WITH
11007                                                                  ;'BR 17$'' = 000763
11008  046512                                  18$:    ;THE FOLLOWING WILL TEST DSTM=6 MFPI.
11009                                          ;
11010  046512  012767  030340  131256  19$:    MOV     #030340,PSW     ;MAKE PREVIOUS MODE USER
11011  046520  005002                          CLR     R2              ;MAKE REGISTER 2 A ZERO
11012  046522  006562  100000                  MFPI    100000(R2)      ;READ FROM PHYSICAL 140000
11013  046526  012601                          MOV     (KSP)+,R1       ;POP KERNEL STACK INTO R1
11014  046530  020001                          CMP     R0,R1           ;WAS DATA FETCHED SAME AS STORED
11015  046532  001401                          BEQ     20$
11016  046534  104000                          EMT                     ;WRONG DATA WAS FETCHED
11017                                                                  ;FOR TIGHTER SCOPE LOOP
11018                                                                  ;REPLACE ERROR CALL WITH
11019                                                                  ;'BR 19$'' = 000766
11020  046536                                  20$:    ;THE FOLLOWING WILL TEST DSTM=7 MFPI.
11021                                          ;
11022  046536  012767  030340  131232  21$:    MOV     #030340,PSW     ;MAKE PREVIOUS MODE USER
11023  046544  012767  100000  170614          MOV     #100000,$TMP2   ;LOAD TEST LOC. V.A. INTO $TMP2
11024  046552  012702  037366                  MOV     #$TMP2,R2       ;LOAD ADDRESS OF $TMP2 INTO R2
11025  046556  006572  000000                  MFPI    @0(R2)          ;USE $TMP2 TO FETCH VIRTUAL
11026                                                                  ;ADDRESS OF 140000
11027  046562  012601                          MOV     (KSP)+,R1       ;POP KERNEL STACK INTO R1
11028  046564  020001                          CMP     R0,R1           ;WAS DATA FETCHED SAME AS STORED
11029  046566  001401                          BEQ     22$
11030  046570                                  23$:
11031  046570  104000                          EMT                     ;WRONG DATA WAS FETCHED
11032                                                                  ;FOR TIGHTER SCOPE LOOP
11033                                                                  ;REPLACE ERROR CALL WITH
11034                                                                  ;'BR 21$'' = 000762
11035  046572  012767  021276  131450  22$:    MOV     #TO250,MMVEC    ;SET M.M. VECTOR TO NORMAL ROUTINE
11036
11037
11038                                          ;*****************************************************************************
11039                                          ;TEST 414       MOVE TO PREVIOUS (USER) I-SPACE
11040                                          ;*****************************************************************************
11041  046600                                  TS414:
11042  046600  012767  077406  123502  1$:     MOV     #77406,KIPDR4   ;KERNEL I-SPACE PAGE 4 READ/WRITE
11043  046606  012767  077406  130774          MOV     #77406,UIPDR4   ;USER I-SPACE PAGE 4 READ/WRITE
11044  046614  012767  001400  123526          MOV     #1400,KIPAR4    ;MAP KERNEL I PAGE 4 TO 24K
11045  046622  012767  001400  131020          MOV     #1400,UIPAR4    ;MAP USER I PAGE 4 TO 24K
11046  046630  012767  047322  131412          MOV     #20$,MMVEC      ;SET M.M. VECTOR TO 20$
11047                                          ;THE FOLLOWING WILL TEST DSTM=0 MTPI
11048                                          ;
```

```
11049  046636  012767  030340  131132  2$:     MOV     #030340,PSW     ;MAKE PREVIOUS MODE USER
11050  046644  012746  007777                  MOV     #7777,-(KSP)    ;PUSH DATA ON KERNEL STACK
11051  046650  006606                          MTPI    USP             ;LOAD USER STACK POINTER
11052  046652  006506                          MFPI    USP             ;READ USER STACK POINTER
11053  046654  012601                          MOV     (KSP)+,R1       ;POP KERNEL STACK INTO R1
11054  046656  022701  007777                  CMP     #7777,R1        ;WAS USER STACK POINTER CHANGED
11055  046662  001401                          BEQ     3$
11056  046664  104000                          EMT                     ;USER STACK POINTER NOT CHANGED
11057                                                                  ;FOR TIGHTER SCOPE LOOP
11058                                                                  ;REPLACE ERROR CALL WITH
11059                                                                  ;"BR 2$" = 000764
11060  046666  012767  030340  131102  3$:     MOV     #030340,PSW     ;MAKE PREVIOUS MODE USER
11061  046674  012746  000600                  MOV     #USESTK,-(KSP)  ;GET READY TO RESTORE USER S. POINT
11062  046700  006606                          MTPI    USP             ;RESTORE USER STACK POINTER
11063  046702                          4$:     ;THIS WILL TEST DSTM = 1 MTPI.
11064  046702  012702  100000                  MOV     #100000,R2      ;LOAD VIRTUAL ADDRESS INTO R2
11065  046706  012700  125252                  MOV     #125252,R0      ;LOAD TEST DATA INTO R0
11066  046712  010046                  5$:     MOV     R0,-(KSP)       ;PUSH TEST DATA ON KERNEL STACK
11067  046714  105067  123370                  CLRB    KIPDR4          ;MAKE KERNEL I PAGE 4 NON-RESIDENT
11068  046720  006612                          MTPI    (R2)            ;LOAD TEST DATA INTO PHYSICAL 140000
11069  046722  112767  000006  123360          MOVB    #006,KIPDR4     ;MAKE KERNEL PAGE 4 RESIDENT
11070  046730  011201                          MOV     (R2),R1         ;READ FROM ADDRESS 140000
11071  046732  020001                          CMP     R0,R1           ;SEE IF DATA WAS STORED AT CORRECT PLACE
11072  046734  001401                          BEQ     6$
11073  046736  104000                          EMT                     ;INCORRECT STORE
11074                                                                  ;FOR TIGHTER SCOPE LOOP
11075                                                                  ;REPLACE ERROR CALL WITH
11076                                                                  ;"BR 5$" = 000765
11077  046740                          6$:     ;THE FOLLOWING WILL TEST DSTM=2 MTPI.
11078                                          ;
11079  046740  012767  030340  131030          MOV     #030340,PSW     ;MAKE PREVIOUS MODE USER
11080  046746  012700  125252                  MOV     #125252,R0      ;LOAD TEST DATA INTO R0
11081  046752  012702  100000                  MOV     #100000,R2      ;LOAD VIRTUAL ADDRESS INTO R2
11082  046756  010046                  8$:     MOV     R0,-(KSP)       ;PUSH TEST DATA ON KERNEL STACK
11083  046760  105067  123324                  CLRB    KIPDR4          ;MAKE KERNEL PAGE 4 NON-RESIDENT
11084  046764  006612                          MTPI    (R2)            ;LOAD TEST DATA INTO PHYSICAL 140000
11085  046766  112767  000006  123314          MOVB    #006,KIPDR4     ;MAKE KERNEL PAGE 4 RESISENT
11086  046774  013701  100000                  MOV     @#100000,R1     ;READ FROM ADDRESS 140000
11087  047000  020001                          CMP     R0,R1           ;SEE IF DATA WAS STORED CORRECTLY
11088  047002  001401                          BEQ     9$
11089  047004  104000                          EMT                     ;INCORRECT STORE
11090                                                                  ;FOR TIGHTER SCOPE LOOP
11091                                                                  ;REPLACE ERROR CALL WITH
11092                                                                  ;"BR 8$" = 000764
11093  047006                          9$:     ;THIS WILL TEST DSTM = 3 MTPI.
11094  047006  012767  030340  130762          MOV     #030340,PSW     ;MAKE PREVIOUS MODE USER
11095  047014  012700  052525                  MOV     #52525,R0       ;LOAD TEST DATA INTO R0
11096  047020  010046                  10$:    MOV     R0,-(KSP)       ;PUSH TEST DATA ON KERNEL STACK
11097  047022  105067  123262                  CLRB    KIPDR4          ;MAKE KERNEL I PAGE 4 NON-RESIDENT
11098  047026  006637  100000                  MTPI    @#100000        ;LOAD TEST DATA INTO PHYSICAL 140000
11099  047032  112767  000006  123250          MOVB    #006,KIPDR4     ;MAKE KERNEL PAGE 4 RESIDENT
11100  047040  013701  100000                  MOV     @#100000,R1     ;READ FROM ADDRESS 140000
11101  047044  020001                          CMP     R0,R1           ;SEE IF DATA WAS STORED CORRECTLY
11102  047046  001531                          BEQ     TS415
11103  047050  104000                          EMT                     ;
11104  047052  001401                          BEQ     11$
```

```
11105  047054  104000                          EMT                             ;INCORRECT STORE
11106                                                                          ;FOR TIGHTER SCOPE LOOP
11107                                                                          ;REPLACE ERROR CALL WITH
11108                                                                          ;'BR 10$'' = 000763
11109  047056                          11$:    ;THIS WILL TEST DSTM = 4 MTPI.
11110  047056  012767  030340  130712          MOV     #030340,PSW             ;MAKE PREVIOUS MODE USER
11111  047064  012700  125252                  MOV     #125252,R0              ;LOAD TEST DATA INTO R0
11112  047070  010046                  12$:    MOV     R0,-(KSP)               ;PUSH TEST DATA ON KERNEL STACK
11113  047072  012702  100002                  MOV     #100002,R2              ;LOAD VIRTUAL ADDRESS INTO R2
11114  047076  105067  123206                  CLRB    KIPDR4                  ;MAKE KERNEL I PAGE 4 NON-RESIDENT
11115  047102  006642                          MTPI    -(R2)                   ;LOAD TEST DATA INTO PHYSICAL 140000
11116  047104  112767  000006  123176          MOVB    #006,KIPDR4             ;MAKE KERNEL PAGE 4 RESIDENT
11117  047112  013701  100000                  MOV     @#100000,R1             ;READ FROM ADDRESS 140000
11118  047116  020001                          CMP     R0,R1                   ;SEE IF DATA WAS STORED CORRECTLY
11119  047120  001401                          BEQ     13$
11120  047122  104000                          EMT                             ;INCORRECT STORE
11121                                                                          ;FOR TIGHTER SCOPE LOOP
11122                                                                          ;REPLACE ERROR CALL WITH
11123                                                                          ;'BR 12$'' = 000762
11124  047124                          13$:    ;THE FOLLOWING WILL TEST DSTM=5 MTPI.
11125                                          ;
11126  047124  012767  030340  130644          MOV     #030340,PSW             ;MAKE PREVIOUS MODE USER
11127  047132  012700  052525                  MOV     #52525,R0               ;LOAD TEST DATA INTO R0
11128  047136  012702  037370                  MOV     #<$TMP2+2>,R2           ;LOAD ADDR. OF LOC. $TMP2+2 INTO R2
11129  047142  012767  100000  170216          MOV     #100000,$TMP2           ;LOAD VIRT. ADDR. OF TEST LOC. INTO $TMP2
11130  047150  010046                  14$:    MOV     R0,-(KSP)               ;PUSH TEST DATA ON KERNEL STACK
11131  047152  105067  123132                  CLRB    KIPDR4                  ;MAKE KERNEL PAGE 4 NON-RESIDENT
11132  047156  006652                          MTPI    @-(R2)                  ;LOAD TEST DATA INTO PHYSICAL 140000
11133  047160  112767  000006  123122          MOVB    #006,KIPDR4             ;MAKE KERNEL PAGE 4 RESIDENT
11134  047166  013701  100000                  MOV     @#100000,R1             ;READ FROM ADDRESS 140000
11135  047172  020001                          CMP     R0,R1                   ;SEE IF DATA WAS STORED CORRECTLY
11136  047174  001401                          BEQ     15$
11137  047176  104000                          EMT                             ;INCORRECT STORE
11138                                                                          ;FOR TIGHTER SCOPE LOOP
11139                                                                          ;REPLACE ERROR CALL WITH
11140                                                                          ;'BR 14$'' = 000764
11141  047200                          15$:    ;THIS WILL TEST DSTM = 6 MTPI.
11142                                          ;
11143  047200  012767  030340  130570          MOV     #030340,PSW             ;MAKE PREVIOUS MODE USER
11144  047206  012700  052525                  MOV     #52525,R0               ;LOAD TEST DATA INTO R0
11145  047212  005002                          CLR     R2                      ;MAKE REGISTER 2 ZERO
11146  047214  010046                  16$:    MOV     R0,-(KSP)               ;PUSH TEST DATA ON KERNEL STACK
11147  047216  105067  123066                  CLRB    KIPDR4                  ;MAKE KERNEL I PAGE 4 NON-RESIDENT
11148  047222  006662  100000                  MTPI    100000(R2)              ;LOAD TEST DATA INTO PHYSICAL 140000
11149  047226  112767  000006  123054          MOVB    #006,KIPDR4             ;MAKE KERNEL PAGE 4 RESIDENT
11150  047234  013701  100000                  MOV     @#100000,R1             ;READ FROM ADDRESS 140000
11151  047240  020001                          CMP     R0,R1                   ;SEE IF DATA WAS STORED CORRECTLY
11152  047242  001401                          BEQ     17$
11153  047244  104000                          EMT                             ;INCORRECT STORE
11154                                                                          ;FOR TIGHTER SCOPE LOOP
11155                                                                          ;REPLACE ERROR CALL WITH
11156                                                                          ;'BR 16$'' = 000763
11157  047246                          17$:    ;THE FOLLOWING WILL TEST DSTM=7 MTPI.
11158                                          ;
11159  047246  012767  030340  130522          MOV     #030340,PSW             ;MAKE PREVIOUS MODE USER
11160  047254  012700  125252                  MOV     #125252,R0              ;LOAD TEST DATA INTO R0
```

```
11161  047260  012767  100000  170100          MOV     #100000,$TMP2   ;LOAD VIRT. ADDR. OF TEST LOCATION
11162                                                                   ;INTO LOCATION $TMP2
11163  047266  012702  037366                  MOV     #$TMP2,R2       ;LOAD ADDRESS OF $TMP2 INTO R2
11164  047272  010046                  18$:    MOV     R0,-(KSP)       ;PUSH TEST DATA ON KERNEL STACK
11165  047274  105067  123010                  CLRB    KIPDR4          ;MAKE KERNEL PAGE 4 NON-RESIDENT
11166  047300  006672  000000                  MTPI    @0(R2)          ;LOAD TEST DATA INTO PHYSICAL 140000
11167  047304  112767  000006  122776          MOVB    #006,KIPDR4     ;MAKE KERNEL PAGE 4 RESIDENT
11168  047312  013701  100000                  MOV     @#100000,R1     ;READ FROM ADDRESS 140000
11169  047316  020001                          CMP     R0,R1           ;SEE IF DATA WAS STORED CORRECTLY
11170  047320  001401                          BEQ     19$
11171  047322                          20$:
11172  047322  104000                          EMT                     ;INCORRECT STORE
11173                                                                   ;FOR TIGHTER SCOPE LOOP
11174                                                                   ;REPLACE ERROR CALL WITH
11175                                                                   ;"BR 18$" = 000763
11176  047324  012767  021276  130716  19$:    MOV     #T0250,MMVEC    ;RESTORE M.M. VECTOR TO NORMAL ROUTINE
11177
11178
11179
11180                                   ;*************************************************************************************
11181                                   ;TEST 415       MOVE FROM PREVIOUS (KERNEL) I-SPACE TO USER MODE
11182                                   ;*************************************************************************************
11183  047332                          TS415:
11184  047332  012700  077406          1$:     MOV     #77406,R0       ;MAKE ALL USER I-SPACE PAGES RESIDENT
11185                                                                   ;READ/WRITE, LENGTH 200 BLOCKS
11186  047336  012702  000010                  MOV     #10,R2          ;SET LOOP COUNTER TO 8
11187  047342  012701  177600                  MOV     #UIPDR0,R1      ;LOAD ADDRESS OF FIRST PDR IN R1
11188  047346  010021                  2$:     MOV     R0,(R1)+        ;LOAD PDR WITH 77406
11189  047350  077202                          SOB     R2,2$           ;LOOP UNTIL 8 USER PDRS LOADED
11190  047352  012767  140340  130416  3$:     MOV     #140340,PSW     ;GO TO USER MODE FOR THIS TEST
11191  047360  012767  077406  122722          MOV     #77406,KIPDR4   ;KERNEL I-SPACE PAGE 4 READ/WRITE
11192  047366  012767  001400  122754          MOV     #1400,KIPAR4    ;MAP KERNEL I PAGE 4 TO 24K
11193  047374  012767  001400  130246          MOV     #1400,UIPAR4    ;MAP USER I PAGE 4 TO 24K
11194  047402  012700  036514                  MOV     #36514,R0       ;LOAD DATA PATTERN INTO R0
11195  047406  010037  100000                  MOV     R0,@#100000     ;LOAD DATA PATTERN INTO PHY 140000
11196  047412  012702  100000                  MOV     #100000,R2      ;LOAD VIRTUAL ADDRESS INTO R2
11197                                          ;THE FOLLOWING WILL TEST DSTM=0 MFPI
11198                                          ;
11199  047416  012767  047714  130624          MOV     #21$,MMVEC      ;SET M.M. VECTOR TO 21$
11200  047424  105067  130160                  CLRB    UIPDR4          ;MAKE USER I-SPACE PAGE 4 NON-RESIDENT
11201  047430  012767  140340  130340          MOV     #140340,PSW     ;MAKE PREVIOUS MODE KERNEL PRESENT USER
11202  047436  006506                  -4$:    MFPI    KSP             ;PUT KERNEL STACK POINTER ON USER STACK
11203  047440  022706  000600                  CMP     #USESTK,USP     ;WAS SOMETHING PUSHED ON STACK AT 1$
11204  047444  001405                          BEQ     5$              ;BRANCH IF NOTHING WAS PUSHED
11205  047446  012600                          MOV     (USP)+,R0       ;POP USER STACK INTO R0
11206  047450  012701  001000                  MOV     #KERSTK,R1      ;EXPECTING 1100 AS KSP
11207  047454  020001                          CMP     R0,R1           ;DID YOU GET THE RIGHT POINTER?
11208  047456  001401                          BEQ     6$
11209  047460                          5$:
11210  047460  104000                          EMT                     ;WRONG THING WAS PUSHED ON STACK
11211                                                                   ;FOR TIGHTER SCOPE LOOP
11212                                                                   ;REPLACE ERROR CALL WITH
11213                                                                   ;"BR 4$" = 000766
11214  047462                          6$:     ;THE FOLLOWING WILL TEST DSTM=1 MFPI.
11215  047462  012767  140340  130306  7$:     MOV     #140340,PSW     ;MAKE PREVIOUS MODE KERNEL PRESENT USER
11216  047470  012700  036514                  MOV     #36514,R0       ;LOAD DATA EXPECTED INTO R0
```

```
11217  047474  012702  100000              MOV     #100000,R2      ;LOAD VIRTUAL ADDRESS INTO R2
11218  047500  006512                      MFPI    (R2)            ;READ FROM PHYSICAL 140000
11219  047502  012601                      MOV     (USP)+,R1       ;POP USER STACK INTO R1
11220  047504  020001                      CMP     R0,R1           ;WAS DATA FETCHED SAME AS STORED
11221  047506  001401                      BEQ     9$
11222  047510  104000                      EMT                     ;WRONG DATA WAS FETCHED
11223                                                             ;FOR TIGHTER SCOPE LOOP
11224                                                             ;REPLACE ERROR CALL WITH
11225                                                             ;"BR 7$" = 000764
11226                                      ;THE FOLLOWING WILL TEST DSM=2 MFPI.
11227  047512  012767  140340  130256  9$:   MOV     #140340,PSW     ;MAKE PREVIOUS MODE KERNEL PRESENT USER
11228  047520  012702  100000              MOV     #100000,R2      ;LOAD VIRTUAL ADDRESS INTO R2
11229  047524  006522                      MFPI    (R2)+           ;READ FROM PHYSICAL 140000
11230  047526  012601                      MOV     (USP)+,R1       ;POP USER STACK INTO R1
11231  047530  020001                -     CMP     R0,R1           ;WAS DATA FETCHED SAME AS STORED
11232  047532  001401                      BEQ     11$
11233  047534  104000                      EMT                     ;WRONG DATA WAS FETCHED
11234                                                             ;FOR TIGHTER SCOPE LOOP
11235                                                             ;REPLACE ERROR CALL WITH
11236                                                             ;"BR 9$" = 000766
11237                                      ;THE FOLLOWING WILL TEST DSTM=3 MFPI.
11238  047536  012767  140340  130232  11$:   MOV     #140340,PSW     ;MAKE PREVIOUS MODE KERNEL PRESENT USER
11239  047544  006537  100000              MFPI    @#100000        ;READ FROM PHYSICAL 140000
11240  047550  012601                      MOV     (USP)+,R1       ;POP USER STACK INTO R1
11241  047552  020001                      CMP     R0,R1           ;WAS DATA FETCHED SAME AS STORED
11242  047554  001401                      BEQ     13$
11243  047556  104000                      EMT                     ;WRONG DATA WAS FETCHED
11244                                                             ;FOR TIGHTER SCOPE LOOP
11245                                                             ;REPLACE ERROR CALL WITH
11246                                                             ;"BR 11$" = 000767
11247                                      ;THE FOLLOWING WILL TEST DSTM=4 MFPI.
11248  047560  012767  140340  130210  13$:   MOV     #140340,PSW     ;MAKE PREVIOUS MODE DERNEL PRESENT USER
11249  047566  012702  100002              MOV     #100002,R2      ;LOAD VIRTUAL ADDRESS INTO R2
11250  047572  006542                      MFPI    -(R2)           ;READ FROM PHYSICAL 140000
11251  047574  012601                      MOV     (USP)+,R1       ;POP USER STACK INTO R1
11252  047576  020001                      CMP     R0,R1           ;WAS DATA FETCHED SAME AS STORED
11253  047600  001401                      BEQ     15$
11254  047602  104000                      EMT                     ;WRONG DATA WAS FETCHED
11255                                                             ;FOR TIGHTER SCOPE LOOP
11256                                                             ;REPLACE ERROR CALL WITH
11257                                                             ;"BR 13$" = 000766
11258                                      ;THE FOLLOWING WILL TEST DSTM=5 MFPI.
11259                                      ;
11260  047604  012767  140340  130164  15$:   MOV     #140340,PSW     ;MAKE PREVIOUS MODE KERNEL PRESENT USER
11261  047612  012767  100000  167546        MOV     #100000,$TMP2   ;LOAD TEST LOC. VIRT. ADDR INTO LOC. $TMP2
11262  047620  012702  037370              MOV     #<$TMP2+2>,R2   ;LOAD ADDRESS OF $TMP2+2 INTO R2
11263  047624  006552                      MFPI    @-(R2)          ;READ FROM PHYSICAL 140000
11264  047626  012601                      MOV     (USP)+,R1       ;POP USER STACK INTO R1
11265  047630  020001                      CMP     R0,R1           ;WAS DATA FETCHED SAME AS STORED
11266  047632  001401                      BEQ     17$
11267  047634  104000                      EMT                     ;WRONG DATA WAS FETCHED
11268                                                             ;FOR TIGHTER SCOPE LOOP
11269                                                             ;REPLACE ERROR CALL WITH
11270                                                             ;"BR 15$" = 000763
11271                                      ;THE FOLLOWING WILL TEST DSTM=6 MFPI.
11272                                      ;
```

```
11273  047636  012767  140340  130132  17$:    MOV     #140340,PSW     ;MAKE PREVIOUS MODE KERNEL PRESENT USER
11274  047644  005002                          CLR     R2              ;MAKE REGISTER 2 A ZERO
11275  047646  006562  100000                  MFPI    100000(R2)      ;READ FROM PHYSICAL 140000
11276  047652  012601                          MOV     (USP)+,R1       ;POP USER STACK INTO R1
11277  047654  020001                          CMP     R0,R1           ;WAS DATA FETCHED SAME AS STORED
11278  047656  001401                          BEQ     19$
11279  047660  104000                          EMT                     ;WRONG DATA WAS FETCHED
11280                                                                  ;FOR TIGHTER SCOPE LOOP
11281                                                                  ;REPLACE ERROR CALL WITH
11282                                                                  ;"BR 17$" = 000766
11283                                          ;THE FOLLOWING WILL TEST DSTM=7 MFPI.
11284                                          ;
11285  047662  012767  140340  130106  19$:    MOV     #140340,PSW     ;MAKE PREVIOUS MODE KERNEL PRESENT USER
11286  047670  012767  100000  167470          MOV     #100000,$TMP2   ;LOAD TEST LOC. VIRT. ADDR. INTO $TMP2
11287  047676  012702  037366                  MOV     #$TMP2,R2       ;LOAD ADDRESS OF $TMP2 INTO R2
11288  047702  006572  000000                  MFPI    @0(R2)          ;READ FROM PHYSICAL 140000
11289  047706  012601                          MOV     (USP)+,R1       ;POP USER STACK INTO R1
11290  047710  020001                          CMP     R0,R1           ;WAS DATA FETCHED SAME AS STORED
11291  047712  001401                          BEQ     20$
11292  047714                          21$:
11293  047714  104000                          EMT                     ;WRONG DATA WAS FETCHED
11294                                                                  ;FOR TIGHTER SCOPE LOOP
11295                                                                  ;REPLACE ERROR CALL WITH
11296                                                                  ;"BR 19$" = 000762
11297  047716  012767  021276  130324  20$:    MOV     #T0250,MMVEC    ;SET M.M. VECTOR TO NORMAL ROUTINE
11298  047724  012767  000340  130044          MOV     #00340,PSW      ;GO BACK TO KERNEL MODE, PREVIOUS KERNEL
11299
11300                                          ;*************************************************************************
11301                                          ;TEST 416       MOVE FROM/TO D-SPACE = MOVE FROM/TO I-SPACE
11302                                          ;*************************************************************************
11303  047732                          TS416:
11304  047732  012767  030340  130036  1$:     MOV     #030340,PSW     ;MAKE PREVIOUS MODE=USER,CURRENT=KERNEL
11305  047740  106506                          MFPD    USP             ;MFPD SHOULD ACT LIKE MFPI PUTTING
11306                                                                  ;USER STACK POINTER ON THE KERNEL STACK
11307  047742  022706  001000                  CMP     #KERSTK,KSP     ;WAS SOMETHING PUSHED ON KERNEL STACK?
11308  047746  001405                          BEQ     2$              ;BRANCH IF NO
11309  047750  012600                          MOV     (KSP)+,R0       ;POP KERNEL STACK INTO R0
11310  047752  012701  000600                  MOV     #USESTK,R1      ;EXPECTING TO GET 700 AS USP
11311  047756  020001                          CMP     R0,R1           ;DID GET RIGHT POINTER VALUE?
11312  047760  001401                          BEQ     4$
11313  047762                          2$:
11314  047762  104000                          EMT                     ;WRONG THING WAS PUSHED ON STACK
11315                                                                  ;FOR TIGHTER SCOPE LOOP
11316                                                                  ;REPLACE ERROR CALL WITH
11317                                                                  ;"BR 1$" = 000763
11318  047764  012746  007777          4$:     MOV     #7777,-(KSP)    ;PUSH DATA ON KERNEL STACK
11319  047770  106606                          MTPD    USP             ;LOAD THE USER STACK POINTER
11320  047772  106506                          MFPD    USP             ;READ USER STACK POINTER
11321  047774  012601                          MOV     (KSP)+,R1       ;POP KERNEL STACK INTO R1
11322  047776  022701  007777                  CMP     #7777,R1        ;WAS USER STACK POINTER CHANGED?
11323  050002  001401                          BEQ     5$
11324  050004  104000                          EMT                     ;USER STACK POINTER NOT CHANGED
11325                                                                  ;FOR TIGHTER SCOPE LOOP
11326                                                                  ;REPLACE ERROR CALL WITH
11327                                                                  ;"BR 4$" = 000767
11328  050006  012746  000600          5$:     MOV     #USESTK,-(KSP)  ;GET READY TO RESTORE USER STK. PTR.
```

```
11329  050012  106606                    MTPD    USP             ;RESTORE USER STACK POINTER
11330
11331                                    ;*************************************************************************************
11332                                    ;TEST 417       MOVE FROM PREVIOUS I=SPACE (PREVIOUS=CURRENT=KERNEL)
11333                                    ;*************************************************************************************
11334  050014                            TS417:
11335  050014  005037  177776           1$:     CLR     @#PSW           ;SET PREVIOUS = CURRENT = KERNEL
11336  050020  012700  001000                   MOV     #KERSTK,R0      ;SETUP VALUE FOR STACK POINTER
11337  050024  010006                           MOV     R0,KSP          ;LOAD STACK POINTER
11338  050026  006506                           MFPI    KSP             ;THE VALUE "STACK" SHOULD BE PUSHED
11339                                                                    ;BEFORE BEING DECREMENTED
11340  050030  011601                           MOV     (KSP),R1        ;READ DATA WHICH WAS PUSHED
11341  050032  020001                           CMP     R0,R1           ;WAS THE ORIGINAL VALUE OF THE
11342                                                                    ;STACK POINTER PUSHED?
11343  050034  001401                           BEQ     2$
11344  050036  104000                           EMT                     ;MFPI FETCHED WRONG DATA
11345                                                                    ;FOR TIGHTER SCOPE LOOP
11346                                                                    ;REPLACE ERROR CALL WITH
11347                                                                    ;"BR 1$" = 000766
11348  050040  005740                    2$:     TST     -(R0)           ;SETUP EXPECTED STACK POINTER VALUE
11349  050042  020600                           CMP     KSP,R0          ;WAS THE STACK POINTER DECREMENTED?
11350  050044  001401                           BEQ     3$
11351  050046  104000                           EMT                     ;STACK NOT PUSHED BY THE MFPI
11352                                                                    ;FOR TIGHTER SCOPE LOOP
11353                                                                    ;REPLACE ERROR CALL WITH
11354                                                                    ;"BR 1$" = 000762
11355  050050  012706  001000           3$:     MOV     #KERSTK,KSP     ;RESTORE STACK POINTER
11356  050054  005067  127512                   CLR     SR0             ;TURN OFF MEMORY MANAGEMENT UNIT
11357  050060  000167  000436                   JMP     FPSTRT          ;GET OVER SUBROUTINES TO FLOATING POINT TESTS
```

```
11358                                   .SBTTL  *****   SUBROUTINES USED BY THIS PROGRAM   *****
11359
11360                                   .SBTTL  TURN OFF T-BIT AND SAVE CURRENT PSW
11361                                   ;*********************************************************************************
11362                                   ;*
11363                                   ;*      THIS SUBROUTINE IS USED TO TURN OFF THE TRACE TRAP BIT IN THE PSW
11364                                   ;*      IF IT IS ON.  THE PROCESSOR STATUS IS SAVED IN "TBITPS" SO THAT
11365                                   ;*      THE PSW CAN BE RESTORED TO ITS PREVIOUS CONDITION WHEN CONDITIONS
11366                                   ;*      WARRANT T-BIT TRAPPING.
11367                                   ;*
11368                                   ;*********************************************************************************
11369  050064  036727  127706  000020  TOFF:   BIT     PSW,#TBIT       ;IS THE T-BIT SET IN THE PSW?
11370  050072  001411                          BEQ     1$              ;EXIT IF NO
11371  050074  016746  127676                  MOV     PSW,-(SP)       ;PUSH PRESENT PSW ON THE STACK
11372  050100  011667  167254                  MOV     (SP),TBITPS     ;ALSO SAVE IT IN "TBITPS" FOR
11373                                                                   ;RESTORING LATER
11374  050104  042716  000020                  BIC     #TBIT,(SP)      ;CLEAR THE T-BIT (BIT 4) IN THE PSW
11375  050110  012746  050116                  MOV     #1$,-(SP)       ;PUSH PC OF "RTS" ON STACK
11376  050114  000006                          RTT                     ;"RETURN" TO 1$ WITH T-BIT OFF
11377  050116  000207                  1$:     RTS     PC              ;RETURN TO PROGRAM
11378
11379                                   .SBTTL  TURN ON T-BIT AND RESTORE PREVIOUS PSW
11380                                   ;*********************************************************************************
11381                                   ;*
11382                                   ;*      THIS SUBROUTINE IS USED TO RESTORE THE PROCESSOR STATUS TO ITS
11383                                   ;*      PREVIOUS CONDITION BY RESTORING THE "T-BIT PSW" SAVED BY THE
11384                                   ;*      "TOFF" SUBROUTINE IN THE "TBITPS" LOCATION.
11385                                   ;*
11386                                   ;*********************************************************************************
11387  050120  036727  167234  000020  TON:    BIT     TBITPS,#TBIT    ;WAS T-BIT ON IN THE PREVIOUS PSW?
11388  050126  001410                          BEQ     1$              ;EXIT IF NO
11389  050130  016746  167224                  MOV     TBITPS,-(SP)    ;PUSH PREVIOUS PSW ON THE STACK
11390  050134  012767  000340  167216          MOV     #340,TBITPS     ;RESET THE "TBITPS" LOCATION
11391  050142  012746  050150                  MOV     #1$,-(SP)       ;PUSH PC OF "RTS" ON STACK
11392  050146  000006                          RTT                     ;"RETURN" TO 1$ WITH T-BIT RESTORED
11393  050150  000207                  1$:     RTS     PC              ;RETURN TO PROGRAM
11394
11395                                   .SBTTL  SET ALL WRITEABLE BITS IN ALL PAR/PDR'S
11396                                   ;*********************************************************************************
11397                                   ;*
11398                                   ;*      THIS SUBROUTINE IS USED BY THE PAR/PDR DUAL ADDRESSING TEST
11399                                   ;*      TO SET ALL WRITEABLE BITS IN ALL KERNEL AND USE PAR'S AND
11400                                   ;*      PDR'S TO A 1.  THE "INITIAL STATE" OF HAVING ALL BITS=1 IS
11401                                   ;*      USED TO SEE THAT ONLY ONE REGISTER IS CLEARED IN RESPONSE TO
11402                                   ;*      A SINGLE PAR OR PDR ADDRESS.
11403                                   ;*
11404                                   ;*********************************************************************************
11405
11406  050152  012702  000010  SETREG: MOV     #10,R2          ;LOAD LOOP COUNTER WITH AN 8
11407  050156  012701  172300          MOV     #KIPDR0,R1      ;LOAD ADDRESS OF FIRST PDR INTO R1
11408  050162  012721  177777  1$:     MOV     #-1,(R1)+       ;SET BITS IN KERNEL PDR TO 1
11409  050166  077203                  SOB     R2,1$           ;LOOP TO 1$ UNTIL ALL KERNEL PDR'S LOADED
11410  050170  012702  000010          MOV     #10,R2          ;LOAD LOOP COUNTER WITH AN 8
11411  050174  012701  172340          MOV     #KIPAR0,R1      ;LOAD ADDRESS OF FIRST PAR INTO R1
11412  050200  012721  177777  2$:     MOV     #-1,(R1)+       ;SET BITS IN A KERNEL PAR TO 1
11413  050204  077203                  SOB     R2,2$           ;LOOP TO 2$ UNTIL ALL KERNEL PAR'S LOADED
```

```
11414  050206  012702  000010          MOV     #10,R2          ;LOAD LOOP COUNTER WITH AN 8
11415  050212  012701  177600          MOV     #UIPDR0,R1      ;LOAD ADDRESS OF FIRST PDR INTO R1
11416  050216  012721  177777  3$:     MOV     #-1,(R1)+       ;SET BITS IN A USER PDR TO 1
11417  050222  077203                  SOB     R2,3$           ;LOOP TO 3$ UNTIL ALL USER PDR'S LOADED
11418  050224  012702  000010          MOV     #10,R2          ;LOAD LOOP COUNTER WITH AN 8
11419  050230  012701  177640          MOV     #UIPAR0,R1      ;LOAD ADDRESS OF FIRST PAR INTO R1
11420  050234  012721  177777  4$:     MOV     #-1,(R1)+       ;SET BITS IN A USER PAR TO 1
11421  050240  077203                  SOB     R2,4$           ;LOOP TO 4$ UNTIL ALL USER PAR'S LOADED
11422  050242  000207                  RTS     PC              ;RETURN TO TEST
11423
11424                          .SBTTL  READ & COMPARE KERNEL & USER PAR/PDR'S
11425                          ;*****************************************************************************
11426                          ;*
11427                          ;*      THIS SUBROUTINE IS USED BY PAR/PDR DUAL ADDRESSING TEST TO
11428                          ;*      READ ALL THE PAR'S AND PDR'S TO SEE THAT ONLY ONE REGISTER
11429                          ;*      WAS CLEARED IN RESPONSE TO A SINGLE PAR OR PDR ADDRESS.
11430                          ;*      ANY FAILURES FOUND BY THE PAR/PDR DUAL ADDRESSING TEST WILL
11431                          ;*      BE REPORTED BY THIS SUBROUTINE.
11432                          ;*
11433                          ;*****************************************************************************
11434  050244                  CMPREG:
11435  050244  012701  172300          MOV     #KIPDR0,R1      ;LOAD ADDRESS OF FIRST KERNEL PDR IN R1
11436  050250  012704  000010          MOV     #10,R4          ;LOAD LOOP COUNTER WITH AN 8
11437  050254  012705  077416          MOV     #77416,R5       ;PUT EXPECTED PDR CONTENTS IN R5
11438  050260  021105          1$:     CMP     (R1),R5         ;ARE ALL WRITEABLE BITS SET AS EXPECTED?
11439  050262  001403                  BEQ     2$              ;BRANCH IF YES
11440  050264  020100                  CMP     R1,R0           ;WAS IT THE REG. THAT WAS CLEARED?
11441  050266  001401                  BEQ     2$
11442  050270  104000                  EMT                     ;A PDR WAS EFFECTED BY CLEARING A DIFFERENT PAR/PRD
11443                                                          ;FOR TIGHTER SCOPE LOOP
11444                                                          ;REPLACE ERROR CALL WITH
11445                                                          ;AN "RTS PC" = 000207
11446  050272  062701  000002  2$:     ADD     #2,R1           ;FORM NEXT ADDRESS
11447  050276  077410                  SOB     R4,1$           ;LOOP TO 1$ UNTIL ALL KERNEL PDR'S CHECKED
11448  050300  012701  172340          MOV     #KIPAR0,R1      ;LOAD ADDRESS OF FIRST KERNEL PAR IN R1
11449  050304  012704  000010          MOV     #10,R4          ;LOAD LOOP COUNTER WITH AN 8
11450                                                          ;****F11 CHANGE**** FROM #7777 TO #177777
11451  050310  012705  177777          MOV     #177777,R5      ;PUT EXPECTED PAR CONTENTS IN R5
11452  050314  021105          3$:     CMP     (R1),R5         ;ARE ALL WRITEABLE BITS SET AS EXPECTED?
11453  050316  001403                  BEQ     4$              ;BRANCH IF YES
11454  050320  020100                  CMP     R1,R0           ;WAS IT THE REG. THAT WAS CLEARED?
11455  050322  001401                  BEQ     4$
11456  050324  104000                  EMT                     ;A PAR WAS EFFECTED BY CLEARING A DIFFENENT PAR/PDR
11457                                                          ;FOR TIGHTER SCOPE LOOP
11458                                                          ;REPLACE ERROR CALL WITH
11459                                                          ;AN "RTS PC" = 000207
11460  050326  062701  000002  4$:     ADD     #2,R1           ;FORM NEXT ADDRESS
11461  050332  077410                  SOB     R4,3$           ;LOOP TO 3$ UNTIL ALL KERNEL PAR'S CHECKED
11462  050334  012701  177600          MOV     #UIPDR0,R1      ;LOAD ADDRESS OF FIRST USER PDR IN R1
11463  050340  012704  000010          MOV     #10,R4          ;LOAD LOOP COUNTER WITH AN 8
11464  050344  012705  077416          MOV     #77416,R5       ;PUT EXPECTED PDR CONTENTS IN R5
11465  050350  021105          5$:     CMP     (R1),R5         ;ARE ALL WRITEABLE BITS SET AS EXPECTED?
11466  050352  001403                  BEQ     6$              ;BRANCH IF YES
11467  050354  020100                  CMP     R1,R0           ;WAS IT THE REG. THAT WAS CLEARED?
11468  050356  001401                  BEQ     6$
11469  050360  104000                  EMT                     ;A PDR WAS EFFECTED BY CLEARING A DIFFERENT PAR/PDR
```

```
11470                                                   ;FOR TIGHTER SCOPE LOOP
11471                                                   ;REPLACE ERROR CALL WITH
11472                                                   ;AN "RTS PC" = 000207
11473  050362  062701  000002          6$:     ADD     #2,R1           ;FORM NEXT ADDRESS
11474  050366  077410                  SOB     R4,5$           ;LOOP TO 5$ UNTIL ALL USER PDR'S CHECKED
11475  050370  012701  177640          MOV     #UIPAR0,R1      ;LOAD ADDRESS OF FIRST USER PAR IN R1
11476  050374  012704  000010          MOV     #10,R4          ;LOAD LOOP COUNTER WITH AN 8
11477                                                   ;****F11 CHANGE**** FROM #7777 TO #177777
11478  050400  012705  177777          MOV     #177777,R5      ;PUT EXPECTED PAR CONTENTS IN R5
11479  050404  021105          7$:     CMP     (R1),R5         ;ARE ALL WRITEABLE BITS SET AS EXPECTED?
11480  050406  001403                  BEQ     8$              ;BRANCH IF YES
11481  050410  020100                  CMP     R1,R0           ;WAS IT THE REG. THAT WAS CLEARED?
11482  050412  001401                  BEQ     8$
11483  050414  104000                  EMT                     ;A PAR WAS EFFECTED BY CLEARING A DIFFERENT PAR/PDR
11484                                                   ;FOR TIGHTER SCOPE LOOP
11485                                                   ;REPLACE ERROR CALL WITH
11486                                                   ;AN "RTS PC" = 000207
11487  050416  062701  000002          8$:     ADD     #2,R1           ;FORM NEXT ADDRESS
11488  050422  077410                  SOB     R4,7$           ;LOOP TO 7$ UNTIL ALL USER PAR'S CHECKED
11489  050424  000207                  RTS     PC              ;RETURN TO TEST
11490
11491                                   .SBTTL  INHIBIT 'RESETS' WHILE UNDER APT
11492                                   ;*************************************************************************************
11493                                   ;*
11494                                   ;*      THIS SUBROUTINE CONTROLS THE USAGE OF RESET INST'S WHILE
11495                                   ;*      RUNNING UNDER APT. RESETS ARE ALLOWED DURING THE FIRST
11496                                   ;*      PASS OF THE DIAGNOSTIC.
11497                                   ;*
11498  050426  126727  130366  000001  CHKAPT: CMPB    $ENV,#1         ;ARE WE RUNNING UNDER APT?
11499  050434  001003                  BNE     1$              ;NO BRANCH
11500  050436  005767  130344          TST     $PASS           ;IS THIS THE FIRST PASS?
11501  050442  001002                  BNE     RETA            ;NO BRANCH
11502  050444  062705  000002          1$:     ADD     #2,R5           ;BUMP RETURN ADDRESS FOR NORMAL TESTING
11503  050450  000205                  RETA:   RTS     R5              ;RETURN
11504
11505
11506                                   .SBTTL  ERROR ROUTINE FOR MEMORY MANAGEMENT TEST
11507                                   ;*************************************************************************************
11508                                   ;*      THIS IS THE ONLY ERROR REPORT FOR ALL THE MMU TESTS
11509                                   ;*************************************************************************************
11510
11511  050452  012737  050504  000004  ERROR3: MOV     #1$,@#4         ;SET UP THE TIMEOUT VECTOR
11512  050460  012737  000340  000006          MOV     #340,@#6
11513  050466  005737  177766                  TST     @#177766        ;CHECK TO SEE IF THE POWER FAILED,WILL TRAP
11514                                                   ;TO 1$ IF UNIBUS MAP BOARD IS NOT PRESENT
11515                                                   ;SINCE THE CPUERR(177766)IS ON THE UNIBUS
11516                                                   ;MAP BOARD
11517  050472  001404                  BEQ     1$              ;NO,GO REPORT THE ERROR
11518  050474  012737  000177  001002          MOV     #177,@#$FATAL   ;YES,FLAG THAT THE POWER FAILED
11519  050502  000403                  BR      2$              ; AND GO SET FATAL ERROR FLAG
11520  050504  012737  000002  001002  1$:     MOV     #2,@#$FATAL             ;SET UP FATAL ERROR NUMBER
11521  050512  012767  000001  130260  2$:     MOV     #1,$MSGTY               ;SET FATAL ERROR FLAG
11522  050520  000777          MMUHLT: BR      .               ;STAY IN LOOP
11523
11524
11525
```

```
11526
11527
11528
11529
11530
11531
11532
11533   000244                  FPVECT=244
11534                                   .SBTTL  FPP REGISTER DEFINITIONS
11535   000000                  AC0     =%0
11536   000001                  AC1     =%1
11537   000002                  AC2     =%2
11538   000003                  AC3     =%3
11539   000004                  AC4     =%4
11540   000005                  AC5     =%5
11541   000006                  AC6     =%6
11542   000007                  AC7     =%7
11543
11544
11545 050522 012706 001000      FPSTRT: MOV     #STBOT,SP       ;SET UP STACK POINTER
11546 050526 032777 000002 150570       BIT     #2,@SWR
11547 050534 001402                     BEQ     1$
11548 050536 000167 050016              JMP     SLU1ST
11549 050542 012737 120424 000030 1$:   MOV     #ERROR4,@#30    ;SETUP FOR CORRECT ERROR CALL
11550 050550 012737 000003 001004       MOV     #3,@#STESTN     ;PUT TEST NUMBER IN MAILBOX
11551
11552
11553                           ;*****************************************************************************************
11554                           ;TEST 420       LDFPS, STFPS AND DATA PATHS TEST
11555                           ;*****************************************************************************************
11556 050556                    TS420:
11557 050556 012700 177777              MOV     #-1,R0                  ;INITIALIZE THE COUNT PATTERN.
11558 050562 012737 050634 000244       MOV     #AERR1,@#FPVECT         ;SET UP FOR UNABLE TO DECODE
11559 050570 012737 050634 000010       MOV     #AERR1,@#10             ;FPP INSTRUCTION TRAP TO 244 OR 10.
11560 050576 012737 050634 000004       MOV     #AERR1,@#ERRVECT        ;IF EITHER INSTRUCTION
11561                                                                   ;FAILS TO GO THROUGH THE
11562                                                                   ;CORRECT SRC OR DST MODE AN
11563                                                                   ;ODD ADDRESS TRAP WILL OCCUR.
11564 050604                    A1:
11565 050604 010004             A11:    MOV     R0,R4
11566 050606 042704 030020              BIC     #30020,R4
11567 050612 170104                     LDFPS   R4                      ;TEST INSTRUCTION.
11568
11569 050614 012701 177777              MOV     #-1,R1
11570 050620 170201             A12:    STFPS   R1                      ;TEST INSTRUCTION.
11571 050622 010004                     MOV     R0,R4                   ;MASK OFF UNSETTABLE BITS.
11572 050624 042704 030020              BIC     #30020,R4
11573 050630 020401                     CMP     R4,R1                   ;COMPARE DATA EXPECTED WITH
11574                                                                   ;THE DATA READ.
11575 050632 001401                     BEQ     A2
11576 050634                    AERR1:
11577 050634 104000                     EMT                     ;
11578
11579 050636 012700 000001      A2:     MOV     #1,R0                   ;NEXT PATTERN WILL BE ALL ZERO
11580 050642 077020                     SOB     R0,A1                   ;DECREMENT COUNT PATTERN
11581 050644                    ADONE:
```

```
11582  050644  004767  047624                JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
11583                                                                 ;SEE IF THE USER HAS EXPRESSED
11584                                                                 ;THE DESIRE TO CHANGE THE SOFTWARE
11585                                                                 ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
11586                                                                 ;THE USER TYPED CONTROL G?).
11587
11588                                ;*****************************************************************************
11589                                ;TEST 421       CFCC TEST
11590                                ;*****************************************************************************
11591
11592  050650                        TS421:
11593  050650  012700  000017                MOV     #17,R0                  ;R0 CONTAINS TO TEST PATTERN.
11594
11595  050654                        B1:
11596  050654  170100                        LDFPS   R0                      ;LOAD THE TEST PATTERN
11597
11598  050656                        B2:
11599  050656  170000                        CFCC                            ;COPY CONDITION CODES.
11600
11601  050660  013703  177776                MOV     @#PSW,R3                ;SEE IF PATTERN TRANSFERED.
11602  050664  042703  177760                BIC     #177760,R3
11603  050670  020003                        CMP     R0,R3
11604  050672  001401                        BEQ     B3
11605  050674  104000                        EMT                     ;
11606  050676  077012                B3:     SOB     R0,B1
11607  050700                        BDONE:
11608  050700  004767  047570                JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
11609                                                                 ;SEE IF THE USER HAS EXPRESSED
11610                                                                 ;THE DESIRE TO CHANGE THE SOFTWARE
11611                                                                 ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
11612                                                                 ;THE USER TYPED CONTROL G?).
11613
11614                                ;*****************************************************************************
11615                                ;TEST 422       SETF, SETD, SETI AND SETL TEST
11616                                ;*****************************************************************************
11617  050704                        TS422:
11618  050704  005000                        CLR     R0
11619
11620  050706  170100                        LDFPS   R0                      ;CLEAR THE FPS.
11621  050710  170001                C15:    SETF                            ;TEST INSTRUCTION.
11622
11623  050712  170201                        STFPS   R1                      ;GET RESULT.
11624  050714  005002                        CLR     R2
11625  050716  020201                        CMP     R2,R1                   ;DID AN ERROR OCCUR?
11626  050720  001401                        BEQ     C2
11627  050722  104000                        EMT                     ;
11628  050724  012700  147757        C2:     MOV     #147757,R0
11629
11630  050730  170100                        LDFPS   R0                      ;PUT 147757 IS FPS
11631  050732  170001                C25:    SETF                            ;CLEAR FD BIT.
11632
11633  050734  170201                        STFPS   R1                      ;GET RESULT
11634  050736  012702  147557                MOV     #147557,R2
11635  050742  020102                        CMP     R1,R2                   ;RESULT CORRECT.
11636  050744  001401                        BEQ     C3
11637  050746  104000                        EMT                     ;
```

```
11638  050750  012700  147757          C3:     MOV     #147757,R0
11639
11640  050754  170100                          LDFPS   R0                      ;LOAD 147757 INTO FPS.
11641  050756  170011                  C35:    SETD                            ;SETD FD BIT.
11642
11643  050760  170201                          STFPS   R1
11644  050762  012702  147757                 MOV     #147757,R2
11645  050766  020102                          CMP     R1,R2                   ;RESULT CORRECT?
11646  050770  001401                          BEQ     C4
11647  050772  104000                          EMT                     ;
11648  050774  005000                  C4:     CLR     R0
11649  050776  170100                          LDFPS   R0                      ;CLEAR FPS.
11650  051000  170011                  C45:    SETD                            ;SET FD BIT.
11651
11652  051002  170201                          STFPS   R1                      ;GET RESULT.
11653  051004  012702  000200                 MOV     #200,R2
11654  051010  020102                          CMP     R1,R2                   ;RESULT CORRECT?
11655  051012  001401                          BEQ     C5
11656  051014  104000                          EMT                     ;
11657  051016  005000                  C5:     CLR     R0
11658
11659  051020  170100                          LDFPS   R0                      ;CLEAR FPS
11660  051022  170002                  C55:    SETI                            ;CLEAR FL BIT.
11661
11662  051024  170201                          STFPS   R1                      ;GET RESULT.
11663  051026  005002                          CLR     R2
11664  051030  020201                          CMP     R2,R1                   ;RESULT CORRECT?
11665  051032  001401                          BEQ     C6
11666  051034  104000                          EMT                     ;
11667  051036  012700  147757          C6:     MOV     #147757,R0
11668  051042  170100                          LDFPS   R0                      ;PUT 147757 INTO FPS
11669  051044  170002                  C65:    SETI                            ;CLEAR FL BIT.
11670
11671  051046  170201                          STFPS   R1                      ;GET THE RESULT.
11672  051050  012702  147657                 MOV     #147657,R2
11673  051054  020102                          CMP     R1,R2                   ;RESULT CORRECT?
11674  051056  001401                          BEQ     C7
11675  051060  104000                          EMT                     ;
11676  051062  012700  147757          C7:     MOV     #147757,R0
11677  051066  170100                          LDFPS   R0                      ;SET FPS TO 147757.
11678  051070  170012                  C75:    SETL                            ;SET FL BIT.
11679
11680  051072  170201                          STFPS   R1                      ;GET THE RESULT.
11681  051074  012702  147757                 MOV     #147757,R2
11682  051100  020102                          CMP     R1,R2                   ;RESULT CORRECT?
11683  051102  001401                          BEQ     C8
11684  051104  104000                          EMT                     ;
11685  051106  005000                  C8:     CLR     R0
11686  051110  170100                          LDFPS   R0                      ;CLEAR FPS.
11687  051112  170012                  C85:    SETL                            ;SET FL BIT.
11688
11689  051114  170201                          STFPS   R1
11690  051116  012702  000100                 MOV     #100,R2
11691  051122  020102                          CMP     R1,R2                   ;RESULT CORRECT.
11692  051124  001401                          BEQ     CDONE
11693  051126  104000                          EMT                     ;
```

```
11694  051130
11695  051130  004767  047340                CDONE:  JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
11696                                                                         ;SEE IF THE USER HAS EXPRESSED
11697                                                                         ;THE DESIRE TO CHANGE THE SOFTWARE
11698                                                                         ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
11699                                                                         ;THE USER TYPED CONTROL G?).
11700
11701
11702                                        ;*****************************************************************************
11703                                        ;TEST 423       ILLEGAL FPP OP CODES AND STST TEST
11704                                        ;*****************************************************************************
11705  051134                                TS423:
11706  051134  012705  170003                       MOV     #170003,R5              ;INITIAL OP CODE.
11707  051140  012737  051200  000004               MOV     #DERR2,@#ERRVECT
11708  051146  012737  051232  000244               MOV     #DERR1,@#FPVECT
11709
11710  051154  005000                        D1:     CLR     R0
11711  051156  170100                                LDFPS   R0                      ;CLEAR FPS.
11712  051160  005002                                CLR     R2
11713  051162  010537  051166                       MOV     R5,@#D2                 ;SET UP THE ILLEGAL INSTRUCTION.
11714  051166  000000                        D2:     .WORD   0
11715  051170  170000                        D3:     CFCC
11716  051172  005202                                INC     R2
11717  051174  005202                        D4:     INC     R2
11718
11719  051176  170201                                STFPS   R1                      ;REPORT FAILURE. DID NOT TRAP.
11720  051200                                DERR2:
11721  051200  104000                                EMT                     ;
11722  051202  022705  170010                D5:     CMP     #170010,R5              ;COMPUTE NEXT OP CODE
11723  051206  001003                                BNE     D6
11724  051210  012705  170013                       MOV     #170013,R5
11725  051214  000757                                BR      D1
11726
11727  051216  022705  170077                D6:     CMP     #170077,R5
11728  051222  001001                                BNE     D7
11729  051224  000424                                BR      DDONE
11730  051226  005205                        D7:     INC     R5
11731  051230  000751                                BR      D1
11732
11733  051232  022716  051170                DERR1:  CMP     #D3,(SP)                ;DID TRAP OCCUR ON TEST INSTRUCTION?
11734  051236  001401                                BEQ     1$
11735  051240  104000                                EMT                     ;
11736  051242  022626                        1$:     CMP     (SP)+,(SP)+
11737  051244  170201                                STFPS   R1                      ;GET THE FPS AND SEE IF IT IS
11738  051246  022701  100000                       CMP     #100000,R1              ;SET CORRECTLY.
11739  051252  001401                                BEQ     3$
11740  051254  104000                                EMT                     ;
11741  051256  012704  000001                3$:     MOV     #1,R4
11742  051262  170304                        D8:     STST    R4                      ;GET THE FEC CODE. NOTE THAT
11743                                                                         ;IF THE DESTINATION MODE IS
11744                                                                         ;IMPROPERLY DECODED AN ODD
11745                                                                         ;ADDRESS TRAP TO 4 SHOULD OCCUR.
11746  051264  022704  000002                       CMP     #2,R4                   ;WAS FEC CORRECT?
11747  051270  001001                                BNE     D9
11748  051272  000743                                BR      D5
11749
```

```
11750  051274
11751  051274  104000                    D9:                                     ;REPORT STST FAILURE
                                                EMT                     ;
11752  051276
11753  051276  004767  047172            DDONE:  JSR     PC,..RSET               ;GO INITIALIZE THE FPS AND STACK; AND
                                                                                ;SEE IF THE USER HAS EXPRESSED
                                                                                ;THE DESIRE TO CHANGE THE SOFTWARE
                                                                                ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
                                                                                ;THE USER TYPED CONTROL G?).
11754
11755                                   ;*****************************************************************************
11756                                   ;TEST 424       FID, INTERRUPT DISABLE, BIT TEST
11757                                   ;*****************************************************************************
11758
11759                                   TS424:
11760  051302
11761  051302  012737  051342  000244           MOV     #EERR0,@#FPVECT         ;SETUP FOR THE INTERRUPT.
11762
11763  051310  012700  040000            E1:     MOV     #40000,R0
11764  051314  170100                           LDFPS   R0                      ;SET FID.
11765  051316  170020                     E3:   .WORD   170020                  ;ILLEGAL FPP INSTRUCTION.
11766  051320  170000                     E4:   CFCC
11767
11768  051322  170201                           STFPS   R1                      ;SEE IF ERROR WAS DETECTED.
11769  051324  022701  140000                   CMP     #140000,R1
11770  051330  001004                           BNE     EERR0
11771
11772  051332  170304                           STST    R4                      ;SEE IF FEC=2
11773  051334  022704  000002                   CMP     #2,R4
11774  051340  001401                           BEQ     EDONE
11775  051342                           EERR0:
11776  051342  104000                           EMT                     ;
11777  051344                           EDONE:
11778  051344  004767  047124                   JSR     PC,..RSET               ;GO INITIALIZE THE FPS AND STACK; AND
                                                                                ;SEE IF THE USER HAS EXPRESSED
                                                                                ;THE DESIRE TO CHANGE THE SOFTWARE
                                                                                ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
                                                                                ;THE USER TYPED CONTROL G?).
11779
11780                                   ;*****************************************************************************
11781                                   ;TEST 425       LDD AND STD, WITH SRC AND DST MODE 1, TEST
11782                                   ;*****************************************************************************
11783
11784  051350                           TS425:
11785
11786  051350  005000                           CLR     R0
11787  051352  170100                           LDFPS   R0
11788  051354  170011                           SETD
11789  051356  012701  051620                   MOV     #FDATI0,R1              ;SET UP THE LOAD DATA.
11790  051362  012702  051664                   MOV     #FXDAT0,R2
11791  051366  012703  000010                   MOV     #10,R3
11792
11793  051372  012221                     F2:   MOV     (R2)+,(R1)+
11794  051374  077302                           SOB     R3,F2
11795
11796  051376  012700  051630                   MOV     #FDATI4,R0              ;SETUP R0 FOR THE LDD (R0),AC0.
11797  051402  012737  051616  000004           MOV     #FERR20,@#ERRVECT       ;IF THE SRC FLOWS FAIL THEN
                                                                                ;AN ODD ADDRESS MAY OCCUR.
11798
11799  051410  005003                           CLR     R3
```

```
11806
11807  051412  172410                F3:     LDD     (R0),AC0
11808  051414  005203                F4:     INC     R3
11809  051416  005203                        INC     R3
11810
11811  051420  020027  051630                CMP     R0,#FDATI4              ;WAS R0 AFFECTED?
11812  051424  001401                        BEQ     F5
11813  051426  104000                        EMT                     ;
11814  051430  020327  000002        F5:     CMP     R3,#2                   ;SEE IF THE PC WAS ADVERSELY
11815  051434  001401                        BEQ     1$
11816  051436  104000                        EMT                     ;
11817  051440  012701  051620        1$:     MOV     #FDATI0,R1              ;MAKE SURE THE SOURCE DATA WAS
11818  051444  012702  051664                MOV     #FXDAT0,R2              ;NOT AFFECTED.
11819  051450  012703  000010                MOV     #10,R3
11820  051454  022122                2$:     CMP     (R1)+,(R2)+
11821  051456  001401                        BEQ     3$
11822  051460  104000                        EMT                     ;
11823  051462  077304                3$:     SOB     R3,2$
11824
11825  051464  170201                        STFPS   R1                      ;MAKE SURE THE FPS IS CORRECT.
11826  051466  022701  000200                CMP     #200,R1
11827  051472  001401                        BEQ     F6
11828  051474  104000                        EMT                     ;
11829  051476  012703  177777        F6:     MOV     #-1,R3
11830  051502  012704  000010                MOV     #10,R4
11831  051506  012705  051642                MOV     #FDAT00,R5              ;SET UP THE OUTPUT DATA BUFFER.
11832  051512  010325                F7:     MOV     R3,(R5)+
11833  051514  077402                        SOB     R4,F7
11834
11835  051516  012700  051652                MOV     #FDAT04,R0              ;SET UP R0 FOR DST MODE 1 REG 0.
11836  051522  012737  051616  000004        MOV     #FERR20,@#ERRVECT       ;IF THE DST FLOWS FAIL AN ODD
11837                                                                         ;ADDRESS COULD OCCUR.
11838  051530  005003                        CLR     R3
11839
11840  051532  174010                F10:    STD     AC0,(R0)                ;TEST INSTRUCTION.
11841  051534  005203                F11:    INC     R3
11842  051536  005203                        INC     R3
11843
11844  051540  020027  051652                CMP     R0,#FDAT04              ;WAS R0 MODIFIED?
11845  051544  001401                        BEQ     F12
11846  051546  104000                        EMT                     ;
11847  051550  020327  000002        F12:    CMP     R3,#2                   ;WAS THE PC AFFECTED CORRECTLY?
11848  051554  001401                        BEQ     F135
11849  051556  104000                        EMT                     ;
11850  051560  012701  051642        F135:   MOV     #FDAT00,R1
11851  051564  012702  051664                MOV     #FXDAT0,R2
11852  051570  012703  000010                MOV     #10,R3                  ;SETUP LOOP COUNT
11853  051574  022122                F13:    CMP     (R1)+,(R2)+             ;WAS DATA OUTPUT CORRECTLY
11854  051576  001401                        BEQ     F14
11855  051600  104000                        EMT                     ;
11856  051602  077304                F14:    SOB     R3,F13                  ;SUBTRACT 1 FROM LOOP COUNT AND LOOP IF NOT ZERO
11857  051604  005001                F22:    CLR     R1
11858  051606  170201                        STFPS   R1                      ;MAKE SURE FPS IS CORRECT.
11859  051610  022701  000200                CMP     #200,R1
11860  051614  001433                        BEQ     FDONE
11861  051616                        FERR20:
```

```
11862  051616  104000                  EMT                     ;
11863
11864  051620  177777          FDATI0: -1
11865  051622  177777          FDATI1: -1
11866  051624  177777          FDATI2: -1
11867  051626  177777          FDATI3: -1
11868  051630  177777          FDATI4: -1
11869  051632  177777          FDATI5: -1
11870  051634  177777          FDATI6: -1
11871  051636  177777          FDATI7: -1
11872  051640  177777                  -1
11873  051642  177777          FDATO0: -1
11874  051644  177777          FDATO1: -1
11875  051646  177777          FDATO2: -1
11876  051650  177777          FDATO3: -1
11877  051652  177777          FDATO4: -1
11878  051654  177777          FDATO5: -1
11879  051656  177777          FDATO6: -1
11880  051660  177777          FDATO7: -1
11881  051662  177777                  -1
11882  051664  177777          FXDAT0: -1
11883  051666  177777          FXDAT1: -1
11884  051670  177777          FXDAT2: -1
11885  051672  177777          FXDAT3: -1
11886  051674  052525          FXDAT4: 052525
11887  051676  031463          FXDAT5: 031463
11888  051700  007417          FXDAT6: 007417
11889  051702  000477          FXDAT7: 000477
11890
11891
11892  051704                  FDONE:
11893  051704  004767  046564          JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
11894                                                          ;SEE IF THE USER HAS EXPRESSED
11895                                                          ;THE DESIRE TO CHANGE THE SOFTWARE
11896                                                          ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
11897                                                          ;THE USER TYPED CONTROL G?).
11898
11899
11900                           ;*****************************************************************************
11901                           ;TEST 426       FSRC MODE 0 TEST
11902                           ;*****************************************************************************
11903  051710                  TS426:
11904  051710                  I1:
11905  051710  170011                  SETD                    ;SET FD.
11906  051712  012700  052176          MOV     #IDATI0,R0
11907  051716  012701  052146          MOV     #IPATI0,R1
11908  051722  012702  000004          MOV     #4,R2
11909  051726  012120          I2:     MOV     (R1)+,(R0)+     ;SET UP THE INPUT DATA BUFFER.
11910  051730  077202                  SOB     R2,I2
11911
11912  051732  012700  052176          MOV     #IDATI0,R0      ;LOAD AC1
11913  051736  172510                  LDD     (R0),AC1
11914
11915  051740  012700  052156          MOV     #IPAT20,R0      ;LOAD AC0
11916  051744  172410                  LDD     (R0),AC0
11917
```

```
11918  051746  012701  000001          MOV     #1,R1                   ;IN CASE THE FSRC FLOWS FAIL
11919  051752  172401                  I3:     LDD     AC1,AC0         ;TEST INSTRUCTION.
11920  051754  000240                  I4:     NOP
11921  051756  000240                  I5:     NOP
11922
11923  051760  012700  052166                  MOV     #IDAT00,R0
11924  051764  174010                          STD     AC0,(R0)        ;GET AC0, THE RESULTS.
11925
11926  051766  012700  052166                  MOV     #IDAT00,R0      ;SEE IF DATA IS CORRECT.
11927  051772  012701  052176                  MOV     #IDAT10,R1
11928  051776  012702  000004                  MOV     #4,R2
11929  052002  022021                  I6:     CMP     (R0)+,(R1)+
11930  052004  001401                          BEQ     I105
11931  052006  104000                          EMT                     ;
11932  052010  077204                  I105:   SOB     R2,I6
11933
11934                                   ;NOW TEST THE LOAD INSTRUCTION WITH FSRC MODE ZERO AND FD CLEAR.
11935
11936  052012  012700  052146          I12:    MOV     #IPAT10,R0
11937  052016  012701  052176                  MOV     #IDAT10,R1
11938  052022  012702  000004                  MOV     #4,R2
11939  052026  012021                  I13:    MOV     (R0)+,(R1)+
11940  052030  077202                          SOB     R2,I13
11941
11942  052032  012700  052176                  MOV     #IDAT10,R0      ;SET UP AC1
11943  052036  172510                          LDD     (R0),AC1
11944
11945  052040  012700  052156                  MOV     #IPAT20,R0      ;SET UP AC0
11946  052044  172410                          LDD     (R0),AC0
11947
11948  052046  012701  000001                  MOV     #1,R1
11949  052052  170001                          SETF                    ;CLEAR FD.
11950
11951  052054  172401                  I14:    LDF     AC1,AC0         ;TEST INSTRUCTION.
11952  052056  000240                  I15:    NOP
11953  052060  000240                  I16:    NOP
11954
11955  052062  170200                          STFPS   R0              ;SEE IF FPS IS STILL CLEAR.
11956  052064  022700  000004                  CMP     #4,R0
11957  052070  001401                          BEQ     I17
11958  052072  104000                          EMT                     ;
11959  052074                          I17:                            ;RESET TO DOUBLE MODE.
11960  052074  170011                          SETD
11961
11962  052076  012700  052166                  MOV     #IDAT00,R0
11963  052102  174010                          STD     AC0,(R0)        ;GET AC0
11964
11965  052104  012737  177777  052202          MOV     #-1,@#IDAT12
11966  052112  012737  177777  052204          MOV     #-1,@#IDAT13
11967  052120  012700  052166                  MOV     #IDAT00,R0
11968  052124  012701  052176                  MOV     #IDAT10,R1
11969  052130  012702  000004                  MOV     #4,R2
11970  052134  022021                  I20:    CMP     (R0)+,(R1)+     ;SEE IF AC0 WAS CORRECT.
11971  052136  001401                          BEQ     I23
11972  052140  104000                          EMT                     ;
11973  052142  077204                  I23:    SOB     R2,I20
```

```
11974  052144  000420                    BR      IDONE                   ;NO ERRORS.
11975
11976  052146  000000                    IPAT10: 0
11977  052150  170360                    IPAT11: 170360
11978  052152  016161                    IPAT12: 016161
11979  052154  052525                    IPAT13: 052525
11980
11981  052156  177777                    IPAT20: -1
11982  052160  177777                    IPAT21: -1
11983  052162  177777                    IPAT22: -1
11984  052164  177777                    IPAT23: -1
11985
11986  052166  000000                    IDAT00: 0
11987  052170  000000                    IDAT01: 0
11988  052172  000000                    IDAT02: 0
11989  052174  000000                    IDAT03: 0
11990
11991  052176  000000                    IDATI0: 0
11992  052200  000000                    IDATI1: 0
11993  052202  000000                    IDATI2: 0
11994  052204  000000                    IDATI3: 0
11995
11996  052206                            IDONE:
11997  052206  004767  046262                    JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
11998                                                                    ;SEE IF THE USER HAS EXPRESSED
11999                                                                    ;THE DESIRE TO CHANGE THE SOFTWARE
12000                                                                    ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
12001                                                                    ;THE USER TYPED CONTROL G?).
12002
12003
12004                                   ;*************************************  *********************************************
12005                                   ;TEST 427       FDST MODE 0 TEST
12006                                   ;*************************************  *********************************************
12007  052212                           TS427:
12008  052212  170011                            SETD                    ;SET FD
12009  052214  012700  052452                    MOV     #TPAT10,R0
12010  052220  012701  052502                    MOV     #TDATI0,R1
12011  052224  012702  000004                    MOV     #4,R2
12012  052230  012021                   T2:      MOV     (R0)+,(R1)+     ;SET UP THE INPUT DATA BUFFER.
12013  052232  077202                            SOB     R2,T2
12014
12015  052234  012700  052502                    MOV     #TDATI0,R0      ;LOAD AC0
12016  052240  172410                            LDD     (R0),AC0
12017
12018  052242  012700  052462                    MOV     #TPAT20,R0      ;LOAD AC1
12019  052246  172510                            LDD     (R0),AC1
12020
12021  052250  012701  000001                    MOV     #1,R1           ;IF THE (BUT FDST) FORK FAILS
12022  052254  174001                   T3:      STD     AC0,AC1
12023  052256  000240                   T4:      NOP
12024  052260  000240                   T5:      NOP
12025
12026  052262  012700  052472                    MOV     #TDAT00,R0
12027  052266  174110                            STD     AC1,(R0)        ;GET THE DATA.
12028
12029  052270  012703  052472                    MOV     #TDAT00,R3      ;SEE IF THE DATA IS CORRECT.
```

```
12030  052274  012704  052502          MOV     #TDATI0,R4
12031  052300  012705  000004          MOV     #4,R5
12032  052304  022324          T6:     CMP     (R3)+,(R4)+
12033  052306  001401                  BEQ     T105
12034  052310  104000                  EMT                     ;
12035  052312  077504          T105:   SOB     R5,T6
12036
12037                                  .NOW TEST THE STF AC0,AC1 INSTRUCTION.
12038
12039  052314  012700  052452  T12:    MOV     #TPAT10,R0              ;SET UP THE INPUT DATA BUFFER.
12040  052320  012701  052502          MOV     #TDATI0,R1
12041  052324  012702  000004          MOV     #4,R2
12042  052330  012021          T13:    MOV     (R0)+,(R1)+
12043  052332  077202                  SOB     R2,T13
12044
12045  052334  012700  052502          MOV     #TDATI0,R0              ;SET UP AC0
12046  052340  172410                  LDD     (R0),AC0
12047
12048  052342  012700  052462          MOV     #TPAT20,R0              ;SET UP AC1
12049  052346  172510                  LDD     (R0),AC1
12050
12051  052350  012701  000001          MOV     #1,R1
12052  052354  170001                  SETF                            ;CLEAR FD
12053  052356  174001          T14:    STF     AC0,AC1
12054  052360  000240          T15:    NOP
12055  052362  000240          T16:    NOP
12056
12057  052364  005000                  CLR     R0
12058  052366  170200                  STFPS   R0                      ;SEE IF FPS IS CLEAR.
12059  052370  022700  000010          CMP     #10,R0
12060  052374  001401                  BEQ     T17
12061  052376  104000                  EMT                     ;
12062  052400                  T17:
12063  052400  170011                  SETD                            ;SET FD.
12064
12065  052402  012700  052472          MOV     #TDAT00,R0
12066  052406  174110                  STD     AC1,(R0)                ;PICK UP AC1.
12067
12068  052410  012737  177777  052506  MOV     #-1,a#TDATI2
12069  052416  012737  177777  052510  MOV     #-1,a#TDATI3
12070  052424  012703  052472          MOV     #TDAT00,R3
12071  052430  012704  052502          MOV     #TDATI0,R4
12072  052434  012705  000004          MOV     #4,R5
12073  052440  022324          T20:    CMP     (R3)+,(R4)+             ;WAS THE DATA TRANSFERRED CORRECTLY?
12074  052442  001401                  BEQ     T23
12075  052444  104000                  EMT                     ;
12076  052446  077504          T23:    SOB     R5,T20
12077  052450  000420                  BR      TDONE
12078
12079
12080  052452  000000          TPAT10: 0
12081  052454  170360          TPAT11: 170360
12082  052456  016161          TPAT12: 016161
12083  052460  052525          TPAT13: 052525
12084
12085  052462  177777          TPAT20: -1
```

```
12086  052464  177777                  TPAT21: -1
12087  052466  177777                  TPAT22: -1
12088  052470  177777                  TPAT23: -1
12089
12090  052472  000000                  TDAT00: 0
12091  052474  000000                  TDAT01: 0
12092  052476  000000                  TDAT02: 0
12093  052500  000000                  TDAT03: 0
12094
12095  052502  000000                  TDATI0: 0
12096  052504  000000                  TDATI1: 0
12097  052506  000000                  TDATI2: 0
12098  052510  000000                  TDATI3: 0
12099
12100  052512                          TDONE:
12101  052512  004767  045756                JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
12102                                                                  ;SEE IF THE USER HAS EXPRESSED
12103                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
12104                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
12105                                                                  ;THE USER TYPED CONTROL G?).
12106
12107
12108
12109                           ;*****************************************************************************
12110                           ;TEST 430       ACCUMULATORS DATA PATTERNS TEST
12111                           ;*****************************************************************************
12112  052516                  TS430:
12113  052516  170011                  SETD                            ;SET FD.
12114                          ;TEST ACCUMULATOR 0 WITH FLOATING ONE
12115  052520  012700  054252          MOV     #GPAT00,R0
12116  052524  012701  054312          MOV     #GDAT00,R1
12117  052530  004737  054124          JSR     PC,@#GSETUP             ;LOAD TEST PATTERN.
12118  052534  012703  000102          MOV     #102,R3
12119  052540                  G1:
12120  052540  172410                  LDD     (R0),AC0
12121  052542  174000                  STD     AC0,AC0
12122  052544  172400                  LDD     AC0,AC0         ;STORE THE TEST PATTERN.
12123  052546  174011                  STD     AC0,(R1)
12124  052550  004737  054222          JSR     PC,@#GCMP               ;COMPARE THE DATA READ WITH
12125                                                                  ;THAT WHICH WAS WRITTEN.
12126  052554  005737  054246          TST     @#GFLAG1
12127  052560  001004                  BNE     G2
12128  052562  005137  054246          COM     @#GFLAG1
12129  052566  000261                  SEC
12130  052570  000401                  BR      G3
12131  052572  000241          G2:     CLC
12132  052574  006160  000006  G3:     ROL     6(R0)                   ;GENERATE THE NEXT TEST PATTERN.
12133  052600  006160  000004          ROL     4(R0)
12134  052604  006160  000002          ROL     2(R0)
12135  052610  006110                  ROL     (R0)
12136  052612  004737  054202          JSR     PC,@#GRESET             ;RESET DEFAULT PATTERN IN OUTPUT
12137                                                                  ;BUFFER.
12138  052616  077330                  SOB     R3,G1
12139
12140                          ;TEST ACCUMULATOR 0 WITH FLOATING ZERO
12141  052620  012700  054262          MOV     #GPAT10,R0
```

```
12142  052624  012701  054312          MOV     #GDAT00,R1
12143  052630  004737  054124          JSR     PC,@#GSETUP             ;LOAD TEST PATTERN.
12144  052634  012703  000102          MOV     #102,R3
12145  052640                  G4:
12146  052640  172410                  LDD     (R0),AC0
12147  052642  174000                  STD     AC0,AC0
12148  052644  172400                  LDD     AC0,AC0         ;STORE THE TEST PATTERN.
12149  052646  174011                  STD     AC0,(R1)
12150  052650  004737  054222          JSR     PC,@#GCMP               ;COMPARE THE DATA READ WITH
12151                                                                   ;THAT WHICH WAS WRITTEN.
12152  052654  005737  054246          TST     @#GFLAG1
12153  052660  001004                  BNE     G5
12154  052662  005137  054246          COM     @#GFLAG1
12155  052666  000241                  CLC
12156  052670  000401                  BR      G6
12157  052672  000261          G5:     SEC
12158  052674  006160  000006  G6:     ROL     6(R0)                   ;GENERATE THE NEXT TEST PATTERN.
12159  052700  006160  000004          ROL     4(R0)
12160  052704  006160  000002          ROL     2(R0)
12161  052710  006110                  ROL     (R0)
12162  052712  004737  054202          JSR     PC,@#GRESET             ;RESET DEFAULT PATTERN IN OUTPUT
12163                                                                   ;BUFFER.
12164  052716  077330                  SOB     R3,G4
12165
12166                          ;TEST ACCUMULATOR 1 WITH FLOATING ONE
12167  052720  012700  054252          MOV     #GPAT00,R0
12168  052724  012701  054312          MOV     #GDAT00,R1
12169  052730  004737  054124          JSR     PC,@#GSETUP             ;LOAD TEST PATTERN.
12170  052734  012703  000102          MOV     #102,R3
12171  052740                  G7:
12172  052740  172410                  LDD     (R0),AC0
12173  052742  174001                  STD     AC0,AC1
12174  052744  172401                  LDD     AC1,AC0         ;STORE THE TEST PATTERN.
12175  052746  174011                  STD     AC0,(R1)
12176  052750  004737  054222          JSR     PC,@#GCMP               ;COMPARE THE DATA READ WITH
12177                                                                   ;THAT WHICH WAS WRITTEN.
12178  052754  005737  054246          TST     @#GFLAG1
12179  052760  001004                  BNE     G10
12180  052762  005137  054246          COM     @#GFLAG1
12181  052766  000261                  SEC
12182  052770  000401                  BR      G11
12183  052772  000241          G10:    CLC
12184  052774  006160  000006  G11:    ROL     6(R0)                   ;GENERATE THE NEXT TEST PATTERN.
12185  053000  006160  000004          ROL     4(R0)
12186  053004  006160  000002          ROL     2(R0)
12187  053010  006110                  ROL     (R0)
12188  053012  004737  054202          JSR     PC,@#GRESET             ;RESET DEFAULT PATTERN IN OUTPUT
12189                                                                   ;BUFFER.
12190  053016  077330                  SOB     R3,G7
12191
12192                          ;TEST ACCUMULATOR 1 WITH FLOATING ZERO
12193  053020  012700  054262          MOV     #GPAT10,R0
12194  053024  012701  054312          MOV     #GDAT00,R1
12195  053030  004737  054124          JSR     PC,@#GSETUP             ;LOAD TEST PATTERN.
12196  053034  012703  000102          MOV     #102,R3
12197  053040                  G12:
```

```
12198  053040  172410                  LDD     (R0),AC0
12199  053042  174001                  STD     AC0,AC1
12200  053044  172401                  LDD     AC1,AC0         ;STORE THE TEST PATTERN.
12201  053046  174011                  STD     AC0,(R1)
12202  053050  004737  054222          JSR     PC,@#GCMP               ;COMPARE THE DATA READ WITH
12203                                                                   ;THAT WHICH WAS WRITTEN.
12204  053054  005737  054246          TST     @#GFLAG1
12205  053060  001004                  BNE     G13
12206  053062  005137  054246          COM     @#GFLAG1
12207  053066  000241                  CLC
12208  053070  000401                  BR      G14
12209  053072  000261          G13:    SEC
12210  053074  006160  000006  G14:    ROL     6(R0)                   ;GENERATE THE NEXT TEST PATTERN.
12211  053100  006160  000004          ROL     4(R0)
12212  053104  006160  000002          ROL     2(R0)
12213  053110  006110                  ROL     (R0)
12214  053112  004737  054202          JSR     PC,@#GRESET             ;RESET DEFAULT PATTERN IN OUTPUT
12215                                                                   ;BUFFER.
12216  053116  077330                  SOB     R3,G12
12217
12218                                  ;TEST ACCUMULATOR 2 WITH FLOATING ONE
12219  053120  012700  054252          MOV     #GPAT00,R0
12220  053124  012701  054312          MOV     #GDAT00,R1
12221  053130  004737  054124          JSR     PC,@#GSETUP             ;LOAD TEST PATTERN.
12222  053134  012703  000102          MOV     #102,R3
12223  053140                  G15:
12224  053140  172410                  LDD     (R0),AC0
12225  053142  174002                  STD     AC0,AC2
12226  053144  172402                  LDD     AC2,AC0         ;STORE THE TEST PATTERN.
12227  053146  174011                  STD     AC0,(R1)
12228  053150  004737  054222          JSR     PC,@#GCMP               ;COMPARE THE DATA READ WITH
12229                                                                   ;THAT WHICH WAS WRITTEN.
12230  053154  005737  054246          TST     @#GFLAG1
12231  053160  001004                  BNE     G16
12232  053162  005137  054246          COM     @#GFLAG1
12233  053166  000261                  SEC
12234  053170  000401                  BR      G17
12235  053172  000241          G16:    CLC
12236  053174  006160  000006  G17:    ROL     6(R0)                   ;GENERATE THE NEXT TEST PATTERN.
12237  053200  006160  000004          ROL     4(R0)
12238  053204  006160  000002          ROL     2(R0)
12239  053210  006110                  ROL     (R0)
12240  053212  004737  054202          JSR     PC,@#GRESET             ;RESET DEFAULT PATTERN IN OUTPUT
12241                                                                   ;BUFFER.
12242  053216  077330                  SOB     R3,G15
12243
12244                                  ;TEST ACCUMULATOR 2 WITH FLOATING ZERO
12245  053220  012700  054262          MOV     #GPAT10,R0
12246  053224  012701  054312          MOV     #GDAT00,R1
12247  053230  004737  054124          JSR     PC,@#GSETUP             ;LOAD TEST PATTERN.
12248  053234  012703  000102          MOV     #102,R3
12249  053240                  G20:
12250  053240  172410                  LDD     (R0),AC0
12251  053242  174002                  STD     AC0,AC2
12252  053244  172402                  LDD     AC2,AC0         ;STORE THE TEST PATTERN.
12253  053246  174011                  STD     AC0,(R1)
```

```
12254  053250  004737  054222          JSR     PC,@#GCMP               ;COMPARE THE DATA READ WITH
12255                                                                   ;THAT WHICH WAS WRITTEN.
12256  053254  005737  054246          TST     @#GFLAG1
12257  053260  001004                  BNE     G21
12258  053262  005137  054246          COM     @#GFLAG1
12259  053266  000241                  CLC
12260  053270  000401                  BR      G22
12261  053272  000261          G21:    SEC
12262  053274  006160  000006  G22:    ROL     6(R0)                   ;GENERATE THE NEXT TEST PATTERN.
12263  053300  006160  000004          ROL     4(R0)
12264  053304  006160  000002          ROL     2(R0)
12265  053310  006110                  ROL     (R0)
12266  053312  004737  054202          JSR     PC,@#GRESET             ;RESET DEFAULT PATTERN IN OUTPUT
12267                                                                   ;BUFFER.
12268  053316  077330                  SOB     R3,G20
12269
12270                                  ;TEST ACCUMULATOR 3 WITH FLOATING ONE
12271  053320  012700  054252          MOV     #GPAT00,R0
12272  053324  012701  054312          MOV     #GDAT00,R1
12273  053330  004737  054124          JSR     PC,@#GSETUP             ;LOAD TEST PATTERN.
12274  053334  012703  000102          MOV     #102,R3
12275  053340                  G23:
12276  053340  172410                  LDD     (R0),AC0
12277  053342  174003                  STD     AC0,AC3
12278  053344  172403                  LDD     AC3,AC0         ;STORE THE TEST PATTERN.
12279  053346  174011                  STD     AC0,(R1)
12280  053350  004737  054222          JSR     PC,@#GCMP               ;COMPARE THE DATA READ WITH
12281                                                                   ;THAT WHICH WAS WRITTEN.
12282  053354  005737  054246          TST     @#GFLAG1
12283  053360  001004                  BNE     G24
12284  053362  005137  054246          COM     @#GFLAG1
12285  053366  000261                  SEC
12286  053370  000401                  BR      G25
12287  053372  000241          G24:    CLC
12288  053374  006160  000006  G25:    ROL     6(R0)                   ;GENERATE THE NEXT TEST PATTERN.
12289  053400  006160  000004          ROL     4(R0)
12290  053404  006160  000002          ROL     2(R0)
12291  053410  006110                  ROL     (R0)
12292  053412  004737  054202          JSR     PC,@#GRESET             ;RESET DEFAULT PATTERN IN OUTPUT
12293                                                                   ;BUFFER.
12294  053416  077330                  SOB     R3,G23
12295
12296                                  ;TEST ACCUMULATOR 3 WITH FLOATING ZERO
12297  053420  012700  054262          MOV     #GPAT10,R0
12298  053424  012701  054312          MOV     #GDAT00,R1
12299  053430  004737  054124          JSR     PC,@#GSETUP             ;LOAD TEST PATTERN.
12300  053434  012703  000102          MOV     #102,R3
12301  053440                  G26:
12302  053440  172410                  LDD     (R0),AC0
12303  053442  174003                  STD     AC0,AC3
12304  053444  172403                  LDD     AC3,AC0         ;STORE THE TEST PATTERN.
12305  053446  174011                  STD     AC0,(R1)
12306  053450  004737  054222          JSR     PC,@#GCMP               ;COMPARE THE DATA READ WITH
12307                                                                   ;THAT WHICH WAS WRITTEN.
12308  053454  005737  054246          TST     @#GFLAG1
12309  053460  001004                  BNE     G27
```

```
12310  053462  005137  054246                COM     @#GFLAG1
12311  053466  000241                        CLC
12312  053470  000401                        BR      G30
12313  053472  000261                G27:    SEC
12314  053474  006160  000006        G30:    ROL     6(R0)                   ;GENERATE THE NEXT TEST PATTERN.
12315  053500  006160  000004                ROL     4(R0)
12316  053504  006160  000002                ROL     2(R0)
12317  053510  006110                        ROL     (R0)
12318  053512  004737  054202                JSR     PC,@#GRESET             ;RESET DEFAULT PATTERN IN OUTPUT
12319                                                                         ;BUFFER.
12320  053516  077330                        SOB     R3,G26
12321
12322                                ;TEST ACCUMULATOR 4 WITH FLOATING ONE
12323  053520  012700  054252                MOV     #GPAT00,R0
12324  053524  012701  054312                MOV     #GDAT00,R1
12325  053530  004737  054124                JSR     PC,@#GSETUP             ;LOAD TEST PATTERN.
12326  053534  012703  000102                MOV     #102,R3
12327  053540                        G31:
12328  053540  172410                        LDD     (R0),AC0
12329  053542  174004                        STD     AC0,AC4
12330  053544  172404                        LDD     AC4,AC0         ;STORE THE TEST PATTERN.
12331  053546  174011                        STD     AC0,(R1)
12332  053550  004737  054222                JSR     PC,@#GCMP               ;COMPARE THE DATA READ WITH
12333                                                                         ;THAT WHICH WAS WRITTEN.
12334  053554  005737  054246                TST     @#GFLAG1
12335  053560  001004                        BNE     G32
12336  053562  005137  054246                COM     @#GFLAG1
12337  053566  000261                        SEC
12338  053570  000401                        BR      G33
12339  053572  000241                G32:    CLC
12340  053574  006160  000006        G33:    ROL     6(R0)                   ;GENERATE THE NEXT TEST PATTERN.
12341  053600  006160  000004                ROL     4(R0)
12342  053604  006160  000002                ROL     2(R0)
12343  053610  006110                        ROL     (R0)
12344  053612  004737  054202                JSR     PC,@#GRESET             ;RESET DEFAULT PATTERN IN OUTPUT
12345                                                                         ;BUFFER.
12346  053616  077330                        SOB     R3,G31
12347
12348                                ;TEST ACCUMULATOR 4 WITH FLOATING ZERO
12349  053620  012700  054262                MOV     #GPAT10,R0
12350  053624  012701  054312                MOV     #GDAT00,R1
12351  053630  004737  054124                JSR     PC,@#GSETUP             ;LOAD TEST PATTERN.
12352  053634  012703  000102                MOV     #102,R3
12353  053640                        G34:
12354  053640  172410                        LDD     (R0),AC0
12355  053642  174004                        STD     AC0,AC4
12356  053644  172404                        LDD     AC4,AC0         ;STORE THE TEST PATTERN.
12357  053646  174011                        STD     AC0,(R1)
12358  053650  004737  054222                JSR     PC,@#GCMP               ;COMPARE THE DATA READ WITH
12359                                                                         ;THAT WHICH WAS WRITTEN.
12360  053654  005737  054246                TST     @#GFLAG1
12361  053660  001004                        BNE     G35
12362  053662  005137  054246                COM     @#GFLAG1
12363  053666  000241                        CLC
12364  053670  000401                        BR      G36
12365  053672  000261                G35:    SEC
```

```
12366  053674  006160  000006  G36:    ROL     6(R0)                   ;GENERATE THE NEXT TEST PATTERN.
12367  053700  006160  000004          ROL     4(R0)
12368  053704  006160  000002          ROL     2(R0)
12369  053710  006110                  ROL     (R0)
12370  053712  004737  054202          JSR     PC,@#GRESET             ;RESET DEFAULT PATTERN IN OUTPUT
12371                                                                  ;BUFFER.
12372  053716  077330                  SOB     R3,G34
12373
12374                          ;TEST ACCUMULATOR 5 WITH FLOATING ONE
12375  053720  012700  054252          MOV     #GPAT00,R0
12376  053724  012701  054312          MOV     #GDAT00,R1
12377  053730  004737  054124          JSR     PC,@#GSETUP             ;LOAD TEST PATTERN.
12378  053734  012703  000102          MOV     #102,R3
12379  053740                  G37:
12380  053740  172410                  LDD     (R0),AC0
12381  053742  174005                  STD     AC0,AC5
12382  053744  172405                  LDD     AC5,AC0         ;STORE THE TEST PATTERN.
12383  053746  174011                  STD     AC0,(R1)
12384  053750  004737  054222          JSR     PC,@#GCMP               ;COMPARE THE DATA READ WITH
12385                                                                  ;THAT WHICH WAS WRITTEN.
12386  053754  005737  054246          TST     @#GFLAG1
12387  053760  001004                  BNE     G40
12388  053762  005137  054246          COM     @#GFLAG1
12389  053766  000261                  SEC
12390  053770  000401                  BR      G41
12391  053772  000241          G40:    CLC
12392  053774  006160  000006  G41:    ROL     6(R0)                   ;GENERATE THE NEXT TEST PATTERN.
12393  054000  006160  000004          ROL     4(R0)
12394  054004  006160  000002          ROL     2(R0)
12395  054010  006110                  ROL     (R0)
12396  054012  004737  054202          JSR     PC,@#GRESET             ;RESET DEFAULT PATTERN IN OUTPUT
12397                                                                  ;BUFFER.
12398  054016  077330                  SOB     R3,G37
12399
12400                          ;TEST ACCUMULATOR 5 WITH FLOATING ZERO
12401  054020  012700  054262          MOV     #GPAT10,R0
12402  054024  012701  054312          MOV     #GDAT00,R1
12403  054030  004737  054124          JSR     PC,@#GSETUP             ;LOAD TEST PATTERN.
12404  054034  012703  000102          MOV     #102,R3
12405  054040                  G42:
12406  054040  172410                  LDD     (R0),AC0
12407  054042  174005                  STD     AC0,AC5
12408  054044  172405                  LDD     AC5,AC0         ;STORE THE TEST PATTERN.
12409  054046  174011                  STD     AC0,(R1)
12410  054050  004737  054222          JSR     PC,@#GCMP               ;COMPARE THE DATA READ WITH
12411                                                                  ;THAT WHICH WAS WRITTEN.
12412  054054  005737  054246          TST     @#GFLAG1
12413  054060  001004                  BNE     G43
12414  054062  005137  054246          COM     @#GFLAG1
12415  054066  000241                  CLC
12416  054070  000401                  BR      G44
12417  054072  000261          G43:    SEC
12418  054074  006160  000006  G44:    ROL     6(R0)                   ;GENERATE THE NEXT TEST PATTERN.
12419  054100  006160  000004          ROL     4(R0)
12420  054104  006160  000002          ROL     2(R0)
12421  054110  006110                  ROL     (R0)
```

```
12422  054112  004737  054202                  JSR     PC,@#GRESET             ;RESET DEFAULT PATTERN IN OUTPUT
12423                                                                           ;BUFFER.
12424  054116  077330                          SOB     R3,G42
12425
12426
12427  054120  000137  054322                  JMP     @#GDONE
12428
12429                                  ;USE THIS ROUTINE TO INITIALIZE ALL THE DATA BUFFERS.
12430  054124  012705  054246          GSETUP: MOV     #GFLAG1,R5
12431  054130  012704  000026                  MOV     #26,R4
12432  054134  005025                  1$:     CLR     (R5)+
12433  054136  077402                          SOB     R4,1$
12434
12435  054140  012705  054262                  MOV     #GPAT10,R5
12436  054144  012704  000010                  MOV     #10,R4
12437  054150  005125                  2$:     COM     (R5)+
12438  054152  077402                          SOB     R4,2$
12439
12440  054154  020067  000072          GS1:    CMP     R0,GPAT00
12441  054160  001401                          BEQ     3$
12442  054162  000207                          RTS     PC
12443
12444  054164  012705  054312          3$:     MOV     #GDAT00,R5
12445  054170  012704  000004                  MOV     #4,R4
12446  054174  005125                  4$:     COM     (R5)+
12447  054176  077402                          SOB     R4,4$
12448  054200  000207                          RTS     PC
12449
12450  054202  012705  054312          GRESET: MOV     #GDAT00,R5
12451  054206  012704  000004                  MOV     #4,R4
12452  054212  005025                  1$:     CLR     (R5)+
12453  054214  077402                          SOB     R4,1$
12454  054216  000137  054154                  JMP     @#GS1
12455
12456                                  ;SEE IF THE DATA WRITTEN MATCHES THE DATA READ.
12457  054222  012705  054312          GCMP:   MOV     #GDAT00,R5
12458  054226  012704  000004                  MOV     #4,R4
12459  054232  010002                          MOV     R0,R2
12460  054234  022225                  1$:     CMP     (R2)+,(R5)+
12461  054236  001401                          BEQ     2$
12462  054240  104000                          EMT                     ;
12463  054242  077404                  2$:     SOB     R4,1$
12464  054244  000207                          RTS     PC
12465
12466
12467
12468
12469  054246  000000          GFLAG1: 0
12470  054250  000000          GFLAG2: 0
12471
12472  054252  000000          GPAT00: 0
12473  054254  000000          GPAT01: 0
12474  054256  000000          GPAT02: 0
12475  054260  000000          GPAT03: 0
12476
12477  054262  177777          GPAT10: -1
```

```
12478  054264  177777                  GPAT11: -1
12479  054266  177777                  GPAT12: -1
12480  054270  177777                  GPAT13: -1
12481
12482  054272  177777                  GAND0:  -1
12483  054274  177777                  GAND1:  -1
12484  054276  177777                  GAND2:  -1
12485  054300  177777                  GAND3:  -1
12486
12487  054302  000000                  GOR0:   0
12488  054304  000000                  GOR1:   0
12489  054306  000000                  GOR2:   0
12490  054310  000000                  GOR3:   0
12491
12492  054312  000000                  GDAT00: 0
12493  054314  000000                  GDAT01: 0
12494  054316  000000                  GDAT02: 0
12495  054320  000000                  GDAT03: 0
12496
12497
12498  054322                          GDONE:
12499  054322  004767  044146                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
12500                                                                  ;SEE IF THE USER HAS EXPRESSED
12501                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
12502                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
12503                                                                  ;THE USER TYPED CONTROL G?).
12504
12505
12506                                  ;*************************************************************************************
12507                                  ;TEST 431       FPP ACCUMULATORS DUAL ADDRESS TEST
12508                                  ;*************************************************************************************
12509  054326                          TS431:
12510  054326  005037  055016          H1:     CLR     @#HFLAG
12511  054332  012700  055020                  MOV     #HA1W,R0                ;INITIALIZE THE LOAD BUFFER DATA.
12512  054336  012701  055140                  MOV     #HDAT1,R1
12513  054342  012703  000024                  MOV     #24,R3
12514  054346  012120                  H2:     MOV     (R1)+,(R0)+
12515  054350  077302                          SOB     R3,H2
12516
12517  054352  004767  000420                  JSR     PC,HCLR         ;CLEAR THE OUTPUT DATA BUFFER.
12518
12519  054356  170011                  H3:     SETD
12520                                  ;LOAD ACCUMULATOR 1
12521  054360  012700  055020                  MOV     #HA1W,R0
12522  054364  172410                          LDD     (R0),AC0
12523  054366  174001                          STD     AC0,AC1
12524                                  ;LOAD ACCUMULATOR 2
12525  054370  012700  055030                  MOV     #HA2W,R0
12526  054374  172410                          LDD     (R0),AC0
12527  054376  174002                          STD     AC0,AC2
12528                                  ;LOAD ACCUMULATOR 3
12529  054400  012700  055040                  MOV     #HA3W,R0
12530  054404  172410                          LDD     (R0),AC0
12531  054406  174003                          STD     AC0,AC3
12532                                  ;LOAD ACCUMULATOR 4
12533  054410  012700  055050                  MOV     #HA4W,R0
```

```
12534  054414  172410                  LDD     (R0),AC0
12535  054416  174004                  STD     AC0,AC4
12536                          ;LOAD ACCUMULATOR 5
12537  054420  012700  055060          MOV     #HA5W,R0
12538  054424  172410                  LDD     (R0),AC0
12539  054426  174005                  STD     AC0,AC5
12540
12541  054430  004737  054664  H4:     JSR     PC,@#HSTD               ;GO READ ALL ACCUMULATORS BACK.
12542
12543  054434  004737  054742          JSR     PC,@#HCMP               ;SEE IF DATA IS CORRECT.
12544
12545                          ;COMPLIMENT EACH WORD OF THE DATA STORED IN ACCUMULATOR 1,
12546                          ;RELOAD THAT ACCUMULATOR, READ ALL THE ACCUMULATORS BACK AND CHECK
12547                          ;THE DATA.
12548  054440  012700  055020          MOV     #HA1W,R0
12549  054444  012702  000004          MOV     #4,R2
12550  054450  010001                  MOV     R0,R1
12551  054452  005121          H5:     COM     (R1)+
12552  054454  172410                  LDD     (R0),AC0
12553  054456  174001                  STD     AC0,AC1
12554  054460  004737  054664          JSR     PC,@#HSTD               ;READ ALL THE ACCUMULATORS BACK.
12555  054464  004737  054742          JSR     PC,@#HCMP               ;CHECK THE DATA.
12556  054470  077210                  SOB     R2,H5
12557
12558                          ;COMPLIMENT EACH WORD OF THE DATA STORED IN ACCUMULATOR 2,
12559                          ;RELOAD THAT ACCUMULATOR, READ ALL THE ACCUMULATORS BACK AND CHECK
12560                          ;THE DATA.
12561  054472  012700  055030          MOV     #HA2W,R0
12562  054476  012702  000004          MOV     #4,R2
12563  054502  010001                  MOV     R0,R1
12564  054504  005121          H6:     COM     (R1)+
12565  054506  172410                  LDD     (R0),AC0
12566  054510  174002                  STD     AC0,AC2
12567  054512  004737  054664          JSR     PC,@#HSTD               ;READ ALL THE ACCUMULATORS BACK.
12568  054516  004737  054742          JSR     PC,@#HCMP               ;CHECK THE DATA.
12569  054522  077210                  SOB     R2,H6
12570
12571                          ;COMPLIMENT EACH WORD OF THE DATA STORED IN ACCUMULATOR 3,
12572                          ;RELOAD THAT ACCUMULATOR, READ ALL THE ACCUMULATORS BACK AND CHECK
12573                          ;THE DATA.
12574  054524  012700  055040          MOV     #HA3W,R0
12575  054530  012702  000004          MOV     #4,R2
12576  054534  010001                  MOV     R0,R1
12577  054536  005121          H7:     COM     (R1)+
12578  054540  172410                  LDD     (R0),AC0
12579  054542  174003                  STD     AC0,AC3
12580  054544  004737  054664          JSR     PC,@#HSTD               ;READ ALL THE ACCUMULATORS BACK.
12581  054550  004737  054742          JSR     PC,@#HCMP               ;CHECK THE DATA.
12582  054554  077210                  SOB     R2,H7
12583
12584                          ;COMPLIMENT EACH WORD OF THE DATA STORED IN ACCUMULATOR 4,
12585                          ;RELOAD THAT ACCUMULATOR, READ ALL THE ACCUMULATORS BACK AND CHECK
12586                          ;THE DATA.
12587  054556  012700  055050          MOV     #HA4W,R0
12588  054562  012702  000004          MOV     #4,R2
12589  054566  010001                  MOV     R0,R1
```

```
12590  054570  005121                  H10:    COM     (R1)+
12591  054572  172410                          LDD     (R0),AC0
12592  054574  174004                          STD     AC0,AC4
12593  054576  004737  054664                  JSR     PC,@#HSTD               ;READ ALL THE ACCUMULATORS BACK.
12594  054602  004737  054742                  JSR     PC,@#HCMP               ;CHECK THE DATA.
12595  054606  077210                          SOB     R2,H10
12596
12597                                  ;COMPLIMENT EACH WORD OF THE DATA STORED IN ACCUMULATOR 5,
12598                                  ;RELOAD THAT ACCUMULATOR, READ ALL THE ACCUMULATORS BACK AND CHECK
12599                                  ;THE DATA.
12600  054610  012700  055060                  MOV     #HA5W,R0
12601  054614  012702  000004                  MOV     #4,R2
12602  054620  010001                          MOV     R0,R1
12603  054622  005121                  H11:    COM     (R1)+
12604  054624  172410                          LDD     (R0),AC0
12605  054626  174005                          STD     AC0,AC5
12606  054630  004737  054664                  JSR     PC,@#HSTD               ;READ ALL THE ACCUMULATORS BACK.
12607  054634  004737  054742                  JSR     PC,@#HCMP               ;CHECK THE DATA.
12608  054640  077210                          SOB     R2,H11
12609
12610
12611  054642  005737  055016                  TST     @#HFLAG
12612  054646  001402                          BEQ     H12
12613  054650  000137  055210                  JMP     @#HDONE
12614
12615  054654  005137  055016          H12:    COM     @#HFLAG
12616  054660  000137  054356                  JMP     @#H3
12617
12618                                  ;STORE ALL ACCUMULATORS IN THE OUTPUT BUFFERS.
12619  054664  004737  054776          HSTD:   JSR     PC,@#HCLR               ;CLEAR ALL OUTPUT BUFFERS.
12620                                  ;STORE ACCUMULATOR 1
12621  054670  012704  055070                  MOV     #HA1R,R4
12622  054674  172401                          LDD     AC1,AC0
12623  054676  174014                          STD     AC0,(R4)
12624                                  ;STORE ACCUMULATOR 2
12625  054700  012704  055100                  MOV     #HA2R,R4
12626  054704  172402                          LDD     AC2,AC0
12627  054706  174014                          STD     AC0,(R4)
12628                                  ;STORE ACCUMULATOR 3
12629  054710  012704  055110                  MOV     #HA3R,R4
12630  054714  172403                          LDD     AC3,AC0
12631  054716  174014                          STD     AC0,(R4)
12632                                  ;STORE ACCUMULATOR 4
12633  054720  012704  055120                  MOV     #HA4R,R4
12634  054724  172404                          LDD     AC4,AC0
12635  054726  174014                          STD     AC0,(R4)
12636                                  ;STORE ACCUMULATOR 5
12637  054730  012704  055130                  MOV     #HA5R,R4
12638  054734  172405                          LDD     AC5,AC0
12639  054736  174014                          STD     AC0,(R4)
12640  054740  000207                          RTS     PC
12641
12642                                  ;COMPARE DATA LOADED WITH DATA READ.
12643  054742  012637  055014          HCMP:   MOV     (SP)+,@#HADR            ;SAVE RETURN ADDRESS.
12644  054746  012703  055020                  MOV     #HA1W,R3
12645  054752  012704  055070                  MOV     #HA1R,R4
```

```
12646  054756  012705  000024          MOV     #24,R5
12647  054762  022324          HCMP1:  CMP     (R3)+,(R4)+
12648  054764  001401                  BEQ     HCMP2
12649  054766  104000                  EMT                     ;
12650  054770  077504          HCMP2:  SOB     R5,HCMP1
12651  054772  000177  000016          JMP     @HADR
12652
12653                          ;CLEAR THE DATA OUTPUT BUFFER.
12654  054776  012704  055070  HCLR:   MOV     #HA1R,R4
12655  055002  012705  000024          MOV     #24,R5
12656  055006  005024          HCLR1:  CLR     (R4)+
12657  055010  077502                  SOB     R5,HCLR1
12658  055012  000207                  RTS     PC
12659
12660  055014  000000          HADR:   0
12661  055016  000000          HFLAG:  0
12662
12663  055020  000000  000000  000000  HA1W:   .WORD   0,0,0,0
12664  055026  000000
12665  055030  000000  000000  000000  HA2W:   .WORD   0,0,0,0
12666  055036  000000
12667  055040  000000  000000  000000  HA3W:   .WORD   0,0,0,0
12668  055046  000000
12669  055050  000000  000000  000000  HA4W:   .WORD   0,0,0,0
12670  055056  000000
12671  055060  000000  000000  000000  HA5W:   .WORD   0,0,0,0
12672  055066  000000
12673
12674  055070  000000  000000  000000  HA1R:   .WORD   0,0,0,0
12675  055076  000000
12676  055100  000000  000000  000000  HA2R:   .WORD   0,0,0,0
12677  055106  000000
12678  055110  000000  000000  000000  HA3R:   .WORD   0,0,0,0
12679  055116  000000
12680  055120  000000  000000  000000  HA4R:   .WORD   0,0,0,0
12681  055126  000000
12682  055130  000000  000000  000000  HA5R:   .WORD   0,0,0,0
12683  055136  000000
12684
12685  055140  073567  073567  073567  HDAT1:  .WORD   73567,73567,73567,73567
12686  055146  073567
12687  055150  063146  063146  063146  HDAT2:  .WORD   63146,63146,63146,63146
12688  055156  063146
12689  055160  010421  010421  010421  HDAT3:  .WORD   10421,10421,10421,10421
12690  055166  010421
12691  055170  031463  031463  031463  HDAT4:  .WORD   31463,31463,31463,31463
12692  055176  031463
12693  055200  042104  042104  042104  HDAT5:  .WORD   42104,42104,42104,42104
12694  055206  042104
12695
12696  055210                  HDONE:
12697  055210  004767  043260          JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
12698                                                          ;SEE IF THE USER HAS EXPRESSED
12699                                                          ;THE DESIRE TO CHANGE THE SOFTWARE
12700                                                          ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
12701                                                          ;THE USER TYPED CONTROL G?).
```

```
12702
12703
12704                                   ;*****************************************************************************************
12705                                   ;TEST 432       FSRC MODE 0 WITH ILLEGAL ACCUMULATOR TEST
12706                                   ;*****************************************************************************************
12707  055214                          TS432:
12708  055214  170011                         SETD                            ;SET FD
12709  055216  012700  055476                 MOV     #SPAT10,R0              ;LOAD AC0
12710  055222  172410                         LDD     (R0),AC0
12711
12712  055224  012737  055402  000244         MOV     #SERR0,@#FPVECT         ;USE OF THE NON-EXISTENT AC-
12713                                                                          ;CUMULATOR SHOULD RESULT IN
12714                                                                          ;A TRAP TO 244.
12715  055232  012700  000001                 MOV     #1,R0                   ;A FAILURE IN THE FSRC FLOWS
12716                                                                          ;WILL RESULT IN AN ODD ADDRESS
12717  055236  012737  055310  000004         MOV     #SERR1,@#ERRVECT        ;TRAP TO 4.
12718  055244  005003                         CLR     R3
12719
12720  055246  172407                 SX2:    LDD     AC7,AC0
12721  055250  170000                 SX3:    CFCC
12722  055252  005203                         INC     R3
12723  055254  005203                 SX4:    INC     R3
12724
12725  055256  012701  055506                 MOV     #SDAT00,R1              ;NO TRAP OCCURRED!!
12726  055262  174011                         STD     AC0,(R1)                ;SEE IF AC0 WAS MODIFIED.
12727
12728  055264  012701  055506                 MOV     #SDAT00,R1
12729  055270  012702  055476                 MOV     #SPAT10,R2
12730  055274  012703  000004                 MOV     #4,R3
12731  055300  022122                 SX5:    CMP     (R1)+,(R2)+
12732  055302  001401                         BEQ     SX6
12733  055304  104000                         EMT                             ;
12734  055306  077304                 SX6:    SOB     R3,SX5
12735  055310                          SERR1:
12736  055310  104000                         EMT                             ;
12737
12738                                   ;NOW TEST AC6.
12739  055312  170011                 SX7:    SETD
12740  055314  012700  055476                 MOV     #SPAT10,R0              ;LOAD AC0
12741  055320  172410                         LDD     (R0),AC0
12742  055322  012737  055452  000244         MOV     #SERR4,@#FPVECT
12743  055330  012700  000001                 MOV     #1,R0
12744  055334  005003                         CLR     R3
12745
12746  055336  172406                 SX8:    LDD     AC6,AC0
12747  055340  170000                 SX9:    CFCC
12748  055342  005203                         INC     R3
12749  055344  005203                 SX10:   INC     R3
12750
12751  055346  012701  055506                 MOV     #SDAT00,R1
12752  055352  174011                         STD     AC0,(R1)                ;NO TRAP! GET AC0.
12753
12754  055354  012701  055506                 MOV     #SDAT00,R1              ;WAS AC0 MODIFIED.
12755  055360  012702  055476                 MOV     #SPAT10,R2
12756  055364  012703  000004                 MOV     #4,R3
12757  055370  022122                 SX11:   CMP     (R1)+,(R2)+
```

```
12758  055372  001401                    BEQ     SX12
12759  055374  104000                    EMT                             ;
12760  055376  077304            SX12:   SOB     R3,SX11
12761  055400  104000                    EMT                             ;
12762
12763                            ;TRAPPED TO 244.
12764  055402  021627  055250    SERR0:  CMP     (SP),#SX3               ;PC OF TRAP CORRECT?
12765  055406  001401                    BEQ     1$
12766  055410  104000                    EMT                             ;
12767  055412  012737  055312  055472  1$:     MOV     #SX7,@#SADR
12768  055420  022626            SERR10: CMP     (SP)+,(SP)+
12769  055422  005004                    CLR     R4
12770  055424  170204                    STFPS   R4                      ;IS FPS CORRECT?
12771  055426  022704  100200            CMP     #100200,R4
12772  055432  001326                    BNE     SERR1
12773
12774  055434  005004                    CLR     R4
12775  055436  170304                    STST    R4                      ;IS FEC CORRECT?
12776  055440  022704  000002            CMP     #2,R4
12777  055444  001321                    BNE     SERR1
12778  055446  000177  000020            JMP     @SADR
12779
12780  055452  021627  055340    SERR4:  CMP     (SP),#SX9
12781  055456  001401                    BEQ     1$
12782  055460  104000                    EMT                             ;
12783  055462  012737  055516  055472  1$:     MOV     #SDONE,@#SADR
12784  055470  000753                    BR      SERR10
12785
12786  055472  000000            SADR:   0
12787  055474  177777                    -1
12788  055476  010421            SPAT10: 10421
12789  055500  021042            SPAT11: 21042
12790  055502  031463            SPAT12: 31463
12791  055504  042104            SPAT13: 42104
12792
12793  055506  000000            SDAT00: 0
12794  055510  000000            SDAT01: 0
12795  055512  000000            SDAT02: 0
12796  055514  000000            SDAT03: 0
12797
12798  055516                    SDONE:
12799  055516  004767  042752            JSR     PC,.RSET                ;GO INITIALIZE THE FPS AND STACK; AND
12800                                                                    ;SEE IF THE USER HAS EXPRESSED
12801                                                                    ;THE DESIRE TO CHANGE THE SOFTWARE
12802                                                                    ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
12803                                                                    ;THE USER TYPED CONTROL G?).
12804
12805                            ;*******************************************************************************
12806                            ;TEST 433       FSRC MODE 2 TEST
12807                            ;*******************************************************************************
12808  055522                    TS433:
12809  055522                    J1:
12810  055522  170011                    SETD                            ;SET DOUBLE MODE
12811
12812  055524  012700  055652            MOV     #JDAT0,R0
12813  055530  172410                    LDD     (R0),AC0                ;LOAD AC0=ALL 1
```

```
12814
12815  055532  012700  055632          MOV     #JDATIO,R0
12816  055536  005003                  CLR     R3
12817
12818  055540  172420          J2:     LDD     (R0)+,AC0       ;TEST INSTRUCTION
12819  055542  005203          J3:     INC     R3
12820  055544  005203          J4:     INC     R3
12821
12822  055546  012701  055642          MOV     #JDATOO,R1
12823  055552  174011                  STD     AC0,(R1)        ;PICK UP RESULTS
12824
12825  055554  020027  055622          CMP     R0,#JBUF0       ;WAS AN AUTO
12826  055560  001001                  BNE     1$
12827  055562  104000                  EMT                     ;
12828  055564  012702  055632  1$:     MOV     #JDATIO,R2      ;IS DATA CORRECT?
12829  055570  012703  055642          MOV     #JDATOO,R3
12830  055574  012704  000004          MOV     #4,R4
12831  055600  022223          J5:     CMP     (R2)+,(R3)+
12832  055602  001401                  BEQ     J6
12833  055604  104000                  EMT                     ;
12834  055606  077404          J6:     SOB     R4,J5
12835
12836  055610  022700  055642          CMP     #JDATIO+10,R0   ;WAS R0 INCREM.
12837  055614  001401                  BEQ     J7
12838  055616  104000                  EMT                     ;
12839  055620  000420          J7:     BR      JDONE
12840
12841  055622  010421          JBUF0:  .WORD   010421
12842  055624  021042          JBUF1:          021042
12843  055626  042104          JBUF2:          042104
12844  055630  031463          JBUF3:          031463
12845
12846  055632  052525          JDATIO:         052525
12847  055634  114631          JDATI1:         114631
12848  055636  063146          JDATI2:         063146
12849  055640  073567          JDATI3:         073567
12850
12851  055642  000000          JDATOO:         0
12852  055644  000000          JDATO1:         0
12853  055646  000000          JDATO2:         0
12854  055650  000000          JDATO3:         0
12855
12856  055652  177777          JDATO:          -1
12857  055654  177777          JDAT1:          -1
12858  055656  177777          JDAT2:          -1
12859  055660  177777          JDAT3:          -1
12860
12861
12862  055662                  JDONE:
12863  055662  004767  042606          JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
12864                                                          ;SEE IF THE USER HAS EXPRESSED
12865                                                          ;THE DESIRE TO CHANGE THE SOFTWARE
12866                                                          ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
12867                                                          ;THE USER TYPED CONTROL G?).
12868
12869
```

```
12870
12871                   ;*****************************************************************************
12872                   ;TEST 434       FSRC MODE 4 TEST
12873  055666           ;*****************************************************************************
12874  055666  170011   TS434:  SETD                            ;SET DOUBLE MODE
12875
12876  055670  012700  056016         MOV     #KPAT0,R0
12877  055674  172410         LDD     (R0),AC0                ;LOAD A DEFAULT
12878                                                          ;PATTERN INTO AC0
12879  055676  012700  055776         MOV     #KBUF0,R0
12880  055702  005003         CLR     R3
12881  055704  172440  KX2:   LDD     -(R0),AC0               ;TEST INSTRUCTION
12882  055706  005203  KX3:   INC     R3
12883  055710  005203  KX4:   INC     R3
12884
12885  055712  012701  056006         MOV     #KDAT00,R1
12886  055716  174011         STD     AC0,(R1)                ;PICK UP THE RESULT
12887
12888  055720  020027  056006         CMP     R0,#KBUF0+10    ;WAS AN AUTO
12889  055724  001001         BNE     1$
12890  055726  104000         EMT                             ;
12891  055730  012702  055766  1$:    MOV     #KDATI0,R2      ;IS DATA CORRECT?
12892  055734  012703  056006         MOV     #KDAT00,R3
12893  055740  012704  000004         MOV     #4,R4
12894  055744  022223  KX5:    CMP     (R2)+,(R3)+
12895  055746  001401         BEQ     KX6
12896  055750  104000         EMT                             ;
12897  055752  077404  KX6:    SOB     R4,KX5
12898
12899  055754  022700  055766         CMP     #KBUF0-10,R0    ;WAS R0 DECREMENTED
12900  055760  001401         BEQ     KX7
12901  055762  104000         EMT                             ;
12902  055764  000420  KX7:    BR      KDONE
12903
12904  055766  052525  KDATI0: .WORD   052525
12905  055770  114631  KDATI1:        114631
12906  055772  063140  KDATI2:        063140
12907  055774  073567  KDATI3:        073567
12908
12909  055776  010421  KBUF0:         010421
12910  056000  031463  KBUF1:         031463
12911  056002  042104  KBUF2:         042104
12912  056004  021042  KBUF3:         021042
12913
12914  056006  000000  KDAT00:        0
12915  056010  000000  KDAT01:        0
12916  056012  000000  KDAT02:        0
12917  056014  000000  KDAT03:        0
12918
12919  056016  177777  KPAT0:         -1
12920  056020  177777  KPAT1:         -1
12921  056022  177777  KPAT2:         -1
12922  056024  177777  DPAT3:         -1
12923
12924  056026  KDONE:
12925  056026  004767  042442         JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
```

```
12926                                                   ;SEE IF THE USER HAS EXPRESSED
12927                                                   ;THE DESIRE TO CHANGE THE SOFTWARE
12928                                                   ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
12929                                                   ;THE USER TYPED CONTROL G?).
12930
12931
12932                                   ;*****************************************************************************************
12933                                   ;TEST 435       FSRC MODE 2, WITH FD=0, TEST
12934                                   ;*****************************************************************************************
12935  056032                           TS435:
12936  056032                           L1:
12937  056032  170011                          SETD                            ;SET DOUBLE MODE
12938
12939  056034  012700  056160                  MOV     #LPAT10,R0
12940  056040  172410                          LDD     (R0),AC0                ;LOAD AC0
12941
12942  056042  012700  056202                  MOV     #LDAT10,R0              ;SET UP THE INPUT
12943  056046  012701  056170                  MOV     #LPAT20,R1              ;DATA
12944  056052  012702  000004                  MOV     #4,R2
12945
12946  056056  012120                  1$:     MOV     (R1)+,(R0)+
12947  056060  077202                          SOB     R2,1$
12948
12949  056062  012700  056202                  MOV     #LDAT10,R0
12950  056066  005003                          CLR     R3
12951  056070  170001                          SETF                            ;CLEAR FD.
12952
12953  056072  172420                  L2:     LDF     (R0)+,AC0
12954  056074  005203                  L3:     INC     R3
12955
12956  056076                          L4:
12957  056076  170011                          SETD                            ;SET FD
12958
12959  056100  012701  056214                  MOV     #LDAT00,R1
12960  056104  174011                          STD     AC0,(R1)                ;PICK UP RESULTS
12961
12962  056106  020027  056206                  CMP     R0,#LDAT12              ;WAS R0 INCREMENTED
12963  056112  001401                          BEQ     1$
12964  056114  104000                          EMT                             ;
12965  056116  012737  177777  056206  1$:     MOV     #-1,@#LDAT12
12966  056124  012737  177777  056210          MOV     #-1,@#LDAT13
12967  056132  012702  056202                  MOV     #LDAT10,R2              ;IS DATA CORRECT
12968  056136  012703  056214                  MOV     #LDAT00,R3
12969  056142  012704  000004                  MOV     #4,R4
12970
12971  056146  022223                  L5:     CMP     (R2)+,(R3)+
12972  056150  001401                          BEQ     L6
12973  056152  104000                          EMT                             ;
12974  056154  077404                  L6:     SOB     R4,L5
12975  056156  000422                          BR      LDONE
12976
12977  056160  177777                  LPAT10: .WORD   -1
12978  056162  177777                  LPAT11:         -1
12979  056164  177777                  LPAT12:         -1
12980  056166  177777                  LPAT13:         -1
12981
```

```
12982  056170  052525                  LPAT20:         052525
12983  056172  114631                  LPAT21:         114631
12984  056174  063142                  LPAT22:         063142
12985  056176  073567                  LPAT23:         073567
12986  056200  000001                          .WORD   000001
12987  056202  000000                  LDATI0:         0
12988  056204  000000                  LDATI1:         0
12989  056206  000000                  LDATI2:         0
12990  056210  000000                  LDATI3:         0
12991  056212  000001                          .WORD   00001
12992  056214  000000                  LDATO0:         0
12993  056216  000000                  LDATO1:         0
12994  056220  000000                  LDATO2:         0
12995  056222  000000                  LDATO3:         0
12996
12997  056224                          LDONE:
12998  056224  004767  042244                JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
13000                                                                  ;SEE IF THE USER HAS EXPRESSED
13001                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
13002                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
13003                                                                  ;THE USER TYPED CONTROL G?).
13004
13005                                   ;*************************************************************************************
13006                                   ;TEST 436       FSRC MODE 2 WITH GR7, IMMEDIATE MODE, TEST
13007                                   ;*************************************************************************************
13008  056230                          TS436:
13009
13010  056230                          M1:
13011  056230  170011                          SETD
13012
13013  056232  012700  056332                  MOV     #MPAT10,R0
13014  056236  172410                          LDD     (R0),AC0        ;LOAD BACKROUND
13015                                                                  ;PATTERN INTO AC0.
13016  056240  005004                          CLR     R4
13017  056242  012737  056270  000004          MOV     #MERR3,@#ERRVECT
13018
13019  056250  172427  000000          M15:    LDD     #0,AC0          ;TEST INSTRUCTION
13020          056252                          .=.-2                   ;EFFECTIVELY: 05204 IS PUT IN THE FIRST
13021  056252  005204                          .WORD   5204    ;16 BIT WORD, OR THE "EXP-FRACTION" WORD.
13022  056254  005204                  M2:     INC     R4              ;NOTE THAT
13023  056256  005204                  M3:     INC     R4              ;005204=INC R4
13024  056260  005204                  M4:     INC     R4
13025  056262  020427  000003                  CMP     R4,#3           ;SEE IF THE PC
13026  056266  001401                          BEQ     M8
13027  056270                          MERR3:
13028  056270  104000                          EMT                     ;
13029  056272  012700  056352          M8:     MOV     #MDATO0,R0
13030  056276  174010                          STD     AC0,(R0)        ;GET THE DATA
13031
13032  056300  012700  056352                  MOV     #MDATO0,R0
13033  056304  022720  005204                  CMP     #5204,(R0)+     ;IS THE DATA CORRECT?
13034  056310  001401                          BEQ     M5
13035  056312  104000                          EMT                     ;
13036  056314  012701  000003          M5:     MOV     #3,R1
13037  056320  005720                  M6:     TST     (R0)+
```

```
13038  056322  001401                        BEQ     M7
13039  056324  104000                        EMT                             ;
13040  056326  077104                M7:     SOB     R1,M6
13041  056330  000414                        BR      MDONE
13042
13043  056332  177777                MPAT10: -1
13044  056334  177777                MPAT11: -1
13045  056336  177777                MPAT12: -1
13046  056340  177777                MPAT13: -1
13047
13048  056342  005204                MPAT20: 5204
13049  056344  005204                MPAT21: 5204
13050  056346  005204                MPAT22: 5204
13051  056350  005204                MPAT23: 5204
13052
13053  056352  000000                MDAT00: 0
13054  056354  000000                MDAT01: 0
13055  056356  000000                MDAT02: 0
13056  056360  000000                MDAT03: 0
13057
13058  056362                        MDONE:
13059  056362  004767  042106                JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
13060                                                                ;SEE IF THE USER HAS EXPRESSED
13061                                                                ;THE DESIRE TO CHANGE THE SOFTWARE
13062                                                                ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
13063                                                                ;THE USER TYPED CONTROL G?).
13064
13065
13066                                ;*****************************************************************************************
13067                                ;TEST 437       FSRC MODE 3 TEST
13068                                ;*****************************************************************************************
13069  056366                        TS437:
13070
13071  056366                        N1:
13072  056366  170011                        SETD                    ;SET FD MODE
13073
13074  056370  012700  056516                MOV     #NPAT10,R0
13075  056374  172410                        LDD     (R0),AC0        ;LOAD AC0 WITH A DEFAULT
13076                                                                ;PATTERN
13077  056376  012700  056504                MOV     #NPAT20,R0
13078  056402  005003                        CLR     R3
13079  056404  012737  056456  000004        MOV     #NERR0,@#ERRVECT        ;IF A FAILURE OCCURS
13080                                                                ;IN THE FSRC FLOWS AN
13081                                                                ;ODD TRAP TO 4 COULD OCCUR
13082  056412  172430                N2:     LDD     @(R0)+,AC0      ;TEST INSTRUCTION.
13083  056414  005203                N3:     INC     R3
13084  056416  005203                N4:     INC     R3
13085
13086  056420  012701  056464                MOV     #NDAT00,R1
13087  056424  174011                        STD     AC0,(R1)        ;GET THE DATA
13088
13089  056426  020027  056506                CMP     R0,#NPAT20+2    ;WAS R0 INCREMENTED
13090  056432  001401                        BEQ     N12
13091  056434  104000                        EMT                     ;
13092  056436  012702  056464        N12:    MOV     #NDAT00,R2      ;DATA CORRECT
13093  056442  012703  056526                MOV     #NDAT10,R3
```

```
13094  056446  012704  000004          MOV     #4,R4
13095  056452  022223                  N13:    CMP     (R2)+,(R3)+
13096  056454  001401                          BEQ     N14
13097  056456                          NERR0:
13098  056456  104000                          EMT                     ;
13099  056460  077404                  N14:    SOB     R4,N13
13100  056462  000425                          BR      NDONE
13101
13102  056464  000000                  NDAT00: .WORD   0
13103  056466  000000                  NDAT01:         0
13104  056470  000000                  NDAT02:         0
13105  056472  000000                  NDAT03:         0
13106
13107  056474  052525  052525  052525          .WORD   52525,52525,52525,52525
13108  056502  052525
13109  056504  056526                  NPAT20: .WORD   NDAT10
13110  056506  070707                  NPAT21:         070707
13111  056510  070707                  NPAT22:         070707
13112  056512  070707                  NPAT23:         070707
13113  056514  000001                          .WORD   1
13114  056516  177777                  NPAT10: .WORD   -1
13115  056520  177777                  NPAT11:         -1
13116  056522  177777                  NPAT12:         -1
13117  056524  177777                  NPAT13:         -1
13118
13119  056526  010421                  NDAT10: .WORD   010421
13120  056530  021042                  NDAT11:         021042
13121  056532  031463                  NDAT12:         031463
13122  056534  042104                  NDAT13:         042104
13123
13124  056536                          NDONE:
13125  056536  004767  041732                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
13126                                                                  ;SEE IF THE USER HAS EXPRESSED
13127                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
13128                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
13129                                                                  ;THE USER TYPED CONTROL G?).
13130
13131
13132                                   ;*****************************************************************************
13133                                   ;TEST 440       FSRC MODE 5 TEST
13134                                   ;*****************************************************************************
13135  056542                          TS440:
13136
13137  056542                          01:
13138  056542  170011                          SETD                    ;SET FD MODE
13139
13140  056544  012700  056672                  MOV     #OPAT10,R0
13141  056550  172410                          LDD     (R0),AC0        ;LOAD AC0 WITH A
13142                                                                  ;DEFAULT PATTERN.
13143  056552  012700  056660                  MOV     #OPAT21,R0
13144  056556  005003                          CLR     R3
13145  056560  012737  056610  000004          MOV     #OERR0,@#ERRVEC ;IF A FAILURE
13146                                                                  ;OCCURS IN THE FSRC
13147                                                                  ;FLOWS AN ODD ADDR.
13148                                                                  ;TRAP TO 4 MAY OCCUR.
13149  056566  172450                  02:     LDD     @-(R0),AC0      ;TEST INSTRUCTION
```

```
13150  056570  005203                  03:     INC     R3
13151  056572  005203                  04:     INC     R3
13152
13153  056574  012701  056640                  MOV     #ODAT00,R1
13154  056600  174011                          STD     AC0,(R1)        ;GET THE DATA
13155
13156  056602  020027  056656                  CMP     R0,#OPAT20      ;WAS R0 DECREMENTED
13157  056606  001401                          BEQ     012
13158  056610                          OERR0:
13159  056610  104000                          EMT                     ;
13160  056612  012702  056640          012:    MOV     #ODAT00,R2      ;DATA CORRECT?
13161  056616  012703  056702                  MOV     #ODATI0,R3
13162  056622  012704  000004                  MOV     #4,R4
13163  056626  022223                  013:    CMP     (R2)+,(R3)+
13164  056630  001401                          BEQ     014
13165  056632  104000                          EMT                     ;
13166  056634  077404                  014:    SOB     R4,013
13167  056636  000425                          BR      ODONE
13168
13169  056640  000000                  ODAT00: .WORD   0
13170  056642  000000                  ODAT01:         0
13171  056644  000000                  ODAT02:         0
13172  056646  000000                  ODAT03:         0
13173
13174  056650  052525  052525  052525          .WORD   52525,52525,52525
13175  056656  056702                  OPAT20: .WORD   ODATI0
13176  056660  070707                  OPAT21: 070707
13177  056662  070707                  OPAT22: 070707
13178  056664  070707                  OPAT23: 070707
13179  056666  070707                  OPAT24: 070707
13180  056670  000001                          .WORD   1
13181  056672  177777                  OPAT10: .WORD   -1
13182  056674  177777                  OPAT11:         -1
13183  056676  177777                  OPAT12:         -1
13184  056700  177777                  OPAT13:         -1
13185
13186  056702  073567                  ODATI0: .WORD   73567
13187  056704  004210                  ODATI1:         004210
13188  056706  114631                  ODATI2:         114631
13189  056710  125252                  ODATI3:         125252
13190
13191  056712                          ODONE:
13192  056712  004767  041556                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
13193                                                                  ;SEE IF THE USER HAS EXPRESSED
13194                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
13195                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
13196                                                                  ;THE USER TYPED CONTROL G?).
13197
13198
13199                           ;*****************************************************************************
13200                           ;TEST 441       FSRC MODE 6 TEST
13201                           ;*****************************************************************************
13202  056716                  TS441:
13203
13204  056716                  P1:
13205  056716  170011                  SETD                    ;SET FD MODE
```

```
13206
13207  056720  012700  057004          MOV     #PPAT10,R0
13208  056724  172410                  LDD     (R0),AC0        ;LOAD A DEFAULT PATTERN
                                                                ;INTO AC0
13209
13210  056726  012700  056553          MOV     #PDAT10-241,R0  ;COULD OCCUR.
13211
13212  056732  172460  000241  P2:     LDD     241(R0),AC0
13213          056734          P3=P2+2
13214
13215  056736  012701  057024  P4:     MOV     #PDAT00,R1
13216  056742  174011                  STD     AC0,(R1)        ;GET THE DATA
13217  056744  012703  000004          MOV     #4,R3
13218  056750  012702  057014          MOV     #PDAT10,R2
13219  056754  012701  057024          MOV     #PDAT00,R1
13220  056760  022221          P5:     CMP     (R2)+,(R1)+     ;CHECK THE DATA
13221  056762  001401                  BEQ     2$
13222  056764  104000                  EMT                     ;
13223  056766  077304          2$:     SOB     R3,P5
13224  056770  022700  056553          CMP     #PDAT10-241,R0  ;R0 CORRECT?
13225  056774  001401                  BEQ     1$
13226  056776  104000                  EMT                     ;
13227  057000  000137  057034  1$:     JMP     @#PDONE
13228  057004  177777          PPAT10: .WORD   -1
13229  057006  177777          PPAT11:         -1
13230  057010  177777          PPAT12:         -1
13231  057012  177777          PPAT13:         -1
13232
13233  057014  010421          PDAT10: .WORD   010421
13234  057016  031463          PDAT11:         031463
13235  057020  052525          PDAT12:         052525
13236  057022  073567          PDAT13:         073567
13237
13238  057024  000000          PDAT00: .WORD   0
13239  057026  000000          PDAT01:         0
13240  057030  000000          PDAT02:         0
13241  057032  000000          PDAT03:         0
13242
13243  057034                  PDONE:
13244  057034  004767  041434          JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
13245                                                          ;SEE IF THE USER HAS EXPRESSED
13246                                                          ;THE DESIRE TO CHANGE THE SOFTWARE
13247                                                          ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
13248                                                          ;THE USER TYPED CONTROL G?).
13249
13250
13251                          ;*********************************************************************************************
13252                          ;TEST 442       FSRC MODE 7 TEST
13253                          ;*********************************************************************************************
13254  057040                  TS442:
13255
13256  057040                  Q1:
13257  057040  170011                  SETD
13258
13259  057042  012700  057126          MOV     #QPAT10,R0
13260  057046  172410                  LDD     (R0),AC0        ;LOAD A DEFAULT
                                                                ;PATTERN INTO AC0
13261
```

```
13262  057050  012700  056675          MOV     #QPAT20-241,R0
13263
13264  057054  172470  000241  Q2:     LDD     @241(R0),AC0
13265          057056          Q3=Q2+2
13266
13267  057060  012701  057146  Q4:     MOV     #QDAT00,R1
13268  057064  174011                  STD     AC0,(R1)        ;GET THE DATA
13269
13270  057066  012703  000004          MOV     #4,R3
13271  057072  012704  057146          MOV     #QDAT00,R4
13272  057076  012705  057156          MOV     #QDAT10,R5
13273  057102  022425          Q5:     CMP     (R4)+,(R5)+     ;CHECK THE DATA
13274  057104  001401                  BEQ     2$
13275  057106  104000                  EMT                     ;
13276  057110  077304          2$:     SOB     R3,Q5
13277
13278  057112  022700  056675          CMP     #QPAT20-241,R0  ;CHECK R0.
13279  057116  001401                  BEQ     1$
13280  057120  104000                  EMT                     ;
13281  057122  000137  057166  1$:     JMP     @#QDONE
13282
13283  057126  177777          QPAT10: .WORD   -1
13284  057130  177777          QPAT11:         -1
13285  057132  177777          QPAT12:         -1
13286  057134  177777          QPAT13:         -1
13287
13288  057136  057156          QPAT20: .WORD   QDAT10
13289  057140  052525          QPAT21:         52525
13290  057142  052525          QPAT22:         52525
13291  057144  052525          QPAT23:         52525
13292
13293  057146  000000          QDAT00: .WORD   0
13294  057150  000000          QDAT01:         0
13295  057152  000000          QDAT02:         0
13296  057154  000000          QDAT03:         0
13297
13298  057156  073567          QDAT10: .WORD   073567
13299  057160  052525          QDAT11: .WORD   052525
13300  057162  031463          QDAT12: .WORD   031463
13301  057164  010421          QDAT13: .WORD   010421
13302
13303  057166                  QDONE:
13304  057166  004767  041302          JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
13305                                                          ;SEE IF THE USER HAS EXPRESSED
13306                                                          ;THE DESIRE TO CHANGE THE SOFTWARE
13307                                                          ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
13308                                                          ;THE USER TYPED CONTROL G?).
13309
13310                          ;*****************************************************************************
13311                          ;TEST 443       (BUT EZBT Y8),(BUT ENBT) AND (BUT FIUV) TEST
13312                          ;*****************************************************************************
13313  057172                  TS443:
13314  057172  005037  057744          CLR     @#UFLAG
13315  057176  012700  057674          MOV     #UPAT00,R0      ;SET UP AC#0 DATA.
13316  057202  012701  000004          MOV     #4,R1
13317  057206  012720  177777  U0:     MOV     #-1,(R0)+
```

```
13318  057212  077103                          SOB     R1,U0
13319
13320  057214  012737  000033  057746          MOV     #033,@#UTMP1
13321  057222  012737  000023  057750          MOV     #023,@#UTMP2
13322  057230  012737  057314  000244  U1:     MOV     #UERR0,@#FPVECT ;IN CASE (BUT FIUV FAILS)
13323  057236  012700  000200                  MOV     #200,R0
13324  057242  170100                          LDFPS   R0
13325  057244  012700  057674                  MOV     #UPAT00,R0      ;LOAD AC0
13326  057250  172410                          LDD     (R0),AC0
13327  057252  013737  057746  057752          MOV     @#UTMP1,@#UROM1
13328  057260  012737  000001  057754          MOV     #001,@#UROM2
13329  057266  012737  000254  057756          MOV     #254,@#UROM3
13330
13331  057274  012700  057704                  MOV     #UPAT10,R0      ;LOAD 0 INTO AC0
13332  057300  172410                  U2:     LDD     (R0),AC0
13333  057302  012704  000204                  MOV     #204,R4         ;SEE IF FPS IS CORRECT
13334  057306  170205                          STFPS   R5
13335
13336  057310  020405                          CMP     R4,R5
13337  057312  001401                          BEQ     U3
13338  057314                          UERR0:
13339  057314  104000                          EMT                     ;
13340  057316  012700  000200          U3:     MOV     #200,R0
13341  057322  170100                          LDFPS   R0
13342
13343  057324  012700  057674                  MOV     #UPAT00,R0      ;LOAD AC0
13344  057330  172410                          LDD     (R0),AC0
13345  057332  013737  057750  057752          MOV     @#UTMP2,@#UROM1
13346  057340  012737  000003  057754          MOV     #003,@#UROM2
13347  057346  012737  000054  057756          MOV     #054,@#UROM3
13349
13349  057354  012700  057714                  MOV     #UPAT20,R0      ;LOAD A POSITIVE NUMBER
13350                                                                  ;INTO AC0
13351  057360  172410                  U4:     LDD     (R0),AC0
13352  057362  012704  000200                  MOV     #200,R4         ;FPS CORRECT?
13353  057366  170205                          STFPS   R5
13354
13355  057370  020405                          CMP     R4,R5
13356  057372  001401                          BEQ     U5
13357  057374  104000                          EMT                     ;
13358  057376  012700  000200          U5:     MOV     #200,R0
13359  057402  170100                          LDFPS   R0
13360  057404  012700  057674                  MOV     #UPAT00,R0      ;LOAD AC0
13361  057410  172410                          LDD     (R0),AC0
13362  057412  013737  057750  057752          MOV     @#UTMP2,@#UROM1
13363  057420  012737  000403  057754          MOV     #403,@#UROM2
13364  057426  012737  000056  057756          MOV     #056,@#UROM3
13365  057434  012700  057724                  MOV     #UPAT30,R0      ;LOAD A NEGATIUE
13366                                                                  ;NUMBER INTO AL0
13367  057440  172410                  U6:     LDD     (R0),AC0
13368  057442  012704  000210                  MOV     #210,R4         ;FPS CORRECT
13369  057446  170205                          STFPS   R5
13370  057450  020405                          CMP     R4,R5
13371  057452  001401                          BEQ     U7
13372  057454  104000                          EMT                     ;
13373  057456  012700  000200          U7:     MOV     #200,R0
```

```
13374  057462  170100                        LDFPS   R0
13375  057464  012700  057674                MOV     #UPAT00,R0      ;LOAD AC0
13376  057470  172410                        LDD     (R0),AC0
13377  057472  013737  057746  057752        MOV     @#UTMP1,@#UROM1
13378  057500  012737  000401  057754        MOV     #401,@#UROM2
13379  057506  012737  000256  057756        MOV     #256,@#UROM3
13380  057514  012700  057734                MOV     #UPAT40,R0      ;LOAD -0 INTO AC0
13381  057520  172410                U10:    LDD     (R0),AC0
13382  057522  000240                U11:    NOP                     ;TRAP FROM HERE IF
13383  057524  012704  000214                MOV     #214,R4         ;SEE IF FPS IS CORRECT.
13384  057530  170205                        STFPS   R5
13385  057532  020405                        CMP     R4,R5
13386  057534  001401                        BEQ     U12
13387  057536  104000                        EMT                     ;
13388  057540  005737  057744        U12:    TST     @#UFLAG ;SEE IF ALL THE PATTERNS
13389  057544  001021                        BNE     U14             ;HAVE BEEN TEST WITH
13390                                                                ;BOTH AC NOT EQUAL TO 0 AND AC=0
13391  057546  012700  057674                MOV     #UPAT00,R0      ;IF NOT GO BACK AND
13392  057552  012701  000004                MOV     #4,R1           ;CHECK THEM WITH AC=0
13393  057556  005020                U13:    CLR     (R0)+
13394  057560  077102                        SOB     R1,U13
13395  057562  012737  177777  057744        MOV     #-1,@#UFLAG
13396  057570  012737  000233  057746        MOV     #233,@#UTMP1
13397  057576  012737  000223  057750        MOV     #223,@#UTMP2
13398  057604  000137  057230                JMP     @#U1
13399                          ;NOW SEE IF A TRAP CAN BE FORCED BY SETTING FIUV AND LOADING -0
13400  057610  012737  057646  000244  U14:  MOV     #UERR3,@#FPVECT
13401  057616  012700  004200                MOV     #4200,R0        ;SET FD AND FIUV
13402  057622  1701C0                        LDFPS   R0
13403  057624  012700  057674                MOV     #UPAT00,R0      ;SET UP AC0
13404  057630  172410                        LDD     (R0),AC0
13405  057632  012700  057734                MOV     #UPAT40,R0      ;LOAD -0
13406  057636  172410                U15:    LDD     (R0),AC0        ;SHOULD TRAP TO 244
13407  057640  170000                U16:    CFCC
13408  057642  000240                        NOP
13409  057644  104000                        EMT                     ;
13410
13411                          ;INTERRUPT HERE WHEN FIUV SET AND ATTEMPTED TO LOAD-0
13412  057646  021627  057640        UERR3:  CMP     (SP),#U16
13413  057652  001401                        BEQ     1$
13414  057654  104000                        EMT                     ;
13415  057656  022626                1$:     CMP     (SP)+,(SP)+
13416  057660  005000                        CLR     R0
13417  057662  170300                        STST    R0              ;GET FEC.
13418  057664  022700  000014                CMP     #14,R0          ;CORRECT
13419  057670  001433                        BEQ     UDONE
13420  057672  104000                        EMT                     ;
13421  057674  000000                UPAT00: .WORD   0
13422  057676  000000                UPAT01:         0
13423  057700  000000                UPAT02:         0
13424  057702  000000                UPAT03:         0
13425
13426  057704  000000                UPAT10: .WORD   0               ;0
13427  057706  000000                UPAT11:         0
13428  057710  000000                UPAT12:         0
13429  057712  000000                UPAT13:         0
```

```
13430
13431  057714  010421          UPAT20: .WORD   010421          ;POS NUM
13432  057716  114631          UPAT21:         114631
13433  057720  125252          UPAT22:         125252
13434  057722  177777          UPAT23:         177777
13435
13436  057724  114631          UPAT30:         114631          ;NEG NUM
13437  057726  135673          UPAT31:         135673
13438  057730  146314          UPAT32:         146314
13439  057732  167356          UPAT33:         167356
13440
13441  057734  100000          UPAT40:         100000          ;NEG ZERO
13442  057736  000000          UPAT41:         0
13443  057740  000000          UPAT42:         0
13444  057742  000000          UPAT43:         0
13445
13446  057744  000000          UFLAG:  .WORD   0
13447  057746  000000          UTMP1:          0
13448  057750  000000          UTMP2:          0
13449  057752  000000          UROM1:          0
13450  057754  000000          UROM2:          0
13451  057756  000000          UROM3:          0
13452  057760                  UDONE:
13453
13454
13455                          ;*****************************************************************************************
13456                          ;TEST 444       ADDF,ADDD,SUBF AND SUBD WITH FSRC=AC=0 TEST
13457                          ;*****************************************************************************************
13458  057760                  TS444:
13459  057760  012700  000200          MOV     #200,R0
13460  057764  170100                  LDFPS   R0              ;SET DOUBLE MODE
13461  057766  012700  060310          MOV     #WPAT00,R0      ;LOAD AC0=:
13462  057772  172410                  LDD     (R0),AC0
13463  057774  012700  060310          MOV     #WPAT00,R0
13464  060000  172010          W2:     ADDD    (R0),AC0        ;TEST INSTRUCTION. ADD ITSELF
13465  060002  170205                  STFPS   R5              ;GET FPS
13466  060004  170011                  SETD                    ;SET DOUBLE MODE
13467  060006  012700  060310          MOV     #WPAT00,R0
13468  060012  174010                  STD     AC0,(R0)        ;GET THE RESULT
13469  060014  012701  060310          MOV     #WPAT00,R1
13470  060020  012702  000004          MOV     #4,R2
13471  060024  022021          W3:     CMP     (R0)+,(R1)+     ;IS RESULT CORRECT
13472  060026  001401                  BEQ     W4
13473  060030  104000                  EMT                     ;
13474  060032  077204          W4:     SOB     R2,W3
13475  060034  022705  000204          CMP     #204,R5         ;IS FPS CORRECT
13476  060040  001401                  BEQ     W5
13477  060042  104000                  EMT                     ;
13478  060044  012700  000200  W5:     MOV     #200,R0
13479  060050  170100                  LDFPS   R0              ;SET DOUBLE MODE
13480  060052  012700  060310          MOV     #WPAT00,R0      ;LOAD AC0=0
13481  060056  172410                  LDD     (R0),AC0
13482  060060  005000                  CLR     R0
13483  060062  170100                  LDFPS   R0              ;GO TO FLOATING MODE
13484  060064  012700  060310          MOV     #WPAT00,R0
13485  060070  172010          W6:     ADDF    (R0),AC0        ;TEST INSTRUCTION
```

```
13486  060072  170205                 STFPS   R5              ;GET FPS
13487  060074  170011                 SETD                    ;RESET TO DOUBLE MODE
13488  060076  012700  060310         MOV     #WPAT00,R0
13489  060102  174010                 STD     AC0,(R0)        ;GET THE RESULT
13490  060104  012701  060310         MOV     #WPAT00,R1
13491  060110  012702  000004         MOV     #4,R2
13492  060114  022021           W7:    CMP     (R0)+,(R1)+     ;WAS THE RESULT
13493  060116  001401                 BEQ     W10
13494  060120  104000                 EMT                     ;
13495  060122  077204           W10:   SOB     R2,W7
13496  060124  022705  000004         CMP     #4,R5           ;WAS FPS CORRECT
13497  060130  001401                 BEQ     W11
13498  060132  104000                 EMT                     ;
13499  060134  012700  000200   W11:   MOV     #200,R0
13500  060140  170100                 LDFPS   R0              ;SET DOUBLE MODE
13501  060142  012700  060310         MOV     #WPAT00,R0      ;LOAD AC0=0
13502  060146  172410                 LDD     (R0),AC0
13503  060150  012700  060310         MOV     #WPAT00,R0
13504  060154  173010           W12:   SUBD    (R0),AC0        ;TEST INSTRUCTION
13505  060156  170205                 STFPS   R5              ;GET FPS
13506  060160  170011                 SETD                    ;SET DOUBLE MODE
13507  060162  012700  060310         MOV     #WPAT00,R0
13508  060166  174010                 STD     AC0,(R0)        ;GET THE RESULT
13509  060170  012701  060310         MOV     #WPAT00,R1
13510  060174  012702  000004         MOV     #4,R2
13511  060200  022021           W13:   CMP     (R0)+,(R1)+     ;IS RESULT CORRECT?
13512  060202  001401                 BEQ     W14
13513  060204  104000                 EMT                     ;
13514  060206  077204           W14:   SOB     R2,W13
13515  060210  022705  000204         CMP     #204,R5         ;IS FPS CORRECT?
13516  060214  001401                 BEQ     W15
13517  060216  104000                 EMT                     ;
13518  060220  012700  000200   W15:   MOV     #200,R0
13519  060224  170100                 LDFPS   R0              ;SET DOUBLE MODE
13520  060226  012700  060310         MOV     #WPAT00,R0      ;LOAD AC0=0
13521  060232  172410                 LDD     (R0),AC0
13522  060234  005000                 CLR     R0
13523  060236  170100                 LDFPS   R0              ;ENTER FLOATING MODE.
13524  060240  012700  060310         MOV     #WPAT00,R0
13525  060244  173010           W16:   SUBF    (R0),AC0        ;TEST INSTRUCTION.
13526  060246  170205                 STFPS   R5              ;GET FPS
13527  060250  170011                 SETD                    ;RESET TO DOUBLE MODE
13528  060252  012700  060310         MOV     #WPAT00,R0      ;GET THE RESULT.
13529  060256  174010                 STD     AC0,(R0)
13530  060260  012701  060310         MOV     #WPAT00,R1
13531  060264  012702  000004         MOV     #4,R2
13532  060270  022021           W17:   CMP     (R0)+,(R1)+     ;IS RESULT CORRECT?
13533  060272  001401                 BEQ     W20
13534  060274  104000                 EMT                     ;
13535  060276  077204           W20:   SOB     R2,W17
13536  060300  022705  000004         CMP     #4,R5           ;IS FPS CORRECT?
13537  060304  001411                 BEQ     WDONE
13538  060306  104000                 EMT                     ;
13539
13540  060310  000000           WPAT00: .WORD  0
13541  060312  000000           WPAT01:        0
```

```
13542  060314  000000                  WPAT02:         0
13543  060316  000000                  WPAT03:         0
13544
13545  060320  000000                  WDAP00: .WORD   0
13546  060322  000000                  WDAT01:         0
13547  060324  000000                  WDAT02:         0
13548  060326  000000                  WDAT03:         0
13549
13550  060330                          WDONE:
13551  060330  004767  040140                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
13552                                                                  ;SEE IF THE USER HAS EXPRESSED
13553                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
13554                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
13555                                                                  ;THE USER TYPED CONTROL G?).
13556
13557
13558                                  ;*****************************************************************************
13559                                  ;TEST 445       ADDD AND SUB WITH FSRC=0
13560                                  ;*****************************************************************************
13561  060334                          TS445:
13562  060334  012700  000200                  MOV     #200,R0
13563  060340  170100                          LDFPS   R0              ;SET DOUBLE MODE
13564  060342  012700  060674                  MOV     #XPAT00,R0      ;SET AC0 TO POSITIVE
13565  060346  172410                          LDD     (R0),AC0
13566  060350  012700  060704                  MOV     #XPAT10,R0      ;FSRC=0
13567  060354  172010                  X2:     ADDD    (R0),AC0        ;TEST INSTRUCTION
13568  060356  170205                          STFPS   R5
13569  060360  170011                          SETD
13570  060362  012700  060664                  MOV     #XDAT00,R0      ;GET RESULT.
13571  060366  174010                          STD     AC0,(R0)
13572  060370  012701  060674                  MOV     #XPAT00,R1
13573  060374  012702  000004                  MOV     #4,R2
13574  060400  022021                  X3:     CMP     (R0)+,(R1)+     ;IS RESULT CORRECT?
13575  060402  001401                          BEQ     X4
13576  060404  104000                          EMT                     ;
13577  060406  077204                  X4:     SOB     R2,X3
13600  060410  012704  000200                  MOV     #200,R4
13601  060414  020405                          CMP     R4,R5           ;IS FPS CORRECT?
13602  060416  001401                          BEQ     X5
13603  060420  104000                          EMT                     ;
13604  060422  012700  000200          X5:     MOV     #200,R0
13605  060426  170100                          LDFPS   R0              ;SET DOUBLE MODE
13606  060430  012700  060714                  MOV     #XPAT20,R0      ;SET AC0 TO
13607  060434  172410                          LDD     (R0),AC0
13610  060436  012700  060704                  MOV     #XPAT10,R0      ;FSRC=0
13611  060442  172010                  X6:     ADDD    (R0),AC0        ;TEST INSTRUCTION
13612  060444  170205                          STFPS   R5
13613  060446  170011                          SETD
13614  060450  012700  060664                  MOV     #XDAT00,R0      ;GET RESULT
13615  060454  174010                          STD     AC0,(R0)
13616  060456  012701  060714                  MOV     #XPAT20,R1
13617  060462  012702  000004                  MOV     #4,R2
13620  060466  022021                  X7:     CMP     (R0)+,(R1)+     ;IS RESULT CORRECT?
13621  060470  001401                          BEQ     X10
13622  060472  104000                          EMT                     ;
13623  060474  077204                  X10:    SOB     R2,X7
```

```
13598  060476  012704  000210          MOV     #210,R4
13599  060502  020405                  CMP     R4,R5           ;IS FPS CORRECT?
13600  060504  001401                  BEQ     X11
13601  060506  104000                  EMT                     ;
13602  060510  012700  000200  X11:    MOV     #200,R0
13603  060514  170100                  LDFPS   R0              ;SET DOUBLE MODE
13604  060516  012700  060674          MOV     #XPAT00,R0      ;SET AC0 TO NON-ZERO
13605  060522  172410                  LDD     (R0),AC0
13606  060524  012700  060704          MOV     #XPAT10,R0      ;FSRC=0
13607  060530  173010          X12:    SUBD    (R0),AC0        ;TEST INSTRUCTION
13608  060532  170205                  STFPS   R5
13609  060534  170011                  SETD
13610  060536  012700  060664          MOV     #XDAT00,R0      ;GET RESULT
13611  060542  174010                  STD     AC0,(R0)
13612  060544  012701  060674          MOV     #XPAT00,R1
13613  060550  012702  000004          MOV     #4,R2
13614  060554  022021          X13:    CMP     (R0)+,(R1)+     ;IS RESULT CORRECT?
13615  060556  001401                  BEQ     X14
13616  060560  104000                  EMT                     ;
13617  060562  077204          X14:    SOB     R2,X13
13618  060564  012704  000200          MOV     #200,R4         ;IS FPS CORRECT?
13619  060570  020405                  CMP     R4,R5
13620  060572  001401                  BEQ     X15
13621  060574  104000                  EMT                     ;
13622  060576  012700  000200  X15:    MOV     #200,R0
13623  060602  170100                  LDFPS   R0              ;SET DOUBLE MODE
13624  060604  012700  060714          MOV     #XPAT20,R0      ;SET AC0=A NEGATIVE
13625  060610  172410                  LDD     (R0),AC0
13626  060612  012700  060704          MOV     #XPAT10,R0      ;FSRC=0
13627  060616  173010          X16:    SUBD    (R0),AC0        ;TEST INSTRUCTION.
13628  060620  170205                  STFPS   R5
13629  060622  170011                  SETD
13630  060624  012700  060664          MOV     #XDAT00,R0      ;GET RESULT
13631  060630  174010                  STD     AC0,(R0)
13632  060632  012701  060714          MOV     #XPAT20,R1
13633  060636  012702  000004          MOV     #4,R2
13634  060642  022021          X17:    CMP     (R0)+,(R1)+     ;IS RESULT CORRECT?
13635  060644  001401                  BEQ     X20
13636  060646  104000                  EMT                     ;
13637  060650  077204          X20:    SOB     R2,X17
13638  060652  012704  000210          MOV     #210,R4         ;IS FPS CORRECT?
13639  060656  020405                  CMP     R4,R5
13640  060660  001401                  BEQ     XDONE
13641  060662  104000                  EMT                     ;
13642  060664  000000          XDAT00: .WORD   0
13643  060666  000000          XDAT01:         0
13644  060670  000000          XDAT02:         0
13645  060672  000000          XDAT03:         0
13646
13647  060674  010421          XPAT00: .WORD   010421
13648  060676  021042          XPAT01:         021042
13649  060700  031463          XPAT02:         031463
13650  060702  042104          XPAT03:         042104
13651
13652  060704  000000          XPAT10: .WORD   0
13653  060706  000000          XAPT11:         0
```

```
13654  060710  000000                  XPAT12:         0
13655  060712  000000                  XPAT13:         0
13656  060714  104210                  XPAT20: .WORD   104210
13657  060716  114631                  XPAT21:         114631
13658  060720  125252                  XPAT22:         125252
13659  060722  135673                  XPAT23:         135673
13660
13661  060724                          XDONE:
13662  060724  004767  037544                JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
13663                                                                  ;SEE IF THE USER HAS EXPRESSED
13664                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
13665                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
13666                                                                  ;THE USER TYPED CONTROL G?).
13667
13668                                  ;*****************************************************************************
13669                                  ;TEST 446       SUBD WITH AC=0 TEST
13670                                  ;*****************************************************************************
13671  060730                          TS446:
13672  060730  005037  061104                CLR     @#YFLAG
13673  060734  012737  061124  061106        MOV     #YPAT00,@#YTMP1 ;P
13674  060742  012737  061134  061110        MOV     #YPAT10,@#YTMP2 ;N
13675  060750  012737  000210  061112        MOV     #210,@#YTMP3
13676  060756  012700  000200          Y1:   MOV     #200,R0
13677  060762  170100                        LDFPS   R0              ;SET DOUBLE MODE
13678  060764  012700  061144                MOV     #YPAT20,R0      ;SET AC0=0
13679  060770  172410                        LDD     (R0),AC0
13680  060772  013700  061106                MOV     @#YTMP1,R0
13681  060776  173010                  Y2:   SUBD    (R0),AC0        ;TEST INSTRUCTION
13682  061000  170205                        STFPS   R5
13683  061002  170011                        SETD
13684  061004  012700  061114                MOV     #YDAT00,R0      ;GET RESULT
13685  061010  174010                        STD     AC0,(R0)
13686  061012  012702  000004                MOV     #4,R2
13687  061016  013701  061110                MOV     @#YTMP2,R1      ;CHECK RESULT.
13688  061022  022021                  Y3:   CMP     (R0)+,(R1)+
13689  061024  001401                        BEQ     1$
13690  061026  104000                        EMT                     ;
13691  061030  077204                  1$:   SOB     R2,Y3
13692  061032  023705  061112                CMP     @#YTMP3,R5      ;FPS CORRECT?
13693  061036  001401                        BEQ     Y4
13694  061040  104000                        EMT                     ;
13695  061042  005737  061104          Y4:   TST     @#YFLAG         ;FINISHED TEST?
13696  061046  001015                        BNE     Y5
13697  061050  012737  177777  061104        MOV     #-1,@#YFLAG
13698  061056  012737  061134  061106        MOV     #YPAT10,@#YTMP1
13699  061064  012737  061124  061110        MOV     #YPAT00,@#YTMP2
13700  061072  012737  000200  061112        MOV     #200,@#YTMP3
13701  061100  000726                        BR      Y1
13702  061102  000424                  Y5:   BR      YDONE
13703
13704  061104  000000                  YFLAG:  .WORD   0
13705  061106  000000                  YTMP1:          0
13706  061110  000000                  YTMP2:          0
13707  061112  000000                  YTMP3:          0
13708
13709  061114  000000                  YDAT00: .WORD   0
```

```
13710  061116  000000                  YDAT01:         0
13711  061120  000000                  YDAT02:         0
13712  061122  000000                  YDAT03:         0
13713
13714  061124  063146                  YPAT00:         063146
13715  061126  052525                  YPAT01:         052525
13716  061130  042104                  YPAT02:         042104
13717  061132  167356                  YPAT03:         167356
13718
13719  061134  163146                  YPAT10:         163146
13720  061136  052525                  YPAT11:         052525
13721  061140  042104                  YPAT12:         042104
13722  061142  167356                  YPAT13:         167356
13723
13724  061144  000000                  YPAT20:         0
13725  061146  000000                  YPAT21:         0
13726  061150  000000                  YPAT22:         0
13727  061152  000000                  YPAT23:         0
13728
13729  061154                          YDONE:
13730  061154  004767  037314                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
13731                                                                  ;SEE IF THE USER HAS EXPRESSED
13732                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
13733                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
13734                                                                  ;THE USER TYPED CONTROL G?).
13735                                  ;*****************************************************************************
13736                                  ;TEST 447       ADDD WITH AC=0 TEST
13737                                  ;*****************************************************************************
13738  061160                          TS447:
13739  061160  005067  000134                 CLR     ZFLAG
13740  061164  012737  061336  061322         MOV     #ZPAT00,@#ZTMP1 ;P
13741  061172  012737  000200  061324         MOV     #200,@#ZTMP2
13742  061200  012700  000200         Z1:     MOV     #200,R0
13743  061204  170100                         LDFPS   R0              ;SET DOUBLE MODE
13744  061206  012700  061356                 MOV     #ZPAT20,R0      ;SET AC0=0
13745  061212  172410                         LDD     (R0),AC0
13746  061214  013700  061322                 MOV     @#ZTMP1,R0
13747  061220  172010                 Z2:     ADDD    (R0),AC0        ;TEST INSTRUCTION
13748  061222  170205                         STFPS   R5
13749  061224  170011                         SETD
13750  061226  012700  061326                 MOV     #ZDAT00,R0      ;GET RESULT
13751  061232  174010                         STD     AC0,(R0)
13752  061234  012702  000004                 MOV     #4,R2
13753  061240  013701  061322                 MOV     @#ZTMP1,R1      ;RESULT CORRECT?
13754  061244  022021                 Z3:     CMP     (R0)+,(R1)+
13755  061246  001401                         BEQ     Z4
13756  061250  104000                         EMT                     ;
13757  061252  077204                 Z4:     SOB     R2,Z3
13758  061254  023705  061324                 CMP     @#ZTMP2,R5      ;FPS CORRECT?
13759  061260  001401                         BEQ     Z5
13760  061262  104000                         EMT                     ;
13761  061264  005737  061320         Z5:     TST     @#ZFLAG         ;FINISHED TEST?
13762  061270  001012                         BNE     Z6
13763  061272  012737  177777  061320         MOV     #-1,@#ZFLAG
13764  061300  012737  061346  061322         MOV     #ZPAT10,@#ZTMP1
13765  061306  012737  000210  061324         MOV     #210,@#ZTMP2
```

```
13766  061314  000731                      BR      Z1
13767  061316  000423              Z6:     BR      ZDONE
13768
13769  061320  000000              ZFLAG:  .WORD   0
13770  061322  000000              ZTMP1:          0
13771  061324  000000              ZTMP2:          0
13772
13773  061326  000000              ZDAT00: .WORD   0
13774  061330  000000              ZDAT01:         0
13775  061332  000000              ZDAT02:         0
13776  061334  000000              ZDAT03:         0
13777
13778  061336  031463              ZPAT00:         031463
13779  061340  010421              ZPAT01:         010421
13780  061342  146314              ZPAT02:         146314
13781  061344  156735              ZPAT03:         156735
13782
13783  061346  156735              ZPAT10:         156735
13784  061350  167356              ZPAT11:         167356
13785  061352  135673              ZPAT12:         135673
13786  061354  146314              ZPAT13:         146314
13787
13788  061356  000000              ZPAT20:         0
13789  061360  000000              ZPAT21:         0
13790  061362  000000              ZPAT22:         0
13791  061364  000000              ZPAT23:         0
13792
13793  061366                      ZDONE:
13794  061366  004767  037102              JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
13795                                                              ;SEE IF THE USER HAS EXPRESSED
13796                                                              ;THE DESIRE TO CHANGE THE SOFTWARE
13797                                                              ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
13798                                                              ;THE USER TYPED CONTROL G?).
13799
13800
13801                              ;*****************************************************************************
13802                              ;TEST 450       ADDF AND ADDD WITH E(AC)=E(FSRC) TEST AND (BUT FT) TEST
13803                              ;*****************************************************************************
13804  061372                      TS450:
13805  061372  012700  003240              MOV     #3240,R0
13806  061376  170100              LDFPS   R0              ;SET FIU FIV FD AND FT
13807  061400  012700  061602              MOV     #AAPAT0,R0      ;FLOWS IN TRAP WILL
13808                                                              ;OCCUR
13809  061404  172410              LDD     (R0),AC0        ;SET UP AC0
13810  061406  012700  061612              MOV     #AAPAT1,R0
13811  061412  172010              AA2:    ADDD    (R0),AC0        ;TEST INSTRUCTION
13812                                                              ;SHOULD TRUNCATE
13813  061414  012700  061572      AA3:    MOV     #AADAT0,R0
13814  061420  174010              STD     AC0,(R0)        ;GET THE RESULT
13815  061422  012701  061622              MOV     #AAPAT2,R1
13816  061426  012702  000004              MOV     #4,R2
13817  061432  022021              AA4:    CMP     (R0)+,(R1)+     ;CORRECT?
13818  061434  001401                      BEQ     AA7
13819  061436  104000                      EMT                     ;
13820  061440  077204              AA7:    SOB     R2,AA4
13821
```

```
13822
13823
13824
13825  061442  012700  003200          ;NOW TEST DOUBLE FLOATING ROUND MODE.
13826  061446  170100                  ;A 1 SHOULD BE ADDED TO THE LSB ON ROUNG MODE.
13827  061450  012700  061602
13828  061454  172410          MOV     #3200,R0        ;SET FD FIV FIV. FT=0
13829  061456  012700  061612  LDFPS   R0
13830  061462  172010          MOV     #AAPAT0,R0
13831                          LDD     (R0),AC0        ;SET UP AC0 OPERAND
13832  061464  012700  061572  MOV     #AAPAT1,R0
13833  061470  174010  AA11:   ADDD    (R0),AC0        ;TEST INSTRUCTION
13834  061472  012701  061632                          ;SHOULD ROUND
13835  061476  012702  000004
13836  061502  022021  AA12:   MOV     #AADAT0,R0
13837  061504  001401          STD     AC0,(R0)        ;GET THE RESULT
13838  061506  104000          MOV     #AAPAT3,R1
13839  061510  077204          MOV     #4,R2
13840                  AA13:   CMP     (R0)+,(R1)+     ;CORRECT?
13841                          BEQ     AA20
13842                          EMT                     ;
13843  061512  012700  003200  AA20:   SOB     R2,AA13
13844  061516  170100
13845  061520  012700  061602  ;NOW TEST ADDF WITH FT=0, ROUND MODE
13846  061524  172410
13847  061526  170001          MOV     #3200,R0                ;FIV=1, FIV=1, FT=0
13848  061530  012700  061652  LDFPS   R0
13849  061534  172010          MOV     #AAPAT0,R0      ;LOAD AC0 OPERAND
13850                          LDD     (R0),AC0
13851  061536                  SETF                    ;ENTER FLOATING MODE
13852  061536  170011          MOV     #AAPAT5,R0
13853                  AA22:   ADDF    (R0),AC0        ;TEST INSTRUCTION
13854  061540  012700  061572                          ;SHOULD ROUND
13855  061544  174010
13856  061546  012701  061662  AA23:
13857  061552  012702  000002          SETD                    ;RESET TO DOUBLE
13858  061556  022021                                  ;MODE
13859  061560  001401          MOV     #AADAT0,R0      ;GET THE RESULT
13860  061562  104000          STD     AC0,(R0)
13861  061564  077204          MOV     #AAPAT6,R1      ;CORRECT?
13862  061566  000137  061672  MOV     #2,R2
13863  061572  000000  AA24:   CMP     (R0)+,(R1)+
13864  061574  000000          BEQ     AA27
13865  061576  000000          EMT                     ;
13866  061600  000000  AA27:   SOB     R2,AA24
13867  061602  000200          JMP     @#AADONE
13868  061604  000000  AADAT0:         0
13869  061606  000000                  0
13870  061610  000000                  0
13871  061612  000200                  0
13872  061614  000000  AAPAT0:         200
13873  061616  000000                  0
13874  061620  000001                  0
13875  061622  000400                  0
13876  061624  000000  AAPAT1:         200
13877  061626  000000                  0
                                       0
                                       1
                        AAPAT2:        400
                                       0
                                       0
```

```
13878  061630  000000                          0
13879  061632  000400          AAPAT3:         400
13880  061634  000000                          0
13881  061636  000000                          0
13882  061640  000001                          1
13883  061642  000400          AAPAT4:         400
13884  061644  000000                          0
13885  061646  100000                          100000
13886  061650  000000                          0
13887  061652  000200          AAPAT5:         200
13888  061654  000001                          1
13889  061656  000000                          0
13890  061660  000000                          0
13891  061662  000400          AAPAT6:         400
13892  061664  000001                          1
13893  061666  000000                          0
13894  061670  000000                          0
13895  061672                  AADONE:
13896  061672  004767  036576          JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
13897                                                          ;SEE IF THE USER HAS EXPRESSED
13898                                                          ;THE DESIRE TO CHANGE THE SOFTWARE
13899                                                          ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
13900                                                          ;THE USER TYPED CONTROL G?).
13901  ;*****************************************************************************************
13902  ;TEST 451       ADDF AND ADDD WITH E(AC) LESS THAN E(FSRC) TEST
13903  ;*****************************************************************************************
13904  061676          TS451:
13905  ;EXPONENT DIFFERENCE=57=71 (OCT) FD=1
13906  061676  012704  003200          MOV     #3200,R4        ;SET FIV,FIV, AND FD
13907  061702  170104                  LDFPS   R4
13908  061704  012700  062352          MOV     #CCP0,R0        ;SET AC0 OPERAND
13909  061710  172410                  LDD     (R0),AC0                ;AC0
13910  061712  012700  062372          MOV     #CCP2,R0
13911  061716  172010          CCX2:   ADDD    (R0),AC0        ;TEST INSTRUCTION
13912  061720  170205                  STFPS   R5              ;GET FPS
13913  061722  012700  062342          MOV     #CCDAT0,R0      ;GET THE RESULT
13914  061726  174010                  STD     AC0,(R0)
13915  061730  012701  062372          MOV     #CCP2,R1        ;IS IT CORRECT
13916  061734  012702  000004          MOV     #4,R2
13917  061740  022021          CCX3:   CMP     (R0)+,(R1)+
13918  061742  001401                  BEQ     CCX6
13919  061744  104000                  EMT                     ;
13920  061746  077204          CCX6:   SOB     R2,CCX3
13921  061750  020405                  CMP     R4,R5           ;FPS CORRECT?
13922  061752  001401                  BEQ     CCX7
13923  061754  104000                  EMT                     ;
13924  ;EXPONENT DIFFERENCE=56=70 (OCT) FD=1
13925  061756  012704  003200  CCX7:   MOV     #3200,R4        ;SET FIV,FIV, AND FD
13926  061762  170104                  LDFPS   R4
13927  061764  012700  062352          MOV     #CCP0,R0        ;SET AC0 OPERAND
13928  061770  172410                  LDD     (R0),AC0
13929  061772  012700  062362          MOV     #CCP1,R0        ;FSRC
13930  061776  172010          CCX8:   ADDD    (R0),AC0        ;TEST INSTRUCTION
13931  062000  170205                  STFPS   R5              ;GET FPS
13932  062002  012700  062342          MOV     #CCDAT0,R0      ;GET THE RESULT
13933  062006  174010                  STD     AC0,(R0)
```

```
CJKDE-B  11/24 CPU CLUSTER DIAG.
CJKDEB.P11     05-AUG-82 15:01

MACY11 30(1046)  05-AUG-82  15:03  PAGE 258
T451    ADDF AND ADDD WITH E(AC) LESS THAN E(FSRC) TEST

 13934  062010  012701  062442          MOV     #CCP7,R1        ;IS IT CORRECT
 13935  062014  012702  000004          MOV     #4,R2
 13936  062020  022021          CCX9:   CMP     (R0)+,(R1)+
 13937  062022  001401                  BEQ     CCX12
 13938  062024  104000                  EMT                     ;
 13939  062026  077204          CCX12:  SOB     R2,CCX9
 13940  062030  020405                  CMP     R4,R5           ;FPS CORRECT?
 13941  062032  001401                  BEQ     CCX13
 13942  062034  104000                  EMT                     ;
 13943                  ;EXPONENT DIFFERENCE=25=31 (OCT) FD=0
 13944  062036  012700  062352  CCX13:  MOV     #CCP0,R0        ;SET UP AC0 OPERAND.
 13945  062042  172410                  LDD     (R0),AC0
 13946  062044  012704  003000          MOV     #3000,R4        ;SET FIV,FIV. CLEAR FD.
 13947  062050  170104                  LDFPS   R4
 13948  062052  012700  062432          MOV     #CCP6,R0        ;FSRC
 13949  062056  172010          CCX14:  ADDF    (R0),AC0        ;TEST INSTRUCTION
 13950  062060  170205                  STFPS   R5
 13951  062062  170011                  SETD                    ;REENTER DOUBLE MOVE
 13952  062064  012700  062342          MOV     #CCDAT0,R0      ;GET THE RESULT
 13953  062070  174010                  STD     AC0,(R0)
 13954  062072  012701  062432          MOV     #CCP6,R1        ;IS THE RESULT CORRECT?
 13955  062076  012702  000002          MOV     #2,R2
 13956  062102  022021          CCX15:  CMP     (R0)+,(R1)+
 13957  062104  001401                  BEQ     CCX18
 13958  062106  104000                  EMT                     ;
 13959  062110  077204          CCX18:  SOB     R2,CCX15
 13960  062112  020405                  CMP     R4,R5
 13961  062114  001401                  BEQ     CCX19
 13962  062116  104000                  EMT                     ;
 13963                  ;EXPONENT DIFFERENCE=24=30 (OCT) FD=0
 13964  062120  012700  062402  CCX19:  MOV     #CCP3,R0        ;SET UP AC0 OPERAND.
 13965  062124  172410                  LDD     (R0),AC0
 13966  062126  012704  003000          MOV     #3000,R4        ;SET FIV,FIV. CLEAR FD.
 13967  062132  170104                  LDFPS   R4
 13968  062134  012700  062422          MOV     #CCP5,R0        ;FSRC
 13969  062140  172010          CCX20:  ADDF    (R0),AC0        ;TEST INSTRUCTION
 13970  062142  170205                  STFPS   R5
 13971  062144  170011                  SETD                    ;REENTER DOUBLE MOVE
 13972  062146  012700  062342          MOV     #CCDAT0,R0      ;GET THE RESULT
 13973  062152  174010                  STD     AC0,(R0)
 13974  062154  012701  062452          MOV     #CCP10,R1       ;IS THE RESLT CORRECT?
 13975  062160  012702  000002          MOV     #2,R2
 13976  062164  022021          CCX21:  CMP     (R0)+,(R1)+
 13977  062166  001401                  BEQ     CCX24
 13978  062170  104000                  EMT                     ;
 13979  062172  077204          CCX24:  SOB     R2,CCX21
 13980  062174  020405                  CMP     R4,R5
 13981  062176  001401                  BEQ     CCX25
 13982  062200  104000                  EMT                     ;
 13983                  ;EXPONENT DIFFERENCE=1 FD=1
 13984  062202  012704  003200  CCX25:  MOV     #3200,R4        ;SET FIV,FIV, AND FD
 13985  062206  170104                  LDFPS   R4
 13986  062210  012700  062352          MOV     #CCP0,R0        ;SET AC0 OPERAND
 13987  062214  172410                  LDD     (R0),AC0
 13988  062216  012700  062402          MOV     #CCP3,R0        ;FSRC
 13989  062222  172010          CCX26:  ADDD    (R0),AC0        ;TEST INSTRUCTION
```

```
13990  062224  170205
13991  062226  012700  062342          STFPS   R5                      ;GET FPS
13992  062232  174010                  MOV     #CCDATO,R0              ;GET THE RESULT
13993  062234  012701  062462          STD     AC0,(R0)
13994  062240  012702  000004          MOV     #CCP11,R1               ;IS IT CORRECT
13995  062244  022021                  MOV     #4,R2
13996  062246  001401          CCX27:  CMP     (R0)+,(R1)+
13997  062250  104000                  BEQ     CCX30
13998  062252  077204                  EMT                             ;
13999  062254  020405          CCX30:  SOB     R2,CCX27
14000  062256  001401                  CMP     R4,R5                   ;FPS CORRECT?
14001  062260  104000                  BEQ     CCX31
14002                                   EMT                             ;
                                ;EXPONENT DIFFERENCE=100=144 (OCT) FD=1
14003  062262  012704  003200  CCX31:  MOV     #3200,R4                ;SET FIV,FIV, AND FD
14004  062266  170104                  LDFPS   R4
14005  062270  012700  062352          MOV     #CCP0,R0                ;SET AC0 OPERAND
14006  062274  172410                  LDD     (R0),AC0
14007  062276  012700  062412          MOV     #CCP4,R0                ;FSRC
14008  062302  172010          CCX32:  ADDD    (R0),AC0                ;TEST INSTRUCTION
14009  062304  170205                  STFPS   R5                      ;GET FPS
14010  062306  012700  062342          MOV     #CCDATO,R0              ;GET THE RESULT
14011  062312  174010                  STD     AC0,(R0)
14012  062314  012701  062412          MOV     #CCP4,R1                ;IS IT CORRECT
14013  062320  012702  000004          MOV     #4,R2
14014  062324  022021          CCX33:  CMP     (R0)+,(R1)+
14015  062326  001401                  BEQ     CCX36
14016  062330  104000                  EMT                             ;
14017  062332  077204          CCX36:  SOB     R2,CCX33
14018  062334  020405                  CMP     R4,R5                   ;FPS CORRECT?
14019  062336  001461                  BEQ     CCXDONE
14020  062340  104000                  EMT                             ;
14021  062342  000000          CCDATO: 0
14022  062344  000000                  0
14023  062346  000000                  0
14024  062350  000000                  0
14025  062352  000200          CCP0:   200                             ;E(AC)=1
14026  062354  000000                  0
14027  062356  000000                  0
14028  062360  000000                  0
14029  062362  016200          CCP1:   16200                           ;E(FSRC)=E(AC)+56=57
14030  062364  000000                  0                               ;       =71(OCT)
14031  062366  000000                  0
14032  062370  000000                  0
14033  062372  016400          CCP2:   16400                           ;E(FSRC)=E(AC)+57=58
14034  062374  000000                  0                               ;       =72(OCT)
14035  062376  000000                  0
14036  062400  000000                  0
14037  062402  000400          CCP3:   400                             ;E(FSRC)=E(AC)+1=2
14038  062404  000000                  0
14039  062406  000000                  0
14040  062410  000000                  0
14041  062412  031200          CCP4:   31200                           ;E(FSRC)=E(AC)+100=101=145(OCT)
14042  062414  000000                  0
14043  062416  000000                  0
14044  062420  000000                  0
14045  062422  006200          CCP5:   6200                            ;E(FSRC)=E(AC)+24=25=31(OCT)
```

```
14046  062424  000000                          0
14047  062426  000000                          0
14048  062430  000000                          0
14049  062432  006400                  CCP6:   6400                    ;E(FSRC)=E(AC)+25=26=32(OCT)
14050  062434  000000                          0
14051  062436  000000                          0
14052  062440  000000                          0
14053  062442  016200                  CCP7:   16200                   ;CCP1 RES
14054  062444  000000                          0
14055  062446  000000                          0
14056  062450  000001                          1
14057  062452  006200                  CCP10:  6200                    ;CCP5 RES
14058  062454  000001                          1
14059  062456  000000                          0
14060  062460  000000                          0
14061  062462  000500                  CCP11:  500                     ;CCP3 RES
14062  062464  000000                          0
14063  062466  000000                          0
14064  062470  000000                          0
14065  062472  000200                  CCP12:  200                     ;BAD CONSTANT
14066  062474  000000                          0                       ;RES CCP2,CCP4
14067  062476  000000                          0
14068  062500  000000                          0
14069
14070  062502                          CCXDONE:
14071  062502  004767  035766                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
14072                                                                  ;SEE IF THE USER HAS EXPRESSED
14073                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
14074                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
14075                                                                  ;THE USER TYPED CONTROL G?).
14076
14077                           ;*********************************************************************************************
14078                           ;TEST 452       ADDF AND ADDD WITH E(AC) GREATER THAN E(FSRC) TEST
14079                           ;*********************************************************************************************
14080  062506                  TS452:
14081                           ;EXPONENT DIFFERENCE=57=71 (OCT) FD=1
14082  062506  012704  003200          MOV     #3200,R4                ;SET FIV FIV, AND FD
14083  062512  170104                  LDFPS   R4
14084  062514  012700  063202          MOV     #BBPAT2,R0              ;SET AC0 OPERAND.
14085  062520  172410                  LDD     (R0),AC0
14086  062522  012700  063172          MOV     #BBPAT1,R0              ;FSRC
14087  062526  172010          BB2:    ADDD    (R0),AC0                ;TEST INSTRUCTION
14088  062530  170205                  STFPS   R5
14089  062532  012700  063152  BB3:    MOV     #BBDAT0,R0              ;GET THE RESULT
14090  062536  174010                  STD     AC0,(R0)
14091  062540  012701  063202          MOV     #BBPAT2,R1              ;RESULT CORRECT?
14092  062544  012702  000004          MOV     #4,R2
14093  062550  022021          BB4:    CMP     (R0)+,(R1)+
14094  062552  001401                  BEQ     BB5
14095  062554  104000                  EMT                             ;
14096  062556  077204          BB5:    SOB     R2,BB4
14097                                                                  ;WAS FPS CORRECT?
14098  062560  020405                  CMP     R4,R5
14099  062562  001401                  BEQ     BB6
14100  062564  104000                  EMT                             ;
14101                           ;EXPONENT DIFFERENCE=56=70 (OCT) FD=1
```

```
14102  062566  012704  003200  BB6:    MOV     #3200,R4        ;SET FIV,FIV, AND FD
14103  062572  170104                  LDFPS   R4
14104  062574  012700  063222          MOV     #BBPAT4,R0      ;SET AC0 OPERAND
14105  062600  172410                  LDD     (R0),AC0
14106  062602  012700  063172          MOV     #BBPAT1,R0      ;FSRC
14107  062606  172010          BB7:    ADDD    (R0),AC0        ;TEST INSTRUCTION
14108  062610  170205                  STFPS   R5              ;GET FPS
14109  062612  012700  063152          MOV     #BBDAT0,R0      ;GET THE RESULT
14110  062616  174010                  STD     AC0,(R0)
14111  062620  012701  063262          MOV     #BBP10,R1       ;IS IT CORRECT
14112  062624  012702  000004          MOV     #4,R2
14113  062630  022021          BB10:   CMP     (R0)+,(R1)+
14114  062632  001401                  BEQ     BB13
14115  062634  104000                  EMT                     ;
14116  062636  077204          BB13:   SOB     R2,BB10
14117  062640  020405                  CMP     R4,R5           ;FPS CORRECT?
14118  062642  001401                  BEQ     BB14
14119  062644  104000                  EMT                     ;
14120                          ;EXPONENT DIFFERENCE=25=31 (OCT) FD=0
14121  062646  012700  063162  BB14:   MOV     #BBPAT0,R0      ;SET UP AC0 OPERAND
14122  062652  172410                  LDD     (R0),AC0
14123  062654  012704  003000          MOV     #3000,R4        ;SET FIV AND FIV
14124                                                          ;CLEAR FD
14125  062660  170104                  LDFPS   R4
14126  062662  012700  063172          MOV     #BBPAT1,R0      ;FSRC
14127  062666  172010          BB15:   ADDF    (R0),AC0        ;TEST INSTRUCTION
14128  062670  170205                  STFPS   R5
14129  062672  170011                  SETD                    ;REENTED DOUBLE MODE.
14130  062674  012700  063152          MOV     #BBDAT0,R0      ;GET THE RESULT
14131  062700  174010                  STD     AC0,(R0)
14132  062702  012701  063162          MOV     #BBPAT0,R1      ;IS THE RESULT
14133  062706  012702  000002          MOV     #2,R2           ;CORRECT?
14134  062712  022021          BB16:   CMP     (R0)+,(R1)+
14135  062714  001401                  BEQ     BB17
14136  062716  104000                  EMT                     ;
14137  062720  077204          BB17:   SOB     R2,BB16
14138  062722  020405                  CMP     R4,R5           ;IS FPS CORRECT?
14139  062724  001401                  BEQ     BB20
14140  062726  104000                  EMT                     ;
14141                          ;EXPONENT DIFFERENCE=24=30 (OCT)
14142  062730  012700  063212  BB20:   MOV     #BBPAT3,R0      ;SET UP AC0 OPERAND.
14143  062734  172410                  LDD     (R0),AC0
14144  062736  012704  003000          MOV     #3000,R4        ;SET FIU,FIV. CLEAR FD.
14145  062742  170104                  LDFPS   R4
14146  062744  012700  063172          MOV     #BBPAT1,R0      ;FSRC
14147  062750  172010          BB21:   ADDF    (R0),AC0        ;TEST INSTRUCTION
14148  062752  170205                  STFPS   R5
14149  062754  170011                  SETD                    ;REENTER DOUBLE MODE
14150  062756  012700  063152          MOV     #BBDAT0,R0      ;GET THE RESULT
14151  062762  174010                  STD     AC0,(R0)
14152  062764  012701  063252          MOV     #BBP7,R1        ;IS THE RESULT CORRECT?
14153  062770  012702  000002          MOV     #2,R2
14154  062774  022021          BB22:   CMP     (R0)+,(R1)+
14155  062776  001401                  BEQ     BB25
14156  063000  104000                  EMT                     ;
14157  063002  077204          BB25:   SOB     R2,BB22
```

```
14158  063004  020405                        CMP     R4,R5
14159  063006  001401                        BEQ     BB26
14160  063010  104000                        EMT                     ;
14161                                  ;EXPONENT DIFFERENCE=1
14162  063012  012704  003200          BB26: MOV     #3200,R4
14163  063016  170104                        LDFPS   R4              ;SET UP AC0 OPERAND
14164  063020  012700  063232                MOV     #BBPAT5,R0
14165  063024  172410                        LDD     (R0),AC0
14166  063026  012700  063172                MOV     #BBPAT1,R0      ;FSRC
14167  063032  172010                  BB27: ADDD    (R0),AC0        ;TEST INSTRUCTION
14168  063034  170205                        STFPS   R5
14169  063036  012700  063152                MOV     #BBDAT0,R0      ;GET THE RESULT.
14170  063042  174010                        STD     AC0,(R0)
14171  063044  012701  063272                MOV     #BBP11,R1       ;IS IT CORRECT?
14172  063050  012702  000004                MOV     #4,R2
14173  063054  022021                  BB30: CMP     (R0)+,(R1)+
14174  063056  001401                        BEQ     BB31
14175  063060  104000                        EMT                     ;
14176  063062  077204                  BB31: SOB     R2,BB30
14177  063064  020405                        CMP     R4,R5           ;IS FPS CORRECT
14178  063066  001401                        BEQ     BB32
14179  063070  104000                        EMT                     ;
14180                                 ;EXPONENT DIFFERENCE=100=144 (OCT)
14181  063072  012704  003200          BB32: MOV     #3200,R4
14182  063076  170104                        LDFPS   R4              ;SET FIV,FIV AND FD
14183  063100  012700  063242                MOV     #BBPAT6,R0      ;SET UP AC0 OPERAND.
14184  063104  172410                        LDD     (R0),AC0
14185  063106  012700  063172                MOV     #BBPAT1,R0      ;FSRC
14186  063112  172010                  BB33: ADDD    (R0),AC0        ;TEST INSTRUCTION
14187  063114  170205                        STFPS   R5
14188  063116  012700  063152                MOV     #BBDAT0,R0      ;GET THE RESULT
14189  063122  174010                        STD     AC0,(R0)
14190  063124  012701  063242                MOV     #BBPAT6,R1      ;IS IT CORRECT
14191  063130  012702  000004                MOV     #4,R2
14192  063134  022021                  BB34: CMP     (R0)+,(R1)+
14193  063136  001401                        BEQ     BB35
14194  063140  104000                        EMT                     ;
14195  063142  077204                  BB35: SOB     R2,BB34
14196  063144  020405                        CMP     R4,R5           ;IS FPS CORRECT
14197  063146  001455                        BEQ     BBDONE
14198  063150  104000                        EMT                     ;
14199  063152  000000          BBDAT0: 0
14200  063154  000000                  0
14201  063156  000000                  0
14202  063160  000000                  0
14203  063162  006400          BBPAT0: 6400                    ;F(AC)=E(FSRC)+25=26
14204  063164  000000                  0                       ;       =32(OCT)
14205  063166  000000                  0
14206  063170  000000                  0
14207  063172  000200          BBPAT1: 200
14208  063174  000000                  0                       ;E(FSRC)=1
14209  063176  000000                  0
14210  063200  000000                  0
14211  063202  016400          BBPAT2: 16400
14212  063204  000000                  0                       ;E(AC)=E(FSRC)+57=58
14213  063206  000000                  0                       ;       =72(OCT)
```

```
14214  063210  000000                    0
14215  063212  006200    BBPAT3: 6200                ;E(AC)=E(FSRC)+24=25
14216  063214  000000            0                   ;                 =31(OCT)
14217  063216  000000            0
14218  063220  000000            0
14219  063222  016200    BBPAT4: 16200               ;E(AC)=E(FSR6)+56=57
14220  063224  000000            0                   ;                 =71(OCT)
14221  063226  000000            0
14222  063230  000000            0
14223  063232  000400    BBPAT5: 400                 ;E(AC)=E(FSRC)+1=2
14224  063234  000000            0
14225  063236  000000            0
14226  063240  000000            0
14227  063242  031200    BBPAT6: 31200               ;E(AC)=E(FSRC)+100=101
14228  063244  000000            0                   ;                 =145(OCT)
14229  063246  000000            0
14230  063250  000000            0
14231  063252  006200    BBP7:   6200                ;BBPAT3 RES
14232  063254  000001            1
14233  063256  000000            0
14234  063260  000000            0
14235  063262  016200    BBP10:  16200               ;BBPAT4 RES
14236  063264  000000            0
14237  063266  000000            0
14238  063270  000001            1
14239  063272  000500    BBP11:  500                 ;BBPAT5 RES
14240  063274  000000            0
14241  063276  000000            0
14242  063300  000000            0
14243  063302            BBDONE:
14244  063302  004767  035166        JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
14245                                                        ;SEE IF THE USER HAS EXPRESSED
14246                                                        ;THE DESIRE TO CHANGE THE SOFTWARE
14247                                                        ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
14248                                                        ;THE USER TYPED CONTROL G?).
14249                   ;*****************************************************************************
14250                   ;TEST 453       ADDD WITH NEGATVE OPRANDS TEST
14251                   ;*****************************************************************************
14252  063306           TS453:
14253                   ;BOTH OPERANDS NEGATIVE
14254  063306  012704  003200            MOV     #3200,R4        ;SET FIO, FIV, AND FD
14255  063312  170104                    LDFPS   R4
14256  063314  012700  064072            MOV     #DDP1,R0                ;SET AC0 OPERAND
14257  063320  172410                    LDD     (R0),AC0
14258  063322  012700  064072            MOV     #DDP1,R0                ;ESRC
14259  063326  172010            DD2:    ADDD    (R0),AC0                ;TEST INSTRUCTION
14260  063330  170205                    STFPS   R5                      ;GET FPS
14261  063332  012700  064052            MOV     #DDDAT0,R0              ;GET THE RESULT
14262  063336  174010                    STD     AC0,(R0)
14263  063340  012701  064172            MOV     #DDP9,R1                ;IS IT CORRECT
14264  063344  012702  000004            MOV     #4,R2
14265  063350  022021            DD3:    CMP     (R0)+,(R1)+
14266  063352  001401                    BEQ     DD6
14267  063354  104000                    EMT                     ;
14268  063356  077204            DD6:    SOB     R2,DD3
14269  063360  052704  000010            BIS     #10,R4
```

```
CJKDE-B  11/24 CPU CLUSTER DIAG.          MACY11 30(1046)  05-AUG-82  15:03  PAGE 264
CJKDEB.P11    05-AUG-82 15:01             T453    ADDD WITH NEGATVE OPRANDS TEST

 14270  063364  020405                             CMP     R4,R5                   ;FPS CORRECT?
 14271  063366  001401                             BEQ     DD7
 14272  063370  104000                             EMT                             ;
 14273                                     ;AC POS FSRC NEG         AC=-FSRC
 14274  063372  012704  003200             DD7:    MOV     #3200,R4                ;SET FIO, FIV, AND FD
 14275  063376  170104                             LDFPS   R4
 14276  063400  012700  064102                     MOV     #DDP2,R0                ;SET ACO OPERAND
 14277  063404  172410                             LDD     (R0),AC0
 14278  063406  012700  064072                     MOV     #DDP1,R0                ;FSPC
 14279  063412  172010                     DD8:    ADDD    (R0),AC0                ;TEST INSTRUCTION
 14280  063414  170205                             STFPS   R5                      ;GET FPS
 14281  063416  012700  064052                     MOV     #DDDAT0,R0              ;GET THE RESULT
 14282  063422  174010                             STD     AC0,(R0)
 14283  063424  012701  064062                     MOV     #DDP0,R1                ;IS IT CORRECT
 14284  063430  012702  000004                     MOV     #4,R2
 14285  063434  022021                     DD10:   CMP     (R0)+,(R1)+
 14286  063436  001401                             BEQ     DD11
 14287  063440  104000                             EMT                             ;
 14288  063442  077204                     DD11:   SOB     R2,DD10
 14289  063444  052704  000004                     BIS     #4,R4
 14290  063450  020405                             CMP     R4,R5                   ;FPS CORRECT?
 14291  063452  001401                             BEQ     DD12
 14292  063454  104000                             EMT                             ;
 14293                                     ;AC NEG FSRC POS                        AC=-FSRC
 14294  063456  012704  003200             DD12:   MOV     #3200,R4                ;SET FIU, FIV, AND FD
 14295  063462  170104                             LDFPS   R4
 14296  063464  012700  064072                     MOV     #DDP1,R0                ;SET ACO OPERAND
 14297  063470  172410                             LDD     (R0),AC0
 14298  063472  012700  064102                     MOV     #DDP2,R0                ;FSRC
 14299  063476  172010                     DD13:   ADDD    (R0),AC0                ;TEST INSTRUCTION
 14300  063500  170205                             STFPS   R5                      ;GET FPS
 14301  063502  012700  064052                     MOV     #DDDAT0,R0              ;GET THE RESULT
 14302  063506  174010                             STD     AC0,(R0)
 14303  063510  012701  064062                     MOV     #DDP0,R1                ;IS IT CORRECT
 14304  063514  012702  000004                     MOV     #4,R2
 14305  063520  022021                     DD14:   CMP     (R0)+,(R1)+
 14306  063522  001401                             BEQ     DD15
 14307  063524  104000                             EMT                             ;
 14308  063526  077204                     DD15:   SOB     R2,DD14
 14309  063530  052704  000004                     BIS     #4,R4
 14310  063534  020405                             CMP     R4,R5                   ;EPS CORRECT?
 14311  063536  001401                             BEQ     DD16
 14312  063540  104000                             EMT                             ;
 14313                                     ;AC0 POC        FSRC    NEG     /AC/ > /FSRC/
 14314  063542  012704  003200             DD16:   MOV     #3200,R4                ;SET FIV, FIV AND FD
 14315  063546  170104                             LDFPS   R4
 14316  063550  012700  064112                     MOV     #DDP3,R0                ;SET ACO OPERAND
 14317  063554  172410                             LDD     (R0),AC0
 14318  063556  012700  064142                     MOV     #DDP6,R0                ;ESPC
 14319  063562  172010                     DD17:   ADDD    (R0),AC0                ;TEST INSTRUCTION
 14320  063564  170205                             STFPS   R5                      ;GET FPS
 14321  063566  012700  064052                     MOV     #DDDAT0,R0              ;GET THE RESULT
 14322  063572  174010                             STD     AC0,(R0)
 14323  063574  012701  064152                     MOV     #DDP7,R1                ;IS IT CORRECT
 14324  063600  012702  000004                     MOV     #4,R2
 14325  063604  022021                     DD18:   CMP     (R0)+,(R1)+
```

```
14326  063606  001401                BEQ     DD21
14327  063610  104000                EMT                             ;
14328  063612  077204        DD21:   SOB     R2,DD18
14329  063614  020405                CMP     R4,R5                   ;EPS CORRECT?
14330  063616  001401                BEQ     DD22
14331  063620  104000                EMT                             ;
14332                        ;AC NEG FSRC    POS     /FSRC/ >/AC/
14333  063622  012704  003200  DD22:   MOV     #3200,R4                ;SET FIO,FIV, AND FD
14334  063626  170104                LDFPS   R4
14335  063630  012700  064142        MOV     #DDP6,R0                ;SET AC0 OPERAND
14336  063634  172410                LDD     (R0),AC0
14337  063636  012700  064112        MOV     #DDP3,R0                ;FSPC
14338  063642  172010        DD23:   ADDD    (R0),AC0                ;TEST INSTRUCTION
14339  063644  170205                STFPS   R5                      ;GET FPS
14340  063646  012700  064052        MOV     #DDDAT0,R0              ;GET THE RESULT
14341  063652  174010                STD     AC0,(R0)
14342  063654  012701  064152        MOV     #DDP7,R1                ;IS IT CORRECT?
14343  063660  012702  000004        MOV     #4,R2
14344  063664  022021        DD24:   CMP     (R0)+,(R1)+
14345  063666  001401                BEQ     DD27
14346  063670  104000                EMT                             ;
14347  063672  077204        DD27:   SOB     R2,DD24
14348  063674  020405                CMP     R4,R5                   ;FPS CORRECT?
14349  063676  001401                BEQ     DD30
14350  063700  104000                EMT                             ;
14351                        ;AC0 POS        FSRC    NEG     /AC/</FRSRC/
14352  063702  012704  003200  DD30:   MOV     #3200,R4                ;SET FIO,FIV,AND FD
14353  063706  170104                LDFPS   R4
14354  063710  012700  064122        MOV     #DDP4,R0                ;SET AC0 OPERAND
14355  063714  172410                LDD     (R0),AC0
14356  063716  012700  064132        MOV     #DDP5,R0                ;FSPC
14357  063722  172010        DD31:   ADDD    (R0),AC0                ;TEST INSTRUCTION
14358  063724  170205                STFPS   R5                      ;GET FPS
14359  063726  012700  064052        MOV     #DDDAT0,R0              ;GET THE RESULT
14360  063732  174010                STD     AC0,(R0)
14361  063734  012701  064162        MOV     #DDP8,R1                ;IS IT CORRECT
14362  063740  012702  000004        MOV     #4,R2
14363  063744  022021        DD32:   CMP     (R0)+,(R1)+
14364  063746  001401                BEQ     DD35
14365  063750  104000                EMT                             ;
14366  063752  077204        DD35:   SOB     R2,DD32
14367  063754  052704  000010        BIS     #10,R4
14368  063760  020405                CMP     R4,R5                   ;FPS CORRECT?
14369  063762  001401                BEQ     DD36
14370  063764  104000                EMT                             ;
14371                        ;AC0 NEG        FSRC    POS     /FSRC/</AC/
14372  063766  012704  003200  DD36:   MOV     #3200,R4                ;SET FIO, FIV, AND FD
14373  063772  170104                LDFPS   R4
14374  063774  012700  064132        MOV     #DDP5,R0                ;SET AC0 OPERAND
14375  064000  172410                LDD     (R0),AC0
14376  064002  012700  064122        MOV     #DDP4,R0                ;FSPC
14377  064006  172010        DD37:   ADDD    (R0),AC0                ;TEST INSTRUCTION
14378  064010  170205                STFPS   R5                      ;GET FPS
14379  064012  012700  064052        MOV     #DDDAT0,R0              ;GET THE RESULT
14380  064016  174010                STD     AC0,(R0)
14381  064020  012701  064162        MOV     #DDP8,R1                ;IS IT CORRECT
```

```
 14382  064024  012702  000004          MOV     #4,R2
 14383  064030  022021          DD38:   CMP     (R0)+,(R1)+
 14384  064032  001401                  BEQ     DD41
 14385  064034  104000                  EMT                             ;
 14386  064036  077204          DD41:   SOB     R2,DD38
 14387  064040  052704  000010          BIS     #10,R4
 14388  064044  020405                  CMP     R4,R5                   ;FPS CORRECT?
 14389  064046  001455                  BEQ     DDDONE
 14390  064050  104000                  EMT                             ;
 14391  064052  000000          DDDATO: 0
 14392  064054  000000                  0
 14393  064056  000000                  0
 14394  064060  000000                  0
 14395  064062  000000          DDP0:   0
 14396  064064  000000                  0
 14397  064066  000000                  0
 14398  064070  000000                  0
 14399  064072  100200          DDP1:   100200                          ;-DDP2
 14400  064074  000000                  0
 14401  064076  000000                  0
 14402  064100  000000                  0
 14403  064102  000200          DDP2:   200                             ;-DDP1
 14404  064104  000000                  0
 14405  064106  000000                  0
 14406  064110  000000                  0
 14407  064112  001100          DDP3:   1100                            ;EXP=4
 14408  064114  000000                  0                               ;FRAC=...110...
 14409  064116  000000                  0
 14410  064120  000000                  0
 14411  064122  000600          DDP4:   600                             ;EXP=3
 14412  064124  000000                  0                               ;FRAC=...100...
 14413  064126  000000                  0
 14414  064130  000000                  0
 14415  064132  101100          DDP5:   101100                          ;-DDP3
 14416  064134  000000                  0
 14417  064136  000000                  0
 14418  064140  000000                  0
 14419  064142  100600          DDP6:   100600                          ;-DDP4
 14420  064144  000000                  0
 14421  064146  000000                  0
 14422  064150  000000                  0
 14423  064152  001000          DDP7:   1000                            ;DDP3+DDP6
 14424  064154  000000                  0
 14425  064156  000000                  0
 14426  064160  000000                  0
 14427  064162  101000          DDP8:   101000                          ;DDP5+DDP4
 14428  064164  000000                  0
 14429  064166  000000                  0
 14430  064170  000000                  0
 14431  064172  100400          DDP9:   100400                          ;DDP1+DDP1
 14432  064174  000000                  0
 14433  064176  000000                  0
 14434  064200  000000                  0
 14435  064202          DDDONE:
 14436  064202  004767  034266          JSR     PC,..RSET               ;GO INITIALIZE THE FPS AND STACK; AND
 14437                                                                  ;SEE IF THE USER HAS EXPRESSED
```

```
14438                                                   ;THE DESIRE TO CHANGE THE SOFTWARE
14439                                                   ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
14440                                                   ;THE USER TYPED CONTROL G?).
14441                   ;*********************************************************************************
14442                   ;TEST 454       SUBD TEST
14443                   ;*********************************************************************************
14444   064206          TS454:
14445                   ;       USE POSITIVE OPERANDS
14446   064206  012704  003200          MOV     #3200,R4                ;SET FIU, FIV, AND FD
14447   064212  170104                  LDFPS   R4
14448   064214  012700  064400          MOV     #EEP1,R0                ;SET AC0 OPERAND
14449   064220  172410                  LDD     (R0),AC0
14450   064222  012700  064400          MOV     #EEP1,R0                ;FSPC
14451   064226  173010          EE2:    SUBD    (R0),AC0                ;TEST INSTRUCTION
14452   064230  170205                  STFPS   R5                      ;GET FPS
14453   064232  012700  064356          MOV     #EEDAT0,R0              ;GET THE RESULT
14454   064236  174010                  STD     AC0,(R0)
14455   064240  012701  064366          MOV     #EEP0,R1                ;IS IT CORRECT?
14456   064244  012702  000004          MOV     #4,R2
14457   064250  022021          EE3:    CMP     (R0)+,(R1)+
14458   064252  001401                  BEQ     EE6
14459   064254  104000                  EMT                     ;
14460   064256  077204          EE6:    SOB     R2,EE3
14461   064260  052704  000004          BIS     #4,R4
14462   064264  020405                  CMP     R4,R5                   ;FPS CORRECT?
14463   064266  001401                  BEQ     EE7
14464   064270  104000                  EMT                     ;
14465                   ;USE NEGATIVE OPERANDS
14466   064272  012704  003200  EE7:    MOV     #3200,R4                ;SET FIO, FIV, AND FD
14467   064276  170104                  LDFPS   R4
14468   064300  012700  064420          MOV     #EEP3,R0                ;SET AC0 OPERAND
14469   064304  172410                  LDD     (R0),AC0
14470   064306  012700  064420          MOV     #EEP3,R0                ;FSPC
14471   064312  173010          EE8:    SUBD    (R0),AC0                ;TEST INSTRUCTION
14472   064314  170205                  STFPS   R5                      ;GET FPS
14473   064316  012700  064356          MOV     #EEDAT0,R0              ;GET THE RESULT
14474   064322  174010                  STD     AC0,(R0)
14475   064324  012701  064366          MOV     #EEP0,R1                ;IS IT CORRECT?
14476   064330  012702  000004          MOV     #4,R2
14477   064334  022021          EE9:    CMP     (R0)+,(R1)+
14478   064336  001401                  BEQ     EE12
14479   064340  104000                  EMT                     ;
14480   064342  077204          EE12:   SOB     R2,EE9
14481   064344  052704  000004          BIS     #4,R4
14482   064350  020405                  CMP     R4,R5                   ;FPS CORRECT?
14483   064352  001432                  BEQ     EEDONE
14484   064354  104000                  EMT                     ;
14485   064356  000000  EEDAT0:  0
14486   064360  000000                  0
14487   064362  000000                  0
14488   064364  000000                  0
14489   064366  000000  EEP0:    0
14490   064370  000000                  0
14491   064372  000000          00000
14492   064374  000000                  0
14493   064376  000000                  0
```

```
14494  064400  000200                  EEP1:   200
14495  064402  000000                          0
14496  064404  000000                          0
14497  064406  000000                          0
14498  064410  000400                  EEP2:   400
14499  064412  000000                          0
14500  064414  000000                          0
14501  064416  000000                          0
14502  064420  100200                  EEP3:   100200
14503  064422  000000                          0
14504  064424  000000                          0
14505  064426  000000                          0
14506  064430  100400                  EEP4:   100400
14507  064432  000000                          0
14508  064434  000000                          0
14509  064436  000000                          0
14510  064440                          EEDONE:
14511  064440  004767  034030                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
14512                                                                  ;SEE IF THE USER HAS EXPRESSED
14513                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
14514                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
14515                                                                  ;THE USER TYPED CONTROL G?).
14516                                  ;*****************************************************************************
14517                                  ;TEST 455       NORMALIZE ALGORITHM TEST
14518                                  ;*****************************************************************************
14519  064444                          TS455:
14520                                  ;USE DATA PATTERNS THAT REQUIRE ONLY ONE LEFT SHIFT TO NORMALIZE
14521  064444  012704  003200                  MOV     #3200,R4                ;SET FIO, FIV, AND FD
14522  064450  170104                          LDFPS   R4
14523  064452  012700  064634                  MOV     #FFP2,R0                ;SET ACO OPERAND
14524  064456  172410                          LDD     (R0),AC0
14525  064460  012700  064644                  MOV     #FFP3,R0                ;FSPC
14526  064464  172010                  FF2:    ADDD    (R0),AC0                ;TEST INSTRUCTION
14527  064466  170205                          STFPS   R5                      ;GET FPS
14528  064470  012700  064604                  MOV     #FFDATO,R0              ;GET THE RESULT
14529  064474  174010                          STD     AC0,(R0)
14530  064476  012701  064654                  MOV     #FFP4, R1               ;IS IT CORRECT
14531  064502  012702  000004                  MOV     #4,R2
14532  064506  022021                  FF3:    CMP     (R0)+,(R1)+
14533  064510  001401                          BEQ     FF4
14534  064512  104000                          EMT                     ;
14535  064514  077204                  FF4:    SOB     R2,FF3
14536  064516  020405                          CMP     R4,R5                   ;FPS CORRECT?
14537  064520  001401                          BEQ     FF5
14538  064522  104000                          EMT                     ;
14539                                  ;USE DATA PATTERNS WHICH REQUIRE 56 LEFT SHIFTS TO NORMALIZE
14540                                  ;THE RESULT
14541  064524  012704  003200          FF5:    MOV     #3200,R4                ;SET FIU, FIV, AND FD
14542  064530  170104                          LDFPS   R4
14543  064532  012700  064614                  MOV     #FFP0,R0                ;SET AC0 OPERAND
14544  064536  172410                          LDD     (R0),AC0
14545  064540  012700  064624                  MOV     #FFP1,R0                ;FSRC
14546  064544  172010                  FF6:    ADDD    (R0),AC0                ;TEST INSTRUCTION
14547  064546  170205                          STFPS   R5                      ;GET FPS
14548  064550  012700  064604                  MOV     #FFDATO,R0              ;GET THE RESULT
14549  064554  174010                          STD     AC0,(R0)
```

```
14550  064556  012701  064654          MOV     #FFP4,R1                ;IS IT CORRECT
14551  064562  012702  000004          MOV     #4,R2
14552  064566  022021          FF7:    CMP     (R0)+,(R1)+
14553  064570  001401                  BEQ     FF10
14554  064572  104000                  EMT                             ;
14555  064574  077204          FF10:   SOB     R2,FF7
14556  064576  020405                  CMP     R4,R5                   ;FPS CORRECT?
14557  064600  001431                  BEQ     FFDONE
14558  064602  104000                  EMT                             ;
14559
14560
14561  064604  000000          FFDATO: 0
14562  064606  000000                  0
14563  064610  000000                  0
14564  064612  000000                  0
14565
14566  064614  016000          FFP0:   16000
14567  064616  000000                  0
14568  064620  000000                  0
14569  064622  000001                  1
14570  064624  116000          FFP1:   116000
14571  064626  000000                  0
14572  064630  000000                  0
14573  064632  000000                  0
14574  064634  000500          FFP2:   500
14575  064636  000000                  0
14576  064640  000000                  0
14577  064642  000000                  0
14578  064644  100400          FFP3:   100400
14579  064646  000000                  0
14580  064650  000000                  0
14581  064652  000000                  0
14582  064654  000200          FFP4:   200                             ;FFP4=FFP0+FFP1
14583  064656  000000                  0                               ;    =FFP3+FFP4
14584  064660  000000                  0
14585  064662  000000                  0
14586
14587  064664          FFDONE:
14588  064664  004767  033604          JSR     PC,..RSET               ;GO INITIALIZE THE FPS AND STACK; AND
14589                                                                  ;SEE IF THE USER HAS EXPRESSED
14590                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
14591                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
14592                                                                  ;THE USER TYPED CONTROL G?).
14593
14594
14595
14596  ;*****************************************************************************
14597  ;*****************************************************************************
14598  ;FLOATING POINT SECOND PART
14599  ;*****************************************************************************
14600  ;*****************************************************************************
14601
14602
14603  ;*****************************************************************************************
14604  ;TEST 456        ROUND\TRUNK TEST
14605  ;*****************************************************************************************
```

```
14606  064670                          TS456:
14607
14608                                          ;ROUND AND NORMALIZE TEST
14609
14610  064670  012704  003200                  MOV     #3200,R4                ;SET FIU, FIV, AND FD
14611  064674  170104                          LDFPS   R4
14612  064676  012700  065300                  MOV     #HHP0,R0                ;SET AC0 OPERAND
14613  064702  172410                          LDD     (R0),AC0
14614  064704  012700  065310                  MOV     #HHP1,R0                ;FSPC
14615  064710  172010                  HH2:    ADDD    (R0),AC0                ;TEST INSTRUCTION
14616  064712  170205                          STFPS   R5                      ;GET FPS
14617  064714  012700  065270                  MOV     #HHDAT0,R0              ;GET THE RESULT
14618  064720  174010                          STD     AC0,(R0)
14619  064722  012701  065320                  MOV     #HHP2,R1                ;IS IT CORRECT
14620  064726  012702  000004                  MOV     #4,R2
14621  064732  022021                  HH3:    CMP     (R0)+,(R1)+
14622  064734  001401                          BEQ     HH6
14623  064736  104000                          EMT                     ;
14624  064740  077204                  HH6:    SOB     R2,HH3
14625  064742  020405                          CMP     R4,R5           ;FPS CORRECT?
14626  064744  001401                          BEQ     HH7
14627  064746  104000                          EMT                     ;
14628
14629                                          ;THIS IS A TEST OF THE ABILITY
14630                                          ;OF NORMALIZE TO PRODUCE A ZERO EXP. AND
14631                                          ;OF THE R\T ALGORITHM TO PROPERLY SET THE FPS
14632
14633  064750  012704  043200          HH7:    MOV     #043200,R4              ;SET FIU,FIV,AND FD
14634                                                                          ;FID
14635  064754  170104                          LDFPS   R4
14636  064756  012700  065350                  MOV     #HHP5,R0                ;SET AC0 OPERAND
14637  064762  172410                          LDD     (R0),AC0
14638  064764  012700  065360                  MOV     #HHP6,R0                ;FSPC
14639  064770  172010                  HH8:    ADDD    (R0),AC0                ;TEST INSTRUCTION
14640  064772  170205                          STFPS   R5                      ;GET FPS
14641  064774  012700  065270                  MOV     #HHDAT0,R0              ;GET THE RESULT
14642  065000  174010                          STD     AC0,(R0)
14643  065002  012701  065340                  MOV     #HHP4,R1                ;IS IT CORRECT
14644  065006  012702  000004                  MOV     #4,R2
14645  065012  022021                  HH9:    CMP     (R0)+,(R1)+
14646  065014  001401                          BEQ     HH10
14647  065016  104000                          EMT                     ;
14648  065020  077204                  HH10:   SOB     R2,HH9
14649  065022  052704  100004                  BIS     #100004,R4
14650  065026  020405                          CMP     R4,R5
14651  065030  001401                          BEQ     HH11
14652  065032  104000                          EMT                     ;
14653
14654                                          ;THIS IS A TEST OF THE R\T ALGORITHN'S
14655                                          ;ABILITY TO SET BOTH N AND Z ON A - 0 RESULT
14656  065034  012704  043200          HH11:   MOV     #043200,R4              ;SET FIV. FIV. AND FD
14657
14658  065040  170104                          LDFPS   R4
14659  065042  012700  065400                  MOV     #HHP8,R0                ;SET AC0 OPERAND
14660  065046  172410                          LDD     (R0),AC0
14661  065050  012700  065410                  MOV     #HHP9,R0                ;FSPC
```

```
14662  065054  172010                 HH12:   ADDD    (R0),AC0                ;TEST INSTRUCTION
14663  065056  170205                         STFPS   R5                      ;GET FPS
14664  065060  012700  065270                 MOV     #HHDAT0,R0              ;GET THE RESULT
14665  065064  174010                         STD     AC0,(R0)
14666  065066  012701  065370                 MOV     #HHP7,R1                ;IS IT CORRECT
14667  065072  012702  000004                 MOV     #4,R2
14668  065076  022021                 HH13:   CMP     (R0)+,(R1)+
14669  065100  001401                         BEQ     HH16
14670  065102  104000                         EMT                     ;
14671  065104  077204                 HH16:   SOB     R2,HH13
14672  065106  052704  100014                 BIS     #100014,R4              ;FPS CORRECT?
14673  065112  020405                         CMP     R4,R5
14674  065114  001401                         BEQ     HH17
14675  065116  104000                         EMT                     ;
14676                                  ;TEST THAT CC ARE CLEARED BY R\T
14677  065120  012704  000200         HH17:   MOV     #00200,R4               ;SET FIV, FIV, AND FD
14678  065124  170104                         LDFPS   R4
14679  065126  012700  065400                 MOV     #HHP8,R0                ;SET AC0 OPEPAND
14680  065132  172410                         LDD     (R0),AC0
14681  065134  012700  065400                 MOV     #HHP8,R0                ;FSPC
14682  065140  172010                 HH18:   ADDD    (R0),AC0                ;TEST INSTRUCTION
14683  065142  170205                         STFPS   R5                      ;GET FPS
14684  065144  012700  065270                 MOV     #HHDAT0,R0              ;GET THE RESULT
14685  065150  174010                         STD     AC0,(R0)
14686  065152  012701  065420                 MOV     #HHP10,R1               ;IS IT CORRECT
14687  065156  012702  000004                 MOV     #4,R2
14688  065162  022021                 HH19:   CMP     (R0)+,(R1)+
14689  065164  001401                         BEQ     HH20
14690  065166  104000                         EMT                     ;
14691  065170  077204                 HH20:   SOB     R2,HH19
14692  065172  052704  000000                 BIS     #00000,R4               ;FPS CORRECT?
14693  065176  020405                         CMP     R4,R5
14694  065200  001401                         BEQ     HH21
14695  065202  104000                         EMT                     ;
14696                                  ;TEST THAT N IS SET BY R\T
14697  065204  012704  003200         HH21:   MOV     #3200,R4                ;SET FIV, FIV, AND FD
14698  065210  170104                         LDFPS   R4
14699  065212  012700  065350                 MOV     #HHP5,R0                ;SET AC0 OPERAND
14700  065216  172410                         LDD     (R0),AC0
14701  065220  012700  065350                 MOV     #HHP5,R0                ;FSPC
14702  065224  172010                 HH22:   ADDD    (R0),AC0                ;TEST INSTRUCTION
14703  065226  170205                         STFPS   R5                      ;GET FPS
14704  065230  012700  065270                 MOV     #HHDAT0,R0              ;GET THE RESULT
14705  065234  174010                         STD     AC0,(R0)
14706  065236  012701  065430                 MOV     #HHP11,R1               ;IS IT CORRECT
14707  065242  012702  000004                 MOV     #4,R2
14708  065246  022021                 HH23:   CMP     (R0)+,(R1)+
14709  065250  001401                         BEQ     HH24
14710  065252  104000                         EMT                     ;
14711  065254  077204                 HH24:   SOB     R2,HH23
14712  065256  052704  000010                 BIS     #10,R4
14713  065262  020405                         CMP     R4,R5                   ;FPS CORRECT?
14714  065264  001465                         BEQ     HHDONE
14715  065266  104000                         EMT                     ;
14716  065270  000000                 HHDAT0: 0
14717  065272  000000                         0
```

```
14718  065274  000000                          0
14719  065276  000000                          0
14720  065300  000452          HHP0:   452
14721  065302  125252                  125252
14722  065304  125252                  125252
14723  065306  125253                  125253
14724  065310  000252          HHP1:   252
14725  065312  125252                  125252
14726  065314  125252                  125252
14727  065316  125252                  125252
14728  065320  000600          HHP2:   600                     ;HHP0 + HHP1 WITH
14729  065322  000000                  0                       ;PROPER NORMALIZATION
14730  065324  000000                  0
14731  065326  000000                  0
14732  065330  000400          HHP3:   400                     ;HHP0 + HHP1 WITH
14733  065332  000000                  0                       ;BAD NORMALIZATION
14734  065334  000000                  0
14735  065336  000000                  0
14736  065340  000000          HHP4:   0
14737  065342  000000                  0
14738  065344  000000                  0
14739  065346  000000                  0
14740  065350  100200          HHP5:   100200
14741  065352  000000                  0
14742  065354  000000                  0
14743  065356  000000                  0
14744  065360  000300          HHP6:   300
14745  065362  000000                  0
14746  065364  000000                  0
14747  065366  000000                  0
14748  065370  100000          HHP7:   100000                  ;HHP7 = HHP8 + HHP9
14749  065372  000000                  0                       ;     = HHP5 + HHP6
14750  065374  000000                  0
14751  065376  000000                  0
14752  065400  000200          HHP8:   200
14753  065402  000000                  0
14754  065404  000000                  0
14755  065406  000000                  0
14756  065410  100300          HHP9:   100300
14757  065412  000000                  0
14758  065414  000000                  0
14759  065416  000000                  0
14760  065420  000400          HHP10:  400                     ;HHP10 = HHP8 + HHP8
14761  065422  000000                  0
14762  065424  000000                  0
14763  065426  000000                  0
14764  065430  100400          HHP11:  100400                  ;HHP11 = HHP5 + HHP5
14765  065432  000000                  0
14766  065434  000000                  0
14767  065436  000000                  0
14768  065440                  HHDONE:
14769  065440  004767  033030          JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
14770                                                          ;SEE IF THE USER HAS EXPRESSED
14771                                                          ;THE DESIRE TO CHANGE THE SOFTWARE
14772                                                          ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
14773                                                          ;THE USER TYPED CONTROL G?).
```

```
14774
14775
14776                                   ;*****************************************************************************************
14777                                   ;TEST 457       OVER\UNDER TEST
14778                                   ;*****************************************************************************************
14779  065444                           TS457:
14780
14781                                   ;TEST OVERFLOW CONDITION WITH TRAP DISABLER FIV=0
14782  065444  012704  000200                  MOV     #200,R4         ;CLEAR FIU, FIV, AND SET FD
14783  065450  170104                          LDFPS   R4
14784  065452  012737  065570  000244         MOV     #GGER0,@#FPVECT
14785  065460  012700  066372                  MOV     #GGP5,R0        ;SET AC0 OPERAND
14786  065464  172410                          LDD     (R0),AC0
14787  065466  012700  066372                  MOV     #GGP5,R0        ;FSRC
14788  065472  172010                  GG2:    ADDD    (R0),AC0        ;TEST INSTRUCTION
14789  065474  170205                          STFPS   R5              ;GET FPS
14790  065476  012700  066322                  MOV     #GGDAT0,R0      ;GET THE RESULT
14791  065502  174010                          STD     AC0,(R0)
14792  065504  012701  066402                  MOV     #GGP6,R1        ;IS IT CORRECT
14793  065510  012702  000004                  MOV     #4,R2
14794  065514  022021                  GG3:    CMP     (R0)+,(R1)+
14795  065516  001401                          BEQ     GG4
14796  065520  104000                          EMT                     ;
14797  065522  077204                  GG4:    SOB     R2,GG3
14798  065524  052704  000006                  BIS     #6,R4           ;FPS CORRECT?
14799  065530  020405                          CMP     R4,R5
14800  065532  001401                          BEQ     GG5
14801  065534  104000                          EMT                     ;
14802                                   ;TEST OVERFLOW WITH TRAPS ENABLED
14803                                   ;FIV = 1
14804  065536  012704  001200          GG5:    MOV     #1200,R4        ;CLEAR FIU, SET FIV, AND FD
14805  065542  170104                          LDFPS   R4
14806  065544  012737  065572  000244         MOV     #GG7,@#FPVECT
14807  065552  012700  066372                  MOV     #GGP5,R0        ;SET AC0 OPERAND
14808  065556  172410                          LDD     (R0),AC0
14809  065560  012700  066372                  MOV     #GGP5,R0        ;FSPC
14810  065564  172010                  GG6:    ADDD    (R0),AC0        ;TEST INSTRUCTION
14811  065566  170000                          CFCC                    ;NO OVERFLOW TRAP OCCURED
14812  065570                           GGER0:
14813  065570  104000                          EMT                     ;
14814  065572  012703  065566          GG7:    MOV     #GG6+2,R3
14815  065576  020316                          CMP     R3,(SP)         ;CHECK STACK DATA
14816  065600  001401                          BEQ     1$
14817  065602  104000                          EMT                     ;
14818  065604  022626                  1$:     CMP     (SP)+,(SP)+
14819  065606  170205                          STFPS   R5
14820  065610  012700  066322                  MOV     #GGDAT0,R0      ;GET THE RESULT
14821  065614  174010                          STD     AC0,(R0)
14822  065616  012701  066402                  MOV     #GGP6,R1        ;IS IT CORRECT
14823  065622  012702  000004                  MOV     #4,R2
14824  065626  022021                  GG8:    CMP     (R0)+,(R1)+
14825  065630  001401                          BEQ     GG9
14826  065632  104000                          EMT                     ;
14827  065634  077204                  GG9:    SOB     R2,GG8
14828  065636  052704  100006                  BIS     #100006,R4      ;EXACT ZERO RESULTED IF OVERFLOW
14829  065642  020405                          CMP     R4,R5           ;FPS CORRECT?, CHECK FER, FZ, FV
```

```
14830  065644  001401                        BEQ     1$
14831  065646  104000                        EMT                             ;
14832  065650  012704  000010        1$:     MOV     #10,R4
14833                                ;CHECK FEC
14834  065654  170305                        STST    R5
14835  065656  020405                        CMP     R4,R5
14836  065660  001401                        BEQ     GG10
14837  065662  104000                        EMT                             ;
14838                                ;CHECK UNDER FLOW CONDITION WITH
14839                                ;TRAPS DISABLED (FIU = 0)
14840  065664  012704  000200        GG10:   MOV     #0200,R4        ;SET FIU, FIV, AND FD
14841  065670  170104                        LDFPS   R4
14842  065672  012737  065570  000244        MOV     #GGER0,@#FPVECT
14843  065700  012700  066342                MOV     #GGP2,R0        ;SET AC0 OPERAND
14844  065704  172410                        LDD     (R0),AC0        ;FSRC
14845  065706  012700  066352                MOV     #GGP3,R0
14846  065712  172010                GG11:   ADDD    (R0),AC0        ;TEST INSTRUCTION
14847  065714  170205                        STFPS   R5              ;GET FPS
14848  065716  012700  066322                MOV     #GGDAT0,R0      ;GET THE RESULT
14849  065722  174010                        STD     AC0,(R0)
14850  065724  012701  066402                MOV     #GGP6,R1        ;IS IT CORRECT
14851  065730  012702  000004                MOV     #4,R2
14852  065734  022021                GG12:   CMP     (R0)+,(R1)+
14853  065736  001401                        BEQ     GG13
14854  065740  104000                        EMT                             ;
14855  065742  077204                GG13:   SOB     R2,GG12
14856  065744  052704  000004                BIS     #4,R4           ;FPS CORRECT?
14857  065750  020405                        CMP     R4,R5
14858  065752  001401                        BEQ     GG14
14859  065754  104000                        EMT                             ;
14860                                ;CHECK UNDERFLOW CONDITION WITH
14861                                ;TRAP ENABLED (FIU = 1)
14862  065756  012704  002200        GG14:   MOV     #2200,R4        ;SET FIU, FIV, AND FD
14863  065762  170104                        LDFPS   R4
14864  065764  012737  066010  000244        MOV     #GG16,@#FPVECT
14865  065772  012700  066342                MOV     #GGP2,R0        ;SET AC0 OPERAND
14866  065776  172410                        LDD     (R0),AC0        ;FSPC
14867  066000  012700  066352                MOV     #GGP3,R0
14868  066004  172010                GG15:   ADDD    (R0),AC0        ;TEST INSTRUCTION
14869  066006  170000                        CFCC
14870  066010  012703  066006        GG16:   MOV     #GG15+2,R3
14871  066014  021603                        CMP     (SP),R3
14872  066016  001401                        BEQ     1$
14873  066020  104000                        EMT                             ;
14874  066022  022626                1$:     CMP     (SP)+,(SP)+
14875  066024  170205                        STFPS   R5              ;GET FPS
14876  066026  012700  066322                MOV     #GGDAT0,R0      ;GET THE RESULT
14877  066032  174010                        STD     AC0,(R0)
14878  066034  012701  066412                MOV     #GGP7,R1        ;IS IT CORRECT
14879  066040  012702  000004                MOV     #4,R2
14880  066044  022021                GG17:   CMP     (R0)+,(R1)+
14881  066046  001401                        BEQ     GG18
14882  066050  104000                        EMT                             ;
14883  066052  077204                GG18:   SOB     R2,GG17
14884  066054  052704  100000                BIS     #100000,R4
14885  066060  020405                        CMP     R4,R5           ;FPS CORRECT?
```

```
14886  066062  001401                        BEQ     1$
14887  066064  104000                        EMT                             ;
14888  066066  012704  000012        1$:     MOV     #12,R4
14889                                ;CHECK FEC
14890  066072  170305                        STST    R5
14891  066074  020405                        CMP     R4,R5
14892  066076  001401                        BEQ     GG19
14893  066100  104000                        EMT                             ;
14894                                ;CHECK UNDERFLOW CONDITION WITH TRAPS
14895                                ;DISABLED (FIU = 0)
14896  066102  012704  000200        GG19:   MOV     #0200,R4        ;SET FIU, FIV, AND FD
14897  066106  170104                        LDFPS   R4
14898  066110  012737  066226  000244        MOV     #GGER14,@#FPVECT
14899  066116  012700  066342                MOV     #GGP2,R0        ;SET AC0 OPERAND
14900  066122  172410                        LDD     (R0),AC0
14901  066124  012700  066422                MOV     #GGP8,R0        ;FSPC
14902  066130  172010        GG20:   ADDD    (R0),AC0        ;TEST INSTRUCTION
14903  066132  170205                        STFPS   R5              ;GET FPS
14904  066134  012700  066322                MOV     #GGDAT0,R0      ;GET THE RESULT
14905  066140  174010                        STD     AC0,(R0)
14906  066142  012701  066402                MOV     #GGP6,R1        ;IS IT CORRECT
14907  066146  012702  000004                MOV     #4,R2
14908  066152  022021        GG21:   CMP     (R0)+,(R1)+
14909  066154  001401                        BEQ     GG22
14910  066156  104000                        EMT                             ;
14911  066160  077204        GG22:   SOB     R2,GG21
14912  066162  052704  000004                BIS     #4,R4           ;FPS CORRECT?
14913  066166  020405                        CMP     R4,R5
14914  066170  001401                        BEQ     GG23
14915  066172  104000                        EMT                             ;
14916                                ;CHECK UNDERFLOW CONDITION WITH TRAP
14917                                ;ENABLED (FIU = 1)
14918  066174  012704  002200        GG23:   MOV     #2200,R4        ;SET FIU, FIV, AND FD
14919  066200  170104                        LDFPS   R4
14920  066202  012737  066230  000244        MOV     #GG25,@#FPVECT
14921  066210  012700  066342                MOV     #GGP2,R0        ;SET AC0 OPERAND
14922  066214  172410                        LDD     (R0),AC0
14923  066216  012700  066422                MOV     #GGP8,R0        ;FSRC
14924  066222  172010        GG24:   ADDD    (R0),AC0        ;TEST INSTRUCTION
14925  066224  170000                        CFCC
14926  066226                GGER14:
14927  066226  104000                        EMT                             ;
14928  066230  012703  066224        GG25:   MOV     #GG24+2,R3
14929  066234  020316                        CMP     R3,(SP)
14930  066236  001401                        BEQ     1$
14931  066240  104000                        EMT                             ;
14932  066242  022626        1$:     CMP     (SP)+,(SP)+
14933  066244  170205                        STFPS   R5              ;GET FPS
14934  066246  012700  066322                MOV     #GGDAT0,R0      ;GET THE RESULT
14935  066252  174010                        STD     AC0,(R0)
14936  066254  012701  066432                MOV     #GGP9,R1        ;IS IT CORRECT
14937  066260  012702  000004                MOV     #4,R2
14938  066264  022021        GG26:   CMP     (R0)+,(R1)+
14939  066266  001401                        BEQ     GG27
14940  066270  104000                        EMT                             ;
14941  066272  077204        GG27:   SOB     R2,GG26
```

```
14942  066274  052704  100004          BIS     #100004,R4
14943  066300  020405                  CMP     R4,R5           ;FPS CORRECT?
14944  066302  001401                  BEQ     1$
14945  066304  104000                  EMT                     ;
14946  066306  012704  000012  1$:     MOV     #12,R4
14947                                  ;CHECK FEC
14948  066312  170305                  STST    R5
14949  066314  020405                  CMP     R4,R5
14950  066316  001451                  BEQ     GGDONE
14951  066320  104000                  EMT                     ;
14952  066322  000000          GGDATO: 0
14953  066324  000000                  0
14954  066326  000000                  0
14955  066330  000000                  0
14956
14957  066332  000300          GGP1:   300
14958  066334  000000                  0
14959  066336  000000                  0
14960  066340  000000                  0
14961  066342  100200          GGP2:   100200
14962  066344  000000                  0
14963  066346  000000                  0
14964  066350  000000                  0
14965  066352  000200          GGP3:   200
14966  066354  000000                  0
14967  066356  000000                  0
14968  066360  000001                  1
14969  066362  010200          GGP4:   10200
14970  066364  000000                  0
14971  066366  000000                  0
14972  066370  000000                  0
14973  066372  077600          GGP5:   77600                   ;OVER FLOW = GGP5 + GGP5
14974  066374  000000                  0
14975  066376  000000                  0
14976  066400  000000                  0
14977  066402  000000          GGP6:   0                       ;OVERFLOW RESULT
14978  066404  000000                  0                       ;UNDERFLOW RESULT
14979  066406  000000                  0                       ;GGP6 = GGP4 + GGP5
14980  066410  000000                  0                       ;     = GGP3 + GGP2 (FIU = 0)
14981                                                          ;     = GGP3 + GGP1
14982  066412  062400          GGP7:   62400                   ;GGP7 = GGP3 + GGP2 (FIU = 1)
14983  066414  000000                  0
14984  066416  000000                  0
14985  066420  000000                  0
14986  066422  000340          GGP8:   340
14987  066424  000000                  0
14988  066426  000000                  0
14989  066430  000000                  0
14990  066432  000100          GGP9:   100
14991  066434  000000                  0
14992  066436  000000                  0
14993  066440  000000                  0
14994  066442          GGDONE:
14995  066442  004767  032026          JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
14996                                                          ;SEE IF THE USER HAS EXPRESSED
14997                                                          ;THE DESIRE TO CHANGE THE SOFTWARE
```

```
                                        ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
                                        ;THE USER TYPED CONTROL G?).


                        ;*****************************************************************************
                        ;TEST 460       LDCFD AND LDCDF TEST
                        ;*****************************************************************************
066446                  TS460:
                        ;TEST FOR CORRECT AUTO INCREMENT CONSTANT.
066446  012704  000200          MOV     #200,R4         ;SET LONG INTEGER MODE
066452  170104                  LDFPS   R4
066454  012700  067204          MOV     #HXP1,R0
066460  172410                  LDD     (R0),AC0
066462  012700  067214          MOV     #HXP2,R0
066466  177420          HX2:    LDCFD   (R0)+,AC0
066470  020027  067220          CMP     R0,#HXP2+4      ;IS R0 CORRECT
066474  001401                  BEQ     HX3
066476  104000                  EMT                     ;
066500                  HX3:
066500  170205                  STFPS   R5              ;GET FPS
066502  012700  067174          MOV     #HXDATO,R0
066506  174010                  STD     AC0,(R0)        ;GET AC0
066510  012701  067264          MOV     #HXP7,R1        ;SEE IF RESULT IS
066514  012702  000004          MOV     #4,R2           ;CORRECT
066520  022120          HX4:    CMP     (R1)+,(R0)+
066522  001401                  BEQ     HX7
066524  104000                  EMT                     ;
066526  077204          HX7:    SOB     R2,HX4
066530  012704  000200          MOV     #200,R4         ;FPS CORRECT?
066534  020405                  CMP     R4,R5
066536  001401                  BEQ     HX8
066540  104000                  EMT                     ;
                        ;NOW    TEST    LDCDF
066542  012704  000200  HX8:    MOV #200,R4
066546  170104                  LDFPS R4

066550  012700  067204          MOV     #HXP1,R0
066554  172410                  LDD     (R0),AC0

066556  012700  067214          MOV     #HXP2,R0
066562  170001                  SETF
066564  177420          HX9:    LDCDF   (R0)+,AC0       ;TEST INSTRUCTION
066566  020027  067224          CMP     R0,#HXP2+10     ;WAS A GOOD
066572  001401                  BEQ     HX10
066574  104000                  EMT                     ;

066576                  HX10:
066576  170205                  STFPS   R5
066600  012700  067174          MOV     #HXDATO,R0
066604  170011                  SETD
066606  174010                  STD     AC0,(R0)        ;GET RESULT
066610  012701  067274          MOV     #HXP8,R1
066614  012702  000004          MOV     #4,R2
066620  022120          HX11:   CMP     (R1)+,(R0)+     ;IS IT CORRECT?
066622  001401                  BEQ     HX14
066624  104000                  EMT                     ;
```

```
CJKDE-B  11/24 CPU CLUSTER DIAG.        MACY11 30(1046)  05-AUG-82  15:03  PAGE 278
CJKDEB.P11    05-AUG-82 15:01           T460    LDCFD AND LDCDF TEST

 15054  066626  077204                  HX14:   SOB     R2,HX11
 15055
 15056  066630  012704  000000                  MOV     #0,R4           ;FPS CORRECT?
 15057  066634  020405                          CMP     R4,R5
 15058  066636  001401                          BEQ     HX15
 15059  066640  104000                          EMT                     ;
 15060                                  ;TEST GR7 IMMEDIATE MODE CONSTANT
 15061  066642  012704  000200          HX15:   MOV     #200,R4
 15062  066646  170104                          LDFPS   R4              ;SET FD
 15063  066650  012737  066700  000004          MOV     #HXER9,@#ERRVECT
 15064  066656  005001                          CLR     R1
 15065  066660  177427  043243          HX16:   LDCFD   #5201,AC0
 15066  066664  005201                  HX165:  INC     R1
 15067  066666  005201                          INC     R1
 15068  066670  005201                          INC     R1
 15069  066672  020127  000003                  CMP     R1,#3           ;SEE IF PC WAS
 15070  066676  001401                          BEQ     HX17
 15071  066700                          HXER9:
 15072  066700  104000                          EMT                     ;
 15073  066702  012704  000200          HX17:   MOV     #200,R4
 15074  066706  170104                          LDFPS   R4
 15075  066710  012700  067254                  MOV     #HXP6,R0
 15076  066714  172410                          LDD     (R0),AC0
 15077  066716  012700  067214                  MOV     #HXP2,R0
 15078  066722  177410          HX18:   LDCFD   (R0),AC0
 15079
 15080  066724  012700  067174                  MOV     #HXDAT0,R0
 15081  066730  174010                          STD     AC0,(R0)        ;GET RESULT.
 15082  066732  012701  067264                  MOV     #HXP7,R1
 15083  066736  012702  000004                  MOV     #4,R2
 15084  066742  022021          HX19:   CMP     (R0)+,(R1)+     ;IS RESULT CORRECT?
 15085  066744  001401                          BEQ     HX20
 15086  066746  104000                          EMT                     ;
 15087  066750  077204          HX20:   SOB     R2,HX19
 15088
 15089                                  ;TEST LDCFD WITH NEGATIVE OPERAND
 15090  066752  012704  000200                  MOV     #200,R4
 15091  066756  170104                          LDFPS   R4
 15092  066760  012700  067254                  MOV     #HXP6,R0
 15093  066764  172410                          LDD     (R0),AC0
 15094  066766  012700  067234                  MOV     #HXP4,R0
 15095  066772  177410          HX22:   LDCFD   (R0),AC0
 15096
 15097  066774  012700  067174                  MOV     #HXDAT0,R0
 15098  067000  174010                          STD     AC0,(R0)        ;GET RESULT
 15099
 15100  067002  012701  067244                  MOV     #HXP5,R1
 15101  067006  012702  000004                  MOV     #4,R2
 15102  067012  022120          HX23:   CMP     (R1)+,(R0)+
 15103  067014  001401                          BEQ     HX26
 15104  067016  104000                          EMT                     ;
 15105  067020  077204          HX26:   SOB     R2,HX23
 15106
 15107                           ;TEST  LDCFD    0
 15108
 15109  067022  012704  000200                  MOV     #200,R4
```

```
CJKDE-B  11/24 CPU CLUSTER DIAG.
CJKDEB.P11    05-AUG-82 15:01

MACY11 30(1046)  05-AUG-82  15:03  PAGE 279
T460    LDCFD AND LDCDF TEST

 15110  067026  170104                        LDFPS   R4
 15111
 15112  067030  012700  067204                MOV     #HXP1,R0
 15113  067034  172410                        LDD     (R0),AC0
 15114  067036  172010                        ADDD    (R0),AC0
 15115
 15116  067040  012700  067204                MOV     #HXP1,R0
 15117  067044  177410              HX28:     LDCFD   (R0),AC0
 15118
 15119  067046  170205                        STFPS   R5
 15120
 15121  067050  012700  067174                MOV     #HXDATO,R0
 15122  067054  174010                        STD     AC0,(R0)        ;GET RESULT
 15123
 15124  067056  012701  067204                MOV     #HXP1,R1
 15125  067062  012702  000004                MOV     #4,R2
 15126  067066  022120              HX29:     CMP     (R1)+,(R0)+     ;IS IT 0?
 15127  067070  001401                        BEQ     HX30
 15128  067072  104000                        EMT                     ;
 15129  067074  077204              HX30:     SOB     R2,HX29
 15130
 15131  067076  012704  000204                MOV     #204,R4         ;FPS CORRECT
 15132  067102  020405                        CMP     R4,R5
 15133  067104  001401                        BEQ     HX31
 15134  067106  104000                        EMT                     ;
 15135                       ;TEST   LDCFD   0
 15136  067110  012704  000200      HX31:     MOV     #200,R4
 15137  067114  170104                        LDFPS   R4
 15138  067116  012700  067254                MOV     #HXP6,R0
 15139  067122  172410                        LDD     (R0),AC0
 15140  067124  012700  067204                MOV     #HXP1,R0
 15141  067130  177410              HX32:     LDCFD   (R0),AC0
 15142  067132  170205                        STFPS   R5
 15143  067134  012700  067174                MOV     #HXDATO,R0
 15144  067140  174010                        STD     AC0,(R0)        ;GET RESULT
 15145  067142  012701  067204                MOV     #HXP1,R1
 15146  067146  012702  000004                MOV     #4,R2
 15147  067152  022120              HX33:     CMP     (R1)+,(R0)+     ;IS IT ZERO?
 15148  067154  001401                        BEQ     HX34
 15149  067156  104000                        EMT                     ;
 15150  067160  077204              HX34:     SOB     R2,HX33
 15151
 15152  067162  012704  000204                MOV     #204,R4         ;FPS CORRECT?
 15153  067166  020405                        CMP     R4,R5
 15154  067170  001445                        BEQ     HXDONE
 15155  067172  104000                        EMT                     ;
 15156
 15157  067174  000000              HXDATO:   0
 15158  067176  000000                        0
 15159  067200  000000                        0
 15160  067202  000000                        0
 15161
 15162  067204  000000              HXP1:     0
 15163  067206  000000                        0
 15164  067210  000000                        0
 15165  067212  000000                        0
```

```
15166
15167  067214  000577                  HXP2:   577
15168  067216  177776                          177776
15169  067220  177777                          177777
15170  067222  177776                          177776
15171  067224  005201                  HXP3:   5201
15172  067226  000000                          0
15173  067230  000000                          0
15174  067232  000000                          0
15175  067234  100577                  HXP4:   100577
15176  067236  177776                          177776
15177  067240  177777                          177777
15178  067242  177776                          177776
15179  067244  100577                  HXP5:   100577
15180  067246  177776                          177776
15181  067250  000000                          0
15182  067252  000000                          0
15183  067254  000252                  HXP6:   252
15184  067256  125252                          125252
15185  067260  125252                          125252
15186  067262  125252                          125252
15187
15188  067264  000577                  HXP7:   577
15189  067266  177776                          177776
15190  067270  000000                          0
15191  067272  000000                          0
15192  067274  000577                  HXP8:   577
15193  067276  177777                          177777
15194  067300  000000                          0
15195  067302  000000                          0
15196
15197  067304                          HXDONE:
15198  067304  004767  031164                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
15199                                                                  ;SEE IF THE USER HAS EXPRESSED
15200                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
15201                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
15202                                                                  ;THE USER TYPED CONTROL G?).
15203
15204
15205
15206
15207                                   ;*****************************************************************************************
15208                                   ;TEST 461       CMPD TEST
15209                                   ;*****************************************************************************************
15210  067310                          TS461:
15211
15212                                   ;TEST THE CMPD INSTRUCTION WITH (FSRC=AC=0)
15213  067310  004737  070004          AAA1:   JSR     PC,@#CMPSUB
15214  067314  000000  000000  000000  1$:     .WORD   0,0,0,0                 ;AC0
15215  067322  000000
15216  067324  000000  000000  000000  2$:     .WORD   0,0,0,0                 ;FSRC
15217  067332  000000
15218  067334  000200                  3$:     200                             ;FPS BEFORE EXECUTION
15219  067336  000204                          204                             ;FPS AFTER EXECUTION
15220
15221
```

```
15222                                   ;TEST CMPD WITH (AC=0) AND FSRC POSITIVE.
15223  067340  004737  070004           AAA2:   JSR     PC,@#CMPSUB
15224  067344  000000  000000  000000   1$:     .WORD   0,0,0,0                 ;AC
15225  067352  000000
15226  067354  025252                   2$:     25252                           ;FSRC
15227  067356  052525                           52525
15228  067360  125252                           125252
15229  067362  052525                           52525
15230  067364  000200                   3$:     200                             ;FPS BEFORE EXECUTION
15231  067366  000200                           200                             ;FPS AFTER EXECUTION
15232
15233                                   ;TEST CMPD WITH (AC=0) AND FSRC NEGATIVE
15234  067370  004737  070004           AAA3:   JSR     PC,@#CMPSUB
15235  067374  000000  000000  000000   1$:     .WORD   0,0,0,0                 ;AC
15236  067402  000000
15237  067404  125252                   2$:     125252                          ;FSRC
15238  067406  125252                           125252
15239  067410  052525                           52525
15240  067412  125252                           125252
15241  067414  000200                   3$:     200                             ;FPS BEFORE EXECUTION
15242  067416  000210                           210                             ;FPS AFTER EXECUTION
15243
15244                                   ;TEST CMPD WITH (FSRC=0) AND AC POSITIVE
15245  067420  004737  070004           AAA4:   JSR     PC,@#CMPSUB
15246  067424  025252                   1$:     25252                           ;AC
15247  067426  052525                           52525
15248  067430  125252                           125252
15249  067432  052525                           52525
15250  067434  000000  000000  000000   2$:     .WORD   0,0,0,0                 ;FSRC
15251  067442  000000
15252  067444  000200                   3$:     200                             ;FPS BEFORE EXECUTION
15253  067446  000210                           210                             ;FPS AFTER EXECUTION
15254
15255
15256                                   ;TEST CMPD WITH (FSRC=0) AND AC NEGATIVE
15257  067450  004737  070004           AAA5:   JSR     PC,@#CMPSUB
15258  067454  125252                   1$:     125252                          ;AC
15259  067456  125252                           125252
15260  067460  052525                           52525
15261  067462  125252                           125252
15262  067464  000000  000000  000000   2$:     .WORD   0,0,0,0                 ;FSRC
15263  067472  000000
15264  067474  000200                   3$:     200                             ;FPS BEFORE EXECUTION
15265  067476  000200                           200                             ;FPS AFTER EXECUTION
15266
15267                                   ;TEST CMPD WITH AC POSITIVE AND FSRC NEGATIVE
15268  067500  004737  070004           AAA6:   JSR     PC,@#CMPSUB
15269  067504  052525                   1$:     52525                           ;AC.
15270  067506  125252                           125252
15271  067510  052525                           52525
15272  067512  125252                           125252
15273  067514  125252                   2$:     125252                          ;;FSRC
15274  067516  052525                           52525
15275  067520  125252                           125252
15276  067522  052525                           52525
15277  067524  000200                   3$:     200                             ;FPS BEFORE EXECUTION
```

```
15278  067526  000210                          210                                     ;FPS AFTER EXECUTION
15279
15280
15281                                          ;TEST CMPD WITH AC NEGATIVE AND FSRC POSITIVE
15282  067530  004737  070004                  AAA7:   JSR     PC,@#CMPSUB
15283  067534  125252                          1$:     125252                          ;AC
15284  067536  052525                                  52525
15285  067540  125252                                  125252
15286  067542  052525                                  52525
15287  067544  052525                          2$:     52525                           ;FSRC
15288  067546  125252                                  125252
15289  067550  052525                                  52525
15290  067552  125252                                  125252
15291  067554  000200                          3$:     200                             ;FPS BEFORE EXECUTION
15292  067556  000200                                  200                             ;FPS AFTER EXECUTION
15293
15294                                          ;TEST CMPD WITH AC POSITIVE AND FSRC POSITIVE
15295                                          ;AND EAC LESS THAN EFSRC.
15296  067560  004737  070004                  AAA8:   JSR     PC,@#CMPSUB
15297  067564  012345                          1$:     12345                           ;AC
15298  067566  067654                                  67654
15299  067570  032101                                  32101
15300  067572  023456                                  23456
15301  067574  023456                          2$:     23456                           ;FSRC
15302  067576  076543                                  76543
15303  067600  021012                                  21012
15304  067602  034567                                  34567
15305  067604  000200                          3$:     200                             ;FPS BEFORE EXECUTION
15306  067606  000200                                  200                             ;FPS AFTER EXECUTION
15307
15308
15309                                          ;TEST CMPD WITH AC POSITIVE, FSRC POSITIVE AND EAC GREATER THAN EFSRC
15310  067610  004737  070004                  AAA9:   JSR     PC,@#CMPSUB
15311  067614  045676                          1$:     45676                           ;AC
15312  067616  054321                                  54321
15313  067620  012345                                  12345
15314  067622  067654                                  67654
15315  067624  034567                          2$:     34567                           ;FSRC
15316  067626  065432                                  65432
15317  067630  101234                                  101234
15318  067632  056765                                  56765
15319  067634  000200                          3$:     200                             ;FPS BEFORE EXECUTION
15320  067636  000210                                  210                             ;FPS AFTER EXECUTION
15321
15322                                          ;TEST CMPD WITH AC POSITIVE, FSRC POSITIVE AND AC EQUAL TO FSRC
15323  067640  004737  070004                  AAA10:  JSR     PC,@#CMPSUB
15324  067644  012345                          1$:     12345                           ;AC
15325  067646  067012                                  67012
15326  067650  034567                                  34567
15327  067652  012345                                  012345
15328  067654  012345                          2$:     12345                           ;FSRC
15329  067656  067012                                  67012
15330  067660  034567                                  34567
15331  067662  012345                                  012345
15332  067664  000200                          3$:     200                             ;FPS BEFORE EXECUTION
15333  067666  000204                                  204                             ;FPS AFTER EXECUTION
```

```
15334
15335                                   ;TEST CMPD WITH AC POSITIVE, FSRC POSITIVE, EAC EQUAL TO EFSRC,
15336                                   ;AND FSRC GREATER THAN AC.
15337  067670  004737  070004          AAA11:  JSR     PC,@#CMPSUB
15338  067674  012345                  1$:     12345                           ;AC
15339  067676  067012                          67012
15340  067700  034567                          34567
15341  067702  012345                          012345
15342  067704  012345                  2$:     12345                           ;FSRC
15343  067706  070123                          70123
15344  067710  045670                          45670
15345  067712  123456                          123456
15346  067714  000200                  3$:     200                             ;FPS BEFORE EXECUTION
15347  067716  000200                          200                             ;FPS AFTER EXECUTION
15348
15349                                   ;TEST CMPD WITH AC POSITIVE, FSRC POSITIVE, EAC EQUAL TO EFSRC,
15350                                   ;AND AC GREATER THAN FSRC.
15351  067720  004737  070004          AAA12:  JSR     PC,@#CMPSUB
15352  067724  054321                  1$:     54321                           ;AC
15353  067726  076543                          76543
15354  067730  021076                          21076
15355  067732  054321                          54321
15356  067734  054321                  2$:     54321                           ;FSRC
15357  067736  065432                          65432
15358  067740  107654                          107654
15359  067742  032107                          32107
15360  067744  000200                  3$:     200                             ;FPS BEFORE EXECUTION
15361  067746  000210                          210                             ;FPS AFTER EXECUTION
15362
15363                                   ;TEST CMPD WITH AC NEGATIVE, FSRC NEGATIVE, EAC EQUAL TO EFSRC,
15364                                   ;AND AC GREATER THAN FSRC
15365  067750  004737  070004          AAA13:  JSR     PC,@#CMPSUB
15366  067754  112345                  1$:     112345                          ;AC
15367  067756  043210                          43210
15368  067760  076543                          76543
15369  067762  021076                          21076
15370  067764  112345                  2$:     112345                          ;FSRC
15371  067766  054321                          54321
15372  067770  007654                          07654
15373  067772  032107                          32107
15374  067774  000200                  3$:     200                             ;FPS BEFORE EXECUTION
15375  067776  000210                          210                             ;FPS AFTER EXECUTION
15376
15377
15378  070000  000137  070110                  JMP     @#AAADONE               ;FINISHED CMPD TEST.
15379
15380
15381                                   ;THIS SUBROUTINE, CMPSUB, IS CALLED TO SET UP, EXECUTE
15382                                   ;AND CHECK THE RESULTS OF A CMPD INSTRUCTION.
15383                                   ;IT IS CALLED THUS:
15384                                   ;
15385                                   ;               JSR     PC,@#CMPSUB
15386                                   ;       ACARG:  .WORD   X,X,X,X         ;AC OPERAND
15387                                   ;       FSRCARG:.WORD   X,X,X,X         ;FSRC OPERAND
15388                                   ;       FPSB:   .WORD   X               ;FPS BEFORE EXECUTION
15389                                   ;       FPSA:   .WORD   X               ;FPS AFTER EXECUTION
```

```
15390                                   ;       FPSE:   .WORD   X                       ;ERROR FPS
15391                                   ;       ERR:    ERROR   X                       ;FPS ERROR
15392                                   ;       CONT:                                   ;RETURN ADDRESS
15393                                   ;
15394                                   ;THE OPERANDS ARE SET UP (USING AC0 FOR THE AC OPERAND). THEN
15395                                   ;FPSB IS LOADED INTO THE FPS. THE INSTRUCTION, CMPD, IS EXECUTED.
15396                                   ;AFTER THE EXECUTION THE FPS IS CHECKED AGAINST FPSA. IF IT IS A MATCH
15397                                   ;THEN THERE WAS NO ERROR AND CONTROL IS RETURNED TO CONT. IF
15398                                   ;THE FPS IS INCORRECT IT IS COMPARED WITH FPSE IN AN ATTEMPT TO ANALYSE
15399                                   ;THE FAILURE. IF THE FPS IS THE SAME AS FPSE THEN CONTROL IS
15400                                   ;RETURNED TO THE ERROR CALL AT LOCATION ERR. IF THE FPS WAS
15401                                   ;NOT CORRECT BUT DIDN'T MATCH FPSE A GENERAL ERROR IS REPORTED
15402                                   ;AND CONTROL IS PASSED TO CONT.
15403
15404  070004  012601                  CMPSUB: MOV     (SP)+,R1                ;PICK UP A POINTER TO THE
15405                                                                           ;ARGUMENTS.
15406  070006  016100  000020                  MOV     20(R1),R0               ;GET THE FPS BEFORE EXECUTION.
15407  070012  170100                          LDFPS   R0                      ;LOAD IT INTO THE FPS.
15408
15409  070014  010100                          MOV     R1,R0                   ;GET ADDRESS OF AC OPERAND.
15410  070016  172410                          LDD     (R0),AC0                ;LOAD AC0 OPERAND
15411
15412  070020  010100                          MOV     R1,R0                   ;COMPUTE FSRC OPERAND
15413  070022  062700  000010                  ADD     #10,R0                  ;ADDRESS
15414
15415  070026  000240                          NOP                             ;FOR SCOPING.
15416  070030  173410                  1$:     CMPD    (R0),AC0                ;EXECUTE THE TEST INSTRUCTION.
15417
15418  070032  170205                          STFPS   R5                      ;SAVE FPS AFTER INSTRUCTION.
15419
15420  070034  016104  000022                  MOV     22(R1),R4               ;GET EXPECTED FPS.
15421  070040  020405                          CMP     R4,R5                   ;WAS FPS CORRECT?
15422  070042  020405                          CMP     R4,R5                   ;WAS FPS CORRECT?
15423  070044  001401                          BEQ     3$
15424  070046  104000                          EMT                     ;
15425  070050  012700  070100          3$:     MOV     #CMPTMP,R0              ;IF FPS WAS CORRECT MAKE SURE
15426  070054  174010                          STD     AC0,(R0)                ;AC0 WAS NOT AFFECTED BY CMPD.
15427  070056  010102                          MOV     R1,R2
15428  070060  012703  000004                  MOV     #4,R3
15429  070064  022220                  4$:     CMP     (R2)+,(R0)+
15430  070066  001401                          BEQ     5$
15431  070070  104000                          EMT                     ;
15432  070072  077304                  5$:     SOB     R3,4$
15433
15434  070074  000161  000024                  JMP     24(R1)                  ;RETURN
15435
15436  070100  000000  000000  000000  CMPTMP: .WORD   0,0,0,0
15437  070106  000000
15438
15439
15440
15441  070110                          AADONE:
15442  070110  004767  030360                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
15443                                                                   ;SEE IF THE USER HAS EXPRESSED
15444                                                                   ;THE DESIRE TO CHANGE THE SOFTWARE
15445                                                                   ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
```

```
                                                        ;THE USER TYPED CONTROL G?).

                                ;*****************************************************************************************
                                ;TEST 462       DIVD WITH (FSRC=0) AND (BUT FD) TEST
                                ;*****************************************************************************************
070114                          TS462:

070114  012704  040200          BBB0:   MOV     #40200,R4       ;SET UP FPS
                                                                ;WITH INTERRUPTS
                                                                ;DISABLED.
070120  170104                          LDFPS   R4
070122  012737  070160  000244          MOV     #BBBER1,@#FPVECT;SET UP FOR ANY FP INTERRUPTS.
070130  012700  070344                  MOV     #BBBP1,R0       ;SET UP AC0 = 0
070134  172410                          LDD     (R0),AC0
070136  012701  070344                  MOV     #BBBP1,R1       ;FSRC = 0

070142  174411                  BBB1:   DIVD    (R1),AC0        ;TEST INSTRUCTION

070144  170205                          STFPS   R5              ;GET FPS
070146  170303                          STST    R3              ;GET FEC

070150  012704  140204                  MOV     #140204,R4      ;EXPECTED FPS.
070154  020405                          CMP     R4,R5           ;IS FPS CORRECT.
070156  001401                          BEQ     BBB7
070160                          BBBER1:
070160  104000                          EMT                     ;
070162  012702  000004          BBB7:   MOV     #4,R2           ;EXPECTED FEC.
070166  020203                          CMP     R2,R3           ;IS FEC CORRECT?
070170  001401                          BEQ     BBB2
070172  104000                          EMT                     ;

                                ;TEST DIVD WITH (FSRC=0) AND TRAPS DISABLED.
070174  012704  040200          BBB2:   MOV     #40200,R4       ;LOAD FPS WITH TRAPS DISABLED.
070200  170104                          LDFPS   R4

070202  012700  070354                  MOV     #BBBP2,R0       ;SET UP AC0 OPERAND (NON ZERO).
070206  172410                          LDD     (R0),AC0
070210  012700  070344                  MOV     #BBBP1,R0       ;FSRC=0
070214  174410                  BBB3:   DIVD    (R0),AC0

070216  170205                          STFPS   R5              ;GET FPS.
070220  170303                          STST    R3              ;GET FEC.

070222  012704  140200                  MOV     #140200,R4              ;EXPECTED FPS.
070226  020405                          CMP     R4,R5           ;IS FPS CORRECT?
070230  001401                          BEQ     1$
070232  104000                          EMT                     ;
070234  012702  000004          1$:     MOV     #4,R2           ;EXPECTED FEC.
070240  020203                          CMP     R2,R3           ;WAS FEC CORRECT?
070242  001401                          BEQ     BBB4
070244  104000                          EMT                     ;

                                ;TEST DIVD WITH FSRC=0) AND TRAPS ENABLED.
```

```
15502  070246  012704  000200          BBB4:   MOV     #200,R4         ;SET UP FPS. TRAP ENABLED.
15503  070252  170104                          LDFPS   R4
15504
15505  070254  012700  070354                  MOV     #BBBP2,R0       ;SET UP AC0 OPERAND (NON ZERO).
15506  070260  172410                          LDD     (R0),AC0
15507
15508  070262  012737  070302  000244          MOV     #BBB6,@#FPVECT  ;SET UP FOR THE EXPECTED INTERRUPT.
15509  070270  012700  070344                  MOV     #BBBP1,R0       ;FSRC=0
15510
15511  070274  174410                  BBB5:   DIVD    (R0),AC0        ;TEST INSTRUCTION (SHOULD RESULT IN TRAP).
15512  070276  170000                          CFCC
15513  070300  104000                          EMT                     ;
15514  070302  022716  070276          BBB6:   CMP     #BBB5+2,(SP)    ;TRAP TO HERE WHEN THE DIVISION BY 0
15515                                                                  ;OCCURS. FIRST SEE IF THE ADDRESS OF
15516                                                                  ;THE TRAP IS 2+THE ADDRESS OF THE TEST
15517                                                                  ;DIVD INSTRUCTION.
15518  070306  001401                          BEQ     1$
15519  070310  104000                          EMT                     ;
15520  070312  170205                  1$:     STFPS   R5              ;GET FPS.
15521  070314  170303                          STST    R3              ;GET FEC.
15522  070316  022626                          CMP     (SP)+,(SP)+     ;RESET THE STACK.
15523
15524  070320  012704  100200                  MOV     #100200,R4      ;EXPECTED FPS.
15525  070324  020405                          CMP     R4,R5           ;IS FPS CORRECT?
15526  070326  001401                          BEQ     2$
15527  070330  104000                          EMT                     ;
15528  070332  012702  000004          2$:     MOV     #4,R2           ;EXPECTED FEC.
15529  070336  020203                          CMP     R2,R3           ;IS FEC CORRECT?
15530  070340  001411                          BEQ     BBBDONE
15531  070342  104000                          EMT                     ;
15532
15533  070344  000000  000000  000000  BBBP1:  .WORD   0,0,0,0
15534  070352  000000
15535  070354  012345  054321  023456  BBBP2:  .WORD   12345,54321,23456,76543
15536  070362  076543
15537
15538
15539
15540  070364                          BBBDONE:
15541  070364  004767  030104                  JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
15542                                                                  ;SEE IF THE USER HAS EXPRESSED
15543                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
15544                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
15545                                                                  ;THE USER TYPED CONTROL G?).
15546
15547
15548
15549                           ;*****************************************************************************************
15550                           ;TEST 463       DIVF TEST
15551                           ;*****************************************************************************************
15552  070370                  TS463:
15553
15554                           ;CHECK DIVF WITH (AC=0).
15555  070370  004767  000404  CCC1:   JSR     PC,DIVFSUB
15556  070374  000000  000000  1$:     .WORD   0,0             ;AC
15557  070400  012345  067012  2$:     .WORD   12345,67012     ;FSRC
```

```
15558  070404  000000  000000          3$:     .WORD   0,0             ;RES
15559  070410  000000                  4$:     0                       ;FPS BEFORE EXECUTION
15560  070412  000004                          4                       ;FPS AFTER EXECUTION
15561
15562                                  ;TEST DIVF WITH AC POSITIVE, FSRC POSITIVE AND IN ROUND MODE.
15563  070414  004737  071000          CCC2:   JSR     PC,@#DIVFSUB
15564  070420  065652  125252          1$:     .WORD   65652,125252    ;AC
15565  070424  065600  000000          2$:     .WORD   65600,0         ;FSRC
15566  070430  040252  125252          3$:     .WORD   40252,125252    ;RES
15567  070434  003000                  4$:     3000                    ;FPS BEFORE EXECUTION.
15568  070436  003000                          3000                    ;FPS AFTER EXECUTION.
15569
15570                                  ;TEST DIVF WITH AC POSITIVE, FSRC POSITIVE.
15571  070440  004767  000334          CCC3:   JSR     PC,DIVFSUB
15572  070444  076400  000000          1$:     .WORD   76400,0         ;AC
15573  070450  076400  000000          2$:     .WORD   76400,0         ;FSRC
15574  070454  040200  000000          3$:     .WORD   40200,0         ;RES
15575  070460  001000                  4$:     1000                    ;FPS BEFORE EXECUTION.
15576  070462  001000                          1000                    ;FPS AFTER EXECUTION.
15577                                  ;TEST DIVF WITH BOTH OPERANDS POSITIVE.
15578  070464  004737  071000          CCC4:   JSR     PC,@#DIVFSUB
15579  070470  056777  177777          1$:     .WORD   56777,177777    ;AC
15580  070474  054200  000000          2$:     .WORD   54200,0         ;FSRC
15581  070500  042777  177777          3$:     .WORD   42777,177777    ;RES
15582  070504  000000                  4$:     0                       ;FPS BEFORE EXECUTION.
15583  070506  000000                          0                       ;FPS AFTER EXECUTION.
15584
15585                                  ;TEST THE DIVF INSTRUCTION:
15586  07051u  0u  '37  071000          CCC5:   JSR     PC,@#DIVFSUB
15587  070514  012377  177777          1$:     .WORD   12377,177777    ;AC
15588  070520  012300  000000          2$:     .WORD   12300,0         ;FSRC
15589  070524  040252  125252          3$:     .WORD   40252,125252    ;RES
15590  070530  000000                  4$:     0                       ;FPS BEFORE EXECUTION.
15591  070532  000000                          0                       ;FPS AFTER EXECUTION.
15592
15593                                  ;TEST DIVIDE ALGORITHM. TEST ROUND CONSTANT.
15594  070534  004737  071000          CCC6:   JSR     PC,@#DIVFSUB
15595  070540  064600  000001          1$:     .WORD   64600,1         ;AC
15596  070544  066600  000000          2$:     .WORD   66600,0         ;FSRC
15597  070550  036200  000001          3$:     .WORD   36200,1         ;RES
15598  070554  000000                  4$:     0                       ;FPS BEFORE EXECUTION.
15599  070556  000000                          0                       ;FPS AFTER EXECUTION.
15600
15601                                  ;TEST DIVF.
15602  070560  004737  071000          CCC7:   JSR     PC,@#DIVFSUB
15603  070564  034577  177776          1$:     .WORD   34577,177776    ;AC
15604  070570  023400  000000          2$:     .WORD   23400,0         ;FSRC
15605  070574  051377  177776          3$:     .WORD   51377,177776    ;RES
15606  070600  000017                  4$:     17                      ;FPS BEFORE EXECUTION.
15607  070602  000000                          0                       ;FPS AFTER EXECUTION.
15608
15609
15610                                  ;DIVF TEST.
15611  070604  004737  071000          CCC8:   JSR     PC,@#DIVFSUB
15612  070610  067652  125252          1$:     .WORD   67652,125252    ;AC
15613  070614  056500  000000          2$:     .WORD   56500,0         ;FSRC
```

```
15614  070620  051343  107070          3$:     .WORD   51343,107070    ;RES
15615  070624  000000                  4$:     0                       ;FPS BEFORE EXECUTION.
15616  070626  000000                          0                       ;FPS AFTER EXECUTION.
15617
15618                                  ;DIVF WITH AC NEGATIVE, FSRC NEGATIVE.
15619  070630  004737  071000          CCC9:   JSR     PC,@#DIVFSUB
15620  070634  140400  000000          1$:     .WORD   140400,0        ;AC
15621  070640  140500  000000          2$:     .WORD   140500,0        ;FSRC
15622  070644  040052  125253          3$:     .WORD   040052,125253   ;RES
15623  070650  000000                  4$:     0                       ;FPS BEFORE EXECUTION.
15624  070652  000000                          0                       ;FPS AFTER EXECUTION.
15625
15626                                  ;DIVF WITH AC NEGATIVE AND FSRC POSITIVE.
15627  070654  004737  071000          CCC10:  JSR     PC,@#DIVFSUB
15628  070660  160077  000000          1$:     .WORD   160077,0        ;AC
15629  070664  040277  000000          2$:     .WORD   40277,0         ;FSRC
15630  070670  160000  000000          3$:     .WORD   160000,0        ;RES
15631  070674  000007                  4$:     7                       ;FPS BEFORE EXECUTION.
15632  070676  000010                          10                      ;FPS AFTER EXECUTION.
15633
15634                                  ;DIVF WITH AC POSITIVE AND FSRC NEGATIVE.
15635  070700  004737  071000          CCC11:  JSR     PC,@#DIVFSUB
15636  070704  040400  000000          1$:     .WORD   40400,0         ;AC
15637  070710  140500  000000          2$:     .WORD   140500,0        ;FSRC
15638  070714  140052  125253          3$:     .WORD   140052,125253   ;RES
15639  070720  000017                  4$:     17                      ;FPS BEFORE EXECUTION.
15640  070722  000010                          10                      ;FPS AFTER EXECUTION.
15641
15642
15643                                  ;TEST DIVF BOTH OPERANDS POSITIVE AND TRUNCATE MODE.
15644  070724  004737  071000          CCC12:  JSR     PC,@#DIVFSUB
15645  070730  060100  000001          1$:     .WORD   60100,1         ;AC
15646  070734  040300  000000          2$:     .WORD   40300,0         ;FSRC
15647  070740  060000  000000          3$:     .WORD   60000,0         ;RES
15648  070744  000052                  4$:     52                      ;FPS BEFORE EXECUTION.
15649  070746  000040                          40                      ;FPS AFTER EXECUTION.
15650
15651                                  ;DIVF WITH POSITIVE OPERANDS AND ROUND MODE.
15652  070750  004767  000024          CCC13:  JSR     PC,DIVFSUB
15653  070754  060100  000001          1$:     .WORD   60100,1         ;AC
15654  070760  040300  000000          2$:     .WORD   40300,0         ;FSRC
15655  070764  060000  000001          3$:     .WORD   60000,1         ;RES
15656  070770  000005                  4$:     5                       ;FPS BEFORE EXECUTION.
15657  070772  000000                          0                       ;FPS AFTER EXECUTION.
15658
15659  070774  000137  071116                  JMP     @#CCCDONE       ;GO TO NEXT TEST.
15660
15661                                  ;THIS SUBROUTINE, DIVFSUB, IS CALLED TO SET UP, EXECUTE
15662                                  ;AND CHECK THE RESULT OF A DIVF INSTRUCTION. IT IS CALLED THUS:
15663                                  ;
15664                                  ;               JSR     PC,@#DIVFSUB
15665                                  ;       ACARG:  .WORD   X,X             ;AC OPERAND
15666                                  ;       FSRCARG:.WORD   X,X             ;FSRC OPERAND
15667                                  ;       RES:    .WORD   X,X             ;EXPECTED RESULT
15668                                  ;       FPSB:   .WORD   X               ;FPS BEFORE EXECUTION
15669                                  ;       FPSA:   .WORD   X               ;FPS AFTER EXECUTION
```

```
15670                                   ;       ERRES:  .WORD   X,X                     ;ERROR RESULT
15671                                   ;       ERR:    ERROR   X                       ;RESULT ERROR
15672                                   ;       CONT:                                   ;RETURN ADDRESS
15673                                   ;
15674                                   ;THE OPERANDS ARE SET UP (USING AC0 FOR THE AC OPERAND). THEN
15675                                   ;FPSB IS LOADED INTO THE FPS. THE INSTRUCTION, DIVF IS EXECUTED.
15676                                   ;AFTER THE EXECUTION THE RESULT IS CHECKED AGAINST THE
15677                                   ;EXPECTED CORRECT RESULT, RES. IF IT IS CORRECT THEN THE FPS
15678                                   ;IS CHECKED WITH THE EXPECTED CORRECT FPS, FPSA. IF THE FPS WAS
15679                                   ;INCORRECT THEN IT IS REPORTED. IF THE RESULT WAS INCORRECT IT
15680                                   ;IS COMPARED WITH ERRES IN AN ATTEMPT TO ANALYSE THE ERROR. IF
15681                                   ;THE INCORRECT RESULT MATCHED ERRES THEN CONTROL IS PASSED TO
15682                                   ;THE ERROR CALL AT ERR. IF THE INCORRECT RESULT DID NOT MATCH ERRES
15683                                   ;THEN THE FAILURE IS REPORTED IN DIVFSUB AND CONTROL IS PASSED TO
15684                                   ;CONT. IF NO ERRORS ARE DETECTED THEN DIVFSUB RETURNS CONTROL
15685                                   ;TO CONT.
15686
15687  071000  012601                   DIVFSUB:        MOV     (SP)+,R1        ;GET A POINTER TO THE ARGUMENTS.
15688  071002  012700  000200                   MOV     #200,R0         ;SET FD MODE.
15689  071006  170100                           LDFPS   R0
15690  071010  010100                           MOV     R1,R0           ;LOAD THE AC OPERAND.
15691  071012  172410                           LDD     (R0),AC0
15692  071014  016100  000014                   MOV     14(R1),R0       ;LOAD THE FPS
15693  071020  170100                           LDFPS   R0
15694  071022  010100                           MOV     R1,R0
15695  071024  062700  000004                   ADD     #4,R0           ;ESTABLISH A POINTER TO FSRC.
15696
15697  071030  174410                   1$:     DIVF    (R0),AC0        ;TEST INSTRUCTION.
15698
15699  071032  170204                           STFPS   R4              ;GET THE FPS.
15700  071034  012700  000200                   MOV     #200,R0         ;SET FD MODE
15701  071040  170100                           LDFPS   R0
15702
15703  071042  012700  071106                   MOV     #DIVFT,R0       ;GET THE RESULT OF THE DIVF.
15704  071046  174010                           STD     AC0,(R0)
15705  071050  021061  000010                   CMP     (R0),10(R1)     ;IS THE RESULT CORRECT?
15706  071054  001401                           BEQ     2$
15707  071056  104000                           EMT                     ;
15708  071060  026061  000002  000012 2$:      CMP     2(R0),12(R1)
15709  071066  001401                           BEQ     3$
15710  071070  104000                           EMT                     ;
15711  071072  026104  000016          3$:     CMP     16(R1),R4       ;IS FPS CORRECT?
15712  071076  001401                           BEQ     4$
15713  071100  104000                           EMT                     ;
15714  071102  000161  000020          4$:     JMP     20(R1)          ;IF NO ERRORS OCCURRED RETURN.
15715
15716  071106  000000  000000  000000 DIVFT:   .WORD   0,0,0,0
15717  071114  000000
15718
15719  071116                           CCCDONE:
15720  071116  004767  027352                   JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
15721                                                                   ;SEE IF THE USER HAS EXPRESSED
15722                                                                   ;THE DESIRE TO CHANGE THE SOFTWARE
15723                                                                   ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
15724                                                                   ;THE USER TYPED CONTROL G?).
15725
```

```
15726
15727
15728                                   ;*****************************************************************************************
15729                                   ;TEST 464       DIVD TEST
15730                                   ;*****************************************************************************************
15731  071122                           TS464:
15732
15733                                   ;DIVD TEST WITH POSITIVE OPERANDS AND IN ROUND MODE.
15734  071122  004737  071466           DDD1:   JSR     PC,@#DIVDSUB
15735  071126  034277  000000  000000  1$:     .WORD   34277,0,0,0     ;AC
15736  071134  000000
15737  071136  040277  000000  000000  2$:     .WORD   40277,0,0,0     ;FSRC
15738  071144  000000
15739  071146  034200  000000  000000  3$:     .WORD   34200,0,0,0     ;RES
15740  071154  000000
15741  071156  000200                   4$:     200                     ;FPS BEFORE EXECUTION.
15742  071160  000200                           200                     ;FPS AFTER EXECUTION.
15743
15744                                   ;DIVD WITH AC NEGATIVE AND FSRC POSITIVE IN TRUNCATE MODE.
15745  071162  004737  071466           DDD2:   JSR     PC,@#DIVDSUB
15746  071166  134277  000000  000000  1$:     .WORD   134277,0,0,0    ;AC
15747  071174  000000
15748  071176  040277  000000  000000  2$:     .WORD   40277,0,0,0     ;FSRC
15749  071204  000000
15750  071206  134200  000000  000000  3$:     .WORD   134200,0,0,0    ;RES
15751  071214  000000
15752  071216  000207                   4$:     207                     ;FPS BEFORE EXECUTION.
15753  071220  000210                           210                     ;FPS AFTER EXECUTION.
15754
15755                                   ;DIVD TEST WITH OPERANDS BOTH NEGATIVE AND IN TRUNCATE MODE.
15756  071222  004767  000240           DDD3:   JSR     PC,DIVDSUB
15757  071226  134300  000000  000000  1$:     .WORD   134300,0,0,1    ;AC
15758  071234  000001
15759  071236  140300  000000  000000  2$:     .WORD   140300,0,0,0    ;FSRC
15760  071244  000000
15761  071246  034200  000000  000000  3$:     .WORD   34200,0,0,0     ;RES
15762  071254  000000
15763  071256  000250                   4$:     250                     ;FPS BEFORE EXECUTION.
15764  071260  000240                           240                     ;FPS AFTER EXECUTION.
15765
15766                                   ;DIVD WITH AC POSITIVE AND FSRC NEGATIVE IN ROUND MODE.
15767  071262  004737  071466           DDD4:   JSR     PC,a#DIVDSUB
15768  071266  034300  000000  000000  1$:     .WORD   34300,0,0,1     ;AC
15769  071274  000001
15770  071276  140300  000000  000000  2$:     .WORD   140300,0,0,0    ;FSRC
15771  071304  000000
15772  071306  134200  000000  000000  3$:     .WORD   134200,0,0,1    ;RES
15773  071314  000001
15774  071316  000207                   4$:     207                     ;FPS BEFORE EXECUTION.
15775  071320  000210                           210                     ;FPS AFTER EXECUTION.
15776
15777                                   ;DIVD TEST.
15778  071322  004737  071466           DDD5:   JSR     PC,a#DIVDSUB
15779  071326  100400  000000  000000  1$:     .WORD   100400,0,0,0    ;AC
15780  071334  000000
15781  071336  000500  000000  000000  2$:     .WORD   500,0,0,0       ;FSRC
```

```
15782  071344  000000
15783  071346  140052  125252          3$:     .WORD   140052,125252   ;RES
15784  071352  125252  125252                  .WORD   125252,125252
15785  071356  007647                  4$:     7647                    ;FPS BEFORE EXECUTION.
15786  071360  007650                          7650                    ;FPS AFTER EXECUTION.
15787
15788
15789                                  ;DIVD TEST WITH AC POSITIVE AND FSRC NEGATIVE IN ROUND MODE.
15790  071362  004737  071466          DDD6:   JSR     PC,@#DIVDSUB
15791  071366  000400  000000  000000  1$:     .WORD   400,0,0,0       ;AC
15792  071374  000000
15793  071376  100500  000000  000000  2$:     .WORD   100500,0,0,0    ;FSRC
15794  071404  000000
15795  071406  140052  125252          3$:     .WORD   140052,125252   ;RES
15796  071412  125252  125253                  .WORD   125252,125253
15797  071416  007707                  4$:     7707                    ;FPS BEFORE EXECUTION.
15798  071420  007710                          7710                    ;FPS AFTER EXECUTION.
15799
15800                                  ;DIVD TEST.
15801  071422  004737  071466          DDD7:   JSR     PC,@#DIVDSUB
15802  071426  170360  170360          1$:     .WORD   170360,170360   ;AC
15803  071432  170360  170360                  .WORD   170360,170360
15804  071436  170360  170360          2$:     .WORD   170360,170360   ;FSRC
15805  071442  170360  170360                  .WORD   170360,170360
15806  071446  040200  000000  000000  3$:     .WORD   40200,0,0,0     ;RES
15807  071454  000000
15808  071456  007717                  4$:     7717                    ;FPS BEFORE EXECUTION.
15809  071460  007700                          7700                    ;FPS AFTER EXECUTION.
15810
15811  071462  000137  071610                  JMP     @#DDDDONE       ;GO TO NEXT TEST.
15812
15813
15814                                  ;THIS SUBROUTINE, DIVDSUB, IS CALLED TO SET UP, EXECUTE
15815                                  ;AND CHECK THE RESULT OF A DIVD INSTRUCTION. IT IS CALLED THUS:
15816                                  ;
15817                                  ;               JSR     PC,@#DIVDSUB
15818                                  ;       ACARG:  .WORD   X,X,X,X         ;AC OPERAND
15819                                  ;       FSRCARG:.WORD   X,X,X,X         ;FSRC OPERAND
15820                                  ;       RES:    .WORD   X,X,X,X         ;EXPECTED RESULT
15821                                  ;       FPSB:   .WORD   X               ;FPS BEFORE EXECUTION
15822                                  ;       FPSA:   .WORD   X               ;FPS AFTER EXECUTION
15823                                  ;       ERRES:  .WORD   X,X,X,X         ;ERROR RESULT
15824                                  ;       ERR:    ERROR   X               ;RESULT ERROR
15825                                  ;       CONT:                           ;RETURN ADDRESS
15826                                  ;
15827                                  ;THE OPERANDS ARE SET UP (USING AC0 FOR THE AC OPERAND). THEN
15828                                  ;FPSB IS LOADED INTO THE FPS. THE INSTRUCTION, DIVD IS EXECUTED.
15829                                  ;AFTER THE EXECUTION THE RESULT IS CHECKED AGAINST THE
15830                                  ;EXPECTED CORRECT RESULT, RES. IF IT IS CORRECT THEN THE FPS
15831                                  ;IS CHECKED WITH THE EXPECTED CORRECT FPS, FPSA. IF THE FPS WAS
15832                                  ;INCORRECT THEN IT IS REPORTED. IF THE RESULT WAS INCORRECT IT
15833                                  ;IS COMPARED WITH ERRES IN AN ATTEMPT TO ANALYSE THE ERROR. IF
15834                                  ;THE INCORRECT RESULT MATCHED ERRES THEN CONTROL IS PASSED TO
15835                                  ;THE ERROR CALL AT ERR. IF THE INCORRECT RESULT DID NOT MATCH ERRES
15836                                  ;THEN THE FAILURE IS REPORTED IN DIVDSUB AND CONTROL IS PASSED TO
15837                                  ;CONT. IF NO ERRORS ARE DETECTED THEN DIVDSUB RETURNS CONTROL
```

```
15838
15839
15840  071466  012601                  ;TO CONT.
15841  071470  012700  000200          DIVDSUB:  MOV     (SP)+,R1        ;GET A POINTER TO THE ARGUMENTS.
15842  071474  170100                            MOV     #200,R0         ;SET FD MODE.
15843                                             LDFPS   R0
15844  071476  010100                            MOV     R1,R0           ;SET UP THE AC0 OPERAND.
15845  071500  172410                            LDD     (R0),AC0
15846  071502  016100  000030                    MOV     30(R1),R0       ;LOAD THE FPS.
15847  071506  170100                            LDFPS   R0
15848
15849  071510  010100                            MOV     R1,R0           ;ESTABLISH A POINTER TO FSRC.
15850  071512  062700  000010                    ADD     #10,R0
15851
15852  071516  174410                  1$:       DIVD    (R0),AC0        ;EXECUTE THE TEST INSTRUCTION.
15853  071520  170204                            STFPS   R4              ;GET THE FPS.
15854  071522  012700  000200                    MOV     #200,R0         ;SET FD MODE.
15855  071526  170100                            LDFPS   R0
15856  071530  012700  071600                    MOV     #DIVDT,R0       ;GET THE RESULT.
15857  071534  174010                            STD     AC0,(R0)
15858  071536  010102                            MOV     R1,R2           ;CHECK THE RESULT.
15859  071540  062702  000020                    ADD     #20,R2
15860  071544  012703  071600                    MOV     #DIVDT,R3
15861  071550  012705  000004                    MOV     #4,R5
15862  071554  022223                  2$:       CMP     (R2)+,(R3)+
15863  071556  001401                            BEQ     3$
15864  071560  104000                            EMT                     ;
15865  071562  077504                  3$:       SOB     R5,2$
15866
15867  071564  026104  000032                    CMP     32(R1),R4       ;IS FPS CORRECT?
15868  071570  001401                            BEQ     4$
15869  071572  104000                            EMT                     ;
15870  071574  000161  000034          4$:       JMP     34(R1)          ;RETURN.
15871  071600  000000  000000  000000  DIVDT:    .WORD   0,0,0,0
15872  071606  000000
15873
15874  071610                          DDDDONE:
15875  071610  004767  026660                    JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
15876                                                                    ;SEE IF THE USER HAS EXPRESSED
15877                                                                    ;THE DESIRE TO CHANGE THE SOFTWARE
15878                                                                    ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
15879                                                                    ;THE USER TYPED CONTROL G?).
15880
15881
15882
15883                                   ;*****************************************************************************
15884                                   ;TEST 465       MULF TEST
15885                                   ;*****************************************************************************
15886  071614                          TS465:
15887
15888                                   ;MULF WITH (FSRC=AC=0)
15889  071614  004737  072224          EEE1:     JSR     PC,@#MULFSUB
15890  071620  000000  000000          1$:       .WORD   0,0             ;AC
15891  071624  000000  000000          2$:       .WORD   0,0             ;FSRC
15892  071630  000000  000000          3$:       .WORD   0,0             ;RES
15893  071634  007517                  4$:       7517                    ;FPS BEFORE EXECUTION.
```

```
15894  071636  007504                          7504                    ;FPS AFTER EXECUTION.
15895
15896                                          ;MULF WITH (FSRC=0).
15897  071640  004737  072224                  EEE2:   JSR     PC,@#MULFSUB
15898  071644  071625  034435                  1$:     .WORD   71625,34435     ;AC
15899  071650  000000  000000                  2$:     .WORD   0,0             ;FSRC
15900  071654  000000  000000                  3$:     .WORD   0,0             ;RES
15901  071660  000013                          4$:     13                      ;FPS BEFORE EXECUTION.
15902  071662  000004                                  4                       ;FPS AFTER EXECUTION.
15903
15904                                          ;MULF WITH (AC=0)
15905  071664  004737  072224                  EEE3:   JSR     PC,@#MULFSUB
15906  071670  000000  000000                  1$:     .WORD   0,0             ;AC
15907  071674  071625  153443                  2$:     .WORD   071625,153443   ;FSRC
15908  071700  000000  000000                  3$:     .WORD   0,0             ;RES
15909  071704  007500                          4$:     7500                    ;FPS BEFORE EXECUTION.
15910  071706  007504                                  7504                    ;FPS AFTER EXECUTION.
15911
15912                                          ;MULF WITH AC POSITIVE AND FSRC POSITIVE IN ROUND MODE.
15913  071710  004737  072224                  EEE4:   JSR     PC,@#MULFSUB
15914  071714  040200  000000                  1$:     .WORD   40200,0         ;AC
15915  071720  040177  177777                  2$:     .WORD   40177,-1        ;FSRC
15916  071724  040177  177777                  3$:     .WORD   40177,-1        ;RES
15917  071730  000017                          4$:     17                      ;FPS BEFORE EXECUTION.
15918  071732  000000                                  0                       ;FPS AFTER EXECUTION.
15919
15920                                          ;MULF WITH AC POSITIVE AND FSRC POSITIVE IN TRUNCATE MODE.
15921  071734  004767  000264                  EEE5:   JSR     PC,MULFSUB
15922  071740  040177  177777                  1$:     .WORD   40177,-1        ;AC
15923  071744  040200  000000                  2$:     .WORD   40200,0         ;FSRC
15924  071750  040177  177777                  3$:     .WORD   40177,-1        ;RES
15925  071754  000040                          4$:     40                      ;FPS BEFORE EXECUTION.
15926  071756  000040                                  40                      ;FPS AFTER EXECUTION.
15927
15928                                          ;MULF WITH BOTH OPERANDS POSITIVE NORMALIZE TEST.
15929  071760  004737  072224                  EEE6:   JSR     PC,@#MULFSUB
15930  071764  040100  000000                  1$:     .WORD   40100,0         ;AC
15931  071770  040100  000000                  2$:     .WORD   40100,0         ;FSRC
15932  071774  040020  000000                  3$:     .WORD   40020,0         ;RES
15933  072000  000012                          4$:     12                      ;FPS BEFORE EXECUTION.
15934  072002  000000                                  0                       ;FPS AFTER EXECUTION.
15935
15936                                          ;MULF WITH BOTH OPERANDS POSITIVE IN ROUND MODE.
15937  072004  004737  072224                  EEE7:   JSR     PC,@#MULFSUB
15938  072010  017500  000000                  1$:     .WORD   17500,0         ;AC
15939  072014  023652  125252                  2$:     .WORD   23652,125252    ;FSRC
15940  072020  003177  177777                  3$:     .WORD   3177,-1         ;RES
15941  072024  007417                          4$:     7417                    ;FPS BEFORE EXECUTION.
15942  072026  007400                                  7400                    ;FPS AFTER EXECUTION.
15943
15944                                          ;MULF WITH AC POSITIVE AND FSRC NEGATIVE IN ROUND MODE.
15945  072030  004737  072224                  EEE8:   JSR     PC,@#MULFSUB
15946  072034  040342  000000                  1$:     .WORD   40342,0         ;AC
15947  072040  176542  000000                  2$:     .WORD   176542,0        ;FSRC
15948  072044  176707  102000                  3$:     .WORD   176707,102000   ;RES
15949  072050  000007                          4$:     7                       ;FPS BEFORE EXECUTION.
```

```
15950  072052  000010                        10                      ;FPS AFTER EXECUTION.
15951
15952                                  ;MULF WITH AC NEGATIVE AND FSRC POSITIVE IN ROUND MODE.
15953  072054  004737  072224          EEE9:   JSR     PC,@#MULFSUB
15954  072060  140200  000000          1$:     .WORD   140200,0        ;AC
15955  072064  007417  007417          2$:     .WORD   7417,7417       ;FSRC
15956  072070  107417  007417          3$:     .WORD   107417,7417     ;RES
15957  072074  000000                  4$:     0                       ;FPS BEFORE EXECUTION.
15958  072076  000010                          10                      ;FPS AFTER EXECUTION.
15959
15960                                  ;MULF WITH BOTH OPERANDS NEGATIVE IN ROUND MODE.
15961  072100  004737  072224          EEE10:  JSR     PC,@#MULFSUB
15962  072104  144600  000000          1$:     .WORD   144600,0        ;AC
15963  072110  154000  000000          2$:     .WORD   154000,0        ;FSRC
15964  072114  060400  000000          3$:     .WORD   60400,0         ;RES
15965  072120  000017                  4$:     17                      ;FPS BEFORE EXECUTION.
15966  072122  000000                          0                       ;FPS AFTER EXECUTION.
15967
15968                                  ;MULF BOTH OPERANDS NEGATIVE IN ROUND MODE.
15969  072124  004737  072224          EEE11:  JSR     PC,@#MULFSUB
15970  072130  140300  000000          1$:     .WORD   140300,0        ;AC
15971  072134  160000  000001          2$:     .WORD   160000,1        ;FSRC
15972  072140  060100  000002          3$:     .WORD   60100,2         ;RES
15973  072144  000010                  4$:     10                      ;FPS BEFORE EXECUTION.
15974  072146  000000                          0                       ;FPS AFTER EXECUTION.
15975
15976                                  ;MULF WITH AC POSITIVE AND FSRC NEGATIVE IN TRUNCATE MODE.
15977  072150  004737  072224          EEE12:  JSR     PC,@#MULFSUB
15978  072154  060000  000001          1$:     .WORD   60000,1         ;AC
15979  072160  140300  000000          2$:     .WORD   140300,0        ;FSRC
15980  072164  160100  000001          3$:     .WORD   160100,1        ;RES
15981  072170  007547                  4$:     7547                    ;FPS BEFORE EXECUTION.
15982  072172  007550                          7550                    ;FPS AFTER EXECUTION.
15983
15984                                  ;MULF WITH AC POSITIVE AND FSRC POSITIVE IN ROUND MODE.
15985  072174  004737  072224          EEE13:  JSR     PC,@#MULFSUB
15986  072200  040277  000000          1$:     .WORD   40277,0         ;AC
15987  072204  060000  000001          2$:     .WORD   60000,1         ;FSRC
15988  072210  060077  000001          3$:     .WORD   60077,1         ;RES
15989  072214  000014                  4$:     14                      ;FPS BEFORE EXECUTION.
15990  072216  000000                          0                       ;FPS AFTER EXECUTION.
15991
15992  072220  000167  000116                  JMP     EEEDONE         ;GO TO THE NEXT TEST.
15993
15994                                  ;THIS SUBROUTINE, MULFSUB, IS CALLED TO SET UP, EXECUTE
15995                                  ;AND CHECK THE RESULT OF A MULF INSTRUCTION. IT IS CALLED THUS:
15996                                  ;
15997                                  ;               JSR     PC,@#MULFSUB
15998                                  ;       ACARG:  .WORD   X,X             ;AC OPERAND
15999                                  ;       FSRCARG:.WORD   X,X             ;FSRC OPERAND
16000                                  ;       RES:    .WORD   X,X             ;EXPECTED RESULT
16001                                  ;       FPSB:   .WORD   X               ;FPS BEFORE EXECUTION
16002                                  ;       FPSA:   .WORD   X               ;FPS AFTER EXECUTION
16003                                  ;       ERRES:  .WORD   X,X             ;ERROR RESULT
16004                                  ;       ERR:    ERROR   X               ;RESULT ERROR
16005                                  ;       CONT:                           ;RETURN ADDRESS
```

```
16006                                   ;
16007                                   ;THE OPERANDS ARE SET UP (USING AC0 FOR THE AC OPERAND). THEN
16008                                   ;FPSB IS LOADED INTO THE FPS. THE INSTRUCTION, MULF IS EXECUTED.
16009                                   ;AFTER THE EXECUTION THE RESULT IS CHECKED AGAINST THE
16010                                   ;EXPECTED CORRECT RESULT, RES. IF IT IS CORRECT THEN THE FPS
16011                                   ;IS CHECKED WITH THE EXPECTED CORRECT FPS, FPSA. IF THE FPS WAS
16012                                   ;INCORRECT THEN IT IS REPORTED. IF THE RESULT WAS INCORRECT IT
16013                                   ;IS COMPARED WITH ERRES IN AN ATTEMPT TO ANALYSE THE ERROR. IF
16014                                   ;THE INCORRECT RESULT MATCHED ERRES THEN CONTROL IS PASSED TO
16015                                   ;THE ERROR CALL AT ERR. IF THE INCORRECT RESULT DID NOT MATCH ERRES
16016                                   ;THEN THE FAILURE IS REPORTED IN MULFSUB AND CONTROL IS PASSED TO
16017                                   ;CONT. IF NO ERRORS ARE DETECTED THEN MULFSUB RETURNS CONTROL
16018                                   ;TO CONT.
16019
16020  072224  012601                   MULFSUB:        MOV     (SP)+,R1        ;GET A POINTER TO THE ARGUMENTS.
16021  072226  012700  000200                   MOV     #200,R0         ;SET FD MODE.
16022  072232  170100                           LDFPS   R0
16023  072234  010100                           MOV     R1,R0           ;LOAD THE AC OPERAND.
16024  072236  172410                           LDD     (R0),AC0
16025  072240  016100  000014                   MOV     14(R1),R0       ;LOAD THE FPS
16026  072244  170100                           LDFPS   R0
16027  072246  010100                           MOV     R1,R0
16028  072250  062700  000004                   ADD     #4,R0           ;ESTABLISH A POINTER TO FSRC.
16029
16030  072254  171010                   1$:     MULF    (R0),AC0        ;TEST INSTRUCTION.
16031
16032  072256  170204                           STFPS   R4              ;GET THE FPS.
16033  072260  012700  000200                   MOV     #200,R0         ;SET FD MODE
16034  072264  170100                           LDFPS   R0
16035
16036  072266  012700  072332                   MOV     #MULFT,R0       ;GET THE RESULT OF THE MULF.
16037  072272  174010                           STD     AC0,(R0)
16038  072274  021061  000010                   CMP     (R0),10(R1)     ;IS THE RESULT CORRECT?
16039  072300  001401                           BEQ     2$
16040  072302  104000                           EMT                     ;
16041  072304  026061  000002  000012  2$:     CMP     2(R0),12(R1)
16042  072312  001401                           BEQ     3$
16043  072314  104000                           EMT                     ;
16044  072316  026104  000016           3$:     CMP     16(R1),R4       ;IS FPS CORRECT?
16045  072322  001401                           BEQ     4$
16046  072324  104000                           EMT                     ;
16047  072326  000161  000020           4$:     JMP     20(R1)          ;IF NO ERRORS OCCURRED RETURN.
16048
16049  072332  000000  000000  000000  MULFT:  .WORD   0,0,0,0
16050  072340  000000
16051
16052  072342                           EEEDONE:
16053  072342  004767  026126                   JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
16054                                                                   ;SEE IF THE USER HAS EXPRESSED
16055                                                                   ;THE DESIRE TO CHANGE THE SOFTWARE
16056                                                                   ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
16057                                                                   ;THE USER TYPED CONTROL G?).
16058
16059
16060
16061                                   ;*****************************************************************************************
```

```
16062                                   ;TEST 466       MULD TEST
16063                                   ;*****************************************************************************************
16064  072346                           TS466:
16065
16066                                   ;MULD TEST WITH AC POSITIVE AND FSRC POSITIVE.
16067  072346  004737  072552           FFF1:   JSR     PC,@#MULDSUB
16068  072352  040200  000000  000000   1$:     .WORD   40200,0,0,0     ;AC
16069  072360  000000
16070  072362  023777  177777  177777   2$:     .WORD   23777,-1,-1,-1  ;FSRC
16071  072370  177777
16072  072372  023777  177777  177777   3$:     .WORD   23777,-1,-1,-1  ;RES
16073  072400  177777
16074  072402  000217                   4$:     217                     ;FPS BEFORE EXECUTION.
16075  072404  000200                           200                     ;FPS AFTER ECECUTION.
16076
16077                                   ;MULD TEST WITH BOTH OPERANDS POSITIVE TRUNCATION TEST.
16078  072406  004767  000140           FFF2:   JSR     PC,MULDSUB
16079  072412  065400  000000  000000   1$:     .WORD   65400,0,0,1     ;AC
16080  072420  000001
16081  072422  037577  177777  177777   2$:     .WORD   37577,-1,-1,-2  ;FSRC
16082  072430  177776
16083  072432  064777  177777  177777   3$:     .WORD   64777,-1,-1,-1  ;RES
16084  072440  177777
16085  072442  000247                   4$:     247                     ;FPS BEFORE EXECUTION.
16086  072444  000240                           240                     ;FPS AFTER EXECUTION.
16087
16088                                   ;MULD TEST WITH BOTH OPERANDS NEGATIVE IN ROUND MODE.
16089  072446  004737  072552           FFF3:   JSR     PC,@#MULDSUB
16090  072452  137577  177777  177777   1$:     .WORD   137577,-1,-1,-2 ;AC
16091  072460  177776
16092  072462  165400  000000  000000   2$:     .WORD   165400,0,0,1    ;FSRC
16093  072470  000001
16094  072472  065000  000000  000000   3$:     .WORD   65000,0,0,0     ;RES
16095  072500  000000
16096  072502  007717                   4$:     7717                    ;FPS BEFORE EXECUTION.
16097  072504  007700                           7700                    ;FPS AFTER EXECUTION.
16098
16099                                   ;MULD   TEST WITH AC POSITIVE AND FSRC NEGATIVE IN ROUND MODE.
16100  072506  004737  072552           FFF4:   JSR     PC,@#MULDSUB
16101  072512  017500  000000  000000   1$:     .WORD   17500,0,0,0     ;AC
16102  072520  000000
16103  072522  123652  125252           2$:     .WORD   123652,125252   ;FSRC
16104  072526  125252  125252                   .WORD   125252,125252
16105  072532  103177  177777  177777   3$:     .WORD   103177,-1,-1,-1 ;RES
16106  072540  177777
16107  072542  000200                   4$:     200                     ;FPS BEFORE EXECUTION.
16108  072544  000210                           210                     ;FPS AFTER EXECUTION.
16109
16110  072546  000167  000122                   JMP     FFFDONE
16111
16112                                   ;THIS SUBROUTINE, MULDSUB, IS CALLED TO SET UP, EXECUTE
16113                                   ;AND CHECK THE RESULT OF A MULD INSTRUCTION. IT IS CALLED THUS::
16114                                   ;               JSR     PC,@#MULDSUB
16115                                   ;       ACARG:  .WORD   X,X,X,X                 ;AC OPERAND
16116                                   ;       FSRCARG:.WORD   X,X,X,X                 ;FSRC OPERAND
16117                                   ;       RES:    .WORD   X,X,X,X                 ;EXPECTED RESULT
```

```
16118                                   ;       FPSB:   .WORD   X                       ;FPS BEFORE EXECUTION
16119                                   ;       FPSA:   .WORD   X                       ;FPS AFTER EXECUTION
16120                                   ;       ERRES:  .WORD   X,X,X,X                 ;ERROR RESULT
16121                                   ;       ERR:    ERROR   X                       ;RESULT ERROR
16122                                   ;       CONT:                                   ;RETURN ADDRESS
16123                                   ;
16124                                   ;THE OPERANDS ARE SET UP (USING AC0 FOR THE AC OPERAND). THEN
16125                                   ;FPSB IS LOADED INTO THE FPS. THE INSTRUCTION, MULD IS EXECUTED.
16126                                   ;AFTER THE EXECUTION THE RESULT IS CHECKED AGAINST THE
16127                                   ;EXPECTED CORRECT RESULT, RES. IF IT IS CORRECT THEN THE FPS
16128                                   ;IS CHECKED WITH THE EXPECTED CORRECT FPS, FPSA. IF THE FPS WAS
16129                                   ;INCORRECT THEN IT IS REPORTED. IF THE RESULT WAS INCORRECT IT
16130                                   ;IS COMPARED WITH ERRES IN AN ATTEMPT TO ANALYSE THE ERROR. IF
16131                                   ;THE INCORRECT RESULT MATCHED ERRES THEN CONTROL IS PASSED TO
16132                                   ;THE ERROR CALL AT ERR. IF THE INCORRECT RESULT DID NOT MATCH ERRES
16133                                   ;THEN THE FAILURE IS REPORTED IN MULDSUB AND CONTROL IS PASSED TO
16134                                   ;CONT. IF NO ERRORS ARE DETECTED THEN MULDSUB RETURNS CONTROL
16135                                   ;TO CONT.
16136
16137  072552  012601                   MULDSUB:        MOV     (SP)+,R1        ;GET A POINTER TO THE ARGUMENTS.
16138  072554  012700  000200                   MOV     #200,R0         ;SET FD MODE.
16139  072560  170100                           LDFPS   R0
16140
16141  072562  010100                           MOV     R1,R0           ;SET UP THE AC0 OPERAND.
16142  072564  172410                           LDD     (R0),AC0
16143  072566  016100  000030                   MOV     30(R1),R0       ;LOAD THE FPS.
16144  072572  170100                           LDFPS   R0
16145
16146  072574  010100                           MOV     R1,R0           ;ESTABLISH A POINTER TO FSRC.
16147  072576  062700  000010                   ADD     #10,R0
16148
16149  072602  171010                   1$:     MULD    (R0),AC0        ;EXECUTE THE TEST INSTRUCTION.
16150
16151  072604  170204                           STFPS   R4              ;GET THE FPS.
16152  072606  012700  000200                   MOV     #200,R0         ;SET FD MODE.
16153  072612  170100                           LDFPS   R0
16154
16155  072614  012700  072664                   MOV     #MULDT,R0       ;GET THE RESULT.
16156  072620  174010                           STD     AC0,(R0)
16157  072622  010102                           MOV     R1,R2           ;CHECK THE RESULT.
16158  072624  062702  000020                   ADD     #20,R2
16159  072630  012703  072664                   MOV     #MULDT,R3
16160  072634  012705  000004                   MOV     #4,R5
16161  072640  022223                   2$:     CMP     (R2)+,(R3)+
16162  072642  001401                           BEQ     3$
16163  072644  104000                           EMT                     ;               ;
16164  072646  077504                   3$:     SOB     R5,2$                   ;       ;
16165
16166  072650  026104  000032                   CMP     32(R1),R4       ;IS FPS CORRECT?
16167  072654  001401                           BEQ     4$
16168  072656  104000                           EMT                     ;
16169  072660  000161  000034           4$:     JMP     34(R1)          ;RETURN.
16170
16171  072664  000000  000000  000000 MULDT:   .WORD   0,0,0,0
16172  072672  000000
16173  072674                           FFFDONE:
```

```
16174  072674  004767  025574                  JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
16175                                                                   ;SEE IF THE USER HAS EXPRESSED
16176                                                                   ;THE DESIRE TO CHANGE THE SOFTWARE
16177                                                                   ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
16178                                                                   ;THE USER TYPED CONTROL G?).
16179
16180
16181
16182                                   ;*****************************************************************************
16183                                   ;TEST 467       UNDER\OVER FLOW, USING MULF WITH TRAPS DISABLED, TEST
16184                                   ;*****************************************************************************
16185  072700                           TS467:
16186
16187                                   ;UNDERFLOW, WITH EXPONENT OF RESULT = -129
16188  072700  004737  073044           III1:   JSR     PC,@#OVUNFNT
16189  072704  020200  000000           1$:     .WORD   20200,0         ;AC
16190  072710  020000  000000           2$:     .WORD   20000,0         ;FSRC
16191  072714  000000  000000           3$:     .WORD   0,0             ;RES
16192  072720  000000                   5$:     0                       ;FPS BEFORE EXECUTION.
16193  072722  000004                           4                       ;FPS AFTER EXECUTION.
16194  072724  000012                   6$:     12                      ;FEC
16195  072726  177777                           -1                      ;FLAG
16196
16197                                   ;UNDERFLOW, WITH EXPONENT OF RESULT = -193
16198  072730  004737  073044           III2:   JSR     PC,@#OVUNFNT
16199  072734  010200  000000           1$:     .WORD   10200,0         ;AC
16200  072740  010000  000000           2$:     .WORD   10000,0         ;FSRC
16201  072744  000000  000000           3$:     .WORD   0,0             ;RES
16202  072750  005013                   5$:     5013                    ;FPS BEFORE EXECUTION.
16203  072752  005004                           5004                    ;FPS AFTER EXECUTION.
16204  072754  000012                   6$:     12                      ;FEC
16205  072756  177777                           -1                      ;FLAG
16206                                   ;OVERFLOW, EXPONENT OF RESULT = 128
16207  072760  004737  073044           III3:   JSR     PC,@#OVUNFNT
16208  072764  060200  000000           1$:     .WORD   60200,0         ;AC
16209  072770  060000  000000           2$:     .WORD   60000,0         ;FSRC
16210  072774  000000  000000           3$:     .WORD   0,0             ;RES
16211  073000  000000                   5$:     0                       ;FPS BEFORE EXECUTION.
16212  073002  000006                           6                       ;FPS AFTER EXECUTION.
16213  073004  000010                   6$:     10                      ;FEC
16214  073006  000000                           0                       ;FLAG
16215                                   ;OVERFLOW, EXPONENT OF RESULT = 130
16216  073010  004737  073044           III4:   JSR     PC,@#OVUNFNT
16217  073014  060200  000000           1$:     .WORD   60200,0         ;AC
16218  073020  060200  000000           2$:     .WORD   60200,0         ;FSRC
16219  073024  000000  000000           3$:     .WORD   0,0             ;RES
16220  073030  006011                   5$:     6011                    ;FPS BEFORE EXECUTION.
16221  073032  006006                           6006                    ;FPS AFTER EXECUTION.
16222  073034  000010                   6$:     10                      ;FEC
16223  073036  000000                           0                       ;FLAG
16224  073040  000167  000132           8$:     JMP     IIIDONE         ;GO TO NEXT TEST.
16225
16226
16227
16228                                   ;THIS SUBROUTINE, OVUNFNT, IS USED TO SET UP THE OPERANDS, EXECUTE
16229                                   ;THE MULF INSTRUCTION AND CHECK THE RESULTS OF AN INSTRUCTION WITH
```

```
16230                                   ;OPERANDS WHICH SHOULD RESULT IN EITHER OVERFLOW OR UNDERFLOW. A CALL
16231                                   ;TO IT IS MADE THUS:
16232                                   ;
16233                                   ;               ACARG:  .WORD   X,X             ;AC OPERAND
16234                                   ;               FSRCARG:.WORD   X,X             ;FSRC OPERAND
16235                                   ;               RES:    .WORD   X,X             ;EXPECTED RESULT
16236                                   ;               ERRES:  .WORD   X,X             ;ERROR RESULT
16237                                   ;               FPSB:   .WORD   X               ;FPS BEFORE EXECUTION
16238                                   ;               FPSA:   .WORD   X               ;FPS AFTER EXECUTION
16239                                   ;               FEC:    .WORD   X               ;EXPECTED FEC
16240                                   ;               FLAG:   .WORD   X               ;0/-1,OVER/UNDER FLOW FLAG
16241                                   ;               ERR1:   ERROR   X               ;TRAP ERROR.
16242                                   ;               BR      CONT
16243                                   ;               ERR2:   ERROR   X               ;DATA, RESULT ERROR
16244                                   ;               CONT:                           ;RETURN ADDRESS
16245                                   ;
16246                                   ;THE OPERANDS ARE SET UP (USING AC0 AS THE ACCUMULATOR). THEN
16247                                   ;THE MULF INSTRUCTION IS EXECUTED. IF NO TRAP OCCURS THEN THE
16248                                   ;RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS
16249                                   ;COMPARED WITH FPSA IF THIS TOO IS CORRECT OVUNFNT RETURNS CONTROL
16250                                   ;TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD OVUNFNT
16251                                   ;REPORTS THIS FAILURE AND THEN RETURNS TO CONT. IF THE RESULT OF THE
16252                                   ;MULF IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE
16253                                   ;ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN
16254                                   ;THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN OVUNFNT
16255                                   ;WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR2. OTHERWISE THE
16256                                   ;RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND OVUNFNT WILL
16257                                   ;REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.
16258                                   ;IF A TRAP OCCURS (IT SHOULD NOT) THEN OVUNFNT WILL READ THE FEC.
16259                                   ;SHOULD THE FEC MATCH THE ANTICIPATED FEC OVUNFNT WILL
16260                                   ;STORE ALL DATA AND TRANSFER CONTROL TO THE ERROR CALL AT ERR1. IF THE
16261                                   ;FEC IS NOT THE SAME AS THE ANTICIPATED FEC OVUNFNT WILL REPORT
16262                                   ;THE ERROR AND RETURN TO CONT. NOTE THAT OVUNFNT USES THE FLAG
16263                                   ;TO TELL WHETHER OR NOT THESE PARTICULAR OPERANDS WILL RESULT IN
16264                                   ;UNDERFLOW (FLAG=-1) OR OVERFLOW (FLAG=0).
16265
16266  073044  012601                   OVUNFNT:        MOV     (SP)+,R1        ;GET A POINTER TO THE ARGUMENTS.
16267  073046  012700  000200                   MOV     #200,R0         ;SET FD MODE.
16268  073052  170100                           LDFPS   R0
16269
16270  073054  010100                           MOV     R1,R0           ;LOAD AC0. OPERAND.
16271  073056  172410                           LDD     (R0),AC0
16272  073060  016100  000014                   MOV     14(R1),R0       ;LOAD THE FPS
16273  073064  170100                           LDFPS   R0
16274  073066  012737  073146  000244           MOV     #25$,@#FPVECT   ;SET UP THE FP TRAP VECTOR IN CASE
16275                                                                    ;OF ERROR.
16276  073074  010100                           MOV     R1,R0           ;COMPUTE THE ADDRESS OF FSRC.
16277  073076  062700  000004                   ADD     #4,R0
16278
16279  073102  171010                   1$:     MULF    (R0),AC0        ;TEST INSTRUCTION.
16280
16281  073104  170204                   2$:     STFPS   R4              ;GET FPS.
16282  073106  170305                           STST    R5              ;GET FEC.
16283  073110  012700  000200                   MOV     #200,R0         ;SET FD MODE.
16284  073114  170100                           LDFPS   R0
16285  073116  012700  073166                   MOV     #OVFNTT,R0      ;GET THE RESULT.
```

```
                                        STD     AC0,(R0)
                                        MOV     #OVFNTT,R0      ;CHECK THE RESULT.
                                        MOV     R1,R2
                                        ADD     #10,R2
                                        MOV     #2,R3
                                3$:     CMP     (R0)+,(R2)+
                                        BEQ     5$
                                25$:
                                        EMT                     ;
                                5$:     SOB     R3,3$

                                        CMP     16(R1),R4       ;WAS FPS CORRECT?
                                        BEQ     4$
                                        EMT                     ;
                                4$:     JMP     24(R1)          ;RETURN, TEST COMPLETED.

                                OVFNTT: .WORD   0,0,0,0

                                IIIDONE:
                                        JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
                                                                ;SEE IF THE USER HAS EXPRESSED
                                                                ;THE DESIRE TO CHANGE THE SOFTWARE
                                                                ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
                                                                ;THE USER TYPED CONTROL G?).

                                ;*****************************************************************************************
                                ;TEST 470       UNDER\OVER FLOW, USING MULD WITH TRAP DISABLED, TEST
                                ;*****************************************************************************************
073202                          TS470:

                                ;UNDERFLOW, EXPONENT OF RESULT=-129
                                JJJ1:   JSR     PC,@#OVUNDNT
                                1$:     .WORD   20200,0         ;AC
                                        .WORD   127272,0
                                2$:     .WORD   20000,0,0,0     ;FSRC

                                3$:     .WORD   0,0,0,0         ;RES

                                5$:     200                     ;FPS BEFORE EXECUTION.
                                        204                     ;FPS AFTER EXECUTION.
                                6$:     12                      ;FEC
                                        -1                      ;FLAG

                                ;UNDERFLOW, EXPONENT OF RESULT = -193
                                JJJ2:   JSR     PC,@#OVUNDNT
                                1$:     .WORD   10200,0         ;AC
                                        .WORD   123456,0
                                2$:     .WORD   10000,0,0,0     ;FSRC

                                3$:     .WORD   0,0,0,0         ;RES

                                5$:     5213                    ;FPS BEFORE EXECUTION.
```

```
16342  073304  005204                          5204                    ;FPS AFTER EXECUTION.
16343  073306  000012                  6$:     12                      ;FEC
16344  073310  177777                          -1                      ;FLAG
16345
16346                                  ;OVERFLOW, EXPONENT OF RESULT = 128
16347  073312  004737  073426          JJJ3:   JSR     PC,@#OVUNDNT
16348  073316  060200  000000          1$:     .WORD   60200,0         ;AC
16349  073322  065432  000000                  .WORD   65432,0
16350  073326  060000  000000  000000  2$:     .WORD   60000,0,0,0     ;FSRC
16351  073334  000000
16352  073336  000000  000000  000000  3$:     .WORD   0,0,0,0         ;RES
16353  073344  000000
16354  073346  000200                  5$:     200                     ;FPS BEFORE EXECUTION.
16355  073350  000206                          206                     ;FPS AFTER EXECUTION.
16356  073352  000010                  6$:     10                      ;FEC
16357  073354  000000                          0                       ;FLAG
16358
16359                                  ;OVERFLOW, EXPONENT OF RESULT = 130
16360  073356  004737  073426          JJJ4:   JSR     PC,@#OVUNDNT
16361  073362  060200  000000          1$:     .WORD   60200,0         ;AC
16362  073366  125252  000000                  .WORD   125252,0
16363  073372  060200  000000  000000  2$:     .WORD   60200,0,0,0     ;FSRC
16364  073400  000000
16365  073402  000000  000000  000000  3$:     .WORD   0,0,0,0         ;RES
16366  073410  000000
16367  073412  006211                  5$:     6211                    ;FPS BEFORE EXECUTION.
16368  073414  006206                          6206                    ;FPS AFTER EXECUTION.
16369  073416  000010                  6$:     10                      ;FEC
16370  073420  000000                          0                       ;FLAG
16371  073422  000137  073560          8$:     JMP     @#JJJDONE       ;GO TO NEXT TEST
16372
16373                                  ;THIS SUBROUTINE, OVUNDNT, IS USED TO SET UP THE OPERANDS, EXECUTE
16374                                  ;THE MULD INSTRUCTION AND CHECK THE RESULTS OF AN INSTRUCTION WITH
16375                                  ;OPERANDS WHICH SHOULD RESULT IN EITHER OVERFLOW OR UNDERFLOW. A CALL
16376                                  ;TO IT IS MADE THUS:
16377                                  ;
16378                                  ;               ACARG:  .WORD   X,X,X,X         ;AC OPERAND
16379                                  ;               FSRCARG:.WORD   X,X,X,X         ;FSRC OPERAND
16380                                  ;               RES:    .WORD   X,X,X,X         ;EXPECTED RESULT
16381                                  ;               ERRES:  .WORD   X,X,X,X         ;ERROR RESULT
16382                                  ;               FPSB:   .WORD   X               ;FPS BEFORE EXECUTION
16383                                  ;               FPSA:   .WORD   X               ;FPS AFTER EXECUTION
16384                                  ;               FEC:    .WORD   X               ;EXPECTED FEC
16385                                  ;               FLAG:   .WORD   X               ;0/-1,OVER/UNDER FLOW FLAG
16386                                  ;               ERR1:   ERROR   X               ;TRAP ERROR.
16387                                  ;               BR      CONT
16388                                  ;               ERR2:   ERROR   X               ;DATA, RESULT ERROR
16389                                  ;               CONT:                           ;RETURN ADDRESS
16390                                  ;
16391                                  ;THE OPERANDS ARE SET UP (USING AC0 AS THE ACCUMULATOR). THEN
16392                                  ;THE MULD INSTRUCTION IS EXECUTED. IF NO TRAP OCCURS THEN THE
16393                                  ;RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS
16394                                  ;COMPARED WITH FPSA IF THIS TOO IS CORRECT OVUNDNT RETURNS CONTROL
16395                                  ;TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD OVUNDNT
16396                                  ;REPORTS THIS FAILURE AND THEN RETURNS TO CONT. IF THE RESULT OF THE
16397                                  ;MULD IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE
```

```
16398                                   ;ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN
16399                                   ;THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN OVUNDNT
16400                                   ;WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR2. OTHERWISE THE
16401                                   ;RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND OVUNDNT WILL
16402                                   ;REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.
16403                                   ;IF A TRAP OCCURS (IT SHOULD NOT) THEN OVUNDNT WILL READ THE FEC.
16404                                   ;SHOULD THE FEC MATCH THE ANTICIPATED FEC OVUNDNT WILL
16405                                   ;STORE ALL DATA AND TRANSFER CONTROL TO THE ERROR CALL AT ERR1. IF THE
16406                                   ;FEC IS NOT THE SAME AS THE ANTICIPATED FEC OVUNDNT WILL REPORT
16407                                   ;THE ERROR AND RETURN TO CONT. NOTE THAT OVUNDNT USES THE FLAG
16408                                   ;TO TELL WHETHER OR NOT THESE PARTICULAR OPERANDS WILL RESULT IN
16409                                   ;UNDERFLOW (FLAG=-1) OR OVERFLOW (FLAG=0).
16410
16411  073426  012601                   OVUNDNT:    MOV     (SP)+,R1        ;GET A POINTER TO THE ARGUMENTS.
16412  073430  012700  000200                   MOV     #200,R0         ;SET FD MODE.
16413  073434  170100                           LDFPS   R0
16414
16415  073436  010100                           MOV     R1,R0           ;LOAD AC0, OPERAND.
16416  073440  172410                           LDD     (R0),AC0
16417  073442  016100  000030                   MOV     30(R1),R0       ;LOAD THE FPS.
16418  073446  170100                           LDFPS   R0
16419  073450  012737  073530  000244           MOV     #25$,@#FPVECT   ;SET UP THE FP TRAP VECTOR IN CASE
16420                                                                    ;OF ERROR.
16421  073456  010100                           MOV     R1,R0           ;COMPUTE THE ADDRESS OF FSRC.
16422  073460  062700  000010                   ADD     #10,R0
16423
16424  073464  171010                   1$:     MULD    (R0),AC0        ;TEST INSTRUCTION.
16425
16426  073466  170204                   2$:     STFPS   R4              ;GET FPS.
16427  073470  170305                           STST    R5              ;GET FEC.
16428  073472  012700  000200                   MOV     #200,R0         ;SET FD MODE.
16429  073476  170100                           LDFPS   R0
16430  073500  012700  073550                   MOV     #OVDNTT,R0      ;GET THE RESULT.
16431  073504  174010                           STD     AC0,(R0)
16432  073506  012700  073550                   MOV     #OVDNTT,R0      ;CHECK THE RESULT.
16433  073512  010102                           MOV     R1,R2
16434  073514  062702  000020                   ADD     #20,R2
16435  073520  012703  000004                   MOV     #4,R3
16436  073524  022022                   3$:     CMP     (R0)+,(R2)+
16437  073526  001401                           BEQ     5$
16438  073530                           25$:
16439  073530  104000                           EMT                     ;
16440  073532  077304                   5$:     SOB     R3,3$
16441
16442  073534  026104  000032                   CMP     32(R1),R4       ;WAS FPS CORRECT?
16443  073540  001401                           BEQ     4$
16444  073542  104000                           EMT                     ;
16445  073544  000161  000040           4$:     JMP     40(R1)          ;RETURN, TEST COMPLETED.
16446
16447  073550  000000  000000  000000   OVDNTT: .WORD   0,0,0,0
16448  073556  000000
16449
16450  073560                           JJJDONE:
16451  073560  004767  024710                   JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
16452                                                                    ;SEE IF THE USER HAS EXPRESSED
16453                                                                    ;THE DESIRE TO CHANGE THE SOFTWARE
```

```
16454                                                   ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
16455                                                   ;THE USER TYPED CONTROL G?).
16456
16457
16458
16459
16460                                   ;*****************************************************************************************
16461                                   ;TEST 471       UNDER\OVER FLOW, USING MULF WITH TRAPS ENABLED, TEST
16462                                   ;*****************************************************************************************
16463  073564                           TS471:
16464
16465                                   ;UNDERFLOW, EXPONENT OF RESULT = -129
16466  073564  004737  073730           KKK1:   JSR     PC,@#OVUNFT
16467  073570  020123  045676           1$:     .WORD   20123,45676     ;AC
16468  073574  020200  000000           2$:     .WORD   20200,0         ;FSRC
16469  073600  000123  045676           3$:     .WORD   123,45676       ;RES
16470  073604  002000                   5$:     2000                    ;FPS BEFORE EXECUTION.
16471  073606  102004                           102004                  ;FPS AFTER EXECUTION.
16472  073610  000012                   6$:     12                      ;FEC
16473  073612  177777                           -1                      ;FLAG
16474
16475                                   ;UNDERFLOW, EXPONENT OF THE RESULT = -193
16476  073614  004737  073730           KKK3:   JSR     PC,@#OVUNFT
16477  073620  010127  127272           1$:     .WORD   10127,127272    ;AC
16478  073624  010200  000000           2$:     .WORD   10200,0         ;FSRC
16479  073630  060127  127272           3$:     .WORD   60127,127272    ;RES
16480  073634  007017                   5$:     7017                    ;FPS BEFORE EXECUTION.
16481  073636  107000                           107000                  ;FPS AFTER EXECUTION.
16482  073640  000012                   6$:     12                      ;FEC
16483  073642  177777                           -1
16484
16485                                   ;OVERFLOW, EXPONENT OF THE RESULT = 128
16486  073644  004737  073730           KKK4:   JSR     PC,@#OVUNFT
16487  073650  060252  125252           1$:     .WORD   60252,125252    ;AC
16488  073654  060000  000000           2$:     .WORD   60000,0         ;FSRC
16489  073660  000052  125252           3$:     .WORD   000052,125252   ;RES
16490  073664  001000                   5$:     1000                    ;FPS BEFORE EXECUTION.
16491  073666  101006                           101006                  ;FPS AFTER EXECUTION.
16492  073670  000010                   6$:     10                      ;FEC
16493  073672  000000                           0                       ;FLAG
16494
16495                                   ;OVERFLOW, EXPONENT OF RESULT = 130
16496  073674  004737  073730           KKK5:   JSR     PC,@#OVUNFT
16497  073700  060345  067654           1$:     .WORD   60345,67654     ;AC
16498  073704  060200  000000           2$:     .WORD   60200,0         ;FSRC
16499  073710  000345  067654           3$:     .WORD   345,67654       ;RES
16500  073714  007015                   5$:     7015                    ;FPS BEFORE EXECUTION.
16501  073716  107002                           107002                  ;FPS AFTER EXECUTION.
16502  073720  000010                   6$:     10                      ;FEC
16503  073722  000000                           0                       ;FLAG
16504  073724  000167  000162           8$:     JMP     KKKDONE
16505
16506                                   ;THIS SUBROUTINE, OVUNFT, IS USED TO SET UP THE OPERANDS, EXECUTE
16507                                   ;THE MULF INSTRUCTION AND CHECK THE RESULTS OF AN INSTRUCTION WITH
16508                                   ;OPERANDS WHICH SHOULD RESULT IN EITHER OVERFLOW OR UNDERFLOW. A CALL
16509                                   ;TO IT IS MADE THUS:
```

```
16510                                   ;
16511                                   ;       ACARG:  .WORD   X,X             ;AC OPERAND
16512                                   ;       FSRCARG:.WORD   X,X             ;FSRC OPERAND
16513                                   ;       RES:    .WORD   X,X             ;EXPECTED RESULT
16514                                   ;       ERRES:  .WORD   X,X             ;ERROR RESULT
16515                                   ;       FPSB:   .WORD   X               ;FPS BEFORE EXECUTION
16516                                   ;       FPSA:   .WORD   X               ;FPS AFTER EXECUTION
16517                                   ;       FEC:    .WORD   X               ;EXPECTED FEC
16518                                   ;       FLAG:   .WORD   X               ;0/-1,OVER/UNDER FLOW FLAG
16519                                   ;       ERR1:   ERROR   X               ;TRAP ERROR.
16520                                   ;       BR      CONT
16521                                   ;       ERR2:   ERROR   X               ;DATA, RESULT ERROR
16522                                   ;       CONT:                           ;RETURN ADDRESS
16523                                   ;
16524                                   ;THE OPERANDS ARE SET UP (USING AC0 AS THE ACCUMULATOR). THEN
16525                                   ;THE MULF INSTRUCTION IS EXECUTED. IF THE TRAP OCCURS THEN THE
16526                                   ;RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS
16527                                   ;COMPARED WITH FPSA IF THIS TOO IS CORRECT OVUNFT RETURNS CONTROL
16528                                   ;TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD OVUNFT
16529                                   ;REPORTS THIS FAILURE AND THEN RETURNS TO CONT. THE FEC IS TREATED
16530                                   ;IN THE SAME WAY. IF THE RESULT OF THE
16531                                   ;MULF IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE
16532                                   ;ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN
16533                                   ;THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN OVUNFT
16534                                   ;WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR2. OTHERWISE THE
16535                                   ;RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND OVUNFT WILL
16536                                   ;REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.
16537                                   ;IF NO TRAP OCCURS CONTROL IS PASSED TO ERR1.
16538                                   ;NOTE THAT OVUNFNT USES THE FLAG
16539                                   ;TO TELL WHETHER OR NOT THESE PARTICULAR OPERANDS WILL RESULT IN
16540                                   ;UNDERFLOW (FLAG=-1) OR OVERFLOW (FLAG=0).
16541
16542  073730  012601                   OVUNFT: MOV     (SP)+,R1        ;GET A POINTER TO THE ARGUMENTS.
16543  073732  012700  000200                   MOV     #200,R0         ;SET FD MODE.
16544  073736  170100                           LDFPS   R0
16545  073740  010100                           MOV     R1,R0           ;LOAD AC0, OPERAND.
16546  073742  172410                           LDD     (R0),AC0
16547  073744  016100  000014                   MOV     14(R1),R0       ;LOAD THE FPS.
16548  073750  170100                           LDFPS   R0
16549  073752  012737  073774  000244           MOV     #50$,a#FPVECT   ;SET UP THE FP TRAP VECTOR IN CASE
16550                                                                   ;OF ERROR.
16551  073760  010100                           MOV     R1,R0           ;COMPUTE THE ADDRESS OF FSRC.
16552  073762  062700  000004                   ADD     #4,R0
16553
16554  073766  171010                   1$:     MULF    (R0),AC0        ;TEST INSTRUCTION. SHOULD CAUSE TRAP.
16555  073770  170000                   2$:     CFCC
16556  073772  104000                           EMT                     ;
16557  073774  011602                   50$:    MOV     (SP),R2         ;TRAP TO HERE AND SEE IF THE PC OF THE
16558  073776  020227  073770                   CMP     R2,#2$          ;TRAP WAS THAT OF THE MULF INSTRUCTION.
16559  074002  001401                           BEQ     51$
16560  074004  104000                           EMT                     ;
16561  074006  022626                   51$:    CMP     (SP)+,(SP)+     ;RESET THE STACK
16562  074010  170204                           STFPS   R4              ;GET FPS.
16563  074012  170305                           STST    R5              ;GET FEC.
16564  074014  012700  000200                   MOV     #200,R0         ;SET FD MODE.
16565  074020  170100                           LDFPS   R0
```

```
16566  074022  012700  074102            MOV     #OVFTT,R0       ;GET THE RESULT.
16567  074026  174010                    STD     AC0,(R0)
16568  074030  012700  074102            MOV     #OVFTT,R0       ;CHECK THE RESULT.
16569  074034  010102                    MOV     R1,R2
16570  074036  062702  000010            ADD     #10,R2
16571  074042  012703  000002            MOV     #2,R3
16572  074046  022022            3$:     CMP     (R0)+,(R2)+
16573  074050  001401                    BEQ     5$
16574  074052  104000                    EMT                     ;
16575  074054  077304            5$:     SOB     R3,3$
16576
16577  074056  026104  000016            CMP     16(R1),R4       ;WAS FPS CORRECT?
16578  074062  001401                    BEQ     6$
16579  074064  104000                    EMT                     ;
16580  074066  026105  000020    6$:     CMP     20(R1),R5       ;IS FEC CORRECT?
16581  074072  001401                    BEQ     4$
16582  074074  104000                    EMT                     ;
16583  074076  000161  000024    4$:     JMP     24(R1)          ;RETURN, TEST COMPLETED.
16584
16585  074102  000000  000000  000000 OVFTT:  .WORD   0,0,0,0
16586  074110  000000
16587
16588  074112                    KKKDONE:
16589  074112  004767  024356            JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
16590                                                            ;SEE IF THE USER HAS EXPRESSED
16591                                                            ;THE DESIRE TO CHANGE THE SOFTWARE
16592                                                            ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
16593                                                            ;THE USER TYPED CONTROL G?).
16594
16595
16596
16597
16598                                    ;*****************************************************************************************
16599                                    ;TEST 472       UNDER\OVER FLOW, USING MULD WITH TRAPS ENABLED, TEST
16600                                    ;*****************************************************************************************
16601  074116                    TS472:
16602
16603                                    ;UNDERFLOW, EXPONENT OF RESULT = -129
16604  074116  004737  074342    LLL1:   JSR     PC,@#OVUNDT
16605  074122  020052  125252    1$:     .WORD   20052,125252    ;AC
16606  074126  125252  125252            .WORD   125252,125252
16607  074132  020300  000000  000000 2$:  .WORD   20300,0,0,0    ;FSRC
16608  074140  000000
16609  074142  000177  177777  177777 3$:  .WORD   177,-1,-1,-1   ;RES
16610  074150  177777
16611  074152  002200            5$:     2200                    ;FPS BEFORE EXECUTION.
16612  074154  102204                    102204                  ;FPS AFTER EXECUTION.
16613  074156  000012            6$:     12                      ;FEC
16614  074160  177777                    -1                      ;FLAG
16615
16616                                   ;UNDERFLOW, EXPONENT OF THE RESULT = -193
16617  074162  004737  074342    LLL2:   JSR     PC,@#OVUNDT
16618  074166  010327  127272    1$:     .WORD   10327,127272    ;AC
16619  074172  036363  045454            .WORD   36363,45454
16620  074176  010000  000000  000000 2$:  .WORD   10000,0,0,0    ;FSRC
16621  074204  000000
```

```
16622  074206  060127  127272          3$:     .WORD   60127,127272    ;RES
16623  074212  036363  045454                  .WORD   36363,45454
16624  074216  007217                  5$:     7217                    ;FPS BEFORE EXECUTION.
16625  074220  107200                          107200                  ;FPS AFTER EXECUTION.
16626  074222  000012                  6$:     12                      ;FEC
16627  074224  177777                          -1                      ;FLAG
16628
16629                                  ;OVERFLOW, EXPONENT OF THE RESULT = 128
16630  074226  004737  074342          LLL3:   JSR     PC,@#OVUNDT
16631  074232  060252  125252          1$:     .WORD   60252,125252    ;AC
16632  074236  125252  125252                  .WORD   125252,125252   ;FSRC
16633  074242  160100  000000  000000 2$:     .WORD   160100,0,0,0    ;FSRC
16634  074250  000000
16635  074252  100177  177777  177777 3$:     .WORD   100177,-1,-1,-1 ;RES
16636  074260  177777
16637  074262  001200                  5$:     1200                    ;FPS BEFORE EXECUTION.
16638  074264  101216                          101216                  ;FPS AFTER EXECUTION.
16639  074266  000010                  6$:     10                      ;FEC
16640  074270  000000                          0                       ;FLAG
16641
16642                                  ;OVERFLOW, EXPONENT OF THE RESULT = 130
16643  074272  004737  074342          LLL4:   JSR     PC,@#OVUNDT
16644  074276  060345  067654          1$:     .WORD   60345,67654     ;AC
16645  074302  056765  045676                  .WORD   56765,45676
16646  074306  060200  000000  000000 2$:     .WORD   60200,0,0,0     ;FSRC
16647  074314  000000
16648  074316  000345  067654          3$:     .WORD   345,67654       ;RES
16649  074322  056765  045676                  .WORD   56765,45676
16650  074326  007215                  5$:     7215                    ;FPS BEFORE EXECUTION.
16651  074330  107202                          107202                  ;FPS AFTER EXECUTION.
16652  074332  000010                  6$:     10                      ;FEC
16653  074334  000000                          0                       ;FLAG
16654  074336  000137  074524          8$:     JMP     @#LLLDONE
16655
16656                                  ;THIS SUBROUTINE, OVUNDT, IS USED TO SET UP THE OPERANDS, EXECUTE
16657                                  ;THE MULD INSTRUCTION AND CHECK THE RESULTS OF AN INSTRUCTION WITH
16658                                  ;OPERANDS WHICH SHOULD RESULT IN EITHER OVERFLOW OR UNDERFLOW. A CALL
16659                                  ;TO IT IS MADE THUS:
16660                                  ;
16661                                  ;               ACARG:  .WORD   X,X,X,X         ;AC OPERAND
16662                                  ;               FSRCARG:.WORD   X,X,X,X         ;FSRC OPERAND
16663                                  ;               RES:    .WORD   X,X,X,X         ;EXPECTED RESULT
16664                                  ;               ERRES:  .WORD   X,X,X,X         ;ERROR RESULT
16665                                  ;               FPSB:   .WORD   X               ;FPS BEFORE EXECUTION
16666                                  ;               FPSA:   .WORD   X               ;FPS AFTER EXECUTION
16667                                  ;               FEC:    .WORD   X               ;EXPECTED FEC
16668                                  ;               FLAG:   .WORD   X               ;0/-1,OVER/UNDER FLOW FLAG
16669                                  ;               ERR1:   ERROR   X               ;TRAP ERROR.
16670                                  ;               BR      CONT
16671                                  ;               ERR2:   ERROR   X               ;DATA, RESULT ERROR
16672                                  ;               CONT:                           ;RETURN ADDRESS
16673                                  ;
16674                                  ;THE OPERANDS ARE SET UP (USING AC0 AS THE ACCUMULATOR). THEN
16675                                  ;THE MULD INSTRUCTION IS EXECUTED. IF THE TRAP OCCURS THEN THE
16676                                  ;RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS
16677                                  ;COMPARED WITH FPSA IF THIS TOO IS CORRECT OVUNDT RETURNS CONTROL
```

```
                                        ;TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD OVUNDT
                                        ;REPORTS THIS FAILURE AND THEN RETURNS TO CONT. THE FEC IS TREATED
                                        ;IN THE SAME WAY. IF THE RESULT OF THE
                                        ;MULF IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE
                                        ;ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN
                                        ;THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN OVUNDT
                                        ;WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR2. OTHERWISE THE
                                        ;RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND OVUNDT WILL
                                        ;REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.
                                        ;IF NO TRAP OCCURS CONTROL IS PASSED TO ERR1.
                                        ;NOTE THAT OVUNDNT USES THE FLAG
                                        ;TO TELL WHETHER OR NOT THESE PARTICULAR OPERANDS WILL RESULT IN
                                        ;UNDERFLOW (FLAG=-1) OR OVERFLOW (FLAG=0).

074342  012601              OVUNDT: MOV     (SP)+,R1        ;GET A POINTER TO THE ARGUMENTS.
074344  012700  000200              MOV     #200,R0         ;SET FD MODE.
074350  170100                      LDFPS   R0

074352  010100                      MOV     R1,R0           ;LOAD AC0, OPERAND.
074354  172410                      LDD     (R0),AC0
074356  016100  000030              MOV     30(R1),R0       ;LOAD THE FPS.
074362  170100                      LDFPS   R0
074364  012737  074406  000244      MOV     #50$,@#FPVECT   ;SET UP THE FP TRAP VECTOR IN CASE
                                                            ;OF ERROR.
074372  010100                      MOV     R1,R0           ;COMPUTE THE ADDRESS OF FSRC.
074374  062700  000010              ADD     #10,R0

074400  171010              1$:     MULD    (R0),AC0        ;TEST INSTRUCTION. SHOULD CAUSE TRAP.
074402  170000              2$:     CFCC
074404  104000                      EMT                     ;
074406  011602              50$:    MOV     (SP),R2         ;TRAP TO HERE AND SEE IF THE PC OF THE
074410  020227  074402              CMP     R2,#2$          ;TRAP WAS THAT OF THE MULF INSTRUCTION.
074414  001401                      BEQ     51$             ;BRANCH IF YES.
074416  104000                      EMT                     ;
074420  022626              51$:    CMP     (SP)+,(SP)+     ;RESET THE STACK
074422  170204                      STFPS   R4              ;GET FPS.
074424  170305                      STST    R5              ;GET FEC.
074426  012700  000200              MOV     #200,R0         ;SET FD MODE.
074432  170100                      LDFPS   R0
074434  012700  074514              MOV     #OVDTT,R0       ;GET THE RESULT.
074440  174010                      STD     AC0,(R0)
074442  012700  074514              MOV     #OVDTT,R0       ;CHECK THE RESULT.
074446  010102                      MOV     R1,R2
074450  062702  000020              ADD     #20,R2
074454  012703  000004              MOV     #4,R3
074460  022022              3$:     CMP     (R0)+,(R2)+
074462  001401                      BEQ     5$
074464  104000                      EMT                     ;
074466  077304              5$:     SOB     R3,3$
074470  026104  000032              CMP     32(R1),R4       ;WAS FPS CORRECT?
074474  001401                      BEQ     6$
074476  104000                      EMT                     ;
074500  026105  000034      6$:     CMP     34(R1),R5       ;IS FEC CORRECT?
074504  001401                      BEQ     4$
074506  104000                      EMT                     ;
074510  000161  000040      4$:     JMP     40(R1)          ;RETURN, TEST COMPLETED.
```

```
16734
16735  074514  000000  000000  000000  OVDTT:  .WORD   0,0,0,0
16736  074522  000000
16737
16738  074524                          LLLDONE:
16739  074524  004767  023744                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
16740                                                                  ;SEE IF THE USER HAS EXPRESSED
16741                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
16742                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
16743                                                                  ;THE USER TYPED CONTROL G?).
16744
16745
16746
16747
16748                                  ;*************************************************************************************************
16749                                  ;TEST 473       MODF TEST
16750                                  ;*************************************************************************************************
16751
16752  074530                          TS473:
16753
16754                                  ;MODF WITH (FSRC=AC=0)
16755  074530  004737  075254          GGG1:   JSR     PC,@#MODFSUB
16756  074534  000000  000000          1$:     .WORD   0,0             ;AC
16757  074540  000000  000000          2$:     .WORD   0,0             ;FSRC
16758  074544  000000  000000          3$:     .WORD   0,0             ;FRACTIONAL RES.
16759  074550  000000  000000          4$:     .WORD   0,0             ;INTEGER RES.
16760  074554  000013                  7$:     13                      ;FPS BEFORE EXECUTION.
16761  074556  000004                          4                       ;FPS AFTER EXECUTION.
16762
16763                                  ;MODF TEST, WITH (FSRC=0)
16764  074560  004737  075254          GGG2:   JSR     PC,@#MODFSUB
16765  074564  123456  076543          1$:     .WORD   123456,76543    ;AC
16766  074570  000000  000000          2$:     .WORD   0,0             ;FSRC
16767  074574  000000  000000          3$:     .WORD   0,0             ;FRACTIONAL RES.
16768  074600  000000  000000          4$:     .WORD   0,0             ;INTEGER RESULT.
16769  074604  000000                  7$:     0                       ;FPS BEFORE EXECUTION.
16770  074606  000004                          4                       ;FPS AFTER EXECUTION.
16771
16772                                  ;MODF TEST WITH (AC=0)
16773  074610  004737  075254          GGG3:   JSR     PC,@#MODFSUB
16774  074614  000000  000000          1$:     .WORD   0,0             ;AC
16775  074620  076543  021234          2$:     .WORD   76543,21234     ;FSRC
16776  074624  000000  000000          3$:     .WORD   0,0             ;FRACTIONAL RES.
16777  074630  000000  000000          4$:     .WORD   0,0             ;INTEGER RES.
16778  074634  000003                  7$:     3                       ;FPS BEFORE EXECUTION.
16779  074636  000004                          4                       ;FPS AFTER EXECUTION.
16780
16781                                  ;MODF TEST WITH EXPONENT OF THE RESULT = 25
16782  074640  004737  075254          GGG4:   JSR     PC,@#MODFSUB
16783  074644  046252  125252          1$:     .WORD   46252,125252    ;AC
16784  074650  040300  000000          2$:     .WORD   40300,0         ;FSRC
16785  074654  000000  000000          3$:     .WORD   0,0             ;FRACTIONAL RES.
16786  074660  046377  177777          4$:     .WORD   46377,-1        ;INTEGER RES.
16787  074664  000013                  7$:     13                      ;FPS BEFORE EXECUTION.
16788  074666  000004                          4                       ;FPS AFTER EXECUTION.
16789
```

```
16790
16791  074670  004737  075254          ;MODF TEST WITH EXPONENT OF THE RESULT = 127
16792  074674  077652  125252  GGG5:   JSR     PC,@#MODFSUB
16793  074700  040300  000000  1$:     .WORD   77652,125252    ;AC
16794  074704  000000  000000  2$:     .WORD   40300,0         ;FSRC
16795  074710  077777  177777  3$:     .WORD   0,0             ;FRACTIONAL RES.
16796  074714  000000          4$:     .WORD   77777,-1        ;INTEGER RES.
16797  074716  000004          7$:     0                       ;FPS BEFORE EXECUTION.
16798                                  4                       ;FPS AFTER EXECUTION.
16799
16800  074720  004737  075254          ;MODF TEST WITH EXPONENT OF RESULT = 25
16801  074724  046200  000001  GGG6:   JSR     PC,@#MODFSUB
16802  074730  040340  000000  1$:     .WORD   46200,1         ;AC
16803  074734  000000  000000  2$:     .WORD   40340,0         ;FSRC
16804  074740  046340  000001  3$:     .WORD   0,0             ;FRACTIONAL RES.
16805  074744  000013          4$:     .WORD   46340,1         ;INTEGER RES.
16806  074746  000004          7$:     13                      ;FPS BEFORE EXECUTION.
16807                                  4                       ;FPS AFTER EXECUTION.
16808
16809  074750  004737  075254          ;MODF   TEST WITH EXPONENT OF THE RESULT = 24
16810  074754  046000  000001  GGG7:   JSR     PC,@#MODFSUB
16811  074760  040340  000000  1$:     .WORD   46000,1         ;AC
16812  074764  040100  000000  2$:     .WORD   40340,0         ;FSRC
16813  074770  046140  000001  3$:     .WORD   40100,0         ;FRACTIONAL RES.
16814  074774  000000          4$:     .WORD   46140,1         ;INTEGER RESULT.
16815  074776  000000          7$:     0                       ;FPS BEFORE EXECUTION.
16816                                  0                       ;FPS AFTER EXECUTION.
16817
16818  075000  004737  075254          ;MODF TEST WITH EXPONENT OF THE RESULT = 10
16819  075004  042577  177777  GGG8:   JSR     PC,@#MODFSUB
16820  075010  040200  000000  1$:     .WORD   42577,-1        ;AC
16821  075014  040177  176000  2$:     .WORD   40200,0         ;FSRC
16822  075020  042577  140000  3$:     .WORD   40177,176000    ;FRACTIONAL RES.
16823  075024  000000          4$:     .WORD   42577,140000    ;INTEGER RES.
16824  075026  000000          7$:     0                       ;FPS BEFORE EXECUTION.
16825                                  0                       ;FPS AFTER EXECUTION.
16826
16827  075030  004737  075254          ;MODF TEST WITH THE EXPONENT OF THE RESULT = 10
16828  075034  042577  140001  GGG9:   JSR     PC,@#MODFSUB
16829  075040  040200  000000  1$:     .WORD   42577,140001    ;AC
16830  075044  034600  000000  2$:     .WORD   40200,0         ;FSRC
16831  075050  042577  140000  3$:     .WORD   34600,0         ;FRACTIONAL RES.
16832  075054  000000          4$:     .WORD   42577,140000    ;INTEGER RES.
16833  075056  000000          7$:     0                       ;FPS BEFORE EXECUTION.
16834                                  0                       ;FPS AFTER EXECUTION.
16835
16836  075060  004737  075254          ;MODF TEST WITH EXPONENT OF THE RESULT = 9
16837  075064  042377  100000  GGG10:  JSR     PC,@#MODFSUB
16838  075070  040200  000000  1$:     .WORD   42377,100000    ;AC
16839  075074  000000  000000  2$:     .WORD   40200,0         ;FSRC
16840  075100  042377  100000  3$:     .WORD   0,0             ;FRACTIONAL RES.
16841  075104  000013          4$:     .WORD   42377,100000    ;INTEGER RES.
16842  075106  000004          7$:     13                      ;FPS BEFORE EXECUTION.
16843                                  4                       ;FPS AFTER EXECUTION.
16844
16845  075110  004737  075254          ;MODF TEST WITH EXPONENT OF THE RESULT = 0
                               GGG11:  JSR     PC,@#MODFSUB
```

```
16846  075114  040177  177777          1$:     .WORD   40177,-1         ;AC
16847  075120  040200  000000          2$:     .WORD   40200,0          ;FSRC
16848  075124  040177  177777          3$:     .WORD   40177,-1         ;FRACTIONAL RES.
16849  075130  000000  000000          4$:     .WORD   0,0              ;INTEGER RES.
16850  075134  000017                  7$:     17                       ;FPS BEFORE EXECUTION.
16851  075136  000000                          0                        ;FPS AFTER EXECUTION.
16852
16853                                  ;MODF TEST WITH EXPONENT OF THE RESULT = -15
16854  075140  004737  075254          GGG12:  JSR     PC,@#MODFSUB
16855  075144  034377  177777          1$:     .WORD   34377,-1         ;AC
16856  075150  040200  000000          2$:     .WORD   40200,0          ;FSRC
16857  075154  034377  177777          3$:     .WORD   34377,-1         ;FRACTIONAL RES.
16858  075160  000000  000000          4$:     .WORD   0,0              ;INTEGER RES.
16859  075164  000000                  7$:     0                        ;FPS BEFORE EXECUTION.
16860  075166  000000                          0                        ;FPS AFTER EXECUTION.
16861
16862                                  ;MODF TEST WITH EXPONENT OF RESULT = -64, IN ROUND MODE
16863  075170  004737  075254          GGG13:  JSR     PC,@#MODFSUB
16864  075174  020000  000001          1$:     .WORD   20000,1          ;AC
16865  075200  040300  000000          2$:     .WORD   40300,0          ;FSRC
16866  075204  020100  000002          3$:     .WORD   20100,2          ;FRACTIONAL RES.
16867  075210  000000  000000          4$:     .WORD   0,0              ;INTEGER RES.
16868  075214  000000                  7$:     0                        ;FPS BEFORE EXECUTION.
16869  075216  000000                          0                        ;FPS AFTER EXECUTION.
16870
16871                                  ;MODF TEST WITH EXPONENT OF RESULT = 11
16872  075220  004737  075254          GGG14:  JSR     PC,@#MODFSUB
16873  075224  142777  170000          1$:     .WORD   142777,170000    ;AC
16874  075230  040200  000000          2$:     .WORD   40200,0          ;FSRC
16875  075234  140000  000000          3$:     .WORD   140000,0         ;FRACTIONAL RES.
16876  075240  142777  160000          4$:     .WORD   142777,160000    ;INTEGER RES.
16877  075244  000007                  7$:     7                        ;FPS BEFORE EXECUTION.
16878  075246  000010                          10                       ;FPS AFTER EXECUTION.
16879  075250  000167  000204          9$:     JMP     GGGDONE          ;GO TO NEXT TEST.
16880
16881
16882                                  ;THIS SUBROUTINE, MODFSUB, IS CALLED TO SETUP THE
16883                                  ;OPERANDS, EXECUTE THE MODF INSTRUCTION AND CHECK THE RESULTS.
16884                                  ;IT IS CALLED THUS:
16885                                  ;
16886                                  ;               ACARG:   .WORD   X,X             ;AC OPERAND
16887                                  ;               FSRCARG: .WORD   X,X             ;FSRC OPERAND
16888                                  ;               FRES:    .WORD   X,X             ;FRACTIONAL RESULT
16889                                  ;               INTRES:  .WORD   X,X             ;INTEGER RESULT
16890                                  ;               ERFRES:  .WORD   X,X             ;ERROR FRACTION RESULT
16891                                  ;               ERINTRES:.WORD   X,X             ;ERROR INTEGER RESULT
16892                                  ;               FPSB:    .WORD   X               ;FPS BEFORE EXECUTION
16893                                  ;               FPSA:    .WORD   X               ;FPS AFTER EXECUTION
16894                                  ;               ERR1:    ERROR   X               ;FRACTION ERROR
16895                                  ;                        BR      CONT
16896                                  ;               ERR2:    ERROR   X               ;INTEGER ERROR
16897                                  ;               CONT:                            ;RETURN ADDRESS
16898                                  ;
16899                                  ;THE OPERANDS ARE SET UP (USING AC0 FOR THE AC ARGUMENT). THE MODF
16900                                  ;INSTRUCTION IS EXECUTED. THEN THE RESULTS ARE RETRIEVED.
16901                                  ;THE FRACTION PART OF THE RESULT IS COMPARED WITH FRES. IF THIS IS CORRECT
```

```
16902                                   ;THEN THE INTEGER PART IS COMPARED WITH INTRES. IF BOTH OF THESE ARE CORRECT
16903                                   ;THEN THE FPS IS COMPARED WITH FPSA. AFTER EXECUTION IF NO ERRORS OCCURRED
16904                                   ;THEN MODFSUB WILL RETURN TO CONT. IF THE FPS WAS INCORRECT
16905                                   ;IT IS REPORTED HERE. IF THE FRACTION IS INCORRECT IT IS COMPARED WITH
16906                                   ;THE ANTICIPATED BAD FRACTION, ERFRES. IF THIS DOESN'T MATCH
16907                                   ;THE TRUE RESULT THEN THE ERROR IS REPORTED HERE. IF THE ANTICIPATED
16908                                   ;FAILURE MATCHES THE TRUE RESULT THEN  MODFSUB PASSES CONTROL TO THE
16909                                   ;ERROR CALL AT ERR1. LIKEWISE IF THE INTEGER PART OF THE RESULT IS
16910                                   ;NOT CORRECT THEN IT IS COMPARED WITH THE ANTICIPATED INTEGER
16911                                   ;FAILURE. IF THIS DOEN'T MATCH THEN THE ERROR IS REPORTED HERE.
16912                                   ;IF A MATCH IS MADE HOWEVER, MODFSUB WILL RETURN CONTROL TO THE ERROR
16913                                   ;CALL AT ERR2.
16914
16915  075254  012601                   MODFSUB:        MOV     (SP)+,R1        ;GET A POINTER TO THE ARGUMENTS
16916  075256  012700  000200                   MOV     #200,R0         ;SET FD MODE.
16917  075262  170100                           LDFPS   R0
16918  075264  010100                           MOV     R1,R0           ;SET UP AC0
16919  075266  172410                           LDD     (R0),AC0
16920  075270  012700  075450                   MOV     #MODP1,R0       ;PUT A BACKROUND PATTERN INTO AC1.
16921  075274  172510                           LDD     (R0),AC1
16922  075276  016100  000020                   MOV     20(R1),R0       ;SET UP THE FFS.
16923  075302  170100                           LDFPS   R0
16924  075304  010100                           MOV     R1,R0           ;COMPUTE THE ADDRESS OF THE FSRC.
16925  075306  062700  000004                   ADD     #4,R0
16926
16927  075312  171410                   1$:     MODF    (R0),AC0        ;EXECUTE THE TEST INSTRUCTION.
16928
16929  075314  170204                           STFPS   R4              ;GET THE FPS.
16930  075316  012700  000200                   MOV     #200,R0         ;SET FD MODE.
16931  075322  170100                           LDFPS   R0
16932  075324  012700  075430                   MOV     #MODFT0,R0      ;GET THE FRACTIONAL RESULT.
16933  075330  174010                           STD     AC0,(R0)
16934  075332  012700  075440                   MOV     #MODFT1,R0      ;GET THE INTEGER RESULT.
16935  075336  174110                           STD     AC1,(R0)
16936  075340  012702  075430                   MOV     #MODFT0,R2      ;CHECK THE FRACTIONAL RESULT.
16937  075344  026112  000010                   CMP     10(R1),(R2)
16938  075350  001401                           BEQ     2$
16939  075352  104000                           EMT                     ;
16940  075354  026162  000012  000002   2$:     CMP     12(R1),2(R2)
16941  075362  001401                           BEQ     3$
16942  075364  104000                           EMT                     ;
16943  075366  012702  075440           3$:     MOV     #MODFT1,R2      ;CHECK THE INTEGER RESULT.
16944  075372  026112  000014                   CMP     14(R1),(R2)
16945  075376  001401                           BEQ     4$
16946  075400  104000                           EMT                     ;
16947  075402  026162  000016  000002   4$:     CMP     16(R1),2(R2)
16948  075410  001401                           BEQ     5$
16949  075412  104000                           EMT                     ;
16950  075414  026104  000022           5$:     CMP     22(R1),R4       ;CHECK THE FPS.
16951  075420  001401                           BEQ     9$
16952  075422  104000                           EMT                     ;
16953  075424  000161  000024           9$:     JMP     24(R1)          ;RETURN.
16954
16955  075430  000000  000000  000000   MODFT0: .WORD   0,0,0,0
16956  075436  000000
16957
```

```
16958  075440  000000  000000  000000  MODFT1: .WORD   0,0,0,0
16959  075446  000000
16960
16961  075450  177777  177777  177777  MODP1:  .WORD   -1,-1,-1,-1
16962  075456  177777
16963
16964  075460                          GGGDONE:
16965  075460  004767  023010                  JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
16966                                                                  ;SEE IF THE USER HAS EXPRESSED
16967                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
16968                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
16969                                                                  ;THE USER TYPED CONTROL G?).
16970
16971
16972
16973
16974                                   ;*****************************************************************************************
16975                                   ;TEST 474       MODD TEST
16976                                   ;*****************************************************************************************
16977  075464                           TS474:
16978
16979                                   ;MODD WITH (FSRC=AC=0)
16980  075464  004737  076500           HHH1:   JSR     PC,@#MODDSUB
16981  075470  000000  000000  000000   1$:     .WORD   0,0,0,0         ;AC
16982  075476  000000
16983  075500  000000  000000  000000   2$:     .WORD   0,0,0,0         ;FSRC
16984  075506  000000
16985  075510  000000  000000  000000   3$:     .WORD   0,0,0,0         ;FRACTIONAL RES.
16986  075516  000000
16987  075520  000000  000000  000000   4$:     .WORD   0,0,0,0         ;INTEGER RES.
16988  075526  000000
16989  075530  000200                   7$:     200                     ;FPS BEFORE EXECUTION.
16990  075532  000204                           204                     ;FPS AFTER EXECUTION.
16991
16992                                   ;MODD TEST WITH FSRC=0
16993  075534  004737  076500           HHH2:   JSR     PC,@#MODDSUB
16994  075540  012345  067012           1$:     .WORD   012345,67012    ;AC
16995  075544  034567  012345                   .WORD   34567,012345
16996  075550  000000  000000  000000   2$:     .WORD   0,0,0,0         ;FSRC
16997  075556  000000
16998  075560  000000  000000  000000   3$:     .WORD   0,0,0,0         ;FRACTIONAL RES.
16999  075566  000000
17000  075570  000000  000000  000000   4$:     .WORD   0,0,0,0         ;INTEGER RES.
17001  075576  000000
17002  075600  000213                   7$:     213                     ;FPS BEFORE EXECUTION.
17003  075602  000204                           204                     ;FPS AFTER EXECUTION.
17004
17005                                   ;MODD TEST WITH (AC=0)
17006  075604  004737  076500           HHH3:   JSR     PC,@#MODDSUB
17007  075610  000000  000000  000000   1$:     .WORD   0,0,0,0         ;AC
17008  075616  000000
17009  075620  072727  127272           2$:     .WORD   72727,127272    ;FSRC
17010  075624  072727  127272                   .WORD   72727,127272
17011  075630  000000  000000  000000   3$:     .WORD   0,0,0,0         ;FRACTIONAL RES.
17012  075636  000000
17013  075640  000000  000000  000000   4$:     .WORD   0,0,0,0         ;INTEGER RES.
```

```
17014  075646  C00000
17015  075650  000213                    7$:     213                     ;FPS BEFORE EXECUTION.
17016  075652  000204                            204                     ;FPS AFTER EXECUTION.
17017
17018                                    ;MODD TEST WITH EXPONENT OF THE RESULT = 57
17019  075654  004737  076500            HHH4:   JSR     PC,@#MODDSUB
17020  075660  056252  125252            1$:     .WORD   56252,125252    ;AC
17021  075664  125252  125250                    .WORD   125252,125250
17022  075670  040300  000000  000000    2$:     .WORD   40300,0,0,0     ;FSRC
17023  075676  000000
17024  075700  000000  000000  000000    3$:     .WORD   0,0,0,0         ;FRACTIONAL RES.
17025  075706  000000
17026  075710  056377  177777  177777    4$:     .WORD   56377,-1,-1,-4  ;INTEGER RES.
17027  075716  177774
17028  075720  000213                    7$:     213                     ;FPS BEFORE EXECUTION.
17029  075722  000204                            204                     ;FPS AFTER EXECUTION.
17030
17031                                    ;MODD TEST WITH EXPONENT OF THE RESULT = 79
17032  075724  004737  076500            HHH5:   JSR     PC,@#MODDSUB
17033  075730  140240  000000  000000    1$:     .WORD   140240,0,0,0    ;AC
17034  075736  000000
17035  075740  063714  146314            2$:     .WORD   63714,146314    ;FSRC
17036  075744  133572  167737                    .WORD   133572,167737
17037  075750  000000  000000  000000    3$:     .WORD   0,0,0,0         ;FRACTIONAL RES.
17038  075756  000000
17039  075760  163777  177777            4$:     .WORD   163777,-1       ;INTEGER RES.
17040  075764  162531  125726                    .WORD   162531,125726
17041  075770  000210                    7$:     210                     ;FPS BEFORE EXECUTION.
17042  075772  000204                            204                     ;FPS AFTER EXECUTION.
17043
17044                                    ;MODD TEST WITH EXPONENT OF THE RESULT = 57
17045  075774  004737  076500            HHH6:   JSR     PC,@#MODDSUB
17046  076000  056200  000000  000000    1$:     .WORD   56200,0,0,1     ;AC
17047  076006  000001
17048  076010  040340  000000  000000    2$:     .WORD   40340,0,0,0     ;FSRC
17049  076016  000000
17050  076020  000000  000000  000000    3$:     .WORD   0,0,0,0         ;FRACTIONAL RES.
17051  076026  000000
17052  076030  056340  000000  000000    4$:     .WORD   56340,0,0,1     ;INTEGER RES.
17053  076036  000001
17054  076040  000213                    7$:     213                     ;FPS BEFORE EXECUTION.
17055  076042  000204                            204                     ;FPS AFTER EXECUTION.
17056
17057                                    ;MODD TEST WITH EXPONENT OF THE RESULT = 56
17058  076044  004737  076500            HHH7:   JSR     PC,@#MODDSUB
17059  076050  056000  000000  000000    1$:     .WORD   56000,0,0,1     ;AC
17060  076056  000001
17061  076060  040340  000000  000000    2$:     .WORD   40340,0,0,0     ;FSRC
17062  076066  000000
17063  076070  040100  000000  000000    3$:     .WORD   40100,0,0,0     ;FRACTIONAL RES.
17064  076076  000000
17065  076100  056140  000000  000000    4$:     .WORD   56140,0,0,1     ;INTEGER RES.
17066  076106  000001
17067  076110  000213                    7$:     213                     ;FPS BEFORE EXECUTION.
17068  076112  000200                            200                     ;FPS AFTER EXECUTION.
17069
```

```
17070                                   ;MODD TEST WITH EXPONENT OF THE RESULT = 36
17071  076114  004737  076500           HHH8:   JSR     PC,@#MODDSUB
17072  076120  051177  177777  177777   1$:     .WORD   51177,-1,-1,-1  ;AC
17073  076126  177777
17074  076130  040200  000000  000000   2$:     .WORD   40200,0,0,0     ;FSRC
17075  076136  000000
17076  076140  040177  177760  000000   3$:     .WORD   40177,-20,0,0   ;FRACTIONAL RES.
17077  076146  000000
17078  076150  051177  177777  177760   4$:     .WORD   51177,-1,-20,0  ;INTEGER RES.
17079  076156  000000
17080  076160  000217                   7$:     217                     ;FPS BEFORE EXECUTION.
17081  076162  000200                           200                     ;FPS AFTER EXECUTION.
17082
17083                                   ;MODD TEST WITH EXPONENT OF THE RESULT = 30
17084  076164  004737  076500           HHH9:   JSR     PC,@#MODDSUB
17085  076170  040200  000000  000000   1$:     .WORD   40200,0,0,0     ;AC
17086  076176  000000
17087  076200  047577  177777           2$:     .WORD   47577,-1        ;FSRC
17088  076204  176000  000001                   .WORD   176000,1
17089  076210  031600  000000  000000   3$:     .WORD   31600,0,0,0     ;FRACTIONAL RES.
17090  076216  000000
17091  076220  047577  177777           4$:     .WORD   47577,-1        ;INTEGER RES.
17092  076224  176000  000000                   .WORD   176000,0
17093  076230  000200                   7$:     200                     ;FPS BEFORE EXECUTION.
17094  076232  000200                           200                     ;FPS AFTER EXECUTION.
17095
17096                                   ;MODD TEST WITH EXPONENT OF THE RESULT = 31
17097  076234  004737  076500           HHH10:  JSR     PC,@#MODDSUB
17098  076240  047777  177777           1$:     .WORD   47777,-1        ;AC
17099  076244  177000  000000                   .WORD   177000,0
17100  076250  040200  000000  000000   2$:     .WORD   40200,0,0,0     ;FSRC
17101  076256  000000
17102  076260  000000  000000  000000   3$:     .WORD   0,0,0,0         ;FRACTIONAL RES.
17103  076266  000000
17104  076270  047777  177777           4$:     .WORD   47777,-1        ;INTEGER RES.
17105  076274  177000  000000                   .WORD   177000,0
17106  076300  000213                   7$:     213                     ;FPS BEFORE EXECUTION.
17107  076302  000204                           204                     ;FPS AFTER EXECUTION.
17108
17109                                   ;MODD TEST WITH EXPONENT OF THE RESULT = 0
17110  076304  004737  076500           HHH11:  JSR     PC,@#MODDSUB
17111  076310  040200  000000  000000   1$:     .WORD   40200,0,0,0     ;AC
17112  076316  000000
17113  076320  040177  072727           2$:     .WORD   40177,72727     ;FSRC
17114  076324  127272  072727                   .WORD   127272,72727
17115  076330  040177  072727           3$:     .WORD   40177,72727     ;FRACTIONAL RES.
17116  076334  127272  072727                   .WORD   127272,72727
17117  076340  000000  000000  000000   4$:     .WORD   0,0,0,0         ;INTEGER RES.
17118  076346  000000
17119  076350  000200                   7$:     200                     ;FPS BEFORE EXECUTION.
17120  076352  000200                           200                     ;FPS AFTER EXECUTION.
17121
17122                                   ;MODD TEST WITH EXPONENT OF THE RESULT = -115
17123  076354  004737  076500           HHH12:  JSR     PC,@#MODDSUB
17124  076360  003377  177777           1$:     .WORD   3377,-1         ;AC
17125  076364  177777  052525                   .WORD   -1,52525
```

```
17126  076370  040200  000000  000000  2$:     .WORD   40200,0,0,0      ;FSRC
17127  076376  000000
17128  076400  003377  177777          3$:     .WORD   3377,-1          ;FRACTIONAL RES.
17129  076404  177777  052525                  .WORD   -1,52525
17130  076410  000000  000000  000000  4$:     .WORD   0,0,0,0          ;INTEGER RES.
17131  076416  000000
17132  076420  000200                  7$:     200                      ;FPS BEFORE EXECUTION.
17133  076422  000200                          200                      ;FPS AFTER EXECUTION.
17134
17135                                  ;MODD TEST WITH EXPONENT OF THE RESULT = -63, IN ROUND MODE.
17136  076424  004737  076500          HHH13:  JSR     PC,@#MODDSUB
17137  076430  040300  000000  000000  1$:     .WORD   40300,0,0,0      ;AC
17138  076436  000000
17139  076440  020200  000000  000000  2$:     .WORD   20200,0,0,1      ;FSRC
17140  076446  000001
17141  076450  020300  000000  000000  3$:     .WORD   20300,0,0,2      ;FRACTIONAL RES.
17142  076456  000002
17143  076460  000000  000000  000000  4$:     .WORD   0,0,0,0          ;INTEGER RES.
17144  076466  000000
17145  076470  000200                  7$:     200                      ;FPS BEFORE EXECUTION.
17146  076472  000200                          200                      ;FPS AFTER EXCCUTION.
17147  076474  000137  076674          9$:     JMP     @#HHHDONE        ;GO TO THE NEXT TEST.
17148
17149                                  ;THIS SUBROUTINE, MODDSUB, IS CALLED TO SETUP THE
17150                                  ;OPERANDS, EXECUTE THE MODD INSTRUCTION AND CHECK THE RESULTS.
17151                                  ;IT IS CALLED THUS:
17152                                  ;
17153                                  ;               ACARG:  .WORD   X,X,X,X          ;AC OPERAND
17154                                  ;               FSRCARG:.WORD   X,X,X,X          ;FSRC OPERAND
17155                                  ;               FRES:   .WORD   X,X,X,X          ;FRACTIONAL RESULT
17156                                  ;               INTRES: .WORD   X,X,X,X          ;INTEGER RESULT
17157                                  ;               ERFRES: .WORD   X,X,X,X          ;ERROR FRACTION RESULT
17158                                  ;               ERINTRES:.WORD  X,X,X,X          ;ERROR INTEGER RESULT
17159                                  ;               FPSB:   .WORD   X                ;FPS BEFORE EXECUTION
17160                                  ;               FPSA:   .WORD   X                ;FPS AFTER EXECUTION
17161                                  ;               ERR1:   ERROR   X                ;FRACTION ERROR
17162                                  ;                       BR      CONT
17163                                  ;               ERR2:   ERROR   X                ;INTEGER ERROR
17164                                  ;               CONT:                            ;RETURN ADDRESS
17165                                  ;
17166                                  ;THE OPERANDS ARE SET UP (USING AC0 FOR THE AC ARGUMENT). THE MODD
17167                                  ;INSTRUCTION IS EXECUTED. THEN THE RESULTS ARE RETRIEVED.
17168                                  ;THE FRACTION PART OF THE RESULT IS COMPARED WITH FRES. IF THIS IS CORRECT
17169                                  ;THEN THE INTEGER PART IS COMPARED WITH INTRES. IF BOTH OF THESE ARE CORRECT
17170                                  ;THEN THE FPS IS COMPARED WITH FPSA, AFTER EXECUTION IF NO ERRORS OCCURRED
17171                                  ;THEN MODDSUB WILL RETURN TO CONT. IF THE FPS WAS INCORRECT
17172                                  ;IT IS REPORTED HERE. IF THE FRACTION IS INCORRECT IT IS COMPARED WITH
17173                                  ;THE ANTICIPATED BAD FRACTION, ERFRES. IF THIS DOESN'T MATCH
17174                                  ;THE TRUE RESULT THEN THE ERROR IS REPORTED HERE. IF THE ANTICIPATED
17175                                  ;FAILURE MATCHES THE TRUE RESULT THEN  MODDSUB PASSES CONTROL TO THE
17176                                  ;ERROR CALL AT ERR1. LIKEWISE IF THE INTEGER PART OF THE RESULT IS
17177                                  ;NOT CORRECT THEN IT IS COMPARED WITH THE ANTICIPATED INTEGER
17178                                  ;FAILURE. IF THIS DOEN'T MATCH THEN THE ERROR IS REPORTED HERE.
17179                                  ;IF A MATCH IS MADE HOWEVER, MODDSUB WILL RETURN CONTROL TO THE ERROR
17180                                  ;CALL AT ERR2.
17181
```

```
17182  076500  012601                  MODDSUB:        MOV     (SP)+,R1        ;GET A POINTER TO THE ARGUMENTS
17183  076502  012700  000200                  MOV     #200,R0         ;SET FD MODE.
17184  076506  170100                          LDFPS   R0
17185  076510  010100                          MOV     R1,R0           ;SET UP AC0
17186  076512  172410                          LDD     (R0),AC0
17187  076514  012700  075450                  MOV     #MODP1,R0       ;PUT A BACKROUND PATTERN INTO AC1.
17188  076520  172510                          LDD     (R0),AC1
17189  076522  016100  000040                  MOV     40(R1),R0       ;SET UP THE FPS.
17190  076526  170100                          LDFPS   R0
17191  076530  010100                          MOV     R1,R0           ;COMPUTE THE ADDRESS OF THE FSRC.
17192  076532  062700  000010                  ADD     #10,R0
17193
17194  076536  171410                  1$:     MODD    (R0),AC0        ;EXECUTE THE TEST INSTRUCTION.
17195
17196  076540  170204                          STFPS   R4              ;GET THE FPS.
17197  076542  012700  000200                  MOV     #200,R0         ;SET FD MODE.
17198  076546  170100                          LDFPS   R0
17199  076550  012700  076654                  MOV     #MODDT0,R0      ;GET THE FRACTIONAL PESULT.
17200  076554  174010                          STD     AC0,(R0)
17201  076556  012700  076664                  MOV     #MODDT1,R0      ;GET THE INTEGER RESULT.
17202  076562  174110                          STD     AC1,(R0)
17203  076564  012702  076654                  MOV     #MODDT0,R2      ;CHECK THE FRACTIONAL RESULT.
17204  076570  010103                          MOV     R1,R3
17205  076572  062703  000020                  ADD     #20,R3
17206  076576  012705  000004                  MOV     #4,R5
17207  076602  022223                  2$:     CMP     (R2)+,(R3)+
17208  076604  001401                          BEQ     4$
17209  076606  104000                          EMT                     ;
17210  076610  077504                  4$:     SOB     R5,2$
17211  076612  012702  076664                  MOV     #MODDT1,R2      ;CHECK THE INTEGER RESULT.
17212  076616  010103                          MOV     R1,R3
17213  076620  062703  000030                  ADD     #30,R3
17214  076624  012705  000004                  MOV     #4,R5
17215  076630  022223                  3$:     CMP     (R2)+,(R3)+
17216  076632  001401                          BEQ     5$
17217  076634  104000                          EMT                     ;
17218  076636  077504                  5$:     SOB     R5,3$
17219  076640  026104  000042                  CMP     42(R1),R4       ;CHECK THE FPS.
17220  076644  001401                          BEQ     9$
17221  076646  104000                          EMT                     ;
17222  076650  000161  000044          9$:     JMP     44(R1)          ;RETURN.
17223
17224  076654  000000  000000  000000  MODDT0: .WORD   0,0,0,0
17225  076662  000000
17226
17227  076664  000000  000000  000000  MODDT1: .WORD   0,0,0,0
17228  076672  000000
17229
17230  076674                  HHHDONE:
17231  076674  004767  021574                  JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
17232                                                                  ;SEE IF THE USER HAS EXPRESSED
17233                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
17234                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
17235                                                                  ;THE USER TYPED CONTROL G?).
17236
17237
```

```
17238
17239
17240                           ;*****************************************************************************************
17241                           ;TEST 475       UNDER\OVER FLOW, USING MODF WITH TRAPS DISABLED, TEST
17242                           ;*****************************************************************************************
17243  076700                   TS475:
17244
17245                           ;UNDERFLOW TEST, WITH EXPONENT OF THE RESULT = -129, FIU = 1, FID = 1
17246  076700  004767  000214   MMM1:   JSR     PC,MODFOV
17247  076704  020123  045676   1$:     .WORD   20123,45676     ;AC
17248  076710  020200  000000   2$:     .WORD   20200,0         ;FSRC
17249  076714  000123  045676   3$:     .WORD   123,45676       ;FRACTIONAL RES.
17250  076720  000000  000000   4$:     .WORD   0,0             ;INTEGER RES.
17251  076724  042000           7$:     42000                   ;FPS BEFORE EXECUTION.
17252  076726  142004                   142004                  ;FPS AFTER EXECUTION.
17253  076730  000012                   12                      ;FEC
17254  076732  104000                   EMT                     ;
17255
17256                           ;UNDERFLOW EXP OF RESULT = -193, FIU = 0, FID = 1
17257  076734  004737  077120   MMM2:   JSR     PC,@#MODFOV
17258  076740  010200  000000   1$:     .WORD   10200,0         ;AC
17259  076744  010000  000000   2$:     .WORD   10000,0         ;FSRC
17260  076750  000000  000000   3$:     .WORD   0,0             ;FRACTIONAL RES.
17261  076754  000000  000000   4$:     .WORD   0,0             ;INTEGER RES.
17262  076760  005013           7$:     5013                    ;FPS BEFORE EXECUTION.
17263  076762  005004                   5004                    ;FPS AFTER EXECUTION.
17264  076764  000012                   12                      ;FEC
17265  076766  000240                   NOP
17266
17267                           ;OVERFLOW TEST WITH EXPONENT OF THE RESULT = 128, FIV = 1, FID = 1
17268  076770  004737  077120   MMM3:   JSR     PC,@#MODFOV
17269  076774  060052  125252   1$:     .WORD   60052,125252    ;AC
17270  077000  060200  000000   2$:     .WORD   60200,0         ;FSRC
17271  077004  000000  000000   3$:     .WORD   0,0             ;FRACTIONAL RES.
17272  077010  000052  125252   4$:     .WORD   52,125252       ;INTEGER RES.
17273  077014  041000           7$:     41000                   ;FPS BEFORE EXECUTION.
17274  077016  141006                   141006                  ;FPS AFTER EXECUTION.
17275  077020  000010                   10                      ;FEC
17276  077022                   8$:
17277  077022  104000                   EMT                     ;
17278                           ;OVERFLOW TEST WITH EXPONENT OF THE RESULT = 130, FIV = 0, FID = 1
17279  077024  004737  077120   MMM4:   JSR     PC,@#MODFOV
17280  077030  060345  067654   1$:     .WORD   60345,67654     ;AC
17281  077034  060200  000000   2$:     .WORD   60200,0         ;FSRC
17282  077040  000000  000000   3$:     .WORD   0,0             ;FRACTIONAL RES.
17283  077044  000000  000000   4$:     .WORD   0,0             ;INTEGER RES.
17284  077050  006011           7$:     6011                    ;FPS BEFORE EXECUTION.
17285  077052  006006                   6006                    ;FPS AFTER EXECUTION.
17286  077054  000010                   10                      ;FEC
17287  077056  000240           8$:     NOP
17288                           ;OVERFLOW TEST WITH EXPONENT OF THE RESULT = 128, RESULT NEGATIVE
17289                           ;AND FIV = 1, FID = 1
17290  077060  004737  077120   MMM5:   JSR     PC,@#MODFOV
17291  077064  160252  125252   1$:     .WORD   160252,125252   ;AC
17292  077070  060000  000000   2$:     .WORD   60000,0         ;FSRC
17293  077074  000000  000000   3$:     .WORD   0,0             ;FRACTIONAL RES.
```

```
17294  077100  100052  125252          4$:     .WORD   100052,125252   ;INTEGER RES.
17295  077104  041000                  7$:     41000                   ;FPS BEFORE EXECUTION.
17296  077106  141006                          141006                  ;FPS AFTER EXECUTION.
17297  077110  000010                          10                      ;FEC
17298  077112                          8$:
17299  077112  104000                          EMT                     ;
17300  077114  000137  077334          9$:     JMP     @#MMMDONE       ;GO TO THE NEXT TEST.
17301
17302                                  ;THIS SUBROUTINE, MODFOV, IS CALLED TO SETUP THE
17303                                  ;OPERANDS, EXECUTE THE MODF INSTRUCTION AND CHECK THE RESULTS.
17304                                  ;IT IS CALLED THUS:
17305                                  ;
17306                                  ;               ACARG:  .WORD   X,X             ;AC OPERAND
17307                                  ;               FSRCARG:.WORD   X,X             ;FSRC OPERAND
17308                                  ;               FRES:   .WORD   X,X             ;FRACTIONAL RESULT
17309                                  ;               INTRES: .WORD   X,X             ;INTEGER RESULT
17310                                  ;               ERFRES: .WORD   X,X             ;ERROR FRACTION RESULT
17311                                  ;               ERINTRES:.WORD  X,X             ;ERROR INTEGER RESULT
17312                                  ;               FPSB:   .WORD   X               ;FPS BEFORE EXECUTION
17313                                  ;               FPSA:   .WORD   X               ;FPS AFTER EXECUTION
17314                                  ;               FEC:    .WORD   X               ;FEC
17315                                  ;               ERR1:   ERROR   X               ;FEC ERROR
17316                                  ;                       BR      CONT
17317                                  ;               ERR2:   ERROR   X               ;INTEGER ERROR
17318                                  ;               CONT:                           ;RETURN ADDRESS
17319                                  ;
17320                                  ;THE OPERANDS ARE SET UP (USING AC0 FOR THE AC ARGUMENT). THE MODF
17321                                  ;INSTRUCTION IS EXECUTED. THEN THE RESULTS ARE RETRIEVED.
17322                                  ;THE FRACTION PART OF THE RESULT IS COMPARED WITH FRES. IF THIS IS CORRECT
17323                                  ;THEN THE INTEGER PART IS COMPARED WITH INTRES. IF BOTH OF THESE ARE CORRECT
17324                                  ;THEN THE FPS IS COMPARED WITH FPSA. AFTER EXECUTION IF NO ERRORS OCCURRED
17325                                  ;THEN MODFOV WILL RETURN TO CONT. IF THE FPS WAS INCORRECT
17326                                  ;IT IS REPORTED HERE. IF THE FRACTION IS INCORRECT IT IS COMPARED WITH
17327                                  ;THE ANTICIPATED BAD FRACTION, ERFRES. IF THIS DOESN'T MATCH
17328                                  ;THE TRUE RESULT THEN THE ERROR IS REPORTED HERE. IF THE ANTICIPATED
17329                                  ;FAILURE MATCHES THE TRUE RESULT THEN  MODFOV PASSES CONTROL TO THE
17330                                  ;ERROR CALL AT ERR1. LIKEWISE IF THE INTEGER PART OF THE RESULT IS
17331                                  ;NOT CORRECT THEN IT IS COMPARED WITH THE ANTICIPATED INTEGER
17332                                  ;FAILURE. IF THIS DOEN'T MATCH THEN THE ERROR IS REPORTED HERE.
17333                                  ;IF A MATCH IS MADE HOWEVER, MODFOV WILL RETURN CONTROL TO THE ERROR
17334                                  ;CALL AT ERR2.
17335
17336  077120  012601                  MODFOV: MOV     (SP)+,R1        ;GET A POINTER TO THE ARGUMENTS
17337  077122  012700  000200                  MOV     #200,R0         ;SET FD MODE.
17338  077126  170100                          LDFPS   R0
17339  077130  010100                          MOV     R1,R0           ;SET UP AC0
17340  077132  172410                          LDD     (R0),AC0
17341  077134  012700  075450                  MOV     #MODP1,R0       ;PUT A BACKROUND PATTERN INTO AC1.
17342  077140  172510                          LDD     (R0),AC1
17343  077142  016100  000020                  MOV     20(R1),R0       ;SET UP THE FPS.
17344  077146  170100                          LDFPS   R0
17345  077150  010100                          MOV     R1,R0           ;COMPUTE THE ADDRESS OF THE FSRC.
17346  077152  062700  000004                  ADD     #4,R0
17347
17348  077156  171410                  1$:     MODF    (R0),AC0        ;EXECUTE THE TEST INSTRUCTION.
17349
```

```
17350  077160  170204                          STFPS   R4              ;GET THE FPS.
17351  077162  170305                          STST    R5              ;GET FEC.
17352  077164  012700  000200                  MOV     #200,R0         ;SET FD MODE.
17353  077170  170100                          LDFPS   R0
17354  077172  012700  077314                  MOV     #MODFD0,R0      ;GET THE FRACTIONAL RESULT.
17355  077176  174010                          STD     AC0,(R0)
17356  077200  012700  077324                  MOV     #MODFD1,R0      ;GET THE INTEGER RESULT.
17357  077204  174110                          STD     AC1,(R0)
17358  077206  012702  077314                  MOV     #MODFD0,R2      ;CHECK THE FRACTIONAL RESULT.
17359  077212  026112  000010                  CMP     10(R1),(R2)
17360  077216  001401                          BEQ     2$
17361  077220  104000                          EMT                     ;
17362  077222  026162  000012  000002  2$:     CMP     12(R1),2(R2)
17363  077230  001401                          BEQ     3$
17364  077232  104000                          EMT                     ;
17365  077234  012702  077324          3$:     MOV     #MODFD1,R2      ;CHECK THE INTEGER RESULT.
17366  077240  026112  000014                  CMP     14(R1),(R2)
17367  077244  001401                          BEQ     4$
17368  077246  104000                          EMT                     ;
17369  077250  026162  000016  000002  4$:     CMP     16(R1),2(R2)
17370  077256  001401                          BEQ     5$
17371  077260  104000                          EMT                     ;
17372  077262  026104  000022          5$:     CMP     22(R1),R4       ;CHECK THE FPS.
17373  077266  001401                          BEQ     6$
17374  077270  104000                          EMT                     ;
17375  077272  026105  000024          6$:     CMP     24(R1),R5       ;CHECK THE FEC.
17376  077276  001002                          BNE     25$             ;BRANCH IF INCORRECT.
17377
17378  077300  000161  000030          9$:     JMP     30(R1)          ;RETURN.
17379                                  ;REPORT FEC ERROR.
17380  077304  010102                  25$:    MOV     R1,R2
17381  077306  062702  000026                  ADD     #26,R2
17382  077312  000112                          JMP     (R2)
17383
17384  077314  000000  000000  000000  MODFD0: .WORD   0,0,0,0
17385  077322  000000
17386
17387  077324  000000  000000  000000  MODFD1: .WORD   0,0,0,0
17388  077332  000000
17389
17390  077334                          MMMDONE:
17391  077334  004767  021134                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
17392                                                                  ;SEE IF THE USER HAS EXPRESSED
17393                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
17394                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
17395                                                                  ;THE USER TYPED CONTROL G?).
17396
17397
17398
17399
17400                                  ;*****************************************************************************
17401                                  ;TEST 476       UNDER\OVER FLOW, USING MODD WITH TRAPS DISABLED, TEST
17402                                  ;*****************************************************************************
17403  077340                          TS476:
17404
17405                                  ;UNDERFLOW TEST WITH EXPONENT OF THE RESULT = -129, FIU = 1, FID = 1
```

```
17406  077340  004737  077624          NNN1:   JSR     PC,@#MODDOV
17407  077344  020252  125252          1$:     .WORD   20252,125252    ;AC
17408  077350  125252  125252                  .WORD   125252,125252
17409  077354  020100  000000  000000  2$:     .WORD   20100,0,0,0     ;FSRC
17410  077362  000000
17411  077364  000177  177777  177777  3$:     .WORD   177,-1,-1,-1    ;FRACTIONAL RES.
17412  077372  177777
17413  077374  000000  000000  000000  4$:     .WORD   0,0,0,0         ;INTEGER RES.
17414  077402  000000
17415  077404  042200                  7$:     42200                   ;FPS BEFORE EXECUTION.
17416  077406  142204                          142204                  ;FPS AFTER EXECUTION.
17417  077410  000012                          12                      ;FEC
17418  077412                          8$:
17419  077412  104000                          EMT                     ;
17420                                  ;UNDERFLOW TEST WITH EXPONENT OF THE RESULT = -193, FIU = 0, FID = 1
17421  077414  004737  077624          NNN2:   JSR     PC,@#MODDOV
17422  077420  010000  000000          1$:     .WORD   10000,0         ;AC
17423  077424  123456  000000                  .WORD   123456,0
17424  077430  010200  000000  000000  2$:     .WORD   10200,0,0,0     ;FSRC
17425  077436  000000
17426  077440  000000  000000  000000  3$:     .WORD   0,0,0,0         ;FRACTIONAL RES.
17427  077446  000000
17428  077450  000000  000000  000000  4$:     .WORD   0,0,0,0         ;INTEGER RES.
17429  077456  000000
17430  077460  005213                  7$:     5213                    ;FPS BEFORE EXECUTION.
17431  077462  005204                          5204                    ;FPS AFTER EXECUTION.
17432  077464  000012                          12
17433  077466  000240                  8$:     NOP
17434                                  ;OVERFLOW TEST WITH EXPONENT OF THE RESULT = 128, FIV = 1, FID = 1
17435  077470  004737  077624          NNN3:   JSR     PC,@#MODDOV
17436  077474  060252  125252          1$:     .WORD   60252,125252    ;AC
17437  077500  125252  125252                  .WORD   125252,125252
17438  077504  060100  000000  000000  2$:     .WORD   60100,0,0,0     ;FSRC
17439  077512  000000
17440  077514  000000  000000  000000  3$:     .WORD   0,0,0,0         ;FRACTIONAL RES.
17441  077522  000000
17442  077524  000177  177777  177777  4$:     .WORD   177,-1,-1,-1    ;INTEGER RES.
17443  077532  177777
17444  077534  041200                  7$:     41200                   ;FPS BEFORE EXECUTION.
17445  077536  141206                          141206                  ;FPS AFTER EXECUTION.
17446  077540  000010                          10                      ;FEC
17447  077542                          8$:
17448  077542  104000                          EMT                     ;
17449                                  ;OVERFLOW TEST WITH EXPONENT OF THE RESULT = 130, FIV = 0, FID = 1
17450  077544  004737  077624          NNN4:   JSR     PC,@#MODDOV
17451  077550  060200  000000          1$:     .WORD   60200,0         ;AC
17452  077554  125252  000000                  .WORD   125252,0
17453  077560  060200  000000  000000  2$:     .WORD   60200,0,0,0     ;FSRC
17454  077566  000000
17455  077570  000000  000000  000000  3$:     .WORD   0,0,0,0         ;FRACTIONAL RES.
17456  077576  000000
17457  077600  000000  000000  000000  4$:     .WORD   0,0,0,0         ;INTEGER RES.
17458  077606  000000
17459  077610  006211                  7$:     6211                    ;FPS BEFORE EXECUTION.
17460  077612  006206                          6206                    ;FPS AFTER EXECUTION.
17461  077614  000010                          10                      ;FEC
```

```
17462  077616  000240                  8$:     NOP
17463  077620  000137  100040          9$:     JMP     @#NNNDONE       ;GO TO NEXT TEST.
17464
17465                                  ;THIS SUBROUTINE, MODDOV, IS CALLED TO SETUP THE
17466                                  ;OPERANDS, EXECUTE THE MODD INSTRUCTION AND CHECK THE RESULTS.
17467                                  ;IT IS CALLED THUS:
17468                                  ;
17469                                  ;               ACARG:   .WORD   X,X,X,X        ;AC OPERAND
17470                                  ;               FSRCARG:.WORD    X,X,X,X        ;FSRC OPERAND
17471                                  ;               FRES:    .WORD   X,X,X,X        ;FRACTIONAL RESULT
17472                                  ;               INTRES:  .WORD   X,X,X,X        ;INTEGER RESULT
17473                                  ;               ERFRES:  .WORD   X,X,X,X        ;ERROR FRACTION RESULT
17474                                  ;               ERINTRES:.WORD   X,X,X,X        ;ERROR INTEGER RESULT
17475                                  ;               FPSB:    .WORD   X              ;FPS BEFORE EXECUTION
17476                                  ;               FPSA:    .WORD   X              ;FPS AFTER EXECUTION
17477                                  ;               ERR1:    ERROR   X              ;FRACTION ERROR
17478                                  ;                        BR      CONT
17479                                  ;               ERR2:    ERROR   X              ;INTFGER ERROR
17480                                  ;               CONT:                           ;RETURN ADDRESS
17481                                  ;
17482                                  ;THE OPERANDS ARE SET UP (USING AC0 FOR THE AC ARGUMENT). THE MODD
17483                                  ;INSTRUCTION IS EXECUTED. THEN THE RESULTS ARE RETRIEVED.
17484                                  ;THE FRACTION PART OF THE RESULT IS COMPARED WITH FRES. IF THIS IS CORRECT
17485                                  ;THEN THE INTEGER PART IS COMPARED WITH INTRES. IF BOTH OF THESE ARE CORRECT
17486                                  ;THEN THE FPS IS COMPARED WITH FPSA. AFTER EXECUTION IF NO ERRORS OCCURRED
17487                                  ;THEN MODDOV WILL RETURN TO CONT. IF THE FPS WAS INCORRECT
17488                                  ;IT IS REPORTED HERE. IF THE FRACTION IS INCORRECT IT IS COMPARED WITH
17489                                  ;THE ANTICIPATED BAD FRACTION, ERFRES. IF THIS DOESN'T MATCH
17490                                  ;THE TRUE RESULT THEN THE ERROR IS REPORTED HERE. IF THE ANTICIPATED
17491                                  ;FAILURE MATCHES THE TRUE RESULT THEN  MODDOV PASSES CONTROL TO THE
17492                                  ;ERROR CALL AT ERR1. LIKEWISE IF THE INTEGER PART OF THE RESULT IS
17493                                  ;NOT CORRECT THEN IT IS COMPARED WITH THE ANTICIPATED INTEGER
17494                                  ;FAILURE. IF THIS DOEN'T MATCH THEN THE ERROR IS REPORTED HERE.
17495                                  ;IF A MATCH IS MADE HOWEVER, MODDOV WILL RETURN CONTROL TO THE ERROR
17496                                  ;CALL AT ERR2.
17497
17498  077624  012601                  MODDOV: MOV     (SP)+,R1        ;GET A POINTER TO THE ARGUMENTS
17499  077626  012700  000200                  MOV     #200,R0         ;SET FD MODE.
17500  077632  170100                           LDFPS   R0
17501  077634  010100                           MOV     R1,R0           ;SET UP AC0
17502  077636  172410                           LDD     (R0),AC0
17503  077640  012700  075450                   MOV     #MODP1,R0       ;PUT A BACKROUND PATTERN INTO AC1.
17504  077644  172510                           LDD     (R0),AC1
17505  077646  016100  000040                   MOV     40(R1),R0       ;SET UP THE FPS.
17506  077652  170100                           LDFPS   R0
17507  077654  010100                           MOV     R1,R0           ;COMPUTE THE ADDRESS OF THE FSRC.
17508  077656  062700  000010                   ADD     #10,R0
17509
17510  077662  171410                  1$:     MODD    (R0),AC0        ;EXECUTE THE TEST INSTRUCTION.
17511
17512  077664  170305                           STST    R5              ;GET THE FPS.
17513  077666  170204                           STFPS   R4              ;GET THE FPS.
17514  077670  012700  000200                   MOV     #200,R0         ;SET FD MODE.
17515  077674  170100                           LDFPS   R0
17516  077676  012700  100020                   MOV     #MODDD0,R0      ;GET THE FRACTIONAL RESULT.
17517  077702  174010                           STD     AC0,(R0)
```

```
17518  077704  012700  100030          MOV     #MODDD1,R0      ;GET THE INTEGER RESULT.
17519  077710  174110                  STD     AC1,(R0)
17520  077712  012702  100020          MOV     #MODDD0,R2      ;CHECK THE FRACTIONAL RESULT.
17521  077716  010103                  MOV     R1,R3
17522  077720  062703  000020          ADD     #20,R3
17523  077724  012700  000004          MOV     #4,R0
17524  077730  022223          2$:     CMP     (R2)+,(R3)+
17525  077732  001401                  BEQ     4$
17526  077734  104000                  EMT                     ;
17527  077736  077004          4$:     SOB     R0,2$
17528  077740  012702  100030          MOV     #MODDD1,R2      ;CHECK THE INTEGER RESULT
17529  077744  010103                  MOV     R1,R3
17530  077746  062703  000030          ADD     #30,R3
17531  077752  012700  000004          MOV     #4,R0
17532  077756  022223          3$:     CMP     (R2)+,(R3)+
17533  077760  001401                  BEQ     5$
17534  077762  104000                  EMT                     ;
17535  077764  077004          5$:     SOB     R0,3$
17536  077766  026104  000042          CMP     42(R1),R4       ;CHECK THE FPS.
17537  077772  001401                  BEQ     6$
17538  077774  104000                  EMT                     ;
17539  077776  026105  000044  6$:     CMP     44(R1),R5       ;CHECK THE FEC.
17540  100002  001002                  BNE     25$
17541
17542  100004  000161  000050  9$:     JMP     50(R1)          ;RETURN.
17543                          ;REPORT FEC ERROR.
17544  100010  010102          25$:    MOV     R1,R2
17545  100012  062702  000046          ADD     #46,R2
17546  100016  000112                  JMP     (R2)
17547
17548  100020  000000  000000  000000  MODDD0: .WORD   0,0,0,0
17549  100026  000000
17550
17551  100030  000000  000000  000000  MODDD1: .WORD   0,0,0,0
17552  100036  000000
17553
17554  100040                  NNNDONE:
17555  100040  004767  020430          JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
17556                                                          ;SEE IF THE USER HAS EXPRESSED
17557                                                          ;THE DESIRE TO CHANGE THE SOFTWARE
17558                                                          ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
17559                                                          ;THE USER TYPED CONTROL G?).
17560
17561
17562                  ;*****************************************************************************
17563                  ;TEST 477       MORE MICROCODES COVERAGE
17564                  ;*****************************************************************************
17565  100044          TS477:
17566  100044  012737  100060  000244  XT1:    MOV     #XT1A,@#244
17567  100052  170227  000000          STFPS   #0
17568  100056  000401                  BR      XT2
17569  100060          XT1A:
17570  100060  104000                  EMT                     ;
17571
17572  100062  012700  177777  XT2:     MOV     #-1,R0
17573  100066  170127  000000          LDFPS   #0
```

```
 17574  100072  170200                  STFPS   R0
 17575  100074  005700                  TST     R0
 17576  100076  001401                  BEQ     XT2A
 17577  100100  104000                  EMT                             ;
 17578  100102  012700  100636  XT2A:   MOV     #XPAT0,R0
 17579  100106  172440                  LDF     -(R0),AC0
 17580  100110  022700  100632          CMP     #XPAT0-4,R0
 17581  100114  001401                  BEQ     XT2B
 17582  100116  104000                  EMT                             ;
 17583  100120  170200          XT2B:   STFPS   R0
 17584  100122  022700  000004          CMP     #4,R0                   ;CHECK IF FZ IS SET?
 17585  100126  001401                  BEQ     XT3
 17586  100130  104000                  EMT                             ;
 17587  100132  170127  000000  XT3:    LDFPS   #0
 17588  100136  012700  100636          MOV     #XPAT0,R0
 17589  100142  174040                  STF     AC0,-(R0)
 17590  100144  022700  100632          CMP     #XPAT0-4,R0
 17591  100150  001401                  BEQ     XT3A
 17592  100152  104000                  EMT                             ;
 17593  100154  170200          XT3A:   STFPS   R0
 17594  100156  005700                  TST     R0
 17595  100160  001401                  BEQ     XT4
 17596  100162  104000                  EMT                             ;
 17597
 17598  100164  170127  000000  XT4:    LDFPS   #0
 17599  100170  012737  100214  000244  MOV     #XT4A,@#244
 17600  100176  170127  004000          LDFPS   #04000                  ;INTRPT ON UNDEFINED VARIABLE
 17601  100202  172437  100636          LDF     @#XPAT0,AC0
 17602  100206  174437  100666          DIVF    @#XPAT3,AC0             ;GET UNDEFINED VARIABLE. _0
 17603  100212  104000                  EMT                             ;
 17604  100214  170200          XT4A:   STFPS   R0
 17605  100216  022700  104004          CMP     #104004,R0              ;CHECK: FER,FIUV,FZ ARE SET?
 17606  100222  001401                  BEQ     XT4B
 17607  100224  104000                  EMT                             ;
 17608  100226  012700  100626  XT4B:   MOV     #XBUF,R0
 17609  100232  174010                  STF     AC0,(R0)
 17610  100234  005737  100626          TST     @#XBUF
 17611  100240  001401                  BEQ     XT5
 17612  100242  104000                  EMT                             ;
 17613
 17614  100244  012737  100264  000244  XT5:    MOV     #XT5A,@#244
 17615  100252  170127  004000          LDFPS   #04000                  ;INTRPT ON UNDEFINED VARIBALE
 17616  100256  177437  100666          LDCDF   @#XPAT3,AC0             ;GET UNDEFINED VARIABLE. _0
 17617  100262  104000                  EMT                             ;
 17618  100264  170200          XT5A:   STFPS   R0
 17619  100266  022700  104014          CMP     #104014,R0              ;CHECK: FER,FIUV,FN,FZ ARE SET?
 17620  100272  001401                  BEQ     XT5B
 17621  100274  104000                  EMT                             ;
 17622  100276  012700  100626  XT5B:   MOV     #XBUF,R0
 17623  100302  174010                  STF     AC0,(R0)
 17624  100304  005737  100626          TST     @#XBUF
 17625  100310  001401                  BEQ     XT6
 17626  100312  104000                  EMT                             ;
 17627
 17628  100314  012737  100340  000244  XT6:    MOV     #XT6A,@#244
 17629  100322  170127  004000          LDFPS   #04000                  ;INTRPT ON UNDEFINED VARIBALE
```

```
17630  100326  172437  100636          LDF     @#XPAT0,AC0
17631  100332  172037  100666          ADDF    @#XPAT3,AC0
17632  100336  104000                  EMT                             ;
17633  100340  170200          XT6A:   STFPS   R0
17634  100342  022700  104004          CMP     #104004,R0              ;CHECK: FER,FIUV,FZ ARE SET?
17635  100346  001401                  BEQ     XT6B
17636  100350  104000                  EMT                             ;
17637  100352  012700  100626  XT6B:   MOV     #XBUF,R0
17638  100356  174010                  STF     AC0,(R0)
17639  100360  005737  100626          TST     @#XBUF
17640  100364  001401                  BEQ     XT7
17641  100366  104000                  EMT                             ;
17642
17643  100370  170127  000000  XT7:    LDFPS   #0
17644  100374  172437  100676          LDF     @#XPAT4,AC0
17645  100400  175437  100726          STCFI   AC0,@#XPAT0
17646  100404  022737  000002  100726  CMP     #2,@#XPAT0              ;CHECK DATA
17647  100412  001401                  BEQ     XT8
17648  100414  104000                  EMT                             ;
17649
17650  100416  170127  000100  XT8:    LDFPS   #100                    ;SET FL
17651  100422  172437  100676          LDF     @#XPAT4,AC0
17652  100426  175467  000274          STCFI   AC0,XPAT0
17653  100432  022737  000002  100730  CMP     #2,@#XPAT0+2
17654  100440  001401                  BEQ     XT9
17655  100442  104000                  EMT                             ;
17656
17657                          ;START OF FPP2
17658  100444  170127  000000  XT9:    LDFPS   #0
17659  100450  172437  100636          LDF     @#XPAT0,AC0
17660  100454  172037  100676          ADDF    @#XPAT4,AC0
17661  100460  170200                  STFPS   R0
17662  100462  005700                  TST     R0
17663  100464  001401                  BEQ     XT10
17664  100466  104000                  EMT                             ;
17665
17666  100470  170127  000000  XT10:   LDFPS   #0
17667  100474  172437  100676          LDF     @#XPAT4,AC0
17668  100500  173037  100676          SUBF    @#XPAT4,AC0
17669  100504  170200                  STFPS   R0
17670  100506  022700  000004          CMP     #4,R0
17671  100512  001401                  BEQ     XT11
17672  100514  104000                  EMT                             ;
17673
17674  100516  170127  000000  XT11:   LDFPS   #0
17675  100522  172437  100676          LDF     @#XPAT4,AC0
17676  100526  173437  100676          CMPF    @#XPAT4,AC0
17677  100532  170200                  STFPS   R0
17678  100534  022700  000004          CMP     #4,R0                   ;CHECK IF FZ IS SET?
17679  100540  001401                  BEQ     XT12
17680  100542  104000                  EMT                             ;
17681
17682  100544  170127  000000  XT12:   LDFPS   #0
17683  100550  172437  100676          LDF     @#XPAT4,AC0
17684  100554  174437  100656          DIVF    @#XPAT2,AC0
17685  100560  012700  100626          MOV     #XBUF,R0
```

```
17686  100564  174010                          STF     AC0,(R0)
17687  100566  022737  040176  100626          CMP     #040176,@#XBUF  ;CHECK DATA
17688  100574  001401                          BEQ     XT13
17689  100576  104000                          EMT                     ;
17690
17691  100600  170127  000000          XT13:   LDFPS   #0
17692  100604  172437  100706                  LDF     @#XPAT5,AC0
17693  100610  174437  100716                  DIVF    @#XPAT6,AC0
17694  100614  170200                          STFPS   R0
17695  100616  022700  000004                  CMP     #4,R0
17696  100622  001445                          BEQ     XTDONE
17697  100624  104000                          EMT                     ;
17698
17699
17700  100626  000000  000000  000000  XBUF:   .WORD   0,0,0,0
17701  100634  000000
17702  100636  000000  000000  000000  XPAT0:  .WORD   0,0,0,0
17703  100644  000000
17704  100646  000001  000001  000001  XPAT1:  .WORD   1,1,1,1
17705  100654  000001
17706  100656  040401  000000  000000  XPAT2:  .WORD   40401,0,0,0
17707  100664  000000
17708  100666  100000  000000  000000  XPAT3:  .WORD   100000,0,0,0
17709  100674  000000
17710  100676  040400  000000  000000  XPAT4:  .WORD   040400,0,0,0
17711  100704  000000
17712  100706  000207  000000  000000  XPAT5:  .WORD   207,0,0,0
17713  100714  000000
17714  100716  077007  000000  000000  XPAT6:  .WORD   77007,0,0,0
17715  100724  000000
17716  100726  000000  000000  000000  XPAT0:  .WORD   0.0,0,0
17717  100734  000000
17718
17719  100736                          XTDONE:
17720  100736  004767  017532                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
17721                                                                  ;SEE IF THE USER HAS EXPRESSED
17722                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
17723                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
17724                                                                  ;THE USER TYPED CONTROL G?).
17725
17726
17727
17728
17729                                   ;*************************************************************************************
17730                                   ;TEST 500       STF WITH ILLEGAL ACCUMULATOR TEST
17731                                   ;*************************************************************************************
17732  100742                           TS500:
17733
17734  100742  005000                          CLR     R0              ;SET THE FPS.
17735  100744  170100                          LDFPS   R0
17736
17737  100746  012737  100766  000244          MOV     #000T,@#FPVECT  ;SET UP FOR FP TRAPS.
17738  100754  012737  100762  037366          MOV     #1$,@#$TMP2
17739
17740  100762  174007                  1$:     STF     AC0,AC7         ;THIS TEST INSTRUCTION SHOULD
17741                                                                  ;CAUSE A TRAP.
```

```
17742
17743
17744  100764
17745  100764  104000                  ;REPORT FAILURE OF USE OF ILLEGAL ACCUMULATOR 7 TO CAUSE AN FPP TRAP.
                                0002:
                                        EMT                     ;INSTRUCTION DID NOT TRAP
17746
17747                           ;TRAP TO 0001, HERE, WHEN THE EXPECTED ERROR OCCURS.
17748  100766  011600            0001:   MOV     (SP),R0         ;MAKE SURE THE ERROR OCCURRED
17749  100770  022700  100764            CMP     #0002,R0        ;AT THE CORRECT ADDRESS.
17750  100774  001420                    BEQ     TS501
17751  100776  104000                    EMT                     ;FLOATING POINT TRAP DID NOT OPERATE RIGHT
17752
17753  101000  170204            0003:   STFPS   R4              ;GET FPS.
17754  101002  170305                    STST    R5              ;GET FEC.
17755  101004  012702  100000            MOV     #100000,R2      ;EXPECTED FPS
17756  101010  012703  000002            MOV     #2,R3           ;EXPECTED FEC
17757  101014  022626                    CMP     (SP)+,(SP)+     ;RESET THE STACK.
17758
17759  101016  020204                    CMP     R2,R4           ;WAS FPS CORRECT?
17760  101020  001401                    BEQ     0004
17761  101022  104000                    EMT                     ;FPS INCORRECTLY SET AFTER USE OF ILLEGAL ACC
17762  101024  020305            0004:   CMP     R3,R5           ;WAS THE FEC CORRECT?
17763  101026  001401                    BEQ     0001DONE
17764  101030  104000                    EMT                     ;INCORRECT FEC AFTER USE OF ILLEGAL ACC
17765
17766  101032                    0001DONE:
17767  101032  004767  017436            JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
                                                                ;SEE IF THE USER HAS EXPRESSED
                                                                ;THE DESIRE TO CHANGE THE SOFTWARE
                                                                ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
                                                                ;THE USER TYPED CONTROL G?).
17768
17769
17770
17771
17772
17773
17774
17775
17776                           ;**********************************************************************************
17777                           ;TEST 501       FDST MODE 1, FLOATING MODE, TEST
17778                           ;**********************************************************************************
17779  101036                  TS501:
17780
17781
17782  101036  012700  177777            MOV     #-1,R0          ;SET UP A BACKROUND PATTERN IN THE
17783  101042  012701  101152            MOV     #PPPBF0,R1      ;INPUT BUFFER.
17784  101046  012702  000014            MOV     #14,R2
17785  101052  010021            PPP2:   MOV     R0,(R1)+
17786  101054  077202                    SOB     R2,PPP2
17787
17788  101056  012700  000200            MOV     #200,R0         ;SET FD MODE.
17789  101062  170100                    LDFPS   R0
17790  101064  012700  101202            MOV     #PPPTP1,R0      ;PUT TEST DATA INTO AC0.
17791  101070  172410                    LDD     (R0),AC0
17792
17793  101072  012700  101166            MOV     #PPPBF1,R0      ;FDST ADDRESS.
17794  101076  005002                    CLR     R2              ;CLEAR THE FPS.
17795  101100  170102                    LDFPS   R2
17796
17797  101102  174010            PPP3:   STF     AC0,(R0)        ;TEST INSTRUCTION.
```

```
17798
17799  101104  022700  101166          CMP     #PPPBF1,R0      ;WAS R0 MODIFIED DURING EXECUTION?
17800  101110  001401                  BEQ     PPP4
17801  101112  104000                  EMT                     ;R0 MODIFIED
17802
17803  101114  012700  101166  PPP4:   MOV     #PPPBF1,R0      ;CHECK THE DATA IN THE OUTPUT BUFFER.
17804  101120  012701  101202          MOV     #PPPTP1,R1
17805  101124  022021                  CMP     (R0)+,(R1)+
17806  101126  001031                  BNE     PPP10           ;BRANCH IF INCORRECT.
17807  101130  022011                  CMP     (R0)+,(R1)
17808  101132  001027                  BNE     PPP10           ;BRANCH IF INCORRECT.
17809  101134  022720  177777          CMP     #-1,(R0)+       ;WAS FLOATING MODE USED?
17810  101140  001024                  BNE     PPP10           ;BRANCH IF NOT.
17811  101142  022710  177777          CMP     #-1,(R0)
17812  101146  001021                  BNE     PPP10
17813  101150  000421                  BR      PPPDONE ;GO TO NEXT TEST.
17814
17815  101152  177777  177777  177777  PPPBF0: .WORD   -1,-1,-1,-1,-1,-1
17816  101160  177777  177777  177777
17817
17818  101166  177777  177777  177777  PPPBF1: .WORD   -1,-1,-1,-1,-1,-1
17819  101174  177777  177777  177777
17820
17821  101202  123456  023456          PPPTP1: .WORD   123456,23456
17822  101206  034567  045671                  .WORD   34567,45671
17823
17824  101212                          PPP10:
17825  101212  104000                          EMT                     ;
17826  101214                          PPPDONE:
17827  101214  004767  017254                  JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
17828                                                                  ;SEE IF THE USER HAS EXPRESSED
17829                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
17830                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
17831                                                                  ;THE USER TYPED CONTROL G?).
17832
17833
17834
17835
17836                                   ;*****************************************************************************************
17837                                   ;TEST 502       FDST MODE 2 TEST
17838                                   ;*****************************************************************************************
17839  101220                          TS502:
17840
17841                                   ;FIRST TEST STF.
17842
17843  101220  012700  177777                  MOV     #-1,R0  ;SET UP THE OUTPUT BUFFER.
17844  101224  012701  101334                  MOV     #QQQBF0,R1
17845  101230  012702  000014                  MOV     #14,R2
17846  101234  010021                  QQQ2:   MOV     R0,(R1)+
17847  101236  077202                          SOB     R2,QQQ2
17848
17849  101240  012700  000200                  MOV     #200,R0         ;SET FD MODE.
17850  101244  170100                          LDFPS   R0
17851  101246  012700  101364                  MOV     #QQQTP1,R0      ;SETUP AC0.
17852  101252  172410                          LDD     (R0),AC0
17853
```

```
17854  101254  012700  101350          MOV     #QQQBF1,R0      ;FDST ADDRESS.
17855  101260  005002                  CLR     R2
17856  101262  170102                  LDFPS   R2              ;SET FPS.
17857  101264  174020          QQQ3:   STF     AC0,(R0)+       ;TEST INSTRUCTION.
17858
17859  101266  022700  101354          CMP     #QQQBF1+4,R0    ;WAS R0 INCREMENTED BY 4 PROPERLY?
17860
17861  101272  001401                  BEQ     QQQ4
17862  101274  104000                  EMT                     ;REPORT R0 INCORRECT AFTER FDST MODE 2
17863  101276  012700  101350  QQQ4:   MOV     #QQQBF1,R0      ;WAS THE OUTPUT DATA CORRECT?
17864  101302  012701  101364          MOV     #QQQTP1,R1
17865  101306  022021                  CMP     (R0)+,(R1)+
17866  101310  001031                  BNE     QQQ10           ;BRANCH IF INCORRECT.
17867  101312  022021                  CMP     (R0)+,(R1)+
17868  101314  001027                  BNE     QQQ10           ;BRANCH IF INCORRECT.
17869  101316  022027  177777          CMP     (R0)+,#-1       ;SEE IF ANY OTHER DATA BUFFER WORDS WERE MODIFIED.
17870  101322  001024                  BNE     QQQ10           ;BRANCH IF INCORRECT.
17871  101324  022027  177777          CMP     (R0)+,#-1
17872  101330  001021                  BNE     QQQ10           ;BRANCH IF INCORRECT.
17873  101332  000421                  BR      QQQ20
17874  101334  177777  177777  177777 QQQBF0: .WORD   -1,-1,-1,-1,-1,-1
17875  101342  177777  177777  177777
17876  101350  177777  177777  177777 QQQBF1: .WORD   -1,-1,-1,-1,-1,-1
17877  101356  177777  177777  177777
17878  101364  076543          QQQTP1: 76543
17879  101366  065432                  65432
17880  101370  054321                  54321
17881  101372  043210                  43210
17882                          ;REPORT OUTPUT DATA INCORRECT:
17883  101374                  QQQ10:
17884  101374  104000                  EMT                     ;
17885
17886                          ;NOW TEST STD MODE 2.
17887
17888  101376  012700  101334  QQQ20:  MOV     #QQQBF0,R0      ;SET UP DEFAULT INPUT DATA BUFFER.
17889  101402  010001                  MOV     R0,R1
17890  101404  012702  000014          MOV     #14,R2
17891  101410  010021          QQQ22:  MOV     R0,(R1)+
17892  101412  077202                  SOB     R2,QQQ22
17893  101414  012700  000200          MOV     #200,R0         ;ENTER FLOATING DOUBLE MODE.
17894  101420  170100                  LDFPS   R0
17895  101422  012700  101364          MOV     #QQQTP1,R0      ;LOAD AC0.
17896  101426  172410                  LDD     (R0),AC0
17897  101430  012700  101350          MOV     #QQQBF1,R0      ;SET DESTINATION ADDRESS.
17898  101434  012737  101442  037366  MOV     #QQQ23,@#$TMP2
17899  101442  174020          QQQ23:  STD     AC0,(R0)+       ;TEST INSTRUCTION.
17900  101444  022700  101360          CMP     #QQQBF1+10,R0   ;WAS R0 INCREMENTED BY 10 CORRECTLY?
17901  101450  001401                  BEQ     QQQ24
17902  101452  104000                  EMT                     ;REPORT R0 INCORRECTLY INCREMENTED
17903  101454  012700  101350  QQQ24:  MOV     #QQQBF1,R0      ;DID THE DATA REACH THE OUTPUT BUFFER CORRECTLY?
17904  101460  012701  101364          MOV     #QQQTP1,R1
17905  101464  012702  000004          MOV     #4,R2
17906  101470  022021          1$:     CMP     (R0)+,(R1)+
17907  101472  001002                  BNE     QQQ25           ;BRANCH IF INCORRECT.
17908  101474  077203                  SOB     R2,1$
17909  101476  000401                  BR      QQQDONE
```

```
17910
17911  101500
17912  101500  104000                    ;REPORT DATA INCORRECT.
17913  101502                    QQQ25:
17914  101502  004767  016766            EMT                     ;
17915                             QQQDONE:
17916                                     JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
17917                                                             ;SEE IF THE USER HAS EXPRESSED
17918                                                             ;THE DESIRE TO CHANGE THE SOFTWARE
17919                                                             ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
17920                                                             ;THE USER TYPED CONTROL G?).
17921                             ;*****************************************************************************
17922                             ;TEST 503       FDST MODE 2, WITH GR7, TEST
17923  101506                     ;*****************************************************************************
17924                             TS503:
17925  101506  012700  101556            MOV     #RRR3,R0        ;SET UP THE DATA BUFFER FOLLOWING THE TEST INSTRUCTION.
17926  101512  012701  101624            MOV     #RRRTP1,R1
17927  101516  012702  000004            MOV     #4,R2
17928  101522  012021             1$:     MOV     (R0)+,(R1)+
17929  101524  077202                    SOB     R2,1$
17930  101526  012700  000200            MOV     #200,R0         ;ENTER FLOATING DOUBLE MODE.
17931  101532  170100                    LDFPS   R0
17932  101534  012700  101634            MOV     #RRRTP2,R0      ;SET UP AC0.
17933  101540  172410                    LDD     (R0),AC0
17934  101542  012737  101622  000004    MOV     #RRR10,@#ERRVECT ;SET UP FOR AN ODD ADDRESS.
17935  101550  005001                    CLR     R1
17936  101552  005004                    CLR     R4
17937                             ;THIS IS THE TEST INSTRUCTION. IT SHOULD MODIFY THE FIRST LOCATION
17938                             ;AFTER IT TO BE AN INCREMENT R4, INC R4, INSTRUCTION INSTEAD
17939                             ;OF AN INCREMENT R1 INSTRUCTION. THE INCREMENT R4 SHOULD NOT BE
17940                             ;EXECUTED SINCE THE PC SHOULD BE INCREMENTED BY TWO DURING IMMEDIATE
17941                             ;MODE ADDRESSING. THUS AFTER THE EXECUTION OF THE NEXT 5 INSTRUCTIONS
17942                             ;R1 SHOULD CONTAIN 3 AND R4 SHOULD CONTAIN 0.
17943  101554  174027             RRR2:   STD     AC0,(R7)+       ;TEST INSTRUCTION.
17944  101556  005201             RRR3:   INC     R1              ;THE STD INSTRUCTION SHOULD CHANGE THIS TO INC R4.
17945  101560  005201                     INC     R1
17946  101562  005201                     INC     R1
17947  101564  005201                     INC     R1
17948  101566  012700  101644            MOV     #RRREXP,R0      ;SEE IF THE DATA WAS OUTPUT CORRECTLY.
17949  101572  012702  101556            MOV     #RRR3,R2
17950  101576  012703  000004            MOV     #4,R3
17951  101602  022022             RRR4:   CMP     (R0)+,(R2)+
17952  101604  001006                     BNE     RRR10           ;BRANCH IF INCORRECT.
17953  101606  077303                     SOB     R3,RRR4
17954  101610  005704                     TST     R4              ;MAKE SURE R4 IS 0.
17955  101612  001003                     BNE     RRR10           ;BRANCH IF R4 IS INCORRECT.
17956  101614  022701  000003            CMP     #3,R1           ;SEE IF R1 IS CORRECT.
17957  101620  001415                     BEQ     RRRDONE
17958  101622                     RRR10:
17959  101622  104000                     EMT                     ;
17960                             ;THESE ARE TEST DATA PATTERNS USED TO SET UP THE OUTPUT BUFFER AT RRR3.
17961  101624  005201             RRRTP1: INC     R1
17962  101626  005201                     INC     R1
17963  101630  005201                     INC     R1
17964  101632  005201                     INC     R1
17965                             ;THIS IS THE DATA PUT IN AC0 BEFORE EXECUTION OF THE STD.
```

```
17966  101634  005204                  RRRTP2: INC     R4
17967  101636  005204                          INC     R4
17968  101640  005204                          INC     R4
17969  101642  005204                          INC     R4
17970                                  ;THIS IS THE EXPECTED DATA AT RRR3 AFTER EXECUTION OF THE STD.
17971  101644  005204                  RRREXP: INC     R4
17972  101646  005201                          INC     R1
17973  101650  005201                          INC     R1
17974  101652  005201                          INC     R1
17975  101654                          RRRDONE:
17976  101654  004767  016614                  JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
17977                                                                  ;SEE IF THE USER HAS EXPRESSED
17978                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
17979                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
17980                                                                  ;THE USER TYPED CONTROL G?).
17981
17982                                  ;*****************************************************************************
17983                                  ;TEST 504       FDST MODE 4 TEST
17984                                  ;*****************************************************************************
17985  101660                          TS504:
17986
17987  101660  012700  177777                  MOV     #-1,R0          ;SET UP THE OUTPUT BUFFER.
17988  101664  012701  102006                  MOV     #SSSBF0,R1
17989  101670  012702  000010                  MOV     #10,R2
17990  101674  010021                  1$:     MOV     R0,(R1)+
17991  101676  077202                          SOB     R2,1$
17992  101700  012700  000200                  MOV     #200,R0         ;ENTER FLOATING DOUBLE MODE.
17993  101704  170100                          LDFPS   R0
17994  101706  012700  102026                  MOV     #SSSTP1,R0      ;SET UP AC0.
17995  101712  172410                          LDD     (R0),AC0
17996  101714  012737  102036  000004         MOV     #SSS10,@#ERRVECT ;SET UP FOR A TRAP TO 4.
17997  101722  012700  102016                  MOV     #SSSA1,R0       ;SET UP THE DESTINATION ADDRESS.
17998
17999  101726  174040                  SSS2:   STD     AC0,-(R0)       ;TEST INSTRUCTION.
18000  101730  005201                          INC     R1
18001  101732  020027  102006                  CMP     R0,#SSSBF0      ;SEE IF R0 WAS DECREMENTED PROPERLY.
18002  101736  001037                          BNE     SSS10           ;BRANCH IF R0 IS INCORRECT.
18003  101740  012700  102006                  MOV     #SSSBF0,R0      ;WAS THE OUTPUT DATA CORRECT?
18004  101744  012701  102026                  MOV     #SSSTP1,R1
18005  101750  012702  000004                  MOV     #4,R2
18006  101754  022021                  1$:     CMP     (R0)+,(R1)+
18007  101756  001027                          BNE     SSS10           ;BRANCH IF INCORRECT.
18008  101760  077203                          SOB     R2,1$
18009  101762  012700  177777                  MOV     #-1,R0          ;IS THE REST OF THE OUTPUT BUFFER CORRECT, -1?
18010  101766  012701  102016                  MOV     #SSSA1,R1
18011  101772  012702  000004                  MOV     #4,R2
18012  101776  020021                  2$:     CMP     R0,(R1)+
18013  102000  001016                          BNE     SSS10           ;BRANCH IF INCORRECT.
18014  102002  077203                          SOB     R2,2$
18015  102004  000415                          BR      SSSDONE
18016
18017                                  ;THIS IS THE OUTPUT DATA BUFFER.
18018  102006  177777                  SSSBF0: -1
18019  102010  177777                          -1
18020  102012  177777                          -1
18021  102014  177777                          -1
```

```
18022  102016  177777                  SSSA1:  -1
18023  102020  177777                          -1
18024  102022  177777                          -1
18025  102024  177777                          -1
18026
18027                                  ;THIS IS THE TEST DATA LOADED INTO AC0:
18028  102026  147250                  SSSTP1: 147250
18029  102030  036147                          36147
18030  102032  025036                          25036
18031  102034  147250                          147250
18032
18033  102036                         SSS10:
18034  102036  104000                          EMT                     ;
18035  102040                         SSSDONE:
18036  102040  004767  016430                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
18037                                                                  ;SEE IF THE USER HAS EXPRESSED
18038                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
18039                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
18040                                                                  ;THE USER TYPED CONTROL G?).
18041
18042                                  ;*****************************************************************************
18043                                  ;TEST 505       FDST MODE 3 TEST
18044                                  ;*****************************************************************************
18045  102044                         TS505:
18046
18047  102044  012701  102154                  MOV     #TTTBF0,R1      ;SET UP THE OUTPUT DATA BUFFER.
18048  102050  012700  177777                  MOV     #-1,R0
18049  102054  012702  000013                  MOV     #13,R2
18050  102060  010021                  1$:     MOV     R0,(R1)+
18051  102062  077202                          SOB     R2,1$
18052  102064  012737  102154  102170          MOV     #TTTBF0,@#TTTA2
18053  102072  012700  000200                  MOV     #200,R0         ;ENTER DOUBLE FLOATING MODE.
18054  102076  170100                          LDFPS   R0
18055  102100  012700  102172                  MOV     #TTTTP1,R0      ;SET UP AC0.
18056  102104  172410                          LDD     (R0),AC0
18057  102106  012737  102202  000004          MOV     #TTT10,@#ERRVECT ;SET UP FOR TRAPS TO 4.
18058  102114  012700  102170                  MOV     #TTTA2,R0       ;SET UP THE DESTINATION ADDRESS.
18059
18060  102120  174030                  TTT2:   STD     AC0,@(R0)+      ;TEST INSTRUCTION.
18061
18062  102122  020027  102172                  CMP     R0,#TTTA2+2     ;SEE IF R0 WAS INCREMENTED CORRECTLY.
18063  102126  001025                          BNE     TTT10           ;BRANCH IF INCORRECT.
18064  102130  012701  102154                  MOV     #TTTBF0,R1      ;CHECK THE OUTPUT DATA BUFFER.
18065  102134  012702  102172                  MOV     #TTTTP1,R2
18066  102140  012703  000004                  MOV     #4,R3
18067  102144  022122                  TTT3:   CMP     (R1)+,(R2)+
18068  102146  001015                          BNE     TTT10           ;BRANCH IF NOT CORRECT.
18069  102150  077303                          SOB     R3,TTT3
18070  102152  000414                          BR      TTTDONE
18071
18072                                  ;THIS IS THHE OUTPUT DATA BUFFER:
18073  102154  177777                  TTTBF0: -1
18074  102156  177777                          -1
18075  102160  177777                          -1
18076  102162  177777                          -1
18077  102164  177777                          -1
```

```
18078  102166  177777                  TTTA1:  -1
18079  102170  102154                  TTTA2:  TTTBF0
18080  102172  101213                  TTTTP1: 101213
18081  102174  141516                          141516
18082  102176  071727                          71727
18083  102200  037475                          37475
18084
18085  102202                          TTT10:
18086  102202  104000                          EMT                     ;
18087
18088  102204                          TTTDONE:
18089  102204  004767  016264                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
18090                                                                  ;SEE IF THE USER HAS EXPRESSED
18091                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
18092                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
18093                                                                  ;THE USER TYPED CONTROL G?).
18094
18095                                  ;*****************************************************************************
18096                                  ;TEST 506       FDST MODE 5 TEST
18097                                  ;*****************************************************************************
18098  102210                          TS506:
18099
18100  102210  012701  102320                  MOV     #UUUBF0,R1      ;SET UP THE OUTPUT DATA BUFFER.
18101  102214  012700  177777                  MOV     #-1,R0
18102  102220  012702  000013                  MOV     #13,R2
18103  102224  010021                  1$:     MOV     R0,(R1)+
18104  102226  077202                          SOB     R2,1$
18105  102230  012737  102320  102332          MOV     #UUUBF0,@#UUUA1
18106  102236  012700  000200                  MOV     #200,R0         ;ENTER DOUBLE FLOATING MODE.
18107  102242  170100                          LDFPS   R0
18108  102244  012700  102336                  MOV     #UUUTP1,R0      ;SET UP AC0.
18109  102250  172410                          LDD     (R0),AC0
18110  102252  012737  102346  000004          MOV     #UUU10,@#ERRVECT ;GET READY FOR ANY TRAPS TO 4.
18111  102260  012700  102334                  MOV     #UUUA2,R0       ;SET UP THE DESTINATION ADDRESS.
18112  102264  174050                  UUU2:   STD     AC0,@-(R0)      ;TEST INSTRUCTION.
18113  102266  020027  102332                  CMP     R0,#UUUA2-2     ;WAS R0 DECRIMENTED PROPERLY?
18114  102272  001025                          BNE     UUU10           ;BRANCH IF R0 IS INCORRECT.
18115  102274  012701  102320                  MOV     #UUUBF0,R1      ;WAS THE DATA OUTPUT CORRECTLY?
18116  102300  012702  102336                  MOV     #UUUTP1,R2
18117  102304  012703  000004                  MOV     #4,R3
18118  102310  022122                  UUU3:   CMP     (R1)+,(R2)+
18119  102312  001015                          BNE     UUU10           ;BRANCH IF DATA IS INCORRECT.
18120  102314  077303                          SOB     R3,UUU3
18121  102316  000414                          BR      UUUDONE
18122
18123                                  ;THIS IS THE OUTPUT DATA BUFFER
18124  102320  177777                  UUUBF0: -1
18125  102322  177777                          -1
18126  102324  177777                          -1
18127  102326  177777                          -1
18128  102330  177777                          -1
18129  102332  102320                  UUUA1:  UUUBF0
18130  102334  177777                  UUUA2:  -1
18131  102336  020212                  UUUTP1: 20212
18132  102340  023242                          23242
18133  102342  026273                          26273
```

```
18134  102344  031323                          031323
18135
18136  102346                          UUU10:
18137  102346  104000                          EMT                     ;
18138  102350                          UUUDONE:
18139  102350  004767  016120                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
18140                                                                  ;SEE IF THE USER HAS EXPRESSED
18141                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
18142                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
18143                                                                  ;THE USER TYPED CONTROL G?).
18144
18145                                  ;*****************************************************************************
18146                                  ;TEST 507       FDST MODE 6, INDEX MODE, TEST
18147                                  ;*****************************************************************************
18148  102354                          TS507:
18149
18150  102354  012700  000200                  MOV     #200,R0         ;ENTER DOUBLE FLOATING MODE.
18151  102360  170100                          LDFPS   R0
18152  102362  012701  102464                  MOV     #VVVBF0,R1      ;SET UP THE OUT PUT DATA BUFFER.
18153  102366  012700  177777                  MOV     #-1,R0
18154  102372  012702  000004                  MOV     #4,R2
18155  102376  010021                  1$:     MOV     R0,(R1)+
18156  102400  077202                          SOB     R2,1$
18157  102402  012737  102504  000004        MOV     #VVV10,@#ERRVECT ;SET UP VECTOR 4 INCASE OF ERROR.
18158  102410  012700  102474                  MOV     #VVVTP1,R0      ;SET UP AC0.
18159  102414  172410                          LDD     (R0),AC0
18160  102416  012700  074563                  MOV     #VVVBF0-5701,R0 ;SET UP THE DESTINATION ADDRESS.
18161  102422  012701  000001                  MOV     #1,R1
18162  102426  174060  005701          VVV2:   STD     AC0,5701(R0)    ;TEST INSTRUCTION.
18163
18164  102432  020027  074563                  CMP     R0,#VVVBF0-5701 ;SEE IF R0 WAS MODIFIED.
18165  102436  001022                          BNE     VVV10           ;BRANCH IF INCORRECT.
18166  102440  012702  102464                  MOV     #VVVBF0,R2      ;WAS THE OUTPUT DATA CORRECT.
18167  102444  012703  102474                  MOV     #VVVTP1,R3
18168  102450  012704  000004                  MOV     #4,R4
18169  102454  022223                  1$:     CMP     (R2)+,(R3)+
18170  102456  001012                          BNE     VVV10           ;BRANCH IF INCORRECT DATA.
18171  102460  077403                          SOB     R4,1$
18172  102462  000411                          BR      VVVDONE
18173  102464  177777                  VVVBF0: -1
18174  102466  177777                          -1
18175  102470  177777                          -1
18176  102472  177777                          -1
18177  102474  030313                  VVVTP1: 30313
18178  102476  023334                          23334
18179  102500  035363                          35363
18180  102502  074041                          74041
18181
18182  102504                          VVV10:
18183  102504  104000                          EMT                     ;
18184  102506                          VVVDONE:
18185  102506  004767  015762                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
18186                                                                  ;SEE IF THE USER HAS EXPRESSED
18187                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
18188                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
18189                                                                  ;THE USER TYPED CONTROL G?).
```

```
18190
18191                                   ;*****************************************************************************
18192                                   ;TEST 510       FDST MODE 7, INDEX DEFERRED MODE, TEST
18193                                   ;*****************************************************************************
18194  102512                           TS510:
18195
18196  102512  012700  000200                   MOV     #200,R0         ;ENTER DOUBLE FLOATING MODE.
18197  102516  170100                           LDFPS   R0
18198  102520  012701  102630                   MOV     #WWWBF0,R1      ;SET UP THE OUTPUT DATA BUFFER.
18199  102524  012700  177777                   MOV     #-1,R0
18200  102530  012702  000004                   MOV     #4,R2
18201  102534  010021                   1$:     MOV     R0,(R1)+
18202  102536  077202                           SOB     R2,1$
18203  102540  012737  102660  000004         MOV     #WWW10,@#ERRVECT ;SET UP FOR TRAPS TO 4.
18204  102546  012700  102640                   MOV     #WWWTP1,R0      ;SET UP AC0.
18205  102552  172410                           LDD     (R0),AC0
18206  102554  012700  074747                   MOV     #WWWBF1-5701,R0 ;SET UP THE DESTINATION ADDRESS.
18207  102560  012701  000001                   MOV     #1,R1
18208  102564  012737  102630  102650         MOV     #WWWBF0,@#WWWBF1
18209  102572  174070  005701           WWW2:   STD     AC0,@5701(R0)   ;TEST INSTRUCTION.
18210
18211  102576  020027  074747                   CMP     R0,#WWWBF1-5701 ;IS R0 CORRECT?
18212  102602  001026                           BNE     WWW10           ;BRANCH IF INCORRECT.
18213  102604  012702  102630                   MOV     #WWWBF0,R2      ;WAS THE DATA OUTPUT CORRECTLY?
18214  102610  012703  102640                   MOV     #WWWTP1,R3
18215  102614  012704  000004                   MOV     #4,R4
18216  102620  022223                   1$:     CMP     (R2)+,(R3)+
18217  102622  001016                           BNE     WWW10           ;BRANCH IF DATA IS INCORRECT.
18218  102624  077403                           SOB     R4,1$
18219  102626  000415                           BR      WWWDONE
18220  102630  177777           WWWBF0: -1
18221  102632  177777                   -1
18222  102634  177777                   -1
18223  102636  177777                   -1
18224  102640  041424           WWWTP1: 41424
18225  102642  034445                   34445
18226  102644  046475                   46475
18227  102646  051525                   051525
18228  102650  177777           WWWBF1: -1
18229  102652  177777                   -1
18230  102654  177777                   -1
18231  102656  177777                   -1
18232
18233  102660                           WWW10:
18234  102660  104000                           EMT                     ;
18235  102662                           WWWDONE:
18236  102662  004767  015606                   JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
18237                                                                   ;SEE IF THE USER HAS EXPRESSED
18238                                                                   ;THE DESIRE TO CHANGE THE SOFTWARE
18239                                                                   ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
18240                                                                   ;THE USER TYPED CONTROL G?).
18241
18242                                   ;*****************************************************************************
18243                                   ;TEST 511       STCFD TEST
18244                                   ;*****************************************************************************
18245  102666                           TS511:
```

```
18246
18247                                   ;AC=0
18248  102666  004767  000262  XXX1:   JSR     PC,STCFDS
18249  102672  000000          1$:     0               ;AC
18250  102674  000000                  0
18251  102676  000000                  0
18252  102700  000000                  0
18253  102702  000000          2$:     0               ;RES
18254  102704  000000                  0
18255  102706  000000                  0
18256  102710  000000                  0
18257  102712  000000          3$:     0               ;ERROR RES.
18258  102714  000000                  0
18259  102716  177777                  -1
18260  102720  177777                  -1
18261  102722  047000          4$:     47000           ;FPS BEFORE EXECUTION.
18262  102724  047004                  47004           ;FPS AFTER EXECUTION.
18263  102726  177777                  -1              ;FEC
18264  102730  147004                  147004          ;ERROR FPS.
18265
18266
18267  102732  004767  000216  XXX2:   JSR     PC,STCFDS
18268  102736  017203          1$:     17203           ;AC
18269  102740  142536                  142536
18270  102742  047506                  47506
18271  102744  172031                  172031
18272  102746  017203          2$:     17203           ;RES
18273  102750  142536                  142536
18274  102752  000000                  0
18275  102754  000000                  0
18276  102756  017203          3$:     17203           ;ERROR RES.
18277  102760  142536                  142536
18278  102762  047506                  47506
18279  102764  172031                  172031
18280  102766  040000          4$:     40000           ;FPS BEFORE EXECUTION.
18281  102770  040000                  40000           ;FPS AFTER EXECUTION.
18282  102772  177777                  -1              ;FEC
18283  102774  177777                  -1              ;ERROR FPS.
18284
18285
18286  102776  004767  000152  XXX3:   JSR     PC,STCFDS
18287  103002  050717          1$:     50717           ;AC
18288  103004  027374                  27374
18289  103006  075767                  75767
18290  103010  077071                  77071
18291  103012  050717          2$:     50717           ;RES
18292  103014  027374                  27374
18293  103016  000000                  0
18294  103020  000000                  0
18295  103022  000000          3$:     0               ;ERROR RES.
18296  103024  000000                  0
18297  103026  000000                  0
18298  103030  000000                  0
18299  103032  047000          4$:     47000           ;FPS BEFORE EXECUTION.
18300  103034  047000                  47000           ;FPS AFTER EXECUTION.
18301  103036  177777                  -1              ;FEC
```

```
18302  103040  174002                          174002          ;ERROR FPS.
18303
18304
18305  103042  004767  000106          XXX4:   JSR     PC,STCFDS
18306  103046  020212                  1$:     20212           ;AC
18307  103050  032425                          32425
18308  103052  026272                          26272
18309  103054  002123                          02123
18310  103056  020212                  2$:     20212           ;RES
18311  103060  032425                          32425
18312  103062  000000                          0
18313  103064  000000                          0
18314  103066  020212                  3$:     20212           ;ERROR RES.
18315  103070  032425                          32425
18316  103072  100000                          100000
18317  103074  000000                          0
18318  103076  040000                  4$:     40000           ;FPS BEFORE EXECUTION.
18319  103100  040000                          40000           ;FPS AFTER EXECUTION.
18320  103102  177777                          -1              ;FEC
18321  103104  177777                          -1              ;ERROR FPS.
18322
18323
18324  103106  004767  000042          XXX5:   JSR     PC,STCFDS
18325  103112  121314                  1$:     121314          ;AC
18326  103114  151617                          151617
18327  103116  101112                          101112
18328  103120  131415                          131415
18329  103122  121314                  2$:     121314          ;RES
18330  103124  151617                          151617
18331  103126  000000                          0
18332  103130  000000                          0
18333  103132  021314                  3$:     21314           ;ERROR RES.
18334  103134  151617                          151617
18335  103136  000000                          0
18336  103140  000000                          0
18337  103142  040000                  4$:     40000           ;FPS BEFORE EXECUTION.
18338  103144  040010                          40010           ;FPS AFTER EXECUTION.
18339  103146  177777                          -1              ;FEC
18340  103150  177777                          -1              ;ERROR FPS.
18341  103152  000460                  6$:     BR      XXXDONE
18342
18343                                  ;
18344
18345
18346                                  ;THIS SUBROUTINE, STCFDS, IS USED TO SET UP THE OPERANDS, EXECUTE
18347                                  ;THE STCFD INSTRUCTION AND CHECK THE RESULTS. A CALL
18348                                  ;TO IT IS MADE THUS:
18349                                  ;
18350                                  ;               JSR     PC,@#STCFDS
18351                                  ;               ACARG:  .WORD   X,X,X,X         ;AC OPERAND
18352                                  ;               RES:    .WORD   X,X,X,X         ;EXPECTED RESULT
18353                                  ;               ERRES:  .WORD   X,X,X,X         ;ERROR RESULT
18354                                  ;               FPSB:   .WORD   X               ;FPS BEFORE EXECUTION
18355                                  ;               FPSA:   .WORD   X               ;FPS AFTER EXECUTION
18356                                  ;               FEC:    .WORD   X               ;EXPECTED FEC
18357                                  ;               ERFPS:  .WORD   X               ;ERROR FPS.
```

```
18358                                   ;               ERR1:   ERROR   X               ;DATA ERROR.
18359                                   ;                       BR      CONT
18360                                   ;               ERR2:   ERROR   X               ;FPS ERROR.
18361                                   ;               CONT:                           ;RETURN ADDRESS
18362                                   ;
18363                                   ;THE OPERANDS ARE SET UP (USING AC0 AS THE ACCUMULATOR). THEN
18364                                   ;THE STCFD INSTRUCTION IS EXECUTED.
18365                                   ;THE RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS
18366                                   ;COMPARED WITH FPSA IF THIS TOO IS CORRECT STCFDS RETURNS CONTROL
18367                                   ;TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD STCFDS
18368                                   ;COMPARE IT TO ERROR FPS. IF THIS MATCHES THEN STCFDS WILL RETURN
18369                                   ;TO THE ERROR CALL AT ERR2, OTHERWISE STCFDS ITSELF
18370                                   ;REPORTS THIS FAILURE AND THEN RETURNS TO CONT. IF THE RESULT OF THE
18371                                   ;STCFD IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE
18372                                   ;ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN
18373                                   ;THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN STCFDS
18374                                   ;WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR1. OTHERWISE THE
18375                                   ;RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND STCFDS WILL
18376                                   ;REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.
18377
18378  103154  012601                   STCFDS: MOV     (SP)+,R1                ;PICK UP THE POINTER TO THE OPERANDS.
18379  103156  012700  000200                   MOV     #200,R0         ;ENTER DOUBLE FLOATING MODE.
18380  103162  170100                           LDFPS   R0
18381  103164  010100                           MOV     R1,R0           ;LOAD AC0.
18382  103166  172410                           LDD     (R0),AC0
18383  103170  012700  177777                   MOV     #-1,R0          ;FILL THE OUTPUT BUFFER WITH -1'S.
18384  103174  012702  103304                   MOV     #STCFT,R2
18385  103200  012703  000004                   MOV     #4,R3
18386  103204  010022                   1$:     MOV     R0,(R2)+
18387  103206  077302                           SOB     R3,1$
18388  103210  016100  000030                   MOV     30(R1),R0       ;LOAD THE FPS.
18389  103214  170100                           LDFPS   R0
18390  103216  012700  103304                   MOV     #STCFT,R0       ;SET UP THE DESTINATION ADDRESS.
18391  103222  176010                   2$:     STCFD   AC0,(R0)        ;TEST INSTRUCTION.
18392
18393  103224  170204                           STFPS   R4              ;GET THE FPS.
18394  103226  170305                           STST    R5              ;GET THE FEC.
18395  103230  010102                           MOV     R1,R2           ;CHECK THE RESULT.
18396  103232  062702  000010                   ADD     #10,R2
18397  103236  012703  103304                   MOV     #STCFT,R3
18398  103242  012700  000004                   MOV     #4,R0
18399  103246  022223                   3$:     CMP     (R2)+,(R3)+
18400  103250  001014                           BNE     10$             ;BRANCH IF INCORRECT.
18401  103252  077003                           SOB     R0,3$
18402
18403  103254  016102  000032                   MOV     32(R1),R2
18404  103260  020204                           CMP     R2,R4           ;IS THE FPS CORRECT?
18405  103262  001007                           BNE     10$             ;BRANCH IF FPS INCORRECT.
18406  103264  005702                           TST     R2              ;IF EXPECTED FPS IS NEGATIVE, THEN
18407  103266  100003                           BPL     4$              ;GO AHEAD AND CHECK THE FEC.
18408  103270  026105  000036                   CMP     36(R1),R5
18409  103274  001002                           BNE     10$             ;BRANCH IF FEC IS INCORRECT.
18410  103276  000161  000040           4$:     JMP     40(R1)          ;RETURN.
18411  103302                           10$:
18412  103302  104000                           EMT                     ;
18413  103304  177777  177777  177777 STCFT:  -1,-1,-1,-1
```

```
18414  103312  177777
18415  103314
18416  103314  004767  015154          XXXDONE:
                                               JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
                                                                       ;SEE IF THE USER HAS EXPRESSED
                                                                       ;THE DESIRE TO CHANGE THE SOFTWARE
                                                                       ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
                                                                       ;THE USER TYPED CONTROL G?).
18421
18422                                  ;*********************************************************************************
18423                                  ;TEST 512       STCDF TEST
18424                                  ;*********************************************************************************
18425  103320                          TS512:
18426
18427                                  ;AC=0
18428  103320  004767  000262         YYY1:   JSR     PC,STCDFS
18429  103324  000000                 1$:     0                       ;AC
18430  103326  000000                         0
18431  103330  000000                         0
18432  103332  000000                         0
18433  103334  000000                 2$:     0                       ;RES
18434  103336  000000                         0
18435  103340  177777                         -1
18436  103342  177777                         -1
18437  103344  000000                 3$:     0                       ;ERROR RES.
18438  103346  000000                         0
18439  103350  000000                         0
18440  103352  000000                         0
18441  103354  047200                 4$:     47200                   ;FPS BEFORE EXECUTION.
18442  103356  047204                         47204                   ;FPS AFTER EXECUTION.
18443  103360  177777                         -1                      ;FEC
18444  103362  177777                         -1                      ;ERROR FPS.
18445
18446
18447  103364  004767  000216         YYY2:   JSR     PC,STCDFS
18448  103370  067574                 1$:     67574                   ;AC0
18449  103372  073727                         73727
18450  103374  170777                         170777
18451  103376  067574                         67574
18452  103400  067574                 2$:     67574                   ;RES
18453  103402  073730                         73730
18454  103404  177777                         -1
18455  103406  177777                         -1
18456  103410  067574                 3$:     67574                   ;ERROR RES.
18457  103412  073727                         73727
18458  103414  177777                         -1
18459  103416  177777                         -1
18460  103420  040200                 4$:     40200                   ;FPS BEFORE EXECUTION.
18461  103422  040200                         40200                   ;FPS AFTER EXECUTION.
18462  103424  177777                         -1                      ;FEC
18463  103426  177777                         -1                      ;ERROR FPS.
18464
18465
18466  103430  004767  000152         YYY3:   JSR     PC,STCDFS
18467  103434  077777                 1$:     77777                   ;AC0
18468  103436  177777                         -1
18469  103440  100000                         100000
```

```
18470  103442  000000                    0
18471  103444  000000          2$:       0                       ;RES
18472  103446  000000                    0
18473  103450  177777                    -1
18474  103452  177777                    -1
18475  103454  077777          3$:       77777                   ;ERROR RES.
18476  103456  177777                    -1
18477  103460  177777                    -1
18478  103462  177777                    -1
18479  103464  040200          4$:       40200                   ;FPS BEFORE EXECUTION.
18480  103466  040206                    40206                   ;FPS AFTER EXECUTION.
18481  103470  177777                    -1                      ;FEC
18482  103472  040204                    40204                   ;ERROR FPS.
18483
18484
18485  103474  004767  000106    YYY4:   JSR     PC,STCDFS
18486  103500  077777          1$:       77777                   ;AC0
18487  103502  177777                    -1
18488  103504  100000                    100000
18489  103506  000000                    0
18490  103510  000000          2$:       0                       ;RES
18491  103512  000000                    0
18492  103514  177777                    -1
18493  103516  177777                    -1
18494  103520  077777          3$:       77777                   ;ERROR RES.
18495  103522  177777                    -1
18496  103524  177777                    -1
18497  103526  177777                    -1
18498  103530  040200          4$:       40200                   ;FPS BEFORE EXECUTION.
18499  103532  040206                    40206                   ;FPS AFTER EXECUTION.
18500  103534  177777                    -1                      ;FEC
18501  103536  140206                    140206                  ;ERROR FPS.
18502
18503
18504  103540  004767  000042    YYY5:   JSR     PC,STCDFS
18505  103544  177777          1$:       177777                  ;AC0
18506  103546  177777                    -1
18507  103550  100000                    100000
18508  103552  000000                    0
18509  103554  100000          2$:       100000                  ;RES
18510  103556  000000                    0
18511  103560  177777                    -1
18512  103562  177777                    -1
18513  103564  000000          3$:       0                       ;ERROR RES.
18514  103566  000000                    0
18515  103570  177777                    -1
18516  103572  177777                    -1
18517  103574  047200          4$:       47200                   ;FPS BEFORE EXECUTION.
18518  103576  147216                    147216                  ;FPS AFTER EXECUTION.
18519  103600  000010                    10                      ;FEC
18520  103602  047206                    47206                   ;ERROR FPS.
18521  103604  000460          6$:       BR      YYYDONE
18522                          ;THIS SUBROUTINE, STCDFS, IS USED TO SET UP THE OPERANDS, EXECUTE
18523                          ;THE STCDF INSTRUCTION AND CHECK THE RESULTS. A CALL
18524                          ;TO IT IS MADE THUS:
18525                          ;
```

```
18526                                   ;               JSR     PC,@#STCFDS
18527                                   ;               ACARG:  .WORD   X,X,X,X         ;AC OPERAND
18528                                   ;               RES:    .WORD   X,X,X,X         ;EXPECTED RESULT
18529                                   ;               ERRES:  .WORD   X,X,X,X         ;ERROR RESULT
18530                                   ;               FPSB:   .WORD   X               ;FPS BEFORE EXECUTION
18531                                   ;               FPSA:   .WORD   X               ;FPS AFTER EXECUTION
18532                                   ;               FEC:    .WORD   X               ;EXPECTED FEC
18533                                   ;               ERFPS:  .WORD   X               ;ERROR FPS.
18534                                   ;               ERR1:   ERROR   X               ;DATA ERROR.
18535                                   ;                       BR      CONT
18536                                   ;               ERR2:   ERROR   X               ;FPS ERROR.
18537                                   ;               CONT:                           ;RETURN ADDRESS
18538                                   ;
18539                                   ;THE OPERANDS ARE SET UP (USING AC0 AS THE ACCUMULATOR). THEN
18540                                   ;THE STCFD INSTRUCTION IS EXECUTED.
18541                                   ;THE RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS
18542                                   ;COMPARED WITH FPSA IF THIS TOO IS CORRECT STCFDS RETURNS CONTROL
18543                                   ;TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD STCFDS
18544                                   ;COMPARE IT TO ERROR FPS. IF THIS MATCHES THEN STCFDS WILL RETURN
18545                                   ;TO THE ERROR CALL AT ERR2, OTHERWISE STCFDS ITSELF
18546                                   ;REPORTS THIS FAILURE AND THEN RETURNS TO CONT. IF THE RESULT OF THE
18547                                   ;STCFD IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE
18548                                   ;ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN
18549                                   ;THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN STCFDS
18550                                   ;WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR1. OTHERWISE THE
18551                                   ;RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND STCFDS WILL
18552                                   ;REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.
18553
18554  103606  012601                  STCDFS: MOV     (SP)+,R1        ;PICK UP THE POINTER TO THE OPERANDS.
18555  103610  012700  000200                  MOV     #200,R0         ;ENTER DOUBLE FLOATING MODE.
18556  103614  170100                          LDFPS   R0
18557  103616  010100                          MOV     R1,R0           ;LOAD AC0.
18558  103620  172410                          LDD     (R0),AC0
18559  103622  012700  177777                  MOV     #-1,R0          ;FILL THE OUTPUT BUFFER WITH -1'S.
18560  103626  012702  103736                  MOV     #STCDT,R2
18561  103632  012703  000004                  MOV     #4,R3
18562  103636  010022                  1$:     MOV     R0,(R2)+
18563  103640  077302                          SOB     R3,1$
18564  103642  016100  000030                  MOV     30(R1),R0       ;LOAD THE FPS.
18565  103646  170100                          LDFPS   R0
18566  103650  012700  103736                  MOV     #STCDT,R0       ;SET UP THE DESTINATION ADDRESS.
18567  103654  176010                  2$:     STCDF   AC0,(R0)        ;TEST INSTRUCTION.
18568
18569  103656  170204                          STFPS   R4              ;GET THE FPS.
18570  103660  170305                          STST    R5              ;GET THE FEC.
18571  103662  010102                          MOV     R1,R2           ;CHECK THE RESULT.
18572  103664  062702  000010                  ADD     #10,R2
18573  103670  012703  103736                  MOV     #STCDT,R3
18574  103674  012700  000004                  MOV     #4,R0
18575  103700  022223                  3$:     CMP     (R2)+,(R3)+
18576  103702  001014                          BNE     10$             ;BRANCH IF INCORRECT.
18577  103704  077003                          SOB     R0,3$
18578
18579  103706  016102  000032                  MOV     32(R1),R2
18580  103712  020204                          CMP     R2,R4           ;IS THE FPS CORRECT?
18581  103714  001007                          BNE     10$             ;BRANCH IF FPS INCORRECT.
```

```
18582  103716  005702                          TST     R2              ;IF EXPECTED FPS IS NEGATIVE, THEN
18583  103720  100003                          BPL     4$              ;GO AHEAD AND CHECK THE FEC.
18584  103722  026105  000034                  CMP     34(R1),R5
18585  103726  001002                          BNE     10$             ;BRANCH IF FEC IS INCORRECT.
18586  103730  000161  000040          4$:     JMP     40(R1)          ;RETURN.
18587  103734                          10$:
18588  103734  104000                          EMT                     ;
18589  103736  177777  177777  177777  STCDT:  -1,-1,-1,-1
18590  103744  177777
18591  103746                          YYYDONE:
18592  103746  004767  014522                  JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
18593                                                                  ;SEE IF THE USER HAS EXPRESSED
18594                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
18595                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
18596                                                                  ;THE USER TYPED CONTROL G?).
18597                                  ;*****************************************************************************
18598                                  ;TEST 513       STCFD WITH ILLEGAL ACCUMULATOR TEST
18599                                  ;*****************************************************************************
18600  103752                          TS513:
18601
18602  103752  012700  040000                  MOV     #40000,R0       ;DISSABLE INTERRUPTS.
18603  103756  170100                          LDFPS   R0
18604  103760  176006                  ZZZ2:   STCFD   AC0,AC6         ;THIS TEST INSTRUCTION SHOULD CAUSE AN ERROR.
18605
18606  103762  170204                          STFPS   R4              ;GET FPS.
18607  103764  170305                          STST    R5              ;GET FEC.
18608  103766  020427  140000                  CMP     R4,#140000      ;IS FPS CORRECT?
18609  103772  001004                          BNE     ZZZ10           ;BRANCH IF INCORRECT FPS.
18610  103774  022705  000002                  CMP     #2,R5           ;IS FEC CORRECT?
18611  104000  001001                          BNE     ZZZ10           ;BRANCH IF INCORRECT.
18612  104002  000401                          BR      ZZZDONE
18613
18614  104004                          ZZZ10:
18615  104004  104000                          EMT                     ;
18616
18617  104006                          ZZZDONE:
18618  104006  004767  014462                  JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
18619                                                                  ;SEE IF THE USER HAS EXPRESSED
18620                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
18621                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
18622                                                                  ;THE USER TYPED CONTROL G?).
18623
18624                                  ;*****************************************************************************
18625                                  ;TEST 514       CLRD TEST
18626                                  ;*****************************************************************************
18627  104012                          TS514:
18628  104012  012700  104116                  MOV     #AABTP1,R0      ;SET UP OUTPUT BUFFER
18629  104016  012701  104106                  MOV     #AABBF0,R1
18630  104022  012702  000004                  MOV     #4,R2
18631  104026  012021                  1$:     MOV     (R0)+,(R1)+
18632  104030  077202                          SOB     R2,1$
18633  104032  012700  104106                  MOV     #AABBF0,R0      ;SET UP DESTINATION OPERAND ADDRESS.
18634  104036  012701  000213                  MOV     #213,R1         ;SET UP FPS.
18635  104042  170101                          LDFPS   R1
18636  104044  170410                  2$:     CLRD    (R0)            ;TEST INSTRUCTION.
18637
```

```
18638  104046  170205                  STFPS   R5              ;GET FPS.
18639  104050  012702  000004          MOV     #4,R2           ;SEE IF RESULT CLEAR, 0.
18640  104054  012701  104106          MOV     #AABBF0,R1
18641  104060  005721          3$:     TST     (R1)+
18642  104062  001010                  BNE     AAB2            ;BRANCH IF RESULT INCORRECT, NOT 0.
18643  104064  077203                  SOB     R2,3$
18644  104066  022705  000204          CMP     #204,R5         ;SEE IF FPS IS CORRECT.
18645  104072  001004                  BNE     AAB2            ;BRANCH IF INCORRECT.
18646  104074  020027  104106          CMP     R0,#AABBF0      ;SEE IF R0 IS CORRECT.
18647  104100  001001                  BNE     AAB2            ;BRANCH IF R0 IS INCORRECT.
18648  104102  000411                  BR      AABDONE
18649
18650
18651  104104                  AAB2:
18652  104104  104000                  EMT                     ;
18653
18654                          ;THIS IS THE TEST DATA BUFFER, OUTPUT DATA BUFFER.
18655  104106  073475          AABBF0: 73475
18656  104110  067707                  67707
18657  104112  127347                  127347
18658  104114  056770                  56770
18659                          ;THIS IS THE DATA USED TO SET UP THE OUTPUT BUFFER.
18660  104116  073475          AABTP1: 73475
18661  104120  067707                  67707
18662  104122  127347                  127347
18663  104124  056770                  56770
18664  104126                  AABDONE:
18665  104126  004767  014342          JSR     PC,,RSET        ;GO INITIALIZE THE FPS AND STACK; AND
18666                                                          ;SEE IF THE USER HAS EXPRESSED
18667                                                          ;THE DESIRE TO CHANGE THE SOFTWARE
18668                                                          ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
18669                                                          ;THE USER TYPED CONTROL G?).
18670
18671                          ;*****************************************************************************
18672                          ;TEST 515       CLRD WITH ILLEGAL ACCUMULATOR TEST
18673                          ;*****************************************************************************
18674  104132                  TS515:
18675  104132  012700  040200          MOV     #40200,R0       ;SET UP THE FPS, NO INTERRUPTS AND FD=1.
18676  104136  170100                  LDFPS   R0
18677  104140  170407          CCB2:   CLRD    AC7             ;TEST INSTRUCTION.
18678
18679  104142  170204                  STFPS   R4              ;GET FPS.
18680  104144  170305                  STST    R5              ;GET FEC.
18681  104146  020427  140200          CMP     R4,#140200              ;IS THE FPS CORRECT?
18682  104152  001004                  BNE     CCB10           ;BRANCH IF FPS IS INCORRECT.
18683  104154  022705  000002          CMP     #2,R5           ;IS THE FEC CORRECT?
18684  104160  001001                  BNE     CCB10           ;BRANCH IF FEC IS INCORRECT.
18685  104162  000401                  BR      CCBDONE
18686
18687  104164                  CCB10:
18688  104164  104000                  EMT                     ;
18689  104166                  CCBDONE:
18690  104166  004767  014302          JSR     PC,,RSET        ;GO INITIALIZE THE FPS AND STACK; AND
18691                                                          ;SEE IF THE USER HAS EXPRESSED
18692                                                          ;THE DESIRE TO CHANGE THE SOFTWARE
18693                                                          ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
```

```
                                        ;THE USER TYPED CONTROL G?).

                        ;*****************************************************************************
                        ;TEST 516       NEGF, ABSF AND TSTF SOURCE MODE 0 WITH ILLEGAL AC7, TEST
                        ;*****************************************************************************
104172                  TS516:

104172  012700  040200          MOV     #40200,R0               ;SET UP THE FPS, FID=1 AND FD=1.
104176  170100                  LDFPS   R0
104200  170707          VVB2:   NEGD    AC7             ;TEST INSTRUCTION.

104202  170204                  STFPS   R4              ;GET FPS.
104204  170305                  STST    R5              ;GET FEC.

104206  022704  140200          CMP     #140200,R4              ;IS FPS CORRECT?
104212  001004                  BNE     VVB10           ;BRANCH IF FPS IS INCORRECT.
104214  022705  000002          CMP     #2,R5           ;IS FEC CORRECT?
104220  001001                  BNE     VVB10           ;BRANCH IF FEC IS INCORRECT.
104222  000401                  BR      VVBDONE
104224                  VVB10:
104224  104000                  EMT                     ;

104226                  VVBDONE:
104226  004767  014242          JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
                                                        ;SEE IF THE USER HAS EXPRESSED
                                                        ;THE DESIRE TO CHANGE THE SOFTWARE
                                                        ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
                                                        ;THE USER TYPED CONTROL G?).

                        ;*****************************************************************************
                        ;TEST 517       NEGF, ABSF AND TSTF SOURCE MODE 0 TEST
                        ;*****************************************************************************
104232                  TS517:

104232  012700  000200          MOV     #200,R0         ;SET FD MODE.
104236  170100                  LDFPS   R0
104240  012700  104332          MOV     #DDBTP1,R0      ;SET UP AC0.
104244  172410                  LDD     (R0),AC0                ;SET AC0 = 0
104246  005000                  CLR     R0              ;CLEAR THE FPS.
104250  170100                  LDFPS   R0
104252  012700  104342          MOV     #DDBTP2,R0              ;LOAD AC0 TO BE A FLOATING 0.
104256  172410                  LDF     (R0),AC0        ;SET AC0=ZERO
                                                        ;FLOAT
104260  012700  000201          MOV     #201,R0         ;SET FD MODE.
104264  170100                  LDFPS   R0
104266  170700          DDB2:   NEGD    AC0             ;TEST INSTRUCTION

104270  170205                  STFPS   R5              ;GET FPS.
104272  012700  000200          MOV     #200,R0         ;SET FD MODE.
104276  170100                  LDFPS   R0
104300  012700  104352          MOV     #DDBBF0,R0      ;GET THE RESULT OUT OF AC0.
104304  174010                  STD     AC0,(R0)
                                                        ;SEE IF THE RESULT IS CORRECT.
104306  012701  000004          MOV     #4,R1
104312  005720          1$:     TST     (R0)+
104314  001005                  BNE     DDB5            ;BRANCH IF THE RESULT IS INCORRECT.
```

```
18750  104316  077103                  SOB     R1,1$
18751  104320  022705  000204          CMP     #204,R5         ;IS THE FPS CORRECT?
18752  104324  001001                  BNE     DDB5            ;BRANCH IF THE FPS IS INCORRECT.
18753  104326  000415                  BR      DDBDONE
18754  104330                  DDB5:
18755  104330  104000                  EMT                     ;
18756
18757                          ;THESE ARE TEST DATA TABLES AND AN OUTPUT BUFFER.
18758  104332  101112          DDBTP1: 101112
18759  104334  131415                  131415
18760  104336  161710                  161710
18761  104340  111213                  111213
18762  104342  000000          DDBTP2: 0
18763  104344  000000                  0
18764  104346  000000                  0
18765  104350  000000                  0
18766
18767  104352  177777          DDBBF0: -1
18768  104354  177777                  -1
18769  104356  177777                  -1
18770  104360  177777                  -1
18771
18772  104362                  DDBDONE:
18773  104362  004767  014106          JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
18774                                                          ;SEE IF THE USER HAS EXPRESSED
18775                                                          ;THE DESIRE TO CHANGE THE SOFTWARE
18776                                                          ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
18777                                                          ;THE USER TYPED CONTROL G?).
18778
18779                          ;*****************************************************************************
18780                          ;TEST 520       NEGF, ABSF AND TSTF SOURCE MODE 1 TEST
18781                          ;*****************************************************************************
18782  104366                  TS520:
18783
18784  104366  012700  104466          MOV     #EEBTP1,R0      ;SET UP THE DATA BUFFER.
18785  104372  012701  104506          MOV     #EEBBF1,R1
18786  104376  012702  000004          MOV     #4,R2
18787  104402  012021          1$:     MOV     (R0)+,(R1)+
18788  104404  077202                  SOB     R2,1$
18789  104406  012700  000200          MOV     #200,R0         ;SET FD MODE.
18790  104412  170100                  LDFPS   R0
18791  104414  012700  104506          MOV     #EEBBF1,R0      ;SET UP THE OPERAND ADDRESS.
18792  104420  012737  104516  000004  MOV     #EEB10,@#ERRVECT ;SET UP VECTOR 4 IN CASE OF ERROR.
18793  104426  170710          EEB2:   NEGD    (R0)            ;TEST INSTRUCTION.
18794
18795  104430  170205                  STFPS   R5              ;GET FPS.
18796  104432  012701  104506          MOV     #EEBBF1,R1      ;SEE IF RESULT IS CORRECT.
18797  104436  012702  000004          MOV     #4,R2
18798  104442  005721          1$:     TST     (R1)+
18799  104444  001024                  BNE     EEB10           ;BRANCH IF NOT CORRECT.
18800  104446  077203                  SOB     R2,1$
18801
18802  104450  020027  104506          CMP     R0,#EEBBF1      ;IS R0 CORRECT?
18803  104454  001020                  BNE     EEB10                   ;BRANCH IF NOT CORRECT.
18804  104456  022705  000204          CMP     #204,R5         ;IS THE FPS CORRECT?
18805  104462  001015                  BNE     EEB10           ;BRANCH IF NOT CORRECT.
```

```
18806  104464  000415                          BR      EEBDONE
18807
18808                                          ;THESE ARE TEST DATA TABLES AND A BUFFER.
18809  104466  000177                  EEBTP1: 177
18810  104470  167574                          167574
18811  104472  137271                          137271
18812  104474  107675                          107675
18813  104476  177777                  EEBBF0: -1
18814  104500  177777                          -1
18815  104502  177777                          -1
18816  104504  177777                          -1
18817  104506  177777                  EEBBF1: -1
18818  104510  177777                          -1
18819  104512  177777                          -1
18820  104514  177777                          -1
18821  104516                          EEB10:
18822  104516  104000                          EMT                     ;
18823  104520                          EEBDONE:
18824  104520  004767  013750                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
18825                                                                  ;SEE IF THE USER HAS EXPRESSED
18826                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
18827                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
18828                                                                  ;THE USER TYPED CONTROL G?).
18829
18830                                          ;*****************************************************************************
18831                                          ;TEST 521       NEGF, ABSF AND TSTF SOURCE MODE 2 TEST
18832                                          ;*****************************************************************************
18833  104524                          TS521:
18834
18835  104524  012700  104624                  MOV     #FFBTP1,R0              ;SET UP THE DATA BUFFER.
18836  104530  012701  104634                  MOV     #FFBBF1,R1
18837  104534  012702  000004                  MOV     #4,R2
18838  104540  012021                  1$:     MOV     (R0)+,(R1)+
18839  104542  077202                          SOB     R2,1$
18840  104544  012700  000200                  MOV     #200,R0         ;SET FD.
18841  104550  170100                          LDFPS   R0
18842  104552  012700  104634                  MOV     #FFBBF1,R0      ;SET UP THE OPERAND ADDRESS.
18843  104556  012737  104644  000004          MOV     #FFB10,@#ERRVECT ;SET UP VECTOR 4 IN CASE OF AN ERROR.
18844
18845  104564  170620                  FFB2:   ABSD    (R0)+           ;TEST INSTRUCTION.
18846
18847  104566  170205                          STFPS   R5              ;GET FPS.
18848  104570  012701  104634                  MOV     #FFBBF1,R1              ;CHECK RESULT.
18849  104574  012702  000004                  MOV     #4,R2
18850  104600  005721                  1$:     TST     (R1)+
18851  104602  001020                          BNE     FFB10           ;BRANCH IF INCORRECT.
18852  104604  077203                          SOB     R2,1$
18853
18854  104606  020027  104644                  CMP     R0,#FFBBF1+10   ;IS R0 CORRECT?
18855  104612  001014                          BNE     FFB10           ;BRANCH IF INCORRECT.
18856  104614  022705  000204                  CMP     #204,R5         ;IS THE FPS CORRECT?
18857  104620  001011                          BNE     FFB10           ;BRANCH IF INCORRECT.
18858  104622  000411                          BR      FFBDONE
18859
18860                                          ;THESE ARE TEST DATA TABLES AND DATA BUFFER.
18861  104624  000177                  FFBTP1: 177
```

```
18862  104626  167574                          167574
18863  104630  137271                          137271
18864  104632  107675                          107675
18865  104634  177777                  FFBBF1: -1
18866  104636  177777                          -1
18867  104640  177777                          -1
18868  104642  177777                          -1
18869  104644                          FFB10:
18870  104644  104000                          EMT                     ;
18871  104646                          FFBDONE:
18872  104646  004767  013622                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
18873                                                                  ;SEE IF THE USER HAS EXPRESSED
18874                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
18875                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
18876                                                                  ;THE USER TYPED CONTROL G?).
18877                                  ;*****************************************************************************
18878                                  ;TEST 522       NEGF, ABSF AND TSTF SOURCE MODE 4 TEST
18879                                  ;*****************************************************************************
18880  104652                          TS522:
18881
18882  104652  012700  104752                  MOV     #GGBTP1,R0              ;SET UP THE DATA BUFFER.
18883  104656  012701  104762                  MOV     #GGBBF0,R1
18884  104662  012702  000004                  MOV     #4,R2
18885  104666  012021                  1$:     MOV     (R0)+,(R1)+
18886  104670  077202                          SOB     R2,1$
18887  104672  012700  000200                  MOV     #200,R0         ;SET FD.
18888  104676  170100                          LDFPS   R0
18889  104700  012700  104772                  MOV     #GGBBF1,R0      ;SET UP THE OPERAND ADDRESS.
18890  104704  012737  105002  000004          MOV     #GGB10,@#ERRVECT ;SET UP VECTOR 4 IN CASE OF AN ERROR.
18891
18892  104712  170640                  GGB2:   ABSD    -(R0)           ;TEST INSTRUCTION.
18893
18894  104714  170205                          STFPS   R5              ;GET FPS.
18895  104716  012701  104762                  MOV     #GGBBF0,R1              ;CHECK RESULT.
18896  104722  012702  000004                  MOV     #4,R2
18897  104726  005721                  1$:     TST     (R1)+
18898  104730  001024                          BNE     GGB10           ;BRANCH IF INCORRECT.
18899  104732  077203                          SOB     R2,1$
18900
18901  104734  020027  104762                  CMP     R0,#GGBBF0      ;IS R0 CORRECT?
18902  104740  001020                          BNE     GGB10           ;BRANCH IF INCORRECT.
18903  104742  022705  000204                  CMP     #204,R5         ;IS THE FPS CORRECT?
18904  104746  001015                          BNE     GGB10           ;BRANCH IF INCORRECT.
18905  104750  000415                          BR      GGBDONE
18906
18907                                  ;THESE ARE TEST DATA TABLES AND DATA BUFFER.
18908  104752  000177                  GGBTP1: 177
18909  104754  117273                          117273
18910  104756  147576                          147576
18911  104760  177071                          177071
18912  104762  177777                  GGBBF0: -1
18913  104764  177777                          -1
18914  104766  177777                          -1
18915  104770  177777                          -1
18916  104772  177777                  GGBBF1: -1
18917  104774  177777                          -1
```

```
18918  104776  177777                          -1
18919  105000  177777                          -1
18920  105002                          GGB10:
18921  105002  104000                          EMT                     ;
18922  105004                          GGBDONE:
18923  105004  004767  013464                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
18924                                                                  ;SEE IF THE USER HAS EXPRESSED
18925                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
18926                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
18927                                                                  ;THE USER TYPED CONTROL G?).
18928                          ;*****************************************************************************
18929                          ;TEST 523       NEGF, ABSF AND TSTF SOURCE MODE 3 TEST
18930                          ;*****************************************************************************
18931  105010                  TS523:
18932
18933  105010  012700  105110                  MOV     #HHBTP1,R0              ;SET UP THE DATA BUFFER.
18934  105014  012701  105130                  MOV     #HHBBF0,R1
18935  105020  012702  000010                  MOV     #10,R2
18936  105024  012021                  1$:     MOV     (R0)+,(R1)+
18937  105026  077202                          SOB     R2,1$
18938  105030  012700  000200                  MOV     #200,R0         ;SET FD.
18939  105034  170100                          LDFPS   R0
18940  105036  012700  105140                  MOV     #HHBBF1,R0      ;SET UP THE OPERAND ADDRESS.
18941  105042  012737  105150  000004          MOV     #HHB10,@#ERRVECT ;SET UP VECTOR 4 IN CASE OF AN ERROR.
18942
18943  105050  170630                  HHB2:   ABSD    @(R0)+          ;TEST INSTRUCTION.
18944
18945  105052  170205                          STFPS   R5              ;GET FPS.
18946  105054  012701  105130                  MOV     #HHBBF0,R1              ;CHECK RESULT.
18947  105060  012702  000004                  MOV     #4,R2
18948  105064  005721                  1$:     TST     (R1)+
18949  105066  001030                          BNE     HHB10           ;BRANCH IF INCORRECT.
18950  105070  077203                          SOB     R2,1$
18951  105072  020027  105142                  CMP     R0,#HHBBF1+2    ;IS R0 CORRECT?
18952  105076  001024                          BNE     HHB10           ;BRANCH IF INCORRECT.
18953  105100  022705  000204                  CMP     #204,R5         ;IS THE FPS CORRECT?
18954  105104  001021                          BNE     HHB10           ;BRANCH IF INCORRECT.
18955  105106  000421                          BR      HHBDONE
18956
18957                                  ;THESE ARE TEST DATA TABLES AND DATA BUFFER.
18958  105110  000177                  HHBTP1: 177
18959  105112  147576                          147576
18960  105114  177071                          177071
18961  105116  107576  105130  177777          107576,HHBBF0,-1,-1,-1
18962  105124  177777  177777
18963  105130  177777                  HHBBF0: -1
18964  105132  177777                          -1
18965  105134  177777                          -1
18966  105136  177777                          -1
18967  105140  177777                  HHBBF1: -1
18968  105142  177777                          -1
18969  105144  177777                          -1
18970  105146  177777                          -1
18971  105150                          HHB10:
18972  105150  104000                          EMT                     ;
18973  105152                          HHBDONE:
```

```
18974  105152  004767  013316                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
18975                                                                   ;SEE IF THE USER HAS EXPRESSED
18976                                                                   ;THE DESIRE TO CHANGE THE SOFTWARE
18977                                                                   ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
18978                                                                   ;THE USER TYPED CONTROL G?).
18979                                  ;*****************************************************************************
18980                                  ;TEST 524       NEGF, ABSF AND TSTF SOURCE MODE 5 TEST
18981                                  ;*****************************************************************************
18982  105156                          TS524:
18983
18984  105156  012700  105256                  MOV     #IIBTP1,R0              ;SET UP THE DATA BUFFER.
18985  105162  012701  105276                  MOV     #IIBBF0,R1
18986  105166  012702  000010                  MOV     #10,R2
18987  105172  012021                  1$:     MOV     (R0)+,(R1)+
18988  105174  077202                          SOB     R2,1$
18989  105176  012700  000200                  MOV     #200,R0         ;SET FD.
18990  105202  170100                          LDFPS   R0
18991  105204  012700  105310                  MOV     #IIBBF1+2,R0    ;SET UP THE OPERAND ADDRESS.
18992  105210  012737  105316  000004          MOV     #IIB10,@#ERRVECT ;SET UP VECTOR 4 IN CASE OF AN ERROR.
18993
18994  105216  170750                  IIB2:   NEGD    @-(R0)          ;TEST INSTRUCTION.
18995
18996  105220  170205                          STFPS   R5              ;GET FPS.
18997  105222  012701  105276                  MOV     #IIBBF0,R1              ;CHECK RESULT.
18998  105226  012702  000004                  MOV     #4,R2
18999  105232  005721                  1$:     TST     (R1)+
19000  105234  001030                          BNE     IIB10           ;BRANCH IF INCORRECT.
19001  105236  077203                          SOB     R2,1$
19002  105240  020027  105306                  CMP     R0,#IIBBF1      ;IS R0 CORRECT?
19003  105244  001024                          BNE     IIB10           ;BRANCH IF INCORRECT.
19004  105246  022705  000204                  CMP     #204,R5         ;IS THE FPS CORRECT?
19005  105252  001021                          BNE     IIB10           ;BRANCH IF INCORRECT.
19006  105254  000421                          BR      IIBDONE
19007
19008                                  ;THESE ARE TEST DATA TABLES AND DATA BUFFER.
19009  105256  000176                  IIBTP1: 176
19010  105260  177074                          177074
19011  105262  127374                          127374
19012  105264  157677  105276  177777          157677,IIBBF0,-1,-1,-1
19013  105272  177777  177777
19014  105276  177777                  IIBBF0: -1
19015  105300  177777                          -1
19016  105302  177777                          -1
19017  105304  177777                          -1
19018  105306  177777                  IIBBF1: -1
19019  105310  177777                          -1
19020  105312  177777                          -1
19021  105314  177777                          -1
19022
19023  105316                          IIB10:
19024  105316  104000                          EMT                     ;
19025  105320                          IIBDONE:
19026  105320  004767  013150                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
19027                                                                   ;SEE IF THE USER HAS EXPRESSED
19028                                                                   ;THE DESIRE TO CHANGE THE SOFTWARE
19029                                                                   ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
```

```
                                        ;THE USER TYPED CONTROL G?).
                        ;*****************************************************************************
                        ;TEST 525       NEGF, ABSF AND TSTF SOURCE MODE 6 TEST
                        ;*****************************************************************************
105324                  TS525:

                                MOV     #JJBTP1,R0              ;SET UP THE DATA BUFFER.
                                MOV     #JJBBF0,R1
                                MOV     #4,R2
                        1$:     MOV     (R0)+,(R1)+
                                SOB     R2,1$
                                MOV     #200,R0         ;SET FD.
                                LDFPS   R0
                                MOV     #JJBBF0-7,R0    ;SET UP THE OPERAND ADDRESS.
                                MOV     #JJB10,@#ERRVECT ;SET UP VECTOR 4 IN CASE OF AN ERROR.

                        JJB2:   ABSD    7(R0)           ;TEST INSTRUCTION.

                                STFPS   R5              ;GET FPS.
                                MOV     #JJBBF0,R1              ;CHECK RESULT.
                                MOV     #4,R2
                        1$:     TST     (R1)+
                                BNE     JJB10           ;BRANCH IF INCORRECT.
                                SOB     R2,1$
                                CMP     R0,#JJBBF0-7    ;IS R0 CORRECT?
                                BNE     JJB10           ;BRANCH IF INCORRECT.
                                CMP     #204,R5         ;IS THE FPS CORRECT?
                                BNE     JJB10           ;BRANCH IF INCORRECT.
                                BR      JJBDONE

                        ;THESE ARE TEST DATA TABLES AND DATA BUFFER.
                        JJBTP1: 177
                                161524
                                131273
                                107174,
                        JJBBF0: -1
                                -1
                                -1
                                -1
                        JJB10:
                                EMT                     ;
                        JJBDONE:
                                JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
                                                        ;SEE IF THE USER HAS EXPRESSED
                                                        ;THE DESIRE TO CHANGE THE SOFTWARE
                                                        ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
                                                        ;THE USER TYPED CONTROL G?).
                        ;*****************************************************************************
                        ;TEST 526       NEGF, ABSF AND TSTF SOURCE MODE 7 TEST
                        ;*****************************************************************************
105456                  TS526:

                                MOV     #KKBTP1,R0              ;SET UP THE DATA BUFFER.
                                MOV     #KKBBF0,R1
                                MOV     #10,R2
                        1$:     MOV     (R0)+,(R1)+
```

```
19086  105474  077202                          SOB     R2,1$
19087  105476  012700  000200                  MOV     #200,R0         ;SET FD.
19088  105502  170100                          LDFPS   R0
19089  105504  012700  105601                  MOV     #KKBBF1-7,R0    ;SET UP THE OPERAND ADDRESS.
19090  105510  012737  105620  000004          MOV     #KKB10,@#ERRVECT ;SET UP VECTOR 4 IN CASE OF AN ERROR.
19091
19092  105516  170770  000007          KKB2:   NEGD    @7(R0)          ;TEST INSTRUCTION.
19093
19094  105522  170205                          STFPS   R5              ;GET FPS.
19095  105524  012701  105600                  MOV     #KKBBF0,R1              ;CHECK RESULT.
19096  105530  012702  000004                  MOV     #4,R2
19097  105534  005721                  1$:     TST     (R1)+
19098  105536  001030                          BNE     KKB10           ;BRANCH IF INCORRECT.
19099  105540  077203                          SOB     R2,1$
19100  105542  020027  105601                  CMP     R0,#KKBBF1-7    ;IS R0 CORRECT?
19101  105546  001024                          BNE     KKB10           ;BRANCH IF INCORRECT.
19102  105550  022705  000204                  CMP     #204,R5         ;IS THE FPS CORRECT?
19103  105554  001021                          BNE     KKB10           ;BRANCH IF INCORRECT.
19104  105556  000421                          BR      KKBDONE
19105
19106                                  ;THESE ARE TEST DATA TABLES AND DATA BUFFER.
19107  105560  000177                  KKBTP1: 177
19108  105562  167574                          167574
19109  105564  137271                          137271
19110  105566  107675  105600  177777          107675,KKBBF0,-1,-1,-1
19111  105574  177777  177777
19112  105600  177777                  KKBBF0: -1
19113  105602  177777                          -1
19114  105604  177777                          -1
19115  105606  177777                          -1
19116  105610  177777                  KKBBF1: -1
19117  105612  177777                          -1
19118  105614  177777                          -1
19119  105616  177777                          -1
19120  105620                          KKB10:
19121  105620  104000                          EMT                     ;
19122  105622                          KKBDONE:
19123  105622  004767  012646                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
19124                                                                  ;SEE IF THE USER HAS EXPRESSED
19125                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
19126                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
19127                                                                  ;THE USER TYPED CONTROL G?).
19128                                  ;*****************************************************************************
19129                                  ;TEST 527       NEGF, ABSF AND TSTF SOURCE MODE 6, GR7, TEST
19130                                  ;*****************************************************************************
19131  105626                          TS527:
19132  105626  012700  105716                  MOV     #LLBTP1,R0              ;SET UP THE DATA BUFFER.
19133  105632  012701  105726                  MOV     #LLBBF0,R1
19134  105636  012702  000004                  MOV     #4,R2
19135  105642  012021                  1$:     MOV     (R0)+,(R1)+
19136  105644  077202                          SOB     R2,1$
19137  105646  012700  000200                  MOV     #200,R0         ;SET FD.
19138  105652  170100                          LDFPS   R0
19139  105654  012737  105736  000004          MOV     #LLB10,@#ERRVECT ;SET UP VECTOR 4 IN CASE OF AN ERROR.
19140
19141  105662  170767  000040          LLB2:   NEGD    LLBBF0          ;TEST INSTRUCTION.
```

```
19142
19143  105666  170205                  STFPS   R5              ;GET FPS.
19144  105670  012701  105726          MOV     #LLBBF0,R1              ;CHECK RESULT.
19145  105674  012702  000004          MOV     #4,R2
19146  105700  005721                  1$:     TST     (R1)+
19147  105702  001015                  BNE     LLB10           ;BRANCH IF INCORRECT.
19148  105704  077203                  SOB     R2,1$
19149  105706  022705  000204          CMP     #204,R5         ;IS THE FPS CORRECT?
19150  105712  001011                  BNE     LLB10           ;BRANCH IF INCORRECT.
19151  105714  000411                  BR      LLBDONE
19152
19153                                  ;THESE ARE TEST DATA TABLES AND DATA BUFFER.
19154  105716  000127                  LLBTP1: 127
19155  105720  137475                          137475
19156  105722  147372                          147372
19157  105724  117057                          117057
19158  105726  177777                  LLBBF0: -1
19159  105730  177777                          -1
19160  105732  177777                          -1
19161  105734  177777                          -1
19162
19163  105736                          LLB10:
19164  105736  104000                          EMT             ;
19165  105740                          LLBDONE:
19166  105740  004767  012530                  JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
19167                                                          ;SEE IF THE USER HAS EXPRESSED
19168                                                          ;THE DESIRE TO CHANGE THE SOFTWARE
19169                                                          ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
19170                                                          ;THE USER TYPED CONTROL G?).
19171                                  ;*****************************************************************************
19172                                  ;TEST 530       NEGF, ABSF AND TSTF SOURCE MODE 7, GR7, TEST
19173                                  ;*****************************************************************************
19174  105744                          TS530:
19175
19176  105744  012700  106034                  MOV     #MMBTP1,R0              ;SET UP THE DATA BUFFER.
19177  105750  012701  106054                  MOV     #MMBBF0,R1
19178  105754  012702  000010                  MOV     #10,R2
19179  105760  012021                  1$:     MOV     (R0)+,(R1)+
19180  105762  077202                  SOB     R2,1$
19181  105764  012700  000200                  MOV     #200,R0         ;SET FD.
19182  105770  170100                  LDFPS   R0
19183  105772  012737  106074  000004          MOV     #MMB10,@#ERRVECT ;SET UP VECTOR 4 IN CASE OF AN ERROR.
19184
19185  106000  170677  000060          MMB2:   ABSD    @MMBBF1         ;TEST INSTRUCTION.
19186
19187  106004  170205                  STFPS   R5              ;GET FPS.
19188  106006  012701  106054          MOV     #MMBBF0,R1              ;CHECK RESULT.
19189  106012  012702  000004          MOV     #4,R2
19190  106016  005721                  1$:     TST     (R1)+
19191  106020  001025                  BNE     MMB10           ;BRANCH IF INCORRECT.
19192  106022  077203                  SOB     R2,1$
19193  106024  022705  000204          CMP     #204,R5         ;IS THE FPS CORRECT?
19194  106030  001021                  BNE     MMB10           ;BRANCH IF INCORRECT.
19195  106032  000421                  BR      MMBDONE
19196
19197                                  ;THESE ARE TEST DATA TABLES AND DATA BUFFER.
```

```
19198  106034  000137                  MMBTP1: 137
19199  106036  045607                          045607
19200  106040  101230                          101230
19201  106042  045607  106054  177777          45607,MMBBF0,-1,-1,-1
19202  106050  177777  177777
19203  106054  177777                  MMBBF0: -1
19204  106056  177777                          -1
19205  106060  177777                          -1
19206  106062  177777                          -1
19207  106064  177777                  MMBBF1: -1
19208  106066  177777                          -1
19209  106070  177777                          -1
19210  106072  177777                          -1
19211
19212  106074                          MMB10:
19213  106074  104000                          EMT                     ;
19214  106076                          MMBDONE:
19215  106076  004767  012372                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
19216                                                                  ;SEE IF THE USER HAS EXPRESSED
19217                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
19218                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
19219                                                                  ;THE USER TYPED CONTROL G?).
19220                                  ;*****************************************************************************
19221                                  ;TEST 531       SPECIAL DEST, MODE 0, TEST
19222                                  ;*****************************************************************************
19223  106102                          TS531:
19224
19225  106102  012700  000200                  MOV     #200,R0         ;SET FD.
19226  106106  170100                          LDFPS   R0
19227  106110  012700  106170                  MOV     #NNBTP1,R0              ;SET UP AC0.
19228  106114  172410                          LDD     (R0),AC0
19229  106116  170700                  NNB2:   NEGD    AC0             ;TEST INSTRUCTION.
19230
19231  106120  170205                          STFPS   R5              ;GET FPS.
19232  106122  012700  000200                  MOV     #200,R0         ;SET FD.
19233  106126  170100                          LDFPS   R0
19234  106130  012700  106210                  MOV     #NNBBF0,R0              ;GET THE RESULT.
19235  106134  174010                          STD     AC0,(R0)
19236  106136  012700  106210                  MOV     #NNBBF0,R0              ;IS THE RESULT CORRECT?
19237  106142  012701  106200                  MOV     #NNBTP2,R1
19238  106146  012702  000004                  MOV     #4,R2
19239  106152  022021                  1$:     CMP     (R0)+,(R1)+
19240  106154  001021                          BNE     NNB10           ;BRANCH IF INCORRECT.
19241  106156  077203                          SOB     R2,1$
19242  106160  022705  000210                  CMP     #210,R5         ;IS THE FPS CORRECT?
19243  106164  001015                          BNE     NNB10           ;BRANCH IF INCORRECT.
19244  106166  000415                          BR      NNBDONE
19245
19246                                  ;THESE ARE DATA TABLES AND A DATA BUFFER.
19247  106170  013572                  NNBTP1: 013572
19248  106172  046013                          46013
19249  106174  057246                          57246
19250  106176  013570                          013570
19251  106200  113572                  NNBTP2: 113572
19252  106202  046013                          46013
19253  106204  057246                          57246
```

```
                                013570
19254  106206  013570   NNBBF0: 0
19255  106210  000000           0
19256  106212  000000           0
19257  106214  000000           0
19258  106216  000000
19259
19260  106220           NNB10:
19261  106220  104000           EMT                     ;
19262  106222           NNBDONE:
19263  106222  004767  012246   JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
19264                                                    ;SEE IF THE USER HAS EXPRESSED
19265                                                    ;THE DESIRE TO CHANGE THE SOFTWARE
19266                                                    ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
19267                                                    ;THE USER TYPED CONTROL G?).
19268           ;*************************************************************************************
19269           ;TEST 532       SPECIAL DEST, MODE 1, TEST
19270           ;*************************************************************************************
19271  106226   TS532:
19272
19273  106226  012701  106330           MOV     #OOBTP1,R1      ;SET UP THE DATA BUFFER.
19274  106232  012700  106340           MOV     #OOBTP2,R0
19275  106236  012702  000004           MOV     #4,R2
19276  106242  012021           1$:     MOV     (R0)+,(R1)+
19277  106244  077202                   SOB     R2,1$
19278  106246  012700  106330           MOV     #OOBTP1,R0
19279  106252  042710  100000           BIC     #100000,(R0)    ;MAKE OPERAND POSITIVE.
19280  106256  012701  000200           MOV     #200,R1         ;SET FD.
19281  106262  170101                   LDFPS   R1
19282
19283  106264  170710           OOB2:   NEGD    (R0)            ;TEST INSTRUCTION.
19284  106266  170205                   STFPS   R5              ;GET FPS.
19285  106270  012701  106330           MOV     #OOBTP1,R1              ;IS THE RESULT CORRECT.
19286  106274  012702  106340           MOV     #OOBTP2,R2
19287  106300  012703  000004           MOV     #4,R3
19288  106304  022122           1$:     CMP     (R1)+,(R2)+
19289  106306  001020                   BNE     OOB10           ;BRANCH IF INCORRECT.
19290  106310  077303                   SOB     R3,1$
19291  106312  022700  106330           CMP     #OOBTP1,R0      ;IS R0 CORRECT.
19292  106316  001014                   BNE     OOB10           ;BRANCH IF INCORRECT.
19293  106320  022705  000210           CMP     #210,R5         ;IS THE FPS CORRECT?
19294  106324  001011                   BNE     OOB10           ;BRANCH IF INCORRECT.
19295  106326  000411                   BR      OOBDONE
19296
19297           ;THESE ARE DATA TABLES AND A DATA BUFFER.
19298  106330  023245           OOBTP1: 023245
19299  106332  026720                   26720
19300  106334  122324                   122324
19301  106336  052672                   52672
19302  106340  123245           OOBTP2: 123245
19303  106342  026720                   26720
19304  106344  122324                   122324
19305  106346  052672                   52672
19306
19307  106350           OOB10:
19308  106350  104000           EMT                     ;
19309  106352           OOBDONE:
```

```
19310  106352  004767  012116                  JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
19311                                                                   ;SEE IF THE USER HAS EXPRESSED
19312                                                                   ;THE DESIRE TO CHANGE THE SOFTWARE
19313                                                                   ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
19314                                                                   ;THE USER TYPED CONTROL G?).
19315                                  ;*****************************************************************************
19316                                  ;TEST 533       SPECIAL DEST, MODE 2, TEST
19317                                  ;*****************************************************************************
19318  106356                          TS533:
19319
19320  106356  012701  106460                  MOV     #PPBTP1,R1      ;SET UP THE DATA BUFFER.
19321  106362  012700  106470                  MOV     #PPBTP2,R0
19322  106366  012702  000004                  MOV     #4,R2
19323  106372  012021                  1$:     MOV     (R0)+,(R1)+
19324  106374  077202                          SOB     R2,1$
19325  106376  012700  106460                  MOV     #PPBTP1,R0
19326  106402  042710  100000                  BIC     #100000,(R0)    ;MAKE OPERAND POSITIVE.
19327  106406  012701  000200                  MOV     #200,R1         ;SET FD.
19328  106412  170101                          LDFPS   R1
19329
19330  106414  170720                  PPB2:   NEGD    (R0)+           ;TEST INSTRUCTION.
19331
19332  106416  170205                          STFPS   R5              ;GET FPS.
19333  106420  012701  106460                  MOV     #PPBTP1,R1              ;IS THE RESULT CORRECT.
19334  106424  012702  106470                  MOV     #PPBTP2,R2
19335  106430  012703  000004                  MOV     #4,R3
19336  106434  022122                  1$:     CMP     (R1)+,(R2)+
19337  106436  001020                          BNE     PPB10           ;BRANCH IF INCORRECT.
19338  106440  077303                          SOB     R3,1$
19339  106442  022700  106470                  CMP     #PPBTP1+10,R0   ;IS R0 CORRECT.
19340  106446  001014                          BNE     PPB10           ;BRANCH IF INCORRECT.
19341  106450  022705  000210                  CMP     #210,R5         ;IS THE FPS CORRECT?
19342  106454  001011                          BNE     PPB10           ;BRANCH IF INCORRECT.
19343  106456  000411                          BR      PPBDONE
19344
19345                                  ;THESE ARE DATA TABLES AND A DATA BUFFER.
19346  106460  023245                  PPBTP1: 023245
19347  106462  026720                          26720
19348  106464  122324                          122324
19349  106466  052672                          52672
19350  106470  123245                  PPBTP2: 123245
19351  106472  026720                          26720
19352  106474  122324                          122324
19353  106476  052672                          52672
19354
19355  106500                          PPB10:
19356  106500  104000                          EMT                     ;
19357  106502                          PPBDONE:
19358  106502  004767  011766                  JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
19359                                                                   ;SEE IF THE USER HAS EXPRESSED
19360                                                                   ;THE DESIRE TO CHANGE THE SOFTWARE
19361                                                                   ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
19362                                                                   ;THE USER TYPED CONTROL G?).
19363                                  ;*****************************************************************************
19364                                  ;TEST 534       SPECIAL DEST, MODE 4, TEST !
19365                                  ;*****************************************************************************
```

```
19366  106506                                  TS534:
19367  106506  012701  106612                          MOV     #QQBTP1,R1      ;SET UP THE DATA BUFFER.
19368  106512  012700  106632                          MOV     #QQBTP2,R0
19369  106516  012702  000004                          MOV     #4,R2
19370  106522  012021                          1$:     MOV     (R0)+,(R1)+
19371  106524  077202                                  SOB     R2,1$
19372  106526  012700  106622                          MOV     #QQBTP1+10,R0
19373  106532  042760  100000  177770                  BIC     #100000,-10(R0) ;MAKE OPERAND POSITIVE.
19374  106540  012701  000200                          MOV     #200,R1         ;SET FD.
19375  106544  170101                                  LDFPS   R1
19376
19377  106546  170740                          QQB2:   NEGD    -(R0)           ;TEST INSTRUCTION.
19378
19379  106550  170205                                  STFPS   R5              ;GET FPS.
19380  106552  012701  106612                          MOV     #QQBTP1,R1              ;IS THE RESULT CORRECT.
19381  106556  012702  106632                          MOV     #QQBTP2,R2
19382  106562  012703  000004                          MOV     #4,R3
19383  106566  022122                          1$:     CMP     (R1)+,(R2)+
19384  106570  001024                                  BNE     QQB10           ;BRANCH IF INCORRECT.
19385  106572  077303                                  SOB     R3,1$
19386  106574  022700  106612                          CMP     #QQBTP1,R0      ;IS R0 CORRECT.
19387  106600  001020                                  BNE     QQB10           ;BRANCH IF INCORRECT.
19388  106602  022705  000210                          CMP     #210,R5         ;IS THE FPS CORRECT?
19389  106606  001015                                  BNE     QQB10           ;BRANCH IF INCORRECT.
19390  106610  000415                                  BR      QQBDONE
19391
19392                                          ;THESE ARE DATA TABLES AND A DATA BUFFER.
19393  106612  023245                          QQBTP1: 023245
19394  106614  026720                                  26720
19395  106616  122324                                  122324
19396  106620  052672                                  52672
19397  106622  177777  177777  177777                .WORD   -1,-1,-1,-1
19398  106630  177777
19399  106632  123245                          QQBTP2: 123245
19400  106634  026720                                  26720
19401  106636  122324                                  122324
19402  106640  052672                                  52672
19403
19404  106642                                  QQB10:
19405  106642  104000                                  EMT                     ;
19406  106644                                  QQBDONE:
19407  106644  004767  011624                          JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
19408                                                                          ;SEE IF THE USER HAS EXPRESSED
19409                                                                          ;THE DESIRE TO CHANGE THE SOFTWARE
19410                                                                          ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
19411                                                                          ;THE USER TYPED CONTROL G?).
19412
19413                                          ;*****************************************************************************
19414                                          ;TEST 535       SPECIAL DEST, MODE 3, TEST
19415                                          ;*****************************************************************************
19416  106650                                  TS535:
19417
19418  106650  012701  106760                          MOV     #RRBTP1,R1      ;SET UP THE DATA BUFFER.
19419  106654  012700  106770                          MOV     #RRBTP2,R0
19420  106660  012702  000004                          MOV     #4,R2
19421  106664  012021                          1$:     MOV     (R0)+,(R1)+
```

```
19422  106666  077202                          SOB     R2,1$
19423  106670  012700  107000                  MOV     #RRBTP3,R0
19424  106674  012710  106760                  MOV     #RRBTP1,(R0)
19425  106700  042737  100000  106760          BIC     #100000,@#RRBTP1        ;MAKE THE OPERAND POSITIVE.
19426  106706  012701  000200                  MOV     #200,R1         ;SET FD.
19427  106712  170101                          LDFPS   R1
19428
19429  106714  170730                  RRB2:   NEGD    @(R0)+          ;TEST INSTRUCTION.
19430
19431  106716  170205                          STFPS   R5              ;GET FPS.
19432  106720  012701  106760                  MOV     #RRBTP1,R1              ;IS THE RESULT CORRECT.
19433  106724  012702  106770                  MOV     #RRBTP2,R2
19434  106730  012703  000004                  MOV     #4,R3
19435  106734  022122                  1$:     CMP     (R1)+,(R2)+
19436  106736  001021                          BNE     RRB10           ;BRANCH IF INCORRECT.
19437  106740  077303                          SOB     R3,1$
19438  106742  022700  107002                  CMP     #RRBTP3+2,R0    ;IS R0 CORRECT.
19439  106746  001015                          BNE     RRB10           ;BRANCH IF INCORRECT.
19440  106750  022705  000210                  CMP     #210,R5         ;IS THE FPS CORRECT?
19441  106754  001012                          BNE     RRB10           ;BRANCH IF INCORRECT.
19442  106756  000412                          BR      RRBDONE
19443
19444                                  ;THESE ARE DATA TABLES AND A DATA BUFFER.
19445  106760  023245                  RRBTP1: 023245
19446  106762  026720                          26720
19447  106764  122324                          122324
19448  106766  052672                          52672
19449  106770  123245                  RRBTP2: 123245
19450  106772  026720                          26720
19451  106774  123324                          123324
19452  106776  052672                          52672
19453  107000  106760                  RRBTP3: RRBTP1
19454
19455  107002                          RRB10:
19456  107002  104000                          EMT                     ;
19457  107004                          RRBDONE:
19458  107004  004767  011464                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
19459                                                                  ;SEE IF THE USER HAS EXPRESSED
19460                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
19461                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
19462                                                                  ;THE USER TYPED CONTROL G?).
19463
19464                                  ;*****************************************************************************
19465                                  ;TEST 536       SPECIAL DEST, MODE 5, TEST
19466                                  ;*****************************************************************************
19467  107010                          TS536:
19468  107010  012701  107122                  MOV     #SSBTP1,R1      ;SET UP THE DATA BUFFER.
19469  107014  012700  107132                  MOV     #SSBTP2,R0
19470  107020  012702  000004                  MOV     #4,R2
19471  107024  012021                  1$:     MOV     (R0)+,(R1)+
19472  107026  077202                          SOB     R2,1$
19473  107030  012700  107144                  MOV     #SSBTP3+2,R0
19474  107034  012760  107122  177776          MOV     #SSBTP1,-2(R0)
19475  107042  042737  100000  107122          BIC     #100000,@#SSBTP1        ;MAKE THE OPERAND POSITIVE.
19476  107050  012701  000200                  MOV     #200,R1         ;SET FD.
19477  107054  170101                          LDFPS   R1
```

```
19478
19479  107056  170750                  SSB2:   NEGD    @-(R0)          ;TEST INSTRUCTION.
19480
19481  107060  170205                          STFPS   R5              ;GET FPS.
19482  107062  012701  107122                  MOV     #SSBTP1,R1              ;IS THE RESULT CORRECT.
19483  107066  012702  107132                  MOV     #SSBTP2,R2
19484  107072  012703  000004                  MOV     #4,R3
19485  107076  022122                  1$:     CMP     (R1)+,(R2)+
19486  107100  001021                          BNE     SSB10           ;BRANCH IF INCORRECT.
19487  107102  077303                          SOB     R3,1$
19488  107104  022700  107142                  CMP     #SSBTP3,R0      ;IS R0 CORRECT.
19489  107110  001015                          BNE     SSB10           ;BRANCH IF INCORRECT.
19490  107112  022705  000210                  CMP     #210,R5         ;IS THE FPS CORRECT?
19491  107116  001012                          BNE     SSB10           ;BRANCH IF INCORRECT.
19492  107120  000412                          BR      SSBDONE
19493
19494                                  ;THESE ARE DATA TABLES AND A DATA BUFFER.
19495  107122  023245                  SSBTP1: 023245
19496  107124  026720                          26720
19497  107126  122324                          122324
19498  107130  052672                          52672
19499  107132  123245                  SSBTP2: 123245
19500  107134  026270                          26270
19501  107136  122324                          122324
19502  107140  052672                          52672
19503  107142  107122                  SSBTP3: SSBTP1
19504
19505  107144                          SSB10:
19506  107144  104000                          EMT                     ;
19507  107146                          SSBDONE:
19508  107146  004767  011322                  JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
19509                                                                  ;SEE IF THE USER HAS EXPRESSED
19510                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
19511                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
19512                                                                  ;THE USER TYPED CONTROL G?).
19513                                  ;*****************************************************************************
19514                                  ;TEST 537       SPECIAL DEST, FLOATING MODE 2, TEST
19515                                  ;*****************************************************************************
19516  107152                          TS537:
19517  107152  012701  107254                  MOV     #TTBTP1,R1      ;SET UP THE DATA BUFFER.
19518  107156  012700  107264                  MOV     #TTBTP2,R0
19519  107162  012702  000004                  MOV     #4,R2
19520  107166  012021                  1$:     MOV     (R0)+,(R1)+
19521  107170  077202                          SOB     R2,1$
19522  107172  012700  107254                  MOV     #TTBTP1,R0
19523  107176  042710  100000                  BIC     #100000,(R0)    ;MAKE OPERAND POSITIVE.
19524  107202  012701  000000                  MOV     #000,R1         ;SET FD.
19525  107206  170101                          LDFPS   R1
19526
19527  107210  170720                  TTB2:   NEGF    (R0)+           ;TEST INSTRUCTION.
19528
19529  107212  170205                          STFPS   R5              ;GET FPS.
19530  107214  012701  107254                  MOV     #TTBTP1,R1              ;IS THE RESULT CORRECT.
19531  107220  012702  107264                  MOV     #TTBTP2,R2
19532  107224  012703  000004                  MOV     #4,R3
19533  107230  022122                  1$:     CMP     (R1)+,(R2)+
```

```
19534  107232  001020                          BNE     TTB10           ;BRANCH IF INCORRECT.
19535  107234  077303                          SOB     R3,1$
19536  107236  022700  107260                  CMP     #TTBTP1+4,R0    ;IS R0 CORRECT.
19537  107242  001014                          BNE     TTB10           ;BRANCH IF INCORRECT.
19538  107244  022705  000010                  CMP     #010,R5         ;IS THE FPS CORRECT?
19539  107250  001011                          BNE     TTB10           ;BRANCH IF INCORRECT.
19540  107252  000411                          BR      TTBDONE
19541
19542                                          ;THESE ARE DATA TABLES AND A DATA BUFFER.
19543  107254  023245                  TTBTP1: 023245
19544  107256  026720                          26720
19545  107260  122324                          122324
19546  107262  052672                          52672
19547  107264  123245                  TTBTP2: 123245
19548  107266  026720                          26720
19549  107270  122324                          122324
19550  107272  052672                          52672
19551
19552  107274                          TTB10:
19553  107274  104000                          EMT                     ;
19554  107276                          TTBDONE:
19555  107276  004767  011172                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
19556                                                                  ;SEE IF THE USER HAS EXPRESSED
19557                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
19558                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
19559                                                                  ;THE USER TYPED CONTROL G?).
19560                                  ;*****************************************************************************
19561                                  ;TEST 540       SPECIAL DEST, MODE2, GR7 (IMMEDIATE), TEST
19562                                  ;*****************************************************************************
19563  107302                          TS540:
19564  107302  012700  107420                  MOV     #UUBTP2,R0
19565  107306  012701  107346                  MOV     #UUBTP1,R1      ;SET UP THE DATA BUFFER.
19566  107312  012702  000004                  MOV     #4,R2
19567  107316  012021                  1$:     MOV     (R0)+,(R1)+
19568  107320  077202                          SOB     R2,1$
19569  107322  012700  107346                  MOV     #UUBTP1,R0
19570  107326  042737  100000  107346          BIC     #100000,@#UUBTP1        ;MAKE THE OPERAND POSITIVE.
19571  107334  012701  000200                  MOV     #200,R1         ;SET FD.
19572  107340  170101                          LDFPS   R1
19573  107342  005001                          CLR     R1
19574
19575  107344  170727                  UUB2:   NEGD    (R7)+           ;TEST INSTRUCTION.
19576  107346  005201  005201  005201  UUBTP1: 5201,5201,5201,5201
19577  107354  005201
19578                                  ;NOTE THAT AFTER EXECUTING THIS INSTRUCTION R1 SHOULD CONTAIN 3.
19579  107356  170205                          STFPS   R5              ;GET FPS.
19580  107360  012703  107346                  MOV     #UUBTP1,R3      ;IS THE RESULT CORRECT.
19581  107364  012702  107420                  MOV     #UUBTP2,R2
19582  107370  012704  000004                  MOV     #4,R4
19583  107374  022322                  1$:     CMP     (R3)+,(R2)+
19584  107376  001014                          BNE     UUB10           ;BRANCH IF INCORRECT.
19585  107400  077403                          SOB     R4,1$
19586  107402  022701  000003                  CMP     #3,R1           ;WAS R1 INCREMENTED CORRECTLY.
19587  107406  001010                          BNE     UUB10           ;BRANCH IF INCORRECT.
19588  107410  022705  000210                  CMP     #210,R5         ;IS THE FPS CORRECT?
19589  107414  001005                          BNE     UUB10           ;BRANCH IF INCORRECT.
```

```
19590  107416  000405                          BR      UUBDONE
19591
19592                                          ;THESE ARE DATA TABLE.
19593  107420  105201                  UUBTP2: 105201
19594  107422  005201                          5201
19595  107424  005201                          5201
19596  107426  005201                          5201
19597
19598  107430                          UUB10:
19599  107430  104000                          EMT                     ;
19600  107432                          UUBDONE:
19601  107432  004767  011036                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
19602                                                                  ;SEE IF THE USER HAS EXPRESSED
19603                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
19604                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
19605                                                                  ;THE USER TYPED CONTROL G?).
19606                                          ;*************************************************************************
19607                                          ;TEST 541       SPECIAL DEST, MODE 6, TEST
19608                                          ;*************************************************************************
19609  107436                          TS541:
19610  107436  012701  107552                  MOV     #XXBTP1,R1      ;SET UP THE DATA BUFFER.
19611  107442  012700  107562                  MOV     #XXBTP2,R0
19612  107446  012702  000004                  MOV     #4,R2
19613  107452  012021                  1$:     MOV     (R0)+,(R1)+
19614  107454  077202                          SOB     R2,1$
19615  107456  012700  102351                  MOV     #XXBTP1-5201,R0
19616  107462  042737  100000  107552          BIC     #100000,@#XXBTP1;MAKE OPERAND POSITIVE.
19617  107470  012701  000200                  MOV     #200,R1         ;SET FD.
19618  107474  170101                          LDFPS   R1
19619
19620  107476  005001                          CLR     R1
19621  107500  170760  005201          XXB2:   NEGD    5201(R0)                ;TEST INSTRUCTION.
19622
19623  107504  170205                          STFPS   R5              ;GET FPS.
19624  107506  005701                          TST     R1
19625  107510  001030                          BNE     XXB10           ;WAS THE PC CORRECT AFTER EXECUTION?
19626  107512  012701  107552                  MOV     #XXBTP1,R1              ;IS THE RESULT CORRECT.
19627  107516  012702  107562                  MOV     #XXBTP2,R2
19628  107522  012703  000004                  MOV     #4,R3
19629  107526  022122                  1$:     CMP     (R1)+,(R2)+
19630  107530  001020                          BNE     XXB10           ;BRANCH IF INCORRECT.
19631  107532  077303                          SOB     R3,1$
19632  107534  022700  102351                  CMP     #XXBTP1-5201,R0 ;IS R0 CORRECT.
19633  107540  001014                          BNE     XXB10           ;BRANCH IF INCORRECT.
19634  107542  022705  000210                  CMP     #210,R5         ;IS THE FPS CORRECT?
19635  107546  001011                          BNE     XXB10           ;BRANCH IF INCORRECT.
19636  107550  000411                          BR      XXBDONE
19637
19638                                          ;THESE ARE DATA TABLES AND A DATA BUFFER.
19639  107552  023245                  XXBTP1: 023245
19640  107554  026720                          26720
19641  107556  122324                          122324
19642  107560  052672                          52672
19643  107562  123245                  XXBTP2: 123245
19644  107564  026720                          26720
19645  107566  122324                          122324
```

```
                                        52672


                                XXB10:
                                        EMT                     ;
                                XXBDONE:
107574  004767  010674                JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
                                                                ;SEE IF THE USER HAS EXPRESSED
                                                                ;THE DESIRE TO CHANGE THE SOFTWARE
                                                                ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
                                                                ;THE USER TYPED CONTROL G?).

                                ;*****************************************************************************
                                ;TEST 542       SPECIAL DEST, MODE 7, TEST
                                ;*****************************************************************************
107600                          TS542:

107600  012701  107722                MOV     #YYBTP1,R1      ;SET UP THE DATA BUFFER.
107604  012700  107732                MOV     #YYBTP2,R0
107610  012702  000004                MOV     #4,R2
107614  012021                1$:     MOV     (R0)+,(R1)+
107616  077202                        SOB     R2,1$
107620  012700  102541                MOV     #YYBTP3-5201,R0
107624  012760  107722  005201        MOV     #YYBTP1,5201(R0)
107632  042737  100000  107722        BIC     #100000,@#YYBTP1        ;MAKE THE OPERAND POSITIVE.
107640  012701  000200                MOV     #200,R1         ;SET FD.
107644  170101                        LDFPS   R1

107646  005001                        CLR     R1
107650  170770  005201        YYB2:   NEGD    @5201(R0)               ;TEST INSTRUCTION.

107654  170205                        STFPS   R5              ;GET FPS.
107656  005701                        TST     R1              ;WAS THE PC CORRECT AFTER EXECUTION?
107660  001031                        BNE     YYB10
107662  012701  107722                MOV     #YYBTP1,R1              ;IS THE RESULT CORRECT.
107666  012702  107732                MOV     #YYBTP2,R2
107672  012703  000004                MOV     #4,R3
107676  022122                1$:     CMP     (R1)+,(R2)+
107700  001021                        BNE     YYB10           ;BRANCH IF INCORRECT.
107702  077303                        SOB     R3,1$
107704  022700  102541                CMP     #YYBTP3-5201,R0 ;IS R0 CORRECT.
107710  001015                        BNE     YYB10           ;BRANCH IF INCORRECT.
107712  022705  000210                CMP     #210,R5         ;IS THE FPS CORRECT?
107716  001012                        BNE     YYB10           ;BRANCH IF INCORRECT.
107720  000412                        BR      YYBDONE

                                ;THESE ARE DATA TABLES AND A DATA BUFFER.
107722  023245                YYBTP1: 023245
107724  026720                        26720
107726  122324                        122324
107730  052672                        52672
107732  123245                YYBTP2: 123245
107734  026720                        26720
107736  123324                        123324
107740  052672                        52672
107742  107722                YYBTP3: YYBTP1
```

```
19702  107744
19703  107744  104000                  YYB10:
19704                                          EMT                     ;
19705  107746
19706  107746  004767  010522          YYBDONE:
                                               JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
19707                                                                  ;SEE IF THE USER HAS EXPRESSED
19708                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
19709                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
19710                                                                  ;THE USER TYPED CONTROL G?).
19711                                  ;*********************************************************************************
19712                                  ;TEST 543       NEGD, ABSD AND TSTD TEST
19713                                  ;*********************************************************************************
19714  107752                          TS543:
19715                                  ;TEST NEGD WITH POS NONZERO OPERAND
19716  107752  004767  000526          WWB1:   JSR     PC,NATSUB
19717  107756  000000                  1$:     0                       ;FLAG=NEGD.
19718  107760  016341                  2$:     16341                   ;OPERAND.
19719  107762  055772                          55772
19720  107764  021133                          21133
19721  107766  055447                          55447
19722  107770  116341                  3$:     116341                  ;RESULT.
19723  107772  055772                          55772
19724  107774  021133                          21133
19725  107776  055447                          55447
19726  110000  016341                  4$:     16341                   ;ERROR RES.
19727  110002  055772                          55772
19728  110004  021133                          21133
19729  110006  055447                          55447
19730  110010  000207                  5$:     207                     ;FPS BEFORE EXECUTION.
19731  110012  000210                          210                     ;FPS AFTER EXECUTION.
19732  110014  000200                          200                     ;ERROR FPS.
19733  110016  177777                          -1                      ;FEC
19734                                  ;TEST NEGD WITH NEG OPERAND.
19735  110020  004767  000460          WWB2:   JSR     PC,NATSUB
19736  110024  000000                  1$:     0                       ;FLAG=NEGD.
19737  110026  152525                  2$:     152525                  ;OPERAND.
19738  110030  053545                          53545
19739  110032  055565                          55565
19740  110034  057505                          57505
19741  110036  052525                  3$:     52525                   ;RESULT.
19742  110040  053545                          53545
19743  110042  055565                          55565
19744  110044  057505                          57505
19745  110046  152525                  4$:     152525                  ;ERROR RES.
19746  110050  053545                          53545
19747  110052  055565                          55565
19748  110054  057505                          57505
19749  110056  000217                  5$:     217                     ;FPS BEFORE EXECUTION.
19750  110060  000200                          200                     ;FPS AFTER EXECUTION.
19751  110062  000210                          210                     ;ERROR FPS.
19752  110064  177777                          -1                      ;FEC
19753                                  ;TEST ABSD WITH POSITIVE OPERAND
19754  110066  004767  000412          WWB3:   JSR     PC,NATSUB
19755  110072  000001                  1$:     1                       ;FLAG=ABSD.
19756  110074  060705                  2$:     60705                   ;OPERAND.
19757  110076  124735                          124735
```

```
19758  110100  060124                          60124
19759  110102  073560                          73560
19760  110104  060705                  3$:     60705                   ;RESULT.
19761  110106  124735                          124735
19762  110110  060124                          60124
19763  110112  073560                          73560
19764  110114  160705                  4$:     160705                  ;ERROR RES.
19765  110116  124735                          124735
19766  110120  060124                          60124
19767  110122  073560                          73560
19768  110124  000217                  5$:     217                     ;FPS BEFORE EXECUTION.
19769  110126  000200                          200                     ;FPS AFTER EXECUTION.
19770  110130  000210                          210                     ;ERROR FPS.
19771  110132  177777                          -1                      ;EITHER BUT OP1B
19772                                  ;TEST ABSD WITH NEG. OPERAND
19773  110134  004767  000344        WWB4:   JSR     PC,NATSUB
19774  110140  000001                1$:     1                       ;FLAG=ABSD.
19775  110142  154345                2$:     154345                  ;OPERAND.
19776  110144  076567                        76567
19777  110146  032123                        32123
19778  110150  043234                        43234
19779  110152  054345                3$:     54345                   ;RESULT.
19780  110154  076567                        76567
19781  110156  032123                        32123
19782  110160  043234                        43234
19783  110162  154345                4$:     154345                  ;ERROR RES.
19784  110164  076567                        76567
19785  110166  032123                        32123
19786  110170  043234                        43234
19787  110172  000217                5$:     217                     ;FPS BEFORE EXECUTION.
19788  110174  000200                        200                     ;FPS AFTER EXECUTION.
19789  110176  177777                        -1                      ;ERROR FPS.
19790  110200  177777                        -1
19791                                  ;TEST WITH POSITIVE OP
19792  110202  004767  000276        WWB5:   JSR     PC,NATSUB
19793  110206  000002                1$:     2                       ;FLAG=TSTD.
19794  110210  012321                2$:     12321                   ;OPERAND.
19795  110212  045654                        45654
19796  110214  070107                        70107
19797  110216  034543                        34543
19798  110220  012321                3$:     12321                   ;RESULT.
19799  110222  045654                        45654
19800  110224  070107                        70107
19801  110226  034543                        34543
19802  110230  112321                4$:     112321                  ;ERROR RES.
19803  110232  045654                        45654
19804  110234  070107                        70107
19805  110236  034543                        34543
19806  110240  000217                5$:     217                     ;FPS BEFORE EXECUTION.
19807  110242  000200                        200                     ;FPS AFTER EXECUTION.
19808  110244  000210                        210                     ;ERROR FPS.
19809  110246  177777                        -1
19810                                  ;TEST TSTD WITH NEG OP
19811  110250  004767  000230        WWB6:   JSR     PC,NATSUB
19812  110254  000002                1$:     2                       ;FLAG=TSTD.
19813  110256  123765                2$:     123765                  ;OPERAND.
```

```
 19814  110260  023407                      23407
 19815  110262  034510                      34510
 19816  110264  045621                      45621
 19817  110266  123765              3$:     123765                  ;RESULT.
 19818  110270  023407                      23407
 19819  110272  034510                      34510
 19820  110274  045621                      45621
 19821  110276  023765              4$:     23765                   ;ERROR RES.
 19822  110300  023407                      23407
 19823  110302  034510                      34510
 19824  110304  045621                      45621
 19825  110306  000207              5$:     207                     ;FPS BEFORE EXECUTION.
 19826  110310  000210                      210                     ;FPS AFTER EXECUTION.
 19827  110312  000200                      200                     ;ERROR FPS.
 19828  110314  177777                      -1
 19829                          ;TEST TSTD 0 OP
 19830  110316  004767  000162  WWB7:   JSR     PC,NATSUB
 19831  110322  000002          1$:     2                       ;FLAG=TSTD.
 19832  110324  000175          2$:     175                     ;OPERAND.
 19833  110326  176737                  176737
 19834  110330  071727                  71727
 19835  110332  037574                  37574
 19836  110334  000175          3$:     175                     ;RESULT.
 19837  110336  176737                  176737
 19838  110340  071727                  71727
 19839  110342  037574                  37574
 19840  110344  000000          4$:     0                       ;ERROR RES.
 19841  110346  000000                  0
 19842  110350  000000                  0
 19843  110352  000000                  0
 19844  110354  000200          5$:     200                     ;FPS BEFORE EXECUTION.
 19845  110356  000204                  204                     ;FPS AFTER EXECUTION.
 19846  110360  000214                  214                     ;ERROR FPS.
 19847  110362  177777                  -1
 19848                          ;TEST TSTD -0 OP FIUV=0
 19849  110364  004767  000114  WWB10:  JSR     PC,NATSUB
 19850  110370  000002          1$:     2                       ;FLAG=TSTD.
 19851  110372  100123          2$:     100123                  ;OPERAND.
 19852  110374  021012                  21012
 19853  110376  034565                  34565
 19854  110400  043210                  43210
 19855  110402  100123          3$:     100123                  ;RESULT.
 19856  110404  021012                  21012
 19857  110406  034565                  34565
 19858  110410  043210                  43210
 19859  110412  000000          4$:     0                       ;ERROR RES.
 19860  110414  000000                  0
 19861  110416  000000                  0
 19862  110420  000000                  0
 19863  110422  040203          5$:     40203                   ;FPS BEFORE EXECUTION.
 19864  110424  040214                  040214                  ;FPS AFTER EXECUTION.
 19865  110426  140214                  140214                  ;ERROR FPS.
 19866  110430  177777                  -1
 19867                          ;TEST TSTD -0 OP FIUV=1
 19868  110432  004767  000046  WWB11:  JSR     PC,NATSUB
 19869  110436  000002          1$:     2                       ;FLAG=TSTD.
```

```
19870  110440  100137                  2$:     100137                  ;OPERAND.
19871  110442  024613                          24613
19872  110444  057024                          57024
19873  110446  060137                          60137
19874  110450  100137                  3$:     100137                  ;RESULT.
19875  110452  024613                          24613
19876  110454  057024                          57024
19877  110456  060137                          60137
19878  110460  000000                  4$:     0                       ;ERROR RES.
19879  110462  000000                          0
19880  110464  000000                          0
19881  110466  000000                          0
19882  110470  044200                  5$:     44200                   ;FPS BEFORE EXECUTION.
19883  110472  144214                          144214                  ;FPS AFTER EXECUTION.
19884  110474  044214                          044214                  ;ERROR FPS.
19885  110476  000014                          14
19886  110500  000167  000162                  JMP     WWBDONE
19887
19888                                  ;THIS SUBROUTINE, NATSUB, IS USED TO SET UP THE OPERANDS, EXECUTE
19889                                  ;THE EITHER A TSTD, AN ABSD OR A NEGD INSTRUCTION AND CHECK THE RESULTS. A CALL
19890                                  ;TO IT IS MADE THUS:
19891                                  ;
19892                                  ;               JSR     PC,@#NATSUB
19893                                  ;               FLAG:   .WORD   X               ;INSTRUCTION TYPE FLAG.
19894                                  ;               ACARG:  .WORD   X,X,X,X         ;OPERAND
19895                                  ;               RES:    .WORD   X,X,X,X         ;EXPECTED RESULT
19896                                  ;               ERRES:  .WORD   X,X,X,X         ;ERROR RESULT
19897                                  ;               FPSB:   .WORD   X               ;FPS BEFORE EXECUTION
19898                                  ;               FPSA:   .WORD   X               ;FPS AFTER EXECUTION
19899                                  ;               FEC:    .WORD   X               ;EXPECTED FEC
19900                                  ;               ERFPS:  .WORD   X               ;ERROR FPS.
19901                                  ;               ERR1:   ERROR   X               ;DATA ERROR.
19902                                  ;                       BR      CONT
19903                                  ;               ERR2:   ERROR   X               ;FPS ERROR.
19904                                  ;               CONT:                           ;RETURN ADDRESS
19905                                  ;
19906                                  ;THE OPERAND IS SET UP IN NATBF1. THEN
19907                                  ;THE EITHER THE TSTD, NEGD OR ABSD INSTRUCTION IS EXECUTED.
19908                                  ;NATSUB USES THE FIRST OPERAND AS A FLAG TO DETERMINE WHICH INSTRUCTION
19909                                  ;IS TO BE EXECUTED: 0 = NEGD, 1 = ABSD, 2 = TSTD.
19910                                  ;THE RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS
19911                                  ;COMPARED WITH FPSA. IF THIS TOO IS CORRECT NATSUB RETURNS CONTROL
19912                                  ;TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD NATSUB
19913                                  ;COMPARE IT TO ERROR FPS. IF THIS MATCHES THEN NATSUB WILL RETURN
19914                                  ;TO THE ERROR CALL AT ERR2, OTHERWISE NATSUB ITSELF
19915                                  ;REPORTS THIS FAILURE AND THEN RETURNS TO CONT. IF THE RESULT OF THE
19916                                  ;INSTRUCTION IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE
19917                                  ;ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN
19918                                  ;THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN NATSUB
19919                                  ;WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR1. OTHERWISE THE
19920                                  ;RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND NATSUB WILL
19921                                  ;REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.
19922
19923
19924  110504  012601                  NATSUB: MOV     (SP)+,R1                ;GET A POINTER TO THE ARGUMENTS.
19925  110506  010102                          MOV     R1,R2           ;COPY THE OPERAND.
```

```
19926  110510  062702  000002                ADD     #2,R2
19927  110514  012703  110654                MOV     #NATBF1,R3
19928  110520  012704  000004                MOV     #4,R4
19929  110524  012223              1$:       MOV     (R2)+,(R3)+
19930  110526  077402                        SOB     R4,1$
19931  110530  016100  000032                MOV     32(R1),R0       ;LOAD THE FPS.
19932  110534  170100                        LDFPS   R0
19933  110536  012700  110654                MOV     #NATBF1,R0      ;SET UP THE OPERAND ADDRESS.
19934  110542  011102                        MOV     (R1),R2         ;GET THE FLAG TO DETERMINE WHICH
19935  110544  006302                        ASL     R2              ;INSTRUCTION TO EXECUTE.
19936  110546  006302                        ASL     R2              ;0 = NEGD, 1 = ABSD, 2 = TSTD
19937  110550  012703  110560                MOV     #NATINS,R3
19938  110554  060203                        ADD     R2,R3
19939  110556  000113                        JMP     (R3)            ;GO EXECUTE THE INSTRUCTION.
19940  110560  170710              NATINS:   NEGD    (R0)
19941  110562  000403                        BR      2$
19942  110564  170610                        ABSD    (R0)
19943  110566  000401                        BR      2$
19944  110570  170510                        TSTD    (R0)
19945
19946  110572  170204              2$:       STFPS   R4              ;GET THE FPS.
19947  110574  170305                        STST    R5              ;GET THE FEC.
19948  110576  010100                        MOV     R1,R0           ;WAS THE RESULT CORRECT?
19949  110600  062700  000012                ADD     #12,R0
19950  110604  012702  110654                MOV     #NATBF1,R2
19951  110610  012703  000004                MOV     #4,R3
19952  110614  022022              3$:       CMP     (R0)+,(R2)+
19953  110616  001014                        BNE     10$             ;BRANCH IF INCORRECT.
19954  110620  077303                        SOB     R3,3$
19955  110622  026104  000034                CMP     34(R1),R4       ;WAS THE FPS CORRECT?
19956  110626  001010                        BNE     10$             ;BRANCH IF INCORRECT.
19957  110630  005761  000034                TST     34(R1)          ;IF THE EXPECTED FPS WAS NEGATIVE CHECK THE FEC.
19958  110634  100003                        BPL     4$
19959  110636  026105  000040                CMP     40(R1),R5       ;WAS THE FEC CORRECT.
19960  110642  001002                        BNE     10$             ;BRANCH IF INCORRECT.
19961  110644  000161  000042        4$:     JMP     42(R1)          ;RETURN.
19962
19963  110650                      10$:
19964  110650  104000                        EMT                     ;
19965
19966  110652  177777                        .WORD   -1
19967  110654  177777  177777  177777  NATBF1: .WORD -1,-1,-1,-1,-1
19968  110662  177777  177777
19969
19970  110666                      WWBDONE:
19971  110666  004767  007602                JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
19972                                                                ;SEE IF THE USER HAS EXPRESSED
19973                                                                ;THE DESIRE TO CHANGE THE SOFTWARE
19974                                                                ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
19975                                                                ;THE USER TYPED CONTROL G?).
19976
19977
19978
19979                               ;*****************************************************************************
19980                               ;TEST 544       SOURCE MODES, MODE 1 (FL=0), TEST
19981                               ;*****************************************************************************
```

```
19982  110672                                  TS544:
19983
19984
19985
19986  110672  012700  110742                          MOV     #AACTP1,R0      ;SET UP TEST DATA IN BUFFER.
19987  110676  012710  147517                          MOV     #147517,(R0)
19988  110702  012737  110716  037366                  MOV     #AAC2,@#$TMP2
19989  110710  012737  110746  000004                  MOV     #AAC10,@#ERRVECT        ;SET UP FOR TRAPS TO 4.
19990  110716  170110                          AAC2:   LDFPS   (R0)            ;TEST INSTRUCTION.
19991
19992  110720  170205                                  STFPS   R5              ;GET FPS
19993
19994  110722  020027  110742                          CMP     R0,#AACTP1      ;IS R0 CORRECT?
19995  110726  001007                                  BNE     AAC10           ;BR IF NOT.
19996  110730  022705  147517                          CMP     #147517,R5      ;IS FPS CORRECT?
19997  110734  001004                                  BNE     AAC10           ;BR IF NOT.
19998  110736  000404                                  BR      AACDONE
19999
20000                                          ;TEST BUFFER AND DATA:
20001  110740  177777                                  -1
20002  110742  147517                          AACTP1: 147517
20003  110744  177777                                  -1
20004  110746                                  AAC10:
20005  110746  104000                                  EMT                     ;
20006
20007  110750                                  AACDONE:
20008  110750  004767  007520                          JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
20009                                                                          ;SEE IF THE USER HAS EXPRESSED
20010                                                                          ;THE DESIRE TO CHANGE THE SOFTWARE
20011                                                                          ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
20012                                                                          ;THE USER TYPED CONTROL G?).
20013
20014
20015                                          ;*****************************************************************************
20016                                          ;TEST 545       SOURCE MODES, MODE 2 (FL=0), TEST
20017                                          ;*****************************************************************************
20018  110754                                  TS545:
20019
20020
20021  110754  012700  111016                          MOV     #BBCTP1,R0      ;SET UP TEST DATA IN BUFFER.
20022  110760  012710  145212                          MOV     #145212,(R0)
20023  110764  012737  111022  000004                  MOV     #BBC10,@#ERRVECT ;SET UP FOR TRAPS TO 4.
20024
20025  110772  170120                          BBC2:   LDFPS   (R0)+           ;TEST INSTRUCTION.
20026
20027  110774  170205                                  STFPS   R5              ;GET FPS
20028
20029  110776  020027  111020                          CMP     R0,#BBCTP1+2    ;IS R0 CORRECT?
20030  111002  001007                                  BNE     BBC10           ;BR IF NOT.
20031  111004  022705  145212                          CMP     #145212,R5      ;IS THE FPS CORRECT?
20032  111010  001004                                  BNE     BBC10           ;BR IF NOT.
20033  111012  000404                                  BR      BBCDONE
20034
20035
20036                                          ;TEST BUFFER AND DATA:
20037  111014  177777                                  -1
```

```
20038  111016  177777                  BBCTP1: .WORD   -1
20039  111020  177777                          -1
20040
20041
20042  111022                          BBC10:
20043  111022  104000                          EMT                     ;
20044  111024                          BBCDONE:
20045  111024  004767  007444                  JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
20046                                                                  ;SEE IF THE USER HAS EXPRESSED
20047                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
20048                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
20049                                                                  ;THE USER TYPED CONTROL G?).
20050
20051
20052                                   ;*************************************************************************************
20053                                   ;TEST 546       SOURCE MODES, MODE 4 (FL=0), TEST
20054                                   ;*************************************************************************************
20055  111030                           TS546:
20056
20057
20058  111030  012700  111112                  MOV     #DDCTP1+2,R0    ;SET UP THE TEST DATA BUFFER.
20059  111034  012760  105252  177776          MOV     #105252,-2(R0)
20060  111042  012737  111056  037366          MOV     #DDC2,@#$TMP2
20061  111050  012737  111122  000004          MOV     #DDC10,@#ERRVEC
20062  111056  170140                  DDC2:   LDFPS   -(R0)
20063  111060  170205                          STFPS   R5
20064  111062  020027  111110                  CMP     R0,#DDCTP1
20065  111066  001015                          BNE     DDC10
20066  111070  022705  105252                  CMP     #105252,R5
20067  111074  001012                          BNE     DDC10
20068  111076  000412                          BR      DDCDONE
20069
20070  111100  177777  177777  177777          -1,-1,-1,-1
20071  111106  177777
20072  111110  177777                  DDCTP1: -1
20073  111112  177777  177777  177777          -1,-1,-1,-1
20074  111120  177777
20075  111122                          DDC10:
20076  111122  104000                          EMT                     ;
20077  111124                          DDCDONE:
20078  111124  004767  007344                  JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
20079                                                                  ;SEE IF THE USER HAS EXPRESSED
20080                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
20081                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
20082                                                                  ;THE USER TYPED CONTROL G?).
20083                                   ;*************************************************************************************
20084                                   ;TEST 547       SOURCE MODES, MODE 3 (FL=0), TEST
20085                                   ;*************************************************************************************
20086  111130                           TS547:
20087  111130  012700  111216                  MOV     #EECTP2,R0
20088  111134  012710  111206                  MOV     #EECTP1,(R0)
20089  111140  012767  103456  000040          MOV     #103456,EECTP1
20090  111146  012737  111230  000004          MOV     #EEC10,@#ERRVECT ;SET UP FOR TRAPS TO 4.
20091  111154  170130                  EEC2:   LDFPS   @(R0)+          ;TEST INSTRUCTION.
20092  111156  170205                          STFPS   R5              ;GET THE FPS.
20093  111160  020027  111220                  CMP     R0,#EECTP2+2    ;IS R0 CORRECT?
```

```
20094  111164  001021                          BNE     EEC10           ;BR IF NOT.
20095  111166  022705  103456                  CMP     #103456,R5      ;IS THE FPS CORRECT?
20096  111172  001016                          BNE     EEC10           ;BR IF NOT.
20097  111174  000416                          BR      EECDONE
20098
20099
20100                                  ;TEST BUFFER AND DATA:
20101  111176  177777  177777  177777            -1,-1,-1,-1
20102  111204  177777
20103  111206  177777                  EECTP1: -1
20104  111210  177777  177777  177777            -1,-1,-1
20105  111216  111206  177777  177777  EECTP2: EECTP1,-1,-1,-1,
20106  111224  177777  000000
20107
20108  111230                          EEC10:
20109  111230  104000                          EMT                     ;
20110  111232                          EECDONE:
20111  111232  004767  007236                  JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
20112                                                                  ;SEE IF THE USER HAS EXPRESSED
20113                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
20114                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
20115                                                                  ;THE USER TYPED CONTROL G?).
20116                                  ;*****************************************************************************
20117                                  ;TEST 550       SOURCE MODES, MODE 5 (FL=0), TEST
20118                                  ;*****************************************************************************
20119  111236                          TS550:
20120  111236  012700  111322                  MOV     #FFCTP2+2,R0    ;SET UP THE TEST DATA BUFFER.
20121  111242  012760  111310  177776          MOV     #FFCTP1,-2(R0)
20122  111250  012737  045412  111310          MOV     #45412,@#FFCTP1
20123  111256  012737  111330  000004          MOV     #FFC10,@#ERRVECT ;SET UP FOR TRAPS TO 4.
20124  111264  170150                  FFC2:   LDFPS   @-(R0)          ;TEST INSTRUCTION.
20125  111266  170205                          STFPS   R5              ;GET THE FPS.
20126  111270  020027  111320                  CMP     R0,#FFCTP2      ;IS R0 CORRECT?
20127  111274  001015                          BNE     FFC10           ;BR IF NOT.
20128  111276  022705  045412                  CMP     #45412,R5       ;IS THE FPS CORRECT?
20129  111302  001012                          BNE     FFC10           ;BR IF NOT.
20130  111304  000412                          BR      FFCDONE
20131
20132
20133                                  ;TEST BUFFER AND DATA:
20134  111306  177777                          -1
20135  111310  177777                  FFCTP1: -1
20136  111312  177777  177777  177777            -1,-1,-1
20137  111320  111310  177777  177777  FFCTP2: FFCTP1,-1,-1,-1
20138  111326  177777
20139
20140  111330                          FFC10:
20141  111330  104000                          EMT                     ;
20142  111332                          FFCDONE:
20143  111332  004767  007136                  JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
20144                                                                  ;SEE IF THE USER HAS EXPRESSED
20145                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
20146                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
20147                                                                  ;THE USER TYPED CONTROL G?).
20148                                  ;*****************************************************************************
20149                                  ;TEST 551       SOURCE MODES, MODE 6 (FL=0), TEST
```

```
20150                                   ;*****************************************************************************
20151  111336                           TS551:
20152  111336  012700  104211                   MOV     #GGCTP1-5201,R0 ;SET UP THE TEST DATA BUFFER.
20153  111342  012737  046543  111412           MOV     #46543,@#GGCTP1
20154  111350  005001                           CLR     R1
20155  111352  012737  111424  000004           MOV     #GGC10,@#ERRVECT ;SET UP FOR TRAPS TO 4.
20156  111360  170160  005201           GGC2:   LDFPS   5201(R0)                ;TEST INSTRUCTION.
20157  111364  170204                           STFPS   R4              ;GET THE FPS.
20158  111366  005701                           TST     R1              ;WAS PC CORRECT AFTER EXECUTION?
20159  111370  001015                           BNE     GGC10           ;BR IF NOT.
20160  111372  020027  104211                   CMP     R0,#GGCTP1-5201 ;IS R0 CORRECT?
20161  111376  001012                           BNE     GGC10           ;BR IF NOT.
20162  111400  022704  046543                   CMP     #46543,R4       ;IS THE FPS CORRECT?
20163  111404  001007                           BNE     GGC10           ;BR IF NOT.
20164  111406  000407                           BR      GGCDONE
20165
20166
20167                                   ;TEST BUFFER AND DATA:
20168  111410  177777                           -1
20169  111412  177777  177777  177777   GGCTP1: -1,-1,-1,-1
20170  111420  177777
20171  111422  177777                           -1
20172  111424                           GGC10:
20173  111424  104000                           EMT                     ;
20174  111426                           GGCDONE:
20175  111426  004767  007042                   JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
20176                                                                    ;SEE IF THE USER HAS EXPRESSED
20177                                                                    ;THE DESIRE TO CHANGE THE SOFTWARE
20178                                                                    ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
20179                                                                    ;THE USER TYPED CONTROL G?).
20180                                   ;*****************************************************************************
20181                                   ;TEST 552       SOURCE MODES, MODE 7 (FL=0), TEST
20182                                   ;*****************************************************************************
20183  111432                           TS552:
20184  111432  012700  104323                   MOV     #HHCTP2-5201,R0 ;SET UP THE TEST DATA BUFFER.
20185  111436  012760  111514  005201           MOV     #HHCTP1,5201(R0)
20186  111444  012737  004547  111514           MOV     #4547,@#HHCTP1
20187  111452  005001                           CLR     R1
20188  111454  012737  111534  000004           MOV     #HHC10,@#ERRVECT ;SET UP FOR TRAPS TO 4.
20189  111462  170170  005201           HHC2:   LDFPS   @5201(R0)               ;TEST INSTRUCTION.
20190  111466  170204                           STFPS   R4              ;GET THE FPS.
20191  111470  005701                           TST     R1              ;WAS PC CORRECT AFTER EXECUTION?
20192  111472  001020                           BNE     HHC10           ;BR IF NOT.
20193  111474  020027  104323                   CMP     R0,#HHCTP2-5201 ;IS R0 CORRECT?
20194  111500  001015                           BNE     HHC10           ;BR IF NOT.
20195  111502  022704  004547                   CMP     #4547,R4        ;IS THE FPS CORRECT?
20196  111506  001012                           BNE     HHC10           ;BR IF NOT.
20197  111510  000412                           BR      HHCDONE
20198
20199
20200                                   ;TEST BUFFER AND DATA:
20201  111512  177777                           -1
20202  111514  177777  177777  177777   HHCTP1: .WORD -1,-1,-1,-1
20203  111522  177777
20204  111524  177777  177777  177777   HHCTP2: .WORD -1,-1,-1,-1
20205  111532  177777
```

```
20206  111534                          HHC10:
20207  111534  104000                          EMT                     ;
20208  111536                          HHCDONE:
20209  111536  004767  006732                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
20210                                                                  ;SEE IF THE USER HAS EXPRESSED
20211                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
20212                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
20213                                                                  ;THE USER TYPED CONTROL G?).
20214
20215
20216
20217                                   ;*************************************************************************************
20218                                   ;TEST 553       SOURCE MODES, MODE 2 GR7 (FL=1), TEST
20219                                   ;*************************************************************************************
20220  111542                          TS553:
20221
20222  111542  012737  111600  000004          MOV     #IIC20,@#ERRVECT ;SET UP FOR TRAPS TO 4.
20223  111550  012700  000300                  MOV     #300,R0
20224  111554  170100                          LDFPS   R0
20225  111556  005001                          CLR     R1
20226
20227  111560  177027                  IIC2:   LDCLD   (R7)+,AC0               ;TEST INSTRUCTION.
20228  111562  005201                          5201
20229  111564  005201                          5201
20230  111566  005201                          5201
20231  111570  005201                          5201
20232
20233  111572  020127  000003                  CMP     R1,#3           ;WAS PC CORRECT AFTER EXECUTION?
20234  111576  001401                          BEQ     IICDONE
20235  111600                          IIC20:
20236  111600  104000                          EMT                     ;
20237
20238  111602                          IICDONE:
20239  111602  004767  006666                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
20240                                                                  ;SEE IF THE USER HAS EXPRESSED
20241                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
20242                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
20243                                                                  ;THE USER TYPED CONTROL G?).
20244
20245
20246                                   ;*************************************************************************************
20247                                   ;TEST 554       SOURCE MODES, MODE 2 (FL=1), TEST
20248                                   ;*************************************************************************************
20249  111606                          TS554:
20250
20251  111606  012700  000300                  MOV     #300,R0
20252  111612  170100                          LDFPS   R0
20253  111614  012700  111660                  MOV     #TCCBF0,R0      ;SET UP THE TEST DATA BUFFER.
20254  111620  177020                  TCC2:   LDCLD   (R0)+,AC0               ;TEST INSTRUCTION.
20255
20256  111622  170204                          STFPS   R4              ;GET THE FPS.
20257  111624  012701  111670                  MOV     #TCCBF1,R1      ;GET THE RESULT.
20258  111630  012702  000200                  MOV     #200,R2
20259  111634  170102                          LDFPS   R2
20260  111636  174011                          STD     AC0,(R1)
20261  111640  020027  111664                  CMP     R0,#TCCBF0+4    ;IS R0 CORRECT?
```

```
20262  111644  001401                    BEQ     TCC3
20263  111646  104000                    EMT                     ;
20264
20265  111650  022704  000300  TCC3:     CMP     #300,R4 ;IS THE FPS CORRECT?
20266  111654  001411                    BEQ     TCCDONE
20267  111656  104000                    EMT                     ;
20268
20269
20270                          ;TEST BUFFER AND DATA:
20271  111660  001234  067076  054321  TCCBF0: .WORD   01234,67076,54321,012345
20272  111666  012345
20273  111670  177777  177777  177777  TCCBF1: -1,-1,-1,-1
20274  111676  177777
20275
20276  111700                    TCCDONE:
20277  111700  004767  006570            JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
20278                                                            ;SEE IF THE USER HAS EXPRESSED
20279                                                            ;THE DESIRE TO CHANGE THE SOFTWARE
20280                                                            ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
20281                                                            ;THE USER TYPED CONTROL G?).
20282
20283
20284                          ;*************************************************************************
20285                          ;TEST 555       LDCIF AND LDCLF TEST
20286                          ;*************************************************************************
20287
20288  111704                  TS555:
20289
20290
20291                          ;ZERO   OPERAND FL=0
20292
20293  111704  004737  112576  KKC1:   JSR     PC,@#LDCFSUB    ;GO EXECUTE INSTRUCTION.
20294
20295  111710  000000  000000  1$:     .WORD   0,0             ;FSRC OPERAND.
20296  111714  000000  000000  2$:     .WORD   0,0             ;EXPECTED RESULT.
20297  111720  177777  177777  3$:     .WORD   -1,-1           ;ANTICIPATED ERRONEOUS RESULT.
20298  111724  000000          4$:     0                       ;FPS BEFORE EXECUTION.
20299  111726  000004                  4                       ;FPS AFTER EXECUTION.
20300  111730  177777                  -1                      ;ANTICIPATED ERRONEOUS FPS.
20301                          ;ZERO   OPERAND FL=0
20302
20303  111732  004737  112576  KKC2:   JSR     PC,@#LDCFSUB    ;GO EXECUTE THE INSTRUCTION.
20304
20305  111736  000000  177777  1$:     .WORD   0,-1            ;FSRC OPERAND.
20306  111742  000000  000000  2$:     .WORD   0,0             ;EXPECTED RESULT.
20307  111746  004177  177400  3$:     4177,177400             ;ANTICIPATED ERRONEOUS RESULT.
20308  111752  000000          4$:     0                       ;FPS BEFORE EXECUTION.
20309  111754  000004                  4                       ;FPS AFTER EXECUTION.
20310  111756  177777                  -1                      ;ANTICIPATED ERRONEOUS FPS.
20311                          ;ZERO   OPERAND FL=1
20312
20313  111760  004737  112576  KKC3:   JSR     PC,@#LDCFSUB    ;GO EXECUTE THE INSTRUCTION.
20314
20315  111764  000000  000000  1$:     .WORD   0,0             ;FSRC OPERAND.
20316  111770  000000  000000  2$:     .WORD   0,0             ;EXPECTED RESULT.
20317  111774  177777  177777  3$:     .WORD   -1,-1           ;ANTICIPATED ERRONEOUS RESULT.
```

```
20318  112000  000100                 4$:     100                     ;FPS BEFORE EXECUTION.
20319  112002  000104                         104                     ;FPS AFTER EXECUTION.
20320  112004  000004                         4                       ;ANTICIPATED ERRONEOUS FPS.
20321                                  ;OPERAND        POSITIVE        FL=0
20322  112006  004737  112576        KKC4:   JSR     PC,@#LDCFSUB    ;GO EXECUTE THE INSTRUCTION.
20323  112012  040000  000000        1$:     .WORD   40000,0         ;FSRC OPERAND.
20324  112016  043600  000000        2$:     .WORD   43600,0         ;EXPECTED RESULT.
20325  112022  047600  000000        3$:     .WORD   47600,0         ;ANTICIPATED ERRONEOUS RESULT.
20326  112026  000017                 4$:     17                      ;FPS BEFORE EXECUTION.
20327  112030  000000                         0                       ;FPS AFTER EXECUTION.
20328  112032  177777                         -1                      ;ANTICIPATED ERRONEOUS FPS.
20329                                  ;OPERAND=1,     FL=0
20330  112034  004737  112576        KKC5:   JSR     PC,@#LDCFSUB    ;GO EXECUTE THE INSTRUCTION.
20331  112040  000001  000000        1$:     .WORD   1,0             ;FSRC OPERAND.
20332  112044  040200  000000        2$:     .WORD   40200,0         ;EXPECTED RESULT.
20333  112050  044200  000000        3$:     .WORD   44200,0         ;ANTICIPATED ERRONEOUS RESULT.
20334  112054  000017                 4$:     17                      ;FPS BEFORE EXECUTION.
20335  112056  000000                         0                       ;FPS AFTER EXECUTION.
20336  112060  177777                         -1                      ;ANTICIPATED ERRONEOUS FPS.
20337                                  ;OPERAND=       PATTERN FL=0
20338  112062  004737  112576        KKC6:   JSR     PC,@#LDCFSUB    ;GO EXECUTE THE INSTRUCTION.
20339  112066  000252  000000        1$:     .WORD   252,0           ;FSRC OPERAND.
20340  112072  042052  000000        2$:     .WORD   42052,0         ;EXPECTED RESULT.
20341  112076  046052  000000        3$:     .WORD   46052,0         ;ANTICIPATED ERRONEOUS RESULT.
20342  112102  000000                 4$:     0                       ;FPS BEFORE EXECUTION.
20343  112104  000000                         0                       ;FPS AFTER EXECUTION.
20344  112106  177777                         -1                      ;ANTICIPATED ERRONEOUS FPS.
20345                                  ;OPERAND=-40000 FL=0
20346  112110  004737  112576        KKC7:   JSR     PC,@#LDCFSUB    ;GO EXECUTE THE INSTRUCTION.
20347  112114  140000  000000        1$:     .WORD   -40000,0                ;FSRC OPERAND.
20348  112120  143600  000000        2$:     .WORD   143600,0                ;EXPECTED RESULT.
20349  112124  043600  000000        3$:     .WORD   43600,0         ;ANTICIPATED ERRONEOUS RESULT.
20350  112130  000007                 4$:     7                       ;FPS BEFORE EXECUTION.
20351  112132  000010                         10                      ;FPS AFTER EXECUTION.
20352  112134  177777                         -1                      ;ANTICIPATED ERRONEOUS FPS.
20353                                  ;OPERAND=-1     FL-0
20354  112136  004737  112576        KKC10:  JSR     PC,@#LDCFSUB    ;GO EXECUTE THE INSTRUCTION.
20355  112142  177777  000000        1$:     .WORD   -1,0            ;FSRC OPERAND.
20356  112146  140200  000000        2$:     .WORD   140200,0                ;EXPECTED RESULT.
20357  112152  144000  000400        3$:     .WORD   144000,400              ;ANTICIPATED ERRONEOUS RESULT.
20358  112156  000000                 4$:     0                       ;FPS BEFORE EXECUTION.
20359  112160  000010                         10                      ;FPS AFTER EXECUTION.
20360  112162  177777                         -1                      ;ANTICIPATED ERRONEOUS FPS.
20361                                  ;OPERAND=PATTERN                FL=0
20362  112164  004737  112576        KKC11:  JSR     PC,@#LDCFSUB    ;GO EXECUTE THE INSTRUCTION.
20363  112170  125252  000000        1$:     .WORD   125252,0                ;FSRC OPERAND.
20364  112174  143652  126000        2$:     .WORD   143652,126000           ;EXPECTED RESULT.
20365  112200  043652  126000        3$:     .WORD   43652,126000            ;ANTICIPATED ERRONEOUS RESULT.
20366  112204  000007                 4$:     7                       ;FPS BEFORE EXECUTION.
20367  112206  000010                         10                      ;FPS AFTER EXECUTION.
20368  112210  177777                         -1                      ;ANTICIPATED ERRONEOUS FPS.
20369                                  ;OPERAND        POS     FL-1
20370  112212  004737  112576        KKC12:  JSR     PC,@#LDCFSUB    ;GO EXECUTE THE INSTRUCTION.
20371  112216  040000  000000        1$:     .WORD   40000,0         ;FSRC OPERAND.
20372  112222  047600  000000        2$:     .WORD   47600,0         ;EXPECTED RESULT.
20373  112226  043600  000000        3$:     .WORD   43600,0         ;ANTICIPATED ERRONEOUS RESULT.
```

```
20374  112232  000117                  4$:     117                     ;FPS BEFORE EXECUTION.
20375  112234  000100                          100                     ;FPS AFTER EXECUTION.
20376  112236  177777                          -1                      ;ANTICIPATED ERRONEOUS FPS.
20377                                  ;OPERAND=1      FL=1
20378  112240  004737  112576          KKC13:  JSR     PC,@#LDCFSUB    ;GO EXECUTE THE INSTRUCTION.
20379  112244  000000  000001          1$:     .WORD   0,1             ;FSRC OPERAND.
20380  112250  040200  000000          2$:     .WORD   40200,0         ;EXPECTED RESULT.
20381  112254  034200  000000          3$:     .WORD   34200,0         ;ANTICIPATED ERRONEOUS RESULT.
20382  112260  000100                  4$:     100                     ;FPS BEFORE EXECUTION.
20383  112262  000100                          100                     ;FPS AFTER EXECUTION.
20384  112264  177777                          -1                      ;ANTICIPATED ERRONEOUS FPS.
20385                                  ;OPERAND=       PATTERN FL=1
20386  112266  004737  112576          KKC14:  JSR     PC,@#LDCFSUB    ;GO EXECUTE THE INSTRUCTION.
20387  112272  000000  000252          1$:     .WORD   0,252           ;FSRC OPERAND.
20388  112276  042052  000000          2$:     .WORD   42052,0         ;EXPECTED RESULT.
20389  112302  036052  000000          3$:     .WORD   36052,0         ;ANTICIPATED ERRONEOUS RESULT.
20390  112306  000111                  4$:     111                     ;FPS BEFORE EXECUTION.
20391  112310  000100                          100                     ;FPS AFTER EXECUTION.
20392  112312  177777                          -1                      ;ANTICIPATED ERRONEOUS FPS.
20393                                  ;OPERAND=-40000,0       FL=1
20394  112314  004737  112576          KKC15:  JSR     PC,@#LDCFSUB    ;GO EXECUTE THE INSTRUCTION.
20395  112320  140000  000000          1$:     .WORD   -40000,0                ;FSRC OPERAND.
20396  112324  147600  000000          2$:     .WORD   147600,0                ;EXPECTED RESULT.
20397  112330  047600  000000          3$:     .WORD   47600,0         ;ANTICIPATED ERRONEOUS RESULT.
20398  112334  000107                  4$:     107                     ;FPS BEFORE EXECUTION.
20399  112336  000110                          110                     ;FPS AFTER EXECUTION.
20400  112340  177777                          -1                      ;ANTICIPATED ERRONEOUS FPS.
20401                                  ;OPERAND=-1,-1  FL=1
20402  112342  004737  112576          KKC16:  JSR     PC,@#LDCFSUB    ;GO EXECUTE THE INSTRUCTION.
20403  112346  177777  177777          1$:     .WORD   -1,-1           ;FSRC OPERAND.
20404  112352  140200  000000          2$:     .WORD   140200,0                ;EXPECTED RESULT.
20405  112356  150000  000000          3$:     .WORD   150000,0                ;ANTICIPATED ERRONEOUS RESULT.
20406  112362  000100                  4$:     100                     ;FPS BEFORE EXECUTION.
20407  112364  000110                          110                     ;FPS AFTER EXECUTION.
20408  112366  177777                          -1                      ;ANTICIPATED ERRONEOUS FPS.
20409                                  ;OPERAND=-PATTERN       FL=1,   ROUND MODE
20410  112370  004737  112576          KKC17:  JSR     PC,@#LDCFSUB    ;GO EXECUTE THE INSTRUCTION.
20411  112374  125252  125252          1$:     .WORD   125252,125252           ;FSRC OPERAND.
20412  112400  147652  125253          2$:     .WORD   147652,125253           ;EXPECTED RESULT.
20413  112404  047652  125253          3$:     .WORD   47652,125253            ;ANTICIPATED ERRONEOUS RESULT.
20414  112410  000105                  4$:     105                     ;FPS BEFORE EXECUTION.
20415  112412  000110                          110                     ;FPS AFTER EXECUTION.
20416  112414  177777                          -1                      ;ANTICIPATED ERRONEOUS FPS.
20417                                  ;OPERAND=77777,177500   FL=1,   ROUND MODE
20418  112416  004737  112576          KKC20:  JSR     PC,@#LDCFSUB    ;GO EXECUTE THE INSTRUCTION.
20419  112422  077777  177500          1$:     .WORD   77777,177500            ;FSRC OPERAND.
20420  112426  047777  177777          2$:     .WORD   47777,177777            ;EXPECTED RESULT.
20421  112432  047777  177776          3$:     .WORD   47777,177776            ;ANTICIPATED ERRONEOUS RESULT.
20422  112436  000117                  4$:     117                     ;FPS BEFORE EXECUTION.
20423  112440  000100                          100                     ;FPS AFTER EXECUTION.
20424  112442  177777                          -1                      ;ANTICIPATED ERRONEOUS FPS.
20425                                  ;OPERAND=40000,000100   FL=1,   ROUND MODE
20426  112444  004737  112576          KKC21:  JSR     PC,@#LDCFSUB    ;GO EXECUTE THE INSTRUCTION.
20427  112450  040000  000100          1$:     .WORD   40000,100               ;FSRC OPERAND.
20428  112454  047600  000001          2$:     .WORD   47600,1         ;EXPECTED RESULT.
20429  112460  047600  000000          3$:     .WORD   47600,0         ;ANTICIPATED ERRONEOUS RESULT.
```

```
20430  112464  000102                4$:     102                     ;FPS BEFORE EXECUTION.
20431  112466  000100                        100                     ;FPS AFTER EXECUTION.
20432  112470  177777                        -1                      ;ANTICIPATED ERRONEOUS FPS.
20433                                ;OPERAND=40000,000100   FL=1,    TRUNC MODE
20434  112472  004737  112576        KKC22:  JSR     PC,@#LDCFSUB    ;GO EXECUTE THE INSTRUCTION.
20435  112476  040000  000100        1$:     .WORD   40000,100               ;FSRC OPERAND.
20436  112502  047600  000000        2$:     .WORD   47600,0         ;EXPECTED RESULT.
20437  112506  047600  000001        3$:     .WORD   47600,1         ;ANTICIPATED ERRONEOUS RESULT.
20438  112512  000157                4$:     157                     ;FPS BEFORE EXECUTION.
20439  112514  000140                        140                     ;FPS AFTER EXECUTION.
20440  112516  177777                        -1                      ;ANTICIPATED ERRONEOUS FPS.
20441                                ;OPERAND=100000,0 (MOST NEG #)  FL=0
20442  112520  004737  112576        KKC23:  JSR     PC,@#LDCFSUB    ;GO EXECUTE THE INSTRUCTION.
20443  112524  100000  000000        1$:     .WORD   100000,0                ;FSRC OPERAND.
20444  112530  144000  000000        2$:     .WORD   144000,0                ;EXPECTED RESULT.
20445  112534  143600  000000        3$:     .WORD   143600,0                ;ANTICIPATED ERRONEOUS RESULT.
20446  112540  000007                4$:     7                       ;FPS BEFORE EXECUTION.
20447  112542  000010                        10                      ;FPS AFTER EXECUTION.
20448  112544  177777                        -1                      ;ANTICIPATED ERRONEOUS FPS.
20449                                ;OPERAND=100000,0       FL=1
20450  112546  004737  112576        KKC24:  JSR     PC,@#LDCFSUB    ;GO EXECUTE THE INSTRUCTION.
20451  112552  100000  000000        1$:     .WORD   100000,0                ;FSRC OPERAND.
20452  112556  150000  000000        2$:     .WORD   150000,0                ;EXPECTED RESULT.
20453  112562  147600  000000        3$:     .WORD   147600,0                ;ANTICIPATED ERRONEOUS RESULT.
20454  112566  000107                4$:     107                     ;FPS BEFORE EXECUTION.
20455  112570  000110                        110                     ;FPS AFTER EXECUTION.
20456  112572  177777                        -1                      ;ANTICIPATED ERRONEOUS FPS.
20457  112574  000441                6$:     BR      KKCDONE
20458
20459                                ;THIS SUBROUTINE, LDCFSUB, IS USED TO SET UP THE OPERANDS, EXECUTE
20460                                ;THE LDCIF OR LDCLF INSTRUCTION AND CHECK THE RESULTS. A CALL
20461                                ;TO IT IS MADE THUS:
20462                                ;
20463                                ;               JSR     PC,@#LDCFSUB
20464                                ;               ACARG:  .WORD   X,X             ;AC OPERAND
20465                                ;               RES:    .WORD   X,X             ;EXPECTED RESULT
20466                                ;               ERRES:  .WORD   X,X             ;ERROR RESULT
20467                                ;               FPSB:   .WORD   X               ;FPS BEFORE EXECUTION
20468                                ;               FPSA:   .WORD   X               ;FPS AFTER EXECUTION
20469                                ;               ERFPS:  .WORD   X               ;ERROR FPS
20470                                ;               ERR1:   ERROR   X               ;DATA ERROR
20471                                ;                       BR      CONT
20472                                ;               ERR2:   ERROR   X               ;FPS ERROR
20473                                ;               CONT:                           ;RETURN ADDRESS
20474                                ;
20475                                ;THE OPERANDS ARE SET UP (USING AC0 AS THE ACCUMULATOR). THEN
20476                                ;THE LDCIF OR LDCLF INSTRUCTION IS EXECUTED.
20477                                ;THE RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS
20478                                ;COMPARED WITH FPSA IF THIS TOO IS CORRECT LDCFSUB RETURNS CONTROL
20479                                ;TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD LDCFSUB WILL
20480                                ;COMPARE IT TO ERROR FPS. IF THIS MATCHES THEN LDCFSUB WILL RETURN
20481                                ;TO THE ERROR CALL AT ERR2, OTHERWISE LDCFSUB ITSELF
20482                                ;REPORTS THIS FAILURE AND THEN RETURNS TO CONT. IF THE RESULT OF THE
20483                                ;LDCIF OR LDCLF IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE
20484                                ;ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN
20485                                ;THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN LDCFSUB
```

```
20486                                   ;WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR1. OTHERWISE THE
20487                                   ;RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND LDCFSUB
20488                                   ;REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.
20489
20490  112576  012601                   LDCFSUB:        MOV     (SP)+,R1        ;GET A POINTER TO THE ARGUMENTS.
20491  112600  016100  000014                   MOV     14(R1),R0       ;SET THE FPS.
20492  112604  170100                           LDFPS   R0
20493  112606  010100                           MOV     R1,R0
20494
20495  112610  177010                   1$:     LDCIF   (R0),AC0                ;TEST INSTRUCTION LDCIF OR LDCLF.
20496
20497  112612  170204                           STFPS   R4              ;GET FPS.
20498  112614  012700  112670                   MOV     #LDCT,R0        ;GET THE RESULT.
20499  112620  012702  000200                   MOV     #200,R2
20500  112624  170102                           LDFPS   R2
20501  112626  174010                           STD     AC0,(R0)
20502
20503  112630  012702  112670                   MOV     #LDCT,R2        ;SEE IF THE RESULT WAS CORRECT.
20504  112634  010100                           MOV     R1,R0
20505  112636  062700  000004                   ADD     #4,R0
20506  112642  012703  000002                   MOV     #2,R3
20507  112646  022022                   2$:     CMP     (R0)+,(R2)+
20508  112650  001006                           BNE     10$             ;BR IF INCORRECT.
20509  112652  077303                           SOB     R3,2$
20510
20511  112654  026104  000016                   CMP     16(R1),R4       ;SEE IF THE FPS WAS CORRECT.
20512  112660  001002                           BNE     10$             ;BR IF INCORRECT.
20513  112662  000161  000022           3$:     JMP     22(R1)          ;RETURN.
20514  112666                           10$:
20515  112666  104000                           EMT                     ;
20516
20517                                   ;DATA BUFFER:
20518  112670  000000  000000  000000   LDCT:   .WORD   0,0,0,0
20519  112676  000000
20520
20521  112700                           KKCDONE:
20522  112700  004767  005570                   JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
20523                                                                   ;SEE IF THE USER HAS EXPRESSED
20524                                                                   ;THE DESIRE TO CHANGE THE SOFTWARE
20525                                                                   ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
20526                                                                   ;THE USER TYPED CONTROL G?).
20527
20528
20529                                   ;*****************************************************************************************
20530                                   ;TEST 556       LDCID AND LDCLD TEST
20531                                   ;*****************************************************************************************
20532  112704                           TS556:
20533                                   ;OPERAND=0      FL=0,   FD=1
20534  112704  004737  113362           LLC1:   JSR     PC,@#LDCDSUB    ;GO EXECUTE THE INSTRUCTION.
20535  112710  000000  000000           1$:     .WORD   0,0             ;FSRC OPERAND.
20536  112714  000000  000000  000000   2$:     .WORD   0,0,0,0         ;EXPECTED RESULT.
20537  112722  000000
20538  112724  177777  177777  177777   3$:     .WORD   -1,-1,-1,-1             ;ANTICIPATED ERRONEOUS RESULT.
20539  112732  177777
20540  112734  000213                   4$:     213                     ;FPS BEFORE EXECUTION.
20541  112736  000204                           204                     ;FPS AFTER EXECUTION.
```

```
20542  112740  177777                          -1                              ;ANTICIPATED ERRONEOUS FPS.
20543                                  ;OPERAND=0      FL=0,   FD=1
20544  112742  004737  113362          LLC2:   JSR     PC,@#LDCDSUB    ;GO EXECUTE THE INSTRUCTION.
20545  112746  000000  177777          1$:     .WORD   0,-1            ;FSRC OPERAND.
20546  112752  000000  000000  000000  2$:     .WORD   0,0,0,0         ;EXPECTED RESULT.
20547  112760  000000
20548  112762  004177  177400  000000  3$:     .WORD   4177,177400,0,0         ;ANTICIPATED ERRONEOUS RESULT.
20549  112770  000000
20550  112772  000200                  4$:     200                     ;FPS BEFORE EXECUTION.
20551  112774  000204                          204                     ;FPS AFTER EXECUTION.
20552  112776  177777                          -1                      ;ANTICIPATED ERRONEOUS FPS.
20553                                  ;OPERAND=0      FL=1    FD=1
20554  113000  004737  113362          LLC3:   JSR     PC,@#LDCDSUB    ;GO EXECUTE THE INSTRUCTION.
20555  113004  000000  000000          1$:     .WORD   0,0             ;FSRC OPERAND.
20556  113010  000000  000000  000000  2$:     .WORD   0,0,0,0         ;EXPECTED RESULT.
20557  113016  000000
20558  113020  177777  177777  177777  3$:     .WORD   -1,-1,-1,-1             ;ANTICIPATED ERRONEOUS RESULT.
20559  113026  177777
20560  113030  000211                  4$:     211                     ;FPS BEFORE EXECUTION.
20561  113032  000204                          204                     ;FPS AFTER EXECUTION.
20562  113034  177777                          -1                      ;ANTICIPATED ERRONEOUS FPS.
20563                                  ;OPERAND=40000  FL=0     FD=1
20564  113036  004737  113362          LLC4:   JSR     PC,@#LDCDSUB    ;GO EXECUTE THE INSTRUCTION.
20565  113042  040000  000000          1$:     .WORD   40000,0         ;FSRC OPERAND.
20566  113046  043600  000000  000000  2$:     .WORD   43600,0,0,0             ;EXPECTED RESULT.
20567  113054  000000
20568  113056  047600  000000  000000  3$:     .WORD   47600,0,0,0             ;ANTICIPATED ERRONEOUS RESULT.
20569  113064  000000
20570  113066  000217                  4$:     217                     ;FPS BEFORE EXECUTION.
20571  113070  000200                          200                     ;FPS AFTER EXECUTION.
20572  113072  177777                          -1                      ;ANTICIPATED ERRONEOUS FPS.
20573                                  ;OPERAND=-40000 FL=0     FD=1
20574  113074  004737  113362          LLC5:   JSR     PC,@#LDCDSUB    ;GO EXECUTE THE INSTRUCTION.
20575  113100  140000  000000          1$:     .WORD   -40000,0                ;FSRC OPERAND.
20576  113104  143600  000000  000000  2$:     .WORD   143600,0,0,0            ;EXPECTED RESULT.
20577  113112  000000
20578  113114  043600  000000  000000  3$:     .WORD   43600,0,0,0             ;ANTICIPATED ERRONEOUS RESULT.
20579  113122  000000
20580  113124  000200                  4$:     200                     ;FPS BEFORE EXECUTION.
20581  113126  000210                          210                     ;FPS AFTER EXECUTION.
20582  113130  177777                          -1                      ;ANTICIPATED ERRONEOUS FPS.
20583                                  ;OPERAND=40000,0        FL=1    FD=1
20584  113132  004737  113362          LLC6:   JSR     PC,@#LDCDSUB    ;GO EXECUTE THE INSTRUCTION.
20585  113136  040000  000000          1$:     .WORD   40000,0         ;FSRC OPERAND.
20586  113142  047600  000000  000000  2$:     .WORD   47600,0,0,0             ;EXPECTED RESULT.
20587  113150  000000
20588  113152  043600  000000  000000  3$:     .WORD   43600,0,0,0             ;ANTICIPATED ERRONEOUS RESULT.
20589  113160  000000
20590  113162  000317                          317                     ;FPS BEFORE EXECUTION.
20591  113164  000300                          300                     ;FPS AFTER EXECUTION.
20592  113166  177777                          -1                      ;ANTICIPATED ERRONEOUS FPS.
20593                                  ;OPERAND=0,1    FL=1    FD=1
20594  113170  004737  113362          LLC7:   JSR     PC,@#LDCDSUB    ;GO EXECUTE THE INSTRUCTION.
20595  113174  000000  000001          1$:     .WORD   0,1             ;FSRC OPERAND.
20596  113200  040200  000000  000000  2$:     .WORD   40200,0,0,0             ;EXPECTED RESULT.
20597  113206  000000
```

```
20598  113210  034200  000000  000000  3$:     .WORD   34200,0,0,0            ;ANTICIPATED ERRONEOUS RESULT.
20599  113216  000000
20600  113220  000300                  4$:     300                     ;FPS BEFORE EXECUTION.
20601  113222  000300                          300                     ;FPS AFTER EXECUTION.
20602  113224  177777                          -1                      ;ANTICIPATED ERRONEOUS FPS.
20603                                  ;OPERAND=77777,177777   FL=1     FD=1
20604  113226  004737  113362          LLC10:  JSR     PC,@#LDCDSUB    ;GO EXECUTE THE INSTRUCTION.
20605  113232  077777  177777          1$:     .WORD   77777,177777            ;FSRC OPERAND.
20606  113236  047777  177777  177000  2$:     .WORD   47777,177777,177000,0           ;EXPECTED RESULT.
20607  113244  000000
20608  113246  177777  177777  177777  3$:     .WORD   -1,-1,-1,-1             ;ANTICIPATED ERRONEOUS RESULT.
20609  113254  177777
20610  113256  000317                  4$:     317                     ;FPS BEFORE EXECUTION.
20611  113260  000300                          300                     ;FPS AFTER EXECUTION.
20612  113262  177777                          -1                      ;ANTICIPATED ERRONEOUS FPS.
20613                                  ;OPERAND=-PATTERN       FL=1    FD=1
20614
20615  113264  004767  000072          LLC11:  JSR     PC,LDCDSUB      ;GO EXECUTE THE INSTPUCTION.
20616  113270  177777  177526          1$:     .WORD   -1,-252         ;FSRC OPERAND.
20617  113274  142052  000000  000000  2$:     .WORD   142052,0,0,0            ;EXPECTED RESULT.
20618  113302  000000
20619  113304  136052  000000  000000  3$:     .WORD   136052,0,0,0            ;ANTICIPATED ERRONEOUS RESULT.
20620  113312  000000
20621  113314  000307                  4$:     307                     ;FPS BEFORE EXECUTION.
20622  113316  000310                          310                     ;FPS AFTER EXECUTION.
20623  113320  177777                          -1                      ;ANTICIPATED ERRONEOUS FPS.
20624                                  ;OPERAND=PATTERN        FL=1    FD=1    FI=1
20625  113322  004767  000034          LLC12:  JSR     PC,LDCDSUB      ;GO EXECUTE THE INSTRUCTION.
20626  113326  012345  067012          1$:     .WORD   12345,67012             ;FSRC OPERAND.
20627  113332  047247  025560  050000  2$:     .WORD   47247,025560,050000,0           ;EXPECTED RESULT.
20628  113340  000000
20629  113342  177777  177777  177777  3$:     .WORD   -1,-1,-1,-1             ;ANTICIPATED ERRONEOUS RESULT.
20630  113350  177777
20631  113352  000352                  4$:     352                     ;FPS BEFORE EXECUTION.
20632  113354  000340                          340                     ;FPS AFTER EXECUTION.
20633  113356  177777                          -1                      ;ANTICIPATED ERRONEOUS FPS.
20634  113360  000435                  6$:     BR      LLCDONE
20635
20636                                  ;THIS SUBROUTINE, LDCDSUB, IS USED TO SET UP THE OPERANDS, EXECUTE
20637                                  ;THE LDCID OR LDCLD INSTRUCTION AND CHECK THE RESULTS. A CALL
20638                                  ;TO IT IS MADE THUS:
20639                                  ;
20640                                  ;               JSR     PC,@#LDCDSUB
20641                                  ;               ACARG:  .WORD   X,X             ;AC OPERAND
20642                                  ;               RES:    .WORD   X,X,X,X         ;EXPECTED RESULT
20643                                  ;               ERRES:  .WORD   X,X,X,X         ;ERROR RESULT
20644                                  ;               FPSB:   .WORD   X               ;FPS BEFORE EXECUTION
20645                                  ;               FPSA:   .WORD   X               ;FPS AFTER EXECUTION
20646                                  ;               ERFPS:  .WORD   X               ;ERROR FPS.
20647                                  ;               ERR1:   ERROR   X               ;DATA ERROR.
20648                                  ;                       BR      CONT
20649                                  ;               ERR2:   ERROR   X               ;FPS ERROR.
20650                                  ;               CONT:                           ;RETURN ADDRESS
20651                                  ;
20652                                  ;THE OPERANDS ARE SET UP (USING AC0 AS THE ACCUMULATOR). THEN
20653                                  ;THE LDCID OR LDCLD INSTRUCTION IS EXECUTED.
```

```
20654                                   ;THE RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS
20655                                   ;COMPARED WITH FPSA IF THIS TOO IS CORRECT LDCDSUB RETURNS CONTROL
20656                                   ;TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD LDCDSUB
20657                                   ;COMPARE IT TO ERROR FPS. IF THIS MATCHES THEN LDCDSUB WILL RETURN
20658                                   ;TO THE ERROR CALL AT ERR2, OTHERWISE LDCDSUB ITSELF
20659                                   ;REPORTS THIS FAILURE AND THEN RETURNS TO CONT. IF THE RESULT OF THE
20660                                   ;LDCID OR LDCLD IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE
20661                                   ;ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN
20662                                   ;THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN LDCDSUB
20663                                   ;WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR1. OTHERWISE THE
20664                                   ;RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND LDCDSUB WILL
20665                                   ;REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.
20666
20667  113362  012601                   LDCDSUB:    MOV     (SP)+,R1        ;GET A POINTER TO THE ARGUMENTS.
20668  113364  016100  000024                   MOV     24(R1),R0       ;SET THE FPS.
20669  113370  170100                           LDFPS   R0
20670  113372  010100                           MOV     R1,R0
20671  113374  177010                   1$:     LDCID   (R0),AC0        ;TEST INSTRUCTION, LDCID OR LDCLD.
20672
20673  113376  170204                           STFPS   R4              ;GET FPS.
20674  113400  012700  112670                   MOV     #LDCT,R0        ;GET THE RESULT.
20675  113404  012702  000200                   MOV     #200,R2
20676  113410  170102                           LDFPS   R2
20677  113412  174010                           STD     AC0,(R0)
20678
20679                                   ;SEE IF THE RESULT IS CORRECT.
20680  113414  012702  112670                   MOV     #LDCT,R2
20681  113420  010100                           MOV     R1,R0
20682  113422  062700  000004                   ADD     #4,R0
20683  113426  012703  000002                   MOV     #2,R3
20684  113432  022022                   2$:     CMP     (R0)+,(R2)+
20685  113434  001006                           BNE     10$             ;BR IF INCORRECT.
20686  113436  077303                           SOB     R3,2$
20687
20688  113440  026104  000026                   CMP     26(R1),R4               ;IS THE FPS CORRECT?
20689  113444  001002                           BNE     10$             ;BR IF INCORRECT.
20690  113446  000161  000032           3$:     JMP     32(R1)          ;RETURN.
20691  113452                           10$:
20692  113452  104000                           EMT                     ;
20693
20694  113454                           LLCDONE:
20695  113454  004767  005014                   JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
20696                                                                   ;SEE IF THE USER HAS EXPRESSED
20697                                                                   ;THE DESIRE TO CHANGE THE SOFTWARE
20698                                                                   ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
20699                                                                   ;THE USER TYPED CONTROL G?).
20700
20701
20702                                   ;*****************************************************************************
20703                                   ;TEST 557       LDEXP TEST
20704                                   ;*****************************************************************************
20705  113460                           TS557:
20706
20707                                   ; NON-ZERO RES. VALID EXPON=210 (EXCESS 200)=10
20708  113460  004767  001136           MMC1:   JSR     PC,LDXSUB       ;GO EXECUTE THE INSTRUCTION.
20709  113464  012345  067012  034567  1$:     .WORD   12345,67012,34567,012345        ;AC0 OPERAND.
```

```
20710  113472  012345
20711  113474  000010                    2$:     .WORD   10                      ;EXPONENT OPERAND.
20712  113476  042145  067012  034567    3$:     .WORD   42145,67012,34567,012345                ;EXPECTED RESULT.
20713  113504  012345
20714  113506  002145  067012  034567    4$:     .WORD   2145,67012,34567,012345         ;ANTICIPATED ERRONEOUS RESULT.
20715  113514  012345
20716  113516  047217                    5$:     47217                   ;FPS BEFORE EXECUTION.
20717  113520  047200                            47200                   ;FPS AFTER EXECUTION.
20718  113522  147200                            147200                  ;ANTICIPATED ERRONEOUS FPS.
20719  113524  177777                            -1              ;EXPECTED FEC.
20720                                    ;NON-ZERO       RES     NEG.
20721  113526  004737  114622            MMC2:   JSR     PC,@#LDXSUB     ;EXPON=377
20722  113532  123456  070123  045670    1$:     .WORD   123456,70123,45670,123456       ;AC0 OPERAND.
20723  113540  123456
20724  113542  000177                    2$:     .WORD   177                     ;EXPONENT OPERAND.
20725  113544  177656  070123  045670    3$:     .WORD   177656,70123,45670,123456               ;EXPECTED RESULT.
20726  113552  123456
20727  113554  137656  070123  045670    4$:     .WORD   137656,70123,45670,123456               ;ANTICIPATED ERRONEOUS RESULT.
20728  113562  123456
20729  113564  047207                    5$:     47207                   ;FPS BEFORE EXECUTION.
20730  113566  047210                            47210                   ;FPS AFTER EXECUTION.
20731  113570  147210                            147210                  ;ANTICIPATED ERRONEOUS FPS.
20732  113572  177777                            -1              ;EXPECTED FEC.
20733                                    ;NON-ZERO       RES,    EXP=256=(56)REAL
20734  113574  004737  114622            MMC3:   JSR     PC,@#LDXSUB     ;GO EXECUTE THE INSTRUCTION.
20735  113600  073261  057645  043323    1$:     .WORD   73261,057645,43323,101760       ;AC0 OPERAND.
20736  113606  101760
20737  113610  000056                    2$:     .WORD   56                      ;EXPONENT OPERAND.
20738  113612  053461  057645  043323    3$:     .WORD   53461,057645,43323,101760               ;EXPECTED RESULT.
20739  113620  101760
20740  113622  177777  177777  177777    4$:     .WORD   -1,-1,-1,-1             ;ANTICIPATED ERRONEOUS RESULT.
20741  113630  177777
20742  113632  047200                    5$:     47200                   ;FPS BEFORE EXECUTION.
20743  113634  047200                            47200                   ;FPS AFTER EXECUTION.
20744  113636  147200                            147200                  ;ANTICIPATED ERRONEOUS FPS.
20745  113640  177777                            -1              ;EXPECTED FEC.
20746                                    ;EXP=27 (EXCESS 200)=-151 (OCT)
20747  113642  004737  114622            MMC4:   JSR     PC,@#LDXSUB     ;GO EXECUTE THE INSTRUCTION.
20748  113646  012223  024252  062720    1$:     .WORD   12223,24252,62720,21222 ;AC0 OPERAND.
20749  113654  021222
20750  113656  177627                    2$:     .WORD   -151                    ;EXPONENT OPERAND.
20751  113660  005623  024252  062720    3$:     .WORD   5623,24252,62720,21222          ;EXPECTED RESULT.
20752  113666  021222
20753  113670  177777  177777  177777    4$:     .WORD   -1,-1,-1,-1             ;ANTICIPATED ERRONEOUS RESULT.
20754  113676  177777
20755  113700  047200                    5$:     47200                   ;FPS BEFORE EXECUTION.
20756  113702  047200                            47200                   ;FPS AFTER EXECUTION.
20757  113704  147200                            147200                  ;ANTICIPATED ERRONEOUS FPS.
20758  113706  177777                            -1              ;EXPECTED FEC.
20759                                    ;EXP=0 (EXCESS 200)=-200 (OCT), POSITIVE FRAC
20760                                    ; FIV=1
20761  113710  004737  114622            MMC5:   JSR     PC,@#LDXSUB     ;GO EXECUTE THE INSTRUCTION.
20762  113714  030131  032334  035363    1$:     .WORD   30131,32334,35363,73031 ;AC0 OPERAND.
20763  113722  073031
20764  113724  177600                    2$:     .WORD   -200                    ;EXPONENT OPERAND.
20765  113726  000131  032334  035363    3$:     .WORD   00131,32334,35363,73031         ;EXPECTED RESULT.
```

```
20766  113734  073031
20767  113736  000000  000000  000000  4$:     .WORD   0,0,0,0          ;ANTICIPATED ERRONEOUS RESULT.
20768  113744  000000
20769  113746  042200                  5$:     42200                   ;FPS BEFORE EXECUTION.
20770  113750  142204                          142204                  ;FPS AFTER EXECUTION.
20771  113752  042202                          42202                   ;ANTICIPATED ERRONEOUS FPS.
20772  113754  000012                          12              ;EXPECTED FEC.
20773                                  ;EXP=0  (EXCESS 200)=-200 (OCT), NEG FRACT,FIU=1
20774  113756  004737  114622          MMC6:   JSR     PC,@#LDXSUB     ;GO EXECUTE THE INSTRUCTION.
20775  113762  140414  024344  045464  1$:     .WORD   140414,24344,45464,74045        ;AC0 OPERAND.
20776  113770  074045
20777  113772  177600                  2$:     .WORD   -200                    ;EXPONENT OPERAND.
20778  113774  100014  024344  045464  3$:     .WORD   100014,24344,45464,74045        ;-0             ;EXPECTED RESULT.
20779  114002  074045
20780  114004  000000  000000  000000  4$:     .WORD   0,0,0,0         ;ANTICIPATED ERRONEOUS RESULT.
20781  114012  000000
20782  114014  042200                  5$:     42200                   ;FPS BEFORE EXECUTION.
20783  114016  142214                          142214                  ;FPS AFTER EXECUTION.
20784  114020  042214                          42214                   ;ANTICIPATED ERRONEOUS FPS.
20785  114022  000012                          12              ;EXPECTED FEC.
20786                                  ;EXP=0 (EXCESS 200)=-200 (OCT),POS FRAC, FIU=0
20787
20788  114024  004737  114622          MMC7:   JSR     PC,@#LDXSUB     ;GO EXECUTE THE INSTRUCTION.
20789  114030  051525  035455  005675  1$:     .WORD   51525,35455,5675,05152  ;AC0 OPERAND.
20790  114036  005152
20791  114040  177600                  2$:     .WORD   -200                    ;EXPONENT OPERAND.
20792  114042  000000  000000  000000  3$:     .WORD   0,0,0,0                 ;EXPECTED RESULT.
20793  114050  000000
20794  114052  000125  035455  005675  4$:     .WORD   00125,35455,5675,05152          ;ANTICIPATED ERRONEOUS RESULT.
20795  114060  005152
20796  114062  045200                          45200                   ;FPS BEFORE EXECUTION.
20797  114064  045204                          45204                   ;FPS AFTER EXECUTION.
20798  114066  145204                          145204                  ;ANTICIPATED ERRONEOUS FPS.
20799  114070  177777                          -1              ;EXPECTED FEC.
20800                                  ;EXP=-1405 (EXCESS 200)=-1605 (OCT), FIU=1
20801  114072  004737  114622          MMC10:  JSR     PC,@#LDXSUB     ;GO EXECUTE THE INSTRUCTION.
20802  114076  061626  062636  046566  1$:     .WORD   61626,62636,46566,67606 ;AC0 OPERAND.
20803  114104  067606
20804  114106  176173                  2$:     .WORD   -1605                   ;EXPONENT OPERAND.
20805  114110  076626  062636  046566  3$:     .WORD   76626,62636,46566,67606         ;EXPECTED RESULT.
20806  114116  067606
20807  114120  000000  000000  000000  4$:     .WORD   0,0,0,0         ;ANTICIPATED ERRONEOUS RESULT.
20808  114126  000000
20809  114130  042200                  5$:     42200                   ;FPS BEFORE EXECUTION.
20810  114132  142200                          142200                  ;FPS AFTER EXECUTION.
20811  114134  042204                          42204                   ;ANTICIPATED ERRONEOUS FPS.
20812  114136  000012                          12              ;EXPECTED FEC.
20813                                  ;EXP=-17416 (EXCESS 200)=-17616 (OCT), FIU=0
20814  114140  004737  114622          MMC11:  JSR     PC,@#LDXSUB     ;GO EXECUTE THE INSTRUCTION.
20815  114144  071727  037475  076777  1$:     .WORD   71727,37475,76777,17273 ;AC0 OPERAND.
20816  114152  017273
20817  114154  160162                  2$:     .WORD   -17616                  ;EXPONENT OPERAND.
20818  114156  000000  000000  000000  3$:     .WORD   0,0,0,0                 ;EXPECTED RESULT.
20819  114164  000000
20820  114166  074527  037475  076777  4$:     .WORD   74527,37475,76777,17273         ;ANTICIPATED ERRONEOUS RESULT.
20821  114174  017273
```

```
20822  114176  045200                  5$:     45200                   ;FPS BEFORE EXECUTION.
20823  114200  045204                          45204                   ;FPS AFTER EXECUTION.
20824  114202  145200                          145200                  ;ANTICIPATED ERRONEOUS FPS.
20825  114204  177777                          -1              ;EXPECTED FEC.
20826                                  ;EXP=-1601 (EXCESS 200)=-2001 (OCT), FIU=1
20827  114206  004737  114622          MMC12:  JSR     PC,@#LDXSUB     ;GO EXECUTE THE INSTRUCTION.
20828  114212  001020  030405  006070  1$:     .WORD   01020,30405,06070,00102 ;AC0 OPERAND.
20829  114220  000102
20830  114222  175777                  2$:     .WORD   -2001                   XPONENT OPERAND.
20831  114224  037620  030405  006070  3$:     .WORD   37620,30405,06070,00102         ;EXPECTED RESULT.
20832  114232  000102
20833  114234  000000  000000  000000  4$:     .WORD   0,0,0,0                 ;ANTICIPATED ERRONEOUS RESULT.
20834  114242  000000
20835  114244  042200                  5$:     42200                   ;FPS BEFORE EXECUTION.
20836  114246  142200                          142200                  ;FPS AFTER EXECUTION.
20837  114250  042204                          42204                   ;ANTICIPATED ERRONEOUS FPS.
20838  114252  000012                          12              ;EXPECTED FEC.
20839                                  ;EXP=1206 (EXCESS 200)=1006 (OCT) FIV =1
20840  114254  004737  114622          MMC13:  JSR     PC,@#LDXSUB     ;GO EXECUTE THE INSTRUCTION.
20841  114260  012131  014151  016171  1$:     .WORD   12131,14151,16171,10111 ;AC0 OPERAND.
20842  114266  010111
20843  114270  001006                  2$:     .WORD   1006                    ;EXPONENT OPERAND.
20844  114272  041531  014151  016171  3$:     .WORD   41531,14151,16171,10111         ;EXPECTED RESULT.
20845  114300  010111
20846  114302  000000  000000  000000  4$:     .WORD   0,0,0,0                 ;ANTICIPATED ERRONEOUS RESULT.
20847  114310  000000
20848  114312  041200                  5$:     41200                   ;FPS BEFORE EXECUTION.
20849  114314  141202                          141202                  ;FPS AFTER EXECUTION.
20850  114316  041204                          41204                   ;ANTICIPATED ERRONEOUS FPS.
20851  114320  000010                          10              ;EXPECTED FEC.
20852                                  ;EXP=16315 (EXCESS 200)=16115 (OCT) FIV=0
20853  114322  004737  114622          MMC14:  JSR     PC,@#LDXSUB     ;GO EXECUTE THE INSTRUCTION.
20854  114326  027262  025242  023222  1$:     .WORD   27262,25242,23222,21202 ;AC0 OPERAND.
20855  114334  021202
20856  114336  016115                  2$:     .WORD   16115           ;EXPONENT OPERAND.
20857  114340  000000  000000  000000  3$:     .WORD   0,0,0,0         ;EXPECTED RESULT.
20858  114346  000000
20859  114350  063262  025242  023222  4$:     .WORD   63262,25242,23222,21202         ;ANTICIPATED ERRONEOUS RESULT.
20860  114356  021202
20861  114360  046200                  5$:     46200                   ;FPS BEFORE EXECUTION.
20862  114362  046206                          46206                   ;FPS AFTER EXECUTION.
20863  114364  146202                          146202                  ;ANTICIPATED ERRONEOUS FPS.
20864  114366  177777                          -1              ;EXPECTED FEC.
20865                                  ;EXP=11011 (EXCESS 200)=10611 (OCT) FIV=1
20866
20867  114370  004737  114622          MMC15:  JSR     PC,@#LDXSUB     ;GO EXECUTE THE INSTRUCTION.
20868  114374  030313  032333  034353  1$:     .WORD   30313,32333,34353,36373 ;AC0 OPERAND.
20869  114402  036373
20870  114404  010611                  2$:     .WORD   10611           ;EXPONENT OPERAND.
20871  114406  002313  032333  034353  3$:     .WORD   2313,32333,34353,36373          ;EXPECTED RESULT.
20872  114414  036373
20873  114416  000000  000000  000000  4$:     .WORD   0,0,0,0         ;ANTICIPATED ERRONEOUS RESULT.
20874  114424  000000
20875  114426  041200                  5$:     41200                   ;FPS BEFORE EXECUTION.
20876  114430  141202                          141202                  ;FPS AFTER EXECUTION.
20877  114432  041204                          41204                   ;ANTICIPATED ERRONEOUS FPS.
```

```
20878  114434  000010                          10                      ;EXPECTED FEC.
20879                                  ;EXP=17123 (EXCESS 200)=16723 (OCT) FIV=0
20880
20881  114436  004737  114622          MMC16:  JSR     PC,@#LDXSUB     ;GO EXECUTE THE INSTRUCTION.
20882  114442  040414  042434  044454  1$:     .WORD   40414,42434,44454,46474 ;AC0 OPERAND.
20883  114450  046474
20884  114452  016723                  2$:     .WORD   16723           ;EXPONENT OPERAND.
20885  114454  000000  000000  000000  3$:     .WORD   0,0,0,0         ;EXPECTED RESULT.
20886  114462  000000
20887  114464  024614  042434  044454  4$:     .WORD   24614,42434,44454,46474         ;ANTICIPATED ERRONEOUS RESULT.
20888  114472  046474
20889  114474  046200                  5$:     46200                   ;FPS BEFORE EXECUTION.
20890  114476  046206                          46206                   ;FPS AFTER EXECUTION.
20891  114500  146202                          146202                  ;ANTICIPATED ERRONEOUS FPS.
20892  114502  177777                          -1              ;EXPECTED FEC.
20893                                  ;EXP=   254 (OCT)=      454 (EXCESS 200)        FIV=1
20894
20895  114504  004737  114622          MMC17:  JSR     PC,@#LDXSUB     ;GO EXECUTE THE INSTPUCTION.
20896  114510  050515  052535  054555  1$:     .WORD   50515,52535,54555,56575 ;AC0 OPERAND.
20897  114516  056575
20898  114520  000254                  2$:     .WORD   254             ;EXPONENT OPERAND.
20899  114522  013115  052535  054555  3$:     .WORD   13115,52535,54555,56575         ;EXPECTED RESULT.
20900  114530  056575
20901  114532  000000  000000  000000  4$:     .WORD   0,0,0,0         ;ANTICIPATED ERRONEOUS RESULT.
20902  114540  000000
20903  114542  041200                  5$:     41200                   ;FPS BEFORE EXECUTION.
20904  114544  141202                          141202                  ;FPS AFTER EXECUTION.
20905  114546  041204                          41204                   ;ANTICIPATED ERRONEOUS FPS.
20906  114550  000010                          10              ;EXPECTED FEC.
20907                                  ;EXP=   313 (OCT)=      513(EXCESS 200) FIV=0
20908
20909  114552  004737  114622          MMC20:  JSR     PC,@#LDXSUB     ;GO EXECUTE THE INSTRUCTION.
20910  114556  060616  062636  064656  1$:     .WORD   60616,62636,64656,66676 ;AC0 OPERAND.
20911  114564  066676
20912  114566  000313                  2$:     .WORD   313             ;EXPONENT OPERAND.
20913  114570  000000  000000  000000  3$:     .WORD   0,0,0,0         ;EXPECTED RESULT.
20914  114576  000000
20915  114600  022616  062636  064656  4$:     .WORD   22616,62636,64656,66676         ;ANTICIPATED ERRONEOUS RESULT.
20916  114606  066676
20917  114610  046200                  5$:     46200                   ;FPS BEFORE EXECUTION.
20918  114612  046206                          46206                   ;FPS AFTER EXECUTION.
20919  114614  146202                          146202                  ;ANTICIPATED ERRONEOUS FPS.
20920  114616  177777                          -1              ;EXPECTED FEC.
20921  114620  000457                          BR      MMCDONE
20922
20923                                  ;THIS SUBROUTINE, LDXSUB, IS USED TO SET UP THE OPERANDS, EXECUTE
20924                                  ;THE LDEXP INSTRUCTION AND CHECK THE RESULTS. A CALL
20925                                  ;TO IT IS MADE THUS:
20926                                  ;
20927                                  ;               JSR     PC,@#LDXSUB
20928                                  ;               ACARG:  .WORD   X,X,X,X         ;AC OPERAND
20929                                  ;               EXP:    .WORD   X               ;EXPONENT
20930                                  ;               RES:    .WORD   X,X,X,X         ;EXPECTED RESULT
20931                                  ;               ERRES:  .WORD   X,X,X,X         ;ERROR RESULT
20932                                  ;               FPSB:   .WORD   X               ;FPS BEFORE EXECUTION
20933                                  ;               FPSA:   .WORD   X               ;FPS AFTER EXECUTION
```

```
20934                                   ;               ERFPS:  .WORD   X               ;ERROR FPS.
20935                                   ;               FEC:    .WORD   X               ;EXPECTED FEC
20936                                   ;               ERR1:   ERROR   X               ;DATA ERROR.
20937                                   ;                       BR      CONT
20938                                   ;               ERR2:   ERROR   X               ;FPS ERROR.
20939                                   ;               CONT:                           ;RETURN ADDRESS
20940                                   ;
20941                                   ;THE OPERANDS ARE SET UP (USING AC0 AS THE ACCUMULATOR). THEN
20942                                   ;THE LDEXP INSTRUCTION IS EXECUTED.
20943                                   ;THE RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS
20944                                   ;COMPARED WITH FPSA IF THIS TOO IS CORRECT LDXSUB RETURNS CONTROL
20945                                   ;TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD LDXSUB
20946                                   ;COMPARE IT TO ERROR FPS. IF THIS MATCHES THEN LDXSUB WILL RETURN
20947                                   ;TO THE ERROR CALL AT ERR2, OTHERWISE LDXSUB ITSELF
20948                                   ;REPORTS THIS FAILURE AND THEN RETURNS TO CONT. IF THE RESULT OF THE
20949                                   ;LDEXP IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE
20950                                   ;ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN
20951                                   ;THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN LDXSUB
20952                                   ;WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR1. OTHERWISE THE
20953                                   ;RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND LDXSUB WILL
20954                                   ;REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.
20955
20956  114622  012601                  LDXSUB: MOV     (SP)+,R1        ;GET A POINTER TO THE ARGUMENTS.
20957  114624  012700  000200                  MOV     #200,R0         ;LOAD THE AC0 OPERAND.
20958  114630  170100                          LDFPS   R0
20959  114632  010100                          MOV     R1,R0
20960  114634  172410                          LDD     (R0),AC0
20961  114636  016100  000032                  MOV     32(R1),R0       ;SET UP THE FPS.
20962  114642  170100                          LDFPS   R0
20963  114644  010100                          MOV     R1,R0
20964  114646  062700  000010                  ADD     #10,R0
20965
20966  114652  176410                  1$:     LDEXP   (R0),AC0        ;TEST INSTRUCTION.
20967
20968  114654  170204                          STFPS   R4              ;GET THE FPS.
20969  114656  170305                          STST    R5              ;GET THE FEC.
20970  114660  012700  000200                  MOV     #200,R0         ;GET THE RESULT.
20971  114664  170100                          LDFPS   R0
20972  114666  012700  114750                  MOV     #LDXT,R0
20973  114672  174010                          STD     AC0,(R0)
20974  114674  012702  114750                  MOV     #LDXT,R2        ;SEE IF THE RESULT WAS CORRECT.
20975  114700  010103                          MOV     R1,R3
20976  114702  062703  000012                  ADD     #12,R3
20977  114706  012700  000004                  MOV     #4,R0
20978  114712  022223                  2$:     CMP     (R2)+,(R3)+
20979  114714  001014                          BNE     10$             ;BRANCH IF NOT CORRECT.
20980  114716  077003                          SOB     R0,2$
20981  114720  020461  000034                  CMP     R4,34(R1)       ;SEE IF THE FPS WAS CORRECT.
20982  114724  001010                          BNE     10$             ;BRANCH IF NOT CORRECT.
20983  114726  005761  000034                  TST     34(R1)
20984  114732  100003                          BPL     3$
20985  114734  020561  000040                  CMP     R5,40(R1)       ;SEE IF THE FEC WAS CORRECT.
20986  114740  001002                          BNE     10$             ;BRANCH IF NOT CORRECT.
20987
20988  114742  000161  000042          3$:     JMP     42(R1)          ;RETURN.
20989  114746                          10$:
```

```
20990  114746  104000                          EMT                     ;
20991
20992                                          ;DATA BUFFER:
20993  114750  000000  000000  000000  LDXT:   .WORD   0,0,0,0
20994  114756  000000
20995
20996  114760                          MMCDONE:
20997  114760  004767  003510                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
20998                                                                  ;SEE IF THE USER HAS EXPRESSED
20999                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
21000                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
21001                                                                  ;THE USER TYPED CONTROL G?).
21002
21003
21004
21005                                          ;*************************************************************************************
21006                                          ;TEST 560       DESTINATION MODES, MODE 1 (FL=0), TEST
21007                                          ;*************************************************************************************
21008  114764                          TS560:
21009
21010
21011  114764  012700  115054                  MOV     #NNCTB0,R0      ;SET UP THE DATA BUFFER.
21012  114770  012701  000006                  MOV     #6,R1
21013  114774  012720  177777          1$:     MOV     #-1,(R0)+
21014  115000  077103                          SOB     R1,1$
21015  115002  012700  102345                  MOV     #102345,R0
21016  115006  012737  115070  000004          MOV     #NNC10,@#ERRVECT ;SET UP FOR TRAPS TO 4.
21017  115014  170100                          LDFPS   R0              ;SET UP FPS.
21018  115016  012700  115060                  MOV     #NNCTB1,R0
21019
21020  115022  170210                  NNC2:   STFPS   (R0)            ;TEST INSTRUCTION.
21021  115024  020027  115060                  CMP     R0,#NNCTB1      ;IS R0 CORRECT?
21022  115030  001017                          BNE     NNC10           ;BRANCH IF NOT CORRECT.
21023  115032  023727  115060  102345          CMP     @#NNCTB1,#102345   ;IS RESULT CORRECT?
21024  115040  001013                          BNE     NNC10           ;BRANCH IF NOT CORRECT.
21025  115042  023727  115062  177777          CMP     @#NNCTB1+2,#-1  ;IS THE RESULT CORRECT?
21026  115050  001007                          BNE     NNC10           ;BRANCH IF NOT CORRECT.
21027  115052  000407                          BR      NNCDONE
21028
21029                                          ;TEST DATA BUFFER:
21030  115054  177777  177777          NNCTB0: .WORD   -1,-1
21031  115060  177777  177777  177777  NNCTB1: .WORD   -1,-1,-1,-1
21032  115066  177777
21033  115070                          NNC10:
21034  115070  104000                          EMT                     ;
21035
21036  115072                          NNCDONE:
21037  115072  004767  003376                  JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
21038                                                                  ;SEE IF THE USER HAS EXPRESSED
21039                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
21040                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
21041                                                                  ;THE USER TYPED CONTROL G?).
21042
21043
21044                                          ;*************************************************************************************
21045                                          ;TEST 561       DESTINATION MODES, MODE 2 (FL=0), TEST
```

```
21046                                   ;*****************************************************************************
21047  115076                           TS561:
21048
21049
21050  115076  012700  115166                   MOV     #OOCTB0,R0      ;SET UP THE DATA BUFFER.
21051  115102  012701  000006                   MOV     #6,R1
21052  115106  012720  177777           1$:     MOV     #-1,(R0)+
21053  115112  077103                           SOB     R1,1$
21054  115114  012700  105412                   MOV     #105412,R0
21055  115120  012737  115202  000004         MOV     #OOC10,@#ERRVECT  ;SET UP FOR TRAPS TO VECTOR 4.
21056  115126  170100                           LDFPS   R0              ;SET UP FPS.
21057  115130  012700  115172                   MOV     #OOCTB1,R0
21058
21059  115134  170220                   OOC2:   STFPS   (R0)+           ;TEST INSTRUCTION.
21060  115136  020027  115174                   CMP     R0,#OOCTB1+2    ;IS R0 CORRECT?
21061  115142  001017                           BNE     OOC10           ;BRANCH IF NOT CORRECT.
21062  115144  023727  115172  105412         CMP     @#OOCTB1,#105412  ;IS THE RESULT CORRECT?
21063  115152  001013                           BNE     OOC10           ;BRANCH IF NOT CORRECT.
21064  115154  023727  115174  177777         CMP     @#OOCTB1+2,#-1  ;IS THE RESULT CORRECT?
21065  115162  001007                           BNE     OOC10           ;BRANCH IF NOT CORRECT.
21066  115164  000407                           BR      OOCDONE
21067
21068                                   ;TEST DATA BUFFER:
21069  115166  177777  177777           OOCTB0: .WORD   -1,-1
21070  115172  177777  177777  177777   OOCTB1: .WORD   -1,-1,-1,-1
21071  115200  177777
21072  115202                           OOC10:
21073  115202  104000                           EMT                     ;
21074
21075  115204                           OOCDONE:
21076  115204  004767  003264                   JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
21077                                                                   ;SEE IF THE USER HAS EXPRESSED
21078                                                                   ;THE DESIRE TO CHANGE THE SOFTWARE
21079                                                                   ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
21080                                                                   ;THE USER TYPED CONTROL G?).
21081
21082
21083
21084                                   ;*****************************************************************************
21085                                   ;TEST 562       DESTINATION MODES, MODE 4 (FL=0), TEST
21086                                   ;*****************************************************************************
21087  115210                           TS562:
21088
21089  115210  012700  115300                   MOV     #PPCTB0,R0      ;SET UP THE DATA BUFFER.
21090  115214  012701  000006                   MOV     #6,R1
21091  115220  012720  177777           1$:     MOV     #-1,(R0)+
21092  115224  077103                           SOB     R1,1$
21093  115226  012700  105555                   MOV     #105555,R0
21094  115232  012737  115314  000004         MOV     #PPC10,@#ERRVECT  ;SET UP FOR TRAPS TO VECTOR 4.
21095  115240  170100                           LDFPS   R0              ;SET UP FPS.
21096  115242  012700  115306                   MOV     #PPCTB1+2,R0
21097
21098  115246  170240                   PPC2:   STFPS   -(R0)           ;TEST INSTRUCTION.
21099  115250  020027  115304                   CMP     R0,#PPCTB1      ;IS R0 CORRECT?
21100  115254  001017                           BNE     PPC10           ;BRANCH IF NOT CORRECT.
21101  115256  023727  115304  105555         CMP     @#PPCTB1,#105555  ;IS THE RESULT CORRECT?
```

```
21102  115264  001013                          BNE     PPC10           ;BRANCH IF NOT CORRECT.
21103  115266  023727  115306  177777          CMP     @#PPCTB1+2,#-1  ;IS THE RESULT CORRECT?
21104  115274  001007                          BNE     PPC10           ;BRANCH IF NOT CORRECT.
21105  115276  000407                          BR      PPCDONE
21106
21107                                  ;TEST DATA BUFFER:
21108  115300  177777  177777          PPCTB0: .WORD   -1,-1
21109  115304  177777  177777  177777  PPCTB1: .WORD   -1,-1,-1,-1
21110  115312  177777
21111  115314                          PPC10:
21112  115314  104000                          EMT                     ;
21113  115316                          PPCDONE:
21114  115316  004767  003152                  JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
21115                                                                  ;SEE IF THE USER HAS EXPRESSED
21116                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
21117                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
21118                                                                  ;THE USER TYPED CONTROL G?).
21119
21120
21121
21122                                  ;*****************************************************************************
21123                                  ;TEST 563       DESTINATION MODES, MODE 3 (FL=0), TEST
21124                                  ;*****************************************************************************
21125  115322                          TS563:
21126
21127  115322  012700  115416                  MOV     #QQCTB0,R0      ;SET UP THE DATA BUFFER.
21128  115326  012701  000010                  MOV     #10,R1
21129  115332  012720  177777          1$:     MOV     #-1,(R0)+
21130  115336  077103                          SOB     R1,1$
21131  115340  012700  106653                  MOV     #106653,R0
21132  115344  012737  115436  000004          MOV     #QQC10,@#ERRVECT  ;SET UP FOR TRAPS TO VECTOR 4.
21133  115352  170100                          LDFPS   R0              ;SET UP FPS.
21134  115354  012700  115432                  MOV     #QQCTB2,R0
21135  115360  012710  115422                  MOV     #QQCTB1,(R0)
21136
21137  115364  170230                  QQC2:   STFPS   @(R0)+          ;TEST INSTRUCTION.
21138  115366  020027  115434                  CMP     R0,#QQCTB2+2    ;IS R0 CORRECT?
21139  115372  001021                          BNE     QQC10           ;BRANCH IF NOT CORRECT.
21140  115374  023727  115422  106653          CMP     @#QQCTB1,#106653  ;IS THE RESULT CORRECT?
21141  115402  001015                          BNE     QQC10           ;BRANCH IF NOT CORRECT.
21142  115404  023727  115432  115422          CMP     @#QQCTB2,#QQCTB1  ;IS THE RESULT CORRECT?
21143  115412  001011                          BNE     QQC10           ;BRANCH IF NOT CORRECT.
21144  115414  000411                          BR      QQCDONE
21145
21146                                  ;TEST DATA BUFFER:
21147  115416  177777  177777          QQCTB0: .WORD   -1,-1
21148  115422  177777  177777  177777  QQCTB1: .WORD   -1,-1,-1,-1
21149  115430  177777
21150  115432  177777  177777          QQCTB2: .WORD   -1,-1
21151  115436                          QQC10:
21152  115436  104000                          EMT                     ;
21153  115440                          QQCDONE:
21154  115440  004767  003030                  JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
21155                                                                  ;SEE IF THE USER HAS EXPRESSED
21156                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
21157                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
```

```
                                                        ;THE USER TYPED CONTROL G?).


                                        ;*****************************************************************************************
                                        ;TEST 564       DESTINATION MODES, MODE 5 (FL=0), TEST
                                        ;*****************************************************************************************
115444                                  TS564:

115444  012700  115542                          MOV     #RRCTB0,R0      ;SET UP THE DATA BUFFER.
115450  012701  000006                          MOV     #6,R1
115454  012720  177777                  1$:     MOV     #-1,(R0)+
115460  077103                                  SOB     R1,1$
115462  012700  004301                          MOV     #004301,R0
115466  012737  115562  000004                  MOV     #RRC10,@#ERRVECT  ;SET UP FOR TRAPS TO VECTOR 4.
115474  170100                                  LDFPS   R0              ;SET UP FPS.
115476  012700  115560                          MOV     #RRCTB2+2,R0
115502  012760  115546  177776                  MOV     #RRCTB1,-2(R0)

115510  170250                          RRC2:   STFPS   @-(R0)          ;TEST INSTRUCTION.
115512  020027  115556                          CMP     R0,#RRCTB2      ;IS R0 CORRECT?
115516  001021                                  BNE     RRC10           ;BRANCH IF NOT CORRECT.
115520  023727  115546  004301                  CMP     @#RRCTB1,#004301  ;IS THE RESULT CORRECT?
115526  001015                                  BNE     RRC10           ;BRANCH IF NOT CORRECT.
115530  023727  115556  115546                  CMP     @#RRCTB2,#RRCTB1  ;IS THE RESULT CORRECT?
115536  001011                                  BNE     RRC10           ;BRANCH IF NOT CORRECT.
115540  000411                                  BR      RRCDONE

                                        ;TEST DATA BUFFER:
115542  177777  177777                  RRCTB0: .WORD   -1,-1
115546  177777  177777  177777          RRCTB1: .WORD   -1,-1,-1,-1
115554  177777
115556  177777  177777                  RRCTB2: .WORD   -1,-1
115562                                  RRC10:
115562  104000                                  EMT                     ;
115564                                  RRCDONE:
115564  004767  002704                          JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
                                                                        ;SEE IF THE USER HAS EXPRESSED
                                                                        ;THE DESIRE TO CHANGE THE SOFTWARE
                                                                        ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
                                                                        ;THE USER TYPED CONTROL G?).


                                        ;*****************************************************************************************
                                        ;TEST 565       DESTINATION MODES, MODE 6 (FL=0), TEST
                                        ;*****************************************************************************************
115570                                  TS565:

115570  012700  115672                          MOV     #SSCTB0,R0      ;SET UP THE DATA BUFFER.
115574  012701  000006                          MOV     #6,R1
115600  012720  177777                  1$:     MOV     #-1,(R0)+
115604  077103                                  SOB     R1,1$
115606  012700  102514                          MOV     #102514,R0
115612  012737  115706  000004                  MOV     #SSC10,@#ERRVECT  ;SET UP FOR TRAPS TO VECTOR 4.
```

```
21214  115620  170100                  LDFPS   R0              ;SET UP FPS.
21215  115622  005001                  CLR     R1
21216  115624  012700  110475          MOV     #SSCTB1-5201,R0
21217
21218  115630  170260  005201  SSC2:   STFPS   5201(R0)                ;TEST INSTRUCTION.
21219  115634  020127  000000          CMP     R1,#0           ;WAS PC CORRECT AFTER EXECUTION?
21220  115640  001022                  BNE     SSC10           ;BRANCH IF NOT CORRECT.
21221  115642  020027  110475          CMP     R0,#SSCTB1-5201 ;IS R0 CORRECT?
21222  115646  001017                  BNE     SSC10           ;BRANCH IF NOT CORRECT.
21223  115650  023727  115676  102514  CMP     @#SSCTB1,#102514  ;IS THE RESULT CORRECT?
21224  115656  001013                  BNE     SSC10           ;BRANCH IF NOT CORRECT.
21225  115660  023727  115700  177777  CMP     @#SSCTB1+2,#-1  ;IS THE RESULT CORRECT?
21226  115666  001007                  BNE     SSC10           ;BRANCH IF NOT CORRECT.
21227  115670  000407                  BR      SSCDONE
21228
21229                          ;TEST DATA BUFFER:
21230  115672  177777  177777  SSCTB0: .WORD   -1,-1
21231  115676  177777  177777  177777  SSCTB1: .WORD   -1,-1,-1,-1
21232  115704  177777
21233  115706                  SSC10:
21234  115706  104000                  EMT                     ;
21235  115710                  SSCDONE:
21236  115710  004767  002560          JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
21237                                                          ;SEE IF THE USER HAS EXPRESSED
21238                                                          ;THE DESIRE TO CHANGE THE SOFTWARE
21239                                                          ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
21240                                                          ;THE USER TYPED CONTROL G?).
21241
21242
21243                          ;*****************************************************************************************
21244                          ;TEST 566       DESTINATION MODES, MODE 7 (FL=0), TEST
21245                          ;*****************************************************************************************
21246  115714                  TS566:
21247
21248  115714  012700  116024          MOV     #TTCTB0,R0      ;SET UP THE DATA BUFFER.
21249  115720  012701  000010          MOV     #10,R1
21250  115724  012720  177777  1$:     MOV     #-1,(R0)+
21251  115730  077103                  SOB     R1,1$
21252  115732  012700  103747          MOV     #103747,R0
21253  115736  012737  116044  000004  MOV     #TTC10,@#ERRVECT  ;SET UP FOR TRAPS TO VECTOR 4.
21254  115744  170100                  LDFPS   R0              ;SET UP FPS.
21255  115746  005001                  CLR     R1
21256  115750  012700  110637          MOV     #TTCTB2-5201,R0
21257  115754  012760  116030  005201  MOV     #TTCTB1,5201(R0)
21258
21259  115762  170270  005201  TTC2:   STFPS   @5201(R0)               ;TEST INSTRUCTION.
21260  115766  022701  000000          CMP     #0,R1           ;WAS PC CORRECT AFTER EXECUTION?
21261  115772  001024                  BNE     TTC10           ;BRANCH IF NOT CORRECT.
21262  115774  020027  110637          CMP     R0,#TTCTB2-5201 ;IS R0 CORRECT?
21263  116000  001021                  BNE     TTC10           ;BRANCH IF NOT CORRECT.
21264  116002  023727  116030  103747  CMP     @#TTCTB1,#103747  ;IS THE RESULT CORRECT?
21265  116010  001015                  BNE     TTC10           ;BRANCH IF NOT CORRECT.
21266  116012  023727  116032  177777  CMP     @#TTCTB1+2,#-1  ;IS THE RESULT CORRECT?
21267  116020  001011                  BNE     TTC10           ;BRANCH IF NOT CORRECT.
21268  116022  000411                  BR      TTCDONE
21269
```

```
21270                                   ;TEST DATA BUFFER:
21271  116024  177777  177777           TTCTB0: .WORD   -1,-1
21272  116030  177777  177777  177777   TTCTB1: .WORD   -1,-1,-1,-1
21273  116036  177777
21274  116040  177777  177777           TTCTB2: .WORD   -1,-1
21275  116044                          TTC10:
21276  116044  104000                          EMT                     ;
21277  116046                          TTCDONE:
21278  116046  004767  002422                  JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
21279                                                                  ;SEE IF THE USER HAS EXPRESSED
21280                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
21281                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
21282                                                                  ;THE USER TYPED CONTROL G?).
21283
21284                                   ;*****************************************************************************
21285                                   ;TEST 567       DESTINATION MODES, MODE 2 (FL=1), TEST
21286                                   ;*****************************************************************************
21287  116052                          TS567:
21288  116052  012700  000300                  MOV     #300,R0         ;SET UP FPS.
21289  116056  170100                          LDFPS   R0
21290  116060  012700  116104                  MOV     #UUCTP1,R0      ;SET UP THE AC0 OPERAND.
21291  116064  172410                          LDD     (R0),AC0
21292  116066  012700  116116                  MOV     #UUCBF0,R0
21293
21294  116072  175420                  UUC2:   STCDL   AC0,(R0)+       ;TEST INSTRUCTION.
21295
21296  116074  020027  116122                  CMP     R0,#UUCBF0+4    ;IS R0 CORRECT?
21297  116100  001411                          BEQ     UUCDONE
21298  116102  104000                          EMT                     ;
21299                                  ;TEST DATA BUFFER:
21300  116104  000000  000000  000000  UUCTP1: .WORD   0,0,0,0
21301  116112  000000
21302  116114  177777                          -1
21303  116116  177777  177777  177777  UUCBF0: .WORD   -1,-1,-1
21304
21305  116124                          UUCDONE:
21306  116124  004767  002344                  JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
21307                                                                  ;SEE IF THE USER HAS EXPRESSED
21308                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
21309                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
21310                                                                  ;THE USER TYPED CONTROL G?).
21311
21312                                   ;*****************************************************************************
21313                                   ;TEST 570       DESTINATION MODES, MODE 4 (FL=1), TEST
21314                                   ;*****************************************************************************
21315  116130                          TS570:
21316
21317  116130  012700  000300                  MOV     #300,R0         ;SET UP FPS.
21318  116134  170100                          LDFPS   R0
21319  116136  012700  116162                  MOV     #VVCTP1,R0      ;SET UP THE AC0 OPERAND.
21320  116142  172410                          LDD     (R0),AC0
21321  116144  012700  116200                  MOV     #VVCBF0+4,R0
21322
21323  116150  175440                  VVC2:   STCDL   AC0,-(R0)               ;TEST INSTRUCTION.
21324
21325  116152  020027  116174                  CMP     R0,#VVCBF0      ;IS R0 CORRECT?
```

```
21326  116156  001411                          BEQ     VVCDONE
21327  116160  104000                          EMT                             ;
21328                                  ;TEST DATA BUFFER:
21329  116162  000000  000000  000000  VVCTP1: .WORD   0,0,0,0
21330  116170  000000
21331  116172  177777                          -1
21332  116174  177777  177777  177777  VVCBF0: .WORD   -1,-1,-1
21333
21334  116202                          VVCDONE:
21335  116202  004767  002266                  JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
21336                                                                  ;SEE IF THE USER HAS EXPRESSED
21337                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
21338                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
21339                                                                  ;THE USER TYPED CONTROL G?).
21340
21341                                  ;*****************************************************************************
21342                                  ;TEST 571       STCDI AND STCDL TEST
21343                                  ;*****************************************************************************
21344  116206                          TS571:
21345
21346                                  ;FIRST TEST STC WITH EXP=100 (EXCESS 200)
21347  116206  004737  117144          WWC1:   JSR     PC,@#STCSUB     ;GO EXECUTE THE INSTRUCTION.
21348  116212  020000  000000  000000  1$:     .WORD   20000,0,0,0     ;AC0 OPERAND.
21349  116220  000000
21350  116222  000000  000000          2$:     .WORD   0,0             ;EXPECTED RESULT.
21351  116226  177777  177777          3$:     .WORD   -1,-1           ;ERROR RES.
21352  116232  040300                  4$:     40300                   ;FPS BEFORE EXECUTION.
21353  116234  040304                          40304                   ;FPS AFTER EXECUTION.
21354  116236  140304                          140304                  ;ANTICIPATED ERRONEOUS FPS.
21355  116240  177777                          -1              ;REPORT RESULT INCORRECT.
21356                                  ;EXP=0 (OCT)    FL=1    FIC=0
21357  116242  004737  117144          WWC2:   JSR     PC,@#STCSUB     ;GO EXECUTE THE INSTRUCTION.
21358  116246  040000  000000  000000  1$:     .WORD   40000,0,0,0     ;AC     ;AC0 OPERAND.
21359  116254  000000
21360  116256  000000  000000          2$:     .WORD   0,0             ;EXPECTED RESULT.
21361  116262  177777  177777          3$:     .WORD   -1,-1           ;ANTICIPATED ERRONEOUS RESULT.
21362  116266  040313                  4$:     40313                   ;FPS BEFORE EXECUTION.
21363  116270  040304                          40304                   ;FPS AFTER EXECUTION.
21364  116272  140304                          140304                  ;ANTICIPATED ERRONEOUS FPS.
21365  116274  177777                          -1              ;EXPECTED FEC.
21366                                  ;EXP=37 (OCT)   FL=1    FIC=1
21367  116276  004737  117144          WWC3:   JSR     PC,@#STCSUB     ;GO EXECUTE THE INSTRUCTION.
21368  116302  047667  075757  157737  1$:     .WORD   47667,75757,157737,167773       ;AC0 OPERAND.
21369  116310  167773
21370  116312  055675  173757          2$:     .WORD   55675,173757            ;EXPECTED RESULT.
21371  116316  122102  004021          3$:     .WORD   122102,004021           ;ANTICIPATED ERRONEOUS RESULT.
21372  116322  040717                  4$:     40717                   ;FPS BEFORE EXECUTION.
21373  116324  040700                          40700                   ;FPS AFTER EXECUTION.
21374  116326  140705                          140705                  ;ANTICIPATED ERRONEOUS FPS.
21375  116330  177777                          -1              ;EXPECTED FEC.
21376                                  ;EXP=40 (OCT)   FL=1    FIC=1
21377  116332  004737  117144          WWC4:   JSR     PC,@#STCSUB     ;GO EXECUTE THE INSTRUCTION.
21378  116336  050000  000000  000000  1$:     .WORD   50000,0,0,0     ;AC0 OPERAND.
21379  116344  000000
21380  116346  000000  000000          2$:     .WORD   0,0             ;EXPECTED RESULT.
21381  116352  177777  177777          3$:     .WORD   -1,-1           ;ANTICIPATED ERRONEOUS RESULT.
```

```
21382  116356  040700                  4$:     40700                   ;FPS BEFORE EXECUTION.
21383  116360  140705                          140705                  ;FPS AFTER EXECUTION.
21384  116362  040705                          40705                   ;ANTICIPATED ERRONEOUS FPS.
21385  116364  000006                          6               ;EXPECTED FEC.
21386
21387                                  ;EXP=40 (OCT)   FL=1    FIC=0
21388  116366  004737  117144          WWC5:   JSR     PC,@#STCSUB     ;GO EXECUTE THE INSTRUCTION.
21389  116372  050000  000000  000000  1$:     .WORD   50000,0,0,0     ;ACO OPERAND.
21390  116400  000000
21391  116402  000000  000000          2$:     .WORD   0,0             ;EXPECTED RESULT.
21392  116406  177777  177777          3$:     .WORD   -1,-1           ;ANTICIPATED ERRONEOUS RESULT.
21393  116412  040312                  4$:     40312                   ;FPS BEFORE EXECUTION.
21394  116414  040305                          40305                   ;FPS AFTER EXECUTION.
21395  116416  140305                          140305                  ;ANTICIPATED ERRONEOUS FPS.
21396  116420  177777                          -1              ;EXPECTED FEC.
21397                                  ;EXP=30 (OCT)   FL=1    FIC=1
21398  116422  004737  117144          WWC6:   JSR     PC,@#STCSUB     ;GO EXECUTE THE INSTRUCTION.
21399  116426  046000  000001  000000  1$:     .WORD   46000,1,0,0     ;ACO OPERAND.
21400  116434  000000
21401  116436  000200  000001          2$:     .WORD   200,1           ;EXPECTED RESULT.
21402  116442  177777  177777          3$:     .WORD   -1,-1           ;ANTICIPATED ERRONEOUS RESULT.
21403  116446  040700                  4$:     40700                   ;FPS BEFORE EXECUTION.
21404  116450  040700                          40700                   ;FPS AFTER EXECUTION.
21405  116452  177777                          -1                      ;ANTICIPATED ERRONEOUS FPS.
21406  116454  177777                          -1              ;EXPECTED FEC.
21407                                  ;EXP=27 (OCT)   FL=1    FIC=1
21408  116456  004737  117144          WWC7:   JSR     PC,@#STCSUB     ;GO EXECUTE THE INSTRUCTION.
21409  116462  045600  000001  000000  1$:     .WORD   45600,1,0,0     ;ACO OPERAND.
21410  116470  000000
21411  116472  000100  000000          2$:     .WORD   100,0           ;EXPECTED RESULT.
21412  116476  177777  177777          3$:     .WORD   -1,-1           ;ANTICIPATED ERRONEOUS RESULT.
21413  116502  040707                  4$:     40707                   ;FPS BEFORE EXECUTION.
21414  116504  040700                          40700                   ;FPS AFTER EXECUTION.
21415  116506  177777                          -1                      ;ANTICIPATED ERRONEOUS FPS.
21416  116510  177777                          -1              ;EXPECTED FEC.
21417                                  ;EXP=17 (OCT)   FL=0    FIC=1
21418  116512  004737  117144          WWC10:  JSR     PC,@#STCSUB     ;GO EXECUTE THE INSTRUCTION.
21419  116516  043600  000000  000000  1$:     .WORD   43600,0,0,0     ;ACO OPERAND.
21420  116524  000000
21421  116526  040000  177777          2$:     .WORD   40000,-1                ;EXPECTED RESULT.
21422  116532  000000  177777          3$:     .WORD   0,-1            ;ANTICIPATED ERRONEOUS RESULT.
21423  116536  040600                  4$:     40600                   ;FPS BEFORE EXECUTION.
21424  116540  040600                          40600                   ;FPS AFTER EXECUTION.
21425  116542  140604                          140604                  ;ANTICIPATED ERRONEOUS FPS.
21426  116544  177777                          -1              ;EXPECTED FEC.
21427
21428                                  ;EXP=20 (OCT)   FL=0    FIC=1
21429  116546  004737  117144          WWC11:  JSR     PC,@#STCSUB     ;GO EXECUTE THE INSTRUCTION.
21430  116552  044000  000000  000000  1$:     .WORD   44000,0,0,0     ;ACO OPERAND.
21431  116560  000000
21432  116562  000000  177777          2$:     .WORD   0,-1            ;EXPECTED RESULT.
21433  116566  177777  177777          3$:     .WORD   -1,-1           ;ANTICIPATED ERRONEOUS RESULT.
21434  116572  040600                  4$:     40600                   ;FPS BEFORE EXECUTION.
21435  116574  140605                          140605                  ;FPS AFTER EXECUTION.
21436  116576  040600                          40600                   ;ANTICIPATED ERRONEOUS FPS.
21437  116600  000006                          6               ;EXPECTED FEC.
```

```
21438                                   ;EXP=10 (OCT), AC NEGATIVE, FL=0, FIC=1
21439  116602  004737  117144           WWC12:  JSR     PC,@#STCSUB     ;GO EXECUTE THE INSTRUCTION.
21440  116606  142000  000000  000000   1$:     .WORD   142000,0,0,0    ;AC0 OPERAND.
21441  116614  000000
21442  116616  177600  177777           2$:     .WORD   177600,-1               ;EXPECTED RESULT.
21443  116622  000200  000000           3$:     .WORD   200,0           ;ANTICIPATED ERRONEOUS RESULT.
21444  116626  040600                   4$:     40600                   ;FPS BEFORE EXECUTION.
21445  116630  040610                           40610                   ;FPS AFTER EXECUTION.
21446  116632  040600                           40600                   ;ANTICIPATED ERRONEOUS FPS.
21447  116634  177777                           -1              ;EXPECTED FEC.
21448                                   ;EXP=37 (OCT), FL=1, FIC=1, AC NEG.
21449  116636  004737  117144           WWC13:  JSR     PC,@#STCSUB     ;GO EXECUTE THE INSTRUCTION.
21450  116642  147600  000000  000000   1$:     .WORD   147600,0,0,0    ;AC0 OPERAND.
21451  116650  000000
21452  116652  140000  000000           2$:     .WORD   140000,0                ;EXPECTED RESULT.
21453  116656  137777  000000           3$:     .WORD   137777,0                ;ANTICIPATED ERRONEOUS RESULT.
21454  116662  040700                   4$:     40700                   ;FPS BEFORE EXECUTION.
21455  116664  040710                           40710                   ;FPS AFTER EXECUTION.
21456  116666  177777                           -1                      ;ANTICIPATED ERRONEOUS FPS.
21457  116670  177777                           -1              ;EXPECTED FEC.
21458                                   ;EXP=37  (OCT),  FL=1,  FIC=1,  AC  NEG
21459  116672  004737  117144           WWC14:  JSR     PC,@#STCSUB     ;GO EXECUTE THE INSTRUCTION.
21460  116676  147600  000000  001000   1$:     .WORD   147600,0,1000,0 ;AC0 OPERAND.
21461  116704  000000
21462  116706  137777  177777           2$:     .WORD   137777,177777           ;EXPECTED RESULT.
21463  116712  140000  177777           3$:     .WORD   140000,177777           ;ANTICIPATED ERRONEOUS RESULT.
21464  116716  040707                   4$:     40707                   ;FPS BEFORE EXECUTION.
21465  116720  040710                           40710                   ;FPS AFTER EXECUTION.
21466  116722  177777                           -1                      ;ANTICIPATED ERRONEOUS FPS.
21467  116724  177777                           -1              ;EXPECTED FEC.
21468                                   ;EXP=41 (OCT),  AC NEG, FL=1, FIC=1
21469  116726  004737  117144           WWC15:  JSR     PC,@#STCSUB     ;GO EXECUTE THE INSTRUCTION.
21470  116732  150200  000000  000000   1$:     .WORD   150200,0,0,0    ;AC0 OPERAND.
21471  116740  000000
21472  116742  000000  000000           2$:     .WORD   0,0                     ;EXPECTED RESULT.
21473  116746  177777  177777           3$:     .WORD   -1,-1           ;ANTICIPATED ERRONEOUS RESULT.
21474  116752  040700                   4$:     40700                   ;FPS BEFORE EXECUTION.
21475  116754  140705                           140705                  ;FPS AFTER EXECUTION.
21476  116756  177777                           -1                      ;ANTICIPATED ERRONEOUS FPS.
21477  116760  000006                           6               ;EXPECTED FEC.
21478                                   ;EXP=40 (OCT),  AC NEG,  FL=1,  FIC=1
21479  116762  004737  117144           WWC16:  JSR     PC,@#STCSUB     ;GO EXECUTE THE INSTRUCTION.
21480  116766  150000  000001  000000   1$:     .WORD   150000,1,0,0    ;AC0 OPERAND.
21481  116774  000000
21482  116776  000000  000000           2$:     .WORD   0,0                     ;EXPECTED RESULT.
21483  117002  100000  177600           3$:     .WORD   100000,-200                     ;ANTICIPATED ERRONEOUS RESULT.
21484  117006  040700                   4$:     40700                   ;FPS BEFORE EXECUTION.
21485  117010  140705                           140705                  ;FPS AFTER EXECUTION.
21486  117012  040700                           40700                   ;ANTICIPATED ERRONEOUS FPS.
21487  117014  000006                           6               ;EXPECTED FEC.
21488                                   ;EXP=40, AC NEGATIVE, FL=1, FIC=1
21489  117016  004737  117144           WWC17:  JSR     PC,@#STCSUB     ;GO EXECUTE THE INSTRUCTION.
21490  117022  150001  000000  000000   1$:     .WORD   150001,0,0,0    ;AC0 OPERAND.
21491  117030  000000
21492  117032  000000  000000           2$:     .WORD   0,0                     ;EXPECTED RESULT.
21493  117036  077400  000000           3$:     .WORD   77400,0                 ;ANTICIPATED ERRONEOUS RESULT.
```

```
21494  117042  040700                          4$:     40700                   ;FPS BEFORE EXECUTION.
21495  117044  140705                                  140705                  ;FPS AFTER EXECUTION.
21496  117046  177777                                  -1                      ;ANTICIPATED ERRONEOUS FPS.
21497  117050  000006                                  6                               ;EXPECTED FEC.
21498                                          ;EXP 40    (OCT), AC MOST NEG LONG INT, FL=1
21499                                          ;FIC=1
21500  117052  004737  117144                  WWC20:  JSR     PC,@#STCSUB     ;GO EXECUTE THE INSTRUCTION.
21501  117056  150000  000000  000000          1$:     .WORD   150000,0,0,0    ;AC0 OPERAND.
21502  117064  000000
21503  117066  100000  000000                  2$:     .WORD   100000,0                ;EXPECTED RESULT.
21504  117072  000000  000000                  3$:     .WORD   0,0             ;ANTICIPATED ERRONEOUS RESULT.
21505  117076  040700                          4$:     40700                           ;FPS BEFORE EXECUTION.
21506  117100  040710                                  40710                   ;FPS AFTER EXECUTION.
21507  117102  140705                                  140705                  ;ANTICIPATED ERRONEOUS FPS.
21508  117104  177777                                  -1                              ;EXPECTED FEC.
21509                                          ;EXP=20, AC = MOST NEG INTEGER, FL=0, FIC=1
21510
21511  117106  004737  117144                  WWC21:  JSR     PC,@#STCSUB     ;GO EXECUTE THE INSTPUCTION.
21512  117112  144000  000001  000000          1$:     .WORD   144000,1,0,0    ;AC0 OPERAND.
21513  117120  000000
21514  117122  100000  177777                  2$:     .WORD   100000,-1               ;EXPECTED RESULT.
21515  117126  100000  177400                  3$:     .WORD   100000,177400           ;ANTICIPATED ERRONEOUS RESULT.
21516  117132  040600                          4$:     40600                   ;FPS BEFORE EXECUTION.
21517  117134  040610                                  40610                   ;FPS AFTER EXECUTION.
21518  117136  140605                                  140605                  ;ANTICIPATED ERRONEOUS FPS.
21519  117140  177777                                  -1                              ;EXPECTED FEC.
21520  117142  000457                          6$:     BR      WWCDONE
21521
21522                                          ;THIS SUBROUTINE, STCSUB, IS USED TO SET UP THE OPERANDS, EXECUTE
21523                                          ;THE STCDI OR STCDL INSTRUCTION AND CHECK THE RESULTS. A CALL
21524                                          ;TO IT IS MADE THUS:
21525                                          ;
21526                                          ;               JSR     PC,@#STCSUB
21527                                          ;               ACARG:  .WORD   X,X,X,X         ;AC OPERAND
21528                                          ;               RES:    .WORD   X,X             ;EXPECTED RESULT
21529                                          ;               ERRES:  .WORD   X,X             ;ERROR RESULT
21530                                          ;               FPSB:   .WORD   X               ;FPS BEFORE EXECUTION
21531                                          ;               FPSA:   .WORD   X               ;FPS AFTER EXECUTION
21532                                          ;               ERFPS:  .WORD   X               ;ERROR FPS.
21533                                          ;               FEC:    .WORD   X               ;EXPECTED FEC
21534                                          ;               ERR1:   ERROR   X               ;DATA ERROR.
21535                                          ;                       BR      CONT
21536                                          ;               ERR2:   ERROR   X               ;FPS ERROR.
21537                                          ;               CONT:                           ;RETURN ADDRESS
21538
21539                                          ;THE OPERANDS ARE SET UP (USING AC0 AS THE ACCUMULATOR). THEN
21540                                          ;THE STCDI OR STCDL INSTRUCTION IS EXECUTED.
21541                                          ;THE RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS
21542                                          ;COMPARED WITH FPSA IF THIS TOO IS CORRECT STCSUB RETURNS CONTROL
21543                                          ;TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD STCSUB
21544                                          ;COMPARE IT TO ERROR FPS. IF THIS MATCHES THEN STCSUB WILL RETURN
21545                                          ;TO THE ERROR CALL AT ERR2, OTHERWISE STCSUB ITSELF
21546                                          ;REPORTS THIS FAILURE AND THEN RETURNS TO CONT. IF THE RESULT OF THE
21547                                          ;STCDI OR STCDL IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE
21548                                          ;ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN
21549                                          ;THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN STCSUB
```

```
21550                                   ;WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR1. OTHERWISE THE
21551                                   ;RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND STCSUB WILL
21552                                   ;REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.
21553
21554  117144  012601                   STCSUB: MOV     (SP)+,R1        ;GET A POINTER TO THE ARGUMENTS.
21555  117146  012700  000200                   MOV     #200,R0         ;SET UP THE AC0 OPERAND.
21556  117152  170100                           LDFPS   R0
21557  117154  010100                           MOV     R1,R0
21558  117156  172410                           LDD     (R0),AC0
21559  117160  012702  117272                   MOV     #STCIBF,R2      ;INITIALIZE THE OUT PUT BUFFER.
21560  117164  012700  000004                   MOV     #4,R0
21561  117170  012722  177777           1$:     MOV     #-1,(R2)+
21562  117174  077003                           SOB     R0,1$
21563  117176  016100  000020                   MOV     20(R1),R0       ;SET THE FPS.
21564  117202  170100                           LDFPS   R0
21565  117204  012700  117272                   MOV     #STCIBF,R0
21566  117210  175410                   2$:     STCDL   AC0,(R0)        ;TEST INSTRUCTION.
21567
21568  117212  170204                           STFPS   R4              ;GET THE FPS.
21569  117214  170305                           STST    R5              ;GET THE FEC.
21570  117216  010102                           MOV     R1,R2
21571  117220  062702  000010                   ADD     #10,R2
21572  117224  012700  117272                   MOV     #STCIBF,R0      ;SEE IF THE RESULT IS CORRECT.
21573  117230  012703  000002                   MOV     #2,R3
21574  117234  022022                   3$:     CMP     (R0)+,(R2)+
21575  117236  001014                           BNE     10$
21576  117240  077303                           SOB     R3,3$
21577  117242  016102  000022                   MOV     22(R1),R2
21578  117246  020204                           CMP     R2,R4           ;SEE IF THE FPS IS CORRECT.
21579  117250  001007                           BNE     10$             ;BRANCH IF INCORRECT.
21580  117252  005702                           TST     R2
21581  117254  100003                           BPL     4$
21582  117256  026105  000026                   CMP     26(R1),R5       ;SEE IF THE FEC IS CORRECT.
21583  117262  001002                           BNE     10$             ;BRANCH IF INCORRECT.
21584
21585  117264  000161  000030           4$:     JMP     30(R1)          ;RETURN.
21586  117270                           10$:
21587  117270  104000                           EMT                     ;
21588
21589                                   ;DATA BUFFER:
21590  117272  177777  177777  177777 STCIBF: .WORD   -1,-1,-1,-1
21591  117300  177777
21592
21593  117302                           WWCDONE:
21594  117302  004767  001166                   JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
21595                                                                   ;SEE IF THE USER HAS EXPRESSED
21596                                                                   ;THE DESIRE TO CHANGE THE SOFTWARE
21597                                                                   ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
21598                                                                   ;THE USER TYPED CONTROL G?).
21599
21600
21601                                   ;******************************************************************************
21602                                   ;TEST 572       STCFL AND STCFI TEST
21603                                   ;******************************************************************************
21604  117306                           TS572:
21605
```

```
21606
21607                                   ;EXPONENT=37, FL=1
21608  117306  004737  117144                   JSR     PC,@#STCSUB     ;GO EXECUTE THE INSTRUCTION.
21609  117312  047777  177777  177777  1$:      .WORD   47777,-1,-1,-1  ;AC0 OPERAND.
21610  117320  177777
21611  117322  077777  177600          2$:      .WORD   77777,177600            ;EXPECTED RESULT.
21612  117326  077777  177777          3$:      .WORD   77777,177777            ;ANTICIPATED ERRONEOUS RESULT.
21613  117332  040100                  4$:      40100                   ;FPS BEFORE EXECUTION.
21614  117334  040100                           40100                   ;FPS AFTER EXECUTION.
21615  117336  177777                           -1                      ;ANTICIPATED ERRONEOUS FPS.
21616  117340  177777                           -1              ;EXPECTED FEC.
21617  117342                          XXCDONE:
21618  117342  004767  001126                   JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
21619                                                                   ;SEE IF THE USER HAS EXPRESSED
21620                                                                   ;THE DESIRE TO CHANGE THE SOFTWARE
21621                                                                   ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
21622                                                                   ;THE USER TYPED CONTROL G?).
21623
21624
21625                                   ;*******************************************************************************
21626                                   ;TEST 573       STEXP TEST
21627                                   ;*******************************************************************************
21628  117346                          TS573:
21629
21630                                   ; EXP = 100 (EXCESS 200)
21631  117346  004737  117554          YYC1:   JSR     PC,@#STXSUB
21632  117352  020000  000000  000000  1$:     .WORD   20000,0,0,0                     ;AC
21633  117360  000000
21634  117362  177700                  2$:     -100                            ;EXP RES
21635  117364  052525                  3$:     52525                           ;ERROR EXP.
21636  117366  040000                  4$:     40000                           ;FPSB
21637  117370  040010                          40010                           ;FPSA
21638  117372  040000                          40000                           ;ERROR FPS
21639                                   ; EXP = 200 (EXCESS 200)
21640  117374  004737  117554          YYC2:   JSR     PC,@#STXSUB     ;GO EXECUTE THE INSTRUCTION.
21641  117400  040000  000000  000000  1$:     .WORD   40000,0,0,0     ;AC0 OPERAND.
21642  117406  000000
21643  117410  000000                  2$:     0                       ;EXPECTED EXPONENT RESULT.
21644  117412  052525                  3$:     52525           ;ANTICIPATED ERRONEOUS RESULT.
21645  117414  040000                  4$:     40000                   ;FPS BEFORE EXECUTION.
21646  117416  040004                          40004                   ;FPS AFTER EXECUTION.
21647  117420  040000                          40000                   ;ANTICIPATED ERRONEOUS FPS.
21648                                   ; EXP = 201 (EXCESS 200)
21649  117422  004737  117554          YYC3:   JSR     PC,@#STXSUB     ;GO EXECUTE THE INSTRUCTION.
21650  117426  040200  000000  000000  1$:     .WORD   40200,0,0,0     ;AC0 OPERAND.
21651  117434  000000
21652  117436  000001                  2$:     1                       ;EXPECTED EXPONENT RESULT.
21653  117440  052525                  3$:     52525           ;ANTICIPATED ERRONEOUS RESULT.
21654  117442  040000                  4$:     40000                   ;FPS BEFORE EXECUTION.
21655  117444  040000                          40000                   ;FPS AFTER EXECUTION.
21656  117446  040004                          40004                   ;ANTICIPATED ERRONEOUS FPS.
21657                                   ; EXP = 375  (EXCESS 200)
21658
21659  117450  004737  117554          YYC4:   JSR     PC,@#STXSUB     ;GO EXECUTE THE INSTRUCTION.
21660  117454  077200  000000  000000  1$:     .WORD   77200,0,0,0     ;AC0 OPERAND.
21661  117462  000000
```

```
CJKDE-B  11/24 CPU CLUSTER DIAG.        MACY11 30(1046)  05-AUG-82  15:03  PAGE 396
CJKDEB.P11     05-AUG-82 15:01          T573    STEXP TEST

 21662  117464  000175                  2$:     175                     ;EXPECTED EXPONENT RESULT.
 21663  117466  052525                  3$:     52525           ;ANTICIPATED ERRONEOUS RESULT.
 21664  117470  040000                  4$:     40000                   ;FPS BEFORE EXECUTION.
 21665  117472  040000                          40000                   ;FPS AFTER EXECUTION.
 21666  117474  040010                          40010                   ;ANTICIPATED ERRONEOUS FPS.
 21667                                  ; EXP = 1  (EXCESS 200)
 21668
 21669  117476  004737  117554          YYC5:   JSR     PC,@#STXSUB     ;GO EXECUTE THE INSTRUCTION.
 21670  117502  000200  000000  000000  1$:     .WORD   200,0,0,0       ;AC0 OPERAND.
 21671  117510  000000
 21672  117512  177601                  2$:     -177                    ;EXPECTED EXPONENT RESULT.
 21673  117514  052525                  3$:     52525           ;ANTICIPATED ERRONEOUS RESULT.
 21674  117516  040000                  4$:     40000                   ;FPS BEFORE EXECUTION.
 21675  117520  040010                          40010                   ;FPS AFTER EXECUTION.
 21676  117522  040000                          40000                   ;ANTICIPATED ERRONEOUS FPS.
 21677                                  ; EXP = 156  (EXCESS 200)
 21678
 21679  117524  004737  117554          YYC6:   JSR     PC,@#STXSUB     ;GO EXECUTE THE INSTPUCTION.
 21680  117530  033400  000000  000000  1$:     .WORD   33400,0,0,0     ;AC0 OPERAND.
 21681  117536  000000
 21682  117540  177756                  2$:     -22                     ;EXPECTED EXPONENT RESULT.
 21683  117542  052525                  3$:     52525           ;ANTICIPATED ERRONEOUS RESULT.
 21684  117544  047707                  4$:     47707                   ;FPS BEFORE EXECUTION.
 21685  117546  047710                          47710                   ;FPS AFTER EXECUTION.
 21686  117550  177777                          -1                      ;ANTICIPATED ERRONEOUS FPS.
 21687  117552  000452                          BR      YYCDONE
 21688
 21689                                  ;THIS SUBROUTINE, STXSUB, IS USED TO SET UP THE OPERANDS, EXECUTE
 21690                                  ;THE STEXP INSTRUCTION AND CHECK THE RESULTS. A CALL
 21691                                  ;TO IT IS MADE THUS:
 21692                                  ;
 21693                                  ;               JSR     PC,@#STXSUB
 21694                                  ;               ACARG:  .WORD   X,X,X,X         ;AC OPERAND
 21695                                  ;               RES:    .WORD   X               ;EXPECTED RESULT
 21696                                  ;               ERRES:  .WORD   X               ;ERROR RESULT
 21697                                  ;               FPSB:   .WORD   X               ;FPS BEFORE EXECUTION
 21698                                  ;               FPSA:   .WORD   X               ;FPS AFTER EXECUTION
 21699                                  ;               ERFPS:  .WORD   X               ;ERROR FPS.
 21700                                  ;               ERR1:   ERROR   X               ;DATA ERROR.
 21701                                  ;                       BR      CONT
 21702                                  ;               ERR2:   ERROR   X               ;FPS ERROR.
 21703                                  ;               CONT:                           ;RETURN ADDRESS
 21704                                  ;
 21705                                  ;THE OPERANDS ARE SET UP (USING AC0 AS THE ACCUMULATOR). THEN
 21706                                  ;THE STEXP INSTRUCTION IS EXECUTED.
 21707                                  ;THE RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS
 21708                                  ;COMPARED WITH FPSA IF THIS TOO IS CORRECT STXSUB RETURNS CONTROL
 21709                                  ;TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD STXSUB
 21710                                  ;COMPARE IT TO ERROR FPS. IF THIS MATCHES THEN STXSUB WILL RETURN
 21711                                  ;TO THE ERROR CALL AT ERR2, OTHERWISE STXSUB ITSELF
 21712                                  ;REPORTS THIS FAILURE AND THEN RETURNS TO CONT. IF THE RESULT OF THE
 21713                                  ;STEXP IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE
 21714                                  ;ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN
 21715                                  ;THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN STXSUB
 21716                                  ;WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR1. OTHERWISE THE
 21717                                  ;RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND STXSUB WILL
```

```
                                ;REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.
                                
117554 012601                   STXSUB: MOV     (SP)+,R1        ;GET A POINTER TO THE ARGUMENTS.
117556 010102                           MOV     R1,R2
117560 012737 123456 117666             MOV     #123456,@#STXBF
117566 012737 076543 117670             MOV     #76543,@#STXBF+2
117574 012700 000200                    MOV     #200,R0
117600 170100                           LDFPS   R0
117602 010100                           MOV     R1,R0           ;SET UP THE AC0 OPERAND.
117604 172410                           LDD     (R0),AC0
117606 016100 000016                    MOV     16(R1),R0       ;SET THE FPS.
117612 170100                           LDFPS   R0
117614 012700 117666                    MOV     #STXBF,R0
117620 175010                   1$:     STEXP   AC0,(R0)        ;TEST INSTRUCTION.
117622 170204                           STFPS   R4              ;GET FPS.
117624 026137 000010 117666             CMP     10(R1),@#STXBF  ;WAS RESULT CORRECT?
117632 001401                           BEQ     5$
117634 104000                           EMT                     ;
117636 020461 000016            5$:     CMP     R4,16(R1)       ;SEE IF THE FPS IS CORRECT.
117642 001401                           BEQ     10$
117644 104000                           EMT                     ;
                                ;SEE IF MORE THAN ONE WORD WAS WRITTEN IN THE OUTPUT BUFFER.
117646 022737 076543 117670     10$:    CMP     #76543,@#STXBF+2
117654 001401                           BEQ     4$
117656 104000                           EMT                     ;
117660 000161 000022            4$:     JMP     22(R1)
                                
117664 177777                           -1
117666 177777 177777 177777     STXBF:  .WORD   -1,-1,-1,-1,-1
117674 177777 177777
                                
117700                          YYCDONE:
117700 004767 000570                    JSR     PC,..RSET       ;GO INITIALIZE THE FPS AND STACK; AND
                                                                ;SEE IF THE USER HAS EXPRESSED
                                                                ;THE DESIRE TO CHANGE THE SOFTWARE
                                                                ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
                                                                ;THE USER TYPED CONTROL G?).
                                
                                ;*****************************************************************************
                                ;TEST 574       STST TEST
                                ;*****************************************************************************
117704                          TS574:
                                
117704 012700 040000                    MOV     #40000,R0       ;SET FPS. FID=1.
117710 170100                           LDFPS   R0
                                
117712 170003                   ZZC2:   .WORD   170003                  ;ILLEGAL FPP
                                                                        ;OP CODE
117714 012700 117774                    MOV     #ZZCBF,R0       ;SET UP THE OUTPUT BUFFER.
117720 012710 177777                    MOV     #-1,(R0)
117724 012760 177777 000002             MOV     #-1,2(R0)
117732 170310                   ZZC3:   STST    (R0)                    ;GET FEC AND
                                                                        ;FEA
117734 170204                           STFPS   R4              ;GET FPS.
117736 012700 117774                    MOV     #ZZCBF,R0
117742 022710 000002                    CMP     #2,(R0) ;SEE IF FEC IS CORRECT.
```

```
21774  117746  001010                        BNE     ZZC10           ;BRANCH IF INCORRECT.
21775  117750  022760  117712  000002        CMP     #ZZC2,2(R0)     ;SEE IF FEA, ADDRESS, IS CORRECT.
21776  117756  001004                        BNE     ZZC10           ;BRANCH IF INCORRECT.
21777  117760  022704  140000                CMP     #140000,R4      ;SEE IF FPS IS CORRECT.
21778  117764  001001                        BNE     ZZC10           ;BRANCH IF INCORRECT.
21779  117766  000407                        BR      ZZCDONE
21780  117770                        ZZC10:
21781  117770  104000                        EMT                     ;
21782
21783                                 ;DATA BUFFER:
21784  117772  177777                        -1
21785  117774  177777  177777  177777  ZZCBF: .WORD   -1,-1,-1,-1
21786  120002  177777
21787  120004  177777                        -1
21788
21789  120006                        ZZCDONE:
21790  120006  004767  000462                JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
21791                                                                 ;SEE IF THE USER HAS EXPRESSED
21792                                                                 ;THE DESIRE TO CHANGE THE SOFTWARE
21793                                                                 ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
21794                                                                 ;THE USER TYPED CONTROL G?).
21795
21796
21797                                 ;*****************************************************************************
21798                                 ;TEST 575       SPECIAL CASE TEST
21799                                 ;*****************************************************************************
21800  120012                         TS575:
21801  120012  012746  144724         AAD1:   MOV     #144724, -(SP)  ;PUT FRACTION ON STACK
21802  120016  012746  040600                 MOV     #40600, -(SP)   ;PUT EXPONENT ON STACK
21803  120022  005046                         CLR     -(SP)           ;PUT SUBTRAHEND FRACTION ON STACK
21804  120024  012746  040600                 MOV     #40600, -(SP)   ;PUT SUBTRAHEND EXPONENT ON STACK
21805  120030  172466  000004                 LDF     4(SP), AC0      ;LOAD FP ACCUMULATORS
21806  120034  173026                         SUBF    (SP)+, AC0      ;DO SUBTRACTION
21807  120036  174037  120066                 STF     AC0, @#AADBF    ;GET AND STORE ANSWER
21808  120042  022737  036711  120066         CMP     #36711, @#AADBF ;IS EXPONENT CORRECT
21809  120050  001401                         BEQ     1$
21810  120052  104000                         EMT                     ;BAD EXPONENT FROM SUBTRACTION
21811  120054  022737  152000  120070  1$:    CMP     #152000, @#AADBF+2 ;IS FRACTION CORRECT
21812  120062  001403                         BEQ     AADDONE
21813  120064  104000                         EMT                     ;FRACTION INCORRECT
21814
21815  120066  000000                 AADBF:  .WORD   0
21816  120070  000000                         .WORD   0
21817
21818  120072  012706  001000         AADDONE: MOV    #STBOT, SP      ;RESTORE STACK POINTER
21819  120076  004767  000372                 JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
21820                                                                 ;SEE IF THE USER HAS EXPRESSED
21821                                                                 ;THE DESIRE TO CHANGE THE SOFTWARE
21822                                                                 ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
21823                                                                 ;THE USER TYPED CONTROL G?).
21824
21825
21826
21827                                 ;*****************************************************************************
21828                                 ;TEST 576       POWER MONITOR BIT CHECK
21829                                 ;*****************************************************************************
```

```
21830  120102
21831  120102  013700  000004          TS576:  MOV     @#4,R0
21832  120106  013701  000006                  MOV     @#6,R1          ;SAVE THE TIMEOUT VECTOR
21833  120112  012737  120136  000004          MOV     #1$,@#4
21834  120120  012737  000340  000006          MOV     #340,@#6        ;SET UP THE TIMEOUT VECTOR TO WITHIN THE TEST
21835  120126  005737  177766                  TST     @#177766        ;IS THE MAP PRESENT?(NO TRAP TO 1$)
21836  120132  001403                          BEQ     2$              ;YES,AND IF EQUAL TO ZERO THEN CLEAN UP
21837                                                                  ;AND GO TO NEXT TEST
21838  120134  104000                          EMT                     ;IF POWER HAS FAILED THEN GO REPORT ERROR
21839  120136  005726                  1$:     TST     (SP)+           ;READJUST THE STACK TO COMPENSATE FOR THE
21840  120140  005726                          TST     (SP)+           ;STACK
21841  120142  010037  000004          2$:     MOV     R0,@#4          ;RESTORE THE TIMEOUT VECTOR
21842  120146  010137  000006                  MOV     R1,@#6          ;AND GO TO NEXT TEST
21843
21844                                  ;*****************************************************************************************
21845                                  ;TEST 577       INTERRUPTABILITY TEST
21846                                  ;*****************************************************************************************
21847  120152                          TS577:
21848  120152  004567  130250          BBD1:   JSR     R5,CHKAPT
21849  120156  000520                          BR      FPEXIT          ;SKIP TEST IF ON APT AND NOT FIRST PASS
21850
21851  120160  005001                          CLR     R1              ;INITIALIZE A COUPLE OF COUNTERS
21852  120162  005000                          CLR     R0
21853  120164  013767  000064  117170          MOV     @#64,   $TMP0   ;SAVE INTERRUPT VECTOR
21854  120172  013767  000066  117164          MOV     @#66,   $TMP1   ;SAVE INTERRUPT PRIORITY
21855  120200  012737  120252  000064          MOV     #3$,    @#64    ;SET UP INTERRUPT PRIORITY FOR THIS TEST
21856  120206  005037  000066                  CLR     @#66            ;AND PRIORITY
21857  120212  005067  057560                  CLR     PS              ;PUT PROCESSOR PRIORITY AT 0
21858  120216  005067  057344                  CLR     TPB             ;SEND A NULL CHARACTER
21859  120222  105767  057336          1$:     TSTB    TTCSR           ;WAIT FOR DONE TO SET
21860  120226  100375                          BPL     1$
21861  120230  005067  057332                  CLR     TPB             ;SEND A SECOND CHARACTER
21862  120234  052767  000100  057322          BIS     #BIT6,  TTCSR   ;SET INTERRUPT ENABLE
21863  120242  005200                  2$:     INC     R0              ;INCREMENT COUNTER TO GET BASE TIME
21864  120244  001376                          BNE     2$              ;CONTINUE LOOPING UNLESS COUNTER GOES TO 0
21865  120246  000005                          RESET                   ;IF NO INTERRUPT YET KILL IT
21866  120250  104000                          EMT                     ;NO INTERRUPT OCCURRED IN ALLOTTED TIME
21867  120252  166700  000110          3$:     SUB     Y,      R0      ;SUBTRACT TIME FOR FP INSTRUCTION
21868  120256  010067  000106                  MOV     R0,     Z       ;SAVE FIRST TIME
21869  120262  012737  120340  000064          MOV     #7$,    @#64    ;SET UP FOR NEXT INTERRUPT
21870  120270  005100                  4$:     COM     R0              ;MAKE PRE LOOP COUNTER NEGATIVE
21871  120272  005067  057266                  CLR     TTCSR           ;MAKE SURE NO INTERRUPT YET
21872  120276  005067  057264                  CLR     TPB             ;SEND A CHARACTER
21873  120302  105767  057256          5$:     TSTB    TTCSR           ;WAIT FOR READY BIT TO SET
21874  120306  100375                          BPL     5$
21875  120310  005067  057252                  CLR     TPB             ;SEND SECOND CHARACTER
21876  120314  052767  000100  057242          BIS     #BIT6,  TTCSR   ;SET INTERRUPT ENABLE
21877  120322  005200                  6$:     INC     R0              ;DO PRE LOOP
21878  120324  001376                          BNE     6$
21879  120326  171227  040400                  MULF    #2,     AC2     ;DO FLOATING POINT INSTRUCTION
21880  120332  000240                          NOP                     ;JUST IN CASE INTERRUPT TAKES TOO LONG
21881  120334  000005                          RESET                   ;IF NO INTERRUPT CLEAR THE WORLD
21882  120336  104000                          EMT                     ;INTERRUPT NOT BACK IN ALLOTTED TIME
21883  120340  005201                  7$:     INC     R1              ;INCREMENT TIMES THROUGH COUNTER
21884  120342  020127  000015                  CMP     R1,     #15     ;HAVE WE PASSED HERE 15 TIMES BEFORE
21885  120346  001411                          BEQ     BBDDONE         ;IF YES I MAY NEVER PASS HERE AGAIN
```

```
21886  120350  062767  000002  000012          ADD     #2.     Z       ;IF NO ADD A LITTLE TIME TO PRELOOP
21887  120356  016700  000006                  MOV     Z,      R0      ;PUT NEW COUNT IN COUNTER
21888  120362  000742                          BR      4$              ;DO IT ALL AGAIN
21889
21890  120364  000000                  X:      .WORD   0
21891  120366  000026                  Y:      .WORD   26
21892  120370  000000                  Z:      .WORD   0
21893
21894  120372  042767  000100  057164  BBDDONE:BIC     #100,   TTCSR   ;CLEAR INTERRUPT ENABLE BEFORE EXITING TEST
21895  120400  016737  116756  000064          MOV     $TMP0,  @#64    ;RESTORE PRINTER VECTOR
21896  120406  016737  116752  000066          MOV     $TMP1,  @#66    ;RESTORE PRINTER PRIORITY
21897  120414  004767  000054                  JSR     PC,.RSET        ;GO INITIALIZE THE FPS AND STACK; AND
21898                                                                  ;SEE IF THE USER HAS EXPRESSED
21899                                                                  ;THE DESIRE TO CHANGE THE SOFTWARE
21900                                                                  ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
21901                                                                  ;THE USER TYPED CONTROL G?).
21902  120420  000167  000134          FPEXIT: JMP     SLU1ST          ;GET OVER SUBROUTINES TO NEXT TEST
21903
21904
21905  120424  012737  120456  000004  ERROR4: MOV     #1$,@#4         ;SET UP THE TIMEOUT VECTOR
21906  120432  012737  000340  000006          MOV     #340,@#6
21907  120440  005737  177766                  TST     @#177766        ;CHECK TO SEE IF THE POWER FAILED,WILL TRAP
21908                                                                  ;TO 1$ IF UNIBUS MAP BOARD IS NOT PRESENT
21909                                                                  ;SINCE THE CPUERR(177766)IS ON THE UNIBUS
21910                                                                  ;MAP BOARD
21911  120444  001404                          BEQ     1$              ;NO,GO REPORT THE ERROR
21912  120446  012737  000177  001002          MOV     #177,@#$FATAL   ;YES,FLAG THAT THE POWER FAILED
21913  120454  000403                          BR      2$              ; AND GO SET FATAL ERROR FLAG
21914  120456  012737  000003  001002  1$:     MOV     #3,@#$FATAL                     ;SET UP FATAL ERROR NUMBER
21915  120464  012767  000001  060306  2$:     MOV     #1,$MSGTY                       ;SET FATAL ERROR FLAG
21916  120472  000777                  FPHLT:  BR      .               ;STAY HERE FOREVER
21917                                          .SBTTL  FLAG RESET ROUTINE
21918                                  ;*******************************************************************************
21919                                  ;*THIS ROUTINE WILL BE CALLED AT THE END OF EACH FLOATING POINT TEST
21920                                  ;*TO RESET THE STACK, CLEAR THE FPS AND REINITIALIZE TRAP VECTORS
21921
21922  120474  012737  120424  000244  .RSET:  MOV     #ERROR4,@#$PVECT
21923  120502  012737  021256  000004          MOV     #T04,@#ERRVECT
21924  120510  012737  021260  000010          MOV     #T010,@#10
21925  120516  011600                          MOV     (SP),R0
21926  120520  012706  001000                  MOV     #STBOT,SP
21927  120524  005004                          CLR     R4
21928  120526  170104                          LDFPS   R4
21929  120530  000110                          JMP     (R0)
21930
21931                                  ;THESE ARE SOME EQUATES USE IN THE LAST THREE SECTIONS
21932          000001                          BIT0=000001
21933          000002                          BIT1=000002
21934          000004                          BIT2=000004
21935          000010                          BIT3=000010
21936          000020                          BIT4=000020
21937          000040                          BIT5=000040
21938          000100                          BIT6=000100
21939          000200                          BIT7=000200
21940          000400                          BIT8=000400
21941          001000                          BIT9=001000
```

```
21942           002000                          BIT10=002000
21943           004000                          BIT11=004000
21944           010000                          BIT12=010000
21945           020000                          BIT13=020000
21946           040000                          BIT14=040000
21947           100000                          BIT15=100000
21948
21949  120532   177560          RCSR:   177560          ;ADDRESS OF RECEIVER COMMAND/STATUS REGISTER
21950  120534   177562          RBUF:   177562          ;ADDRESS OF RECEIVER BUFFER
21951  120536   177564          TCSR:   177564          ;ADDRESS OF TRANSMITTER COMMAND/STATUS REGISTER
21952  120540   177566          TBUF:   177566          ;ADDRESS OF TRANSMITTER BUFFER
21953  120542   000060          RVECT:  60              ;RECEIVER INTERRUPT VECTOR
21954  120544   000062          RPSW:   62
21955  120546   000064          TVECT:  64              ;TRANSMITTER INTERRUPT VECTOR
21956  120550   000066          TPSW:   66
21957
21958                           ;REAL TIME CLOCK REGISTER AND VECTOR ADDRESSES
21959  120552   177546          LKS:    .WORD   177546
21960  120554   000100          RTCVT:  .WORD   100
21961  120556   000102          RTCPSW: .WORD   102
21962
21963  120560   032777  000004  100536  SLU1ST: BIT     #4,@SWR
21964  120566   001402                          BEQ     1$
21965  120570   000167  002424                  JMP     KWSTRT
21966  120574   012737  000004  001004  1$:     MOV     #4,@#$TESTN     ;PUT TEST NUMBER IN MAILBOX
21967  120602   012737  123150  000030          MOV     #ERROR5,@#30    ;SET UP FOR CORRECT ERROR CALL
21968
21969
21970                           ;*****************************************************************************
21971                           ;TEST 600       TEST ABILITY TO REFERENCE TCSR
21972                           ;*****************************************************************************
21973  120610                   TS600:
21974  120610   013703  000004          MOV     @#4,R3          ;SAVE TIMEOUT VECTOR
21975  120614   012737  120630  000004  MOV     #1$,@#4         ;SET UP TIMEOUT VECTOR
21976  120622   005777  177710          TST     @TCSR           ;REFERENCE THE XMIT COMMAND/STATUS REG.
21977  120626   000401                  BR      4$
21978  120630                   1$:
21979  120630   104000          EMT             ;
21980  120632   010337  000004  4$:     MOV     R3,@#4          ;RESTORE TIMEOUT VECTOR
21981
21982
21983
21984                           ;*****************************************************************************
21985                           ;TEST 601       TEST ABILITY TO REFERENCE TBUF
21986                           ;*****************************************************************************
21987  120636                   TS601:
21988  120636   013703  000004          MOV     @#4,R3          ;SAVE TIMEOUT VECTOR
21989  120642   012737  120656  000004  MOV     #1$,@#4         ;SET UP TIMEOUT VECTOR
21990  120650   005777  177664          TST     @TBUF           ;REFERENCE THE XMIT BUFFER
21991  120654   000401                  BR      4$
21992  120656                   1$:
21993  120656   104000          EMT             ;
21994  120660   010337  000004  4$:     MOV     R3,@#4          ;RESTORE TIMEOUT VECTOR
21995
21996
21997                           ;*****************************************************************************
```

```
21998                                   ;TEST 602       TEST THAT TCSR BIT7(DONE) CLEARS WHEN XBUF IS LOADED
21999                                   ;*****************************************************************************
22000  120664                           TS602:
22001  120664  032737  000001  001020          BIT     #1,@#$ENV       ;ARE WE RUNNING UNDER APT
22002  120672  001405                          BEQ     70$             ;IF NO THEN SERIES OF TESTS
22003  120674  005737  001006                  TST     @#$PASS         ;IS THIS FIRST PASS
22004  120700  001402                          BEQ     70$             ;IF YES THEN DO SERIES OF TESTS
22005  120702  000167  002312                  JMP     KWSTRT          ;IF NO THEN BYPASS SERIES OF TESTS
22006  120706  005077  177626          70$:    CLR     @TBUF           ;LOAD XBUF
22007  120712  105777  177620                  TSTB    @TCSR           ;CHECK DONE
22008  120716  100006                          BPL     3$              ;BR IF CLEAR
22009                                                                   ;FILL SECOND BUFFER BECUASE REFRESH COULD CAUSE
22010                                                                   ;FIRST TEST TO FAIL
22011  120720  005077  177614                  CLR     @TBUF           ;FILL DOUBLE BUFFER
22012  120724  105777  177606                  TSTB    @TCSR           ;CHECK DONE
22013  120730  100001                          BPL     3$
22014  120732  104000                          EMT                     ;
22015  120734  005000                  3$:     CLR     R0              ;CLEAR TIMER
22016  120736  105777  177574          4$:     TSTB    @TCSR           ;CHECK FOR XMIT DONE
22017  120742  100403                          BMI     5$              ;IF DONE SETS, BR TO END OF TEST
22018  120744  005200                          INC     R0              ;INCREMENT TIMER
22019  120746  001373                          BNE     4$
22020  120750  104000                          EMT                     ;
22021  120752                           5$:
22022
22023
22024                                   ;*****************************************************************************
22025                                   ;TEST 603       TEST THAT TCSR "DONE" SETS WITH RESET
22026                                   ;*****************************************************************************
22027  120752                           TS603:
22028  120752  005077  177562                  CLR     @TBUF           ;LOAD TRANSMIT BUFFER
22029  120756  105777  177554          1$:     TSTB    @TCSR           ;WAIT FOR DONE
22030  120762  100375                          BPL     1$
22031  120764  005077  177550                  CLR     @TBUF           ;LOAD SECOND BUFFER
22032  120770  000240                          NOP
22033  120772  000005                          RESET                   ;SET DONE WITH RESET
22034  120774  105777  177536                  TSTB    @TCSR           ;CHECK FOR DONE SET
22035  121000  100401                          BMI     TS604
22036  121002  104000                          EMT                     ;
22037
22038
22039                                   ;*****************************************************************************
22040                                   ;TEST 604       TEST ABILITY TO ACCESS RCSR
22041                                   ;*****************************************************************************
22042  121004                           TS604:
22043  121004  013703  000004                  MOV     @#4,R3          ;SAVE TIMEOUT VECTOR
22044  121010  012737  121024  000004          MOV     #1$,@#4         ;SET UP TIMEOUT VECTOR
22045  121016  005777  177510                  TST     @RCSR           ;ACCESS RCSR
22046  121022  000401                          BR      2$
22047  121024                           1$:
22048  121024  104000                          EMT                     ;
22049  121026  010337  000004          2$:     MOV     R3,@#4          ;RESTORE TIMEOUT VECTOR
22050  121030
22051
22052                                   ;*****************************************************************************
22053
```

```
                                        ;TEST 605       TEST ABILITY TO ACCESS RBUF
                                        ;*************************************************************************************
                                        TS605:
121032                                          MOV     @#4,R3          ;SAVE TIMEOUT VECTOR
121032  013703  000004                          MOV     #1$,@#4         ;SET UP TIMEOUT VECTOR
121036  012737  121052  000004                  TST     @RBUF           ;ACCESS RBUF
121044  005777  177464                          BR      2$
121050  000401                                1$:
121052                                          EMT                     ;
121052  104000                          2$:     MOV     R3,@#4          ;RESTORE TIMEOUT VECTOR
121054  010337  000004


                                        ;*************************************************************************************
                                        ;TEST 606       TEST THAT BIT2(MAINT. BIT) CAN BE SET & RESET
                                        ;*************************************************************************************
121060                                  TS606:
121060  032777  000004  177450                  BIT     #BIT2,@TCSR     ;TEST FOR BIT2 OF TCSR CLEAR
121066  001401                                  BEQ     3$
121070  104000                                  EMT                     ;
121072  052777  000004  177436          3$:     BIS     #BIT2,@TCSR     ;SET BIT2 OF TCSR
121100  032777  000004  177430                  BIT     #BIT2,@TCSR     ;TEST FOR BIT2 SET
121106  001001                                  BNE     4$
121110  104000                                  EMT                     ;
121112  042777  000004  177416          4$:     BIC     #BIT2,@TCSR     ;CLEAR BIT2 OF TCSR
121120  032777  000004  177410                  BIT     #BIT2,@TCSR     ;TEST BIT2 CLEAR
121126  001401                                  BEQ     7$
121130  104000                                  EMT                     ;
121132  052777  000004  177376          7$:     BIS     #BIT2,@TCSR     ;SET BIT2 OF TCSR
121140  000005                                  RESET                   ;CLEAR BIT2 WITH RESET
121142  032777  000004  177366                  BIT     #BIT2,@TCSR     ;TEST FOR BIT2 CLEAR
121150  001401                                  BEQ     TS607
121152  104000                                  EMT                     ;


                                        ;*************************************************************************************
                                        ;TEST 607       TEST THAT BIT6(XMIT INT EN) CAN BE SET & RESET
                                        ;*************************************************************************************
121154                                  TS607:
121154  017703  177366                          MOV     @TVECT,R3       ;SAVE XMIT VECTOR
121160  012777  121202  177360                  MOV     #1$,@TVECT      ;SET UP INTERRUPT VECTOR FOR ERROR REPORT
121166  106427  000340                          MTPS    #340            ;SET PSW TO PRIORITY 7
121172  032777  000100  177336                  BIT     #BIT6,@TCSR     ;TEST BIT6 OF TCSR
121200  001401                                  BEQ     2$
121202                                  1$:
121202  104000                                  EMT                     ;
121204  052777  000100  177324          2$:     BIS     #BIT6,@TCSR     ;SET BIT6 OF TCSR
121212  032777  000100  177316                  BIT     #BIT6,@TCSR     ;TEST BIT6 OF TCSR
121220  001001                                  BNE     3$
121222  104000                                  EMT                     ;
121224  042777  000100  177304          3$:     BIC     #BIT6,@TCSR     ;CLEAR BIT6 OF TCSR
121232  032777  000100  177276                  BIT     #BIT6,@TCSR     ;TEST BIT6 OF TCSR
121240  001401                                  BEQ     4$
```

```
22110  121242  104000                          EMT                     ;
22111  121244                          4$:
22112  121244  052777  000100  177264          BIS     #BIT6,@TCSR     ;SET BIT6 OF TCSR
22113  121252  000005                          RESET                   ;CLEAR BIT6 WITH RESET
22114  121254  032777  000100  177254          BIT     #BIT6,@TCSR     ;TEST BIT6 OF TCSR
22115  121262  001401                          BEQ     5$
22116  121264  104000                          EMT                     ;
22117  121266  010377  177254          5$:     MOV     R3,@TVECT       ;RESTORE XMIT VECTOR
22118
22119
22120                                  ;*****************************************************************************
22121                                  ;TEST 610       TEST THAT BIT6 OF RCSR CAN BE SET & RESET
22122                                  ;*****************************************************************************
22123  121272                          TS610:
22124  121272  017703  177244                  MOV     @RVECT,R3       ;SAVE RECEIVE VECTOR
22125  121276  012777  121320  177236          MOV     #1$,@RVECT      ;SET UP INTERRUPT VECTOR FOR ERROR REPORT
22126  121304  106427  000340                  MTPS    #340            ;SET PSW TO PRIORITY 7
22127  121310  032777  000100  177214          BIT     #BIT6,@RCSR     ;TEST BIT6 OF RCSR
22128  121316  001401                          BEQ     2$
22129  121320                          1$:
22130  121320  104000                          EMT                     ;
22131  121322  052777  000100  177202  2$:     BIS     #BIT6,@RCSR     ;SET BIT6 OF RCSR
22132  121330  032777  000100  177174          BIT     #BIT6,@RCSR     ;TEST BIT6 OF RCSR
22133  121336  001001                          BNE     3$
22134  121340  104000                          EMT                     ;
22135  121342  042777  000100  177162  3$:     BIC     #BIT6,@RCSR     ;CLEAR BIT6 OF RCSR
22136  121350  032777  000100  177154          BIT     #BIT6,@RCSR     ;TEST BIT6 OF RCSR
22137  121356  001401                          BEQ     4$
22138  121360  104000                          EMT                     ;
22139  121362                          4$:
22140  121362  052777  000100  177142          BIS     #BIT6,@RCSR     ;SET BIT6 OF RCSR
22141  121370  000005                          RESET                   ;CLEAR BIT6OF RCSR WITH RESET
22142  121372  032777  000100  177132          BIT     #BIT6,@RCSR     ;TEST BIT6 OF RCSR
22143  121400  001401                          BEQ     5$
22144  121402  104000                          EMT                     ;
22145  121404  010377  177132          5$:     MOV     R3,@RVECT       ;RESTORE RECEIVE VECTOR
22146
22147
22148
22149                                  ;*****************************************************************************
22150                                  ;TEST 611       TEST THAT XMIT INTERRUPTS ONLY WHEN ENABLED
22151                                  ;*****************************************************************************
22152  121410                          TS611:
22153  121410  042777  000100  177120          BIC     #BIT6,@TCSR     ;CLEAR TRANSMIT INTERRUPT ENABLE
22154  121416  017703  177124                  MOV     @TVECT,R3       ;SAVE XMIT VECTOR
22155  121422  012777  121444  177116          MOV     #2$,@TVECT      ;POINT XMIT VECTOR TO ERROR REPORT
22156  121430  105777  177102          1$:     TSTB    @TCSR           ;WAIT FOR DONE
22157  121434  100375                          BPL     1$
22158  121436  106427  000140                  MTPS    #140            ;SET PSW TO PRIORITY 3
22159  121442  000401                          BR      3$
22160  121444                          2$:
22161  121444  104000                          EMT                     ;
22162  121446  012777  121466  177072  3$:     MOV     #4$,@TVECT      ;SET XMIT VECTOR TO END OF TEST
22163  121454  052777  000100  177054          BIS     #BIT6,@TCSR     ;ENABLE INTERRUPTS
22164  121462  000240                          NOP
22165
```

```
22166  121464  104000                        EMT                     ;XMIT DID NOT INTERRUPT
22167
22168  121466  042777  000100  177042  4$:   BIC     #BIT6,@TCSR     ;DISABLE INTERRUPTS
22169  121474  022626                        CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
22170  121476  010377  177044                MOV     R3,@TVECT       ;RESTORE XMIT VECTOR
22171
22172
22173                                  ;*************************************************************************************
22174                                  ;TEST 612       TEST THAT XMIT INTERRUPTS DO NOT OCCUR WHEN DISABLED
22175                                  ;*************************************************************************************
22176  121502                          TS612:
22177  121502  042777  000100  177026        BIC     #BIT6,@TCSR     ;DISABLE INTERRUPTS
22178  121510  106427  000340              MTPS    #340            ;SET PSW TO PRIORITY 7
22179  121514  017703  177026              MOV     @TVECT,R3       ;SAVE XMIT VECTOR
22180  121520  012777  121546  177020        MOV     #2$,@TVECT      ;POINT XMIT VECTOR TO ERROR REPORT
22181  121526  105777  177004        1$:   TSTB    @TCSR           ;WAIT FOR DONE
22182  121532  100375                        BPL     1$
22183  121534  052777  000100  176774        BIS     #BIT6,@TCSR     ;ENABLE INTERRUPT
22184  121542  000240                        NOP
22185  121544  000401                        BR      3$
22186  121546                          2$:
22187  121546  104000                        EMT                     ;
22188  121550  042777  000100  176760  3$:   BIC     #BIT6,@TCSR     ;CLEAR INTERRUPT ENABLE
22189  121556  012777  121574  176762        MOV     #4$,@TVECT      ;POINT XMIT VECTOR TO ERROR REPORT
22190  121564  106427  000140              MTPS    #140            ;SET PSW TO PRIORITY 3
22191  121570  000240                        NOP
22192  121572  000401                        BR      5$
22193  121574                          4$:
22194  121574  104000                        EMT                     ;
22195  121576  010377  176744        5$:   MOV     R3,@TVECT       ;RESTORE XMIT VECTOR
22196
22197
22198                                  ;*************************************************************************************
22199                                  ;TEST 613       TEST TRANSMITTER FOR DOUBLE INTERRUPTS
22200                                  ;*************************************************************************************
22201  121602                          TS613:
22202  121602  042777  000100  176726        BIC     #BIT6,@TCSR     ;CLEAR INTERRUPT ENABLE
22203  121610  017703  176732              MOV     @TVECT,R3       ;SAVE XMIT VECTOR
22204  121614  017704  176730              MOV     @TPSW,R4        ;SAVE XMIT PSW VECTOR
22205  121620  012777  121660  176720        MOV     #2$,@TVECT      ;SET UP XMIT VECTOR
22206  121626  012777  000340  176714        MOV     #340,@TPSW      ;SET PIO 7 AFTER INTERRUPT
22207  121634  106427  000140              MTPS    #140            ;SET PSW TO PRIORITY 3
22208  121640  105777  176672        1$:   TSTB    @TCSR           ;WAIT FOR DONE
22209  121644  100375                        BPL     1$
22210  121646  052777  000100  176662        BIS     #BIT6,@TCSR     ;ENABLE INTERRUPTS
22211  121654  000240                        NOP
22212
22213  121656  104000                        EMT                     ;
22214                                                                  ;XMIT INTERRUPT DID NOT OCCUR
22215  121660  022626                2$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
22216  121662  012777  121706  176656        MOV     #4$,@TVECT      ;POINT XMIT VECTOR TO ERROR
22217  121670  106427  000140              MTPS    #140            ;SET PSW TO PRIORITY 3
22218  121674  000240                        NOP                     ;GIVE TIME FOR ANY INTERRUPTS
22219  121676  042777  000100  176632        BIC     #BIT6,@TCSR     ;DISABLE INTERRUPTS
22220  121704  000401                        BR      5$
22221  121706                          4$:
```

```
22222  121706  104000                          EMT                     ;
22223  121710  010377  176632          5$:     MOV     R3,@TVECT       ;RESTORE XMIT VECTOR
22224  121714  010477  176630                  MOV     R4,@TPSW        ;RESTORE XMIT PSW VECTOR
22225
22226                                  ;*************************************************************************************
22227                                  ;TEST 614       TEST THAT XMIT INTERRUPT CLEARS WITH LOADING TBUF
22228                                  ;*************************************************************************************
22229  121720                          TS614:
22230  121720  042777  000100  176610          BIC     #BIT6,@TCSR     ;DISABLE INTERRUPTS
22231  121726  106427  000340                  MTPS    #340            ;SET PSW TO PRIORITY 7
22232  121732  017703  176610                  MOV     @TVECT,R3       ;SAVE XMIT VECTOR
22233  121736  012777  122006  176602          MOV     #2$,@TVECT      ;POINT XMIT VECTOR TO ERROR
22234  121744  052777  000100  176564          BIS     #BIT6,@TCSR     ;ENABLE INTERRUPTS
22235  121752  005077  176562                  CLR     @TBUF           ;LOAD TBUF
22236  121756  105777  176554          1$:     TSTB    @TCSR           ;WAIT FOR DONE (INTERRUPT)
22237  121762  100375                          BPL     1$
22238  121764  005077  176550                  CLR     @TBUF           ;FILL SECOND BUFFER TO RESET INT.
22239  121770  106427  000140                  MTPS    #140            ;SET PSW TO PRIORITY 3
22240  121774  000240                          NOP                     ;GIVE TIME FOR ANY INTERRUPTS
22241  121776  042777  000100  176532          BIC     #BIT6,@TCSR     ;DISABLE INTERRUPTS
22242  122004  000401                          BR      3$
22243  122006                          2$:
22244  122006  104000                          EMT                     ;
22245  122010  010377  176532          3$:     MOV     R3,@TVECT       ;RESTORE XMIT VECTOR
22246  122014  005000                          CLR     R0              ;INITIALIZE LOOP COUNTER
22247  122016  005200                  4$:     INC     R0              ;INCREMENT LOOP COUNTER
22248  122020  001376                          BNE     4$              ; UNTIL COUNTER = 0
22249  122022  005777  176506                  TST     @RBUF           ;CLEAR RECEIVER BUFFER
22250
22251
22252                                  ;*************************************************************************************
22253                                  ;TEST 615       TEST THAT RCVR DONE (7) SET & CLEAR PROPERLY
22254                                  ;*************************************************************************************
22255  122026                          TS615:
22256  122026  052777  000004  176502          BIS     #BIT2,@TCSR     ;SET MAINTENANCE WRAP
22257  122034  005000                          CLR     R0              ;CLEAR A TIMER
22258  122036  005077  176476                  CLR     @TBUF           ;LOAD TRANSMIT BUFFER
22259  122042  105777  176464          WDONE1: TSTB    @RCSR           ;CHECK FOR RECEIVER DONE
22260  122046  100406                          BMI     6$              ;BR, IF DONE
22261  122050  005200                          INC     R0              ;INCREMENT TIMER, IF NOT DONE
22262  122052  001373                          BNE     WDONE1          ;CONTINUE WAIT IF TIME REMAINS
22263  122054  042777  000004  176454          BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT
22264  122062  104000                          EMT                     ;RECEIVER DONE NEVER SET
22265
22266  122064  000005                  6$:     RESET                   ;CLEAR DONE, MAINTENANCE MODE AND RECEIVER
22267                                                                  ;   BUFFER WITH RESET
22268  122066  105777  176440                  TSTB    @RCSR           ;CHECK FOR DONE CLEAR
22269  122072  001401                          BEQ     7$
22270
22271  122074  104000                          EMT                     ;RESET DID NOT CLEAR RCVR DONE
22272
22273  122076                          7$:
22274
22275                                  ;*************************************************************************************
22276                                  ;TEST 616       TEST THAT READING RBUF CLEARS RECEIVER DONE
22277                                  ;*************************************************************************************
```

```
22278  122076
22279  122076  052777  000004  176432  TS616:  BIS   #BIT2,@TCSR     ;SET MAINTENANCE WRAP
22280  122104  005077  176430          CLR   @TBUF                  ;LOAD TRANSMITTER
22281  122110  105777  176416          1$:   TSTB  @RCSR            ;WAIT FOR RECEIVER DONE
22282  122114  100375                      BPL   1$
22283  122116  017700  176412          MOV   @RBUF,R0               ;READ RECEIVE BUFFER
22284  122122  042777  000004  176406  BIC   #BIT2,@TCSR           ;CLEAR MAINTENANCE BIT
22285  122130  105777  176376          TSTB  @RCSR                  ;CHECK FOR RECEIVE DONE CLEAR
22286  122134  001401                      BEQ   TS617
22287  122136  104000                      EMT                          ;
                                                                     ;READING RBUF DID NOT CLEAR RCVR DONE
22288
22289
22290
22291                                  ;*****************************************************************************
22292                                  ;TEST 617       TEST THAT RCVR INTERRUPTS ONLY WHEN ENABLED
22293                                  ;*****************************************************************************
22294  122140                          TS617:
22295  122140  042777  000100  176370  BIC   #BIT6,@TCSR           ;DISABLE TRANSMIT INTERRUPTS
22296  122146  042777  000100  176356  BIC   #BIT6,@RCSR           ;DISABLE RECEIVER INTERRUPTS
22297  122154  052777  000004  176354  BIS   #BIT2,@TCSR           ;SET MAINTENANCE WRAP
22298  122162  017703  176354          MOV   @RVECT,R3              ;SAVE RECEIVE VECTOR
22299  122166  012777  122222  176346  MOV   #2$,@RVECT           ;POINT RCV VECTOR TO ERROR REPORT
22300  122174  106427  000140          MTPS  #140                   ;SET PSW TO PRIORITY 3
22301  122200  005077  176334          CLR   @TBUF                  ;SEND A CHARACTER
22302  122204  105777  176322          1$:   TSTB  @RCSR            ;WAIT FOR RECEIVER DONE
22303  122210  100375                      BPL   1$
22304  122212  042777  000004  176316  BIC   #BIT2,@TCSR           ;CLEAR MAINTENANCE BIT
22305  122220  000404                      BR    3$                 ;CONTINUE TEST
22306
22307  122222  042777  000004  176306  2$:   BIC   #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT
22308  122230  104000                      EMT                          ;
22309  122232  012777  122252  176302  3$:   MOV   #4$,@RVECT      ;POINT RCV VECTOR TO END OF TEST
22310  122240  052777  000100  176264  BIS   #BIT6,@RCSR           ;ENABLE RCV INTERRUPTS
22311  122246  000240                      NOP                          ;GIVE ANY INTERRUPTS TIME
22312  122250  104000                      EMT                          ;
22313  122252  042777  000100  176252  4$:   BIC   #BIT6,@RCSR     ;DISABLE INTERRUPTS
22314  122260  022626                      CMP   (SP)+,(SP)+            ;RESTORE SP AFTER INTERRUPT
22315  122262  010377  176254          MOV   R3,@RVECT              ;RESTORE RECEIVE VECTOR
22316  122266  005777  176242          TST   @RBUF                  ;CLEAR RECEIVER BUFFER
22317
22318
22319                                  ;*****************************************************************************
22320                                  ;TEST 620       TEST THAT RCVR INTERRUPTS DO NOT OCCUR WHEN DISABLED
22321                                  ;*****************************************************************************
22322  122272                          TS620:
22323  122272  106427  000340          MTPS  #340                   ;SET PSW TO PRIORITY 7
22324  122276  017703  176240          MOV   @RVECT,R3              ;SAVE RECEIVE VECTOR
22325  122302  012777  122342  176232  MOV   #2$,@RVECT           ;POINT RCVR VECTOR TO ERROR REPORT
22326  122310  052777  000004  176220  BIS   #BIT2,@TCSR           ;SET MAINTENANCE WRAP
22327  122316  005077  176216          CLR   @TBUF                  ;SEND A CHARACTER
22328  122322  105777  176204          1$:   TSTB  @RCSR            ;WAIT FOR RECEIVER DONE
22329  122326  100375                      BPL   1$
22330  122330  052777  000100  176174  BIS   #BIT6,@RCSR           ;ENABLE INTERRUPTS
22331  122336  000240                      NOP                          ;GIVE TIME FOR INTERRUPT
22332  122340  000404                      BR    3$                 ;CONTINUE TEST
22333  122342  042777  000004  176166  2$:   BIC   #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT
```

```
22334  122350  104000                        EMT                     ;
22335  122352  042777  000100  176152  3$:   BIC     #BIT6,@RCSR       ;CLEAR INTERRUPT ENABLE
22336  122360  012777  122404  176154        MOV     #4$,@RVECT        ;POINT RCVR VECTOR TO ERROR REPORT
22337  122366  106427  000140              MTPS    #140              ;SET PSW TO PRIORITY 3
22338  122372  000240                        NOP                       ;GIVE TIME FOR ANY INTERRUPT
22339  122374  042777  000004  176134        BIC     #BIT2,@TCSR       ;CLEAR MAINTENANCE BIT
22340  122402  000404                        BR      5$                ;BR TO END OF TEST, IF NO INTERRUPT
22341
22342  122404  042777  000004  176124  4$:   BIC     #BIT2,@TCSR       ;CLEAR MAINTENANCE BIT
22343  122412  104000                        EMT                     ;
22344  122414  010377  176122        5$:   MOV     R3,@RVECT         ;RESTORE RECEIVE VECTOR
22345  122420  005777  176110              TST     @RBUF             ;CLEAR RECEIVER BUFFER
22346
22347
22348                                  ;*****************************************************************************
22349                                  ;TEST 621       TEST RECEIVER FOR DOUBLE INTERRUPTS
22350                                  ;*****************************************************************************
22351  122424                          TS621:
22352  122424  017703  176112                MOV     @RVECT,R3         ;SAVE RFCEIVE VECTOR
22353  122430  017704  176110                MOV     @RPSW,R4          ;SAVE RECEIVE PSW VECTOR
22354  122434  012777  122514  176100        MOV     #2$,@RVECT        ;POINT RCV VECTOR TO CONTINUE TEST
22355  122442  012777  000340  176074        MOV     #340,@RPSW        ;SET PRIORITY TO 7 AFTER INTERRUPT
22356  122450  106427  000140              MTPS    #140              ;SET PSW TO PRIORITY 3
22357  122454  052777  000004  176054        BIS     #BIT2,@TCSR       ;SET MAINTENANCE WRAP
22358  122462  005077  176052                CLR     @TBUF             ;SEND A CHARACTER
22359  122466  105777  176040        1$:     TSTB    @RCSR             ;WAIT FOR RCVR DONE
22360  122472  100375                        BPL     1$
22361  122474  042777  000004  176034        BIC     #BIT2,@TCSR       ;CLEAR MAINTENANCE BIT
22362  122502  052777  000100  176022        BIS     #BIT6,@RCSR       ;ENABLE RCV INTERRUPTS
22363  122510  000240                        NOP                       ;GIVE SOME TIME
22364  122512  104000                        EMT                     ;
22365  122514  022626              2$:       CMP     (SP)+,(SP)+       ;RESTORE SP AFTER INTERRUPT
22366  122516  012777  122552  176016        MOV     #3$,@RVECT        ;POINT RCV VECTOR TO ERROR REPORT
22367  122524  106427  000140              MTPS    #140              ;SET PSW TO PRIORITY 7
22368  122530  000240                        NOP                       ;GIVE SOME TIME
22369  122532  042777  000100  175772        BIC     #BIT6,@RCSR       ;CLEAR INTERRUPT ENABLE
22370  122540  010377  175776                MOV     R3,@RVECT         ;RESTORE RECEIVE VECTOR
22371  122544  010477  175774                MOV     R4,@RPSW          ;RESTORE RECEIVE PSW VECTOR
22372  122550  000401                        BR      4$
22373  122552                          3$:
22374  122552  104000                        EMT                     ;
22375  122554  010377  175762        4$:     MOV     R3,@RVECT         ;RESTORE RECEIVE VECTOR
22376  122560  005777  175750              TST     @RBUF             ;CLEAR RECEIVER BUFFER
22377
22378
22379                                  ;*****************************************************************************
22380                                  ;TEST 622       TEST THAT RCVR INTERRUPT CLEARS BY READING RBUF
22381                                  ;*****************************************************************************
22382  122564                          TS622:
22383  122564  106427  000340              MTPS    #340              ;SET PSW TO PRIORITY 7
22384  122570  017703  175746                MOV     @RVECT,R3         ;SAVE RECEIVE VECTOR
22385  122574  012777  122660  175740        MOV     #2$,@RVECT        ;POINT RCV VECTOR TO ERROR REPORT
22386  122602  052777  000100  175722        BIS     #BIT6,@RCSR       ;SET RCVR INTERRUPT ENABLE
22387  122610  052777  000004  175720        BIS     #BIT2,@TCSR       ;SET MAINTENANCE WRAP
22388  122616  005077  175716                CLR     @TBUF             ;SEND A CHARACTER
22389  122622  105777  175704        1$:     TSTB    @RCSR             ;WAIT FOR DONE (INTERRUPT)
```

```
                        BPL     1$
                        BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT
                        TST     @RBUF           ;READ RBUF TO CLEAR PENDING INTERRPUT
                        MTPS    #140            ;SET PSW TO PRIORITY 3
                        NOP                     ;ALLOW TIME FOR ANY ERRONEOUS INTERRUPT
                        BIC     #BIT6,@RCSR     ;NO INTERRUPT-CLEAR INT. ENABLE
                        BR      3$
                2$:
                        EMT                     ;
                3$:     MOV     R3,@RVECT       ;RESTORE RECEIVE VECTOR


                ;*******************************************************************************
                ;TEST 623       TEST THAT RESET CLEARS RECEIVE INTERRUPT
                ;*******************************************************************************
                TS623:
                        MTPS    #340            ;SET PSW TO PRIORITY 7
                        MOV     @RVECT,R3       ;SAVE RECEIVE VECTOR
                        MOV     #2$,@RVECT      ;POINT RCV VECTOR TO ERROR REPORT
                        BIS     #BIT6,@RCSR     ;SET RCV INTERRUPT ENABLE
                        BIS     #BIT2,@TCSR     ;SET MAINTENANCE WRAP
                        MOV     #377,@TBUF      ;SEND AN ALL 1'S CHARACTER
                1$:     TSTB    @RCSR           ;WAIT FOR RCV DONE
                        BPL     1$
                        RESET                   ;CLEAR RCV INTERRUPT & RBUF
                        BIS     #BIT6,@RCSR     ;TURN ON RECEIVER INTERRUPT
                        MTPS    #140            ;SET PSW TO PRIORITY 3
                        NOP                     ;ALLOW TIME FOR AN ERRONEOUS INTERRUPT
                        BIC     #BIT6,@RCSR     ;NO INTERRUPT-CLEAR INT. ENABLE
                        BR      3$
                2$:
                        EMT                     ;
                3$:     MOV     R3,@RVECT       ;RESTORE RECEIVE VECTOR


                ;*******************************************************************************
                ;TEST 624       TEST THAT THE "OR" ERROR (BIT14) & "ERROR" (BIT15) CAN BE SET
                ;*******************************************************************************
                TS624:
                        BIS     #BIT2,@TCSR     ;SET MAINTENANCE WRAP
                        MOV     #3,R0           ;SET CHARACTER COUNT TO SEND 3 CHAR.
                1$:     CLR     @TBUF           ;LOAD TRANSMIT BUFFER
                2$:     TSTB    @TCSR           ;WAIT FOR TRANSMIT DONE
                        BPL     2$
                        DEC     R0              ;DECREMENT CHARACTER COUNT
                        BNE     1$              ;BR IF ALL CHARACTERS NOT TRANSMITTED
                        BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT
                        BIT     #BIT14,@RBUF    ;TEST FOR "OR" ERROR FLAG
                        BNE     3$
                        EMT                     ;
                3$:     BIT     #BIT15,@RBUF    ;TEST "ERROR" FLAG
                        BNE     4$
                        EMT                     ;
                4$:     CLR     R0              ;INITIALIZE LOOP COUNTER
                5$:     INC     R0              ;INCREMENT LOOP COUNTER
```

```
22446  123056  001376                          BNE     5$              ;  UNTIL COUNTER = 0
22447  123060  005777  175450                  TST     @RBUF           ;CLEAR RECEIVER BUFFER
22448
22449
22450                                  ;*************************************************************************************
22451                                  ;TEST 625       TEST DATA PATH FROM TRANSMITTER TO RECEIVER USING MAINTENANCE WRAP
22452                                  ;*************************************************************************************
22453  123064                          TS625:
22454  123064  000005                          RESET                   ;CLEAR THE WORLD
22455  123066  005001                          CLR     R1              ;CLEAR REGISTER FOR TEST DATA
22456  123070  052777  000004  175440          BIS     #BIT2,@TCSR     ;SET MAINTENANCE WRAP
22457  123076  105201                  1$:     INCB    R1              ;INCREMENT THE TEST DATA
22458  123100  110177  175434                  MOVB    R1,@TBUF        ;XMIT A CHARACTER
22459  123104  105777  175422          2$:     TSTB    @RCSR           ;WAIT FOR RECEIVER DONE
22460  123110  100375                          BPL     2$
22461  123112  017702  175416                  MOV     @RBUF,R2        ;GET RECEIVED CHARACTER
22462  123116  020102                          CMP     R1,R2           ;COMPARE DATA
22463  123120  001404                          BEQ     3$              ;BR, IF NON-COMPARE
22464  123122  042777  000004  175406          BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT
22465  123130  104000                          EMT                     ;
22466  123132  105701                  3$:     TSTB    R1              ;TEST XMIT DATA FOR ZERO
22467  123134  001360                          BNE     1$              ;IF ALL DATA HES NOT BEEN CHECKED GO BACK
22468  123136  042777  000004  175372          BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT
22469  123144  000167  000050                  JMP     KWSTRT          ;GET TO NEXT TEST
22470
22471  123150  012737  123202  000004  ERROR5: MOV     #1$,@#4         ;SET UP THE TIMEOUT VECTOR
22472  123156  012737  000340  000006          MOV     #340,@#6
22473  123164  005737  177766                  TST     @#177766        ;CHECK TO SEE IF THE POWER FAILED,WILL TRAP
22474                                                                  ;TO 1$ IF UNIBUS MAP BOARD IS NOT PRESENT
22475                                                                  ;SINCE THE CPUERR(177766)IS ON THE UNIBUS
22476                                                                  ;MAP BOARD
22477  123170  001404                          BEQ     1$              ;NO,GO REPORT THE ERROR
22478  123172  012737  000177  001002          MOV     #177,@#$FATAL   ;YES,FLAG THAT THE POWER FAILED
22479  123200  000403                          BR      2$              ; AND GO SET FATAL ERROR FLAG
22480  123202  012737  000004  001002  1$:     MOV     #4,@#$FATAL     ;SET UP FATAL ERROR NUMBER
22481  123210  012767  000001  055562  2$:     MOV     #1,$MSGTY       ;SET FATAL ERROR FLAG
22482  123216  000777                  SL1HLT: BR      .
22483
22484
22485  123220  032777  000010  076076  KWSTRT: BIT     #10,@SWR
22486  123226  001402                          BEQ     1$
22487  123230  000167  001246                  JMP     SLU2ST
22488  123234  012737  000005  001004  1$:     MOV     #5,@#$TESTN     ;PUT TEST NUMBER IN MAILBOX
22489  123242  012737  124412  000030          MOV     #ERROR6,@#30    ;SET UP ERROR CALL
22490
22491  123250                          LKSTST:
22492                                  ;*************************************************************************************
22493                                  ;TEST 626       TEST ABILITY TO ACCESS LKS
22494                                  ;*************************************************************************************
22495  123250                          TS626:
22496  123250  013703  000004                  MOV     @#4,R3          ;SAVE TIMEOUT VECTOR
22497  123254  012737  123270  000004          MOV     #1$,@#4         ;SET UP TIMEOUT VECTOR
22498  123262  005777  175264                  TST     @LKS            ;ACCESS LKS
22499  123266  000401                          BR      2$
22500  123270                          1$:
22501  123270  104000                          EMT                     ;
```

```
22502  123272  010337  000004          2$:     MOV     R3,@#4          ;RESTORE TIMEOUT VECTOR
22503
22504                                  ;*************************************************************************************
22505                                  ;TEST 627       TEST THAT BIT6 OF LKS CAN BE SET & RESET
22506                                  ;*************************************************************************************
22507  123276                          TS627:
22508  123276  017703  175252                  MOV     @RTCVT,R3       ;SAVE LINE CLOCK VECTOR
22509  123302  012777  123324  175244          MOV     #1$,@RTCVT      ;SET UP INTERRUPT VECTOR FOR ERROR REPORT
22510  123310  106427  000340                  MTPS    #340            ;SET PSW TO PRIORITY 7
22511  123314  032777  000100  175230          BIT     #BIT6,@LKS      ;TEST BIT6 OF LKS
22512  123322  001401                          BEQ     2$
22513  123324                          1$:
22514  123324  104000                          EMT                     ;
22515  123326  052777  000100  175216  2$:     BIS     #BIT6,@LKS      ;SET BIT6 OF LKS
22516  123334  032777  000100  175210          BIT     #BIT6,@LKS      ;TEST BIT6 OF LKS
22517  123342  001001                          BNE     3$
22518  123344  104000                          EMT                     ;
22519  123346  042777  000100  175176  3$:     BIC     #BIT6,@LKS      ;CLEAR BIT6 OF LKS
22520  123354  032777  000100  175170          BIT     #BIT6,@LKS      ;TEST BIT6 OF LK
22521  123362  001401                          BEQ     4$
22522  123364  104000                          EMT                     ;
22523  123366  032737  000001  001020  4$:     BIT     #1,@#$ENV       ;ARE WE RUNNING UNDER APT
22524  123374  001403                          BEQ     70$             ;IF NO THEN DO TEST
22525  123376  005737  001006                  TST     @#$PASS         ;IS THIS FIRST PASS
22526  123402  001011                          BNE     5$              ;IF NO SKIP TO TEST END
22527  123404                          70$:
22528  123404  052777  000100  175140          BIS     #BIT6,@LKS      ;SET BIT6 OF LKS
22529  123412  000005                          RESET                   ;CLEAR BIT6 OF LKS WITH PESET
22530  123414  032777  000100  175130          BIT     #BIT6,@LKS      ;TEST BIT6 OF LKS
22531  123422  001401                          BEQ     5$
22532  123424  104000                          EMT                     ;
22533  123426  010377  175122          5$:     MOV     R3,@RTCVT       ;RESTORE LINE CLOCK VECTOR
22534
22535                                  ;*************************************************************************************
22536                                  ;TEST 630       TEST THAT BIT7 OF LKS SETS & CAN BE CLEARED
22537                                  ;*************************************************************************************
22538  123432                          TS630:
22539  123432                          1$:
22540  123432  032737  000001  001020          BIT     #1, @#$ENV      ;ARE WE RUNNING UNDER APT
22541  123440  001403                          BEQ     70$             ;IF NO THEN DO TEST
22542  123442  005737  001006                  TST     @#$PASS         ;IS THIS FIRST PASS
22543  123446  001032                          BNE     TS631           ;IF NO THEN SHIP TO NEXT TEST
22544  123450                          70$:
22545  123450  105777  175076                  TSTB    @LKS            ;TEST FOR BIT7 OF LKS
22546  123454  100401                          BMI     2$
22547  123456  104000                          EMT                     ;
22548  123460  042777  000200  175064  2$:     BIC     #BIT7,@LKS      ;CLEAR BIT7 OF LKS
22549  123466  032777  000200  175056          BIT     #BIT7,@LKS      ;TEST BIT7 OF LKS
22550  123474  001410                          BEQ     3$
22551  123476  042777  000200  175046          BIC     #BIT7,@LKS      ;TRY ONE MOR TIME BECAUSE THE CLOCK MAY
22552  123504  032777  000200  175040          BIT     #BIT7,@LKS      ;MAY HAVE SET IMMEDIATELY AFTER THE FIRST CLEAR
22553  123512  001401                          BEQ     3$
22554  123514  104000                          EMT                     ;
22555  123516  005000                  3$:     CLR     R0              ;CLEAR TIMER
22556  123520  105777  175026          CONT1:  TSTB    @LKS            ;TEST FOR BIT7 OF LKS
22557  123524  100403                          BMI     1$              ;BR, IF SET
```

```
22558  123526  005200                          INC     R0              ;INCREMENT TIMER
22559  123530  001373                          BNE     CONT1
22560  123532  104000                          EMT                     ;
22561  123534                          1$:
22562
22563
22564                                  ;*************************************************************************************
22565                                  ;TEST 631       TEST THAT THE REAL TIME CLOCK INTERRUPTS PROPERLY
22566                                  ;*************************************************************************************
22567  123534                          TS631:
22568  123534  106427  000340                  MTPS    #340            ;SET PSW TO PRIORITY 7
22569  123540  017703  175010                  MOV     @RTCVT,R3       ;SAVE LINE CLOCK VECTOR
22570  123544  017704  175006                  MOV     @RTCPSW,R4      ;SAVE LINE CLOCK PSW VECTOR
22571  123550  012777  123612  174776          MOV     #2$,@RTCVT      ;SET RTC INTERRUPT VECTOR TO ERROR REPORT
22572  123556  012777  000340  174772          MOV     #340,@RTCPSW    ;KEEP PRIORITY AT 7
22573  123564  042777  000200  174760          BIC     #BIT7,@LKS      ;CLEAR CLOCK DONE FLAG
22574  123572  052777  000100  174752          BIS     #BIT6,@LKS      ;SET INTERRUPT ENABLE
22575  123600  105777  174746          1$:     TSTB    @LKS            ;WAIT FOR RTC DONE(INTERRUPT REQUEST)
22576  123604  100375                          BPL     1$
22577  123606  000240                          NOP                     ;GIVE TIME FOR ANY INTERRUPTS
22578  123610  000401                          BR      3$
22579  123612                          2$:
22580  123612  104000                          EMT                     ;
22581  123614  005077  174732          3$:     CLR     @LKS            ;DISABLE RTC INTERRUPTS & CLEAR DONE
22582  123620  012777  123644  174726          MOV     #4$,@RTCVT      ;SET RTC INTERRUPT VECTOR FOR ERROR
22583  123626  106427  000240                  MTPS    #240            ;CHANGE PSW TO PRIORITY 5
22584  123632  105777  174714          20$:    TSTB    @LKS            ;WAIT FOR DONE (INTERRUPT REQUEST)
22585  123636  100375                          BPL     20$
22586  123640  000240                          NOP                     ;GIVE TIME FOR ANY INTERRUPT
22587  123642  000401                          BR      5$
22588  123644                          4$:
22589  123644  104000                          EMT                     ;
22590  123646  012777  123702  174700  5$:     MOV     #7$,@RTCVT      ;POINT RTC VECTOR TO END OF TEST
22591  123654  042777  000200  174670          BIC     #BIT7,@LKS      ;CLEAR CLOCK DONE FLAG
22592  123662  052777  000100  174662          BIS     #BIT6,@LKS      ;ALLOW INTERRUPTS
22593  123670  105777  174656          6$:     TSTB    @LKS            ;WAIT FOR RTC DONE
22594  123674  100375                          BPL     6$
22595  123676  000240                          NOP                     ;GIVE TIME FOR INTERRUPT
22596
22597  123700  104000                          EMT                     ;RTC INTERRUPT DID NOT OCCUR
22598
22599  123702  022626                  7$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
22600  123704  042777  000100  174640          BIC     #BIT6,@LKS      ;DISABLE INTERRUPTS
22601  123712  010377  174636                  MOV     R3,@RTCVT       ;RESTORE LINE CLOCK VECTOR
22602  123716  010477  174634                  MOV     R4,@RTCPSW      ;RESTORE LINE CLOCK PSW VECTOR
22603
22604
22605
22606
22607
22608                                  ;*************************************************************************************
22609                                  ;TEST 632       TEST RTC FOR DOUBLE INTERRUPTS
22610                                  ;*************************************************************************************
22611  123722                          TS632:
22612  123722  032737  000001  001020          BIT     #1, @#$ENV      ;ARE WE RUNNING UNDER APT
22613  123730  001403                          BEQ     70$             ;IF NO THEN DO TEST
```

```
22614  123732  005737  001006          TST     @#$PASS         ;IS THIS FIRST PASS
22615  123736  001047                  BNE     TS633           ;IF NO THEN SHIP TO NEXT TEST
22616  123740                  70$:
22617  123740  017703  174610          MOV     @RTCVT,R3       ;SAVE LINE CLOCK VECTOR
22618  123744  017704  174606          MOV     @RTCPSW,R4      ;SAVE LINE CLOCK PSW VECTOR
22619  123750  012777  124016  174576  MOV     #2$,@RTCVT      ;SET UP RTC INTERRUPT VECTOR
22620  123756  012777  000340  174572  MOV     #340,@RTCPSW    ;DISALLOW INTERRUPTS AFTER THE INTERRUPT
22621  123764  106427  000240          MTPS    #240            ;SET PSW TO PRIORITY 5
22622  123770  042777  000200  174554  BIC     #BIT7,@LKS      ;CLEAR CLOCK DONE FLAG
22623  123776  052777  000100  174546  BIS     #BIT6,@LKS      ;ENABLE CLOCK INTERRUPTS
22624  124004  105777  174542  1$:     TSTB    @LKS            ;WAIT FOR DONE
22625  124010  100375                  BPL     1$
22626  124012  000240                  NOP                     ;GIVE TIME FOR ANY INTERRUPT
22627
22628  124014  104000                  EMT                     ;RTC INTERRUPT DID NOT OCCUR
22629
22630  124016  022626          2$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
22631  124020  012777  124036  174526  MOV     #3$,@RTCVT      ;POINT RTC VECTOR TO ERROR REPORT
22632  124026  106427  000240          MTPS    #240            ;SET PSW TO PRIORITY 5
22633  124032  000240                  NOP                     ;GIVE SOME TIME FOR AN INTERRUPT
22634  124034  000401                  BR      4$
22635  124036                  3$:
22636  124036  104000                  EMT                     ;
22637  124040  042777  000100  174504  4$:     BIC     #BIT6,@LKS      ;DISABLE CLOCK INTERRUPTS
22638  124046  010377  174502          MOV     R3,@RTCVT       ;RESTORE LINE CLOCK VECTOR
22639  124052  010477  174500          MOV     R4,@RTCPSW      ;RESTORE LINE CLOCK PSW VECTOR
22640
22641
22642                           ;*****************************************************************************************
22643                           ;TEST 633       TEST THAT RTC INTERRUPT CLEARS WITH RESET
22644                           ;*****************************************************************************************
22645  124056                  TS633:
22646  124056  032737  000001  001020          BIT     #1, @#$ENV      ;ARE WE RUNNING UNDER APT
22647  124064  001403                  BEQ     70$             ;IF NO THEN DO TEST
22648  124066  005737  001006          TST     @#$PASS         ;IS THIS FIRST PASS
22649  124072  001033                  BNE     TS634           ;IF NO THEN SHIP TO NEXT TEST
22650  124074                  70$:
22651  124074  106427  000340          MTPS    #340            ;SET PSW TO PRIORITY 7
22652  124100  017703  174450          MOV     @RTCVT,R3       ;SAVE LINE CLOCK VECTOR
22653  124104  012777  124154  174442  MOV     #2$,@RTCVT      ;POINT RTC VECTOR TO ERROR REPORT
22654  124112  042777  000200  174432  BIC     #BIT7,@LKS      ;CLEAR CLOCK DONE FLAG
22655  124120  052777  000100  174424  BIS     #BIT6,@LKS      ;ENABLE CLOCK INTERRUPTS
22656  124126  105777  174420  1$:     TSTB    @LKS            ;WAIT FOR DONE (INTERRUPT REQUEST)
22657  124132  100375                  BPL     1$
22658  124134  000005                  RESET                   ;CLEAR PENDING INTERRUPT WITH RESET
22659  124136  106427  000240          MTPS    #240            ;SET PSW TO PRIORITY 5
22660  124142  000240                  NOP                     ;GIVE TIME FOR ANY INTERRUPT
22661  124144  042777  000100  174400  BIC     #BIT6,@LKS      ;DISALLOW INTERRUPTS
22662  124152  000401                  BR      3$
22663  124154                  2$:
22664  124154  104000                  EMT                     ;
22665  124156  010377  174372  3$:     MOV     R3,@RTCVT       ;RESTORE LINE CLOCK VECTOR
22666
22667
22668                           ;*****************************************************************************************
22669                           ;TEST 634       TEST THAT RTC INTERRUPT CLEARS BY CLEARING BIT7 OF LKS
```

```
                                ;*****************************************************************************
                                ;TS634:
124162                          TS634:
124162  106427  000340                  MTPS    #340            ;SET PSW TO PRIORITY 7
124166  017703  174362                  MOV     @RTCVT,R3       ;SAVE LINE CLOCK VECTOR
124172  012777  124246  174354          MOV     #2$,@RTCVT      ;POINT RTC VECTOR TO ERROR REPORT
124200  042777  000200  174344          BIC     #BIT7,@LKS      ;CLEAR CLOCK DONE FLAG
124206  052777  000100  174336          BIS     #BIT6,@LKS      ;ENABLE CLOCK INTERRUPTS
124214  105777  174332          1$:     TSTB    @LKS            ;WAIT FOR DONE (INTERRUPT REQUEST)
124220  100375                          BPL     1$
124222  042777  000200  174322          BIC     #BIT7,@LKS      ;CLEAR DONE & INTERRUPT
124230  106427  000240                  MTPS    #240            ;SET PSW TO PRIORITY 5
124234  000240                          NOP                     ;GIVE TIME FOR ANY INTERRUPT
124236  042777  000100  174306          BIC     #BIT6,@LKS      ;DISALLOW INTERRUPTS
124244  000401                          BR      3$
124246                          2$:
124246  104000                          EMT                     ;

124250  010377  174300          3$:     MOV     R3,@RTCVT       ;RESTORE LINE CLOCK VECTOR
124254  106427  000340                  MTPS    #340            ;SET PSW TO PRIORITY 7


                                ;*****************************************************************************
                                ;TEST 635       TEST CLOCK REPEATABILITY
                                ;*****************************************************************************
124260                          TS635:
124260  032737  000001  001020          BIT     #1,@#$ENV       ;ARE WE RUNNING UNDER APT
124266  001403                          BEQ     70$             ;IF NO GO DO TEST
124270  005737  001006                  TST     @#$PASS         ;IS THIS FIRST PASS
124274  001102                          BNE     SLU2ST          ;IF NO THEN SKIP REST OF RTC TESTING
124276                          70$:
124276  042777  000100  174246          BIC     #BIT6,@LKS      ;DISALLOW INTERRUPTS

124304  005000                          CLR     R0              ;CLEAR A TIMER
124306  012701  177777                  MOV     #-1,R1          ;SET A FLAG INDICATING FIRST PASS THRU THIS LOOP
124312  005002                  1$:     CLR     R2              ;CLEAR CLOCK COUNTER
124314  005077  174232                  CLR     @LKS            ;CLEAR DONE
124320  105777  174226          2$:     TSTB    @LKS            ;SYNC ON DONE
124324  100375                          BPL     2$
124326  005077  174220                  CLR     @LKS            ;CLEAR DONE
124332  105777  174214          3$:     TSTB    @LKS            ;IS CLOCK DONE?
124336  100003                          BPL     4$              ;BR IF NOT , TO INCREMENT TIMER
124340  005202                          INC     R2              ;IF DONE, INCREMENT CLOCK COUNT
124342  005077  174204                  CLR     @LKS            ;CLEAR DONE
124346  005200                  4$:     INC     R0              ;INCREMENT TIMER
124350  001370                          BNE     3$              ;BR IF TIME REMAINS
124352  005201                          INC     R1              ;INCREMENT LOOP PASS FLAG
124354  001003                          BNE     CMPARE          ;BR IF TWO PASSES HAVE BEEN MADE
124356  010267  000024                  MOV     R2,KFIRST       ;IF NOT, STORE FIRST CLOCK COUNT
124362  000753                          BR      1$              ;DO LOOP AGAIN
124364  016701  000016          CMPARE: MOV     KFIRST,R1       ;RECALL FIRST CLOCK COUNT
124370  160201                          SUB     R2,R1           ;CALCULATE DIFFERENCE OF TWO COUNTS
124372  100001                          BPL     TOLER           ;IF POSITIVE,SKIP NEGATION OF DIFFERENCE
124374  005401                          NEG     R1              ;MAKE DIFFERENCE A POSITIVE NUMBER
124376  020127  000002          TOLER:  CMP     R1,#2           ;COMPARE DIFFERENCE WITH DESIRED TOLERANCE
124402  003437                          BLE     SLU2ST
124404  104000                          EMT                     ;
```

```
22726
22727  124406  000000                  KFIRST: .WORD   0
22728  124410  000000                  SECND:  .WORD   0
22729
22730
22731  124412  012737  124444  000004  ERROR6: MOV     #1$,@#4         ;SET UP THE TIMEOUT VECTOR
22732  124420  012737  000340  000006          MOV     #340,@#6
22733  124426  005737  177766                  TST     @#177766        ;CHECK TO SEE IF THE POWER FAILED,WILL TRAP
22734                                                                   ;TO 1$ IF UNIBUS MAP BOARD IS NOT PRESENT
22735                                                                   ;SINCE THE CPUERR(177766)IS ON THE UNIBUS
22736                                                                   ;MAP BOARD
22737  124432  001404                          BEQ     1$              ;NO,GO REPORT THE ERROR
22738  124434  012737  000177  001002          MOV     #177,@#$FATAL   ;YES,FLAG THAT THE POWER FAILED
22739  124442  000403                          BR      2$              ; AND GO SET FATAL ERROR FLAG
22740  124444  012737  000005  001002  1$:     MOV     #5,@#$FATAL                     ;SET UP FATAL ERROR NUMBER
22741  124452  012767  000001  054320  2$:     MOV     #1,$MSGTY                       ;SET FATAL ERROR FLAG
22742  124460  000777                  LTCHLT: BR      .
22743
22744                                  ;SERIAL LINE UNIT REGISTER AND VECTOR ADDRESSES FOR SLU2
22745
22746  124462  176500                  RCSR2:  176500                  ;ADDRESS OF RECEIVER COMMAND/STATUS REGISTER
22747  124464  176502                  RBUF2:  176502                  ;ADDRESS OF RECEIVER BUFFER
22748  124466  176504                  TCSR2:  176504                  ;ADDRESS OF TRANSMITTER COMMAND/STATUS REGISTER
22749  124470  176506                  TBUF2:  176506                  ;ADDRESS OF TRANSMITTER BUFFER
22750  124472  000300                  RVECT2: 300                     ;RECEIVER INTERRUPT VECTOR
22751  124474  000302                  RPSW2:  302
22752  124476  000304                  TVECT2: 304                     ;TRANSMITTER INTERRUPT VECTOR
22753  124500  000306                  TPSW2:  306
22754
22755  124502  032777  000020  074614  SLU2ST: BIT     #20,@SWR
22756  124510  001402                          BEQ     1$
22757  124512  000167  002610                  JMP     UNIQUE
22758  124516  012737  000006  001004  1$:     MOV     #6,@#$TESTN     ;PUT TEST NUMBER IN MAILBOX
22759  124524  012737  127234  000030          MOV     #ERROR7,@#30    ;SET UP FOR CORRECT ERROR CALL
22760
22761
22762                                  ;*****************************************************************************
22763                                  ;TEST 636       TEST ABILITY TO REFERENCE TCSR2
22764                                  ;*****************************************************************************
22765  124532                          TS636:
22766  124532  013703  000004                  MOV     @#4,R3          ;SAVE TIMEOUT VECTOR
22767  124536  012737  124552  000004          MOV     #1$,@#4         ;SET UP TIMEOUT VECTOR
22768  124544  005777  177716                  TST     @TCSR2          ;REFERENCE THE XMIT COMMAND/STATUS REG.
22769  124550  000401                          BR      4$
22770  124552                          1$:
22771  124552  104000                          EMT                     ;
22772  124554  010337  000004          4$:     MOV     R3,@#4          ;RESTORE TIMEOUT VECTOR
22773
22774
22775
22776                                  ;*****************************************************************************
22777                                  ;TEST 637       TEST ABILITY TO REFERENCE TBUF2
22778                                  ;*****************************************************************************
22779  124560                          TS637:
22780  124560  013703  000004                  MOV     @#4,R3          ;SAVE TIMEOUT VECTOR
22781  124564  012737  124600  000004          MOV     #1$,@#4         ;SET UP TIMEOUT VECTOR
```

```
22782  124572  005777  177672          TST     @TBUF2          ;REFERENCE THE XMIT BUFFER
22783  124576  000401                  BR      4$
22784  124600                  1$:
22785  124600  104000                  EMT                     ;
22786  124602  010337  000004  4$:     MOV     R3,@#4          ;RESTORE TIMEOUT VECTOR
22787
22788
22789                          ;*************************************************************************************
22790                          ;TEST 640       TEST THAT TCSR2 BIT7(DONE) CLEARS WHEN XBUF IS LOADED
22791                          ;*************************************************************************************
22792  124606                  TS640:
22793  124606  032737  000001  001020          BIT     #1, @#$ENV      ;ARE WE RUNNING UNDER APT
22794  124614  001403                  BEQ     70$             ;IF NO THEN DO TEST
22795  124616  005737  001006          TST     @#$PASS         ;IS THIS FIRST PASS
22796  124622  001022                  BNE     TS641           ;IF NO THEN SHIP TO NEXT TEST
22797  124624                  70$:
22798  124624  005077  177640          CLR     @TBUF2          ;LOAD XBUF
22799  124630  105777  177632          TSTB    @TCSR2          ;CHECK DONE
22800  124634  100006                  BPL     3$              ;BR IF CLEAR
22801                                                          ;FILL SECOND BUFFER BECUASE REFRESH COULD CAUSE
22802                                                          ;FIRST TEST TO FAIL
22803  124636  005077  177626          CLR     @TBUF2          ;FILL DOUBLE BUFFER
22804  124642  105777  177620          TSTB    @TCSR2          ;CHECK DONE
22805  124646  100001                  BPL     3$
22806  124650  104000                  EMT                     ;
22807  124652  005000          3$:     CLR     R0              ;CLEAR TIMER
22808  124654  105777  177606  4$:     TSTB    @TCSR2          ;CHECK FOR XMIT DONE
22809  124660  100403                  BMI     5$              ;IF DONE SETS, BR TO END OF TEST
22810  124662  005200                  INC     R0              ;INCREMENT TIMER
22811  124664  001373                  BNE     4$
22812  124666  104000                  EMT                     ;
22813  124670                  5$:
22814
22815
22816                          ;*************************************************************************************
22817                          ;TEST 641       TEST THAT TCSR2 "DONE" SETS WITH RESET
22818                          ;*************************************************************************************
22819  124670                  TS641:
22820  124670  032737  000001  001020          BIT     #1, @#$ENV      ;ARE WE RUNNING UNDER APT
22821  124676  001403                  BEQ     70$             ;IF NO THEN DO TEST
22822  124700  005737  001006          TST     @#$PASS         ;IS THIS FIRST PASS
22823  124704  001015                  BNE     TS642           ;IF NO THEN SHIP TO NEXT TEST
22824  124706                  70$:
22825  124706  005077  177556          CLR     @TBUF2          ;LOAD TRANSMIT BUFFER
22826  124712  105777  177550  1$:     TSTB    @TCSR2          ;WAIT FOR DONE
22827  124716  100375                  BPL     1$
22828  124720  005077  177544          CLR     @TBUF2          ;LOAD SECOND BUFFER
22829  124724  000240                  NOP
22830  124726  000005                  RESET                   ;SET DONE WITH RESET
22831  124730  105777  177532          TSTB    @TCSR2          ;CHECK FOR DONE SET
22832  124734  100401                  BMI     TS642
22833  124736  104000                  EMT                     ;
22834
22835
22836
22837                          ;*************************************************************************************
```

```
                                        ;TEST 642       TEST ABILITY TO ACCESS RCSR2
                                        ;*************************************************************************************
                                        TS642:
                        013703  000004          MOV     @#4,R3          ;SAVE TIMEOUT VECTOR
                        012737  124760  000004  MOV     #1$,@#4         ;SET UP TIMEOUT VECTOR
                        005777  177504          TST     @RCSR2          ;ACCESS RCSR
                        000401                  BR      2$
                                        1$:
                        104000                  EMT                     ;
                        010337  000004  2$:     MOV     R3,@#4          ;RESTORE TIMEOUT VECTOR

                                        ;*************************************************************************************
                                        ;TEST 643       TEST ABILITY TO ACCESS RBUF2
                                        ;*************************************************************************************
                                        TS643:
                        013703  000004          MOV     @#4,R3          ;SAVE TIMEOUT VECTOR
                        012737  125006  000004  MOV     #1$,@#4         ;SET UP TIMEOUT VECTOR
                        005777  177460          TST     @RBUF2          ;ACCESS RBUF
                        000401                  BR      2$
                                        1$:
                        104000                  EMT                     ;
                        010337  000004  2$:     MOV     R3,@#4          ;RESTORE TIMEOUT VECTOR

                                        ;*************************************************************************************
                                        ;TEST 644       TEST THAT BIT0(BREAK BIT) CAN BE SET & CLEARED & RESET
                                        ;*************************************************************************************
                                        TS644:
                        032777  000001  177444          BIT     #BIT0,@TCSR2    ;CHECK BIT0 OF TCSR CLEAR
                        001401                          BEQ     3$
                        104000                          EMT                     ;
                        052777  000001  177432  3$:     BIS     #BIT0,@TCSR2    ;SET BIT0 IN TCSR
                        032777  000001  177424          BIT     #BIT0,@TCSR2    ;TEST BIT0 OF TCSR
                        001001                          BNE     4$
                        104000                          EMT                     ;
                        042777  000001  177412  4$:     BIC     #BIT0,@TCSR2    ;CLEAR BIT0 OF TCSR
                        032777  000001  177404          BIT     #BIT0,@TCSR2    ;TEST BIT0 OF TCSR
                        001401                          BEQ     7$
                        104000                          EMT                     ;
                                        7$:
                        032737  000001  001020          BIT     #1, @#$ENV      ;ARE WE RUNNING UNDER APT
                        001403                          BEQ     70$             ;IF NO THEN DO TEST
                        005737  001006                  TST     @#$PASS         ;IS THIS FIRST PASS
                        001011                          BNE     TS645           ;IF NO THEN SHIP TO NEXT TEST
                                        70$:
                        052777  000001  177354          BIS     #BIT0,@TCSR2    ;SET BIT0 IN TCSR
                        000005                          RESET                   ;CLEAR BIT0 WITH RESET
                        032777  000001  177344          BIT     #BIT0,@TCSR2    ;TEST BIT0 CLEAR
                        001401                          BEQ     TS645
                        104000                          EMT                     ;
```

```
22894
22895                                   ;*****************************************************************************
22896                                   ;TEST 645       TEST THAT BIT6(XMIT INT EN) CAN BE SET & RESET
22897                                   ;*****************************************************************************
22898  125126                           TS645:
22899  125126  017703  177344                   MOV     @TVECT2,R3      ;SAVE XMIT VECTOR
22900  125132  012777  125154  177336           MOV     #1$,@TVECT2     ;SET UP INTERRUPT VECTOR FOR ERROR REPORT
22901  125140  106427  000340                   MTPS    #340            ;SET PSW TO PRIORITY 7
22902  125144  032777  000100  177314           BIT     #BIT6,@TCSR2    ;TEST BIT6 OF TCSR
22903  125152  001401                           BEQ     2$
22904  125154                           1$:
22905  125154  104000                           EMT                     ;
22906  125156  052777  000100  177302  2$:      BIS     #BIT6,@TCSR2    ;SET BIT6 OF TCSR
22907  125164  032777  000100  177274           BIT     #BIT6,@TCSR2    ;TEST BIT6 OF TCSR
22908  125172  001001                           BNE     3$
22909  125174  104000                           EMT                     ;
22910  125176  042777  000100  177262  3$:      BIC     #BIT6,@TCSR2    ;CLEAR BIT6 OF TCSR
22911  125204  032777  000100  177254           BIT     #BIT6,@TCSR2    ;TEST BIT6 OF TCSR
22912  125212  001401                           BEQ     4$
22913  125214  104000                           EMT                     ;
22914  125216  032737  000001  001020  4$:      BIT     #1,@#$ENV       ;ARE WE RUNNING UNDER APT
22915  125224  001403                           BEQ     70$             ;IF NO THEN DO TEST
22916  125226  005737  001006                   TST     @#$PASS         ;IF THIS FIRST PASS
22917  125232  001011                           BNE     5$              ;IF NO THEN SKIP TO END OF TEST
22918  125234                           70$:
22919  125234  052777  000100  177224           BIS     #BIT6,@TCSR2    ;SET BIT6 OF TCSR
22920  125242  000005                           RESET                   ;CLEAR BIT6 WITH RESET
22921  125244  032777  000100  177214           BIT     #BIT6,@TCSR2    ;TEST BIT6 OF TCSR
22922  125252  001401                           BEQ     5$
22923  125254  104000                           EMT                     ;
22924  125256  010377  177214           5$:      MOV     R3,@TVECT2      ;RESTORE XMIT VECTOR
22925
22926
22927                                   ;*****************************************************************************
22928                                   ;TEST 646       TEST THAT BIT6 OF RCSR2 CAN BE SET & RESET
22929                                   ;*****************************************************************************
22930  125262                           TS646:
22931  125262  017703  177204                   MOV     @RVECT2,R3      ;SAVE RECEIVE VECTOR
22932  125266  012777  125310  177176           MOV     #1$,@RVECT2     ;SET UP INTERRUPT VECTOR FOR ERROR REPORT
22933  125274  106427  000340                   MTPS    #340            ;SET PSW TO PRIORITY 7
22934  125300  032777  000100  177154           BIT     #BIT6,@RCSR2    ;TEST BIT6 OF RCSR
22935  125306  001401                           BEQ     2$
22936  125310                           1$:
22937  125310  104000                           EMT                     ;
22938  125312  052777  000100  177142  2$:      BIS     #BIT6,@RCSR2    ;SET BIT6 OF RCSR
22939  125320  032777  000100  177134           BIT     #BIT6,@RCSR2    ;TEST BIT6 OF RCSR
22940  125326  001001                           BNE     3$
22941  125330  104000                           EMT                     ;
22942  125332  042777  000100  177122  3$:      BIC     #BIT6,@RCSR2    ;CLEAR BIT6 OF RCSR
22943  125340  032777  000100  177114           BIT     #BIT6,@RCSR2    ;TEST BIT6 OF RCSR
22944  125346  001401                           BEQ     4$
22945  125350  104000                           EMT                     ;
22946  125352  032737  000001  001020  4$:      BIT     #1,@#$ENV       ;ARE WE RUNNING UNDER APT
22947  125360  001403                           BEQ     70$             ;IF NO THEN DO TEST
22948  125362  005737  001006                   TST     @#$PASS         ;IS THIS FIRST PASS
22949  125366  001011                           BNE     5$              ;IF NO THEN SKIP TO END OF TEST
```

```
22950  125370
22951  125370  052777  000100  177064  70$:    BIS     #BIT6,@RCSR2    ;SET BIT6 OF RCSR
22952  125376  000005                          RESET                   ;CLEAR BIT6OF RCSR2 WITH RESET
22953  125400  032777  000100  177054          BIT     #BIT6,@RCSR2    ;TEST BIT6 OF RCSR
22954  125406  001401                          BEQ     5$
22955  125410  104000                          EMT                     ;
22956  125412  010377  177054          5$:     MOV     R3,@RVECT2      ;RESTORE RECEIVE VECTOR
22957
22958
22959
22960                                  ;*********************************************************************************************
22961                                  ;TEST 647       TEST THAT XMIT INTERRUPTS ONLY WHEN ENABLED
22962                                  ;*********************************************************************************************
22963  125416                          TS647:
22964  125416  042777  000100  177042          BIC     #BIT6,@TCSR2    ;CLEAR TRANSMIT INTERRUPT ENABLE
22965  125424  017703  177046                  MOV     @TVECT2,R3      ;SAVE XMIT VECTOR
22966  125430  012777  125452  177040          MOV     #2$,@TVECT2     ;POINT XMIT VECTOR TO ERROR REPORT
22967  125436  105777  177024          1$:     TSTB    @TCSR2          ;WAIT FOR DONE
22968  125442  100375                          BPL     1$
22969  125444  106427  000140                  MTPS    #140            ;SET PSW TO PRIORITY 3
22970  125450  000401                          BR      3$
22971  125452                          2$:
22972  125452  104000                          EMT                     ;
22973  125454  012777  125474  177014  3$:     MOV     #4$,@TVECT2     ;SET XMIT VECTOR TO END OF TEST
22974  125462  052777  000100  176776          BIS     #BIT6,@TCSR2    ;ENABLE INTERRUPTS
22975  125470  000240                          NOP
22976
22977  125472  104000                          EMT                     ;XMIT DID NOT INTERRUPT
22978
22979  125474  042777  000100  176764  4$:     BIC     #BIT6,@TCSR2    ;DISABLE INTERRUPTS
22980  125502  022626                          CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
22981  125504  010377  176766                  MOV     R3,@TVECT2      ;RESTORE XMIT VECTOR
22982
22983
22984                                  ;*********************************************************************************************
22985                                  ;TEST 650       TEST THAT XMIT INTERRUPTS DO NOT OCCUR WHEN DISABLED
22986                                  ;*********************************************************************************************
22987  125510                          TS650:
22988  125510  042777  000100  176750          BIC     #BIT6,@TCSR2    ;DISABLE INTERRUPTS
22989  125516  106427  000340                  MTPS    #340            ;SET PSW TO PRIORITY 7
22990  125522  017703  176750                  MOV     @TVECT2,R3      ;SAVE XMIT VECTOR
22991  125526  012777  125554  176742          MOV     #2$,@TVECT2     ;POINT XMIT VECTOR TO ERROR REPORT
22992  125534  105777  176726          1$:     TSTB    @TCSR2          ;WAIT FOR DONE
22993  125540  100375                          BPL     1$
22994  125542  052777  000100  176716          BIS     #BIT6,@TCSR2    ;ENABLE INTERRUPT
2299   125550  000240                          NOP
22996  125552  000401                          BR      3$
22997  125554                          2$:
22998  125554  104000                          EMT                     ;
22999  125556  042777  000100  176702  3$:     BIC     #BIT6,@TCSR2    ;CLEAR INTERRUPT ENABLE
23000  125564  012777  125602  176704          MOV     #4$,@TVECT2     ;POINT XMIT VECTOR TO ERROR REPORT
23001  125572  106427  000140                  MTPS    #140            ;SET PSW TO PRIORITY 3
23002  125576  000240                          NOP
23003  125600  000401                          BR      5$
23004  125602                          4$:
23005  125602  104000                          EMT                     ;
```

```
23006  125604  010377  176666          5$:     MOV     R3,@TVECT2      ;RESTORE XMIT VECTOR
23007
23008
23009                                  ;*************************************************************************************
23010                                  ;TEST 651       TEST TRANSMITTER FOR DOUBLE INTERRUPTS
23011                                  ;*************************************************************************************
23012  125610                          TS651:
23013  125610  042777  000100  176650          BIC     #BIT6,@TCSR2    ;CLEAR INTERRUPT ENABLE
23014  125616  017703  176654                  MOV     @TVECT2,R3      ;SAVE XMIT VECTOR
23015  125622  017704  176652                  MOV     @TPSW2,R4       ;SAVE XMIT PSW VECTOR
23016  125626  012777  125666  176642          MOV     #2$,@TVECT2     ;SET UP XMIT VECTOR
23017  125634  012777  000340  176636          MOV     #340,@TPSW2     ;SET PIO 7 AFTER INTERRUPT
23018  125642  106427  000140                  MTPS    #140            ;SET PSW TO PRIORITY 3
23019  125646  105777  176614          1$:     TSTB    @TCSR2          ;WAIT FOR DONE
23020  125652  100375                          BPL     1$
23021  125654  052777  000100  176604          BIS     #BIT6,@TCSR2    ;ENABLE INTERRUPTS
23022  125662  000240                          NOP
23023
23024  125664  104000                          EMT                     ;
23025                                                                  ;XMIT INTERRUPT DID NOT OCCUR
23026  125666  022626                  2$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
23027  125670  012777  125714  176600          MOV     #4$,@TVECT2     ;POINT XMIT VECTOR TO ERROR
23028  125676  106427  000140                  MTPS    #140            ;SET PSW TO PRIORITY 3
23029  125702  000240                          NOP                     ;GIVE TIME FOR ANY INTERRUPTS
23030  125704  042777  000100  176554          BIC     #BIT6,@TCSR2    ;DISABLE INTERRUPTS
23031  125712  000401                          BR      5$
23032  125714                          4$:
23033  125714  104000                          EMT                     ;
23034  125716  010377  176554          5$:     MOV     R3,@TVECT2      ;RESTORE XMIT VECTOR
23035  125722  010477  176552                  MOV     R4,@TPSW2       ;RESTORE XMIT PSW VECTOR
23036
23037                                  ;*************************************************************************************
23038                                  ;TEST 652       TEST THAT XMIT INTERRUPT CLEARS WITH LOADING TBUF2
23039                                  ;*************************************************************************************
23040  125726                          TS652:
23041  125726  032737  000001  001020          BIT     #1, @#$ENV      ;ARE WE RUNNING UNDER APT
23042  125734  001403                          BEQ     70$             ;IF NO THEN DO TEST
23043  125736  005737  001006                  TST     @#$PASS         ;IS THIS FIRST PASS
23044  125742  001043                          BNE     TS653           ;IF NO THEN SHIP TO NEXT TEST
23045  125744                          70$:
23046  125744  042777  000100  176514          BIC     #BIT6,@TCSR2    ;DISABLE INTERRUPTS
23047  125752  106427  000340                  MTPS    #340            ;SET PSW TO PRIORITY 7
23048  125756  017703  176514                  MOV     @TVECT2,R3      ;SAVE XMIT VECTOR
23049  125762  012777  126032  176506          MOV     #2$,@TVECT2     ;POINT XMIT VECTOR TO ERROR
23050  125770  052777  000100  176470          BIS     #BIT6,@TCSR2    ;ENABLE INTERRUPTS
23051  125776  005077  176466                  CLR     @TBUF2          ;LOAD TBUF
23052  126002  105777  176460          1$:     TSTB    @TCSR2          ;WAIT FOR DONE (INTERRUPT)
23053  126006  100375                          BPL     1$
23054  126010  005077  176454                  CLR     @TBUF2          ;FILL SECOND BUFFER TO RESET INT.
23055  126014  106427  000140                  MTPS    #140            ;SET PSW TO PRIORITY 3
23056  126020  000240                          NOP                     ;GIVE TIME FOR ANY INTERRUPTS
23057  126022  042777  000100  176436          BIC     #BIT6,@TCSR2    ;DISABLE INTERRUPTS
23058  126030  000401                          BR      3$
23059  126032                          2$:
23060  126032  104000                          EMT                     ;
23061  126034  010377  176436          3$:     MOV     R3,@TVECT2      ;RESTORE XMIT VECTOR
```

```
23062  126040  005000                          CLR     R0              ;INIT LOOP COUNTER
23063  126042  005200                  4$:     INC     R0              ;INCREMENT COUNTER
23064  126044  001376                          BNE     4$              ;UNTIL COUNTER = 0
23065  126046  005777  176412                  TST     @RBUF2          ;CLEAR RECEIVER BUFFER
23066
23067
23068                                  ;*************************************************************************************
23069                                  ;TEST 653       TEST THAT RCVR DONE (7) SET & CLEAR PROPERLY
23070                                  ;*************************************************************************************
23071  126052                          TS653:
23072  126052  005000                          CLR     R0              ;CLEAR A TIMER
23073  126054  005077  176410                  CLR     @TBUF2          ;LOAD TRANSMIT BUFFER
23074  126060  105777  176376          WDONE2: TSTB    @RCSR2          ;CHECK FOR RECEIVER DONE
23075  126064  100403                          BMI     6$              ;BR, IF DONE
23076  126066  005200                          INC     R0              ;INCREMENT TIMER, IF NOT DONE
23077  126070  001373                          BNE     WDONE2
23078  126072  104000                          EMT                     ;RECEIVER DONE NEVER SET
23079
23080  126074  032737  000001  001020  6$:     BIT     #1,@#$ENV       ;ARE WE RUNNING UNDER APT
23081  126102  001403                          BEQ     70$             ;IF NO THEN DO TEST
23082  126104  005737  001006                  TST     @#$PASS         ;IS THIS FIRST PASS
23083  126110  001005                          BNE     2$              ;IF NO THEN SKIP TO END OF TEST
23084  126112                          70$:
23085  126112  000005                          RESET                   ;CLEAR DONE WITH RESET
23086  126114  105777  176342                  TSTB    @RCSR2          ;CHECK FOR DONE CLEAR
23087  126120  001401                          BEQ     2$
23088  126122  104000                          EMT                     ;RESET DID NOT CLEAR RCVR DONE
23089  126124  005000                  2$:     CLR     R0              ;INIT LOOP COUNTER
23090  126126  005200                  3$:     INC     R0              ;INCREMENT COUNTER
23091  126130  001376                          BNE     3$              ;UNTIL COUNTER = 0
23092  126132  005777  176326                  TST     @RBUF2          ;CLEAR RECEIVER BUFFER
23093
23094
23095                                  ;*************************************************************************************
23096                                  ;TEST 654       TEST THAT READING RBUF2 CLEARS RECEIVER DONE
23097                                  ;*************************************************************************************
23098  126136                          TS654:
23099  126136  005077  176326                  CLR     @TBUF2          ;LOAD TRANSMITTER
23100  126142  105777  176314          1$:     TSTB    @RCSR2          ;WAIT FOR RECEIVER DONE
23101  126146  100375                          BPL     1$
23102  126150  017700  176310                  MOV     @RBUF2,R0       ;READ RECEIVE BUFFER
23103  126154  105777  176302                  TSTB    @RCSR2          ;CHECK FOR RECEIVE DONE CLEAR
23104  126160  001401                          BEQ     TS655
23105  126162  104000                          EMT                     ;
23106                                                                  ;READING RBUF2 DID NOT CLEAR RCVR DONE
23107
23108
23109                                  ;*************************************************************************************
23110                                  ;TEST 655       TEST THAT RCVR INTERRUPTS ONLY WHEN ENABLED
23111                                  ;*************************************************************************************
23112  126164                          TS655:
23113  126164  042777  000100  176274          BIC     #BIT6,@TCSR2    ;DISABLE TRANSMIT INTERRUPTS
23114  126172  042777  000100  176262          BIC     #BIT6,@RCSR2    ;DISABLE RECEIVER INTERRUPTS
23115  126200  017703  176266                  MOV     @RVECT2,R3      ;SAVE RECEIVE VECTOR
23116  126204  012777  126232  176260          MOV     #2$,@RVECT2     ;POINT RCV VECTOR TO ERROR REPORT
23117  126212  106427  000140                  MTPS    #140            ;SET PSW TO PRIORITY 3
```

```
23118  126216  005077  176246          CLR     @TBUF2          ;SEND A CHARACTER
23119  126222  105777  176234  1$:     TSTB    @RCSR2          ;WAIT FOR RECEIVER DONE
23120  126226  100375                  BPL     1$
23121  126230  000401                  BR      3$
23122  126232                  2$:
23123  126232  104000                  EMT                     ;
23124  126234  012777  126254  176230  3$:     MOV     #4$,@RVECT2     ;POINT RCV VECTOR TO END OF TEST
23125  126242  052777  000100  176212          BIS     #BIT6,@RCSR2    ;ENABLE RCV INTERRUPTS
23126  126250  000240                  NOP                     ;GIVE ANY INTERRUPTS TIME
23127  126252  104000                  EMT                     ;
23128  126254  042777  000100  176200  4$:     BIC     #BIT6,@RCSR2    ;DISABLE INTERRUPTS
23129  126262  022626                  CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
23130  126264  005777  176174          TST     @RBUF2          ;CLEAR CHARACTER FROM RECEIVER BUFFER
23131  126270  010377  176176          MOV     R3,@RVECT2      ;RESTORE RECEIVE VECTOR
23132
23133
23134                                  ;*************************************************************************************
23135                                  ;TEST 656       TEST THAT RCVR INTERRUPTS DO NOT OCCUR WHEN DISABLED
23136                                  ;*************************************************************************************
23137  126274                  TS656:
23138  126274  106427  000340          MTPS    #340            ;SET PSW TO PRIORITY 7
23139  126300  017703  176166          MOV     @RVECT2,R3      ;SAVE RECEIVE VECTOR
23140  126304  012777  126336  176160  MOV     #2$,@RVECT2     ;POINT RCVR VECTOR TO ERROR REPORT
23141  126312  005077  176152          CLR     @TBUF2          ;SEND A CHARACTER
23142  126316  105777  176140  1$:     TSTB    @RCSR2          ;WAIT FOR RECEIVER DONE
23143  126322  100375                  BPL     1$
23144  126324  052777  000100  176130  BIS     #BIT6,@RCSR2    ;ENABLE INTERRUPTS
23145  126332  000240                  NOP                     ;GIVE TIME FOR INTERRUPT
23146  126334  000401                  BR      3$
23147  126336                  2$:
23148  126336  104000                  EMT                     ;RCVR INTERRUPTS AT PRIORITY 7
23149  126340  042777  000100  176114  3$:     BIC     #BIT6,@RCSR2    ;CLEAR INTERRUPT ENABLE
23150  126346  012777  126364  176116  MOV     #4$,@RVECT2     ;POINT RCVR VECTOR TO ERROR REPORT
23151  126354  106427  000140          MTPS    #140            ;SET PSW TO PRIORITY 3
23152  126360  000240                  NOP                     ;GIVE TIME FOR ANY INTERRUPT
23153  126362  000401                  BR      5$
23154  126364                  4$:
23155  126364  104000                  EMT                     ;RCVR INTERRUPT REQUEST PASSED WITH BIT6 CLEAR
23156  126366  005777  176072  5$:     TST     @RBUF2          ;CLEAR CHARACTER FROM RECEIVER BUFFER
23157  126372  010377  176074          MOV     R3,@RVECT2      ;RESTORE RECEIVE VECTOR
23158
23159
23160                                  ;*************************************************************************************
23161                                  ;TEST 657       TEST RECEIVER FOR DOUBLE INTERRUPTS
23162                                  ;*************************************************************************************
23163  126376                  TS657:
23164  126376  017703  176070          MOV     @RVECT2,R3      ;SAVE RECEIVE VECTOR
23165  126402  017704  176066          MOV     @RPSW2,R4       ;SAVE RECEIVE PSW VECTOR
23166  126406  012777  126452  176056  MOV     #2$,@RVECT2     ;POINT RCV VECTOR TO CONTINUE TEST
23167  126414  012777  000340  176052  MOV     #340,@RPSW2     ;SET PRIORITY TO 7 AFTER INTERRUPT
23168  126422  106427  000140          MTPS    #140            ;SET PSW TO PRIORITY 3
23169  126426  005077  176036          CLR     @TBUF2          ;SEND A CHARACTER
23170  126432  105777  176024  1$:     TSTB    @RCSR2          ;WAIT FOR RCVR DONE
23171  126436  100375                  BPL     1$
23172  126440  052777  000100  176014  BIS     #BIT6,@RCSR2    ;ENABLE RCV INTERRUPTS
23173  126446  000240                  NOP                     ;GIVE SOME TIME
```

```
23174  126450  104000                          EMT                     ;
23175  126452  022626                  2$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
23176  126454  012777  126510  176010          MOV     #3$,@RVECT2     ;POINT RCV VECTOR TO ERROR REPORT
23177  126462  106427  000140                  MTPS    #140            ;SET PSW TO PRIORITY 3
23178  126466  000240                          NOP                     ;GIVE SOME TIME
23179  126470  042777  000100  175764          BIC     #BIT6,@RCSR2    ;CLEAR INTERRUPT ENABLE
23180  126476  010377  175770                  MOV     R3,@RVECT2      ;RESTORE RECEIVE VECTOR
23181  126502  010477  175766                  MOV     R4,@RPSW2       ;RESTORE RECEIVE PSW VECTOR
23182  126506  000401                          BR      4$
23183  126510                          3$:
23184  126510  104000                          EMT                     ;
23185  126512  005777  175746          4$:     TST     @RBUF2          ;CLEAR CHARACTER FROM RECEIVER BUFFER
23186  126516  010377  175750                  MOV     R3,@RVECT2      ;RESTORE RECEIVE VECTOR
23187
23188
23189                                  ;*******************************************************************************
23190                                  ;TEST 660       TEST THAT RCVR INTERRUPT CLEARS BY READING RBUF2
23191                                  ;*******************************************************************************
23192  126522                          TS660:
23193  126522  106427  000340                  MTPS    #340            ;SET PSW TO PRIORITY 7
23194  126526  017703  175740                  MOV     @RVECT2,R3      ;SAVE RECEIVE VECTOR
23195  126532  012777  126602  175732          MOV     #2$,@RVECT2     ;POINT RCV VECTOR TO ERROR REPORT
23196  126540  052777  000100  175714          BIS     #BIT6,@RCSR2    ;SET RCVR INTERRUPT ENABLE
23197  126546  005077  175716                  CLR     @TBUF2          ;SEND A CHARACTER
23198  126552  105777  175704          1$:     TSTB    @RCSR2          ;WAIT FOR DONE (INTERRUPT)
23199  126556  100375                          BPL     1$
23200  126560  005777  175700                  TST     @RBUF2          ;READ RBUF TO CLEAR PENDING INTERRPUT
23201  126564  106427  000140                  MTPS    #140            ;SET PSW TO PRIORITY 3
23202  126570  000240                          NOP                     ;ALLOW TIME FOR ANY ERRONEOUS INTERRUPT
23203  126572  042777  000100  175662          BIC     #BIT6,@RCSR2    ;NO INTERRUPT-CLEAR INT. ENABLE
23204  126600  000401                          BR      3$
23205  126602                          2$:
23206  126602  104000                          EMT                     ;
23207  126604  010377  175662          3$:     MOV     R3,@RVECT2      ;RESTORE RECEIVE VECTOR
23208
23209
23210
23211                                  ;*******************************************************************************
23212                                  ;TEST 661       TEST THAT RESET CLEARS RECEIVE INTERRUPT
23213                                  ;*******************************************************************************
23214  126610                          TS661:
23215  126610  032737  000001  001020          BIT     #1, @#$ENV      ;ARE WE RUNNING UNDER APT
23216  126616  001403                          BEQ     70$             ;IF NO THEN DO TEST
23217  126620  005737  001006                  TST     @#$PASS         ;IS THIS FIRST PASS
23218  126624  001036                          BNE     TS662           ;IF NO THEN SHIP TO NEXT TEST
23219  126626                          70$:
23220  126626  106427  000340                  MTPS    #340            ;SET PSW TO PRIORITY 7
23221  126632  017703  175634                  MOV     @RVECT2,R3      ;SAVE RECEIVE VECTOR
23222  126636  012777  126714  175626          MOV     #2$,@RVECT2     ;POINT RCV VECTOR TO ERROR REPORT
23223  126644  052777  000100  175610          BIS     #BIT6,@RCSR2    ;SET RCV INTERRUPT ENABLE
23224  126652  012777  000377  175610          MOV     #377,@TBUF2     ;SEND AN ALL 1'S CHARACTER
23225  126660  105777  175576          1$:     TSTB    @RCSR2          ;WAIT FOR RCV DONE
23226  126664  100375                          BPL     1$
23227  126666  000005                          RESET                   ;CLEAR RCV INTERRUPT & RBUF2
23228  126670  052777  000100  175564          BIS     #BIT6,@RCSR2    ;SET RECEIVER INTERRUPT
23229  126676  106427  000140                  MTPS    #140            ;SET PSW TO PRIORITY 3
```

```
23230  126702  000240                          NOP                     ;ALLOW TIME FOR AN ERRONEOUS INTERRUPT
23231  126704  042777  000100  175550          BIC     #BIT6,@RCSR2    ;NO INTERRUPT-CLEAR INT. ENABLE
23232  126712  000401                          BR      3$
23233  126714                          2$:
23234  126714  104000                          EMT                     ;
23235  126716  010377  175550          3$:     MOV     R3,@RVECT2      ;RESTORE RECEIVE VECTOR
23236
23237
23238                                  ;*****************************************************************************
23239                                  ;TEST 662       TEST THAT THE "OR" ERROR (BIT14) & "ERROR" (BIT15) CAN BE SET
23240                                  ;*****************************************************************************
23241  126722                          TS662:
23242  126722  012700  000003                  MOV     #3,R0           ;SET CHARACTER COUNT TO SEND 3 CHAR.
23243  126726  005077  175536          1$:     CLR     @TBUF2          ;LOAD TRANSMIT BUFFER
23244  126732  105777  175530          2$:     TSTB    @TCSR2          ;WAIT FOR TRANSMIT DONE
23245  126736  100375                          BPL     2$
23246  126740  005300                          DEC     R0              ;DECREMENT CHARACTER COUNT
23247  126742  001371                          BNE     1$              ;BR IF ALL CHARACTERS NOT TRANSMITTED
23248  126744  032777  040000  175512          BIT     #BIT14,@RBUF2   ;TEST FOR "OR" ERROR FLAG
23249  126752  001001                          BNE     3$
23250  126754  104000                          EMT                     ;
23251  126756  032777  100000  175500  3$:     BIT     #BIT15,@RBUF2   ;TEST "ERROR" FLAG
23252  126764  001001                          BNE     4$
23253  126766  104000                          EMT                     ;
23254  126770  005000                  4$:     CLR     R0              ;CLEAR LOOP COUNTER
23255  126772  005200                  5$:     INC     R0              ;INCREMENT LOOP COUNTER
23256  126774  001376                          BNE     5$              ;  UNTIL COUNTER = 0
23257  126776  005777  175462                  TST     @RBUF2          ;CLEAR CHARACTER FROM RECEIVER BUFFER
23258
23259
23260                                  ;*****************************************************************************
23261                                  ;TEST 663       TEST THAT BREAK TRANSMITS ALL ZEROES
23262                                  ;*****************************************************************************
23263  127002                          TS663:
23264  127002  032737  000001  001020          BIT     #1, @#$ENV      ;ARE WE RUNNING UNDER APT
23265  127010  001403                          BEQ     70$             ;IF NO THEN DO TEST
23266  127012  005737  001006                  TST     @#$PASS         ;IS THIS FIRST PASS
23267  127016  001027                          BNE     TS664           ;IF NO THEN SHIP TO NEXT TEST
23268  127020                          70$:
23269  127020  012777  177777  175442          MOV     #-1,@TBUF2      ;TRANSMIT ALL ONES TO RCVR
23270  127026  105777  175430          1$:     TSTB    @RCSR2          ;WAIT FOR RCVR DONE
23271  127032  100375                          BPL     1$
23272  127034  005777  175424                  TST     @RBUF2          ;CLEAR DONE (LEAVING ALL ONES IN RBUF)
23273  127040  052777  000001  175420          BIS     #BIT0,@TCSR2    ;TRANSMIT BREAK
23274  127046  005000                          CLR     R0              ;CLEAR A TIMER
23275  127050  105777  175406          2$:     TSTB    @RCSR2          ;WAIT FOR RCVR DONE
23276  127054  100403                          BMI     CONT42          ;BR IF DONE
23277  127056  005200                          INC     R0              ;IF NOT, INCREMENT TIMER
23278  127060  001373                          BNE     2$
23279  127062  104000                          EMT                     ;BREAK DID NOT TRANSMIT ANYTHING
23280
23281  127064  105777  175374          CONT42: TSTB    @RBUF2          ;CHECK RECEIVE BUFFER FOR ZERO
23282  127070  001401                          BEQ     3$
23283  127072  104000                          EMT                     ;BREAK DID NOT TRANSMIT ALL ZEROES
23284
23285  127074  000005                  3$:     RESET                   ;CLEAR ERRORS
```

```
23286
23287
23288                                   ;*****************************************************************************************
23289                                   ;TEST 664       TEST THAT "FR" ERROR CAN BE SET DURING BREAK
23290                                   ;*****************************************************************************************
23291  127076                           TS664:
23292  127076  052777  000001  175362           BIS     #BIT0,@TCSR2    ;SEND BREAK
23293  127104  005077  175360                   CLR     @TBUF2          ;TRANSMIT A CHARACTER TO TIME BREAK
23294  127110  105777  175346           1$:     TSTB    @RCSR2          ;WAIT FOR RCVR DONE
23295  127114  100375                           BPL     1$
23296  127116  042777  000001  175342           BIC     #BIT0,@TCSR2    ;CLEAR BREAK BITS
23297  127124  032777  020000  175332           BIT     #BIT13,@RBUF2   ;CHECK FOR FRAMING ERROR FLAG
23298  127132  001001                           BNE     2$
23299  127134  104000                           EMT                     ;BREAK DID NOT SET FRAMING ERROR
23300  127136  032777  100000  175320   2$:     BIT     #BIT15,@RBUF2   ;TEST "ERROR" FLAG
23301  127144  001001                           BNE     3$
23302  127146  104000                           EMT                     ;"ERROR" FLAG DID NOT SET WITH "OR" FLAG
23303  127150  005777  175310           3$:     TST     @RBUF2          ;CLEAR RECEIVER BUFFER
23304
23305                                   ;*****************************************************************************************
23306                                   ;TEST 665       TEST DATA PATHS USING WRAP CABLE
23307                                   ;*****************************************************************************************
23308  127154                           TS665:
23309  127154  005001                           CLR     R1              ;CLEAR REGISTER FOR TEST DATA
23310  127156  105201           1$:     INCB    R1              ;INCREMENT THE TEST DATA
23311  127160  010177  175304                   MOV     R1,@TBUF2       ;XMIT A CHARACTER
23312  127164  005000                           CLR     R0              ;CLEAR A TIMER
23313  127166  105777  175270           2$:     TSTB    @RCSR2          ;WAIT FOR RECEIVER DONE
23314  127172  100403                           BMI     3$              ;BR IF DONE
23315  127174  005200                           INC     R0              ;INCREMENT TIMER IF NOT
23316  127176  001373                           BNE     2$
23317  127200  104000                           EMT                     ;
23318  127202  017702  175256           3$:     MOV     @RBUF2,R2       ;GET RECEIVED CHARACTER
23319  127206  020102                           CMP     R1,R2           ;COMPARE DATA
23320  127210  001401                           BEQ     4$
23321  127212  104000                           EMT                     ;
23322  127214  105701           4$:     TSTB    R1              ;TEST XMIT DATA FOR ZERO
23323  127216  001357                           BNE     1$              ;BR, IF NOT FINISHED
23324  127220  000167  000102                   JMP     UNIQUE          ;FINISHED TESTING DEVICES SEPARATELY
23325                                                                   ;GO TEST THEM ALL TOGETHER
23326  127224  000000           $BDADR: 0
23327  127226  000000           $BDDAT: 0
23328  127230  000000           $GDADR: 0
23329  127232  000000           $GDDAT: 0
23330
23331
23332  127234  012737  127266  000004   ERROR7: MOV     #1$,@#4         ;SET UP THE TIMEOUT VECTOR
23333  127242  012737  000340  000006           MOV     #340,@#6
23334  127250  005737  177766                   TST     @#177766        ;CHECK TO SEE IF THE POWER FAILED,WILL TRAP
23335                                                                   ;TO 1$ IF UNIBUS MAP BOARD IS NOT PRESENT
23336                                                                   ;SINCE THE CPUERR(177766)IS ON THE UNIBUS
23337                                                                   ;MAP BOARD
23338  127254  001404                           BEQ     1$              ;NO,GO REPORT THE ERROR
23339  127256  012737  000177  001002           MOV     #177,@#$FATAL   ;YES,FLAG THAT THE POWER FAILED
23340  127264  000403                           BR      2$              ; AND GO SET FATAL ERROR FLAG
23341  127266  012737  000006  001002   1$:     MOV     #6,@#$FATAL                     ;SET UP FATAL ERROR NUMBER
```

```
23342  127274  012767  000001  051476  2$:     MOV     #1,$MSGTY                       ;SET FATAL ERROR FLAG
23343  127302  000777                  SL2HLT: BR      .
23344
23345
23346  127304  177560                  DADTBL: .WORD   177560
23347  127306  177562                          .WORD   177562
23348  127310  177564                          .WORD   177564
23349  127312  177566                          .WORD   177566
23350  127314  176500                          .WORD   176500
23351  127316  176502                          .WORD   176502
23352  127320  176504                          .WORD   176504
23353  127322  176506                          .WORD   176506
23354  127324  177564                  TBLEND: .WORD   177564
23355
23356
23357  127326  032777  000034  071770  UNIQUE: BIT     #34,@SWR
23358  127334  001402                          BEQ     1$
23359  127336  000167  002112                  JMP     ENDPAS
23360  127342  012737  000007  001004  1$:     MOV     #7,@#$TESTN     ;UPDATE TEST NUMBER FOR APT
23361  127350  012737  130404  000030          MOV     #ERROR8,@#30    ;SET UP FOR CORRECT ERROR CALL
23362
23363                                  ;*****************************************************************************
23364                                  ;TEST 666       UNIQUE INTERNAL ADDRESS TEST
23365                                  ;*****************************************************************************
23366  127356                          TS666:
23367  127356  032737  000001  001020          BIT     #1, @#$ENV      ;ARE WE RUNNING UNDER APT
23368  127364  001403                          BEQ     70$             ;IF NO THEN DO TEST
23369  127366  005737  001006                  TST     @#$PASS         ;IS THIS FIRST PASS
23370  127372  001044                          BNE     TS667           ;IF NO THEN SHIP TO NEXT TEST
23371  127374                          70$:
23372  127374  012767  000340  050374          MOV     #340,PS         ;WE WILL BE PLAYING WITH BIT6
23373                                                                  ;SO LOCK OUT EXTRAINEOUS INTERRUPTS
23374  127402  012700  127304                  MOV     #DADTBL,R0      ;GET LOCATION OF FIRST REGISTER ADDRESS
23375  127406  012703  127304          1$:     MOV     #DADTBL,R3      ;MAKE R3 POINT TO LOCATION OF FIRST
23376                                                                  ;REGISTER ADDRESS
23377  127412  012701  000011                  MOV     #11,R1          ;SET LOOP COUNTER TO CLEAR ALL REG.
23378  127416  005033                  2$:     CLR     @(R3)+          ;CLEAR A REGISTER
23379  127420  077102                          SOB     R1,2$           ;LOOP UNTIL ALL REGISTERS CLEARED
23380  127422  012770  000100  000000          MOV     #BIT6,@(R0)     ;SET TEST BIT IN DEVICE REGISTERS
23381  127430  012701  127304                  MOV     #DADTBL,R1      ;GET LOCATION OF FIRST REGISTER ADDRESS
23382  127434  012702  000011                  MOV     #11,R2          ;SET UP TEST LOOP COUNTER
23383  127440  032731  000100          3$:     BIT     #BIT6,@(R1)+    ;IS TEST BIT SET IN THIS REGISTER
23384  127444  001006                          BNE     5$              ;IF YES GO SEE IF THERE IS AN ERROR
23385  127446  077204                  4$:     SOB     R2,3$           ;LOOP UNTIL ALL REGISTER CHECKED
23386  127450  005030                          CLR     @(R0)+          ;CLEAR REGISTER JUST TESTED AND POINT
23387                                                                  ;TO NEXT ONE
23388  127452  020027  127324                  CMP     R0,#TBLEND              ;ARE WE DONE TESTING
23389  127456  001407                          BEQ     7$              ;IF YES GO TO NEXT TEST
23390  127460  000752                          BR      1$              ;CONTINUE TESTING
23391  127462  021041                  5$:     CMP     (R0),-(R1)      ;DID WE COMPARE THE REGISTER TO ITSELF?
23392  127464  001401                          BEQ     6$
23393  127466  104000                          EMT                     ;WRITE TO 1 INTERNAL ADDRESS MODIFIED
23394                                                                  ;ANOTHER SO ADDRESS NOT UNIQUE
23395  127470  062701  000002          6$:     ADD     #2,R1           ;RESTORE POINTER
23396  127474  000764                          BR      4$              ;GET BACK IN TEST LOOP
23397  127476  005000                  7$:     CLR     R0              ;INITIALIZE LOOP COUNTER
```

```
23398  127500  005200                    8$:     INC     R0              ;INCREMEMT COUNTER
23399  127502  001376                            BNE     8$              ;  UNTIL LOOP COUNTER = 0
23400
23401
23402
23403                                    ;*************************************************************************************
23404                                    ;TEST 667       TEST ALL INTERNAL OPTIONS SIMULTANEOUSLY
23405                                    ;*************************************************************************************
23406  127504                            TS667:
23407  127504  032737  000001  001020            BIT     #1, @#$ENV      ;ARE WE RUNNING UNDER APT
23408  127512  001405                            BEQ     70$             ;IF NO DO TEST
23409  127514  005737  001006                    TST     @#$PASS         ;IS THIS FIRST PASS
23410  127520  001402                            BEQ     70$             ;IF YES DO TEST
23411  127522  000167  001726                    JMP     ENDPAS          ;IF NO THEN SKIP THIS TEST
23412  127526  000005                    70$:    RESET                   ;CLEAR EVERY BODY
23413  127530  012767  000340  050240            MOV     #340,PS         ;SET PROCESSOR PRIORITY TO 7
23414  127536  017767  174734  107616            MOV     @TVECT2,$TMP0
23415  127544  017767  174722  107612            MOV     @RVECT2,$TMP1
23416  127552  017767  170770  107606            MOV     @TVECT,$TMP2
23417  127560  017767  170756  107602            MOV     @RVECT,$TMP3
23418  127566  017767  170762  107576            MOV     @RTCVT,$TMP4
23419  127574  005067  000572                    CLR     XMTCT1          ;INITIALIZE COUNTERS
23420  127600  005067  000570                    CLR     XMTCT2
23421  127604  005067  000566                    CLR     RECCT1
23422  127610  005067  000564                    CLR     RECCT2
23423  127614  005067  000562                    CLR     TICKS
23424  127620  012777  130020  170720            MOV     #XMIT1,@TVECT   ;SET UP SLU1 TRANSMIT VECTOR
23425  127626  012777  000340  170714            MOV     #340, @TPSW     ;AND PSW
23426  127634  012777  130054  170700            MOV     #REC1, @RVECT   ;SET UP SLU1 RECEIVER VECTOR
23427  127642  012777  000340  170674            MOV     #340, @RPSW     ;AND PSW
23428  127650  012777  130102  174620            MOV     #XMIT2, @TVECT2 ;SET UP SLU2 TRANSMIT VECTOR
23429  127656  012777  000340  174614            MOV     #340, @TPSW2    ;AND PSW
23430  127664  012777  130136  174600            MOV     #REC2, @RVECT2  ;SET UP SLU2 RECEIVER VECTOR
23431  127672  012777  000340  174574            MOV     #340, @RPSW2    ;AND PSW
23432  127700  012777  130010  170646            MOV     #TICKER, @RTCVT ;SET UP RTC VECTOR
23433  127706  012777  000340  170642            MOV     #340, @RTCPSW   ;AND PSW
23434  127714  052777  000004  170614            BIS     #BIT2, @TCSR    ;ENABLE SLU1 MAINTENANCE WRAP
23435  127722  052777  000100  170606            BIS     #BIT6, @TCSR    ;ENABLE SLU1 XMIT INTERRUPT
23436  127730  052777  000100  170574            BIS     #BIT6, @RCSR    ;ENABLE SLU1 RECEIVER INTERRUPT
23437  127736  012702  130454                    MOV     #BUF1, R2       ;SET UP RECEIVER BUFFER
23438  127742  052777  000100  174516            BIS     #BIT6, @TCSR2   ;ENABLE SLU2 XMIT INTERRUPT
23439  127750  052777  000100  174504            BIS     #BIT6, @RCSR2   ;ENABLE SLU2 RECEIVER INTERRUPT
23440  127756  012703  131054                    MOV     #BUF2, R3       ;SET UP RECEIVER BUFFER
23441  127762  052777  000100  170562            BIS     #BIT6, @LKS     ;ENABLE RTC INTERRUPTS
23442  127770  012700  177777            3$:     MOV     #-1, R0         ;INITIALIZE DATA FOR SLU1
23443  127774  012701  177777                    MOV     #-1, R1         ;INITIALIZE DATA FOR SLU2
23444  130000  005067  047772                    CLR     PS              ;DROP PROCESSOR PRIORITY TO 0
23445  130004  000001                    WAITIO: WAIT                    ;WAIT FOR INTERRUPT
23446  130006  000776                            BR      WAITIO
23447
23448  130010  005267  000366            TICKER: INC     TICKS           ;UPDATE COUNT
23449  130014  000167  000140                    JMP     IOHAND          ;GO TO INTERRUPT HANDLER
23450  130020  005267  000346            XMIT1:  INC     XMTCT1          ;UPDATE XMIT INTERRUPT COUNT
23451  130024  005200                            INC     R0              ;UPDATE XMIT DATA
23452  130026  010077  170506                    MOV     R0, @TBUF       ;SEND NEXT CHARACTER
23453  130032  026727  000334  000400            CMP     XMTCT1,#400     ;IF 256 CHARACTERS HAVE NOT BEEN
```

```
23454  130040  002403                        BLT     1$                ;TRANSFERRED CONTINUE
23455  130042  042777  000100  170466        BIC     #100,   @TCSR     ;ELSE NO MORE TRANSMITTER INTERRUPTS
23456  130050  000167  000104          1$:   JMP     IOHAND            ;GO TO INTERRUPT HANDLER
23457
23458  130054  005267  000316        REC1:   INC     RECCT1            ;UPDATE RECEIVER INTERUPT COUNT
23459  130060  005777  170450                TST     @RBUF             ;BIT 15 SET IF ANY ERRORS OCCURRED
23460  130064  100002                        BPL     3$                ;IF BIT IS CLEAR NO ERROR
23461  130066  000005                        RESET                     ;CLEAR THE WORLD STOP ALL
23462                                                                  ;INTERRUPTS
23463  130070  104000                        EMT                       ;RECEIVER STATUS ERROR
23464  130072  117722  170436          3$:   MOVB    @RBUF, (R2)+      ;GET DATA AND STORE IT
23465  130076  000167  000056                JMP     IOHAND            ;GO TO INTERRUPT HANDLER
23466
23467  130102  005267  000266        XMIT2:  INC     XMTCT2            ;UPDATE XMIT INTERRUPT COUNT
23468  130106  005201                        INC     R1                ;UPDATE XMIT DATA
23469  130110  010177  174354                MOV     R1, @TBUF2        ;SEND NEXT CHARACTER
23470  130114  026727  000254  000400        CMP     XMTCT2, #400      ;IF 256 CHARACTERS HAVE NOT
23471  130122  002403                        BLT     1$                ;BEEN TRANSFERRED CONTINUE
23472  130124  042777  000100  174334        BIC     #BIT6, @TCSR2     ;ELSE NO MORE XMIT INTERRUPTS
23473  130132  000167  000022          1$:   JMP     IOHAND            ;GO TO INTERRUPT HANDLER
23474
23475  130136  005267  000236        REC2:   INC     RECCT2            ;UPDATE RECEIVER INTERRUPT COUNT
23476  130142  005777  174316                TST     @RBUF2            ;BIT 15 SETS IF ANY ERRORS OCCURRED
23477  130146  100002                        BPL     3$                ;IF BIT IS CLEAR NO ERRORS
23478  130150  000005                        RESET                     ;CLEAR THE WORLD - STOP ALL
23479                                                                  ;INTERRUPTS
23480  130152  104000                        EMT                       ;RECEIVER STATUS ERROR
23481  130154  117723  174304          3$:   MOVB    @RBUF2, (R3)+     ;GET DATA AND STORE IT
23482
23483  130160  026727  000216  000074  IOHAND: CMP    TICKS, #74        ;HAS 1 SEC ELAPSED
23484  130166  001401                        BEQ     1$                ;IF YES STOP TEST
23485  130170  000002                        RTI                       ;RETURN FROM INTERRUPT TO AWAIT NEXT
23486  130172  042777  000100  170336  1$:   BIC     #BIT6, @TCSR      ;IF YES STOP TRANSMISSIONS
23487  130200  042777  000100  174260        BIC     #BIT6, @TCSR2     ;
23488  130206  042777  000100  170336        BIC     #BIT6,  @LKS      ;TURN OFF LINE CLOCK
23489
23490  130214  106427  000000        WAITER: MTPS    #0                ;LOWER PRIORITY TO ALLOW TIME FOR RECEIVER TO FINISH
23491  130220  012705  140000                MOV     #-40000,R5        ;SET UP LOOP COUNTER
23492  130224  062705  000001          1$:   ADD     #1, R5            ;DO LOOP UNTIL R5 = 0
23493  130230  001375                        BNE     1$
23494  130232  000005                        RESET                     ;STOP EVERYONE SHOULD BE DONE
23495
23496  130234  026767  000132  000134  CHECK1: CMP    XMTCT1,RECCT1     ;# OF XMIT INTERRUPTS = REC INTERRUPTS
23497  130242  001401                        BEQ     1$
23498  130244  104000                        EMT                       ;INTERRUPT COMPARISON ERROR
23499  130246  012702  130454          1$:   MOV     #BUF1, R2         ;POINT TO FIRST DATA
23500  130252  005000                        CLR     R0                ;INITIALIZE TO FIRST DATA XMIT
23501  130254  016704  000112                MOV     XMTCT1, R4        ;GET # OF BYTES TRANSFERRED
23502  130260  122200                2$:     CMPB    (R2)+, R0         ;IS RECEIVED DATA = EXPECTED
23503  130262  001401                        BEQ     3$
23504  130264  104000                        EMT                       ;SLU1 DATA COMPARISON ERROR
23505  130266  005200                3$:     INC     R0                ;UPDATE TO NEXT GOOD DATA
23506  130270  077405                        SOB     R4,2$             ;LOOP UNTIL ALL DATA CHECKED
23507  130272  026767  000076  000100  CHECK2: CMP    XMTCT2, RECCT2    ;#OF XMIT INTERRUPTS = REC INTERRUPTS
23508  130300  001401                        BEQ     1$
23509  130302  104000                        EMT                       ;INTERRUPT COMPARISON ERROR
```

```
23510  130304  012703  131054          1$:     MOV     #BUF2, R3       ;INITIALIZE TO FIRST RECEIVED DATA
23511  130310  005001                          CLR     R1              ;INITIALIZE TO FIRST XMIT DATA
23512  130312  016704  000056                  MOV     XMTCT2, R4      ;GET # OF BYTES TRANSFERRED
23513  130316  122301                  2$:     CMPB    (R3)+, R1       ;IS RECEIVED DATA = EXPECTED DATA
23514  130320  001401                          BEQ     3$
23515  130322  104000                          EMT                     ;SLU2 DATA COMPARISON ERROR
23516  130324  005201                  3$:     INC     R1              ;UPDATE TO NEXT GOOD DATA
23517  130326  077405                          SOB     R4,2$           ;LOOP UNTIL ALL DATA CHECKED
23518  130330  016777  107026  174140  FINIE:  MOV     $TMP0, @TVECT2  ;RESTORE VECTORS
23519  130336  016777  107022  174126          MOV     $TMP1, @RVECT2
23520  130344  016777  107016  170174          MOV     $TMP2, @TVECT
23521  130352  016777  107012  170162          MOV     $TMP3, @RVECT
23522  130360  016777  107006  170166          MOV     $TMP4, @RTCVT
23523  130366  000167  001062                  JMP     ENDPAS          ;FINISHED TESTING GO TO END OF PASS
23524
23525  130372  000000                  XMTCT1: .WORD   0
23526  130374  000000                  XMTCT2: .WORD   0
23527  130376  000000                  RECCT1: .WORD   0
23528  130400  000000                  RECCT2: .WORD   0
23529  130402  000000                  TICKS:  .WORD   0
23530
23531  130404  012737  130436  000004  ERROR8: MOV     #1$,@#4         ;SET UP THE TIMEOUT VECTOR
23532  130412  012737  000340  000006          MOV     #340,@#6
23533  130420  005737  177766                  TST     @#177766        ;CHECK TO SEE IF THE POWER FAILED,WILL TRAP
23534                                                                  ;TO 1$ IF UNIBUS MAP BOARD IS NOT PRESENT
23535                                                                  ;SINCE THE CPUERR(177766)IS ON THE UNIBUS
23536                                                                  ;MAP BOARD
23537  130424  001404                          BEQ     1$              ;NO,GO REPORT THE ERROR
23538  130426  012737  000177  001002          MOV     #177,@#$FATAL   ;YES,FLAG THAT THE POWER FAILED
23539  130434  000403                          BR      2$              ; AND GO SET FATAL ERROR FLAG
23540  130436  012737  000007  001002  1$:     MOV     #7,@#$FATAL                     ;SET UP FATAL ERROR NUMBER
23541  130444  012767  000001  050326  2$:     MOV     #1,$MSGTY                       ;SET FATAL ERROR FLAG
23542  130452  000777                  COMHLT: BR      .
23543
23544  130454  000200                  BUF1:   .BLKW   200
23545  131054  000200                  BUF2:   .BLKW   200
23546
23547
23548
23549
23550  131454  005327                  ENDPAS: DEC     (PC)+           ;DECREMENT TEST LOOP COUNTER
23551  131456  000001                  $EOPCT: .WORD   1
23552  131460  003043                          BGT     $DOAGN          ;IF COUNTER NOT 0 DO TEST AGAIN
23553  131462  005267  047320                  INC     $PASS           ;INCREMENT PASS COUNTER
23554  131466  042767  100000  047312          BIC     #100000,$PASS   ;DON'T LET IT BE NEGATIVE
23555  131474  016767  047324  177754          MOV     $USWR,$EOPCT    ;RESET TEST LOOP COUNTER
23556  131502  012700  131713                  MOV     #ENDMSG,R0      ;LET R0 POINT TO ENDPASS MESSAGE
23557  131506  004767  000126                  JSR     PC,TYPE         ;GO TYPE END PASS MESSAGE
23558  131512  016700  046324                  MOV     42,R0           ;GET MONITOR ADDRESS
23559  131516  001405                          BEQ     DOAGIN          ;IF = 0 NO MONITOR SO DON'T STOP
23560  131520  000005                          RESET                   ;IF MONITOR CLEAR THE WORLD
23561  131522  004710                  $ENDAD: JSR     PC,(R0)         ;GO TO MONITOR
23562  131524  000240                          NOP                     ;THESE THREE LOCATIONS RESERVED
23563  131526  000240                          NOP
23564  131530  000240                          NOP
23565  131532  013737  000004  037362  DOAGIN: MOV     @#4,@#$TMP0
```

```
23566  131540  012737  131556  000004          MOV     #1$,@#4
23567  131546  012737  000001  164000          MOV     #1,@#164000
23568  131554  000402                          BR      2$
23569  131556  062706  000004          1$:     ADD     #4,SP
23570  131562  013737  037362  000004  2$:     MOV     @#$TMP0,@#4
23571  131570  000137                  $DOAGN: JMP     @(PC)+          ;RETURN TO TEST AT LOCATION RESTRT
23572  131572  001206                          .WORD   RESTRT
23573
23574
23575
23576                                   ;*****************************************************************************
23577                                   ;*COMMON SUBROUTINES THAT ARE NEEDED BY THE PROGRAM
23578                                   ;*
23579                                   ;*****************************************************************************
23580
23581  131574  012737  131604  000024  PWRDN:  MOV     #PWRUP,@#24     ;SET UP POWER FAIL VECTOR FOR POWER UP
23582  131602  000000                          HALT
23583
23584  131604  012737  131574  000024  PWRUP:  MOV     #PWRDN,@#24     ;SET UP POWER FAIL VECTOR FOR POWER DOWN
23585  131612  012706  001000                  MOV     #STBOT,SP       ;SET UP STACK
23586  131616  005737  000172                  TST     @#MTFLAG        ;ARE WE ON MULTI-OPTION TESTER
23587  131622  001004                          BNE     1$              ;IF YES SKIP TYPE OUT
23588  131624  012700  131674                  MOV     #PWRMSG,R0      ;POINT R0 TO POWER FAIL MESSAGE
23589  131630  004767  000004                  JSR     PC,TYPE         ;GO TYPE IT
23590  131634  000167  047346          1$:     JMP     RESTRT          ;GO RESTART TEST
23591
23592
23593  131640  132767  000040  047153  TYPE:   BITB    #40,$ENVM       ;TYPE OUTS DISABLED
23594  131646  001011                          BNE     3$              ;IF YES GET TO EXIT
23595  131650  105737  177564          1$:     TSTB    @#TTCSR         ;TEST FOR PRINTER READY BIT
23596  131654  100375                          BPL     1$              ;IF NOT READY WAIT FOR IT
23597  131656  112037  177566                  MOVB    (R0)+,@#TPB     ;WHEN READY PRINT A CHARACTER
23598  131662  001372                          BNE     1$              ;IF LAST CHARACTER NOT NULL CONTINUE TYPING
23599  131664  105737  177564          2$:     TSTB    @#TTCSR         ;WAIT FOR PRINTER TO FINISH
23600  131670  100375                          BPL     2$
23601  131672  000207                  3$:     RTS     PC
23602
23603                                   ;*****************************************************************************
23604                                   ;*MESSAGES
23605                                   ;*
23606                                   ;*****************************************************************************
23607
23608  131674  047520  042527  020122  PWRMSG: .ASCIZ  /POWER FAILED/<12><15>
23609  131702  040506  046111  042105
23610  131710  006412     000
23611  131713     105  042116  047440  ENDMSG: .ASCIZ  /END OF PASS CJKDEB0/<12><15>
23612  131720  020106  040520  051523
23613  131726  041440  045512  042504
23614  131734  030102  006412     000
23615
23616
23617          000001                  .END
```

```
A       020370          5744#   5750*   5751    5754    5758    5768*   5769    5772    5776    5786*   5787*   5788*   5789
                        5792    5796    5800    5805    5813*   5814*   5815    5816*   5819    5823    5829    5833    5859
                        5861    5869*   5870    5872    5880*   5881*   5882    5890*   5891*   5892
AAADON  070110          15378   15441#
AAA1    067310          15213#
AAA10   067640          15323#
AAA11   067670          15337#
AAA12   067720          15351#
AAA13   067750          15365#
AAA2    067340          15223#
AAA3    067370          15234#
AAA4    067420          15245#
AAA5    067450          15257#
AAA6    067500          15268#
AAA7    067530          15282#
AAA8    067560          15296#
AAA9    067610          15310#
AABBF0  104106          18629   18633   18640   18646   18655#
AABDON  104126          18648   18664#
AABTP1  104116          18628   18660#
AAB2    104104          18642   18645   18647   18651#
AACDON  110750          19998   20007#
AACTP1  110742          19986   19994   20002#
AAC10   110746          19989   19995   19997   20004#
AAC2    110716          19988   19990#
AADATO  061572          13813   13832   13854   13863#
AADBF   120066          21807*  21808   21811   21815#
AADDON  120072          21812   21818#
AADONE  061672          13862   13895#
AAD1    120012          21801#
AAPAT0  061602          13807   13827   13845   13867#
AAPAT1  061612          13810   13829   13871#
AAPAT2  061622          13815   13875#
AAPAT3  061632          13834   13879#
AAPAT4  061642          13883#
AAPAT5  061652          13848   13887#
AAPAT6  061662          13856   13891#
AA11    061462          13830#
AA12    061464          13832#
AA13    061502          13836#  13839
AA2     061412          13811#
AA20    061510          13837   13839#
AA22    061534          13849#
AA23    061536          13851#
AA24    061556          13858#  13861
AA27    061564          13859   13861#
AA3     061414          13813#
AA4     061432          13817#  13820
AA7     061440          13818   13820#
ABASE = 000000            564
ACDW1 = 000000            564
ACDW2 = 000000            564
ACPUOP= 000000            564     579
ADC1    014334          4549    4550    4552#
ADC2    014336          4551    4554#
ADC3    014356          4558    4559    4561#
```

```
ADC4     014360            4560    4563#
ADC5     014376            4566    4567    4568    4570#
ADDW0 =  000000             564
ADDW1 =  000000             564
ADDW10=  000000             564
ADDW11=  000000             564
ADDW12=  000000             564
ADDW13=  000000             564
ADDW14=  000000             564
ADDW15=  000000             564
ADDW2 =  000000             564
ADDW3 =  000000             564
ADDW4 =  000000             564
ADDW5 =  000000             564
ADDW6 =  000000             564
ADDW7 =  000000             564
ADDW8 =  000000             564
ADDW9 =  000000             564
ADD1     014216            4504    4505    4507#
ADD2     014220            4506    4509#
ADD3     014234            4512    4513    4515#
ADD4     014236            4514    4517#
ADD5     014254            4520    4521    4523#
ADD6     014256            4522    4525#
ADD7     014270            4526    4527    4529#
ADD8     014272            4528    4531#
ADD9     014312            4534    4535    4536    4538#
ADEVCT=  000000             564     570
ADEVM =  000000             564
ADONE    050644           11581#
AENV  =  000000             564     575
AENVM =  000000             564     576
AERR1    050634           11558   11559   11560   11576#
AFATAL=  000000             564     567
AMADR1=  000000             564
AMADR2=  000000             564
AMADR3=  000000             564
AMADR4=  000000             564
AMAMS1=  000000             564
AMAMS2=  000000             564
AMAMS3=  000000             564
AMAMS4=  000000             564
AMSGAD=  000000             564     572
AMSGLG=  000000             564     573
AMSGTY=  000000             564     566
AMTYP1=  000000             564
AMTYP2=  000000             564
AMTYP3=  000000             564
AMTYP4=  000000             564
APASS =  000000             564     569
APRIOR=  000000             564
APTENV=  000001             549#    6650
AROUN    001514             726     729#
AROUND   025046            6793    6804#
ASLB1    015714            5016    5018#
ASLB2    015702            5010    5011    5013#
```

```
ASLB3   015704            5012    5015#
ASLB4   015726            5019    5020    5021    5023#
ASL1    015306            4866    4867    4868    4870#
ASL2    015310            4869    4872#
ASL3    015326            4875    4876    4877    4879#
ASL4    015330            4878    4881#
ASL5    015344            4884    4885    4887#
ASL6    015346            4886    4889#
ASL7    015372            4892    4893    4894    4895    4898#
ASRB1   015752            5036    5038#
ASRB2   015764            5039    5040    5041    5043#
ASRB3   015766            5042    5045#
ASRB4   015774            5046    5048#
ASRB5   015776            5047    5050#
ASRB6   016016            5053    5054    5055    5057#
ASRB7   016020            5056    5059#
ASR1    015416            4908    4909    4910    4912#
ASR2    015420            4911    4914#
ASR3    015442            4918    4919    4920    4922#
ASR4    015444            4921    4924#
ASR5    015460            4927    4928    4929    4931#
ASR6    015462            4930    4933#
ASR7    015512            4937    4938    4939    4940    4943#
ASTART  025536            6961#   7135    7139
ASWREG= 000000             564     577
ATESTN= 000000             564     568
ATRAP   023440            6477    6496#
AUNIT = 000000             564     571
AUSWR = 000000             564     578
AUTO1   023532            6522#
AVECT1= 000000             564
AVECT2= 000000             564
A1      050604           11564#  11580
A11     050604           11565#
A12     050620           11570#
A2      050636           11575   11579#
BBBDON  070364           15530   15540#
BBBER1  070160           15460   15473#
BBBP1   070344           15461   15463   15486   15509   15533#
BBBP2   070354           15484   15505   15535#
BBB0    070114           15456#
BBB1    070142           15465#
BBB2    070174           15477   15481#
BBB3    070214           15487#
BBB4    070246           15498   15502#
BBB5    070274           15511#  15514
BBB6    070302           15508   15514#
BBB7    070162           15472   15475#
BBCDON  111024           20033   20044#
BBCTP1  111016           20021   20029   20038#
BBC10   111022           20023   20030   20032   20042#
BBC2    110772           20025#
BBDATO  063152           14089   14109   14130   14150   14169   14188   14199#
BBDDON  120372           21885   21894#
BBDONE  063302           14197   14243#
BBD1    120152           21848#
```

```
BBPAT0  063162          14121   14132   14203#
BBPAT1  063172          14086   14106   14126   14146   14166   14185   14207#
BBPAT2  063202          14084   14091   14211#
BBPAT3  063212          14142   14215#
BBPAT4  063222          14104   14219#
BBPAT5  063232          14164   14223#
BBPAT6  063242          14183   14190   14227#
BBP10   063262          14111   14235#
BBP11   063272          14171   14239#
BBP7    063252          14152   14231#
BB10    062630          14113#  14116
BB13    062636          14114   14116#
BB14    062646          14118   14121#
BB15    062666          14127#
BB16    062712          14134#  14137
BB17    062720          14135   14137#
BB2     062526          14087#
BB20    062730          14139   14142#
BB21    062750          14147#
BB22    062774          14154#  14157
BB25    063002          14155   14157#
BB26    063012          14159   14162#
BB27    063032          14167#
BB3     062532          14089#
BB30    063054          14173#  14176
BB31    063062          14174   14176#
BB32    063072          14178   14181#
BB33    063112          14186#
BB34    063134          14192#  14195
BB35    063142          14193   14195#
BB4     062550          14093#  14096
BB5     062556          14094   14096#
BB6     062566          14099   14102#
BB7     062606          14107#
BDONE   050700          11607#
BELL  = 000240            537#
BIC1    013576          4297    4298    4300#
BIC2    013600          4299    4302#
BIC3    013616          4305    4306    4308#
BIS1    013642          4318    4319    4320    4322#
BIS2    013644          4321    4324#
BIS3    013664          4327    4328    4329    4331#
BITCHK  020044          5626#
BITCLR  017772          5612#
BITCON  020120          5639    5642#
BITSET  020010          5619#
BITST1  013532          4275    4276    4278#
BITST2  013534          4277    4281#
BITST3  013552          4284    4285    4287#
BIT0  = 000001          9280#   9851    9875    9899    9924    9945    9975    9999    10023   10047   10089   21932#  22871
                        22874   22875   22878   22879   22888   22890   23273   23292   23296
BIT1  = 000002          21933#
BIT10 = 002000          21942#
BIT11 = 004000          21943#
BIT12 = 010000          21944#
BIT13 = 020000          21945#  23297
```

```
BIT14 = 040000          21946#  22438   23248
BIT15 = 100000          21947#  22441   23251   23300
BIT2  = 000004          21934#  22074   22077   22078   22081   22082   22085   22087   22256   22263   22279   22284   22297
                        22304   22307   22326   22333   22339   22342   22357   22361   22387   22391   22411   22430   22437
                        22456   22464   22468   23434
BIT3  = 000010          21935#
BIT4  = 000020           9898    9944    9974    9998   10022   10046   10088   21936#
BIT5  = 000040          21937#
BIT6  = 000100          21862   21876   21938#  22099   22103   22104   22107   22108   22112   22114   22127   22131   22132
                        22135   22136   22140   22142   22153   22163   22168   22177   22183   22188   22202   22210   22219
                        22230   22234   22241   22295   22296   22310   22313   22330   22335   22362   22369   22386   22395
                        22410   22416   22419   22511   22515   22516   22519   22520   22528   22530   22574   22592   22600
                        22623   22637   22655   22661   22676   22682   22700   22902   22906   22907   22910   22911   22919
                        22921   22934   22938   22939   22942   22943   22951   22953   22964   22974   22979   22988   22994
                        22999   23013   23021   23030   23046   23050   23057   23113   23114   23125   23128   23144   23149
                        23172   23179   23196   23203   23223   23228   23231   23380   23383   23435   23436   23438   23439
                        23441   23472   23486   23487   23488
BIT7  = 000200          21939#  22548   22549   22551   22552   22573   22591   22622   22654   22675   22679
BIT8  = 000400          21940#
BIT9  = 001000          21941#
BRCT    001540            713*    741#    747*
BRH     001524            714*    734#
BRTAB   021162            711    5956#
BR1     021362           6043    6046#
BR10    021524           6089    6092#
BR11    021604           6107    6110#
BR12    021644           6116    6119#
BR13    021704           6125    6128#
BR14    021744           6134    6137#
BR15    022022           6151    6154#
BR16    022034           6155    6158#
BR17    022046           6159    6162#
BR2     021402           6049    6052#
BR20    022060           6163    6165#
BR21    022072           6166    6169#
BR22    022104           6170    6173#
BR23    022116           6174    6177#
BR3     021416           6055    6058#
BR4     021434           6062    6065#
BR5     021452           6069    6072#
BR6     021470           6076    6078#
BR7     021506           6082    6085#
BR70    023260           6441#
BR71    024016           6571    6578#
BTCON   020156           5658    5661#
BTERR   020150           5659#
BTRAP   023506           6504    6516#
BUF1    130454          23437   23499   23544#
BUF2    131054          23440   23510   23545#
B1      050654          11595#  11606
B2      050656          11598#
B3      050676          11604   11606#
CARRY1  003206           1084    1086#
CC    = 177776            544#    6828*
CCBDON  104166          18685   18689#
CCB10   104164          18682   18684   18687#
```

```
CCB2    104140          18677#
CCCDON  071116          15659   15719#
CCC1    070370          15555#
CCC10   070654          15627#
CCC11   070700          15635#
CCC12   070724          15644#
CCC13   070750          15652#
CCC2    070414          15563#
CCC3    070440          15571#
CCC4    070464          15578#
CCC5    070510          15586#
CCC6    070534          15594#
CCC7    070560          15602#
CCC8    070604          15611#
CCC9    070630          15619#
CCDATO  062342          13913   13932   13952   13972   13991   14010   14021#
CCERR   020342           5727#
CCP0    062352          13908   13927   13944   13986   14005   14025#
CCP1    062362          13929   14029#
CCP10   062452          13974   14057#
CCP11   062462          13993   14061#
CCP12   062472          14065#
CCP2    062372          13910   13915   14033#
CCP3    062402          13964   13988   14037#
CCP4    062412          14007   14012   14041#
CCP5    062422          13968   14045#
CCP6    062432          13948   13954   14049#
CCP7    062442          13934   14053#
CCXDON  062502          14019   14070#
CCX12   062026          13937   13939#
CCX13   062036          13941   13944#
CCX14   062056          13949#
CCX15   062102          13956#  13959
CCX18   062110          13957   13959#
CCX19   062120          13961   13964#
CCX2    061716          13911#
CCX20   062140          13969#
CCX21   062164          13976#  13979
CCX24   062172          13977   13979#
CCX25   062202          13981   13984#
CCX26   062222          13989#
CCX27   062244          13995#  13998
CCX3    061740          13917#  13920
CCX30   062252          13996   13998#
CCX31   062262          14000   14003#
CCX32   062302          14008#
CCX33   062324          14014#  14017
CCX36   062332          14015   14017#
CCX6    061746          13918   13920#
CCX7    061756          13922   13925#
CCX8    061776          13930#
CCX9    062020          13936#  13939
CC1     001520            716*    718*    732#
CC2     020252           5701*   5709#   5712*   5718*
CC3     020236           5700*   5705#   5713*   5714    5716
CDONE   051130          11692   11694#
```

```
CHECK1  130234          23496#
CHECK2  130272          23507#
CHKAPT  050426           9549   11498#  21848
CIS     025334           6816    6870#
CISADR  025040           6799#   6808    6809
CISTRP  025024           6796#   6806
CLRCD   020234           5704#   5715    5719
CLR1    014072           4435    4436    4437    4439#
CMPARE  124364          22716   22719#
CMPREG  050244           9718    9725    9732    9739   11434#
CMPSUB  070004          15213   15223   15234   15245   15257   15268   15282   15296   15310   15323   15337   15351   15365
                        15404#
CMPTMP  070100          15425   15436#
CMP1    014514           4626    4627    4629#
CMP2    014516           4628    4631#
CMP3    014540           4635    4636    4638#
CMP4    014542           4637    4640#
CMP5    014566           4644    4645    4646    4648#
CMP6    014570           4647    4650#
CMP7    014610           4653    4654    4656#
COMHLT  130452            683*  23542#
COM1    014632           4667    4668    4670#
CONCIS  025100           6797    6812#
CONT    001542            724     728     742#
CONT1   123520          22556#  22559
CONT42  127064          23276   23281#
CON1    020260           5710    5712#
CON2    020344           5726    5729#
CORH    023500           6497*   6510#
COUNT   025414           6901#   6902    6938*   6973*   6978    7002*   7007    7030*   7035    7058*   7063    7087*   7093
                         7117*   7122    7388*   7410*   7420    7447*   7456    7484*   7493
CPUHLT  002130            677*    816     832#
CTRAP   023456           6502#   6521
C15     050710          11621#
C2      050724          11626   11628#
C25     050732          11631#
C3      050750          11636   11638#
C35     050756          11641#
C4      050774          11646   11648#
C45     051000          11650#
C5      051016          11655   11657#
C55     051022          11660#
C6      051036          11665   11667#
C65     051044          11669#
C7      051062          11674   11676#
C75     051070          11678#
C8      051106          11683   11685#
C85     051112          11687#
DADTBL  127304          23346#  23374   23375   23381
DAERR   020116           5627    5629    5631    5633    5635    5637    5640#
DALTB1  044126          10439   10495#
DALTB2  044162          10453   10513#
DALTB3  044412          10533   10589#
DALTB4  044446          10547   10607#
DBE     024646           6745#   6749
DBE1    024654           6740    6749#
```

```
DBE2    024652          6742    6747#
DBE3    024666          6750    6752#
DBE4    024700          6753    6755#
DBE5    024710          6756    6758#
DDBBF0  104352         18744   18767#
DDBDON  104362         18753   18772#
DDBTP1  104332         18730   18758#
DDBTP2  104342         18734   18762#
DDB2    104266         18739#
DDB5    104330         18749   18752   18754#
DDCDON  111124         20068   20077#
DDCTP1  111110         20058   20064   20072#
DDC10   111122         20061   20065   20067   20075#
DDC2    111056         20060   20062#
DDDATO  064052         14261   14281   14301   14321   14340   14359   14379   14391#
DDDDON  071610         15811   15874#
DDDONE  064202         14389   14435#
DDD1    071122         15734#
DDD2    071162         15745#
DDD3    071222         15756#
DDD4    071262         15767#
DDD5    071322         15778#
DDD6    071362         15790#
DDD7    071422         15801#
DDONE   051276         11729   11752#
DDP0    064062         14283   14303   14395#
DDP1    064072         14256   14258   14278   14296   14399#
DDP2    064102         14276   14298   14403#
DDP3    064112         14316   14337   14407#
DDP4    064122         14354   14376   14411#
DDP5    064132         14356   14374   14415#
DDP6    064142         14318   14335   14419#
DDP7    064152         14323   14342   14423#
DDP8    064162         14361   14381   14427#
DDP9    064172         14263   14431#
DD10    063434         14285#  14288
DD11    063442         14286   14288#
DD12    063456         14291   14294#
DD13    063476         14299#
DD14    063520         14305#  14308
DD15    063526         14306   14308#
DD16    063542         14311   14314#
DD17    063562         14319#
DD18    063604         14325#  14328
DD2     063326         14259#
DD21    063612         14326   14328#
DD22    063622         14330   14333#
DD23    063642         14338#
DD24    063664         14344#  14347
DD27    063672         14345   14347#
DD3     063350         14265#  14268
DD30    063702         14349   14352#
DD31    063722         14357#
DD32    063744         14363#  14366
DD35    063752         14364   14366#
DD36    063766         14369   14372#
```

```
DD37    064006          14377#
DD38    064030          14383#  14386
DD41    064036          14384   14386#
DD6     063356          14266   14268#
DD7     063372          14271   14274#
DD8     063412          14279#
DEC1    013772           4385    4386   4387   4389#
DEC2    013774           4388    4391#
DEC3    014010           4394    4395   4397#
DEC4    014012           4396    4399#
DEC5    014026           4402    4403   4405#
DEC6    014030           4404    4407#
DEC7    014052           4411    4412   4413   4415#
DERR1   051232          11708   11733#
DERR2   051200          11707   11720#
DISPRE  000174            638#
DIVDSU  071466          15734   15745  15756  15767  15778  15790  15801  15840#
DIVDT   071600          15856   15860  15871#
DIVFSU  071000          15555   15563  15571  15578  15586  15594  15602  15611  15619  15627  15635  15644  15652
                        15687#
DIVFT   071106          15703   15716#
DL11W   023600           6532    6535#
DNMB0A  007412           2941    2942   2943   2945#
DNMB0B  007414           2944    2947#
DNMB2A  007546           3000    3001   3002   3004#
DNMB2B  007550           3003    3006#
DNMB2C  007556           3007    3009#
DNMB2D  007572           3011    3012   3014#
DNMB2E  007574           3013    3016#
DNMB2F  007604           3018    3020#
DNMB3A  007650           3037    3038   3039   3041#
DNMB3B  007652           3040    3043#
DNMB3C  007662           3044    3046#
DNMB3D  007700           3049    3050   3052#
DNMB3E  007702           3051    3054#
DNMB4A  010022           3092    3093   3094   3096#
DNMB4B  010024           3095    3098#
DNMB4C  010034           3099    3101#
DNMB4D  010044           3102    3104#
DNMB4E  010046           3103    3106#
DNMB4F  010054           3107    3109#
DNM03A  007012           2688    2689   2690   2692#
DNM03B  007014           2691    2694#
DNM03C  007024           2695    2698#
DNM1    006724           2655    2657#
DNM1A   007444           2959    2960   2961   2963#
DNM1B   007446           2962    2965#
DNM2    006732           2658    2660#
DNM2A   007476           2977    2978   2980#
DNM2B   007500           2979    2982#
DNM2C   007506           2985#
DNM2D   007510           2984    2987#
DNM3    006742           2662    2664#
DNM4    006756           2668    2670#
DNM4A   007746           3069    3070   3071   3073#
DNM4B   007750           3072    3075#
```

```
DNM4C    007756            3076    3078#
DNM5A    010116            3123    3124    3125    3127#
DNM5B    010120            3126    3129#
DNM5C    010130            3130    3132#
DNM6A    010172            3145    3146    3147    3149#
DNM6B    010174            3148    3151#
DNM6C    010204            3152    3154#
DNM7A    010250            3167    3168    3169    3171#
DNM7B    010252            3170    3173#
DNM7C    010262            3174    3176#
DOAGIN   131532           23559   23565#
DOPB2A   007232            2851    2853#
DOPB2B   007264            2874    2876#
DOP0A    006560            2587    2589#
DOP0B    006576            2594    2596#
DOP0C    006610            2599    2601#
DOP0D    006632            2608    2610#
DOP03A   006672            2631    2632    2633    2635#
DOP03B   006674            2634    2637#
DOP1     007132            2782    2784#
DOP2     007202            2826    2828#
DOP4     011244            3491#
DOP5     011312            3520#
DPAT3    056024           12922#
DTRAP1   023476            6508#   6520
DUMMY =  000000            6897#   7613    7633    7654    7675    7695    7716    7737
D1       051154           11710#  11725   11731
D2       051166           11713*  11714#
D3       051170           11715#  11733
D4       051174           11717#
D5       051202           11722#  11748
D6       051216           11723   11727#
D7       051226           11728   11730#
D8       051262           11742#
D9       051274           11747   11750#
EDONE    051344           11776   11779#
EEBBF0   104476           18813#
EEBBF1   104506           18785   18791   18796   18802   18817#
EEBDON   104520           18806   18823#
EEBTP1   104466           18784   18809#
EEB10    104516           18792   18799   18803   18805   18821#
EEB2     104426           18793#
EECDON   111232           20097   20110#
EECTP1   111206           20088   20089*  20103#  20105
EECTP2   111216           20087   20093   20105#
EEC10    111230           20090   20094   20096   20108#
EEC2     111154           20091#
EEDATO   064356           14453   14473   14485#
EEDONE   064440           14483   14510#
EEEDON   072342           15992   16052#
EEE1     071614           15889#
EEE10    072100           15961#
EEE11    072124           15969#
EEE12    072150           15977#
EEE13    072174           15985#
EEE2     071640           15897#
```

```
EEE3    071664          15905#
EEE4    071710          15913#
EEE5    071734          15921#
EEE6    071760          15929#
EEE7    072004          15937#
EEE8    072030          15945#
EEE9    072054          15953#
EEP0    064366          14455   14475   14489#
EEP1    064400          14448   14450   14494#
EEP2    064410          14498#
EEP3    064420          14468   14470   14502#
EEP4    064430          14506#
EERR0   051342          11763   11772   11777#
EE12    064342          14478   14480#
EE2     064226          14451#
EE3     064250          14457#  14460
EE6     064256          14458   14460#
EE7     064272          14463   14466#
EE8     064312          14471#
EE9     064334          14477#  14480
EISEND  037342           9214    9216#
EMTA  = 104377            547#    885
ENDMSG  131713          23556   23611#
ENDPAS  131454          23359   23411   23523   23550#
ENT176  031224           7595    7602#
ENT51   027150           7194    7198#
ER      001536            725     727    739#
ERROR1  002062            740     768    770    772    774    776    782    784    786    797    799    801    803
                          805     811    813    815    821#   843    845    847    849    851    857    859    861
                          872     874    876    878    880    886    888    890    896   1004   6240   6250   6261
                         6262    6272   6282   6292   6305
ERROR2  002400            891     896#   909    911    913    915    917    923    925    927    944    946    948
                          950     952    958    960    962    973    975    977    979    981    987    989    991
ERROR3  050452           9310   11511#
ERROR4  120424          11549   21905#  21922
ERROR5  123150          21967   22471#
ERROR6  124412          22489   22731#
ERROR7  127234          22759   23332#
ERROR8  130404          23361   23531#
ERRVEC= 000004           9281#  10258*  10271*  11560*  11707*  11803*  11836*  12717*  13017*  13079*  13145*  15063*  17934*
                        17996*  18057*  18110*  18157*  18203*  18792*  18843*  18890*  18941*  18992*  19044*  19090*  19139*
                        19183*  19989*  20023*  20061*  20090*  20123*  20155*  20188*  20222*  21016*  21055*  21094*  21132*
                        21173*  21213*  21253*  21923*
E1      051310          11765#
E3      051316          11767#
E4      051320          11768#
F     = 000063           6898#   7206    7223#   7240#   7257#   7274#   7291#   7308#   7325#   7342#   7359#   7376#
FDATI0  051620          11795   11817   11864#
FDATI1  051622          11865#
FDATI2  051624          11866#
FDATI3  051626          11867#
FDATI4  051630          11802   11811   11868#
FDATI5  051632          11869#
FDATI6  051634          11870#
FDATI7  051636          11871#
FDATO0  051642          11831   11850   11873#
```

```
FDAT01  051644          11874#
FDAT02  051646          11875#
FDAT03  051650          11876#
FDAT04  051652          11835   11844   11877#
FDAT05  051654          11878#
FDAT06  051656          11879#
FDAT07  051660          11880#
FDONE   051704          11860   11892#
FERR20  051616          11803   11836   11861#
FFBBF1  104634          18836   18842   18848   18854   18865#
FFBDON  104646          18858   18871#
FFBTP1  104624          18835   18861#
FFB10   104644          18843   18851   18855   18857   18869#
FFB2    104564          18845#
FFCDON  111332          20130   20142#
FFCTP1  111310          20121   20122*  20135#  20137
FFCTP2  111320          20120   20126   20137#
FFC10   111330          20123   20127   20129   20140#
FFC2    111264          20124#
FFDAT0  064604          14528   14548   14561#
FFDONE  064664          14557   14587#
FFFDON  072674          16110   16173#
FFF1    072346          16067#
FFF2    072406          16078#
FFF3    072446          16089#
FFF4    072506          16100#
FFP0    064614          14543   14566#
FFP1    064624          14545   14570#
FFP2    064634          14523   14574#
FFP3    064644          14525   14578#
FFP4    064654          14530   14550   14582#
FF10    064574          14553   14555#
FF2     064464          14526#
FF3     064506          14532#  14535
FF4     064514          14533   14535#
FF5     064524          14537   14541#
FF6     064544          14546#
FF7     064566          14552#  14555
FINIE   130330          23518#
FINISH  025400           6792*   6822   6888#
FOVER   022700           6314    6326#
FPEXIT  120420          21849   21902#
FPHLT   120472            679*  21916#
FPP     025370           6792    6820   6884#
FPSTRT  050522           9309   11357  11545#
FPVECT= 000244          11533#  11558*  11708*  11763*  12712*  12742*  13322*  13400*  14784*  14806*  14842*  14864*  14898*
                        14920*  15460*  15508*  16274*  16419*  16549*  16700*  17737*  21922*
FXDAT0  051664          11796   11818   11851   11882#
FXDAT1  051666          11883#
FXDAT2  051670          11884#
FXDAT3  051672          11885#
FXDAT4  051674          11886#
FXDAT5  051676          11887#
FXDAT6  051700          11888#
FXDAT7  051702          11889#
F10     051532          11840#
```

```
F11     051534          11841#
F12     051550          11845   11847#
F13     051574          11853#  11856
F13S    051560          11848   11850#
F14     051602          11854   11856#
F2      051372          11799#  11800
F22     051604          11857#
F3      051412          11807#
F4      051414          11808#
F5      051430          11812   11814#
F6      051476          11827   11829#
F7      051512          11832#  11833
GAND0   054272          12482#
GAND1   054274          12483#
GAND2   054276          12484#
GAND3   054300          12485#
GCMP    054222          12124   12150   12176   12202   12228   12254   12280   12306   12332   12358   12384   12410   12457#
GDATO0  054312          12116   12142   12168   12194   12220   12246   12272   12298   12324   12350   12376   12402   12444
                        12450   12457   12492#
GDATO1  054314          12493#
GDATO2  054316          12494#
GDATO3  054320          12495#
GDONE   054322          12427   12498#
GFLAG1  054246          12126   12128*  12152   12154*  12178   12180*  12204   12206*  12230   12232*  12256   12258*  12282
                        12284*  12308   12310*  12334   12336*  12360   12362*  12386   12388*  12412   12414*  12430   12469#
GFLAG2  054250          12470#
GGBBF0  104762          18883   18895   18901   18912#
GGBBF1  104772          18889   18916#
GGBDON  105004          18905   18922#
GGBTP1  104752          18882   18908#
GGB10   105002          18890   18898   18902   18904   18920#
GGB2    104712          18892#
GGCDON  111426          20164   20174#
GGCTP1  111412          20152   20153*  20160   20169#
GGC10   111424          20155   20159   20161   20163   20172#
GGC2    111360          20156#
GGDATO  066322          14790   14820   14848   14876   14904   14934   14952#
GGDONE  066442          14950   14994#
GGER0   065570          14784   14812#  14842
GGER14  066226          14898   14926#
GGGDON  075460          16879   16964#
GGG1    074530          16755#
GGG10   075060          16836#
GGG11   075110          16845#
GGG12   075140          16854#
GGG13   075170          16863#
GGG14   075220          16872#
GGG2    074560          16764#
GGG3    074610          16773#
GGG4    074640          16782#
GGG5    074670          16791#
GGG6    074720          16800#
GGG7    074750          16809#
GGG8    075000          16818#
GGG9    075030          16827#
GGP1    066332          14957#
```

```
GGP2    066342          14843   14865   14899   14921   14961#
GGP3    066352          14845   14867   14965#
GGP4    066362          14969#
GGP5    066372          14785   14787   14807   14809   14973#
GGP6    066402          14792   14822   14850   14906   14977#
GGP7    066412          14878   14982#
GGP8    066422          14901   14923   14986#
GGP9    066432          14936   14990#
GG10    065664          14836   14840#
GG11    065712          14846#
GG12    065734          14852#  14855
GG13    065742          14853   14855#
GG14    065756          14858   14862#
GG15    066004          14868#  14870
GG16    066010          14864   14870#
GG17    066044          14880#  14883
GG18    066052          14881   14883#
GG19    066102          14892   14896#
GG2     065472          14788#
GG20    066130          14902#
GG21    066152          14908#  14911
GG22    066160          14909   14911#
GG23    066174          14914   14918#
GG24    066222          14924#  14928
GG25    066230          14920   14928#
GG26    066264          14938#  14941
GG27    066272          14939   14941#
GG3     065514          14794#  14797
GG4     065522          14795   14797#
GG5     065536          14800   14804#
GG6     065564          14810#  14814
GG7     065572          14806   14814#
GG8     065626          14824#  14827
GG9     065634          14825   14827#
GIN1    025112           6814#   6821    6845
GIN2    025154           6825#   6846
GIN3    025202           6823    6830#
GOR0    054302          12487#
GOR1    054304          12488#
GOR2    054306          12489#
GOR3    054310          12490#
GPAT00  054252          12115   12167   12219   12271   12323   12375   12440   12472#
GPAT01  054254          12473#
GPAT02  054256          12474#
GPAT03  054260          12475#
GPAT10  054262          12141   12193   12245   12297   12349   12401   12435   12477#
GPAT11  054264          12478#
GPAT12  054266          12479#
GPAT13  054270          12480#
GRESET  054202          12136   12162   12188   12214   12240   12266   12292   12318   12344   12370   12396   12422   12450#
GSETUP  054124          12117   12143   12169   12195   12221   12247   12273   12299   12325   12351   12377   12403   12430#
GS1     054154          12440#  12454
G1      052540          12119#  12138
G10     052772          12179   12183#
G11     052774          12182   12184#
G12     053040          12197#  12216
```

```
G13     053072          12205   12209#
G14     053074          12208   12210#
G15     053140          12223#  12242
G16     053172          12231   12235#
G17     053174          12234   12236#
G2      052572          12127   12131#
G20     053240          12249#  12268
G21     053272          12257   12261#
G22     053274          12260   12262#
G23     053340          12275#  12294
G24     053372          12283   12287#
G25     053374          12286   12288#
G26     053440          12301#  12320
G27     053472          12309   12313#
G3      052574          12130   12132#
G30     053474          12312   12314#
G31     053540          12327#  12346
G32     053572          12335   12339#
G33     053574          12338   12340#
G34     053640          12353#  12372
G35     053672          12361   12365#
G36     053674          12364   12366#
G37     053740          12379#  12398
G4      052640          12145#  12164
G40     053772          12387   12391#
G41     053774          12390   12392#
G42     054040          12405#  12424
G43     054072          12413   12417#
G44     054074          12416   12418#
G5      052672          12153   12157#
G6      052674          12156   12158#
G7      052740          12171#  12190
HADR    055014          12643*  12651   12660#
HA1R    055070          12621   12645   12654   12674#
HA1W    055020          12511   12521   12548   12644   12663#
HA2R    055100          12625   12676#
HA2W    055030          12525   12561   12665#
HA3R    055110          12629   12678#
HA3W    055040          12529   12574   12667#
HA4R    055120          12633   12680#
HA4W    055050          12533   12587   12669#
HA5R    055130          12637   12682#
HA5W    055060          12537   12600   12671#
HCLR    054776          12517   12619   12654#
HCLR1   055006          12656#  12657
HCMP    054742          12543   12555   12568   12581   12594   12607   12643#
HCMP1   054762          12647#  12650
HCMP2   054770          12648   12650#
HDAT1   055140          12512   12685#
HDAT2   055150          12687#
HDAT3   055160          12689#
HDAT4   055170          12691#
HDAT5   055200          12693#
HDONE   055210          12613   12696#
HERE  = 000000           6018#   6041*   6047*   6093
HFLAG   055016          12510*  12611   12615*  12661#
```

```
HHBBF0  105130          18934   18946   18961   18963#
HHBBF1  105140          18940   18951   18967#
HHBDON  105152          18955   18973#
HHBTP1  105110          18933   18958#
HHB10   105150          18941   18949   18952   18954   18971#
HHB2    105050          18943#
HHCDON  111536          20197   20208#
HHCTP1  111514          20185   20186*  20202#
HHCTP2  111524          20184   20193   20204#
HHC10   111534          20188   20192   20194   20196   20206#
HHC2    111462          20189#
HHDATO  065270          14617   14641   14664   14684   14704   14716#
HHDONE  065440          14714   14768#
HHHDON  076674          17147   17230#
HHH1    075464          16980#
HHH10   076234          17097#
HHH11   076304          17110#
HHH12   076354          17123#
HHH13   076424          17136#
HHH2    075534          16993#
HHH3    075604          17006#
HHH4    075654          17019#
HHH5    075724          17032#
HHH6    075774          17045#
HHH7    076044          17058#
HHH8    076114          17071#
HHH9    076164          17084#
HHP0    065300          14612   14720#
HHP1    065310          14614   14724#
HHP10   065420          14686   14760#
HHP11   065430          14706   14764#
HHP2    065320          14619   14728#
HHP3    065330          14732#
HHP4    065340          14643   14736#
HHP5    065350          14636   14699   14701   14740#
HHP6    065360          14638   14744#
HHP7    065370          14666   14748#
HHP8    065400          14659   14679   14681   14752#
HHP9    065410          14661   14756#
HH10    065020          14646   14648#
HH11    065034          14651   14656#
HH12    065054          14662#
HH13    065076          14668#  14671
HH16    065104          14669   14671#
HH17    065120          14674   14677#
HH18    065140          14682#
HH19    065162          14688#  14691
HH2     064710          14615#
HH20    065170          14689   14691#
HH21    065204          14694   14697#
HH22    065224          14702#
HH23    065246          14708#  14711
HH24    065254          14709   14711#
HH3     064732          14621#  14624
HH6     064740          14622   14624#
HH7     064750          14626   14633#
```

CJKDE-B 11/24 CPU CLUSTER DIAG. MACY11 30(1046) 05-AUG-82 15:03 PAGE 448
CJKDEB.P11 05-AUG-82 15:01 CROSS REFERENCE TABLE -- USER SYMBOLS

```
HH8      064770           14639#
HH9      065012           14645#  14648
HICORE   023372            6481#   6499
HLT    = 000000             525#
HSTD     054664           12541   12554   12567   12580   12593   12606   12619#
HXDATO   067174           15018   15046   15080   15097   15121   15143   15157#
HXDONE   067304           15154   15197#
HXER9    066700           15063   15071#
HXP1     067204           15009   15034   15112   15116   15124   15140   15145   15162#
HXP2     067214           15011   15013   15037   15040   15077   15167#
HXP3     067224           15171#
HXP4     067234           15094   15175#
HXP5     067244           15100   15179#
HXP6     067254           15075   15092   15138   15183#
HXP7     067264           15020   15082   15188#
HXP8     067274           15049   15192#
HX10     066576           15041   15044#
HX11     066620           15051#  15054
HX14     066626           15052   15054#
HX15     066642           15058   15061#
HX16     066660           15065#
HX165    066664           15066#
HX17     066702           15070   15073#
HX18     066722           15078#
HX19     066742           15084#  15087
HX2      066466           15012#
HX20     066750           15085   15087#
HX22     066772           15095#
HX23     067012           15102#  15105
HX26     067020           15103   15105#
HX28     067044           15117#
HX29     067066           15126#  15129
HX3      066500           15014   15016#
HX30     067074           15127   15129#
HX31     067110           15133   15136#
HX32     067130           15141#
HX33     067152           15147#  15150
HX34     067160           15148   15150#
HX4      066520           15022#  15025
HX7      066526           15023   15025#
HX8      066542           15028   15031#
HX9      066564           15039#
H1       054326           12510#
H10      054570           12590#  12595
H11      054622           12603#  12608
H12      054654           12612   12615#
H2       054346           12514#  12515
H3       054356           12519#  12616
H4       054430           12541#
H5       054452           12551#  12556
H6       054504           12564#  12569
H7       054536           12577#  12582
IDATI0   052176           11906   11912   11927   11937   11942   11968   11991#
IDATI1   052200           11992#
IDATI2   052202           11965*  11993#
IDATI3   052204           11966*  11994#
```

```
IDAT00  052166          11923   11926   11962   11967   11986#
IDAT01  052170          11987#
IDAT02  052172          11988#
IDAT03  052174          11989#
IDONE   052206          11974   11996#
IIBBF0  105276          18985   18997   19012   19014#
IIBBF1  105306          18991   19002   19018#
IIBDON  105320          19006   19025#
IIBTP1  105256          18984   19009#
IIB10   105316          18992   19000   19003   19005   19023#
IIB2    105216          18994#
IICDON  111602          20234   20238#
IIC2    111560          20227#
IIC20   111600          20222   20235#
IIIDON  073176          16224   16305#
III1    072700          16188#
III2    072730          16198#
III3    072760          16207#
III4    073010          16216#
IJMP    013014           4083    4086#
IJMP4   012632           4044    4047#   4055
IJMP5   012764           4075    4078#
ILLA  = 004700            542#
ILLB  = 000100            543#
INC1    013706           4353    4354    4356#
INC2    013710           4355    4358#
INC3    013732           4362    4363    4364    4366#
INC4    013734           4365    4369#
INC5    013750           4372    4373    4375#
INST    025402           6824*   6825*   6829    6837    6844    6889#
IOHAND  130160          23449   23456   23465   23473   23483#
IPAT10  052146          11907   11936   11976#
IPAT11  052150          11977#
IPAT12  052152          11978#
IPAT13  052154          11979#
IPAT20  052156          11915   11945   11981#
IPAT21  052160          11982#
IPAT22  052162          11983#
IPAT23  052164          11984#
ITRAP5= 000004            527#
I1      051710          11904#
I105    052010          11930   11932#
I12     052012          11936#
I13     052026          11939#  11940
I14     052054          11951#
I15     052056          11952#
I16     052060          11953#
I17     052074          11957   11959#
I2      051726          11909#  11910
I20     052134          11970#  11973
I23     052142          11971   11973#
I3      051752          11919#
I4      051754          11920#
I5      051756          11921#
I6      052002          11929#  11932
JBUF0   055622          12825   12841#
```

CJKDE-B 11/24 CPU CLUSTER DIAG. MACY11 30(1046) 05-AUG-82 15:03 PAGE 450
CJKDEB.P11 05-AUG-82 15:01 CROSS REFERENCE TABLE -- USER SYMBOLS

```
JBUF1   055624          12842#
JBUF2   055626          12843#
JBUF3   055630          12844#
JDATI0  055632          12815   12828   12836   12846#
JDATI1  055634          12847#
JDATI2  055636          12848#
JDATI3  055640          12849#
JDATO0  055642          12822   12829   12851#
JDATO   055652          12812   12856#
JDATO1  055644          12852#
JDATO2  055646          12853#
JDATO3  055650          12854#
JDAT1   055654          12857#
JDAT2   055656          12858#
JDAT3   055660          12859#
JDONE   055662          12839   12862#
JJBBFO  105440          19037   19043   19049   19054   19065#
JJBDON  105452          19058   19071#
JJBTP1  105426          19036   19061#
JJB10   105450          19044   19052   19055   19057   19069#
JJB2    105364          19046#
JJJDON  073560          16371   16450#
JJJ1    073202          16321#
JJJ2    073246          16334#
JJJ3    073312          16347#
JJJ4    073356          16360#
JMPCK   013016           4086    4088#
JMPERR  020202           5676    5677    5678    5680#
JMPSEQ  013030           4035*   4041    4045*   4049    4052*   4058    4062*   4065    4069*   4072    4076*   4080    4084*
                         4088    4091#
JMPT    020172           5675    5676#
JMP2    012634           4036    4049#
JMP2A   012644           4050    4052#
JMP3    012576           4038#   4053
JMP3A   012606           4039    4041#
JMP3B   012620           4042    4044#
JMP4    012656           4047    4055#
JMP4A   012666           4056    4058#
JMP4B   012700           4059    4061#
JMP5    012740           4061    4072#
JMP5A   012752           4073    4075#
JMP6    012712           4065#   4078
JMP6A   012724           4066    4068#
JMP7    012766           4068    4080#
JMP7A   013000           4081    4083#
JSRCK   013400           4200    4203#
JSRCKA  013374           4197    4200#
JSRCK1  013416           4114    4204    4207#
JSRSEQ  013376           4118*   4127    4139*   4142    4154*   4158    4164*   4168    4176*   4178    4186*   4190    4196*
                         4201#   4203
JSR0    013034           4114#
JSR1    013040           4113    4116#
JSR1A   013062           4124#   4144
JSR2    013136           4117    4142#   4160
JSR2A   013166           4143    4145    4147    4150#
JSR2B   013170           4149    4152#
```

```
JSR3    013064          4127#   4135    4155
JSR3A   013124          4128    4130    4132    4134    4137#
JSR3B   013126          4136    4139#
JSR4    013212          4129    4140    4158#
JSR4A   013230          4159    4162#
JSR4B   013232          4161    4164#
JSR5    013302          4165    4178#   4182    4192
JSR5A   013326          4179    4181    4184#
JSR5B   013330          4183    4186#
JSR6    013244          4168#   4180    4199
JSR6A   013270          4169    4171    4174#
JSR6AD  013372          4172    4187    4199#   4205
JSR6B   013272          4173    4176#
JSR7    013342          4170    4177    4190#
JSR7A   013360          4191    4194#
JSR7B   013362          4193    4196#
J1      055522         12809#
J2      055540         12818#
J3      055542         12819#
J4      055544         12820#
J5      055600         12831#  12834
J6      055606         12832   12834#
J7      055620         12837   12839#
KBUF0   055776         12879   12888   12899   12909#
KBUF1   056000         12910#
KBUF2   056002         12911#
KBUF3   056004         12912#
KDATI0  055766         12891   12904#
KDATI1  055770         12905#
KDATI2  055772         12906#
KDATI3  055774         12907#
KDATO0  056006         12885   12892   12914#
KDATO1  056010         12915#
KDATO2  056012         12916#
KDATO3  056014         12917#
KDONE   056026         12902   12924#
KERSTK= 001000           545#   9386    9390    9716    9723    9730    9737   10260   10443   10464   10537   10558   10640
                       10693   10698   10751   10768   10811   10857   10939   11206   11307   11336   11355
KFIRST  124406         22717*  22719   22727#
KIPAR0= 172340          9266#   9428    9568    9640    9722    9767    9831   10905*  11411   11448
KIPAR1= 172342          9267#  10906*
KIPAR2= 172344          9268#  10907*
KIPAR3= 172346          9269#  10146   10292*  10628*  10908*
KIPAR4= 172350          9270#   9848*   9872*   9896*   9921*   9943*   9972*   9996*  10020*  10044*  10073*  10119*  10126*
                       10293*  10629*  10909*  10928*  11044*  11192*
KIPAR5= 172352          9271#  10074*  10120*  10127*  10671*
KIPAR6= 172354          9272#  10270*
KIPAR7= 172356          9273#  10910*
KIPDR0= 172300          9255#   9440    9602    9677    9714    9756    9838   10150   10153   10166   10914   11407   11435
KIPDR1= 172302          9256#
KIPDR2= 172304          9257#
KIPDR3= 172306          9258#  10296*  10437*  10630*
KIPDR4= 172310          9259#  10117*  10124*  10303*  10362*  10446*  10457*  10540*  10551*  10631*  10656*  10672*  10739*
                       10927*  10933*  11042*  11067*  11069*  11083*  11085*  11097*  11099*  11114*  11116*  11131*  11133*
                       11147*  11149*  11165*  11167*  11191*
KIPDR5= 172312          9260#  10118*  10125*  10438*  10673*  10740*
```

```
KIPDR6= 172314            9261#  10257*  10261   10269*
KIPDR7= 172316            9262#  10247*  10250   10802*  10831*
KKBBF0  105600           19083   19095   19110   19112#
KKBBF1  105610           19089   19100   19116#
KKBDON  105622           19104   19122#
KKBTP1  105560           19082   19107#
KKB10   105620           19090   19098   19101   19103   19120#
KKB2    105516           19092#
KKCDON  112700           20457   20521#
KKC1    111704           20293#
KKC10   112136           20354#
KKC11   112164           20362#
KKC12   112212           20370#
KKC13   112240           20378#
KKC14   112266           20386#
KKC15   112314           20394#
KKC16   112342           20402#
KKC17   112370           20410#
KKC2    111732           20303#
KKC20   112416           20418#
KKC21   112444           20426#
KKC22   112472           20434#
KKC23   112520           20442#
KKC24   112546           20450#
KKC3    111760           20313#
KKC4    112006           20322#
KKC5    112034           20330#
KKC6    112062           20338#
KKC7    112110           20346#
KKKDON  074112           16504   16588#
KKK1    073564           16466#
KKK3    073614           16476#
KKK4    073644           16486#
KKK5    073674           16496#
KPAT0   056016           12876   12919#
KPAT1   056020           12920#
KPAT2   056022           12921#
KWSTRT  123220           21965   22005   22469   22485#
KX2     055704           12881#
KX3     055706           12882#
KX4     055710           12883#
KX5     055744           12894#  12897
KX6     055752           12895   12897#
KX7     055764           12900   12902#
K1      021300            6020#   6102*  6103    6106    6111*  6112    6115    6119*  6121    6128*  6130    6137*  6139
                          6142
K10     021316            6027#   6158   6162    6165    6169   6173    6177
K11     021320            6028#
K12     021322            6029#
K2      021302            6021#
K3      021304            6022#
K4      021306            6023#
K5      021310            6024#   6101*  6104    6110*   6120*  6122    6124    6129*  6131    6133    6138*  6140
K6      021312            6025#   6113   6162
K7      021314            6026#   6150   6154    6158    6165   6177
LDATI0  056202           12942   12949   12967   12987#
```

```
LDATI1  056204          12988#
LDATI2  056206          12962   12965*  12989#
LDATI3  056210          12966*  12990#
LDATO0  056214          12959   12968   12992#
LDATO1  056216          12993#
LDATO2  056220          12994#
LDATO3  056222          12995#
LDCDSU  113362          20534   20544   20554   20564   20574   20584   20594   20604   20615   20625   20667#
LDCFSU  112576          20293   20303   20313   20322   20330   20338   20346   20354   20362   20370   20378   20386   20394
                        20402   20410   20418   20426   20434   20442   20450   20490#
LDCT    112670          20498   20503   20518#  20674   20680
LDONE   056224          12975   12997#
LDXSUB  114622          20708   20721   20734   20747   20761   20774   20788   20801   20814   20827   20840   20853   20867
                        20881   20895   20909   20956#
LDXT    114750          20972   20974   20993#
LKS     120552          21959#  22498   22511   22515*  22516   22519*  22520   22528*  22530   22545   22548*  22549   22551*
                        22552   22556   22573*  22574*  22575   22581*  22584   22591*  22592*  22593   22600*  22622*  22623*
                        22624   22637*  22654*  22655*  22656   22661*  22675*  22676*  22677   22679*  22682*  22700*  22705*
                        22706   22708*  22709   22712*  23441*  23488*
LKSTST  123250          22491#
LLBBFO  105726          19133   19141*  19144   19158#
LLBDON  105740          19151   19165#
LLBTP1  105716          19132   19154#
LLB10   105736          19139   19147   19150   19163#
LLB2    105662          19141#
LLCDON  113454          20634   20694#
LLC1    112704          20534#
LLC10   113226          20604#
LLC11   113264          20615#
LLC12   113322          20625#
LLC2    112742          20544#
LLC3    113000          20554#
LLC4    113036          20564#
LLC5    113074          20574#
LLC6    113132          20584#
LLC7    113170          20594#
LLLDON  074524          16654   16738#
LLL1    074116          16604#
LLL2    074162          16617#
LLL3    074226          16630#
LLL4    074272          16643#
LPAT10  056160          12939   12977#
LPAT11  056162          12978#
LPAT12  056164          12979#
LPAT13  056166          12980#
LPAT20  056170          12943   12982#
LPAT21  056172          12983#
LPAT22  056174          12984#
LPAT23  056176          12985#
LTCHLT  124460            680*  22742#
L1      056032          12936#
L2      056072          12953#
L3      056074          12954#
L4      056076          12956#
L5      056146          12971#  12974
L6      056154          12972   12974#
```

```
MBDM2A  010404            3245    3246    3248#
MBDM2B  010406            3247    3250#
MBDM2C  010416            3251    3253#
MBDM2D  010430            3254    3255    3257#
MBDM2E  010432            3256    3259#
MBDM2F  010442            3260    3262#
MBDM4A  010652            3343    3345#
MBDM4B  010662            3346    3348#
MBDM4C  010674            3349    3350    3352#
MBDM4D  010676            3351    3354#
MBDM4E  010704            3355    3357#
MDAT00  056352           13029   13032   13053#
MDAT01  056354           13054#
MDAT02  056356           13055#
MDAT03  056360           13056#
MDM1A   010314            3195    3196    3198#
MDM1B   010316            3197    3200#
MDM2A   010344            3219    3220    3222#
MDM2B   010346            3221    3224#
MDM2C   010354            3227#
MDM2D   010356            3226    3229#
MDM3A   010500            3279    3280    3282#
MDM3B   010502            3281    3284#
MDM3C   010512            3285    3287#
MDM3D   010524            3288    3290#
MDM3E   010544            3292    3294#
MDM4A   010606            3314    3315    3317#
MDM4B   010610            3316    3319#
MDM4C   010616            3320    3322#
MDM5A   010736            3378    3379    3381#
MDM5B   010740            3380    3383#
MDM5C   010750            3384    3386#
MDM5D   010760            3387    3389#
MDM5E   011000            3392    3394#
MDM6A   011032            3414    3415    3417#
MDM6B   011034            3416    3419#
MDM6C   011044            3420    3422#
MDM6D   011056            3423    3425#
MDM6E   011100            3428    3430#
MDM7A   011136            3449    3450    3452#
MDM7B   011140            3451    3454#
MDM7C   011150            3455    3457#
MDM7D   011162            3458    3460#
MDM7E   011200            3462    3464#
MDONE   056362           13041   13058#
MERR3   056270           13017   13027#
MFPI0   017670            5571    5574#
MFPI0A  017710            5576    5578#
MFPS1   016760            5345    5348#
MFPS2A  017032            5364    5365    5366    5368#
MFPS2B  017034            5367    5370#
MFPS2C  017046            5371    5373#
MFPS3A  017106            5385    5386    5387    5389#
MFPS3B  017110            5388    5391#
MFPS3C  017122            5392    5394#
MFPS4A  017162            5406    5407    5408    5410#
```

```
MFPS4B  017164          5409    5412#
MFPS4C  017176          5413    5415#
MFPS5A  017236          5427    5428    5429    5431#
MFPS5B  017240          5430    5433#
MFPS5C  017252          5434    5436#
MFPS6A  017314          5448    5449    5450    5452#
MFPS6B  017316          5451    5454#
MFPS6C  017330          5455    5457#
MFPS7A  017372          5469    5470    5471    5473#
MFPS7B  017374          5472    5475#
MFPS7C  017406          5476    5478#
MFPT  = 000007          5904#   5906
MMBBF0  106054         19177   19188   19201   19203#
MMBBF1  106064         19185*  19207#
MMBDON  106076         19195   19214#
MMBTP1  106034         19176   19198#
MMB10   106074         19183   19191   19194   19212#
MMB2    106000         19185#
MMCDON  114760         20921   20996#
MMC1    113460         20708#
MMC10   114072         20801#
MMC11   114140         20814#
MMC12   114206         20827#
MMC13   114254         20840#
MMC14   114322         20853#
MMC15   114370         20867#
MMC16   114436         20881#
MMC17   114504         20895#
MMC2    113526         20721#
MMC20   114552         20909#
MMC3    113574         20734#
MMC4    113642         20747#
MMC5    113710         20761#
MMC6    113756         20774#
MMC7    114024         20788#
MMMDON  077334         17300   17390#
MMM1    076700         17246#
MMM2    076734         17257#
MMM3    076770         17268#
MMM4    077024         17279#
MMM5    077060         17290#
MMUHLT  050520           678*  11522#
MMUTST  037374          9216    9302#
MMVEC = 000250          9222#   9303*   9304*  10087*  10130*  10302*  10348*  10361*  10400*  10442*  10455*  10490*  10536*
                       10549*  10584*  10634*  10657*  10690*  10696*  10741*  10932*  11035*  11046*  11176*  11199*  11297*
MODDD0  100020         17516   17520   17548#
MODDD1  100030         17518   17528   17551#
MODDOV  077624         17406   17421   17435   17450   17498#
MODDSU  076500         16980   16993   17006   17019   17032   17045   17058   17071   17084   17097   17110   17123   17136
                       17182#
MODDT0  076654         17199   17203   17224#
MODDT1  076664         17201   17211   17227#
MODFD0  077314         17354   17358   17384#
MODFD1  077324         17356   17365   17387#
MODFOV  077120         17246   17257   17268   17279   17290   17336#
MODFSU  075254         16755   16764   16773   16782   16791   16800   16809   16818   16827   16836   16845   16854   16863
```

```
                    16872   16915#
MODFT0  075430      16932   16936   16955#
MODFT1  075440      16934   16943   16958#
MODP1   075450      16920   16961#  17187   17341   17503
MOR0    020376       5733    5745#
MOR1    020420       5755    5758#
MOR2    020454       5773    5776#
MOR3    020522       5793    5796#
MOR4    020534       5797    5800#
MOR5    020546       5802    5805#
MOR6    020612       5820    5823#
MOR7    020624       5825    5829#
MOR8    020636       5830    5833#
MOV1    013466       4253    4254    4256#
MOV2    013470       4255    4259#
MOV3    013506       4262    4263    4265#
MPAT10  056332      13013   13043#
MPAT11  056334      13044#
MPAT12  056336      13045#
MPAT13  056340      13046#
MPAT20  056342      13048#
MPAT21  056344      13049#
MPAT22  056346      13050#
MPAT23  056350      13051#
MRK1    016274       5181    5186#
MRK2    016316       5186    5187    5188    5190    5193#
MRK3    016320       5192    5195#
MRK4    016342       5198    5200#
MRK5    016346       5199    5202#
MRK6    016362       5203    5206#
MTFLAG  000172        637#    668*   23586
MTPI0   017756       5591    5594#
MTPS1   016406       5226    5228#
MTPS1A  016426       5232    5233    5234    5236#
MTPS2   016456       5248    5250#
MTPS3   016522       5264    5266#
MTPS4   016564       5279    5281#
MTPS5   016620       5294    5296#
MTPS6   016664       5309    5311#
MTPS7   016730       5324    5326#
MULDSU  072552      16067   16078   16089   16100   16137#
MULDT   072664      16155   16159   16171#
MULFSU  072224      15889   15897   15905   15913   15921   15929   15937   15945   15953   15961   15969   15977   15985
                    16020#
MULFT   072332      16036   16049#
M1      056230      13010#
M15     056250      13019#
M2      056254      13022#
M3      056256      13023#
M4      056260      13024#
M5      056314      13034   13036#
M6      056320      13037#  13040
M7      056326      13038   13040#
M8      056272      13026   13029#
N     = 000307       6899#   7608    7628#   7648#   7670#   7690#   7710#   7732#   7752#   7775#   7780    7803#   7826#
                     7849#   7872#   7895#   7918#   7941#   7964#   7987#   8010#   8024    8045#   8066#   8087#   8110#
```

```
                    8131#  8152#  8175#  8196#  8217#  8238#  8261#  8282#  8303#  8324#  8347#  8368#  8389#
                    8412#  8416   8437#  8458#  8479#  8500#  8521#  8542#  8563#  8584#  8605#  8626#  8632
                    8653#  8674#  8697#  8718#  8739#  8762#  8783#  8804#  8825#  8848#  8869#  8890#  8913#
                    8934#  8955#  8973#  8989#  8993   9014#  9035#  9056#  9077#  9098#  9119#  9140#  9161#
                    9182#  9203#
NATBF1  110654      19927  19933  19950  19967#
NATINS  110560      19937  19940#
NATSUB  110504      19716  19735  19754  19773  19792  19811  19830  19849  19868  19924#
NBR     001530        724*   727*   736#
NDATI0  056526      13093  13109  13119#
NDATI1  056530      13120#
NDATI2  056532      13121#
NDATI3  056534      13122#
NDATO0  056464      13086  13092  13102#
NDATO1  056466      13103#
NDATO2  056470      13104#
NDATO3  056472      13105#
NDONE   056536      13100  13124#
NEGAT   026550       6989   7017   7045   7073   7103   7132   7136#
NEG00   004570       1714   1715   1716   1718#
NEG01   004572       1717   1721#
NEG02   004600       1722   1725#
NEG03   004614       1727   1728   1729   1731#
NEG04   004616       1730   1733#
NEG1    014422       4591   4592   4593   4595#
NEG10   004644       1744   1745   1746   1748#
NEG11   004646       1747   1751#
NEG12   004656       1752   1754#
NEG13   004672       1756   1757   1758   1760#
NEG14   004674       1759   1762#
NEG2    014424       4594   4597#
NEG20   004724       1773   1774   1775   1777#
NEG21   004726       1776   1779#
NEG22   004746       1785   1787#
NEG3    014446       4601   4602   4603   4605#
NEG30   005156       1911   1912   1913   1915#
NEG31   005160       1914   1917#
NEG32   005166       1918   1920#
NEG33   005204       1923   1925#
NEG34   005212       1926   1928#
NEG4    014450       4604   4607#
NEG40   005446       2062   2063   2064   2066#
NEG41   005450       2065   2068#
NEG42   005456       2069   2071#
NEG5    014470       4611   4612   4613   4615#
NEG50   005514       2086   2087   2088   2090#
NEG51   005516       2089   2092#
NEG52   005524       2093   2095#
NEG60   005564       2110   2111   2112   2114#
NEG61   005566       2113   2116#
NEG70   005620       2128   2129   2130   2132#
NEG71   005622       2131   2134#
NERR0   056456      13079  13097#
NNBBF0  106210      19234  19236  19255#
NNBDON  106222      19244  19262#
NNBTP1  106170      19227  19247#
```

```
NNBTP2  106200          19237   19251#
NNB10   106220          19240   19243   19260#
NNB2    106116          19229#
NNCDON  115072          21027   21036#
NNCTB0  115054          21011   21030#
NNCTB1  115060          21018   21021   21023   21025   21031#
NNC10   115070          21016   21022   21024   21026   21033#
NNC2    115022          21020#
NNNDON  100040          17463   17554#
NNN1    077340          17406#
NNN2    077414          17421#
NNN3    077470          17435#
NNN4    077544          17450#
NODL    023566           6530    6533#
NODL2   024236           6622#
NOP   = 000240            511     538#
NOR     023366           6479#   6482
NOSUB   023462           6501    6504#
NPAT10  056516          13074   13114#
NPAT11  056520          13115#
NPAT12  056522          13116#
NPAT13  056524          13117#
NPAT20  056504          13077   13089   13109#
NPAT21  056506          13110#
NPAT22  056510          13111#
NPAT23  056512          13112#
N1      056366          13071#
N12     056436          13090   13092#
N13     056452          13095#  13099
N14     056460          13096   13099#
N2      056412          13082#
N3      056414          13083#
N4      056416          13084#
ODATI0  056702          13161   13175   13186#
ODATI1  056704          13187#
ODATI2  056706          13188#
ODATI3  056710          13189#
ODATO0  056640          13153   13160   13169#
ODATO1  056642          13170#
ODATO2  056644          13171#
ODATO3  056646          13172#
ODONE   056712          13167   13191#
OERR0   056610          13145   13158#
OOBDON  106352          19295   19309#
OOBTP1  106330          19273   19278   19285   19291   19298#
OOBTP2  106340          19274   19286   19302#
OOB10   106350          19289   19292   19294   19307#
OOB2    106264          19283#
OOCDON  115204          21066   21075#
OOCTB0  115166          21050   21069#
OOCTB1  115172          21057   21060   21062   21064   21070#
OOC10   115202          21055   21061   21063   21065   21072#
OOC2    115134          21059#
OODON   101032          17763   17766#
OOOT    100766          17737   17748#
OOO2    100764          17744#  17749
```

CJKDE-B 11/24 CPU CLUSTER DIAG. MACY11 30(1046) 05-AUG-82 15:03 PAGE 459
CJKDEB.P11 05-AUG-82 15:01 CROSS REFERENCE TABLE -- USER SYMBOLS

```
0003    101000          17753#
0004    101024          17760   17762#
OPAT10  056672          13140   13181#
OPAT11  056674          13182#
OPAT12  056676          13183#
OPAT13  056700          13184#
OPAT20  056656          13156   13175#
OPAT21  056660          13143   13176#
OPAT22  056662          13177#
OPAT23  056664          13178#
OPAT24  056666          13179#
OVDNTT  073550          16430   16432   16447#
OVDTT   074514          16717   16719   16735#
OVFNTT  073166          16285   16287   16302#
OVFTT   074102          16566   16568   16585#
OVUNDN  073426          16321   16334   16347   16360   16411#
OVUNDT  074342          16604   16617   16630   16643   16692#
OVUNFN  073044          16188   16198   16207   16216   16266#
OVUNFT  073730          16466   16476   16486   16496   16542#
01      056542          13137#
012     056612          13157   13160#
013     056626          13163#  13166
014     056634          13164   13166#
02      056566          13149#
03      056570          13150#
04      056572          13151#
PCN01   020652           5850#   5851
PCN1    024512           6689#   6691
PCN2    020670           5860#   5861
PCN3    020720           5871#   5872
PCN4    020744           5881#   5882
PCN5    020766           5891#   5892
PDATI0  057014          13210   13218   13224   13233#
PDATI1  057016          13234#
PDATI2  057020          13235#
PDATI3  057022          13236#
PDAT00  057024          13215   13219   13238#
PDAT01  057026          13239#
PDAT02  057030          13240#
PDAT03  057032          13241#
PDONE   057034          13227   13243#
PDRTB1  044144          10440   10504#
PDRTB2  044176          10454   10521#
PDRTB3  044430          10534   10598#
PDRTB4  044462          10548   10615#
PPAT10  057004          13207   13228#
PPAT11  057006          13229#
PPAT12  057010          13230#
PPAT13  057012          13231#
PPBDON  106502          19343   19357#
PPBTP1  106460          19320   19325   19333   19339   19346#
PPBTP2  106470          19321   19334   19350#
PPB10   106500          19337   19340   19342   19355#
PPB2    106414          19330#
PPCDON  115316          21105   21113#
PPCTB0  115300          21089   21108#
```

```
PPCTB1  115304          21096   21099   21101   21103   21109#
PPC10   115314          21094   21100   21102   21104   21111#
PPC2    115246          21098#
PPPBF0  101152          17783   17815#
PPPBF1  101166          17793   17799   17803   17818#
PPPDON  101214          17813   17826#
PPPTP1  101202          17790   17804   17821#
PPP10   101212          17806   17808   17810   17812   17824#
PPP2    101052          17785#  17786
PPP3    101102          17797#
PPP4    101114          17800   17803#
PS    = 177776            514#   1393*   1394    1402*   1403    1411*   1412    1420*   1421    5208#   5225    5245*   5247
                         5261*   5263    5276*   5278    5293    5306*   5308    5321*   5323    5342*   5350*   5362*   5383*
                         5404*   5425*   5446*   5467*   5499*   5501    5515*   5521*   5523*   5537*   5541*   5543*   5548*
                         5550*   5554*   5567*   5570    5572*   5574*   5584*   5586*   5590    5592*   5594*   5654*   5655*
                         5656    5659*   5661*   5706    5722    5933*   5936*   5945*   5951*   9277    21857*  23372*  23413*
                        23444*
PSW   = 177776           9277#   9339*   9340*   9341    9351*   9357*   9359*   9360    9369*   9371*   9372    9385*   9387*
                         9389*   9522*   9532*   9917    9939    10070*  10094   10111   10121*  10123*  10193*  10238*  10306
                        10339*  10345*  10347*  10365   10397*  10399*  10750*  10755*  10767*  10770*  10772*  10782*  10786
                        10788*  10847*  10856*  10858*  10860*  10936*  10952*  10963*  10974*  10984*  10997*  11010*  11022*
                        11049*  11060*  11079*  11094*  11110*  11126*  11143*  11159*  11190*  11201*  11215*  11227*  11238*
                        11248*  11260*  11273*  11285*  11298*  11304*  11335*  11369   11371   11601
PSWORD  025416           6903#   6904    6969*   6970    6998*   6999    7026*   7027    7054*   7055    7083*   7084    7113*
                         7114    7212*   7213    7229*   7230    7246*   7247    7263*   7264    7280*   7281    7297*   7298
                         7314*   7315    7331*   7332    7348*   7349    7365*   7366    7406*   7407    7443*   7444    7480*
                         7481    7617*   7618    7637*   7638    7658*   7659    7679*   7680    7699*   7700    7720*   7721
                         7741*   7742    7761*   7762    7789*   7790    7812*   7813    7835*   7836    7858*   7859    7881*
                         7882    7904*   7905    7927*   7928    7950*   7951    7973*   7974    7996*   7997    8031*   8032
                         8052*   8053    8073*   8074    8095*   8096    8117*   8118    8138*   8139    8160*   8161    8182*
                         8183    8203*   8204    8224*   8225    8246*   8247    8268*   8269    8289*   8290    8310*   8311
                         8332*   8333    8354*   8355    8375*   8376    8397*   8398    8423*   8424    8444*   8445    8465*
                         8466    8486*   8487    8507*   8508    8528*   8529    8549*   8550    8570*   8571    8591*   8592
                         8612*   8613    8640*   8641    8661*   8662    8683*   8684    8705*   8706    8726*   8727    8748*
                         8749    8770*   8771    8791*   8792    8812*   8813    8834*   8835    8856*   8857    8877*   8878
                         8899*   8900    8921*   8922    8942*   8943    8964*   8965*   8966    8981*   8982*   8983    9001*
                         9002    9022*   9023    9043*   9044    9064*   9065    9085*   9086    9106*   9107    9127*   9128
                         9148*   9149    9169*   9170    9190*   9191
PUSRM = 030000            518#
PWRDN   131574            663   23581#  23584
PWRMSG  131674          23588   23608#
PWRUP   131604          23581   23584#
P1      056716          13204#
P2      056732          13212#  13213
P3    = 056734          13213#
P4      056736          13215#
P5      056760          13220#  13223
QDATI0  057156          13272   13288   13298#
QDATI1  057160          13299#
QDATI2  057162          13300#
QDATI3  057164          13301#
QDATO0  057146          13267   13271   13293#
QDATO1  057150          13294#
QDATO2  057152          13295#
QDATO3  057154          13296#
QDONE   057166          13281   13303#
```

```
QPAT10  057126          13259   13283#
QPAT11  057130          13284#
QPAT12  057132          13285#
QPAT13  057134          13286#
QPAT20  057136          13262   13278   13288#
QPAT21  057140          13289#
QPAT22  057142          13290#
QPAT23  057144          13291#
QQBDON  106644          19390   19406#
QQBTP1  106612          19367   19372   19380   19386   19393#
QQBTP2  106632          19368   19381   19399#
QQB10   106642          19384   19387   19389   19404#
QQB2    106546          19377#
QQCDON  115440          21144   21153#
QQCTB0  115416          21127   21147#
QQCTB1  115422          21135   21140   21142   21148#
QQCTB2  115432          21134   21138   21142   21150#
QQC10   115436          21132   21139   21141   21143   21151#
QQC2    115364          21137#
QQQBF0  101334          17844   17874#  17888
QQQBF1  101350          17854   17859   17863   17876#  17897   17900   17903
QQQDON  101502          17909   17913#
QQQTP1  101364          17851   17864   17878#  17895   17904
QQQ10   101374          17866   17868   17870   17872   17883#
QQQ2    101234          17846#  17847
QQQ20   101376          17873   17888#
QQQ22   101410          17891#  17892
QQQ23   101442          17898   17899#
QQQ24   101454          17901   17903#
QQQ25   101500          17907   17911#
QQQ3    101264          17857#
QQQ4    101276          17861   17863#
Q1      057040          13256#
Q2      057054          13264#  13265
Q3    = 057056          13265#
Q4      057060          13267#
Q5      057102          13273#  13276
RBUF    120534          21950#  22059   22249   22283   22316   22345   22376   22392   22438   22441   22447   22461   23459
                        23464
RBUF2   124464          22747#  22856   23065   23092   23102   23130   23156   23185   23200   23248   23251   23257   23272
                        23281   23297   23300   23303   23318   23476   23481
RCSR    120532          21949#  22046   22127   22131*  22132   22135*  22136   22140*  22142   22259   22268   22281   22285
                        22296*  22302   22310*  22313*  22328   22330*  22335*  22359   22362*  22369*  22386*  22389   22395*
                        22410*  22413   22416*  22419*  22459   23436*
RCSR2   124462          22746#  22843   22934   22938*  22939   22942*  22943   22951*  22953   23074   23086   23100   23103
                        23114*  23119   23125*  23128*  23142   23144*  23149*  23170   23172*  23179*  23196*  23198   23203*
                        23223*  23225   23228*  23231*  23270   23275   23294   23313   23439*
RECCT1  130376          23421*  23458*  23496   23527#
RECCT2  130400          23422*  23475*  23507   23528#
REC1    130054          23426   23458#
REC2    130136          23430   23475#
REGR1   025664           6988    6991#
REGR2   026012           7016    7019#
REGR23  030106           7431    7434#
REGR3   026140           7044    7047#
REGR4   026264           7072    7075#
```

```
REGR5   026414            7102    7105#
REG01   027726            7396#   7508
REG1    003422            1195#   1198
REG1A   003450            1210#   1213
REG1E   003434            1196    1200#
REG2    003502            1225#   1228
REG2B   003530            1240#   1243
REG2E   003514            1226    1230#
REG3    003562            1256#   1259
REG3A   003610            1271#   1274
REG3E   003574            1257    1261#
REG4    003642            1287#   1290
REG4A   003670            1302#   1305
REG4E   003654            1288    1292#
REG45   030262            7467    7470#
REG5    003722            1319#   1322
REG5A   003750            1334#   1337
REG5E   003734            1320    1324#
REG6    004002            1350#   1353
REG6A   004030            1365#   1368
REG6E   004014            1351    1355#
RESET2  024306            6633    6641#
RESET3  024304            6639#
REST    017456            5504#
RESTRT  001206             663#   23572   23590
RET     025214            6826    6834#
RETA    050450           11501   11503#
RETAT   022744            6335    6341#
RETBT   022774            6347    6353#
RETCT   023030            6361    6366#
RETR1   024520            6688    6691#
RETR2   024556            6703    6707#
RETR3   024602            6720    6724#
RET1    025224            6835    6837#
RET2    025236            6838    6840#
RET3    025246            6841    6844#
RET4    025244            6842#
RITSH   030446            7432    7468    7506    7509#
ROL1    015076            4785    4786    4787    4789#
ROL2    015100            4783    4791#
ROL3    015116            4794    4795    4796    4798#
ROL4    015120            4797    4800#
ROL5    015134            4803    4804    4806#
ROL6    015136            4805    4808#
ROL7    015160            4811    4812    4813    4816#
RORB1   015536            4956    4958#
RORB10  015620            4982    4983    4985#
RORB11  015622            4984    4987#
RORB12  015634            4988    4990#
RORB13  015646            4991    4992    4993    4995#
RORB14  015650            4994    4997#
RORB2   015550            4959    4960    4961    4963#
RORB3   015552            4962    4965#
RORB4   015562            4966    4967    4969#
RORB5   015564            4968    4971#
RORB7   015574            4972    4974#
```

```
ROR1    015204          4826    4827    4828    4830#
ROR2    015206          4829    4832#
ROR3    015224          4835    4836    4837    4839#
ROR4    015226          4838    4841#
ROR5    015244          4844    4845    4846    4848#
ROR6    015246          4847    4850#
ROR7    015262          4853    4854    4856#
ROTX    012160          3768    3770*   3774    3780#   3793*   3795*   3797    3813*   3814    3818
ROTXAD  012250          3814*   3816*   3822#
ROT0A   011464          3586    3587    3590#
ROT0B   011466          3589    3592#
ROT0C   011510          3595    3596    3599#
ROT1A   011540          3619    3620    3623#
ROT1B   011542          3622    3625#
ROT1C   011566          3628    3629    3632#
ROT1D   011570          3631    3634#
ROT1E   011620          3639    3640    3643#
ROT2A   011654          3661    3663    3667#
ROT2B   011656          3666    3669#
ROT2C   011706          3673    3675    3678#
ROT2D   011710          3677    3680#
ROT2E   011744          3685    3687    3691#
ROT3A   011774          3708    3711#
ROT3B   011776          3710    3713#
ROT3C   012024          3716    3719#
ROT3D   012026          3718    3721#
ROT3E   012054          3724    3727#
ROT4    012112          3746    3748    3751#
ROT5    012156          3773    3775    3778#
ROT6    012210          3796    3799#
ROT7    012246          3817    3820#
RPSW    120544          21954#  22353   22355*  22371*  23427*
RPSW2   124474          22751#  23165   23167*  23181*  23431*
RRBDON  107004          19442   19457#
RRBTP1  106760          19418   19424   19425*  19432   19445#  19453
RRBTP2  106770          19419   19433   19449#
RRBTP3  107000          19423   19438   19453#
RRB10   107002          19436   19439   19441   19455#
RRB2    106714          19429#
RRCDON  115564          21185   21194#
RRCTB0  115542          21168   21188#
RRCTB1  115546          21176   21181   21183   21189#
RRCTB2  115556          21175   21179   21183   21191#
RRC10   115562          21173   21180   21182   21184   21192#
RRC2    115510          21178#
RRRDON  101654          17957   17975#
RRREXP  101644          17948   17971#
RRRTP1  101624          17926   17961#
RRRTP2  101634          17932   17966#
RRR10   101622          17934   17952   17955   17958#
RRR2    101554          17943#
RRR3    101556          17925   17944#  17949
RRR4    101602          17951#  17953
RTCPSW  120556          21961#  22570   22572*  22602*  22618   22620*  22639*  23433*
RTCVT   120554          21960#  22508   22509*  22533*  22569   22571*  22582*  22590*  22601*  22617   22619*  22631*  22638*
                        22652   22653*  22665*  22673   22674*  22687*  23418   23432*  23522*
```

```
RTI1     023200            6414    6418#
RTI2     023204            6415    6420#
RTRAP  = 000010             541#    763*    764*    778*    779*   6742*
RTRAP1= 000034              532#    792*    793*    807*    808*
RTRAP2= 000020              531#    838*    839*    853*    854*
RTRAP3= 000030              530#    867*    868*    882*    883*
RTRAP4= 000014              529#    904*    905*    919*    920*   6335*   6347*   6361*
RTRAP5= 000004              528#    939*    940*    954*    955*    968*    969*    983*    984*   6688*   6703*   6720*   6740*
RTS1     013440            4224    4229#
RTT1     023070            6379    6382#
RTT2     023076            6380    6386#
RTT3     023130            6394    6398#
RTT4     023140            6395    6402#
RTT5     023102            6392#   6400    6405
RTT6     023152            6403    6407#
RVECT    120542           21953#  22124   22125*  22145*  22298   22299*  22309*  22315*  22324   22325*  22336*  22344*  22352
                          22354*  22366*  22370*  22375*  22384   22385*  22399*  22408   22409*  22423*  23417   23426*  23521*
RVECT2   124472           22750#  22931   22932*  22956*  23115   23116*  23124*  23131*  23139   23140*  23150*  23157*  23164
                          23166*  23176*  23180*  23186*  23194   23195*  23207*  23221   23222*  23235*  23415   23430*  23519*
ROTRAP   023412            6483    6488#
R1ERR    003466            1211    1216#
R2ERR    003546            1241    1246#
R3ERR    003626            1272    1277#
R4ERR    003706            1303    1308#
R5ERR    003766            1335    1340#
R6ERR    004046            1366    1371#
SADR     055472           12767*  12778   12783*  12786#
SBC1     014770            4733    4734    4735    4737#
SBC2     014772            4736    4739#
SBC3     015010            4742    4743    4744    4746#
SBC4     015012            4745    4748#
SBC5     015030            4751    4752    4753    4755#
SBC6     015032            4754    4757#
SBC7     015052            4761    4762    4764#
SB0      012264            3838    3840#
SB2      012344            3878    3880#
SB4      012426            3918    3920#
SB5      012470            3946#
SB5A     012462            3942    3944#
SB5X     012472            3939*   3941    3948#   3949
SB5XAD   012474            3938    3944    3949#
SB6      012524            3970#
SB6X     012526            3965*   3966    3972#
SB7      012556            3994#
SB7X     012560            3989*   3996#   3997
SB7XAD   012562            3990    3997#
SCOPE  = 000240             511#
SC3      020322            5702*   5721#   5730*   5731
SC4      020336            5703*   5725#   5729*
SDATO0   055506           12725   12728   12751   12754   12793#
SDATO1   055510           12794#
SDATO2   055512           12795#
SDATO3   055514           12796#
SDONE    055516           12783   12798#
SECND    124410           22728#
SERRO    055402           12712   12764#
```

```
SERR1   055310          12717   12735#  12772   12777
SERR10  055420          12768#  12784
SERR4   055452          12742   12780#
SETBR   001410            714#    751
SETCC   001430            718#    746
SETCD   020320           5717    5720#   5732
SETREG  050152           9715    9754   11406#
SETUP   001372            711#
SET2BR  001500            723     727#
SHL     003234           1097#   1100
SHLE    003250           1098    1102#
SHR     003314           1123#   1126
SHRE    003330           1124    1128#
SKTST2  024324           6644#
SLU1ST  120560           6534    6554   11548   21902   21963#
SLU2ST  124502          22487   22698   22724   22755#
SL1HLT  123216            681*  22482#
SL2HLT  127302            682*  23343#
SNMB0A  005736           2206    2207    2209#
SNMB1A  006006           2253    2254    2256#
SNMB1B  006010           2255    2258#
SNMB1C  006032           2263    2264    2265    2267#
SNMB2A  006112           2315    2316    2318#
SNMB2B  006114           2317    2320#
SNMB2C  006122           2321    2323#
SNMB2D  006142           2327    2328    2329    2331#
SNMB2E  006144           2330    2333#
SNMB3A  006244           2389    2390    2392#
SNMB3B  006246           2391    2394#
SNMB3C  006264           2397    2398    2399    2401#
SNMB3D  006266           2400    2403#
SNM0A   005714           2182    2183    2184    2186#
SNM1A   005762           2229    2230    2231    2233#
SNM2A   006056           2286    2287    2288    2290#
SNM2B   006060           2289    2292#
SNM3A   006202           2356    2357    2358    2360#
SNM3B   006204           2359    2362#
SNM4A   006320           2425    2426    2428#
SNM4B   006322           2427    2430#
SNM5A   006356           2453    2454    2456#
SNM5B   006360           2455    2458#
SNM6A   006416           2481    2482    2484#
SNM6B   006420           2483    2486#
SNM7A   006454           2508    2509    2511#
SNM7B   006456           2510    2513#
SOB1    016210           5152#   5159
SOB2    016216           5152    5153    5155#
SOB3    016220           5154    5157#
SOB4    016240           5160    5161    5162    5165#
SOPA    005650           2155    2157#
SOPB    005670           2159    2162#
SOPB0A  004244           1513    1515#
SOPB0B  004254           1516    1519#
SOPB1A  004316           1561    1563#
SOPB1B  004334           1564    1567    1570#
SOPB1C  004354           1592    1594#
```

```
SOPB1D  004374            1599    1602#
SOPB2A  004460            1658    1660#
SOPB2B  004500            1664    1668#
SOPB2C  004524            1687    1689#
SOPB2D  004550            1695    1699#
SOPB3A  005034            1848    1850#
SOPB3B  005060            1853    1855    1860#
SOPB3C  005102            1886    1888#
SOPB3D  005124            1894    1897#
SOPX    005642            2154#   2157*   2158*   2164
SOPXAD  005672            2160*   2164#
SOPZA   004416            1625    1627#
SOP0A   004160            1460    1462#
SOP0B   004172            1465    1467#
SOP0C   004210            1487    1489#
SOP0D   004234            1491    1494    1499#
SOP1A   004266            1536    1538#
SOP1B   004300            1539    1543#
SOP2B   004436            1630    1635#
SOP3A   004774            1814    1816#
SOP3B   005010            1819    1822#
SOP4A   005244            1950    1952#
SOP4B   005264            1955    1960#
SOP5A   005316            1991    1993#
SOP5B   005332            1996    1999#
SOP6A   005352            2018    2020#
SOP6B   005366            2021    2024#
SOP7A   005410            2045    2047#
SOP7B   005424            2048    2051#
SPAT10  055476           12709   12729   12740   12755   12788#
SPAT11  055500           12789#
SPAT12  055502           12790#
SPAT13  055504           12791#
SR0   = 177572            9226#   9306*   9415    9476    9523*   9525    9531*   9851*   9853*   9875*   9877*   9899*   9901*
                           9924*   9926*   9945*   9947*   9975*   9977*   9999*  10001*  10023*  10025*  10047*  10049*  10089*
                          10132*  10248   10249*  10320   10335*  10378   10393*  10465   10481*  10484*  10559   10575*  10578*
                          10648*  10694   10699   10715*  10716   10730*  10812   10828*  10853   10855*  11356*
SR1   = 177574            9227#   9539
SR2   = 177576            9228#   9485    9505   10321   10379   10466   10560   10641   10674   10682   10695   10700   10720
                          10731   10813   10854
SR3   = 172516            9229#   9545*   9546    9553*   9554    9850*   9874*   9898*   9923*   9944*   9974*   9998*  10022*
                          10046*  10088*
SSBDON  107146           19492   19507#
SSBTP1  107122           19468   19474   19475*  19482   19495#  19503
SSBTP2  107132           19469   19483   19499#
SSBTP3  107142           19473   19488   19503#
SSB10   107144           19486   19489   19491   19505#
SSB2    107056           19479#
SSCDON  115710           21227   21235#
SSCTB0  115672           21208   21230#
SSCTB1  115676           21216   21221   21223   21225   21231#
SSC10   115706           21213   21220   21222   21224   21226   21233#
SSC2    115630           21218#
SSSA1   102016           17997   18010   18022#
SSSBF0  102006           17988   18001   18003   18018#
SSSDON  102040           18015   18035#
```

```
SSSTP1  102026          17994   18004   18028#
SSS10   102036          17996   18002   18007   18013   18033#
SSS2    101726          17999#
START   001200            654     662#
STATUS= 177776            539#    765*    769     780*    783     794*    798     809*    812     840*    844     855*    858
                          869*    873     884*    887     906*    910     921*    924     941*    945     956*    959     970*
                          974     985*    988    6488*   6489    6516*   6517    6547*   6553*   6567*   6574*   6588*   6641*
                         6667*   6670
STBOT   001000            545     546     651#    655     664     671     762     771     773     775     785     791     800
                          802     804     814     837     846     848     850     860     866     875     877     879     889
                          903     912     914     916     926     938     947     949     951     961     967     976     978
                          980     990    1392    4116    4131    4146    4152    4222    5178    5191    5202    5553    5555
                         5566    5575    5588    5595    5905    6149    6313    6334    6346    6353    6360    6366    6376
                         6392    6412    6430    6449    6455    6478    6492    6505    6520    6529    6566    6587    6632
                         6656    6673    6687    6691    6758    6774    6779    6827    6834    6837    6840    6940    9302
                        11545   21818   21926   23585
STCDFS  103606          18428   18447   18466   18485   18504   18554#
STCDT   103736          18560   18566   18573   18589#
STCFDS  103154          18248   18267   18286   18305   18324   18378#
STCFT   103304          18384   18390   18397   18413#
STCIBF  117272          21559   21565   21572   21590#
STCSUB  117144          21347   21357   21367   21377   21388   21398   21408   21418   21429   21439   21449   21459   21469
                        21479   21489   21500   21511   21554#  21608
STP     022702           6325    6328#
STP3    023336           6457#
STP3D   023340           6456    6459#
STP4    024462           6675#
STP4E   024464           6653    6674    6677#
STXBF   117666          21722*  21723*  21730   21733   21740   21746#
STXSUB  117554          21631   21640   21649   21659   21669   21679   21720#
SUB0    006540           2563    2564    2565    2567#
SUB0A   006542           2566    2569#
SUB1    014656           4692    4693    4695#
SUB2    014660           4694    4697#
SUB3    014702           4701    4702    4704#
SUB4    014704           4703    4706#
SUB5    014722           4710    4711    4713#
SUB6    014724           4712    4715#
SUB7    014744           4718    4719    4720    4722#
SWB1    014154           4472    4473    4475#
SWB2    014156           4474    4477#
SWB3    014174           4480    4481    4482    4484#
SWR     021324           6030#   6034*   6796*   6811*   6818    9307    11546   21963   22485   22755   23357
SWREG   000176            639#
SXT0    016056           5079    5080    5081    5082    5085#
SXT1    016060           5084    5087#
SXT2    016110           5093    5094    5095    5096    5099#
SX10    055344          12749#
SX11    055370          12757#  12760
SX12    055376          12758   12760#
SX2     055246          12720#
SX3     055250          12721#  12764
SX4     055254          12723#
SX5     055300          12731#  12734
SX6     055306          12732   12734#
SX7     055312          12739#  12767
```

```
SX8      055336          12746#
SX9      055340          12747#  12780
S1       025434           6915#   6916    7204    7245    7777    7788    7834
S10      025456           6924#   8991    9021
S11      025460           6925#
S2       025436           6916#   7205    7228    7778    7811
S3       025440           6917#
S4       025442           6918#
S5       025444           6919#   6920    8413    8422    8464
S6       025446           6920#   8414    8443
S7       025450           6921#
S8       025452           6922#
S9       025454           6923#   6924    8990    9000    9042
TABLE    025260           6813    6848#
TBIT   = 000020           9278#  11369   11374   11387
TBITPS   037360           9293#   9305*  11372*  11387   11389   11390*
TBLEND   127324          23354#  23388
TBL1     011256           3484    3485*   3486*   3487*   3488*   3489    3498#   3514*   3515*   3516*   3517*   3518    3522
                          3523    3524    3525    3526    3541    3542*   3543*   3544*   3545*   3546    3564*   3565*   3566*
                          3567*   3568
TBL2     011324           3513    3526#   3563
TBUF     120540          21952#  21990   22006*  22011*  22028*  22031*  22235*  22238*  22258*  22280*  22301*  22327*  22358*
                         22388*  22412*  22432*  22458*  23452*
TBUF2    124470          22749#  22782   22798*  22803*  22825*  22828*  23051*  23054*  23073*  23099*  23118*  23141*  23169*
                         23197*  23224*  23243*  23269*  23293*  23311*  23469*
TCCBF0   111660          20253   20261   20271#
TCCBF1   111670          20257   20273#
TCCDON   111700          20266   20276#
TCC2     111620          20254#
TCC3     111650          20262   20265#
TCSR     120536          21951#  21976   22007   22012   22016   22029   22034   22074   22077*  22078   22081*  22082   22085*
                         22087   22099   22103*  22104   22107*  22108   22112*  22114   22153*  22156   22163*  22168*  22177*
                         22181   22183*  22188*  22202*  22208   22210*  22219*  22230*  22234*  22236   22241*  22256*  22263*
                         22279*  22284*  22295*  22297*  22304*  22307*  22326*  22333*  22339*  22342*  22357*  22361*  22387*
                         22391*  22411*  22430*  22433   22437*  22456*  22464*  22468*  23434*  23435*  23455*  23486*
TCSR2    124466          22748#  22768   22799   22804   22808   22826   22831   22871   22874*  22875   22878*  22879   22888*
                         22890   22902   22906*  22907   22910*  22911   22919*  22921   22964*  22967   22974*  22979*  22988*
                         22992   22994*  22999*  23013*  23019   23021*  23030*  23046*  23050*  23052   23057*  23113*  23244
                         23273*  23292*  23296*  23438*  23472*  23487*
TDATI0   052502          12010   12015   12030   12040   12045   12071   12095#
TDATI1   052504          12096#
TDATI2   052506          12068*  12097#
TDATI3   052510          12069*  12098#
TDATO0   052472          12026   12029   12065   12070   12090#
TDATO1   052474          12091#
TDATO2   052476          12092#
TDATO3   052500          12093#
TDEC1    022162           6190    6193#
TDEC2    022176           6200    6202#
TDEC3    022242           6215    6217#
TDEC4    022274           6222    6225#
TDEC6    022310           6228#
TDEC7    022312           6226    6230#
TDEC77   023704           6549    6558#
TDEC8    023702           6551    6556#
TDONE    052512          12077   12100#
```

```
TEMP1   025420          6550* 6561  6568* 6581  6591* 6603  6657* 6677  6905# 6906  6941* 6961  6991
                        7019  7047  7075  7106  7136* 7142* 7157* 7164* 7182* 7195* 7389* 7397  7434
                        7471  7510* 7518* 7532* 7540* 7547* 7552* 7558* 7589* 7596*
TEMP2   025422          6907# 6908  6942* 6964  6968  6985* 6994  6997  7013* 7022  7025  7041* 7050
                        7053  7069* 7079  7082  7099* 7109  7112  7129* 7137* 7143* 7149* 7153* 7158*
                        7165* 7170* 7176* 7183* 7189* 7390* 7398  7435  7472  7511* 7559* 7566* 7577*
                        7582* 7590* 7597*
TEMP3   025424          6909# 6910  6943* 6974  6986* 7003  7014* 7031  7042* 7059  7070* 7088  7100*
                        7118  7130* 7138* 7144* 7159* 7166* 7171* 7177* 7184* 7190* 7391* 7402  7405
                        7426* 7439  7442  7462* 7476  7479  7500* 7512* 7524* 7528* 7533* 7553* 7560*
                        7571* 7578* 7583* 7598*
TEMP4   025426          6911# 6912  6944* 6970  6999  7027  7055  7084  7114  7145* 7160* 7172* 7178*
                        7185* 7191* 7196* 7392* 7411  7429* 7448  7465* 7485  7503* 7513* 7519* 7534*
                        7541* 7567* 7572* 7584* 7599*
TEMP5   025430          6913# 7393* 7414  7428* 7451  7464* 7488  7502* 7514* 7535* 7542* 7548* 7561*
                        7585* 7591*
TEMP6   025432          6914# 7394* 7407  7444  7481  7520* 7536* 7543* 7554* 7562* 7573* 7592* 7600*
TENSAV  025044          6788* 6801# 6812
TESTN1  021326          5953  6032#
TEST1   014112          4449  4450  4451  4453#
TEST2   014114          4452  4455#
TEST3   014132          4459  4460  4462#
THRPRT  025466          6831  6935#
TICKER  130010         23432 23448#
TICKS   130402         23423* 23448* 23483 23529#
TKB   = 177562           535#  6616
TOFF    050064         10144 10194  10245 10749 10838 11369#
TOLER   124376         22721 22723#
TON     050120         10187 10237  10272 10774 10892 11387#
TONT1   023262          6434  6443#
TO10    021260           616  1007  5999# 6241  6760  6780  6830  21924
TO114   021272           628  6009#
TO14    021262           618  1008  6001# 6283  6443  6459  6643
TO20    021264           620  1010  6003# 6251  6444
TO244   021274           631  6011#
TO250   021276           633  6013#  9303 10130 10348 10400 10490 10584 10657 10741 10830 10890 11035
                       11176 11297
TO30    021266           623  6005#
TO34    021270           625  1009  6007# 6273  6602
TO4     021256           614   669  1006  5997# 6293  6306  6328  6524  6533  6535  6559  6759  10271
                       10773 10829 10888 21923
TPAT10  052452         12009 12039 12080#
TPAT11  052454         12081#
TPAT12  052456         12082#
TPAT13  052460         12083#
TPAT20  052462         12018 12048 12085#
TPAT21  052464         12086#
TPAT22  052466         12087#
TPAT23  052470         12088#
TPB   = 177566           516#   536#  6662* 6665* 21858* 21861* 21872* 21875* 23597*
TPS   = 177564           515#
TPSW    120550         21956# 22204 22206* 22224* 23425*
TPSW2   124500         22753# 23015 23017* 23035* 23429*
TRACE   023256          6431  6439#
TRAPA = 000077           540#   766   781  6745
TRAPB   023534          6493  6511  6524#
```

```
TRAPC = 104777            548#    810
TRAPPC  037350           9289#
TRAPPS  037352           9290#
TRAP10  025046           6789    6802#
TRCSR = 177560            534#   6617*   6619
TRC1    023326           6450    6453    6455#
TRPADR  023410           6485#   6492
TRT   = 000003            526#    907     922
TR0     024014           6569    6576#
TR2     024020           6572    6580#
TR3     024126           6590    6597#
TR4     024132           6592    6600#
TR5     024130           6594    6598#
TSTSPC  037310           9207#
TST160  030502           7433    7469    7507    7516#
TST161  030530           7517    7522#
TST162  030546           7523    7526#
TST163  030564           7527    7530#
TST164  030626           7531    7538#
TST165  030664           7539    7545#
TST166  030710           7546    7550#
TST167  030740           7551    7556#
TST170  030776           7557    7564#
TST171  031022           7565    7569#
TST172  031050           7570    7575#
TST173  031072           7576    7580#
TST174  031130           7581    7587#
TST175  031164           7588    7594#
TST176  031236           7612#
TST177  031304           7632#
TST200  031352           7652#
TST201  031424           7674#
TST202  031472           7694#
TST203  031540           7714#
TST204  031612           7736#
TST205  031660           7756#
TST206  031752           7784#
TST207  032030           7807#
TST210  032106           7830#
TST211  032164           7853#
TST212  032240           7876#
TST213  032314           7899#
TST214  032370           7922#
TST215  032446           7945#
TST216  032524           7968#
TST217  032600           7991#
TST220  032654           8028#
TST221  032724           8049#
TST222  032774           8070#
TST223  033044           8091#
TST224  033120           8114#
TST225  033170           8135#
TST226  033240           8156#
TST227  033314           8179#
TST230  033364           8200#
TST231  033434           8221#
```

```
TST232  033504          8242#
TST233  033560          8265#
TST234  033630          8286#
TST235  033700          8307#
TST236  033750          8328#
TST237  034024          8351#
TST240  034074          8372#
TST241  034144          8393#
TST242  034234          8420#
TST243  034304          8441#
TST244  034354          8462#
TST245  034424          8483#
TST246  034472          8504#
TST247  034540          8525#
TST250  034606          8546#
TST251  034656          8567#
TST252  034726          8588#
TST253  034774          8609#
TST254  035042          8636#
TST255  035116          8657#
TST256  035172          8678#
TST257  035252          8701#
TST260  035326          8722#
TST261  035402          8743#
TST262  035462          8766#
TST263  035536          8787#
TST264  035612          8808#
TST265  035666          8829#
TST266  035746          8852#
TST267  036022          8873#
TST270  036076          8894#
TST271  036156          8917#
TST272  036232          8938#
TST273  036306          8959#
TST274  036354          8977#
TST275  036432          8997#
TST276  036506          9018#
TST277  036562          9039#
TST300  036636          9060#
TST301  036710          9081#
TST302  036762          9102#
TST303  037034          9123#
TST304  037110          9144#
TST305  037164          9165#
TST306  037236          9186#
TST37   026576          6990    7018    7046    7074    7104    7134    7140#
TST40   026632          7141    7147#
TST41   026646          7148    7151#
TST42   026664          7152    7155#
TST43   026720          7156    7162#
TST44   026752          7163    7168#
TST45   027004          7169    7174#
TST46   027036          7175    7180#
TST47   027074          7181    7187#
TST50   027124          7188    7193#
TST51   027176          7210#
```

```
TST52   027236            7227#
TST53   027276            7244#
TST54   027336            7261#
TST55   027374            7278#
TST56   027432            7295#
TST57   027470            7312#
TST60   027530            7329#
TST61   027570            7346#
TST62   027626            7363#
TS1     001372             676     710#
TS10    002646             966#
TS100   005716            2185    2200#
TS101   005740            2208    2223#
TS102   005764            2232    2246#
TS103   006034            2266    2280#
TS104   006070            2294    2308#
TS105   006154            2335    2348#
TS106   006214            2364    2379#
TS107   006276            2405    2418#
TS11    003042            1016#
TS110   006330            2431    2444#
TS111   006370            2460    2473#
TS112   006426            2487    2500#
TS113   006464            2514    2526#
TS114   006502            2532    2542#
TS115   006520            2548    2558#
TS116   006550            2570    2584#
TS117   006644            2613    2624#
TS12    003060            1020    1026#
TS120   006710            2639    2650#
TS121   006766            2672    2682#
TS122   007026            2697    2710#
TS123   007046            2717    2729#
TS124   007066            2736    2749#
TS125   007106            2756    2773#
TS126   007142            2786    2799#
TS127   007164            2807    2820#
TS13    003100            1030    1036#
TS130   007212            2830    2845#
TS131   007242            2854    2866#
TS132   007274            2878    2891#
TS133   007320            2896    2908#
TS134   007344            2913    2925#
TS135   007370            2930    2936#
TS136   007422            2948    2954#
TS137   007454            2966    2972#
TS14    003120            1040    1046#
TS140   007520            2988    2994#
TS141   007614            3021    3028#
TS142   007714            3056    3062#
TS143   007770            3079    3085#
TS144   010064            3110    3116#
TS145   010142            3133    3139#
TS146   010216            3155    3161#
TS147   010274            3177    3189#
TS15    003140            1049    1069#
```

```
TS150   010324          3201    3213#
TS151   010366          3230    3241#
TS152   010454          3263    3274#
TS153   010564          3296    3309#
TS154   010626          3323    3337#
TS155   010714          3358    3373#
TS156   011010          3395    3409#
TS157   011112          3431    3444#
TS16    003166          1074    1080#
TS160   011212          3465    3483#
TS161   011260          3490    3512#
TS162   011326          3519    3540#
TS163   011374          3547    3562#
TS164   011442          3569    3582#
TS165   011512          3598    3614#
TS166   011622          3642    3656#
TS167   011746          3690    3704#
TS17    003220          1087    1093#
TS170   012056          3726    3741#
TS171   012114          3750    3767#
TS172   012162          3777    3792#
TS173   012212          3798    3812#
TS174   012252          3819    3835#
TS175   012274          3841    3854#
TS176   012320          3859    3873#
TS177   012354          3881    3895#
TS2     001614           761#
TS20    003252          1101    1108#
TS200   012400          3899    3913#
TS201   012434          3921    3937#
TS202   012476          3945    3964#
TS203   012530          3969    3988#
TS204   012564          3993    4034#
TS205   013032          4089    4112#
TS206   013420          4206    4221#
TS207   013450          4230    4249#
TS21    003300          1113    1119#
TS210   013510          4264    4270#
TS211   013554          4286    4292#
TS212   013620          4307    4313#
TS213   013666          4330    4348#
TS214   013752          4374    4381#
TS215   014054          4414    4431#
TS216   014074          4438    4445#
TS217   014134          4461    4467#
TS22    003332          1127    1154#
TS220   014176          4483    4500#
TS221   014314          4537    4544#
TS222   014400          4569    4586#
TS223   014472          4614    4621#
TS224   014612          4655    4662#
TS225   014634          4669    4687#
TS226   014746          4721    4728#
TS227   015054          4763    4780#
TS23    003344          1158    1164#
TS230   015162          4815    4821#
```

| | | | | |
|---|---|---|---|---|
| TS231 | 015264 | 4855 | 4861# | |
| TS232 | 015374 | 4897 | 4903# | |
| TS233 | 015514 | 4942 | 4950# | |
| TS234 | 015662 | 4998 | 5005# | |
| TS235 | 015730 | 5022 | 5030# | |
| TS236 | 016030 | 5060 | 5074# | |
| TS237 | 016112 | 5098 | 5112# | |
| TS24 | 003360 | 1167 | 1173# | |
| TS240 | 016200 | 5135 | 5148# | |
| TS241 | 016242 | 5164 | 5177# | |
| TS242 | 016364 | 5205 | 5221# | |
| TS243 | 016430 | 5235 | 5242# | |
| TS244 | 016466 | 5251 | 5257# | |
| TS245 | 016532 | 5267 | 5273# | |
| TS246 | 016572 | 5282 | 5288# | |
| TS247 | 016630 | 5297 | 5303# | |
| TS25 | 003374 | 1176 | 1182# | |
| TS250 | 016674 | 5312 | 5318# | |
| TS251 | 016740 | 5327 | 5341# | |
| TS252 | 017006 | 5353 | 5359# | |
| TS253 | 017056 | 5374 | 5380# | |
| TS254 | 017132 | 5395 | 5401# | |
| TS255 | 017206 | 5416 | 5422# | |
| TS256 | 017262 | 5437 | 5443# | |
| TS257 | 017340 | 5458 | 5464# | |
| TS26 | 003410 | 1185 | 1191# | |
| TS260 | 017416 | 5479 | 5493# | |
| TS261 | 017456 | 5497 | 5502 | 5514# |
| TS262 | 017516 | 5536# | | |
| TS263 | 017630 | 5565# | | |
| TS264 | 017710 | 5583# | | |
| TS265 | 017772 | 5596 | 5611# | |
| TS266 | 020124 | 5653# | | |
| TS267 | 020162 | 5672# | | |
| TS27 | 003436 | 1199 | 1206# | |
| TS270 | 020204 | 5679 | 5699# | |
| TS271 | 020376 | 5749# | | |
| TS272 | 020432 | 5761 | 5767# | |
| TS273 | 020466 | 5779 | 5785# | |
| TS274 | 020556 | 5806 | 5812# | |
| TS275 | 020646 | 5834 | 5848# | |
| TS276 | 020664 | 5852 | 5858# | |
| TS277 | 020706 | 5862 | 5868# | |
| TS3 | 001736 | 790# | | |
| TS30 | 003470 | 1215 | 1221# | |
| TS300 | 020736 | 5873 | 5879# | |
| TS301 | 020762 | 5883 | 5889# | |
| TS302 | 021004 | 5893 | 5903# | |
| TS303 | 021022 | 5908 | 5918# | |
| TS304 | 021052 | 5924 | 5930# | |
| TS305 | 021114 | 5938 | 5944# | |
| TS306 | 021344 | 6039# | | |
| TS307 | 021544 | 6095 | 6100# | |
| TS31 | 003516 | 1229 | 1236# | |
| TS310 | 022004 | 6143 | 6148# | |
| TS311 | 022130 | 6178 | 6185# | |

```
TS312   022162          6198#
TS313   022206          6203    6209#
TS314   022312          6235#
TS315   022346          6245#
TS316   022402          6256#
TS317   022436          6267#
TS32    003550          1245    1252#
TS320   022472          6277#
TS321   022526          6287#
TS322   022572          6295    6300#
TS323   022626          6311#
TS324   022714          6333#
TS325   022744          6345#
TS326   023004          6354    6359#
TS327   023042          6367    6374#
TS33    003576          1260    1267#
TS330   023076          6383    6390#
TS331   023152          6411#
TS332   023212          6422    6428#
TS333   023276          6448#
TS334   023346          6474#
TS335   023606          6540#
TS336   023730          6565#
TS337   024040          6586#
TS34    003630          1276    1283#
TS340   024172          6610#
TS341   024236          6545    6614    6620    6626#
TS342   024324          6630    6649#
TS343   024500          6682#
TS344   024532          6692    6701#
TS345   024562          6708    6719#
TS346   024612          6725    6739#
TS347   024730          6772#
TS35    003656          1291    1298#
TS350   024766          6785#
TS351   037456          9318#
TS352   037512          9337#
TS353   037554          9356#
TS354   037642          9375    9384#
TS355   037700          9391    9414#
TS356   037724          9426#
TS357   037744          9438#
TS36    003710          1307    1315#
TS360   037764          9450#
TS361   040004          9462#
TS362   040024          9474#
TS363   040142          9520#
TS364   040176          9537#
TS365   040260          9556    9566#
TS366   040350          9593    9600#
TS367   040446          9629    9638#
TS37    003736          1323    1330#
TS370   040552          9668    9675#
TS371   040656          9704    9711#
TS372   041022          9746#
TS373   041206          9752    9829#
```

```
TS374   041662            9952    9964#
TS375   042212           10068#
TS376   042560           10131   10142#
TS377   042734           10192#
TS4     002132             836#
TS40    003770            1339    1346#
TS400   043122           10243#
TS401   043244           10289#
TS402   043522           10308   10354#
TS403   043712           10436#
TS404   044212           10459   10492   10532#
TS405   044476           10553   10586   10627#
TS406   044652           10664#
TS407   045244           10669   10748#
TS41    004016            1354    1361#
TS410   045402           10779#
TS411   045446           10790   10800#
TS412   045600           10837#
TS413   046104           10904#
TS414   046600           11041#
TS415   047332           11102   11183#
TS416   047732           11303#
TS417   050014           11334#
TS42    004050            1370    1391#
TS420   050556           11556#
TS421   050650           11592#
TS422   050704           11617#
TS423   051134           11705#
TS424   051302           11762#
TS425   051350           11790#
TS426   051710           11903#
TS427   052212           12007#
TS43    004072            1395    1401#
TS430   052516           12112#
TS431   054326           12509#
TS432   055214           12707#
TS433   055522           12808#
TS434   055666           12873#
TS435   056032           12935#
TS436   056230           13008#
TS437   056366           13069#
TS44    004112            1404    1410#
TS440   056542           13135#
TS441   056716           13202#
TS442   057040           13254#
TS443   057172           13313#
TS444   057760           13458#
TS445   060334           13561#
TS446   060730           13671#
TS447   061160           13738#
TS45    004132            1413    1419#
TS450   061372           13804#
TS451   061676           13904#
TS452   062506           14080#
TS453   063306           14252#
TS454   064206           14444#
```

```
TS455   064444          14519#
TS456   064670          14606#
TS457   065444          14779#
TS46    004152           1422   1458#
TS460   066446          15005#
TS461   067310          15210#
TS462   070114          15454#
TS463   070370          15552#
TS464   071122          15731#
TS465   071614          15886#
TS466   072346          16064#
TS467   072700          16185#
TS47    004200           1468   1484#
TS470   073202          16318#
TS471   073564          16463#
TS472   074116          16601#
TS473   074530          16752#
TS474   075464          16977#
TS475   076700          17243#
TS476   077340          17403#
TS477   100044          17565#
TS5     002254            865#
TS50    004236           1498   1511#
TS500   100742          17732#
TS501   101036          17750  17779#
TS502   101220          17839#
TS503   101506          17923#
TS504   101660          17985#
TS505   102044          18045#
TS506   102210          18098#
TS507   102354          18148#
TS51    004256           1518   1533#
TS510   102512          18194#
TS511   102666          18245#
TS512   103320          18425#
TS513   103752          18600#
TS514   104012          18627#
TS515   104132          18674#
TS516   104172          18699#
TS517   104232          18726#
TS52    004302           1542   1556#
TS520   104366          18782#
TS521   104524          18833#
TS522   104652          18880#
TS523   105010          18931#
TS524   105156          18982#
TS525   105324          19034#
TS526   105456          19080#
TS527   105626          19131#
TS53    004336           1569   1586#
TS530   105744          19174#
TS531   106102          19223#
TS532   106226          19271#
TS533   106356          19318#
TS534   106506          19366#
TS535   106650          19416#
```

```
TS536   107010          19467#
TS537   107152          19516#
TS54    004376           1601   1618#
TS540   107302          19563#
TS541   107436          19609#
TS542   107600          19661#
TS543   107752          19714#
TS544   110672          19982#
TS545   110754          20018#
TS546   111030          20055#
TS547   111130          20086#
TS55    004440           1634   1651#
TS550   111236          20119#
TS551   111336          20151#
TS552   111432          20183#
TS553   111542          20220#
TS554   111606          20249#
TS555   111704          20288#
TS556   112704          20532#
TS557   113460          20705#
TS56    004502           1667   1679#
TS560   114764          21008#
TS561   115076          21047#
TS562   115210          21087#
TS563   115322          21125#
TS564   115444          21165#
TS565   115570          21205#
TS566   115714          21246#
TS567   116052          21287#
TS57    004552           1698   1710#
TS570   116130          21315#
TS571   116206          21344#
TS572   117306          21604#
TS573   117346          21628#
TS574   117704          21759#
TS575   120012          21800#
TS576   120102          21830#
TS577   120152          21847#
TS6     002402            902#
TS60    004624           1734   1739#
TS600   120610          21973#
TS601   120636          21987#
TS602   120664          22000#
TS603   120752          22027#
TS604   121004          22035   22043#
TS605   121032          22056#
TS606   121060          22073#
TS607   121154          22088   22095#
TS61    004704           1763   1768#
TS610   121272          22123#
TS611   121410          22152#
TS612   121502          22176#
TS613   121602          22201#
TS614   121720          22229#
TS615   122026          22255#
TS616   122076          22278#
```

```
TS617   122140          22286   22294#
TS62    004756           1788    1808#
TS620   122272          22322#
TS621   122424          22351#
TS622   122564          22382#
TS623   122666          22406#
TS624   122770          22429#
TS625   123064          22453#
TS626   123250          22495#
TS627   123276          22507#
TS63    005012           1821    1840#
TS630   123432          22538#
TS631   123534          22543   22567#
TS632   123722          22611#
TS633   124056          22615   22645#
TS634   124162          22649   22671#
TS635   124260          22694#
TS636   124532          22765#
TS637   124560          22779#
TS64    005062           1859    1879#
TS640   124606          22792#
TS641   124670          22796   22819#
TS642   124740          22823   22832   22840#
TS643   124766          22853#
TS644   125014          22870#
TS645   125126          22886   22891   22898#
TS646   125262          22930#
TS647   125416          22963#
TS65    005126           1896    1902#
TS650   125510          22987#
TS651   125610          23012#
TS652   125726          23040#
TS653   126052          23044   23071#
TS654   126136          23098#
TS655   126164          23104   23112#
TS656   126274          23137#
TS657   126376          23163#
TS66    005230           1931    1945#
TS660   126522          23192#
TS661   126610          23214#
TS662   126722          23218   23241#
TS663   127002          23263#
TS664   127076          23267   23291#
TS665   127154          23308#
TS666   127356          23366#
TS667   127504          23370   23406#
TS67    005266           1959    1981#
TS7     002524            937#
TS70    005334           1998    2013#
TS71    005370           2023    2039#
TS72    005426           2050    2057#
TS73    005464           2072    2077#
TS74    005534           2097    2102#
TS75    005574           2117    2122#
TS76    005640           2138    2152#
TS77    005674           2161    2177#
```

```
TTBDON  107276          19540   19554#
TTBTP1  107254          19517   19522   19530   19536   19543#
TTBTP2  107264          19518   19531   19547#
TTB10   107274          19534   19537   19539   19552#
TTB2    107210          19527#
TTCDON  116046          21268   21277#
TTCSR = 177564            533#   6531    6552*   6558*   6570*   6582*   6589*   6605*   6655*   6660    6663    6666*   6678*
                         6786*  21859   21862*  21871*  21873   21876*  21894*  23595   23599
TTCTB0  116024          21248   21271#
TTCTB1  116030          21257   21264   21266   21272#
TTCTB2  116040          21256   21262   21274#
TTC10   116044          21253   21261   21263   21265   21267   21275#
TTC2    115762          21259#
TTTA1   102166          18078#
TTTA2   102170          18052*  18058   18062   18079#
TTTBF0  102154          18047   18052   18064   18073#  18079
TTTDON  102204          18070   18088#
TTTTP1  102172          18055   18065   18080#
TTT10   102202          18057   18063   18068   18085#
TTT2    102120          18060#
TTT3    102144          18067#  18069
TVECT   120546          21955#  22096   22097*  22117*  22154   22155*  22162*  22170*  22179   22180*  22189*  22195*  22203
                        22205*  22216*  22223*  22232   22233*  22245*  23416   23424*  23520*
TVECT2  124476          22752#  22899   22900*  22924*  22965   22966*  22973*  22981*  22990   22991*  23000*  23006*  23014
                        23016*  23027*  23034*  23048   23049*  23061*  23414   23428*  23518*
TYPE    131640          23557   23589   23593#
T105    052312          12033   12035#
T12     052314          12039#
T13     052330          12042#  12043
T14     052356          12053#
T15     052360          12054#
T16     052362          12055#
T17     052400          12060   12062#
T2      052230          12012#  12013
T20     052440          12073#  12076
T23     052446          12074   12076#
T3      052254          12022#
T4      052256          12023#
T5      052260          12024#
T6      052304          12032#  12035
UDONE   057760          13419   13452#
UERR0   057314          13322   13338#
UERR3   057646          13400   13412#
UFLAG   057744          13314*  13388   13395*  13446#
UIPAR0= 177640           9244#   9452    9594    9669    9736    9791    10075   10752*  10769*  10921*  11419   11475
UIPAR1= 177642           9245#  10922*
UIPAR2= 177644           9246#  10923*
UIPAR3= 177646           9247#  10196   10294*  10839*  10924*
UIPAR4= 177650           9248#  10092*  10113*  10128*  10295*  10840*  10929*  11045*  11193*
UIPAR5= 177652           9249#  10093*  10114*  10129*
UIPAR6= 177654           9250#
UIPAR7= 177656           9251#   9592    9667    10925*
UIPDR0= 177600           9233#   9464    9630    9705    9729    9779    10082   10200   10203   10216   10918   11187   11415
                        11462
UIPDR1= 177602           9234#
UIPDR2= 177604           9235#
```

```
UIPDR3= 177606          9236#  10297*  10841*  10891*
UIPDR4= 177610          9237#  10090*  10115*  10304*  10363*  10842*  11043*  11200*
UIPDR5= 177612          9238#  10091*  10116*
UIPDR6= 177614          9239#
UIPDR7= 177616          9240#   9628    9703
UNIQUE  127326         22757   23324   23357#
UPAT00  057674         13315   13325   13343   13360   13375   13391   13403   13421#
UPAT01  057676         13422#
UPAT02  057700         13423#
UPAT03  057702         13424#
UPAT10  057704         13331   13426#
UPAT11  057706         13427#
UPAT12  057710         13428#
UPAT13  057712         13429#
UPAT20  057714         13349   13431#
UPAT21  057716         13432#
UPAT22  057720         13433#
UPAT23  057722         13434#
UPAT30  057724         13365   13436#
UPAT31  057726         13437#
UPAT32  057730         13438#
UPAT33  057732         13439#
UPAT40  057734         13380   13405   13441#
UPAT41  057736         13442#
UPAT42  057740         13443#
UPAT43  057742         13444#
UROM1   057752         13327*  13345*  13362*  13377*  13449#
UROM2   057754         13328*  13346*  13363*  13378*  13450#
UROM3   057756         13329*  13347*  13364*  13379*  13451#
USESTK= 000600           546#   5568    5575    5587    5934    5937    5946    9388   10756   10771   10859   10942   11061
                       11203   11310   11328
USP1    017472          5518#   5519
USP1A   017510          5520    5523#
USP2    017546          5540    5543#
USP3    017564          5545    5547#
USP4    017612          5551    5553#
USRM  = 140000           517#   5515    5521    5523    5537    5541    5543    5548    5550    5554    5567    5572    5574
                        5586    5590    5592
UTMP1   057746         13320*  13327   13377   13396*  13447#
UTMP2   057750         13321*  13345   13362   13397*  13448#
UUBDON  107432         19590   19600#
UUBTP1  107346         19565   19569   19570*  19576#  19580
UUBTP2  107420         19564   19581   19593#
UUB10   107430         19584   19587   19589   19598#
UUB2    107344         19575#
UUCBF0  116116         21292   21296   21303#
UUCDON  116124         21297   21305#
UUCTP1  116104         21290   21300#
UUC2    116072         21294#
UUUA1   102332         18105*  18129#
UUUA2   102334         18111   18113   18130#
UUUBF0  102320         18100   18105   18115   18124#  18129
UUUDON  102350         18121   18138#
UUUTP1  102336         18108   18116   18131#
UUU10   102346         18110   18114   18119   18136#
UUU2    102264         18112#
```

```
UUU3    102310          18118#  18120
U0      057206          13317#  13318
U1      057230          13322#  13398
U10     057520          13381#
U11     057522          13382#
U12     057540          13386   13388#
U13     057556          13393#  13394
U14     057610          13389   13400#
U15     057636          13406#
U16     057640          13407#  13412
U2      057300          13332#
U3      057316          13337   13340#
U4      057360          13351#
U5      057376          13356   13358#
U6      057440          13367#
U7      057456          13371   13373#
VDEC    022340           6238    6241#
VDEC10  022514           6279    6282#
VDEC11  022550           6289    6292#
VDEC12  022554           6290    6293#
VDEC13  022614           6302    6305#
VDEC14  022620           6303    6306#
VDEC2   022334           6237    6240#
VDEC3   022374           6248    6251#
VDEC4   022370           6247    6250#
VDEC5   022430           6259    6262#
VDEC6   022424           6258    6261#
VDEC7   022464           6270    6273#
VDEC8   022460           6269    6272#
VDEC9   022520           6280    6283#
VVBDON  104226          18712   18716#
VVB10   104224          18709   18711   18713#
VVB2    104200          18703#
VVCBF0  116174          21321   21325   21332#
VVCDON  116202          21326   21334#
VVCTP1  116162          21319   21329#
VVC2    116150          21323#
VVVBF0  102464          18152   18160   18164   18166   18173#
VVVDON  102506          18172   18184#
VVVTP1  102474          18158   18167   18177#
VVV10   102504          18157   18165   18170   18182#
VVV2    102426          18162#
WAITER  130214          23490#
WAITI0  130004          23445#  23446
WASR6   037346          9288#
WASSR0  037354           9291#  10320*  10322   10378*  10380   10465*  10468   10559*  10562   10699*  10701   10716*  10717
                        10812*  10815   10853*  10872
WASSR2  037356           9292#   9485*   9487    9505*   9506   10321*  10329   10379*  10387   10466*  10475   10560*  10569
                        10641*  10642   10674*  10676   10682*  10684   10700*  10704   10720*  10721   10731*  10733   10813*
                        10822   10854*  10875
WATE    024442           6658    6670#
WATE1   024374           6660#   6661
WATE2   024410           6663#   6664
WATE3   024436           6668#   6673
WBIT  = 000100           9279#  10159   10167   10178   10209   10217   10228
WDAP00  060320          13545#
```

```
WDAT01  060322          13546#
WDAT02  060324          13547#
WDAT03  060326          13548#
WDONE   060330          13537   13550#
WDONE1  122042          22259#  22262
WDONE2  126060          23074#  23077
WPAT00  060310          13461   13463   13467   13469   13480   13484   13488   13490   13501   13503   13507   13509   13520
                        13524   13528   13530   13540#
WPAT01  060312          13541#
WPAT02  060314          13542#
WPAT03  060316          13543#
WWBDON  110666          19886   19970#
WWB1    107752          19716#
WWB10   110364          19849#
WWB11   110432          19868#
WWB2    110020_         19735#
WWB3    110066          19754#
WWB4    110134          19773#
WWB5    110202          19792#
WWB6    110250          19811#
WWB7    110316          19830#
WWCDON  117302          21520   21593#
WWC1    116206          21347#
WWC10   116512          21418#
WWC11   116546          21429#
WWC12   116602          21439#
WWC13   116636          21449#
WWC14   116672          21459#
WWC15   116726          21469#
WWC16   116762          21479#
WWC17   117016          21489#
WWC2    116242          21357#
WWC20   117052          21500#
WWC21   117106          21511#
WWC3    116276          21367#
WWC4    116332          21377#
WWC5    116366          21388#
WWC6    116422          21398#
WWC7    116456          21408#
WWWBF0  102630          18198   18208   18213   18220#
WWWBF1  102650          18206   18208*  18211   18228#
WWWDON  102662          18219   18235#
WWWTP1  102640          18204   18214   18224#
WWW10   102660          18203   18212   18217   18233#
WWW2    102572          18209#
W10     060122          13493   13495#
W11     060134          13497   13499#
W12     060154          13504#
W13     060200          13511#  13514
W14     060206          13512   13514#
W15     060220          13516   13518#
W16     060244          13525#
W17     060270          13532#  13535
W2      060000          13464#
W20     060276          13533   13535#
W3      060024          13471#  13474
```

CJKDE-B 11/24 CPU CLUSTER DIAG. MACY11 30(1046) 05-AUG-82 15:03 PAGE 484
CJKDEB.P11 05-AUG-82 15:01 CROSS REFERENCE TABLE -- USER SYMBOLS

```
W4      060032          13472   13474#
W5      060044          13476   13478#
W6      060070          13485#
W7      060114          13492#  13495
X       120364          21890#
XAPT11  060706          13653#
XBUF    100626          17608   17610   17622   17624   17637   17639   17685   17687   17700#
XDAT00  060664          13570   13590   13610   13630   13642#
XDAT01  060666          13643#
XDAT02  060670          13644#
XDAT03  060672          13645#
XDONE   060724          13640   13661#
XMIT1   130020          23424   23450#
XMIT2   130102          23428   23467#
XMTCT1  130372          23419*  23450*  23453   23496   23501   23525#
XMTCT2  130374          23420*  23467*  23470   23507   23512   23526#
XOR1    016146           5118    5119    5120    5121    5124#
XOR2    016150           5123    5126#
XOR3    016176           5130    5131    5132    5133    5136#
XPAT0   100726          17645*  17646   17652*  17653   17716#
XPAT0   100636          17578   17580   17588   17590   17601   17630   17659   17702#
XPAT00  060674          13564   13572   13604   13612   13647#
XPAT01  060676          13648#
XPAT02  060700          13649#
XPAT03  060702          13650#
XPAT1   100646          17704#
XPAT10  060704          13566   13586   13606   13626   13652#
XPAT12  060710          13654#
XPAT13  060712          13655#
XPAT2   100656          17684   17706#
XPAT20  060714          13584   13592   13624   13632   13656#
XPAT21  060716          13657#
XPAT22  060720          13658#
XPAT23  060722          13659#
XPAT3   100666          17602   17616   17631   17708#
XPAT4   100676          17644   17651   17660   17667   17668   17675   17676   17683   17710#
XPAT5   100706          17692   17712#
XPAT6   100716          17693   17714#
XTDONE  100736          17696   17719#
XT1     100044          17566#
XT1A    100060          17566   17569#
XT10    100470          17663   17666#
XT11    100516          17671   17674#
XT12    100544          17679   17682#
XT13    100600          17688   17691#
XT2     100062          17568   17572#
XT2A    100102          17576   17578#
XT2B    100120          17581   17583#
XT3     100132          17585   17587#
XT3A    100154          17591   17593#
XT4     100164          17595   17598#
XT4A    100214          17599   17604#
XT4B    100226          17606   17608#
XT5     100244          17611   17614#
XT5A    100264          17614   17618#
XT5B    100276          17620   17622#
```

```
XT6     100314          17625   17628#
XT6A    100340          17628   17633#
XT6B    100352          17635   17637#
XT7     100370          17640   17643#
XT8     100416          17647   17650#
XT9     100444          17654   17658#
XXBDON  107574          19636   19651#
XXBTP1  107552          19610   19615   19616*  19626   19632   19639#
XXBTP2  107562          19611   19627   19643#
XXB10   107572          19625   19630   19633   19635   19649#
XXB2    107500          19621#
XXCDON  117342          21617#
XXXDON  103314          18341   18415#
XXX1    102666          18248#
XXX2    102732          18267#
XXX3    102776          18286#
XXX4    103042          18305#
XXX5    103106          18324#
X10     060474          13595   13597#
X11     060510          13600   13602#
X12     060530          13607#
X13     060554          13614#  13617
X14     060562          13615   13617#
X15     060576          13620   13622#
X16     060616          13627#
X17     060642          13634#  13637
X2      060354          13567#
X20     060650          13635   13637#
X3      060400          13574#  13577
X4      060406          13575   13577#
X5      060422          13580   13582#
X6      060442          13587#
X7      060466          13594#  13597
Y       120366          21867   21891#
YBR     001534            725*    728*    738#
YDAT00  061114          13684   13709#
YDAT01  061116          13710#
YDAT02  061120          13711#
YDAT03  061122          13712#
YDONE   061154          13702   13729#
YFLAG   061104          13672*  13695   13697*  13704#
YNTAB   021220            712    5973#
YPAT00  061124          13673   13699   13714#
YPAT01  061126          13715#
YPAT02  061130          13716#
YPAT03  061132          13717#
YPAT10  061134          13674   13698   13719#
YPAT11  061136          13720#
YPAT12  061140          13721#
YPAT13  061142          13722#
YPAT20  061144          13678   13724#
YPAT21  061146          13725#
YPAT22  061150          13726#
YPAT23  061152          13727#
YTMP1   061106          13673*  13680   13698*  13705#
YTMP2   061110          13674*  13687   13699*  13706#
```

```
YTMP3   061112          13675* 13692  13700* 13707#
YYBDON  107746          19690  19705#
YYBTP1  107722          19663  19669  19670* 19680  19693#  19701
YYBTP2  107732          19664  19681  19697#
YYBTP3  107742          19668  19686  19701#
YYB10   107744          19679  19684  19687  19689  19702#
YYB2    107650          19675#
YYCDON  117700          21687  21749#
YYC1    117346          21631#
YYC2    117374          21640#
YYC3    117422          21649#
YYC4    117450          21659#
YYC5    117476          21669#
YYC6    117524          21679#
YYYDON  103746          18521  18591#
YYY1    103320          18428#
YYY2    103364          18447#
YYY3    103430          18466#
YYY4    103474          18485#
YYY5    103540          18504#
Y1      060756          13676# 13701
Y2      060776          13681#
Y3      061022          13688# 13691
Y4      061042          13693  13695#
Y5      061102          13696  13702#
Z       120370          21868* 21886* 21887  21892#
ZDAT00  061326          13750  13773#
ZDAT01  061330          13774#
ZDAT02  061332          13775#
ZDAT03  061334          13776#
ZDONE   061366          13767  13793#
ZFLAG   061320          13739* 13761  13763* 13769#
ZPAT00  061336          13740  13778#
ZPAT01  061340          13779#
ZPAT02  061342          13780#
ZPAT03  061344          13781#
ZPAT10  061346          13764  13783#
ZPAT11  061350          13784#
ZPAT12  061352          13785#
ZPAT13  061354          13786#
ZPAT20  061356          13744  13788#
ZPAT21  061360          13789#
ZPAT22  061362          13790#
ZPAT23  061364          13791#
ZTMP1   061322          13740* 13746  13753  13764* 13770#
ZTMP2   061324          13741* 13758  13765* 13771#
ZZCBF   117774          21766  21772  21785#
ZZCDON  120006          21779  21789#
ZZC10   117770          21774  21776  21778  21780#
ZZC2    117712          21764# 21775
ZZC3    117732          21769#
ZZZDON  104006          18612  18617#
ZZZ10   104004          18609  18611  18614#
ZZZ2    103760          18604#
Z1      061200          13742# 13766
Z2      061220          13747#
```

```
Z3      061244          13754#  13757
Z4      061252          13755   13757#
Z5      061264          13759   13761#
Z6      061316          13762   13767#
$APTHD  001030            597     603#
$BDADR  127224          23326#
$BDDAT  127226          23327#
$CPUOP  001026            579#
$DEVCT  001010            570#
$DOAGN  131570          23552   23571#
$ENDAD  131522            556   23561#
$ENV    001020            575#    675   5494   6032   6541   6611   6627   6650   9749  10666  11498  22001  22523
                        22540   22612  22646  22695  22793  22820  22883  22914  22946  23041  23080  23215  23264
                        23367   23407
$ENVM   001021            576#  23593
$EOPCT  131456          23551#  23555*
$ETABL  001020            574#
$ETEND  001030            586#    609
$FATAL  001002            567#    673*    828*    830*  11518*  11520*  21912*  21914*  22478*  22480*  22738*  22740*  23339*
                        23341*  23538*  23540*
$GDADR  127230          23328#
$GDDAT  127232          23329#
$HIBTS  001030            604#
$MAIL   001000            565#    605     609
$MBADR  001032            605#
$MSGAD  001014            572#
$MSGLG  001016            573#
$MSGTY  001000            566#    674*    831*  11521*  21915*  22481*  22741*  23342*  23541*
$PASS   001006            569#    662*   5496   6543   6613   6629   6652   6962   6992   7020   7048   7077   7107
                          7400    7437   7474   9751  10668  11500  22003  22525  22542  22614  22648  22697  22795
                        22822   22885  22916  22948  23043  23082  23217  23266  23369  23409  23553*  23554*
$PASTM  001036            607#
$SETUP= 000020            6929#
$STUP = 177777            6929#
$SVPC = 000400            554#    559
$SWR  = 000000            507#
$SWREG  001022            577#   6034
$TESTN  001004            568#    656    672*   5642   6937   9311*  11550*  21966*  22488*  22758*  23360*
$TMP0   037362           9294#   9849*   9855   9873*   9879   9897*   9903   9973*   9979   9997*  10003  10021*  10027
                        10045*  10051  10094*  10306*  10336  10365*  10394  10694*  10701  10861*  10867*  10871*  10874*
                        10878*  10879  21853*  21895  23414*  23518  23565*  23570
$TMP1   037364           9295#  10691*  10703*  10706*  10707  10713*  10719*  10723*  10724  21854*  21896  23415*  23519
$TMP2   037366           9296#  10695*  10704   10998*  10999  11023*  11024   11128  11129*  11161*  11163  11261*  11262
                        11286*  11287  17738*  17898*  19988*  20060*  23416*  23520
$TMP3   037370           9297#  23417*  23521
$TMP4   037372           9298#  23418*  23522
$TN   = 000670            507#    707    711#    758    762#    787    791#    833    837#    862    866#    899    903#
                           934    938#    963    967#   1013   1017#   1020   1023   1027#   1030   1033   1037#   1040
                          1043   1047#   1049   1066   1070#   1074   1077   1081#   1087   1090   1094#   1101   1105
                          1109#  1113   1116   1120#   1127   1151   1155#   1158   1161   1165#   1167   1170   1174#
                          1176   1179   1183#   1185   1188   1192#   1199   1203   1207#   1215   1218   1222#   1229
                          1233   1237#   1245   1249   1253#   1260   1264   1268#   1276   1280   1284#   1291   1295
                          1299#  1307   1312   1316#   1323   1327   1331#   1339   1343   1347#   1354   1358   1362#
                          1370   1388   1392#   1395   1398   1402#   1404   1407   1411#   1413   1416   1420#   1422
                          1455   1459#   1468   1481   1485#   1498   1508   1512#   1518   1530   1534#   1542   1553
                          1557#   1569   1583   1587#   1601   1615   1619#   1634   1648   1652#   1667   1676   1680#
```

```
1698    1707    1711#   1734    1736    1740#   1763    1765    1769#   1788    1805    1809#   1821
1837    1841#   1859    1876    1880#   1896    1899    1903#   1931    1942    1946#   1959    1978
1982#   1998    2010    2014#   2023    2036    2040#   2050    2054    2058#   2072    2074    2078#
2097    2099    2103#   2117    2119    2123#   2138    2149    2153#   2161    2174    2178#   2185
2197    2201#   2208    2220    2224#   2232    2243    2247#   2266    2277    2281#   2294    2305
2309#   2335    2345    2349#   2364    2376    2380#   2405    2415    2419#   2431    2441    2445#
2460    2470    2474#   2487    2497    2501#   2514    2523    2527#   2532    2539    2543#   2548
2555    2559#   2570    2581    2585#   2613    2621    2625#   2639    2647    2651#   2672    2679
2683#   2697    2707    2711#   2717    2726    2730#   2736    2746    2750#   2756    2770    2774#
2786    2796    2800#   2807    2817    2821#   2830    2842    2846#   2854    2863    2867#   2878
2888    2892#   2896    2905    2909#   2913    2922    2926#   2930    2933    2937#   2948    2951
2955#   2966    2969    2973#   2988    2991    2995#   3021    3025    3029#   3056    3059    3063#
3079    3082    3086#   3110    3113    3117#   3133    3136    3140#   3155    3158    3162#   3177
3186    3190#   3201    3210    3214#   3230    3238    3242#   3263    3271    3275#   3296    3306
3310#   3323    3334    3338#   3358    3370    3374#   3395    3406    3410#   3431    3441    3445#
3465    3480    3484#   3490    3509    3513#   3519    3537    3541#   3547    3559    3563#   3569
3579    3583#   3598    3611    3615#   3642    3653    3657#   3690    3701    3705#   3726    3738
3742#   3750    3764    3768#   3777    3789    3793#   3798    3809    3813#   3819    3832    3836#
3841    3851    3855#   3859    3870    3874#   3881    3892    3896#   3899    3910    3914#   3921
3934    3938#   3945    3961    3965#   3969    3985    3989#   3993    4031    4035#   4089    4109
4113#   4206    4218    4222#   4230    4246    4250#   4264    4267    4271#   4286    4289    4293#
4307    4310    4314#   4330    4345    4349#   4374    4378    4382#   4414    4428    4432#   4438
4442    4446#   4461    4464    4468#   4483    4497    4501#   4537    4541    4545#   4569    4583
4587#   4614    4618    4622#   4655    4659    4663#   4669    4684    4688#   4721    4725    4729#
4763    4777    4781#   4815    4818    4822#   4855    4858    4862#   4897    4900    4904#   4942
4947    4951#   4998    5002    5006#   5022    5027    5031#   5060    5071    5075#   5098    5109
5113#   5135    5145    5149#   5164    5174    5178#   5205    5218    5222#   5235    5239    5243#
5251    5254    5258#   5267    5270    5274#   5282    5285    5289#   5297    5300    5304#   5312
5315    5319#   5327    5338    5342#   5353    5356    5360#   5374    5377    5381#   5395    5398
5402#   5416    5419    5423#   5437    5440    5444#   5458    5461    5465#   5479    5490    5494#
5497    5502    5511    5515#   5533    5537#   5562    5566#   5580    5584#   5596    5608    5612#
5650    5654#   5669    5673#   5679    5696    5700#   5746    5750#   5761    5764    5768#   5779
5782    5786#   5806    5809    5813#   5834    5845    5849#   5852    5855    5859#   5862    5865
5869#   5873    5876    5880#   5883    5886    5890#   5893    5900    5904#   5908    5915    5919#
5924    5927    5931#   5938    5941    5945#   6036    6040#   6095    6097    6101#   6143    6145
6149#   6178    6182    6186#   6195    6199#   6203    6206    6210#   6232    6236#   6242    6246#
6253    6257#   6264    6268#   6274    6278#   6284    6288#   6295    6297    6301#   6308    6312#
6330    6334#   6342    6346#   6354    6356    6360#   6367    6371    6375#   6383    6387    6391#
6408    6412#   6422    6425    6429#   6445    6449#   6471    6475#   6537    6541#   6562    6566#
6583    6587#   6607    6611#   6614    6620    6623    6627#   6630    6646    6650#   6679    6683#
6692    6698    6702#   6708    6716    6720#   6725    6736    6740#   6769    6773#   6782    6786#
9315    9319#   9334    9338#   9353    9357#   9375    9381    9385#   9391    9411    9415#   9423
9427#   9435    9439#   9447    9451#   9459    9463#   9471    9475#   9517    9521#   9534    9538#
9556    9563    9567#   9593    9597    9601#   9629    9635    9639#   9668    9672    9676#   9704
9708    9712#   9743    9747#   9752    9826    9830#   9952    9961    9965#   10065   10069#  10131
10139   10143#  10189   10193#  10240   10244#  10286   10290#  10308   10351   10355#  10433   10437#
10459   10492   10529   10533#  10553   10586   10624   10628#  10661   10665#  10669   10745   10749#
10776   10780#  10790   10797   10801#  10834   10838#  10901   10905#  11038   11042#  11102   11180
11184#  11300   11304#  11331   11335#  11553   11557#  11589   11593#  11614   11618#  11702   11706#
11759   11763#  11787   11791#  11900   11904#  12004   12008#  12109   12113#  12506   12510#  12704
12708#  12805   12809#  12870   12874#  12932   12936#  13005   13009#  13066   13070#  13132   13136#
13199   13203#  13251   13255#  13310   13314#  13455   13459#  13558   13562#  13668   13672#  13735
13739#  13801   13805#  13901   13905#  14077   14081#  14249   14253#  14441   14445#  14516   14520#
14603   14607#  14776   14780#  15002   15006#  15207   15211#  15451   15455#  15549   15553#  15728
15732#  15883   15887#  16061   16065#  16182   16186#  16315   16319#  16460   16464#  16598   16602#
16749   16753#  16974   16978#  17240   17244#  17400   17404#  17562   17566#  17729   17733#  17750
```

```
                    17776  17780#  17836  17840#  17920  17924#  17982  17986#  18042  18046#  18095  18099#  18145
                    18149# 18191   18195# 18242   18246# 18422   18426# 18597   18601# 18624   18628# 18671   18675#
                    18696  18700#  18723  18727#  18779  18783#  18830  18834#  18877  18881#  18928  18932#  18979
                    18983# 19031   19035# 19077   19081# 19128   19132# 19171   19175# 19220   19224# 19268   19272#
                    19315  19319#  19363  19367#  19413  19417#  19464  19468#  19513  19517#  19560  19564#  19606
                    19610# 19658   19662# 19711   19715# 19979   19983# 20015   20019# 20052   20056# 20083   20087#
                    20116  20120#  20148  20152#  20180  20184#  20217  20221#  20246  20250#  20285  20289#  20529
                    20533# 20702   20706# 21005   21009# 21044   21048# 21084   21088# 21122   21126# 21162   21166#
                    21202  21206#  21243  21247#  21284  21288#  21312  21316#  21341  21345#  21601  21605#  21625
                    21629# 21756   21760# 21797   21801# 21827   21831# 21844   21848# 21970   21974# 21984   21988#
                    21997  22001#  22024  22028#  22035  22040   22044# 22053   22057# 22070   22074# 22088   22092
                    22096# 22120   22124# 22149   22153# 22173   22177# 22198   22202# 22226   22230# 22252   22256#
                    22275  22279#  22286  22291   22295# 22319   22323# 22348   22352# 22379   22383# 22403   22407#
                    22426  22430#  22450  22454#  22492  22496#  22504  22508#  22535  22539#  22543  22564   22568#
                    22608  22612#  22615  22642   22646# 22649   22668  22672#  22691  22695#  22762  22766#  22776
                    22780# 22789   22793# 22796   22816  22820#  22823  22832   22837  22841#  22850  22854#  22867
                    22871# 22886   22891  22895   22899# 22927   22931# 22960   22964# 22984   22988# 23009   23013#
                    23037  23041#  23044  23068   23072# 23095   23099# 23104   23109  23113#  23134  23138#  23160
                    23164# 23189   23193# 23211   23215# 23218   23238  23242#  23260  23264#  23267  23288   23292#
                    23305  23309#  23363  23367#  23370  23403   23407#

$TPB    025462   6926#
$TPS    025464   6927#
$TSTM   001034    606#
$UNIT   001012    571#
$UNITM  001040    608#
$USWR   001024    578#  23555
$X    = 127504    711#   762#   791#   837#   866#   903#   938#   967#  1017#  1027#  1037#  1047#  1070#
                 1081#  1094#  1109#  1120#  1155#  1165#  1174#  1183#  1192#  1207#  1222#  1237#  1253#
                 1268#  1284#  1299#  1316#  1331#  1347#  1362#  1392#  1402#  1411#  1420#  1459#  1485#
                 1512#  1534#  1557#  1587#  1619#  1652#  1680#  1711#  1740#  1769#  1809#  1841#  1880#
                 1903#  1946#  1982#  2014#  2040#  2058#  2078#  2103#  2123#  2153#  2178#  2201#  2224#
                 2247#  2281#  2309#  2349#  2380#  2419#  2445#  2474#  2501#  2527#  2543#  2559#  2585#
                 2625#  2651#  2683#  2711#  2730#  2750#  2774#  2800#  2821#  2846#  2867#  2892#  2909#
                 2926#  2937#  2955#  2973#  2995#  3029#  3063#  3086#  3117#  3140#  3162#  3190#  3214#
                 3242#  3275#  3310#  3338#  3374#  3410#  3445#  3484#  3513#  3541#  3563#  3583#  3615#
                 3657#  3705#  3742#  3768#  3793#  3813#  3836#  3855#  3874#  3896#  3914#  3938#  3965#
                 3989#  4035#  4113#  4222#  4250#  4271#  4293#  4314#  4349#  4382#  4432#  4446#  4468#
                 4501#  4545#  4587#  4622#  4663#  4688#  4729#  4781#  4822#  4862#  4904#  4951#  5006#
                 5031#  5075#  5113#  5149#  5178#  5222#  5243#  5258#  5274#  5289#  5304#  5319#  5342#
                 5360#  5381#  5402#  5423#  5444#  5465#  5494#  5515#  5537#  5566#  5584#  5612#  5654#
                 5673#  5700#  5750#  5768#  5786#  5813#  5849#  5859#  5869#  5880#  5890#  5904#  5919#
                 5931#  5945#  6040#  6101#  6149#  6186#  6199#  6210#  6236#  6246#  6257#  6268#  6278#
                 6288#  6301#  6312#  6334#  6346#  6360#  6375#  6391#  6412#  6429#  6449#  6475#  6541#
                 6566#  6587#  6611#  6627#  6650#  6683#  6702#  6720#  6740#  6773#  6786#  9319#  9338#
                 9357#  9385#  9415#  9427#  9439#  9451#  9463#  9475#  9521#  9538#  9567#  9601#  9639#
                 9676#  9712#  9747#  9830#  9965#  10069#  10143#  10193#  10244#  10290#  10355#  10437#  10533#
                10628#  10665#  10749#  10780#  10801#  10838#  10905#  11042#  11184#  11304#  11335#  11557#  11593#
                11618#  11706#  11763#  11791#  11904#  12008#  12113#  12510#  12708#  12809#  12874#  12936#  13009#
                13070#  13136#  13203#  13255#  13314#  13459#  13562#  13672#  13739#  13805#  13905#  14081#  14253#
                14445#  14520#  14607#  14780#  15006#  15211#  15455#  15553#  15732#  15887#  16065#  16186#  16319#
                16464#  16602#  16753#  16978#  17244#  17404#  17566#  17733#  17780#  17840#  17924#  17986#  18046#
                18099#  18149#  18195#  18246#  18426#  18601#  18628#  18675#  18700#  18727#  18783#  18834#  18881#
                18932#  18983#  19035#  19081#  19132#  19175#  19224#  19272#  19319#  19367#  19417#  19468#  19517#
                19564#  19610#  19662#  19715#  19983#  20019#  20056#  20087#  20120#  20152#  20184#  20221#  20250#
                20289#  20533#  20706#  21009#  21048#  21088#  21126#  21166#  21206#  21247#  21288#  21316#  21345#
                21605#  21629#  21760#  21801#  21831#  21848#  21974#  21988#  22001#  22028#  22044#  22057#  22074#
```

```
                22096# 22124# 22153# 22177# 22202# 22230# 22256# 22279# 22295# 22323# 22352# 22383# 22407#
                22430# 22454# 22496# 22508# 22539# 22568# 22612# 22646# 22672# 22695# 22766# 22780# 22793#
                22820# 22841# 22854# 22871# 22899# 22931# 22964# 22988# 23013# 23041# 23072# 23099# 23113#
                23138# 23164# 23193# 23215# 23242# 23264# 23292# 23309# 23367# 23407#
.      = 131741   550#   554   555#   557#   559#   560#   593   594#   596#   598#   613#   622#   627#
                  630#   636#   644#   650#   653#   660#   711   722   745   750   762   791   832
                   837   866   903   938   967  1017  1027  1037  1047  1070  1081  1094  1109
                  1120  1155  1165  1174  1183  1192  1207  1222  1237  1253  1268  1284  1299
                  1316  1331  1347  1362  1392  1402  1411  1420  1459  1485  1512  1534  1557
                  1587  1619  1652  1680  1711  1740  1769  1809  1841  1880  1903  1946  1982
                  2014  2040  2058  2078  2103  2123  2153  2178  2201  2224  2247  2281  2309
                  2349  2380  2419  2445  2474  2501  2527  2543  2559  2585  2625  2651  2683
                  2711  2730  2750  2774  2800  2821  2846  2867  2892  2909  2926  2937  2955
                  2973  2995  3029  3063  3086  3117  3140  3162  3190  3214  3242  3275  3310
                  3338  3374  3410  3445  3484  3513  3541  3563  3583  3615  3657  3705  3742
                  3768  3793  3813  3836  3855  3874  3896  3914  3938  3965  3989  4035  4038
                  4113  4222  4250  4271  4293  4314  4349  4382  4432  4446  4468  4501  4545
                  4587  4622  4663  4688  4729  4781  4822  4862  4904  4951  5006  5031  5075
                  5113  5149  5178  5222  5243  5258  5274  5289  5304  5319  5342  5360  5381
                  5402  5423  5444  5465  5494  5515  5537  5566  5584  5612  5654  5673  5700
                  5750  5768  5786  5813  5849  5859  5869  5880  5890  5904  5919  5931  5945
                  5956  5957  5958  5959  5960  5961  5962  5963  5964  5965  5966  5967  5968
                  5969  5970  6040  6101  6149  6186  6199  6210  6236  6246  6257  6268  6278
                  6288  6301  6312  6334  6337  6346  6349  6360  6363  6366  6375  6391  6412
                  6429  6436  6449  6475  6541  6566  6587  6611  6627  6650  6683  6702  6720
                  6740  6773  6786  6888  6902# 6904# 6906# 6908# 6910# 6912#  9319  9338  9357
                  9385  9415  9427  9439  9451  9463  9475  9521  9538  9567  9601  9639  9676
                  9712  9747  9830  9965 10069 10143 10193 10244 10290 10355 10437 10533 10628
                 10665 10749 10780 10801 10838 10905 11042 11184 11304 11335 11522 11557 11593
                 11618 11706 11763 11791 11904 12008 12113 12510 12708 12809 12874 12936 13009
                 13020# 13070 13136 13203 13255 13314 13459 13562 13672 13739 13805 13905 14081
                 14253 14445 14520 14607 14780 15006 15211 15455 15553 15732 15887 16065 16186
                 16319 16464 16602 16753 16978 17244 17404 17566 17733 17780 17840 17924 17986
                 18046 18099 18149 18195 18246 18426 18601 18628 18675 18700 18727 18783 18834
                 18881 18932 18983 19035 19081 19132 19175 19224 19272 19319 19367 19417 19468
                 19517 19564 19610 19662 19715 19983 20019 20056 20087 20120 20152 20184 20221
                 20250 20289 20533 20706 21009 21048 21088 21126 21166 21206 21247 21288 21316
                 21345 21605 21629 21760 21801 21831 21848 21916 21974 21988 22001 22028 22044
                 22057 22074 22096 22124 22153 22177 22202 22230 22256 22279 22295 22323 22352
                 22383 22407 22430 22454 22482 22496 22508 22539 22568 22612 22646 22672 22695
                 22742 22766 22780 22793 22820 22841 22854 22871 22899 22931 22964 22988 23013
                 23041 23072 23099 23113 23138 23164 23193 23215 23242 23264 23292 23309 23343
                 23367 23407 23542 23544# 23545#
.RSET  120474   11582 11608 11695 11753 11780 11893 11997 12101 12499 12697 12799 12863 12925
                 12998 13059 13125 13192 13244 13304 13551 13662 13730 13794 13896 14071 14244
                 14436 14511 14588 14769 14995 15198 15442 15541 15720 15875 16053 16174 16306
                 16451 16589 16739 16965 17231 17391 17555 17720 17767 17827 17914 17976 18036
                 18089 18139 18185 18236 18416 18592 18618 18665 18690 18717 18773 18824 18872
                 18923 18974 19026 19072 19123 19166 19215 19263 19310 19358 19407 19458 19508
                 19555 19601 19652 19706 19971 20008 20045 20078 20111 20143 20175 20209 20239
                 20277 20522 20695 20997 21037 21076 21114 21154 21195 21236 21278 21306 21335
                 21594 21618 21750 21790 21819 21897 21922#
.$X    = 001030   593#   598
```

CJKDE-B 11/24 CPU CLUSTER DIAG. MACY11 30(1046) 05-AUG-82 15:03 PAGE 492
CJKDEB.P11 05-AUG-82 15:01 CROSS REFERENCE TABLE -- MACRO NAMES

```
ACCMAC  11532#  12114   12140   12166   12192   12218   12244   12270   12296   12322   12348   12374   12400
ADDTST   9286#   9844    9868    9892    9968    9992   10016   10040
APTSKP    507#   5494    6611    6627    9749   10665   22539   22612   22646   22793   22820   22882   23041   23215   23264
         23367
COMMEN       1#
ENDCOM       1#
ERROR      507#    739     767     782     796     811     842     857     871     886     908     923     943     958     972
            987   1020    1030    1040    1049    1074    1084    1087    1101    1113    1127    1158    1167    1176    1185
           1199   1215    1229    1245    1260    1276    1291    1307    1323    1339    1354    1370    1395    1404    1413
           1422   1460    1465    1468    1487    1498    1513    1518    1536    1542    1561    1569    1592    1601    1625
           1634   1658    1667    1687    1698    1717    1722    1730    1734    1747    1752    1759    1763    1776    1785
           1788   1814    1821    1848    1859    1886    1896    1914    1918    1923    1926    1931    1950    1959    1991
           1998   2018    2023    2045    2050    2065    2069    2072    2089    2093    2097    2113    2117    2131    2138
           2155   2161    2185    2208    2232    2255    2266    2289    2294    2317    2321    2330    2335    2359    2364
           2391   2400    2405    2427    2431    2455    2460    2483    2487    2510    2514    2532    2548    2566    2570
           2587   2594    2599    2608    2613    2634    2639    2655    2658    2662    2668    2672    2691    2697    2717
           2736   2756    2782    2786    2807    2826    2830    2851    2854    2874    2878    2896    2913    2930    2944
           2948   2962    2966    2979    2984    2988    3003    3007    3013    3018    3021    3040    3044    3051    3056
           3072   3076    3079    3095    3099    3103    3107    3110    3126    3130    3135    3148    3152    3155    3170
           3174   3177    3197    3201    3221    3226    3230    3247    3251    3256    3260    3263    3281    3285    3288
           3292   3296    3316    3320    3323    3343    3346    3351    3355    3358    3380    3384    3387    3392    3395
           3416   3420    3423    3428    3431    3451    3455    3458    3462    3465    3490    3519    3547    3569    3589
           3598   3622    3631    3642    3666    3677    3690    3710    3718    3726    3750    3777    3798    3819    3838
           3841   3859    3878    3881    3899    3918    3921    3942    3945    3969    3993    4039    4042    4050    4056
           4059   4066    4073    4081    4089    4124    4136    4149    4161    4173    4183    4193    4206    4228    4230
           4255   4264    4277    4286    4299    4307    4321    4330    4355    4365    4374    4388    4396    4404    4414
           4438   4452    4461    4474    4483    4506    4514    4522    4528    4537    4551    4560    4569    4594    4604
           4614   4628    4637    4647    4655    4669    4694    4703    4712    4721    4736    4745    4754    4763    4788
           4797   4805    4815    4829    4838    4847    4855    4869    4878    4886    4897    4911    4921    4930    4942
           4956   4962    4968    4972    4984    4988    4994    4998    5012    5016    5022    5036    5042    5047    5056
           5060   5084    5098    5123    5135    5154    5164    5185    5192    5201    5205    5226    5235    5248    5251
           5264   5267    5279    5282    5294    5297    5309    5312    5324    5327    5345    5353    5367    5371    5374
           5388   5392    5395    5409    5413    5416    5430    5434    5437    5451    5455    5458    5472    5476    5479
           5502   5522    5542    5545    5552    5573    5577    5593    5596    5639    5660    5679    5710    5726    5755
           5761   5773    5779    5793    5797    5802    5806    5820    5825    5830    5834    5852    5862    5873    5883
           5893   5908    5924    5938    5953    5997    5999    6001    6003    6005    6007    6009    6011    6013    6043
           6049   6055    6062    6069    6076    6082    6089    6095    6107    6116    6125    6134    6143    6151    6155
           6159   6163    6166    6170    6174    6178    6192    6203    6218    6224    6228    6295    6325    6340    6352
           6354   6367    6383    6401    6405    6419    6422    6439    6441    6456    6485    6490    6493    6511    6518
           6521   6556    6576    6578    6598    6620    6639    6669    6671    6674    6690    6692    6707    6723    6725
           6746   6747    6750    6753    6756    6836    6839    6841    6971    6975    7000    7004    7028    7032    7056
           7060   7085    7089    7115    7119    7199    7214    7217    7231    7234    7248    7251    7265    7268    7282
           7285   7299    7302    7316    7319    7333    7336    7350    7353    7367    7370    7408    7412    7417    7421
           7445   7449    7454    7457    7482    7486    7491    7494    7603    7619    7622    7639    7642    7660    7663
           7681   7684    7701    7704    7722    7725    7743    7746    7763    7766    7769    7791    7794    7797    7814
           7817   7820    7837    7840    7843    7860    7863    7866    7883    7886    7889    7906    7909    7912    7929
           7932   7935    7952    7955    7958    7975    7978    7981    7998    8001    8004    8033    8036    8039    8054
           8057   8060    8075    8078    8081    8097    8100    8103    8119    8122    8125    8140    8143    8146    8162
           8165   8168    8184    8187    8190    8205    8208    8211    8226    8229    8232    8248    8251    8254    8270
           8273   8276    8291    8294    8297    8312    8315    8318    8334    8337    8340    8356    8359    8362    8377
           8380   8383    8399    8402    8405    8425    8428    8431    8446    8449    8452    8467    8470    8473    8488
           8491   8494    8509    8512    8515    8530    8533    8536    8551    8554    8557    8572    8575    8578    8593
           8596   8599    8614    8617    8620    8642    8645    8648    8663    8666    8669    8685    8688    8691    8707
           8710   8713    8728    8731    8734    8750    8753    8756    8772    8775    8778    8793    8796    8799    8814
           8817   8820    8836    8839    8842    8858    8861    8864    8879    8882    8885    8901    8904    8907    8923
           8926   8929    8944    8947    8950    8967    8984    9003    9006    9009    9024    9027    9030    9045    9048
```

CJKDE-B 11/24 CPU CLUSTER DIAG. MACY11 30(1046) 05-AUG-82 15:03 PAGE 493
CJKDEB.P11 05-AUG-82 15:01 CROSS REFERENCE TABLE -- MACRO NAMES

```
          9051    9066    9069    9072    9087    9090    9093    9108    9111    9114    9129    9132    9135    9150    9153
          9156    9171    9174    9177    9192    9195    9198    9211    9214    9325    9344    9364    9375    9391    9480
          9488    9499    9508    9526    9540    9547    9555    9572    9582    9606    9618    9648    9660    9685    9696
          9760    9772    9783    9796    9858    9882    9906    9931    9952    9982   10006   10030   10054   10100   10133
         10160   10170   10179   10210   10220   10229   10252   10264   10308   10315   10323   10330   10367   10373   10381
         10388   10459   10469   10476   10485   10553   10563   10570   10579   10643   10677   10685   10708   10725   10734
         10763   10790   10807   10816   10823   10880   10944   10957   10968   10978   10989   11003   11015   11029   11055
         11072   11088   11102   11104   11119   11136   11152   11170   11208   11221   11232   11242   11253   11266   11278
         11291   11312   11323   11343   11350   11441   11455   11468   11482   11575   11604   11626   11636   11646   11655
         11665   11674   11683   11692   11720   11734   11739   11751   11776   11812   11815   11821   11827   11845   11848
         11854   11860   11930   11957   11971   12033   12060   12074   12461   12648   12732   12735   12758   12761   12765
         12781   12826   12832   12837   12889   12895   12900   12963   12972   13026   13034   13038   13090   13096   13157
         13164   13221   13225   13274   13279   13337   13356   13371   13386   13409   13413   13419   13472   13476   13493
         13497   13512   13516   13533   13537   13575   13580   13595   13600   13615   13620   13635   13640   13689   13693
         13755   13759   13818   13837   13859   13918   13922   13937   13941   13957   13961   13977   13981   13996   14000
         14015   14019   14094   14099   14114   14118   14135   14139   14155   14159   14174   14178   14193   14197   14266
         14271   14286   14291   14306   14311   14326   14330   14345   14349   14364   14369   14384   14389   14458   14463
         14478   14483   14533   14537   14553   14557   14622   14626   14646   14651   1466°   14674   14689   14694   14709
         14714   14795   14800   14812   14816   14825   14830   14836   14853   14858   14872   14881   14886   14892   14909
         14914   14926   14930   14939   14944   14950   15014   15023   15028   15041   15052   15058   15070   15085   15103
         15127   15133   15148   15154   15423   15430   15472   15477   15494   15498   15513   15518   15526   15530   15706
         15709   15712   15863   15868   16039   16042   16045   16162   16167   16292   16298   16437   16443   16556   16559
         16573   16578   16581   16707   16711   16724   16728   16731   16938   16941   16945   16948   16951   17208   17216
         17220   17254   17276   17298   17360   17363   17367   17370   17373   17418   17447   17525   17533   17537   17569
         17576   17581   17585   17591   17595   17603   17606   17611   17617   17620   17625   17632   17635   17640   17647
         17654   17663   17671   17679   17688   17696   17745   17750   17760   17763   17800   17824   17861   17883   17901
         17911   17957   18033   18085   18136   18182   18233   18411   18587   18614   18651   18687   18713   18754   18821
         18869   18920   18971   19023   19069   19120   19163   19212   19260   19307   19355   19404   19455   19505   19552
         19598   19649   19702   19963   20004   20042   20075   20108   20140   20172   20206   20234   20262   20266   20514
         20691   20989   21033   21072   21111   21151   21192   21233   21275   21297   21326   21586   21734   21737   21741
         21780   21809   21812   21866   21882   21977   21991   22013   22019   22035   22047   22060   22075   22079   22083
         22088   22100   22105   22109   22115   22128   22133   22137   22143   22159   22166   22185   22192   22213   22220
         22242   22264   22271   22286   22308   22312   22334   22343   22364   22372   22396   22420   22439   22442   22465
         22499   22512   22517   22521   22531   22546   22553   22559   22578   22587   22597   22628   22634   22662   22683
         22724   22769   22783   22805   22811   22832   22844   22857   22872   22876   22880   22891   22903   22908   22912
         22922   22935   22940   22944   22954   22970   22977   22996   23003   23024   23031   23058   23077   23087   23104
         23121   23127   23146   23153   23174   23182   23204   23232   23249   23252   23278   23282   23298   23301   23316
         23320   23392   23463   23480   23497   23503   23508   23514
ESCAPE      1#
GETPRI      1#
GETSWR      1#
HMAC1   11528#   12520   12524   12528   12532   12536
HMAC2   11530#   12620   12624   12628   12632   12636
HMAC3   11531#   12545   12558   12571   12584   12597
JNE       507#     720     743     748
MSG     11553#  11589#  11614#  11702#  11759#  11787#  11900#  12003#  12108#  12506#  12704#  12805#  12869#  12931#  13004#
        13065#  13131#  13198#  13250#  13310#  13455#  13558#  13668#  13735#  13801#  13901#  14077#  14249#  14441#  14516#
        14603#  14775#  15001#  15206#  15450#  15548#  15727#  15882#  16060#  16181#  16314#  16459#  16597#  16748#  16973#
        17239#  17399#  17561#  17728#  17775#  17835#  17920#  17982#  18042#  18095#  18145#  18191#  18242#  18422#  18597#
        18624#  18671#  18695#  19711#  20216#  20245#  20284#  20528#  20701#  21284#  21312#  21341#  21601#  21625#  21756#
MSG1     9315#  18723#  19220#  19978#
MSG10    9447#
MSG11    9459#
MSG12    9471#
MSG13    9517#
MSG14    9534#
```

```
MSG15     9559#
MSG16     9597#
MSG17     9635#
MSG2      9334#  21004#
MSG20     9672#
MSG21     9708#
MSG21A    9743#
MSG22     9826#
MSG23     9961#
MSG24    10065#
MSG25    10139#
MSG26    10189#
MSG27    10240#
MSG3      9353#
MSG30    10286#
MSG31    10351#
MSG32    10432#
MSG33    10528#
MSG34    10623#
MSG35    10660#
MSG36    10744#
MSG36A   10776#
MSG37    10796#
MSG4      9381#
MSG40    10833#
MSG41    10901#
MSG42    11038#
MSG43    11180#
MSG44    11300#
MSG45    11331#
MSG5      9410#
MSG6      9423#
MSG7      9435#
MULT         1#
NEWTST       1#   507#   707   758   787   833   862   899   934   963  1013  1023  1033  1043  1066
             1077  1090  1105  1116  1151  1161  1170  1179  1188  1203  1218  1233  1249  1264  1280
             1295  1312  1327  1343  1358  1388  1398  1407  1416  1455  1481  1508  1530  1553  1583
             1615  1648  1676  1707  1736  1765  1805  1837  1876  1899  1942  1978  2010  2036  2054
             2074  2099  2119  2149  2174  2197  2220  2243  2277  2305  2345  2376  2415  2441  2470
             2497  2523  2539  2555  2581  2621  2647  2679  2707  2726  2746  2770  2796  2817  2842
             2863  2888  2905  2922  2933  2951  2969  2991  3025  3059  3082  3113  3136  3158  3186
             3210  3238  3271  3306  3334  3370  3406  3441  3480  3509  3537  3559  3579  3611  3653
             3701  3738  3764  3789  3809  3832  3851  3870  3892  3910  3934  3961  3985  4031  4109
             4218  4246  4267  4289  4310  4345  4378  4428  4442  4464  4497  4541  4583  4618  4659
             4684  4725  4777  4818  4858  4900  4947  5002  5027  5071  5109  5145  5174  5218  5239
             5254  5270  5285  5300  5315  5338  5356  5377  5398  5419  5440  5461  5490  5511  5533
             5562  5580  5608  5650  5669  5696  5745  5764  5782  5809  5845  5855  5865  5876  5886
             5900  5915  5927  5941  6035  6097  6145  6182  6195  6206  6232  6242  6253  6264  6274
             6284  6297  6308  6330  6342  6356  6371  6387  6408  6425  6445  6471  6537  6562  6583
             6607  6623  6646  6679  6698  6716  6736  6769  6782  9315  9334  9353  9381  9411  9423
             9435  9447  9459  9471  9517  9534  9563  9597  9635  9672  9708  9743  9826  9961 10065
            10139 10189 10240 10286 10351 10433 10529 10624 10661 10745 10776 10797 10834 10901 11038
            11180 11300 11331 11553 11589 11614 11702 11759 11787 11900 12004 12109 12506 12704 12805
            12870 12932 13005 13066 13132 13199 13251 13310 13455 13558 13668 13735 13801 13901 14077
            14249 14441 14516 14603 14776 15002 15207 15451 15549 15728 15883 16061 16182 16315 16460
            16598 16749 16974 17240 17400 17562 17729 17776 17836 17920 17982 18042 18095 18145 18191
```

```
        18242   18422   18597   18624   18671   18696   18723   18779   18830   18877   18928   18979   19031   19077   19128
        19171   19220   19268   19315   19363   19413   19464   19513   19560   19606   19658   19711   19979   20015   20052
        20083   20116   20148   20180   20217   20246   20285   20529   20702   21005   21044   21084   21122   21162   21202
        21243   21284   21312   21341   21601   21625   21756   21797   21827   21844   21970   21984   21997   22024   22040
        22053   22070   22092   22120   22149   22173   22198   22226   22252   22275   22291   22319   22348   22379   22403
        22426   22450   22492   22504   22535   22564   22608   22642   22668   22691   22762   22776   22789   22816   22837
        22850   22867   22895   22927   22960   22984   23009   23037   23068   23095   23109   23134   23160   23189   23211
        23238   23260   23288   23305   23363   23403
NXTTST   507#    9593    9629    9668    9704   10131   10492   10586
POP        1#
PUSH       1#
REPORT     1#
RSET    11525#  11581   11607   11694   11752   11779   11892   11996   12100   12498   12696   12798   12862   12924   12997
        13058   13124   13191   13243   13303   13550   13661   13729   13793   13895   14070   14243   14435   14510   14587
        14768   14994   15197   15441   15540   15719   15874   16052   16173   16305   16450   16588   16738   16964   17230
        17390   17554   17719   17766   17826   17913   17975   18035   18088   18138   18184   18235   18415   18591   18617
        18664   18689   18716   18772   18823   18871   18922   18973   19025   19071   19122   19165   19214   19262   19309
        19357   19406   19457   19507   19554   19600   19651   19705   19970   20007   20044   20077   20110   20142   20174
        20208   20238   20276   20521   20694   20996   21036   21075   21113   21153   21194   21235   21277   21305   21334
        21593   21617   21749   21789   21819   21897
SETPRI     1#
SETUP      1#
SKIP       1#
SLASH      1#
STARS      1#    507#    552     563     590     592     599     610     612     641     643     648     685     707     709
         758     760     787     789     817     820     833     835     862     864     892     895     899     901     934
         936     963     965     993    1013    1015    1023    1025    1033    1035    1043    1045    1052    1066    1068
        1077    1079    1090    1092    1105    1107    1116    1118    1131    1151    1153    1161    1163    1170    1172
        1179    1181    1188    1190    1203    1205    1218    1220    1233    1235    1249    1251    1264    1266    1280
        1282    1295    1297    1312    1314    1327    1329    1343    1345    1358    1360    1374    1388    1390    1398
        1400    1407    1409    1416    1418    1424    1439    1443    1455    1457    1472    1481    1483    1502    1508
        1510    1522    1530    1532    1546    1553    1555    1574    1583    1585    1605    1615    1617    1638    1648
        1650    1671    1676    1678    1702    1707    1709    1736    1738    1765    1767    1791    1805    1807    1825
        1837    1839    1863    1876    1878    1899    1901    1934    1942    1944    1963    1978    1980    2002    2010
        2012    2027    2036    2038    2054    2056    2074    2076    2099    2101    2119    2121    2141    2149    2151
        2166    2174    2176    2189    2197    2199    2212    2220    2222    2236    2243    2245    2270    2277    2279
        2297    2305    2307    2338    2345    2347    2367    2376    2378    2407    2415    2417    2434    2441    2443
        2463    2470    2472    2490    2497    2499    2517    2523    2525    2535    2539    2541    2551    2555    2557
        2573    2581    2583    2616    2621    2623    2641    2647    2649    2674    2679    2681    2700    2707    2709
        2720    2726    2728    2739    2746    2748    2759    2770    2772    2789    2796    2798    2810    2817    2819
        2833    2842    2844    2856    2863    2865    2880    2888    2890    2898    2905    2907    2915    2922    2924
        2933    2935    2951    2953    2969    2971    2991    2993    3025    3027    3059    3061    3082    3084    3113
        3115    3136    3138    3158    3160    3180    3186    3188    3204    3210    3212    3233    3238    3240    3266
        3271    3273    3299    3306    3308    3326    3334    3336    3361    3370    3372    3398    3406    3408    3434
        3441    3443    3468    3480    3482    3500    3509    3511    3527    3537    3539    3549    3559    3561    3571
        3579    3581    3602    3611    3613    3646    3653    3655    3694    3701    3703    3730    3738    3740    3754
        3764    3766    3782    3789    3791    3802    3809    3811    3825    3832    3834    3844    3851    3853    3863
        3870    3872    3885    3892    3894    3903    3910    3912    3925    3934    3936    3952    3961    3963    3975
        3985    3987    4000    4031    4033    4093    4109    4111    4211    4218    4220    4232    4246    4248    4267
        4269    4289    4291    4310    4312    4334    4345    4347    4378    4380    4419    4428    4430    4442    4444
        4464    4466    4487    4497    4499    4541    4543    4573    4583    4585    4618    4620    4659    4661    4674
        4684    4686    4725    4727    4767    4777    4779    4818    4820    4858    4860    4900    4902    4947    4949
        5002    5004    5027    5029    5063    5071    5073    5101    5109    5111    5138    5145    5147    5167    5174
        5176    5209    5218    5220    5239    5241    5254    5256    5270    5272    5285    5287    5300    5302    5315
        5317    5330    5338    5340    5356    5358    5377    5379    5398    5400    5419    5421    5440    5442    5461
        5463    5482    5490    5492    5506    5511    5513    5526    5533    5535    5557    5562    5564    5580    5582
```

```
                5601    5608    5610    5644    5650    5652    5663    5669    5671    5682    5696    5698    5735    5746    5748
                5764    5766    5782    5784    5809    5811    5838    5845    5847    5855    5857    5865    5867    5876    5878
                5886    5888    5895    5899    5900    5902    5913    5915    5917    5927    5929    5941    5943    5991    5995
                6015#   6036    6038    6097    6099    6145    6147    6182    6184    6195    6197    6206    6208    6232    6234
                6242    6244    6253    6255    6264    6266    6274    6276    6284    6286    6297    6299    6308    6310    6330
                6332    6342    6344    6356    6358    6371    6373    6387    6389    6408    6410    6425    6427    6445    6447
                6471    6473    6537    6539    6562    6564    6583    6585    6607    6609    6623    6625    6646    6648    6679
                6681    6698    6700    6716    6718    6736    6738    6769    6771    6782    6784    9315    9317    9334    9336
                9353    9355    9381    9383    9397    9408    9411    9413    9423    9425    9435    9437    9447    9449    9459
                9461    9471    9473    9517    9519    9534    9536    9563    9565    9597    9599    9635    9637    9672    9674
                9708    9710    9743    9745    9826    9828    9961    9963   10065   10067   10139   10141   10189   10191   10240
               10242   10274   10284   10286   10288   10351   10353   10414   10429   10433   10435   10529   10531   10624   10626
               10661   10663   10745   10747   10776   10778   10797   10799   10834   10836   10893   10898   10901   10903   11038
               11040   11180   11182   11300   11302   11331   11333   11361   11368   11380   11386   11396   11404   11425   11433
               11492   11507   11509   11553   11555   11589   11591   11614   11616   11702   11704   11759   11761   11787   11789
               11900   11902   12004   12006   12109   12111   12506   12508   12704   12706   12805   12807   12870   12872   12932
               12934   13005   13007   13066   13068   13132   13134   13199   13201   13251   13253   13310   13312   13455   13457
               13558   13560   13668   13670   13735   13737   13801   13803   13901   13903   14077   14079   14249   14251   14441
               14443   14516   14518   14603   14605   14776   14778   15002   15004   15207   15209   15451   15453   15549   15551
               15728   15730   15883   15885   16061   16063   16182   16184   16315   16317   16460   16462   16598   16600   16749
               16751   16974   16976   17240   17242   17400   17402   17562   17564   17729   17731   17776   17778   17836   17838
               17920   17922   17982   17984   18042   18044   18095   18097   18145   18147   18191   18193   18242   18244   18422
               18424   18597   18599   18624   18626   18671   18673   18696   18698   18723   18725   18779   18781   18830   18832
               18877   18879   18928   18930   18979   18981   19031   19033   19077   19079   19128   19130   19171   19173   19220
               19222   19268   19270   19315   19317   19363   19365   19413   19415   19464   19466   19513   19515   19560   19562
               19606   19608   19658   19660   19711   19713   19979   19981   20015   20017   20052   20054   20083   20085   20116
               20118   20148   20150   20180   20182   20217   20219   20246   20248   20285   20287   20529   20531   20702   20704
               21005   21007   21044   21046   21084   21086   21122   21124   21162   21164   21202   21204   21243   21245   21284
               21286   21312   21314   21341   21343   21601   21603   21625   21627   21756   21758   21797   21799   21827   21829
               21844   21846   21918   21970   21972   21984   21986   21997   21999   22024   22026   22040   22042   22053   22055
               22070   22072   22092   22094   22120   22122   22149   22151   22173   22175   22198   22200   22226   22228   22252
               22254   22275   22277   22291   22293   22319   22321   22348   22350   22379   22381   22403   22405   22426   22428
               22450   22452   22492   22494   22504   22506   22535   22537   22564   22566   22608   22610   22642   22644   22668
               22670   22691   22693   22762   22764   22776   22778   22789   22791   22816   22818   22837   22839   22850   22852
               22867   22869   22895   22897   22927   22929   22960   22962   22984   22986   23009   23011   23037   23039   23068
               23070   23095   23097   23109   23111   23134   23136   23160   23162   23189   23191   23211   23213   23238   23240
               23260   23262   23288   23290   23305   23307   23363   23365   23403   23405   23576   23579   23603   23606

SWRSU             1#
TIMMSG         9286#
TIMTST         9286#   9427    9439    9451    9463
TRAPTS          756#    758     787     833     862     899     934     963
TYPBIN            1#
TYPDEC            1#
TYPNAM            1#
TYPNUM            1#
TYPOCS            1#
TYPOCT            1#
TYPTXT            1#
USER           9286#   9287
VTRP           6231#   6232    6242    6264    6274    6284    6297
WMSG           9286#
WTST           9286#  10143   10194
$ASHC          6934#   7608    7628    7648    7670    7690    7710    7732    7752
$ASHC$         6934#   7780    7803    7826    7849    7872    7895    7918    7941    7964    7987
$ASH$          6934#   7206    7223    7240    7257    7274    7291    7308    7325    7342    7359
$DIV           8017#   8632    8653    8674    8697    8718    8739    8762    8783    8804    8825    8848    8869    8890    8913
```

```
        8934    8955    8973    8993    9014    9035    9056    9077    9098    9119    9140    9161    9182
$MUL    8017#   8024    8045    8066    8087    8110    8131    8152    8175    8196    8217    8238    8261    8282    8303
        8324    8347    8368    8389    8416    8437    8458    8479    8500    8521    8542    8563    8584    8605
$SKIP    507#   5497    6614    6630    9752   10669   22543   22615   22649   22796   22823   22886   23044   23218   23267
       23370
$$ERCD   507#    740     768     782     797     811     843     857     872     886     909     923     944     958     973
         987    1021    1031    1041    1050    1075    1085    1088    1103    1114    1129    1159    1168    1177    1186
        1201    1217    1231    1247    1262    1278    1293    1309    1325    1341    1356    1372    1396    1405    1414
        1423    1461    1466    1469    1488    1500    1514    1520    1537    1544    1562    1571    1593    1603    1626
        1636    1659    1669    1688    1700    1719    1723    1732    1735    1749    1753    1761    1764    1778    1786
        1789    1815    1823    1849    1861    1887    1898    1916    1919    1924    1927    1932    1951    1961    1992
        2000    2019    2025    2046    2052    2067    2070    2073    2091    2094    2098    2115    2118    2133    2139
        2156    2163    2187    2210    2234    2257    2268    2291    2295    2319    2322    2332    2336    2361    2365
        2393    2402    2406    2429    2432    2457    2461    2485    2488    2512    2515    2533    2549    2568    2571
        2588    2595    2600    2609    2614    2636    2640    2656    2659    2663    2669    2673    2693    2699    2718
        2737    2757    2783    2787    2808    2827    2831    2852    2855    2875    2879    2897    2914    2931    2946
        2949    2964    2967    2981    2986    2989    3005    3008    3015    3019    3022    3042    3045    3053    3057
        3074    3077    3080    3097    3100    3105    3108    3111    3128    3131    3134    3150    3153    3156    3172
        3175    3178    3199    3202    3223    3228    3231    3249    3252    3258    3261    3264    3283    3286    3289
        3293    3297    3318    3321    3324    3344    3347    3353    3356    3359    3382    3385    3388    3393    3396
        3418    3421    3424    3429    3432    3453    3456    3459    3463    3466    3492    3521    3548    3570    3591
        3600    3624    3633    3644    3668    3679    3692    3712    3720    3728    3752    3779    3800    3821    3839
        3842    3860    3879    3882    3900    3919    3922    3943    3947    3971    3995    4040    4043    4051    4057
        4060    4067    4074    4082    4090    4125    4138    4151    4163    4175    4185    4195    4208    4228    4231
        4257    4266    4279    4288    4301    4309    4323    4332    4357    4367    4376    4390    4398    4406    4416
        4440    4454    4463    4476    4485    4508    4516    4524    4530    4539    4553    4562    4571    4596    4606
        4616    4630    4639    4649    4657    4671    4696    4705    4714    4723    4738    4747    4756    4765    4790
        4799    4807    [illegible]    4831    4840    4849    4857    4871    4880    4888    4899    4913    4923    4932    4944
        4957    4964    4970    4973    4986    4989    4996    4999    5014    5017    5024    5037    5044    5049    5058
        5061    5086    5100    5125    5137    5156    5166    5185    5194    5201    5207    5227    5237    5249    5252
        5265    5268    5280    5283    5295    5298    5310    5313    5325    5328    5346    5354    5369    5372    5375
        5390    5393    5396    5411    5414    5417    5432    5435    5438    5453    5456    5459    5474    5477    5480
        5503    5522    5542    5546    5552    5573    5577    5593    5597    5641    5660    5681    5711    5728    5756
        5762    5774    5780    5794    5798    5803    5807    5821    5826    5831    5835    5853    5863    5874    5884
        5894    5909    5925    5939    5954    5998    6000    6002    6004    6006    6008    6010    6012    6014    6044
        6050    6056    6063    6070    6077    6083    6090    6096    6108    6117    6126    6135    6144    6152    6156
        6160    6164    6167    6171    6175    6179    6192    6204    6219    6224    6229    6296    6327    6340    6352
        6355    6368    6384    6401    6406    6419    6423    6440    6442    6458    6486    6491    6494    6512    6519
        6523    6557    6577    6579    6599    6621    6640    6669    6672    6676    6690    6693    6709    6723    6726
        6746    6748    6751    6754    6757    6836    6839    6843    6972    6977    7001    7006    7029    7034    7057
        7062    7086    7091    7116    7121    7200    7215    7218    7232    7235    7249    7252    7266    7269    7283
        7286    7300    7303    7317    7320    7334    7337    7351    7354    7368    7371    7409    7413    7418    7422
        7446    7450    7455    7458    7483    7487    7492    7495    7604    7620    7623    7640    7643    7661    7664
        7682    7685    7702    7705    7723    7726    7744    7747    7764    7767    7770    7792    7795    7798    7815
        7818    7821    7838    7841    7844    7861    7864    7867    7884    7887    7890    7907    7910    7913    7930
        7933    7936    7953    7956    7959    7976    7979    7982    7999    8002    8005    8034    8037    8040    8055
        8058    8061    8076    8079    8082    8098    8101    8104    8120    8123    8126    8141    8144    8147    8163
        8166    8169    8185    8188    8191    8206    8209    8212    8227    8230    8233    8249    8252    8255    8271
        8274    8277    8292    8295    8298    8313    8316    8319    8335    8338    8341    8357    8360    8363    8378
        8381    8384    8400    8403    8406    8426    8429    8432    8447    8450    8453    8468    8471    8474    8489
        8492    8495    8510    8513    8516    8531    8534    8537    8552    8555    8558    8573    8576    8579    8594
        8597    8600    8615    8618    8621    8643    8646    8649    8664    8667    8670    8686    8689    8692    8708
        8711    8714    8729    8732    8735    8751    8754    8757    8773    8776    8779    8794    8797    8800    8815
        8818    8821    8837    8840    8843    8859    8862    8865    8880    8883    8886    8902    8905    8908    8924
        8927    8930    8945    8948    8951    8968    8985    9004    9007    9010    9025    9028    9031    9046    9049
        9052    9067    9070    9073    9088    9091    9094    9109    9112    9115    9130    9133    9136    9151    9154
```

```
                9157    9172    9175    9178    9193    9196    9199    9212    9215    9326    9345    9365    9376    9392    9481
                9489    9500    9509    9527    9541    9548    9557    9573    9583    9607    9619    9649    9661    9686    9697
                9761    9773    9784    9797    9859    9883    9907    9932    9953    9983   10007   10031   10055   10101   10133
               10161   10171   10180   10211   10221   10230   10253   10265   10309   10316   10324   10331   10367   10374   10382
               10389   10460   10470   10477   10485   10554   10564   10571   10579   10644   10678   10686   10709   10726   10735
               10763   10791   10807   10817   10824   10881   10946   10958   10969   10979   10990   11004   11016   11031   11056
               11073   11089   11103   11105   11120   11137   11153   11172   11210   11222   11233   11243   11254   11267   11279
               11293   11314   11324   11344   11351   11442   11456   11469   11483   11577   11605   11627   11637   11647   11656
               11666   11675   11684   11693   11721   11735   11740   11751   11778   11813   11816   11822   11828   11846   11849
               11855   11862   11931   11958   11972   12034   12061   12075   12462   12649   12733   12736   12759   12761   12766
               12782   12827   12833   12838   12890   12896   12901   12964   12973   13028   13035   13039   13091   13098   13159
               13165   13222   13226   13275   13280   13339   13357   13372   13387   13409   13414   13420   13473   13477   13494
               13498   13513   13517   13534   13538   13576   13581   13596   13601   13616   13621   13636   13641   13690   13694
               13756   13760   13819   13838   13860   13919   13923   13938   13942   13958   13962   13978   13982   13997   14001
               14016   14020   14095   14100   14115   14119   14136   14140   14156   14160   14175   14179   14194   14198   14267
               14272   14287   14292   14307   14312   14327   14331   14346   14350   14365   14370   14385   14390   14459   14464
               14479   14484   14534   14538   14554   14558   14623   14627   14647   14652   14670   14675   14690   14695   14710
               14715   14796   14801   14813   14817   14826   14831   14837   14854   14859   14873   14882   14887   14893   14910
               14915   14927   14931   14940   14945   14951   15015   15024   15029   15042   15053   15059   15072   15086   15104
               15128   15134   15149   15155   15424   15431   15474   15478   15495   15499   15513   15519   15527   15531   15707
               15710   15713   15864   15869   16040   16043   16046   16163   16168   16294   16299   16439   16444   16556   16560
               16574   16579   16582   16707   16711   16725   16729   16732   16939   16942   16946   16949   16952   17209   17217
               17221   17254   17277   17299   17361   17364   17368   17371   17374   17419   17448   17526   17534   17538   17570
               17577   17582   17586   17592   17596   17603   17607   17612   17617   17621   17626   17632   17636   17641   17648
               17655   17664   17672   17680   17689   17697   17745   17751   17761   17764   17801   17825   17862   17884   17902
               17912   17959   18034   18086   18137   18183   18234   18412   18588   18615   18652   18688   18714   18755   18822
               18870   18921   18972   19024   19070   19121   19164   19213   19261   19308   19356   19405   19456   19506   19553
               19599   19650   19703   19964   20005   20043   20076   20109   20141   20173   20207   20236   20263   20267   20515
               20692   20990   21034   21073   21112   21152   21193   21234   21276   21298   21327   21587   21735   21738   21742
               21781   21810   21813   21866   21882   21979   21993   22014   22020   22036   22049   22062   22076   22080   22084
               22089   22102   22106   22110   22116   22130   22134   22138   22144   22161   22166   22187   22194   22213   22222
               22244   22264   22271   22287   22308   22312   22334   22343   22364   22374   22398   22422   22440   22443   22465
               22501   22514   22518   22522   22532   22547   22554   22560   22580   22589   22597   22628   22636   22664   22685
               22725   22771   22785   22806   22812   22833   22846   22859   22873   22877   22881   22892   22905   22909   22913
               22923   22937   22941   22945   22955   22972   22977   22998   23005   23024   23033   23060   23078   23088   23105
               23123   23127   23148   23155   23174   23184   23206   23234   23250   23253   23279   23283   23299   23302   23317
               23321   23393   23463   23480   23498   23504   23509   23515
$$ERRO          507#    1020    1030    1040    1049    1074    1087    1101    1113    1127    1158    1167    1176    1185    1199
                1215    1229    1245    1260    1276    1291    1307    1323    1339    1354    1370    1395    1404    1413    1422
                1468    1498    1518    1542    1569    1601    1634    1667    1698    1734    1763    1788    1821    1859    1896
                1931    1959    1998    2023    2050    2072    2097    2117    2138    2161    2185    2208    2232    2266    2294
                2335    2364    2405    2431    2460    2487    2514    2532    2548    2570    2613    2639    2672    2697    2717
                2736    2756    2786    2807    2830    2854    2878    2896    2913    2930    2948    2966    2988    3021    3056
                3079    3110    3133    3155    3177    3201    3230    3263    3296    3323    3358    3395    3431    3465    3490
                3519    3547    3569    3598    3642    3690    3726    3750    3777    3798    3819    3841    3859    3881    3899
                3921    3945    3969    3993    4089    4206    4230    4264    4286    4307    4330    4374    4414    4438    4461
                4483    4537    4569    4614    4655    4669    4721    4763    4815    4855    4897    4942    4998    5022    5060
                5098    5135    5164    5205    5235    5251    5267    5282    5297    5312    5327    5353    5374    5395    5416
                5437    5458    5479    5502    5596    5679    5761    5779    5806    5834    5852    5862    5873    5883    5893
                5908    5924    5938    6095    6143    6178    6203    6295    6354    6367    6383    6422    6620    6692    6708
                6725    9375    9391    9556    9952   10308   10459   10553   10790   11102   17750   22035   22088   22286   22832
               22891   23104
$$ESCA          1#
$$NEWT          1#     507#     707     758     787     833     862     899     934     963    1013    1023    1033    1043    1066
                1077    1090    1105    1116    1151    1161    1170    1179    1188    1203    1218    1233    1249    1264    1280
                1295    1312    1327    1343    1358    1388    1398    1407    1416    1455    1481    1508    1530    1553    1583
```

```
      1615   1648   1676   1707   1736   1765   1805   1837   1876   1899   1942   1978   2010   2036   2054
      2074   2099   2119   2149   2174   2197   2220   2243   2277   2305   2345   2376   2415   2441   2470
      2497   2523   2539   2555   2581   2621   2647   2679   2707   2726   2746   2770   2796   2817   2842
      2863   2888   2905   2922   2933   2951   2969   2991   3025   3059   3082   3113   3136   3158   3186
      3210   3238   3271   3306   3334   3370   3406   3441   3480   3509   3537   3559   3579   3611   3653
      3701   3738   3764   3789   3809   3832   3851   3870   3892   3910   3934   3961   3985   4031   4109
      4218   4246   4267   4289   4310   4345   4378   4428   4442   4464   4497   4541   4583   4618   4659
      4684   4725   4777   4818   4858   4900   4947   5002   5027   5071   5109   5145   5174   5218   5239
      5254   5270   5285   5300   5315   5338   5356   5377   5398   5419   5440   5461   5490   5511   5533
      5562   5580   5608   5650   5669   5696   5746   5764   5782   5809   5845   5855   5865   5876   5886
      5900   5915   5927   5941   6036   6097   6145   6182   6195   6206   6232   6242   6253   6264   6274
      6284   6297   6308   6330   6342   6356   6371   6387   6408   6425   6445   6471   6537   6562   6583
      6607   6623   6646   6679   6698   6716   6736   6769   6782   9315   9334   9353   9381   9411   9423
      9435   9447   9459   9471   9517   9534   9563   9597   9635   9672   9708   9743   9826   9961  10065
     10139  10189  10240  10286  10351  10433  10529  10624  10661  10745  10776  10797  10834  10901  11038
     11180  11300  11331  11553  11589  11614  11702  11759  11787  11900  12004  12109  12506  12704  12805
     12870  12932  13005  13066  13132  13199  13251  13310  13455  13558  13668  13735  13801  13901  14077
     14249  14441  14516  14603  14776  15002  15207  15451  15549  15728  15883  16061  16182  16315  16460
     16598  16749  16974  17240  17400  17562  17729  17776  17836  17920  17982  18042  18095  18145  18191
     18242  18422  18597  18624  18671  18696  18723  18779  18830  18877  18928  18979  19031  19077  19128
     19171  19220  19268  19315  19363  19413  19464  19513  19560  19606  19658  19711  19979  20015  20052
     20083  20116  20148  20180  20217  20246  20285  20529  20702  21005  21044  21084  21122  21162  21202
     21243  21284  21312  21341  21601  21625  21756  21797  21827  21844  21970  21984  21997  22024  22040
     22053  22070  22092  22120  22149  22173  22198  22226  22252  22275  22291  22319  22348  22379  22403
     22426  22450  22492  22504  22535  22564  22608  22642  22668  22691  22762  22776  22789  22816  22837
     22850  22867  22895  22927  22960  22984  23009  23037  23068  23095  23109  23134  23160  23189  23211
     23238  23260  23288  23305  23363  23403

$$SKIP      1#
.EQUAT      1#
.HEADE      1#
.KT11       1#   9217#   9218
.MSG    21826#
.SETUP      1#    550#   6929
.SWRHI      1#
.$ACT1      1#    550#
.$APTB      1#    550#    561
.$APTH      1#    550#    588
.$APTY      1#
.$ASTA      1#
.$CATC      1#
.$CMTA      1#
.$DB2D      1#
.$DB2O      1#
.$DIV       1#
.$EOP       1#
.$ERRO      1#
.$ERRT      1#
.$MULT      1#
.$POWE      1#
.$RAND      1#
.$RDDE      1#
.$RDOC      1#
.$READ      1#
.$R2AZ      1#
.$SAVE      1#
.$SB2D      1#
```

```
.$SB20      1#
.$SCOP      1#
.$SIZE      1#
.$SUPR      1#
.$TRAP      1#
.$TYPB      1#
.$TYPD      1#
.$TYPE      1#
.$TYPO      1#
.$40CA      1#
.1170       1#


. ABS.  131741     000


 ERRORS DETECTED:  0

 CJKDEB.BIN,CJKDEB.LST/CRF/NL:TOC/SOL=SYSMAC.SML,CJKDEB.P11
 RUN-TIME: 63 75 11 SECONDS
 RUN-TIME RATIO: 432/150=2.8
 CORE USED:  51K  (102 PAGES)
```