



RQDX1 EXERCISER CZRQACO COPYRIGHT (c) 1983 AH-T399C-MC FICHE 3 OF 3 RQDX1 RX50 RD51 RD52 less wes

APR 1984

UNIBUS

DECTAPE

MASSBUS

SEQ 0001

Page

1

VAX-11 Bliss-16 V3-555

DISK \$USER2: [DIETZ.RDRX]ZRQACO.BL1:82 (1)

DECUS

0049

C 0050

DIGITAL

DEC

VAX-11 Bliss-16 V3-555 Page DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (2)

2

ZRQAM1 VO1.2		RD/RX	EXERCISER	5-Dec-1983 10:27:14 5-Dec-1983 10:27:04
:	C 0051			
:	C 0053			
:	C 0054 C 0055			
:	C 0056 C 0057			
:	C 0058			TABLE OF CONTENTS
:	C 0059			
:	C 0061		1.0	GENERAL INFORMATION
:	C 0063		1.1	PROGRAM ABSTRACT
:	C 0064 C 0065		1.2.1	SYSTEM REQUIREMENTS HARDWARE REQUIREMENTS
:	C 0066 C 0067		1.2.2	SOFTWARE REQUIREMENTS RELATED DOCUMENTS AND STANDARDS
	C 0068		1.4	DIAGNOSTIC HIERARCHY PREREQUISITES
:	C 0070		1.5	ASSUMPTIONS MEMORY MAP
:	C 0071		2.0	OPERATING INSTRUCTIONS
:	C 0073		2.1	HARDWARE QUESTIONS SOFTWARE QUESTIONS
	C 0075			
	C 0077		3.0	ERROR TYPES ERROR INFORMATION
	C 0078		3.2	INITIALIZATION ERRORS
:	C 0079		3.3	EXERCISER ERRORS
:	C 0080		3.4	ERROR LOG MESSAGES
:	C 0081		3.5	MSCP ERRORS
	C 0085		3.6	SAMPLE MSCP ERROR STATEMENT
:	C 0083		3.7	DUP ERRORS
:	C 0084		3.8	SAMPLE DUP ERROR STATEMENT
:	C 0085		4.0	PERFORMANCE AND PROGRESS REPORTS
:	C 0086			
:	C 0087		5.0	TEST SUMMARY
:	C 0088		5.1	INITIALIZATION SUBTEST
:	C 0089		5.2	EXERCISER
:	C 0090		5.2	DROP UNIT SUMMARY
:	C 0091			
	C 0092		6.0	ERROR LIST
	C 0093	*	0.0	
;	C 0094	,	7.0	DATA PATTERNS

SEQ 0003

Page

3

ZRQAM1 RD/RX EXERCISER 5-Dec-1983 10:27:14 VAX-11 Bliss-16 V3-555 V01.2 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (3) 5-Dec-1983 10:27:04 C 0095 C 0096 0097 1.0 GENERAL INFORMATION C 0098 C 0099 C 0100 C 0101 PROGRAM ABSTRACT 1.1 C 0102 C 0103 C 0104 This program will functionally verify and exercise RQDX1 Controller/Disk Drive subsystems. It is designed to verify C 0105 C 0106 that the subsystem is functioning correctly and operating C 0107 within design specifications. C 0108 C 0109 C 0110 C 0111 SYSTEM REQUIREMENTS 1.2 C 0112 C 0113 C 0114 1.2.1 HARDWARE REQUIREMENTS C 0115 C 0116 C 0117 LSI - 11/23 processor with 28K or more of memory, console C 0118 C 0119 C 0120 device (eg. VT100) and RQDX1 CONTROLLER board and attached RD-51 WINCHESTER drive(s) and RX-50 FLOPPY drive(s) C 0122 1.2.2 SOFTWARE REQUIREMENTS C 0123 C 0124 This diagnostic is designed to run with the Diagnostic C 0125 Supervisor as described in paragraph 2.0. C 0126 C 0127 C 0129 RELATED DOCUMENTS AND STANDARDS C 0129 C 0130 C 0131 C 0132 XXDP+ SUPERVISOR/USERS MANUAL UQSSP UNIBUS/Q-BUS STORAGE SYSTEMS PORT MSCP MASS STORAGE SYSTEM PROTOCOL C 0133 C 0134 DUP DIAGNOSTIC/UTILITIES PROTOCOL C 0135 C 0136 DIAGNOSTIC HIERARCY PREREQUISITES C 0137 C 0138 C 0139 NONE C 0140 C 0141 C 0142 1.5 **ASSUMPTIONS** C 0143 C 0144 C 0145 C 0146 The hardware, other than the subsystem being tested is assumed to work properly. False errors may be reported if C 0147 the processor, memory, etc., do not function properly.

VAX-11 Bliss-16 V3-555 Page DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (4)

ZRQAM1 VO1.2		RD/RX	EXERCISER	5-Dec-1983 10:27:14 5-Dec-1983 10:27:04
	C 0148 C 0149 C 0150 C 0151 C 0152 C 0153 C 0154 C 0155 C 0156		1.6	MEMORY MAP  Memory layout on 28k machine - XXDP environment
	C 0157			ADDRESS
	C 0158 C 0159 C 0160 C 0161 C 0162 C 0163 C 0164 C 0165 C 0166 C 0167 C 0168 C 0169 C 0170 C 0171 C 0172 C 0173			XXDP+ MONITOR  XXDP+ TTY I/O AREA  DRS  121000
	C 0174 C 0175 C 0176			EXERCISER
:	C 0177 C 0178 C 0179 C 0180			STACKS 2000
	C 0181 C 0182 C 0183 C 0184 C 0185			VECTOR AREA
:	C 0185 C 0186 C 0187 C 0188 C 0189			In a machine with more memory, free space will ocuur between the exerciser and the DRS.

5-Dec-1983 10:27:14 5-Dec-1983 10:27:04

VAX-11 Bliss-16 V3-555 DISK\$USER2: [DIETZ.RDRX]ZRQACO.BL1:82 (5)

SEQ 0005 Page

5

#### OPERATING INSTRUCTIONS 2.0

RD/RX EXERCISER

This is a Rev C Supervisor Diagnostic: for operating instructions, please see chapter 5 of XXDP+ operator's manual. They are no longer included in the diagnostic because it is desired that a change in those instructions not require a re-assembly of all Supervisor Diagnostics.

#### HARDWARE QUESTIONS 2.1

The following series of questions comprise the parameters necessary to identify each disk subsystem.

# Hardware Configuration Questions

The program will ask the following questions response to a START command (non-script).

#### 1. CHANGE HW (L) Y ?

Answer NO to use the pre-built answers for all hardware questions. This program will be released pre-built to test three unit with default answers shown below. The pre-built answers may be changed at any time with the setup utility. Answer YES if you want all the hardware questions to be asked.

### 2. NUMBER OF UNITS (D) ?

No default. Answer with the number of disk drive units to be exercised or tested. This answer will determine how many times the following questions are asked. A range of 1 to 4 units may be specified. A unit number will be assigned sequentially from 0 by the Diagnostic supervisor for each unit.

#### 3. IP ADDRESS (0) 172150 ?

Enter the address of the IP register of one RQDX1 as addressed by the processor with memory management turned off. The program expects an even 16-bit address in the range of 160000 to 177774. 172150 is the default.

0293

5-Dec-1983 10:27:14 5-Dec-1983 10:27:04

VAX-11 Bliss-16 V3-555 Page DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (6)

SEQ 0006

6

4. VECTOR ADDRESS (0) 154 ?

Answer with the interrupt vector of same RQDX1 in the above question. A vector address in the range of 4 to 774 may be specified. 154 is the default.

5. BR LEVEL (D) 4 ?

RD/RX EXERCISER

Answer with the bus request interrupt level used by the above RQDX1. Levels 4 through 7 are acceptable. 4 is the default.

6. RQDX1 DRIVE NUMBER (D) 0 ?

Enter the logical unit number for one drive associated with the IP address above. Drive numbers are in the range of 0 through 3. The number entered here must match the unit plug on the front panel of the device. 0 is the default answer.

7. ALSO EXERCISE DIAGNOSTIC AREA (-NON-CUSTOMER AREA RDs ONLY) ?

A "Yes" answer to this question will turn on the DUP (Diagnostic/Utilities Protocol) Exerciser. The DUP Exerciser will read the DBNs (Diagnostic Blocks) in a sequential order from 0 to octal (217). DBNs can only be accessed throw DUP protocol making the blocks unreachable throw normal customer use. The DUP Exerciser is contained in the middle of the MSCP (Mass Storage Control Protocol) Exerciser which reads LBNs (Logical blocks). So physically a large amount of LBNs will be READ and/or MRITTEN then the DUP Exerciser will turn on and READ and/or WRITE a few DBNs. The DUP Exerciser will then reinitialize the controller so the MSCP Exerciser can continue where it left off. The processes of reinitializing takes a few seconds.

NOTE This question only pertains to Winchester type devices. If a yes answer is given for an RX-50 nothing will happen.

8. WRITE ON DIAGNOSTIC AREA?

A "yes" answer to this statement will allow the DUP Exerciser to WRITE/READ and compare the DBNs (Diagnostic Blocks). Where a "NO" answer will allow the program to READ only the DBNs. If this is an RX-50 nothing will be affected.

NOTE \*\* IF yes ANSWER, DATA ON DBNs WILL BE DESTROYED.

:

:

C 0328

C 0329 C 0330

C 0331

C 0332 C 0333

C 0334

C 0335

RD/RX EXERCISER

5-Dec-1983 10:27:14 5-Dec-1983 10:27:04 VAX-11 Bliss-16 V3-555 Page DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (7)

7

9. STARTING LBN (D) 0 ?

Enter the starting logical block number of the customer data area that you are going to test. LBNs range from 0 to 21599 (RD51), or 0 to 47999 (RD51), or 0 to 799 (RX50), with 0 as the default. If to large a number is given for that particular device the program will default to 0.

10. ENDING LBN (MAX - RX50: 799, RD51: 21599) (D) 21599 ?

Answer this question for the last customer LBN you wish to test. LBNs range from 0 to 21599 (RD51), or 0 to 47999 (RD52), or 0 to 799 (RX50), with the default being larger than all units. If the number given is larger than the amount of LBNs for that particular unit the program will default the end track to the highest track for that unit.

NOTE: The two previous questions are generally Software Parameter questions, but since two different disk devices exist on the RQDX1 subsystem, this becomes a unit by unit question. It is possible to specify an LBN which is too large since we are dealing with different devices. The program will check for block number bounds and if they are exceeded, will assign the maximum bound for that device.

11. EXERCISE ON CUSTOMER DATA AREA ON THIS DISK UNIT (L) ?

Answering YES will destroy any customer data that is on the disk; therefore, the following warning message will appear, followed by a confirmation prompt:

\*\* WARNING - CUSTOMER DATA AREA WILL BE OVERWRITTEN! ...
CONFIRM (L) ?

This question will default to NO if the operator has decided to bypass the hardware questions. Otherwise, there is no default.

C 0336 0337 C 0338

0339 0340 0341

0342 0343 0344

C 0345

C

0346

0347

0348 0349

0350 0351

0357 0358

0359

0360

0361

0362

0363 0364

0365 0366

0367 0368

0369

0370

0371 0372

0373

0374

0375

0376 0377

0378 0379

0385

0386

0387

0388

C

C

C

:

:

.

:

:

RD/RX EXERCISER

5-Dec-1983 10:27:14

5-Dec-1983 10:27:04

VAX-11 Bliss-16 V3-555

Page

SEQ 0008

DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (8)

#### 2.2 SOFTWARE QUESTIONS

Software Parameter Questions

The program will ask the following questions in response to the START, RESTART, and CONTINUE commands.

#### 1. CHANGE SW (L) Y ?

Answer NO to bypass the following questions in this section. This question should normally be answered NO when the Exerciser is first run. A NO answer will cause the Exerciser to select the default parameters shown with each question below. Then, depending on the errors detected, it may be desirable to change this answer to YES to alter the test parameters and further isolate the problem.

#### 2. HARD ERROR LIMIT (D) 32 ?

Enter the number of hard errors allowed before a unit is dropped from testing. A number in the range of 1 to 65535 will be accepted.

### 3. TRANSFER LIMIT IN MEGABYTES (O FOR QUICK PASS) (D) 0 ?

When the specified number of bytes have been transferred to/from a unit, the unit will be dropped from testing. When all units are dropped, an end-of-pass will be indicated. This is the method used to determine how long the Exerciser is to run.

The only other way the Exerciser will declare end-ofpass is if all units are dropped because the error limit on each is exceeded. However, the operator can always abort the program at any time by typing CONTROL-C.

#### 4. PERCENTAGE OF RD51 OPERATIONS OUT OF TOTAL OPERATONS (D) 99 ?

In order to maintain typical usage for the devices of this exercise, a certain percentage of operations must be directed to the RD51s (the rest go to the RX50s). It turns out that this percentage is very high (as indicated by the 99% figure given as the default). It may be desirable in some cases to direct more activity to the RX50s. This is easily done by directing a smaller percentage of the operations to the RD51s. The numbers associated with usage are adjusted internally by the program according to device type and percentage.

5-Dec-1983 10:27:04

0429

0430

RD/RX' EXERCISER

5-Dec-1983 10:27:14

VAX-11 Bliss-16 V3-555

SEQ 0009 VAX-11 Bliss-16 V3-555 Page DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (9)

9

5. NUMBER OF DBNs TRANSFERRED AT ONE "DUP" PASS (11) ?

This variable adjusts the amount of DBNs read in one pass of the DUP Exerciser. The DUP Exerciser has to reinit the controller every time it goes back into the MSCP Exerciser. This Hard reinitialization takes a few seconds. The ratio of LBN tranfers to DBN tranfers DOESN'T change only the amount of DBNs read on one pass. So the higher this number the less reinitializing the program does and the less time to run. The lower this number the more reinitializations the longer amount of time to tranfer the same amount LBNs and DBNs.

6. CLEAR STATISTICAL TABLES AFTER PRINTING (L) N ?

Answering YES causes the statistical fields to be cleared to zero after the report is printed (either at end of pass, or at operator request). Otherwise, cumulative totals are maintained.

7. RANDOM UNIT MODE (L) Y ?

Answer YES causes the units to be pick in a random fashion starting with either floppys at random or winchesters at random. A NO answer causes the units to be in a sequential order.

8. PERCENTAGE OF WINCHESTER OPERATIONS OUT OF TOTAL OPERATIONS (98)?

This question is only asked when a YES answer is given to the random unit mode. Any number from 0 to 100 may be given to define the percentage of winchester transfers to total transfers.

9. RANDOM BLOCK MODE (Y)?

A YES answer to this question will pick LBN blocks at random. A NO answer will pick LBN blocks in a sequential order starting at the beginning LBN and going up to the ending LBN and then back.

RD/RX EXERCISER

5-Dec-1983 10:27:14 5-Dec-1983 10:27:04 VAX-11 Bliss-16 V3-555 Page 10 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (10)

10. READ-COMPARES PERFORMED AT THE CONTROLLER (L) N ?

Answering YES causes all read commands to include the "compare" modifier. This essentially forces the controller to perform two read operations on the same disk address, and to compare the results.

The following message will appear after the operator has answered this question:

THE REMAINING QUESTIONS ONLY APPLY TO UNPROTECTED DISK UNITS.

11. WRITE-COMPARES PERFORMED AT THE CONTROLLER (L) N ?

Answering YES causes all write I/O requests to be changed to write-compare. After each write, the controller will read the data and compare it to data re-obtained from the host.

12. CHECK ALL WRITES AT HOST BY READING (L) N ?

This question will only be asked if the previous question was answered NO. Answering YES causes all writes to be checked by the host by reading the data immediately after the write operation. This option consumes extra CPU time, and doubles the amount of storage required for writes. Therefore, it is only recommended when device write-compare operations are suspect.

13. USER-DEFINED DATA PATTERN (L) N ?

An answer of YES allows the operator to define his/her own data pattern to be used in all write operations. A NO answer will allow the operator to select a pre-defined data pattern in the next question.

14. SELECT PRE-DEFINED DATA PATTERN (O FOR SEQUENTIAL SELECTION) (D) 0 ?

There are 21 predefined data patterns available, selected as 1 to 21 (see section 4.9). A zero answer will cause patterns 1 to 21 to be sequentially selected for each write. (Note that pattern 1 consists entirely of random numbers).

VAX-11 Bliss-16 V3-555 Page 11 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (11)

RQAM1 01.2			RD/RX	EXERCISE	5-Dec-1983 5-Dec-1983	10:27	7:14 7:04	
	000000	0479 0480 0481 0482 0483 0484 0485		15.	NUMBER OF WORDS IN DATA PATTERN (16 MAXIMUM) PATTERN VALUES (0) ?  These questions will only be asked if the op decided to define his/her own data pattern. bit patterns will be entered as octal (PDP-11	erator The a	r ha	95

VAX-11 Bliss-16 V3-555 Page 12 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (12)

ZRQAM1 VO1.2		RD/RX EXERCISER	5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	
	C 0487			
:	C 0488 C 0489	3.0	ERROR TYPES	
	C 0490	3.0	ERROR TIPES	
	C 0491			
:	C 0492 C 0493 C 0494		This program has four types of error classifications; system fatal, device fatal, hard and soft.	
	C 0495		SYSTEM FATAL ERRORS	
:	C 0496 C 0497			
	C 0498		System fatal errors are used to indicate that an error	
:	C 0499 C 0500		was detected by the Diagnostic Supervisor in relation to loading/controlling the diagnostic process.	
:	C 0501		*	
:	C 0502 C 0503 C 0504		The content of each error is such that it should be self explanatory. However, the messages utilize some terms that are specific to the disk subsystem, and may	
	C 0505 C 0506 C 0507		require some getting use to.	
	C 0508		DEVICE FATAL ERRORS	
	C 0509			
	C 0510			
	C 0511 C 0512		Device fatal errors are a result of:	
	C 0513		an error that is considered fatal to the device, but	
	C 0514 C 0515		testing will continue.	
:	C 0516			
:	C 0517 C 0518		HARD ERRORS	
	C 0519			
	C 0520 C 0521		Hard errors are a result of:	
:	C 0522		1. retries of a soft error or *	
:	C 0523 C 0524		2. a non-recoverable error	
:	C 0525		3. a soft error if retrys are not set.	
	C 0526 C 0527		* Note: Retries are executed in the controller	
:	C 0528		SOFT ERRORS	
	C 0529			
:	C 0530			
:	C 0531 C 0532		Soft errors are media related errors. All soft errors	1
	C 0533		will be retried by the controller.	
	C 0534 C 0535		Note: Soft errors are retrieved from the controller via the error log capabilities of MSCP.	

C 0536 C 0537 C 0538

C 0539 C 0540 C 0541

C 0542

C 0543

C 0544 C 0545

C 0546 C 0547 C 0548

C 0549

C 0550 C 0551

C 0552

C 0553 C 0554

C 0555

C 0556

C 0557

C 0558

C 0559 C 0560

C 0561 C 0562 C 0563 C 0564

C 0565 C 0566 C 0567

C 0568 C 0569

C 0570

C 0571 C 0572

C 0573 C 0574

C 0575 C 0576

C 0577 C 0578

C 0579 C 0580

C 0581 C 0582

C 0583 C 0584

C 0585 C 0586 RD/RX EXERCISER

5-Dec-1983 10:27:14 5-Dec-1983 10:27:04 VAX-11 Bliss-16 V3-555 Page 13 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (13)

3.1 ERROR INFORMATION

All general error messages will include the type of error (system-fatal, device-fatal, hard, soft) and a unit number. If the error applies to a controller, then only the first unit number of the controller will be given. (The user will know the other unit numbers when subsequent "drop unit" messages are printed).

Basic error messages provide more details about the error. The Exerciser will print all basic error messages, along with the disk address, if applicable. In some cases where a device-fatal error applies to a controller, the controller's IP address will be printed.

Extended error messages will be used to print the relevant fields of command and end message packets, status codes, SA register contents, and error log messages. All values will be in octal (PDP-11).

The error messages in this section do not include errors detected and printed by the Diagnostic Supervisor.

# 3.2 INITIALIZATION ERRORS

Two kinds of errors will be reported to the operator during the Initialization Test. The System-fatal error is - too many units specified. A system-fatal error will cause the Exerciser to abort.

Device-fatal errors only affect the unit(s) involved. Testing will continue on all other units. This class of errors includes, but is not limited to, the following:

- 1. Register Existence Test failure (no device present)
- 2. Vector Test failure
- 3. BR Level Test failure
- 4. Initialization sequence failure
- 5. Online failed
- 6. Access failed

:

RD/RX EXERCISER

C

5-Dec-1983 10:27:14 5-Dec-1983 10:27:04

VAX-11 Bliss-16 V3-555 Page DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (14)

SEQ 0014 Page 14

3.3 EXERCISER ERRORS

Most errors reported during this test will originate from MSCP end message packets. The status code field will be converted to text and printed as part of a basic error message. Any subcode value will follow if extended error messages are enabled.

The following list represents some of the error conditions reported via MSCP:

- Disk unit went offline (a sub-code may follow detailing the reason)
- 2. Compare error
- 3. Data error (a sub-code may follow)
- 4. Drive error (a sub-code may follow)
- 5. Host buffer access error
- 6. Media format error (a sub-code may follow)

### 3.4 ERROR LOG MESSAGES

The contents of the error-log messages received from the controller are printed as received, and should be deciphered using the MSCP specs.

#### 3.5 MSCP ERRORS

An MSCP error occurs when the host receives an Invalid Command End Message from the RQDX1. In such cases, the host will print out the erroneous command followed by the reason for the error. If extended printouts are enabled, then the entire contents of the end message will be displayed in octal without interpretation of the data.

ZRQAM1 VO1.2

> C 0636 C 0637 C 0638

C 0639 C 0640 C 0641 C 0642

C 0643

C 0644

C 0645

C 0646 C 0647 C 0648

C 0649 C 0650

C 0651

C 0652

C 0653 C 0654 C 0655

0660

0665 0666

C 0667 C 0668 C 0669 C 0670 C 0671 C 0672 C 0673 C 0674 C 0675 C 0676

> 0678 0679 0680

0681

0682 0683

0684

0685 0686 0687

0688

RD/RX EXERCISER

5-Dec-1983 10:27:14 5-Dec-1983 10:27:04

VAX-11 Bliss-16 V3-555 Page 15 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (15)

SEQ 0015

3.6 SAMPLE MSCP ERROR STATEMENT

The errors listed by the exerciser are usually very descriptive and are self explanatory. The following is an example error statement. This error statement is the extented error message.

(example)

(comments)

\* DISK: XXX

CRN: XXXXX

MESSAGE TYPE: - SEQUENTIAL

COMMAND: -MSCP-READ-COMPARE
STATUS CODE: UNIT OFFLINE
STATUS SUB-CODE: NO VOLUME MOUNTED OR DRIVE DISABLED BY SWITCH! SUB CODE
BYTE COUNT IN COMMAND XXXXX

NUMBER OF BYTES WANTED TO READ
ACTURL \* OF BYTES TRANSFERED XXXXX !NUMBER OF BYTES ACTUALLY READ
I/O BUFFER ADDRESS (32 BITS)

XXXXXX XXXXXX

LBN: XXX

END MESSAGE FLAGS:

! THERE ARE NO END FLAGS FOR THIS ERROR

The status code in an end messages is broken into two pieces. The first 5 bits represent the major status which is given by the "invalid command" message. The 11 remaining bits represent the sub-code, which tells in greater detail the error in the controller. The LBN is the logical block on the disk the controller was trying to read. The byte count refers to the number of bytes the controller was going to read off the LBN. The actual number of bytes transfered refers to the number of bytes read before the error. The end message flags give any flags that might have been set by the controller. It is pretty apparent that this error was caused by something physically switching the disk offline.

# 3.7 DUP ERRORS

A DUP error occurs when the host receives an Invalid Command End Message from the RQDX1. In such cases, the host will print out the erroneous command followed by the reason for the error.

There are two major places where errors in DUP will occur. The first being in the status code much the same as MSCP, and the second in the DUP I/O Buffer. Using the DUP sub-protocol (using Receive/Send commands to communicate with controller local programs (p. 25 of DUP. VO5)) the controller may send an error

ZRQAM1 VO1.2

RD/RX EXERCISER

5-Dec-1983 10:27:14 5-Dec-1983 10:27:04

VAX-11 Bliss-16 V3-555 SEQ 0016 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (15)

C 0689

message to the host by writting in the DUP I/O Buffer.

ZRQAM1 VO1.2	RD/RX EXERCISER	5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bl;ss-16 V3-555 Page 17 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (16)
## C 0690 ## C 0693 ## C 0693 ## C 0694 ## C 0695 ## C 0696 ## C 0697 ## C 0698 ## C 0699 ## C 0700 ## C 0701 ## C 0702 ## C 0703 ## C 0704 ## C 0705 ## C 0706 ## C 0707 ## C 0708 ## C 0709 ## C 0711 ## C 0712 ## C 0713 ## C 0714 ## C 0715 ## C 0716 ## C 0717 ## C 0718 ## C 0719 ## C 0720 ## C 0721 ## C 0722 ## C 0723 ## C 0724 ## C 0725 ## C 0726 ## C 0727 ## C 0727 ## C 0728	criptive and are self explanatory error statement. This error statement is the statement of the statement	serciser are usually very deal. The following is an example atement is the extented end at the controller packet number of the post of the pos	DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (16)  BS-Die FOR  EN TO DRIVE EAD  EXPECTED  BS-DIE FOR  BS-DIE FOR  EXPECTED
: C 0729 C 0730	by an ILLEGAL UNIT NUMBER. The di	sk went off line.	

SEQ 0018

Page 18

ZRQAM1 RD/RY EXERCISER 5-Dec-1983 10:27:14 VAX-11 Bliss-16 V3-555 V01.2 5-Dec-1983 10:27:04 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (17) C 0731 C 0732 0732 C 0733 PERFORMANCE AND PROGRESS REPORTS 0734 C 0735 C 0736 C 0737 C 0738 A summary report is printed at the end of each pass of the Exerciser or upon demand by the operator. The fields may be cleared to zero after the report is printed depending on 0739 . 0740 the operator's response to this option in the software ques-. 0741 tions. Any units added to the test cycle will also begin with : 0742 cleared statistics. : 0743 There are two basic listings one for LBNs and one for DBNs. The DBN listing will only contain RD51s for the simple 0744 reason that they contain DBNs and RX50s do not. The DBNs are READ and WRITTEN by blocks instead of by bytes. All units 0745 0746 C 0746 C 0747 C 0748 C 0750 C 0751 C 0752 C 0753 C 0754 C 0755 contain LBNs. The errors for each unit will be listed next to the LBNs. Errors are grouped into two basic catagories: hard and soft. Each is sub divided into four more catagories, depending on the most probable classification for that error. The sub catagories are: 1. disk related errors 0757 2. seek (or format) related errors 0758 . 0759 3. controller or drive related errors 0760 C 0761 C 0762 C 0763 C 0764 4. host (the CPU) related errors. All numeric values are in decimal radix. 0765 UNT # OF BYTS # OF BYTES -- HRD ERS ---- SFT ERS --0766 TYPE READS READ WRITES WRITTEN DAT SEK DRV HST DAT SEK DRV HST C 0767 C 0768 C 0769 **RD51** XXXXXX C 0770 **RX50** C 0771 C 0772 **RX50** ... C 0773 UNIT DISK # OF # BLKS OF # BLKS C 0774 C 0775 C 0776 C 0777 TYPE READS READ WRITES WRITTEN DBNRD51 X X XXXXX XXXXX XXXXX XXXXX

ZRQAM1 V01.2

:

.

.

:

.

.

.

:

.

:

:

.

C 0778 0779 0780

> 0781 0782 0783

0784

0785

0786

0787 0788

0789

0790

0791

0792

0793

0794

0795 0796

0797

0798

0799

0800 0801 0802

0803

0804

0809 0810

0811 0812

0813

0814

0815

0816

0817 0818

0819

0820

0821

0822 0823

0824

C

C

C

RD/RX EXERCISER

5-Dec-1983 10:27:14 5-Dec-1983 10:27:04

VAX-11 Bliss-16 V3-555

SEQ 0019 Page 19 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (18)

#### 5.0 TEST SUMMARY

The RQDX1 functional tester and exerciser consists of two parts, the initialization subtest and the performance exerciser. The operator is not able to select which of these two parts he/she wishes to run: they both must be executed.

## 5.1 INITIALIZATION SUBTEST

The purpose of this subtest is to verify the hardware configuration as specified by the operator, and to bring each unit online. The Initialization Subtest will always precede the execution of any other test.

First, the presence of each device register will be verified, along with a check on the BR level specified by the operator. Then, an initialization will be issued to each controller configured for testing. When the initialization sequence has been completed, an attempt will be made to bring each unit online. If this succeeds, one or two MSCP reads will be issued to the inner-most LBN of each selected disk to to ensure that each disk drive can seek and be read.

Any device-fatal or hard errors encountered during this test will cause the appropriate unit(s) to be dropped. If basic error messages are enabled, then the program will print out the specific reason for dropping the unit(s). Henceforth, the failed unit(s) will not be tested unless the operator intervenes (adds unit(s) or restarts Exerciser).

Upon successful completion of the Initialization Subtest. the program will begin executing the Exerciser.

### 5.2 EXERCISER

------

The purpose of this subtest is to exercise the disk drives in a manner similar to the typical usage under standard operating systems. Execution of this test should give an indication of the operating performance of the disk drive subunits. This test will utilitize random disk addresses, random word counts, and data patterns, all subject to the limits and specifications made by the operator. All protected disks will be subject to read-only operations, while unprotected disks may be read or written, depending on the answers given to the software parameter questions. End-of-pass will be declared when the specified number of bytes have been transferred for all the disks taken as a whole.

ZRQAM1 V01.2

.

.

:

C 0830 0831 0832

0833

0834

0839 0840

0841

0842

0843

0844 0845

0846

0847

0848

0849

0854

0855 0856 0857

0858

0859 0860

0861 0862

0863

0864 0865

0866

0871 0872 0873

0874 0875 C 0876

Č

RD/RX EXERCISER

5-Dec-1983 10:27:14 5-Dec-1983 10:27:04 DISK\*USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (19)

SEQ 0020

If a read/write error occurs during this test, then the RQDX1 CONTROLLER will initiate an appropriate number of retries. If all retries fail, then a hard error will be reported to the host, an error message will be diplayed on the console terminal and the error will be tallied for the summary report. The unit will be dropped if the hard error count has exceeded the specified limit.

The Exerciser is actually two exercisers combined together. The main MSCP exerciser writes and reads LBNs while the less used DUP exerciser writes and reads DBNs. The DUP exerciser is used once per 25 LBN transfers or alot less than the MSCP exerciser. The two Exercisers use a some what different protocol to tranfer I/O. It is possible to go from MSCP protocol to DUP protocol without reinitializing the controller but impossible to go from DUP to MSCP protocol. Therfore after the DUP Exercise pass the controller is reinitialize and control given back to the MSCP Exerciser. The reinitialization process takes a few seconds. For this reason a variable is placed in the DUP Exerciser to allow it to transfer more than 1 DBN per pass. The variable, "X", is multiplied by 25 to give the amount of MSCP transfers before the DUP Exerciser can tranfer "X" amount of DBNs. The higher the variable the less reinits the controller must do.

# DROP UNIT SUMMARY

During the Initialization Subtest, individual units will be dropped from the test sequence if they are unable to be brought online or the operator specified device does not match the hardware.

During the Exercise, the program will drop a unit for one of three reasons. The normal path is for each unit to complete the transfer of N megabytes, where N is specified by the operator during SW questioning and be soft-dropped. Otherwise, a unit will be hard-dropped if the number of hard errors encountered exceeds the operator-specified limit, or if a fatal error is detected. Units hard-dropped may later be added to the test cycle. However, statistics for the hard-added unit will be cleared to zero; if a transfer limit was specified, in which case the unit was soft-dropped, the statistics may or may not be cleared depending on the operators answer to Software question 12.

			12	
ZRQAM1 VO1.2	RD/RX EXERCISER		-Dec-1983 10:27:14 -Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555
	C 0877 C 0878 C 0879 6.0 E	RROR CODES GENERATED BY ZRQA EXER	CISER	
	C 0881 C 0882 SYST C 0883	EM FATAL ERRORS		
	C 0886	More than 4 units specified		
	C 0887 C 0888 DEVI C 0889	CE FATAL ERRORS		
	C 0891 10	Controller couldn't be addressed at the address given.	Wrong IP address se	lected
	C 0894 11 C 0895 C 0896	Controller didn't interrupt at the interrupt vector given.	Wrong vector addres ected.	
	C 0898 C 0899	Controller didn't interrupt at the BR lelvel given.	Wrong BR level sele	
	C 0900 C 0901 C 0902 C 0903 C 0904 C 0905 C 0906	Init sequence failed.	Either one of the initialization stenot receive the coresponse from the troller, or one steps timed-out.	ps did orrect Con-
:		Fatal Controller error.	The error bit (bit the SA register was	
	C 0910 C 0911 C 0912 C 0913	Failed to bring unit on-line.	On-line response herror code. (see #s 22 and 23.)	
		Write protect conflict.		rdware   write   wested
	C 0919 C 0920 C 0921	Access to inner track failed.	Innermost track's may be corrupted.	header
:	C 0922 C 0923	Unit went off-line.		
:	C 0924 20	Failed to send 'Set Controller Characteristics" command.	Either the unit is line or the Diagnos corrupted because problems with its RA	of any

				UZ
ZRQAM1 VO1.2		RD/RX EXERCI		SEQ 0022 5-Dec-1983 10:27:14 VAX-11 Bliss-16 V3-555 Page 22 5-Dec-1983 10:27:04 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (21)
	C 0928 C 0929 C 0930 C 0931 C 0932		21 Controller returned wrong 'end code' for the 'Set Controller Characteristics' command.	Problem with the Control- ler microcode or the port/ DMA intterface.
	C 0933 C 0934 C 0935 C 0936 C 0937 C 0938		22 Failed to send 'On-line' command	Either the unit is off- line or the diagnostic is corrupted because of any problems with its RAM.
	C 0939 C 0940 C 0941 C 0942		23 Controller returned wrong 'end code' for the 'On-line' command.	Problem with the Control- ler's microcode or the port/DMA interface.
	C 0944 C 0945		24 Device went to available state	Fault switch or door mechanism
	C 0946 C 0947 C 0948		25 Unknown device type	Drive not identifying itself properly
	C 0949 C 0950 C 0951 C 0952		HARD ERRORS	
	C 0953	MSCP ERRORS		
	C 0954 C 0955 C 0956 C 0957 C 0958 C 0959 C 0960 C 0961 C 0962 C 0963		31 Controller received an invalid command.	The diagnostic is corrupted because of any problems with its RAM, or there is a problem with the Controller microde (RAM or ROM) or there is problem with the port/DMA interface.
	C 0964 C 0965 C 0966		32 Command aborted by the Control- ler.	Command timed-out in the Controller.
	C 0967 C 0968		35 Media format error.	
	C 0969 C 0970		36 Device write protected.	
	C 0971 C 0972 C 0973		37 Controller read or write com- pare error.	
	C 0974 C 0975 C 0976		38 Data error.	CRC error in the data field of a disk block.
	C 0977 C 0978		39 Host buffer access error	
•	C 0979 C 0980		40 Controller error.	Difficult to catagorize without looking at the

ZRQAM1, VO1.2

RD/RX EXERCISER

C 0981 C 0982 C 0983

5-Dec-1983 10:27:14 5-Dec-1983 10:27:04

VAX-11 Bliss-16 V3-555 Page 23 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (21)

error sub-code or any associated error-log mes-sage.

			LC
ZRQAM1 VO1.2		RD/RX EXERCISER	5-Dec-1983 10:27:14 VAX-11 Bliss-16 V3-555 Page 24 5-Dec-1983 10:27:04 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (22)
:	C 0984		
	C 0985 C 0986 C 0987	41 Drive error.	See #40.
•	C 0988	42 Host write compare error.	Error detected when Host
	C 0989 C 0990 C 0991 C 0992 C 0993	42 Host write compare error.	CPU compared the data written and read back. May be a problem with the Host or Controller RAM.
	C 0994 C 0995	43 Message from internal diagnostic	See #40.
	C 0996 C 0997 C 0998	44 Duplicate unit number detecte by the Controller.	ed
:	C 0999	45 Unknown end code received.	Problem with the Control-
	C 1000		ler microcode or the port/
:	C 1001		DMA interface.
:	C 1003	DUP ERRORS	HT THE THE THE THE THE THE THE THE THE T
	C 1004	Host found error	보고 있으면 가게 하는 것 같아. 이번 가는 그는 것이 되었다. 그를 내는 것 같아. 그렇게 되었다.
:	C 1005	46 DBN compare error.	see # 42
:	C 1006 C 1007	Message errors	: [1] [1] [1] [1] [1] [1] [1] [1] [1] [1]
	C 1008 C 1009	47 No local media	Controller local program on RAM may be corrupt
	C 1010 C 1011 C 1012	48 Illegal Unit #	Unit went offline
	C 1013 C 1014	49 Illegal relative or physical BLM	( # see # 31
:	C 1015 C 1016	50 Device Error	Possible write protected
	C 1017 C 1018	51 Zero lenght message	see # 31
	C 1019	Status errors	
:	C 1020	52 Invalid Command	see # 31
	C 1022	53 No region available	see # 31
:	C 1023		나는 보통하는 경기를 잃었다면 하는 사람들은 보다 되었다면 보다 하는 것이 없는 것이 없는 것이 없다면
	C 1024 C 1025	54 No region suitable	see # 31
	C 1026 C 1027	55 Program not known	see # 47
	C 1028	56 Load failure	
:	C 1030 C 1031	57 Stand alone type program	see # 31
	C 1032	58 DUP unkown status code	see # 31

		-	-
P	1		J
		-	

ZRQAM VO1.2		EXERCISER	5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Page DISK*USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (23)	25
:	C 1033 C 1034 C 1035 C 1036	SOFT ERRORS			
	C 1037 C 1038 C 1039 C 1040	60 Controller error.	See error-log pa details as the exa may not be evident	ct cause	
	C 1041 C 1042 C 1043	61 Host memory access	s error. See #50.		
	C 1044 C 1045	62 Disk transfer erro	or. See #50.		
	C 1046 C 1047 C 1048	63 'Standard Disk error.	Inteconnect' See #50.		
i	C 1049	64 'Small Disk' error	See #50.		

VAX-11 Bliss-16 V3-555 Page 26 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (24)

ZRQAM1 VO1.2		RD/RX EXERCISER			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	
	C 1050 C 1051 C 1052 C 1053 C 1054	7.0	DATA PATTE	ERNS		
	C 1055 C 1056 C 1057		HEX	OCTAL	BINARY	
	C 1058 C 1059 C 1060	Pattern 1		RANDOM	NUMBERS	
	C 1061 C 1062	Pattern 2	0000	000000	0 000 000 000 000 000	
	C 1063 C 1064	Pattern 3	FFFF	177777	1 111 111 111 111 111	
	C 1065 C 1066	Pattern 4	8B8B	105613	1 000 101 110 001 011	
	C 1067 C 1068	Pattern 5	3333	031463	0 011 001 100 110 011	
:	C 1069 C 1070	Pattern 6	3091	030221	0 011 000 010 010 001	
	C 1071 C 1072 C 1073 C 1074 C 1075 C 1076 C 1077 C 1078 C 1079 C 1080 C 1081 C 1082 C 1083 C 1084 C 1085 C 1086 C 1087 C 1088	Pattern 7	0001 0003 0007 000F 001F 003F 007F 01FF 07FF 07FF 17FF 37FF 77FF	000001 000003 000007 000017 000037 000077 000177 000777 001777 003777 017777 017777	C 000 000 000 000 001 0 000 000 000 000 011 0 000 000 000 000 111 0 000 000 000 001 111 0 000 000 000 011 111 0 000 000 000 111 111 0 000 000 001 111 111 0 000 000 011 111 111 0 000 001 111 111 111 0 000 011 111 111 111 0 001 111 111 111 111 0 011 111 111 111 111 1 111 111 111 111 11	
	C 1089 C 1090 C 1091 C 1092 C 1093 C 1094 C 1095 C 1096 C 1097 C 1098 C 1099 C 1100 C 1101 C 1102	Pattern 8	FFFE FFFO FFFO FFEO FFOO FEOO FCOO FOOO EOOO COOO	177776 177774 177770 177760 177740 177700 177600 177400 177000 176000 174000 170000 160000	1 111 111 111 111 110 1 111 111 111 110 1 111 11	

ZRQAM1 VO1.2 RD/RX EXERCISER

5-Dec-1983 10:27:14 5-Dec-1983 10:27:04

C 1103 C 1104

8000 100000 1 000 000 000 000 000 000 000 000

				65	
ZRQAM1 VO1.2	RD/RX EX	ERCISER		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Page 28 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (25)
	C 1108 C 1109 C 1110 C 1111 C 1112 C 1113 C 1114 C 1115 C 1116 C 1117 C 1118 C 1119 C 1120 C 1121 C 1122	tern 9 0000 0000 0000 FFFF FFFF 0000 0000 FFFF 0000 FFFF 0000 FFFF	000000 000000 177777 177777 177777 000000 000000 177777 177777 000000 177777 000000 177777	0 000 000 000 000 000 0 000 000 000 000	
	C 1123 C 1124 Pat C 1125	tern 10 B6D9	133331	1 011 011 011 011 001	
		5555 5555 5555 5555 AAAA AAAA 5555 AAAA AAAA 5555 AAAA 5555 AAAA 5555 AAAA 5555 AAAA	052525 052525 052525 125252 125252 125252 052525 052525 125252 052525 125252 052525 125252 052525 125252	0 101 010 101 010 101 0 101 010 101 010 101 0 101 010 101 010 101 1 010 101 010 101 010 1 010 101 010 101 010 1 010 101 010 101 010 0 101 010 101 010 101 0 101 010 101 010 101 1 010 101 010 101 010 1 010 101 010 101 010 1 010 101 010 101 010 1 010 101 010 101 010 0 101 010 101 010 101 1 010 101 010 101 010 1 010 101 010 101 010 0 101 010 101 010 101 1 010 101 010 101 010	
		2020 2020 2020 2020 0202 0202 2020 2020 2020 2020 2020 2020 2020 2020 2020 2020 2020 2020	026455 026455 026455 151322 151322 026455 026455 151322 026455 026455 026455 151322 026455 151322 026455	0 010 110 100 101 101 0 010 110 100 101 101 0 010 110 100 101 101 1 101 001 011 010 010 1 101 001 011 010 010 1 101 001 011 010 010 0 010 110 100 101 101 0 010 110 100 101 101 1 101 001 011 010 010 1 101 001 011 010 010 1 101 001 011 010 010 1 101 001 011 010 010 0 010 110 100 101 101 0 010 110 100 101 101 1 101 001 011 010 010	

ZRQAM1 VO1.2	RD/RX EXERCISER			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555
	C 1158 C 1159 C 1160 C 1161 C 1162	2020 0202 2020 0202	026455 151322 026455 151322 026455	0 010 110 100 101 101 1 101 001 011 010 010	

ZRQAM1 VO1.2	RD/RX EXERCISER		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555
1	C 1163		3-560-1703-10.27.04	DISK FOSERE: [DIETZ.RDRX]ZR@ACO.BLI;02 (26)
	C 1164 C 1165 Pattern 13 C 1166	6DB6 066666	0 110 110 110 110 110	
	C 1167 C 1168 C 1169 C 1170 C 1171 C 1172 C 1173 C 1174 C 1175 C 1176 C 1177 C 1178 C 1179 C 1180 C 1181 C 1182 C 1183	0001 000001 0002 000002 0004 000004 0008 000010 0010 000020 0020 000040 0080 000200 0100 000400 0200 001000 0400 002000 0400 002000 0800 004000 1000 010000 2000 02000 4000 020000 4000 020000 4000 040000 8000 100000	0 000 000 000 000 001 0 000 000 000 000 010 0 000 000 000 000 100 0 000 000 000 001 000 0 000 000 000 100 000 0 000 000 001 000 000 0 000 000 010 000 000 0 000 000 100 000 000 0 000 010 000 000 000 0 000 100 000 000 000 0 001 000 000 000 000 0 010 000 000 000 000 0 100 000 000 000 000	
	C 1184 Pattern 15 C 1185 C 1186 C 1187 C 1188 C 1189 C 1190 C 1191 C 1192 C 1193 C 1194 C 1195 C 1196 C 1197 C 1198 C 1199	FFFE 177776 FFFD 177775 FFFB 177773 FFF7 177767 FFEF 177757 FFBF 177677 FFFF 177577 FEFF 177577 FEFF 175777 FBFF 175777 FFFF 175777 FFFF 175777 FFFF 175777 FFFF 175777 FFFF 175777 FFFF 175777	1 111 111 111 111 110 1 111 111 111 111	
	C 1200 C 1201 Pattern 16 C 1202 C 1203 C 1204 C 1205 C 1206 C 1207 C 1208 C 1209 C 1210 C 1211 C 1212 C 1213 C 1214 C 1215	B609 133331 B609 133331 DB6C 155554 DB6C 155554 DB6C 155554 B609 133331 B609 133331 DB6C 155554 DB6C 155554 B609 133331 DB6C 155554 B609 133331 DB6C 155554 B609 133331	1 011 011 011 011 001 1 011 011 011 011	

F3

ZRQAM1 VO1.2

RD/RX EXERCISER

5-Dec-1983 10:27:14 5-Dec-1983 10:27:04

C 1216

DB6C 155554

1 101 101 101 101 100

ZRQAM1 VO1.2	RD/RX EXERCISER		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Page 32 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (27)
	C 1217 C 1218 C 1219 Pattern 17 C 1220 C 1221 C 1222 C 1223 C 1224 C 1225 C 1226 C 1227 C 1228 C 1229 C 1230 C 1231 C 1232 C 1233 C 1234 C 1235 C 1236 C 1237	LBN LBN 8D36 106466 8D36 106466 72C9 071311 72C9 071311 8D36 106466 8D36 106466 8D36 106466 8D36 106466 8D36 106466 72C9 071311 8D36 106466 8D36 106466 8D36 106466 8D36 106466	LBN  1 C00 110 100 110 110 1 000 110 100 110 110	
	C 1237 C 1238 C 1239 C 1240 C 1241 Pattern 18 C 1242 C 1243 C 1244 C 1245 C 1246 C 1247 C 1248 C 1249 C 1250 C 1251 C 1252 C 1253 C 1254 C 1255 C 1256 C 1257 C 1258 C 1259 C 1260 C 1261	8D36 106466 8D36 106466 8D36 106466 LBN LBN 72C9 071311 8D36 106466 8D36 106466 8D36 106466 72C9 071311 72C9 071311 72C9 071311 72C9 071311 8D36 106466 8D36 106466 8D36 106466 8D36 106466 8D36 106466 8D36 106466 8D36 106466 8D36 106466 8D36 106466 72C9 071311 72C9 071311 72C9 071311 72C9 071311	1 000 110 100 110 110 1 000 110 100 110 11	

			H3	
ZRQAM1 VO1.2	RD/RX EXERCISER		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555
	C 1262 C 1263 C 1264 Pattern 19 C 1265 C 1266 C 1267 C 1268 C 1269 C 1270 C 1271 C 1272 C 1273 C 1274 C 1275 C 1276 C 1277 C 1278 C 1279 C 1280 C 1281 C 1282 C 1283 C 1284	LBN LBN B999 134631 4666 043146 4666 04314 4666 04314 4666 04314 4666 04314 4666 04314 4666 04314 4666 04314 4666 04314 4666 04314 4666 04314 4666 04314 4666 04314 4666 04314	LBN  1 011 100 110 011 001 1 011 100 110 011 001 0 100 011 001 100 110 0 100 011 001 100 110 0 100 011 001 100 110 1 011 100 110 011 001 1 011 100 110 011 001 1 011 100 110 011 001 1 011 100 110 011 001 1 011 100 110 011 001 0 100 011 001 100 110 0 100 011 001 100 110 0 100 011 001 100 110 0 100 011 001 100 110 1 011 100 110 011 001 1 011 100 110 011 001 1 011 100 110 011 001 1 011 100 110 011 001 1 011 100 110 011 001 1 011 100 110 011 001 1 011 100 110 011 001	
	C 1285 C 1286 Pattern 20 C 1287 C 1288 C 1289 C 1290 C 1291 C 1292 C 1293 C 1294 C 1295 C 1296 C 1297 C 1298 C 1299 C 1300 C 1301 C 1302 C 1303 C 1304 C 1305 C 1306 C 1307	B999 134631 B999 134631 B999 134631 B999 134631 B999 134631 4666 043146 4666 043146 4666 043146 B999 134631 B999 134631	1 011 100 110 011 001  CBN  0 100 011 001 100 110  1 011 100 110 011 001  1 011 100 110 011 001  1 011 100 110 011 001  0 100 011 001 100 110  0 100 011 001 100 110  0 100 011 001 100 110  1 011 100 110 011 001  1 011 100 110 011 001  1 011 100 110 011 001  1 011 100 110 011 001  1 011 100 110 011 001  1 011 100 110 011 001  1 011 100 110 011 001  0 100 011 001 100 110  0 100 011 001 100 110  0 100 011 001 100 110  0 100 011 001 100 110  0 100 011 001 100 110  0 100 011 001 100 110  0 100 011 001 100 110	
	C 1308 Pattern 21 C 1309 1310 )s	LBN LBN	LBN	

```
ZRQAM1
                 RD/RX EXERCISER
                                                                        5-Dec-1983 10:27:14
                                                                                                  VAX-11 Bliss-16 V3-555 Page 34 DISK*USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (29)
V01.2
                 PROGRAM HEADER
                                                                        5-Dec-1983 10:27:04
           1311 #sbttl 'PROGRAM HEADER'
           1312
           1313 library 'ZRQACO.L16';
                                                                       ! RDRX EXERCISER GLOBAL LIBRARY
           1314
           1315 require 'BLSMAC.REQ';
                                                                       ! DIAGNOSTIC SUPERVISOR LIBRARY
           2806
2807
2808
                 DS$NBR_OF_TESTS = 1;
                                                                       ! NUMBER OF TESTS IN THIS DIAGNOSTIC
           2809
           2810 EQUALS:
           2811
           2812 POINTER (ALL);
           2813
           2814 !+
2815 ! THE PROGRAM HEADER IS THE INTERFACE BETWEEN
PROGRAM AND THE SUPERVISOR.
           2817 !-
           2818
           2819 HEADER (#ascii'ZRQA', #ascii'C', #ascii'O', 32767, 1, PRIOO);
```

VAX-11 Bliss-16 V3-555 Page 35 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (30)

ZRQAM1 VO1.2	RD/RX EXERCISER DISPATCH TABLE		5-Dec-1983 5-Dec-1983	
: 2820 : 2821				
: 2823 : 2823	! THE DISPATCH TABLE CONTAINS THE	STARTING AD	DRESS OF EACH	TEST.
: 2825	!-	DISPATOR TO	z chon rest.	
: 2827	DISPATCH (DS\$NBR_OF_TESTS);			

```
SEQ 0036
ZRQAM1
                   RD/RX EXERCISER
                                                                                 5-Dec-1983 10:27:14
                                                                                                             VAX-11 Bliss-16 V3-555
                                                                                                                                                           Page 36
V01.2
                   GLOBAL DATA SECTION
                                                                                 5-Dec-1983 10:27:04
                                                                                                             DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (31)
            2828 #sbttl 'GLOBAL DATA SECTION'
            2829
            2830
            2831
                   ! THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
            2832
                    ! IN MORE THAN ONE TEST.
            2833
            2834
            2835
                   psect
            2836
                         global = $FFF$ (read, nowrite, execute, local, concatenate);
            2837
            2838
                   global
            2839
                         CST : blockvector [MAX_CTLR, CST_LEN, word] field (CST_FIELDS),
            2840
                                                  ! RUN-TIME CONTROLLER STATUS TABLES
            2841
                         CST_ADDR : ref block [CST_LEN, word] field (CST_FIELDS)
                        ! CONTROLLER STATUS TABLE ADDRESS OF "CURRENT" CONTROLLER
DCT : blockvector [MAX_CTLR, DCT_LEN, word] field (DCT_FIELDS),
! DRIVER CONTROLLER TABLES
            2842
            2843
            2844
            2845
                         DCT_ADDR : ref block [DCT_LEN, word] field (DCT_FIELDS)
            2846
                                                  ! ADDRESS OF "CURRENT" DRIVER CONTROLLER TABLE
            2847
                         RDRX_ADDR : ref rdrx field (RC_REG),
            2848
                                                  ! DEVICE ADDRESS OF "CURRENT" CONTROLLER
                        IRDRX_ADDR : ref rdrx field (RC_REG),
ICOM_ADDR : ref block (COMM_LEN, word) field (COM_FIELDS),
! ADDRESS OF INTERRUPTING CONTROLLER'S COMMUNICATION AREA
            2849
            2850
            2851
            2852
                         ICST_ADDR : ref block [CST_LEN, word] field (CST_FIELDS),
! ADDRESS OF INTERRUPTING CONTROLLER'S CST
            2853
            2854
                         IDCT_ADDR : ref block [DCT_LEN, word] field (DCT_FIELDS),
! ADDRESS OF INTERRUPTING CONTROLLER'S DCT
            2855
                         RDM_CNT : word initial (RDM_LEN),
            2856
                                                                                  NUMBER OF RANDOM NUMBERS
                                                                                                                 \ KEEP
            2857
                                                                                ! RANDOM NUMBER TABLE
                         RANDOM : vector [RDM_LEN, word],
                                                                                                                  / TOGETHER
            2858
                                                  ! DEVICE ADDRESS OF INTERRUPTING CONTROLLER
            2859
                         TRK_SGN : vector [MAX_UNITS, byte, signed] initial (byte (rep MAX_UNITS of (1))),
                                                                                                                                           ! CURRENT TRACK DIRE
CTION
                        DUPPKT : BLOCK [257, WORD] field (DP_FIELDS).
! BUFFER CONTAINING DUP INFORMATION FROM RECEIVE AND SEND COMMANDS
            2860
            2861
            2862
                         BST : blockvector [MAX_UNITS, 2, WORD], . CONATIN LBNS(LO & HI FIELDS) FOR SEQUENTIAL I/O TRANSFER FOR EACH UNIT
            2863
            2864
                         TALLY : vector [MAX_UNITS * TALLY_LEN, word] field (T_FIELDS).
! STATISTICS TABLES
            2865
                        T_ADDR : ref block [TALLY_LEN, word] field (T_FIELDS), ! ADDRESS OF STATISTICS TABLE (TALLY) FOR CURRENT UNIT
            2866
            2867
            2868
                         C_ERR_TBL : blockvector [MAX_CTLR, C_ERR_LEN, word] field (C_ERR_FIELDS), ! STATISTICS TABLE FOR CONTROLLER ERRORS
            2869
            2870
                         MSCP_PKT : blockvector [PKT_CNT, PKT_LEN, word] field (PKT_FIELDS).
            2871
                                                  ! MSCP PACKET POOL
            2872
                         IPKT_ADDR : ref block [PKT_LEN, word] field (PKT_FIELDS).
! ADDRESS OF AN MSCP PACKET (INTERUPT PROCESSING)
            2873
                        PKT_USE : vector [PKT_CNT, byte, signed],
! MSCP PACKET POOL ALLOCATION TABLE
RETPKT : blockvector [RP_CNT, RP_LEN, word] field (RP_FIELDS),
            2874
            2875
            2876
            2877
                                                  ! RETURN PACKET POOL
                        RP_USE : vector [RP_CNT, byte, signed]. ! RETURN PACKET POOL ALLOCATION TABLE
            2878
            2879
            2880
                         RP_INDX : word.
                                                  ! CURRENT RETURN PACKET INDEX
```

Page 37

```
ZRQAM1
                     RD/RX EXERCISER
                                                                                        5-Dec-1983 10:27:14
                                                                                                                      VAX-11 Bliss-16 V3-555
V01.2
                     GLOBAL DATA SECTION
                                                                                       5-Dec-1983 10:27:04
                                                                                                                      DISK $USER2: [DIETZ.RDRX]ZRQACO.BL1:82 (31)
              2881
                           RP_ADDR : ref block [RP_LEN, word] field (RP_FIELDS).
              2882
                                                      ! CURRENT RETURN PACKET ADDRESS
.
                          ELOG_PKT : blockvector [EP_CNT, EP_LEN, word] field (EP_FIELDS),
! ERROR-LOG PACKET SAVE AREA

BUFF_ADDR : vector [MAX_BUF_CNT],
! TABLE OF I
BUFF_OWN : vector [MAX_BUF_CNT, byte, signed],
! I/O BUFFER
              2883
:
              2884
              2885
                                                                                                 ! TABLE OF I/O BUFFER DESCRIPTORS
              2886
                                                                                                ! I/O BUFFER OWNERSHIP (CTLR NUMBER)
                           IODQ : vector [IODQ_LEN, byte].
              2887
                                                                           ! I/O DONE QUEUE - CIRCULAR QUEUE OF RETPKT INDECES ! I/O DONE QUEUE IN POINTER ! I/O DONE QUEUE OUT POINTER
              2888
              2889
                           IODQ_IN : word,
              2890
                           IODQ_OUT : word,
                           ENTRY_REASON : byte.
              2891
                                                                              CURRENT OPERATOR COMMAND
                           EOP_FLAG : byte.
              2892
                                                                              END-OF-PASS FLAG
                           DUP FLAGS : WORD.
                                                                           ! DUP FLAGS
              2893
              2894
                           CCTLR : word,
                                                                            ! NUMBER OF "CURRENT" CTLR
              2895
                           CDISK : word.
                                                                              CURRENT DISK ADDRESS (RD/RX DISK NUMBER)
                                                                              CURRENT UNIT CST OFFSET
              2896
                           CUOFF : word,
              2897
                           CTLR_CNT : word.
                                                                            ! TOTAL NUMBER OF CONFIGURED CTLRS
                           DUR : vector [MAX_UNITS, byte],
QIO : vector [MAX_CTLR, byte],
                                                                              DROP UNIT REASON
              2898
:
              2899
                                                                              NUMBER OF OUTSTANDING QIOS PER CTLR
:
                          FREE_MEM_ADDR.
BYTS_PER_QIO : word.
ST_CODE : word.
                                                                              START OF FREE MEMORY
SIZE (BYTES) OF AN I/O BUFFER
              2900
:
              2901
                                                                             CURRENT STATUS CODE
CURRENT SUB-CODE
CURRENT STEP IN HARD_INIT
OFFSET (0 OR 2) TO READ IP OR SA
STORAGE FOR SA REGISTER READS AND WRITES
              2902
              2903
                           SB_CODE : word.
                           STEP : word,
              2904
                           OF_RC : signed word,
              2905
                           SA_REG : word,
              2906
              2907
                           CMD_TIME : word.
                                                                              COMMAND TIMEOUT VALUE (IN SECONDS)
NON-EXISTENT MEMORY TRAP INDICATOR
              2908
                           NEX : word.
              2909
                           CRN_LOW : word.
                                                                              COMMAND REF NUMBER OF LAST COMMAND SENT
              2910
                                                                            ! COMMAND REF NUMBER (HI ORDER)
                           CRN_HIGH : word.
.
                           P_INDEX : signed word, S_DUPPKT : WORD,
                                                                ! CURRENT message PACKET INDEX ! DBN BYTE COUNTER
              2911
              2912
2913
                           S_PATTERN : WORD,
CREDIT_BAL : word,
INIT_OCCURED : BYTE,
NXT_PKT_2USE : byte;
                                                                 ! THE PATTERN WRITTEN TO DBN'S
              2914
                                                                           ! CREDIT BALANCE
              2915
                                                                           ! INDICATES IF EXERCISER FINISHED INIT SEQUENCE
              2916
                                                                            ! POINTER TO NEXT ENTRY IN PKT_USE TABLE
              2917
```

2918 ERRTBL:

Page 38

```
ZRQAM1
                  RD/RX EXERCISER
                                                                         5-Dec-1983 10:27:14
                                                                                                    VAX-11 Bliss-16 V3-555
V01.2
                  GLOBAL TEXT SECTION
                                                                         5-Dec-1983 10:27:04
                                                                                                    DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (32)
           2919 #sbttl 'GLOBAL TEXT SECTION'
           2920
.
           2921
           2922
                  ! THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS.
           2923
                    MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
           2924
                  ! MORE THAN ONE TEST.
           2925
           2926
           2927
                  global bind
           2928
           2929
                    HARDWARE DIALOG
           2930
           2931
                      HWQ1 = uplit (#asciz'IP ADDRESS'),
           2932
                      HWQ2 = uplit (#asciz'VECTOR'),
                      HWQ3 = uplit (#asciz'BR LEVEL'),
HWQ4 = uplit (#asciz'RD/RX DRIVE NUMBER'),
HWQ6 = uplit (#asciz'STARTING LBN'),
           2933
           2934
           2935
           2936
                      HWQ7 = uplit (#esciz'ENDING LBN (MAXIMUM - RX50: 799, RD51: 21599, RD52: 47999)'),
:
           2937
                      HWQ8 = uplit (#asciz'WRITE ON CUSTOMER DATA AREA ON THIS DISK'),
                      HWQ9 = uplit (#asciz' ** WARNING - CUSTOMER DATA AREA MAY BE OVERWRITTEN! ... CONFIRM'),
           2938
                      HWQ10 = uplit (#esciz'EXERCISE ON DIAGNOSTIC AREA (-NON-CUSTOMER AREA RDs ONLY)'),
HWQ11 = uplit (#esciz'WRITE ON DIAGNOSTIC AREA'),
           2939
.
           2940
           2941
           2942
           2943
                    SOFTWARE DIALOG
                  .
           2944
           2945
                       SWQ1 = uplit (#esciz'HARD ERROR LIMIT'),
           2946
                       SWQ2 = uplit (#asciz'TRANSFER LIMIT IN MEGABYTES (0 for "QUICK PASS")').
           2947
2948
2949
                       SWQ4 = uplit (#esciz'RANDOM UNIT MODE'),
                       SWQ7 = uplit (#asciz'READ-COMPARES PERFORMED AT THE CTLR')
                       SWQ9 = uplit (#asciz'WRITE-COMPARES PERFORMED AT THE CTLR'), SWQ10 = uplit (#asciz'CHECK ALL WRITES AT HOST BY READING'),
           2950
           2951
                       SWQ11 = uplit (#esciz'USER-DEFINED DATA PATTERN').
                       SWQ12 = uplit (#asciz'SELECT PRE-DEFINED DATA PATTERN (0 for sequential selection)'), SWQ13 = uplit (#asciz'NUMBER OF WORDS IN DATA PATTERN (16 maximum)'),
           2952
           2953
           2954
                       SWQ14 = uplit (#asciz'PATTERN VALUE')
           2955
                       SWG15 = uplit (#eeciz'CLEAR STATISTICAL TABLES AFTER PRINTING')
           2956
                       SWQ17 = uplit (#asciz'PERCENTAGE OF WINCHESTER OPERATIONS OUT OF TOTAL OPERATIONS').
                       SWQ19 = uplit (#eeciz'RANDOM BLOCK MODE'),
           2957
                       SWG20 = uplit (#asciz'WANT TO REWRITE BLOCKS WHEN "FORCED ERROR" DETECTED ON READS')
           2958
           2959
2960
                       SWG21 - uplit (#eeciz'IF "HALT ON ERROR" FLAG SET, WANT TO HALT ON HARD/SOFT ERRORS ALSO').
                       SWQ22 = uplit (#eeciz'NUMBER OF DBNs TRANSFERRED AT ONE "DUP" PASS')
           2961
                       SWM1 - uplit ( seciz' THE REMAINING QUESTIONS ONLY APPLY TO UNPROTECTED DISKS').
           2962
                      NULL = uplit (#asciz''),
           2963
           2964
           2965
                     THE FOLLOWING DBMs ARE DEBUG MESSAGES, AND SHOULD BE REMOVED BEFORE
           2966
                     RELEASING THE PROGRAM. THEY INCLUDE THE NAMES OF EACH ROUTINE. PLUS
           2967
                     FORMAT STATEMENTS FOR PRINTING OUT OTHER INFORMATION.
           2968
           2969
           2970
                             " uplit (#asciz'#N#A** DROP UNIT #D2').
           2971
                      DBM12 = uplit (#asciz'#N#A++ PROC_RETPKT: CONN ID = #D5#A RECEIVED').
```

```
SEQ 0039
ZRQAM1
                    RD/RX EXERCISER
                                                                                     5-Dec-1983 10:27:14
                                                                                                                   VAX-11 Bliss-16 V3-555
                                                                                                                  VAX-11 Bliss-16 V3-555 Page 39 DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (32)
V01.2
                    GLOBAL TEXT SECTION
                                                                                     5-Dec-1983 10:27:04
             2972
                           DBM15 = uplit (#asciz'#N#A** MULTI-DRIVE TEST').
                          DBM18 = uplit (#asciz'#N#A** FTL ERR: RETPKT NOT AVAILABLE'),
             2973
                          DBM19 = uplit (#asciz'#N#A** FSET_UPAR: CAN''T FIND DISK #D3#A IN CST #D1'),
DBM20 = uplit (#asciz'#N#A** BAD CONN ID = #D5#A RECEIVED FROM #06'),
             2974
             2975
.
             2976
                          DBM21 = uplit (#asciz'#N#A** MESSAGE TYPE #D2#A RECEIVED IN MSCP PACKET'),
             2977 !
                           DBM22 = uplit (#asciz'#N#A++ SEQUEN: RETPKT NOT AVAILABLE'),
                          DBM23 = uplit (#asciz'#N#A++ ERR IN SET_CTLR_CHAR'),
DBM25 = uplit (#asciz'#N#A++ CTLR TIMEOUT = #D3#A SECONDS'),
             2978
             2979
                         DBM26 = uplit (#asciz'#N#A+* ERR IN UNIT_INIT'),

DBM27 = uplit (#asciz'#N#A+* UNIT_INIT: RETPKT HAS BAD ENDCODE'),

DBM28A = uplit (#asciz'#N#A+* UNIT_SIZE (LO) = #D5'),

DBM28B = uplit (#asciz'#N#A+* UNIT_SIZE (HI) = #D5'),
             2980
             2981
:
             2982
:
             2983
                          DBM29 = uplit (#asciz'#N#A++ ACCESS: RETPKT HAS BAD ENDCODE')
             2984
                           DBM32 = uplit (#asciz'#N#A++ QIO_UNIT: CST #D1#A NO UNIT SELECTED'),
DBM101 = uplit (#asciz'#N#A++ UNIT # IS: #06'),
             2985
             2986
             2987
                           DBM104 = uplit (#asciz'#N#A++ RX50 IS SELECTED').
.
                           DBM105 = uplit (#asciz'#N#A** RD51 IS SELECTED').
             2988
:
                         DBM107 = uplit (#asciz'#N#A** ILLEGAL FUNCTION: #06'),
DBM108 = uplit (#asciz'#N#A** COMMAND REF # #D5#A. NOT SENT BY HOST'),
DBM109 = uplit (#asciz'#N#A** UNKNOWN ERROR LOG FORMAT #D3#A. RECEIVED'),
DBM110 = uplit (#asciz'#N#A** ERROR-LOG SAVE AREA FULL'),
DBM111 = uplit (#asciz'#N#A** REINIT MSCP EXERCISER'),
             2989
.
             2990
             2991
             2992
             2993
                          DBM112 = uplit (#asciz'#N#A++ DUP: PKT NOT AVAILABLE').
             2994
             2995
                     !DER10 = uplit (#asciz'#N#A++ DUP')
             2996
                     !DER13 = uplit (#asciz'#N#A++ DUP COMMAND').
             2997
             2998
                    ! DROP UNIT MESSAGES
             2999
             3000
                          DU_MSG = uplit (#asciz'#N#AUNIT#D2#A DROPPED - ').
:
             3001
                          DU_RSN = uplit
             3002
                                     uplit (#asciz'#AUSER CMD#N'),
             3003
                                     uplit (#asciz'#ACONFIGURATION ERR#N'),
             3004
                                     uplit (#asciz'#AINIT ERR#N')
             3005
                                     uplit (#asciz'#ATRANSFER LIMIT REACHED#N'),
:
             3006
                                     uplit (#asciz'#AERR LIMIT REACHED#N').
                                     uplit (#asciz'#AUNRECOVERABLE DEV ERR#N'),
uplit (#asciz'#AUNRECOVERABLE CTLR ERR#N'),
             3007
             3008
                                     uplit (#asciz'#AFAILED TO COME ONLINE#N')
             3009
             3010
                                     uplit (#asciz'#AFAILED TO ACCESS LAST TRACK DURING INIT#N').
             3011
                                     uplit (#asciz'#ADISK WRITE PROTECTED#N'),
             3012
                                     uplit (#asciz'#ACMD TIME OUT#N')
             3013
                                     uplit (#asciz' #AUNIT WENT TO AVAILABLE STATE N')) : vector [11],
             3014
             3015
                       SYSTEM MESSAGES (PRINTF)
             3016
             3017
                          MSG_01 = uplit (#asciz'#N#APOWER DELAY - WAITING')
             3018
                          MSG_02 = uplit (#asciz'#N#AFUNCTIONAL TEST STARTED').
             3019
                          MSG_03 = uplit (#asciz'#N#N#AEXERCISER STARTED#N'),
             3020
             3021
                       REPORT MESSAGES (PRINTS)
             3022 !
             3023
                          RPT1 = uplit (#asciz'#N#N#AUNT DSK#S8#A# OF # BYTES # OF
                                                                                                               # BYTES').
             3024
                          RPT2 = uplit (#asciz'#A --HARD ERRCRS-- --SOFT ERRORS--').
```

```
SEQ 0040
ZRQAM1
                RD/RX EXERCISER
                                                                    5-Dec-1983 10:27:14
                                                                                            VAX-11 Bliss-16 V3-555 Page 40 DISK#USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (32)
V01.2
                 GLOBAL TEXT SECTION
                                                                    5-Dec-1983 10:27:04
                     RPT3 - uplit (#esciz'#N#A # # TYPE READS
          3025
                                                                         READ WRITES
                                                                                          WRITTEN').
          3026
                     RPT4 - uplit (#esciz'#A SEK DAT DRV HST SEK DAT DRV HST').
          3027
                     RPT5 - uplit (#asciz'#N#A--- --- ----
          3028
                     RPT6 = uplit (#esciz'#A --- --- ).
          3029
                     RPT7 - uplit (#asciz'#N#D2#D4#A RX50').
                     RPT8 - uplit (#esciz'#N#D2#D4#A RD51'),
          3030
          3031
                     RPT9 = uplit (#esciz'#D4#Z3#D3#A,#Z3#A,#Z3')
          3032
                     RPT10 = uplit (#asciz'#D4#D4#D4#D4#D4#D4#D4#D4").
                    3033
                                                                                      3034
                                                                       . #D4#A .').
                     RPT13 - UPLIT(#ASCIZ'#N#N#AUNIT DISK
          3035
                                                                                # BLKS
                                                                                              Ø OF
                                                                        Ø OF
                                                                                                      # BLKS ').
                     RPT14 - UPLIT(#ASCIZ'#N#A . .
                                                                                           WRITES WRITTEN ').
          3036
                                                              TYPE
                                                                     READS
                                                                                READ
          3037
                     RPT15 = UPLIT(#ASCIZ'#N#A----
                     RPT16 = UPLIT(#ASCIZ'#N#S1#D2#S4#D2#A DBNRD51 #D6#S3#D6#S5#D6#S3#D6'),
          3038
          3039
                     RPT17 - uplit (#esciz'#N#D2#D4#A RD52').
          3040
                     RPT18 = UPLIT(#ASCIZ'#N#S1#D2#S4#D2#A DBNRD52 #D6#S3#D6#S5#D6#S3#D6').
          3041
                     RPT19 - uplit (#esciz'#N#D2#D4#A ????').
          3042
          3043
                   GENERAL ERROR MESSAGES
          3044
          3045
                         SYSTEM FATAL (ERRSF)
          3046
          3047
                     EGS_01 = uplit (#asciz'TOO MANY UNITS').
          3048
                     EGS_02 = uplit (#esciz'NOT ENOUGH FREE MEMORY FOR ALLOCATING READ/WRITE BUFFERS').
          3049 !
          3050
                         DEVICE FATAL (ERROF)
          3051 !
          3052
                     EGD_10 = uplit (#eeciz'REG EXISTENCE TEST FAILED'),
          3053
                     EGD_11 * uplit (#asciz'VECTOR TEST FAILED'),
          3054
                     EGD_12 = uplit (#eeciz'BR LEVEL TEST FAILED'),
                     EGD_13 = uplit (#eeciz'INIT SEQUENCE FAILED'), EGD_14 = uplit (#eeciz'FATAL CTLR ERR'),
          3055
          3056
           3057
                     EGD_15 = uplit (#eeciz'ONLINE FAILED'),
EGD_16 = uplit (#eeciz'MRITE-PROTECT CONFLICT'),
EGD_17 = uplit (#eeciz'ACCESS FAILED'),
          3058
          3059
                     EGD_18 - uplit (seciz'FATAL I/O ERR').
          3060
                     EGD_19 = uplit (#eeciz'CTLR TIMEOUT'),
EGD_20 = uplit (#eeciz'FAILED TO SEND SET-CTLR-CHARACTERISTICS COMMAND').
          3061
          3062
          3063
                     EGD_21 = uplit (#eeciz'SET-CTLR-CHARACTERISTICS RESPONSE HAS BAD ENDCODE OR FLAGS IN ERR').
          3064
                     EGD_22 - uplit ( seciz' FAILED TO SEND ON-LINE COMMAND').
          3065
                     EGD_23 = uplit (#esciz'ON-LINE RESPONSE HAS BAD ENDCODE'),
EGD_24 = uplit (#esciz'ON-LINE RESPONSE HAS UNKNOWN DEVICE'),
          3066
           3067
           3068
                         HARD or SOFT (ERRHRD or ERRSOFT)
           3069
           3070
                     EGH_30 = uplit (#esciz'I/O REQUEST FAILED'),
           3071
          3072
                   BASIC ERROR MESSAGES (PRINTB)
           3073
           3074 !
                         SYSTEM FATAL (ERRSF)
           3075
          3076
                     EBS_01 = uplit (#esciz'#AMORE THAN #D2#A UNITS SPECIFIED').
          3077 !
```

```
SEQ 0041
ZRQAM1
                      RD/RX EXERCISER
                                                                                           5-Dec-1983 10:27:14
                                                                                                                          VAX-11 Bliss-16 V3-555 Page 41 DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (32)
                                                                                                                           VAX-11 Bliss-16 V3-555
                                                                                           5-Dec-1983 10:27:04
V01.2
                      GLOBAL TEXT SECTION
                                 DEVICE FATAL (ERRDF)
              3079 !
              3080
                            EBD_10 = uplit (#asciz'#A+ NO RESPONSE AT ADDRESS #06')
              3081
                            EBD_12 - uplit (#asciz'#A+ INCORRECT BR LEVEL FOR DEV #06'),
              3082
                            EBD_13 = uplit (#esciz'#A+ STEP #D1#A READ ERR'),
              3083
                            EBD_14 = uplit (#asciz'#A+ BAD SA CODE FROM DEV #06'),
              3084
                            EBD_18 = uplit (#aeciz'#A+ DISK#D2#A WENT OFFLINE')
              3085
                            EBD_19 = uplit (#asciz'#A+ DEVICE #06#A NOT PROCESSING COMMAND PACKETS').
              3086 !
              3087 !
                                 HARD or SOFT (ERRHRD or ERRSOFT)
              3088 !
                            EH_O = UPLIT (#ASCIZ' - unrecognized MESSAGE TYPE')
              3089
              3090
                            EH_1 = UPLIT (#ASCIZ' - unrecognized connection id'),
              3091
                            EH_2 = UPLIT (#ASCIZ' - unrecognized RETURN message'),
                           EH_3 = UPLIT (#ASCIZ' - unrecognized RETURN PACKET'),
EH_4 = UPLIT (#ASCIZ' - unrecognized CRN'),
EH_5 = UPLIT (#ASCIZ' - UNRECOGNIZED OPCODE'),
              3092
              3093
              3094
                           EH_6 = UPLIT (#ASCIZ' - MSCP STATUS CODE ERR'),
EH_7 = UPLIT (#ASCIZ' - DUP STATUS CODE ERR'),
              3095
              3096
                           EH_8 = UPLIT (#ASCIZ' - Unrecognized STATUS CODE'),
EH_9 = UPLIT (#ASCIZ' - LBN HOST COMPARE ERR'),!
EH_10 = UPLIT (#ASCIZ' - DBN HOST COMPARE ERR'),
EH_12 = UPLIT (#ASCIZ' - UNABLE TO LOAD DUP MEDIA'),
EH_13 = UPLIT (#ASCIZ' - ERR IN DUP-PKT WHEN USING CTLR LC PRG'),
              3097
              3098
              3099
              3100
              3101
                            ERR_COD - uplit (
              3102
                                          uplit (#esciz'#AINVALID COMMAND').
              3103
                                          uplit (#eeciz'#ACOMMAND ABORTED').
              3104
              3105
                                          uplit (#esciz'#AUNIT OFFLINE').
                                         uplit (#eeciz'#ATRANSITION TO AVAILABLE STATE'),
uplit (#eeciz'#AMEDIA FORMAT ERR'),
uplit (#eeciz'#AMRITE-PROTECTED'),
uplit (#eeciz'#ADEVICE COMPARE ERR'),
              3106
              3107
              3108
              3109
                                         uplit (#eeciz'#ADEVICE COMPARE ERR'),
uplit (#eeciz'#ADATA ERR'),
uplit (#eeciz'#AHOST BUFFER ACCESS ERR'),
uplit (#eeciz'#ACTLR ERR'),
uplit (#eeciz'#ADRIVE ERR'),
uplit (#eeciz'#AMESSAGE FROM INTERNAL DIAGNOSTICS'),
              3110
              3111
              3112
              3113
              3114
              3115
                                          uplit (#seciz'#AHOST COMPARE ERR'),
              3116
                                          uplit (#asciz' #ACOMMAND TIMEOUT')) : vector [14].
              3117 !
              3118 !
                                 ERROR LOG MESSAGE (ERRSOFT)
              3119 !
                           ELG_00 - uplit (#eeciz'#N#AERR LOG MESSAGE RECEIVED:#N'), ELG_FMT - uplit (
              3120
              3121
              3122
                                         uplit (#eeciz'#A+ CTLR ERR#N'),
uplit (#eeciz'#A+ HOST MEMORY ACCESS ERR#N'),
              3123
              3124
                                          uplit (#esciz'#A+ DISK#D2#A - DISK TRANSFER ERR#N')
              3125
                                          uplit (#eeciz'#A+ DISK#D2#A - "STANDARD DISK INTERCONNECT" ERR#N'),
              3126
                                          uplit (#eeciz'#A+ DISK#D2#A - "SMALL DISK" ERR#N')) : vector [5].
              3127
              3128 !
                         EXTENDED ERROR MESSAGES (PRINTX)
              3129 !
```

3130

```
SEQ 0042
ZRQAM1
                              RD/RX EXERCISER
                                                                                                                              5-Dec-1983 10:27:14
                                                                                                                                                                       VAX-11 Bliss-16 V3-555
                                                                                                                                                                          DISK USER2: [DIETZ.RDRX]ZRQACO.BL1;82 (32)
V01.2
                              GLOBAL TEXT SECTION
                                                                                                                              5-Dec-1983 10:27:04
                                      EX_BDR = uplit (#asciz'#N#AI/O BUFFER ADDRESS FOR READ (32 BITS): #06#A #06#N'), EX_BDW = uplit (#asciz'#N#AI/O BUFFER ADDRESS FOR WRITE (32 BITS): #06#A #06'),
                   3132
                                      EX_LBR = uplit (#esciz'#N#ALBN: (READ) #D5#A. (OCT #06#A #06#A)'),
EX_LBW = uplit (#esciz'#N#ALBN: (WRITE) #D5#A. (OCT #06#A #06#A)'),
                   3133
                   3134
                   3135
                                      EX_RBN = uplit (#esciz'#N#AREPLACEMENT BLOCK NO. #D5#A. (OCT #06#A #06#A)').
                                      EX_CBR = uplit (#aeciz'#N#ABYTE COUNT IN READ COMMAND: #D5#A.'),
EX_CBW = uplit (#aeciz'#N#ABYTE COUNT IN WRITE COMMAND: #D5#A.'),
                   3136
                   3137
                   3138
                   3139 XX13 = UPLIT (#ASCIZ'#NMA * DISK : #D2').
                   3140 XX14 = uplit (#eeciz'#N#ASA: #06'),
                   3141 XX15 = uplit (#eeciz'#N#ASTATUS CODE: ').
                   3142 XX16 = uplit (#esciz'#N#ASTATUS SUB-CODE: '),
                   3143 XX17 = uplit (#eeciz'#N#ACOMMAND: ').
                              XX18 = uplit (#esciz'#A-DUP-'),
                   3144
                  3145 XX19 = uplit (#eeciz'#A-MSCP-'),
3146 XX20 = uplit (#eeciz'#A-COMPARE'),
3147 XX21 = uplit (#eeciz'#N#ABAD BLOCK REPORTED: #06#A #06#A.'),
3148 XX22 = uplit (#eeciz'#N#ALBN: #D5#A. (OCT #06#A #06#A)'),
3149 XX23 = UPLIT (#ASCIZ'#N#ADBN: #D5#A. (OCT #06#A)'),
3150 XX24 = uplit (#eeciz'#N#ABYTE COUNT IN COMMAND: #05'),
3151 XX25 = uplit (#eeciz'#N#AACTUAL # OF BYTES TRANSFERRED: #05'),
                  3151 XX25 = uplit (#emciz'#N#AACTUAL # OF BYTES TRANSFERRED: #D5'),
3152 XX26 = uplit (#emciz'#N#AI/O BUFFER ADDRESS (32 BITS): #O6#A #O6'),
3153 XX27 = uplit (#emciz'#N#ACONTENTS OF RETURN PACKET:#N'),
3154 XX29 = UPLIT (#ASCIZ'#N#AMESSAGE TYPE: '),
3155 XX30 = UPLIT (#ASCIZ'#N#AMESSAGE NUMBERS: '),
3156 XX31 = UPLIT (#ASCIZ'#N#AMESSAGE ERR CODES: '),
3157 XX32 = UPLIT (#ASCIZ'#N#ABYTE NUMBER: #D3'),
3158 XX33 = UPLIT (#ASCIZ'#N#ARANDOM WRITTEN WORD :#B16'),
3159 XX34 = UPLIT (#ASCIZ'#N#ARANDOM READ WORD bin:#B16#A oct:#O6'),
3160 XX35 = UPLIT (#ASCIZ'#N#ARANDOM READ WORD bin:#B16#A oct:#O6'),
3161 !XX36 = UPLIT (#ASCIZ'#N#ATHE EXPECTED CRN : #O6#A #O6'),
3162 XX37 = UPLIT (#ASCIZ'#A - UNKNOWN : #D2').
                   3162 XX37 = UPLIT (#ASCIZ'#A - UNKNOWN : #D2'),
3163 XX38 = UPLIT (#ASCIZ'#A - UNKNOWN CONNECTION ID: #D3#A -'),
                   3164 XX39 - UPLIT (#ASCIZ'#N#ACTLR FLAGS:'),
                   3165 XX40 - UPLIT (MASCIZ'MNMAUNIT FLAGS:')
                   3166 XX41 - UPLIT (MASCIZ' MNMAEND MESSAGE FLAGS:')
                   3167 XX42 = UPLIT (Seeciz'SNSACONTENTS OF DUP I/O PACKET: SN'),
                   3168
                   3169
                   3170
                             ! UNKNOWN RETURN MESSAGES
                   3171 !
                                             EB_DCT = UPLIT (#ASCIZ'#N#A DRIVER CTLR TABLE = ADDR: #D6#N'),
EB_COMM = UPLIT (#ASCIZ'#N#A CMD INT, RSP INT, COMMAND RING = ADDR: #D6#N'),
EB_PKT = UPLIT (#ASCIZ'#N#A ALL PACKETS IN MESSAGE AREA'),
EB_RAL = UPLIT (#ASCIZ'#N#A ALL RETURN PACKETS IN AREA'),
EB_ADDR = UPLIT (#ASCIZ'#N#A ADDR: #D6#A PACKET = #N'),
                   3172
                   3173
                   3174
                   3175
                   3176
                                              EBNEX1 - UPLIT (#ASCIZ'#N#A ADDR OF RESPONSE RING TO BE POLLED #D6').
EB_NEX2 - UPLIT (#ASCIZ'#N#A ADDR OF MESSAGE PACKET RESPONSE RING SLOT POINTS TO #D6').
                   3177
                   3178
                   3179
                                              EBNEX3 - UPLIT (#ASCIZ' #N#A ADDR OF MESSAGE PACKET COMMAND RING SLOT POINTS TO #D6').
                   3180
                                              EB_SA = UPLIT (#ASCIZ' #N#A Contents of SA Register'),
                   3181
                                  CONFIGURATION ERROR MESSAGES (PRINTF)
                   3182
                   3183
```

```
SEQ 0043
ZRQAM1
                                RD/RX EXERCISER
                                                                                                                                    5-Dec-1983 10:27:14
                                                                                                                                                                                   VAX-11 Bliss-16 V3-555 Page 43
DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (32)
                                                                                                                                                                                    VAX-11 Bliss-16 V3-555
                                GLOBAL TEXT SECTION
V01.2
                                                                                                                                    5-Dec-1983 10:27:04
                                        CER_O1 = uplit (#asciz'#N#ADUPLICATE UNIT:#D2#A AT IP: #06')
                    3184
                    3185
                                        CER_O2 = uplit (#asciz'#N#AMORE THAN #D1#A DIFFERENT IP ADDRESSES').
                    3186
                    3187
                    3188
                              ! MESSAGE TYPES
                    3189
                                       EX_SEQ = UPLIT (#ASCIZ'#A- SEQUENTIAL'),

EX_CRD = UPLIT (#ASCIZ'#A- CREDIT NOTIFICATION'),

EX_MTN = UPLIT (#ASCIZ'#A- MAINTENANCE'),

EX_DGM = UPLIT (#ASCIZ'#A- DATAGRAM'),
                    3190
                    3191
                    3192
                    3193
                    3194
                    3195
                                ! commands
                    3196
                               !mscp
                    3197
                                        EX_RD = uplit (#esciz'#AREAD')
                    3198
                                        EX_WRT = uplit (#esciz'#AWRITE')
                    3199
                                        EX_ACC = uplit (#esc:z'#AACCESS')
                    3200
                                        EX_ONL = uplit (#esciz'#AON LINE')
                                        EX_SCC = uplit (#esciz'#ASET CONTROL CHAR.').
                    3201
                    3202
                                !dup
                    3203
                                        EX_GDS = uplit (#esciz'#AGET DUST STATUS').
                                        EX_ESP = uplit (#eeciz'#AEXECUTE SUPPLIED PRG'), EX_ELP = uplit (#eeciz'#AEXECUTE LOCAL PRG'),
                    3204
                    3205
                                       EX_SDD = uplit (#esciz'#ASEND DATA'),

EX_RCD = uplit (#esciz'#ARECEIVE DATA'),

EX_ABP = uplit (#esciz'#AABORT'),
                    3206
                    3207
                    3208
                    3209
                    3210
                                    ERROR/EVENT SUB CODES (PRINTX)
                    3211 !
                    3212
                                        SC_SDI = uplit (#eeciz'#ASPIN-DOWN IGNORED'), SC_CON = uplit (#eeciz'#ASTILL CONNECTED'),
                    3213
                    3214
                                         SC_DUP = uplit (#eeciz'#ADUPLICATE UNIT NUMBER'),
                    3215
                                         SC_ONL = uplit (#eeciz'#AALREADY ONLINE'),
                                       SC_ONL = uplit (#eeciz'#AALREADY ONLINE'),
SC_SON = uplit (#eeciz'#ASTILL ONLINE'),
SC_UNK = uplit (#eeciz'#AUNIT UNKNOWN OR ONLINE TO ANOTHER CTLR'),
SC_VOL = uplit (#eeciz'#AUNIT INOPERATIVE (RDS1 WRITE FAULT'),
SC_IOP = uplit (#eeciz'#AUNIT INOPERATIVE (RDS1 WRITE FAULT'),
SC_DIS = uplit (#eeciz'#AUNIT DISABLED BY FIELD SERVICE OR INTERNAL DIAGNOSTICS'),
SC_FER = uplit (#eeciz'#AFORCED ERR" DETECTED UMILE ACCESSING FCT OR RCT'),
SC_FE2 = uplit (#eeciz'#ASECTOR WRITTEN WITH "FORCED ERR" MODIFIER'),
SC_ISH = uplit (#eeciz'#AFCT OR RCT UNREADABLE - INVALID SECTOR HEADER'),
SC_IS2 = uplit (#eeciz'#AFCT OR RCT UNREADABLE - DATA SYNC TIMEOUT'),
SC_DS1 = uplit (#eeciz'#AFCT OR RCT UNREADABLE - DATA SYNC TIMEOUT'),
                    3216
3217
                    3218
                    3219
                    3220
3221
                    3222
                    3223
                    3224
                    3225
                                        SC_DS2 = uplit (#eeciz' #ADATA SYNC NOT FOUND (DATA SYNC TIMEOUT)'),
SC_ECC = uplit (#eeciz' #AFCT OR RCT UNREADABLE - UNCORRECTABLE ECC ERR'),
SC_ECD = uplit (#eeciz' #AUNCORRECTABLE ECC ERR'),
                    3226
                    3227
                    3228
                                        SC_ECD = uplit (#eeciz'#AUNCORRECTABLE ECC ERR'),
SC_RCT = uplit (#eeciz'#ARCT CORRUPTED'),
SC_FUL = uplit (#eeciz'#ANO REPLACEMENT BLOCK AVAILABLE (RCT FULL)'),
SC_576 = uplit (#eeciz'#ADISK NOT FORMATTED WITH 512 BYTE SECTORS'),
SC_FCT = uplit (#eeciz'#ADISK NOT FORMATTED OR FCT CORRUPTED'),
SC_EC1 = uplit (#eeciz'#AONE SYMBOL ECC ERR'),
SC_EC2 = uplit (#eeciz'#ATHOSYMBOL ECC ERR'),
                    3229
                    3230
                    3231
3232
3233
3234
                    3235
                                         SC_EC3 = uplit (#eeciz' #ATHREE SYMBOL ECC ERR'),
                                         SC_EC4 - uplit (#esciz'#AFOUR SYMBOL ECC ERR'),
```

```
SEQ 0044
ZRQAM1
                                 RD/RX EXERCISER
                                                                                                                                      5-Dec-1983 10:27:14
                                                                                                                                                                                      VAX-11 Bliss-16 V3-555
                                                                                                                                                                                                                                                                 Page
V01.2
                                GLOBAL TEXT SECTION
                                                                                                                                      5-Dec-1983 10:27:04
                                                                                                                                                                                     DISK$USER2: [DIETZ.RDRX]ZRQACO.BL1:82 (32)
                     3237
                                         SC_EC5 = uplit (#asciz' #AFIVE SYMBOL ECC ERR').
                    3238
                                         SC_EC6 = uplit (#asciz'#ASIX SYMBOL ECC ERR').
                     3239
                                         SC_EC7 - uplit (#asciz'#ASEVEN SYMBOL ECC ERR'),
                                        SC_EC8 = uplit (#asciz'#AEIGHT SYMBOL ECC ERR'),
SC_EC9 = uplit (#asciz'#ACORRECTABLE ERR IN ECC FIELD'),
SC_SWP = uplit (#asciz'#AUNIT SOFTWARE WRITE PROTECTED'),
SC_HWP = uplit (#asciz'#AUNIT HARDWARE WRITE PROTECTED'),
SC_ODA = uplit (#asciz'#AODD TRANSFER ADDRESS'),
                     3240
                     3241
                     3242
                    3243
                     3244
                    3245
                                         SC_ODB = uplit (#eeciz'#AODD BYTE COUNT'),
                                         SC_NXM = uplit (#esciz'#ANON-EXISTENT HOST MEMORY'),
                     3246
                     3247
                                         SC_PAR = uplit (#eeciz'#AHOST MEMORY PARITY ERR'),
                     3248
                                         SC_CTO = uplit (#aeciz'#ACOMMAND TIMOUT OR RETRY LIMIT EXCEEDED')
                     3249
                                         SC_SDS = uplit (#eeciz'#ASERIALIZER/DESERIALIZER OVERRUN OR UNDERRUN'),
                     3250
                                         SC_EDC = uplit (#eeciz'#AEDC ERR'),
                     3251
                                         SC_IDS = uplit (#eeciz'#AINCONSISTENT INTERNAL DATA STRUCTURE').
                                         SC_SRT = uplit ( #aeciz' #ADRIVE COMMAND TIMEOUT (NO RESPONSE OR SEEK INCOMPLETE)'),
SC_SRI = uplit ( #aeciz' #ACTLR DETECTED TRANSMISSION OR PROTOCOL ERR'),
SC_POE = uplit ( #aeciz' #APOSITION ERR (MIS-SEEK)'),
                     3252
                     3253
.
                    3254
3255
.
                                         SC_RDY = uplit (#eeciz'#ALOST READ/WRITE READY DURING/BETWEEN TRANSFERS'),
SC_CLK = uplit (#eeciz'#ADRIVE CLOCK DROPOUT'),
SC_RSP = uplit (#eeciz'#ALOST RECEIVER READY BETWEEN SECTORS'),
SC_SUR = uplit (#eeciz'#ADRIVE DETECTED ERR'),
                     3256
                     3257
                     3258
                     3259
                                         SC_PSP = uplit (#esciz'#ACTLR DETECTED PULSE OR STATE PARITY ERR').
                     3260
                     3261
                                ! MSCP END MESSAGE FLAGS
                     3262
                    3263 !F_O = uplit (#eeciz'#N#A) Bad Block Reported'),

3264 F_1 = uplit (#eeciz'#N#A ) Bad Block Unreported'),

3265 F_2 = uplit (#eeciz'#N#A ) Err Log Generated'),

3266 F_3 = uplit (#eeciz'#N#A ) Serious Exception'),
                    3266
3267
                    3267 ! MSCP Controller Flage
3268 F_4 = uplit (#esciz'#N#A) Enable Attention Messages'),
3269 F_5 = uplit (#esciz'#N#A) Enable Miscellaneous Err Log Messages'),
3270 F_6 = uplit (#esciz'#N#A) Enable Other Hosts Err Log Messages'),
3271 F_7 = uplit (#esciz'#N#A) Enable This Hosts Err Log Messages'),
3272 F_7 = uplit (#esciz'#N#A) Enable This Hosts Err Log Messages'),
                    3272 F_8 = uplit (#eeciz'#N#A) Ctlr Initiated Bad Block Rplcmnt'), 3273 F_9 = uplit (#eeciz'#N#A) Shadowing'),
                     3274 F_10 = uplit (#eeciz'#N#A) 576 Byte Sectors'),
                     3275
                     3276
                                ! MSCP UNIT FLAGS
                     3277
                   3277
3278 F_11 = uplit (#esciz'#NMA) Compare Reade'),
3279 F_12 = uplit (#esciz'#NMA) Compare Writes'),
3280 F_13 = uplit (#esciz'#NMA) Ctlr Initiated Bad Block Rplcmnt'),
3281 F_14 = uplit (#esciz'#NMA) Inactive Shadow Set Unit'),
3282 F_15 = uplit (#esciz'#NMA) Removable Media'),
3283 F_16 = uplit (#esciz'#NMA) Suppress Caching (high speed)'),
3284 F_17 = uplit (#esciz'#NMA) Suppress Caching (low speed)'),
3285 F_18 = uplit (#esciz'#NMA) Write-back (non-volatile)'),
3286 F_19 = uplit (#esciz'#NMA) Write Protect (hardware)'),
3287 F_20 = uplit (#esciz'#NMA) Write Protect (software or volume)'),
3288 F_21 = uplit (#esciz'#NMA) 576 Byte Sectors').
                     3288 F_21 = uplit (#esciz'#NWA) 576 Byte Sectors').
```

```
SEQ 0045
ZRQAM1
                     RD/RX EXERCISER
                                                                                     5-Dec-1983 10:27:14
                                                                                                                   VAX-11 Bliss-16 V3-555
                                                                                                                   VAX-11 Bliss-16 V3-555 Page 45
DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (32)
V01.2
                     GLOBAL TEXT SECTION
                                                                                     5-Dec-1983 10:27:04
             3290 ! DUP RETURN PACKET MESSAGES
             3291
                   ! STATUS CODE
                          EBH_30 = uplit (#asciz'#A - SUCCESS'),
EBH_44 = UPLIT (#ASCIZ'#A - INVALID COMMAND(SERVER nonIDLE or no media if EX-LC-PRG cmd)'),
             3292
             3293
3294
                          EBH_45 - UPLIT (#ASCIZ'#A - NO REGION AVAILABLE').
             3295
                                                            - NO REGION SUITABLE'),
                          EBH 46 = UPLIT (#ASCIZ'#A
             3296
                          EBH_47 = UPLIT (#ASCIZ'#A - PROGRAM NOT KNOWN (NO SUCH PROGRAM ON MEDIA)').
             3297
                          EBH_48 = UPLIT (#ASCIZ'#A - LOAD FAILURE (INPUT ERR WHILE LOADING PROGRAM)')
                          EBH_49 - UPLIT (#ASCIZ'#A - STANDALONE (STANDALONE MODIFIER NOT SPECIFIED FOR STAND ALONE PRG.)').
             3298
             3299
             3300
                    ! DUP GET DUST STATUS FLAGS
             3301
             3302
                          df_0 = uplit (#asciz'#N#A) One Server at a Time'),
                          df_1 = uplit (#asciz'#N#A) Contains Local Media'),
df_2 = uplit (#asciz'#N#A) Execute Local Prg cmd is UNSUPPORTED'),
             3303
             3304
             3305
                          df_3 = uplit (#asciz'#N#A) Currently in Active State'),
             3306
             3307
                     ! DUP EXECUTE LOCAL PRG END FLAGS
                          df_4 = uplit (#asciz'#N#A) Standalone Prg'),
df_5 = uplit (#asciz'#N#A) Needs overlay'),
df_6 = uplit (#asciz'#N#A) Needs Writeable/Readable Overlay')
             3308
             3309
             3310
                          df_7 = uplit (#esciz'#N#A) Uses Std Dup Dialog: REC/SEND/REC'),
             3311
             3312
             3313
                    ! DUP LOCAL PROGRAM PACKET MESSAGES
             3314
             3315
                          T_QUE = uplit (#asciz'#N#A ** QUESTION'),
             3316
                          T_DEF = uplit (#esciz'#N#A
                                                             ** DEFAULT QUESTION').
             3317
                          T_INF = uplit (#esciz'#N#A
                                                               ** INFORMATION').
             3318
                          T_TER = uplit (#esciz'#N#A
                                                              ** TERMINATION').
             3319
                          T_FAT = uplit (#esciz'#N#A
                                                              ** FATAL ERR').
                          T_SPL = uplit (#@@ciz'#N#A ** SPECIAL'),

E_SUC = UPLIT (#ASCIZ'#N#A - SUCCESS'),

E_UNT = UPLIT (#ASCIZ'#N#A - ILLEGAL UNIT NUMBER'),

E_BLK = UPLIT (#ASCIZ'#N#A - ILLEGAL PHYSICAL OR RELATIVE BLOCK NUMBER'),

E_DEV = UPLIT (#ASCIZ'#N#A - DEVICE ERR'),
             3320
             3321
             3322
             3323
                          E_DEV = UPLIT (#ASCIZ'#N#A - DEVICE ERR'),
E_ZER = UPLIT (#ASCIZ'#N#A - ZERO LENGHT MESSAGE'),
             3324
             3325
             3326
                          M_ASC = UPLIT (#ASCIZ'#N#A -- ASCII INFORMATION ')
             3327
                          M_BIN = UPLIT (#ASCIZ'#N#A --
                                                                 NON-ACSII INFORMATION').
             3328
                          M_TER - UPLIT (#ASCIZ'#N#A -- TERMINATION MESSAGE')
             3329
                          M_COD = UPLIT (#ASCIZ'#N#A -- SUCCESS/FAILURE CODE')
             3330
                          M_DAT - UPLIT (#ASCIZ' #N#A -- SEND BINARY DATA'),
                          M_UR = UPLIT (#ASCIZ'#N#A -- SEND UNIT NUMBER, RELATIVE DBN'),
M_URP = UPLIT (#ASCIZ'#N#A -- SEND UNIT NUMBER, RELATIVE DBN, WRITE PATTERN'),
M_UP = UPLIT (#ASCIZ'#N#A -- SEND UNIT NUMBER, PHYSICAL BLOCK NUMBER'),
M_UL = UPLIT (#ASCIZ'#N#A -- SEND UNIT NUMBER, LOGICAL BLOCK NUMBER'),
             3331
             3332
             3333
             3334
             3335
             3336
                       CONTROLLER GENERIC ERROR CODES
             3337
                          CNTR_ERR = uplit (
uplit (#aeciz'#ACTLR TIMEOUT'),
             3338
             3339
             3340
                                        uplit (#asciz' #AENVELOPE/PACKET READ ERR (PARITY OR TIMEOUT)').
             3341
                                        uplit (#esciz'#AENVELOPE/PACKET WRITE ERR (PARITY OR TIMEOUT)').
                                        uplit (#asciz' #ACTLR ROM AND RAM PARITY ERR'),
```

```
SEQ 0046
ZRQAM1
                     RD/RX EXERCISER
                                                                                      5-Dec-1983 10:27:14
                                                                                                                    VAX-11 Bliss-16 V3-555
                                                                                                                    VAX-11 Bliss-16 V3-555 Page 46
DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (32)
V01.2
                     GLOBAL TEXT SECTION
                                                                                      5-Dec-1983 10:27:04
                                        uplit (#asciz'#ACTLR RAM PARITY ERR'),
uplit (#asciz'#ACTLR ROM PARITY ERR'),
uplit (#asciz'#ARING READ ERR (PARITY OR TIMEOUT)')
             3343
             3344
             3345
             3346
                                         uplit (#esciz'#ARING WRITE ERR (PARITY OR TIMEOUT)'),
             3347
                                        uplit (#asciz'INTERRUPT MASTER FAILURE'),
                                        uplit (#eeciz'#AHOST ACCESS TIMEOUT (HIGHER LEVEL PROTOCOL DEPENDENT)'),
             3348
             3349
                                        uplit (#esciz'#ACREDIT LIMIT EXCEEDED'),
             3350
                                        uplit (#asciz'#AQ-BUS MASTER ERR').
             3351
                                        uplit (#esciz'#ACTLR FATAL ERR'),
             3352
                                        uplit (#asciz'#AINSTRUCTION LOOP TIMEOUT')
             3353
                                        uplit ( seciz' sAILLEGAL VIRTUAL CIRCUIT ID').
             3354
                                        uplit (#asciz'#AINTERRUPT VECTOR ILLEGAL').
                                        uplit (#asciz'#AMAINTENANCE READ/WRITE INVALID REGION IDENTIFIER'),
uplit (#asciz'#AMAINTENANCE WRITE LOAD TO NON-LOADABLE CTLR'),
             3355
             3356
                                        uplit (#asciz'#ACTLR RAM ERR (NON-PARITY)'),
uplit (#asciz'#AINIT SEQUENCE ERR'),
uplit (#asciz'#AHIGHER LEVEL PROTOCOL INCOMPATIBILITY ERR'),
uplit (#asciz'#APURGE/POLL HARDWARE FAILURE'),
             3357
             3358
             3359
             3360
             3361
                                        uplit (#eeciz'#AMAPPING REGISTER READ FAILURE (PARITY OR TIMEOUT)')) : vector [23].
             3362
             3363
                    ! RD/RX CONTROLLER DEPENDENT ERRORS CODES
             3364 !
             3365
                          RDRX_ERR = uplit (
             3366
                                        uplit (#esciz'#AT11 CPU FAILURE')
             3367
                                         uplit (#esciz' #ANON-PARITY RAM ERR').
             3368
3369
3370
                                         uplit ( Masciz' MASTATE MACHINE FAILURE - T11 ADDRESS REGISTER' )
                                         uplit ( seciz' sASTATE MACHINE FAILURE - Q-BUS ADDRESS REGISTER'),
                                        uplit (#esciz'#ASTATE MACHINE FAILURE - CRC REGISTER'),
uplit (#esciz'#ASTATE MACHINE FAILURE - SERIALIZER/DESERIALIZER REGISTER'),
uplit (#esciz'#ASTATE MACHINE FAILURE - WRONG HARDWARE VERSION')) : vector [7],
             3371
             3372
             3373
             3374
                    ! MISCELLANEOUS
             3375
             3376
                          EX_MRD = uplit (#asciz'#A #06')
             3377
                          EX_OP = uplit (#esciz'#Aoct #04').
             3378
                          SPACE4 = uplit (#eeciz'#$4'),
             3379
                          CRLF
                                      = uplit (#asciz'#N'),
= uplit (#asciz'#A - '),
             3380
                          DASH
             3381
                          ASTERISK = uplit (#asciz'#A+ ');
```

```
ZRQAM1
                        RD/RX EXERCISER
                                                                                                                                      VAX-11 Bliss-16 V3-555 Page 47 DISK*USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (33)
                                                                                                   5-Dec-1983 10:27:14
V01.2
                        DEFAULT HARDWARE P-TABLE
                                                                                                   5-Dec-1983 10:27:04
                3382 #sbttl 'DEFAULT HARDWARE P-TABLE'
                3383
                3384
                       THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF THE TEST-DEVICE PARAMETERS. THE STRUCTURE OF THIS TABLE IS IDENTICAL TO THE STRUCTURE OF THE HARDWARE P-TABLES. AND IS USED AS A "TEMPLATE" FOR BUILDING THE P-TABLES.
                3385
               3386
                3387
                3388
                3389
                3390
                3391
                        BGNHW (DFPTBL):
                3392
                3393
                        global
                              HMPT_IP_ADDR : word initial (INIT_IP_ADDR), ! IP ADDRESS
HMPT_VECTOR : word initial (INIT_INTR_VECT),! VECTOR ADDRESS
HMPT_BR_LEVEL : word initial (INIT_BR_LEVEL),!BR LEVEL
                3394
                3395
                3396
                              HMPT_DISK : word initial (%o'100034'),
                3397
                                                                                                  ! DISK NUMBER, TYPE, PROTECTON BIT
                              HWPT_S_TRK : word initial (0), HWPT_E_TRK : word initial (#0'177777');
                3398
                                                                                                  ! STARTING TRACK
                3399
                                                                                                  ! ENDING TRACK ACTUALLY THE PROGRAM WILL
                3400
                                                                                                  ! FIRGURE OUT MAXIMUM IN UNIT_INIT ROUTINE
                3401
:
                3402 ENDHW:
```

```
ZRQAM1
                  RD/RX EXERCISER
                                                                           5-Dec-1983 10:27:14
                                                                                                      VAX-11 Bliss-16 V3-555
                                                                                                      VAX-11 Bliss-16 V3-555 Page 48
DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (34)
V01.2
                  SOFTWARE P-TABLE
                                                                           5-Dec-1983 10:27:04
           3403 #sbttl 'SOFTWARE P-TABLE'
           3404
:
           3405
.
                 ! THE SOFTWARE TABLE CONTAINS VARIOUS DATA USED BY THE
           3406
           3407
                  PROGRAM AS OPERATIONAL PARAMETERS. THESE PARAMETERS ARE SET UP AT ASSEMBLY TIME AND MAY BE VARIED BY THE OPERATOR
           3408
           3409
                  ! AT RUN TIME.
           3410
           3411
           3412
                  BGNSW (SFPTBL):
           3413
           3414
                  global
           3415
3416
                       SWP_ERROR : word initial (32),
SWP_XFER : word initial (0),
                                                                          ! HARD ERROR LIMIT FOR DROPPING UNIT
                                                                          ! TRANSFER LIMIT FOR DROPPING UNIT
           3417
                       SWP_FLAGS : word initial (%o'1002'),
                                                                          ! FLAGS (SEE DOCUMENTATION)
           3418
                       SWP_DPAT : word initial (0).
                                                                          ! DATA PATTERN NUMBER
           3419
                       SWP_RAT : word initial (98),
                                                                          ! RD51 OPERATION RATIO
.
           3420
                       dupround : word initial (11),
                                                                          ! NUMBER OF DBN'S WRITTEN AT ONE TIME
           3421
                                                                         ! USER DATA PATTERN COUNT ! USER DATA PATTERN
                       SWP_UCNT : word initial (MAX_UDP_CNT),
           3422
                       SWP_UDPAT : vector [MAX_UDP_CNT, word];
           3423
           3424 ENDSW:
```

Page 49

```
ZRQAM1
                   RD/RX EXERCISER
                                                                                                        VAX-11 Bliss-16 V3-555
                                                                            5-Dec-1983 10:27:14
V01.2
                   PROTECTION TABLE
                                                                            5-Dec-1983 10:27:04
                                                                                                        DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (35)
            3425 #sbttl 'PROTECTION TABLE'
            3426
.
            3427
.
            3428 ! THIS TABLE IS USED BY THE RUNTIME SERVICES 3429 ! TO PROTECT THE LOAD MEDIA.
:
            3430 !-
            3431
                  BGNPROT (0, -1, 6);
            3432
.
            3433
.
                                     OFFSET INTO P-TABLE FOR CSR ADDRESS
OFFSET INTO P-TABLE FOR MASSBUS ADDRESS
OFFSET INTO P-TABLE FOR DRIVE NUMBER
            3434
                   !1ST ARG =
:
            3435
                   ! 2ND ARG =
:
                   : 3RD ARG =
            3436
:
            3437
.
            3438 ENDPROT:
:
            3439
                  end
.
            3440
.
            3441 eludom
:
                                                         .TITLE ZRQAM1 RD/RX EXERCISER
                                                         .IDENT /V01.2/
                                                         .ENABL AMA
000000
                                                         .PSECT
                                                                  *CODE *.
                                                                            RO
000000
                                               L$NAME::. ASCII
                      122
             132
                                121
                                                                  /ZRQ/
000003
             101
                                                         . ASCII
                                                                  /A/
000004
             000
                                                         .BYTE
000005
             000
                                                         .BYTE
000006
             000
                                                         .BYTE
000007
             000
                                                         .BYTE
000010
                                               L$REV::
000010
             103
000011
             060
                                                         . ASCII
                                                                  101
000012
         00000G
                                               L$UNIT::.WORD
                                                                  T$PTHV
000014
         077777
                                               L$TIML::.WORD
                                                                  77777
                                               L#HPCP::.WORD
L#SPCP::.WORD
L#HPTP::.WORD
000016
         00000G
                                                                  L$HARD
000020
         000000G
                                                                  L#SOFT
000022
         024532
                                                                  L$HW
000024
                                               L#SPTP::.WORD
L#LADP::.WORD
         0245521
                                                                  L#SW
000026
         000000G
                                                                  L$LAST
000030
         000000
                                               L#STA:: . WORD
000032
         000000
                                               L$CO:: .WORD
000034
000036
000040
         000001
                                               L#DTYP::.WORD
         000000
                                               L#APT:: .WORD
         000124
                                               L#DTP:: .WORD
                                                                  L#DISPATCH
000042
         000000
                                               L$PRIO::.WORD
000044
         000000
                                               L$ENVI::. WORD
                                                                  0
000046
000050
         000000
                                               L#EXP1::.WORD
                                                                  0
```

L#MREV::

L\$EF:: . WORD

.BYTE

0

000050

000051

000052 000000

003

003

			L4	
ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Page 50 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (35)
000056 000060 000062 000064 000066 000070 000072 000074 000100 000102 000104 000110 000112 000114 000116 000120 000120	000000 00000G 00000G 00000G 00000G 00000G 00000G 00000G 104035 000126' 00000G 00000G 00000G 024632' 00000G 024632' 000000 000000 000000	L\$SPC:: WORD O L\$DEVP:: WORD L\$DVTY L\$REPP:: WORD L\$RPT L\$EXP4:: WORD O L\$EXP5:: WORD O L\$AUT:: WORD L\$AU L\$DUT:: WORD L\$DU L\$LUN:: WORD L\$DU L\$LUN:: WORD L\$DESC L\$LOAD:: WORD -73743 L\$ETP:: WORD L\$ERRT L\$ICP:: WORD L\$INIT L\$CCP:: WORD L\$INIT L\$CCP:: WORD L\$PROT L\$PRT:: WORD L\$PROT L\$PRT:: WORD O L\$PRT:: WORD O L\$PRT:: WORD O L\$PROT:: WORD O L\$PROT:: WORD O	BL N	
000126 000130 000132 000134 000136 000141 000147 000152 000155 000160 000162 000165 000170 000173	111 120 040 101 104 104 122 105 123 123 000 000 126 105 103 124 117 122 000 000 102 122 040 114 105 126 105 114 000	ERRTYP::BLKW 1 ERRNBR::BLKW 1 ERRMSG::BLKW 1 ERRBLK::BLKW 1 P.AAA: ASCII /IP / ASCII /ADD/ ASCII /RES/ ASCII /S/<00 P.AAB: ASCII /VEC/ ASCII /TOR/ ASCII /ASCII /BR / ASCII /LEV/ ASCII /EL/<0	0>	
000174 000177 000202 000205 000210 000213 000216 000220 000223 000226 000231 000234	000 122 104 057 122 130 040 104 122 111 126 105 040 116 125 115 102 105 122 000 000 123 124 101 122 124 111 116 107 040 114 102 116 000 000	P.AAD: ASCII <00> ASCII /RD/<5 .ASCII /RX / .ASCII /DRI/ .ASCII /VE / .ASCII /NUM/ .ASCII /BER/ .ASCII /STA/ .ASCII /RTI/ .ASCII /LBN/ .ASCII <00><0	0>	
000236 000241 000244 000247	105 116 104 111 116 107 040 114 102 116 040 050	P.AAF: .ASCII /END/ .ASCII /ING/ .ASCII / LB/ .ASCII /N (/		

ZRQAM: VO1.2	1	RD/RX EX					5-Dec-1983 5-Dec-1983	VAX-11 Bliss-16 V3-555 SEQ 0051 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
000253 000263 000263 000263 000273 000273 000303 000313 000313 000323 000323 000323 000333 000333 000334 000343 000343 000353 000373 000373 000373 000403 00	111 115 040 130 072 071 040 065 040 065 067 071 127 124 117 103 124 1105 1111 104 1113 052 1115 040 1111 105 107 107 108 1115 107 108 1117 1117 1117 1117 1117 1117 1	101 115 040 040 065 040 071 122 061 062 071 040 071 051 122 105 116 125 117 124 123 111 040 105 117 124 123 111 040 105 111 111 040 105 111 111 101 112 105 116 127 124 116 127 124 116 127 124 127 124 127 128 128 129 129 129 129 129 129 129 129 129 129	130 125 055 122 060 067 054 104 072 061 071 122 062 064 071 000 111 040 040 123 115 040 124 101 116 110 040 123 115 040 124 101 116 117 122 116 055 117 122 104 040 105 115 040 115 115 116 117 117 117 118 119 119 119 119 119 119 119 119 119	P.AAH:	ASCIII AS	/MAX/ /MU/ /M -/ /RO/ /SO/ /SO/ /SO/ /SO/ /SO/ /SO/ /SO/ /SO/ /CUS/ /ON/ /CUS/	0>	

ZRQAM1	RD/RX EXERCISER		5 Dec 1007	10.07.14	SEQ 0052
V01.2	PROTECTION TABLE		5-Dec-1983 5-Dec-1983		VAX-11 Bliss-16 V3-555 Page 52
	THOTECTION TABLE		3-0ec-1963	10:27:04	DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
000507	122 103 111	.ASCII /R	CI/		
000512	123 105 040	.ASCII /S	E /		
000515	117 116 040	.ASCII /C	N /		
000520	104 111 101	.ASCII /C	IA/		
000523	107 116 117	.ASCII /G	NO/		
000526	123 124 111	.ASCII /S	TI/		
000531	103 040 101	.ASCII /C	A/		
000534 000537	122 105 101		EA/		
000542	040 050 055 116 117 116	.ASCII /	(-/		
000545	116 117 116 055 103 125	ASCII	ON/		
000550	123 124 117	ASCII /S	CU/ TO/		
000553	115 105 122	ASCII /	ER/		
000556	040 101 122	.ASCII /	AR/		
000561	105 101 040	.ASCII /E	A /		
000564	122 104 163	.ASCII /F	Ds/		
000567	040 117 116	.ASCII /	ON/		
000572	114 131 051	.ASCII /L	Y)/		
000575	000	.ASCII «C	0>		
000576	127 122 111	P.AAJ: .ASCII /	RI/		
000601	124 105 040 117 116 040	.ASCII /1	E /		
000604 000607	104 111 101	ASCII /	N /		
000612	107 116 117	ASCIT /	NO/		
000615	123 124 111	ASCII /S	TI/		
000620	103 040 101	.ASCII /C	A/		
000623	122 105 101	ASCII /F	EA/		
000626	000 000		0><00>		
000630 000633	110 101 122	P.AAK: .ASCII /	AR/		하다 내 내가 내가 되었다. 이번 시간 그 전 경에는 이 유민 없었다.
000636	104 040 105 122 122 117	.ASCII /C	E/ RO/		
000641	122 040 114		L/		
000644	111 115 111	ASCII /I	MI/		
000647	124 000 000		/<00><00>		
000652	124 122 101	P.AAL: .ASCII /1	RA/		
000655	116 123 106	.ASCII /N	ISF/		
000660 000663	105 122 040	.ASCII /E	R /		
000566	114 111 115 111 124 040	ASCII /L	IM/		
000671	111 124 040 111 116 040	.ASCII /I	T /		
000674	115 105 107	ASCII /	EG/		
000677	101 102 131	.ASCII //	BY/		
000702	124 105 123	.ASCII /1	ES/		
000705	040 050 060	.ASCII /	(0/		
000710 000713	040 146 157	.ASCII /	fo/		
000716	162 040 042 121 125 111		"/		
000721	121 125 111 103 113 040	ASCII /	UI/		
000724	120 101 123	ASCII /F	AS/		
000727	123 042 051	.ASCII /S	")/	,	
000732	000 000	.ASCII <	0><00>		
000734	122 101 116 104 117 115	P.AAM: .ASCII /F	AN/		
000737	104 117 115	.ASCII /	OM/		

7000M1	DD /DV EX	VEDCTCED			F D 1007		SEQ 0053
ZRQAM1 VO1.2		KERCISER ION TABLE			5-Dec-1983 5-Dec-1983	10:27:14	VAX-11 Blies-16 V3-555 Page 53
*****	PROTECT	TON THOLE			3.0ec.1402	10:27:04	DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
000742	040 125	116	.ASC	II / UN/			
000745	111 124	040	. ASC	II /IT /			
000750	115 117	104	. ASC	II /MOD/			
000753	105 000	000	. ASC	II /E/<00>	<00>		
000756	122 105	101	P.AAN: .ASC	II /REA/			
000761	104 055	103	.ASC	II /D-C/			
000764	117 115	120	. ASC	II /OMP/			
000767	101 122	105	. ASC	II /ARE/			
000772	123 040	120	. ASC	II /S P/			
000775	105 122	106	. ASC	II /ERF/			
001000	117 122	115	. ASC	II /ORM/			
001003	105 104	040	. ASC	II /ED /			
001006	101 124	040	. ASC	II /AT /			
001011	124 110	105	. ASC	II /THE/			
001014	040 103	124	. ASC	II / CT/			
001017	114 122	000	. ASC	II /LR/<00	>		
001022	127 122	111	P.AAO: .ASC	II /WRI/			
001025	124 105	055	. ASC	II /TE-/			
001030	103 117	115	. ASC	II /COM/			
001033	120 101	122	. ASC	II /PAR/			
001036	105 123	040	. ASC	II /ES /			
001041	120 105	122	. ASC	II /PER/			
001044	106 117	122	.ASC	II /FOR/			
001047	115 105	104	.ASC	II /MED/			
001052	040 101	124	.ASC	II / AT/			
001055 001060	040 124	110	.ASC	II / TH/			
001063	105 040 124 114	103	.ASC	II /E C/			
001066	124 114 000 000	122	.ASC	II /TLR/			
001070	103 110	105	P.AAP: .ASC	II <00><00	,		
001073	103 113	040	.ASC	II /CK /			
001076	101 114	114	ASC	II /ALL/			
001101	040 127	122	.ASC	II / WR/			
001104	111 124	105	ASC	II /ITE/			
001107	123 040	101	.ASC	II /S A/			
001112	124 040	110	. ASC	11 /T H/			
001115	117 123	124	. ASC	II /OST/			상의 물로 보기 때문에 가는 사람들이 되는 것이 모든 살아가지 않아 되었다.
001120	040 102	131	. ASC	II / BY/			
001123	040 122	105	. ASC	II / RE/			
001126	101 104	111	.ASC P.AAQ: .ASC	II /ADI/			
001131	116 107	000	. ASC	II /NG/<00	>		
001134 001137	125 123 122 055	105	P.AAQ: .ASC	II /USE/			
001137	122 055	104	. ASC	II /R-D/			
001142	105 106	111	. ASC	II /EFI/			HONOR
001145 001150	116 105	104	. ASC	II /NED/			
001153	040 104	101	. ASC . ASC . ASC	II / DA/			
001156	124 101 120 101	040	. ASC	II /TA/			
001161		124 122	. ASC	II /PAT/			
001164	124 105 116 000	155	. ASC	II /TER/			
001166	123 105	114	P.AAR: .ASC	II /N/<00>			사람들이 가장 그 경기 이 보는 것이 되었다. 그리고 사용하다 하지 않아 보다 되었다. 그 나를 다 없다고 있다.
001171	105 103	124	.ASC	II /SEL/			유민이 얼마 얼마 얼마 나는 아이들이 되었다. 그는 그 그 그 그 그 그 그 그 그 그 그 그 그 그 그 그 그 그
001174	040 120	122	ASC	II / PR/			일 병과 부모에 가는 사람들이 가는 것 같아요. 그리아를 받는 것을 다니다.

ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.	SEQ 0054 Page 54 BL1:82 (35)
001177 001202 001205 001210 001213 001216 001221 001224 001227 001232 001235 001240 001243 001246 001251 001254 001262 001264 001267 001272 001272 001275 001300 001303 001306 001311 001314 001317 001322 001325 001335 001336 001341 001342 001345 001350 001353 001366 001371 001374 001377 001402 001405 001410 001413 001416 001421	105	. ASCI .	I /EFI/ II /NED/ II /DA/ II /DA/ II /PAT/ II /O F/ II /O		DISK VOSEKS; [DIE12, NONA ) ZNIGHCO.	
001424 001427	111 116 107	. ASCI	II /ING/			

ZRQAM1 VO1.2	RD/RX EXERCISE PROTECTION TAE			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Page 55 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
001430 001433 001436 001441 001444 001447 001452 001455 001460 001463 001466 001471 001474 001477	120 105 122 103 105 116 124 101 107 105 040 117 106 040 127 111 116 103 124 105 123 124 105 122 040 117 126 124 111 117 116 123 040 117 125 124 040 117 106 040 124 117		.ASCII /PER/ .ASCII /CEN/ .ASCII /TAG/ .ASCII /E O/ .ASCII /F W/ .ASCII /INC/ .ASCII /HES/ .ASCII /TER/ .ASCII / OP/ .ASCII / ERA/ .ASCII / TIO/ .ASCII / NS / .ASCII / OF/ .ASCII / OF/ .ASCII / TO/		
001505 001510 001513 001516 001521 001524 001527 001532 001535 001540 001543 001546 001551	124 101 114 040 117 120 105 122 101 124 111 117 116 123 000 122 101 116 104 117 115 040 102 114 117 103 113 040 115 117 104 105 000 116 125 115 102 105 122 040 117 106	P.AAW:	ASCII /TAL/ ASCII / OP/ ASCII / OP/ ASCII /ERA/ ASCII /TIO/ ASCII /NS/<00 ASCII /RAN/ ASCII /DOM/ ASCII / BL/ ASCII / OCK/ ASCII / MO/ ASCII / DE/<00 ASCII /NUM/ ASCII / BER/ ASCII / OF/ ASCII / DB/		
001557 001562 001565 001570 001573 001576 001601 001604 001607 001612 001615	040 104 102 116 163 040 124 122 102 116 123 106 105 122 122 105 104 040 101 124 040 117 116 105 040 042 104 125 120 042 040 120 102		ASCII /Ne / ASCII /TRA/ ASCII /NSF/ ASCII /ERR/ ASCII /ED / ASCII /AT / ASCII /ONE/ ASCII / "D/ ASCII / "D/ ASCII / PA/ ASCII / SS/<00		
001623 001624 001627 001632 001635 001640 001643 001646 001651 001654 001657	123 123 000 124 110 105 040 122 105 115 101 111 116 111 116 107 040 125 125 105 125 124 111 117 116 123 040 117 116 114 131 040 105 120 120 114		ASCII (00) ASCII /THE/ ASCII / RE/ ASCII / RE/ ASCII /MAI/ ASCII /NIN/ ASCII /G Q/ ASCII /UES/ ASCII /TIO/ ASCII /NS / ASCII /ONL/ ASCII /Y A/ ASCII /PPL/		

ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	V/Y-11 Bliss-16 V3-555
001665 001670 001673 001676 001701 001704 001707 001712 001714 001716 001721 001724 001727 001732 001735 001740 001743 001744 001747 001752 001755 001760 001763 001766 001771 001774 001777 001777 001777	131 040 124 117 040 125 116 120 122 117 124 105 103 124 105 104 040 104 111 123 113 123 000 000 000 045 116 045 101 052 052 040 104 122 117 120 040 125 116 111 124 040 045 104 062 000 000 045 116 045 101 052 052 040 120 122 117 103 137 122 105 124 120 113 124 072 040 103 117 116 116 040 075 040 045 104 065 045 104 065 045 101 040 122 105 103 117 116 116 040 075 040 045 104 065 045 101 040 122 105 103 105 111 126	P.AAZ: .ASCII <00 P.ABA: .ASCII /#N .ASCII /A* .ASCII / D .ASCII / DP .ASCII / A* .ASCII / PP .ASCII / PP .ASCII / PP .ASCII / DP	U/ R/ E/ E/ D/ K/ <00> */ */ */ */ */ */ */ */ */ */ */ */ */	
002021 002022 002025 002030 002033 002036 002041 002044 002047 002052 002055 002060 002063 002066 002070 002073	000 045 116 045 101 052 052 040 106 124 114 040 105 122 122 072 040 122 105 124 120 113 124 040 116 117 124 040 101 126 101 111 114 101 102 114 105 000 000	P.ABC: ASCII <00 ASCII /AA ASCII /AA ASCII / F ASCII / F ASCII / R ASCII / R ASCII / T ASCII / AV ASCII / BL ASCII <00	#/ T/ E/ :/ E/ K/ N/ / A/ A/ E/ ><00>	
002070 002073 002076 002101 002104 002107 002112	045 116 045 101 052 052 040 106 123 105 124 137 125 120 101 122 072 040 103 101 116	ASCII /BL ASCII /AN ASCII /AN ASCII /AN ASCII /AN ASCII /F ASCII /F ASCII /LT ASCII /LT ASCII /CA	Š/ Ā/	

ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555
V01.2  002115 002120 002123 002126 002131 002134 002137 002142 002145 002150 002153 002154 002157 002162 002165 002170 002173 002176 002201	PROTECTION TABLE  047	ASCII	5-Dec-1983 10:27:04  /'T / /FIN/ /D D/ /ISK/ / **D/ /3**A/ / IN/ / CS/ /T **/ /D1/<00> <00> /*N#/ /A**/ / BA/ / D C/ /ONN/ / ID/ / ** / ** / ** / ** / ** / ** / ** /	VAX-11 Bliss-16 V3-555 Page 57
002207 002212 002215 002220 002223 002226 002231 002232 002235 002240 002243 002246 002251 002254 002257	105 104 040 106 122 117 115 040 045 117 066 000 000 045 116 045 101 052 052 040 115 105 123 123 101 107 105 040 124 131 120 105 040 045 104 062 045 101 040 122	P.ABF: ASCII	/ED / /FRO/ /M %/ /06/<00> <00> /#N%/ /A**/ / ME/ /SSA/ /GE / /TYP/ /E %/ /D2%/ /A R/	
002265 002270 002273 002276 002301 002304 002307 002312 002314 002317 002322 002325 002330 002333 002336 002341	105 103 105 111 126 105 104 040 111 116 040 115 123 103 120 040 120 101 103 113 105 124 000 045 116 045 101 052 052 040 105 122 122 040 111 116 040 123 105 124 137 103 124 114 122 137 103 110 101 122	ASCII	/ECE/ /IVE/ /D I/ /N M/ /SCP/ / PA/ /CKE/ /T/<00> /#N#/ /A++/ / ER/ /R I/ /N S/ /ET_/ /CTL/ /R_C/ /HĀR/	

ZRQAM VO1.2			XERCISER ION TABLE				5-Dec-1983 5-Dec-1983	VAX-11 Bliss-16 V3-555 Page 58 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
00234	0 045	116	045	P.ABH:	.ASCII	<00>		
00235 00235	6 040	052 103	052 124		.ASCII	/A++/		
00236 00236	1 114 4 124	122	040 115		.ASCII	/LR /		
00236	7 105	117	125		. ASCII	/EOU/		
00237	2 124 5 040	040 045	075 104		.ASCII	/T =/		
00240	0 063	045	101		. ASCII	/3#A/		
00240	6 103	123 117	105 116		.ASCII	/ SE/		
00241	1 104	123	000	D 407	. ASCII	/DS/<00>		
00241	7 101	116 052	045 052	P.ABI:	.ASCII	/SNS/		
00242	2 040	105 040	122		. ASCII	/ ER/		
00243	0 116	040	125		.ASCII	/R I/ /N U/		
00243 00243	3 116 6 137	111	124 116		. ASCII	/NIT/ /_IN/		
00244	1 111	124	000		. ASCII	/IT/<00>		
00244	7 101	116 052	045 052	P.ABJ:	.ASCII	/#N#/ /A++/		
00245 00245	2 040	101	103		. ASCII	/ AC/		
00246	0 123	105 072	123 040		.ASCII	/CES/ /S:/		
00246 00246	3 122	105	124		.ASCII	/RET/		
00247	1 040	113 110	124 101		.ASCII	/PKT/		
00247	4 123 7 101	104	102 040		.ASCII	/S B/		
00250	2 105	116	104		. ASCII	/END/		
00250 00251	5 103 0 105	117	104		.ASCII	/COD/ /E/<00>		
00251 00251	2 045	116	045	P.ABK:	. ASCII	/SNS/		
00252	5 101	052 111	052 114		.ASCII	/A++/		
00252	3 114 6 101	105 114	107		. ASCII	/LEG/		
00253	1 106	125	116		.ASCII	/AL /		
00253	4 103 7 117	124 116	072		. ASCII	/CTI/		
00254	2 040	045	117		.ASCII	/ \$0/		
00252 00252 00253 00253 00253 00254 00255 00255 00255 00256 00256	5 066 0 045	000 116	000 045	P.ABL:	.ASCII .ASCII .ASCII	/6/<00><	00>	
00255	3 101 6 040	052	052		. ASCII	/A++/		
00256	1 115	103	117		.ASCII	/ CO/		
00256	4 116 7 122	104 105	040 106		.ASCII	/ND / /REF/		
00257	2 040	043	040		.ASCII	101		
00257	5 045 0 045	104	065 056		.ASCII	/#D5/		
			030		, HJULL	/ =n./		

ZRQAM1 VO1.2		XERCISER ION TABLE				5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555
002603 002606 002611 002614 002617 002622	040 116 124 040 105 116 040 102 040 110 123 124	117 123 124 131 117		.ASCII / .ASCII / .ASCII / .ASCII /	NO/ T S/ ENT/ BY/ HO/ ST/<00>		
002622 002625 002626 002631 002634 002637 002642 002645 002650 002653	000 045 116 101 052 040 125 113 116 127 116 105 122 117 122 114 117 040 106	045 052 116 117 040 122 040 107	P.ABM:	ASCII / ASCII / ASCII / ASCII / ASCII / ASCII / ASCII / ASCII /	00> 25N5/ 2644/ UN/ KNO/ WN / ZERR/ COR / LOG/		
002661 002664 002667 002672 002675 002700 002703 002706 002711	122 115 124 040 104 063 101 056 122 105 105 111 105 104 045 116 101 052	101 045 045 040 103 126 000 045	P.ABN:	.ASCII / .ASCII / .ASCII / .ASCII / .ASCII / .ASCII / .ASCII /	RMA/ 'T #/ 'D3#/ 'A. / 'REC/ 'EIV/ 'ED/<00> 'A++/		
002714 002717 002722 002725 002730 002733 002736 002741	040 105 122 117 055 114 107 040 101 126 040 101 105 101 106 125	052 122 122 117 123 105 122 040 114		.ASCII / .ASCII / .ASCII / .ASCII / .ASCII / .ASCII / .ASCII /	CER/ CROR/ C-LO/ CAVE/ CAVE/ CAR/ CFUL/		
002744 002746 002751 002754 002757 002762 002765 002770 002773	114 000 045 116 101 052 040 104 120 072 120 113 040 116 124 040 126 101	045 052 125 040 124 117 101	P.ABO:	.ASCII / .ASCII / .ASCII / .ASCII / .ASCII / .ASCII / .ASCII /	/L/<00> /dN#/ /A++/ / DU/ /P: / /PKT/ / NO/ /T A/		
002776 003001 003004 003007 003012 003015 003020 003023 003026	114 101 114 105 045 116 101 125 111 124 104 062 101 040 122 117 120 105	102 000 045 116 045 045 104 120 104	P.ABP:	.ASCII / .ASCII / .ASCII / .ASCII / .ASCII / .ASCII / .ASCII /	LAB/ LE/<00> MM/ AUN/ ITS/ D2S/ A D/ ROP/		
003031 003034	040 055 000 000	040		.ASCII /	PED/ 00><00>		

-	ZRQAM1		XERCISER				5-Dec-1983 10:27	:14 V	AX-11 Bliss-16 V3-555 SEQ 0060	,
ŀ	V01.2	PROTECT	ION TABLE				5-Dec-1983 10:27:	:04 D	ISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)	
	003036 003041 003044	045 101 123 105 040 103	125 122 115	P.ABR:	.ASCII .ASCII .ASCII	/#AU/ /SER/ / CM/				
-	003047 003052	104 045 000 000	116		.ASCII	<00><00>				
	003054 003057 003062	045 101 117 116	103 106	P.ABS:	.ASCII	/#AC/				
-	003065 003070	111 107 122 101 111 117	125 124 116		.ASCII .ASCII .ASCII	/IGU/ /RAT/ /ION/				
-	003073 003076	040 105 122 045	122		.ASCII .ASCII .ASCII	/ ER/				
	003101 003102	000 045 101	111	P.ABT:	. ASCII	<00>				
	003105 003110	116 111 040 105	124 122		.ASCII	/NIT/ / ER/				
-	003113 003116 003120	122 045 000 000 045 101	116	D. ADII.	.ASCII	/R#N/				
-	003123 003126	045 101 122 101 123 106	124 116 105	P.ABU:	.ASCII .ASCII .ASCII .ASCII	/#AT/ /RAN/ /SFE/				
A CHARLES AND	003131 003134	122 040 111 115	114		ASCII	/R L/ /IMI/				
-	003137 003142	124 040 105 101	122 103		.ASCII	/T R/ /EAC/				
-	003145 003150	110 105 045 116	104		.ASCII	/MED/ /MN/<00>				
-	003153 003154 003157	000 045 101 122 122	105 040	P.ABV:	.ASCII .ASCII .ASCII	<00> /≰AE/ /RR /				
	003162 003165	114 111 111 124	115		ASCII ASCII ASCII	/LIM/				
and the same of	003170 003173	122 105 103 110	101		.ASCII	/REA/ /CHE/				
-	003176 003201	104 045	116		.ASCII	/D≤N/ <00>				
-	003202	045 101 116 122	125 105	P.ABW:	.ASCII	/#AU/ /NRE/				
-	003213 003216	103 117 105 122 102 114 040 104 126 040	126 101 105 105		ASCII ASCII ASCII ASCII ASCII ASCII	/COV/ /ERA/ /BLE/				
	003221 003224	040 104 126 040	105		.ASCII	/ DE/				
-	003227	116 000	105 045		.ASCII .ASCII .ASCII	/RR#/ /N/<00>				
	003202 003205 003210 003213 003216 003221 003224 003227 003232 003234 003237 003242 003245 003250 003250 003250	045 101 116 122 103 117 105 122 102 114	125 105	P.ABX:	.ASCII	/WAU/				
	003245 003250	105 122 102 114	126 101 105		.ASCII .ASCII .ASCII	/COV/ /ERA/ /BLE/				
-	003253 003256	040 103	124 040		.ASCII .ASCII .ASCII .ASCII	/ CT/				
-	003261	114 122 105 122	122		.ASCII	/ERR/				

-	ZRQAM1 VO1.2		RD/RX EXE					5-Dec-1983 5-Dec-1983	10:27:14 10:27:04	VAX-11 Bliss-16 V3-555 Page 61 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
Company (see	003264	045	116	000		.ASCII	/#N/<00>			
-	003267	000				.ASCII	<00>			어느 이 이 개막되는 보고 있다면 하는 사람이 되었다면 하다면 하는데 하는데 다른데
1	003270	045	101	106	P.ABY:	. ASCII	/MAF/			그런 그렇게 되는 아이를 하는 것이 하는 것이 하는 것이 없는 것이 없다.
1	003273	101	111	114		.ASCII	/AIL/			[설명 등 역사 : 보통도 16 P. 10 P.
1	003276	105	104	040		ASCII	/ED /			
1	003301	124	117	040		ASCIT	/TO /			
1		107	117			.ASCII				
1	003304	103	117	115		. ASCII	/COM/			
	003307	105	040	117		.ASCII	/E 0/			
	003312 003315	116	114	111		. ASCII	/NLI/			
1	003315	116	105	045		. ASCII	/NE#/			연극이 많아 먹는 점점 등이 가고 들었다면 하다 먹는 것이 되었다면 하나 없었다.
	003320	116	000			. ASCII	/N/<00>			
1	003322	045	101	106	P.ABZ:	. ASCII	/SAF/			[2] 1 : [1] [1] [1] [1] [2] [2] [2] [2] [2] [2] [2] [2] [2] [2
1	003325	101	111	114		. ASCII	/AIL/			
	003330	105	104	040		.ASCII	/ED /			
	003333	124	117	040		. ASCII	/TO /			병원 회사 회사 이 교통 사람이 하나 가장 얼마나 하는 것이 없는데 하다 되었다.
ì	003336	101	103	103		ASCIT	/ACC/			
1	003341	105	123	123		.ASCII	/ESS/			
1	003344	040	114	101		ASCII				
1	003347	128	124			. MSCII	/ LA/			
1	003347	123	124	040		.ASCII .ASCII .ASCII	/ST /			
1	003352	124	122	101		. ASCII	/TRA/			
1	003355	103	113	040		.ASCII	/CK /			
1	003360 003363	104	125	122		.ASCII	/DUR/			
	003363	111	116	107		. ASCII	/ING/			시 그 그 이 없는 그리아 아래 아래 아래 장마의 보고 있는 어디를 내려 있다. 뭐하다
	003366	040	111	116		.ASCII .ASCII .ASCII	/ IN/			
	003371 003374	111	124	045		. ASCII	/ITS/			
	003374	116	000			.ASCII	/N/<00>			
	003376	045	101	104	P.ACA:	.ASCII	/#AD/			
İ	003401	111	123	113		ASCII	/ISK/			
1	003404	040	127	122		ASCII	/ WR/			
1	003407	111	124	105		ASCII	/ITE/			
	003412	040	120	122		ASCII	1001			
	003415	117	120			.ASCII	/ PR/			
	003420	103	124	105		. MSCII	/OTE/			
	003423		124	105		.ASCII	/CTE/			
	003423	104	045	116		.ASCII	/DEN/			그 그 그 그는 그들이 가장 가장하다. 이 경기가 되었다고 있다고 있다.
1	003426	000	000			.ASCII	<00><00>			네 이 그리고 보고 하는 사람들은 사용하는 것으로 되는 것 같아요?
1	003430	045	101	103	P.ACB:	. ASCII	/SAC/			
	003433	115	104	040		. ASCII	/MD /			
minute of the last	003436	124 105	111	115		. ASCII	/TIM/			
1	003441	105	040	117		.ASCII .ASCII .ASCII	/E 0/			
	003444 003447 003452 003455 003460	125 116	000	045		.ASCII	/UTS/			
	003447	116	000	000		. ASCII	/N/<00><	00>		
	003452	045	101	000 125	P.ACC:	ASCIT	/SAU/			
	003455	116	111	124		ASCIT	/NIT/			
1	003460	040	127	105		ASCIT	/ WE/			
i	003463	116	127 124 117 126 114	040		.ASCII .ASCII .ASCII .ASCII .ASCII	/NT /			
1	003466	116 124	117	040		ASCIT	/TO /			
	003471	101	126			ASCIT	/TO /			
-	003474	111	114	101		ASCIT	/AVA/			
-	003477	102	117	101		. MSCII	/ILA/			
	003502	102	114	105		. ASCII	/BLE/			
1	003502	040	123	124		. ASCII	/ ST/			
1	003505	101	124 116	105		.ASCII .ASCII .ASCII	/ATE/			
*	003510	045	116	000		. ASCII	/#N/<00>			
	003513	000				.ASCII	<00>			[1]

							1/2		
ZRQAM1 VO1.2		RD/RX EXE PROTECTION					5-Dec-1983 5-Dec-1983	10:27:14 10:27:04	VAX-11 Bliss-16 V3-555 Page 62 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
003514 003516 003520 003522 003524 003526 003530 003532	003036' 003054' 003102' 003120' 003154' 003202' 003234' 003270'			P.ABQ:	. WORD . WORD . WORD . WORD . WORD . WORD . WORD	P.ABR P.ABS P.ABU P.ABV P.ABW P.ABX P.ABY P.ABZ			
003536 003540 003544 003547 003552 003555 003560 003563	003376' 003430' 003452' 045 101 127 040 114 040 127	116 120 105 104 101 055	045 117 122 105 131 040 111	P.ACD:	.ASCII .ASCII .ASCII	P.ACA P.ACB P.ACC /MNM/ /APO/ /WER/ / DE/ /LAY/ /WAI/			
003571 003574 003576 003601 003604 003607 003612 003615 003620 003623	124 107 045 101 116 111 101 124 124	111 000 116 106 103 117 114 105 040	116 045 125 124 116 040 123 123 123	P.ACE:	.ASCII .ASCII .ASCII .ASCII .ASCII	/TIN/ /G/<00> /MNM/ /AFU/ /NCT/ /ION/ /AL / /TES/ /T S/ /TAR/			
003626 003631 003632 003635 003640 003643 003646 003651	124 000 045 116 105 122 123 040 101	105 116 045 130 103 105 123 122	104 045 101 105 111 122 124 124 045	P.ACF:	ASCII ASCII ASCII ASCII ASCII ASCII ASCII ASCII ASCII	/TED/ <00> /MMA/ /EXE/ /RCI/ /SER/ / ST/ /ART/			
003657 003662 003664 003667 003672 003675 003700 003703 003706	105 116 045 116 125 040 113 070 043 106	104 000 116 045 116 104 045 045 040	045 101 124 123 123 101 117 040	P.ACG:	.ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII	/ED#/ /N/<00> /#N#/ /N#A/ /UNT/ / DS/ /K#S/ /8#A/ /# 0/ /F /			
003714 003717 003722 003725 003730	040 102 105 040 040	043 131 123 040 117	040 124 040 043 106		ASCII ASCII ASCII ASCII	/BYT/ /ES / / e/ / OF/			

 ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE	5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Page 63 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
003733 040 003741 102 003747 000 003750 045 003753 040 003756 110 003761 104 003767 122 003767 122 003772 055 004000 106 004003 105 004006 117 004011 055 004017 101 004022 040 004025 043 004030 124 004030 124 004030 124 004030 124 004030 124 004030 124 004030 124 004030 124 004030 124 004030 124 004031 104 004044 040 004047 040 004055 040 004066 040 004066 040 004066 040 004066 040 004071 122 004066 040 004066 040 004071 122 004111 101 004114 104 004117 040 004130 104 004130 104 004131 124 004131 125 004131 126 004131 126	040 040		DISK#USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
004163 055	040 040 .ASC	I /- /	

			113	
ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE		5-Dec-1983 10:27:14 VAX-11 Blies-16 V3-555 5-Dec-1983 10:27:04 DISK\$USER2:[DIETZ.RDRX]ZRG	SEQ 0064 Page 64 PACO.BL1;82 (35)
V01.2  004166 004171 004174 004177 004202 004205 004210 004213 004216 004221 004224 004227 004232 004235 004240 004240 004251 004254 004257 004262	055         055         055           055         055         040           040         055         055           055         055         055           055         055         055           055         055         055           055         055         055           055         055         040           040         055         055           055         055         055           055         055         055           055         055         055           055         055         055           040         055         055           055         040         055           055         055         040           055         055         055           040         055         055           040         055         055           040         055         055           055         040         055           055         055         055           040         055         055           055         055         055           055         055         055	P. ACL:	5-Dec-1983 10:27:04 DISK\$USER2:[DIETZ.RDRX]ZRG  ASCII //	ACO.BL1;82 (35)
004262 004265 004270 004273 004276 004301 004304 004307 004312 004315 004320 004323 004326 004331	055 055 040 055 055 055 040 055 055 055 000 000 045 116 045 104 062 045 104 064 045 101 040 040 122 130 065 060 000 000 045 116 045 104 062 045 104 062 045	P. ACM: .A	ASCII // ASCII /-/<00><00> ASCII /#N#/ ASCII /D2#/ ASCII /D4#/ ASCII /RX5/ ASCII /O/<00><00> ASCII /M#/ ASCII /D2#/ ASCII /D2#/ ASCII /D4#/	
004334 004337 004342 004345 004350 004353 004356 004361 004364 004367	101 040 040 122 104 065 061 000 000 045 104 064 045 132 063 045 104 063 045 101 054 045 132 063 045 101 054 045 132 063 045 101 054	P.ACO: .A	ASCII /RD5/ ASCII /1/<00><00> ASCII /#D4/ ASCII /#Z3/ ASCII /#A./ ASCII /#A./ ASCII /#A./ ASCII /#A./	
004370 004373 004376 004401 004404 004407 004412 004415 004420	045 104 064 045 104 064	P.ACP: .A	ASCII <00> ASCII /#D4/	

			113	
ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 SEQ 0065 Page 65 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (35)
004422 004425 004430 004433 004436 004441 004444	045 116 045 101 040 056 040 040 040 056 040 040 103 116 124 122 040 040 040 040 040 040 056 040	P.ACQ: .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII	/A ./	
004452 004455 004460 004463 004466 004471 004474	040 056 056 056 056 056 056 056 056 056 040 040 040 040 040 040 056 040 040 056 056	. ASCII . ASCII . ASCII . ASCII . ASCII		
004502 004505 004510 004513 004516 004521 004524 004527	056 056 056 056 000 000 045 101 040 040 040 056 040 040 040 056 045 104 064 045 101 040 040 040	ASCII	//<00><00> /#A / /.#D/ /4#A/	
004532 004535 004540 004543 004546 004551 004554	056 040 040 040 056 040 040 040 056 045 104 064 045 101 040 040 040 056 000 000 045 116 045	ASCII	/*. / /#D4/ /#A /	
004561 004567 004572 004575 004600 004603 004606	116 045 101 125 116 111 124 040 040 104 111 123 113 040 040 040 040 040 040 040 040	. ASCII . ASCII . ASCII . ASCII	/NEA/ /UNI/ /T / /DIS/ /K /	
004611 004617 004622 004625 004630 004633	040 043 040 117 106 040 040 040 043 040 102 114 113 123 040 040 040 040 040 040	ASCII	/ # / /OF / / BL/ /KS /	
004641 004644 004647 004652 004655	043 040 117 106 040 040 040 040 043 040 102 114 113 123 040	ASCII ASCII ASCII ASCII ASCII	/ BL/ /KS /	

VAX-11 Bliss-16 V3-555 Page 66 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)

ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04
004656 045 004661 101 004664 043 004667 040 004672 043 004675 040 004700 124 004706 040 004711 101 004714 040 004717 040 004725 040 004725 040 004730 040 004730 040 004736 124 004741 040 004741 040	040 040 040 040 040 040 040 040 040 122 105 104 040 040 040 040 040 040 040 040 040	P.ACT:	.ASCII /#N#/ .ASCII /A / .ASCII /E / .ASCII /E / .ASCII /ADS/ .ASCII / R/ .ASCII / EAD/ .ASCII / EAD/ .ASCII / LASCII / LAS	
004752 004754 004757 004762 004765 004770 004776 005001 005004 005007 005012 005015 005015 005020 005023 005023 005026 005031 005034 005037 005042 005045 005045 005050	000 116	P.ACU:	ASCII / /<00: ASCII /#N#/ ASCII /A/ ASCII / /	
005053 000 005054 045 005057 123 005062 104 005065 123 005070 104 005073 101 005076 040 005101 116 005104 065 005107 040	116 045 061 045 062 045 064 045 062 045 040 040 104 102 122 104 061 040	P.ACV:	.ASCII / /<00 .ASCII /00> .ASCII /6N%/ .ASCII /51%/ .ASCII /02%/ .ASCII /02%/ .ASCII /02%/ .ASCII /0 / .ASCII / DB/ .ASCII /NRD/ .ASCII /51 / .ASCII / #D/	

						CO		
ZRQAM1		RD/RX EXE	RCISER			5-Dec-1983	10.27.14	VAX-11 Bliss-16 V3-555 SEQ 0067 Page 67
V01.2		PROTECTIO				5-Dec-1983	10:27:04	VAX-11 Bliss-16 V3-555 Page 67 DISK*USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
005112	066	045	123		.ASCII	/6#S/		
005115	063	045	104		ASCII	/3#D/		
005120	066	045	123		ASCII	/6#S/		
005123	065	045	104		ASCII	/5#D/		
005126	066	045	123		ASCII			
005131	063				.ASCII	/6#S/		
005134	065	045	104		. ASCII	/3#D/		
005134	066 045	000	DAE	0 0011	. ASCII	/6/<00>		
005136 005141	104	116	045	P. ACW:	.ASCII	/#N#/		
005144		062	045		.ASCII	\D2=\		
005147	104	064	045		.ASCII	/D4#/		
005152	101	040	040		.MSCII	/A /		
005155	122	104	065		. ASCII	/RD5/		
005160	062 045	000	000	D ACV	. ASCII	/2/<00><00>		보다는 사람이 되는 것이 없었다. 이렇게 하지만 그리다는 그리고 있다고 있다.
	045	116	045	P.ACX:	.ASCII	\4M4\		
005163	123	061	045		. ASCII	/S1#/		
005166	104	062	045		.ASCII	\D5=\		
005171 005174	123	064	045		.ASCII	/54#/		[배고 : [배기 : 1 ] [배기 : [편집 : [ ] ] [ ] [ ] [ [ ] [ ] [ ] [ ] [ ] [
	104	062	045		ASCII	10541		
005177 005202	101	040	040		.ASCII	/A		
005202	040	104	102		.ASCII	/ D8/		
005205	116 065	122	104		.ASCII	/NRD/		
005210		062	040		.ASCII	/52 /		그러움이 있다. 그리고 그리고 그리고 있었다면 나 되었다면 하다니다.
005215	040	045	104		.ASCII	/ #D/		
005221	066	045	123		.ASCII	/6#S/		
005202 005205 005210 005213 005216 005221 005224 005227 005232 005235 005240 005242	063	045	104		.ASCII	/340/		
005227	066 065	045	123		.ASCII	/6#S/		
005227	066	045	104		.ASCII	/5 <b>#</b> 0/		
005235	063	045 045	123 104		. ASCII	/6#S/		
005240	066	000	104		.ASCII	/3#D/		그는 그 나는 것 같아 없는 그들은 아니라 보는 아무네요? 사용하다 되었다.
005242	045	116	045	P.ACY:	. ASCII	/6/<00> /#N#/		
005245	104	062	045	P.ACT:	.ASCII	/D24/		
005245 005250 005253 005256	104	064	045		ASCII	/D4#/		
005253	101	040	040		.ASCII	/A /		
005256	077	077	077		ASCII	/222/		
005261	077	000	000		ASCTT	/?/<00><00>		
005264	124	117	117	P.ACZ:	.ASCII	/100/		
005264 005267 005272 005275 005300 005303 005304 005307	040	115	101	· .nca:	ASCII	/ MA/		
005272	116	131	040		ASCIT	/NY /		
005275	125	116	111		.ASCII	/UNI/		
005300	124	116 123	000		ASCII	/TS/<00>		
005303	000				ASCIT	<00>		
005304	116	117	124	P.ADA:	.ASCII	/NOT/		
005307	040	105	116		.ASCII	/ EN/		
005312	117	125	107		.ASCII	/0UG/		
005312 005315 005320 005323 005326	110	040	106		ASCIT	/H F/		
005320	122	105	105		.ASCII	/REE/		
005323	040	115	105		.ASCII	/ ME/		
005326	115	117	122		.ASCII	/MOR/		: : : : : : : : : : : : : : : : : : :
005551	131	040	106		.ASCII	/Y F/		
005334	117	122	040		.ASCII	/OR /		
005337	101	114	114		. ASCII	/ALL/		
005342	117	103	114		.ASCII	/OCA/		일 내가 이렇게 하고 가면 가는 경우 나는 사람들이 얼마나 되었다.

							DO		
ZRQAM1		RD/RX EXE	EDCTCED				E Das 1007	10.07.14	SEQ 0068
V01.2		PROTECTIO					5-Dec-1983 5-Dec-1983		VAX-11 Bliss-16 V3-555 Page 68 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
									525 TO SELECTION TO SELECTION (55)
005345	124	111	116		. ASCII	/TIN/			
005350	107	040	122		.ASCII	/G R/			
005353	105	101	104		.ASCII	/EAD/			
005356	057	127	122		. ASCII	<57>/WR/			
005361	111	124	105		ASCII	/ITE/			
005364	040	102	125		ASCII	/ BU/			
005367		106	105		ACCTT				
005307	106	106 123	105		. ASCII	/FFE/			
005372 005375	122	123	000		. ASCII	/RS/<00>			
005575	000				.ASCII .ASCII .ASCII	<00>			
005376	122	105	107	P.ADB:	.ASCII	/REG/			
005401	040	105	130		. ASCII	/ EX/			
005404	111	123	124		.ASCII	/IST/			
005407	105	116	103		.ASCII	/ENC/			
005412	105	040	124		.ASCII	/E T/			[18] [18] [18] [18] [18] [18] [18] [18]
005415	105	123	124		ASCIT	/EST/			가장하다 나는 아이들에 가르게 되는 바이를 다 살아 있다.
005420	040	106	101		.ASCII	/ FA/			
005423	111	114	105		ASCII				그래마 195. 마시트 아니라 내가 있다고 하게 되었다면 다 하는데 보다.
005426	104		103		ACCTT	/ILE/			
005470	104	000	107	0 400	. ASCII	/D/<00>			
005430	126	105	103	P.ADC:	. ASCII	/VEC/			
005433	124	117	122		.ASCII	/TOR/			
005436 005441	040	124	105		. ASCII	/ TE/			1992년 1월 1일 1일 전 1일
005441	123	124	040		. ASCII	/ST /			
005444 005447 005452	106	101	111		.ASCII .ASCII .ASCII	/FAI/			
005447	114	105	104		.ASCII	/LED/			
005452	000	000			.ASCII	<00><00>			
005454 005457 005462	102	122	040	P.ADD:	.ASCII .ASCII .ASCII	/BR /			
005457	114	105	126		ASCIT	/LEV/			
005462	105	114	040		ASCIT	/EL /			그 나는 이번 그 것은 그는 내가 없다고 있다면 가는 것은 사람들이 없는 그 없어요? 그 나를 다 다 다 다 없다면 다 없다면 다 되었다.
005465 005470	124	105	123		.ASCII .ASCII .ASCII	/TES/			
005470	124	040	106		ASCIT	IT FI			
005473	101	111	114		ASCII	/AIL/			
005476	105	104	114		ASCII	/MIL/			
005501	000	104	000		.ASCII	/ED/<00>			
005501 005502		***		0 405	. ASCII	<00>			
005505	111	116	111	P.ADE:	. ASCII	/INI/			
005510	124	040	123		.ASCII	/T S/			
005510	105	121	125		. ASCII	/EQU/			
005513	105	116	103		.ASCII	/EQU/			
005516 005521 005524 005527 005530 005533	105	040	106		.ASCII .ASCII .ASCII	/E F/			이 경영 아이들 아니는 그 아이들 때문에 가장 아이들 때문에 그 양반 없었다.
005521	101	111	114		.ASCII	/AIL/			
005524	105	104	000		.ASCII	/ED/<00>			
005527	000				.ASCII .ASCII .ASCII .ASCII .ASCII	<00>			
005530	106	101	124	P.ADF:	.ASCII	/FAT/			
005533	101	114	040		ASCIT	/AL /			그리즘 하는 이 경기 () 하는 것으로 보는 사람들이 보면 살아가지 않는 것도 없는 것 같다.
005536	103	124	114		ASCIT	/CTL/			
005541	122	040	105		ASCTT	RE/			"고려있는 이 그리고 있는 다른 것이다. 그리고 그리고 하나 가지 않는 것이다.
005544	122	122	000		ASCTT	/RR/<00>			아이는 이 이 이 이 역사 사람들은 하는 것이 하는 것이 되었다. 나는 사람들이 되었다.
005547	000	166	000		ASCIT				
005541 005544 005547 005550 005553 005556	117	116	114	D ADC	.ASCII .ASCII .ASCII	<00>			
005553	111	116	114	P.ADG:	. MSCII	/ONL/			
005554	111	116	105		. ASCII	/INE/			
005556	040	106	101		.ASCII	/ FA/			나는 사용하는 방법 방문 등 등 보고 있는 것이 맛있다. 무료 살을 내려왔다. 사용 함
000001	111	114	105		.ASCII	/ILE/			
005564	104	000			.ASCII	/D/<00>			
005566	127	122	111	P.ADH:	.ASCII	/WRI/			이상 그렇게 있는 것으로 살아보니 사람들이 되었다. 그렇게 되었다면 하셨다. 그 나는 그리
									사람이 가장 그는 이번 생각이 되는 것이 되지 않는데 되었다.

ZRQAM1 VO1.2	RD/RX EX	ERCISER ON TABLE			5-Dec-1983 5-Dec-1983	VAX-11 Bliss-16 V3-555 Page 69 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
005571 005574 005577 005602 005605 005610 005613 005616 005621	124 105 120 122 124 105 124 040 117 116 114 111 124 000 101 103 105 123	055 117 103 103 106 103 000 103	P.ADI: A	SCII SCII SCII SCII SCII SCII	/TE-/ /PRO/ /TEC/ /T C/ /ONF/ /LIC/ /T/<00><00> /ACC/	
005624 005627 005632 005634 005637 005642	040 106 111 114 104 000 106 101 101 114 111 057	123 101 105 124 040 117	P.ADJ: .A	SCII SCII SCII SCII	/ESS/ / FA/ /ILE/ /D/<00> /FAT/ /AL / /I/<57>/O/	
005645 005650 005652 005655 005660 005663	040 105 122 000 103 124 122 040 111 115 117 125 000 000	114 124 105 124	P.ADK: A	SCII SCII SCII SCII SCII	/ ER/ /R/<00> /CTL/ /R T/ /IME/ /OUT/	
005666 005670 005673 005676 005701 005704 005707 005712 005715 005720 005723	106 101 114 105 C40 124 O40 123 116 104 123 105 O55 103 114 122 103 110 122 101 124 105	111 104 117 105 040 124 124 055 101 103 122	.A .A .A .A .A	SCII SCII SCII SCII SCII SCII SCII SCII	<pre>&lt;00&gt;&lt;00&gt; /FAI/ /LED/ / TO/ / SE/ /ND / /SET/ /-CT/ /LR-/ /CHA/ /RAC/ /TER/</pre>	
005731 005734 005737 005742 005745 005750 005753 005756 005761 005764 005767 005772 005775 006000 006003	111 123 111 103 040 103 115 115 116 104 123 105 055 103 114 122 103 110 122 101 124 105 111 123 111 103 040 122 123 120	124 123 117 101 000 124 124 055 101 103 122 124 123 105	P. ADM: .A .A .A .A .A .A	SCII SCII SCII SCII SCII SCII SCII SCII	/IST/ /ICS/ / CO/ /MMA/ /ND/<00> /SET/ /-CT/ /LR-/ /CHA/ /RAC/ /TER/ /IST/ /ICS/ / RE/ /SPO/	
006006 006011 006014 006017 006022	123 120 116 123 040 110 123 040 101 104 105 116	105 101 102 040 104	:A	SCII SCII SCII	/NSE/ / HA/ /S B/ /AD / /END/	

			10	
ZRQAM1	RD/RX EXERCISER		5-Dec-1983 10:27:14	VAX-11 Bliss-16 V3-555 SEQ 0070 Page 70
V01.2	PROTECTION TABLE		5-Dec-1983 10:27:04	DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
V01.2  006025 006030 006033 006036 006041 006044 006047 006052 006055 006060 006063 006066 006071 006074 006077 006102 006105 006110 006112 006115	PROTECTION TABLE  103	.ASCII /COD/ .ASCII /E 0/ .ASCII /R F/ .ASCII /R F/ .ASCII /LAG/ .ASCII /S I/ .ASCII /N E/ .ASCII /N E/ .ASCII /RR/< P.ADN: .ASCII /FAI/ .ASCII /LED/ .ASCII / SE/ .ASCII / ND / .ASCII /ON-/ .ASCII /AND/ .ASCII /AND/ .ASCII /AND/ .ASCII /ON-/ .ASCII /ON-/ .ASCII /LIN/ .ASCII /LIN/ .ASCII /LIN/ .ASCII /LIN/ .ASCII /LIN/ .ASCII /E R/	5-Dec-1983 10:27:04	DISK \$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
006123 006126 006131 006134 006137 006142 006145 006150 006153	105 123 120 117 116 123 105 040 110 101 123 040 102 101 104 040 105 116 104 103 117 104 105 000 000 117 116 055	.ASCII /ESP/ .ASCII /ONS/ .ASCII /E H/ .ASCII /AS / .ASCII /BAD/ .ASCII / EN/ .ASCII /DCO/ .ASCII /DE/ .ASCII /ON-/	(00>	
006157 006162 006165 006170 006173 006176 006201 006204 006207 006212 006215	114 111 116 105 040 122 105 123 120 117 116 123 105 040 110 101 123 040 125 116 113 116 117 127 116 040 104 105 126 111 103 105 000 111 057 117	.ASCII /LIN/ .ASCII /E R/ .ASCII /ESP/ .ASCII /ONS/ .ASCII /AS / .ASCII /AS / .ASCII /NOW/ .ASCII /N D/ .ASCII /EVI/ .ASCII /CE/	00>	
006204 006207 006212 006215 006220 006223 006226 006231 006234 006237 006242 006244	111 057 117 040 122 105 121 125 105 123 124 040 106 101 111 114 105 104 000 000 045 101 115 117 122 105	P.ADQ: ASCII /CE/ ASCII /CE/ ASCII /I/<5 .ASCII / RE/ .ASCII /QUE/ .ASCII /FAI/ .ASCII /LED/ .ASCII /WAM/ .ASCII /ORE/	57>/0/ // // // // //	
006252 006255	040 124 110 101 116 040	ASCII / TH/	/	

ZRQAM	1	RD/RX EX	ERCISER				5-Dec-1983 10:27:	14 VAX-11 Bliss-16 V3-555 SEQ 0071
V01.2		PROTECTI					5-Dec-1983 10:27	04 DISK*USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
006260		104	062		.ASCII	/\$D2/		
00626		101	040		.ASCII	/#A /		
006260		116	111		. ASCII	/UNI/		
00627		123	040		. ASCII	/TS /		
006274	4 123	120	105		. ASCII	/SPE/		
00627	7 103	111	106		.ASCII	/CIF/		
00630	2 111	105	104		.ASCII	/IED/		
00630	5 000				.ASCII .ASCII .ASCII	<00>		
00630	6 045	101	052	P.ADS:	. ASCII	/#A+/		
00631	1 040	116	117		ASCII	/ NO/		
00631	4 040	122	105		ASCIT	/ RE/		
00631	7 123	120	117		ASCII ASCII ASCII ASCII ASCII	/SP0/		
00631 00632	2 116	120 123	105		ASCIT	/NSE/		
00632	5 040	101	124		ASCTT	/ AT/		
00632	0 040	101	104		ASCTT	/ AD/		
00633	3 104	122	105		ASCII			
00633	6 123	123	040		ASCII	/DRE/		
		123			. MSCII	/SS /		
00634	1 045	117	066		. MOLII	/#06/		
00634	4 000	000	050	0 407	.ASCII	<00><00>		
00634	6 045	101	052	P.ADT:	. ASCII	/#A+/		
00635	1 040	111	116		.ASCII	/ IN/		
006354	4 103	117	122		. ASCII	/COR/		
00635 00635 00635 00636	7 122	105	103		.ASCII .ASCII .ASCII .ASCII	/REC/		
00636	2 124	040	102		. ASCII	/T B/		
00636 00637	5 122	040	114		ASCII ASCII ASCII ASCII ASCII ASCII	/R L/		
00637	0 105	126	105		, ASCII	/EVE/		
00637 00637	3 114	040	106		. ASCII	/L F/		
00637		122	040		. ASCII	/OR /		
00640	1 104	105	126		. ASCII	/DEV/		
00640	4 040	045	117		. ASCII	/ 40/		
00640	7 066	000	000		. ASCII	/6/<00><	00>	
00641	2 045	101	052	P. ADU:	. ASCII	/SA4/		
00641	5 040	123	124		. ASCII	/ ST/		
00641 00642 00642	0 105	120	040		.ASCII	/EP /		
00642	3 045	104	061		ASCII	/#D1/		
00642	6 045	101	040		. ASCII	/#A /		
00643	1 122	105	101		ASCII	/REA/		
00643	4 104	040	105		.ASCII	/D E/		
00643	7 122	122	000		ASCII	/RR/<00>		
00644	2 045	101	052	P.ADV:	.ASCII	/SA4/		
00644 00645	5 040	102	101		.ASCII .ASCII .ASCII .ASCII	/ BA/		
00645	0 104	040	123		ASCTT	/D S/		
00645	3 101	040	103		ASCIT	/A C/		
00645	6 117	104	105		ASCTT	/ODE/		
00646	1 040	106	122		ASCTT	/ FR/		
00646	4 117	106 115	122 040		.ASCII	/OM /		
00646 00646	7 104	105	126		ASCIT	/DEV/		
00647	2 040	105 045	117		.ASCII	/DEV/		
00647	5 066	000			ASCIT	/ #0/	00>	
00650	0 045	101	000	D ADU	.ASCII	/6/<00><	00,	
00650	3 040	101	052	P. ADW:	.ASCII	/#A+/		
00650	6 127	104	111		.ASCII	/ DI/		
00651	6 123 1 104	113	045 045		.ASCII	/SK#/		
00031	104	062	045		.ASCII	10541		

ZRQAM1 VO1.2		RD/RX EX				5	Dec - 1983 Dec - 1983	10:27:14 10:27:04	VAX-11 Bliss-16 V3-555 Page 72 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
006514 006517 006522	101 105 040	040 116	127		.ASCII	/A W/			
006525	106	117	106 111		.ASCII	/ OF/ /FLI/			
006530	116	105	000		ASCII	/NE/<00>			
006533 006534 006537	000				. ASCII	<00>			
006534	045	101	052	P.ADX:	.ASCII	/#A+/			
006537	040	104	105		.ASCII	/ DE/			
006542 006545	126 105	040	103 045		.ASCII	/VIC/			
006550	117	066	045		ASCIT	/06#/			
006550 006553	101	040	116		.ASCII	/A N/			
006556	117	124	040		ASCII	/OT /			
006561	120	122	117		.ASCII .ASCII .ASCII	/PRO/			
006564	103	105	123		. ASCII	/CES/			그런 이번 때문에 가장 생각하다 하는 것이 모든 것이 되었다.
006567 006572	123	111	116		.ASCII	/SIN/			
006575	107 117	040 115	103 115		. ASCII	/G C/			
006600	101	116	104		ASCII	/AND/			
006600 006603 006606 006611	040	120	101		. ASCII	/ PA/			
006606	103	113	105		.ASCII	/CKE/			
006611	124	123	000		.ASCII .ASCII .ASCII	/TS/<00>			
006614	040	055	040	P.ADY:	.ASCII	/ - /			
006622	165 145	156 143	162 157		.ASCII	/unr/			
006625	147	156	151		ASCIT	/gni/			
006617 006622 006625 006630 006633	172	145	144		. ASCII	/zed/			
006633	040	115	105		.ASCII	/ ME/			어떻게 되는 사람들이 되었다. 그리는 이 사람이 되었다. 그 그 그 그 때문
006636	123	123	101		.ASCII .ASCII .ASCII	/SSA/			
006641 006644	107 124	105	040		.ASCII	/GE /			
006647	105	131	120 000		.ASCII	/TYP/ /E/<00><00	1		요즘 등 사람들은 이 내가 들어 먹었다. 그 그렇게 되는 것이 없는데 그렇게 되었다.
006652	040	055	040	P.ADZ:	ASCIT	/-/	,		
006652 006655	165	055 156	162		.ASCII	/unr/			
006660	145	143	157		. ASCII	/eco/			
006663	147	156	151		.ASCII	/gni/			
006666 006671	172 040	145 143	144 157		.ASCII .ASCII .ASCII	/zed/			
006674	156	156	145		ASCIT	/ co/			그는 가장 그렇게 다른 그 가게 하지 않는 것은 때 바라면 하는 것이다.
006674 006677	156 143	156 164	151		ASCII	/cti/			
006702	157	156	040		.ASCII	/on /			
006705	151	144	000		. ASCII	/id/<00>			
006710 006713	040 165 145	055	040	P.AEA:	.ASCII	1 - 1			
006716	145	143	162 157		. ASCII	/unr/			
006721	147	156	151		ASCII ASCII ASCII ASCII ASCII ASCII	/eco/			
006724	172	055 156 143 156 145	151 144		ASCII	/zed/			
006727	040	122 125	105 122 155 163 145		.ASCII .ASCII .ASCII	/ RE/			
006732	124	125	122		.ASCII	/TUR/			
006735 006740	116 145	040 163	155		. ASCII	/N m/			
006743	141	147	145		.ASCII .ASCII .ASCII	/000/			
006746	000	000	243		ASCII	<00><00>			

	ZRQAM1 VO1.2	RD/RX EX	KERCISER ION TABLE		5-Dec-1983 10:27:14 VAX-11 Bliss-16 5-Dec-1983 10:27:04 DISK\$USER2:[DIET	SEQ 0073 V3-555 Page 73 Z.RDRX]ZRQACO.BL1;82 (35)
	006750 006753 006756 006761 006764	040 055 165 156 145 143 147 156 172 145	040 162 157 151 144	P.AEB: .AS .AS .AS	/ - / /unr/ /eco/ /gni/ /zed/	
	006767 006772 006775 007000 007003 007006	040 122 124 125 116 040 101 103 105 124 040 055	105 122 120 113 000 040	. AS . AS . AS . AS P. AEC: . AS	/ RE/ /TUR/ /N P/ /ACK/	
	007011 007014 007017 007022 007025	165 156 145 143 147 156 172 145 040 103	162 157 151 144 122	. AS . AS . AS	/eco/ /gni/ /zed/ / CR/	
	007030 007032 007035 007040 007043 007046	116 000 040 055 125 116 105 103 107 116 132 105	040 122 117 111 104	P.AED: .AS .AS .AS .AS	/ - / /UNR/ /ECO/ /GNI/	
	007051 007054 007057 007062 007065 007070	040 117 103 117 105 000 040 055 115 123 120 040	120 104 000 040 103	P.AEE: AS	/ OP/ /COD/ /E/<00><00> / - / /MSC/	
	007073 007076 007101 007104 007107	124 101 125 123 103 117 105 040 122 122	123 124 040 104 105 000	. AS . AS . AS . AS . AS	/TAT/ /US / /COD/ /E E/	
	007112 007115 007120 007123 007126	040 055 104 125 040 123 101 124 123 040	040 120 124 125 103	P.AEF: .AS .AS .AS	/ _ / /DUP/ / ST/ /ATU/	
	007131 007134 007137 007142 007145 007150	117 104 040 105 122 000 040 055 165 156 145 143	105 122 000 040 162 157	P. AEG: AS	/R/<00><00>	
	007153 007156 007161 007164 007167	147 156 172 145 040 123 101 124	151 144 124 125 103	. AS . AS . AS . AS . AS	/ATU/	
-	007172 007175 007176 007201	123 040 117 104 000 040 055 114 102	105 040 116	P.AEH: AS	(00)	

	ZRQAM1 /01.2		RD/RX EXE					5-Dec-1983 5-Dec-1983		VAX-11 Bliss-16 V3-555 Page DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (35)	74
	007204	040	110	117		.ASCII	/ HO/	J-060-1703	10127104	DISK FOSERS: [DIE12.RDRX JZRWACO.BL1;82 (55)	,
0	007207	123	124	040		. ASCII	/ST /				
9	007212	103	117	115		.ASCII	/COM/				
	007215 007220	120 105	101 040	122 105		.ASCII	/PAR/ /E E/				
ò	007223	122	122	000		ASCII	/RR/<00>				
. (	007226	040	055	040	P.AEI:	ASCII	1 - 1				
0	007231	104	102	116		.ASCII	/DBN/				
9	007234	040	110	117		.ASCII	/ HO/				
6	007237 007242	123	124 117	040 115		.ASCII	/ST /				
1	007245	120	101	122		.ASCII	/PAR/				
0	007250	105	040	105		. ASCII	/E E/				
9	007253	122	122	000		. ASCII	/RR/<00>				
1	007256 007261	125	055	040 101	P.AEJ:	. ASCII	1.50				
1	007264	102	116 114	105		.ASCII	/UNA/ /BLE/				
(	007267	040	124	117		ASCII	/ TO/				
(	007272	040	114	117		.ASCII	/ LO/				
5	007275	101	104	040		. ASCII	/AD /				
1	007300 007303	104	125 115	120 105		.ASCII	/DUP/ / ME/				
1	007306	104	iii	101		ASCII	/DIA/				
	007311	040	000	000		.ASCII	/ /400>4	00>			
9	007314	040	055	040	P. AEK:	.ASCII	1 - 1				
1 8	007317 007322	105	111	122		.ASCII	/ERR/				
1 6	007325	040	104	116 125		ASCII	/ IN/				
(	007325 007330	120	055	120		ASCII	/P-P/				
(	007333	113	124	040		. ASCII	/KT /				
	007336 007341	127	110	105		.ASCII	/WHE/				
	007344	116 123	040 111	125 116		.ASCII	/N U/ /SIN/				
(	007347	107	040	103		ASCII	/G C/				
	007352	124	114	122		. ASCII	/TLR/				
1	007355	040	114	103		.ASCII	/ LC/				
1	007360 007363	107	120	122		.ASCII	/ PR/ /G/<00><(	005			
(	007366	045	101	111	P.AEM:	ASCII	/#AI/	007			
(	007371	116	101 126 111 103 115	111		.ASCII .ASCII .ASCII	/NVA/				
1	007374 007377	114	111	104		.ASCII	/LID/				
1	007402	040 115	105	101		.ASCII	/ CO/				
	007405	116	104	000		ASCIT	/MMA/ /ND/<00>				
(	007410	116 045	101	103	P.AEN:	ASCII ASCII ASCII ASCII	/SAC/				
5	007413	117	115 116	115 104		.ASCII	/OMM/				
1	007416 007421	040	116	104		. MSCII	/AND/				
1	007424	117	101 122	102 124		.ASCII	/ AB/ /ORT/				
(	007427	105	104	000		.ASCII	/ED/<00>				
	007432	045	101	125 124	P.AEO:	. ASCII	/SAU/				
5	007435 007440	116	111	124		.ASCII	/NIT/				
,	007440	040	117	106		.ASCII	/ OF/				

	QAM1		RD/RX EXER PROTECTION					5-Dec-1983 5-Dec-1983	10:27:14 10:27:04	VAX-11 Bliss-16 V3-555 Page 75 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (35)
00	7446	106	114 105	111		.ASCII	/FLI/ /NE/<00>			
00	7452 7455	000 045 122 123	101 101	124 116	P.AEP:	.ASCII .ASCII	<00> /≰AT/ /RAN/			
00	7463 7466	111 040 040	111 117 124	124 116 117		.ASCII .ASCII	/SIT/ /ION/ / TO/			
00	7474 7477	101	101 111 102	126 114 114		.ASCII .ASCII .ASCII	/AV/ /AIL/ /ABL/			
00	7505 7510	105 124 105 045	040 101 000	123	0.450	.ASCII	/E S/ /TAT/ /E/<00>			
00	7515 7520	105 101 117	101 104 040	115 111 106 115	P.AEQ:	.ASCII .ASCII	/#AM/ /EDI/ /A F/			
00	7526 7531	101 105 000	122 124 122 000	040 122		.ASCII .ASCII .ASCII	/ORM/ /AT / /ERR/ <00><00>			
00	7536 7541	045 122 105	101 111 055	127 124 120	P.AER:	.ASCII .ASCII .ASCII	/#AW/ /RIT/ /E-P/			
00	7547 7552	122 105 105	117 103 104	124 124 000		.ASCII .ASCII .ASCII	/ROT/ /ECT/ /ED/<00>			
00	7560 7563	045 105 103	101 126 105	104 111 040	P.AES:	.ASCII	/#AD/ /EVI/ /CE /			
00	7571 7574 7577	103 120 105	117 101 040	115 122 105		.ASCII .ASCII .ASCII	/COM/ /PAR/ /E E/			
00	7602 7605 7606	122 000 045	122	104	P.AET:	.ASCII .ASCII .ASCII	/RR/<00> <00> /#AD/			
00	7614	101 040 122 045	124 105 000	101 122 000		.ASCII .ASCII .ASCII	/ATA/ / ER/ /R/<00><	00>		
00	7625 7630	117 040	101 123 102	110 124 125	P.AEU:	.ASCII	/#AH/ /OST/ / BU/			
00	7636	106 122 103 123	106 040 103	105 101 105		.ASCII .ASCII .ASCII	/FFE/ /R A/ /CCE/			
00	7647 7652	105	123 122 000	040 122	0.454	ASCII	/SS / /ERR/ <00><00>			
00	7657 7662	045 124 040	101 114 105	103 122 122	P.AEV:	.ASCII .ASCII .ASCII	/#AC/ /TLR/ / ER/			
00	7670	122 045	101	104	P.AEW:	.ASCII	/R/<00> </td <td>00&gt;</td> <td></td> <td></td>	00>		

								LO		
	ZRQAM1 VO1.2		RD/RX EXE					5-Dec-1983 5-Dec-1983	VAX-11 Bliss-16 V3-555 SEQ 0076 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)	6
CANCELL STREET STREET,	007673 007676 007701 007704 007707 007712 007715 007720 007723 007726	122 105 122 045 105 101 040 117 111 105	111 040 122 101 123 107 106 115 116 122	126 105 000 115 123 105 122 040 124 116 040	P.AEX:	.ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII	/RIV/ /E E/ /RR/<00> /#AM/ /ESS/ /AGE/ / FR/ /OM / /INT/ /ERN/ /AL /			
The second secon	007734 007737 007742 007745 007750 007753 007756 007761 007764 007767	104 107 123 103 045 117 040 115 122 105	111 116 124 123 101 123 103 120 105 122	101 117 111 000 110 124 117 101 040 122	P.AEY:	.ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII	/DIA/ /GNO/ /STI/ /CS/<00> /#AH/ /OST/ / CO/ /MPA/ /RE / /ERR/ <00><00>			
THE R. P. LEWIS CO., LANSING, MICH. LANSING, MICH. LANSING, MICH. LANSING, MICH. LANSING, MICH. LANSING, MICH.	007774 007777 010002 010005 010010 010013 010016 010020 010022 010024 010026	045 117 101 040 115 125 007366' 007410' 007432'	101 115 116 124 105 124	103 115 104 111 117 000	P.AEZ:	ASCII ASCII ASCII	/#AC/ /OMM/ /AND/ / TI/ /MEO/ /UT/<00> P.AEM P.AEN P.AEO			
THE RESERVE OF THE PARTY OF THE	010030 010032 010034 010036 010040 010042 010044 010046 010050	007452' 007512' 007536' 007560' 007606' 007622' 007654' 007670' 007704' 007750'				. WORD . WORD	P.AEP P.AEQ P.AES P.AET P.AEU P.AEV P.AEW P.AEX P.AEX P.AEZ			
The second of the first first the second sec	010052 010055 010060 010063 010066 010071 010074 010077 010102 010105 010110	045 101 122 117 115 123 105 105 111 104 116	116 105 040 107 105 101 040 103 126 072	045 122 114 040 123 107 122 105 105	P.AFA:	ASCII	/#N#/ /AER/ /R L/ /OG / /MES/ /SAG/ /E R/ /ECE/ /IVE/ /D:#/ /N/<00>			
-										

	ZRQAM1		XERCISER				5-Dec-1983	10:27:14	VAX-11 Bliss-16 V3-555 SEQ 0077 Page 77
-	V01.2	PROTECT	ION TABLE				5-Dec-1983	10:27:04	DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
-	010115 04 010120 11	45 101 40 103 14 122 05 122	052 124 040 122	P.AFC:	.ASCII .ASCII .ASCII .ASCII	/#A+/ / CT/ /LR / /ERR/			
-	010126 010131	45 116 00 45 101	000	P.AFD:	. ASCII	/#N/<00> <00> /#A+/			
the case of constant in	010135 04 010140 12 010143 11	40 110 23 124 15 105	117 040 115		.ASCII .ASCII .ASCII .ASCII	/ HO/ /ST / /MEM/			
-	010154 10	17 122 40 101 03 105 23 040	131 103 123 105		.ASCII	/ORY/ / AC/ /CES/ /S E/			
	010162 12 010165 12 010170 04	22 122 16 000 45 101	045 000 052	P.AFE:	.ASCII .ASCII .ASCII	/RR#/ /N/<00><0 /#A+/	0>		
-	010176 12	40 104 23 113 04 062 01 040	111 045 045 055		.ASCII .ASCII .ASCII	/ DI/ /SK#/ /D2#/ /A -/			
	010212 12	40 104 23 113 24 122 16 123	111 040 101		.ASCII .ASCII .ASCII	/ DI/ /SK / /TRA/			
-	010226 10	05 122 05 122 45 116	106 040 122 000		.ASCII .ASCII .ASCII	/NSF/ /ER / /ERR/ /#N/<00>			
-	010237 04	45 101 40 104 23 113 04 062	052 111 045 045	P.AFF:	.ASCII .ASCII .ASCII	/#A+/ / DI/ /SK#/			
-	010250 10 010253 00 010256 12	01 040 40 042 24 101	055 123 116		.ASCII .ASCII .ASCII	/D2#/ /A -/ / "S/ /TAN/			
-	010264 10 010267 11	04 101 04 040 11 123 40 111	122 104 113		.ASCII .ASCII .ASCII	/DAR/ /D D/ /ISK/			
-	010275 010300 010303	40 111 24 105 03 117 16 105	116 122 116 103		.ASCII	/ IN/ /TER/ /CON/ /NEC/			
and the same of the same of	010306 12 010311 10 010314 06	24 042 05 122 45 116	040 122 000		.ASCII .ASCII .ASCII	/T" / /ERR/ /#N/<00>			
	010320 04 010323 04	00 45 101 40 104 23 113	052 111 045	P.AFG:	.ASCII .ASCII .ASCII	<00> /#A*/ / DI/ /SK#/			
-	010331 10 010334 10 010337 04	04 062 01 040 40 042	045 055 123		.ASCII .ASCII	/D2#/ /A -/ / "S/			
	010342 1	15 101	114		.ASCII	/MAL/			

	ZRQAM1 VO1.2		EXERCISER TION TABLE		5-Dec-1983 10:27:1 5-Dec-1983 10:27:0	SEQ 0078 VAX-11 Bliss-16 V3-555 Page 78 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
Company of the Compan	010345 010350 010353 010356 010361 010364 010366 010370 010372	114 040 111 123 042 040 122 122 116 000 010112' 010132' 010170' 010234'	104 113 105 045 000	P.AFB: WORD	I /ISK/ I /" E/ I /RR#/ I /N/<00><00> P.AFC P.AFD P.AFE P.AFF	
THE THE PARTY OF T	010374 010376 010401 010404 010407 010412 010415 010420 010423 010426 010431 010434 010437 010445 010450 010450 010456 010461	010320' 045 116 101 111 117 040 125 106 105 122 101 104 122 105 123 040 117 122 122 105 104 040 063 062 102 111 123 051 040 045 066 045 040 045	045 057 102 106 040 104 123 106 040 101 050 040 124 072 117 101 117	P.AFH: .ASCI .ASCI .ASCI .ASCI .ASCI .ASCI .ASCI .ASCI .ASCI .ASCI .ASCI .ASCI	I /MN#/ I /AI/<57> I /O B/ I /UFF/ I /ER / I /ADD/ I /RES/ I /S F/ I /OR / I /REA/ I /D (/ I /32 / I /BIT/ I /S):/ I /#0/	
AND A SECOND CONTRACTOR OF SEC	010464 010466 010471 010474 010477 010502 010505 010510 010513 010516 010521 010524 010527 010532 010535 010540 010543	000 000 045 116 101 111 117 040 125 106 105 122 101 104 122 105 123 040 117 122 127 122 124 105 050 063 040 102 124 123 072 040 117 066	045 057 102 106 040 104 123 106 040 111 040 062 111	P.AFI: .ASCI .ASCI .ASCI .ASCI .ASCI .ASCI .ASCI .ASCI .ASCI .ASCI .ASCI .ASCI	I <00><00> I /MNM/ I /AI/<57> I /0 B/ I /UFF/ II /ER / II /ADD/ II /RES/ II /S F/ II /OR / II /HRI/ II /TE / II /(32/ II /IS)/ II /: #/	
AND DESCRIPTION OF THE PROPERTY OF THE PERSON NAMED IN COLUMN TWO IS NOT THE PERSON NAMED IN COLUMN TWO IS NAMED IN THE PERSON NAMED IN THE PERSON NAMED IN THE PERSON NAMED IN THE PERS	010546 010551 010554 010557 010562 010565 010570 010573	101 040 117 066 045 116 101 114 116 072 050 122 101 104 040 045	045 000 045 102 040 105 051	. ASC: . ASC: . ASC: . ASC: . ASC: . ASC: . ASC: . ASC:	I /06/<00> II /#N#/ II /ALB/ II /N: / II /(RE/ II /AD)/	

		D /
ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE	5-Dec-1983 10:27:14 VAX-11 Bl;ss-16 V3-555 Page 79 5-Dec-1983 10:27:04 DISK*USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (35)
010576 010601 010604 010607 010612 010615 010620 010623 010626 010631 010634 010642 010645 010650 010653 010656 010661 010667 010672 010672 010675 010700 010703 010706 010711 010714 010717 010722 010725 010730 010733 010744 010747 010752 010755 010760 010764 010767 010764 010767 010767 010768 010775 010769 010775 010769 010775 010760 010763 010764 010775 010760 010763 010764 010775 010760 010775 010760 010775 010760 010763 010764 010775 010765 010760 010763 010764 010775 010765 010765 010765 010765 010760 010765 010765 010765 010765 010765 010765 010765 010765 010765	065	. ASCII / COT/ . ASCII / COT/ . ASCII / GMA/ . ASCII / MNN/ . ASCI

VAX-11 Bliss-16 V3-555 Page 80 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)

ZRQAM1 VO1.2	RD/RX EXER PROTECTION					5-Dec-1983 5-Dec-1983	
011034 011037 011042 1011045 11050 11053 11056 11061 11064 11067 11072 11075 11075 11075 11075 11075 11075 11075	00 45 01 102 24 105 03 117 16 124 11 116 27 122 24 105 03 117 15 101 04 072 45 101	045 131 040 125 040 040 111 040 115 116 040 065 056	P.AFN:	ASCII	<pre>&lt;00&gt; /#N#/ /ABY/ /TE / /COU/ /NT / /IN / /WRI/ /TE / /COM/ /MAN/ /D: / /#D5/ /#A./</pre>		
011104 0 011107 1 011112 0 011115 1 011120 0 011123 1	00 45 116 01 040 40 104 23 113 72 040 04 062	045 052 111 040 045 000	P.AFO:	ASCII ASCII ASCII ASCII ASCII ASCII	<pre>&lt;00&gt; /#N#/ /A */ / DI/ /SK / /: #/ /D2/&lt;00&gt;</pre>		
011131 1 011134 0 011137 1 011142 0 011145 1 011150 1	45 116 01 123 72 040 17 066 45 116 01 123 01 124 23 040	045 101 045 000 045 124 125 103	P.AFP:	ASCII ASCII ASCII ASCII ASCII ASCII ASCII	/#N#/ /ASA/ /: #/ /06/<00> /#N#/ /AST/ /ATU/ /S C/		
011156 1 011161 0 011164 0 011167 1 011172 1 011175 1 011200 1	17 104 72 040 45 116 01 123 01 124 23 040 25 102 03 117	105 000 045 124 125 123 055	P.AFR:	.ASCII .ASCII .ASCII .ASCII .ASCII .ASCII	/ODE/ /: / <oo> /#N#/ /AST/ /ATU/ /S S/ /UB-/</oo>		
011206 1 011211 0 011212 0 011215 1 011220 1 011223 1 011226 0	05 072 00 45 116 01 103 15 115 16 104 40 000	104 040 045 117 101 072	P.AFS:	ASCII ASCII ASCII ASCII ASCII ASCII ASCII ASCII ASCII	/COD/ /E: / <00> /siNsi/ /ACO/ /MMA/ /ND:/ / /<00>		
011233 1 011236 0 011240 0 011243 1 011246 1	45 101 04 125 55 000 45 101 15 123 20 055	055 120 055 103 000	P.AFT: P.AFU:	.ASCII .ASCII .ASCII .ASCII .ASCII .ASCII	/#A-/ /DUP/ /-/<00> /#A-/ /MSC/ /P-/<00>		
011252 0	45 101 03 117	055 115	P.AFV:	ASCII ASCII	/#A-/ /COM/		

		U	
ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE	5-Dec-1983 10:2 5-Dec-1983 10:2	
011260 011263 011266 011271 011274 011277 011302 011305 011310 011313	120 101 122 105 000 000 045 116 045 101 102 101 104 040 102 114 117 103 113 040 122 105 120 117 122 124 105 104 072 040 045 117 066	.ASCII /PAR/ .ASCII /E/<00><00> P.AFW: .ASCII /MNM/ .ASCII /ABA/ .ASCII /D B/ .ASCII /LOC/ .ASCII /K R/ .ASCII /EPO/ .ASCII /RTE/ .ASCII /D: / .ASCII /MO6/	
011321 011324 011327 011332	045 101 040 045 117 066 045 101 056 000 000	.ASCII /#A / .ASCII /#06/ .ASCII /#A./ .ASCII <00><00>	
011334 011337 011342 011345 011350 011353 011356 011361	045 116 045 101 114 102 116 072 040 045 104 065 045 101 056 040 050 117 103 124 040 045 117 066	P.AFX: .ASCII /#N#/ .ASCII /ALB/ .ASCII /N: / .ASCII /#D5/ .ASCII /#A./ .ASCII / (0/	
011364 011367 011372 011375 011376	045 101 040 045 117 066 045 101 051 000 045 116 045	.ASCII /#A / .ASCII /#06/ .ASCII /#A)/ .ASCII (00> P.AFY: .ASCII /#N#/	
011401 011404 011407 011412 011415 011420 011423 011426 011431	101 104 102 116 072 040 045 104 065 045 101 056 040 050 117 103 124 040 045 117 066 045 101 051	.ASCII /ADB/ .ASCII /N: / .ASCII /#D5/ .ASCII /#A./ .ASCII / (O/ .ASCII /CT / .ASCII /#O6/ .ASCII /#A)/ .ASCII /#A)/ .ASCII /#N#/	
011432 011435 011440 011443 011446 011451 011454 011457 011462	045 116 045 101 102 131 124 105 040 103 117 125 116 124 040 111 116 040 103 117 115 115 101 116 104 072 040	.ASCII /ABY/ .ASCII /TE / .ASCII /COU/ .ASCII /NT / .ASCII /IN / .ASCII /COM/ .ASCII /MAN/ .ASCII /D: /	
011465 011470 011472 011475 011500 011503 011506	045 104 065 000 000 045 116 045 101 101 103 124 125 101 114 040 043 040 117 106	.ASCII /605/ .ASCII <00><00> P.AGA: .ASCII /6N6/ .ASCII /AAC/ .ASCII /TUA/ .ASCII /L #/ .ASCII / OF/	

ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bl;ss-16 V3-555 Page 82 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
011511 011514 011517 011522 011525 011530 011533 011536 011541	040 102 131 124 105 123 040 124 122 101 116 123 106 105 122 122 105 104 072 040 045 104 065 000	.ASCII / BY/ .ASCII / TES/ .ASCII / TR/ .ASCII / ANS/ .ASCII /FER/ .ASCII /RED/ .ASCII /: #/ .ASCII /D5/<00	) <b>&gt;</b>	
011542 011545 011550 011553 011556 011561 011564 011567 011572 011575 011600 011603	045 116 045 101 111 057 117 040 102 125 106 106 105 122 040 101 104 104 122 105 123 123 040 050 063 062 040 102 111 124 123 051 072 040 045 117	.ASCII /D5/<00 .ASCII <00> P.AGB: ASCII /#N#/ .ASCII /AI/<57 .ASCII /O B/ .ASCII /UFF/ .ASCII /ER / .ASCII /ADD/ .ASCII /RES/ .ASCII /32 / .ASCII /BIT/ .ASCII /S):/ .ASCII / #0/		
011606 011611 011614 011616 011621 011624 011627 011632 011635 011640 011643 011646 011651	066 045 101 040 045 117 066 000 045 116 045 101 103 117 116 124 105 116 124 123 040 117 106 040 122 105 124 125 122 116 040 120 101 103 113 105 124 072 045 116 000	.ASCII /6#A/ .ASCII / #0/ .ASCII / #0/ .ASCII /6/<00: P.AGC: .ASCII /#N#/ .ASCII /ACO/ .ASCII /NTE/ .ASCII /NTS/ .ASCII / OF/ .ASCII / TUR/ .ASCII / ACK/ .ASCII /#N/<00		
011657 011660 011663 011666 011671 011674 011677 011702	000 045 116 045 101 115 105 123 123 101 107 105 040 124 131 120 105 072 040	.ASCII <00> P.AGD: .ASCII /#N#/ .ASCII /AME/ .ASCII /SSA/ .ASCII /GE / .ASCII /TYP/ .ASCII /E: / .ASCII <00><00		
011704 011707 011712 011715 011720 011723 011726 011731	000 000 045 116 045 101 115 105 123 123 101 107 105 040 116 125 115 102 105 122 123 072 040	P.AGE: .ASCII /MNB/ .ASCII /AME/ .ASCII /SSA/ .ASCII /GE / .ASCII /NUM/ .ASCII /BER/ .ASCII /S: /		
011732 011735	045 116 045 101 115 105	P.AGF: .ASCII <00> .ASCII /#N#/ .ASCII /AME/		

ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Page 83 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
011740 011743 011746 011751 011754 011757	123 123 101 107 105 040 105 122 122 040 103 117 104 105 123 072 040 000	.ASCII /SSA/ .ASCII /GE / .ASCII /ERR/ .ASCII / CO/ .ASCII /DES/ .ASCII /: /<00		
011762 011765 011770 011773 011776 012001 012004	045 116 045 101 102 131 124 105 040 116 125 115 102 105 122 072 040 045 104 063 000	P.AGG: .ASCII /#N#/ .ASCII /ABY/ .ASCII /TE / .ASCII /NUM/ .ASCII /BER/ .ASCII /: #/ .ASCII /D3/<00		
012007 012010 012013 012016 012021 012024 012027 012032 012035	000 045 116 045 101 122 101 116 104 117 115 040 127 122 111 124 124 105 116 040 127 117 122 104 040	P.AGH: ASCII <00> ASCII /#N#/ .ASCII /ARA/ .ASCII /NDO/ .ASCII /M W/ .ASCII /RIT/ .ASCII /TEN/ .ASCII / WO/ .ASCII /RD /		
012040 012043 012046 012051 012054 012057 012062 012065 012070	072 045 102 061 066 000 045 116 045 101 122 101 116 104 117 115 040 122 105 101 104 040 127 117	ASCII /:#8/ ASCII /16/<00 P.AGI: ASCII /#N#/ ASCII /ARA/ ASCII /NDO/ ASCII /M R/ ASCII /EAD/ ASCII / WO/	0>	
012073 012076 012101 012104 012107	122 104 040 142 151 156 072 045 102 061 066 045 101 040 157 143 164 072 045 117 066 000 045 116 045	.ASCII /RD / .ASCII /bin/ .ASCII /:#8/ .ASCII /16#/ .ASCII /A o/ .ASCII /ct:/ .ASCII /#06/ .ASCII <00>		
012115 012116 012121 012124 012127 012132 012135 012140 012143	101 103 122 116 040 072 040 045 117 066 045 101 040 040 045 117 066 000	P.AGJ: .ASCII /#N#/ .ASCII /ACR/ .ASCII /N :/ .ASCII / #0/ .ASCII /6#A/ .ASCII /06/<0/ .ASCII /06/<0/	0>	
012144 012147 012152 012155 012160 012163 012166	045 101 040 055 040 125 116 113 116 117 127 116 040 072 040 045 104 062 000 000	P.AGK: .ASCII /#A / .ASCII /- U/ .ASCII /NKN/ .ASCII /OWN/ .ASCII /#D2/ .ASCII <00><00	0>	

	ZRQAM1		D/RX EXER	TTEED				5 Dag 1007	10.27.14	SEQ 0084
	V01.2		ROTECTION					5-Dec-1983 5-Dec-1983		VAX-11 Bliss-16 V3-555 Page 84 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
	012170 012173 012176 012201 012204	045 055 116 117 040	101 040 113 127 103	040 125 116 116 117	P.AGL:	.ASCII .ASCII .ASCII .ASCII	/#A / /- U/ /NKN/ /OWN/ / CO/			
	012207 012212 012215 012220 012223 012226 012231 012234 012237 012242 012245 012250 012253 012254 012257 012262 012265 012270 012273 012274 012277 012302 012310 012313 012316	116 103 117 111 040 063	116 124 116 104 045 045	105 111 040 072 104 101		.ASCII .ASCII .ASCII .ASCII .ASCII	/NNE/ /CTI/ /ON / /ID:/ / %D/ /3#A/			
	012231 012234 012237 012242	040 045 101 114	055 116 103 122	000 045 124 040	P.AGM:	ASCII ASCII ASCII ASCII	/ -/<00> /#N#/ /ACT/ /LR /			
	012245 012250 012253 012254	106 107 000 045	114 123 116	101 072 045	P.AGN:	.ASCII .ASCII .ASCII	/FLA/ /GS:/ <00> /#N#/			
	012257 012262 012265 012270	101 111 106 107 000	125 124 114 123	116 040 101 072		.ASCII .ASCII .ASCII .ASCII	/AUN/ /IT / /FLA/ /GS:/			
-	012274 012277 012302 012305	045 101 104 105	116 105 040 123	045 116 115 123	P.AGO:	.ASCII .ASCII .ASCII	(00) /#N#/ /AEN/ /D M/ /ESS/			
	012310 012313 012316 012321	101 040 101 072	107 106 107 000	105 114 123 000		.ASCII .ASCII .ASCII .ASCII	/AGE/ / FL/ /AGS/ /:/<00><	00>		
	012321 012324 012327 012332 012335 012340	045 101 116 116 040	116 103 124 124	045 117 105 123	P.AGP:	.ASCII	/ACO/ /NTE/ /NTS/			
	012343 012346 012351 012354 012357 012362	040 120 057 120	117 104 040 117 101	106 125 111 040 103		.ASCII .ASCII .ASCII .ASCII	/ OF/ / DU/ /P I/ <57>/O / /PAC/			
	012357 012362 012365 012366	113 072 000 045	105 045 116 040	124 116 045 104	P.AGQ:	.ASCII .ASCII .ASCII .ASCII	/KET/ /:#N/ <00>			
	012365 012366 012371 012374 012377 012402 012405	101 122 105 103 122	040 111 122 124 040	104 126 040 114 124		.ASCII .ASCII .ASCII .ASCII	/A D/ /RIV/ /ER / /CTL/ /R T/			
	012410 012413 012416	101 105 040	102 040 101	114 075 104		ASCII ASCII ASCII	/ABL/ /E =/ / AD/			

ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Page 85 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
012421 012424 012427 012432 012434 012437 012442 012445 012450 012453 012456 012461	104 122 072 040 045 104 066 045 116 000 000 045 116 045 101 040 103 115 104 040 111 116 124 054 040 122 123 120 040 111 116 124 054 040 103	. ASC . ASC	II / #D/ II /6#N/ II <00><00> II /#N#/ II /A C/ II /MD / II /INT/ II /, R/ II /SP / II /INT/ II /, C/		
012464 012467 012472 012475 012500 012503 012506 012511 012514 012516 012521 012524 012527 012532 012535 012540 012540 012540 012540 012551 012554 012551 012554	117 115 115 101 116 104 040 122 111 116 107 040 075 040 101 104 104 122 072 040 045 104 066 045 116 000 045 116 045 101 040 101 114 114 040 120 101 103 113 105 124 123 040 111 116 040 115 105 123 123 101 107 105 040 101 122 105 101 000	. ASC . ASC	II /OMM/ II /AND/ II / RI/ II /NG / II /= A/ II /DDR/ II /: %/ II /D6%/ II /N/<00> II /MN%/ II /A A/ II /LL / II /PAC/ II /KET/ II /S I/ II /N M/ II /ESS/ II /AGE/ II /AR/		
012566 012571 012574 012577	000 045 116 045 101 040 101 114 114 040 122 105 124 125 122 116 040 120 101 103 113 105 124 123 040 111 116 040 101 122 105 101 000	P.AGT: ASC ASC ASC ASC ASC ASC ASC ASC ASC ASC	II <00> II /#N#/ II /A A/ II /LL / II /RET/ II /URN/ II / PA/ II / CKE/ II /TS /		
012602 012610 012613 012616 012620 012623 012626 012631 012634 012637 012642 012645 012650	045 116 045 101 040 101 104 104 122 072 040 045 104 066 045 101 040 040 040 040 040 120 101 103 113 105 124	P.AGU: ASC ASC ASC ASC ASC ASC ASC ASC	II /#N#/ II /A A/ II /DOR/ II /: #/ II /D6#/ II /A / II / / II / /		

ZRQAM1 VO1.2		RD/RX EX					5-Dec-1983 10: 5-Dec-1983 10:	27:14 27:04	VAX-11 Bliss-16 V3-555 Page 86 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (35)
012653 012656 012661	040 045 000	075 116	040		.ASCII	/=/ /#N/<00>			
012662 012665 012670 012673 012676 012701 012704	045 101 104 040 040 123 116	116 040 104 117 122 120 123	045 101 122 106 105 117 105	P.AGV:	.ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII	/#N#/ /A A/ /DDR/ / OF/ / RE/ /SPO/ /NSE/			
012707 012712 012715 012720 012723 012726 012731 012734	040 116 124 102 120 114 040 066	122 107 117 105 117 105 045	111 040 040 040 114 104		.ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII	/ RI/ /NG / /TO / /BE / /POL/ /LED/ / #D/ /6/<00>			
012736 012741 012744 012747 012752 012755 012760 012763 012766 012771	045 101 104 040 040 123 107 120 113 040	116 040 104 117 115 123 105 101 105 122 120	045 101 122 106 105 101 040 103 124 105	P.AGW:	.ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII	/#N#/ /A A/ /DDR/ / OF/ / ME/ /SSA/ /GE / /PAC/ /KET/ / RE/			
012777 013002 013005 013010 013013 013016 013021 013024 013027	123 116 040 116 123 124 117 124 124 045 000	123 122 107 114 040 111 123 117	117 105 111 040 117 120 116 040 040		ASCII	/SPO/ /NSE/ / RI/ /NG / /SLO/ /T P/ /OIN/ /TS / /TO / /#D6/ <00><00>			
013032 013034 013037 013042 013045 013050 013053 013056 013061 013064 013067 013072 013075 013100 013103	045 101 104 040 040 123 107 120 113 040 115 116 122 107	000 116 040 104 117 115 123 105 101 105 103 115 104 111	045 101 122 106 105 101 040 103 124 117 101 040 116 123	P.AGX:	ASCII	/MNM/ /A A/ /DDR/ / OF/ / ME/ /SSA/ /GE / /PAC/ /KET/ / CO/ /MMA/ /ND / /RIN/ /G S/			

ZRQAM1 VO1.2		RD/RX EXI					5-Dec-1983 5-Dec-1983	10:27:14 10:27:04	VAX-11 Bliss-16 V3-555 Page 87 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
013106	114	117	124		.ASCII	/LOT/			
013111	040	120	117		ASCII	/ PO/			
013114	111	116	124		.ASCII	/INT/			
013117	123	040	124		.ASCII	/S T/			
013122	117	040	045		.ASCII	10 %/			
013125	104	066	000		.ASCII	/D6/<00>			
013130	045	116	045	P.AGY:	ASCII	/WNW/			
013133	101	040	103		.ASCII	/A C/			
013136 013141	157	156	164		ASCII	/ont/			
013141	145	156	164		ASCIT	/ent/			
013144	163	040	157		.ASCII .ASCII .ASCII	18 0/			
013147	146	040	123		ASCIT	/F S/			
013152	101	040	122		.ASCII	/A R/			
013155	145	147	151		.ASCII	/egi/			
013160	163	164	145		ASCII	/ste/			
013163	162	000	000		ASCII	/r/<00><	00>		
013166	045	116	045	P.AGZ:	ASCIT	/MNS/			
013171	101	104	125		.ASCII	/ADU/			
013174	120	114	iii		ASCII	/PLI/			
013174 013177	120 103	101	124		ASCII	/CAT/			
013202	105	040	125		ASCII	/E U/			
013205	116	111	125 124		ASCII	/NIT/			
013210	072	045	104		ASCTT	/:#D/			~ 기계 기계 하는 사람들이 있는 이 사이 함께 있는 사람들도 기계하다면 다음
013213	062	045	101		ASCIT	/2#A/			그는 내 없다. 그리지 않는 하늘이 내가 되어 나는 이렇게 하는데 되었다.
013202 013205 013210 013213 013216	040	101	124		.ASCII .ASCII .ASCII	/ AT/			네
013221	040	iii	120		ASCII	/ IP/			
013221 013224 013227 013232 013235 013240 013243	072	040	045		ASCII	1: 4/			
013227	117	066	000		ASCII	/06/<00>			
013232	045	116	045	P.AHA:	.ASCII	/SNS/			트리티스 발매 길이 이미리는 나를 하고 있는 그렇게 있는 생각을 보였다.
013235	101	115	117		ASCIT	/AMO/			
013240	122	105	040		.ASCII	/RE /			강마다 마르네트 마리 나는 가는 그리는 아니라 하다 하다 하는데 다른데 다른데 다른데 다른데 다른데 다른데 다른데 다른데 다른데 다른
013243	124	110	101		.ASCII	/THA/			
013246 013251 013254 013257	116	040	045		.ASCII	/N %/			그렇게 하면 있는 사람이 그 사람들이 얼마나 하는 것 같아 주면 하면 없다.
013251	104	061	045		.ASCII	/D15/			
013254	101	040	104		.ASCII	/A D/			장마이 이 그는 그는 그리면 사람들이 얼마나 하는데 되었다면 생각이 되었다면 생각이 되었다.
013257	111	106	106		ASCTT	/IFF/			어린 내가 가는 사람들이 가장하는 것 같아 하지만 하는 것이 없다면 하다 하다 하다.
013262 013265	105	122	105		. ASCII	/ERE/		-	목 사람이 그는 하는 경영 하는 하는 사람들은 그 가장 살아 바라가 하셨다.
013265	116	124	040		ASCII ASCII ASCII ASCII	/NT /			
013270 013273 013276 013301 013304 013306	111	120	040		. ASCII	/IP /			
013273	101	104	104		. ASCII	/ADD/			
013276	122 123	105	123 123		. ASCII	/RES/			
013301	123	105	123		ASCII ASCII ASCII ASCII	/SES/			[ - 10 - 10 - 10 - 10 - 10 - 10 - 10 - 1
013304	000 045	000			.ASCII	<00><00>			요요하는 그는 그리고 하는 이 얼마나 아이를 모든 것이다.
015306	045	101	055	P.AHB:	. ASCII	/8A-/			
013311	040	123	105		. ASCII	/ SE/			요즘 가는 이 사람이 하는 것이 없었다. 나를 보는 사람들은 사람이 되었다.
015514	121	125	105		. ASCII	/QUE/			그 그들은 그 그는 사람이 아이들이 얼마나 사람이 되었다.
013311 013314 013317 013322	116	123 125 124 114	000		Wactt	/NTI/			그렇게 하는 경우 살아 있는 사람들이 얼마나 되는 것이 되었다.
013322	101	114	000		. ASCII	/AL/<00>			[
013325	000				. ASCII	<00>			보다는 그는 그리고 얼마를 잃으로 그렇게 하는 아이를 보다 하게 되는 것 같아.
013325 013326 013331	045	101	055	P.AHC:	. ASCII	/SA-/			
015551	040	103	122		. ASCII	/ CR/			
013334	105	104	111		.ASCII	/EDI/			
013337	124	040	116		. ASCII	/T N/			

TO THE REAL PROPERTY.				111		
ZRQAM1 VO1.2	RD/RX EXER PROTECTION			5-Dec-1983 5-Dec-1983	10:27:14 10:27:04	VAX-11 Bliss-16 V3-555 Page 88 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
013342 013345 013350 013353 013356 013361 013364 013367 013372	117 124 106 111 101 124 117 116 045 101 040 115 111 116 105 116 116 103	111 103 111 000 055 101 124 101 105	.ASCII / MA/ .ASCII /INT/ .ASCII /ENA/ .ASCII /NCE/	00>		
013375 013376 013401 013404 013407 013412	000 045 101 040 104 124 101 122 101 000 000	055 P.AHE: 101 107 115	.ASCII <00> .ASCII /#A-/ .ASCII / DA/ .ASCII / TAG/ .ASCII /RAM/ .ASCII <00><			
013414 013417 013422	045 101 105 101 000 000	122 P.AHF:	.ASCII /#AR/ .ASCII /EAD/ .ASCII <00><			
013424 013427 013432	045 101 122 111 105 000	127 P.AHG:	.ASCII /#AW/			
013434 013437 013442	045 101 103 103 123 123 000	101 P.AHH: 105 000	.ASCII /#AA/ .ASCII /CCE/ .ASCII /SS/<			
013445 013446 013451 013454 013457	045 101 116 040 111 116	117 P.AHI: 114 105	.ASCII /≰AO/ .ASCII /N L/ .ASCII /INE/			
013460 013463 013466 013471 013474	045 101 105 124 103 117 124 122 114 040	123 P.AHJ: 040 116 117 103	.ASCII <00> .ASCII /#AS/ .ASCII /ET / .ASCII /CON/ .ASCII /TRO/ .ASCII /L C/			
013477 013502	110 101 056 000 045 101 105 124	122 107 P.AHK:	.ASCII /HAR/ .ASCII /./<0 .ASCII /#AG/ .ASCII /ET /	00>		
013512 013515 013520 013523	124 040 124 101 125 123	123 123 124 000	ASCII /DUS/ ASCII /T S/ ASCII /TAT/ ASCII /US/	:00>		
013504 013507 013512 013515 013520 013523 013526 013531 013534 013537 013542 013545 013550	045 101 130 105 125 124 040 123 120 120 111 105	105 P.AHL: 103 105 125 114 104	.ASCII /#AE/ .ASCII /XEC/ .ASCII /UTE/ .ASCII / SU/ .ASCII /PPL/ .ASCII /IED/			
013550 013553 013556 013561 013564	040 120 107 000 045 101 130 105 125 124	122 000 105 103 105 P.AHM:	.ASCII / PR/	00><00>		

							L /	
ZRQAM1 VO1.2		RD/RX EXE PROTECTION					5-Dec-1983 5-Dec-1983	VAX-11 Bliss-16 V3-555 Page 89 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (35)
013567	040	114	117		.ASCII	/ LO/		
013572	103	101	114		.ASCII	/CAL/		
013575 013600	107	120	122		.ASCII	/ PR/		
013602	045	101	123	P. AHN:	.ASCII	/G/<00>		
013605	105	116	104	r.Aniv.	ASCII	/END/		
013610	040	104	101		ASCII	/ DA/		
013613	124	101	000		. ASCII	/TA/<00>		
013616 013621	045	101	122	P. AHO:	.ASCII	/#AR/		
013621	105	103	105		. ASCII	/ECE/		
013624 013627	111	126	105		. ASCII	/IVE/		
013627	040	104	101		. ASCII	/ DA/		
013632 013635	124	101	000		.ASCII	/TA/<00>		
013636	000 045	101	101	P. AHP:	.ASCII	<00>		
013641	102	117	122	F.MM:	.ASCII	/#AA/ /BOR/		
013644	124	000	155		ASCII	/T/<00>		
013644 013646	045	101	123	P. AHQ:	ASCII	/#AS/		
013651	120	111	116		ASCIT	/PIN/		
013651 013654 013657 013662 013665 013670	055	104	117		.ASCII .ASCII .ASCII .ASCII	/-00/		
013657	127	116	040		. ASCII	/WN /		
013662	111	107	116		. ASCII	/IGN/		
013665	117	122	105		.ASCII	/ORE/		
013672	104 045	000	127	D AND.	.ASCII	/D/<00>		
013675	124	101	123 114	P.AHR:	.ASCII	/#AS/ /TIL/		
013700	114	040	103		ASCTT	/L C/		
013700 013703	117	116	116		.ASCII	/ONN/		
013706	105	103	124		ASCII	/ECT/		
013711	105	104	000		.ASCII	/ED/<00>		
013714	045	101	104	P. AHST	. ASCII	/#AD/		
013717 013722 013725	125	120	114		. ASCII	/UPL/		
013722	111	103	101		.ASCII	/ICA/		
013730	124 125	105 116	040		.ASCII	/TE /		
013733	124	040	111		.ASCII	/UNI/		
013736	125	115	102		.ASCII	/T N/		
013741	105	122	000		ASCIT	/ER/<00>		
013744 013747 013752 013755 013760	045	122 101	101	P.AHT:	.ASCII	/SAA/		
013747	114	122	105		. ASCII	/LRE/		
013752	101	104	131		.ASCII .ASCII .ASCII	/ADY/		
013755	040	117	116		. ASCII	/ ON/		
013760	114	111	116		. ASCII	/LIN/		
013766	105 045	000	000 123 114	D ALEL	.ASCII	/E/<00><	00>	
013771	124	101	114	P.AHU:	.ASCII	/#AS/ /TIL/		
013763 013766 013771 013774 013777	114	040	117		ASCIT	10/		
013777	116	114	iii		.ASCII .ASCII .ASCII	/NLI/		
014002	116	105	000		.ASCII	/NE/<00>		
014005	000				. ASCII	<00>		
014006	045	101	125	P.AHV:	. ASCII	/SAU/		
014011	116	111	125 124 116		. ASCII	/NIT/		
014014	040	125	116		.ASCII	/ UN/		

	700000										SEQ 0091	
-	ZRQAM1		RD/RX EXER					5-Dec-1983	10:27:14	VAX-11 Bliss-16 V3-555	Page	91
	V01.2		PROTECTION	IABLE				5-Dec-1983	10:27:04	DISK\$USER2:[DIETZ.RDRX]ZRQACO	.BL1;82 (35)	
	014255	105	122	116		ACCTT	/EDN/					
1	014260	101	114	040		.ASCII	/ERN/					
	014263	104	iii	101		.ASCII						
1	014266	107				.ASCII	/DIA/					
1	014271	123	116	117		.ASCII	/GNO/					1
	014274	103	124 123	000		.ASCII	/STI/ /CS/<00>					
1	014277	000	153	000		ASCII						
1	014277	045	101	042	D AU7.	.ASCII	<00>					
1	014300 014303	106	101	042	P.AHZ:	. ASCII	/#A"/					
	014306	103	105	122 104		ASCII	/FOR/					
1	014311	040				ASCII	/CED/					
1	014314	122	105 042	122 040		.ASCII .ASCII .ASCII	/ ER/					
1	014317	104				ASCII	/R" /					
1	014322	105	105 103	124 124		.ASCII	/DET/					
1	014325	105	104	040		.ASCII	/ECT/					
1	014330	127	110	111		.ASCII	/ED /					
1	014333	114	105	040		.ASCII						
1	014336	101	103	103		.ASCII	/LE /					
1	014341	105	123	123		ASCTT	/ESS/					
1	014344	111	116	107		.ASCII	/ING/					
1	014347	040	106	103		ASCII	/ FC/					
1	014352	124	040	117		ASCII	/T 0/					
1	014347 014352 014355	122	040	122		ASCII	/R R/					
1	014360	103	124	000		ASCIT	/CT/<00>					
1	014363	000		-		ASCII ASCII ASCII	<00>					
1	014364	045	101	123	P.AIA:	ASCIT	/#AS/					
1	014367	105	103	124		.ASCII	/ECT/					
1	014372 014375	117	122	040		.ASCII	/OR /					
1	014375	127	122	111		.ASCII	/WRI/					
1	014400	124	124	105		ASCII	/TTE/					
1	014403	116	040	127		ASCII ASCII	/N W/					
-	014406	111	124	110		. 2CCII	/ITH/					
1	014411	040	042	106		. ASCII	/ "F/					
1	014414	117	122	103		. ASCII	/ORC/					
1	014417	105	104	040		. ASCII	/ED /					
1	014422	105	122	122		. ASCII	/ERR/					
-	014425	042	040	115		. ASCII	/" M/					
1	014430	117	104	111		. ASCII	/ODI/					
1	014433	106	000	105		. ASCII	/FIE/					
1	014436	122	000			.ASCII	/R/<00>					
1	014440 014443	045	101	106	P.AIB:	. ASCII	/SAF/					
	014446	103	124	040		. ASCII	/CT /					
1	014451	117	122	040		.ASCII	/OR /					
	014454	040	103	124		. ASCII	/RCT/					
1	014457	040	125 105	116		.ASCII .ASCII .ASCII	/ UN/					
Ĭ.	014462	122	103	101		. ASCII	/REA/					
1	014465	114	101 105	102 040		.ASCII	/DAB/					
-	014470	055	040	111		.ASCII	/LE /					1
-	014473	116	126	101		.ASCII	/- I/					
1	014476	114	111	104		.ASCII	/NVA/					
4	014501	040	123	105		.ASCII	/LID/					
	014504	103	123 124	105 117		ASCII	/ SE/					
				•••		. MJCII	, 010,					

				DO	
ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Page 92 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
014507 014512 014515 014520 014523 014526 014531 014534 014537 014542 014545	122 040 110 105 101 104 105 122 000 045 101 110 105 101 104 105 122 040 103 117 115 120 101 122 105 040 105 122 122 040 050 126 101 114 111 104	P.AIL: ASCII	/EAD/ /ER/<00° /#AH/ /EAD/ /ER / /COM/ /PAR/ /E E/ /RR / /VA/ /LID/		
014553 014566 014561 014564 014567 014572 014575 014576 014601	040 110 105 101 104 105 122 040 116 117 124 040 106 117 125 116 104 051 000 045 101 106 103 124 040	ASCII	/ ME/ /ADE/ /R N/ /OT / /FOU/ /ND)/ (OO>		
014604 014607 014612 014615 014620 014623 014626 014631	117 122 040 122 103 124 040 125 116 122 105 101 104 101 102 114 105 040 055 040 104 101 124 101	ASCI ASCI ASCI ASCI ASCI ASCI ASCI	/ OR / I / RCT/ I / UN/ I / REA/ I / DAB/ I / LE / I / - D/		
014634 014637 014642 014645 014650 014652 014655 014660 014663	040 123 131 116 103 040 124 111 115 105 117 125 124 000 045 101 104 101 124 101 040 123 131 116 103 040	ASCI ASCI ASCI ASCI ASCI ASCI ASCI ASCI	/ SY/   /NC /   /TIM/   /EOU/   /T/ <oo>   /#AD/   /ATA/   / SY/   /NC /</oo>		
014666 014671 014674 014677 014702 014705 014710 014713 014716	116 117 124 040 106 117 125 116 104 040 050 104 101 124 101 040 123 131 116 103 040 124 111 115 105 117 125	.ASCI .ASCI .ASCI .ASCI .ASCI .ASCI .ASCI	I / FO/ I /UND/ I / (D/ I /ATA/ I / SY/ I /NC / I /TIM/ I /EOU/		
014721 014724 014727 014732 014735 014740	124 051 000 045 101 106 103 124 040 117 122 040 122 103 124 040 125 116	P.AIF: .ASCI .ASCI .ASCI .ASCI .ASCI	I /#AF/ I /CT / I /OR / I /RCT/		

			CO	
ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555
V01.2  014743 014746 014751 014754 014757 014762 014765 014776 015001 015004 015007 015012 015015 015020 015023 015026 015031 015034 015037 015042 015045 015050 015053 015054 015057 015062 015065	PROTECTION TABLE  122	ASCII /C	5-Dec-1983 10:27:04  REA/ DAB/ LE / U/ NCO/ RRE/ CTA/ BLE/ EC/ CRE/ CTA/ BLE/ CC/ CRE/ CC/ CRE/ CC/ CRE/ CC/ CC/ CC/ CC/ CC/ CC/ CC/ CC/ CC/ C	VAX-11 Bliss-16 V3-555 Page 93
015073 015076 015101 015104 015107 015112 015115 015120 015123 015126 015130 015133 015136 015141 015144 015147 015155 015160 015163 015166 015171	124 040 102 114 117 103 113 040 101 126 101 111 114 101 102 114 105 040 050 122 103 124 040 106 125 114 114 051 000 045 101 104 111 123 113 040 116 117 124 040 106 117 122 115 101 124 124 105 104 040 127 111 124 110 040 065 061 062 040 102 131 124 105 040 123 105 103 124	. ASCII / / . ASCI	B	

							DO		
ZRQAM1		RD/RX EXE	DCTCED				E D 1007	10.07.14	SEQ_0094
V01.2		PROTECTIO					5-Dec-1983 5-Dec-1983		VAX-11 Bliss-16 V3-555 Page 94
*****			JIV THOLL				2-066-1903	10:27:04	DISK \$USER2: [DIETZ.RDRX]ZRQACO.BL1;82 (35)
015177	117	122	123		.ASCII	/ORS/			
015202	000	000			. ASCII	<00><00>			
015204	045	101	104	P.AIK:	.ASCII	/SAD/			
015207	111	123	113		. ASCII	/ISK/			
015212	040	116	117		.ASCII	/ NO/			
015215	124	040	106		, ASCII	/T F/			
015220	117	122	115		.ASCII	/ORM/			
015223	101	124	124		.ASCII	/ATT/			
015226	105	104	040		ASCII	/ED /			
015231	117	122	040		.ASCII	/OR /			나왔다. 하는 사람들은 그는 얼룩됐다면 모든 사람들이 모든 그림에 모른
015234	106	103	124		.ASCII	/FCT/			
015237	040	103	117		.ASCII	/ CO/			
015242	122	122	125		.ASCII	/RRU/			
015245	120	124	105		ASCII	/PTE/			[전투 ] 사람 및 경기 (대) 시간 시간 시간 (대) (대) 사람들이 되었다.
015250	104	000			ASCIT	/D/<00>			하다 하다 하나 보다를 보고 있다면 보고 그리고 있다면 없는 것이다. 그리고 있다면 다 없다.
015252	045	101	117	P.AIL:	.ASCII .ASCII .ASCII	/#A0/			
015255	116	105	040	·	ASCIT	/NE /			
015260	123	131	115		ASCII	/SYM/			그리고 하면 그리고 어떻게 하는데 그는 그 그 그리고 있다.
015263	102	117	114		ASCIT	/BOL/			
015266	040	105	103		.ASCII	/ EC/			마이 (1981) (Biggs of Section )
015271	103	040	105		ASCIT	/CE/			
015274	122	122	000		ASCII	/RR/<00>			경기 없는 이 학생들은 그 아이에 가르는 사람들이 되었다면 하다.
015277	000	155	000		ASCII	<00>			
015212 015215 015220 015223 015226 015231 015234 015237 015242 015245 015250 015250 015252 015260 015263 015263 015266 015271 015274 015277 015300 015303	045	101	124	P.AIM:	ASCII ASCII ASCII ASCII	/#AT/			
015303	127	117	040	F.AIII;	ASCII				
015306	123	131	115		ASCII	/WO /			
015306 015311 015314	102	117	114		.ASCII	/SYM/			
015314	040	105	103		.ASCII	/BOL/			
015317	103				ASCII	/ EC/			
015317 015322 015325	122	040	105 000		.ASCII	/C E/			
015325	000	122	000		ASCII	/RR/<00>			그리 가능을 비는 그는 것은 마음을 받아 있는 것이 없는 것 같아 없었다.
015326	045	101	124	D ATM.	.ASCII	<00>			
015326 015331 015334 015337	110	101	124 105	P.AIN:	.ASCII	/#AT/			
015334	105	040	123		.ASCII	/HRE/			
015337	131	115	102		.ASCII	/E S/			[18] [18]
015342	117				.ASCII	/YMB/			
015345	105	114	040		.ASCII .ASCII .ASCII	/OL / /ECC/ / ER/			뭐 되었는 사람은 하루하나의 말이 하는 데로 모든데 되었다.
015350	040	103 105	103		.MSCII	/ECC/			
015353	122	000	122		ASCII	/ ER/	00.		
015350 015353 015356 015361 015364 015367	045		106	D ATO.	.ASCII	/R/<00><0	00>		
015361	117	101	106	P.AIO:	. ASCII	/#AF/			그렇게 그녀를 가지 않니까 하나 가는 것이 되었다. 그리고 하다 하다.
015364	040	125	122 131		.ASCII	/OUR/			
015367		123	117		. MSCII	/ SY/			
015372	115	102	117		ASCII	/MB0/			
015375	103	040	105		.ASCII .ASCII .ASCII	/L E/			
015400	105	103 122	040		. ASCII	/CC /			그냥 내가는 어느님, 하는 것이 있는 사이를 하는 것이 되었다. 그렇게 살아왔다.
015403	000	155	122		.ASCII	/ERR/			일 이 경기를 하는 것이 되었다. 그렇게 되는 것은 것은 그리고 있다면 없다면 하셨다.
015404	045	101	106	D ATD	.ASCII	<00>			
015407		101	106	P.AIP:	.ASCII	/#AF/			그런 사이는 사이를 하는 것들이 없는 것으로 살이고 있다면 걸었다.
015412	040	126	105		.ASCII	/IVE/			
015415	115	123	131		.ASCII	/ SY/			
015420	114	102	117		. ASCII	/MB0/			
015420 015423	103	040	105 040		.ASCII	/L E/			그는 그리는 마음이 이번 이 없는 그 그는 사람이 하면 하면 되었다면 생겨 있습니다.
013423	103	103	040		.ASCII	/CC /			1900년 1일

							-0		
ZRQAM1 VO1.2		RD/RX EXP						10:27:14 10:27:04	VAX-11 Bliss-16 V3-555 Page 95 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
015426	105	122	122		.ASCII	/ERR/			
015431	000	166	166		ASCII	<00>			
015432	045	101	122	D ATO.	.ASCII				
013432		101	123	P.AIQ:	.ASCII	/#AS/			
015435	111	130	040		.ASCII	/IX /			
015440	123	131	115		. ASCII	/SYM/			
015443	102	117	114		.ASCII	/BOL/			
015446	040	105	103		.ASCII	/ EC/			
015451	103	040	105		. ASCII	/C E/			
015454 015457	122	122	000		.ASCII	/RR/<00>			
015457	000				. ASCII	<00>			
015460	045	101	123	P.AIR:	. ASCII	/#AS/			
015463	105	126	105		.ASCII	/EVE/			
015466	116	040	123		.ASCII	/N S/			
015471	131	115	102		ASCII	/YMB/			
015474	117	114	040		ASCII	/OL /			
015477	105	103	103		ASCII				
015502					.ASCII	/ECC/			
012205	040	105	122		.ASCII	/ ER/			
015505	122	000	000		.ASCII	/R/<00><00>			
015510	045	101	105	P.AIS:	. ASCII	/#AE/			
015513	111	107	110		. ASCII	/IGH/			
015516	124	040	123		.ASCII	/T S/			
015521	131	115	102		.ASCII	/YMB/			
015524	117	114	040		.ASCII	/OL /			
015527	105	103	103		.ASCII	/ECC/			
015510 015513 015516 015521 015524 015527 015532 015535 015540 015543 015546 015551 015554	040	105	122		.ASCII	/ ER/			
015535	122	000	000		.ASCII	/R/<00><00>			
015540	045	101	103	P.AIT:	ASCII	/#AC/			
015543	117	122	122	r.na	ASCII	/ORR/			
015546	105	103	124		ASCII	/ECT/			
015551	101	102	114		ASCII				
015554	105				.ASCII	/ABL/			
015557		040	105		.ASCII	/E E/			
015562	122	122	040		. ASCII	/RR /			
015562 015565 015570	111	116	040		.ASCII	/IN /			
015570	105	103	103		.ASCII	/ECC/			
015570	040	106	111		.ASCII	/ FI/			
015573	105	114	104		.ASCII	/ELD/			
015576	000	000			. ASCII	<00><00>			
015600	045	101	125	P.AIU:	. ASCII	/SAU/			
015603	116	111	124		. ASCII	/NIT/			
015603 015606 015611 015614 015617 015622 015625 015630 015633	040	111 123 124	117 127		ASCIT	/ SO/			
015611	106	124	127		ASCII	/FTW/			
015614	101	122	105		ASCII	/ARE/			
015617	040	127	122		ASCIT	/ WR/			
015622	111	124	105		ASCIT	/ITE/			
015625	040	120	122		ASCII ASCII ASCII ASCII	/ PR/			
015630	117	124	122 105		ASCII	/OTE/			
015633	103	124	105		ACCTT				
015636	104	000	103		. ASCII	/CTE/			
015640	045		125	0 674	. ASCII	/D/<00>			
015640 015643		101	125	P.AIV:	.ASCII	/#AU/			
015646	116	111	124		. ASCII	/NIT/			
015646	040	110	101		. ASCII	/ HA/			
015651	122	104	127		.ASCII	/RDW/			
015654	101	122	105		. ASCII	/ARE/			

ZRQAM1		RD/RX EX	ERCISER			5-Dec-1983 10:27:14	VAX-11 Bliss-16 V3-555 SEQ 0096 Page 96
V01.2		PROTECTIO	ON TABLE			5-Dec-1983 10:27:04	DISK USER2: [DIETZ.RDRX]ZRQACO.BL1;82 (35)
015657	040	127	122		.ASCII	/ WR/	
015662	111	124	105		.ASCII	/ITE/	10 10 전에 가지하게 되었습니다. 그 사람이 되었습니다. 그런 나는 이 사람들이 되었습니다.
015665	040	120	122		.ASCII	/ PR/	[[[[[] [[] [[] [[] [] [] [] [] [] [] []
015670	117	124	105		.ASCII	/OTE/	나이라는 그 아무리는 내용 사람이 나를 보면 되었다. 그런 보는 그리
015673	103	124	105		ASCII	/CTE/	
015676	104	000	103		ASCIT	/D/<00>	기는 이 그리게 경영된 가게 된 사람들은 전환 경영 이 지난 사람들은 이 이 때문
015700	045		117	D ATH.	.ASCII		
015700 015703 015706		101		P.AIW:	.ASCII .ASCII .ASCII	/#A0/	"하게 되지 않는데 한다면 무슨 사람들이 얼마나 아니다.
015705	104	104	040		. ASCII	/00 /	
015706	124	122	101		. ASCII	/TRA/	
015711	116	123	106		.ASCII	/NSF/	
015714	105	122	040		.ASCII	/ER /	
015717	101	104	104		.ASCII	/ADD/	
015722	122	105	123		.ASCII	/RES/	
015725	123	000	000		. ASCII	/S/<00><00>	
015725 015730	045	101	117	P.AIX:	.ASCII	/#AO/	
015733	104	104	040		. ASCII	/DD /	사람들은 사람들은 사람들이 되었다면 하는 것이 없었다면 하는 것이 없었다.
015736	102	131	124		. ASCII	/BYT/	
015741	105	040	103		.ASCII	/E C/	
015744	117	125	116		.ASCII	/OUN/	
015747	124	000	000		ASCIT	/T/<00><00>	
015747 015752 015755 015760	045	101	116	P.AIY:	.ASCII	/#AN/	그 얼마나 얼마나 그 얼마나 나는 얼마나 얼마나 얼마나 얼마나 없었다.
015755	117	116	055	r.nai.	ASCIT	/ON-/	
015760	105	130	111		.ASCII	/EXI/	
015763	123	134	105		ASCII	/EXI/	
015766	123	124	105		.ASCII	/STE/	
015771	116	124	040		.ASCII	/NT /	
015771	110	117	123		. ASCII	/HOS/	
015774	124	040	115		.ASCII	/T M/	
015777	105	115 131	117		. ASCII	/EMO/	
016002	122	151	000		.ASCII	/RY/<00>	
016005	000				.ASCII	<00>	
016006	045	101 123	110	P.AIZ:	.ASCII	/#AH/	
016011	117	123	124		. ASCII	/OST/	
016014	040	115	105		. ASCII	/ ME/	
016017	115	117	122		.ASCII	/MOR/	
016022	131	040	120		. ASCII	/Y P/	
016025	101	122	111		.ASCII	/ARI/	
016030	124	131	040		. ASCII	/TY / /ERR/	
016033	105	122	122		.ASCII	/ERR/	
016036	000	000			.ASCII	<00><00>	
016040	045	101	103	P.AJA:	.ASCII	/MAC/	
016043	117	115	115		ASCIT	/OP#1/	
016046	101	116	104		.ASCII	/AND/	
016051	040	124	111		ASCIT	/ TI/	
016054	115	117	125		ASCTT	/MOU/	
016057	124	040	117		ASCTT		
016054 016057 016062	122	040	111 125 117 122		.ASCII .ASCII .ASCII	/T 0/ /R R/	
016065	105	124	122		ASCII	/ETD/	
016070	131	040	114		.ASCII	/ETR/	
016073			111		ASCTT.	/Y L/	
016076	111	115	111		.ASCII	/IMI/	
016101	124	040	105		. ASCII	/T E/	
016104	130	103	105		.ASCII	/XCE/	
016104	105	104	105		.ASCII	/EDE/	
016107	104	000	000		.ASCII	/D/<00><00>	

	ZRQAM1 VO1.2		RD/RX EXE					5-Dec-1983 5-Dec-1983	VAX-11 Bliss-16 V3-555 Page 97 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
A COLOR OF THE COL	016112 016115 016120 016123 016126 016131 016134 016137 016142 016145 016150 016153	045 105 101 132 057 123 111 111 122 126 122	101 122 114 105 104 105 101 132 040 105 125	123 111 111 122 105 122 114 105 117 122 116	P.AJB:	.ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII	/#AS/ /ERI/ /ALI/ /ZER/ <57>/DE/ /SER/ /IAL/ /IZE/ /R O/ /VER/ /RUN/		
	016156 016161 016164 016167 016170	040 040 104 122 000 045	117 125 105 125	122 116 122 116	P.AJC:	.ASCII .ASCII .ASCII .ASCII .ASCII	/ OR/ / UN/ /DER/ /RUN/ <00> /#AE/		
And the same of th	016173 016176 016201 016202 016205	104 105 000 045 116	103 122 101 103	040 122 111 117	P.AJD:	.ASCII	/DC / /ERR/ <00> /#AI/ /NCO/		
	016210 016213 016216 016221 016224	116 123 116 111 105	123 124 124 116 122	111 105 040 124 116		.ASCII .ASCII .ASCII .ASCII .ASCII .ASCII	/NSI/ /STE/ /NT / /INT/ /ERN/		
AND THE PERSON NAMED IN COLUMN TWO IS NOT THE OWNER.	016227 016232 016235 016240 016243 016246	101 104 101 124 103 122	114 101 040 122 124 105	040 124 123 125 125 000		.ASCII .ASCII .ASCII .ASCII .ASCII	/AL / /DAT/ /A S/ /TRU/ /CTU/ /RE/<00>		
The same of the same with the same of the	016251 016252 016255 016260 016263 016266 016271 016274	000 045 122 105 117 101 040 115	101 111 040 115 116 124 105	104 126 103 115 104 111	P.AJE:	.ASCII .ASCII .ASCII .ASCII .ASCII	<pre>&lt;00&gt; /#AD/ /RIV/ /E C/ /OMM/ /AND/ / TI/ /MEO/</pre>		
	016274 016277 016302 016305 016310 016313 016316 016321	125 050 040 123 116 040 040	124 116 122 120 123 117 123	040 117 105 117 105 122 105		.ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII	/UT / /(NO/ / RE/ /SPO/ /NSE/ / OR/ / SE/		
The state of the s	016324 016327 016332 016335 016340	105 111 117 114 105	113 116 115 105 051	040 103 120 124 000		ASCII ASCII ASCII ASCII	/EK / /INC/ /OMP/ /LET/ /E)/<00>		

				110	
ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Page 98 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
016343 016344 016347 016352 016355 016360 016363 016366 016371 016374 016377 016402 016405 016410 016413	000 045 101 103 124 114 122 040 104 105 124 105 103 124 105 104 040 124 122 101 116 123 115 111 123 123 111 117 116 040 117 122 040 120 122 117 124 117 103 117 114 040 105 122 122 000	P.AJF: ASCII	<pre>&lt;00&gt; /#AC/ /TLR/ / DE/ /TEC/ /TED/ / TR/ /ANS/ /MIS/ /SIO/ /N O/ /R P/ /ROT/ /OCO/ /L E/ /RR/&lt;00&gt;</pre>		
016421 016422 016425 016430 016433 016436 016441 016444	000 045 101 120 117 123 111 124 111 117 116 040 105 122 122 040 050 115 111 123 055 123 105 105 113	P.AJG: ASCII .ASCII	<00> /#AP/ /OSI/ /TIO/ /N E/ /RR / /(MI/ /S-S/ /EEK/		
016452 016454 016457 016462 016465 016470 016476 016501 016504 016507 016512 016515 016520 016523	051 000 045 101 114 117 123 124 040 122 105 101 104 057 127 122 111 124 105 040 122 105 101 104 131 040 104 125 122 111 116 107 057 102 105 124 127 105 125 126 127 105 116 040 124 122 101 116 123 106 105 122 123	P.AJH: ASCII	/)/<00> /#AL/ /OST/ / RE/ /AD/<57> /WRI/ /TE / /PEA/ /DY / /DUR/ /ING/ <57>/BE/ /TWE/ /EN / /TRA/ /NSF/		
016531 016534 016536 016541 016544 016547 016552 016555 016560 016563	000 000 045 101 104 122 111 126 105 040 103 114 117 103 113 040 104 122 117 120 117 125 124 000	P.AJI: ASCII	/ERS/ <00><00> /¥AD/ /RIV/ /E C/ /LOC/ /K D/ /ROP/ /OUT/ <00>		
016564 016567	045 101 114 117 123 124	P.AJJ: .ASCII	/SAL/		

		PROTECTIO	ERCISER ON TABLE				5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Page DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (35)
016572	040	122	105		.ASCII	/ RE/		
016575	103	105	111		ASCII	/CEI/		
016600	126	105	122		.ASCII	/VER/		
016603	040	122	105		.ASCII	/ RE/		
016606	101	104	131		.ASCII	/ADY/		
016611	040	102	105		.ASCII	/ BE/		
016614	124	127	105		.ASCII	/TWE/		
016617	105	116	040		.ASCII	/EN /		
016622	123	105	103		.ASCII	/SEC/		
016625	124	117	122		ASCII	/TOR/		
016630	123	000			.ASCII	/5/<00>		
016632	045	101	104	P.AJK:	ASCII	/#AD/		
016635	122	iii	126	· .non.	ASCII	/RIV/		
016640	105	040	104		ASCII	E D/		
016643	105	124	105		ASCII	/ETE/		
016646	103	124	105		ASCTT	/CTE/		
016651	104	040	105		. ASCII			
016654	122	122	000		.ASCII	/D E/ /RR/<00>		
016657	000	TEE	000		ASCII	<00>		
016660	045	101	103	D A	ASCII			
016663	124	114	103	P.AJL:	.ASCII	/#AC/		
016666	040		122		.ASCII	/TLR/		
016671		104	105		.ASCII	/ DE/		
016674	124	105	103		. ASCII	/TEC/		
016677	124	105	104		. ASCII	/TED/		
016677 016702	040	120	125		.ASCII .ASCII .ASCII	/ PU/		
016702	114	123	105		. ASCII	/LSE/		
016705	040	117	122 124		.ASCII	/ OR/		
016710	040	123	124		.ASCII	/ ST/		
016713	101	124	105		. ASCII	/ATE/		
016716	040	120	101		.ASCII	/ PA/		
016721	122	111	124		. ASCII	/RIT/		
016724	131	040	105		. ASCII	/Y E/		
016727	122	122	000		.ASCII	/RR/<00>		
016732	045	116	045	P.AJM:	.ASCII	/SNS/		
016735	101	040	174		.ASCII	/A /<174	>	
016740	040	102	141		.ASCII	/ Ba/		
016743	144	040	102		. ASCII	/d B/		
016746	154 153	157	143		.ASCII .ASCII .ASCII	/loc/		
016751	153	040	125 145		.ASCII	/k U/		
016754	156	162 157	145		. ASCII	/nre/		
016757	160	157	162		. ASCII	/por/		
016762	164	145	144		. ASCII	/ted/		
016765 016766	000				.ASCII .ASCII .ASCII	<00>		
016766	045	116	045	P.AJN:	.ASCII	/sins/		
016771	101	040	174		. ASCII	/A /<174	>	
016774	040	105	162		. ASCII	/ Er/		
016777	162	040	114		. ASCII	/r L/		
017002	157	147	040		.ASCII	100 /		
017005	107	145	156		.ASCII	/Gen/		
017010	145	162	141		.ASCII	/ere/		
017013	164	145	144		. ASCII	/ted/		
017016	000	000			.ASCII	<00><00>		
017020	045	116	045	P.AJO:	.ASCII	/MNM/		

ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Page 100 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
017023 017026 017031 017034 017037 017042 017045 017050	101 040 174 040 123 145 162 151 157 165 163 040 105 170 143 145 160 164 151 157 156	.ASCII /A /<174 .ASCII / Se/ .ASCII /rio/ .ASCII /us / .ASCII /Exc/ .ASCII /ept/ .ASCII /ion/		
017052 017055 017060 017063 017066 017071 017074 017077 017102 017105	000 000 045 116 045 101 174 040 105 156 141 142 154 145 040 101 164 164 145 156 164 151 157 156 040 115 145 163 163 141 147 145	.ASCII <00><00: P.AJP: .ASCII /#N#/ .ASCII /A/<174: .ASCII /Enm/ .ASCII /ble/ .ASCII / At/ .ASCII /ten/ .ASCII /tio/ .ASCII /n M/ .ASCII /esm/ .ASCII /esm/	·//	
017110 017112 017115 017120 017123 017126 017131 017134 017137 017142 017145 017150 017153 017156	163 000 045 116 045 101 174 040 105 156 141 142 154 145 040 115 151 163 143 145 154 154 141 156 145 157 165 163 040 105 162 162 040 114 157 147 040 115 145 163 163 141 147 145	. ASCII /e/<00> P.AJQ: .ASCII /#N#/ .ASCII /A/<174: .ASCII /Ena/ .ASCII /ble/ .ASCII / Mi/ .ASCII / Mi/ .ASCII / Mi/ .ASCII / Mi/ .ASCII / Lo/		
017164 017166 017171 017174 017177 017202 017205 017210 017213 017216 017221 017224 017227 017235 017240 017240 017240 017240 017251 017254	163 000 045 116 045 101 174 040 105 156 141 142 154 145 040 117 164 150 145 162 040 110 157 163 164 163 040 105 162 162 040 114 157 147 040 115 145 163 163 141 147	.ASCII /e/<00> P.AJR: .ASCII /#N#/ .ASCII /A/<174: .ASCII /Ena/ .ASCII /ble/ .ASCII / Ot/ .ASCII / Her/ .ASCII / Ho/ .ASCII / Er/ .ASCII / Er/ .ASCII / Cr/	»//	
017232 017235 017240 017243 017246 017251 017254	163 141 147 145 163 000 045 116 045 101 174 040 105 156 141 142 154 145 040 124 150	ASCII /ee/<00: ASCII /ee/<00: ASCII /e/<00: ASCII /A/<174: ASCII /Ene/ ASCII /ble/ ASCII / Th/		

							10		
ZRQAM1 VO1.2		D/RX EXE	RCISER ON TABLE					10:27:14	VAX-11 Bliss-16 V3-555 Page 101 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (35)
017257	151	163	040		.ASCII	/is /			
017262	110	157	163		ASCII	/Hos/			
017265	164	163	040		ASCII	/ts /			
017270	105	162	162		ASCII	/Err/			
017273	040	114	157		ASCII	/. Lo/			
017276		040	115		ASCII				
017201	147		115		.ASCII	/9 M/			
017301	145	163	163		. ASCII	/ess/			
017304 017307 017312 017315 017320	141	147	145		. ASCII	/age/			
01/30/	163	000	000		.ASCII	/8/<00><00:	•		
017312	045	116	045	P.AJT:	.ASCII	/#N#/			
017315	101	174	040		. ASCII	/A/<174>/	/		
017320	103	164	154		. ASCII	/Ct1/			
01/323	162	040	111		.ASCII	/r I/			
017326	156	151	164		.ASCII	/nit/			
017331	151	141	164		. ASCII	/iat/			
017334	145	144	040		.ASCII	/ed /			
017331 017334 017337	102	141	144		.ASCII	/Bad/			
017342	040	102	154		. ASCII	/ 81/			
017345	157	143	153		. ASCII	/ock/			
017850	040	122	160		ASCTT	/ Rp/			
017353	154	143	155		.ASCII	/lcm/			
017356	156	164	000		ASCTT	/nt/<00>			
017361	000	104	000		ASCTT	<00>			
017362	045	116	045	P.AJU:	.ASCII .ASCII .ASCII	/sins/			
017365		174	040	P.AJU:	ASCII		,		
017353 017356 017361 017362 017365 017370 017373	101				. ASCII	/A/<174>/			
017373	123	150	141		. ASCII	/Sha/			
017375	144	157	167		. ASCII	/dow/			
017401	151	156	147		. ASCII	/ing/			
OTIANT	000				. ASCII	<00>			
017402	045	116	045	P.AJV:	. ASCII	/sns/			
017405	101	174	040		. ASCII	/A/<174>/	/		
017410	065	067	066		. ASCII	/576/			
017413	040	102	171		.ASCII	/ By/			
017416	164	145	040		. ASCII	/te /			
017421	123	145	143		.ASCII	/Sec/			
017424	164	157	162		.ASCII	/tor/			
017427	163	000	000		. ASCII	/8/<00><00	>		
017432	045	116	045	P.AJW:	.ASCII	/46N/46/			
017435	101	174	040		. ASCII	/A/<174>/	/		
017440	103	157	155		. ASCII	/Com/			
017443	160	141	162		. ASCII	/par/			
017446	145	040	122		. ASCII	/e R/			리마이 아이들은 아이는 내내 보다는 사람은 그리아 살아갔다. 나라
017451	145	141	144		. ASCII	/ead/			
017454	163	000			. ASCII	/8/<00>			
017456	045	116	045	P.AJX:	.ASCII	/sNs/			
017461	101	174	040		.ASCII	/A/<174>/	/		
017464	103	157	155		.ASCII	/Com/			
017467	160	141	162		.ASCII	/per/			
017472	145	040	127		ASCII	/e W/			
017475	162	151	164		ASCII	/rit/			
017500	145	163	000		ASCII	/es/<00>			
017503	000	200			ASCII	<00>			
017504	045	116	045	P.AJY:	ASCII	/MNS/			
1			0.0			, =14=7			

			LO	
ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE	*	5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 SEQ 0102 Page 102 DISK*USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
	PROTECTION TABLE  101	ASCII  ASCII	5-Dec-1983 10:27:04  /A/<174>/ / Ct1/ /r I/ /nit/ /iat/ /ed / /Bad/ / B1/ /ock/ / Rp/ /lcm/ /nt/<00> <00> /MN#/ /A/<174>/ / /Ina/ /cti/ /ve / /Sha/ /dow/ / Se/ /t U/ /nit/ <00><00> /#N#/ /A/<174>/ / /Rem/ /ova/ /ble/ / Me/ /dia/ <00> /#N#/ /A/<174>/ / /Sup/ /pre/ /es / /Cac/ /hin/ /g (/ /hig/ /h s/	VAX-11 Bliss-16 V3-555 Page 102
017703 017706 017711 017714 017717 017722 017725 017730 017733	160 145 145 144 051 000 045 116 045 101 174 040 123 165 160 160 162 145 163 163 040 103 141 143 150 151 156 147 040 050 154 157 167	ASCII	/pee/ /d)/<00> /sNs/ /A/<174>/ / /Sup/ /pre/ /es / /Cac/ /hin/ /g (/ /low/	

			110	
ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Page 103 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (35)
017741 017744 017747 017752 017755 017760 017763 017766	040 163 160 145 145 144 051 000 000 045 116 045 101 174 040 127 162 151 164 145 055 142 141 143	P.AKD: ASCI ASCI ASCI ASCI ASCI ASCI ASCI	/eed/ /)/<00><00> /#N#/ /A/<174>/ / /Wri/ /te-/ /bac/	
017771 017774 017777 020002 020005 020010 020012	153 040 050 156 157 156 055 166 157 154 141 164 151 154 145 051 000 045 116 045	.ASCI .ASCI .ASCI .ASCI .ASCI .ASCI P.AKE: .ASCI	/-vo/ /lat/ /ile/ /)/<00> /#N#/	
020015 020020 020023 020026 020031 020034 020037	101 174 040 127 162 151 164 145 040 120 162 157 164 145 143 164 040 050 150 141 162	. ASCI . ASCI . ASCI . ASCI . ASCI . ASCI	/Wri/ /te / /Pro/ /tec/ /t (/	
020042 020045 020050 020052 020055 020060 020063 020066	144 167 141 162 145 051 000 000 045 116 045 101 174 040 127 162 151 164 145 040	P.AKF: ASCI ASCI ASCI ASCI ASCI ASCI ASCI ASCI	(00><00> /#N#/ /A/<174>//	
020071 020077 020077 020102 020105 020110	120 162 157 164 145 143 164 040 050 163 157 146 164 167 141 162 145 040 157 162 040	. ASCI . ASCI . ASCI . ASCI . ASCI	/tec/ /t (/ /sof/ /twa/ /re /	
020113 020116 020121 020124 020127 020132 020135	166 157 154 165 155 145 051 000 000 045 116 045 101 174 040 065 067 066 040 102 171	.ASCI .ASCI .ASCI P.AKG: .ASCI	/vol/ /ume/ /)/<00><00> /sNs/ /A/<174>//	
020140 020143 020146 020151 020154 020157 020162	164 145 040 123 145 143 164 157 162 163 000 000 045 101 040 055 040 123 125 103 103	ASCI ASCI ASCI ASCI ASCI ASCI ASCI ASCI	/te / /Sec/ /tor/ /e/<00><00> /dA / /- S/ /UCC/	
020165 020170 020172	105 123 123 000 000 045 101 040	P.AKI: ASCI	(00><00>	

				110	
ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 SEQ 0104 Page 104 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
020175 020200 020203 020206 020211 020214 020217 020222 020225 020230 020233 020236 020241 020244 020247 020252 020255 020260 020263 020266 020271 020274 020277 020302 020305 020310 020313 020316 020311 020324 020321 020324 020325 020355 020310 020313 020316 020311 020324 020327 020322 020355 020310 020313 020316 020311 020324 020325 020355 020310 020311 020324 020325 020350 020350 020350 020357 020342 020356 020357 020357 020364 020375 020400 020403 020406 020411 020414 020417 020422 020425 020430	055	P.AKK: P.AKK:	.ASCII /- I/ .ASCII /NVA/ .ASCII /NVA/ .ASCII /LID/ .ASCII /CO/ .ASCII /ND(/ .ASCII /ND(/ .ASCII /ND(/ .ASCII /ND/		

ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bl;ss-16 V3-555
020433 020436 020440 020443 020446 020451 020457 020462 020465 020470 020473 020476 020501 020504 020507	104 111 101 051 000 045 101 040 055 040 114 117 101 104 040 106 101 111 114 125 122 105 040 050 111 116 120 125 124 040 105 122 122 040 127 110 111 114 105 040 114 117 101 104 111 116 107 040 120 122	.ASCII /DIA/ .ASCII /)/<0 P.AKM: .ASCII /#A / .ASCII /- L/ .ASCII /- L/ .ASCII / FA/ .ASCII / FA/ .ASCII / ILU/ .ASCII / ILU/ .ASCII / ER/ .ASCII / PR/	0>	
020515 020520 020523 020524 020527 020532 020535 020540 020540 020551 020554 020557 020562 020565 020570 020573	117 107 122 101 115 051 000 045 101 040 055 040 123 124 101 116 104 101 114 117 116 105 040 050 123 124 101 116 104 101 116 104 101 114 117 116 105 040 115 117 104 111 106 111 105 122 040 116 117 124 040 123	. ASCII /OGR/ . ASCII /AM)/ . ASCII (00> P.AKN: . ASCII /#A / . ASCII /- S/ . ASCII /TAN/ . ASCII /DAL/ . ASCII / (S/ . ASCII / TAN/ . ASCII / DAL/ . ASCII / NO/ . ASCII / IER/ . ASCII / NO/ . ASCII / NO/ . ASCII / NO/ . ASCII / TS/		
020601 020604 020607 020612 020615 020620 020623 020626 020631 020634 020636 020641 020647 020652 020655 020660 020663	120	.ASCII /IFI/ .ASCII /ED / .ASCII /FOR/ .ASCII / ST/ .ASCII / AND/ .ASCII / AND/ .ASCII / ONE/ .ASCII / PR/ .ASCII /G.)/ .ASCII /ONE/ .ASCII /G.)/	74>//	

							6		
ZRQAM1		RD/RX EXE	POTTER				5 Dec 1987	10:27:14	VAY 11 B1: 16 VZ 555 SEQ 0106
V01.2		PROTECTIO						10:27:04	VAX-11 Bliss-16 V3-555 Page 106 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
000000									
020666 020671	155	145	000		.ASCII	/me/<00>			
020672	045	116	045	P. AKP:	.ASCII	<00>			
020675	101	174	040	P.ANP;	.ASCII	/A/<174>	,,		
020700	103	157	156		ASCII	/Con/	, ,		
020703	164	141	151		ASCII	/tai/			
020706	156	163	040		ASCII	/09 /			
020711	114	157	143		ASCII	/Loc/			
020714	141	154	040		.ASCII	/al /			
020717	115	145	144		.ASCII	/Med/			
020722	151	141	000		.ASCII	/ia/<00>			
020725	000				. ASCII	<00>			
020726	045	116	045	P.AKQ:	. ASCII	/sNs/			
020731	101	174	040		. ASCII	/A/<174>	11		[Most : 10 7 ] : 1 - 10 ] : 10 ] : 10 ] : 10 ] : 10 [Most : 10 ]
020734	105	170	145		.ASCII	/Exe/			
020737	143	165	164		.ASCII	/cut/			
020742	145	040	114		. ASCII	/e L/			
020745	157	143	141		. ASCII	/oca/			
020750	154	040	120		.ASCII	/1 P/			
020753	162	147	040		.ASCII	/rg /			
020756 020761	143	155	144		.ASCII .ASCII .ASCII .ASCII	/cmd/			
020764	040	151	163		.ASCII	/ is/			
020767	123	125	116		.ASCII	/ UN/			
020772	120	125 117	120 122		.ASCII	/SUP/ /POR/			
020775	124	105	104		.ASCII	/TED/			
021000	000	000	104		ASCIT	<00><00>			
021002	045	116	045	P.AKR:	.ASCII	/sNs/			
021005	101	174	040		.ASCII	/A/<174>	11		
021010	103	165	162		.ASCII	/Cur/			
021013	162	145	156		.ASCII	/ren/			
021016	164	154	171		.ASCII	/tly/			
021021	040	151	156		.ASCII	/ in/			
021024	040	101	143		. ASCII	/ Ac/			
021027	164	151	166		. ASCII	/tiv/			
021032	145	040	123		.ASCII	/e S/			보는 그리는 사람은 경기를 가장하는 것이 되었다. 하나 가는 것이다.
021035 021040	164	141	164		. ASCII	/tat/			[5] 16 16 16 16 16 16 16 16 16 16 16 16 16
021042	145 045	000	DAE	0 446	.ASCII	/e/<00>			
021045	101	116 174	045 040	P.AKS:	.ASCII	/sNs/			내 등록 되지 때 다양하다 가장 내 병자에서 함께 살아갔다.
021050	123	164	141		.ASCII	/A/<174>	, ,		
021053	156	144	141		ASCII	/Sta/ /nda/			
021056	154	157	156		.ASCII	/lon/			
021061	154 145	040	120		ASCIT	/e P/			
021064	162	147	000		.ASCII	/rg/<00>			
021067	000				ASCII	<00>			
021070	045	116	045	P.AKT:	.ASCII	/ENS/			
021073	101	174	040		. ASCII	/A/<174>	11		
021076	116	145	145		. ASCII	/Nee/			
021101	144	163	040		.ASCII	/de /			
021104	157	166	145		.ASCII	/ove/			
021107	162	154	141		. ASCII	/rle/			
021112	171	000			.ASCII	/y/<00>			
									가장 내내는 사람들 하다면 내려왔다. 그 하는 사람들이 가는 가장 하게 되는 것이다. 나는 사람들이 되었다.

ROPER   ROPER   ROPER   S-Dec-1983 10:27:14   VAX-II Bl:sm-16 VS-555   SEG 0107   VOI.2   Collidary   Voi.2   Collidary   Voi.2   Collidary   Voi.2   Collidary   Voi.2   Collidary   Voi.2							U	
O21114							5-Dec-1983 10:27:14	VAX-11 Bliss-16 V3-555 Page 107
021117 101 174 040	*****		WILC'IL	N INDEE			3-066-1963 10:27:04	DISK DUSENZ: [DIE12. NUNX JZNUACO. BL1;82 (35)
021117 101 174 040 ASCII /A/-1747 / 021125 146 145 145 ASCII /A/-1747 / 021136 142 154 145 ASCII / Obe / 021136 142 154 145 ASCII / Obe / 021136 142 154 145 ASCII / Obe / 021141 051 122 145 ASCII / Obe / 021141 051 124 145 ASCII / Obe / 021142 144 154 145 ASCII / Obe / 021143 145 162 154 ASCII / Obe / 021145 145 162 154 ASCII / Obe / 021146 147 147 154 165 ASCII / Obe / 021155 145 162 154 ASCII / Obe / 021156 145 160 161 164 ASCII / Obe / 021161 141 141 144 ASCII / Obe / 021163 040 171 000 ASCII / Obe / 021164 045 116 045 P.AKYI ASCII / Obe / 021165 104 165 166 ASCII / Obe / 021167 101 174 040 ASCII / Obe / 021167 102 164 143 ASCII / Obe / 021167 102 103 104 165 160 ASCII / Obe / 021206 040 104 151 ASCII / Obe / 021206 040 104 151 ASCII / Obe / 021207 104 165 160 ASCII / Obe / 021208 105 106 107 ASCII / Obe / 021208 107 108 108 108 ASCII / Obe / 021208 108 108 108 108 ASCII / Obe / 021208 109 109 109 109 ASCII / Obe / 021209 109 109 109 109 ASCII / Obe / 021209 109 109 109 ASCII / Obe / 021209 109 109 109 109 ASCII / Obe / 021209 109 109 109 109 ASCII / Obe / 021209 109 109 109 109 ASCII / Obe / 021209 109 109 109 109 ASCII / Obe / 021209 109 109 109 109 ASCII / Obe / 021209 109 109 109 109 ASCII / Obe / 021209 109 109 109 109 ASCII / Obe / 021209 109 109 109 109 ASCII / Obe / 021209 109 109 109 109 ASCII / Obe / 021209 109 109 109 109 ASCII / Obe / 021209 109 109 109 109 ASCII / Obe / 021209 109 109 109 109 ASCII / Obe / 021209 109 109 109 109 109 ASCII / Obe / 021209 109 109 109 109 109 ASCII / Obe / 021209 109 109 109 109 109 109 ASCII / Obe / 021209 109 109 109 109 109 109 109 109 109 1	021114	045	116	045	P. AKU:	. ASCII	/siNs/	
021122 116 145 145 145 ASCII /New/ 021133 124 165 040 ASCII /Ne/ 021136 124 165 141 ASCII /Ne/ 021136 124 165 141 ASCII /Ne/ 021136 124 145 ASCII /Ne/ 021136 124 145 ASCII /Ne/ 021136 124 141 141 141 ASCII /Ne/ 021137 142 154 141 ASCII /Ne/ 021137 142 154 141 ASCII /Ne/ 021137 142 154 141 ASCII /Ne/ 021137 143 144 141 ASCII /Ne/ 021137 145 145 ASCII /Ne/ 021138 145 ASCII /Ne/ 021151 145 165 ASCII /Ne/ 021151 145 165 ASCII /Ne/ 021152 140 141 171 000 ASCII /Ne/ 021153 145 165 ASCII /Ne/ 021154 145 ASCII /Ne/ 021155 165 165 145 ASCII /Ne/ 021167 141 174 000 ASCII /Ne/ 021167 141 174 000 ASCII /Ne/ 021175 163 040 123 ASCII /Ne/ 021175 163 145 165 ASCII /Ne/ 021175 163 145 165 ASCII /Ne/ 021200 164 144 040 ASCII /Ne/ 021214 141 154 157 ASCII /Ne/ 021214 141 154 157 ASCII /Ne/ 021214 141 154 157 ASCII /Ne/ 021214 147 073 040 ASCII /Ne/ 021214 147 040 ASCI	021117		174			. ASCII		
021125 144 163 040 ASCII /de / 021136 167 162 151 ASCII /de / 021136 168 145 154 145 ASCII /tea/ 021137 162 154 145 ASCII /tea/ 021141 167 122 145 ASCII /tea/ 021141 167 122 145 ASCII /tea/ 021141 141 144 141 ASCII /ble/ 021155 146 117 166 ASCII /ble/ 021155 040 117 166 ASCII /ble/ 021163 000 11 100 ASCII /ble/ 021163 000 11 100 ASCII /ble/ 021167 101 174 040 ASCII /ble/ 021200 164 144 050 ASCII /ble/ 021200 165 164 044 ASCII /ble/ 021217 122 055 105 05 ASCII /ble/ 021217 122 057 125 105 05 ASCII /ble/ 021225 116 104 057 ASCII /ble/ 021224 052 057 125 105 05 ASCII /ble/ 021225 116 104 057 ASCII /ble/ 021226 057 125 105 105 ASCII /ble/ 021226 057 125 105 105 ASCII /ble/ 021226 057 125 105 105 ASCII /ble/ 021226 057 125 105 125 ASCII /ble/ 021226 050 126 116 045 P.AKH. ASCII /ble/ 021226 050 126 116 045 P.AKH. ASCII /ble/ 021226 050 126 116 045 P.AKH. ASCII /ble/ 021226 050 126 116 055 P.AKH. ASCII /ble/ 021226 050 105 106 101 052 ASCII /ble/ 021226 050 105 106 106 101 ASCII /ble/ 021226 050 105 106 101 107 ASCII /ble/ 021226 105 106 106 101 ASCII /ble/ 021226 105 106 106 101 ASCII /ble/ 021227 107 107 101 011 052 ASCII /ble/ 021228 106 107 107 107 107 ASCII /ble/ 021228 106 107 107 107 ASCII /ble/ 021227 107 107 107 107 ASCII /ble/ 021237 107 107 107 107 ASCII /ble/ 021237 107 107 107 107 ASCI						. ASCII		
021130 127 162 151 ASCII /Mri/ 021131 164 145 141 ASCII /tes/ 021131 164 145 141 ASCII /tes/ 021147 142 154 141 ASCII /ble/ 021147 142 154 145 ASCII /ble/ 021147 142 154 145 ASCII /ble/ 021155 145 162 154 ASCII /ble/ 021164 045 116 045 P.AKYI ASCII /ble/ 021164 045 116 045 P.AKYI ASCII /ble/ 021172 125 163 145 ASCII /ble/ 021172 125 163 145 ASCII /ble/ 021173 163 040 123 ASCII /ble/ 021175 163 040 123 ASCII /ble/ 0212164 144 154 157 ASCII /ble/ 0212174 147 073 040 ASCII /ble/ 0212175 163 040 123 ASCII /ble/ 0212175 163 040 125 ASCII /ble/ 021217 122 125 165 ASCII /ble/ 021217 122 125 165 ASCII /ble/ 021217 122 125 ASCII /ble/ 021224 045 ASCII /ble/ 021225	021125					ASCIT		
021141 057 122 145	021130		162			ASCIT		
021141 057 122 145	021133	164	145	141		ASCIT		
021141 057 122 145	021136					ASCTT		
021144 141 144 141 145	021141					ASCTI		
021147 142 154 145 145	021144					ASCII		
021152 040 117 166	021147					ASCII		
021155 145 162 154 ASCII /el/ 021163 000 021164 045 116 045 P.AKY: ASCII /el/ 021164 045 116 045 P.AKY: ASCII /el/ 021172 121 174 040 ASCII /el/ 021175 125 163 144 040 ASCII /el/ 021107 164 144 040 ASCII /el/ 021200 164 144 040 ASCII /el/ 021206 040 104 151 ASCII /el/ 021206 040 104 151 ASCII /el/ 021214 147 073 040 ASCII /el/ 021214 147 073 040 ASCII /el/ 021215 116 104 057 ASCII /el/ 021225 116 104 057 ASCII /el/ 021225 116 104 057 ASCII /el/ 021223 000 021223 000 021223 005 122 105 103 ASCII /el/ 021223 105 105 ASCII /el/ 021225 116 101 011 052 ASCII /el/ 021226 152 105 105 ASCII /el/ 021226 152 105 105 ASCII /el/ 021226 045 116 045 P.AKW: ASCII /el/ 021226 045 116 045 P.AKW: ASCII /el/ 021226 052 040 104 ASCII /el/ 021226 053 111 17 16 ASCII /el/ 021226 053 111 17 16 ASCII /el/ 021226 053 111 17 ASCII /el/ 021236 045 116 045 P.AKY: ASCII /el/ 021237 105 106 101 ASCII /el/ 021238 106 000 000 000 000 000 000 000 000 000	021152					. MSCII		
021160 141 171 000 ASCII /ay/*00   021163 000   021164 045 116 045 P.AKV: ASCII /ay/*   000   021167 101 174 040   021167 123 163 145   021275 123 163 145   021203 104 144 165 160   021203 104 164 165 160   021203 104 165 150   021204 104 165 150   021203 104 165 150   021204 104 165 150   021204 104 165 150   021204 104 165 150   021204 104 165 150   021204 104 165 150   021204 104 165 150   021204 104 165 150   021211 141 154 157   021211 141 154 157   021217 122 105 103   021222 057 123 105   021223 057 123 105   021223 116 104 057   021224 116 104 057   021225 116 104 057   021225 116 104 057   021225 116 104 057   021225 105 105 103   021225 000 105 103   021225 000 105 103   021225 000 105 103   021225 000 105 103   021225 000 105 103   021225 000 105 103   021225 000 105 105   021225 000 121   021225 000 121   021225 000 121   021225 000 121   021225 000 121   021225 000 121   021225 000 100 100   021226 000 000   021226 000 100 100   021226 000 100 100 100   021226 000 100 100 100 100   021226 000 100 100 100 100 100   021226 000 100 121 125   021227 000 100 121 125   021227 000 100 122 124   021227 000 100 122 124   021225 000 100 122 125   021225 000 100 122 126   021225 000 100 122 126   021225 000 100 122 126   021226 000 000   021310 005 116 005   000 000   021310 005 116 005   000 000   001334 005 116 000 000   021335 005 116 000 000   021334 005 116 000 000   021335 005 116 000 000   021335 005 116 000 000   021335 005 116 000 000   021335 005 116 000 000   021335 005 116 000 000   021335 005 116 000 000   021335 005 116 005 000 000   021335 005 116 005 000 000   021335 005 116 005 000 000   021335 005 116 005 000 000   021335 005 116 005 000 000   021335 005 116 005 000 000   021335 005 116 005 000 000   021335 005 116 005 000 000   021335 005 116 000 000 000   021335 005 116 000 000 000   021335 005 116 000 000 000    021335 005 116 000 000 000    021335 005 116 000 000 000    021335 005 116 000 000 000 000    021335 005 000 000 000 000 000 000 000 000	021156		111			. MSCII	/ 00/	
021163 000 021167 001 174 040 P.AKV: ASCII / 600 021167 101 174 040 P.AKV: ASCII / 600 021175 163 040 123 ASCII / 600 021175 163 040 123 ASCII / 600 021203 104 164 164 040 ASCII / 600 021203 104 165 160 ASCII / 600 021203 104 165 160 ASCII / 600 021211 141 154 157 ASCII / 600 021214 141 154 157 ASCII / 600 021221 141 154 157 ASCII / 600 021222 057 123 105 ASCII / 600 021223 166 104 057 ASCII / 600 021223 122 105 103 ASCII / 600 021223 104 105 105 ASCII / 600 021224 052 106 107 ASCII / 600 021225 106 100 057 ASCII / 600 021226 052 040 121 ASCII / 600 021227 101 011 052 ASCII / 600 021228 052 040 121 ASCII / 600 021225 116 101 015 125 ASCII / 600 021225 124 105 105 105 ASCII / 600 021225 105 105 105 ASCII / 600 021225 105 105 ASCII / 600 021226 052 040 121 ASCII / 600 021226 105 106 101 052 ASCII / 600 021227 040 121 125 ASCII / 600 021227 125 114 124 ASCII / 600 021227 125 114 124 ASCII / 600 021227 125 114 124 ASCII / 600 021227 124 111 117 ASCII / 700 021227 124 111 117 ASCII / 700 021227 124 111 117 ASCII / 700 021227 124 111 117 116 ASCII / 700 021227 124 111 107 107 ASCII / 7000 021233 045 116 000 101 052 ASCII / 7000 021334 045 116 000 101 052 ASCII / 7000 021335 045 116 000 101 052 ASCII / 7000 021336 045 116 000 101 052 ASCII / 7000 021337 124 111 011 052 ASCII / 7000 021337 101 001 001 052 ASCII / 7000 021334 045 116 000 101 011 052 ASCII / 7000 021335 045 116 000	021122		102			. ASCII		
021164	021160		1/1	000		. ASCII		
021167 101 174 040 .ASCII /A/<1747 / 021175 163 040 123 .ASCII /Use/ 021175 163 040 123 .ASCII /Use/ 021203 104 165 160 .ASCII /Use/ 021203 104 165 160 .ASCII /Use/ 021204 040 104 167 .ASCII /Use/ 021214 147 073 040 .ASCII /Use/ 021214 147 073 040 .ASCII /Use/ 0212122 057 123 105 .ASCII /Use/ 021222 057 123 105 .ASCII /Use/ 021223 116 104 057 .ASCII /Use/ 021230 122 105 103 .ASCII /SEC/ 021233 122 105 103 .ASCII /Wile/ 021234 045 116 045 .ASCII /Wile/ 021242 052 040 121 .ASCII /Wile/ 021242 052 040 121 .ASCII /Wile/ 021242 052 040 121 .ASCII /Use/ 021253 125 105 105 .ASCII /Use/ 021265 125 105 105 .ASCII /Wile/ 0212661 105 105 .ASCII /Use/ 0212661 105 105 .ASCII /Wile/ 021267 105 106 101 052 .ASCII /Wile/ 021267 105 106 101 052 .ASCII /Wile/ 021267 105 106 101 .ASCII /Wile/ 021275 040 121 125 .ASCII /Wile/ 021303 111 117 116 .ASCII /Wile/ 021304 045 116 045 .P.AKY: .ASCII /Wile/ 021305 116 106 045 .P.AKY: .ASCII /Wile/ 021307 124 111 117 .ASCII /Wile/ 021308 116 000 000 000 .ASCII /Wile/ 021308 045 116 045 .P.AKY: .ASCII /Wile/ 021309 111 117 .ASCII /Wile/ 021309 110 011 052 .ASCII /Wile/ 021309 110 011 052 .ASCII /Wile/ 021309 005 116 005 .ASCII /Wile/ 021309 005 116 005 .ASCII /Wile/ 021309 005 116 005 .ASCII /Wile/ 021309 005 105 126 124 .ASCII /Wile/ 021309 005 105 126 124 .ASCII /Wile/ 021309 005 105 106 005 .ASCII /Wile/ 021309 005 105 106 005 .ASCII /Wile/ 021309 005 105 106 005 .ASCII /Wile/ 021309 005 105 106 0	021163			***		.ASCII		
021172 125 163 145	021164				P.AKV:	. ASCII		
021175 163 040 123	021167	101				. ASCII		
021203 164 144 040	021172	125				. ASCII		
021212 057 123 105 103	021175			123		. ASCII		
021212 057 123 105 103	021200					. ASCII		
021212 057 123 105 103	021203					. ASCII	/Dup/	
021212 057 123 105 103	021206			151		.ASCII		
021212	021211					. ASCII	/alo/	
021212	021214					. ASCII	/9: /	
021225 116 104 057 .ASCII /NO/557> 021233 000 021234 045 116 045 P.AKW: .ASCII /NN/60> 021237 101 011 052 .ASCII /NC/00> 021242 052 040 121 .ASCII /N/60> 021250 124 111 117 .ASCII /N/60> 021250 124 111 117 .ASCII /N/60> 021251 105 045 116 045 P.AKX: .ASCII /N/60> 021250 124 111 117 .ASCII /N/60> 021251 105 045 116 045 P.AKX: .ASCII /N/60> 021264 052 040 104 .ASCII /N/60> 021256 105 045 116 045 P.AKX: .ASCII /N/60> 021264 052 040 104 .ASCII /N/60> 021265 105 106 101 .ASCII /N/60> 021267 105 106 101 .ASCII /N/60 021272 125 114 124 .ASCII /EFA/ 021275 040 121 125 .ASCII /N/60 021300 105 123 124 .ASCII /N/60 021303 111 117 116 .ASCII /N/60 021310 045 116 045 P.AKY: .ASCII /N/60 021310 045 116 045 P.AKY: .ASCII /N/60 021310 045 116 045 P.AKY: .ASCII /N/60 021324 122 115 101 .ASCII /N/60 021324 122 115 101 .ASCII /N/60 021324 122 115 101 .ASCII /N/60 021332 116 000 .ASCII /N/60 021333 101 111 .ASCII /N/60 021333 101 011 052 .ASCII /N/60 021334 045 116 045 P.AKY: .ASCII /N/60 021335 116 000 .ASCII /N/60 021337 101 011 052 .ASCII /N/60	021217	122	105			.ASCII	/REC/	에게 되어 내가 되느냐 하는 것이 되었다는 것 같아 되어 되었다.
021237 101 011 052 021242 052 040 121 021245 125 105 123 021250 124 111 117 021253 116 000 000 021256 045 116 045 P.AKX: ASCII /VES/ 021264 052 040 104 021264 052 040 104 021267 105 106 101 021272 125 114 124 021275 040 121 125 021275 040 121 125 021275 040 121 125 021275 040 121 125 021276 040 104 021271 125 116 105 021303 111 117 116 021303 111 117 116 021303 111 117 116 021304 050 000 021313 101 011 052 021316 052 040 111 021316 052 040 111 021327 124 111 17 021327 124 111 17 021327 124 111 17 021327 124 111 17 021327 124 111 17 021327 124 111 17 021332 116 000 021331 105 016 000 021332 124 111 117 021332 124 111 117 021333 116 006 17 021337 124 111 17 021337 101 011 052 021337 101 011 052 021337 101 011 052 021337 101 011 052 021337 101 011 052 021337 124 111 17 021337 101 011 052	021222					. ASCII		유리를 하는 그 아이들이 없는 것이 그 사람들이 되었다면 하는 것이
021237 101 011 052 021242 052 040 121 021245 125 105 123 021250 124 111 117 021253 116 000 000 021256 045 116 045 P.AKX: ASCII /VES/ 021264 052 040 104 021264 052 040 104 021267 105 106 101 021272 125 114 124 021275 040 121 125 021275 040 121 125 021275 040 121 125 021275 040 121 125 021276 040 104 021271 125 116 105 021303 111 117 116 021303 111 117 116 021303 111 117 116 021304 050 000 021313 101 011 052 021316 052 040 111 021316 052 040 111 021327 124 111 17 021327 124 111 17 021327 124 111 17 021327 124 111 17 021327 124 111 17 021327 124 111 17 021332 116 000 021331 105 016 000 021332 124 111 117 021332 124 111 117 021333 116 006 17 021337 124 111 17 021337 101 011 052 021337 101 011 052 021337 101 011 052 021337 101 011 052 021337 101 011 052 021337 124 111 17 021337 101 011 052	021225	116	104	057		. ASCII		
021237 101 011 052 021242 052 040 121 021245 125 105 123 021250 124 111 117 021253 116 000 000 021256 045 116 045 P.AKX: ASCII /VES/ 021264 052 040 104 021264 052 040 104 021267 105 106 101 021272 125 114 124 021275 040 121 125 021275 040 121 125 021275 040 121 125 021275 040 121 125 021276 040 104 021271 125 116 105 021303 111 117 116 021303 111 117 116 021303 111 117 116 021304 050 000 021313 101 011 052 021316 052 040 111 021316 052 040 111 021327 124 111 17 021327 124 111 17 021327 124 111 17 021327 124 111 17 021327 124 111 17 021327 124 111 17 021332 116 000 021331 105 016 000 021332 124 111 117 021332 124 111 117 021333 116 006 17 021337 124 111 17 021337 101 011 052 021337 101 011 052 021337 101 011 052 021337 101 011 052 021337 101 011 052 021337 124 111 17 021337 101 011 052	021230	122	105	103		.ASCII		
021237 101 011 052 021242 052 040 121 021245 125 105 123 021250 124 111 117 021253 116 000 000 021256 045 116 045 P.AKX: ASCII /VES/ 021264 052 040 104 021264 052 040 104 021267 105 106 101 021272 125 114 124 021275 040 121 125 021275 040 121 125 021275 040 121 125 021275 040 121 125 021276 040 104 021271 125 116 105 021303 111 117 116 021303 111 117 116 021303 111 117 116 021304 050 000 021313 101 011 052 021316 052 040 111 021316 052 040 111 021327 124 111 17 021327 124 111 17 021327 124 111 17 021327 124 111 17 021327 124 111 17 021327 124 111 17 021332 116 000 021331 105 016 000 021332 124 111 117 021332 124 111 117 021333 116 006 17 021337 124 111 17 021337 101 011 052 021337 101 011 052 021337 101 011 052 021337 101 011 052 021337 101 011 052 021337 124 111 17 021337 101 011 052	021233					. ASCII		
021242 052 040 121	021234				P. AKW:	. ASCII		
021261 101 011 052	021237					. ASCII		
021261 101 011 052	021242	052		121		. ASCII		
021261 101 011 052	021245	125	105	123		. ASCII		
021261 101 011 052	021250					. ASCII	/110/	
021264 052 040 104 .ASCII /A 0/ 021267 105 106 101 .ASCII /A 0/ 021272 125 114 124 .ASCII /ULT/ 021275 040 121 125 .ASCII /ULT/ 021300 105 123 124 .ASCII /EFA/ 021303 111 117 116 .ASCII /ION/ 021310 045 116 045 P.AKY: .ASCII /MM/ 021311 010 011 052 .ASCII /A/411>/ASCII /A/411>/ASCI	021253					.ASCII		
021264 052 040 104 .ASCII /* D/ 021267 105 106 101 .ASCII /EFA/ 021272 125 114 124 .ASCII /ULT/ 021275 040 121 125 .ASCII / ULT/ 021300 105 123 124 .ASCII /EST/ 021306 000 000 021310 045 116 045 P.AKY: ASCII /MIMS/ 021313 101 011 052 .ASCII /ASCII	021256				P.AKX:	.ASCII		
021275 040 121 125		101	011	052		. ASCII	/A/<11>/4/	
021275 040 121 125	021264	052	040	104		. ASCII	/* D/	
021275 040 121 125	021267	105	106	101		. ASCII	/EFA/	
021310 045 116 045 P.AKY: ASCII /6Nm/ 021313 101 011 052 ASCII /4/<11> 021316 052 040 111 ASCII /4/(1)/ 021321 116 106 117 ASCII /NFO/ 021324 122 115 101 ASCII /RMA/ 021327 124 111 117 ASCII /TIO/ 021332 116 000 ASCII /N/<00> 021334 045 116 045 P.AKZ: ASCII /MM/ 021337 101 011 052 ASCII /A/<11>	021272	125	114	124		. ASCII	/ULT/	
021310 045 116 045 P.AKY: ASCII /6Nm// 021313 101 011 052 ASCII /4/<11>/ 021316 052 040 111 ASCII /4/(1)// 021321 116 106 117 ASCII /NFO/ 021324 122 115 101 ASCII /RMA/ 021327 124 111 117 ASCII /TIO/ 021332 116 000 ASCII /N/<00> 021334 045 116 045 P.AKZ: ASCII /MM// 021337 101 011 052 ASCII /A/<11>/ 021337 101 011 052 ASCII /A/<11>/	021275		121	125		.ASCII	/ QU/	
021310 045 116 045 P.AKY: ASCII /6Nm// 021313 101 011 052 ASCII /4/<11>/ 021316 052 040 111 ASCII /4/(1)// 021321 116 106 117 ASCII /NFO/ 021324 122 115 101 ASCII /RMA/ 021327 124 111 117 ASCII /TIO/ 021332 116 000 ASCII /N/<00> 021334 045 116 045 P.AKZ: ASCII /MM// 021337 101 011 052 ASCII /A/<11>/ 021337 101 011 052 ASCII /A/<11>/	021300	105	123	124		. ASCII	/EST/	
021313 101 011 052 .ASCII /A/<11>/021316 052 040 111 .ASCII /A/ / I/ 021321 116 106 117 .ASCII /NFO/ 021324 122 115 101 .ASCII /RMA/ 021327 124 111 117 .ASCII /IIO/ 021332 116 000 .ASCII /IIO/ 021334 045 116 045 P.AKZ: ASCII /MMA/ 021337 101 011 052 .ASCII /A/<11>/021337 101 011 052 .ASCII /A/<11>/04/	021303	111	117	116		.ASCII	/ION/	
021313 101 011 052 .ASCII /A/<11>/021316 052 040 111 .ASCII /A // 1/ 021321 116 106 117 .ASCII /NFO/ 021324 122 115 101 .ASCII /RMA/ 021327 124 111 117 .ASCII /IIO/ 021332 116 000 .ASCII /IIO/ 021334 045 116 045 P.AKZ: ASCII /MMA/ 021337 101 011 052 .ASCII /A/<11>/02	021306	000	000			.ASCII		
021316 052 040 111 .ASCII /* I/ 021321 116 106 117 .ASCII /NFO/ 021324 122 115 101 .ASCII /RMA/ 021327 124 111 117 .ASCII /TIO/ 021332 116 000 .ASCII /N/<00> 021334 045 116 045 P.AKZ: ASCII /MNM/ 021337 101 011 052 .ASCII /A/<11>/*/	021310		116	045	P.AKY:	.ASCII		
021321 116 106 117 .ASCII /NFO/ 021324 122 115 101 .ASCII /RMA/ 021327 124 111 117 .ASCII /TIO/ 021332 116 000 .ASCII /N/<00> 021334 045 116 045 P.AKZ: ASCII /MNS/ 021337 101 011 052 .ASCII /A/<11>/4/	021313		011	052		.ASCII		
021324 122 115 101 .ASCII /RMA/ 021327 124 111 117 .ASCII /TIO/ 021332 116 000 .ASCII /N/<00> 021334 045 116 045 P.AKZ: ASCII /MMM/ 021337 101 011 052 .ASCII /A/<11>/4/	021310			111		. ASCII		
021332 116 000 .ASCII /TIO/ 021334 045 116 045 P.AKZ: ASCII /M/<00> 021337 101 011 052 .ASCII /M/<11>/#/	021321			117		. ASCII		중합니다 이 그 그 이 경구를 받아 있는 것 같아 되었습니다.
021332 116 000 .ASCII /N/<00> 021334 045 116 045 P.AKZ: .ASCII /MNM/ 021337 101 011 052 .ASCII /A/<11>/4/	021324	122		101		. ASCII		사람이 없는 사람들이 살아 살아가 되었다면 하는데 하는데 없는데 없었다.
021334 045 116 045 P.AKZ: ASCII /N/<00> 021337 101 011 052 .ASCII /A/<11> 021342 052 040 124 .ASCII /A T/	021327	116	111	117		ASCII	/110/	
021337 101 011 052 .ASCII /A/<11>/021342 052 040 124 .ASCII /A T/	021332		000	DAE	0 447	. ASCII		
021342 052 040 124 .ASCII /A/(11)/4/ .ASCII /4 T/	021334			045	P.AKZ:	. ASCII		
VELS-E V3E V4V 124 .MSCII /# 1/	021337		011	134		ASCII	/A/(11)/4/	4. 에 마르크 : Salar in the control of
	VE1342	UJE	040	124		. MSCII	/• 1/	

ZRQAM1 VO1.2		RD/RX EXI	ERCISER ON TABLE				5-Dec-1983 5-Dec-1983		VAX-11 Bliss-16 V3-555 Page 108 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (35)
021345	105	122	115		ACCTT	/EDM /	3-066-1703	10121104	013N 703EN2: [ 01E 12. NDNA ]ZNWACO. BL1; 02 ( 35 )
021350	111	116	101		.ASCII	/ERM/ /INA/			경기 :
021353	124	iii	117		ASCII	/TIO/			
021356	116	000	***		ASCII	/N/<00>			
021360	045	116	045	P.ALA:	.ASCII	/MNS/			[[[하다]] 그리아 아름아 나는 나는 아니다 나를 다 먹는 것이 없는 것이다.
021363	101			P.ALA;	.ASCII				[[하는 경기 : 1. 2] [[하면 하고 그는 사람이 하면 하고 그 그 그 그 그 그 그 이 없다.]
021365	052	011	052		.ASCII	/A/<11>/4	./		
021366 021371		040	106		. ASCII	/4 F/			
021374	101	124	101		. ASCII	/ATA/			경기 회사 사람들이 하는데 가는 것이 되는데 그런 것이 되었습니다.
021377	114	040	105		.ASCII	/L E/			
021402	122	122	000	0 41 0	. ASCII	/RR/<00>			
021405	045	116	045	P.ALB:	. ASCII	/sNs/			
021410	101	011	052		.ASCII	/A/<11>/4	./		
021413	052 120	040	123		. ASCII	/# S/			1 이 경기 전 경기 등 경기 보고 있다.
021416		105	103		.ASCII	/PEC/			경기 위에서 보고 있는데 보고 있는데 그리고 있는데 그리고 있었다.
021421	111	101	114		. ASCII	/IAL/			
021422	000	116	DAE	0 4 6	.ASCII	<00>			
	045	116	045	P.ALC:	.ASCII	/MNS/			
021425	101	040	055		. ASCII	/A -/			
021430	040	111	114		.ASCII	/ IL/			
021433	114	105	107		. ASCII	/LEG/			
021436	101	114	040		.ASCII .ASCII .ASCII	/AL /			
021441	125	116	111		. ASCII	/UNI/			
021444	124	040	116		. ASCII	/T N/			
021447	125	115	102		.ASCII	/UMB/			
021452	105	122	000		.ASCII	/ER/<00>			어린 경우 아이들 아니다 이 작가 없는 것이 없는 그 때문에 없다.
021455	000		0.00		.ASCII	<00>			
021456	045	116	045	P.ALD:	.ASCII	/95N95/			
021461	101	040	055		.ASCII	/A -/			
021464	040	111	114		.ASCII	/ IL/			
021467	114	105	107		. ASCII	/LEG/			
021472	101	114	040		.ASCII	/AL /			
021475	120	110	131		.ASCII	/PHY/			선거 생물 등 시간 기업을 내려왔다면 없는 것이 되는 것이 되었다고 있다.
021500 021503 021506	123	111	103		. ASCII	/SIC/			
021506	101	114	040		.ASCII	/AL /			
021511	117	122	040		.ASCII	/OR /			
021514	122	105	114		.ASCII	/REL/			병사 중에 가는 이번 하면 있었다. 이렇게 되는 사람들이 되었다.
021517	101	124	111		. ASCII	/ATI/			
021517 021522 021525 021530 021533 021536	126 102	105	040		.ASCII .ASCII .ASCII	/VE /			
021525	103	114	117		.ASCII	/BLO/			
021530	116	113	040		.ASCII	/CK /			
021533	116 102	125	115 122		.ASCII	/NUM/			
021536	000	105	155		.ASCII	/BER/			
021540	045	000	DAE		.ASCII	<00><00>			
021543	101	116	045	P.ALE:	. MSCII	/sins/			요즘 병원 그리고 하다 보다 보다 내가 하는 것이 없다고 있다.
021546	040	104	055 105		. ASCII	/A -/			
021551	126	111	103		.ASCII	/ DE/			
021540 021543 021546 021551 021554 021557 021562	105	040	105		.ASCII	/VIC/			: (1) - [1] : [1]
021557	122	122	000		.ASCII	/E E/ /RR/<00>			
021562	045	116	045	P.ALF:	ASCII				
021565	101	040	055	F.MLF;	.ASCII	/SNS/			
021570	040	132	105		.ASCII	/A -/			20. 하는 10 10.0 이 작은 사람들은 10.0 He
021565 021570 021573	122	132 117	105 040		ASCII	/RO /			
			040		. MJCII	/NU /			

	ZRQAM1 VO1.2		EXERCISER CTION TABLE				5-Dec-1983 5-Dec-1983	10:27:14 10:27:04	VAX-11 Bliss-16 V3-555 Page 109 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
	021576 021601 021604 021607 021612 021615	114 109 107 119 040 119 123 129 107 109	0 124 5 105 3 101		.ASCII .ASCII .ASCII .ASCII .ASCII	/LEN/ /GHT/ / ME/ /SSA/ /GE/<00>			
The case of the ca	021616 021621 021624 021627 021632 021635 021640 021643 021646 021651	045 110 101 040 055 040 123 100 111 040 116 100 122 110 124 111 116 040	0 055 0 101 3 111 0 111 6 117 5 101 1 117	P.ALG:	ASCII	/#N#/ /A -/ /- A/ /SCI/ /I I/ /NFO/ /RMA/ /TIO/ /N /<00>			
	021652 021655 021660 021663 021666 021671 021674 021677 021702 021705	045 110 101 040 055 040 117 110 101 101 111 11 117 120 101 120 117 110	0 055 0 116 6 055 3 123 1 040 6 106 2 115 4 111	P.ALH:	.ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII	/MNM/ /A -/ /- N/ /ON-/ /ACS/ /II / /INF/ /ORM/ /ATI/ /ON/ <oo></oo>			
	021710 021713 021716 021721 021724 021727 021732 021735 021740 021743	045 110 101 040 055 040 105 12: 111 110 124 11 116 040 105 12: 101 10	6 045 0 055 0 124 2 115 6 101 1 117 0 115 3 123	P.ALI:	.ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII	/#N#/ /A -/ /- T/ /ERM/ /INA/ /TIO/ /N M/ /ESS/ /AGE/			
	021744 021747 021752 021755 021760 021763 021766 021771 021774 021777	045 110 101 04 055 04 125 10 105 12 057 10 111 11 122 10 103 11	0 055 0 123 3 103 3 123 6 101 4 125 5 040	P.ALJ:	.ASCII .ASCII .ASCII .ASCII .ASCII .ASCII .ASCII	<pre>&lt;00&gt; /#N#/ /A -/ /- S/ /UCC/ /ESS/ &lt;57&gt;/FA/ /ILU/ /RE / /COD/</pre>			
	022002 022005 022010 022013 022016 022021 022024	105 00 045 11 101 04 055 04 105 11 040 10 116 10 131 04	6 045 0 055 0 123 6 104 2 111 1 122	P.ALK:	ASCII	/E/<00> /#N#/ /A -/ /- S/ /END/ / BI/ /NAR/ /Y D/	00>		

ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Page 110 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
022027 022032 022034 022037 022042 022045	101 124 101 000 000 045 116 045 101 040 055 055 040 123 105 116 104	.ASCII /ATA/ .ASCII <00>< P.ALL: .ASCII /#N#/ .ASCII /A -/ .ASCII /- S/ .ASCII /END/	00>	
022050 022053 022056 022061 022064 022067 022072 022075 022100	040 125 116 111 124 040 116 125 115 102 105 122 054 040 122 105 114 101 124 111 126 105 040 104 102 116 000	.ASCII / UN/ .ASCII /IT / .ASCII /NUM/ .ASCII /BER/ .ASCII /. R/ .ASCII /ELA/ .ASCII /ELA/ .ASCII /E D/ .ASCII /BN/<		
022103 022104 022107 022112 022115 022120 022123 022126	000 045 116 045 101 040 055 055 040 123 105 116 104 040 125 116 111 124 040	P.ALM: .ASCII <00> P.ALM: .ASCII /#N#/ .ASCII /A -/ .ASCII /- S/ .ASCII /END/ .ASCII / UN/		
022131 022134 022137 022142 022145 022150	116 125 115 102 105 122 054 040 122 105 114 101 124 111 126 105 040 104 102 116 054	.ASCII /NUM/ .ASCII /BER/ .ASCII /, R/ .ASCII /ELA/ .ASCII /TIV/ .ASCII /E D/ .ASCII /BN,/		
022153 022156 022161 022164 022167 022172 022175	040 127 122 111 124 105 040 120 101 124 124 105 122 116 000 045 116 045 101 040 055	.ASCII / WR/ .ASCII / ITE/ .ASCII / PA/ .ASCII / TTE/ .ASCII / RN/< P.ALN: .ASCII / SN#/ .ASCII / A - /	00>	
022200 022203 022206 022211 022214 022217 022222 022225 022230 022233 022236 022241 022244 022247	055 040 123 105 116 104 040 125 116 111 124 040 116 125 115 102 105 122 054 040 120 110 131 123	.ASCII /- S/ .ASCII /END/ .ASCII / UN/ .ASCII / IT / .ASCII /NUM/ .ASCII /BER/ .ASCII / P/ .ASCII /HYS/ .ASCII /L B/		
022230 022233 022236 022241 022244 022247 022252	111 103 101 114 040 102 114 117 103 113 040 116 125 115 102 105 122 000 045 116 045	.ASCII /ICA/ .ASCII /L B/ .ASCII /LOC/ .ASCII /K N/ .ASCII /UMB/ .ASCII /ER/< P.ALO: .ASCII /#N#/	00>	
022252 022255 022260	101 040 055 055 040 123	.ASCII /A -/ .ASCII /- S/		

		Π <i>7</i>
ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE	5-Dec-1983 10:27:14 VAX-11 Bliss-16 V3-555 Page 111 5-Dec-1983 10:27:04 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
022263 022274 022277 022302 022305 022310 022313 022316 022321 022324 022327 022332 022334 022337 022342 022350 022350 022353 022354 022357 022362 022365 022370 022373 022376 022370 022373 022370 022373 022376 022370 022373 022376 022370 022373 022376 022370	105	.ASCII / UN/ .ASCII / IT / .ASCII / IT / .ASCII / BER/ .ASCII / BER/ .ASCII / OGI/ .ASCII / OGI/ .ASCII / BC/ .ASCII / RC/ .ASCII / RC/ .ASCII / RC/ .ASCII / TLR/ .ASCII / UI/< .ASCII / IT/ .ASCII / RC/ .ASCII / IT/ .ASCI

										SEQ 01
Î	ZRQAM1		RD/RX EX					5-Dec-1983		VAX-11 Bliss-16 V3-555 Pag
	V01.2		PROTECTIO	ON TABLE				5-Dec-1983	10:27:04	DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (3
-	022517	124	114	122		. ASCII	/TLR/			
	022522	040	122	117		ASCII	/ RO/			
I	022525	115	040	101		ASCII	/M A/			
	022530	116	104	040		ASCII	/ND /			
1	022533	122	101	115		ASCII	/RAM/			
	022536	040	120	101		ASCII	/ PA/			
	022541	122	111	124		ASCII				
-	022544	131	040	105		.ASCII	/RIT/			
1	022547					.ASCII	/Y E/			
-	022541 022544 022547 022552 022555	122	122	000	D 4111	.ASCII	/RR/<00>			
1	022552	045	101	103	P.ALU:	. ASCII	/SAC/			
1	022555	124	114	122		.ASCII	/TLR/			
-	022560	040	122	101		.ASCII	/ RA/			
1	022563	115	040	120		. ASCII	/M P/			
-	022566 022571 022574 022577	101	122	111		.ASCII	/ARI/			
1	022571	124	131	040		. ASCII	/TY /			
1	022574	105	122	122		. ASCII	/ERR/			
-	022577	000				. ASCII	<00>			
1	055600	045	101	103	P.ALV:	. ASCII	/SAC/			
1	022603	124	114	122		. ASCII	/TLR/			
-	022606	040	122	117		. ASCII	/ RO/			
i	022611	115	040	120		. ASCII	/M P/			
-	022614	101	122	111		. ASCII	/ARI/			
-	022617	124	131	040		ASCII	/TY /			
1	022622	105	122	122		.ASCII .ASCII .ASCII	/ERR/			
1	022625	000				.ASCII	<00>			
-	022606 022611 022614 022617 022622 022625 022626 022631 022634 022637	045	101	122	P. ALW:	.ASCII	/#AR/			
-	022631	111	116	107		.ASCII	/ING/			
-	022634	040	122	105		.ASCII	/ RE/			
i	022637	101	104	040		ASCTT	/AD /			
-	022642	105	122	122		.ASCII	/ERR/			
-	022645	040	050	120		ASCII	/ (P/			
-	022650 022653 022656 022661	101	122	111		ASCIT	/ARI/			
-	022653	124	131	040		.ASCII				
-	022656	117	122	040		.ASCII	/TY /			
1	022661	124	111	115		.ASCII	/OR /			
-	022664	105	117	125		. ASCII	/TIM/ /EOU/			
-	022667	124	051	152		. ASCII	/EUU/			
-	022672	045	101	000	DAIV.	. ASCII	/T)/<00>			
-	022675	111		122	P.ALX:	. MSCII	/#AR/			
-	022700	040	116	107		. ASCII	/ING/			
1	022700 022703	040	127	122		. ASCII	/ WR/			
-	022706	111	124	105		. ASCII	/ITE/			
1	022700	040	105	122		. ASCII	/ ER/			
-	022711 022714	122	040	050 122 131		. ASCII	/R (/			
1	022714	120	101	122		. ASCII	/PAR/			
-	022717	111	124 117	151		. ASCII	/ITY/			
*	022717 022722 022725 022730	040	117	122 111		ASCII ASCII ASCII ASCII ASCII ASCII	/ OR/			
	022725	040	124	111		Warti	/ TI/			
-	022750	115	105	117		. ASCII	/MEO/			
-	022733	125	124	051		. ASCII	/UT)/			
1	022736	000	000			. ASCII	<00><00>			
-	022740	111	116	124	P.ALY:	. ASCII	/INT/			
-	022743	105	122	122		.ASCII	/ERR/			
-	022746	125	120	124 122 124		. ASCII	/UPT/			
-										

ZRQAM1 VO1.2	RD/RX EXERC PROTECTION	CISER TABLE		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Page 113 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (35)
022751 022754 022757 022762 022765 022770	040 115 123 124 122 040 101 111 125 122 000 000	101 105 106 114 105	.ASCII / MA/ .ASCII /STE/ .ASCII /R F/ .ASCII /AIL/ .ASCII /URE/ .ASCII <00><00:		
022772 022775 023000 023003 023006 023011 023014 023017 023022 023025 023030	045 101 117 123 040 101 103 105 123 040 111 115 117 125 040 050 111 107 105 122	110 P.ALZ: 124 103 123 124 105 124 110 110	.ASCII /#AH/ .ASCII /OST/ .ASCII / AC/ .ASCII /CES/ .ASCII /S T/ .ASCII /IME/ .ASCII /OUT/ .ASCII / (H/ .ASCII / IGH/		
023033 023036 023041 023044 023047 023052 023055	114 105 105 114 120 122 124 117 117 114 104 105 105 116 105 116 051 000 045 101	126 040 117 103 040 120 104 124	.ASCII /ER / .ASCII /LEV/ .ASCII /EL / .ASCII /PRO/ .ASCII /TOC/ .ASCII /OL / .ASCII /DEP/ .ASCII /END/ .ASCII /ENT/ .ASCII /J<00> .ASCII /#AC/		
023062 023065 023070 023073 023076 023101 023104 023107 023112	122 105 111 124 114 111 111 124 105 130 105 105 105 104 045 101	104 040 115 040 103 104 000 121 P.AMB:	.ASCII /RED/ .ASCII /IT / .ASCII /LIM/ .ASCII /IT / .ASCII /EXC/ .ASCII /EED/ .ASCII /ED/<00:		
023115 023120 023123 023126 023131 023134 023136 023141	055 102 123 040 101 123 105 122 105 122 000 000 045 101 124 114 040 106	115 124 040 122 103 P.AMC:	.ASCII /-BU/ .ASCII /S M/ .ASCII /AST/ .ASCII /ER / .ASCII /ERR/ .ASCII /MAC/ .ASCII /TLR/		
023144 023147 023152 023155 023160 023163 023166 023171 023174 023177	124 101 040 105 122 000 045 101 116 123 122 125 124 111 116 040	101 114 122 000 111 P.AMD: 124 103 117 114	.ASCII /TLR/ .ASCII / FA/ .ASCII / FA/ .ASCII / FA/ .ASCII / ER/ .ASCII /R/<00> .ASCII /AAI/ .ASCII /NST/ .ASCII /RUC/ .ASCII /TIO/ .ASCII /N L/ .ASCII /OOP/	<00>	
023171 023174	124 111 116 040	117	.ASCII /TIO/		

	ZRQAM1 VO1.2		RD/RX EX PROTECTI				5-Dec	c-1983 10:27:14 c-1983 10:27:04	VAX-11 Bliss-16 V3-555 SEQ 0114 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (35)	-
	023205	115	105	117		.ASCII	/MEO/			1
1	023210	125	124	000		. ASCII	/UT/<00>			-
į	023213	000				.ASCII	<00>			1
	023214	045	101	111	P. AME:	. ASCII	/SAI/			-
	023217	114	114	105		.ASCII	/LLE/			
1	023222	107	101	114		ASCII	/GAL/			i
1	023225	040	126	111		. ASCII	/ VI/			
1	023230	122	124	125		.ASCII	/RTU/			-
	023217 023222 023225 023230 023233	101	114	040		. ASCII	/AL /			1
1	023236	103	111	122		.ASCII .ASCII .ASCII	/CIR/			i
	023241	103	125	111		. ASCII	/CUI/			1
1	023244	124	040	111		.ASCII	/T I/			1
1	023247 023252	104	000	000		ASCII	/D/<00><00>			1
1	023252	045	101	111	P. AMF:	. ASCII	/#AI/			1
1	023255	116	124	105		. ASCII	/NTE/			1
1	023260	122	122	125		. ASCII	/RRU/			1
-	023260 023263	120	124	040		.ASCII .ASCII .ASCII	/PT /			1
1	023266	126	105	103		. ASCII	/VEC/			-
1	023271	124	117	122		. ASCII	/TOR/			-
1	023274	040	111	114		ASCII	/ IL/			-
i	023277	114	105	107		.ASCII	/LEG/			1
1	023302	101	114	000		. ASCII	/AL/<00>			1
	023274 023277 023302 023305	000				.ASCII	<00>			1
	023306	045	101	115	P. AMG:	.ASCII .ASCII .ASCII	/#AM/			1
	023311	101	111	116		. ASCII	/AIN/			1
l	023314	124	105	116		. ASCII	/TEN/			
	023311 023314 023317	101	116	103		. ASCII	/ANC/			
1	023322	105	040	122		. ASCII	/E R/			1
1	023325 023330	105	101	104		.ASCII	/EAD/			1
ĺ	023330	057	127	122		. ASCII	<57>/WR/			
1	023333 023336 023341	111	124	105		.ASCII	/ITE/			1
1	023336	040	111	116		. ASCII	/ IN/			1
1	023341	126	101	114		ASCII	/VAL/			-
-	023344 023347	111	104	040		.ASCII	/ID /			-
1	023347	122	105	107		. ASCII	/REG/			1
1	023352	111	117	116		. ASCII	/ION/			1
	023355	040	111 116	104		. ASCII	/ ID/ /ENT/			1
1	023360	105 111	116	124		. ASCII	/ENT/			1
l	023363	111	106	111		.ASCII .ASCII .ASCII	/IFI/			-
l	023366 023371 023372 023375	105	122	000		. ASCII	/ER/<00>			-
	023371	000	***			.ASCII	<00>			
1	023372	045	101	115	P. AMH:	. ASCII	/MAM/			1
-	023373	101	111	116		. ASCII	/AIN/			1
	023400 023403	124	105	116		.ASCII	/TEN/			-
	023406	101	116	103		.ASCII	/ANC/			1
	023411	105	040	127		.ASCII	/E W/			
-	023414	122 105	111	124		.ASCII	/RIT/			1
-	023417		040	114		.ASCII	/E L/			1
-	023422	117 040	101	104		. ASCII	/OAD/			
	023425	040	124	117		.ASCII	/ 10/			
-	023430	116	116 055	117		. ASCII	/ NO/			
-	023430 023433	117	101	114		.ASCII	/N-L/			
1000	020433	11,	101	104		. ASCII	/OAD/			
										- 1

						_ >		
ZRQAM1 VO1.2	RD/RX EXE PROTECTIO						10:27:14 10:27:04	VAX-11 Bliss-16 V3-555 Page 115 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
023436 023441 023444 023447	101 102 105 040 124 114	114 103 122		.ASCII /E	ABL/ E C/ TLR/ 00>			
023450 023453 023456	045 101 124 114 040 122	103 122 101	P.AMI:	.ASCII /1	FAC/ TLR/ RA/			
023461 023464 023467 023472	115 040 122 122 050 116 116 055	105 040 117 120		.ASCII /F	M E/ RR / (NO/ N-P/			
023475 023500 023503	101 122 124 131 000	111 051		.ASCII /A	ARI/ TY)/ DO>			
023504 023507 023512 023515	045 101 116 111 040 123 121 125	111 124 105 105	P.AMJ:	.ASCII /	MAI/ NIT/ SE/ QUE/			
023520 023523 023526 023530 023533 023536	116 103 040 105 122 000	105 122	D. AMY	.ASCII /	NCE/ ER/ R/<00>			
023533 023536 023541	045 101 111 107 105 122 114 105	110 110 040 126	P. AMK:	.ASCII /	#AH/ IGH/ ER / LEV/	,		
023544 023547 023552 023555	105 114 120 122 124 117 117 114	040 117 103 040		.ASCII /F	EL / PRO/ TOC/ OL /			
023541 023544 023547 023552 023555 023560 023563 023566 023571 023574	111 116 117 115 101 124	103 120 111		.ASCII /	INC/ DMP/ ATI/			
023311	102 111 111 124 040 105 122 000	114 131 122		.ASCII /	BIL/ ITY/ ER/ R/<00>			
023604 023607 023612 023615 023620 023623 023626 023631 023634 023637	045 101 125 122 105 057 117 114	120 107 120 114	P.AML:	.ASCII /	#AP/ URG/ E/<57>/P/			
023620 023623 023626	040 110 122 104 101 122	101 127 105		.ASCII /	OLL/ HA/ RDW/ ARE/			
023634 023637 023642	040 106 111 114 122 105 045 101	101 125 000 115	P.AMM:	.ASCII /	FA/ ILU/ RE/<00>			
023642 023645 023650 023653	101 120 111 116 040 122	120 107	r	.ASCII /	APP/ ING/ RE/			
023656 023661 023664	107 111 124 105 040 122	105 123 122 105		.ASCII /	GIS/ TER/ RE/			

-	ZRQAM1 VO1.2		RD/RX EXE					5-Dec-1983 5-Dec-1983	10:27:14 10:27:04	VAX-11 Bliss-16 V3-555 Page 116 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
	023730 023732 023734 023736 023740 023742 023744 023746 023750 023754 023756 023760 023764 023766 023766 023770 023776 023776 023776 023776 023776	101 106 114 105 120 111 040 040 115 125 000 022354 022354 022552 022600 022626 022672 022600 02262672 022740 022772 023160 023112 023160 02314 023252 023372 023372 023504 023504	104 101 125 040 101 124 117 124 105 124	040 111 122 050 122 131 122 111 117 051	P.ALP:	. ASCII . WORD	/AD / /FAI/ /EAR/ /EAR/ /EAR/ /EAR/ /ORI / ORI /			
	024004 024007 024012 024015 024020 024023	045 061 103 040 111 122	101 061 120 106 114 105	124 040 125 101 125 000	P.AMO:	.ASCII .ASCII .ASCII	/#AT/ /11 / /CPU/ / FA/ /ILU/ /RE/<00>			
THE REAL PROPERTY AND ADDRESS OF THE PERSON	024026 024031 024034 024037 024042 024045 024050 024053	045 117 120 111 040 115 122	101 116 101 124 122 040 122	116 055 122 131 101 105 000	P.AMP:	.ASCII .ASCII .ASCII .ASCII .ASCII	/#AN/ /ON-/ /PAR/ /ITY/ / RA/ /M E/ /RR/ <oo></oo>			
The second second on the second secon	024054 024057 024062 024065 024070	000 045 124 105 101 111	101 101 040 103 116	123 124 115 110 105	P.AMQ:	ASCII ASCII ASCII ASCII ASCII ASCII	<00> /#AS/ /TAT/ /E M/ /ACH/ /INE/			

	ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE	5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 SEQ 0117 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
	024073 040 024076 111 024101 122 024104 055 024107 061 024112 101 024115 122 024120 123 024123 105 024126 123 024131 122 024134 045 024137 124 024145 101 024153 040 024156 111 024151 122 024164 055 024167 055 024167 055 024172 123 024175 104 024200 105 024203 040 024206 107 024211 124 024214 000 024216 045 024221 124 024224 105 024221 124 024224 105 024227 101 024235 040 024240 111 024235 040 024240 111 024236 055 024257 111 024262 105	106 101 114 125 105 040 040 124 061 040 104 104 105 123 040 122 107 111 124 105 000 000 101 123 P.AMR: 101 104 125 105 040 040 121 102 125 040 101 114 125 105 040 040 121 102 125 040 101 104 122 123 123 122 105 111 123 105 122 000 101 124 040 105 106 101 114 125 105 040 101 114 125 105 040 101 124 040 115 103 110 116 105 106 101 114 125 105 040 040 103 103 040 104 103 105 107 123 124 122 000	.ASCII / FA/ .ASCII /RE / .ASCII /RE / .ASCII /- T/ .ASCII /- T/ .ASCII /ADD/ .ASCII /ADD/ .ASCII /RES/ .ASCII /S R/ .ASCII /STE/ .ASCII /STE/ .ASCII /ASCII /RES/ .ASCII /ASCII /RAS/ .ASCII /ACH/ .ASCII /ACH/ .ASCII /INE/ .ASCII /INE/ .ASCII /RE / .ASCII /S A/ .ASCII /BU/ .ASCII /BU/ .ASCII /BU/ .ASCII /RE / .ASCII /GIS/ .ASCII /INE/ .ASCII /IN	
The state of the s	024265 000 024266 045 024271 124 024274 105 024277 101 024302 111 024305 040 024310 111 024313 122 024316 055 024321 105 024324 101	101 123 P.AMT: 101 124 040 115 103 110 116 105 106 101 114 125 105 040 040 123 122 111 114 111	.ASCII /ER/<00> .ASCII /OO> .ASCII /OO> .ASCII /AS/ .ASCII /AT/ .ASCII /E M/ .ASCII /ACH/ .ASCII /INE/ .ASCII / FA/ .ASCII /ILU/ .ASCII /ILU/ .ASCII /- S/ .ASCII /ERI/ .ASCII /ALI/	

						DIO	
ZRQAM1		RD/RX EX				5-Dec-1983 10:27:14	VAX-11 Bliss-16 V3-555 SEQ 0118 Page 118
V01.2		PROTECTI	ON TABLE			5-Dec-1983 10:27:04	DISK&USER2:[DIETZ.RDRX]ZRQACO.8L1;82 (35)
024327 024335 024340 024343 024346 024351 024354 024357 024365 024365 024370 024373 024376 024401 024404 024407 024412 024415 024420 024423 024426 024431 024434 024434 024436 024436 024436 024437 024446 024450 024450	132 057 123 111 111 122 105 123 124 105 101 111 040 111 122 055 122 107 101 127 105 101 127 105 101 127 105 101 127 105 101 127 105 105 101 127 105 105 105 105 107 107 107 107 107 107 107 107 107 107	105 104 105 101 132 040 107 124 000 101 101 040 103 116 106 114 105 040 117 040 122 101 040 122 117 000	122 105 122 114 105 122 111 105 000 123 124 115 110 105 101 125 040 127 116 110 104 122 126 123 116	P.AMN:	. ASCII . ASCI	/ZER/ <57>/DE/ /SER/ /IAL/ /IZE/ /R R/ /EGI/ /STE/ /R/<00><00> /#AS/ /TAT/ /E M/ /ACH/ /INE/ / FA/ /ILU/ /RE / /- W/ /RON/ /G H/ /ARD/ /WAR/ /E V/ /ERS/ /ION/ <00><00> P.AMO P.AMP P.AMQ P.AMR	DISKOSERZ:[DIETZ.HURA]ZNURACU.BEI;02 (55)
024454 024456 024460 024462 024465 024470	024216' 024266' 024362' 045 045	101 117 000	040 066	P.AMV:	.WORD .WORD .WORD .ASCII .ASCII	P.AMS P.AMT P.AMU /#A / /#06/ <00><00>	
024472	045	101	157	P. AMW:	. ASCII	/#Ao/	
024500	143 045	164 117	040 064		.ASCII	/ct /	
024503	000	111	004		.ASCII	/#04/	
024504	045	123	064	P.AMX:	. ASCII	<00> /#S4/	
024507	000	153	V04	P.ARA:	.ASCII		
024510	045	116	000	D AMY.	.ASCII	<00>	
024513	000	110	000	P.AMY:	.ASCII	/#N/<00>	
024514	045	101	040	0 447	.ASCII	<00>	
024517		101	040	P.AMZ:	.ASCII	/#A /	
024517	055	040	000		.ASCII	/- /<00>	
024522	045	101	052	P.ANA:	. ASCII	/#A+/	
024525	040	000	000		.ASCII	/ /<00><00>	
024530	000000C			L \$HMLEN	::		
024532	172150			HMPT.IP	. WORD	< <l\$ndhw-l\$hwlen>/2&gt;</l\$ndhw-l\$hwlen>	
004574	000454				. WORD	-5630	그렇고 그렇게 보는 것이 없었다. 그 이 사람이 되는 것이 되었다.
024534	000154			HWPT.VE	CTOR::		
							그 그리다 가는 사람들은 사람들이 가는 것이 가는 것이 되었다.

ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE		5-Dec-1983 10:27:14 VAX-11 Bliss-16 V3-555 Page 119 5-Dec-1983 10:27:04 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (35)
101.2	PROTECTION TROLE	. WORD	5-Dec-1983 10:27:04 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
024536	000004	HWPT.BR.LEVEL::	#####################################
024540	100034	HWPT.DISK::	-77744
024542	000000	HWPT.S.TRK::	
024544	177777	HWPT.E.TRK::	0
024546 024550	000000C	.WORD L\$NDHW::.BLKW L\$SWLEN::	i
024552	000040	SWP.ERROR::	< <l\$ndsw-l\$swlen>/2&gt;</l\$ndsw-l\$swlen>
024554	000000	SWP.XFER::	40
024556	001002	.WORD	0
024560	000000	SWP.DPAT::	1002
024562	000142	SWP.RAT::	
024564	000013	DUPROUND::	142
024566	000020	SWP.UCNT::	13
024570		SWP. UDPAT::	20
024630		L\$NDSW::.BLKW	20
024634	000000 177777	L \$PROT :: . WORD . WORD	0
024636	000006	. WORD	6
000000		CST:: .PSECT	\$FFF\$. RO
000076		CST.ADDR::	1
000100		DCT:: .BLKW DCT.ADDR::	ii
000124		RDRX.ADDR::	1
000126		.BLKW IRDRX.ADDR::	
000130		.BLKW	1
000132		.BLKW	1
000134		IDCT. ADDR::	
	000020	RDM. CNT ::	1
,		HOT. CHT;	

ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04
000140		.WORD 20 RANDOM::.BLKW 20	
000500	001	TRK.SGN::	
000201	001 001	.BYTE 1	
000203	001	DUPPKT::.BLKW 401	
001206		BST:: .BLKW 10 TALLY:: .BLKW 160	
001566 001570		T.ADDR::.BLKW 1 C.ERR.TBL::	
001572		BLKW 1	
		.BLKW 630	
003252		IPKT.ADDR::	
003254		PKT.USE::	
003270 003570		RETPKT::.BLKW 140 RP.USE::.BLKW 2	
003574		RP.INDX::	
003576		RP.ADDR::	
003600		ELOG.PKT::	
005230		BUFF . ADDR :: BLKW 10	
005250		BUFF.OWN::	
005260 005264		IODQ:: .BLKW 2	
005266		IODQ.IN::	
005270		IODQ.OUT::	
		ENTRY . REASON::	
005271		EOP.FLAG::	
005272		DUP.FLAGS:: .BLKW 1	
005274 005276		CCTLR:: .BLKW 1	
005300		CDISK:: .BLKW 1 CUOFF:: .BLKW 1	
005302		CTLR.CNT::	•
005304		DUR:: .BLKW 1	
005310		DUR:: .BLKW 2 QIO:: .BLKB 1 .EVEN	
005312		FREE.MEM.ADDR::	
005314		BYTS.PER.QIO::	

VAX-11 Bliss-16 V3-555 Page 120 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)

	ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Page 121 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
					013N 03ENE. (01E 12. NONA) ZNGHOU. BE1;02 (33)
	005316		ST.CODE::	1	
			.BLKW	1	
	005320		SB.CODE::		
	005322		STEP:: .BLKW		
	005324		OF .RC :: .BLKW	i	
	005326 005330		SA.REG::.BLKW	1	아이들 아이들 아이들 때문에 가는 사람이 되었다.
			.BLKW	1	
	005332		NEX:: .BLKW	1	
1	005334		CRN.LOW::	1	
	005336		CRN.HIGH::		아이들 살아왔다면 하나 아이들은 살아 있다면 하는데
	005340		P. INDEX::	1	이 기계 하는 이 프로그램이다 그는 그는 이 경험을 보고 있다.
1			.BLKW	1	
-	005342		S.DUPPKT::		기계가 하시는데 없는 것이 하시는데 나는데 하는 사람들이 되었다.
-	005344		S.PATTERN:	1	일 없는 그 얼마를 살아가 하는 것이 없는 것이 없는 것이 없다.
1			.BLKW	1	
-	005346		CREDIT.BAL::	1	
	005350		INIT.OCCURED::		[2] :
1	005351		.BLKB NXT.PKT.2USE::	1	교육 시간에 가는 사람이 있는데 그 아니는 얼마나 하는데 없다.
	003031		.BLKB	1	()
ŀ			.GLOBL	L\$SOFT, T\$PTHV, L\$RPT, L\$INIT	: 2011년에 12일 시간 전 12일
			.GLOBL	L&CLEAN, L&LAST, L&HARD, L&DVTYF	
			.GLOBL	L\$DESC, L\$DU, L\$AU, L\$AUTG, T1	지내면 하다 들어가 되었습니다. 한 경기 모든 점 그리고 하는 것은
i		100000 040000	BIT15 BIT14	-100000 40000	[10] [18] [18] [18] [18] [18] [18] [18] [18
		020000	BIT13	20000	
		010000	BIT12	20000	사는 시간에 가장하면 생각하면 많아 하나 있다면 하다 되었다.
		004000 002000	BIT11 BIT10	4000 2000	현대 1956년 1일 전 1954년
1		001000	BIT09==	1000	
		000400 000200	BITOS	400	
		000100	BIT07 BIT06	200	살아내는 내가 되는 것이 되었다. 그 살아 없는 것이 없는 것이 없는 것이 없는 것이 없다.
		000040	BITOS==	40	
		000020 000010	BIT04 BIT03	20	이 경기 가입니다. 아들은 사람들은 아들은 아들은 사람들이 되었다.
		000004	BITO2	4	
1		000002 000001	BITO1	5	
		001000	BIT00 BIT9	1000	
		000400	BITS	400	
		000200	BIT7	200	

ZRQAM1	RD/RX EXERCISER		5-Dec-1983 10:27:14	VAX-11 Bliss-16 V3-555 Page 122
ZRQAM1 V01.2 0001 0000 0000 0000 0000 0000 0000	PROTECTION TABLE  00 40 20 10 04 02 01 40 37 36 35 34 40 00 40 00 00 00 00 00 00 00 00 00 00	BIT6 BIT5 BIT4 BIT3 BIT2 BIT1 BIT0 EF.START EF.RESTART EF.NEW EF.NEW PRIO7 PRIO6 PRIO5 PRIO4 PRIO2 PRIO1 PRIO0 EVL LOT ADR IDU ISR UAM BOE PNI	5-Dec-1983 10:27:14 5-Dec-1983 10:27:04 100 40 20 10 4 2 1 40 37 36 35 34 340 300 240 200 140 100 40 0 0 4 10 20 40 100 20 40 100 20 40 20 20 20 20 20 20 20 20 20 2	VAX-11 Blies-16 V3-555 Page 122 DISK*USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (35)
0200 0400 1000 0001 0245 0001 0001 0001 0002 0003 0004 0005 0006 0006 0006 0007	000 26' 52' 32' 11' 36' 52' 62' 74' 20' 36' 36' 36' 36' 36' 36' 36' 36	IER LOE HOE L	20000 40000 -100000 ERRTYP L\$SMLEN+2 L\$HMLEN+2 L\$REV+1 P.AAA P.AAB P.AAC	

ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Page 123 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (35)
	PROTECTION TABLE	SWQ10== SWQ11== SWQ12== SWQ13== SWQ14== SWQ15== SWQ17== SWQ19== SWQ22== SWM1== DBM12== DBM12== DBM12== DBM23== DBM25== DBM25== DBM25== DBM107== DBM107== DBM107== DBM107== DBM107== DBM108== DW.RSN== MSG.01== MSG.01== MSG.03== RPT1== RPT3== RPT4== RPT3== RPT1== RPT13== RPT13== RPT14== RPT15== RPT15== RPT15== RPT15== RPT15== RPT16== RPT17== RPT16== RPT17== RPT16== RPT17== RPT16== RPT17== RPT16== RPT17== RPT16== RPT17== RPT18== RPT19==	P.A.A.A.A.A.A.A.A.A.A.A.A.A.A.A.A.A.A.A	5-Dec-1983 10:27:04  AP AG AR AS	VAX-11 Bliss-16 V3-555 Page 123 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
005304 005376		EGS.02 EGD.10	P.AC P.AD P.AD	A	

RQAM1	RD/RX EXERCISER PROTECTION TABLE		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555
	0054301	EGD.11==	P.ADC	7
	0054541	EGD.12==	P. ADD	
	0055021	EGD.13==	P. ADE	
	005530'	EGD.14==	P.ADF	
	005550'	EGD.15==	P.ADG	
	005566'	EGD.16	P. ADH	
	005616'	EGD.17	P. ADI	
	005634' 005652'	EGD.18	P. ADJ	
	005670	EGD.19== EGD.20==	P.ADK P.ADL	
	005750	EGD.21==	P. ADM	
	0060521	EGD.22==	P. ADN	
	006112'	EGD.23	P. ADO	
	0061541	EGD.24==	P. ADP	
	006220'	EGH. 30==	P. ADQ	
	0062441	EBS.01==	P. ADR	
	006306'	EBD.10==	P.ADS	
	0063461	EBD.12==	P.ADT	
	006412'	EBD.13==	P.ADU	
	006442'	EBD.14	P. ADV	
	006500' 006534'	EBD.18==	P. ADW	
	006614'	EBD.19== EH.0==	P.ADX P.ADY	
	006652	EH.1==	P. ADZ	
	006710'	EH.2==	P.AEA	
	0067501	EH.3==	P. AEB	
	007006'	EH.4==	P. AEC	
	0070321	EH.5==	P. AED	
	007062'	EH.6==	P.AEE	
	007112'	EH.7==	P.AEF	
	007142'	EH.8	P.AEG	
	007176	EH.9	P.AEH	
	007226' 007256'	EH. 10==	P. AEI	
	007314'	EH.12== EH.13==	P.AEJ P.AEK	
	010016	ERR.COD==	P. AEL	
	010052	ELG.00==	P. AFA	
	010364	ELG.FMT	P.AFB	
	010376'	EX.BDR==	P. AFH	
	010466'	EX.BDW	P.AFI	
	010554	EX.LBR ==	P.AFJ	
	010626	EX.LBW	P.AFK	
	010700'	EX.RBN	P.AFL	
	010764' 011034'	EX.CBR	P. AFM	
	011104	EX.CBW	P. AFN	
	011126'	XX13 XX14	P. AFO P. AFP	
	011142'	XX15	P.AFQ	
	011164	XX16==	P.AFR	
	011212'	XX17	P.AFS	
	011230'	XX18	P.AFT	
	011240'	XX19	P. AFU	
	011252'	XX20	P.AFV	

ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Page 125 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (35)
	011266'	VV21		
	011334	XX21==	P. AFW	
		XX22==	P. AFX	
	011376'	XX23==	P.AFY	
	011432'	XX24==	P.AFZ	
	011472'	XX25	P.AGA	
	011542'	XX26==	P.AGB	
	011616'	XX27==	P.AGC	
	011660'	XX29==	P. AGD	
	011704'	XX30==	P.AGE	
	011732'	XX31==	P.AGF	
	011762'	. XX32==	P.AGG	
	012010'	XX33==	P. AGH	
	012046'	XX34==	P.AGI	
	012116'	XX35==	P. AGJ	
	012144'	XX37==	P. AGK	
	012170'	XX38==	P. AGL	
	012234'	XX39	P. AGM	
	012254'	XX40==	P. AGN	
	012274'	XX41	P. AGO	
	0123241	XX42==	P. AGP	
	012366'	EB.DCT	P. AGQ	
	012434'	EB.COM1==	P. AGR	
	012516'	EB.COM1== EB.PKT==	P.AGS	
	012560'	EB.RAL ==	P. AGT	
	012620'	EB.ADDR==	P. AGU	
	012662'	EBNEX1 ==	P. AGV	
	012736'	EB.NEX2==	P. AGW	
	013034	EBNEX3 ==	P. AGX	
	013130'	EB.SA==	P. AGY	
	013166'	CER.01	P. AGZ	
	013232'	CER.02==	P. AHA	
	013306'	EX.SEQ	P. AHB	
	013326'	EX.CRD==	P. AHC	
	013356'	EX.MTN==	P. AHD	
	013376'	EX.DGM==	P. AHE	
	013414'	EX.RD==	P. AHF	
	013424	EX.WRT==	P. AHG	기가 보고 있다면 내가 되었다고 하는 것이 없는데 모든 사람이 되었다.
	013434'	EX.ACC==	P. AHH	
	013446'	EX.ONL ==	P.AHH P.AHI P.AHJ P.AHK	
	013460'	EX.SCC==	P. AHJ	
	013504	EX.GDS==	P. AHK	
	013526	EX.GDS== EX.ESP==	P. AHL P. AHM	
	013556'	EX.ELP	P.AHM	
	013602	EX.SDD	P. AHN	
	013616'	EX.RCD	P.AHO	
	013636'	EX.ABP	P. AHP	
	013646	SC.SDI== SC.CON==	P. AHQ	
	013672'	SC.CON==	P. AHR	
	013714'	SC.DUP==	P. AHS	
	013744	SC.ONL ==	P.AHT	
	013766'	SC.SON==	P.AHU	
	014006	SC.UNK ==	P. AHV	
	014060'	SC.VOL==	P. AHW	

			010	이 경기 이렇게 하면 가지 않는데 이번 사람들이 되는 것이 하게 되었다면 하다를 보고 있었다. 그런데 이번 사람들이 되었다.
ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Page 126 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)
	4140'	SC.IOP ==	P. AHX	아름이 살아 얼마나 살아 있다면 아니라 아니라 아니라 아니다 나는 것이다.
	4206'	SC.DIS==	P. AHY	
	4300'	SC.FER==	P. AHZ	
	4364'	SC.FER== SC.FE2==	P.AIA	
	4440'	SC.ISH==	P.AIB	바다 나는 그 아이는 살아가지 않는 아이들이 되어 보다 하네요.
	4520'	SC.IS2==	P.AIC	
	4576'	SC.DST==	P.AID	
01	4652'	SC.DS2==	P.AIE	
01	4724'	SC.DST== SC.DS2== SC.ECC== SC.ECD==	P.AIF	
01	5004' 5034'	SC.RCT==	P. AIG	
01	5054	SC.FUL	P.AIH P.AII	
	5130'	SC.576==	P.AIJ	
	52041	SC.FCT	P.AIK	
01	5252'	SC.EC1==	P.AIL	
01	5300'	SC.EC2==	P.AIM	
01	5326'	SC.EC3	P.AIN	
01	5356'	SC.EC1== SC.EC2== SC.EC3== SC.EC4==	P.AIO	
01	5404'	SC.EC5**	P.AIP	
01	5432'	SC.EC6	P.AIQ	
01	5460' 5510'	SC.EC7 SC.EC8 SC.EC9	P.AIR	
01	5540'	SC.EC8	P.AIS	
01	5600'	SC.SWP==	P.AIT P.AIU	
01	5640'	SC.HMP==	P.AIV	
01	5700'	SC.ODA==	P.AIW	그렇게 살아내는 이 그 이번 생각이 되는 것이 없는데 되었다면 되었다.
01	5730'	SC.ODB==	P.AIX	아마다 마시트 이 전에 있다는 그리아 모르는 그리다 하다면 되었다.
	5752'	SC.NXM==	P.AIY	
01	6006'	SC.PAR==	P.AIZ	하기 보고 있으면 생겨를 보면 맛있다. 그리가 그리고 있다.
01	.6040' .6112'	SC.CTO	P.AJA	
01	6170'	SC.SDS SC.EDC	P. AJB	사람들 보는 중요한 가장 그리고 계약하다. 그리고 그렇게 먹었다고 있다고 있다.
	6202'	SC.IDS	P.AJC P.AJD	
01	6252'	SC.SRT==	P.AJE	
01	6344'	SC.SRI	P.AJF	
01	6422'	SC.POE==	P.AJG	
01	6454	SC.RDY==	DAM	
01	.6536 <sup>4</sup>	SC.CLK	P.AJI	· 그리고 :
01	6632	SC.RSP==	P.AJI P.AJJ P.AJK P.AJL P.AJM P.AJN P.AJO	이렇게 하는 것 같아 하는 사람이 하는 사람들이 가면 하는 것이 없다면 하는데
01	6660'	SC.SUR SC.PSP	P. AJR	그는 경기는 이 모든 그들은 아니라의 무리 가게 되었다면 되었다.
01	6732	F.100	P. A.IM	그 경우 그 나는 아이를 하게 하는 것이 하는 것 같아.
01	6766'	F.2	P. AJN	그는 사람들이 되는 사람들이 살아왔다. 그런 바라를 다 먹었다.
01	7020'	F.1** F.2** F.3** F.4**	P.AJO	
01	7052'	F.4	P. AJP	
01	7112'	F.5**	P.AJQ	
01	7166'	F.6 F.7	P. AJR	
01	7240' 7312'	F 8	P.AJS P.AJT	
01	7362	F.8 F.9	P. AJU	
01	7402'	F.10==	P. AJV	
01	.7432'	F.11	P. AJW	
01	7456'	F.12	P.AJX	에 그 그래요 있는 사람들이 되었다. 어디어 가장 얼마나 얼마를 하는 것이다.

				*** ****
ZRQAM1 VO1.2	RD/RX EXERCISER PROTECTION TABLE		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555
0175	504	F.13	P.AJY	
0175		F.14==	P.AJZ	
0176		F.15	P. AKA	
0176		F.16==	P. AKB	
0177		F.17==	P. AKC	
0177		F.18==	P. AKD	
0200	012'	F.19==	P. AKE	
0200		F.20==	P.AKF	
0201		F.21	P.AKG	
0201		EBH.30==	P.AKH	
0201		EBH.44==	P.AKI	
0202		EBH.45==	P. AKJ	
0203	250	EBH.46==	P. AKK	
0204		EBH.47== EBH.48==	P. AKL	
0205	24'	EBH. 49==	P. AKM P. AKN	
0200	36,	DF.0==	P. AKO	
0200		DF.1==	P. AKP	
020		DF.2==	P. AKQ	
0210		DF.3==	P. AKR	
0210		DF.4==	P. AKS	
0210	70'	DF.5==	P.AKT	
0211		DF.6==	P.AKU	
0211		DF.7==	P.AKV	
0212		T.QUE	P.AKW	
0212	256'	T.DEF	P. AKX	
021	10.	T.INF ==	P. AKY	
0213	160'	T.TER T.FAT	P.AKZ P.ALA	
0214		T.SPL==	P.ALB	
0214		E.UNT	P.ALC	
0214		E.BLK==	P.ALD	
0215	540'	E.DEV==	P.ALE	
0215		E.ZER==	P.ALF	
0210		M.ASC==	P.ALG	
0210		M.BIN	P.ALH	
021	10.	M. TER	P.ALI	
021	0021	M.COD== M.DAT==	P.ALJ P.ALK	
0220	34'	M.UR==	P. ALL	
022	104'	M. URP==	P. ALM	
0221	172'	M.UP	P. ALN	
0222	252'	M.UL	P.ALO	
023	726'	CNTR.ERR==	P. ALP	
0244	144'	RDRX.ERR==	P. AMN	
0244	62'	EX.WRD==	P. AMV	
0244	72'	EX.OP==	P.AMW	
0245		SPACE4	P. AMX	
024 024		CRLF==	P. AMY	
024		DASH==	P. AMZ	
024		ASTERISK == DFPTBL ==	P. ANA	
024	552	SFPTBL ==	L#HWLEN+2 L#SWLEN+2	
		3.7.02	LYSHLEHYE	

ZRQAM1 VO1.2

:

.

:

RD/RX EXERCISER PROTECTION TABLE

5-Dec-1983 10:27:14 5-Dec-1983 10:27:04 VAX-11 Bliss-16 V3-555 Page 128 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (35)

PSECT SUMMARY

Psect Name \$CODE\$ \$FFF\$ Words Attributes 5328 RO . I 1397 RO . I

RO . I . LCL. REL. CON RO . I . LCL. REL. CON

LIBRARY STATISTICS

File Total Loaded Percent Read
DISK\$USER2:[DIETZ.RDRX]ZRQACO.L16;14 400 173 43 50

COMMAND QUALIFIERS

BLISS /PDP11 ZRQACO.BL1/LIST=ZRQACO.LI1/OBJECT=ZRQACO.OB1/SOURCE=PAGE:53

```
ZRQAM2
                     RD/RX EXERCISER
                                                                                     5-Dec-1983 10:27:14
                                                                                                                   VAX-11 Bliss-16 V3-555
                     PROTECTION TABLE
                                                                                     5-Dec-1983 10:27:04
                                                                                                                   DISK*USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (36)
             3442 module ZRQAM2 (
:
             3443
.
             3444
                    #title 'RD/RX EXERCISER'
.
             3445
                                          ident = 'V01.2',
             3446
                                          addressing_mode (absolute),
             3447
                                          environment (noeis)
             3448
             3449
             3450
                    begin
:
             3451
:
             3452
                    #sbttl 'DECLARATIONS'
             3453
             3454
                     library 'ZRQACO.L16':
                                                                                   ! RDRX EXERCISER GLOBAL LIBRARY
             3455
             3456
                     require 'BLSMAC.REQ':
                                                                                   ! DIAGNOSTIC SUPERVISOR LIBRARY
             4947
.
             4948
                    forward routine
:
             4949
                          NEX_TRAP : LISR novalue.
             4950
                          EMS_01 : novalue.
             4951
                          EMS_21 : novalue,
                          EMS_13 : novalue.
             4952
             4953
                          EMS_DUP : novalue,
.
             4954
                          EMS_BLK : novalue.
.
             4955
                          EMSCMD : NOVALUE,
.
                          SET_CPAR : novalue,
SET_UPAR : novalue,
             4956
:
             4957
             4958
                          EMS_DBN : novalue:
             4959
.
                     external
             4960
                          CST : blockvector [MAX_CTLR, CST_LEN, word] field (CST_FIELDS), ! RUN-TIME CONTROLLER STATUS TABLES
.
             4961
                          CST_ADDR : ref block [CST_LEN, word] field (CST_FIELDS),
! CONTROLLER STATUS TABLE ADDRESS OF "CURRENT" CONTROLLER
DCT : blockvector [MAX_CTLR, DCT_LEN, word] field (DCT_FIELDS),
! DRIVER CONTROLLER TABLES
             4962
             4963
             4964
             4965
:
                          DCT_ADDR : ref block [DCT_LEN, word] field (DCT_FIELDS).
! ADDRESS OF "CURRENT" DRIVER CONTROLLER TABLE
             4966
             4967
                          RDRX_ADDR : ref rdrx field (RC_REG).
! DEVICE ADDRESS OF "CURRENT" CONTROLLER
IRDRX_ADDR : ref rdrx field (RC_REG).
! DEVICE ADDRESS OF INTERRUPTING CONTROLLER
             4968
             4969
             4970
             4971
                          ICOM_ADDR : ref block [COMM_LEN, word] field (COM_FIELDS).
! ADDRESS OF INTERRUPTING CONTROLLER'S COMMUNICATION AREA
             4972
             4973
             4974
                          ICST_ADDR : ref block [CST_LEN, word] field (CST_FIELDS),
! ADDRESS OF INTERRUPTING CONTROLLER'S CST
             4975
             4976
                          IDCT_ADDR : ref block [DCT_LEN, word] field (DCT_FIELDS).
! ADDRESS OF INTERRUPTING CONTROLLER'S DCT
:
             4977
.
             4978
                          RDM_CNT : word.
:
                                                                                    ! NUMBER OF RANDOM NUMBERS \ KEEP
             4979
             4980
                          RANDOM : vector [RDM_LEN, word],
:
                                                                                  ! RANDOM NUMBER TABLE
                                                                                                                         / TOGETHER
             4981
             4982
                          TRK_SGN : vector [MAX_UNITS, byte, signed],
                                                                                                       ! CURRENT TRACK DIRECTION
             4983
             4984
                          DUPPKT : BLOCK [257, WORD] field (DP_FIELDS).
:
```

```
ZRQAM2
                    RD/RX EXERCISER
                                                                                 5-Dec-1983 10:27:14
                                                                                                               VAX-11 Bliss-16 V3-555
V01.2
                    DECLARATIONS
                                                                                 5-Dec-1983 10:27:04
                                                                                                               DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (36)
            4985
                                                  ! BUFFER CONTAINING DUP INFORMATION FROM RECEIVE AND SEND COMMANDS
                         BST : blockvector [MAX_UNITS, 2, WORD]
            4986
            4987
                                                  ! CONATIN LBNS(LO & HI FIELDS) FOR SEQUENTIAL I/O TRANSFER FOR EACH UNIT
            4988
                         TALLY : vector [MAX_UNITS * TALLY_LEN, word] field (T_FIELDS),
            4989
                                                    STATISTICS TABLES
                        T_ADDR : ref block [TALLY_LEN, word] field (T_FIELDS),
! ADDRESS OF STATISTICS TABLE (TALLY) FOR CURRENT UNIT
C_ERR_TBL : blockvector [MAX_CTLR, C_ERR_LEN, word] field (C_ERR_FIELDS),
! STATISTICS TABLE FOR CONTROLLER ERRORS
! STATISTICS TABLE FOR CONTROLLER ERRORS
            4990
            4991
             4992
             4993
                         MSCP_PKT : blockvector [PKT_CNT, PKT_LEN, word] field (PKT_FIELDS),
             4994
             4995
                                                   ! MSCP PACKET POOL
                         IPKT_ADDR : ref block [PKT_LEN, word] field (PKT_FIELDS),
! ADDRESS OF AN MSCP PACKET (INTERRUPT PROCESSING)
             4996
            4997
                        PKT_USE : vector [PKT_CNT, byte, signed].
! MSCP PACKET POOL ALLOCATION TABLE
             4998
             4999
                         RETPKT : blockvector [RP_CNT, RP_LEN, word] field (RP_FIELDS), ! RETURN PACKET POOL
             5000
             5001
                         RP_USE : vector [RP_CNT, byte, signed].
! RETURN PACKET POOL ALLOCATION TABLE
             5002
             5003
             5004
                         RP_INDX : word.
                                                    CURRENT RETURN PACKET INDEX
             5005
                         RP_ADDR : ref block [RP_LEN, word] field (RP_FIELDS), ! CURRENT RETURN PACKET ADDRESS
             5006
             5007
                         ELOG_PKT : blockvector [EP_CNT, EP_LEN, word] field (EP_FIELDS), ! ERROR-LOG PACKET SAVE AREA
             5008
                        BUFF_ADDR : vector [MAX_BUF_CNT],
BUFF_OWN : vector [MAX_BUF_CNT, byte, signed],
             5009
                                                                                          ! TABLE OF I/O BUFFER DESCRIPTORS
             5010
                                                                                          ! I/O BUFFER OWNERSHIP (CONTROLLER NUMBER)
            5011
                         IODQ : vector [IODQ_LEN, byte],
             5012
                                                                       ! I/O DONE QUEUE - CIRCULAR QUEUE OF RETPKT INDECES
             5013
                         IODQ_IN : word, IODQ_OUT : word,
                                                                        I/O DONE QUEUE IN POINTER
             5014
                                                                        I/O DONE QUEUE OUT POINTER
             5015
                         ENTRY_REASON : byte,
                                                                         CURRENT OPERATOR COMMAND
                        EOP_FLAG : byte,
DUP_FLAGS : WORD,
CCTLR : word,
             5016
                                                                         END-OF-PASS FLAG
             5017
                                                                         DUP FLAGS
             5018
                                                                         NUMBER OF "CURRENT" CONTROLLER
             5019
                         CDISK : word,
                                                                         CURRENT DISK ADDRESS (RD/RX DISK NUMBER)
             5020
                         CUOFF : word,
                                                                         CURRENT UNIT CST OFFSET
             5021
                         CTLR_CNT : word.
                                                                         TOTAL NUMBER OF CONFIGURED CONTROLLERS
             5022
                         DUR : vector [MAX_UNITS, byte],
                                                                         DROP UNIT REASON
             5023
                         QIO : vector [MAX_CTLR, byte],
                                                                         NUMBER OF OUTSTANDING QIOS PER CONTROLLER
             5024
                         FREE_MEM_ADDR,
                                                                         START OF FREE MEMORY
                         BYTS_PER_QIO : word,
ST_CODE : word,
SB_CODE : word,
             5025
                                                                         SIZE (BYTES) OF AN I/O BUFFER
             5026
                                                                         CURRENT STATUS CODE
                                                                        CURRENT SUB-CODE
CURRENT STEP IN HARD_INIT
OFFSET (O OR 2) TO READ IP OR SA
STORAGE FOR SA REGISTER READS AND WRITES
             5027
             5028
                         STEP : word,
             5029
                         OF_RC : signed word,
                         SA_REG : word.
             5030
             5031
                         CMD_TIME : word,
                                                                         COMMAND TIMEOUT VALUE (IN SECONDS)
             5032
                                                                         NON-EXISTENT MEMORY TRAP INDICATOR
                         NEX : word,
             5033
                         CRN_LOW : word,
                                                                         COMMAND REF NUMBER OF LAST COMMAND SENT
             5034
                         CRN_HIGH : word.
                                                                         COMMAND REF NUMBER (HI ORDER)
                         P_INDEX : signed word, S_DUPPKT : WORD,
             5035
                                                            ! CURRENT message PACKET INDEX
             5036
                                                            ! DBN BYTE COUNTER
.
                         S_PATTERN : WORD.
             5037
                                                            ! THE PATTERN WRITTEN TO DBN'S
```

```
ZRQAM2
                      RD/RX EXERCISER
V01.2
                      DECLARATIONS
                            CREDIT_BAL : word. INIT_OCCURED : BYTE.
              5039
:
              5040
                            NXT_PKT_2USE : byte.
              5041
                            DBM5.
              5042
                            DBM107.
              5043
                            DU_MSG.
                           DU_RSN : vector [12],
ERR_COD : vector [14],
ELG_FMT : vector [5],
              5044
              5045
              5046
5047 !
              5048
                            HWQ1.
              5049
                            HWQ2.
              5050
                            HWQ3.
              5051
                            HWQ4.
              5052
                            HWQ6.
              5053
                            HWQ7.
              5054
                            HWQ8.
              5055
                            HWQ9.
              5056
                            HWQ10.
              5057
5058
                            HWQ11.
                            SWQ1.
                            SWQ2.
              5059
                            SHQ4.
SHQ7.
              5060
              5061
              5062
5063
5064
5065
                            SWQ9.
                            SWQ10,
SWQ11,
                            SWQ12.
              5066
5067
5068
5069
5070
5071
                            SWQ13.
                            SWQ14.
                            SWQ15.
                            SWQ17.
                            SWQ19.
                            SWQ22.
              5072
5073
                            SWM1.
              5074
5075
                            NULL.
                           MSG_01,
MSG_02,
MSG_03,
RPT1,
RPT2,
              5076
              5077
              5078
5079
              5080
5081
5082
                            RPT3.
                            RPT4.
                            RPTS.
                            RPT6.
RPT7.
              5083
              5084
              5085
                            RPT8.
              5086
                            RPT9.
              5087
                            RPT10.
              5088
                            RPT11.
              5089
                            RPT12.
              5090
                            RPT13,
```

5-Dec-1983 10:27:14 VAX-11 Bliss-16 V3-555 Page 131 5-Dec-1983 10:27:04 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (36)

! CREDIT BALANCE ! INDICATES IF EXERCISER FINISHED INIT SEQUENCE ! POINTER TO NEXT ENTRY IN PKT\_USE TABLE

ZRQAM2 VO1.2	F	D/RX EXERCISER DECLARATIONS
	5091 5092 5093 5094 5095 5096 5097 5098 5099 5100 5101 5102 5103 5104 5105 5106 5107 5108 5109 5110 5111 5112 5113 5114 5115 5126 5127 5128 5129 5120 5121 5122 5123 5124 5125 5126 5127 5128 5129 5130 5131 5132 5133 5134 5135 5136 5137 5138 5139 5140 5141 5142 5143	RPT14. RPT15. RPT16. RPT17. RPT18. RPT19. EGS_01. EGS_02. EGD_10. EGD_11. EGD_12. EGD_13. EGD_14. EGD_15. EGD_16. EGD_17. EGD_16. EGD_20. EGD_21. EGD_22. EGD_23. EGD_24. EGD_24. EGM_30. EH_0. EH_1. EH_2. EH_3. EH_5. EH_6. EH_7. EH_6. EH_7. EH_6. EH_12. EH_13. EBD_14. EBD_13. EBD_14. EBD_13. EBD_14. EBD_18. EBD_19. EX_BDM, EX_BDM, EX_LBM, EX_CBR, EX_CBM,

VAX-11 Bliss-16 V3-555 Page 132 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (36) 5-Dec-1983 10:27:14 5-Dec-1983 10:27:04

```
ZRQAM2
                       RD/RX EXERCISER
V01.2
                       DECLARATIONS
                      XX13.
               5145
                       XX14.
:
               5146
                       XX15.
               5147
                       XX16.
               5148 XX17.
               5149 XX18.
               5150 XX19,
               5151 XX20.
               5152 XX21.
               5153
                       XX22.
               5154
                       XX23.
               5155
                       XX24.
               5156
                       XX25.
              5157
5158
5159
                       XX26.
:
                      XX27.
XX29.
:
:
              5160
                      XX30.
:
               5161 XX31.
              5162 XX32.
5163 XX33.
               5164 XX34,
               5165 XX35.
               5166 !XX36.
               5167 XX37.
               5168
                       XX38.
              5169
                       XX39.
              5170
5171
                       XX40.
.
                       XX41.
              5171 XX41,
5172 XX42,
5173 EB_DCT,
5174 EB_COMM,
5175 EB_PKT,
5176 EB_RAL,
               5177 EB_ADDR.
               5178 EBNEX1.
              5179 EBNEX1,
5180 EBNEX3,
5181 EB_SA,
5182 CER_01,
5183 CER_02,
:
:
.
.
                            EX_SEQ.
EX_CRD.
EX_MTN,
EX_DGM.
EX_HRT.
EX_ACC.
EX_ONL.
EX_SCC.
EX_GDS.
EX_ESP.
EX_SDD,
               5184
:
               5185
:
               5186
:
               5187
               5188
               5189
               5190
               5191
              5192
5193
              5194
5195
:
               5196
```

SEQ 0133 VAX-11 Bliss-16 V3-555
DISK\*USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (36) 5-Dec-1983 10:27:14 5-Dec-1983 10:27:04

ZRQAM2 VO1.2		RD/RX EXERCISER DECLARATIONS
	5197 5198 5199 5200 5201 5202 5203 5204 5205 5206 5207 5210 5211 5212 5213 5214 5213 5214 5215 5221 5222 5223 5224 5223 5224 5225 5226 5227 5228 5229 5230 5231 5232 5232 5233 5236 5237 5238 5237 5238 5238 5238 5238 5238 5238 5238 5238	SC_DIS. SC_FER. SC_FE2. SC_ISH. SC_ISH. SC_IS2. SC_DST. SC_DS2. SC_ECC. SC_ECC. SC_ECT.

E11

VAX-11 Bliss-16 V3-555 SEQ 0134
DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (36) 5-Dec-1983 10:27:14 5-Dec-1983 10:27:04

```
ZRQAM2
                                                       RD/RX EXERCISER
V01.2
                                                       DECLARATIONS
                                 5250 F.4.

5251 F.5.

5252 F.6.

5253 F.7.

5254 F.8.

5255 F.9.

5256 F.10.

5257 F.11.

5258 F.12.

5259 F.13.

5260 F.14.

5261 F.15.

5262 F.16.

5263 F.17.

5264 F.18.

5265 F.19.
:
                                 5262 F_16,
5263 F_17,
5264 F_18,
5265 F_19,
5266 F_20,
5267 F_21,
.
:
                                                                    EBH_30,
EBH_44,
                                  5268
:
                                  5269
                                  5270
5271
5272
5273
5274
5275
5276
5277
5278
5279
                                                                     EBH_45.
                                                                    EBH_45.

EBH_46.

EBH_47.

EBH_49.

df_0.

df_1.

df_2.

df_3.

df_4.

df_5.

df_6.

df_7.

T_QUE.

T_DEF.
.
                                  5280
                                  5281
5282
                                  5283
5284
5285
                                                                     T_DEF.
T_INF.
T_TER.
T_FAT.
                                  5286
5287
5288
5289
5290
5291
5292
5293
5294
5295
5296
5297
5298
5299
5300
5301
5302
                                                                     T_SPL.
E_UNT.
                                                                    E_BLK.
E_DEV.
E_ZER.
                                                                     M_ASC.
                                                                     M_BIN.
                                                                     M_TER,
                                                                     M_COD.
                                                                     M_DAT.
                                                                     M_UR ,
M_URP,
.
                                                                    M_UP,
M_UL,
CNTR_ERR : vector [23],
.
:
```

5-Dec-1983 10:27:14 VAX-11 Bliss-16 V3-555 Page 135 5-Dec-1983 10:27:04 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (36)

```
ZRQAM2
                                       RD/RX EXERCISER
                                                                                                                                                               5-Dec-1983 10:27:14
                                                                                                                                                                                                                       DISK*USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (36)
V01.2
                                       DECLARATIONS
                                                                                                                                                               5-Dec-1983 10:27:04
                         5303
                                                 RDRX_ERR : vector [7].
                                                EX_WRD,
EX_OP,
SPACE4,
                        5304
                         5305
                         5306
                         5307
                                                 CRLF.
                         5308
                                                 DASH.
                         5309
                                                 ASTERISK.
                                                SWP_FLAGS : word,
L$HIMEM,
                         5310
                         5311
                         5312
                                                L$LUN.
                         5313
                                                L$UNIT;
                         5314
.
                         5315
.
                         5316
                                      OWN
                                                 TBL_SUC : vector [17] initial (NULL, SC_SDI, SC_CON, NULL, SC_DUP, NULL, SC_SON),
TBL_OFL : vector [9] initial (SC_UNK, SC_VOL, SC_IOP, NULL, SC_DUP, NULL, NULL,
                         5317
                         5318
                         5319
                                                TBL_OFL: vector [9] initial (SC_UNK, SC_VOL, SC_IOP, NULL, SC_DUP, NULL NULL, NULL, SC_DIS),

TBL_MFE: vector [11] initial (SC_FER, NULL, SC_ISH, SC_DST, SC_EC9, SC_576, SC_FCT, SC_ECC, SC_RCT, SC_FUL, SC_EC1),

TBL_MPT: vector [3] initial (NULL, SC_SMP, SC_HMP),

TBL_DAT: vector [16] initial (SC_FE2, NULL, SC_IS2, SC_DS2, SC_EC9, NULL, NULL, SC_ECD, SC_ECD, SC_EC1, SC_EC3, SC_EC4, SC_EC5, SC_EC6, SC_EC7, SC_EC8),

TBL_MST: vector [5] initial (NULL, SC_ODA, SC_ODB, SC_NXM, SC_PAR),

TBL_CNT: vector [4] initial (SC_CT0, SC_SDs, SC_EDC, SC_IDS),

TBL_DRV: vector [9] initial (NULL, SC_SRI, SC_POE, SC_RDY, SC_CLK, SC_RSP, SC_SUR, SC_PSP);
                         5320
                         5321
                         5322
                         5323
                         5324
                         5325
                         5326
.
                         5327
.
                         5328
:
                         5329
:
```

## H11

ZRQAM2 VO1.2		RD/RX EXERCISER TYPE AND DESCRIPTION	5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Page 137 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (37)
:	5330 5331	#sbttl 'TYPE AND DESCRIPTION'		
	5332 5333	EQUALS;		
	5334	DEVTYP (#asciz'RQDX1'); DESCRIPT (#asciz'RD/RX EXERCISER');	! NAME OF DEVICE SUPPORTED BY ! TEST DESCRIPTION	PROGRAM

```
ZRQAM2
                       RD/RX EXERCISER
                                                                                               5-Dec-1983 10:27:14
5-Dec-1983 10:27:04
                                                                                                                                 VAX-11 Bliss-16 V3-555
V01.2
                       HARDWARE PARAMETER CODING SECTION
                                                                                                                                 DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (38)
               5336 #sbttl 'HARDWARE PARAMETER CODING SECTION'
               5337
:
               5338 !+
               5339 ! THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
               5340 ! THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
               5341 ! MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
               5342 ! INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
.
               5343
                       ! MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
.
               5344 ! WITH THE OPERATOR.
.
               5345 !-
:
              5346
5347 BGNHRD:
:
.
.
              5349 GPRMA (HMQ1, 0, 0, %o'160000', %o'177777', YES, 1);
5350 GPRMA (HMQ2, 2, 0, %o'4', %o'774', YES, 1);
5351 GPRMD (HMQ3, 4, 0, %o'377', %o'0', %o'7', YES, 1);
5352 GPRMD (HMQ4, 6, D, %o'3', %decimal'0', %decimal'3', YES, 1);
5353 GPRML (HMQ10, 6, %o'000010', YES, 1);
                                                                                                                                 ! IP ADDRESS
:
.
                                                                                                                                 ! VECTOR
.
                                                                                                                                 ! BR LEVEL
.
                                                                                                                                 ! RDRX DRIVE NUMBER
.
                                                                                                                                 ! run dup exerciser
              5354 XFERF (NODU);
5355 GPRML (HMQ11, 6, %0'000020', YES, 1);
             5350 $L (NODU);

5357 GPRMD (HMQ6, 8, D, %o'177777', %decimal'0', %0'177777', YES, 1);

5358 GPRMD (HMQ7, 10, D, %o'177777', GP$ATLO (8), %0'177777', YES, 1);

5359 GPRML (HMQ8, 6, %o'100000', NO, 1);

5360 XFERF (HMDONE);

5361 GPRML (HMQ9, 6, %o'100000', NO, 1);

5362 $L (HMDONE);
:
                                                                                                                                 ! WRITE TO DBN'S
:
                                                                                                                          ! STARTING LBN
.
.
                                                                                                                                 ! ENDING LBN
.
.
.
               5363
:
               5364 ENDHRD:
:
```

```
RD/RX EXERCISER
ZRQAM2
                                                                                    5-Dec-1983 10:27:14
                                                                                                                 VAX-11 Bliss-16 V3-555
V01.2
                    SOFTWARE PARAMETER CODING SECTION
                                                                                                                 DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (39)
                                                                                    5-Dec-1983 10:27:04
             5365 #sbttl 'SOFTWARE PARAMETER CODING SECTION'
             5366
.
             5367
:
             5368
                   ! THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
             5369
                    ! THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
             5370
                    ! MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
                    ! INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
             5371
                    ! MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
             5372
             5373
                    ! WITH THE OPERATOR.
:
             5374
                    ! -
:
             5375
:
             5376
                   BGNSFT:
:
             5377 !
.
            5378 !GPRML (SWQ16, 4, SWF_TRC, YES, 1);
5379 GPRMD (SWQ1, 0, D, #0'177777', 0, 65535, YES, 1);
5380 GPRMD (SWQ2, 2, D, #0'177777', 0, 99, YES, 1);
5381 GPRMD (SWQ22, 10, D, #0'177777', 0, 144, YES, 1);
5382 GPRML (SWQ15, 4, SWF_CST, YES, 1);
5383 !GPRML (SWQ20, 4, SWF_FER, YES, 1);
5384 !GPRML (SWQ20, 4, SWF_HOE, YES, 1);
5385 GPRML (SWQ21, 4, SWF_HOE, YES, 1);
5386 XFERF (SW2);
5387 GPRMD (SWQ17, 8, D, #0'177777', 0, 100, YES, 1);
5388 $L (SW2);
:
                                                                                             ! ENABLE DIAGNOSTIC TRACE
                                                                                             ! ERROR LIMIT
.
                                                                                             ! TRANSFER LIMIT
                                                                                  ! NUMBER OF DBN'S WRITTEN AT ONE TIME ! CLEAR STATISTICAL TABLES ?
:
:
                                                                                  ! REWRITE BLOCKS WHEN "FORCED ERROR" BIT SET?
.
                                                                                 ! HALT ON HARD/SOFT ERRORS WITH 'HOE' FLAG SET?
.
                                                                                  ! RANDOM UNIT MODE ?
:
                                                                                  ! IF ANSWER FALSE NO SENSE IN ASK RATIO OF RDs TO RXS
.
             5388
                    $L (SH2);
.
             5389
                    GPRML (SWQ19, 4, SWF_BLK, YES, 1);
                                                                                   ! RANDOM BLOCK MODE?
.
                    GPRML (SWQ7, 4, SWF_CRC, YES, 1);
             5390
:
                                                                                   ! READ-COMPARES AT CONTROLLER ?
             5391
                    DISPLAY (SWM1);
                                                                                   ! REMAINING QUESTIONS ONLY APPLY ...
             5392 GPRML (SWQ9, 4, SWF_CWC, YES, 1);
5393 XFERF (SW3);
                                                                                   ! WRITE-COMPARES AT CONTROLLER ?
.
:
                                                                                  ! IF NO. DO NEXT QUESTION
             5394
                    XFER (SW4);
.
             5395
:
                    $L (SW3);
             5396
                    GPRML (SWQ10, 4, SWF_HMC, YES, 1);
                                                                               ! CHECK WRITES AT HOST BY READING ?
             5397
                    $L (SW4);
                   GPRML (SWQ11, 4, SWF_UDP, YES, 1);
XFERF (SW5);
             5398
                                                                                 ! USER-DEFINED DATA PATTERN ?
             5399
                                                                                  ! IF NO. DO NEXT QUESTION
             5400 XFER (SW6);
             5401 $L (SW5);
:
             5402 GPRMD (SWQ12, 6, D, #0'177777', 0, DP_CNT, YES, 1);
.
                                                                                         ! SELECT PRE-DEFINED DATA PATTERN
             5403 XFER (SW7);
                                                                                             ! DONE
             5404 $L (SM6);
.
             5405 GPRMD (SWQ13, 12, D, %0'177777', 1, MAX_UDP_CNT, YES, 1): NO. OF WORDS IN USER DATA PATTERN 5406 GPRMD (SWQ14, 14, 0, %0'177777', 0, %0'177777', NO, 12): PATTERN VALUES
             5407
                    $L (SW7):
:
             5408
.
             5409 ENDSFT;
:
```

```
SEQ 0140
ZRQAM2
                   RD/RX EXERCISER
                                                                               5-Dec-1983 10:27:14
                                                                                                            VAX-11 Bliss-16 V3-555
V01.2
                   REPORT CODING SECTION
                                                                               5-Dec-1983 10:27:04
                                                                                                            DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (40)
            5410 #sbttl 'REPORT CODING SECTION'
            5411
:
            5412
5413
                   ! THE REPORT CODING SECTION CONTAINS THE
            5414
                   ! "PRINTS" CALLS THAT GENERATE STATISTICAL REPORTS.
            5415
            5416
            5417
                   BGNRPT:
            5418
                                                                                                            ! PRINTS MSCP DATA
            5419
                   PRINTS (RPT1):
            5420
                   PRINTS (RPT2):
            5421
                   PRINTS (RPT3):
                  PRINTS (RPT4);
PRINTS (RPT5);
PRINTS (RPT6);
            5422
            5423
.
            5424
:
            5425
.
            5426
                   incr CTLR from 0 to MAX_CTLR - 1 do
            5427
                        begin
SET_CPAR (.CTLR);
            5428
            5429
            5430
                        incr DISK from (0 + OF_UN) to (3 * UNIT_SIZE + OF_UN) by UNIT_SIZE do
.
            5431
                             begin
SET_UPAR (.DISK);
            5432
            5433
            5434
                             if (.CST_ADDR [.DISK, D_TYPE] eql RX_50) and (.CST_ADDR [.DISK, D_PRES] eql PRESENT)
                                                                                                                                !RX 50
            5435
            5436
5437
5438
                                  PRINTS (RPT7, .L$LUN, .CST_ADDR [.DISK, D_DISK_NUM]);
            5439
                             if (.CST_ADDR [.DISK, D_TYPE] eql RD_51) and
                                                                                                                                !RD51
            5440
                                 (.CST_ADDR [.DISK, D_PRES] eq1 PRESENT)
            5441
            5442
                                  PRINTS (RPT8, .L$LUN, .CST_ADDR [.DISK, D_DISK_NUM]);
            5443
            5444
                             if (.CST_ADDR [.DISK, D_TYPE] eql RD_52) and (.CST_ADDR [.DISK, D_PRES] eql PRESENT)
                                                                                                                                !RD52
            5445
            5446
                             then
            5447
                                  PRINTS (RPT17, .L#LUN, .CST_ADDR (.DISK, D_DISK_NUM));
            5448
            5449
                             if (.CST_ADDR (.DISK, D_TYPE) neq RD_52) and (.CST_ADDR (.DISK, D_TYPE) neq RD_51) and (.CST_ADDR (.DISK, D_TYPE) neq RX_50) and (.CST_ADDR (.DISK, D_PRES) eq1 PRESENT)
                                                                                                                                !RD52
            5450
            5451
            5452
            5453
            5454
                                  PRINTS (RPT19, .L$LUN, .CST_ADDR [.DISK, D_DISK_NUM]);
            5455
            5456
            5457
                             if .CST_ADDR [.DISK, D_PRES] eq1 PRESENT
            5458
                             then
            5459
                                  begin
PRINTS (RPT9,
            5460
:
            5461
                                       .T_ADDR [TOT_READS_HI], .T_ADDR [TOT_READS_LO],
            5462
                                       .T_ADDR [MTOT_BYT_RED], .T_ADDR [TOT_BYT_RED_HI], .T_ADDR [TOT_BYT_RED_LO]);
```

Page 141

```
SEQ 0141
ZRQAM2
                  RD/RX EXERCISER
                                                                          5-Dec-1983 10:27:14
                                                                                                     VAX-11 Bliss-16 V3-555
V01.2
                  REPORT CODING SECTION
                                                                                                    DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (40)
                                                                          5-Dec-1983 10:27:04
           5463
           5464
                                    .T_ADDR (TOT_WRITES_HI), .T_ADDR (TOT_WRITES_LO), .T_ADDR (MTOT_BYT_WRT], .T_ADDR (TOT_BYT_WRT_HI), .T_ADDR (TOT_BYT_WRT_LO));
           5465
           5466
                                PRINTS (RPT10,
                                    .T_ADDR [ERR_HRD_SEK], .T_ADDR [ERR_HRD_DAT], .T_ADDR [ERR_HRD_DRV], .T_ADDR [ERR_HRD_HST]
           5467
           5468
                                    .T_ADDR [ERR_SFT_SEK], .T_ADDR [ERR_SFT_DAT], .T_ADDR [ERR_SFT_DRV], .T_ADDR [ERR_SFT_HST]);
           5469
           5470
           5471
                           end:
           5472
:
           5473
5474
                       if .CST [.CTLR, STATE] eql PRESENT
                       then
           5475
                           begin
PRINTS (RPT11):
           5476
           5477
                           PRINTS (RPT12, .C_ERR_TBL [.CTLR, C_ERR_HRD], .C_ERR_TBL [.CTLR, C_ERR_SFT]);
            5478
                           end:
           5479
                       PRINTS (CRLF);
            5480
            5481
            5482
                       end:
            5483
                  begin
                                                                                                     ! PRINTS DUP DATA
            5484
                  prints(crlf);
                  PRINTS(RPT13); !+
           5485
           5486
                  PRINTS(RPT14);
                  PRINTS(RPT15);
            5487
:
            5488
                  INCR CTLR FROM O TO MAX_CTLR-1 DO
            5489
                           BEGIN
            5490
                           SET_CPAR(.CTLR);
                           INCR DISK FROM (0+0F_UN) TO (3*UNIT_SIZE+OF_UN) BY UNIT_SIZE DO
           5491
           5492
                                    BEGIN
           5493
                                    SET_UPAR(.DISK);
           5494
                                    IF .CST_ADDR[.DISK, D_TYPE] EQLU RD_51 and .CST_ADDR [.DISK, D_PRES] eq1 PRESENT
           5495
5496
                                    THEN
                                PRINTS (RPT16,
.L$LUN, .CST_ADDR [.DISK, D_DISK_NUM],
.T_ADDR [T_DBN_RD], .T_ADDR [T_BLK_RD], .T_ADDR [T_DBN_WT], .T_ADDR [T_BLK_WT]);
           5497
         P
           5498
5499
           5500
                                    IF .CST_ADDR[.DISK, D_TYPE] EQLU RD_52 and .CST_ADDR [.DISK, D_PRES] eq1 PRESENT
           5501
5502
                                    THEN
                                PRINTS (RPT18,
                                    .L.L.D. .CST_ADDR [.DISK, D_DISK_NUM].
.T_ADDR [T_DBN_RD], .T_ADDR [T_BLK_RD], .T_ADDR [T_DBN_WT], .T_ADDR [T_BLK_WT]);
           5503
           5504
           5505
                                    END:
           5506
                           END:
           5507
                  end:
           5508
:
           5509
                  PRINTS (CRLF):
           5510
:
           5511 ENDRPT:
```

.TITLE ZRQAM2 RD/RX EXERCISER .IDENT /V01.2/

VAX-11 Bliss-16 V3-555 Page 142 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (40)

ZRQAM2 VO1.2		RD/RX EX	ERCISER ODING SECTION				5-Dec-1983 10:27:14 5-Dec-1983 10:27:04
					.ENABL	AMA	
000000					.PSECT	\$CODE\$.	RO
000000	122	121	104	L\$DVTYP:	:		
000007			***		. ASCII	/RQD/	
000003	130	061	000		.ASCII	/X1/<00>	
000010	122	104	057	L\$DESC:	.BLKB	2 /RD/<57>	
000013	122	130	040	L+DESC:	ASCII	/RX /	
000016	105	130	105		ASCII	/EXE/	
000021	122	103	111		.ASCII	/RCI/	
000024	123	105	122		. ASCII	/SER/	
000027	000				. ASCII	<00>	
000030					.BLKB	5	
000032	0000000			L\$HRDLN:			
000034	000031			CD41	. WORD		RD-L\$HRDLN>/2>-1>
000036	00000G			GP\$1::	. WORD	31 HWQ1	
000040	160000				. WORD	-20000	
000042	177777				WORD	-1	
000044	001031			GP\$2::	. WORD	1031	
000046	000000G				. WORD	HWQ2	
000050	000004				. WORD	4	
000052	000774				. WORD	774	
000054 000056	002032			GP\$3::	. WORD	2032	
000060	000000G 000377				. WORD	HWQ3 377	
000062	000000				. WORD	0"	
000064	000007				WORD	7	
000066	003052			GP\$4::	. WORD	3052	
000070	000000G				. WORD	HWQ4	
000072	000003				. WORD	3	
000074	000000				. WORD	0	
000100	003130			CD4E	. WORD	3130	
000102	000000G			GP#5::	. WORD	HWQ10	
000104	000010				WORD	10	
000106	000000C			\$NODU:	. WORD		DU-\$NODU>\$400>+4>+40>
000110	003130			GP\$6::	. WORD	3130	
000112	00000G				. WORD	HWQ11	
000114	000020				. WORD	20	
000116	001004			\$LNODU:	. WORD	1004	
000122	000000G			GP\$7::	. WORD	4052 HWQ6	
000124	177777				. WORD	-1	
000126	000000				. WORD	0	
000130	177777				. WORD	-1	
000132	005452			GP\$8::	. WORD	5452	
000134	000000G				. WORD	HWQ7	
000136	177777				. WORD	-1	
000140	177777				. WORD	4.	
000142	Tilli				. WORD	-1	

Page 143

```
ZRQAM2
                RD/RX EXERCISER
                                                                     5-Dec-1983 10:27:14
                                                                                            VAX-11 Bliss-16 V3-555
V01.2
                REPORT CODING SECTION
                                                                     5-Dec-1983 10:27:04
                                                                                             DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (40)
                                                   . WORD
000144
        000001
000146
        003120
                                          GP$9::
                                                   . WORD
                                                           3120
000150
        00000G
                                                   . WORD
                                                           HWQ8
000152
        100000
                                                   . WORD
                                                           -100000
                                          $HWDONE: . WORD
000154
        0000000
                                                           <<<<$LHWDONE-$HWDONE>*400>+4>+40>
000156
        003120
                                          GP$10:: . WORD
                                                           3120
000160
        000000G
                                                   . WORD
                                                           HWQ9
000162
        100000
                                                   . WORD
                                                           -100000
000164
        001004
                                          $LHWDONE:
                                                   . WORD
                                                           1004
000166
                                          L$NDHRD::
                                                   .BLKW
000170 00000000
                                          L$SFTLN::
                                                    WORD
                                                           <<<L$NDSFT-L$SFTLN>/2>-1>
000172
        000052
                                          GP$11:: . WORD
                                                           52
000174
        000000G
                                                   . WORD
                                                           SWQ1
000176
        177777
                                                   . WORD
                                                           -1
000200
        000000
                                                   . WORD
                                                           0
       177777
000202
                                                   . WORD
000204
       001052
                                          GP$12:: .WORD
                                                           1052
000206
        000000G
                                                   . WORD
                                                           SWQ2
000210
        177777
                                                   . WORD
                                                           -1
000212
        000000
                                                   . WORD
                                                           0
000214
        000143
                                                   . WORD
                                                           143
000216
        005052
                                          GP$13:: . WORD
                                                           5052
000220
                                                   . WORD
        000000G
                                                           SWQ22
000222
        177777
                                                   . WORD
                                                           -1
000224
        000000
                                                   . WORD
                                                           0
000226
        000220
                                                           220
                                                   . WORD
000230
                                          GP$14:: . WORD
        002130
                                                           2130
000232
        00000G
                                                   . WORD
                                                           SWQ15
000234
        000200
                                                   . WORD
                                                           200
000236
                                          GP$15:: .WORD .WORD
        002130
                                                           2130
000240
        000000G
                                                           SWQ4
000242
        000002
                                                   . WORD
                                                           2
000244
        0000000
                                          $SW2:
                                                   . WORD
                                                           <<<<$LSW2-$SW2>#400>+4>+40>
000246
        004052
                                          GP#16:: . WORD
                                                           4052
000250
        000000G
                                                   . WORD
                                                           SWQ17
000252
        177777
                                                   . WORD
                                                           -1
        000000
000254
                                                   . WORD
                                                           0
000256
        000144
                                                   . WORD
                                                           144
000260
        001004
                                          $LSW2:
                                                   . WORD
                                                           1004
000262
       002130
                                          GP$17:: . WORD
                                                           2130
000264
        00000G
                                                   . WORD
                                                           SWQ19
000266
        001000
                                                   . WORD
                                                           1000
000270
        002130
                                          GP$18:: . WORD
                                                           2130
000272
        000000G
                                                   . WORD
                                                           SWQ7
000274
        000004
                                                    WORD
000276
        000003
                                          GP#DISP::
                                                   . WORD
                                                           3
000300
        000000G
                                                   . WORD
                                                           SWM1
000302
                                          GP$19:: . WORD
        002130
                                                           2130
000304
        000000G
                                                    WORD
                                                           SWQ9
```

Page 144

```
ZRQAM2
                  RD/RX EXERCISER
                                                                         5-Dec-1983 10:27:14
                                                                                                    VAX-11 Bliss-16 V3-555
V01.2
                  REPORT CODING SECTION
                                                                         5-Dec-1983 10:27:04
                                                                                                    DISK SUSER2: [DIETZ.RDRX]ZRQACO.BL1:82 (40)
                                                      . WORD
000306 000020
                                                               50
000310 000000C
                                             $SW3:
                                                      . WORD
                                                               <<<<$LSW3-$SW3>+400>+4>+40>
000312 000000C
                                             $ SW4 :
                                                       . WORD
                                                               <<<$LSW4-$SW4>#400>+4>
000314 001004
                                             $LSW3: . WORD
                                                                1004
000316 002130
                                             GP$20:: . WORD
                                                                2130
000320 000000G
                                                       . WORD
                                                               SWQ10
000322 000040
000324 001004
                                                       . WORD
                                                               40
                                             $LSW4: . WORD
                                                               1004
000326 002130
000330 000000G
                                             GP$21:: . WORD
                                                                2130
                                                       . WORD
                                                                SWQ11
000332 000100
000334 000000C
                                                       . WORD
                                                                100
                                             $SW5:
                                                       . WORD
                                                                <<<<$LSW5-$SW5>+400>+4>+40>
000336 000000C
000340 001004
                                             $ SW6:
                                                       . WORD
                                                                <<<$LSW6-$SW6>+400>+4>
                                             $LSW5: . WORD
                                                               1004
000342 003052
000344 000000G
                                             GP$22:: . WORD
                                                                3052
                                                       . WORD
                                                                SWQ12
000346 177777
000350 000000
                                                       . WORD
                                                                -1
                                                       . WORD
000352 000025
                                                       . WORD
000354 000000C
                                                       . WORD
                                             $SW7:
                                                               <<<$LSW7-$SW7>4400>+4>
000356 001004
000360 006052
                                             $LSW6: . WORD
                                                               1004
                                             GP$23:: . WORD
                                                               6052
000362 000000G
000364 177777
000366 000001
                                                       . WORD
                                                               SWQ13
                                                       . WORD
                                                                -1
                                                       . WORD
000370 000020
                                                       . WORD
                                                               20
000372 007222
                                             GP$24:: . WORD
                                                               7222
000374 000000G
                                                       . WORD
                                                                SWQ14
000376 177777
                                                       . WORD
                                                                -1
000400 000000
                                                       . WORD
                                                               0
000402 177777
                                                       . WORD
                                                                -1
000404
        000006
                                                       . WORD
000406
        001004
                                             $LSW7:
                                                     . WORD
                                                                1004
000410
                                             L#NDSFT::
                                                      .BLKW
000000
                                                       .PSECT #OWN#, D
000000 000000G
                                             TBL . SUC : . WORD
                                                               NULL
                                                       . WORD
                                                               SC.SDI
SC.CON
000004 000000G
                                                       . WORD
000006 000000G
                                                       . WORD
                                                               NULL.
000010 000000G
                                                       . WORD
                                                               SC. DUP
000012 000000G
                                                       . WORD
                                                               NULL
000014 000000G
                                                       . WORD
                                                               NULL
000016 000000G
                                                       . WORD
                                                               NULL
000020 000000G
                                                       . WORD
                                                               SC. ONL
000022 000000G
                                                       . WORD
                                                               NULL
000024
         000000G
                                                       . WORD
                                                               NULL
000026
         000000G
                                                       . WORD
                                                               NULL
000030
        000000G
                                                       WORD
                                                                NULL
000032 000000G
                                                       . WORD
                                                                NULL
```

ZRQAM2 VO1.2	RD/RX EXERCISER REPORT CODING SECTION			5-Dec-1983 5-Dec-1983	10:27:14 10:27:04	VAX-11 Bliss-16 V3-555
000034 000036 000040 000042 000044 000046 000050 000052	00000G 00000G 00000G 00000G	. WORD . WORD . WORD . WORD . WORD . WORD . WORD	NULL SC.SON SC.UNK SC.VOL SC.IOP NULL SC.DUP			
000054 000056 000060 000062 000064 000066 000070 000072	000000G 000000G 000000G 000000G 000000G 000000	. WORD . WORD . WORD	NULL NULL SC.DIS SC.FER NULL SC.ISH SC.DST			
000076 000100 000102 000104 000106 000110 000112	000000G 000000G 000000G 000000G 000000G 000000	. WORD . WORD TBL . WPT: . WORD	SC.ISH SC.DST SC.EC9 SC.576 SC.FCT SC.ECC SC.RCT SC.FUL SC.EC1 NULL SC.SMP			
000116 000120 000122 000124 000126 000130 000132	000000G 000000G 000000G 000000G 000000G	BL.DAT: .WORD .WORD .WORD .WORD .WORD .WORD .WORD	SC.FE2 NULL SC.IS2 SC.DS2 SC.EC9 NULL NULL			
000136 000140 000142 000144 000150 000152 000154	000000G 000000G 000000G 000000G 000000G 000000	. WORD . WORD . WORD . WORD	SC.ECD SC.EC1 SC.EC2 SC.EC3 SC.EC4 SC.EC5 SC.EC6 SC.EC6 SC.EC7 SC.EC6			
000156 000160 000162 000164 000166 000170 000172 000174	000000G 000000G 000000G 000000G 000000G 000000	. WORD . WORD	SC.EC8 NULL SC.ODA SC.ODB SC.NXM SC.PAR SC.CTO SC.SDS SC.EDC			
000176 000200 000202 000204	000000G 000000G	TBL.DRV:.WORD	SC.EDC SC.IDS NULL SC.SRT			

			DIE
ZRQAM2 VO1.2	RD/RX EXERCISER REPORT CODING SECTION		5-Dec-1983 10:27:14 VAX-11 Bliss-16 V3-555 SEQ 0146 5-Dec-1983 10:27:04 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (40)
000550	000000G 000000G 000000G 000000G 000000G	. WORD . WORD . WORD . WORD . WORD . WORD	SC.SRI SC.POE SC.RDY SC.CLK SC.RSP SC.SUR SC.PSP
		.GLOBL .GLOBL .GLOBL .GLOBL .GLOBL .GLOBL .GLOBL .GLOBL .GLOBL	MSCP.PKT, IPKT.ADDR, PKT.USE, RETPKT RP.USE, RP.INDX, RP.ADDR, ELOG.PKT BUFF.ADDR, BUFF.OMN, IODG, IODG.IN IODG.OUT, ENTRY.REASON, EOP.FLAG DUP.FLAGS, CCTLR, CDISK, CUOFF CTLR.CNT, DUR, QIO, FREE.MEM.ADDR BYTS.PER.QIO, ST.CODE, SB.CODE STEP, OF.RC, SA.REG, CMD.TIME NEX, CRN.LOW, CRN.HIGM, P.INDEX S.DUPPKT, S.PATTERN, CREDIT.BAL INIT.OCCURED, NXT.PKT.2USE, DBMS DBM107, DU.MSG, DU.RSN, ERR.COD ELG.FMT, HWQ1, HWQ2, HWQ3, HWQ4 HWQ6, HWQ7, HWQ8, HWQ9, HWQ10 HWQ11, SWQ1, SWQ2, SWQ4, SWQ7 SWQ9, SWQ10, SWQ11, SWQ12, SWQ13 SWQ14, SWQ15, SWQ17, SWQ19, SWQ22 SWM1, NULL, MSG.O1, MSG.O2, MSG.O3 RPT1, RPT2, RPT3, RPT4, RPT5, RPT6 RPT7, RPT8, RPT9, RPT10, RPT11 RPT12, RPT13, RPT14, RPT15, RPT16

```
RD/RX EXERCISER
REPORT CODING SECTION
```

```
5-Dec-1983 10:27:14 VAX-11 Bliss-16 V3-555 Page 147 
5-Dec-1983 10:27:04 DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (40)
```

```
GLOBL EX.MTN, EX.DGM, EX.RD, EX.WRT
GLOBL EX.ACC, EX.ONL, EX.SCC, EX.GDS
GLOBL EX.ESP, EX.ELP, EX.SDD, EX.RCD
GLOBL EX.ABP, SC.SDI, SC.CON, SC.DUP
GLOBL SC.ONL, SC.SON, SC.UNK, SC.VOL
GLOBL SC.IOP, SC.DIS, SC.FER, SC.FE2
GLOBL SC.ISH, SC.IS2, SC.DST, SC.DS2
GLOBL SC.ECC, SC.ECD, SC.RCT, SC.FUL
GLOBL SC.576, SC.FCT, SC.EC1, SC.EC2
GLOBL SC.EC3, SC.EC4, SC.EC5, SC.EC6
GLOBL SC.EC7, SC.EC8, SC.EC9, SC.SMP
GLOBL SC.HMP, SC.ODA, SC.ODB, SC.NXM
GLOBL SC.PAR, SC.CTO, SC.SDS, SC.EDC
GLOBL SC.PAR, SC.CTO, SC.SDS, SC.EDC
GLOBL SC.RDY, SC.CLK, SC.RSP, SC.SUR
GLOBL SC.RDY, SC.CLK, SC.RSP, SC.SUR
GLOBL SC.PSP, F.1, F.2, F.3, F.4, F.5
GLOBL F.6, F.7, F.8, F.9, F.10, F.11
GLOBL F.12, F.13, F.14, F.15, F.16, F.17
GLOBL F.18, F.19, F.20, F.21, EBH.30
GLOBL EBH.44, EBH.45, EBH.46, EBH.47
GLOBL EBH.48, EBH.49, DF.0, DF.1, DF.2
GLOBL T.DEF, T.INF, T.TER, T.FAT, T.SPL
GLOBL T.DEF, T.INF, T.TER, T.FAT, T.SPL
GLOBL E.UNT, E.BLK, E.DEV, E.ZER, M.ASC
GLOBL M.BIN, M.TER, M.COD, M.DAT, M.UR
GLOBL M.URP, M.UP, M.UL, CNTR.ERR, RDRX.ERR
GLOBL EX.WRD, EX.OP, SPACE4, CRLF, DASH
GLOBL ASTERISK, SWP.FLAGS, L$HIMEM, L$LUN
GLOBL L$UNIT
```

040000       BIT14==       40000         020000       BIT13==       20000         010000       BIT12==       10000         002000       BIT10==       2000         001000       BIT09==       1000         000400       BIT08==       400         000200       BIT06==       100         000100       BIT06==       40         000020       BIT05==       40         000020       BIT04==       20         000010       BIT03==       10	00000	BIT15	-100000
020000       BIT13==       20000         010000       BIT12==       10000         004000       BIT11==       4000         001000       BIT09==       1000         000400       BIT08==       400         000200       BIT06==       100         000100       BIT06==       40         000040       BIT05==       40         000020       BIT04==       20         000010       BIT03==       10	40000		
010000       BIT12=-       10000         004000       BIT11=-       4000         002000       BIT10=-       2000         001000       BIT09=-       1000         000400       BIT08=-       400         000100       BIT06=-       100         000040       BIT05=-       40         000020       BIT04=-       20         000010       BIT03=-       10	20000		
004000       BIT11==       4000         002000       BIT10==       2000         001000       BIT09==       1000         000400       BIT08==       400         000200       BIT06==       100         000100       BIT05==       40         000020       BIT04==       20         000010       BIT03==       10	10000		
002000       BIT10==       2000         001000       BIT09==       1000         000400       BIT08==       400         000200       BIT06==       100         000100       BIT05==       40         000020       BIT04==       20         000010       BIT03==       10			
001000     BIT09==     1000       000400     BIT08==     400       000200     BIT07==     200       000100     BIT06==     100       000040     BIT05==     40       000020     BIT04==     20       000010     BIT03==     10			
000400     BIT08=-     400       000200     BIT07=-     200       000100     BIT06=-     100       000040     BIT05=-     40       000020     BIT04=-     20       000010     BIT03=-     10			
000200 BIT07== 200 000100 BIT06== 100 000040 BIT05== 40 000020 BIT04== 20 000010 BIT03== 10			
000100 BIT06=- 100 000040 BIT05=- 40 000020 BIT04=- 20 000010 BIT03=- 10			
000040 BIT05== 40 000020 BIT04== 20 000010 BIT03== 10			
000020 BIT04== 20 000010 BIT03== 10			
000010 BIT03 10			
000010 BIT03 10		BIT04==	20
	00010	BIT03	
000004 BIT02 4	00004		
000002 BIT01 2	00002		2
000001 BIT00 1	00001		ī
001000 BIT9 1000			1000
000400 BIT8 400			
000040 BIT5 40			
000020 BIT4 20	00020	BIT4	20

				112		
ZRQAM2 V01.2	RD/RX EXERCISER REPORT CODING SECTION			5-Dec-1983 10:27:16 5-Dec-1983 10:27:06		oe 148
000010 000004 000001 000037 000035 000034 000340 000200 000240 000100 000004 000010 000000 000000 000000 000000 000000		BIT3== BIT2== BIT1== BIT0== EF.STAR EF.STAR EF.CONT EF.NEW= EF.PWR= PRIO7== PRIO6== PRIO6== PRIO2== PRIO2== PRIO1== PRIO1== LOT== LOT== LOT== LOT== LOE== LSR== LOE== L\$HARD= L\$SOFT==	ART = INUE = =	10 4 2 1 40 37 36 35 34 340 300 240 200 140 100 40 0 4 10 20 40 100 200 400 1000 2000 400 1000 2000 4000 1000 1000 2000 4000 100		
000412			.SBTTL .PSECT	LRPT REPORT CODING SECTION #CODE#, RO		
000000 004137 000004 012746 000010 012746 000014 010600 000016 104416	000000G 000001	LRPT:	JSR MOV MOV	R1.#SAVE4 #RPT1,-(SP) #1(SP) SP.RO	: : SP.*	5409 5419
000016 104416 000020 012716 000024 012746 000030 010600	000000G 000001		TRAP MOV MOV	16 #RPT2,(SP) #1(SP) SP,R0	: SP.*	5420
000032 104416 000034 012716 000040 012746 000044 010600	000000G 000001		TRAP MOV MOV	16 #RPT3.(SP) #1(SP) SP.RO	: SP.*	5421
000046 104416 000050 012716 000054 012746	000000G		TRAP MOV MOV	16 #RPT4,(SP) #1,-(SP)		5422

	ZRQAM2 VO1.2		RD/RX EXERCISER REPORT CODING SECTION			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL	SEQ 0149 Page 149 1;82 (40)
1	000060	010600			MOV	SP.RO	; SP. *	
	000062	104416			TRAP	16	1 3 1	
1	000064	012716	000000G		MOV	#RPT5,(SP)		5423
	000070	012746	000001		MOV	#1,-(SP)		3423
1	000074	010600			MOV	SP.RO	; SP,4	
	000076	104416			TRAP	16		
1	000100 000104	012716	000000G		MOV	#RPT6,(SP)		5424
1	000104	012746	000001		MOV	#1,-(SP)		
1	000110	010600			MOV	SP.RO	; SP.*	
	000112	104416			TRAP	16		
	000114	005002			CLR	R2	; CTLR	5426
1	000116	010216		1:	MOV	R2.(SP) PC.SET.CPAR	; CTLR,*	5428
	000120	004737	000000V		JSR	PC.SET.CPAR		
1	000124	012703	000003		MOV	#3,R3 R3.(SP) PC.SET.UPAR	; *,DISK	5430
1	000130	010316	0000001	2\$:	MOV	R3,(SP)	; DISK,*	5432
	000132	004737	000000V		JSR	PC.SET.UPAR		
	000136	010301			MOV	R3,R1	; DISK,*	5434
1	000140	006301			ASL	R1		
	000142	010100	0000000		MOV	R1,R0		
1	000144	063700	000000G		ADD	CST.ADDR,RO		
1	000154	132710 001020	000034		BITB	#34,(RO)		
1	000150 000154 000156	032710	040000		BNE	3#		
	000158	001415	040000		BIT	#40000,(RO)	1	5435
	000164	111016			BEQ	34		
1	000166	042716	177774		MOVB	(RO),(SP)		5437
1	000172	013746	000000G		BIC	#177774,(SP)		
	000176	012746	000000G		MOV	L\$LUN, -(SP)		
	000202	012746	000003		MOV	#RPT7,-(SP)		
1	000206	010600	000003		MOV	SP.RO	. CD 4	
	000210	104416			TRAP	16	; SP.4	
1	000210 000212	062706	000006		ADD	46.SP		
	000216 000220 000224	010100	***************************************	34:	MOV	81.80		5439
1	000220	063700	000000G	٠٠.	ADD	R1,R0 CST.ADDR.RO (RO),R4		3437
	000224	111004			MOVB	(RO).R4		
1	000226	042704	177743		BIC	#177743,R4		
1	000232	020427	000004		CMP	R4,04		
1	000236	001020			BNE	41		
1	000240	032710	040000		BIT	#40000,(RO)		5440
	000244	001415			BEQ	41		
	000246	111016			MOVB	(RO),(SP)		5442
1	000250 000254	111016 042716	177774		BIC	#177774,(SP)		
	000254	013746	000000G		MOV	HRUN, -(SP)		
	000260 000264 000270 000272	012746	00000G		MOV	#RPT8,-(SP)		
1	000264	012746	000003		MOV	#3,-(SP)		
	000270	010600			MOV	SP,RO	; SP.*	
1	000272	104416	*******		TRAP	16		
1	000274	062706	000006		ADD	46.SP		
1	000300	010100		48:	MOV	R1.R0	1	5444
	000302	063700	00000G		ADD	CST. ADDR, RO		
	000306	111004			MOVB	(RO),R4		
1	000310	042704	177743		BIC	#177743,R4		
	000314	020427	000010		CMP	R4,010		

ZRQAM2 V01.2		RD/RX EXERCISER REPORT CODING SECTION			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.B	SEQ 0150 Page 150 L1;82 (40)
000320	001020			BNE	5#		
000322	032710	040000		BIT	#40000,(RO)		5445
000326	001415			BEQ	54		
000330	111016 042716	177774		MOVB	(RO),(SP)		5447
000336	013746	00000G		BIC	#177774.(SP)		
000336 000342 000346 000352	012746	000000G		MOV	L\$LUN,-(SP) #RPT17,-(SP)		
000346	012746	000003		MOV	43(SP)		
000352	010600			MOV	#3,-(SP) SP.RO	; SP.*	
000354	104416			TRAP	16		
000356	062706	000006		ADD	46.SP		
000362	010100		5\$:	MOV	R1.R0		5449
000364	063700	00000G		ADD	CST.ADDR.RO (RO),R4		
000364 000370 000372	111004			MOVB	(RO),R4		
000372	042704	177743		BIC	#177743,R4		
000376	020427 001431	000010		CMP	R4.#10		
000404	111004			BEQ MOVB	6\$		
000406	042704	177743		BIC	(RO),R4 #177743.R4		5450
000412	020427	000004		CMP	R4.04		
000416	001423			BEQ	6#		
000420	132710	000034		BITB	#34,(RO)		5451
000420 000424	132710 001420			BEQ	61		3432
000426	032710	040000		BIT	#40000,(RO)		5452
000432	001415			MOVB	6\$		
000434	111016			MOVB	(RO),(SP)		5454
000436 000442	042716	177774		BIC	#177774,(SP)		
000446	013746	000000G		MOV	L\$LUN, -(SP)		
000452	012746	000000G 000003		MOV	AZ (CD)		
000456	010600	000003		MOV	#RPT19,-(SP) #3,-(SP) SP,R0	. CD .	
000460	104416			TRAP	16	; SP.4	
000462 000466	062706	000006		ADD	●6,SP		
000466	010100		6\$:	MOV	R1.R0		5457
000470	063700	000000G		ADD	CST.ADDR.RO		3431
000474	032710	040000		BIT	#40000,(RO)		
000500	001506			BEQ	7\$		
000502	013700	000000G		MOV	T.ADDR.RO		5462
000502 000506 000512	016016	000032 000034		MOV	32(RO),(SP) 34(RO),-(SP)		
000512	016046 016046	000034		MOV	34(RO),-(SP)		
000522	016046	000016		MOV	36(RO),-(SP)		
000526	016046	000020		MOV	16(RO),-(SP) 20(RO),-(SP) #RPT9,-(SP)		
000532	012746	000000G		MOV	ARPT9 - (SP)		
000536	012746	000006		MOV	46(SP)		
000542	010600			MOV	SP.RO	; SP.4	
000544	104416			TRAP	16		
000512 000516 000522 000526 000532 000536 000542 000544 000546 000552	013700	00000G		MOV	16 T.ADDR.RO		5465
000552	016016	000040		MOV	40(R0),(SP) 42(R0),-(SP)		
000556	016046	000042		MOV	42(RO),-(SP)		
205	016046	000044		MOV	44(RO),-(SP)		
000566 000572	016046 016046	000024 000026		MOV	24(RO),-(SP)		
000312	010040	000020		MOV	26(RO),-(SP)		

	ZRQAM2		RD/RX EXERCISER			5-Dec-1983 10:27:14	V6.4-11 R1:ee-16 V3-555	0 0151
	V01.2		REPORT CODING SECTION			5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;8	2 (40)
	000576	012746	00000G		MOV	#RPT9,-(SP)		
	000602	012746	000006		MOV	46,-(SP)		
	000606	010600			MOV	SP.RO	; SP.*	
	000610	104416	******		TRAP	16		
	000612	013700	00000G		MOV	T.ADDR,RO		5468
	000616 000620	005016 116016	000067		CLR	(SP)		
1	000624	005046	000067		MOVB	67(RO),(SP) -(SP)		
	000626	116016	000066		MOVB	66(RO),(SP)		
1	000632	005046	***************************************		CLR	-(SP)		The second second
1	000634	116016	000065		MOVB	65(RÓ),(SP)		
1	000640	005046			CLR	-(SP)		
	000642	116016	000064		MOVB	64(RO).(SP)		
	000646	005046			CLR	-(SP)		
!	000650	116016	000063		MOVB	63(RO),(SP)		
1	000654	005046	000060		CLR	-(SP)		
1	000656	116016 005046	000062		MOVB	62(RO),(SP)		
	000664	116016	000061		CLR MOVB	-(SP) 61(RO),(SP)		
1	000670	005046	000001		CLR	-(SP)		
	000672	116016	000060		MOVB	60(RO),(SP)		
	000670 000672 000676	116016 012746	000000G		MOV	#RPT10,-(SP)		
1	000702	012746	000011		MOV	#11,-(SP)		
	000706	010600			MOV	SP,RO	; SP.4	
i	000710	104416	*****		TRAP	16		
	000712 000716	062706	000052	7.	ADD	452,SP	The same of the sa	5459
	000722	062703 020327	000007 000030	7\$:	ADD	\$7.R3	: *.DISK	5430
	000726	003002	000030		CMP BGT	R3,#30 8#	; DISK, *	
1	000730	000137	0005421		JMP	21		
	000734	010216		8\$:	MOV	R2,(SP)	; CTLR.*	5473
1	000736	012746	000076		MOV	476,-(SP)	1 0.5.11-	34.3
1	000742	004737	00000G		JSR	PC,BL\$MUL		
	000746	005726			TST	(SP)+		
-	000750 000754	005760	000002G		TST	CST+2(RO)		
1	000756	100026 012716	0000000		BPL	96		
	000762	012746	000000G 000001		MOV	#RPT11,(SP) #1,-(SP)		5476
	000766	010600	000001		MOV	SP.RO	. CD .	i
1	000770	104416			TRAP	16	; SP.4	
1	000772	010200 006300			MOV	R2,R0	; CTLR.+	5477
1	000774	006300			ASL	RO	1 0.0.1	34
1	000776	005016			CLR	(SP)		
	001000	116016	000001G		MOVB	C.ERR.TBL+1(RO),(SP)		
1	001000 001004 001006	005046	0000000		CLR	-(SP) C.ERR.TBL(RO),(SP)		
1	001012	116016 012746	000000G 000000G		MOVB	C.ERR.TBL(RO),(SP)		
	001016	012746	000003		MOV	#RPT12,-(SP)		
	001016 001022	010600	***************************************		MOV	#3,-(SP) SP,RO	: SP.*	
	001024	104416			TRAP	16		
-	001026 001032	062706	000010		ADD	#10.SP		5475
-	001032	012716	00000G	94:	MOV	#CRLF,(SP)		5480
	001036	012746	000001		MOV	#1,-(SP)	경영하다 그렇게 맞아서 말하다면 해 된 아니라니다 경영 하고?	

	ZRQAM2 V01.2		RD/RX EXERCISER REPORT CODING SECTION			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.B	SEQ 0152 Page 152 1;82 (40)
	001042 001044	010600 104416			MOV TRAP	SP.RO	; SP,*	
1	001046 001050 001052	005726 005202 000243			INC	(SP)+ R2 CLV!CLC	CTLR	5427 5426
1								
	001054 001056	003002	0005301		BGT JMP	10\$		
1	001062	012716	00000G	10\$:	MOV	#CRLF,(SP)		5484
1	001066	012746	000001		MOV	#1,-(SP)		
	001072	010600 104416			MOV TRAP	SP,RO	: SP.*	
1	001066 001072 001074 001076	012716	00000G		MOV	#RPT13,(SP)		5485
1	001102	012746	000001		MOV	#1,-(SP)		3.03
1	001106	010600 104416			MOV TRAP	SP.RO	; SP,*	
1	001112	012716	00000G		MOV	#RPT14.(SP)		5486
1	001116	012746	000001		MOV	#1,-(SP) SP,RO		3.00
	001122	010600 104416			MOV TRAP	SP.RO 16	; SP.*	
1	001126	012716	00000G		MOV	#RPT15,(SP)		5487
-	001132	012746	000001		MOV	#1,-(SP)		3401
	001136	104416			MOV TRAP	SP.RO	; SP.*	
	001142	005003			CLR	R3	; CTLR	5488
	001110 001112 001116 001124 001126 001136 001136 001140 001144 001146 001152 001156 001160 001164	010600 104416 005003 010316 004737		11:	MOV	R3.(SP) PC.SET.CPAR	; CTLR.*	5490
1	001146	012702	000000V 000003		JSR MOV	PC.SET.CPAR	- DTCV	
1	001156	010216	000003	124:	MOV	#3,R2 R2.(SP)	: *.DISK : DISK,*	5491 5493
1	001160	004737	000000V		JSR	R2.(SP) PC.SET.UPAR		3473
	001166	010201 006301			MOV	R2.R1	; DISK.*	5494
1	001170	010100			MOV	R1.R0		
	001172	063700	00000G		ADD	CST.ADDR.RO (RO).R4		
	001176 001200	111004	177743		MOVB	(RO),R4 #177743,R4		
1	001204	020427	000004		CMP	R4.04		
1	001210	001032			BNE	13#		
1	001212 001216	032710 001427	040000		BEQ	#40000,(RO) 13#		
	001220	013704	000000G		MOV	T.ADDR.R4		5498
1	001220 001224 001230	016416	000050 000052		MOV	50(R4),(SP)		3470
	001230	016446 016446	000052 000054		MOV	52(R4),-(SP)		
1	001240	016446	000056		MOV	54(R4),-(SP) 56(R4),-(SP)		
	001244	111046 042716			MOVB	56(R4),-(SP) (R0),-(SP) #17774,(SP) L#LUN,-(SP)		
	001246	013746	177774 000000G		BIC	#177774,(SP)		
	001256	012746	000000G		MOV	#RPT16,-(SP)		
	001234 001240 001244 001246 001252 001256 001266	012746	000007		MOV	07,-(SP)		
1	M1500	010600			MOV	SP,RO	; SP.4	
	001270 001272	104416 062706	000016		TRAP	16 416 SP		
		002100	000010		AUU	#16.SP		

ZRQAM2 VO1.2		RD/RX EXERCISER REPORT CODING SECTION			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:	EQ 0153 Page 153 B2 (40)
001276 001300	010100	0000000	13\$:	MOV	R1.R0		5500
001304	063700 111001	00000G		ADD	CST.ADDR,RO		
001306	042701	177743		MOVB	(RO),R1 #177743,R1		
001312	020127	000010		CMP	R1,#10		
001316	001032	000010		BNE	145		
001320	032710	040000		BIT	#40000,(RO)		
001324	001427			BEQ	144		
001326	013701	00000G		MOV	T ADDR R1		5504
001332	016116	000050		MOV	50(R1),(SP) 52(R1),-(SP) 54(R1),-(SP) 56(R1),-(SP) (R0),-(SP)		3304
001336	016146	000052		MOV	52(R1),-(SP)		
001342	016146	000054		MOV	54(R1),-(SP)		
001346	016146	000056		MOV	56(R1),-(SP)		
001352	111046			MOVB	(RO),-(SP)		
001354	042716	177774		BIC	91////4,(SP)		
001360	013746	000000G		MOV	L\$LUN, -(SP) #RPT18, -(SP)		
001364	012746	00000G		MOV	#RPT18,-(SP)		
001370	012746	000007		MOV	#7,-(SP)		
001374 001376	010600			MOV	SP.RO	; SP.*	
001400	104416	000016		TRAP	16		
001404	062706 062702	000016 000007	144.	ADD	<b>♦16.SP</b>	. 0704	
001410	020227	000030	144:	ADD	\$7,R2	, A.DISK	5491
001414	003660	000030		BLE	R2,430 12\$	; DISK,*	
001416	005203			INC	R3	; CTLR	EAGO
001420	000243			. WORD C	LVICLC	1 CILK	5488
001422	003650			BLE	11#		
001424	012716	00000G		MOV	#CRLF.(SP)		5509
001430	012746	000001		MOV	#1,-(SP)		-
001434	010600			MOV	SP.RO	; SP.*	
001436	104416			TRAP	16		
001440	062706	000030		ADD	#30.SP		5409
001444	000207			RTS	PC		
; Routing	ne Size: um stack	403 words, Routine depth per invocation:	Base: 35 words	*CODE* •	0412		
					LARRY DEPOST CONTING CONTING		
000000	004737	0004121	L#RPT::	.SBTTL	L\$RPT REPORT CODING SECTION PC,LRPT		5500
000004	104425	***************************************	LAMP !!!	TRAP	25		5509
000006	000207			RTS	25 PC		
				A13			
: Routin	ne Size:	4 words, Routing	Base:	*CODE* +	2060		
		depth per invocation:					

```
ZRQAM2
                  RD/RX EXERCISER
                                                                         5-Dec-1983 10:27:14
                                                                                                   DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (41)
                                                                                                   VAX-11 Bliss-16 V3-555
V01.2
                  INITIALIZE SECTION
                                                                         5-Dec-1983 10:27:04
           5512 #sbttl 'INITIALIZE SECTION'
           5513
           5514 BGNINIT:
:
           5515
.
           5516 local
           5517
                      DELAY_MULT : word,
           5518
                      FLAG : byte.
           5519
                      TEMP : word,
           5520
                      HMPT_REF : ref block [HMPT_LEN, word] field (HMP_FIELDS),
:
           5521
5522
5523
                      CLEAR_TABLES : byte;
:
:
                 SETPRI (PRIO7);
                                                                     ! PRIORITY 7 - NO INTERRUPTS ALLOWED DURING INIT
:
           5524
           5525
                 if READEF (EF_NEW)
                                                                       ! IS THIS A NEW PASS?
           5526
5527
5528
5529
5530
                 then
                      begin
ENTRY_REASON = NEW_PASS;
                      if (.SWP_FLAGS and SWF_CST) neg SWF_CST
           5531
           5532
                          CLEAR_TABLES = FALSE
           5533
                      else
           5534
                          CLEAR_TABLES = TRUE:
.
           5535
5536
5537
.
.
                      end:
           5538 IF READEF (EF_START)
                                                                       ! IS THIS A START?
           5539 then
5540 then
5541 E
.
                      begin
BRESET:
.
                      ENTRY_REASON = START;
           5543
5544
5545
                      CLEAR_TABLES = TRUE:
                      INIT_OCCURED . FALSE:
:
                      end:
           5546
5547
5548
5549
5550
:
                  if READEF (EF_RESTART)
                                                                       ! IS THIS A RESTART?
                 then
                      begin
ENTRY_REASON = RESTART;
.
           5551
5552
5553
                      CLEAR_TABLES = TRUE;
.
                      end;
           5554
                 if READEF (EF_CONTINUE)
                                                                    ! IS THIS A CONTINUE?
           5555 then
           5556
                      begin
ENTRY_REASON = CONT;
.
           5557
.
           5558
.
           5559
5560
                      if (.SMP_FLAGS and SWF_CST) neg SWF_CST
:
           5561
                          CLEAR_TABLES - FALSE
           5562
.
                      else
           5563
                          CLEAR_TABLES = TRUE:
.
           5564
:
```

```
ZRQAM2
                 RD/RX EXERCISER
                                                                      5-Dec-1983 10:27:14
                                                                                               DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (41)
V01.2
                 INITIALIZE SECTION
                                                                      5-Dec-1983 10:27:04
          5565
                     end:
          5566
.
                 if READEF (EF_PWR)
           5567
                                                                     ! ARE WE HERE BECAUSE OF POWER FAIL?
.
           5568
                 then
          5569
                     begin
ENTRY_REASON = PWR_FAIL:
          5570
                     CLEAR_TABLES = TRUE;
INIT_OCCURED = FALSE;
          5571
          5572
          5573
                     PRINTF (MSG_01);
                                                                     ! "POWER DELAY - WAITING"
          5574
          5575
                     incr COUNT from 0 to 60 do
                                                                     ! WAIT APPROX. 60 SECONDS
          5576
                         begin
DELAY_MULT = 333;
          5577
          5578
                         DELAY (.DELAY_MULT):
           5579
                         BREAK:
                                                                     ! BREAK FOR ACT
          5580
                          end:
.
          5581
5582
:
                     end:
:
           5583
.
           5584
                 !SETVEC (O_TVEC, O_BRK, PRIO7);
                                                                     ! SET ODT TRAP VECTOR
:
           5585
           5586
                 ! *
:
          5587
                         MAKE SURE THAT NOT MORE THAN MAX_UNITS HAVE BEEN SPECIFIED.
.
          5588
                 .
                          IF THERE ARE TOO MANY, NOTIFY USER AND RETURN TO SUPERVISOR.
          5589
                 .
                         (DIAGNOSTIC IS ABORTED).
          5590
          5591
          5592
                 if .L$UNIT gtru MAX_UNITS
:
          5593
                 then
          5594
5595
                     begin
ERRSF (1, EGS_01, EMS_01);
           5596
                     DOCLN:
           5597
                     end:
           5598
          5599
                 ! .
           5600
                 .
                          THE FOLLOWING CODE IS EXECUTED FOR ALL ENTRY REASONS EXCEPT NEW_PASS.
           5601
                          ALL RUN-TIME CONTROLLER STATUS TABLES (CSTs) ARE CLEARED TO O. THEN
           5602
                         LOADED WITH CONFIGURATION DATA FROM THE HARDWARE P-TABLES.
           5603
                 ! -
.
           5604
:
           5605
                 if (.ENTRY_REASON neg NEW_PASS)
:
           5606
                 then
           5607
                     begin
           5608
           5609
                     incr COUNT from 0 to ((MAX_CTLR * CST_LEN * 2) - 2) by 2 do (CST + .COUNT) = 0;
           5610
          5611
           5612
                     incr UNIT from 0 to (.L$UNIT - 1) do
                                                                     ! LOOP THROUGH ALL UNITS
           5613
           5614
                          if GPHARD (.UNIT, HMPT_REF) nega 0
                                                                     ! IF HWP TABLE FOUND
           5615
                          then
           5616
           5617
                              FLAG = NOT_FOUND:
```

```
ZRQAM2
                          RD/RX EXERCISER
                                                                                                          5-Dec-1983 10:27:14
                                                                                                                                                VAX-11 Bliss-16 V3-555
                                                                                                                                                                                                          Page 156
V01.2
                          INITIALIZE SECTION
                                                                                                                                               DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (41)
                                                                                                          5-Dec-1983 10:27:04
                5618
                5619
                                             incr CTLR from 0 to (MAX_CTLR - 1) do ! LOOP THROUGH ALL CSTs
:
                5620
                5621
                                                    if .CST [.CTLR, IP_ADDR] eala .HWPT_REF [HWP_IP_ADDR]
                5622
                5623
                5624
                                                           if .CST [.CTLR, .HWPT_REF [HWP_NUM] * UNIT_SIZE + OF_UN, D_PRES] eq1 NOT_PRESENT
                 5625
                                                           then
                 5626
                                                                                                                                                            ! IF EMPTY SLOT FOUND
                                                                 TEMP = .HWPT_REF (HWP_NUM) * UNIT_SIZE + OF_UN;
CST (.CTLR, .TEMP, D_ALL) = .HWPT_REF (HWP_DISK);
CST (.CTLR, .TEMP, D_UNIT) = .UNIT;
CST (.CTLR, .TEMP, D_FATAL) = FALSE;
CST (.CTLR, .TEMP, D_FATAL) = PALSE;
                 5627
                 5628
                                                                                                                                                         ! COPY DISK ADDR AND PROT BIT
                5629
                5630
:
                 5631
                                                                 CST [.CTLR, .TEMP, D_PRES] = PRESENT;
                                                                CST [.CTLR, .TEMP + 1, D_BEGO] = .HWPT_REF [HWP_BEG_TRK];
CST [.CTLR, .TEMP + 2, D_BEGO] = .HWPT_REF [HWP_BEG_TRK];
CST [.CTLR, .TEMP + 3, D_ENDO] = .HWPT_REF [HWP_END_TRK];
CST [.CTLR, .TEMP + 4, D_ENDO] = .HWPT_REF [HWP_END_TRK];
CST [.CTLR, .TEMP + 5, D_DBN] = 0;
CST [.CTLR, .TEMP + 5, NODUPMEDIA] = NOT(.HWPT_REF [HWP_DUPEX]);
CST [.CTLR, .TEMP + 5, DUPWRITE] = (.HWPT_REF [HWP_DUPWT]);
CST [.CTLR, .TEMP + 6, D_COUNT] = 0;
                 5632
                 5633
                 5634
                 5635
                         .
                5636
                5637
:
                 5638
:
                 5639
:
                 5640
                 5641
                                                                 FLAG = FOUND:
                 5642
:
                                                                 exitloop:
                 5643
.
                                                                 end
                 5644
                                                          else
                 5645
                                                                                                         ! DUPLICATE UNIT
                                                                 PRINTF (CER_O1, .HWPT_REF [HWP_NUM], .HWPT_REF [HWP_IP_ADDR]);
! "DUPLICATE UNIT: XX AT IP: XXXXXX"
                 5646
                 5647
.
                 5648
                                                                 DUR (.UNIT) = DU_CONF: ! CONFIGURATION ERROR
.
                 5649
                                                                 DODU (.UNIT);
                                                                                                         ! DROP UNIT
                 5650
                                                                 FLAG - FOUND:
                 5651
                                                                 exitloop;
                 5652
                                                                 end:
                 5653
                 5654
                                              if .FLAG eql NOT_FOUND
                                                                                                      ! IF NO IP ADDR MATCH TO EXISTING CST
                 5655
                 5656
                                                    begin
                 5657
                 5658
                                                    incr CTLR from 0 to (MAX_CTLR - 1) do ! LOOP THROUGH EACH CST
                 5659
.
                 5660
                                                           if .CST [.CTLR, IP_ADDR] eqla 0 ! IF EMPTY CST FOUND
:
                 5661
:
                                                           then
                 5662
                                                                 begin
FLAG = FOUND:
:
                 5663
                                                                CST (.CTLR, IP_ADDR) = .HWPT_REF (HWP_IP_ADDR);
CST (.CTLR, VEC_ADDR) = .HWPT_REF (HWP_VECTOR);
CST (.CTLR, BR_LEV) = .HWPT_REF (HWP_BR_LEVEL);
TEMP = .HWPT_REF (HWP_NUM) * UNIT_SIZE * OF_UN;
CST (.CTLR, .TEMP, D_ALL) = .HWPT_REF (HWP_DISK);
CST (.CTLR, .TEMP, D_UNIT) = .UNIT;
CST (.CTLR, .TEMP, D_FATAL) = .FALSE.
                 5664
                 5665
                 5666
.
                 5667
                 5668
                                                                                                                                                            !COPY DISK ADDR AND PROT BIT
                 5669
.
                                                                 CST [.CTLR, .TEMP, D_FATAL] = FALSE;
                 5670
```

```
SEQ 0157
ZRQAM2
                     RD/RX EXERCISER
                                                                                       5-Dec-1983 10:27:14
                                                                                                                      VAX-11 Bliss-16 V3-555 Page 157
DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (41)
                                                                                                                      VAX-11 Bliss-16 V3-555
V01.2
                     INITIALIZE SECTION
                                                                                       5-Dec-1983 10:27:04
             5671
                                                     CST [.CTLR, .TEMP, D_PRES] = PRESENT;
                                                     CST [.CTLR, .TEMP + 1, D_BEGO] = .HWPT_REF [HWP_BEG_TRK];
CST [.CTLR, .TEMP + 2, D_BEGO] = .HWPT_REF [HWP_BEG_TRK];
CST [.CTLR, .TEMP + 3, D_ENDO] = .HWPT_REF [HWP_END_TRK];
CST [.CTLR, .TEMP + 4, D_ENDO] = .HWPT_REF [HWP_END_TRK];
CST [.CTLR, .TEMP + 5, D_DBN] = 0;
CST [.CTLR, .TEMP + 5, NODUPMEDIA] = NOT(.HWPT_REF [HWP_DUPEX]);
CST [.CTLR, .TEMP + 5, DUPWRITE] = (.HWPT_REF [HWP_DUPWT]);
             5672
:
             5673
             5674
:
             5675 !
.
             5676
:
             5677
:
             5678
:
                                                     CST [.CTLR, .TEMP + 6, D_COUNT] = 0;
             5679
:
             5680
             5681
                                                     exitloop:
:
             5682
                                                                                     ! IF EMPTY CST FOUND
:
                                                     end:
             5683
.
             5684
                                           if .FLAG eql NOT_FOUND
                                                                                     ! IF NO EMPTY CST FOUND
:
             5685
                                           then
:
                                                begin
PRINTF (CER_O2, MAX_CTLR);
DUR [.UNIT] = DU_CONF;
             5686
             5687
                                                                                    ! "MORE THAN X DIFFERENT IP ADDRESSES."
             5688
                                                                                     ! CONFIGURATION ERROR
             5689
                                                DODU (.UNIT);
                                                                                      ! DROP UNIT
:
             5690
                                                end;
:
             5691
             5692
                                          end:
                                                                                     ! IF NO IP ADDR MATCH IN CST
             5693
             5694
                                                                                      ! IF GPHARD RETURNS A HUP TABLE
             5695
             5696
                             CONFIGURATION CHECK FOR LEGAL RDRX UNIT MIX BECAUSE WE HAVE DIFFERENT
.
             5697
                             DRIVES : THE RD51, AND RX50.
             5698
                             (NEEDED?)
             5699
.
             5700
:
                          end:
                                                                                     ! END OF "NON NEW PASS" INITIALIZATION
             5701
             5702
                    if .ENTRY_REASON eq1 NEW_PASS
             5703
                     then
             5704
                          begin
             5705
:
             5706
:
                           incr UNIT from 0 to (.L$UNIT - 1) do
             5707
                               GPHARD (.UNIT, HWPT_REF):
                                                                                                ! DUMMY GPHARDS FOR NEW PASS
             5708
             5709
                           incr CTLR from 0 to (MAX_CTLR - 1) do
                                incr OFFSET from (0 + OF_UN) to (3 * UNIT_SIZE + OF_UN) by UNIT_SIZE do (CST [.CTLR, .OFFSET, D_STAT] = OFFLINE); ! START EACH UNIT AS OFFLINE
             5710
             5711
             5712
:
             5713
             5714
             5715
                          end:
             5716
             5717
                    if (.ENTRY_REASON eq1 START)
:
             5718
                    then
:
             5719
                          begin
CTLR_CNT = 0;
             5720
                                                                                      ! NUMBER OF CONFIGURED CONTROLLERS
             5721
                          CRN_LOW - CRN_HIGH - O:
                                                                                      ! INITIALIZE COMMAND REF NUMBER
             5722
                           incr CTLR from 0 to (MAX_CTLR - 1) do
```

5723

ZRQAM2 VO1.2		RD/RX EXERCISER INITIALIZE SECTION			5-Dec-1983 10:27:1 5-Dec-1983 10:27:0	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQA	SEQ 0158 Page 158 CO.BL1;82 (41)
:	5724	if .CST [.CTL	R. IP_ADDR	nega 0	! IF CONTROLLER IS	PRESENT	
:	5725 5726	then CTLR_CNT	CTLR_CN	T . 1;	! INCREMENT CONTROL	LER COUNT	
:	5727 5728	MEMORY (FREE_MEM_			! GET START OF FREE		
:	5729 5730	end:			! END OF "START" IN		
	5731 5732					212112011	
	5733 5734	CLEAR STATIST	ICS TABLES				
	5735 5736		MAY INITE	1 40	A CLEAR CHORENT CTA	1101100	
	5737 5738 5739	incr COUNT from 0 TALLY [.UNITS	to TALLY_	CLEAR -	! CLEAR CURRENT STA 1 do UNT) = 0;	1151105	
		if .CLEAR_TABLES			! IF CLEAR TABLES O	N EVERY PASS	
	5742	incr UNITS from 0	to MAX_UN	ITS - 1	do		
	5/44	TALLY (.U	NITS + TAL	LY_LEN +	TALLY_LEN - 1 do ! I	NITIALIZE TOTALS	
:	5745 5746	if .CLEAR_TABLES					
	5748	incr CTLR from 0	to MAX_CTL	R - 1 do			
	5749 5750	C_ERR_TBL [.C	TLR. C_ERR	_HRD] =	O: ! INITALIZE CONTROL	LER ERRORS	
	5751 5752	C_ERR_TBL (.C	TLR. C_ERR	_SFT] =	0; !		
:	5753 5754	SETPRI (PRIOO);			! SET PROGRAM PRIOR	ITY TO O	
:	5755 5756	ENDINIT:					
				.GLOBL	L\$DLY		
				.SBTTL	LINIT INITIALIZE SECTION		
000000	004137 162706	000000G 000016	LINIT:	JSR SUB	R1. \$SAVE5 \$16.SP	•	5511
000010 000014	012700 104441	000340		MOV TRAP	#340,R0 41		5523
000016	012700 104447	000035		MOV TRAP	#35,R0 47	•	5525
000022 000024 000026	103012 112737	000005 000000G		BHIS	25 65,ENTRY.REASON		5528
000034	105737	00000G		TSTB	SWP.FLAGS		5530
000042 000044	105016			CLRB	(SP)	: CLEAR.TABLES	5532
000046 000052	112716	000001 000040	14:	MOVB	#1,(SP)	+.CLEAR.TABLES	5530 5534
	722.00	33340	24:	.104	040,R0		5538

				DIS		
ZRQAM2 VO1.2	RD/RX EXE	ERCISER ZE SECTION		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO	SEQ 0159 Page 159 .BL1;82 (41)
000056	104447		TRAP	47		
000060	103010		BHIS	34		
000062	104433		TRAP	33		5540
000064	112737 000001 0	00000G	MOVB	#1.ENTRY.REASON		5542
000072	112716 000001		MOVB	01.(SP)	, *, CLEAR, TABLES	5543
000076	105037 000000G		CLRB	INIT.OCCURED		5544
000102 000106 000110	012700 000037	34:		#37,R0		5547
000106	104447		TRAP	47		
000110	103005	2000000	BHIS	46		
000112	112737 000002 0 112716 000001	00000G	MOVB	#2.ENTRY.REASON		5550
000120	012700 000036	41:	MOVB	#1,(SP)	: *,CLEAR.TABLES	5551
000124	104447		MOV	#36.R0 47		5554
000132	103012		BHIS	66		
000124 000130 000132 000134 000142	112737 000003 0	00000G	MOVB	#3,ENTRY.REASON		5557
000142	112737 000003 0 105737 000000G		TSTB	SWP.FLAGS		5559
COOLAR	100402		BMI	5#		3339
000150	105016		CLRB	(SP)	: CLEAR.TABLES	5561
000152	000402		BR	61	1	5559
000150 000152 000154 000160 000164	112716 000001	5#:		41,(SP)	. *,CLEAR.TABLES	5563
000160	012700 000034 104447	6\$:	MOV	434,R0		5567
000164	104447		TRAP	47		
000166	103040		BHIS	126		
000170	112737 000004 0	00000G	MOVB	44.ENTRY.REASON	1	5570
000176	112716 000001		MOVB	#1,(SP)	* *, CLEAR . TABLES	5571
000170 000176 000202 000206 000212	105037 000000G		CLRB	#4.ENTRY.REASON #1.(SP) INIT.OCCURED #MSG.01(SP) #1(SP) SP.RO	1	5572
000206	012746 000000G 012746 000001		MOV	9MSG.01,-(SP)		5573
000216	012746 000001 010600		MOV	Ø1,-(SP)		
000220	104417		MOV TRAP	17	; SP,*	
000222	012702 000075		MOV	075.R2	. A COLAIT	6676
000216 000220 000222 000226 000232 000234	012703 000515	78:		4515,R3	: *.COUNT : *.DELAY.MULT	5575 5577
000232	010301		MOV	R3,R1	: DELAY.MULT. \$\$TMP2	5578
000234	001411	81:		116	, been incertaine	3310
000236	013700 000000G		MOV	L\$DLY,RO	: *, \$\$TMP1	
000242	001404		BEQ	10#		
000244	005066 000020	9#:	CLR	20(SP)	; \$\$TMP	
000250	005300		DEC	RO	; \$\$TMP1	
000252	001374		BNE	91		
000254	005301	100		R1	: \$\$TMP2	
000256	000766		BR	81		
000260	104422	110		22 R2		
000262	005302 001360		DEC	74	: COUNT	5575
000266	022626		BNE	7\$ (SB), (SB),		22/0
000270	023727 000000G (	000004 120	: CMP	(SP)+,(SP)+ L&UNIT,04		5569
000276	101405	12.	BLOS	13#		5592
000244 000250 000252 000254 000260 000262 000264 000266 000270 000276 000300 000302	104454		TRAP	54		5595
000302	000001		. WORD			3393
000304	000000G		. WORD	ĒGS.01		
000306	000000V		. WORD	EMS.01		
000310	104444		TRAP	44		
000312	123727 000000G (	000005 130		ENTRY.REASON. #5		5605

ZRQAM2 VO1.2		RD/RX EXERCISER INITIALIZE SECTION			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.B	SEQ 0160 Page 160 L1:82 (41)
000320	001002			BNE	14\$		
000322	000137	0036241		JMP	35#		
000326	005000		14\$:	CLR	00	; COUNT	E600
000330	005060	000000G	15\$:	CLR	CST(RO)	+ (COUNT)	5609
000334	062700	000002	134.	ADD	42 BO	* *(COUNT) * *,COUNT * COUNT,*	5610
000334	030037	000074			#2.R0	; *,COUNT	5609
000340 000344 000346 000354	020027	000074		CMP	RO.#74	; COUNT, 4	
000344	003771	0000000 000010		BLE	15#		
000346	013766 005005	000000G 000012		MOV	L\$UNIT,12(SP)	1	5612
000354	005005			CLR	R5	UNIT	
000356 000362 000364	000137	003602'		JMP	33\$		
000362	010500		16\$:	MOV	R5,R0	; UNIT,*	5614
000364	104442			TRAP	42		
000366 000372 000374	010066	000010		MOV	RO,10(SP)	; *,HWPT.REF	
000372	001002			BNE	17\$		
000374	001002 000137 105004	003600'		JMP	324		
000400	105004		178:	CLRB	R4	; FLAG	5617
000402	005066	000002		CLR	2(SP)	CTLR	
000406	016646	000002	18\$:	MOV	2(50) -(50)	; CTLR,+	5619
000412	012746	000076	204.	MOV	2(SP),-(SP) #76,-(SP)	; CILR,+	5621
000416	004737	000000G		JSR	DC DI AMI		
000416 000422 000424 000432	004737 022626	000000		CMD	PC.BL#MUL		
000422	026026	0000000 000010		CMP	(SP)+,(SP)+		
000424	026076 001174	000000G 000010		CMP	CST(RO),@10(SP)	; *,HWPT.REF	
000432	001174			BNE	236		
000434	012766	000001 000004		MOV	#1,4(SP)		5641
000442 000446	112704 012700	000001		MOVB	01,R4	: A.FLAG	
000446	012700	000006		MOV	46,R0		5624
000452 000456	066600 010066 111046	000010 000006		ADD	10(SP),R0	: HWPT.REF. *	
000456	010066	000006		MOV	RO.6(SP) (RO)(SP) #177774.(SP) #7(SP)		
000462	111046			MOVB	(RO),-(SP)		
000464	042716	177774		BIC	#177774.(SP)		
000470	012746	000007		MOV	47(SP)		
000474	004737	000000G		JSR	PC.BL \$MUL		
000500	010003			MOV	RO,R3		
000500 000502 000504	004737 010003 005726 016616			TST	(SP)+		
000504	016616	000004		MOV	A(SP) (SP)	; CTLR.*	
000510	012746	000037		MOV	4(SP),(SP) #37,-(SP)	; CILR.*	
000514	004737	000000G		JSR	PC.BL#MUL		
000520	010002	000000			PC . BC + ITOL		
000520 000522 000524	022626			MOV	RO,R2		
000524	060300				(SP)+,(SP)+		
000524	060300 006300 032760			ADD	R3,R0		
000526 000530 000536	033760	040000 0000000		ASL	RO		
000536	002100	040000 000006G		BIT	#40000,CST+6(RO)		
000540	001106			BNE	221		
000540	010301	******		MOV	R3,R1	: A.TEMP	5627
000542	062701	000003		ADD	#3,R1	: *.TEMP	
000540 000542 000546 000550 000552	010200			MOV	R2,R0		5628
000550	060100			ADD	R1,R0	: TEMP. 4	
000552	006300			ASL	RO		
000554	062700	00000G		ADD	♦CST,RO		
00000	017610	000006		MOV	86(SP),(RO)		
000564	010503			MOV	R5,R3	; UNIT.*	5629
000566 000570	000303			SWAB	R3		3029
000570	042703	170377		BIC	#170377,R3		
				010	42100111NO		

ZRQAM2		DO /DV EX	PERCICER			F D 1007 10 07 11		SEQ 0161
V01.2		RD/RX EX	IZE SECTION			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bl;ss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.B	Page 161
						3 500 1703 10.27.04	DISK FOSENZ: [DIETZ. NDNX )ZNUMCO. B	L1;02 (41)
000574	042710	007400			BIC	#7400,(RO)		
000600	050310	010000			BIS	R3,(R0)		
000602	042710	010000			BIC	#10000,(RO)		5630
000613	052710 010200	040000			BIS	#40000,(RO)		5631
000606 000612 000614	060100				ADD	R2,R0 R1,R0	TEMP	5632
000616	006300				ASL	PO	; TEMP, *	
000620	016603	000010			MOV	10(SP),R3 10(R3),CST+2(R0) R2.R0	: HWPT.REF.*	
000624 000632 000634 000636	016360	000010	000002G		MOV	10(83) CST+2(80)	* *(HWPT.REF).*	
000632	010200		***************************************		MOV	R2,R0	; +(rimr1, NEr /,+	5634
000634	060100				ADD	R1,R0	TEMP. 4	3034
000636	006300				ASL	RO		
000640	016360	000012	000006G		MOV	12(R3),CST+6(R0)	; *(HWPT.REF),*	
000646	010200				MOV	R2,R0		5636
000650 000652	060100				ADD	R1.R0	; TEMP, *	2000
000652	006300				ASL	RO		
000654	062700	000012G			ADD	#CST+12,RO		
000660	105010				CLRB	(RO)		
000654 000660 000662 000664 000672	005003 132776	000010	*******		CLR	R3		5637
000664	132776	000010	000006		BITB	#10,86(SP)		
000674	001401				BEQ	19#		
000676	005203 005103			104.	INC	R3		
000676 000700	042710	100000		19\$:	BIC	R3		
000704	032703	000001			BIT	#10000C,(RO) #1,R3		
000710	001402	000001			BEQ	206		
000712	052710	100000			BIS	#100000,(RO)		
000716	117603	000006		201:	MOVB	96(SP),R3		5638
000722	042710	010000		201.	BIC	#10000,(RO)		2030
000726	032703	000020			BIT	#20,R3		
000732	001402				BEQ	21#		
000726 000732 000734	052710	010000			BIS	#10000,(R0)		
000740	010200			21\$:	MOV	R2.R0		5639
000742	060100				ADD	R1.R0	; TEMP. 4	
000744	006300				ASL	RO		
000746	005060	000014G			CLR	CST+14(RO)		
000752 000754		000010			BR	241	1	5626 5646
000760	017646 117646	000010		22#:	MOV	810(SP),-(SP)	; HWPT.REF, 4	5646
000764	042716	000010 177774			MOVB	810(SP),-(SP) #177774,(SP)		
000770	012746	000000G			BIC	#1////4.(SP)		
000774	012746	000003			MOV	#CER.01,-(SP) #3,-(SP)		
001000	010600	00000			MOV	SP.RO		
001000 001002	104417				TRAP	17	; SP.4	
001004	062706	000010			ADD	#10,SP		
001010 001016	112765		00000G		MOVB	#1.DUR(R5)	: *,*(UNIT)	5648
001016	010500				MOV	R5,R0	UNIT.	5649
001020	104451				TRAP	51		3047
001022	000406				BR	241		5645
001024	005266	000002		23\$:	INC	2(SP)	; CTLR	5619
001030	000243				. WORD	CLV!CLC		
001032	003002				PCT	244		
001032	003002				BGT	241		

ZRQAM2 VO1.2		RD/RX EXERCISER INITIALIZE SECTION			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL	SEQ 0162 Page 162 1;82 (41)
001034	000137	002476'		JMP	18\$		
001040	105704		24\$:	TSTB	R4	; FLAG	5654
001042	001402			BEQ	25\$		3034
001044	000137	003600'		JMP	32\$		
001050	005002		25\$:	CLR	R2	; CTLR	5658
001052	010246	000074	26\$:	MOV	R2,-(SP)	; CTLR,+	5660
001054 001060	012746	000076 000000G		MOV	476,-(SP)		
001064	022626	000000		JSR CMP	PC,BL\$MUL		
001066	005760	00000G		TST	(SP)+,(SP)+ CST(RO)		
001072	001162	000000		BNE	30\$		
001074	112704	000001		MOVB	#1,R4	: *.FLAG	5663
001100	017660	000010 000000G		MOV	810(SP),CST(RO)	: HWPT.REF.*	5664
001106	016646	000010		MOV	10(SP),-(SP)	; HWPT.REF. *	5665
001112	062716	000002		ADD	#2.(SP) #(SP)+.R3		3003
001116	013603			MOV	a(SP)+,R3		
001120	042703	177000		BIC	#177000.R3 #777.CST+2(RO)		
001124	042760	000777 000002G		BIC	#777,CST+2(RO)		
001132	050360	000002G		BIS	R3.CST+2(R0) 10(SP).R3		
001142	016603 116360	000010 000004 000004G		MOV	10(SP),R3	; HWPT.REF, #	5666
001150	012700	000006		MOVB	4(R3),CST+4(R0) 46,R0	: *(HWPT.REF),*	
001132 001136 001142 001150 001154	060300	00000		ADD	R3,R0	: HWPT.REF.+	5667
001156	010066	000006		MOV	80.6(SP)	; nwri.ker.*	
001162	111046			MOVB	(RO), -(SP)		
001162 001164	042716	177774		BIC	RO,6(SP) (RO),-(SP) #177774,(SP)		
001170 001174	012746	000007		MOV	47,-(SP)		
001174	004737	00000G		JSR	PC,BL\$MUL		
001200	005726			TST	(SP)+		
001202	010001			MOV	RO.R1	; A, TEMP	
001204 001210	062701 010216	000003		ADD	#3,R1	: A.TEMP	
001212	012746	000037		MOV	R2.(SP)	; CTLR.*	5668
001213	004737	000000G		MOV	#37, -(SP)		
001213	010003	000000		JSR MOV	PC.BL\$MUL RO.R3		
001224	005726			TST	(SP)+		
001226	060100			ADD	R1,R0	; TEMP, 4	
001230	006300			ASL	RO	. 16.4.	
001232	062700	000000G		ADD	#CST,RO		
001236	017610	000010		MOV	010(SP),(RO)		
001242	010516			MOV	R5.(SP)	; UNIT.*	5669
001244	000316			SWAB	(SP)		
001250	042716	170377		BIC	#170377,(SP)		
001256	042710 052610	007400		BIC	#7400,(RO)		
001260	042710	010000		BIS	(SP)+,(RO)		
001230 001232 001236 001242 001244 001246 001252 001256 001260 001264 001270	052710	040000		BIC	#10000,(R0) #40000,(R0)		5670
001270	010300	0.000		MOA	R3,R0		5671
001272	060100			ADD	R1.RO	TEMP. *	5672
VOLETA	006300			ASL	RO	1 1011	
001276	016646	000010		MOV	10(SP),-(SP)	; HWPT.REF. 4	
001302	062716	000010		ADD	#10,(SP)		
001306	013660	000002G		MOV	a(SP)+,CST+2(RO)		

					HI 2		
RQAM2		RD/RX EXERCISER INITIALIZE SECTION			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO	SEQ 0163 Page 16 .BL1;82 (41)
01312	010300			MOV	R3,R0		567
01314	060100			ADD	R1,R0	; TEMP. *	-
001316 001320 001324 001330 001334 001336 001340 001346 001350 001352 001356 001364 001366 001366 001367 001374 001376 001402	006300	******		ASL	RO		
01320	016646 062716	000010		MOV	10(SP),-(SP)	: HWPT.REF. *	
01324	013660	000012 000006G		ADD MOV	#12.(SP) @(SP)+.CST+6(RO)		
01334	010300	000000		MOV	R3,R0		567
01336	060100			ADD	R1,R0	: TEMP. 4	307
01340	006300			ASL	RO		
01342	062700	000012G		ADD	#CST+12.RO		
01346	105010 005046 131776			CLRB	(RO)		
01350	005046			CLR	-(SP)		567
01332	131776	000010		BITB	(PC),810(SP)		
01350	001401			BEQ	27\$ (SP)		
01362	005116		27\$:	COM	(SP)		
01364	011646			MOV	(SP),-(SP)		
01366	042710	100000		BIC	#100000,(RO)		
01372	042710 006026			ROR	#100000,(RO) (SP)+		
01374	1030u2 052710			BCC	28\$		
01376	052710	100000		BIS	#100000,(RO)		
01406	117616	000010 010000	28#:	MOVB	@10(SP),(SP) #10000,(RO)	•	567
01412	042710	000020		BIC	#20.(SP)+		
01416	001402	030020		BEQ	291		
01412 01416 01420 01424 01426	032726 001402 052710 010300	010000		BIS	#10000,(RO)		
01424	010300		291:	MOV	R3,R0		567
01426	060100			ADD	R1,R0	; TEMP.4	
01430	006300	0000140		ASL	RO		
01430 01432 01436	005060 000403	000014G		CLR	CST+14(RO)		
01440	005202		30#:	BR	31¢ R2	CTLR	566 565
01442	000243		307.		CLVICLC	. CICK	363
01444				BLE	26\$		
01450	105704		31#:	TSTB BNE	R4	; FLAG	568
01452	001017	000001		MOV	32\$ #1,-(SP)		568
01456	012746	000000G		MOV	#CER.02,-(SP)		300
01462	012746	000002		MOV	#2,-(SP)		
01466	010600			MOV	SP.RO	; SP.*	
01470	104417			TRAP	17		
01472	112765	000001 000000G		MOVB	#1,DUR(R5)	: *,*(UNIT)	568
01500	010500			MOV	R5.R0	: UNIT,+	568
01504	104451 062706 005205	000006		TRAP	51 46,SP		544
01510	005205		324:	INC	R5	UNIT	568 561
01470 01472 01500 01502 01504 01510 01512	020566	000012	334:	CMP	R5.12(SP)	; UNIT.*	301
01516	002002			BGE	344		
01516 01520 01524	000137 123727	0024521		JMP	16\$		
01524	123727	000000G 000005	344:	CMPB	ENTRY.REASON, #5		570
01532	001035	0000000	754	BNE	404		
01534	013701	00000G	35#:	MOV	L\$UNIT,R1		570

ZRQAM2		RD/RX EXERCISER			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555	SEQ 0164 Page 164
V01.2		INITIALIZE SECTION			5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL	:82 (41)
001540 001542	005002 000405			CLR BR	R2 37\$	; UNIT	
001544	010200 104442		36\$:	MOV TRAP	R2.R0	; UNIT,*	5707
001550	010066 005202	000010		MOV	RO,10(SP)	: 4, HWPT.REF	
001546 001550 001554 001560 001562 001564 001570 001572 001574	020201 002771		37\$:	CMP	R2,R1 36\$	: UNIT : UNIT, *	5706
001562	005003	000007	704	CLR	R3	; CTLR	5709
001570	012701 010300	000003	38\$: 39\$:	MOV	#3,R1 R3,R0	: *,OFFSET : CTLR,*	5710 5711
001572	060100 006300			ADD ASL	R1.R0 R0	; OFFSET, 4	
001576 001604	042760 062701	020000 000000G 000007		BIC	#20000,CST(RO) #7,R1	: *,OFFSET	5710
001610 001614		000030		CMP	R1.#30 39\$	: OFFSET.*	3/10
001616 001622	062703	000037		ADD	#37.R3 CLV!CLC	; *,CTLR	5709
001624	003757			BLE	38#		
001626 001634 001636		000000G 000001	40\$:	CMPB BNE	ENTRY.REASON, #1		5717
001636	005037	000000G 000000G		CLR	CTLR.CNT		5720
001642 001646 001652 001654	005037	000000G		CLR	CRN.HIGH CRN.LOW		5721
001654	005000 005760	000000G	418:	CLR	CST(RO)	: CTLR : *(CTLR)	5722 5724
001660 001662	001402 005237	000000G		BEQ	42\$ CTLR.CNT		5726
001666 001672	062700 000243	000076	424:	ADD . WORD	#76.RO CLV!CLC	: +,CTLR	5722
001674 001676	003767 104431			BLE	416		
001700	010037	000000G		TRAP	31 RO,FREE.MEM.ADDR	•	5728
001704 001706	005001 005003		434: 444:	CLR	R1 R3	: UNITS : COUNT	5736 5737
001710 001712	060100		454:	MOV ADD	R3,R0 R1,R0	: COUNT. 4 : UNITS. 4	5738
001714 001716	006300 005060	000000G		ASL	RO TALLY(RO)	. 0.12.0.2	
001722	005203	000006		INC	R3	: COUNT	5737
001730	020327			BLE	R3,06 454	: COUNT, 4	
001714 001716 001722 001724 001730 001732	062701 020127	000034 000124		ADD	#34,R1 R1,#124	: *,UNITS : UNITS,*	5736
001742 001744 001750 001752	003761	000001		BLE	44\$ 01.(SP)	CLEAR.TABLES	5740
001752	001435 005001			BEQ	49¢ R1	UNITS	5742
001754 001760	012705	000007	464:	MOV	#7,R3 R3,R0	: *.COUNT : COUNT.*	5743 5744

ZRQAM2 VO1.2	RD/RX EXERCISER INITIALIZE SECTION	5-0 5-0	Dec-1983 10:27:14 VAX-1	SEQ 1 Bliss-16 V3-555 P SUSER2:[DIETZ.RDRX]ZRQACO.BL1;82	age 165
001762 060100 001764 006300 001766 005060	000000G	ADD R1,RO ASL RO CLR TALLY(RO)	; UNI	TS,*	
001772 005203 001774 020327	000033	INC R3 CMP R3,#33	; COU		5743
002002 062701	000034 000124	BLE 47\$ ADD #34,R1 CMP R1,#124	; 4,U		5742
002006 020127 002012 003760 002014 032716 002020 001411	000001	BLE 46\$ BIT #1.(SP) BEQ 49\$		CLEAR . TABLES	5746
002022 005000 002024 105060 002030 105060 002034 062700 002040 000243	000000G 000001G 000002	CLR RO CLRB C.ERR.TBL(RO CLRB C.ERR.TBL+1( ADD #2.RO .WORD CLV!CLC		TLR)	5748 5750 5751 5748
002042 003770 002044 005000 002046 104441 002050 062706 002054 000207	49\$: 000016	BLE 48\$ CLR RO TRAP 41 ADD #16.SP RTS PC	:		5754 5511
; Routine Size: ; Maximum stack	535 words. Routine Base: depth per invocation: 19 word	*CODE* + 2070			
000000 004737 000004 104411 000006 000207	002070' L\$INIT		TALIZE SECTION		5754
: Routine Size:	4 words, Routine Base: depth per invocation: 2 words	*CODE* + 4146			

```
SEQ 0166
ZRQAM2
                    RD/RX EXERCISER
                                                                                                                VAX-11 Bliss-16 V3-555
                                                                                   5-Dec-1983 10:27:14
                                                                                                                VAX-11 Bliss-16 V3-555 Page 166
DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (42)
V01.2
                    AUTODROP SECTION
                                                                                   5-Dec-1983 10:27:04
             5757 #sbttl 'AUTODROP SECTION'
             5758
.
             5759 !+
:
            5760 ! THIS CODE IS EXECUTED IMMEDIATELY AFTER THE INITIALIZE CODE IF 5761 ! THE "ADR" FLAG WAS SET. THE UNIT(S) UNDER TEST ARE CHECKED TO 5762 ! SEE IF THEY WILL RESPOND. THOSE THAT DON'T ARE IMMEDIATELY
.
:
:
             5763 ! DROPPED FROM TESTING.
.
             5764 !-
.
             5765
.
             5766 BGNAUTO:
:
             5767
:
             5768 !if (.SWP_FLAGS and SWF_TRC) eql SWF_TRC 5769 !then PRINTF (DBM3);
:
             5770
.
             5771 ENDAUTO:
: INFO#219
                      L1:5756
: Empty compound expression is illegal : Error occurred expanding macro ENDAUTO, called from source
                                                              .SBTTL LAUTO AUTODROP SECTION
000000 000207
                                                   LAUTO: RTS
                                                                                                                                                                    5756
: Routine Size: 1 word,
                                        Routine Base: $CODE$ + 4156
; Maximum stack depth per invocation: 0 words
                                                              .SBTTL L$AUTO AUTODROP SECTION
000000 004737 004156'
000004 104461
                                                   L$AUTO:: JSR
                                                                       PC, LAUTO
                                                                                                                                                                    5766
                                                                       61
PC
                                                              TRAP
000006
          000207
                                                             RTS
; Routine Size: 4 words.
                                        Routine Base: $CODE$ + 4160
; Maximum stack depth per invocation: 2 words
```

```
SEQ 0167
ZRQAM2
                RD/RX EXERCISER
                                                                    5-Dec-1983 10:27:14
                                                                                            VAX-11 Bliss-16 V3-555
                                                                                                                                  Page 167
V01.2
                CLEANUP CODING SECTION
                                                                    5-Dec-1983 10:27:04
                                                                                            DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (43)
          5772 #sbttl 'CLEANUP CODING SECTION'
          5773
.
          5774
:
          5775
                ! THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS PERFORMED
:
          5776
                ! AFTER THE HARDWARE TESTS HAVE BEEN PERFORMED.
:
          5777
.
          5778
.
          5779
                BGNCLN:
:
          5780
:
          5781
                incr CTLR from 0 to (MAX_CTLR - 1) do ! FOR EACH CONTROLLER
          5782
          5783
                     if (RDRX_ADDR = .CST [.CTLR, IP_ADDR]) nega 0 ! IF CONTROLLER EXISTS
:
          5784
                     then
.
          5785
                         begin
:
          5786
                         if .DCT [.CTLR, STAT] eql ONLINE
:
          5787
                         then
:
          5788
                                  incr COUNT from 1 to 10000 do
:
                                         begin
DELAY (1):
if .DCT [.CTLR, CRING_CNT] eql 0 !WAIT TIL OUTSTANDING COMMANDS FINISHED
          5789
          5790
:
          5791
:
          5792
                                          then EXITLOOP:
.
          5793
:
                                          end:
                         WRT_RDRX (RCIP, RC_ALL, ALL_ONES);
CLRVEC (.CST[.CTLR, VEC_ADDR]);
          5794
                                                                   ! WRITE IP TO STOP DEVICE
.
          5795
                                                                   ! RETURN CONTROLLER'S TRAP VECTOR TO SUPERVISOR
:
          5796
                         end:
:
          5797
                DORPT:
                                                                   !GIVE REPORT
.
          5798
                ENDCLN:
:
                                         LCLEAN: JSR R1. $SAVE5
000000 004137 000000G
                                                                                                                                       5771
000004
        005746
                                                  TST
                                                           -(SP)
000006 005005
                                                  CLR
                                                           R5
                                                                                            : CTLR
                                                                                                                                       5781
000010 010546
                                          18:
                                                  MOV
                                                           R5,-(SP)
                                                                                            : CTLR.+
                                                                                                                                       5783
000012 012746
                000076
                                                  MOV
                                                           476,-(SP)
000016
        004737
                00000G
                                                   JSR
                                                           PC.BL #MUL
000022
        010004
                                                  MOV
                                                           RO.R4
000024
        022626
                                                  CMP
                                                           (SP)+,(SP)+
CST(R4),RDRX.ADDR
000026
        016437
                000000G 000000G
                                                  MOV
000034
        001444
                                                  BEQ
                                                           8
000036
        010546
                                                           R5,-(SP)
                                                                                            : CTLR.+
                                                                                                                                       5786
000040 012746
                 000022
                                                  MOV
                                                          #22, -(SP)
PC, BL #MUL
000044 004737
                                                   JSR
                 000000G
000050 022626
                                                           (SP)+,(SP)+
DCT(RO)
                                                  CMP
000052 005760
                 000000G
                                                  TST
000056 100022
                                                  BPL
000060 012703
                 023420
                                                  MOV
                                                           #23420.R3
                                                                                            : *, COUNT
                                                                                                                                       5788
000064 012702
                000001
                                                  MOV
                                                           #1,R2
                                          21:
                                                                                            : *, $$TMP2
                                                                                                                                       5790
000070 001410
                                                  BEQ
                                          34:
000072 013701
                                                  MOV
                000000G
                                                           L$DLY.R1
                                                                                            : *. $$TMP1
000076
        001403
                                                  BEQ
                                                           5#
000100
        005016
                                                  CLR
                                                           (SP)
                                          41:
                                                                                            : $$TMP
000102
        005301
                                                  DEC
                                                           R1
                                                                                            : $$TMP1
```

	701.2		RD/RX EXERCISER CLEANUP CODING SECTION			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1	SEQ 0168 Page 168 1;82 (43)
(	000106	001375 005302 000767		5\$:	BNE DEC BR	4 \$ R2 3 \$	; \$\$TMP2	
0	000112	105760 001402 005303	000000G	6\$:	TSTB BEQ DEC	DCT(RO) 7\$ R3	: COUNT	5791 5792 5788
0	000124 000130 000134	001360 012700 010077 016400 042700	177777 000000G 000002G 177000	7\$:	BNE MOV MOV BIC	2\$ #-1,R0 RO,@RDRX.ADDR CST+2(R4),R0 #177000,R0	: *.RC.REG : RC.REG.*	5794 5795
1	000144	104436 005205 000243	177000	8\$:	TRAP INC . WORD C	36 R5	; CTLR	5781
1 8	000154	003716 104424 005726 000207			BLE TRAP TST RTS	1\$ 24 (SP)+ PC	:	5796 5771
	Routing Maximu	e Size: m stack	57 words. Routine depth per invocation:	Base: 10 words	CODE\$ +	4170		
	000000	004737	004170'	L\$CLEAN	.SBTTL	L\$CLEAN CLEANUP CODING SECTION		
	000004	104412 000207	004210	LVCLEAN	JSR TRAP RTS	PC.LCLEAN 12 PC		5797
1								

Routine Size: 4 words. Routine Base: \$CODE\$ + 4352 Maximum stack depth per invocation: 2 words

```
SEQ 0169
ZRQAM2
                 RD/RX EXERCISER
                                                                       5-Dec-1983 10:27:14
                                                                                                VAX-11 Bliss-16 V3-555
                                                                                                                                        Page 169
V01.2
                 DROP UNIT SECTION
                                                                       5-Dec-1983 10:27:04
                                                                                                DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (44)
           5799 #sbttl 'DROP UNIT SECTION'
           5800
:
           5801
:
                 ! THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
           5802
.
           5803
                 ! TO NO LONGER BE TESTED.
           5804
           5805
           5806
                BGNDU:
           5807
           5808
                 local
           5809
                      UNIT : word,
                                                                                       ! NUMBER OF UNIT BEING DROPPED
:
           5810
                      PRINT : byte initial (byte (FALSE));
                                                                                       ! NO PRINTING OF DROP UNIT MESSAGE
:
           5811
:
           5812
                 label
:
                      SEARCH:
           5813
           5814
           5815
                 begin
           5816
.
           5817 register
:
           5818
                      INPUT = 0:
:
                                                                                        ! UNIT NUMBER APPEARS IN RO UPON ENTRY
           5819
:
           5820 UNIT = . INPUT;
                                                                                        ! GET UNIT NUMBER
           5821
                                                                                        ! UNDECLARE REGISTER
:
                 end;
           5822
.
           5823
                 if (.SWP_FLAGS and SWF_TRC) eql SWF_TRC
:
           5824 then
:
           5825
                     PRINTF (DBM5, .UNIT);
.
           5826
           5827
                 SEARCH :
:
                                                                                       ! BEGIN SEARCH BLOCK
           5828 begin
.
           5829
.
           5830 incr CTLR from 0 to (MAX_CTLR - 1) do
:
                                                                                       ! FOR EACH CONTROLLER
           5831
           5832
                      incr OFFSET from (0 + OF_UN) to (3 * UNIT_SIZE + OF_UN) by UNIT_SIZE do
                                                                                                      ! FOR EACH UNIT ENTRY IN CST
           5833
:
           5834
                          if (.CST [.CTLR, .OFFSET, D_UNIT] eql .UNIT) and (.CST [.CTLR, .OFFSET, D_PRES] eql PRESENT)
                                                                                                        ! IF UNIT MATCHES CST ENTRY
           5835
           5836
                          then
           5837
                              begin
           5838
:
                              if (.CST [.CTLR, .OFFSET, D_STAT] eql ONLINE) or ! IF UNIT IS STILL ALIVE
  (.DUR [.UNIT] eql DU_ONLINE) or
  (.DUR [.UNIT] eql DU_PROTECT)
           5839
:
           5840
.
           5841
           5842
                               then
           5843
                                   begin
PRINT - TRUE:
           5844
                                                                                       ! O.K. TO PRINT MESSAGE
           5845
5
           5846
                                   if (.CST [.CTLR, U_CNT] gtru 0) and
.
           5847
                                      (.CST [.CTLR, .OFFSET, D_STAT] eql ONLINE)
.
           5848
.
           5849
:
                                       CST [.CTLR, U_CNT] = .CST [.CTLR, U_CNT] - 1;! DECREMENT UNIT COUNT
           5850
:
           5851
;
                                   if (.CST [.CTLR, U_CNT] eql 0) and
```

ZRQAM2 VO1.2	RD/RX EXERCISER DROP UNIT SECTION			5-Dec-1983 10 5-Dec-1983 10	0:27:14 0:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQA	SEQ 0170 Page 170 CO.BL1:82 (44)
: 58	52	.CST [.CTL	R. OFFSE	T. D_STAT) eq1 ONLINE)			
	53 ther	1					
	54 55	EOP_FLAG -	TRUE:		! DECL!	ARE END OF PASS IF ALL UNITS	OFFLINE
: 58 : 58	56 CST 57 end:	[.CTLRO	FFSET. D_	STAT) - OFFLINE;	! MARK ! IF UN	UNIT OFFLINE NIT WAS STILL ALIVE	
	58 59 leave St	ARCH:			• FXTT	SEARCH BLOCK	
58	60 end;					NIT FOUND IN CST	
	61 62 end;						
58	63						
: 58 : 58 : 58	64 if .PRINT or 65 (.DUR [.UNIT] eq 66 (.DUR [.UNIT] eq 67 (.DUR [.UNIT] eq 68 (.DUR [.UNIT] eq	L DU_INIT) L DU_ONLINE	or ) or		! IF O	C TO PRINT MESSAGE	
: 58	69 (.DUR [.UNIT] eq	DU_PROTEC	(T)				
	70 then 71 begin						
: 58 : 58 : 58	72 PRÎNTF (DU_MSG. 73 PRÎNTF (.DU_RSN 74 end;	.UNIT); [.DUR [.UN	(ITI);		! "UNII	T XX DROPPED - "	
	75 76 ENDDU;						
000000 0041	37 000000G	LDU:	.SBTTL JSR	LDU DROP UNIT SECTION R1. \$SAVES			5700
000004 0246	46	LUU.	CMP	-(SP),-(SP)		•	5798
000006 1050			CLRB	R4		: PRINT	
000012 0327			MOV	RO,R3 #1,SWP.FLAGS		: INPUT,UNIT	5820 5823
00020 0014	11		BEQ	1\$			3023
000022 0103	46 000000G		MOV	R3,-(SP)		: UNIT, 4	5825
	46 000002		MOV	#DBM5,-(SP) #2,-(SP)			
000034 0106	00		MOV	SP,RO		; SP.*	
000036 1044	17 06 000006		TRAP	17			
000040 0627 000044 0050	05	18:	ADD CLR	96.SP R5		· CTI B	5830
000046 0105 000050 0127	46	28:	MOV	R5,-(SP)		: CTLR : CTLR.*	5834
00050 0127	46 000037 37 000000G		MOV	#37,-(SP)			
000060 0100	66 000006		JSR MOV	PC,BL#MUL RO,6(SP)			
000064 0127	01 000003		MOV	#3,R1		: 4.OFFSET	5832
000030 0127 000034 0106 000036 1044 000040 0627 000044 0050 000050 0127 000054 0047 000060 0100 000064 0127 000072 0666 000072 0666	00 000006	34:	MOV	#3,R1 R1,R0		: *.OFFSET : OFFSET.*	5834
000076 0061	00 000006 00		ADD ASL	6(SP),RO RO			
100100 010	66 COOOOOG OOOOO4		MOV	OCST,4(SP)			
000100 0127			ADD	RO,4(SP)			
000100 0127 000106 0600 000112 0103	66 000004		MOV	R3,R2		: UNIT	

						C14		
ZRQAM2 VO1.2		RD/RX EX	KERCISER IT SECTION			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.E	SEQ 0171 Page 171 BL1:82 (44)
000130	000200				CHAD			
000120	000300 042700	177760			SWAB	RO #177760.RO		
000126	020002	111100			CMP	RO.R2		
000126 000130	001060				BNE	95		
000132	032776	040000	000004		BIT	#40000,84(SP)		5835
000140	001454				BEQ	9\$		
000142	005002				CLR	R2		5839
000144	032776	020000	000004		BIT	#20000,84(SP)		
000152 000154 000156 000160	001402				BEQ	45		
000154	005202 000410				INC BR	R2		
000150	126327	000000G	000007	41:	CMPB	DUR(R3), #7	; *(UNIT),*	5840
000166	001404	000000	000001		BEQ	5.	, -(014217,-	3040
000170	126327	000000G	000011		CMPB	DUR(R3), #11	; *(UNIT),*	5841
000170 000176	001033				BNE	8\$		
000200	112704	000001		5\$:	MOVB	01.R4	: *.PRINT	5844
000204	010516	000076			MOV	R5.(SP)	; CTLR.*	5846
000206	012746	000076			MOV	476,-(SP)		
000200 000204 000206 000212 000216	004737	000000G			JSR TST	PC.BL\$MUL (SP)+		
000216 000220 000224 000230 000232 000234 000240 000250 000250 000252 000260 000270	062700	000004G			ADD	OCST+4.RO		
000224	105760	000001			TSTB	1(RO)		
000230	001404				BEQ	61		
000232	006002				ROR	R2		5847
000234	001404 006002 105660 001007	000001			SBCB	1(RO)		5849
000240	001007		*****		BNE	76		5851
000242	032776	020000	000004	6\$:	BIT	#20000,84(SP)		5852
000252	001403 112737	000001	000000G		BEQ MOVB	7\$ #1,EOP.FLAG		5854
000260	042776	020000	000004	78:	BIC	#20000,84(SP)		5856
000266	022626		••••	81:	CMP	(SP)+,(SP)+		5837
000270	022626				BR	10\$		
AAAEIE	062701	000007		98:	ADD	#7.R1	: *.OFFSET	5832
000276	020127	000030			CMP	R1,#30	: OFFSET.*	
000302 000304	003672				BLE	34		
000304	022626				INC	(SP)+,(SP)+ R5	. CTI D	5830
000306 000310	005205 000243					CLVICLC	; CTLR	3630
000312	003655				BLE	21		
000314	006004			104:	ROR	R4	; PRINT	5864
000316	103424				BLO	116	• • • • • • • • • • • • • • • • • • • •	-
000320	126327	000000G	000001		CMPB	DUR(R3), #1	; *(UNIT),*	5865
000326	001420				BEQ	116		
000330	126327	000000G	000002		CMPB	DUR(R3),#2	; *(UNIT),*	5866
000320 000326 000330 000336 000340	001414	0000000	000007		BEQ	114		5043
000346	126327 001410	000000G	000007		CMPB	DUR(R3), #7	; *(UNIT),*	5867
000350	126327	000000G	000013		BEQ CMPB	11\$ DUR(R3),#13	: *(UNIT),*	5868
000350 000356	126327 001404	000000	000013		BEQ	11#	1 -(01417)-	3000
000360	126327	000000G	000011		CMPB	DUR(R3),#11	; *(UNIT),*	5869
000366	001023				BNE	124		
000370	010346			11\$:	MOV	R3,-(SP)	; UNIT, *	5872

	ZRQAM2 VO1.2	RD/RX EXERCISER DROP UNIT SECTION		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 PS DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (	ge 172
	000372 012746 000376 012746 000402 010600 000404 104417	000002	MOV MOV TRAP	#DU.MSG(SP) #2(SP) SP.RO 17	; SP.4	
	000406 005000 000410 156300 000414 006300		CLR BISB ASL	RO DUR(R3),RO RO	: *(UNIT),*	5873
	000416 016016 000422 012746 000426 010600 000430 104417	000000G 000001	MOV MOV TRAP	DU.RSN(RO),(SP) #1,-(SP) SP,RO 17	; SP.4	
	000432 062706 000436 022626 000440 000207	000010	ADD CMP RTS	#10.SP (SP)+.(SP)+ PC	:	5871 5798
-	: Routine Size: : Maximum stack	145 words. Routine Base: 4 depth per invocation: 14 words	CODE: .	4362		
-	000000 004737 000004 104453 000006 000207	004362' L\$DU::	.SBTTL JSR TRAP RTS	L\$DU DROP UNIT SECTION PC.LDU 53 PC	•	5874
	: Routine Size:	A words Poutine Reser t	CODE .	5024		

<sup>:</sup> Routine Size: 4 words. Routine Base: \$CODE\$ + 5024 : Meximum stack depth per invocation: 2 words

```
SEQ 0173
                                                                                             VAX-11 Bliss-16 V3-555 Page 173
DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (45)
ZRQAM2
                RD/RX EXERCISER
                                                                    5-Dec-1983 10:27:14
                 ADD UNIT SECTION
                                                                    5-Dec-1983 10:27:04
V01.2
          5877 #sbttl 'ADD UNIT SECTION'
          5878
          5879
          5880
                ! THE ADD-UNIT SECTION CONTAINS ANY CODE THE PROGRAMMER WISHES
          5881
                ! TO BE EXECUTED IN CONJUNCTION WITH THE ADDING OF A UNIT BACK
          5882
                ! TO THE TEST CYCLE.
          5883
          5884
          5885
                BGNAU:
          5886
          5887
                 local
          5888
                     STINDX : word,
          5889
                     ENDIDX : word:
:
          5890
          5891
                register
                    UNIT - 0:
          5892
                                                                   ! UNIT NUMBER APPEARS IN RO UPON ENTRY
:
          5893
:
          5894
                 if (.SWP_FLAGS and SWF_CST) eq1 SWF_CST
          5895
                 then
          5896
                                                                   ! IF CLEAR STAT. TABLES TRUE....
                     begin
:
          5897
                     STINDX = .UNIT + TALLY_LEN;
                                                                   ! ZERO OUT
.
          5898
                     ENDIDX = .STINDX + TALLY_LEN - 1:
                                                                         ADDED
:
          5899
          5900
                     incr COUNT from .STINDX to .ENDIDX do
                                                                         UNIT'S
                         TALLY [.COUNT] - 0;
          5901
                                                                         STATISTICS
          5902
.
          5903
                     end;
.
          5904
:
          5905
                ENDAU:
.
                                                   . SBTTL
                                                           LAU ADD UNIT SECTION
000000
       004137
                                          LAU:
                000000G
                                                   JSR
                                                           R1, $SAVE2
                                                                                                                                        5876
000004
        105737
                000000G
                                                   TSTB
                                                           SWP.FLAGS
                                                                                                                                        5894
000010
        100023
                                                   BPL
                                                           3$
000012
                                                           RC.-(SP)
       010046
                                                   MOV
                                                                                             : UNIT. .
                                                                                                                                        5897
000014
        012746
                 000034
                                                           434, -(SP)
                                                   MOV
000020
        004737
                 000000G
                                                   JSR
                                                           PC.BL #MUL
000024
        010002
                                                   MOV
                                                           RO,R2
                                                                                             ; STINDX, ENDIDX
                                                                                                                                        5898
000026
                                                                                             : *.ENDIDX
        062702
                 000033
                                                   ADD
                                                           #33.R2
000032
        010001
                                                                                             : STINDX, COUNT
                                                   MOV
                                                           RO.R1
                                                                                                                                        5900
000034
        005301
                                                   DEC
                                                           R1
                                                                                             : COUNT
000036
        000404
                                                           21
000040
        010100
                                                   MOV
                                                           R1.RO
                                                                                                                                        5901
                                          18:
                                                                                             ; COUNT, 4
000042 006300
                                                   ASL
000044
        005060
                 000000G
                                                           TALLY(RO)
000050
        005201
                                          21:
                                                           R1
                                                                                             : COUNT
                                                                                                                                        5900
000052
        020102
                                                           R1.R2
                                                                                             : COUNT.ENDIDX
000054
        003771
                                                   BLE
000056
                                                           (SP)+,(SP)+
        022626
                                                                                                                                        5896
000060
        000207
                                          31:
                                                   RTS
                                                                                                                                        5876
                                                                                             :
; Routine Size: 25 words,
                                  Routine Base: $CODE$ + 5034
```

F14

ZRQAM2 V01.2

RD/RX EXERCISER ADD UNIT SECTION 5-Dec-1983 10:27:14 5-Dec-1983 10:27:04

SEQ 0174 VAX-11 Bliss-16 V3-555 Page 174 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (45)

: Maximum stack depth per invocation: 6 words

000000 004737 0050341 000004 104452 000006 000207

L\$AU:: JSR PC.LAU
TRAP 52
RTS PC

: Routine Size: 4 words. Routine Base: : Maximum stack depth per invocation: 2 words Routine Base: \$CODE\$ + 5116

5903

ZRQAM2 V01.2		RD/RX EXERCISER NON-EXISTENT MEMORY TR	AP HANDLER		10:27:14 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQA	SEQ 0175 Page 175 ACO.BL1;82 (46)				
	5906 5907 5908 5909 5910 5911 5912 5913	THIS TRAP HAND ERRORS, INDICA MEMORY LOCATIO	THIS TRAP HANDLER IS VECTORED FROM LOCATION 4 FOR ALL UNIBUS TIMEOUT ERRORS, INDICATING THAT AN ATTEMPT WAS MADE TO REFERENCE A NON-EXISTENT MEMORY LOCATION. ITS MAIN PURPOSE IS TO SET A FLAG FOR THE RDRX REGISTER EXISTENCE TEST, INDICATING THE ABSENCE OF A DEVICE REGISTER.								
	5914 5915 5916 5917 5918 5919	BGNSRV (NEX_TRAP); NEX = TRUE; ENDSRV;		! NEX TRAP	OCCURRED						
	012737	000001 000000G	NEX.TRAP::	NEX.TRAP NON-EXISTER	NT MEMORY TO	RAP HANDLER	5917 5915				
		4 words. Routing depth per invocation:	e Base: \$CODE\$ +	5126							

```
SEQ 0176
ZRQAM2
                  RD/RX EXERCISER
                                                                           5-Dec-1983 10:27:14 VAX-11 Bliss-16 V3-555
5-Dec-1983 10:27:04 DISK$USER2:[DIETZ.RDRX]
                                                                                                                                                Page 176
V01.2
                  GLOBAL ROUTINES
                                                                                                      DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (47)
           5920 #sbttl 'GLOBAL ROUTINES'
           5921
           5922 global routine SET_CPAR (CTLR) : novalue =
            5923
           5924 !+
            5925 !
                            THIS ROUTINE SETS UP THE COMMONLY-USED CONTROLLER-RELATED DATA ITEMS
            5926
                            FOR THE GIVEN CONTROLLER NUMBER.
            5927
                            INPUTS:
           5928
                                     CTLR - CONTROLLER NUMBER
           5929
:
           5930
:
                           IMPLICIT OUTPUTS:
            5931
:
                                     CCTLR - CURRENT CONTROLLER NUMBER
            5932
:
                                     CST_ADDR - ADDRESS OF CONTROLLER'S STATUS TABLE DCT_ADDR - ADDRESS OF CONTROLLER'S DRIVER TABLE
            5933
:
            5934
:
            5935
                                     RDRX_ADDR - ADDRESS OF CONTROLLER'S IP REGISTER
:
            5936 !-
:
            5937
.
                       begin

CCTLR = .CTLR;

CST_ADDR = CST + (.CTLR + CST_LEN + 2);

DCT_ADDR = DCT + (.CTLR + DCT_LEN + 2);
            5938
:
            5939
                                                                          ! SET CURRENT CONTROLLER NUMBER
:
            5940
                                                                       ! CALCULATE ADDRESS OF CONTROLLER'S CST
! CALCULATE ADDRESS OF CONTROLLER'S DCT
:
            5941
.
           5942
                       RDRX_ADDR = .CST_ADDR [IP_ADDR];
                                                                        ! GET CONTROLLER'S DEVICE ADDRESS
.
           5943
.
                       end:
                                                        .SBTTL SET.CPAR GLOBAL ROUTINES
000000 010146
                                              SET.CPAR::
                                                                 R1.-(SP)
                                                                                                                                                     5922
000002
         016601
                                                                 4(SP),R1
                                                                                                      : CTLR.+
                  000004
                                                        MOV
                                                                                                                                                     5939
000006
         010137
                  000000G
                                                        MOV
                                                                 R1.CCTLR
000012
         010146
                                                        MOV
                                                                 R1.-(SP)
                                                                                                                                                     5940
                                                                                                      :
000014
         012746
                  000076
                                                                 476, -(SP)
                                                        MOV
000020
         004737
                  000000G
                                                        JSR
                                                                 PC, BL $MUL
000024
         062700
                  000000G
                                                        ADD
                                                                 OCST.RO
000030
         010037
                  000000G
                                                        MOV
                                                                 RO, CST. ADDR
000034
000036
         010116
                                                                 R1,(SP)
                                                                                                                                                     5941
                                                                                                      :
         012746
                  000022
                                                                 #22,-(SP)
                                                        MOV
000042 004737
000046 062700
                  000000G
                                                        JSR
                                                                 PC.BL #MUL
                  000000G
                                                        ADD
                                                                 OCT, RO
000052
         010037
                  000000G
                                                        MOV
                                                                 RO.DCT.ADDR
000056
         017737
                  000000G 000000G
                                                        MOV
                                                                 SCST. ADDR, RDRX, ADDR
                                                                                                                                                     5942
                                                                                                      :
000064
         062706
                  000006
                                                                 46, SP
                                                        ADD
                                                                                                                                                     5938
                                                                                                      :
000070
         012601
                                                        MOV
                                                                 (SP)+,R1
                                                                                                                                                     5922
000072 000207
; Routine Size: 30 words,
                                     Routine Base: #CODE# + 5136
```

: Maximum stack depth per invocation: 5 words

```
SEQ 0177
ZRQAM2
                 RD/RX EXERCISER
                                                                      5-Dec-1983 10:27:14 VAX-11 Bliss-16 V3-555 Page 1
5-Dec-1983 10:27:04 DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (48)
                                                                                                                                       Page 177
V01.2
                 GLOBAL ROUTINES
           5944 global routine SET_UPAR (OFFSET) : novalue =
           5945
           5946
           5947
                          THIS ROUTINE SETS UP THE COMMONLY-USED UNIT-RELATED DATA ITEMS FOR
.
           5948
                          THE CURRENT CONTROLLER AND GIVEN CST OFFSET.
.
           5949
:
           5950
                          INPUTS:
                                  OFFSET - WORD OFFSET INTO CURRENT CONTROLLER'S CST WHICH
           5951
           5952
                                                    DESCRIBES A UNIT
           5953
:
                          IMPLICIT INPUTS:
           5954
:
           5955
                                  CST_ADDR - ADDRESS OF CURRENT CONTROLLER'S CST
:
           5956
:
           5957
                          IMPLICIT OUTPUTS:
:
           5958
                                   CUOFF - CURRENT UNIT'S CST OFFSET
           5959
                                   CDISK - CURRENT DISK ADDRESS (RD/RX DISK NUMBER)
           5960
                                  L$LUN - CURRENT UNIT NUMBER (DRS UNIT NUMBER)
:
                                   T_ADDR - ADDRESS OF CURRENT UNIT'S STATISTICS BLOCK (TALLY)
           5961
:
           5962 !-
:
           5963
:
           5964
                     begin
CUOFF = .OFFSET;
           5965
                     CDISK = .CST_ADDR [.OFFSET, D_DISK_NUM];
L*LUN = .CST_ADDR [.OFFSET, D_UNIT];
           5966
.
           5967
.
           5968
                      T_ADDR = TALLY + (.L$LUN + TALLY_LEN + 2);
.
           5969
                      end:
                                                     .SBTTL SET. UPAR GLOBAL ROUTINES
000000 010146
                                            SET. UPAR::
                                                             R1.-(SP)
                                                    MOV
                                                                                                                                            5944
000002
                                                             4(SP),CUOFF
4(SP),RO
        016637
                 000004 000000G
                                                                                                : OFFSET. *
                                                    MOV
                                                                                                                                            5965
000010
        016600
                 000004
                                                    MOV
                                                                                                : CUOFF. 4
                                                                                                                                            5966
000014
        006300
                                                    ASL
                                                             RO
000016
        063700
                 000000G
                                                             CST. ADDR. RO
                                                    ADD
000022
        111037
                 000000G
                                                    MOVB
                                                             (RO), CDISK
000026
        042737
                 177774 000000G
                                                             4177774, CDISK
                                                    BIC
000034
        011001
                                                    MOV
                                                             (RO),R1
                                                                                                                                            5967
000036
        000301
                                                    SMAB
                                                             R1
000040
        042701
                 177760
                                                             #177760.R1
                                                    BIC
000044
        010137
                 000000G
                                                    MOV
                                                             R1,L$LUN
000050
        010146
                                                             R1,-(SP)
                                                    MOV
                                                                                                : L$LUN. *
                                                                                                                                            5968
000052
        012746
                                                    MOV
                                                             #70,-(SP)
000056
        004737
                 000000G
                                                     JSR
                                                             PC, BL #MUL
000062
        062700
                 000000G
                                                             #TALLY, RO
                                                    ADD
000066
        010037
                 000000G
                                                             RO,T.ADDR
(SP)+,(SP)+
                                                    MOV
000072 022626
                                                    CMP
                                                                                                                                            5964
000074 012601
                                                    MOV
                                                             (SP)+,R1
                                                                                                                                            5944
                                                                                                :
000076 000207
; Routine Size: 32 words,
                                  Routine Base: #CODE# + 5232
; Maximum stack depth per invocation: 4 words
```

SEQ 0178

```
ZRQAM2
                  RD/RX EXERCISER
                                                                         5-Dec-1983 10:27:14
                                                                                                  VAX-11 Bliss-16 V3-555
V01.2
                  GLOBAL ROUTINES
                                                                                                  DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (49)
                                                                         5-Dec-1983 10:27:04
           5971
           5972 global routine GET_PKT (CTLR) =
:
           5973
           5974 !+
           5975 !
                           THIS ROUTINE SEARCHES THE MSCP PACKET POOL ALLOCATION TABLE (PKT_USE)
                           FOR A FREE MSCP PACKET TO ALLOCATE TO THE GIVEN CONTROLLER. IF ONE IS
           5976
           5977
                           FOUND, THE PACKET IS ZEROED OUT, AND THE PACKET INDEX IS RETURNED
:
           5978
                           TO THE CALLER. OTHERWISE, A -1 IS RETURNED INDICATING NONE AVAILABLE.
.
           5979
:
                           INPUTS:
           5980
:
           5981
                                   CTLR - CONTROLLER NUMBER REQUESTING ALLOCATION
:
           5982
.
           5983
           5984
                      begin
:
           5985
:
           5986
                      local
:
           5987
                           index : signed word initial (-1),
:
           5988
                           RING_ADDR : word.
:
           5989
                           PACKET_OWNED : byte.
.
           5990
                           NEW_PKT : byte:
           5991
.
           5992
                      NEW_PKT = .NXT_PKT_2USE:
:
                                                             ! NEXT PACKET TO TRY
           5993
:
           5994
5995
                      incr COUNT from 0 to (PKT_CNT - 1) do
:
                                                                     ! FOR EACH ENTRY IN ALLOCATION TABLE
                          begin
PACKET_OWNED = FALSE;
:
           5996
.
           5997
.
           5998
                           IF .PKT_USE [.NEW_PKT] les 0 ! IF ENTRY INDICATES FREE PACKET
.
           5999
:
                           then
           6000
.
           6001
                               RING_ADDR = .DCT_ADDR [RR_BEG]; ! FIRST RESPONSE PACKET'S ADDRESS
           6002
.
                               incr I from 1 to (RRING_LEN + CRING_LEN) do ! FOR EACH PACKET ADDRESS if (..RING_ADDR eqla .MSCP_PKT [.NEW_PKT, PKT_LO]) and (((.RING_ADDR + 2) and ED_OWN) eql ED_OWN)
           6003
.
           6004
:
           6005
:
           6006
:
                                    then
           6007
:
                                        begin
PACKET_OWNED = TRUE;
                                                                       ! CHECK ADDRESS AND OWNERSHIP
           6008
.
                                                                       ! PACKET OWNED BY CONTROLLER
           6009
                                        exitloop;
           6010
:
                                        end
           6011
:
           6012
                                        RING_ADDR = .RING_ADDR + 4; ! ADDRESS OF NEXT PACKET IN RING
           6013
:
           6014
                               if not .PACKET_OWNED
.
                                                                       ! IF NOT ALREADY USED
           6015
.
                               then
           6016
                                   PKT_USE [ .NEW_PKT] = .CTLR; ! ALLOCATE PACKET TO CONTROLLER
:
           6017
:
           6018
           6019
:
                                    incr J from 2 to (PKT_LEN - 1) do ! 2
MSCP_PKT [.NEW_PKT, .J, 0, 16, 0] = 0;
           6020
:
                                                                               ! ZERO OUT PACKET
           6021
.
           6022
;
           6023
                                   exitloop;
                                                                        ! DONE
```

```
SEQ 0179
ZRQAM2
                  RD/RX EXERCISER
                                                                         5-Dec-1983 10:27:14
                                                                                                    VAX-11 Bliss-16 V3-555
                                                                                                                                            Page 179
V01.2
                  GLOBAL ROUTINES
                                                                                                   DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (49)
                                                                         5-Dec-1983 10:27:04
           6024
                                    end:
           6025
:
           6026
                               end:
           6027
           6028
                           NEW_PKT = .NEW_PKT + 1:
                                                            ! TRY NEXT PACKET IN RING
           6029
           6030
                           if .NEW_PKT gegu PKT_CNT
           6031
                           then
:
                               NEW PKT = 0:
           6032
                                                                      ! IF BEYOND ALL PACKETS, START AT THE TOP
.
           6033
:
           6034
                           end:
:
           6035
:
                       if (.index geq 0) and
(.PKT_USE [.index] geq 0)
           6036
                                                                     ! IF PACKET FOUND
:
           6037
           6038
.
                          begin
MSCP_PKT [.index, MSGLEN] = SZ_GEN; ! PACKET SIZE - OF
MSCP_PKT [.index, CREDITS] = 1; ! CREDIT SIZE
NXT_PKT_2USE = .NEW_PKT + 1; ! NEXT PACKET TO ALLOCATE
           6039
.
           6040
                                                                        ! PACKET SIZE - ONLY ONLINE AND SCC CHANGE IT
:
           6041
:
           6042
:
           6043
:
           6044
                           if.NXT_PKT_2USE gegu PKT_CNT
.
           6045
                           then
.
           6046
                               NXT_PKT_2USE = 0:
                                                                      ! CYCLE BACK TO BEGINNING IF AT END
.
           6047
.
           6048
:
                           end:
           6049
:
           6050
                       return . index:
.
           6051
                       end:
.
                                                       .SBTTL GET.PKT GLOBAL ROUTINES
000000 004137 000000G
                                             GET.PKT::
                                                               R1, $SAVES
                                                                                                                                                  5972
                                                                                                    :
000004
         162706
                  000006
                                                       SUB
                                                               46.SP
000010
         012704
                  177777
                                                       MOV
                                                               4-1.R4
                                                                                                    : *.INDEX
                                                                                                                                                  5984
000014
         113705
                  000000G
                                                      MOVB
                                                               NXT.PKT.2USE.R5
                                                                                                    : *, NEW. PKT
                                                                                                                                                  5992
000020
         012766
                  000014 000004
                                                       MOV
                                                               #14,4(SP)
                                                                                                    : *, COUNT
                                                                                                                                                  5994
000026
000032
         105066
                  000002
                                                               2(SP)
                                                                                                    : PACKET. OWNED
                                                       CLRB
                                                                                                                                                  5996
         005003
                                                       CLR
                                                                R3
                                                                                                                                                  5998
000034
         150503
                                                       BISB
                                                               R5.R3
                                                                                                    : NEW.PKT. .
000036
        105763
                  000000G
                                                               PKT.USE(R3)
                                                       TSTB
000042 002076
                                                       BGE
000044 013700
                  000000G
                                                       MOV
                                                               DCT.ADDR.RO
                                                                                                                                                  6001
000050
        016016
                  000004
                                                       MOV
                                                               4(RO),(SP)
                                                                                                    : *,RING.ADDR
000054
         010346
                                                       MOV
                                                               R3,-(SP)
                                                                                                                                                  6004
000056
000062
         012746
                  000104
                                                       MOV
                                                               #104, -(SP)
         004737
                  000000G
                                                       JSR
                                                               PC.BL #MUL
000066
         012702
                  000010
                                                       MOV
                                                               #10,R2
                                                                                                                                                  6003
                                                      CMP
BNE
MOV
000072
         027660
                  000004
                           000000G
                                             21:
                                                                84(SP), MSCP. PKT(RO)
                                                                                                    : RING. ADDR. .
                                                                                                                                                  6004
000100
         001016
                                                                3$
                                                               #2,-(SP)
6(SP),(SP)
000102 012746
                  000002
                                                                                                                                                  6005
000106
         066616
                  000006
                                                       ADD
                                                                                                    : RING. ADDR. .
000112 012601
                                                       MOV
                                                                (SP)+,R1
```

ZRQAM2 V01.2		RD/RX EX	XERCISER ROUTINES			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.B	SEQ 0180 Page 180 L1;82 (49)
000114	042701	077777			DTC			
000114	020127	077777			BIC	#77777,R1 R1,#-100000		
000124	001004	100000			BNE	3\$		
000126	112766	000001	000006		MOVB	#1,6(SP)	: *,PACKET.OWNED	6008
000134	000405				BR	4\$	, TITACKET, OWNED	6007
000136	062766	000004	000004	3\$:	ADD	44.4(SP)	. *,RING.ADDR	6012
000144	005302			• • • • • • • • • • • • • • • • • • • •	DEC	R2	· T	6003
000146	001351				BNE	21		0003
000146 000150	032766	000001	000006	4\$:	BIT	#1.6(SP)	; *,PACKET.OWNED	6014
000156	001027				BNE	6\$		0021
000160	116663	000030	00000G		MOVB	30(SP),PKT.USE(R3)	; CTLR,*	6017
000166	010304				MOV	R3.R4	; *, INDEX	6018
000170	010316				MOV	R3,(SP)		6021
000172	012746	000042			MOV	#42,-(SP) PC,BL\$MUL		
000176 000202	004737	000000G			JSR	PC,BL\$MUL		
000202	005726				TST	(SP)+ #2,R1		
000204	012701	000002			MOV	#2.R1	; *,J	6020
000210	010003			54:	MOV	RO.R3	1	6021
000212	060103				ADD	R1.R3	; J,*	
000214	006303				ASL	R3		
000216	005063	000000G			CLR	MSCP.PKT(R3)		
000216 000222 000224	005201	000000			INC	R1	; J,*	6020
000224	020127 003767	000041			CMP	R1.041	; J,*	
000230	003/6/				BLE	54		
000232	022626				CMP	(SP)+,(SP)+		6016
000230 000232 000234 000236 000240	000411				BR	9\$		
000236	022626			6\$:	CMP	(SP)+,(SP)+	1 11711 7117	6000
000240	105205	000014		7\$:	INCB	R5	: NEW.PKT	6028
000242 000246	120527 103401	000014			CMPB	R5.#14	; NEW.PKT,*	6030
000250	105005				BLO CLRB	8	NEU DUT	6070
000250 000252	005366	000004		8\$:	DEC	4(SP)	: NEW.PKT : COUNT	6032
000256	001263	000004		0*:	BNE	16	; COONT	5994
000260	005704			9\$:	TST	Ř4	: INDEX	6036
000262	005704 002434			74.	BLT	11#	: INDEX	6036
000264	105764	000000G			TSTB	PKT.USE(R4)	; *(INDEX)	6037
000270	002431				BLT	11#	, -(11000)	0037
000272	010446				MOV	R4,-(SP)	; INDEX.*	6040
000274	012746	000104			MOV	#104,-(SP)	, THOUNTY	0040
000300 000304 000312	004737	000000G			JSR	PC,BL \$MUL		
000304	012760	000040	000006G		MOV	#40, MSCP. PKT+6(RO)		
000312	142760	000017	000010G		BICB	#17,MSCP.PKT+10(RO)		6041
000320 000326 000330	012760 142760 152760	000001	000010G		BISB	#1,MSCP.PKT+10(RO)		0012
000326	005000	400000000000000000000000000000000000000			CLR	RO		6042
000330	150500				BISB	R5,R0	: NEW.PKT.*	
000332	150500 005200				INC	RO		
000334 000340	110037 120027	000000G			MOVB	RO, NXT, PKT, 2USE		
000340	120027	000014			CMPB	RO, #14	; NXT.PKT.2USE.*	6044
000344	103402				BLO	10#		
000346	105037	000000G			CLRB	NXT.PKT.2USE		6046
000352	022626			10\$:	CMP	(SP)+,(SP)+		6039
000354	010400			114:	MOV	R4,R0	; INDEX.*	5984
000356	062706	000006			ADD	#6.SP		5972

M14

ZRQAM2 V01.2

RD/RX EXERCISER GLOBAL ROUTINES

5-Dec-1983 10:27:14 5-Dec-1983 10:27:04

VAX-11 Bliss-16 V3-555 Page 181 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (49)

SEQ 0181

000362 000207

RTS PC

: Routine Size: 122 words, Routine Base: \$CODE\$ + 5332 : Maximum stack depth per invocation: 13 words

6052

```
SEQ 0182
ZRQAM2
                RD/RX EXERCISER
                                                                  5-Dec-1983 10:27:14
                                                                                        VAX-11 Bliss-16 V3-555
                                                                                                                             Page 182
V01.2
                GLOBAL ROUTINES
                                                                  5-Dec-1983 10:27:04
                                                                                         DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (50)
          6053 global routine PUT:PKT (index) : novalue =
          6054
:
          6055 !+
:
          6056
                        THE MSCP PACKET DESIGNATED BY "INDEX" IS RETURNED TO THE POOL BY THIS
                .
          6057
                .
                        ROUTINE.
          6058
                ! -
          6059
          6060
                    begin
          6061
          6062
                    local
                        RING ADDR : word.
          6063
          6064
                        OWNER : word:
          6065
          6066
                    RING_ADDR = .DCT_ADDR [RR_BEG]:
                                                                      ! ADDRESS IN FIRST RESPONSE RING
          6067
                    incr COUNT from 1 to (RRING_LEN + CRING_LEN) do
          6068
                                                                      ! FOR EACH ADDRESS IN THE RINGS
.
          6069
          6070
          6071
                        if .MSCP_PKT [.index, PKT_LO] eqla ..RING_ADDR ! IF ADDRESS MATCHES
          6072
                        then
          6073
                            DWNER = .RING_ADDR + 2;
          6074
                                                                         ! ADDRESS OF OWNERSHIP WORD
                            .OWNER = .. OWNER and (not (ED_OWN)) and (not (ED_FLAG)) ; ! GIVE OWNERSHIP TO HOST
          6075
          6076
:
          6077
          6078
                        RING_ADDR = .RING_ADDR + 4;
                                                           ! LOOK AT NEXT PACKET ADDRESS IN RING
          6079
                        end:
:
          6080
.
          6081
                    PKT_USE [.index] = -1:
:
          6082
                    end:
                                                 .SBTTL PUT.PKT GLOBAL ROUTINES
000000 004137 000000G
                                        PUT.PKT::
                                                 JSR
                                                         R1, $SAVE4
                                                                                                                                  6053
000004 013700
                000000G
                                                MOV
                                                        DCT. ADDR, RO
                                                                                                                                  6066
000010
        016003
                000004
                                                MOV
                                                         4(RO),R3
                                                                                         : *,RING.ADDR
000014
        016601
                000014
                                                MOV
                                                         14(SP).R1
                                                                                         ; INDEX. *
                                                                                                                                  6071
000020
        010146
                                                MOV
                                                         R1.-(SP)
000022
        012746
                000104
                                                MOV
                                                         #104,-(SP)
000026
        004737
                000000G
                                                 JSR
                                                        PC.BL $MUL
000032
        012702
                000010
                                                 MOV
                                                         #10,R2
                                                                                         : *, COUNT
                                                                                                                                  6068
000036
        026013
                000000G
                                                         MSCP.PKT(RO),(R3)
                                        1$:
                                                 CMP
                                                                                         : *,RING.ADDR
                                                                                                                                  6071
000042
        001005
                                                BNE
                                                         2$
000044
        012704
                000002
                                                MOV
                                                         42.R4
                                                                                         : *.OWNER
                                                                                                                                  6074
000050
        060304
                                                 ADD
                                                        R3, R4
                                                                                         ; RING. ADDR. OWNER
000052
        042714
                140000
                                                 BIC
                                                         #140000,(R4)
                                                                                         : *, OWNER
                                                                                                                                  6075
000056
        062703
                000004
                                        24:
                                                 ADD
                                                         44.R3
                                                                                         : *,RING.ADDR
                                                                                                                                  6078
000062
        005302
                                                 DEC
                                                         R2
                                                                                         : COUNT
                                                                                                                                  6068
000064
        001364
                                                 BNE
000066
                000377 000000G
        112761
                                                MOVB
                                                         #377,PKT.USE(R1)
                                                                                                                                  6081
000074
        022626
                                                CMP
                                                         (SP)+,(SP)+
                                                                                                                                  6060
000076
        000207
                                                RTS
                                                                                                                                  6053
```

ZRQAM2 V01.2

RD/RX EXERCISER GLOBAL ROUTINES

5-Dec-1983 10:27:14 5-Dec-1983 10:27:04

: Routine Size: 32 words. Routine Base: \$CODE\$ - 5716 : Maximum stack depth per invocation: 8 words

				013		
ZRQAM2 VO1.2		RD/RX EXERCISER GLOBAL ROUTINES		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.B	SEQ 0184 Page 184 E1;82 (51)
	6083 6084 6085 6086 6087 6088 6089 6090 6091	THIS ROUTINE DEALLOCATO A PARTICULAR CONTROL  INPUTS:  CTLR - CONTROL	TES ALL MSCP PACI DLLER.	KETS WHICH HAVE BEEN ALLO	CATED	
	6093 6094 6095 6096 6097	incr COUNT from 0 to (PKT)  if .PKT_USE [.COUNT] of then  PKT_USE [.COUNT]	eql .CTLR			
000004 000010 000014 000016 000024 000026 000032 000034	010146 005000 116001 020166 001003 112760 005200 020027 003764 012601 000207	000000G 000004 000377 000000G 000013	PKT: MOV R1,-(*) CLR R0 MOVB PKT.U CMP R1,4(*) BNE 2\$	SE(RO),R1 SP) PKT.USE(RO)	COUNT:  *(COUNT).*  **.CTLR  **.*(COUNT)  COUNT: COUNT.*	6083 6093 6095 6097 6093
: Routin	ne Size: um stack	16 words, Routine Base: depth per invocation: 2 word	\$CODE\$ • 6016			

```
SEQ 0185
ZRQAM2
                RD/RX EXERCISER
                                                                   5-Dec-1983 10:27:14
                                                                                           VAX-11 Bliss-16 V3-555 Page 185
DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (52)
                                                                                           VAX-11 Bliss-16 V3-555
V01.2
                GLOBAL ROUTINES
                                                                   5-Dec-1983 10:27:04
          6098 global routine GET_RETPKT (CTLR) =
          6099
:
          6100
               . .
:
          6101
               .
                        THIS ROUTINE SEARCHES THE RETURN PACKET POOL ALLOCATION TABLE (RP_USE)
:
          6102
                        FOR A FREE RETURN PACKET TO ALLOCATE TO THE GIVEN CONTROLLER. IF ONE IS
                        FOUND, THE PACKET IS ZEROED OUT, AND THE PACKET INDEX IS RETURNED TO
          6103
          6104
                        THE CALLER. OTHERWISE, A -1 IS RETURNED INDICATING NONE AVAILABLE.
          6105
                        INPUTS:
          6106
                                 CTLR - CONTROLLER NUMBER REQUESTING ALLOCATION
          6107
               .
          6108 !-
:
          6109
:
          6110
:
                    begin
          6111
          6112
:
                    local
          6113
                         index : signed word initial (-1);
:
                                                                 ! ASSUME NONE AVAILABLE
          6114
:
                    incr COUNT from 0 to (RP_CNT - 1) do
          6115
:
                                                                  ! FOR EACH ENTRY IN TABLE
          6116
:
          6117
                         if .RP_USE [.COUNT] lss 0
                                                                  ! IF FREE RETPKT IS FOUND
          6118
                        then
          6119
                            begin
.
          6120
                             RP_USE [.COUNT] = .CTLR:
.
                                                                  ! ALLOCATE RETURN PACKET TO CONTROLLER
          6121
                             index = .COUNT;
:
          6122
          6123
                             incr J from 0 to (RP_LEN - 1) do ! ZERO OUT RETPKT
          6124
                                 RETPKT [.COUNT, .J. 0, 16, 0] = 0;
          6125
:
          6126
:
                             exitloop:
                                                                  ! DONE
          6127
:
                             end;
          6128
          6129
:
                    return . index:
                                                                  ! RETURN PACKET INDEX (OR -1) TO CALLER
          6130
:
                    end:
                                                  .SBTTL GET.RETPKT GLOBAL ROUTINES
000000 004137 000000G
                                         GET.RETPKT::
                                                          R1. $SAVE4
                                                  JSR
                                                                                                                                     6098
000004 012704
                177777
                                                                                           : *, INDEX
                                                 MOV
                                                          0-1,R4
                                                                                                                                     6110
000010
       005003
                                                                                           : COUNT
                                                 CLR
                                                          R3
                                                                                                                                     6115
000012 105763
                000000G
                                                 TSTB
                                         18:
                                                          RP.USE(R3)
                                                                                           : *(COUNT)
                                                                                                                                     6117
000016
       002025
                                                 BGE
                                                          3$
000020 116663
                000014 000000G
                                                          14(SP), RP. USE(R3)
                                                 MOVB
                                                                                           : CTLR. *(COUNT)
                                                                                                                                    6120
000026 010304
                                                 MOV
                                                          R3,R4
                                                                                           ; COUNT, INDEX
                                                                                                                                    6121
000030 010346
                                                          R3,-(SP)
                                                  MOV
                                                                                           : COUNT. +
                                                                                                                                     6124
000032 012746
                000030
                                                 MOV
000036 004737
                000000G
                                                  JSR
                                                          PC.BL $MUL
000042 022626
                                                  CMP
                                                          (SP)+,(SP)+
000044
       005002
                                                  CLR
                                                                                           : 1
                                                                                                                                     6123
000046
       010001
                                         21:
                                                 MOV
                                                          RO.R1
                                                                                                                                     6124
000050
        060201
                                                  ADD
                                                          R2,R1
                                                                                           : J. 4
000052 006301
                                                  ASL
000054
       005061 000000G
                                                          RETPKT(R1)
                                                 CLR
```

ZRQAM2 VO1.2	RD/RX EXERCISER GLOBAL ROUTINES			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.8	SEQ 0186 Page 186 BL1;82 (52)
000060 005202 000062 020227 000066 003767	000027	INC CMP BLE	R2 R2,#27 2\$		; J.*	6123
000070 000404 000072 005203 000074 020327 000100 003744	000003	BR INC CMP BLE	4\$ R3 R3,#3		COUNT	6119 6115
000102 010400 000104 000207	4\$:	MOV RTS	R4.RO PC		: INDEX.*	6110 6098
; Routine Size: ; Maximum stack	35 words. Routine Base: depth per invocation: 8 words	*CODE* +	6056			

			113		
ZRQAM2 V01.2		RD/RX EXERCISER GLOBAL ROUTINES	5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;88	9 0187 Page 187 2 (53)
:	6132	global routine PUT_RETPKT (index) : nov	alue =		
	6133 6134 6135 6136 6137 6138	THE RETURN PACKET DESIGNATED BY ROUTINE.  RP_USE [.index] = -1;	"INDEX" IS RETURNED TO THE POOL	BY THIS	
000000	016600	.SBTTL PUT.RETPKT::	PUT.RETPKT GLOBAL ROUTINES		
000004	112760 000207	000377 000000G MOVB	2(SP),R0 #377,RP.USE(R0) PC	: INDEX.*	6138
: Routie	ne Size:	6 words. Routine Base: \$CODE\$ + depth per invocation: 0 words			6131

```
SEQ 0188
ZRQAM2
                RD/RX EXERCISER
                                                                   5-Dec-1983 10:27:14
                                                                                           DISK*USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (54)
                                                                                           VAX-11 Bliss-16 V3-555
V01.2
                GLOBAL ROUTINES
                                                                   5-Dec-1983 10:27:04
          6139 global routine GET_IO_BUFF (ADDR) : novalue =
          6140
:
          6141 !+
:
          6142
                         THIS ROUTINE HANDLES THE ALLOCATION OF AN I/O BUFFER FROM THE BUFFER
                .
:
          6143
                        POOL.
:
          6144
                         INPUTS:
          6145
          6146
                                 ADDR - ADDRESS TO STORE THE 2-WORD BUFFER DESCRIPTOR
          6147
:
                        IMPLICIT IMPUTS:
          6148
.
          6149
                                 CCTLR - CURRENT CONTROLLER NUMBER
.
          6150
:
                        OUTPUTS:
          6151
          6152
                                 THE ALLOCATED BUFFER'S DESCRIPTOR IS LOADED INTO THE TWO
          6153
                                 WORDS AT "ADDR" AND "ADDR + 2". OTHERWISE, A ZERO IS RETURNED
.
                                 AT "ADDR" IF NO BUFFERS ARE AVAILABLE.
          6154
.
          6155
:
          6156
:
          6157
                    begin
.ADDR = 0;
:
          6158
                                                                  ! ASSUME FAILURE
          6159
:
          6160
                     incr COUNT from 0 to (QIO_PER_CTLR + MAX_CTLR - 1) do ! FOR EACH ENTRY IN BUFFER TABLE
.
          6161
.
          6162
                         if .BUFF_OWN [.COUNT] les 0
                                                                  ! IF BUFFER IS FREE
          6163
:
                         then
                            begin
BUFF_OWN [.COUNT] = .CCTLR;
          6164
.
          6165
.
                                                                  ! ALLOCATE BUFFER TO CONTROLLER
                             .ADDR = .BUFF_ADDR [.COUNT];
          6166
.
                                                                  ! RETURN BUFFER DESCRIPTOR
:
          6167
                             exitloop:
                                                                  ! DONE
.
          6168
                             end:
:
          6169
          6170
:
                    end:
                                                               ! ROUTINE GET_IO_BUFF
                                                  .SBTTL GET.IO.BUFF GLOBAL ROUTINES
000000 010146
                                         GET. IO. BUFF ::
                                                 MOV
                                                          R1.-(SP)
                                                                                                                                     6139
000002 005076
                000004
                                                  CLR
                                                          84(SP)
                                                                                           : ADDR
                                                                                                                                     6158
000006
        005001
                                                  CLR
                                                                                           : COUNT
                                                                                                                                     6160
000010
        105761
                000000G
                                         18:
                                                  TSTB
                                                          BUFF. OWN(R1)
                                                                                           : *(COUNT)
                                                                                                                                     6162
000014
        002011
                                                  BGE
000016
        113761
                000000G 000000G
                                                  MOVB
                                                          CCTLR, BUFF. OWN(R1)
                                                                                           ; *, *(COUNT)
                                                                                                                                     6165
000024
        010100
                                                  MOV
                                                          R1,R0
                                                                                           : COUNT. *
                                                                                                                                     6166
000026
        006300
                                                  ASL
000030 016076
                000000G 000004
                                                          BUFF . ADDR(RO) . 84(SP)
                                                  MOV
                                                                                           : * . ADDR
000036
        000404
                                                                                                                                     6164
000040
        005201
                                         21:
                                                  INC
                                                          R1
                                                                                           : COUNT
                                                                                                                                     6160
000042
        020127
                000007
                                                  CMP
                                                          R1.47
                                                                                           : COUNT. *
000046
        003760
000050
        012601
                                                          (SP)+,R1
                                         34:
                                                  MOV
                                                                                                                                     6139
000052
        000207
: Routine Size: 22 words,
                                 Routine Base: $CODE$ + 6200
```

ZRQAM2 VO1.2

RD/RX EXERCISER GLOBAL ROUTINES

: Maximum stack depth per invocation: 2 words

5-Dec-1983 10:27:14 5-Dec-1983 10:27:04

ZRQAM2 V01.2		RD/RX EXERCISER GLOBAL ROUTINES		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.	SEQ 0190 Page 190 BL1;82 (55)
:	6171	global routine PUT_IO_BUFF (	ADDR) : novalue =			
	6172 6173					
	6174		THE DEALLOCATION	OF AN I/O BUFFER, RETURN	NING IT	
	6175	! TO THE BUFFER POOL.				
	6176	INPUTS:				
	6178	! ADDR - ADDRE		UFFER DESCRIPTOR TO BE		
	6179 6180		DEALLOCATED			
	6181					
	6182	incr COUNT from 0 to (QI	D_PER_CTLR * MAX_C	TLR - 1) do ! FOR	EACH ENTRY IN BUFFER TABLE	
	6183 6184	if .BUFF_ADDR [.COUN	[] eglaADDR	! IF THIS IS THE BUFFE	ER'S ENTRY	
	6185	then				
	6186 6187	begin BUFF_OHN [.COUNT	11.	! DEALLOCATE BUFFER		
	6188	exitloop;		! DONE		
•	6189	end;				
			COTTI DUT TO	DUES CLODAL DOUTTNES		
000000	010146	PUT.	IO.BUFF::	.BUFF GLOBAL ROUTINES		
000000	005000		MOV R1,-(S	P)	1	617
000002 000004	010100	16:	CLR R1 MOV R1.R0		: COUNT : COUNT. *	618 618
000006	006300		ASL RO			010
000010 000016	026076	000000G 000004	CMP BUFF.A	DDR(RO), 84(SP)	: *.ADDR	
000020	112761	000377 000000G	MOVB #377.8	UFF.OWN(R1)	; *,*(COUNT)	618
	000404	2\$:	BR 3\$ INC R1		COUNT	618
000032	020127	000007	CMP R1.47		: COUNT. *	618
000036 000040	003762		BLE 1\$			
	000207	3\$:	MOV (SP)+.	MI		617
; MOUTIF	ne Size:	18 words, Routine Base depth per invocation: 2 wor	: \$CODE\$ + 6254			

ZRQAM2 VO1.2		RD/RX EXERCISER GLOBAL ROUTINES			5-Dec 5-Dec	-1983 10 -1983 10	:27:14 :27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.	SEQ 0191 Page 191 BL1;82 (56)
:	6190 6191	global routine PUTA_	BUFF : novalu	Je =					
	6192 6193 6194 6195 6196	THIS ROUTINE THE CURRENT	DEALLOCATES CONTROLLER (	ALL I/O BUF	FFERS WHICH	HAVE BE	EN ALLOCAT	ED TO	
	6197	incr COUNT from	to (QIO_PER	R_CTLR + MA	X_CTLR - 1)	do	! FOR EA	CH ENTRY IN BUFFER TABLE	
	6199	if .BUFF_OWN	[.COUNT] eq	L .CCTLR	! IF T	HIS BUFF	ER IS ALLO	CATED TO THE CURRENT CONTROLLE	R
•	6201		[.COUNT] =	-1;	! DEAL	LOCATE I	T		
000000	010146		PUTA.BUFF	SBTTL PUT	A.BUFF GLOB	AL ROUTI	NES		
000002	005000	000000		OLR RO	-(SP)			COUNT	6190 6197
000010 000014	116001 020137 001003	00000G 00000G	(		F.OWN(RO),R CCTLR	1		; *(COUNT),*	6199
000016 000024	112760 005200	000377 000000G			7, BUFF. OWN(	RO)		: *,*(COUNT) : COUNT	6201
000026	020027	000007	(	MP RO.	<b>4</b> 7			COUNT, #	6197
000034 000036	012601 000207				)+,R1			•	6190

<sup>:</sup> Routine Size: 16 words. Routine Base: \$CODE\$ + 6320 : Maximum stack depth per invocation: 2 words

ZRQAM2 VO1.2	RD/RX EXERCISER GLOBAL ROUTINES	5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555
: 6202 : 6203 : 6204 : 6205 : 6206 : 6207 : 6208 : 6209 : 6210 : 6211 : 6212 : 6213 : 6214 : 6215 : 6215 : 6216 : 6221 : 6221 : 6221 : 6221 : 6221 : 6223 : 6224 : 6225 : 6226 : 6227 : 6228 : 6228	THIS ROUTINE RETURNS TO THE CALLER PROCESSED FROM THE I/O DONE QUEUE QUEUE IS ALSO UPDATED.  INPUTS: NONE OUTPUTS: THE INDEX OF THE NEXT RETRIES.	(IODQ). THE "OUT" POINTER TO	E ING OF QUEUE
000000 013700 000004 116000 000010 042700 000014 005237 000020 023727 000026 103402 000030 005037 000034 000207 : Routine Size	000000G	ODQ.OUT	6221 * . INDEX * . INDEX 6222 6224 6226 6202
: Maximum stac	k depth per invocation: 0 words		

```
SEQ 0193
ZRQAM2
                 RD/RX EXERCISER
                                                                    5-Dec-1983 10:27:14
                                                                                             VAX-11 Bliss-16 V3-555
                                                                                                                                   Page 193
V01.2
                GLOBAL ROUTINES
                                                                    5-Dec-1983 10:27:04
                                                                                             DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (58)
          6230 global routine IN_IODQ (index) : novalue =
          6231
:
          6232 !+
          6233 !
                         THIS ROUTINE INSERTS A RETURN PACKET INDEX INTO THE I/O DONE QUEUE. AND
          6234
6235
1-
                         UPDATES THE IODQ_IN POINTER.
:
          6237
                     if ((.IODQ_IN + 1) eql .IODQ_OUT) or
:
          6238
                        (.IODQ_IN - (IODQ_LEN - 1) eql .IODQ_OUT)
:
          6239
                     then
:
          6240
6241
6242
6243
6244
6245
                         return
.
                     else
:
                         begin
.
                         IODQ [.IODQ_IN] = .index;
                                                                   ! LOAD INDEX INTO QUEUE
.
                         IODQ_IN = .IODQ_IN + 1:
                                                                   ! ADVANCE "IN" POINTER
.
:
          6246
                         if .IODQ_IN gegu IODQ_LEN
                                                                   ! IF BEYOND END OF QUEUE
:
          6247
                         then
          6248
                             IODQ_IN - O:
                                                                   ! CYCLE BACK TO BEGINNING OF QUEUE
          6249
:
          6250
                         end:
                                                                   ! IF IODQ IS NOT FULL
.
                                                   .SBTTL IN. IODQ GLOBAL ROUTINES
000000 010146
                                          IN. IODQ::
                                                           R1.-(SP)
                                                                                                                                        6230
000002 013701 000000G
                                                           IODQ. IN, R1
                                                   MOV
                                                                                                                                        6237
000006 010100
                                                   MOV
                                                           R1.RO
000010 005200
                                                   INC
                                                           RO
000012 020037
                                                           RO, IODQ. OUT
                 000000G
                                                   CMP
000016 001421
                                                   BEQ
                                                           1$
000020 010100
                                                   MOV
                                                           R1,R0
                                                                                                                                        6238
                                                                                             :
000022
        162700
                                                   SUB
                 000003
                                                           43,RO
        020037
                 000000G
                                                   CMP
                                                           RO. IODQ. OUT
000032
000034
000042
        001413
                                                   BEQ
                                                                                                                                        6240
                                                           4(SP), IODQ(R1)
        116661
                 000004 000000G
                                                   MOVB
                                                                                             : INDEX. *
                                                                                                                                        6243
        005237
                 000000G
00000G 000004
                                                   INC
                                                           IODQ.IN
IODQ.IN, #4
                                                                                                                                        6244
000046 023727
                                                                                                                                        6246
000054 103402
                                                   BLO
000056
        005037
                 000000G
                                                   CLR
                                                           IODQ. IN
                                                                                                                                        6248
000062 012601
                                                   MOV
                                                           (SP)+,R1
                                          18:
                                                                                                                                        6230
000064 000207
; Routine Size: 27 words.
                                 Routine Base: $CODE$ + 6416
```

; Maximum stack depth per invocation: 2 words

```
SEQ 0194
ZRQAM2
                RD/RX EXERCISER
                                                                    5-Dec-1983 10:27:14
                                                                                            VAX-11 Bliss-16 V3-555
                                                                                                                                  Page 194
                                                                    5-Dec-1983 10:27:04
V01.2
                GLOBAL ROUTINES
                                                                                           DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (59)
          6251 global routine DROP_CTLR (CTLR, REASON): novalue =
:
          6252
:
          6253 !+
:
          6254
                         THIS ROUTINE DROPS ALL UNITS ASSOCIATED WITH THE CONTROLLER DESIGNATED
                .
          6255
                         BY "CTLR". THE REASON FOR DROPPING THE DEVICE IS LOADED INTO THE DUR
                .
          6256
                         VECTOR FOR EACH ATTACHED UNIT. THIS DATA IS THEN USED BY THE DROP UNIT
          6257
                .
                         SECTION.
          6258
                ! -
          6259
          6260
                    begin
          6261
          6262
                     local
          6263
                         UNIT:
          6264
          6265
                     incr N from (0 + OF_UN) to (3 * UNIT_SIZE + OF_UN) by UNIT_SIZE do ! FOR EACH UNIT IN CST
          6266
:
          6267
                         if .CST [.CTLR. .N. D_PRES] eql PRESENT ! IF UNIT IS CONFIGURED
          6268
                         then
:
          6269
                             begin
UNIT = .CST [.CTLR, .N, D_UNIT];
:
          6270
                                                                   ! GET DRS UNIT NUMBER
                             DUR [.UNIT] = .REASON;
          6271
                                                                  ! SET REASON FOR DROPPING UNIT
          6272
                                                                  ! DROP UNIT
                             DODU (.UNIT);
.
          6273
                             end:
:
          6274
:
          6275
                     end:
                                                  .SBTTL DROP.CTLR GLOBAL ROUTINES
000000 004137 000000G
                                         DROP.CTLR::
                                                  JSR
                                                          R1. $SAVE3
                                                                                                                                      6251
                                                                                            CTLR.
                                                          14(SP),-(SP)
#37,-(SP)
PC,BL#MUL
000004
        016646
                000014
                                                  MOV
                                                                                                                                      6267
000010 012746
                000037
                                                  MOV
000014
        004737
                000000G
                                                  JSR
000020
        010003
                                                  MOV
                                                          RO.R3
000022 012702
                000003
                                                  MOV
                                                          43,R2
                                                                                                                                      6265
                                                                                            : *.N
000026
        010300
                                                  MOV
                                         1$:
                                                          R3.RO
                                                                                                                                      6267
000030
        060200
                                                  ADD
                                                          R2,RO
                                                                                            : N. .
000032
        006300
                                                  ASL
                                                          RO
000034
        032760
                040000 000000G
                                                  BIT
                                                           #40000, CST(RO)
000042
        001412
                                                  BEQ
000044
        016001
                000000G
                                                           CST(RO).R1
                                                  MOV
                                                                                            ; *,UNIT
                                                                                                                                      6270
000050
        000301
                                                  SWAB
                                                                                            : UNIT
                                                          R1
000052
        042701
                 177760
                                                  BIC
                                                          #177760,R1
                                                                                            : *,UNIT
000056
        116661
                000016 000000G
                                                  MOVB
                                                           16(SP), DUR(R1)
                                                                                            ; REASON, *(UNIT)
                                                                                                                                      6271
000064
        010100
                                                  MOV
                                                           R1.RO
                                                                                            : UNIT. *
                                                                                                                                      6272
000066
        104451
                                                          51
#7,R2
                                                  TRAP
000070
        062702
                000007
                                          2$:
                                                  ADD
                                                                                            : *.N
                                                                                                                                      6265
000074
        020227
                                                  CMP
                000030
                                                           R2.430
                                                                                            : N. *
000100
        003752
                                                  BLE
000102
                                                           (SP)+,(SP)+
        022626
                                                  CMP
                                                                                                                                      6260
000104
        000207
                                                  RTS
                                                                                                                                      6251
; Routine Size: 35 words,
                                 Routine Base: $CODE$ + 6504
```

N15

ZRQAM2 VO1.2

RD/RX EXERCISER GLOBAL ROUTINES

: Maximum stack depth per invocation: 8 words

5-Dec-1983 10:27:14 5-Dec-1983 10:27:04

VAX-11 Bliss-16 V3-555 SEQ 0195
DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (59)

		010		
ZRQAM2 VO1.2	RD/RX EXERCISER GLOBAL ROUTINES	5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.B	SEQ 01% Page 1% L1:82 (60)
: 66 : 66 : 66 : 66 : 66 : 66 : 66 : 66	UNRECOVERABLE CONTROLLER ERROR CLEAN UP ALL CONTROLLER-RELATE PROGRAM. THIS INCLUDES MARKING C-RING COUNT, AND DEALLOCATING RING. INPUTS: CTLR - DYING CONTROLLE CTLR - DCT LEN, W CTLR	TIMCHK AND FATAL_ERROR WHENEVER HAS BEEN DETECTED. ITS PURPOSE D DATA IN THE "DRIVER" PORTION OF THE CONTROLLER OFFLINE, CLEARING MSCP PACKETS DESCRIBED IN THE RESERVED IN TH	IS TO F THE G THE ESPONSE  ROLLER'S DCT ADDRESS ADDR	
: 6	297 PUTA_PKT (.CTLR);	RELEASE ALL PACKETS	ALLOCATED TO CONTROLLER	
: 6	298 DROP_CTLR (.CTLR, DU_CFATAL); 299 end;	! DROP ALL UNITS ON TH ! ROUTINE DRV_CTLERR	E CONTROLLER	
000000 010 000002 016 000006 010 000010 012 000014 004 000020 062 000024 005 000026 010	601 000004 MOV 146 MOV 746 000022 MOV 737 000000G JSR 700 00000G ADD	DRV.CTLERR GLOBAL ROUTINES  R1,-(SP) 4(SP),R1 R1,-(SP) #22,-(SP) PC,BL#MUL #DCT,R0 (R0)	: CTLR	6276 6295 6296
000030 004	737 006016' JSR	R1,(SP) PC,PUTA,PKT		6297
000042 004 000046 062	116 746 000006 MOV 737 006504' JSR 706 000006 ADD	R1,(SP)  #6,-(SP)  PC,DROP.CTLR  #5,SP		6298
000052 012 000054 000		(SP)+,R1		6276
; Routine S	ize: 23 words, Routine Base: \$CODE\$			

SEQ 0197

```
ZRQAM2
                    RD/RX EXERCISER
                                                                                  5-Dec-1983 10:27:14
                                                                                                               VAX-11 Bliss-16 V3-555
V01.2
                    GLOBAL ROUTINES
                                                                                 5-Dec-1983 10:27:04
                                                                                                              DISK:USER2:[DIETZ.RDRX]ZRQACO.9L1:82 (61)
            6300 global routine SEND (index) .
            6301
            6302
                              IF THE CURRENT RDRX IS ONLINE AND ITS CRING IS NOT FULL, THEN THIS ROUTINE "SENDS" A COMMAND TO THE RDRX BY LOADING THE PACKET
            6303
                  .
            6304
                   .
                              DESCRIPTOR OF AN MSCP PACKET INTO THE COMMAND RING AND READING THE
            6305
:
            6306
:
                              DEVICE'S IP REGISTER. IF THE
                              CURRENT RDRX IN NOT ONLINE, THEN A FAILURE INDICATION IS RETURNED TO
            6307
            6308
                              THE CALLER, AND NO ACTION IS TAKEN.
            6309
:
                              INPUTS:
            6310 !
:
                                        INDEX - INDEX OF MSCP PACKET CONTAINING THE COMMAND TO
            6311
:
            6312
:
                                                  BE SENT
            6313
:
                              IMPLICIT INPUTS:
            6314
:
            6315 !
                                        CCTLR - CURRENT CONTROLLER NUMBER
            6316
                                        DCT_ADDR - ADDRESS OF CURRENT CONTROLLER'S DCT
:
            6317 !-
.
            6318
:
            6319
                         begin
:
            6320
            6321
                         local
            6322
                              SLOT_ADDR.
            6323
                              TEMP : word;
:
            6324
:
                         if ((.DCT_ADDR [STAT] eql ONLINE) and
  (.DCT_ADDR [CRING_CNT] lssu CRING_LEN)) or
  (.MSCP_PKT [.index, OPCODE] eql OP_SCC)
            6325
                                                                                                     ! IF DEVICE IS ONLINE AND
            6326
                                                                                                    ! ITS CRING IS NOT FULL
            6327
                                                                                                    ! OR IT IS A SET-CTRL-CHAR COMMAND
            6328
            6329
                              6330
            6331
            6332
            6333
                                         (.MSCP_PKT [.index, OPCODE] eql OP_SCC) or (.MSCP_PKT [.index, OPCODE] eql OP_WRT) OR
:
            6334
:
                                         (.MSCP_PKT[.INDEX, OPCODE] EQL OP_SDD) OR

(.MSCP_PKT[.INDEX, OPCODE] EQL OP_RCD) OR

(.MSCP_PKT[.INDEX, OPCODE] EQL OP_GDS) OR

(.MSCP_PKT[.INDEX, OPCODE] EQL OP_ELP) OR

(.MSCP_PKT[.INDEX, OPCODE] EQL OP_ABT) OR

(.MSCP_PKT[.INDEX, OPCODE] EQL OP_ESP) ))
            6335
:
            6336
:
            6337
            6338
.
            6339
:
            6340
;
            6341
                              then
:
            6342
                                  PRINTF (DBM107, .MSCP_PKT [.index, OPCODE]);
            6343
            6344
                                   return FAILURE:
            6345
                                   end
            6346
                              else
            6347
                                   begin
            6348
            6349
                                   do
            6350
                                                                                                    ! LOOP TILL CREDIT BALANCE POSITIVE
            6351
                                   until ((.MSCP_PKT [.index, CMD_TYPE] eql IMM_CMD) and
.
            6352
                                            (,CREDIT_BAL gegu 1)) or
```

ZRQAM2 VO1.2		RD/RX EXERCISER GLOBAL ROUTINES		5-De 5-De	c-1983 10:27:14 c-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQ	SEQ 0198 Page 198 ACO.BL1:82 (61)
	6353	(.0	REDIT_BAL gtru				
:	6354						
:	6355	MSCP_PKT [	.index. CRN_LC	)] - (CRN_LOWC	RN_LOW + 1);	! ASSIGN CMD REF NUM	
	6356						
•	6357 6358	if .CRN_LO	W eql 0				
:	6359	then LKN_	HIGH CRN_HI	LGM + 1;			
:	6360	MCCD DKT [	Inday CON HI	11 - CON HTCH.			
	6361	SLOT ADDR	= DCT ADDR	[] = .CRN_HIGH;	1 0000	OF NEXT COMMAND SLOT	
	6362	3201_1001	0C1_NOON 10	- N-145 X 1 );	: ADDR	OF NEXT COMMAND SLUT	
	6363	DO BREAK					
	6364		.SLOT_ADDR . 2	2) and ED_OWN) eq1	0):		
:	6365						
	6366	SETPRI (PR	(107);				
	6367	0. 07					
•	6368	. SLOT_ADDR	- MSCP_PKT [	[.index, PKT_LO];	! LOAD	BUFF DESC (LO) INTO COMMAND NCE TO NEXT WORD BUFF DESC (HI) INTO COMMAND R INTERRUPT FLAG IN CASE SET	SLOT
	6369 6370	SLUI_ADDR	- SLUT_ADDR	21	! ADVA	NCE TO NEXT WORD	
	6371	SLOT ADDR	SINT ANNO	.ingex, PRI_HIJ;	C)).	BUFF DESC (HI) INTO COMMAND	SLOT
	6372	SLOT ADDR	SLOT ADDE	On FD OLAN	GITTE	OWNERSHIP TO CONTROLLER	
	6373	SLOT ADDR	- SLOT ADDR	or ED_OWN;	ADVA	NCE TO NEXT COMMAND SLOT	
	6374					NOCE TO NEXT CONTINUE SECT	
:	6375	if .SLOT_A	DDR gtra .DCT.	ADDR [CR_END]	! IF 6	EYOND END OF CRING	
:	6376	then					
•	6377	SLOT_A	NDDR = .DCT_ADD	OR [CR_BEG];	! CYCL	E BACK TO BEGINNING	1
	6378 6379	1 000A TOO	CD NEVT1 - C	07 4000			
:	6380	DCT_ADDR [	CRINEALL . SI	DCT ADDR COTAC C	NT1 . 1. REST	ORE CR_NEXT POINTER IN DCT  # OF COMMANDS IN CRING SCP command EMENT CREDIT BALANCE	
	6381	if C.MSCP	PKT ( index (	COMMITCH COLUMN	CD) : : INCH	A OL COLLINOS IN CKING	
	6382	then (CRED	IT BAL CREE	OIT BAL - 1):	DECR	EMENT CREDIT BALANCE IP TO FORCE PORT TO POLL	
:	6383	TEMP = .RD	RX_ADDR [RCIP.	RC ALL 1:	! READ	IP TO FORCE PORT TO POLL	
	6384				! LOWE	R PRIORITY	
	6385	return SUC	CESS;				
	6386	end					
1	6387 6388	-1					
	6389	else return FAILURE				EVICE TO NOT ON THE	
	6390	TECOM FALLONE			: 17 0	EVICE IS NOT ONLINE	
	6391	end;		! ROU	TINE-SEND		
000000	004137	000000G	.581		OUTINES		
000004	005746	000000	SEND:: JSR	R1. \$SAVE2		1	6300
000006	005777	00000G	TST	-(SP) aDCT.ADDR			6705
000012	005777 100004	***************************************	BPL	1\$			6325
000014	127727	000000G 000004	CMPS				6326
000022	103413		BLO	2\$			6326
000024	016646	000012	1\$: MOV	12(SP),-(SP)		; INDEX.*	6327
000030	012746	000104	MOV	#104,-(SP)			
000034	004737	00000G	JSR	PC.BL #MUL			
000040	022626 126027	0000336 000004	CMP	(SP)+,(SP)+	^		
200042	150051	000022G 000004	CMPE	MSCP.PKT+22(R	0),94		

					C10		
ZRQAM2 VO1.2		RD/RX EXERCISER GLOBAL ROUTINES			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.	SEQ 0199 Page 199
		CLOURE ROOTERES			J-06C-1703 10:27:04	DISK FOSENZ: [ DIE 12 , NUNA JZNUMCO,	011105 (01)
000050 000052 000056	001170 016646 012746	000012 000104	2\$:	BNE MOV	10\$ 12(SP),-(SP)	; INDEX.*	6330
000062 000066 000070 000072	004737 010002 022626 005000	000000G		MOV JSR MOV CMP CLR	#104(SP) PC.BL#MUL RO.R2 (SP)+,(SP)+ RO		
000074	156200 020027 001450	000020		BISB CMP BEQ	MSCP.PKT+22(R2),R0 R0,#20 3\$		
000104 000106 000112	020027 001445	000011		CMP BEQ	RO.#11		6331
000114	020027	000041		CMP BEQ	RO.041		6332
000122 000126	020027 001437	000004		CMP BEQ	RO, #4		6333
000130 000134	020027 001434	000042		CMP BEQ	RO, #42		6334
000136	020027	000004		CMP BEQ	RO.04		6335
000142 000144 000150 000152 000156 000160	020027 001426	000005		CMP BEQ	RO, #5		6336
000152 000156	020027 001423	000001		CMP BEQ	RO, #1	•	6337
000164	001420	000003		CMP BEQ	RO, #3	•	6338
000166 000172 000174	020027 001415	000006		CMP BEQ	RO, 46	•	6339
000174 000200 000202	020027 001412	000002		CMP BEQ	RO.#2	•	6340
000204	010046 012746	000000G		MOV	RO,-(SP) #DBM107,-(SP)		6343
000210 000214 000216	012746 010600 104417	000002		MOV	02,-(SP) SP,R0	: SP. 4	
000220 000224 000226	062706 000502	000006		TRAP ADD BR	17 96.SP 10\$		6342 6330
000226	104422 005762	000004G	3#:	TRAP	22 MSCP.PKT+4(R2)		6349 6351
000234 000236	001003 005737	000000G		BNE	4\$ CREDIT.BAL		6352
000242 000244	001004 023727	000000G 000001	41:	BNE	5# CREDIT.BAL.#1		6353
000252 000254	101765 013700	000000G	5#:	BLOS	34 CRN.LOW,RO		6355
000262	005200 010037	000000G		INC	RO RO, CRN. LOW		The state of the s
000266 000272	010062	000012G		MOV BNE	RO.MSCP.PKT+12(R2)		6357
000274	005237	000000G		INC	CRN.HIGH		6358
000300	013762		6\$:			•	6360
00000	020100					A. SLOT, ADDR	6361
000226 000230 000234 000236 000242 000254 000254 000260 000262 000266 000272 000274 000300 000306 000312	020100	000000G 000000G 000000G 000020	6\$:	BNE INC MOV MOV MOV	6#	SLOT. ADDR	6

ZRQAM2 VO1.2		RD/RX EXERCISE GLOBAL ROUTINE			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQAC	SEQ 0200 Page 200 D.BL1:82 (61)
000316 000320 000326	104422 032761 001373	100000 00000	2 7\$:	TRAP BIT BNE	22 #-100000,2(R1) 7\$	: *.*(SLOT.ADDR)	6363 6364
000330 000334	012700 0 104441	000340		MOV	#340.RO 41		6366
000336 000342 000346 000352 000356 000362	016221 0 016211 0 042711 0 052721 1 013700 0 020160 0	000000G 000002G 040000 100000 000000G		MOV MOV BIC BIS MOV CMP BLOS	MSCP.PKT(R2),(R1)+ MSCP.PKT+2(R2),(R1) #40000,(R1) #100000,(R1)+ DCT.ADDR,R0 R1,12(R0) 8\$	: *.SLOT.ADDR : *.SLOT.ADDR : *.SLOT.ADDR : *.SLOT.ADDR : SLOT.ADDR.*	6368 6370 6371 6372 6375
000370 000374 000400 000402 000406	010160 0 105210	000010 000020 000011G	8#:	MOV MOV INCB TSTB BNE	10(R0),R1 R1,20(R0) (R0) MSCP.PKT+11(R2)	: *.SLOT.ADDR : SLOT.ADDR.*	6377 6379 6380 6381
000410 000414 000420 000422		00000G 00000G	9\$:	DEC MOV CLR TRAP	CREDIT.BAL BRDRX.ADDR,(SP) RO 41	. *.RC.REG	6382 6383 6384
000424 000430 000432 000434	012700 0 000401 005000 005726	000001	108:	MOV BR CLR	\$1.RO 11\$ RO	:	6330 6319
000436	000207		11\$:	RTS	(SP)+ PC		6300

<sup>:</sup> Routine Size: 144 words. Routine Base: \$CODE\$ + 6670 : Maximum stack depth per invocation: 9 words

ZRQAM2 VO1.2	RD/RX EXERCISER GLOBAL ROUTINES	5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Page DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (62	e 201
: 6392 : 6393 : 6394 : 6395 : 6396 : 6398 : 6399 : 6400	THE PURPOSE OF THIS ROUTINE IS TO KILL RESULTS IN A RETURN PACKET INDEX BEING QUEUE (IODQ).	TIME UNTIL AN RDRX INTER DEPOSITED INTO THE I/O	RRUPT	
000000 104422 000000 000002 023737 000010 001773 000012 000207	O00000G 000000G WAIT::  1\$: TRAP 22  CMP IODQ.: BEQ 1\$	N, IODQ. OUT	:	6399 6401 6392
: Routine Size : Maximum stac	: 6 words. Routine Base: \$CODE\$ + 7330 k depth per invocation: 2 words			

```
SEQ 0202
ZRQAM2
                  RD/RX EXERCISER
                                                                          5-Dec-1983 10:27:14 VAX-11 Bliss-16 V3-555 Page 2
5-Dec-1983 10:27:04 DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (63)
                                                                                                                                             Page 202
V01.2
                  GLOBAL ROUTINES
           6402 global routine MODULAS (LO_LIMIT, HI_LIMIT) =
           6403
           6404 !+
           6405 !
                           THE PURPOSE OF THIS ROUTINE IS TO GET A RANDOM NUMBER
:
                           BETWEEN LO AND HI LIMITS. THIS SHOULD WORK FOR A 16 BIT WORD. THE "MOD"FUNC ONLY WORKS ON 15 BITS.
           6406 !
           6407 !
           6408 !-
:
           6409 begin
6410 OWN
                           ANSWER : unsigned word.

SAVESZ : UNSIGNED WORD,

SIZE : unsigned word:

! VARIABLE FOR RANDOM WORD TABLE
! FINAL ANSWER
! SAVES THE CASE
:
:
           6411 LOCAL
:
           6412
:
                                                                                            ! SAVES THE SIZE OF WINDOW
           6413
           6414
           6415 X = .X + 1;
6416 IF .X GEQ RDM_LEN
.
.
           6417 THEN X = 0;
                                                           ! KEEP ROTATING RANDOM NUMBERS BEING USED
.
           6418
:
           6419 SIZE = .HI_LIMIT - .LO_LIMIT;
6420 SAVESZ = .HI_LIMIT - .LO_LIMIT;
6421 IF (.SIZE lequ #0'077777')
:
                                                                      ! IF 15TH BIT NOT SET
:
           THEN ANSWER = ((.RANDOM (.X) and #0'077777') MOD (.SIZE + 1)) ! ONLY 15 BIT WORD SO TAKE RANDOM SAMPLE
:
:
                      begin
SIZE = .SIZE + -1;
ANSWER = (.RANDOM [.X] and #0'077777') MOD (.SIZE + 1);
! MAKES SIZE A 15 BIT LEN
! GETS 15 BIT RANDOM #
           6424
:
           6425
.
                                                                                           ! MAKES SIZE A 15 BIT LENGHT OR DIVIDE IN HALF
           6426
:
                       ANSWER = .ANSWER + 1;
ANSWER = .ANSWER + (.RANDOM [.X + 1] and 1);
! BUILD UP TO REGULAR SI
           6427
:
                                                                                          ! BUILD UP TO REGULAR SIZE
           6428
:
                      if (.ANSMER gtru SAVESZ)
then ANSMER = .SAVESZ;
           6429
:
           6430
:
                                                             ! IT IS POSSIBLE TO BE 1 LARGER THAN SIZE SO CHECK
           6431
:
                       end;
                                                                                           ! AND MAKE CORRECTION
           6432 return . ANSWER:
:
           6433 end;
:
                                             ! end of MODULAS ROUTINE
007344
                                             X:
                                                       .BLKW 1
                                                       .SBTTL MODULAS GLOBAL ROUTINES
000000 004137 000000G
                                             MODULAS::
                                                                R1. $SAVE2
                                                                                                                                                   6402
                                                                                                     :
000004 005746
                                                       TST
                                                                -(SP)
000006 005237
                  007344
                                                       INC
                                                                                                                                                   6415
000012
         023727
                  007344' 000020
                                                       CMP
                                                                X.420
                                                                                                                                                   6416
000020
         002402
                                                       BLT
                                                                1#
000022
         005037
                  007344
                                                       CLR
                                                                                                                                                   6417
000026
         016600
                  000012
                                             18:
                                                       MOV
                                                                12(SP).RO
                                                                                                     : HI.LIMIT.+
                                                                                                                                                   6419
000032
         166600
                  000014
                                                                14(SP),RO
                                                       SUB
                                                                                                     : LO.LIMIT. .
000036
         010001
                                                       MOV
                                                                RO,R1
                                                                                                     : *.SIZE
        010016
000040
                                                       MOV
                                                                RO.(SP)
                                                                                                     : *. SAVESZ
                                                                                                                                                   6420
000042
         013700
                  007344
                                                       MOV
                                                                X.RO
                                                                                                                                                   6422
000046
         006300
                                                       ASL
                                                                RO
000050
         020127
                  077777
                                                       CMP
                                                                R1.077777
                                                                                                     : SIZE.*
                                                                                                                                                   6421
000054
         101011
```

	ZRQAM2 VO1.2		RD/RX EXERCISER GLOBAL ROUTINES			5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO	SEQ 0203 Page 203 .BL1:82 (63)
-	000056 000062 000066 000070 000072	016046 042716 010146 005216 004737	000000G 100000		MOV BIC MOV INC	RANDOM(RO),-(SP) #100000,(SP) R1,-(SP) (SP)	; SIZE,*	6422
***************************************	000076 000100 000102	000431 006201	000000G	2\$:	JSR BR ASR	PC,BL\$MOD 3\$ R1	SIZE	6421 6425
	000106 000112 000114	016046 042716 010146 005216	000000G 100000		MOV BIC MOV INC	RANDOM(RO),-(SP) #100000,(SP) R1,-(SP) (SP)	; SIZE,*	6426
-	000116 000122 000124	004737 006300 013701	000000G 007344'		JSR ASL MOV	PC.BL\$MOD RO X.R1	: ANSWER	6427 6428
-	000130 000132 000136 000142	006301 116102 042702 060200	000002G 177776		ASL MOVB BIC ADD	R1 RANDOM+2(R1),R2 #177776,R2 R2,R0	: *.ANSWER	
A SAME AND PARTY AND POST OF PERSONS ASSESSED.	000144 000150 000152	012701 060601 020001	000004		MOV ADD CMP	#4,R1 SP.R1 RO.R1	: SAVESZ.* : ANSWER.*	6429
Name (cold spinors, section) in column 1	000154 000156 000162 000166	101402 016600 062706 000207	000004 000006	3#:	BLOS MOV ADD RTS	3\$ 4(SP),RO #6,SP PC	: SAVESZ, ANSWER	6430 6402

<sup>:</sup> Routine Size: 60 words. Routine Base: \$CODE\$ + 7346 : Maximum stack depth per invocation: 7 words

```
SEQ 0204
ZRQAM2
                RD/RX EXERCISER
                                                                   5-Dec-1983 10:27:14
5-Dec-1983 10:27:04
                                                                                          VAX-11 Bliss-16 V3-555
                                                                                                                               Page 204
V01.2
                ERROR MESSAGE SUBROUTINES
                                                                                           DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (64)
          6434 #sbttl 'ERROR MESSAGE SUBROUTINES'
          6435
          6436 routine EMS_SA : novalue =
:
          6437
          6438 !+
          6439 !
                        THIS ROUTINE PRINTS (EXTENDED) THE GLOBAL DATUM "SA REG" WHICH CONTAINS
          6440 !
                        THE CONTENTS OF THE SA REGISTER.
          6441 !-
          6442
          6443
                     if .SA_REG eql #0'177777'
                                                                                        ! IF CONTROLLER TIME-OUT
:
          6444
                    then
:
                        begin
PRINTX (CRLF);
PRINTX (ASTERISK);
          6445
:
          6446
:
          6447
:
          6448
                         PRINTX (.CNTR_ERR [0]);
:
          6449
                        end
          6450
                    else
:
          6451
.
          6452
                         if (.SA_REG and #0'003777') legu 22
                                                                                   ! IF GENERIC CONTROLLER ERROR
:
          6453
                         then
:
          6454
:
                             begin
          6455
                             PRINTX (CRLF);
                             PRINTX (ASTERISK):
          6456
          6457
                             PRINTX (.CNTR_ERR [.SA_REG and #0'003777']);
.
          6458
:
          6459
                         else
:
          6460
:
          6461
                             if ((.SA_REG and #0'003777') - 400) legu 6
                                                                                        ! IF RDRX SPECIFIC CONTROLLER ERROR
          6462
.
          6463
                                 begin
PRINTX (CRLF):
:
          6464
.
          6465
                                 PRINTX (ASTERISK);
          6466
                                 PRINTX (.RDRX_ERR [(.SA_REG and #0'003777') - 400]);
          6467
                                 end
          6468
          6469
                                 PRINTX (XX14, .SA_REG);
                                                                                 ! JUST PRINT CONTENTS OF SA
.
                                                  .SBTTL EMS.SA ERROR MESSAGE SUBROUTINES
000000 010146
                                         EMS. SA: MOV
                                                          R1.-(SP)
                                                                                                                                     6436
000002 013701
000006 020127
                000000G
                                                  MOV
                                                          SA.REG.R1
                                                                                                                                     6443
               177777
                                                  CMP
                                                          R1.4-1
000012 001023
                                                  BNE
000014 012746
                000000G
                                                          OCRLF, -(SP)
                                                  MOV
                                                                                                                                     6446
                                                                                           :
000020 012746
                000001
                                                  MOV
                                                          41,-(SP)
000024 010600
                                                  MOV
                                                          SP.RO
                                                                                           : SP. *
000026 104415
                                                          15
                                                  TRAP
000030 012716 000000G
                                                          #ASTERISK, (SP)
                                                  MOV
                                                                                                                                     6447
000034 012746
                000001
                                                  MOV
                                                          #1,-(SP)
000040 010600
                                                          SP.RO
                                                  MOV
                                                                                           : SP. .
000042 104415
                                                  TRAP
                                                          15
000044
        013716 000000G
                                                  MOV
                                                          CNTR.ERR,(SP)
                                                                                                                                     6448
000050 012746
                000001
                                                  MOV
                                                          #1,-(SP)
```

					1/10		
ZRQAM2 VO1.2		RD/RX EXERCISER ERROR MESSAGE SUBROUTI	NES		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.	SEQ 0205 Page 205 BL1:82 (64)
000054	010600			MOV	SP.RO	: SP.4	
000056 000060	104415			TRAP	15		
000062	010100		1\$:	BR MOV	R1.R0		6445
000064	042700	174000	• • • •	BIC	#174000,R0		6452
000070	020027	000026		CMP	RO,#26		
000070 000074 000076 000102	101030			BHI	21		
000076	012746	000000G		MOV	#CRLF,-(SP)		6455
000102	012746	000001		MOV	#1(SP) SP,R0	: SP.*	
000110	104415			TRAP	15	; 37,*	
000112	012716	00000G		MOV	#ASTERISK.(SP)		6456
000116	012746	000001		MOV	#1(SP) SP.RO		
000122	010600			MOV	SP.RO	; SP.*	
000124 000126	104415	000000G		TRAP	15 SA.REG.RO		****
000132	042700	174000		BIC	#174000.RO	1	6457
000136	006300			ASL	RO		
000140	016016	00000G		MOV	CNTR.ERR(RO),(SP)		
000144	012746	000001		MOV	#1,-(SP)		
000150	010600 104415 000437			MOV	SP.RO	: SP.*	
000154	000437			BR	34		6454
000144 000150 000152 000154 000156	010100		2\$:	MOV			6461
000160	042700	174000		BIC	R1,R0 #174000,R0		0401
000164	162700	000620		SUB	<b>#620,R0</b>		
000174	020027 101031	000006		CMP BHI	RO.#6		
000170 000174 000176	012746	00000G		MOV	4\$ #CRLF,-(SP)		6464
000202	012746	000001		MOV	#1(SP)	•	0404
000206	010600			MOV	#1,-(SP) SP,R0	; SP. 4	
000210	104415	******		TRAP	15		
000212	012716	00000G		MOV	MASTERISK, (SP)		6465
000222	010600	000001		MOV	#1,-(SP) SP,R0	: SP.4	
000224	104415			TRAP	15	, 35,4	
000226	013700	000000G		MOV	SA.REG,RO		6466
000232	042700	174000		BIC	#174000,R0		
000236	006300 016016	176340G		ASL	RO RODY ERD 1440(RO) (CD)		
000244	012746	000001		MOV	RDRX.ERR-1440(RO),(SP) #1,-(SP)		
000250	010600			MOV	SP.RO	; SP.*	
000252	104415			TRAP	15		
000254	005726		34:	TST	(SP)+	1	6463
000256	000407 010146			BR	54	1	6461
000262	012746	000000G	48:	MOV	R1,-(SP) #XX14,-(SP)		6469
000266	012746	000002		MOV	#2,-(SP)		
000236 000240 000250 000252 000254 000256 000260 000262 000266 000272	010600			MOV	SP,RO	; SP.*	
000274	104415	22222		TRAP	15		
000276 000302	062706	000006	5#:	ADD	46,SP		6443
000304	000207				C2L)+'KI		6436
000302	012601 000207			MOV	(SP)+,R1 PC		643

L16

ZRQAM2 VO1.2

RD/RX EXERCISER ERROR MESSAGE SUBROUTINES

SEQ 0206 5-Dec-1983 10:27:14 VAX-11 Bliss-16 V3-555 Page 206 5-Dec-1983 10:27:04 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (64)

Routine Size: 99 words. Routine Base: \$CODE\$ + 7536 Maximum stack depth per invocation: 7 words

SEQ 0207

```
ZRQAM2
                RD/RX EXERCISER
                                                                   5-Dec-1983 10:27:14
                                                                                          VAX-11 Bliss-16 V3-555
                ERROR MESSAGE SUBROUTINES
V01.2
                                                                  5-Dec-1983 10:27:04
                                                                                          DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (65)
          6470 routine EMS_SBC : novalue =
          6471
          6472 !+
          6473 !
                        THIS ROUTINE PRINTS THE GLOBAL DATUM "SB_CODE" (SUB-CODE) IF
          6474
                        EITHER THE STATUS CODE (ST_CODE) OR THE SUB-CODE IS NON-ZERO. (A
               .
                        NON-ZERO SUB-CODE ALWAYS HAS SIGNIFICANCE, WHEREAS A ZERO SUB-CODE ONLY
          6475
          6476
                        HAS MEANING WITH A NON-ZERO STATUS CODE).
          6477
          6478
          6479
                    begin
          6480
          6481
                    if (.ST_CODE or .SB_CODE) neg 0
                                                                                          ! PRINT SUB-CODE ONLY ON ERROR
          6482
                    then
                        begin
PRINTB (XX16);
          6483
          6484
                                                                                          ! SUB-CODE :
          6485
          6486
                        case .ST_CODE from ST_SUC to ST_DRV of
          6487
                             set
          6488
          6489
                             [ST_SUC]:
                                                 if .SB_CODE legu 16
                                                                                          ! SUCCESS SUB-CODES
          6490
                                                 then
          6491
                                                     PRINTB (.TBL_SUC [.SB_CODE]);
          6492
          6493
                            [ST_CMD]:
                                                 PRINTB (EX_OP, .SB_CODE / 8);
                                                                                          ! INVALID COMMAND
          6494
          6495
                            [ST_ABO]:
                                                                                          ! COMMAND ABORTED
          6496
                             [ST_OFL]:
                                                 if .SB_CODE legu 8
                                                                                          ! UNIT OFFLINE
          6498
                                                 then
          6499
                                                     PRINTB (.TBL_OFL [.SB_CODE]);
          6500
          6501
                             [ST_AVL.]:
                                                                                          ! UNIT AVAILABLE
          6502
          6503
                             (ST_MFE):
                                                 if .SB_CODE legu 10
                                                                                          ! MEDIA FORMAT ERROR
          6504
          6505
                                                     PRINTB (.TBL_MFE [.SB_CODE]):
          6506
          6507
                             [ST_WPT]:
                                                 if (.SB_CODE / 128) legu 2
                                                                                          ! WRITE PROTECTED
          6508
                                                 then
          6509
                                                     PRINTB (.TBL_WPT [(.SB_CODE / 128)]);
          6510
          6511
                             [ST_CMP]:
                                                                                          ! COMPARE ERROR
                                                 :
          6512
          6513
                             [ST_DAT]:
                                                 if .SB_CODE legu 15
                                                                                          ! DATA ERROR
          6514
          6515
                                                     PRINTB (.TBL_DAT [.SB_CODE]);
          6516
          6517
                             [ST_HST]:
                                                 if .SB_CODE legu 4
                                                                                          ! HOST ACCESS ERROR
          6518
                                                 then
          6519
                                                     PRINTB (.TBL_HST [.SB_CODE]);
          6520
          6521
                             [ST_CNT]:
                                                 if .SB_CODE legu 3
;
                                                                                          ! CONTROLLER ERROR
          6522
                                                 then
:
```

ZRQAM2 VO1.2		RD/RX EXERCISER ERROR MESSAGE SUBROUTI	INES	5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO	SEQ 0208 Page 208 0.BL1:82 (65)
	6523					
	6524			PRINTB (.TBL_CNT [.SB_CODE]);		
	6525	[ST_DRV]:	if.	SB_CODE legu 8	! DRIVE ERROR	
•	6526 6527		then			
	6528			PRINTB (.TBL_DRV [.SB_CODE]);		
	6529	[outrange]	: PRIN	TB (EX_OP, .SB_CODE);	! JUST PRINT SUB-CODE IF NO !	TATCH
	6530 6531	tes;				
	6532	end;				
	6533					
:	6534	end;				
000000	017700	0000000	SB1		ITINES	
000004	013700 053700	000000G 000000G	EMS.SBC:MOV BIS	ST.CODE.RO SB.CODE.RO		6481
000010	001001	***************************************	BNE	1\$		
000012	000207		RTS	PC		
000014	012746 012746	000000G 000001	1\$: MOV	•XX16,-(SP)	1	6484
000024	010600	000001	MOV	#1,-(SP) SP,R0	: SP. 4	
000024 000026 000030	104414		TRAP	14	1 3.1.	
000030	013700	000000G 000013	MOV	ST.CODE.RO	1	6486
000040	101003	000013	CMP	RO.#13		
000042	006300		ASL	RO		
000044	066007	000000,	ADD	P.AAA(RO).PC	; Case dispatch	
000054	013716 012746	000000G 000000G	34: MOV	SB.CODE.(SP) WEX.OP,-(SP)		6529
000060	012746	000002	MOV	02,-(SP)		
000064 000066	010600		MOV	SP.RO	; SP.4	
000070	104414 022626		TRAP	14 (SP)+,(SP)+		
000072	000435		BR	61		6486
000074	023727	000000G 000020	48: CMP	SB.CODE.020		6489
000102 000104	101165	000000G	BHI	146		****
000110	006300	000000	ASL	SB.CODE.RO		6491
000112	016016	000000	MOV	TBL.SUC(RO),(SP)		
000116 000122	012746	000001	MOV	●1(SP)		
000124	104414		MOV	SP.RO	: SP. •	
000126	000565		BR	15#		
000130 000134	013716 012746	000000G	5#: MOV	SB.CODE,(SP)		6493
000140	004737	000010 000000G	MOV JSR	#10,-(SP) PC.BL#DIV		
000144	010016		MOV	RO.(SP)		
000146	012746	000000G	MOV	<b>#EX.OP,-(SP)</b>		
000152 000156	012746 010600	000002	MOV	42(SP)	. 60 4	
000160	104414		MOV	SP.RO	: SP.4	
000162		000006	ADD	46, SP		

ZRQAM2		RD/RX EXERCISER ERROR MESSAGE SUBRE	OUTTNEC		5-Dec-1983 10:27:14	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;	EQ 0209 Page 209
V01.2		ERRUR HESSAGE SUBRI	DOLINES		5-Dec-1985 10:27:04	DISK \$USER2: [DIETZ.RDRX]ZRQACO.BL1;	82 (65)
000166	000546		61:	BR	16\$		6486
000170	023727	000000G 000010	7\$:	CMP	SB.CODE, #10		6497
000176	101142	00000G		BHI	16\$ SB.CODE,RO RO		
000204	006300	0000003		ASL	SB.CODE,RO		6499
000206	016016	0000421		MOV	TBL.OFL(RO),(SP)		
000212 000216 000220	012746	000001		MOV	41,-(SP)		
000216	010600			MOV	SP,RO	; SP,*	
000550	104414			TRAP	14		
000224	023727	000000G 000012	81:	BR CMP	15 \$ SB.CODE,#12 16 \$ SB.CODE,RO		
0000232	101124	0000003 000012	0	BHI	16\$		6503
000234 000240 000242 000246	013700	000000G		MOV	SB.CODE.RO		6505
000240	006300			ASL	RO		0303
000242	016016	000064		MOV	TBL.MFE(RO),(SP)		
000246	012746	000001		MOV	#1(SP)		
000254	104414			MOV	SP.RO	: SP.*	
000256	000511			BR	15:		
000260	013716	00000G	98:	MOV	SB.CODE,(SP)		6507
000264	012746 004737	000200		MOV	#200,-(SP)		
000270	004737	000000G		JSR	PC.BL DIV		
000246 000254 000256 000260 000264 000270 000274	020027	000002		TST	(SP)+ RO,#2		
000302	101100	000002		BHI	16\$		
000302 000304 000306 000312	006300			ASL	RO		6509
000306	016016	000112'		MOV	TBL.WPT(RO),(SP)		0007
000312	012746	000001		MOV	#1,-(SP)		
000316 000320	010600 104414			MOV TRAP	SP.RO	; SP.4	
000322	000467			BR	15+		
000322 000324 000332 000334 000340	023727	000000G 000017	104:	CMP	SB.CODE, #17		6513
000332	101064	*******		BHI	16#		
000334	013700 006300	00000G		MOV	SB.CODE,RO		6515
000342	016016	000120'		ASL	RO TBL.DAT(RO),(SP)		
000346	012746	000001		MOV	#1,-(SP)		
000352	010600			MOV	SP.RO	: SP. *	
000354 000356	104414			TRAP	14		
000360	000451 023727	0000000 000004		BR	154		
000366	101046	000000G 000004	11#:	CMP BHI	SB.CODE, #4		6517
000366 000370	101046 013700	000000G		MOV	SB.CODE,RO		6519
000374	006300			ASL.	RO		0319
000376	016016	000160		MOV	TBL.HST(RO),(SP)		
000374 000376 000402 000406	012746 010600	000001		MOV	#1,-(SP)		
000410	104414			MOV	SP.RO	; SP. 4	
000410 000412	000433			BR	154		
000414	023727	000000G 000003	124:	CMP	SB.CODE, #3		6521
000422	101030			BHI	16#		
000424	013700	000000G		MOV	SB.CODE.RO	1	6523
000430	000300			ASL	RO		

	ZRQAM2 VO1.2	RD/RX EXERCISER ERROR MESSAGE SUBROUTINES		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555	SEQ 0210 Page 210 ;82 (65)
	000432 016016 000436 012746 000442 010600 000444 104414 000446 000415	000172'	MOV MOV MOV TRAP BR	TBL.CNT(RO),(SP) \$1,-(SP) SP,RO 14 15\$	; SP.4	
	000450 023727 000456 101012	000000G 000010 13\$: 14\$:	CMP	SB.CODE, #10		6525
	000460 013700	000000G	MOV	SB.CODE,RO		6527
	000464 006300 000466 016016 000472 012746 000476 010600 000500 104414	000001	ASL MOV MOV MOV TRAP	RO TBL.DRV(RO),(SP) #1,-(SP) SP,RO 14	; SP.4	
-	000502 005726 000504 022626 000506 000207	15#: 16#:	TST CMP RTS	(SP)+ (SP)+,(SP)+ PC		6483
	: Routine Size: : Maximum stack	164 words. Routine Base: depth per invocation: 7 words		10044 \$PLIT\$, RO , D		6470
	000000 000024 000002 000060 000004 000434 000006 000120 000010 000434 000012 000154 000014 000210 000016 000434 000020 000254 000022 000310 000024 000344 000026 000400	P.AAA 2\$:		24 60 434 120 434 154 210 434 254 310 344 400	; CASE Table for EMS.SBC+0044 ; [4*] ; [5*] ; [16*] ; [7*] ; [16*] ; [8*] ; [9*] ; [16*] ; [10*] ; [11*] ; [12*] ; [13*]	6486

```
SEQ 0211
ZRQAM2
                 RD/RX EXERCISER
                                                                      5-Dec-1983 10:27:14
                                                                                               VAX-11 Bliss-16 V3-555
                 ERROR MESSAGE SUBROUTINES
V01.2
                                                                      5-Dec-1983 10:27:04
                                                                                               DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (66)
          6535 GLOBAL routine EMSCMD : novalue =
           6536
           6537 !+
           6538 !
                          THIS ROUTINE PRINTS THE ENTIRE RETURN PACKET INCLUDING OPCODE.
           6539 !
                          STAUTUS, SUB-STATUS, MODFIERS OR FLAGS, AND ETC.
           6540
                          THESE FIELDS ARE "TRANSLATED" INTO ENGLISH TEXT IF POSSIBLE
           6541
                         RATHER THAN PRINTED AS RAW NUMBERS.
           6542
           6543
                          IMPLICIT INPUTS:
           6544
                                  RP_ADDR - ADDRESS OF THE CURRENT RETURN PACKET
           6545
           6546 begin
.
           6547
.
           6548
                 OWN
:
           6549
                         EBH_TB1 : VECTOR [7] INITIAL (EBH_30.EBH_44.EBH_45.
.
           6550
                                                   EBH_46.EBH_47.EBH_48.EBH_49);
:
           6551
           6552
                                  ! TABLE OF BASIC. HARD ERROR MESSAGE ADDRESSES. INDEXED BY STATUS CODE
           6553
:
                 PRINTB (XX13, .CDISK);
           6554
:
                                                            ! "DISK XXX"
                 !PRINTB (XX36, .CRN_LOW);
           6555
                                                                             ! EXPECTED CRN : XXXXXX
:
                 PRINTX (XX35, .RP_ADDR [CRF_HI], .RP_ADDR [CRF_LO]);
printX (xx29);
           6556
:
                                                                                     ! RECEIVED CRN : XXXXXX
           6557
                                                                    ! "message type:
           6558
                 SELECTU (.RP_ADDR [MESTYP]) OF
           6559
                                  SET
                                   (#0'0'): PRINTX (EX_SEQ);
           6560
.
                                                                     ! "SEQUENTIAL"
          6561
6562
                                                                       "DATAGRAM"
                                   #0'2']: PRINTX (EX_CRD);
.
                                                                     ! "CREDIT NOTIFICATION"
                                                                                                                PACKET TYPE
           6563
                                   (#0'15'): PRINTX (EX_MTN);
                                                                     ! "MAINTENANCE"
           6564
                                   (OTHERWISE): PRINTX (XX37, .RP_ADDR [MESTYP]); ! UNKOWN MESSAGE TYPE
           6565
           6566
          6567
6568
                 PRINTB (XX17):
                                                            ! "COMMAND: "
           6569
                 SELECTU (.RP_ADDR [conid]) OF
           6570 SET
.
           6571 [#0'2']:
.
           6572
                     BEGIN
.
                     PRINTB (XX18);
SELECTU (.RP_ADDR [ENDCOD]) OF
           6573
:
                                                                                      ! PRINTS -DUP-
           6574
           6575
                                   SET
           6576
                                   $6'201']: PRINTB (EX_GDS);
           6577
                                   #0'202']: PRINTB (EX_ESP): #0'203']: PRINTB (EX_ELP);
.
                                                                                     ! PRINTS A COMMAND
           6578
:
                                   #6'205'): PRINTB (EX_RCD);
           6579
           6580
           6581
                                   #0'206']: PRINTB (EX_ABP);
           6582
                                   OTHERWISE]: PRINTB (EX_OP, .RP_ADDR [ENDCOD]); ! PRINT ENDCODE VALUE
           6583
           6564
                     printb (xx15);
.
                                                                                               ! "status:"
                     IF (.RP_ADDR [STSCOD] GEQU 0) AND (.RP_ADDR [STSCOD] LEQU 7)
THEN PRINTB (.EBH_TB1 [.RP_ADDR [STSCOD]])
           6585
:
                                                                                               ! IF STATUS CODE IS WITHIN RANGE
           6586
                                                                                               ! PRINTB APPROPRIATE MESSAGE
           6587
                     ELSE
                              PRINTB (ex_op. .RP_ADDR [STSCOD]);
                                                                                      ! JUST PRINT STATUS CODE
```

```
SEQ 0212
ZRQAM2
                  RD/RX EXERCISER
                                                                          5-Dec-1983 10:27:14
5-Dec-1983 10:27:04
                                                                                                     VAX-11 Bliss-16 V3-555
                                                                                                                                              Page 212
V01.2
                  ERROR MESSAGE SUBROUTINES
                                                                                                     DISK#USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (66)
           6588
           6589
                       IF .RP_ADDR [ENDCOD] EQL #0'204' or
                          .RP_ADDR [ENDCOD] EQL #0'205'
           6590
                                                                                         ! IF A SEND DATA OR RECEIVE DATA COMMAND THEN
           6591
           6592
                           PRINTX (XX25, .RP_ADDR [BCNT_LO]); ! FOR ANY "ACTUAL # OF BYTES TRANSFERRED: XXXXX."
PRINTX (XX26, .RP_ADDR [BUFF_1], .RP_ADDR [BUFF_0]); ! "I/O BUFFER DESCRIPTOR: XXXXXX XXXXXX"
           6593
                                                                                  ! FOR ANY "ACTUAL # OF BYTES TRANSFERRED: XXXXX."
           6594
           6595
                           EMS_DUP ():
                                                                                            ! prints contents of dup packet
           6596
                           end:
                       IF .RP_ADDR [ENDCOD] EQL #0'201'
           6597
:
           6598
:
           6599
                           begin
           6600
                           if BIT_TST (RP_ADDR [9, 8, 1, 0], 1)
.
                           then PRINTB (dF_0);
if BIT_TST (RP_ADDR [9, 9, 1, 0], 1)
           6601
.
           6602
.
                           then PRINTB (df_1);
if BIT_TST (RP_ADDR [9, 10, 1, 0], 1)
           6603
.
           6604
                           then PRINTB (df_2);
if BIT_TST (RP_ADDR [9, 11, 1, 0], 1)
           6605
           6606
           6607
                                then PRINTB (df_3);
           6608
:
           6609
:
           6610
                       IF .RP_ADDR [ENDCOD] EQL #0'203'
                                                                                          ! IF A GET DUST STATUS OR EXEC. LOCAL PRG COMMAND TH
EN
           6611
:
                       then
           6612
                           begin
.
           6613
                           if BIT_TST (RP_ADDR [9, 8, 1, 0], 1)
.
           6614
                                then PRINTB (dF_4);
:
                           if BIT_TST (RP_ADDR [9, 9, 1, 0], 1)
           6615
                           then PRINTB (df 5);
if BIT_TST (RP_ADDR [9, 10, 1, 0], 1)
           6616
           6617
           6618
                           then PRINTB (df_6);
if BIT_TST (RP_ADDR [9, 11, 1, 0], 1)
           6619
           6620
                                then PRINTB (df_7);
           6621
           6622
                       PRINTX (XX23, .CST_ADDR [.CUOFF + 5, D_DBN], .CST_ADDR [.CUOFF + 5, D_DBN]);
                                                                                                                     ! "DBN: XXXXXX."
           6623
                       END:
:
           6624
6625
                 [#0'0']:
.
                       BEGIN
           6626
                       PRINTB (XX19);
                                                                         !PRINTS -MSCP-
                                                                                                                                                   !MSC
           6627
                       SELECTU (.RP_ADDR [ENDCOD]) OF
           6628
                                    SET
           6629
                                     (%0'204']: PRINTB (EX_SCC);
                                     MO'211' ]: PRINTB (EX_ONL);
           6630
           6631
6632
                                     #0'220']: PRINTB (EX_ACC):
                                     (#0'241'): PRINTB (EX_RD);
                                                                                           ! PRINTS THE COMMAND
           6633
           6634
                                     [OTHERWISE]: PRINTB (EX_OP, .RP_ADDR [ENDCOD]); ! PRINT ENDCODE VALUE
           6635
           6636
                       if .RP_ADDR [CHDMOD] eq1 MD_CMP THEN PRINTB (XX20); ! PRINTS THE MODIFIER IF NECESSARY
           6637
                       PRINTB (XX15);
           6638
                                                                         ! STATUS:
           6639
                       if (.ST_CODE gtru 0) and (.ST_CODE legu 11)
                                                                         ! IF STATUS CODE IS WITHIN RANGE
           6640
```

```
SEQ 0213
PROAM2
                  RD/RX EXERCISER
                                                                          5-Dec-1983 10:27:14
                                                                                                    VAX-11 Bliss-16 V3-555
                                                                                                                                              Page 213
V01.2
                  ERROR MESSAGE SUBROUTINES
                                                                          5-Dec-1983 10:27:04
                                                                                                    DISK $USER2: [DIETZ.RDRX]ZRQACO.BL1:82 (66)
           6641
                           PRINTB (.ERR_COD [.ST_CODE - 1])
           6642
                                                                             ! PRINTB APPROPRIATE MESSAGE
           6643
                       else
           6644
           6645
                           if .ST_CODE eql ST_DIA
           6646
           6647
                                    PRINTB (.ERR_COD [11])
                                                                                  ! MESSAGE FROM INTERNAL DIAGNOSTICS
           6648
                           else
           6649
                                    PRINTB (EX_OP, .ST_CODE);
                                                                                  ! JUST PRINT STATUS CODE WHEN NO MATCH
           6650
           6651
                      EMS_SBC ():
                                                                                  ! PRINTS STATUS SUB-CODE
           6652
:
           6653
                       IF .RP_ADDR [ENDCOD] EQLU #0'220' OR
                                                                                                                                          ! MSCP acces
  command
S
           6654
                               .RP_ADDR [ENDCOD] EQLU #0'241' OR
.
                                                                                                                                          ! mscp read
           6655
                               .RP_ADDR [ENDCOD] EQLU #0'242'
                                                                                                                                          ! mscp write
           6656
                       THEN
           6657
                                    begin
                                    6658
           6659
           6660
           6661
           6662
           6663
                                             PRINTB (XX21, .RP_ADDR [BBLK_HI], .RP_ADDR [BBLK_LO]) ! "BAD BLOCK REPORTED: XXXXXX."
           6664
           6665
                                             printX (XX22, .RP_ADDR [LBN_LO], .RP_ADDR [LBN_HI], .RP_ADDR [LBN_LO]);
                                                                                                                                         ! "LBN: XXXX
XX"
:
           6666
                                    PRINTB (XX41);
if BIT_TST (RP_ADDR [FLAGS], EF_1)
           6667
:
                                                                                ! IF BAD BLOCK UNREPORTED
           6668
                                         then PRINTB (F_1);
.
                                    if BIT_TST (RP_ADDR [FLAGS], EF_2)
then PRINTB (F_2);
           6669
                                                                                ! IF ERROR LOG GENERATED
           6670
                                     IF BIT_TST (RP_ADDR [FLAGS], EF_3)
           6671
                                                                                ! IF SERIOUS EXCEPTION
           6672
                                         then PRINTB (F_3);
                                    END:
           6673
           6674
                       IF .RP_ADDR [ENDCOD] EQLU #0'204'
                                                                                                                                ! MSCP SET CTLR CHAR
command
           6675
.
           6676
                           begin
           6677
                                    PRINTB (XX39);
           6678
                                    if BIT_TST (RP_ADDR (BCNT_HI), EF_4)
                                                                                  ! IF
                                    then PRINTB (F_4);
if BIT_TST (RP_ADDR [BCNT_HI], EF_5)
           6679
           6680
                                                                                  ! IF
                                    then PRINTB (F_5);
if BIT_TST (RP_ADDR (BCNT_HI), EF_6)
then PRINTB (F_6);
if BIT_TST (RP_ADDR (BCNT_HI), EF_7)
then PRINTB (F_7);
if BIT_TST (RP_ADDR (BCNT_HI), EF_8)
then PRINTB (F_8);
if BIT_TST (RP_ADDR (BCNT_HI), EF_8)
           6681
           6682
                                                                                  ! IF
           6683
           6684
                                                                                  ! IF
           6685
           6686
                                                                                  ! IF
           6687
                                    if BIT_TST (RP_ADDR (BCNT_HI], EF_9)
then PRINTB (F_9);
if BIT_TST (RP_ADDR (BCNT_HI], EF_10)
then PRINTB (F_10);
           6688
                                                                                  ! IF
           6689
           6690
           6691
           6692
                      IF .RP_ADDR [ENDCOD] EQLU #0'211'
           6693
```

```
SEQ 0214
ZRQAM2
                     RD/RX EXERCISER
                                                                                       5-Dec-1983 10:27:14
                                                                                                                      VAX-11 Bliss-16 V3-555 Page 214 DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (66)
                                                                                                                      VAX-11 Bliss-16 V3-555
                     ERROR MESSAGE SUBROUTINES
                                                                                       5-Dec-1983 10:27:04
V01.2
             6694
                           THEN
                                                                                                                                                      ! MSCP ONLINE comman
d
             6695
                                begin
.
                                           PRINTB (XX40);
             6696
                                           IF BIT_TST (RP_ADDR [BCNT_HI], EF_11)
             6697
                                           then PRINTB (F_11);
if BIT_TST (RP_ADDR [BCNT_HI], EF_12)
             6698
             6699
                                                                                                ! IF
                                           then PRINTB (F_12);
if BIT_TST (RP_ADDR [BCNT_HI], EF_13)
then PRINTB (F_13);
             6700
             6701
                                                                                                ! IF
             6702
                                           if BIT_TST (RP_ADDR [BCNT_HI], EF_14)
             6703
                                                                                                ! IF
             6704
                                                then PRINTB (F_14);
                                           if BIT_TST (RP_ADDR [BCNT_HI], EF_15)
             6705
                                                                                                ! IF
                                           then PRINTB (F_15);
if BIT_TST (RP_ADDR [BCNT_HI], EF_16)
             6706
             6707
                                                                                                ! IF
                                          if BIT_TST (RP_ADDR [BCNT_HI], EF_16)
then PRINTB (F_16);
if BIT_TST (RP_ADDR [BCNT_HI], EF_17)
then PRINTB (F_17);
if BIT_TST (RP_ADDR [BCNT_HI], EF_18)
then PRINTB (F_18);
if BIT_TST (RP_ADDR [BCNT_HI], EF_19)
then PRINTB (F_19);
if BIT_TST (RP_ADDR [BCNT_HI], EF_20)
then PRINTB (F_20);
if BIT_TST (RP_ADDR [BCNT_HI], EF_21)
then PRINTB (F_21);
             6708
             6709
                                                                                                ! IF
             6710
             6711
                                                                                                ! IF
             6712
             6713
             6714
             6715
                                                                                                ! IF
             6716
             6717
                                                                                                ! IF
                                                then PRINTB (F_21);
             6718
             6719
                                end:
                           END:
             6720
             6721
                     tes:
             6722
                                                                PRINTS RETURN OR MESSAGE PACKET IN A BLOCK OF OCTAL WORDS
             6723
             6724
             6725
                     !PRINTX (XX27):
                                                                           ! "CONTENTS OF PACKET:"
                                                                             PRINT BLOCK OF WORDS AS LONG AS A MESSAGE PACKET INCASE A PACKET IS USED INSTEAD OF A RETURN PACKET
             6726
                     !EMS_BLK (.RP_ADDR, PKT_LEN);
             6727
             6728
                     !PRINTX (XX42);
                                                                           ! PRINTS CONTENTS OF DUP I/O PACKET
             6729
                     !EMS_BLK (DUPPKT, 3);
             6730 PRINTB (CRLF);
                                                                           ! PRINTS CARRIAGE RETURN AFTER ERROR MESSAGE
             6731 end;
                                                      ! ROUTINE EMSCMD
010554
                                                                 .PSECT
                                                                          *CODE *.
                                                     EBH. TB1: . WORD
           000000G
010554
                                                                           EBH.30
010556
           000000G
                                                                 . WORD
                                                                           EBH.44
010560
           000000G
                                                                  WORD
                                                                           EBH.45
010562
           000000G
                                                                           EBH.46
                                                                 . WORD
010564
           000000G
                                                                  WORD
                                                                           EBH.47
010566
           000000G
                                                                 WORD
                                                                           EBH.48
010570
           000000G
                                                                 WORD
                                                                           EBH.49
                                                                 SBTTL EMSCMD ERROR MESSAGE SUBROUTINES
000000 004137 000000G
                                                     EMSCMD:: JSR
                                                                           R1. $SAVE3
                                                                                                                                                                            6535
```

					11		
ZRQAM VO1.2	2	RD/RX EXERCISER ERROR MESSAGE SUBROUTINE	ES		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL	SEQ 0215 Page 215 1;82 (66)
00000 00001 00001	012746	000000G 00000G 000002		MOV MOV MOV	CDISK,-(SP) #XX13,-(SP) #2,-(SP)		6554
00002 00002 00002	010600	00002		MOV	SP.RO	; SP.4	
00002	013700	00000G 00004		MOV	RP.ADDR.RO 4(RO).(SP)	•	6556
00003- 00004- 00004-	012746	000006 00000G 000003		MOV MOV MOV	6(RO),-(SP) exx35,-(SP)		
00005 00005 00005	010600			MOV TRAP	#3,-(SP) SP,RO 15	; SP.*	
00006	012746	000000G 000001		MOV	#XX29,(SP) #1,-(SP)	•	6557
00006 00007	104415	000000G		MOV TRAP MOV	SP.RO 15 RP.ADDR.RO	; SP.*	6558
00007 00010 00010	1 116002	000002		MOVB	2(RO),R2 R2	•	6536
00010	006202			ASR ASR	R2 R2		
00010 00011 00011	012702	177760 177777		ASR BIC MOV	R2 #177760,R2 #-1,R1		
00012 00012	005702			BNE	R2		
00012	012716	000000G 000001		CLR MOV MOV	R1 #EX.SEQ.(SP) #1,-(SP)		6560
00013	010600			MOV	SP.RO	; SP.4	
00014 00014 00015	020227	000001	14:	TST CMP BNE	(SP)+ R2.#1 2\$		6558
00015	005001	000000G		CLR	R1 #EX.DGM.(SP) #1(SP)		6561
00016 00016 00016	010600	000001		MOV MOV TRAP	#1(SP) SP.RO 15	; SP.*	
00017	005726	000002	26:	TST	(SP)+ R2,#2		6558
00017	0.05001	000000G		CLR	R1		
00020	012716 012746 010600 104415	000001		MOV MOV	#EX.CRD,(SP) #1,-(SP) SP,R0	: SP.*	6562
00020 00020 00021 00021 00022	104415 005726 0020227	000015	74.	TRAP	15 (SP)+		
00022	6 005001	000015	34:	CMP BNE CLR	R2.015 46 R1		6558
00023	012716	000000G 000001		MOV	#EX.MTN.(SP)		6563

ZRQAM2 VO1.2		RD/RX EXERCISER ERROR MESSAGE SUBROUT	TNES		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;	Page 216
		EMMON TIESSAGE SOBROOT	1140		J-Dec-1905 10:27:04	DISK FOSERZ: [DIE12. RDRA JZRGACO. BLI;	02 (66)
000240 000242 000244 000246 000250	010600 104415 005726			MOV TRAP TST	SP.RO 15 (SP)+	; SP,*	
000246	005701 001422		4\$:	TST BEQ	R1 5#	•	6558
000252	013700	00000G		MOV	RP.ADDR.RO		6564
000250 000252 000256 000262 000264 000270 000270	116001	000002		MOVB	2(RO),R1		
000264	006201			ASR ASR	R1 R1		
000266	006201 006201			ASR	R1		
000270	006201	177760		ASR	R1		
000272	042701	177760		BIC	#177760,R1 R1.(SP)		
000300 000304 000310 000312 000314 000316	012746	00000G		MOV	4XX37,-(SP)		
000304	012746	000002		MOV	#2,-(SP) SP,RO		
000310	104415			MOV	SP.RO 15	; SP,*	
000314	010600 104415 022626 012716			CMP	(SP)+.(SP)+		
000316	012716	00000G	5\$:	MOV	(SP)+,(SP)+ #XX17,(SP)		6567
000322	012746	000001		MOV	#1(SP) SP.RO	; SP.*	
000322 000326 000330 000332 000336 000340 000340	104414			TRAP	14	1 37,4	
000332	013700	00000G		MOV	RP.ADDR,RO	1	6569
000336	104414 013700 005003 156003 020327 001402	000003		CLR BISB	R3		
000344	020327	000002		CMP	3(RO),R3 R3,02		
000350	001402			BEQ	6#		
000352	000137	012256'		JMP	26\$		
000362	012716 012746	000000G 000001	6\$:	MOV	#XX18.(SP) #1(SP)		6573
000366	010600			MOV	SP,RO	; SP,*	
000352 000356 000362 000366 000370 000372	104414	0000000		TRAP	14		
000376	005002	00000G		MOV	RP.ADDR,RO		6574
000400	156002 012701	000014 177777		BISB	14(RO),R2		
000404	012701	177777		MOV	#-1,R1		
000414	020227 001010 005001	000201		CMP BNE	R2. #201		
000416	005001			CLR	R1		
000420	012716	000000G		MOV	●EX.GDS.(SP)	•	6576
000424 000430	012746 010600	000001		MOV	#1,-(SP) SP.RO	: SP.*	
000432	104414 005726			TRAP	14	1 37,0	
000432 000434 000436 000442	005726	000000		TST	(SP)+		
000442	001010	000202	76:	CMP BNE	R2.0202	1	6574
000444 000446	020227 001010 005001			CLR	R1		
000446	012716	00000G		MOV	ØEX.ESP.(SP)		6577
000452 000456	012746 010600	000001		MOV	41(SP)	. 60 4	
000460	104414			MOV	SP.RO	; SP.4	
000462	005726			TST	(SP)+		
000464	020227	000203	84:	CMP	R2,#203		6574

					1/1		
701.2		RD/RX EXERCISER ERROR MESSAGE SU	BROUTINES		5-Dec-1983 10:27:1 5-Dec-1983 10:27:0	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQAG	SEQ 0217 Page 217 CO.BL1:82 (66)
000470	001010			DNE			
000470	001010 005001			BNE	9\$ R1		
000474	012716	000000G		MOV	ØEX.ELP.(SP)		6578
000500	01.2746	000001		MOV	#1(SP)		6376
000504	010600			MOV	SP,RO	; SP,*	
000506	104414			TRAP	14		
000510	005726			TST	(SP)+		
000504 000506 000510 000512	005726 020227	000205	9\$:	CMP	R2,#205		6574
000516	001010 005001			BNE	10\$		
000516 000520	005001			CLR	R1		
000522 000526	012716	00000G		MOV	#EX.RCD,(SP)		6579
000526	012746	000001		MOV	#1(SP) SP.RO		
000532 000534 000536 000540 000544	010600 104414			MOV	SP.RO	: SP.*	
100534 100536	104414			TRAP	14		
100536	005726 020227	000204	10\$:	TST	(SP)+ R2,#204		4574
000544	001010	000204	104:	CMP BNE	11\$	•	6574
000546	005001			CLR	RI		
M M I TO TO I	012716	000000G		MOV	₩EX.SDD,(SP)		6580
000554	012746	000001		MOV	#1,-(SP)		0300
000554 000560 000562 000564 000566 000572	010600			MOV	SP.RO	; SP.*	
200562	104414			TRAP	14		
000564	005726			TST	(SP)+		
00566	104414 005726 020227	000206	114:	CMP	R2.#206	1	6574
00572	001010 005001			BNE	124		
000574	005001			CLR	R1		
91 CUUL	012716	000000G		MOV	MEX.ABP.(SP)		6581
000602	012746 010600	000001		MOV	#1(SP) SP,RO	co .	
000610	104414			MOV TRAP	14	; SP.4	
000612	104414 005726			TST	(SP)+		
000614	005701		124:	TST	R1		6574
000616	001414			BEQ	134		0314
000620	013700	00000G		MOV	RP.ADDR.RO		6582
000624	005016			CLR	(SP)		
000626	116016	000014 000000G		MOVB	14(RO),(SP) #EX.OP,-(SP)		
000632	012746	000000G		MOV	WEX.OP,-(SP)		
000636	012746	000002		MOV	#2(SP)		
000642	010600			MOV	SP.RO	; SP.4	
000644 000646 000650 000654 000660 000662	104414 022626 012716 012746			TRAP	14		
000650	012716	0000000	174.	CMP	(SP)+,(SP)+		6584
000654	012746	000000G 000001	136:	MOV	#XX15.(SP) #1(SP)	•	6364
000660	010600	000002		MOV	SP.RO	: SP.4	
000662	104414			TRAP	14	1 0 1	
JUU004	010600 104414 013700	000000G		MOV	RP.ADDR,RO		6585
000670	116000	000016		MOVB	16(RO),RO		
000670 000674	116000 042700	177740		BIC	#177740.RO		
000700	020027	000007		CMP	RO.#7		
000704	101010			BHI	148		
000706	006300	010551		ASL	RO		6586
000710	016016	010554		MOV	EBH. TB1(RO),(SP)		
000714	012746	000001		MOV	#1,-(SP)		

ZRQAM2 VO1.2		RD/RX EX	KERCISER ESSAGE SUBROUTIN	ES		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Property of the Propert	0218 age 218 (66)
000720 000722	010600 104414				MOV	SP.RO	: SP,*	
000724	000410			443	BR	15\$		6585
000726	010016			14:	MOV	15\$ RO,(SP) #EX.OP,-(SP)		6587
000730	012746	000000G			MOV	#EX.OP, -(SP)		
000734	012746	000002			MOV	#2,-(SP) SP,RO	<b>co</b> .	
000742	010600				MOV TRAP	14	; SP,*	
000744	104414 005726				TST	(SP)+		1 - 1 - 1
000746	013700	000000G		15\$:	MOV	RP.ADDR.RO	사용하다는 경험에 가장 없는 사람들이 살아보다 그를 받다.	6500
000752	126027	000014	000204	257.	CMPB	14(RO).#204	•	6589
000760	001404				BEQ	16#		
000762	126027	000014	000205		CMPB	14(RO), #205		6590
000770	001032				BNE	17\$		0570
000772	013700	000000G		16#:	MOV	RP.ADDR.RO 20(RO),(SP)		6593
000776	016016	000020			MOV	20(RO),(SP)		
001002	012746	000000G			MOV	#XX25,-(SP)		
001006	012746	000002			MOV	#2,-(SP)		
001012 001014	010600				MOV	SP.RO	; SP.*	
001014	104415	0000000			TRAP	15		
001016	013700 016016	000000G 000024			MOV	RP.ADDR,RO		6594
001026	016046	000024			MOV	24(R0),(SP) 26(R0),-(SP) #XX26,-(SP)		
001032	012746	000000G			MOV	AVV26 -(SD)		
001032 001036	012746	000003			MOV	#3,-(SP)		
001042	010600	00000			MOV	SP.RO	: SP,*	
001044	104415				TRAP	15	1 35.4	
001046 001052	004737	000000V			JSR	PC.EMS.DUP		6595
001052	062706	000012			ADD	412,SP		6592
001056	013700	000000G		178:	MGV	RP.ADDR.RO		6597
001062	126027	000014	000201		CMPB	14(R0),4201		
001070	001062				BNE	21\$		
001072	032760 001407 012716	000400	000022		BIT	#400,22(R0)		6600
001100	001407				BEQ	18#		
001102	012716	000000G			MOV	#DF.0,(SP)		6601
001112	010600	000001			MOV	#1,-(SP)		
001114	104414				MOY TRAP	SP.RO	: SP.4	
001116	005726				TST	(SP)+		i
001120	013700	000000G		184:	MOV	RP. ADDR. RO		6602
001124 001132 001134	032760		000022	201.	BIT	#1000,22(R0)		9002
001132	001407				BEQ	19#		
001134	012716	000000G			MOV	#DF.1.(SP)		6603
001140 001144	012746	000001			MOV	#1,-(SP)	그렇게 되었다.	-
001144	010600				MOV	SP.RO	; SP.4	
001146 001150	104414				TRAP	14		
001150	005726				TST	(SP)+		
001152 001156	013700	000000G	000000	198:	MOV	RP.ADDR.RO		6604
001156	032760	002000	000022		BIT	#2000,22(RO)		
001164 001166	001407 012716	000000G			BEQ	204		
001172	012716	0000000			MOV	#DF.2,(SP)		6605
001176	010600	000001			MOV	#1,-(SP)	. 60 4	
302213	020000				1104	SP.RO	: SP.4	

						111		
ZRQAM2		RD/RX EXE	RCTSER			5-Dec-1983 10-27-14	VAY-11 Blice-16 V3-555	SEQ 0219
V01.2		ERROR MES	SAGE SUBROUT	INES		5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO	.BL1;82 (66)
001200	104414				TRAP	14		
001202 001204 001210	005726				TST	(SP)+		
001204	013700	00000G		20\$:	MOV	RP.ADDR.RO		6606
001210	032760	004000 00	00022		BIT	#4000,22(RO)		0000
001216	001407				BEQ	21\$		
001216	012716	000000G			MOV	#DF.3,(SP)		6607
001224	012746	000001			MOV	#1,-(SP)		
001230	010600				MOV	SP,RO	; SP,*	
001232	104414 005726				TRAP	14		
001234	005726				TST	(SP)+		
001236	013700	000000G		21\$:	MOV	RP.ADDR.RO		6610
001242	126027	000014 0	00203		CMPB	14(RO),#203		
001250	001062				BNE	25\$		
001252	032760	000400 0	00022		BIT	4400,22(RO)		6613
001260	001407				BEQ	22\$		
001262	012716	00000G			MOV	4DF.4.(SP)	:	6614
001266	012746	000001			MOV	#1(SP) SP,R0		
001272	010600				MOV	SP.RO	; SP,*	
001274	010600 104414 005726				TRAP	14		
001276	005726				TST	(SP)+		
001234 001230 001232 001234 001236 001242 001250 001252 001260 001262 001266 001272 001274 001276 001300 001304	013700	000000G		22\$:	MOV	RP.ADDR.RO		6615
001304	032760	001000 0	00022		BIT	<b>#1000,22(R0)</b>		
001312	001407				BEQ	23#		
001314	012716	000000G			MOV	#DF.5,(SP)		6616
001320	012746	000001			MOV	41,-(SP)		
001304 001312 001314 001320 001324 001326 001330 001332 001336 001344 001346 001352	012746				MOV	SP,RO	; SP.*	
001326	104414 005726				TRAP	14		
001330	005726				TST	(SP)+		
001332	013700	000000G		234:	MOV	RP.ADDR.RO #2000.22(RO)		6617
001336	032760	002000 0	00022		BIT	#2000,22(R0)		
001344	001407				BEQ	24\$		
001346	012716 012746	00000G			MOV	#DF.6.(SP) #1,-(SP)		6618
001352	012746	000001			MOV	41,-(SP)		
AAT330	010600				MOV	SP.RO	; SP.*	
001360	104414				TRAP	14		
001362	005726				TST	(SP)+		
001364	013700	000000G	*****	24\$:	MOV	RP.ADDR.RO		6619
001370	032760 001407	004000 0	00022		BIT	#4000,22(R0)		
001376	001407	000000			BEQ	251		
001400	012716	000000G			MOV	#DF.7,(SP)		6620
001404	012/46	000001			MOV	#1,-(SP)		
001410	010600				MOV	SP.RO	; SP.*	
001412	104414				TRAP	14		
001414	013700	0000000		054	TST	(SP)+		
001433	006700	000000G		25#:	MOV	CUOFF,RO	•	6622
001414 001416 001422 001424	005726 013700 006300 063700	0000000			ASL	RO CST ADDR BO		
001430	005016	00000G			ADD	CST. ADDR, RO		
001432	005016	000013			CLR	(SP)		
001436	116016	000012			MOVB	12(RO),(SP)		
001436	005046	000012			CLR	-(SP)		
001440	116016	000012			MOVB	12(RO).(SP)		
001450	012746 012746	000000G			MOV	#XX23,-(SP)		
001430	012140	000003			MOV	#3,-(SP)		

N1

ZRQAM2 VO1.2		RD/RX EXERCISER ERROR MESSAGE SUBROUTI	NES		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL	SEQ 0220 Page 220 .1;82 (66)
001454	010600			MOV	SP,RO	; SP.*	
001456	104415			TRAP	15		
001460	062706	000014		ADD	#14.SP		6572
001464	005703		26\$:	TST	R3		6569
001466	001402	0147221		BEQ	27\$		
001470 001474 001500 001504 001506 001510 001514 001516 001522 001526 001532 001534 001536 001542 001546 001550 001552 001554 001560 001562 001570 001570 001576	012716	014322' 000000G	27\$:	JMP	66\$		
001500	012746	000001	214:	MOV	#XX19,(SP)	•	6626
001504	010600	000001		MOV	#1,-(SP) SP,RO	; SP.*	
001506	104414			TRAP	14	; 57,*	
001510	013700	000000G		MOV	RP.ADDR.RO		6627
001514	005002			CLR	R2		1200
001516	156002	000014		BISB	14(RO),R2		
001522	012701	177777		MOV	#-1,R1		
001526	020227	000204		CMP	R2,#204		
001532	001010 005001			BNE	28\$		
001534	005001			CLR	R1		
001536	012716	00000G		MOV	#EX.SCC.(SP) #1(SP)	:	6629
001542	012746	000001		MOV	#1,-(SP)		
001546	010600			MOV	SP.RO	; SP.*	
001550	104414			TRAP	14		
001554	005726 020227 001010	000211	28\$:	TST	(SP)+		
001560	001010	OODELL	204:	BNE	R2.#211 29\$	1	6627
001562	005001			CLR	R1		
001564	012716	00000G		MOV	WEX.ONL,(SP)		6670
001570	012746	000001		MOV	#1(SP)		6630
001574	010600			MOV	SP.RO	; SP.*	
001576	104414			TRAP	14	1 57 1-	
001600	005726			TST	(SP)+		
001602	020227	000220	29\$:	CMP	R2.#220		6627
001606	001010			BNE	30#		
001610	005001			CLR	R1		
001612	012716	000000G		MOV	MEX.ACC.(SP)		6631
001616 001622	012746	000001		MOV	#1(SP) SP.RO		
00000	104414			MOV	SP, RO	: SP.*	
001626	005726			TRAP	14 (SP)+		
001630	020227	000241	304:	CMP	R2,#241		*****
001634	001010		301.	BNE	31\$	•	6627
001636	005001			CLR	R1		
001640	012716 012746	000000G		MOV	#EX.RD.(SP)		6632
001644	012746	000001		MOV	#1,-(SP)		0032
001650	010600			MOV	SP.RO	; SP.4	
001652	104414			TRAP	14		
001654	005726			TST	(SP)+		
001624 001636 001634 001636 001640 001650 001652 001654 001656 001662 001664	020227	000242	314:	CMP	R2, #242	1	6627
001662	001010			BNE	324		
001666	005001	0000000		CLR	R1		
001672	012716	000000G		MOV	ØEX.WRT.(SP)	•	6633
001676	012746	000001		MOV	#1,-(SP)		
001700	104414			MOV	SP.RO	; SP.*	
002.00	104414			INAP	A-7		

ZRQAM2 VO1.2	RD/RX EXERCISER ERROR MESSAGE SUBROUTINES	•	5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 PDISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82	0221 age 221 (66)
001702 005726		TST	(SP)+		
001704 005701 001706 001414	3	324: TST BEQ	R1 33#	1	6627
001710 013700	000000G	MOV	RP.ADDR.RO		6634
001714 005016		CLR	(SP)		9034
001716 116016	000014	MOVB	14(RO),(SP)		
001722 012746 001726 012746	00000G 000002	MOV	0EX.0P,-(SP)		
001726 012746 001732 010600 001734 104414 001736 022626	000002	MOV	02,-(SP) SP,RO	: SP. 4	
001734 104414 001736 022626		TRAP	14	, 5,,,	
001736 022626		CMP	(SP)+,(SP)+		
001740 013700 001744 026027	000000G 3	33\$: MOV	RP. ADDR, RO		6636
001752 001007	000012 040000	CMP BNE	12(RO),#40000 34\$		
001754 012716	000000G	MOV	exx20.(SP)		
001760 012746	000001	MOV	01,-(SP)		
001754 012716 001760 012746 001764 010600 001766 104414		MOV	SP.RO	; SP.*	
001770 005726		TRAP	14 (SP)+		
001772 012716	000000G 3	545: MOV	0XX15.(SP)		6638
AA4 776 A4 A746	000001	MOV	#1,-(SP)		0030
002002 010600		MOV	SP.RO	; SP. 4	
002004 104414 002006 013700	00000G	TRAP	ST.CODE.RO		
002012 001413	000000	BEQ	35\$		6639
002014 020027	000013	CMP	RO, #13		6640
002020 101010		BHI	35#		
002022 006300 002024 016016	177776G	ASL MOV	RO	1	6642
002030 012746	000001	MOV	ERR.COD-2(RO),(SP) #1,-(SP)		
002034 010600		MOV	SP,RO	: SP. 4	
AACA30 TA4414		TRAP	14		
002040 000422 002042 020027	000037	BR SS4: CMP	37\$		6639
002046 001007	3	SS4: CMP BNE	RO. #37 36#		6645
002050 013716		MOV	ERR.COD+26.(SP)		6647
002054 012746	000001	MOV	#1,-(SP)		
002060 010600 002062 104414		MOV	SP.RO	; SP.4	
002064 000410		TRAP BR	14 37¢		6645
002066 010016	3	564: MOV	RO.(SP)		6645 6649
002070 012746	000000G	MOV	<b>⊕</b> EX.OP,-(SP)		
002074 012746 002100 010600	000002	MOV	#2,-(SP)	•	
002102 104414		HOV TRAP	SP,RO	; SP.4	
002104 005726		TST	(SP)+		
002106 004737	010044'	578: JSR	PC.EMS.SBC		6651
002112 013700 002116 116000	00000G	MOV	RP.ADDR, RO	1	6653
002122 042700	000014 177400	MOVB	14(RO),RO #177400,RO		
AAFTER AFAAFI	000220	CMP	RO. #220		
002132 001406		BEQ	38#		
002134 020027	000241	CMP	RO,#241	1	6654

ZRQAM2 VO1.2		RD/RX EX	KERCISER ESSAGE SUBROUTINES		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.	SEQ 0222 Page 222 BL1;82 (66)
002140 002142	001403	000242		BEQ	38\$		
002146	001154	000242		BNE	RO. #242		6655
002150	013700	000000G	381		RP.ADDR.RO		6658
002154	016016	000044		MOV	44(RO),(SP)		0050
002160	012746	000000G		MOV	exx24,-(SP)		
002164	012746	000002		MOV	#2,-(SP) SP,RO		
002172	104415			TRAP	15	; SP.4	
002174	013700	000000G		MOV	RP.ADDR.RO		6659
002200	016016	000050		MOV	20(RO),(SP)		
002200 002204 002210 002214	012746	00000G		MOV	exx25,-(SP)		
002214	012746	000002		MOV	02,-(SP) SP,R0	: SP.*	
002216	104415			TRAP	15	; 57.*	
002220	013700	000000G		MOV	RP.ADDR.RO		6660
002224	016016	000024		MOV	24(RO),(SP)		0000
002230	016046 012746	000026		MOV	26(RO),-(SP)		
002224 002230 002234 002240	012746	00000G 000003		MOV	#XX26,-(SP)		
002244	010600	00000		MOV	SP.RO	: SP.*	
002240 002244 002246 002250 002264 002262 002266 002272 002276 002304 002304	104415			TRAP	15	1 5 1	
002250	013700	000000G		MOV	RP.ADDR.RO		6661
002254	005760 100013	000014		TST	14(RO)		
002262	016016	000040		BPL	394 40(RO),(SP)		****
002266	016046	000042		MOV	42(RO),-(SP)		6663
002272	012746	000000G		MOV	0XX21,-(SP)		
002276	012746	000003		MOV	#3,-(SP)		
002302	010600 104414			MOV	SP.RO	; SP. 4	
002306	000415			BR	14		6661
ANESTA	OTOOTO	000050	390		50(RO),(SP)		6661 6665
002314	016046	000052		MOV	52(RO),-(SP)		0005
002320 002324	016046 012746	000050 000000G		MOV	50(RO),-(SP)		
002330	012746	0000004		MOV	0XX22,-(SP)		
002334	010600	000004		MOV	44,-(SP) SP.RO	: SP	
002336	104415			TRAP	15	. 5	
002340	005726	******		TST	(SP)+		
002342	012716 012746	000000G 000001	400		exx41.(SP)		6666
002352	010600	000001		MOV	♦1(SP) SP,R0		
002354	104414			TRAP	14	: SP.4	
002356	104414	000000G		MOV	RP.ADDR.RO		6667
002362	032760	040000	000014	BIT	040000,14(RO)		
002324 002330 002334 002336 002342 002346 002352 002354 002356 002362 002370 002372	001407 012716	000000G		BEQ	416		
002376	012746	0000001		MOV	<pre>#F.1,(SP) #1,-(SP)</pre>	•	6668
002402 002404				MOV	SP.RO	: SP.*	
002404	104414			TRAP	14		
002406	005726	0000000		TST	(SP)+		
002410	013700	000000G	410	: MOV	RP.ADDR,RO		6669

ZRQAM2 VO1.2		RD/RX EXERCISER ERROR MESSAGE SUBRO	OUTINES		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.	SEQ 0223 Page 223 .BL1;82 (66)
002414	032760	020000 000014		BIT			
002422	001407	0000005		BEQ	421		
002424 002430	012716	000000G 000001		MOV	0F.2,(SP) 01,-(SP)	•	6670
002434	010600	00000		MOV	SP.RO	; SP.*	
002436	104414			TRAP	14		
002440 002442	005726	000000G	421:	TST	(SP)+ RP.ADDR,RO		****
002446	032760	010000 000014	727.	BIT	A10000 14(DO)	•	6671
002454	001407			BEQ	436		
002456 002462	012716	00000G 000001		MOV	0F.3,(SP)	1	6672
002466	010600	000001		MOV	#1,-(SP) SP,RO	; SP. *	
002466 002470	104414			TRAP	14		
002472 002474	005726 062706	000036	474.	TST	(SP)+		
002500	013700	000026 000000G	43\$:	MOV	#26,SP RP.ADDR,RO		5657
002504	126027	000014 000204	****	CMPB	14(RO), #204		6674
002512	001144			BNE	52\$		
002500 002504 002512 002514 002520 002526 002530 002534 002540 002542 002554 002556 002560 002564	012716	00000G 000001		MOV	exx39,(SP)	1	6677
002524	010600	000001		MOV	#1(SP) SP.RO	: SP. *	
002526	104414			TRAP		1 37.1	
002530	013700	000000G		MOV	RP.ADDR.RO		6678
002540	105760 100007	000022		TSTB BPL	22(RO) 45#		
002542	012716	000000G		MOV			6679
002546	012746	000001		MOV	0F.4.(SP) 01(SP)		0017
002552	010600 104414			MOV	SP,RO	; SP. 4	
002556	005726			TRAP	14 (SP)+		
002560	013700	000000G	454:	MOV	RP. ADDR. RO		6680
002564	032760	000100 000022		BIT	RP.ADDR.RO #100,22(RO)		0000
002574	001407	000000G		BEQ	461 46 5 (CD)		
002600	012746	000001		MOV	0F.5,(SP) 01,-(SP)		6681
002604 002606 002610	010600			MOV	SP,RO	; SP. 4	
002610	104414			TRAP	14		
002612	013700	000000G	461:	TST	(SP)+ RP.ADDR,RO		6682
002612 002616	032760	000040 000022		BIT	440,22(RO)		0002
002624	001407	0000000		BEQ	476		
002632	012716 012746 010600	000000G 000001		MOV	0F.6.(SP)	1	6683
002636	010600	000001		MOV	#1,-(SP) SP,RO	: SP. *	
002640	104414			TRAP	14		
002642	005726	0000000	474	TST	(SP)+		
002616 002624 002632 002636 002640 002642 002644 002650 002666	013700 032760	000000G 000020 000022	476:	BIT	RP.ADDR,RO #20,22(RO)		6684
002656	001407			BEQ	481		
002660	012716	000000G		MOV	0F.7,(SP)		6685
002664 002670	012746	000001		MOV	#1,-(SP)		
002010	010000			MOV	SP.RO	; SP.4	

ZRQA VO1.		RD/RX EXERCISER ERROR MESSAGE SUBROL	ITTNES		5-Dec-1983 10:27:14	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.B	SEQ 0224 Page 224
		ERROR FIESSAGE SOBROC	, TITES		3-066-1903 10:27:04	DIBLACSENS: [ DIE 12 . MONY JSMMWCO . R	r1:05 (00)
0026	72 104414			TRAP	14		
0026	74 005726			TST	(SP)+		
0026		000000G	48\$:	MOV	RP.ADDR.RO 22(RO).RO		6686
0027	02 016000	000055		MOV	22(RO),RO		
0027	06 042700	077777		BIC	477777,RO		
0027	12 020027	100000		CMP	RO.#-100000		
0027 0027	16 001007 20 012716	000000G		BNE	491		****
0027	24 012746	000001		MOV	0F.8,(SP)	1	6687
0027 0027 0027 0027	30 010600	000001		MOV	#1,-(SP) SP,R0	: SP.*	
0027	32 104414			TRAP	14	; 35,4	
0027	34 005726			TST	(SP)+		
0027	36 013700	000000G	491:	MOV	RP.ADDR,RO		6688
0027	42 032760	000002 000022		BIT	42,22(RO)		0000
0027 0027 0027 0027	50 001407			BEQ	50#		
0027	52 012716	00000G 000001		MOV	0F.9,(SP)	1	6689
0027	56 012746	000001		MOV	#1,-(SP)		
0027	62 010600			MOV	SP.RO	; SP.4	
0027	64 104414			TRAP	14		
0027	66 005726	******		TST	(SP)+		
0027	70 013700	000000G	50#:	MOV	RP.ADDR.RO		6690
0027	74 032760	000001 000022		BIT	#1,22(RO)		
0030	001407	0000000		BEQ	514		
0030	012716	00000G 000001		MOV	9F.10,(SP)	•	6691
0027 0027 0030 0030 0030	14 010600	000001		MOV	#F.10,(SP) #1,-(SP) SP,R0		
00.50	104414			TRAP	14	; SP.4	
0030	20 005726			TST	(SP)+		
0030	22 005726		514:	TST	(SP)+		6676
0030	24 013700	000000G	524:	MOV	RP.ADDR.RO		6693
0030 0030 0030 0030	30 126027	000014 000211		CMPB	14(RO),#211		0075
0030	36 001402			BEQ	534		
0050	140 000137	014316'		JMP	65#		
0030	44 012716	000000G	534:	MOV	0XX40,(SP)	1	6696
0030	50 012746	000001		MOV	#1,-(SP) SP.RO		
0030	010600			MOV	SP.RO	: SP.4	
0030	56 104414	0000000		TRAP	14		
0030	060 013700 064 032760			MOV	RP. ADDR.RO		6697
0030	72 001407	000001 000022		BIT	01.22(RO)		
0030	74 012716	000000G		MOV	544 45 11 (SP)		4400
0030 0031	74 012716 00 012746	000001		MOV	<b>0F.11.(SP)</b> <b>01(SP)</b>		6698
0031	010600			MOV	SP.RO	: SP.+	
0031	06 104414			TRAP	14		
0031	10 005726			TST	(SP)+		
0031 0031 0031	12 013700	00000G	541:	MOV	RP.ADDR.RO		6699
0031	16 032760	000005 000055		BIT	#2,22(RO)		
0031 0031 0031	24 001407			BEQ	55#		
0031	26 012716	00000G		MOV	0F.12,(SP)		6700
0031	32 012746	000001		MOV	#1,-(SP)		
0031	36 010600			MOV	SP.RO	1 SP.4	
0031	40 104414			TRAP	14		
0031	42 005726			TST	(SP)+		

ZRQAM2 VO1.2	RD/RX EXERCISER ERROR MESSAGE SUBROUTINE	s	5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Page DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (66	25 225
003144 013700 003150 016000 003154 042700 003160 020027 003164 001007 003166 012716	000000G 000022 077777 100000	55\$: MOV MOV BIC CMP BNE	RP.ADDR.RO 22(RO).RO #77777.RO RO.#-100000 56#		6701
003166 012716 003172 012746 003176 010600 003200 104414 003202 005726 003204 013700 003210 032760 003216 001407 003220 012716 003224 012746 003230 010600 003232 104414 003234 005726 003236 013700 003242 105760 003246 100007 003250 012716 003254 012746 003264 005726 003266 013700 003262 104414 003264 005726 003266 013700 003272 032760 003300 001407 003300 001407 003300 0012746 003312 010600 003312 010600	000000G 000001	MOV MOV MOV TRAP TST	#F.13,(SP) #1,-(SP) SP,R0	; SP,*	6702
003204 013700 003210 032760 003216 001407	000000G 040000 000022	564: MOV BIT BEQ	(SP)+ RP.ADDR.RO #40000,22(RO) 57#		6703
003220 012716 003224 012746 003230 010600	000000G 000001	MOV MOV MOV	(SP)+ RP.ADDR,RO #40000,22(RO) 57# #F.14,(SP) #1,-(SP) SP.RO 14 (SP)+ RP.ADDR,RO 22(RO) 58# #F.15,(SP) #1,-(SP) SP.RO 14	: SP.*	6704
003232 104414 003234 005726 003236 013700	000000G	TRAP TST 57\$: MOV	(SP)+ RP.ADDR,RO		6705
003242 105760 003246 100007 003250 012716	0000022 000000G	TSTB BPL MOV	22(RO) 58# #F.15,(SP)		6706
003254 012746 003260 010600 003262 104414	000001	MOV MOV TRAP	01,-(SP) SP.RO 14	: SP.+	
003264 005726 003266 013700 003272 032760 003300 001407	000000G 004000 000022	58\$: MOV BIT BEQ	14 (SP)+ RP.ADDR,RO #4000,22(RO) 59\$ #F.16,(SP) #1,-(SP) SP.RO 14 (SP)+ RP.ADDR.RO		6707
003302 012716 003306 012746 003312 010600	000000G 000001	MOV MOV MOV	#F.16.(SP) #1(SP) SP.RO	: : SP.*	6708
003316 005726 003320 013700	000000G	TRAP TST 594: MOV	*** ***********************************		6709
003332 001407	000000G	BEQ MOV	#2000,22(R0) 60# #F.17,(SP)		6710
003340 012746 003344 010600 003346 104414 003350 005726	000001	MOV MOV TRAP	#1,-(SP) SP,RO 14	: SP.*	
003340 012716 003340 012746 003344 010600 003346 104414 003350 005726 003352 013700 003356 032760 003364 001407 003366 012716 003372 012746 003376 010600 003400 104414 003402 005726 003404 013700 003410 032760	000000G 000100 000022	604: MOV BIT BEQ	(SP)+ RP.ADDR.RO #100,22(RO) 61#		6711
003366 012716 003372 012746 003376 010600	000000G 000001	MOV MOV MOV	#F.18.(SP) #1,-(SP) SP,R0	: SP.*	6712
003376 010600 003400 104414 003402 005726 003404 013700	000000G	TRAP TST 614: MOV	14 (SP)+ RP.ADDR,RO	, 57,5	6713
003410 032760 003416 001407	020000 000022	BIT	#20000,22(R0) 62#		5.10

ZRQAM2 VO1.2	RD/RX EXERCISER ERROR MESSAGE SUBROUTINES	5-Dec-1983 10:2 5-Dec-1983 10:2	7:14 VAX-11 Bliss-16 V3-555
003420 012716 003424 012746 003430 010600 003432 104414	000001	MOV #F.19.(SP) MOV #1(SP) MOV SP.RO TRAP 14	: 6714 : SP.*
003434 005726 003436 013700 003442 032760 003450 001407	000000G 010000 000022	TST (SP)+ MOV RP.ADDR,RO BIT #10000,22(RO) BEQ 63#	i 6715
003452 012716 003456 012746 003462 010600 003464 104414	000001	MOV #F.20,(SP) MOV #1,-(SP) MOV SP,RO TRAP 14	: 6716 : SP.*
003466 005726 003470 013700 003474 032760 003502 001407	000000G 000004 000022 63\$:	TST (SP)+ MOV RP.ADDR.RO BIT #4,22(RO) BEQ 64#	: 6717
003504 012716 003510 012746 003514 010600 003516 104414	000001	MOV #F.21,(SP) MOV #1,-(SP) MOV SP,RO TRAP 14	: 6718 : SP.*
003520 005726 003522 005726 003524 062706 003530 012716 003534 012746	000006 65\$: 00000G 66\$:	TST (SP)+ TST (SP)+ ADD #6.SP MOV #CRLF.(SP)	: 6695 : 6625 : 6730
003540 010600 003542 104414 003544 062706 003550 000207		MOV #1(SP) MOV SP.RO TRAP 14 ADD #22.SP RTS PC	; SP, 4 : 6546 : 6535

<sup>:</sup> Routine Size: 949 words. Routine Base: #CODE# + 10572 : Maximum stack depth per invocation: 29 words

```
SEQ 0227
                                                                                                                      5-Dec-1983 10:27:14 VAX-11 Bliss-16 V3-555 Page 2
5-Dec-1983 10:27:04 DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (67)
ZRQAM2
                  RD/RX EXERCISER
ERROR MESSAGE SUBROUTINES
                                                                                                                                                                                                                             Page 227
V01.2
                  6732 !+
                  6733 GLOBAL ROUTINE EMS_DBN : NOVALUE =
:
                  6734 !+
:
                  6735 !
                                         THIS ROUTINE PRINTS THE PRESENT DBN
.
                  6736
6737
.
                                      IMPLICIT INPUTS:
                  6738 !
                                         CST_ADDR - ADDRESS OF CONTROLLER STATUS TABLE
                  6739 !-
                  6740 BEGIN
                6740 BEGIN
6741 PRINTB (XX13, .CDISK);
6742 PRINTB (XX23, .CST_ADDR [.CUOFF + 5, D_DBN], .CST_ADDR [.CUOFF + 5, D_DBN]);
6743 PRINTB (XX32, .S_DUPPKT - 2);
6744 PRINTB (XX33, .S_PATTERN);
6745 PRINTB (XX34, .(DUPPKT + .S_DUPPKT), .(DUPPKT + .S_DUPPKT));
6746 PRINTB (XX34, .(DUPPKT + .S_DUPPKT), .(DUPPKT + .S_DUPPKT));
6747 PRINTS THE WORD READ
6746 PRINTS THE WORD READ
6747 END;
6747 PRINTS THE WORD READ
6748 PRINTS THE WORD READ
6749 PRINTS THE WORD READ
6749 PRINTS THE WORD READ
6740 PRINTS THE WORD READ
6741 PRINTS THE WORD READ
6741 PRINTS THE WORD READ
6742 PRINTS THE WORD READ
6743 PRINTS THE WORD READ
6744 PRINTS THE WORD READ
6745 PRINTS THE WORD READ
6746 PRINTS THE WORD READ
6747 PRINTS THE WORD READ
6748 PRINTS THE WORD READ
6749 PRINTS THE WORD READ
6749 PRINTS THE WORD READ
6740 PRINTS THE WORD READ
6740 PRINTS THE WORD READ
6741 PRINTS THE WORD READ
6742 PRINTS THE WORD READ
6743 PRINTS THE WORD READ
6744 PRINTS THE WORD READ
6745 PRINTS THE WORD READ
6746 PRINTS THE WORD READ
6747 PRINTS THE WORD READ
6747 PRINTS THE WORD READ
6748 PRINTS THE WORD READ
6749 PRINTS THE WORD READ
6749 PRINTS THE WORD READ
6749 PRINTS THE WORD READ
6740 PRINTS THE WORD READ
6741 PRINTS THE WORD READ
6741 PRINTS THE WORD READ
.
.
:
:
:
.
.
:
                                                                                        .SBTTL EMS.DBN ERROR MESSAGE SUBROUTINES
                                                  EMS.DBN::
000000 013746 000000G
                                                                                                      CDISK, -(SP)
                                                                                                                                                                                                                                           6741
000004 012746 000000G
                                                                                        MOV
                                                                                                      4XX13,-(SP)
000010 012746
                            000002
                                                                                       MOV
                                                                                                      #2,-(SP)
SP,R0
000014 010600
                                                                                       MOV
                                                                                                                                                                 : SP. .
000016 104414
000020 013700 000000G
000024 006300
                                                                                        TRAP
                                                                                       MOV
                                                                                                      CUOFF, RO
                                                                                                                                                                                                                                          6742
                                                                                                                                                                 :
                                                                                        ASL
                                                                                                       RO
000026 063700 000000G
                                                                                                      CST. ADDR, RO
                                                                                        ADD
000032 005016
                                                                                        CLR
                                                                                                       (SP)
000034 116016 000012
                                                                                       MOVB
                                                                                                       12(RO),(SP)
000040 005046
                                                                                       CLR
                                                                                                       -(SP)
000042 116016 000012
                                                                                                       12(RO),(SP)
                                                                                       MOVB
000046 012746 000000G
                                                                                                      #XX23,-(SP)
                                                                                       MOV
000052 012746 000003
                                                                                       MOV
000056 010600
                                                                                                       SP.RO
                                                                                       MOV
                                                                                                                                                                 : SP. *
000060 104414
000062 013716 000000G
000066 162716 000002
000072 012746 000000G
000060
                                                                                        TRAP
                                                                                                       14
                                                                                       MOV
                                                                                                       S.DUPPKT, (SP)
                                                                                                                                                                                                                                           6743
                                                                                        SUB
                                                                                                       #2.(SP)
                                                                                       MOV
                                                                                                       ♦XX32, -(SP)
000076 012746
                             000002
                                                                                                      #2.-(SP)
SP.RO
                                                                                       MOV
000102 010600
                                                                                       MOV
                                                                                                                                                                 : SP. .
000104 104414
                                                                                        TRAP
                                                                                                       14
000106 013716 000000G
                                                                                       MOV
                                                                                                       S.PATTERN. (SP)
                                                                                                                                                                                                                                           6744
                                                                                                                                                                 .
000112 012746 000000G
                                                                                       MOV
                                                                                                       4XX33,-(SP)
000116 012746
                            000002
                                                                                                       42,-(SP)
                                                                                       MOV
000122 010600
                                                                                       MOV
                                                                                                       SP,RO
                                                                                                                                                                 : SP. .
000124 104414
                                                                                        TRAP
000126
              013700 000000G
                                                                                                       S.DUPPKT.RO
                                                                                       MOV
                                                                                                                                                                                                                                           6745
000132
                             000000G
              016016
                                                                                                       DUPPKT(RO),(SP)
                                                                                       MOV
000136
                                                                                                      (SP),-(SP)

#XX34,-(SP)
              011646
                                                                                       MOV
000140 012746
                             000000G
                                                                                       MOV
000144 012746
                             000003
                                                                                       MOV
                                                                                                       #3,-(SP)
000150 010600
                                                                                       MOV
                                                                                                       SP,RO
                                                                                                                                                              : SP. 4
```

_	_	144	_
п		-	`
- 1			,
		-	

ZRQAM2 VO1.2		RD/RX EXERCISER ERROR MESSAGE SUBROUTINES		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL	SEQ 0228 Page 228 1;82 (67)
000154 000160	104414 012716 012746 004737	000002G 000400 000000V	TRAP MOV MOV	14 #DUPPKT+2,(SP) #400,-(SP)		6746
000170	062706 000207	000034	JSR ADD RTS	PC.EMS.BLK #34.SP PC	:	6740 6733

<sup>:</sup> Routine Size: 63 words, Routine Base: \$CODE\$ + 14344 : Maximum stack depth per invocation: 15 words

```
SEQ 0229
ZRQAM2
                  RD/RX EXERCISER
                                                                           5-Dec-1983 10:27:14
                                                                                                      VAX-11 Bliss-16 V3-555
                                                                                                                                                Page 229
V01.2
                  ERROR MESSAGE SUBROUTINES
                                                                           5-Dec-1983 10:27:04
                                                                                                      DISK $USER2: [DIETZ.RDRX]ZRQACO.BL1:82 (68)
           6748 ROUTINE EMS_DUP : NOVALUE =
           6749 !+
.
           6750
                            THIS ROUTINE PRINTS OUT THE LISTING OF THE DUP PACKETS ONLY ASSOCIATED WITH DUP RECEIVED DATA COMMAND
:
           6751
                            AND TE SEND DATA COMMAND.
                  .
.
           6752
:
           6753 begin
:
           6754
                  OWN
           6755
                           MESSAGETYPE : VECTOR [6] INITIAL (T_QUE, T_DEF, T_INF, T_TER, T_FAT, T_SPL),
MSGNUMBERS : VECTOR [9] INITIAL (M_TER, M_BIN, M_COD, M_DAT, M_UR, M_URP, M_UP, M_UL, M_ASC),
RCD_ERRORS : VECTOR [5] INITIAL (ebh_30, E_UNT, E_BLK, E_DEV, E_ZER);
! TABLE OF BASIC, HARD ERROR MESSAGE ADDRESSES, INDEXED BY STATUS CODE
           6756
           6757
           6758
           6759
           6760
           6761 PRINTB (XX29):
                                                                                             ! PRINTS DUP MESSAGE TYPE
           6762
                  if (.duppkt [duptype] leau 6)
           6763
                  then
           6764
                       PRINTB (.MESSAGETYPE [.DUPPKT [DUPTYPE] - 1])
           6765
                 else
.
           6766
                       printb (ex_op, .duppkt [duptype]);
:
           6767
:
           6768 PRINTB (XX30):
                                                                                            ! PRINTS DUP MESSAGE NUMBER
:
           6769
                  if (.duppkt [dupmesg] lssu 9)
           6770
                  then
                       PRINTB (.MSGNUMBERS [.DUPPKT [DUPMESG] - 1])
           6771
:
           6772
                  else
           6773
                       printb (ex_op, .duppkt [dupmesg]);
           6774
           6775 PRINTB (XX31):
                                                                                             ! PRINTS DUP BUFFER 1 WHICH SOMETIMES IS AN
           6776
                  IF (.DUPPKT [DUPBF1] LSSU 5)
                                                                                             ! ERROR MESSAGE
                  THEN
           6777
           6778
                       PRINTB (.RCD_ERRORS [.DUPPKT [DUPBF1]])
            6779
            6780
                       PRINTB (EX_MRD, .DUPPKT [DUPBF1]);
:
            6781
           6782 end;
.
014542 000000G
                                              MESSAGETYPE:
                                                        . WORD
                                                                 T.QUE
014544 000000G
                                                                 T.DEF
                                                         WORD
014546
         000000G
                                                        . WORD
                                                                 T. INF
014550
         000000G
                                                        . WORD
                                                                 T. TER
014552
014554
         000000G
                                                         WORD
                                                                 T.FAT
         000000G
                                                         WORD
                                                                T.SPL
014556
         000000G
                                              MSGNUMBERS:
                                                        . WORD
                                                                 M. TER
014560 000000G
                                                         . WORD
                                                                 M.BIN
014562
         000000G
                                                        . WORD
                                                                 M. COD
014564
         000000G
                                                        . WORD
                                                                 M. DAT
014566 000000G
                                                        . WORD
                                                                 M. UR
014570 000000G
                                                                 M. URP
                                                        . WORD
014572 000000G
                                                        . WORD
                                                                 M.UP
014574 000000G
                                                        . WORD
                                                                 M.UL
```

K2

ZRQAM2 VO1.2		RD/RX EXERCISER ERROR MESSAGE SUBROUTIN		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.	SEQ 0230 Page 230 BL1;82 (68)
014576 014600	000000G		RCD.ERRORS:	M. ASC		
014602 014604	000000G 000000G		. WORD . WORD . WORD	EBH.30 E.UNT E.BLK		
014606 014610	000000G 000000G		. WORD . WORD	E.DEV E.ZER		
000000	012746	000000G	.SBTTL EMS.DUP:MOV	EMS.DUP ERROR MESSAGE SUBROUTI	NES	
000004	012746	000001	MOV	#1,-(SP) SP,R0	: SP,*	6761
000012	104414 013700 006200	000000G	TRAP MOV	14 DUPPKT.RO		6762
000020	006200		ASR ASR ASR	RO RO		
000026	006200		ASR SWAB	RO RO		
000032 000036 000042	042700 020027 101010	177760 000006	EIC CMP BHI	#177760,RO RO.#6 1\$		
000010 000012 000014 000020 000022 000024 000026 000030 000032 000036 000042 000044 000046 000052 000056 000060 000062	101010 006300 016016	014540'	ASL MOV	RO MESSAGETYPE-2(RO),(SP)	1	6764
000052 000056 000060	012746 010600 104414	000001	MOV MOV TRAP	#1,-(SP) SP.RO 14	; SP.4	
000062 000064	010600 104414 000410 010016		1#: BR MOV	2\$ RO,(SP)	:	6762 6766
000066 000072 000076	012746 012746 010600	00000G 000002	MOV MOV MOV	#EX.OP,-(SP) #2,-(SP) SP,R0	; SP.*	
000100	104414		TRAP	14 (SP)+	; 3r.•	
000104 000110 000114	012716 012746 010600	000000G 000001	24: MOV	#XX30,(SP) #1,-(SP)		6768
000116	104414	000000G	MOV TRAP MOV	SP.RO 14 DUPPKT.RO	; SP.4	6769
000124 000130 000134 000136	013700 042700 020027 103010 006300	170000 000011	BIC	#170000,R0 R0,#11		
000136 000140	006300 016016	014554	BHIS ASL MOV	RO MSGNUMBERS-2(RO),(SP)		6771
000140 000144 000150 000152 000154 000156	016016 012746 010600 104414	000001	MOV	#1,-(SP) SP,R0	; SP.4	
000154 000156	010016		TRAP BR 34: MOV	14 48 RO,(SP)	:	6769 6773
000164	012746 012746	00000G 000002	MOV	#EX.OP(SP)		
000170	010600		MOV	SP.RO	; SP.4	

		-	
		-	٦
		-	,
L	_		

	ZRQAM2 VO1.2	RD/RX EXERCISER ERROR MESSAGE SUBROUTIN	ES		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL	SEQ 0231 Page 231 .1;82 (68)
erialist for the time or an artist of the con-	000172 104414 000174 005726 000176 012716 000202 012746	000000G 000001	48:	TRAP TST MOV MOV	14 (SP)+ #XX31,(SP) #1,-(SP)		6775
	000206 010600 000210 104414 000212 013700 000216 020027 000222 103010	000002G 000005		MOV TRAP MOV CMP BHIS	SP.RO 14 DUPPKT+2.RO RO.#5 5#	: SP.*	6776
	000224 006300 000226 016016 000232 012746 000236 010600	014600' 000001		ASL MOV MOV MOV	RO RCD.ERRORS(RO),(SP) #1,-(SP) SP,RO	; SP.*	6778
	000240 104414 000242 000410 000244 010016 000246 012746 000252 012746	000000G 000002	5#:	TRAP BR MOV MOV MOV	14 6\$ RO,(SP) #EX.WRD,-(SP) #2,-(SP)	:	6776 6780
	000256 010600 000260 104414 000262 005726 000264 062706	000016	68:	MOV TRAP TST ADD	SP.RO 14 (SP)+ #16.SP	; SP.*	6753
-	000270 000207	07		RTS	PC	•	6748

Routine Size: 93 words. Routine Base: \$CODE\$ + 14612 : Maximum stack depth per invocation: 10 words

```
SEQ 0232
ZRQAM2
                RD/RX EXERCISER
                                                                   5-Dec-1983 10:27:14
                                                                                           VAX-11 Bliss-16 V3-555
                                                                                                                                Page 232
V01.2
                ERROR MESSAGE SUBROUTINES
                                                                   5-Dec-1983 10:27:04
                                                                                           DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (69)
          6783 global routine EMS_BLK (ADDR, LENGTH) : novalue =
          6784
.
          6785 !+
.
          6786
                         THIS ROUTINE WILL PRINTX A BLOCK OF MEMORY WHICH IS "LENGTH" WORDS
               .
:
          6787 !
                        LONG STARTING AT ADDRESS "ADDR". PRINTING IS DONE IN OCTAL. 8 WORDS
;
          6788
                         TO A LINE.
:
          6789 !-
          6790
.
          6791
                    begin
:
          6792
.
          6793
                    literal
:
          6794
                        MASK = #0'7':
:
          6795
                PRINTX (CRLF):
:
          6796
                     incr COUNT from 1 to .LENGTH do
                                                                 ! FOR EACH WORD TO PRINT
:
          6797
                        begin
          6798
.
                         if ((.COUNT - 1) and MASK) eql 0
          6799
                                                                 ! IF AT START OF A NEW LINE
.
          6800
                         then
.
                            PRINTX (SPACE4);
          6801
                                                                  ! PRINTX 4 SPACES
.
          6802
:
          6803
                         PRINTX (EX_WRD, ..ADDR);
                                                                  ! PRINTX A WORD
          6804
                         ADDR = .ADDR + 2;
                                                                  ! ADVANCE TO NEXT ADDRESS
          6805
.
          6806
                         if (((.COUNT and MASK) eql 0) or
.
                                                                 ! IF AT THE END OF A LINE OR
                            (.COUNT eql .LENGTH))
          6807
:
                                                                 ! WHEN DONE
          6808
.
                         then
          6809
                            PRINTX (CRLF);
                                                                  PRINTX <CR><LF>
          6810
.
          6811
.
                         end;
          6812
.
          6813
:
                    end:
                                                  .SBTTL EMS.BLK ERROR MESSAGE SUBROUTINES
000000 010146
                                         EMS.BLK::
                                                          R1,-(SP)
                                                                                                                                    6783
200000
        012746
                000000G
                                                 MOV
                                                          #CRLF, -(SP)
                                                                                                                                    6795
                                                                                           :
000006
        012746
                000001
                                                 MOV
                                                          #1,-(SP)
000012 010600
                                                          SP.RO
                                                 MOV
                                                                                           : SP. .
000014 104415
                                                 TRAP
000016
        005001
                                                 CLR
                                                          R1
                                                                                           : COUNT
                                                                                                                                     6796
000020
                                                 BR
        000445
                                                          5$
000022
        010100
                                         18:
                                                 MOV
                                                          R1,RO
                                                                                           : COUNT. *
                                                                                                                                     6799
000024
        005300
                                                 DEC
                                                          RO
000026
        032700
                000007
                                                 BIT
                                                          47.RO
000032
        001007
                                                  BNE
000034
                000000G
        012716
                                                          #SPACE4,(SP)
                                                 MOV
                                                                                                                                     6801
                                                                                           .
000040
        012746
                000001
                                                 MOV
                                                          #1,-(SP)
000044
        010600
                                                          SP.RO
                                                 MOV
                                                                                           : SP. +
000046
        104415
                                                  TRAP
000050
        005726
                                                          (SP)+
                                                 TST
000052
        017616
                000012
                                                 MOV
                                                          812(SP),(SP)
                                         21:
                                                                                           : ADDR. +
                                                                                                                                     6803
000056
        012746
                000000G
                                                          MEX. WRD, -(SP)
                                                 MOV
```

	-
NI	)
ıv	-

 ZRQAM2 VO1.2		RD/RX EX ERROR ME	KERCISER ESSAGE SUBROUTINE	s		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL	SEQ 0233 Page 233 1:82 (69)
000062 000066 000070 000072 000100 000104 000106 000112 000114 000120	012746 010600 104415 062766 032701 001403 020166 001007 012716 012746 010600	000002 000007 000014 000000G 000001	000016	3\$:	MOV MOV TRAP ADD BIT BEQ CMP BNE MOV MOV	#2(SP) SP.R0 15 #2.16(SP) #7.R1 3\$ R1.14(SP) 4\$ #CRLF.(SP) #1(SP) SP.R0	: SP,*  : *.ADDR : *.COUNT : COUNT, LENGTH :	6804 6806 6807 6809
000126 000130 000132 000134 000136 000142 000144 000146 000150	104415 005726 022626 005201 020166 003727 022626 012601 000207	000010			TRAP TST CMP INC CMP BLE CMP MOV RTS	15 (SP)+ (SP)+,(SP)+ R1 R1,10(SP) 1\$ (SP)+,(SP)+ (SP)+,R1 PC	COUNT COUNT, LENGTH	6797 6796 6791 6783

<sup>:</sup> Routine Size: 53 words. Routine Base: \$CODE\$ + 15104 : Maximum stack depth per invocation: 8 words

ZRQAM2 VO1.2	RD/RX EXERCISER ERROR MESSAGE SUBROUTINES	5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 Page 2 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (70)	234
: 681	ROUTINE EMS_MAL : NOVALUE =			
: 681 : 681	THIS ROUTINE PRINTS ALL TABLES	IN AN EFFORT TO FIND THE MISSIN	G MESSAGE OR THE PROBLEM	
: 682 : 682 : 682	PRINTB (EB_DCT,dct); L EMS_BLK (DCT, DCT_LEN);	! PRINT " DCT TABLE CO ! PRINT BLOCK OF WORDS	NTENTS"	
682 682 682	PRINTB (EB_COMM, .DCT [0, RR_BEG]); EMS_BLK (.DCT [0, RR_BEG] - 4, COMM_LEI	! PRINT "COMMAND RING" ! PRINT BLOCK	AND STARTING ADDR OF COMMAND RING	
; 682	PRINTB (EBNEX1, .DCT [O, RR_POLL]);	PRINT ADDR OF	COMMAND OF NEXT RR POLL	
: 682 : 682	PRINTB (EB_NEX2,DCT (O, RR_POLL) -	B); !PRINT	ADDR OF PACKET TO BE POLLED	
: 682 : 683 : 683	PRINTB (EBNEX3, .DCT [0, CR_POLL] - 8) PRINTB (EB_PKT); PRINTB (CB_PKT);	PRINT ADDR OF PRINTS "PACKETS IN ME FOR EACH MSCP ENVELO	PACKET TO BE POLLED PE	
: 683	begin EMS_BLK ((MSCP_PKT [.COUNT, 0,0	0.16.0]), PKT_LEN); !PRINT	S CONTENTS OF PACKETS	
: 683	end; printb (EB_SA); printb (ex_wrd, .(172150)); end;	! "Contents of SA Regis! Contents of sa regis	ster" ter	
000000 01014	EMS.MAL:MOV	EMS.MAL ERROR MESSAGE SUBROUTI		814
000002 01274 000006 01274	5 00000G MOV 5 00000G MOV	WEB.DCT(SP)		820
000012 01274 000016 01060 000020 10441	MOV MOV TRAP	#2,-(SP) SP,RO 14	: SP. 4	
000022 01271 000026 01274	5 000000G MOV 5 000011 MOV	#DCT,(SP) #11,-(SP)	1 68	821
000042 01274 000046 01274	000000G MOV	PC.EMS.BLK DCT+4.(SP) #EB.COMM(SP) #2(SP)	: 68	823
000052 01060 000054 10441 000056 01371	MOV	SP.RO	: SP. *	
000062 16271 000066 01274	5 000004G MOV 5 000004 SUB 6 000020 MOV	14 DCT+4,(SP) 04,(SP) 020,-(SP)	: 68	824
000072 00473 000076 01371 000102 01274 000106 01274	5 000014G MOV 5 00000G MOV 5 000002 MOV	PC.EMS.BLK DCT+14.(SP) #EBNEX1(SP) #2(SP)		826
000112 01060 000114 10441	TRAP	SP.RO	1 SP.4	
000116 01771 000122 16271		#DCT+14,(SP)	1 66	828

ZRQAM2 VO1.2		RD/RX EXERCISER ERROR MESSAGE SUBROUTINES	5	5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.	SEQ 0235 Page 235 .BL1:82 (70)
000126		00000G	MO			
000132 000136	010600	000002	MO		: SP.4	
000140			TR	IP 14		
000142	013716 162716	000016G 000010	MO		1	6830
000152	012746	000000G	SUI	#10,(SP)		
000156	012746	000002	MO	42(SP)		
000162	010600		MO	SP,RO	; SP,*	
000164 000166	104414 012716	000000G	TR			
000172	012746	000001	MO			6831
000176	010600		MO	SP.RO	; SP, *	
000200	104414		TR			
000202	010116		L\$: MO		; COUNT ; COUNT , 4	6832
000202 000204 000206 000212	062716 012746	000000G	ADI	MSCP.PKT.(SP)	; COONT,=	6834
000212	012746	000042	MO	442,-(SP)		
000216	004737 005726	015104'	JSI TS	PC.EMS.BLK		
000224	062701	000104	ADI		COUNT	6833 6832
000224 000230	020127	001354	CM	R1.01354	: COUNT.+	6032
000234 000236	003763 012716	0000000	BLI	15		
000242	012746	000000G 000001	MO'			6836
000246	010600		MO	SP.RO	: SP. *	
000250	104414	120166	TR	VP 14		
000256	013716 012746	120166 000000G	MO'			6837
000262	012746	000002	MO			
000252 000256 000262 000266 000270	010600		MO	SP.RO	; SP. 4	
000270	104414	000042	TR			
000276	012601	VVVV2	MO			6818 6814
000300	000207		RT			0014

<sup>:</sup> Routine Size: 97 words. Routine Base: #CODE# + 15256 : Maximum stack depth per invocation: 20 words

:

ZRQAM2 VOI.2		RD/RX EXERCISER 5-De ERROR MESSAGE SUBROUTINES 5-De	ec - 1983 ec - 1983	10:27:14 10:27:04	VAX-11 Bliss-16 V3-555 Page 236 DISK*USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (71)
	6840				
:	6841	!•			
:	6842	! THIS ROUTINE PRINTS ALL return packets IN AN	EFFORT '	TO FIND THE	MISSING packet OR THE PROBLEM
	6843	!.			TESTING POUNCE ON THE PRODUCT
	6844	!begin			
	6845	!PRINTB (EB_RAL);			
	6846				
	6847	! begin			
	6848	! EMS_BLK ((RETPKT + .COUNT * RP_LEN) , RP_LEN)	),		! PRINT BLOCK OF WORDS
	6849	! end:			THE PEOCH OF MONDS
:	6850				
	6851				
:	6852				

ZRQAM2 VO1.2		RD/RX EXERCISER ERROR MESSAGE SUBI	ROUTINES		5-Dec-1 5-Dec-1	983 10:27:14 983 10:27:04	VAX-11 Bliss- DISK &USER2: [D	16 V3-555 IETZ.RDRX]ZRQACO.BL	SEQ 0237 Page 237 .1;82 (72)
:	6853	routine EMS_LBN :	novalue =						
:	6854								
:	6855 6856		THE DOTHTS (EV	TENDED)	ONE OF THE BLOCK	MI MOEDS ADDEAD	THE TH		
:	6857	THE CURREN	NT RETURN PACK	ET. NORM	ONE OF TWO BLOCK ALLY, THE LBN FIE	LD IS PRINTED.	THIS		
	6858	! FIELD WAS	COPIED INTO T	HE RETUR	N PACKET FROM THE	ASSOCIATED CO	MMAND		
:	6859	! PACKET. H	DWEVER, IF THE	"FLAGS"	FIELD OF THE CUR	RENT RETURN PA	CKET		
:	6860 6861	PRINTED.	"BAD BLUCK RE	PURTED".	THEN THE "FIRST	BAD BLOCK" FIE	LD IS		
:	6862	!							
:	6863	! IMPLICIT	INPUTS:						
	6864		P_ADDR - ADDRE	SS OF TH	E CURRENT RETURN	PACKET			
	6865 6866	!-							
	6867	IF BIT_TST (RE	P_ADDR [FLAGS]	. EF_BBR	)	! IF B	AD BLOCK REPORT	ED	
	6868	then							
:	6869 6870	else	X21RP_ADDR	(BBCK"HI	]RP_ADDR [BBLK	_LO]) ! "BAD	BLOCK REPORTED	: XXXXXX."	
:	6871		X22PP ADDR	[LBN LO]	RP_ADDR [LBN_H	II RP ADDR (	LBN LO1): ! "LBI	N: XXXXXX."	
				.SBTTL	EMS.LBN ERROR ME	SSAGE SURPOUTT	NEC		
000000		00000G	EMS.LBN		RP.ADDR.RO	33/102 300/100/12	1		6867
000004	005760	000014		TST	14(RO)				
000010 000012		000040		BPL MOV	1\$ 40(RO),-(SP)				6060
000016	016046	000042		MOV	42(RO),-(SP)				6869
000022	012746	000000G		MOV	#XX21,-(SP)				
000026	012746	000003		MOV	#3,-(SP)				
000032 000034 000036	010600 104415			MOV TRAP	SP.RO		; SP.4		
000036	000415			BR	26				6867
000040	016046	000050	18:	MOV	50(RO),-(SP)				6871
000044	016046 016046	000052 000050		MOV	52(RO), -(SP)				
000054	012746	000000G		MOV	50(R0),-(SP) •XX22,-(SP)				
000060 000064	012746	000004		MOV	44,-(SP)				
000064	010600			MOV	SP.RO		: SP.4		
000066 000070	104415			TRAP	15 (SP)+				
000072	062706	000010	24:	ADD	#10.SP				6867
000076	000207			RTS	PC				6853
: Rout i	ne Size.	32 words, R	outine Base:	*CODE .	15560				
; Maxim	um stack	depth per invocat	ion: 7 words	******	13300				

```
SEQ 0238
ZRQAM2
                   RD/RX EXERCISER
                                                                              5-Dec-1983 10:27:14
                                                                                                         VAX-11 Bliss-16 V3-555 Page 238
DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (73)
                                                                                                          VAX-11 Bliss-16 V3-555
V01.2
                   ERROR MESSAGE SUBROUTINES
                                                                             5-Dec-1983 10:27:04
            6872 global routine EMS_EL (index) : novalue =
            6873
:
            6874 !+
:
            6875 !
                             THIS ROUTINE IS CALLED FROM 'SEQUEN' AND 'DATAGM' AND PRINTS THE CONTENTS OF THE
            6876
                  .
                            ERROR-LOG PACKET
.
            6877 !-
            6878
            6879
                       begin
            6880
            6881
                        local
            6882
                            ELOG_ADDR : ref block [EP_LEN, word] field (EP_FIELDS),
:
            6883
                            REASON : word,
                            DISK_NUM : byte.
            6884
            6885
                            ELOG_CODE : byte.
            6886
                            ELOG_SUB : word:
            6887
                       ELOG_ADDR = ELOG_PKT + (.index + EP_LEN + 2);

REASON = .ELOG_ADDR (EL_FORMAT);

DISK_NUM = .ELOG_ADDR (EL_DK_NUM);

ELOG_CODE = .ELOG_ADDR (EL_CODE);

ELOG_SUB = .ELOG_ADDR (EL_SUBCODE);
            6888
                                                                                                ! ERROR LOG PACKET'S ADDRESS
            6889
                                                                                                ! FORMAT
            6890
.
                                                                                                ! DISK NUMBER
            6891
:
                                                                                                ! CODE
            6892
:
                                                                                                ! SUBCODE
            6893
                       PRINTB (ELG_00):
:
                                                                                                ! ERROR-LOG MESSAGE RECEIVED
            6894
            6895
                        if (.REASON eql FORMAT_CNTR) or
            6896
                           (.REASON eql FORMAT_HOST)
.
            6897
                        then
            6898
                            PRINTB (.ELG_FMT [.REASON])
                                                                                                ! PRINT BASIC REASON
            6899
                       else
            6900
                            PRINTB (.ELG_FMT [.REASON], .DISK_NUM);
                                                                                                ! PRINT BASIC REASON WITH DISK NUMBER
            6901
.
                        if (.ELOG_CODE gtru 0) and (.ELOG_CODE legu 11)
            6902
.
            6903
:
            6904
6905
                        then
                            PRINTX (ASTERISK);
PRINTX (.ERR_COD [.ELOG_CODE - 1]);
            6906
            6907
                                                                                                ! CODE
            6908
                            end
            6909
                       else
            6910
            6911
                             if .ELOG_CODE eql ST_DIA
                                                                                                ! MESSAGE FROM INTERNAL DIAGNOSTICS
            6912
                             then
            6913
                                 begin
PRINTX (ASTERISK);
            6914
            6915
                                 PRINTX (.ERR_COD [12]);
            6916
            6917
            6918
                        if (.ELOG_CODE eql ST_MFE) and (.ELOG_SUB legu 10)
            6919
.
            6920
                        then
.
            6921
                            begin
PRINTX (CRLF):
.
            6922
.
            6923
                            PRINTX (ASTERISK);
:
            6924
                            PRINTX (.TBL_MFE [.ELOG_SUB]);
                                                                                                ! MEDIA FORMAT ERROR
```

```
SEQ 0239
ZRQAM2
                   RD/RX EXERCISER
                                                                            5-Dec-1983 10:27:14
                                                                                                       VAX-11 Bliss-16 V3-555 Page 239 DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (73)
                                                                                                        VAX-11 Bliss-16 V3-555
                   ERROR MESSAGE SUBROUTINES
V01.2
                                                                            5-Dec-1983 10:27:04
            6925
                            end:
            6926
                        if (.ELOG_CODE eql ST_DAT) and (.ELOG_SUB lequ 15)
            6927
            6928
            6929
                        then
            6930
                            begin
PRINTX (CRLF):
            6931
            6932
                            PRINTX (ASTERISK):
:
            6933
                            PRINTX (.TBL_DA1 [.ELOG_SUB]);
                                                                                              ! DATA ERROR
            6934
:
            6935
.
            6936
                        if (.ELOG_CODE eql ST_HST) and
:
            6937
                           (.ELOG_SUB legu 4)
:
            6938
:
            6939
                            begin
PRINTX (CRLF):
:
            6940
.
            6941
                            PRINTX (ASTERISK);
:
            6942
                            PRINTX (.TBL_HST [.ELOG_SUB]);
                                                                                              ! HOST ACCESS ERROR
.
            6943
                            end:
:
            6944
:
                        if (.ELOG_CODE eql ST_CNT) and
            6945
.
            6946
                           (.ELOG_SUB legu 3)
            6947
                        then
                            pegin
PRINTX (CRLF);
PRINTX (ASTERISK);
PRINTX (.TBL_CNT [.ELOG_SUB]);
            6948
.
            6949
:
            6950
.
            6951
6952
:
                                                                                              ! CONTROLLER ERROR
.
            6953
:
            6954
                        if (.ELOG_CODE eq1 ST_DRV) and
.
            6955
                           (.ELOG_SUB legu 8)
:
                        then
            6956
:
                            begin
PRINTX (CRLF);
            6957
:
            6958
                            PRINTX (ASTERISK);
            6959
:
            6960
                            PRINTX (.TBL_DRV [.ELOG_SUB]);
.
                                                                                             ! DRIVE ERROR
            6961
.
            6962
6963
:
                        if .REASON eql FORMAT_XFER
:
                                                                                              ! IF DISK XFER INVOLVED
            6964
            6965
:
            6966
                             if .ELOG_ADDR (EL_BLOCK_TYPE) eql TYPE_LBN
.
                                                                                              ! PRINT LBN OR RBN
            6967
.
            6968
                                 PRINTX (XX22, .ELOG_ADDR [EL_BLOCK], O, .ELOG_ADDR [EL_BLOCK])
.
            6969
            6970
                                 PRINTX (EX_RBN, .ELOG_ADDR (EL_BLOCK), O, .ELOG_ADDR (EL_BLOCK));
            6971
            6972
                        PRINTX (CRLF);
.
                        EMS_BLK ((.ELOG_ADDR + 2), ((.ELOG_ADDR [EL_MSGLEN] + 1) / 2) + 2); ! PRINTX CONTENTS OF PACKET ELOG_ADDR [EL_CONTENTS] = EMPTY; ! DECLARE SAVE AREA FREE
            6973
.
            6974
.
            6975
                        PRINTX (CRLF);
.
            6976
:
                        end:
```

					113		CEO 0040
ZRQAM2 VO1.2			ERCISER SSAGE SUBROUTI	NES	5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO	SEQ 0240 Page 240 .BL1;82 (73)
				.SBTT		INES	
000000	004137 0 005746	00000G		EMS.EL::JSR TST	R1, \$SAVE5 -(SP) 20(SP), -(SP) #102, -(SP)		6872
00006	016646 0	00020		MOV	20(SP),-(SP)	: INDEX,*	6888
00012 00016	012746 0 004737 0	00102 00000G		MOV JSR	#102,-(SP)		
00022	062700 0	00000G		ADD	#102,-(SP) PC,BL\$MUL #ELOG.PKT,RO		
00026	010003 005004			MOV	#ELOG.PKT,RO RO,R3 R4 16(R3),R4 12(R3),4(SP) 20(R3),RO #177740,RO	: *,ELOG. ADDR	
00032	156304 0	00016		CLR BISB	16(R3),R4	: REASON : *(ELOG.ADDR), REASON	6889
00036			000004	MOVB	12(R3),4(SP)	: *(ELOG.ADDR).DISK.NUM	6890
00044 00050	042700 1	77740		MOVB	#177740.RO	; *(ELOG.ADDR),*	6891
00054 00056	105002			CLRB	R2	; ELOG.CODE	
00060	050002 016301 0	00020		BIS	20(R3).R1	: *,ELOG.CODE : *(ELOG.ADDR),ELOG.SUB	6892
00064	006201			ASR	R2 R0,R2 20(R3),R1 R1 R1 R1 R1 R1 R1	; ELOG. SUB	0072
00070	006201 006201			ASR ASR	R1 R1	ELOG. SUB	
00066 00070 00072 00074	006201			ASR	R1	ELOG. SUB	
00076	006201 042701 1	74000		ASR BIC	#174000.R1	: ELOG.SUB	
00102	012716 0	00000G		MOV	<b>#ELG.00.(SP)</b>	1	6893
00106 00112 00114	010600	00001		MOV	#1(SP) SP.RO	: SP.*	
00114 00116	104414			TRAP	14		
00120	006305			MOV ASL	R4,R5 R5	; REASON. *	6898
00122	005704 001403			TST	R4	: REASON	6895
00126	020427 0	00001		BEQ	18 R4.01	: REASON. *	6896
00132 00134	001007 016516 0	00000G		14: BNE	ELC EMT(DE) (CD)		
00140	012746 0	000001		MOV	ELG.FMT(R5),(SP)	•	6898
00144 00146	010600 104414			MOV	SP.RO	: SP.*	
00150 00152	000412			BR	36		6895
00152 00154	005016	00006		24: CLR MOVB	(SP)	DTCV NIM A	6900
00160	116616 0 016546 0 012746 0	00000G		MOV	6(SP),(SP) ELG.FMT(R5),-(SP)	: DISK.NUM, *	
00164 00170	012746 0	00002		MOV	42,-(SP) SP,R0	: SP.4	
00172	104414			TRAP	14	: SP.*	
00172 00174 00176	005726 105702			34: TSTB	(SP)+ R2	: ELOG.CODE	6902
00200 00202 00206	001423			BEQ	41		
00202	120227 0 101020	000013		CMPB	R2.013	: ELOG.CODE.+	6903
00210	012716 0	00000G		MOV	#ASTERISK,(SP)		6906
00214	012746 0 010600	000001		MOV	#1,-(SP) SP,R0	: SP.+	
000222	104415			TRAP	15		

ZRQAN VO1.	42	RD/RX EXERCISER ERROR MESSAGE SUBRO	OUTINES		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.8	SEQ 0241 Page 241 L1;82 (73)
0002	26 150200			CLR	RO R2.RO	: ELOG.CODE.*	6907
0002 0002 0002 0002 0002	30 006300 32 016016 36 012746	177776G 000001		ASL MOV MOV	RO ERR.COD-2(RO),(SP) #1,-(SP) SP,RO 15		
0002	42 010600 44 104415 46 000417			MOV TRAP BR	#1(SP) SP.RO 15 5\$ R2.#37	; SP.*	6905
0002	50 120227 54 001015	000037	48:	CMPB BNE	R2,037	: ELOG.CODE,*	6911
0002	56 012716 52 012746 56 010600	000000G 000001		MOV MOV	#ASTERISK.(SP) #1(SP) SP.RO	; SP.*	6914
0005	66 010600 70 104415 72 013716 76 012746	000030G 000001		TRAP		1	6915
0003	02 010600 04 104415	000001		MOV MOV TRAP	#1(SP) SP.RO	: SP.4	
0003	04 104415 06 022626 10 120227	000005	5#: 6#:	CMPB	ERR.COD+30.(SP) #1(SP) SP.RO 15 (SP)+.(SP)+ R2.#5	ELOG.CODE.	6913 6918
0002: 0002: 0002: 0002: 0003: 0003: 0003: 0003: 0003: 0003: 0003: 0003: 0003: 0003: 0003: 0003:	10 120227 14 001031 16 020127 22 101026 24 012716	000012		BNE CMP BHI	R1.012	; ELOG.SUB.*	6919
0003 0003	24 012716 30 012746 34 010600	000000G 000001		MOV MOV MOV	7\$  #CRLF,(SP)  #1,-(SP)  SP,R0  15  #ASTERISK,(SP)		6922
0003	34 010600 36 104415 40 012716 44 012746	000000G 000001		TRAP	15 #ASTERISK.(SP)	; SP.4	6923
0003	50 010600 52 104415	000001		MOV MOV TRAP	#ASTERISK.(SP) #1(SP) SP.RO 15	; SP.4	
0003	54 010100 56 006300			MOV	R1.RO RO	; ELOG.SUB.*	6924
0003	70 010600	000064		MOV MOV TRAP	TBL.MFE(RO),(SP) #1,-(SP) SP,RO	: SP.4	
0003 0004 0004	74 062706	000006 000010	76:	ADD CMPB BNE	15 #6.SP R2.#10 8#	ELOG.CODE.	6921 6927
0004 0004 0004	06 020127 12 101026	000017		CMP	R1.017	: ELOG.SUB.*	6928
0004 0004	14 012716 20 012746 24 010600	000000G 000001		MOV	#CRLF,(SP) #1,-(SP) SP,RO		6931
0004; 0004; 0004; 0004; 0004;	24 010600 26 104415 30 012716	000000G		MOV TRAP MOV	15 #ASTERISK.(SP)	; SP.*	6932
0004 0004 0004	54 012746 40 010600 42 104415	000001		MOV	#1,-(SP) SP,R0	: SP.4	0,02
0004	44 010100 46 006300	0001201		MOV ASL	R1.RO RO	; ELOG.SUB.*	6933
0004	50 016016	0001201		MOV	TBL.DAT(RO),(SP)		

ZRQAM VO1.2	2	RD/RX EXERCISER ERROR MESSAGE SUBROL	UTINES		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.B	SEQ 0242 Page 242 1;82 (73)
00045 00046 00046	0 010600	000001		MOV MOV	#1(SP) SP.RO	; SP,*	
00046 00047 00047	4 062706	000006 000011	84:	TRAP ADD CMPB	15 #6.SP R2.#11	: ELOG.CODE,*	6930 6936
00047	6 020127	000004		BNE CMP BHI	9\$ R1.04 9\$	; ELOG.SUB, *	6937
00050	4 012716 0 012746	000000G 000001		MOV	OCRLF.(SP)		6940
00051 00051	4 010600 6 104415			MOV TRAP	#1,-(SP) SP,R0 15	; SP.*	
00052	0 012716 4 012746	000000G 000001		MOV	#ASTERISK,(SP)	'	6941
00053	0 010600 2 104415 4 010100			TRAP	SP.RO 15 R1.RO	; SP,*	6040
00053	6 006300 0 016016	0001601		MOV ASL MOV	RO TBL.HST(RO),(SP)	; ELOG.SUB,*	6942
00050 00051 00051 00051 00052 00053 00053 00053 00054 00056 00056 00056 00056 00056 00056 00066 00066	0 016016 4 012746 0 010600	000160'		MOV	#1(SP) SP.RO 15	: SP.*	
00055	2 104415 4 062706	000006		TRAP	46.SP		6939
00056	0 120227 4 001031	000012	9\$:	CMPB	R2.#12 10#	: ELOG.CODE.*	6945
00056	6 020127 2 101026 4 012716	000003		CMP	R1.#3 10\$	; ELOG.SUB.*	6946
0005	4 012716 0 012746	000000G 000001		MOV	#CRLF,(SP) #1(SP) SP,RO		6949
00060	4 010600 6 104415 0 012716	000000G		MOV TRAP MOV	15 #ASTERISK,(SP)	: SP.*	6950
00061	4 012746 0 010600	000001		MOV	#1(SP) SP.RO	; SP.*	8930
00062	4 010100			TRAP	15 R1.R0	; ELOG.SUB,*	6951
00063	6 006300 0 016016	000172'		MOV	TBL.CNT(RO),(SP)		
00064	012746 0 010600 2 104415	000001		MOV MOV TRAP	#1(SP) SP.RO 15	; SP.4	
00063 00063 00064 00064 00065 00065 00066 00066	4 062706 0 120227	000006 000013	10#:	ADD	66.SP R2.013	ELOG.CODE.	6948 6954
0006	4 001030 6 020127			BNE	116 R1,010	; ELOG.SUB.+	6955
00066	66 020127 52 101025 54 012716 70 012746	000000G 000001		MOV	OCRLF.(SP)		6958
00067	4 010600 6 104415	00001		MOV MOV TRAP	#1(SP) SP.RO 15	: SP.*	
00067 00070 00070	4 012746	00000G 000001		MOV	#ASTERISK,(SP)	•	6959
00071	0 010600			MOV	SP.RO	: SP.4	

					110		
ZRQAM2		RD/RX EXERC	ISER		5-Dec-1983 10:27:14	VAX-11 Bliss-16 V3-555	SEQ 0243 Page 243
V01.2		ERROR MESSA	GE SUBROUTINES		5-Dec-1983 10:27:04	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.	BL1:82 (73)
000712	104415			TRAP	15		
000714	006301			ASL	R1		6960
000716	016116	0002021		MOV	TBL.DRV(R1),(SP)		
000722	012746	000001		MOV	#1(SP) SP.RO		
000726 000730 000732 000736 000742 000744	010600 104415			MOV	15	; SP,*	
000732	062706	000006		ADD	6.SP		6957
000736	062706 020427	000002	118:	CMP	R4.#2	; REASON, *	6963
000742	001035			BNE	14\$		
000744	032763	170000 000	060	BIT	#170000,60(R3)	; *,*(ELOG.ADDR)	6966
000752	001014	0000E6		BNE	12\$	- (FLOC 4000) .	
000754 000760	016316 005046	000056		MOV	56(R3),(SP)	; *(ELOG.ADDR),*	6968
000762	016346	000056		MOV	56(R3),-(SP)	; *(ELOG.ADDR),*	
000766 000772	012746	000000G		MOV	0XX22,-(SP)	,	
000772	012746	000004		MOV	-(SP) 56(R3),-(SP) 000000000000000000000000000000000000		
000776	010600			MOV	SP.RO	: SP.*	
001000	104415 000413			TRAP BR	15 13#		6966
001004	016316	000056	12#:	MOV	56(R3).(SP)	*(ELOG.ADDR),*	6970
001010	016316 005046 016346			CLR	-(SP)	, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	07.0
001012	016346	000056		MOV	56(R3),-(SP)	; *(ELOG.ADDR),*	
001016	012746	000000G 000004		MOV	-(SP) 56(R3),-(SP) 6EX.RBN,-(SP) 64,-(SP)		
001022	012746 010600	000004		MOV	SP.RO	: SP.4	
001030	104415			TRAP	15	1 37,4	
001032	062706	000010 000000G	13#:	ADD	#10.SP #CRLF,(SP)		6966
001036	012716 012746	000000G	144:	MOV	#CRLF,(SP)	•	6972
000776 001000 001004 001010 001012 001016 001022 001030 001032 001036 001042 001046	012746	000001		MOV	41,-(SP) SP,R0		
001050	010600 104415			MOV TRAP	5P.RO 15	; SP.4	
001052	012716	000002		MOV	#2.(SP)		6973
001056	060316			ADD	R3.(SP)	ELOG.ADDR.4	07.0
001060	016346	000002		MOV	2(R3),-(SP)	* *(ELOG.ADDR).*	
001064	005216	000000		INC	(SP)		
001066 001072	012746 004737	000000G		MOV JSR	#2,-(SP) PC,BL#DIV		
001076		000002		MOV	RO.2(SP)		
001102	062766	000002 000	0002	ADD	#2,2(SP)		
001110	005726			TST	(SP)+		
001112	004737	015104		JSR	PC.EMS.BLK	. (5) 00 4000	****
001116	105063 012716	000001 000000G		CLRB	1(R3) #CRLF,(SP)	: *(ELOG.ADDR)	6974 6975
001126	012746	000001		MOV	#1,-(SP)		07/3
001132	010600			MOV	SP.RO	: SP.4	
001134	104415			TRAP	15		
001136		000020		ADD	#20,SP	1	6872
001142	000207			RTS	PC		

<sup>:</sup> Routine Size: 306 words. Routine Base: #CODE# + 15660 : Maximum stack depth per invocation: 17 words

```
SEQ 0244
                      RD/RX EXERCISER
                                                                                                                        DISK $USER2: [DIETZ.RDRX]ZRQACO.BL1;82 (74)
                                                                                                                        VAX-11 Bliss-16 V3-555
ZRQAM2
                                                                                         5-Dec-1983 10:27:14
                      ERROR MESSAGE SUBROUTINES
V01.2
                                                                                        5-Dec-1983 10:27:04
             6977 global routine EMS_CMP (ADDR) : novalue =
:
             6978
.
             6979
:
             6980
                      ! THIS ROUTINE IS CALLED FROM 'HOST_WRT_CHK' AND PRINTS RELEVENT DATA ON A HOST
:
             6981
                      ! COMPARE ERROR
:
             6982
                      ! -
:
             6983
:
             6984
                           begin
.
             6985
.
             6986
                           local
.
             6987
                                ORIG_ADDR : ref block [RP_LEN, word] field (RP_FIELDS);
.
             6988
:
             6989
                           ORIG_ADDR = .ADDR;
                                                                                                              ! ADDRESS OF THE WRITE RETPKT
.
             6990
                           PRINTB (XX13, .CDISK);
                                                                                                              ! "DISK XXX"
:
                           PRINTB (DASH);
             6991
.
                                                                                                              ! " - HOST COMPARE ERROR"
             6992
                           PRINTB (.ERR_COD [12]);
                          PRINTB (.ERR_COD [12]);

PRINTX (EX_LBW, .ORIG_ADDR [LBN_LO], .ORIG_ADDR [LBN_HI], .ORIG_ADDR [LBN_LO]); ! LBN (WRITE)

PRINTX (EX_LBR, .RP_ADDR [LBN_LO], .RP_ADDR [LBN_HI], .RP_ADDR [LBN_LO]); ! LBN (READ)

PRINTX (EX_CBW, .ORIG_ADDR [CBCNT_LO]); ! BYTE COUNT (WRITE)

PRINTX (XX25, .ORIG_ADDR [BCNT_LO]); ! BYTE COUNT (READ);

PRINTX (EX_CBR, .RP_ADDR [BCNT_LO]); ! BYTE COUNT XMITTED (READ)

PRINTX (XX25, .RP_ADDR [BCNT_LO]); ! BYTE COUNT XMITTED (READ)

PRINTX (EX_BDW, .ORIG_ADDR [BUFF_1], .ORIG_ADDR [BUFF_0]); ! BUFFER ADDRESS (WRITE)

PRINTX (EX_BDR, .RP_ADDR [BUFF_1], .RP_ADDR [BUFF_0]); ! BUFFER ADDRESS (READ)
:
             6993
:
              6994
.
              6995
:
              6996
:
              6997
:
              6998
:
              6999
.
              7000
.
              7001
                           end:
.
                                                                  .SBTTL EMS.CMP ERROR MESSAGE SUBROUTINES
000000
          004137 000000G
                                                       EMS.CMP::
                                                                             R1, $SAVE2
                                                                  JSR
                                                                                                                                                                                6977
000004
           016602
                                                                  MOV
                                                                             10(SP),R2
                      000010
                                                                                                                         : ADDR, ORIG. ADDR
                                                                                                                                                                                6989
000010
           013746
                      000000G
                                                                  MOV
                                                                             CDISK, -(SP)
                                                                                                                                                                                6990
                                                                            #XX13,-(SP)
#2,-(SP)
SP,R0
14
000014
           012746
                      000000G
                                                                  MOV
000020
           012746
                      000002
                                                                  MOV
000024
           010600
                                                                                                                         : SP. 4
                                                                  MOV
000026
           104414
                                                                  TRAP
000030
                      000000G
           012716
                                                                  MOV
                                                                             #DASH, (SP)
                                                                                                                                                                                6991
000034
           012746
                      000001
                                                                  MOV
                                                                             #1,-(SP)
000040
           010600
                                                                  MOV
                                                                             SP,RO
                                                                                                                         : SP. 4
000042
           104414
                                                                  TRAP
                                                                             14
000044
           013716
                      000030G
                                                                             ERR. COD+30, (SP)
                                                                  MOV
                                                                                                                                                                                6992
000050
           012746
                      000001
                                                                             #1,-(SP)
                                                                  MOV
000054
           010600
                                                                             SP.RO
                                                                                                                         : SP. .
                                                                  MOV
000056
           104414
                                                                  TRAP
                                                                             14
000060
           016216
                      000050
                                                                             50(R2),(SP)
                                                                                                                         : *(ORIG.ADDR).*
                                                                  MOV
                                                                                                                                                                                6993
000064
           016246
                      000052
                                                                  MOV
                                                                             52(R2),-(SP)
                                                                                                                         : *(ORIG.ADDR),*
000070
           016246
                      000050
                                                                             50(R2),-(SP)
                                                                  MOV
                                                                                                                         : *(ORIG.ADDR).*
000074
          012746
                      000000G
                                                                             #EX.LBW, -(SP)
                                                                  MOV
000100
           012746
                      000004
                                                                  MOV
000104
           010600
                                                                             SP.RO
                                                                  MOV
                                                                                                                         : SP. .
000106
          104415
                                                                  TRAP
000110
          013701
                      000000G
                                                                  MOV
                                                                             RP. ADDR. R1
                                                                                                                                                                                6994
000114
                                                                             50(R1),(SP)
          016116
                      000050
                                                                  MOV
```

ZRQAM2 VO1.2		RD/RX EXERCISER ERROR MESSAGE SUBROUTINES		5-Dec-1983 10:27:14 5-Dec-1983 10:27:04	VAX-11 Blies-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.	SEQ 0245 Page 245 BL1;82 (74)
000120 000122 000126 000132 000136	010100 016046 016146 012746 012746	000052 000050 000000G 000004	MOV MOV MOV MOV	R1,R0 52(R0),-(SP) 50(R1),-(SP) #EX.LBR,-(SP) #4,-(SP)	; RP.ADDR,*	
000142 000144	010600	00004	MOV	SP.RO	; SP.#	
000146 000152	016216	000044 000000G	MOV	44(R2),(SP) #EX.CBW,-(SP)	; *(ORIG.ADDR),*	6995
000156 000162 000164	012746 010600 104415	000002	MOV MOV TRAP	#2,-(SP) SP,R0 15	; SP.*	
000166	016216	000020 00000G	MOV	20(R2),(SP) ***X25(SP)	; *(ORIG.ADDR),*	6996
000176 000202 000204	012746 010600 104415	000002	MOV MOV TRAP	#2(SP) SP.RO 15	: SP.*	
000204 000206 000212	104415 013700 016016	000000G 000044	MOV	RP.ADDR.RO 44(RO).(SP) #EX.CBR(SP) #2(SP)	•	6997
000226	012746 012746 010600 104415	000000G 000002	MOV MOV MOV	SP.RO	: SP.*	
000230	104415 013700 016016	000000G 000020	TRAP MOV MOV	15 RP. ADDR. RO		6998
000242 000246	012746 012746 010600	00000G 000002	MOV	20(R0),(SP) #XX25,-(SP) #2,-(SP) SP,R0		
000252	104415		MOV TRAP	15	; SP.*	
000212 000216 000222 000226 000230 000232 000236 000242 000246 000252 000254 000256 000266	016216 016246 012746	000024 000026 000000G	MOV MOV MOV	24(R2),(SP) 26(R2),-(SP) #EX.BDW(SP)	: *(ORIG.ADDR).* : *(ORIG.ADDR).*	6999
000272 000276 000300	012746 012746 010600 104415	000003	MOV MOV TRAP	#EX.BDW(SP) #3(SP) SP.RO 15	: SP.4	
000302 000306	013700 016016	00000G 000024	MOV	RP.ADDR.RO 24(RO),(SP)	•	7000
000312 000316 000322	016046 012746 012746	000026 00000G 000003	MOV MOV MOV	26(RO),-(SP) #EX.BDR,-(SP) #3,-(SP)		
000326	010600 104415		MOV TRAP	SP.RO	; SP.4	
000332 000336	062706 000207	000066	ADD RTS	#66,SP PC	:	6984 6977

Routine Size: 112 words. Routine Base: #CODE# + 17024 : Maximum stack depth per invocation: 32 words

SEQ 0246 ZRQAM2 RD/RX EXERCISER 5-Dec-1983 10:27:14 VAX-11 Bliss-16 V3-555 VAX-11 Bliss-16 V3-555 Page 246 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (75) V01.2 ERROR MESSAGE SUBROUTINES 5-Dec-1983 10:27:04 7002 BGNMSG (EMS\_01): .SBTTL EMS.01 ERROR MESSAGE SUBROUTINES PC.M#EMS.01 23 PC 000000 004737 000000V EMS.01:: JSR 7002 000004 104423 TRAP 000006 000207 RTS ; Routine Size: 4 words. Routine Base: \$CODE\$ + 17364 ; Maximum stack depth per invocation: 2 words 7003 PRINTB (EBS\_01, MAX\_UNITS); ! "MORE THAN XX UNITS SPECIFIED" 7004 ENDMSG: . .SBTTL M\$EMS.01 ERROR MESSAGE SUBROUTINES 000000 012746 000004 M\$EMS.01: 44,-(SP) 7003 000004 012746 000000G #EBS.01,-(SP) MOV 000010 012746 000002 MOV 000014 010600 SP.RO MOV : SP. + 000016 104414 TRAC 14 000020 062706 000006 #6.SP PC ADU 7002 : 000024 000207 RTS

; Routine Size: 11 words.

: Routine Size: 11 words. Routine Base: #CODE# + 17374 : Maximum stack depth per invocation: 5 words

SEQ 0247 RD/RX EXERCISER ZRQAM2 5-Dec-1983 10:27:14 VAX-11 Bliss-16 V3-555 Page 247 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (76) VAX-11 Bliss-16 V3-555 V01.2 ERROR MESSAGE SUBROUTINES 5-Dec-1983 10:27:04 7005 BGNMSG (EMS\_10); .SBTTL EMS. 10 ERROR MESSAGE SUBROUTINES 000000 004737 000000V EMS. 10: : JSR PC.MSEMS.10 7005 000004 104423 TRAP 23 000006 000207 RIS : Routine Size: 4 words. Routine Base: \$CODE\$ + 17422 ; Maximum stack depth per invocation: 2 words 7006 PRINTB (EBD\_10, .RDRX\_ADDR + .OF\_RC); ! "NO RESPONSE AT ADDRESS XXXXXX" 7007 ENDMSG; : .SBTTL M&EMS.10 ERROR MESSAGE SUBROUTINES 000000 013746 000000G M\$EMS.10: RDRX.ADDR.-(SP) OF.RC.(SP) MOV 7006 000004 063716 000000G ADD #EBD.10,-(SP) #2,-(SP) SP,R0 000010 012746 000000G MOV 000014 012746 200000 MOV 000020 010600 : SP. . MOV 000022 104414 TRAP 14 000024 062706 000006 #6.SP ADD 7005 000030 000207 RTS ; Routine Size: 13 words. Routine Size: 13 words. Routine Base: \$CODE\$ + 17432 : Maximum stack depth per invocation: 5 words

```
SEQ 0248
ZRQAM2
                RD/RX EXERCISER
                                                                     5-Dec-1983 10:27:14
                                                                                             VAX-11 Bliss-16 V3-555
                                                                                             VAX-11 Bliss-16 V3-555 Page 248
DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (77)
V01.2
                ERROR MESSAGE SUBROUTINES
                                                                     5-Dec-1983 10:27:04
          7008 BGNMSG (EMS_12);
                                                   .SBTTL EMS.12 ERROR MESSAGE SUBROUTINES
000000 004737 000000V
                                          EMS.12:: JSR
                                                           PC.MSEMS.12
                                                                                                                                         7008
000004 104423
                                                   TRAP
                                                           23
000006 000207
                                                   RTS
: Routine Size: 4 words.
                               Routine Base: $CODE$ + 17464
: Maximum stack depth per invocation: 2 words
          7009 PRINTB (EBD_12, .RDRX_ADDR);
                                                                  ! "INCORRECT BR LEVEL GIVEN FOR DEVICE XXXXXX"
          7010 ENDMSG:
                                                   .SBTTL M&EMS.12 ERROR MESSAGE SUBROUTINES
000000 013746 000000G
                                          M$EMS.12:
                                                           RDRX.ADDR,-(SP)
#EBD.12,-(SP)
#2,-(SP)
SP.RO
14
#6,SP
PC
                                                   MOV
                                                                                                                                         7009
000004 012746 000000G
                                                   MOV
000010 012746
                200000
                                                   MOV
000014
       010600
                                                   MOV
                                                                                             : SP. .
000016
       104414
                                                   TRAP
000020
       062706
                000006
                                                   ADD
                                                                                                                                         7008
                                                                                             .
000024
       000207
                                                   RTS
```

Routine Base: \$CODE\$ + 17474

; Routine Size: 11 words.

: Maximum stack depth per invocation: 5 words

```
SEQ 0249
ZRQAM2
                 RD/RX EXERCISER
                                                                         5-Dec-1983 10:27:14
                                                                                                  VAX-11 Bliss-16 V3-555
                                                                                                  VAX-11 Bliss-16 V3-555 Page 249
DISK$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (78)
V01.2
                 ERROR MESSAGE SUBROUTINES
                                                                         5-Dec-1983 10:27:04
           7011 BGNMSG (EMS_13);
                                                     .SBTTL EMS.13 ERROR MESSAGE SUBROUTINES
000000 004737 000000V
                                            EMS. 13: : JSR
                                                              PC.MSEMS.13
                                                                                                                                                7011
000004
        104423
                                                      TRAP
                                                              23
000006 000207
                                                              PC
                                                      RTS
: Routine Size: 4 words.
                                Routine Base: $CODE$ + 17522
: Maximum stack depth per invocation: 2 words
           7012 PRINTB (EBD_13, .STEP);
7013 EMS_SA ();
7014 ENDMSG;
.
                                                                       ! "STEP X READ ERROR"
                                                                       ! PRINTX SA CONTENTS
.
                                                      .SBTTL M&EMS.13 ERROR MESSAGE SUBROUTINES
000000 013746 000000G
                                            M$EMS.13:
                                                              STEP,-(SP)

#EBD.13,-(SP)

#2,-(SP)

SP,R0
                                                      MOV
                                                                                                                                                7012
000004 012746
                 000000G
                                                      MOV
000010 012746
                 000002
                                                      MOV
000014
        010600
                                                                                                   : SP. .
                                                      MOV
000016
        104414
                                                      TRAP
                                                              14
000020
        004737
                 0075361
                                                      JSR
                                                              PC.EMS.SA
                                                                                                                                                7013
000024
        062706
                                                              66.SP
                 000006
                                                      ADD
                                                                                                                                                7011
000030
        000207
: Routine Size: 13 words. Routine Base: : Maximum stack depth per invocation: 5 words
```

Routine Base: #CODE# + 17532

ZRQAM2 VO1.2	RD/RX EXERCISER ERROR MESSAGE SUBROUTINES	5-Dec-1983 10:27:14 VAX-11 Bliss-16 V3-555 Page 5-Dec-1983 10:27:04 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1:82 (79)	250
; 7015	BGNMSG (EMS_14);		
000000 004737 000004 104423 000006 000207	OOOOOOV EMS.14::JSR TRAP RTS	DO MARIA AA	7015
: Routine Size: : Maximum stack	4 words. Routine Base: \$CODE\$ depth per invocation: 2 words	+ 17564	
: 7016 : 7017 : 7018	PRINTB (EBD_14, .IRDRX_ADDR); EMS_SA (); ENDMSG;	! "BAD SA CODE FROM DEVICE XXXXXX" ! PRINTX SA REGISTER CONTENTS	
000000 013746	OCCOOCC MASKS 14	M#EMS.14 ERROR MESSAGE SUBROUTINES	
000004 012746 000010 012746	000000G M\$EMS.14: 000000G MOV 000002 MOV	IRDRX.ADDR(SP) ; 7 #EBD.14,-(SP) #2,-(SP)	7016
000014 010600 000016 104414	MOV TRAP	SP.RO : SP.4	
000020 004737 000024 062706 000030 000207	007536' JSR 000006 ADD RTS		7017 7015
: Routine Size: : Maximum stack	13 words, Routine Base: #CODE# depth per invocation: 5 words	• 17574	

ZRQAM2 VO1.2		RD/RX EXERCISER ERROR MESSAGE SUBROUTINES	5-Dec-1983 10 5-Dec-1983 10	:27:14 VAX-11 Bliss-16 V3-555 :27:04 DISK\$USER2:[DIETZ.RDRX	SEQ 0251 Page 251 ]ZRQACO.BL1;82 (80)
•	7019	BGNMSG (EMS_18);			
000000 000004 000006	104423	OOOOOOV EMS.18::JSR TRAI RTS	P 23	UBROUTINES	7019
: Rout : Maxi	ine Size: mum stack	4 words, Routine Base: \$COD depth per invocation: 2 words	E\$ + 17626		
	7020 7021 7022	PRINTB (EBD_18, .CDISK); EMSCMD (); ENDMSG;	! "DISK XXX WEI ! PRINTX RELEV	NT OFFLINE" ANT RETPKT FIELDS	
000000	013746	.SB 000000G M\$EMS.18:	TTL M#EMS.18 ERROR MESSAGE	SUBROUTINES	
000004	012746	000000G MOV 0000002 MOV	CDISK,-(SP) #EBD.18,-(SP) #2,-(SP)		7020
000014 000016 000026	104414	010572' JSR 000006 ADD	P 14 PC.EMSCMD	; SP.4	7021
000030	000207	13 words, Routine Base: \$COD depth per invocation: 5 words	PC		7019

SEQ 0252 VAX-11 Bliss-16 V3-555 Page 252 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (81) ZRQAM2 RD/RX EXERCISER 5-Dec-1983 10:27:14 ERROR MESSAGE SUBROUTINES 5-Dec-1983 10:27:04 V01.2 7023 BGNMSG (EMS 21): .SBTTL EMS.21 ERROR MESSAGE SUBROUTINES PC.M#EMS.21 23 PC 000000 004737 000000V EMS.21::JSR 7023 000004 104423 TRAP 000006 000207 RTS : Routine Size: 4 words, Routine Base: \$CODE\$ + 17670 : Maximum stack depth per invocation: 2 words 7024 EMSCMD (): ! CONTENTS OF RETURN PACKET . 7025 !EMS\_RAL (); 7026 EMS\_MAL (); ! all return packets : ! all message packets : 7027 ENDMSG: : .SBTTL M#EMS.21 ERROR MESSAGE SUBROUTINES 000000 004737 0105721 M\$EMS.21: PC.EMSCMD PC.EMS.MAL 7024 000004 004737 015256' 000010 000207 JSR 7026 RTS 7023

: Routine Size: 5 words. Routine Base: \$CODE\$ + 17700 : Maximum stack depth per invocation: 1 word 1-14

ZRQAM2 V01.2

000004

RD/RX EXERCISER

ERROR MESSAGE SUBROUTINES

5-Dec-1983 10:27:14 5-Dec-1983 10:27:04 VAX-11 Bliss-16 V3-555 Page 253 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (82)

SEQ 0253

7028 BGNMSG (EMS\_22)

000000 004737 000000V 104423

.SBTTL EMS.22 ERROR MESSAGE SUBROUTINES EMS. 22: : JSR PC.MSEMS.22

23 PC TRAP RTS

7028

000006 000207

: Routine Size: 4 words, Routine Base: \$CODE\$ + 17712

: Maximum stack depth per invocation: 2 words

7029 EMS\_DBN (); 7030 ENDMSG:

! contents of dup buffer

000000 004737 014344'

.SBTTL M\$EMS.22 ERROR MESSAGE SUBROUTINES

M\$EMS.22:

000004 000207

PC.EMS.DBN RTS

7029 7028

: Routine Size: 3 words. Routine Base: \$CODE\$ + 17722

; Maximum stack depth per invocation: 1 word

7031

7032

7031

```
SEQ 0254
ZRQAM2
                RD/RX EXERCISER
                                                                   5-Dec-1983 10:27:14
                                                                                           VAX-11 Bliss-16 V3-555
                                                                                          VAX-11 Bliss-16 V3-555 Page 254 DISK*USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (83)
V01.2
                ERROR MESSAGE SUBROUTINES
                                                                   5-Dec-1983 10:27:04
          7031 BGNMSG (EMS_30);
:
                                                  .SBTTL EMS.30 ERROR MESSAGE SUBROUTINES
000000 004737 000000V
                                         EMS.30:: JSR
                                                         PC.MSEMS.30
        104423
000004
                                                 TRAP
                                                         23
000006
        000207
                                                 RTS
                                                         PC
: Routine Size: 4 words.
                                Routine Base: $CODE$ + 17730
: Maximum stack depth per invocation: 2 words
          7032 EMSCMD ():
                                                                  ! contents of return packet
          7033 ENDMSG:
.
                                                  .SBTTL M&EMS.30 ERROR MESSAGE SUBROUTINES
000000 004737 0105721
                                         M$EMS.30:
                                                         PC.EMSCMD
PC
000004 000207
                                                                                           .
: Routine Size: 3 words.
                                 Routine Base: $CODE$ + 17740
; Maximum stack depth per invocation: 1 word
          7034
.
          7035
.
                end
          7036
.
          7037
                eludom
:
:
                                         OTS external references
                                                  .GLOBL #SAVES, #SAVE4, #SAVE3, #SAVE2
                                                  .GLOBL BL DIV, BL MOD, BL MUL
                                         PSECT SUMMARY
.
.
        Psect Name
                                         Nords
74
                                                    Attributes
.
         $OWN$
:
         *CODE *
                                          4083
.
         $PLIT$
                                            12
                                 LIBRARY STATISTICS
:
                                               ----- Symbols -----
                                                                            Blocks
        File
                                              Total
                                                                 Percent
                                                        Loaded
                                                                              Read
   DISK*USER2: [DIETZ.RDRX]ZRQACO.L16;14
                                                400
                                                                      74
```

J4

ZRQAM2 VO1.2

.

RD/RX EXERCISER

ERROR MESSAGE SUBROUTINES

5-Dec-1983 10:27:14 5-Dec-1983 10:27:04 VAX-11 Bliss-16 V3-555 Page 255 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL1;82 (83)

: Information: 1 : Warnings: 0 : Errors: 0

COMMAND QUALIFIERS

BLISS /PDP11 ZRQACO.BL1/LIST=ZRQACO.LI1/OBJECT=ZRQACO.OB1/SOURCE=PAGE:53

; Size: 3922 code + 6972 data words ; Run Time: 03:47.9 ; Elapsed Time: 34:26.9 ; Memory Used: 695 pages ; Compilation Complete

```
ZRQAM3
                                                                                 14-Dec-1983 16:12:07
                                                                                                                VAX-11 Bliss-16 V3-555
                                                                                 14-Dec-1983 16:12:00
                                                                                                                DISK $USER2: [DIETZ.RDRX] ZRQACO.BL2:161 (1)
            0001 module ZRQAM3 (
            0002
            0003
                    stitle 'RD/RX EXERCISER'
                                        ident = 'V01.2',
addressing_mode (absolute),
            0004
            0005
            0006
                                         environment (noeis)
.
            0007
            8000
            0009
                    begin
            0010
            0011 #sbttl 'DECLARATIONS'
            0012
            0013 library 'ZRQACO.L16';
                                                                                 ! RDRX EXERCISER GLOBAL LIBRARY
            0014
:
            0015 require 'BLSMAC.REQ';
                                                                                 ! DIAGNOSTIC SUPERVISOR LIBRARY
.
             1506
.
             1507
                    EQUALS:
:
             1508
.
             1509
                    forward routine
                                                                                 ! ROUTINES APPEAR IN THIS ORDER
             1510
                         INIT_TEST : novalue.
                                                                                        INDENTATION IMPLIES CALLED SUBROUTINE
:
                              DRIVER_INIT : novalue,
CTLR_INIT : novalue,
INI_CTLR_DAT : novalue,
             1511
.
             1512
.
             1513
.
                                         REG_EXIST
.
             1514
                                         VEC_BR_TEST.
             1515
.
                                         INT_GEN.
             1516
             1517
                                         HARD_INIT,
.
             1518
                                         INI_RRING : novalue,
.
                                   SET_CTLR_CHAR,
UNIT_INIT : novalue,
DR_ERR : novalue,
             1519
             1520
             1521
                         ACCESS: novalue,
MULTI_DRIVE: novalue,
MD_INIT: novalue,
INIT_IO_BUFF: novalue,
FATAL_ERROR: novalue,
             1522
             1523
1524
1525
1526
                              QIO_OK,
             1527
.
             1528
             1529
1530
                                    QIO_GEN : novalue.
                                         GET_RANDOM : novalue.
.
             1531
1532
1533
                                         QIO_UNIT : novelue.
QIO_FUNC : novelue.
:
                                           DUP : novalue,
DUPWRTDBN : novalue,
DUPREDDBN : novalue,
DUPCOMMAND : novalue,
             1534
             1535
             1536
.
             1537
                                                        DUPIDLE : novalue,
.
             1538
                                         QIO_LBN : novalue.
.
             1539
                                         QIO_SIZE : novelue,
.
             1540
                                         FILL_BUFF : novalue,
.
             1541
                                    PROC_RETPKT : novalue,
.
             1542
                                         DIO_RETPKT : novalue,
.
                                              DUP_COMPARE : novalue.
```

```
ZRQAM3
                       RD/RX EXERCISER
                                                                                             14-Dec-1983 16:12:07
                                                                                                                                VAX-11 Bliss-16 V3-555
V01.2
                       DECLARATIONS
                                                                                                                                DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2:161 (1)
                                                                                             14-Dec-1983 16:12:00
              1544
                                              IO_RETPKT : novalue,
              1545
                                                    FSET_UPAR : novalue,
.
               1546
                                                    HARD ERROR : novalue,
2
               1547
                                                    UPD_IO_TALLY : novalue,
OVF_CHK : novalue,
.
               1548
:
                                                    HOST_WRT_CHK,
               1549
.
               1550
                                                    SWEEP : novalue,
               1551
                                                          RPS_REM.
:
               1552
                                              DR_RETPKT : novalue.
.
               1553
                             AZINTO : LIISR novalue,
.
               1554
                                  AZINT : novelue.
                                        FATAL_ERROR : novalue,
POLL_CRING : novalue,
POLL_RRING : novalue,
               1555 !
               1556
.
               1557
                                              DUP_RSP : novalue, MSCP_RSP : novalue,
               1558
               1559
                                                    SEQUEN : novalue,
               1560
:
               1561
                                                          SOFT_ERROR : novalue.
.
               1562
                                                    DATAGM : novalue;
:
               1563 !
                                                          SOFT_ERROR : novalue;
:
               1564
               1565
                     external
               1566
1567
                            CST : blockvector [MAX_CTLR, CST_LEN, word] field (CST_FIELDS), ! RUN-TIME CONTROLLER STATUS TABLES
.
.
                            CST_ADDR : ref block [CST_LEN, word] field (CST_FIELDS),
! CONTROLLER STATUS TABLE ADDRESS OF "CURRENT" CONTROLLER
DCT : blockvector [MAX_CTLR, DCT_LEN, word] field (DCT_FIELDS),
! DRIVER CONTROLLER TABLES
               1568
:
               1569
.
               1570
               1571
.
                             DCT_ADDR : ref block [DCT_LEN, word] field (DCT_FIELDS), ! ADDRESS OF "CURRENT" DRIVER CONTROLLER TABLE
               1572
:
               1573
.
                            RDRX_ADDR : ref rdrx field (RC_REG).
! DEVICE ADDRESS OF "CURRENT" CONTROLLER
IRDRX_ADDR : ref rdrx field (RC_REG).
               1574
               1575
               1576
               1577
                                                            DEVICE ADDRESS OF INTERRUPTING CONTROLLER
               1578
                             ICOM_ADDR : ref block (COMM_LEN, word) field (COM_FIELDS).
! ADDRESS OF INTERRUPTING CONTROLLER'S COMMUNICATION AREA
.
               1579
:
               1580
                             ICST_ADDR : ref block [CST_LEN, word] field (CST_FIELDS), ! ADDRESS OF INTERRUPTING CONTROLLER'S CST
               1581
:
                            IDCT_ADDR : ref block [DCT_LEN, word] field (DCT_FIELDS).
! ADDRESS OF INTERRUPTING CONTROLLER'S DCT
DUPPKT : BLOCK [257, WORD] field (DP_FIELDS).
! BUFFER CONTAINING DUP INFORMATION FROM RECEIVE AND SEND COMMANDS
               1583
:
               1585
.
                             BST : blockvector (MAX_UNITS, 2, word).
! BLOCK SEQUENCE TABLE FOR SEQUENTIAL LBN (VS. RANDOM SEEK) MODE
               1586
               1587
                             TALLY : vector [MAX_UNITS * TALLY_LEN, word] field (T_FIELDS), ! STATISTICS TABLES
               1588
               1589
               1590
                             T_ADDR : ref block [TALLY_LEN, word] field (T_FIELDS).
! ADDRESS OF STATISTICS TABLE (TALLY) FOR CURRENT UNIT
               1591
.
                             C_ERR_TBL : blockvector [MAX_CTLR, C_ERR_LEN, word] field (C_ERR_FIELDS), ! STATISTICS TABLE FOR CONTROLLER ERRORS
               1592
               1593
                             MSCP_PKT : blockvector (PKT_CNT, PKT_LEN, word) field (PKT_FIELDS).
! MSCP PACKET POOL
               1594
:
.
               1596
                             IPKT_ADDR : ref block [PKT_LEN, word] field (PKT_FIELDS),
```

Page

```
ZRQAM3
                       RD/RX EXERCISER
                                                                                            14-Dec-1983 16:12:07
                                                                                                                               VAX-11 Bliss-16 V3-555
V01.2
                       DECLARATIONS
                                                                                            14-Dec-1983 16:12:00
                                                                                                                               DISK $USER2: [DIETZ.RDRX]ZRQACO.BL2:161 (1)
              1597
                                                          ! ADDRESS OF AN MSCP PACKET (INTERRUPT PROCESSING)
                            PKT_USE : vector [PKT_CNT, byte, signed], ! MSCP PACKET POOL ALLOCATION TABLE
              1598
.
              1599
:
                            RETPKT : blockvector [RP_CNT, RP_LEN, word] field (RP_FIELDS), ! RETURN PACKET POOL
              1600
.
              1601
                            RP_USE : vector [RP_CNT, byte, signed],
! RETURN PACKET POOL ALLOCATION TABLE
              1602
.
              1603
.
                             RP_INDX : word.
              1604
                                                          ! CURRENT RETURN PACKET INDEX
.
                            RP_ADDR : ref block [RP_LEN, word] field (RP_FIELDS), ! CURRENT RETURN PACKET ADDRESS
              1605
:
              1606
:
                                                                                            ! NUMBER OF RANDOM NUMBERS \ KEEP
              1607
                             RDM_CNT : word.
:
                             RANDOM : vector [RDM_LEN, word],
              1608
                                                                                            ! RANDOM NUMBER TABLE
                                                                                                                                     / TOGETHER
                            TRK_SGN: vector [MAX_UNITS, byte, signed], ! CURRENT TRACK DIRECTION

ELOG_PKT: blockvector [EP_CNT, EP_LEN, word] field (EP_FIELDS),

! ERROR-LOG PACKET SAVE AREA

BUFF_ADDR: vector [MAX_BUF_CNT], ! TABLE OF I/O BUFFER DESCRIPTORS

BUFF_OWN: vector [MAX_BUF_CNT], byte, signed], ! I/O BUFFER OWNERSHIP (CONTROLLER NUMBER)
              1609
              1610
:
              1611
:
              1612
.
              1613
.
                             IODQ : vector [IODQ_LEN, byte],
              1614
.
              1615
                                                                                 ! I/O DONE QUEUE - CIRCULAR QUEUE OF RETPKT INDECES
                                                                                 ! I/O DONE QUEUE IN POINTER
              1616
                             IODQ_IN : word.
              1617
                             IODQ_OUT : word,
                                                                                 ! I/O DONE QUEUE OUT POINTER
              1618
                             ENTRY_REASON : byte,
                                                                                   CURRENT OPERATOR COMMAND
.
                            EOP_FLAG : byte,
DUP_FLAGS : WORD,
CCTLR : word,
CDISK : word,
CUOFF : word,
CTLR_CNT : word,
              1619
                                                                                   END-OF-PASS FLAG
.
                                                                                   DUP FLAGS
NUMBER OF "CURRENT" CONTROLLER
CURRENT DISK ADDRESS (RD/RX DISK NUMBER)
CURRENT UNIT CST OFFSET
TOTAL NUMBER OF CONFIGURED CONTROLLERS
              1620
.
              1621
:
              1622
              1623
               1624
:
                             DUR : vector [MAX_UNITS, byte],
QIO : vector [MAX_CTLR, byte],
                                                                                   DROP UNIT REASON
              1625
.
               1626
                                                                                   NUMBER OF OUTSTANDING GIOS PER CONTROLLER
:
               1627
                             FREE_MEM_ADDR,
                                                                                   START OF FREE MEMORY
                             BYTS_PER_QIO : word,
ST_CODE : word,
               1628
                                                                                   SIZE (BYTES) OF AN I/O BUFFER
                                                                                   CURRENT STATUS CODE CURRENT SUB-CODE
              1629
               1630
                             SB_CODE : word.
.
                                                                                 ! CURRENT STEP IN HARD_INIT ! OFFSET (0 OR 2) TO READ IP OR SA
               1631
                             STEP : word.
.
                             OF_RC : signed word,
SA_REG : word,
               1632
:
                                                                                STORAGE FOR SA REGISTER READS AND WRITES COMMAND TIMEOUT VALUE (IN SECONDS)
               1633
               1634
                             CMD_TIME : word,
                                                                                ! NON-EXISTENT MEMORY TRAP INDICATOR
! COMMAND REF NUMBER OF LAST COMMAND SENT
! COMMAND REF NUMBER OF LAST COMMAND SENT
                             NEX : word,
CRN_LOW : word,
CRN_HIGH : word,
               1635
               1636
               1637
                                                                     ! CURRENT message PACKET INDEX ! DBN BYTE COUNTER
                             P_INDEX : signed word, S_DUPPKT : MORD,
               1638
               1639
                             S_PATTERN : WORD,
               1640
                                                                     ! THE PATTERN WRITTEN TO DBN'S
               1641
                             CREDIT_BAL : word,
                                                                                 ! CREDIT BALANCE
                             INIT_OCCURED : byte,
               1642
                                                                                 ! indicates if exerciser finished init sequence
               1643
                             NXT_PKT_2USE : byte.
                                                                                 ! POINTER TO NEXT ENTRY IN PKT_USE TABLE
               1644
                             DBM12.
:
               1645
                             DBM18,
.
               1646
                             DBM19,
.
                             DBM20,
               1647
:
               1648
                             DBM21
:
```

1649

! DBM22.

```
ZRQAM3
                        RD/RX EXERCISER
V01.2
                         DECLARATIONS
               1650
                               DBM23,
               1651
                               DBM25.
.
               1652
                               DBM26,
.
               1653
                               DBM29,
.
               1654
                               DBM108.
.
               1655
                               DBM109.
:
               1656
                               DBM110.
.
                               DBM112.
               1657
.
               1658
                        !der10.
               1659
                        !der13,
               1660
                               EH_O.
.
                              EH_1.
EH_2.
EH_3.
               1661
:
               1662
.
                1663
.
                              EH_4.
EH_5.
EH_6.
EH_7.
                1664
.
                1665
.
               1666
                1667
.
                              EH_8.
               1668
:
                1669
:
                1670
                               EH_10.
:
                              EH_12.
EH_13.
MSG_02.
               1671
.
               1672
               1673
.
                              MSG_03.
               1674
.
                              EGS_03.

EGS_02.

EGD_10.

EGD_11.

EGD_12.

EGD_13.

EGD_14.

EGD_15.

EGD_16.

EGD_17.

EGD_18.
               1675
:
.
               1676
                1677
               1678
:
                1679
.
                1680
.
               1681
.
                1682
.
               1683
               1684
.
                              EGD_19.
EGD_20.
EGD_21.
               1685
.
                1686
                1687
.
                              EGD 22.
EGD 23.
EGD 24.
EGH 30.
                1688
.
                1689
                1690
.
               1691
.
               1692 EX_GDS.
1693 EX_ESP.
1694 EX_ELP.
1695 EX_RCD.
1696 EX_SDD.
.
.
.
.
               1697 EX_ABP.
.
                1698
                       EX_WRD.
.
               1699
1700
.
                              CRLF,
SWP_ERROR : word,
SWP_XFER : word,
.
                1701
:
               1702
:
```

14-Dec-1983 16:12:07 VAX-11 Bliss-16 V3-555 Page 4
14-Dec-1983 16:12:00 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (1)

! HARD ERROR LIMIT FOR DROPPING UNIT ! TRANSFER LIMIT FOR DROPPING UNIT

```
ZRQAM3
                                   RD/RX EXERCISER
                                                                                                                                               14-Dec-1983 16:12:07
                                                                                                                                                                                                    VAX-11 Bliss-16 V3-555
V01.2
                                   DECLARATIONS
                                                                                                                                               14-Dec-1983 16:12:00
                                                                                                                                                                                                    DISK&USER2:[DIETZ.RDRX]ZRQACO.BL2:161 (1)
                      1703
                                             SWP_FLAGS : word.
                                                                                                                                               ! FLAGS (SEE DOCUMENTATION)
                      1704
                                             dupround : word.
                                                                                                                                               ! ratio constant for dup exerciser
                       1705
                                             SWP_RAT : word.
                                                                                                                                                  RD51 OPERATION RATIO
                       1706
                                             SWP_DPAT : word.
                                                                                                                                                  DATA PATTERN NUMBER
                       1707
                                             SWP_UCNT : word.
                                                                                                                                                  USER DATA PATTERN COUNT
                       1708
                                             SWP_UDPAT : vector [MAX_UDP_CNT, word].
                                                                                                                                               ! USER DATA PATTERN
                       1709
                                            LILUN.
                       1710
                                             L$UNIT:
                       1711
                       1712
                                   psect
                      1713
                                            own = $GGG$(read, nowrite, execute, local, concatenate);
                      1714
:
                      1715
.
                       1716
                                             COMM_AREA : blockvector [MAX_CTLR, COMM_LEN, word] field (COM_FIELDS).
:
                      1717
                                                                                         ! COMMUNICATIONS AREA BETWEEN HOST AND AZTEC CONTROLLERS
.
                      1718
                                            DPST : vector [MAX_UNITS, byte],
                       1719
                                                                                                                                               ! DATA PATTERN SEQUENCE TABLE
                                            MAX_LBN : vector [MAX_UNITS, word], ! LARGEST LBN ALLOWED STORAGE : vector [MAX_UNITS, word], ! DUMMY STORAGE INT_ADDR : vector [MAX_CTLR] initial (AZINTO $(, AZINT1, AZINT2, AZINT3)$),
                      1720
                       1721
                       1722
                       1723
                                                                                         ! INTERRUPT SERVICE ROUTINE ADDRESS TABLE
                                             ICTLR : word.
                       1724
                                                                                                                                                  INTERRUPTING CONTROLLING NUMBER
                       1725
                                                                                                                                                  MSCP PKT INDEX FOR FIRST QIO MSCP PKT INDEX FOR SECOND QIO
                                             MX1 : signed word.
                       1726
                                             MX2 : signed word.
                                            MAD1 : ref block [PKT_LEN, word] field (PKT_FIELDS).
! ADDRESS OF MSCP PACKET FOR FIRST QIO
                       1727
                       1728
                       1729
                                             MAD2 : ref block [PKT_LEN, word] field (PKT_FIELDS)
                       1730
                                                                                          ! ADDRESS OF MSCP PACKET FOR SECOND QIO
                       1731
                                            LAST_PKT : blockvector [MAX_CTLR, LAST_PKT_LEN, word] field (LAST_PKT_FIELDS).
                       1732
                                                                                          ! SAVE AREA FOR INFO ABOUT LAST RESPONSE PACKET
                       1733
                                            PATO2: vector [2] initial (1.
                                                                                                                                                                                   ! PATTERN 2
                       1734
                                                              #o'000000').
                                            PATO3 : vector [2] initial (1.
                       1735
                                                                                                                                                                                   ! PATTERN 3
                       1736
                       1737
                                            PATO4 : vector [2] initial (1.
                                                                                                                                                                                  ! PATTERN 4
                       1738
                                                               #o' 105613' ),
:
                       1739
                                             PATOS: vector [2] initial (1.
:
                                                                                                                                                                                  ! PATTERN 5
                       1740
                                                               so' 031463' ),
                       1741
                                             PATO6 : vector [2] initial (1,
                                                                                                                                                                                   ! PATTERN 6
                       1742
                                                               #o'030221').
                       1743
                                            PATO7 : vector [17] initial (16.
                                           PATO7: vector [17] initial (16, %o'000001', %o'000001', %o'000001', %o'000003', %o'000007', %o'000017', %o'000037', %o'000077', %o'000177', %o'000377', %o'000777', %o'007777', %o'07777', %o'07777', %o'07777', %o'07777', %o'17777'), PATO8: vector [17] initial (16, %o'177776', %o'177774', %o'177770', %o'177760', %o'177740', %o'177700', %o'177600', %o'177000', %o'177000', %o'177000', %o'170000', %o'17000', %o'1700', %o'1700', %o'1700', %o'1700
                                                                                                                                                                                  ! PATTERN 7
                       1744
                       1745
                       1746
                       1747
                       1748
                                                                                                                                                                                  ! PATTERN 8
                       1749
                       1750
                                           #6'177000', #6'176000', #6'174000', #6'170000', #6'160000', #6'140000', #6'100000', #6'000000'), #6'100000', #6'000000'), part of (#6'000000'), rep 3 of (#6'177777'),
                       1751
                       1752
                       1753
                                                                                                                                                                                   ! PATTERN 9
                       1754
                       1755
                                                              rep 2 of (%o'000000'), rep 2 of (%o'177777'),
```

ZRQAM3 VO1.2	RD/RX EXERCIDECLARATION		14 - Dec - 1983 14 - Dec - 1983	16:12:07 16:12:00	VAX-11 Bliss-16 V3-555 Page 6 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (1)
	1756	#0'000000', #0'177777', #0'000000'.	50' 177777' .		
	1757	#o'000000', #o'177777'),			
	1758 PAT10 :	vector [2] initial (1.		! PATTE	RN 10
•	1759	#o'133331'),			
	1760 PAT11 :	vector [17] initial (16,	112525213	! PATTE	RN 11
	1762	rep 3 of (%o'052525'), rep 3 of (%o rep 2 of (%o'052525'), rep 2 of (%o'052525')	1252521)		
	1763	#0'052525', #0'125252', #0'052525',	#0' 125252' .		
:	1764	#o'052525', #o'125252'),			
:	1765 PAT12 :	vector [21] initial (20,		! PATTE	RN 12
•	1766	rep 3 of (%o'026455'), rep 3 of (%o	151322').		
	1767 1768	rep 2 of (%0'026455'), rep 2 of (%0 rep 2 of (%0'026455'),	151322').		
	1769	#0'151322', #0'026455', #0'151322',	do' 0264551		
	1770	#0' 151322', #0' 026455', #0' 151322',	do' 026455' )		
	1771 PAT13 :	vector [2] initial (1.	-0 020133 /	! PATTE	RN 13
:	1772	#o'066666'),			
	1773 PAT14 :	vector [17] initial (16.		! PATTE	RN 14
	1774 1775	%0'000001', %0'000002', %0'000004',	#6'000010',		
	1776	#6'000020', #6'000040', #6'000100', #6'000400', #6'001000', #6'002000',	#0.000500.		
	1777	%0'010000', %0'020000', %0'040000'.	#o'100000')		
	1778 PAT15 :	vector [17] initial (16.		! PATTE	RN 15
	1779	#0'177776'. #0'177775'. #0'177773'.	#0'177767'.		
	1780	#0'177757', #0'177737', #0'177677',	#o' 177577' .		
	1781 1782	#0'177377', #0'176777', #0'175777'.	#o' 173777' .		
	1783 PAT16 :	#0'167777', #0'157777', #0'137777', vector [17] initial (16,	#0.011111.)	! PATTE	DN 16
	1784	rep 3 of (%o'133331'), rep 3 of (%o	11555541).	: PAIII	WW 10
:	1785	rep 2 of (%o'133331'), rep 2 of (%o	155554').		
	1786	#0'133331', #0'155554', #0'133331'.	#o' 155554' .		
	1787	#o'133331', #o'155554'), vector [22] initial (21,			
	1788 PAT17 :	#0'000000', rep 2 of (#0'106466'),		! PATTE	RN 17
	1790	rep 3 of (%0'071311'), rep 4 of (%0	11064661)		
	1791	rep 5 of (#0'071311'), rep 6 of (#0	106466')).		
:	1792 PAT18 :	vector [22] initial (21.		! PATTE	RN 18
	1793	#0'106466', #0'000000', #0'071311',			
:	1794 1795	rep 3 of (%o'106466'), rep 4 of (%o	(071311'),		
		rep 5 of (%o'106466'), rep 6 of (%o vector [22] initial (21,	071311')).	1 DATE	2011 4.0
	1797	#0'000000', rep 2 of (#0'134631'),		! PATTE	INN 19
	1798	rep 3 of (%o'043146'), rep 4 of (%o	1346311).		
:	1799	rep 5 of (#0'043146'), rep 6 of (#0	134631')).		
	1800 PAT20 :	vector [22] initial (21.		! PATTE	RN 20
	1801	#0'134631', #0'000000', #0'043146',			
:	1802 1803	rep 3 of (%o'134631'), rep 4 of (%o	043146').		병 보고 내가 하는 것이 어떻게 하는 사이들이 어떤 때문을 하는 것이다.
		vector [2] initial (1,	043740. ))'	1 DATTE	ERN 21
	1805	#o'000000'),			BN)
:	1806 DPA_TBL	: vector [DP_CNT] initial			PATTERN ADDRESS TABLE
	1807	(RDM_CNT, PATO2, PATO3, PATO4, PA	T05,		
	1808	PATOS, PATO7, PATO8, PATO9, PAT10	. PAT11.		

7

```
ZRQAM3
                    RD/RX EXERCISER
V01.2
                    DECLARATIONS
            1809
                                      PAT12. PAT13. PAT14. PAT15. PAT16. PAT17. PAT18. PAT19. PAT20. PAT21).
             1810
            1811
                         BST_CNT : word initial (0),
                                                                                 ! CURRENT SEQUENTIAL BLOCK COUNT ! CURRENT SEQUENTIAL BLOCK DEVICE
            1812
                         BST_DEV : word initial (0),
            1813
                         CURRENT_VECTOR : word.
                                                                                CURRENT DEVICE'S VECTOR ADDRESS
            1814
            1815
                         BRLEVEL : word.
                         DUOFF : word,
COMPARE_DATA : byte;
            1816
                                                                              ! STORAGE FOR DUP OFFSET INTO CST TABLE ! FLAGGED CLEARED TO BYPASS HOST COMPARES
            1817
            1818
                  external routine
NEX_TRAP : L*ISR novalue,
SET_CPAR : novalue,
            1819
            1820
            1821
            1822
                         SET_UPAR : novalue.
                         OUT_IODQ.
IN_IODQ : novalue,
             1823
             1824
             1825
                         GET_PKT.
                         PUT_PKT : novalue, GET_RETPKT,
             1826
             1827
            1828
                         PUT_RETPKT : novalue.
                         GET_IO_BUFF : novalue,
PUT_IO_BUFF : novalue,
PUTA_BUFF : novalue,
            1829
            1830
             1831
                         SEND.
             1832
                         MAIT : novalue,
DROP_CTLR : novalue,
DRV_CTLERR : novalue,
             1833
             1834
```

1835 1836

1837 1838 1839

1840

1841 1842

1843 1844 1845

1846

1847

:

.

:

.

MODULAS.

EMSCMD : novalue, EMS\_22 : novalue,

EMS\_EL : novalue, EMS\_CMP : novalue,

EMS\_10 : novalue, EMS\_12 : novalue, EMS\_13 : novalue, EMS\_14 : novalue, EMS\_18 : novalue, EMS\_21 : novalue, EMS\_21 : novalue,

```
SEQ 0263
ZRQAM3
                  RD/RX EXERCISER
                                                                         14-Dec-1983 16:12:07
                                                                                                    VAX-11 Bliss-16 V3-555 Page
DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2:161 (2)
V01.2
                  TEST SECTION
                                                                         14-Dec-1983 16:12:00
           1848 #sbttl 'TEST SECTION'
           1849
           1850 !+
:
           1851
                  .
                           THIS SECTION CONTAINS THE TOP-LEVEL TEST CODE FOR THE RDRX EXERCISER.
.
                           THE EXERCISER CONSISTS OF ONE TEST WHICH IS SUBDIVIDED INTO A NUMBER OF SUBTESTS. ALL SUBTESTS ARE DECLARED WITHIN THIS BLOCK.
           1852
:
           1853
           1854
:
           1855
           1856
                  BGNTST:
           1857
:
           1858
                  EOP_FLAG = TRUE:
.
                                                                                  ! ASSUME NO UNIT AVAILABLE
                  COMPARE_DATA = TRUE;
DUP_FLAGS = .DUP_FLAGS AND (NOT SWP_DINT);
           1859
                                                                                  ! ALLOW HOST COMPARES IF ASKED FOR
:
           1860
                                                                                  ! CLEAR DUP INIT FLAG
           1861
                  INIT_TEST ():
                                                                                  ! INITIALIZE TEST ENVIRONMENT
:
           1862
:
           1863
                 IF BIT_TST (SWP_FLAGS, SWF_CWC)
                  then SMP_FLAGS = .SMP_FLAGS and (NOT SMF_HMC);
           1864
                                                                                  ! DISALLOWS SIMUTANEOUS CONTROLLER/HOST WRITE COMPARES
:
           1865
.
                 incr CTLR from 0 to (MAX_CTLR - 1) do
           1866
.
                                                                                  ! FOR EVERY CONTROLLER
           1867
:
                      if (.CST [.CTLR, STATE] eql ONLINE) and (.DCT [.CTLR, STAT] eql ONLINE) and (.CST [.CTLR, U_CNT] gequ 0)
           1868
:
                                                                                  ! IF CONTROLLER ONLINE
           1869
           1870
           1871
.
           1872
.
           1873
                           incr OFFSET from (0 + OF_UN) to (3 * UNIT_SIZE + 4) by UNIT_SIZE do
           1874
           1875
                                if .CST [.CTLR, .OFFSET, D_STAT] eql ONLINE ! IF AT LEAST ONE UNIT ALIVE
           1876
                                then
           1877
                                    begin
EOP_FLAG " FALSE:
.
           1878
                                                                                  ! NOT END OF PASS
                                    exitloop:
           1879
           1880
                                    end:
           1881
           1882
                  if not .EOP_FLAG
.
           1883
                  then
           1884
                      MULTI_DRIVE ():
                                                                                  ! RUN MULTI-DRIVE TEST
           1885
           1886
                 DELAY (10);
                                                                                  ! MAKE SURE ALL COMMANDS ARE DONE
           1887
                 ENDTST;
.
                                                       .TITLE ZRQAM3 RD/RX EXERCISER
                                                       .IDENT /V01.2/
                                                        ENABL
000000
                                                       .PSECT #GGG#, RO
000000
                                             COMM. AREA:
                                                       .BLKW
000050
                                                       . BLKW
000054
                                             MAX.LBN: .BLKW
000064
                                             STORAGE: . BLKW
```

				1 3		
ZRQAM3 VO1.2	RD/RX EXERCISER TEST SECTION			14-Dec-1983 14-Dec-1983	16:12:07 16:12:00	VAX-11 Bl;ss-16 V3-555 Page 9 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (2)
000074	000000V	INT.ADDR:				
000076 000100 000102 000104 000106 000110		.WORD ICTLR: BLKW MX1: BLKW MX2: BLKW MAD1: BLKW MAD2: BLKW LAST.PKT:	AZINTO 1 1 1 1 1			
000116	000001 000000	PATO2: .WORD .WORD	3 1 0			
000122 000124	000001 177777	PATO3: .WORD	1			
000126	000001	PATO4: .WORD	i			
000130 000132	105613 000001	PATOS: .WORD	-72165 1			
000134 000136	031463 000001	PATO6: .WORD	31463			
000140 000142	030221 000020	. WORD	30221			
000144 000146	000001	PATO7: .WORD .WORD .WORD	20			
000146	000003 000007	. WORD	3 7			
000150 000152 000154	000017	. WORD . WORD	17			
000156	000037 000077	. MORD . MORD . MORD	37 77			
000160	000177 000377	. WORD	177 377			
000164	000777	. WORD	777			
000166 000170 000172	001777 003777	. WORD	1777 3777			
000172 000174	007777 017777	. MORD . MORD . MORD . MORD . MORD	7777 17777			
000176	037777	WORD	37777			
000505	077777 177777	. WORD	77777 -1			
000204	000020 177776	PATO8: . WORD	20 -2 -4			
000210	177774	WORD	-4			
000210 000212 000214 000216 000220 000222 000224 000226 000230	177770 177760	PATOS: .MORD	-10 -20 -40			
000216	177740 177700	. WORD	-40			
000222	177600	WORD	-100 -200			
000224	177400 177000	, WORD	-400 -1000			
000230	176000 174000	. WORD	-2000			
VVV234	170000	. WORD	-4000 -10000			
000236 000240	160000 140000	. WORD	-20000 -40000			
000242 000244	100000	. WORD	-100000			
000244	000000	. WORD	0			

ZRQAM3 VO1.2	RD/RX EXERCISER TEST SECTION			14-Dec-1983 16 14-Dec-1983 16	:12:07	VAX-11 Bliss-16 V3-555 Page 10 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2:161 (2)
000246 000250 000252 000254 000256 000260 000264 000266 000270 000272 000274 000276 000300 000302	000020 000000 000000 177777 177777 177777 000000 000000 177777 177777 000000 177777	PATO9: .WO	ORD 0 ORD 0 ORD -1 ORD -1 ORD -1 ORD 0 ORD 0 ORD 0 ORD -1 ORD -1 ORD 0 ORD -1 ORD 0			
000306 000310	177777 000001	PATIO: .WO	RD -1			
000312 000314	1 7 7 7 7 1	PAT11: .WO	RD -44447			
000316	000020 052525 052525 052525 125252 125252 125252 052525 052525 125252	.WC	IRD 52525			
000320 000322 000324	052525 125252	LIC LIC	MDD 52525			
000326 000330	125252 125252	. MC . MC . MC . MC	RD -52526 RD -52526			
000332 000334	052525 052525	: 40	RD 52525 RD 52525			
000336 000340	125252	: MC	RD -52526 RD -52526			
000342 000344	052525 125252	. MO	RD 52525			
000346 000350	052525 125252 052525	. MO . MO . MO	RD -52526 RD 52525			
000352 000354	052525 135353	. 140	RD 52525			
000356 000360	125252 000024	PAT12: .WO	RD -52526 RD 24 RD 26455			
000362 000364	026455 026455	. 140	RD 26455			
000366	151322	. 140	RD 26455 RD -26456			
000370	026455 151322 151322 151322 026455	. 40	RD -26456 IRD -26456			
000374	026433	. 40	IRD -26456 IRD -26456 IRD -26456 IRD 26455 IRD 26455			
000400	151322 151322 026455	PAT12: .WG	RD -26456 RD -26456			
000404 000406	026455	. 60	RD 26455 RD 26455			
000410 000412	151322 026455	. MC	RD -26456 RD 26455			
000414 000416	151322 026455	. WO	RD -26456			
			20433			

	ZRQAM3 VO1.2	F	RD/RX EXERCISER TEST SECTION				14-Dec-1983 14-Dec-1983	16:12:07 16:12:00	VAX-11 Bliss-16 V3-555 Page 11 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (2)
CARL STREET, SECTION S	000420 000422 000424 000426 000430 000432 000434	151322 026455 151322 026455 000001 066666 000020		PAT13:	. WORD . WORD . WORD . WORD . WORD . WORD	-26456 26455 -26456 26455 1 66666			
STATE OF THE PERSON NAMED IN COLUMN TWO IS NOT THE OWNER. THE PERSON NAMED IN COLUMN TWO IS NOT THE OWNER.	000436 000440 000442 000444 000446 000450 000452	000001 000002 000004 000010 000020 000040 000100		FA124:	. WORD . WORD . WORD . WORD . WORD . WORD . WORD . WORD . WORD	1 2 4 10 20 40 100			
CARREL CONTRACTOR CARROLL STATES AND THE CARROLL SERVICES SARROLL SERVICES	000454 000456 000460 000462 000464 000466 000470	000200 000400 001000 002000 004000			- WORD	200 400 1000 2000 4000 10000 20000			
No made quinte a materiale de condition de canado incentro abbi somo alganosidade	000472 000474 000476 000500 000502 000504 000506 000510	020000 040000 100000 000020 177776 177775 177773 177767		PAT15:	. WORD . WORD . WORD . WORD . WORD . WORD . WORD . WORD	40000 -100000 20 -2 -3 -5 -11			
	000510 000512 000514 000516 000520 000522	177767 177757 177737 1777677 177577 177377 176777			. WORD . WORD . WORD . WORD . WORD . WORD . WORD . WORD . WORD	-21 -41 -101 -201 -401 -1001 -2001			
AND THE PERSON NAMED IN COLUMN TWO IS NOT THE OWNER, OF THE OWNER, OF THE OWNER, OF THE OWNER, OWNER	000526 000530 000532 000534 000536 000540	173777 167777 157777 137777		PAT16:	. WORD . WORD . WORD . WORD . WORD . WORD	-4001 -10001 -20001 -40001 77777 20			
White State of the	000544 000546 000550 000552 000554 000560	000020 133331 133331 133331 155554 155554 133331 133331 155554			. WORD . WORD	-4447 -4447 -4447 -2224 -2224 -2224 -4447			
The same provide the same party of the same same of the same same same of the same same same of the same same same of the same same of the same same same same same same same sam	000560 000562 000564 000566 000570	133331 155554 155554 133331 155554			. WORD . WORD . WORD . WORD	-44447 -22224 -22224 -44447 -22224			

ZRQAM3 VO1.2	RD/RX EXERCISER TEST SECTION		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 Page 12 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (2)
000572 133333 000574 155554 000576 133333 000600 155554 000602 00002 000604 000000 000606 106466 000612 071313 000614 071313 000616 071313 000620 106466 000622 106466 000624 106466 000626 106466	PAT17:	.WORD -44447 .WORD -22224 .WORD -44447 .WORD -22224 .WORD 0 .WORD 0 .WORD -71312 .WORD 71311 .WORD 71311 .WORD 71311 .WORD 71311 .WORD -71312 .WORD -71312 .WORD -71312 .WORD 71311		
000632 07131 000634 07131 000636 07131 000640 07131 000642 106466 000644 106466 000650 106466 000652 106466 000654 106466 000654 106466 000656 00002 000660 106466 000662 00000 000664 07131 000666 106466 000672 106466 000672 106466	PAT18:	.WORD -71312 .WORD -71312 .WORD -71312 .WORD -71312 .WORD -71312 .WORD -71312 .WORD 0 .WORD 71311 .WORD -71312 .WORD -71312 .WORD -71312 .WORD 71311 .WORD 71311 .WORD 71311		
000702 07131 000704 106466 000706 106466 000712 106466 000714 106466 000716 07131 000720 07131 000722 07131 000724 07131 000726 07131 000730 07131 000730 07131 000730 07131 000730 07131 000732 00002 000734 00000 000736 13463 000742 04314	PAT19:	.WORD 71311 .WORD -71312 .WORD -71312 .WORD -71312 .WORD -71312 .WORD 71311 .WORD 71311		

TRAINS   NO.   TEST SECTION   14-Dec-1983 16:12:07   TEST SECTION   14-Dec-1983 16:12:07   TEST SECTION   14-Dec-1983 16:12:07   TEST SECTION   14-Dec-1983 16:12:07   TEST SECTION   TE					05		
000746 0-3146		RD/RX EXERCISER TEST SECTION			14-Dec-1983 14-Dec-1983	16:12:07 16:12:00	VAX-11 Bliss-16 V3-555 Page 13 DISK*USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (2)
001112 000314' 001114 000356' .WORD PAT12	000746 04314 000750 13463 000752 13463 000754 13463 000760 04314 000762 04314 000764 04314 000766 04314 000772 13463 000774 13463 001002 13463 001004 13463 001004 03463 001012 00006 001014 04314 001016 13463 001022 13463 001024 04314 001026 04314 001030 04314 001030 04314 001030 04314 001031 13463 001041 13463 001042 13463 001045 04314 001050 04314	66	. WORD .	43146 -43147 -43147 -43147 43146 43146 43146 43147 -43147			

```
ZRQAM3
                                                               RD/RX EXERCISER
                                                                                                                                                                                                                                                                                                                                                                      DISK $USER2: [DIETZ.RDRX]ZRQACO.BL2:161 (2)
                                                                                                                                                                                                                                                                     14-Dec-1983 16:12:07 VAX-11 Bliss-16 V3-555
                                                               TEST SECTION
V01.2
                                                                                                                                                                                                                                                                     14-Dec-1983 16:12:00
001116 000430'
001120 000434'
                                                                                                                                                                                                  . WORD
                                                                                                                                                                                                                                   PAT13
                                                                                                                                                                                                    . WORD
                                                                                                                                                                                                                                   PAT14
001122 0004761
                                                                                                                                                                                                    . WORD
                                                                                                                                                                                                                                   PAT15
001124 000540
                                                                                                                                                                                                    . WORD
                                                                                                                                                                                                                                    PAT16
001126 0006021
                                                                                                                                                                                                   . WORD
                                                                                                                                                                                                                                    PAT17
001130 000656'
                                                                                                                                                                                                    . WORD
                                                                                                                                                                                                                                   PAT18
001132 000732'
                                                                                                                                                                                                     . WORD
                                                                                                                                                                                                                                    PAT19
 001134 001006'
                                                                                                                                                                                                     . WORD
                                                                                                                                                                                                                                    PAT20
001136 001062'
                                                                                                                                                                                                     . WORD
                                                                                                                                                                                                                                    PAT21
001140 000000
                                                                                                                                                                  BST.CNT:.WORD
001142 000000
                                                                                                                                                                   BST.DEV:.WORD
                                                                                                                                                                                                                                    0
                                                                                                                                                                   CURRENT. VECTOR:
001144
                                                                                                                                                                                                     .BLKW
                                                                                                                                                                    BRLEVEL: . BLKW
001146
001150
                                                                                                                                                                    DUOFF: .BLKW
001152
                                                                                                                                                                    COMPARE. DATA:
                                                                                                                                                                                                     .BLKB
                                                                                                                                                                                                  GLOBL CST, CST.ADDR, DCT, DCT.ADDR, RDRX.ADDR
GLOBL IRDRX.ADDR, ICOM.ADDR, ICST.ADDR
GLOBL IDCT.ADDR, DUPPKT, BST, TALLY
GLOBL T.ADDR, C.ERR.TBL, MSCP.PKT, IPKT.ADDR
PKT.USE, RETPKT, RP.USE, RP.INDX
GLOBL RP.ADDR, RDM.CNT, RANDOM, TRK.SGN
GLOBL ELOG.PKT, BUFF.ADDR, BUFF.OMN
GLOBL IODQ, IODQ.IN, IODQ.OUT, ENTRY.REASON
GLOBL EOP.FLAG, DUP.FLAGS, CCTLR, CDISK
GLOBL CUOFF, CTLR.CNT, DUR, QIO, FREE.MEM.ADDR
GLOBL BYTS.PER.QIO, ST.CODE, SB.CODE
GLOBL STEP, OF.RC, SA.REG, CMD.TIME
GLOBL STEP, OF.RC, SA.REG, CMD.TIME
GLOBL STEP, OF.RC, SA.REG, CMD.TIME
GLOBL S.DUPPKT, S.PATTERN, CREDIT.BAL
GLOBL INIT.OCCURED, NXT.PKT.2USE, DBM12
GLOBL DBM18, DBM19, DBM29, DBM108, DBM109
GLOBL DBM10, DBM112, EM.O, EM.1, EM.2
GLOBL DBM10, DBM112, EM.O, EM.1, EM.2
GLOBL EM.3, EH.4, EM.5, EM.6, EM.7, EM.8
GLOBL EM.9, EM.10, EM.12, EM.13, MSG.02
GLOBL EGD.12, EGD.13, EGD.14, EGD.15
GLOBL EGD.20, EGD.21, EGD.22, EGD.23
GLOBL EGD.20, EGD.21, EGD.22, EGD.23
GLOBL EX.MRD, CRLF, SMP.ERROR, SMP.XFER
GLOBL EX.MRD, CRLF, SMP.ERROR, SMP.XFER
GLOBL SMP.FLAGS, DUPROUND, SMP.RAT, SMP.DPAT
GLOBL SMP.CRLF, SMP.ERROR, SMP.XFER
GLOBL SMP.FLAGS, DUPROUND, SMP.RAT, SMP.DPAT
GLOBL SMP.CRLF, SMP.ERROR, SMP.XFER
GLOBL SMP.CRLF, SMP.CRCD, EX.SDD, EX.SDD
GLOBL SMP.CRLF, SMP.CRCD, EM.S.22
```

RD/RX EXERCISER TEST SECTION

14-Dec-1983 16:12:07 14-Dec-1983 16:12:00 VAX-11 Bliss-16 V3-555 Page 15 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (2) VAX-11 Bliss-16 V3-555

SEQ 0270

.GLOBL EMS.EL, EMS.CMP, EMS.10, EMS.12 .GLOBL EMS.13, EMS.14, EMS.18, EMS.21 .GLOBL EMS.30, L\$DLY

BIT15 ---100000 BIT14 --40000 BIT13 --20000 BIT12 --10000 BIT11== 4000 BIT10== 2000 1000 BIT09== BIT08 --400 BIT07--200 BIT06 --100 BIT05 --40 20 BIT04 --BIT03 --BIT02 --BIT01 --BIT00 --BIT9 --1000 BIT8 --400 BIT7 --200 **BIT6**--100 40 **BIT5**--20 BIT4 --BIT3 --4 2 1 40 37 36 35 34 340 300 240 200 BIT2 --BIT1 --BITO --EF.START == EF.RESTART == EF.CONTINUE --EF.NEW .. EF.PWR --PRI07 --PRI06 --PRI05 --PRI04 --140 100 PRI03 --PRI02 --PRI01 --40 04 PRI00 --EVL --10 20 40 100 200 400 LOT--ADR == IDU--ISR --UAM --BOE --PNT --1000 PRI --

	ZRQAM3		RD/RX EX	KERCISER					14-Dec-1983 16:12:07	V	AX-11 Bliss-16 V3-555	SEQ 0271 Page 16
	V01.2		TEST SEC						14-Dec-1983 16:12:00	D	AX-11 Blies-16 V3-555 ISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2	161 (2)
Consideration of the constant		004000 010000 020000 040000 100000			IXE == IBE == IER == LOE == HOE ==			4000 1000 2000 4000 -100	00			
	000000					.SBTTL .PSECT	\$T1 \$COD	TEST	SECTION RO			
	000000	004137	000000G		\$T1:	JSR TST	R1.\$	SAVE	:3	:		1847
	000006	112737 112737 042737 004737 032737	000001 000002 000000V	000000G 001152' 000000G		MOVB MOVB BIC JSR BIT	#1.E #1.C #2.D PC.I	OP.F OMPA UP.F NIT.	LAG NRE.DATA LAGS TEST FLAGS	:		1858 1859 1860 1861 1863
-	000042 000044	001403 042737 005003	000040	000000G		BEG	440.		FLAGS			1864
	000054 000056 000062	010346 012746 004737	000076 000000G		1\$: 2\$:	CLR MOV MOV JSR MOV CMP	R3 R3,- #76, PC.B RO,R (SP)	-(SP  L#MU  1  +,(S	P) L SP)+		CTLR,*	1866 1868
	000106	010001 022626 005761 100040 010346 012746 004737 022626 005760	000002G 00000G 00000G			TST BPL MOV MOV JSR CMP TST	CST+ 6‡ R3,- #22, PC,B (SP) DCT(	(SP) -(SP L#MU			CTLR.*	1869
	000124	022626 005760 100027 010346 012746 004737	000037 000000G			BPL MOV MOV JSR	6\$ R3,- \$37, PC.B	(SP)	)		CTLR.+	1875
	000134 000140 000142 000144	012702 010001 060201 006301 032761	000003		36:	MOV MOV ADD ASL	#3.R RO.R R2.R R1	12		:	*.OFFSET OFFSET.*	1873 1875
-	000144 000146 000154 000156	032761 001403 105037	000000G	00000G		BIT BEQ CLRB	#200 4\$ EOP.		CST(R1)			1979
	000162 000164 000170 000174	000405 062702 020227 003761	000007 000031		46:	BR ADD CMP BLE	54 47,R R2,4	12		:	4.OFFSET OFFSET.4	1878 1877 1873
Married Account of the Party of	000176 000200 000202	022626 005203 000243			5#: 6#:	INC	(SP) R3 LV!CL		SP)+		CTLR	1866
Section of Section 2	000204 000206	003723 132737	000001	000000G		BLE	2\$ #1,E	OP.F	FLAG			1882

-	
NI	-
1.71	1

ZRQAM3 VO1.2	RD/RX EXERCISER TEST SECTION		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555	0272 Page 17 1 (2)
000214 001002 000216 004737 000222 012701 000226 001410 000230 013700 000234 001403 000236 005016 000240 005300 000242 001375 000244 005301 000246 000767 000250 005726 000252 000207 : Routine Size: ; Maximum stack	000000V 000012	BNE JSR MOV BEQ MOV BEQ CLR DEC BNE DEC BR TST RTS	7\$ PC.MULTI.DRIVE #12.R1 11\$ L\$DLY.R0 10\$ (SP) R0 9\$ R1 8\$ (SP)+ PC	: *, \$ \$ TMP2 : *, \$ \$ TMP1 : \$ \$ TMP1 : \$ \$ TMP2 :	1884 1886
000000 004737 000000 000004 104466 000006 006000 000010 103773 000012 000207	000000° T1::	.SBTTL  JSR TRAP ROR BLO RTS	T1 TEST SECTION  PC.\$T1 66 R0 1\$ PC		1886
: Routine Size: : Maximum stack	6 words, Routine Base: depth per invocation: 2 words	*CODE* +	0254		

```
SEQ 0273
ZRQAM3
                    RD/RX EXERCISER
                                                                                   14-Dec-1983 16:12:07
                                                                                                                  VAX-11 Bliss-16 V3-555
                                                                                                                  VAX-11 Bliss-16 V3-555 Page 18
DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2:161 (3)
V01.2
                     INITIALIZATION TEST ROUTINES
                                                                                   14-Dec-1983 16:12:00
                    #abttl 'INITIALIZATION TEST ROUTINES'
             1889
             1890
                    routine INIT_TEST : novalue =
             1891
             1892
             1893
                               THE INITIALIZATION TEST IS DESIGNED TO VERIFY THE EXISTENCE OF THE
                    :
             1894
                               DEVICES AS CONFIGURED BY THE OPERATOR DURING THE HW DIALOG, AND TO
                               BRING EACH DEVICE ONLINE IN PREPARATION FOR EITHER THE MULTI-DRIVE TEST
             1895
             1896
                               OR THE DM EXERCISER.
             1897
                               BASICALLY, THE DEVICES ARE BROUGHT ONLINE VIA "DRIVER_INIT", WHICH IS INVOKED IMMEDIATELY. ANY DEVICES WHICH FAIL DURING THIS PHASE WILL BE MARKED OFFLINE IN THEIR DCT AND CST. FOR THOSE DEVICES WHICH SURVIVE
             1898
             1899
             1900
             1901
                               THE INITIALIZATION, THIS ROUTINE WILL ATTEMPT 1 OR 2 ACCESS COMMANDS TO
                               EACH DISK VIA ROUTINE "ACCESS". THE INITIALIZATION TEST IS DEEMED A SUCCESS IF A BLOCK ON THE INNER TRACK OF EACH DISK CAN BE ACCESSED.
             1902
             1903
             1904
             1905
             1906
                         begin
DRIVER_INIT ();
             1907
                                                                                   ! INIT DRIVER DATA AND DEVICES
             1908
:
             1909
                          incr CTLR from 0 to (MAX_CTLR - 1) do
                                                                                   ! FOR EACH CONTROLLER
             1910
                               begin
SET_CPAR (.CTLR);
             1911
                                                                                   ! SET UP COMMONLY-USED CONTROLLER-RELATED DATA ITEMS
             1912
             1913
                               if .CST_ADDR (STATE) eql ONLINE
                                                                                   ! IF CONTROLLER IS STILL ALIVE
             1914
                               then
             1915
             1916
                                    incr OFFSET from (0 + OF_UN) to (3 + UNIT_SIZE + OF_UN) by UNIT_SIZE do
                                                                                                                                      ! FOR EACH DISK
             1917
                                         if (.CST_ADDR [.OFFSET, D_PRES] eql PRESENT) and
  (.CST_ADDR [.OFFSET, D_STAT] eql ONLINE) and
  (not .CST_ADDR [.OFFSET, D_FATAL])
             1918
             1919
             1920
             1921
                                         then
                                              begin
SET_UPAR (.OFFSET); ! SET UP UNIT-RELATED DATA ITEMS
IF SWP_DINT NEQ (.DUP_FLAGS AND SWP_DINT) ! IF DUP CAUSED INIT THEN SKIP THIS SECTION
THEN ACCESS (); ! TRY ACCESS TO INNER TRACK
PRESENT AND ONLINE
             1922
             1923
             1924
             1925
             1926
             1927
:
             1928
:
                               end;
                                                                                   ! CONTROLLER LOOP
             1929
:
             1930
.
                          end:
                                                                                   ! ROUTINE INIT_TEST
                                                               .SBTTL INIT.TEST INITIALIZATION TEST ROUTINES
000000 004137 000000G
                                                    INIT. TEST:
                                                              J'SR
                                                                        R1. $SAVE2
                                                                                                                                                                      1890
000004
          004737
                    000000V
                                                              JSR
                                                                        PC, DRIVER. INIT
                                                                                                                                                                      1907
000010
          005002
                                                                                                                  : CTLR
                                                              CLR
                                                                        R2
                                                                                                                                                                      1909
000012
          010246
                                                              MOV
                                                                        R2, -(SP)
                                                    18:
                                                                                                                  : CTLR. .
                                                                                                                                                                      1911
000014
          004737
                    000000G
                                                                        PC. SET. CPAR
                                                              JSR
000020
          013700
                    000000G
                                                              MOV
                                                                        CST. ADDR. RO
                                                                                                                                                                      1913
                                                                                                                  .
```

ZRQAM3 VO1.2		RD/RX EXERCISER INITIALIZATION TEST R	DUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.	SEQ 0274 Page 19 BL2;161 (3)
000024	005760 100035	000002		TST BPL	2(RO)		1
000032 000036 000040	012701 010100 006300	000003	24:	MOV MOV ASL	#3,R1 R1,R0 R0	: *,OFFSET : OFFSET,*	1916 1918
000042 000046 000052	063700 032710 001417	000000G 040000		BIT	CST.ADDR,R0 #40000,(R0)		
000054 000060 000062	032710	020000		BEQ BIT BEQ	3\$ #20000.(RO) 3\$		1919
000066	032710 001011 010116	010000		BIT BNE MOV	#10000,(R0) 3# R1,(SP)	: OFFSET.4	1920 1923
000072 000076 000104	004737 032737 001002	000000G 000000G		JSR BIT BNE	PC.SET.UPAR #2.DUP.FLAGS 3#	1	1924
000106 000112 000116	004737 062701 020127	000000V 000007 000030	3\$:	JSR ADD CMP	PC.ACCESS 07.R1 R1.030	: +.OFFSET : OFFSET.+	1925 1916
000122 000124 000126 000130	003745 005726 005202 000243		44:	BLE TST INC . WORD	2\$ (SP)+ R2 CLV!CLC	CTLR	1910 1909
000132 000134	003727 000207			BLE	18 PC		1890
: Rout	ine Size: num stack	47 words. Routing depth per invocation:	ne Base: 5 words	\$CODE\$	• 0270		

```
SEQ 0275
ZRQAM3
                   RD/RX EXERCISER
                                                                            14-Dec-1983 16:12:07
                                                                                                         DISK#USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (4)
                                                                                                         VAX-11 Bliss-16 V3-555
V01.2
                   INITIALIZATION TEST ROUTINES
                                                                            14-Dec-1983 16:12:00
            1931 routine DRIVER_INIT : novalue =
            1932
.
            1933 !+
            1934
                            THIS ROUTINE IS EQUIVALENT IN FUNCTION TO THE INITIALIZATION ENTRY
            1935
                            POINT OF A STANDARD DEVICE DRIVER. ITS RESPONSIBILITY IS TO INITIALIZE
            1936
                            DRIVER DATA, AND TO BRING EACH RDRX CONTROLLER AND UNIT (DISK)
            1937
                            ONLINE.
            1938 !-
            1939
            1940
                       begin
            1941
            1942
                        local
            1943
                            PKT_ADDR:
            1944
            1945
                        PKT_ADDR = MSCP_PKT + 10:
                                                                            ! ADDR (TEXT + 0) OF FIRST MSCP PACKET
            1946
1947
1948
                        NXT_PKT_2USE . O:
:
                                                                            ! NEXT PACKET TO ALLOCATE
.
                        incr COUNT from 0 to (PKT_CNT - 1) do
:
                                                                            ! FOR EACH MSCP PACKET
                            PKT_USE [.COUNT] = -1;

MSCP_PKT [.COUNT, PKT_LO] = .PKT_ADDR; ! LOAD PKT ADDR INTO BUFFER DESCRIPTOR

MSCP_PKT [.COUNT, PKT_HI] = 0;

MSCP_PKT [.COUNT, CONNID] = CID_MSCP; ! SET CONNECTION ID TO MSCP ID

MSCP_PKT [.COUNT, CONNID] = CID_MSCP; ! ADVANCE ADDR TO NEXT PACKET
            1949
:
            1950
            1951
            1952
            1953
.
            1954
            1955
                            end:
            1956
            1957
                        incr CTLR from 0 to (MAX_CTLR - 1) do
                                                                            ! FOR EACH CONTROLLER
            1958
:
            1959
                            if .CST [.CTLR, IP_ADDR] nega 0
.
                                                                            ! IF CONTROLLER IS PRESENT
            1960
1961
1962
                            then
                                 SET_CPAR (.CTLR);
                                                                            ! SET UP CURRENT CONTROLLER PARAMETERS
                                 CURRENT_VECTOR = .CST_ADDR (VEC_ADDR); ! SET CURRENT CONTROLLER'S VECTOR = .CST_ADDR (BR_LEV) + 5; ! SET CURRENT CONTROLLER'S BR LEVEL
            1963
                                                                                     ! SET CURRENT CONTROLLER'S VECTOR ADDRESS
            1964
                                 CTLR_INIT ():
            1965
                                                                            ! INIT DEVICE AND CTLR DATA
            1966
            1967
                                 if .DCT_ADDR [STAT] eql ONLINE
                                                                            ! IF CONTROLLER IS STILL ALIVE
            1968
            1969
.
            1970
:
                                      incr OFFSET from (0 + OF_UN) to (3 * UNIT_SIZE + OF_UN) by UNIT_SIZE do ! FOR EACH UNIT (DISK)
            1971
:
            1972
                                           if (.CST_ADDR [.OFFSET, D_PRES] eql PRESENT) and ! IF UNIT EXISTS
            1973
                                              (not .CST_ADDR [.OFFSET, D_FATAL])
            1974
                                           then
            1975
                                               SET_UPAR (.OFFSET);
UNIT_INIT ();
            1976
                                                                            ! SET UP UNIT-RELATED DATA ITEMS
            1977
                                                                              BRING UNIT ONLINE
            1978
                                                                            ! IF UNIT EXISTS
                                               end:
            1979
            1980
                                 end:
                                                                            ! IF CONTROLLER IS PRESENT
            1981
            1982
                        end;
                                                                            ! ROUTINE DRIVER_INIT
```

000004 012 000010 105 000014 005 000016 112 000024 010 000026 012 000032 004 000036 010 000042 005 000046 105 000052 062	4137 000000G 2702 000012G 5037 000000G 5001 2761 000377 0146 2746 000104 4737 000000G 0260 000000G		DRIVER.	.SBTTL INIT: JSR MOV CLRB			
000004 012 000010 105 000014 005 000016 112 000024 010 000026 012 000032 004	2702 000012G 5037 000000G 5001 2761 000377 0146 2746 000104 4737 000000G 0260 000000G			INIT: JSR MOV CLRB	DRIVER.INIT INITIALIZATION TEST	ROUTINES	
000004 012 000010 105 000014 005 000016 112 000024 010 000026 012 000032 004	2702 000012G 5037 000000G 5001 2761 000377 0146 2746 000104 4737 000000G 0260 000000G			INIT: JSR MOV CLRB			
000004 012 000010 105 000014 005 000016 112 000024 010 000026 012 000032 004	2702 000012G 5037 000000G 5001 2761 000377 0146 2746 000104 4737 000000G 0260 000000G			JSR MOV CLRB	R1. \$SAVE2		
000010 105 000014 005 000016 112 000024 010 000026 012 000032 004 000036 010	5037 000000G 5001 2761 000377 0146 2746 000104 4737 000000G 0260 000000G		14:	MOV	AMSCD DKTA12 D2		1931
000014 005 000016 112 000024 010 000026 012 000032 004 000036 010	5001 2761 000377 0146 2746 000104 4737 000000G 0260 000000G		18:	CLRB	WINGE ILVIATE IVE	# .PKT.ADDR	1945
000016 112 000024 010 000026 012 000032 004 000036 010	2761 000377 0146 2746 000104 4737 000000G 0260 000000G	000000G	18:		NXT.PKT.2USE	1	1946
000024 010 000026 012 000032 004 000036 010	0146 2746 000104 4737 000000G 0260 000000G	00000G	1\$:	CLR	R1	COUNT	1948
000026 012 000032 004 000036 010	2746 000104 4737 000000G 0260 000000G			MOVB	#377,PKT.USE(R1)	: *,*(COUNT)	1950
000032 004	4737 000000G 0260 000000G			MOV	R1(SP) #104(SP) PC.BL#MUL R2.MSCP.PKT(R0) MSCP.PKT+2(R0) MSCP.PKT+11(R0)	: COUNT, 4	1951
000036 010	0260 000000G			JSR	PC DI AMI		
000000 000	5060 0000026			MOV	PO MSCP PKT(PA)	; PKT.ADDR.4	
000046 105 000052 062 000056 022				CLR	MSCP.PKT+2(RO)	, FRI. ADDR, *	1952
000052 062 000056 022	5060 000011G			CLRB	MSCP.PKT+11(RO)		1953
000056 022	2702 000104			ADD	#104.R2	PKT. ADDR	1954
	2626			CMP	#104.R2 (SP)+,(SP)+	1	1949
000060 005	5201			INC	R1	COUNT	1948
000065 050	0127 000013			CMP	R1,013	; COUNT, *	
000066 003	3753			BLE	16		
000070 005	5002			CLR	R2	; CTLR	1957
000072 010	0246 2746 000076 4737 000000G		2\$:	MOV	R2,-(SP)	: CTLR,*	1959
000074 012	2746 000076 4737 000000G			MOV	476,-(SP)		
000104 022	2626			JSR	PC,BL#MUL		
000106 005	2626 5760 000000G			CMP	(SP)+,(SP)+ CST(RO)		
000112 001	1460			REO	6\$		
000112 001 000114 010	0246			MOV	82 -(SP)	: CTLR.+	1962
000116 004	4737 000000G			JSR	R2,-(SP) PC.SET.CPAR CST.ADDR.R0 2(RO),CURRENT.VECTOR #177000,CURRENT.VECTOR	, CILN, -	1702
000122 013	3700 000000G			MOV	CST. ADDR. RO		1963
000126 016	6037 000002	001144'		MOV	2(RO), CURRENT, VECTOR		1,00
000134 042	2737 177000	001144'		BIC	#177000, CURRENT, VECTOR		
000142 005	5016			CLR	(SP)		1964
000144 116	6016 000004 2746 000005 4737 000000G			MOVB	4(RO),(SP)		
000150 012	2746 000005			MOV	45,-(SP) PC,BL#SHF		
000154 004	4737 000000G			JSR	PC.BL+SHF		
000160 010 000164 004	0037 001146			MOV	RO.BRLEVEL PC.CTLR.INIT		
000170 000	0037 001146' 4737 000000V 5777 000000G			JSR	PC.CILR.INIT		1965
000174 100	0026			TST	ADCT . ADDR		1967
000176 012	2701 000003			BPL MOV	03.R1	. A DEECET	1070
000202 010	0100		34:	MOV	R1.RO	: *.OFFSET : OFFSET.*	1970 1972
000204 000	0100 6300		54.	ASL	RO	, orraci, .	1415
000206 063	3700 000000G			ADD	CST.ADDR,RO		
000212 032	2710 040000			BIT	#40000,(RO)		
000216 001	1410			BEQ BIT BNE	46		
000220 032	2710 010000			BIT	#10000,(RO)	1	1973
000224 001	1005			BNE	41		
000226 010	0116			MOV	R1.(SP)	: OFFSET.*	1976
000230 004	4737 000000G			JSR	PC.SET.UPAR		
000E34 004	4737 000000V 2701 000007			JSR	PC.UNIT.INIT		1977
000244 020	0127 000030		46:	ADD	#7,R1 R1,#30	: *.OFFSET : OFFSET.*	1970
000250 003	JOOUSU				MI. 430	I UFF SEI. #	

 ZRQAM3 VO1.2	RD/RX EXERCISER INITIALIZATION TEST ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.B	SEQ 0277 Page 22 L2:161 (4)
000252 022626 000254 005202 000256 000243	5\$: 6\$:	CMP INC . WORD	(SP)+,(SP)+ R2 CLV!CLC	CTLR	1961 1957
 000260 003704 000262 000207		BLE RTS	PC PC		1931
 : Routine Size	90 words. Routine Rase:	*CODE *	. 0426		

: Maximum stack depth per invocation: 6 words

```
ZRQAM3
                  RD/RX EXERCISER
                                                                        14-Dec-1983 16:12:07
                                                                                                   VAX-11 Bliss-16 V3-555
V01.2
                  INITIALIZATION TEST ROUTINES
                                                                        14-Dec-1983 16:12:00
                                                                                                   DISK $USER2: [DIETZ.RDRX]ZRQACO.BL2:161 (5)
                 routine CTLR_INIT : novalue =
           1984
:
           1985
                 . .
                           THIS "DRIVER" ROUTINE IS CALLED FROM DRIVER_INIT FOR EACH CONTROLLER CONFIGURED FOR TESTING. ITS GENERAL PURPOSE IS TO BRING THE RDRX ONLINE
           1986
           1987
           1988
                           TO THE HOST. SPECIFICALLY, IT IS WRITTEN TO:
           1989
           1990
                           1. INITIALIZE DRIVER CONTROLLER DATA, INCLUDING THE DCT.
                           2. SET UP THE DEVICE'S INTERRUPT VECTOR ADDRESS,
3. PERFORM A REGISTER EXISTENCE TEST TO VERIFY THE DEVICE'S PRESENCE,
           1991
:
           1992
           1993
                           4. PERFORM A VECTOR AND BR LEVEL TEST TO VERIFY THE DEVICE'S VECTOR
           1994
                                    ADDRESS AND INTERRUPT REQUEST LEVEL.
.
           1995
                           5. DO A HARD INITIALIZATION (FOUR STEPS) ON THE DEVICE.
.
           1996
1997
.
                           IF ANY OF THESE INITIAL TESTS FAIL, THEN ALL UNITS ASSOCIATED WITH THE
:
           1998
                           DEVICE ARE DROPPED.
:
           1999
                 ! -
:
           2000
:
           2001
                      begin
.
           2002
           2003
                      local
           2004
                           RESULT : byte:
:
           2005
           2006
                      INI_CTLR_DAT ():
                                                                        ! INITIALIZE CONTROLLER DATA
           2007
                      SETVEC (.CURRENT_VECTOR, .INT_ADDR [.CCTLR], PRIO7);
DCT_ADDR [IG_INT] = TRUE; ! SET "IG
:
                                                                                          ! SET DEVICE'S ASSUMED VECTOR ADDRESS
           2008
                                                                        ! SET "IGNORE INTERRUPT" BIT
           2009
                      L$LUN = .CST_ADDR [OF_UN, D_UNIT]:
                                                                        ! GET FIRST UNIT NUMBER OF CONTROLLER
           2010
                                                                        ! (USED BY DRS FOR DEVICE-FATAL CTLR ERRORS)
           2011
                  IF SMP_DINT NEQ (.DUP_FLAGS AND SMP_DINT)
                                                                        ! IF DUP CAUSED INIT THEN SKIP THIS SECTION
           2012
                  THEN
           2013
                       if REG_EXIST () eql FAILURE
                                                                        ! REGISTER EXISTENCE TEST
           2014
                      then
           2015
                          begin
DROP_CTLR (.CCTLR, DU_INIT);
           2016
                                                                      ! DROP ALL CONTROLLER'S UNITS
           2017
                           return;
           2018
                           end:
           2019
                  IF SWP_DINT NEQ (.DUP_FLAGS AND SWP_DINT)
           2020
:
                                                                        ! IF DUP CAUSED INIT THEN SKIP THIS SECTION
           2021
                  THEN
:
           2022
                      if VEC_BR_TEST () eql FAILURE
                                                                        ! VECTOR ADDR AND BR LEVEL TEST
           2023
                      then
           2024
2025
2026
                           begin
DROP_CTLR (.CCTLR, DU_INIT);
                                                                        ! DROP ALL CONTROLLER'S UNITS
                           return:
           2027
                           end:
           2028
           2029
                      RESULT - HARD_INIT ();
                                                                        ! ATTEMPT HARD DEVICE INIT
           2030
                      DCT_ADDR [IG_INT] - FALSE:
                                                                        ! CLAER "IGNORE INTERRUPT" BIT
           2031
           2032
                      if .RESULT eal SUCCESS
                                                                        ! IF HARD INIT WAS SUCCESSFUL
           2033
                      then
.
           2034
                          begin
INI_RRING ();
.
           2035
:
                                                                        ! INITIALIZE RESPONSE RING
```

					110		
ZRQAM3 VO1.2			XERCISER IZATION TEST	ROUTINES	14-Dec-1983 16:12: 14-Dec-1983 16:12:	VAX-11 Bliss-16 V3-555 DISK#USER2:[DIETZ.RDRX]Z	SEQ 0279 Page 21 RQACO.BL2:161 (5)
	2036		WRT_RDRX (RO	CSA. RC_ALL. SA_GO)	! SET "GO" BIT (ST	TART CTLR POLLING)	
	2037 2038 2039 2040		if SET_CTLR	_CHAR () eql SUCCESS	! SET CONTROLLER C	CHARACTERISTICS	
	2041 2042 2043 2044 2045		DCT_ADDR CST_ADDR end;	R (STAT) = ONLINE; R (STATE) = ONLINE;	! MARK CONTROLLER ! MARK CONTROLLER	ONLINE IN "DRIVER" ONLINE IN "PROGRAM"	
:	2046	else			! HARD INIT FAILED		
	2047 2048 2049		DROP_CTLR ( end;	.CCTLR, DU_INIT);	! DROP ALL CONTROL	LER'S UNITS	
1	2050 2051	end			! ROUTINE CTLR_INI	п	
000000	010146			.SBTTL	CTLR.INIT INITIALIZATION 1	TEST ROUTINES	
000002	004737	000000V		MOV JSR	R1(SP) PC.INI.CTLR.DAT		1983
000006	012746	000340		MOV	4340,-(SP)		2006 2007
000012	013700 006300	000000G		MOV ASL	CCTLR, RO		
000020	016046	0000741		MOV	INT.ADDR(RO),-(SP)		
000024 000030	013746	001144		MOV	CURRENT. VECTOR, -(SP)		
000034 000036	104437			TRAP	37		
000036	052777 013700	040000 000000G	000000G	BIS	#40000, SDCT. ADDR CST. ADDR, RO	. 한 10년 - 10년	2008
000044 000050 000054	016001	000006		MOV	6(RO),R1		2009
000054	000301	177760		SWAB	R1 #177760.R1		
000062	010137	000000G		MOV	R1.L\$LUN		
000066 000074	032737 001025	000002	000000G	BIT	#2.DUP.FLAGS		2011
000076	004737	000000V		BNE	PC.REG.EXIST		2013
000102	005700			TST	RO		
000106	001410 032737	00000/2	00000G	BEQ	1\$ #2.DUP.FLAGS		2016 2020
000104 000106 000114 000116 000122 000124 000126	001015			BNE	21		
000118	004737 005700	000000V		JSP. 7ST	PC.VEC.BR.TEST		2022
000124	001011			BNE	24		
000126	013716 012746	00000G		14: MOV	CCTLR,(SP)		2025
000136	004737	000000G		MOV JSR	#2,-(SP) PC.DROP.CTLR		
000132 000136 000142 000146 000150	062706	000012		ADD	●12.SP		2022
000150	000450 004737	000000V		2#: BR	PC.HARD.INIT		2024 2029
000154	110001			MOVB	RO,R1	RESULT	2029
000156	042777	040000	00000G	BIC	#40000, BDCT . ADDR		2030

-	ZRQAM3 VO1.2		RD/RX EXERCISER INITIALIZATION TEST ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL	SEQ 0280 Page 25 2;161 (5)
-	000164	120127	000001	CMPB BNE	R1.#1	; RESULT,*	2032
	000172 000176 000202	004737 012701 013700	000000V 000001 000000G	JSR MOV MOV	PC, INI.RRING #1,R1 RDRX, ADDR, RO	* *,RC.REG	2035 2036
	000206 000212 000216	010160 004737 020027	000002 000000V 000001	MOV JSR CMP	R1,2(R0) PC.SET.CTLR.CHAR R0,#1	: RC.REG.*	2038
-	000222 000224 000232 000236	001020 052777 013700 052760	100000 000000G 000000G 100000 000002	BNE BIS MOV BIS	4\$ #100000, aDCT. ADDR CST. ADDR, RO #100000, 2(RO)		2041 2042
-	000244 000246 000252 000256	000407 013716 012746	000000G 000002	BR MOV MOV	4\$ CCTLR,(SP) #2,-(SP)	:	2032 2048
	000256 000264 000270 000272	004737 005726 062706 012601 000207	000000G 000010 4\$: 5\$:	JSR TST ADD MOV RTS	PC.DROP.CTLR (SP)+ #10.SP (SP)+,R1 PC		2047 2001 1983

<sup>:</sup> Routine Size: 94 words. Routine Base: \$CODE\$ + 0712 : Maximum stack depth per invocation: 7 words

```
SEQ 0281
ZRQAM3
                   RD/RX EXERCISER
                                                                              14-Dec-1983 16:12:07
                                                                                                            VAX-11 Bliss-16 V3-555
                                                                                                                                                         Page 26
V01.2
                   INITIALIZATION TEST ROUTINES
                                                                              14-Dec-1983 16:12:00
                                                                                                            DISK $USER2: [DIETZ.RDRX]ZRQACO.BL2:161 (6)
                   routine INI_CTLR_DAT : novalue =
            2053
:
            2054
:
            2055
                             THIS ROUTINE IS RESPONSIBLE FOR INITIALIZING ALL CONTROLLER-RELATED
.
            2056
                             DATA IN THE "DRIVER" PORTION OF THE EXERCISER. THIS INCLUDES THE
            2057
                             CONTROLLER'S DCT AND OUTSTANDING COMMAND LIST.
.
            2058
.
            2059
                             IMPLICIT INPUTS:
:
            2060
                                       CCTLR - CURRENT CONTROLLER NUMBER
:
            2061
                                       DCT_ADDR - ADDRESS OF CURENT CONTROLLER'S DCT
:
            2062
.
            2063
                        begin
DCT_ADDR [WORDO] = 0;
DCT_ADDR [RR_BEG] = COMM_AREA + 8 + (.CCTLR * COMM_LEN * 2);
DCT_ADDR [RR_END] = .DCT_ADDR [RR_BEG] + ((RRING_LEN - 1) * 4);
DCT_ADDR [CR_BEG] = .DCT_ADDR [RR_END] + 4;
DCT_ADDR [CR_END] = .DCT_ADDR [CR_BEG] + ((CRING_LEN - 1) * 4);
DCT_ADDR [RR_POLL] = .DCT_ADDR [RR_BEG];
DCT_ADDR [CR_POLL] = .DCT_ADDR [CR_NEXT] = .DCT_ADDR [CR_BEG];
            2064
.
            2065
                                                                                                            ! CLEAR FIRST DCT WORD
:
            2066
                                                                                                            ! START OF RESPONSE RING
.
            2067
                                                                                                             ! LAST SLOT IN RESPONSE RING
:
            2068
                                                                                                             ! START OF COMMAND RING
:
            2069
                                                                                                             ! LAST SLOT IN COMMAND RING
.
            2070
                                                                                                             ! FIRST RRING SLOT TO POLL
            2071
:
                                                                                                             ! CRING POLL AND NEXT COMMAND POINTERS
            2072
                        end:
.
                                                           .SBTTL INI.CTLR.DAT INITIALIZATION TEST ROUTINES
000000 004137 000000G
                                                 INI.CTLR.DAT:
                                                                     R1. $SAVE2
                                                           JSR
                                                                                                                                                              2052
000004
         013701
                                                           MOV
                   000000G
                                                                     DCT.ADDR.R1
                                                                                                                                                              2065
000010
         005011
                                                           CLR
                                                                     (R1)
000012
         012702
                   000004
                                                           MOV
                                                                     44,R2
                                                                                                                                                              2066
000016
         060102
                                                           ADD
                                                                     R1,R2
000020
         013746
                                                                     CCTLR, -(SP)
#50, -(SP)
PC,BL#MUL
                   000000G
                                                           MOV
000024 012746
                                                           MOV
                   000050
000030 004737
                   000000G
                                                           JSR
000034
         062700
                   000010
                                                           ADD
                                                                     COMM. AREA+10.RO
000040
         010012
                                                           MOV
                                                                     RO,(R2)
000042
         010061
                   000006
                                                           MOV
                                                                     RO,6(R1)
                                                                                                                                                              2067
                                                                                                             :
000046
         062761
                   000014
                                                           ADD
                             000006
                                                                     #14,6(R1)
         012700
000054
                   000010
                                                           MOV
                                                                     #10.RO
                                                                                                                                                              2068
000060
         060100
                                                           ADD
                                                                     R1.RO
         016110
                   000006
                                                           MOV
                                                                     6(R1),(R0)
000066
         062710
                   000004
                                                           ADD
                                                                     44,(RO)
000072
         011061
                   000012
                                                           MOV
                                                                     (RO), 12(R1)
                                                                                                                                                              2069
000076
         062761
                   000014
                                                                     #14,12(R1)
(R2),14(R1)
                             000012
                                                           ADD
         011261
000104
                   000014
                                                           MOV
                                                                                                                                                              2070
000110
         011061
                   000020
                                                                     (RO),20(R1)
(RO),16(R1)
                                                           MOV
                                                                                                                                                              2071
000114
         011061
                   000016
                                                           MOV
000120
         022626
                                                           CMP
                                                                     (SP)+,(SP)+
                                                                                                                                                              2064
000122
         000207
                                                                                                                                                              2052
; Routine Size: 42 words,
                                       Routine Base: #CODE# + 1206
```

: Maximum stack depth per invocation: 6 words

Page 27

```
ZRQAM3
                        RD/RX EXERCISER
                                                                                               14-Dec-1983 16:12:07
                                                                                                                                   VAX-11 Bliss-16 V3-555
                        INITIALIZATION TEST ROUTINES
V01.2
                                                                                               14-Dec-1983 16:12:00
                                                                                                                                   DISK$USER2: [DIETZ.RDRX]ZRQACO.BL2:161 (7)
               2073 routine REG_EXIST =
               2074
.
               2075
                      ! +
                                   THIS IS THE REGISTER EXISTENCE (OR "PROBE") TEST DESIGNED TO VERIFY THE PRESENCE OF AN RDRX DEVICE. THIS OBJECTIVE IS ACCOMPLISHED BY SETTING UP THE NON-EXISTENT MEMORY (NEX) TRAP VECTOR (LOCATION 4) AND ATTEMPTING TO READ WHAT IS ASSUMED TO BE THE DEVICE'S SA AND IP REGISTERS. IF THE NEX TRAP HANDLER IS INVOKED DUE TO AN ABSENT DEVICE, THEN THE GLOBAL DATUM "NEX" WILL BE SET TO "TRUE". THIS DATUM DETERMINES THE SUCCESS / FAILURE VALUE OF THIS ROUTINE.
               2076
               2077
.
               2078
.
               2079
:
               2080
:
               2081
:
               2082
:
               2083
                       ! -
               2084
:
               2085
                              begin
.
               2086
.
               2087
                              local
.
               2088
                                    TEMP : word.
                                                                                                ! TEMP FOR READING SA AND IP
.
               2089
                                    DUMMY : word:
                                                                                               ! AS THE NAME IMPLIES
:
               2090
:
               2091
                              if .ENTRY_REASON egl NEW_PASS
               2092
                              then
:
               2093
                                    return SUCCESS:
                                                                                               ! SKIP TEST FOR NEXT PASS
.
               2094
               2095
                              OF_RC = 2:
                                                                                               ! SET UP TO READ SA FIRST
               2096
               2097
                              do
               2098
                                    begin
NEX = FALSE;
               2099
                                                                                                ! SET TO "TRAP NOT RECEIVED"
                                                                                                  SET LOCATION 4 TRAP VECTOR ADDRESS
READ REGISTER (THEN TRAP OR CONTINUE)
                                    SETVEC (4. NEX_TRAP, PRIO7):
               2100
               2101
                                    TEMP = .(.RDRX_ADDR + .OF_RC);
               2102
                                    DUMMY = 0:
                                                                                                ! DUMMY INSTRUCTION TO COVER TRAP RETURN BUG
               2103
                                                                                                            (TRAP RETURNS TO NEXT INSTRUCTION)
               2104
                                                                                                ! CLEAR LOCATION 4 TRAP VECTOR ADDRESS
                                    CLRVEC (4):
               2105
               2106
                                    IF .NEX
                                                                                                ! IF NEX TRAP OCCURRED
.
               2107
                                    then
                                         begin

C_ERR_TBL [.CCTLR, C_ERR_MRD] = .C_ERR_TBL [.CCTLR, C_ERR_HRD] + 1;

ERROF (10, EGD_10, EMS_10); ! REGISTER EXISTENCE TEST FAILED

SETPRI (PRIOO); ! LOWER PRIORITY
               2108
               2109
               2110
               2111
               2112
.
               2113
.
                                          end
               2114
                                    else
.
                                          OF_RC = .OF_RC - 2;
               2115
                                                                                              ! SET UP FOR IP REG OR QUIT
               2116
               2117
                              until .OF_RC les 0;
               2118
               2119
.
               2120
                              return SUCCESS:
               2121
                              end;
```

000000 004137 000000G

SBTTL REG.EXIST INITIALIZATION TEST ROUTINES REG. EXIST:

QAM3		INITIALI	ERCISER	ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.	Page 81.2:161 (7)
0004	123727	000000G	000005		JSR CMPB	R1, \$SAVE2 ENTRY.REASON, #5		20 20
0012	001461	000000	00000		BEQ	3\$		20
0014	012737	000002	00000G		MOV	#2,0F.RC		20
0026	005037	000000G		14:	CLR	NEX		20
0026	012746	000340			MOV	#340,-(SP)		21
0032	012746	000000G 000004			MOV	#340,-(SP) #NEX.TRAP,-(SP)		
0036	012746	000004			MOV	44,-(SP)		
0042 0046 0050 0054	012746	000003			MOV	#3,-(SP)		
0046	104437	0000000			TRAP	37		
0050	013700 063700	000000G			ADD	RDRX.ADDR,RO		2:
2060	011001	0000000			MOV	OF.RC,RO (RO),R1	; *.TEMP	
0060 0062 0064	005002				CLR	R2	; DUMMY	2
0064	011001 005002 012700	000004			MOV	44.RO	; DOTHIT	2
0070	104436				TRAP	36		-
0072	104436 032737	000001	00000G		BIT	#1.NEX		2
0100	001416				BEQ	21		
0102	001416 013700	00000G			MOV	CCTLR,RO		2
0106	006300				ASL	RO		
0110	013700 006300 105260 104455 000012 000000G 005000 104441 062706 000413 162737 062706 005737	000000G			INCB	C.ERR.TBL(RO)		
0114	104455				TRAP	55		2
0116	0000012				. WORD	12		
0122	0000000				. WORD . WORD . WORD	EGD.10 EMS.10		
0124	005000				CLR	RO RO		2
0124 0126	104441				TRAP	41		2
0130 0134	062706	000010			ADD	#10.SP		2
134	000413				BR	41		2
0136	162737	000002	000000G	24:	SUB	#2,0F.RC		2
0144	062706	000010			ADD	#10.SP		2
0150	005737	00000G			TST	OF.RC		2
0154	002322 012700 000207				BGE	16		
0156	012700	000001		34:	MOV	#1,R0	1	2
0162 0164	005000				RTS	PC		
0166	000207			44:	CLR RTS	RO PC		2
2200	OUCUT				KIS			

```
ZRQAM3
                       RD/RX EXERCISER
                                                                                             14-Dec-1983 16:12:07
                                                                                                                                VAX-11 Bliss-16 V3-555
                                                                                                                                DISK#USER2: [DIETZ.RDRX]ZRQACO.BL2;161 (8)
V01.2
                       INITIALIZATION TEST ROUTINES
                                                                                             14-Dec-1983 16:12:00
              2122 routine VEC_BR_TEST =
              2123
2
              2124
                      . .
              2125
                                   THIS ROUTINE ATTEMPTS TO VERIFY (A) THAT THE RDRX VECTOR ADDRESS GIVEN
                                  BY THE USER DURING THE HW DIALOG IS VALID, AND (B) THAT THE USER-SPECIFIED BUS REQUEST LEVEL FOR THE DEVICE IS CORRECT. THE FIRST OBJECTIVE IS ACCOMPLISHED BY SETTING THE CPU PRIORITY TO O AND FORCING AN RDRX INTERRUPT. IF THE USER SPECIFIED AND INCORRECT VECTOR ADDRESS, THEN THE RESULT MAY BE UNPREDICTABLE. FOR THIS REASON, THE MESSAGE "FUNCTIONAL TEST STARTED" IS PRINTED BEFORE THE TEST, AND
              2126
              2127
              2128
              2129
              2130
              2131
                                   "EXERCISER STARTED" IS PRINTED AT ITS SUCCESSFUL CONCLUSION. IF
              2132
                                  EITHER "FUNCTIONAL TEST ..." OR "EXERCISER ..." DOES NOT APPEAR, THEN PROGRAM CONTROL IS ASSUMED LOST AND A FATAL TRAP IS LIKELY TO OCCUR. AT THIS POINT, THE EXERCISER MUST BE STARTED AGAIN.
              2133
              2134
              2135
               2136
                                  IF THIS TEST SUCCEEDS, THEN THE BR LEVEL TEST IS RUN BY SETTING THE PROCESSOR PRIORITY TO THE ASSUMED INTERRUPT PRIORITY GIVEN BY THE USER. A FORCED INTERRUPT SHOULD NOT OCCURR. THEN, BY LOWERING THE
              2137
.
              2138
.
              2137
:
               2140
                                   PRIORITY BY ONE, THE DELAYED INTERRUPT SHOULD OCCUR.
:
              2141
                      !-
:
              2142
.
              2143
                             begin
.
               2144
.
               2145
                             if .ENTRY_REASON eql NEW_PASS
.
              2146
                             then
               2147
                                   begin
                                   SETPRI (PRIOO):
               2148
                                                                                            ! LOWER PRIORITY
              2149
                                                                                            ! SKIP TEST IF NEXT PASS
                                   return SUCCESS:
               2150
.
                                   end:
               2151
.
               2152
                             PRINTF (MSG_02):
                                                                                             ! "FUNCTIONAL TEST STARTED"
              2153
2154
:
                             if INT_GEN () eql FALSE
                                                                                             ! FORCE AN INTERRUPT
               2155
                             then
                                   begin ! IF INTERRUPT DID NOT OCCUR
C_ERR_TBL [.CCTLR, C_ERR_HRD] = .C_ERR_TBL [.CCTLR, C_ERR_HRD] + 1;
ERRDF (11, EGD_11, 0); ! VECTOR TEST FAILED
              2156
.
               2157
                                   ERROF (11, EGD_11, 0);
return FAILURE;
               2158
               2159
               2160
                                   end
               2161
               2162
                                   begin
PRINTF (MSG_03);
                                                                                             ! INTERRUPT DID OCCUR
               2163
                                                                                             ! "EXERCISER STARTED"
               2164
                                   SETPRI (.BRLEVEL);
                                                                                             ! SET PRIORITY TO ASSUMED BR LEVEL
.
               2165
               2166
2167
                                   if INT_GEN () eql FALSE
                                                                                            ! FORCE AN INTERRUPT (SHOULD NOT OCCUR)
                                   then
               2168
                                        SETPRI (.BRLEVEL - #0'40');
                                                                                             ! IF INTERRUPT DID NOT OCCUR
               2169
                                                                                             ! LOWER PRIORITY BY 1
               2170
                                         DELAY (1);
:
               2171
.
               2172
                                         if .DCT_ADDR [SA_SAVE] neg 0
                                                                                            ! IF INTERRUPT DID OCCUR (SA_SAVE WOULD BE NON-ZERO)
.
               2173
                                         then
.
               2174
                                              begin
```

N6

ZRQAM3 VO1.2		RD/RX EXERCISER INITIALIZATION TEST R	OUTINES		14-Dec-1983 1 14-Dec-1983 1	6:12:07 6:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.	SEQ 0285 Page 30 BL2;161 (8)
	2175 2176 2177 2178 2179 2180 2181 2182	end;			! RESTORE PRO ! ONLY SUCCES			
	2183 2184 2185 2186 2187	SETPRI (PRIOO); C_ERR_TBL [.CCTLR ERRDF (12. EGD_12 return FAILURE; end;	. C_ERR_H . EMS_12)	IRD) = .C.	! COME HERE O _ERR_TBL [.CCTLR, C_ERR	ONLY FOR BE	TEST FAILURE	
000000	010146		VEC.BR	.SBTTL	VEC.BR.TEST INITIALIZ	ATION TEST	ROUTINES	
000002	005746			MOV	R1,-(SP)			2122
000004	123727	000000G 000005		CMPB	-(SP) ENTRY.REASON, #5			2145
000012	001003			BNE CLR	RO RO			2148
000020	104441 000473			TRAP BR	41 7\$			2147
000022	012746 012746	000000G 000001	14:	MOV	#MSG.02,-(SP)		•	2152
000032	010600 104417 004737			MOV TRAP	SP.RO		; SP.*	
000036	004737	000000V		JSR TST	PC.INT.GEN			2154
000044	001012 013700	000000G		BNE	2\$			
000052	006300			MOV	CCTLR,RO		•	2157
000014 000016 000020 000022 000032 000034 000036 000042 000044 000046 000052 000054	006300 105260 104455	000000G		INCB	C.ERR.TBL(RO)			2158
	000013 000000G 000000			. WORD	13 EGD.11			
000066	000000			. WORD BR	0			2154
000064 000066 000070 000072 000076 000102 000104 000106	000466 012716 012746 010600 104417 013700	000000G 000001	2\$:	MOV	#MSG.03.(SP)			2154 2163
000102	010600	***************************************		MOV	SP.RO		: SP.4	
000106	013700	001146'		TRAP MOV TRAP	17 BRLEVEL,RO			2164
000112	104441 004737	000000V		JSR	PC.INT.GEN			2166
000120	005700 001035			JSR TST BNE	RO 8#			
000112 000114 000120 000122 000124 000130 000134	013700 162700	001146' 000040		MOV	BRLEVEL,RO			2169
000134 000136	104441 012701	000001		TRAP	41			
000142	001411	00001	34:	MOV	#1.R1		: *.**TMP2	2170

ZRQAM3 VO1.2		RD/RX EXERCISER INITIALIZATION TEST	ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bl;es-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2;1	Q 0286 Page 31 61 (8)
000144	013700	000000G		MOV BEQ	L\$DLY.RO	; *, \$\$TMP1	
000152 000156 000160	005066 005300 001374	000006	48:	CLR DEC BNE	6(SP) RO 4\$	: \$\$TMP : \$\$TMP1	
000162 000164	005301 000766		5\$:	DEC	R1 31	; \$\$TMP2	
000166 000172 000176	013700 005760 001407	000005 000000C	6\$:	MOV TST BEQ	DCT.ADDR,RO 2(RO) 8\$	•	2172
000505	005000 104441			CLR	RO 41	1	2175
000204 000210 000214	062706 012700 000416	000006 000001	7\$:	MOV	06.SP 01.RO	:	2172 2174
000216	005726 005000		81:	BR TST CLR	10\$ (SP)+ RO	:	2162 2183
000220 000222 000224 000230	104441 013700 006300	000000G		MOV ASL	CCTLA, RO		2184
000232 000236 000240 000242	105260 104455 000014 000000G	000000G		INCB TRAP . WORD . WORD	C.ERR.TBL(RO) 55 14 EGD.12	•	2185
000244 000246 000250 000252	000000G 022626 005000 005726		98: 108:	. WORD CMP CLR TST	EMS.12 (SP)+.(SP)+ RO (SP)+	•	2122
000254 000256	012601 000207			MOV RTS	(SP)+.R1 PC		

: Routine Size: 88 words, Routine Base: \$CODE\$ + 1522 : Maximum stack depth per invocation: 7 words

```
SEQ 0287
ZRQAM3
                  RD/RX EXERCISER
                                                                         14-Dec-1983 16:12:07
                                                                                                    VAX-11 Bliss-16 V3-555
                                                                                                    VAX-11 Bliss-16 V3-555 Page 32 DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (9)
                  INITIALIZATION TEST ROUTINES
V01.2
                                                                         14-Dec-1983 16:12:00
           2188 routine INT_GEN =
           2189
           2190 ! .
           2191 !
                            THIS ROUTINE BEGINS AN RORX INITIALIZATION SEQUENCE, BUT ONLY
           2192
                           COMPLETES THROUGH THE STEP 1 WRITE. ITS PURPOSE IS TO CREATE AN RDRX
                            INTERRUPT (AT THE COMPLETEION OF STEP 1) IN ORDER TO HELP VERIFY THE
           2193
                            THE USER-SPECIFIED VECTOR ADDRESS AND BUS REQUEST INTERRUPT LEVEL.
           2194
                           A VALUE OF "TRUE" IS RETURNED TO THE CALLER IF AN INTERRUPT OCCURS, AND "FALSE" OTHERWISE. THE INTERRUPT IS VERIFIED BY A NON-ZERO VALUE
           2195
           2195
           2197
                           IN THE "SA SAVE" WORD IN THE DEVICE'S DCT.
           2198 !-
           2199
           2200
                      begin
:
           2201
           2202
                       local
           2203
                           SA : word:
                                                                       ! STORAGE FOR STEP 1 READ AND WRITE
           2204
                      DCT_ADDR [SA_SAVE] = 0;
WRT_RDRX (RCIP, RC_ALL, ALL_ONES);
           2205
                                                                         ! ZERO OUT SA SAVE WORD IN DCT
           2206
                                                                         ! WRITE IP TO START INIT SEQUENCE
           2207
                       DELAY (10):
                                                                         ! WAIT
.
                      SA = .RDRX_ADDR [RCSA, RC_ALL]; STEP 1 REAL SA = (WR_RING + 8) or (.CURRENT_VECTOR + -2) or SA_INT; WRT_RDRX (RCSA, RC_ALL, .SA); STEP 1 WRIT
           2208
                                                                         ! STEP 1 READ
           2209
                                                                                           ! STEP 1 WRITE VALUE
           2210
                                                                       ! STEP 1 WRITE
           2211
           2212
                       incr COUNT from 1 to 1600 do
:
           2213
                           begin
DELAY (5);
2
           2214
                                                                        ! TOTAL DELAY COUNT OF 8,000
:
:
           2215
                           BREAK:
           2216
           2217
                            if .DCT_ADDR [SA_SAVE] neg 0
.
                                                                        ! IF SA WAS CHANGED
           2218
.
                           then
           2219
                               return TRUE:
.
                                                                         ! INTERRUPT OCCURED
           2220
:
                           end:
           2221
:
           5555
                       return FALSE:
                                                                        ! IF INTERRUPT DID NOT OCCUR
           2223
                       end:
                                                       .SBTTL INT.GEN INITIALIZATION TEST ROUTINES
000000
         004137
                                              INT.GEN: JSR
                  000000G
                                                                R1. $SAVE2
                                                                                                                                                   2188
000004
         024646
                                                                -(SP), -(SP)
000006
         013700
                  000000G
                                                       MOV
                                                                DCT. ADDR, RO
                                                                                                                                                   2205
000012
         005060
                  200000
                                                       CLR
                                                                2(RO)
000016
         012700
                  177777
                                                       MOV
                                                                0-1,RO
                                                                                                     # .RC.REG
                                                                                                                                                   2206
000022
         010077
                  000000G
                                                                RO, BRDRX, ADDR
                                                       MOV
                                                                                                     : RC.REG. 4
000026
         012701
                  000012
                                                       MOV
                                                                412.R1
                                                                                                     1 4. $$TMP2
                                                                                                                                                   2207
000032
         001411
                                              18:
                                                       BEQ
000034
         013700
                  000000G
                                                       MOV
                                                                L $DLY.RO
                                                                                                     : 4,8$TMP1
000040
         001404
                                                       BEQ
                                                                3$
000042
                                                       CLR
         005066
                  000002
                                                                2(SP)
                                              21:
                                                                                                     : $STMP
         005300
000046
                                                       DEC
                                                                RO
                                                                                                     : $$TMP1
000050
         001374
                                                       BNE
                                                                21
000052
         005301
                                              36:
                                                       DEC
                                                                R1
                                                                                                     : $$TMP2
```

ZRQAM3 VO1.2		RD/RX EXERCISER INITIALIZATION TEST	ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK#USER2:[DIETZ.RDRX]ZRQACO.BL	SEQ 0288 Page 33 2;161 (9)
000054 000056 000062	000766 013700 016016	000000G	4\$:	BR MOV MOV	1\$ RDRX.ADDR.RO 2(RO).(SP)	RC.REG	2208
000066 000072 000074	013701 006201 006201	001144		MOV ASR ASR	CURRENT. VECTOR, R1 R1 R1	; *,RC.REG	2209
000076 000100 000104 000106	010102 052702 010201	111200		MOV BIS MOV	R1.R2 #111200.R2 R2.R1	: *.SA : *.SA : SA.RC.REG	2210
000106	010160	000002		MOV	R1,2(R0)	; RC.REG.*	
000112	012702 012701 001411	003100 000005	54: 64:	MOV MOV BEQ	#3100.R2 #5.R1 9\$	: *.COUNT : *.\$\$TMP2	2212 2214
000124	013700 001404	000000G	٠٠.	MOV BEQ	L\$DLY,RO	: *, \$\$TMP1	
000132	005066 005300	000002	7\$:	CLR DEC	2(SP) RO	: \$\$TMP : \$\$TMP1	
000140 000142 000144	001374 005301 000766		81:	BNE DEC BR	7\$ R1	: ##TMP2	
000146	104422	000000G	91:	TRAP	6\$ 22 DCT.ADDR.RO		2217
000150 000154 000160	005760 001403	000002		TST BEQ	2(RO) 10\$		2217
000162 000166	012700 000403	000001		MOV BR	#1.RO		2219
000166 000170 000172	005302		10#:	DEC	R2	: COUNT	2212
000174 000176 000200	005000 022626 000207		116:	CLR CMP RTS	RO (SP)+,(SP)+ PC		2200 2188

<sup>:</sup> Routine Size: 65 words. Routine Base: \$CODE\$ + 2002 : Maximum stack depth per invocation: 7 words

```
SEQ 0289
ZRQAM3
                    RD/RX EXERCISER
                                                                                   14-Dec-1983 16:12:07
                                                                                                                  VAX-11 Bliss-16 V3-555
                                                                                                                                                                 Page 34
V01.2
                    INITIALIZATION TEST ROUTINES
                                                                                                                  DISK $USER2: [DIETZ.RDRX]ZRQACO.BL2;161 (10)
                                                                                   14-Dec-1983 16:12:00
            2224 routine HARD_INIT =
             2225
.
             2226
                    . .
                               THIS ROUTINE PERFORMS THE FOUR READ / WRITE STEPS REQUIRED TO INITIALIZE AN RORX DEVICE. IF NO READ ERRORS ARE DETECTED IN ANY OF THE FOUR STEPS, THEN A SUCCESS VALUE IS RETURNED TO THE CALLER. OTHERWISE, ADDITIONAL ATTEMPTS MAY BE MADE TO INITIALIZE THE DEVICE.
             2227
             2228
             2229
             2230
             2231
                               IF ALL ATTEMPTS FAIL. A FAILURE INDICATION IS RETURNED.
:
             2232 !-
.
             2233
:
             2234
                         begin
:
             2235
:
             2236
:
                          local
             2237
                               IE_VEC : word:
                                                                                             ! IE-BIT-AND-VECTOR-ADDRESS/4 BYTE
             2238
2239
.
                                                                                             ! (USED IN STEP 1 WRITE AND STEP 3 READ)
.
             2240
                          IE_VEC = .CURRENT_VECTOR + -2:
                                                                                             ! GET VECTOR ADDR/4 (IE = 0)
:
             2241
:
             2242
                          incr ATTEMPTS from 1 to INI_ATT do
:
             2243
:
                               begin
             2244
:
             2245
2246
                               label
.
                                    STEP_1_READ.
STEP_2_READ.
STEP_3_READ.
STEP_4_READ;
.
             2247
             2248
.
             2249
             2250
             2251
                               WRT_RDRX (RCIP, RC_ALL, ALL_ONES);
.
                                                                                            ! WRITE IP TO START INIT SEQUENCE
             2252 !
2253 !
2254 !
2255
2256
2257
2258
.
                               STEP 1 READ
.
.
                               STEP - 1;
                               STEP_1_READ:
.
:
                                    begin
:
             2259
2260
                                    incr COUNT from 1 to 100 do
.
                                         begin
DELAY (5);
             2261
                                                                                             ! TOTAL DELAY COUNT OF 500 FOR STEP 1
             2262
                                          BREAK:
.
             2263
2264
                                          SA_REG = .RDRX_ADDR [RCSA, RC_ALL];
.
                                                                                             ! READ SA
:
             2265
2266
.
                                          if (.SA_REG and S1_MASK) eq1 SA_S1
                                                                                             ! IF STEP 1 READ IS O.K.
                                         then
.
             2267
                                               leave STEP_1_READ;
.
             2268
             2269
                                         end:
             2270
             2271
                                    exitloop;
             2272
                                    end;
.
             2273
.
             2274
.
             2275
                               STEP 1 WRITE
:
             2276
```

```
SEQ 0290
ZRQAM3
                 RD/RX EXERCISER
                                                                      14-Dec-1983 16:12:07
                                                                                                VAX-11 Bliss-16 V3-555
                                                                                                                                        Page 35
V01.2
                 INITIALIZATION TEST ROUTINES
                                                                      14-Dec-1983 16:12:00
                                                                                                DISK#USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (10)
                          SA_REG = (WR_RING + 8) or .IE_VEC;
                                                                              ! STEP 1 WRITE VALUE
! STEP 1 WRITE
           2277
           2278
                          WRT_RDRX (RCSA, RC_ALL, .SA_REG);
:
           2279 !
           2280 !
                          STEP 2 READ
           2281 !
           2282
                          STEP . STEP + 1:
           2283
                          STEP_2_READ:
           2284
                              begin
.
           2285
.
          2286
2287
                               incr COUNT from 1 to 2000 do
:
                                   begin
DELAY (5);
:
           2288
                                                                              ! TOTAL DELAY COUNT OF 10,000 FOR STEP 2
:
           2289
                                   BREAK:
.
           2290
                                   SA_REG = .RDRX_ADDR [RCSA, RC_ALL];
                                                                              ! READ SA
.
           2291
.
           2292
                                   if (.SA_REG and S2_MASK) eql (SA_S2 or WR_RING) ! IF STEP 2 READ IS O.K.
.
           2293
.
          2294
2295
                                       leave STEP_2_READ;
:
.
           2296
                                   end;
.
           2297
           2298
                              exitloop:
           2299
.
                              end;
           2300
.
          2301
2302
2303
                          STEP 2 WRITE
          2304
2305
2306
                          WRT_RDRX (RCSA, RC_ALL, .DCT_ADDR [RR_BEG]); ! RINGBASE-LO, PI = 0
.
.
                          STEP 3 READ
:
           2307 !
           2308
                          STEP . STEP . 1:
           2309
                          STEP_3_READ:
           2310
                              begin
           2311
           2312
2313
                               incr COUNT from 1 to 2000 do
                                  begin
DELAY (5):
           2314
                                                                              ! TOTAL DELAY COUNT OF 10,000 FOR STEP 3 READ
           2315
                                   BREAK:
           2316
                                   SA_REG = .RDRX_ADDR [RCSA, RC_ALL];
.
                                                                              ! READ SA
           2317
.
           2318
2319
                                   if (.SA_REG and S3_MASK) eq1 (SA_S3 or .IE_VEC) ! IF STEP 3 READ IS O.K.
.
           2320
                                       leave STEP_3_READ;
           2321
           2322
                                   end;
           2323
          2324
2325
2326
2327
2328
                              exitloop;
.
                              end;
.
.
                          STEP 3 WRITE
.
           2329
```

```
SEQ 0291
ZRQAM3
                 RD/RX EXERCISER
                                                                      14-Dec-1983 16:12:07
                                                                                                 VAX-11 Bliss-16 V3-555
                                                                                                                                         Page 36
                 INITIALIZATION TEST ROUTINES
V01.2
                                                                      14-Dec-1983 16:12:00
                                                                                                 DISK $USER2: [DIETZ.RDRX] ZRQACO.BL2:161 (10)
           2330
                          WRT_RDRX (RCSA, RC_ALL, 0);
                                                                               ! PP. RINGBASE-HI = 0
           2331
:
           2332
                          STEP 4 READ
           2333
           2334
                          STEP . STEP + 1:
                          STEP_4_READ:
           2335
           2336
                              begin
           2337
           2338
                               incr COUNT from 1 to 2000 do
           2339
                                   begin
           2340
                                   DELAY (5):
                                                                             ! TOTAL DELAY COUNT OF 10,000 FOR STEP 4 READ
           2341
2342
2343
2344
2345
2346
2347
2348
2349
                                   BREAK;
                                   SA_REG = .RDRX_ADDR [RCSA, RC_ALL]:
.
                                                                             ! READ SA
:
                                   if (.SA_REG and S4_MASK) eq1 SA_S4
                                                                             ! IF STEP 4 READ IS O.K.
:
:
                                   then
                                      leave STEP_4_READ:
                                   end:
           2350
                              exitloop:
           2351
                              end:
           2352
                          STEP 4 WRITE
           2353
           2354
                          CREDIT_BAL - 1:
           2355
                                                                               ! START WITH A CREDIT BALANCE = 1
                          MRT_RDRX (RCSA, RC_ALL, 0);
           2356
                                                                               ! BURST, LF, GO = 0
           2357
                          return SUCCESS:
                                                                              ! SUCCESS EXIT POINT
           2358
           2359
                          end:
                                                                             ! TRY AGAIN OR GIVE UP
           2360
2361
2362
                      CREDIT_BAL = 0;

C_ERR_TBL [.CCTLR, C_ERR_HRD] = .C_ERR_TBL [.CCTLR, C_ERR_HRD] + 1;

ERROF (13, EGD_13, EMS_13); ! INIT SEQUENCE FAILED
           2363
           2364
:
                      return FAILURE:
           2365
:
                      end:
                                                                      ! ROUTINE HARD_INIT
                                                     .SBTTL HARD.INIT INITIALIZATION TEST ROUTINES
000000 004137 000000G
                                            HARD. INIT:
                                                             R1. $SAVES
                                                     JSR
                                                                                                                                             2224
000004
        162706
                 000012
                                                    SUB
                                                             #12.SP
000010 013704
                 001144
                                                              CURRENT. VECTOR. R4
                                                                                                 : *.IE.VEC
                                                                                                                                             2240
000014 006204
                                                     ASR
                                                                                                 : IE.VEC
000016 006204
                                                     ASR
                                                             R4
                                                                                                 : IE.VEC
000020
        012705
                 000002
                                                     MOV
                                                              42.R5
                                                                                                 . . ATTEMPTS
                                                                                                                                             2242
000024
        012700
                 177777
                                                     MOV
                                                              #-1.RO
                                                                                                 : *.RC.REG
                                                                                                                                             2251
000030
        010077
                 000000G
                                                     MOV
                                                             RO, BRDRX, ADDR
                                                                                                 : RC.REG. .
000034
        012737
                 000001 000000G
                                                     MOV
                                                              #1.STEP
                                                                                                                                             2255
000042
        012702
                 000144
                                                     MOV
                                                              #144.R2
                                                                                                 # .COUNT
                                                                                                                                             2259
000046
        012701
                 000005
                                                     MOV
                                                              45,R1
                                                                                                 : 4,8$TMP2
                                                                                                                                             2261
000052
        001411
                                                     BEQ
        013700
000054
                 000000G
                                                     MOV
                                                             L$DLY.RO
                                                                                                 : 4. $ $ TMP1
```

					П/		
ZRQAM3 VO1.2		RD/RX EXERCISER INITIALIZATION TE	CT DOUTTNEC		14-Dec-1983 16:12:07	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACG	SEQ 0292 Page 37
401.2		INTITALIZATION TO	SI MUUITNES		14-066-1985 16:12:00	DISK \$USER2:[DIE12.RURX ]ZRUACO	).BL2;161 (10)
000060	001404			BEQ	4\$		
000065	005066	000010	3\$:	CLR	10(SP)	; \$\$TMP	
000066	005300			DEC	RO	; \$\$TMP1	
000070	001374 005301		41:	BNE	3\$ R1	. AATMDO	
000074	000766		***	BR	2	: \$\$TMP2	
000076	104422		5\$:	TRAP	22		
000100	013700	00000G		MOV	RDRX.ADDR,RO		2263
000104	016066	000002 000006 000006 000000G		MOV	2(RO).6(SP)	, +,RC.REG	
000120	016637	000006 000000G		MOV	6(SP),SA.REG 6(SP),RO #1777,RO RO,#4000	RC.REG.*	
000120	016600 042700	000006 001777		BIC	6(SP),R0	; SA.REG.*	2265
000130	020027	004000		CMP	RO. #4000		
000134	001403	001000		BEQ	61		2267
000134 000136 000140	005302			CMP BEQ DEC BNE	R2	COUNT	2259
000140	001342			BNE	14		
000142 000144	000576 010437	*******		BR	241	1	2243
000144	052737	000000G	6\$:	MOV	R4.SA.REG	; IE.VEC.*	2277
000156	013701	111000 000000G 000000G		BIS	#111000.SA.REG SA.REG.R1	: *.RC.REG	2278
000162	013700	000000G		MOV	RDRX.ADDR,RO	, TING.NEG	2210
000166	010160	000002		MOV	R1,2(R0)	; RC.REG.+	
000172	005237 012702 012701 001411	00000G		INC	STEP		2282
000176	012702	003720 000005		MOV	#3720,R2	: +,COUNT	2286
000202	012/01	000005	7\$: 8\$:	MOV	#5.R1 11#	: 4,\$\$TMP2	2288
000156 000162 000166 000172 000176 000202 000210 000214 000216 000222 000224 000226 000230	013700	000000G	0+:	MOV	L\$DLY.RO	; *, \$\$TMP1	
000214	001404	***************************************		BEQ	10#	,	
000216	005066	000010	9#:	CLR	10(SP)	: \$\$TMP	
000222	005300			DEC	RO	: \$\$TMP1	
000224	005300 001374 005301		104.	BNE	9\$	AATMOO	
000220	000766		10#:	DEC BR	R1 8¢	; \$\$TMP2	
000232	104422		114:	TRAP	22		
	013700	000000G	••••	MOV	RDRX.ADDR.RO	-1	2290
000240	016066	000002 000004		MOV	2(RO),4(SP)	* *.RC.REG	
000246	016637 016600	000004 000000G		MOV	4(SP),SA.REG	*.RC.REG RC.REG.* SA.REG.*	
000254	016600	003400		MOV	4(SP).RO	: SA.REG.+	2292
000264	042700 020027	010222		BIC	#3400,R0 R0,#10222		
000270	001403	010000		BEQ	124		2294
000272	005302			BEQ DEC BNE	128 R2 78	COUNT	2286
000274	001342			BNE	76		
000276	001342 000534 013700	0000000		BR	261		2243
000300	016001	00000G 000004	12#:	MOV	DCT.ADDR.RO	A DC DEC	2304
000310	013700	000000G		MOV	4(RO),R1 RDRX.ADDR.RO	: *.RC.REG	
000234 000240 000246 000254 000260 000270 000272 000274 000276 000300 000304 000310 000314	010160	000002		MOV	R1.2(R0)	: RC.REG.*	
000320	005237	00000G		INC	STEP		2308
000324	010403			MOV	STÉP R4,R3	; IE.VEC.*	2318
000326	052703	020000		BIS	#20000,R3		
000320 000324 000326 000332 000336	012702 012701	003720 000005	124.	MOV	#3720,R2	: *.COUNT	2312
000000	OTEIOT	000003	134:	HUV	45,R1	: 4,\$\$TMP2	2314

700047		DD /DV EVEDOTOED					SEQ 0293
ZRQAM3 VO1.2		RD/RX EXERCISER INITIALIZATION	TEST ROUTINES		14-Dec-1983 16:12:07	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO	Page 38
						DISTRIBUTE TE THORNYENGHOU	.002,101 (10)
000342 000344 000350 000352 000356 000360 000362 000364 000366 000370 000374	001411	000000G	14\$:	MOV	17\$ L\$DLY,RO	: 4,88TMP1	
000350	001404	000000		BEQ	16\$	; *,**INP1	
000352	005066	000010	15#:	CLR	10(SP)	; \$\$TMP	
000356	005300			DEC	RO	; \$\$TMP1	
000362	001374 005301		16\$:	BNE	15# R1	: \$\$TMP2	
000364	000766			BR	14\$		
000366	104422 013700	**********	17#:	TRAP	22		
000370	015700	000000G		MOV	RDRX.ADDR.RO 2(RO),2(SP) 2(SP),SA.REG 2(SP),RO #3400,RO	. A DC DEC	2316
000402	016637	000002 000002 000002 000000G		VCM	2(SP).SA.REG	*.RC.REG *RC.REG.* *SA.REG.*	
OCCUPE	016600	000002		MOV	2(SP),R0	; SA.REG.*	2318
000414	042700	003400		BIC	#3400,R0		
000420	020003			CMP	KO'K2		0700
000424	001403			BEQ	18# R2	COUNT	2320 2312
000426	005302 001343 000457			BNE	13#	, court	2312
000430	000457			BR	26\$	1	2243
000432	013700	000000G	18#:	MOV	RDRX.ADDR,RO		2330
000436	005060 005237	000000		CLR	2(RO) STEP		2334
000446	012703	00000G 003720		MOV	#3720,R3	COUNT	2338
000452	012701 001411 013700	000005	19#:	MOV	45,R1	: *, \$\$TMP2	2338 2340
000456	001411	*********	20\$:	BEQ	23#		
000420 000424 000426 000430 000432 000436 000442 000446 000456 000460 000464	001404	000000G		MOV	L#DLY,RO 22#	: 4,\$\$TMP1	
000466	005066	000010	21#:	CLR	10(SP)	; \$STMP	
000472	005300			DEC	RO	: \$\$TMP1	
000474	001374		204	BNE	21#	447400	
000500	005066 005300 001374 005301 000766		22\$:	DEC BR	R1 20\$	; \$\$TMP2	
000502	104422		234:	TRAP	22		
000504 000510	013700	000000G		MOV	RDRX.ADDR.RO 2(RO),(SP)		2342
000510	016016	000002		MOV	2(RO),(SP)	* *.RC.REG	
000514	011637 011600	00000G		MOV	(SP),SA.REG	RC.REG.	2344
000522	042700	003777		BIC	(SP),RO #3777,RO	; SA.REG. *	2344
000526	020027	040000		CMP	RO, 040000		
000532	001403			BEQ	254	1	2346
000536	005303 001345			DEC	R3 196	COUNT	2338
000540	000413		241:	BR	261		2243
000542	012737	000001 0000000	25#:	MOV	#1,CREDIT.BAL	i	2355
000550	005001	0000000		CLR	R1	RC.REG	2356
000556	005060	00000G 000002		MOV	RDRX.ADDR,RO 2(RO)		
000520 000522 000526 000532 000534 000536 000540 000550 000550 000552 000566 000566 000570	000413 012737 005001 013700 005060 012700	000001		MOV	#1.RO		2243
000566	000414			BR	274		
000570	005037	000000G	26#:	CLR	CREDIT.BAL	•	2361
000600	013700 006300	00000G		MOV	CCTLR, RO	•	2362
000602	105260	00000G		INCB	C.ERR.TBL(RO)		

- 1	-
	/
	1

	ZRQAM3 VO1.2		RD/RX EXERCISER INITIALIZATION TEST	ROUTINES			14-Dec-1983 14-Dec-1983	VAX-11 Blies-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.B	SEQ 0294 Page 39 L2:161 (10)
-	000606 000610 000612 000614	104455 000015 000000G 000000G			TRAP . WORD . WORD . WORD	55 15 EGD.13 EMS.13			2363
-	000616 000620 000624	005000 062706 000207	000012	27\$:	CLR ADD RTS	RO #12,SP PC		1	2234 2224

Routine Size: 203 words, Routine Base: \$CODE\$ + 2204 : Maximum stack depth per invocation: 13 words

```
SEQ 0295
ZRQAM3
                    RD/RX EXERCISER
                                                                               14-Dec-1983 16:12:07
                                                                                                             VAX-11 Bliss-16 V3-555
                                                                                                                                                           Page 40
                    INITIALIZATION TEST ROUTINES
                                                                                                             DISK#USER2: [DIETZ.RDRX]ZRQACO.BL2;161 (11)
V01.2
                                                                               14-Dec-1983 16:12:00
            2366 routine INI_RRING : novalue =
            2367
:
            2368 !+
.
                             THIS ROUTINE IS RESPONSIBLE FOR ALLOCATING ENOUGH MSCP PACKETS TO FILL AN RDRX RESPONSE RING. THE BUFFER DESCRIPTOR OF EACH PACKET (LOCATED IN FRONT OF THE PACKET ITSELF) IS LOADED INTO SUCCESSIVE RRING SLOTS. NOTE THAT THE BUFFER DESCRIPTORS HAVE BEEN INITIALIZED
            2369
                    .
.
            2370
.
            2371
:
            2372
2
                              WITH THE FLAG AND OWNERSHIP BITS SET TO "1". MAKING EACH SLOT
             2373
.
            2374
                              CONTROLLER-OWNED.
.
             2375
                              IMPLICIT INPUTS:
             2376
.
            2377
                                       CCTLR - CURRENT CONTROLLER NUMBER
.
             2378
                                       DCT_ADDR - ADDRESS OF CURRENT CONTROLLER'S DCT
.
             2379
                  ! -
.
             2380
             2381
                         begin
:
             2382
:
             2383
                         local
                              index : word,
             2384
.
             2385
                              RRING_ADDR;
:
             2386
:
             2387
                         RRING_ADDR = .DCT_ADDR [RR_BEG];
                                                                                        ! FIRST RESPONSE RING SLOT
             2388
             2389
                         incr COUNT from 1 to RRING_LEN do
             2390
                              index = GET_PKT (.CCTLR);
.RRING_ADDR = .MSCP_PKT [.index, PKT_L0];
RRING_ADDR = .RRING_ADDR + 2;
.RRING_ADDR = .MSCP_PKT [.index, PKT_HI];
             2391
                                                                                          ! GET AN MSCP PACKET
.
             2392
                                                                                      ! LOAD LO-ORDER BUFF DESC INTO SLOT
             2393
                                                                                          ! ADVANCE TO SECOND WORD
             2394
                                                                                          ! LOAD HI-ORDER BUFF DESC INTO SLOT
             2395
                              PKT_USE [.index] = .CCTLR;
                                                                                          ! PACKET IN USE
                              .RRING_ADDR = ..RRING_ADDR or ED_OWN or ED_FLAG; GIVE OWNERSHIP TO CONTRLLER RRING_ADDR = .RRING_ADDR + 2; ADVANCE TO NEXT SLOT
             2396
             2397
             2398
                              end:
             2399
             2400
:
                         end:
                                                            SBTTL INI.RRING INITIALIZATION TEST ROUTINES
000000 004137 000000G
                                                  INI.RRING:
                                                            JSR
                                                                      R1, #SAVE4
                                                                                                                                                                2366
000004 013700
                    000000G
                                                            MOV
                                                                      DCT.ADDR, RO
                                                                                                                                                                2387
000010 016004
                    000004
                                                            MOV
                                                                      4(RO),R4
                                                                                                                . RRING. ADDR
000014 013703
                    000000G
                                                            MOV
                                                                      CCTLR,R3
                                                                                                                                                                2391
000020
          012702
                    000004
                                                                                                              : *, COUNT
                                                            MOV
                                                                      44,R2
                                                                                                                                                                2389
                                                                      R3, -(SP)
000024
          010346
                                                  18:
                                                            MOV
                                                                                                                                                                2391
000026
          004737
                    000000G
                                                            JSR
                                                                      PC,GET.PKT
000032
          010001
                                                            MOV
                                                                      RO,R1
                                                                                                              : *, INDEX
000034
          010116
                                                            MOV
                                                                      R1,(SP)
                                                                                                                                                                2392
                                                                                                              : INDEX. *
000036
          012746
                    000104
                                                            MOV
                                                                      #104,-(SP)
          004737
000042
                    000000G
                                                            JSR
                                                                      PC.BL #MUL
000046
                    000000G
                                                                      MSCP.PKT(RO),(R4)+
MSCP.PKT+2(RO),(R4)
          016024
                                                            MOV
                                                                                                              : *,RRING.ADDR
000052
          016014
                    000002G
                                                            MOV
                                                                                                              . . RRING. ADDR
                                                                                                                                                                2394
000056
          013703
                    000000G
                                                            MOV
                                                                      CCTLR.R3
                                                                                                                                                                2395
```

ZRQAM3 VO1.2		RD/RX EXERCISER INITIALIZATION TEST ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL	SEQ 0296 Page 41 2:161 (11)
000062 000066 000072 000074 000076 000100	005302 001352	000000G 140000	MOVB BIS CMP DEC BNE RTS	R3,PKT.USE(R1) #140000,(R4)+ (SP)+,(SP)+ R2 1\$ PC	: *.*(INDEX) : *,RRING.ADDR : COUNT	2396 2390 2389 2366

<sup>:</sup> Routine Size: 33 words. Routine Base: #CODE# + 3032 : Maximum stack depth per invocation: 8 words

SEQ 0297

```
ZRQAM3
                 RD/RX EXERCISER
                                                                     14-Dec-1983 16:12:07
                                                                                               VAX-11 Bliss-16 V3-555
                                                                                               DISK&USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (12)
V01.2
                 INITIALIZATION TEST ROUTINES
                                                                     14-Dec-1983 16:12:00
           2401 routine SET_CTLR_CHAR =
           2402
          2403 !+
           2404
                          THIS ROUTINE IS CALLED BY CTLR_INIT AFTER THE RDRX HAS BEEN HARD-
.
           2405
                .
                          INITIALIZED. ITS PURPOSE IS TO FORMAT AND SEND THE "SET CONTROLLER
.
                          CHARACTERISTICS" COMMAND, AND TO VALIDATE THE RESPONSE (END MESSAGE).
           2406
                .
.
           2407
                 .
:
           2408
                          IMPLICIT INPUTS:
                .
:
                                  CCTLR - CURRENT CONTROLLER NUMBER
           2409
           2410 !-
           2411
           2412
                     begin
           2413
.
           2414 !+
:
           2415
2416
                          MISCELLANEOUS INITIALIZATON
                .
:
                !-
:
           2417
:
           2418
.
           2419 QIO [.CCTLR] = 0;
2420 CST [.CCTLR, U_CNT] = 0;
                                                                 ! INITIALIZE NO. OF OUTSTANDING QIOS
.
                                                                     ! CLEAR UNITS IN CST TABLE
.
                incr COUNT from 0 to (RP_CNT - 1) do
           2421
                                                                    ! INITIALIZE RETURN PACKET POOL
:
                     RP_USE [.COUNT] = -1:
           2422
.
           2423
:
           2424 IODQ_IN = IODQ_OUT = 0:
                                                                    ! INITIALIZE I/O DONE QUEUE POINTERS
.
           2425
           2426
                     ! GET AN MSCP PACKET
           2427
                                                                     ! PACKET SIZE ! OPCODE - SET CTLR CHAR
           2428
:
           2429
.
           2430
.
           2431
           2432
:
           2433
                      if SEND (.P_INDEX) eql FAILURE
                                                                     ! ATTEMPT SEND
:
           2434
                      then
                         ! IF SEND WAS UNSUCCESSFUL

C_ERR_TBL [.CCTLR, C_ERR_HRD] = .C_ERR_TBL [.CCTLR, C_ERR_HRD] + 1;

ERROF (20, EGD_20, 0);

PUT_PKT (.P_INDEX);

DROP CTUP (.CCTLR)
.
           2435
:
           2436
:
           2437
                          PUT_PKT (.P_INDEX); ! RETURN PACKET TO DROP_CTLR (.CCTLR, DU_CFATAL); ! DROP CONTROLLER
           2438
           2439
.
           2440
                          return FAILURE:
.
           2441
                          end
:
           2442
.
                     else
           2443
:
                          begin
                                                                    ! IF SEND WAS SUCCESSFUL
           2444
:
           2445
:
           2446
                              WAIT ():
.
           2447
                                                                    ! WAIT FOR RETPKT RESPONSE
.
                              RP_INDX = OUT_IODQ ();
           2448
                                                                     ! GET INDEX OF RETPKT
.
           2449
                              RP_ADDR = RETPKT + (.RP_INDX + RP_LEN + 2); ! CALCULATE RETPKT ADDRESS
.
           2450
.
           2451
                              if .RP_ADDR [MESTYP] neg MT_SEQ
.
                                                                    ! RETURN ALL RETPKTS NOT SENT BY CONTROLLER
           2452
.
           2453
                                  PUT_RETPKT (.RP_INDX);
```

```
SEQ 0298
ZRQAM3
                  RD/RX EXERCISER
                                                                         14-Dec-1983 16:12:07
                                                                                                     VAX-11 Bliss-16 V3-555
                                                                                                                                              Page 43
V01.2
                  INITIALIZATION TEST ROUTINES
                                                                         14-Dec-1983 16:12:00
                                                                                                    DISK $USER2: [DIETZ.RDRX]ZRQACO.BL2:161 (12)
           2454
           2455
:
                           until (.RP_ADDR [CONID] eql CID_DRIVER) or ((.RP_ADDR [MESTYP] eql MT_SEQ) and ((.RP_ADDR [ENDCOD] and OP_END) eql OP_END);
           2456
           2457
:
           2458
:
           2459
:
           2460
                           if .RP_ADDR [CONID] eql CID_DRIVER ! IF RETPKT IS FROM "DRIVER"
           2461
                           then
           2462
                                begin
PRINTF (DBM23):
           2463
                                                                         ! "ERROR IN SET_CTLR_CHAR"
           2464
                                PUT_RETPKT (.RP_INDX);
                                                                         ! RELEASE RETURN PACKET
:
           2465
                                DR_ERR ();
                                                                         ! DROP CONTROLLER
:
           2466
                                return FAILURE:
:
           2467
                                end
.
           2468
                           else
:
           2469
:
                               begin
                                                                         ! ELSE - RETPKT IS FROM DISK MSCP
           2470
.
           2471
                                if (.RP_ADDR [ENDCOD] neq (OP_SCC or OP_END)) or
  ((.RP_ADDR [C_FLGS] and CF_MASK) neq CF_MASK)
.
                                                                                           ! IF WRONG ENDCODE
           2472
.
                                                                                           ! OR FLAGS IN ERROR
           2473
                                then
:
                                    C_ERR_TBL [.CCTLR, C_ERR_HRD] = .C_ERR_TBL [.CCTLR, C_ERR_HRD] + 1;
           2474
:
           2475
:
           2476
                                    ERROF (21, EGD_21, EMS_21);
DROP_CTLR (.CCTLR, DU_CFATAL);
           2477
                                                                         ! DROP CONTROLLER
           2478
                                    PUT_RETPKT (.RP_INDX);
                                                                         ! RELEASE RETURN PACKET
           2479
                                    return FAILURE:
           2480
                                    end
           2481
                                else
           2482
                                    begin
CMD_TIME = .RP_ADDR [C_TIME] + 2;
                                                                         ! RETPKT HAS CORRECT ENDCODE
           2483
           2484
           2485
                                    if (.SWP_FLAGS and SWF_TRC) eql SWF_TRC
           2486
           2487
                                         PRINTF (DBM25, .RP_ADDR [C_TIME]);
           2488
           2489
                                    end:
                                                                         ! RETPKT HAS CORRECT ENDCODE
           2490
           2491
                                end;
                                                                         ! IF RETPKT WAS SENT BY DISK MSCP
           2492
:
           2493
                           PUT_RETPKT (.RP_INDX);
           2494
:
                           return SUCCESS:
                                                                         ! IF SEND WAS SUCCESSFUL
           2495
.
                           end:
           2496
           2497
                      end:
                                                                         ! ROUTINE SET-CTLR_CHAR
                                                       . SBTTL
                                                               SET.CTLR.CHAR INITIALIZATION TEST ROUTINES
000000 010146
                                             SET. CTLR. CHAR:
                                                      MOV
                                                                R1,-(SP)
                                                                                                                                                   2401
         013701
000002
                  000000G
                                                                CCTLR,R1
                                                      MOV
                                                                                                                                                   2419
000006
         105061
                  000000G
                                                      CLRB
                                                                QIO(R1)
000012
         010146
                                                      MOV
                                                                R1.-(SP)
                                                                                                                                                  2420
000014
         012746
                                                                476,-(SP)
                 000076
                                                      MOV
```

									SEQ 0299
	ZRQAM3		RD/RX EX	XERCISER			14-Dec-1983 16:12:07	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.B	Page 44
	V01.2		INTITAL	IZATION TEST	ROUTINES		14-Dec-1983 16:12:00	DISK \$USER2: [DIETZ.RDRX]ZRQACO.B	2:161 (12)
	000020	004737	000000G						
	000024	105060	000005G			JSR CLRB	PC.BL \$MUL CST+5(RO)		
	000030	005000	0000036			CLR	CS1+3(RU)	CO. D. T	
	000032	112760	000377	00000G	15:	MOVB	RO #377,RP.USE(RO)	: COUNT	2421
	000040	005200	000311	000000	14:	INC	RO RO	: 4,4(COUNT)	2422
	000042	020027	000003			CMP	RO,#3	: COUNT	2421
	000046	003771	000003			BLE	1\$	: COUNT, +	
	000042 000046 000050 000054 000060	005037	000000G			CLR	IODQ.OUT		
	000054	005037 005037	000000G			CLR	IODQ.OUT IODQ.IN R1.(SP) PC.GET.PKT		2424
	000060	010116	000000			MOV	IODQ.IN R1.(SP) PC.GET.PKT		2007
	000062	004737	000000G			JSR	DC CET DAT		2427
	000062 000066	010037	000000G			MOV	RO,P.INDEX		
	000072	010016	000000			MOV	RO.(SP)	D THOSY .	
	000072 000074	012746	000104			MOV	#104,-(SP)	; P.INDEX,4	2428
1	000100	004737	000000G			JSR	DC DI AMIR		
1	000104	012760	0000040	000006G		MOV	AAO MCCD DVT.6(DO)		
	000112	112760	000004	000022G		MOVB	PC.BL*MUL #40.MSCP.PKT+6(R0) #4.MSCP.PKT+22(R0) #120.MSCP.PKT+30(R0) MSCP.PKT+4(R0)		
1	000120	012760	000120	000030G		MOV	A120 MCCD DVI. ZO(DA)		2429
-	000126	005060	000004G	000000		CLR	MCCD DYT. A(DA)		2430
	000132	013716	000000G			MOV	D THOEY (CD)		2431
	000136	004737	000000G			JSR	P.INDEX.(SP) PC.SEND		2433
1	000142	013716 004737 005700	000000			TST	RO		
	000144	001026				BNE	26		
	000132 000136 000142 000144 000146	013700	000000G			MOV	CCTLR.RO		2075
3	000152	006300	000000			ASL	RO	•	2436
	000152 000154 000160 000162	105260	000000G			INCB	C.ERR.TBL(RO)		
	000160	104455	000000			TRAP	55		
-	000162	000024				HODD	24		2437
	000164	000024 000000G				. MORD . MORD . MORD	EGD.20		
	000166	000000				HORD.	0		
	000170	013716	000000G			MOV	P.INDEX.(SP)		2470
	000174 000200 000204 000210	004737	000000G			JSR	PC, PUT. PKT	•	2438
	000200	013716	000000G			MOV	CCTLR.(SP)		0070
	000204	012746	000006			MOV	46,-(SP)	•	2439
1	000210	012746	000000G			JSR	PC.DROP.CTLR		
ŀ	000214	005726	000000			TST	(SP)+		2475
		005000				CLB	RO		2435
. O	000220	000560				CLR BR	116		2412
-	000222	004737	000000G		28:	JSR	PC.WAIT		2007
	000226	004737 004737	000000G		24.	JSR	PC.OUT.IODQ		2447
1	000232	010037	000000G			MOV	RO, RP, INDX		2448
	000236	010016				MOV	RO.(SP)	. DO THOY A	2000
-	000240	012746	000060			MOV	460, -(SP)	; RP.INDX.4	2449
1	000244	004737	000000G			JSR	PC, BL MUL		
	000216 000220 000222 000236 000236 000240 000244 000250 000254 000260 000266 000270	062700	000000G			ADD	PRETPKT, RO		
	000254	010037	000000G			MOV	RO, RP. ADDR		
	000260	132760	000360	000002		BITB	#360,2(RO)	6. 마음 : 10 H	2451
	000266	010037 132760 001404				BEQ	36		2451
1	000270	013716	000000G			MOV	RP.INDX.(SP)		2457
	000274	004737	000000G			JSR	PC.PUT.RETPKT		2453
	000300	005726			34:	TST	(SP)+		2446
	000302	013701	000000G			MOV	RP.ADDR.R1		2446
	000306	005000				CLR	RO		2456
									1

	ZRQAM3 VO1.2		RD/RX EX	XERCISER IZATION TEST	POLITTMES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 PO DISK\$USER2: [DIETZ.RDRX]ZRQACO.BL2:161	300 age 45
	101.2		THE I THE	TENITON IESI	HOUTTHES		14-Dec-1965 16:12:00	DISK FUSER2: [DIETZ.RDRX ]ZRQACO.BL2;161	(12)
	000310	126127	000003	000003		CMPB	3(R1),#3		
	000316	001002				BNE	41		
	000320	005200				INC	RO		
	000322	000407				BR	51		
	000324	132761	000360	200000	41:	BITB	#360,2(R1)		2457
	000332	001333				BNE	21		2457
	000324 000332 000334 000340	105761	000014			TSTB	14(R1)		2450
	000340	100330				BPL	21		2458
	000342	006000			51:	ROR	RO		2460
	000344	103015			٠	BCC	61		2460
1	000342 000344 000346	012716	000000G			MOV	#DBM23,(SP)		2467
ł.	000352	012746	000001			MOV	01,-(SP)		2463
1	000352 000356 000360 000362	010600				MOV	SP.RO	; SP. 4	
1	000360	104417				TRAP	17	; SP. 4	
-	000362	013716	000000G			MOV	RP.INDX,(SP)		2464
1	000366	004737	000000G			JSR	PC.PUT.RETPKT		2404
-	000372 000376	004737	000000V			JSR	PC.DR.ERR		2465
i.	000376	000436				BR	81		
1	000400	126127	000014	000204	61:	CMPB	14(R1),#204		2460
	000406 000410	001007				BNE	76		2471
1	000410	016100	000022			MOV	22(R1),R0		2472
1	000414	042700	177357			BIC	#177657.RO		2415
	000420	020027	000120			CMP	RO.#120		
1	000424	001426				BEQ	91		
1	000426	013700	000000G		78:	MOV	CCTLR,RO		2475
1	000432 000434	006300				ASL	RO		2415
000	000434	105260 104455	000000G			INCB	C.ERR.TBL(RO)		
	000440	104455				TRAP	55		2476
1	000442 000444	000025				. WORD	25		2410
	000444	000000G				. WORD	EGD.21		
	000446	000000G				. WORD	EMS.21		
101100	000450 000454	013716	000000G			MOV	CCTLR,(SP)		2477
	000454	012746	000006			MOV	46,-(SP)		2411
	000460	004737	000000G			JSR	PC.DROP.CTLR		
1	000464	013716	000006 000000G 000000G			MOV	RP.INDX.(SP)		2478
	000470	004737	000000G			JSR	PC, PUT. RETPKT		24.0
-	000474	062706	000010		84:	ADD	●10.SP		2471
	000500 000502	000433				BR	124		2474
-	000502	016137	000024	000000G	98:	MOV	24(R1),CMD.TIME		2483
1	000510	006337	000000G			ASL	CMD. TIME		
1	000514 000522	032737	000001	000000G		BIT	41, SWP.FLAGS		2485
1	000522	001411				BEQ	101		
1	000524	016116	000024			MOV	24(R1),(SP)		2487
	000530	012746	000000G			MOV	#08M25, -(SP)		
	000534	012746	000002			MOV	#2,-(SP)		
	000540	010600				MOV	SP.RO	; SP.4	
	000542	104417				TRAP	17		
	000524 000530 000534 000540 000542 000544	022626				CMP	(SP)+,(SP)+		
1	000546	013716	000000G		104:	MOA	RP.INDX.(SP)		2493
1	<b>WUDDS</b>	004737	000000G			JSR	PC.PUT.RETPKT	나 아이들이 하는 사람들이 가는데 있는 그녀를 하나 나가 있다.	
	000556	012700	000001			MOV	●1.RO		2412
-	000562 000566	062706	000006		114:	ADD	46,SP		2401
	000000	000401				BR	136		2412

ZRQAM3 RD/RX EXERCISER V01.2 INITIALIZATION TEST ROUTINES 14-Dec-1983 16:12:07 14-Dec-1983 16:12:00

VAX-11 Bliss-16 V3-555 Page 46 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2:161 (12)

SEQ 0301

000570 005000 000572 012601 000574 000207

12\$: 13\$: CLR RO (SP)+,R1 PC RTS

:

2401

: Routine Size: 191 words. Routine Base: \$CODE\$ + 3134 : Maximum stack depth per invocation: 8 words

Page 47

```
SEQ 0302
ZRQAM3
                    RD/RX EXERCISER
                                                                               14-Dec-1983 16:12:07
                                                                                                              VAX-11 Bliss-16 V3-555
V01.2
                    INITIALIZATION TEST ROUTINES
                                                                               14-Dec-1983 16:12:00
                                                                                                              DISK $USER2: [DIETZ.RDRX]ZRQACO.BL2:161 (13)
            2498 routine UNIT_INIT : novalue =
            2499
            2500
                    ! .
            2501
                              THIS ROUTINE IS CALLED FROM DRIVER_INIT FOR EACH CONFIGURED UNIT
            2502
                              (DISK) WHICH IS ATTACHED TO A CONTROLLER THAT SURVIVED
            2503
                              INITIALIZATION. ITS PURPOSE IS TO FORMAT AND SEND AN "ONLINE" MESSAGE, AND TO VERIFY THE RESPONSE.
            2504
            2505
            2506
                              IMPLICIT IMPUTS:
            2507
                                        CCTLR - CURRENT CONTROLLER NUMBER
            2508
                                        CDISK - CURRENT DISK ADDRESS (RD/RX DISK NUMBER)
            2509
                                        L$LUN - CURRENT (DRS) UNIT NUMBER
            2510
.
                                        CST_ADDR - ADDRESS OF CURRENT CONTROLLER'S CST
            2511
            2512
            2513
                         begin
:
            2514
                         local
.
            2515
2516
                              MAXO_LBNS : WORD UNSIGNED,
                                                                                ! UNIT'S MAXIMUM LO WORD LBN
:
                              MAX1_LBNS : WORD UNSIGNED:
:
                                                                                ! UNIT'S MAXIMUM HI WORD LBN
            2517
                        P_INDEX = GET_PKT (.CCTLR);

MSCP_PKT [.P_INDEX, MSGLEN] = SZ_ONL;

MSCP_PKT [.P_INDEX, DK_NUM] = .CDISK;

MSCP_PKT [.P_INDEX, OPCODE] = OP_ONL;

MSCP_PKT [.P_INDEX, DDPAR] = BITOO;

MSCP_PKT [.P_INDEX, CMD_TYPE] = SEQ_CMD;
            2518
                                                                                ! GET AN MSCP PACKET
            2519
                                                                                ! PACKET SIZE
            2520
                                                                                ! SET DISK ADDRESS (RD/RX DISK NUMBER)
            2521
                                                                                ! OPCODE FOR "ONLINE"
            2522
                                                                                ! SHOW ALL ECC ERRORS IN ERROR LOG MESSAGES
            2523
                                                                                ! SEQUENTIAL COMMAND
            2524
            2525
                         if SEND (.P_INDEX) eql FAILURE
                                                                                ! ATTEMPT TO SEND; IF CTLR IS OFFLINE
             2526
                             begin
T_ADDR [ERR_HRD_HST] = .T_ADDR [ERR_HRD_HST] + 1;
CST_ADDR [.CUOFF, D_FATAL] = TRUE; ! FATAL EF
ERROF (22, EGD_22, 0);
DUR [.L$LUN] = DU_ONLINE; ! SETUP RE
DROP_UN:
            2527
2528
            2529
                                                                                ! FATAL ERROR
            2530
            2531
                                                                                ! SETUP REASON TO DROP UNIT
            2532
                              DODU (.L$LUN);
                                                                                ! DROP UNIT
            2533
                              PUT_PKT (.P_INDEX):
                                                                                ! RETURN PACKET TO POOL
            2534
                              end
            2535
                         else
            2536
.
                              begin
                                                                                ! OTHERWISE (SEND WAS SUCCESSFUL)
             2537
:
            2538
2539
2540
2541
2542
2543
2544
                              do
                                  begin
WAIT ():
                                                                                ! WAIT FOR RETPKT RESPONSE
                                   RP_INDX - OUT_IODQ ();
                                                                                ! GET INDEX OF RETPKT
                                   RP_ADDR = RETPKT + (.RP_INDX + RP_LEN + 2); ! CALCULATE RETPKT ADDRESS
                                   if .RP_ADDR [MESTYP] neg MT_SEQ
                                                                               ! RETURN ALL RETPKTS NOT SENT BY CONTROLLER
            2545
2546
                                   then
                                       PUT_RETPKT (.RP_INDX);
.
            2547
             2548
.
                              until (.RP_ADDR [CONID] eql CID_DRIVER) or
            2549
:
            2550
                                     ((.RP_ADDR [MESTYP] eql MT_SEQ) and
```

.

```
SEQ 0303
ZRQAM3
                   RD/RX EXERCISER
                                                                              14-Dec-1983 16:12:07
                                                                                                           VAX-11 Bliss-16 V3-555
                                                                                                                                                        Page 48
                   INITIALIZATION TEST ROUTINES
V01.2
                                                                              14-Dec-1983 16:12:00
                                                                                                           DISK $USER2: [DIETZ.RDRX]ZRQACO.BL2:161 (13)
                                     ((.RP_ADDR [ENDCOD] and OP_END) eq1 OP_END));
            2552
:
            2553
                             if .RP_ADDR [CONID] eql CID_DRIVER
                                                                              ! IF RETPKT IS FROM "DRIVER"
            2554
                             then
            2555
                                 begin
PRINTF (DBM26);
                                                                              ! "ERROR IN UNIT_INIT"
            2556
:
            2557
2558
                                  DR_ERR ():
                                                                              ! DROP CONTROLLER
2
                                  end
            2559
                             else
2
            2560
:
            2561
2562
2563
                                  if .RP_ADDR [ENDCOD] neg (OP_ONL or OP_END) ! IF RETPKT IS FROM DISK MSCP
:
:
                                      begin
T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
CST_ADDR [.CUOFF, D_FATAL] = TRUE;
ERRDF (23, EGD_23, EMS_21); ! FATAL ERROR
ERROF (23, EGD_23, EMS_21); ! FATAL ERROR
.
            2564
.
            2565
.
            2566
:
                                                                              ! SETUP REASON TO DROP UNIT
            2567
                                       DUR [.L$LUN] = DU_ONLINE;
:
            2568
                                                                              ! DROP UNIT
                                       DODU (.L$LUN):
:
            2569
                                       end
:
            2570
                                  else
:
            2571
                                                                              ! RETPKT HAS GOOD ENDCODE
.
                                       begin
                                       ST_CODE = .RP_ADDR [STSCOD];
SB_CODE = .RP_ADDR [SUBCOD];
            2572
                                                                              ! GET STATUS CODE
.
            2573
2574
                                                                              ! GET SUB-CODE
:
            2575
                                       if .ST_CODE neg ST_SUC
                                                                              ! IF STATUS CODE IS NOT SUCCESSFUL
            2576
                                       then
                                           t_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
CST_ADDR [.CUOFF, D_FATAL] = TRUE;
ERROF (15, EGD_15, EMS_30); ! ONLINE FAILED
            2577
.
            2578
            2579
            2580
2581
                                            DUR [.L. LUN] - DU_ONLINE; ! SET UP REASON FOR DROPPING UNIT
            2582
                                                                              ! DROP UNIT
                                            DODU (.L$LUN);
            2583
                                            end
            2584
2585
                                       else
                                                                              ! SUCCESFUL OPERATION
                                            begin
            2586
2587
                                            MAXO_LBNS - .RP_ADDR [SIZEO];
MAX1_LBNS - .RP_ADDR [SIZE1];
                                                                                                                      ! LOAD LOWER WORD OF UNIT SIZE ! LOAD UPPER WORD OF UNIT SIZE
            2588
            2589
            2590
                                            if (.MAXO_LBNS eql 0)
                                                                                                                      ! THIS SUBTRACTS ONE FROM THE TOTAL
            2591
                                            then
                                                                                                                      ! BECAUSE EVERYTHING STARTS AT O
            2592
                                                                                                                      ! THROUGH (MAXIMUM - 1)
                                                 begin
                                                 MAXO_LBNS - #0'177777':
            2593
            2594
                                                 MAX1_LBNS = .MAX1_LBNS - 1;
            2595
                                                 end
             2596
            2597
                                                 MAXO_LBNS - .MAXO_LBNS - 1;
.
            2598
                                            if (.CST_ADDR [.CUOFF + 2, D_BEG1] gtru .MAX1_LBNS) or
                                                                                                                              ! THIS SECTION CHECKS TO SEE
 IF LBNs LISTED
            2600
             2601
                                                 ((.CST_ADDR [.CUOFF + 2, D_BEG1] eqlu .MAX1_LBNS) and
                                                                                                                                ! IN SOFTWARE QUESTIONS WERE
 TO LARGE FOR
            2602
                                                 (.CST_ADDR [.CUOFF + 1, D_BEGO] gtru (.MAXO_LBNS - 1)))
                                                                                                                              ! DEVICE SPECIFIED
            2603
                                                                                                                      ! note 1 less then max. or diagnosti
   will arror
```

```
SEQ 0304
ZRQAM3
                   RD/RX EXERCISER
                                                                              14-Dec-1983 16:12:07
                                                                                                           VAX-11 Bliss-16 V3-555
                                                                                                                                                        Page 49
                                                                              14-Dec-1983 16:12:00
V01.2
                   INITIALIZATION TEST ROUTINES
                                                                                                           DISK#USER2: [DIETZ.RDRX]ZRQACO.BL2;161 (13)
            2604
                                            then
.
                                                                                                                      ! operator error
                                                begin
CST_ADDR [.CUOFF + 2. D_BEG1] = 0;
            2605
            2606
            2607
                                                 CST_ADDR [.CUOFF + 1. D_BEGO] = 0:
                                                                                                                  ! change beginning 1bn to 0
.
            2608
                                                 end:
            2609
            2610
            2611
                                                (.CST_ADDR [.CUOFF + 4, D_END1] gtru .MAX1_LBNS) or
:
            2612
:
            2613
                                                 ((.CST_ADDR [.CUOFF + 4, D_END1] eqlu .MAX1_LBNS) and
:
            2614
                                                 (.CST_ADDR [.CUOFF + 3, D_ENDO] atru .MAXO_LBNS))
:
            2615
                                             then
:
            2616
                                                CST_ADDR [.CUOFF + 4, D_END1] = .MAX1_LBNS;
            2617
            2618
                                                 CST_ADDR [.CUOFF + 3, D_ENDO] = .MAXO_LBNS;
                                                                                                                  ! and ending lbn to max_lbn
:
            2619
                                                 end:
:
            2620
.
            2621
.
            2622
:
            2623
                                                 if (((.ENTRY_REASON eql RESTART) or
                                                                                                           ! if restart or
            2624
                                                      (.ENTRY_REASON eq1 START)) and
                                                                                                           ! if continue
            2625
:
            2626
                                                      (.CRN_LOW leg 8) and
:
            2627
                                                      (.CRN_HIGH eql 0))
                                                                                                            ! first initialization
:
            2628
.
            2629
                                                 THEN
                                                                                                            ! intialize block numbers
                                                     begin

BST [.L$LUN, LO_WRD] = .CST_ADDR [.CUOFF + 1, D_BEGO];

BST [.L$LUN, HI_WRD] = .CST_ADDR [.CUOFF + 2, D_BEG1];

TRK_SGN [.L$LUN] = 1;
            2630
.
            2631
.
                                                                                                                               ! LOAD sequential LBN table
            2632
:
            2633
                                                                                                                                ! POSITIVE TRACKING DIRECTIO
            2634
.
                                                      end;
                                                                                                            ! THIS SECTION LOADS TYPE INTO CST TABLE
            2635
.
            2636
                                                 selectoneu .RP_ADDR [R_MODEL] of
:
                                                                                                            ! MODEL BYTE TELLS WHAT TYPE OF UNIT IN
            2637
:
                                                                                                            ! INDENTIFICATION BLOCK
            2638
:
                                                      set
            2639
.
            2640
                                                      [#0'6']: CST_ADDR [.CUOFF, D_TYPE] = RD_51; [#0'7']: CST_ADDR [.CUOFF, D_TYPE] = RX_50; [#0'10']: CST_ADDR [.CUOFF, D_TYPE] = RD_52;
                                                                                                                      ! RD 51
.
            2641
2642
.
                                                                                                                      ! RX 50
:
                                                                                                                      ! RD 52
            2643
:
            2644
:
                                                      [otherwise] : BEGIN
            2645
.
                                                                       ERRDF (25 ,EGD_24 ,EMS_30);
                                                                                                                     ! ERROR UNKNOWN DEVICE
            2646
                                                                       END:
            2647
:
                                                      tes:
            2648
.
            2649
                                            if ((.RP_ADDR [U_FLGS] and UF_WPH) eql UF_WPH) and (.CST_ADDR [.CUOFF, D_PROT] eql UNPROTECTED)
.
                                                                                                                   ! STATUS CODE IS O.K.
            2650
:
            2651
:
                                                begin

T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;

CST_ADDR [.CUOFF, D_FATAL] = TRUE;

ERRDF (16, EGD_16, EMS_30);

DUR [.L$LUN] = DU_PROTECT;
            2652
.
            2653
.
            2654
            2655
:
                                                                                                                      ! WRITE-PROTECT CONFLICT
            2656
                                                                                                                      ! SET REASON TO DROP UNIT
```

```
SEQ 0305
                                                              14-Dec-1983 16:12:07 VAX-11 Bliss-16 V3-555 Page 50 DISK*USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (13)
ZRQAM3
                 RD/RX EXERCISER
                 INITIALIZATION TEST ROUTINES
V01.2
                                            DODU (.L$LUN):
                                                                                                         ! DROP UNIT
           2658
.
                                            end
           2659
:
                                            begin
CST_ADDR [.CUOFF, D_STAT] = ONLINE;
CST [.CCTLR, U_CNT] = .CST [.CCTLR, U_CNT] + 1;
! WRITE PROTECT SWITCH IS O.K.
! SET ONLINE FLAG
! ADD UNIT TO CTRL TABLE
           2660
:
           2661
           2662
.
           2663
.
           2664
                                       end:
:
           2665
                                   end:
                                                                     ! IF RETPKT HAS CORRECT ENDCODE
:
           2666
.
           2667
                          PUT_RETPKT (.RP_INDX);
:
           2668
                                                                      ! IF SEND WAS SUCCESSFUL
                          end:
.
           2669
:
           2670
                      end:
                                                                     ! ROUTINE UNIT-INIT
.
                                                      .SBTTL UNIT.INIT INITIALIZATION TEST ROUTINES
000000 004137 000000G
                                         UNIT.INIT:
                                                     JSR
CMP
                                                              R1. $SAVES
                                                                                                                                               2498
000004
                                                              -(SP),-(SP)
        024646
000006
        013746
                 000000G
                                                     MOV
                                                              CCTLR, -(SP)
                                                                                                                                               2518
000012
                                                              PC,GET.PKT
        004737
                 000000G
                                                     JSR
000016
                 000000G
        010037
                                                     MOV
                                                              RO, P. INDEX
000022
                                                     MOV
        010016
                                                              RO,(SP)
                                                                                                : P.INDEX.*
                                                                                                                                               2519
000024
        012746
                                                              #104,-(SP)
                 000104
000030
        004737
                 000000G
                                                     JSR
                                                              PC,BL #MUL
000034 012760
                                                              044.MSCP.PKT+6(RO)
CDISK,MSCP.PKT+16(RO)
                 000044 000006G
                                                     MOV
                 000000G 000016G
000011 000022G
000042 013760
                                                     MOV
                                                                                                                                               2520
000050 112760
                                                     MOVB
                                                              #11,MSCP.PKT+22(RO)
                                                                                                                                               2521
000056 012760
                                                              #1.MSCP.PKT+46(RO)
#1.MSCP.PKT+4(RO)
                 000001
                          000046G
                                                     MOV
                                                                                                                                               2522
000064 012760
                                                     MOV
                 000001
                          000004G
                                                                                                                                               2523
000072 013716
                 000000G
                                                              P. INDEX, (SP)
                                                                                                                                               2525
000076
        004737
005700
                                                     JSR
                 000000G
                                                              PC, SEND
000102
                                                     TST
                                                              RO
000104
        001033
                                                     BNE
000106
        013700
                 000000G
                                                     MOV
                                                              T. ADDR, RO
                                                                                                                                               2528
000112 105260
                 000063
                                                     INCB
                                                              63(RO)
000116
       013700
                 000000G
                                                              CUOFF, RO
                                                                                                                                               2529
000122
        006300
                                                     ASL
000124
        063700
                 000000G
                                                     ADD
                                                              CST. ADDR. RO
000130
        052710
                 010000
                                                     BIS
                                                              #10000,(RO)
000134
        104455
                                                     TRAP
                                                                                                                                               2530
000136
        000026
                                                      . WORD
000140
        000000G
                                                     . WORD
                                                              EGD.22
000142
000144
000150
        000000
                                                      . WORD
         013700
                                                     MOV
                                                              L&LUN, RO
                                                                                                                                               2531
        112760
                 000007 000000G
                                                     MOVB
                                                              #7, DUR(RO)
000156
         104451
                                                     TRAP
000160
        013716
                                                     MOV
JSR
JMP
                                                              P. INDEX, (SP)
                                                                                                                                               2533
000164
        004737
                 000000G
                                                              PC, PUT, PKT
000170
        000137
                 005264
                                                              24#
                                                                                                                                               2525
000174
        004737
                 000000G
                                                      JSR
                                                              PC.WAIT
                                          14:
                                                                                                                                               2540
000200
        004737
                 000000G
                                                      JSR
                                                              PC.OUT. IODQ
                                                                                                                                               2541
```

PROME							SEQ 0306
ZRQAM3 VO1.2		INITIALIZATION	TEST ROUTINES		14-Dec-1983 16:12:07	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.	Page 51
						DISKYOSENE ! [DIE 12 . NDNA JZNUNCO .	DL2;101 (13)
000204 000210	010037 010016	00000G		MOV	RO, RP, INDX	DO THOY .	
000212	012746	000060		MOV	RO,(SP) #60,-(SP)	; RP.INDX,*	2542
000016	004737	00000G		JSR	PC.BL \$MUL		
000222	062700	000000G		ADD	PC.BL #MUL #RETPKT,RO		
000226	010037	00000G		MOV	RO, RP. ADDR		
000210 000222 000226 000232 000240 000242 000246 000252	132760	000360 000002		BITB	#360,2(RO)		2544
000240	001404	*******		BEQ	21		
000242	013716 004737	000000G		MOV	RP.INDX,(SP)		2546
000252	005726	000000	2\$:	JSR TST	PC,PUT.RETPKT	그 그 그리고 그는 그 그리다 그리다 하다 가셨다.	2570
000254	013701	00000G	24.	MOV	RP. ADDR. R1		2539 2549
000260	005000	***************************************		CLR	RO		2349
000262	126127	000003 000003		CMPB	3(R1),#3		
000270	001002 005200 000407			BNE	3\$		
000272	005200			INC	RO		
000274	000407	000760 000000	••	BR	41		
000276	132761 001333	000360 000002	34:	BITB	#360,2(R1)		2550
000306	105761	000014		BNE	1\$ 14(R1)		2551
000312	100330	000014		BPL	16		2551
000314	100330 006000 103012 012716		44:	ROR	RO		2553
000316	103012			BCC	5#		2330
000320	012716	000000G		MOV	#DBM26,(SP)		2556
000324	012/46	000001		MOV	#1(SP)		
000260 000262 000270 000274 000276 000304 000306 000312 000316 000320 000324 000330 000334 000340 000344 000350 000350 000366 000366	010600 104417			MOV	SP.RO	: SP.*	
000334	004737	000000V		TRAP JSR	17 PC.DR.ERR		2557
000340	000137	0052521		JMP	22\$	이 없는 이 그리고 있는 것이 없는 것이 없다.	2557 2555
000344	000137 013705	000000V 005252' 000000G 000000G	54:	MOV	CST. ADDR. R5		2565
000350	013766	000000G 000006		MOV	CUOFF,6(SP) 6(SP)		2505
000356	006366 060566	000006		ASL	6(SP)		
000362	060566	000006 000006 000014 000211		ADD	R5,6(SP)		
000338	126127 001422	000014 000211		CMPB	14(R1),#211		2561
000376	013700	000000G		BEQ	6\$ T.ADDR.RO		2564
000402	105260	000062		INCB	62(RO)		2564
000406	105260 052776	010000 000006		BIS	#10000,86(SP)		2565
000414	104455			TRAP	55		2566
000416	000027			. WORD	27		
000420 000422	0000000			. WORD	EGD.23		
000422	000027 0000000 0000000 013700 112760	0000000		. WORD	EMS.21		
000424 000430 000436	112760	000000G 000007 000000G		MOVB	L\$LUN,RO #7,DUR(RO)		2567
000436	104451	000000		TRAP	51		2568
000440	104451 000445			BR	76		2561
000440 000442 000450 000456	116137 042737	000016 000000G 177740 000000G	6#:	MOVB	16(R1),ST,CODE		2572
000450	042737	177740 000000G		BIC	#177740,ST.CODE		
000456	016100	000016		MOV	16(R1),R0	1	2573
000462 000464	006200 006200			ASR	RO		
000466	006200			ASR	RO RO		
000470	006200			ASR	RO		

			00		
ZRQAM3 VO1.2	RD/RX EXERCISER INITIALIZATION TEST RO	UTINES	14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.B	SEQ 0307 Page 52 L2:161 (13)
000472 0	06200	ASR	RO		
	42700 174000	BIC	#174000,R0		
000500 0	010037 000000G 005737 000000G	MOV	RO.SB.CODE		
000500 0 000504 0 000510 0 000516 1 000522 0 000530 1 000532 0 000534 0 000536 0 000540 0 000540 0 000540 0 000564 0 000564 0 000574 0 000574 0 000574 0 000574 0 000606 0 000602 0 000604 0 000606 0 000612 0 000614 0	01423	TST BEQ	ST.CODE 8\$		2575
000512 0	01423 013700 000000G	MOV	T.ADDR,RO		2578
000516 1	.05260 000062	INCB	62(RO)		23.0
000522 0	52776 010000 000006	BIS	#10000,86(SP)		2579
000530 1	.04455 000017	TRAP . WORD	55 17		2580
000534 0	00000G	WORD	EGD.15		
000536 0	00000G 00000G 013700 00000G	. WORD	EMS.30		
000540 0	13700 000000G	MOV	L\$LUN,RO		2581
000544 1	12760 000007 000000G	MOVB	#7,DUR(RO)		
000554 0	00137 005254'	74: TRAP	51 23¢		2582
000560 0	16103 000044	8\$: MOV	44(R1).R3	MAXO.LBNS	2575 2587
000564 0	16104 000046	MOV	46(R1),R4	: *.MAX1.LBNS	2588
000570 0	016104 000046 005703 001004	TST	R3	; MAXO.LBNS	2590
000574 0	012703 177777	BNE	9\$ #-1,R3	. A MAYO I DNC	2507
000600	05304	DEC	R4	# .MAXO.LBNS # MAX1.LBNS	2593 2594
000602 0	00401 005303	BR	10\$	1	2590
000604 0	005303	94: BR DEC	R3	: MAXO.LBNS	2597
000606	013700 000000G	108: MOV	CUOFF, RO	1	2599
000612	06300 060500	ASL ADD	RO R5.RO		
000616 0	011766 000004	MOV	(PC),4(SP)		
000622 0	060066 000004	ADD	RO.4(SP) 84(SP),R4		
000626 0	27604 000004	CMP	84(SP),R4	: *,MAX1.LBNS	
000632	01012	BHI	116		200
000622 0 000626 0 000632 1 000634 0 000636 0	013700 000000G	MOV	CUOFF.RO		2601 2602
000642 0	006300	ASL	RO		2002
000644 0	060500	ADD	R5.R0		
000646 0	010302 005302	MOV	R3,R2	; MAXO.LBNS.*	
000652	26002 000002	DEC	R2 2(R0),R2		
000656 1	01410	BLOS	124		
000650 0 000652 0 000656 1 000660 0 000664 0	05076 000004	114: BLOS	84(SP)		2606
000654 0	013700 000000G 006300	MOV	CUOFF,RO	1	2607
000672	060500	ASL	RO R5,RO		
000674	05060 000002	ADD CLR	2(RO)		
000700	005060 000002 013702 000000G 006302	12\$: MOV	CUOFF,R2		2611
000704 0	006302	ASL	R2		
000672 000674 000700 000704 000706 000710 000714	060502 026204 000010	ADD	R5,R2	A MAYA I BUC	
000714 1	101010	CMP	10(R2),R4 13#	; *,MAX1.LBNS	
000119 0	001017	BNE	144		2613
000720 0	013700 000000G	MOV	CUOFF, RO		2614
000724 0	006300	ASL	RO		
000726 0	060500	ADD	R5,R0		

ZRQAM3 VO1.2		RD/RX EXERCIS	ER IN TEST ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQAC	Page 53 0.BL2;161 (13)
000730	026003 101410	000006		CMP BLOS	6(RO),R3	; *,MAXO.LBNS	
000736 000742 000746 000750	010462 013700 006300 060500	000010 000000G	13#:	MOV MOV ASL	R4,10(R2) CUOFF,RO RO	: MAX1.LBNS.*	2617 2618
000750 000752 000756 000764	060500 010360 123727 001404	000006 000000G 00000	2 14#:	ADD MOV CMPB BEQ	R5,R0 R3,6(R0) ENTRY.REASON,#2 15#	: MAXO.LBNS.*	2623
000766 000774	123727 001031	000000G 00000	)1	CMPB BNE	ENTRY.REASON,#1		2624
000776 001004	023727	000000G 00001	.0 15\$:	CMP BGT	CRN.LOW.#10		2626
001006	003025 005737	000000G		TST	CRN.HIGH		2627
001014 001020 001022	001022 013704 010403 006303	000000G		MOV MOV ASL	L\$LUN,R4 R4,R3 R3		2631
001024 001026 001032 001034	006303 013700 006300 060500	000000G		ASL MOV ASL ADD	R3 CUOFF,RO RO R5,RO		
001036 001044 001052	016063	000002 00000	)2G	MOV	2(R0),BST(R3) 84(SP),BST+2(R3) #1,TRK.SGN(R4)		2632
001052 001060 001062 001066 001072 001074	112764 005003 156103 020327 001011	000001 00000 000032 000006	16\$:	MOVB CLR BISB CMP	#1,TRK.SGN(R4) R3 32(R1),R3 R3,#6		2633 2636
001100	015700	000000G		BNE MOV ASL	17\$ CUOFF,RO RO	•	2640
001102 001104 001110 001114	060500 142710 152710 000432	000034 000004		ADD BICB BISB BR	R5,R0 #34,(R0) #4,(R0) 20#		~~
001116	000707	000007	176:	CMP	R3.47		2636
001122 001124 001130 001132 001134 001140 001146 001150 001154 001156 001160 001164 001170 001172	013700 006300 060500	000000G		MOV ASL ADD BICB	CUOFF,RO RO R5,RO		2641
001140	000420	000034		BR	#34,(RO) 208		2636
001146	001011	000010	18#:	BNE	R3.410 198		
001154 001156 001160	020327 001007 013700 006300 060500 142710 000420 020327 001011 013700 006300 060500 142710 152710 000404 104455	000000G 000034		MOV ASL ADD BICB	CUOFF,RO RO R5,RO #34,(RO)		2642
001164	152710	000010		BISB	#10,(RO) 20#		2636
001172 001174 001176	104455 000031 000000G		19#:	BR TRAP . WORD . WORD	55 31 EGD.24		2636 2645

ZRQAM3 VO1.2		RD/RX EX	XERCISER IZATION TEST	ROUTINES		14-Dec-1983 16: 14-Dec-1983 16:	:12:07 VAX :12:00 DIS	(-11 Bliss-16 V3-555 SK\$USER2:[DIETZ.RDRX]ZRQACO.BL	SEQ 0309 Page 54 2:161 (13)
001200	000000G 032761 001430	020000	000022	20\$:	.WORD BIT BEO	EMS.30 #20000,22(R1)			2649
001216 001222	013700 006300 060500 005710	00000G			MOV ASL ADD TST	CUOFF,RO RO R5,RO (RO)	•		2650
001226	013700	000000G			MOV	T.ADDR.RO			2653
001246	052776 104455 000020 000000G		000006		BIS TRAP . WORD . WORD	#10000,86(SP) 55 20 EGD.16	:		2654 2655
001254 001260	013700 112760	000000G 000011	000000G		MOVB	L\$LUN,RO #11,DUR(RO)			2656
001266	000414		******		BR	23#	:		2657 2649
001272 001300 001304 001310 001314	013716 012746 004737 105260	020000 000000G 00000G 000005G	000006	215:	MOV MOV JSR INCB	CCTLR.(SP) #76,-(SP) PC.BL#MUL CST+5(RO)	:		2661 2662
001320 001322 001326	013716	000000G		224:	TST	(SP)+ RP.INDX,(SP)	e!		2660 2667
001332 001336	062706 000207	000010		241:	ADD RTS	#10.SP PC			2498
	V01.2  001200 001202 001210 001212 001216 001220 001224 001226 001232 001236 001244 001246 001250 001252 001254 001260 001266 001270 001272 001300 001314 001320 001322 001326 001332	V01.2  001200 000000G  001202 032761  001210 001430  001212 013700  001216 006300  001220 060500  001222 005710  001224 100022  001226 013700  001232 105260  001236 052776  001244 104455  001246 000020  001250 000000G  001252 000000G  001254 013700  001260 112760  001260 112760  001260 104451  001270 000414  001272 052776  001300 013716  001304 012746  001310 004737  001314 105260  001322 013716  001326 004737  001332 062706	VOI.2 INITIAL:  001200 000000G 001202 032761 020000 001210 001430 001212 013700 000000G 001216 006300 001222 005710 001224 100022 001226 013700 00000G 001232 105260 000062 001232 105260 000062 001234 104455 001246 000020 001250 000000G 001252 000000G 001254 013700 00000G 001256 104451 001270 000414 001272 052776 020000 001300 013716 000000G 001304 012746 00076 001310 004737 000000G 001320 005726 001322 013716 000000G 001326 004737 000000G 001326 004737 000000G 001332 062706 000010	V01.2 INITIALIZATION TEST  001200 000000G 001202 032761 020000 000022 001210 001430 001212 013700 000000G 001220 060500 001222 005710 001224 100022 001226 013700 00000G 001232 105260 000062 001236 052776 010000 000006 001250 00000G 001250 00000G 001250 00000G 001254 013700 00000G 001254 013700 00000G 001254 013700 00000G 001266 104451 001270 000414 001272 052776 020000 00000G 001300 013716 00000G 001304 012746 000076 001310 004737 000000G 001320 005726 001322 013716 000000G	V01.2 INITIALIZATION TEST ROUTINES  001200 000000G 001202 032761 020000 000022 20\$:  001210 001430 000000G 001212 013700 000000G 001220 060500 001222 005710 001224 100022 001226 013700 00000G 001232 105260 000062 001236 052776 010000 000006 001250 000000G 001250 000000G 001252 000000G 001254 013700 000000G 001254 013700 000000G 001255 000000G 001250 000000G 001350 005726 020000 000006 001310 004737 000000G 001320 005726 001322 013716 000000G 001332 062706 000010 24\$:	V01.2         INITIALIZATION TEST ROUTINES           001200         000000G 001202         032761 001210         020000         000022         20\$:         BIT BEQ MOV           001212         013700 001216         000000G         MOV         ASL ADD ADD MOV           001224         005710 001224         TST 001226         MOV         MOV           001236         052776 001236         010000         MOV         MOV           001236         052776 001236         010000         000006         BIS TRAP           001244         104455 001250         000000G 001250         MOV         MORD MOVB           001250         000000G 001250         000001 001260         MOVB TRAP         TRAP BR           001270         000414 001270         000001 001304         000000 001310         000000 001314         105260 000000 001320         000000 00000G         21\$:         BIS MOV 001320         NOV 001320         NO	V01.2 INITIALIZATION TEST ROUTINES  001200 000000G 001202 032761 020000 000022 20\$: BIT	VOI.2	VOI.2

<sup>:</sup> Routine Size: 368 words. Routine Base: \$CODE\$ + 3732 : Maximum stack depth per invocation: 13 words

						CEO	0710
ZRQAM3 VO1.2		RD/RX EXERCISER INITIALIZATION TEST ROUTINES		14-Dec-1983 14-Dec-1983	16:12:07 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2:16	0310 Page 55 1 (14)
	2671	routine DR_ERR : novalue =					
:	2672 2673	1.					
	2674	! THIS ROUTINE IS DESIGNED	TO PROCESS RE	TURN PACKETS	THAT ORIGINA	TE AT	
:	2675 2676	THE "DRIVER" RATHER THA	N THE DEVICE. DO	RIVER-ORIGINA ND TIMEOUT S	TED PACKETS	INDICATE	
i	2677	! EITHER A FATAL DEVICE E	INITIALIZATION	TEST, IT TREA	TS A COMMAND	TIMEOUT	
	2678 2679	! AS AN INITIALIZATION ER	ROR.				
	2680 2681	! IMPLICIT INPUTS:	CC OF A DETOUT	THAT ORTOTAL		DTVEO#	
	2682	P_ADDR - ADDRE	CONNECTION ID =	CID_DRIVER)	ED AT THE "U	KIVER"	
:	2683 2684	1.					
	2685	begin					
	2686 2687	local					
	2688 2689	REASON : word initial (	DU_TIME);	! ASSUME CO	MMAND TIMEOU	Т	
:	2690	if .RP_ADDR [MESTYP] eql MT	FATAL	! IF FATAL	DEVICE ERROR		
:	2691 2692	REASON - DU_DFATAL;		! CHANGE RE	ASON TO FATA	FRROR	
:	2693 2694						
:	2695	DROP_CTLR (.CCTLR, .REASON) end;	•	! DROP ALL	ONTIS ON CON	INOLLER	
000000	010146	DR.ERR:	.SBTTL DR.ERR MOV R1(S	INITIALIZATIO	ON TEST ROUT	INES	2671
000002	012701	000012	MOV #12.R1			REASON	2671 2685
000006	013700 116000	00000G 000002	MOV RP. ADD MOVB 2(RO),	R,RO RO			2690
000016	042700	177417 000060	BIC #17741	7.RO			
000026	001002		BNE 1#				
000030 000034	012701	000005 000000G 1\$:	MOV #5,R1 MOV CCTLR,	-(SP)		: *.REASON	2692 2694
000040	010146		MOV R1,-(S	P)		: REASON. *	2034
000042 000046	004737 022626	00000G	JSR PC.DRO	P.CTLR (SP)+			2685
000050 000052	012601		MOV (SP)+.				2671
			RTS PC				
: Routi	ne Size: um stack	22 words, Routine Base: depth per invocation: 4 words	*CODE* + 5272				

SEQ 0311

```
ZRQAM3
                 RD/RX EXERCISER
                                                                   14-Dec-1983 16:12:07
                                                                                             VAX-11 Bliss-16 V3-555
V01.2
                 INITIALIZATION TEST ROUTINES
                                                                   14-Dec-1983 16:12:00
                                                                                             DISK $USER2: [DIETZ.RDRX]ZRQACO.BL2:161 (15)
                routine ACCESS : novalue =
          2697
          2698
.
                         THIS ROUTINE IS CALLED BY INIT_TEST TO VERIFY THAT THE CURRENT DISK CAN BE ACCESSED. THIS OBJECTIVE IS ACCOMPLISHED BY FORMATTING AND
          2699
:
          2700
                         SENDING ONE OR TWO MSCP ACCESS COMMANDS TO THE DISK, AND CHECKING THE STATUS FIELD OF THE RESPONSE MESSAGE(S).
          2701
.
          2702
.
          2703
          2704
                         IMPLICIT INPUTS:
.
          2705
                                 CCTLR - CURRENT CONTROLLER NUMBER
          2706
                                 CDISK - CURRENT DISK ADDRESS (RD/RX DISK NUMBER)
          2707 !
                                 L$LUN - CURRENT (DRS) UNIT NUMBER
          2708 !-
          2709
:
          2710
                     begin
          2711
:
          2712
                local
:
          2713
                         RESULT : word initial (FAILURE).
                                                                  ! GUILTY UNTIL PROVEN INNOCENT
          2714
                         LBN : word.
                         PASS : word initial (1);
          2715
                                                                   ! LOOP PASS COUNT
          2716
:
                     ST_CODE - SB_CODE - 0;
          2717
                                                                   ! STATUS CODE AND SUB-CODE
                     LBN = (((.MAX_LBN [.L$LUN] + 1) + -1) and #0'77777') - 1;
          2718
          2719
                                                                   ! START WITH LAST LBN ON TOP SURFACE: [(X+1)/2] -1
          2720
          2721
                     do
          2722
                                                                   ! LOOP STARTS HERE
                        2723
          2724
                                                                   ! SET DISK ADDR (RD/RX DISK NUMBER)
          2725
          2726
          2727
          2728
          2729
          2730
                         if SEND (.P_INDEX) eq1 FAILURE
                                                                   ! ATTEMPT TO SEND; IF CTLR NOT ONLINE
          2731
                         then
          2732
                             begin
PUT_PKT (.P_INDEX);
           2733
                                                                   ! RETURN PACKET TO POOL
                             PASS - 2:
          2734
                                                                   ! NO MORE TRIES
          2735
                             end
          2736
                         else
          2737
                             begin
                                                                   ! IF SEND WAS SUCCESSFUL
          2738
.
          2739
:
          2740
                                 begin
WAIT ();
          2741
                                                                   ! WAIT FOR RESPONSE
          2742
                                 RP_INDX - OUT_IODQ ();
                                                                   ! GET RETPKT (RESPONSE) INDEX
          2743
                                 RP_ADDR = RETPKT + (.RP_INDX + RP_LEN + 2);
                                                                                    ! CALCULATE RETPKT ADDRESS
          2744
          2745
                                  if .RP_ADDR [MESTYP] neg MT_SEQ ! RETURN ALL RETPKTS NOT SENT BY CONTROLLER
           2746
          2747
                                     PUT_RETPKT (.RP_INDX);
:
          2748
```

```
SEQ 0312
ZRQAM3
                    RD/RX EXERCISER
                                                                                14-Dec-1983 16:12:07
                                                                                                              VAX-11 Bliss-16 V3-555 Page 57 DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (15)
V01.2
                    INITIALIZATION TEST ROUTINES
                                                                                14-Dec-1983 16:12:00
            2749
                                   until (.RP_ADDR [CONID] eql CID_DRIVER) or
            2750
                                          ((.RP_ADDR [MESTYP] eq1 MT_SEQ) and ((.RP_ADDR [ENDCOD] and OP_END) eq1 OP_END);
            2751
            2752
            2753
            2754
2755
                                   if .RP_ADDR (CONID) eql CID_DRIVER ! IF RETPKT CAME FROM "DRIVER"
                                   then
            2756
                                       PASS = 2
                                                                                ! NO MORE TRIES
            2757
                                   else
            2758
            2759
                                        if .RP_ADDR [ENDCOD] neg (OP_ACC or OP_END)
            2760
                                        then
            2761
                                             begin
PRINTF (DBM29):
            2762
                                                                                ! "RETPKT HAS BAD ENDCODE"
            2763
                                             EMSCMD ():
            2764
                                             end
            2765
                                        else
            2766
                                             begin
                                                                                ! RETPKT HAS CORRECT ENDCODE
                                             ST_CODE = .RP_ADDR [STSCOD]: GET STATUS CODE FROM PACKET
SB_CODE = .RP_ADDR [SUBCOD]: GET SUB-CODE FROM PACKET
            2767
            2768
            2769
            2770
                                             if .ST_CODE eql ST_SUC
                                                                                ! IF STATUS CODE INDICATES SUCCESS
            2771
                                             then
            2772
                                                  begin
RESULT - SUCCESS:
            2773
            2774
                                                  PASS - 2:
                                                                                ! NO NEED TO TRY AGAIN
            2775
                                                  end:
            2776
            2777
                                             end:
                                                                                ! IF RETPKT HAS CORRECT ENDCODE
            2778
            2779
                                   PUT_RETPKT (.RP_INDX);
            2780
                                                                                ! IF SEND WAS SUCCESSFUL
                                   end:
            2781
            2782
                              LBN - .LBN + 1;
                                                                                ! ADVANCE TO FIRST LBN OF BOTTOM SURFACE
            2783
                              PASS - .PASS + 1:
                                                                                ! SECOND PASS
            2784
                                                                                ! END OF PASS LOOP
                              end
            2785
                         until .PASS gegu 3:
            2786
            2787
                         if .RESULT eql FAILURE
            2788
:
                         then
                             t_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
CST_ADDR [.CUOFF, D_FATAL] = TRUE; ! FATAL EI
ERROF (17, EGD_17, EMS_30);
DUR [.L$LUN] = DU_ACCESS; ! SET REA!
DODU (.L$LUN); ! DROP UN
! IF ACCE
            2789
:
            2790
:
            2791
                                                                                ! FATAL ERROR
:
            2792
                                                                                          ! ACCESS FAILED
            2793
                                                                                ! SET REASON TO DROP UNIT
            2794
                                                                                ! DROP UNIT
            2795
                                                                                ! IF ACCESS FAILED
            2796
:
                         end;
                                                                                ! ROUTINE ACCESS
```

000000 004137 000000G

ACCESS: JSR ACCESS INITIALIZATION TEST ROUTINES R1. \$ SAVE4

2696

ZRQAM3 VO1.2		RD/RX EXERCISER INITIALIZATION TE	ST ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK&USER2:[DIETZ.RDRX]ZRQACO.BL	SEQ 0313 Page 58 .2:161 (15)
000004 000006	005003			CLR	R3	: RESULT	2710
000006	012702 005037	000001 000000G		MOV	#1.R2	PASS	
000012	005037	000000G		CLR	SB.CODE ST.CODE		2717
	013700	000000G		MOV	L\$LUN,RO		2718
000026	006300			ASL	RO		2110
000030	016000 060200	0000541		MOV	MAX.LBN(RO),RO		
000036	006200			ADD ASR	R2.R0 R0		
000022 000026 000030 000034 000036 000040 000042 000046 000050 000054 000060 000064 000066	010004 042704			MOV	RO,R4	; +,LBN	
000042	042704	100000		BIC	#100000,R4	; *,LBN	
000046	005304 013746	000000G		DEC	R4	; LBN	
000054	004737	000000G	18:	JSR	CCTLR,-(SP) PC.GET.PKT RO,P.INDEX		2723
000060	010037	000000G		MOV	RO.P. INDEX		
000064	010037 010016			MOV		; P.INDEX,*	2724
000066	012746 004737	000104 000000G		MOV	#104,-(SP)		
000076	013760	000000G 000016G		JSR MOV	COTSK MSCP PKT-16(PA)		
00000	112760	000020 000022G		MOVB	#0,(SP) #104,-(SP) PC,BL#MUL CDISK,MSCP.PKT+16(R0) #20,MSCP.PKT+22(R0) #1000,MSCP.PKT+26(R0) R4,MSCP.PKT+46(R0) #2,MSCP.PKT+4(R0) P.INDEX,(SP) PC,SEND		2725
000112	012760	001000 0000266		MOV	#1000,MSCP.PKT+26(RO)		2726
000120	010460 012760 013716	000046G 000002 000000G 000000G		MOV	R4.MSCP.PKT+46(R0)	: LBN.+	2727
000124	013716	0000005 0000046		MOV	P THOSY (CD)		2728
000136	004737	000000G		JSR	PC. SEND		2730
000142	005700			TST	NO		
000103 000120 000124 000132 000136 000142 000144 000146 000152	001007	0000000		BNE	21		
000152	004737	000000G		MOV JSR	P.INDEX.(SP) PC.PUT.PKT		2733
000156	013716 004737 012702	000000G 000002		MOV	#2,R2	: .PASS	2734
AAATOS	200524			BR	91	1	2730
000164	004737 004737	000000G	28:	JSR	PC.WAIT		2741
000174	010037	000000G 000000G		JSR MOV	PC.OUT.IODQ RO.RP.INDX	1	2742
000170 000174 000200 000202	010037 010016			MOV	RO.(SP)	: RP.INDX.4	2743
000202	012746	000060 000000G 000000G		MOV	#60,-(SP) PC.BL#MUL #RETPKT,RO	1 11 12 10 11	2143
000206	004737 062700	0000006		JSR	PC, BL #MUL		
000216	010037	0000006		ADD MOV	RO.RP. ADDR		
000222	132760	000360 000002		BITB	#360,2(RO)		2745
000230	001404 013716 004737 005726			BEQ	34		
000232	013716	000000G		MOV	RP.INDX.(SP)		2747
000242	005726	000000	34:	JSR TST	PC,PUT.RETPKT		2740
000244	015/01	000000G		MOV	RP.ADDR,R1		2740 2750
000250	005000			CLR	RO		2130
000212 000216 000222 000230 000232 000236 000242 000244 000250 000252 000260 000262	126127	000003 000003		CMPB	3(R1),03		
000262	001002 005200			BNE	46 RO		
000264	000407			BR	56		
000266	132761	000360 000002	46:	BITB	#360,2(R1)		2751
000266 000274 000276	001333	000014		BNE	21		
000210	105761	000014		TSTB	14(R1)		2752

	ZRQAM3 VO1.2		RD/RX EXERCISE INITIALIZATION	R TEST ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL	SEQ 0314 Page 59 .2:161 (15)
1.	000302	100330			BPL	21		
	000304 000306	006000		5\$:	ROR	2\$ RO		2754
1	000306	103444	000014 000000		BLO	78		2756
-	000316	126127 001412	000014 000220		CMPB BEQ	14(R1),#220 6\$		2759
-	000310 000316 000320	012716	000000G		MOV	#DBM29,(SP)		2762
	000324	012746	000001		MOV	#1,-(SP)		2102
1	000330	010600			MOV	SP,RO	; SP.4	
1	000332	104417	000000G		TRAP	17 DC EMECHD		
-	000324 000330 000332 000334 000340 000342 000344 000352 000360 000366 000370 000372 000374 000376 000402 000406 000412 000414 000420	005726	***************************************		JSR TST	PC,EMSCMD (SP)+		2763
1	000342	000430			BR	81		2761 2759
-	000344	116137	000016 000000	G 64:	MOVB	16(R1).ST.CODE #177740,ST.CODE		2767
-	000352	042737	177740 000000	G	BIC	#177740,ST.CODE		
1	000364	006500	000016		MOV ASR	16(R1),R0 R0		2768
1	000366	006200			ASR	RO		
	000370	016100 006200 006200 006200			ASR	RO		
1	000372	006200			ASR	RO		
	000374	006200	174000		ASR	RO		
	000402	042700	174000 000000G		BIC	#174000,R0		
1	000406	010037 005737 001004	000000G		TST	RO,SB.CODE ST.CODE		2772
-	000412	001004			BNE	81		2770
1	000414	012703	000001		MOV	01.R3	: *.RESULT	2773
1	000420	012702	000002	7\$:	MOV	42.R2	PASS	2774
1	000424	013716	000000G	84:	MOV	RP.INDX,(SP)		2779
1	000434	005204	000000G	98:	JSR INC	PC.PUT.RETPKT	. 104	0700
1	000424 000430 000434 000436	013716 004737 005204 005202		701	INC	R2	I LBN I PASS	2782 2783
	000440 000442 000446 000450 000452	022626			CMP	(SP)+,(SP)+	1	2722
1	000442	020227	000003		CMP	R2.43	PASS. 4	2785
1	000450	103600 005703			BLO	16		
1	000452	001025			TST	R3 10¢	; RESULT	2787
-	000454	001025 013700	000000G		MOV	T.ADDR.RO		2790
1	000460	105260	000062 000000G		INCB	62(RO)		2190
-	000464	013700	000000G		MOV	CUOFF, RO		2791
1	000470 000472	006300	0000000		ASL	RO		
	000476	063700	000000G 010000		ADD	CST.ADDR.RO		
-	000502 000504 000506 000510	052710 104455			BIS	#10000,(R0) 55		2702
1	000504	000021 000000G 000000G 013700			WORD	21		2792
	000506	000000G			. MORD . MORD . MORD	EGD.17		
1	000510	000000G	0000000		. WORD	EMS.30		
-	000512 000516	112760	000000G 000010 000000	c	MOV	L&LUN,RO		2793
	000524	104451	000010 000000		MOVB	#10,DUR(R0) 51		2704
-	000526	000207		106:	RTS	PC		2794 2696
1			172					2070
1	HOUT	ne bize:	172 words.	Routine Base:	*CODE *	5546		

Routine Size: 172 words. Routine Base: #CODE# + 5346 : Maximum stack depth per invocation: 10 words

SEQ 0315

```
ZRQAM3
                  RD/RX EXERCISER
                                                                         14-Dec-1983 16:12:07
                                                                                                     VAX-11 Bliss-16 V3-555
                                                                                                     DISK&USER2: [DIETZ.RDRX]ZRQACO.BL2:161 (16)
                  MULTI-DRIVE TEST ROUTINES
V01.2
                                                                         14-Dec-1983 16:12:00
           2798 #sbttl 'MULTI-DRIVE TEST ROUTINES'
           2799
           2800 routine MULTI_DRIVE : novalue .
           2801
           2802 !+
           2803 !
                            THIS SUBTEST IS THE MOST SIGNIFICANT PART OF THE ENTIRE PROGRAM. THE
           2804
                           MULTI-DRIVE TEST IS A HOST-CONTROLLED EXERCISER DESIGNED TO GIVE THE
           2805
                           USER AN INDICATION OF HOW ONE OR SEVERAL RDRX DRIVES WOULD PERFORM IN
           2806
                           AN OPERATING SYSTEM ENVIRONMENT.
           2807
           2808
                            THIS ROUTINE ACTS AS AN "EXECUTIVE" TO THE WHOLE PROCESS. AFTER
                           INVOKING MD_INIT TO INITIALIZE MULTI-DRIVE TEST DATA, THIS ROUTINE ENTERS A LOOP WHICH ISSUES GIOS TO ALL ACTIVE CONTROLLERS AND PROCESSES
           2809
           2810
:
                           ANY RESPONSES. IN ADDITION, ALL OUTSTANDING COMMANDS ARE TIMED IN DRY_TIMCHK WHICH IS INVOKED EVERY SECOND. NORMAL TERMINATION OF THIS LOOP OCCURS WHEN QIOS ARE NO LONGER BEING ISSUED, AND ALL OUTSTANDING
           2811
2
           2812
:
           2813
2
                           QIOS HAVE COMPLETED.
           2814
.
           2815 !-
           2816
:
           2817 begin
.
           2818
.
           2819 MD_INIT ():
                                                                                   ! INIT MULTI-DRIVE TEST DATA
.
           2820 INIT_OCCURED - TRUE;
                                                                         ! INIT SEQUENCE DONE
:
           2821 do
           2822
                                                                                   ! START OF EXECUTIVE LOOP
                       begin
           2823
:
            2824
                       incr CTLR from 0 to (MAX_CTLR - 1) do
                                                                                   ! FOR EACH CONTROLLER
:
            2825
                           begin
SET_CPAR (.CTLR);
                                                                         ! start of controller loop
:
            2826
.
                                                                                   ! SET UP CURRENT CONTROLLER PARAMETERS
            2827
:
            2828
                            SETPRI (PRIO7):
                                                                         ! NO INTERRUPTS WHEN EXAMINING SA
                                                                          ! FAKE INTERRUPTING CONTROLLER'S NUMBER ! FAKE INTERRUPTING CONTROLLER'S CST ADDRESS
            2829
                            ICTLR - .CCTLR;
.
                            ICST_ADDR - .CST_ADDR;
            2830
:
                           2831
                                                                         ! FAKE INTERRUPTING CONTROLLER'S DCT ADDRESS
:
            2832
:
                                                                                   ! FAKE INTERRUPTING CONTROLLER'S ADDRESS
            2833
.
            2834
                                                                                   ! CONTENTS OF THE SA REGISTER
.
            2835
:
            2836
                            if BIT_TST (IDCT_ADDR [SA_SAVE], SA_ERR)
                                                                                   ! IF SA SHOWS AN ERROR
.
            2837
:
                            then
                                     begin
FATAL_ERROR ();
SETPRĪ (PRIOO);
            2838
:
            2839
                                                                                   ! DECLARE FATAL ERROR
.
            2840
                                                                                   ! LOWER PRIORITY
            2841
                                     exitloop:
                                                                                   ! QUIT
.
                                     end
            2843
                            else
            2844
                                     SETPRI (PRIOO);
                                                                                   ! IF NO ERROR, CONTINUE
            2845
            2846
                            if QIO_OK ()
                                                                         ! IF O.K. TO ISSUE QIO(S) TO THIS CONTROLLER
            2847
                            then
            2848
                                     begin
8
                                     QIO_GEN ();
            2849
                                                                                   ! GENERATE 1 OR 2 QIOS
.
            2850
.
```

```
SEQ 0316
ZRQAM3
                 RD/RX EXERCISER
                                                                    14-Dec-1983 16:12:07 VAX-11 Bliss-16 V3-555
                                                                                                                                      Page 61
                                                                     14-Dec-1983 16:12:00 DISK#USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (16)
                 MULTI-DRIVE TEST ROUTINES
V01.2
          2851
                                   if (.MX1 geq 0) and (not .EOP_FLAG)
                                                                             ! IF SUCCESS ON FIRST QIO
           2852
.
           2853
:
           2854
.
           2855
                                       if SEND (.MX1) eql SUCCESS ! ATTEMPT TO SEND IT. IF SUCCESS
:
           2856
.
           2857
                                           QIO [.CTLR] = .QIO [.CTLR] + 1 ! INCR OUTSTANDING QIO COUNT
:
           2858
.
           2859
                                           PUT_PKT (.MX1):
                                                                             ! RETURN PACKET TO POOL
.
           2860
.
                                  if (.MX2 geq 0) and (not .EOP_FLAG)
           2861
                                                                             ! IF SUCCESS ON SECOND QIO
.
           2862
:
           2863
.
           2864
           2865
                                       if SEND (.MX2) eql SUCCESS
                                                                              ! ATTEMPT TO SEND IT. IF SUCCESS
.
           2866
.
           2867
                                           QIO (.CTLR) - .QIO (.CTLR) + 1 ! INCR OUTSTANDING QIO COUNT
:
           2868
                                       else
:
           2869
                                           PUT_PKT (.MX2);
                                                                              ! RETURN PACKET TO POOL
:
           2870
:
           2871
                                                                              ! O.K. TO ISSUE QIO(S)
:
                                   end:
           2872
.
           2873
                          end;
                                                                     ! end of CONTROLLER LOOP
.
           2874
                                                                     !all controllers should have 1 or 2 cmds in packets
.
           2875
.
           2876
                     PROC_RETPKT ();
                                                                     ! PROCESS ANY RETURN PACKETS
.
           2877
.
           2878
.
                      end
                                                                     ! EXECUTIVE PROCESSING LOOP
           2879
.
.
           2880
                until (not QIO_OUT ()) or
           2881
                          (.EOP_FLAG):
:
           2882
.
                                                                     ! EXERCISER
                                                     .SBTTL MULTI.DRIVE MULTI-DRIVE TEST ROUTINES
000000 004137 000000G
                                           MULTI.DRIVE:
                                                             R1. #SAVE2
                                                                                                                                           2800
000004
        005746
                                                    TST
                                                             -(SP)
000006
        004737
                 000000V
                                                    JSR
                                                             PC.MD. INIT
                                                                                                                                           2819
000012
        112737
                 000001 000000G
                                                    MOVB
                                                             #1.INIT.OCCURED
                                                                                                                                            2820
000020
        005002
                                                    CLR
                                                                                               : CTLR
                                                                                                                                            2824
000022
        010246
                                                             R2,-(SP)
                                                                                                : CTLR.+
                                                                                                                                           2826
000024
        004737
                 000000G
                                                    JSR
                                                             PC.SET.CPAR
000030
000034
        012700
                 000340
                                                    MOV
                                                             #340,RO
                                                                                                                                           2828
                                                    TRAP
                                                            CCTLR, ICTLR
CST.ADDR, ICST.ADDR
DCT.ADDR, IDCT.ADDR
000036
        013737
                 000000G 000076'
                                                    MOV
                                                                                                                                           2829
                 000000G 000000G
000000G 000000G
000044
        013737
                                                    MOV
                                                                                                                                            2830
000052
        013737
                                                    MOV
                                                                                                                                            2831
000060 017737
                 000000G 000000G
                                                            SICST.ADDR, IRDRX.ADDR
IDCT.ADDR,R1
                                                    MOV
                                                                                                                                            2832
000066 013701
                 000000G
                                                    MOV
                                                                                                                                            2833
000072 013700
                 000000G
                                                    MOV
                                                             IRDRX. ADDR, RO
                                                             2(R0),2(SP)
2(SP),2(R1)
000076
        016066
                 000002 000002
                                                                                               : *,RC.REG
000104
        016661
                 000002
                          000002
                                                                                                RC.REG.
```

						0.9		
ZRQAM3		RD/RX EX	ERCISER			14-Dec-1983 16:12:07	7 VAX-11 Bliss-16 V3-555	SEQ 0317 Page 62
V01.2		MULTI-DR	RIVE TEST F	ROUTINES		14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK#USER2:[DIETZ.RDRX]ZRQACO.BL	2:161 (16)
000112	016601	000002			MOV	2(SP),R1		2836
000116	042701	077777			BIC	#77777,R1		
000122	020127	100000			CMP	R1,#-100000		
000126	001006	0000000			BNE	3\$		
000130	004737	000000V			JSR	PC.FATAL.ERROR	내가의 [1] 내가 아이는 그 그런 그가 하고 있다고 있다.	2839
000134	104441				TRAP	41	[[선생님 : 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1.	2840
000140	005726				TST	(SP)+		2838
000136 000136 000146 000146	000464				BR	81		2000
000144	005000			3\$:	CLR	RO		2844
00014	104441				TRAP	41		
000150 000150 000150	004737	000000V			JSR	PC.QIO.OK		2846
000154	103052				ROR	RO 7\$		
00016	004737	000000V			BCC JSR	PC.QIO.GEN		2849
00016	013700	000100			MOV	MX1.RO		2851
000170	002421				BLT	54		2031
00017	132737	000001	000000G		BITB	#1.EOP.FLAG		2852
00020	001015				BNE	5#		
00020	010016	0000000			MOV	RO.(SP)		2855
00020	004737	000000G 000001			JSR	PC.SEND		
00021	020027	000001			CMP	RO.01		
00021	001003 105262	000000G			INCB	QIO(R2)	: *(CTLR)	2857
00022	000404				BR	54	1	2855
00022	013716	000100		48:	MOV	MX1,(SP)		2859
000164 000176 000206 000206 000216 000216 000226 000226 000236 000246 000256 000256	004737	000000G			JSR	PC.PUT.PKT		
00023	013700	000102		5#:	MOV	MX2,RO		2861
00024	002421 132737	000001	000000G		BLT	7\$ #1.EOP.FLAG		2062
00025	001015	000001	000000		BITB	76		2862
00025	010016				MOV	RO,(SP)		2865
00025	004737	00000G			JSR	PC SEND		2003
00026	020027	000001			CMP	RO. #1		
00026	001003				BNE	61		
00026	105262 000404	000000G			INCB	QIO(R2)	: *(CTLR)	2867
00027 00027 00030	013716	000102		64.	BR	7\$ MX2,(SP)		2865
00030	004737	000000G		6#:	MOV JSR	PC, PUT. PKT		2869
00030 00030 00031	005726	000000		76:	TST	(SP)+		2825
00030	005202				INC	R2	CTLR	2824
00031	000243				. WORD	CLV!CLC		
00031	003643				BLE	21		
00031	004737	000000V		84:	JSR	PC.PROC.RETPKT		2876
00032	004737	000000V			JSK	PC.QIO.OUT		2880
00052	006000				ROR	RO 96		
00032	103004 132737	000001	000000G		BCC	AL EOD ELAC		2001
00032 00032 00033 00033	001630	000001	***************************************		BEQ	#1.EOP.FLAG		2881
00054	005726			91:	TST	(SP).		2800
	000207				RTS	PC	•	2000

ZRQAM3 VO1.2

RD/RX EXERCISER MULTI-DRIVE TEST ROUTINES

14-Dec-1983 16:12:07 14-Dec-1983 16:12:00

SEQ 0318 VAX-11 Bliss-16 V3-555 Page 63 DISK\*USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (16)

: Routine Size: 114 words. Routine Base: \$CODE\$ + 6076 : Maximum stack depth per invocation: 7 words

```
SEQ 0319
ZRQAM3
                 RD/RX EXERCISER
                                                                      14-Dec-1983 16:12:07
                                                                                                VAX-11 Bliss-16 V3-555
                                                                                                                                        Page 64
V01.2
                 MULTI-DRIVE TEST ROUTINES
                                                                      14-Dec-1983 16:12:00
                                                                                                DISK*USER2: [DIETZ.RDRX]ZRQACO.BL2:161 (17)
                routine MD_INIT : novalue =
           2884
           2885
           2886
                          THIS ROUTINE IS CALLED BY ROUTINE MULTI-DRIVE TO INITIALIZE DATA ITEMS
                 :
           2887
                          USED BY THE MULTI-DRIVE TEST.
                 .
           2888
           2889
           2890
                      begin
           2891
                      IF NOT .INIT_OCCURED
           2892
                                                                                       ! IF THIS IS A START
           2893
                      then
           2894
                          INIT_IO_BUFF ():
                                                                                       ! PARTITION FREE MEMORY INTO I/O BUFFERS
           2895
           2896
2897
                      if (.ENTRY_REASON neg CONT) and
                                                                                      ! IF START, RESTART, OR PWR FAIL
                        (.ENTRY_REASON neg NEW_PASS)
           2898
           2899
           2900
                          incr CTLR from 0 to (MAX_CTLR - 1) do
           2901
                              begin
SET_CPAR (.CTLR);
           2902
           2903
2904
                               incr DISK from (0 + OF_UN) to (3 * UNIT_SIZE + OF_UN) by UNIT_SIZE do
           2905
                                   begin
SET_UPAR (.DISK);
DPST (.L$LUN) = DP_CNT;
           2906
           2907
                                                                                     ! INITIALIZE DATA PATTERN SEQUENCE TABLE
           2908
2909
           2910
2911
2912
                      incr COUNT from 0 to (QIO_PER_CTLR * MAX_CTLR - 1) do BUFF_OWN [.COUNT] = -1;
                                                                                       ! INITIALIZE I/O BUFFER ALLOCATION
           2913
                                                                                              TABLE
           2914
.
           2915
                      end:
                                                                                       ! ROUTINE MD_INIT
                                                     .SBTTL
                                                             MD.INIT MULTI-DRIVE TEST ROUTINES
000000
        004137
                 000000G
                                            MD. INIT: JSR
                                                             R1. $SAVE2
                                                                                                                                             2883
000004
        132737
                 000001 000000G
                                                    BITB
                                                             #1.INIT.OCCURED
                                                                                                                                             2892
000012
        001002
                                                    BNE
000014
        004737
                 000000V
                                                     JSR
                                                             PC. INIT. IO. BUFF
                                                                                                                                             2894
000020
        123727
                 000000G 000003
                                                     CMPB
                                            18:
                                                             ENTRY . REASON . #3
                                                                                                                                             2896
        001433
                                                     BEQ
000030
        123727
                 000000G 000005
                                                    CMPB
BEQ
                                                             ENTRY . REASON , 45
                                                                                                                                             2897
000036
        001427
000040
        005002
                                                     CLR
                                                             R2
                                                                                                : CTLR
                                                                                                                                             2900
000042
        010246
                                                    MOV
                                                             R2,-(SP)
                                            21:
                                                                                                                                             2902
000044
        004737
                 000000G
                                                     JSR
                                                             PC. SET. CPAR
000050
        012701
                 000003
                                                    MOV
                                                             43,R1
                                                                                                : *.DISK
                                                                                                                                             2904
000054
        010116
                                                    MOV
                                            34:
                                                             R1,(SP)
                                                                                                : DISK. .
                                                                                                                                             2906
000056
        004737
                 000000G
                                                             PC. SET. UPAR
000062
        013700
                 000000G
                                                     MOV
                                                             L&LUN, RO
                                                                                                                                             2907
                          0000501
000066
        112760
                 000025
                                                    MOVB
                                                             #25.DPST(RO)
000074
        062701
                                                             47.R1
                                                     ADD
                                                                                                : *.DISK
                                                                                                                                             2904
```

-	ZRQAM3 VO1.2		RD/RX EXERCISER MULTI-DRIVE TEST ROUTINES	14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 Page 65 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (17)
-	000100 000104	020127 003763	000030	CMP R1.#30 BLE 3# TST (SP)+	; DISK,*
-	000106 000112	005726 005202 000243		IST (SP)+ INC R2 .WORD CLV!CLC	CTLR 2900
THE REAL PROPERTY OF STREET	000114 000116 000120 000126	003752 005000 112760 005200	000377 000000G 4\$: 5\$:	BLE 2\$ CLR RO MOVB #377,BUFF.OWN(RO) INC RO CMP RO.#7	: COUNT 2912 : *,*(COUNT) 2913 : CCUNT 2912
-	000130 000134 000136	020027 003771 000207	000007	CMP RO.07 BLE 5\$ RTS PC	: COUNT, * 2883

<sup>:</sup> Routine Size: 48 words. Routine Base: \$CODE\$ + 6442 : Maximum stack depth per invocation: 5 words

```
SEQ 0321
ZRQAM3
                    RD/RX EXERCISER
                                                                                 14-Dec-1983 16:12:07
                                                                                                               VAX-11 Bliss-16 V3-555
V01.2
                    MULTI-DRIVE TEST ROUTINES
                                                                                 14-Dec-1983 16:12:00
                                                                                                               DISK $USER2: [DIETZ.RDRX]ZRQACO.BL2:161 (18)
            2916 routine INIT_IO_BUFF : novalue =
            2917
:
            2918
                    . .
2
                             THIS ROUTINE IS CALLED BY MD_INIT WHEN THE MULTI-DRIVE TEST IS FIRST STARTED. IT IS RESPONSIBLE FOR PARTITIONING FREE MEMORY INTO A COLLECTION OF I/O BUFFERS. THE SIZE OF EACH I/O BUFFER IS DETERMINED BY A NUMBER OF FACTORS, INCLUDING THE NUMBER OF UNITS, THE NUMBER OF CONTROLLERS, AND THE SIZE OF FREE MEMORY.
            2919
            2920
            2921
            2922
            2923
            2924
            2925
                              ONCE THE BUFFER SIZE IS DETERMINED, THE NUMBER OF I/O BUFFERS IS
                              CALCULATED. FINALLY, THE BUFFER ADDRESS (BUFF_ADDR) TABLE IS LOADED WITH FIXED BUFFER DESCRIPTORS THAT ARE USED IN THE ALLOCATION AND
            2926
            2927
            2928
                              DEALLOCATION PROCESS.
            2929
            2930
                              IMPLICIT IMPUTS:
            2931
                                        CTLR_CNT - THE NUMBER OF CONTROLLERS CONFIGURED
            2932
                                        L&UNIT - THE NUMBER OF UNITS AVAILABLE FOR TESTING
            2933
                                        FREE_MEM_ADDR - START OF FREE MEMORY
            2934
2935
2936
                         begin
            2937
             2938
                         local
             2939
                              DRS_START;
            2940
            2941
2942
2943
2944
2945
2946
2947
2948
2949
2950
                         DRS_START = .FREE_MEM_ADDR + 2 + ( ..FREE_MEM_ADDR + 2);
                                                                                                     ! START OF SUPERVISOR
                         BUFF_ADDR [0] = (.FREE_MEM_ADDR + 2 + 1) and #0'177776';
                                                                                                    ! START OF READ/WRITE BUFFERS
                         while (.BUFF_ADDR [0] and #0'37') neg 0 do
                                                                                                      ! FORCE FIRST I/O BUFFER TO START
                              BUFF_ADDR [0] . BUFF_ADDR [0] + 2;
                                                                                                      ! ON EVEN BOUNDARY
                         BYTS_PER_QIO = ((.DRS_START - .BUFF_ADDR [0]) / (QIO_PER_CTLR + MAX_CTLR)) and #0'177740';
                                                                                                      ! MAX TRANSFER SIZE
                         if .BYTS_PER_QIO atru MAX_XFER_SIZE
             2951
             2952
                              BYTS_PER_QIO . MAX_XFER_SIZE:
                                                                                                     ! ADJUST TRANSFER SIZE LOWER
            2953
2954
                         if .BYTS_PER_QIO lesu 32
             2955
                         then
             2956
                              begin
ERRSF (2, EGS_02, 0);
             2957
                                                                                                     ! ERROR IF NOT ENOUGH MEMORY
             2958
                              DOCLN:
            2959
2960
2961
2962
2963
2964
                              end:
                         if (QIO_PER_CTLR * MAX_CTLR) gtru 1
                         incr index from 1 to (QIO_PER_CTLR + MAX_CTLR - 1) do
                                                                                                                ! INIT REMAINING TABLE ENTRIES
             2965
                              BUFF_ADDR [.index] = .BUFF_ADDR [.index - 1] + .BYTS_PER_QIO: ! FIXED BUFFER ADDRESS
            2966
2967
                         end:
                                                                                                                ! ROUTINE INIT_IO_BUFF
```

ZRQAM3 VO1.2		RD/RX EXERC MULTI-DRIVE	ISER TEST ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.E	SEQ 0322 Page 67 BL2:161 (18)
000000	004137	00000G	TAITT	.SBTTL	INIT.10.BUFF MULTI-DRIVE TEST	ROUTINES	
000000	004131	000000	INIT	IO.BUFF:	R1, \$SAVE3		2016
000004	013701	000000G		MOV	FREE.MEM.ADDR,R1		2916 2941
000010	011100			MOV	(R1),R0		
000012	006300 060100			ASL	RO		
22222	062700	000002		ADD	R1,R0 #2,R0		2936
000022	062701	000003		ADD	43,R1		2941 2942
000026	010137	000000G		MOV	R1.BUFF.ADDR		276
000032	042737	000001 000	000G	BIC	#1.BUFF.ADDR		
000040	032737	000037 000	0000G 1\$:	BIT	#37.BUFF.ADDR	•	2944
000050	062737	000002 000	00006	BEQ	2\$ #2,BUFF.ADDR		2045
000056	000770	000002 000		BR	1\$		2945 2944
000016 000022 000026 000032 000040 000050 000056 000060 000062 000066 000072	010046		21:	MOV	RO,-(SP)	: DRS.START.*	2947
000062	163716	000000G		SUB	BUFF.ADDR.(SP)		
000066	012746 004737	000010 000000G		MOV	#10,-(SP) PC,BL#DIV RO,BYTS.PER.QIO		
000076	010037	000000G		JSR MOV	PO BYTS PED OTO		
OOOTOE	042737	000037 000	000G	BIC	#37,BYTS.PER.QIO		
000110	023727	000000G 002	2000	CMP	BYTS.PER.QIO.#2000		2950
000116	101403			BLOS	3#		
000120 000126	012737	002000 000	0000G	MOV	#2000,BYTS.PER.QIO	1	2952
000126	023727 103005	000000G 000	0040 3\$:	CMP BHIS	BYTS.PER.QIO.440		2954
000134 000136	104454			TRAP	54		2957
000140	000002			. WORD	2		2731
000142	000000G			. WORD	EGS.02		
000144 000146	000000			. WORD	0		
000150	104444	000001	44:	TRAP	44 #1,R2	: *.INDEX	2061
000154	010201	000002	54:	MOV	R2.R1	INDEX.	2961 2965
000156	006301			ASL	R1	1 2.02.11	2,03
000160	010200			MOV	R2.R0	: INDEX.*	
000162	006300 016003	1777760		ASL	RO SUEE ADDR 2000 DZ		
000170	063703	177776G 000000G		ADD	BUFF.ADDR-2(RO),R3 BYTS.PER.QIO,R3		
000174	010361	000000G		MOV	R3.BUFF.ADDR(R1)		
000200	005202			INC	R2	; INDEX	2961
000202	020227	000007		CMP	R2.07	: INDEX.*	
000206	003762 022626			BLE	54		
000212	000207			CMP	(SP)+,(SP)+ PC		2936
				113			2916
; Routi	ne Size:	70 words,	Routine Base	#CODE#	6602		

```
SEQ 0323
ZRQAM3
                 RD/RX EXERCISER
                                                                    14-Dec-1983 16:12:07
                                                                                              VAX-11 Bliss-16 V3-555
                                                                                                                                     Page 68
V01.2
                 MULTI-DRIVE TEST ROUTINES
                                                                                              DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (19)
                                                                    14-Dec-1983 16:12:00
           2968 routine QIO_OK =
           2969
:
           2970 !+
.
           2971 !
                          THIS ROUTINE IS CALLED BY THE MULTI_DRIVE "EXECUTIVE" IN ORDER TO
.
           2972
                         DETERMINE WHETHER OR NOT A GIO REQUEST (OR GIO PAIR) SHOULD BE GENERATED TO THE CURRENT CONTROLLER. A VALUE OF "TRUE" IS RETURNED IF
                .
           2973
:
                          THE CONTROLLER MEETS 3 REQUIREMENTS:
           2974
           2975
           2976
                                  A. THE CONTROLLER IS ONLINE:
:
                                  B. THE NUMBER OF OUTSTANDING QIOS IS AT LEAST 2 LESS THAN THE
           2977
:
           2978
                                           MAXIMUM ALLOWED FOR ANY ONE CONTROLLER:
:
                                  C. THERE IS AT LEAST ONE DISK ONLINE TO THE CONTROLLER.
           2979
:
           2980
:
           2981
                          IF ANY OF THESE TEST FAIL, THEN A VALUE OF "FALSE" IS RETURNED.
:
           2982
           2983
                          IMPLICIT IMPUTS:
:
           2984
                                  CCTLR - CURRENT CONTROLLER NUMBER
:
           2985
                                  CST_ADDR - ADDRESS OF CURRENT CONTROLLER'S CST
.
           2986
                ! -
.
           2987
:
           2988
                     if (.CST_ADDR [STATE] eql ONLINE) and
                                                                             ! IF CONTROLLER IS ONLINE
           2989
                         (not .EOP_FLAG) and
                         ((.QIO [.CCTLR] + 2) legu QIO_PER_CTLR) and
           2990
                                                                             ! IF OUTSTANDING QIO COUNT IS O.K.
                         (.CST_ADDR [U_CNT] neg 0)
           2991
                                                                             ! IF THERE IS VALID UNIT
           2992
                     then
.
           2993
:
                         return TRUE
                                                                             ! "TRUE" EXIT POINT
           2994
2995
                     else
:
                                                                             ! "FALSE" EXIT POINT
.
                         return FALSE:
                                                            QIO.OK MULTI-DRIVE TEST ROUTINES
                                                    SBTTL
000000
        013700 000000G
                                           QIO.OK: MOV
                                                            CST. ADDR, RO
                                                                                                                                          2988
000004
                                                            2(R0)
        005760
                 000002
                                                   TST
000010
        100027
                                                   BPL
000012
        132737
                 000001 000000G
                                                   BITB
                                                            #1.EOP.FLAG
                                                                                                                                          2989
000020
        001023
                                                   BNE
000022
        013700
                 000000G
                                                   MOV
                                                            CCTLR, RO
                                                                                                                                          2990
000026
        116000
                 000000G
                                                   MOVB
                                                            QIO(RO),RO
000032
        042700
                 177400
                                                   BIC
                                                            #177400,RO
000036
        062700
                 000002
                                                    ADD
                                                            #2,R0
        020027
000042
                 000010
                                                    CMP
                                                            RO. #10
000046
        101010
                                                    BHI
000050
        013700
                 000000G
                                                   MOV
                                                            CST. ADDR. RO
                                                                                                                                          2991
                                                                                               .
000054
        105760
                 000005
                                                    TSTB
                                                            5(RO)
000060
        001403
                                                   BEQ
000062
        012700
                 000001
                                                   MOV
                                                            41.RO
                                                                                                                                          2968
000066
        000207
                                                            PC
                                                   RTS
000070
        005000
                                           18:
                                                    CLR
000072
        000207
                                                            PC
                                                    RTS
; Routine Size: 30 words,
                                  Routine Base: #CODE# + 7016
```

; Maximum stack depth per invocation: 0 words

RQAM3		RD/RX EXERCISER MULTI-DRIVE TEST ROUTE	INES		14 - Dec	c-1983 16:12:07 c-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQAC	SEQ 0324 Page 0.BL2:161 (20
	2996 2997	routine QIO_OUT =						
	2998	!+						
	2999	! THIS ROUTINE !	S CALLED	BY THE I	MULTI_DRIVE EXE	CUTIVE FOR DETERM	INING THE	
	3000	END OF THE MILE	TT_DDTVE	TECT T	re pulippoet te t	O EVANTLE THE OTO	VECTOR	
	3001 3002	PETIDNED TE TO	ANDING QI	DS ON AN	CONTROLLER. A	VALUE OF "TRUE" DING ON ANY CONTR OUTSTANDING QIOS.	IS .	
		! OTHERWISE. "F/	LSE" IS	RETURNED	INDICATING NO	DING UN ANT CUNIK	ULLER.	
	3004	1-			2.1020/112110 110	oorstriid atos.		
	3005							
	3006 3007	begin						
	3008	incr CTLR from 0	CMAX C	TIR - 1)	do			
	3009				•			
	3010	begin SET_CPAR (.CTL	R);		! SET	UP CURRENT CONTR	OLLER PARAMETERS	
	3011	: CCT ADDD 1	CTATES -	-1 000 700				
	3013	then	SINIE] e	dt ONLTH	: 11	CONTROLLER IS ONL	INE	
	3014	return TRI	JE:					
	3015							
	3016 3017	end;						
	3018	return FALSE:			1 EVT	T - NO CONTROLLER	C ON THE	
	3019	end;				1 - NO CONTROLLER	3 ONLINE	
				.SBTTL	QIO.OUT MULTI	-DRIVE TEST ROUTI	NES	
0000 01	0146		QIO.OU	T:MOV	R1(SP)			2
0002 00	0146			CLR	R1		; CTLR	3
0006 00	4737	000000G	14:	MOV JSR	R1,-(SP) PC.SET.CPAR		: CTLR,+	3
0012 01	3700	00000G		MOV	CST. ADDR. RO			3
0016 00	5760	000002		TST	2(R0)			•
0022 10 0024 00	00004 05726			BPL	2\$			
<i>1</i> 026 01	2700	000001		TST	(SP)+ #1,R0			3
00 2800	0405			BR	3#			
0034 00	5726		2\$:	TST	(SP)+			3
0036 00	)5201 )0243			INC . WORD	R1 CLV!CLC		: CTLR	3
0042 00	3760			BLE	1\$ RO			
0044 00	5000 2601		**	CLR				3 2
0050 00	0207		34:	MOV	(SP)+,R1 PC		•	2
		21 words, Routin	ne Base:	*CODE*				

ZRQAM3 RD/RX EXERCISER 14-Dec-1983 16:12:07 VAX-11 Bliss-16 V3-555 Page 70 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (21) VAX-11 Bliss-16 V3-555 V01.2 MULTI-DRIVE TEST ROUTINES 14-Dec-1983 16:12:00 3020 routine QIO\_GEN : novalue = 3021 3022 . . THIS ROUTINE IS CALLED BY THE MULTI DRIVE EXECUTIVE FOR AN ONLINE CONTROLLER ELIGIBLE TO RECEIVE I/O TRANSFER REQUESTS. IT IS RESPONSIBLE FOR SECURING ONE OR TWO MSCP PACKETS AND LOADING THEM WITH VARIOUS PARAMETERS COMPRISING THE I/O REQUEST. THE I/O REQUEST GENERATED HERE IS DESTINED TO A PARTICULAR UNIT SELECTED AT RANDOM FROM 3023 . 3024 . 3025 3026 3027 3028 THOSE CONFIGURED UNDER THE CURRENT CONTROLLER. 3029 EACH FIELD OF THE PACKET(S) IS LOADED WITHIN INDIVIDUAL ROUTINES 3030 (QIO\_FUNC, QIO\_LBN, QIO\_SIZE, ETC.). MOST OF THE VALUES SELECTED FOR EACH FIELD ARE BASED ON A SET OF RANDOM NUMBER GENERATED AT THE START. 3031 3032 3033 3034 UNDER NORMAL CIRCUMSTANCES. ONLY ONE I/O REQUEST IS GENERATED. HOWEVER, IF THIS I/O REQUEST IS A "WRITE", AND IF THE OPERATOR SELECTED THE OPTION FOR HOST WRITE-COMPARES, THEN A SECOND "READ" REQUEST WILL BE GENERATED WITH THE SAME LBN AND BYTE COUNT. 3035 3036 3037 3038 3039 AFTER THE PACKET(S) HAVE BEEN LOADED, THIS ROUTINE REGAINS CONTROL AND ATTEMPTS TO GET ONE OR THO I/O BUFFERS FOR THE ACTUAL DATA 3040 TRANSFERS. THE SUCCESS / FAIL STATUS OF THIS ENTIRE OPERATION IS PASSED BACK TO THE CALLER THROUGH THE GLOBALS "MX1" AND "MX2"; THEY CONTAIN VALID MSCP PACKET INDECES, OR -1. 3041 3042 3043 3044 3045 Note that the DUP Exerciser is located inside the QIO\_FUNC routine. 3046 Every so often the Dup exerciser will run and return the MSCP Exerciser 3047 to it's normal state. 3048 3049 3050 IMPLICIT INPUTS: 3051 CCTLR - CURRENT CONTROLLER NUMBER 3052 3053 3054 begin MX2 = -1; 3055 ! ASSUME FAILURE IN SECURING 2ND PACKET 3056 3057 if (MX1 = GET\_PKT (.CCTLR)) les 0 ! TRY TO GET 1ST PACKET. IF FAILURE 3058 3059 return; ! NO POINT IN CONTINUING 3060 3061 if (MX2 - GET\_PKT (.CCTLR)) les 0 ! TRY TO GET 2ND PACKET. IF FAILURE 3062 then 3063 begin PUT\_PKT (.MX1); 3064 3065 ! RETURN 1ST PACKET TO POOL MX1 = -1; ! INDICATE FAILURE 3066 return: ! DONE 3067 end: 3068 MAD1 - MSCP\_PKT + (.MX1 + PKT\_LEN + 2); MAD2 - MSCP\_PKT + (.MX2 + PKT\_LEN + 2); 3069 ! CALCULATE STARTING ADDRESSES 3070 : OF BOTH PACKETS 3071 GET\_RANDOM (); : GENERATE A SET OF RANDOM NUMBERS QIO\_UNIT (); ! LOAD RANDOM UNIT NUMBER INTO PACKETS

```
SEQ 0326
                                                                                              VAX-11 Bliss-16 V3-555 Page 71
DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (21)
ZRQAM3
                 RD/RX EXERCISER
                                                                    14-Dec-1983 16:12:07
V01.2
                 MULTI-DRIVE TEST ROUTINES
                                                                    14-Dec-1983 16:12:00
          3073
          3074
                     if .EOP_FLAG
                                                                    ! RETURN IF NO UNIT ONLINE
          3075
                     then
          3076
                          return:
           3077
           3078
                     QIO_FUNC ():
                                                                    ! LOAD RANDOM IMSCP FUNCTION CODE (OPCODE)O OR IDUP EXERCISER TEST A
ND MSCP OPCODED
           3079
                                                                    ! THIS IS THE POINT WHERE THE DUP EXERCISER WILL CUT IN TO THE MSCP
EXERCISER
           3080
                                                                    ! START WRITTING AND READING DBN'S ONCE FINISHED IT WILL RETURN THE
EXERCISER
                                                                    ! TO ITS NORMAL MSCP MODE....
! IF IT WAS IN DUP TEST AND FAILED TO GET A ENVOLOPE RETURN
          3081
:
           3082
                     if (.MX1 les 0) OR (.EOP_FLAG)
:
           3083
                                                                     ! NO POINT IN CONTINUING
                     then return:
           3084
           3085
                     QIO_LBN ();
                                                                     ! LOAD LBN (RANDOM OR SEQUENTIAL)
           3086
                     QIO_SIZE ();
                                                                     ! LOAD RANDOM BYTE COUNT
           3087
                     GET_IO_BUFF (MAD1 [BUF_0]):
                                                                     ! TRY TO GET AN I/O BUFFER
           3088
                     if .MX2 geg 0
           3089
                                                                    ! IF TWO GIOS ARE TO BE ISSUED
           3090
                     then
           3091
           3092
                          GET_IO_BUFF (MAD2 [BUF_0]);
                                                                    ! TRY TO GET 2ND I/O BUFFER
           3093
           3094
                          if .MAD2 [BUF_0] eqla 0
                                                                    ! IF 2ND BUFFER ALLOCATION FAILED
.
           3095
                          then
.
           3096
                              begin
           3097
           3098
                              if .MAD1 [BUF_0] nega 0
                                                                    ! IF 1ST I/O BUFFER WAS ALLOCATED
           3099
                              then
           3100
                                  begin
PUT_IO_BUFF (MAD1 [BUF_0]);
           3101
                                                                    ! RETURN 1ST I/O BUFFER TO POOL
           3102
                                  MAD1 [BUF_0] - 0;
                                                                     ! MARK IT AS FAILED
           3103
                                  end:
           3104
           3105
                              PUT_PKT (.MX2):
                                                                     ! RETURN 2ND PACKET TO POOL
           3106
                                                                     ! INDICATE FAILURE
:
                              MX2 - -1:
           3107
                                                                     ! IF 2ND I/O BUFFER ALLOCATION FAILED
                              end:
           3108
           3109
                                                                     ! IF TWO QIOS ARE TO BE ISSUED
                          end:
           3110
           3111
                      if .MAD1 [BUF_0] eqle 0
                                                                     ! IF 1ST I/O BUFFER ALLOCATION FAILED
           3112
           3113
                          begin
PUT_PKT (.MX1);
           3114
                                                                     ! RETURN 1ST PACKET TO POOL
           3115
                          MX1 = -1;
                                                                     ! INDICATE FAILURE
           3116
                          end
           3117
                     else
           3118
           3119
                          if .MAD1 [OPCODE] eql OP_WRT
                                                                     ! OTHERWISE, IF 1ST OPCODE IS A WRITE (ALL IS O.K.)
           3120
:
           3121
                              FILL_BUFF ():
                                                                     ! FILL 1ST I/O BUFFER WITH APPROPRIATE DATA PATTERN
.
           3122
.
           3123
                                                                     ! ROUTINE QIO_GEN
                     end;
```

					DIO		
ZRQAM3		RD/RX EX	FRCISER		14-Dec-1983 16:13	0.07 VAY-11 B1:00-16 VZ	SEQ 0327
V01.2		MULTI-DR	IVE TEST	ROUTINES	14-Dec-1983 16:12 14-Dec-1983 16:12	2:00 DISK USER2: (DIETZ.	-555 Page 72 RDRX]ZRQACO.BL2;161 (21)
				.SBTT	QIO.GEN MULTI-DRIVE TEST	ROUTINES	
000000	012737	177777 000000G	000102	QIO.GEN:MOV	#-1,MX2 CCTLR,-(SP) PC.GET.PKT RO,MX1		3055
000012	004737	000000G		MOV JSR	PC GET PKT		3057
000016	010037	000100		MOV	RO.MX1		
000055	005726			TST	(SP)+		
000024 000026	005700 002572			TST	RO	; MX1	
	013746	000000G		BLT MOV	6\$ CCTLR,-(SP)		3059
000034	004737	000000G		JSR	PC.GET.PKT		3061
000040	010037 005726	0001021		MOV	RO,MX2		
000044	005726			TST	(SP)+		
000050	002011			TST	RO 1\$	; MX2	
000052	013746	000100		BGE MOV	MX1(SP)		3064
000056	004737	000000G		JSR	MX1,-(SP) PC,PUT.PKT		3004
000062	012737	177777	000100	MOV	0-1,MX1		3065
000030 000034 000040 000046 000050 000052 000056 000062 000070 000072	012737 005726 000207			TST RTS	(SP)+		3061
	013746	000100		18: NOV	MX1(SP)		3063 3069
000100 000104	012746	000104 000000G		MOV	#104,-(SP) PC.BL#MUL #MSCP.PKT.RO		
000104	004737	0000000		JSR ADD	PC.BL \$MUL		
000110 000114 000120	010037	000104		MOV	RO, MAD1		
000120	062700 010037 013716	000000G 000104' 000102' 000104		MOV	MX2.(SP)		3070
000124 000130 000134	012746 004737	000104		HOV	#104,-(SP) PC.BL#MUL #MSCP.PKT,RO		
000134	062700	000000G		JSR ADD	PC.BL FRUL		
000140 000144	010037 004737	0001061		HOV	RO.MAD2		
000144	004737	000000V		JSR	PC.GET.RANDOM		3071
000150 000154	004737 132737	000000V 000001	000000G	JSR	PC.QIO.UNIT	•	3072
000162	001112	000001	000000	BITB	SI SI		3074 3020
000164	004737	000000V		JSR	PC.QIO.FUNC		3078
000170	005737	000100		TST	MX1		3082
000174 000176	002505 132737	000001	000000G	BLT	#1,EOP.FLAG		
000204	001101	000002	000000	BNE	51		3020
000206	004737	000000V		JSR	PC,QIO.LBN		3085
000212	004737 013716	000000V		JSR	PC,QIO.SIZE	1	3086
000222	062716	0001041		MOV	MAD1,(SP) #32,(SP)		3087
000226	062716 004737	000032 000000G		JSR	PC,GET.10.BUFF		
000232	005737	0001021		TST	MX2		3089
000236	002437 013716	000106		BLT	36		
000176 000204 000206 000212 000216 000222 000236 000236 000240 000244 000250 000254 000260	062716	000032		MOV	MAD2.(SP)		3092
000250	004737	000000G		JSR	#32.(SP) PC.GET.IO.BUFF		
000254	013700 005760	000106		MOV	MAD2,RO		3094
000264	001024	000032		TST BNE	32(RO) 3#		
000266	013700	000104		MOV	MAD1,RO		3098
000272	062700	000032		ADD	#32,R0		3090

000276 005710 TST (R0) 000300 001407 BEQ 2\$	
000302 010016 000304 004737 000000G MOV RO.(SP) JSR PC.PUT.IO.BUFF	3101
000310 013700 000104' MOV MAD1,RO ; 000314 005060 000032 CLR 32(RO)	3102
000320 013716 000102' 24: MOV MX2,(SP) 000324 004737 000000G JSR PC,PUT,PKT	3105
000330 012737 177777 000102' MOV #-1.MX2 000336 013700 000104' 38: MOV MAD1.RO	3106 3111
000342 005760 000032 TST 32(R0) 000346 001010 BNE 4\$	
000350 013716 000100' MOV MX1,(SP) 000354 004737 000000G JSR PC,PUT,PKT 000360 012737 177777 000100' MOV #-1,MX1	3114
000366 000410 BR 5#	3115 3111
000370 013700 000104' 4\$: MOV MAD1.RO 000374 126027 000022 000042 CMPB 22(RO),#42 000402 001002 BNE 5\$	3119
000404 004737 000000V JSR PC.FILL.BUFF : 000410 062706 000006 51: ADD #6.SP :	3121
000414 000207 6#: RTS PC	3054 3020

<sup>:</sup> Routine Size: 135 words. Routine Base: #CODE# + 7164 : Maximum stack depth per invocation: 4 words

```
SEQ 0329
ZRQAM3
                  RD/RX EXERCISER
                                                                         14-Dec-1983 16:12:07
                                                                                                     VAX-11 Bliss-16 V3-555
                                                                                                                                               Page 74
V01.2
                  MULTI-DRIVE TEST ROUTINES
                                                                         14-Dec-1983 16:12:00
                                                                                                     DISK#USER2: [DIETZ.RDRX]ZRQACO.BL2;161 (22)
            3124 routine GET_RANDOM : novalue =
           3125
.
           3126
                 . .
                            THIS ROUTINE IS CALLED BY QIO_GEN TO GENERATE A SET OF RANDOM NUMBERS, AND TO STORE THEM INTO THE RANDOM NUMBER TABLE (RANDOM). THE RANDOM
           3127 !
           3128
            3129
                            NUMBERS ARE USED TO SELECT I/O REQUEST PARAMETERS FOR THE CURRENT QIO
           3130
                            OR QIO PAIR. IN ADDITION, IF DATA PATTERN #1 IS BEING USED, THESE
           3131
                            RANDOM NUMBERS WILL BE USED IN THE WRITE OPERATION.
           3132
.
           3133
.
            3134
                       begin
:
            3135
            3136
            3137
                           SEED : word initial (173),
                           NEXT_RANDNUM : word initial (245);
            3138
            3139
.
            3140
                       incr COUNT from 0 to (RDM_LEN - 1) do
                           begin
SEED = (.SEED + .NEXT_RANDNUM + 1) + 4;
NEXT_RANDNUM = (.NEXT_RANDNUM / 4) + .SEED;
           3141
            3142
            3143
            3144
                            RANDOM [.COUNT] = .NEXT_RANDNUM;
            3145
                            end:
.
            3146
.
            3147
                       end;
.
001153
                                                        .PSECT
                                                                *GGG*.
                                                        .EVEN
001154 000255
                                              SEED:
                                                        WORD
                                                                255
001156 000365
                                              NEXT. RANDNUM:
                                                        . WORD
                                                                 365
                                                        . SBTTL
                                                                GET. RANDOM MULTI-DRIVE TEST ROUTINES
007602
                                                                *CODE*, RO
000000 004137 000000G
                                              GET. RANDOM:
                                                       JSR
MOV
                                                                 R1, $SAVE3
                                                                                                                                                    3124
000004 013702
                 001154
                                                                 SEED, R2
                                                                                                                                                    3142
000010 013703
                  001156
                                                                 NEXT, RANDNUM, R3
                                                       MOV
000014 005001
                                                                R1
R3,R0
                                                       CLR
                                                                                                        COUNT
                                                                                                                                                    3140
000016 010300
                                                       MOV
                                              18:
                                                                                                                                                    3142
000020 060200
                                                       ADD
ASL
ASL
                                                                 R2,RO
000022
         006300
                                                                 RO
                                                                                                                                                    3141
000024
000026
000032
         006300
                                                                 RO
                                                                RO, SEED
         010037
                                                       MOV
                  001154
                                                                                                                                                    3142
         062737
                  000004 001154'
                                                       ADD
                                                                 44 SEED
000040
000042
000046
000052
         010346
                                                       MOV
                                                                 R3, -(SP)
                                                                                                                                                    3143
         012746
                  000004
                                                                 44, -(SP)
                                                       MOV
         004737
                                                       JSR
MOV
                  000000G
                                                                PC.BL DIV
         013702
                  001154
                                                                 SEED, R2
000056
         060200
                                                       ADD
                                                                 R2.RO
```

000060 010037 001156' MOV RO.NEXT.RANDNUM 000064 010003 MOV RO.R3 000066 010361 000000G MOV R3.RANDOM(R1)	83 16:12:07 83 16:12:00	VAX-11 Bliss-16 V3-555 Page DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (22)	75
000072 022626 000074 062701 000002 000100 020127 000036 000104 003744 000106 000207 CMP (SP)+,(SP)+ ADD #2,R1 CMP R1,#36 BLE 1\$ RTS PC		: *,*(COUNT) : *,COUNT 31: : COUNT,*	44 41 40

<sup>:</sup> Routine Size: 36 words. Routine Base: \$CODE\$ + 7602 : Maximum stack depth per invocation: 7 words

```
ZRQAM3
                   RD/RX EXERCISER
                                                                            14-Dec-1983 16:12:07
                                                                                                         VAX-11 Bliss-16 V3-555 Page 76
DISK*USER2:[DIETZ.RDRX]ZRQACO.BL2:161 (23)
                                                                                                         VAX-11 Bliss-16 V3-555
V01.2
                   MULTI-DRIVE TEST ROUTINES
                                                                            14-Dec-1983 16:12:00
            3148 routine QIO_UNIT : novalue =
            3149
            3150 !+
            3151
                            THIS ROUTINE IS CALLED BY QIO_GEN TO SELECT ONE UNIT
                            CONFIGURED UNDER THE CURRENT CONTROLLER (CCTLR) TO BE USED FOR THE CURRENT QIO OR QIO PAIR. THE UNIT SELECTED IS BASED ON THE NUMBER OF UNITS ELIGIBLE TO RECEIVE AN I/O REQUEST (FROM 1 TO 4). IF A "YES"
            3152
            3153
            3154
            3155
                            ANSWER IS GIVEN FOR THE RANDOM UNIT MODE THE UNITS WILL BE PICKED AT
            3156
                            RANDOM. IF NOT THEN THE UNITS WILL BE PICKED IN A SEQUENTIAL ORDER.
            3157
            3158
                            IMPLICIT IMPUTS:
            3159
                                      CST_ADDR - ADDRESS OF CURRENT CONTROLLER'S CST
            3160
                            IMPLICIT OUTPUTS:
            3161
                                      THE RD/RX DISK NUMBER (DISK ADDRESS) IS LOADED INTO THE
            3162
            3163
                                                APPROPRIATE FIELD OF BOTH MSCP PACKETS.
            3164
                   ! -
            3165
            3166
                  begin
.
            3167
:
            3168
                            RAT_COUNT : word initial (0);
.
            3169
                        local
.
            3170
                                        : word,
                            MOD_COUNT : byte.
            3171
                            TBL_COUNT : byte.
            3172
                            SELECT_RD : byte;
            3173
            3174
            3175 MOD_COUNT = 0:
                                                                            ! find out if there is a unit online
            3176
            3177
                   incr OFFSET from (0 + OF_UN) to (3 + UNIT_SIZE + OF_UN) by UNIT_SIZE do
            3178
                       if (.CST_ADDR [.OFFSET, D_PRES] eql PRESENT) and
(.CST_ADDR [.OFFSET, D_STAT] eql ONLINE) and
(not .CST_ADDR [.OFFSET, D_FATAL])
            3179
            3180
            3181
            3182
                        then
            3183
                            begin
MOD_COUNT = .MOD_COUNT + 1;
            3184
            3185
            3186
            3187
                   if .MOD_COUNT eal 0
                                                                           ! IF no units on line then END OF PASS
            3188
                   then
            3189
                        begin
EOP_FLAG = TRUE:
            3190
            3191
                        return;
            3192
                        end:
            3193
            3194
            3195 if ((.SMP_FLAGS and SMF_UNT) neg SMF_UNT)
                                                                                      !check if sequential mode 0 = SEQUENTIAL. 1 = RANDOM
            3196 then
                                                                                      ! SEQUENTIAL UNIT MODE
            3197
                       begin
            3198
                        do
            3199
:
                            if (.BST_DEV eql 0)
                                                                                      ! IF sequential device is unit 0
                            then
            3200
```

```
SEQ 0332
ZRQAM3
                     RD/RX EXERCISER
                                                                                   14-Dec-1983 16:12:07
                                                                                                                   VAX-11 Bliss-16 V3-555 Page 77 DISK$USER2: [DIETZ.RDRX]ZRQACO.BL2;161 (23)
                                                                                                                   VAX-11 Bliss-16 V3-555
V01.2
                     MULTI-DRIVE TEST ROUTINES
                                                                                   14-Dec-1983 16:12:00
                                         BST_DEV = MAX_DRIVES - 1
                                                                                              ! Make it one less then max drive # or 3
             3202
                               else
.
             3203
                                         BST_DEV - .BST_DEV - 1
                                                                                            ! else just subtract 1 from current device
             3204
                         until (.CST_ADDR [.BST_DEV * UNIT_SIZE + OF_UN, D_PRES] eql PRESENT) and (.CST_ADDR [.BST_DEV * UNIT_SIZE + OF_UN, D_STAT] eql ONLINE) and (not .CST_ADDR [.BST_DEV * UNIT_SIZE + OF_UN, D_FATAL]);
SET_UPAR (.BST_DEV * UNIT_SIZE + OF_UN);
MAD1 [DK_NUM] = .CST_ADDR [.CUOFF, D_DISK_NUM];
             3205
                                                                                                                              ! do until find a unit online
             3206
             3207
3208
:
2
                                                                                                                              ! set up characterictics
             3209
                                                                                                                                                   ! drop in command pa
cket
             3210
                          MAD2 [DK_NUM] = .CST_ADDR [.CUOFF, D_DISK_NUM];
             3211
                          return:
                                                                                                                              !proceed to next routine
             3212
                          end
             3213
                    else
             3214
                          begin
             3215
             3216
                    ! RANDOM SELECTION OF DRIVES
             3217 !
             3218 !
                               this part selects the device by the ratio
             3219
             3220
                          rat_count = .rat_count + 1;
                                                                                                         ! increment counter from 0 to 100
                          if (.rat_count geq 100) then rat_count = 0;
if (.rat_count les .sup_rat)
             3221
                                                                                                        ! in case counter gets to large reinit to 0
             3222
             3223
                          then
             3224
                               SELECT RD - true
                                                                                                                   ! if counter greater than swap ratio then do
    rx-50
 .
             3225
                                                                                                                   ! and reiniate the counter
             3226
3227
                               SELECT_RD - felse:
                                                                                                                   ! if counter less than ratio do a rd-51
             3228
                          if (100 eql .swp_rat)
                                                                                                                   ! if ratio equal 100 do rd
             3229
                          then
             3230
                               SELECT_RD = true:
             3231
             3232
3233
3234
                          if (0 eql .swp_rat)
:
                                                                                                                   ! if ratio equals 0 do rx
.
                               SELECT_RD - FALSE:
             3235
             3236
                       IF ROSIS SELECTED
             3237
             3238
                       COUNT NUMBER OF RDs AVAILABLE
             3239
             3240
                          if .SELECT_RD
             3241
                          then
             3242
             3243
3244
3245
3246
3247
3248
                                                                                              ! COUNT THE NUMBER OF RDs IN THE SYSTEM
                                incr OFFSET from (0 + OF_UN) to (3 + UNIT_SIZE + OF_UN) by UNIT_SIZE do
                                     if (.CST_ADDR [.OFFSET, D_PRES] eql PRESENT) and
  (.CST_ADDR [.OFFSET, D_STAT] eql ONLINE) and
  (.CST_ADDR [.OFFSET, D_TYPE] neq RX_50) and
  (not .CST_ADDR [.OFFSET, D_FATAL])
             3249
             3250
                                     then
             3251
3252
                                          STORAGE [.MOD_COUNT] - .OFFSET;
             3253
                                          MOD_COUNT = .MOD_COUNT + 1;
```

```
ZRQAM3
                       RD/RX EXERCISER
                                                                                              14-Dec-1983 16:12:07
                                                                                                                                 VAX-11 Bliss-16 V3-555 Page 78 DISK*USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (23)
                       MULTI-DRIVE TEST ROUTINES
V01.2
                                                                                              14-Dec-1983 16:12:00
                                              end:
              3255
3256
                       ! SELECT ONE OF THE RD51s
              3257
3258
                                   if .MOD_COUNT neg 0
                                                                                                        ! IF AT LEAST ONE RD51 PRESENT
               3259
                                   then
               3260
               3261
                                               X = ((.RANDOM [.TBL_COUNT] and #0'77777') mod .MOD_COUNT);
              3262
3263
3264
3265
                                               SET_UPAR (.STORAGE [.X]);
MAD1 [DK_NUM] = .CST_ADDR [.CUOFF, D_DISK_NUM];
MAD2 [DK_NUM] = .CST_ADDR [.CUOFF, D_DISK_NUM];
                                               return:
               3266
                                               end:
               3267
                                   end
               3268
                             else
               3269
               3270
                       ! IF NO RD51 SELECTED, SELECT AN RX50
               3271
               3272
                       ! COUNT THE NUMBER OF RX50s
               3273 !
.
               3274
                                   begin
MOD_COUNT = 0;
               3275
                                                                                                         ! COUNT THE NUMBER OF RXs IN THE SYSTEM
                                   incr OFFSET from (0 + OF_UN) to (3 + UNIT_SIZE + OF_UN) by UNIT_SIZE do
               3276
               3277
                                         if (.CST_ADDR [.OFFSET, D_PRES] eql PRESENT) and
(.CST_ADDR [.OFFSET, D_STAT] eql ONLINE) and
(.CST_ADDR [.OFFSET, D_TYPE] eql RX_50) and
(not .CST_ADDR [.OFFSET, D_FATAL])
               3278
               3279
               3280
               3281
               3282
3283
                                              begin
STORAGE [.MOD_COUNT] = .OFFSET;
MOD_COUNT = .MOD_COUNT + 1;
               3284
               3285
               3286
               3287
3288
3289
                       ! AND CHOOSE ONE OF THE RXs
               3290
               3291
3292
3293
3294
3295
3296
3297
3298
3299
3300
                                   if .MOD_COUNT neg 0
                                                                                                        ! IF AT LEAST ONE RD51 PRESENT
                                   then
                                               X = ((.RANDOM [.TBL_COUNT] and #0'77777') mod .MOD_COUNT);

SET_UPAR (.STORAGE [.X]);

MAD1 [DK_NUM] = .CST_ADDR [.CUOFF, D_DISK_NUM];

MAD2 [DK_NUM] = .CST_ADDR [.CUOFF, D_DISK_NUM];
                                               return:
                                               end:
                                   end:
               3301
               3302
               3303
               3304
                       ! IF NO UNIT SELECTED SO FAR BY ABOVE METHOD, SELECT ANY ONE AT RANDOM
               3305
               3306
                       ! COUNT ALL UNITS AVAILABLE
```

```
SEQ 0334
                                                                           ZRQAM3
                  RD/RX EXERCISER
V01.2
                  MULTI-DRIVE TEST ROUTINES
            3307 !
            3308
                       MOD_COUNT = 0:
                                                                                   ! COUNT THE NUMBER OF ONLINE UNITS IN THE SYSTEM
.
                       incr OFFSET from (0 + OF_UN) to (3 * UNIT_SIZE + OF_UN) by UNIT_SIZE do
            3309
2
            3310
.
                            if (.CST_ADDR [.OFFSET, D_PRES] eq1 PRESENT) and
  (.CST_ADDR [.OFFSET, D_STAT] eq1 ONLINE) and
  (not .CST_ADDR [.OFFSET, D_FATAL])
            3311
            3312
            3313
.
            3314
                            then
.
                                     begin
STORAGE [.MOD_COUNT] = .OFFSET;
MOD_COUNT = .MOD_COUNT + 1;
            3315
.
            3316
:
            3317
.
            3318
                                     end:
.
            3319
.
            3320
.
            3321 ! AND CHOOSE ONE OF THEM
.
            3322 !
.
            3323
                                                           ! IF AT LEAST ONE RD51 PRESENT
                       if .MOD_COUNT neg 0
.
            3324
            3325
                            begin
                            X = ((.RANDOM [.TBL_COUNT] and #0'77777') mod .MOD_COUNT);

SET_UPAR (.STORAGE [.X]);

MAD1 [DK_NUM] = .CST_ADDR [.CUOFF, D_DISK_NUM];

MAD2 [DK_NUM] = .CST_ADDR [.CUOFF, D_DISK_NUM];
            3326
            3327
3328
3329
.
            3330
                            return:
:
            3331
                            end:
.
            3332
            3333 EOP_FLAG - TRUE;
                                                                           !JUST IN CASE NO UNITS ONLINE
.
            3334
                  end:
                                                                           ! ROUTINE QIO UNIT
.
001160
                                                         .PSECT #GGG#, RO
001160 000000
                                               RAT. COUNT:
                                                                 0
                                                         . SBTTL
                                                                 QIO.UNIT MULTI-DRIVE TEST ROUTINES
007712
                                                         .PSECT
                                                                 *CODE*, RO
000000 004137 000000G
                                               QIO.UNIT:
                                                        JSR
                                                                  R1. $SAVE4
                                                                                                                                                       3148
000004 105002
                                                        CLRB
                                                                                                       : MOD.COUNT
                                                                                                                                                       3175
000006
        013703
                  000000G
                                                                  CST. ADDR, R3
                                                                                                                                                       3179
000012 012700
                  000006
                                                                  46,RO
                                                        MOV
                                                                                                       . .OFFSET
                                                                                                                                                       3177
000016
        010001
                                                        MOV
                                              18:
                                                                  RO,R1
                                                                                                       : OFFSET. *
                                                                                                                                                       3179
000020
         060301
                                                                  R3.R1
000020
000022
000026
000030
         032711
                  040000
                                                        BIT
                                                                  440000 (R1)
         001407
                                                        BEQ
         032711
                                                                  #20000,(R1)
                  020000
                                                        BIT
                                                                                                                                                       3180
000034
         001404
                                                        BEQ
000036
         032711
                  010000
                                                        BIT
                                                                  #10000,(R1)
                                                                                                                                                       3181
000042
         001001
000044
         105202
                                                                  R2
                                                                                                       # MOD. COUNT
                                                                                                                                                       3184
```

						LIV		
ZRQAM3 VO1.2		RD/RX EX	XERCISER RIVE TEST	ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK#USER2:[DIETZ.RDRX]ZRQACO	SEQ 0335 Page 80 .BL2;161 (23)
000046 000052 000056	062700 020027 003757	000016 000060		2\$:	ADD CMP BLE	#16.RO RO.#60 1\$	: *,OFFSET : OFFSET.*	3177
000060 000062 000064 000070 000076	105702	010664			TSTB BNE JMP	R2 3# 23#	MOD.COUNT	3187 3190
000070	000137 032737 001072	000002	00000G	3#:	BIT	#2.SWP.FLAGS		3195
000100	013701	001142'		41:	MOV	BST.DEV,R1 R1	•	3199
000106 000110	001004 012737	000003	001142'		BNE MOV BR	5\$ #3.8ST.DEV 6\$		3201
000116 000120 000124	000402 005337 013701	001142		5#: 6#:	DEC	BST.DEV BST.DEV.R1 R1,-(SP) #7,-(SP)		3199 3203 3205
000130 000132	010146 012746 004737	000007 000000G			MOV MOV JSR	R1,-(SP) #7,-(SP)		
000142 000144	010004 022626	000000			MOV	PC.BL#MUL RO.R4 (SP)+,(SP)+		
000124 000130 000132 000136 000142 000144 000150 000152 000156 000162 000164 000170	010004 022626 006300 060300 062700	000006			ASL ADD ADD	R0 R3.R0 #6.R0		
000156 000162	032710	040000			BIT BEQ BIT	040000,(RO)		
000164	032710 001745 032710 001342	020000			BIT BEQ BIT	#20000,(RO)	•	3206
000176	010446	010000			BNE	#10000,(RO) 4# R4,-(SP)		3207 3208
000172 000176 000200 000202 000206 000212	062716 004737	000003 000000G			ADD JSR	#3,(SP) PC,SET.UPAR		
000222	013700 013701 006301	0001041 000000G			MOV MOV ASL	MAD1,RO CUOFF,R1 R1		3209
000224	063701 111160 042760	000000G 000016 177774			MOVB	CST.ADDR.R1 (R1),16(R0) #177774,16(R0)		
000234 000242 000246 000252 000260 000262 000264 000270 000276	013700	000016	000016		BIC MOV MOVB	MAD2.RO (R1),16(RO)		3210
000252 000260	111160 042760 005726 000207	177774	000016		BIC	#177774,16(RO) (SP)+ PC		3195
000264 000270	005237 023727 002402 005037	001160	000144	76:	RTS INC CMP	RAT.COUNT RAT.COUNT, #144		3197 3220 3221
000276 000300 000304	002402 005037 013701	001160°			BLT	84 RAT.COUNT		
000310 000314	023701 002003	001160		84:	MOV CMP BGE	SWP.RAT,R1 RAT.COUNT,R1 9#		3222
000316	112700 000401	000001			MOVB BR	#1.R0 10\$ R0	. *,SELECT.RD	3224 3222
000324	105000			96:	CLRB	NO .	; SELECT.RD	3226

M10

ZRQAM3 V01.2		RD/RX EXERCISER MULTI-DRIVE TEST R	OUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO	SEQ 0336 Page 81 .BL2;161 (23)
000326 000332 000334 000340 000342 000346 000350 000352 000354 000360 000362	020127	000144	10\$:	CMP BNE	R1.#144 11\$		3228
000334	112700	000001		MOVB	#1,R0	; *, SELECT.RD	3230
000340	005701		11\$:	TST	R1	1	3232
000342	001001			BNE	12\$		0200
000344	105000 105002 006000 103037			CLRB	RO	: SELECT.RD : MOD.COUNT : SELECT.RD	3234
000546	105002		12\$:	CLRB	R2	; MOD.COUNT	3243
000350	103037			ROR BCC	RO	; SELECT.RD	3240
000354	012701	000003		MOV	16\$ #3,R1	. A DEESET	7044
000360	010100	000003	13#:	MOV	R1.R0	: *,OFFSET : OFFSET,*	3244 3246
000362	006300			ASL	RO	, 0,, 3,, ,	3240
000364	060300 032710			ADD	R3.R0		
000364 000366 000372 000374	032710	040000		BIT	#40000,(RO)		
000372	001417 032710	*****		BEQ	148		
000374	032/10	020000		BIT	#20000,(RO)		3247
000400	001414	000034		BEQ	14\$ #34,(RO)		7046
000402 000406	001411	000034		BEG	146		3248
000410	032710	010000		BEQ	#10000,(RO)		3249
000414 000416	001006			BNE	144		3247
000416	001006 005000 150200 006300			CLR	RO		3252
000420	150200			BISB	R2,R0	: MOD.COUNT.*	
000420 000422 000424	006300			ASL	RO		
000424	010160 105202	0000641		MOV	R1.STORAGE(RO)	; OFFSET, 4	
000430	062701	000007	148:	INCB	R2	: OFFSET,* : MOD.COUNT : *.OFFSET : OFFSET,*	3253
000436	020127	000030	144:	ADD	#7,R1 R1,#30	: #,UFFSET	3244
000442	003746	000000		BLE	13#	; UFF 3E1, 4	
000430 000432 000436 000442 000444 000450	062701 020127 003746 105702 001436		15#:	TSTB	R2	; MOD.COUNT	3258
000446	001436			BEQ	19#		
000450	000472	*****		BR	221	1	3261
000452 000456	012701	000003	16#:	MOV	#3,R1	: *,OFFSET : OFFSET,*	3276
000460	010100		17#:	MOV	R1.RO RO	; OFFSET,*	3278
000462	060300			ADD	R3,R0		
000464	032710	040000		BIT	#40000,(RO)		
000470	001417 032710 001414 132710 001011 032710			BEQ	18#		
000472	032710	020000		BEQ	#20000,(RO)		3279
000476	001414			BEQ	18# #34,(RO)		
000500	132710	000034		BITB	#34,(RO)		3280
000506	032710	010000		BNE	184		7004
000512	001006	010000		BIT	#10000,(RO) 18#		3281
000514	005000			CLR	RO		3284
000516	150200			CLR BISB	R2,R0	MOD.COUNT.4	320-
000520	001006 005000 150200 006300 010160 105202 062701 020127			ASL	RO		
000522	010160	0000641		MOV	R1,STORAGE(RO)	; OFFSET, *	
000526	105202	000007		INCB	R2	; MOD.COUNT	3285
000534	020127	000007 000030	18#:	ADD	97.R1	; *,OFFSET	3276
000472 000476 000500 000504 000516 000514 000516 000520 000522 000526 000530 000534	003746	000030		BLE	R1.#30	: OFFSET.4	
000542	000740			BR	176 156		7201
				0	• • • • • • • • • • • • • • • • • • • •		3291

R I	/1	^
N	1	( )
1 4		

ZRQAM3 VO1.2		RD/RX EXERCISER MULTI-DRIVE TES	T ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACG	SEQ 0337 Page 82 0.BL2;161 (23)
000544 000546 000552 000554	105002	000003	19\$:	CLRB	R2	# MOD.COUNT # ,OFFSET # OFFSET,#	3308
000546	012701	000003		MOV	#3,R1	; *, OFFSET	3309
000552	010100 006300		20\$:	MOV	R1,R0	; OFFSET,*	3311
000554	063700	0000000		ASL	RO COT ADDO DO		
000553	032710	000000G 040000		ADD	CST.ADDR,RO		
000566	001414	040000		BIT	#40000,(RO) 21\$		
000570	032710	020000		BIT	#20000,(RO)		7740
000556 000562 000566 000570 000574	001414 032710 001411 032710 001006 005000 150200	020000		BEQ	21\$		3312
000576	032710	010000		BIT	#10000,(RO)		3313
000602 000604 000606	001006			BIT	214		3313
000604	005000			CLR	RO		3316
000606	150200			BISB	R2.R0	: MOD.COUNT.*	0010
000610	UUDSUU			ASL	RO		
000612	010160 105202 062701 020127	0000641		MOV	R1,STORAGE(RO)	; OFFSET.* ; MOD.COUNT	
000616	105202	000007	***	INCB	R2	; MOD.COUNT	3317
000620	002/01	000007	21#:	ADD	#7.R1	; *,OFFSET	3309
000630	003750	000030		CMP	R1.430	: OFFSET.*	
000612 000616 000620 000624 000630 000632 000634 000640 000640 000650 000654 000656 000660 000666	105702			BLE	20\$ R2	MOD COUNT	
000634	001446			BEQ	274	: MOD.COUNT	3323
000636	105702 001446 005000 150400 006300 016046		22#:	CLR	23¢ R0		7706
000640	150400		CCV.	BISB	R4.RO	TBL.COUNT.*	3326
000642	006300			ASL	RO	; IBL.COOKI,+	
000644	016046	000000G		MOV	RANDOM(RO), -(SP)		
000650	042/16	100000		BIC	#100000.(SP)		
000654	005046			CLR	RANDOM(RO),-(SP) #100000,(SP) -(SP) R2,(SP)		
000656	110216			CLR	R2.(SP)	; MOD.COUNT, #	
000660	004737	000000G		JSR	PC.BL #MOD RO.R3		
000666	110216 004737 010003 006300			MOV	RO,R3	; *,X	
000670	016016	0000644		ASL	RO	1	3327
000674	004737	0000641 000000G		MOV	STORAGE(RO),(SP)		
000700	013700	0001041		JSR MOV	PC.SET.UPAR MAD1.RO		
000704	004737 013700 013701 006301	000000G		MOV	CUOFF.R1	1	3328
000710	006301	***************************************		ASL	R1		
000712	063701	000000G		ADD	CST. ADDR. R1		
000716	111160	000016		MOVB	CST.ADDR,R1 (R1),16(R0)		
000722	042760	177774 000016		BIC	#177774,16(RO)		
000730	013700	000106'		MOV	MAD2.RO		3329
000734	111160	000016		MOVB	(R1),16(R0)		
000740	111160 042760 022626 000207	177774 000016		BIC	#177774,16(RO)		
000746	0000007			CMP	(SP)+,(SP)+	1	3323
000752	112737	000001 000000G	224	RTS	PC	•	3325
000760	000207	000001 000000G	234:	MOVB	#1.EOP.FLAG		3333
	300201			HIS			3148
: Routi	ne Size:	249 words,	Routine Base:	*CODE*	7712		

<sup>:</sup> Routine Size: 249 words, Routine Base: #CODE# + 7712 : Maximum stack depth per invocation: 8 words

```
SEQ 0338
ZRQAM3
                          RD/RX EXERCISER
                                                                                                         14-Dec-1983 16:12:07
                                                                                                                                                VAX-11 Bliss-16 V3-555 Page 83
DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (24)
                                                                                                                                                VAX-11 Bliss-16 V3-555
V01.2
                          MULTI-DRIVE TEST ROUTINES
                                                                                                         14-Dec-1983 16:12:00
                3335 routine QIO_FUNC : novalue .
                 3336
                 3337
                                        THIS ROUTINE IS CALLED BY QIO_GEN TO SELECT THE I/O FUNCTION (OPCODE)
                 3338
                 3339
                                       TO BE USED FOR THE CURRENT GIO OR GIO PAIR. THE FUNCTION IS DETERMINED
                 3340
                                       BY THE FOLLWING ALGORITHM:
                 3341
                 3342
                                                     IF THE CHOSEN UNIT IS PROTECTED
                 3343
                                                     THEN
                 3344
                                                                 FUNCTION - READ
                 3345
                                                    ELSE (UNPROTECTED)
                 3346
                                                                 FUNCTION (WRITE OR READ) IS BASED ON A RANDOM
                 3347
                 3348
                                       IN ADDITION, IF THE OPERATOR SELECTED THE OPTION OF PERFORMING WRITE-COMPARES AT THE HOST, AND IF A "WRITE" FUNCTION WAS CHOSEN ABOVE FOR THE FIRST QIO, THEN A "READ" OPCODE IS LOADED INTO THE SECOND MSCP ENVELOPE. OTHERWISE, THE SECOND MSCP ENVELOPE IS RETURNED TO THE POOL.
                 3349
                 3350
                 3351
                 3352
                 3353
                 3354
                                        THIS ROUTINE ALSO DECIDES WHEATHER IT IS TIME TO RUN THE DUP EXERCISER.
                                       THE EXERCISER WRITES 25 LBNS FOR EVERY 1 DBN. FOR INITIALIZATION REASONS THE MULTIPLE OF 25 LBNS CAN BE READ FOR 1 * MULTIPLE OF DBNS.
                 3355
                 3356
                                       DUP EXERCISER WRITES X BLOCKS PER PASS THRU THE DUP ROUTINE. THERFORE THE RATIO OF 1 TO 25 MUST BE MULTIPLIED BY X FOR A RATIO OF 1 TO
                 3357
                 3358
                                        25 . X. SO EVERY 25.X LBN'S READ OFF A WINCHESTER UNIT X DBN'S WILL
                 3359
                                      BE READ IF ASKED BY THE USER. X is represented by the VARIABLE "DUPROUND".

DUPROUND MAY BE CHANGED IN THE SOFTWARE QUESTION GIVEN AT THE START OF
RUNNING THE EXERCISER PROGARM. THE DUP EXERCISER THEN REINITIALIZES
THE CONTROLLER AND CONTINUES AS IF THE REGULAR MSCP EXERCISER WAS
NEVER INTERRUPTED. NOTE THAT THE REINITIALIZATION PROCESSES TAKES
A COUPLE OF SECONDS WHICH ONCE ADDED UP AFTER A COUPLE MILLION READS
CAN PROVE TO BE QUITE TIMELY. THERFORE I SUGGEST THAT IF A LARGE AMOUNT OF
I/O TRANFERS ARE TO BE DONE THE "DUPROUND" VARIABLE BE RAISED TO SPEED UP
                 3360
:
                 3361
                 3362
                 3363
                 3364
                 3365
                 3366
                 3367
                 3368
                                       UP THE PROCESS.
                 3369
                 3370
                                       IMPLICIT IMPUTS:
                 3371
                                                    CST_ADDR - ADDRESS OF CURRENT CONTROLLER'S CST
                 3372
                                                    CUOFF - CURRENT UNIT CST OFFSET
                 3373
                 3374
                                       IMPLICIT OUTPUTS:
                 3375
                                                     THE OPCODE FIELD OF ONE OR BOTH MSCP ENVELOPES IS LOADED.
                 3376 !-
                 3377
                 3378
                                begin
                 3379
                 3380
                 3381
                                       FUNC : word;
                                                                                                         ! OPCODE (READ OR WRITE)
                          !PRINTX (DER9);
                 3382
                 3383
                                 DUOFF . . CUOFF;
:
                                                                                                         !TEMPERARILY STORE VALUE INCASE ANOTHER COMMANDS LEFT IN QUEUE
                                IF ((.CST_ADDR (.DUOFF + 6, D_COUNT) LEQ 0) AND (.CST_ADDR (.DUOFF, D_TYPE) NEQ RX_50) AND (.CST_ADDR (.DUOFF + 5, NODUPMEDIA) NEQ 1))
                 3384
:
                                                                                                                                   ! IF MSCP FUNC CNT EQUAL TO O !IF WINCHESTER DISK
                 3385
8
```

!IF NODUPMEDIA FLAG BIT IS CLEAR

3386

3387

```
SEQ 0339
ZRQAM3
               RD/RX EXERCISER
                                                              14-Dec-1983 16:12:07
                                                                                     VAX-11 Bliss-16 V3-555
                                                              14-Dec-1983 16:12:07 VAX-11 Bliss-16 V3-555 Page 84 14-Dec-1983 16:12:00 DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (24)
V01.2
               MULTI-DRIVE TEST ROUTINES
         3388
                               BEGIN
                               PUT_PKT (.MX2):
         3389
                                                                      ! RETURN 2nd ENVELOPE TO POOL
         3390
                               MX2 = -1:
                                                                      ! INDICATE FAILURE
                               DUP ():
         3391
                                                                      ! DO DUP TEST
         3392
                               !PRINTX (DBM111):
                                                                      ! PRINT MSCP EXERCISER REINIT
         3393
                               CST_ADDR [.DUOFF + 6, D_COUNT] = (25 + .dupround);
                                                                                     ! REINITIALIZE MSCP FUNC COUNTER
         3394
              ! ********* SO THE MSCP EXERCISER CAN
         3395
         3396
         3397
         3398
                               DUP_FLAGS = .DUP_FLAGS OR SWP_DINT;
                                                                             ! SET DUP INIT FLAG
                               INIT_TEST ();
                                                                              ! THIS REINITIALIZES THE CONTROLLER FOR MSCP MODE
         3399
                               DUP_FLAGS = . DUP_FLAGS AND (NOT SWP_DINT);
         3400
                                                                              ! CLEAR DUP INIT FLAG
         3401
         3402
                               MX2 = -1:
                                                                             ! ASSUME FAILURE IN SECURING 2ND ENVELOPE
         3403
                               IF (MX1 . GET_PKT (.CCTLR)) LSS 0
                                                                              ! TRY TO GET 1ST ENVELOPE.
         3404
                                      OR (.EOP_FLAG)
                                                                              ! IF FAILURE
         3405
                                      RETURN:
                                                                             ! NO POINT IN CONTINUING
                               IF (MX2 = GET_PKT (.CCTLR)) LSS 0
OR (.EOP_FLAG)
         3406
                                                                             ! TRY TO GET 2ND ENVELOPE.
         3407
                                                                             ! IF FAILURE
         3408
                               THEN
                                       BEGIN
         3409
                                       PUT_PKT (.MX1):
                                                                             ! RETURN 1ST ENVELOPE TO POOL
         3410
                                      MX1 - -1:
                                                                                     ! INDICATE FAILURE
         3411
                                      RETURN:
         3412
                                      END:
         3413
         3414
                               MAD1 - MSCP_PKT + (.MX1 + PKT_LEN + 2);
MAD2 - MSCP_PKT + (.MX2 + PKT_LEN + 2);
                                                                             ! CALCULATE STARTING ADDRESSES
         3415
                                                                                   OF BOTH ENVELOPES
         3416
                               GET_RANDOM ():
                                                                              ! GENERATE A SET OF RANDOM NUMBERS
         3417
3418
3419
                               QIO_UNIT ():
                                                                              ! LOAD RANDOM UNIT NUMBER INTO ENVELOPES
                               END:
         3420
               3421
                                      START OF ROUTINE MSCP
         3422
               3423
         3424
                   CST_ADDR [.CUOFF + 6, D_COUNT] . .CST_ADDR [.CUOFF + 6, D_COUNT] - 1: ! DECREMENT MSCP FUNC COUNTER
         3425
         3426
                   MAD2 [OPCODE] = 0:
                                                              ! ASSUME 2ND PACKET NOT NEEDED
         3427
         3428
                   if .CST_ADDR [.CUOFF. D_PROT] eq1 PROTECTED ! IF UNIT IS PROTECTED
         3429
                   then
         3430
3431
                       FUNC - OP_RD
                                                              ! SET FUNCTION TO READ
                   else
         3432
3433
3434
                       if (.RANDOM [1] and 1)
                                                              ! USE 2ND RANDOM NUMBER TO SELECT
         3435
                           FUNC - OP_RD
                                                                    READ
         3436
         3437
                           FUNC - OP_WRT;
                                                                    WRITE
         3438
         3439
                   if (MAD1 [OPCODE] . FUNC) eq1 OP_WRT
                                                              ! LOAD CHOSEN OPCODE. IF WRITE
         3440
```

then

```
SEQ 0340
ZRQAM3
                 RD/RX EXERCISER
                                                                      14-Dec-1983 16:12:07
                                                                                                VAX-11 Bliss-16 V3-555 Page 85
DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (24)
V01.2
                 MULTI-DRIVE TEST ROUTINES
                                                                      14-Dec-1983 16:12:00
                          begin
MAD1 (CMD_TYPE) = NON_SEQ_CMD;
           3442
                                                                      ! NON-SEQUENTIAL COMMAND
           3443
           3444
                          IF BIT_TST (SWP_FLAGS, SWF_CWC)
                                                                      ! IF CONTROLLER DOES WRITE-COMPARES
           3445
                          then
           3446
                              MAD1 [MODIFY] - MD_CMP:
                                                                      ! ADD COMPARE MODIFIER
           3447
           3448
                          IF BIT_TST (SWP_FLAGS, SWF_HWC)
                                                                      ! IF HOST DOES WRITE-COMPARES
           3449
                          then
                              MAD2 [OPCODE] = OP_RD;
MAD2 [CMD_TYPE] = NON_SEQ_CMD;
           3450
           3451
                                                                      ! SET READ OPCODE INTO 2ND MSCP PACKET
           3452
                                                                      ! NON-SEQUENTIAL COMMAND
           3453
           3454
           3455
                          end
           3456
                      else
           3457
                          begin
           3458
                          MAD1 [CMD_TYPE] = NON_SEQ_CMD;
                                                                      ! NON-SEQUENTIAL COMMAND
           3459
           3460
                          if BIT_TST (SWP_FLAGS, SWF_CRC)
                                                                      ! IF CONTROLLER DOES READ-COMPARES - FUNCTION IS READ
           3461
           3462
                              MAD1 [MODIFY] - MD_CMP;
                                                                      ! ADD COMPARE MODIFIER
           3463
           3464
                          end;
.
           3465
           3466
                      if .MAD2 [OPCODE] eql 0
                                                                      ! IF NO OPCODE IN 2ND PACKET
           3467
                      then
           3468
                          begin
PUT_PKT (.MX2);
.
           3469
3470
                                                                      ! RETURN 2ND PACKET TO POOL
.
                          MX2 = -1:
                                                                      ! MARK IT UNUSED
.
           3471
.
                          end:
           3472
:
           3473
                      end:
                                                                      ! ROUTINE QIO_FUNC
                                                     .SBTTL QIO.FUNC MULTI-DRIVE TEST ROUTINES
000000 004137 000000G
                                            QIO.FUNC:
                                                             R1. #SAVE3
                                                     JSR
                                                                                                                                             3335
000004
        013737
                 000000G 001150'
                                                     MOV
                                                              CUOFF, DUOFF
                                                                                                                                             3383
                                                                                                 .
000012
        013702
                 000000G
                                                             CST. ADDR, R2
DUOFF, R1
                                                     MOV
                                                                                                                                             3384
000016
        013701
                 001150
                                                     MOV
000022
        010100
                                                              R1.RO
                                                     MOV
000024
        006300
                                                     ASL
                                                             RO
000026
        060200
                                                     ADD
                                                             R2.RO
000030
        005760
                 000014
                                                     TST
                                                              14(RO)
000034
        003146
                                                     BGT
                                                              41
000036
        010100
                                                             R1.RO
                                                     MOV
                                                                                                                                             3385
000040
        006300
                                                     ASL
                                                             RO
000042
        060200
                                                     ADD
                                                             R2.RO
000044
         132710
                 000034
                                                     BITB
                                                             #34,(RO)
000050
        001540
                                                     BEQ
                                                             44
000052
        010100
                                                     MOV
                                                             R1.RO
                                                                                                                                             3386
000054
        006300
                                                     ASL
                                                             RO
```

	ZRQAM3		RD/RX FX	KERCISER			14-000-1983 16-12-07	VAV 11 01:00 16 UZ 555	SEQ 0341
	V01.2		MULTI-DE	RIVE TEST	ROUTINES		14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2	Page 86 ;161 (24)
-	000056 0	060200				ADD	R2,R0		
	000060 0	005760	000012			TST	12(RO)		
1	000064 1 000066 0	100532	000102			BMI	4\$		
1	000072	004737	000000G			MOV JSR	MX2,-(SP) PC,PUT.PKT		3389
1	000076 0	012737	177777	0001021		MOV	0-1,MX2		3390
1	000104 0	004737	000000V			JSR	PC.DUP		3391
	000110 0	006301	001150			MOV	DUOFF,R1		3393
1	000116	63701	000000G			ASL	R1 CST.ADDR.R1		
	000122 0	013716	000000G			MOV	DUPROUND.(SP)		
1	000126	12746	000031			MOV	#31,-(SP)		
1	000132 0	004737	000000G 000014			JSR MOV	PC.BL#MUL		
1	000136 000142	010061 052737	000002	000000G		BIS	RO,14(R1) #2.DUP.FLAGS		3398
	000150 0	004737	0002701			JSR	PC.INIT.TEST		3399
1	000154 0	042737	000002 177777	000000G		BIC	#2.DUP.FLAGS		3400
-	000170	012737	000000G	000105,		MOV	#2.DUP.FLAGS PC.INIT.TEST #2.DUP.FLAGS #-1.MX2 CCTLR.(SP)		3402
1	000174 0	013716 004737	000000G			JSR	PC.GET.PKT		3403
-	000200	010037	0001001			MOV	RO,MX1		
-	000170 000174 000200 000204 000206 1	010037 002426 132737	000001	000000G		BLT	24		
1	000214	001022	000001	000000		BITB	#1,EOP.FLAG		3404
1	000216	013716 004737	000000G			MOV	CCTLR.(SP)		3335 3406
1	000555 0	004737	000000G			JSR	PC,GET.PKT		5.00
1	000228	010037 002404	000102			MOV BLT	RO.MX2		
	000234 1	L32737	000001	000000G		BITB	1,EOP.FLAG		3407
1	000242	001411				BEQ	34		3401
	000244 0	004737	000000G		1#:	MOV	MX1,(SP)		3409
	000254	012737	177777	0001001		JSR MOV	PC.PUT.PKT #-1,MX1		3410
-	000262 0	012737 022626 000207			24:	CMP	(SP)+,(SP)+		3406
1	000264 0	000207 013716	0001001			RTS	PC		3408
-		012746	000100		34:	MOV	MX1,(SP)	기가 된다고 말했다면 하는 그는 내가 되었다면 하다 하다.	3414
1	000276 0	004737	000000G			JSR	#104,-(SP) PC,BL#MUL		
	000302 0	062700	000000G			ADD	OMSCP.PKT,RO		
1	000306 0	062700 010037 013716	000104			MOV	RO, MAD1		
	000312 000316 000322	12746	000102			MOV	MX2,(SP) #104,-(SP)		3415
	000322	012746 004737	000104 000000G			JSR	PC.BL MUL		
-	000326 0	062700	000000G			ADD	PC.BL #MUL #MSCP.PKT,RO		Ber House Self
-	000336	010037 004737	0001061			MOV JSR	PC.GET.RANDOM		
-	000342 0	004737	007712'			JSR	PC.QIO.UNIT		3416 3417
-	000346	062706	000010			ADD	♦10,SP		3388
-	000325 0	013700 006300	000000G		46:	MOV	CUOFF, RO	•	3424
-	000360	063700	000000G			ASL	RO CST.ADDR.RO		
-	000364 0	005360	000014			DEC	14(RO)		
1	000370	013700	000106			MOV	MAD2,RO		3426
1									12 2 2 2

ZRQAM3 VO1.2		RD/RX EXERCISER MULTI-DRIVE TEST ROUT	INES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.	SEQ 0342 Page 87 BL2;161 (24)
000374	012703	000022		MOV	#22,R3		
000400	060003			ADD	RO,R3		
000402	105013 013700			CLRB	(R3)		
000404	013700	00000G		MOV	CUOFF,RO	1	3428
000410	006300 063700	000000G		ASL	RO		
000412 000416	032710	100000		BIT	CST.ADDR.RO #100000.(RO)		
000422 000424 000432 000434 000440 000442 000452	001404	000001 000002G 000041		BEQ	COUFF, RO RO CST. ADDR, RO #100000, (RO) 5# #1.RANDOM+2 6# #41.R1 7# #42,R1 MAD1,RO SWP.FLAGS,R2 R1.22(RO) R1.#42 9# #2.4(RO) #20,R2 8# #40000,24(RO) #40,R2 10# #41.(R3)		7470
000424	001404 032737	000001 000002G		BIT	#1.RANDOM+2		3430 3433
000432	001403 012701 000402 012701			BEQ	61		3433
000434	012701	000041	5#:	MOV	041,R1	: *,FUNC	3435
000440	000402	*****		BR	76	1	3433
000442	013700	000042	68:	MOV	#42.R1	: *,FUNC	3437
000452	013702	000000G	/*:	MOV	MADI.RO SWP.FLAGS.R2	•	3439
000456	110160	000042 0001041 000000G 000022 000042		MOVB	R1,22(R0)	FUNC.4	3444
000462	110160 020127	000022 000042		CMP	R1,042	FUNC.4	3439
000466	001024			BNE	91	1 1010,-	
000456 000462 000466 000470 000476 000502 000504 000512 000516 000520 000524 000536 000546 000552 000554 000564 000566 000572	001024 012760 032702	000002 000004		MOV	#2,4(RO)		3442
000476	032702	000020		BIT	#20,R2		3444
000502	001403 012760 032702 001421	040000 000004		BEQ	81		
000504	012760	040000 000024 000040		MOV	440000,24(RO)		3446
000516	001421	000040	8#:	BIT	040,R2 10\$	•	3448
000520	112713	000041		MOVB	441,(R3)		7451
000524	013701	000106'		MOV	MAD2.R1		3451 3452
000530	112713 013701 012761 000411 012760	000002 000004		MOV	MAD2,R1 #2,4(R1)		3436
000536	000411			BR	10#		3439
000546	012760	000002 000004 000004	9#:	MOV	42.4(RO)		3458
000552	001403	000004		BIT	44,R2		3460
000554	032702 001403 012760 105713 001010	040000 000024		MOV	108 #40000,24(RO)	그렇게 하는 사람이 되는 것이 되었다.	7440
000562	105713	0.0000	104:	TSTB	(R3)		3462 3466
000564	001010			BNE	116		3400
000566	013746	0001021		MOV	MX2,-(SP)		3469
000572	004737	000000G		JSR	PC.PUT.PKT		
000576 000604	012737	000102' 000000G 177777 000102'		MOV	0-1,MX2		3470
000606	005726		114.	TST	(SP)+		3468
000000	000201		114:	RTS	PC	•	3335
; Routi	ine Size:	196 words. Routing depth per invocation:	ne Base: 9 words	*CODE*	• 10674		

```
ZRQAM3
                    RD/RX EXERCISER
                                                                                  14-Dec-1983 16:12:07
                                                                                                                 DISK#USER2:[DIETZ.RDRX]ZRQACO.BL2:161 (25)
                                                                                                                 VAX-11 Bliss-16 V3-555
V01.2
                    MULTI-DRIVE TEST ROUTINES
                                                                                  14-Dec-1983 16:12:00
             3474 !+
             3475
             3476
                    ROUTINE DUP : NOVALUE .
             3477
             3478
                               THIS ROUTINE IS CALLED BY QIO_FUNC AFTER 25 * "DUPROUND" RD/WTS .
THIS EXERCISER WAS PLACED IN THE MIDDLE OF THE MSCP EXERCISER SO A
             3479
             3480
                               COMMON INITIALIZATION AND OTHER ROUTINES COULD BE USED
             3481
                                         THE DUP EXCERSIZER WILL RUN A READ ONLY OR A WRITE/READ COMPARE
             3482
                               TO THE DIAGONOSTIC BLOCKS OR DBN'S. IT WILL RECORD
             3483
                               THE STATICS IN THE TALLY TABLES.
             3484
                               THE PROGRAM USES CONTROLLER LOCAL PROGRAMS TO WRITE AND READ THE DBN'S. WHEN WRITTING TO THE DBN'S A ONE WORD PATTERN WILL BE SELECTED
             3485
             3486
                              AND COPY TO A 256 WORD BLOCK, THE ROUTINE WILL WRITE TO "DUPROUND" AMOUNT OF DBN SEQUENTIAL BLOCKS. IF A THERE ARE CONTROLLER LOCAL PROGRAMS AND IF THE USER SO DESIRES A WRITE AND READ OF EACH BLOCK AND A COMPARISON TO THE DATA PATTERN WILL BE GIVEN TO TEST FOR FAULTY DBN'S. IF THE USER DOES NOT WANT TO WRITE TO THE DBN'S ONLY A READ WILL BE GIVEN AND NO COMPARISON WILL BE DONE. THE BAD BLOCKS FOUND IN THE COMPARISON TEST WILL NOT BE LISTED IN THE RCT TABLES.
             3487
             3488
             3489
             3490
             3491
             3492
             3493
             3494
             3495
                               AFTER THE EXERCISER HAS EXAMINE "DUPROUND" AMOUNT OF BLOCKS IT WILL
             3496
                               REINITIATE THE ENVOLOPES SO THAT THE MSCP EXERCISER MAY CONTINUE AS
             3497
                               BEFORE.
            3498
             3499
3500
                               IMPLICIT IMPUTS:
                                         CCTLR - CURRENT CONTROLLER NUMBER
             3501
                                         CST_ADDRS - CONTAINS THE CURRENT CONTROLLER STATUS TABLE
             3502
                                                       - CURRENT OFFSET IN CST TABLE FOR PARTICULAR DRIVE
             3503
             3504
                               IMPLICIT OUTPUTS:
             3505
                                         S_PATTERN - PATTERN BEING WRITTEN TO AND READ FROM DBN'S
             3506
             3507
                    BEGIN
             3508
                    OWN
             3509
                               TEMP : WORD:
             3510
             3511
                     !PRINTX (DBM110);
             3512
                    !PRINTX (DER10):
             3513
             3514
                    until (.CRN_LOW eqlu .RP_ADDR (CRF_LO)) or
                                                                                  ! TO ENSURE THAT ALL RETURN MESSAGES HAVE BEEN PROCESSED
             3515
                            (.EOP_FLAG eql true) do
                                                                                   ! Make sure all MSCP commands are completed
                         begin
BREAK;
             3516
             3517
                                                                                     BREAK FOR ACT
             3518
                          PROC_RETPKT();
                                                                                     PROCESS RETURN PACKET TO SEE IF OK FOR DUP
                         3519
             3520
             3521
3522
3523
                          end:
             3524
             3525
                    S_PATTERN = .RANDOM [1];
                                                                                             !OTHER UNIT VARIABLES
             3526
```

A-Dec-1983 16:12:00   VAX-11 Blie-16 V3-555   Page 80   Page 1985   Page 198									
1   3528   THEN (CST_ADDR [.DUOFF + 5, D_DBN] = 0];   CIRCLE ARROUND IF DBN TO LARGE			RD/RX EXERCISES MULTI-DRIVE TE	R ST ROUTINES		14-Dec-198 14-Dec-198	3 16:12:07 VAX 3 16:12:00 DIS	-11 Bliss-16 V3-555 K\$USER2:[DIETZ.RDRX]ZRQACO	SEQ 0344 Page 89 .BL2;161 (25)
3530   DUPDLE ();   10 A GET DUST STAINS TO FIND IF LOCAL DUP NEDIA   1 3533   IF . CST. ADDR [.DUOFF + 5, D.DRN]   1 1 3533   IFP - S.T. ADDR [.DUOFF + 5, D.DRN]   1 3533   INCR DRINCT FROM (.TEMP + .) TO (.TEMP + .dupround) DO		3528	IF (.CST_ADDR THEN (CST_ADDR	(.DUOFF + 5, D_DE	BN) + .du	pround) GEQ 144 !	TEST TO SEE IF NE	XT DBN'S TO LARGE DBN TO LARGE	
3533   IRCR OBNCNT FROM LTRPH -1) TO LTEPH - 10 TO LTEPH -10 TO LTEP		3530 3531	DUPIDLE (): IF .CST_ADDR [	.DUOFF + 5, NODUF	PMEDIA) E	QL 1 THEN RETURN; !	OO A GET DUST STA	TUS TO FIND IF LOCAL DUP MI IA NOT THERE THEN RETURN	EDIA
3535 BEGIN   F. CST_ADDR (.DUOFF + 5, DUPWRITE)   ! IF WRITE FLAG SET IN CST TABLE THEN WRITE		3533	TEMPCST_ADI	DR [.DUOFF + 5, [ OM (.TEMP + 1) TO	D_DBN);	.dupround) DO	! !	NCREMENT FROM RELATIVE DBN	TO DBN + dupro
3537	:			T_ADDR [.DUOFF +	5. DUPWR	ITE)	! 1	F WRITE FLAG SET IN CST TA	BLE THEN WRITE
3540   DUPNETOBN ()	:	3538	THEN				! M	AKE SURE THE CONTROLLER IS	IN AN IDLE STA
SSA4	TE :	3541					! 0	ALL ROUTINE TO HANDLE WRIT	TING ROUTINES
3546   ST_ADDR [.DUOFF + 5, D_DBN] = .CST_ADDR [.DUOFF + 5, D_DBN] + 1; ! INCREMENT RELATIVE DBN COUNTER 3549   IF .CST_ADDR [.DUOFF + 5, D_DBR] + 1; ! INCREMENT RELATIVE DBN COUNTER 3549   IF .CST_ADDR [.DUOFF + 5, DUPERROR] EQL 1   ! ERROR IN DUP REINITIALIZE   AND RETURN   END;   END;		3543 3544	DUPIDLI DUPRED	E (); DBN ();					
### 3548		3546	CST_AD	DR [.DUOFF + 5, 1	D_DBN] -	.CST_ADDR [.DUOFF +	5. D_DBN] + 1; !	INCREMENT RELATIVE DBN CO	UNTER
001162 001162  TEMP: .BLKM 1  .PSECT		3548 3549 3550	THEN R	T_ADDR [.DUOFF + ETURN;	5, DUPER	ROR) EQL 1			
000000 004137 000000G				TEMP:					
000004 013700 00000G 00000G 10 10 10 10 10 10 10 10 10 10 10 10 10	011504						ST ROUTINES		
000072 062700 000000G ADD #RÉTPKT.RO 000076 010037 000000G MOV RO.RP.ADDR	000004	004137 013700 023760	000000G 000000G 000000G 000004	18:	MOV	CRN.LOW,4(RO)	:		3476 3514
000072 062700 000000G ADD #RÉTPKT.RO 000076 010037 000000G MOV RO.RP.ADDR	000020	123727 001427	000000G 000001		CHPB	EOP.FLAG. #1			3515
000072 062700 000000G ADD #RÉTPKT.RO 000076 010037 000000G MOV RO.RP.ADDR	000032	004737	000000V		JSR	PC.PROC.RETPKT	- :		3516 3518
000072 062700 000000G ADD #RÉTPKT.RO 000076 010037 000000G MOV RO.RP.ADDR	000036	005237	000000G 000000G 000004		INC	RP.INDX RP.INDX,#4			3519 3520
HOY RO, RP. ADDR	000012	062700	00000G 00000G 00000G	24:	CLR MOV MOV JSR ADD	RP.INDX RP.INDX,-(SP) 460,-(SP) PC.BL#MUL #RETPKT.RO			
	000102	022626	0000006		CMP	RO, RP. ADDR			3516

	RD/RX EXERCISER MULTI-DRIVE TEST ROU	TINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK*USER2:[DIETZ.RDRX]ZRQACO.B	SEQ 0345 Page 90 L2;161 (25)
000737			BR	16		3514
013737	000002G 000000G	3\$:	MOV			3525
013700	001150'		MOV	DUOFF, RO		3527
006300				RO		
063700	000000G		ADD			
005001	*****		CLR			
156001	000012		BISB	12(R0),R1		
003/01	0000006		AUU			
000157	000220					
105060	000012		CLDD			7500
004737	000000V	44.	ISP	PC DUPTOLE		3528
013700	001150	77.		DUOFF BO		3530 3531
006300	***************************************			RO		2221
063700	000000G					
005760	000012		TST	12(RO)		
100456			BMI	8#		
116037	000015 001165,		MOVB	12(RO), TEMP		3533
105037	001163'		CLRB	TEMP+1		
013702	001162'		MOV	TEMP,R2		3534
063702	000000G		ADD	DUPROUND, R2		
013700	001150'		MOV	DUOFF, RO		3536
006300	0000000		ASL	RO		
063700	0000006		ADD	CST.ADDR,RO		
060703	000013			NO. RS		
013701	000012		MOV	TEMP DI	- A DOMONT	7074
000427	001105				; *,UBNUNI	3534
032713	010000	54.				3536
001404	010000	34.	REQ			3330
004737	000000V		JSR		교육하는 그들은 화학 등 경기를 다 보다 다니다.	3539
004737	000000V		JSR	PC.DUPWRTDBN		3540
004737	000000V	61:	JSR	PC.DUPIDLE		3543
004737	OC:0000A		JSR	PC, DUPREDDBN		3544
013700	001150'			DUOFF,RO		3546
	******		ASL			
063700	000000G		ADD	CST.ADDR,RO		
062703	000012		MUV	NO, RS		
105213	000015		TNCD	ATC' K2		
032713	040000		BIT			7540
001003	J. 5000		BNE			3548
005201		74.	TNC		DRINCHT	3549 3534
020102			CMP	R1.R2	DRNCNT.	3334
003746			BLE	54	, conciti t	
000207		84:	RTS	PC		3476
	105060 004737 013700 006300 063700 005760 100456 116037 105037 013702 063702 013700 006300 063700 010003 062703 013701 000427 032713 001404 004737	MULTI-DRIVE TEST ROU  000737 013737 000002G 000000G 013700 001150' 006300 063700 00000G 020127 000220 002402 105060 000012 004737 000000V 013700 001150' 006300 063700 00000G 005760 000012 100456 116037 000163' 013702 001162' 063702 000000G 013700 001150' 006300 063700 00000G 013700 001150' 006300 063700 00000G 013701 001162' 003746	MULTI-DRIVE TEST ROUTINES  000737 013737 000002G 000000G 013700 001150' 0063700 00000G 020127 000220 002127 000220 004737 000000V 004737 00000V 005760 00012 100456 116037 00012 105037 001163' 013702 001162' 063702 00000G 013700 001150' 006300 063700 001150' 006300 063700 001162' 063702 00000G 013700 001162' 003703 00012 013701 001162' 003704 004737 00000V	MULTI-DRIVE TEST ROUTINES   BR   MOV   M	RD/RX EXERCISER   14-Dec-1983 16:12:00	RD/RX EXERCISER MULTI-ORIVE TEST ROUTINES  14-Dec-1983 16:12:07

```
SEQ 0346
                      RD/RX EXERCISER
                                                                                         14-Dec-1983 16:12:07 VAX-11 Bliss-16 V3-555 Page 9
14-Dec-1983 16:12:00 DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (26)
ZRQAM3
                                                                                                                                                                                 Page 91
V01.2
                      MULTI-DRIVE TEST ROUTINES
              3553 ROUTINE DUPWRTDBN : NOVALUE .
              3554
2
               3555
                     THIS ROUTINE IS CALLED BY DUP ROUTINE TO USE THE CONTROLLER LOCAL PROGRAM
"WRTDBN". TO USE THE PROGRAM THE OPTIONAL DUP SUB-PROTOCAL IS USED TO
COMMUNICATE WITH THE CONTROLLER. THE PROGRAM WRITES TO A DIAGONOSTIC BLOCK (DBN)
THE WORD IN "S_PATTERN" IS WRITTEN TO THE 256 WORDS IN THE DBN. IF AN ERROR OCCURS
WHILE RUNNING THE CONTROLLER LOCAL PROGRAM THE ERROR IS USSUALLY REPORTED IN THE
               3556
               3557 !
               3558
               3559
.
               3560
.
               3561
                       ! DUP BUFFER. (EX. ILLEGAL UNIT NUMBER, ILLEGAL BLK 4, DEVICE ERROR, ZERO LENGHT MSG)
.
               3562
               3563
                                  IMPLICIT INPUTS:
               3564 !
                                              CST_ADDRS - CONTAINS THE CURRENT CONTROLLER STATUS TABLE
               3565
                                                              - CURRENT OFFSET IN CST TABLE FOR PARTICULAR DRIVE
               3566
                                              S_PATTERN - CONTAINS PATTERN WORD! -
.
              3567
3568
3569
                      BEGIN
.
                       !PRINTX (DER11):
.
                      T_ADDR [T_DBN_WT] = .T_ADDR [T_DBN_WT] + 1; ! INCREMENT # OF WRITES GIVEN
.
               3570
:
              3571 MSCP_PKT [.MX1, MSGLEN] = SZ_ELP;
                                                                                           ! PACKET SIZE
                                                                                                                                                      EXECUTE LOCAL PROGRAM WRT DB
              3572 MSCP_PKT [.MX1, OPCODE] = OP_ELP;
3573 MSCP_PKT [.MX1, L1] = #eecii'W';
3574 MSCP_PKT [.MX1, L2] = #eecii'R';
.
                                                                                           ! OPCODE - EXECUTE LOCAL PROGRAM
                                                                                            ! FILL IN PROGRAM NAME WITH ASCII LETTERS
.
              3575 MSCP_PKT [.MX1, L3] = #eeci'T';
3576 MSCP_PKT [.MX1, L4] = #eeci'D';
3577 MSCP_PKT [.MX1, L5] = #eeci'B';
3578 MSCP_PKT [.MX1, L6] = #eeci'N';
3579 MSCP_PKT [.MX1, L6] = #eeci'N';
                     MSCP_PKT [.MX1, MODIFY] = 1;
MSCP_PKT [.MX1, MSGTYP] = IMM_CMD;
DUPCOMMAND ();
                                                                                            ! STANDALONE MODIFIER
               3579
               3580
3581
                                                                                            ! CALL IT IMMEDIATE
                                                                                            ! SENDS AND RECEIVES THE COMMAND
               3582
               3583
                      IF .CST_ADDR [.DUOFF + 5, DUPERROR] EQL 1
                                                                                            !status error
               3584
                      THEN RETURN;
.
               3585
               3586 DO (MX1 - GET_PKT (.CCTLR))
               3587 UNTIL (.MX1 GEQ 0);
                                                                                 ! TRY TO GET AN ENVELOPE. IF FAILURE LOOP PRG ERROR
               3588
                                  MSCP_PKT [.MX1, MSGLEN] = SZ_REC;
MSCP_PKT [.MX1, OPCODE] = OP_RCD;
MSCP_PKT [.MX1, BC_LO] = 80;
               3589
:
                                                                                                        ! PACKET SIZE
                                                                                                                                                                  RECIEVE DATA
               3590
                                                                                                        ! OPCODE - RECEIVE DATA
.
                                                                                                        ! BYTE COUNT TO BE TRANSFERED EQUALS 2 ***see pg 26 of DUP s
               3591
pec
                                  MSCP_PKT [.MX1, BUF_0] = DUPPKT;

MSCP_PKT [.MX1, MODIFY] = 0;

MSCP_PKT [.MX1, MSGTYP] = SEQ_CMD;

DUPCOMMAND ();
               3592
                                                                                                        ! LOAD DESCRIBTOR BUFFER
               3593
                                                                                                        CALL IT sequential SENDS AND RECEIVES THE COMMAND
               3594
.
               3595
:
               3596
8
               3597
                                   IF (.CST_ADDR (.DUOFF + 5, DUPERROR) EQL 1) OR !status error
                                       (.DUPPKT (DUPTYPE) NEQU 1) OR
(.DUPPKT (DUPMESG) NEQU 6)
               3598
                                                                                                        !dup type error
               3599
               3600
               3601
                                              (HARD_ERROR ():
               3602
                                                CST_ADDR [.DUOFF + 5, DUPERROR] = 1; ! SET FLAG
               3603
                                                                                                        ! NO POINT IN CONTINUING
                                                RETURN: ):
8
               3604
.
                                  DO (MX1 - GET_PKT (.CCTLR))
```

```
SEQ 0347
                                                                                      ZRQAM3
                      RD/RX EXERCISER
                      MULTI-DRIVE TEST ROUTINES
V01.2
              3606
                                 UNTIL (.MX1 GEQ 0):
                                                                                                   ! TRY TO GET AN ENVELOPE. IF FAILURE LOOP PRG ERROR
              3607
                                MSCP_PKT [.MX1, MSGLEN] = SZ_SEN;
MSCP_PKT [.MX1, OPCODE] = OP_SDD;
MSCP_PKT [.MX1, BC_LO] = 6;
MSCP_PKT [.MX1, BUF_O] = DUPPKT;
DUPPKT [DUPBFO] = .CST_ADDR [.DUOFF, D_DISK_NUM]; !LOAD UNIT NUMBER (RDRX)
DUPPKT [DUPBF1] = .CST_ADDR [.DUOFF + 5, D_DBN]; !LOAD DBN NUMBER
DUPPKT [DUPBF2] = .S_PATTERN;
MSCP_PKT [.MX1, MODIFY] = 0;
MSCP_PKT [.MX1, MSGTYP] = SEQ_CMD;
DUPCOMMAND (); ! CALL IT sequential
SENDS AND RECEIVES THE COMMAND
.
              3608
2
              3609
.
                                                                                                   ! BYTE COUNT TO BE TRANSFERED EQUALS 6
              3610
              3611
              3612
              3613
              3614
.
              3615
:
              3616
:
              3617
.
              3618
:
              3619
                                 IF .CST_ADDR [.DUOFF + 5, DUPERROR] EQL 1
.
                                                                                                 ! status error
              3620
                                 THEN RETURN:
.
              3621
3622
:
                                 DO (MX1 - GET_PKT (.CCTLR))
.
              3623
                                                                                     ! TRY TO GET AN ENVELOPE. IF FAILURE LOOP PRG ERROR
                                 UNTIL (.MX1 GEQ 0):
.
              3624
.
                                 MSCP_PKT [.MX1, MSGLEN] = SZ_REC;

MSCP_PKT [.MX1, OPCODE] = OP_RCD;

MSCP_PKT [.MX1, BC_LO] = 4;

MSCP_PKT [.MX1, BUF_O] = DUPPKT;

MSCP_PKT [.MX1, MODIFY] = 0;

MSCP_PKT [.MX1, MSGTYP] = SEQ_CMD;
              3625
                                                                                                    ! PACKET SIZE
:
                                                                                                                                                           RECEIVE DATA
              3626
                                                                                                   ! OPCODE - RECEIVE DATA
! BYTE COUNT TO BE TRANSFERED EQUALS 4
              3627
.
              3628
3629
                                                                                                ! LOAD DESCRIBTOR BUFFER
.
:
              3630
3631
                                                                                               ! CALL IT sequential ! SENDS AND RECEIVES THE COMMAND
:
                                 DUPCOMMAND ():
.
              3632
.
                                 IF (.CST_ADDR [.DUOFF + 5, DUPERROR] EQL 1) or (.DUPPKT [DUPTYPE] NEQU 3) or (.DUPPKT [DUPMESG] NEQU 3) or (.DUPPKT [DUPBF1] NEQU 0) !non successful
              3633
.
              3634
.
                                                                                                   !dup type error
              3635
.
              3636
.
                                                                                           !non successful write code
              3637
.
              3638
                                            (HARD_ERROR ():
:
                                             CST_ADDR [.DUOFF + 5, DUPERROR] = 1; ! SET FLAG
RETURN;);
              3639
.
              3640
                                                                                                   ! NO POINT IN CONTINUING
.
              3641
:
              3642 DO (MX1 = GET_PKT (.CCTLR))
:
              3643 UNTIL (.MX1 GEQ 0);
                                                                                      ! TRY TO GET AN ENVELOPE.
.
              3644
.
              3645
3646
                     T_ADDR [T_BLK_WT] = .T_ADDR [T_BLK_WT] + 1; !INCREMENT COUNTER IF A SUCCESS
.
.
              3647 END:
.
                                                                   SBTTL DUPWRTDBN MULTI-DRIVE TEST ROUTINES
000000 010146
                                                       DUPWRTDBN:
                                                                              R1.-(SP)
                                                                                                                                                                                  3553
000002 013700
                      000000G
                                                                              T. ADDR, RO
                                                                  MOV
                                                                                                                                                                                  3569
000006
           005260
                      000052
                                                                  INC
                                                                              52(RO)
000012
                                                                             MX1,-(SP)
          013746
                      000100
                                                                  MOV
                                                                                                                                                                                  3571
000016
          012746
                      000104
                                                                  MOV
          004737
                      000000G
000022
                                                                   JSR
                                                                             PC, BL #MUL
000026 012760
                      000022 000006G
                                                                              #22, MSCP . PKT+6(RO)
```

TOOLANT		00 /0V EV	-				SE	Q 0348
ZRQAM3 VO1.2		RD/RX EX	CERCISER OTUE TEST	ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555	Page 93
		110212-01	1246 1631	ROOTENES		14-060-1903 10:12:00	DISK*USER2: [DIETZ.RDRX]ZRQACO.BL2;1	61 (26)
000034	112760	000003	000022G		MOVB	#3,MSCP.PKT+22(RO)		3572
000042	112760	000127	000026G		MOVB	#127.MSCP.PKT+26(RO)		3573
000050	112760		000027G		MOVB	#122,MSCP.PKT+27(RO)		3574
000056	112760	000124	000030G		MOVB	#124.MSCP.PKT+30(RO)		3575
000064	112760	000104	000031G		MOVB	#104,MSCP.PKT+31(RO)		3576
000072	112760	000102	000032G		MOVB	#102.MSCP.PKT+32(RO)		3577
000064 000072 000100	112760 012760	000116	000033G		MOVB	#116,MSCP.PKT+33(R0) #1,MSCP.PKT+24(R0) #360,MSCP.PKT+10(R0)		3578
000106	012760	000001	000024G		MOV	#1.MSCP.PKT+24(RO)		3579
000114	142760	000360	000010G		BICB	4360.MSCP.PKT+10(RO)		3580
000122	004737	000000V			JSR	PC, DUPCOMMAND		3581
000126	013700	001150			MOV	DUOFF, RO		3583
000132	006300				ASL	RO		-
000134	063700	000000G			ADD	CST.ADDR,RO		
000140	032760	040000	000012		BIT	440000,12(R0)		
000146	001402				BEQ	16		
000150	022626				CMP	(SP)+,(SP)+		3553
000152 000154	000505				BR	3#		3584
000154	013716	000000G		1\$:	MOV	CCTLR,(SP)		3586
000160	004737	000000G			JSR	PC.GET.PKT		
000164 000170	010037	0001001			MOV	RO,MX1		
000170	010037 002771 010016				BLT	16		3587
000172	010016				MOV	RO,(SP)		3589
000174	012746	000104			MOV	#104,-(SP) PC,BL#MUL		
000200	004737	000000G			JSR	PC,BL#MUL		
000204	012760	000034	000006G		MOV	#34,MSCP.PKT+6(RO)		
000200 000204 000212 000220 000226 000234 000240 000254 000260 000264	112760 012760	000005	000022G		MOVB	#5.MSCP.PKT+22(R0) #120.MSCP.PKT+26(R0)		3590
000220	012760	000120 000000G	0000266		MOV	#120,MSCP.PKT+26(RO)		3591
000226	012760	000000G	0000326		MOV	#DUPPKT, MSCP.PKT+32(RO) MSCP.PKT+24(RO) #360, MSCP.PKT+10(RO)		3592
000234	005060 142760	000024G 000360	0000100		CLR	MSCP.PKT+24(RO)		3593
000246	152760	000020	000010G		BICB	#360, MSCP. PKT+10(RO)		3594
000254	152760 004737	000000V	000010G		BISB	#20, MSCP. PKT+10(R0)		2505
000250	013700	001150			JSR	PC, DUPCOMMAND		3595
000264	006300	001130			MOV	DUOFF,RO		3597
000266	006300 063700	000000G			ADD	RO CST.ADDR,RO		
000272	032760	040000	000012		BIT	#40000,12(RO)		
000300	001016	010000	OOOOTE		BNE	24		
000700	017700	000000G			MOV	DUPPKT,RO		3598
000306	042700	007777			BIC	♦7777.RO		3390
000312	020027	010000			BIC CMP BNE	RO.#10000		
000316	001007				BNE	24		
000320	013700	000000G			MOV	DUPPKT, RO		3599
000324	042700	000000G 170000			BIC	#170000,R0		00,,,
000330	020027	000006			BIC	RO, #6		
000334	001415				BEQ	41		
000312 000316 000320 000324 000336 000336 000342 000346 000350 000354	013700 042700 020027 001007 013700 042700 020027 001415 004737 013700 006300 063700 052760	000000V		24:	BEQ JSR	PC, HARD. ERROR		3601
000342	013700	001150			MOV	DUOFF, RO		3602
000346	006300				ASL	RO		
000350	063700	000000G			ADD	CST. ADDR, RO		
000354	052760	040000	000012		BIS	#40000,12(R0)		
00000E	A05 100	000006			ADD	46.SP		3597
000366 000370	000504			34: 44:	BR	5#		3601
	013716	000000G			MOV	CCTLR,(SP)		3605

## M11

ZRQAM3 VO1.2		RD/RX EXERCISER MULTI-DRIVE TEST RO	UTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 PEDISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2:161	noe 94
000374	004737	00000G		JSR	PC,GET.PKT		
000400	010037	000100'		MOV	RO.MX1		
000404	002771			BLT	41		3606
000406	010016			MOV	RO,(SP)		3608
000410	012746	000104		MOV	#104,-(SP)		3000
000414	004737	00000G		JSR	PC.BL \$MUL		
000420	012760 112760	000034 000006G		MOV	#34.MSCP.PKT+6(RO)		
000426	112760	000004 000022G		MOVB	#4,MSCP.PKT+22(R0) #6,MSCP.PKT+26(R0) #DUPPKT,MSCP.PKT+32(R0)		3609
000434	012760	000006 000026G		MOV	96,MSCP.PKT+26(RO)	1	3610
000450	013701	000000G 000032G		MOV	900PPKT, MSCP. PKT+32(RO)		3611
000454	006301	001130		MOV	DUOFF,R1		3612
000456	006301 063701	000000G		ADD	R1 CST.ADDR,R1		
000456 000462	111137	00000G		MOVB	(R1),DUPPKT		
000466	042737	177774 000000G		BIC	#177774.DUPPKT		
000474	111137 042737 013701	001150'		MOV	DUOFF,R1		3613
000500 000502 000506 000514 000520 000526 000532 000540 000546 000552 000560 000564 000572	006301			ASL	R1		3013
000502	063701	00000G		ADD	CST.ADDR.R1		
000506	116137	000012 000002G		MOVB	12(R1),DUPPKT+2 DUPPKT+3		
000514	116137 105037 013737 005060 142760	000012 000002G 000003G 000000G 000004G		CLRB	DUPPKT+3		
000520	013737	000000G 000004G		MOV	S.PATTERN, DUPPKT+4		3614
000526	005060	000024G 000360 000010G		CLR	MSCP.PKT+24(RO) #360.MSCP.PKT+10(RO) #20.MSCP.PKT+10(RO)		3615
000532	152760	000360 000010G		BICB	#360,MSCP.PKT+10(R0)		3616
000546	152760	000020 000010G 000000V		BISB	#20,MSCP.PKT+10(R0)		
000552	013700	001150		JSR MOV	PC, DUPCOMMAND		3617
000556	004737 013700 006300 063700	001130		ASL	DUOFF, RO RO		3619
000560	063700	000000G		ADD	CST.ADDR,RO		
000564	032760	040000 000012		BIT	#40000,12(RO)		
000572	001403			BEQ	61		
000574	062706	000010		ADD	#10.SP		3553
000600 000606	000524 013716 004737		54:	BR	10\$		3620
000602	013716	000000G	6#:	MOV	CCTLR,(SP)		3622
000606	004737	00000G		JSR	PC,GET.PKT		
000612	010037 002771	000100'		MOV	RO, MX1		
000620	010016			BLT	61		3623
000622	012746	000104		MOV	RO.(SP)		3625
000626	004737	000000G		MOV JSR	#104,-(SP)		
000626 000632	012760	000034 000006G		MOV	PC.BL#MUL #34.MSCP.PKT+6(RO)		
000640	112760	000005 000022G		MOVB	45.MSCP.PKT+22(RO)		3626
000646	012760	000004 000026G		MOV	44.MSCP.PKT+26(RO)		3627
000640 000646 000654	012760	000000G 000032G		MOV	#4,MSCP.PKT+26(RO) #DUPPKT,MSCP.PKT+32(RO)		3628
000662 000666 000674	005060 142760	000024G		CLR	MSCP.PKT+24(RO)		3629
000666	142760	000360 000010G		BICB	#360,MSCP.PKT+10(RO) #20,MSCP.PKT+10(RO)		3630
000674	152760	000020 000010G		BISB	#20,MSCP.PKT+10(R0)		
000702	004737	000000V		JSR	PC, DUPCOMMAND		3631
000706 000712	013700	001150'		MOV	DUOFF, RO		3633
000714	006300 063700	000000G		ASL	RO		
000720	032760	040000 000012		ADD	CST.ADDR,RO		
000726	001021	ANON MAILE		BIT	#40000,12(RO)		
000730	013700	000000G		BNE	7\$ DUPPKT,RO		2020
				1101	DOFFINI INV		3634

NI	1	4
N	T	1

	ZRQAM3 VO1.2		RD/RX EXERCISER MULTI-DRIVE TEST ROUTE	NES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO	SEQ 0350 Page 95 .BL2;161 (26)
-	000734 000740 000744	042700 020027 001012	007777 030000		BIC CMP BNE	#7777.RO RO.#30000 7\$		
-	000746 000752 000756 000762	013700 042700 020027 001003	000000G 170000 000003		MOV BIC CMP BNE	DUPPKT.RO #170000.RO RO.#3 7\$	•	3635
-	000764	005737	000002G		TST	DUPPKT+2	•	3636
	000772 000776 001002 001004	004737 013700 006300 063700	000000V 001150' 000000G	7\$:	JSR MOV ASL ADD	PC, HARD. ERROR DUOFF, RO RO CST. ADDR, RO	:	3638 3639
-	001010 001016 001020 001024 001030	052760 000413 013716 004737 010037	040000 000012 000000G 000100'	8#:	BIS BR MOV JSR MOV	#40000,12(R0) 9# CCTLR,(SP) PC,GET.PKT R0,MX1	:	3633 3642
	001034 001036 001042	002771 013700 005260	000000G 000050		BLT MOV INC	8# T.ADDR.RO 50(RO)	:	3643 3645
-	001046 001052 001054	062706 012601 000207	000012	9\$: 10\$:	ADD MOV RTS	#12.SP (SP)+.R1 PC	:	3567 3553

<sup>:</sup> Routine Size: 279 words. Routine Base: #CODE# + 12040 : Maximum stack depth per invocation: 7 words

```
SEQ 0351
ZRQAM3
                     RD/RX EXERCISER
                                                                                   14-Dec-1983 16:12:07 VAX-11 Bliss-16 V3-555
                                                                                    14-Dec-1983 16:12:07 VAX-11 Bliss-16 V3-555 Page 96 14-Dec-1983 16:12:00 DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2:161 (27)
                     MULTI-DRIVE TEST ROUTINES
V01.2
             3648 ROUTINE DUPREDDBN : NOVALUE .
             3649
             3650 !+
                    ! THIS ROUTINE IS CALLED BY DUP ROUTINE TO USE THE CONTROLLER LOCAL PROGRAM
             3651
             3652
                    ! "REDDBN". TO USE THE PROGRAM THE OPTIONAL DUP SUB-PROTOCAL IS USED TO
                    COMMUNICATE WITH THE CONTROLLER. THE PROGRAM READS A DIAGONOSTIC BLOCK (DBN) AND PLACES IT IN THE DUP BUFFER CALLED "DUPPKT". IF AN ERROR OCCURS WHILE
             3653
             3654
                    ! RUNNING THE CONTROLLER LOCAL PROGRAM THE ERROR IS USSUALLY REPORTED IN THE
             3655
                    ! DUP BUFFER. (EX. ILLEGAL UNIT NUMBER, ILLEGAL BLK #, DEVICE ERROR, ZERO LENGHT MSG)
             3656
             3657
             3658
             3659
                               IMPLICIT INPUTS:
                                          CST_ADDR - CONTAINS THE CURRENT CONTROLLER STATUS TABLE
DUOFF - CURRENT OFFSET IN CST TABLE FOR PARTICULAR DE
             3660
             3661
                                                        - CURRENT OFFSET IN CST TABLE FOR PARTICULAR DRIVE
             3662
             3663
                    BEGIN
             3664
                     !PRINTX (DER12):
                    T_ADDR [T_DBN_RD] = .T_ADDR [T_DBN_RD] + 1; ! INCREMENT # OF READS GIVEN
             3665
             3666
             3667
                    MSCP_PKT [.MX1, MSGLEN] - SZ_ELP;
                                                                                    ! PACKET SIZE
                                                                                                                                          EXECUTE REDDBN PROGRAM
             3668 MSCP_PKT [.MX1, OPCODE] = OP_ELP;
                                                                                ! OPCODE - EXECUTE LOCAL PROGRAM
            3668 MSCP_PKT [.MX1, OPCODE] = OP_ELP;
3669 MSCP_PKT [.MX1, L1] = #eeci; R';
3670 MSCP_PKT [.MX1, L2] = #eeci; E';
3671 MSCP_PKT [.MX1, L3] = #eeci; D';
3672 MSCP_PKT [.MX1, L4] = #eeci; D';
3673 MSCP_PKT [.MX1, L4] = #eeci; B';
3674 MSCP_PKT [.MX1, L6] = #eeci; N';
3675 MSCP_PKT [.MX1, MODIFY] = 1;
3676 MSCP_PKT [.MX1, MSGTYP] = IMM_CMD;
3677 DUPCOMMAND ();
                                                                                     ! FILL IN PROGRAM NAME WITH ASCII LETTERS
                                                                                  ! STANDALONE MODIFIER
! CALL IT IMMEDIATE
             3677
                    DUPCOMMAND ():
                                                                                     ! SENDS AND RECEIVES THE COMMAND
             3678
             3679 IF .CST_ADDR [.DUOFF + 5, DUPERROR] EQL 1
                                                                                     !status error
             3680 THEN RETURN;
             3681
             3682
                    DO (MX1 = GET_PKT (.CCTLR))
             3683
                    UNTIL (.MX1 GEQ 0):
                                                                   ! TRY TO GET AN ENVELOPE. IF FAILURE LOOP PRG ERROR
             3684
                               MSCP_PKT [.MX1. MSGLEN] = SZ_REC;
MSCP_PKT [.MX1. OPCODE] = OP_RCD;
MSCP_PKT [.MX1. BC_LO] = 80;
             3685
                                                                                                ! PACKET SIZE
                                                                                                                                                     RECIEVE DATA
             3686
                                                                                               ! OPCODE . RECEIVE DATA
             3687
                                                                                                ! BYTE COUNT TO BE TRANSFERED EQUALS 2 *****see pg 26 DUP sp
ec
                               MSCP_PKT [.MX1, BUF_0] = DUPPKT;
MSCP_PKT [.MX1, MODIFY] = 0;
MSCP_PKT [.MX1, MSGTYP] = SEQ_CMD;
             3688
                                                                                              ! LOAD DESCRIBTOR BUFFER
             3689
             3690
                                                                                         ! CALL IT sequential
             3691
                                DUPCOMMAND ():
                                                                                                ! SENDS AND RECEIVES THE COMMAND
             3692
                               IF (.CST_ADDR [.DUOFF + 5, DUPERROR] EQL 1) OR !status error (.DUPPKT [DUPTYPE] NEQU 1) OR !dup type error (.DUPPKT [DUPMESG] NEQU 5)
             3693
             3694
                                                                                                !dup type error
             3695
:
             3696
:
                                          (HARD_ERROR ();
CST_ADDR (.DUOFF + 5, DUPERROR) = 1; ! SET FLAG
             3697
:
             3698
             3699
                                            RETURN; );
                                                                                                ! NO POINT IN CONTINUING
             3700
```

```
SEQ 0352
                    RD/RX EXERCISER

14-Dec-1983 16:12:07 VAX-11 Blies-16 V3-555 Page 9

MULTI-DRIVE TEST ROUTINES

14-Dec-1983 16:12:00 DISK*USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (27)
ZRQAM3
                                                                                                                                                          Page 97
V01.2
                               DO (MX1 - GET PKT (.CCTLR))
             3702
                               UNTIL (.MX1 GEQ O):
                                                                                           ! TRY TO GET AN ENVELOPE. IF FAILURE LOOP PRG ERROR
             3703
                              MSCP_PKT [.MX1, MSGLEN] = SZ_SEN; PACKET SIZE

MSCP_PKT [.MX1, OPCODE] = OP_SDD; OPCODE = SEND DATA

MSCP_PKT [.MX1, BC_LO] = 4; BYTE COUNT TO BE TRANSFERE

MSCP_PKT [.MX1, BUF_O] = DUPPKT; LOAD DESCRIBTOR BUFFER

DUPPKT [DUPBFO] = .CST_ADDR [.DUOFF, D_DISK_NUM]; LOAD UNIT NUMBER (RDRX)

DUPPKT [DUPBF1] = .CST_ADDR [.DUOFF + 5, D_DBN]; LOAD DBN NUMBER

MSCP_PKT [.MX1, MODIFY] = O;

MSCP_PKT [.MX1, MSGTYP] = SEQ_CMD; CALL IT sequential

DUPCOMMAND ();
             3704
                                                                                                                                                   SEND DATA
             3705
                                                                                             BYTE COUNT TO BE TRANSFERED EQUALS 4
             3706
             3707
             3708
             3709
             3710
             3711
                               DUPCOMMAND ():
                                                                                             ! SENDS AND RECEIVES THE COMMAND
             3712
             3713
             3714
                               IF .CST_ADDR [.DUOFF + 5, DUPERROR] EQL 1
                                                                                           !status error
                               THEN RETURN:
             3715
:
             3716
                               DO (MX1 - GET_PKT (.CCTLR))
             3717
                               UNTIL (.MX1 GEQ 0);
             3718
                                                                                 ! TRY TO GET AN ENVELOPE. IF FAILURE LOOP PRG ERROR
             3719
                               MSCP_PKT [.MX1. MSGLEN] = SZ_REC;

MSCP_PKT [.MX1. OPCODE] = OP_RCD;

MSCP_PKT [.MX1. BC_LO] = 514;

MSCP_PKT [.MX1. BUF_O] = DUPPKT;
             3720
                                                                                              ! PACKET SIZE
                                                                                                                                                   RECEIVE DATA
                                                                                              PCODE - GET DUST STATUS
             3721
             3722
                                                                                              ! BYTE COUNT TO BE TRANSFERED EQUALS 512
             3723
                                                                                              ! LOAD DESCRIBTOR BUFFER
                               MSCP_PKT [.MX1, MODĪFY] = 0;
MSCP_PKT [.MX1, MSGTYP] = SEQ_CMD;
DUPCOMMAND ();
             3724
             3725
                                                                                      ! CALL IT sequential
             3726
                                                                                              ! SENDS AND RECEIVES THE COMMAND
             3727
                               IF (.CST_ADDR [.DUOFF + 5, DUPERROR] EQL 1) OR !status error (.DUPPKT [DUPTYPE] NEQU 6) OR !dup type error (.DUPPKT [DUPMESG] NEQU 2)
             3728
             3729
                                                                                              !dup type error
             3730
             3731
                               THEN
             3732
                                          (HARD_ERROR ();
             3733
                                           CST_ADDR [.DUOFF + 5, DUPERROR] - 1; ! SET FLAG
             3734
                                           RETURN: ):
                                                                                              ! NO POINT IN CONTINUING
             3735
:
             3736 DO (MX1 - GET_PKT (.CCTLR))
:
             3737 UNTIL (.MX1 GEQ 0);
:
                                                                      ! TRY TO GET AN ENVELOPE. IF FAILURE LOOP PRG ERROR
             3738
.
             3739 T_ADDR [T_BLK_RD] - .T_ADDR [T_BLK_RD] + 1;
.
                                                                                           !IF DUP NO ERROR THEN INCREMENT COUNTER
             3740
:
            3741 END;
:
                                                               .SBTTL DUPREDOBN MULTI-DRIVE TEST ROUTINES
000000 010146
                                                    DUPREDOBN:
                                                                         R1,-(SP)
                                                               MOV
                                                                                                                                                                         3648
200000
          013700
                    000000G
                                                               MOV
                                                                         T. ADDR, RO
                                                                                                                                                                         3665
000006
          005260
                    000056
                                                               INC
                                                                         56(RO)
000012
          013746
                    0001001
                                                                         MX1, -(SP)
                                                               MOV
                                                                                                                                                                        3667
000016
          012746
                     000104
                                                                         #104.-(SP)
                                                               MOV
000022
          004737
                    000000G
                                                               JSR
                                                                         PC.BL SMUL
         012760
000026
                    000022 000006G
                                                              MOV
                                                                         #22, MSCP. PKT+6(RO)
000034
         112760
                    000003 000022G
                                                                         43, MSCP. PKT+22(RO)
                                                                                                                                                                         3668
```

	PROME		DD /DV E	VEDSTOCE					SEQ 0353
	ZRQAM3 VO1.2			XERCISER DIVE TEST	ROUTINES		14-Dec-1983 16:12:07	VAX-11 Bliss-16 V3-555	Page 98
	****		HOLIT-D	MINE IESI	HOUTTHES		14-Dec-1983 16:12:00	DISK \$USER2: (DIETZ.RDRX)ZRQACO.BL2	;161 (27)
	000042	112760	000122	000026G		MOVB	#122,MSCP.PKT+26(RO)		3669
	000050	112760	000105	000027G		MOVB	#105.MSCP.PKT+27(RO)		3670
	000056	112760	000104	000030G		MOVB	#104,MSCP.PKT+30(RO)		3671
	000064	112760	000104	000031G		MOVB	#104.MSCP.PKT+30(RO) #104.MSCP.PKT+31(RO)		3672
	000072	112760	000102	000032G		MOVB	#102,MSCP.PKT+32(RO)		3673
	000100	112760	000116	000033G		MOVB	#116,MSCP.PKT+33(RO)		3674
	000106	012760	000001	000024G		MOV	#1.MSCP.PKT+24(RO)		3675
	000114	142760	000360	000010G		BICB	#360, MSCP.PKT+10(RO)		3676
	000122	004737	000000V			JSR	PC.DUPCOMMAND		3677
	000126	013700	001150			MOV	DUOFF,RO		3679
	000132	006300	000000			ASL	RO		
	000134	063700	000000G			ADD	CST.ADDR,RO		
ŀ	000140 000146	032760	040000	000012		BIT	440000,12(RO)		
L	000150	001402				BEQ	16		
	000152	022626				CMP	(SP)+,(SP)+		3648
ì	000154	013716	000000G		18:	BR MOV	3\$ CCTI D (CD)		3680
1	000160	004737	000000G		1.	JSR	CCTLR.(SP)		3682
į.	000164	010037	000100			MOV	PC.GET.PKT RO.MX1		
1	000170	002771	000200			BLT	18		7/07
ŀ	000172	010016				MOV	RO.(SP)		3683
1	000174	012746	000104			MOV	#104,-(SP)		3685
1	000200	004737	000000G			JSR	PC.BL MUL		
l	000204	012760	000034	000006G		MOV	#34,MSCP.PKT+6(RO)		
l	000212	112760	000005	000022G		MOVB	45,MSCP.PKT+22(RO)		3686
Į.	000220	012760	000120	000026G		MOV	#120,MSCP.PKT+26(RO)		3687
1	000226	012760	000000G	000032G		MOV	#DUPPKT.MSCP.PKT+32(RO)		3688
	000234	005060	000024G			CLR	MSCP.PKT+24(RO)		3689
1	000240	142760	000360	000010G		BICB	#360.MSCP.PKT+10(RO)		3690
1	000246	152760	000020	000010G		BISB	#360,MSCP.PKT+10(R0) #20,MSCP.PKT+10(R0)		30.70
	000254 000260	004737	000000V			JSR	PC , DUPCOMMAND		3691
1	000260	013700	001150			MOV	DUOFF,RO		3693
1	000264	006300				ASL	RO		
1	000266 000272	063700	000000G			ADD	CST.ADDR,RO		
ì	000300	032760	040000	000012		BIT	440000,12(RO)		
1	000302	001016	000000			BNE	21		
l	000306	013700 042700	000000G			MOV	DUPPKT, RO		3694
-	000312	020027	010000			BIC	#7777,RO		i
ì	000312 000316	001007	010000			CMP	RO. #10000		
1	000320 000324 000330 000334 000342	013700	000000G			BNE	DUPPKT,RO		7405
Ī	000324	042700	170000			BIC	#170000.RO		3695
1	000330	020027	000005			CMP	RO.45		
	000334	001415				BEQ	46		
ŀ	000336	004737	000000V		28:	JSR	PC.HARD.ERROR		3697
	000342	013700	001150			MOV	DUOFF, RO		3698
	000346 000350	006300				ASL	RO		3070
-	000350	063700	000000G			ADD	CST.ADDR,RO		P. Carlotte
-	000354 000362	052760	040000	000012		BIS	#40000,12(R0)		
-	000362	062706	000006			ADD	46, SP		3693
1	000366	000501			34:	BR	54		3697
	000370	013716	000000G		44:	MOV	CCTLR,(SP)	사람들이 되었다. 그 아이들은 사람들이 있는데 없어 하는데 없다.	3701
	000374	004737	000000G			JSR	PC,GET.PKT		

					C12		
ZRQAM3		RD/RX EXERCISER			14-Dec-1987 16-12-07	VAV 11 D1: 16 V7 FFF	SEQ 0354
V01.2		MULTI-DRIVE TEST	ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL	Page 99 2;161 (27)
000400	010037	0001001		MOV	RO,MX1		
000404	002771			BLT	46		3702
000406	010016			MOV	RO,(SP)		3704
000410	012746	000104		MOV	#104,-(SP)		3704
000414	004737	000000G		JSR	PC.BL sMUL		
000420	012760	000034 000006G		MOV	PC.BL #MUL #34,MSCP.PKT+6(RO)		
000426	112760	000004 000022G		MOVB	44.MSCP.PKT+22(RO)		3705
000434	012760	000004 000026G		MOV	#4.MSCP.PKT+22(RO) #4.MSCP.PKT+26(RO)		3706
000434 000442 000450 000454 000456	012760 013701 006301 063701	000000G 000032G		MOV	#DUPPKT, MSCP.PKT+32(RO)		3707
000450	013701	001150'		MOV	DUOFF,R1		3708
000454	006301			ASL	R1		3100
000456	063701	000000G		ADD	CST. ADDR. R1		
000462	111137	00000G		MOVB	CST.ADDR.R1 (R1),DUPPKT		
000466	042737	177774 000000G		BIC	0177774.DUPPKT		
000474	042737 013701	001150'		MOV	#177774.DUPPKT DUOFF,R1		3709
000500	006301 063701			ASL	R1		0.00
000502	063701	00000G		ADD	CST.ADDR.R1 12(R1),DUPPKT+2 DUPPKT+3 MSCP.PKT+24(R0)		
000506	116137	000012 000002G		MOVB	12(R1), DUPPKT+2		
000514	105037	000003G		CLRB	DUPPKT+3		
000520	116137 105037 005060	000024G		CLR	MSCP.PKT+24(RO)		3710
000524	142760	000360 000010G		BICB	#360,MSCP.PKT+10(R0) #20,MSCP.PKT+10(R0)		3711
000532	152760	000020 000010G		BISB	#20,MSCP.PKT+10(R0)		
000540	152760 004737	000000V		JSR	PC, DUPCOMMAND		3712
000544	013700	001150'		MOV	DUOFF,RO		3714
000462 000466 000474 000500 000502 000506 000514 000520 000524 000532 000540 000550 000556 000564 000566 000572	013700 006300 063700			ASL	RO		
000552	063700	000000G		ADD	CST.ADDR,RO		
000556	032760 001403	040000 000012		BIT	040000,12(RO)		
000564	001403			BEQ	61		
000566	062706	000010		ADD	#10.SP	1	3648
000572	062706 000521 013716	0000000	54:	BR	108		3715
000600	004737	000000G	6\$:	MOV	CCTLR.(SP)		3717
000604	010037	000000G		JSR	PC.GET.PKT		
000610	002771	000100'		MOV	RO,MX1		
000612	010016			BLT	6\$		3718
000614	012746	000104		MOV	RO,(SP)		3720
000620	004737	000104 000000G		MOV JSR	#104,-(SP)		
000624	012760	000034 000006G		MOV	PC.BL#MUL #34.MSCP.PKT+6(RO) #5.MSCP.PKT+22(RO) #1002.MSCP.PKT+26(RO)		
000632	112760	000005 000022G		MOVB	AS MCCD DKT. 22(DA)		2721
000632 000640	012760	001002 000026G		MOV	A1002 MSCP PKT-26(PO)		3721 3722
000646 000654 000660 000666 000674 000700	012760 005060 142760 152760 004737	001002 000026G 000000G 000032G		MOV	OUPPKT, MSCP. PKT+32(RO)		3723
000654	005060	000024G		CLR	MSCP.PKT+24(RO)		3724
000660	142760	000024G 000360 000010G 000020 000010G		BICB	#360.MSCP.PKT+10(RO)		3725
000666	152760	000020 000010G		BISB	#20,MSCP.PKT+10(RO)		3123
000674	004737	000000V		JSR	PC , DUPCOMMAND		3726
000700	013700	001150'		MOV	DUOFF, RO		3728
000704	006300			ASL	RO		0.20
000706	063700	00000G		ADD	CST.ADDR,RO		
000712	032760	040000 000012		BIT	440000,12(R0)		
000720	001016			BNE	76		
000722	013700	000000G		MOV	DUPPKT, RO		3729
000726	042700	007777		BIC	#7777.RO		
000732	020027	060000		CMP	RO, #60000		

	ZRQAM3 VO1.2		RD/RX EXERCISER MULTI-DRIVE TEST ROU	TINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK*USER2:[DIETZ.RDRX]ZRQACO.	SEQ 0355 Page 100 BL2;161 (27)
	000736 000740 000744 000750 000754	001007 013700 042700 020027 001413	000000G 170000 000002		BNE MOV BIC CMP	7\$ DUPPKT,RO #170000,RO RO,#2		3730
described assets of the second	000756 000762 000766 000770 000774	004737 013700 006300 063700	000000V 001150'	7\$:	JSR MOV ASL ADD	PC.HARD.ERROR DUOFF.RO RO CST.ADDR.RO	:	3732 3733
The residence of the least of t	001002 001004 001010 001014	052760 000413 013716 004737 010037	040000 000012 000000G 000100'	8#:	BIS BR MOV JSR MOV	#40000,12(R0) 9\$ CCTLR,(SP) PC.GET.PKT RO,MX1	:	3728 3736
-	001059 001050 001050	002771 013700 005260	000000G 000054		BLT MOV INC	T.ADDR,RO 54(RO)	1	3737 3739
-	001032 001036 001040	062706 012601 000207	000012	9\$: 10\$:	ADD MOV RTS	#12.SP (SP)+.R1 PC	:	3663 3648

<sup>:</sup> Routine Size: 273 words. Routine Base: #CODE# + 13116 : Maximum stack depth per invocation: 7 words

3742

.

```
SEQ 0356
ZRQAM3
                  RD/RX EXERCISER
                                                                        14-Dec-1983 16:12:07
                                                                                                   VAX-11 Bliss-16 V3-555
                                                                                                                                             Page 101
V01.2
                  MULTI-DRIVE TEST ROUTINES
                                                                        14-Dec-1983 16:12:00
                                                                                                   DISK $USER2: [DIETZ.RDRX]ZRQACO.BL2:161 (28)
           3744 ROUTINE DUPCOMMAND : NOVALUE =
.
           3745
.
           3746
.
           3747 ! THIS ROUTINE IS CALLED BY DUP TO PROCESS COMMANDS.
.
                 ! THE COMMAND ENVOLOPES ARE FILLED IN DUP ROUTINES IN THE "MX1" INDEX.
           3748
                 ! WITH THE INDEX THIS ROUTINE SENDS THE COMMAND, WAITS FOR A
           3749
           3750
                  ! RESPONSES AND THEN PROCESSES THE RETURN PACKET.
           3751
           3752
                  BEGIN
:
                  !PRINTX (DER13):
           3753
.
           3754
:
                 MSCP_PKT [.MX1, CREDITS] = 0;
MSCP_PKT [.MX1, CONNID] = CID_DUP;
MSCP_PKT [.MX1, DK_NUM] = 0;
                                                                       ! DUP DOES NOT USE THE CREDIT SYSTEM ! MAKE PACKAGE EQUAL A DUP COMMAND
           3755
           3756
           3757
                                                                        ! DISK NUMBER (NOT APPLICABLE)
           3758
           3759 IF SEND (.MX1) EQLU FAILURE
                                                                       ! ATTEMPT SEND; IF CTLR IS OFFLINE
           3760 THEN
:
           3761
                           BEGIN
:
                           PUT_PKT (.MX1):
           3762
:
           3763
                           MX1 = -1:
                                                                        ! RETURN ENVELOPE TO POOL
           3764
                           CST_ADDR [.DUOFF + 5, DUPERROR] = 1;
           3765
                           PRINTF (DBM112):
                                                                        ! "DUP: PKT NOT AVAILABLE"
:
           3766
                           END
.
           3767
:
           3768 ELSE
:
           3769
                           do
.
           3770
                                    begin
BREAK;
:
           3771
                                                                               ! BREAK FOR ACT
.
           3772
                                    PROC_RETPKT ();
                                                                                          ! PROCESS RETURN PACKET TO SEE IF OK FOR DUP
.
           3773
:
           3774
                           until (.CRN_LOW eqlu .RP_ADDR [CRF_LO]) or
.
                                                                                 ! TO ENSURE THAT ALL RETURN MESSAGES HAVE BEEN PROCESSED
                           (.EOP_FLAG eql true);
           3775
                                                                                 ! or end of pass caused by error
           3776 END:
                                                       .SBTTL DUPCOMMAND MULTI-DRIVE TEST ROUTINES
000000 013746 000100'
                                             DUPCOMMAND:
                                                               MX1,-(SP)

#104,-(SP)

PC.BL#MUL

#17,MSCP.PKT+10(RO)

#2,MSCP.PKT+11(RO)
                                                      MOV
                                                                                                                                                 3755
000004 012746
                  000104
                                                      MOV
000010 004737
                  000000G
                                                       JSR
000014 142760
                  000017 000010G
                                                      BICB
000022 112760
                  000002 000011G
                                                      MOVB
                                                                                                                                                  3756
000030 005060
                  000016G
                                                      CLR
                                                               MSCP.PKT+16(RO)
                                                                                                                                                  3757
000034 013716
000040 004737
000044 005700
                                                      MOV
                  0001001
                                                               MX1,(SP)
                                                                                                                                                  3759
                  000000G
                                                       JSR
                                                               PC, SEND
                                                      TST
                                                               RO
000046
         001027
                                                      BNE
                                                               18
000050 013716
000054 004737
                                                      MOV
                  0001001
                                                               MX1,(SP)
                                                                                                                                                  3762
         004737
                  000000G
                                                       JSR
                                                               PC.PUT.PKT
000060
        012737
                  177777 000100'
                                                      MOV
                                                               #-1,MX1
                                                                                                                                                  3763
000066 013700
000072 006300
        013700
                  001150
                                                      MOV
                                                               DUOFF, RO
                                                                                                                                                  3764
                                                      ASL
```

-	ZRQAM3 VO1.2		RD/RX EXERCISER MULTI-DRIVE TEST	ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK#USER2:[DIETZ.RDRX]ZRQACO.	SEQ 0357 Page 102 BL2;161 (28)
The same of the sa	000074 000100 000106 000112 000116 000120	063700 052760 012716 012746 010600 104417	000000G 040000 000012 000000G 000001		ADD BIS MOV MOV MOV TRAP	CST.ADDR.RO #40000,12(RO) #DBM112,(SP) #1,-(SP) SP.RO 17	: SP.*	3765
	000122 000124 000126 000130 000134 000140 000146	005726 000415 104422 004737 013700 023760 001404	000000V 000000G 000000G 000004	14:	TST BR TRAP JSR MOV CMP BEQ	(SP)+ 2\$ 22 PC,PROC.RETPKT RP.ADDR,RO CRN.LOW,4(RO) 2\$		3761 3759 3770 3772 3774
-	000150 000156 000160	123727 001363 022626	000000G 000001	28:	CMPB BNE CMP	EOP.FLAG.#1 1\$ (SP)+.(SP)+		3775
-	000162	000207		٤٠:	RTS	PC PC		3752 3744

<sup>:</sup> Routine Size: 58 words. Routine Base: \$CODE\$ + 14160 : Maximum stack depth per invocation: 5 words

```
SEQ 0358
                                                                            14-Dec-1983 16:12:07 VAX-11 Bliss-16 V3-555 Page 103 14-Dec-1983 16:12:00 DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2:161 (29)
ZRQAM3
                   RD/RX EXERCISER
V01.2
                   MULTI-DRIVE TEST ROUTINES
            3777
            3778 ROUTINE DUPIDLE : NOVALUE =
:
            3779
:
                   THIS ROUTINE IS CALLED BY DUP ROUTINE TO INSURE THAT THE CONTROLLER IS NOT IN A ACTIVE STATE. IF CALLED AND THE CONTROLLER IS IN AN ACTIVE STATE THE CONTROLLER WILL GIVE AN ABORT COMMAND WHICH SHOULD KILL THE
            3780
.
            3781
            3782
:
                   ! CURRENT JOB OR LOCAL PROGRAM.
            3783
            3784
            3785
                   BEGIN
                                                                         !CLEAR DUP ERROR FLAG;
            3786
                   CST_ADDR [.DUOFF + 5, DUPERROR] = 0;
            3787
                   MSCP_PKT [.MX1, MSGLEN] = SZ_GDS;
MSCP_PKT [.MX1, OPCODE] = OP_GDS;
MSCP_PKT [.MX1, MODIFY] = O;
MSCP_PKT [.MX1, MSGTYP] = IMM_CMD;
            3788
                                                                              ! PACKET SIZE
                                                                                                                                GET DUST STATUS
            3789
                                                                               ! OPCODE = GET DUST STATUS
            3790
            3791
                                                                               ! CALL IT IMMEDIATE
            3792 DUPCOMMAND ():
                                                                               ! SENDS AND RECEIVES THE COMMAND
            3793
                                                                               ! GDS ONLY RETURNS SUCCESS or it don't return
            3794
.
            3795
                   DO (MX1 = GET_PKT (.CCTLR))
.
                   UNTIL (.MX1 GEQ 0):
            3796
                                                                             ! TRY TO GET AN ENVELOPE. IF FAILURE LOOP PRGRAM ERROR
:
            3797
.
                   if .CST_ADDR [.DUOFF + 5, D_ACTIVE] neg IDLE ! if not in idle state then abort the program
            3798
.
            3799
                   then
                        begin

MSCP_PKT [.MX1, MSGLEN] = SZ_ABT;

MSCP_PKT [.MX1, OPCODE] = OP_ABT;

MSCP_PKT [.MX1, MODIFY] = O;

MSCP_PKT [.MX1, MSGTYP] = IMM_CMD;
            3800
.
            3801
                                                                                         ! PACKET SIZE
.
                                                                                                                                                    ABORT CMD
            3802
                                                                                         ! OPCODE - ABORT PROGRAM
.
            3803
.
            3804
                                                                                         ! CALL IT IMMEDIATE
            3805
                        DUPCOMMAND ():
.
                                                                                         ! SENDS AND RECEIVES THE COMMAND
             3806
                                                                                         !ONLY ERROR IS already in idle state
.
                        DO (MX1 - GET_PKT (.CCTLR))
             3807
.
                                                                     ! TRY TO GET AN ENVELOPE. IF FAILURE LOOP PRGRAM ERROR
             3808
                        UNTIL (.MX1 GEQ 0);
:
            3809
.
                        end:
            3810 end:
.
                                                            .SBTTL DUPIDLE MULTI-DRIVE TEST ROUTINES
000000 010146
                                                 DUPIDLE: MOV
                                                                     R1,-(SP)
                                                                                                                                                               3778
000002 013700 001150
                                                                     DUOFF, RO
                                                           MOV
                                                                                                                                                               3786
000006
         006300
                                                           ASL
                                                                     RO
000010
         063700
                                                           ADD
                   000000G
                                                                     CST. ADDR. RO
000014
         042760
                   040000 000012
                                                           BIC
                                                                     #40000,12(RO)
000022
          013746
                   0001001
                                                                     MX1,-(SP)
                                                           MOV
                                                                                                                                                               3788
                                                                                                             .
000026
          012746
                    000104
                                                           MOV
000032
          004737
                    000000G
                                                            JSR
                                                                     PC, BL #MUL
000036
000044
                   000014 000006G
          012760
                                                                     #14.MSCP.PKT+6(RO)
#1.MSCP.PKT+22(RO)
                                                           MOV
         112760
                   000001
                             000022G
                                                           MOVB
                                                                                                                                                               3789
000052 005060
                                                                     MSCP.PKT+24(RO)
#360,MSCP.PKT+10(RO)
PC.DUPCOMMAND
                   000024G
                                                           CLR
                                                                                                                                                               3790
000056 142760
                   000360 000010G
                                                           BICB
                                                                                                                                                               3791
000064
         004737
                   014160'
                                                            JSR
                                                                                                                                                               3792
000070 013716
                   000000G
                                                           MOV
                                                                     CCTLR, (SP)
                                                18:
                                                                                                                                                               3795
000074 004737
                   000000G
                                                            JSR
                                                                     PC.GET.PKT
000100 010037
                   0001001
                                                                     RO, MX1
```

ZRQAM3 VO1.2		RD/RX EXERCISER MULTI-DRIVE TEST ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.	SEQ 0359 Page 104 BL2;161 (29)
000104 000106	010001		MOV BLT	RO,R1	; MX1,*	3796
000110 000114	013700 006300	001150'	MOV	1\$ DUOFF,RO RO	•	3798
000116 000122 000130	063700 032760 001432	050000 000015 0000000	ADD BIT BEQ	CST.ADDR,RO #20000,12(RO) 3\$		
000132 000134 000140	010116 012746 004737	000104 000000G	MOV MOV JSR	R1,(SP) #104(SP) PC,BL#MUL		3801
000144	012760 112760	000014 000006G 000006 000022G	MOV	#14.MSCP.PKT+6(RO) #6,MSCP.PKT+22(RO)		3802
000160 000164	005060 142760	000024G 000360 000010G	CLR BICB	MSCP.PKT+24(RO) #360,MSCP.PKT+10(RO)		3803 3804
000172 000176 000202 000206	004737 013716 004737 010037	014160' 000000G 000000G 000100'	JSR MOV JSR MOV	PC, DUPCOMMAND CCTLR, (SP) PC, GET. PKT RO, MX1		3805 3807
000212 000214	002771 005726		BLT	2\$ (SP)+		3808 3800
000555 000550 000550	022626 012601 000207	34:	CMP MOV RTS	(SP)+,(SP)+ (SP)+,R1 PC		3785 3778

<sup>:</sup> Routine Size: 74 words. Routine Base: \$CODE\$ + 14344 : Maximum stack depth per invocation: 5 words

```
SEQ 0360
ZRQAM3
                 RD/RX EXERCISER
                                                                     14-Dec-1983 16:12:07
                                                                                               VAX-11 Bliss-16 V3-555
                                                                                                                                       Page 105
V01.2
                 MULTI-DRIVE TEST ROUTINES
                                                                     14-Dec-1983 16:12:00
                                                                                               DISK&USER2: [DIETZ.RDRX]ZRQACO.BL2:161 (30)
           3811 routine QIO_LBN : novalue =
           3812
           3813
                 ! +
           3814
                          THIS ROUTINE IS CALLED BY QIO_GEN TO SELECT THE LOGICAL BLOCK NUMBER TO
           3815
                          BE USED FOR THE CURRENT QIO OR QIO PAIR.
           3816
                          IF THE OPERATOR CHOSE THE RANDOM BLOCK MODE OPTION, THEN THE LBN IS
           3817
           3818
                          RANDOMLY CHOSEN WITHIN THE SPECIFIED LIMITS FOR THE LBN.
           3819
                          OTHERWISE, THE NEXT SEQUENTIAL LBN IS DERIVED FROM THE BLOCK SEQUENCE
           3820
                          TABLE (BST).
           3821
           3822
                          IMPLICIT IMPUTS:
                                  L$LUN - CURRENT (DIAGNOSTIC SUPERVIOR) UNIT NUMBER
           3823
           3824
           3825
                          IMPLICIT OUTPUTS:
:
           3826
                                  THE LBN IS LOADED INTO ONE OR BOTH MSCP PACKETS.
.
           3827
                 ! -
           3828
           3829
                 begin
           3830
           3831
                 local
           3832
                     RD_DISK : byte:
                                        ! FLAG TO INDICATE WINCHESTER DISK SELECTED
           3833
           3834
           3835
                 if .CST_ADDR [.CUOFF, D_TYPE] eql RX_50
           3836
                 then
           3837
                     RD_DISK - FALSE
           3838
                 else
           3839
3840
                     RD_DISK = TRUE;
           3841
                 MAD1 (LBN_L) = .BST (.L$LUN, LO_WRD);
MAD1 (LBN_H) = .BST (.L$LUN, HI_WRD);
                                                                              ! LOAD LBN INTO 1ST PACKET ! LOAD LBN INTO 1ST PACKET
           3842
           3843
           3844
                 if .MX2 geg 0
                                                            ! IF 2 QIOS
           3845
                 then
           3846
                     begin
MAD2 (LBN_L) = .BST (.L$LUN, LO_WRD);
MAD2 (LBN_H) = .BST (.L$LUN, HI_WRD);
           3847
3848
                                                                                       ! LOAD LBN INTO 2ND PACKET
                                                                             ! LOAD LBN INTO 2ND PACKET
           3849
           3850
           3851
3852
                 IF BIT_TST (SWP_FLAGS, SWF_BLK)
                                                     ! IF RANDOM BLOCK MODE
                 then
           3853
                     begin if NOT ((.RD_DISK) and
           3854
           3855
                       (((.RANDOM [0] and #0'077777') mod (99)) legu 33))
                                                                                                        ! REDUCES SEEKS TO 66# OF TRANFERS o
n winchesters
           3856
                      then
           3857
                          begin
                                                                                                        ! NOTE IF NOT CALLED THE LBN REMAINS
 THE SAME
                          if .CST_ADDR (.CUOFF + 2, D_BEG1) eqlu .CST_ADDR (.CUOFF + 4, D_END1)
           3859
                          then
                                                                                                        ! if upper word of beg trk and endin
  trk same
           3860
                                  BST [.L$LUN, LO_MRD] = .CST_ADDR [.CUOFF + 1, D_BEGO] +
                                                                                                                 ! select low lbn from random
 number WINDOW
           3861
                                  MODULAS (.CST_ADDR [.CUOFF + 1, D_BEGO], .CST_ADDR [.CUOFF + 3, D_ENDO])
           3862
           3863
                          else
                                                                                                        ! if upper word of beg trk and end t
rk different
```

```
SEQ 0361
ZRQAM3
                  RD/RX EXERCISER
                                                                           14-Dec-1983 16:12:07
                                                                                                       VAX-11 Bliss-16 V3-555
                                                                                                                                                 Page 106
V01.2
                  MULTI-DRIVE TEST ROUTINES
                                                                          14-Dec-1983 16:12:00
                                                                                                       DISK $USER2: [DIETZ.RDRX]ZRQACO.BL2:161 (30)
                                begin
BST [.L$LUN, HI_WRD] = .CST_ADDR [.CUOFF + 2, D_BEG1] +
            3865
:
                                                                                                                ! select upper 1bn from window
                                 MODULAS (.CST_ADDR [.CUOFF + 2, D_BEG1], .CST_ADDR [.CUOFF + 4, D_END1]);
            3866
.
            3867
            3868
                                 if .BST [.L$LUN, HI_WRD] eql .CST_ADDR [.CUOFF + 4, D_END1]
                                                                                                              ! IF UPPER WORD EQUALS HI LIMIT BE S
URE LO
            3869
                                then .BST [.L$LUN, LO_WRD] = MODULAS (O, .CST_ADDR [.CUOFF + 3, D_ENDO]); ! WORD DOES NOT PASS HI LIMIT
            3870
2
            3871
                                 if .BST [.L$LUN, HI_WRD] eql .CST_ADDR [.CUOFF + 2, D_BEG1]
                                                                                                              ! if upper word equal lo limit make
sure lowe
            3872
                                then BST [.L$LUN, LO_WRD] = #0'177777' - MODULAS (.CST_ADDR [.CUOFF + 1, D_BEGO], #0'177777');
            3873
                                                                                                                ! word is above lo limit
            3874
            3875
                                if .BST [.L$LUN, HI_WRD] gtr .CST_ADDR [.CUOFF + 2, D_BEG1] and .BST [.L$LUN, HI_WRD] les .CST_ADDR [.CUOFF + 4, D_END1]
:
            3876
                                                                                                              ! if neither of the above then any n
:
umber is
            3877
                                 then BST [.L$LUN, LO_WRD] = .RANDOM [5]:
:
            3878
                                end:
.
            3879
                            end:
            3880
                       end
            3881
                  else
:
            3882
                       begin
                                                                          ! ELSE - SEQUENTIAL LBN MODE
.
            3883
                       if (.TRK_SGN [.L$LUN] geg 1)
:
            3884
.
                       then
                                                                           ! if positive track direction add one to multiword
            3885
                            (if .BST [.L$LUN, LO_WRD] ealy #0'177777'
            3886
                            then
            3887
                                     begin
BST [.L$LUN, LO_WRD] = 0;
            3888
            3889
                                     BST [.L$LUN, HI_WRD] - .BST [.L$LUN, HI_WRD] + 1;
            3890
            3891
                            else
                                     BST [.L$LUN, LO_WRD] = .BST [.L$LUN, LO_WRD] + 1)
            3892
.
            3893
                                                                          ! if negative track direction subtract one from multiword
            3894
3895
                            if .BST [.L$LUN, LO_WRD] eqlu #0'0'
                            then
            3896
                                     begin
BST [.L$LUN, LO_WRD] = #0'177777';
BST [.L$LUN, HI_WRD] = .BST [.L$LUN, HI_WRD] - 1;
            3897
            3898
            3899
            3900
                            else
            3901
                                     BST [.L$LUN, LO_WRD] = .BST [.L$LUN, LO_WRD] - 1;
            3902
            3903
                       if .BST [.L$LUN, LO_WRD] gequ (.CST_ADDR [.CUOFF + 3, D_ENDO]) and ! if hi limit then change direction
.BST [.L$LUN, HI_WRD] gequ (.CST_ADDR [.CUOFF + 4, D_END1])
then TRK_SGN [.L$LUN] = -1;
            3904
            3905
:
            3906
3907
3908
.
                       if .BST [.L$LUN, LO_MRD] lequ (.CST_ADDR [.CUOFF + 1, D_BEGO] + 1) and ! if low limit then change direction
.BST [.L$LUN, HI_MRD] lequ (.CST_ADDR [.CUOFF + 2, D_BEG1])
then TRK_SGN [.L$LUN] = 1;
:
            3909
:
            3910
            3911
                       end;
            3912
                  end:
                                                                                    ! ROUTINE QIO LBN
                                                         SBTTL QIO.LBN MULTI-DRIVE TEST ROUTINES
```

QIO.LBN:JSR

R1. \$SAVES

3811

000000 004137 000000G

## M12

ZRQAM3 VO1.2		RD/RX EXERCISER MULTI-DRIVE TEST R	OUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2;1	Q 0362 Page 107 161 (30)
000004 000006 000012 000016	005746 013703 013704 010400	000000G 000000G		TST MOV MOV	-(SP) CST.ADDR,R3 CUOFF,R4 R4,R0		3835
000020 000024 000030 000032 000034 000036 000042 000054 000056 000060 000064 000066 000064	006300 060300 132710 001002 105005	000034		ASL ADD BITB BNE CLRB	RO R3,RO #34,(RO) 1\$ R5	; RD.DISK	3837
000034 000036 000042	001002 105005 000402 112705 013700	000001 000104	1\$: 2\$:	BR MOVB MOV	2\$ #1.R5 MAD1.RO	*.RD.DISK	3835 3839 3841
000046 000052 000054 000056	013702 010201 006301 006301	000000G		MOV MOV ASL ASL	L\$LUN,R2 R2,R1 R1 R1		
000060 000064 000066	012716 060116 017660	000000G 000000 000046		MOV ADD MOV	#BST,(SP) R1,(SP) 80(SP),46(R0) #BST+2,R1		
000074 000100 000104	062701 011160 005737	000002G 000050 000102'		ADD MOV TST	(R1),50(R0) MX2		3842 3844
000104 000110 000112 000116 000124	005737 002407 013700 017660	000106' 000000 000046 000050		BLT MOV MOV	3\$ MAD2,RO 80(SP),46(RO) (R1),50(RO)	•	3847
000130	011160 032737 001002	000050 001000 000000G	3#:	MOV BIT BNE JMP	#1000, SWP.FLAGS	:	3848 3851
000140 000144 000146 000150	000137 006005 103014 013746	000000G	41:	ROR BCC MOV	11\$ R5 5\$ PANDOM -(SP)	; RD.DISK	3854
000154 000160 000164 000170	042716 012746 004737	100000 000143 000000G		BIC MOV JSR CMP	RANDOM,-(SP) #100000,(SP) #143,-(SP) PC,BL\$MOD (SP)+,(SP)+		3855
000172 000176 000200 000202	020027 101565 010400 006300 060300 016002 010400 006300 060300 020260	000041	5#:	CMP BLOS MOV ASL	RO. #41 10\$ R4.RO RO	•	3858
000176 000200 000204 000206 000212 000214 000216 000220 000224 000226 000230 000232 000234 000240	060300 016002 010400 006300	000004		ADD MOV MOV ASL	R3,R0 4(R0).R2 R4,R0 R0		
000216 000220 000224 000226	060300 020260 001021 010405	000010		ADD CMP BNE MOV	R3.R0 R2.10(R0) 6# R4.R5		3860
000230 000232 000234	001021 010405 006305 060305 016546	000002		ASL ADD MOV	R5 R3.R5 2(R5),-(SP)		3861
000240 000242	010400 006300			MOV	R4.RO RO		5501

N12

STREET, SQUARE, STREET, SQUARE, SQUARE	ZRQAM3 VO1.2		RD/RX EXERCISER MULTI-DRIVE TES	T ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQAC	SEQ 0363 Page 108 0.BL2;161 (30)
	000244 000246 000252	060300 016046 004737	000006 00000G		ADD MOV JSR	R3,R0 6(R0),-(SP) PC,MODULAS 2(R5),R0		
	000252 000256 000262 000270 000272 000276 000302 000304 000306 000312	066500 010076	000002 000004		ADD	RO,84(SP)	,	3860
-	000270	000530 010246 016046	000010	6\$:	BR MOV MOV	9\$ R2,-(SP) 10(R0),-(SP)	:	3858 3866
	000276 000302 000304	004737 060200 010011	000000G		JSR ADD MOV	PC,MODULAS R2,R0 R0,(R1)		3865
-	000306	013702	000000G		MOV	L\$LUN,R2 R2	•	3868
-	000316	006302 006302 013700 006300	000000G		ASL MOV ASL	R2 CUOFF,RO RO		
-	000324 000330 000336	063700	000000G 000000G		ADD CMP BNE	CST.ADDR,RO BST+2(R2),10(R0) 7\$		
-	000340 000342	001015 005016 013700 006300	000000G		CLR MOV ASL	(SP) CUOFF,RO RO	•	3869
-	000316 000322 000324 000330 000340 000340 000346 000350 000354 000360 000364 000370 000372 000376 000400	016046	000000G 000006		ADD	CST.ADDR,RO 6(RO),-(SP) PC.MODULAS RO.ABST(R2)		
-	000364 000370	004737 010072 005726 013701 006301	000000G 000000G		JSR MOV TST	(SP)+		
-	000372 000376 000400	006501	000000G	7\$:	MOV ASL ASL	L\$LUN,R1 R1 R1	•	3871
-	000402 000406 000410	013700	000000G 000000G		MOV ASL ADD	CUOFF, RO RO CST. ADDR, RO		
-	000414	063700 026160 001021	000002G 000004		CMP	BST+2(R1),4(R0)		
-	000424 000430 000432 000436	013700 006300 063700	000000G		MOV ASL ADD	CUOFF,RO RO CST.ADDR,RO	•	3872
-	000436 000442 000446	016016 012746 004737	000000G 000002 177777 000000G 177777 000000G		MOV MOV JSR	2(RO).(SP)		
-	000452 000460 000464	012761 160061 005726	177777 000000G		MOV SUB TST	#-1,-(SP) PC.MODULAS #-1,BST(R1) RO,BST(R1) (SP)+		
	000436 000446 000452 000460 000464 000466 000472 000474 000476	012761 160061 005726 013701 006301 013700 006300	000000G	8#:	MOV	L\$LUN,R1 R1	1	3875
-	000476	013700 006300	000000G		ASL MOV ASL	R1 CUOFF,RO RO		
	000504 000510 000516 000520	026160 003414	000000G 000002G 000004		ADD CMP BLE	CST.ADDR,RO BST+2(R1),4(R0)		
-	000520	013700	00000G		MOV	CUOFF,RO	•	3876

ZRQAM3 VO1.2	RD/RX EXERCISER MULTI-DRIVE TEST ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.B	SEQ 0364 Page 109 L2;161 (30)
000524 006300 000526 063700 000532 026160 000540 002003	000000G 000002G 000010	ASL ADD CMP	RO CST.ADDR,RO BST+2(R1),10(RO)		
000542 013761 000550 022626	000012G 000000G	BGE MOV CMP	9\$ RANDOM+12.BST(R1) (SP)+,(SP)+	:	3877 3857
000552 000471	000000G 10\$	: BR	17\$ #TRK.SGN.R2 (R2)		3851 3883
000562 003413 000564 027627	000000 177777	BLE	13\$ 80(SP),#-1		3885
000574 005076 000600 005211	000000	BNE CLR INC	12\$ 80(SP) (R1)	:	3888 3889
000602 000415 000604 005276 000610 000412	000000 128	: INC BR	15# 80(SP) 15#		3885 3892
000612 005776 000616 001005 000620 012776	000000 13# 177777 000000	: TST BNE	80(SP) 14\$	;	3883 3894
000626 005311 000630 000402		MOV DEC BR	#-1,80(SP) (R1) 15#		3897 3898 3894
000626 005311 000630 000402 000632 005376 000636 010400 000640 006300 000642 060300	000000 148 158		80(SP) R4,R0 R0		3901 3904
000642 060300 000644 027660 000652 103410 000654 010400	000000 000006	ADD CMP BLO	R3,R0 80(SP),6(R0) 16#		
000656 006300		MOV	R4,R0 R0		3905
000660 060300 000662 021160 000666 103402 000670 112712	000010	ADD CMP BLO	R3.R0 (R1).10(R0) 16#		
000674 010400 000676 006300	000377	: MOVB	#377.(R2) R4.R0 R0		3906 3908
000700 060300 000702 016000 000706 005200	000002	ADD MOV INC	R3,R0 2(R0),R0 R0		
000710 027600 000714 101010 000716 010400	000000	CMP	80(SP),R0 17#		
000720 006300 000722 060300	000004	MOV ASL ADD	R4.R0 R0 R3.R0		3909
000724 021160 000730 101002 000732 112712	000001	CMP BHI MOVB	(R1),4(R0) 17¢ ¢1,(R2)		3910
000736 005726 000740 000207	176		(SP)+ PC	•	3811

Routine Size: 241 words. Routine Base: \$CODE\$ + 14570 ; Maximum stack depth per invocation: 11 words

```
SEQ 0365
ZRQAM3
                 RD/RX EXERCISER
                                                                      14 -Dec - 1983 16:12:07
                                                                                                VAX-11 Bliss-16 V3-555 Page 110
DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (31)
                                                                                                VAX-11 Bliss-16 V3-555
V01.2
                 MULTI-DRIVE TEST ROUTINES
                                                                      14-Dec-1983 16:12:00
           3913 routine QIO_SIZE : novalue *
           3914
           3915
                 ! .
           3916
                          THIS ROUTINE IS CALLED BY QIO_GEN TO SELECT THE I/O TRANSFER BYTE COUNT
                          TO BE USED FOR THE CURRENT QIO OR QIO PAIR. THE BYTE COUNT IS
           3917
                          DETERMINED BY A RANDOM NUMBER, AND WILL ALWAYS FALL BETWEEN 1 AND THE I/O BUFFER SIZE (BYTS_PER_QIO). It is assumed that BYTS_PER_QIO will
           3918
           3919
           3920
                          never be larger than one binary word or 65000 bytes.
           3921
           3922
                          IMPLICIT OUTPUTS:
           3923
                                   THE BYTE COUNT IS LOADED INTO ONE OR BOTH MSCP PACKETS.
           3924 !-
           3925
           3926
                     begin
           3927
:
           3928
                      local
                          SIZE : word,
           3929
.
                                                                                                         ! BYTE COUNT
           3930
                          BLOCKS_LEFT : word:
:
                                                                                                         ! REMAINING BLOCKS LEFT
           3931
           3932
                     SIZE = ((.RANDOM [4] and %o'077777') mod (.BYTS_PER_QIO + 1)) and %o'177760';!GET BYTE COUNT FROM RANDOM NUMBER
           3933
           3934
                     if .SIZE eql 0
           3935
                      *hen
           3936
                          SIZE - 16:
           3937
           3938
                     if .CST_ADDR [.CUOFF + 4, D_END1] gtru .MAD1 [LBN_H]
           3939
                      then BLOCKS_LEFT = #0'177777'
                                                                                                                  ! find
           3940
3941
3942
                     else BLOCKS_LEFT = .CST_ADDR [.CUOFF + 3, D_ENDO] - .MAD1 [LBN_L] + 1;
                                                                                                                  ! REMAINING BLOCK COUNT
                      if ((.SIZE . BYTES_PER_SECT - 1) / BYTES_PER_SECT) gtru .BLOCKS_LEFT
                                                                                                         ! IF BLOCK COUNT NOT ENOUGH
           3943
                      then
           3944
                          SIZE . BLOCKS_LEFT . BYTES_PER_SECT:
.
                                                                                                         ! ADJUST BYTE COUNT DOWN
           3945
           3946
                     MAD1 (BC_LO) - .SIZE;
                                                                                                         ! LOAD SIZE INTO 1ST MSCP PACKET
           3947
           3948
                      if .MX2 geq 0
                                                                                                         ! IF 2 QIOS
           3949
:
                      then
           3950
                          MAD2 (BC_LO) - .SIZE;
:
                                                                                                         ! LOAD SIZE INTO 2ND MSCP PACKET
           3951
:
:
                     end:
                                                                                                         ! ROUTINE QIO_SIZE
                                                    .SBTTL QIO.SIZE MULTI-DRIVE TEST ROUTINES
000000 004137 000000G
                                           QIO. SIZE:
                                                    JSR
                                                             R1. $SAVE3
                                                                                                                                            3913
000004
        013746
                 000010G
                                                    MOV
                                                             RANDOM+10, -(SP)
                                                                                                                                            3932
                                                                                                .
000010
        042716
                 100000
                                                    BIC
                                                             #100000,(SP)
000014
        013746
                 000000G
                                                             BYTS.PER.QIO, -(SP)
                                                    MOV
000020
        005216
                                                    INC
                                                             (SP)
000022
        004737
                 000000G
                                                    JSR
                                                             PC, BL $MOD
000026
        010003
                                                    MOV
                                                             RO,R3
000030
        042703
                 000017
                                                             #17,R3
                                                                                                : *.SIZE
                                                    BIC
000034
        001002
                                                                                                                                            3934
```

000036 012703 000000		ZRQAM3 VO1.2		RD/RX EXERCISER MULTI-DRIVE TEST	ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK*USER2:[DIETZ.RDRX]ZRQACO.	SEQ 0366 Page 111 .BL2;161 (31)
000054 013701 000104' 000050 CPG 101405 000050 000050 CPF 10(R0).50(R1) 000050 026061 000010 000050 BLOS 2# 10(R0).50(R1) 000074 000413 000074 000413 000076 013700 000006 101405 000006 013700 000006 2#: MOV CUOFF.R0		000042 0 000046 0	13700 06300	00000G	1\$:	MOV	CUOFF, RO	: *,SIZE	
000074 00413 000006 013700 000000G 28: MOV CUOFF,RO ; 3938 3940 00102 065300 000006 ADD CST, ADDR,RO ; 000114 166100 000006 HOV 6(RO),RO ; 000114 166100 00006 HOV 6(RO),RO ; 000122 005202 INC R2 ; 8LOCKS,LEFT 000124 010316 00077 ADD 6777,(SP) ; SIZE,* 3942 000125 010002 HOV \$1000,-(SP) 000135 010270 000006 JSR PC,BL\$** 15T (SP)** 000140 02002 CMP RO,R2 ; *,BLOCKS,LEFT 000140 000140 02002 FSF CMP RO,R2 ; *,BLOCKS,LEFT 000140 000140 00000 HOV \$1000,-(SP) 000140 00000 HOV \$1000,-(SP) 000140 00000 HOV \$1000,-(SP) 000140 00000 HOV \$1000,-(SP) 000150 010200 CMP RO,R2 ; *,BLOCKS,LEFT 000150 010200 HOV \$1000,-(SP) 000150 010200 CLRB RO 000154 105000 CLRB RO 000156 006300 O00156 105000 ASL RO 000150 010003 HOV RO,R3 ; *,SIZE 000160 010003 HOV RO,R3 ; *,SIZE 000174 013700 000105 HOV RO,R3 ; *,SIZE 0000206 000206 D00206 D00206 D00206 D00206 D00206 D00206 HOV RO,R3 ; *,SIZE 000206 D00206 D0020		000050 0 000054 0 000060 0 000066 1	13701 26061	000104		MOV	MAD1,R1 10(R0),50(R1)		
000106 013700 000000		000074 0	12702			MOV BR	#-1,R2 3\$	: *.BLOCKS.LEFT	
000114 166100 000066		000102 0	06300		2\$:	ASL	RO	•	
000124 010316		000110 0	16000	000006		MOV	6(RO),RO 46(R1),RO		
000126 062716 000777	A	000124 0	05202 010316		34:	INC	R2	: *.BLOCKS.LEFT : BLOCKS.LEFT : SIZE.*	3942
000146 101405	CHARLES STREET, SQUARE	000126 0 000132 0 000136 0	62716 12746 104737	001000		ADD MOV JSR	#777,(SP) #1000,-(SP) PC.BL#DIV		3742
000156 006300 000160 010003 000162 010361 000026 000166 005737 000102' 000172 002404 000174 013700 000106' 000200 010360 000026 000204 022626 000204 022626 000204 022626 000205 000207 000206 000207	-	000144 0	20002			CMP BLOS	RO,R2	: *.BLOCKS.LEFT	
000160 010003 000162 010361 000026 000166 005737 000102' TST MX2 000172 002404 000174 013700 000106' MOV MAD2.RO 000200 010360 000026 MOV R3.26(R0) MOV R3.26(R0) SIZE.* 3946 3948 3950 3950 3950	Contract of management	000150 0 000152 0 000154 1 000156 0	10200 00300 05000 06300			SWAB	RO RO	: BLOCKS.LEFT.*	3944
000172 002404 000174 013700 000106' MOV MAD2.RO 000200 010360 000026 MOV R3.26(RO) 000204 022626 5\$: CMP (SP)+,(SP)+	-	000160 0	10003		41:	MOV	R3,26(R1)	: *.SIZE : SIZE.*	
000200 010360 000026 000204 022626 54: CMP (SP)+,(SP)+	-	000172 0	02404			BLT	5#		
00000 00000	-	000200 0	10360	000026		MOV	R3,26(R0)	SIZE.	
	Section Section	000206 0	00207		<b>3</b> *:		PC (SP)+		

<sup>:</sup> Routine Size: 68 words. Routine Base: #CODE# + 15532 : Maximum stack depth per invocation: 8 words

SEQ 0367

Page 112

```
ZRQAM3
                 RD/RX EXERCISER
                                                                    14-Dec-1983 16:12:07
                                                                                              VAX-11 Bliss-16 V3-555
V01.2
                 MULTI-DRIVE TEST ROUTINES
                                                                    14-Dec-1983 16:12:00
                                                                                              DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (32)
                 routine FILL_BUFF : novalue =
           3954
.
           3955
           3956
                          THIS ROUTINE IS CALLED BY QIO_GEN TO LOAD THE I/O BUFFER DESCRIBED IN
                          THE FIRST MSCP PACKET WITH THE APPROPRIATE DATA PATTERN.
           3957
.
           3958
           3959
                          THE DATA PATTERN TO BE SELECTED IS BASED ON THE FOLLOWING ALGORITHM:
           3960
           3961
                                  IF THE OPERATOR DEFINED A DATA PATTERN
           3962
                                  THEN
:
           3963
                                           SELECT IT
.
           3964
                                  ELSE
:
          3965
3966
3967
3968
                                           GET DATA PATTERN NUMBER FROM SW P-TABLE
.
                                           IF DATA PATTERN NUMBER = 0
:
:
:
                                                   GET DATA PATTERN NUMBER FROM THE UNIT'S ENTRY
           3969
:
                                                   IN THE DATA PATTERN SEQUENCE TABLE (DPST)
           3970
.
           3971
                          NOTE THAT PATTERN # 1 CONSISTS OF RANDOM NUMBERS. AND PATTERNS # 17 -
.
                         21 USE THE ACTUAL LBN OF THE WRITE REQUEST.
           3972
:
           3973
:
           3974
                          IMPLICIT INPUTS:
.
           3975
                                  L$LUN - CURRENT (DRS) UNIT NUMBER
           3976
.
           3977
:
           3978
.
                     begin
           3979
:
           3980
                     local
           3981
                         DP_NUM : word, DP_ADDR,
                                                                    ! DATA PATTERN NUMBER SELECTED
           3982
.
                                                                      ADDR OF DATA PATTERN (LENGTH)
                          IOB_ADDR,
SRC_ADDR,
                                                                      I/O BUFFER ADDRESS (DESTINATION)
           3983
                                                                    ! WORKING SOURCE ADDRESS
           3984
           3985
                          COUNT : word:
                                                                    ! NO. OF WORDS IN DATA PATTERN
           3986
           3987
                     IF BIT_TST (SMP_FLAGS, SMF_UDP)
:
                                                                    ! IF USER DEFINED A DATA PATTERN
           3988
:
           3989
3990
3991
                         DP_ADDR - SMP_UCNT
                                                                    ! SELECT IT
                     else
                          begin
           3992
           3993
.
                          if .SMP_DPAT neg 0
                                                                    ! IF USER SELECTED A PRE-DEFINED DATA PATTERN
           3994
.
           3995
                              DP_NUM . SWP_DPAT
                                                                    ! SELECT IT
           3996
3997
:
                          else
                              begin
DP_NUM = .DPST [.L&LUN];
.
           3998
                                                                    ! GET PATTERN NUMBER FROM SEQUENCE TABLE
           3999
                              DPST (.L&LUN) . . DPST (.L&LUN) . 1; ! ADVANCE TO NEXT PATTERN NUMBER
:
           4000
.
           4001
                              if .DPST [.L$LUN] gtru DP_CNT
.
                                                                    ! CHECK FOR HIGH LIMIT
           4002
.
                              then
.
           4003
                                  DPST [.L&LUN] - 1;
           4004
:
          4005
                              end:
```

```
SEQ 0368
ZRQAM3
                 RD/RX EXERCISER
                                                                       14-Dec-1983 16:12:07
                                                                                                 VAX-11 Bliss-16 V3-555
                                                                                                                                         Page 113
V01.2
                 MULTI-DRIVE TEST ROUTINES
                                                                      14-Dec-1983 16:12:00
                                                                                                 DISK#USER2: [DIETZ.RDRX]ZRQACO.BL2:161 (32)
           4006
           4007
                          DP_ADDR = .DPA_TBL [.DP_NUM - 1];
                                                                    ! ADDRESS OF DATA PATTERN (COUNT)
:
           4008
.
           4009
                          if .DP_NUM gegu 17
.
           4010
                          then
.
           4011
:
           4012
                               IF . DP_NUM
                                                                       ! CHECK MACRO
                                                                                                ! IF PATTERN 17, 19, OR 21
:
           4013
.
                               then
           4014
                                   (.DP_ADDR 2) . MAD1 [LBN_L] ! LOAD LBN INTO FIRST WORD OF PATTERN
:
           4015
.
           4016
                                   (.DP_ADDA + 4) = .MAD1 [LBN_L]: ! LOAD LBN INTO SECOND WORD OF PATTERN
.
           4017
:
           4018
                          end:
:
           4019
:
                      IOB_ADDR - .MAD1 [BUF_0];
           4020
.
                                                                       ! I/O BUFFER ADDRESS
                      COUNT = ..DP_ADDR;
SRC_ADDR = .DP_ADDR + 2;
           4021
                                                                      ! NO. OF WORDS IN DATA PATTERN
! START OF THE ACTUAL DATA PATTERN
:
           4022
:
           4023
.
                      incr N from 1 to ((.MAD1 [BC_LO] + 1) / 2) do ! FOR EACH WORD IN THIS WRITE REQUEST
           4024
:
                          begin
.IOB_ADDR = ..SRC_ADDR:
IOB_ADDR = .IOB_ADDR + 2:
SRC_ADDR = .SRC_ADDR + 2:
           4025
:
           4026
:
                                                                       ! MOVE 1 WORD
           4027
                                                                      ! ADVANCE DESTINATION ADDRESS ! ADVANCE SOURCE ADDRESS
.
           4028
.
           4029
                           COUNT - . COUNT - 1;
.
                                                                       ! DECREMENT COUNT
           4030
:
           4031
                           if .COUNT eql 0
                                                                      ! IF END OF DATA PATTERN
.
           4032
.
                           then
                              begin
COUNT = ..DP_ADDR;
SRC_ADDR = .DP_ADDR + 2;
           4033
.
           4034
.
                                                                      ! REPEAT DATA PATTERN
           4035
:
           4036
.
                               end:
           4037
.
           4038
:
                          end:
                                                                       ! WORD TRANSFER LOOP
           4039
:
           4040
                                                                      ! ROUTINE FILL_BUFF
.
                      end:
                                                     .SBTTL FILL.BUFF MULTI-DRIVE TEST ROUTINES
000000 004137 000000G
                                            FILL.BUFF:
                                                              R1. $SAVES
                                                                                                                                              3953
000004 005746
                                                     TST
                                                              -(SP)
000006
        032737
                 000100 000000G
                                                     BIT
                                                              #100.SWP.FLAGS
                                                                                                                                              3987
000014
        001403
                                                     BEQ
000016 012703
                 000000G
                                                     MOV
                                                              #SWP.UCNT.R3
                                                                                                  : *, DP. ADDR
                                                                                                                                              3989
000022
        000443
                                                     BR
                                                                                                                                              3987
000024
        013700
                 000000G
                                                              SWP. DPAT. RO
                                            18:
                                                     MOV
                                                                                                                                              3993
000030
         001402
                                                     BEQ
000032
        010001
                                                     MOV
                                                              RO.R1
                                                                                                  : A.DP.NUM
                                                                                                                                              3995
000034
         000414
                                                     BR
                                                              3
                                                                                                                                              3993
000036
        013700
                 000000G
                                            21:
                                                     MOV
                                                              L$LUN, RO
                                                                                                                                              3998
000042
        062700
                 0000501
                                                     ADD
                                                              #DPST,RO
000046
        005001
                                                                                                 : DP.NUM
                                                     CLR
000050
        151001
                                                              (RO).R1
                                                                                                 . . DP. NUM
```

						010		
ZRQAM3 VO1.2		RD/RX EXER	RCISER VE TEST ROUTI	NES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK#USER2:[DIETZ.RDRX]ZRQACO.B	SEQ 0369 Page 114 L2;161 (32)
000052 000054	105210 121027	000025			INCB CMPB BLOS	(RO) (RO),#25 3#		3999 4001
000062 000066 000070	101402 112710 010100 006300	000001		3\$:	MOVB MOV ASL	#1.(RO) R1.RO	DP.NUM.	4003 4007
000060 000062 000066 000070 000072 000076 000102	016003 020127 103413	0010641			MOV CMP BLO	DPA.TBL-2(RO),R3 R1,#21 5# MAD1,RO R1 4# 46(RO),2(R3)	: #.DP.ADDR : DP.NUM.*	4009
000104 000110 000112	013700 006001 103004	000104			MOV ROR BCC	MAD1,RO R1 4\$	DP.NUM	4014 4012
000114 000122 000124	016063 000403 016063	000046 00	00002	4#: 5#:	MOV BR MOV	46(R0),2(R3) 5# 46(R0),4(R3)	: *,*(DP.ADDR) : *,*(DP.ADDR)	4014 4012 4016
000132 000136 000142	013700	0001041		5#:	MOV MOV	5# 46(R0),4(R3) MAD1,R0 32(R0),R5 (R3),R2 #2.R4 R3,R4 R4.(SP)	#.IOB.ADDR DP.ADDR.COUNT	4020
000144 000150 000152	011302 012704 060304 010416	000002			MOV ADD MOV	#2.R4 R3,R4 R4.(SP) 26(R0),-(SP)	DP.ADDR.*  *.SRC.ADDR	4022
000154	010416 016046 005216 012746	000026 00000G			HOV INC HOV	(SP) #2,-(SP)		4024
000172 000174	004737 005001 000412				JSR CLR BR	PC.BL*DIV R1 7\$	1 N	
000202	017625 062766 005302 001003	000002 00	00004	64:	ADD DEC	94(SP),(R5)+ #2,4(SP) R2	: SRC.ADDR, IOB.ADDR : *.SRC.ADDR : COUNT	4026 4028 4029
000110 000112 000114 000122 000124 000132 000136 000142 000150 000152 000154 000160 000162 000166 000172 000174 000176 000202 000210 000212 000214 000224 000224 000226 000230 000230	011302 010466 005201 020100	000004		76:	BNE MOV MOV INC	7\$ 94(SP),(R5)+ \$2.4(SP) R2 7\$ (R3),R2 R4.4(SP) R1 R1,R0	DP.ADDR.COUNT  *.SRC.ADDR	4031 4034 4035
000224 000226	020100 003763 062706	000006		/•:	CMP	•	: N . +	4024
000234	000207	00000			ADD RTS	♦6.SP PC		3953

<sup>:</sup> Routine Size: 79 words. Routine Base: #CODE# + 15742 : Maximum stack depth per invocation: 10 words

```
SEQ 0370
ZRQAM3
                 RD/RX EXERCISER
                                                                      14-Dec-1983 16:12:07
                                                                                                 VAX-11 Bliss-16 V3-555
                                                                                                                                         Page 115
                                                                      14-Dec-1983 16:12:00
V01.2
                 MULTI-DRIVE TEST ROUTINES
                                                                                                 DISK#USER2: [DIETZ.RDRX]ZRQACO.BL2:161 (33)
           4041 routine PROC_RETPKT : novalue =
           4042
           4043 ! .
:
           4044 !
                          THIS ROUTINE IS CALLED FROM THE MULTI_DRIVE "EXECUTIVE" AND DUP_COMMAND TO CHECK FOR
           4045
                          AND PROCESS ANY RETURN PACKETS THAT HAVE BEEN "SENT" BY THE "DRIVER"
                          PORTION OF THE PROGRAM, THE I/O DONE QUEUE (IODQ) ACTS AS THE LINK BETWEEN THE TWO PROGRAM PARTS: IT HOLDS INDECES OF RETURN PACKETS WHICH
           4046
           4047
.
           4048
                          REQUIRE PROCESSING.
:
           4049
.
           4050
                          UNDER THE MULTI-DRIVE TEST, RETURN PACKETS ORIGINATE FROM TWO SOURCES:
:
           4051
                                   1. MSCP
                                                     - THE MORE COMMON, DESCRIBING A COMPLETED I/O
.
           4052
                                                     OPERATION.
           4053
                                   2. DUP
                                                     - THE LESS COMMON, DESCRIBING A PORTION OF I/O
.
           4054
                                                     COMMUNICATIONS WITH THE CONTROLLER PROGRAM.
:
           4055
                                   3. THE PROGRAM "DRIVER" - DESCRIBING A CONTROLLER ERROR OR
:
                                                     COMMAND TIMEOUT.
           4056
:
           4057 !-
:
           4058
:
           4059
                      while .IODQ_IN neg .IODQ_OUT do
                                                                                        ! DO UNTIL I/O DONE QUEUE IS EMPTY
                          begin
RP_INDX = OUT_IODQ ();
RP_ADDR = RETPKT + (.RP_INDX + RP_LEN + 2);
if NOT (.RP_ADDR [CONID] eql CID_DUP)
then (SET_CPAR (.RP_ADDR [CTLR]););
           4060
.
           4061
                                                                                        ! GET INDEX OF NEXT RETPKT AND ADVANCE OUT POINTER
.
           4062
                                                                                        ! CALCULATE RETPKT ADDRESS
.
           4063
:
                                                                                        ! if not DUP than
           4064
                                                                                        ! SET UP CURRENT CONTROLLER PARAMETERS
:
           4065
           4066
                          selectoneu .RP_ADDR [CONID] of
.
                                                                                     ! CONNECTION ID INDICATES PACKET SOURCE
           4067
                               set
.
           4068
:
           4069
                               [CID_MSCP] :
                                                     IO_RETPKT ();
                                                                                        ! DISK MSCP (I/O TRANSFER DONE)
:
           4070
                               [CID_DUP] :
                                                     DIO_RETPKT ();
.
                                                                                         ! DUP (I/O TRANSFER DONE)
           4071
                               [CID DRIVER] :
                                                     DR_RETPKT ():
                                                                                        ! MESSAGE FROM "DRIVER"
           4072
.
           4073
                               [otherwise] :
                                                     PRINTF (DBM12. .RP_ADDR [CONID]): "CONN ID = XXXXX RECEIVED"
.
           4074
:
                               tes;
           4075
:
           4076
                          end:
:
                                                                                         ! UNITL I/O DONE QUEUE IS EMPTY
                                                      .SBTTL PROC.RETPKT MULTI-DRIVE TEST ROUTINES
000000 010146
                                            PROC.RETPKT:
                                                              R1,-(SP)
                                                     MOV
                                                                                                                                              4041
000002 023737 000000G 000000G
                                                              IODQ. IN, IODQ. OUT
                                                     CMP
                                                                                                                                              4059
000010 001467
                                                     BEQ
000012 004737
                                                              PC.OUT.IODQ
                 000000G
                                                     JSR
                                                                                                                                              4061
000016 010037
                 000000G
                                                              RO, RP. INDX
000022 010046
                                                     MOV
                                                              RO,-(SP)
                                                                                                  : RP.INDX.+
                                                                                                                                              4062
000024
        012746
                 000060
                                                     MOV
000030 004737
                 000000G
                                                     JSR
                                                              PC.BL #MUL
000034
        062700
                 000000G
                                                     ADD
                                                              MRETPKT, RO
000040
        010037
                 000000G
                                                     MOV
                                                              RO, RP. ADDR
000044
         126027
                 000003 000002
                                                     CMPB
                                                              3(RO), #2
                                                                                                                                              4063
        001406
000052
                                                     BEQ
000054
        116016 000002
                                                              2(RO),(SP)
                                                     MOVB
                                                                                                                                              4064
```

	ZRQAM3 VO1.2		RD/RX EXERCISÉR MULTI-DRIVE TEST ROUT	INES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK*USER2:[DIETZ.RDRX]ZRQACO.8L2	SEQ 0371 Page 116 1:161 (33)
	000060 000064 000070 000074	042716 004737 013700 005001	177760 000000G 000000G	24:	BIC JSR MOV CLR	#177760,(SP) PC,SET.CPAR RP.ADDR,RO R1		4066
	000076 000102 000104 000106	156001 005701 001003 004737	000003 000000V		BISB TST BNE	3(RO),R1 R1 3\$		
	000112 000114 000120	000424 020127 001003	000002	34:	JSR BR CMP BNE	PC,IO.RETPKT 6\$ R1.#2 4\$		4069 4066
	000122 000126 000130 000134	004737 000416 020127 001003	000000V 000003	41:	JSR BR CMP BNE	PC.DIO.RETPKT 6\$ R1.#3 5\$		4070 4066
	000136 000142 000144 000146	004737 000410 010116 012746	000000V	5#:	JSR BR MOV MOV	PC.DR.RETPKT 6\$ R1.(SP) #DBM12(SP)		4071 4066 4073
	000152 000156 000160 000162	012746 010600 104417 022626	000002		MOV MOV TRAP	♦2,-(SP) SP,R0 17	; SP.4	
-	000164 000166 000170 000172	022626 000705 012601 000207		6\$: 7\$:	CMP CMP BR MOV RTS	(SP)+,(SP)+ (SP)+,(SP)+ 1\$ (SP)+,R1 PC		4060 4059 4041

<sup>:</sup> Routine Size: 62 words. Routine Base: #CODE# + 16200 : Maximum stack depth per invocation: 7 words

SEQ 0372

```
ZRQAM3
                                  RD/RX EXERCISER
                                                                                                                                         14-Dec-1983 16:12:07
                                                                                                                                                                                             VAX-11 Bliss-16 V3-555
                                                                                                                                                                                             VAX-11 Bliss-16 V3-555 Page 117 DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (34)
                                  MULTI-DRIVE TEST ROUTINES
V01.2
                                                                                                                                         14-Dec-1983 16:12:00
                      4077 !+
                     4078 ROUTINE DIO_RETPKT : NOVALUE =
:
                      4079
:
                     4080 !+
.
                      4081
                                  .
                                                    THIS ROUTINE IS CALLED BY PROC_RETPKT TO HANDLE ALL DUP I/O TRANSFER
.
                      4082
                                                    RETURN PACKETS. PROCESSING OF THESE PACKETS INCLUDES DECLARING ANY
:
                      4083
                                                    HARD ERRORS THAT MAY HAVE OCCURRED. UPDATING THE STATISTICS.
:
                      4084
:
                      4085
                                                    IMPLICIT IMPUTS:
                      4086
                                                                     RP_ADDR - ADDRESS OF THE CURRENT RETURN PACKET
                      4087
                                                                     T_ADDR - ADDRESS OF THE CURRENT UNIT'S STATISTICS BLOCK (TALLY)
.
                                                                     CST_ADDR - ADDRESS OF THE CURRENT CONTROLLER'S CST
DUOFF - CST OFFSET FOR THE CURRENT UNIT
                      4088
:
                      4089
.
                                                                     L$LUN - CURRENT UNIT NUMBER
CCTLR - CURRENT CONTROLLER NUMBER
                      4090
:
                      4091
:
                      4092
                                                   IMPLICIT OUTPUTS
                      4093
                      4094
                                                                     CST_ADDR [.DUOFF + 5. NODUPMEDIA] - IF THIS BIT SET NO DUP EXERCISER
.
                      4095
.
                      4096
.
                                  BEGIN
                      4097
                      4098
                      4099
                                LOCAL
                                                   FLAG : BYTE INITIAL(BYTE(TRUE)).
                      4100
                                                    SUM2 : WORD,
.
                      4101
                                                    SUM : WORD:
                                                                                                                                                  ! TOTAL NUMBER OF BYTES TRANSFERRED TO/FROM A UNIT
.
                                  !PRINTX (DER18);
                      4102
2
                      4103
:
                      4104
                                 IF .RP_ADDR (STATUS) NEQU ST_SUC
.
                                                                                                                                                                         ! IF STATUS CODE INDICATES ERROR
                      4105 THEN
                      4106
                                                    BEGIN
.
                      4107
                                                    CST_ADDR [.DUOFF + 5, DUPERROR] = 1;
.
                                                                                                                                                       ! SET DUP ERROR FLAG
                                                    HARD_ERROR ();
                      4108
.
                                                    IF .RP_ADDR (ENDCOD) EQLU (OP_ELP + OP_END) OR ! IF ENDCODE IS EXECUTE LOCAL PROGRAM .RP_ADDR (ENDCOD) EQLU (OP_GDS + OP_END) ! OR GET DUST STATUS
                      4109
:
                      4110
                      4111
:
                                                                     BEGIN
                      4112
                                                                     CST_ADDR [.DUOFF + 5, NODUPMEDIA] = 1:
.
                                                                                                                                                                                          ! TURN OFF DUP EXERCISE
                      4113
:
                      4114
                                                    END
:
                      4115 ELSE
:
                                                                                                                                         ! ELSE - I/O WAS SUCCESSFUL
                      4116
                      4117
:
                      4118
                                           IF .RP_ADDR [ENDCOD] EQLU (OP_GDS + OP_END) ! IF ENDCODE IS GET DUST STATUS
.
                      4119
                                            THEN
.
                      4120
:
                                                    BEGIN
                      4121
                                                    IF .RP_ADDR [9,11,1,0] EQL 1
:
                                                                     THEN CST_ADDR (.DUOFF + 5, D_ACTIVE) = ACTIVE ! CONTROLLER IN AN ACTIVE STAE ELSE CST_ADDR (.DUOFF + 5, D_ACTIVE) = IDLE; ! CONTROLLER IN AN IDLE STATE | CO
                      4122
:
                      4123
:
                      4124
                                                    IF .RP_ADDR (9,9,1,0) NEQ 1 THEN
:
                      4125
:
                                                                     BEGIN
                      4126
                                                                     HARD_ERROR ();
.
                      4127
                                                                     CST_ADDR [.DUOFF + 5, NODUPMEDIA] = 1;
:
                                                                                                                                                                              ! TURN OFF DUP EXERCISE
                      4128
:
                                                                     END:
                      4129
                                                    END:
:
```

ZRQAM3 VO1.2		RD/RX EXERCISER MULTI-DRIVE TEST ROU	TINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK#USER2:[DIETZ.RDRX]ZRQACO.E	SEQ 0373 Page 118 SL2;161 (34)
	4121	IF (.RP_ADDR [ENDCOD (.DUPPKT [DUPTYPE (.DUPPKT [DUPMESG (.CST_ADDR [.DUOF THEN DUP_COM	PARE ();	OP_END)) A	!IF IT IS A RECEIVE D ! IF WRITE FLAG SET IN ! COMPARE THE FOLLOWIN	BN COMMAND WITH TYPE 6 AND MESSAG CST TABLE THEN COMPARE BLOCKS	SE 2 THEN
	4139	PUT_RETPKT (.RP_INDX	);		! ROUTINE DIO_RETPKT		
000000 0	10146		.SB DIO.RETPKT:	TTL DIO.RE	ETPKT MULTI-DRIVE TEST RO	UTINES	
	20240		MOV	R1,-(5	SP)		4078
000002 11	12700	000001 000000G	MOV	B #1.RO		# .FLAG	4097
000006 0	13701	00000G	MOV	RP. ADD	OR,R1		4104
	05761	000016	TST	16(R1)			
000016 00 000020 01 000024 00 000032 01 000040 00 000044 01 000050 11 000056 00 000060 11 000066 00 000070 01 000074 00	01435 13700	001150'	BEQ MOV	DUOFF,	PA .		4107
000024 0	06300	001130	ASI	RO	, RO	•	4107
000026 0	63700	000000G	ASL ADD	CST. AL	DDR,RO		
000032 0	63700 52760 04737	000000G 040000 000012 000000G	BIS	#40000	0.12(RO)		
000040 00	04737	000000V	JSR	PC.HAF	0.12(RO) RD.ERROR DR.RO		4108
000044 0	13700	00000G	MOV	RP. ADD	OR, RO		4109
000050 1	26027 01404	000014 000203	CMP	B 14(RO)	0.4203		
000056 00	01404		BEQ	1\$			
000066	26027	000014 000201	CMP		0.0201	•	4110
0000000 00	01112	001150/	BNE	6\$	00		****
000074 0	13700 06300	001150'	1#: MOV	DUOFF, RO	, RO	•	4112
000076 0	63700	000000G	ADD		008.80		
000102 0	52760	100000 000012	BIS	<b>#1000</b>	DDR.RO DO.12(RO)		
000110 0	00501		BR	6\$			4104
000112 1	26127	000014 000201	24: CMP	B 14(R1	0.4201		4118
000120 0	01036		BNE	5#			
000136 0	13700	001150'	MOV	DUOFF	, RO		4122
000126 0	06300 63700	000000G	ASL	RO	000 00		
000134 0	32761	004000 000022	ADD BIT	64000	DDR.RO ,22(R1)		4121
000142 0	01404		REO	34	(66/41)		4121
000144 0	52760	020000 000012	BEQ	<b>#2000</b> 0	0.12(RO)		4122
000152 0	00403		BR	48			4121
000130 00 000134 03 000142 00 000144 03 000152 00 000154 04 000162 03 000170 00 000172 00	01404 52760 00403 42760	020000 000012	34: BIC	<b>#20000</b>	0.12(RO)		4123
000162 0	32761	001000 000022	44: BIT	<b>#1000</b>	.22(R1)		4124
000170 0	01012	0000001	BNE	58			
000172 0	04737 13700	000000V	JSR		RD.ERROR		4126
L COOTIO O	06300	001150'	MOV	DUOFF, RO	, RU		4127
000204 0	63700	000000G	ADD		DDR,RO		
000210 0	52760	100000 000012	BIS		00,12(RO)		
			-				

	11	7
	1	4
_		-

-	ZRQAM3 VO1.2		RD/RX EXE		ROUTINES		14-Dec-1983 16 14-Dec-1983 16	5:12:07 5:12:00	VAX-11 Bliss-16 V3-555 DISK*USER2:[DIETZ.RDRX]ZRQACO	SEQ 0374 Page 119 0.BL2:161 (34)
-	000216 000222 000230	013700 126027 001031	000000G 000014 0	000205	5\$:	MOV CMPB BNE	RP.ADDR.RO 14(RO).#205 6\$		•	4132
-	000232 000236 000242 000246	013700 042700 020027 001022	000000G 007777 060000			MOV BIC CMP BNE	DUPPKT,RO #7777,RO RO,#60000			4133
-	000250 000254 000260 000264	013700 042700 020027 001013	000000G 170000 000002			MOV BIC CMP BNE	DUPPKT,RO #170000,RO RO,#2 6\$			4134
	000266 000272 000274 000300 000306	013700 006300 063700 032760 001402	001150' 000000G 010000 0	000012		MOV ASL ADD BIT BEQ	DUOFF,RO RO CST.ADDR,RO #10000,12(RO)			4135
	000310 000314 000320	004737 013746 004737	000000V 000000G 000000G		6\$:	JSR MOV JSR	PC.DUP.COMPARE RP.INDX,-(SP) PC.PUT.RETPKT		:	4136 4140
-	000324 000326 000330	005726 012601 000207				TST MOV RTS	(SP)+ (SP)+,R1 PC		:	4097 4078

<sup>:</sup> Routine Size: 109 words. Routine Base: \$CODE\$ + 16374 : Maximum stack depth per invocation: 3 words

.

```
SEQ 0375
ZRQAM3
                  RD/RX EXERCISER
                                                                          14-Dec-1983 16:12:07
                                                                                                      VAX-11 Bliss-16 V3-555 Page 120 DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (35)
                                                                                                      VAX-11 Bliss-16 V3-555
                  MULTI-DRIVE TEST ROUTINES
V01.2
                                                                          14-Dec-1983 16:12:00
                 ROUTINE DUP_COMPARE : NOVALUE =
           4143
           4144
:
           4145
.
           4146
                  ! +
           4147
                            THIS ROUTINE IS CALLED BY DIO_RETPKT WHEN THE RECEIVE DATA COMMAND
           4148
                            IS BEING PROCESSED. THIS COMMAND COMPARES THE WRITTEN BUFFER WITH
.
                           THE PATERN WORD GIVEN IN SEND DATA COMMAND. FOR EVERY WORD COMPARED THE ROUTINE INCREMENTS THE TALLY TABLE. IF THE COMPARE SHOWS AN ERROR. THE DBN HARD ERROR COUNTER WILL BE INCREMENTED AND THE
           4149
.
           4150
           4151
           4152
                            THE DBN NUMBER AND BYTE COUNT WILL BE PRINTED.
:
           4153
           4154
                            IMPLICIT INPUTS:
                                     S_PATTERN
           4155
                                                       ! THE SAVED PATTERN WRITTEN TO THE DBN'S
.
           4156
                                     S_DUPPKT
                                                       ! THE POINTER FOR DUP BUFFER
.
                                                       ! THE ADDRESS OF THE TALLY TABLE FOR THIS UNIT ! THE ADDRESS OF PRESENT CONTROLLER STATUS TABLE
           4157
                                     T_ADDR
.
                                     CST_ADDR
           4158
           4159
                  BEGIN
           4160
           4161
           4162
                  OWN
           4163
                            COUNT : WORD:
.
           4164
                  !PRINTX (DER19);
           4165
           4166
                  S DUPPKT . O:
                  INCR COUNT FROM 1 TO 256 DO
           4167
                                                       !INDEX PIONTER FOR DATA STORED IN MSCP ENV PACKET
           4168
                            BEGIN
                            S_DUPPKT = .S_DUPPKT + 2:

IF .(DUPPKT + .S_DUPPKT) NEQ .S_PATTERN THEN
           4169
                                                                                             ! INITIALLY THIS SKIPS THE FIRST WORD OF DUPPKT
           4170
                                                                                             ! IF THE CONTENTS OF DBN DOESN'T EQUAL PATTERN
           4171
                                     BEGIN
           4172
                                     CST_ADDR [.DUOFF + 5, DUPERROR] = 1;
                                                                                             ! SET DUP ERROR FLAG
           4173
                                     ERRHRD (46, EH_10, EMS_22);
                                                                                             !LIST ERROR
            4174
:
                                     EXITLOOP:
           4175
                                     END:
.
           4176
                            END:
                                                                          !GO THROUGH ALL DBN WORDS
           4177 END:
                                                                          !END ROUTINE DUP-COMPARE
001164
                                                        .PSECT #GGG#. RO
001164
                                              COUNT:
                                                        .BLKW
                                                        .SBTTL
.PSECT
                                                                 DUP. COMPARE MULTI-DRIVE TEST ROUTINES
016726
                                                                 $CODE$, RO
000000 010146
                                              DUP. COMPARE:
                                                        MOV
                                                                 R1,-(SP)
                                                                                                                                                     4143
000002 005037
                  000000G
                                                        CLR
                                                                 S. DUPPKT
                                                                                                                                                     4166
000006
        012701
                  000400
                                                                 4400,R1
                                                                                                         +. COUNT
                                                                                                                                                     4167
000012
         062737
                  000002 000000G
                                                        ADD
                                                                 42.S.DUPPKT
                                              18:
                                                                                                                                                     4169
000020
         013700
                                                        MOV
                  000000G
                                                                 S.DUPPKT, RO
                                                                                                                                                     4170
000024
         026037
                  000000G 000000G
                                                        CMP
                                                                 DUPPKT(RO), S. PATTERN
000032
         001415
                                                        BEQ
```

## N13

-	ZRQAM3 VO1.2		RD/RX EXERCISER MULTI-DRIVE TEST ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2;	Page 121 161 (35)
	000034 000040 000042 000046	013700 006300 063700 052760	001150' 000000G 040000 000012	MOV ASL ADD	DUOFF,RO RO CST.ADDR,RO		4172
	000054 000056 000060 000062	104456 000056 000000G		BIS TRAP .WORD .WORD .WORD	#40000,12(R0) 56 56 EH.10 EMS.22		4173
-	000064 000066 000070	000402 005301 001350	2\$:	BR DEC BNE	3\$ R1 1\$	COUNT	4171 4167
	000072 000074	012601 000207	3\$:	MOV	(SP)+,R1 PC		4143

Routine Size: 31 words, Routine Base: \$CODE\$ + 16726 : Maximum stack depth per invocation: 3 words

<sup>4178</sup> 4179 4180

Page 122

```
SEQ 0377
ZRQAM3
                  RD/RX EXERCISER
                                                                          14-Dec-1983 16:12:07
14-Dec-1983 16:12:00
                                                                                                      VAX-11 Bliss-16 V3-555
V01.2
                  MULTI-DRIVE TEST ROUTINES
                                                                                                      DISK&USER2: [DIETZ.RDRX]ZRQACO.BL2:161 (36)
           4181 routine IO_RETPKT : novalue =
           4182
           4183 ! .
           4184 !
                           THIS ROUTINE IS CALLED BY PROC_RETPKT TO HANDLE ALL I/O TRANSFER RETURN PACKETS. PROCESSING OF THESE PACKETS INCLUDES DECLARING ANY
           4185
                           HARD ERRORS THAT MAY HAVE OCCURRED, UPDATING THE STATISTICS, AND
           4186
           4187
                           PERFORMING HOST WRITE-COMPARES IF REQUIRED.
           4188
           4189
                            IMPLICIT IMPUTS:
                                     CST_ADDR - ADDRESS OF CURRENT CONTROLLER'S CST
RP_ADDR - ADDRESS OF THE CURRENT RETURN PACKET
           4190
           4191
                                     T_ADDR - ADDRESS OF CURRENT UNIT'S STATISTICS BLOCK (TALLY)
           4192
           4193
                                     CCTLR - CURRENT CONTROLLER NUMBER
           4194 !
                                     L$LUN - CURRENT UNIT NUMBER
           4195 !-
           4196
           4197
                       begin
           4198
           4199
                       local
           4200
                           FLAG : byte initial (byte (TRUE));
           4201
                       FSET_UPAR ();
ST_CODE = .RP_ADDR [STSCOD];
SB_CODE = .RP_ADDR [SUBCOD];
           4202
                                                                          ! FIND UNIT'S ENTRY IS CST AND SET UP UNIT-RELATED DATA
           4203
                                                                          ! GET STATUS CODE FROM RETPKT
           4204
                                                                          ! GET SUB-CODE, IF ANY
           4205
           4206
                       if (.ST_CODE neg ST_SUC)
                                                                 ! IF STATUS CODE INDICATES ERROR
           4207
                       then
           4208
                           begin
HARD_ERROR ();
           4209
                                                                          ! UPDATE ERROR COUNT
           4210
                            COMPARE_DATA . FALSE:
                                                                          ! NO POINT IN DOING HOST COMPARES ON ERROR
           4211
                           if (.ST_CODE neg ST_OFL) and
  (.st_code neg ST_AVL) and
  (.T_ADDR [ERR_HARD] gequ .SWP_ERROR)
           4212
                                                                          ! DROP UNIT IF ERROR COUNTS EXCEEDS LIMIT
           4213
           4214
           4215
                            then
           4216
                                DUR [ .L &LUN] - DU_HERR;
           4217
                                                                          ! LOAD REASON FOR DROPPING UNIT
           4218
                                DODU (.L&LUN);
                                                                          ! DROP UNIT
           4219
                                end;
           4220
           4221
                           end;
           4222
           4223
                       if .ST_CODE eql ST_SUC
                                                                         ! IF I/O WAS SUCCESSFUL
           4224
                       then
           4225
4226
                           begin
UPO_IO_TALLY ();
                                                                          ! UPDATE I/O TALLY (STATISTICS)
           4227
           4228
                            if .RP_AGOR [ENDCOD] eql (OP_WRT or OP_END)
           4229
                            then COMPARE_DATA . TRUE:
                                                                          ! HOST COMPARES MAY BE ALLOWED IF NO FURTHER ERRORS
           4230
           4231
                            IF (BIT_TST (SWP_FLAGS, SWF_HWC)) and ! IF HOST IS DOING WRITE-COMPARES
           4232
                               (.COMPARE_DATA)
           4233
                            then
```

ZRQAM3		RD/RX EX	KERCISER	N.F.C	14-Dec-1983 16:	12:07 VAX-11 Bliss-16 V3-55	SEQ 0378 Page 12
01.2		HOL II-DE	TAE IEZI KOOIT	Can	14-Dec-1983 16:	12:00 DISK \$USER2:[DIETZ.RDR	X JZRQACO.BL2;161 (36)
	4234		FLAG - HOS	T_WRT_CHK ();	! SAVE I/O PACK	ET OR DO WRITE-CHECK	
	4235						
	4236		end;				
	4237		F: 40				
	4238		FLAG		! IF FLAG IS ST	ILL TRUE	
	4239 4240	ther					
	4241		SWEEP ();		! DEALLOCATE BU	FFER(S) AND RETPRT(S)	
	4242	OIO	[.CCTLR]QT	O [ .CCTLR] - 1.	I DECREMENT NO	OF OUTSTANDING OTOS	
	4243	end	1		! DECREMENT NO. ! ROUTINE IO_RE	TPKT	
				.SBTTL	IO.RETPKT MULTI-DRIVE TO	EST ROUTINES	
000000	004137	000000G		IO.RETPKT:			
				JSR	R1. \$SAVE2	,	418
00004	112701	000001		MOVB	R1.#SAVE2 #1.R1 PC.FSET.UPAR RP.ADDR.RO 16(RO).ST.CODE	: +,FLAG	419
00010	004737	000000V		JSR	PC,FSET.UPAR		420
00014	013700	000000G	0000000	MOV	RP. ADDR, RO		420
00026	116037 042737	177740	000000G 000000G	MOVB	ALTTTAN ST. CODE		
00034	016002	000016	000000	MOV	#177740,ST.CODE 16(RO),R2		
2222	006202	000010		ASR	R2		420
00042	006202			ASR	R2		
00044	006202			ASR	R2 R2		
00046	006202			ASR	R2		
00050	006202 006202 006202 042702			ASR	R2		
00042 00044 00046 00050 00052 00056 00062	042702	174000		BIC	#174000.R2		
000056	010237	000000G		MOV	R2.SB.CODE		
200005	005737	000000G		TST	ST.CODE	1	420
000070	001433 004737	000000V		BEQ	21		
000074	105037	001152		JSR CLRB	PC, HARD. ERROR		420
00100	023727	000000G	000003	CMP	COMPARE.DATA ST.CODE,#3		421
00106	001420	000000	000003	BEQ	1#		421
000110	023727	000000G	000004	CMP	ST.CODE.04		431
000116	001414			BEQ	16		421
00120	013700	000000G		MOV	T.ADDR,RO		421
00124	026037 103406	000014	000000G	CMP	14(RO), SWP. ERROR		
00132	103406	*******		BLO	14		
00134	013700	000000G	0000000	MOV	L\$LUN,RO		421
00146	112760 104451	000004	0000000	MOVB	#4.DUR(RO)		
000150	005737	000000G		TRAP	51		42:
00150 00154	001026	000000		14: TST BNE	ST.CODE		420
00156	004737	000000V		24: JSR	PC,UPD.IO.TALLY		420
00162	013700	000000G		MOV	RP. ADDR. RO		423
00166	126027	000014	000242	CMPB	14(RO).0242		423
00174	001003			BNE	34		
00176	112737	000001	0011521	MOVB	#1, COMPARE. DATA		42
00204	032737	000040	000000G	34: BIT	440, SWP.FLAGS		42
212000	001407			BEQ	41		
000214	032737	000001	001152'	BIT	#1.COMPARE.DATA		423
000222	001403			BEQ	41		

ZRQAM3 VO1.2		RD/RX EXERCISER MULTI-DRIVE TEST ROUT	INES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.E	SEQ 0379 Page 124 BL2;161 (36)
000224	004737 110001	000000V		JSR MOVB	PC.HOST.WRT.CHK	FLAG	4234
000232 000234	006001		41:	ROR BCC	R1 5#	FLAG	4238
000236 000242 000246	004737 013700 105360	000000V 000000G 000000G	5#:	JSR MOV DECB	PC.SWEEP CCTLR,RO QIO(RO)	:	4240 4242
000252	000207	000000		RTS	PC		4181

<sup>:</sup> Routine Size: 86 words. Routine Base: \$CODE\$ + 17024 : Maximum stack depth per invocation: 5 words

						SEO 0790
ZRQAM3 VO1.2		RD/RX EXERCISER MULTI-DRIVE TEST ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO	SEQ 0380 Page 125 .BL2;161 (37)
:	4244	routine FSET_UPAR : novalue =				
	4245 4246	1.				
:	4247	THIS ROUTINE IS CALLED	BY TO RETPET	AND OTHERS TO SEARCH THE	CIPPENT	
	4248	! CONTROLLER STATUS TABLE	E (CST) FOR TH	E DISK ADDRESS WHICH IS		
	4249	! CONTAINED IN THE CURRE	NT RETURN PACKI	ET. WHEN FOUND. THE OFFSET	T INTO THE	
	4250 4251	DATA PARAMETERS.	D SET_UPAR, WH	ICH SETS UP CURRENT UNIT-	RELATED	
	4252	PATA PARAMETERS.				
:	4253	! IMPLICIT INPUTS:				
	4254	P_ADDR - ADDR	ESS OF CURRENT	RETURN PACKET		
:	4255 4256	CST_ADDR - ADD	RESS OF CURREN	T CONTROLLER'S CST		
	4257					
:	4258	begin				
:	4259 4260	ions OFFSET from (A . OF II	W A- /7 - INT	7 6776 - 05 1813 5 18177 61		
:	4261	THE OFFSET FROM (O + OF_O	M) £0 (2 * ONT	1_SIZE + UF_UN) By UNIT_S	IZE do ! FOR EACH UNIT IN CS	
	4262	if .CST_ADDR [.OFFSET,	D_DISK_NUM) e	ql .RP_ADDR [DISK]		
	4263			! IF RETPKT UNIT NUMBE	ER MATCHES CST ENTRY	
:	4264 4265	then begin				
	4266	SET_UPAR (.OFFSET)	:	! SET UP UNIT-RELATED	DATA	
:	4267	return;		! DONE		
•	4268 4269	end;				
	4270	PRINTF (DBM19, .RP_ADDR [D	ISK1CCTLR):	! "CAN'T FIND DISK XX	K IN CST X"	
	4271	end;		! ROUTINE FSET_UPAR		
			.SBTTL FSET	.UPAR MULTI-DRIVE TEST ROL	JTINES	
000000	004137	000000G FSET.U	PAR:			
000004	012702	000003	JSR R1.#	SAVE4	- OFFICET	4244
000010	010201	16:	MOV R2.R	1	: *.OFFSET : OFFSET.*	4260 4262
000012	006301		ASL. R1		1 0 52.10	4505
000014	063701	000000G 000000G	AD() CST.	ADDR,R1		
000024	016004	000010	MOV RP. A	DDR,RO		
000024 000030 000032	111103 042703		MOVB (R1)	0),R4 ,R3 774,R3		
000032	042703	177774	BIC #177	774,R3		
000036	020304 001005		CMP R3,R			
000042	010246		BNE 24 MOV R2,-	(SP)	: OFFSET. *	4266
000044	010246 004737	000000G	JSR PC.S	ET.UPAR	1 017 321,0	4200
000050	005726		TST (SP)			4262
000036 000040 000042 000044 000050 000052	000207 062702	000007 28:	RTS PC ADD #7,R		- OFFCET	4265
000060	020227	000030	CMP R2.0		: 4,OFFSET : OFFSET, 4	4260
000060 000064 000066	003751		BLE 1\$			
000066	013746 013700	000000G 000000G		R,-(SP)		4270
000076	016046	000010		DDR,RO O),-(SP)		
		******	TO(M	V/1-( 3F /		

ZRO	AM3	RD/RX EXERCISER MULTI-DRIVE TEST ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 Page DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (37	126
000	0102 012746 0106 012746 0112 010600 0114 104417	000003	MOV MOV MOV TRAP	#DBM19,-(SP) #3,-(SP) SP,R0 17	; SP.*	
000	0116 062706 0122 000207	000010	ADD RTS	#10.SP PC		258 244

<sup>:</sup> Routine Size: 42 words. Routine Base: \$CODE\$ + 17300 : Maximum stack depth per invocation: 11 words

SEQ 0382

```
ZRQAM3
                  RD/RX EXERCISER
                                                                          14-Dec-1983 16:12:07
                                                                                                       VAX-11 Bliss-16 V3-555 Page 127 DISK*USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (38)
                  MULTI-DRIVE TEST ROUTINES
                                                                          14-Dec-1983 16:12:00
V01.2
           4272 routine HARD_ERROR : novalue =
           4273
.
           4274
                 . .
                           THIS ROUTINE IS CALLED BY IO_RETPKT, DIO_RETPKT, AND OTHERS TO INCREMENT THE HARD ERROR STATISTIC FIELD FOR THE CURRENT UNIT. IF THE HARD ERROR COUNT
           4275
           4276
.
           4277
                            HAS EXCEEDED THE OPERATOR-SPECIFIED LIMIT, THEN THE UNIT IS DROPPED
           4278
                            FROM TESTING.
           4279
                            IMPLICIT INPUTS:
           4280
.
                                     L$LUN - CURRENT UNIT NUMBER
            4281
:
                                     CST_ADDR - ADDRESS OF CURRENT CONTROLLER'S CST
            4282
.
                                     CUOFF - CST OFFSET FOR CURRENT UNIT
           4283
.
           4284
                                     T_ADDR - ADDRESS OF CURRENT UNIT'S STATISTICS BLOCK (TALLY)
:
            4285
.
           4286
:
           4287
                  begin

T_ADDR [ERR_HARD] = .T_ADDR [ERR_HARD] + 1;

if .RP_ADDR [CONID] EQL CID_MSCP
:
           4288
                                                                                                                ! INCREMENT UNIT'S HARD ERROR COUNT
.
           4289
.
           4290
                  THEN
:
            4291
                       selectoneu .ST_CODE of
            4292
                            set
            4293
.
            4294
                            [ST_SUC]:
                                               if .SB_CODE neg 0
                                                                                                                ! SUCCESS WITH NON-ZERO SUB-CODE
.
            4295
                                               then
.
           4296
4297
:
                                                   begin
            4298
                                                    if .SB_CODE eql 4
            4299
.
                                                    then
            4300
.
           4301
                                                        T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1
.
.
                                                        end
            4303
                                                   else
            4304
                                                        T_ADDR [ERR_HRD_HST] . T_ADDR [ERR_HRD_HST] + 1;
:
            4305
.
           4306
4307
:
                                                   ERRHRD (44, EGH_30, EMS_30);
:
                                                   end:
            4308
:
            4309
                            [ST_CMD]:
                                              begin
T_ADDR (ERR_HRD_HST) - .T_ADDR (ERR_HRD_HST) + 1;
                                                                                                                ! INVALID COMMAND
            4310
                                              ERRHRD (31, EGH_30, EMS_30);
            4311
:
            4312
:
            4313
                                              T_ADDR (ERR_HRD_DRV) = .T_ADDR (ERR_HRD_DRV) + 1;
            4314
                            [ST_ABO]:
:
                                                                                                                ! COMMMAND ABORTED
            4315
            4316
            4317
            4318
.
                                              t_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
ERRDF (18, EGD_18, EMS_18);
DUR [.L$LUN] = DU_DFATAL;
            4319
                            [ST_OFL] :
                                                                                                                 ! OFFLINE
.
            4320
:
            4321
            4322
                                                                                                                 ! DEVICE FATAL ERROR
            4323
                                                                                                                ! DROP UNIT
                                               DODU (.L$LUN);
            4324
                                               end
```

			1114	
ZRQAM3 VO1.2	RD/RX EXERCISER MULTI-DRIVE TEST RO	OUTINES	14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555
	4325 4326 (ST_AVL): 4327 4328 4329 4330 4331	begin T_ADDR [ERR_HRD_DRV] = ERRDF (24, EGD_18, EMS DUR [.L\$LUN] = DU_AV; DODU (.L\$LUN); end;	.T_ADDR [ERR_HRD_DRV] +	1; ! DEVICE WENT AVAILABLE STATE ! DROP UNIT
	4332 4333 [ST_MFE]: 4334 4335 4336 4337	begin T_ADDR [ERR_HRD_SEK] = ERRHRD (35, EGH_30, EM end;	.T_ADDR [ERR_HRD_SEK] +	! MEDIA FORMAT ERROR
	4338 [ST_WPT]: 4339	begin		! DEVICE WRITE PROTECTED
	4340 4341 4342 4343	if .SB_CODE eql 128 then T_ADDR [ERR_HRD_HS else	T) = .T_ADDR (ERR_HRD_HS	7) • 1
	4344 4345	T_ADDR [ERR_HRD_DR	V) = .T_ADDR [ERR_HRD_DR	V) + 1:
	4346 4347 4348	ERRHRD (36, EGH_30, EM end;	S_30);	
	4349 [ST_CMP]: 4350 4351 4352 4353	begin T_ADDR [ERR_HRD_DAT] = ERRHRD (37, EGH_30, EM end;	.T_ADDR [ERR_HRD_DAT] +	! COMPARE ERROR
	4354 [ST_DAT]:	begin		! DATA ERROR
	4356 4357 4358	if .SB_CODE eql 2		
	4359 4360	else	K) = .T_ADDR (ERR_HRD_SE	
	4361 4362 4363 4364	ERRHRD (38, EGH_30, EM		
	4365 [ST_HST]: 4366 4367 4368 4369	begin T_ADDR [ERR_HRD_HST] = ERRHRD (39, EGH_30, EM end;	.T_ADDR [ERR_HRD_HST] +	! HOST ACCESS ERROR
	4370 [ST_CNT]: 4371 4372 4373 4374	begin T_ADDR [ERR_HRD_DRV] = ERRHRD (40, EGH_30, EM end;	.T_ADDR [ERR_HRD_DRV] +	! CONTROLLER ERROR
	4375 [ST_DRV]:	begin		! DRIVE ERROR
:	4377	if .SB_CODE eql 3		

```
SEQ 0384
ZRQAM3
                 RD/RX EXERCISER
                                                                     14-Dec-1983 16:12:07
                                                                                               VAX-11 Bliss-16 V3-555 Page 129
DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (38)
                                                                                               VAX-11 Bliss-16 V3-555
V01.2
                 MULTI-DRIVE TEST ROUTINES
                                                                     14-Dec-1983 16:12:00
          4378
          4379
                                               T_ADDR [ERR_HRD_SEK] = .T_ADDR [ERR_HRD_SEK] + 1
          4380
          4381
                                               T_ADDR [ERR_HRD_DRV] - .T_ADDR [ERR_HRD_DRV] + 1;
          4382
           4383
                                           ERRHRD (41, EGH_30, EMS_30);
           4384
                                           end:
           4385
           4386
                          [ST_DIA]:
                                           begin
T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
                                                                                                        ! MESSAGE FROM INTERNAL DIAGNOSTICS
           4387
           4388
                                           ERRHRD (43, EGH_30, EMS_30);
.
           4389
                                           end:
:
          4390
.
          4391
                                           begin
C_ERR_TBL [.CCTLR, C_ERR_HRD] = .C_ERR_TBL [.CCTLR, C_ERR_HRD] + 1;
                          [otherwise]:
:
                                                                                                        ! PRINT STATUS CODE IF NO MATCH
          4392
.
          4393
                                           ERRHRD (45, EGH_30, EMS_30);
          4394
:
          4395
:
          4396
:
                 if .RP_ADDR [CONID] EQL CID DUP
          4397
:
          4398
:
          4399
           4400
                     selectoneu .RP_ADDR [STSCOD] of
           4401
                              SET
           4402
                              [#0'0']
                                                                                       ! if status code succesful
                                                   : begin
           4403
                                                    if .RP_ADDR [ENDCOD] EQLU (OP_GDS + OP_END) and ! IF ENDCODE IS GET DUST STATUS
           4404
                                                       .RP_ADDR [9,9,1,0] NEQ 1
                                                                                                        ! TEST TO SEE IF CONTROLLER LOCAL PR
OGRAMS
           4405
.
                                                    then
                                                                                                                 ! (PG 18 OF DUP DOC)
           4406
           4407
                                                                     ERRHRD (47, EH_12, EMS_30);
                                                                                                        ! UNABLE TO LOAD LOCAL CONTROLLER DU
  MEDIA
           4408
                                                                     T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
           4409
                                                                     END
           4410
                                                    else
          4411
                                                            begin
if (.DUPPKT [DUPTYPE] eql 5)
           4412
                                                                                                        ! if fatal error
           4413
                                                            then
                                                                     DUR [ LALUN] - DU_DFATAL:
           4414
           4415
           4416
                                                                                                        ! FATAL DEVICE ERROR DROP UNIT);
           4417
                                                                     end;
.
                                                                                                        ! SET REASON FOR DROPPING UNIT
           4418
                                                             selectoneu .DUPPKT [DUPMESG] of
           4419
                                                                     SET
           4420
                                                                     [#0'0'] : begin
           4421
                                                                              errhrd (99, eh_13, ems_30); ! succesfull message
           4422
                                                                              T_ADDR [ERR_HRD_HST] . T_ADDR [ERR_HRD_HST] . 1;
           4423
                                                                              end:
           4424
                                                                     [#0'1'] : begin
           4425
                                                                              errhrd (48, eh_13, ems_30); ! illegel unit number T_ADDR [ERR_HRD_HST] = .T_ADDR [ERR_HRD_HST] + 1;
           4426
           4427
                                                                              end;
           4428
                                                                     [#0'2'] : begin
           4429
                                                                              errhrd (49, eh_13, ems_30); ! illegal relative or physical b
lock #
           4430
                                                                              T_ADDR [ERR_HRD_HST] = .T_ADDR [ERR_HRD_HST] + 1;
```

```
SEQ 0385
ZRQAM3
                      RD/RX EXERCISER
                                                                                         14-Dec-1983 16:12:07
                                                                                                                           VAX-11 Bliss-16 V3-555
                                                                                                                          DISK&USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (38)
V01.2
                      MULTI-DRIVE TEST ROUTINES
                                                                                         14-Dec-1983 16:12:00
              4431
                                                                                                    end:
              4432
                                                                                         [#0'3'] : begin
                                                                                                    errhrd (50, eh_13, ems_30); ! device error
T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
              4433
              4434
              4435
                                                                                                     end:
              4436
                                                                                         [#0'4'] : begin
:
              4437
                                                                                                    errhrd (51, eh_13, ems_30); ! zero lenght message T_ADDR [ERR_HRD_HST] = .T_ADDR [ERR_HRD_HST] + 1;
:
              4438
.
                                                                                         end:
[OTHERWISE]: begin
ERRHRD (98, EH_8, EMS_30); ! DUP UNKNOWN STATUS CODE
C_ERR_TBL [.CCTLR, C_ERR_HRD] = .C_ERR_TBL [.CCTLR, C_ERR_HR
              4439
              4440
              4441
.
              4442
    . 1:
D]
              4443
                                                                                                    end:
              4444
                                                                                         tes:
.
              4445
                                                                              end:
              4446
              4447
                                                                   end:
                                                        : begin
ERRHRD (52, EH_7, EMS_30);
              4448
                                       [50'1']
              4449
                                                                                                     ! INVALID COMMAND
              4450
                                                        T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
              4451
                                                        end:
              4452
                                                        : begin
ERPHRD (53, EH_7, EMS_30); ! NO REGION AVAILA
T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
                                       [#0'2']
              4453
                                                                                                    ! NO REGION AVAILABLE
              4454
              4455
                                                        end;
              4456
                                       [#o'3']
                                                           : begin
              4457
                                                        ERRHRD (54, EH_7, EMS_30); ! NO REGION SUITAR
T_ADDR (ERR_HRD_HST) = .T_ADDR (ERR_HRD_HST) + 1;
                                                                                                     ! NO REGION SUITABLE
              4458
              4459
.
                                                        end;
                                                        : begin
ERRHRD (55, EH_7, EMS_30); ! PROGRAM NOT KNOW
T_ADDR (ERR_HRD_HST) = .T_ADDR (ERR_HRD_HST) + 1;
              4460
                                       [#0'4']
.
              4461
                                                                                                    ! PROGRAM NOT KNOWN
              4462
              4463
                                                        end;
                                                        : begin
ERRHRD (56, EH_7, EMS_30); ! LOAD FAILURE
T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
              4464
                                       [#o'5']
              4465
              4466
              4467
                                                        end;
                                                        : begin
ERRHRD (57, EH_7, EMS_30); ! STANDALONE
T_ADDR (ERR_HRD_HST) = .T_ADDR (ERR_HRD_HST) + 1;
              4468
                                       [$0'6']
              4469
              4470
              4471
                                                        end:
                                                       : begin
ERRHRD (58, EH_8, EMS_30); ! DUP UNKNOWN STATUS CODE
C_ERR_TBL [.CCTLR, C_ERR_HRD] = .C_ERR_TBL [.CCTLR, C_ERR_HRD] + 1;
              4472
                                       [OTHERWISE]
              4473
              4474
              4475
              4476
                                       TES:
              4477
              4478
                            end;
.
                                                                                                                                      ! ROUTINE HARD_ERROR
                                                                    .SBTTL HARD.ERROR MULTI-DRIVE TEST ROUTINES
000000 004137 000000G
                                                        HARD . ERROR:
                                                                   JSR
                                                                              R1, $SAVE3
                                                                                                                                                                                   4272
```

ZRQAM3 VO1.2		RD/RX EXERCISER MULTI-DRIVE TEST RO	UTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO	SEQ 0386 Page 131 .BL2;161 (38)
000004 000010	013701 005261 013700	000000G 000014		MOV	T.ADDR.R1 14(R1)	•	4288
000014	013700	000000G		MOV	RP. ADDR. RO		4289
000020 000024 000026	105760	000003		TSTB	3(RO)		4207
000024	001157	********		BNE	12\$		
000026	013700 001022	000000G		BNE	ST.CODE,RO		4291
000032	013702	00000G		MOV	3\$ SB.CODE,R2		4294
000040	001574	***************************************		BEQ	16\$		4274
000026 000032 000034 000040 000042 000046 000050 000054	001574 012703	000062		MOV	462,R3		4301
000046	060103	******		ADD	R1,R3		
000050	020227	000004		CMP	R2.44		4298
000056	001002 105213			BNE	1\$ (R3)		4701
000060	000402			BR	2\$		4301 4298
000062	105263	000001	18:	INCB	1(R3)		4304
000060 000062 000066 000070 000072	000402 105263 104456		2\$:	TRAP	56		4306
000070	000054			. WORD	54		
000072	000054 000000G 000000G			. WORD	EGH. 30		
000076	000567			. WORD BR	EMS.30		4204
000076 000100 000104	020027 001007 105261 104456 000037 000000G 00000G 000567 020027	000001	34:	CMP	RO.#1		4291
000104	001007			BNE	41		
000106 000112 000114	105261	000063		INCB	63(R1)		4310
000112	104456			TRAP	56		4311
000114	000037			. WORD	37		
000120	0000000			. WORD	EGH.30 EMS.30		
000120 000122	000567			BR	20#		4291
000124 000130	020027	000002	48:	CMP	RO. #2		4671
000130	OOTOOL			BNE	5#		
000132 000136	105261	000062		INCB	62(R1)		4315
000140	104456			TRAP . WORD	56 40		4316
000142	000040 000000G 000000G			WORD	EGH. 30		
000144	000000G			WORD	EMS.30		
000146	000576			BR	241		4291
000150	020027	000003	5#:	CMP	RO.#3		
000154	105361	000060		BNE	61		
000162	104455	000062		INCB	62(R1)		4320
000164	000022			TRAP .WORD .WORD .WORD	55 22 EGD.18		4321
000166	000000G			WORD	EGD.18		
000170	000000G			. WORD	EMS.18		
000156 000162 000164 000166 000170 000172	013700	000000G		MOV	L\$LUN,RO		4322
000204	104451	000005 000000G		MOVB	#5,DUR(RO)		
000204 000206 000210 000214 000216 000222	020027 001015 105261 104455 000022 000000G 013700 112760 104451 000570			TRAP BR	51 26¢		4323
000210	020027	000004	6#:	CMP	RO. 44		4291
000214	020027 001015			BNE	76		
000216	105261	000062		INCB	62(R1)		4327
000222	104455			TRAP	55		4328
000224	000030			. WORD	30		

L14

ZRQAM3 VO1.2		RD/RX EXERCISER MULTI-DRIVE TEST	ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL	SEQ 0387 Page 132 2:161 (38)
000226	000000G			. WORD	EGD.18		
000226 000230 000232 000236 000244 000246 000250 000254 000262 000264 000270 000272 000274 000300 000302 000306 000310 000316 000320 000320 000324 000326 000330 000326 000336 000336 000340 000340 000350 000350	000000G 013700	0000000		. WORD	EMS.18		
000236	112760	000000G 000013 000000G		MOVB	L\$LUN,RO #13,DUR(RO)		4329
000244	104451 000562			TRAP	51		4330
000246	020027	000005	7\$:	BR CMP	28\$		4291
000254	001007		74:	BNE	RO.#5		
000256	105261	000060		INCB	60(R1)		4334
000262	105261 104456 000043 000000G			TRAP	56 43		4335
000266	000000G			. WORD	EGH. 30		
000270	000000G			. WORD	EMS.30		
000272	000550 020027	000006	81:	BR	28\$		4291
000300	001020	00000	0+:	CMP BNE	RO.#6 11\$		
000302	012702	000062		MOV	462,R2		4342
000306	001020 012702 060102 023727	000000G 000200		ADD	R1,R2 SB.CODE,#200		
000316	nninns			BNE	9\$		4340
000320	105262 000401 105212 104456 000044 000000G 000000G	000001		INCB	1(R2)		4342
000324	105212		04.	BR	10\$		4340
000330	104456		9\$: 10\$:	INCB	(R2) 56		4344 4346
000332	000044			. WORD	44		4340
000334	000000G			. WORD	EGH. 30		
000340	000525			BR	EMS.30 28\$		4291
000342	020027	000007	114:	CMP	RO.#7		4672
000346	105261	000061		BNE	13\$		4750
000354	020027 001007 105261 104456 000045 000000G	000001		TRAP	61(R1) 56		4350 4351
000356	000045			. WORD	45		4032
000360	00000006			. WORD	EGH.30 EMS.30		
000362 000364	000000G 000513		124:	BR	28#		4291
000366	020027 001020 012702	000010	12#: 13#:	CMP	RO.#10	[발화되어 등 구역 및 10 등 기념을 보고 있었습니다.	
000372 000374	011020	000060		BNE	17\$ #60,R2		4750
000400	060102 023727			ADD	R1.R2		4358
000402 000410 000412	023727	000000G 000002		CMP	SB.CODE,#2		4356
000412	105212			INCB	14\$ (R2)		4750
000414 000416 000422 000424	000402			BR	15#		4358 4356
000416	105262	000001	144:	INCB	1(R2)		4360
000422	000046		15#:	TRAP	56		4362
000426	000000G			. WORD	46 EGH. 30		
000430	001002 105212 000402 105262 104456 000046 000000G			. WORD	EMS.30		
000432 000434	000470 020027	000011	16#: 17#:	BR	284		4291
000440	001007	***************************************	1/0:	BNE	RO.#11 19#		
000442	105261	000063		INCB	63(R1)	1	4366

M14

ZRQAM3 VO1.2		RD/RX EX MULTI-DR	ERCISER RIVE TEST	ROUTINES		14-Dec-1983 16:12:0 14-Dec-1983 16:12:0	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQA	SEQ 0388 Page 133 CO.BL2;161 (38)
000446 000450 000452 000454	104456 000047 000000G 000000G				TRAP . WORD . WORD . WORD	56 47 EGH.30 EMS.30	•	4367
000454 000456 000460 000464	000456	000012		18\$: 19\$:	BR CMP BNE	28\$ RO.#12 21\$	•	4291
000466 000472 000474	105261 104456 000050	000062			INCB TRAP . WORD . WORD	62(R1) 56 50	;	4371 4372
000500 000502	000000G 000003G 000444 020027	000013		20\$: 21\$:	. WORD BR CMP	EGH.30 EMS.30 28\$ RO.#13		4291
000510 000512 000520	001016	000000G	000003	2141	BNE CMP BNE	25\$ SB.CODE,#3 22\$		4377
000522 000526 000530	105261 000402 105261	000060		224:	INCB BR INCB	60(R1) 23\$ 62(R1)		4379 4377 4381
000534 000536 000540	105261 000402 105261 104456 000051 000000G			23#:	TRAP . WORD . WORD	56 51 EGH. 30		4383
000544 000546 000552	00000G 000423 020027 001007	000037		24#: 25#:	. WORD BR CMP BNE	EMS.30 28\$ RO,#37 27\$		4291
000466 000472 000474 000476 000500 000502 000504 000510 000512 000520 000522 000526 000530 000534 000546 000546 000546 000552 000560 000562 000564 000566 000570 000572	000423 020027 001007 105261 104456 000053 000000G	000062			INCB TRAP . WORD . WORD	62(R1) 56 53 EGH. 30	1	4387 4388
	000411 013700 006300	000000G		26#: 27#:	. WORD BR MOV ASL	EMS.30 28\$ CCTLR,RO RO		4291 4392
000600 000604 000606 000610	105260 104456 000055 000000G 000000G	000000G			INCB TRAP .WORD .WORD .WORD	C.ERR.TBL(RO) 56 55 EGH.30		4393
000612 000614 000620 000636 000632 000636 000642 000644 000652 000654 000662	013700 126027 001401	00000G 000003	000002	28#:	MOV CMPB BEQ	EMS.30 RP.ADDR.RO 3(RO).#2 29\$		4397
000630 000632 000636 000642	126027 001401 000207 116001 042701 001111 126027	000016 177740		29#:	RTS MOVB BIC BNE	PC 16(RO),R1 #177740,R1 37#		4400
000644 000652	126027 001011	000014	000201		CMPB	14(RO),#201 30#		4403
000654 000662	001011 032760 001005	001000	000055		BIT	#1000,22(R0)		4404
000664 000666	001005 104456 000057				TRAP . WORD	30 \$ 56 57		4407

N14

ZRQAM3 VO1.2	RD/RX EXERCISER MULTI-DRIVE TEST ROUTIN	ES	14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2;16	0389 Page 134 1 (38)
000670 0000000 000672 0000000 000674 000543 000676 013700 000702 042700 000706 020027	000000G 007777 050000	.WORD .WORD BR 30\$: MOV BIC CMP	EH.12 EMS.30 42\$ DUPPKT,RO #7777,RO RO.#50000	:	4408 4412
000712 001006 000714 013700 000720 112760	000000G 000005 000000G	BNE MOV MOVB	31\$ L\$LUN,RO #5,DUR(RO)		4415
000730 013700	000000G 170000	31\$: MOV BIC	51 DUPPKT,RO #170000,RO	:	4416 4418
000742 104456		BNE TRAP . WORD . WORD . WORD	32\$ 56 143 EH.13 EMS.30	•	4421
000746 000000G 000750 000000G 000752 000530 000754 020027 000760 001005	000001	324: BR CMP BNE	44\$ RO.#1 33\$	;	4422 4418
000762 104456		TRAP .WORD .WORD .WORD	56 60 EH.13 EMS.30	•	4425
000766 0000000 000770 0000000 000772 000520 000774 020027 001000 001005	000002	334: BR CMP BNE	44\$ RO.#2 34\$	:	4426 4418
001002 104456 001004 000061 001006 0000000 001010 0000000		TRAP .WORD .WORD .WORD	56 61 EH.13 EMS.30		4429
001012 000510 001014 020027 001020 001005	000003	344: BR CMP BNE	44\$ RO.#3 35\$		4430 4418
001022 104456 001024 000062 001026 0000006 001030 0000006 001032 000464 001034 020027		TRAP . WORD . WORD . WORD	56 62 EH.13 EMS.30	•	4433
001032 000464 001034 020027 001040 001005		354: BR CMP BNE	42\$ RO.#4 36\$	:	4434 4418
001040 001005 001042 104456 001044 000063 001046 0000000 001050 00000000 001052 000470 001054 104456		TRAP . WORD . WORD . WORD	56 63 EH.13 EMS.30		4437
001052 000470 001054 104456 001056 000142 001060 0000000 001062 00000000 001064 000474		BR TRAP . WORD . WORD . WORD	44\$ 56 142 EH.8 EMS.30	•	4438 4441
001064 000474 001066 020127 001072 001005	000001	374: BR CMP BNE	46\$ R1.#1 38\$	;	4442 4400

						013		
;	ZRQAM3 VO1.2		RD/RX EXERCISER MULTI-DRIVE TEST	ROUTINES		14-Dec-1983 16:12: 14-Dec-1983 16:12:	07 VAX-11 Bliss-16 V3-555 00 DISK\$USER2:[DIETZ.RDRX]ZR	SEQ 0390 Page 135 QACO.BL2;161 (38)
	001074 001076 001100 001102	104456 000064 000000G 000000G			TRAP .WORD .WORD	56 64 EH. 7 EMS. 30	•	4449
	001104 001106 001112	000437 020127 001005	000002	381:	BR CMP BNE	42\$ R1.42 39\$	:	4450 4400
	001114 001116 001120 001122 001124	104456 000065 000000G 000000G			TRAP .WORD .WORD	56 65 EH. 7 EMS. 30	•	4453
	001126	000427 020127 001005 104456	000003	39\$:	BR CMP BNE	42\$ R1.#3 40\$		4454 4400
	001134 001136 001140 001142	000066 000000G 000000G 000433			TRAP .WORD .WORD	56 66 EH. 7 EMS. 30		4457
	001140 001142 001144 001146 001152 001154	020127	000004	401:	BR CMP BNE	44\$ R1.04 41\$		4458 4400
	001162	104456 000067 000000G 000000G 000423			TRAP .WORD .WORD .WORD BR	56 67 EH. 7 EMS. 30		4461
	001166 001172 001174	020127	000005	418:	CMP BNE TRAP	R1.05 43\$		4462 4400
	001166 001172 001174 001176 001200 001202	104456 000070 000000G 000000G			. WORD . WORD	56 70 EH. 7 EMS. 30		4465
	001204 001210 001214	013700 105260 000207	00000G 000062	424:	MOV INCB RTS	T.ADDR,RO 62(RO) PC		4466 4400
	001216	020127 001011 104456	000006	436:	CMP BNE TRAP	R1.06 45\$		
	001226 001230 001232	000071 000000G			. WORD . WORD . WORD	56 71 EH. 7 EMS. 30		4469
	001234 001240 001244	000000G 013700 105260 000207	00000G 000063	446:	MOV INCB RTS	EMS.30 T.ADDR.RO 63(RO) PC	•	4470
	001222 001224 001226 001230 001232 001234 001240 001246 001250 001252 001254 001256 001262 001264	104456 000072 000000G 000000G 013700		45#:	TRAP . WORD . WORD . WORD	56 72 EH. 8 EMS. 30		4473
	001256 001262 001264	105260	000000G	461:	MOV ASL INCB	CCTLR,RO RO C.ERR.TBL(RO)	•	4474
•	001270	000207			RTS	PC	•	4272
								The state of the s

ZRQAM3 V01.2

RD/RX EXERCISER MULTI-DRIVE TEST ROUTINES

14-Dec-1983 16:12:07 14-Dec-1983 16:12:00

: Routine Size: 349 words. Routine Base: \$CODE\$ + 17424 : Maximum stack depth per invocation: 6 words

. 2.

```
SEQ 0392
ZRQAM3
                      RD/RX EXERCISER
                                                                                        14-Dec-1983 16:12:07
                                                                                                                          VAX-11 Bliss-16 V3-555
                                                                                                                                                                            Page 137
                                                                                                                          DISK&USER2: [DIETZ.RDRX]ZRQACO.BL2;161 (39)
                      MULTI-DRIVE TEST ROUTINES
V01.2
                                                                                        14-Dec-1983 16:12:00
             4479 routine UPD_IO_TALLY : novalue =
              4480
             4481
              4482
                                 THIS ROUTINE IS CALLED FROM IO_RETPKT FOR ALL I/O TRANSFER RETURN
                     .
              4483
                                 PACKETS WITH "SUCCESS" STATUS CODES. ITS PURPOSE IS TO UPDATE ALL THE
                                 APPROPRIATE STATISTICAL FIELDS FOR THE CURRENT UNIT. A CHECK IS ALSO
              4484
              4485
                                 MADE ON THE TOTAL NUMBER OF BYTES TRANSFERRED THUS FAR; IF THE
                                 OPERATOR-SPECIFIED LIMIT HAS BEEN REACHED. THEN THE UNIT IS DROPPED.
              4486
              4487
                                 IMPLICIT IMPUTS:
              4488
              4489
                                            RP_ADDR - ADDRESS OF THE CURRENT RETURN PACKET
              4490
                                            T_ADDR - ADDRESS OF THE CURRENT UNIT'S STATISTICS BLOCK (TALLY)
                                            CST_ADDR - ADDRESS OF THE CURRENT CONTROLLER'S CST
              4491
                                            CUOFF - CST OFFSET FOR THE CURRENT UNIT
              4492
              4493
                                            L$LUN - CURRENT UNIT NUMBER
              4494 !-
              4495
              4496
                           begin
              4497
              4498
                            local
              4499
                                 THOUSANDS : word.
              4500
                                 MILLIONS : word:
                                                                                                               ! TOTAL NUMBER OF BYTES TRANSFERRED TO/FROM A UNIT
              4501
              4502
                            if .RP_ADDR [ENDCOD] eql (OP_RD or OP_END)
                                                                                                               ! IF ENDCODE IS READ
              4503
                                begin
T_ADDR [TOT_READS_LO] = .T_ADDR [TOT_READS_LO] + 1; ! INCREMENT NO. (
T_ADDR [BYTES_READ_LO] = .T_ADDR [BYTES_READ_LO] + .RP_ADDR [BCNT_LO];
T_ADDR [TOT_BYT_RED_LO] = .T_ADDR [TOT_BYT_RED_LO] + .RP_ADDR [BCNT_LO];
OVF_CHK (T_ADDR [TOT_READS_LO]); ! CHECK FOR FIELD
OVF_CHK (T_ADDR [BYTES_READ_LO]); !
OVF_CHK (T_ADDR [TOT_BYT_RED_LO]); !
              4504
              4505
                                                                                                               ! INCREMENT NO. OF READS AND ADD BYTE COUNT
              4506
              4507
              4508
                                                                                                               ! CHECK FOR FIELD OVERFLOW
              4509
              4510
              4511
              4512
                            else
              4513
              4514
                                  if .RP_ADDR [ENDCOD] eql (OP_WRT or OP_END)
                                                                                                              ! IF ENDCODE IS WRITE
              4515
                                 then
                                     T_ADDR [TOT_WRITES_LO] = .T_ADDR [TOT_WRITES_LO] + 1; ! INCREMENT NO. OF T_ADDR [BYTES_WRIT_LO] = .T_ADDR [BYTES_WRIT_LO] + .RP_ADDR [BCNT_LO]; T_ADDR [TOT_BYT_WRT_LO] + .RP_ADDR [BCNT_LO]; OVF_CHK (T_ADDR [TOT_WRITES_LO]); ! CHECK FOR FIELD OVERFLOW OVF_CHK (T_ADDR [BYTES_WRIT_LO]); ! OVF_CHK (T_ADDR [TOT_BYT_WRT_LO]); !
              4516
              4517
                                                                                                                          ! INCREMENT NO. OF WRITES AND ADD BYTE COUNT
              4518
              4519
              4520
              4521
              4522
              4523
              4524
                            if (.RP_ADDR [ENDCOD] eql (OP_RD or OP_END)) or
(.RP_ADDR [ENDCOD] eql (OP_WRT or OP_END))
              4525
              4526
              4527
4528
                            then
                                 begin
:
              4529
                                 MILLIONS = .T_ADDR (MBYTES_READ) + .T_ADDR (MBYTES_WRIT);
THOUSANDS = .T_ADDR (BYTES_READ_HI) + .T_ADDR (BYTES_WRIT_HI);
                                                                                                                        ! TOTAL BYTES TRANSFERRED
:
              4530
```

4531

	ZRQAM3		RD/RX EXERCISER		14 0 100			SEQ 0393
	V01.2		MULTI-DRIVE TEST ROU	TINES	14 - Dec - 198	3 16:12:07 3 16:12:00	VAX-11 Bliss-16 V3-555	Page 138
			MODITE SHIPE TEST MOD	21123	14-066-198	3 10:12:00	DISK \$USER2: [DIETZ.RDRX]ZRQAC	.O.BL2;161 (39)
	:	4532	if .THOUSANDS	gequ 1000				
	:	4533	then					
	:	4534	begin	MT1 . TOUG				
	•	4535 4536	THOUSAND	MILLIONS + 1;	000	! COUNT	THE LOWER OVERFLOW TOO!	
	:	4537	end:	THOUSANDS - 1	000;			
		4538	6101					
		4539	•					
	:	4540	! THIS ADDED BECAUSE	IT WILL TAKE FORE	VER TO TRANSFER ON T	HE ORDER OF A	MEGABYTE TO A FLOPPY	
	:	4541	! BUT IT IS A MUCH MO	DRE REASONABLE MEA:	SURE FOR THE RD51 WI	NCHESTER. TH	E QUESTION NOW REFERS TO	
Ī	:	4542	! THE TOTAL DATA TRAI	NSFER TO THE CONTRI	OLLER AND THIS IS PR	ETTY CLOSE SI	NCE THE FLOPPIES GET	
	•	4543 4544	! ABOUT 1/1000 THE DA	ATA THE HARD DISK(	S) GET.			
1	:	4545						
-		4546	if .SWP_XFER	eal 0		I TE TH	ERE IS A TRANSFER LIMIT	
1		4547	then	-4		. 1	ENE 13 A INMISER CITILI	
	:	4548	begin					
1		4549		SANDS gtru 100				
1		4550	then					
		4551 4552		FLAG - TRUE;		! SET E	ND-OF-PASS FLAG	
-	:	4553	else					
1		4554	begin					
1		4555	if MILL	IONS gequ .SWP_XFE	R	! IF TR	ANSFER LIMIT IS REACHED	
	:	4556	then				THIS EN CENTE IS NEACHED	
	:	4557	_	FLAG = TRUE;		! SET E	ND-OF-PASS FLAG	
		4558	end;					
1	:	4559 4560	end;			end of	read/write tallying	
1		4500	eno,			: K0011	NE UPD_IO_TALLY	
	000000			. SBTTL	UPD. IO. TALLY MULTI	-DRIVE TEST R	OUTINES	
	000000	004137	000000G	UPD. IO. TALLY:				
1	000004	013701	000000G	JSR	R1, #SAVE2			4479
	000010	126127	000014 000241	MOV	RP.ADDR,R1		•	4502
1	000016	001027	000014 000541	BNE	14(R1), #241			
1	000020 000024	013700 005260 066110	000000G	MOV	T.ADDR.RO			4505
1	000024	005260	000016 000020 000020 000032 000016	INC	16(RO)			4505
1	000030	066110	000020	ADD	20(R1),(R0)			4506
1	0000042	066160 012746	000020 000032	ADD	20(R1),32(R0)		1	4507
1	000046	060016	000016	VOM	#16(SP) RO.(SP) PC.OVF.CHK		•	4508
1	000050	004737	000000V	ADD JSR	PC OVE CHE	•		
	000054	013716 004737	000000G	MOV	T.ADDR.(SP)			4509
-	000060	004737	000000V	JSR	T.ADDR,(SP) PC.OVF.CHK			4309
1	000034 000042 000046 000050 000054 000060 000064	013716	00000G	MOV	T.ADDR,(SP)		1	4510
1	000070 000074	062716	000032	ADD	#32,(SP)			
	000074	000435 126127	000014 000040	BR CHOO	26			
1	000104	001034	000014 000242	14: CMPB BNE	14(R1),#242 36			4514
	000106	013700	00000G	MOV	T.ADDR,RO			4517
	000112	005260	000024	INC	24(RO)			4517

	ZRQAM3 V01.2		RD/RX EXERCIS MULTI-DRIVE T			14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.E	SEQ 0394 Page 139 SL2:161 (39)
	000116 000124 000132 000136	066160 066160 012746 060016	000020 00000 000020 00004 000024	6	ADD ADD MOV ADD	20(R1),6(R0) 20(R1),40(R0) #24,-(SP) R0,(SP)		4518 4519 4520
	000140 000144 000150 000154	004737 013716 062716 004737	000000V 00000G 000006 000000V		JSR MOV ADD JSR	PC,OVF.CHK T.ADDR.(SP) #6.(SP)	•	4521
-	000160 000164 000170	013716 062716 004737	000000G 000040 000000V	21:	MOV ADD JSR	PC.OVF.CHK T.ADDR.(SP) #40.(SP) PC.OVF.CHK	•	4522
	000174 000176 000202	005726 013700 126027	000000G 000014 00024	34:	TST MOV CMPB	(SP)+ RP.ADDR,RO 14(RO),#241	:	4516 4525
-	000210 000220	001404 126027 001034	000014 00024	2	BEQ CMPB BNE	4\$ 14(RO),#242 8\$		4526
-	000222 000226 000232	013700 016002 066002	00000G 000004 000012	44:	MOV MOV ADD	T.ADDR.RO 4(RO).R2 12(RO).R2	. *.MILLIONS . *.MILLIONS	4529
-	000236 000246 000252	016001 066001 020127 103403	000002 000010 001750		ADD CMP	2(RO),R1 10(RO),R1 R1,#1750 5#	* *, THOUSANDS * *, THOUSANDS * THOUSANDS, *	4530 4532
-	000236 000242 000246 000252 000254 000256 000262 000266 000270	005202 162701 013700	001750 000000G	5#:	BLO INC SUB MOV	R2 #1750,R1 SWP.XFER.RO	: MILLIONS : *, THOUSANDS	4535 4536
-	000266 000270 000274 000276	001004 020127 101406	000144		BNE CMP BLOS	6\$ R1,#144 8\$	; THOUSANDS. *	4546 4549
	000300	000402 020200 103403		64:	BR CMP BLO	7\$ R2.R0 8\$	MILLIONS.*	4551 4555
-	000304 000312	112737	000001 00000	OG 75: 85:	RTS	#1,EOP.FLAG PC		4557 4479

<sup>:</sup> Routine Size: 102 words. Routine Base: \$CODE\$ + 20716 : Maximum stack depth per invocation: 5 words

```
SEQ 0395
ZRQAM3
                   RD/RX EXERCISER
                                                                              14-Dec-1983 16:12:07
                                                                                                           VAX-11 Bliss-16 V3-555
                                                                                                                                                       Page 140
V01.2
                   MULTI-DRIVE TEST ROUTINES
                                                                             14-Dec-1983 16:12:00
                                                                                                           DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (40)
            4561 routine OVF_CHK (ADDR) : novalue =
            4562
:
            4563 !+
4564 !
:
                             THIS ROUTINE IS CALLED FROM UPD_IO_TALLY TO CHECK FOR OVERFLOW IN
.
                             CERTAIN STATISTICAL FIELDS OF THE CURRENT UNIT. SPECIFICALLY, THE LOW-ORDER FIELD OF THE NUMBER OF BYTES READ OR WRITTEN IS CHECKED FOR EXCEEDING 1000. IF TRUE, THEN THE HIGH-ORDER COUNT IS INCREMENTED. IF THAT EXCEEDS 1000, THEN THE MEGABYTE COUNT IN INCREMENTED.
            4565
:
            4566
            4567
:
            4568
:
            4569
.
                             INPUTS:
            4570
:
                                      ADDR - ADDRESS OF THE BYTES_READ_LO OR BYTES_WRIT_LO FIELD FOR THE CURRENT UNIT (SEE STATISTIC TABLE (TALLY) LAYOUT)
            4571
:
            4572
.
            4573 !-
:
            4574
:
            4575
                        begin
:
            4576
:
            4577
                        while .. ADDR gegu 1000 do
                                                                             ! IF LO-ORDER OVERFLOW
            4578
                             ADDR = ..ADDR - 1000;
            4579
                                                                              ! SUBTRACT 1000
                             (.ADDR + 2) = .(.ADDR + 2) + 1;
            4580
                                                                              ! INCR HI-ORDER
            4581
:
            4582
.
            4583
                        if .(.ADDR + 2) gegu 1000
                                                                             ! IF HI-ORDER OVERFLOW
            4584
.
                        then
            4585
                             begin
(.ADDR + 2) = .(.ADDR + 2) - 1000;
.
            4586
:
                                                                              ! SUBTRACT 1000
            4587
                             (.ADDR + 4) = .(.ADDR + 4) + 1;
.
                                                                              ! INCREMENT MBYTES
            4588
.
                             end:
            4589
            4590
:
                        end:
                                                                             ! ROUTINE OVF_CHK
                                                           . SBTTL
                                                                    OVF.CHK MULTI-DRIVE TEST ROUTINES
000000 010146
                                                OVF . CHK : MOV
                                                                    R1,-(SP)
                                                                                                                                                            4561
200000
         016600
                   000004
                                                                    4(SP),R0
                                                          MOV
                                                                                                           : ADDR. .
                                                                                                                                                            4577
000006
         012701
                   000002
                                                          MOV
                                                                    #2.R1
                                                                                                                                                            4580
000012
         060001
                                                          ADD
                                                                    RO,R1
000014
         021027
                   001750
                                                          CMP
                                                18:
                                                                    (RO).#1750
                                                                                                                                                            4577
000020
         103404
000022
                                                          SUB
         162710
                   001750
                                                                    #1750,(RO)
                                                                                                                                                            4579
000026
         005211
                                                                    (R1)
                                                                                                                                                            4580
000030
         000771
                                                          BR
                                                                                                                                                            4577
000032
         021127
                   001750
                                                21:
                                                                    (R1), #1750
                                                                                                                                                            4583
000036
         103404
                                                          BLO
                                                                    34
000040
          162711
                   001750
                                                          SUB
                                                                    #1750,(R1)
                                                                                                                                                            4586
000044
         005260
                   000004
                                                          INC
                                                                    4(RO)
                                                                                                                                                            4587
000050
         012601
                                                          MOV
                                                 34:
                                                                    (SP)+,R1
                                                                                                                                                            4561
000052
         000207
: Routine Size: 22 words,
                                      Routine Base: #CODE# + 21232
```

: Maximum stack depth per invocation: 2 words

```
SEQ 0396
ZRQAM3
                   RD/RX EXERCISER
                                                                              14-Dec-1983 16:12:07
                                                                                                            VAX-11 Bliss-16 V3-555
                                                                                                            VAX-11 Bliss-16 V3-555 Page 141
DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2:161 (41)
V01.2
                   MULTI-DRIVE TEST ROUTINES
                                                                              14-Dec-1983 16:12:00
            4591 routine HOST_WRT_CHK =
            4592
2
            4593 !+
2
                             THIS ROUTINE IS CALLED FROM IO_RETPKT FOR ALL I/O TRANSFER RETURN PACKETS WITH "SUCCESS" STATUS CODES, BUT ONLY IF THE HOST WRITE-COMPARE OPTION WAS SELECTED BY THE OPERATOR.
            4594
            4595
            4596
            4597
            4598
                             IF THE CURRENT RETPKT BEING PROCESSED IS A WRITE FUNCTION, THEN THE
                             PACKET INDEX (RP_INDX) IS SAVED IN THE CONTROLLER'S RETURN PACKET SAVE AREA (RP_SAVE). OTHERWISE, THE PACKET IS A READ, SO ITS ASSOCIATED WRITE PACKET IS REMOVED FROM THE SAVE AREA, AND A BYTE-BY-BYTE
            4599
            4600
            4601
            4602
                             COMPARISON IS PERFORMED ON THE TWO I/O BUFFERS. ANY DIFFERENCES
            4603
                             ENCOUNTERED RESULTS IN THE DECLARATION OF A HARD ERROR.
            4604
                             IMPLICIT INPUTS:
            4605
:
                                       RP_ADDR - ADDRESS OF THE CURRENT RETURN PACKET RP_INDX - INDEX OF THE CURRENT RETURN PACKET
            4606
            4607
            4608
:
            4609
            4610
                        begin
            4611
            4612
                        local
                             BUFF1 : ref block [MAX_XFER * 2. byte]. ! I/O BUFFER ADDRESS BUFF2 : ref block [MAX_XFER * 2. byte]. ! I/O BUFFER ADDRESS
            4613
            4614
            4615
                             BUFFW.
                                                                              ! I/O BUFFER ADDRESS
            4616
                             COUNT : word,
                                                                              ! BYTE COUNT
            4617
                             FLAG : byte initial (byte (TRUE)),
.
            4618
                             index : signed word;
            4619
:
            4620
                        if .RP_ADDR [ENDCOD] eq1 (OP_WRT or OP_END) ! IF WRITE OPERATION
            4621
                        then
            4622
                             FLAG - FALSE
                                                                              ! DON'T CALL SWEEP FROM IO_RETPKT
            4623
                             if (.RP_ADDR [ENDCOD] eql (OP_RD or OP_END)) and
            4624
            4625
                                                                           ! IF ASSOCIATED WRITE PACKET IS FOUND ELSE ENDCODE IS READ
                                 ((index = RPS_REM ()) geq 0)
            4626
                             then
            4627
                                  begin
BUFFW = RETPKT [.index, BUFF_0];
            4628
                                                                             ! ADDR OF ADDR OF WRITE I/O BUFFER
            4629
                                                                              ! ADDR OF WRITE I/O BUFFER
                                  BUFF1 = ..BUFFW;
            4630
                                  BUFF2 = .RP_ADDR [BUFF_0];
                                                                              ! ADDR OF READ I/O BUFFER
            4631
                                  COUNT - . RP_ADDR [BCNT_LO]:
                                                                              ! BYTE COUNT
            4632
            4633
                                  incr I from 1 to .COUNT do
                                                                              ! FOR EACH BYTE IN BUFFERS
            4634
            4635
                                       if .(.BUFF1)<0, 8, 0> eql .(.BUFF2)<0, 8, 0> ! IF BYTES COMPARE O.K.
            4636
                                       then
            4637
                                           begin
BUFF1 = .BUFF1 + 1;
            4638
                                                                              ! ADVANCE WRITE BUFFER ADDR
            4639
                                            BUFF2 - .BUFF2 + 1:
                                                                              ! ADVANCE READ BUFFER ADDR
            4640
.
                                            end
            4641
.
                                       else
            4642
:
                                                                               ! ELSE - COMPARE ERROR
                                            T_ADDR [ERR_HARD] . .T_ADDR [ERR_HARD] . 1;
            4643
:
```

3000H3	DD 104 EVEROTOER				SEQ 0397
ZRQAM3 VO1.2	RD/RX EXERCISER MULTI-DRIVE TEST ROUTINES	14-	Dec-1983 16:12:07 Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO	.BL2;161 (41)
: 4644	T ADDR	ERR_HRD_HST] = .T_ADDR			
: 4645 : 4646	ERRHRD EMS_CMP	42, EGH_30, 0); ! I (RETPKT + (.index + RP_	O REQUEST FAILED		
: 4647 : 4648 : 4649	if .T_Al	DDR [ERR_HARD] gequ .SWP	_ERROR		
: 4650	beg		E EDDOD COLDIT EVEEED		
: 4651 : 4652 : 4653	DOD! end		ROP UNIT	:0	
: 4654 : 4655	exitloo	. ! N	O NEED TO CONTINUE		
: 4656 : 4657	end;	! 1	F COMPARE ERROR		
: 4658	end;	! 1	F ASSOCIATED WRITE RE	ETPKT WAS FOUND	
: 4659 : 4660	return (.FLAG);				
: 4661	end;	! R	OUTINE HOST_WRT_CHK		
		COTTI MOCT MOT CM	W M TT DOTUE TEST D		
000000 004137	000000G H0S	T.WRT.CHK:	K MULTI-DRIVE TEST RO	DUITNES	
000004 005746		JSR R1, \$SAVE5 TST -(SP)		1	4591
000006 112705 000012 013700	000001 000000G	MOVB #1,R5		: *.FLAG	4610
000016 126027	000014 000242	CMPB 14(RO), 4242			4620
000024 001002 000026 105005 000030 000500 000032 126027 000040 001074		BNE 1\$ CLRB R5		; FLAG	4622
000030 000500 000032 126027	000014 000241 1\$:	BR 6\$			4620
000040 001074		BNE 6\$			4624
000042 004737 000046 005700	000000V	JSR PC,RPS.REM		INDEX	4625
000050 002470 000052 010046		BLT 6\$			4628
000054 012746	000060	MOV 460, -(SP)		: INDEX.4	4020
000064 010066	00000G 000004	JSR PC.BL#MUL MOV RO.4(SP)			
000070 062700 000074 011002	000024G	ADD #RETPKT+24, MOV (RO),R2	RO	: *.BUFFW : BUFFW.BUFF1	4629
000076 013700	00000G	MOV RP. ADDR, RO			4630
000102 016003 000106 016004 000112 005001	000024 000020	MOV 24(RO),R3 MOV 20(RO),R4		: *,BUFF2 : *,COUNT	4631
000106 016004 000112 005001 000114 000442		CLR R1 BR 4\$		i I	4633
000116 121213	24:	CMPB (R2),(R3)		: BUFF1.BUFF2	4635
000120 001003 000122 005202		BNE 34 INC R2		; BUFF1	4638
000122 005202 000124 005203 000126 000435		INC R3		BUFF2	4639
000130 013700	000000G 3#:	MOV T.ADDR,RO			4635 4643
000134 005260	000014	INC 14(RO)			

	ZRQAM3 VO1.2		RD/RX EXERCISER MULTI-DRIVE TEST ROUTINES	14-Dec- 14-Dec-	1983 16:12:07 VAX-11 Bliss-16 V3-555 1983 16:12:00 DISK\$USER2:[DIETZ.RDRX	SEQ 0398 Page 143 ]ZRQACO.BL2;161 (41)
	000140 000144 000146 000150 000152	105260 104456 000052 000000G	000063	INCB 63(RO) TRAP 56 .WORD 52 .WORD EGH.30 .WORD 0	•	4644 4645
1	000154 000160 000164 000170	016616 062716 004737 013700	000004 000000G 000000G	MOV 4(SP),(SP) ADD #RETPKT,(SP) JSR PC,EMS.CMP MOV T.ADDR,RO		4646
	000174 000202 000204 000210	026037 103412 013700 112760	000014 000000G 000000G 000004 000000G	CMP 14(RO), SWP.ERRO BLO 54 MOV L\$LUN, RO MOVB 44, DUR(RO)	DR .	4648
	000216 000220 000222 000224	104451 000403 005201 020104	41:	TRAP 51 BR 5# INC R1 CMP R1.R4	I I.COUNT	4652 4642 4633
	000226 000230 000232 000234 000236 000240	003733 022626 005000 150500 005726 000207	5#: 6#:	BLE 2\$ CMP (SP)+,(SP)+ CLR RO BISB R5,RO TST (SP)+ RTS PC	FLAG.*	4627 4610 4591

<sup>:</sup> Routine Size: 81 words. Routine Base: #CODE# + 21306 : Maximum stack depth per invocation: 11 words

```
SEQ 0399
ZRQAM3
                   RD/RX EXERCISER
                                                                             14-Dec-1983 16:12:07
                                                                                                          VAX-11 Bliss-16 V3-555
                                                                                                                                                      Page 144
V01.2
                   MULTI-DRIVE TEST ROUTINES
                                                                             14-Dec-1983 16:12:00
                                                                                                          DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (42)
            4662 routine SWEEP : novalue =
            4663
.
            4664
:
                             THIS ROUTINE IS CALLED FROM IO_RETPKT AND OTHERS TO DEALLOCATE THE RESOURCES ASSOCIATED WITH THE CURRENT RETURN PACKET. THIS INCLUDES THE
            4665
.
            4666
                            PACKET ITSELF AND THE I/O BUFFER. IN ADDITION, IF THE HOST IS PERFORMING WRITE-COMPARES, AND IF THE CURRENT RETURN PACKET IS A READ FUNCTION, THEN THE CURRENT CONTROLLER'S RP_SAVE AREA IS SEARCHED FOR THE ASSOCIATED WRITE RETPKT SO THAT ITS RESOURCES CAN ALSO BE
            4667
            4668
.
            4669
.
            4670
.
                             DEALLOCATED.
            4671
:
            4672
.
                             IMPLICIT INPUTS:
            4673
:
            4674
                                      RP_ADDR - ADDRESS OF CURRENT RETURN PACKET
                                      RP_INDX - INDEX OF CURRENT RETURN PACKET
            4675
.
            4676
.
            4677
.
            4678
                        begin
.
            4679
.
            4680
.
                        local
            4681
                             index : signed word;
:
            4682
.
            4683
                        if (.RP_ADDR (ENDCOD) and OP_MSK) eql OP_RD ! IF READ OPCODE OR ENDCODE
.
            4684
                        then
:
            4685
:
            4686
                             if BIT_TST (SWP_FLAGS, SWF_HWC)
                                                                             ! IF HOST IS DOING WRITE-COMPARES
:
            4687
.
            4688
.
            4689
                                  if (index = RPS_REM ()) geq 0
                                                                             ! IF ASSOCIATED WRITE RETPKT IS FOUND
.
            4690
                                  then
.
                                      begin
PUT_IO_BUFF (RETPKT [.index, BUFF_0]); ! RETURN WRITE I/O BUFFER TO POOL
            4691
.
            4692
.
            4693
.
            4694
.
            4695
:
:
            4696
                        PUT_IO_BUFF (RP_ADDR [BUFF_0]);
                                                                             ! RETURN CURRENT I/O BUFFER TO POOL
            4697
                        PUT_RETPKT (.RP_INDX);
.
                                                                             ! RETURN CURRENT RETPKT TO POOL
            4698
                                                                             ! ROUTINE SWEEP
                                                                   SWEEP MULTI-DRIVE TEST ROUTINES
                                                           . SBTTL
000000 010146
                                                          MOV
                                                                    R1,-(SP)
                                                SWEEP:
                                                                                                                                                            4662
000002
         013700
                   000000G
                                                          MOV
                                                                    RP. ADDR. RO
                                                                                                                                                           4683
000006
         116000
                   000014
                                                          MOVB
                                                                    14(RO).RO
000012
         042700
                   177600
                                                                    #177600,RO
                                                          BIC
000016
         020027
                   000041
                                                                    RO, 441
000022
         001026
                                                          BNE
000024
         032737
                   000040 000000G
                                                                    440. SWP. FLAGS
                                                          BIT
                                                                                                                                                           4686
000032
         001422
000034
         004737
                   000000V
                                                          JSR
                                                                    PC, RPS. REM
                                                                                                                                                           4689
000040
         010001
                                                                                                             +, INDEX
                                                          MOV
                                                                    RO,R1
000042
         002416
                                                          BLT
000044
         010146
                                                          MOV
                                                                    R1,-(SP)
                                                                                                           : INDEX. *
                                                                                                                                                           4692
000046
         012746
                   000060
```

 ZRQAM3 VO1.2		RD/RX EXERCISER MULTI-DRIVE TEST ROUTIN	IES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL	SEQ 0400 Page 145 2;161 (42)
 000052 000056 000062 000064 000070 000072 000076 000100 000104 000110 000114	004737 062700 010016 004737 010116 004737 022626 013746 062716 004737 013716	000000G 000000G 000000G 000000G 000024 000000G 000000G	18:	JSR ADD MOV JSR MOV JSR CMP MOV ADD JSR MOV JSR	PC.BL\$MUL #RETPKT+24.RO RO.(SP) PC.PUT.IO.BUFF R1.(SP) PC.PUT.RETPKT (SP)+,(SP)+ RP.ADDR,-(SP) #24.(SP) PC.PUT.IO.BUFF RP.INDX.(SP) PC.PUT.RETPKT	; INDEX, 4	4693 4691 4696 4697
 000124 000126 000130	005726 012601 000207			TST MOV RTS	(SP)+ (SP)+,R1 PC	;	4678 4662

<sup>:</sup> Routine Size: 45 words. Routine Base: \$CODE\$ + 21550 : Maximum stack depth per invocation: 4 words

```
SEQ 0401
ZRQAM3
                  RD/RX EXERCISER
                                                                         14-Dec-1983 16:12:07
                                                                                                    VAX-11 Bliss-16 V3-555
                                                                                                                                              Page 146
                                                                                                    DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2:161 (43)
V01.2
                  MULTI-DRIVE TEST ROUTINES
                                                                         14-Dec-1983 16:12:00
           4699 routine RPS_REM =
           4700
:
           4701 !+
:
                           THIS ROUTINE SEARCHES THE CURRENT CONTROLLER'S RP_SAVE AREA FOR A
           4702 !
:
           4703
                           RETURN PACKET WHOSE COMMAND REFERENCE NUMBER (CRN) IS ONE LESS THAN THE
.
                           CRN OF THE CURRENT RETURN PACKET (I.E., SEARCHING FOR THE SAVED WRITE
           4704
:
           4705
                           OPERATION ASSOCIATED WITH THE CURRENT READ OPERATION). IF FOUND, THE
.
           4706
                           RP_SAVE ENTRY IS CLEARED (TO -1) AND THE RETPKT INDEX OF THE WRITE
.
           4707
                           OPERATION IS RETURNED TO THE CALLER.
:
           4708
:
           4709
                           IMPLICIT INPUTS:
:
           4710
                                    RP_ADDR - ADDRESS OF THE CURRENT RETURN PACKET
:
           4711
:
           4712
                           OUTPUTS:
.
           4713
                                    INDEX (VALUE OF THIS ROUTINE) - INDEX OF THE RETPKT CONTAINING
:
           4714
                                                       A CRN WHICH IS ONE LESS THAN THE CURRENT
:
           4715 !-
:
           4716
:
           4717
                       begin
.
           4718
:
           4719
                       local
           4720
                           index : signed word initial (-1):
                                                                                                              ! ASSUME NOT FOUND
           4721
.
           4722
                       incr COUNT from 0 to RP_CNT - 1 do
.
                                                                                                              ! FOR EACH ENTRY IN RP_SAVE
           4723
:
           4724
                           if (.RP_USE [.COUNT] eql .CCTLR) and
                                                                                                                       ! IF THIS IS A VALID RETPKT
INDEX
           4725
                               (.RETPKT [.COUNT, ENDCOD] eql (OP_WRT or OP_END))
.
           4726
.
           4727
.
                               if ((.RETPKT [.COUNT, CRF_LO] eql (.RP_ADDR [CRF_LO] - 1)) and (.RETPKT [.COUNT, CRF_HI] eql .RP_ADDR [CRF_HI])) or ((.RETPKT [.COUNT, CRF_HI] eql (.RP_ADDR [CRF_HI] - 1)) and (.RETPKT [.COUNT, CRF_LO] eql ≤o'177777') and (.RP_ADDR [CRF_LO] eql 0))
           4728
:
                                                                                                              ! IF CORRECT CRN
           4729
           4730
           4731
:
           4732
:
           4733
:
           4734
:
                                     begin
           4735
:
                                     index = .COUNT;
                                                                                                              ! INDEX TO BE RETURNED
           4736
:
                                     exitloop:
                                                                                                              ! DONE
           4737
.
                                     end:
           4738
.
           4739
                       return . index;
.
           4740
:
                       end:
                                                                                                              ! ROUTINE RPS_REM
                                                       SBTTL
                                                                RPS.REM MULTI-DRIVE TEST ROUTINES
000000
         004137
                  000000G
                                              RPS.REM: JSR
                                                                R1. $SAVE4
                                                                                                                                                   4699
000004
         012704
                  177777
                                                       MOV
                                                                #-1,R4
                                                                                                     : *.INDEX
                                                                                                                                                   4717
000010
         005003
                                                       CLR
                                                                R3
                                                                                                     : COUNT
                                                                                                                                                   4722
000012
         116300
                  00000G
                                                       MOVB
                                                                RP.USE(R3),RO
                                              14:
                                                                                                     : *(COUNT), *
                                                                                                                                                   4724
000016
         020037
                  000000G
                                                       CMP
                                                                RO, CCTLR
000022
         001053
                                                       BNE
                                                                41
000024
         010346
                                                       MOV
                                                                R3,-(SP)
                                                                                                     ; COUNT, *
                                                                                                                                                   4725
000026
         012746
                  000060
                                                       MOV
                                                                460.-(SP)
```

ZRQAM3 V01.2		RD/RX EXERCISER MULTI-DRIVE TEST R	OUTINES		14-Dec-1983 1 14-Dec-1983 1	6:12:07 6:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO	SEQ 0402 Page 147 .BL2;161 (43)
000032	004737	00000G		JSR CMP	PC,BL\$MUL (SP)+,(SP)+			
000040	126027	000014G 000242		CMPB	RETPKT+14(RO),#242			
000046	001041			BNE	4\$			
000050	010346			MOV	R3,-(SP)		COUNT, *	4728
000052	012746	000060		MOV	#60,-(SP)			4120
000056 000062	004737	00000G		JSR	PC,BL\$MUL			
000062	022626			CMP	(SP)+,(SP)+			
000064	013701	00000G		MOV	RP.ADDR,R1			
000070	016102	000004		MOV	4(R1),R2			
000074	005302	0000045		DEC	R2			
000076	026002	000004G		CMP	RETPKT+4(RO),R2			
000102	001004 026061	000006G 000006		BNE	2\$			
000112	001415	000008 000008		CMP	RETPKT+6(RO),6(R1)			4729
000114	016102	000006	2\$:	BEQ	3\$			
000120	005302	000000	24:	MOV	6(R1),R2 R2			4730
000122	026002	000006G		CMP	RETPKT+6(RO),R2			
000126	001011	000000		BNE	4\$			
000130	026027	000004G 177777		CMP	RETPKT+4(RO),#-1			4771
000136	001005			BNE	48			4731
000140 000144	005761	000004		TST	4(R1)			4732
000144	001002			BNE	46			4132
000146	010304		3\$:	MOV	R3,R4		COUNT, INDEX	4735
000150	000404			BR	5#			4734
000152	005203		44:	INC	R3		COUNT	4722
000154	020327	000003		CMP	R3,43		COUNT, *	7.66
000160	003714			BLE	1\$			
000162	010400		5#:	MOV	R4.RO		: INDEX,*	4717
000164	000207			RTS	PC			4699

Routine Size: 59 words. Routine Base: \$CODE\$ + 21702 Maximum stack depth per invocation: 8 words

ZRQAM3 VO1.2		RD/RX EXERCISER MULTI-DRIVE TEST ROUT:	INES		14 - Dec - 1983 14 - Dec - 1983	5 16:12:07 5 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL	SEQ 0403 Page 148 2:161 (44)
:	4741 4742	routine DR_RETPKT : no	ovalue -					
	4743 4744 4745 4746 4747	! THIS ROUTINE ! ! THE "DRIVER" ! ! FATAL DEVICE !	PORTION OF	BY PROC	RETPKT FOR ALL PACKE GRAM. THIS INCLUDES	ETS ORIGINATI PACKETS DESC	ING AT PRIBING	
	4748 4749 4750 4751	FOR FATAL DEVI	R. THE CON	TROLLER	OUTINE RELEASES ALL IS MARKED OFFLINE IN R ARE DROPPED.	RESOURCES HE	ID ALL	
	4752 4753 4754 4755 4756 4756	PADI CST_AI	DX - INDEX DR - ADDRE DDR - ADDR	SS OF THESS OF 1	CURRENT RETURN PACKE IE CURRENT RETURN PAC THE CURRENT CONTROLLE LER NUMBER	CKET		
	4758 4759 4760 4761	begin						
	4762	PUTA_BUFF ();			! RELEASE	ALL I/O BUFFE	RS HELD BY CONTROLLER	
:	4763 4764	incr index from 0	to RP_CNT	- 1 do	! FOR EACH	ENTRY IN COM	ITROLLER'S RP_SAVE	
:	4765 4766	if .RP_USE [.	index l eal	CCTLD		RETPKT INDEX		
:	4767	then						
:	4768 4769	PUT_RETPK	(.index)	:	! RETURN RE	ETPKT TO POOL		
	4770 4771 4772	QIO [.CCTLR] = 0; CST_ADDR [STATE]	· OFFLINE:		! MARK CST	OF OUTSTAND		
	4773	DROP_CTLR (.CCTLR PUT_RETPKT (.RP_II end;	NDX);	L);	! DROP CON ! PUT BACK ! ROUTINE (		(15	
		eno,			: NOOTINE !	DH_HEIPKI		
000000	010146		DR.RETP	KT:	DR.RETPKT MULTI-DR	IVE TEST ROUT	TINES	
000002	004737	000000G		JSR JSR	R1(SP) PC.PUTA.BUFF			4741 4762
000010	005001 116100 020037 001004	000000G 000000G	16:	CLR MOVB CMP BNE	R1 RP.USE(R1),R0 RO,CCTLR 2\$		: INDEX : *(INDEX).*	4764 4766
000020 000022 000024 000030 000032	010146 004737 005726	000000G		MOV JSR TST	R1(SP) PC,PUT.RETPKT (SP)+		: INDEX.*	4768
000034	005201 020127 003763	000003	24:	INC CMP BLE	R1 R1.03 16		: INDEX : INDEX.*	4764
000042 000046	013701 105061	000000G 000000G		MOV	CCTLR.R1			4770
000052	013700	000000G		CLRB	QIO(R1) CST.ADDR.RO			4771

ZRQAM3 VO1.2	RD/RX EXERCISER MULTI-DRIVE TEST ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.	SEQ 0404 Page 149 BL2;161 (44)
000056 04276 000064 01014 000066 01274 000072 00473	5 000006 7 00000G	BIC MOV MOV JSR	#100000.2(RO) R1(SP) #6(SP) PC.DROP.CTLR	•	4772
000076 01371 000102 00473	7 00000G	MOV JSR	RP.INDX,(SP) PC,PUT.RETPKT	•	4773
000106 02262 000110 01260 000112 00020		MOV RTS	(SP)+,(SP)+ (SP)+,R1 PC		4759 4741

<sup>:</sup> Routine Size: 38 words. Routine Base: \$CODE\$ + 22070 : Maximum stack depth per invocation: 4 words

ZRQAM3 VO1.2		RD/RX EXERCISER RDRX INTERRUPT SERVICE ROUTINES	14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 Pa DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2;161	age 150
	4775 4776 4777 4778 4779 4780 4781 4782 4783 4784 4785 4786 4787	! THERE EXISTS AN RDRX INTERRUPT SERVICE! CONTROLLER. EACH SERVICE ROUTINE BEGIN	S BY SIMPLY SETTING THE TLR". ALL SERVICE ROUTINE		
000000 000002 000006 000012 000014	005037 004737	.SBTTL AZINTO  O00076' O00000V  AZINTO::MOV RO(S CLR ICTLR MOV (SP)+	NT	OUTINES	4784 4785 4786 4784
: Rout	ne Size:	7 words. Routine Base: \$CODE\$ + 22204 depth per invocation: 2 words			

```
SEQ 0406
ZRQAM3
                    RD/RX EXERCISER
                                                                                 14-Dec-1983 16:12:07
14-Dec-1983 16:12:00
                                                                                                                 VAX-11 Bliss-16 V3-555
                                                                                                                                                               Page 151
V01.2
                    RDRX INTERRUPT SERVICE ROUTINES
                                                                                                                 DISK&USER2: [DIETZ.RDRX]ZRQACO.BL2;161 (46)
            4788 routine AZINT : novalue =
             4789
            4790 !+
             4791
                               THIS IS THE COMMON INTERRUPT SERVICE ROUTINE FOR ALL RDRX CONTROLLERS.
                    :
                              AFTER CALCULATING THE DCT ADDRESS FOR THE INTERRUPTING DEVICE, THIS ROUTINE WILL SAVE THE CURRENT CONTENTS OF THE SA REGISTER IN THE DCT. THEN, IF THE "IGNORE INTERRUPT" BIT IS SET, NO FURTHER ACTION IS TAKEN. OTHERWISE, THE SA VALUE IS CHECKED FOR A FATAL ERROR, AND THE COMMAND
             4792
             4793
             4794
             4795
                               AND RESPONSE RINGS ARE POLLED.
             4796
             4797
             4798
:
                         DCT_ADDR = DCT + (.ICTLR + DCT_LEN + 2); ! GET DCT ADDRESS ICST_ADDR = CST + (.ICTLR + CST_LEN + 2); ! GET CST ADDRESS
             4799
             4800
             4801
                         IRDRX_ADDR = .ICST_ADDR [IP_ADDR]; ! GET RDRX ADDRESS
ICOM_ADDR = COMM_AREA + (.ICTLR + COMM_LEN + 2); ! GET COMM_AREA ADDR
IDCT_ADDR [SA_SAVE] = .IRDRX_ADDR [RCSA, RC_ALL]; ! SAVE SA REGISTER
             4802
             4803
             4804
             4805
.
             4806
                          if .IDCT_ADDR [IG_INT]
:
                                                                                   ! IGNORE INTERRUPT?
             4807
                          then
             4808
                              return:
                                                                                  ! RETURN IF INTERRUPTS IGNORED
             4809
             4810
                          if BIT_TST (IDCT_ADDR [SA_SAVE], SA_ERR) ! IF FATAL ERROR
             4811
.
             4812
                              FATAL_ERROR ()
:
             4813
                          else
             4814
                              begin
                              POLL_CRING ();
POLL_RRING ();
             4815
                                                                                 ! POLL COMMAND RING
             4816
.
                                                                                ! POLL RESPONSE RING
             4817
                               end:
:
             4818
:
             4819
                         end:
                                                               SBTTL
                                                                        AZINT RDRX INTERRUPT SERVICE ROUTINES
000000 010146
                                                    AZINT:
                                                             MOV
                                                                        R1,-(SP)
-(SP)
                                                                                                                                                                      4788
000002 005746
                                                              TST
000004 013701
                    0000761
                                                              MOV
                                                                        ICTLR.R1
                                                                                                                                                                      4800
000010 010146
                                                              MOV
                                                                        R1,-(SP)
000012 012746 000022
                                                                        #22.-(SP)
                                                              MOV
000016 004737
                    000000G
                                                              JSR
                                                                        PC.BL #MUL
000022 062700
                    000000G
                                                              ADD
                                                                        OCT.RO
000026
         010037
                    000000G
                                                              MOV
                                                                        RO, IDCT. ADDR
000032
         010116
                                                              MOV
                                                                        R1,(SP)
                                                                                                                                                                      4801
000034
         012746
                    000076
                                                              MOV
                                                                        476, -(SP)
         004737
000040
                    000000G
                                                              JSR
                                                                        PC.BL SMUL
000044
          062700
                    000000G
                                                              ADD
                                                                        #CST,RO
000050
          010037
                    000000G
                                                              MOV
                                                                        RO, ICST. ADDR
(RO), IRDRX. ADDR
000054
          011037
                    000000G
                                                              MOV
                                                                                                                  : ICST.ADDR.+
                                                                                                                                                                      4802
000060
          010116
                                                              MOV
                                                                        R1.(SP)
                                                                                                                                                                      4803
000062
         012746
                    000050
                                                                        450, -(SP)
                                                              MOV
000066
         004737 000000G
                                                              JSR
                                                                        PC.BL #MUL
000072 062700 000000'
                                                              ADD
                                                                        OCOMM. AREA, RO
```

	ZRQAM3 VO1.2		RD/RX EXERCISER RDRX INTERRUPT SERVICE ROUT	TINES	14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.B	SEQ 0407 Page 152 L2:161 (46)
	000076 000102 000106 000112 000120	010037 013700 013701 016166 016660	000000G 000000G 000002 000010 000010 000002	MOV MOV MOV MOV	RO,ICOM.ADDR IDCT.ADDR,RO IRDRX.ADDR,R1 2(R1),10(SP) 10(SP),2(R0)	; *.RC.REG ; RC.REG.*	4804
the same property and the same	000126 000132 000134 000140 000144 000150	032710 001016 016600 042700 020027 001003	040000 000010 077777 100000	BIT BNE MOV BIC CMP BNE	#40000,(R0) 2\$ 10(SP),R0 #77777,R0 R0,#-100000	*.IDCT.ADDR	4806 4788 4810
	000152 000156 000160 000164 000170 000174 000176	004737 000404 004737 004737 062706 012601 000207	000000V 000000V 000012 2\$	JSR BR JSR JSR	PC.FATAL.ERROR 28 PC.POLL.CRING PC.POLL.RRING #12.SP (SP)+.R1 PC		4812 4810 4815 4816 4788

<sup>:</sup> Routine Size: 64 words. Routine Base: #CODE# + 22222 : Maximum stack depth per invocation: 7 words

```
SEQ 0408
ZRQAM3
                                  RD/RX EXERCISER
                                                                                                                                          14-Dec-1983 16:12:07
                                                                                                                                                                                               VAX-11 Bliss-16 V3-555
                                                                                                                                                                                                                                                                             Page 153
V01.2
                                  RDRX INTERRUPT SERVICE ROUTINES
                                                                                                                                          14-Dec-1983 16:12:00
                                                                                                                                                                                               DISK $USER2: [DIETZ.RDRX] ZRQACO.BL2:161 (47)
                     4820 routine FATAL_ERROR : novalue =
                     4821
                     4822 !+
                     4823
                                                    THIS ROUTINE IS CALLED BY THE INTERRUPT SERVICE ROUTINE (AZINT) UPON
                                 .
                     4824
                                                   DETECTING AN UNRECOVERABLE ERROR THROUGH THE DEVICE'S SA REGISTER. ITS PURPOSE IS TO CLEAN UP DEVICE DATA IN THE "DRIVER" PORTION OF
                                 .
                     4825
                     4826
                                                    THE EXERCISER, AND TO INFORM THE "PROGRAM" PORTION OF THE EVENT VIA
                     4827
                                                   RETURN PACKET.
                     4828
                                                   IMPLICIT IMPUTS:
                     4829
                                                                     ICTLR - INTERRUPTING CONTROLLER NUMBER
                     4830
                                                                     IDCT_ADDR - ADDRESS OF INTERRUPTING CONTROLLER'S DCT ICST_ADDR - ADDRESS OF INTERRUPTING CONTROLLER'S CST
                     4831
                     4832
                                                                     IRDRX_ADDR - ADDRESS OF INTERRUPTING CONTROLLER'S IP REGISTER
                     4833
                     4834
                                  ! -
                     4835
                     4836
                                          begin
                     4837
                     4838
                                           local
                     4839
                                                    index : signed word,
                     4840
                                                   U_SAVE : word:
                     4841
                     4842
                                           SA_REG = .IDCT_ADDR [SA_SAVE];
                                          U_SAVE = .L$LUN;

C_ERR_TBL [.ICTLR, C_ERR_HRD] = .C_ERR_TBL [.ICTLR, C_ERR_HRD] + 1;

L$LUN = .ICST_ADDR [OF_UN, D_UNIT];

ERROF (14, EGD_14, EMS_14);

L$LUN = .U_SAVE;

! SAVE PRE-INTERRUPT CUI

                     4843
                                                                                                                                           ! SAVE PRE-INTERRUPT CURRENT UNIT NUMBER
                     4844
                     4845
                                                                                                                                           ! SET CURRENT UNIT TO FIRST IN CONTROLLER
                     4846
                                                                                                                                           ! FATAL CONTROLLER ERROR
                     4847
                                                                                                                                              RESTORE PRE-INTERRUPT CURRENT UNIT
                     4848
                                           DRY_CTLERR (.ICTLR):
                                                                                                                                           ! CLEAN UP DRIVER DATA FOR CONTROLLER
                      4849
                     4850
                                           if (index = GET_RETPKT (.ICTLR)) lss 0
                                                                                                                                          ! TRY TO GET A RETPKT; IF FAILURE
                     4851
                                           then
                     4852
                                                   PRINTF (DBM18)
                                                                                                                                           ! "FATAL_ERROR: RETPKT NOT AVAILABLE"
                      4853
                                           else
                                                   begin
RETPKT [.index, CONID] = CID_DRIVER;
MESTYP] = MT_FATAL;
                      4854
                                                                                                                                           ! IF RETPKT WAS ALLOCATED
                      4855
                                                                                                                                           ! SET CONNECTION ID TO "DRIVER"
                                                    RETPKT [.index, MESTYP] = MT_FATAL;
RETPKT [.index, CTLR] = .ICTLR;
                      4856
                                                                                                                                           ! FATAL ERROR
                      4857
                                                                                                                                           ! CONTROLLER NUMBER
                      4858
                                                    IN_IODQ (.index);
                                                                                                                                           ! LOAD RETPKT INDEX INTO IODQ
                      4859
                                                                                                                                           ! IF RETPKT WAS ALLOCATED
                                                    end:
                      4860
                      4861
                                           end:
                                                                                                                                           ! ROUTINE FATAL_ERR
                                                                                                         SBTTL FATAL.ERROR RDRX INTERRUPT SERVICE ROUTINES
000000 004137 000000G
                                                                                      FATAL . ERROR:
                                                                                                        JSR
                                                                                                                         R1. $SAVE2
                                                                                                                                                                                                                                                                                      4820
000004
                013700
                                  000000G
                                                                                                        MOV
                                                                                                                          IDCT.ADDR.RO
                                                                                                                                                                                                                                                                                      4842
000010
                016037
                                  0000002 000000G
                                                                                                                          2(RO), SA.REG
                                                                                                        MOV
000016
                 013701
                                  000000G
                                                                                                                          L$LUN,R1
                                                                                                        MOV
                                                                                                                                                                                                : *.U.SAVE
                                                                                                                                                                                                                                                                                      4843
000022
                 013700
                                  0000761
                                                                                                        MOV
                                                                                                                          ICTLR, RO
                                                                                                                                                                                                                                                                                      4844
000026
                 006300
                                                                                                        ASL
000030
                105260
                                  000000G
                                                                                                                          C.ERR. TBL(RO)
```

				1110		
ZRQAM3 VO1.2		RD/RX EXERCISER RDRX INTERRUPT SERVICE R	OUTINES	14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO	SEQ 0409 Page 154 .BL2;161 (47)
000034 000040 000044	013700 016002 000302	000000G 000006	MOV MOV SWAB	ICST.ADDR,RO 6(RO),R2 R2	•	4845
000046 000052 000056	042702 010237 104455	177760 000000G	BIC MOV TRAP	#177760,R2 R2,L\$LUN 55		4846
000060 000062 000064	000016 000000G 000000G		. WORD . WORD . WORD	16 EGD.14 EMS.14		4040
000066 000072 000076	010137 013746 004737	000000G 000076' 000000G	MOV MOV JSR	R1,L\$LUN ICTLR,-(SP) PC.DRV.CTLERR	; U.SAVE,*	4847 4848
000102 000106 000112	010001	000076' 000000G	MOV JSR MOV	PC.GET.RETPKT RO.R1	: *.INDEX	4850
000114 000116 000122	012746	000000G 000001	BGE MOV MOV MOV	1\$ #OBM18,(SP) #1(SP) SP.RO	: SP.*	4852
000126 000130 000132 000134	104417 000424 010116		TRAP BR 1\$: MOV	17 2\$ R1.(SP)	INDEX.4	4850 4855
000136 000142 000146	012746 004737 062700	000060 00000G 000002G	MOV JSR ADD	#60,-(SP) PC.BL#MUL #RETPKT+2,RO		4033
000152 000160 000164 000170	042702	000003 000001 000076' 177760	MOVB MOV BIC	#3,1(RO) ICTLR,R2 #177760,R2		4857
000176 000176 000200	112710 150210 010116 004737	000060	MOVB BISB MOV	#60.(RO) R2.(RO) R1.(SP)	; INDEX.*	4858
000204 000206	022626 000207	000000G	24: JSR CMP RTS	PC.IN.IODQ (SP)+.(SP)+ PC		4836 4820
. David	6:			00100		

Routine Size: 68 words. Routine Base: \$CODE\$ + 22422 : Maximum stack depth per invocation: 7 words

```
SEQ 0410
                 RD/RX EXERCISER
ZRQAM3
                                                                       14-Dec-1983 16:12:07
14-Dec-1983 16:12:00
                                                                                                  VAX-11 Bliss-16 V3-555
                                                                                                  VAX-11 Bliss-16 V3-555 Page 155
DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (48)
V01.2
                 RDRX INTERRUPT SERVICE ROUTINES
           4862 routine POLL_CRING : novalue =
           4863
           4864
           4865 !
                           THIS ROUTINE IS CALLED BY THE RDRX INTERRUPT SERVICE ROUTINE (AZINT)
                          FOR EACH DEVICE INTERRUPT EXCEPT DURING INITIALIZATION OR FATAL ERROR.
           4866
           4867
                          ITS PURPOSE IS TO SCAN THE DEVICE'S COMMAND RING AND CHECK FOR ANY
                          COMMAND SLOTS THAT HAVE BEEN "TAKEN" BY THE CONTROLLER. SUCH SLOTS
           4868
           4869
                          HAVE BEEN RETURNED TO THE HOST, INDICATED BY A ZERO OWNERSHIP BIT. FOR
           4870
                          EACH SLOT THAT HAS BEEN RETURNED TO THE HOST, THE CRING COUNT IS
           4871
                          DECREMENTED, AND THE CR_POLL ADDRESS IS ADVANCED TO THE NEXT SLOT IN
.
           4872
                          THE COMMAND RING.
:
           4873
:
           4874
                          IMPLICIT IMPUTS:
.
           4875
                                   ICTLR - INTERRUPTING CONTROLLER NUMBER
:
                                   IDCT_ADDR - ADDRESS OF INTERRUPTING CONTROLLER'S DCT
ICOM_ADDR - ADDRESS OF INTERRUPTING CONTROLLER'S COMM_AREA
           4876
           4877
           4878 !-
:
           4879
.
           4880
                      begin
.
           4881
                      while ((.IDCT_ADDR [CRING_CNT] gtru 0) and ! WHILE # OF COMMANDS IN CRIN not (BIT_TST ((.IDCT_ADDR [CR_POLL] + 2), ED_OWN))) do ! CURRENT SLOT IS HOST-OWNED
           4882
                                                                                         ! WHILE # OF COMMANDS IN CRING > O AND
           4883
           4884
                          begin
IDCT_ADDR [CRING_CNT] = .IDCT_ADDR [CRING_CNT] - 1;
           4885
                                                                                         ! DECREMENT # CMDS IN CRING
.
           4886
                           IDCT_ADDR [CR_POLL] = .IDCT_ADDR [CR_POLL] + 4:
                                                                                         ! ADVANCE TO NEXT SLOT TO POLL
:
           4887
           4888
                           if .IDCT_ADDR [CR_POLL] gtra .IDCT_ADDR [CR_END]
                                                                                         ! IF BEYOND END OF RING
           4889
                           then
           4890
                               IDCT_ADDR [CR_POLL] = .IDCT_ADDR [CR_BEG];
                                                                                         ! SET POINTER TO TOP OF CRING
           4891
           4892
                          end;
           4893
           4894
                      ICOM_ADDR [CMD_INT] = 0;
                                                                                         ! CLEAR COMMAND INTERRUPT WORD IN RING HEADER
           4895
                      end:
                                                      .SBTTL POLL.CRING RDRX INTERRUPT SERVICE ROUTINES
000000 004137 000000G
                                            POLL . CRING:
                                                      JSR
                                                              R1, $SAVE2
                                                                                                                                               4862
000004
         013701
                  000000G
                                                              IDCT. ADDR, R1
                                                     MOV
                                                                                                                                               4882
000010
        012702
                  000016
                                                     MOV
                                                              $16,R2
                                                                                                                                               4886
000014
         060102
                                                      ADD
                                                              R1,R2
000016
         105711
                                                              (R1)
                                                      TSTB
                                            18:
                                                                                                                                               4882
000020
         001422
                                                      BEQ
                                                              21
000022
         016100
                  000016
                                                              16(R1),R0
                                                     MOV
                                                                                                                                               4883
000026
         016000
                  000002
                                                     MOV
                                                              2(RO), RO
000032
         042700
                  077777
                                                     BIC
                                                              #77777.RO
000036
         020027
                  100000
                                                     CMP
                                                              RO, #-100000
000042
         001411
                                                     BEQ
000044
         105311
                                                     DECB
                                                              (R1)
                                                                                                                                               4885
000046
         062712
                  000004
                                                      ADD
                                                              44,(R2)
                                                                                                                                               4886
                                                                                                   .
000052
        021261
                  000012
                                                     CMP
                                                              (R2),12(R1)
                                                                                                                                               4888
000056
        101757
                                                     BLOS
```

J16

	ZRQAM3 VO1.2		RD/RX EXERCISER RDRX INTERRUPT SERVICE	ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK*USER2:[DIETZ.RDRX]ZRQACO.B	SEQ 0411 Page 156 L2;161 (48)
	000060	016112	000010		MOV BR	10(R1),(R2)		4890
-	000066	013700	000000G 000004	2\$:	MOV	ICOM. ADDR. RO		4882 4894
-	000076	000207	00004		RTS	4(RO) PC		4862

<sup>:</sup> Routine Size: 32 words, Routine Base: \$CODE\$ + 22632 : Maximum stack depth per invocation: 4 words

```
SEQ 0412
ZRQAM3
                      RD/RX EXERCISER
                                                                                         14-Dec-1983 16:12:07
                                                                                                                          VAX-11 Bliss-16 V3-555
                                                                                                                                                                            Page 157
V01.2
                      RDRX INTERRUPT SERVICE ROUTINES
                                                                                         14-Dec-1983 16:12:00
                                                                                                                          DISK $USER2: [DIETZ.RDRX]ZRQACO.BL2:161 (49)
                     routine POLL_RRING : novalue =
              4896
              4897
.
              4898
                      ! +
:
                                 THIS ROUTINE IS CALLED BY THE RDRX INTERRUPT SERVICE ROUTINE (AZINT) FOR EACH DEVICE INTERRUPT EXCEPT DURING INITIALIZATION OR FATAL ERROR. ITS PURPOSE IS TO SCAN THE DEVICE'S RESPONSE RING AND CHECK FOR ANY SLOTS WHICH HAVE BEEN RETURNED TO THE HOST (OWNERSHIP BIT = 0). FOR
              4899
:
              4900
:
              4901
              4902
                                 EACH SUCH SLOT, THE ASSOCIATED MESSAGE IS PROCESSED BASED ON ITS CONNECTION ID (MSCP OR DUP). AFTER PROCESSING, THE MESSAGE PACKET
              4903
.
              4904
.
              4905
                                 IS RE-INITIALIZED AND RETURNED TO THE CONTROLLER (OWNERSHIP BIT SET
.
              4906
                                 TO 1).
:
              4907
:
              4908
                                 IMPLICIT INPUTS:
:
              4909
                                            ICTLR - NUMBER OF INTERRUPTING CONTROLLER
              4910
                                             IDCT_ADDR - ADDRESS OF INTERRUPTING CONTROLLER'S DCT
:
              4911 !-
:
              4912
:
              4913
                            begin
:
              4914
:
              4915
                            while not (BIT_TST ((.IDCT_ADDR [RR_POLL] + 2), ED_OWN)) do
:
                                                                                                                                  ! WHILE O = O
              4916
                                 begin
IPKT_ADDR = ..IDCT_ADDR [RR_POLL] - 10; ! ADDRESS OF RESPONSE PACKET
:
              4917
.
              4918
.
              4919
                                  if NOT (.IPKT_ADDR (CONNID) eql CID_DUP)
.
              4920
:
                                 then (CREDIT_BAL = .CREDIT_BAL + .IPKT_ADDR [CREDITS];);
                                                                                                                                      ! It was notice that Dup was sending
              4921
                                                                                                                                      ! credits back which it should not
              4922
                                 selectoneu .IPKT_ADDR [CONNID] of
:
              4923
:
              4924
:
                                       [CID_MSCP] :
              4925
:
                                                                   MSCP_RSP ();
              4926
                                       [CID_DUP] :
                                                                   DUP_RSP ():
              4927
:
              4928
                                                                  PRINTF (DBM20, .IPKT_ADDR [CONNID], .IRDRX_ADDR);
! "BAD CONN ID = XXXXX RECEIVED FROM XXXXXX"
                                       [otherwise] :
:
              4929
:
              4930
:
                                       tes:
              4931
:
                                 IPKT_ADDR (MSGLEN) = MSG_LEN + 2;
IDCT_ADDR (RR_POLL) = .IDCT_ADDR (RR_POLL) + 2; ! ADVANCE TO HI ORDER WORD OF RING SLOT
.IDCT_ADDR (RR_POLL) = .IPKT_ADDR (PKT_HI); ! RETURN SLOT TO CONTROLLER
.IDCT_ADDR (RR_POLL) = ..IDCT_ADDR (RR_POLL) or ED_OWN or ED_FLAG; ! OWNERSHIP TOO
IDCT_ADDR (RR_POLL) = .IDCT_ADDR (RR_POLL) + 2; ! ADVANCE TO NEXT RRING SLOT
              4932
              4933
              4934
.
              4935
.
              4936
4937
:
:
              4938
:
                                  if .IDCT_ADDR [RR_POLL] gtra .IDCT_ADDR [RR_END]! IF BEYOND END OF RING
              4939
:
              4940
                                       IDCT_ADDR [RR_POLL] = .IDCT_ADDR [RR_BEG]; ! CYCLE TO TOP OF RING
:
              4941
.
              4942
                                                                                         ! WHILE LOOP
.
              4943
                            ICOM_ADDR [RSP_INT] = 0;
                                                                                         ! CLEAR RESPONSE INTERRUPT WORD IN RING HEADER
:
              4944
                            end;
.
```

000000 004137 000000G

.SBTTL POLL.RRING RDRX INTERRUPT SERVICE ROUTINES POLL.RRING:

						L10		
ZRQAM3 VO1.2		RD/RX EX	KERCISER TERRUPT S	ERVICE ROUTINE	s	14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO	SEQ 0413 Page 158 .BL2;161 (49)
000004 000010	013702 062702	000000G 000014			JSR MOV ADD	R1, \$SAVE3 IDCT.ADDR,R2 #14,R2	;	4896 4915
000014 000016 000022 000036 000034 000042 000050 000054 000056 000062 000066 000070	011200 016000 042700	000002 077777 100000		1\$:	MOV MOV BIC CMP	(R2),R0 2(R0),R0 #77777,R0 R0,#-100000		
000032	020027 001506 017237 162737	000000	000000G 000000G		BEQ MOV SUB	6\$ 80(R2),IPKT.ADDR #12,IPKT.ADDR	1	4917
000050 000054	013700 005001	000000G	000000		MOV	IPKT.ADDR.RO		4919
000056 000062 000066	156001 020127 001410	000011			BISB CMP BEQ	11(RO),R1 R1,#2 2\$		
OOOTOO	116003 042703 063703	000010 177760 000000G			MOVB BIC ADD	10(R0).R3 #177760.R3 CREDIT.BAL.R3	•	4920
000104	010337	00000G		24:	MOV TST	R3.CREDIT.BAL R1		4922
000110 000112 000114	001003 004737 000421	000000V			BNE JSR BR	PC.MSCP.RSP	•	4925 4922
000120 000122 000126	020127	000002		3#:	CMP BNE	R1,02		4762
000130 000134 000136	004737	000000V			JSR BR	PC, DUP, RSP	:	4926 4922
000142 000144 000150	013746 010146 012746 012746	000000G 000003		44:	MOV MOV	IRDRX.ADDR,-(SP) R1,-(SP) #DBM20,-(SP)		4928
000154 000156 000160	010600 104417 062706				MOV MOV TRAP	#3,-(SP) SP,R0 17	; SP.*	
000164 000170	013700	000010 00000G 000074	000006	54:	ADD MOV MOV	#10.SP IPKT.ADDR.RO #74.6(RO)		4932
000176 000202 000204	012760 013701 010102 062702	000000G 000014			MOV MOV ADD	IDCT.ADDR,R1 R1,R2 #14,R2	•	4933
000210	062712 016072 052772	000005	000000		ADD MOV	#2,(R2) 2(R0),80(R2)		4934
000222	062712	140000	000000		BIS	#-40000,80(R2) #2,(R2)		4935 4936
000234	021261 101665	000006			BLOS	(R2),6(R1)	•	4938
000242 000246	016112	000004			MOV BR	4(R1),(R2) 1\$		4940 4915
000250 000254	013700	000000G 000006		64:	MOV CLR	ICOM. ADDR, RO 6(RO)	•	4943
000260	000207				RTS	PC	•	4896

Routine Size: 89 words, Routine Base: \$CODE\$ + 22732 Haximum stack depth per invocation: 10 words

Page 159

```
ZRQAM3
                    RD/RX EXERCISER
                                                                                 14-Dec-1983 16:12:07
                                                                                                               VAX-11 Bliss-16 V3-555
V01.2
                    RDRX INTERRUPT SERVICE ROUTINES
                                                                                                               DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (50)
                                                                                 14-Dec-1983 16:12:00
                   ROUTINE DUP_RSP : NOVALUE =
            4946
:
            4947
.
            4948 !+
:
            4949 !
                              THIS ROUTINE IS CALLED BY POLL RRING FOR EACH DUP RESPONSE
            4950
                              ITS GENERAL PURPOSE IS TO ACT ON A DATAGRAM OR SEQUENTIAL MESSAGE.
            4951
                              IF THE MESSAGE TYPE IS SEQUENTIAL, THE ROUTINE COPIES THE
            4952
                              CONTENTS OF THE MESSAGE ENVELOPE INTO A RETURN PACKET SO THAT THE
.
                              ENVELOPE CAN BE RETURNED TO THE CONTROLLER.
            4953
:
            4954
:
            4955
                              IMPLICIT INPUTS:
:
                                        ICTLR - INTERRUPTING CONTROLLER NUMBER
            4956
:
            4957
                                        IPKT_ADDR - ADDRESS OF MSCP ENVELOPE CONTAINING RESPONSE
:
            4958
            4959
                         begin
.
            4960
:
            4961
                         local
:
                              R_INDEX : signed word,
            4962
:
            4963
                              SRC_ADDR.
:
            4964
                              DST_ADDR.
:
            4965
                              R_ADDR : ref block [RP_LEN, word] field (RP_FIELDS);
            4966
                         !PRINTX (DER34);
:
            4967
.
            4968
                         incr COUNT from 0 to PKT_CNT - 1 do
:
            4969
:
                              if (.MSCP_PKT [.COUNT, CRN_LO] eql .IPKT_ADDR [CRN_LO]) and
  (.MSCP_PKT [.COUNT, CRN_HI] eql .IPKT_ADDR [CRN_HI]) and
  (.MSCP_PKT [.COUNT, PKT_LO] neqa .IPKT_ADDR [PKT_LO]) and
  ((.MSCP_PKT [.COUNT, OPCODE] and OP_END) neq OP_END) and
  (.MSCP_PKT [.COUNT, CONNID] eql CID_DUP) and
  ((.IPKT_ADDR [OPCODE] and OP_END) eql OP_END)
            4970
:
                                                                                                               ! IF THIS IS THE ASSOC CMD
            4971
:
            4972
.
            4973
.
            4974
:
            4975
.
            4976
                              then
            4977
                                   begin
P_INDEX = .COUNT;
.
            4978
.
                                                                                 ! SET PKT NUMBER
            4979
.
                                   exitloop:
            4980
:
                                   end:
             4981
:
             4982
                         if .P_INDEX les 0
                                                                                 ! IF COMMAND NOT FOUND
             4983
:
                         then
             4984
                              PRINTF (DBM108, .IPKT_ADDR [CRN_LO]); ! UNKNOWN COMMAND REF. NUMBER
.
             4985
:
             4986
:
                              return;
             4987
:
                              end:
             4988
:
             4989
                         if (R_INDEX = GET_RETPKT (.ICTLR)) les 0
                                                                                 ! IF RETPKT IS NOT AVAILABLE
             4990
:
                              PRINTF (DBM112)
             4991
.
                                                                                 ! "DUP-RSP: RETPKT NOT AVAILABLE"
             4992
                         else
:
                             begin
SRC_ADDR = .IPKT_ADDR + 6; ! SET UP COPY (SKIP OVER PKT DESC)
R_ADDR = DST_ADDR = RETPKT + (.R_INDEX * RP_LEN * 2); ! START OF ALLOCATED RETPKT
             4993
4994
:
:
             4995
:
             4996
:
             4997
                              incr COUNT from 1 to RP_LEN do
:
```

						DI		
ZRQAM3		RD/RX EXERC	ISER			14-Dec-1983 16:12:0	7 VAX-11 Bliss-16 V3-555	SEQ 0415 Page 160
v01.2		RDRX INTERR	UPT SERVIC	E ROUTINE	S	14-Dec-1983 16:12:0	DISK SUSER2: [DIETZ.RDRX]	ZRQACO.BL2;161 (50)
:	4998		begin		4000			
•	4999		.DST_ADDR	- DET OF	ADDR:	! COPY 1 WORD	ON ADDD	
	5000 5001		DST_ADDR SRC_ADDR	UST_AU	DR + 2:	! ADVANCE DESTINATI ! ADVANCE SOURCE AD	ON ADDR	
	5002		end:	SAC_AU	DK . 5!	! COPY LOOP	UR .	
:	5003		eno;			: COPY LOOP		
	5004	IN	IODQ (.R_I	NDEX):		! PUT RETPKT INDEX	INTO TODO	
	5005	end				! IF RETPKT WAS ALL	OCATED	
	5006							
	5007							
:	5008	if .P_1	INDEX geq 0			! IF ASSOC CMD PKT	WAS FOUND	
	5009	then						
:	5010	PUI	T_PKT (.P_I	NDEX);		! RETURN COMMAND PA	CKET TO POOL	
:	5011					. DOUTTHE DIE DOO		
	5012	end;				! ROUTINE DUP-RSP		
					. SBTTL		ICE ROUTINES	
000000	004137	000000G		DUP.RS		R1. \$SAVE3	1	494
000004		000000G			MOV	IPKT.ADDR,R1	1	497
000010	005002				CLR	R2	: COUNT	496
000012	010246 012746	000104		1\$:	MOV	R2,-(SP)	: COUNT, 4	497
000020	004737	000104 000000G			JSR	#104,-(SP) PC,BL\$MUL		
000024	022626	000000			CMP	(SP)+,(SP)+		
000026	026061	000012G 000	0012		CMP	MSCP.PKT+12(R0),12(R1)		
000034	001024				BNE	21		
000036	026061	000014G 000	0014		CMP	MSCP.PKT+14(RO),14(R1)		497
000044	001020				BNE	2\$		
000046	026011	000000G			CMP	MSCP.PKT(RO),(R1)		497
000052	001415	0000000			BEQ	5\$		407
000060	105760	000022G			TSTB	MSCP.PKT+22(RO)		497
2000062	126027	000011G 000	0002		BMI CMPB	2\$ MSCP.PKT+11(RO).#2		497
000070	001006	0000110 000	7002		BNE	2\$		
	105761	000022			TSTB	22(R1)		497
000076	100003				BPL	21		
000100	010237	000000G			MOV	R2.P.INDEX	; COUNT. 4	497
000104	000406				BR	34	1	497
000106	005202			2\$:	INC	R2	: COUNT	496
000110	020227	000013			CMP	R2.013	: COUNT.4	
000116	003736 005737	00000G			BLE	P. INDEX		498
000122	002013	000000		34:	BGE	46		430
000124	016146	000012			MOV	12(R1),-(SP)		498
000130	012746	00000G			MOV	#D8M108, -(SP)		
000134	012746	000002			MOV	#2,-(SP)		
000140	010600				MOV	SP.RO	: SP.4	
000142	104417				TRAP	17		
000144	062706	000006			ADD	06.SP	1	498
000150	000207	0000761			RTS	PC		498
000152 000156	013746	0000761 000000G		46:	MOV	ICTLR, -(SP)		498
300136	004/5/	000000			JSR	PC.GET.RETPKT		

ZRQAM3 VO1.2		RD/RX EXERCISER RDRX INTERRUPT SERVICE	ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00		Page 161 2:161 (50)
000162				MOV	RO,R3	: *.R.INDEX	
000164				TST	(SP). R3	; R.INDEX	
000170				BGE	51		
000172	012746	00000G		MOV	#DBM112,-(SP)		4991
000176		000001		MOV	01,-(SP)		4774
000202	010600	000001		MOV	SP.RO	; SP.4	
000204	104417			TRAP	17		
000206				BR	78		4989
000210	013701	00000G	58:	MOV	IPKT.ADDR.R1	. SRC.ADDR	4994
000214	062701	000006		ADD	96,R1	SRC. ADDR	7,,,
000220	010346	00000		MOV	R3,-(SP)	R. INDEX.	4995
000222	012746	000060		MOV	060,-(SP)	,	4,,,,
000226	004737	00000G		JSR	PC.BL \$MUL		
000232	062700	00000G		ADD	PRETPKT, RO		
000236	010002	000000		MOV	RO.R2	: *.DST.ADDR	
000240	012700	000030		MOV	#30.R0	COUNT	4997
000244	012122		68:	MOV	(R1)+,(R2)+	; SRC.ADDR.DST.ADDR	4999
000246	005300			DEC	RO	COUNT	4997
000250	001375			BNE	61		
000252	010316			MOV	R3,(SP)	; R.INDEX.*	5004
000254	004737	000000G		JSR	PC.IN. IODQ		
000260	013700	000000G	78:	MOV	P. INDEX, RO		5008
000264	002403			BLT	81		
000266				MOV	RO,(SP)		5010
000270	004737	000000G		JSR	PC.PUT.PKT		
000274			81:	CMP	(SP)+,(SP)+		4959
000276	000207			RTS	PC		4946
: Rout	ine Size: mum stack	96 words. Routin	e Base: 9 words	*CODE * ·	23214		

; 5013

ZRQAM3 VO1.2		RD/RX EXERCISER RDRX INTERRUPT SERVICE	E ROUTINES			16:12:07	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.8	SEQ 0417 Page 162 L2;161 (51)
	5014	routine MSCP_RSP : no	value =					
	5015							
	5016	!•						
	5017				RRING FOR EACH RESPO			
	5018	! WHICH HAS A C	ONNECTION	ID INDIC	ATING A DISK MSCP OR	IGINATOR		
:	5019	! (I.E., ALL EX	CEPT DUP R	ESPONSES	). ITS PURPOSE IS TO	PASS		
	5020	: CONTROL TO TH	E APPROPRI	ATE ROUT	INE BASED ON THE MES	SAGE TYPE		
	5021 5022	: FIELD (SEGUEN	ITAL. DATA	GRAM, UN	CREDIT NOTIFICATION	1).		
	5023	IMPLICIT INPU	TS.					
	5024			RESS OF	MSCP PACKET CONTAINS	NG RESPONSE		
	5025			MESSAGE		NO NEST ONSE		
	5026	!-						
:	5027							
:	5028	. selectoneu .IPKT_	ADDR [MSGT	YP] of				
:	5029	set						
•	5030	[MT CEO]	CEOLEN					
	5031 5032	(MT_SEQ) :	SEQUEN	();				
:	5033	[MT_DG] :	DATAGM	().				
	5034	12007 .	on mon	.,,				
	5035	[otherwise] :	PRINTF	(DBM21.	. IPKT_ADDR [MSGTYP]	! "MES!	SAGE TYPE XX RECEIVED"	
:	5036	tes;						
000000 000002 000006 000012 000014 000016	013700	000000G 000010	MSCP.RS	MOV MOVB ASR ASR ASR	R1,-(SP) IPKT.ADDR.R0 10(R0),R1 R1 R1 R1		•	5014 5028
000020	006201			ASR	R1			
000022	042701	177760		BIC	#177760.R1			
000026	001003			BNE	16			
000034	004/5/	000000V		JSR	PC. SEQUEN			5031
000036	000417	000001		BR	36		•	5028
000042	001003	000001	18:	CMP BNE	R1.01			
000044	004737	000000V		JSR	PC.DATAGM			5033
000050	000411			BR	36			5028
000052	010146		21:	MOV	R1,-(SP)			5035
000054	012746	000000G		MOV	#DBM21,-(SP)			
000060	012746	000002		MOV	#2(SP)			
000064 000066	010600			MOV	SP.RO		; SP.*	
000070	104417	000006		TRAP	17			
000074	012601	000008	3#:	MOV	#6,SP (SP)+,R1			EOLA
	000207		34:	RTS	PC PC			5014
	ne Size:	32 words, Routi	ne Base:	*CODE*				

```
SEQ 0418
ZRQAM3
                     RD/RX EXERCISER
                                                                                   14-Dec-1983 16:12:07
                                                                                                                  VAX-11 Bliss-16 V3-555
                                                                                                                                                                 Page 163
V01.2
                     RDRX INTERRUPT SERVICE ROUTINES
                                                                                   14-Dec-1983 16:12:00
                                                                                                                  DISK $USER2: [DIETZ.RDRX]ZRQACO.BL2:161 (52)
             5037 routine SEQUEN : novalue =
:
             5038
:
             5039
                    ! .
                               THIS ROUTINE IS CALLED BY MSCP_RSP FOR EACH DISK MSCP RESPONSE MESSAGE WITH THE "SEQUENTIAL" MESSAGE TYPE. ITS GENERAL PURPOSE IS TO COPY THE CONTENTS OF THE MESSAGE PACKET INTO A RETURN PACKET SO THAT THE
             5040
             5041
             5042
             5043
                               PACKET CAN BE RETURNED TO THE CONTROLLER. IN ADDITION.
                               IF THE COMMAND WAS AN I/O TRANSFER (READ, WRITE, OR ACCESS), THEN SOME FIELDS OF THE COMMAND PACKET ARE COPIED INTO THE RETURN PACKET.
             5044
             5045
             5046
             5047
                               IMPLICIT IMPUTS:
             5048
                                          ICTLR - INTERRUPTING CONTROLLER NUMBER
             5049
                                         IPKT_ADDR - ADDRESS OF MSCP PACKET CONTAINING RESPONSE
             5050 !-
             5051
             5052
                          begin
             5053
             5054
                          local
             5055
                               R_INDEX : signed word,
                               SRC_ADDR.
DST_ADDR.
             5056
             5057
             5058
                               R_ADDR : ref block [RP_LEN, word] field (RP_FIELDS),
             5059
                               TEMP UNIT
                               SFT_ERR_PRINTED : byte initial (byte (FALSE));
             5060
             5061
             5062
                          incr COUNT from 0 to PKT_CNT - 1 do
             5063
             5064
                               if (.MSCP_PKT [.COUNT, CRN_LO] eql .IPKT_ADDR [CRN_LO]) and (.MSCP_PKT [.COUNT, CRN_HI] eql .IPKT_ADDR [CRN_HI]) and
                                                                                                                  ! IF THIS IS THE ASSOC CMD
             5065
                                   (.MSCP_PKT [.COUNT, PKT_LO] nege .IPKT_ADDR [PKT_LO]) and ((.MSCP_PKT [.COUNT, OPCODE] and OP_END) neg OP_END) and (.MSCP_PKT [.COUNT, MSGTYP] eql MT_SEQ) and ((.IPKT_ADDR [OPCODE] and OP_END) eql OP_END) and
             5066
             5067
             5068
             5069
             5070
                                   (.PKT_USE [.count] eql .ICTLR)
                                                                                                                  ! don't want old packets from other controll
er
             5071
                               then
             5072
                                    begin
P_INDEX = .COUNT:
:
             5073
                                                                                  ! SET PKT NUMBER
             5074
                                    exitloop;
             5075
                                    end:
             5076
             5077
                          if .P_INDEX les 0
                                                                                  ! IF COMMAND NOT FOUND
             5078
                          then
             5079
                               begin
             5080
                               PRINTF (DBM108, .IPKT_ADDR [CRN_LO]); ! UNKNOWN COMMAND REF. NUMBER
             5081
                               return;
             5082
             5083
             5084
                          if (R_INDEX = GET_RETPKT (.ICTLR)) les 0
                                                                                   ! IF RETPKT IS NOT AVAILABLE
             5085
                          then
             5086
                               PRINTF (DBM22)
                                                                                   ! "SEQUEN: RETPKT NOT AVAILABLE"
             5087
                          else
             5088
                               begin
SRC_ADDR = .IPKT_ADDR + 6;
             5089
                                                                                ! SET UP COPY (SKIP OVER PKT DESC)
```

```
SEQ 0419
ZRQAM3
                    RD/RX EXERCISER
                                                                                  14-Dec-1983 16:12:07
                                                                                                                VAX-11 Bliss-16 V3-555
                                                                                                                                                               Page 164
                    RDRX INTERRUPT SERVICE ROUTINES
                                                                                                                DISK $USER2: [DIETZ.RDRX]ZRQACO.BL2;161 (52)
V01.2
                                                                                 14-Dec-1983 16:12:00
            5090
                              R_ADDR = DST_ADDR = RETPKT + (.R_INDEX * RP_LEN * 2); ! START OF ALLOCATED RETPKT
             5091
             5092
                               incr COUNT from 1 to RP_LEN do
             5093
                                    begin
                                   .DST_ADDR = ..SRC_ADDR;
DST_ADDR = .DST_ADDR + 2;
SRC_ADDR = .SRC_ADDR + 2;
             5094
                                                                                  ! COPY 1 WORD
             5095
                                                                                  ! ADVANCE DESTINATION ADDR
             5096
                                                                                  ! ADVANCE SOURCE ADDR
             5097
             5098
                                   if .IPKT_ADDR [OPCODE] eql (OP_ONL or OP_END)
                                                                                                    ! IF THIS IS THE ONLINE END MESSAGE
             5099
                                   then
             5100
                                        if .COUNT eql 10
            5101
                                                                                ! SKIP OVER RESERVED WORDS
            5102
                                         then
                                              SRC_ADDR = .SRC_ADDR + 4; !
            5103
                                                                                          IN ONLINE END - MESSAGE
             5104
             5105
                                    end:
                                                                                 ! COPY LOOP
             5106
             5107
                              R_ADDR [CTLR] = .ICTLR;
                                                                                 ! LOAD CONTROLLER NUMBER INTO PACKET
            5108
            5109
                               if .P_INDEX geq 0
                                                                                 ! IF ASSOC. CMD PKT WAS FOUND
             5110
             5111
                                    if (.IPKT_ADDR [OPCODE] eql (OP_RD or OP_END)) or ! IF END MESSAGE IS
             5112
                                        (.IPKT_ADDR [OPCODE] eql (OP_WRT or OP_END)) or !
             5113
                                                                                                               READ, WRITE, OR
                                        (.IPKT_ADDR [OPCODE] eql (OP_ACC or OP_END))
             5114
             5115
                                    then
                                        R_ADDR [CMDMOD] = .MSCP_PKT [.P_INDEX, MODIFY]; ! COPY
R_ADDR [CBCNT_LO] = .MSCP_PKT [.P_INDEX, BC_LO];! RELEVANT
R_ADDR [CBCNT_HI] = .MSCP_PKT [.P_INDEX, BC_HI];! FIELDS
R_ADDR [LBN_LO] = .MSCP_PKT [.P_INDEX, LBN_L]; ! FROM
R_ADDR [LBN_HI] = .MSCP_PKT [.P_INDEX, LBN_H]; ! COMMAND
R_ADDR [BUFF_O] = .MSCP_PKT [.P_INDEX, BUF_O]; ! PACKET
R_ADDR [BUFF_O] = .MSCP_PKT [.P_INDEX, BUF_O]; ! TO RETPK
             5116
             5117
            5118
             5119
             5120
             5121
             5122
             5123
                                                                                                      ! TO RETPKT
             5124
                                                                                                       ! IF ENDCODE WAS READ, WRITE, OR ACCESS
                                         end:
             5125
             5126
             5127
                              IN_IODQ (.R_INDEX);
                                                                                                       ! PUT RETPKT INDEX INTO IODQ
             5128
                                                                                                       ! IF RETPKT WAS ALLOCATED
             5129
             5130
                         if (.IPKT_ADDR [STATUS_CODE] neg ST_SUC) or
(.IPKT_ADDR [STATUS_SUBCODE] neg 0)
             5131
             5132
                          then
             5133
                              LAST_PKT [.ICTLR, LAST_HRD_ERR] = HRD_OCCURED
                                                                                                      ! SAVE ERROR CONDITION
             5134
                         else
             5135
                               LAST_PKT [.ICTLR, LAST_HRD_ERR] = HRD_NOT_OCCURED;
             5136
             5137
                         LAST_PKT [.ICTLR, LAST_CRN_LO] = .IPKT_ADDR [CRN_LO];
LAST_PKT [.ICTLR, LAST_CRN_HI] = .IPKT_ADDR [CRN_HI];
                                                                                                       ! SAVE COMMAND REFERENCE NUMBER
             5138
             5139
             5140
                          incr index from 0 to EP_CNT - 1 do
                                                                                                      ! IF CORRESPONDING REF NUM HAD AN ERROR-LOG
             5141
             5142
                               if (.ELOG_PKT [.index, EL_CNTR] eql .ICTLR) and
```

```
SEQ 0420
ZRQAM3
                RD/RX EXERCISER
                                                                 14-Dec-1983 16:12:07
                                                                                          VAX-11 Bliss-16 V3-555
                                                                                                                               Page 165
V01.2
                RDRX INTERRUPT SERVICE ROUTINES
                                                                 14-Dec-1983 16:12:00
                                                                                          DISK&USER2:[DIETZ.RDRX]ZRQACO.BL2:161 (52)
          5143
                           (.ELOG_PKT [.index, EL_CRN_LO] eql .IPKT_ADJR [CRN_LO]) and
                           (.ELOG_PKT [.index, EL_CRN_HI] eql .IPKT_ADDR [CRN_HI]) and
          5144
          5145
                           (.ELOG_PKT [.index, EL_CONTENTS] eq1 FULL)
          5146
                        then
          5147
                            begin
          5148
          5149
                            if .LAST_PKT [.ICTLR, LAST_HRD_ERR] eq1 HRD_NOT_OCCURED
                                                                                       ! IF SOFT ERROR OCCURED
          5150
          5151
          5152
                                 if .ELOG_PKT [.index, EL_FORMAT] legu 4
          5153
                                then
          5154
                                    begin
SOFT_ERROR (.index);
          5155
                                                                                  ! UPATE SOFT ERROR COUNT
.
          5156
                                     TEMP_UNIT = .L$LUN:
                                                                                  ! SAVE UNIT NUMBER AS KNOWN TO DRS
:
          5157
:
          5158
                                     incr OFFSET from (0 + OF_UN) to (3 * UNIT_SIZE + OF_UN) by UNIT_SIZE do
          5159
          5160
                                         if (.ICST_ADDR [.OFFSET, D_DISK_NUM] eql .ELOG_PKT [.index, EL_DK_NUM]) and
          5161
                                            (.ICST_ADDR [.OFFSET, D_PRES] eq1 PRESENT)
          5162
                                         then
          5163
                                             begin
          5164
                                             L$LUN = .ICST_ADDR [.OFFSET, D_UNIT];
                                                                                          ! CORECT UNIT NUMBER FOR ERROR MESSAGE
          5165
                                             exitloop;
          5166
                                             end:
          5167
          5168
                                    case .ELOG_PKT [.index, EL_FORMAT] from 0 to 4 of
          5169
.
          5170
          5171
                                         :[0]
                                                 ERRSOFT (60, 0, 0);
                                                                                 ! CONTROLLER ERROR
          5172
          5173
                                         [1]:
                                                 ERRSOFT (61, 0, 0);
                                                                                 ! HOST MEMORY ACCESS ERROR
          5174
          5175
                                         [2]:
                                                 ERRSOFT (62. 0. 0):
                                                                                 ! DISK TRANSFER ERROR
          5176
          5177
                                         [3]:
                                                 ERRSOFT (63. 0. 0):
                                                                                 ! SDI ERROR
          5178
          5179
                                         [4]:
                                                 ERRSOFT (64, 0, 0);
                                                                                 ! SMALL DISK ERROR
          5180
                                         tes:
          5181
          5182
:
                                     L$LUN = .TEMP_UNIT;
                                                                                  ! RESTORE UNIT NUMBER
          5183
                                     SFT_ERR_PRINTED . TRUE;
                                                                                  ! SOFT ERROR PRINTOUT OCCURED
          5184
                                     end
          5185
          5186
                                else
          5187
                                    PRINTF (DBM109, .ELOG_PKT [.index, EL_FORMAT]); ! UNKNOWN ERROR-LOG FORMAT
          5188
          5189
                            if not (.SFT_ERR_PRINTED)
          5190
                            then
:
          5191
                                PRINTB (CRLF):
:
                                                                                  ! EXTRA CARRIAGE-RETURN/LINE-FEED
          5192
;
          5193
                            EMS_EL (.index);
                                                                                  ! PRINT ERROR-LOG CONTENTS
          5194
                            end:
          5195
```

ZRQAM3 VO1.2	5196 5197 5198 5199			SERVICE ROUTINES		14-Dec-1983 16:	:12:07	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.	SEQ 0421 Page 166
	5197 5198		D THREY			14-DEC-1983 18:	:12:00	DISKTOSENE. [DIETE, NORA JENGACO.	BL2;161 (52)
	5198	then		geq 0			! IF	ASSOC CMD PKT WAS FOUND	
		crieri	DUT DET	(.P_INDEX);			. DE1	TURN COMMAND DACKET TO DOOL	
			PUI_PKI	(.P_INDEX);			: ME	TURN COMMAND PACKET TO POOL	
	5200	end;					! ROU	UTINE DISK_RSP	
					.SBTTL		SERVICE	E ROUTINES	
000000 0 000004 1	004137 105046	00000G		SEQUEN:	CLRB	R1, \$SAVE5 -(SP)		: SFT.ERR.PRINTED	5037
	013701	000000G			MOV	IPKT.ADDR,R1		; SFI.ERR.FRINIED	5052 5064
000012 0	200500				CLR	R2		COUNT	5062
000014 0	010246			1\$:	MOV	R2,-(SP)		: COUNT	5064
000016 0	012746	000104			MOV	#104,-(SP)			
000022 0	004737	000000G			JSR	PC.BL\$MUL (SP)+ (SP)+			
000030 0	022626 026061	0000130	000013		CMP	(SP)+, (SP)+			
	001031	000012G	000012		CMP BNE	MSCP.PKT+12(R0),12(R1)			
000040 0	026061	000014G	000014		CMP	MSCP.PKT+14(RO),14(R1)			5065
000046	001025				BNE	21			3003
000050	026011	000000G			CMP	MSCP.PKT(RO),(R1)			5066
000046 0 000050 0 000054 0 000056 1 000062 1	001422				BEQ	2\$			
000056 1	105760	000022G			TSTB	MSCP.PKT+22(RO)			5067
000062 1	100417	000760	0000100		BMI	24			
0000072	132760 001013	000360	0000106		BITB	#360,MSCP.PKT+10(R0)			5068
000064 1 000072 0 000074 1	105761	000022			TSTB	2\$ 22(R1)			5060
000100 1	100010	OUGUEE			BPL	21			5069
000102 1	116200	000000G			MOVB	PKT.USE(R2),R0		; *(COUNT),*	5070
000106 0	020037	0000761			CMP	RO, ICTLR			30.0
	001003				BNE	2\$			
000114 0	010237	000000G			MOV	R2.P.INDEX		; COUNT, *	5073
000120 0 000122 0	000406 005202 020227				BR	34		1 00.00	5072
000124 0	005202	000013		2\$:	INC	R2 R2,013		: COUNT	5062
000130	003731	000013			BLE	18		: COUNT.*	
000132 0	005737	000000G			TST	P. INDEX			5077
000136 0	002014			34:	BGE	41			30
000140 0	016146	000012			MOV	12(R1),-(SP)			5080
000144 0	012746	000000G			MOV	#DBM108,-(SP)			
000150 0	012746	000002			MOV	42(SP)			
000154 0 000156 1	010600				MOV	SP.RO		: SP.*	
000160	104417 062706	000006			TRAP	17 96.SP			5077
000164 0	000137	025040			ADD	304			5077 5079
000170	013746	000076		48:	MOV	ICTLR,-(SP)			5084
000174 0	004737	00000G			JSR	PC.GET.RETPKT			3004
000200 0	010005				MOV	RO,R5		; *,R.INDEX	
000202 0	005726				TST	(SP)+			
000204 0	005705				TST	R5		; R.INDEX	
000206	002526	0000000			BLT	91			
	013704 062704	00000G 000006			ADD	IPKT.ADDR,R4		: *.SRC.ADDR : *.SRC.ADDR	5089

	ZRQAM3 VO1.2		RD/RX EX	KERCISER TERRUPT SERVICE	ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2:16	Page 167 51 (52)
	000220	010546				MOV	R5,-(SP)	: R.INDEX.*	5090
	000222		000060			MOV	#60,-(SP)	, K. INDEX, -	3090
	000226	004737	00000G			JSR	PC.BL\$MUL		
	000232	062700	00000G			ADD	ARETPKT RO		
	000236	010003	000000			MOV	PO P3	: *,DST.ADDR	
	000240	010002				MOV	PO P2	* *.R.ADDR	
	000242	013701	000000G			MOV	PC,BL\$MUL #RETPKT,RO RO,R3 RO,R2 IPKT.ADDR,R1 #1,RO (R4)+,(R3)+ 22(R1),#211 6\$	; +,n.noon	5098
	000242	012700	0000001			MOV	A1 DO	- COLINT	
	000246 000252 000254	012428	000001		5\$:	MOV	(DA), (DZ),	: *,COUNT	5092
	000252	012423	000022	000311	34:	CMPB	22(01) 4211	; SRC.ADDR,DST.ADDR	5094
	000234	126127	000022	000211			SE(MI), WEII		5098
1	000262 000264	001005	000013			BNE			E101
1	000204	020027	000012			CMP	RO.#12	; COUNT, #	5101
1	000270	001002	000004			BNE	6\$ #4.R4 R0 R0.#30	. CDC 4000	5407
1	000272	062704	000004			ADD	#4.R4	: *,SRC.ADDR	5103
	000276	005200	000070		6\$:	INC	R0	; COUNT	5092
1	000300	020027 003762	000030			CMP	RO.#30	: COUNT, #	
1	000304	003/62	0000761			BLE	3+		
-	000306	013700	000076			MOV	ICTLR, RO		5107
1	000312	042700	177760	000000		BIC	#177760,R0	(0 4000)	1
1	000316	142762		000002		BICB	#17,2(R2)	; *,*(R.ADDR)	
1	000324 000330 000334	150062	000002			BISB	R0,2(R2)	; *,*(R.ADDR)	
	000330	013704	000000G			MOV	P.INDEX,R4		5109
	000334	002447				BLT	0.0		
-	000336	005000				CLR	RO		5112
1	000340	156100	000022			BISB	22(R1),R0		
-	000344	020027	000241			CMP	RO. #241		
1	000350	001406				BEQ	7\$		
1	000352	020027	000242			CMP	RO.#242		5113
1	000356	001403				BEQ	76		
1	000360	020027	000550			CMP	RO.#220		5114
	000364	001033				BNE	8#		
	000366	010416			7\$:	MOV	R4,(SP)		5117
	000370	012746	000104			MOV	#104,-(SP)		
1	000374	004737	000000G			JSR	PC.BL*MUL MSCP.PKT+24(R0),12(R2) MSCP.PKT+26(R0),44(R2)		
	000400	016062	000024G	000012		MOV	MSCP.PKT+24(R0),12(R2)	: *.*(R.ADDR)	
-	000406	016062	000026G	000044		MOV	MSCP.PKT+26(RO),44(R2)	; *,*(R.ADDR)	5118
95	000414	016062		000046		MOV	MSCP.PKI+30(RU),46(R2)	; *,*(R.ADDR)	5119
1	000422	016062	000046G	000050		MOV	MSCP.PKT+46(RO),50(R2)	; *,*(R.ADDR)	5120
4	000430	016062	000050G	000052		MOV	MSCP.PKT+50(R0),52(R2)	; *,*(R.ADDR)	5121
1	000436	016062	000032G	000024		MOV	MSCP.PKT+32(R0),24(R2)	; *,*(R.ADDR)	5122
1	000444	016062	000034G	000026		MOV	MSCP.PKT+34(RO),26(R2)	; *,*(R.ADDR)	5123
1	000452	005726				TST	(SP)+	1	5116
1	000454	010516			84:	MOV	R5.(SP)	; R.INDEX,*	5127
-	000456	004737	000000G			JSR	PC, IN. IODQ		
-	000462	022626				CMP	(SP)+,(SP)+		5088
	000464	013746	0000761		94:	MOV	ICTLR, -(SP)	1	5133
1	000470	012746	000006			MOV	46(SP)		
	000474	004737	000000G			JSR	PC.BL#MUL		1
	000500	013702	000000G			MOV	IPKT.ADDR,R2		5130
	000504	012703	000024			MOV	#24,R3		
	000510	060203				ADD	R2,R3		
	000512	132713	000037			BITB	#37,(R3)		
	000516	001003				BNE	10#		

ZRQAN VO1.2		RD/RX E	XERCISER TERRUPT SERV	ICE ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2;	Page 168 161 (52)
00052 00052	0 032713 4 001404	177740			BIT	#177740,(R3) 11\$		5131
00052 00053	6 012760	000001	000110	100:	MOV BR	#1.LAST.PKT(RO)	!	5133
00053	6 005060	000110		115:	CLR	12\$ LAST.PKT(RO) 12(R2),LAST.PKT+2(RO)		5130 5135
00054	2 016260	000012	000112'	12\$:	MOV	12(R2),LAST,PKT+2(R0)		5137
00055	0 016260	000014	000114'		MOV	14(R2),LAST.PKT+4(R0)		5138
00055	6 005003				CLR	R3	; INDEX	5140
00056	0 010316			13\$:	MOV	R3.(SP)	; INDEX,*	5142
00056 00056 00056	2 012746	000102 000000G			MOV	#102,-(SP)		
00057	2 010005	0000000			JSR	PC.BL\$MUL RO.R5		
00057	4 005726				MOV	(SP)+		
00057	6 005000				CLR	RO		
00060		000000G			BISB	ELOG.PKT(R5),R0		
00060	4 020037	000076			CMP	RO, ICTLR		
00061	0 001170				BNE	27\$		
00061	2 013700	000000G			MOV	IPKT.ADDR.RO		5143
00063		0000066	000012		CMP	ELOG.PKT+6(R5),12(R0)		
00062	4 001162 6 026560	000010G	000014		BNE	27\$ ELOG.PKT+10(R5),14(R0)		****
00063	4 001156	0000100	000014		BNE	27\$		5144
00063	6 126527	000001G	000001		CMPB	ELOG.PKT+1(R5),#1		5145
00063 00064	4 001152				BNE	278		3243
00064	6 013716	000076			MOV	ICTLR,(SP) 46,-(SP)		5149
00065	2 012746	000006			MOV	46,-(SP)		
00065	6 004737	000000G			JSR	PC.BL \$MUL		
00066	2 005726 4 005760	000110			TST	(SP)+ LAST.PKT(RO)		
0006	0 001122	000110			BNE	25#		
00067	2 126527	0000160	000004		CMPB	ELOG.PKT+16(R5),#4		5152
00070	0 101104				BHI	24\$		
00070	2 010316 4 004737				MOV	R3.(SP) PC.SOFT.ERROR	; INDEX,*	5155
00070	004757	000000V			JSR	PC, SOFT. ERROR		
0007		0000006			MOV	L\$LUN,R2 #6,R0	: *,TEMP.UNIT	5156
0007	0 010004	000000		141:	MOV	RO, R4	: *,OFFSET : OFFSET.*	5158 5160
0007	2 063704	0000000		• • • • • • • • • • • • • • • • • • • •	ADD	ICST.ADDR.R4	, 017321,4	3100
00072	6 016546	0000120			MOV	ELOG.PKT+12(R5),-(SP)		
00073					MOVB	(R4),R1		
00073	4 042701	177774			BIC	0177774.R1		
00074	001012				CMP	R1.(SP)+		
00074	4 032714	040000			BNE	15# #40000,(R4)		E161
00075		040000			BEQ	154		5161
00075	2 011401				MOV	(R4),R1	•	5164
00075	4 000301				SWAB	R1		
00075		177760			BIC	#177760,R1		
00076		0000000			MOV	R1.L\$LUN		
00076		000016		154	BR	16\$	. 055057	5163
0007		000016		156:	ADD	#16,R0 R0,#60	: *,OFFSET : OFFSET.*	5158
00100		000000			BLE	14\$	; UFF 3E1, #	

ZRQAM3 VO1.2		RD/RX EXERCISER RDRX INTERRUPT SERVI	CE ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555	Page 169 161 (52)
001002 001004	005000 156500	000016G	16\$:	CLR BISB	RO ELOG.PKT+16(R5),RO	•	5168
001010	006300	0000001		ASL	RO SAACES SE		
001012	066007	000000'		ADD	P.AAA(RO),PC	: Case dispatch	
001016	104457		18\$:	TRAP	57		5171
001020	000074			. WORD	74		
001022	000000			. WORD	0		
001024	000000			. WORD	0		
001026	000423			BR	23\$		5168
001030	104457		19\$:	TRAP	57		5173
001032	000075			. WORD	75		
001034	000000			. WORD	0		
001036	000000		*	. WORD	0		
001040	000416			BR	23\$		5168
001042	104457		20\$:	TRAP	57		5175
001044	000076			. WORD	76		
001046	000000			. WORD	0		
001050	000000			. WORD	0		
001052	000411			BR	231		5168
001054	104457		21\$:	TRAP	57		5177
001056	000077			. WORD	77		32
001060	000000			. WORD	o		
001062	000000			. WORD	ŏ		
001064	000404			BR	23\$		5160
001066	104457		224:	TRAP	57		5168
001070	000100		254:	. WORD	100		5179
001072	000000			. WORD			
001074	000000			. WORD	0		
001076	010237	00000G	224.			TEMP INITE	5400
001102	112766	000001 000004	23#:	MOVE	R2,L\$LUN	: TEMP.UNIT.*	5182
001110	000412	000001 000004		MOVB	01,4(SP)	: *.SFT.ERR.PRINTED	5183
001112	005016		244	BR	25#		5152
001114		0000160	244:	CLR	(SP)		5187
001120	116516	000016G		MOVB	ELOG.PKT+16(R5),(SP)		
	012746	000000G		MOV	#DBM109,-(SP)		
001124	012746	000002		MOV	#2,-(SP)		
001130	010600			MOV	SP.RO	; SP.*	
001132	104417			TRAP	17		
001134	022626			CMP	(SP)+.(SP)+		i
001136	032766	000001 000004	25#:	BIT	#1,4(SP)	; *,SFT.ERR.PRINTED	5189
001144	001007	******		BNE	26#		
001146 001152	012716	00000G		MOV	#CRLF.(SP)		5191
001152	012746	000001		MOV	#1,-(SP)		
001156	010600			MOV	SP,RO	; SP.4	
001160	104414			TRAP	14		
001162	005726			TST	(SP)+		
001164	010316		26\$:	MOV	R3,(SP)	; INDEX.*	5193
001166	004737	00000G		JSR	PC.EMS.EL		
001172 001174	005203		278:	INC	R3	; INDEX	5140
001174	020327	000013		CMP	R3,#13	; INDEX.*	
001200	003002			BGT	28\$		
001202	000137	024374'		JMP	134		
001206	013700	00000G	28\$:	MOV	P.INDEX.RO		5196
001212	002403			BLT	29\$		22.70

ZRQAM3 VO1.2	1	RD/RX EXERCISER RDRX INTERRUPT SERVICE	ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2;	Page 170 161 (52)
001214 001216 001224 001224	004737 022626 005726	000000G	29\$: 30\$:	MOV JSR CMP TST RTS	RO,(SP) PC.PUT.PKT (SP)+,(SP)+ (SP)+	:	5198 5052 5037
	mum stack	332 words. Routine depth per invocation:	Base: 13 words	*CODE * . PSECT	23614 \$PLIT\$, RO , D		
000000 000000 000000 000000	000012 000024 000036		P.AAA: 17\$:	. WORD . WORD . WORD . WORD . WORD	0 12 24 36 50	: CASE Table for SEQUEN+1012 : [18\$] : [19\$] : [20\$] : [21\$] : [22\$]	5168

```
14-Dec-1983 16:12:07
                                                                                                  VAX-11 Bliss-16 V3-555
                 RD/RX EXERCISER
                                                                                                  VAX-11 Bliss-16 V3-555 Page 171
DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (53)
ZRQAM3
                 RDRX INTERRUPT SERVICE ROUTINES
                                                                       14-Dec-1983 16:12:00
V01.2
           5201 routine DATAGM : novalue =
           5202
           5203 !+
           5204
                           THIS ROUTINE HANDLES ALL DATAGRAM (ERROR LOG) MESSAGES RECEIVED FROM
           5205
                          THE RDRX
           5206
5207
                          IMPLICIT INPUTS:
           5208
                                   IPKT_ADDR - ADDRESS OF MSCP PACKET CONTAINING ERROR LOG
           5209
                                                     MESSAGE
                                   ICST_ADDR - ADDRESS OF THE INTERRUPTING CONTROLLER'S CST
           5210 !
           5211 !-
           5212
           5213
                      begin
           5214
           5215
           5216
                           index : signed word initial (-1),
           5217
                           SAVE_ADDR : ref block [EP_LEN, word] field (EP_FIELDS),
           5218
                           SRC_ADDR.
           5219
                          DST_ADDR.
           5220
                           TEMP UNIT
                           SFT_ERR_PRINTED : byte initial (byte (FALSE));
           5221
           5222
           5223
           5224 ! FIND AN EMPTY SLOT IN THE ERROR-LOG PACKET SAVE AREA
           5225 !
           5226
           5227
                     incr COUNT from 0 to EP_CNT - 1 do
           5228
           5229
                           if .ELOG_PKT [.COUNT, EL_CONTENTS] eq1 EMPTY ! IF EMPTY SLOT FOUND
           5230
                           then
           5231
                               begin
           5232
                               index = .COUNT;
                                                                                ! SAVE INDEX INTO THE SAVE AREA
           5233
                               exitloop;
           5234
                               end:
           5235
           5236
           5237
                    IF AN EMPTY SLOT FOUND, SAVE THE PACKET CONTENTS
           5238
           5239
           5240
                      if .index geq 0
           5241
                      then
           5242
                           begin
                           SAVE_ADDR = ELOG_PKT + (.index + EP_LEN + 2);
                                                                                ! ADDRESS OF THE SAVE AREA
           5243
                           SAVE_ADDR (EL_CONTENTS ) = FULL;
SAVE_ADDR (EL_CNTR) = .ICTLR;
           5244
                                                                                 ! MARK IT FULL
           5245
                                                                                 ! OWNERSHIP
                           SRC_ADDR = .IPKT_ADDR + 6;
DST_ADDR = .SAVE_ADDR + 2;
           5246
                                                                                  SETUP COPY ADDRESSES
           5247
           5248
           5249
                           incr COUNT from 1 to ((.IPKT_ADDR [MSGLEN] + 1) / 2) + 2 do
                               begin

.DST_ADDR = ..SRC_ADDR;

SRC_ADDR = .SRC_ADDR + 2;

DST_ADDR = .DST_ADDR + 2;
           5250
           5251
                                                                                ! COPY A WORD
                                                                                 ! UPDATE ADDRESS POINTERS
```

```
VAX-11 Bliss-16 V3-555
                  RD/RX EXERCISER
                                                                        14-Dec-1983 16:12:07
ZRQAM3
                                                                                                   VAX-11 Bliss-16 V3-555 Page 172 DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2:161 (53)
                  RDRX INTERRUPT SERVICE ROUTINES
                                                                        14-Dec-1983 16:12:00
V01.2
           5254
                               end:
           5255
5256
                           end
           5257
                      else
           5258
                           begin
           5259
                           PRINTF (DBM110);
                                                                              ! IF EMPTY SLOT NOT FOUND, PRINT MESSAGE
           5260
                           return:
           5261
                           end:
           5262
           5263
                 ! CHECK IF THE CORRESPONDING RESPONSE HAS ALREADY BEEN RECEIVED
           5264
           5265 !
           5266
                       if (.SAVE_ADDR [EL_CRN_LO] eql .LAST_PKT [.ICTLR, LAST_CRN_LO]) and (.SAVE_ADDR [EL_CRN_HI] eql .LAST_PKT [.ICTLR, LAST_CRN_HI])
           5267
           5268
           5269
                       then
           5270
5271
                           begin
           5272
                           if .LAST_PKT [.ICTLR, LAST_HRD_ERR] eq1 HRD_NOT_OCCURED ! IF SOFT ERROR HAD OCCURED
           5273
                           then
           5274
           5275
                                if .SAVE_ADDR [EL_FORMAT] legu 4
           5276
                                then
                                    begin
SOFT_ERROR (.index);
           5277
           5278
                                                                                 ! UPDATE SOFT ERROR COUNT
           5279
                                    TEMP_UNIT = .L$LUN;
                                                                                 ! SAVE UNIT NUMBER AS KNOWN TO DRS
           5280
           5281
                                    incr OFFSET from (0 + OF_UN) to (3 * UNIT_SIZE + OF_UN) by UNIT_SIZE do
           5282
                                         if (.ICST_ADDR [.OFFSET, D_DISK_NUM] eql .SAVE_ADDR [EL_DK_NUM]) and
  (.ICST_ADDR [.OFFSET, D_PRES] eql PRESENT)
           5283
5284
           5285
                                         then
           5286
           5287
                                             L$LUN = .ICST_ADDR (.OFFSET, D_UNIT); ! CORRECT UNIT NUMBER FOR ERROR MESSAGE
                                             exitloop:
           5288
           5289
                                             end:
           5290
           5291
                                    case .SAVE_ADDR [EL_FORMAT] from 0 to 4 of
           5292
                                         set
           5293
                                         [0]:
           5294
                                                      ERRSOFT (60, 0, 0);
                                                                                          ! CONTROLLER ERROR
           5295
           5296
                                         [1]:
                                                                                          ! HOST MEMORY ACCESS ERROR
                                                      ERRSOFT (61, 0, 0);
           5297
           5298
                                         [2]:
                                                      ERRSOFT (62, 0, 0);
                                                                                          ! DISK TRANSFER ERROR
           5299
           5300
                                         [3] :
                                                      ERRSOFT (63, 0, 0);
                                                                                          ! SDI ERROR
           5301
           5302
                                         [4]:
                                                      ERRSOFT (64, 0, 0);
                                                                                          ! SMALL DISK ERROR
           5303
                                         tes;
           5304
                                    L$LUN = .TEMP_UNIT;
           5305
                                                                                          ! RESTORE UNIT NUMBER
                                    SFT_ERR_PRINTED = TRUE:
           5306
                                                                                           ! SOFT ERROR PRINTOUT OCCURED
```

					DC			
ZRQAM3 VO1.2		RD/RX EXER	RCISER RRUPT SERVICE ROUTINES		14 - Dec - 1983 14 - Dec - 1983	16:12:07 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.	SEQ 0428 Page 173 .BL2;161 (53)
:	5307		end					
:	5308 5309		-1					
:	5310		PRINTF (DBM109.	SAVE A	DDR [EL_FORMAT]);	! ERROR	LOG FORMAT UNKNOWN	
	5311							
:	5312		f not (.SFT_ERR_PRINTE	D)				
:	5313 5314	ti	PRINTB (CRLF);			. EVIDA	CARRIEGE-RETURN/LINE-FEED	
:	5315		PRINIB (CREF.)			: EXIMA	CARRIEGE - RETORN/LINE - FEED	
:	5316	E	MS_EL (.index);			! PRINT	PACKET CONTENTS	
:	5317		nd:			! CORRE	SPONDING RESPONSE RECEIVED	
	5318							
•	5319	end;						
				.SBTTL	DATAGM RDRX INTERRU	PT SERVICE R	ROUTINES	
025044				.PSECT	*CODE*, RO			
000000	004137		DATAGM:	JSR	R1. \$SAVES			5201
000004	012705	177777		MOV	0-1,R5		; *, INDEX	5213
000010	105046			CLRB	-(SP)		SFT.ERR.PRINTED	E227
000012	005001 010146		16:	MOV	R1,-(SP)		: COUNT	5227 5229
000016	012746	000102	•••	MOV	#102,-(SP)		, coom,	2007
000022	004737	000000G		JSR	PC.BL \$MUL			
000026	022626	*******		CMP	(SP)+,(SP)+			
000030	105760 001002	000001G		TSTB	ELOG.PKT+1(RO)			
000036	010105			MOV	R1.R5		; COUNT, INDEX	5232
000040	000405			BR	34			5231
000042	005201		2\$:	INC	R1		: COUNT	5227
000044	020127	000013		CMP	R1.013		: COUNT.4	
000052	005705			BLE	1\$ R5		: INDEX	5240
000054	002446		36:	BLT	61		1 11000	3240
000056	010546			MOV	R5,-(SP)		; INDEX	5243
000060	012746	000102		MOV	#102,-(SP)			
000064	004737	000000G		JSR ADD	PC.BL \$MUL #ELOG.PKT.RO			
000074	010004	000000		MOV	RO,R4		: .SAVE.ADDR	
000076	111764	000001		MOVB	(PC),1(R4)		: *,*(SAVE.ADDR)	5244
000102	113714	0000761		MOVB	ICTLR.(R4)		SAVE. ADDR	5245
000106	013700	000000G		MOV	IPKT.ADDR.RO		1	5246
000112	012702	000006		ADD	06,R2 R0,R2		: *,SRC.ADDR : *,SRC.ADDR	
000120	012703	000002		MOV	#2,R3		. A.DST.ADDR	5247
000124	060403			ADD	R4,R3		SAVE.ADDR.DST.ADDR	
000126	016016	000006		MOV	6(RO),(SP)		•	5249
000132	005216	000000		INC	(SP)			
000134	012746	00000G		MOV	#2,-(SP)			
000144	062700	000002		JSR ADD	PC.BL\$DIV			
000150	005001	30002		CLR	R1		: COUNT	

					CC		
ZRQAM3		RD/RX EXERCISER			14-Dec-1983 16:12:07	VAX-11 Bliss-16 V3-555	SEQ 0429 Page 174
V01.2		RDRX INTERRUPT SERVI	CE ROUTINE	S	14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO	.BL2;161 (53)
000152	000401			BR	54		
000154	012223		45:	MOV	(R2)+,(R3)+	; SRC.ADDR,DST.ADDR	5251
000156	005201		5\$:	INC	R1	; COUNT	5249
000160	020100			CMP	R1.R0	; COUNT, 4	
000162	003774			BLE	41		
000164	062706	000006		ADD	46.SP		5242
000170 000172	000416			BR	7\$		5240
000172	012746	00000G	6\$:	MOV	#DBM110,-(SP)		5259
000176	012746	000001		MOV	#1(SP)		
000505	010600			MOV	SP,RO	; SP.4	
000202 000204 000206	104417 022626			TRAP	17		
000206	055656			CMP	(SP)+,(SP)+		5240
000210	000560			BR	221		5258
000212	013746	0000761	78:	MOV	ICTLR, -(SP)		5267
000216	012746	000006		MOV	46(SP)		
000222	004737	000000G		JSR	PC.BL#MUL (SP)+.(SP)+ 6(R4),LAST.PKT+2(R0)		
000226	022626			CMP	(SP)+,(SP)+		
000230	026460	000006 000112'		CMP	6(R4),LAST.PKT+2(R0)	; *(SAVE.ADDR),*	
000216 000222 000226 000230 000236 000240	001145			BNE	551		
000240	026460	000010 000114'		CMP	10(R4),LAST.PKT+4(R0)	; *(SAVE.ADDR),*	5268
000246	001141			BNE	221		
090250	005760	000110'		TST	LAST.PKT(RO)	:	5272
000254	001120			BNE	20\$		
000256	005001			CLR	R1		5275
000240 000250 000254 000256 000260 000264	001120 005001 156401	000016		BISB	16(R4),R1	; *(SAVE.ADDR),*	
000264	020127	000004		CMP	R1.04		
000270	101101			BHI	18\$		
000272 000274 000300	010546			MOV	R5,-(SP)	; INDEX, 4	5278
000274	004737	000000V		JSR	PC.SOFT.ERROR L&LUN,R3		
000300	013703	00000G		MOV	L\$LUN,R3	; *,TEMP.UNIT	5279
000304	012700	000006		MOV	06,RO	: *.OFFSET	5281
000310	010002		84:	MOV	RO,R2	; OFFSET, *	5283
000312	063702	000000G		ADD	ICST.ADDR,R2		
000316	016446	000012		MOV	12(R4),-(SP)	; *(SAVE.ADDR),*	
000322	111246			MOVB	ICST.ADDR.R2 12(R4),-(SP) (R2),-(SP)		
000324	042716	177774		BIC	#1////4,(SP)		
000330	022626			CMP	(SP)+,(SP)+		
000332	001012			BNE	96		
000334	032712	040000		BIT	040000,(R2)		5284
000340	001407			BEQ	96		
000342 000344 000346 000352	011246 000316			MOV	(R2),-(SP)	1	5287
000344	000316			SWAB	(SP)		
000346	042716 012637	177760		BIC	#177760,(SP)		
000352	012657	000000G		MOV	(SP)+,L\$LUN		
000356	000405			BR	106		5286
000360	062700	000016	98:	ADD	#16.RO	: *.OFFSET	5281
000364 000370	020027	000060		CMP	RO,060	: OFFSET.4	
000370	003747			BLE	86		1
000372	006301	0000101	108:	ASL	R1	1	5291
000374	066107	0000121		ADD	P.AAB(R1),PC	: Case dispatch	
000400	104457		124:	TRAP	57		5294
000402	000074			. WORD	74		
000404	000000			. WORD	0		

ZRQAM3 V01.2	RD/RX EXERCISER RDRX INTERRUPT SERVICE	ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2:16	0430 Page 175 61 (53)
000406 000000 000410 000423 000412 104457 000414 000075 000416 000000 000420 000000		13\$:	. WORD BR TRAP . WORD . WORD	0 17\$ 57 75 0	:	5291 5296
000422 000416 000424 104457 000426 000076 000430 000000 000432 000000		141:	BR TRAP .WORD .WORD	17\$ 57 76 0	;	5291 5298
000434 000411 000436 104457 000440 000077 000442 000000 000444 000000		15#:	BR TRAP . WORD . WORD . WORD	17\$ 57 77 0	:	5291 5300
000446 000404 000450 104457 000452 000100 000454 000000 000456 000000		16\$:	BR TRAP . WORD . WORD . WORD	17\$ 57 100 0	:	5291 5302
000460 010337 000464 112766 000472 000410 000474 010146 000476 012746	000000G 000001 000002	17\$:	MOV MOVB BR MOV	R3.L\$LUN #1.2(SP) 198 R1(SP)	: TEMP.UNIT.+ : +.SFT.ERR.PRINTED	5305 5306 5275 5310
000502 012746 000506 010600 000510 104417 000512 022626	000000G 000002		MOV MOV MOV TRAP CMP	#DBM109(SP) #2(SP) SP.RO 17 (SP)+,(SP)+	: SP.*	3310
000514 005726 000516 032716 000522 001007 000524 012746	000001 000000G	19#: 20#:	TST BIT BNE MOV	(SP). #1.(SP) 21\$ #CRLF,-(SP)	. *.SFT.ERR.PRINTED	5275 5312
000530 012746 000534 010600 000536 104414 000540 022626	000001		MOV MOV TRAP CMP	#1,-(SP) SP,R0 14 (SP)+,(SP)+	; SP.*	5314
000542 010546 000544 004737 000550 005726	000000G	214:	MOV JSR TST	R5(SP) PC.EMS.EL (SP)+	: INDEX.*	5316 5270
000554 000207 ; Routine Size:	183 words, Routine	224: Base: 4	TST RTS CODE# +	(SP)+ PC 25044		5201
000012	depth per invocation:	12 words	.PSECT	#PLIT#, RO . D		
000012 000000 000014 000012		P.AAB: 114:	. WORD	0 12	: CASE Table for DATAGM+0374 : [124] : [134]	5291

ZRQAM3 VO1.2	RD/RX EXERCISER RDRX INTERRUPT SERVICE ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555
000016 000 000020 000 000022 000	36 . WORD	36		: [14\$] : [15\$] : [16\$]

```
SEQ 0432
                 RD/RX EXERCISER
ZRQAM3
                                                                                              VAX-11 Bliss-16 V3-555 Page 177 DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2:161 (54)
                                                                    14-Dec-1983 16:12:07
V01.2
                 RDRX INTERRUPT SERVICE ROUTINES
                                                                    14-Dec-1983 16:12:00
          5320 routine SOFT_ERROR (INDEX) : novalue =
          5321
          5322
          5323
                          THIS ROUTINE UPDATES THE SOFT ERROR COUNT IN THE TALLY TABLE FOR EACH
          5324
                         ERROR LOG MESSAGE RECEIVED
          5325
          5326
                         IMPLICIT IMPUTS:
          5327
                                  ICST_ADDR - ADDRESS OF THE INTERRUPTING CONTROLLER'S CST
          5328
                ! -
          5329
          5330
                     begin
          5331
          5332
                     local
          5333
                         FOUND: byte initial (byte (FALSE)),
:
                         SOFT_OCCURED : byte initial (byte (FALSE)).
          5334
.
                         UNIT: word,
ERROR_CODE: byte,
ERROR_SUB: word,
TALLY_ADDR: ref block [TALLY_LEN, word] field (T_FIELDS),
           5335
:
           5336
           5337
           5338
          5339
                         ELOG_ADDR : ref block [EP_LEN, word] field (EP_FIELDS);
          5340
          5341
                     ELOG_ADDR = ELOG_PKT + (.index + EP_LEN + 2);
                                                                                                                        ! ADDRESS OF ERROR L
OG PACKET
          5342
                     ERROR_CODE = .SLOG_ADDR [EL_CODE];
:
                                                                                                                        ! ERROR CODE
          5343
                     ERROR_SUB = .ELOG_ADDR [EL_SUBCODE];
                                                                                                                        ! ERROR SUBCODE
          5344
           5345
                     incr OFFSET from (0 + OF_UN) to (3 * UNIT_SIZE + OF_UN) by UNIT_SIZE do
          5346
          5347
                         if (.ICST_ADDR [.OFFSET, D_PRES] eql PRESENT) and
                                                                                                                        ! MAP DISK NUMBER TO
 UNIT NUMBER
          5348
                             (.ICST_ADDR [.OFFSET, D_DISK_NUM] eql .ELOG_ADDR [EL_DK_NUM])
          5349
                         then
          5350
                             begin
FOUND - TRUE;
          5351
          5352
                              UNIT = .ICST_ADDR [.OFFSET, D_UNIT];
                                                                                                                        ! UNIT NUMBER OF DIS
          5353
                              exitloop;
          5354
                              end:
          5355
          5356
                     if (.ELOG_ADDR [EL_SUCCESS]) or
:
          5357
                        (.ELOG_ADDR [EL_CONTINUE])
          5358
                :
                     then
           5359
                         SOFT_OCCURED = TRUE:
                                                                                                                        ! SOFT ERROR FLAG
          5360
          5361
                     if .FOUND
                                                                                                                        ! IF UNIT NUMBER FOU
ND
          5362
                     then
.
          5363
           5364
                         TALLY_ADDR = TALLY + (.UNIT + TALLY_LEN + 2);
                                                                                                                        ! ADDRESS OF TALLY T
ABLE
          5365
          5366
                         if .SOFT_OCCURED
                                                                                                                        ! FOR SOFT ERRORRS
          5367
                          then
          5368
                              selectoneu .ERROR_CODE of
          5369
                                  set
          5370
          5371
                                  [ST_MFE]:
                                                   TALLY_ADDR [ERR_SFT_SEK] = .TALLY_ADDR [ERR_SFT_SEK] + 1:
                                                                                                                       ! SOFT - MEDIA FORMA
          5372
```

```
SEQ 0433
                 RD/RX EXERCISER
                                                                                            VAX-11 Bliss-16 V3-555 Page 178
DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (54)
ZRQAM3
                                                                   14-Dec-1983 16:12:07
V01.2
                RDRX INTERRUPT SERVICE ROUTINES
                                                                   14-Dec-1983 16:12:00
          5373
                                 [ST_DAT]:
                                                  if .ERROR_SUB eq1 2
                                                                                                                      ! SOFT - DATA
          5374
          5375
                                                       TALLY_ADDR [ERR_SFT_SEK] = .TALLY_ADDR [ERR_SFT_DAT] + 1
          5376
                                                      TALLY_ADDR [ERR_SFT_DAT] = .TALLY_ADDR [ERR_SFT_DAT] + 1:
          5377
          5378
          5379
                                 [ST_HST]:
                                                  TALLY_ADDR [ERR_SFT_HST] = .TALLY_ADDR [ERR_SFT_HST] + 1:
                                                                                                                      ! SOFT - HOST ACCESS
          5380
                                                  C_ERR_TBL [.ICTLR, C_ERR_SFT] = .C_ERR_TBL [.ICTLR, C_ERR_SFT] + 1;
          5381
                                 [ST_CNT]:
          5382
                                                                                                                      ! SOFT - CONTROLLER
          5383
                                                  if .ERROR_SUB eql 3
          5384
                                 [ST DRV]:
                                                                                                                      ! SOFT - DRIVE
          5385
          5386
                                                      TALLY_ADDR [ERR_SFT_SEK] = .TALLY_ADDR [ERR_SFT_SEK] + 1
          5387
          5388
                                                      TALLY_ADDR [ERR_SFT_DRV] = .TALLY_ADDR [ERR_SFT_DRV] + 1;
          5389
                                  tes
          5390
                         else
          5391
                              if (.ELOG_ADDR [EL_CRN_LO] eq1 0) and
          5392
          5393
                                 (.ELOG_ADDR [EL_CRN_HI] eql 0)
          5394
          5395
                                  selectoneu .ERROR_CODE of
          5396
                                     set
          5397
          5398
                                                  TALLY_ADDR [ERR_MRD_SEK] = .TALLY_ADDR [ERR_MRD_SEK] + 1;
                                                                                                                      ! HARD - MEDIA FORMA
          5399
:
          5400
                                                                                                                      ! HARD - DATA
                                      [ST_DAT]:
                                                  if .ERROR_SUB eql 2
.
          5401
:
           5402
                                                      TALLY_ADDR (ERR_HRD_SEK) = .TALLY_ADDR (ERR_HRD_SEK) + 1
           5403
           5404
                                                       TALLY_ADDR (ERR_HRD_DAT) = .TALLY_ADDR (ERR_HRD_DAT) + 1;
           5405
           5406
                                      [ST_HST]:
                                                  TALLY_ADDR [ERR_HRD_HST] = .TALLY_ADDR [ERR_HRD_HST] + 1;
                                                                                                                      ! HARD - HOST ACCESS
           5407
           5408
                                      [ST_CNT]:
                                                  C_ERR_TBL (.ICTLR, C_ERR_MRD) = .C_ERR_TBL (.ICTLR, C_ERR_MRD) + 1;
           5409
                                                                                                                       ! HARD - CONTROLLER
          5410
5411
                                      [ST_DRV]:
                                                  if .ERROR_SUB eql 3
                                                                                                                      ! HARD - DRIVE
          5412
           5413
                                                       TALLY_ADDR [ERR_HRD_SEK] = .TALLY_ADDR [ERR_HRD_SEK] + 1
           5414
           5415
                                                       TALLY_ADDR [ERR_HRD_DRV] = .TALLY_ADDR [ERR_HRD_DRV] + 1;
          5416
5417
5418
5419
5420
                                      tes:
                         end
:
                     else
                                                                                                                       ! UNIT NOT FOUND
           5421
           5422
                         if .SOFT_OCCURED
           5423
           5424
                             C_ERR_TBL [.ICTLR, C_ERR_SFT] = .C_ERR_TBL [.ICTLR, C_ERR_SFT] + 1
           5425
                         else
```

Page 179						ZDOAMS
ZRQACO.BL2;161 (54)	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQAC	14-Dec-1983 16:12:	RVICE ROUTINES	RDRX INTE		ZRQAM3 VO1.2
	0] + 1;	D)C_ERR_TBL [.ICTLR. C_	TBL [.ICTLR, C_ERR_HE		5426	
					5427	:
	E SOFT_ERROR	•		end;	5428	
	E ROUTINES	SOFT.ERROR RDRX INTERRUPT \$CODE\$, RO	.PSECT			025622
			SOFT.ERROR:	00000G	004137	000000
5320	:	R1. \$SAVE5	JSR			
		-(SP),-(SP)	CMP		024646	000004
5330	: FOUND	R1	CLRB	000000	105001	000006
	: SOFT.OCCURED	2(SP)	CLRB	000002	105066	000010
5341	: INDEX.*	22(SP),-(SP)	MOV	000022	016646	000014
		#102,-(SP)	JSR	000000G	004737	000024
		PC.BL\$MUL #ELOG.PKT.RO	ADD	000000G	062700	000024
	: *,ELOG.ADDR	RO.R4	MOV	000000	010004	000034
5342	: *(ELOG.ADDR).*	20(R4).R0	MOVB	000020	116400	000036
3342	; *(ELUG. NUUN ), *	#177740.RO	BIC	177740	042700	000042
	: ERROR.CODE	R2	CLRB	111140	105002	000042
	. A EDDOD CODE		PTC		050002	000050
B 5343	. A(ELOG ADDD) EDDOD CUR	20(PA) P3		000020	016403	000052
5 5545	. EDDOD CIR			000020	006203	000056
	. EDDOD CIR				006203	000060
	FROM SUB	93			006203	000062
	. FRECH SUR	93			006203	000064
	FRROR SUR				006203	000066
	. A. FRROR SUB	#174000 . R3		174000	042703	000070
5345	. A. OFFSET	46.RO			012700	000074
5347	OFFSET.	RO.RS		***************************************	010005	000100
3011		ICST. ADDR. R5		00000G		
					001420	
5348	: *(ELOG.ADDR).*			000012	016446	000114
	,	(R5),-(SP)			111546	000120
		#177774.(SP)		177774		
		(SP)+,(SP)+	CMP			000126
			BNE		001011	000130
5351	; *,FOUND	01.R1	MOVB	000001	112701	000132
5352			MOV		011546	000136
		(SP)	SWAB		000316	000140
		#177760,(SP)	BIC	177760	042716	000142
	; *,UNIT		MOV	000004	012666	000146
5350		3#	BR		000405	000152
5345	: *.OFFSET	#16,R0	2\$: ADD	000016	062700	000154
	; OFFSET.4	RO.460	CMP	000060	020027	000160
		14	BLE		003745	000164
5359	; *,SOFT.OCCURED	#1.6(SP)	3#: MOVB	000001	112766	
5361	FOUND	R1	ROR			
		17\$	BCC		103154	000176
5364	: UNIT.*	4(SP),(SP)	MOV	000004	016616	
		#70,-(SP)	MOV	000070	012746	000204
	: OFFSET.*  : *.SOFT.OCCURED  : FOUND	#177760.(SP) (SP)+,4(SP) 3\$ #16,R0 R0,#60 1\$ #1.6(SP) R1 17\$ 4(SP),(SP)	BIC MOV BR 2\$: ADD CMP BLE 3\$: MOVB ROR BCC MOV	000001 177760 000004 000016 000060 000001	111546 042716 022626 001011 112701 011546 000316 042716 012666 000405 062700 020027 003745 112766 006001 103154 016616	000122 000126 000130 000132 000136 000140 000142 000146 000152 000154 000160 000164 000174 000176 000200

700047		DD 484 EVEDSTOED					SEQ 0435
ZRQAM3 VO1.2		RDRX INTERRUPT SERVICE R	ROUTINES		14-Dec-1983 16:12:07	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL	Page 180
		NONA INTERNOT I SERVICE !	.0012.423		14 566 1703 10:12:00	DISKTOSCHE![DICTE!RDRA]ENGHCO.BC	2,101 (34)
000210	004737	00000G		JSR	PC,BL\$MUL		
000214	062700	00000G		ADD	#TALLY,RO		
000220	032766	000001 000010		BIT	#1,10(SP)	; *,SOFT.OCCURED	5366
000226	001455			BEQ	91		
000230	120227	000005		CMPB	R2.#5	; ERROR.CODE, *	5368
000230 000234 000236 000242 000244 000250 000252 000256 000260 000262 000270 000272	001444			BEQ	7\$	1	5371
000236	120227	000010		CMPB	R2.#10	; ERROR.CODE.*	5368
000242	001014	000004		BNE	45		
000244	012701	000064		MOV	#64,R1	TALLY 4000 .	5375
000250	060001 020327	000002		ADD	RO,R1	: TALLY.ADDR.* : ERROR.SUB.*	6777
000252	001065	000002		BNE	R3,#2 10\$	; ERRUR.508,*	5373
000250	005004			CLR	R4		5375
000260	156104	000001		BISB	1(R1),R4		3313
000266	005204	000001		INC	R4		
000270	110411			MOVB	R4,(R1)		
000272	110411 000514			BR	16\$		5373
000274	120227	000011	45:	CMPB	R2,#11	: ERROR.CODE.*	5368
000300	001003			BNE	54		3000
000302	105260	000067		INCB	67(RO)	; *(TALLY.ADDR)	5379
000306	000506			BR	16#		5368
000310	120227	000012	5#:	CMPB	R2,412	; ERROR.CODE.*	
000314	120227 001006 013701			BNE	6\$		
000316	013701	0000761		MOV	ICTLR,R1		5381
000322	006301			ASL	R1		
000300 000302 000306 000310 000314 000322 000324 000330 000336 000340 000344	105261	000001G		INCB	C.ERR.TBL+1(R1)		
000330	000475			BR	16\$	1	5368
000332	120227	000013	6\$:	CMPB	R2.013	: ERROR.CODE.*	
000336	001072 020327	000007		BNE	16#	50000 CID .	
000340	001003	000003		CMP	R3,#3	: ERROR.SUB.*	5384
000346	105260	000064	7\$:	INCB	8\$ 64(RO)	- A(TALLY ADDD)	5704
000352	000464	000004	70:	BR	16\$	: *(TALLY.ADDR)	5386
000354	105260	000066	84:	INCB	66(RO)	* *(TALLY.ADDR)	5384 5388
000360	000461	00000	٠٠.	BR	16\$	· · · · · · · · · · · · · · · · · · ·	5368
000362	005764	000006	91:	TST	6(R4)	* *(ELOG.ADDR)	5392
000366	001056			BNE	16#	, -(2200110011)	3072
000370	005764	000010		TST	10(R4)	; *(ELOG.ADDR)	5393
000374	001053			BNE	16#		
000376	120227	000005		CMPB	R2.45	; ERROR.CODE.*	5395
000402	001443			BEQ	14#		5398
000404	120227	000010		CMPB	R2.#10	; ERROR.CODE.*	5395
000410	001013			BNE	116		
000412	012701	000060		MOV	#60,R1	1	5402
000416	060001			ADD	RO,R1	: TALLY.ADDR.+	
000420	020327	000002		CMP	R3,42	; ERROR.SUB. *	5400
000424 000426	001002			BNE	10\$		F440
000426	105211			INCB	(R1)		5402
000432	000435 105261	000001	104-	BR	16#		5400
000436	000432	***************************************	10#:	INCB BR	1(R1) 16#		5404 5395
000440	120227	000011	114:	CMPB	R2.#11	: ERROR.CODE.*	3373
000444	001003	00011	***	BNE	124	, ENNON. CODE, -	
				5110			

ZRQAM3 V01.2		RD/RX EXERCISER RDRX INTERRUPT SERVICE	ROUTINES		14-Dec-1983 16:12:07 14-Dec-1983 16:12:00	VAX-11 Bliss-16 V3-555 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL	SEQ 0436 Page 181 L2;161 (54)
000446 000452 000454 000460	105260 000424 120227 001006	000063	12\$:	INCB BR CMPB BNE	63(RO) 16\$ R2.#12 13\$	: #(TALLY.ADDR) : ERROR.CODE,#	5406 5395
000462 000466 000470	013701 006301 105261	0000761 000000G		MOV ASL INCB	ICTLR,R1 R1 C.ERR.TBL(R1)		5408
000474	000413 120227 001010	000013	13#:	BR CMPB BNE	16\$ R2.#13 16\$	: ERROR.CODE.*	5395
000502 000504 000510	020327	000003		CMP BNE	R3, #3 15#	; ERROR.SUB.*	5411
000512	105260	000060	144:	INCB BR	60(RO) 16\$	; *(TALLY.ADDR)	5413 5411
000520 000524 000526 000530 000534 000536 000542 000550 000556	105260 005726 000415	000062	15#: 16#:	INCB TST BR	62(RO) (SP)+ 19\$	*(TALLY.ADDR)	5415 5363 5361
000530 000534	013700 006300	0000761 000000G	17\$:	MOV ASL	ICTLR,RO RO		5424
000542 000550	062700 032766 001403	000001 000006		ADD BIT BEQ	#C.ERR.TBL.RO #1.6(SP) 18\$	: *.SOFT.OCCURED	5422
OOC JOU	LUJEIU	000001	184:	INCB BR INCB	1(RO) 19\$ (RO)		5424 5422 5426
000562 000566	062706 000207	000010	19#:	ADD RTS	#10.SP PC		5320
: Rout : Maxin	ine Size: num stack	188 words. Routine depth per invocation:	Base: 12 words	*CODE*	25622		
	5429 5430 5431	end					
	5432	eludom					

OTS external references
.GLOBL #SAVE5, #SAVE4, #SAVE3, #SAVE2
.GLOBL BL#SHF, BL#DIV, BL#MOD, BL#MUL

## PSECT SUMMARY

	Psect Name	Words	Attrib	bu	tes			
:	#GGG#	315	RO .		I	LCL.	REL.	CON
	\$CODE\$	5765	RO .		Ī	LCL.	REL.	CON
:	\$PLIT\$	10	RO .		D	LCL. LCL.	REL.	CON

KS

ZRQAM3 V01.2

. :

:

:

:

:

RD/RX EXERCISER

RDRX INTERRUPT SERVICE ROUTINES

14-Dec-1983 16:12:07 14-Dec-1983 16:12:00

VAX-11 Bliss-16 V3-555 Page 182 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (54)

SEQ 0437

LIBRARY STATISTICS

----- Symbols -----Blocks File Loaded Percent Total Read DISK\$USER2:[DIETZ.RDRX]ZRQACO.L16:14 400 309 77 113

COMMAND QUALIFIERS

BLISS /PDP11 ZRQACO.BL2/LIST=ZRQACO.LI2/OBJECT=ZRQACO.OB2/SOURCE=PAGE:53

Page 183

```
ZRQAM4
                  RD/RX EXERCISER
                                                                       14-Dec-1983 16:12:07
                                                                                                   VAX-11 Bliss-16 V3-555
                  RDRX INTERRUPT SERVICE ROUTINES
                                                                       14-Dec-1983 16:12:00
                                                                                                   DISK $USER2: [DIETZ.RDRX]ZRQACO.BL2:161 (55)
           5433 module ZRQAM4 (
:
           5434
           5435 stitle 'RD/RX EXERCISER'
:
           5436
5437
5438
                                    ident = 'V01.2'.
.
                                    addressing_mode (absolute), environment (noeis)
:
:
           5439
                                    ) =
.
           5440
.
           5441
                 begin
:
           5442
:
           5443 #sbttl 'LASTAD AND SETUP'
.
           5444
.
           5445 library 'ZRQACO.L16';
.
           5446
:
           5447 require 'BLSMAC.REQ';
                                                                       ! DIAGNOSTIC SUPERVISOR LIBRARY
:
           6938
:
           6939 LASTAD
:
           6940
.
        6941 BGNSETUP (3)
6942
P 6943 BGNP1
P 6944
:
:
                           BGNPTAB
:
                                    INIT_IP_ADDR. INIT_INTR_VECT. INIT_BR_LEVEL. #0'000030'. O. RD_MAX_LBN
.
         P 6945
                                             ! IP, VECTOR, BR, DISK ADDR, START BLOCK, END BLOCK
.
           6946
                           ENDPTAB
.
           6947
.
         P 6948
                           BGNPTAB
;
         P 6949
                                    INIT_IP_ADDR, INIT_INTR_VECT, INIT_BR_LEVEL, #0'000001', 0, RX_MAX_LBN
.
           6950
                                             ! IP, VECTOR, BR, DISK ADDR, START BLOCK, END BLOCK
           6951
                           ENDPTAB
:
           6952
:
         P 6953
:
                           BGNPTAB
                                    INIT_IP_ADDR. INIT_INTR_VECT. INIT_BR_LEVEL. #0'000002'. O. RX_MAX_LBN ! IP. VECTOR. BR. DISK ADDR. START BLOCK. END BLOCK
           6954
:
           6955
           6956
                           ENDPTAB
:
           6957
:
           6958 ENDSETUP
                                                      .TITLE ZRQAM4 RD/RX EXERCISER
                                                      .IDENT /V01.2/
                                                      .ENABL
                                                               AMA
000000
                                                               $XYZ$.
                                                      .PSECT
                                                                        RO
000000
         000064
                                             BL $LAS: : . WORD
                                                               T$FREE
000002
         000000C
                                                      . WORD
                                                               <<T$FREE-<BL$LAS+4>>/2>
000004
         0000301
                                             P.AAA:
                                                      . WORD
                                                               L$LAST+24
000006
         000006
                                                       . WORD
                                                                                                   ; Plit count word
000010
         172150
                                             P. AAB:
                                                      . WORD
                                                               -5630
000012
         000154
                                                      . WORD
                                                               154
000014
         000004
                                                      . WORD
000016
         000030
                                                      . WORD
                                                               30
000020
         000000
                                                       . WORD
                                                               0
```

```
SEQ 0439
ZRQAM4
                  RD/RX EXERCISER
                                                                        14-Dec-1983 16:12:07
                                                                                                   VAX-11 Bliss-16 V3-555
                                                                                                                                            Page 184
V01.2
                  LASTAD AND SETUP
                                                                        14-Dec-1983 16:12:00
                                                                                                   DISK$USER2:[DIETZ.RDRX]ZRQACO.BL2;161 (55)
000022
         052137
                                                       . WORD
                                                               52137
000024 000050
000026 000006
000030 172150
         000050
                                             P. AAC:
                                                       . WORD
                                                               L$LAST+44
                                                       . WORD
                                                               6
                                                                                                    : Plit count word
                                             P.AAD:
                                                               -5630
                                                       . WORD
000032 000154
000034 000004
                                                               154
                                                       . WORD
                                                       . WORD
000036 000001
                                                       . WORD
000040 000000
                                                       . WORD
                                                               0
000042 001437
                                                       . WORD
                                                               1437
000044
         000000
                                             P. AAE:
                                                       . WORD
                                                               0
000046
         000006
                                                       . WORD
                                                               6
                                                                                                   : Plit count word
000050
                                             P.AAF:
         172150
                                                                -5630
                                                       . WORD
000052
000054
000056
         000154
                                                       . WORD
                                                               154
         000004
                                                       . WORD
         000002
                                                       . WORD
                                                               2
000060
000062
000064
         000000
                                                       . WORD
                                                               0
         001437
                                                       . WORD
                                                               1437
         000000
                                             T$FREE::.WORD
         000004
                                             L$LAST ==
                                                                    BL$LAS+4
         000003
                                             T$PTHV ==
         0000041
                                             $LAS4=
                                                                    P.AAA
         0000101
                                             $REM4=
                                                                    P. AAB
         000024
                                              $LAS3=
                                                                    P. AAC
         0000301
                                                                   P. AAD
                                             $REM3=
         000044
                                                                    P. AAE
                                             $$LAS1=
         0000501
                                                                    P. AAF
                                             $REM2=
                                                       .SBTTL $END.LINK LASTAD AND SETUP
000000 000207
                                             $END.LINK::
                                                      RTS
                                                                                                                                                 6937
                                                                                                    :
; Routine Size: 1 word,
                                    Routine Base: $XYZ$ + 0066
; Maximum stack depth per invocation: 0 words
           6959
.
                  end
           6960
.
:
           6961
                 eludom
                                             PSECT SUMMARY
.
         Psect Name
.
                                             Words
                                                        Attributes
:
          $XYZ$
                                                28
                                                          RO , I , LCL, REL, CON
```

LIBRARY STATISTICS

:

N2

ZRQAM4 RD/RX EXERCISER VOI.2 LASTAD AND SETUP 14-Dec-1983 16:12:07 14-Dec-1983 16:12:00

VAX-11 Bliss-16 V3-555 Page 185 DISK\$USER2:[DIETZ.RDRX]ZRQACO.BL2:161 (55)

File Symbols ----- Symbols ----- Blocks
Total Loaded Percent Read
DISK\$USER2:[DIETZ.RDRX]ZRQACO.L16:14 400 7 1 15

COMMAND QUALIFIERS

BLISS /PDP11 ZRQACO.BL2/LIST=ZRQACO.LI2/OBJECT=ZRQACO.OB2/SOURCE=PAGE:53

6962 6963

:

:

: Size: 5766 code + 352 data words : Run Time: 03:18.3

Run Time: 03:18.3 Elapsed Time: 06:22.2 Memory Used: 419 pages Compilation Complete