

.REM \_

IDENTIFICATION

PRODUCT CODE: AC-E851H-MC  
PRODUCT NAME: CXDRBH0 DR11-B MODULE  
PRODUCT DATE: SEPTEMBER 1978  
MAINTAINER: DEC/X11 SUPPORT GROUP

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITALS COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1973,1978 DIGITAL EQUIPMENT CORPORATION

1. ABSTRACT

DRB IS A IOMOD THAT EXERCISES ONE DR11-B. THE DEVICE IS EXERCISED USING THE MAINTENANCE MODE TO TRANSFER A 16 WORD BUFFER.

2. REQUIREMENTS

HARDWARE: ONE DR11-B INTERFACE A M968 MAINTENANCE MODULE  
STORAGE: DRB REQUIRES:  
1. DECIMAL WORDS: 205  
2. OCTAL WORDS: 0315  
3. OCTAL BYTES: 632

3. PASS DEFINITION

ONE PASS OF DRB CONSISTS OF TRANSFERRING ONE 16 WORD BLOCK OF DATA 77000(8) TIMES

4. EXECUTION TIME

ONE PASS OF DRB RUNNING ALONE ON A PDP11/05 PROCESSOR TAKES APPROXIMATELY TEN SECONDS.

5. CONFIGURATION REQUIREMENTS

DEFAULT PARAMETERS:  
DEVADR: 172410, VECTOR: 124, BR1: 5, DEVCNT: 1  
REQUIRED PARAMETERS:  
NONE

6. DEVICE/OPTION SET-UP

INSTALL THE M-968 MAINTENANCE MODULE

7. MODULE OPERATION

TEST SEQUENCE:

- A. SET UP VECTOR AND DEVICE REGISTERS
- B. TRANSFER 16 WORDS IN MAINT. MODE
- C. COMPARE DATA IN:OUT - REPORT ERRORS
- D. REPEAT 77000 TIMES
- E. SIGNAL END OF PASS, RESTART AT A.

DRBH DEC/X11 SYSTEM EXERCISER MODULE MACY11 30A(1052) 12-OCT-78 16:31 PAGE 4  
XDRBH0.P11 12-OCT-78 11:55

SFQ 0003

IF DEVICE FAILS TO INTERRUPT NO END OF PASS PRINTOUT WILL  
OCCUR.

8. OPERATION OPTIONS

NONE

9. NON STANDARD PRINTOUTS

NONE: ALL PRINTOUTS HAVE THE STANDARD FORMATS DESCRIBED IN THE  
DEC/X11 DOCUMENT.

```

000000* JDR11-B DEC/X11 EXERCISER MODULE
000000* <DRBH> 172410,124,566,77000,56
000000* MODULE 140000,DRBH,172410,124,266,77000,56
, TITLE DRBH DEC/X11 SYSTEM EXERCISER MODULE
, DDXCOM VERSION 6 23-NOV-78
*****.LIST BIN
000000* *****
000000* BEGIN: *****
000005* 051104 044102 040 MODNAM: .ASCII /DRBH / ;MODULE NAME.
000006* 000 .000 XFLAG: .BYTE OPEN ;USED TO KEEP TRACK OF WBUFF USAGE
000010* 172410 ADDR: 172410+0 ;1ST DEVICE ADDR.
000012* 000124 VECTOR: 124+0 ;1ST DEVICE VECTOR.
000013* 000 BR1: .BYTE PRTY5+0 ;1ST BR LEVEL.
000014* 000001 BR2: .BYTE PRTY+0 ;2ND BR LEVEL.
000016* 000000 DVID1: +1 ;DEVICE INDICATOR 1.
000017* 000000 SR1: OPEN ;SWITCH REGISTER 1
000018* 000000 SR2: OPEN ;SWITCH REGISTER 2
000019* 000000 SR3: OPEN ;SWITCH REGISTER 3
000020* 000000 SR4: OPEN ;SWITCH REGISTER 4
000021* 000000 *****
000026* 140000 STAT: 140000 ;STATUS WORD
000030* 000224 INIT: START ;MODULE START ADDR.
000032* 000224 SPOINT: MODSP ;MODULE STACK POINTER.
000034* 000000 PASCNT: 0 ;PASS COUNTER
000036* 077000 ICOUNT: 77000 ;# OF ITERATIONS PER PASS=77000
000040* 000000 LCCNT: 0 ;LCC TO COUNT ITERATIONS
000042* 000000 SOFCNT: 0 ;LCC TO SAVE TOTAL SOFT ERRORS
000044* 000000 HRDCNT: 0 ;LCC TO SAVE TOTAL HARD ERRORS
000046* 000000 SOFPAS: 0 ;LCC TO SAVE SOFT ERRORS PER PASS
000050* 000000 HRDPAS: 0 ;LCC TO SAVE HARD ERRORS PER PASS
000052* 000000 SYSCNT: 0 ;# OF SYS ERRORS ACCUMULATED
000054* 000000 RANUM: 0 ;HOLDS RANDOM # WHEN RAND MACRO IS CALLED
000056* 000000 COMPTG: 0 ;RESERVED FOR MONITOR USE
000060* 000000 RES1: 0 ;RESERVED FOR MONITOR USE
000062* 000000 SVR0: OPEN ;LCC TO SAVE R0.
000064* 000000 SVR1: OPEN ;LCC TO SAVE R1.
000066* 000000 SVR2: OPEN ;LCC TO SAVE R2.
000070* 000000 SVR3: OPEN ;LCC TO SAVE R3.
000072* 000000 SVR4: OPEN ;LCC TO SAVE R4.
000074* 000000 SVR5: OPEN ;LCC TO SAVE R5.
000076* 000000 SVR6: OPEN ;LCC TO SAVE R6.
001000* 000000 CSRA: OPEN ;ADDR OF CURRENT CSR.
00102* 000000 SBADR: OPEN ;ADDR OF GOOD DATA, OR
00104* 000000 WASADR: OPEN ;ADDR OF BAD DATA, OR
00106* 000000 ASTAT: OPEN ;STATUS REG CONTENTS.
00110* 000000 ERRYP: OPEN ;TYPE OF ERROR
00112* 000240 AWAS: OPEN ;EXPECTED DATA.
00114* 000000 RSTRT: RSTRT ;RESTART ADDRESS AFTER END OF PASS
00116* 000000 WDT0: OPEN ;WORDS TO MEMORY PER ITERATION
00118* 000000 WDF: OPEN ;WORDS FROM MEMORY PER ITERATION
00120* 000000 INTR: OPEN ;# OF INTERRUPTS PER ITERATION
00122* 000056 IDNUM: 56 ;MODULE IDENTIFICATION NUMBER=56
    
```

```

000040 .REPT SPSIZ ;MODULE STACK STARTS HERE.
.WLIST
.WORD 0
.LIST
.ENDR
000224* MODSP:
*****
;THIS MODULE TESTS THE DR-11B DIRECT MEMORY ACCESS INTERFACE
;MAINTENANCE MODULE M-968 TO BE USED WITH THIS TEST
;INITIALIZATION FOR (DMA) DR-11B
181
182
183
184
185
186
187 000224* 012767 00001 177666 START: MOV #1,INTR ;1 INTERRUPT PER ITERATION
188 000224* 012767 000016 177654 MOV #16,WDT0 ;16 WORDS TO MEM PER ITERATION
189
190
191 000240* 014407 000000* RESTRT: BREAKS,BEGIN ;TEMPORARY RETURN TO MONITOR...
192 000240* 014407 000000* MOV ADDR,R5 ;THEN CONTINUE AT NEXT INSTRUCTION.
193 000240* 016705 177532 MOV #20,(R5)+ ;GET DEVICE ADDRESS
194 000240* 012725 177760 MOV VECTOR,R0 ;SIXTEEN WORD TRANSFER
195 000240* 016700 177524 MOV DRIR,(R0)+ ;LOAD DEVICE VECTOR
196 000240* 012720 000240* MOV BRL,(R0)+ ;SET VECTOR TO SERVICE ROUTINE
197 000270* 116720 177516 MOV BDR6UP,VA ;SET PRIORITY
198 000274* 012767 000572* MOV #DR6UP,VA ;SETUP BUS ADDRESS
199 000307* 104415 000000* 000560* GETPAS,BEGIN,VA ;SET PHYSICAL ADDRESS FROM 16-BIT VA
200 000310* 016725 000246 CLR #4,(R5)+ ;SET UP REAL ADDR.
201 000314* 005025 CLR (R5)+ ;CLEAR THE CSR
202 000316* 012715 177777 MOV #1,(R5) ;SET UP DATA
203 000322* 056745 000236 BIS EA-(R5) ;SET EXTENDED MEM. BITS
204 000326* 005067 000234 CLR DONFLG ;CLEAR THE DEVICE COMPLETION FLAG
205 000332* 052715 010101 BIS #010101,(R5) ;SETUP MAINTENANCE MODE
206
207 000336* 012767 000010 000224 TIME: MOV #10,TMRCNT ;ENABLE INTERRUPT AND GO
208 000344* 005004 CLR R4 ;SET UP TIMING LOOP
209
210 000346* 014407 000000* TIMER: BREAKS,BEGIN ;TEMPORARY RETURN TO MONITOR...
211 000352* 014407 000000* MOV ADDR,R5 ;THEN CONTINUE AT NEXT INSTRUCTION.
212 000356* 005767 000204 TST DONFLG ;DID THE INTERRUPT OCCUR?
213 000362* 001012 BNE DONE ;IF YES CALL FOR END OF PASS
214 000364* 005304 DEC R4 ;IF NO, COUNT SOME TIME. HAVE WE TIMED OUT?
215 000366* 001367 BNE TIMER ;IF NO, GO BREAK AGAIN
216 000370* 005367 DEC TMRCNT ;DECREASE THE OVERALL COUNT
217 000374* 100364 RPL TIMER ;GO AGAIN IF MORE TIME
218 000376* 104403 000000* 000520* MSGNS,BEGIN,HUNG ;ASCII MESSAGE CALL WITH COMMON HEADER
219 000404* 104410 000000* ENDS,BEGIN ;
220
221 000410* 104413 000000* DONE: ENDS,BEGIN ;SIGNAL END OF ITERATION.
222 000414* 000167 177620 JMP RESTRT ;MONITOR SHALL TEST END OF PASS
223 ;CHECK DATA TRANSFER ;ELSE DO IT AGAIN
224
225
226 000420* DRIR:
227 000420* 000004 000000* 000426* ;IRQS,BEGIN,CHECK ; QUEUE UP TO CONTINUE AT CHECK AND RTI
228
229
    
```

230  
231 000426\* 012701 000572\*  
232 000432\* 012702 000010  
233 000436\* 021221  
234 000440\* 001003  
235 000442\* 005302  
236 000444\* 003374  
237 000450\* 002419  
238 000450\* 012769  
239 000456\* 010567 177416 177424  
240 000462\* 012767 177777 177416  
241 000470\* 014167 177416  
242 000474\* 010167 177404  
243  
244 000500\* 104404 000000\*  
245  
246  
247 000504\* 042715 000100  
248 000510\* 005267 000052  
249 000514\* 104400 000000\*  
250  
251  
252 000520\* 000524\*  
253 000524\* 177777  
254 000524\* 042504 044526 042503  
255 000532\* 043040 044501 042514  
256 000540\* 020104 047524 044440  
257 000544\* 052116 051110  
258 000554\* 000000  
259  
260  
261 000560\* 000000  
262 000562\* 000000  
263 000564\* 000000  
264 000566\* 000000  
265 000570\* 000000  
266 000572\* 000000  
267 000001 000001

CHECK: MOV #DRBUF,R1 ; GET THE BUFFER ADDRESS  
MOV #R1,R2 ; LOAD THE COUNTER  
1\$: CMP (R1)+,(R1)+ ; ARE THE TWO SEQUENTIAL WORDS EQUAL ?  
BNE ; NO, REPORT AN ERROR  
DEC R2 ; DONE THE WHOLE BUFFER ?  
BGT ; NO, KEEP CHECKING  
BR ; YES, CONTINUE  
GOOD: MOV #DRBUF,SBADR ; GOOD DATA ADDRESS  
RS,CSRA ; MOVE STATUS REG ADDRESS  
MOV #-1,ASB ; SHOULD BE  
MOV -(R1),AWAS ; WAS  
MOV R1,WASADR ; BAD DATA ADDRESS  
;\*\*\*\*\*  
DATERS,BEGIN ;DATA ERROR!!!  
;\*\*\*\*\*  
GOOD: BIC #100, (RS) ;CLEAR INTERRUPT ENABLE  
INC DONFLG ;SET THE COMPLETION FLAG  
EXITS,BEGIN ;EXIT TO MONITOR. MODULE WAIT FOR INTERRUPT.  
  
HUNG: FAIL  
177777  
FAIL: .ASCIZ "DEVICE FAILED TO INTERRUPT"  
  
.EVEN  
  
VA: OPEN ;MODULE REF. TAG  
PA: OPEN ;REAL ADDRESS  
EA: OPEN ;EX. MEM. ADDR.  
DONFLG: OPEN ;DEVICE COMPLETION FLAG  
TMRCHT: OPEN  
DRBUF: .BLKW 20  
.END

ACSR 000102R 163#  
ADDR 000006R 181#  
ADDR22= 181#  
ASB 000106R 167#  
ASTAT 000104R 165#  
AWAS 000108R 169#  
BEGIN 000000R 181#  
BIT0 = 000001 181#  
BIT1 = 000002 181#  
BIT10 = 002000 181#  
BIT11 = 004000 181#  
BIT12 = 010000 181#  
BIT13 = 020000 181#  
BIT14 = 040000 181#  
BIT15 = 080000 181#  
BIT2 = 000004 181#  
BIT3 = 000010 181#  
BIT4 = 000020 181#  
BIT5 = 000040 181#  
BIT6 = 000100 181#  
BIT7 = 000200 181#  
BIT8 = 000400 181#  
BIT9 = 001000 181#  
BREAK\$= 104407 181#  
BR1 000012R 133#  
BR2 000013R 133#  
BTODS = 104411 181#  
CDATA\$= 104412 181#  
CHECK 000426R 228#  
CONFIG 000056R 152#  
CSRA 000100R 161#  
DATCK\$= 104411 181#  
DATERS = 104404 181#  
DONE 000410R 213#  
DONFLG 000566R 204#  
DRBUF 000572R 198#  
DRIR 000420R 196#  
DVID1 000014R 133#  
EA 000564R 203#  
ENDITS= 104413 181#  
ENDS = 104410 181#  
ERRTYP 000106R 166#  
EXITS = 104400 181#  
FAIL = 000524R 254#  
GETPAS = 104415 181#  
GOOD 000504R 237#  
GWBUF\$= 104414 181#  
HRDCM\$= 000044R 146#  
HRDRS = 104405 181#  
HRDPAS 000050R 148#  
HUNG 000520R 219#  
ICONT 000036R 143#  
ICOUNT 000040R 144#  
IDNUM 000122R 173#  
INIT 000030R 140#  
INTR 000120R 172#

193  
240\*  
241\*  
191 192 199 210 211 218 219 221 228 244 248  
191 192 210 211  
197 192 210 211  
231#  
239\*  
244  
220#  
247\* 264#  
238 238 286#  
226#  
263#  
221  
219  
248  
254#  
199  
246#  
252#  
187\*

MAP225 = 104416	181#																			
MODNAM = 000000R	127#																			
MODSP = 000224R	181#	179#																		
MSGNS = 104401	181#	210#																		
MSGSS = 104402	181#																			
MSG5 = 104401	181#																			
NULL = 000000	181#																			
OPEN = 000000	163#	134	135	136	137	154	155	156	157	158	159	160	161							
	165	167	168	170	171	172	181#	261	262	263	264	265								
OTQAS = 104420	181#																			
PA = 000562R	209#																			
PASCNT = 000034R	143#	262#																		
PIRQS = 000004	181#																			
POPS1 = 005726	181#																			
POPS2 = 022626	181#																			
PRTY = 000000	132#	181#																		
PRTY0 = 000000	181#																			
PRTY1 = 000040	181#																			
PRTY2 = 000100	181#																			
PRTY3 = 000140	181#																			
PRTY4 = 000200	181#																			
PRTY5 = 000240	131#	181#																		
PRTY6 = 000300	181#																			
PRTY7 = 000340	181#																			
PS = 177776	181#																			
PSW = 177776	181#																			
PUSH = 005746	181#																			
PUSH2 = 024646	181#																			
RANDS = 104417	181#																			
RANNUM = 000054R	150#																			
RESTR1 = 000240R	169#	190#	223																	
RES1 = 000056R	153#																			
RES2 = 000060R	153#																			
RSTRT = 000112R	169#																			
SADDR = 000102R	162#	238*																		
SOPCNT = 000142R	147#																			
SOPFRS = 104406	181#																			
SOPPAS = 000046R	147#																			
SPOINT = 000032R	147#																			
SPSTZ = 000040	174																			
SR1 = 000016R	134#																			
SR2 = 000020R	134#																			
SR3 = 000024R	134#																			
SR4 = 000028R	134#																			
START = 000224R	140#	187#																		
STAT = 000026R	139#																			
SVR0 = 000062R	155#																			
SVR1 = 000064R	155#																			
SVR2 = 000066R	156#																			
SVR3 = 000070R	157#																			
SVR4 = 000072R	158#																			
SVR5 = 000074R	159#																			
SVR6 = 000076R	160#																			
SYS CNT = 000052R	149#																			
TIME = 000344R	208#																			
TIMER = 000346R	209#	215	217																	

TMHCNT = 000570R	207#	216*	265#																	
TRPDPD = 000022	181#		261#																	
VA = 000560R	198#																			
VECTOR = 000010R	130#	199																		
WASADR = 000104R	162#	242*																		
WDR = 000116R	171#																			
WDT0 = 000114R	170#	188*																		
XFLAG = 000005R	128#																			
.	259#	266#																		

ABS. 000000 000  
000632 001

ERRORS DETECTED: 0  
DEFAULT GLOBALS GENERATED: 0  
XDRBH0, XDRBH0/SOL/CRF:SYM=DDXCOM, XDRBH0  
RUN-TIME: 1 1 .2 SECONDS  
RUN-TIME RATIO: 9/2=3.3  
CORE USED: 7K (13 PAGES)