

MAINTAIN III

PIMTST

PAGE
thru 12¹

```

1 * THIS IS A COPYRIGHTED PROGRAM. COPYRIGHT 1970 BY VARIAN DATA MACHINES 02 00001
2 * V.D.M. PART NO. 92L0107-009E 02 00002
3 * 02 00003
4 * 02 00004
5 * 02 00005
6 * 02 00006
7 * 02 00007
8 * 02 00008
9 * 02 00009
10 * 02 00010
11 * 02 00011
12 * 02 00012
13 ***** 620F/620I PRIORITY INTERRUPT MODULE [PIM] TEST ***** 02 00013
14 * 02 00014
15 ***** 02 00015
16 * 02 00016
17 * RETURN TO EXECUTIVE 02 00017
18 * 02 00018
19 ***** 02 00019
20 * 02 00020
21 * 02 00021
22 * ORG 0 02 00022
23 * JMP EXECUTIVE 02 00023
24 * 02 00024
25 * 02 00025
26 ***** 02 00026
27 * 02 00027
28 * POWER FAIL / RESTART 02 00028
29 * 02 00029
30 ***** 02 00030
31 * 02 00031
32 * 02 00032
33 * 02 00033
34 * ORG 040 02 00034
35 * JMPM POWER DOWN ROUTINE 02 00035
36 * JMP POWER UP ROUTINE 02 00036
37 * 02 00037
38 * 02 00038
39 ***** 02 00039
40 * 02 00040
41 * NOTE: THE TEST EXECUTIVE RESERVES LOCATIONS 0400 TO 0500 02 00041
42 * FOR A POINTER TABLE TO STANDARD ROUTINES, AND AS AN AREA 02 00042
43 * FOR EXECUTIVE DATA. ALL TEST PROGRAMS WORKING WITH THE 02 00043
44 * EXECUTIVE MUST PRESERVE THIS BLOCK 02 00044
45 * 02 00045
46 * 02 00046
47 * 02 00047
48 * 02 00048
000400 49 * ORG 0400 02 00049
50 * 02 00050
51 * 02 00051
52 * 02 00052
53 * 02 00053
54 * 02 00054
55 * 02 00055
56 * 02 00056
57 * 02 00057
58 * 02 00058
59 * 02 00059
000400 60 OUTA BSS 1 OUTPUT ONE CHAR ROUTINE 02 00060
000401 61 OUTB BSS 1 OUTPUT TWO CHAR ROUTINE 02 00061
000402 62 OUTC BSS 1 OUTPUT CR/LF ROUTINE 02 00062
000403 63 OUTD BSS 1 OUTPUT MESSAGE ROUTINE 02 00063
000404 64 OUTE BSS 1 OUTPUT OCTAL WORD ROUTINE 02 00064
000405 65 OUTF BSS 1 OUTPUT OCTAL ADDR ROUTINE 02 00065
000406 66 OUTG BSS 1 OUTPUT ERROR MSG ROUTINE 02 00066
000407 67 OUTH BSS 1 OUTPUT CONTROL CHAR TO TTY ROUTINE 02 00067
000410 68 IMPA BSS 1 INPUT ONE CHAR ROUTINE 02 00068
000411 69 IMPB BSS 1 INPUT AND PRINT ONE CHAR ROUTINE 02 00069
000412 70 IMPC BSS 1 INPUT ONE CHAR EDITED ROUTINE 02 00070
000413 71 IMPD BSS 1 INPUT ONE ALPHA CHAR ROUTINE 02 00071
000414 72 INPE BSS 1 INPUT TWO ALPHA CHAR ROUTINE 02 00072
000415 73 INPF BSS 1 INPUT COMMA/PERIOD TERMINATION ROUTINE 02 00073
000416 74 INPG BSS 1 INPUT OCTAL NUMBER ROUTINE 02 00074
000417 75 TOUT BSS 1 TIME-OUT ROUTINE 02 00075
000420 76 TDLY BSS 1 TIME DELAY ROUTINE 02 00076
000421 77 SSWT HSS 1 STANDARD SENSE SWITCH ROUTINE 02 00077
000422 78 ELBC BSS 1 LOWEST CORE LOCATION USED BY EXEC 02 00078
79 *
80 *
81 * ORG 0440 02 00080
82 * 02 00081
83 * EXECUTIVE DATA TABLE 02 00082
84 * 02 00083
85 * 02 00084
000440 85 SFLG BSS 1 LOOP ON ERROR FLAG, 0=DON'T LOOP 1=LOOP 02 00085
000441 86 SMEM BSS 1 MEMORY SIZE (HIGHEST AVAIL CORE) 02 00086
000442 87 SCOM BSS 1 0=CONSOLE MODE 1=TTY MODE 02 00087
000443 88 RSS 22 02 00088
000471 89 TS04 BSS 1 DIGIT COUNTER FOR INPG 02 00089
90 *
91 ***** 02 00091
92 * 02 00092
93 ***** 02 00093
94 * 02 00094
95 * 02 00095

```

PAGE	2	MAINTAIN III	PIMTST	
		96 *		02 00096
		97 * 620F/620I PRIORITY INTERRUPT MODULE [PIM] TEST		02 00097
		98 *		02 00098
000504	A	99 IAOR EQU 0504	INDIRECT ADDRESS POINTER	C 02 00099
000520	A	100 LTOR EQU 0520	LITERAL POINTER	C 02 00100
000500		101 *		02 00101
000500	001000	A 102 ORG 0500		02 00102
000501	000600	A 103 JMP PIMT		02 00103
000502	001000	A 104 JMP PIMI		02 00104
000503	001021	A 105 *		02 00105
000600		106 ORG 0600		02 00106
000600	010442	A 107 * PIMT LDA \$CON	CONSOLE MODE?	02 00107
000601	001010	A 108 JAZ PIMI		02 00108
000602	001021	A 109 CALL* DUTD	PRINT 'PIM TEST'	02 00109
000603	030000	L 110 LDX =MS1		02 00110
000604	005001	A 111 TZA		02 00111
000605	051701	A 112 STA CC		02 00112
000606	002000	A 113 CALL* DUTD		02 00113
000607	100403	A 114 LDA TPIM		C 02 00114
000611	001010	A 115 JAZ *+4		C 02 00115
000612	000615	A 116 JMP PIMA		C 02 00116
000613	001000	A 117 TTY1 LDXI MS10		C 02 00117
000616	002102	A 118 CALL* DUTD		C 02 00118
000617	002000	A 119 CALL* INPG	GET TTY PIM	C 02 00119
000621	002000	A 120 JMP PIMT	TERMINATE	C 02 00120
000622	100416	A 121 JMP TTY1	ABORT	C 02 00121
000623	001000	A 122 JMP *+2	COMMA	C 02 00122
000630	000631	A 123 STA TPIM	PERIOD	C 02 00123
000631	051717	A 124 JAZ PIMA		C 02 00124
000633	000662	A 125 CALL* INPG	GET READ/WRITE INTERRUPT	C 02 00125
000635	100416	A 126 JMP PIMT	TERMINATE	C 02 00126
000637	000600	A 127 JMP TTY1	ABORT	C 02 00127
000640	001000	A 128 JMP *+2	COMMA	C 02 00128
000641	000615	A 129 DRAI 1	PERIOD	C 02 00129
000642	001000	A 130 STA TYI1		C 02 00130
000643	000644	A 131 CALL* INPG	GET WRITE/READ INTERRUPT	C 02 00131
000644	006110	A 132 JMP PIMT	TERMINATE	C 02 00132
000645	000001	A 133 JMP TYI1	ABORT	C 02 00133
000646	051720	A 134 JMP *+2	COMMA	C 02 00134
000647	002000	A 135 DRAI 1	PERIOD	C 02 00135
000651	001000	A 136 STA TYI2		C 02 00136
000652	000600	A 137 PIMA JSS3	PIMH	C 02 00137
000663	001014	A 138 PIMB LDX =MS2		02 00138
000664	030000	L 139 CALL* DUTD	REQUEST PIM DEVICE ADDRESS	02 00139
000665	002000	A 140 CALL* INPG		02 00140
000666	100403	A 141 JMP PIMT	TERMINATE	02 00141
000667	002000	A 142 JMP PIMB	ABORT	02 00142
000674	000664	A 143 JMP *+2		02 00143
000675	001000	A 144 STA PIMC		02 00144
000700	002000	A 145 CALL* DUTC		02 00145
000701	100402	A 146 PIMC LDX =MS3		02 00146
000702	030000	L 147 CALL* DUTD	REQUEST ORIGIN OF TRAP ADDRESS	02 00147
000703	002000	A 148 CALL* INPG		02 00148
000704	100403	A 149 JMP PIMT	TERMINATE	02 00149
000705	002000	A 150 JMP PIMC	ABORT	02 00150
000706	100416	A 151 JMP *+2		02 00151
000710	000600	A 152 STA PADR		02 00152
000711	001000	A 153 CALL* DUTC		02 00153
000712	000702	A 154 PIMD CALL PLDW	SAVE CONTENTS O PART OF INTERRUPT AREA	02 00154

MAINTAIN III

PIMTST

PAGE 3

000721	001425	A	155	CALL	PMOD	CONSTRUCT PIM I/O INSTRUCTIONS	02 00155
000722	002000	A	156	CALL	POVL	MODIFY INTERRUPT ADDRESS LOCATIONS	02 00156
000723	001472	A	157	PIME	LDA	\$CON	02 00157
000724	002000	A	158	EXC	0500		02 00158
000725	001436	A	159	JZ	*44		02 00159
000726	010442	A	160	JMP	PIMF	NO	02 00160
000727	002000	A	161	TZA			02 00161
000728	005002	A	162	TZB			02 00162
000729	005003	A	163	TZX			02 00163
000730	001010	A	164	HLT	02	ENTER TEST NUMBER, CYCLE COUNT	02 00164
000731	000730	A	165	STA	TCNT		02 00165
000732	001000	A	166	STA	CYCL		02 00166
000733	000744	A	167	JMP	PIMG		02 00167
000734	005001	A	168	PIMF	LDX	#MS4	02 00168
000735	002000	A	169	CALL*	OUTD	PRINT "ENTER TEST NUMBER"	02 00169
000736	000403	R	170	CALL*	INPG		02 00170
000737	002000	R	171	JMP	PTER	TERMINATE	02 00171
000738	000777	A	172	JMP	PIME	ABORT	02 00172
000739	001000	A	173	JMP	*+2		02 00173
000740	000757	A	174	STA	TCNT		02 00174
000741	002000	A	175	CALL*	OUTC		02 00175
000742	000402	A	176	PIMG	LDA	TCNT	02 00176
000743	001000	A	177	JZ	PIME		02 00177
000744	000725	A	178	JZ	PIME		02 00178
000745	001010	A	179	SUBI	Z		C 02 00179
000746	000602	R	180	JAP	PIME		02 00180
000747	000726	A	181	TZA			02 00181
000748	005001	A	182	STA	IFLG	RESET INTERRUPT FLAG	02 00182
000749	001000	A	183	JMP	PIMJ	SELECT TEST	02 00183
000750	001000	A	184	*			02 00184
000751	000726	A	185	*	TERMINATE TEST		02 00185
000752	000402	A	186	*			02 00186
000753	010000	L	187	PTER	LDA	=01000	02 00187
001000	050000	A	188	STA	0		02 00188
001001	050042	A	189	STA	342		02 00189
001002	010000	L	190	STA	002000		02 00190
001003	050040	A	191	STA	040		02 00191
001004	011700	R	192	STA	041		02 00192
001005	050001	A	193	STA	1		02 00193
001006	011700	R	194	STA	2541		02 00194
001007	050041	A	195	STA	241		02 00195
001008	011707	R	196	STA	243		02 00196
001009	050043	A	197	STA	242		02 00197
001010	001000	A	198	JMP	PINT	GO TO BEGINNING OF TEST	02 00198
001011	000600	A	199	*			02 00199
001012	030000	L	200	PIMH	LDA	#MSS	02 00200
001013	002000	A	201	CALL*	OUTP	PRINT "RESET SSUB"	02 00201
001014	000403	R	202	JAP	PIMD		02 00202
001015	001000	A	203	*			02 00203
001016	000720	A	204	*			02 00204
001017	001000	A	205	PIMI	TZA		02 00205
001018	0005001	A	206	STA	\$CON		02 00206
001019	050442	A	207	STA			02 00207
001020	005002	A	208	TZX			02 00208
001021	005004	A	209	HLT	01		02 00209
001022	000601	A	210	STA	PIM		02 00210
001023	050710	A	211	STA	PIUR		02 00211
001024	011704	R	212	JMP	PIMD		02 00212
001025	001000	A	213	*			02 00213
001026	000720	A	214	*			02 00214
001027	001000	A	215	*	SELECT SUBTEST		02 00215
001028	000720	A	216	*			02 00216
001029	001000	A	217	PIMJ	LDA	TCNT	02 00217
001030	005311	A	218	DAR			02 00218
001031	001010	A	219	JZ	PIRA		02 00219
001032	011716	A	220	DAR			02 00220
001033	005311	A	221	JZ	PIRA		02 00221
001034	001010	A	222	DAR			02 00222
001035	001061	A	223	JZ	PICA		02 00223
001036	005311	A	224	DAR			02 00224
001037	001010	A	225	JZ	PICA		02 00225
001038	001065	A	226	DAR			02 00226
001039	005311	A	227	JZ	PICA		02 00227
001040	001065	A	228	DAR			02 00228
001041	005311	A	229	JZ	PICA		02 00229
001042	001010	A	230	DAR			02 00230
001043	001123	A	231	JZ	PIDA		02 00231
001044	005311	A	232	DAR			02 00232
001045	001010	A	233	JZ	PIDA		02 00233

PAGE	4	MAINTAIN III		PIMTST			
001046	001130	A	226	DAR	PIEA	C 02 00226	
001047	005311	A	227	JAZ	PIEA	C 02 00227	
001050	001010	A					
001051	001140	A	228	DAR		C 02 00228	
001052	005311	A	229	JAZ	PIFA	C 02 00229	
001053	001010	A					
001054	001146	A	230	JAZ	PIFA	C 02 00230	
001055	001010	A					
001056	001146	A	231	JMP	PIME	02 00231	
001057	001000	A					
001060	000726	A	232	*		02 00232	
			233	*	TEST 1	02 00233	
			234	*		02 00234	
001061	103000	A	235	PIAA	0,PIZZ	DISABLE MASK REGISTER 02 00235	
001062	001712	A					
001063	001000	A	236	JMP	PIAB	02 00236	
001064	001203	A					
			237	*		02 00237	
			238	*	TEST 2	02 00238	
			239	*		02 00239	
001065	103000	A	240	PIBA	0,PIZY	ENABLE MASK REGISTER 02 00240	
001066	001711	A					
001067	100500	A	241	EXC	0500	CLEAR INTERRUPT REGISTER AND DISABLE PIM 02 00241	
001070	010442	A	242	LDA	\$CON	CONSOLE MODE?	02 00242
001071	001010	A	243	JAZ	PIB3	YES	02 00243
001072	001120	A					
001073	030000	L	244	LDX	=MS6	02 00244	
001074	002000	A	245	CALL*	OUTD	02 00245	
001075	100403	A					
001076	002000	A	246	CALL*	INPG	02 00246	
001077	100416	A					
001100	001000	A	247	JMP	PTER	TERMINATE 02 00247	
001101	000777	A					
001102	001000	A	248	JMP	PIB2	ABORT 02 00248	
001103	001070	A					
001104	001000	A	249	JMP	*+2	02 00249	
001105	001106	A					
001106	001004	A	250	JAN	PIB2	02 00250	
001107	001070	A					
001110	001010	A	251	JAZ	*+4	02 00251	
001111	001114	A					
001112	001000	A	252	JMP	*+3	02 00252	
001113	001115	A					
001114	005211	A	253	CPR		02 00253	
001115	051702	A	254	STR	CYCL	02 00254	
001116	002000	A	255	CALL*	OUTC	02 00255	
001117	100402	A					
001120	100200	A	256	PIB3	EXC	02000	ENABLE PIM 02 00256
001121	001000	A	257	JMP	PIAD		02 00257
001122	001206	A					
			258	*		02 00258	
			259	*	TEST 3	02 00259	
			260	*		02 00260	
001123	103000	A	261	PICA	0,PIZY	ENABLE MASK REGISTER 02 00261	
001124	001711	A					
001125	100400	A	262	EXC	0400	DISABLE PIM 02 00262	
001126	001000	A	263	JMP	PIAC		02 00263
001127	001204	A					
			264	*		02 00264	
			265	*	TEST 4	02 00265	
			266	*		02 00266	
001130	103000	A	267	PIDA	0,PIZY	ENABLE MASK REGISTER 02 00267	
001131	001711	A					
001132	100500	A	268	EXC	0500	CLEAR INTERRUPT REG AND DISABLE INTERRUPTS 02 00268	
001133	002000	A	269	CALL	PIQ	PRINT 'SET INTERRUPTS'	02 00269
001134	001542	A					
001135	100300	A	270	EXC	0300	CLEAR INTERRUPT REG AND ENABLE INTERRUPTS 02 00270	
001136	001000	A	271	JMP	PIAD		02 00271
001137	001206	A					
			272	*		C 02 00272	
			273	*		C 02 00273	
			274	*	TEST 5	C 02 00274	
			275	*		C 02 00275	
001140	103000	A	276	PIEA	0,PIZY	ENABLE MASK REGISTER C 02 00276	
001141	001711	A					
001142	100300	A	277	EXC	0300	CLEAR INTERRUPT REG. AND ENABLE PIM C 02 00277	
001143	010444	A	278	EXC	0444	DISABLE ALL PIMS C 02 00278	
001144	001000	A	279	JMP	PIAC		C 02 00279
001145	001204	A					
			280	*		C 02 00280	
			281	*	TEST 6	C 02 00281	
			282	*		C 02 00282	
001146	103000	A	283	PIFA	0,PIZY	ENABLE MASK REGISTER C 02 00283	
001147	001711	A					
001150	100500	A	284	EXC	0500	CLEAR INTERRUPT REG. AND DISABLE PIM C 02 00284	
001151	010442	A	285	PIF2	LDA	\$CON C 02 00285	
001152	001010	A	286	JAZ	PIF3	CONSOLE MODE? YES C 02 00286	
001153	001200	A					
001154	006030	A	287	LDXI	MS6	C 02 00287	
001155	002023	A					
001156	002000	A	288	CALL*	OUTD	C 02 00288	
001157	100403	A					
001160	002000	A	289	CALL*	INPG	C 02 00289	
001161	100416	A					

MAINTAIN III						PIMTST	PAGE 5
001162	001000	A	290	JMP	PTER	TERMINATE	C 02 00290
001163	000777	A	291	JMP	PIF2	ABORT	C 02 00291
001164	001000	A	292	JMP	*#2	COMMA	C 02 00292
001165	001151	A	293	JAN	PIF2	PERIOD	C 02 00293
001167	001170	A	294	JAZ	*#4		C 02 00294
001170	001004	A	295	JMP	*#3		C 02 00295
001171	001151	A	296	CPA			C 02 00296
001172	001010	A	297	STA	CYCL		C 02 00297
001200	100244	A	298	PIF3	EXC 0244	ENABLE ALL PIMS	C 02 00298
001201	001000	A	299	JMP	PIAB		C 02 00299
001202	001206	A	300	*			
001203	100200	A	301	PIAB	EXC 0200	ENABLE PIM	02 00300
001204	002000	A	302	PIAC	CALL PIU	PRINT *SET INTERRUPTS*	02 00301
001205	001542	A	303	PIAB	TZA		02 00302
001206	005001	A	304	PIAE	LDA #16		02 00303
001207	010000	L	305	PIAJ	LDX #32767		02 00304
001210	030000	L	306	CALL*	TBLY	DELAY LOOP	02 00305
001211	002000	A	307	JAZ	PIAK		02 00306
001212	100420	A	308	BAR			02 00307
001213	001010	A	309	JMP	PIAJ		02 00308
001214	001220	A	310	PIAK	LDA CYCL		02 00309
001215	005311	A	311	JAM	PIAI		02 00310
001217	001210	A	312	BAR			02 00311
001220	011702	A	313	JAZ	PIAF	END OF TEST	02 00312
001221	001004	A	314	STA	CYCL		02 00313
001222	001255	A	315	JMP	PIRE	RECYCLE	02 00314
001223	005311	A	316	PIAF	LDA \$0000	CONSOLE MODE?	E 02 00315
001224	001010	A	317	EXC	0500	DISABLE PIM	02 00316
001225	001231	A	318	JAZ	PIAL		02 00317
001226	051702	A	319	LDA	#FLG	INTERRUPT FLAG SET?	02 00318
001227	001000	A	320	JAZ	PIAG	NO	02 00319
001230	001207	A	321	JMP	PIAH		02 00320
001231	010442	A	322	PIAG	LDX #MSZ		02 00321
001232	100500	A	323	CALL*	OUTP	PRINT *NO INTERRUPTS*	02 00322
001233	001010	A	324	PIAH	OUTC		02 00323
001234	001251	A	325	JMP	PIME		02 00324
001235	011703	A	326	*			02 00325
001236	001010	A	327	PIAL	LDA TELG		02 00326
001237	001242	A	328	HLT	#0		02 00327
001238	000005	A	329	JMP	PIME		02 00328
001254	000726	A	330	*		DISPLAY STATE OF INTERRUPT FLAG	02 00329
001255	002000	A	331	PIAI	CALL#		02 00330
001256	100421	A	332	MCG	011		02 00331
001257	005011	A	333	MCG	011	BC NOT HALT	02 00332
001260	000300	L	334	MCG	011	AL DECAYE	02 00333
001261	000772	A	335	MCG	011		02 00334
001262	001262	A	336	MCG	011		02 00335
001263	001000	A	337	JMP	PIME		02 00336
001264	001207	A	338	*			02 00337
001265	000000	A	339	*			02 00338
001266	002000	A	340	*			02 00339
001267	001611	A	341	PIMI	ENTR	SAVE REGISTERS	02 00340
001270	010000	L	342	CALL	PSAV		02 00341
001271	002000	A	343	LDA	#P261		02 00342
001272	001513	A	344	CALL	T120	PRINT LINE NUMBER	02 00343
001273	002000	A	345	CALL	PRCS	RESTORE REGISTERS	02 00344
001274	001612	A	346	INR	IFLG	SET INTERRUPT FLAG	02 00345
001275	041703	A	347	EXC	0900	ENABLE INTERRUPTS	02 00346
001276	100200	A	348	JMP*	PIMI		02 00347
001277	001000	A	349	*			02 00348
001300	101265	A	350	PIIN2	ENTR	SAVE REGISTERS	02 00349
001301	000000	A	351	CALL	PSAV		02 00350
001302	002000	A	352	LDA	#P262		02 00351
001303	001611	A	353	CALL	T120	PRINT LINE NUMBER	02 00352
001304	010000	L	354	PRCS		RESTORE REGISTERS	02 00353
001305	002000	A	355	INR	IFLG	SET INTERRUPT FLAG	02 00354
001306	001513	A	356				02 00355
001307	002000	A	357				02 00356
001310	001612	A	358				02 00357
001311	041703	A	359				02 00358

PAGE	6	MAINTAIN III			PIMTST		
001312	100200	A	355	EXC	0200	ENABLE INTERRUPTS	02 00355
001313	001000	A	356	JMP*	PIN2	RETURN	02 00356
001314	101301	A	357 *				
001315	000000	A	358	PIN3	ENTR	SAVE REGISTERS	02 00357
001316	002000	A	359	CALL	PSAV		02 00358
001317	001611	A					02 00359
001320	010000	L	360	LDA	=0263	PRINT LINE NUMBER	02 00360
001321	002000	A	361	CALL	TT20		02 00361
001322	001513	A					
001323	002000	A	362	CALL	PRES	RESTORE REGISTERS	02 00362
001324	001617	A					
001325	041703	A	363	INR	IFLG	SET INTERRUPT FLAG	02 00363
001326	100200	A	364	EXC	0200	ENABLE INTERRUPTS	02 00364
001327	001000	A	365	JMP*	PIN3		02 00365
001330	101315	A	366 *				
001331	000000	A	367	PIN4	ENTR	SAVE REGISTERS	02 00366
001332	002000	A	368	CALL	PSAV		02 00367
001333	001611	A					02 00368
001334	010000	L	369	LDA	=0264	PRINT LINE NUMBER	02 00369
001335	002000	A	370	CALL	TT20		02 00370
001336	001513	A					
001337	002000	A	371	CALL	PRES	RESTORE REGISTERS	02 00371
001340	001617	A					
001341	041703	A	372	INR	IFLG	SET INTERRUPT FLAG	02 00372
001342	100200	A	373	EXC	0200	ENABLE INTERRUPTS	02 00373
001343	001000	A	374	JMP*	PIN4		02 00374
001344	101331	A	375 *				
001345	000000	A	376	PIN5	ENTR	SAVE REGISTERS	02 00375
001346	002000	A	377	CALL	PSHV		02 00376
001347	001611	A					02 00377
001350	010000	L	378	LDA	=0265	PRINT LINE NUMBER	02 00378
001351	002000	A	379	CALL	TT20		02 00379
001352	001513	A					
001353	002000	A	380	CALL	PRES	RESTORE REGISTERS	02 00380
001354	001617	A					
001355	041703	A	381	INR	IFLG	SET INTERRUPT FLAG	02 00381
001356	100200	A	382	EXC	0200	ENABLE INTERRUPTS	02 00382
001357	001000	A	383	JMP*	PIN5		02 00383
001360	101345	A	384 *				
001361	000000	A	385	PIN6	ENTR	SAVE REGISTERS	02 00384
001362	002000	A	386	CALL	PSAV		02 00385
001363	001611	A					02 00386
001364	010000	L	387	LDA	=0266	PRINT LINE NUMBER	02 00387
001365	002000	A	388	CALL	TT20		02 00388
001366	001513	A					
001367	002000	A	389	CALL	PRES	RESTORE REGISTERS	02 00389
001370	001617	A					
001371	041703	A	390	TND	IFLG	SET INTERRUPT FLAG	02 00390
001372	100200	A	391	LDA	0200	ENABLE INTERRUPTS	02 00391
001373	001000	A	392	JMP*	PIN6		02 00392
001374	101361	A	393 *				
001375	000000	A	394	PIN7	ENTR	SAVE REGISTERS	02 00393
001376	002000	A	395	CALL	PSAV		02 00394
001377	001611	A					02 00395
001400	010000	L	396	LDA	=0267	PRINT LINE NUMBER	02 00396
001401	002000	A	397	CALL	TT20		02 00397
001402	001513	A					
001403	002000	A	398	CALL	PRES	RESTORE REGISTERS	02 00398
001404	001617	A					
001405	041703	A	399	TND	IFLG	SET INTERRUPT FLAG	02 00399
001406	100200	A	400	LDA	0200	ENABLE INTERRUPTS	02 00400
001407	001000	A	401	JMP*	PIN7		02 00401
001410	101375	A	402 *				
001411	000000	A	403	PIN8	ENTR	SAVE REGISTERS	02 00410
001412	002000	A	404	CALL	PSHV		02 00411
001413	001611	A					02 00412
001414	010000	L	405	LDA	=0270	PRINT LINE NUMBER	02 00413
001415	002000	A	406	CALL	TT20		02 00414
001416	001513	A					
001417	002000	A	407	CALL	PRES	RESTORE REGISTERS	02 00415
001420	001617	A					
001421	041703	A	408	INR	IFLG	SET INTERRUPT FLAG	02 00416
001422	100200	A	409	EXC	0200	ENABLE INTERRUPTS	02 00417
001423	001000	A	410	JMP*	PIN8		02 00418
001424	101311	A	411 *				
			412 *				
			413 * SAVE ORIGINAL TRANSFER VECTORS WHICH GET OVERLID				
			414 *				
001425	000000	A	415	PLOW	ENTR		02 00419
001426	010001	A	416	LDA	1		02 00420
001427	051705	A	417	STA	P01	SAVE CONSOLE INTERRUPT,	02 00421
001428	010041	A	418	LDA	041	POWER UPDOWN ADDRESSES	02 00422
001431	051706	A	419	STA	0741		02 00423
001432	010043	A	420	LDA	040		02 00424
001433	051707	A	421	STA	0043		02 00425
001435	001000	A	422	JMP*	PLOW		02 00426
			423 *				

MAINTAIN III				PIMTST	
001436 000000 R	424 *				02 00424
001437 005004 R	425 *	FILL INTERRUPT AREA WITH ENTRIES TO INTERRUPT ROUTINES			02 00425
001440 020000 L	426 *				02 00426
001441 010000 L	427 *				02 00427
001442 055000 R	428 P0VL ENTR				02 00428
001443 005144 R	429 TZX				02 00429
001444 010000 L	430 LDB =128				02 00430
001445 055000 R	431 PDV2 LDA =02000				02 00431
001446 005144 R	432 STA 0,1				02 00432
001447 005322 R	433 IXR				02 00433
001448 001020 R	434 LDA =PINX				02 00434
001449 001454 R	435 STA 0,1				02 00435
001450 001020 R	436 IXR				02 00436
001451 001454 R	437 DBR				02 00437
001452 001020 R	438 JBR	PDV3			02 00438
001453 001441 R	439 JMP PDV2				02 00439
001454 031704 R	440 PDV3 LDX PADDR				02 00440
001455 020000 L	441 LDB =PTAB				02 00441
001456 016000 R	442 PDV4 LDA 0,2		MOVE INTERRUPT TRANSFER VECTORS		02 00442
001457 001010 R	443 JBR PDV5			C	02 00443
001460 001466 R	444 STA 0,1				02 00444
001462 005122 R	445 LDP				02 00445
001463 005144 R	446 IXR				02 00446
001464 001000 R	447 JMP PDV4				02 00447
001465 001456 R	448 PDV5 LDA =PIM			C	02 00448
001467 001010 R	449 JBR P0VL			C	02 00449
001470 101436 R	450 LDRI TTYI	SET		C	02 00450
001472 001605 R	451 STAK TTY1	UP		C	02 00451
001473 057000 I	452 STAK TTY2	TTY		C	02 00452
001475 001000 R	453 JMP* P0VL	INTERRUPTS		C	02 00453
001476 101436 R	454 *				02 00454
001477 000000 R	455 *				02 00455
001500 030000 L	456 * ADD DEVICE ADDRESS TO PIM I/O INSTRUCTIONS				02 00456
001501 025000 R	457 * PMOD ENTR				02 00457
001502 001020 R	458 LDX APPDOP				02 00458
001503 101472 R	459 PMOD LDR C,1				02 00459
001504 016000 R	460 LDR PMOD		GOT POINTER		02 00460
001505 150000 L	461 JBR* END OF TABLE				02 00461
001506 111710 R	462 LDR 0,2				02 00462
001507 056000 R	463 LDR =9177700		GET INSTRUCTION		02 00463
001508 005144 R	464 P0D PIM				02 00464
001509 001000 R	465 STA 0,2		ADD PIM DEVICE ADDRESS		02 00465
001510 001501 R	466 LDR 0,2				02 00466
001511 001000 R	467 JBR PMOD				02 00467
001512 001501 R	468 *				02 00468
001513 000000 R	469 *				02 00469
001514 020442 R	470 TT20 ENTR				02 00470
001515 001020 R	471 LDRI SC0N	CONSOLE MORE?			02 00471
001516 001521 R	472 JBR 0,2				02 00472
001517 001000 R	473 JMP TTY1				02 00473
001520 001525 R	474 LDR 0,2				02 00474
001521 150000 L	475 P0D =017	YES			02 00475
001522 000006 R	476 STA 0,2	DISPLAY INTERRUPT LINE NUMBER			02 00476
001523 001020 R	477 JBR TTY20				02 00477
001524 101510 R	478 LDR 0,2				02 00478
001525 002000 R	479 TT21 TTYL*	0010			02 00479
001526 100430 R	480 LDR 0,2				02 00480
001527 041701 R	481 IXR 0,2				02 00481
001528 011701 R	482 LDR 0,2				02 00482
001529 140000 L	483 LDR 0,2		CROSS COUNT EXCEEDED?		02 00483
001530 001000 R	484 JBR 0,2	NO			02 00484
001531 101510 R	485 LDR 0,2				02 00485
001532 002000 R	486 CALL* OUTC	YES* PRINT PROFILE			02 00486
001533 100430 R	487 LDR 0,2				02 00487
001534 005001 R	488 JBR 0,2				02 00488
001535 051702 R	489 LDR CYCL				02 00489
001536 010442 R	490 LDR =600H		CONSOLE MORE?		02 00490
001537 001010 R	491 JBR P102	YES			02 00491
001538 001563 R	492 LDR =PMS				02 00492
001539 030000 L	493 LDR =PTER				02 00493
001541 002000 R	494 CALL* OUTD	PRINT 'SET INTERRUPTS'			02 00494
001542 010600 L	495 LDR =PTER				02 00495
001543 051702 R	496 LDR CYCL				02 00496
001544 010442 R	497 LDR =600H				02 00497
001545 001010 R	498 JBR P102				02 00498
001546 001563 R	499 LDR =PMS				02 00499
001547 030000 L	500 LDR =PTER				02 00500
001548 002000 R	501 CALL* OUTD	TERMINATE			02 00501
001549 100402 R	502 CALL* OUTC				02 00502

PAGE	8	MAINTAIN III		PIMTST			
001561	001000	A	498	JMP*	PIO	02 00498	
001562	101542	A	499	PIO2	HLT 03	02 00499	
001563	000003	A	500	JMP*	PIO	02 00500	
001564	001000	A	501	*		02 00501	
001565	101542	A	502	*		02 00502	
001566	000000	A	503	PINX	ENTR	02 00503	
001567	002000	A	504	CALL	PSAV	02 00504	
001570	001611	A	505	CALL*	SSWT	02 00505	
001571	002000	A	506	HLT	04	INVALID INTERRUPTS	02 00506
001572	100421	A	507	DATA	MS9	02 00507	
001573	000004	A	508	DATA	PIER	02 00508	
001574	002067	A	509	DATA	*+1	02 00509	
001575	000777	A	510	CALL	PRES	RESTORE REGISTERS	02 00510
001600	001612	A	511	INR	IFLG	SET INTERRUPT FLAG	02 00511
001602	100200	A	512	PINI	EXC 0200	ENABLE INTERRUPTS	02 00512
001603	001000	A	513	JMP*	PINX		02 00513
001604	101566	A	514	TTYI	ENTR	TTY INTERRUPT	C 02 00514
001605	000000	A	515	PUT	EXC 0200	ENABLE PIM UNDER TEST	B 02 00515
001607	001000	A	516	JMP*	TTYI		C 02 00516
001610	101605	A	517	*			02 00517
			518	*			02 00518
			519	* SAVE/RESTORE REGISTERS			02 00519
			520	*			02 00520
001611	000000	A	521	PSAV	ENTR		02 00521
001612	051713	A	522	STA	SAVA		02 00522
001613	061714	A	523	STB	SAVB		02 00523
001614	071715	A	524	STX	SAVX		02 00524
001615	001000	A	525	JMP*	PSAV		02 00525
001616	101611	A	526	*			02 00526
001617	000000	A	527	PRES	EMTR		02 00527
001620	011713	A	528	LDA	SAVA		02 00528
001621	021714	A	529	LDB	SAVB		02 00529
001622	031715	A	530	LDX	SAVX		02 00530
001623	001000	A	531	JMP*	PRES		02 00531
001624	101617	A	532	*			02 00532
			533	*			02 00533
			534	*			02 00534
001625	002000	A	535	PTAB	JMPM PIN1		02 00535
001626	001265	A	536	JMPM	PIN2		02 00536
001627	002000	A	537	JMPM	PIN3		02 00537
001630	001301	A	538	JMPM	PIN4		02 00538
001631	002000	A	539	JMPM	PIN5		02 00539
001632	001315	A	540	JMPM	PIN6		02 00540
001633	002000	A	541	JMPM	PIN7		02 00541
001634	001331	A	542	JMPM	PIN8		02 00542
001635	002000	A	543	DATA	0		02 00543
001636	001345	A	544	*			02 00544
001637	002000	A	545	PPOP	DATA PIAA		02 00545
001647	000727	A	546	DATA	PIME+1		02 00546
001650	001123	A	547	DATA	PICA		02 00547
001651	001123	A	548	DATA	PICA+2		02 00548
001652	001130	A	549	DATA	PIDA		02 00549
001653	001132	A	550	DATA	PIDA+2		02 00550
001654	001135	A	551	DATA	PIDA+5		02 00551
001655	001203	A	552	DATA	PIDB		02 00552
001656	001065	A	553	DATA	PIDB		02 00553
001657	001067	A	554	DATA	CIBA+2		02 00554
001660	001120	A	555	DATA	PICB		02 00555
001661	001276	A	556	DATA	PIN1+9		02 00556
001662	001312	A	557	DATA	PIN0+9		02 00557
001663	001326	A	558	DATA	PIN3+9		02 00558
001664	001342	A	559	DATA	PIN4+9		02 00559
001665	001356	A	560	DATA	PIN5+9		02 00560
001666	001372	A	561	DATA	PIN3+9		02 00561
001667	001406	A	562	DATA	PIN7+9		02 00562
001670	001422	A	563	DATA	PIN8+0		02 00563
001671	001602	A	564	DATA	PINI		02 00564
001672	001140	A	565	DATA	PICA		02 00565
001673	001142	A	566	DATA	PICA+2		02 00566
001674	001146	A	567	DATA	PIDA		02 00567
001675	001150	A	568	DATA	PIDA+2		02 00568
001676	001232	A	569	DATA	PIDF+1		02 00569
001677	001606	A	570	DATA	PUT		02 00570
001700	000000	A	571	DATA	0		02 00571
			572	*			02 00572
			573	*			02 00573
001701	000000	A	574	CC	DATA 0		02 00574
001702	000000	A	575	CYCL	DATA 0		02 00575

MAINTAIN III

PIMTST

PAGE 9

001703 000000 A	576 IFLG	DATA	0	02 00576
001704 000000 A	577 PADR	DATA	0	02 00577
001705 000000 A	578 PB1	DATA	0	02 00578
001706 000000 A	579 PB41	DATA	0	02 00579
001707 000000 A	580 PD43	DATA	0	02 00580
001710 000000 A	581 PIM	DATA	0	02 00581
001711 000000 A	582 PIZY	DATA	0	02 00582
001712 177777 A	583 PIZZ	DATA	0177777	02 00583
001713 000000 A	584 SAVA	DATA	0	02 00584
001714 000000 A	585 SAVE	DATA	0	02 00585
001715 000000 A	586 SAVX	DATA	0	02 00586
001716 000000 A	587 TCNT	DATA	0	02 00587
001717 000000 A	588 TFIM	DATA	0	C 02 00588
001720 000000 A	589 TY11	DATA	0	C 02 00589
001721 000000 A	590 TY12	DATA	0	C 02 00590
	591 *			02 00591
	592 *			02 00592
001722 106612 A	593 MS1	DATA	0106612, 'PIM TEST', 0106612, 0	02 00593
001723 150311 A				
001724 146640 A				
001725 152305 A				
001726 151724 A				
001727 106612 A				
001730 000000 A				
001731 106612 A	594 MS2	DATA	0106612, 'ENTER PIM DEVICE ADDRESS ', 0	02 00594
001732 142716 A				
001733 152305 A				
001734 151240 A				
001735 150311 A				
001736 146640 A				
001737 142305 A				
001740 153311 A				
001741 141705 A				
001742 120301 A				
001743 142304 A				
001744 151305 A				
001745 151723 A				
001746 120240 A				
001747 000000 A				
001750 106612 A	595 MS3	DATA	0106612, 'ENTER ORIGIN OF TRAP ADDRESSES ', 0	02 00595
001751 142716 A				
001752 152305 A				
001753 151240 A				
001754 147722 A				
001755 144707 A				
001756 144716 A				
001757 120317 A				
001760 143240 A				
001761 152322 A				
001762 140720 A				
001763 120301 A				
001764 142304 A				
001765 151305 A				
001766 151723 A				
001767 142723 A				
001770 120240 A				
001771 000000 A				
001772 106612 A	596 MS4	DATA	0106612, 'ENTER SUBTEST NUMBER ', 0	02 00596
001773 142716 A				
001774 152305 A				
001775 151240 A				
001776 151725 A				
001777 141324 A				
002000 142723 A				
002001 152210 A				
002002 152323 A				
002003 146702 A				
002004 142722 A				
002005 120240 A				
002006 000000 A				
002007 151305 A				
002010 151723 A				
002011 152320 A				
002012 151705 A				
002013 147323 A				
002014 142640 A				
002015 151727 A				
002016 144724 A				
002017 141710 A				
002020 120263 A				
002021 106612 A				
002022 000000 A				
002023 142716 A	597 MS5	DATA	'RESET SENSE SWITCH 3', 0106612, 0	02 00597
002024 152305 A				
002025 151240 A				
002026 142325 A				
002027 146702 A				
002030 142722 A				
002031 120317 A				
002032 143240 A				
002033 132640 A				
002034 151705 A				
002035 141717 A				
002036 147304 A				
002037 120311 A				
598 MS6	DATA	'ENTER NUMBER OF 5 SECOND INTERVALS ', 0	02 00598	

PAGE 10 MAINTAIN III PIMTST

```

002040 147324 A
002041 142722 A
002042 153301 A
002043 146323 A
002044 120240 A
002045 000000 A
002046 147317 A 599 MS7 DATA "NO INTERRUPTS",0 02 00599
002047 120311 A
002050 147324 A
002051 142722 A
002052 151325 A
002053 150324 A
002054 151640 A
002055 000000 A
002056 151705 A 600 MS8 DATA "SET INTERRUPTS ",0 02 00600
002057 152240 A
002060 144716 A
002061 152305 A
002062 151322 A
002063 152720 A
002064 152323 A
002065 120240 A
002066 000000 A
002067 144716 A 601 MS9 DATA "INVALID INTERRUPT",0106612,0 02 00601
002070 153301 A
002071 146311 A
002072 142240 A
002073 144716 A
002074 152305 A
002075 151322 A
002076 152720 A
002077 152240 A
002100 106612 A
002101 000000 A
002102 106612 A 602 MS10 DATA 0106612,"TTY INTERRUPTS? ",0 C 02 00602
002103 152324 A
002104 154640 A
002105 144716 A
002106 152305 A
002107 151322 A
002110 152720 A
002111 152323 A
002112 137640 A
002113 000000 A
000600 A 603 END PIMT 02 00603

```

ENTRY NAMES
EXTERNAL NAMES
SYMBOLS

000442 A \$CON	000440 A \$FLG	000441 A \$MEM	001701 A CC
001702 A CYCL	000422 A ELOC	000504 A IADR	001703 A IFLG
000410 A INPA	000411 A INPB	000412 A INPC	000413 A INPD
000414 A INPE	000415 A INPF	000416 A INPG	000520 A LTOR
001722 A MS1	002102 A MS10	001731 A MS2	001750 A MS3
001722 A MS4	002007 A MS5	002023 A MSS	002046 A MS7
002056 A MSS	002067 A MS9	000400 A OUTA	000401 A OUTB
000402 A OUTC	000403 A OUTD	000404 A OUTE	000405 A OUTF
000406 A OUTG	000407 A OUTH	001704 A PADR	001705 A PD1
001706 A PD41	001707 A PD43	001061 A PIAA	001203 A PIAB
001204 A PIAC	001206 A PIAD	001207 A PIAE	001231 A PIAF
001242 A PIAG	001245 A PIAH	001255 A PIAI	001210 A PIAJ
001220 A PIAK	001251 A PIAL	001070 A PIE2	001120 A PIE3
001065 A PIBA	001123 A PICA	001130 A PIDA	001140 A PIEA
001151 A PIF2	001200 A PIF3	001146 A PIFA	001710 A PIM
000662 A PIMA	000664 A PIMB	000702 A PIMC	000720 A PIMD
000726 A PIME	000744 A PIMF	000762 A PIMG	001014 A PIMH
001021 A PIMI	001032 A PIMJ	000600 A PIMT	001265 A PIN1
001301 A PIM2	001315 A PIN3	001331 A PIN4	001345 A PIN5
001361 A PIM6	001375 A PIN7	001411 A PINS	001602 A PIMI
001566 A PIMX	001542 A PIO	001563 A PIO2	001711 A PIZY
001712 A PIZZ	001425 A PLow	001501 A PM02	001472 A PMOD
001441 A POV2	001454 A POV3	001456 A POV4	001466 A POV5
001436 A POV1	001646 A PP0P	001617 A PRES	001611 A PSAV
001625 A PTAB	000777 A PTER	001606 A PUT	001713 A SAVA
001714 A SAVB	001715 A SAVX	000421 A SSWT	001716 A TCNT
000420 A TDLY	000417 A TOUT	001717 A TPIM	000471 A TS04
001513 A TT20	001525 A TT21	000615 A TTY1	001605 A TTYI

0 ERRORS ASSEMBLY COMPLETE

LITERALS

000520 001722
000521 001731
000522 001750
000523 001772
000524 001000
000525 002000
000526 002007
000527 002023
000530 000020
000531 077777
000532 002046
000533 000261
000534 000262
000535 000263
000536 000264
000537 000265

000540	000266								
000541	000267								
000542	000270								
000543	000200								
000544	001666								
000545	001625								
000546	001646								
000547	177700								
000550	000017								
000551	000106								
000552	000001								
000553	002056								
POINTERS									
000504	101720								
000505	101721								
87	\$COM	108	157	206	242	285	316	471	491
85	\$FLG	*							
86	\$MEM	*							
574	CC	112	428	479	484				
575	CYCL	166	254	297	310	314	490		
78	ELOC	*							
99	IAOR	*							
576	IIFLG	182	319	327	345	354	363	372	381
		399	408	511					390
68	INPA	*							
69	INPB	495							
70	INPC	*							
71	INPB	*							
72	INPE	*							
73	INPF	*							
74	INPG	119	125	131	148	149	170	246	289
100	LTOR	*							
593	MS1	110							
602	MS10	117							
594	MS2	138							
595	MS3	146							
596	MS4	160							
597	MS5	200							
598	MS6	244	287						
599	MS7	320							
600	MS8	493							
601	MS9	507							
60	OUTA	477							
61	OUTB	*							
62	OUTC	145	153	175	255	324	482	497	
63	OUTD	113	118	130	147	169	201	245	288
		494							323
64	OUTE	*							
65	OUTF	*							
66	OUTG	*							
67	OUTH	*							
572	PDDR	152	211	440					
573	PDI	192	417						
579	PDI41	194	419						
580	PDI43	196	421						
835	PIDAB	219	545						
391	PIDAB	236	552						
392	PIDAC	260	579						
303	PIDAB	257	571	299					
304	PIDAC	315	526						
316	PIDAF	310	562						
322	PIDAB	320							
324	PIDAB	321							
331	PIDAB	311							
335	PIDAB	309							
310	PIDAB	327							
327	PIDAB	318							
342	PIDAB	249	250						
256	PIDAB	263	556						
260	PIDAB	261	552	554					
261	PIDAB	273	547	548					
267	PIDAB	225	549	550	551				
226	PIDAB	207	561	562					
225	PIDAB	291	593						
220	PIDAB	229	567	568					
221	PIDAB	104	210	424					
132	PIDAB	116	126	260					
138	PIDAB	132							
146	PIDAB	100							
154	PIDAB	212							
157	PIDAB	172	173	180	231	325	329	546	
160	PIDAB	160	172						
176	PIDAB	152							
200	PIDAB	237							
205	PIDAB	104	109						
212	PIDAB	189							
108	PIM1	103	120	126	132	141	149	193	603
340	PIM1	307	535	536					
349	PIM2	356	536	537					
358	PIM3	363	537	553					
367	PIM4	374	538	559					
326	PIM5	383	539	569					
305	PIM6	392	540	561					
394	PIM7	401	541	560					

PAGE 12

MAINTAIN III

PIMTST

403	PIN8	410	542	563					
512	PINI	564							
503	PINX	434	513						
488	PIO	269	302	498	500				
499	PI02	492							
582	PIZY	240	261	267	276	283			
583	PIZZ	235							
415	PLOW	154	422						
468	PM02	462							
458	PMOD	155	461						
431	POV2	439							
440	POV3	438							
442	POV4	447							
448	POVS	443							
428	POVL	156	449	453					
545	PPOP	459							
527	PRES	344	353	352	371	380	389	398	407
		531							510
521	PSAV	341	350	359	368	377	386	395	404
		525							504
535	PTAB	441							
187	PTER	171	247	290	334	496	508		
515	PUT	570							
584	SAVA	522	528						
585	SAVB	523	529						
586	SAVX	524	530						
72	SSHT	331	505						
587	TCNT	165	174	176	217				
76	TDLY	306							
75	TDUT	*							
588	TPIM	114	123	448					
89	TS04	*							
470	TT20	343	352	361	370	379	388	397	406
		481	485						476
477	TT21	473							
112	TTY1	121	127	133					
514	TTYI	450	516						
582	TY11	130	451						
590	TY12	136	452						