

MXM-B

M funct Diag  
CVMx BAO

AH-T552A-HC  
Juli' 1983

A large grid of approximately 15 columns and 25 rows of small, illegible text or data points, likely representing a functional diagram or test results. The text is too small to be transcribed accurately.



IDENTIFICATION

PRODUCT CODE: AC-T551A-MC  
PRODUCT NAME: CVMXBA0 MXV11-B MFUNCT DIAG  
PRODUCT DATE: 02-MAR-83  
MAINTAINER: E.S.D. METHODS  
AUTHOR: DICE SYSTEMS, INC.

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1983 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL  
DEC

PDP  
DECUS

JNIBUS  
DECTAPE

MASSBUS

MXV11-B DIAGNOSTIC USER'S MANUAL

TABLE OF CONTENTS

1. GENERAL PROGRAM INFORMATION
  1. PROGRAM PURPOSE (ABSTRACT)
  2. SYSTEM REQUIREMENTS
  3. RELATED DOCUMENTS AND STANDARDS
  4. DIAGNOSTIC HIERAPCHY PREREQUISTES
  5. ASSUMPTIONS
  5. VT-100 CONSOLE SETUP
2. OPERATING INSTRUCTIONS
  1. LOADING AND START PROCEDURES
  2. SPECIAL ENVIRONMENTS
  3. OPERATIONAL SWITCH SETTINGS
  4. PROGRAM OPTIONS AND DEFAULTS
  5. EXECUTION TIMES
  6. POWER FAIL
3. ERROR INFORMATION
  1. ERROR REPORTING PROCEDURE
  2. ERROR HALTS
  3. ERROR NUMBERS
4. PERFORMANCE AND PROGRESS REPOP.S
  1. PERFORMANCE REPORTS
5. DEVICE INFORMATION TABLES
6. SUMMARY OF TESTS

## 1.0 GENERAL PROGRAM INFORMATION.

### 1.1 PROGRAM PURPOSE (ABSTRACT).

THIS DIAGNOSTIC IS A LOGIC TEST TO VERIFY THE OPERATION OF THE 2 SERIAL LINE UNITS, ROM AND CLOCK OPTIONS, THE PCR REGISTER AND THE DDR REGISTER, AND RAM ON THE MXV11-B.

THE PROGRAM WILL TEST TO WHATEVER OPTIONS THE DEVICE MAP (\$DEVN) IS SET TO. SEE PROGRAM OPTIONS AND DEFAULTS SEC 2.4. THE PROGRAM WILL PRINT THE CONTENTS OF \$DEVN FOR OPERATOR VERIFICATION AND A SUMMARY OF SIGNIFICANT DIFFERENCES FROM THE DEFAULT CONDITIONS I.E.: CHANNEL(S) DROPPED FROM TESTING, CHANNEL 1 AS CONSOLE. ROM/RAM TESTING BYPASSED AND CLOCK ENABLED.

SERIAL LINE UNIT TESTING IS DONE IN TWO DISTINCT PHASES:

1. EACH OF THE 2 CHANNELS OF THE MXV11-B IS TESTED INDIVIDUALLY.
2. THE MXV11-B MODULE IS TESTED AS A WHOLE FOR CHANNEL INTERACTION PROBLEMS. THIS DIAGNOSTIC IS DESIGNED TO TEST AND DETECT ERRORS TO THE LOGIC LEVEL AND NOT THE CHIP LEVEL.

THE OPERATOR MUST INSTALL DATA WRAP AROUND CONNECTORS TO DO DATA TESTING. TO BYPASS DATA TESTS, THE OPERATOR MUST MODIFY \$DEVN. SEE PROGRAM OPTIONS SEC. 2.4

THE ADDRESSES AND VECTOR RANGES ARE AS FOLLOWS:

CHANNEL 0: 776500 THRU 777570  
CHANNEL 1: 776510 THRU 777600  
          777560 ( AS CONSOLE )  
VECTORS : 4 THRU 376  
PCR : 777520           DDR: 777524   LTC: 777546

THE DEFAULT ADDRESSES AND VECTORS ARE AS FOLLOWS:

CHANNEL 0: 776500 THRU 776506   VECTORS: 300/304  
CHANNEL 1: 177560 THRU 177566   VECTORS: 60/64

FOR ANY OTHER DEVICE ADDRESSES THE OPERATOR MUST CHANGE THE DEFAULT LOCATIONS. SEE PROGRAM OPTIONS AND DEFAULTS SEC. 2.4 .

THIS PROGRAM IS DESIGNED TO RUN ON ANY Q-BUS/Q22 PDP-11, WITH 64K MEMORY, AND WITH AN MXV11-B (Q-BUS/Q22) MODULE. IT CAN RUN UNDER XXDP AND APT MONITORS, AND ON PROCESSORS WITH NO HARDWARE SWITCH REGISTER.

## 1.2 SYSTEM REQUIREMENTS.

### 1.2.1 HARDWARE REQUIREMENTS: -

KDF11 PROCESSOR  
64K WORDS MEMORY - MINIMUM (CONTAINED ON THE MXV11-B)  
A SPECIAL DATA WRAP AROUND CONNECTOR (PN M3270-A) OR EQUIVALENT  
(REQ'D IF DATA WRAP AROUND TESTS DESIRED)

IF CHAN. 1 IS THE CONSOLE, TESTS 11-14, 16-21, 23-24 ARE BYPASSED ( BYPASS FOR CHAN.1 ONLY ).

IF DATA WRAP AROUND TESTS ARE BYPASSED, TESTS 12-14, 16-21, 23-24 ARE BYPASSED.

### 1.2.2 SOFTWARE REQUIREMENTS: -

THIS DIAGNOSTIC CAN RUN IN THE FOLLOWING WAYS:

STAND ALONE  
WITH APT MONITOR  
WITH XXDP MONITOR (CHAINABLE IF RENAMED TO .BIC EXTENSION)

THIS DIAGNOSTIC IS NOT DESIGNED TO RUN WITH THE DIAGNOSTIC SUPERVISOR.

### 1.3 RELATED DOCUMENTS AND STANDARDS.

DIAGNOSTIC ENGINEERING STANDARDS AND CONVENTIONS	175-003-009-02
APT	MD-11-DZZMA
SYSMAC	MD-11-DZQAC

### 1.4 DIAGNOSTIC HIERARCHY PREREQUISITES.

NO SPECIAL DIAGNOSTICS ARE REQUIRED TO RUN BEFORE THIS, BUT THE PROCESSOR, MEMORY, AND BUS ARE ASSUMED TO BE FULLY OPERATIONAL.

### 1.5 ASSUMPTIONS.

THE OPERATOR MUST:

1. SET THE SOFTWARE SWITCH REGISTER (SWR) IF NOT DEFAULTED.(SEC. 2.3)
2. SET THE DEVICE MAP (\$DEVN) IF NOT DEFAULTED.(SEC. 2.4)
3. SET THE SERIAL LINE ADDRESSES AND VECTORS IF NOT DEFAULTED.(SEC 2.4)
4. SET THE RUN HI AND LO ADDR IF NOT DEFAULTED.(SEC 2.4)

### 1.6 VT-100 CONSOLE SETUP

IF CHANNEL 1 IS CONFIGURED AS THE CONSOLE AND THE VT-100 IS THE CONSOLE DEVICE, 'SETUP B' MUST BE SET IN FOR THE FOLLOWING:

- A. DISABLE XON/XOFF
- B. JUMP SCROLL ON
- C. NEW LINE OFF
- D. ALL OTHER OPTIONS PER SYSTEM REQUIREMENTS.

## 2.0 OPERATING INSTRUCTIONS

### 2.1 LOADING AND STARTING PROCEDURES.

USE STANDARD PROCEDURE FOR PDP-11 ABSOLUTE BINARY FORMATTED MEDIA.

ALL NORMAL STARTS AND RESTARTS ARE FROM LOCATION 200.

THERE ARE 2 STARTING ADDRESSES TO BE USED OFF LINE ONLY FOR INTERRUPT VECTOR TROUBLE SHOOTING:

1334 START: LOADS ADDRESSES 0 TO 1000 WITH THE ADDRESS OF AN INTERRUPT ROUTINE THAT JUST DOES RTI'S ALLOWING LOOPING IN THAT PART OF THE TEST WHERE INTERRUPT VECTOR PROBLEMS ARE OCCURING. NORMAL TESTING WILL THEN BEGIN.

1356 START: LOADS ADDRESSES 0 TO 1000 WITH TRAP CATCHER CODE. ANY INTERRUPT TO THIS REGION WILL HALT. NORMAL TESTING WILL THEN BEGIN.

AS SOON AS TESTING STARTS, THE OPERATOR CAN CHANGE THE SWITCH REGISTER ONLY BY A 'BREAK' AND MANUALLY LOADING LOCATION 176 (SWREG) WITH THE DESIRED CONTENTS (SEE SEC. 2.3) THEN DOING A 'P' TO PROCEED.

THE USER CAN SELECT A SPECIFIC TEST TO BE EXECUTED BY SETTING BIT 8 IN SWREG AND THE TEST NUMBER (IN OCTAL) IN BITS <7:0>. (NOTE: ALL TESTS PREVIOUS TO THE SELECTED ONE ARE EXECUTED WITHOUT ITERATIONS.)

## 2.2 SPECIAL ENVIRONMENTS.

THIS DIAGNOSTIC FOLLOWS THE STANDARD PROCEDURE FOR RUNNING UNDER APT,XXDP MONITORS, AS DESCRIBED IN THEIR RESPECTIVE PROCEDURES MANUAL AND SYSMAC PACKAGE.

## 2.3 OPERATIONAL SWITCH SETTINGS

THE SOFTWARE SWITCH REGISTER (LOC. 176) IS USED FOR ALL OPERATIONAL SWITCH SETTINGS. THIS CAN BE ACCOMPLISHED IN THE FOLLOWING WAY:

1. TYPE CONTROL G <G>: THIS WILL ALLOW THE TTY TO ENTER DATA INTO LOC. 176 AT SELECTED POINTS WITHIN THE PROGRAM.
2. THE MACHINE WILL THEN TYPE: 'SWR=XXXXXX NEW=' (XXXXXX IS THE OCTAL CONTENTS OF THE SOFTWARE SWITCH REGISTER.)
3. AFTER THE 'NEW=' HAS BEEN TYPED THEN THE OPERATOR CAN DO ONE OF THE FOLLOWING AT THE TTY:
  1. TYPE A NUMBER TO BE LOADED INTO LOC. 176 FOLLOWED BY A <CR>. (ONLY NUMBERS BETWEEN 0-7 WILL BE ACCEPTED). LEADING ZEROS NEED NOT BE TYPED. AND IF MORE THAN 6 DIGITS ARE TYPED THE LAST 6 WILL BE USED. IF A <CR> IS THE FIRST KEY DEPRESSED THE SOFTWARE SWITCH REGISTER CONTENTS WILL NOT BE CHANGED.
  2. IF A CONTROL U <U> IS DEPRESSED THEN THE PROGRAM WILL SEND YOU BACK TO STEP 3
  3. IF THE INPUT CHARACTER IS NOT ONE OF THE CHARACTERS MENTIONED ABOVE THEN A QUESTION MARK (?) WILL BE TYPED CARRIAGE RETURN AND A LINE FEED SEQUENCE THEN PROCEED FROM STEP 2 (ERASING ALL PREVIOUS INPUT).
4. THE DIAGNOSTIC WILL CONTINUE ON RUNNING <CR>.



NOTE: BECAUSE OF THE FREQUENT BUS RESETS IN THE PROGRAM, MULTIPLE CONTROL-G'S MAY BE REQ'D. IF NECESSARY, 'BREAK' INTO THE PROGRAM AND LOAD LOCATION 176 (SWREG) BY 'JDT' TO THE DESIRED CONTENTS. DO A 'P' TO PROCEED.

SOFTWARE SWITCH REGISTER OPTIONS (SWREG)

BIT 15 SET = 100000 = HALT ON ERROR  
14 SET = 40000 = LOOP ON TEST (TO BE USED ONLY WHILE TESTING  
IN PROGRESS)  
13 SET = 20000 = INHIBIT ERROR TYPEOUTS  
12 SET = 10000 = ENABLE PERFORMANCE REPORTS  
11 SET = 4000 = INHIBIT ITERATIONS  
10 SET = 2000 = BELL ON ERROR  
9 SET = 1000 = LOOP ON ERROR  
8 SET = 400 = LOOP ON TEST IN SWR<7:0>  
7:0 = NUMBER OF TEST TO LOOP ON (USED WITH BIT 8)  
(ALL TESTS PREVIOUS TO THE SELECTED TEST  
ARE EXECUTED FIRST WITH 1 ITERATION ONLY)


NOTE: IF BIT 14, 9 OR 8 IS SELECTED THE LEDS ON THE MXV11-B MODULE MAY GIVE FALSE TEST NUMBER INDICATIONS. IF A TEST HAS A UNIBUS RESET COMMAND THE LEDS WILL BE FULLY LIGHTED EVERY PASS THROUGH THE RESET INSTRUCTION. THUS, TEST 7 WILL APPEAR AS TEST 17 (ALL LEDS ON) ETC.

2.4 PROGRAM OPTIONS AND DEFAULTS.

THIS PROGRAM REQUIRES THE ADDRESS OF THE FIRST RCSR OF EACH SERIAL LINE UNIT AND ITS INTERRUPT VECTORS TO BE PREVIOUSLY STORED IF NOT DEFAULTED:

	REGISTER -----	LOCATION -----	DEFAULT -----	
CHANNEL 0	BASE0 VECT0	1254 1256	776500 300	RCSR VECTOR
CHANNEL 1	BASE1 VECT1	1260 1262	777560 60	RCSR VECTOR
**SECOND MXV11-B**				
CHANNEL 2	BASE2 VECT2	1264 1266	776510 310	RCSR VECTOR
CHANNEL 3	BASE3 VECT3	1270 1272	776520 320	RCSR VECTOR

LOCATION 'SDEVN' IS USED AS A BIT MAP TO INDICATE WHICH OPTIONS ARE PRESENT AND TO BE TESTED. THE OPERATOR IS PROMPTED ON INITIAL PROGRAM STARTUP. 'SDEVN' CAN BE CHANGED ANY TIME BY TYPING 'CONTROL-G' AND 'CONTROL-C'. THE PROGRAM WILL RE-SIZE AND RESTART AT THE BEGINNING AGAIN.



- BIT 15: 0 = TEST CHANNEL 0 = DEFAULT  
1 = BYPASS CHANNEL 0 TEST = 100000
- BIT 13: 0 = TEST 1 MXV11B MODULE = DEFAULT  
1 = TEST 2 MXV11B MODULES = 020000
- BIT 12: 0 = CPU HAS MEMORY MANAGEMENT = DEFAULT  
1 = CPU HAS NO MEM MNGT (LSI/2) = 10000
- BIT 11: 0 = BREAK DETECTION DISABLED = DEFAULT  
1 = BREAK DETECTION ENABLED = 4000  
NOTE: BREAK DETECTION IS TESTED ON CHANNEL 0 ONLY
- BIT 10: 0 = DO DATA WRAP AROUND TESTS = DEFAULT  
1 = BYPASS DATA WRAP TESTS = 2000
- BIT 9: 0 = DO DATA WRAP EXTERNAL TESTS = DEFAULT  
1 = DO DATA WRAP INTERNAL TESTS = 1000  
NOTE: THIS BIT SELECTION IS ONLY USED IF DATA WRAP HAS ALREADY BEEN SELECTED VIA BIT 10 OR 3.
- BIT 8: 0 = BYPASS CHANNEL 1 TEST = DEFAULT  
1 = TEST CHANNEL 1 = 400
- BIT 7: 0 = ENABLE PCR REGISTER TEST = DEFAULT  
1 = BYPASS PCR REGISTER TEST = 200
- BIT 6: 0 = ENABLE LEDS TEST DISPLAY = DEFAULT  
1 = BYPASS USE OF LEDS = 100  
NOTE: THE LED REGISTER IS THE ALSO KNOWN AS THE DDR REGISTER.
- BIT 4: 0 = BREAK DETECTION DISABLED = DEFAULT  
1 = BREAK DETECTION ENABLED = 20  
NOTE: BIT 4 AFFECTS CHANNEL 1 ONLY

BIT 3: 0 = BYPASS DATA WRAP TESTS = DEFAULT  
1 = DO DATA WRAP AROUND TESTS = 10  
NOTE: BIT 3 AFFECTS CHANNEL 1 ONLY

BIT 2: 0 = TEST RAM = DEFAULT  
1 = BYPASS RAM TESTS = 4

BIT 1: 0 = BYPASS ROM TESTING = DEFAULT  
1 = ROM PRESENT (TEST) = 2

BIT 0: 0 = CLOCK OPTION DISABLED = DEFAULT  
1 = CLOCK OPTION ENABLED = 1

**IMPORTANT:**

1. IF RUNNING UNDER APT THE CONSOLE IS ON THE MXV11-B, THE CONSOLE MUST NOT BE TESTED SINCE APT SENDS 'BREAKS' TO THE CONSOLE WHICH INTERFERES WITH THE TESTS.
2. CPU'S WITHOUT MEMORY MANAGEMENT (LSI OR LSI/2) CANNOT TEST ALL OF THE MXV11-B'S MEMORY. THESE SYSTEMS CAN ONLY VERIFY/TEST THE LOWER 32K WORDS (ACTUALLY 32K WORDS MINUS THE I/O PAGE I.E. LOWER 28K). CPU'S WITH MEMORY MANAGEMENT CAN CHECK UP TO TWO MXV11-B MODULES MINUS THE I/O PAGE I.E. 124K WORDS.

SUMMARY OF USER LOCATIONS AND DEFAULTS.

	LOC	DEFAULT	
	-----	-----	
SDEVH	1252	0	DEVICE MAP
SWREG	176	0	SOFTWARE SWITCH REGISTER
BASE0	1254	776500	CHANNEL 0
VECT0	1256	300	CHANNEL 0
BASE1	1260	777560	CHANNEL 1
VECT1	1262	60	CHANNEL 1
LOROM	1274	773000	LOW ROM ADDRESS
HIROM	1276	773776	HIGH ROM ADDRESS (256 WORDS)
LOROM2	1300	765000	2ND LOW ROM ADDRESS
HIROM2	1302	765776	2ND HIGH ROM ADDRESS (256 WORDS)
BASE2	1264	776510	CHANNEL 2
VECT2	1266	310	CHANNEL 2
BASE3	1270	776520	CHANNEL 3
VECT3	1272	320	CHANNEL 3

### 2.5 EXECUTION TIMES.

EXECUTION TIMES FOR AN LSI-11 PROCESSOR WITH THE MXV11-B MODULE AT SHIPMENT CONFIGURATION:

CH. 0 AT 500 BAUD.  
CH. 1 (CONSOLE) AT 9600 BAUD.

	LSI-11	F-11	
ARE: FIRST PASS-	17 SEC	08 SEC	WITH 1 MXV11-B
ADDITIONAL PASSES	45 SEC	23 SEC	WITH 1 MXV11-B

THE TEST TIME IS BAUD RATE DEPENDENT. HIGHER BAUD RATES RESULT IN SHORTER PASS TIMES.

THE RAM TESTS REQUIRE THE ADDITIONAL TIMES SHOWN BELOW FOR ALL PASSES:

	LSI-11	F-11 (64KW)	F-11 (124KW)
1ST PASS	4 SEC	10 SEC	19 SEC
2ND PASS	16 SEC	10 SEC	33 SEC

### 2.6 POWER FAIL

AUTO START FROM POWER FAIL IS IMPLEMENTED IN THIS PROGRAM. UPON POWER UP, THE PROGRAM WILL RESTART FROM THE BEGINNING.

### 3.0 ERROR INFORMATION

#### 3.1 ERROR REPORTING PROCEDURE.

SINCE THIS DIAGNOSTIC WAS DESIGNED TO FIT INTO 16K OF MEMORY THE ERROR TYPEOUT IS VERY BRIEF. THE FORMAT OF THE ERROR TYPEOUT IS AS FOLLOWS:

TEST \_\_,ERROR \_\_,PC=\_\_ ADDRESS=\_\_ VECTOR=\_\_

WHERE ALL VALUES TYPED ARE OCTAL.  
THE ADDRESS AND VECTOR REFER TO THE FAILING CHANNEL.  
FOR FURTHER INFORMATION THE LISTING MUST BE CONSULTED.  
BITS 15,13,10 AND 9 OF THE SWITCH REGISTER (SWREG) CONTROL THE SEQUENCE OF EVENTS AFTER AN ERROR IS CAUGHT.

BIT 15 SET: CAUSES THE PROGRAM TO HALT IN THE ERROR ROUTINE.  
IF THE PROGRAM IS CONTINUED, IT WILL PROCEED FROM WHERE IT HALTED.

BIT 13 SET: DISABLES THE PRINTING OF THE ERROR MESSAGE.

BIT 10 SET: CAUSES THE BELL TO RING ON ERROR.

BIT 9 SET: CAUSES THE DIAGNOSTIC TO LOOP FROM BEGINNING OF TEST TO ERROR.

THE ERROR ROUTINE SUPPORTS THE CONTROL G <G> FUNCTION.  
REFER TO SECTION 2.3 FOR DETAILS.

#### 3.2 ERROR HALTS.

THE ONLY HALT IN THIS DIAGNOSTIC IS IN THE ERROR ROUTINE, AND IS EXECUTED ONLY IF BIT 15 OF THE SWITCH REGISTER (SWREG) IS SET WHEN AN ERROR OCCURS

#### 3.3 ERROR NUMBERS

THE ERROR NUMBERS HAVE BEEN UPDATED TO REFLECT THE TEST THEY ARE CALLED FROM. FOR EXAMPLE:

ERROR 3 = TEST 3, ERROR NUMBER WITHIN THE TEST IS 5

ERROR 237 = TEST 23, ERROR NUMBER WITHIN THE TEST IS 7

NOTE: ALL TESTS CONFORM TO THIS FORMAT EXCEPT TEST 21. THAT TEST NUMBERS ITS TESTS FROM 1 TO 13 (OCTAL).

#### 4.0 PERFORMANCE AND PROGRESS REPORTS.

#### 4.1 PERFORMANCE REPORTS. (BIT 12 SET IN THE SWITCH REGISTER 'SWREG')

AS EACH CHANNEL COMPLETES ONE PASS OF THE DIAGNOSTIC,  
THE FOLLOWING ITEMS ARE TYPED:

'CSR: \_' : THE BASE ADDRESS OF THE LINE UNDER TEST  
'VECTOR: \_' : THE ASSOCIATED VECTOR  
'ERRORS: \_' : THE TOTAL NUMBER OF ERRORS ON THIS DEVICE  
ON THIS PASS.

AFTER ALL MODULES AND CHANNELS TO BE TESTED HAVE BEEN EXERCISED,  
AN END PASS STATEMENT IS TYPED:

'END PASS \_.'

EXAMPLE OF PRINTOUT ASSUMING: SEPERATE CONSOLE DEVICE  
64K RAM  
CLOCK ENABLED  
NO ERRORS

CVMXB4, MXV11B DIAGNOSTIC

SWR= 000000 NEW= 10000<CR>

(ENABLE  
PERFORMANCE  
REPORTS)

DEVM = 000000 NEW = 201<CR>

(8 BITS WORD  
[NO PARITY],  
CLOCK ENABLED.)

64K MEMORY  
CLOCK ENABLED

\*\* PHASE 1 SUMMARY \*\*

CSR: 776500, VECTOR: 000760, ERRORS: 0  
CSR: 777500, VECTOR: 000770, ERRORS: 0

(CHANNEL 0)  
(CHANNEL 1)

\*\* PHASE 2 SUMMARY \*\*

CSR: 776500, VECTOR: 000760, ERRORS: 0

(INTERACTION TESTS  
STARTING  
WITH CH 0)


END PASS 1

NOTE: THE DEVICE MAP 'SDEVM' CAN BE CHANGED AT ANY TIME BY TYPING  
'CONTROL-G' AND 'CONTROL-C'. SEE SEC. 2.4.

THE PROGRAM WILL RE-SIZE AND RESTART AT THE BEGINNING AGAIN.



5.0 DEVICE REGISTERS.



NOTES:

1. RCSR AT BASE ADDRESS (SBASE)  
 RBUF AT SBASE+2  
 TCSR AT SBASE+4  
 TBUF AT SBASE+6
2. BLANK BITS INDICATE UNUSED AND RESERVED  
 BIT POSITIONS. SEE THE LISTING FOR AN  
 EXPLANATION OF THE BITS.
3. ORERR = OVERRUN ERROR  
 FRERR = FRAMING ERROR

6.0 SUMMARY OF TESTS AND SPECIAL SUBROUTINES.

PHASE 1 TESTS

TEST 1 RAM ADDRESS TEST

---- -

THIS TEST WRITES THE ENTIRE FIRST 32K WITH THE ADDRESS OF THE LOCATION. IT THEN CHECKS THE MEMORY TO BE SURE THE WRITE WAS CORRECT. IF AN ERROR OCCURS, AND THE PROGRAM HAS BEEN SET UP TO HALT, THE FAILING ADDRESS IS IN CPU REGISTER 0.

THIS TEST ALSO CHECKS FOR THE PRESENCE OF THE DDR REGISTER. IF THE REGISTER 'READ' CREATES A TIMEOUT AN ERROR WILL BE GENERATED. TEST 1 HAS ERRORS 11-12

TEST 2 RAM DATA VOLITILITY TEST

---- -

WRITE ALL MEMORY TO BACKGROUND OF ALL 1'S.  
TEST LOCATION FOR CORRECT BACKGROUND.  
FLOAT 0'S COMPLEMENT THRU WORD. RESET LOCATION TO BACKGROUND.  
REPEAT ABOVE 3 STEPS FOR EACH LOCATION.  
WHEN ALL LOCATIONS TESTED, CHECK ENTIRE MEMORY FOR BACKGROUND PATTERN.  
REPEAT ALL THE ABOVE FOR BACKGROUND PATTERN OF ALL 0'S FLOATING 1'S.  
THIS TEST USES THE MEMORY MANAGEMENT OPTION. IF A FAILURE OCCURS EXAMINE CPU REGISTER R2. THIS REGISTER WILL CONTAIN THE FAILING 4K (OCTAL) PAGE NUMBER.  
TEST 2 HAS ERRORS 21-24

TEST 3 ROM TESTS

---- -

THIS IS A TWO PART TEST. THE FIRST PART CHECKS ADDRESS X73000-X73776 FOR PRESENCE.  
THE SECOND PART CHECKS X65000-X65776 FOR PRESENCE.

THIS TEST ALSO CHECKS FOR THE PRESENCE, IF SDEVN SELECTED, OF THE PCR REGISTER. IF THE REGISTER IS PRESENT THEN IT CHECKS FOR AN ALL ONES WRITE TO THE REGISTER. IT THEN FLOATS A ONE THROUGH A FIELD OF ZEROS.  
TEST 3 HAS ERRORS 31-37

TEST 4 CLOCK TESTS

---- -

THE CLOCK TEST, IF SELECTED VIA THE SDEVN, SIMPLY ENABLES THE CLOCK AND CHECKS FOR AN INTERRUPT.  
TEST 4 HAS ERRORS 41 AND 42

TEST 5 ADDRESSABILITY

---- -

THIS TEST VERIFIES THAT ALL 8 REGISTERS OF THE CHANNEL

UNDER TEST RESPOND TO THEIR ADDRESSES.  
TEST 5 HAS ERRORS 51-55

THE FOLLOWING 3 TESTS TEST ALL 'READ WRITE' BITS

TEST 6 BREAK - TCSR 0 SET, CLEAR,  
---- -

TEST 6 HAS ERRORS 61-64

TEST 7 XMITIE - TCSR 6 SET, CLEAR,  
---- -

TEST 7 HAS ERRORS 71-74

TEST 10 RCVRIE - RCSR 6 SET, CLEAR,  
---- --

TEST 10 HAS ERRORS 101-105

TEST 11 XMIT RDY - TCSR 7 - CLEARS WHEN TBUF IS LOADED  
---- -- WITH A CHARACTER AND THAT IT SETS WITHIN A  
REASONABLE AMOUNT OF TIME.

TEST 11 HAS ERRORS 111-113

TEST 12 OUTPUTTING A CHAR FROM TBUF (WITH WRAP AROUND CONNECTED)  
---- -- RESULTS IN RCVRDONE SETTING WITHIN A  
REASONABLE AMOUNT OF TIME.

TEST 12 HAS ERRORS 121-122

TEST 3 RCVRDONE IS CLEARED BY READING RBUF  
---- --

TEST 13 HAS ERRORS 131 AND 132

TEST 14 OVERRUN ERROR BIT - RBUF 14  
---- --

TEST 14 HAS ERRORS 141-147

TEST 15 TRANSMITTER INTERRUPT LOGIC TEST  
---- --

LOGICALLY THIS IS 4 SEPARATE TESTS

A) DOES TRANSMITTER INTERRUPT LOGIC WORK  
B) AT PRIORITY OF 0  
C) AND ONLY ONCE  
D) BUT NOT WITH INTERRUPT ENABLE CLEAR  
TEST 15 HAS ERRORS 151-154

TEST 16 RECEIVER INTERRUPT LOGIC TEST THIS TEST COVERS ALL  
---- -- OF THE RECEIVER SIDE OF THE INTERRUPT LOGIC IN  
CHARACTER MODE.  
TEST 16 HAS ERRORS 161-164

TEST 17 TEST DATA WRAP AROUND BINARY COUNT: FLAG MODE.  
---- --

TEST 17 HAS ERRORS 171-176

TEST 20 TEST DATA WRAP AROUND BINARY COUNT: INTERRUPT MODE.  
---- --

TEST 20 HAS ERRORS 201-205

TEST 21 TEST BREAK LOGIC: TRANSMIT KNOWN CHAR  
---- --

- A) TRANSMIT KNOWN CHAR WITH BREAK SET  
AND COMPARE RECEIVED WITH 0
- B) TEST FOR FRAMING ERROR ON BREAK
- C) IF PARITY IS ENABLED AND ODD PARITY IS SELECTED,  
CHECK TO BE SURE PARITY ERROR WAS GENERATED
- D) IF PARITY IS ENABLED AND EVEN PARITY IS SELECTED,  
CHECK TO BE SURE NO PARITY ERROR OCCURRED

TEST 21 HAS ERRORS 1-13

TEST 22 NOT A TEST - SEND BACK TO LOOP

\*\*\*\*\* PHASE 2 TESTS \*\*\*\*\*

TEST 23 TEST THAT CHANNELS INTERRUPT AT ASSIGNED PRIORITY  
---- --

TEST 23 HAS ERRORS 231-237

TEST 24 TEST DATA TRANSFERS WITH ALL ACTIVE LINES INTERRUPTING.  
---- --

TEST 24 HAS ERRORS 241-245

TEST 25 TEST THAT CHANNELS INTERRUPT AT ASSIGNED PRIORITY  
---- --

THIS TEST IS EXECUTED ONLY ON THE SECOND MXV11-B MODULE.  
CHANNELS 2 AND 3. ANY FAILURE IS RELATED TO THE SECOND  
MXV11-B BOARD.  
TEST 25 HAS ERRORS 251-256

TEST 26 TEST DATA TRANSFERS WITH ALL ACTIVE LINES INTERRUPTING.  
---- --

THIS TEST IS EXECUTED ONLY ON THE SECOND MXV11-B MODULE.  
CHANNELS 2 AND 3. ANY FAILURE IS RELATED TO THE SECOND  
MXV11-B BOARD.  
TEST 26 HAS ERRORS 261-264

.REM 2

IDENTIFICATION

PRODUCT CODE: AC-T551A-MC  
 PRODUCT NAME: CVMXBAO MXV11B DIAG  
 PRODUCT DATE: FEBRUARY 1983  
 MAINTAINER: E.S.D. METHODS

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1982,1983 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL	PDP	UNIBUS	MASSBUS
DEC	DECUS	DECTAPE	

TABLE OF CONTENTS

1.0	GENERAL PROGRAM INFORMATION.
1.1	PROGRAM PURPOSE (ABSTRACT).
1.2	SYSTEM REQUIREMENTS.
1.3	RELATED DOCUMENTS AND STANDARDS.
1.4	DIAGNOSTIC HIERARCHY PREREQUISITES.
1.5	ASSUMPTIONS.
1.6	VT-100 CONSOLE SETUP.
2.0	OPERATING INSTRUCTIONS.
2.1	LOADING AND STARTING PROCEDURES.
2.2	SPECIAL ENVIRONMENTS.
2.3	OPERATIONAL SWITCH SETTINGS
2.4	PROGRAM OPTIONS & DEFAULTS.
2.5	EXECUTION TIMES.
2.6	POWER FAIL.

- 3.0 ERROR INFORMATION.
  - 3.1 ERROR REPORTING PROCEDURE.
  - 3.2 ERROR HALTS.
  - 3.3 ERROR NUMBERS
  
- 4.0 PERFORMANCE AND PROGRESS REPORTS.
  - 4.1 PERFORMANCE REPORTS.
  
- 5.0 DEVICE INFORMATION TABLES.
  
- 6.0 SUMMARY OF TESTS.

**1.0 GENERAL PROGRAM INFORMATION.**  
-----**1.1 PROGRAM PURPOSE (ABSTRACT).**

THIS DIAGNOSTIC IS A LOGIC TEST TO VERIFY THE OPERATION OF THE 2 SERIAL LINE UNITS, ROM & CLOCK OPTIONS, THE PCR REGISTER, THE DDR REGISTER & RAM ON THE MXV11-B.

THE PROGRAM WILL TEST TO MAKE SURE (EVERY OPTION) THE DEVICE MAP (SDEV) IS SET TO 10. SEE PROGRAM OPTIONS & DEFAULTS SEC 2.4 .  
THE PROGRAM WILL PRINT THE CONTENTS OF SDEV FOR OPERATOR VERIFICATION & A SUMMARY OF SIGNIFICANT DIFFERENCES FROM THE DEFAULT CONDITIONS  
I.E: CHANNEL(S) DROPPED FROM TESTING, CHANNEL 1 AS CONSOLE, ROM/RAM TESTING BYPASSED & CLOCK ENABLED.

SERIAL LINE UNIT TESTING IS DONE IN TWO DISTINCT PHASES:

1. EACH OF THE 2 CHANNELS OF THE MXV11-B IS TESTED INDIVIDUALLY.
2. THE MXV11-B MODULE IS TESTED AS A WHOLE FOR CHANNEL INTERACTION PROBLEMS. THIS DIAGNOSTIC IS DESIGNED TO TEST AND DETECT ERRORS TO THE LOGIC LEVEL & NOT THE CHIP LEVEL.

THE OPERATOR MUST INSTALL DATA WRAP AROUND CONNECTORS TO DO DATA TESTING. TO BYPASS DATA TESTS, THE OPERATOR MUST MODIFY SDEV. SEE PROGRAM OPTIONS SEC. 2.4

THE ADDRESSES & VECTOR RANGES ARE AS FOLLOWS:

CHANNEL 0: 776500 THRU 777570  
CHANNEL 1: 776510 THRU 777600  
          777560 ( AS CONSOLE )  
VECTORS : 4 THRU 376  
PCR :777520 DDR :777524 LTC :777546

THE DEFAULT ADDRESSES & VECTORS ARE AS FOLLOWS:

CHANNEL 0: 776500 THRU 776506 VECTORS: 300/304  
CHANNEL 1: 777560 THRU 777566 VECTORS: 60/64

FOR ANY OTHER DEVICE ADDRESSES THE OPERATOR MUST CHANGE THE DEFAULT LOCATIONS. SEE PROGRAM OPTIONS & DEFAULTS SEC. 2.4 .

THIS PROGRAM IS DESIGNED TO RUN ON ANY Q-BUS/Q22 PDP-11 WITH 64K OF MEMORY AND AN MXV11-B (Q-BUS/Q22) MODULE. IT CAN RUN UNDER XXDP & APT MONITORS, AND ON PROCESSORS WITH NO HARDWARE SWITCH REGISTER.



## 1.2 SYSTEM REQUIREMENTS.

### HARDWARE REQUIREMENTS:

KDF11 PROCESSOR  
64K MEMORY - MINIMUM (CONTAINED ON THE MXV11-B)  
A SPECIAL DATA WRAP AROUND CONNECTOR (PN # H3270-A) OR EQUIVALENT  
(REQ'D IF EXTERNAL DATA WRAP AROUND TESTS DESIRED)

IF CHAN. 1 IS THE CONSOLE, TESTS 11-14, 16-21, 23-24 ARE BYPASSED.  
(BYPASS IS FOR CHANNEL 1 ONLY)

IF DATA WRAP AROUND TESTS ARE BYPASSED, TESTS 12-14, 16-21, 23-24 ARE BYPASSED.

### SOFTWARE REQUIREMENTS:

THIS DIAGNOSTIC CAN RUN IN THE FOLLOWING WAYS:

STAND ALONE  
WITH APT MONITOR  
WITH XXDP+ MONITOR (CHAINABLE IF RENAMED TO .BIC EXTENSION)

THIS DIAGNOSTIC IS NOT DESIGNED TO RUN WITH THE DIAGNOSTIC SUPERVISOR.

## 1.3 RELATED DOCUMENTS AND STANDARDS.

DIAGNOSTIC ENGINEERING STANDARDS AND CONVENTIONS	175-003-009-02
APT	MD-11-DZZMA
SYSMAC	MD-11-DZQAC

## 1.4 DIAGNOSTIC HIERARCHY PREREQUISITES.

NO SPECIAL DIAGNOSTICS ARE REQUIRED TO RUN BEFORE THIS, BUT THE PROCESSOR, MEMORY, AND BUS ARE ASSUMED TO BE FULLY OPERATIONAL.

## 1.5 ASSUMPTIONS.

THE OPERATOR MUST:

1. SET THE SOFTWARE SWITCH REGISTER (SWR) IF NOT DEFAULTED. (SEC. 2.3)
2. SET THE DEVICE MAP (SDEVN) IF NOT DEFAULTED. (SEC. 2.4)
3. SET THE SERIAL LINE ADDRESSES & VECTORS IF NOT DEFAULTED. (SEC 2.4)
4. SET THE ROM HI & LO ADDR IF NOT DEFAULTED. (SEC 2.4)
5. SET BIT 15 (SDEVN) IF CHANNELS ON A SECOND MXV11-B ARE TO BE TESTED.

## 1.6 VT-100 CONSOLE SETUP.

IF CHANNEL 1 IS CONFIGURED AS THE CONSOLE & THE VT-100 IS THE CONSOLE DEVICE, "SETUP B" MUST BE SET IN FOR THE FOLLOWING.

- A. DISABLE XON/XOFF
- B. JUMP SCROLL ON
- C. NEW LINE OFF
- D. ALL OTHER OPTIONS PER SYSTEM REQUIREMENTS.

2.0 OPERATING INSTRUCTIONS.  
-----

2.1 LOADING AND STARTING PROCEDURES.

USE STANDARD PROCEDURE FOR PDP-11 ABSOLUTE BINARY FORMATTED MEDIA.

ALL NORMAL STARTS & RESTARTS ARE FROM LOCATION 200.

THERE ARE 2 STARTING ADDRESSES TO BE USED OFF LINE ONLY FOR INTERRUPT VECTOR TROUBLE SHOOTING:

1334 START: LOADS ADDRESSES 0 TO 1000 WITH THE ADDRESS OF AN INTERRUPT ROUTINE THAT JUST DOES RTI'S ALLOWING LOOPING IN THAT PART OF THE TEST WHERE INTERRUPT VECTOR PROBLEMS ARE OCCURRING.  
NORMAL TESTING WILL THEN BEGIN.

1356 START: LOADS ADDRESSES 0 TO 1000 WITH TRAP CATCHER CODE. ANY INTERRUPT TO THIS REGION WILL HALT.  
NORMAL TESTING WILL THEN BEGIN.

AS SOON AS TESTING STARTS, THE OPERATOR CAN CHANGE THE SWITCH REGISTER ONLY BY A 'BREAK' & MANUALLY LOADING LOCATION 176 (SWREG) WITH THE DESIRED CONTENTS (SEE SEC. 2.3) THEN DOING A 'P' TO PROCEED.

THE USFR CAN SELECT A SPECIFIC TEST TO BE EXECUTED BY SETTING BIT 8 IN SWREG AND THE TEST NUMBER (IN OCTAL) IN BITS <7:0>.

(NOTE: ALL TESTS PREVIOUS TO THE SELECTED ONE ARE EXECUTED WITHOUT ITERATIONS.)

2.2 SPECIAL ENVIRONMENTS.

THIS DIAGNOSTIC FOLLOWS THE STANDARD PROCEDURE FOR RUNNING UNDER APT,XXDP+ MONITORS, AS DESCRIBED IN THEIR RESPECTIVE PROCEDURES MANUAL AND SYSMAC PACKAGE.

2.3 OPERATIONAL SWITCH SETTINGS

THE SOFTWARE SWITCH REGISTER (LOC. 176) IS USED FOR ALL OPERATIONAL SWITCH SETTINGS.  
THIS CAN BE ACCOMPLISHED IN THE FOLLOWING WAY:

- 1) TYPE CONTROL G <^G>; THIS WILL ALLOW THE TTY TO ENTER DATA INTO LOC. 176 AT SELECTED POINTS WITHIN THE PROGRAM.
- 2) THE MACHINE WILL THEN TYPE: 'SWR=XXXXXX NEW=' (XXXXXX IS THE OCTAL CONTENTS OF THE SOFTWARE SWITCH REGISTER.)
- 3) AFTER THE 'NEW=' HAS BEEN TYPED THEN THE OPERATOR CAN DO ONE OF THE FOLLOWING AT THE TTY:
  - A) TYPE A NUMBER TO BE LOADED INTO LOC. 176 FOLLOWED BY A <CR>. (ONLY OCTAL NUMBERS BETWEEN 0-7 WILL BE ACCEPTED). LEADING ZEROS NEED NOT BE TYPED, AND IF MORE THAN 6 DIGITS ARE TYPED THE LAST 6 WILL BE USED. IF A <CR> IS THE FIRST KEY DEPRESSED THE SOFTWARE SWITCH REGISTER CONTENTS WILL NOT BE CHANGED.
  - B) IF A CONTROL U <^U> IS DEPRESSED THEN THE PROGRAM WILL SEND YOU BACK TO STEP 3.
  - C) IF THE INPUT CHARACTER IS NOT ONE OF THE CHARACTERS MENTIONED ABOVE THEN A QUESTION MARK (?) WILL BE TYPED FOLLOWED BY A CARRAGE RETURN AND A LINE FEED SEQUENCE THEN PROCEED FROM STEP 2 (ERASING ALL PREVIOUS INPUT).
- 4) THE DIAGNOSTIC WILL CONTINUE ON RUNNING <CR>.

NOTE: BECAUSE OF THE FREQUENT BUS RESETS IN THE PROGRAM, MULTIPLE CONTROL-G'S MAY BE REQ'D. IF NECESSARY, 'BREAK' INTO THE PROGRAM & LOAD LOCATION 176 (SWREG) BY 'ODT' TO THE DESIRED CONTENTS. DO A 'P' TO PROCEED.

SOFTWARE SWITCH REGISTER OPTIONS (SWREG)

- 
- BIT 15 SET = 100000 = HALT ON ERROR
  - 14 SET = 40000 = LOOP ON TEST (TO BE USED ONLY WHILE TESTING IN PROGRESS)
  - 13 SET = 20000 = INHIBIT ERROR TIMEOUTS
  - 12 SET = 10000 = ENABLE PERFORMANCE REPORTS
  - 11 SET = 4000 = INHIBIT ITERATIONS
  - 10 SET = 2000 = BELL ON ERROR
  - 9 SET = 1000 = LOOP ON ERROR
  - 8 SET = 400 = LOOP ON TEST IN SWR<7:0>
  - 7:0 = NUMBER OF TEST TO LOOP ON (USED WITH BIT 8)  
(ALL TESTS PREVIOUS TO THE SELECTED TEST ARE EXECUTED FIRST WITH 1 ITERATION ONLY)

NOTE: IF BIT 14, 9 OR 8 IS SELECTED THE LEDS ON THE MXV11-B MODULE MAY GIVE FALSE TEST NUMBER INDICATIONS. IF A TEST HAS A JMBUS RESET COMMAND THE LEDS WILL BE FULLY LIGHTED EVERY PASS THROUGH THE RESET INSTRUCTION. THUS, TEST 7 WILL APPEAR AS TEST 17 (ALL LEDS ON) ETC.


2.4 PROGRAM OPTIONS & DEFAULTS.

THIS PROGRAM REQUIRES THE ADDRESS OF THE FIRST RCSR OF EACH SERIAL LINE UNIT & ITS INTERRUPT VECTORS TO BE PREVIOUSLY STORED IF NOT DEFAULTED:

	REGISTER	LOCATION	DEFAULT	
CHANNEL 0	BASE0	1254	776500	RCSR
	VECT0	1256	300	VECTOR
CHANNEL 1	BASE1	1260	777560	PCSR
	VECT1	1262	60	VECTOR
SECOND MXV11-B				
CHANNEL 2	BASE2	1264	776510	RCSR
	VECT2	1266	310	VECTOR
CHANNEL 3	BASE3	1270	776520	RCSR
	VECT3	1272	320	VECTOR

LOCATION 'SDEVN' IS USED AS A BIT MAP TO INDICATE WHICH OPTIONS ARE PRESENT AND TO BE TESTED. THE OPERATOR IS PROMPTED ON INITIAL PROGRAM STARTUP. 'SDEVN' CAN BE CHANGED ANY TIME BY TYPING 'CONTROL-G' AND 'CONTROL-C'. THE PROGRAM WILL RE-SIZE & RESTART AT THE BEGINNING AGAIN.

SDEVN DEFAULT = 000000



- BIT 15: 0 = TEST CHANNEL 0 = DEFAULT  
1 = BYPASS CHANNEL 0 TEST = 100000
- BIT 13: 0 = TEST 1 MXV11B MODULE = DEFAULT  
1 = TEST 2 MXV11B MODULES = 020000
- BIT 12: 0 = CPU HAS MEMORY MANAGEMENT = DEFAULT  
1 = CPU HAS NO MEM MGMT (LS:1/2) = 10000
- BIT 11: 0 = BREAK DETECTION DISABLED = DEFAULT  
1 = BREAK DETECTION ENABLED = 4000  
NOTE: BREAK DETECTION IS TESTED ON CHANNEL 0 ONLY
- BIT 10: 0 = DO DATA WRAP AROUND TESTS = DEFAULT  
1 = BYPASS DATA WRAP TESTS = 2000  
NOTE: THIS BIT CONTROLS DATA WRAP ON CHANNEL 0 AND 2/3 IF SELECTED.

BIT 9: 0 = DO DATA WRAP EXTERNAL TESTS = DEFAULT  
 1 = DO DATA WRAP INTERNAL TESTS = 1000  
 NOTE: THIS BIT SELECTION IS ONLY USED IF DATA WRAP HAS ALREADY BEEN SELECTED VIA BIT 10 OR 3.

BIT 8: 0 = BYPASS CHANNEL 1 TEST = DEFAULT  
 1 = TEST CHANNEL 1 = 400

BIT 7: 0 = ENABLE PCR REGISTER TEST = DEFAULT  
 1 = BYPASS PCR REGISTER TEST = 200

BIT 6: 0 = ENABLE LEDS TEST # DISPLAY = DEFAULT  
 1 = BYPASS USE OF LEDS = 100  
 NOTE: THE LED REGISTER IS THE ALSO KNOWN AS THE DDR REGISTER.

BIT 4: 0 = BREAK DETECTION DISABLED = DEFAULT  
 1 = BREAK DETECTION ENABLED = 20  
 NOTE: BIT 4 AFFECTS CHANNEL 1 ONLY

BIT 3: 0 = BYPASS DATA WRAP TESTS = DEFAULT  
 1 = DO DATA WRAP AROUND TESTS = 10  
 NOTE: BIT 3 AFFECTS CHANNEL 1 ONLY

BIT 2: 0 = TEST RAM = DEFAULT  
 1 = BYPASS RAM TESTS = 4

BIT 1: 0 = BYPASS ROM TESTING = DEFAULT  
 1 = ROM PRESENT (TEST) = 2

BIT 0: 0 = CLOCK OPTION DISABLED = DEFAULT  
 1 = CLOCK OPTION ENABLED = 1

**IMPORTANT:**

1. IF RUNNING UNDER APT & THE CONSOLE IS ON THE MXV11-B, THE CONSOLE MUST NOT BE TESTED SINCE APT SENDS 'BREAKS' TO THE CONSOLE WHICH INTERFERES WITH THE TESTS.
2. CPU'S WITHOUT MEMORY MANAGEMENT (LSI OR LSI/2) CANNOT TEST ALL OF THE MXV11-B'S MEMORY. THESE SYSTEMS CAN ONLY VERIFY/TEST THE LOWER 32K WORDS (ACTUALLY 32K WORDS MINUS THE I/O PAGE I.E. LOWER 28K). CPU'S WITH MEMORY MANAGEMENT CAN CHECK UP TO TWO MXV11-B MODULES MINUS THE I/O PAGE I.E. 124K WORDS.

**SUMMARY OF USER LOCATIONS & DEFAULTS.**

	LOC	DEFAULT	
SDEVN	1252	0	DEVICE MAP SOFTWARE SWITCH REGISTER
SWREG	176	0	
BASE0	1254	776500	CHANNEL 0 CHANNEL 0
VECTO	1256	300	

BASE1	1260	777560	CHANNEL 1
VECT1	1262	60	CHANNEL 1
LOROM	1274	773000	LOW ROM ADDRESS
HIROM	1276	773776	HIGH ROM ADDRESS (256 WORDS)
LOROM2	1300	765000	2ND LOW ROM ADDRESS
HIROM2	1302	765776	2ND HIGH ROM ADDRESS (256 WORDS)
BASE2	1264	776510	CHANNEL 2
VECT2	1266	310	CHANNEL 2
BASE3	1270	776520	CHANNEL 3
VECT3	1272	320	CHANNEL 3

2.5 EXECUTION TIMES.

EXELUTION TIMES FOR AN LSI-11 PROCESSOR WITH THE MXV11-B MODULE AT SHIPMENT CONFIGURATION:

CH. 0 AT 300 BAUD.  
 CH. 1 (CONSOLE) AT 9600 BAUD.

	LSI-11	F-11	
	-----	----	
ARE: FIRST PASS-	17 SEC	08 SEC	WITH 1 MXV11-B
ADDITIONAL PASSES	45 SEC	23 SEC	WITH 1 MXV11-B

THE TEST TIME IS BAUD RATE DEPENDENT; HIGHER BAUD RATES RESULT IN SHORTER PASS TIMES.

THE RAM TESTS REQUIRE THE ADDITIONAL TIMES SHOWN BELOW FOR ALL PASSES:

	LSI-11	F-11 (64KW)	F-11 (124KW)
	-----	-----	-----
1ST PASS	4 SEC	10 SEC	19 SEC
2ND PASS	16 SEC	10 SEC	33 SEC

2.6 POWER FAIL.

AUTO START FROM POWER FAIL IS IMPLEMENTED IN THIS PROGRAM. UPON POWER UP, THE PROGRAM WILL RESTART FROM THE BEGINNING.

### 3.0 ERROR INFORMATION.

-----

#### 3.1 ERROR REPORTING PROCEDURE.

-----

SINCE THIS DIAGNOSTIC WAS DESIGNED TO FIT IN 16K OF MEMORY THE ERROR TYPEOUT IS VERY BRIEF. THE FORMAT OF THE ERROR TYPEOUT IS AS FOLLOWS:

TEST#\_\_\_\_,ERROR#\_\_\_\_,PC=\_\_\_\_,ADDRESS=\_\_\_\_,VECTOR=\_\_\_\_

WHERE ALL VALUES TYPED ARE OCTAL.  
THE ADDRESS AND VECTOR REFER TO THE FAILING CHANNEL.  
FOR FURTHER INFORMATION THE LISTING MUST BE CONSULTED.  
BITS 15,13,10 AND 9 OF THE SWITCH REGISTER (SWREG) CONTROL THE SEQUENCE OF EVENTS AFTER AN ERROR IS CAUGHT.

BIT 15 SET: CAUSES THE PROGRAM TO HALT IN THE ERROR ROUTINE.  
IF THE PROGRAM IS CONTINUED, IT WILL PROCEED FROM WHERE IT HALTED.

BIT 13 SET: DISABLES THE PRINTING OF THE ERROR MESSAGE.

BIT 10 SET: CAUSES THE BELL TO RING ON ERROR.

BIT 9 SET: CAUSES THE DIAGNOSTIC TO LOOP FROM BEGINNING OF TEST TO ERROR.

THE ERROR ROUTINE SUPPORTS THE CONTROL G <^G> FUNCTION.  
REFER TO SECTION 2.3 FOR DETAILS.

#### 3.2 ERROR HALTS.

-----

THE ONLY HALT IN THIS DIAGNOSTIC IS IN THE ERROR ROUTINE, AND IS EXECUTED ONLY IF BIT 15 OF THE SWITCH REGISTER (SWREG) IS SET WHEN AN ERROR OCCURS.

#### 3.3 ERROR NUMBERS

-----

THE ERROR NUMBER HAVE BEEN UP DATED TO REFLECT THE TEST THEY ARE CALLED FROM. FOR EXAMPLE:

ERROR # 35 = TEST 3, ERROR NUMBER WITHIN THE TEST IS 5

ERROR # 237 = TEST 23, ERROR NUMBER WITHIN THE TEST IS 7

NOTE: ALL TEST CONFORM TO THIS FORMAT EXCEPT TEST 21. THAT TEST NUMBERS ITS TESTS FROM 1 TO 13 (OCTAL).



4.0 PERFORMANCE AND PROGRESS REPORTS.  
-----

4.1 PERFORMANCE REPORTS. (BIT 12 SET IN THE SWITCH REGISTER 'SWREG')

AS EACH CHANNEL COMPLETES ONE PASS OF THE DIAGNOSTIC,  
THE FOLLOWING ITEMS ARE TYPED:

'CSR:-----' : THE BASE ADDRESS OF THE LINE UNDER TEST  
'VECTOR:---' : THE ASSOCIATED VECTOR  
'ERRORS:--' : THE TOTAL NUMBER OF ERRORS ON THIS DEVICE  
ON THIS PASS.

AFTER ALL MODULES & CHANNELS TO BE TESTED HAVE BEEN EXERCISED,  
AN END PASS STATEMENT IS TYPED:

'END PASS#-----.'

EXAMPLE OF PRINTOUT ASSUMING: SEPERATE CONSOLE DEVICE  
64K RAM  
CLOCK ENABLED  
NO ERRORS

CVHXBAO MXV11B DIAGNOSTIC

SWR= 000000 NEW= 10000<CR>

(ENABLE PERFORMANCE REPORTS)

DEVM = 000000 NEW = 201<CR>

(CH.1 = 8 BITS/WORD (NO PARITY), CLOCK ENABLED)

64K MEMORY  
CLOCK ENABLED

\*\* PHASE 1 SUMMARY \*\*

CSR: 776500, VECTOR: 000760, ERRORS: 0  
CSR: 777500, VECTOR: 000770, ERRORS: 0

(CHANNEL 0)  
(CHANNEL 1)

\*\* PHASE 2 SUMMARY \*\*


CSR: 776500, VECTOR: 000760, ERRORS: 0

(INTERACTION TESTS STARTING  
WITH CH 0)

END PASS # 1

NOTE: THE DEVICE MAP 'SDEVN' CAN BE CHANGED AT ANY TIME BY TYPING  
'CONTROL-G' & 'CONTROL-C'. SEE SEC. 2.4.  
THE PROGRAM WILL RE-SIZE & RESTART AT THE BEGINNING AGAIN.

5.0 DEVICE REGISTERS.



NOTES:

1. RCSR AT BASE ADDRESS (SBASE)  
RBUF AT SBASE+2  
TCSR AT SBASE+4  
TBUF AT SBASE+6
2. BLANK BITS INDICATE UNUSED AND RESERVED BIT POSITIONS. SEE THE LISTING FOR AN EXPLANATION OF THE BITS.
3. ORERR = OVERRUN ERROR  
FRERR = FRAMING ERROR

6.0 SUMMARY OF TESTS AND SPECIAL SUBROUTINES.  
-----

PHASE 1 TESTS

TEST 1 RAM ADDRESS TEST  
-----

THIS TEST WRITES THE ENTIRE FIRST 32K WITH THE ADDRESS OF THE LOCATION. IT THEN CHECKS THE MEMORY TO BE SURE THE WRITE WAS CORRECT. IF AN ERROR OCCURS, AND THE PROGRAM HAS BEEN SET UP TO HALT, THE FAILING ADDRESS IS IN CPU REGISTER 0.

THIS TEST ALSO CHECKS FOR THE PRESENCE OF THE DDR REGISTER. IF THE REGISTER 'READ' CREATES A TIMEOUT AN ERROR WILL BE GENERATED. TEST 1 HAS ERRORS 11 THROUGH 12

TEST 2 RAM DATA & VOLITILITY TEST  
-----

WRITE ALL MEMORY TO BACKGROUND OF ALL 1'S.  
TEST LOCATION FOR CORRECT BACKGROUND.  
FLOAT 0'S & COMPLEMENT THRU WORD. RESET LOCATION TO BACKGROUND.  
REPEAT ABOVE 3 STEPS FOR EACH LOCATION.  
WHEN ALL LOCATIONS TESTED, CHECK ENTIRE MEMORY FOR BACKGROUND PATTERN.  
REPEAT ALL THE ABOVE FOR BACKGROUND PATTERN OF ALL 0'S & FLOATING 1'S.  
THIS TEST USES THE MEMORY MANAGEMENT OPTION. IF A FAILURE OCCURS EXAMINE CPU REGISTER R2. THIS REGISTER WILL CONTAIN THE FAILING 4K (OCTAL) PAGE NUMBER.  
TEST 2 HAS ERRORS 21 THROUGH 24

TEST 3 ROM TESTS  
-----

THIS IS A TWO PART TEST. THE FIRST PART CHECKS ADDRESS X730C0-X73776 FOR PRESENCE. THE SECOND PART CHECKS X65000-X65776 FOR PRESENCE.

THIS TEST ALSO CHECKS FOR THE PRESENCE, IF SDEVN SELECTED, OF THE PCR REGISTER. IF THE REGISTER IS PRESENT THEN IT CHECKS FOR AN ALL ONES WRITE TO THE REGISTER. IT THEN FLOATS A ONE THROUGH A FIELD OF ZEROS.  
TEST 3 HAS ERRORS 31 THROUGH 37

TEST 4 CLOCK TESTS  
-----

THE CLOCK TEST, IF SELECTED VIA THE SDEVN, SIMPLY ENABLES THE CLOCK AND CHECKS FOR AN INTERRUPT.  
TEST 4 HAS ERRORS 41 THROUGH 42

TEST 5 ADDRESSABILITY  
-----

THIS TEST VERIFIES THAT ALL 8 REGISTERS OF THE CHANNEL UNDER TEST RESPOND TO THEIR ADDRESSES.  
TEST 5 HAS ERRORS 51 THROUGH 55

THE FOLLOWING 3 TESTS TEST ALL 'READ WRITE' BITS

TEST 6 BREAK - TCSR 0 SET, CLEAR

---- -

TEST 6 HAS ERRORS 61 THROUGH 64

TEST 7 XMITIE - TCSR 6 SET, CLEAR

---- -

TEST 7 HAS ERRORS 71 THROUGH 74

TEST 10 RCVRIE - RCSR 6 SET, CLEAR

---- --

TEST 10 HAS ERRORS 101 THROUGH 105

TEST 11 XMIT RDY - TCSR 7 - CLEARS WHEN TBUF IS LOADED  
---- -- WITH A CHARACTER AND THAT IT SETS WITHIN A  
REASONABLE AMOUNT OF TIME.

TEST 11 HAS ERRORS 111 THROUGH 113

TEST 12 OUTPUTTING A CHAR FROM TBUF (WITH WRAP AROUND CONNECTED)  
---- -- RESULTS IN RCVRDONE SETTING WITHIN A  
REASONABLE AMOUNT OF TIME.

TEST 12 HAS ERRORS 121 THROUGH 122

TEST 13 RCVRDONE IS CLEARED BY READING RBUF

---- --

TEST 13 HAS ERRORS 131 THROUGH 132

TEST 14 OVERRUN & ERROR BIT - RBUF 14

---- --

TEST 14 HAS ERRORS 141 THROUGH 147

TEST 15 TRANSMITTER INTERRUPT LOGIC TEST

---- --

LOGICALLY THIS IS 4 SEPARATE TESTS  
A) DOES TRANSMITTER INTERRUPT LOGIC WORK  
B) AT PRIORITY OF 6  
C) AND ONLY ONCE  
D) BUT NOT WITH INTERRUPT ENABLE CLEAR

TEST 15 HAS ERRORS 151 THROUGH 154

TEST 16 RECEIVER INTERRUPT LOGIC TEST THIS TEST COVERS ALL  
---- -- OF THE RECEIVER SIDE OF THE INTERRUPT LOGIC IN  
CHARACTER MODE.

TEST 16 HAS ERRORS 161 THROUGH 164

TEST 17 TEST DATA WRAP AROUND BINARY COUNT: FLAG MODE.  
---- --

FLAG MODE DENOTES THAT THE PROGRAM IS WAITING (CHECKING) FOR THE DONE BIT TO BE SET IN THE CSR REGISTER. THUS, IT CAN BE CONSIDERED NON-INTERRUPT MODE.

TEST 17 HAS ERRORS 171 THROUGH 176

TEST 20 TEST DATA WRAP AROUND BINARY COUNT: INTERRUPT MODE.  
---- --

INTERRUPT MODE DENOTES THAT THE PROGRAM HAS SET THE "IE" (INTERRUPT ENABLE) BIT IN THE CSR REGISTER. THE PROGRAM ALSO MUST HAVE AN ADDRESS AND NEW PSW VALUE PLACED AT THE INTERRUPT VECTOR LOCATIONS. AT THE SPECIFIED ADDRESS THE PROGRAM MUST ALSO HAVE AN "RTI" INSTRUCTION AT THE END OF THE INTERRUPT ROUTINE. INTERRUPT MODE CAN ALSO BE CONSIDERED AS NON-FLAG MODE.

TEST 20 HAS ERRORS 201 THROUGH 205

TEST 21 TEST BREAK LOGIC: TRANSMIT KNOWN CHAR  
---- --

- A) TRANSMIT KNOWN CHAR WITH BREAK SET AND COMPARE RECEIVED WITH 0
- B) TEST FOR FRAMING ERROR ON BREAK
- C) IF PARITY IS ENABLED AND ODD PARITY IS SELECTED, CHECK TO BE SURE PARITY ERROR WAS GENERATED
- D) IF PARITY IS ENABLED AND EVEN PARITY IS SELECTED, CHECK TO BE SURE NO PARITY ERROR OCCURRED

TEST 21 HAS ERRORS 1 THROUGH 13

TEST 22 NOT A TEST - SEND BACK TO LOOP

\*\*\*\*\* PHASE 2 TESTS \*\*\*\*\*

TEST 23 TEST THAT CHANNELS INTERRUPT AT ASSIGNED PRIORITY  
---- --

TEST 23 HAS ERRORS 231 THROUGH 237

TEST 24 TEST DATA TRANSFERS WITH ALL ACTIVE LINES INTERRUPTING.  
---- --

TEST 24 HAS ERRORS 241 THROUGH 247

TEST 25 TEST THAT CHANNELS INTERRUPT AT ASSIGNED PRIORITY  
---- --

THIS TEST IS EXECUTED ONLY ON THE SECOND MXV11-B MODULE. CHANNELS 2 AND 3. ANY FAILURE IS RELATED TO THE SECOND MXV11-B BOARD.

TEST 25 HAS ERRORS 251 THROUGH 256

TEST 26 TEST DATA TRANSFERS WITH ALL ACTIVE LINES INTERRUPTING.  
---- --

THIS TEST IS EXECUTED ONLY ON THE SECOND MXV11-B MODULE.  
CHANNELS 2 AND 3. ANY FAILURE IS RELATED TO THE SECOND  
MXV11-B BOARD.

TEST 26 HAS ERRORS 261 THROUGH 264

8

823  
824

```
.TITLE CVMXBAO MXV11B DIAG
:*COPYRIGHT (C) 1982
:*DIGITAL EQUIPMENT CORP.
:*MAYNARD, MASS. 01754
:*
:*PROGRAM BY DICE SYSTEMS, INC.
:*
:*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
:*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
:*
```

825  
826

```
.SBTTL OPERATIONAL SWITCH SETTINGS
:*.
:*.          SWITCH          USE
:*.          -----          -
:*.          15             HALT ON ERROR
:*.          14             LOOP ON TEST
:*.          13             INHIBIT ERROR TYPEOUTS
:*.          11             INHIBIT ITERATIONS
:*.          10             BELL ON ERROR
:*.          9              LOOP ON ERROR
:*.          8              LOOP ON TEST IN SWR<7:0>
```

827

```
.SBTTL BASIC DEFINITIONS
:*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
STACK= 1100
ERROR=EMT          ;;BASIC DEFINITION OF ERROR CALL
SCOPE=IOT          ;;BASIC DEFINITION OF SCOPE CALL
:*MISCELLANEOUS DEFINITIONS
000011             HT= 11          ;;CODE FOR HORIZONTAL TAB
000012             LF= 12          ;;CODE FOR LINE FEED
000015             CR= 15          ;;CODE FOR CARRIAGE RETURN
000200             CRLF= 200       ;;CODE FOR CARRIAGE RETURN-LINE FEED
177776             PS= 177776     ;;PROCESSOR STATUS WORD
177776             PSW=PS
177774             STKLMT= 177774  ;;STACK LIMIT REGISTER
177772             PIR0= 177772   ;;PROGRAM INTERRUPT REQUEST REGISTER
177570             DSWR= 177570   ;;HARDWARE SWITCH REGISTER
177570             DDISP= 177570  ;;HARDWARE DISPLAY REGISTER
:*GENERAL PURPOSE REGISTER DEFINITIONS
000000             R0= 0          ;;GENERAL REGISTER
000001             R1= 1          ;;GENERAL REGISTER
000002             R2= 2          ;;GENERAL REGISTER
000003             R3= 3          ;;GENERAL REGISTER
000004             R4= 4          ;;GENERAL REGISTER
000005             R5= 5          ;;GENERAL REGISTER
000006             R6= 6          ;;GENERAL REGISTER
000007             R7= 7          ;;GENERAL REGISTER
000006             SP= 6          ;;STACK POINTER
000007             PC= 7          ;;PROGRAM COUNTER
:*PRIORITY LEVEL DEFINITIONS
000000             PR0= 0         ;;PRIORITY LEVEL 0
000040             PR1= 40        ;;PRIORITY LEVEL 1
000100             PR2= 100       ;;PRIORITY LEVEL 2
000140             PR3= 140       ;;PRIORITY LEVEL 3
000200             PR4= 200       ;;PRIORITY LEVEL 4
000240             PR5= 240       ;;PRIORITY LEVEL 5
```

```
000300 PR6= 300 ::PRIORITY LEVEL 6
000340 PR7= 340 ::PRIORITY LEVEL 7
;*"SWITCH REGISTER" SWITCH DEFINITIONS
100000 SW15= 100000
040000 SW14= 40000
020000 SW13= 20000
010000 SW12= 10000
004000 SW11= 4000
002000 SW10= 2000
001000 SW09= 1000
000400 SW08= 400
000200 SW07= 200
000100 SW06= 100
000040 SW05= 40
000020 SW04= 20
000010 SW03= 10
000004 SW02= 4
000002 SW01= 2
000001 SW00= 1
001000 SW9=SW09
000400 SW8=SW08
000200 SW7=SW07
000100 SW6=SW06
000040 SW5=SW05
000020 SW4=SW04
000010 SW3=SW03
000004 SW2=SW02
000002 SW1=SW01
000001 SW0=SW00
;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
100000 BIT15= 100000
040000 BIT14= 40000
020000 BIT13= 20000
010000 BIT12= 10000
004000 BIT11= 4000
002000 BIT10= 2000
001000 BIT09= 1000
000400 BIT08= 400
000200 BIT07= 200
000100 BIT06= 100
000040 BIT05= 40
000020 BIT04= 20
000010 BIT03= 10
000004 BIT02= 4
000002 BIT01= 2
000001 BIT00= 1
001000 BIT9=BIT09
000400 BIT8=BIT08
000200 BIT7=BIT07
000100 BIT6=BIT06
000040 BIT5=BIT05
000020 BIT4=BIT04
000010 BIT3=BIT03
000004 BIT2=BIT02
000002 BIT1=BIT01
000001 BIT0=BIT00
;*BASIC "CPU" TRAP VECTOR ADDRESSES
```



```

000004 ERRVEC= 4      ;; TIME OUT AND OTHER ERRORS
000010 RESVEC= 10   ;; RESERVED AND ILLEGAL INSTRUCTIONS
000014 TBITVEC= 4    ;; "T" BIT
000014 TRTVEC= 14   ;; TRACE TRAP
000014 BPTVEC= 14   ;; BREAKPOINT TRAP (BPT)
000020 IOTVEC= 20   ;; INPUT/OUTPUT TRAP (IOT) **SCOPE**
000024 PWRVEC= 24   ;; POWER FAIL
000030 EMTVEC= 30   ;; EMULATOR TRAP (EMT) **ERROR**
000034 TRAPVEC= 34  ;; "TRAP" TRAP
000060 TKVEC= 60     ;; TTY KEYBOARD VECTOR
000064 TPVEC= 64   ;; TTY PRINTER VECTOR
000240 PIRQVEC= 240  ;; PROGRAM INTERRUPT REQUEST VECTOR
    
```

826  
 830  
 831  
 832  
 833  
 834  
 835  
 836  
 837  
 838  
 839  
 840  
 841  
 842  
 843  
 844  
 845  
 846  
 847  
 848  
 849  
 850  
 851  
 853  
 855  
 856  
 857  
 858  
 859  
 860  
 861  
 862  
 863  
 866  
 867  
 868  
 869  
 870  
 871  
 872  
 873  
 874  
 875

```

177777
000000
000001

000200
000100

100000
040000
020000
010000

000200
000100
000001

172340
172342
172344
172346
172350
172352
172354
172356
172300
172302
172304
172306
172310
172312
172314
172316
177572
172516
    
```

```

SET= -1      ;; THE FOLLOWING DEFINITIONS APPLY TO THE GLOBAL SUBS
CLR= 0
TRUE= 1
    
```

; RCSR REGISTER BIT NAMES

```

DONE= BIT07      ; RECEIVER DONE
IE= BIT06        ; RECEIVER INTERRUPT ENABLE
    
```

; RBUF REGISTER BIT NAMES

```

ERR15= BIT15     ; ERROR INDICATOR
ORERR= BIT14     ; OVERRUN ERROR
FRERR= BIT13     ; FRAMING ERROR
PEERR= BIT12     ; PARITY ERROR
    
```

; TCR REGISTER BIT NAMES

```

RDY= BIT07       ; TRANSMITTER READY
IE= BIT06        ; TRANSMITTER INTERRUPT ENABLE
BREAK= BIT00     ; SEND BREAK (CONTINUOUS SPACE)
    
```

; MEMORY MANAGEMENT DEFINITIONS

```

PAR0= 172340
PAR1= 172342
PAR2= 172344
PAR3= 172346
PAR4= 172350
PAR5= 172352
PAR6= 172354
PAR7= 172356
PDR0= 172300
PDR1= 172302
PDR2= 172304
PDR3= 172306
PDR4= 172310
PDR5= 172312
PDR6= 172314
PDR7= 172316
SR0= 177572
SR3= 172516
    
```

```
881      ;:*****
882      .SBTTL TRAP CATCHER
          .=0
          ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT*"
          ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
          ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
          .=174
000174   000174
000176   000000
          DISPREG: .WORD 0           ;;SOFTWARE DISPLAY REGISTER
          SWREG:   .WORD 0           ;;SOFTWARE SWITCH REGISTER
          .SBTTL STARTING ADDRESS(ES)
000200   000137 001414
          JMP      @START ;;JUMP TO STARTING ADDRESS OF PROGRAM

883
884
885      .SBTTL ACT11 HOOKS
          ;:*****
          ;HOOKS REQUIRED BY ACT11
          $SVPC=.           ;SAVE PC
          .=46
000046   000204
          SENDAD           ;;1)SET LOC.46 TO ADDRESS OF SENDAD IN .SEOP
          .=52
000052   000000
          .WORD 0           ;;2)SET LOC.52 TO ZERO
          .=$SVPC           ;; RESTORE PC

          .=1000
          .SBTTL APT PARAMETER BLOCK
          ;:*****
          ;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
          ;:*****
          .SX=.           ;;SAVE CURRENT LOCATION
          .=24           ;;SET POWER FAIL TO POINT TO START OF PROGRAM
000024   000024
          200           ;;FOR APT START UP
          .=44           ;;POINT TO APT INDIRECT ADDRESS PNTR.
000044   000200
          $APTHDR ;;POINT TO APT HEADER BLOCK
          .=$X           ;;RESET LOCATION COUNTER
          ;:*****
          ;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
          ;INTERFACE SPEC.
          $APTHD:
001000   000000
          $HIBTS: .WORD 0           ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
001002   001174
          $MADR:  .WORD $MAIL      ;;ADDRESS OF APT MAILBOX (BITS 0-15)
001004   000202
          $TSTM:  .WORD 130.       ;;RUN TIME OF LONGEST TEST
001006   000214
          $PASTM: .WORD 140.       ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
001010   000175
          $UNITM: .WORD 125.       ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
001012   000030
          .WORD SETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)
```

888

```
.SBTTL COMMON TAGS
:*****
:*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
:*USED IN THE PROGRAM.
.=1100

001100 001100          $CMTAG:                ;;START OF COMMON TAGS
001100 000000          .WORD 0
001102 000          $TSTNM: .BYTE 0                ;;CONTAINS THE TEST NUMBER
001103 000          $ERFLG: .BYTE C                ;;CONTAINS ERROR FLAG
001104 000000          $ICHT: .WORD 0                ;;CONTAINS SUBTEST ITERATION COUNT
001106 000000          $LPADR: .WORD 0                ;;CONTAINS SCOPE LOOP ADDRESS
001110 000000          $LPERR: .WORD 0                ;;CONTAINS SCOPE RETURN FOR ERRORS
001112 000000          $ERTTL: .WORD 0                ;;CONTAINS TOTAL ERRORS DETECTED
001114 000          $ITEMB: .BYTE 0                ;;CONTAINS ITEM CONTROL BYTE
001115 001          $ERMAX: .BYTE 1                ;;CONTAINS MAX. ERRORS PER TEST
001116 000000          $ERRPC: .WORD 0                ;;CONTAINS PC OF LAST ERROR INSTRUCTION
001120 000000          $GDADR: .WORD 0                ;;CONTAINS ADDRESS OF 'GOOD' DATA
001122 000000          $BDADR: .WORD 0                ;;CONTAINS ADDRESS OF 'BAD' DATA
001124 000000          $GDDAT: .WORD 0                ;;CONTAINS 'GOOD' DATA
001126 000000          $BDDAT: .WORD 0                ;;CONTAINS 'BAD' DATA
001130 000000          .WORD 0                ;;CONTAINS 'BAD' DATA
001132 000000          .WORD 0                ;;RESERVED--NOT TO BE USED
001134 000          .WORD 0
001135 000          $AUTOB: .BYTE 0                ;;AUTOMATIC MODE INDICATOR
001136 000000          $INTAG: .BYTE 0                ;;INTERRUPT MODE INDICATOR
001140 177570          .WORD 0
001142 177570          $WR: .WORD DSWR                ;;ADDRESS OF SWITCH REGISTER
001144 177560          $DISPLAY: .WORD DDISP            ;;ADDRESS OF DISPLAY REGISTER
001146 177562          $TKS: 177560                ;;TTY KBD STATUS
001150 177564          $TKB: 177562                ;;TTY KBD BUFFER
001152 177566          $TPS: 177564                ;;TTY PRINTER STATUS REG. ADDRESS
001154 000          $TPB: 177566                ;;TTY PRINTER BUFFER REG. ADDRESS
001155 002          $NULL: .BYTE 0                ;;CONTAINS NULL CHARACTER FOR FILLS
001156 012          $FILLS: .BYTE 2                ;;CONTAINS # OF FILLER CHARACTERS REQUIRED
001157 000          $FILLC: .BYTE 12                ;;INSERT FILL CHARS. AFTER A 'LINE FEED'
001160 000000          $STPFLG: .BYTE 0                ;;'TERMINAL AVAILABLE' FLAG (BIT<07>=0=YES)
001162 000000          $TIMES: 0                ;;MAX. NUMBER OF ITERATIONS
001164 207          $SESCAPE: 0                ;;ESCAPE ON ERROR ADDRESS
001167 000          $SBELL: .ASCIZ <207><377><377>    ;;CODE FOR BELL
001170 077          $QUES: .ASCII /?/                ;;QUESTION MARK
001171 015          $SCRLF: .ASCII <15>                ;;CARRIAGE RETURN
001172 012          $SLF: .ASCIZ <12>                ;;LINE FEED
:*****
.SBTTL APT MAILBOX-ETABLE
:*****
.EVEN
001174 000000          $MAIL:                ;;APT MAILBOX
001176 000000          $MSGTY: .WORD AMSGTY                ;;MESSAGE TYPE CODE
001200 000000          $SFATAL: .WORD AFATAL                ;;FATAL ERROR NUMBER
001202 000000          $STESTN: .WORD ATESTN                ;;TEST NUMBER
001204 000000          $SPASS: .WORD APASS                ;;PASS COUNT
001206 000000          $SDEVCT: .WORD ADEVCT                ;;DEVICE COUNT
001210 000000          $SUNIT: .WORD AUNIT                ;;I/O UNIT NUMBER
001212 000000          $MSGAD: .WORD AMSGAD                ;;MESSAGE ADDRESS
001214 000000          $MSGLG: .WORD AMGLG                ;;MESSAGE LENGTH
001214 000          $SETABLE:                ;;APT ENVIRONMENT TABLE
001214 000          $SENV: .BYTE AENV                ;;ENVIRONMENT BYTE
```

001215	000	SEVM:	.BYTE	AENV:	::ENVIRONMENT MODE BITS
001216	000000	SSWREG:	.WORD	ASWREG:	::APT SWITCH REGISTER
001220	000000	SUSR:	.WORD	AUSR:	::USER SWITCHES
001222	000000	SCPUOP:	.WORD	ACPUOP:	::CPU TYPE,OPTIONS
		.*			BITS 15-11=CPU TYPE
		.*			11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
		.*			11/70=06,PDQ=07,Q=10
		.*			BIT 10=REAL TIME CLOCK
		.*			BIT 9=FLOATING POINT PROCESSOR
		.*			BIT 8=MEMORY MANAGEMENT
001224	000	SMAMS1:	.BYTE	AMAMS1:	::HIGH ADDRESS,M.S. BYTE
001225	000	SMTYP1:	.BYTE	AMTYP1:	::MEM. TYPE,BLK#1
		.*			MEM.TYPE BYTE -- (HIGH BYTE)
		.*			900 NSEC CORE=001
		.*			300 NSEC BIPOLAR=002
		.*			500 NSEC MOS=003
001226	000000	SMADR1:	.WORD	AMADR1:	::HIGH ADDRESS,BLK#1
		.*			MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF "TYPE" ABOVE
001230	000	SMAMS2:	.BYTE	AMAMS2:	::HIGH ADDRESS,M.S. BYTE
001231	000	SMTYP2:	.BYTE	AMTYP2:	::MEM. TYPE,BLK#2
001232	000000	SMADR2:	.WORD	AMADR2:	::MEM.LAST ADDRESS,BLK#2
001234	000	SMAMS3:	.BYTE	AMAMS3:	::HIGH ADDRESS,M.S.BYTE
001235	000	SMTYP3:	.BYTE	AMTYP3:	::MEM. TYPE,BLK#3
001236	000000	SMADR3:	.WORD	AMADR3:	::MEM.LAST ADDRESS,BLK#3
001240	000	SMAMS4:	.BYTE	AMAMS4:	::HIGH ADDRESS,M.S.BYTE
001241	000	SMTYP4:	.BYTE	AMTYP4:	::MEM. TYPE,BLK#4
001242	000000	SMADR4:	.WORD	AMADR4:	::MEM.LAST ADDRESS,BLK#4
001244	000000	SVECT1:	.WORD	AVECT1:	::INTERRUPT VECTOR#1,BUS PRIORITY#1
001246	000000	SVECT2:	.WORD	AVECT2:	::INTERRUPT VECTOR#2BUS PRIORITY#2
001250	000000	SBASE:	.WORD	ABASE:	::BASE ADDRESS OF EQUIPMENT UNDER TEST
001252	000000	SDEVN:	.WORD	ADEVN:	::DEVICE MAP
001254		SETEND:			
		.MEXIT			

```
.SBTTL ERROR POINTER TABLE
:*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
:*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
:*LOCATION %ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
:*NOTE1: IF %ITEMB IS 0 THE ONLY PERTINENT DATA IS (%ERRPC).
:*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
:*      EM      ::POINTS TO THE ERROR MESSAGE
:*      DM      ::POINTS TO THE DATA HEADER
:*      DT      ::POINTS TO THE DATA
:*      DF      ::POINTS TO THE DATA FORMAT
```

001254				
889				
890	001254	176500		BASE0: 176500 ;DEFAULT CH 0 BASE ADDR
891	001256	000300		VECT0: 300 ;DEFAULT CH 0 VECTOR
892	001260	177560		BASE1: 177560 ;DEFAULT CH 1 BASE ADDR (CONSOLE)
893	001262	000060		VECT1: 60 ;DEFAULT CH 1 VECTOR
894	001264	176510		BASE2: 176510 ;DEFAULT CH 2 BASE ADDR
895	001266	000310		VECT2: 310 ;DEFAULT CH 2 VECTOR
896	001270	176520		BASE3: 176520 ;DEFAULT CH 3 BASE ADDR
897	001272	000320		VECT3: 320 ;DEFAULT CH 3 VECTOR
898	001274	173000		LOROM: 173000 ;DEFAULT LO ROM ADDR
899	001276	173776		HIROM: 173776 ;DEFAULT HI ROM ADDR (256 WORDS)
900	001300	165000		LOROM2: 165000 ;DEFAULT LO ROM ADDR SECOND ROM
901	001302	165776		HIROM2: 165776 ;DEFAULT HI ROM ADDR 2ND ROM (256 WORDS)
902	001304	177524		LEDREG: 177524 ;ADDRESS REGISTER FOR LEDS
903				:OPTION 1: 4K 000000 - 017776
904				:OPTION 2: 4K 020000 - 037776
905				
906	001306	177546		LKSREG: 177546 ;LINE CLOCK REGISTER ADDRESS
907	001310	177520		PCRREG: 177520 ;PCR REGISTER CONSTANT
908	001312	000000		DLADD: 0 ;CH ADDR UNDER TEST...LOADED BY 'CYCLE'
909	001314	000000		RCSR: 0 ;CH REGS UNDER TEST...LOADED BY 'LOOP'
910	001316	000000		RBUF: 0
911	001320	000000		TCSR: 0
912	001322	000000		TBUF: 0
913	001324	000000		DLVEC: 0 ;CH RECVR VECTOR UNDER TEST...LOADED BY 'CYCLE'
914		000100		CLKVEC: 100 ;LINE CLOCK INTR VECTOR
915	001326	000000		TMP1: 0 ;TEMPORARY REGS
916	001330	000000		TMP2: 0
917	001332	000000		LEDHLD: .WORD ;THIS HOLD VALUE IN LED
918	001334	015	000	CARR: .ASCIZ <15>
919				.EVEN
920				
921				:::*****
922				:::TRAP CATCHER FOR OFF LINE USE ONLY. BEGIN PROGRAM WITH FRESH LOAD
923				:::*****
924				
925	001336	005000		TRPCAT: CLR R0
926	001340	012720	021522	18: MOV #INTSRV,(R0)+
927	001344	012720	000340	MOV #PR7,(R0)+
928	001350	020027	001000	CMP R0,#1000
929	001354	001371		BNE 18
930	001356	000412		BR 38
931				
932	001360	005000		CLR R0
933	001362	012701	000002	MOV #2,R1
934	001366	010120		28: MOV R1,(R0)+

935	001370	005020		CLR	(R0)+	
936	001372	062701	000004	ADD	#4,R1	
937	001376	020027	001000	CMP	R0,#1000	
938	001402	001371		BNE	28	
939	001404	005067	176566	38:	CLR	176
940	001410	000167	000000		JMP	STANT
941						
943	001414	000005		START:	RESET	
944	001416	012700	177777		MOV	#-1,R0
945	001422	005300		38:	DEC	R0
946	001424	001376			GNE	38
947						
	001426	012706	001100	.SBTTL	INITIALIZE THE COMMON TAGS	
	001432	005026		::CLEAR	THE COMMON TAGS (SCMTAG) AREA	
	001434	022706	001140		MOV	#SCMTAG,R6
	001440	001374			CLR	(R6)+
	001442	012706	001100		CMP	#SWR,R6
					BNE	.-6
					MOV	#STACK,SP
	001446	012737	026762	000020	::INITIALIZE	A FEW VECTORS
	001454	012737	000340	000022	MOV	#SCOPE,#IOTVEC
	001462	012737	026562	000030	MOV	#340,#IOTVEC+2
	001470	012737	000340	000032	MOV	#ERROR,#EMTVEC
	001476	012737	027714	000034	MOV	#340,#EMTVEC+2
	001504	012737	000340	000036	MOV	#STRAP,#TRAPVEC
	001512	012737	025006	000024	MOV	#340,#TRAPVEC+2
	001520	012737	000340	000026	MOV	#SPWRDN,#PPWRVEC
	001526	016767	023166	023156	MOV	#340,#PPWRVEC+2
	001534	005067	177420		MOV	SENDCT,SECPCT
	001540	005067	177416		CLR	STIMES
	001544	112767	000001	177343	CLR	SESCAPE
	001552	012767	001552	177326	MOV	#1,SEMAX
	001560	012767	001560	177322	MOV	#.,SLPADR
					MOV	#.,SLPERR
					::SIZE	FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
					::EQUAL	TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
	001566	013746	000004		MOV	#ERRVEC,-(SP)
	001572	012737	001626	000004	MOV	#648,#ERRVEC
	001600	012767	177570	177332	MOV	#DSWR,SWR
	001606	012767	177570	177326	MOV	#DDISP,DISPLAY
	001614	022777	177777	177316	CMP	#-1,DSWR
	001622	001012			BNE	668
	001624	000403			BR	658
	001626	012716	001634		648:	MOV
	001632	000002				RTI
	001634	012767	000176	177276	658:	MOV
	001642	012767	000174	177272		MOV
	001650	012637	000004		668:	MOV
	001654	005067	177322			CLR
	001660	132767	000200	177327		BITB
	001666	001403				BEG
	001670	012767	001216	177242		MOV
	001676				678:	
948					.SBTTL	TYPE PROGRAM NAME
	001676	005227	177777		::TYPE	THE NAME OF THE PROGRAM IF FIRST PASS
	001702	001045			INC	#-1
					BNE	688

```

001704 022737 024752 000042      CMP      #SENDAD,#42      ;;ACT-11?
001712 001441                      BEQ      68$              ;;BRANCH IF YES
001714 134401 001762                      TYPE     ,69$            ;;TYPE ASCIZ STRING
                                .SBTTL  GET VALUE FOR SOFTWARE SWITCH REGISTER
001720 005737 060042                      TST     #42              ;;ARE WE RUNNING UNDER XXDP/ACT?
001724 001012                      BNE     70$              ;;BRANCH IF YES
001726 126727 177262 000001          CMPB    SEND,#1          ;;ARE WE RUNNING UNDER APT?
001734 001406                      BEQ     70$              ;;BRANCH IF YES
001736 026727 177176 000176          CMP     SWR,#SWREG       ;;SOFTWARE SWITCH REG SELECTED?
001744 001005                      BNE     71$              ;;BRANCH IF NO
001746 104406                      GTSWR                      ;;GET SOFT-SWR SETTINGS
001750 000403                      BR      71$
001752 112767 000001 177154 70$:   MOVB    #1,$AUTOB        ;;SET AUTO-MODE INDICATOR
001760 000416                      71$:   BR      68$
                                ;;69$:  .ASCIZ  <CRLF>*CVMXBAO MXV11B DIAGNOSTIC* <CRLF>
                                68$:
949 002016 012767 177524 177260      MOV     #177524,LEDREG    ;SET UP LED REGISTER
950 002024 005227 177777                      INC     #-1              ;1'ST TIME?
951 002030 001014                      BNE     1$              ;BR IF NO
952 002032 126727 177156 000001          CMPB    SEND,#1          ;APT?
953 002040 001410                      BEQ     1$              ;BR IF YES
954 002042 005737 000042                      TST     #42              ;CHECK FOR CHAIN MODE
955 002046 001404                      BEQ     2$              ;0=NOT CHAINED NON-ZERO= CHAINED
956 002050 052767 000004 177174          BIS     #BIT2,$DEVN      ;SET UP VALUE FOR TEST
957 002056 000401                      BR      1$              ;SKIP OVER QUESTION
958 002060 104412                      2$:   GTDEVN             ;ELSE SHOW CURRENT DEVN & GET NEW
959
960 002062 004767 015726                      1$:   JSR     PC,$SIZE      ;SIZE THE MXV11-B
961
962 002066 012706 001100          RAMROM: MOV    #STACK,$SP ;RESET STACK P/R
963
964
965
976
                                ;*****
                                ;*TEST 1          RAM ADDRESS TEST
                                ;*
                                ;*   WRITE ENTIRE MEMORY WITH ADDRESS AS DATA.
                                ;*   READ ENTIRE MEMORY TO VERIFY.
                                ;*
                                ;*****
002072 000004          TST1:  SCOPE
002074 012767 000001 177056      MOV     #1,$TIMES        ;;DO 1 ITERATION
002102 012767 000001 177070      MOV     #1,$TESTN        ;;SET TEST NUMBER IN APT MAIL BOX
981 002110 000240                      NOP                      ;;SPECIAL DEBUG FEATURE (GOOD HALT LOC)
982
983 002112 032767 000004 177132          BIT     #BIT2,$DEVN      ;BYPASS RAM TESTS?
984 002120 001022                      BNE     5$              ;BR, IF NO RAM TESTS
985
986 002122 012700 037776          MOV     #37776,$RO       ;ADDRESS REG
987
988 002126 010010                      1$:   MOV     $RO,($RO)      ;LOAD ADDRESS AS DATA
989 002130 020027 137776          CMP     $RO,#137776      ;LAST ADDR (LEAVE ROOM FOR XXDP)
990 002134 001402                      BEQ     2$              ;BR IF YES
991 002136 005720                      TST     ($RO)+           ;ELSE BUMP ADDR REG
992 002140 000772                      BR      1$
993

```

```

994 002142 012700 037776      28:  MOV      #37776,R0      :VERIFY
995 002146 020010              38:  CMP      R0,(R0)      :READ & CHECK
996 002150 001401              BEQ      48              :
997 002152              ERROR  48              :
          002152 104011          EMT 11          :DATA NOT = ADDRESS
998
999 002154 020027 137776      48:  CMP      R0,#137776    :LAST ADDR (LEAVE ROOM FOR XXDP)
1000 002160 001402              BEQ      58              :BR, IF ALL DONE RAM TESTS
1001 002162 005720              TST      (R0)+          :ELSE BUMP ADDR
1002 002164 000770              BR       38              :
1003 002166 032767 000100 177056 58:  BIT      #BIT6,SDEVN    :SHOULD WE TEST/USE THE LEDS
1004 002174 001023              BNE     TST2            :BR, IF WE SHOULDN'T
1005 002176 005067 017326              CLR     INTFLG          :RESET INT FLAG
1006 002202 005777 177076              TST     @LEDREG         :ARE LEDS THERE
1007 002206 005767 017316              TST     INTFLG          :DID WE GET A TRAP
1008 002212 001012              BNE     68              :BR, IF THEY WEREN'T THERE
1009
1010 002214 016700 176662              MOV     $STNA,R0        :GET TEST NUMBER
1011 002216 005100              COM     R0              :1'S COMP TEST NUMBER
1012 002218 032767 000100 177022  BIT     #BIT6,SDEVN    :CAN THE LEDS BE USED
1013 002230 001002              BNE     5018            :BR, IF THEY CAN'T
1014 002232 110077 177046              MOVB   R0,@LEDREG      :DISPLAY TEST NUMBER IN LEDS
1015 002236              5018:
1016 002236 000402              BR     TST2            :ALL DONE
1017 002240              68:  ERROR  12              :LEDS NOT THERE
          002240 104012          EMT 12
1018 002242 000400              BR     TST2            :GO ON
  
```



1020  
1037

```

*****
*TEST 2      RAM DATA & VOLITILITY TEST
*
* WRITE ALL MEMORY TO BACKGROUND OF ALL 1'S.
* TEST LOCATION FOR CORRECT BACKGROUND.
* FLOAT 0'S & COMPLEMENT THRU WORD.
* RESET LOCATION TO BACKGROUND.
* REPEAT ABOVE 3 STEPS FOR EACH LOCATION.
* WHEN ALL LOCATIONS TESTED, CHECK ENTIRE MEMORY FOR BACKGROUND PATTERN.
* CHECK VOLITILITY BY WAITING MORE THAN 5 SEC & RECHECKING BACKGROUND PATT.
* REPEAT ALL THE ABOVE FOR BACKGROUND PATTERN OF ALL 0'S & FLOATING 1'S.
*****

```

```

002244 000004
002246 012767 000001 176704
002254 012767 000002 176716
1042 002262 000240
1043
1044 002264 016700 176612
1045 002270 005100
1046 002272 032767 000100 176752
1047 002300 001002
1048 002302 110077 176776
1049 002306
1050 002306 032767 010000 176736
1051 002314 001004
1052 002316 032767 000004 176726
1053 002324 001402
1054 002326 000167 000456
1055
1056
1057
1058 002332
1059 002332 012701 172340
1060 002336 012705 172300
1061 002342 005000
1062 002344 010021
1063 002346 012725 077406
1064 002352 062700 000200
1065 002356 020027 001600
1066 002362 003770
1067 002364 012741 007600
1068 002370 052737 000001 177572
1069 002376 012704 000200
1070 002402 012737 002434 000004
1071 002410 012737 000340 000006
1072 002416 010437 172354
1073 002422 005737 140000
1074 002426 062704 000200
1075 002432 000771
1076 002434
1077 002434 012737 000400 172354
1078 002442 005005
1079 002444 012701 140000
1080 002450 010521
1081 002452 020127 157776

```

```

TST2:  SCOPE
      MOV  #1,$TIMES      ;;DO 1 ITERATION
      MOV  #2,$TESTN     ;;SET TEST NUMBER IN APT MAIL BOX
      NOP                ;;SPECIAL DEBUG FEATURE (GOOD HALT LOC)

      MOV  $STMM,$R0     ;GET TEST NUMBER
      COM  $R0           ;1'S COMP TEST NUMBER
      BIT  #BIT6,$DEVH   ;CAN THE LEDS BE USED
      BNE  $501$        ;BR, IF THEY CAN'T
      MOVB $R0,$LEDREG  ;DISPLAY TEST NUMBER IN LEDS
501$:  BIT  #BIT12,$DEVH ;BYPASS MEM MNGT CODE
      BNE  $511$        ;BR, IF BY PASS IS SELECTED
      BIT  #BIT2,$DEVH  ;BYPASS RAM TESTS?
      BEQ  $TEST5A      ;BR, IF TESTS ARE TO BE RUN
511$:  JMP  $TST3       ;JMP IF RAM TESTS ARE NOT TO BE RUN

      .SBTTL  EXTENDED MEMORY TEST

TEST5A:
      MOV  #PAR0,$R1    ;START OF PAR REGISTERS
      MOV  #PDR0,$R5    ;START OF THE PDR REGISTERS
      CLR  $R0          ;FIRST PAGE BASE ADDRESS
20$:  MOV  $R0,($R1)+    ;SET BASE FOR NEXT MAP
      MOV  #77406,($R5)+ ;4K READ/WRITE EACH PAGE
      ADD  #200,$R0     ;BASE FOR THE NEXT PAGE
      CMP  $R0,#1600   ;DONE ALL PAGES ?
      BLE  $20$        ;SET UP ALL MEMORY MANAGEMENT PAGES
      MOV  #7600,-($R1) ;SET UP I/O PAGE
      BIS  #1,$SR0     ;ENABLE MEMORY MANAGEMENT
      MOV  #200,$R4    ;4K INC VALUE FOR PAR6
      MOV  #168,$R4   ;LOAD UP VECTOR AREA
      MOV  #340,$R6   ;PSW = NO INTERRUPTS
15$:  MOV  $R4,$PAR6   ;START CHECKING FOR TOP
      TST  #140000    ;LOOK AT MEMORY
      ADD  #200,$R4   ;NEXT 4K VALUE
      BR   $15$       ;LOOP UNTIL TOP OF MEMORY

16$:  MOV  #400,$PAR6  ;START MEMORY PAGE 00000
      CLR  $R5        ;INITIAL VALUE
17$:  MOV  #140000,$R1 ;START AT LOC 0, RELATIVE TO PAR6
10$:  MOV  $R5,($R1)+ ;STORE 0 MEMORY
      CMP  $R1,#157776 ;END OF MEMORY PAGE YET ?

```

1082	002456	101774			BLOS	108		:LOOP TILL WHOLE PAGE WRITTEN
1083	002460	062737	000200	172354	ADD	#200,#PAR6		:MAP INTO NEXT PAGE
1084	002466	023704	172354		CMP	#PAR6,R4		:UP TO THE I/O PAGE YET ?
1085	002472	002764			BLT	178		: JP UNTIL ALL MEMORY WRITTEN
1086	002474	162737	000200	172354	SUB	#200,#PAR6	278:	:MOVE DOWN TO THE NEXT PAGE
1087	002502	003443			BLE	338		:ALL DONE WHEN BELOW START
1088	002504	012701	160000		MOV	#160000,R1		:TOP ADDRESS OF PAGE+2
1089	002510	012705	177777		MOV	#-1,R5	118:	:SET TO ALL ONES
1090	002514	005741			TST	-(R1)	188:	:CHECK FOR 0 AND DEC ADDRESS
1091	002516	001012			BNE	28		:L.I. IN NOT = 0 (ERROR)
1092	002520	074511			XOR	R5,(R1)		:LOAD MEMORY SORT OF
1093	002522	005111			COM	(R1)		:CHECK FOR CORRECT DATA
1094	002524	001001			BNE	128		:BR, IF NOT 0 (ERROR)
1095	002526	000414			BR	138		:KEEP GOING
1096	002530	042737	000001	177572	BIC	#1,#SRO	128:	:TURN OFF MEMORY MNGT
1097	002536	013702	172354		MOV	#PAR6,R2		:CONTENTS OF CURRENT MAPPING REGISTER
1098	002542				ERROR	21		:PRINT 'MEM BAD'
	002542	104021			EMT	21		
1099	002544	042737	000001	177572	BIC	#1,#SRO	28:	:TURN OFF MEMORY MANGEMENT
1100	002552	013702	172354		MOV	#PAR6,R2		:CONTENTS OF CURRENT MAPPING REGISTER
1101	002556				ERROR	22		:PRINT 'MEM BAD'
	002556	104022			EMT	22		
1102	002560	005011			CLR	(R1)	138:	:RETURN MEMORY TO ORIG STATE
1103	002562	020127	140000		CMP	R1,#140000		:TESTED ALL OF PAGE ?
1104	002566	101352			BHI	188		:BR IF NOT
1105	002570	062701	020000		ADD	#20000,R1		:SET TO START VALUE
1106	002574	162737	000200	172354	SUB	#200,#PAR6		:RESET THE MAP REGISTER
1107	002602	023727	172354	000400	LMP	#PAR6,#400		:CHECK FOR END
1108	002610	101341			BHI	188		:BR, IF MORE TO TEST
1109	002612						338:	
1110	002612	012737	000400	172354	MOV	#400,#PAR6		:START MEMORY PAGE 0000
1111	002620	012705	177777		MOV	#-1,R5		:ALL ONES THIS TIME
1112	002624	012701	140000		MOV	#140000,R1	1178:	:START AT LOC 0, RELATIVE TO PAR6
1113	002630	010521			MOV	R5,(R1)+	1108:	:STORE 0 MEMORY
1114	002632	020127	157776		CMP	R1,#157776		:END OF MEMORY PAGE YET ?
1115	002636	101774			BLOS	1108		:LOOP TILL WHOLE PAGE WRITTEN
1116	002640	062737	000200	172354	ADD	#200,#PAR6		:MAP INTO NEXT PAGE
1117	002646	023704	172354		CMP	#PAR6,R4		:UP TO THE I/O PAGE YET ?
1118	002652	002764			BLT	1178		:LOOP UNTIL ALL MEMORY WRITTEN
1119	002654	162737	000200	172354	SUB	#200,#PAR6	1278:	:MOVE DOWN TO THE NEXT PAGE
1120	002662	003443			BLE	1338		:ALL DONE WHEN BELOW ZERO 0000
1121	002664	012701	160000		MOV	#160000,R1		:TOP ADDRESS OF THE PAGE +2
1122	002670	005005			CLR	R5	1118:	:SET R5 TO 00000'S
1123	002672	005741			TST	-(R1)	1168:	:CHECK FOR 0 AND DEC ADDRESS
1124	002674	001412			BEG	2128		:BR, IF = 0 (ERROR)
1125	002676	010511			MOV	R5,(R1)		:LOAD MEMORY SORT OF
1126	002700	005111			COM	(R1)		:CHECK FOR CORRECT DATA
1127	002702	001401			BEG	1128		:BR, IF 0 (ERROR)
1128	002704	000414			BR	1138		:KEEP GOING
1129	002706	042737	000001	177572	BIC	#1,#SRO	1128:	:TURN OFF MEMORY MANGEMENT
1130	002714	013702	172354		MOV	#PAR6,R2		:CONTENTS OF CURRENT MAPPING REGISTER
1131	002720				ERROR	23		:PRINT 'MEM BAD'
	002720	104023			EMT	23		
1132	002722	042737	000001	177572	BIC	#1,#SRO	2128:	:TURN OFF MEMORY MANGEMENT
1133	002730	013702	172354		MOV	#PAR6,R2		:CONTENTS OF CURRENT MAPPING REGISTER
1134	002734				ERROR	24		:PRINT 'MEM BAD'
	002734	104024			EMT	24		

1135	002736	012711	177777	1135:	MOV	#-1,(R1)	:RETURN MEMORY TO ORIG STATE
1136	002742	020127	140000		CMP	R1,#140000	:TESTED ALL OF PAGE ?
1137	002746	101351			BHI	1168	:BR IF NOT
1138	002750	062701	020000		ADD	#20000,R1	:SET TO START VALUE
1139	002754	162737	000200 172354		SUB	#?00,#PAR6	:RESET THE MAP REGISTER
1140	002762	023727	172354 000400		CMP	#PAR6,#400	:CHECK FOR END
1141	002770	101340			BHI	1168	:BK, IF MORE TO TEST
1142	002772			1335:			
1143	002772	042737	000001 177572		BIC	#1,#SRO	:TURN OFF MEMORY MANAGEMENT
1144				:			
1145				:			
1146				:			
1147	003000	000403			BR	TST3	:ALL DONE
1148							
1149	003002	000000		BKGND:	0		:BACKGROUND
1150	003004	000000		RDWRD:	0		:STORE READ WORD HERE
1151	003006	000000		SAVBK:	0		:ROTATE BACKGROUND HERE
1152							
1153							

1159

```

:*****
:TEST 3 ROM TESTS
:*****

```

```

003010 000004
003012 012767 000010 176140
003020 012767 000003 176152
1164 003026 000240

```

```

TST3: SCOPE
MOV #10,STIMES ;DO 10 ITERATIONS
MOV #3,STIN ;SET TEST NUMBER IN APT MAIL BOX
NOP ;SPECIAL DEBUG FEATURE (GOOD HALT LOC)

```

```

1165
1166
1167 003030 016700 176046
1168 003034 005100
1169 003036 032767 000100 176206
1170 003044 001002
1171 003046 110077 176232
1172 003052

```

```

MOV STSTNM,RO ;GET TEST NUMBER
COM RO ;1'S COMP TEST NUMBER
BIT #BIT6,SDEVH ;CAN THE LEDS BE USED
BNE S01S ;BR, IF THEY CAN'T
MOVB RO,@LEDREG ;DISPLAY TEST NUMBER IN LEDS

```

```

1173 003052 032767 000002 176172
1174 003060 001521
1175 003062 012767 021522 174714
1176 003070 012767 000200 174710

```

```

S01S: BIT #BIT1,SDEVH ;BYPASS ROM TEST?
BEQ TST35 ;EXIT IF YES
MOV #INTSRV,ERRVEC ;SETUP TIMEOUT TRAP ADDR
MOV #200,ERRVEC+2

```

```

1181
1182
1183
1184
1189

```

```

:*****
:TEST 'LOROM' TO 'HIROM' PRESENT
:*****

```

```

1190 003076 016703 176172
1191 003102 005067 016422
1192 003106 005713
1193 003110 005767 016414
1194 003114 001403
1195 003116 010367 000200
1196 003122
003122 104031

```

```

3S: MOV LOROM,R3
CLR INTFLG
TST (R3) ;ACCESS
TST INTFLG ;TIMEOUT?
BEQ 4S ;BR IF NO
MOV R3,ADDR ;FOR ERROR ANALYSIS
ERRCR 31
EMT 31

```

```

1197
1198 003124 020367 176146
1199 003130 001403
1200 003132 062703 000002
1201 003136 000761

```

```

4S: CMP R3,HIROM ;ALL DONE?
BEQ 5S ;BR IF YES
ADD #2,R3 ;ELSE BUMP ADDR
BR 3S

```

```

1202
1207
1208
1209

```

```

:*****
:TEST THAT ROM CANNOT BE WRITTEN INTO
:*****

```

```

1214
1215 003140 016703 176130
1216 003144 012700 101010
1217 003150 010013
1218 003152 011301
1219 003154 020100
1220 003156 001003
1221 003160 010367 000136
1222 003164
003164 104032

```

```

5S: MOV LOROM,R3
6S: MOV #101010,RO ;PATTERN FOR WRITE
MOV RO,(R3) ;TRY TO WRITE INTO ROM
MOV (R3),R1 ;READ ROM BACK
CMP R1,RO ;CHECK IN VS OUT
BNE 7S ;BR IF YES
MOV R3,ADDR ;FOR ERROR ANALYSIS
ERRCR 32
EMT 32

```

```

1223
1224 003166 020367 176104
1225 003172 001403
1226 003174 062703 000002
1227 003206 000761
1232

```

```

7S: CMP R3,HIROM ;ALL DONE?
BEQ 8S ;BR IF YES
ADD #2,R3 ;ELSE BUMP ADDR
BR 6S

```

```

1233
1234
1235
1240
1241 003202 016703 176072
1242 003206 005067 016316
1243 003212 005713
1244 003214 005767 016310
1245 003220 01403
1246 003222 010367 000074
1247 003226
      003226 104033
1248
1249 003230 020367 176046
1250 003234 001403
1251 003236 062703 000002
1252 003242 000761
1253
1258
1259
1260
1265
1266 003244 016703 176030
1267 003250 012700 101010
1268 003254 010013
1269 003256 011301
1270 003260 020100
1271 003262 001003
1272 003264 010367 000032
1273 003270
      003270 104034
1274
1275 003272 020367 176004
1276 003276 001403
1277 003300 062703 000002
1278 003304 000761
1279 003306 012767 000006 174470
1280 003314 005067 174466
1281 003320 000401
1282
1283 003322 000000
1284
1285
1286
1287
1288
1289 003324 032767 000200 175720
1290 003332 001067
1291 003334 012767 021522 174442
1292 003342 012767 000200 174436
1293 003350 005067 016154
1294 003354 005777 175730
1295 003360 005767 016144
1296 003364 001401
1297 003366
      003366 104035
1298 003370 012701 177777

```

```

:*****
:TEST 'LOROM2' TO 'HIROM2' PRESENT
:*****

88:  MOV  LOROM2,R3
188: CLR  INTFLG
      TST  (R3)           ;ACCESS
      TST  INTFLG        ;TIMEOUT?
      BEQ  98            ;BR IF NO
      MOV  R3,ADDR       ;FOR ERROR ANALYSIS
      ERROR 33
      EMT 33

98:  CMP  R3,HIROM2      ;:ALL DONE?
      BEQ  108           ;:BR IF YES
      ADD  #2,R3         ;:ELSE BUMP ADDR
      BR   188

:*****
:TEST THAT ROM CANNOT BE WRITTEN INTO
:*****

108: MOV  LOROM2,R3
118: MOV  #101010,R0      ;:PATTERN FOR WRITE
      MOV  R0,(R3)       ;:TRY TO WRITE INTO ROM
      MOV  (R3),R1       ;:READ ROM BACK
      CMP  R1,R0         ;:CHECK IN VS OUT
      BNE  128           ;:BR IF YES
      MOV  R3,ADDR       ;:FOR ERROR ANALYSIS
      ERROR 34
      EMT 34

128: CMP  R3,HIROM2      ;:ALL DONE?
      BEQ  138           ;:BR IF YES
      ADD  #2,R3         ;:ELSE BUMP ADDR
      BR   118

138: MOV  #ERRVEC+2,ERRVEC ;:RESTORE TIMEOUT VECTOR
      CLR  ERRVEC+2
      BR   TST35        ;:EXIT TEST

ADDR: .WORD 0           ;:ROM ADDRESS WHERE ERROR OCCURED
:
:*****
:TEST OF PCR REGISTER
:*****

TST35: BIT  #BIT7,SDEVM   ;:IS THE PCR REGISTER THERE
      BNE  TST4          ;:BR, IF NO TESTING TO BE DONE
      MOV  #INTSRV,ERRVEC ;:SET UP VECTOR
      MOV  #200,ERRVEC+2 ;:SET UP BR
      CLR  INTFLG        ;:CLEAR INTERRUPT INDICATOR
      TST  @PCRREG       ;:LOOK AT REGISTER
      TST  INTFLG        ;:CHECK FOR TRAP
      BEQ  !05           ;:BR, IF NO TRAP (OK)
      ERROR 35
      EMT 35

108:  MOV  #17777?,R1    ;:ALL ONES

```

1299	003374	042701	160340		BIC	#160340,R1		:PCR REGISTER MASK
1300	003400	010177	175704		MOV	R1,@PCRREG		:LOAD REGISTER WITH "ALL" ONES
1301	003404	017702	175700		MOV	@PCRREG,R2		:READ REGISTER BACK
1302	003410	042702	160340		BIC	#160340,R2		:PCR REGISTER MASK
1303	003414	020201			CMP	R2,R1		:CAN PCR HOLD "ALL" ONES
1304	003416	001401			BEQ	12\$		:BR, IF PCR CAN (GOOD)
1305	003420				ERROR	36		:ERROR IT CAN'T
	003420	104036			EMT	36		
1306	003422			12\$:				
1307	003422	005000			CLR	R0		:CLEAR REGISTER
1308	003424	000241			CLC			:CLEAR THE CARRY BIT
1309	003426	012701	000001		MOV	#1,R1		:SET UP COUNTER
1310	003432	012703	000016		MOV	#16,R3		:SET ANOTHER COUNTER
1311	003436	010100		15\$:	MOV	R1,R0		:START MASK
1312	003440	042700	160340		BIC	#160340,R0		:REAL MASK
1313	003444	010077	175640		MOV	R0,@PCRREG		:LOAD THE PCR REGISTER
1314	003450	017702	175634		MOV	@PCRREG,R2		:READ IT BACK
1315	003454	042702	160340		BIC	#160340,R2		:REAL MASK (ONLY 10 BITS USED)
1316	003460	020002			CMP	R0,R2		:RIGHT BITS COME BACK
1317	003462	001401			BEQ	20\$		:BR, IF ALL OK (EQUAL)
1318	003464				ERROR	37		
	003464	104037			EMT	37		
1319	003466	006301		20\$:	ASL	R1		:SHIFT BIT
1320	003470	005701			TST	R1		:CHECK FOR END
1321	003472	001401			BEQ	20\$		:BR, IF AT END
1322	003474	000760			BR	15\$		:KEEP GOING NOT DONE
1323	003476	012767	000006	174300	30\$:	MOV	#ERRVEC+2,ERRVEC	:RESET VECTORS
1324	003504	005067	174276		CLR	ERRVEC+2		:RESET VECTORS
1325	003510	000400			BR	TST4		:NEXT TEST
1326					:			
1327					:			
1328					:			
					END OF PCR REGISTER TEST			

1350  
1355

```

*****
*TEST 4          CLOCK TESTS
*
*   THE CLOCK TESTS NOW WORK AS FOLLOWS:
*   1.THE BR LEVEL IS SET TO 6
*   2.THE CLOCK VECTOR IS SET WITH INTSRV ADDRESS
*     THE PRIORITY IS ALSO SET TO ZERO (ALLOW ANYONE)
*   3.THE BR LEVEL IS DROPPED TO ZERO AND INTERRUPT
*     ENABLE IS SET IN THE CLOCK'S CSR (BIT 6)
*   4.PROGRAM DELAYS ONE REGISTER COUNT DOWN
*   5.IF NO INTERRUPT OCCURRED
*     THEN PRINT ERROR NUMBER 41
*   6.DISABLE CLOCK INTERRUPTS (BIT 6 = 0)
*   7.PROGRAM DELAYS ONE REGISTER COUNT DOWN
*   8.IF AN INTERRUPT OCCURRED
*     THEN PRINT ERROR 42
*   9.SET INTERRUPT PRIORITY AT MAXIMUM (BR = 7)
*  10.RESTORE THE CLOCK'S INTERRUPT VECTOR
*  11.DROP BR LEVEL BACK TO 0
*****

```

```

003512 000004
003514 012767 000010 175436
003522 012767 000004 175450
1360 003530 000240
1361
1362 003532 016700 175344
1363 003536 005100
1364 003540 032767 000100 175504
1365 003546 001002
1366 003550 110077 175530
1367 003554
1368 003554 032767 000001 175470
1369 003562 001002
1370 003564 000167 000136
1371 003570
1372 003570 106427
1373 003572 000300
1374 003574 012767 021522 174276
1375 003602 012767 000340 174272
1376 003610 005067 015714
1377 003614 106427
1378 003616 000000
1379 003620 112777 000100 175460
1380
1381
1382 003626 012700 177777
1383 003632 005300
1384 003634 001376
1385 003636 0427.7 000100 175442
1386 003638 005767 015660
1387 003640 001002
1388 003652
003652 104041
1389 003654 000412
1390

TST4:  SCOPE
MOV     #10,RTIMES      ;;DO 10 ITERATIONS
MOV     #4,STESTN      ;;SET TEST NUMBER IN APT MAIL BOX
NOP                                ;SPECIAL DEBUG FEATURE (GOOD HALT LOC)

MOV     $STNM,RO        ;GET TEST NUMBER
COM     RO              ;1'S COMP TEST NUMBER
BIT     #BIT6,$DEVN     ;CAN THE LEDS BE USED
BNE     $018            ;BR, IF THEY CAN'T
MOVB   RO,$LEDREG      ;DISPLAY TEST NUMBER IN LEDS

5018:  BIT     #BIT0,$DEVN ;SHOULD WE TEST THE CLOCK
BNE     $028            ;BR, IF YES WE SHOULD
JMP     $LU            ;NO DON'T TEST THE CLOCK

5028:  .WORD   106427      ;MTPS
        .WORD   300       ;SET THE BR LEVEL = 6
MOV     #INTSRV,CLKVEC ;SETUP VECTOR AREA
MOV     #340,CLKVEC+2  ;LET ANYONE IN AFTER CLOCK'S INTR
CLR     INTFLG
        .WORD   106427      ;MTPS
        .WORD   0         ;ALLOW CLOCK TO INTERR THRU INTSRV
MOVB   #100,$LKSREG    ;SET BIT6 (IE)

18:    MOV     #-1,RO     ;TIMER
DEC     RO
BNE     $18
BIC     #BIT6,$LKSREG  ;CLEAR IE SO NO MORE CLOCK INTERRUPTS
TST     INTFLG        ;GOT INTERRUPT?
BNE     $28           ;BR IF YES
ERROR  41             ;NO CLOCK INTERRUPT
EMT 41
BR     $48

```

```
.391 003656
1392 003656 005067 015646      28:
1393 003662 012700 177777      MOV #1,RO      ;CLEAR OUT THE INTERRUPT FLAG
1394 003666 005300      38:      DEC RO      ;TIMER
1395 003670 001376      BNE 38
1396 003672 005767 015632      TST INT+LG      ;GOT INTERRUPT?
1397 003676 001401      BEQ 48      ;BR, IF NO INTERRUPT (GOOD)
1398 003700      ERROR 42      ;DID NOT EXPECT 2ND INTERRUPT
      003700 104042
1399
1400 003702      48:
1401
1402 003702 106427      .WORD 106427      ;MTPS
1403 003704 000340      .WORD 340      ;DISABLE INTERR
1404
1405 003706 012767 022560 174164      MOV #ILLCLK,CLKVEC      ;RESTORE CLOCK VECTOR AREA
1406 003714 012767 000340 174160      MOV #340,CLKVEC+2
1407
1408 003722 106427      .WORD 106427      ;MTPS
1409 003724 000000      .WORD 0      ;ENABLE INTERRUPTS
```



```

1411
1412 003726 005067 016424      SLU:  CLR  PHASE2      ;INIT FOR TESTS
1413 003732 005067 175250      CLR  SUNIT          ;CONTAINS CHAN # UNDER TEST ( 0 OR 1 )
1414 003736 005067 016416      CLR  PICNT
1415
1416 003742 012706 001100      LOOP: MOV  #STACK,SP  ;RESET STACK POINTER
1417 003746 005767 015442      TST  NOCHAN         ;ANY CHANNELS TO TEST?
1418 003752 001404          BEQ  1$             ;BR IF YES
1419 003754 104401 001334      TYPE ,CARR
1420 003760 000167 020700      JMP  $EOP          ;ELSE ALI. DONE
1421
1422 003764 004767 015542      1$:  JSR  PC,CYCLE   ;ELSE SETUP MODULE AND CHANNEL
1423
1424 003770 016767 175316 175316  MOV  DLADD,RCSR
1425
1426 003776 016767 175310 175312  MOV  DLADD,RBUF
1427 004004 062767 000002 175304  ADD  #2,RBUF
1428
1429 004012 016767 175274 175300  MOV  DLADD,TCSR
1430 004020 062767 000004 175272  ADD  #4,TCSR
1431
1432 004026 016767 175260 175266  MOV  DLADD,TBUF
1433 004034 062767 000006 175260  ADD  #6,TBUF
1434
1435 004042 012706 177777          MOV  #-1,R0        ;DELAY TO ALLOW ANY PREVIOUS YMIT TO
1436 004046 077001          SOB  R0            ;FINISH BEFORE RESET
1437 004050 004567 016512          JSR  R5,TIMER     ;GO OUT TO TIMER
1438 004054 001320          TCSR
1439 004056 000200          DONE
1440 004060 000240          NOP
1441 004062 000240          NOP
1442 004064 000005          RESET
1443
1444 004066 005267 175112          INC  $DEVCT
1445 004072 126727 016260 000001  CMPB PHASE2,#TRUE  ;DOING PHASE 2?
1446 004100 001010          BNE  2$           ;BR IF NO
1447 004102 042777 000004 175210  BIC  #BIT2,@TCSR  ;ALWAYS TURN OFF INTERNAL MAINT. BIT
1448 004110 112767 000022 174764  MOVB #22,$STNM   ;GET TEST NUMBER READY
1449 004116 000167 005362          JMP  MODTST
1450
1451
28:

```

1464

```

*****
*TEST 5 ADDRESSABILITY
*
* THIS TEST VERIFIES THAT ALL 4 REGISTERS OF THE CHANNEL UNDER TEST
* RESPOND TO THEIR ADDRESSES.
*****
TST5: SCOPE
MOV #2,STIMES ;;DO 2 ITERATIONS
MOV #5,STESTN ;;SET TEST NUMBER IN APT MAIL BOX
NOP ;SPECIAL DEBUG FEATURE (GOOD HALT LOC)
BIC #BIT2,STCSR ;ALWAYS TURN OFF INTERNAL MAINT. BIT
MOV STSTMR,RO ;GET TEST NUMBER
COM RO ;1'S COMP TEST NUMBER
BIT #BIT6,SDEVN ;CAN THE LEDS BE USED
BNE 5018 ;OR, IF THEY CAN'T
MOVB RO,LEDREG ;DISPLAY TEST NUMBER IN LEDS

5018: MOV #INTSRV,ERRVEC ;SETUP TIMEOUT VECTOR
MOV #PR7,ERRVEC+2
CLR RO
MOV RCSR,R1
18: CLR INTFLG
TST (R1)+ ;DARE TO TIMEOUT
TST INTFLG ;DID IT?
BEQ 28 ;OR IF NO
ERROR 51 ;TIMEOUT ON CHANNEL ADDRESS

28: INC RO
CMP RO,#4 ;ALL DONE?
BNE 18 ;OR IF NO
MOV #6,ERRVEC ;RESTORE TIMEOUT VECTOR
CLR ERRVEC+2
BIT #177477,RCR ;CHECK THAT ALL UNUSED BITS ARE 0
BEQ 38
ERROR 52 ;RCR HAS UNUSED BITS SET

38: BIT #7400,RBUF
BEQ 48
ERROR 53 ;RBUF HAS UNUSED BITS SET

48: BIT #177476,STCSR
BEQ 58
ERROR 54 ;TCSR HAS UNUSED BITS SET

58: BIT #177400,STBUF
BEQ +4 ;EXIT IF OK
ERROR 55 ;TBUF HAS UNUSED BITS SET
EMT 55

```

004122	000004		
004124	012767	000002	175026
004132	012767	000005	175040
1469 004140	000240		
1472 004142	042777	000004	175150
1473 004150	016700	174726	
1474 004154	005100		
1475 004156	032767	000100	175066
1476 004164	001002		
1477 004166	110077	175112	
1478 004172			
1479 004172	012767	021522	173604
1480 004200	012767	000340	173600
1482 004206	005000		
1483 004210	016701	175100	
1485 004214	005067	015310	
1486 004220	005721		
1487 004222	005767	015302	
1488 004226	001401		
1489 004230			
004230	104051		
1491 004232	005200		
1492 004234	020027	000004	
1493 004240	001365		
1495 004242	012767	000006	173534
1496 004250	005067	173532	
1498 004254	032777	177477	175032
1499 004262	001401		
1500 004264			
004264	104052		
1502 004266	032777	007400	175022
1503 004274	001401		
1504 004276			
004276	104053		
1506 004300	032777	177476	175012
1507 004306	001401		
1508 004310			
004310	104054		
1510 004312	032777	177400	175002
1511 004320	001401		
1512 004322			
004322	104055		

1519  
1520  
1521  
1522  
1523  
1532

\*\*\*\*\*  
\* THE FOLLOWING 3 TESTS TEST ALL 'READ WRITE' BITS  
\*\*\*\*\*

\*\*\*\*\*  
\*TEST 6 BREAK - TCSR 0 SET, CLEAR, RESET  
\* THIS BIT IS THE ONLY ONE IN THIS POSITION  
\* THAT IS READ AND WRITE.  
\*\*\*\*\*

1537	004324	000004			TST6:	SCOPE		
	004326	012767	000010	174624		MOV	#10,\$TIMES	::DO 10 ITERATIONS
	004334	012767	000006	174636		MOV	#6,\$TESTN	::SET TEST NUMBER IN APT MAIL BOX
1538	004342	000240				NOP		:SPECIAL DEBUG FEATURE (GOOD HALT LOC)
1539	004344	042777	000004	174746		BIC	#BIT2,@TCSR	:ALWAYS TURN OFF INTERNAL MAINT. BIT
1540	004352	016700	174524			MOV	\$TSTNM,R0	:GET TEST NUMBER
1541	004356	005100				COM	R0	:1'S COMP TEST NUMBER
1542	004360	032767	000100	174664		BIT	#BIT6,\$DEVN	:CAN THE LEDS BE USED
1543	004366	001002				BNE	50,\$	:BR, IF THE/ CAN'T
1544	004370	110077	174710			MOVB	R0,@LEDREG	:DISPLAY TEST NUMBER IN LEDS
1545	004374	005767	015750		501\$:	TST	BRK	:BREAK DETECTION ENABLED?
1546	004374	001403				BEQ	1\$	:BR IF NO
1547	004400	005767	015746			TST	CONSOLE	:ELSE ARE WE ON CONSOLE?
1548	004402					SKIP	NE,<EXIT IF YES>	
1553	004410				1\$:			: SEE IF IT IS CLEAR
1554	004410							LPADR
1555	004410	012767	004416	174472		MOV	#64\$,\$LPERR	
1556	004416				64\$:			
1557	004416	032777	000001	174674		BIT	#BREAK,@TCSR	:IF #BREAK SET IN @TCSR THEN
1558	004424	001401				BEQ	10\$	:DID BREAK RESET TCSK
1559	004426					ERROR 61		:BR, IF NO ERROR
1560	004426	104061				EMT 61		
1561	004430				10\$:			:ENDIF
1562	004430							: TRY TO SET BREAK BIT
1563	004430	012767	004436	174452		MOV	#65\$,\$LPERR	LPADR
1564	004436				65\$:			
1565	004436	052777	000001	174654		BIS	#BREAK,@TCSR	:LET @TCSR := @TCSR SET.BY #BREAK
1566	004444							:SET BREAK TO A ONE
1567	004444	032777	000001	174646		BIT	#BREAK,@TCSR	: STUCK TO 0
1568	004452	001001				BNE	20\$	:IF #BREAK NOTSET IN @TCSR THEN
1569	004454					ERROR 62		:DID BIT GET SET
1570	004454	104062				EMT 62		: BREAK DID NOT SET IN TCSR
1571	004456				20\$:			:BR, IF NO ERROR
1572	004456							:ENDIF
1573	004456							: TRY TO CLEAR A SET BIT
1574	004456	012767	004464	174424		MOV	#66\$,\$LPERR	LPADR
1575	004464				66\$:			
1576	004464	042777	000001	174626		BIC	#BREAK,@TCSR	:LET @TCSR := @TCSR CLR.BY #BREAK

```
1577
1578 004472 032777 000001 174620      BIT      #BREAK,@TCSR
1579 004500 001401                      BEQ      308
1580
1581 004502                      ERROR 63
      004502 104063                      EMT 63
1582 004504                      308:
1583
1584
1585 004504                      MOV      #678,$LPERR
      004504 012767 004512 174376      678:
      004512
1586 004512 052777 000001 174600      BIS      #BREAK,@TCSR
1587
1588 004520 012700 177777      MOV      #-1,R0
1589 004524 077001      SOB     R0,,
1590 004526 000005      RESET
1591 004530 032777 000001 174562      BIT      #BREAK,@TCSR
1592 004536 001401                      BEQ      408
1593
1594 004540                      ERROR 64
      004540 104064                      EMT 64
1595 004542                      408:

```

```

: SHOULD HAVE CLEARED
: IF #BREAK SET IN @TCSR THEN
: BR, IF OK (NO ERROR)
: BREAK DID NOT CLEAR IN TCSR

:ENDIF

: NOW SEE IF RESET CLEARS IT
LPADR

:LET @TCSR := @TCSR SET.BY #BREAK
: ISSUE BUS RESET
:DELAY TO ALLOW ANY PREVIOUS XMIT TO
:FINISH BEFORE RESET

:IF #BREAK SET IN @TCSR THEN
:BR, IF NO ERROR BIT NOT SET
: BREAK DID NOT RESET IN TCSR

:ENDIF

```

1597  
1602

\*\*\*\*\*  
 :\*TEST 7 IE - TCSR 6 SET, CLEAR, RESET  
 \*\*\*\*\*

004542	000004			TST7:	SCOPE		
004544	012767	000010	174406		MOV #10,\$TIMES	::DO 10 ITERATIONS	
004552	012767	000007	174420		MOV #7,\$TESTN	::SET TEST NUMBER IN APT MAIL BOX	
1603						: USE PRIORITY OF 7	
1608	004560	000240			NOP	:SPECIAL DEBUG FEATURE (GOOD HALT LOC)	
1609							
1610	004562	042777	000004	174530	BIC #BIT2,@TCSR	:ALWAYS TURN OFF INTERNAL MAINT. BIT	
1611	004570	016790	174306		MOV \$TSTN,R0	:GET TEST NUMBER	
1612	004574	005100			COM R0	:1'S COMP TEST NUMBER	
1613	004576	032767	000100	174446	BIT #BIT6,\$DEVN	:CAN THE LEDS BE USED	
1614	004604	001002			BNE 501\$	:BR, IF THEY CAN'T	
1615	004606	110077	174472		MOVB R0,@LEDREG	:DISPLAY TEST NUMBER IN LEDS	
1616	004612			501\$:			
1621	004612	012746	000340		MOV #PR7,-(SP)	::PUT NEW PS ON STACK	
	004616	012746	004624		MOV #64\$,-(SP)	::PUT NEW PC ON STACK	
	004622	000002			RTI	::POP NEW PC AND PS	
	004624			64\$:			
1626							
1627						: SEE IF IT IS CLEAR	
1628	004624					LPADR	
	004624	012767	004632	174256	MOV #65\$,\$LPERR		
	004632			65\$:			
1629							
1630	004632	032777	000100	174460	BIT #IE,@TCSR	:IF #IE SET IN @TCSR THEN	
1631						: IE DID NOT RESET IN TCSR	
1632	004640	001401			BEG 50\$	:BR, IF NO ERROR	
1633	004642				ERROR 71		
	004642	104071			EMT 71		
1634	004644			50\$:		:ENDIF	
1635							
1636						: TRY TO SET IE BIT	
1637	004644					LPADR	
	004644	012767	004652	174236	MOV #66\$,\$LPERR		
	004652			66\$:			
1638	004652	052777	000100	174440	BIS #IE,@TCSR	:LET @TCSR := @TCSR SET BY #IE	
1639						: STUCK TO 0	
1640	004660	032777	000100	174432	BIT #IE,@TCSR	:IF #IE NOT SET IN @TCSR THEN	
1641						: XMIT DID NOT SET IN TCSR	
1642	004666	001001			BNE 60\$	:BR, IF NO ERROR	
1643	004670				ERROR 72		
	004670	104072			EMT 72		
1644	004672			60\$:		:ENDIF	
1645							
1646						: TRY TO CLEAR A SET BIT	
1647	004672					LPADR	
	004672	012767	004700	174210	MOV #67\$,\$LPERR		
	004700			67\$:			
1648	004700	042777	000100	174412	BIC #IE,@TCSR	:LET @TCSR := @TCSR CLR BY #IE	
1649						: SHOULD HAVE CLEARED	
1650	004706	032777	000100	174404	BIT #IE,@TCSR	:IF #IE SET IN @TCSR THEN	
1651						: XMIT DID NOT CLEAR IN TCSR	
1652	004714	001401			BEG 70\$	:BR, IF NO ERROR	
1653	004716				ERROR 73		

```
1654 004716 104073          EMT 73
1655 004720          70S:          :ENDIF
1656
1657 004720          : NOW SEE IF RESET CLEARS IT
      004720 012767 004726 174162      LPADR
      004726          :
1658 004726 052777 000100 174364      68S:  MOV    #68D,$LPERR
1659          :LET @TCSR := @TCSR SET.BY #IE
      000005          : ISSUE BUS RESET
1660 004734 016700 174140          RESET
1661 004736 005100          MOV    $TSTNM,R0
1662 004742 000100 174300          COM    R0
1663 004744 001002 174324          BIT    #BIT6,$DEVN
1664 004752 110077          BNE   502S
1665 004760 032777 000100 174332      502S:  MOVB  R0,@LEDREG
1666 004766 001401          BIT    #IE,@TCSR
1667 004770          : IF #IE SET IN @TCSR THEN
1668          : XMIT DID NOT RESET IN TCSR
1669 004772 104074          BEQ   80S
1670 004772          ERROR 74
1671 004772          EMT 74
      80S:          :ENDIF
```

1673  
1682

```

:*****
:TEST 10      IE - RCSR 6      SET, CLEAR, RESET
:             THIS BIT IS THE ONLY ONE IN THIS POSITION
:             THAT IS READ AND WRITE.
:*****

```

1687	004772	000004			TST10:	SCOPE		
1688	004774	012767	000010	174156		MOV	#10,STIMES	::DO 10 ITERATIONS
	005002	012767	000010	174170		MOV	#10,STESTN	::SET TEST NUMBER IN APT MAIL BOX
1689	005010	000240				NOP		:SPECIAL DEBUG FEATURE (GOOD HALT LOC)
1690	005012	042777	000004	174300		BIC	#BIT2,@TCSR	:ALWAYS TURN OFF INTERNAL MAINT. BIT
1691	005020	016700	174056			MOV	\$TSTNM,R0	:GET TEST NUMBER
1692	005024	005100				COM	R0	:1'S COMP TEST NUMBER
1693	005026	032767	000100	174216		BIT	#BIT6,\$DEVH	:CAN THE LEDS BE USED
1694	005034	001002				BNE	5018	:BR, IF THEY CAN'T
1695	005036	110077	174242		5018:	MOVB	R0,@LEDREG	:DISPLAY TEST NUMBER IN LEDS
1696	005042							: SEE IF IT IS CLEAR
1697	005042							LPADR
	005042	012767	005050	174040		MOV	#648,\$LPERR	
1698	005050	032777	000100	174236	648:	BIT	#IE,@RCSR	:IF #IE SET IN @RCSR THEN
1699								: IE DID NOT RESET IN RCSR
1700	005056	001401				BEG	1108	
1701	005060					ERRR	101	
	005060	104101				ENT	101	
1702	005062				1108:			:ENDIF
1703								: TRY TO SET IE BIT
1704	005062							LPADR
	005062	012767	005070	174020		MOV	#658,\$LPERR	
1705	005070	052777	000100	174216	658:	BIS	#IE,@RCSR	:LET @RCSR := @RCSR SET BY #IE
1706								: STUCK TO 0
1707	005076	032777	000100	174210		BIT	#IE,@RCSR	:IF #IE NOT SET IN @RCSR THEN
1708								: IE DID NOT SET IN RCSR
1709	005104	001001				BNE	1208	:BR, IF NO ERROR
1710	005106					ERRR	102	
	005106	104102				ENT	102	
1711	005110				1208:			:ENDIF
1712								: TRY TO CLEAR A SET BIT
1713	005110							LPADR
	005110	012767	005116	173772		MOV	#668,\$LPERR	
1714	005116	042777	000100	174170	668:	BIC	#IE,@RCSR	:LET @RCSR := @RCSR CLR BY #IE
1715								: SHOULD HAVE CLEARED
1716	005124	032777	000100	174162		BIT	#IE,@RCSR	:IF #IE SET IN @RCSR THEN
1717								: IE DID NOT CLEAR IN RCSR
1718	005132	001401				BEG	1308	:BR, IF NO ERROR
1719	005134					ERRR	103	
	005134	104103				ENT	103	
1720	005136				1308:			:ENDIF
1721								: NOW SEE IF RESET CLEARS II
1722	005136							LPADR
	005136	012767	005144	173744		MOV	#678,\$LPERR	
1723	005144	052777	000100	174142	678:	BIS	#IE,@RCSR	:LET @RCSR := @RCSR SET BY #IE

```
1724  
1725 005152 000005 RESET : ISSUE BUS RESET  
1726 005154 016700 173722 MOV $TSTNM,RO :GET TEST NUMBER  
1727 005160 005100 COM RO :1'S COMP TEST NUMBER  
1728 005162 032767 000100 174062 BIT #BIT6,$DEVN :CAN THE LEDS BE USED  
1729 005170 001002 BNE 502$ :BR, IF THEY CAN'T  
1730 005172 110077 174106 MOVB RO,@LEDREG :DISPLAY TEST NUMBER IN LEDS  
1731 005176 502$:  
1732 005176 032777 000100 174110 BIT #IE,@RCSR :IF #IE SET IN @RCSR THEN  
1733 BEQ 140$ : IE DID NOT RESET IN RCSR  
1734 005204 001401 ERROR 104 :BR, IF NO ERROR  
1735 005206 104104 EMT 104  
1736 005210 140$:  
1737 005210 012767 005216 173672 MOV #18,$LPERR :ENDIF  
1738 :XMIT RDY SHOULD BE SET BY RESET ABOVE  
1739 005216 032777 000200 174074 18: BIT #RDY,@TCSR  
1744 005224 001013 BNE TST11 ;;EXIT IF SET  
1749 005226 104105 ERROR 105  
1750 EMT 105  
1751 005230 000005 RESET :ALLOW LOOPING ON ERROR  
1752 005232 016700 173644 MOV $TSTNM,RO :GET TEST NUMBER  
1753 005236 005100 COM RO :1'S COMP TEST NUMBER  
1754 005240 032767 000100 174004 BIT #BIT6,$DEVN :CAN THE LEDS BE USED  
1755 005246 001002 BNE 503$ :BR, IF THEY CAN'T  
1756 005250 110077 174030 MOVB RO,@LEDREG :DISPLAY TEST NUMBER IN LEDS  
1757 005254 503$:  
1758
```



1760  
1769

\*\*\*\*\*  
\*TEST 11 TEST THAT XMIT RDY - TCSR 7 - CLEARS  
\* WHEN TBUF IS LOADED WITH A CHARACTER  
\* AND THAT IT SETS WITHIN A REASONABLE AMOUNT OF TIME.  
\*\*\*\*\*

005254 000004  
005256 012767 000010 173674  
005264 012767 000011 173706  
1774 005272 000240  
1775 005274 042777 000004 174016  
1776 005302 016700 173574  
1777 005306 005100  
1778 005310 032767 000100 173734  
1779 005316 001002  
1780 005320 110077 173760  
1781 005324  
1782  
1783  
1784 005324 005767 015024  
1785 005330  
1790  
1791 005332 005067 000164  
1792 005336  
1793  
1794 005336 005067 000162  
1795 005342 005067 000160  
1796  
1797  
1798  
1799  
1800  
1801 005346 105077 173750  
1802  
1803 005352 004567 015210  
1804 005356 001320  
1805 005360 000200  
1806 005362  
005362 104111  
1811 005364 000461  
1816  
1817 005366 105077 173730  
1818 005372 105777 173722  
1819 005376 100375  
1820  
1821  
1822  
1823  
1824 005400 105077 173716  
1825 005404 000240  
1826  
1827  
1828 005406 032777 000200 173704  
1829 005414 001404  
1830  
1831  
1832 005416 012767 177777 000100

TST11: SCOPE  
MOV #10,\$TIMES ;;DO 10 ITERATIONS  
MOV #11,\$TESTN ;;SET TEST NUMBER IN APT MAIL BOX  
NOP ;SPECIAL DEBUG FEATURE (GOOD HALT LOC)  
BIC #BIT2,@TCSR ;ALWAYS TURN OFF INTERNAL MAINT. BIT  
MOV \$STNM,RO ;GET TEST NUMBER  
COM RO ;1'S COMP TEST NUMBER  
BIT #BIT6,\$DEVN ;CAN THE LEDS BE USED  
BNE 5018 ;BR, IF THEY CAN'T  
MOVB RO,@LEDREG ;DISPLAY TEST NUMBER IN LEDS  
5018:  
: TST WRAP ;CAN WE TEST DATA WRAP  
: SKIP NE,<EXIT IF N?>  
: TST CONSOLE ;ARE WE ON CONSOLE?  
: SKIP NE,<EXIT IF YES>  
1508: CLR PASS ;LET PASS := #0 ;INIT COUNT OF TIMES THRU  
;LOOP START OF LOOP  
: ; MAX OF 2 TIMES THRU  
CLR ERRFLG ;LET ERRFLG := #0  
CLR EXFLG ;LET EXFLG := #0  
; LOAD TBUF WITH ONE CHARACTER  
; WAIT FOR READY TO SET  
; (SHOULD BE VERY SHORT WAIT  
; SINCE UART DOUBLE BUFFERS ITS INPUT)  
;SEND A CHARACTER  
;LET @TB' ' :B= #0  
CLRB @TBUF  
JSR R5,TIMER ;WAIT FOR XMIT READY  
TCSR  
RDY  
ERROR 111 ;XMIT RDY DID NOT SET IN TCSR  
EAT 111  
BR TST12 ;;EXIT TEST  
18: CLRB @TBUF ;SHIP 1'ST CHAR  
TSTB @TCSR ;WAIT FOR RDY  
BPL 18  
; LOAD TBUF WITH A SECOND CHARACTER (TO DOUBLE RUFFE  
; CHECK IMMEDIATELY THAT RDY IS CLEAR  
; AND THEN WAIT FOR IT TO SET  
;SEND SECOND CHARACTER  
CLRB @TBUF ;LET @TBUF :B= #0  
NOP ;GIVE IT TIME TO CLEAR  
; RDY SHOULD HAVE CLEARED UPON  
; RECEIPT OF A CHARACTER  
BIT #RDY,@TCSR ;IF #RDY SET IN @TCSR THEN  
BEQ 1708 ;BR, IF READY DID CLEAR  
; RDY DID NOT CLEAR IN TCSR  
;WILL RESULT IN ERR 67 IF FAILS 2X  
MOV #SET,ERRFLG ;LET ERRFLG := #SET

```

1833
1834 005424 000406
1835 005426          170$: BR      200$           ; DEFER ERROR TYPEOUT
1836 005426 004567 015134 JSR     R5,TIMER         ;ELSE
1837 005432 001320          TCSR          ;WAIT FOR XMIT READY
1838 005434 000200          RDY
1839 005436          ERROR 112           ;XMIT RDY DID NOT SET IN TCSR
      005436 104112          EMT 112
1844 005440 000433          BR      TS:12           ;;EXIT TEST
1849 005442          200$: CMP     ERRFLG,#SET        ;ENDIF OF DEFERED ERROR CALL
1850 005442 026727 000056 177777 B'E    210$           ;IF ERRFLG EQ #SET THEN
1851 005450 001013          INC    PASS           ;BR, IF NO ERROR
1852 005452 005267 000044          CM?   PASS,#1        ;LET PASS := PASS + #1
1853 005456 026727 000040 000001          ;IF PASS GT #1 THEN
1854          ;CALL ERROR IF 2ND TRY
1855          ;ON XMIT RDY NOT CLEARING
1856 005464 003404          B_E    220$           ;BR, NO ERROR
1857 005466          ERROR 113
      005466 104113          EMT 113
1858 005470 012767 177777 000030 MOV    #SET,EXFLG     ;LET EXFLG := #SET
1859 005476          220$: BR      230$           ;ENDIF
1860 005476 000403          BR      230$           ;ELSE NO ERROR
1861 005500          210$: MOV    #SET,EXFLG     ;LET EXFLG := #SET
1862 005500 012767 177777 000020          ;ENDIF
1863 005506          230$: CMP    EXFLG,#SET        ;EXIF EXFLG EQ #SET
1864 005506 026727 000014 177777 BEQ    160$           ;BR, IF NO ERROR
1865 005514 001401          BR      150$           ;ENDLOOP
1866          ;LOOP
1867 005516 000707          BR      150$
1868 005520          160$: BR      .+10
1869 005520 000403          BR      .+10
1870          ;EXIT TEST
1871 005522 000000          PASS:      0
1872 005524 000000          ERRFLG:   0
1873 005526 000000          EXFLG:    0
  
```

1875  
 1884  
 1885

```

*****
:TEST 12      TEST OUTPUT CHAR FROM TBUF (WRAP CONNECTED)
:             RESULTS IN DONE SETTING WITHIN A REASONABLE AMOUNT OF TIME
:             AND THAT RESET CLEARS THE BIT.
*****
1890 005530 000004 000010 173420  TST12: SCOPE
1891 005532 012767 000012 173432  MOV #10,STIMES ;;DO 10 ITERATIONS
1892 005540 012767 000012 173432  MOV #12,STESTN ;;SET TEST NUMBER IN APT MAIL BOX
1893 005546 000240 000000 000000  NOP ;;SPECIAL DEBUG FEATURE (GOOD HALT LOC)
1894 005550 042777 000004 173542  BIC #BIT2,@TCSR ;ALWAYS TURN OFF INTERNAL MAINT. BIT
1895 005556 016700 173320 000000  MOV $TSTNM,R0 ;GET TEST NUMBER
1896 005562 055100 000000 000000  COM R0 ;1'S COMP TEST NUMBER
1897 005564 032767 000100 173460  BIT #BIT6,$DEVN ;CAN THE LEDS BE USED
1898 005572 001002 000000 000000  BNE 5018 ;BR, IF THEY CAN'T
1899 005574 110077 173504 000000  MOVB R0,@LEDREG ;DISPLAY TEST NUMBER IN LEDS
1900 005600 005767 014546 000000 5018: TST WRAP ;DOING DATA WRAP TESTS?
1901 005604 005767 014542 000000  SKIP NE,<EXIT IF NO>
1902 005606 005767 014542 000000  TST CONSOLE ;ARE WE ON CONSOLE?
1903 005612 005767 014542 000000  SKIP NE,<EXIT IF YES>
1904 005614 012767 005622 173266  MOV #64$,SLPERR LPADR
1905 005622 005622 005622 173266 64$:
1906 005622 032767 001000 173422  BIT #BIT9,$DEVN ; SEND A CHARACTER AND LET IT WRAP AROUND
1907 005630 001403 000000 000000  BEQ 235$ ;INTERNAL OR EXTERNAL
1908 005632 052777 000004 173460  BIS #BIT2,@TCSR ;BR, IF EXTERNAL
1909 005640 105077 173456 000000 235$: CLRB @TBUF ;SET MAINTENANCE BIT INT LOOP
1910 005644 004567 014716 000000  JSR R5,TIMER ;LET @TBUF :B= #0
1911 005650 001314 000000 000000  ;WAIT FOR RECV DONE
1912 005652 000200 000000 000000  RCSR
1913 005654 104121 000000 000000  ERROR 121 ;RECV DONE DID NOT SET IN RCSR
1914 005656 000415 000000 000000  EMT 121
1915 005656 000415 000000 000000  BR TST13 ;;EXIT TEST
1916 005660 000000 000000 000000  LPADR
1917 005660 012767 005666 173222  MOV #65$,SLPERR
1918 005666 005666 005666 173222 65$:
1919 005666 016702 173420 000000  MOV PL,ADD,R2 ; NOW THAT IT IS SET SEE IF IT CAN BE RESET
1920 005672 062702 000002 000000  ADD #2,R2 ;LOAD R2 WITH BASE ADDR
1921 005676 011203 000000 000000  MOV (R2),R3 ;BUMP R2 TO POINT TO RBUF
1922 005700 032777 000200 173406  BIT #DONE,@RCSR ;DUMMY READ OF BUFFER
1923 005706 001401 000000 000000  ;IF #DONE SET IN @RCSR THEN
1924 005710 000000 000000 000000  ; DONE DID NOT RESET IN RCSR.
1925 005710 104122 000000 000000  ;BR, IF NO ERROR
1926 005712 000000 000000 000000 240$: EMT 122
1927 005712 000000 000000 000000 ;ENDIF

```

1938  
1943

```

:*****1*****
:*TEST 13 TEST THAT DONE IS CLEARED BY READING RBUF
:*****
  
```

005712 000004  
 005714 012767 000010 173236  
 005722 012767 000013 173250

```

TST13: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #15,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
  
```

1948

1949 005730 000240  
 1950 005732 042777 000004 173360  
 1951 005740 016700 173136  
 1952 005744 005100  
 1953 005746 032767 000100 173276  
 1954 005754 001002  
 1955 005756 110077 173322

```

NOP ;SPECIAL DEBUG FEATURE (GOOD HALT LOC)
BIC #BIT2,@TCSR ;ALWAYS TURN OFF INTERNAL MAINT. BIT
MOV $TSTNM,RO ;GET TEST NUMBER
COM RO ;1'S COMP TEST NUMBER
BIT #BIT6,$DEVH ;CAN THE LEDS BE USED
BNE 501$ ;BR, IF THEY CAN'T
MOVB RO,@LEDREG ;DISPLAY TEST NUMBER IN LEDS
  
```

1956 005762  
 1957 005762 005767 014364  
 1958 005766  
 1959 005770 005767 014360  
 1960 005774

```

501$: TST WRAP .DOING DATA WRAP TESTS?
SKIP NE,<EXIT IF NO>
TST CONSOLE ;ARE WE ON CONSOLE?
SKIP NE,<EXIT IF YES>
  
```

1965

1966 005776  
 005776 012767 006004 173104  
 006004

```

64$: MOV #64,$LPERR LPADR
  
```

1967

1968  
 1969 006004 032767 001000 173240  
 1970 006012 001403  
 1971 006014 052777 000004 173276  
 1972 006022 105077 173274

```

; OUTPUT A CHARACTER AND WAIT FOR DONE TO SET.
; OUTPUT A CHARACTER
; INTERNAL OR EXTERNAL
; BK, IF EXTERNAL
245$: BIS #BIT2,@TCSR ;SET MAINTENANCE BIT INT LOOP
CLRB @TBUF ;LET @TBUF :B= #0
  
```

1973  
 1974 006026 004567 014534  
 1975 006032 001314  
 1976 006034 000200

```

JSR R5,TIMER ;WAIT FOR RECV DONE
RCSR
DONE
  
```

1977 006036  
 006036 104131  
 1982 006040 000407

```

ERROR 131 ;RECV DONE DID NOT SET IN RCSR
EMT 131
BR TST14 ;;EXIT TEST
  
```

1987

1988

1989

1990

1991 006042 117700 173250  
 1992 006046 032777 000200 173240

```

; NOW THAT IT IS SET LETS SEE IF READING THE
; BUFFER CLEARS DONE.
; READ BUFFER
; LET RO :B= @RBUF
; IF #DONE SET IN @RCSR THEN
; DONE DID NOT CLEAR IN RCSR
; BR, IF NO ERROR
  
```

1993

1994 006054 001401  
 1995 006056  
 006056 104132

```

BEQ 250$
ERROR 132
EMT 132
  
```

1996

1997 006060

```

250$: ; SET IT BACK TO CONTINUE
;ENDIF
  
```

1999  
 2004

006060 000004  
 006062 012767 000010 173070  
 006070 012767 000014 173102  
 2005 006076 000240  
 2006 006100 052777 000004 173212  
 2007 006106 042777 000004 173204  
 2008 006114 005767 014232  
 2009 006120 001136  
 2010 006122 005767 014226  
 2011 006126 001133  
 2016  
 2017 006130 016700 172746  
 2018 006134 005100  
 2019 006136 032767 000100 173106  
 2020 006144 001002  
 2021 006146 110077 173132  
 2022 006152  
 2023  
 2024 006152  
 006152 012767 006160 172730  
 006160  
 2025  
 2026  
 2027  
 2028  
 2029 006160 032767 001000 173064  
 2030 006166 001403  
 2031 006170 052777 000004 173122  
 2032 006176 105077 173120  
 2033  
 2034 006202 004567 014360  
 2035 006206 001314  
 2036 006210 000200  
 2037 006212  
 006212 104141  
 2042 006214 000500  
 2047  
 2048  
 2049 006216 032767 001000 173026  
 2050 006224 001403  
 2051 006226 052777 000004 173064  
 2052 006234 105077 173062  
 2053 006240 004767 014440  
 2054  
 2055 006244 017704 173046  
 2056  
 2057 006250 032704 040000  
 2058  
 2059 006254 001002  
 2060 006256  
 006256 104142  
 2061  
 2066 006260 000456

```

:*****
:*TEST 14 TEST THE OVERRUN & ERROR BITS - RBUF 14
:*****
TST14: SCOPE
MOV #10,%TIMES ;;DO 10 ITERATIONS
MOV #14,%TESTN ;;SET TEST NUMBER IN APT MAIL BOX
NOP ;SPECIAL DEBUG FEATURE (GOOD HALT LOC)
BIS #BIT2,%TCSR ;SET MAINTENANCE BIT INT LOOP
BIC #BIT2,%TCSR ;ALWAYS TURN OFF INTERNAL MAINT. BIT
TST WRAP ;DOING DATA WRAP TESTS?
BNE TST15 ;;EXIT IF NO
TST CONSOLE ;ARE WE ON CONSOLE?
BNE TST15 ;;EXIT IF YES

MOV %STMM,%RO ;GET TEST NUMBER
COM RO ;1'S COMP TEST NUMBER
BIT #BIT6,%SDEVN ;CAN THE LEDS BE USED
BNE %S01S ;BR, IF THEY CAN'T
MOVB RO,%LEDREG ;DISPLAY TEST NUMBER IN LEDS

501S:
MOV #64,%SLPERR LPADR
64S:
;OUTPUT 2 CHARACTERS
;THIS SHOULD AN CAUSE OVERRUN ERROR.

;OUTPUT 1 CHARACTER
;INTERNAL OR EXTERNAL
;BR, IF EXTERNAL
;SET MAINTENANCE BIT INT LOOP
;LET %TBUF :B= #0
255S:
BIS #BIT9,%SDEVN
BEQ %S255S
CLR %TBUF
JSR R5,%TIMER ;WAIT FOR RECV DONE
RCSR
DONE
ERROR 141 ;RECV DONE DID NOT SET IN RCSR
EMT 141
BR TST15 ;;EXIT TEST

;OUTPUT 2ND CHARACTER
;INTERNAL OR EXTERNAL
;BR, IF EXTERNAL
;SET MAINTENANCE BIT INT LOOP
;LET %TBUF :B= #0
;LET OVERRUN HAPPEN
;READ BUFFER AND ERROR BITS
;LET R4 := %RBUF
;IT DIDN'T SET
;IF %ORERR NOTSET IN R4 THEN
;ORERR DID NOT SET IN RBUF
;BR, IF NO ERROR
257S:
BIS #BIT9,%SDEVN
BEQ %S257S
BIS #BIT2,%TCSR
CLR %TBUF
JSR PC,%WAIT
MOV %RBUF,%R4
BIT #ORERR,%R4
BNE %S260S
ERROR 142
EMT 142
BR TST15 ;NO USE COMPOUNDING ERRORS
;;EXIT TEST
  
```



```
2142
2147 006402 000405
2152 006404          3108: BR      TST15          ::EXIT TEST      :SKIP AROUND REST
2153                                     :ENDIF
2154 006404 032777 100000 172704 BIT #ERR15,RBUF :IF #ERROR SET IN RBUF THEN
2155                                     :ERROR DID NOT CLEAR IN RBUF
2156 006412 001401 BEQ      3208          :BR, IF NO ERROR
2157 006414          ERROR 147
          006414 104147 EMT 147
2158
2159 006416          3208:                                     :ENDIF
```

2161  
2173

```

*****
*TEST 15 TRANSMITTER INTERRUPT LOGIC TEST
* LOGICALLY THIS IS 4 SEPARATE TESTS
* A) DOES TRANSMITTER INTERRUPT LOGIC WORK
* B) AT PRIORITY OF 0
* C) AND ONLY ONCE
* D) BUT NOT WITH INTERRUPT ENABLE CLEAR
*****
  
```

```

006416 000004
006420 012767 000010 172532
006426 012767 000015 172544
2178 006434 000240
2179
2180 006436 042777 000004 172654
2181 006444 016700 172432
2182 006450 005100
2183 006452 032767 000100 172572
2184 006460 001002
2185 006462 110077 172616
2186 006466
2187
2188 006466 005067 013036
2189
2190 006472 016703 172626
2191 006476 062703 000004
2192 006502 012723 021522
2193 006506 012713 000340
2194 006512
      J06512 012767 006520 172370
      006520
2195 006520 004567 014042
2196 006524 001320
2197 006526 000200
2198 006530
      006530 104151
2203 006532 000453
2208
2209 006534 042777 000100 172556
221' 006542 012746 000000
      006546 012746 006554
      006552 000002
      006554
2219
2220 006554 052777 000100 172536
2221 006562 004567 014054
2222 006566 021530
2223 006570
      006570 104152
2228 006572 000433
2233
2234 006574 026727 013554 000000
2235 006602 001007
2236 006604 004767 014074
2237
2238 006610 026727 012714 000001
2239
TST15: SCOPE
      MOV #10,STIMES ;;DO 10 ITERATIONS
      MOV #15,STESTN ;;SET TEST NUMBER IN APT MAIL BOX
      NOP ;;SPECIAL DEBUG FEATURE (GOOD HALT LOC)
5018:
      BIC #BIT2,@TCSR ;ALWAYS TURN OFF INTERNAL MAINT. BIT
      MOV STSTNM,R0 ;GET TEST NUMBER
      COM R0 ;1'S COMP TEST NUMBER
      BIT #BIT6,$DEVN ;CAN THE LEDS BE USED
      BNE 5018 ;BR, IF THEY CAN'T
      MOVB R0,@LEDREG ;DISPLAY TEST NUMBER IN LEDS
648:
      CLR INTFLG
      MOV DLVEC,R3
      ADD #4,R3 ;GET XMIT VECT ADDR
      MOV #INTSRV,(R3)+
      MOV #PR7,(R3)
      LPADR
      MOV #648,$LPERR
      JSR R5,TIMER ;WAIT FOR XMIT READY
      TCSR
      RDY
      ERROR 151 ;XMIT RDY DID NOT SET IN TCSR
      EMT 151
      BR TST16 ;;EXIT TEST
      ;CLEAR INTERRUPT ENABLE
      ;LET @TCSR := @TCSR CLR.BY #IE
      ;PUT NEW PS ON STACK
      ;PUT NEW PC ON STACK
      ;POP NEW PC AND PS
658:
      BIS #IE,@TCSR ;NOW SET I.E. BIT
      JSR R5,TIMER+1 ;LET @TCSR := @TCSR SET.BY #IE
      INTFLG ;SFE IF FLAG SETS
      ERROR 152 ;INTERR FLAG DID NOT SET
      EMT 152
      BR TST16 ;;EXIT TEST
      ;BYPASS THIS PART IF CONSOLE
      ;IF CONSOLE EQ 0 THEN ;;000 IS 0 CORRECT???
      ;BR, IF NO ERROR
      JSR PC,WAIT ;LET POSSIBLE 2'ND INTERR OCCUR
      ;DID EXACTLY 1 INTERRUPT OCCUR
      ;IF INTFLG GT #1 THEN
      ;TRANSMITTER INTERRUPTED TWICE
  
```



```

2240 006616 003401          BLE      3408          :BR, IF NO ERROR
2241 006620          ERROR    153
      006620 104153          EMT 153
2242 006622          3408:          :ENDIF
2243 006622          3308:          :ENDIF
2244
2245
2246 006622          :INTERRUPT WITHOUT INTERRUPT ENABLE SET
      006622 012767 006630 172260 668: MOV      #668,SLPERR LPADR
      006630
2247
2248 006630 042777 000100 172462 BIC      #IE,@TCSR      :CLEAR INTERRUPT ENABLE
2249
2250 006636 005067 012666          CLR      INTFLG        :LET @TCSR := @TCSR CLR.BY #IE
2251
2252
2253 006642 005077 172454          CLR      @TBUF         :CLEAR 'INTERRUPT OCCURED' FLAG
2254
2255 006646 004767 014032          JSR      PC,WAIT       :LET INTFLG := #0
2256 006652 005767 012652          TST      INTFLG        :NO INTERRUPTS SHOULD OCCUR, PSW STILL AT 0.
2257 006656 001401          BEQ      .+4           :DARE IT TO HAPPEN
2258 006660 104154          ERROR    154          :LET @TBUF := #0
      006660
2259
2260

```

:BR IF NO  
:INTERR FLAG OCCURED WITH IE DISABLED

2262  
 2272

```

*****
*TEST 16 RECEIVER INTERRUPT LOGIC TEST
* THIS TEST COVERS ALL OF THE RECEIVER
* SIDE OF THE INTERRUPT LOGIC IN
* CHARACTER MODE.
*****
  
```

```

006662 000004
006664 012767 000010 172266
006672 012767 000016 172300
2273 006700 000240
2274 006702 042777 000004 172410
2275 006710 005767 013436
2276 006714 001135
2277 006716 005767 013432
2278 006722 001132
2283
2284 006724 042777 000004 172366
2285 006732 016700 172144
2286 006736 005100
2287 006740 032767 000100 172304
2288 006746 001002
2289 006750 110077 172330
2290 006754
2291
2292
2293 006754 016701 172344
2294 006760 012721 021522
2295 006764 012711 000340
2296
2297
2298 006770
006776 012767 006776 172112
006776
2299 006776 005067 012526
2300
2301 007002 042777 000100 172304
2302
2303
2308 007010 012746 000000
007014 012746 007022
007020 000002
007022
2313
2314 007022 032767 001000 172222
2315 007030 001403
2316 007032 052777 000004 172260
2317 007040 105077 172256
2318 007044 004567 013516
2319 007050 001320
2320 007052 000200
2321 007054
007054 144161
2326 007056 000454
2331
2332
2333 007060 052777 000100 172226
  
```

```

TST16: SCOPE
MOV #10,STIMES ;;DO 10 ITERATIONS
MOV #16,STESTN ;;SET TEST NUMBER IN APT MAIL BOX
NOP ;;SPECIAL DEBUG FEATURE (GOOD HALT LOC)
BIC #BIT2,@TCSR ;;ALWAYS TURN OFF INTERNAL MAINT. BIT
TST WRAP ;;DOING DATA WRAP TESTS?
BNE TST17 ;;EXIT IF NO
TST CONSOLE ;;ARE WE ON CONSOLE?
BNE TST17 ;;EXIT IF YES

BIC #BIT2,@TCSR ;;ALWAYS TURN OFF INTERNAL MAINT. BIT
MOV $STNM,R0 ;;GET TEST NUMBER
COM R0 ;;1'S COMP TEST NUMBER
BIT #BIT6,$DEVN ;;CAN THE LEDS BE USED
BNE $018 ;;BR, IF THEY CAN'T
MOVB R0,$LEDREG ;;DISPLAY TEST NUMBER IN LEDS

501$:
;;CLEAR INTERRUPT OCCURED FLAG
;;SET UP RECEIVER INTER.VECTOR

MOV DLVEC,R1
MOV #INTSRV,(R1)+
MOV #PR7,(R1)

;;PRIORITY 0 AND MULTIPLE INTERRUPT TEST.-IE
LPADR

64$: MOV #64,$LPERR
CLR INTFLG ;;LET INTFLG := #0
;;CLEAR INTERRUPTS
BIC #IE,@RCSR ;;LET @RCSR := @RCSR CLR.BY #IE
;;CHANGE PRIORITY
...TO 0
;;PUT NEW PS ON STACK
;;PUT NEW PC ON STACK
;;POP NEW PC AND PS

65$:
;;SEND A CHARACTER
;;INTERNAL OR EXTERNAL
BEQ $3458 ;;BR, IF EXTERNAL
BIS #BIT2,@TCSR ;;SET MAINTENANCE BIT INT LOOP
CLRB @TBUF ;;LET @TBUF := #0
JSR R5,TIMER ;;WAIT FOR XMIT READY

TCSR
RDY
ERROR 161 ;;XMIT RDY DID NOT SET IN TCSR
EMT 161
BR TST17 ;;EXIT TEST

BIS #IE,@RCSR ;;SET INTERRUPT ENABLE
;;LET @RCSR := @RCSR SET.BY #IE
  
```

```

2334
2335 007066 004567 013550      JSR      R5,TIMER1          ;SEE IF FLAG SETS
2336 007072 021530              INTFLG
2337 007074 104162              ERROR 162                  ;INTERR FLAG DID NOT SET
                                EMT 162
2342 007076 000444              BR      TST17              ;;EXIT TEST
2347
2348 007100 004767 013600      JSR      PC,WAIT
2349                                ;LET POSSIBLE 2'ND INTERR OCCUR
2350
2351 007104 026727 012420 000001  CMP      INTFLG,#1          ;EXACTLY 1 INTERRUPT?
2352                                ;IF INTFLG GT #1 THEN
2353 007112 003401              ' BLE     3508              ;RECEIVER INTERRUPTED TWICE
2354 007114 104163              ERROR 163                  ;BR, IF NO ERROR
                                EMT 163
2355 007116 3508:
2356
2357                                ;INTERRUPT WITHOUT IE SCT.
2358 007116 012767 007124 171764 668:  MOV     #668,$LPERR        LPADR
                                007116
                                007124
2359
2360 007124 042777 000100 172162  BIC     #IE,$RCSR          ;CLEAR INTERRUPT
2361                                ;LET $RCSR := $RCSR CLR.BY #IE
2362 007132 005067 012372              CLR     INTFLG            ;CLEAR INTERRUPT FLAG
2363                                ;LET INTFLG := #0
2364 007136 032767 001000 172106  ' BIT     #BIT9,$DEVN        ; SEND A CHARACTER
2365 007144 001403              BEQ     3558              ;INTERNAL OR EXTERNAL
2366 007146 052777 000004 172144  BIS     #BIT2,$TCSR        ;BH, IF EXTERNAL
2367 007154 105077 172142 3558:  CLRB   $TBUF              ;SET MAINTENANCE BIT INT LOOP
2368                                ;LET $TBUF :B= #0
2369 007160 004767 013520              JSR     PC,WAIT            ; DARE IT
2370 007164 005767 012340              TST     INTFLG            ;SEE IF INTERR FLAG EVER SETS
2371 007170 001401              BEQ     +4
2372 007172 104164              ERROR 164                  ;BR IF NO
                                EMT 164              ;INTERR FLAG OCCURED WITH IE DISABLED
2373
2378 007174 012746 000340              MOV     #PR7,-(SP)         ;;PUT NEW PS ON STACK
                                007200 012746 007206      MOV     #678,-(SP)         ;;PUT NEW PC ON STACK
                                007204 000002              RTI                          ;;POP NEW PC AND PS
                                007206
2383 007206 000005 678:  RESET
2384                                ;CLEAR THE WORLD
  
```

2386  
2391

```

*****
:TEST 17      TEST DATA WRAP AROUND  BINARY COUNT: FLAG MODE
*****
TST17:  SCOPE
        MOV     #1, @TIMES           ;;DO 1 ITERATION
        MOV     #17, @TESTN        ;;SET TEST NUMBER IN APT MAIL BOX
        NOP
        BIC     #BIT2, @TCSR        ;SPECIAL DEBUG FEATURE (GOOD HALT LOC)
        TST     WRAP                ;ALWAYS TURN OFF INTERNAL MAINT. BIT
        BNE    TST20                ;DOING DATA WRAP TESTS?
        TST     CONSOLE              ;;EXIT IF NO
        BNE    TST20                ;ARE WE ON CONSOLE?
        TST     CONSOLE              ;;EXIT IF YES
        BNE    TST20

        MOV     @STNM, R0            ;GET TEST NUMBER
        COM     R0                   ;1'S COMP TEST NUMBER
        BIT     #BIT6, @DEVN        ;CAN THE LEDS BE USED
        BNE    501$                 ;BR, IF THEY CAN'T
        MOVB   R0, @LEDREG          ;DISPLAY TEST NUMBER IN LEDS
501$:   MOV     @RBUF, R4            ;READ REGISTER TO ASSURE DONE CLF.
        ;BINARY COUNT PATTERN
        ;INCR R2 FROM #0 TO #377 BY #1
        CLR    R2
        BR     360$
370$:  INC     R2
360$:  CMP     R2, #377              ;CMP FOR END
        BGT    400$                 ;BR, IF GREATER THAN
        JSR    R5, TIMER            ;WAIT FOR XMIT READY
        TCSR   RDY
        ERROR  171                   ;XMIT RDY DID NOT SET IN TCSR
        EMT   171
        BR     TST20                ;;EXIT TEST

        BIT     #BIT9, @DEVN        ;START IT ON ITS WAY
        BEQ    365$                 ;INTERNAL OR EXTERNAL
        BIS    #BIT2, @TCSR        ;BR, IF EXTERNAL
        MOVB   R2, @TBUF            ;SET MAINTENANCE BIT INT LOOP
        ;LET @TBUF :B= R2
        JSR    R5, TIMER            ;WAIT FOR RECV DONE
        RCSR   DONE
        ERROR  172                   ;RECV DONE DID NOT SET IN RCSR
        EMT   172
        BR     TST20                ;;EXIT TEST

        MOV     @RBUF, R3           ;RETRIEVE
        ;LET R3 := @RBUF
        BIT     #ERR15, R3          ;CHECK FOR ERROR DURING TRANSFER
        ;IF #ERROR SET IN R3 THEN
        BEQ    410$                 ;ERROR BIT SET IN HIGH BYTE OF RBUF
        ERROR  173                   ;BR, IF NO ERROR
        EMT   173
410$:  CMP     R3, R2                ;ENDIF
        ;CLAPARE DATA
  
```

2459	007404	001402		BEG	48				
2460	007406			ERROR	174				:BR IF OK
	007406	104174		EMT	174				:DATA COMPARE ERR IN 8 BIT WORD
2465	007410	000401		BR	TST20			::EXIT TEST	
2467									
2468	007412		48:						:ENDINC :R2
2469	007412	000734		BR	3708				:LOOP
2470	007414		4008:						

2472  
2477

\*\*\*\*\*  
 : \*TEST 20 TEST DATA WRAP AROUND BINARY COUNT: INTERRUPT MODE  
 : \*\*\*\*\*

007414 000004  
 007416 012767 000001 171534  
 007424 012767 000020 171546  
 2482 007432 000240  
 2483  
 2484 007434 042777 000004 171656  
 2485 007442 016700 171434  
 2486 007446 005100  
 2487 007450 032767 000100 171574  
 2488 007456 001002  
 2489 007460 110077 171620  
 2490 007464  
 2491 007464 005767 012662  
 2492 007470 001003  
 2493 007472 005767 012656  
 2494 007476 001402  
 2495 007500 000167 000232  
 2496 007504

TS120: SCOPE

MOV #1,STIMES ;DO 1 ITERATION  
 MOV #20,STESTN ;SET TEST NUMBER IN APT MAIL BOX  
 NOP ;SPECIAL DEBUG FEATURE (GOOD HALT LOC)

BIC #BIT2,BTCR ;ALWAYS TURN OFF INTERNAL MAINT. BIT  
 MOV \$STNM,R0 ;GET TEST NUMBER  
 COM R0 ;1'S COMP TEST NUMBER  
 BIT #BIT6,\$DEVN ;CAN THE LEDS BE USED  
 BNE 501\$ ;BR, IF THEY CAN'T  
 MOVB R0,@LEDREG ;DISPLAY TEST NUMBER IN LEDS

501\$:

TST WRAP ;DOING DATA WRAP TESTS?  
 BNE 1\$ ;BR IF NO  
 TST CONSOLE ;ARE WE ON CONSOLE?  
 BEQ 2\$ ;BR IF NO  
 JMP EX1 ;EXIT TEST

1\$:  
2\$:

: THIS TEST WILL RUN BOTH TRANSMITTER AND  
 : RECIEVER AT FULL SPEED TESTING  
 : THE ABILITY OF THE MODULE  
 : TO HANDLE INTERRUPTS FROM BOTH SIDES AT ONCE.  
 :  
 : DOUBLE BUFFERING IS NOT FULLY TESTED BECAUSE OF  
 : APT CONSIDERATIONS. I.E. 'BREAK' FROM APT  
 : CAUSES OVERKUN ERRORS. THEREFORE TRANSMIT INTR IS  
 : ENABLED ONLY AFTER THE RECVR HAS OBTAINED THE LAST

: THIS TEST WILL TRANSFER A MAXIMUM OF 400(P)  
 : CHARACTERS THROUGH THE MODULE, BUT IF AN ERROR  
 : IS DETECTED BY THE TEST A PREMATURE SHUTDOWN OCCUR

:CHANGE PRIORITY

...TO 0  
 ;PUT NEW PS ON STACK  
 ;PUT NEW PC ON STACK  
 ;POP NEW PC AND PS

64\$:

2517 007504 012746 000000  
 007510 012746 007516  
 007514 000002  
 007516

MOV #PRO,-(SP)  
 MOV #64\$,-(SP)  
 RTI

2522  
 2523 007516 016701 171602  
 2524  
 2525 007522 012721 010020  
 2526 007526 012721 000340  
 2527  
 2528  
 2529 007532 012721 007744  
 2530 007536 012711 000340  
 2531  
 2532 007542 005067 000172  
 2533 007546 005067 000244  
 2534  
 2535 007552 012767 000400 000162  
 2536

MOV DLVEC,R1 ;GET VECTOR ADDRESS  
 MOV #REC,(R1)+ ;LET R1 := DLVEC  
 MOV #PR7,(R1)+ ;RCVR VECTOR  
 MOV #TRAN,(R1)+ ;LET (R1)+ := #REC  
 MOV #PR7,(R1)+ ;LET (R1)+ := #PR7  
 CLR ERRCNT ;POINT TO TRANSMITTER VECTOR  
 CLR DATA ;AND SET IT UP ALSO  
 MOV #400,NUMBER ;LET (R1)+ := #TRAN  
 ;LET (R1) := #PR7  
 ; CLEAR ERROR COUNTER  
 ;LET ERRCNT := #0  
 ;LET DATA := #0 XMIT DATA

2537	007560				4\$:				:SET I.E. IN TRANSMITTER
2538	007560	052777	000100	171532		BIS	#IE,@TCSR		:LET @TCSR := @TCSR SET.BY #IE
2539									:AND RECEIVER
2540	007566	052777	000100	171520		BIS	#IE,@RCSR		:LET @RCSR := @RCSR SET.BY #IE
2541									
2542									
2543									:NOW WE WAIT
2544	007574	012767	000050	171526		MOV	#50,TMP2		
2545	007602	012767	177777	171516	8\$:	MOV	#-1,TMP1		
2546	007610	026767	000202	000124	5\$:	CMP	DATA,NUMBER		:ALL DONE?
2547	007616	001413				BEQ	7\$		:BR IF YES
2548	007620	005357	171502			DEC	TMP1		:ELSE TIMER DONE?
2549	007624	001005				BNE	6\$		:BR IF NO
2550	007626	005367	171476			DEC	TMP2		
2551	007632	001363				BNE	8\$		
2552	007634					ERROR	201		:HUNG, NO DATA XFERS
	007634	104201				EMT	201		
2553	007636	000403				BR	7\$		
2554									
2555	007640	005767	000074		6\$:	TST	ERRCNT		:ANY ERRORS?
2556	007644	001761				BEQ	5\$		:BR IF NO & TRY AGAIN
2557	007646				7\$:				:NOW LETS CHECK.
2558									:TURN OFF ALL INTR ENABLE
2559	007646	042777	000100	171444		BIC	#IE,@TCSR		:LET @TCSR := @TCSR CLR.BY #IE
2560	007654	042777	000100	171432		BIC	#IE,@RCSR		:LET @RCSR := @RCSR CLR.BY #IE
2561	007662	005767	000052			TST	ERRCNT		:IF ERRCNT NE #0 THEN
2562	007666	001423				BEQ	42C\$		:BR, IF NO ERROR
2563	007670	032767	104000	000226		BIT	#ERROR,RHLD		:IF #ERROR SETIN RHLD THEN
2564	007676	001416				BEQ	430\$		:BR, IF NO ERROR
2565	007700	032767	040000	000216		BIT	#ORERR,RHLD		:IF #ORERR SETIN RHLD THEN
2566	007706	001402				BEQ	440\$		:BR, IF NO ERROR
2567									:OVERRUN ERROR
2568	007710					ERROR	202		
	007710	104202				EMT	202		
2569	007712	000407				BR	450\$		:ELSE IF #FRERR SETIN RHLD THEN
2570	007714				440\$:				
2571									:FRAMING ERROR
2572	007714	032767	020000	000202		BIT	#FREPR,RHLD		
2573	007722	001402				BEQ	460\$		:BR, IF NO ERROR
2574	007724					ERROR	203		
	007724	104203				EMT	203		
2575	007726	000403				BR	520\$		:EXIT THE TEST
2576									
2577	007730				460\$:				
2578	007730				500\$:				
2579									:FRAMING ERROR
2580	007730					ERROR	204		
	007730	104204				EMT	204		
2581	007732				510\$:				
2582	007732				470\$:				
2583	007732				450\$:				
2584									:ENDIF
2585	007732	000401				BR	520\$		:ELSE
2586									:DATA COMPARE ERROR
2587	007734				430\$:				
2588	007734					ERROR	205		
	007734	104205				EMT	205		

```

2589 007736          5208:          :ENDIF
2590 007736          4208:          :ENDIF
2595 007736          EX1:           :ENDIF
      007736 000473      BR      TST21      ::EXIT TEST
2600
2601
2602 007740 000000      ERRCNT: 0
2603 007742 000000      NUMBER: 0
2604
2605
2606
2611
2612                ::*****
2613                :TRANSMIT INTERRUPT HANDLER
2618                :*****
2619 007744          TRAN:          ;IF DATA NE NUMBER AND ERRCNT EQ #0 THEN
2620 007744 026767 000046 177770      CMP      DATA,NUMBER
2621 007752 001415          BEQ      530$
2622 007754 005767 177760          TST      ERRCNT
2623 007760 001012          BNE      530$
2624
2625 007762 032767 001000 171262      BIT      #BIT9,$DEVH
2626 007770 001403          BEQ      525$
2627 007772 052777 000004 171320      BIS      #BIT2,@TCSR
2628 010000 016777 000012 171314      525$:  MOV      DATA,@TBUF
2629 010006          530$:
2630
2631 010006 042777 000100 171304      BIC      #IE,@TCSR
2632 010014 000002          RTI
2633
2634 010016 000000      DATA:  0
    
```



2636  
2641  
2642  
2643  
2648  
2649 010020  
2650 010020 017767 171272 000076  
2651  
2652 010026 036727 000072 100000  
2653 010034 001004  
2654 010036 026767 000062 177752  
2655 010044 001411  
2656 010046  
2657  
2658 010046 016767 177670 177742  
2659 010054 042777 000100 171232  
2660 010062 005267 177652  
2661 010066 000415  
2662 010070  
2663 010070 005267 177722  
2664 010074 026767 177716 177640  
2665 010102 001004  
2666 010104 042777 000100 171202  
2667 010112 000403  
2668 010114  
2669  
2670 010114 052777 000100 171176  
2671 010122  
2672 010122  
2673 010122 000002  
2674  
2675 010124 000000  
2676

```

:*****
:RECEIVER INTERRUPT HANDLER
:*****

```

```

REC:
MOV @RBUF,RHLD           ;GET CHAR
                           ;LET RHLD := @RBUF
                           ;CHECK ERROR
                           ;IF #ERROR SET IN RHLD OR RHLD NE DATA THEN
                           ;BR, IF NO ERROR
BIT RHLD,#ERR15
BNE 540$
CMP RHLD,DATA
BEQ 550$                 ;BR, IF EQUAL

540$:
MOV NUMBER,DATA          ;STOP ALL INTERR PROC & GET OUT
BIC #IE,@RCSR            ;LET DATA := NUMBER
INC ERRCNT               ;LET @RCSR := @RCSR CLR.BY #IE
BR 560$                  ;LET ERRCNT := ERRCNT + #1
                           ;ELSE ;LET DATA := DATA + #1

550$:
INC DATA
CMP DATA,NUMBER
BNE 570$
BIC #IE,@RCSR
BR 600$                  ;IF DATA EQ NUMBER THEN
                           ;BR, IF NO ERROR
                           ;LET @RCSR := @RCSR CLR.BY #IE
                           ;ELSE

570$:
BIS #IE,@TCSR            ;ALLOW NEXT XMIT INTERR
                           ;LET @TCSR := @TCSR SET.BY #IE

600$:
560$:
RTI                       ;ENDIF
                           ;ENDIF

RHLD: 0

```

2678  
2689

```

*****
*TEST 21      TEST BREAK LOGIC
*             TRANSMIT KNOWN CHAR WITH BREAK SET
*             AND COMPARE RECEIVED WITH 0.
*             FRAMING ERROR WILL ALSO BE CHECKED
*             IF ERROR BITS ARE ENABLED.
*****
010126 000004
010130 012767 000010 171022
010136 012767 000021 171034
2694 010144 000240
2695
2696 010146 042777 000004 171144
2697 010154 016700 170722
2698 010160 005100
2699 010162 032767 000100 171062
2700 010170 001002
2701 010172 110077 171106
2702 010176
2703
2704 010176 005767 012150
2705 010202 001006
2706 010204 005767 012144
2707 010210 001003
2708 010212 005767 012132
2709 010216 001402
2710 010220 000167 000350
2711 010224
2712 010224
    010224 012767 010232 170656
    010232
2713
2714 010232 005067 000340
2715
2716
2717 010236 032767 001000 171006
2718 010244 001403
2719 010246 052777 000004 171044
2720 010254 052777 000001 171036
2721
2722
2723 010262 004567 012300
2724 010266 001314
2725 010270 000200
2726 010272
    010272 104001
2731 010274 000541
2736
2737 010276 017700 171014
2738 010302 105700
2739
2740 010304 001403
2741 010306 052767 000001 000262
2742 010314
2743 010314
2744 010314 032700 020000

TST21: SCOPE
        MOV #10,STIMES      ;;DO 10 ITERATIONS
        MOV #21,STESTN     ;;SET TEST NUMBER IN APT MAIL BOX
        NOP                ;SPECIAL DEBUG FEATURE (GOOD HALT LOC)

        BIC #BIT2,@TCSR    ;ALWAYS TURN OFF INTERNAL MAINT. BIT
        MOV STSTNM,RO      ;GET TEST NUMBER
        COM RO             ;1'S COMP TEST NUMBER
        BIT #BIT6,$DEVN    ;CAN THE LEDS BE USED
        BNE 501$          ;BR, IF THEY CAN'T
        MOVB RO,@LEDREG    ;DISPLAY TEST NUMBER IN LEDS

501$:
        TST WRAP           ;WRAP TESTS?
        BNE 1$            ;BR IF NO
        TST CONSOLE       ;ELSE ARE WE ON CONSOLE?
        BNE 1$            ;BR IF YES...DONT TEST
        TST BRK           ;ELSE IS BREAK DET ENABLED?
        BEQ 2$            ;BR IF NO
        JMP EX2

1$:
2$:
        LPADR

64$: MOV #64$,$LPERR

        CLR ERRCHK        ;LET ERRCHK := #0 CLEAR ERROR WORD
                          ;SET BREAK BIT
                          ;NON-ZERO CHAR. '*'
                          ;INTERNAL OR EXTERNAL
                          ;BR, IF EXTERNAL
                          ;SET MAINTENANCE BIT INT LOOP
                          ;LET @TCSR := @TCSR SET.BY #BREAK
                          ;LET @TBUF := #125

60$: BIS #BIT9,$DEVN
        BEQ 60$S
        BIS #BIT2,@TCSR
        ;MOVB #125,@TBUF

        JSR R5,TIMER      ;WAIT FOR RECV DONE
        RCSR
        DONE
        ERROR 1          ;RECV DONE DID NOT SET IN RCSR
        EM1 1
        BR TST22        ;;EXIT TEST

        MOV @RBUF,RO     ;LET RO := @RBUF
        TSTB RO          ;IFB RO NE #0 THEN
                          ;BREAK DID NOT EQUAL 0
                          ;BR, IF NOT = 0
                          ;LET ERRCHK := ERRCHK SET.BY #BIT0
                          ;ENDIF

610$:
611$: BIT #FRERR,RO      ;IF #FRERR NOTSET IN RO THEN
    
```

T21 TEST BREAK LOG: C

```

2745 010320 001003      BNE      6208
2746 010322 052767 000002 000246      BIS      #BIT1,ERRCHK      ;LET ERRCHK := ERRCHK SET.BY #BIT1
2747 010330      6208:      ;ENDIF
2748
2749 010330      48:
2750 010330 042777 000001 170762      BIC      #BREAK,@TCSR      ;LET @TCSR := @TCSR CLR.BY #BREAK
2751 010336 004767 012342      JSR      PC,WAIT      ;WAIT FOR REC BREAK BIT TO CLEAR
2752 010342 032777 004000 170746      BIT      #BIT11,@RBUF      ;NO CHECK BIT FOR CLEAR
2753 010350 001402      BEQ      58      ;BR, IF CLEAR (NO ERROR)
2754 010352      ERROR    2      ;BREAK FAILED TO CLEAR IN RBUF
      010352 104002      EMT 2
2755 010354 000511      BR      TST22      ;EXIT TEST
2756 010356      58:
2757 010356 032767 001000 170666      BIT      #BIT9,$DEVH      ;INTERNAL OR EXTERNAL
2758 010364 001403      BEQ      6258      ;BR, IF EXTERNAL
2759 010366 052777 000004 170724      BIS      #BIT2,@TCSR      ;SET MAINTENANCE BIT INT LOOP
2760 010374 112777 000125 170720 6258:      MOVB     #125,@TBUF      ;SEND OUT CHARACTER
2761 010402 004567 012160      JSR      R5,TIMER      ;WAIT FOR READY
2762 010406 001314      RCSR
2763 010410 000200      DONE
2764 010412      ERROR    3      ;DONE FAILED TO SET
      010412 104003      EMT 3
2765 010414 000471      BR      TST22      ;EXIT
2766 010416 032777 170000 170672      BIT      #170000,@RBUF
2767 010424 001401      BEQ      18
2768 010426      ERROR    4      ;RESET DID NOT CLEAR ERROR BITS
      010426 104004      EMT 4
2769
2770 010430      18:
2771
2772 010430 032767 000001 000140      BIT      #BIT0,ERRCHK      ;IF #BIT0 SET IN ERRCHK THEN
2773 010436 001401      BEQ      6308      ;BREAK ERROR
2774 010440      ERROR    5
      010440 104005      EMT 5
2775 010442      6308:
2776 010442 032767 000002 000126      BIT      #BIT1,ERRCHK      ;ENDIF
2777 010450 001401      BEQ      6608      ;IF #BIT1 SET IN ERRCHK THEN
2778 010452      ERROR    6      ; FRAMING ERROR
      010452 104006      EMT 6
2779
2780      ;OCCURED WITH EVEN PARITY
2781 010454      6608:      ;ENABLED AND BREAK SET
2782 010454      ;ENDIF
      010454 012767 010462 170426      MOV      #648,$LPERR      LPADR
      010462      648:
2783
2784 010462 052777 000001 170630      BIS      #BREAK,@TCSR      ;SET BREAK BIT
2785      ;LET @TCSR := @TCSR SET.BY #BREAK
2786 010470 004567 012072      JSR      R5,TIMER      ;WAIT FOR BREAK BIT
2787 010474 001320      TCSR
2788 010476 000001      BREAK
2789 010500      ERROR    11      ;BREAK DID NOT SET IN TCSR
      010500 104011      EMT 11
2794 010502 000436      BR      TST22      ;:EXIT TEST
2799
2800
2801 010504 042777 000001 170606      BIC      #BREAK,@TCSR      ;CLEAR BREAK BIT
      ;LET @TCSR := @TCSR CLR.BY #BREAK

```

```

2802
2803 010512 004767 012166      JSR    PC,WAIT
2804
2805 010516 017700 170574      MOV    @RBUF,R0
2806
2807 010522 032767 001000 170522  BIT    #B119,SDEVH
2808 010530 001403              BEQ    6658
2809 010532 052777 000004 170560  BIS    #BIT2,@TCSR
2810 010540 112777 000125 170554 6658:  MOVB  #125,@TBUF
2811
2812 010546 004567 012014      JSR    RS,TIMER
2813 010552 001314
2814 010554 000200
2815 010556
2815 010556 104012
2820 010560 000407
2825
2826
2827 010562 027727 170530 000125  CMP    @RBUF,#125
2828 010570 001401              BEQ    6708
2829
2830 010572
2830 010572 104013
2831 010574
2836 010574
2836 010574 000401
2841
2842 010576 000000
ERRCHK: .WORD 0

```

```

;READ RBUF TO CLEAR REC DONE
;LET R0 := @RBUF
;SEND CHAR
;INTERNAL OR EXTERNAL
;BR, IF EXTERNAL
;SET MAINTENANCE BIT INT LOOP
;LET @TBUF := #125

;WAIT FOR RECV DONE

;RECV DONE DID NOT SET IN RCSR

::EXIT TEST

;WAS CHAR AFTER BREAK RECEIVED
;IFB @RBUF NE #125 THEN
;BR, IF NO ERROR
;CHAR AFTER BREAK NOT RECEIVED CORRECTLY

;ENDIF

::EXIT TEST

```

```

2844
2849 010600
2850
    10600 000004
    010602 012767 000001 170350
2855 010610 000240
2856
2857
2858 010612 012700 000022
2859 010616 005100
2860 010620 032767 000100 170424
2861 010626 001092
2862 010630 110077 170450
2863 010634
2864 010634 032777 010000 170276
2865 010642 001002
2866 010644 000167 000560
2867 010650 026727 011502 000001 3038:
2868 010656 001176
2869 010660 032767 100000 170364
2870 010666 001061
2871 010670
2872 010730
2873 010744
2874 010752
2875 010772
2876 011000
2877 011020
2878 011026 104401 001171
2879 011032 032767 020000 170212 348:
2880 011040 001002
2881 011042 000167 000362
2882 011046
2883 011062
2884 011070
2885 011110
2886 011116
2887 011136
2888 011144 104401 001171
2889 011150
2890 011164
2891 011172
2892 011212
2893 011220
2894 011240
2895 011246 104401 001171
2896 011252 000466
2897
2898 011254 005767 011100 18:
2899 011260 001022
2900 011262
2901 011322 005267 011032
2902
2903 011326
2904 011342

NOTST:
:*****
:TEST 22 NOT A TEST - SEND BACK TO LOOP
:*****
TST22: SCOPE
MOV #1,STIMES ;;DO 1 ITERATION
NOP ;SPECIAL DEBUG FEATURE (GOOD HALT LOC)

MOV #22,R0 ;GET TEST NUMBER
COM R0 ;1'S COMP TEST NUMBER
BIT #BIT6,SDEVN ;CAN THE LEDS BE USED
BNE 501$ ;BR, IF THEY CAN'T
MOV# R0,BLEDREG ;DISPLAY TEST NUMBER IN LEDS

501$: BIT #BIT12,@SWR ;WANT SUMMARY?
BNE 303$ ;BR, IF YES
JMP 3$ ;JUMP IF NO
303$: CMP PHASE2,#TRUE ;ELSE IN PHASE 2?
BNE 1$ ;BR IF NO
BIT #BIT15,SDEVN ;IS CHANNEL 0 BEING TESTED
BNE 34$ ;BR, IF IT NOT BEING TESTED
TYPTXT <<CRLF>/ ** PHASE 2 SUMMARY **/<<CRLF>>
TYPTXT <*<CSR: *>
TYPOCT BASE0
TYPTXT <*,VECTOR: *>
TYPOCT VECT0
TYPTXT <*,ERRORS: *>
TYPDEC SERTTL
TYPE ,SCRLF
34$: BIT #BIT13,SDEVN ;CHECK FOR 2ND MXV
BNE 33$ ;BR IF PRESENT
JMP 3$ ;JUMP IF NOT PRESENT
33$: TYPTXT <*"CSR: *>
TYPOCT BASE2
TYPTXT <*,VECTOR: *>
TYPOCT VECT2
TYPTXT <*,ERRORS: *>
TYPDEC SERTTL
TYPE ,SCRLF
TYPTXT <*<CSR: *>
TYPOCT BASE3
TYPTXT <*,VECTOR: *>
TYPOCT VECT3
TYPTXT <*,ERRORS: *>
TYPDEC SERTTL
TYPE ,SCRLF
BR 3$

18: TST PICNT
BNE 2$
TYPTXT <<CRLF>/ ** PHASE 1 SUMMARY **/<<CRLF>>
INC PICNT

28: TYPTXT <*<CSR: *>
TYPOCT D,ADD
    
```

```

2905 011350          TYPTXT  <*,VECTOR: *>
2906 011370          TYPOCT  DLVEC
2907 011376          TYPTXT  <*,ERRORS: *>
2908 011416          TYPDEC  SERTTL
2909 011424 104401 001171  TYPE      ,%CRLF
2910
2911 011430 005067 167456 38:  CLR      SERTTL          ; RESET FOR NEXT DEVICE/PASS
2912 011434 026727 010716 000001  CMP      PHASE2,#TRUE    ; IN PHASE 2?
2913 011442 001010          BNE      48             ; BR IF NO
2914 011444 005067 010706  CLR      PHASE2
2915 011450 005067 167532  CLR      $UNIT
2916 011454 104401 001334  TYPE     ,CARR
2917 011460 000167 013200  JMP      $EOP
2918
2919 011464 042777 000004 167626 48:  BIC      #BIT2,@TCSR    ; ALWAYS TURN OFF INT MAINT WRAP
2920 011472 112767 000005 167402  MOVB    #5,$STSN#     ; FAKE OUT FOR 2'ND CHANNEL
2921 011500 000167 172236  JMP      LOOP         ; BACK UP TO THE BEGINNING
2926
  
```

2928  
2929 011504  
2930  
2936

MODTST:

```

:*****
:TEST 23      TEST THAT CHANNELS INTR AT ASSIGNED PRIORITY.
:             INTERRUPTS WILL BE ENABLED ON ALL ACTIVE CHANNELS.
:             RECEIVER AND TRANSMITTER. THEN WE'LL CHECK TO
:             SEE IF THEY INTERRUPTED IN THE ASSIGNED SEQUENCE.
:*****

```

```

011504 000004
011506 012767 000001 167444
011514 012767 000023 167456
2941 011522 000240
2942
2943
2944 011524 042777 000004 167566
2945 011532 012700 000023
2946 011536 005100
2947 011540 032767 000100 167504
2948 011546 001002
2949 011550 110077 167530
2950 011554
2951 011554 036727 167472 100000
2952 011562 001406
2953 011564 036727 167462 000400
2954 011572 001002
2955 011574 000167 000756
2956 011600
2957 011600 005067 000742
2958 011604 005067 000740
2959 011610 005067 000736
2960 011614 005067 000734
2961
2966 011620 012746 000340
011624 012746 011632
011630 000002
011632
2971
2972 011632 032767 002000 167412
2973 011640 001406
2974 011642 032767 000010 167402
2975 011650 001002
2976 011652 000167 003040
2977 011656
2978 011656 032767 100000 167366
2979 011664 001052
2980 011666 032767 002000 167356
2981 011674 001046
2982
2983 011676 016700 167354
2984 011702 012720 012450
2985 011706 012720 000340
2986 011712 012720 012464
2987 011716 012710 000340
2988
2989 011722 016700 167326
2990 011726 052710 000100

```

```

TST23: SCOPE
MOV #1,$TIMES      ;;DO 1 ITERATION
MOV #23,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX
NOP               ;;SPECIAL DEBUG FEATURE (GOOD HALT LOC)

501$: BIC #BIT2,$TCSR      ;CLEAR MAINTENANCE BIT
MOV #23,$R0        ;GET TEST NUMBER
COM $R0            ;1'S COMP TEST NUMBER
BIT #BIT6,$SDEVH  ;CAN THE LEDS BE USED
BNE $018          ;BR, IF THEY CAN'T
MOV $R0,$LEDREG   ;DISPLAY TEST NUMBER IN LEDS

504$: BIT $SDEVH,#BIT15   ;CHANNEL 0 SELECTED
BEQ $048          ;BR, IF CHANNEL 0 SELECTED
BIT $SDEVH,#BIT8  ;CHECK FOR CHANNEL 1
BNE $048          ;BR, IF CHANNEL 1 SELECTED
JMP TST24        ;NEITHER CHANNEL SELECTED GET OUT

504$: CLR INTABL          ;CLEAR OUT INTERRUPT TABLE
CLR INTABL+2
CLR INTABL+4
CLR INTABL+6

64$: MOV #PR7,-($SP)     ;;PUT NEW PS ON STACK
MOV #64$,-($SP)     ;;PUT NEW PC ON STACK
RTI                 ;;POP NEW PC AND PS

691$: BIT #<BIT10>,$SDEVH ;CHECK FOR TEST SKIP
BEQ $691$         ;BR, IF NOT TO BE SKIPPED
BIT #<BIT3>,$SDEVH ;CHECK OTHER CHANNEL
BNE $691$         ;BR, IF NOT TO BE SKIPPED
JMP TST25        ;YEP SKIP THIS TEST

691$: BIT #<BIT15>,$SDEVH ;CH 0 DROPPED OR NO WRAP?
BNE $1$          ;BR IF EITHER SET
BIT #<BIT10>,$SDEVH ;CH 0 DROPPED OR NO WRAP?
BNE $1$          ;BR IF EITHER SET

MOV VECT0,$R0     ;SETUP CH 0 VECTOR AREA
MOV #CH0R,($R0)+ ;RCV
MOV #PR7,($R0)+
MOV #CH0X,($R0)+ ;XMIT
MOV #PR7,($R0)

MOV BASE0,$R0    ;ENABLE INTERRUPTS
BIS #IE,($R0)   ;RCV

```

```

2991 011732 062700 000004          ADD    #4,RO
2992 011736 032767 001000 167306    BIT    #BIT9,$DEVH          ;INTERNAL OR EXTERNAL
2993 011744 001402                    BEQ    680$                 ;BR, IF EXTERNAL
2994 011746 052710 000004          BIS    #BIT2,(RO)          ;SET MAINTENANCE BIT INT LOOP
2995 011752 052720 000100          BIS    #!E,(RO)+         ;XMIT
2996
2997 011756 012710 000125          MOV    #125,(RO)          ;XMIT CHAR TO PRIME RECEIVERS
2998 011762 162700 000006          SUB    #6,RO              ;GO BACK TO RCSR
2999 011766 012767 100000 167332    MOV    #100000,TMP1
3000 011774 032710 000200          BIT    #DONE,(RO)        ;DONE?
3001 012000 001004                    BNE    2$                 ;BR IF YES
3002 012002 005367 167320          DEC    TMP1              ;TIMED OUT?
3003 012006 001372                    BNE    7$                 ;BR IF NO
3004 012010          ERROR 231                ;NO RCVR DONE
      012010 104231
3005 012012 032767 000400 167232 1$:  BIT    #<BIT8>,$DEVH      ;CH 1 DROPPED OR NO WRAP?
3006
3007 012020 001456                    BEQ    2$                 ;BR IF EITHER SET
3008 012022 032767 000010 167222    BIT    #<BIT3>,$DEVH      ;CH 1 DROPPED OR NO WRAP?
3009 012030 001452                    BEQ    2$                 ;BR IF EITHER SET
3010 012032 026767 167222 167104    CMP    BASE1,$TKS        ;CH 1 CONSOLE?
3011 012040 001446                    BEQ    2$                 ;BR IF YES
3012
3013 012042 016700 167214          MOV    VECT1,RO          ;SETUP CH 1 VECTOR AREA
3014 012046 012720 012506          MOV    #CH1R,(RO)+       ;RECV
3015 012052 012720 000340          MOV    #PR7,(RO)+
3016 012056 012720 012524          MOV    #CH1X,(RO)+
3017 012062 012710 000340          MOV    #PR7,(RO)        ;XMIT
3018
3019 012066 016700 167166          MOV    BASE1,RO          ;ENABLE INTERRUPTS
3020 012072 052710 000100          BIS    #!E,(RO)         ;RECV
3021 012076 062700 000004          ADD    #4,RO
3022 012102 032767 001000 167142    BIT    #BIT9,$DEVH      ;IS INTERNAL WRAP SELECTED
3023 012110 001402                    BEQ    690$               ;BR, IF IT IS NOT
3024 012112 052710 000004          BIS    #BIT2,(RO)        ;SET THE MAINTENANCE BIT
3025 012116          690$:
3026 012116 052720 000100          BIS    #!E,(RO)+         ;XMIT
3027
3028 012122 012710 000125          MOV    #125,(RO)        ;XMIT CHAR TO PRIME RECEIVERS
3029 012126 162700 000006          SUB    #6,RO              ;GO BACK TO RCSR
3030 012132 012767 100000 167166    MOV    #100000,TMP1
3031 012140 032710 000200          BIT    #DONE,(RO)        ;DONE?
3032 012144 001004                    BNE    2$                 ;BR IF YES
3033 012146 005367 167154          DEC    TMP1              ;TIMED OUT?
3034 012152 001372                    BNE    8$                 ;BR IF NO
3035 012154          ERROR 232                ;NO RCVR DONE
      012154 104232
3036
3037
3038
3039
3040
3041
3042
3043
3044
3045 012156 032767 100000 167066 2$:  BIT    #<BIT15>,$DEVH      ;CH0 DROPPED OR NO WRAP?

```

```

;ALL XMIT & REC INTERRUPTS SHOULD BE
;IN CONTENTION.
;CHAN 0 HAS PRIORITY OVER CHAN 1.
;RECEIVE HAS PRIORITY OVER XMIT INTERRUPTS.
;THEREFORE, ONCE CPU PRIORITY IS LOWERED,
;INTERRUPTS S/B IN THE ORDER SHOWN IN THE
;CHANNEL IDENTIFIER TABLE (RCHO:)

```



```

3046 012164 001007          BNE      58          ;BR IF EITHER SET
3047 012166 032767 002000 167056 BIT      #<BIT10>,$DEV0 ;CH0 DROPPED OR NO WRAP?
3048 012174 001003          BNE      58          ;BR IF EITHER SET
3049
3050 012174 012704 012546          MOV      #INTABL,R4      ;SETUP FOR SERVICE ROUTINES
3051 012202 000402          BR        68
3052
3053 012204 012704 012552          58:     MOV      #INTABL+4,R4
3054 012210 68:
3055 012210 012700 177777          MOV      #-1,R0          ;DELAY TO ALLOW ANY PREVIOUS XMIT TO
3056 012214 077001          SOB      R0              ;FINISH BEFORE RESET
3057 012216 012700 177777          MOV      #-1,R0          ;DELAY TO ALLOW ANY PREVIOUS XMIT TO
3058 012222 077001          SOB      R0              ;FINISH BEFORE RESET
3059
3064 012224 012746 000000          MOV      #PP0,-(SP)      ;;PUT NEW PS ON STACK
          012230 012746 012226          MOV      #658,-(SP)     ;;PUT NEW PC ON STACK
          012234 000002          RTI                    ;;POP NEW PC AND PS
          012236          658:
3069 012236 012700 177777          MOV      #-1,R0          ;DELAY TO ALLOW ANY PREVIOUS XMIT TO
3070 012242 077001          SOB      R0              ;FINISH BEFORE RESET
3071 012244 000005          RESET          ;DISABLE ALL INTERRUPTS
3076 012246 012746 000340          MOV      #PR7,-(SP)     ;;PUT NEW PS ON STACK
          012252 012746 012260          MOV      #668,-(SP)     ;;PUT NEW PC ON STACK
          012256 000002          RTI                    ;;POP NEW PC AND PS
          012260          668:
3081
3082
3083
          ;NOW LETS SEE IF INTABL HAS ENTRIES IN THE CORRECT O
3084 012260 032767 100000 166764 BIT      #<BIT15>,$DEV0 ;CH 0 DROPPED OR NO WRAP?
3085 012266 001015          BNE      38          ;BR IF EITHER SET
3086 012270 032767 002000 166754 BIT      #<BIT10>,$DEV0 ;CH 0 DROPPED OR NO WRAP?
3087 012276 001011          BNE      38          ;BR IF EITHER SET
3088
3089 012300 005767 000242          TST      INTABL          ;1'ST ENTRY 0?
3090 012304 001401          BEQ      +4            ;BR IF YES
3091 012306          ERROR    233          ;DID NOT INTERR AT ASSIGNED PRIOR
          012306 104233          EMT 233
3092
3093 012310 026727 000234 000001          CMP      INTABL+2,#1     ;2'ND ENTRY 1?
3094 012316 001401          PEQ      +4            ;BR IF YES
3095 012320          ERROR    234          ;BR IF YES
          012320 104234          EMT 234
3096
3097 012322 032767 000400 166722 38:   BIT      #<BIT8>,$DEV0   ;CH 1 DROPPED OR NO WRAP?
3098 012330 001422          BEQ      48          ;BR IF EITHER SET
3099 012332 032767 000010 166712          BIT      #<BIT3>,$DEV0 ;CH 1 DROPPED OR NO WRAP?
3100 012340 001416          BEQ      48          ;BR IF EITHER SET
3101 012342 026767 166712 166574          CMP      BASE1,$TKS     ;CH ? CONSOLE?
3102 012350 001412          BEQ      48          ;BR IF YES
3103
3104 012352 026727 000174 000002          CMP      INTABL+4,#2     ;3'RD ENTRY 2?
3105 012360 001401          BEQ      +4            ;BR IF YES
3106 012362          ERROR    235          ;BR IF YES
          012362 104235          EMT 235
3107
3108 012364 026727 000164 000003          CMP      INTABL+6,#3     ;4'TH ENTRY 3?
3109 012372 001401          BEQ      +4            ;BR IF YES
    
```

```
3110 012374          ERROR 236
      012374 104236    EMT 236
3111 012376 112777 000000 166716 48:  MOVB #0,@TBUF      ;SEND OUT DUMMY CHARACTER
3112 012404 004567 010156          JSR  R5,TIMER      ;CALL TIMER ROUTINE
3113 012410 001314          RCSR
3114 012412 000200          DONE
3115 012414          ERROR 237      ;DONE FAILED TO SET AFTER TRANSMIT
      012414 104237    EMT 237
3116 012416 000401          BR 5028      ;EXIT TEST BRANCH
3117 012420 000402          BR 5038      ;GOOD BRANCH ETC
3118 012422 000167 177512          5028: JMP 88      ;REALLY EXIT TEST
3119 012426 117700 166664          5038: MOVB @RBUF,R0    ;CLEAR OUT REC BUFFER
3120 012432 012737 026762 000020    MOV #$$SCOPE,@#IOTVEC ;RESET VECTOR 20 IN CASE USED
3121 012440 012737 000340 000022    MOV #340,@#IOTVEC+2  ;SET TO LEVEL 7 AGAIN
3122
3127 012446 000443          BR TST24      ;;EXIT TEST
3132
```

3134  
 3135  
 3136  
 3137  
 3138  
 3139 012450 005024  
 3140 012452 016700 166576  
 3141 012456 042710 000100  
 3142 012462 000002  
 3143  
 3144 012464 012724 000001  
 3145 012470 016700 166560  
 3146 012474 062700 000004  
 3147 012500 042710 000100  
 3148 012504 000002  
 3149  
 3150 012506 012724 000002  
 3151 012512 016700 166542  
 3152 012516 042710 000100  
 3153 012522 000002  
 3154  
 3155 012524 012724 000003  
 3156 012530 016700 166524  
 3157 012534 062700 000004  
 3158 012540 042710 000100  
 3159 012544 000002  
 3160  
 3161  
 3162  
 3163  
 3164  
 3165  
 3166 012546  
 3167  
 3168

\*\*\*\*\*  
 \* START OF SERVICE ROUTINES  
 \*\*\*\*\*

CHOR: CLR (R4)+ :PUT IDENTIFIER IN TABLE  
 MOV BASE0,RO  
 BIC #IE,(RO) : 1 INTERR IS ALL WE WANT  
 RTI  
 CHOX: MOV #1,(R4)+ :PUT IDENTIFIED IN TABLE  
 MOV BASE0,RO  
 ADD #4,RO  
 BIC #IE,(RO) : 1 INTERR IS ALL WE WANT  
 RTI  
 CH1R: MOV #2,(R4)+ :PUT IDENTIFIER IN TABLE  
 MOV BASE1,RO  
 BIC #IE,(RO) : 1 INTERR IS ALL WE WANT  
 RTI  
 CH1X: MOV #3,(R4)+ :PUT IDENTIFIED IN TABLE  
 MOV BASE1,RO  
 ADD #4,RO  
 BIC #IE,(RO) : 1 INTERR IS ALL WE WANT  
 RTI

:THIS TABLE WILL CONTAIN ENTRIES  
 :REPRESENTING EACH INTR IN THE ORDER  
 :THAT IT OCCURED  
 : S/B IN THE FOLLOWING ORDER: 0,1,2,3

INTABL: .BLKW 4

3170  
3186

```

*****
*TEST 24      TEST DATA XFRS, ALL ACTIVE LINES INTERRUPTING
*              IN THIS WE'LL ENABLE INTERRUPTS ON ALL CHANNELS.
*              THE J WE'LL XMIT AN INCREMENTING
*              DATA PATERN VIA INTERRUPTS AND RECORD THE RECEIVER
*              INTR. IN THE RECEIVER STATUS TABLE.
*              NOTE: DOUBLE BUFFERING CANNOT BE TESTED AT ITS MAX SPEED
*              BECAUSE OF APT CONSIDERATIONS. I.E. APT SENDS
*              'BREAKS' WHICH CAUSE OVERRUN ERRORS. THEREFORE
*              THE XMIT IE IS NOT ENABLED AGAIN UNTIL THE RECVR
*              HAS OBTAINED THE PREVIOUS WORD.
*****
    
```

```

012556 000004
012560 012767 000001 166372
012566 012767 000024 166404
3191 012574 000240
3192
3193
3194 012576 042777 000004 166514
3195 012604 012700 000024
3196 012610 005100
3197 012612 032767 000100 166432
3198 012620 001002
3199 012622 110077 166456
3200 012626
3201 012626 036727 166420 100000
3202 012634 001406
3203 012636 036727 166410 000400
3204 012644 001002
3205 012646 000167 002044
3206 012652
3207 012652 032767 001000 166372
3208 012660 001403
3209 012662 052777 000004 166430
3210 012670 112777 000000 166424
3211 012676 004567 007664
3212 012702 001314
3213 012704 000200
3214 012706
012706 104241
3215 012710 000401
3216 012712 000402
3217 012714 000167 000534
3218 012720 117700 166372
3219 012724 032767 002000 166320
3220 012732 001402
3221 012734 000167 000514
3222 012740 000567 007622
3223 012744 001314
3224 012746 000200
3225 012750 000240
3226 012752 000240
3227 012754 000240
3228 012756 117700 166334
3229 012762 005067 001716
3230 012764 012767 000100 001714

TST24: SCOPE
MOV #1,$TIMES ::DO 1 ITERATION
MOV #24,$TESTN ::SET TEST NUMBER IN APT MAIL BOX
NOP ;SPECIAL DEBUG FEATURE (GOOD HALT LOC)

501$:
BIT $DEVN,#BIT15 ;CHANNEL 0 SELECTED
BEQ 504$ ;BR, IF CHANNEL 0 SELECTED
BIT $DEVN,#BIT8 ;CHECK FOR CHANNEL 1
BNE 504$ ;BR, IF CHANNEL 1 SELECTED
MOVB RO,$LEDREG ;DISPLAY TEST NUMBER IN LEDS

504$:
BIT #BIT9,$DEVN ;CHECK FOR MAINTENANCE BIT (LOOP)
BEQ 9$ ;BR, IF NOT SET
BIS #BIT2,$TCR ;SET EXTERNAL LOOP BACK BIT
MOVB #0,$TBUF ;SEND OUT DUMMY CHARACTER
JSR R5,$TIMER ;CALL TIMER ROUTINE

9$:
RCSR
DONE
ERROR 241 ;DONE FAILED TO SET AFTER TRANSMIT
EM 241
BR 502$ ;EXIT TEST BRANCH
BR 503$ ;GOOD BRANCH ETC
502$: JMP 8$ ;REALLY EXIT TEST
503$: MOVB @RBUF,R0 ;CLEAR OUT REC BUFFER
BIT #BIT10,$DEVN ;CHECK FOR DATA WRAP
BEQ 10$ ;BR, IF DATA WRAP SELECTED
JMP 8$ ;BR, IF WRAP NOT SELECTED
10$: JSR R5,$TIMER ;CALL TIMER ROUTINE
RCSR ;LOOK AT THE THE RECEIVER REGISTER
DONE ;CHECK FOR DONE
NOP
NOP
NOP
MOVB @RBUF,R0 ;CLEAR OUT REC BUFFER ONCE MORE
CLR COXMIT ;1'ST WORD OF CH 0 TO XMIT
MOV #100,$CXMIT ;1'ST WORD OF CH 1 TO XMIT
    
```

```

3231
3232 012774 012700 013704      MOV      #CHOTAB,RO      ;CLEAR OUT RECEIVER TABLES
3233 013000 005020              CLR      (RO)+
3234 013002 020027 014704      CMP      RO,#STATEND    ;ALL DONE?
3235 013006 001374              BNE     .-6             ;BR IF NO
3236
3241 013010 012746 000340      MOV      #PR7,-(SP)     ;;PUT NEW PS ON STACK
      013014 012746 013022      MOV      #648,-(SP)    ;;PUT NEW PC ON STACK
      013020 000002              RTI     ;;POP NEW PC AND PS
      013022
      648:
3246
3247 013022 032767 100000 166222    BIT      #<BIT15>,$DEV0 ;CH 0 DROPPED OR NO WRAP?
3248 013030 001031              BNE     1$             ;BR IF EITHER SET
3249 013032 032767 002000 166212    BIT      #<BIT10>,$DEV0 ;CH 0 DROPPED OR NO WRAP?
3250 013040 001025              BNE     1$             ;BR IF EITHER SET
3251
3252 013042 016700 166210      MOV      VECTO,RO      ;SETUP CH 0 VECTOR AREA
3253 013044 012720 013474      MOV      #ROSRV,(RO)+  ;RCVR
3254 013052 012720 000340      MOV      #PR7,(RO)+
3255 013056 012720 013534      MOV      #XOSRV,(RO)+ ;XMIT
3256 013062 012710 000340      MOV      #PR7,(RO)
3257
3258 013066 016700 166162      MOV      BASE0,RO      ;ENABLE INTERRUPTS
3259 013072 052710 000100      BIS     #IE,(RO)      ;RCVR
3260 013076 062700 000004      ADD     #4,RO
3261 013102 052710 000100      BIS     #IE,(RO)      ;XMIT
3262
3263 013106 012767 000177 001572    MOV      #177,COEND    ;8 BIT CHARACTERS
3264
3265 013114 032767 000400 166130 1$: BIT      #<BIT8>,$DEV0 ;CH 1 DROPPED OR NO WRAP?
3266 013122 001435              BEQ     2$             ;BR IF EITHER SET
3267 013124 032767 000010 166120    BIT      #<BIT3>,$DEV0 ;CH 1 DROPPED OR NO WRAP?
3268 013132 001431              BEQ     2$             ;BR IF EITHER SET
3269 013134 026767 166120 166002    CMP     BASE1,STKS    ;CH 1 CONSOLE?
3270 013142 001425              BEQ     2$             ;BR IF YES
3271
3272 013144 016700 166112      MOV      VECT1,RO      ;SETUP CH 1 VECTOR AREA
3273 013150 012720 013600      MOV      #R1SRV,(RO)+ ;RCVR
3274 013154 012720 000340      MOV      #PR7,(RO)+
3275 013160 012720 013640      MOV      #X1SRV,(RO)+ ;XMIT
3276 013164 012710 000340      MOV      #PR7,(RO)
3277
3278 013170 016700 166064      MOV      BASE1,RO      ;ENABLE INTERRUPTS
3279 013174 052710 000100      BIS     #IE,(RO)      ;RCVR
3280 013200 062700 000004      ADD     #4,RO
3281 013204 052710 000100      BIS     #IE,(RO)      ;XMIT
3282
3283
3284 013210 012767 000177 001474    MOV      #177,C1END    ;8 BIT CHARACTERS
3285 013216 012700 013704 2$: MOV      #CHOTAB,RO    ;INIT BUFFER PTRS FOR SERV ROUTINES
3286 013222 012701 014304      MOV      #CHITAB,R1
3287
3292 013226 012746 000000      MOV      #PRO,-(SP)    ;;PUT NEW PS ON STACK
      013232 012746 013240      MOV      #658,-(SP)   ;;PUT NEW PC ON STACK
      013236 000002              RTI     ;;POP NEW PL AND PS
      013240
      658:
3297

```

```

3298 013240 02767 000040 001446      MOV    #32.,SPTMR      ;SET UP SPECIAL TIMER
3299 013246 012703 177777      650$: MOV    #-1,R3      ;DELAY TO ALLOW ANY PREVIOUS XMIT TO
3300 013252 077301      SOB    R3              ;FINISH BEFORE RESET
3301 013254 005367 001434      DEC    SPTMR          ;BUMP BIG COUNTER
3302 013260 001372      BNE    650$          ;BR, IF MORE TIME TO GO
3303 013262 000005      RESET                ;DISABLE ALL INTERR
3304
3309 013264 012746 000340      MOV    #PR7,-(SP)     ;;PUT NEW PS ON STACK
      013270 012746 013276      MOV    #66$,-(SP)    ;;PUT NEW PC ON STACK
      013274 000002      RTI                  ;;POP NEW PC AND PS
      013276      66$:
3314
3315
3316
      ;NOW LETS CHECK TO SEE IF TABLE(S) ARE IN CORRECT OR
3317 013276 032767 100000 165746      BIT    #<BIT15>,$DEVH ;CH 0 DROPPED OR NO WRAP
3318 013304 001025      BNE    $S            ;BR IF EITHER SET
3319 013306 032767 002000 165736      BIT    #<BIT10>,$DEVH ;CH 0 DROPPED OR NO WRAP
3320 013314 001021      BNE    $S            ;BR IF EITHER SET
3321
3322 013316 005000      CLR    R0             ;EXPECTED WORD
3323 013320 012701 013704      MOV    #CHOTAB,R1     ;TABLE PTR
3324
3325 013324 020011      3$:  CMP    R0,(R1)       ;EXPECT = ACTUAL?
3326 013326 001405      BEQ    4$            ;BR IF YES
3327
3328 013330 005711      TST    (R1)           ;ERROR SET?
3329 013332 100002      BPL    .+6           ;BR IF NO
3330 013334 104242      ERROR 242           ;ERROR FLAG AFTER XFER
      013334 000401      BR     .+4
3331 013336 000401      BR     .+4
3332 013340 104243      ERROR 243           ;DATA COMPARE ERROR
      013340 104243      EMT 243
3333
3334 013342 020067 001340      4$:  CMP    R0,COEND      ;ALL DONE?
3335 013346 001404      BEQ    $S            ;BR IF YES
3336 013350 005200      INC    R0
3337 013352 062701 000002      ADD    #2,R1
3338 013356 000762      BR     $S            ;ELSE DO AGAIN
3339
3340 013360 032767 000400 165664 5$:  BIT    #<BIT8>,$DEVH  ;CH 1 DROPPED OR NO WRAP
3341 013366 001432      BEQ    $S            ;BR IF EITHER SET
3342 013370 032767 000010 165654      BIT    #<BIT3>,$DEVH  ;CH 1 DROPPED OR NO WRAP
3343 013376 001426      BEQ    $S            ;BR IF EITHER SET
3344 013400 026767 165654 165536      CMP    BASE1,$TKS    ;CH 1 CONSOLE?
3345 013406 001422      BEQ    $S            ;BR IF YES
3346
3347 013410 012700 000100      MOV    #100,R0        ;EXPECTED WORD
3348 013414 012701 014304      MOV    #CH1TAB,R1     ;TABLE PTR
3349
3350 013420 020011      6$:  CMP    R0,(R1)       ;EXPECT = ACTUAL?
3351 013422 001405      BEQ    7$            ;BR IF YES
3352
3353 013424 005711      TST    (R1)           ;ERROR SET?
3354 013426 100002      BPL    .+6           ;BR IF NO
3355 013430 104244      ERROR 244           ;ERROR FLAG UP AFTER XFER
      013430 000401      BR     .+4
3356 013432 000401
  
```

```

3357 013434          ERROR 245          :DATA COMPARE ERROR
      013434 104245          EMT 245
3358
3359 013436 020067 001250      78:    CMP      RO,C1END          :ALL DONE?
3360 013442 001404          BEQ      84          :BR IF YES
3361 013444 005200          INC      RO
3362 013446 062701 000002      ADD      #2,R1
3363 013452 000762          BR       65          :ELSE DO AGAIN
3364
3365 013454 012737 026762 000020 88:    MOV      #SSCOPE,#IOTVEC          :RESET VECTOR 20 IN CASE USED
3366 013462 012737 000340 000022      MOV      #340,#IOTVEC+2          :SET TO LEVEL 7 AGAIN
3367 013470 000167 001222      JMP      TST25          :BR COULDN'T MAKE IT
3368
3373          ::*****
3374          :*
3375          :*          START OF SERVICE ROUTINES
3376          :*          *****
3377 013474 016702 165554      ROSRV:  MOV      BASE0,R2
3378 013500 062702 000002      ADD      #2,R2          :POINT TO RBUF
3379 013504 011220          MOV      (R2),(R0)+          :PUT IN TABLE
3380 013506 026767 001172 001172      CMP      COXMIT,COEND          :LAST CHAR?
3381 013514 001406          BEQ      18          :BR IF YES
3382 013516 005267 001162      INC      COXMIT          :ELSE BUMP CHAR TO XMIT NEXT
3383 013522 062702 000002      ADD      #2,R2          :POINT TO XCSR
3384 013526 052712 000100      BIS      #IE,(R2)          :RE-ENABLE
3385 013532 000002      18:    RTI
3386
3387 013534 016702 165514      XOSRV:  MOV      BASE0,R2
3388 013540 062702 000006      ADD      #6,R2          :POINT TO XBUF
3389 013544 032767 001000 165500      BIT      #BIT9,SDEVN          :INTERNAL OR EXTERNAL
3390 013552 001403          BEQ      18          :BR, IF EXTERNAL
3391 013554 052777 000004 165536      BIS      #BIT2,OTCSR          :SET MAINTENANCE BIT INT LOOP
3392 013562 016712 001116      18:    MOV      COXMIT,(R2)          :SHIP WORD
3393 013566 016702 000002      SUB      #2,R2          :POINT TO XCSR
3394 013572 052712 000100      BIC      #IE,(R2)          :DISABLE XMIT INTERR
3395
3396 013576 000002          RTI          :RE-ENABLE IN REC HANDLER
3397
3398
3399 013600 016702 165454      RISRV:  MOV      BASE1,R2
3400 013604 062702 000002      ADD      #2,R2          :POINT TO RBUF
3401 013610 011221          MOV      (R2),(R1)+          :PUT IN TABLE
3402 013612 026767 001072 001072      CMP      C1XMIT,C1END          :LAST CHAR?
3403 013620 001406          BEQ      18          :BR IF YES
3404 013622 005267 001062      INC      C1XMIT          :ELSE BUMP CHAR TO XMIT NEXT
3405 013626 062702 000002      ADD      #2,R2          :POINT TO XCSR
3406 013632 052712 000100      BIS      #IE,(R2)          :RE-ENABLE
3407 013636 000002      18:    RTI
3408
3409 013640 016702 165414      XISRV:  MOV      BASE1,R2
3410 013644 062702 000006      ADD      #6,R2          :POINT TO XBUF
3411 013650 032767 001000 165374      BIT      #BIT9,SDEVN          :INTERNAL OR EXTERNAL
3412 013656 001403          BEQ      18          :BR, IF EXTERNAL
3413 013660 052777 000004 165432      BIS      #BIT2,OTCSR          :SET MAINTENANCE BIT INT LOOP
3414 013666 016712 001016      18:    MOV      C1XMIT,(R2)          :SHIP WORD
3415 013672 062702 000002      SUB      #2,R2          :POINT TO XCSR
3416 013676 042712 000100      BIC      #IE,(R2)          :DISABLE XMIT INTERR
    
```

3417  
3418 013702 000002  
3419  
3420  
3421  
3422  
3423 013704  
3424 014304  
3425 014704  
3426  
3427 014704 000000  
3428 014706 000000  
3429 014710 000000  
3430 014712 000000  
3431 014714 000000  
3432

RTI

:RE-ENABLE IN REC HANDLER

\*\*\* RECEIVER STATUS TABLES \*\*\*  
CHOTAB: .BLKW 200  
CH1TAB: .BLKW 200  
STATEND:

: 0- 77  
:100-177

COXMIT: 0  
COEND: 0  
C1XMIT: 0  
C1END: 0  
SPTMR: 0

:START WORD FOR CH 0: 0  
:END WORD FOR CH 0:137 OR 177  
:START WORD FOR CH 1: 100  
:END WORD FOR CH 1: 137 OR 177  
:SPECIAL TIMER AREA



3439

```

*****
*TEST 25 TEST THAT CHANNELS INTR AT ASSIGNED PRIORITY.
* INTERRUPTS WILL BE ENABLED ON ALL ACTIVE CHANNELS.
* RECEIVER AND TRANSMITTER. THEN WE'LL CHECK TO
* SEE IF THEY INTERRUPTED IN THE ASSIGNED SEQUENCE.
*****

```

```

014716 000004
014720 012767 000001 164232
014726 012767 000025 164244
3444 014734 000240
3445
3446
3447 014736 042777 000004 164354
3448 014744 012700 000025
3449 014750 005100
3450 014752 032767 000100 164272
3451 014760 001002
3452 014762 110077 164316
3453 014766
3454 014766 032767 020000 164256
3455 014774 001002
3456 014776 000167 000654
3457 015002
3458 015002 032767 002000 164242
3459 015010 001402
3460 015012 000167 000640
3461 015016 005067 000624
3462 015022 005067 000622
3463 015026 005067 000620
3464 015032 005067 000616
3465
3470 015036 012746 000340
015042 012746 015050
015046 000002
015050
3475
3476
3477 015050 016700 164212
3478 015054 016767 164204 164230
3479 015062 016767 164270 164234
3480 015070 012720 015540
3481 015074 012720 000340
3482 015100 012720 015560
3483 015104 012710 000340
3484
3485 015110 016700 164150
3486 015114 052710 000100
3487 015120 062700 000004
3488 015124 032767 001000 164120
3489 015132 001402
3490 015134 052710 000004
3491 015140 052720 000100
3492
3493 015144 012710 000125
3494 015150 162700 000006
3495 015154 012767 100000 164144
3496 015162 032710 000200

```

```

TST25: SCOPE
MOV #1,STIMES ;;DO 1 ITERATION
MOV #25,STESTN ;;SET TEST NUMBER IN APT MAIL BOX
NOP ;;SPECIAL DEBUG FEATURE (GOOD HALT LOC)

501S:
BIC #BIT2,OTCSR ;CLEAR MAINTENANCE BIT
MOV #25,RO ;GET TEST NUMBER
COM RO ;1'S COMP TEST NUMBER
BIT #BIT6,SDEVH ;CAN THE LEDS BE USED
BNE 501S ;BR, IF THEY CAN'T
MOVB RO,BLEDREG ;DISPLAY TEST NUMBER IN LEDS

522S:
BIT #BIT13,SDEVH ;SECOND MXV11-B SELECTED?
BNE 522S ;BR, IF SELECTED IN DEVH
JMP TST26 ;EXIT TEST

10S:
BIT #BIT10,SDEVH ;CHECK FOR DATA WRAP
BEQ 10S ;BR, IF DATA WRAP SELECTED
JMP TST26 ;BR, IF WRAP NOT SELECTED
CLR INTABM ;CLEAR OUT INTERRUPT TABLE
CLR INTABM+2
CLR INTABM+4
CLR INTABM+6

64S:
MOV #PR7,-(SP) ;;PUT NEW PS ON STACK
MOV #64S,-(SP) ;;PUT NEW PC ON STACK
RTI ;;POP NEW PC AND PS

164230:
MOV VECT2,RO ;SETUP CH 0 VECTOR AREA
MOV BASE2,DLADD ;SET ERROR CALL UP
MOV VECT2,DLVEC ;SET ERROR CALL UP
MOV #CH2R,(RO)+ ;RCV
MOV #PR7,(RO)+ ;XMIT
MOV #CH2X,(RO)+
MOV #PR7,(RO)

680S:
MOV BASE2,RO ;ENABLE INTERRUPTS
BIS #IE,(RO) ;RCV
ADD #4,RO
BIT #BIT9,SDEVH ;INTERNAL OR EXTERNAL
BEQ 680S ;BR, IF EXTERNAL
BIS #BIT2,(RO) ;SET MAINTENANCE BIT INT LOOP
BIS #IE,(RO)+ ;XMIT

7S:
MOV #125,(RO) ;XMIT CHAR TO PRIME RECEIVERS
SUB #6,RO ;GO BACK TO RCSR
MOV #100000,TMP1
LIT #DONE,(RO) ;DONE?

```

```

3497 015165 001004          BNE      1$          ;BR IF YES
3498 015170 005367 164132   DEC      TMP1       ;TIMED OUT?
3499 015174 001372          BNE      7$          ;BR IF NO
3500 015176          ERROR   251       ;NO RCVR DONE
      015176 104251   EMT 251
3501
3502 015200 016700 164066   1$:  MOV     VECT3,R0    ;SETUP CH 1 VECTOR AREA
3503 015204 016767 164060 164100   MOV     BASE3,DLADD  ;SET ERROR CALL UP
3504 015212 016767 164054 164104   MOV     VECT3,DLVEC  ;SET ERROR CALL UP
3505 015220 012720 015602   MOV     #CH3R,(R0)+  ;RCV
3506 015224 012720 000340   MOV     #PR7,(R0)+
3507 015230 012720 015624   MOV     #CH3X,(R0)+  ;XMIT
3508 015234 012710 000340   MOV     #PR7,(R0)
3509
3510 015240 016700 164024   MOV     BASE3,R0    ;ENABLE INTERRUPTS
3511 015244 052710 000100   BIS     #IE,(R0)    ;RCV
3512 015250 062700 000004   ADD     #4,R0
3513 015254 032767 001000 163770   BIT     #BIT9,$DEVH ;INTERNAL OR EXTERNAL
3514 015262 001402          BEQ     690$
3515 015264 052710 000004   BIS     #BIT2,(R0)  ;BR, IF EXTERNAL
3516 015270 052720 000100 690$: BIS     #IE,(R0)+  ;SET MAINTENANCE BIT INT LOOP
3517
3518 015274 012710 000125   MOV     #125,(R0)   ;XMIT CHAR TO PRIME RECEIVERS
3519 015300 162700 000006   SUB     #6,R0       ;GC BACK TO RCSR
3520 015304 012767 100000 164014   MOV     #100000,TMP1
3521 015312 032710 000200 8$:  BIT     #DONE,(R0)  ;DONE?
3522 015316 001004          BNE     2$          ;BR IF YES
3523 015320 005367 164002   DEC     TMP1        ;TIMED OUT?
3524 015324 001372          BNE     8$          ;BR IF NO
3525 015326          ERROR   252       ;NO RCVR DONE
      015326 104252   EMT 252
3526
3527
3528
3529
3530
3531
3532
3533
3534
3535 015330 012704 015646   2$:  MOV     #INTABN,R4  ;SETUP FOR SERVICE ROUTINES
3536 015334 000402          BR      6$
3537
3538 015336 012704 015652   5$:  MOV     #INTABN+4,R4
3539
3540 015342 012700 177777   6$:  MOV     #-1,R0      ;DELAY TO ALLOW ANY PREVIOUS XMIT TO
3541 015346 077001          SOB     R0          ;FINISH BEFORE RESET
3542 015350 012700 177777   MOV     #-1,R0      ;DELAY TO ALLOW ANY PREVIOUS XMIT TO
3543 015354 077001          SOB     R0          ;FINISH BEFORE RESET
3544
3549 015356 012746 000000   MOV     #PRO,-(SP)  ;;PUT NEW PS ON STACK
      015362 012746 015370   MOV     #65$,-(SP) ;;PUT NEW PC ON STACK
      015366 000002          RTI              ;;POP NEW PC AND PS
      015370
3554 015370 012700 177777   65$: MOV     #-1,R0      ;DELAY TO ALLOW ANY PREVIOUS XMIT TO
3555 015374 077001          SOB     R0          ;FINISH BEFORE RESET
3556 015376 000005          RESET          ;DISABLE ALL INTERRUPTS

```

```

3561 015400 012746 000340      MOV    #PR7,-(SP)      ;;PUT NEW PS ON STACK
      015404 012746 015412      MOV    #668,-(SP)     ;;PUT NEW PC ON STACK
      015410 000002                      RTI                    ;;POP NEW PC AND PS
      015412                      668:
3566
3567
3568                                ;NOW LETS SEE IF INTABM HAS ENTRIES IN THE CORRECT O
3569 015412 016767 163646 163672      MOV    BASE2,DLADD     ;SET ERROR CALL UP
3570 015420 016767 163542 163676      MOV    VECT2,DLVEC    ;SET ERROR CALL UP
3571
3572 015426 005767 000214      TST    INTABM          ;1'ST ENTRY 0?
3573 015432 001401              BEQ    .+4             ;BR IF YES
3574 015434 104253              ERROR  253            ;DID NOT INTERR AT ASSIGNED PRIOR
      015434                      EMT 253
3575
3576 015436 026727 000206 000001      CMP    INTABM+2,#1     ;2'ND ENTRY 1?
3577 015444 001401              BEQ    .+4             ;BR IF YES
3578 015446 104254              ERROR  254
      015446                      EMT 254
3579
3580 015450                      38:
3581 015450 016767 163614 163634      MOV    BASE3,DLADD     ;SET ERROR CALL UP
3582 015456 016767 163610 163640      MOV    VECT3,DLVEC    ;SET ERROR CALL UP
3583
3584 015464 026727 000162 000002      CMP    INTABM+4,#2     ;3'RD ENTRY 2?
3585 015472 001401              BEQ    .+4             ;BR IF YES
3586 015474 104255              ERROR  255
      015474                      EMT 255
3587
3588 015476 026727 000152 000003      CMP    INTABM+6,#3     ;4'TH ENTRY 3?
3589 015504 001401              BEQ    .+4             ;BR IF YES
3590 015506 104256              ERROR  256
      015506                      EMT 256
3591 015510                      48:
3592 015510 000402                      BR     5038            ;GOOD BRANCH ETC
3593 015512 000167 177574          5028: JMP     88              ;REALLY EXIT TEST
3594 015516 117700 163574          5038: MOV    @RBUF,R0        ;CLEAR OUT REC BUFFER
3595 015522 012737 026762 000020      MOV    #SCOPE,@IOTVEC ;RESET VECTOR 20 IN CASE USED
3596 015530 012737 000340 000022      MOV    #340,@IOTVEC+2 ;SET TO LEVEL 7 AGAIN
3597
3602 015536 000447                      BR     TST26          ;;EXIT TEST
3607
3608
3609                                ;*****
3610                                ;*          START OF SERVICE ROUTINES
3611                                ;*****
3612
3613 015540 005024                      CH2R: CLR    (R4)+       ;PUT IDENTIFIER IN TABLE
3614 015542 016700 163516          MOV    BASE2,R0
3615 015546 042710 000100          BIC   #IE,(R0)
3616 015552 116701 163510          MOV   BASE2+2,R1     ; 1 INTERR IS ALL WE WANT
3617 015556 000002                      RTI                    ;CLEAN OUT THE REC BUFFER
3618
3619 015560 012724 000001                      CH2X: MOV    #1,(R4)+   ;PUT IDENTIFIED IN TABLE
3620 015564 016700 163474          MOV    BASE2,R0
3621 015570 042700 000004          ADD   #4,R0
3622 015574 042710 000100          BIC   #IE,(R0)       ; 1 INTERR IS ALL WE WANT
    
```

```
3623 015600 000002 RTI
3624
3625 015602 012724 000002 CH3R: MOV #2,(R4)+ :PUT IDENTIFIER IN TABLE
3626 015606 016700 163456 MOV BASE3,RO
3627 015612 042710 000100 BIC #1E,(R0) : 1 INTERR IS ALL WE WANT
3628 015616 116701 163450 MOVB BASE3+2,R1 :CLEAN OUT THE REC BUFFER
3629 015622 000002 RTI
3630
3631 015624 012724 000003 CH3X: MOV #3,(R4)+ :PUT IDENTIFIED IN TABLE
3632 015630 016700 163434 MOV BASE3,RO
3633 015634 062700 000004 ADD #4,RO
3634 015640 042710 000100 BIC #1E,(R0) : 1 INTERR IS ALL WE WANT
3635 015644 000002 RTI
3636
3637
3638
3639
3640
3641
3642
3643 015646 INTABM: .BLKW 4
3644
3645
```

:THIS TABLE WILL CONTAIN ENTRIES  
:REPRESENTING EACH INTR IN THE ORDER  
:THAT IT OCCURED  
: S/B IN THE FOLLOWING ORDER: 0,1,2,3

3662

```

*****
:TEST 26      TEST DATA XFRS, ALL ACTIVE LINES INTERRUPTING
:              IN THIS WE'LL ENABLE INTERRUPTS ON ALL CHANNELS.
:              THEN WE'LL XMIT AN INCREMENTING
:              DATA PATERN VIA INTERRUPTS AND RECORD THE RECEIVER
:              INTR. IN THE RECEIVER STATUS TABLE.
:              NOTE: DOUBLE BUFFERING CANNOT BE TESTED AT ITS MAX SPEED
:              BECAUSE OF APT CONSIDERATIONS. I.E. APT SENDS
:              'BREAKS' WHICH CAUSE OVERRUN ERRORS. THEREFORE
:              THE XMIT IE IS NOT ENABLED AGAIN UNTIL THE RECVR
:              HAS OBTAINED THE PREVIOUS WORD.
*****

```

```

015656 000004
015660 012767 0000G1 163272
015666 012767 000026 163304
3667 015674 000240
3668
3669
3670 015676 042777 000004 163414
3671 015704 012700 000026
3672 015710 005100
3673 015712 032767 000100 163332
3674 015720 001002
3675 015722 110077 163356
3676 015726
3677 015726 032767 020000 163316
3678 015734 001002
3679 015736 000167 000612
3680 015742
3681 015742 032767 002000 163302
3682 015750 001402
3683 015752 000157 000576
3684 015756 032767 001000 163266
3685 015764 001414
3686 015766 016700 163272
3687 015772 062700 000004
3688 015776 052710 000004
3689 016002 016700 163262
3690 016006 062700 000004
3691 016012 052710 000004
3692 016016 016767 163242 163272
3693 016024 062767 000002 163264
3694 016032 117701 163260
3695 016036 004567 004524
3696 016042 001264
3697 016044 000200
3698 016046 000401
3699 016050 000770
3700 016052
3701 016052 016767 163212 163236
3702 016060 062767 000002 163230
3703 016066 117701 163224
3704 016072 004567 004470
3705 016076 001270
3706 016100 000200
3707 016102 000401
3708 016104 000770

TST26: SCOPE
MOV #1,STIMES ;;DO 1 ITERATION
MOV #26,STESTN ;;SET TEST NUMBER IN APT MAIL BOX
NOP ;;SPECIAL DEBUG FEATURE (GOOD HALT LOC)

;CLEAR MAINTENANCE BIT
;GET 1ST NUMBER
;1'S COMP TEST NUMBER
;CAN THE LEDS BE USED
;BR, IF THEY CAN'T
;DISPLAY TEST NUMBER IN LEDS

501$: BIT #BIT13,$DEVH ;SECOND MXV11-B SELECTED
BNE 502$ ;BR, IF SELECTED IN DEVH
JMP 8$ ;EXIT TEST (NOT SELECTED)

502$: BIT #BIT10,$DEVH ;CHECK FOR DATA WRAP
BFG 503$ ;BR, IF DATA WRAP SELECTED
JMP 8$ ;BR, IF WRAP NOT SELECTED

503$: BIT #BIT9,$DEVH ;CHECK FOR MAINTENANCE BIT (LOOP)
BEQ 9$ ;BR, IF NOT SET
MOV BASE2,R0 ;GET ADDRESS OF 2ND MX'S 1ST LINE
ADD #4,R0 ;POINT AT THE TRANSMITTER'S CSR
BIS #BIT2,(R0) ;SET INTERNAL LOOP BACK BIT
MOV BASE3,R0 ;GET ADDRESS OF 2ND MX'S 2ND LINE
ADD #4,R0 ;POINT AT THE TRANSMITTER'S CSR
BIS #BIT2,(R0) ;SET INTERNAL LOOP BACK BIT
MOV BASE2,R0F ;GET BASE ADDRESS
ADD #2,RBUF ;NOW POINTS TO REC BUFFER
MOVB @RBUF,R1 ;READ REC BUFFER
JSR R5,TIMER ;CALL TIMER ROUTINE
BASE2 ;ADDRESS OF CSR
DONE ;DONE CHECK BITS
BR 12$ ;BR, IF DONE IS NOT SET
BR 11$ ;BR, TO TRY AND CLEAR REC DONE

12$:
19$: MOV BASE3,RBUF ;GET BASE ADDRESS
ADD #2,RBUF ;NOW POINTS TO REC BUFFER
MOVB @RBUF,R1 ;READ REC BUFFER
JSR R5,TIMER ;CALL TIMER ROUTINE
BASE3 ;ADDRESS OF CSR
DONE ;DONE CHECK BITS
BR 112$ ;BR, IF DONE IS NOT SET
BR 111$ ;BR, TO TRY AND CLEAR REC DONE

```

```

3709 016106          1128:
3710 016106 032767 002000 163136 BIT #BIT10,SDEVN ;CHECK FOR DATA WRAP
3711 016114 001402 BEQ 108 ;BR, IF DATA WRAP SELECTED
3712 016116 000167 000432 JMP 88 ;BR, IF WRAP NOT SELECTED
3713 016122 005067 001656 108: CLR C?XMIT ;1'ST WORD OF CH 0 TO XMIT
3714 016126 012767 000100 001654 MOV #100,C3XMIT ;1'ST WORD OF CH 1 TO XMIT
3715
3716 016134 012700 017004 MOV #CH2TAB,RO ;CLEAR OUT RECEIVER TABLES
3717 016140 005020 CLR (RO)+
3718 016142 020027 020004 CMP RO,#STTEND ;ALL DONE?
3719 016146 001374 BNE -6 ;BR IF NO
3720
3725 016150 012746 000340 MOV #PR7,-(SP) ;;PUT NEW PS ON STACK
016154 012746 016162 MOV #648,-(SP) ;;PUT NEW PC ON STACK
016160 000002 RTI ;;POP NEW PC AND PS
016162
3730 648:
3731 016162 016700 163100 MOV VECT2,RO ;SETUP CH 0 VECTOR AREA
3732 016166 016767 163072 163116 MOV BASE2,DLADD ;SET ERROR CALL UP
3733 016174 016767 163066 163122 MOV VECT2,DLVEC ;SET ERROR CALL UP
3734 016202 012720 016574 MOV #R2SRV,(RO)+ ;RCVR
3735 016206 012720 000340 MOV #PR7,(RO)+
3736 016212 012720 016634 MOV #X2SRV,(RO)+ ;XMIT
3737 016216 012710 000340 MOV #PR7,(RO)
3738
3739 016222 016700 163036 MOV BASE2,RO ;ENABLE INTERRUPTS
3740 016226 052710 000100 BIS #IE,(RO) ;RCVR
3741 016232 062700 000004 ADD #4,RO
3742 016236 052710 000100 BIS #IE,(RO) ;XMIT
3743
3744 016242 012767 000177 001536 MOV #177,C2END ;8 BIT CHARACTER
3745
3746 016250 016700 163016 18: MOV VECT3,RO ;SETUP CH 1 VECTOR AREA
3747 016254 016767 163010 163030 MOV BASE3,DLADD ;SET ERROR CALL UP
3748 016262 016767 163004 163034 MOV VECT3,DLVEC ;SET ERROR CALL UP
3749 016270 012720 015700 MOV #R3SRV,(RO)+ ;RCVR
3750 016274 012720 000340 MOV #PR7,(RO)+
3751 016300 012720 016740 MOV #X3SRV,(RO)+ ;XMIT
3752 016304 012710 000340 MOV #PR7,(RO)
3753
3754 016310 016700 162754 MOV BASE3,RO ;ENABLE INTERRUPTS
3755 016314 052710 000100 BIS #IE,(RO) ;RCVR
3756 016320 062700 000004 ADD #4,RO
3757 016324 052710 000100 BIS #IE,(RO) ;XMIT
3758
3759
3760 016330 012767 000177 001454 MOV #177,C3END ;8 BIT CHARACTERS
3761 016336 012700 017004 28: MOV #CH2TAB,RO ;INIT BUFFER PTRS FOR SERV ROUTINES
3762 016342 012701 017404 MOV #CH3TAB,R1
3763
3768 016346 012746 000000 MOV #PRO,-(SP) ;;PUT NEW PS ON STACK
016352 012746 016360 MOV #658,-(SP) ;;PUT NEW PC ON STACK
016356 000002 RTI ;;POP NEW PC AND PS
016360
3773 658:
3774 016360 012767 000040 176326 MOV #32,,SPTMR ;SET UP SPECIAL TIMER
3775 016366 012703 177777 6508: MOV #-1,R3 ;DELAY TO ALLOW ANY PREVIOUS XMIT TO
  
```



```

3834 016554 012737 026762 000020 8S:  MOV  #SSCOPE,#IOTVEC      :RESET VECTOR 20 IN CASE 'SED
3835 014562 012737 000340 000022      MOV  #340,#IOTVEC+2    :SET TO LEVEL 7 AGAIN
3836 016570 000167 172004      JMP  NOTST
3837
3842
3843      :*****
3844      :*          START OF SERVICE ROUTINES
3845      :*****
3846 016574 016702 162464      R2SRV: MOV  BASE2,R2
3847 016600 062702 000002      ADD  #2,R2              :POINT TO RBUF
3848 016604 011220      MOV  (R2),(R0)+         :PUT IN TABLE
3849 016606 026767 001172 001172  CMP  C2XMIT,C2END      :LAST CHAR?
3850 016614 001406      BEQ  1$                :BR IF YES
3851 016616 005267 001162      INC  C2XMIT            :ELSE BUMP CHAR TO XMIT NEXT
3852 016622 062702 000002      ADD  #2,R2              :POINT TO XCSR
3853 016626 052712 000100      BIS  #IE,(R2)          :RE-ENABLE
3854 016632 000004      1$:  RTI
3855
3856 016634 016702 162424      X2SRV: MOV  BASE2,R2
3857 016640 062702 000006      ADD  #6,R2              :POINT TO XBUF
3858 016644 032767 001000 162400  BIT  #BIT9,$DEVN       :INTERNAL OR EXTERNAL
3859 016652 001403      BEQ  1$                :BR, IF EXTERNAL
3860 016654 052777 000004 162436  BIS  #BIT2,@TCSR       :SET MAINTENANCE BIT INT LOOP
3861 016662 016712 001116      1$:  MOV  C2XMIT,(R2)    :SHIP WORD
3862 016666 162702 000002      SUB  #2,R2              :POINT TO XCSR
3863 016672 042712 000100      BIC  #IE,(R2)          :DISABLE XMIT INTERR
3864
3865 016676 000002      RTI                    :RE-ENABLE IN REC HANDLER
3866
3867
3868 016700 016702 162364      R3SRV: MOV  BASE3,R2
3869 016704 062702 000002      ADD  #2,R2              :POINT TO RBUF
3870 016710 011221      MOV  (R2),(R1)+         :PUT IN TABLE
3871 016712 026767 001072 001072  CMP  C3XMIT,C3END      :LAST CHAR?
3872 016720 001406      BEQ  1$                :BR IF YES
3873 016722 005267 001062      INC  C3XMIT            :ELSE BUMP CHAR TO XMIT NEXT
3874 016726 062702 000002      ADD  #2,R2              :POINT TO XCSR
3875 016732 052712 000100      BIS  #IE,(R2)          :RE-ENABLE
3876 016736 000002      1$:  RTI
3877
3878 016740 016702 162324      X3SRV: MOV  BASE3,R2
3879 016744 062702 000006      ADD  #6,R2              :POINT TO XBUF
3880 016750 032767 001000 162274  BIT  #BIT9,$DEVN       :INTERNAL OR EXTERNAL
3881 016756 001403      BEQ  1$                :BR, IF EXTERNAL
3882 016760 052777 000004 162332  BIS  #BIT2,@TCSR       :SET MAINTENANCE BIT INT LOOP
3883 016766 016712 001016      1$:  MOV  C3XMIT,(R2)    :SHIP WORD
3884 016772 162702 000002      SUB  #2,R2              :POINT TO XCSR
3885 016776 042712 000100      BIC  #IE,(R2)          :DISABLE XMIT INTERR
3886
3887 017002 000002      RTI                    :RE-ENABLE IN REC HANDLER
3888

```



3890  
3891

\*\*\* RECEIVER STATUS TABLES \*\*\*

3892  
3893 017004  
3894 017404  
3895 020004

CH2TAB: .BLKW 200  
CH3TAB: .BLKW 200  
STTEND:

:8 BIT WDS  
: 0- 77  
:100-177

3896  
3897 020004 000000  
3898 020006 000000  
3899 020010 000000  
3900 020012 000000  
3901

C2XMIT: 0  
C2END: 0  
C3XMIT: 0  
C3END: 0

:START WORD FOR CH 0: 0  
:END WORD FOR CH 0: 137 OR 177  
:START WORD FOR CH 1: 100  
:END WORD FOR CH 1: 137 OR 177

```

3903
3904
3905          .SBTTL  ROUTINE TO SIZE THE DEVICE MAP ($DEVN) & MEMORY
3906
3907 020014 032767 100000 161230 SIZE:  BIT    #BIT15,$DEVN      ;TEST CH 0?
3908 020022 001424                BEQ    1$                ;BR IF YES
3909 020024 104401 0231'6          TYPE   ,CODROP
3910 020030 032767 000400 161214  BIT    #BIT8,$DEVN      ;TEST CH 1?
3911 020036 001055                BNE    2$                ;BR IF YES
3912 020040 104401 023146          TYPE   ,CIDROP
3913 020044 032767 020000 161200  BIT    #BIT13,$DEVN     ;TWO MXV11-B BIT
3914 020052 001016                BNE    111$             ;BR, IF THERE ARE TWO (TO BE TESTED)
3915 020054 104401 024226          TYPE   ,TWMXN           ;"SECOND MXV11-B TEST BYPASSED"
3916 020060 012767 000002 002274  MOV    #2,HICHAN       ;SET TO TWO POSSIBLE CHANNELS
3917 020066 005267 001322          INC    NOCHAN          ;SET FLAG
3918 020072 000471                BR     4$
3919
3920 020074 032767 000400 161150 1$:  BIT    #BIT8,$DEVN      ;TEST CH 1?
3921 020102 001033                BNE    2$                ;BR IF YES
3922 020104 104401 023146          TYPE   ,CIDROP
3923 020110 032767 020000 161134 111$: BIT    #BIT13,$DEVN     ;TWO MXV11-B BIT
3924 020116 001025                BNE    2$                ;BR, IF THERE ARE TWO (TO BE TESTED)
3925 020120 104401 024226          TYPE   ,TWMXN           ;"SECOND MXV11-B TEST BYPASSED"
3926 020124 012767 000002 002230  MOV    #2,HICHAN       ;SET TO TWO POSSIBLE CHANNELS
3927 020132 026767 161122 161004  CMP    BASE1,$TKS      ;CONSOLE?
3928 020140 001103                BNE    41$              ;NO, KEEP GOING
3929 020142 104401 024115          TYPE   ,CICON
3930 020146 032767 000400 161076  BIT    #BIT8,$DEVN     ;CHECK FOR CHANNEL 1 USE
3931 020154 001405                BEQ    401$             ;BR, IF NOT BEING TESTED
3932 020156 104401 023227          TYPE   ,NOCH1          ;CAN'T TEST CH1 WHEN CONSOLE
3933 020162 104412                GTDEVN ;NEW DEVN
3934 020164 000167 161224          JMP    START           ;REALLY START OVER
3935 020170                401$:
3936
3937 020170 000425                BR     3$
3938
3939 020172 026767 161062 160744 2$:  CMP    BASE1,$YKS      ;IS IT CONSOLE?
3940 020200 001021                BNE    3$                ;BR IF NO
3941 020202 104401 024115          TYPE   ,CICON
3942 020206 032767 000400 161036  BIT    #BIT8,$DEVN     ;CHECK FOR CHANNEL 1 USE
3943 020214 001405                BEQ    402$             ;BR, IF NOT BEING TESTED
3944 020216 104401 023227          TYPE   ,NOCH1          ;CAN'T TEST CH1 WHEN CONSOLE
3945 020222 104417                GTDEVN ;NEW DEVN
3946 020224 000167 161164          JMP    START           ;REALLY START OVER
3947 020230                402$:
3948 020230 032767 020000 161014  BIT    #BIT13,$DEVN     ;TWO MXV11-B BIT
3949 020236 001002                BNE    3$                ;BR, IF THERE ARE TWO (TO BE TESTED)
3950 020240 104401 024226          TYPE   ,TWMXN           ;"SECOND MXV11-B TEST BYPASSED"
3951 020244 012767 000002 002110 3$:  MOV    #2,HICHAN       ;HIGHEST CHANNEL NUMBER
3952 020252 005067 001136          CLR    NOCHAN
3953
3954 020256 032767 020000 160766 4$:  BIT    #BIT13,$DEVN     ;CHECK TWO MXV11-B BIT
3955 020264 001431                BEQ    41$              ;BR, NO SECOND MX TESTING
3956 020266 104401 024265          TYPE   ,TWMXN           ;"TESTING SECOND MXV11-B"
3957 020272 013746 000004          MOV    @ERRVEC,-(SP)   ;HOLD PRESENT VECTOR
3958 020276 012737 020312 000004  MOV    #100,@ERRVEC    ;NEW GUY IN PLACE
3959 020304 005777 160754          TST   @BASE2          ;TRY READ
  
```

3960	020310	000412				BR	120\$		:NO PROBLEM KEEP GOING
3961	020312	012716	020320	100\$:		MOV	#105\$, (SP)		:HAD PROBLEM
3962	020316	000002				RTI			:RETURN
3963	020320	012637	000004	105\$:		MOV	(SP)+, @ERRVEC		:RESET VECTOR
3964	020324	104401	023675			TYPE	,NOSMK		:SECOND MXV11-B WAS SELECTED NOT PRESENT
3965	020330	104412				GTDEVN			:TRY AGAIN
3966	020332	000167	161056			JMP	START		:REALLY START OVER
3967	020336	012637	000004	120\$:		MOV	(SP)+, @ERRVEC		:RESET VECTOR
3968	020342	012767	000004	002012		MOV	#4, HICHAN		:HIGHEST CHANNEL NUMBER
3969	020350			41\$:					
3970	020350	032767	000004	160674		BIT	#BIT2, \$DEVN		:DO RAM TEST?
3971	020356	C01402				BEQ	10\$		:BR IF YES
3972	020360	104401	024163			TYPE	,NORAM		
3973									
3974	020364	032767	000002	160660	10\$:	BIT	#BIT1, \$DEVN		:DO ROM TEST?
3975	020372	001002				BNE	5\$		:BR IF YES
3976	020374	104401	024140			TYPE	,NOROM		
3977									
3978	020400	032767	000001	160644	5\$:	BIT	#BIT0, \$DEVN		:CLOCK DISABLED?
3979	020406	001427				BEQ	50\$		:BR IF YES
3980	020410	104401	024207			TYPE	,CLKEN		
3981	020414	013746	000004			MOV	@ERRVEC, -(SP)		:HOLD PRESENT VECTOR
3982	020420	012737	020434	000004		MOV	#200\$, @ERRVEC		:NEW GUY IN PLACE
3983	020426	005777	160654			TST	@LKSREG		:TRY READ
3984	020432	000412				BR	220\$		:NO PROBLEM KEEP GOING
3985	020434	012716	020442	200\$:		MOV	#205\$, (SP)		:HAD PROBLEM
3986	020440	000002				RTI			:RETURN
3987	020442	012637	000004	205\$:		MOV	(SP)+, @ERRVEC		:RESET VECTOR
3988	020446	104401	023750			TYPE	,NOCLK		:SECOND MXV11-B WAS SELECTED NOT PRESENT
3989	020452	104412				GTDEVN			:TRY AGAIN
3990	020454	000167	160734			JMP	START		:REALLY START OVER
3991	020460	012637	000004	220\$:		MOV	(SP)+, @ERRVEC		:RESET VECTOR
3992									
3993	020464	000402				BR	51\$		:SKIP OVER MESSAGE
3994	020466	104401	023277	50\$:		TYPE	,CLKDS		:CLOCK DISABLED MESSAGE
3995									
3996	020472	032767	000200	160552	51\$:	BIT	#BIT7, \$DEVN		:PCR REGISTER TESTING?
3997	020500	001403				BEQ	52\$		:BR IF YES
3998	020502	104401	024061			TYPE	,NOPCR		:PCR REGISTER TEST BYPASSED"
3999	020506	000424				BR	53\$		:SKIP OVER CHECK AND MESSAGE
4000	020510			52\$:					
4001	020510	013746	000004			MOV	@ERRVEC, -(SP)		:HOLD PRESENT VECTOR
4002	020514	012737	020530	000004		MOV	#500\$, @ERRVEC		:NEW GUY IN PLACE
4003	020522	005777	160562			TST	@PCRREG		:TRY READ
4004	020526	000412				BR	520\$		:NO PROBLEM KEEP GOING
4005	020530	012716	020536	500\$:		MOV	#505\$, (SP)		:HAD PROBLEM
4006	020534	000002				RTI			:RETURN
4007	020536	012637	000004	505\$:		MOV	(SP)+, @ERRVEC		:RESET VECTOR
4008	020542	104401	023317			TYPE	,NOPCR2		:PCR REGISTER NOT PRESENT
4009	020546	104412				GTDEVN			:TRY AGAIN
4010	020550	000167	160640			JMP	START		:REALLY START OVER
4011	020554	012637	000004	520\$:		MOV	(SP)+, @ERRVEC		:RESET VECTOR
4012									
4013	020560	032767	000100	160464	53\$:	BIT	#BIT6, \$DEVN		:LEDS TO BE USED/TESTED?
4014	020566	001403				BEQ	66\$		:BR IF YES
4015	020570	104401	023176			TYPE	,NOLED		:LEDS NOT USED OR TESTED"
4016	020574	000424				BR	6\$		:SKIP OTHER STUFF

4017									
4018	020576				66\$:				
4019	020576	013746	000004			MOV	#ERRVEC, -(SP)		:HOLD PRESENT VECTOR
4020	020602	012737	020616	000004		MOV	#300\$, #ERRVEC		:NEW GUY IN PLACE
4021	020610	005777	160470			TST	!FDREG		:TRY READ
4022	020614	000412				BR	320\$		:NO PROBLEM KEEP GOING
4023	020616	012716	020624		300\$:	MOV	#305\$, (SP)		:HAD PROBLEM
4024	020622	000002				RTI			:RETURN
4025	020624	012637	000004		305\$:	MOV	(SP)+, #ERRVEC		:RESET VECTOR
4026	020630	104401	024012			TYPE	,NODDR		:NO DDR REGISTER FOUND
4027	020634	104412				GTDEVN			:TRY AGAIN
4028	020636	000167	160552			JMP	START		:REALLY START OVER
4029	020642	012637	000004		320\$:	MOV	(SP)+, #ERRVEC		:RESET VECTOR
4030									
4031	020646				6\$:				
4032	020646	032767	010000	160376		BIT	#<BIT12>, \$DEVN		:MEM MNGT SELECTED
4033	020654	001024				BNE	625\$		:BR, IF NOT SELECTED (I BELIEVE)
4034	020656	013746	000004			MOV	#ERRVEC, -(SP)		:HOLD PRESENT VECTOR
4035	020662	012737	020676	000004		MOV	#600\$, #ERRVEC		:NEW GUY IN PLACE
4036	020670	005767	151444			TST	PAR0		:TRY READ MEMORY MANAGEMENT REGISTER
4037	020674	000412				BR	620\$		:NO PROBLEM KEEP GOING
4038	020676	012716	020704		600\$:	MOV	#605\$, (SP)		:HAD PROBLEM
4039	020702	000002				RTI			:RETURN
4040	020704	012637	000004		605\$:	MOV	(SP)+, #ERRVEC		:RESET VECTOR
4041	020710	104401	023630			TYPE	,NOMMNGT		:NO MEMORY MANAGEMENT PRESENT
4042	020714	104412				GTDEVN			:TRY AGAIN
4043	020716	000167	160472			JMP	START		:REALLY START OVER
4044	020722	012637	000004		620\$:	MOV	(SP)+, #ERRVEC		:RESET VECTOR
4045	020726				625\$:				
4046	020726	032767	000001	160316		BIT	#<BIT0>, \$DEVN		:IS LINE CLOCK SELECTED
4047	020734	001021				BNE	825\$		:BR, IF SELECTED
4048	020736	013746	000004			MOV	#ERRVEC, -(SP)		:HOLD PRESENT VECTOR
4049	020742	012737	020766	000004		MOV	#700\$, #ERRVEC		:NEW GUY IN PLACE
4050	020750	005777	160332			TST	BLKSREG		:TRY AND LOOK AT CLOCK REGISTER
4051	020754	012637	000004			MOV	(SP)+, #ERRVEC		:RESTORE THE VECTOR
4052	020760	104401	023375			TYPE	,LNKMSG		: "LNK AVAIL BUT NOT TESTED"
4053	020764	000405				BR	825\$		:NO PROBLEM KEEP GOING
4054	020766	012716	020774		700\$:	MOV	#705\$, (SP)		:NO PROBLEM IT IS NOT THERE
4055	020772	000002				RTI			:RETURN
4056	020774	012637	000004		705\$:	MOV	(SP)+, #ERRVEC		:RESET VECTOR
4057									
4058	021000	032767	000100	160244	825\$:	BIT	#<BIT6>, \$DEVN		:IS DDR BEING TESTED
4059	021006	001421				BEQ	925\$		:BR, IF SELECTED
4060	021010	013746	000004			MOV	#ERRVEC, -(SP)		:HOLD PRESENT VECTOR
4061	021014	012737	021040	000004		MOV	#800\$, #ERRVEC		:NEW GUY IN PLACE
4062	021022	005777	160256			TST	!LEDREG		:TRY AND LOOK AT DDR REGISTER
4063	021026	012637	000004			MOV	(SP)+, #ERRVEC		:RESTORE THE VECTOR
4064	021032	104401	023442			TYPE	,DDRMSG		: "DDR AVAIL BUT NOT TESTED"
4065	021036	000405				BR	925\$		:NO PROBLEM KEEP GOING
4066	021040	012716	021046		800\$:	MOV	#805\$, (SP)		:NO PROBLEM IT IS NOT THERE
4067	021044	000002				RTI			:RETURN
4068	021046	012637	000004		805\$:	MOV	(SP)+, #ERRVEC		:RESET VECTOR
4069	021052	032767	000200	160172	925\$:	BIT	#<BIT7>, \$DEVN		:IS PCR REGISTER SELECTED
4070	021060	001421				BEQ	975\$		:BR, IF SELECTED
4071	021062	013746	000004			MOV	#ERRVEC, -(SP)		:HOLD PRESENT VECTOR
4072	021066	012737	021112	000004		MOV	#900\$, #ERRVEC		:NEW GUY IN PLACE
4073	021074	005777	160210			TST	!PCRREG		:TRY AND LOOK AT PCR REGISTER

4074	021100	012637	000004		MOV	(SP)+,B#ERRVEC	:RESTORE THE VECTOR	
4075	021104	104401	023561		TYPE	,PCMSG	: 'PCR AVAIL BUT NOT TESTED'	
4076	021110	000405			BR	9758	:NO PROBLEM KEEP GOING	
4077	021112	012716	021120	9008:	MOV	#9058,(SP)	:NO PROBLEM IT IS NOT THERE	
4078	021116	000002			RTI		:RETURN	
4079	021120	012637	000004	9058:	MOV	(SP)+,B#ERRVEC	:RESET VECTOR	
4080	021124			9758:				
4081	021124	012767	021522	156652	MOV	#INTSRV,ERRVEC	:SETUP TIMEOUT TRAP ADDR	
4082	021132	012767	000200	156646	MOV	#200,ERRVEC+2	:LOCKOUT INTERR	
4083	021140	005067	000364		CLR	INTFLG		
4084	021144	012700	020000		MOV	#20000,R0	:GO TO BOT OF NEXT 4K	
4085								
4086	021150	005001			CLR	R1	:MEM MAP. 0=4K, 1=8K, ETC	
4087								
4088	021152	011010		78:	MOV	(R0),(R0)	:DO MOV INSTEAD OF 'TST'	
4089	021154	005767	000350		TST	INTFLG	:GOT TIMEOUT INTERR?	
4090	021160	001006			BNE	88	:BR IF YES	
4091	021162	005201			INC	R1		
4092	021164	062700	020000		ADD	#20000,R0	:GO TO BOT OF NEXT 4K	
4093	021170	020027	160000		CMP	R0,#160000	:BOT OF 32K?	
4094	021174	001366			BNE	78	:BR IF NO	
4095								
4096	021176	010067	000316	88:	MOV	R0,MAXMEM	:SAVE	
4097	021202	162767	000002	000310	SUB	#2,MAXMEM	:GO BACK TO TOP OF LAST VALID BLOCK	
4098	021210	032767	010000	160034	BIT	#BIT12,SDEVN	:CHECK FOR MEMORY MNGT OPTION	
4099	021216	001405			BEQ	858	:BR, IF MEMORY MNGT IS SELECTED	
4100	021220	006301			ASL	R1	:MULT BY 2	
4101	021222	016167	021416	000142	MOV	MENTBL(R1),98		
4102	021230	000457			BR	198		
4103	021232	012701	172340	858:	MOV	#PAR0,R1	:PRINT SIZE	
4104	021236	012705	172300		MOV	#PDR0,R5	:START OF PAR REGISTERS	
4105	021242	005000			CLR	R0	:START OF THE PDR REGISTERS	
4106	021244	010021		208:	MOV	R0,(R1)+	:FIRST PAGE BASE ADDRESS	
4107	021246	012725	077406		MOV	#77406,(R5)+	:SET BASE FOR NEXT MAP	
4108	021252	062700	000200		ADD	#200,R0	:4K READ/WRITE EACH PAGE	
4109	021256	020027	001600		CMP	R0,#1600	:BASE FOR THE NEXT PAGE	
4110	021262	003770			BLS	208	:DONE ALL PAGES ?	
4111	021264	012741	007600		MOV	#7600,-(R1)	:SET UP ALL MEMORY MANAGEMENT PAGES	
4112	021270	052737	000001	177572	BIS	#1,B#SR0	:SET UP I/O PAGE	
4113	021276	012704	000200		MOV	#200,R4	:ENABLE MEMORY MANAGEMENT	
4114	021302	010437	172354	158:	MOV	R4,B#PAR6	:4K INC VALUE FOR PAR6	
4115	021306	005767	000216		TST	INTFLG	:START CHECKING FOR TOP	
4116	021312	001005			BNE	118	:DID WE GET TRAP	
4117	021314	005737	140000		TST	B#140000	:BR, IF WE DID (END OF MEMORY)	
4118	021320	062704	000200		ADD	#200,R4	:LOOK AT MEMORY	
4119	021324	000766			BR	158	:NEXT 4K VALUE	
4120	021326	042737	000001	177572	118:	BIC	#1,B#SR0	:LOOP UNTIL TOP OF MEMORY
4121	021334	162704	000200		SUB	#200,R4	:DISABLE MEMORY MANAGEMENT	
4122		000006			.REPT	6	:SET TO 4K PAGE THAT DIDN'T TRAP	
4124	021340	006204			ASR	R4		
	021342	006204			ASR	R4	:REDUCE TO NUMBER OF 4K PAGES	
	021344	006204			ASR	R4	:REDUCE TO NUMBER OF 4K PAGES	
	021346	006204			ASR	R4	:REDUCE TO NUMBER OF 4K PAGES	
	021350	006204			ASR	R4	:REDUCE TO NUMBER OF 4K PAGES	
	021352	006204			ASR	R4	:REDUCE TO NUMBER OF 4K PAGES	
4125	021354	010401			MOV	R4,R1	:REDUCE TO NUMBER OF 4K PAGES	
4126	021356	162701	000001		SUB	#1,R1	:GET SET TO PRINT MESSAGE	

```

4127 021362 016167 021416 000002      MOV      MEMTBL(R1),9S
4128 021370 104401                      19S:    TYPE
4129 021372 000000                      9S:    .WORD      0           :MEM SIZE
4130 021374 104401 024644              TYPE      ,MEM
4131
4132 021400 012767 000006 156376      MOV      #ERRVEC+2,ERRVEC      :RESET TMO VECTOR
4133 021406 005067 156374              CLR      ERRVEC+2
4134
4135 021412 000207                      RTS      PC
4136
4137 021414 000000                      NOCHAN: 0      : 0 = CHANNEL(S) TO TEST
4138
4139
4140
4141 021416 024327                      MEMTBL: M4K      :MSG ADDRESSES
4142 021420 024334                      M8K           : 0 - 17776
4143 021422 024341                      M12K          : 20000 - 37776
4144 021424 024347                      M16K          : 40000 - 57776
4145 021426 024355                      M20K          : 60000 - 77776
4146 021430 024363                      M24K          : 100000 - 117776
4147 021432 024371                      M28K          : 120000 - 137776
4148 021434 024377                      M32K          : 140000 - 157776
4149 021436 024405                      M36K          : 160000 - 177776
4150 021440 024413                      M40K          : 200000 - 217776
4151 021442 024421                      M44K          : 220000 - 237776
4152 021444 024427                      M48K          : 240000 - 257776
4153 021446 024435                      M52K          : 240000 - 257776
4154 021450 024443                      M56K          : 260000 - 277776
4155 021452 024451                      M60K          : 300000 - 317776
4156 021454 024457                      M64K          : 320000 - 337776
4157 021456 024465                      M68K          : 340000 - 357776
4158 021460 024473                      M72K          : 360000 - 377776
4159 021462 024501                      M76K          : 400000 - 417776
4160 021464 024507                      M80K          : 420000 - 437776
4161 021466 024515                      M84K          : 440000 - 457776
4162 021470 024523                      M88K          : 460000 - 477776
4163 021472 024531                      M92K          : 500000 - 517776
4164 021474 024537                      M96K          : 520000 - 537776
4165 021476 024545                      M100K         : 540000 - 557776
4166 021500 024554                      M104K         : 560000 - 607776
4167 021502 024563                      M108K         : 620000 - 637776
4168 021504 024572                      M112K         : 70000 - 657776
4169 021506 024601                      M116K         : 660000 - 677776
4170 021510 024610                      M120K         : 700000 - 717776
4171 021512 024617                      M124K         : 720000 - 737776
4172 021514 024626                      M128K         : 740000 - 757776
4173 021516 024635                      M132K         : 760000 - 777776
4174
4175 021520 000000                      MAXMEM: 0      :MAX MEMORY
4176
4177
4178
4179
4180                      .SBTTL INTSRV INTERRUPT SERVICE ROUTINE
4181                      :* THIS GLOBAL ROUTINE DOES NOTHING BUT INCREMENT
4182                      :* 'INTFLG' EACH TIME IT IS CALLED. IT ASSUMES
4183                      :* THAT THE MAIN CALLING ROUTINE WILL KNOW WHAT
    
```

```

4184          ;*      TO LOOK FOR.
4185
4186 021522 005267 000002  INTSRV: INC      INTFLG      ;ADD 1 TO 'INTERRUP' OCCURED' FLAG
4187 021526 000002          RTI              ;THAT'S ALL
4188
4189 021530 000000          INTFLG: 0
4190
4191
4192          .SBTTL  ROUTINE TO SET UP FOR NEXT CHANNEL ADDRESS
4193
4194          ;*****
4195          ;*      THIS ROUTINE CAUSES ADRS TO POINT TO THE
4196          ;*      ADDRESS OF CHANNEL UNDER TEST, ADRS +2 TO
4197          ;*      POINT TO THE VECTOR OF THE CHANNEL UNDER TEST.
4198          ;*****
4199
4200 021532 005767 177656  CYCLE:  TST      NOCHAN      ;ANY CHANNELS TO BE TESTED?
4201 021536 001401          BEQ      1$          ;BR IF YES
4202 021540 000207          RTS      PC          ;ELSE RETURN
4203
4204 021542 026767 157440 000612 1$:  CMP      $UNIT,$HICHAN ;DONE ALL AVAIL CHANNELS?
4205 021550 001032          BNE      3$          ;BR IF NO
4206 021552 005067 157430          CLR      $UNIT
4207 021556 016767 157472 157526  MOV     BASE0,DLADD    ;SET CHAN 0 RCSR ADDR
4208 021564 016767 157466 157532  MOV     VECTO,DLVEC    ; & VECTOR
4209 021572 032767 002000 157452  BIT     #BIT10,$DEVN   ;CHAN 0 DATA WRAP?
4210 021600 001410          BEQ      2$          ;BR IF YES
4211 021602 032767 000010 157442  BIT     #BIT3,$DEVN    ;CHAN 1 DATA WRAP?
4212 021610 001404          BEQ      2$          ;BR IF YES
4213 021612 104401 001334          TYPE    ,CARR
4214 021616 000167 003042          JMP     $EOP          ;ELSE ALL DONE
4215
4216 021622 012767 000001 000526 2$:  MOV     #TRUE,$PHASE2
4217 021630 005067 000524          CLR     PICNT
4218 021634 000207          RTS     PC
4219
4220 021636 005767 157344          3$:  TST     $UNIT          ;CHAN 0 TO BE TESTED?
4221 021642 001050          BNE     12$          ;BR IF NO
4222
4223 021644 032767 100000 157400  BIT     #BIT15,$DEVN   ;CHAN 0 TO BE TESTED?
4224 021652 001403          BEQ     4$          ;BR IF YES
4225 021654 005267 157326          INC     $UNIT
4226 021660 000724          BR     CYCLE         ;TRY OVER AGAIN FOR CHAN 1
4227
4228 021662 016767 157366 157422 4$:  MOV     BASE0,DLADD    ;SET CHAN 0 RCSR ADDR
4229 021670 016767 157362 157426  MOV     VECTO,DLVEC    ; & VECTOR
4230
4231 021676 005067 000442          CLR     WORDL        ;ELSE CLEAR TO DEFAULT & NO PARITY
4232
4233 021702 005067 000440          CLR     ODD          ;ELSE CLEAR TO DEFAULT
4234
4235 021706 032767 004000 157336  BIT     #BIT11,$DEVN   ;BREAK DETECTION ENABLED?
4236 021714 001003          BNE     8$          ;BR IF YES
4237 021716 005067 000426          CLR     BRK
4238 021722 000402          BR     +6
4239 021724 005267 000420          8$:  INC     BRK
4240

```

```

4241 021730 032767 002000 157314      BIT      #BIT10,SDEVH      ;DATA WRAP AROUND?
4242 021736 001003                    BNE      9$              ;BR IF NO
4243 021740 005067 000406              CLR      WRAP            ;ELSE CLEAR TO DEFAULT
4244 021744 000402                    BR       .+6
4245 021746 005267 000400      9$:      INC      WRAP
4246
4247 021752 005067 000376      10$:     CLR      CONSOLE
4248 021756 005267 157224      11$:     INC      SUNIT
4249 021762 000207                    RTS      PC              ;CHAN 0 IS NOT CONSOLE
4250
4251 021764 022767 000001 157214 12$:     CMP      #1,SUNIT
4252 021772 001417                    BEQ      13$            ;CHECK FOR UNIT NUMBER ONE
4253 021774 032767 020000 157250      BIT      #BIT13,SDEVH
4254 022002 001410                    BEQ      19$            ;BR, IF PRESENT UNIT = 1
4255 022004 022767 000002 157174      CMP      #2,SUNIT
4256 022012 001456                    BEQ      20$            ;CHECK FOR 2 MXV11-B TESTING
4257 022014 022767 000003 157164      CMP      #3,SUNIT
4258 022022 001511                    BEQ      30$            ;BR, IF NO 2 MXV11-B TESTING
4259 022024 005267 157156      19$:     INC      SUNIT
4260 022030 000640                    BR       CYCLE          ;CHECK FOR UNIT NUMBER 2
4261
4262 022032 032767 000400 157212 13$:     BIT      #BIT8,SDEVH
4263 022040 001771                    BEQ      19$            ;CHECK FOR UNIT NUMBER 3
4264 022042 016767 157212 157242      MOV      BASE1,DLADD
4265 022050 016767 157206 157246      MOV      VECT1,DLVEC
4266
4267 022056 005067 000262              CLR      WORDL
4268 022062 005067 000260              CLR      ODD            ;TEST CHANNEL 1?
4269
4270 022066 032767 000020 157156      BIT      #BIT4,SDEVH
4271 022074 001003                    BNE      17$            ;BR, IF NOT CHANNEL 1 TESTING
4272 022076 005067 000246              CLR      BRK
4273 022102 000402                    BR       .+6
4274 022104 005267 000240      17$:     INC      BRK
4275
4276 022110 032767 000010 157134      BIT      #BIT3,SDEVH
4277 022116 001003                    BNE      18$            ;BREAK DETECTION ENABLED?
4278 022120 005067 000226              CLR      WRAP
4279 022124 000402                    BR       .+6
4280 022126 005267 000220      18$:     INC      WRAP
4281
4282 022132 026767 157122 157004      JMP      BASE1,STKS
4283 022140 001304                    BNE      10$            ;CHAN 1 CONSOLE?
4284 022142 005267 000206              INC      CONSOLE
4285 022146 000207                    RTS      PC              ;BR IF NO
4286
4287
4288
4289 022150 016767 157110 157134 20$:     MOV      BASE2,DLADD
4290 022156 016767 157104 157140      MOV      VECT2,DLVEC
4291 022164 005067 000154              CLR      WORDL
4292 022170 005067 000152              CLR      ODD
4293 022174 032767 000020 157050      BIT      #BIT4,SDEVH
4294 022202 001003                    BNE      21$            ;SET CHAN 2 RCSR ADDR
4295 022204 005067 000140              CLR      BRK
4296 022210 000402                    BR       .+6
4297 022212 005267 000132      21$:     INC      BRK

```

\*\*\*\*\*  
 CHANNEL 2 SETUP  
 \*\*\*\*\*

```

;SET CHAN 2 RCSR ADDR
; & VECTOR
;ELSE CLEAR TO DEFAULT & NO PARITY
;ELSE CLEAR TO DEFAULT
;BREAK DETECTION ENABLED?
;BR IF YES
;ELSE CLEAR TO DEFAULT

```



```

4298 022216 032767 002000 157026      BIT      #BIT10,SDEVH      ;DATA WRAP AROUND?
4299 022224 001003                    BNE      22$           ;BR IF NO
4300 022226 005067 000120              CLR      WRAP         ;ELSE CLEAR TO DEFAULT
4301 022232 000402                    BR       .+6
4302 022234 005267 000112      22$:   INC      WRAP
4303 022240 005267 156742              INC      SUNIT       ;BUMP UNIT NUMBER
4304 022244 000207                    RTS      PC           ;HAVE VECTORS RETURN
4305
4306
4307      ;*****
4308      ;          SET UP FOR CHANNEL 3
4309      ;*****
4309 022246 016767 157016 157036      30$:   MOV      BASE3,DLADD      ;SET CHAN 3 RCSR ADDR
4310 022254 016767 157012 157042      MOV      VECT3,DLVEC      ; 8 VECTOR
4311 022262 005067 000056              CLR      WORDL        ;ELSE CLEAR TO DEFAULT & NO PARITY
4312 022266 005067 000054              CLR      ODD          ;ELSE CLEAR TO DEFAULT
4313 022272 032767 000020 156752      BIT      #BIT4,SDEVH      ;BREAK DETECTION ENABLED?
4314 022300 001003                    BNE      31$           ;BR IF YES
4315 022302 005067 000042              CLR      BRK         ;ELSE CLEAR TO DEFAULT
4316 022306 000402                    BR       .+6
4317 022310 005267 000034      31$:   INC      BRK
4318 022314 032767 002000 156730      BIT      #BIT10,SDEVH     ;DATA WRAP AROUND?
4319 022322 001003                    BNE      32$           ;BR IF NO
4320 022324 005067 000022              CLR      WRAP         ;ELSE CLEAR TO DEFAULT
4321 022330 000402                    BR       .+6
4322 022332 005267 000014      32$:   INC      WRAP
4323 022336 005267 156644              INC      SUNIT       ;BUMP UNIT NUMBER
4324 022342 000207                    RTS      PC           ;HAVE VECTORS RETURN
4325
4326
4327
4328 022344 000000      WORDL: 0      ;WORD LENGTH      0 = 8 BITS (NO PARITY), 1 = 7 BITS (
4329 022346 000000      ODD: 0        ;ODD PARITY      0 = ODD, 1 = EVEN
4330 022350 000000      BRK: 0        ;BREAK DET      0 = DISABL, 1 = ENABL
4331 022352 000000      WRAP: 0       ;DATA WRAP      0 = YES, 1 = NO
4332 022354 000000      CONSOLE: 0    ;CONSOLE        0 = CH UNDER TEST NOT CONSOLE
4333                                     ;               1 = CH UNDER TEST IS CONSOLE
4334 022356 000000      PHASE2: 0
4335 022360 000000      P1CNT: 0      ;CTR TO PRINT 'PHASE 1' ONLY ONCE
4336 022362 000000      HIGHAN: .WORD 0 ;STORE HIGHEST CHANNEL NUMBER
4337
4338
4339      ;*****
4340      ;ROUTINE TO DISPLAY CURRENT DEVH & ALLOW OPERATOR TO INPUT NEW VALUE.
4341      ;*****
4342
4343 022364 104401 024316      GTSDEV: TYPE      ,DEVH      ;SHOW CURRENT
4344 022370 016746 156656      MOV      SDEVH,-(SP)      ;;SAVE SDEVH FOR TYPEOUT
4345 022374 104402                    TYPOC      ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
4346 022376 104401 026302      TYPE      ,SPNEW        ;GET NEW
4347
4348 022402 005046      1$:   CLR      -(SP)        ;CLR CTR
4349 022404 005046              CLR      -(SP)        ;CLR NEW DEVH
4350
4351 022406 105777 156532      2$:   TSTB      @STKS      ;CHAR THERE?
4352 022412 100375              BPL      2$           ;BR IF NO
4353 022414 117746 156526      MOVB      @STKB,-(SP)    ;ELSE GET CHAR
4354 022420 042716 177600              BIC      #'C177,(SP)    ;MAKE IT 7 BIT ASCII
    
```

4354							
4355	022424	021627	000015	38:	CMP	(SP),#15	:<CR>?
4356	022430	001017			BNE	78	:BR IF NO
4357	022432	005766	000004		TST	4(SP)	:ELSE IS IT 1'ST CHAR?
4358	022436	001403			BEQ	48	:BR IF YES
4359	022440	016667	000002	156604	MOV	2(SP),SDEVN	:ELSE SAVE NEW DEVN
4360	022446	104401	001171	48:	TYPE	,SCLRF	
4361	022452	004767	175336	68:	JSR	PC,SIZE	:RE-SIZE
4362	022456	062706	000006		ADD	#6,SP	:RESET STACK
4363	022462	012716	002066		MOV	#RAMROM,(SP)	
4364	022466	000002			RTI		
4365							
4366	022470	004767	002706	78:	JSR	PC,STYPEC	:ECHO CHAR
4367	022474	021627	000060		CMP	(SP),#60	:CHAR < 0?
4368	022500	002420			BLT	98	:BR IF YES
4369	022502	021627	000067		CMP	(SP),#67	:CHAR > 7?
4370	022506	003015			BGT	98	:BR IF YES
4371	022510	042726	000060		BIC	#60,(SP)+	:STRIP OFF ASCII
4372	022514	005766	000002		TST	2(SP)	:1'ST CHAR?
4373	022520	001403			BEQ	88	:BR IF YES
4374	022522	006316			ASL	(SP)	:ELSE SHIFT PRESENT CHAR
4375	022524	006316			ASL	(SP)	:TO MAKE ROOM
4376	022526	006316			ASL	(SP)	:FOR NEW ONE
4377							
4378	022530	005266	000002	88:	INC	2(SP)	:KEEP CHAR CT
4379	022534	056616	177776		BIS	-2(SP),(SP)	:SET IN NEW CHAR
4380	022540	000722			BR	28	:GET NEW ONE
4381							
4382	022542	104401	001170	98:	TYPE	,SQUES	
4383	022546	104401	001171		TYPE	,SCLRF	
4384	022552	005726			TST	(SP)+	:RESET PTR
4385	022554	005016			CLR	(SP)	:CLR DEVN
4386	022556	000713			BR	28	:TRY AGAIN
4387							
4388	022560	104401	023511	ILLCLK:	TYPE,ILLMSG		:ILLEGAL CLOCK INTERRUPT HANDLER
4389	022564	000002			RTI		

```

4391
4392
4393
4394
4395
4396
4397
4398 022566 013567 000044
4399 022572 012567 000042
4400
4401 022576 012701 000010
4402 022602 012700 177777
4403 022606 036777 000026 000022
4404 022614 001005
4405 022616 005300
4406 022620 001372
4407 022622 005301
4408 022624 001366
4409 022626 000402
4410
4411 022630 062705 000004
4412 022634 000205
4413
4414 022636 000000
4415 022640 000000
4416
4417
4418 022642 012567 177770
4419
4420 022646 012701 000010
4421 022652 012700 177777
4422 022656 005777 177754
4423 022662 001005
4424 022664 005300
4425 022666 001373
4426 022670 005301
4427 022672 001367
4428 022674 000402
4429
4430 022676 062705 000004
4431 022702 000205
4432
4433
4434 022704 012700 177777
4435 022710 005300
4436 022712 001376
4437 022714 000207
4438
    ;*****
    ; PROGRAM TIMERS
    ;*****
TIMER:  MOV      @ (R5)+,REGHLD
        MOV      (R5)+,BITHLD
        MOV      #10,R1
        MOV      #-1,R0
        RIT      BITHLD,@REGHLD
        BNF      3$
        DEC      R0
        BNE      2$
        DEC      R1
        BNE      1$
        BR       4$
        ;DOUBLE LOOP
        ;BIT THERE?
        ;BR IF YES
        ;ALL TIMED OUT
3$:     ADD      #4,R5
4$:     RTS      R5
        ;JUMP OVER ERR ON RETURN
REGHLD: 0
BITHLD: 0
        ;REGISTER TO BE TESTED
        ;BIT TO BE TESTED IN REGISTER
TIMER1: MOV      (R5)+,REGHLD
        MOV      #10,R1
        MOV      #-1,R0
        TST      @REGHLD
        BNE      3$
        DEC      R0
        BNE      2$
        DEC      R1
        BNE      1$
        BR       4$
        ;ZERO?
        ;BR IF NO
        ;ALL TIMED OUT
3$:     ADD      #4,R5
4$:     RTS      R5
        ;JUMP OVER ERR ON RETURN
WAIT:   MOV      #-1,R0
        DEC      R0
        BNE      -2
        RTS      PC
    
```

```

4440
4445 022716          MYTYPE: TYPTXT <<CRLF>*TEST # *>
4446 022736          TYPOCT  $TESTN
4447 022744          TYPTXT  <*,ERROR # *>
4448 022764 116767 156124 156204  MOVB  $!TEMB,$FATAL          ; APT FATAL ERROR NUMBER
4449 022772          TYPOCS  $FAIAL
4450 023002          TYPTXT  <*,PC = *>
4451 023020          TYPOCT  $ERRPC
4452
4453 023026 026727 156146 000005  CMP   $TESTN,#5          ;DOING SLU TESTS?
4454 023034 100425          BMI   1$                  ;BR IF NO
4455
4456 023036          TYPTXT  <*,CSR: *>          ;ELSE PROCEED
4457 023054          TYPOCT  DLADD
4458 023062          TYPTXT  <*,VECTOR: *>
4459 023102          TYPOCT  DLVEC
4460 023110 104401 001171 1$:    TYPE  ,SCRLF
4461 023114 000207          RTS   PC
4466
4467
4468 023116          200      103      110  CODROP: .ASCIZ <CRLF>/CHAN 0 TESTING DROPPED/
      023121          101      110      040
      023124          060      040      124
      023127          105      123      124
      023132          111      116      107
      023135          040      104      122
      023140          117      120      120
      023143          105      104      000
4469 023146          200      103      110  CIDROP: .ASCIZ \CRLF>/CHAN 1 TESTING DROPPED/
      023151          101      116      040
      023154          061      040      124
      023157          105      123      124
      023162          111      116      107
      023165          040      104      122
      023170          117      120      120
      023173          105      104      000
4470 023176          200      114      105  NOLED: .ASCIZ <CRLF>/LEDS NOT USED OR TESTED/
      023201          104      123      040
      023204          116      117      124
      023207          040      125      123
      023212          105      104      040
      023215          117      122      040
      023220          124      105      123
      023223          124      105      104
      023226          000
4471
4472 023227          200      103      110  NOCH1: .ASCIZ <CRLF>/CHANNEL 1 CAN'T BE TESTED WHEN CONSOLE/
      023232          101      116      116
      023235          105      114      040
      023240          061      040      103
      023243          101      116      047
      023246          124      040      102
      023251          105      040      124
      023254          105      123      124
      023257          105      104      040
      023262          127      110      105
      023265          116      040      103
  
```

	023270	117	116	123	
	023273	117	114	105	
	023276	000			
4473	023277	200	103	114	CLKDS: .ASCIZ <CRLF>/CLOCK DISABLED/
	023302	117	103	113	
	023305	040	104	111	
	023310	123	101	102	
	023313	114	105	104	
	023316	000			
4474	023317	200	120	103	MPCR2: .ASCIZ <CRLF>/PCR REGISTER TEST SELECTED BUT NOT AVAILABLE/
	023322	122	040	122	
	023325	105	107	111	
	023330	123	124	105	
	023333	122	040	124	
	023336	105	123	124	
	023341	040	123	105	
	023344	114	105	103	
	023347	124	105	104	
	023352	040	102	125	
	023355	124	040	116	
	023360	117	124	040	
	023363	101	126	101	
	023366	111	114	101	
	023371	102	114	105	
	023374	000			
4475					
4476	023375	200	114	111	LNKMSG: .ASCIZ <CRLF>/LINE CLOCK AVAILABLE BUT NOT TESTED/
	023400	116	105	040	
	023403	103	114	117	
	023406	103	113	040	
	023411	101	126	101	
	023414	111	114	101	
	023417	102	114	105	
	023422	040	102	125	
	023425	124	040	116	
	023430	117	124	040	
	023433	124	105	123	
	023436	124	105	104	
	023441	000			
4477	023442	200	104	104	DDRMSG: .ASCIZ <CRLF>/DDR REGISTER AVAILABLE BUT NOT TESTED/
	023445	122	040	122	
	023450	105	107	111	
	023453	123	124	105	
	023456	122	040	101	
	023461	126	101	111	
	023464	114	101	102	
	023467	114	105	040	
	023472	102	125	124	
	023475	040	116	117	
	023500	124	040	124	
	023503	105	123	124	
	023506	105	104	000	
4478	023511	200	111	114	ILLMSG: .ASCIZ <CRLF>/ILLEGAL INTERRUPT THROUGH CLOCK VECTOR/
	023514	114	105	107	
	023517	101	114	040	
	023522	111	116	124	
	023525	105	122	122	

	023530	125	120	124	
	023533	040	124	110	
	023536	122	117	125	
	023541	107	110	040	
	023544	103	114	117	
	023547	103	113	040	
	023552	126	105	103	
	023555	124	117	122	
	023560	000			
4479	023561	200	120	103	PCRMMSG: .ASCIZ <CRLF>/PCR REGISTER AVAILABLE BUT NOT TESTED/
	023564	122	040	122	
	023567	105	107	111	
	023572	123	124	105	
	023575	122	040	101	
	023600	126	101	111	
	023603	114	101	102	
	023606	114	105	040	
	023611	102	125	124	
	023614	040	116	117	
	023617	124	040	124	
	023622	105	123	124	
	023625	105	104	000	
4480	023630	200	115	105	NOMMNGT: .ASCIZ <CRLF>/MEM MNGT SELECTED BUT NOT AVAILABLE/
	023633	115	040	115	
	023636	116	107	124	
	023641	040	123	105	
	023644	114	105	103	
	023647	124	105	104	
	023652	040	102	125	
	023655	124	040	116	
	023660	117	124	040	
	023663	101	126	101	
	023666	111	114	101	
	023671	102	114	105	
	023674	000			
4481	023675	200	123	105	NOSMX: .ASCIZ <CRLF>/SECOND MXV11-B SELECTED BUT NOT AVAILABLE/
	023700	103	117	116	
	023703	104	040	115	
	023706	130	126	061	
	023711	061	055	102	
	023714	040	123	105	
	023717	114	105	103	
	023722	124	105	104	
	023725	040	102	125	
	023730	124	040	116	
	023733	117	124	040	
	023736	101	126	101	
	023741	111	114	101	
	023744	102	114	105	
	023747	000			
4482	023750	200	103	114	NOCLK: .ASCIZ <CRLF>/CLOCK SELECTED BUT NOT AVAILABLE/
	023753	117	103	113	
	023756	040	123	105	
	023761	114	105	103	
	023764	124	105	104	
	023767	040	102	125	
	023772	124	040	116	

	023775	117	124	040	
	024000	101	126	101	
	024003	111	114	101	
	024006	102	114	105	
	024011	000			
4483	024012	200	104	104	NODDR: .ASCIZ <CRLF>/DDR REGISTER SELECTED BUT NOT PRESENT/
	024015	122	040	122	
	024020	105	107	111	
	024023	123	124	105	
	024026	122	040	123	
	024031	105	114	105	
	024034	103	124	105	
	024037	104	040	102	
	024042	125	124	040	
	024045	116	117	124	
	024050	040	120	122	
	024053	105	123	105	
	024056	116	124	000	
4484	024061	200	120	103	NOPCR: .ASCIZ <CRLF>/PCR REGISTER TEST BYPASSED/
	024064	122	040	122	
	024067	105	107	111	
	024072	123	124	105	
	024075	122	040	124	
	024100	105	123	124	
	024103	040	102	131	
	024106	120	101	123	
	024111	123	105	104	
	024114	000			
4485	024115	200	103	110	C1CON: .ASCIZ <CRLF>/CHAN 1 IS CONSOLE/
	024120	101	116	040	
	024123	061	040	111	
	024126	123	040	103	
	024131	117	116	123	
	024134	117	114	105	
	024137	000			
4486	024140	200	122	117	NOROM: .ASCIZ <CRLF>/ROM TEST BYPASSED/
	024143	115	040	124	
	024146	105	123	124	
	024151	040	102	131	
	024154	120	101	123	
	024157	123	105	104	
	024162	000			
4487	024163	015	012	122	NORAM: .ASCIZ <CR><LF>/RAM TEST BYPASSED/
	024166	101	115	040	
	024171	124	105	123	
	024174	124	040	102	
	024177	131	120	101	
	024202	123	123	105	
	024205	104	000		
4488	024207	200	103	114	CLKEN: .ASCIZ <CRLF>/CLOCK ENABLED/
	024212	117	103	113	
	024215	040	105	116	
	024220	101	102	114	
	024223	105	104	040	
4489	024226	015	012	123	TWIXN: .ASCIZ <CR><LF>/SECOND MXV11-B TEST BYPASSED/
	024231	105	103	117	
	024234	116	104	040	

	024237	115	130	126		
	024242	061	061	055		
	024245	102	040	124		
	024250	105	123	124		
	024253	040	102	131		
	024256	120	101	123		
	024261	123	105	104		
	024264	000				
4490	024265	015	012	124	TWOMX:	.ASCIZ <CR><LF>/TESTING SECOND MXV11-B/
	024270	105	123	124		
	024273	111	116	107		
	024276	040	123	105		
	024301	103	117	116		
	024304	104	040	115		
	024307	130	126	061		
	024312	061	055	102		
	024315	000				
4491	024316	200	104	105	DEVM:	.ASCIZ <CRLF>/DEVM = /
	024321	126	115	040		
	024324	075	040	000		
4492	024327	015	012	064	M4K:	.ASCIZ <CR><LF>/4K/
	024332	113	000			
4493	024334	015	012	070	M8K:	.ASCIZ <CR><LF>/8K/
	024337	113	000			
4494	024341	015	012	061	M12K:	.ASCIZ <CR><LF>/12K/
	024344	062	113	000		
4495	024347	015	012	061	M16K:	.ASCIZ <CR><LF>/16K/
	024352	066	113	000		
4496	024355	015	012	062	M20K:	.ASCIZ <CR><LF>/20K/
	024360	060	113	000		
4497	024363	015	012	062	M24K:	.ASCIZ <CR><LF>/24K/
	024366	064	113	000		
4498	024371	015	012	062	M28K:	.ASCIZ <CR><LF>/28K/
	024374	070	113	000		
4499	024377	015	012	063	M32K:	.ASCIZ <CR><LF>/32K/
	024402	062	113	000		
4500	024405	015	012	063	M36K:	.ASCIZ <CR><LF>/36K/
	024410	066	113	000		
4501	024413	015	012	064	M40K:	.ASCIZ <CR><LF>/40K/
	024416	060	113	000		
4502	024421	015	012	064	M44K:	.ASCIZ <CR><LF>/44K/
	024424	064	113	000		
4503	024427	015	012	064	M48K:	.ASCIZ <CR><LF>/48K/
	024432	070	113	000		
4504	024435	015	012	065	M52K:	.ASCIZ <CR><LF>/52K/
	024440	062	113	000		
4505	024443	015	012	065	M56K:	.ASCIZ <CR><LF>/56K/
	024446	066	113	000		
4506	024451	015	012	066	M60K:	.ASCIZ <CR><LF>/60K/
	024454	060	113	000		
4507	024457	015	012	066	M64K:	.ASCIZ <CR><LF>/64K/
	024462	064	113	000		
4508	024465	015	012	066	M68K:	.ASCIZ <CR><LF>/68K/
	024470	070	113	000		
4509	024473	015	012	067	M72K:	.ASCIZ <CR><LF>/72K/
	024476	062	113	000		
4510	024501	015	012	067	M76K:	.ASCIZ <CR><LF>/76K/



	024504	066	113	000		
4511	024507	015	012	070	M80K:	.ASCIZ <CR><LF>/80K/
	024512	060	113	000		
4512	024515	015	012	070	M84K:	.ASCIZ <CR><LF>/84K/
	024520	064	113	000		
4513	024523	015	012	070	M88K:	.ASCIZ <CR><LF>/88K/
	024526	070	113	000		
4514	024531	015	012	071	M92K:	.ASCIZ <CR><LF>/92K/
	024534	062	113	000		
4515	024537	015	012	071	M96K:	.ASCIZ <CR><LF>/96K/
	024542	066	113	000		
4516	024545	015	012	061	M100K:	.ASCIZ <CR><LF>/100K/
	024550	060	060	113		
	024553	000				
4517	024554	015	012	061	M104K:	.ASCIZ <CR><LF>/104K/
	024557	060	064	113		
	024562	000				
4518	024563	015	012	061	M108K:	.ASCIZ <CR><LF>/108K/
	024566	060	070	113		
	024571	000				
4519	024572	015	012	061	M112K:	.ASCIZ <CR><LF>/112K/
	024575	061	062	113		
	024600	000				
4520	024601	015	012	061	M116K:	.ASCIZ <CR><LF>/116K/
	024604	061	066	113		
	024607	000				
4521	024610	015	012	061	M120K:	.ASCIZ <CR><LF>/120K/
	024613	062	060	113		
	024616	000				
4522	024617	015	012	061	M124K:	.ASCIZ <CR><LF>/124K/
	024622	062	064	113		
	024625	000				
4523	024626	015	012	061	M128K:	.ASCIZ <CR><LF>/128K/
	024631	062	070	113		
	024634	000				
4524	024635	015	012	061	M132K:	.ASCIZ <CR><LF>/132K/
	024640	063	062	113		
	024643	000				
4525	024644	040	115	105	MEM:	.ASCIZ / MEM PRESENT/<CR><LF>
	024647	115	040	120		
	024652	122	105	123		
	024655	105	116	124		
	024660	015	012	000		
4526						.EVEN

4528

```

024664
024664 0C0004
024666 065067 154210
024672 005067 154262
024676 005267 154300
024702 042767 100000 154272
024710 005327
024712 000001
024714 003022
024716 012737
024720 000001
024722 024712
024724 104461 024771
024730 016746 154246
024734 104485
024736 104401 024766
024742 013700 000042
024746 001405
024750 000005
024752 004710
024754 0C0240
024756 000240
024760 000240
024762
024762 000137
024764 002066
024766 377 377 000
024771 015 012 105
024774 116 104 040
024777 120 101 123
025002 123 040 043
025005 000
    
```

```

.SBTTL END OF PASS ROUTINE
:*****
:*INCREMENT THE PASS NUMBER (&PASS)
:*INDICATE END-OF-PROGRAM AFTER 1 PASSES THRU THE PROGRAM
:*TYPE 'END PASS #XXXXX' (WHERE XXXXX IS A DECIMAL NUMBER)
:*IF THERES A MONITOR GO TO IT
:*IF THERE ISN'T JUMP TO RAMROM
SEOP:
      SCOPE
      CLR STSTNM          ;;ZERO THE TEST NUMBER
      CLR STIMES         ;;ZERO THE NUMBER OF ITERATIONS
      INC SPASS          ;;INCREMENT THE PASS NUMBER
      BIC #10000,SPASS   ;;DON'T ALLOW A NEG. NUMBER
      DEC (PC)+          ;;LOOP?
SEOPCT: .WORD 1
      BGT SDOAGN         ;;YES
      MOV (PC)+,@(PC)+  ;;RESTORE COUNTER
SENDCT: .WORD 1
      SEOPCT
      TYPE ,SENDMG       ;;TYPE 'END PASS #'
      MOV $PASS,-(SP)    ;;SAVE SPASS FOR TYPEOUT
      TYPDS              ;;GO TYPE--DECIMAL ASCII WITH SIGN
      TYPE ,SENULL       ;;TYPE A NULL CHARACTER
SGET42: MOV @#42,R0     ;;GET MONITOR ADDRESS
      BEQ SDOAGN         ;;BRANCH IF NO MONITOR
      RESET              ;;CLEAR THE WORLD
SENDAD: JSR PC,(R0)    ;;GO TO MONITOR
      NOP                ;;SAVE ROOM
      NOP                ;;FOR
      NOP                ;;ACT11
SDOAGN:
      JMP @ (PC)+        ;;RETURN
SRTNAD: .WORD RAMRGM
SENULL: .BYTE -1,-1,0   ;;NULL CHARACTER STRING
SENDMG: .ASCIZ <15><12>/END PASS #/
    
```

4530

```

.SBTTL POWER DOWN AND UP ROUTINES
:*****
:POWER DOWN ROUTINE
025006 012737 025152 000024 $PWRDN: MOV #SILLUP,@PWRVEC ;;SET FOR FAST UP
025014 012737 000340 000026 MOV #340,@PWRVEC+2 ;;PRIO:7
025022 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
025024 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
025026 010246 MOV R2,-(SP) ;;PUSH R2 ON STACK
025030 010346 MOV R3,-(SP) ;;PUSH R3 ON STACK
025032 010446 MOV R4,-(SP) ;;PUSH R4 ON STACK
025034 010546 MOV R5,-(SP) ;;PUSH R5 ON STACK
025036 017746 154076 MOV @SWR,-(SP) ;;PUSH @SWR ON STACK
025042 010667 000110 MOV SP,$SAVR6 ;;SAVE SP
025046 012737 025060 000024 MOV #SPWRUP,@PWRVEC ;;SET UP VECTOR
025054 000000 HALT
025056 000776 BR -2 ;;HANG UP
:*****
:POWER UP ROUTINE
025060 012737 025152 000024 $PWRUP: MOV #SILLUP,@PWRVEC ;;SET FOR FAST DOWN
025066 016706 000064 MOV $SAVR6,SP ;;GET SP
025072 005067 000060 CLR $SAVR6 ;;WAIT LOOP FOR THE TTY
025076 005267 000054 18: INC $SAVR6 ;;WAIT FOR THE INC
025102 001375 BNE 18 ;;OF WORD
025104 012677 154030 MOV (SP)+,@SWR ;;POP STACK INTO @SWR
025110 012605 MOV (SP)+,R5 ;;POP STACK INTO R5
025112 012604 MOV (SP)+,R4 ;;POP STACK INTO R4
025114 012603 MOV (SP)+,R3 ;;POP STACK INTO R3
025116 012602 MOV (SP)+,R2 ;;POP STACK INTO R2
025120 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
025122 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
025124 012737 025006 000024 MOV #SPWRDN,@PWRVEC ;;SET UP THE POWER DOWN VECTOR
025132 012737 000340 000026 MOV #340,@PWRVEC+2 ;;PRIO:7
025140 104401 TYPE ;;REPORT THE POWER FAILURE
025142 025160 $PWRMG: .WORD $POWER ;;POWER FAIL MESSAGE POINTER
025144 012716 MOV (PC)+,(SP) ;;RESTART AT START
025146 001414 $PWRAD: .WORD START ;;RESTART ADDRESS
025150 000002 RTI
025152 000000 $SILLUP: HALT ;;THE POWER UP SEQUENCE WAS STARTED
025154 000776 BR -2 ;; BEFORE THE POWER DOWN WAS COMPLETE
025156 000000 $SAVR6: 0 ;;PUT THE SP HERE
025160 015 012 120
025163 117 127 105
025166 122 000

.EVEN
    
```

4532

```

.SBTTL TYPE ROUTINE
*****
*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
*NOTE1: SFULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
*NOTE2: SFILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
*NOTE3: SFILLC CONTAINS THE CHARACTER TO FILL AFTER.
*
*CALL:
*1) USING A TRAP INSTRUCTION
*   TYPE      ,MESADR      ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
*OR
*   TYPE
*   MESADR
*
025170 105767 153763
025174 100002
025176 000000
025200 000430
025202 010046
025204 017600 000002
025210 122767 000001 153776
025216 001011
025220 132767 000100 153767
025226 001405
025230 010067 000004
025234 004767 001062
025240 000000
025242 132767 000040 153745
025250 001003
025252 112046
025254 001005
025256 005726
025260 012600
025262 062716 000002
025266 000002
025270 122716 000011
025274 001430
025276 122716 000200
025302 001006
025304 005726
025306 104401
025310 001171
025312 105067 000130
025316 000755
025320 004767 000056
025324 126726 153626
025330 001350
025332 016746 153616

025336 105366 000001
025342 002770
025344 004767 000032
025350 105367 000072
025354 000770

025356 i12716 000040

```

```

STYPE: TSTB STPLG ;;IS THERE A TERMINAL?
        BPL 18 ;;BR IF YES
        HALT ;;HALT HERE IF NO TERMINAL
        BR 38 ;;LEAVE
18: MOV RO,-(SP) ;;SAVE RO
     MOV #2(SP),RO ;;GET ADDRESS OF ASCIZ STRING
     CMPB #APTENV,SENV ;;RUNNING IN APT MODE
     BNE 62S ;;NO,GO CHECK FOR APT CONSOLE
     BITB #APTSPool,SENV ;;SPOOL MESSAGE TO APT
     BEQ 62S ;;NO,GO CHECK FOR CONSOLE
     MOV RO,61S ;;SETUP MESSAGE ADDRESS FOR APT
     JSR PC,SATY3 ;;SPOOL MESSAGE TO APT
61S: .WORD 0 ;;MESSAGE ADDRESS
62S: BITB #APTCSUP,SENV ;;APT CONSOLE SUPPRESSED
     BNE 60S ;;YES,SKIP TYPE OUT
2S: MOVB (RO)+,-(SP) ;;PUSH CHARACTER TO BE TYPED ONTO STACK
     BNE 4S ;;BR IF IT ISN'T THE TERMINATOR
     TST (SP)+ ;;IF TERMINATOR POP IT OFF THE STACK
60S: MOV (SP)+,RO ;;RESTORE RO
3S: ADD #2,(SP) ;;ADJUST RETURN PC
     RTI ;;RETURN
4S: CMPB #HT,(SP) ;;BRANCH IF <HT>
     BEQ 8S
     CMPB #CRLF,(SP) ;;BRANCH IF NOT <CRLF>
     BNE 5S
     TST (SP)+ ;;POP <CR><LF> EQUIV
     TYPE ;;TYPE A CR AND LF
     CLR B SCHARCNT ;;CLEAR CHARACTER COUNT
     BR 2S ;;GET NEXT CHARACTER
5S: JSR PC,STYPEC ;;GO TYPE THIS CHARACTER
6S: CMPB SFILLC,(SP)+ ;;IS IT TIME FOR FILLER CHARS.?
     BNE 2S ;;IF NO GO GET NEXT CHAR.
     MOV SNULL,-(SP) ;;GET # OF FILLER CHARS. NEEDED
     AND THE NULL CHAR.
7S: DECB 1(SP) ;;DCES A NULL NEED TO BE TYPED?
     BLT 6S ;;BR IF NO--GO POP THE NULL OFF OF STACK
     JSR PC,STYPEC ;;GO TYPE A NULL
     DECB SCHARCNT ;;DO NOT COUNT AS A COUNT
     BR 7S ;;LOOP
;HORIZONTAL TAB PROCESSOR
8S: MOVB #' ,(SP) ;;REPLACE TAB WITH SPACE

```

025362	004767	000014		98:	JSR	PC,\$TYPEC	::TYPE A SPACE
025366	132767	000007	000052		BITB	#7,\$CHARCNT	::BRANCH IF NOT AT
025374	001372				BNE	98	::TAB STOP
025376	005726				TST	(SP)+	::POP SPACE OFF STACK
025400	000724				BR	2*	::GET NEXT CHARACTER
025402	105777	153542		\$TYPEC:	TSTB	\$SIPS	::WAIT UNTIL PRINTER IS READY
025406	100375				BPL	\$TYPEC	
025410	116677	000002	153534		MOVB	2(SP),\$STPB	::LOAD CHAR TO BE TYPED INTO DATA REG.
025416	122766	000015	000002		CMPB	#CR,2(SP)	::IS CHARACTER A CARRIAGE RETURN?
025424	001003				BNE	18	::BRANCH IF NO
025426	105067	000014			CLRB	\$CHARCNT	::YES--CLEAR CHARACTER COUNT
025432	000406				BR	\$TYPEX	::EXIT
025434	122766	000012	000002	18:	CMPB	#LF,2(SP)	::IS CHARACTER A LINE FEED?
025442	001402				BEQ	\$TYPEX	::BRANCH IF YES
025444	105227				INCB	(PC)+	::COUNT THE CHARACTER
025446	000000			\$CHARCNT:	.WORD	C	::CHARACTER COUNT STORAGE
025450	000207			\$TYPEX:	RTS	PC	

4534

```

.SBTTL TTY INPUT ROUTINE
:*****
.ENABL LSB
:*****
*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
*WHEN OPERATING IN TTY FLAG MODE.
025452 022767 000176 153460 SCKSWR: CMP #SWREG,SWR ;;IS THE SOFT-SWR SELECTED?
025460 001114 BNE 15$ ;;BRANCH IF NO
025462 105777 153456 TSTB @STKS ;;CHAR THERE?
025466 100111 BPL 15$ ;;IF NO, DON'T WAIT AROUND
025470 117746 153452 MOVB @STKB,-(SP) ;;SAVE THE CHAR
025474 042716 177600 BIC #^C177,(SP) ;;STRIP-OFF THE ASCII
025500 022726 000007 CMP #7,(SP)+ ;;IS IT A CONTROL G?
025504 001102 BNE 15$ ;;NO, RETURN TO USER
025506 126727 153422 000001 CMPB $AUTOB,#1 ;;ARE WE RUNNING IN AUTO-MODE?
025514 001476 BEQ 15$ ;;BRANCH IF YES
025516 104401 026264 TYPE .SCNTLG ;;ECHO THE CONTROL-G (^G)
025522 104401 026271 SGTSWR: TYPE .SMSWR ;;TYPE CURRENT CONTENTS
025526 016746 152444 MOV SWREG,-(SP) ;;SAVE SWREG FOR TYPEOUT
025532 104402 TYPOC ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
025534 104401 026302 TYPE .SMNEW ;;PROMPT FOR NEW SWR
025540 005046 19$: CLR -(SP) ;;CLEAR COUNTER
025542 005046 CLR -(SP) ;;THE NEW SWR
025544 105777 153374 7$: TSTB @STKS ;;CHAR THERE?
025550 100375 BPL 7$ ;;IF NOT TRY AGAIN
025552 117746 153370 MOVB @STKB,-(SP) ;;PICK UP LCHAR
025556 042716 177600 BIC #^C177,(SP) ;;MAKE IT 7-BIT ASCII
025562 021627 000003 CMP (SP),#3 ;;IS IT A CONTROL-C?
025566 001015 BNE 9$ ;;BRANCH IF NOT
025570 104401 026252 TYPE .SCNTLC ;;YES, ECHO CONTROL-C (^C)
025574 062706 000006 ADD #6,SP ;;CLEAN UP STACK
025600 126727 153331 000001 CMPB $INTAG,#1 ;;REENABLE TTY KEYBOARD INTERRUPTS?
025606 001003 BNE 8$ ;;BRANCH IF NO
025610 012777 000100 153326 MOV #100,@STKS ;;ALLOW TTY KEYBOARD INTERRUPTS
025616 000167 174542 8$: JMP GTSDEV ;;CONTROL-C RESTART
025622 021627 000025 9$: CMP (SP),#25 ;;IS IT A CONTROL-U?
025626 001005 BNE 10$ ;;BRANCH IF NOT
025630 104401 026257 TYPE .SCNTLU ;;YES, ECHO CONTROL-U (^U)
025634 062706 000006 20$: ADD #6,SP ;;IGNORE PREVIOUS INPUT
025640 000737 BR 19$ ;;LET'S TRY IT AGAIN
025642 021627 000015 10$: CMP (SP),#15 ;;IS IT A <CR>?
025646 001022 BNE 16$ ;;BRANCH IF NO
025650 005766 000004 TST 4(SP) ;;YES, IS IT THE FIRST CHAR:
025654 001403 BEQ 11$ ;;BRANCH IF YES
025656 016677 000002 153254 MOV 2(SP),@SWR ;;SAVE NEW SWR
025664 062706 000006 11$: ADD #6,SP ;;CLEAN UP STACK
025670 104401 001171 14$: TYPE .SCRLF ;;ECHO <CR> AND <LF>
025674 126727 153235 000001 CMPB $INTAG,#1 ;;RE-ENABLE TTY KBD INTERRUPTS?
025702 001003 BNE 15$ ;;BRANCH IF NOT
025704 012777 000100 153232 MOV #100,@STKS ;;RE-ENABLE TTY KBD INTERRUPTS
025712 000002 15$: RTI ;;RETURN
025714 004767 177462 16$: JSR PC,$TYPEC ;;ECHO CHAR
025720 021627 000060 CMP (SP),#60 ;;CHAR < 0?
025724 002420 BLT 18$ ;;BRANCH IF YES
025726 021627 000067 CMP (SP),#67 ;;CHAR > 7?

```

```

025732 003015          BGT      188          ::BRANCH IF YES
025734 042726 000060  BIC      #60,(SP)+  ::STRIP-OFF ASCII
025740 005766 000002  TST      2(SP)       ::IS THIS THE FIRST CHAR
025744 001403          BEQ      178          ::BRANCH IF YES
025746 006316          ASL      (SP)        ::NO, SHIFT PRESENT
025750 006316          ASL      (SP)        ::CHAR OVER TO MAKE
025752 006316          ASL      (SP)        ::ROOM FOR NEW ONE.
025754 005266 000002  178:   INC      2(SP)       ::KEEP COUNT OF CHAR
025760 056616 177776  BIS      -2(SP),(SP) ::SET IN NEW CHAR
025764 000667          BR       78          ::GET THE NEXT ONE
025766 104401 001170  188:   TYPE     ,SQUES  ::TYPE ?<CR><LF>
025772 000720          BR       208         ::SIMULATE CONTROL-U

```

.DSABL LSB  
\*\*\*\*\*

\*THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY

\*CALL:

```

* RDCHR          ::INPUT A SINGLE CHARACTER FROM THE TTY
* RETURN HERE   ::CHARACTER IS ON THE STACK
*               ::WITH PARITY BIT STRIPPED OFF

```

```

025774 011646          SRDCHR: MOV      (SP),-(SP)  ::PUSH DOWN THE PC
025776 016666 000004 000002  MOV      4(SP),2(SP) ::SAVE THE PS
026004 105777 153134          18:   TSTB     @STKS      ::WAIT FOR
026010 100375          BPL      18          ::A CHARACTER
026012 117766 153130 000004  MOVB     @STKB,4(SP) ::READ THE TTY
026020 042766 177600 000004  BIC      #'C<177>,4(SP) ::GET RID OF JUNK IF ANY
026026 026627 000004 000023  CMP      4(SP),#23   ::IS IT A CONTROL-S?
026034 001013          BNE      38          ::BRANCH IF NG
026036 105777 153102          28:   TSTB     @STKS      ::WAIT FOR A CHARACTER
026042 100375          BPL      28          ::LOOP UNTIL ITS THERE
026044 117746 153076          MOVB     @STKB,-(SP)  ::GET CHARACTER
026050 042716 177600          BIC      #'C177,(SP) ::MAKE IT 7-BIT ASCII
026054 022627 000021          CMP      (SP)+,#21   ::IS IT A CONTROL-Q?
026060 001366          BNE      28          ::IF NOT DISCARD IT
026062 000750          BR       18          ::YES, RESUME
026064 026627 000004 000140  38:   CMP      4(SP),#140  ::IS IT UPPER CASE?
026072 002407          BLT      48          ::BRANCH IF YES
026074 026627 000004 000175  CMP      4(SP),#175  ::IS IT A SPECIAL CHAR?
026102 003003          BGT      48          ::BRANCH IF YES
026104 042766 000040 000004  BIC      #40,4(SP)   ::MAKE IT UPPER CASE
026112 000002          48:   RTI          ::GO BACK TO USER

```

\*\*\*\*\*  
\*THIS ROUTINE WILL INPUT A STRING FROM THE TTY

\*CALL:

```

* RDLIN          ::INPUT A STRING FROM THE TTY
* RETURN HERE   ::ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
*               ::TERMINATOR WILL BE A BYTE OF ALL 0'S

```

```

026114 010346          SRDLIN: MOV      R3,-(SP)  ::SAVE R3
026116 012703 026242          18:   MOV      @STYIN,R3  ::GET ADDRESS
026122 022703 026252          28:   CMP      @STYIN+8.,R3 ::BUFFER FULL?
026126 101415          BLOS     48          ::BR IF YES
026130 104410          RDCHR   ::GO READ ONE CHARACTER FROM THE TTY
026132 112613          MOVB     (SP)+,(R3)  ::GET CHARACTER
026134 122713 000003          CMPB     #3,(R3)    ::IS IT A CONTROL-C?
026140 001005          BNE      108         ::BRANCH IF NO
026142 104401 026252          TYPE     ,SCNTLC    ::TYPE A CONTROL-C (^C)
026146 012603          MOV      (SP)+,R3   ::RESTORE R3

```

```

026150 000167 174210          JMP      GTSDEV      ;;GOTO CONTROL-C RESTART
026154 122713 000177          10S:    CMPB      #177,(R3)  ;;IS IT A RUBOUT
026160 001003                PNE      3S          ;;SKIP IF NOT
026162 104401 001170          4S:     TYPE     ,8QUES  ;;TYPE A '?'
026166 000753                BR       1S          ;;CLEAR THE BUFFER AND LOOP
026170 111367 000044          3S:     MOVB     (R3),9S  ;;ECHO THE CHARACTER
026174 104401 026240          TYPE     ,9S
026200 122723 000015          CMPB     #15,(R3)+  ;;CHECK FOR RETURN
026204 001346                BNE     2S          ;;LOOP IF NOT RETURN
026206 105063 177777          CLRB    -1(R3)     ;;CLEAR RETURN (THE 15)
026212 104401 001172          TYPE     ,SLF      ;;TYPE A LINE FEED
026216 012603                MOV     (SP)+,R3    ;;RESTORE R3
026220 011646                MOV     (SP),-(SP)  ;;ADJUST THE STACK AND PUT ADDRESS OF THE
026222 016666 000004 000002          MOV     4(SP),2(SP) ;;FIRST ASCII CHARACTER ON IT
026230 012766 026242 00U004          MOV     #STTYIN,4(SP)
026236 000000?                RTI
026240 000                9S:     .BYTE    0      ;;RETURN
026241 000                .BYTE    0      ;;STORAGE FOR ASCII CHAR. TO TYPE
026242                .BLKB   8.  ;;TERMINATOR
026252 136 103 015 $TTYIN: .BLKB 8.  ;;RESERVE 8 BYTES FOR TTY INPUT
026255 012 000 $CNTLC: .ASCIZ /^C/<15><12>  ;;CONTROL "C"
026257 136 125 015 $CNTLU: .ASCIZ /^U/<15><12>  ;;CONTROL "U"
026262 012 000 $CNTLG: .ASCIZ /^G/<15><12>  ;;CONTROL "G"
026264 136 107 015 $MSWR: .ASCIZ <15><12>/SWR = /
026267 012 000 $MNEW: .ASCIZ / NEW = /
026271 015 012 123
026274 127 122 040
026277 075 040 000
026302 040 040 116
026305 105 127 040
026310 075 040 000

.EVEN

```



4536

.SBTTL APT COMMUNICATIONS ROUTINE

```

*****
026314 112767 000001 000236 SATY1: MOVB #1,$FFLG ;;TO REPORT FATAL ERROR
026322 112767 000001 000226 SATY3: MOVB #1,$MFLG ;;TO TYPE A MESSAGE
026330 000403 BR SATYC
026332 112767 000001 000220 SATY4: MOVB #1,$FFLG ;;TO ONLY REPORT FATAL ERROR
026340 SATYC:
026340 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
026342 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
026344 105767 000206 TSTB $MFLG ;;SHOULD TYPE A MESSAGE?
026350 001450 BEQ 5$ ;;IF NOT: BR
026352 122767 000001 152634 CMPB #APTENV,$ENV ;;OPERATING UNDER APT?
026360 001031 BNE 3$ ;;IF NOT: BR
026362 132767 000100 152625 BITB #APTSPOOL,$ENVM ;;SHOULD SPOOL MESSAGES?
026370 001425 BEQ 3$ ;;IF NOT: BR
026372 017600 000004 MOV @4(SP),R0 ;;GET MESSAGE ADDR.
026376 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
026404 005767 152564 1$: TST $MSGTYPE ;;SEE IF DONE W/ LAST XMISSION?
026410 001375 BNE 1$ ;;IF NOT: WAIT
026412 010067 152572 MOV R0,$MSGAD ;;PUT ADDR IN MAILBOX
026416 105720 2$: TSTB (R0)+ ;;FIND END OF MESSAGE
026420 001376 BNE 2$
026422 166700 152562 SUB $MSGAD,R0 ;;SUB START OF MESSAGE
026426 006200 ASR R0 ;;GET MESSAGE LNTH IN WORDS
026430 010067 152556 MOV R0,$MSGLEN ;;PUT LENGTH IN MAILBOX
026434 012767 000004 152532 MOV #4,$MSGTYPE ;;TELL APT TO TAKE MSG.
026442 000413 BR 5$
026444 017667 000004 000016 3$: MOV @4(SP),4$ ;;PUT MSG ADDR IN JSR LINKAGE
026452 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDRESS
026460 016746 151312 MOV 177776,-(SP) ;;PUSH 177776 ON STACK
026464 004767 176500 JSR PC,$TYPE ;;CALL TYPE MACRO
026470 000000 4$: .WORD 0
026472 5$:
026472 105767 000062 10$: TSTB $FFLG ;;SHOULD REPORT FATAL ERROR?
026476 001416 BEQ 12$ ;;IF NOT: BR
026500 005767 152510 TST $ENV ;;RUNNING UNDER APT?
026504 001413 BEQ 12$ ;;IF NOT: BR
026506 005767 152462 11$: TST $MSGTYPE ;;FINISHED LAST MESSAGE?
026512 001375 BNE 11$ ;;IF NOT: WAIT
026514 017667 000004 152454 MOV @4(SP),$FATAL ;;GET ERROR #
026522 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
026530 005267 152440 INC $MSGTYPE ;;TELL APT TO TAKE ERROR
026534 105067 000020 12$: CLRB $FFLG ;;CLEAR FATAL FLAG
026540 105067 000013 CLRB $LFLG ;;CLEAR LOG FLAG
026544 105067 000006 CLRB $MFLG ;;CLEAR MESSAGE FLAG
026550 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
026552 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
026554 000207 RTS PC ;;RETURN
026556 000 $MFLG: .BYTE 0 ;;MESSG. FLAG
026557 000 $LFLG: .BYTE 0 ;;LOG FLAG
026560 000 $FFLG: .BYTE 0 ;;FATAL FLAG
.EVEN
000200 APTSIZE=200
000001 APTENV=001
000100 APTSPOOL=100
000040 APTCSUP=040
  
```

4538

```

.SBTTL ERROR HANDLER ROUTINE
:*****:
:*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
:*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
:*AND GO TO MYTYPE ON ERROR
:*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
:*SW15=1      HALT ON ERROR
:*SW13=1      INHIBIT ERROR TYPEOUTS
:*SW10=1      BELL ON ERROR
:*SW09=1      LOOP ON ERROR
:*CALL
:*
ERROR      N      ;;ERROR=EMT AND N=ERROR ITEM NUMBER
$ERROR:
026562      026562      104407
026562      104407      152313      7$:      CKSWR      ;;TEST FOR CHANGE IN SOFT-SWR
026564      105267      152313      INCB      SERFLG      ;;SET THE ERROR FLAG
026570      001775      BEQ      7$      ;;DON'T LET THE FLAG GO TO ZERO
026572      016777      152304      152342      MOV      $STNM,@DISPLAY      ;;DISPLAY TEST NUMBER AND ERROR FLAG
026600      032777      002000      152332      BIT      #BIT10,@SWR      ;;BELL ON ERROR?
026606      001402      BEQ      1$      ;;NO - SKIP
026610      104401      001164      TYPE      ,SBELL      ;;RING BELL
026614      005267      152272      1$:      INC      $ERTTL      ;;COUNT THE NUMBER OF ERRORS
026620      011667      152272      MOV      (SP),$ERRPC      ;;GET ADDRESS OF ERROR INSTRUCTION
026624      162767      000002      152264      SUB      #2,$ERRPC
026632      117767      152260      152254      MOVB     @$ERRPC,$ITEMB      ;;STRIP AND SAVE THE ERROR ITEM CODE
026640      032777      020000      152272      BIT      #BIT13,@SWR      ;;SKIP TYPEOUT IF SET
026646      001004      BNE      20$      ;;SKIP TYPEOUTS
026650      004767      174042      JSR      PC,MYTYPE      ;;GO TO USER ERROR ROUTINE
026654      104401      001171      TYPE      ,$CRLF
026660      026660      122767      000001      152326      20$:      CMPB     #APTENV,$ENV      ;;RUNNING IN APT MODE
026666      001007      BNE      2$      ;;NO,SKIP APT ERROR REPORT
026670      116767      152220      000004      MOVB     $ITEMB,21$      ;;SET ITEM NUMBER AS ERROR NUMBER
026676      004767      177430      JSR      PC,$ATY4      ;;REPORT FATAL ERROR TO APT
026702      000      21$:      .BYTE   0
026703      000      .BYTE   0
026704      000777      22$:      BR      22$      ;;APT ERROR LOOP
026706      005777      152226      2$:      TST     @SWR      ;;HALT ON ERROR
026712      100002      BPL      3$      ;;SKIP IF CONTINUE
026714      000000      HALT     ;;HALT ON ERROR!
026716      104407      CKSWR
026720      032777      001000      152212      3$:      BIT     #BIT09,@SWR      ;;TEST FOR CHANGE IN SOFT-SWR
026726      001402      BEQ      4$      ;;LJJP ON ERROR SWITCH SET?
026730      016716      152154      MOV     $LPERR,(SP)      ;;BR IF NO
026734      005767      152222      4$:      TST     $ESCAPE      ;;FUDGE RETURN FOR LOOPING
026740      001402      BEQ      5$      ;;CHECK FOR AN ESCAPE ADDRESS
026742      016716      152214      MOV     $ESCAPE,(SP)      ;;BR IF NONE
026746      026746      022737      024752      000042      5$:      CMP     #SENDAD,@#42      ;;FUDGE RETURN ADDRESS FOR ESCAPE
026754      001001      BNE      6$      ;;ACT-11 AUTO-ACCEPT?
026756      000000      HALT     ;;BRANCH IF NO
026760      000002      6$:      RTI      ;;YES
026760      000002      RTI      ;;RETURN

```

4540

```

.SBTTL SCOPE HANDLER ROUTINE
:*****
:THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
:AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
:AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
:THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
:*SW14=1      LOOP ON TEST
:*SW11=1      INHIBIT ITERATIONS
:*SW09=1      LOOP ON ERROR
:*SW08=1      LOOP ON TEST IN SWR<7:0>
:*CALL
:SCOPE          ;;SCOPE=10T
$SCOPE:
026762          CKSWR
026762 104407   040000 152146 1$: BIT #BIT14,@SWR      ;;TEST FOR CHANGE IN SCF--SWR
026764 032777   040000 152146 BNE $OVER          ;;LOOP ON PRESENT TEST?
026772 001114   040000 152146      ;;YES IF SW14=1
:*****START OF CODE FOR THE XOR TESTER*****
026774 000416   040000 152146 $XTSTR: BR 6$      ;;IF RUNNING ON THE 'XOR' TESTER CHANGE
:THIS INSTRUCTION TO A 'NOP' (NOP=240)
026776 013746   000004 000004      MOV @ERRVEC,-(SP)    ;;SAVE THE CONTENTS OF THE ERROR VECTOR
027002 012737   027022 000004      MOV #5,@ERRVEC     ;;SET FOR TIMEOUT
027010 005737   177060 000004      TST @#177060      ;;TIME OUT ON XOR?
027014 012637   000004 000004      MOV (SP)+,@ERRVEC  ;;RESTORE THE ERROR VECTOR
027020 000463   000004 000004      BR $SVLAD         ;;GO TO THE NEXT TEST
027022 022626   000004 000004      5$: CMP (SP)+,(SP)+  ;;CLEAR THE STACK AFTER A TIME OUT
027024 012637   000004 000004      MOV (SP)+,@ERRVEC  ;;RESTORE THE ERROR VECTOR
027030 000423   000004 000004      BR 7$            ;;LOOP ON THE PRESENT TEST
027032 032777   000400 152100 6$: *****END OF CODE FOR THE XOR TESTER*****
027032 032777   000400 152100      BIT #BIT08,@SWR    ;;LOOP ON SPEC. TEST?
027040 001404   152072 152032      BEQ 2$            ;;BR IF NO
027042 127767   152072 152032      CMPB @SWR,$TSTNM  ;;ON THE RIGHT TEST? SWR<7:0>
027050 001465   152025 152025      BEQ $OVER         ;;BR IF YES
027052 105767   152025 152025      2$: TSTB $ERFLG    ;;HAS AN ERROR OCCURRED?
027056 001421   152031 152015      BEQ 3$            ;;BR IF NO
027060 126767   001000 152042      CMPB $ERMAX,$ERFLG ;;MAX. ERRORS FOR THIS TEST OCCURRED?
027066 101015   001000 152042      BHI 3$            ;;BR IF NO
027070 032777   001000 152042      BIT #BIT09,@SWR   ;;LOOP ON ERROR?
027076 001404   152004 152000      BEQ 4$            ;;BR IF NO
027100 016767   000446 151767      7$: MOV $LPERR,$LPADR ;;SET LOOP ADDRESS TO LAST SCOPE
027106 000446   152040 151767      BR $OVER
027110 105067   152040 151767      4$: CLRB $ERFLG     ;;ZERO THE ERROR FLAG
027114 005067   152040 151767      CLR $TIMES        ;;CLEAR THE NUMBER OF ITERATIONS TO MAKE
027120 000415   004000 152010      BR 1$            ;;ESCAPE TO THE NEXT TEST
027122 032777   004000 152010      3$: BIT #BIT11,@SWR  ;;INHIBIT ITERATIONS?
027130 001011   152044 151740      BNE 1$            ;;BR IF YES
027132 005767   151740 151732      TST $PASS         ;;IF FIRST PASS OF PROGRAM
027136 001406   151740 151732      BEQ 1$            ;;INHIBIT ITERATIONS
027140 005267   151740 151732      INC $ICNT         ;;INCREMENT ITERATION COUNT
027144 026767   151700 151732      CMP $TIMES,$ICNT  ;;CHECK THE NUMBER OF ITERATIONS MADE
027152 002024   151700 151732      RGE $OVER         ;;BR IF MORE ITERATION REQUIRED
027154 012767   000001 151722      1$: MOV #1,$ICNT    ;;REINITIALIZE THE ITERATION COUNTER
027162 016767   000052 151770      MOV $MXCNT,$TIMES ;;SET NUMBER OF ITERATIONS TO DO
027170 105267   151706 151776      $SVLAD: INCB $TSTNM ;;COUNT TEST NUMBERS
027174 116767   151702 151776      MOVB $TSTNM,$TESTNM ;;SET TEST NUMBER IN APT MAILBOX
027202 011667   151700 151776      MOV (SP),$LPADR   ;;SAVE SCOPE LOOP ADDRESS
027206 011667   151676 151776      MOV (SP),$LPERR   ;;SAVE ERROR LOOP ADDRESS
027212 005067   151744 151776      CLR $ESCAPE       ;;CLEAR THE ESCAPE FROM ERROR ADDRESS

```

CVNXPAD MXV11B DIAG  
SCOPE HANDLER ROUTINE

MACRO M1113 28-FEB-83 16:15 PAGE 51-1

SEQ 0131

027216	112767	000001	151671	MOV	#1, SERMAX	:: ONLY ALLOW ONE(1) ERROR ON NEXT TEST
027224	016777	151652	151710	SOVER: MOV	STSTNM, @DISPLAY	:: DISPLAY TEST NUMBER
027232	016716	151450		MOV	SLPADR, (SP)	:: FUDGE RETURN ADDRESS
027236	003602			RTI		:: FIXES PS
027240	003720			SMXCNT: 2000.		:: MAX. NUMBER OF ITERATIONS

4542

```

.SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
:*****
:*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
:*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
:*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
:*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
:*REPLACED WITH SPACES.
:*CALL:
:*
MOV     NUM,-(SP)      ;;PUT THE BINARY NUMBER ON THE STACK
TYPDS   TYPDS         ;;GO TO THE ROUTINE
STYPDS:
MOV     R0,-(SP)      ;;PUSH R0 ON STACK
MOV     R1,-(SP)      ;;PUSH R1 ON STACK
MOV     R2,-(SP)      ;;PUSH R2 ON STACK
MOV     R3,-(SP)      ;;PUSH R3 ON STACK
MOV     R5,-(SP)      ;;PUSH R5 ON STACK
MOV     #20200,-(SP)  ;;SET BLANK SWITCH AND SIGN
MOV     20(SP),R5     ;;GET THE INPUT NUMBER
BPL     1$           ;;BR IF INPUT IS POS.
NEG     R5           ;;MAKE THE BINARY NUMBER POS.
MOVB   #'-,1(SP)    ;;MAKE THE ASCII NUMBER NEG.
1$:    CLR     R0     ;;ZERO THE CONSTANTS INDEX
MOV     #SDBLK,R3   ;;SETUP THE OUTPUT POINTER
MOVB   #' ,(R3)+    ;;SET THE FIRST CHARACTER TO A BLANK
2$:    CLR     R2     ;;CLEAR THE BCD NUMBER
MOV     $DTBL(R0),R1 ;;GET THE CONSTANT
3$:    SUB     R1,R5  ;;FORM THIS BCD DIGIT
BLT    4$           ;;BR IF DONE
INC    R2           ;;INCREASE THE BCD DIGIT BY 1
BR     3$
4$:    ADD     R1,R5  ;;ADD BACK THE CONSTANT
TST    R2           ;;CHECK IF BCD DIGIT=0
BNE    5$           ;;FALL THROUGH IF 0
TSTB   (SP)        ;;STILL DOING LEADING 0'S?
BMI    7$           ;;BR IF YES
5$:    ASLB   (SP)   ;;MSD?
BCC    6$           ;;BR IF NO
MOVB   1(SP),-1(R3) ;;YES--SET THE SIGN
6$:    BIS    #'0,R2 ;;MAKE THE BCD DIGIT ASCII
7$:    BIS    #' ,R2 ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
MOVB   R2,(R3)+    ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
TST    (R0)+       ;;JUST INCREMENTING
CMP    R0,#10     ;;CHECK THE TABLE INDEX
BLT    2$         ;;GO DO THE NEXT DIGIT
BGT    8$         ;;GO TO EXIT
MOV    R5,R2      ;;GET THE LSD
BR     6$         ;;GO CHANGE TO ASCII
8$:    TSTB   (SP)+  ;;WAS THE LSD THE FIRST NON-ZERO?
BPL    9$         ;;BR IF NO
MOVB   -1(SP),-2(R3) ;;YES--SET THE SIGN FOR TYPING
9$:    CLRB   (R3)  ;;SET THE TERMINATOR
MOV    (SP)+,R5   ;;POP STACK INTO R5
MOV    (SP)+,R3   ;;POP STACK INTO R3
MOV    (SP)+,R2   ;;POP STACK INTO R2
MOV    (SP)+,R1   ;;POP STACK INTO R1
MOV    (SP)+,R0   ;;POP STACK INTO R0
TYPE   ,SDBLK    ;;NOW TYPE THE NUMBER
    
```

027434	016666	000002	000004	MOV	2(SP),4(SP)	::ADJUST THE STACK
027442	012616			MOV	(SP)+,(SP)	
027444	000002			RTI		::RETURN TO USER
027446	023420	\$DTBL:		10000.		
027450	001750			1000.		
027452	000144			100.		
027454	000012			10.		
027456		\$DBLK:		.BLKW	4	

4544

```

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE
*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
*OCTAL (ASCII) NUMBER AND TYPE IT.
*STYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*   MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOS   ;;CALL FOR TYPEOUT
*   .BYTE  N              ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*   .BYTE  M              ;;M=1 OR 0
*                               ;;1=TYPE LEADING ZEROS
*                               ;;0=SUPPRESS LEADING ZEROS
*STYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*STYPOS OR STYPOC
*CALL:
*   MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPON   ;;CALL FOR TYPEOUT
*STYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
*CALL:
*   MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOC   ;;CALL FOR TYPEOUT
027466 017646 000000 000211 STYPOS: MOV     0(SP),-(SP)      ;;PICKUP THE MODE
027472 116667 000001 000211 MOV     1(SP),SOFILL    ;;LOAD ZERO FILL SWITCH
027500 112667 000207 000211 MOV     (SP)+,SOMODE+1 ;;NUMBER OF DIGITS TO TYPE
027504 062716 000092 000211 ADD     #2,(SP)        ;;ADJUST RETURN ADDRESS
027510 000406 000000 000211 BR      STYPON
027512 112767 000001 000171 STYFOC: MOV     #1,SOFILL    ;;SET THE ZERO FILL SWITCH
027520 112767 000006 000165 MOV     #6,SOMODE+1    ;;SET FOR SIX(6) DIGITS
027526 112767 000005 000154 STYPON: MOV     #5,SOCNT    ;;SET THE ITERATION COUNT
027534 010346 000000 000154 MOV     R3,-(SP)       ;;SAVE R3
027536 010446 000000 000154 MOV     R4,-(SP)       ;;SAVE R4
027540 010546 000000 000154 MOV     R5,-(SP)       ;;SAVE R5
027542 116704 000145 000154 MOV     SOMODE+1,R4    ;;GET THE NUMBER OF DIGITS TO TYPE
027546 005404 000000 000154 NEG     R4
027550 062704 000006 000154 ADD     #6,R4          ;;SUBTRACT IT FOR MAX. ALLOWED
027554 110467 000132 000154 MOV     R4,SOMODE      ;;SAVE IT FOR USE
027560 116704 000125 000154 MOV     SOFILL,R4      ;;GET THE ZERO FILL SWITCH
027564 016605 000012 000154 MOV     12(SP),R5      ;;PICKUP THE INPUT NUMBER
027570 005003 000000 000154 CLR     R3             ;;CLEAR THE OUTPUT WORD
027572 006105 000000 000154 1$:   ROL     R5          ;;ROTATE MSB INTO "C"
027574 000404 000000 000154 BR      3$            ;;GO DO MSB
027576 006105 000000 000154 2$:   ROL     R5          ;;FORM THIS DIGIT
027600 006105 000000 000154 ROL     R5
027602 006105 000000 000154 ROL     R5
027604 010503 000000 000154 MOV     R5,R3
027606 006103 000000 000154 3$:   ROL     R3          ;;GET LSB OF THIS DIGIT
027610 105367 000076 000154 DECB   SOMODE          ;;TYPE THIS DIGIT?
027614 100016 000000 000154 BPL    7$             ;;BR IF NO
027616 042703 177770 000154 BIC    #177770,R3     ;;GET RID OF JUNK
027622 001002 000000 000154 BNE    4$            ;;TEST FOR 0
027624 005704 000000 000154 TST    R4             ;;SUPPRESS THIS 0?
027626 001403 000000 000154 BEQ    5$            ;;BR IF YES
027630 005204 000000 000154 4$:   INC     R4          ;;DON'T SUPPRESS ANYMORE 0'S
027632 052703 000060 000154 BIS    #'0,R3        ;;MAKE THIS DIGIT ASCII
027636 052703 000040 000154 5$:   BIS    #' ,R3      ;;MAKE ASCII IF NOT ALREADY
    
```

027642	110367	000040		MOVB	R3,88	::SAVE FOR TYPING
027646	104401	027706		TYPE	.88	::GO TYPE THIS DIGIT
027652	105367	000032	78:	DECB	%OCNT	::COUNT BY 1
027656	003347			BGT	28	::BR IF MORE TO DO
027660	002402			BLT	68	::BR IF DONE
027662	005204			INC	R4	::INSURE LAST DIGIT ISN'T A BLANK
027664	000744			BR	28	::GO DO THE LAST DIGIT
027666	012605		68:	MOV	(SP)+,R5	::RESTORE R5
027670	012604			MOV	(SP)+,R4	::RESTORE R4
027672	012603			MOV	(SP)+,R3	::RESTORE R3
027674	016666	000002 000004		MOV	2(SP),4(SP)	::SET THE STACK FOR RETURNING
027702	012616			MOV	(SP)+,(SP)	
027704	000002			RTI		::RETURN
027706	000		88:	.BYTE	0	::STORAGE FOR ASCII DIGIT
027707	000			.BYTE	0	::TERMINATOR FOR TYPE ROUTINE
027710	000		%OCNT:	.BYTE	0	::OCTAL DIGIT COUNTER
027711	000		%ZILL:	.BYTE	0	::ZERO FILL SWITCH
027712	000000		%MODE:	.WORD	0	::NUMBER OF DIGITS TO TYPE



4546

027714 010046  
027716 016600 000002  
027722 005740  
027724 111000  
027726 006300  
027730 016000 027750  
027734 006200  
  
027736 011646  
027740 016666 000004 000C02  
027746 000002

```
.SBTTL TRAP DECODER
:*****
:THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
:AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
:OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
:GO TO THAT ROUTINE.
STRAP:  MOV    RO,-(SP)      ;;SAVE RO
        MOV    2(SP),RO    ;;GET TRAP ADDRESS
        TST    -(RO)      ;;BACKUP BY 2
        MOVB   (RO),RO    ;;GET RIGHT BYTE OF TRAP
        ASL    RO         ;;POSITION FOR INDEXING
        MOV    STRPAD(RO),RO ;;INDEX TO TABLE
        RTS    RO         ;;GO TO ROUTINE
;;THIS IS USE TO HANDLE THE "GETPRI" MACRO
STRAP2: MOV    (SP),-(SP)  ;;MOVE THE PC DOWN
        MOV    4(SP),2(SP) ;;MOVE THE PSW DOWN
        RTI                    ;;RESTORE THE PSW
```

```
.SBTTL TRAP TABLE
:THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
:BY THE "TRAP" INSTRUCTION.
:ROUTINE
:-----
```

027750 027736  
027752 025170  
027754 027512  
027756 027466  
027760 027526  
027762 027242  
027764 025522  
027766 025452  
027770 025774  
027772 026114  
4547 027774 022364

```
STRPAD: .WORD  STRAP2
        STYPE  ;;CALL=TYPE      TRAP+1(104401)  TTY TYPEOUT ROUTINE
        STYPOC ;;CALL=TYPOC    TRAP+2(104402)  TYPE OCTAL NUMBER (WITH LEADING ZEROS)
        STYPOS ;;CALL=TYPOS    TRAP+3(104403)  TYPE OCTAL NUMBER (NO LEADING ZEROS)
        STYPON ;;CALL=TYPON    TRAP+4(104404)  TYPE OCTAL NUMBER (AS PER LAST CALL)
        STYPDS ;;CALL=TYPDS    TRAP+5(104405)  TYPE DECIMAL NUMBER (WITH SIGN)
        SGTSWR ;;CALL=GTSWR    TRAP+6(104406)  GET SOFT-SWR SETTING
        SCKSWR ;;CALL=CKSWR    TRAP+7(104407)  TEST FOR CHANGE IN SOFT-SWR
        SRDCHR ;;CALL=RDCHR    TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
        SRDLIN ;;CALL=RDLIN    TRAP+11(104411) TTY TYPEIN STRING ROUTINE
        GTSDEV ;;CALL=GTDEV    TRAP+12(104412) ^C WILL OPEN UP DEV MAP
```

4548  
4549  
4550  
4551  
4552

000001

.END

:MAX ADDR FOR 4K ALLOWED FOR APT = 17400  
:MAX ADDR FOR 4K FOR ABS LOADER ONLY = 17500

ABASE = 000000	BITHLD 022640	C1DROP 023146	M104K 024554	PCRREG 001310
ACDW1 = 000000	BIT0 = 000001	C1END 014712	M108K 024563	PDR0 = 172300
ACDW2 = 000000	BIT00 = 000001	C1XMIT 014710	M112K 024572	PDR1 = 172302
ACPUOP= 000000	BIT01 = 000002	C2END 020006	M116K 024601	PDR2 = 172304
ADDR 00332!	BIT02 = 000004	C2XMIT 020004	M12K 024341	PDR3 = 172306
ADDW0 = 0000'0	BIT03 = 000010	C3END 020012	M120K 024610	PDR4 = 172310
ADDW1 = 000000	BIT04 = 000020	C3XMIT 020010	M124K 024617	PDR5 = 172312
ADDW10= 000000	BIT05 = 000040	DATA 010016	M128K 024626	PDR6 = 172314
ADDW11= 000000	BIT06 = 000100	DDISP = 177570	M132K 024635	PDR7 = 172316
ADDW12= 000000	BIT07 = 000200	DDRMSG 023442	M16K 024347	PERR = 010000
ADDW13= 000000	BIT08 = 000400	DEVN 024316	M20K 024355	PHASE2 022356
ADDW14= 000000	BIT09 = 001000	DISPLA 001142	M24K 024363	PIRQ = 177772
ADDW15= 000000	BIT1 = 000002	DISPRE 000174	M28K 024371	PIRQVE= 000240
ADDW2 = 000000	BIT10 = 002000	DLADD 001312	M32K 024377	PRO = 000000
ADDW3 = 000000	BIT11 = 004000	DLVEC 001324	M36K 024405	PR1 = 000040
ADDW4 = 000000	BIT12 = 010000	DONE = 000200	M4K 024327	PR2 = 000100
ADDW5 = 000000	BIT13 = 020000	DSWR = 177570	M40K 024413	PR3 = 000140
ADDW6 = 000000	BIT14 = 040000	EMTVEC= 000030	M44K 024421	PR4 = 090200
ADDW7 = 000000	BIT15 = 100000	ERRCHK 010576	M48K 024427	PR5 = 000240
ADDW8 = 000000	BIT2 = 000004	ERRCNT 007740	M52K 024435	PR6 = 000300
ADDW9 = 000000	BIT3 = 000010	ERRFLG 005524	M56K 024443	PP7 = 000340
ADEVCT= 000000	BIT4 = 000020	ERROR = 104000	M60K 024451	PS = 177776
ADEVN = 000000	BIT5 = 000040	ERRVEC= 000004	M64K 024457	PSW = 177776
AENV = 000000	BIT6 = 000100	ERR15 = 100000	M68K 024465	PURVEC= 000024
AENVN = 000000	BIT7 = 000200	EXFLG 005526	M72K 024473	P1CNT 022360
AFATAL= 000000	BIT8 = 000400	EX1 007736	M76K 024501	RAMROM 002066
AMADR1= 000000	BIT9 = 001000	EX2 010576	M8K 024334	RBUF 001316
AMADR2= 000000	BKGN0 003002	FRERR = 020000	M80K 024507	RCSR 001314
AMADR3= 000000	BPTVEC= 000014	GTDEVN= 104412	M84K 024515	RDCHR = 104410
AMADR4= 000000	BREAK = 000001	GTSWR = 104406	M88K 024523	RDLIN = 104411
AMAMS1= 000000	BRK 022350	GTSDEV 022364	M92K 024531	RDWRD 003004
AMAMS2= 000000	CARR 001334	HICHAN 022362	M96K 024537	RDY = 000200
AMAMS3= 000000	CHOR 012450	HIROM 001276	NOCHAN 021414	REC 010020
AMAMS4= 000000	CHOTAB 013704	HIRCM2 001302	NOCH1 023227	REGHLD 022636
AMSGAD= 000000	CHOX 012464	HT = 000011	NOCLK 023750	RESVEC= 000010
AMSGLG= 000000	CH1R 012506	IE = 000100	NODJR 024012	RHLD 010124
AMSGTY= 000000	CH1TAB 014304	ILLCLK 022560	NOLED 023176	ROSRV 013474
ANTYP1= 000000	CH1X 012524	ILLMSG 023511	NOPMNG 023630	R1SRV 013600
ANTYP2= 000000	CH2R 015540	INTABL 012546	NOPCR 024061	R2SRV 016574
ANTYP3= 000000	CH2TAB 017004	INTABM 015646	NOPCR2 023317	R3SRV 016700
ANTYP4= 000000	CH2X 015560	INTFLG 021530	NORAM 024163	R6 = 8000006
APASS = 000000	CH3R 015602	INTSPV 021522	NOROM 024140	R7 = 8000007
APRIOR= 000000	CH3TAB 017404	IOTVEC= 000020	NOSMX 023675	SAVBK 003006
APTCSU= 000040	CH3X 015624	LEDHLD 001332	NOTST 010600	SCOPE = 000004
APTENV= 000001	CKSWR = 104407	LEDREG 001304	NUMBER 007742	SET = 177777
APTSIZ= 000200	CLKDS 023277	LF = 000012	ODD 022346	SIZE 020014
APTSPO= 000100	CLKEN 024207	LKSREG 001306	ORERR = 040000	SLU 003726
ASWREG= 000000	CLKVEC= 000100	LNKMSG 023375	PARC = 172340	SPTMR 014714
ATESTN= 000000	CLR = 000000	LOOP 003742	PAR1 = 172342	SRO = 177572
AUNIT = 000000	CONSOL 022354	LOROM 001274	PAR2 = 172344	SR3 = 172516
AUSM = 000000	CR = 000015	LOROM2 001300	PAR3 = 172346	STACK = 001100
AVZCT1= 000000	CRLF = 000200	MAXMEM 021520	PAR4 = 172350	START 001414
AVZCT2= 000000	CYCLE 021532	MEM 024644	PAR5 = 172352	STATEN 014704
BI SE0 001254	CODROP 023116	MEMTBL 021416	PAR6 = 172354	STKLMT= 177774
BASE1 001260	COEND 014706	MODTST 011504	PAR7 = 172356	STEND 020004
BASE2 001264	COXMIT 014704	MYTYPE 022716	PASS 005522	SWR 001140
BASE3 001270	C1CON 024115	M100K 024545	PCRMSG 023561	SWREG 000176

CVMXBAO MXV11B DIAG  
SYMBOL TABLE

MACRO M1113 28-FEB-83 16:15 PAGE 54-2

1 11

SEQ 0138

SW0	=	000001	TST13	005712	SBDDAT	001126	SINTAG	001135	SRDLIN	026114
SW00	=	000001	TST14	006060	SBELL	001164	SITEMB	001114	SRDSZ	= 000010
SW01	=	000002	TST15	006416	SCHARC	025446	SLF	001172	SRTNAD	024764
SW02	=	000004	TST16	006662	SCKSWR	025452	SLFLG	025557	SSAVR6	025156
SW03	=	000010	TST17	007210	SCMTAG	001100	SLPADR	001106	SSCOPE	026762
SW04	=	000020	TST2	002244	SCM3	= 000000	SLPERR	001110	SScTUP	= 000137
SW05	=	000040	TST20	007414	SCNTLC	026252	SLSTCN	= 177777	STUP	= 177777
SW06	=	000100	TST21	010126	SCNTLG	026264	SLSTIN	= 000000	SSVLAD	027170
SW07	=	000200	TST22	010600	SCNTLU	026257	SLSTST	= 177777	SSVPC	= 000204
SW08	=	000400	TST23	011504	SCPUOP	001222	SLSTTA	= 000000	SSWR	= 167400
SW09	=	001000	TST24	012556	SCRLF	001171	SMADR1	001226	SSWREG	(01216
SW1	=	000002	TST25	014716	SDBLK	027456	SMADR2	001232	SSWRMK	= 000000
SW10	=	002000	TST26	015656	SDEVCT	001204	SMADR3	001236	STESTN	001200
SW11	=	004000	TST3	003010	SDEVN	001252	SMADR4	001242	STIMES	001160
SW12	=	010000	TST35	003324	SDOAGN	024762	SMAIL	001174	STKB	001146
SW13	=	020000	TST4	003512	SOTBL	027446	SMAMS1	001224	STKS	001144
SW14	=	040000	TST5	004122	SENDAD	024752	SMAMS2	001230	STN	= 000027
SW15	=	100000	TST6	004324	SENDCT	024720	SMAMS3	001234	STPB	001152
SW2	=	000004	TST7	004542	SENDNG	024771	SMAMS4	001240	STPFLG	001157
SW3	=	000010	TWIXN	024226	SENULL	024766	SMADR	001002	STPS	001150
SW4	=	000020	TWOMX	024265	SENV	001214	SMFLG	026556	STRAP	027714
SW5	=	000040	TYPDS	= 104405	SENYM	001215	SMNEW	026302	STRAP2	027736
SW6	=	000100	TYPE	= 104401	SEOP	024664	SMSGAD	001210	STRP	= 000013
SW7	=	000200	TYPOC	= 104402	SEOPCT	024712	SMSGLG	001212	STRPAD	027750
SW8	=	000400	TYPON	= 104404	SERFLG	001103	SMSGTY	001174	STSTM	001004
SW9	=	001000	TYPOS	= 104403	SERMAX	001115	SMSWR	026271	STSTMN	001102
TBITVE	=	000014	VECT0	001256	SERROR	026562	SMTYP1	001225	STTYIN	026242
TBUF		001322	VECT1	001262	SERRPC	001116	SMTYP2	001231	STYPDS	027242
TCSR		001320	VECT2	001266	SERRTB	001254	SMTYP3	001235	STYPE	025170
TESTSA		002332	VECT3	001272	SERTTL	001112	SMTYP4	001241	STYPEC	025402
TIMER		022566	WAIT	022704	SESCAP	001162	SMXCNT	027240	STYPEX	025450
TIMER1		022642	WORDL	022344	SETABL	001214	SMULL	001154	STYPOC	027512
TKVEC	=	000060	WRAP	022352	SETEND	001254	SMUTST	= 000001	STYPON	027526
TMP1		001326	XOSRV	013534	SFATAL	001176	SOCNT	027710	STYPOS	027466
TMP2		001330	X1SRV	013640	SFFLG	026560	SOMODE	027712	SUNIT	001206
TPVEC	=	000064	X2SRV	016634	SFILLC	001156	SOVER	027224	SUNITM	001010
TRAN		007744	X3SRV	016740	SFILLS	001155	SPASS	001202	SUSWR	001220
TRAPVE	=	000034	SAPTHD	001000	SGADR	001120	SPASTM	001006	SVECT1	001244
TRPCAT		001336	SATYC	026340	SGDAT	001124	SPOWER	025160	SVECT2	001246
TRTVEC	=	000014	SATY1	026314	SGET42	024742	SPWRAD	025146	SXTSTR	026774
TRUE	=	000001	SATY3	026322	SGTSWR	025522	SFWRDN	025006	SSGET4	= 000000
TST1		002072	SATY4	026332	SHD	= 000000	SPWRNG	025142	SOFILL	027711
TST10		004772	SAUTOB	001134	SHIBTS	001000	SPURUP	025060	\$61	010314
TST11		005254	SBASE	001250	SICNT	001104	SQUES	001170	.SX	= 001000
TST12		005530	SBDADR	001122	SILLUP	025152	SBDCHR	025774		

. ABS. 027776 000  
000000 001  
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 42136 WORDS ( 165 PAGES)  
DYNAMIC MEMORY: 20310 WORDS ( 78 PAGES)  
ELAPSED TIME: 00:07:51  
CVMXCA,CVMXBA/CR/-SP=SYSMAC/MLB,CVMXBA

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES			
ABASE	=	000000	#13-794	15-888	15-888	
ACDW1	=	000000	15-888			
ACDW2	=	000000	15-888			
ACPUOP	=	000000	15-888	15-888		
ADDR	=	003322	*18-1193	*18-1221	*18-1246	*18-1272 #18-1283
ADDW0	=	000000	15-888			
ADDW1	=	000000	15-888			
ADDW10	=	000000	15-888			
ADDW11	=	000000	15-888			
ADDW12	=	000000	15-888			
ADDW13	=	000000	15-888			
ADDW14	=	000000	15-888			
ADDW15	=	000000	15-888			
ADDW2	=	000000	15-888			
ADDW3	=	000000	15-888			
ADDW4	=	000000	15-888			
ADDW5	=	000000	15-888			
ADDW6	=	000000	15-888			
ADDW7	=	000000	15-888			
ADDW8	=	000000	15-888			
ADDW9	=	000000	15-888			
ADEVCT	=	000000	15-888	15-888		
ADEVN	=	000000	#13-795	15-888	15-888	
AENV	=	000000	15-888	15-888	15-888	
AENVN	=	000000	15-888	15-888	15-888	
AFATAL	=	000000	15-888	15-888	15-888	
AMADR1	=	000000	15-888	15-888	15-888	
AMADR2	=	000000	15-888	15-888	15-888	
AMADR3	=	000000	15-888	15-888	15-888	
AMADR4	=	000000	15-888	15-888	15-888	
AMAMS1	=	000000	15-888	15-888	15-888	
AMAMS2	=	000000	15-888	15-888	15-888	
AMAMS3	=	000000	15-888	15-888	15-888	
AMAMS4	=	000000	15-888	15-888	15-888	
AMSGAD	=	000000	15-888	15-888	15-888	
AMSGLG	=	000000	15-888	15-888	15-888	
AMSGTY	=	000000	15-888	15-888	15-888	
AMTYP1	=	000000	15-888	15-888	15-888	
AMTYP2	=	000000	15-888	15-888	15-888	
AMTYP3	=	000000	15-888	15-888	15-888	
AMTYP4	=	000000	15-888	15-888	15-888	
APASS	=	000000	15-888	15-888	15-888	
APRIOR	=	000000	15-888			
APTCSU	=	000040	47-4532	#49-4536		
APTENV	=	000001	47-4532	49-4536	#49-4536	50-4538
APTSIZ	=	000200	16-947	#49-4536		
APTSPO	=	000100	47-4532	49-4536	#49-4536	
ASWREG	=	000000	15-888	15-888		
ATESTN	=	000000	15-888	15-888		
AUNIT	=	000000	15-888	15-888		
AUSWR	=	000000	#13-797	15-888	15-888	
AVECT1	=	000000	#13-796	15-888	15-888	

CVNIXBA  
SYMBOL

CREATED BY  
CROSS REFERENCE

MACRO ON 28-FEB-83 AT 16:18

PAGE 2  
CREF V01

K 11

SEQ 0140

SYMBOL	VALUE	REFERENCES
AVECT2	= 000000	15-888 15-888
BASE0	001254	#16-890 36-2873 37-2989 38-3140 38-3145 39-3258 39-3377 39-3387 42-4207
BASE1	001260	42-4228 #16-852 37-3010 37-3019 37-3101 38-3151 38-3156 39-3269 39-3278 39-3344
BASE2	001264	39-3399 39-3409 42-3927 42-3939 42-4264 42-4282 #16-894 36-2883 40-3478 40-3485 40-3569 40-3614 40-3616 40-3620 41-3686
BASE3	001270	41-3692 41-3696 41-3732 41-3739 41-3796 41-3846 41-3856 42-3959 42-4289 #16-896 36-2890 40-3503 40-3510 40-3581 40-3626 40-3628 40-3632 41-3689
BITHLD	022640	41-3701 41-3705 41-3747 41-3754 41-3816 41-3868 41-3878 42-4309
BIT0	= 000001	*43-4399 43-4403 #43-4415
BIT00	= 000001	#13-827 19-1368 35-2741 35-2772 42-3978 42-4046
BIT01	= 000002	#13-827 13-827 13-850
BIT02	= 000004	#13-827 13-827
BIT03	= 000010	#13-827 13-827
BIT04	= 000020	#13-827 13-827
BIT05	= 000040	#13-827 13-827
BIT06	= 000100	#13-827 13-827 13-837 13-844
BIT07	= 000200	#13-827 13-827 13-836 13-848
BIT08	= 000400	#13-827 13-827 51-4540
BIT09	= 001000	#13-827 13-827 50-4538 51-4540
BIT1	= 000002	#13-827 18-1173 35-2746 35-2776 42-3974
BIT10	= 002000	#13-827 37-2972 37-2980 37-3047 37-3086 39-3219 39-3249 39-3319 40-3458
BIT11	= 004000	41-3681 41-3710 42-4209 42-4241 42-4298 42-4318 50-4538
BIT12	= 010000	#13-827 35-2752 42-4235 51-4540
BIT13	= 020000	#13-827 13-844 17-1050 36-2864 42-4032 42-4098 #13-827 13-843 36-2879 40-3454 41-3677 42-3913 42-3923 42-3948 42-3954
BIT14	= 040000	42-4253 50-4538
BIT15	= 100000	#13-827 13-842 51-4540 #13-827 13-841 36-2869 37-2951 37-2978 37-3045 37-3084 39-3201 39-3247
BIT2	= 000004	39-3317 42-3907 42-4223 #13-827 16-956 16-983 17-1052 20-1447 22-1472 23-1538 24-1610 25-1689
BIT3	= 000010	26-1775 27-1892 27-1911 28-1950 28-1971 29-2006 29-2007 29-2031 29-2051
BIT4	= 000020	29-2120 30-2180 31-2274 31-2284 31-2316 31-2366 32-2393 32-2433 33-2484
BIT5	= 000040	33-2627 35-2696 35-2719 35-2759 35-2809 36-2919 37-2944 37-2994 37-3024
BIT6	= 000100	39-3194 39-3209 35-3391 39-3413 40-3447 40-3490 40-3515 41-3670 41-3688
BIT7	= 000200	41-3691 41-3860 41-3882 42-3970
BIT8	= 000400	#13-827 37-2974 37-3008 37-3099 39-3267 39-3342 42-4211 42-4276
BIT9	= 001000	#13-827 42-4270 42-4293 42-4313
BKGND	003002	#13-827 16-1003 16-1012 17-1046 18-1169 19-1364 19-1385 22-1475 23-1541
BPTVEC	= 000014	#13-827 24-1613 24-1663 25-1692 25-1728 25-1754 26-1778 27-1895 28-1953 29-2019
		30-2183 31-2287 32-2405 33-2487 35-2699 36-2860 37-2947 39-3197 40-3450
		41-3673 42-4013 42-4058
		#13-827 18-1289 42-3996 42-4069
		#13-827 37-2953 37-3005 37-3097 39-3203 39-3265 39-3340 42-3910 42-3920
		42-3930 42-3942 42-4262
		#13-827 27-1909 28-1969 29-2029 29-2049 29-2118 31-2314 31-2364 32-2431
		33-2625 35-2717 35-2757 35-2807 37-2992 37-3022 39-3207 39-3389 39-3411
		40-3488 40-3513 41-3684 41-3858 41-3880
		#17-1149
		#13-827

CVMXBA  
SYMBOL CROSS REFERENCE

MACRO ON 28-FEB-83 AT 16:18

PAGE 3  
CREF V01

L 11

SEQ 0141

SYMBOL	VALUE	REFERENCES
BREAK	= 000001	#13-850 23-1558 23-1565 23-1568 23-1576 23-1578 23-1586 23-1591 35-2720
BRK	022350	35-2750 35-2784 35-2788 35-2801 23-1545 35-2708 *42-4237 *42-4239 *42-4272 *42-4274 *42-4295 *42-4297 *42-4315 *42-4317 #42-4330
CARR	001334	#16-918 20-1419 36-2916 42-4213
CHOR	012450	37-2984 #38-3139
CHOTAB	013704	39-3232 39-3285 39-3323 #39-3423
CHOX	012464	37-2986 #38-3144
CH1R	012506	37-3014 #38-3150
CH1TAB	014304	39-3286 39-3348 #39-3424
CH1X	012524	37-3016 #38-3155
CH2R	015540	40-3480 #40-3613
CH2TAB	017004	41-3716 41-3761 41-3795 #41-3893
CH2X	015560	40-3482 #40-3619
CH3R	015602	40-3505 #40-3625
CH3TAB	017404	41-3762 41-3815 #41-3894
CH3X	015624	40-3507 #40-3631
CKSWR	= 104407	50-4538 50-4538 51-4540 #54-4546
CLKDS	023277	42-3994 #44-4473
CLKEN	024207	42-3980 #44-4488
CLKVEC	= 000100	#16-914 *19-1374 *19-1375 *19-1405 *19-1406
CLR	= 000000	#13-831
CONSOL	022354	23-1547 26-1784 27-1901 28-1959 29-2010 30-2234 31-2277 32-2396 33-2493 35-2706 *42-4247 *42-4284 #42-4332
CR	= 000015	#13-827 44-4487 44-4489 44-4490 44-4492 44-4493 44-4494 44-4495 44-4496 44-4497 44-4498 44-4499 44-4500 44-4501 44-4502 44-4503 44-4504 44-4505 44-4506 44-4507 44-4508 44-4509 44-4510 44-4511 44-4512 44-4513 44-4514 44-4515 44-4516 44-4517 44-4518 44-4519 44-4520 44-4521 44-4522 44-4523 44-4524 44-4525 47-4532 47-4532
CRLF	= 000200	#13-827 16-948 16-948 36-2871 36-2871 36-2900 36-2900 44-4445 44-4468 44-4469 44-4470 44-4472 44-4473 44-4474 44-4476 44-4477 44-4478 44-4479 44-4480 44-4481 44-4482 44-4483 44-4484 44-4485 44-4486 44-4488 44-4491 47-4532 47-4532
CYCLE	021532	20-1422 #42-4200 42-4226 42-4260
CODROP	023116	42-3909 #44-4468
COENO	014706	*39-3263 39-3334 39-3380 #39-3428
COXMIT	014704	*39-3229 39-3380 *39-3382 39-3392 #39-3427
C1CON	024115	42-3920 42-3941 #44-4485
C1DROP	023146	42-3912 42-3922 #44-4469
C1END	014712	*39-3284 39-3359 39-3402 #39-3430
C1XMIT	014710	*39-3230 39-3402 *39-3404 39-3414 #39-3429
C2END	020006	*41-3744 41-3808 41-3849 #41-3898
C2XMIT	020004	*41-3713 41-3849 *41-3851 41-3861 #41-3897
C3END	020012	*41-3760 41-3828 41-3871 #41-3900
C3XMIT	020010	*41-3714 41-3871 *41-3873 41-3883 #41-3899
DATA	010016	*33-2533 33-2546 33-2620 33-2628 #33-2634 34-2654 *34-2658 *34-2663 34-2664
DDISP	= 177570	#13-827 15-888 16-947
DDRMSG	023442	42-4064 #44-4477
DEVN	024316	42-4343 #44-4491
DISPLA	001142	#15-888 *16-947 *16-947 50-4538 51-4540
DISPRE	000174	#14-882 16-947
DLADD	001312	#16-908 20-1424 20-1426 20-1429 20-1432 27-1929 36-2904 *40-3478 *40-3503

CVMXBA  
SYMBOL CROSS REFERENCE  
SYMBOL VALUE

CREATED BY MACRO ON 28-FEB-83 AT 16:18

PAGE 4  
CREF V01

M 11

SEQ 0142

REFERENCES

DLVEC	001324	*40-3569	*40-3581	*41-3732	*41-3747	*41-3796	*41-3816	*42-4207	*42-4228	*42-4264
		*42-4289	*42-4309	44-4457						
		#16-913	30-2190	31-2293	33-2523	36-2906	*40-3479	*40-3504	*40-3570	*40-3582
		*41-3732	*41-3748	*41-3797	*41-3817	*42-4208	*42-4229	*42-4265	*42-4290	*42-4310
		44-4459								
DONE	= 000200	#13-836	20-1439	27-1915	27-1932	28-1976	28-1992	29-2036	29-2124	32-2438
		35-2725	35-2763	35-2814	37-3000	37-3031	37-3114	39-3213	39-3224	40-3496
		40-3521	41-3697	41-3706						
DOSR	= 177570	#13-827	15-888	16-947						
EMTVEC	= 000030	#13-827	*16-947	*16-947						
ERRCHK	010576	*35-2714	*35-2741	*35-2746	35-2772	35-2776	#35-2842			
ERRCNT	007740	*33-2532	33-2555	33-2561	#33-2602	33-2622	*34-2660			
ERRFLG	005524	*26-1794	*26-1832	26-1850	#26-1872					
ERROR	= 104000	#13-827	33-2563							
ERRVEC	= 000004	#13-827	16-947	*16-947	*16-947	*18-1175	*18-1176	18-1279	*18-1279	*18-1280
		*18-1291	*18-1292	18-1323	*18-1323	*18-1324	*22-1479	*22-1480	*22-1495	*22-1496
		42-3957	*42-3958	*42-3963	*42-3967	42-3981	*42-3982	*42-3987	*42-3991	42-4001
		*42-4002	*42-4007	*42-4011	42-4014	*42-4020	*42-4025	*42-4029	42-4034	*42-4035
		*42-4040	*42-4044	42-4048	*42-4049	*42-4051	*42-4056	42-4060	*42-4061	*42-4063
		*42-4068	42-4071	*42-4072	*42-4074	*42-4079	*42-4081	*42-4082	42-4132	*42-4132
		*42-4133	51-4540	*51-4540	*51-4540	*51-4540				
ERR15	= 100000	#13-841	29-2075	29-2154	32-2453	34-2652				
EXFLG	005526	*26-1795	*26-1858	*26-1862	26-1864	#26-1873				
EX1	007736	33-2495	#33-2595							
EX2	010574	35-2710	#35-2836							
FRERR	= 020000	#13-843	33-2572	35-2744						
GNS	= *****	14-882	14-882	16-948	36-2871	36-2872	36-2874	36-2876	36-2882	36-2884
		36-2886	36-2889	36-2891	36-2893	36-2900	36-2903	36-2905	36-2907	44-4445
		44-4447	44-4450	44-4456	44-4458	54-4546	54-4546	54-4546	54-4546	54-4546
		54-4546	54-4546	54-4546	54-4546	54-4546	54-4546	54-4546	54-4546	54-4546
		54-4546	54-4546	54-4546	54-4546	54-4547	54-4547			
GTDEVP	= 104412	16-958	42-3933	42-3945	42-3965	42-3989	42-4009	42-4027	42-4042	#54-4547
GTSWR	= 104406	16-948	#54-4546							
GTSDEV	022364	#42-4343	48-4534	48-4534	54-4547					
HICHAN	022362	*42-3916	*42-3926	*42-3951	*42-3968	42-4204	#42-4336			
HIROM	001276	#16-899	18-1198	18-1224						
HIROM2	001302	#16-901	18-1249	18-1275						
HT	= 000011	#13-827	47-4532	47-4532						
IE	= 000100	#13-837	#13-849	24-1630	24-1638	24-1640	24-1648	24-1650	24-1658	24-1667
		25-1698	25-1705	25-1707	25-1714	25-1716	25-1723	25-1732	30-2209	30-2220
		30-2248	31-2301	31-2333	31-2360	33-2538	33-2540	33-2559	33-2560	33-2631
		34-2659	34-2666	34-2670	37-2990	37-2995	37-3020	37-3026	38-3141	38-3147
		38-3152	38-3158	39-3259	39-3261	39-3279	39-3281	39-3384	39-3394	39-3406
		39-3416	40-3496	40-3491	40-3511	40-3516	40-3615	40-3622	40-3627	40-3634
		41-3740	41-3742	41-3755	41-3757	41-3853	41-3863	41-3875	41-3885	
ILLCLK	022560	19-1405	#42-4388							
ILLMSG	023511	42-4388	#44-4478							
INTABL	012546	*37-2957	*37-2958	*37-2959	*37-2960	37-3050	37-3053	37-3089	37-3093	37-3104
		37-3108	#38-3166							
INTABM	015646	*40-3461	*40-3462	*40-3463	*40-3464	40-3535	40-3538	40-3572	40-3576	40-3584
		40-3588	#40-3643							
INTFLG	021530	*16-1005	16-1007	*18-1191	18-1193	*18-1242	18-1244	*18-1293	18-1295	*19-1376

CVMXBA CRFATED BY MACRO ON 28-FEB-83 AT 16:18  
 SYMBOL CROSS REFERENCE VALUE

PAGE 5 N 11  
 CREF V01

SEQ 0143

SYMBOL	VALUE	REFERENCES
INTSRV	021522	19-1386 *19-1392 19-1396 *22-1485 22-1487 *30-2188 30-2222 30-2238 *30-2250
IOTVEC	= 000020	30-2256 *31-2299 31-2336 31-235i *31-2362 *31-2370 *42-4083 42-4089 42-4115
LEDHLD	001332	*42-4186 #42-4189 16-926 18-1175 18-1291 19-1374 22-1479 30-2192 31-2294 42-4081 #42-4186
LEDREG	001304	#13-827 *16-947 *16-947 *37-3120 *37-3121 *39-3365 *39-3366 *40-3595 *40-3595
LF	= 000012	*41-3834 *41-3835 #15-917 #16-902 *16-949 16-1006 16-1014 17-1048 18-1171 19-1366 22-1477 23-1543
LKSREG	001306	24-1615 24-1665 25-1694 25-1730 25-1756 26-1780 27-1897 28-1955 29-2021
LNKMSG	023375	30-2185 31-2289 32-2407 33-2489 35-2701 36-2862 37-2949 39-3199 40-3452
LOOP	003742	41-3675 42-4021 42-4062 #13-827 44-4487 44-4489 44-4490 44-4492 44-4493 44-4494 44-4495 44-4496
LOROM	001274	44-4497 44-4498 44-4499 44-4500 44-4501 44-4502 44-4503 44-4504 44-4505
LOROM2	001300	44-4506 44-4507 44-4508 44-4509 44-4510 44-4511 44-4512 44-4513 44-4514
KAXMEM	021520	44-4515 44-4516 44-4517 44-4518 44-4519 44-4520 44-4521 44-4522 44-4523
MEM	024644	44-4524 44-4525 47-4532 47-4532 42-3983 42-4050
MEMTBI	021416	#16-906 19-1379 19-1385 #44-4476
MODTSI	011504	42-4052 #44-4476 #20-1416 36-2921
MYTYPE	022716	#16-898 18-1190 18-1215
M100K	024545	#16-900 18-1241 18-1266
M104K	024554	*42-4096 *42-4097 #42-4175
M108K	024563	42-4130 #44-4525
M112K	024572	42-4101 42-4127 #42-4141
M116K	024601	20-1449 #37-2729
M12K	024341	#44-4445 50-4538
M120K	024610	42-4165 #44-4516
M124K	024617	42-4166 #44-4517
M128K	024626	42-4167 #44-4518
M132K	024635	42-4168 #44-4519
M16K	024347	42-4169 #44-4520
M20K	024355	42-4143 #44-4494
M24K	024363	42-4170 #44-4521
M28K	024371	42-4171 #44-4522
M32K	024377	42-4172 #44-4523
M36K	024405	42-4173 #44-4524
M4K	024327	42-4144 #44-4495
M40K	024413	42-4145 #44-4496
M44K	024421	42-4146 #44-4497
M48K	024427	42-4147 #44-4498
M52K	024435	42-4148 #44-4499
M56K	024443	42-4149 #44-4500
M60K	024451	42-4141 #44-4492
M64K	024457	42-4150 #44-4501
M68K	024465	42-4151 #44-4502
M72K	024473	42-4152 #44-4503
		42-4153 #44-4504
		42-4154 #44-4505
		42-4155 #44-4506
		42-4156 #44-4507
		42-4157 #44-4508
		42-4158 #44-4509



SYMBOL	CROSS REFERENCE	VALUE	REFERENCES							
M76K		024501	42-4159	#44-4510						
M8K		024334	42-4142	#44-4493						
M80K		024507	42-4160	#44-4511						
M84K		024515	42-4161	#44-4512						
M88K		024523	42-4162	#44-4513						
M92K		024531	42-4163	#44-4514						
M96K		024537	42-4164	#44-4515						
NOCHAN		021414	20-1417	*42-3917	*42-3952	#42-4137	42-4200			
NOCH1		023227	42-3932	42-3944	#44-4472					
NOCLK		023750	42-3988	#44-4482						
NODDR		024012	42-4026	#44-4483						
NOLED		023176	42-4015	#44-4470						
NOPMNG		023630	42-4041	#44-4480						
NOPCR		024061	42-3998	#44-4484						
NOPCR2		023317	42-4008	#44-4474						
NORAM		024163	42-3972	#44-4487						
NOROM		024140	42-3976	#44-4486						
NOSMX		023675	42-3964	#44-4481						
NOTST		010600	#36-2849	41-3836						
NUMBER		007742	*33-2535	33-2546	#33-2603	33-2620	34-2658	34-2664		
ODD		022346	*42-4233	*42-4268	*42-4292	*42-4312	#42-4329			
ORERR	=	040000	#13-842	29-2057	29-2096	29-2136	33-2565			
PAR0	=	172340	#13-856	17-1059	42-4036	42-4103				
PAR1	=	172342	#13-857							
PAR2	=	172344	#13-858							
PAR3	=	172346	#13-859							
PAR4	=	172350	#13-860							
PAR5	=	172352	#13-861							
PAR6	=	172354	#13-862	*17-1072	*17-1077	*17-1083	17-1084	*17-1086	17-1097	17-1100
			17-1107	*17-1110	*17-1116	17-1117	*17-1119	17-1130	17-1133	*17-1139
			*42-4114							17-1140
PAR7	=	172356	#13-863							
PASS		005522	*26-1791	*26-1852	26-1853	#26-1871				
PCMSG		023561	42-4075	#44-4479						
PCRREG		001310	#16-907	18-1294	18-1300	18-1301	18-1313	18-1314	42-4003	42-4073
PDR0	=	172300	#13-866	17-1060	42-4104					
PDR1	=	172302	#13-867							
PDR2	=	172304	#13-868							
PDR3	=	172306	#13-869							
PDR4	=	172310	#13-870							
PDR5	=	172312	#13-871							
PDR6	=	172314	#13-872							
PDR7	=	172316	#13-873							
PERR	=	000000	#13-844							
PHASE2		022356	*20-1412	20-1445	36-2867	36-2912	*36-2914	*42-4216	#42-4334	
PIRQ	=	177772	#13-827							
PIRQVE	=	000240	#13-827							
PRO	=	000000	#13-827	30-2214	31-2308	33-2517	37-3064	39-3292	40-3549	41-3768
PR1	=	000040	#13-827							
PR2	=	000100	#13-827							
PR3	=	000140	#13-827							
PR4	=	000200	#13-827							

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
PR5	=	000240	#13-827
PR6	=	000300	#13-827
PR7	=	000340	#13-827
			16-927 22-1480 24-1621 30-2193 31-2295 31-2378 33-2526 33-2530
			37-2966 37-2985 37-2987 37-3015 37-3017 37-3076 39-3241 39-3254 39-3256
			39-3274 39-3276 39-3309 40-3470 40-3481 40-3483 40-3506 40-3508 40-3561
			41-3725 41-3735 41-3737 41-3750 41-3752 41-3785
PS	=	177776	#13-827
PSW	=	177776	#13-827
PWRVEC	=	000024	#13-827
PICNT		022360	*16-947 *16-947 *46-4530 *46-4530 *46-4530 *46-4530 *46-4530 *46-4530
RAMROM		002066	*20-1414 36-2898 *36-2901 *42-4217 #42-4335
RBUF		001316	#16-962 42-4363 45-4528
			#16-910 *20-1426 *20-1427 22-1502 28-1991 29-2055 29-2096 29-2136 29-2154
			32-2409 32-2451 34-2650 35-2737 35-2752 35-2766 35-2805 35-2827 37-3119
			39-3218 39-3228 40-3594 *41-3692 *41-3693 41-3694 *41-3701 *41-3702 41-3703
RCSR		001314	#16-909 *20-1424 22-1483 22-1498 25-1698 25-1705 25-1707 25-1714 25-1716
			25-1723 25-1732 27-1914 27-1932 28-1975 28-1992 29-2055 29-2123 31-2301
			31-2333 31-2360 32-2437 33-2540 33-2560 34-2659 34-2666 35-2724 35-2762
			35-2813 37-3113 39-3212 39-3223
			48-4534 #54-4546
RDCHR	=	104410	#54-4546
RDLIN	=	104411	#54-4546
RDRWD		003004	#17-1150
RDY	=	000200	#13-848 25-1739 26-1805 26-1828 26-1838 30-2197 31-2320 32-2418
REC		010020	33-2525 #34-2649
REGHLD		022636	*43-4398 43-4403 #43-4414 *43-4418 43-4422
RESVEC	=	000010	#13-827
RHLD		010124	33-2563 33-2565 33-2572 *34-2650 34-2652 34-2654 #34-2675
ROSRV		013474	39-3253 #39-3377
R1SRV		013600	39-3273 #39-3399
R2SRV		016574	41-3734 #41-3846
R3SRV		016700	41-3749 #41-3868
R6	=	0000006	#13-827 *16-947 *16-947 16-947
R7	=	0000007	#13-827
SAVBK		003006	#17-1151
SCOPE	=	000004	#13-827
			16-976 17-1037 18-1159 19-1355 22-1464 23-1532 24-1602 25-1682
			26-1769 27-1885 28-1943 29-2004 30-2173 31-2272 32-2391 33-2477 35-2689
			36-2850 37-2936 39-3186 40-3439 41-3662 45-4528
SET	=	177777	#13-830 26-1832 26-1850 26-1864
SIZE		020014	16-960 #42-3907 42-4361
SLU		003726	19-1370 #20-1412
SPTMR		014714	*39-3298 *39-3301 #39-3431 *41-3774 *41-3777
SRO	=	177572	#13-874 *17-1068 *17-1096 *17-1099 *17-1129 *17-1132 *17-1143 *42-4112 *42-4120
SR3	=	172516	#13-875
STACK	=	001100	#13-827 16-947 16-962 20-1416
START		001414	14-882 16-940 #16-943 42-3934 42-3946 42-3966 42-3990 42-4010 42-4028
			42-4043 46-4530
STATEN		014704	39-3234 #39-3425
STKMT	=	177774	#13-827
STTEND		020004	41-3718 #41-3895
SWR		001140	#15-888 16-947 *16-947 16-947 *16-947 *16-947 16-948 36-2864 46-4530
			46-4530 48-4534 48-4534 50-4538 50-4538 50-4538 50-4538 51-4540 51-4540
			51-4540 51-4540
SWREG		000176	#14-882 16-947 16-948 48-4534 48-4534

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
SW0		= 000001	#13-827
SW00		= 000001	#13-827 13-827
SW01		= 000002	#13-827 13-827
SW02		= 000004	#13-827 13-827
SW03		= 000010	#13-827 13-827
SW04		= 000020	#13-827 13-827
SW05		= 000040	#13-827 13-827
SW06		= 000100	#13-827 13-827
SW07		= 000200	#13-827 13-827
SW08		= 000400	#13-827 13-827
SW09		= 001000	#13-827 13-827
SW1		= 000002	#13-827
SW10		= 002000	#13-827
SW11		= 004000	#13-827
SW12		= 010000	#13-827
SW13		= 020000	#13-827
SW14		= 040000	#13-827
SW15		= 100000	#13-827
SW2		= 000004	#13-827
SW3		= 000010	#13-827
SW4		= 000020	#13-827
SW5		= 000040	#13-827
SW6		= 000100	#13-827
SW7		= 000200	#13-827
SW8		= 000400	#13-827
SW9		= 001000	#13-827
TBITVE		= 000014	#13-827
TBUF		001322	#16-912 *20-1432 *20-1433 22-1510 26-1801 26-1817 26-1824 27-1912 28-1972 29-2032 29-2052 29-2121 30-2253 31-2317 31-2367 32-2434 33-2628 35-2760 35-2810 37-3111 39-3210
TCSR		001320	#16-911 *20-1429 *20-1430 20-1438 20-1447 22-1472 22-1506 23-1538 23-1558 23-1565 23-1568 23-1576 23-1578 23-1586 23-1591 24-1610 24-1630 24-1638 24-1640 24-1648 24-1650 24-1658 24-1667 25-1689 25-1739 26-1775 26-1804 26-1818 26-1828 26-1837 27-1892 27-1911 28-1950 28-1971 29-2006 29-2007 29-2031 29-2051 29-2120 30-2180 30-2196 30-2209 30-2220 30-2248 31-2274 31-2284 31-2316 31-2319 31-2366 32-2393 32-2417 32-2433 33-2484 33-2538 33-2559 33-2627 33-2631 34-2670 35-2696 35-2719 35-2720 35-2750 35-2759 35-2784 35-2787 35-2801 35-2809 36-2919 37-2944 39-3194 39-3209 39-3391 39-3413 40-3447 41-3670 41-3860 41-3882
TESTSA		002332	17-1053 #17-1058
TIMER		022566	20-1437 26-1803 26-1836 27-1913 28-1974 29-2034 29-2122 30-2195 31-2318 32-2416 32-2436 35-2723 35-2761 35-2786 35-2812 37-3112 39-3211 39-3222 41-3695 41-3704 #43-4398 30-2221 31-2335 #43-4418
TIMER1		022642	
TKVEC		= 000060	#13-827
TMP1		001326	#16-915 *33-2545 *33-2548 *37-2999 *37-3002 *37-3030 *37-3033 *40-3495 *40-3498 *40-3520 *40-3523
TMP2		001330	#16-916 *33-2544 *33-2550
TPVEC		= 000064	#13-827
TRAN		007744	33-2529 #33-2619
TRAPVE		= 000034	#13-827 *16-947 *16-947
TRPCAT		001336	#16-925

CVMXBA		CREATED BY MACRO ON 28-FEB-83 AT 16:18			PAGE 9	E 12				
SYMBOL	CROSS REFERENCE	REFERENCES	CREF	V01						SEQ 0147
TRIVEC	= 000014	#13-827								
TRUE	= 000001	#13-832	20-1445	36-2867	36-2912	42-4216				
TST1	002072	#16-976								
TST10	004772	#25-1682								
TST11	005254	25-1744	#26-1769							
TST12	005530	26-1785	26-1811	26-1844	#27-1885					
TST13	005712	27-1900	27-1902	27-1921	#28-1943					
TST14	006060	28-1958	28-1960	28-1982	#29-2004					
TST15	006416	29-2009	29-2011	29-2042	29-2066	29-2086	29-2105	29-2130	29-2147	#30-2173
TST16	006662	30-2203	30-2228	#31-2272						
TST17	007210	31-2276	31-2278	31-2326	31-2342	#32-2391				
TST2	002244	16-1004	16-1016	16-1018	#17-1037					
TST20	007414	32-2395	32-2397	32-2424	32-2444	32-2465	#33-2477			
TST21	010126	33-2595	#35-2689							
TST22	010600	35-2731	35-2755	35-2765	35-2794	35-2820	35-2836	#36-2850		
TST23	011504	#37-2936								
TST24	012556	37-2955	37-3127	#39-3186						
TST25	014716	37-2976	39-3205	39-3367	#40-3439					
TST26	015656	40-3456	40-3460	40-3602	#41-3662					
TST3	003010	17-1054	17-1147	#18-1159						
TST35	003324	18-1174	18-1281	#18-1289						
TST4	003512	18-1290	18-1325	#19-1355						
TST5	004122	#22-1464								
TST6	004324	#23-1532								
TST7	004542	23-1548	#24-1602							
TWIXN	024226	42-3915	42-3925	42-3950	#44-4489					
TWOMX	024265	42-3956	#44-4490							
TYPDS	= 104405	36-2877	36-2887	36-2894	36-2908	45-4528	#54-4546			
TYPE	= 104401	16-948	20-1419	36-2871	36-2872	36-2874	36-2876	36-2878	36-2882	36-2884
		36-2886	36-2888	36-2889	36-2891	36-2893	36-2895	36-2900	36-2903	36-2905
		36-2907	36-2909	36-2916	42-3909	42-3912	42-3915	42-3922	42-3925	42-3929
		42-3932	42-3941	42-3944	42-3950	42-3956	42-3964	42-3972	42-3976	42-3980
		42-3989	42-3994	42-3998	42-4008	42-4015	42-4026	42-4041	42-4052	42-4064
		42-4075	42-4128	42-4130	42-4213	42-4343	42-4345	42-4360	42-4382	42-4383
		42-4388	44-4445	44-4447	44-4450	44-4456	44-4458	44-4460	45-4528	45-4528
		46-4530	47-4532	48-4534	48-4534	48-4534	48-4534	48-4534	48-4534	48-4534
		48-4534	48-4534	48-4534	48-4534	50-4538	50-4538	52-4542	53-4544	#54-4546
TYPOC	= 104402	36-2873	36-2875	36-2883	36-2885	36-2890	36-2892	36-2904	36-2906	42-4344
		44-4446	44-4451	44-4457	44-4459	48-4534	#54-4546			
TYPON	= 104404	#54-4546								
TYPOS	= 104403	44-4449	#54-4546							
VECT0	001256	#16-891	36-2875	37-2983	39-3252	42-4208	42-4229			
VECT1	001262	#16-893	37-3013	39-3272	42-4265					
VECT2	001266	#16-895	36-2885	40-3477	40-3479	40-3570	41-3731	41-3733	41-3797	42-4290
VECT3	001272	#16-897	36-2892	40-3502	40-3504	40-3582	41-3746	41-3748	41-3817	42-4310
WAIT	022704	29-2053	30-2236	30-2255	31-2348	31-2369	35-2751	35-2803	#43-4434	
WORDL	022344	*42-4231	*42-4267	*42-4291	*42-4311	#42-4328				
WRAP	022352	27-1899	28-1957	29-2008	31-2275	32-2394	33-2491	35-2704	*42-4243	*42-4245
		*42-4278	*42-4280	*42-4300	*42-4302	*42-4320	*42-4322	#42-4331		
XOSRV	D13534	39-3255	#39-3387							
X1SRV	D13640	39-3275	#39-3409							
X2SRV	D16634	41-3736	#41-3856							

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES								
XSSRV		016740	41-3751	#41-3878							
SAPTHD		001000	14-887	#14-887							
SASTAT	= *****		49-4536	49-4536							
SATYC		026340	49-4536	#49-4536							
SATY1		026314	#49-4536								
SATY3		026322	47-4532	#49-4536							
SATY4		026332	#49-4536	50-4538							
SAUTOB		001134	#15-888	*16-948	48-4534	48-4534	48-4534				
SBASE		001250	#15-888								
SBDADR		001122	#15-888								
SBDADR		001126	#15-888								
SBELL		001164	#15-888	50-4538	50-4538	50-4538					
SCHARC		025446	*47-4532	*47-4532	47-4532	*47-4532	#47-4532				
SCKSWR		025452	#48-4534	54-4546	54-4546						
SCMTAG		001100	#15-888	16-947	16-947	16-947	16-947	16-947	16-947	16-947	
SCMS	= 000000		#15-888	15-888							
SCNTLC		026252	48-4534	48-4534	48-4534	48-4534	#48-4534				
SCNTLG		026264	48-4534	#48-4534							
SCNTLU		026257	48-4534	#48-4534							
SCPUOP		001222	#15-888								
SCRLF		001171	#15-888	36-2878	36-2888	36-2895	36-2909	42-4360	42-4383	44-4460	47-4532
			47-4532	47-4532	48-4534	48-4534	48-4534	50-4538	50-4538	50-4538	
SDBLK		027456	52-4542	52-4542	#52-4542						
SDEVCT		001204	#15-888	*20-1444							
SDEVN		001252	#15-888	*16-956	16-983	16-1003	16-1012	17-1046	17-1050	17-1052	18-1169
			18-1173	18-1289	19-1364	19-1368	22-1475	23-1541	24-1613	24-1663	25-1692
			25-1728	25-1754	26-1778	27-1895	27-1909	28-1953	28-1969	29-2019	29-2029
			29-2049	29-2118	30-2183	31-2287	31-2314	31-2364	32-2405	32-2431	33-2487
			33-2625	35-2699	35-2717	35-2757	35-2807	36-2860	36-2869	36-2879	37-2947
			37-2951	37-2953	37-2972	37-2974	37-2978	37-2980	37-2992	37-3005	37-3008
			37-3022	37-3045	37-3047	37-3084	37-3086	37-3097	37-3099	39-3197	39-3201
			39-3203	39-3207	39-3219	39-3247	39-3249	39-3265	39-3267	39-3317	39-3319
			39-3340	39-3342	39-3389	39-3411	40-3450	40-3454	40-3458	40-3488	40-3513
			41-3673	41-3677	41-3681	41-3684	41-3710	41-3858	41-3860	42-3907	42-3910
			42-3913	42-3920	42-3923	42-3930	42-3942	42-3948	42-3954	42-3970	42-3974
			42-3978	42-3996	42-4013	42-4032	42-4046	42-4058	42-4069	42-4098	42-4209
			42-4211	42-4223	42-4235	42-4241	42-4253	42-4262	42-4270	42-4276	42-4293
			42-4298	42-4313	42-4318	42-4344	*42-4359				
SDOAGN		024762	45-4528	45-4528	#45-4528						
SOTBL		027446	52-4542	#52-4542							
SENDAD		024752	14-885	16-948	#45-4528	50-4538					
SENDCT		024720	16-947	#45-4528							
SENDMG		024771	45-4528	#45-4528							
SENULL		024766	45-4528	#45-4528							
SENV		001214	#15-888	16-948	16-952	47-4532	49-4536	49-4536	50-4538		
SENVN		001215	#15-888	16-947	47-4532	47-4532	49-4536				
SEOP		024664	20-1420	36-2917	42-4214	#45-4528					
SEOPCT		024712	*16-947	#45-4528	45-4528						
SERFLG		001103	#15-888	*50-4538	50-4538	50-4538	51-4540	51-4540	51-4540	*51-4540	51-4540
			51-4540								
SERMAX		001115	#15-888	*16-947	51-4540	*51-4540	51-4540	51-4540			
SERROR		026562	16-947	#50-4538							





CVMXBA  
SYMBOL CROSS REFERENCE  
SYMBOL VALUE

CREATED BY MACRO ON 28-FEB-83 AT 16:18

PAGE 13  
CREF V01

I 12

SEQ 0151

SYMBOL	VALUE	REFERENCES	51-4540	51-4540	51-4540	51-4540	51-4540	51-4540	51-4540	51-4540
SSWREG	001216	#15-888	51-4540	51-4540	51-4540	51-4540	51-4540	51-4540	51-4540	51-4540
SSWRMK	= 000000	13-826	51-4540	51-4540	51-4540	51-4540	51-4540	51-4540	51-4540	51-4540
STESTN	001200	#15-888	16-947	13-826	13-826	13-826	13-826	13-826	13-826	13-826
STIMES	001160	#15-888	16-976	17-1037	18-1159	19-1355	22-1464	23-1532	24-1602	25-1682
STKB	001146	#15-888	16-976	17-1037	18-1159	19-1355	22-1464	23-1532	24-1602	25-1682
STKS	001144	#15-888	16-976	17-1037	18-1159	19-1355	22-1464	23-1532	24-1602	25-1682
STN	= 000027	#15-888	16-976	17-1037	18-1159	19-1355	22-1464	23-1532	24-1602	25-1682
STPB	001152	#15-888	16-976	17-1037	18-1159	19-1355	22-1464	23-1532	24-1602	25-1682
STPFLG	001157	#15-888	16-976	17-1037	18-1159	19-1355	22-1464	23-1532	24-1602	25-1682
STPS	001150	#15-888	16-976	17-1037	18-1159	19-1355	22-1464	23-1532	24-1602	25-1682
STRAP	027714	16-947	16-976	17-1037	18-1159	19-1355	22-1464	23-1532	24-1602	25-1682
STRAP2	027736	#54-4546	16-976	17-1037	18-1159	19-1355	22-1464	23-1532	24-1602	25-1682
STRP	= 000013	#54-4546	16-976	17-1037	18-1159	19-1355	22-1464	23-1532	24-1602	25-1682
STRPAD	027750	#54-4546	16-976	17-1037	18-1159	19-1355	22-1464	23-1532	24-1602	25-1682
STSTM	001004	#14-887	16-976	17-1037	18-1159	19-1355	22-1464	23-1532	24-1602	25-1682
STSTMN	001102	#15-888	16-976	17-1037	18-1159	19-1355	22-1464	23-1532	24-1602	25-1682
STYIN	026242	48-4534	16-976	17-1037	18-1159	19-1355	22-1464	23-1532	24-1602	25-1682
STYPBN	= *****	54-4546	16-976	17-1037	18-1159	19-1355	22-1464	23-1532	24-1602	25-1682
STYPDS	027242	#52-4542	16-976	17-1037	18-1159	19-1355	22-1464	23-1532	24-1602	25-1682
STYPE	025170	#47-4532	16-976	17-1037	18-1159	19-1355	22-1464	23-1532	24-1602	25-1682
STYPEC	025402	42-4366	16-976	17-1037	18-1159	19-1355	22-1464	23-1532	24-1602	25-1682



CREATED BY MACRO ON 28-FEB-83 AT 16:18

PAGE 14  
CREF V01

SEQ 0152

CYMBBA SYMBOL	CROSS REFERENCE VALUE	REFERENCES
STYPEX	025450	47-4532 47-4532 #47-4532
STYPOC	027512	#53-4544 54-4546 54-4546
STYPON	027526	53-4544 #53-4544 54-4546
STYPOS	027466	#53-4544 54-4546
SUNIT	001206	#15-888 *20-1413 *36-2915 42-4204 *42-4206 42-4220 *42-4225 *42-4248 42-4251 42-4255 42-4257 *42-4259 *42-4303 *42-4323
SUNITM	001010	#14-887
SUSWR	001220	#15-898
SVECT1	001244	#15-888
SVECT2	001246	#15-888
SXTSTR	G26774	#51-4540
SSGET4	= 000000	#45-4528 45-4528
SOFILL	G27711	*53-4544 *53-4544 53-4544 #53-4544
S4OCAT	= *****	50-4538 51-4540
S61	010314	#35-2743
.SASTA	= *****	49-4536 49-4536
.SX	= 001000	#14-887 14-887

MACRO NAME	REFERENCES									
COMVEN	#13-827									
ENDCOM	#13-827									
ERROR	#13-814	#16-997	#16-1017	#17-1098	#17-1101	#17-1131	#17-1134	#18-1196	#18-1222	#18-1247
	#18-1273	#18-1297	#18-1305	#18-1318	#19-1398	#19-1398	#22-1489	#22-1500	#22-1504	#22-1508
	#22-1512	#23-1560	#23-1571	#23-1581	#23-1594	#24-1633	#24-1643	#24-1653	#24-1670	#25-1701
	#25-1710	#25-1719	#25-1735	#25-1749	#26-1806	#26-1839	#26-1857	#27-1916	#27-1935	#28-1977
	#28-1995	#29-2037	#29-2060	#29-2078	#29-2099	#29-2125	#29-2139	#29-2157	#30-2198	#30-2223
	#30-2241	#30-2258	#31-2321	#31-2337	#31-2354	#31-2372	#32-2419	#32-2439	#32-2456	#32-2460
	#33-2552	#33-2568	#33-2574	#33-2580	#33-2588	#35-2726	#35-2754	#35-2764	#35-2768	#35-2774
	#35-2778	#35-2789	#35-2815	#35-2830	#37-3004	#37-3035	#37-3091	#37-3095	#37-3106	#37-3110
	#37-3115	#39-3214	#39-3330	#39-3332	#39-3355	#39-3357	#40-3500	#40-3525	#40-3574	#40-3578
	#40-3586	#40-3590	#41-3804	#41-3806	#41-3824	#41-3826				
FESCAPE	#13-827									
GETPRI	#13-827									
GETSWR	#13-827	#16-948	16-948							
LPADR	#13-799	#23-1555	#23-1563	#23-1575	#23-1585	#24-1628	#24-1637	#24-1647	#24-1657	#25-1697
	#25-1704	#25-1713	#25-1722	#27-1907	#27-1927	#28-1966	#29-2024	#29-2074	#29-2093	#29-2112
	#30-2194	#30-2246	#31-2298	#31-2358	#35-2712	#35-2782				
MSG	#16-966	16-976	#17-1021	17-1037	#19-1330	19-1355	#21-1453	22-1464	#23-1524	23-1532
	#25-1678	25-1682	#26-1765	26-1769	#27-1880	27-1885	#30-2166	30-2173	#31-2267	31-2272
	#35-2683	35-2689	#37-2931	37-2936	#39-3171	39-3186	#40-3434	40-3439	#41-3647	41-3662
MULT	#13-827									
NEWTST	#13-827	#16-976	#17-1037	#18-1159	#19-1355	#22-1464	#23-1532	#24-1602	#25-1682	#26-1769
	#27-1885	#28-1943	#29-2004	#30-2173	#31-2272	#32-2391	#33-2477	#35-2689	#36-2850	#37-2936
	#39-3186	#40-3439	#41-3662							
POP	#13-827	#46-4530	#46-4530	#49-4536	#49-4536	#52-4542				
PUSH	#13-827	#46-4530	#46-4530	#49-4536	#49-4536	#49-4536	#52-4542			
REPORT	#13-785	#13-827								
SETPRI	#13-827	#24-1621	#30-2214	#31-2308	#31-2378	#33-2517	#37-2966	#37-3064	#37-3076	#39-3241
	#39-3292	#39-3309	#40-3470	#40-3549	#40-3561	#41-3725	#41-3768	#41-3785		
SETTRA	#54-4546	54-4546	54-4546	54-4546	54-4546	54-4546	54-4546	54-4546	54-4546	54-4546
	54-4547									
SETUP	#13-827	#16-947								
SKIP	#13-827	23-1548	25-1744	26-1785	26-1811	26-1844	27-1900	27-1902	27-1921	28-1958
	28-1960	28-1982	29-2009	29-2011	29-2042	29-2066	29-2086	29-2105	29-2130	29-2147
	30-2203	30-2228	31-2276	31-2278	31-2326	31-2342	32-2395	32-2397	32-2424	32-2444
	32-2465	33-2595	35-2731	35-2794	35-2820	35-2836	37-3127	40-3602		
SLASH	#13-827									
STARS	#13-827	#14-881	#14-885	#14-887	#14-887	#14-887	#15-888	#15-888	#15-888	#16-921
	#16-923	#16-976	#16-976	#17-1037	#17-1037	#18-1159	#18-1159	#18-1182	#18-1184	#18-1207
	#18-1209	#18-1233	#18-1235	#18-1258	#18-1260	#19-1355	#19-1355	#22-1464	#22-1464	#23-1519
	#23-1521	#23-1532	#23-1532	#24-1602	#24-1602	#25-1682	#25-1682	#26-1769	#26-1769	#27-1885
	#27-1885	#28-1943	#28-1943	#29-2064	#29-2004	#30-2173	#30-2173	#31-2272	#31-2272	#32-2391
	#32-2391	#33-2477	#33-2477	#33-2611	#33-2613	#34-2641	#34-2643	#35-2689	#35-2689	#36-2850
	#36-2850	#37-2936	#37-2936	#39-3186	#39-3186	#39-3373	#39-3375	#40-3439	#40-3439	#41-3662
	#41-3662	#41-3842	#41-3844	#42-4194	#42-4198	#42-4339	#42-4341	#43-4392	#43-4396	#45-4528
	#46-4530	#46-4530	#47-4532	#48-4534	#48-4534	#48-4534	#48-4534	#49-4536	#50-4538	#51-4540
	#52-4542	#53-4544	#54-4546							
SURSU	#13-827	#16-947	16-947							
TRMTRP	#54-4546									
TYPBIN	#13-827									
TYPDEL	#13-827	#36-2877	#36-2887	#36-2894	#36-2908	#45-4528				

