

VS60

VS60 INST TST PT3
CZVSCC0

AH-9491C-MC

COPYRIGHT 76-80

FICHE 1 OF 1

JAN 1980

digital

MADE IN USA

IDENTIFICATION

B 1

SEQ 0001

PRODUCT CODE: AC-9490C-MC
PRODUCT NAME: CZVSCCO VS60 INST TST PT3
DATE: JUNE 1979
MAINTAINER: DIAGNOSTIC ENGINEERING

COPYRIGHT (C) 1976, 1979
DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.

THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DEC.

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.

0.0 TABLE OF CONTENTS

- 1.0 ABSTRACT
- 2.0 REQUIREMENTS
 - 2.1 EQUIPMENT
 - 2.2 STORAGE
- 3.0 LOADING PROCEDURE
- 4.0 STARTING PROCEDURE
 - 4.1 STARTING ADDRESS 200
 - 4.2 RESTART ADDRESS 204
- 5.0 SWITCH REGISTER SETTINGS
- 6.0 ERROR REPORTING
 - 6.1 ERROR COMMENTS
 - 6.2 ERROR DATA
- 7.0 MISCELLANEOUS
 - 7.1 VS60 BUS/VECTOR ADDRESS MODIFICATION
 - 7.2 XXDP/APT NOTES
 - 7.3 POWER FAIL
 - 7.4 SINGLE VS60 TESTING
- 8.0 EXECUTION TIME
- 9.0 PROGRAM TEST DESCRIPTIONS
 - 9.1 STACK POINTER TESTS
 - 9.2 STACK TESTS - JSR (PUSH)
 - 9.3 STACK TESTS - POP (RESTORE)
 - 9.4 STACK TESTS ON DPC BETWEEN 8K & 28K
 - 9.5 UPPER MEMORY ADDRESS TEST - ABOVE 28K
 - 9.6 DELTA LENGTH TESTS
 - 9.7 TANGENT TESTS
 - 9.8 SILO TESTS
- 10.0 LISTING

1.0 ABSTRACT

THIS PROGRAM IS ONE OF A SERIES USED TO TEST STRICTLY LOGIC FUNCTIONS OF THE VS60 DISPLAY PROCESSOR. IT IS THE PRIMARY TEST OF THE INTERNAL EIGHT LEVEL STACK AND FOUR LEVEL SILO. THERE ARE ADDITIONAL TESTS WHICH CHECK THE DELTA LENGTH AND TANGENT LOGIC ALONG WITH A MEMORY TEST CONCERNED WITH OPERATING THE VS60 ABOVE 28K OF MEMORY IF AVAILABLE.

*** REV C FIXES THE GREATER-THAN-28K TEST ***

2.0 REQUIREMENTS2.1 EQUIPMENT

- A. PDP-11 COMPUTER WITH AT LEAST 8K OF MEMORY
- B. I/O TERMINAL (I.E. ASR33 TTY)
- C. VS60 DISPLAY PROCESSOR
- D. KT11 FOR MEMORY TEST ONLY

2.2 STORAGE

THIS PROGRAM OCCUPIES LOWER 8K OF MEMORY.

3.0 LOADING PROCEDURE

NORMAL PROCEDURE FOR LOADING A BINARY PROGRAM INTO MEMORY SHOULD BE FOLLOWED.

4.0 STARTING PROCEDURE4.1 STARTING ADDRESS 200

LOADING ADDRESS 200 AND STARTING WILL IDENTIFY THE TEST, INDICATE THE MEMORY SIZE IN THE SYSTEM, INITIALIZE THE SYSTEM, AND BEGIN TESTING.

4.2 RESTART ADDRESS 204

LOADING ADDRESS 204 AND STARTING WILL INITIALIZE THE SYSTEM AND BEGIN TESTING.

5.0 SWITCH REGISTER SETTINGS

SEQ 0004

SWITCH	FUNCTION
SW15=1	HALT ON ERROR
SW14=1	LOOP ON TEST
SW13=1	INHIBIT ERROR TIMEOUTS
SW12=1	HALT AT END OF DIAGNOSTIC
SW11=1	INHIBIT ITERATIONS - NORMALLY 2000(8) AFTER 1ST PASS
SW10=1	BELL ON ERROR
SW09=1	LOOP ON ERROR
SW08=1	LOOP ON TEST IN SWR<7:0>

6.0 ERROR REPORTING

6.1 ERROR COMMENT

ALL ERRORS ARE ACCOMPANIED WITH AN ENGLISH LANGUAGE DESCRIPTIVE COMMENT AS TO THE TYPE OF FAILURE. FURTHER QUALIFICATION OF THE ERROR CAN BE OBTAINED IF NEEDED FROM THE COMMENT AT THE ERROR PC OR FROM THE ERROR TABLE (\$ERRTB:) TOWARD THE FRONT OF THE LISTING.

6.2 ERROR DATA

*PC LISTING ADDRESS WHERE THE ERROR WAS DETECTED
 *TSTNUM TEST NUMBER WHERE THE ERROR OCCURRED
 *BUSADRS DISPLAY BUS ADDRESS WHERE THE RESULTANT DATA WAS EXPECTED
 *EXPCT DATA THAT WAS EXPECTED
 *RCVD DATA THAT WAS RECEIVED
 STK SEL INDICATES STACK LEVEL WHERE FAILURE OCCURED
 GDPC INDICATES LOW ORDER 16 BIT ADDRESS EXPECTED (MEM TST ONLY)
 GDPC-HI INDICATES HIGH ORDER 2 BIT ADDRESS EXPECTED (MEM TST ONLY)
 BDPC RECEIVED LOW ORDER 16 BIT ADDRESS (MEM TST ONLY)
 BDPC-HI RECEIVED HIGH ORDER 2 BIT ADDRESS (MEM TST ONLY)
 VECTOR INDICATES VECTOR VALUE FROM WHICH DELTA LENGTH AND TANGENT ARE CALCULATED

*NOTE: THESE ARE TYPICALLY TYPED.

7.0 MISCELLANEOUS

7.1 VS60 BUS/VECTOR ADDRESS MODIFICATION:
MODIFY LOCATION '\$VECT1' IF BASE VECTOR ADDRESS IS NOT 320.
MODIFY LOCATION '\$BASE' IF BASE BUS ADDRESS IS NOT 172000.

NOTE: A RESTART IS REQUIRED AFTER THE ABOVE ADDRESS MODIFICATION.
THE ABOVE LOCATIONS ARE LOCATED IN THE 'APT MAILBOX-ETABLE'.

7.2 XXDP/APT NOTES:
THIS DIAGNOSTIC IS CHAINABLE UNDER XXDP.
THIS DIAGNOSTIC INCLUDES THE 'APT SCFTWARE HOOKS' HOWEVER, THEY
HAVE NOT BEEN TESTED.

7.3 POWER FAIL:
A POWER FAILURE WILL CAUSE A RESTART MESSAGE ON POWER UP AT
WHICH TIME THE PROGRAM IS RESTARTED AT THE BEGINNING.

7.4 SINGLE VS60 TESTING:
THIS DIAGNOSTIC DOES NOT TEST MULTIPLE VS60'S.

8.0 EXECUTION TIME

EXECUTION TIME RANGES FROM ABOUT 3 SECONDS WITH NO ITERATIONS
TO ABOUT 2 MINUTES WITH ITERATIONS ENABLED. EXECUTION TIME WILL
INCREASE AS MEMORY IS INCREASED ABOVE 8K. AN 'END PASS' MESSAGE
IS TYPED EACH PASS THRU THE DIAGNOSTIC.

9.0 PROGRAM TEST DESCRIPTIONS

9.1 STACK POINTER TESTS

STACK POINTER TESTS INCLUDE:
DECREMENT (JSR), INCREMENT (POP), STACK OVERFLOW (GREATER THAN 8 JSR'S WITHOUT A POP), STACK UNDERFLOW (GREATER THAN 8 POP'S WITHOUT A JSR), STACK OVERFLOW INTERRUPT AND STACK UNDERFLOW INTERRUPT.

9.2 STACK TESTS - JSR (PUSH)

THE STACK CONSISTS OF 8 LEVELS OF 64 BITS. EACH WRITEABLE BIT IS FORCED TO EACH STATE STARTING FROM THE 'TOP OF STACK' POSITION THRU 8 LEVELS TO THE BOTTOM OF THE STACK. FOR EXAMPLE THE TYPICAL FORMAT MIGHT BE AS FOLLOWS: 'TOP OF STACK' IS SET; AN INSTRUCTION IS SET UP AND EXECUTED WHICH SETS UP THE CONDITION UNDER TEST - FOR EXAMPLE LOAD THE VECTOR SCALE TO SOME VALUE; THEN A JSR (PUSH) INSTRUCTION IS EXECUTED - THIS WILL PUSH OR WRITE ON THE STACK THE VECTOR SCALE AT THE BITS ASSIGNED; THEN THE STACK POINTER IS SET (REG 32) TO POINT AT THE STACK LEVEL AND WORD WHERE THE VECTOR SCALE WAS STORED AND CAN BE READ FROM (REG 26); THEN IT IS CHECKED AGAINST WHAT SHOULD HAVE BEEN STORED AND IF OK THE TEST IS REPEATED AT THE NEXT STACK LEVEL.

9.3 STACK TESTS - POP (RESTORE)

THESE STACK TESTS INCLUDE EXACTLY THE SAME PROCEDURE AS 9.2 BUT INSTEAD OF THE CONDITION UNDER TEST BEING VERIFIED ON THE STACK, IT IS RESTORED VIA A POP INSTRUCTION AND VERIFIED FROM THE BUS. NOTE THAT BEFORE THE POP IS PERFORMED THE COMPLEMENT OF WHAT WAS WRITTEN ON THE STACK IS SENT TO THE FLOP/S (CONDITION) UNDER TEST. THERE ARE SEVERAL CONDITIONS (I.E. STOP INTERRUPT ENABLE, L.P. HIT DISABLE, ETC.) THAT CANNOT BE VERIFIED FROM THE BUS, IN THIS CASE AN ADDITIONAL JSR IS EXECUTED AND THE CONDITION IS CHECKED ON THE STACK.

9.4 STACK TESTS ON DPC BETWEEN 8K & 28K

THESE TWO DPC STACK TESTS ARE IDENTICAL TO THE BASIC JSR & POP DPC TESTS EXCEPT THAT THEY ARE PERFORMED AT THE HIGHEST MEMORY BOUNDARY BELOW 28K. THE INTENTION IS TO STACK PREVIOUSLY UNUSED HIGH ORDER DPC BITS. AT THE START OF THE PROGRAM A SIZER PROGRAM IS USED TO DETERMINE HIGHEST AVAILABLE MEMORY TO 28K FOR THESE TESTS. ON 8K SYSTEMS THESE TESTS ARE ABORTED.

9.5 UPPER MEMORY ADDRESS TEST - ABOVE 28K

THIS TEST REQUIRES THAT THE KT11 BE PRESENT OR THE TEST WILL BE ABORTED. THIS TEST WAS INTENDED TO EXERCISE DPC BITS 16 & 17 AT 4K MEMORY INTERVALS ABOVE 28K. THE TEST SEQUENCE FROM EACH 4K BLOCK IS A JSR, POP & LOAD STATUS B INSTRUCTION. THE GRAPH PLOT INCREMENT PORTION OF THE LOAD STATUS B INSTRUCTION CONTAINS A PAGE ADDRESS EQUAL TO ACTUAL 4K MEMORY ADDRESS ABOVE 28K BEING ADDRESSED. REFER TO TEST FOR DETAILED EXPLANATION.

9.6 DELTA LENGTH TESTS

WITH MAINTENANCE MODE SWITCH 3 SET WHEN EXECUTING A LONG VECTOR INSTRUCTION THE X POSITION REGISTER WILL CONTAIN THE DELTA LENGTH. THE DELTA LENGTH IS THE AMOUNT OF CHANGE FROM THE POINT OF ORIGIN TO THE EDGE OF THE SCREEN NOT TO EXCEED 1777. THESE TESTS WILL VERIFY THAT THE CORRECT DELTA LENGTH FROM THE POINT OF ORIGIN CAN BE CALCULATED WITH DIFFERENT VALUES OF X OR Y.

9.7 TANGENT TESTS

WITH MAINTENANCE MODE SWITCH 3 SET WHEN EXECUTING A LONG VECTOR INSTRUCTION THE Y POSITION REGISTER WILL CONTAIN THE TANGENT. THE TANGENT IS THE OPPOSITE DIVIDED BY THE ADJACENT. THESE TESTS WILL VERIFY THE TANGENT VALUE FOR DIFFERENT VALUES OF X OR Y AT A VECTOR SCALE OF UNITY.

9.8 SILO TESTS

THE SILO TESTS DETERMINE THAT EACH LEVEL OF THE SILO CAN RESTORE THE SAVED STATUS WHEN A LIGHT PEN FLAG INTERRUPT IS FORCED (USING MAINTENANCE MODE 3). THE ACTUAL TEST SEQUENCE MIGHT LOOK LIKE THIS: SET UP THE STATUS TO SOME UNIQUE VALUE, DO A GRAPHIC DISPLAY INSTRUCTION (THIS FORCES STATUS TO 1ST LEVEL OF SILO), THEN COMPLEMENT STATUS, THEN CAUSE A LIGHT PEN FLAG INTERRUPT (THIS WILL RESTORE THE STATUS FROM THE 1ST LEVEL OF THE SILO), THEN THE PROGRAM WILL VERIFY THAT THE STATUS WAS RESTORED PROPERLY. SINCE THE SILO ADDRESS POINTER IS ALWAYS RESET ON DISPLAY STARTS, THEN THE ABOVE SEQUENCE MUST BE REPEATED UP TO FOUR TIMES (FOUR LEVELS IN SILO) FOR ALL LEVELS TO BE TESTED. THE ONLY DIFFERENCE WILL BE THAT THE LIGHT PEN INTERRUPT WILL BE FORCED AFTER THE 2ND, 3RD, OR 4TH GRAPHIC INSTRUCTION DEPENDING ON THE SILO LEVEL UNDER TEST (EACH GRAPHIC INSTRUCTION LOADS THE SILO AND BUMPS THE SILO ADDRESS POINTER). AN ADDITIONAL STEP IS TAKEN IN SILO TEST #2 IN THE CASE WHERE THE SILO RESTORED STATUS CANNOT BE READ DIRECTLY FROM THE BUS (L.P. HIT DISABLE, STOP INTR ENA, ECT.). TO VERIFY THESE RESTORED CONDITIONS, A JSR IS PREFORMED WHICH SAVES THIS INFORMATION ON THE STACK WHERE IT IS ACCESSIBLE FROM THE BUS.

10.0

LISTING

1 1

SEQ 0008

PROGRAM LISTING FOLLOWS.


```
12 .TITLE CZVSC-C VS60 INSTRUCTION TEST PART III
(1) : *COPYRIGHT (C) 1976
(1) : *DIGITAL EQUIPMENT CORP.
(1) : *MAYNARD, MASS. 01754
(1) : *
(1) : *PROGRAM BY R. MOORE
(1) : *
(1) : *THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
(1) : *PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
(1) : *
13 :
14 : REV C -- FIXES TEST 107 TO OPERATE ABOVE 28K (G.P. JUNE '79).
15 :
16 : SBTTL BASIC DEFINITIONS
(1) :
(1) : *INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
(1) 001100 STACK= 1100
(1) : EQUIV EMT,ERROR ;;BASIC DEFINITION OF ERROR CALL
(1) : EQUIV IOT,SCOPE ;;BASIC DEFINITION OF SCOPE CALL
(1) :
(1) : *MISCELLANEOUS DEFINITIONS
(1) 000011 HT= 11 ;;CODE FOR HORIZONTAL TAB
(1) 000012 LF= 12 ;;CODE FOR LINE FEED
(1) 000015 CR= 15 ;;CODE FOR CARRIAGE RETURN
(1) 000200 CRLF= 200 ;;CODE FOR CARRIAGE RETURN-LINE FEED
(1) 177776 PS= 177776 ;;PROCESSOR STATUS WORD
(1) : EQUIV PS,PSW
(1) 177774 STKLMT= 177774 ;;STACK LIMIT REGISTER
(1) 177772 PIRQ= 177772 ;;PROGRAM INTERRUPT REQUEST REGISTER
(1) 177570 DSWR= 177570 ;;HARDWARE SWITCH REGISTER
(1) 177570 DDISP= 177570 ;;HARDWARE DISPLAY REGISTER
(1) :
(1) : *GENERAL PURPOSE REGISTER DEFINITIONS
(1) 000000 R0= %0 ;;GENERAL REGISTER
(1) 000001 R1= %1 ;;GENERAL REGISTER
(1) 000002 R2= %2 ;;GENERAL REGISTER
(1) 000003 R3= %3 ;;GENERAL REGISTER
(1) 000004 R4= %4 ;;GENERAL REGISTER
(1) 000005 R5= %5 ;;GENERAL REGISTER
(1) 000006 R6= %6 ;;GENERAL REGISTER
(1) 000007 R7= %7 ;;GENERAL REGISTER
(1) 000006 SP= %6 ;;STACK POINTER
(1) 000007 PC= %7 ;;PROGRAM COUNTER
(1) :
(1) : *PRIORITY LEVEL DEFINITIONS
(1) 000000 PR0= 0 ;;PRIORITY LEVEL 0
(1) 000040 PR1= 40 ;;PRIORITY LEVEL 1
(1) 000100 PR2= 100 ;;PRIORITY LEVEL 2
(1) 000140 PR3= 140 ;;PRIORITY LEVEL 3
(1) 000200 PR4= 200 ;;PRIORITY LEVEL 4
(1) 000240 PR5= 240 ;;PRIORITY LEVEL 5
(1) 000300 PR6= 300 ;;PRIORITY LEVEL 6
(1) 000340 PR7= 340 ;;PRIORITY LEVEL 7
(1) :
(1) : *'SWITCH REGISTER' SWITCH DEFINITIONS
(1) 100000 SW15= 100000
```


(1)	040000	SW14=	40000
(1)	020000	SW13=	20000
(1)	010000	SW12=	10000
(1)	004000	SW11=	4000
(1)	002000	SW10=	2000
(1)	001000	SW09=	1000
(1)	000400	SW08=	400
(1)	000200	SW07=	200
(1)	000100	SW06=	100
(1)	000040	SW05=	40
(1)	000020	SW04=	20
(1)	000010	SW03=	10
(1)	000004	SW02=	4
(1)	000002	SW01=	2
(1)	000001	SW00=	1
(1)		.EQUIV	SW09,SW9
(1)		.EQUIV	SW08,SW8
(1)		.EQUIV	SW07,SW7
(1)		.EQUIV	SW06,SW6
(1)		.EQUIV	SW05,SW5
(1)		.EQUIV	SW04,SW4
(1)		.EQUIV	SW03,SW3
(1)		.EQUIV	SW02,SW2
(1)		.EQUIV	SW01,SW1
(1)		.EQUIV	SW00,SW0

(1)		;*DATA BIT DEFINITIONS (BIT00 TO BIT15)	
(1)	100000	BIT15=	100000
(1)	040000	BIT14=	40000
(1)	020000	BIT13=	20000
(1)	010000	BIT12=	10000
(1)	004000	BIT11=	4000
(1)	002000	BIT10=	2000
(1)	001000	BIT09=	1000
(1)	000400	BIT08=	400
(1)	000200	BIT07=	200
(1)	000100	BIT06=	100
(1)	000040	BIT05=	40
(1)	000020	BIT04=	20
(1)	000010	BIT03=	10
(1)	000004	BIT02=	4
(1)	000002	BIT01=	2
(1)	000001	BIT00=	1

(1)		.EQUIV	BIT09,BIT9
(1)		.EQUIV	BIT08,BIT8
(1)		.EQUIV	BIT07,BIT7
(1)		.EQUIV	BIT06,BIT6
(1)		.EQUIV	BIT05,BIT5
(1)		.EQUIV	BIT04,BIT4
(1)		.EQUIV	BIT03,BIT3
(1)		.EQUIV	BIT02,BIT2
(1)		.EQUIV	BIT01,BIT1
(1)		.EQUIV	BIT00,BIT0

(1)		;*BASIC "CPU" TRAP VECTOR ADDRESSES	
(1)	000004	ERRVEC=	4 ;:TIME OUT AND OTHER ERRORS

(1)	000010	RESVEC= 10	::RESERVED AND ILLEGAL INSTRUCTIONS
(1)	000014	TBITVEC=14	::'T' BIT
(1)	000014	TRTVEC= 14	::TRACE TRAP
(1)	000014	BPTVEC= 14	::BREAKPOINT TRAP (BPT)
(1)	000020	IOTVEC= 20	::INPUT/OUTPUT TRAP (IOT) **SCOPE**
(1)	000024	PWRVEC= 24	::POWER FAIL
(1)	000030	EMTVEC= 30	::EMULATOR TRAP (EMT) **ERROR**
(1)	000034	TRAPVEC=34	::'TRAP' TRAP
(1)	000060	TKVEC= 60	::TTY KEYBOARD VECTOR
(1)	000064	TPVEC= 64	::TTY PRINTER VECTOR
(1)	000240	PIRQVEC=240	::PROGRAM INTERRUPT REQUEST VECTOR
17	172000	ABASE= 172000	
18	100320	AVECT1= 100320	

20
 (1)
 (1)
 (1)
 (1)
 (1)
 (1)
 (1)
 (1)
 (1)
 (1)
 (1)
 (1)
 21
 (1)
 (1) 000000
 (1)
 (1)
 (1)
 (1) 000174 000174
 (1) 000174 000000
 (1) 000176 000000
 (1)
 (1) 000200 000137 002304
 22 000204 000137 003244
 23
 24
 (1)
 (2)
 (1)
 (1) 000210
 (1) 000046 000046
 (1) 000046 024412
 (1) 000052 000052
 (1) 000052 000000
 (1) 000210
 25
 26 001000
 27
 (1)
 (2)
 (1)
 (2)
 (1) 001000
 (1) 000024 000024
 (1) 000024 000200
 (1) 000044 000044
 (1) 000044 001000
 (1) 001000
 (1) 001000 000000
 (1) 001002 001202
 (1) 001004 000012

```

.SBTTL OPERATIONAL SWITCH SETTINGS
:*
:*      SWITCH      USE
:*      -----
:*      15          HALT ON ERROR
:*      14          LOOP ON TEST
:*      13          INHIBIT ERROR TYPEOUTS
:*      12          HALT AT END OF DIAGNOSTIC
:*      11          INHIBIT ITERATIONS
:*      10          BELL ON ERROR
:*      9           LOOP ON ERROR
:*      8           LOOP ON TEST IN SWR<7:0>
.SBTTL TRAP CATCHER
.=0
:*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A "+2,HALT"
:*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
:*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
.=174
DISPREG: .WORD 0      ;;SOFTWARE DISPLAY REGISTER
SWREG:   .WORD 0      ;;SOFTWARE SWITCH REGISTER
.SBTTL STARTING ADDRESS(ES)
JMP @#START ;;JUMP TO STARTING ADDRESS OF PROGRAM
JMP RSTART  ; RESTART.

.SBTTL ACT11 HOOKS
:*****
:HOOKS REQUIRED BY ACT11
$SVPC=.      ;SAVE PC
.=46
$ENDAD      ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .$EOP
.=52
.WORD 0      ;;2)SET LOC.52 TO ZERO
.$SVPC      ;; RESTORE PC

.=1000
.SBTTL APT PARAMETER BLOCK
:*****
:SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
:*****
.$X=.      ;;SAVE CURRENT LOCATION
.=24      ;;SET POWER FAIL TO POINT TO START OF PROGRAM
200      ;;FOR APT START UP
.=44      ;;POINT TO APT INDIRECT ADDRESS PNTR.
$APTHDR    ;;POINT TO APT HEADER BLOCK
.=.$X     ;;RESET LOCATION COUNTER
:*****
:SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
:INTERFACE SPEC.
$APTHD:
$HIBTS: .WORD 0      ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
$MBADR: .WORD $MAIL  ;;ADDRESS OF APT MAILBOX (BITS 0-15)
$STMT:  .WORD 10.   ;;RUN TIM OF LONGEST TEST
  
```


(1) 001006 000036
(1) 001010 000000
(1) 001012 000031
28

\$PASTM: .WORD 30. ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
\$UNITM: .WORD 0 ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
.WORD \$ETEND-\$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)

29
 (1)
 (2)
 (1)
 (1)
 (1)
 (1)
 (1) 001100
 (1) 001100 000000
 (1) 001102 000
 (1) 001103 000
 (1) 001104 000000
 (1) 001106 000000
 (1) 001110 000000
 (1) 001112 000000
 (1) 001114 000
 (1) 001115 001
 (1) 001116 000000
 (1) 001120 000000
 (1) 001122 000000
 (1) 001124 000000
 (1) 001126 000000
 (1) 001130 000000
 (1) 001132 000000
 (1) 001134 000
 (1) 001135 000
 (1) 001136 000000
 (1) 001140 177570
 (1) 001142 177570
 (1) 001144 177560
 (1) 001146 177562
 (1) 001150 177564
 (1) 001152 177566
 (1) 001154 000
 (1) 001155 002
 (1) 001156 012
 (1) 001157 000
 (1) 001160 000000
 (1)
 (3) 001162 000000
 (3) 001164 000000
 (1) 001166 000000
 (1) 001170 000000
 (1) 001172 177607 000377
 (1) 001176 077
 (1) 001177 015
 (1) 001200 000012
 (2)
 (2)
 (2)
 (3)
 (2)
 (2) 001202
 (2) 001202 000000
 (2) 001204 000000
 (2) 001206 000000

```

.SBTTL COMMON TAGS
:*****
:*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
:*USED IN THE PROGRAM.
      .=1100
$CMTAG:                ;;START OF COMMON TAGS
      .WORD            0
$TSTNM: .BYTE          0 ;;CONTAINS THE TEST NUMBER
$ERFLG: .BYTE          0 ;;CONTAINS ERROR FLAG
$ICNT:  .WORD          0 ;;CONTAINS SUBTEST ITERATION COUNT
$LPADR: .WORD          0 ;;CONTAINS SCOPE LOOP ADDRESS
$LPERR: .WORD          0 ;;CONTAINS SCOPE RETURN FOR ERRORS
$ERTTL: .WORD          0 ;;CONTAINS TOTAL ERRORS DETECTED
$ITEMB: .BYTE          0 ;;CONTAINS ITEM CONTROL BYTE
$ERMAX: .BYTE          1 ;;CONTAINS MAX. ERRORS PER TEST
$ERRPC: .WORD          0 ;;CONTAINS PC OF LAST ERROR INSTRUCTION
$GDADR: .WORD          0 ;;CONTAINS ADDRESS OF 'GOOD' DATA
$BDADR: .WORD          0 ;;CONTAINS ADDRESS OF 'BAD' DATA
$GDDAT: .WORD          0 ;;CONTAINS 'GOOD' DATA
$BDDAT: .WORD          0 ;;CONTAINS 'BAD' DATA
      .WORD            0 ;;RESERVED--NOT TO BE USED
      .WORD            0
$AUTOB: .BYTE          0 ;;AUTOMATIC MODE INDICATOR
$INTAG: .BYTE          0 ;;INTERRUPT MODE INDICATOR
      .WORD            0
$SWR:   .WORD          DSWR ;;ADDRESS OF SWITCH REGISTER
$DISP:  .WORD          DDISP ;;ADDRESS OF DISPLAY REGISTER
$TKS:   177560         ;;TTY KBD STATUS
$TKB:   177562         ;;TTY KBD BUFFER
$TPS:   177564         ;;TTY PRINTER STATUS REG. ADDRESS
$TPB:   177566         ;;TTY PRINTER BUFFER REG. ADDRESS
$NULL:  .BYTE          0 ;;CONTAINS NULL CHARACTER FOR FILLS
$FILLS: .BYTE          2 ;;CONTAINS # OF FILLER CHARACTERS REQUIRED
$FILLC: .BYTE          12 ;;INSERT FILL CHARS. AFTER A 'LINE FEED'
$TPFLG: .BYTE          0 ;;'TERMINAL AVAILABLE' FLAG (BIT<07>=0=YES)
$REGAD: .WORD          0 ;;CONTAINS THE ADDRESS FROM
      .WORD            0 ;;WHICH ($REGO) WAS OBTAINED
$REGO:  .WORD          0 ;;CONTAINS (($REGAD)+0)
$TMPO:  .WORD          0 ;;USER DEFINED
$TIMES: 0              ;;MAX. NUMBER OF ITERATIONS
$ESCAPE:0             ;;ESCAPE ON ERROR ADDRESS
$BELL:  .ASCIZ <207><377><377> ;;CODE FOR BELL
$QUES:  .ASCII  /?/    ;;QUESTION MARK
$CRLF:  .ASCII <15>    ;;CARRIAGE RETURN
$LF:    .ASCIZ <12>    ;;LINE FEED
:*****
.SBTTL APT MAILBOX-ETABLE
:*****
.EVEN
$MAIL:                ;;APT MAILBOX
$MSGTY: .WORD         AMSGTY ;;MESSAGE TYPE CODE
$FATAL: .WORD         AFATAL  ;;FATAL ERROR NUMBER
$TESTN: .WORD         ATESTN  ;;TEST NUMBER
  
```


(2)	001210	000000	\$PASS: .WORD	APASS	::PASS COUNT
(2)	001212	000000	\$DEVCT: .WORD	ADEVCT	::DEVICE COUNT
(2)	001214	000000	\$UNIT: .WORD	AUNIT	::I/O UNIT NUMBER
(2)	001216	000000	\$MSGAD: .WORD	AMSGAD	::MESSAGE ADDRESS
(2)	001220	000000	\$MSGLG: .WORD	AMSGLG	::MESSAGE LENGTH
(2)	001222		\$ETABLE:		::APT ENVIRONMENT TABLE
(2)	001222	000	\$ENV: .BYTE	AENV	::ENVIRONMENT BYTE
(2)	001223	000	\$ENVM: .BYTE	AENVM	::ENVIRONMENT MODE BITS
(2)	001224	000000	\$SWREG: .WORD	ASWREG	::APT SWITCH REGISTER
(2)	001226	000000	\$USWR: .WORD	AUSWR	::USER SWITCHES
(2)	001230	000000	\$CPUOP: .WORD	ACPUOP	::CPU TYPE,OPTIONS
(2)			:*		BITS 15-11=CPU TYPE
(2)			:*		11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
(2)			:*		11/70=06,PDQ=07,Q=10
(2)			:*		BIT 10=REAL TIME CLOCK
(2)			:*		BIT 9=FLOATING POINT PROCESSOR
(2)			:*		BIT 8=MEMORY MANAGEMENT
(2)	001232	000	\$MAMS1: .BYTE	AMAMS1	::HIGH ADDRESS,M.S. BYTE
(2)	001233	000	\$MTYP1: .BYTE	AMTYP1	::MEM. TYPE,BLK#1
(2)			:*		MEM.TYPE BYTE -- (HIGH BYTE)
(2)			:*		900 NSEC CORE=001
(2)			:*		300 NSEC BIPOLAR=002
(2)			:*		500 NSEC MOS=003
(2)	001234	000000	\$MADR1: .WORD	AMADR1	::HIGH ADDRESS,BLK#1
(2)			:*		MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF 'TYPE' ABOVE
(2)	001236	000	\$MAMS2: .BYTE	AMAMS2	::HIGH ADDRESS,M.S. BYTE
(2)	001237	000	\$MTYP2: .BYTE	AMTYP2	::MEM. TYPE,BLK#2
(2)	001240	000000	\$MADR2: .WORD	AMADR2	::MEM.LAST ADDRESS,BLK#2
(2)	001242	000	\$MAMS3: .BYTE	AMAMS3	::HIGH ADDRESS,M.S.BYTE
(2)	001243	000	\$MTYP3: .BYTE	AMTYP3	::MEM. TYPE,BLK#3
(2)	001244	000000	\$MADR3: .WORD	AMADR3	::MEM.LAST ADDRESS,BLK#3
(2)	001246	000	\$MAMS4: .BYTE	AMAMS4	::HIGH ADDRESS,M.S.BYTE
(2)	001247	000	\$MTYP4: .BYTE	AMTYP4	::MEM. TYPE,BLK#4
(2)	001250	000000	\$MADR4: .WORD	AMADR4	::MEM.LAST ADDRESS,BLK#4
(2)	001252	100320	\$VECT1: .WORD	AVECT1	::INTERRUPT VECTOR#1,BUS PRIORITY#1
(2)	001254	000000	\$VECT2: .WORD	AVECT2	::INTERRUPT VECTOR#2BUS PRIORITY#2
(2)	001256	172000	\$BASE: .WORD	ABASE	::BASE ADDRESS OF EQUIPMENT UNDER TEST
(2)	001260	000000	\$DEVN: .WORD	ADEVN	::DEVICE MAP
(2)	001262	000000	\$CDW1: .WORD	ACDW1	::CONTROLLER DESCRIPTION WORD#1
(2)	001264		\$ETEND:		
(2)			.MEXIT		

(1) .SBTTL ERROR POINTER TABLE
(1)
(1) : *THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
(1) : *THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
(1) : *LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
(1) : *NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
(1) : *NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
(1)
(1) : * EM ::POINTS TO THE ERROR MESSAGE
(1) : * DH ::POINTS TO THE DATA HEADER
(1) : * DT ::POINTS TO THE DATA
(1) : * DF ::POINTS TO THE DATA FORMAT
(1)
(1) \$ERRTB:
(1) 001264


```

31      ;ERROR 1 - MAINT MODE 3 & L.P. FLAG FAILED TO CAUSE AN INTERRUPT
32
33      001264 027554      EM1      ;L.P. FLAG INTR FAILURE
34      001266 031763      DH1      ;ERRPC TSTNUM BUSADR EXPCT RCVD
35      001270 032310      DT1      ;$ERRPC TSTNUM $BDADR $GDDAT $BDDAT
36      001272 000000      0      ;ALL ARE OCTAL
37
38      ;ERROR 2 - SILO FAILED TO RESTORE AT BUSADRS & LEVEL INDICATED
39
40      001274 027603      EM2      ;SILO FAILURE AT LEVEL INDICATED
41      001276 032232      DH5      ;ERRPC TSTNUM BUSADR EXPCT RCVD LEVEL
42      001300 032324      DT2      ;$ERRPC TSTNUM $BDADR $GDDAT $BDDAT $TMPO
43      001302 000000      0
44
45      ;ERROR 3 - STACK POINTER FAILED TO DECREMENT PROPERLY ON JSR INSTR
46
47      001304 027643      EM3      ;STK PTR DECREMENT ERROR
48      001306 031763      DH1      ;ERRPC TSTNUM BUSADR EXPCT RCVD
49      001310 032310      DT1      ;$ERRPC TSTNUM $BDADR $GDDAT $BDDAT
50      001312 000000      0
51
52      ;ERROR 4 - STACK OVERFLOW BIT FAILED TO SET OR RESET
53
54      001314 027662      EM4      ;STACK OVERFLOW ERROR
55      001316 031763      DH1      ;ERRPC TSTNUM BUSADR EXPCT RCVD
56      001320 032310      DT1      ;$ERRPC TSTNUM $BDADR $GDDAT $BDDAT
57      001322 000000      0
58
59      ;ERROR 5 - JSR RELATIVE INSTR FAILED TO PUSH DPC ONTO STACK
60
61      001324 027704      EM5      ;DPC STACKING ERROR
62      001326 032030      DH2      ;ERRPC TSTNUM BUSADR EXPCT RCVD STK SEL
63      001330 032324      DT2      ;$ERRPC TSTNUM $BDADR $GDDAT $BDDAT $TMPO
64      001332 000000      0
    
```


116										
117										
118	001424	030160	EM15							
119	001426	032030	DH2							
120	001430	032324	DT2							
121	001432	000000	0							
122										
123										
124										
125	001434	030202	EM16							
126	001436	032030	DH2							
127	001440	032324	DT2							
128	001442	000000	0							
129										
130										
131										
132	001444	030221	EM17							
133	001446	032030	DH2							
134	001450	032324	DT2							
135	001452	000000	0							
136										
137										
138										
139	001454	030245	EM20							
140	001456	032030	DH2							
141	001460	032324	DT2							
142	001462	000000	0							
143										
144										
145										
146	001464	030274	EM21							
147	001466	032030	DH2							
148	001470	032324	DT2							
149	001472	000000	0							
150										
151										
152										
153	001474	030325	EM22							
154	001476	032030	DH2							
155	001500	032324	DT2							
156	001502	000000	0							
157										
158										
159										
160	001504	030355	EM23							
161	001506	032030	DH2							
162	001510	032324	DT2							
163	001512	000000	0							

ERROR POINTER TABLE

165										
166										
167	001514	030404	EM24							
168	001516	032030	DH2							
169	001520	032324	DT2							
170	001522	000000	0							
171										
172										
173										
174	001524	030441	EM25							
175	001526	032030	DH2							
176	001530	032324	DT2							
177	001532	000000	0							
178										
179										
180										
181	001534	030465	EM26							
182	001536	032030	DH2							
183	001540	032324	DT2							
184	001542	000000	0							
185										
186										
187										
188	001544	030511	EM27							
189	001546	032030	DH2							
190	001550	032324	DT2							
191	001552	000000	0							
192										
193										
194										
195	001554	030541	EM30							
196	001556	032030	DH2							
197	001560	032324	DT2							
198	001562	000000	0							
199										
200										
201										
202	001564	030571	EM31							
203	001566	032030	DH2							
204	001570	032324	DT2							
205	001572	000000	0							
206										
207										
208										
209										
210	001574	030624	EM32							
211	001576	032030	DH2							
212	001600	032324	DT2							
213	001602	000000	0							

215				:ERROR 33 - POP INSTR FAILED TO INCREMENT THE STACK POINTER				
216								
217	001604	030650	EM33	:STK PTR INCREMENT ER				
218	001606	031763	DH1	:ERRPC TSTNUM BUSADR EXPCT RCVD				
219	001610	032310	DT1	:\$ERRPC TSTNUM \$BDADR \$GDDAT \$BDDAT				
220	001612	000000	0					
221								
222				:ERROR 34 - STACK UNDERFLOW FAILED TO SET OR RESET				
223								
224	001614	030667	EM34	:STACK UNDERFLOW ER				
225	001616	031763	DH1	:ERRPC TSTNUM BUSADR EXPCT RCVD				
226	001620	032310	DT1	:\$ERRPC TSTNUM \$BDADR \$GDDAT \$BDDAT				
227	001622	000000	0					
228								
229				:ERROR 35 - DPC FAILED TO RESTORE ON POP INSTR				
230								
231	001624	030710	EM35	:DPC POP ER				
232	001626	031763	DH1	:ERRPC TSTNUM BUSADR EXPCT RCVD				
233	001630	032310	DT1	:\$ERRPC TSTNUM \$BDADR \$GDDAT \$BDDAT				
234	001632	000000	0					
235								
236				:ERROR 36 - NAME BITS FAILED TO RESTORE ON POP INSTR				
237								
238	001634	030723	EM36	:NAME POP ER				
239	001636	031763	DH1	:ERRPC TSTNUM BUSADR EXPCT RCVD				
240	001640	032310	DT1	:\$ERRPC TSTNUM \$BDADR \$GDDAT \$BDDAT				
241	001642	000000	0					
242								
243				:ERROR 37 - VECTOR SCALE FAILED TO RESTORE ON POP INSTR				
244								
245	001644	030737	EM37	:VECTOR SCALE POP ER				
246	001646	031763	DH1	:ERRPC TSTNUM BUSADR EXPCT RCVD				
247	001650	032310	DT1	:\$ERRPC TSTNUM \$BDADR \$GDDAT \$BDDAT				
248	001652	000000	0					
249								
250				:ERROR 40 - CHAR SCALE FAILED TO RESTORE ON POP INSTR				
251								
252	001654	030763	EM40	:CHAR SCALE POP ER				
253	001656	031763	DH1	:ERRPC TSTNUM BUSADR EXPCT RCVD				
254	001660	032310	DT1	:\$ERRPC TSTNUM \$BDADR \$GDDAT \$BDDAT				
255	001662	000000	0					
256								
257				:ERROR 41 - CHAR ROTATE FAILED TO RESTORE ON POP INSTR				
258								
259	001664	031005	EM41	:CHAR ROTATE POP ER				
260	001666	031763	DH1	:ERRPC TSTNUM BUSADR EXPCT RCVD				
261	001670	032310	DT1	:\$ERRPC TSTNUM \$BDADR \$GDDAT \$BDDAT				
262	001672	000000	0					

264										
265										
266	001674	031030	EM42							
267	001676	031763	DH1							
268	001700	032310	DT1							
269	001702	000000	0							
270										
271										
272										
273	001704	031053	EM43							
274	001706	031763	DH1							
275	001710	032310	DT1							
276	001712	000000	0							
277										
278										
279										
280	001714	031072	EM44							
281	001716	031763	DH1							
282	001720	032310	DT1							
283	001722	000000	0							
284										
285										
286										
287	001724	031106	EM45							
288	001726	031763	DH1							
289	001730	032310	DT1							
290	001732	000000	0							
291										
292										
293										
294	001734	031133	EM46							
295	001736	031763	DH1							
296	001740	032310	DT1							
297	001742	000000	0							
298										
299										
300										
301	001744	031160	EM47							
302	001746	031763	DH1							
303	001750	032310	DT1							
304	001752	000000	0							
305										
306										
307										
308	001754	031210	EM50							
309	001756	031763	DH1							
310	001760	032310	DT1							
311	001762	000000	0							


```

313 ;ERROR 51 - INTENSITY LEVEL FAILED TO RESTORE ON POP INSTR
314
315 001764 031231 EM51 ;INTENSITY LEVEL POP ER
316 001766 031763 DH1 ;ERRPC TSTNUM BUSADR EXPCT RCVD
317 001770 032310 DT1 ;$ERRPC TSTNUM $BDADR $GDDAT $BDDAT
318 001772 000000 0
319
320 ;ERROR 52 - BLINK FAILED TO RESTORE ON POP INSTR
321
322 001774 031260 EM52 ;BLINK POP ER
323 001776 031763 DH1 ;ERRPC TSTNUM BUSADR EXPCT RCVD
324 002000 032310 DT1 ;$ERRPC TSTNUM $BDADR $GDDAT $BDDAT
325 002002 000000 0
326
327 ;ERROR 53 - MODE FAILED TO RESTORE ON POP INSTR
328
329 002004 031275 EM53 ;MODE POP ER
330 002006 031763 DH1 ;ERRPC TSTNUM BUSADR EXPCT RCVD
331 002010 032310 DT1 ;$ERRPC TSTNUM $BDADR $GDDAT $BDDAT
332 002012 000000 0
333
334 ;ERROR 54 - STOP INTR ENABLED FAILED TO RESTORE ON POP INSTR
335
336 002014 031311 EM54 ;STOP INTR ENA POP ER
337 002016 031763 DH1 ;ERRPC TSTNUM BUSADR EXPCT RCVD
338 002020 032310 DT1 ;$ERRPC TSTNUM $BDADR $GDDAT $BDDAT
339 002022 000000 0
340
341 ;ERROR 55 - DEPTH QUEING OR DEPTH QUE CONTROL FAILED TO RESTORE ON POP INSTR
342
343 002024 031336 EM55 ;DEPTH QUE POP ER
344 002026 031763 DH1 ;ERRPC TSTNUM BUSADR EXPCT RCVD
345 002030 032310 DT1 ;$ERRPC TSTNUM $BDADR $GDDAT $BDDAT
346 002032 000000 0
347
348 ;ERROR 56 - EDGE INTR ENABLED FAILED TO RESTORE ON POP INSTR
349
350 002034 031357 EM56 ;EDGE INTR ENA POP ER
351 002036 031763 DH1 ;ERRPC TSTNUM BUSADR EXPCT RCVD
352 002040 032310 DT1 ;$ERRPC TSTNUM $BDADR $GDDAT $BDDAT
353 002042 000000 0
354
355 ;ERROR 57 - CHAR STRING ESCAPE FAILED TO RESTORE ON POP INSTR
356
357 002044 031404 EM57 ;CHAR STRING ESC POP ER
358 002046 031763 DH1 ;ERRPC TSTNUM BUSADR EXPCT RCVD
359 002050 032310 DT1 ;$ERRPC TSTNUM $BDADR $GDDAT $BDDAT
360 002052 000000 0
  
```


362			:ERROR 60 - L.P. HIT DISABLE FAILED TO RESTORE ON POP INSTR				
363			EM60	:L.P. HIT DISABLE POP ER			
364	002054	031433	DH1	:ERRPC	TSTNUM	BUSADR	EXPCT RCVD
365	002056	031763	DT1	:\$ERRPC	TSTNUM	\$BDADR \$GDDAT	\$BDDAT
366	002060	032310	0				
367	002062	000000					
368			:ERROR 61 - SHIFT OUT FAILED TO RESTORED ON POP INSTR				
369			EM61	:SHIFT OUT ER			
370			DH1	:ERRPC	TSTNUM	BUSADR	EXPCT RCVD
371	002064	031463	DT1	:\$ERRPC	TSTNUM	\$BDADR \$GDDAT	\$BDDAT
372	002066	031763	0				
373	002070	032310					
374	002072	000000					
375			:ERROR 62 - TERMINATE CHARACTER FAILED TO POP THE STACK				
376			EM62	:TERMINATE CHAR POP ER			
377			DH1	:ERRPC	TSTNUM	BUSADR	EXPCT RCVD
378	002074	031504	DT1	:\$ERRPC	TSTNUM	\$BDADR \$GDDAT	\$BDDAT
379	002076	031763	0				
380	002100	032310					
381	002102	000000					
382			:ERROR 63 - STACK OVERFLOW FAILED ON INTERRUPT				
383			EM63	:STK OVFLD INT ER			
384			DH1	:ERRPC	TSTNUM	BUSADR	EXPCT RCVD
385	002104	031532	DT1	:\$ERRPC	TSTNUM	\$BDADR \$GDDAT	\$BDDAT
386	002106	031763	0				
387	002110	032310					
388	002112	000000					
389			:ERROR 64 - STACK UNDERFLOW FAILED ON INTERRUPT				
390			EM64	:STK UNFLO INT ER			
391			DH1	:ERRPC	TSTNUM	BUSADR	EXPCT RCVD
392	002114	031553	DT1	:\$ERRPC	TSTNUM	\$BDADR \$GDDAT	\$BDDAT
393	002116	031763	0				
394	002120	032310					
395	002122	000000					
396			:ERROR 65 - INCORRECT DELTA LENGTH FOR X OR Y VECTOR INDICATED				
397			EM65	:DELTA LENGTH ER			
398			DH4	:ERRPC	TSTNUM	VECTOR	EXPCT RCVD
399	002124	031574	DT4	:\$ERRPC	TSTNUM	\$TMPO \$GDDAT	\$BDDAT
400	002126	032165	0				
401	002130	032360					
402	002132	000000					
403			:ERROR 66 - TANGENT ERROR FOR X OR Y VECTOR INDICATED				
404			EM66	:TANGENT ER			
405			DH4	:ERRPC	TSTNUM	VECTOR	EXPCT RCVD
406	002134	031614	DT4	:\$ERRPC	TSTNUM	\$TMPO \$GDDAT	\$BDDAT
407	002136	032165	0				
408	002140	032360					
409	002142	000000					

411										
412										
413	002144	031627	EM67							
414	002146	031763	DH1							
415	002150	032310	DT1							
416	002152	000000	0							
417										
418										
419										
420	002154	031644	EM70							
421	002156	032110	DH3							
422	002160	032342	DT3							
423	002162	000000	0							
424										
425										
426										
427	002164	031672	EM71							
428	002166	031763	DH1							
429	002170	032310	DT1							
430	002172	000000	0							
431										
432										
433										
434	002174	031722	EM72							
435	002176	031763	DH1							
436	002200	032310	DT1							
437	002202	000000	0							

```

:ERROR 67 - DPC HIGH ORDER BIT 16 & 17 FAILED TO SET OR RESET
      :DPC 16-17 ER
      :ERRPC TSTNUM BUSADR EXPCT RCVD
      :$ERRPC TSTNUM $BDADR $GDDAT $BDDAT

:ERROR 70 - VS60 ADDRESS FAILURE ABOVE 28K
      :ADRS ER
      :ERRPC TSTNUM GD-1716 GD-DPC BD-1716 BD-DPC
      :$ERRPC TSTNUM G1716 $GDDAT B1716 $BDDAT

:ERROR 71 - STOP FLAG FAILED TO SET WHEN VS60 OPERATING AT FULL SPEED
      :STOP FLAG FAILED TO SET
      :ERRPC TSTNUM BUSADR EXPCT RCVD
      :$ERRPC TSTNUM $BDADR $GDDAT $BDDAT

:ERROR 72 - START FAILED TO CLR STACK BITS & SET 'TOP OF STACK'
      :START FAILED TO SET 'TOP OF STK'
      :ERRPC TSTNUM BUSADR EXPCT RCVD
      :$ERRPC TSTNUM $BDADR $GDDAT $BDDAT
  
```



```

439                                     ;MORE PROGRAM DEFINITIONS
440
441         000000      OPEN= 0           ;LOCATION WILL LATER BE REWRITTEN
442         010000      MAINT1= 10000    ;SINGLE STEP MAINTENANCE BIT - NO NPR ALLOWED
443         020000      MAINT2= 20000    ;SINGLE CYCLE MAINTENANCE BIT - ONE NPR ALLOWED
444
445         000250      KTERRV= 250       ;KT TRAP ADRS
446         177572      KTSRO= 177572    ;KT STATUS REG
447
448                                     ;MORE PROGRAM TAGS
449
450 002204 000000      TSTNUM: OPEN      ;CONTAINS TEST NO OF TEST WITH ERROR
451 002206 000000      DLYCNT: OPEN      ;COUNTER USED BY DELAY ROUTINE
452 002210 000000      LDRSV1: OPEN     ;LOCATION SAVES DATA OF LOC USED IN MEM TEST
453 002212 000000      LDRSV2: OPEN     ;DITTO
454 002214 000000      MEMMAX: OPEN     ;CONTAINS STARTING ADRS OF HIGHEST 4K
455 002216 000000      CENAB: OPEN     ;NON ZERO ENABLES THE DPC MEM TEST
456 002220 000000      KTENAB: OPEN     ;NON ZERO ENABLES THE ABOVE 28K DPC MEM TEST
457 002222 000000      KTMAX: OPEN     ;CONTAINS LAST 4K PAGE ADRS AVAILABLE ABOVE 28K
458 002224 000000      G1716: OPEN     ;CONTAINS EXPECTED ADRS BITS 17 & 16
459 002226 000000      B1716: OPEN     ;CONTAINS ACTUAL ADRS BITS 17 & 16
460
461                                     ;KT11 PAGE ADDRESS REGS & PAGE DESCRIPTOR REGS ADDRESSES
462
463 002230 172340      KIPAR0: 172340    ;PAR 0
464 002232 172300      KIPDR0: 172300    ;PDR 0
465 002234 172344      KIPAR2: 172344    ;PAR 2
466 002236 172304      KIPDR2: 172304    ;PDR 2
467 002240 172356      KIPAR7: 172356    ;PAR 7
468 002242 172316      KIPDR7: 172316    ;PDR 7
469
470                                     ;VS60 REGISTER ADDRESS POINTERS
471
472 002244 000000      DPC: OPEN         ;DISPLAY PROCESSOR PC
473 002246 000000      SREG0: OPEN      ;STATUS REG 1
474 002250 000000      XPOS: OPEN      ;X POSITION & GRAPHPLOT INC REG
475 002252 000000      YPOS: OPEN      ;Y POSITION & CHAR REG
476 002254 000000      RLO: OPEN       ;RELOCATE REG
477 002256 000000      SREG1: OPEN      ;STATUS REG 2
478 002260 000000      XDOFF: OPEN     ;X DYNAMIC OFFSET REG
479 002262 000000      YDOFF: OPEN     ;Y DYNAMIC OFFSET REG
480 002264 000000      ANAME: OPEN     ;ASSOCIATE NAME REG
481 002266 000000      CONS: OPEN      ;CONSOLE INDICATORS & COLOR LEVEL
482 002270 000000      DNAME: OPEN     ;DPU NAME REG
483 002272 000000      STKVAL: OPEN    ;STACK READ REG
484 002274 000000      TERMCH: OPEN   ;TERMINATE CHAR REG
485 002276 000000      STKPT: OPEN    ;MAINTENANCE & STK PTR
486 002300 000000      ZPOS: OPEN     ;Z POSOITION REG
487 002302 000000      ZDOFF: OPEN    ;Z DYNAMIC OFFSET REG
  
```



```

489 ;SOFTWARE INITIALIZATION ROUTINE
490
492 002304 START:
(1) .SBTTL INITIALIZE THE COMMON TAGS
(1) ;;CLEAR THE COMMON TAGS ($CMTAG) AREA
(1) 002304 012706 001100 MOV #CMTAG,R6 ;;FIRST LOCATION TO BE CLEARED
(1) 002310 005026 CLR (R6)+ ;;CLEAR MEMORY LOCATION
(1) 002312 022706 001140 CMP #SWR,R6 ;;DONE?
(1) 002316 001374 BNE -6 ;;LOOP BACK IF NO
(1) 002320 012706 001100 MOV #STACK,SP ;;SETUP THE STACK POINTER
(1) ;;INITIALIZE A FEW VECTORS
(1) 002324 012737 025116 000020 MOV #SCOPE,@IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE
(1) 002332 012737 000340 000022 MOV #340,@IOTVEC+2 ;;LEVEL 7
(1) 002340 012737 025642 000030 MOV #ERROR,@EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
(1) 002346 012737 000340 000032 MOV #340,@EMTVEC+2 ;;LEVEL 7
(1) 002354 012737 027134 000034 MOV #STRAP,@TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
(1) 002362 012737 000340 000036 MOV #340,@TRAPVEC+2 ;;LEVEL 7
(1) 002370 012737 027204 000024 MOV #SPWRDN,@PWRVEC ;;POWER FAILURE VECTOR
(1) 002376 012737 000340 000026 MOV #340,@PWRVEC+2 ;;LEVEL 7
(1) 002404 013737 024360 024352 MOV SENDCT,$EOPCT ;;SETUP END-OF-PROGRAM COUNTER
(1) 002412 005037 001166 CLR $TIMES ;;INITIALIZE NUMBER OF ITERATIONS
(1) 002416 005037 001170 CLR $ESCAPE ;;CLEAR THE ESCAPE ON ERROR ADDRESS
(1) 002422 112737 000001 001115 MOV #1,$ERMAX ;;ALLOW ONE ERROR PER TEST
(1) 002430 012737 002430 001106 MOV #,$SLPADR ;;INITIALIZE THE LOOP ADDRESS FOR SCOPE
(1) 002436 012737 002436 001110 MOV #,$SLPERR ;;SETUP THE ERROR LOOP ADDRESS
(2) ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
(2) ;;EQUAL TO A '-1', SETUP FOR A SOFTWARE SWITCH REGISTER.
(2) 002444 013746 000004 MOV @ERRVEC,-(SP) ;;SAVE ERROR VECTOR
(2) 002450 012737 002504 000004 MOV #64,$@ERRVEC ;;SET UP ERROR VECTOR
(2) 002456 012737 177570 001140 MOV #DSWR,SWR ;;SETUP FOR A HARDWARE SWICH REGISTER
(2) 002464 012737 177570 001142 MOV #DDISP,DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
(2) 002472 022777 177777 176440 CMP #-1,@SWR ;;TRY TO REFERENCE HARDWARE SWR
(2) 002500 001012 BNE 66$ ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
(2) ;;AND THE HARDWARE SWR IS NOT = -1
(2) 002502 000403 BR 65$ ;;BRANCH IF NO TIMEOUT
(2) 002504 012716 002512 64$: MOV #65$,(SP) ;;SET UP FOR TRAP RETURN
(2) 002510 000002 RTI
(2) 002512 012737 000176 001140 65$: MOV #SWREG,SWR ;;POINT TO SOFTWARE SWR
(2) 002520 012737 000174 001142 MOV #DISPREG,DISPLAY
(2) 002526 012637 000004 66$: MOV (SP)+,@ERRVEC ;;RESTORE ERROR VECTOR
(1)
(2) 002532 005037 001210 CLR $PASS ;;CLEAR PASS COUNT
(2) 002536 132737 000200 001223 BITB #APTSIZE,$ENVM ;;TEST USER SIZE UNDER APT
(2) 002544 001403 BEQ 67$ ;;YES,USE NON-APT SWITCH
(2) 002546 012737 001224 001140 MOV #SWREG,SWR ;;NO,USE APT SWITCH REGISTER
(2) 002554 67$:
493 002554 005737 000042 TST @#42 ;;TEST IF RUNNING CHAIN MODE UNDER XXDP
494 002560 001002 BNE START1 ;;BR IF SO
495 002562 104401 027423 TYPE ,MSG1 ;;GO IDENTIFY TEST
496 002566 013700 001256 START1: MOV $BASE,R0 ;;GET 1ST VS60 BUS ADRS
497 002572 012701 002244 MOV #DPC,R1 ;;INITIALIZE VS60 REG POINTER
498 002576 010011 SETPTR: MOV R0,(R1) ;;SET UP THIS ADRS POINTER
499 002600 062700 000002 ADD #2,R0 ;;ADVANCE TO NEXT REG ADRS
500 002604 062701 000002 ADD #2,R1 ;;MOVE POINTER TO NEXT REG ADRS
501 002610 020127 002304 CMP R1,#DPC+40 ;;HAVE WE DONE ALL REG POINTERS?
502 002614 001370 BNE SETPTR ;;BR IF NOT

```



```

503 002616 005037 002216          CSIZR: CLR      CENAB      ;TURN OFF DPC MEM TEST
504 002622 005037 002220          CLR      KTENAB     ;TURN OFF KT UPPER MEM TEST
505 002626 012737 002666 000004  MOV      #2$,@#ERRVEC ;SET UP MEM TIMEOUT SERVICE ADRS
506 002634 012700 040000          MOV      #40000,R0  ;START MEM SIZER GREATER THAN 8K
507 002640 010001          1$: MOV      R0,R1    ;DO ACTUAL TESTING IN R1
508 002642 005721          TST      (R1)+      ;CHECK EVEN ADRS
509 002644 005711          TST      (R1)       ;CHECK ODD ADRS
510 002646 062700 020000          ADD      #20000,R0  ;BUMP IT BY 4K
511 002652 022700 160000          CMP      #160000,R0 ;ARE WE TO I/O PAGE?
512 002656 001370          BNE      1$        ;BR IF NOT
513 002660 005237 002220          INC      KTENAB     ;'KTENAB' NON-ZERO MEANS KT11 SIZER REQ
514 002664 000401          BR       3$        ;GO SAVE 28K MEM LIMIT
515 002666 022626          2$: CMP      (R6)+,(R6)+ ;FIX STACK SINCE NO RTI ON MEM TIMEOUT
516 002670 012737 000006 000004  3$: MOV      #ERRVEC+2,@#ERRVEC ;RESTORE LOC 4 & 6
517 002676 162700 020000          SUB      #20000,R0  ;BACK UP TO LAST 4K MEM BLK
518 002702 010037 002214          MOV      R0,MEMMAX  ;SAVE HIGHEST NON-KT MEM ADRS
519 002706 020027 020000          CMP      R0,#20000  ;IS THERE MORE THAN 8K?
520 002712 101002          BHI      4$        ;BR IF SO
521 002714 000137 003202          JMP      TYPCOR     ;GO TYPE CORE AMT - NOTHING OVER 8K
522 002720 005237 002216          4$: INC      CENAB     ;NON-ZERO REQ DPC MEM TEST
523 002724 005737 002220          TST      KTENAB     ;DO WE NEED TO DO KT MEM SIZER?
524 002730 001002          BNE      KTSIZR    ;BR IF SO
525 002732 000137 003202          JMP      TYPCOR     ;GO TYPE CORE AMT - LESS THAN 28K
526 002736 012737 024630 000250  KTSIZR: MOV      #KTSER,@#KTERRV ;GET UP KT11 TRAP SERVICE ADRS
527 002744 012737 003022 000004  MOV      #2$,@#ERRVEC ;RETURN TO 2$ ON KT TIMOUT
528 002752 005737 177572          TST      @#KTSRO    ;LOOK FOR STATUS REG
529 002756 005077 177246          1$: CLR      @KIPAR0  ;SET UP FOR TRAPS TO PAGE 0
530 002762 012777 077406 177242  MOV      #77406,@KIPDR0 ;4K PAGE LENGTH, EXPAND UP, R/W ACCESS
531 002770 012777 001600 177236  MOV      #1600,@KIPAR2  ;START AT 28K
532 002776 012777 077406 177232  MOV      #77406,@KIPDR2 ;4K PAGE LENGTH, EXPAND UP, R/W ACCESS
533 003004 012777 007600 177226  MOV      #7600,@KIPAR7  ;SET UP I/O 4K PAGE ADRS
534 003012 012777 077406 177222  MOV      #77406,@KIPDR7 ;4K PAGE LENGTH, EXPAND UP, R/W ACCESS
535 003020 000410          BR       3$        ;SKIP OVER TIMEOUT STUFF
536 003022 022626          2$: CMP      (R6)+,(R6)+ ;FIX STACK SINCE NO RTI
537 003024 005037 002220          CLR      KTENAB     ;THERE IS NO KT11
538 003030 012737 000006 000004  MOV      #ERRVEC+2,@#ERRVEC ;RESTORE 4 & 6
539 003036 000137 003202          JMP      TYPCOR     ;GO TYPE CORE AMT - KT NOT THERE
540 003042 012737 003114 000004  3$: MOV      #5$,@#ERRVEC ;SET UP NON-EXISTENT MEM TIMEOUT ADRS
541 003050 012700 040000          4$: MOV      #40000,R0  ;START WITH ADRS 0 AT PAGE ADRS IN KIPAR2
542 003054 052737 001400 177572  BIS      #1400,@#KTSRO ;ENAB KT (MAINT)
543 003062 005720          TST      (R0)+      ;IS THIS BLK THERE?
544 003064 005720          TST      (R0)+      ;CK INTERLEAVING ALSO
545 003066 042737 001400 177572  BIC      #1400,@#KTSRO ;DISABLE KT
546 003074 062777 000200 177132  ADD      #200,@KIPAR2 ;ADVANCE TO NEXT 4K BLK
547 003102 027777 177126 177130  CMP      @KIPAR2,@KIPAR7 ;ARE WE OUT TO 128K?
548 003110 001357          BNE      4$        ;BR IF NOT
549 003112 000403          BR       6$        ;GO SET UP KTMAX
550 003114 005037 177572          5$: CLR      @#KTSRO    ;DISABLE KT
551 003120 022626          CMP      (R6)+,(R6)+ ;FIX STACK SINCE NO RTI
552 003122 012737 000006 000004  6$: MOV      #ERRVEC+2,@#ERRVEC ;RESTORE ERRVEC
553 003130 162777 000200 177076  SUB      #200,@KIPAR2 ;BACK UP TO LAST AVAILABLE BLK
554 003136 017737 177072 002222  MOV      @KIPAR2,KTMAX ;SAVE IT
555 003144 023727 002222 001600  CMP      KTMAX,#1600  ;ARE WE OVER 28K?
556 003152 103004          BHIS    7$        ;BR IF SO
557 003154 005037 002220          CLR      KTENAB     ;DON'T USE KT
558 003160 000137 003202          JMP      TYPCOR     ;KT THERE BUT NOTHING OVER 28K?
    
```



```

559 003164 013700 002222      7$:      MOV      KTMAX,R0      ;GET MAX PAGE ADRS VALUE
560 003170 006300              ASL      R0          ;JUSTIFY RIGHT FOR TYPE
561 003172 000300              SWAB     R0          ;
562 003174 006300              ASL      R0          ;
563 003176 006300              ASL      R0          ;
564 003200 000406              BR       TYPMEM     ;GO TYPE IT
565 003202 013700 002214      TYPCOR: MOV      MEMMAX,R0 ;GET TOP 4K BLK NO BELOW 28K
566 003206 000300              SWAB     R0          ;SET IT UP FOR TYPE
567 003210 006200              ASR      R0          ;ADJUST FOR TYPE
568 003212 006200              ASR      R0          ;
569 003214 006200              ASR      R0          ;
570 003216 062700 000004      TYPMEM: ADD      #4,R0   ;POINT TO LAST ADRS
571 003222 005737 000042      TST      @#42       ;TEST IF RUNNING CHAIN MODE UNDER XXDP
572 003226 001006              BNE     RSTART     ;BR IF SO
573 003230 104401 027530      TYPE     ,MSG3     ;GO TYPE 'MEMORY SIZE='
574 003234 010046              MOV      R0,-(SP)  ;SAVE IT ON STK FOR DECIMAL TYPE
575 003236 104405              TYPDS   ,MSG4     ;GO TYPE IT
576 003240 104401 027550      TYPE     ,MSG4     ;TYPE 'K'
577 003244 000005      RSTART: RESET    ;INITIALIZE THE VS60
578 003246 012706 001100      MOV      #STACK,SP ;SET UP STACK POINTER
579 003252 012737 000340 177776  MOV      #340,PSW  ;SET UP PSW TO HIGHEST LEVEL
580 003260 105037 001102      CLRB    $TSTNM    ;CLR TEST NO. ON RESTARTS
    
```


582
583
584
585
586
(3)
(3)
(2) 003264 000004
(2) 003266 012737 000001 001206
587 003274 012737 003330 001110
588 003302 013737 002276 001122
589 003310 012700 020040
590 003314 012737 000034 001124
591 003322 012737 163000 032374
592 003330 010077 176742
593 003334 012777 032374 176702
594 003342 004537 024446
595 003346 000001
596 003350 017737 176722 001126
597 003356 042737 177703 001126
598 003364 023737 001124 001126
599 003372 001401
600 003374 104003
601 003376 162700 000004
602 003402 162737 000004 001124
603 003410 001347
604
605
(3)
(3)
(2) 003412 000004
(2) 003414 012737 000002 001206
606 003422 012737 000340 177776
607 003430 013737 002256 001122
608 003436 012777 020040 176632
609 003444 005037 001124
610 003450 012700 000011
611 003454 012737 163000 032374
612 003462 012777 032374 176554
613 003470 004537 024446
614 003474 000001
615 003476 005300
616 003500 001410
617 003502 032777 020000 176546
618 003510 001764
619 003512 012737 020000 001126
620 003520 104004
621 003522 032777 020000 176526
622 003530 001006
623 003532 012737 020000 001124
624 003540 005037 001126
625 003544 104004
626
627
(3)
(3)

```
.SBTTL
.SBTTL THESE TESTS USE MAINT. SW 2
.SBTTL

:*****
:*TEST 1 TEST THAT THE JSR REL INSTR WILL DECREMENT THE STACK POINTER
:*****
TST1: SCOPE
MOV #1,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
MOV #1$, $LPERR ;;SET UP SCOPE LOOP ADRS
MOV STKPT,$BDADR ;;SET UP REG 32 ADRS
MOV #20040,R0 ;;SET TOP OF STACK & MAINT SW2 IN R0
MOV #34,$GDDAT ;;WILL EXPECT PTR TO BE 34 INITIALLY
MOV #163000,BUFFER ;;SET UP JSR INSTR
1$: MOV R0,@STKPT ;;SET UP STACK PTR
MOV #BUFFER,@DPC ;;START
JSR R5,DELAY ;;STALL FOR STACKING
BIT0 ;;COUNT TO 1
MOV @STKPT,$BDDAT ;;READ STACK POINTER
BIC #177703,$BDDAT ;;ONLY WANT STACK POINTER - TOP OF STK SB 0
CMP $GDDAT,$BDDAT ;;IS IT CORRECT?
BEQ 2$ ;;BR IF OK
ERROR 3 ;;JSR REL INSTR FAILED TO DECREMENT STACK PTR
2$: SUB #4,R0 ;;SET UP NEXT STK PTR VALUE IN R0
SUB #4,$GDDAT ;;ADVANCE TO NEXT EXPECTED PTR VALUE
BNE 1$ ;;BR IF THIS VALUE NOT TESTED YET

:*****
:*TEST 2 TEST THAT THE STACK OVERFLOW BIT CAN SET
:*****
TST2: SCOPE
MOV #2,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
MOV #340,$PSW ;;SET PRIORITY TO HIGHEST LEVEL
MOV SREG1,$BDADR ;;SET UP REG 12 ADRS
MOV #20040,@STKPT ;;RESET THE STACK PTR
CLR $GDDAT ;;EXPECT NO OVERFLOW FOR 8 JSR'S
MOV #11,R0 ;;SET UP COUNT FOR 9 JSR'S
MOV #163000,BUFFER ;;SET UP JSR INSTR
1$: MOV #BUFFER,@DPC ;;START
JSR R5,DELAY ;;STALL FOR STACKING
BIT0 ;;COUNT TO 1
DEC R0 ;;COUNT STACKING OPERATION
BEQ 2$ ;;BR IF THIS IS OVERFLOW
BIT #20000,@SREG1 ;;SEE THAT OVERFLOW IS NOT SET
BEQ 1$ ;;BR IF OVERFLOW NOT SET
MOV #20000,$BDDAT ;;INDICATE STACK OVERFLOW
ERROR 4 ;;STACK OVERFLOW SET PREMATURELY
2$: BIT #20000,@SREG1 ;;IS STACK OVERFLOW SET?
BNE TST3 ;;ADVANCE TO NEXT TEST IF OK
MOV #20000,$GDDAT ;;EXPECTED STACK OVERFLOW
CLR $BDDAT ;;INDICATE IT WAS NOT SET
ERROR 4 ;;STACK OVERFLOW FAILED TO SET

:*****
:*TEST 3 TEST THAT START WILL SET 'TOP OF STACK'
:*****
```



```

(2) 003546 000004 TST3: SCOPE
(2) 003550 012737 000003 001206 MOV #3,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
628 003556 013737 002276 001122 MOV STKPTR,$BDADR ;;SET UP REG 32 ADRS
629 003564 012737 000040 001124 MOV #40,$GDDAT ;;EXPECT TOP OF STACK
630 003572 012777 010037 176476 MOV #10037,@STKPTR ;;SET ALL STACK BITS & MAINT 1
631 003600 005077 176440 CLR @DPC ;;START - NO NPR
632 003604 017737 176466 001126 MOV @STKPTR,$BDDAT ;;READ STK PTR REG
633 003612 042737 177701 001126 BIC #177701,$BDDAT ;;SAVE ONLY STK PTR BITS
634 003620 023737 001124 001126 CMP $GDDAT,$BDDAT ;;DID START SET 'TOP OF STACK'?
635 003626 001401 BEQ TST4 ;;NEXT TEST IF SO
636 003630 104072 ERROR 72 ;;START FAILED TO SET 'TOP OF STACK'
637
638
(3)
(3)
(2) 003632 000004 TST4: SCOPE
(2) 003634 012737 000004 001206 MOV #4,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
639 003642 013737 002272 001122 MOV STKVAL,$BDADR ;;SET UP REG 26 ADRS
640 003650 012737 163000 032374 MOV #163000,BUFFER ;;SET UP JSR RELATIVE INSTR
641 003656 012700 000034 MOV #34,R0 ;;SET UP STK SEL AFTER JSR IN R0
642 003662 012701 020040 MOV #20040,R1 ;;SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
643 003666 012737 032376 001124 MOV #BUFFER+2,$GDDAT ;;EXPECT ADRS BUFFER+2 ON STACK
644 003674 012737 003702 001110 MOV #1$,$LPERR ;;SET UP SCOPE LOOP ADRS
645 003702 010177 176370 1$: MOV R1,@STKPTR ;;SET STK PTR BEFORE JSR
646 003706 012777 032374 176330 MOV #BUFFER,@DPC ;;START
647 003714 004537 024446 JSR R5,DELAY ;;STALL FOR STACKING
648 003720 000001 BIT0 ;;COUNT TO 1
649 003722 010077 176350 MOV R0,@STKPTR ;;SELECT STK WORD & BYTE
650 003726 017737 176340 001126 MOV @STKVAL,$BDDAT ;;READ STACK BYTE
651 003734 042737 000001 001126 BIC #BIT0,$BDDAT ;;DON'T WANT LSB
652 003742 023737 001124 001126 CMP $GDDAT,$BDDAT ;;DID THE DPC GET STORED OK?
653 003750 001403 BEQ 2$ ;;BR IF OK
654 003752 010037 001164 MOV R0,$TMP0 ;;SET UP STK LEVEL FOR ER TYPE
655 003756 104005 ERROR 5 ;;DPC FAILED TO STACK AT LEVEL INDICATED
656 003760 162701 000004 2$: SUB #4,R1 ;;ADVANCE TO NEXT STK LEVEL
657 003764 162700 000004 SUB #4,R0 ;;ALL STACK LOCATIONS TESTED?
658 003770 100344 BPL 1$ ;;BR IF NOT
659
660
(3)
(3)
(2) 003772 000004 TST5: SCOPE
(2) 003774 012737 000005 001206 MOV #5,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
661 004002 013737 002272 001122 MOV STKVAL,$BDADR ;;SET UP REG 26 ADRS
662 004010 012737 162000 032374 MOV #162000,BUFFER ;;SET UP JSR ABS INSTR
663 004016 012737 032400 001124 MOV #BUFFER+4,$GDDAT ;;EXPC T ADRS BUFFER+4 ON STACK
664 004024 012701 020040 MOV #20040,R1 ;;SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
665 004030 012700 000034 MOV #34,R0 ;;SET UP STACK SEL AFTER JSR IN R0
666 004034 012737 004042 001110 MOV #1$,$LPERR ;;SET UP SCOPE LOOP ADRS
667 004042 010177 176230 1$: MOV R1,@STKPTR ;;SET UP STACK PTR BEFORE JSR
668 004046 012777 032374 176170 MOV #BUFFER,@DPC ;;START
669 004054 004537 024446 JSR R5,DELAY ;;STALL FOR STACKING
670 004060 000001 BIT0 ;;COUNT TO 1
671 004062 005277 176156 INC @DPC ;;ADVANCE TO ABS ADRS
672 004066 004537 024446 JSR R5,DELAY ;;STALL FOR STACKING
673 004072 000001 BIT0 ;;COUNT TO 1
    
```



```

674 004074 010077 176176      MOV      R0,@STKPT      ;SELECT STK WORD & BYTE
675 004100 017737 176166 001126  MOV      @STKVAL,$BDDAT ;READ STACK BYTE
676 004106 042737 000001 001126  BIC      #BIT0,$BDDAT   ;DON'T WANT LSB
677 004114 023737 001124 001126  CMP      $GDDAT,$BDDAT ;DID DPC GET STORED OK?
678 004122 001403      BEQ      2$             ;BR IF OK
679 004124 010037 001164      MOV      R0,$TMP0      ;SET UP STK LEVEL FOR ER TYPE
680 004130 104005      ERROR   5              ;DPC FAILED TO STACK AT LEVEL INDICATED
681 004132 162701 000004 2$:     SUB      #4,R1          ;ADVANCE TO NEXT STK LEVEL
682 004136 162700 000004      SUB      #4,R0          ;ALL STACK LOCATIONS TESTED?
683 004142 100337      BPL      1$             ;BR IF NOT
    
```

```

(3)
(3)
(2) 004144 000004
(1) 004146 012737 000004 001166
(2) 004154 012737 000006 001206
687 004162 012737 153777 032374
688 004170 012737 163000 032376
689 004176 012737 077760 001124
690 004204 012737 004222 001110
691 004212 012701 020040 1$:     MOV      #20040,R1      ;SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
692 004216 012700 000035      MOV      #35,R0        ;SET STACK SELECTION AFTER JSR IN R0
693 004222 010177 176050 2$:     MOV      R1,@STKPT     ;SET STK PTR BEFORE JSR
694 004226 012777 032374 176010  MOV      #BUFFER,@DPC  ;START
695 004234 013737 002272 001122  MOV      STKVAL,$BDADR ;SET UP REG ADRS 26
696 004242 005277 175776      INC      @DPC          ;DO NEXT INSTR
697 004246 004537 024446      JSR      R5,DELAY      ;ALLOW TIME FOR STACKING
698 004252 000001      BIT0     ;COUNT TO 1
699 004254 010077 176016      MOV      R0,@STKPT     ;SELECT STK WORD & BYTE
700 004260 017737 176006 001126  MOV      @STKVAL,$BDDAT ;READ STACK BYTE
701 004266 042737 100017 001126  BIC      #100017,$BDDAT ;ONLY WANT NAME BITS
702 004274 023737 001124 001126  CMP      $GDDAT,$BDDAT ;DID THE NAME BITS GET STORED OK?
703 004302 001403      BEQ      3$             ;BR IF OK
704 004304 010037 001164      MOV      R0,$TMP0      ;SET UP STK LEVEL FOR ER TYPE
705 004310 104006      ERROR   6              ;DPC NAME FAILED TO STACK AT LEVEL INDICATED
706 004312 162701 000004 3$:     SUB      #4,R1          ;ADVANCE TO NEXT STK LEVEL
707 004316 162700 000004      SUB      #4,R0          ;ALL STACK LOCATIONS TESTED?
708 004322 100337      BPL      2$             ;BR IF NOT
709 004324 162737 000020 001124  SUB      #20,$GDDAT     ;ADVANCE TO NEXT PATTERN
710 004332 100403      BMI     TST7           ;ADVANCE TO NEXT TEST IF ALL PATTERNS TESTED
711 004334 005337 032374      DEC     BUFFER         ;SET UP NAME INSTR WITH NEXT PATTERN
712 004340 000724      BR      1$             ;GO TRY NEXT PATTERN
    
```

```

(3)
(3)
(2) 004342 000004
(1) 004344 012737 000010 001166
(2) 004352 012737 000007 001206
715 004360 005037 001124
716 004364 005002
717 004366 012737 163000 032376
718 004374 012737 004412 001110
719 004402 012701 020040 1$:     MOV      #20040,R1      ;SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
    
```



```

720 004406 012700 000035      MOV      #35,R0          ;SET UP STK LEVEL AFTER JSR IN R0
721 004412 010177 175660      MOV      R1,@STKPT      ;SET STK PTR BEFORE JSR
722 004416 012737 100000 032374  MOV      #100000,BUFFER ;SET UP INSTR
723 004424 050237 032374      BIS      R2,BUFFER      ;ADD IN CURRENT INSTR MODE
724 004430 012777 032374 175606  MOV      #BUFFER,@DPC   ;START
725 004436 013737 002272 001122  MOV      STKVAL,$BDADR  ;SET UP REG ADRS 26
726 004444 005277 175574      INC      @DPC           ;RESUME
727 004450 004537 024446      JSR      R5,DELAY       ;STALL FOR STACKING
728 004454 000001      BIT0     ;COUNT TO 1
729 004456 010077 175614      MOV      R0,@STKPT     ;SELECT STACK WORD & BYTE
730 004462 017737 175604 001126  MOV      @STKVAL,$BDDAT ;READ MODE BITS
731 004470 042737 177760 001126  BIC      #177760,$BDDAT ;DON'T WANT NAME BITS
732 004476 023737 001124 001126  CMP      $GDDAT,$BDDAT ;ARE THE MODE BITS CORRECT?
733 004504 001403      BEQ      3$            ;BR IF OK
734 004506 010037 001164      MOV      R0,$TMP0      ;SET UP STK LEVEL BEFORE ER TYPE
735 004512 104007      ERROR    7            ;MODE FAILED TM STACK AT LEVEL INDICATED
736 004514 162701 000004      3$:     SUB      #4,R1    ;ADVANCE TO NEXT STK LEVEL
737 004520 162700 000004      SUB      #4,R0          ;HAS THIS INSTR MODE BEEN WRITTEN THRU STACK?
738 004524 100332      BPL      2$            ;BR IF NOT
739 004526 022702 044000      CMP      #44000,R2     ;IS THIS THE ABS VECTOR INSTR?
740 004532 001405      BEQ      TST10         ;ADVANCE TO NEXT TEST IF SPARE HAS BEEN TESTED
741 004534 062702 004000      ADD      #4000,R2      ;ADVANCE TO NEXT INSTR MODE
742 004540 005237 001124      INC      $GDDAT        ;ADVANCE TO NEXT MODE EXPECTED
743 004544 000716      BR       1$            ;TRY NEXT INSTR
744
745
(3)
(3)
(2) 004546 000004      TST10:  SCOPE
(1) 004550 012737 000010 001166  MOV      #10,$TIMES    ;;DO 10 ITERATIONS
(2) 004556 012737 000010 001206  MOV      #10,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX
746 004564 012737 074000 001124  MOV      #74000,$GDDAT ;EXPECT ALL ONES INITIALLY
747 004572 012737 154037 032374  MOV      #154037,BUFFER ;SET UP LOAD STATUS C INSTR
748 004600 012737 163000 032376  MOV      #163000,BUFFER+2 ;SET UP JSR INSTR
749 004606 012737 004624 001110  MOV      #2$,$LPERR    ;SET UP SCOPE LOOP ADRS
750 004614 012701 020040      1$:     MOV      #20040,R1   ;SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
751 004620 012700 000036      MOV      #36,R0        ;SET UP STK LEVEL AFTER JSR IN R0
752 004624 010177 175446      2$:     MOV      R1,@STKPT  ;SET STK PTR BEFORE JSR
753 004630 012777 032374 175406  MOV      #BUFFER,@DPC  ;START
754 004636 013737 002272 001122  MOV      STKVAL,$BDADR ;SET UP REG ADRS 26
755 004644 005277 175374      INC      @DPC          ;ADVANCE TO JSR INSTR
756 004650 004537 024446      JSR      R5,DELAY     ;STALL FOR STACKING
757 004654 000001      BIT0     ;COUNT TO 1
758 004656 010077 175414      MOV      R0,@STKPT     ;SELECT STACK WORD & BYTE
759 004662 017737 175404 001126  MOV      @STKVAL,$BDDAT ;READ VECTOR SCALE FROM STACK
760 004670 042737 103777 001126  BIC      #103777,$BDDAT ;ONLY WANT VECTOR SCALE BITS
761 004676 023737 001124 001126  CMP      $GDDAT,$BDDAT ;ARE THEY CORRECT?
762 004704 001403      BEQ      3$            ;BR IF OK
763 004706 010037 001164      MOV      R0,$TMP0      ;SET UP STK LEVEL FOR ER TYPE
764 004712 104010      ERROR    10          ;VECTOR SCALE FAILED TO STACK AT LEVEL INDICATED
765 004714 162701 000004      3$:     SUB      #4,R1    ;ADVANCE TO NEXT STK LEVEL
766 004720 162700 000004      SUB      #4,R0          ;ALL STACK LOCATIONS TESTED?
767 004724 100337      BPL      2$            ;BR IF NOT
768 004726 162737 004000 001124  SUB      #4000,$GDDAT  ;ADVANCE TO NEXT VECTOR SCALE PATTERN
769 004734 100403      BMI      TST11         ;ADVANCE TO NEXT TEST IF ALL PATTERNS TESTED
770 004736 005337 032374      DEC      BUFFER        ;UPDATE INSTRUCTION
    
```

 *TEST 10 TEST THAT THE VECTOR SCALE BITS GET PUSHED ON THE STACK

```

(2) 004546 000004      TST10:  SCOPE
(1) 004550 012737 000010 001166  MOV      #10,$TIMES    ;;DO 10 ITERATIONS
(2) 004556 012737 000010 001206  MOV      #10,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX
746 004564 012737 074000 001124  MOV      #74000,$GDDAT ;EXPECT ALL ONES INITIALLY
747 004572 012737 154037 032374  MOV      #154037,BUFFER ;SET UP LOAD STATUS C INSTR
748 004600 012737 163000 032376  MOV      #163000,BUFFER+2 ;SET UP JSR INSTR
749 004606 012737 004624 001110  MOV      #2$,$LPERR    ;SET UP SCOPE LOOP ADRS
750 004614 012701 020040      1$:     MOV      #20040,R1   ;SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
751 004620 012700 000036      MOV      #36,R0        ;SET UP STK LEVEL AFTER JSR IN R0
752 004624 010177 175446      2$:     MOV      R1,@STKPT  ;SET STK PTR BEFORE JSR
753 004630 012777 032374 175406  MOV      #BUFFER,@DPC  ;START
754 004636 013737 002272 001122  MOV      STKVAL,$BDADR ;SET UP REG ADRS 26
755 004644 005277 175374      INC      @DPC          ;ADVANCE TO JSR INSTR
756 004650 004537 024446      JSR      R5,DELAY     ;STALL FOR STACKING
757 004654 000001      BIT0     ;COUNT TO 1
758 004656 010077 175414      MOV      R0,@STKPT     ;SELECT STACK WORD & BYTE
759 004662 017737 175404 001126  MOV      @STKVAL,$BDDAT ;READ VECTOR SCALE FROM STACK
760 004670 042737 103777 001126  BIC      #103777,$BDDAT ;ONLY WANT VECTOR SCALE BITS
761 004676 023737 001124 001126  CMP      $GDDAT,$BDDAT ;ARE THEY CORRECT?
762 004704 001403      BEQ      3$            ;BR IF OK
763 004706 010037 001164      MOV      R0,$TMP0      ;SET UP STK LEVEL FOR ER TYPE
764 004712 104010      ERROR    10          ;VECTOR SCALE FAILED TO STACK AT LEVEL INDICATED
765 004714 162701 000004      3$:     SUB      #4,R1    ;ADVANCE TO NEXT STK LEVEL
766 004720 162700 000004      SUB      #4,R0          ;ALL STACK LOCATIONS TESTED?
767 004724 100337      BPL      2$            ;BR IF NOT
768 004726 162737 004000 001124  SUB      #4000,$GDDAT  ;ADVANCE TO NEXT VECTOR SCALE PATTERN
769 004734 100403      BMI      TST11         ;ADVANCE TO NEXT TEST IF ALL PATTERNS TESTED
770 004736 005337 032374      DEC      BUFFER        ;UPDATE INSTRUCTION
    
```



```

771 004742 000724          BR      1$          ;TRY NEXT VECTOR SCALE VALUE
772
773          ;*****
(3)          ;*TEST 11      TEST THAT THE CHARACTER SCALE BITS GET PUSHED ON THE STACK
(3)          ;*****
(2) 004744 000004          TST11: SCOPE
(1) 004746 012737 000010 001166          MOV      #10,$TIMES          ;;DO 10 ITERATIONS
(2) 004754 012737 000011 001206          MOV      #11,$TESTN          ;;SET TEST NUMBER IN APT MAIL BOX
774 004762 012737 003000 001124          MOV      #3000,$GDDAT          ;EXPECT ALL ONES INITIALLY
775 004770 012737 154340 032374          MOV      #154340,BUFFER          ;SET UP LOAD STATUS C INSTR
776 004776 012737 163000 032376          MOV      #163000,BUFFER+2          ;SET UP JSR INSTR
777 005004 012737 005022 001110          MOV      #2$,$LPERR          ;SET UP LOOP ADRS
778 005012 012701 020040          1$: MOV      #20040,R1          ;SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
779 005016 012700 000036          MOV      #36,R0          ;SET UP STK LEVEL AFTER JSR IN R0
780 005022 010177 175250          2$: MOV      R1,@STKPT          ;SET STK PTR BEFORE JSR
781 005026 012777 032374 175210          MOV      #BUFFER,@DPC          ;START
782 005034 013737 002272 001122          MOV      STKVAL,$BDADR          ;SET UP REG ADRS 26
783 005042 005277 175176          INC      @DPC          ;ADVANCE TO JSR INSTR
784 005046 004537 024446          JSR      R5,DELAY          ;STALL FOR STACKING
785 005052 000001          BIT0          ;COUNT TO 1
786 005054 010077 175216          MOV      R0,@STKPT          ;SELECT STACK WORD & BYTE
787 005060 017737 175206 001126          MOV      @STKVAL,$BDDAT          ;READ CHARACTER SCALE
788 005066 042737 174777 001126          BIC      #174777,$BDDAT          ;ONLY WANT CHAR SCALE
789 005074 023737 001124 001126          CMP      $GDDAT,$BDDAT          ;ARE THEY CORRECT?
790 005102 001403          BEQ      3$          ;BR IF OK
791 005104 010037 001164          MOV      R0,$TMP0          ;SET UP STK LEVEL FOR ER TYPE
792 005110 104011          ERROR      11          ;CHARACTER SCALE FAILED TO STACK AT LEVEL INDICATED
793 005112 162701 000004          3$: SUB      #4,R1          ;ADVANCE TO NEXT STK LEVEL
794 005116 162700 000004          SUB      #4,R0          ;ALL STACK LOCATIONS TESTED?
795 005122 100337          BPL      2$          ;BR IF NOT
796 005124 162737 001000 001124          SUB      #1000,$GDDAT          ;ADVANCE CHARACTER SCALE PATTERN
797 005132 100404          BMI      TST12          ;ADVANCE TO NEXT TEST IF ALL PATTERNS TESTED
798 005134 162737 000040 032374          SUB      #40,BUFFER          ;UPDATE INSTRUCTION
799 005142 000723          BR      1$          ;TRY NEXT CHARACTER SCALE VALUE
800
801          ;*****
(3)          ;*TEST 12      TEST THAT THE CHARACTER ROTATE BIT GETS PUSHED ON THE STACK
(3)          ;*****
(2) 005144 000004          TST12: SCOPE
(2) 005146 012737 000012 001206          MOV      #12,$TESTN          ;;SET TEST NUMBER IN APT MAIL BOX
802 005154 012737 000200 001124          MOV      #200,$GDDAT          ;EXPECT IT TO BE SET INITIALLY
803 005162 012737 155400 032374          MOV      #155400,BUFFER          ;SET UP LOAD STATUS C INSTR
804 005170 012737 163000 032376          MOV      #163000,BUFFER+2          ;SET UP JSR INSTR
805 005176 012737 005214 001110          MOV      #2$,$LPERR          ;SET UP LOOP ADRS
806 005204 012701 020040          1$: MOV      #20040,R1          ;SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
807 005210 012700 000036          MOV      #36,R0          ;SET UP STK LEVEL AFTER JSR IN R0
808 005214 010177 175056          2$: MOV      R1,@STKPT          ;SET STK PTR BEFORE JSR
809 005220 012777 032374 175016          MOV      #BUFFER,@DPC          ;START
810 005226 013737 002272 001122          MOV      STKVAL,$BDADR          ;SET UP REG ADRS 26
811 005234 005277 175004          INC      @DPC          ;ADVANCE TO JSR INSTR
812 005240 004537 024446          JSR      R5,DELAY          ;STALL FOR STACKING
813 005244 000001          BIT0          ;COUNT TO 1
814 005246 010077 175024          MOV      R0,@STKPT          ;SELECT STACK WORD & BYTE
815 005252 017737 175014 001126          MOV      @STKVAL,$BDDAT          ;READ CHARACTER ROTATE BIT
816 005260 042737 177577 001126          BIC      #177577,$BDDAT          ;ONLY WANT CHARACTER ROTATE BIT
817 005266 023737 001124 001126          CMP      $GDDAT,$BDDAT          ;IS IT CORRECT?
    
```


818	005274	001403			BEQ	3\$:BR IF OK
819	005276	010037	001164		MOV	R0,\$TMP0		:SET UP STK LEVEL FOR ER TYPE
820	005302	104012			ERROR	12		:CHARACTER ROTATE FEILED TO STACK AT LEVEL INDICATED
821	005304	162701	000004		3\$: SUB	#4,R1		:ADVANCE TO NEXT STK LEVEL
822	005310	162700	000004		SUB	#4,R0		:ALL STACK LOCATIONS TESTED?
823	005314	100337			BPL	2\$:BR IF NOT
824	005316	162737	000400	032374	SUB	#400,BUFFER		:UPDATE INSTR
825	005324	162737	000200	001124	SUB	#200,\$GDDAT		:EXPECT ZERO NEXT
826	005332	100324			BPL	1\$:BR IF RESET STATE NOT TESTED

827
828
(3)
(3)
:*****
:*TEST 13 TEST THAT THE INTENSITY LEVEL BITS GET PUSHED ON THE STACK
:*****

(2)	005334	000004			TST13: SCOPE			
(1)	005336	012737	000010	001166	MOV	#10,\$TIMES		::DO 10 ITERATIONS
(2)	005344	012737	000013	001206	MOV	#13,\$TESTN		::SET TEST NUMBER IN APT MAIL BOX
829	005352	012737	000160	001124	MOV	#160,\$GDDAT		:EXPECT ALL BITS INITIALLY
830	005360	012737	103600	032374	MOV	#103600,BUFFER		:SET UP ALL INTENSITY LEVEL BITS INITIALLY
831	005366	012737	163000	032376	MOV	#163000,BUFFER+2		:SET UP JSR INSTR
832	005374	012737	005412	001110	MOV	#2\$,\$LPERR		:SET UP LOOP ADRS
833	005402	012701	020040		1\$: MOV	#20040,R1		:SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
834	005406	012700	000036		MOV	#36,R0		:SET UP STK LEVEL AFTER JSR IN R0
835	005412	010177	174660		2\$: MOV	R1,@STKPT		:SET STK PTR BEFORE JSR
836	005416	012777	032374	174620	MOV	#BUFFER,@DPC		:START
837	005424	013737	002272	001122	MOV	STKVAL,\$BDDADR		:SET UP REG ADRS26
838	005432	012777	032376	174604	MOV	#BUFFER+2,@DPC		:START
839	005440	004537	024446		JSR	R5,DELAY		:STALL FOR STACKING
840	005444	000001			BIT0			:COUNT TO 1
841	005446	010077	174624		MOV	R0,@STKPT		:SELECT STACK WORD & BYTE
842	005452	017737	174614	001126	MOV	@STKVAL,\$BDDAT		:READ INTENSITY LEVEL
843	005460	042737	177617	001126	BIC	#177617,\$BDDAT		:ONLY WANT INTENISTY LEVEL BITS
844	005466	023737	001124	001126	CMP	\$GDDAT,\$BDDAT		:ARE THEY CORRECT?
845	005474	001403			BEQ	3\$:BR IF OK
846	005476	010037	001164		MOV	R0,\$TMP0		:SET UP STK LEVEL FOR ER TYPE
847	005502	104013			ERROR	13		:INTENSITY LEVEL FAILED TO STACK AT LEVEL INDICATED
848	005504	162701	000004		3\$: SUB	#4,R1		:ADVANCE TO NEXT STK LEVEL
849	005510	162700	000004		SUB	#4,R0		:ALL STACK LOCATIONS TESTED?
850	005514	100336			BPL	2\$:BR IF NOT
851	005516	162737	000200	032374	SUB	#200,BUFFER		:SET UP NEXT INTENSITY LEVEL
852	005524	162737	000020	001124	SUB	#20,\$GDDAT		:ADVANCE TO NEXT INTENSITY LEVEL
853	005532	100323			BPL	1\$:BR IF RESET STATE NOT TESTED

854
855
(3)
(3)
:*****
:*TEST 14 TEST THAT THE COLOR LEVEL BITS GET PUSHED ON THE STACK
:*****

(2)	005534	000004			TST14: SCOPE			
(1)	005536	012737	000010	001166	MOV	#10,\$TIMES		::DO 10 ITERATIONS
(2)	005544	012737	000014	001206	MOV	#14,\$TESTN		::SET TEST NUMBER IN APT MAIL BOX
856	005552	012737	000014	001124	MOV	#14,\$GDDAT		:EXPECT ALL BIT INITIALLY
857	005560	012737	175600	032374	MOV	#175600,BUFFER		:SET UP ALL COLOR LEVEL BITS INITIALLY
858	005566	012737	163000	032376	MOV	#163000,BUFFER+2		:SET UP JSR INSTR
859	005574	012737	005602	001110	MOV	#1\$,\$LPERR		:SET UP LOOP ADRS
860	005602	012701	020040		1\$: MOV	#20040,R1		:SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
861	005606	012700	000036		MOV	#36,R0		:SET UP STK LEVEL AFTER JSR IN R0
862	005612	010177	174460		2\$: MOV	R1,@STKPT		:SET STK PTR BEFORE JSR
863	005616	012777	032374	174420	MOV	#BUFFER,@DPC		:START


```

864 005624 013737 002272 001122 MOV STKVAL,$BDADR ;SET UP REG ADRS 26
865 005632 005277 174406 INC @DPC ;ADVANCE TO JSR INSTR
866 005636 004537 024446 JSR R5,DELAY ;STALL FOR STACKING
867 005642 000001 BIT0 ;COUNT TO 1
868 005644 010077 174426 MOV R0,@STKPT ;SELECT STACK WORD & BYTE
869 005650 017737 174416 001126 MOV @STKVAL,$BDDAT ;READ COLOR LEVEL FROM STACK
870 005656 042737 177763 001126 BIC #177763,$BDDAT ;SAVE ONLY COLOR LEVEL
871 005664 023737 001124 001126 CMP $GDDAT,$BDDAT ;ARE THEY CORRECT?
872 005672 001403 BEQ 3$ ;BR IF SO
873 005674 010037 001164 MOV R0,$TMP0 ;SET UP STK LEVEL FOR ER TYPE
874 005700 104014 ERROR 14 ;COLOR LEVEL FAILED TO STACK AT LEVEL INDICATED
875 005702 162701 000004 3$: SUB #4,R1 ;ADVANCE TO NEXT STK LEVEL
876 005706 162700 000004 SUB #4,R0 ;ALL STACK LOCATIONS TESTED?
877 005712 100337 BPL 2$ ;BR IF NOT
878 005714 162737 000200 032374 SUB #200,BUFFER ;ADVANCE COLOR LEVEL AT INSTR LOC
879 005722 162737 000004 001124 SUB #4,$GDDAT ;ADVANCE COLOR LEVEL AT EXPECTED LOC
880 005730 100324 BPL 1$ ;BR IF RESET STATE NOT TESTED
    
```

```

881
882 ::*****
(3) :*TEST 15 TEST THAT ITALICS GETS PUSHED ON THE STACK
(3) ::*****
    
```

```

(2) 005732 000004 TST15: SCOPE
(2) 005734 012737 000015 001206 MOV #15,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
883 005742 012737 100000 001124 MOV #100000,$GDDAT ;EXPECT IT TO BE SET INITIALLY
884 005750 012737 170060 032374 MOV #170060,BUFFER ;SET UP ITALICS AT INSTR LOC
885 005756 012737 163000 032376 MOV #163000,BUFFER+2 ;SET UP JSR INSTR
886 005764 012737 006002 001110 MOV #2$,$LPERR ;SET UP SCOPE LOOP ADRS
887 005772 012701 020040 1$: MOV #20040,R1 ;SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
888 005776 012700 000036 MOV #36,R0 ;SET UP STK LEVEL AFTER JSR IN R0
889 006002 010177 174270 2$: MOV R1,@STKPT ;SET STK PTR BEFORE JSR
890 006006 012777 032374 174230 MOV #BUFFER,@DPC ;START
891 006014 013737 002272 001122 MOV STKVAL,$BDADR ;SET UP REG ADRS 26
892 006022 005277 174216 INC @DPC ;ADVANCE TO JSR INSTR
893 006026 004537 024446 JSR R5,DELAY ;STALL FOR STACKING
894 006032 000001 BIT0 ;COUNT TO 1
895 006034 010077 174236 MOV R0,@STKPT ;SELECT STACK WORD & BYTE
896 006040 017737 174226 001126 MOV @STKVAL,$BDDAT ;READ ITALICS FROM STACK
897 006046 042737 077777 001126 BIC #77777,$BDDAT ;SAVE AONLY ITALICS BIT
898 006054 023737 001124 001126 CMP $GDDAT,$BDDAT ;IS IT CORRECT?
899 006062 001403 BEQ 3$ ;BR IF SO
900 006064 010037 001164 MOV R0,$TMP0 ;SET UP STK LEVEL FOR ER TYPE
901 006070 104015 ERROR 15 ;ITALICS FAILED TO STACK AT LEVEL INDICATED
902 006072 162701 000004 3$: SUB #4,R1 ;ADVANCE TO NEXT STK LEVEL
903 006076 162700 000004 SUB #4,R0 ;ALL STACK LOCATIONS TESTED?
904 006102 100337 BPL 2$ ;BR IF NOT
905 006104 162737 000020 032374 SUB #20,BUFFER ;RESET ITALICS BIT AT INSTR LOC
906 006112 162737 100000 001124 SUB #100000,$GDDAT ;RESET ITALICS AT EXPECTED LOCATION
907 006120 100324 BPL 1$ ;BR IF RESET STATE NOT TESTED
    
```

```

908
909 ::*****
(3) :*TEST 16 TEST THAT MENU GETS PUSHED ON THE STACK
(3) ::*****
    
```

```

(2) 006122 000004 TST16: SCOPE
(2) 006124 012737 000016 001206 MOV #16,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
910 006132 012737 020000 001124 MOV #20000,$GDDAT ;EXPECT IT TO BE SET INITIALLY
911 006140 012737 170003 032374 MOV #170003,BUFFER ;SET UP MENU AT INSTR LOC
    
```



```

912 006146 012737 163000 032376      MOV      #163000,BUFFER+2      ;SET UP JSR INSTR
913 006154 012737 006172 001110      MOV      #2$, $LPERR          ;SET UP SCOPE LOOP ADRS
914 006162 012701 020040      1$:     MOV      #20040,R1          ;SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
915 006166 012700 000037      MOV      #37,R0              ;SET UP STK LEVEL AFTER JSR IN R0
916 006172 010177 174100      2$:     MOV      R1,@STKPT        ;SET STK PTR BEFORE JSR
917 006176 012777 032374 174040      MOV      #BUFFER,@DPC        ;START
918 006204 013737 002272 001122      MOV      STKVAL,$BDADR       ;SET UP REG ADRS 26
919 006212 005277 174026      INC      @DPC                ;ADVANCE TO JSR INSTR
920 006216 004537 024446      JSR      R5,DELAY            ;STALL FOR STACKING
921 006222 000001      BIT0                      ;COUNT TO 1
922 006224 010077 174046      MOV      R0,@STKPT          ;SELECT STACK WORD & BYTE
923 006230 017737 174036 001126      MOV      @STKVAL,$BDDAT      ;READ MENU BIT
924 006236 042737 157777 001126      BIC      #157777,$BDDAT      ;SAVE ONLY MENU BIT
925 006244 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;IS IT CORRECT?
926 006252 001403      BEQ      3$                 ;BR IF SO
927 006254 010037 001164      MOV      R0,$TMP0           ;SET UP STK LEVEL FOR ER TYPE
928 006260 104016      ERROR    16                 ;MENU FAILED TO STACK AT LEVEL INDICATED
929 006262 162701 000004      3$:     SUB      #4,R1              ;ADVANCE TO NEXT STK LEVEL
930 006266 162700 000004      SUB      #4,R0              ;ALL STACK LOCATIONS TESTED?
931 006272 100337      BPL      2$                 ;BR IF NOT
932 006274 005337 032374      DEC      BUFFER             ;RESET MENU BIT AT INSTR LOC
933 006300 162737 020000 001124      SUB      #20000,$GDDAT      ;RESET MENU BIT AT EXPECTED LOC
934 006306 100325      BPL      1$                 ;BR IF RESET STATE NOT TESTED
935
936
(3)
(3)
(2) 006310 000004
(2) 006312 012737 000017 001206      MOV      #17,$TESTN         ;:SET TEST NUMBER IN APT MAIL BOX
937 006320 012737 100000 001124      MOV      #100000,$GDDAT     ;EXPECT IT TO BE SET INITIALLY
938 006326 012737 100030 032374      MOV      #100030,BUFFER     ;SET UP BLINK ENA AT INSTR LOC
939 006334 012737 163000 032376      MOV      #163000,BUFFER+2   ;SET UP JSR INSTR
940 006342 012737 006360 001110      MOV      #2$, $LPERR        ;SET UP SCOPE LOOP ADRS
941 006350 012701 020040      1$:     MOV      #20040,R1          ;SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
942 006354 012700 000037      MOV      #37,R0              ;SET UP STK LEVEL AFTER JSR IN R0
943 006360 010177 173712      2$:     MOV      R1,@STKPT        ;SET STK PTR BEFORE JSR
944 006364 012777 032374 173652      MOV      #BUFFER,@DPC        ;START
945 006372 013737 002272 001122      MOV      STKVAL,$BDADR       ;SET UP REG ADRS 26
946 006400 012777 032376 173636      MOV      #BUFFER+2,@DPC     ;START
947 006406 004537 024446      JSR      R5,DELAY            ;STALL FOR STACKING
948 006412 000001      BIT0                      ;COUNT TO 1
949 006414 010077 173656      MOV      R0,@STKPT          ;SELECT STACK WORD & BYTE
950 006420 017737 173646 001126      MOV      @STKVAL,$BDDAT      ;READ BLINK ENA BIT
951 006426 042737 077777 001126      BIC      #77777,$BDDAT      ;SAVE ONLY BLINK ENA
952 006434 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;IS IT CORRECT?
953 006442 001403      BEQ      3$                 ;BR IF SO
954 006444 010037 001164      MOV      R0,$TMP0           ;SET UP STK LEVEL FOR ER TYPE
955 006450 104017      ERROR    17                 ;BLINK ENA FAILED TO STACK AT LEVEL INDICATED
956 006452 162701 000004      3$:     SUB      #4,R1              ;ADVANCE TO NEXT STK LEVEL
957 006456 162700 000004      SUB      #4,R0              ;ALL STACK LOCATIONS TESTED?
958 006462 100336      BPL      2$                 ;BR IF NOT
959 006464 162737 000010 032374      SUB      #10,BUFFER         ;RESET BLINK ENA BIT INSTR LOC
960 006472 162737 100000 001124      SUB      #100000,$GDDAT     ;RESET BLINK ENA AT EXPECTED LOC
961 006500 100323      BPL      1$                 ;BR IF RESET STATE NOT TESTED
962
963

```

 : *TEST 17 TEST THAT BLINK ENA GETS PUSHED ON THE STACK

```

TST17: SCOPE
MOV      #17,$TESTN         ;:SET TEST NUMBER IN APT MAIL BOX
MOV      #100000,$GDDAT     ;EXPECT IT TO BE SET INITIALLY
MOV      #100030,BUFFER     ;SET UP BLINK ENA AT INSTR LOC
MOV      #163000,BUFFER+2   ;SET UP JSR INSTR
MOV      #2$, $LPERR        ;SET UP SCOPE LOOP ADRS
1$:     MOV      #20040,R1          ;SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
MOV      #37,R0              ;SET UP STK LEVEL AFTER JSR IN R0
2$:     MOV      R1,@STKPT        ;SET STK PTR BEFORE JSR
MOV      #BUFFER,@DPC        ;START
MOV      STKVAL,$BDADR       ;SET UP REG ADRS 26
MOV      #BUFFER+2,@DPC     ;START
JSR      R5,DELAY            ;STALL FOR STACKING
BIT0                      ;COUNT TO 1
MOV      R0,@STKPT          ;SELECT STACK WORD & BYTE
MOV      @STKVAL,$BDDAT      ;READ BLINK ENA BIT
BIC      #77777,$BDDAT      ;SAVE ONLY BLINK ENA
CMP      $GDDAT,$BDDAT      ;IS IT CORRECT?
BEQ      3$                 ;BR IF SO
MOV      R0,$TMP0           ;SET UP STK LEVEL FOR ER TYPE
ERROR    17                 ;BLINK ENA FAILED TO STACK AT LEVEL INDICATED
3$:     SUB      #4,R1              ;ADVANCE TO NEXT STK LEVEL
SUB      #4,R0              ;ALL STACK LOCATIONS TESTED?
BPL      2$                 ;BR IF NOT
SUB      #10,BUFFER         ;RESET BLINK ENA BIT INSTR LOC
SUB      #100000,$GDDAT     ;RESET BLINK ENA AT EXPECTED LOC
BPL      1$                 ;BR IF RESET STATE NOT TESTED

```

```

(3)          ;*TEST 20      TEST THAT STOP INTR ENA GETS PUSHED ON THE STACK
(3)          ;:*****
(2) 006502 000004          TST20: SCOPE
(2) 006504 012737 000020 001206      MOV      #20,$TESTN      ;;SET TEST NUMBER IN APT MAIL BOX
964 006512 012737 000001 001124      MOV      #1,$GDDAT      ;EXPECT IT TO BE SET INITIALLY
965 006520 012737 171400 032374      MOV      #171400,BUFFER ;SET UP STOP INTR ENA AT INSTR LOC
966 006526 012737 163000 032376      MOV      #163000,BUFFER+2 ;SET UP JSR INSTR
967 006534 012737 006552 001110      MOV      #2$,$LPERR     ;SET UP SCOPE LOOP ADRS
968 006542 012701 020040          1$:     MOV      #20040,R1      ;SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
969 006546 012700 000037          MOV      #37,R0        ;SET UP STK LEVEL AFTER JSR IN R0
970 006552 010177 173520          2$:     MOV      R1,@STKPT    ;SET STK PTR BEFORE JSR
971 006556 012777 032374 173460      MOV      #BUFFER,@DPC   ;START
972 006564 013737 002272 001122      MOV      STKVAL,$BDADR  ;SET UP REG ADRS 26
973 006572 005277 173446          INC      @DPC           ;ADVANCE TO JSR INSTR
974 006576 004537 024446          JSR      R5,DELAY       ;STALL FOR STACKING
975 006602 000001          BITO     ;COUNT TO 1
976 006604 010077 173466          MOV      R0,@STKPT     ;SELECT WORD & BYTE
977 006610 017737 173456 001126      MOV      @STKVAL,$BDDAT ;READ STOP INTR ENA WORD
978 006616 042737 177776 001126      BIC      #177776,$BDDAT ;SAVE ONLY STOP INTR ENA BIT
979 006624 023737 001124 001126      CMP      $GDDAT,$BDDAT ;IS IT CORRECT?
980 006632 001403          BEQ      3$            ;BR IF SO
981 006634 010037 001164          MOV      R0,$TMP0      ;SET UP STK LEVEL FOR ER TYPE
982 006640 104020          ERROR   20            ;STOP INTR ENA FAILED TO STACK AT LEVEL INDICATED
983 006642 162701 000004          3$:     SUB      #4,R1        ;ADVANCE TO NEXT STK LEVEL
984 006646 162700 000004          SUB      #4,R0        ;ALL STACK LOCATIONS TESTED?
985 006652 100337          BPL     2$            ;BR IF NOT
986 006654 162737 000400 032374      SUB      #400,BUFFER   ;RESET STOP INTR ENA AT INSTR LOC
987 006662 005337 001124          DEC      $GDDAT        ;RESET STOP INTR ENA AT EXPECTED LOC
988 006666 100325          BPL     1$            ;BR IF RESET STATE NOT TESTED
989
990          ;:*****

```

```

(3)          ;*TEST 21      TEST THAT L.P. HIT DISABLE GETS PUSHED ON THE STACK
(3)          ;:*****
(2) 006670 000004          TST21: SCOPE
(2) 006672 012737 000021 001206      MOV      #21,$TESTN     ;;SET TEST NUMBER IN APT MAIL BOX
991 006700 012737 000002 001124      MOV      #2,$GDDAT      ;EXPECT IT TO BE SET INITIALLY
992 006706 012737 170300 032374      MOV      #170300,BUFFER ;SET UP HIT DISABLE AT INSTR LOC
993 006714 012737 163000 032376      MOV      #163000,BUFFER+2 ;SET UP JSR INSTR
994 006722 012737 006740 001110      MOV      #2$,$LPERR     ;SET UP SCOPE LOOP ADRS
995 006730 012701 020040          1$:     MOV      #20040,R1      ;SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
996 006734 012700 000037          MOV      #37,R0        ;SET UP STK LEVEL AFTER JSR IN R0
997 006740 010177 173332          2$:     MOV      R1,@STKPT    ;SET STK PTR BEFORE JSR
998 006744 012777 032374 173272      MOV      #BUFFER,@DPC   ;START
999 006752 013737 002272 001122      MOV      STKVAL,$BDADR  ;SET UP REG ADRS 26
1000 006760 005277 173260          INC      @DPC           ;ADVANCE TO JSR INSTR
1001 006764 004537 024446          JSR      R5,DELAY       ;STALL FOR STACKING
1002 006770 000001          BITO     ;COUNT TO 1
1003 006772 010077 173300          MOV      R0,@STKPT     ;SELECT WORD & BYTE
1004 006776 017737 173270 001126      MOV      @STKVAL,$BDDAT ;READ LP HIT DISABLE WORD
1005 007004 042737 177775 001126      BIC      #177775,$BDDAT ;SAVE ONLY LP HIT DISABLE BIT
1006 007012 023737 001124 001126      CMP      $GDDAT,$BDDAT ;IS IT CORRECT?
1007 007020 001403          BEQ      3$            ;BR IF SO
1008 007022 010037 001164          MOV      R0,$TMP0      ;SET UP STK LEVEL FOR ER TYPE
1009 007026 104021          ERROR   21            ;L.P. HIT DISABLE FAILED TO STACK AT LEVEL INDICATED
1010 007030 162701 000004          3$:     SUB      #4,R1        ;ADVANCE TO NEXT STK LEVEL
1011 007034 162700 000004          SUB      #4,R0        ;ALL STACK LOCATIONS TESTED?

```



```

1012 007040 100337          BPL      2$          ;BR IF NOT
1013 007042 162737 000100 032374  SUB      #100,BUFFER ;RESET LP HIT DISABLE BIT AT INSTR LOC
1014 007050 162737 000002 001124  SUB      #2,$GDDAT  ;RESET LP HIT DISABLE BIT AT EXPECTED LOC
1015 007056 100324          BPL      1$          ;BR IF RESET STATE NOT TESTED
1016
(3)
(3)
(2) 007060 000004          ;*****
(2) 007062 012737 000022 001206  TST22: SCOPE ;*TEST 22 TEST THAT STOP INTR & L.P. HIT ENABLES DON'T CHANGE WHEN CHANGE ENA=0
1017 007070 012737 000003 001124  MOV      #22,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
1018 007076 012737 171700 032374  MOV      #3,$GDDAT  ;EXPECT STOP INTR ENABLED & L.P. HIT FROM STK
1019 007104 012737 163000 032376  MOV      #171700,BUFFER ;SET UP LOAD STATUS A INSTR
1020 007112 012777 020040 173156  MOV      #163000,BUFFER+2 ;SET UP JSR REL INSTR
1021 007120 012777 032374 173116  1$: MOV      #20040,@STKPT ;SET 'TOP OF STACK'
1022 007126 013737 002272 001122  MOV      #BUFFER,@DPC ;START
1023 007134 005277 173104          MOV      STKVAL,$BDADR ;SET UP REG ADRS 26
1024 007140 004537 024446          JSR      R5,DELAY  ;PICK UP JSR INSTR
1025 007144 000001          BITO     ;STALL FOR STACKING
1026 007146 012777 020037 173122  MOV      #20037,@STKPT ;COUNT TO ONE
1027 007154 017737 173112 001126  MOV      @STKVAL,$BDDAT ;SET STACK PTR
1028 007162 042737 177774 001126  BIC      #177774,$BDDAT ;READ STACK
1029 007170 023737 001124 001126  CMP      $GDDAT,$BDDAT ;SAVE ONLY STOP INTR & L.P. HIT
1030 007176 001404          BEQ      2$          ;SHOULD STAY SET ONCE CHANGE ENABLES ARE OFF
1031 007200 012737 000037 001164  MOV      #37,$TMP0  ;BR IF CORRECT
1032 007206 104022          ERROR   22          ;SAVE STACK LEVEL FOR TYPE
1033 007210 022737 171700 032374  2$: CMP      #171700,BUFFER ;LD STATUS A STROBED WHEN CHANGE ENA=0
1034 007216 001004          BNE     TST23      ;IS THIS THE 2ND PASS?
1035 007220 042737 001700 032374  BIC      #1700,BUFFER ;GO TO NEXT TEST IF TESTED WITH CHANGE ENA=0
1036 007226 000731          BR      1$          ;CLR CHANGE ENABLES FOR 2ND PASS THIS TEST
1037
1038
1039
(3)
(3)
(2) 007230 000004          ;*****
(2) 007232 012737 000023 001206  TST23: SCOPE ;*TEST 23 TEST THAT EDGE INT ENA GETS PUSHED ON THE STACK
1040 007240 012737 004000 001124  MOV      #23,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
1041 007246 012737 176060 032374  MOV      #4000,$GDDAT ;EXPECT IT TO BE SET INITIALLY
1042 007254 012737 163000 032376  MOV      #176060,BUFFER ;SET UP EDGE INT ENA AT INSTR LOC
1043 007262 012737 007300 001110  MOV      #163000,BUFFER+2 ;SET UP JSR INSTR
1044 007270 012701 020040          MOV      #25,$LPERR ;SET UP SCOPE LOOP ADRS
1045 007274 012700 000037          MOV      #20040,R1  ;SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
1046 007300 010177 172772          MOV      #37,R0    ;SET UP STK LEVEL AFTER JSR IN R0
1047 007304 012777 032374 172732  1$: MOV      R1,@STKPT ;SET STK PTR BEFORE JSR
1048 007312 013737 002272 001122  MOV      #BUFFER,@DPC ;START
1049 007320 005277 172720          MOV      STKVAL,$BDADR ;SET UP REG ADRS 26
1050 007324 004537 024446          JSR      R5,DELAY  ;ADVANCE TO JSR INSTR
1051 007330 000001          BITO     ;STALL FOR STACKING
1052 007332 010077 172740          MOV      R0,@STKPT ;COUNT TO 1
1053 007336 017737 172730 001126  MOV      @STKVAL,$BDDAT ;SELECT WORD & BYTE
1054 007344 042737 173777 001126  BIC      #173777,$BDDAT ;READ STACK WORD
1055 007352 023737 001124 001126  CMP      $GDDAT,$BDDAT ;SAVE ONLY EDGE INT ENA BIT
1056 007360 001403          BEQ      3$          ;IS IT CORRECT?
1057 007362 010037 001164          MOV      R0,$TMP0  ;BR IF SO
1058 007366 104023          ERROR   23          ;SET UP STK LEVEL FOR ER TYPE
1059 007370 162701 000004          3$: SUB      #4,R1   ;EDGE INTR ENA FAILED TO STACK AT LEVEL INDICATED
;ADVANCE TO NEXT STK LEVEL

```



```

1060 007374 162700 000004          SUB    #4,R0          ;ALL STACK LOCATIONS TESTED?
1061 007400 100337          BPL    2$            ;BR IF NOT
1062 007402 162737 000020 032374    SUB    #20,BUFFER    ;RESET EDGE INT ENA BIT AT INSTR LOC
1063 007410 162737 004000 001124    SUB    #4000,$GDDAT  ;RESET EDGE INT ENA BIT AT EXPECTED LOC
1064 007416 100324          BPL    1$            ;BR IF RESET STATE NOT TESTED
1065
1066          ;:*****
(3)          ;*TEST 24      TEST THAT CHAR STRING ESCAPE BIT GETS PUSHED ON THE STACK
(3)          ;:*****
(2) 007420 000004          TST24: SCOPE
(2) 007422 012737 000024 001206    MOV    #24,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX
1067 007430 012737 010000 001124    MOV    #10000,$GDDAT ;EXPECT IT TO BE SET INITIALLY
1068 007436 012737 176003 032374    MOV    #176003,BUFFER ;SET UP CHAR STRING ESCAPE ENA AT INSTR LOC
1069 007444 012737 163000 032376    MOV    #163000,BUFFER+2 ;SET UP JSR INSTR
1070 007452 012737 007470 001110    MOV    #2$,$LPERR    ;SET UP SCOPE LOOP ADRS
1071 007460 012701 020040          1$:  MOV    #20040,R1    ;SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
1072 007464 012700 000037          MOV    #37,R0        ;SET UP STK LEVEL AFTER JSR IN R0
1073 007470 010177 172602          2$:  MOV    R1,@STKPT    ;SET STK PTR BEFORE JSR
1074 007474 012777 032374 172542    MOV    #BUFFER,@DPC  ;START
1075 007502 013737 002272 001122    MOV    STKVAL,$BDADR ;SET UP REG ADRS 26
1076 007510 005277 172530          INC    @DPC          ;ADVANCE TO JSR INSTR
1077 007514 004537 024446          JSR    R5,DELAY      ;STALL FOR STACKING
1078 007520 000001          BITO          ;COUNT TO 1
1079 007522 010077 172550          MOV    R0,@STKPT    ;SELECT STACK WORD & BYTE
1080 007526 017737 172540 001126    MOV    @STKVAL,$BDAT ;READ STACK WORD
1081 007534 042737 167777 001126    BIC    #167777,$BDAT ;SAVE ONLY CHAR STRING ESCAPE BIT
1082 007542 023737 001124 001126    CMP    $GDDAT,$BDAT ;IS IT CORRECT?
1083 007550 001403          BEQ    3$            ;BR IF OK
1084 007552 010037 001164          MOV    R0,$TMP0     ;SET UP STK LEVEL FOR ER TYPE
1085 007556 104024          ERROR 24            ;CHAR STRING ESCAPE FAILED TO STACK AT LEVEL INDICATED
1086 007560 162701 000004          3$:  SUB    #4,R1        ;ADVANCE TO NEXT STK LEVEL
1087 007564 162700 000004          SUB    #4,R0        ;ALL STACK LOCATIONS TESTED?
1088 007570 100337          BPL    2$            ;BR IF NOT
1089 007572 005337 032374          DEC    BUFFER        ;RESET CHAR STRING ESCAPE AT INSTR LOC
1090 007576 162737 010000 001124    SUB    #10000,$GDDAT ;RESET CHAR STRING ESCAPE AT EXPECTED LOC
1091 007604 100325          BPL    1$            ;BR IF RESET STATE NOT TESTED
1092
1093          ;:*****
(3)          ;*TEST 25      TEST THAT DEPTH QUEING BIT GETS PUSHED ON THE STACK
(3)          ;:*****
(2) 007606 000004          TST25: SCOPE
(2) 007610 012737 000025 001206    MOV    #25,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX
1094 007616 012737 002000 001124    MOV    #2000,$GDDAT  ;EXPECT IT TO BE SET INITIALLY
1095 007624 012737 176014 032374    MOV    #176014,BUFFER ;SET UP DEPTH QUEING AT INSTR LOC
1096 007632 012737 163000 032376    MOV    #163000,BUFFER+2 ;SET UP JSR REL INSTR
1097 007640 012737 007656 001110    MOV    #2$,$LPERR    ;SET UP SCOPE LOOP ADRS
1098 007646 012701 020040          1$:  MOV    #20040,R1    ;SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
1099 007652 012700 000037          MOV    #37,R0        ;SET UP STK LEVEL AFTER JSR IN R0
1100 007656 010177 172414          2$:  MOV    R1,@STKPT    ;SET STK PTR BEFORE JSR
1101 007662 012777 032374 172354    MOV    #BUFFER,@DPC  ;START
1102 007670 013737 002272 001122    MOV    STKVAL,$BDADR ;SET UP REG ADRS 26
1103 007676 005277 172342          INC    @DPC          ;ADVANCE TO JSR INSTR
1104 007702 004537 024446          JSR    R5,DELAY      ;STALL FOR STACKING
1105 007706 000001          BITO          ;COUNT TO 1
1106 007710 010077 172362          MOV    R0,@STKPT    ;SELECT STACK WORD & BYTE
1107 007714 017737 172352 001126    MOV    @STKVAL,$BDAT ;READ STACK WORD
    
```



```

1108 007722 042737 175777 001126 BIC #175777,$BDDAT ;SAVE ONLY DEPTH QUEING BIT
1109 007730 023737 001124 001126 CMP $GDDAT,$BDDAT ;IS IT CORRECT?
1110 007736 001403 BEQ 3$ ;BR IF SO
1111 007740 010037 001164 MOV R0,$TMP0 ;SET UP STK LEVEL FOR ER TYPE
1112 007744 104025 ERROR 25 ;DEPTH QUEING FAILED TO STACK AT LEVEL INDICATED
1113 007746 162701 000004 3$: SUB #4,R1 ;ADVANCE TO NEXT STK LEVEL
1114 007752 162700 000004 SUB #4,R0 ;ALL STACK LOCATIONS TESTED?
1115 007756 100337 BPL 2$ ;BR IF NOT
1116 007760 162737 000004 032374 SUB #4,BUFFER ;RESET DEPTH QUEING BIT AT INSTR LOC
1117 007766 162737 002000 001124 SUB #2000,$GDDAT ;RESET DEPTH QUEING BIT AT EXPECTED LOC
1118 007774 100324 BPL 1$ ;BR IF RESET STATE NOT TESTED
1119
1120

```

 *TEST 26 TEST THAT THE DEPTH QUE CONTROL GETS PUSHED ON THE STACK

```

(2) 007776 000004 TST26: SCOPE
(2) 010000 012737 000026 001206 MOV #26,$TESTN ;:SET TEST NUMBER IN APT MAIL BOX
1121 010006 012737 000400 001124 MOV #400,$GDDAT ;EXPECT IT TO BE SET INITIALLY
1122 010014 012737 176300 032374 MOV #176300,BUFFER ;SET UP DEPTH QUE CONTROL AT INSTR LOC
1123 010022 012737 163000 032376 MOV #163000,BUFFER+2 ;SET UP JSR REL INSTR
1124 010030 012737 010046 001110 MOV #2$,$LPERR ;SET UP SCOPE LOOP ADRS
1125 010036 012701 020040 1$: MOV #20040,R1 ;SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
1126 010042 012700 000037 MOV #37,R0 ;SET UP STK LEVEL AFTER JSR IN R0
1127 010046 010177 172224 2$: MOV R1,@STKPT ;SET STK PTR BEFORE JSR
1128 010052 012777 032374 172164 MOV #BUFFER,@DPC ;START
1129 010060 013737 002272 001122 MOV STKVAL,$BDADR ;SET UP REG ADRS 26
1130 010066 005277 172152 INC @DPC ;ADVANCE TO JSR INSTR
1131 010072 004537 024446 JSR R5,DELAY ;STALL FOR STACKING
1132 010076 000001 BIT0 ;COUNT TO 1
1133 010100 010077 172172 MOV R0,@STKPT ;SEL STK WORD & BYTE
1134 010104 017737 172162 001126 MOV @STKVAL,$BDDAT ;READ STACK WORD
1135 010112 042737 177377 001126 BIC #177377,$BDDAT ;SAVE ONLY DEPTH QUE CONTROL
1136 010120 023737 001124 001126 CMP $GDDAT,$BDDAT ;IS IT CORRECT?
1137 010126 001403 BEQ 3$ ;BR IF SO
1138 010130 010037 001164 MOV R0,$TMP0 ;SET UP STK LEVEL FOR ER TYPE
1139 010134 104025 ERROR 25 ;DEPTH QUE CONTROL FAILED TO STACK
1140 010136 162701 000004 3$: SUB #4,R1 ;ADVANCE TO NEXT STK LEVEL
1141 010142 162700 000004 SUB #4,R0 ;ALL STACK LOCATIONS TESTED?
1142 010146 100337 BPL 2$ ;BR IF NOT
1143 010150 162737 000100 032374 SUB #100,BUFFER ;RESET DEPTH QUE CONTROL BIT AT INSTR LOC
1144 010156 162737 000400 001124 SUB #400,$GDDAT ;RESET DEPTH QUE CONTROL AT EXPECTED LOC
1145 010164 100324 BPL 1$ ;BR IF RESET STATE NOT TESTED
1146
1147

```

 *TEST 27 TEST THAT BITS SET BY LOAD STATUS B' DON'T CHANGE WHEN CHANGE ENA=0

```

(2) 010166 000004 TST27: SCOPE
(1) 010170 012737 000040 001166 MOV #40,$TIMES ;:DO 40 ITERATIONS
(2) 010176 012737 000027 001206 MOV #27,$TESTN ;:SET TEST NUMBER IN APT MAIL BOX
1148 010204 012737 016400 001124 MOV #16400,$GDDAT ;EXPECT ALL LOAD STATUS B' ENABLED BITS FROM STK
1149 010212 012737 176377 032374 MOV #176377,BUFFER ;SET UP LOAD STATUS B' INSTR
1150 010220 012737 163000 032376 MOV #163000,BUFFER+2 ;SET UP JSR REL INSTR
1151 010226 012777 020040 172042 1$: MOV #20040,@STKPT ;SET 'TOP OF STACK'
1152 010234 012777 032374 172002 MOV #BUFFER,@DPC ;START
1153 010242 013737 002272 001122 MOV STKVAL,$BDADR ;SET UP REG ADRS 26
1154 010250 000240 NOP ;ALLOW TIME FOR NPR

```



```

1155 010252 005277 171766      INC      @DPC      ;PICK UP JSR INSTR
1156 010256 004537 024446      JSR      R5,DELAY ;STALL FOR STACKING
1157 010262 000001                BITO                ;COUNT TO 1
1158 010264 012777 020037 172004      MOV      #20037,@STKPTR ;SET STK PTR
1159 010272 017737 171774 001126      MOV      @STKVAL,$BDDAT ;READ STACK
1160 010300 042737 161377 001126      BIC      #161377,$BDDAT ;SAVE ONLY DEPTH QUE, EDGE FLG & CHAR STRING
1161 010306 023737 001124 001126      CMP      $GDDAT,$BDDAT ;THEY SHOULD STAY SET ONCE CHANGE ENABLES ARE OFF
1162 010314 001404                BEQ      2$        ;BR IF SO
1163 010316 012737 000037 001164      MOV      #37,$TMP0    ;SAVE STACK LEVEL FOR TYPE
1164 010324 104022                ERROR    22        ;LD STATUS B' STROBED WHEN CHANGE ENA=0
1165 010326 105737 032374      2$:     TSTB     BUFFER ;IS THIS THE SECOND PASS THIS TEST?
1166 010332 100004                BPL      3$        ;GO TO NEXT TEST IF TESTED WITH CHANGE ENA=0
1167 010334 042737 000377 032374      BIC      #377,BUFFER ;CLR OUT CHANGE ENABLES FOR 2ND PASS THIS TEST
1168 010342 000731                BR       1$        ;GO REPEAT TEST WITH ENA=0
1169 010344 000005      3$:     RESET     ;CLR ENABLES BEFORE ADVANCING
1170
1171

```

```

(3) *****
(3) *TEST 30      TEST THAT THE LINE TYPE BITS GETS PUSHED ON THE STACK
(2) *****
(2) 010346 000004      TST30:  SCOPE
1172 010350 012737 000030 001206      MOV      #30,$TESTN   ;:SET TEST NUMBER IN APT MAIL BOX
1173 010356 012737 000003 001124      MOV      #3,$GDDAT    ;:EXPECT BOTH BITS INITIALLY
1174 010364 012737 100007 032374      MOV      #100007,BUFFER ;:SET UP BOTH LINE TYP BITS AT INSTR LOC
1175 010372 012737 163000 032376      MOV      #163000,BUFFER+2 ;:SET UP JSR INSTR
1176 010400 012737 010416 001110      MOV      #2$,$LPERR   ;:SET UP SCOPE LOOP ADRS
1177 010406 012701 020040      1$:     MOV      #20040,R1 ;:SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
1178 010412 012700 000036      MOV      #36,R0       ;:SET UP STK LEVEL AFTER JSR IN R0
1179 010416 010177 171654      2$:     MOV      R1,@STKPTR ;:SET STK PTR BEFORE JSR
1180 010422 012777 032374 171614      MOV      #BUFFER,@DPC ;:START
1181 010430 013737 002272 001122      MOV      STKVAL,$BDADR ;:SET UP REG ADRS 26
1182 010436 012777 032376 171600      MOV      #BUFFER+2,@DPC ;:START
1183 010444 004537 024446      JSR      R5,DELAY     ;:STALL FOR STACKING
1184 010450 000001                BITO                ;:COUNT TO 1
1185 010452 010077 171620      MOV      R0,@STKPTR  ;:SELECT STACK WORD & BYTE
1186 010456 017737 171610 001126      MOV      @STKVAL,$BDDAT ;:READ STACK
1187 010464 042737 177774 001126      BIC      #177774,$BDDAT ;:SAVE LINE TYPE ONLY
1188 010472 023737 001124 001126      CMP      $GDDAT,$BDDAT ;:ARE THEY CORRECT?
1189 010500 001403                BEQ      3$        ;:BR IF SO
1190 010502 010037 001164      MOV      R0,$TMP0    ;:SET UP STK LEVEL FOR ER TYPE
1191 010506 104026                ERROR    26        ;:LINE TYPE FAILED TO STACK AT LEVEL INDICATED
1192 010510 162701 000004      3$:     SUB      #4,R1     ;:ADVANCE TO NEXT STK LEVEL
1193 010514 162700 000004      SUB      #4,R0       ;:ALL STACK LOCATIONS TESTED?
1194 010520 100336                BPL      2$        ;:BR IF NOT
1195 010522 005337 032374      DEC      BUFFER     ;:ADVANCE LINE TYPE AT INSTR LOC
1196 010526 005337 001124      DEC      $GDDAT     ;:ADVANCE LINE TYPE AT EXPECTED LOC
1197 010532 100325                BPL      1$        ;:BR IF RESET STATE NOT TESTED
1198

```

```

(3) *****
(3) *TEST 31      TEST THAT INTENSITY ENABLED (CONSOLE 0) GETS PUSHED ON THE STACK
(2) *****
(2) 010534 000004      TST31:  SCOPE
1199 010536 012737 000031 001206      MOV      #31,$TESTN   ;:SET TEST NUMBER IN APT MAIL BOX
1200 010544 012737 000004 001124      MOV      #4,$GDDAT    ;:EXPECT IT TO BE SET INITIALLY
1201 010552 012737 164300 032374      MOV      #164300,BUFFER ;:SET UP INT EN AT INSTR LOC
1202 010560 012737 163000 032376      MOV      #163000,BUFFER+2 ;:SET UP JSR REL INSTR
1203 010566 012737 010604 001110      MOV      #2$,$LPERR   ;:SET UP SCOPE LOOP ADRS

```



```

1203 010574 012701 020040      1$:  MOV    #20040,R1      ;SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
1204 010600 012700 000037      MOV    #37,R0         ;SET UP STK LEVEL AFTER JSR IN R0
1205 010604 010177 171466      2$:  MOV    R1,@STKPT    ;SET STK PTR BEFORE JSR
1206 010610 012777 032374 171426  MOV    #BUFFER,@DPC   ;START
1207 010616 013737 002272 001122  MOV    STKVAL,$BDADR  ;SET UP REG ADRS 26
1208 010624 005277 171414      INC    @DPC           ;ADVANCE TO JSR INSTR
1209 010630 004537 024446      JSR    R5,DELAY       ;STALL FOR STACKING
1210 010634 000001      BITO           ;COUNT TO 1
1211 010636 010077 171434      MOV    R0,@STKPT     ;SELECT STK WORD & BYTE
1212 010642 017737 171424 001126  MOV    @STKVAL,$BDDAT ;READ STK BYTE
1213 010650 042737 177773 001126  BIC    #177773,$BDDAT ;SAVE ONLY INTENSITY ENABLED BIT
1214 010656 023737 001124 001126  CMP    $GDDAT,$BDDAT ;IS IT CORRECT?
1215 010664 001403      BEQ    3$            ;BR IF OK
1216 010666 010037 001164      MOV    R0,$TMP0      ;SET UP STK LEVEL FOR ER TYPE
1217 010672 104027      ERROR 27            ;INTENSITY ENABLE FAILED TO STACK AT LEVEL INDICATED
1218 010674 162701 000004      3$:  SUB    #4,R1         ;ADVANCE TO NEXT STK LEVEL
1219 010700 162700 000004      SUB    #4,R0         ;ALL STACK LOCATIONS TESTED?
1220 010704 100337      BPL    2$            ;BR IF NOT
1221 010706 162737 000100 032374  SUB    #100,BUFFER   ;SET UP RESET STATE AT INSTR LOC
1222 010714 162737 000004 001124  SUB    #4,$GDDAT     ;SET UP RESET STATE AT EXPECTED LOC
1223 010722 100324      BPL    1$            ;BR IF RESET STATE NOT TESTED

```

 (3) *TEST 32 TEST THAT INTENSITY ENABLED (CONSOLE 1) GETS PUSHED ON THE STACK
 (3) *****

```

(2) 010724 000004      TST32: SCOPE
(2) 010726 012737 000032 001206  MOV    #32,$TESTN    ;:SET TEST NUMBER IN APT MAIL BOX
1226 010734 013737 002272 001122  MOV    STKVAL,$BDADR ;:SET UP REG 26 ADRS
1227 010742 012737 000020 001124  MOV    #20,$GDDAT    ;:EXPECT IT TO BE SET INITIALLY
1228 010750 012737 164700 032374  MOV    #164700,BUFFER ;:SET UP INT EN AT INSTR LOC
1229 010756 012737 163000 032376  MOV    #163000,BUFFER+2 ;:SET UP JSR REL INSTR
1230 010764 012737 011002 001110  MOV    #2$,$LPERR    ;:SET UP SCOPE LOOP ADRS
1231 010772 012701 020040      1$:  MOV    #20040,R1    ;:SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
1232 010776 012700 000037      MOV    #37,R0       ;:SET UP STK LEVEL AFTER JSR IN R0
1233 011002 010177 171270      2$:  MOV    R1,@STKPT   ;:SET STK PTR BEFORE JSR
1234 011006 012777 032374 171230  MOV    #BUFFER,@DPC  ;:START
1235 011014 013737 002272 001122  MOV    STKVAL,$BDADR ;:SET UP REG ADRS 26
1236 011022 005277 171216      INC    @DPC         ;:ADVANCE TO JSR INSTR
1237 011026 004537 024446      JSR    R5,DELAY     ;:STALL FOR STACKING
1238 011032 000001      BITO           ;:COUNT TO 1
1239 011034 010077 171236      MOV    R0,@STKPT   ;:SEL STK WORD & BYTE
1240 011040 017737 171226 001126  MOV    @STKVAL,$BDDAT ;:READ STK BYTE
1241 011046 042737 177757 001126  BIC    #177757,$BDDAT ;:SAVE ONLY INTENSITY ENABLED BIT
1242 011054 023737 001124 001126  CMP    $GDDAT,$BDDAT ;:IS IT CORRECT?
1243 011062 001403      BEQ    3$            ;:BR IF OK
1244 011064 010037 001164      MOV    R0,$TMP0    ;:SET UP STK LEVEL FOR ER TYPE
1245 011070 104027      ERROR 27            ;:INTENSITY ENABLE FAILED TO STACK AT LEVEL INDICATED
1246 011072 162701 000004      3$:  SUB    #4,R1         ;:ADVANCE TO NEXT STK LEVEL
1247 011076 162700 000004      SUB    #4,R0         ;:ALL STACK LOCATIONS TESTED?
1248 011102 100337      BPL    2$            ;:BR IF NOT
1249 011104 162737 000100 032374  SUB    #100,BUFFER   ;:SET UP RESET STATE AT INSTR LCC
1250 011112 162737 000020 001124  SUB    #20,$GDDAT    ;:SET UP RESET STATE AT EXPECTED LOC
1251 011120 100324      BPL    1$            ;:BR IF RESET STATE NOT TESTED

```

 (3) *TEST 33 TEST THAT L.P. INTR ENABLED (CONSOLE 0) GETS PUSHED ON THE STACK


```

(3)
(2) 011122 000004
(2) 011124 012737 000033 001206
1254 011132 012737 000010 001124
1255 011140 012737 164060 032374
1256 011146 012737 163000 032376
1257 011154 012737 011172 001110
1258 011162 012701 020040
1259 011166 012700 000037
1260 011172 010177 171100
1261 011176 012777 032374 171040
1262 011204 013737 002272 001122
1263 011212 005277 171026
1264 011216 004537 024446
1265 011222 000001
1266 011224 010077 171046
1267 011230 017737 171036 001126
1268 011236 042737 177767 001126
1269 011244 023737 001124 001126
1270 011252 001403
1271 011254 010037 001164
1272 011260 104030
1273 011262 162701 000004
1274 011266 162700 000004
1275 011272 100337
1276 011274 162737 000020 032374
1277 011302 162737 000010 001124
1278 011310 100324
1279
1280
    :*****
    TST33: SCOPE
    MOV #33,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
    MOV #10,$GDDAT ;;EXPECT IT TO BE SET INITIALLY
    MOV #164060,BUFFER ;;SET UP L.P. INTR EN AT INSTR LOC
    MOV #163000,BUFFER+2 ;;SET UP JSR INSTR
    MOV #2$,$LPERR ;;SET UP SCOPE LOOP ADRS
    1$: MOV #20040,R1 ;;SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
    MOV #37,R0 ;;SET UP STK LEVEL AFTER JSR IN R0
    2$: MOV R1,@STKPT ;;SET STK PTR BEFORE JSR
    MOV #BUFFER,@DPC ;;START
    MOV STKVAL,$BDADR ;;SET UP REG ADRS 26
    INC @DPC ;;ADVANCE TO JSR INSTR
    JSR R5,DELAY ;;STALL FOR STACKING
    BIT0 ;;COUNT TO 1
    MOV R0,@STKPT ;;SEL STK WORD & BYTE
    MOV @STKVAL,$BDDAT ;;READ STK BYTE
    BIC #177767,$BDDAT ;;SAVE ONLY L.P. INTR ENABLED BIT
    CMP $GDDAT,$BDDAT ;;IS IT CORRECT?
    BEQ 3$ ;;BR IF SO
    MOV R0,$TMP0 ;;SET UP STK LEVEL FOR ER TYPE
    ERROR 30 ;;L.P. INTR ENABLE FAILED TO STACK AT LEVEL INDICATED
    3$: SUB #4,R1 ;;ADVANCE TO NEXT STK LEVEL
    SUB #4,R0 ;;ALL STACK LOCATIONS TESTED?
    BPL 2$ ;;BR IF NOT
    SUB #20,BUFFER ;;SET UP RESET STATE AT INSTR LOC
    SUB #10,$GDDAT ;;SET UP RESET STATE AT EXPECTED LOC
    BPL 1$ ;;BR IF RESET STATE NOT TESTED
    :*****

```

```

(3)
(3)
(2) 011312 000004
(2) 011314 012737 000034 001206
1281 011322 012737 000040 001124
1282 011330 012737 164460 032374
1283 011336 012737 163000 032376
1284 011344 012737 011362 001110
1285 011352 012701 020040
1286 011356 012700 000037
1287 011362 010177 170710
1288 011366 012777 032374 170650
1289 011374 013737 002272 001122
1290 011402 005277 170636
1291 011406 004537 024446
1292 011412 000001
1293 011414 010077 170656
1294 011420 017737 170646 001126
1295 011426 042737 177737 001126
1296 011434 023737 001124 001126
1297 011442 001403
1298 011444 010037 001164
1299 011450 104030
1300 011452 162701 000004
1301 011456 162700 000004
1302 011462 100337
    :*****
    *TEST 34 TEST THAT L.P. INTR ENABLED (CONSOLE 1) GETS PUSHED ON THE STACK
    :*****
    TST34: SCOPE
    MOV #34,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
    MOV #40,$GDDAT ;;EXPECT IT TO BE SET INITIALLY
    MOV #164460,BUFFER ;;SET UP L.P. INTR EN AT INSTR LOC
    MOV #163000,BUFFER+2 ;;SET UP JSR REL INSTR
    MOV #2$,$LPERR ;;SET UP SCOPE LOOP ADRS
    1$: MOV #20040,R1 ;;SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
    MOV #37,R0 ;;SET UP STK LEVEL AFTER JSR IN R0
    2$: MOV R1,@STKPT ;;SET STK PTR BEFORE JSR
    MOV #BUFFER,@DPC ;;START
    MOV STKVAL,$BDADR ;;SET UP REG ADRS 26
    INC @DPC ;;ADVANCE TO JSR INSTR
    JSR R5,DELAY ;;STALL FOR STACKING
    BIT0 ;;COUNT TO 1
    MOV R0,@STKPT ;;SEL STK WORD & BYTE
    MOV @STKVAL,$BDDAT ;;READ STK BYTE
    BIC #177737,$BDDAT ;;SAVE ONLY L.P. INTR ENABLED BIT
    CMP $GDDAT,$BDDAT ;;IS IT CORRECT?
    BEQ 3$ ;;BR IF SO
    MOV R0,$TMP0 ;;SET UP STK LEVEL FOR ER TYPE
    ERROR 30 ;;L.P. INTR ENABLE FAILED TO STACK AT LEVEL INDICATED
    3$: SUB #4,R1 ;;ADVANCE TO NEXT STK LEVEL
    SUB #4,R0 ;;ALL STACK LOCATIONS TESTED?
    BPL 2$ ;;BR IF NOT
    :*****

```



```

1303 011464 162737 000020 032374 SUB #20,BUFFER ;SET UP RESET STATE AT INSTR LOC
1304 011472 162737 000040 001124 SUB #40,$GDDAT ;SET UP RESET STATE AT EXPECTED LOC
1305 011500 100324 BPL 1$ ;BR IF RESET STATE NOT TESTED
1306
1307
    
```

 *TEST 35 TEST THAT L.P. SWITCH INTR ENABLED (CONSOLE 0) GETS PUSHED ON THE STACK

```

(3)
(3)
(2) 011502 000004 TST35: SCOPE
(2) 011504 012737 000035 001206 MOV #35,$TESTN ;:SET TEST NUMBER IN APT MAIL BOX
1308 011512 012737 000100 001124 MOV #100,$GDDAT ;:EXPECT IT TO BE SET INITIALLY
1309 011520 012737 164014 032374 MOV #164014,BUFFER ;:SET UP L.P. SW INTR EN AT INSTR LOC
1310 011526 012737 163000 032376 MOV #163000,BUFFER+2 ;:SET UP JSR REL INSTR
1311 011534 012737 011552 001110 MOV #2$, $LPERR ;:SET UP SCOPE LOOP ADRS
1312 011542 012701 020040 1$: MOV #20040,R1 ;:SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
1313 011546 012700 000037 MOV #37,R0 ;:SET UP STK LEVEL AFTER JSR IN R0
1314 011552 010177 170520 2$: MOV R1,@STKPT ;:SET STK PTR BEFORE JSR
1315 011556 012777 032374 170460 MOV #BUFFER,@DPC ;:START
1316 011564 013737 002272 001122 MOV STKVAL,$BDADR ;:SET UP REG ADRS 26
1317 011572 005277 170446 INC @DPC ;:ADVANCE TO JSR INSTR
1318 011576 004537 024446 JSR R5,DELAY ;:STALL FOR STACKING
1319 011602 000001 BITO ;:COUNT TO 1
1320 011604 010077 170466 MOV R0,@STKPT ;:SEL STK WORD & BYTE
1321 011610 017737 170456 001126 MOV @STKVAL,$BDDAT ;:READ STK BYTE
1322 011616 042737 177677 001126 BIC #177677,$BDDAT ;:SAVE ONLY L.P. SW INTR ENABLED BIT
1323 011624 023737 001124 001126 CMP $GDDAT,$BDDAT ;:IS IT CORRECT?
1324 011632 001403 BEQ 3$ ;:BR IF OK
1325 011634 010037 001164 MOV R0,$TMP0 ;:SET UP STK LEVEL FOR ER TYPE
1326 011640 104031 ERROR 31 ;:L.P. SW INTR ENABLE FAILED TO STACK AT LEVEL INDICATED
1327 011642 162701 000004 3$: SUB #4,R1 ;:ADVANCE TO NEXT STK LEVEL
1328 011646 162700 000004 SUB #4,R0 ;:ALL STACK LOCATIONS TESTED?
1329 011652 100337 BPL 2$ ;:BR IF NOT
1330 011654 162737 000004 032374 SUB #4,BUFFER ;:SET UP RESET STATE AT INSTR. LOC.
1331 011662 162737 000100 001124 SUB #100,$GDDAT ;:SET UP RESET STATE AT EXPECTED LOC
1332 011670 100324 BPL 1$ ;:BR IF RESET STATE NOT TESTED
1333
1334
    
```

 *TEST 36 TEST THAT L.P. SWITCH INTR ENABLED (CONSOLE 1) GETS PUSHED ON THE STACK

```

(3)
(3)
(2) 011672 000004 TST36: SCOPE
(2) 011674 012737 000036 001206 MOV #36,$TESTN ;:SET TEST NUMBER IN APT MAIL BOX
1335 011702 012737 000200 001124 MOV #200,$GDDAT ;:EXPECT IT TO BE SET INITIALLY
1336 011710 012737 164414 032374 MOV #164414,BUFFER ;:SET UP L.P. SW INSTR EN AT INSTR LOC
1337 011716 012737 163000 032376 MOV #163000,BUFFER+2 ;:SET UP JSR REL INSTR
1338 011724 012737 011742 001110 MOV #2$, $LPERR ;:SET UP SCOPE LOOP ADRS
1339 011732 012701 020040 1$: MOV #20040,R1 ;:SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
1340 011736 012700 000037 MOV #37,R0 ;:SET UP STK LEVEL AFTER JSR IN R0
1341 011742 010177 170330 2$: MOV R1,@STKPT ;:SET STK PTR BEFORE JSR
1342 011746 012777 032374 170270 MOV #BUFFER,@DPC ;:START
1343 011754 013737 002272 001122 MOV STKVAL,$BDADR ;:SET UP REG ADRS 26
1344 011762 005277 170256 INC @DPC ;:ADVANCE TO JSR INSTR
1345 011766 004537 024446 JSR R5,DELAY ;:STALL FOR STACKING
1346 011772 000001 BITO ;:COUNT TO 1
1347 011774 010077 170276 MOV R0,@STKPT ;:SEL STK WORD & BYTE
1348 012000 017737 170266 001126 MOV @STKVAL,$BDDAT ;:READ STK BYTE
1349 012006 042737 177577 001126 BIC #177577,$BDDAT ;:SAVE ONLY L.P. SW INTR ENABLED BIT
1350 012014 023737 001124 001126 CMP $GDDAT,$BDDAT ;:IS IT CORRECT?
    
```


1351	012022	001403			BEQ	3\$:BR IF OK
1352	012024	010037	001164		MOV	R0,\$TMP0		:SET UP STK LEVEL FOR ER TYPE
1353	012030	104031			ERROR	31		:L.P. SW INTR ENABLE FAILED TO STACK AT LEVEL INDICATED
1354	012032	162701	000004	3\$:	SUB	#4,R1		:ADVANCE TO NEXT STK LEVEL
1355	012036	162700	000004		SUB	#4,R0		:ALL STACK LOCATIONS TESTED?
1356	012042	100337			BPL	2\$:BR IF NOT
1357	012044	162737	000004	032374	SUB	#4,BUFFER		:SET UP RESET STATE AT INSTR LOC
1358	012052	162737	000200	001124	SUB	#200,\$GDDAT		:SET UP RESET STATE AT EXPECTED LOC
1359	012060	100324			BPL	1\$:BR IF RESET STATE NOT TESTED

1360
 1361
 (3)
 (3)
 (2) 012062 000004

 :*TEST 37 TEST THAT THE SHIFT OUT BIT GETS PUSHED ON THE STACK

(2)	012064	012737	000037	001206	TST37: SCOPE	MOV	#37,\$TESTN	::SET TEST NUMBER IN APT MAIL BOX
1362	012072	012737	040000	001124		MOV	#40000,\$GDDAT	:EXPECT IT TO BE SET INITIALLY
1363	012100	012737	100000	032374		MOV	#100000,BUFFER	:SET UP CHAR INSTR
1364	012106	012737	007000	032376		MOV	#7000,BUFFER+2	:SET CHAR TO SHIFT OUT
1365	012114	012737	163000	032400		MOV	#163000,BUFFER+4	:SET UP JSR REL INSTR
1366	012122	012737	012140	001110		MOV	#2\$,\$LPERR	:SET UP SCOPE LOOP ADRS
1367	012130	012701	020040		1\$:	MOV	#20040,R1	:SET TOP OF STACK & MAINT SW2 INITIALLY IN R1
1368	012134	012700	000037			MOV	#37,R0	:SET UP STK LEVEL AFTER JSR IN R0
1369	012140	010177	170132		2\$:	MOV	R1,@STKPT	:SET STK PTR BEFORE JSR
1370	012144	012777	032374	170072		MOV	#BUFFER,@DPC	:START
1371	012152	013737	002272	001122		MOV	STKVAL,\$BDADR	:SET UP REG ADRS 26
1372	012160	005277	170060			INC	@DPC	:RESUME
1373	012164	004537	024446			JSR	R5,DELAY	:STALL FOR CHAR DISPLAY
1374	012170	000010				BIT3		:COUNT TO 10
1375	012172	005277	170046			INC	@DPC	:RESUME
1376	012176	004537	024446			JSR	R5,DELAY	:STALL FOR STKING
1377	012202	000001				BIT0		:COUNT TO 1
1378	012204	010077	170066			MOV	R0,@STKPT	:SEL STK WD & BYTE
1379	012210	017737	170056	001126		MOV	@STKVAL,\$BDDAT	:READ STK
1380	012216	042737	137777	001126		BIC	#137777,\$BDDAT	:SAVE SHIFT OUT BIT ONLY
1381	012224	023737	001124	001126		CMP	\$GDDAT,\$BDDAT	:IS IT CORRECT?
1382	012232	001403				BEQ	3\$:BR IF SO
1383	012234	010037	001164			MOV	R0,\$TMP0	:SET UP STK LEVEL FOR ER TYPE
1384	012240	104032				ERROR	32	:SHIFT OUT FAILED TO STACK AT LEVEL INDICATED
1385	012242	162701	000004		3\$:	SUB	#4,R1	:ADVANCE TO NEXT STK LEVEL
1386	012246	162700	000004			SUB	#4,R0	:ALL STACK LOCATIONS TESTED?
1387	012252	100332				BPL	2\$:BR IF MORE STK LOC TO TEST
1388	012254	012737	000017	032376		MOV	#17,BUFFER+2	:PROVIDE CHAR THAT WON'T SET SHIFT OUT
1389	012262	162737	040000	001124		SUB	#40000,\$GDDAT	:EXPECT ZERO STATE NEXT
1390	012270	100317				BPL	1\$:BR IF RESET STATE NOT TESTED

1391
 1392
 (3)
 (3)
 (2) 012272 000004

 :*TEST 40 TEST THAT THE 'POP' INSTR WILL INCREMENT THE STACK POINTER

(2)	012274	012737	000040	001206	TST40: SCOPE	MOV	#40,\$TESTN	::SET TEST NUMBER IN APT MAIL BOX
1393	012302	012777	020000	167766		MOV	#20000,@STKPT	:SET STACK POINTER TO ZERO
1394	012310	012737	000004	001124		MOV	#4,\$GDDAT	:EXPECT STK PTR TO BE 1 INITIALLY
1395	012316	012737	165000	032374		MOV	#165000,BUFFER	:SET UP POP INSTR
1396	012324	012777	032374	167712	1\$:	MOV	#BUFFER,@DPC	:START
1397	012332	013737	002276	001122		MOV	STKPT,\$BDADR	:SET UP REG ADRS 32
1398	012340	017737	167732	001126		MOV	@STKPT,\$BDDAT	:READ STACK SELECTION


```

1399 012346 042737 177740 001126      BIC    #177740,$BDDAT ;SAVE ONLY STK SEL BITS
1400 012354 023737 001124 001126      CMP    $GDDAT,$BDDAT ;ARE THEY CORRECT?
1401 012362 001401                      BEQ    2$             ;BR IF SO
1402 012364 104033                      ERROR  33            ;POP INSTR FAILED TO INCREMENT STACK PTR
1403 012366 062737 000004 001124 2$:   ADD    #4,$GDDAT      ;ADVANCE EXPECTED STACK POINTER VALUE
1404 012374 022737 000040 001124      CMP    #40,$GDDAT    ;HAVE DONE ALL STK LOCS?
1405 012402 001350                      BNE    1$             ;BR IF NOT
1406
1407

```

 :*TEST 41 TEST THAT STACK UNDERFLOW WILL SET

```

(3)
(3)
(2) 012404 000004      TST41: SCOPE
(1) 012406 012737 000040 001166      MOV    #40,$TIMES    ;;DO 40 ITERATIONS
(2) 012414 012737 000041 001206      MOV    #41,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX
1408 012422 012777 020000 167646      MOV    #20000,@STKPT ;SET STACK TO ZERO
1409 012430 005037 001124                      CLR    $GDDAT        ;EXPECT NO UNDERFLOW FOR 8 POPS
1410 012434 012700 000011                      MOV    #11,R0        ;SET UP POP COUNT
1411 012440 012737 165000 032374      MOV    #165000,BUFFER ;SET UP POP INSTR
1412 012446 012777 032374 167570 1$:   MOV    #BUFFER,@DPC   ;START
1413 012454 013737 002256 001122      MOV    SREG1,$BDADR  ;SET UP REG ADRS 12
1414 012462 005300                      DEC    R0             ;COUNT POP OPERATION
1415 012464 001410                      BEQ    2$             ;BR IF UNDERFLOW EXPECTED
1416 012466 032777 010000 167562      BIT    #10000,@SREG1 ;SEE THAT UNDERFLOW NOT SET
1417 012474 001764                      BEQ    1$             ;BR IF OK
1418 012476 012737 010000 001126      MOV    #10000,$BDDAT ;INDICATE STACK UNDERFLOW
1419 012504 104034                      ERROR  34            ;STACK UNDERFLOW SET PREMATURELY
1420 012506 032777 010000 167542 2$:   BIT    #10000,@SREG1 ;SEE THAT UNDERFLOW IS SET
1421 012514 001006                      BNE    3$             ;BR IF SO
1422 012516 012737 010000 001124      MOV    #10000,$GDDAT ;EXPECTED STACK UNDERFLOW
1423 012524 005037 001126                      CLR    $BDDAT        ;INDICATE IT WAS NOT THERE
1424 012530 104034                      ERROR  34            ;STACK UNDERFLOW FAILED TO SET
1425 012532 000005 3$:   RESET                ;RESET STACK UNDERFLOW INT REQ BEFORE ADVANCING
1426
1427

```

 :*TEST 42 TEST THAT THE POP INSTR CAN RESTORE THE DPC

```

(3)
(3)
(2) 012534 000004      TST42: SCOPE
(2) 012536 012737 000042 001206      MOV    #42,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX
1428 012544 013737 002244 001122      MOV    DPC,$BDADR    ;SET UP REG 00 ADRS
1429 012552 012737 032376 001124      MOV    #BUFFER+2,$GDDAT ;EXPECT BUFFER+2 ADRS AFTER POP
1430 012560 012777 020040 167510      MOV    #20040,@STKPT ;SET TOP OF STACK
1431 012566 012737 163000 032374      MOV    #163000,BUFFER ;SET UP JSR REL INSTR
1432 012574 012737 166000 032404      MOV    #166000,BUFFER+10 ;SET UP POP INSTR
1433 012602 012777 032374 167434      MOV    #BUFFER,@DPC  ;START
1434 012610 004537 024446                      JSR    R5,DELAY      ;STALL FOR STACKING
1435 012614 000001                      BIT0                    ;COUNT TO 1
1436 012616 012777 032404 167420      MOV    #BUFFER+10,@DPC ;START
1437 012624 004537 024446                      JSR    R5,DELAY      ;STALL FOR UNSTACKING
1438 012630 000001                      BIT0                    ;COUNT TO 1
1439 012632 017737 167406 001126      MOV    @DPC,$BDDAT    ;READ DPC
1440 012640 023737 001124 001126      CMP    $GDDAT,$BDDAT ;DID THE DPC GET RESTORED OK
1441 012646 001401                      BEQ    TST43          ;ADVANCE TO NEXT TEST IF OK
1442 012650 104035                      ERROR  35            ;POP INSTR FAILED TO RESTORE DPC FROM STACK
1443
1444

```

 :*TEST 43 TEST THAT THE NAME BITS WILL GET RESTORED

```

(3)

```



```
(3)
(2) 012652 000004
(1) 012654 012737 000004 001166
(2) 012662 012737 000043 001206
1445 012670 012737 012720 001110
1446 012676 013737 002270 001122
1447 012704 012737 003777 001124
1448 012712 004437 024462
1449 012716 150000
1450 012720 012737 150000 032374 1$: MOV #150000,BUFFER ;SET UP NAME INSTR
1451 012726 053737 001124 032374 BIS $GDDAT,BUFFER ;SET NAME WORD
1452 012734 004737 024512 JSR PC,DO ;GO CYCLE THRU INSTRUCTIONS
1453 012740 017737 167324 001126 MOV @DNAME,$BDDAT ;READ NAME REG
1454 012746 042737 174000 001126 BIC #174000,$BDDAT ;SAVE ONLY NAME BITS
1455 012754 023737 001124 001126 CMP $GDDAT,$BDDAT ;DID THEY GET RESTORED?
1456 012762 001401 BEQ 2$ ;BR IF SO
1457 012764 104036 ERROR 36 ;NAME FAILED TO RESTORE
1458 012766 005337 001124 2$: DEC $GDDAT ;ADVANCE PATTERN
1459 012772 100405 BMI TST44 ;ADVANCE TO NEXT TEST IF ALL VALUES TESTED
1460 012774 001351 BNE 1$ ;BR IF NAME BITS NOT EQ TO ZERO
1461 012776 052737 003777 032400 BIS #3777,BUFFER+4 ;SET NAME REG TO ALL ONES WHEN RESTORING ZERO
1462 013004 000745 BR 1$ ;GO RESTORE ALL ZEROS
```

```
*****
*TEST 44 TEST THAT THE VECTOR SCALE WILL GET RESTORED
*****
(3)
(3)
(2) 013006 000004
(1) 013010 012737 000100 001166
(2) 013016 012737 000044 001206
1465 013024 012737 013054 001110
1466 013032 013737 002256 001122
1467 013040 012737 000017 001124
1468 013046 004437 024462
1469 013052 154020
1470 013054 012737 154020 032374 1$: MOV #154020,BUFFER ;SET UP LOAD STATUS C INSTR
1471 013062 053737 001124 032374 BIS $GDDAT,BUFFER ;SET VECTOR SCALE
1472 013070 004737 024512 JSR PC,DO ;GO CYCLE THRU INSTRUCTIONS
1473 013074 017737 167156 001126 MOV @SREG1,$BDDAT ;READ VECTOR SCALE REG
1474 013102 042737 177760 001126 BIC #177760,$BDDAT ;SAVE ONLY THE VECTOR SCALE BITS
1475 013110 023737 001124 001126 CMP $GDDAT,$BDDAT ;DID THEY GET RESTORED?
1476 013116 001401 BEQ 2$ ;BR IF SO
1477 013120 104037 ERROR 37 ;VECTOR SCALE FAILED TO RESTORE
1478 013122 005337 001124 2$: DEC $GDDAT ;ADVANCE PATTERN
1479 013126 100405 BMI TST45 ;ADVANCE TO NEXT TEST IF ALL VALUES TESTED
1480 013130 001351 BNE 1$ ;BR IF VECTOR SCALE NOT EQ TO ZERO
1481 013132 052737 000017 032400 BIS #17,BUFFER+4 ;SET VECTOR SCALE TO ALL ONES WHEN RESTORING ZEROS
1482 013140 000745 BR 1$ ;GO RESTORE ALL ZEROS
```

```
*****
*TEST 45 TEST THAT THE CHAR SCALE WILL GET RESTORED
*****
(3)
(3)
(2) 013142 000004
(2) 013144 012737 000045 001206
1485 013152 012737 013206 001110
1486 013160 013737 002256 001122
1487 013166 012737 001400 001124
TST45: SCOPE
MOV #45,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
MOV #1,$LPERM ;SET UP SCOPE LOOP ADRS
MOV SREG1,$BDADR ;SET UP REG 12 ADRS
MOV #1400,$GDDAT ;EXPECT CHAR SCALE AT MAXIMUM VALUE
```



```

1488 013174 012700 000140      MOV      #140,R0      ;START CHAR SCALE AT MAXIMUM VALUE
1489 013200 004437 024462      JSR      R4,POPSET   ;SET UP JSR,POP & LOAD STATUS C INSTR
1490 013204 154200                154200                ;LOAD STATUS C INSTR
1491 013206 012737 154200 032374 1$:  MOV      #154200,BUFFER ;SET UP LOAD STATUS C INSTR
1492 013214 050037 032374      BIS      R0,BUFFER   ;SET CHAR SCALE
1493 013220 004737 024512      JSR      PC,DO       ;GO CYCLE THRU INSTRUCTIONS
1494 013224 017737 167026 001126  MOV      @SREG1,$BDDAT ;READ CHAR SCALE REG
1495 013232 042737 176377 001126  BIC      #176377,$BDDAT ;SAVE ONLY THE CHAR SCALE BITS
1496 013240 023737 001124 001126  CMP      $GDDAT,$BDDAT ;DID THE CHAR SCALE GET RESTORED OK?
1497 013246 001401                BEQ      2$          ;BR IF SO
1498 013250 104040                ERROR    40          ;CHARACTER SCALE FAILED TO RESTORE
1499 013252 162737 000400 001124 2$:  SUB      #400,$GDDAT  ;ADVANCE CHAR SCALE VALUE
1500 013260 162700 000040                SUB      #40,R0      ;SET UP R0 WITH NEXT VALUE
1501 013264 100405                BMI      TST46       ;ADVANCE TO NEXT TEST IF ALL VALUES TESTED
1502 013266 001347                BNE      1$          ;GO TRY NEXT VALUE IF CHAR SCALE NOT EQ ZERO
1503 013270 052737 000140 032400  BIS      #140,BUFFER+4 ;SET CHAR SCALE TO ALL ONES WHEN RESTORING ZEROS
1504 013276 000743                BR       1$          ;GO RESTORE ALL ZEROS
1505
1506

```

```

(3)
(3)
(2) 013300 000004
(2) 013302 012737 000046 001206
1507 013310 012737 013346 001110
1508 013316 013737 002256 001122
1509 013324 012737 002000 001124
1510 013332 004437 024462
1511 013336 155000
1512 013340 012737 155400 032374
1513 013346 004737 024512 1$:  JSR      PC,DO       ;GO CYCLE THRU INSTRUCTIONS
1514 013352 017737 166700 001126  MOV      @SREG1,$BDDAT ;READ CHAR ROTATE REG
1515 013360 042737 175777 001126  BIC      #175777,$BDDAT ;SAVE ONLY CHAR ROTATE BIT
1516 013366 023737 001124 001126  CMP      $GDDAT,$BDDAT ;IS IT CORRECT?
1517 013374 001401                BEQ      2$          ;BR IF SO
1518 013376 104041                ERROR    41          ;CHARACTER ROTATE FAILED TO RESTORE
1519 013400 162737 002000 001124 2$:  SUB      #2000,$GDDAT ;CLR CHAR ROTATE
1520 013406 100407                BMI      TST47       ;ADVANCE TO NEXT TEST IF BOTH STATES TESTED
1521 013410 042737 000400 032374  BIC      #400,BUFFER  ;SET UP FOR RESET STATE
1522 013416 052737 000400 032400  BIS      #400,BUFFER+4 ;SET CHAR ROTATE BIT
1523 013424 000750                BR       1$          ;GO TRY RESET STATE
1524
1525

```

```

(3)
(3)
(2) 013426 000004
(2) 013430 012737 000047 001206
1526 013436 012737 013472 001110
1527 013444 013737 002266 001122
1528 013452 012737 000014 001124
1529 013460 012700 000600
1530 013464 004437 024462
1531 013470 175000
1532 013472 012737 175000 032374 1$:  MOV      #175000,BUFFER ;SET UP LOAD STATUS B INSTR
1533 013500 050037 032374      BIS      R0,BUFFER   ;SET UP COLOR LEVEL
1534 013504 004737 024512      JSR      PC,DO       ;GO CYCLE THRU INSTRUCTIONS
1535 013510 017737 166552 001126  MCV      @CONS,$BDDAT ;READ COLOR LEVEL REG

```



```

1536 013516 042737 177763 001126      BIC    #177763,$BDDAT ;SAVE COLOR LEVEL ONLY
1537 013524 023737 001124 001126      CMP    $GDDAT,$BDDAT ;IS IT CORRECT?
1538 013532 001401                BEQ    2$             ;BR IF SO
1539 013534 104042                ERROR  42             ;COLOR LEVEL FAILED TO RESTORE
1540 013536 162737 000004 001124 2$:    SUB    #4,$GDDAT     ;ADVANCE TO NEXT VALUE
1541 013544 162700 000200                SUB    #200,R0       ;SET UP R4 WITH NEXT VALUE
1542 013550 100405                BMI    TST50         ;ADVANCE TO NEXT TEST IF ALL COLOR LEVELS TESTED
1543 013552 001347                BNE    1$             ;GO TEST NEXT COLOR LEVEL IF NOT ZERO
1544 013554 052737 000600 032400      BIS    #600,BUFFER+4 ;SET COLOR LEVEL TO ALL ONES WHEN RESTORING ZEROS
1545 013562 000743                BR     1$             ;GO RESTORE ALL ZEROS
    
```

 (3) *TEST 50 TEST THAT THE ITALICS BIT GETS RETORED
 (3) *****

```

(2) 013564 000004      TST50: SCOPE
(2) 013566 012737 000050 001206      MOV    #50,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX
1548 013574 012737 013624 001110      MOV    #1$,$LPERR    ;SET UP SCOPE LOOP ADRS
1549 013602 013737 002246 001122      MOV    SREG0,$BADDR  ;SET UP REG 02 ADRS
1550 013610 012737 000020 001124      MOV    #20,$GDDAT    ;EXPECT ITALICS INITIALLY
1551 013616 004437 024462                JSR    R4,$POPSET    ;SET UP JSR,POP & LOAD STATUS A
1552 013622 170040                170040              ;LOAD STATUS A INSTR
1553 013624 012737 170040 032374 1$:    MOV    #170040,BUFFER ;SET UP LOAD STATUS A INSTR
1554 013632 053737 001124 032374      BIS    $GDDAT,BUFFER ;SET UP ITALICS
1555 013640 004737 024512                JSR    PC,DO         ;GO CYCLE THRU INSTRUCTIONS
1556 013644 017737 166376 001126      MOV    @SREG0,$BDDAT ;READ ITALICS REG
1557 013652 042737 177757 001126      BIC    #177757,$BDDAT ;SAVE ONLY ITALICS
1558 013660 023737 001124 001126      CMP    $GDDAT,$BDDAT ;IS IT CORRECT?
1559 013666 001401                BEQ    2$             ;BR IF SO
1560 013670 104043                ERROR  43             ;ITALICS FAILED TO RESTORE
1561 013672 162737 000020 001124 2$:    SUB    #20,$GDDAT    ;GO TO RESET STATE
1562 013700 100404                BMI    TST51         ;ADVANCE TO NEXT TEST IF BOTH STATES TESTED
1563 013702 052737 000020 032400      BIS    #20,BUFFER+4  ;SET ITALICS BIT TO ONE WHEN RESTORING ZERO
1564 013710 000745                BR     1$             ;GO RESTORE RESET STATE
    
```

 (3) *TEST 51 TEST THAT THE MENU BIT GETS RESTORED
 (3) *****

```

(2) 013712 000004      TST51: SCOPE
(2) 013714 012737 000051 001206      MOV    #51,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX
1567 013722 012737 013760 001110      MOV    #1$,$LPERR    ;SET UP SCOPE LOOP ADRS
1568 013730 013737 002256 001122      MOV    SREG1,$BADDR  ;SET UP REG 12 ADRS
1569 013736 012737 000100 001124      MOV    #100,$GDDAT   ;EXPECT MENU INITIALLY
1570 013744 004437 024462                JSR    R4,$POPSET    ;SET UP JSR,POP & LOAD STATUS A INSTR
1571 013750 170002                170002              ;LOAD STATUS A INSTR
1572 013752 012737 170003 032374      MOV    #170003,BUFFER ;SET UP LOAD STATUS A INSTR
1573 013760 004737 024512 1$:    JSR    PC,DO         ;GO CYCLE THRU INSTRUCTIONS
1574 013764 017737 166266 001126      MOV    @SREG1,$BDDAT ;READ MENU REG
1575 013772 042737 177677 001126      BIC    #177677,$BDDAT ;SAVE ONLY THE MENU BIT
1576 014000 023737 001124 001126      CMP    $GDDAT,$BDDAT ;IS IT CORRECT?
1577 014006 001401                BEQ    2$             ;BR IF SO
1578 014010 104044                ERROR  44             ;MENU FAILED TO RESTORE
1579 014012 162737 000100 001124 2$:    SUB    #100,$GDDAT   ;RESET MENU BIT
1580 014020 100407                BMI    TST52         ;ADVANCE TO NEXT TEST IF BOTH STATES TESTED
1581 014022 042737 000001 032374      BIC    #1,BUFFER     ;RESET MENU FOR INSTR USE
1582 014030 052737 000001 032400      BIS    #1,BUFFER+4   ;SET MENU WHEN RESTORING ZERO
1583 014036 000750                BR     1$             ;GO RESTORE ZERO
    
```


1584
 1585
 (3)
 (3)
 (2) 014040 000004
 (2) 014042 012737 000052 001206
 1586 014050 012737 014106 001110
 1587 014056 013737 002266 001122
 1588 014064 012737 100000 001124
 1589 014072 004437 024462
 1590 014076 164200
 1591 014100 012737 164300 032374
 1592 014106 004737 024512
 1593 014112 017737 166150 001126
 1594 014120 042737 077777 001126
 1595 014126 023737 001124 001126
 1596 014134 001401
 1597 014136 104045
 1598 014140 162737 100000 001124
 1599 014146 100407
 1600 014150 042737 000100 032374
 1601 014156 052737 000100 032400
 1602 014164 000750
 1603
 1604
 (3)
 (3)
 (2) 014166 000004
 (2) 014170 012737 000053 001206
 1605 014176 012737 014234 001110
 1606 014204 013737 002266 001122
 1607 014212 012737 001000 001124
 1608 014220 004437 024462
 1609 014224 164600
 1610 014226 012737 164700 032374
 1611 014234 004737 024512
 1612 014240 017737 166022 001126
 1613 014246 042737 176777 001126
 1614 014254 023737 001124 001126
 1615 014262 001401
 1616 014264 104045
 1617 014266 162737 001000 001124
 1618 014274 100407
 1619 014276 042737 000100 032374
 1620 014304 052737 000100 032400
 1621 014312 000750
 1622
 1623
 (3)
 (3)
 (2) 014314 000004
 (2) 014316 012737 000054 001206
 1624 014324 012737 014362 001110
 1625 014332 013737 002266 001122
 1626 014340 012737 004000 001124
 1627 014346 012737 164060 032374

```

*****
*TEST 52      TEST THAT THE INTENSITY ENA GETS RESTORED ON CONSOLE 0
*****
TST52:  SCOPE
        MOV      #52,$TESTN      ;;SET TEST NUMBER IN APT MAIL BOX
        MOV      #1$,$LPERR      ;;SET UP SCOPE LOOP ADRS
        MOV      CONS,$BDADR     ;;SET UP REG 22 ADRS
        MOV      #100000,$GDDAT  ;;EXPECT INTENSITY ENABLED TO BE SET INITIALLY
        JSR      R4,$POPSET      ;;SET UP JSR, POP & NOP INSTRS
        164200
        MOV      #164300,$BUFFER ;;SET UP NOP INSTR
        JSR      PC,$DO          ;;GO CYCLE THRU INSTRS
1$:     MOV      @CONS,$BDDAT     ;;READ REG 22
        BIC      #77777,$BDDAT   ;;SAVE ONLY INTENSITY ENA BIT
        CMP      $GDDAT,$BDDAT  ;;IS IT CORRECT?
        BEQ      2$             ;;BR IF SO
        ERROR   45              ;;INTENSITY ENA FAILED TO RESTORE
        SUB      #100000,$GDDAT  ;;CLR INTENSITY ENA BIT AT EXPECTED LOC
2$:     BMI      TST53          ;;ADVANCE TO NEXT STATE IF BOTH STATES TESTED
        BIC      #100,$BUFFER    ;;SET UP FOR RESET STATE
        BIS      #100,$BUFFER+4  ;;SET INTENSITY ENA AT INSTR LOC
        BR       1$            ;;GO TRY RESET STATE
    
```

```

*****
*TEST 53      TEST THAT THE INTENSITY ENA GETS RESTORED ON CONSOLE 1
*****
TST53:  SCOPE
        MOV      #53,$TESTN      ;;SET TEST NUMBER IN APT MAIL BOX
        MOV      #1$,$LPERR      ;;SET UP SCOPE LOOP ADRS
        MOV      CONS,$BDADR     ;;SET UP REG 22 ADRS
        MOV      #1000,$GDDAT    ;;EXPECT INTENSITY ENABLED TO BE SET INITIALLY
        JSR      R4,$POPSET      ;;SET UP JSR, POP & NOP INSTRS
        164600
        MOV      #164700,$BUFFER ;;SET UP NOP INSTR
        JSR      PC,$DO          ;;GO CYCLE THRU INSTRS
1$:     MOV      @CONS,$BDDAT     ;;READ REG 22
        BIC      #176777,$BDDAT ;;SAVE ONLY INTENSITY ENA BIT
        CMP      $GDDAT,$BDDAT  ;;IS IT CORRECT?
        BEQ      2$             ;;BR IS SO
        ERROR   45              ;;INTENSITY ENA FAILED TO RESTORE
        SUB      #1000,$GDDAT    ;;CLR INTENSITY ENA BIT AT EXPECTED LOC
2$:     BMI      TST54          ;;ADVANCE TO NEXT TEST IF BOTH STATES TESTED
        BIC      #100,$BUFFER    ;;SET UP FOR RESET STATE
        BIS      #100,$BUFFER+4  ;;SET INTENSITY ENA AT INSTR LOC
        BR       1$            ;;GO TRY RESET STATE
    
```

```

*****
*TEST 54      TEST THAT L.P. INTR ENA GETS RESTORED ON CONSOLE 0
*****
TST54:  SCOPE
        MOV      #54,$TESTN      ;;SET TEST NUMBER IN APT MAIL BOX
        MOV      #1$,$LPERR      ;;SET UP SCOPE LOOP ADRS
        MOV      CONS,$BDADR     ;;SET UP REG 22 ADRS
        MOV      #4000,$GDDAT    ;;EXPECT L.P. INTR ENA TO BE SET INITIALLY
        MOV      #164060,$BUFFER ;;SET UP NOP INSTR
    
```



```

1628 014354 004437 024462 JSR R4,POPSET ;SET UP JSR, POP & NOP INSTRS
1629 014360 164040 164040 ;NOP INSTR
1630 014362 004737 024512 1$: JSR PC,DO ;GO CYCLE THRU INSTRS
1631 014366 017737 165674 001126 MOV @CONS,$BDDAT ;READ REG 22
1632 014374 042737 173777 001126 BIC #173777,$BDDAT ;SAVE ONLY L.P. INTR ENA
1633 014402 023737 001124 001126 CMP $GDDAT,$BDDAT ;IS IT CORRECT?
1634 014410 001401 BEQ 2$ ;BR IF SO
1635 014412 104046 ERROR 46 ;L.P. INTR ENA FAILED TO RESTORE
1636 014414 162737 004000 001124 2$: SUB #4000,$GDDAT ;SET UP FOR RESET STATE
1637 014422 100407 BMI TST55 ;ADVANCE TO NEXT TEST IF BOTH STATES TESTED
1638 014424 042737 000020 032374 BIC #20,BUFFER ;SET UP FOR RESET STATE
1639 014432 052737 000020 032400 BIS #20,BUFFER+4 ;SET IT BEFORE POP
1640 014440 000750 BR 1$ ;GO TRY RESET STATE
    
```

```

1641
1642 ;:*****
(3) ;*TEST 55 TEST THAT L.P. INTR ENA GETS RESTORED ON CONSOLE 1
(3) ;:*****
(2) 014442 000004 TST55: SCOPE
(2) 014444 012737 000055 001206 MOV #55,$TESTN ;:SET TEST NUMBER IN APT MAIL BOX
1643 014452 012737 014510 001110 MOV #1$,$LPERR ;SET UP SCOPE LOOP ADRS
1644 014460 013737 002266 001122 MOV CONS,$BDADR ;SET UP REG 22 ADRS
1645 014466 012737 000040 001124 MOV #40,$GDDAT ;EXPECT L.P. INTR ENABLED TO BE SET INITIALLY
1646 014474 012737 164460 032374 MOV #164460,BUFFER ;SET UP NOP INSTR
1647 014502 004437 024462 JSR R4,POPSET ;SET UP JSR, POP & NOP INSTRS
1648 014506 164440 164440 ;NOP INSTR
1649 014510 004737 024512 1$: JSR PC,DO ;GO CYCLE THRU INSTRS
1650 014514 017737 165546 001126 MOV @CONS,$BDDAT ;READ REG 22
1651 014522 042737 177737 001126 BIC #177737,$BDDAT ;SAVE ONLY L.P. INTR ENA
1652 014530 023737 001124 001126 CMP $GDDAT,$BDDAT ;IS IT CORRECT?
1653 014536 001401 BEQ 2$ ;BR IF SO
1654 014540 104046 ERROR 46 ;L.P. INTR ENA FAILED TO RESTORE
1655 014542 162737 000040 001124 2$: SUB #40,$GDDAT ;SET UP FOR RESET STATE
1656 014550 100407 BMI TST56 ;ADVANCE TO NEXT TEST IF BOTH STATES TESTED
1657 014552 042737 000020 032374 BIC #20,BUFFER ;SET UP FOR RESET STATE
1658 014560 052737 000020 032400 BIS #20,BUFFER+4 ;SET IF BEFORE POP
1659 014566 000750 BR 1$ ;GO TRY RESET STATE
    
```

```

1660
1661 ;:*****
(3) ;*TEST 56 TEST THAT L.P. SW INTR ENA GETS RESTORED ON CONSOLE 0
(3) ;:*****
(2) 014570 000004 TST56: SCOPE
(2) 014572 012737 000056 001206 MOV #56,$TESTN ;:SET TEST NUMBER IN APT MAIL BOX
1662 014600 012737 014636 001110 MOV #1$,$LPERR ;SET UP SCOPE LOOP ADRS
1663 014606 013737 002266 001122 MOV CONS,$BDADR ;SET UP REG 22 ADRS
1664 014614 012737 002000 001124 MOV #2000,$GDDAT ;EXPECT L.P. SW INTR ENA TO BE SET INITIALLY
1665 014622 012737 164014 032374 MOV #164014,BUFFER ;SET UP NOP INSTR
1666 014630 004437 024462 JSR R4,POPSET ;SET UP JSR, POP & NOP INSTRS
1667 014634 164010 164010 ;NOP INSTR
1668 014636 004737 024512 1$: JSR PC,DO ;GO CYCLE THRU INSTRUCTIONS
1669 014642 017737 165420 001126 MOV @CONS,$BDDAT ;READ REG 22
1670 014650 042737 175777 001126 BIC #175777,$BDDAT ;SAVE ONLY L.P. SW INTR ENA
1671 014656 023737 001124 001126 CMP $GDDAT,$BDDAT ;IS IT CORRECT?
1672 014664 001401 BEQ 2$ ;BR IF NOT
1673 014666 104047 ERROR 47 ;L.P. SW INTR ENA FAILED TO RESTORE
1674 014670 162737 002000 001124 2$: SUB #2000,$GDDAT ;SET UP FOR RESET STATE
1675 014676 100407 BMI TST57 ;ADVANCE TO NEXT TEST IF BOTH STATES TESTED
    
```



```

1676 014700 042737 000004 032374 BIC #4,BUFFER ;SET UP FOR RESET STATE
1677 014706 052737 000004 032400 BIS #4,BUFFER+4 ;SET IT BEFORE POP
1678 014714 000750 BR 1$ ;GO TRY RESET STATE
1679
1680
(3)
(3)
(2) 014716 000004
(2) 014720 012737 000057 001206
1681 014726 012737 014764 001110
1682 014734 013737 002266 001122
1683 014742 012737 000020 001124
1684 014750 012737 164414 032374
1685 014756 004437 024462
1686 014762 164410
1687 014764 004737 024512 1$: JSR PC,DO ;GO CYCLE THRU INSTRS
1688 014770 017737 165272 001126 MOV @CONS,$BDDAT ;READ REG 22
1689 014776 042737 177757 001126 BIC #177757,$BDDAT ;SAVE ONLY L.P. SW INTR ENA
1690 015004 023737 001124 001126 CMP $GDDAT,$BDDAT ;IS IT CORRECT?
1691 015012 001401 BEQ 2$ ;BR IF NOT
1692 015014 104047 ERROR 47 ;L.P. SW INTR ENA FAILED TO RESTORE
1693 015016 162737 000020 001124 2$: SUB #20,$GDDAT ;SET UP FOR RESET STATE
1694 015024 100407 BMI TST60 ;ADVANCE TO NEXT TEST IF BOTH STATES TESTED
1695 015026 042737 000004 032374 BIC #4,BUFFER ;SET UP RESET STATE
1696 015034 052737 000004 032400 BIS #4,BUFFER+4 ;SET IT BEFORE POPS
1697 015042 000750 BR 1$ ;GO TRY RESET STATE
1698
1699
(3)
(3)
(2) 015044 000004
(2) 015046 012737 000060 001206
1700 015054 012737 015104 001110
1701 015062 013737 002246 001122
1702 015070 012737 000003 001124
1703 015076 004437 024462
1704 015102 100004
1705 015104 012737 100004 032374 1$: MOV #100004,BUFFER ;SET UP CHAR INSTR
1706 015112 053737 001124 032374 BIS $GDDAT,BUFFER ;SET UP LINE TYPE
1707 015120 004737 024512 JSR PC,DO ;GO CYCLE THRU INSTRS
1708 015124 017737 165116 001126 MOV @SREG0,$BDDAT ;READ LINE TYPE
1709 015132 042737 077774 001126 BIC #77774,$BDDAT ;SAVE ONLY LINE TYPE
1710 015140 023737 001124 001126 CMP $GDDAT,$BDDAT ;IS IT CORRECT?
1711 015146 001401 BEQ 2$ ;BR IF SO
1712 015150 104050 ERROR 50 ;LINE TYPE FAILED TO RESTORE
1713 015152 005337 001124 2$: DEC $GDDAT ;ADVANCE TO NEXT VALUE
1714 015156 100405 BMI TST61 ;ADVANCE TO NEXT TEST IF ALL VALUES TESTED
1715 015160 001351 BNE 1$ ;TRY NEXT LINE TYPE IF NOT ZERO
1716 015162 052737 000003 032400 BIS #3,BUFFER+4 ;SET LINE TYPE TO 3 WHEN RESTORING ZEROS
1717 015170 000745 BR 1$ ;GO RESTORE ALL ZEROS
1718
1719
(3)
(3)
(2) 015172 000004
(2) 015174 012737 000061 001206
TST61: SCOPE
MOV #61,$TESTN ;:SET TEST NUMBER IN APT MAIL BOX

```



```

1720 015202 012737 015236 001110      MOV      #1$, $LPERR      ;SET UP SCOPE LOOP ADRS
1721 015210 013737 002246 001122      MOV      SREG0, $BDADR    ;SET UP REG 02 ADRS
1722 015216 012737 003400 001124      MOV      #3400, $GDDAT    ;EXPECT MAX VALUE INITIALLY
1723 015224 012700 001600          MOV      #1600, R0        ;SET UP INTENSITY LEVEL FOR INSTR USE
1724 015230 004437 024462          JSR      R4, POPSET       ;SET UP JSR, POP & CHAR INSTRS
1725 015234 102000          JSR      102000          ;CHAR INSTR
1726 015236 012737 102000 032374 1$:    MOV      #102000, BUFFER   ;SET UP CHAR INSTR
1727 015244 050037 032374          BIS      R0, BUFFER       ;SET UP INTENSITY LEVEL
1728 015250 004737 024512          JSR      PC, DO           ;GO CYCLE THRU INSTR
1729 015254 017737 164766 001126      MOV      @SREG0, $BDDAT   ;READ INTENSITY LEVEL
1730 015262 042737 174377 001126      BIC      #174377, $BDDAT  ;SAVE ONLY INTENSITY LEVEL
1731 015270 023737 001124 001126      CMP      $GDDAT, $BDDAT  ;IS IT CORRECT?
1732 015276 001401          BEQ      2$              ;BR IF SO
1733 015300 104051          ERROR    51              ;INTENSITY LEVEL FAILED TO RESTORE
1734 015302 162700 000200          SUB      #200, R0         ;SET UP R0 WITH NEXT VALUE
1735 015306 162737 000400 001124      SUB      #400, $GDDAT     ;ADVANCE TO NEXT VALUE
1736 015314 100405          BMI     TST62            ;ADVANCE TO NEXT TEST IF ALL VALUES TESTED
1737 015316 001347          BNE     1$              ;BR IF NEXT INTENSITY LEVEL NOT ZERO
1738 015320 052737 001600 032400      BIS      #1600, BUFFER+4  ;SET INTENSITY LEVEL TO ALL ONES WHEN RESTORING ZEROS
1739 015326 000743          BR      1$              ;GO RESTORE ALL ZEROS

```

```

1740
1741      ;*****
1742      ;*TEST 62      TEST THAT BLINK WILL GET RESTORED
1743      ;*****
1744      TST62:  SCOPE
1745      (2) 015330 000004          MOV      #62, $TESTN     ;:SET TEST NUMBER IN APT MAIL BOX
1746      (2) 015332 012737 000062 001206      MOV      #1$, $LPERR     ;:SET UP SCOPE LOOP ADRS
1747      1742 015340 012737 015376 001110      MOV      SREG0, $BDADR    ;:SET UP REG 02 ADRS
1748      1743 015346 013737 002246 001122      MOV      #10, $GDDAT     ;:EXPECT BLINK INITIALLY
1749      1744 015354 012737 000010 001124      MOV      #100030, BUFFER  ;:SET UP CHAR INSTR
1750      1745 015362 012737 100030 032374      JSR      R4, POPSET       ;:SET UP JSR, POP & CHAR INSTRS
1751      1746 015370 004437 024462          JSR      100020          ;:CHAR INSTR
1752      1747 015374 100020          JSR      PC, DO           ;:GO CYCLE THRU INSTRS
1753      1748 015376 004737 024512          MOV      @SREG0, $BDDAT   ;:READ REG 02
1754      1749 015402 017737 164640 001126      BIC      #177767, $BDDAT  ;:SAVE ONLY THE BLINK BIT
1755      1750 015410 042737 177767 001126      CMP      $GDDAT, $BDDAT  ;:IS IT CORRECT?
1756      1751 015416 023737 001124 001126      BEQ      2$              ;:BR IF SO
1757      1752 015424 001401          ERROR    52              ;:BLINK FAILED TO RESTORE
1758      1753 015426 104052          SUB      #10, BUFFER      ;:SET UP RESET STATE
1759      1754 015430 162737 000010 032374      SUB      #10, $GDDAT     ;:GO TO RESET STATE
1760      1755 015436 162737 000010 001124      BMI     TST63            ;:ADVANCE TO NEXT TEST IF BOTH STATES TESTED
1761      1756 015444 100404          BIS      #10, BUFFER+4   ;:SET BLINK WHEN RESTORING ZERO
1762      1757 015446 052737 000010 032400      BR      1$              ;:GO TRY RESET STATE
1763      1758 015454 000750

```

```

1764      ;*****
1765      ;*TEST 63      TEST THAT THE MODE WILL GET RESTORED
1766      ;*****
1767      TST63:  SCOPE
1768      (1) 015456 000004          MOV      #100, $TIMES    ;:DO 100 ITERATIONS
1769      (2) 015460 012737 000100 001166      MOV      #63, $TESTN     ;:SET TEST NUMBER IN APT MAIL BOX
1770      (2) 015466 012737 000063 001206      MOV      #1$, $LPERR     ;:SET UP SCOPE LOOP ADRS
1771      1761 015474 012737 015524 001110      MOV      SREG0, $BDADR    ;:SET UP REG 02 ADRS
1772      1762 015502 013737 002246 001122      MOV      #44000, $GDDAT  ;:EXPECT ABS VEC MODE INITIALLY
1773      1763 015510 012737 044000 001124      JSR      R4, POPSET       ;:SET UP JSR, POP & MODE INSTR
1774      1764 015516 004437 024462          JSR      100000          ;:CHAR INSTR
1775      1765 015522 100000          BIS      #100000, BUFFER+4 ;RESTORE 'INSTR' BIT AT LOC BUFFER+4
1776      1766 015524 052737 100000 032400 1$:

```



```

1767 015532 012737 100000 032374      MOV      #100000,BUFFER ;SET UP CHAR INSTR
1768 015540 053737 001124 032374      BIS      $GDDAT,BUFFER ;SET UP CURRENT DISPLAY INSTR
1769 015546 004737 024512                JSR      PC,DO          ;GO CYCLE THRU INSTRS
1770 015552 042737 100000 032400      BIC      #100000,BUFFER+4 ;USE LOC BUFFER+4 NOW AS DISPLAY DATA
1771 015560 005277 164460                INC      @DPC          ;PICK UP DATA FOR DISPLAY INSTR ISSUED
1772 015564 000240                NOP                        ; BEFORE JSR - THIS WILL LD MODE BITS
1773 015566 017737 164454 001126      MOV      @SREG0,$BDDAT ;READ REG 02
1774 015574 042737 103777 001126      BIC      #103777,$BDDAT ;SAVE ONLY MODE BITS
1775 015602 023737 001124 001126      CMP      $GDDAT,$BDDAT ;IS IT CORRECT?
1776 015610 001401                BEQ      2$            ;BR IF OK
1777 015612 104053                ERROR    53            ;MODE FAILED TO RESTORE
1778 015614 162737 004000 001124 2$:    SUB      #4000,$GDDAT ;GO TO NEXT DISPLAY MODE
1779 015622 100340                BPL      1$            ;BR IF MORE MODES TO TEST
    
```

```

1780
1781      ::*****
1782      (3)      *TEST 64      TEST THAT STOP INTR ENABLED GETS RESTORED-CK IT ON STK
1783      (3)      ::*****
1784      (2) 015624 000004      TST64: SCOPE
1785      (2) 015626 012737 000064 001206      MOV      #64,$TESTN ;:SET TEST NUMBER IN APT MAIL BOX
1786 015634 012737 015672 001110      MOV      #1$,$LPERR ;:SET UP SCOPE LOOP ADRS
1787 015642 013737 002272 001122      MOV      STKVAL,$BDADR ;:SET UP REG 26 ADRS
1788 015650 012737 000001 001124      MOV      #1,$GDDAT ;:EXPECT IT TO BE SET INITIALLY
1789 015656 012737 171400 032374      MOV      #171400,BUFFER ;:SET UP LOAD STATUS A INSTR
1790 015664 004437 024462                JSR      R4,POPSET ;:SET UP JSR, POP & LOAD STATUS A INSTR
1791 015670 171000                171000 ;:LOAD STATUS A INSTR
1792 015672 004737 024512 1$:    JSR      PC,DO          ;:GO CYCLE THRU INSTRS
1793 015676 012777 032376 164340      MOV      #BUFFER+2,@DPC ;:DO A JSR
1794 015704 004537 024446                JSR      R5,DELAY ;:STALL FOR STACKING
1795 015710 000001                BIT0 ;:COUNT TO 1
1796 015712 012777 020037 164356      MOV      #20037,@STKPT ;:SET UP STK SEL
1797 015720 017737 164346 001126      MOV      @STKVAL,$BDDAT ;:READ STOP INTR ENA BYTE FROM STACK
1798 015726 042737 177776 001126      BIC      #177776,$BDDAT ;:SAVE ONLY STOP INTR ENABLED BIT
1799 015734 023737 001124 001126      CMP      $GDDAT,$BDDAT ;:WAS IT RESTORED ON THE POP INSTR?
1800 015742 001401                BEQ      2$            ;:BR IF SO
1801 015744 104054                ERROR    54            ;:STOP INTR ENABLE FAILED TO RESTORE
1802 015746 005337 001124 2$:    DEC      $GDDAT ;:SET UP FOR RESET STATE
1803 015752 100407                BMI      TST65 ;:ADVANCE TO NEXT TEST IF BOTH STATES TESTED
1804 015754 042737 000400 032374      BIC      #400,BUFFER ;:SET UP FOR STKING RESET STATE
1805 015762 052737 000400 032400      BIS      #400,BUFFER+4 ;:SET BIT BEFORE POP INSTR
1806 015770 000740                BR       1$            ;:GO TRY RESET STATE
    
```

```

1807
1808      (3)      *TEST 65      TEST THAT DEPTH QUEING BIT GETS RESTORED-CK IT ON STK
1809      (3)      ::*****
1810      (2) 015772 000004      TST65: SCOPE
1811      (2) 015774 012737 000065 001206      MOV      #65,$TESTN ;:SET TEST NUMBER IN APT MAIL BOX
1812 016002 012737 016040 001110      MOV      #1$,$LPERR ;:SET UP SCOPE LOOP ADRS
1813 016010 013737 002272 001122      MOV      STKVAL,$BDADR ;:SET UP REG 26 ADRS
1814 016016 012737 002000 001124      MOV      #2000,$GDDAT ;:EXPECT IT TO BE SET INITIALLY
1815 016024 012737 176014 032374      MOV      #176014,BUFFER ;:SET UP LOAD STATUS B' INSTR
1816 016032 004437 024462                JSR      R4,POPSET ;:SET UP JSR, POP & LOAD STATUS B' INSTRS
1817 016036 176010                176010 ;:LOAD STATUS B' INSTR
1818 016040 004737 024512 1$:    JSR      PC,DO          ;:GO CYCLE THRU INSTRS
1819 016044 012777 032376 164172      MOV      #BUFFER+2,@DPC ;:DO A JSR
1820 016052 004537 024446                JSR      R5,DELAY ;:STALL FOR STACKING
1821 016056 000001                BIT0 ;:COUNT TO 1
    
```



```

1815 016060 012777 020037 164210      MOV      #20037,@STKPT      ;SET UP STK SEL
1816 016066 017737 164200 001126      MOV      @STKVAL,$BDDAT    ;READ DEPTH QUEING BYTE FROM STK
1817 016074 042737 175777 001126      BIC      #175777,$BDDAT    ;SAVE ONLY DEPTH QUEING BIT
1818 016102 023737 001124 001126      CMP      $GDDAT,$BDDAT    ;WAS IT RESTORED ON THE POP INSTR?
1819 016110 001401                BEQ      2$                ;BR IF SO
1820 016112 104055                ERROR   55                ;DEPTH QUE FAILED TO RESTORE
1821 016114 162737 002000 001124 2$:      SUB      #2000,$GDDAT      ;SET UP FOR RESET STATE
1822 016122 100407                BMI     TST66              ;ADVANCE TO NEXT TEST IF BOTH STATES TESTED
1823 016124 042737 000004 032374      BIC      #4,BUFFER         ;SET UP FOR STKING RESET STATE
1824 016132 052737 000004 032400      BIS      #4,BUFFER+4      ;SET BIT BEFORE POP INSTR
1825 016140 000737                BR      1$                ;GO TRY RESET STATE
1826
1827

```

 *TEST 66 TEST THAT DEPTH QUE CONTROL BIT GETS RESTROED-CK IT ON STK

```

(2) 016142 000004      TST66: SCOPE
(2) 016144 012737 000066 001206      MOV      #66,$TESTN        ;:SET TEST NUMBER IN APT MAIL BOX
1828 016152 012737 016210 001110      MOV      #1$,$LPERR        ;SET UP SCOPE LOOP ADRS
1829 016160 013737 002272 001122      MOV      STKVAL,$BDADR     ;SET UP REG 26 ADRS
1830 016166 012737 000400 001124      MOV      #400,$GDDAT       ;EXPECT IT TO BE SET INITIALLY
1831 016174 012737 176300 032374      MOV      #176300,BUFFER    ;SET UP LOAD STATUS B' INSTR
1832 016202 004437 024462                JSR      R4,POPSET         ;SET UP JSR, POP & LOAD STATUS B' INSTRS
1833 016206 176200                176200                ;LOAD STATUS B' INSTR
1834 016210 004737 024512                JSR      PC,DO             ;GO CYCLE THRU INSTRS
1835 016214 012777 032374 164022 1$:      MOV      #BUFFER,@DPC      ;DO A JSR REL
1836 016222 004537 024446                JSR      R5,DELAY         ;STALL FOR STACKING
1837 016226 000001                BIT0                ;COUNT TO 1
1838 016230 012777 020037 164040      MOV      #20037,@STKPT     ;SET UP STACK SEL
1839 016236 017737 164030 001126      MOV      @STKVAL,$BDDAT    ;READ STACK
1840 016244 042737 177377 001126      BIC      #177377,$BDDAT    ;SAVE ONLY DEPTH QUE CONTROL BIT
1841 016252 023737 001124 001126      CMP      $GDDAT,$BDDAT    ;WAS IT RESTORED ON THE POP INSTR?
1842 016260 001401                BEQ      2$                ;BR IF SO
1843 016262 104055                ERROR   55                ;DEPTH QUE CONTROL FAILED TO RESTORE
1844 016264 162737 000400 001124 2$:      SUB      #400,$GDDAT       ;SET UP FOR RESET SATATE
1845 016272 100407                BMI     TST67              ;ADVANCE TO NEXT TEST IF BOTH STATES TESTED
1846 016274 042737 000100 032374      BIC      #100,BUFFER       ;SET UP FOR STACKING RESET STATE
1847 016302 052737 000100 032400      BIS      #100,BUFFER+4     ;SET BIT BEFORE POP INSTR
1848 016310 000737                BR      1$                ;GO TRY RESET STATE
1849
1850

```

 *TEST 67 TEST THAT EDGE INTR ENABLED GETS RESTORED-CK IT ON STK

```

(2) 016312 000004      TST67: SCOPE
(2) 016314 012737 000067 001206      MOV      #67,$TESTN        ;:SET TEST NUMBER IN APT MAIL BOX
1851 016322 012737 016360 001110      MOV      #1$,$LPERR        ;SET UP SCOPE LOOP ADRS
1852 016330 013737 002272 001122      MOV      STKVAL,$BDADR     ;SET UP REG 26 ADRS
1853 016336 012737 004000 001124      MOV      #4000,$GDDAT      ;EXPECT IT TO BE SET INITIALLY
1854 016344 012737 176060 032374      MOV      #176060,BUFFER    ;SET UP LOAD STATUS B' INSTR
1855 016352 004437 024462                JSR      R4,POPSET         ;SET UP JSR, POP & LOAD STATUS B' INSTR
1856 016356 176040                176040                ;LOAD STATUS B' INSTR
1857 016360 004737 024512                JSR      PC,DO             ;GO CYCLE THRU INSTRS
1858 016364 012777 032376 163652 1$:      MOV      #BUFFER+2,@DPC    ;DO A JSR
1859 016372 004537 024446                JSR      R5,DELAY         ;STALL FOR STACKING
1860 016376 000001                BIT0                ;COUNT TO 1
1861 016400 012777 020037 163670      MOV      #20037,@STKPT     ;SET UP STK SEL
1862 016406 017737 163660 001126      MOV      @STKVAL,$BDDAT    ;READ EDGE INTR ENA BYTE FROM STK

```


1863	016414	042737	173777	001126		BIC	#173777,\$BDDAT	:SAVE ONLY EDGD INTR ENA BIT
1864	016422	023737	001124	001126		CMP	\$GDDAT,\$BDDAT	:WAS IT RESTORED ON THE POP INSTR?
1865	016430	001401				BEQ	2\$:BR IF SO
1866	016432	104056				ERROR	56	:EDGE INTR ENABLE FAILED TO RESTORE
1867	016434	162737	004000	001124	2\$:	SUB	#4000,\$GDDAT	:SET UP FOR RESET STATE
1868	016442	100407				BMI	TST70	:ADVANCE TO NEXT TEST IF BOTH STATES TESTED
1869	016444	042737	000020	032374		BIC	#20,BUFFER	:SET UP FOR STACKING RESET STATE
1870	016452	052737	000020	032400		BIS	#20,BUFFER+4	:SET BIT BEFORE POP INSTR
1871	016460	000737				BR	1\$:GO TRY RESET STATE

1872
 1873
 (3)
 (3)
 (2) 016462 000004
 (2) 016464 012737 000070 001206
 1874 016472 012737 016530 001110
 1875 016500 013737 002272 001122
 1876 016506 012737 010000 001124
 1877 016514 012737 176003 032374
 1878 016522 004437 024462
 1879 016526 176002

 :*TEST 70 TEST THAT CHAR STRING ESCAPE GETS RESTORED-CK IT ON STK

 TST70: SCOPE

1880	016530	004737	024512		1\$:	JSR	PC,DO	:GO CYCLE THRU INSTRS
1881	016534	012777	032376	163502		MOV	#BUFFER+2,@DPC	:DO A JSR
1882	016542	004537	024446			JSR	R5,DELAY	:STALL FOR STACKING
1883	016546	000001				BITO		:COUNT TO 1
1884	016550	012777	020037	163520		MOV	#20037,@STKPT	:SET UP STK SEL
1885	016556	017737	163510	001126		MOV	@STKVAL,\$BDDAT	:READ CHAR STRING ESCAPE BYTE FROM STK
1886	016564	042737	167777	001126		BIC	#167777,\$BDDAT	:SAVE ONLY CHAR STRING ESCAPE BIT
1887	016572	023737	001124	001126		CMP	\$GDDAT,\$BDDAT	:WAS IT RESTORED ON THE POP INSTR?
1888	016600	001401				BEQ	2\$:BR IF SO
1889	016602	104057				ERROR	57	:CHARACTER STRING ESCAPE FAILED TO RESTORE
1890	016604	162737	010000	001124	2\$:	SUB	#10000,\$GDDAT	:SET UP FOR RESET STATE
1891	016612	100407				BMI	TST71	:ADVANCE TO NEXT TEST IF BOTH STATES TESTED
1892	016614	042737	000001	032374		BIC	#1,BUFFER	:SET UP FOR STACKING RESET STATE
1893	016622	052737	000001	032400		BIS	#1,BUFFER+4	:SET BIT BEFORE POP INSTR
1894	016630	000737				BR	1\$:GO TRY RESET STATE

1895
 1896
 (3)
 (3)
 (2) 016632 000004
 (2) 016634 012737 000071 001206
 1897 016642 012737 016700 001110
 1898 016650 013737 002272 001122
 1899 016656 012737 000002 001124
 1900 016664 012737 170300 032374
 1901 016672 004437 024462
 1902 016676 170200

 :*TEST 71 TEST THAT L.P. HIT DISABLE GETS RESTORED-CK IT ON STK

 TST71: SCOPE

1903	016700	004737	024512		1\$:	JSR	PC,DO	:GO CYCLE THRU INSTRS
1904	016704	012777	032376	163332		MOV	#BUFFER+2,@DPC	:DO A JSR
1905	016712	004537	024446			JSR	R5,DELAY	:STALL FOR STACKING
1906	016716	000001				BITO		:COUNT TO 1
1907	016720	012777	020037	163350		MOV	#20037,@STKPT	:SET UP STK SEL
1908	016726	017737	163340	001126		MOV	@STKVAL,\$BDDAT	:READ L.P. HIS DISABLE BYTE FROM STK
1909	016734	042737	177775	001126		BIC	#177775,\$BDDAT	:SAVE ONLY L.P. HIS DISABLE BIT
1910	016742	023737	001124	001126		CMP	\$GDDAT,\$BDDAT	:WAS IT RESTORED ON THE POP INSTR?


```

1911 016750 001401          BEQ      2$          ;BR IF SO
1912 016752 104060          ERROR    60          ;L.P. HIT DISABLE FAILED TO RESTORE
1913 016754 162737 000002 001124 2$:    SUB      #2,$GDDAT  ;SET UP FOR RESET STATE
1914 016762 100407          BMI      TST72      ;ADVANCE TO NEXT TEST IF BOTH STATES TESTED
1915 016764 042737 000100 032374  BIC      #100,BUFFER ;SET UP FOR STKING RESET STATE
1916 016772 052737 000100 032400  BIS      #100,BUFFER+4 ;SET BIT BEFORE POP INSTR
1917 017000 000737          BR       1$          ;GO TRY RESET STATE
1918
1919

```

 *TEST 72 TEST THAT SHIFT OUT WILL GET RESTORED - CK IT ON STK

```

(3)
(3)
(2) 017002 000004          TST72: SCOPE
(2) 017004 012737 000072 001206  MOV      #72,$TESTN  ;;SET TEST NUMBER IN APT MAIL BOX
1920 017012 012737 000340 177776  MOV      #340,PSW    ;SET PRIORITY TO HIGHEST LEVEL
1921 017020 012737 017102 001110  MOV      #1$,$LPERR  ;SET UP SCOPE LOOP ADRS
1922 017026 013737 002272 001122  MOV      STKVAL,$BDADR ;SET UP REG 26 ADRS
1923 017034 012737 040000 001124  MOV      #40000,$GDDAT ;EXPECT SHIFT OUT INITIALLY
1924 017042 012704 032374          MOV      #BUFFER,R4  ;SET UP START ADRS IN R4
1925 017046 012724 100000          MOV      #100000,(R4)+ ;SET UP CHAR INSTR
1926 017052 012724 007000          MOV      #7000,(R4)+  ;SET UP SHIFT OUT CHAR
1927 017056 012724 163001          MOV      #163001,(R4)+ ;SET UP JSR REL + 4
1928 017062 012724 163000          MOV      #163000,(R4)+ ;SET UP JSR REL - THIS WILL FORCE SHIFT OUT BACK ON STK
1929 017066 012724 100000          MOV      #100000,(R4)+ ;SET UP CHAR INSTR TO COM SHIFT OUT
1930 017072 012724 000017          MOV      #17,(R4)+   ;SET UP CHAR LOC - SHIFT IN
1931 017076 012714 166000          MOV      #166000,(R4) ;SET UP POP & RESTORE INSTR
1932 017102 012777 020040 163166 1$:    MOV      #20040,@STKPT ;SET TOP OF STK
1933 017110 012777 032374 163126  MOV      #BUFFER,@DPC ;START
1934 017116 012704 000006          MOV      #6,R4       ;SET UP NPR CNTR
1935 017122 005277 163116          2$:    INC      @DPC        ;ADVANCE TO NEXT INSTR OR DATA
1936 017126 004537 024446          JSR      R5,DELAY    ;ALLOW TIME FOR EACH OPERATION TO COMPLETE
1937 017132 000004          BIT2     ;COUNT TO 4
1938 017134 005304          DEC      R4          ;COUNT THIS NPR
1939 017136 001371          BNE     2$          ;BR IF MORE NPRS
1940 017140 012777 020037 163130  MOV      #20037,@STKPT ;SET UP STK SEL
1941 017146 017737 163120 001126  MOV      @STKVAL,$BDDAT ;READ REG 26
1942 017154 042737 137777 001126  BIC      #137777,$BDDAT ;SAVE ONLY SHIFT OUT
1943 017162 023737 001124 001126  CMP      $GDDAT,$BDDAT ;IS IT CORRECT?
1944 017170 001401          BEQ      3$          ;BR IF SO
1945 017172 104061          ERROR    61          ;SHIFT OUT FAILED TO RESTORE
1946 017174 012737 000017 032376 3$:    MOV      #17,BUFFER+2 ;SET UP FOR NO SHIFT OUT
1947 017202 012737 000016 032406  MOV      #16,BUFFER+12 ;COMPLEMENT IT
1948 017210 162737 040000 001124  SUB      #40000,$GDDAT ;SET UP FOR RESET STATE
1949 017216 100331          BPL      1$          ;BR IF RESET STATE NOT TESTED
1950
1951

```

 *TEST 73 TEST THAT CHAR STRING ESCAPE ON TERMINATE CHAR WILL POP THE STACK

```

(3)
(3)
(2) 017220 000004          TST73: SCOPE
(1) 017222 012737 000010 001166  MOV      #10,$TIMES  ;;DO 10 ITERATIONS
(2) 017230 012737 000073 001206  MOV      #73,$TESTN  ;;SET TEST NUMBER IN APT MAIL BOX
1952 017236 012737 032400 001124  MOV      #BUFFER+4,$GDDAT ;EXPECT ADRS BUFFER+4 AFTER TERM CHAR
1953 017244 012737 176003 032374  MOV      #176003,BUFFER ;SET UP CHAR STRING ESCAPE INSTR
1954 017252 012737 163002 032376  MOV      #163002,BUFFER+2 ;SET UP JSR REL INSTR
1955 017260 012737 100000 032404  MOV      #100000,BUFFER+10 ;SET CHAR INSTR
1956 017266 012700 000377          MOV      #377,R0     ;START WITH MAX TERM CHAR VALUE
1957 017272 012777 020040 162776 1$:    MOV      #20040,@STKPT ;SET TOP OF STACK

```



```

1958 017300 010077 162770      MOV      R0,@TERMCH      ;SET UP TERM CHAR
1959 017304 010037 032406      MOV      R0,BUFFER+12    ;SET UP VALUE FOR INSTR
1960 017310 012777 032374 162726  MOV      #BUFFER,@DPC    ;START
1961 017316 012737 017272 001110  MOV      #1$, $LPERR     ;SET UP SCOPE LOOP ADRS
1962 017324 005277 162714      INC      @DPC            ;ADVANCE TO JSR REL INSTR
1963 017330 004537 024446      JSR      R5,DELAY        ;STALL FOR STACKING
1964 017334 000001                BIT0                     ;COUNT TO 1
1965 017336 005277 162702      INC      @DPC            ;RESUME - SHOULD PICK UP CHAR INSTR
1966 017342 013737 002244 001122  MOV      DPC,$BDADR      ;SET UP REG ADRS 00
1967 017350 005277 162670      INC      @DPC            ;RESUME - PICK UP TERM CHAR
1968 017354 004537 024446      JSR      R5,DELAY        ;STALL FOR POP
1969 017360 000020                BIT4                     ;COUNT TO 20
1970 017362 017737 162656 001126  MOV      @DPC,$BDDAT     ;READ DPC
1971 017370 023737 001124 001126  CMP      $GDDAT,$BDDAT   ;DID IT DO THE POP?
1972 017376 001401                BEQ      2$              ;BR IF SO
1973 017400 104062                ERROR    62             ;TERMINATE CHARACTER FAILED TO POP STACK
1974 017402 105300                2$:  DEC     R0           ;ADVANCE TO NEXT TERMINATE VALUE
1975 017404 100732                BMI     1$              ;BR IF MORE TO TEST
1976
1977
(3)
(3)
(2) 017406 000004
(2) 017410 012737 000074 001206  TST74: SCOPE
1978 017416 012737 032410 001124  MOV      #74,$TESTN      ;;SET TEST NUMBER IN APT MAIL BOX
1979 017424 012737 176002 032374  MOV      #BUFFER+14,$GDDAT ;EXPECT ADRS DPT3 AFTER TERM CHAR
1980 017432 012737 100000 032404  MOV      #176002,BUFFER  ;SET UP CHAR STRING ESCAPE INSTR-OFF
1981 017440 012737 000177 032406  MOV      #100000,BUFFER+10 ;SET UP CHAR INSTR
1982 017446 012777 000377 162620  MOV      #177,BUFFER+12  ;SET UP ASCII TERM CHAR
1983 017454 012777 020040 162614  MOV      #377,@TERMCH    ;SET UP TERM CHAR
1984 017462 012777 032374 162554  MOV      #20040,@STKPT   ;SET TOP OF STACK
1985 017470 012737 163002 032376  MOV      #BUFFER,@DPC    ;START
1986 017476 005277 162542      MOV      #163002,BUFFER+2 ;SET UP JSR REL
1987 017502 004537 024446      INC      @DPC            ;ADVANCE TO JSR INSTR
1988 017506 000001                JSR      R5,DELAY        ;STALL FOR STACKING
1989 017510 005277 162530      BIT0                     ;COUNT TO 1
1990 017514 013737 002244 001122  INC      @DPC            ;ADVANCE TO CHAR INSTR
1991 017522 005277 162516      MOV      DPC,$BDADR      ;SET UP REG ADRS 00
1992 017526 004537 024446      INC      @DPC            ;ADVANCE TO TERM CHAR
1993 017532 000020                JSR      R5,DELAY        ;STALL FOR POTENTIAL POP
1994 017534 017737 162504 001126  BIT4                     ;COUNT TO 20
1995 017542 023737 001124 001126  MOV      @DPC,$BDDAT     ;READ THE DPC
1996 017550 001401                CMP      $GDDAT,$BDDAT   ;IS IT CORRECT?
1997 017552 104062                BEQ      TST75           ;;GO TO NEXT TEST IF OK
1998 017552 104062                ERROR    62             ;TERM CHAR POPPED WHEN CHAR STRING TERM DISABLED
1999
(3)
(3)
(2) 017554 000004
(1) 017556 012737 000040 001166  TST75: SCOPE
(2) 017564 012737 000075 001206  MOV      #40,$TIMES      ;;DO 40 ITERATIONS
2000 017572 013701 001252      MOV      #75,$TESTN      ;;SET TEST NUMBER IN APT MAIL BOX
2001 017576 042701 160000      MOV      $VECT1,R1       ;GET BASIC VECTOR ADRS
2002 017602 012761 017724 000010  BIC      #160000,R1      ;CLR PSW BITS ** C **
2003 017610 012761 000340 000012  MOV      #2$,10(R1)      ;SET UP STK OVFL INT ADRS
2004 017616 013737 002256 001122  MOV      #340,12(R1)     ;SET UP PSW TO 7 ON INT
MOV      SREG1,$BDADR     ;SET UP REG 12 ADRS
    
```



```

2005 017624 012777 020040 162444      MOV    #20040,@STKPT  ;SET TOP OF STK
2006 017632 012700 000011          MOV    #11,R0        ;WILL COUNT TO OVFL IN R0
2007 017636 012737 020000 001124      MOV    #20000,$GDDAT ;WILL EXPECT STK OVFL
2008 017644 012737 163000 032374      MOV    #163000,BUFFER ;SET UP JSR INSTR
2009 017652 012737 000340 177776      1$:   MOV    #340,PSW      ;SET PSW TO 7
2010 017660 012777 032374 162356      MOV    #BUFFER,@DPC  ;START
2011 017666 004537 024446          JSR    R5,DELAY      ;STALL FOR STKING
2012 017672 000001          BITO                   ;COUNT TO 1
2013 017674 005037 177776          CLR    PSW           ;ALLOW INT TO OCCUR
2014 017700 005300          DEC    R0            ;COUNT THIS STK OPERATION
2015 017702 001363          BNE    1$           ;BR IF NOT TO STK OVFL LEVEL
2016 017704 017737 162346 001126      MOV    @SREG1,$BDDAT ;READ REG 12
2017 017712 042737 157777 001126      BIC    #157777,$BDDAT ;SAVE ONLY STK OVFL
2018 017720 104063          ERROR  63           ;STACK OVERFLOW FAILED TO INTERRUPT
2019 017722 000424          BR     4$           ;GO LOOK FOR LOOP ON TEST SWITCH
2020 017724 022626          2$:   CMP    (R6)+,(R6)+  ;FIX STK SINCE NO RTI
2021 017726 032777 020000 162322      BIT    #20000,@SREG1 ;SEE IF STK OVFL BIT SET
2022 017734 001004          BNE    3$           ;BR IF SO
2023 017736 005037 001126          CLR    $BDDAT       ;INDICATE OVFL BIT NOT SET
2024 017742 104063          ERROR  63           ;STACK OVERFLOW INTERRUPTED BUT NO FLAG
2025 017744 000413          BR     4$           ;LOOK FOR LOOP ON TEST SW
2026 017746 005037 001124          3$:   CLR    $GDDAT      ;EXPECT ZERO
2027 017752 000005          RESET                   ;CLR FLAG
2028 017754 032777 020000 162264      BIT    #20000,@SREG0 ;STILL SET?
2029 017762 001404          BEQ    4$           ;BR IF NOT
2030 017764 012737 020000 001126      MOV    #20000,$BDDAT ;INDICATE IT IS STILL SET
2031 017772 104063          ERROR  63           ;RESET FAILED TO CLR STACK OVERFLOW FLAG
2032 017774 004737 024646          4$:   JSR    PC,RSTVEC    ;RESTORE STK OVERFLOW VECTOR HALT
    
```

 : *TEST 76 TEST THAT STACK UNDERFLOW WILL CAUSE AN INTERRUPT
 : *****

```

(2) 020000 000004          TST76: SCOPE
(1) 020002 012737 000040 001166      MOV    #40,$TIMES    ;:DO 40 ITERATIONS
(2) 020010 012737 000076 001206      MOV    #76,$TESTN   ;:SET TEST NUMBER IN APT MAIL BOX
2035 020016 013701 001252          MOV    $VECT1,R1    ;:GET BASIC VECTOR ADRS
2036 020022 042701 160000          BIC    #160000,R1   ;: CLR PSW BITS          ** C **
2037 020026 012761 020150 000010      MOV    #2$,10(R1)   ;:SET UP STK UNDERFLOW INT ADRS
2038 020034 012761 000340 000012      MOV    #340,12(R1) ;:SET UP PSW TO 7 ON INT
2039 020042 013737 002256 001122      MOV    SREG1,$BDADR ;:SET UP REG 12 ADRS
2040 020050 012700 000011          MOV    #11,R0       ;:WILL COUNT TO UNDERFLOW IN R0
2041 020054 012777 020000 162214      MOV    #20000,@STKPT ;:SET STACK PTR TO ZERO
2042 020062 012737 010000 001124      MOV    #10000,$GDDAT ;:WILL EXPECT STK UNDERFLOW
2043 020070 012737 165000 032374      MOV    #165000,BUFFER ;:SET UP POP INSTR
2044 020076 012737 000340 177776      1$:   MOV    #340,PSW     ;:SET PSW TO 7
2045 020104 012777 032374 162132      MOV    #BUFFER,@DPC ;:START
2046 020112 004537 024446          JSR    R5,DELAY     ;:STALL FOR POPING
2047 020116 000001          BITO                   ;:COUNT TO 1
2048 020120 005037 177776          CLR    PSW           ;:ALLOW INT TO OCCUR
2049 020124 005300          DEC    R0            ;:COUNT THIS POP OPERATION
2050 020126 001363          BNE    1$           ;:BR IF NOT ST STK UNDERFLO LEVEL
2051 020130 017737 162122 001126      MOV    @SREG1,$BDDAT ;:READ REG 12
2052 020136 043737 167777 001126      BIC    167777,$BDDAT ;:SAVE ONLY STK UNDERFLOW
2053 020144 104064          ERROR  64           ;:STACK UNDERFLOW FAILED TO INTERRUPT
2054 020146 000424          BR     4$           ;:GO LOOK FOR LOOP ON TEST SWITCH
2055 020150 022626          2$:   CMP    (R6)+,(R6)+  ;:FIX STACK SINCE NO RTI
    
```



```

2056 020152 032777 010000 162076 BIT #10000,@SREG1 ;SEE IF STK UNDERFLOW BIT SET
2057 020160 001004 BNE 3$ ;BR IF SO
2058 020162 005037 001126 CLR $BDDAT ;INDICATE UNDERFLOW BIT NOT SET
2059 020166 104064 ERROR 64 ;STACK UNDERFLOW INTERRUPTED BUT NO FLAG
2060 020170 000413 BR 4$ ;GO LOOK FOR LOOP ON TEST SW
2061 020172 005037 001124 3$: CLR $GDDAT ;EXPECT ZERO
2062 020176 000005 RESET ;CLR FLAG
2063 020200 032777 010000 162040 BIT #10000,@SREG0 ;STILL SET?
2064 020206 001404 BEQ 4$ ;BR IF NOT
2065 020210 012737 010000 001126 MOV #10000,$BDDAT ;INDICATE IT IS STILL SET
2066 020216 104064 ERROR 64 ;RESET FAILED TO CLR STACK UNDERFLOW FLAG
2067 020220 004737 024646 4$: JSR PC,RSTVEC ;RESTORE STK UNDERFLOW VECTOR WITH HALT
2068
2069

```

```

(3)
(3)
(2) 020224 000004 TST77: SCOPE
(1) 020226 012737 000040 001166 MOV #40,$TIMES ;;DO 40 ITERATIONS
(2) 020234 012737 000077 001206 MOV #77,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
2070 020242 000005 RESET ;MAKE SURE ALL FLAGS ARE CLEARED
2071 020244 012737 020326 001110 MOV #1$,$LPERR ;SET UP SCOPE LOOP ADRS
2072 020252 013737 002250 001122 MOV XPOS,$BDADR ;SET UP REG ADRS 04
2073 020260 012700 032374 MOV #BUFFER,R0 ;GET INSTR ADRS POINTER
2074 020264 012720 154024 MOV #154024,(R0)+ ;SET UP UNITY VECTOR SCALE
2075 020270 012720 114000 MOV #114000,(R0)+ ;STORE POINT INSTR
2076 020274 005020 CLR (R0)+ ;X=0
2077 020276 005020 CLR (R0)+ ;Y=0
2078 020300 012720 110000 MOV #110000,(R0)+ ;STORE LONG VECTOR INSTR
2079 020304 005020 CLR (R0)+ ;X TO BE UPDATED
2080 020306 005020 CLR (R0)+ ;Y=0
2081 020310 012710 172000 MOV #172000,(R0) ;STORE STOP INSTR
2082 020314 012700 000001 MOV #1,R0 ;R0 CONTAINS X VECTOR LENGTH
2083 020320 012737 000001 001124 MOV #1,$GDDAT ;CONTAINS EXPECTED DELTA LENGTH
2084 020326 010037 032406 1$: MOV R0,BUFFER+12 ;SET UP NEXT VECTOR LENGTH
2085 020332 004537 025044 JSR R5,EXECUTE ;GO START DISPLAY
2086 020336 000007 7 ;RESUME COUNT
2087
2088 020340 017737 161704 001126 MOV @XPOS,$BDDAT ;DELTA LENGTH READ BACK FROM X POSITION REG
2089 020346 023737 001124 001126 CMP $GDDAT,$BDDAT ;IS IT CORRECT?
2090 020354 001403 BEQ 2$ ;BR IF SO
2091 020356 010037 001164 MOV R0,$TMP0 ;SET UP X VECTOR LENGTH FOR ER TYPE
2092 020362 104065 ERROR 65 ;X DELTA LENGTH INCORRECT
2093 020364 005237 001124 2$: INC $GDDAT ;BUMP EXPECTED DELTA LENGTH
2094 020370 005200 INC R0 ;ADVANCE TO NEXT X VECTOR VALUE
2095 020372 032700 002000 BIT #2000,R0 ;HAVE WE DONE 10 BITS?
2096 020376 001753 BEQ 1$ ;BR IF NOT
2097
2098

```

```

(3)
(3)
(2) 020400 000004 TST100: SCOPE
(1) 020402 012737 000040 001166 MOV #40,$TIMES ;;DO 40 ITERATIONS
(2) 020410 012737 000100 001206 MOV #100,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
2099 020416 012737 020502 001110 MOV #1$,$LPERR ;SET UP SCOPE LOOP ADRS
2100 020424 013737 002252 001122 MOV YPOS,$BDADR ;SET UP REG ADRS 06
2101 020432 012700 032374 MOV #BUFFER,R0 ;GET INSTR ADRS POINTER

```



```

2102 020436 012720 154024      MOV    #154024,(R0)+    ;SET UP UNITY VECTOR SCALE
2103 020442 012720 114000      MOV    #114000,(R0)+    ;STORE POINT INSTR
2104 020446 005020                CLR    (R0)+            ;X=0
2105 020450 012720 001777      MOV    #1777,(R0)+      ;Y=1777
2106 020454 012720 110000      MOV    #110000,(R0)+    ;STORE LONG VECTOR INSTR
2107 020460 005020                CLR    (R0)+            ;X=0
2108 020462 005020                CLR    (R0)+            ;Y TO BE UPDATED
2109 020464 012710 172000      MOV    #172000,(R0)     ;STORE STOP INSTR
2110 020470 012700 020001      MOV    #20001,R0        ;R0 CONTAINS Y VECTOR LENGTH (DRAW TOP TO BOTTOM)
2111 020474 012737 000001 001124  MOV    #1,$GDDAT        ;CONTAINS EXPECTED Y DELTA LENGTH
2112 020502 010037 032410 1$:  MOV    R0,BUFFER+14     ;SET UP NEXT VECTOR LENGTH
2113 020506 004537 025044      JSR    R5,EXECUTE       ;GO START DISPLAY
2114 020512 000007                7                        ;RESUME COUNT
2115
2116 020514 017737 161532 001126  MOV    @YPOS,$BDDAT     ;DELTA LENGTH READ BACK FROM Y POSITION REG
2117 020522 023737 001124 001126  CMP    $GDDAT,$BDDAT    ;IS IT CORRECT?
2118 020530 001403                BEQ    2$               ;BR IF SO
2119 020532 010037 001164      MOV    R0,$TMP0         ;SET UP Y VECTOR LENGTH FOR ER TYPE
2120 020536 104065                ERROR  65               ;Y DELTA LENGTH INCORRECT
2121 020540 005237 001124 2$:  INC    $GDDAT           ;BUMP EXPECTED DELTA LENGTH
2122 020544 005200                INC    R0                ;ADVANCE TO NEXT Y VECTOR VALUE
2123 020546 032700 002000      BIT    #2000,R0         ;HAVE WE DONE 10 BITS?
2124 020552 001753                BEQ    1$               ;BR IF NOT
2125
2126

```

 : *TEST 101 TEST THAT DELTA LENGTH FOLLOWS THE LONGER OF X OR Y WITH MAINT SW3 SET
 : *****

```

(3)
(3)
(2) 020554 000004      TST101: SCOPE
(1) 020556 012737 000040 001166  MOV    #40,$TIMES      ;;DO 40 ITERATIONS
(2) 020564 012737 000101 001206  MOV    #101,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX
2127 020572 012737 020652 001110  MOV    #1,$LPERR      ;SET UP SCOPE LOOP ADRS
2128 020600 013702 002252      MOV    YPOS,R2        ;R2 CONTAINS REG ADRS OF DELTA (X OR Y POS REG)
2129 020604 012700 032374      MOV    #BUFFER,R0     ;GET INSTR ADRS POINTER
2130 020610 012720 154024      MOV    #154024,(R0)+  ;SET UP UNITY VECTOR SCALE
2131 020614 012720 114000      MOV    #114000,(R0)+  ;STORE POINT INSTR
2132 020620 005020                CLR    (R0)+          ;X=0
2133 020622 005020                CLR    (R0)+          ;Y=0
2134 020624 012720 110000      MOV    #110000,(R0)+  ;STORE LONG VECTOR INSTR
2135 020630 005020                CLR    (R0)+          ;X TO BE UPDATED
2136 020632 005020                CLR    (R0)+          ;Y TO BE UPDATED
2137 020634 012710 172000      MOV    #172000,(R0)   ;STORE STOP INSTR
2138 020640 012700 001777      MOV    #1777,R0       ;R0 CONTAINS Y VECTOR LENGTH
2139 020644 005001                CLR    R1              ;R1 CONTAINS X VECTOR LENGTH
2140 020646 010037 001124 1$:  MOV    R0,$GDDAT      ;CONTAINS EXPECTED DELTA LENGTH
2141 020652 010037 032410      MOV    R0,BUFFER+14   ;SET UP Y VECTOR LENGTH (1777 TO 0)
2142 020656 010137 032406      MOV    R1,BUFFER+12   ;SET UP X VECTOR LENGTH (0 TO 1777)
2143 020662 004537 025044      JSR    R5,EXECUTE     ;GO START DISPLAY
2144 020666 000007                7                        ;RESUME COUNT
2145
2146 020670 010237 001122      MOV    R2,$BDADR      ;SET UP REG ADRS WHERE DELTA IS
2147 020674 011237 001126      MOV    (R2),$BDDAT    ;GREATER OF X OF Y DELTA READ FROM X OR Y POS REG
2148 020700 023737 001124 001126  CMP    $GDDAT,$BDDAT  ;IS IT CORRECT?
2149 020706 001404                BEQ    2$               ;BR IF SO
2150 020710 013737 001124 001164  MOV    $GDDAT,$TMP0   ;SET UP LONGEST X OR Y VECTOR LENGTH FOR ER TYPE
2151 020716 104065                ERROR  65               ;DELTA LENGTH DOES N.C. EQUAL LONGER OF X OR Y
2152 020720 005300 2$:  DEC    R0              ;DECREASE Y VECTOR VALUE BY 1

```



```

2153 020722 100413      BMI    TST102      ;;TO NEXT TEST IF 10 BITS OF X & Y HAVE BEEN TESTED.
2154 020724 005201      INC    R1          ;;INCREASE X VECTOR VALUE BY 1
2155 020726 020001      CMP    R0,R1      ;;LOOK FOR THE LARGEST OF X OR Y
2156 020730 101005      BHI   3$          ;;BR IF Y VECTOR STILL GREATER THAN X
2157 020732 013702 002250  MOV    XPOS,R2    ;;NOW DELTA WILL BE IN XPOS
2158 020736 010137 001124  MOV    R1,$GDDAT  ;;DELTA LENGTH WILL BE THAT OF X VECTOR
2159 020742 000743      BR    1$          ;;TRY NEXT VECTOR COMBINATION
2160 020744 010037 001124  3$:   MOV    R0,$GDDAT  ;;DELTA LENGTH WILL BE THAT OF Y VECTOR
2161 020750 000740      BR    1$          ;;TRY NEXT VECTOR COMBINATION
    
```

```

2162
2163
(3) *****
;*TEST 102      CHECK TANGENT WHEN INCREMENTING Y AT 1777 X WITH MAINT SW3 SET
(3) *****
    
```

```

(2) 020752 000004      TST102: SCOPE
(1) 020754 012737 000040 001166  MOV    #40,$TIMES      ;;DO 40 ITERATIONS
(2) 020762 012737 000102 001206  MOV    #102,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX
2164 020770 012737 021056 001110  MOV    #2$,$LPERR     ;;SET UP SCOPE LOOP ADRS
2165 020776 013702 002252      MOV    YPOS,R2       ;;R2 CONTAINS REG ADRS OF TANGENT (X OR Y POS REG)
2166 021002 013701 002262      MOV    YDOFF,R1      ;;R1 CONTAINS REG ADRS OF HI ORDER TANGENT
2167 021006 012700 032374      MOV    #BUFFER,R0    ;;GET INSTR ADRS POINTER
2168 021012 012720 154024      MOV    #154024,(R0)+  ;;SET UP UNITY VECTOR SCALE
2169 021016 012720 114000      MOV    #114000,(R0)+  ;;STORE POINT INSTR
2170 021022 005020      CLR    (R0)+         ;;X=0
2171 021024 005020      CLR    (R0)+         ;;Y=0
2172 021026 012720 110000      MOV    #110000,(R0)+  ;;STORE LONG VECTOR INSTR
2173 021032 012720 001777      MOV    #1777,(R0)+   ;;X=1777
2174 021036 005020      CLR    (R0)+         ;;Y TO BE UPDATED
2175 021040 012710 172000      MOV    #172000,(R0)  ;;STORE STOP INSTR
2176 021044 005000      CLR    R0            ;;R0 CONTAINS INCREMENTING Y VECTOR LENGTH (0-1777)
2177 021046 010037 032410 1$:   MOV    R0,BUFFER+14  ;;SET UP Y VECTOR LENGTH (0-1777)
2178 021052 004737 024732      JSR   PC,CALTAN     ;;GO FIGURE OUT WHAT TAN SHOULD BE
2179 021056 004537 025044 2$:   JSR   R5,EXECUTE    ;;GO START DISPLAY
2180 021062 000007      7                ;;RESUME COUNT
    
```

```

2181
2182 021064 010237 001122      MOV    R2,$BDADR     ;;SET UP REG ADRS WHERE TANGENT IS
2183 021070 011237 001126      MOV    (R2),$BDDAT   ;;TANGENT IS READ FROM X OR Y POSITION REG
2184 021074 011105      MOV    (R1),R5       ;;READ HI ORDER TANGENT BITS
2185 021076 004737 024706      JSR   PC,TANCON     ;;GO MAKE UP 12 BIT TANGENT
2186 021102 023737 001124 001126  CMP    $GDDAT,$BDDAT  ;;IS IT CORRECT?
2187 021110 001403      BEQ   3$            ;;BR IF SO
2188 021112 010037 001164      MOV    R0,$TMP0     ;;SET UP Y VECTOR LENGTH FOR ER TYPE
2189 021116 104066      ERROR 66           ;;INCORRECT TANGENT FOR X & Y VALUE INDICATED
2190 021120 005200      3$:   INC    R0          ;;INCREASE X VECTOR VALUE BY 1
2191 021122 022700 001777      CMP    #1777,R0     ;;R0 UP TO 1777 YET?
2192 021126 101347      BHI   1$            ;;BR IF NOT
2193 021130 103405      BCS   TST103       ;;NEXT TEST IF R0 = 2000
2194 021132 013702 002250      MOV    XPOS,R2      ;;TANGENT WILL NOW BE IN XPOS
2195 021136 013701 002260      MOV    XDOFF,R1     ;;HI ORDER TANGENT BITS NOW IN XDOFF
2196 021142 000741      BR    1$            ;;ONE MORE TIME
    
```

```

2197
2198
(3) *****
;*TEST 103      CHECK TANGENT WHEN INCREMENTING X AT 1777 Y WITH MAINT SW3 SET
(3) *****
    
```

```

(2) 021144 000004      TST103: SCOPE
(1) 021146 012737 000040 001166  MOV    #40,$TIMES      ;;DO 40 ITERATIONS
(2) 021154 012737 000103 001206  MOV    #103,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX
    
```



```

2199 021162 012737 021250 001110 MOV #2$, $LPERR ;SET UP SCOPE LOOP ADRS
2200 021170 013702 002250 MOV XPOS, R2 ;R2 CONTAINS REG ADRS OF TANGENT (X OR Y POS REG)
2201 021174 013701 002260 MOV XDOFF, R1 ;R1 CONTAINS REG ADRS OF HI ORDER TANGENT
2202 021200 012700 032374 MOV #BUFFER, R0 ;GET INSTR ADRS POINTER
2203 021204 012720 154024 MOV #154024, (R0)+ ;SET UP UNITY VECTOR SCALE
2204 021210 012720 114000 MOV #114000, (R0)+ ;STORE POINT INSTR
2205 021214 005020 CLR (R0)+ ;X=0
2206 021216 005020 CLR (R0)+ ;Y=0
2207 021220 012720 110000 MOV #110000, (R0)+ ;STORE LONG VECTOR INSTR
2208 021224 005020 CLR (R0)+ ;X TO BE UPDATED
2209 021226 012720 001777 MOV #1777, (R0)+ ;Y=1777
2210 021232 012710 172000 MOV #172000, (R0) ;STORE STOP INSTR
2211 021236 005000 CLR R0 ;R0 CONTAINS INCREMENTING X VECTOR LENGTH (0-1777)
2212 021240 010037 032406 1$: MOV R0, BUFFER+12 ;SET UP X VECTOR LENGTH (0-1777)
2213 021244 004737 024732 JSR PC, CALTAN ;GO FIGURE OUT WHAT TAN SHOULD BE
2214 021250 004537 025044 2$: JSR R5, EXECUTE ;GO START DISPLAY
2215 021254 000007 7 ;RESUME COUNT
2216
2217 021256 010237 001122 MOV R2, $BDADR ;SET UP REG ADRS WHERE TANGENT IS
2218 021262 011237 001126 MOV (R2), $BDDAT ;TANGENT IS READ FROM X OR Y POSITION REG
2219 021266 011105 MOV (R1), R5 ;READ HI ORDER TANGENT BITS
2220 021270 004737 024706 JSR PC, TANCON ;GO MAKE UP 12 BIT TANGENT
2221 021274 023737 001124 001126 CMP $GDDAT, $BDDAT ;IS IT CORRECT?
2222 021302 001403 BEQ 3$ ;BR IF SO
2223 021304 010037 001164 MOV R0, $TMP0 ;SET UP X VECTOR LENGTH FOR ER TYPE
2224 021310 104066 ERROR 66 ;INCORRECT TANGENT FOR X & Y VALUE INDICATED
2225 021312 005200 3$: INC R0 ;INCREASE Y VECTOR VALUE BY 1
2226 021314 022700 002000 CMP #2000, R0 ;R0 UP TO 2000 YET?
2227 021320 001347 BNE 1$ ;BR IF NOT
2228
2229

```

```

(3) ;*****
(3) ;*TEST 104 TEST THAT DPC BITS 16 & 17 WILL SET & RESET
(2) ;*****
(1) 021322 000004 TST104: SCOPE
(2) 021324 012737 000040 001166 MOV #40, $TIMES ;DO 40 ITERATIONS
2230 021332 012737 000104 001206 MOV #104, $TESTN ;SET TEST NUMBER IN APT MAIL BOX
2231 021340 012737 000060 001124 MOV #60, $GDDAT ;EXPECT BOTH BITS INITIALLY
2232 021346 012700 006000 MOV #6000, R0 ;PUT RELOCATE VALUE IN R0
2233 021352 012737 021360 001110 MOV #1$, $LPERR ;SET UP SCOPE LOOP ADRS
2234 021360 012777 010000 160710 1$: MOV #MAINT1, @STKPT ;SET MAINT SW 1
2235 021366 010077 160662 MOV R0, @RLO ;SET UP RELOCATE VALUE
2236 021372 005077 160646 CLR @DPC ;SET UP DPC ADRS & START DISPLAY
2237 021376 013737 002256 001122 MOV $REG1, $BDADR ;SET UP REG ADRS 12
2238 021404 017737 160646 001126 MOV @SREG1, $BDDAT ;READ REG 12
2239 021412 042737 177717 001126 BIC #177717, $BDDAT ;SAVE ONLY DPC BITS 17 & 16
2240 021420 023737 001124 001126 CMP $GDDAT, $BDDAT ;ARE THEY CORRECT?
2241 021426 001401 BEQ 2$ ;BR IF OK
2242 021430 104067 ERROR 67 ;RELOCATE VALUE FAILED TO SET UP DPC 16 OR 17
2243 021432 162737 000020 001124 2$: SUB #20, $GDDAT ;SET UP NEXT ADRS VALUE AT EXPECTED LOC
2244 021440 162700 002000 SUB #2000, R0 ;SET UP NEXT ADRS VALUE AT R0
2245 021444 100345 BPL 1$ ;BR IF MORE ADRS TO TEST
2246 021446 005037 001110 CLR $LPERR ;NO RESET SCOPE LOOP
2247 021452 005037 001124 CLR $GDDAT ;EXPECT ZERO
2248 021456 012777 006000 160570 MOV #6000, @RLO ;SET BOTH BITS
2249 021464 005077 160554 CLR @DPC ;CLR DPC & START - NO NPR
2249 021470 000005 RESET ;CLR DPC 16 & 17

```



```

2250 021472 017737 160560 001126      MOV    @SREG1,$BDDAT    ;READ REG 12
2251 021500 042737 177717 001126      BIC    #177717,$BDDAT  ;SAVE ONLY DPC 16 & 17
2252 021506 001401                BEQ    3$              ;BR IF CLEARED
2253 021510 104067                ERROR  67              ;RESET FAILED TO CLEAR DPC 16 OR 17
2254 021512 005077 160536      3$:    CLR    @RLO        ;CLR RELOCATE REG BEFORE ADVANCING
2255
2256      ;*****
(3)      ;*TEST 105      TEST THAT DPC GETS PUSHED ONTO STACK AT HIGHEST BOUNDRY BELOW 28K
(3)      ;*****
(2)      TST105: SCOPE
(2) 021516 000004                MOV    #105,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX
2257 021520 012737 000105 001206      TST    CENAB          ;DO WE HAVE MORE THAN 8K?
2258 021532 001477                BEQ    TST106         ;IF NOT - NEXT TEST
2259 021534 012737 021620 001110      1$:    MOV    #3$,$LPERR   ;SET UP SCOPE LOOP ADRS
2260 021542 013737 002272 001122      MOV    STKVAL,$BDADR  ;SET UP REG 26 ADRS
2261 021550 005002                CLR    R2             ;CLR ADRS ROTATIONAL VALUE
2262 021552 013700 002214                MOV    MEMMAX,R0      ;GET LAST 4K MEM BLK
2263 021556 010001                MOV    R0,R1          ;PUT IT INTO R1
2264 021560 010003                MOV    R0,R3          ;PUT IT INTO R3 ALSO
2265 021562 062701 020000                ADD    #20000,R1      ;POINT TO 1ST NON-EXISTENT MEM ADRS IN R1
2266 021566 012704 020040 001164      2$:    MOV    #20040,R4     ;SET UP TOP OF STACK INITIALLY IN R4
2267 021572 012737 000034                MOV    #34,$TMP0     ;SET UP STACK LEVEL WHERE JSR'ED DPC IS STORED
2268 021600 010337 001124                MOV    R3,$GDDAT     ;SAVE EXPECTED JSR RETURN ADRS OF STK
2269 021604 162703 000002                SUB    #2,R3          ;REDUCE ADRS BY 2 TO ALLOW FOR JSR REL INSTR
2270 021610 011337 002210                MOV    (R3),LDRSV1   ;SAVE LOCATION
2271 021614 012713 163400                MOV    #163400,(R3)  ;LOAD UP JSR REL INSTR
2272 021620 010477 160452                3$:    MOV    R4,@STKPT    ;SET STK PTR
2273 021624 010377 160414                MOV    R3,@DPC       ;START AT ADRS IN R3
2274 021630 004537 024446                JSR    R5,DELAY      ;STALL FOR STACKING
2275 021634 000001                BIT0
2276 021636 013777 001164 160432      MOV    $TMP0,@STKPT  ;SEL STK LEVEL OF STORED DPC
2277 021644 017737 160422 001126      MOV    @STKVAL,$BDDAT ;READ STORED JSR RETURN ADRS
2278 021652 023737 001124 001126      CMP    $GDDAT,$BDDAT ;IS IT CORRECT?
2279 021660 001401                BEQ    4$             ;BR IF SO
2280 021662 104005                ERROR  5              ;JSR REL FAILED TO PUSH ON STK THE RETURN ADRS
2281 021664 162704 000004 001164      4$:    SUB    #4,R4          ;ADVANCE TO NEXT STK LEVEL
2282 021670 162737 000004                SUB    #4,$TMP0      ;HAVE ALL 8 LEVELS BEEN TESTED?
2283 021676 100350                BPL    3$             ;BR IF NOT
2284 021700 013713 002210                MOV    LDRSV1,(R3)   ;RESTORE MEM LOC
2285 021704 005702                TST    R2             ;IS THIS THE 1ST ADRS PASS?
2286 021706 001003                BNE    5$             ;BR IF NOT
2287 021710 012702 000002                MOV    #2,R2         ;SET UP ADRS ROTATIONAL FACTOR IN R2
2288 021714 000401                BR     6$             ;THIS TIME DON'T ROTATE
2289 021716 006302                5$:    ASL    R2           ;SELECT NEXT ADRS BIT TO LEFT
2290 021720 010003                6$:    MOV    R0,R3      ;GET HIGHEST ADRS BOUNDRY
2291 021722 060203                ADD    R2,R3          ;ADD IN NEXT ADRS BIT FOR TEST
2292 021724 103402                BCS    TST106         ;TO NEXT TEST IF ADRS GREATER THAN 16 BITS
2293 021726 020103                CMP    R1,R3          ;IS THERE ROOM FOR THIS ADRS BIT?
2294 021730 103316                BCC    2$             ;BR IF SO
2295
2296      ;*****
(3)      ;*TEST 106      TEST THAT DPC GETS RESTORED FROM STACK AT HIGHEST BOUNDRY BELOW 28K
(3)      ;*****
(2)      TST106: SCOPE
(2) 021732 000004                MOV    #106,$TESTN   ;;SET TEST NUMBER IN APT MAIL BOX
2297 021742 005737 000106 001206      TST    CENAB          ;DO WE HAVE MORE THAN 8K?
    
```



```

2298 021746 001516          BEQ     TST107          ;; IF NOT - NEXT TEST
2299 021750 012737 022050 001110 1$:    MOV     #3$, $LPERR    ; SET UP SCOPE LOOP ADRS
2300 021756 005002          CLR     R2             ; CLR ADRS ROTATIONAL VALUE
2301 021760 013700 002214          MOV     MEMMAX, R0     ; GET LAST 4K MEM BLK
2302 021764 010001          MOV     R0, R1         ; PUT IT INTO R1
2303 021766 010003          MOV     R0, R3         ; PUT IT INTO R3 ALSO
2304 021770 062701 020000          ADD     #20000, R1     ; POINT TO 1ST NON-EXISTENT MEM ADRS IN R1
2305 021774 012737 166000 032374          MOV     #166000, BUFFER ; SET UP POP INSTR IN LOWEST 8K
2306 022002 012704 020040 2$:    MOV     #20040, R4     ; SET TOP OF STACK INITIALLY IN R4
2307 022006 012737 000034 001164          MOV     #34, $TMP0    ; SET UP STK LEVEL WHERE JSR'ED DPC IS STORED
2308 022014 010337 001124          MOV     R3, $GDDAT    ; SAVE EXPECTED JSR RETURN ADRS
2309 022020 162703 000004          SUB     #4, R3        ; REDUCE ADRS BY 4 TO ALLOW FOR JSR ABS INSTR
2310 022024 011337 002210          MOV     (R3), LDRSV1  ; SAVE LOCATION
2311 022030 016337 000002 002212          MOV     2(R3), LDRSV2 ; SAVE LOCATION
2312 022036 012713 162000          MOV     #162000, (R3) ; LOAD UP JSR ABS INSTR
2313 022042 012763 032374 000002          MOV     #BUFFER, 2(R3) ; LOAD UP ABS ADRS TO POP INSTR IN LOWEST 8K
2314 022050 010477 160222 3$:    MOV     R4, @STKPT    ; SET UP CURRENT STACK LEVEL
2315 022054 010377 160164          MOV     R3, @DPC     ; START AT ADRS IN R3
2316 022060 013737 002244 001122          MOV     DPC, $BDADR  ; SET UP REG ADRS 00
2317 022066 005277 160152          INC     @DPC          ; PICK UP ABS ADRS (POP INSTR ADRS)
2318 022072 004537 024446          JSR     R5, DELAY    ; DELAY FOR STACKING
2319 022076 000001          BIT0           ; COUNT TO ONE
2320 022100 005277 160140          INC     @DPC          ; PICK UP POP INSTR
2321 022104 004537 024446          JSR     R5, DELAY    ; STALL FOR POPPING
2322 022110 000001          BIT0           ; COUNT TO ONE
2323 022112 017737 160126 001126          MOV     @DPC, $BDDAT ; GET RETURN ADRS FOR DPC
2324 022120 023737 001124 001126          CMP     $GDDAT, $BDDAT ; IS IT CORRECT?
2325 022126 001401          BEQ     4$          ; BR IF SO
2326 022130 104035          ERROR    35         ; DPC FAILED TO RESTORE AT ADRS & STK LEVEL INDICATED
2327 022132 162704 000004 4$:    SUB     #4, R4        ; SET UP NEXT STK SELECTION LEVEL
2328 022136 162737 000004 001164          SUB     #4, $TMP0    ; HAVE WE GONE THRU 8 LEVELS THIS ADRS
2329 022144 100341          BPL     3$          ; BR IF NOT
2330 022146 013723 002210          MOV     LDRSV1, (R3)+ ; RESTORE MEM LOC
2331 022152 013713 002212          MOV     LDRSV2, (R3) ; RESTORE MEM LOC
2332 022156 005702          TST     R2           ; IS THIS THE 1ST ADRS PASS?
2333 022160 001003          BNE     5$          ; BR IF NOT
2334 022162 012702 000002          MOV     #2, R2       ; SET UP ADRS ROTATIONAL FACTOR IN R2
2335 022166 000401          BR      6$          ; THIS TIME DON'T ROTATE
2336 022170 006302 5$:    ASL     R2           ; SELECT NEXT ADRS BIT TO LEFT
2337 022172 010003 6$:    MOV     R0, R3       ; GET HIGHEST 4K BOUNDARY ADRS
2338 022174 060203          ADD     R2, R3       ; ADD IN NEXT ADRS BIT FOR TEST
2339 022176 103402          BCS     TST107      ; TO NEXT TEST IF ADRS GREATER THAN 16 BITS
2340 022200 020103          CMP     R1, R3       ; IS THERE ROOM FOR THIS ADRS BIT?
2341 022202 103277          BCC     2$          ; BR AND EXERCISE THIS BIT IF SO

```

```

2342
2343  ;:*****
(3)  ;: *TEST 107 TEST THAT THE VS60 CAN OPERATE ABOVE 28K
(3)  ;:*****
(2)  022204 000004 TST107: SCOPE
(1)  022206 012737 000040 001166 MOV #40, $TIMES ;; DO 40 ITERATIONS
(2)  022214 012737 000107 001206 MOV #107, $TESTN ;; SET TEST NUMBER IN APT MAIL BOX
2344
2345 ;: THIS TEST USES THE GRAPHLOT INCREMENT PART OF THE 'LOAD STATUS B'
2346 ;: INSTR TO HOLD THE CURRENT 4K MEMORY BLOCK ADRS BEING ADDRESSED
2347 ;: ABOVE 28K. THE 6 BITS OF THE GRAPHLOT HAVE THE FOLLOWING RELATIONSHIP:
2348 ;: 16=32K, 20=36K, 22=40K, 24=44K, ETC. UP TO 76=128K. THE VS60 PREFORMS

```



```

2349                                     :THE FOLLOWING INSTRS IN EA 4K BLK ABOVE 28K - JSR,POP & 'LOAD STATUS
2350                                     :B' (LD GRAPHLOT INC). AN ERROR IS REPORTED IF THE GRAPHLOT VALUE
2351                                     :RECEIVED IS DIFFERENT THAN THE VALUE WRITTEN TO THE 4K BLK UNDER TEST.
2352
2353 022222 005737 002220                TST      KTENAB      ;DO WE HAVE UPPER CORE?
2354 022226 001547                      BEQ      TST110     ;;IF NOT GO TO NEXT TEST
2355 022230 100437                      1$: BMI    3$      ;BR IF MEM ALREADY LOADED WITH DISPLAY CODE
2356 022232 052737 100000 002220        BIS     #100000,KTENAB ;DO IT 1ST TIME ONLY
2357 022240 012777 001600 157766        MOV     #1600,@KIPAR2 ;START AT 28K
2358 022246 012701 174116                MOV     #174116,R1   ;GRAPHLOT VALUE WILL CONTAIN 4K MEM BLK NO
2359 022252 012700 040000                2$: MOV     #40000,R0 ;USE ADRS ZERO & KIPAR2
2360 022256 052737 001400 177572        BIS     #1400,@#KTSR0 ;ENABLE KT MAINT MODE
2361 022264 012720 163001                MOV     #163001,(R0)+ ;SET UP JSR REL INSTR
2362 022270 010120                      MOV     R1,(R0)+    ;SET UP LOAD STATUS B INSTR
2363 022272 012710 166000                MOV     #166000,(R0) ;SET UP POP INSTR
2364 022276 042737 001400 177572        BIC     #1400,@#KTSR0 ;DISABLE KT
2365 022304 027737 157724 002222        CMP     @KIPAR2,KTMAX ;HAS INSTR CODE BEEN LOADED THRU CODE
2366 022312 001406                      BEQ     3$      ;BR IF SO
2367 022314 062777 000200 157712        ADD     #200,@KIPAR2 ;ADVANCE TO NEXT 4K BLK
2368 022322 062701 000002                ADD     #2,R1      ;RECORDED MEM BLK IN GRAPHLOT INC INSTR
2369 022326 000751                      BR      2$      ;GO SET UP INSTRS IN NEXT 4K BLK OF CORE
2370 022330 012777 001600 157676        3$: MOV     #1600,@KIPAR2 ;SET UP 28K ADRS
2371 022336 005077 157712                4$: CLR     @RLO     ;CLR RELOCATE REG
2372 022342 017700 157666                MOV     @KIPAR2,R0  ;GET CURRENT 4K BLK ADRS
2373 022346 004737 024576                JSR     PC,DPCONV   ;GO CONVERT 4K BLK ADRS INTO 18 BIT ADRS
2374 022352 010037 001124                MOV     R0,$GDDAT  ;SAVE 16 BIT ADRS
2375 022356 010137 002224                MOV     R1,G1716   ;SAVE ADRS BITS 17 & 16
2376 022362 006201                      ASR     R1          ;NOW SET UP RELOCATION REG
2377 022364 103003                      BCC     5$      ;BR IF ADRS BIT 16 IS NOT SET
2378 022366 052777 002000 157660        BIS     #2000,@RLO  ;SET UP RELOCATION REG BIT 10
2379 022374 006201                      5$: ASR     R1      ;LOOK AT ADRS BIT 17
2380 022376 103003                      BCC     6$      ;BR IF ADRS BIT 17 IS NOT SET
2381 022400 052777 004000 157646        BIS     #4000,@RLO  ;SET UP RELOCATION REG BIT 11
2382 022406 012777 020040 157662        6$: MOV     #20040,@STKPT ;SET TOP OF STACK
2383 022414 013777 001124 157622        MOV     $GDDAT,@DPC ;START
2384 022422 004537 024446                JSR     R5,DELAY    ;GO STALL FOR STACKING
2385 022426 000001                      BITO    ;COUNT TO 1
2386 022430 005277 157610                INC     @DPC       ;RESUME
2387 022434 004537 024446                JSR     R5,DELAY    ;GO STALL FOR POPPING
2388 022440 000001                      BITO    ;COUNT TO 1
2389 022442 005277 157576                INC     @DPC       ;RESUME
2390 022446 012737 022406 001110        MOV     #6$,$LPERR  ;SET UP SCOPE LOOP ADRS
2391 022454 005001                      CLR     R1        ; CLR HI ORDER BITS ** C **
2392 022456 017700 157566                MOV     @XPOS,R0   ;GET ADRS BLK FROM GRAPHLOT INC BITS
2393 022462 042700 001777                BIC     #1777,R0   ;SAVE ONLY ADRS BLK INFORMATION READ
2394 022466 004737 024610                JSR     PC,DPCON1  ;GO CONVERT BLK ADRS TO A 18 BIT ADRS
2395 022472 010037 001126                MOV     R0,$BDDAT  ;SAVE 16 BIT ADRS READ
2396 022476 010137 002226                MOV     R1,B1716  ;SAVE ADRS BIT 17 & 16
2397 022502 023737 001124 001126        CMP     $GDDAT,$BDDAT ;IS THE 16 BIT ADRS CORRECT?
2398 022510 001004                      BNE     7$      ;BR IF NOT
2399 022512 023737 002224 002226        CMP     G1716,B1716 ;ADRS BIT 17 & 16 CORRECT?
2400 022520 001401                      BEQ     8$      ;BR IF SO
2401 022522 104070                      7$: ERROR 70      ;VS60 FAILED TO EXECUTE INSTRS AT ADRS INDICATED
2402 022524 062777 000200 157502        8$: ADD     #200,@KIPAR2 ;SET NEXT 4K BLK
2403 022532 027737 157476 002222        CMP     @KIPAR2,KTMAX ;HAS INSTR CODE BEEN EXECUTED IN ALL 4K AVAIL BLKS?
2404 022540 101676                      BLOS   4$      ;BR IF NOT

```



```

2405 022542 005077 157506 CLR @RLO ;INSURE RELOCATE REG 0 BEFORE ADVANCING
2406
2407
(3)
(3)
(2) 022546 000004
(1) 022550 012737 000040 001166
(2) 022556 012737 000110 001206
2408 022564 012700 032374
2409 022570 012720 152525
2410 022574 012720 155661
2411 022600 012720 164374
2412 022604 012720 164750
2413 022610 012720 170063
2414 022614 012720 175200
2415 022620 012720 112235
2416 022624 005020
2417 022626 005020
2418 022630 012720 164000
2419 022634 012720 151252
2420 022640 012720 155322
2421 022644 012720 164270
2422 022650 012720 164674
2423 022654 012720 170042
2424 022660 012720 175400
2425 022664 012720 146426
2426 022670 005020
2427 022672 005020
2428
2429 022674 012720 164000
2430 022700 012720 153070
2431 022704 012720 155664
2432 022710 012720 164374
2433 022714 012720 164750
2434 022720 012720 170063
2435 022724 012720 175200
2436 022730 012720 113035
2437 022734 005020
2438 022736 005020
2439 022740 012720 164000
2440 022744 012720 150707
2441 022750 012720 155330
2442 022754 012720 164270
2443 022760 012720 164674
2444 022764 012720 175400
2445 022770 012720 170042
2446 022774 012720 146026
2447 023000 005020
2448 023002 005020
2449 023004 012720 161730
2450
2451 023010 013700 001252
2452 023014 042700 160000
2453 023020 012760 023202 000004
2454 023026 012760 000340 000006
2455 023034 012701 023432

*****
*TEST 110 SILO TEST 1 - ALL STATUS READABLE FROM BUS DIRECTLY
*****
TST110: SCOPE
MOV #40,$TIMES ;:DO 40 ITERATIONS
MOV #110,$TESTN ;:SET TEST NUMBER IN APT MAIL BOX
MOV #BUFFER,R0 ;:GET ADRS WHERE INSTRS GO
MOV #152525,(R0)+ ;:NAME OF 2525
MOV #155661,(R0)+ ;:ROTATE,CHAR SC=1,VEC SC=1
MOV #164374,(R0)+ ;:CONSO=INT,L.P. INTR EN,L.P. SW INTR EN
MOV #164750,(R0)+ ;:CONS1=INT,-L.P. INTR EN,-L.P. SW INTR EN
MOV #170063,(R0)+ ;:ITALICS,MENU
MOV #175200,(R0)+ ;:COLOR=1
MOV #112235,(R0)+ ;:LONG VEC,INT=1,BLINK,LINE=1,MODE=2
CLR (R0)+ ;:X=0
CLR (R0)+ ;:Y=0
MOV #164000,(R0)+ ;:NOP
MOV #151252,(R0)+ ;:NAME=1252
MOV #155322,(R0)+ ;:-ROTATE,CHAR SC=2,VEC SC=2
MOV #164270,(R0)+ ;:CONSO=-INT,L.P. INTR EN,-L.P. SW INTR EN
MOV #164674,(R0)+ ;:CONS1=-INT,L.P. INTR EN,-L.P. SW INTR EN
MOV #170042,(R0)+ ;:-ITALICS,-MENU
MOV #175400,(R0)+ ;:COLOR=2
MOV #146426,(R0)+ ;:ABS VEC,INT=2,-BLINK,LINE=2,MODE=11
CLR (R0)+ ;:X=0
CLR (R0)+ ;:Y=0
MOV #164000,(R0)+ ;:NOP
MOV #153070,(R0)+ ;:NAME=3070
MOV #155664,(R0)+ ;:ROTATE,CHAR SC=1,VEC SC=4
MOV #164374,(R0)+ ;:CONSO=INT,L.P. INTR EN,L.P. SW INTR EN
MOV #164750,(R0)+ ;:CONS1=INT,-L.P. INTR EN,-L.P. SW INTR EN
MOV #170063,(R0)+ ;:ITALICS,MENU
MOV #175200,(R0)+ ;:COLOR=1
MOV #113035,(R0)+ ;:LONG VEC,INT=4,BLINK,LINE=1,MODE=2
CLR (R0)+ ;:X=0
CLR (R0)+ ;:Y=0
MOV #164000,(R0)+ ;:NOP
MOV #150707,(R0)+ ;:NAME=0707
MOV #155330,(R0)+ ;:-ROTATE,CHAR SC=2,VEC SC=10
MOV #164270,(R0)+ ;:CONSO=-INT,L.P. INTR EN,-L.P. SW INTR EN
MOV #164674,(R0)+ ;:CONS1=-INT,L.P. INTR EN,-L.P. SW INTR EN
MOV #175400,(R0)+ ;:COLOR=2
MOV #170042,(R0)+ ;:-ITALICS,-MENU
MOV #146026,(R0)+ ;:ABS VEC,INT=0,-BLINK,LINE=2,MODE=11
CLR (R0)+ ;:X=0
CLR (R0)+ ;:Y=0
MOV #161730,(R0)+ ;:JMP REL TO BUFFER START

MOV $VECT1,R0 ;:GET BASIC VECTOR ADRS
BIC #160000,R0 ;:CLR PSW BITS ** C **
MOV #3$,4(R0) ;:SET UP INTR RETURN ADRS
MOV #340,6(R0) ;:SET PRIORITY TO HIGHEST LEVEL ON INTR
MOV #BSTART,R1 ;:R1 CONTAINS ADRS PTR OF DISPLAY STARTS
    
```


2456	023040	012702	023344			MOV	#SILOR,R2	:R2 CONTAINS ADRS PTR OF EXPECTED SILO RESULTS
2457	023044	012703	023444			MOV	#RCNT,R3	:R3 CONTAINS ADRS PTR OF # OF RESUMES FOR EA SILO LEVEL
2458	023050	012704	023416			MOV	#BADR,R4	:R4 CONTAINS ADRS PTR WHERE REG DATA IS EXPECTED
2459	023054	012705	023344			MOV	#SILOR,R5	:R5 WILL UPDATE R2 ON NEXT BUF START ADRS
2460	023060	005037	001164			CLR	\$TMP0	:\$TMP0 CONTAINS SILO LEVEL UNDER TEST
2461	023064	012777	020040	157204	1\$:	MOV	#20040,@STKPT	:TEST DONE WITH MAINT SW 2
2462	023072	012737	000340	177776		MOV	#340,PSW	:WANT PRIORITY LEVEL AT TOP
2463	023100	011177	157140			MOV	(R1),@DPC	:START
2464	023104	011300				MOV	(R3),R0	:SET UP RESUME CNTR
2465	023106	005277	157132		2\$:	INC	@DPC	:RESUME
2466	023112	012737	023064	001110		MOV	#1\$,\$LPERR	:SET UP SCOPE LOOP ADRS
2467	023120	005300				DEC	R0	:COUNT RESUME
2468	023122	001371				BNE	2\$:BR IF CNT NOT TO ZERO
2469	023124	052777	040000	157144		BIS	#40000,@STKPT	:SET MAINT SW 3
2470	023132	052777	040000	157126		BIS	#40000,@CONS	:SET L.P. FLAG 00
2471	023140	005037	177776			CLR	PSW	:ALLOW INTR
2472	023144	021616				CMP	(SP),(SP)	:LET CPU GRANT REQ
2473	023146	021616				CMP	(SP),(SP)	:
2474	023150	021616				CMP	(SP),(SP)	:
2475	023152	021616				CMP	(SP),(SP)	:
2476	023154	013737	002266	001122		MOV	CONS,\$BDADR	:SET UP REG ADRS 22
2477	023162	012737	144000	001124		MOV	#144000,\$GDDAT	:EXPECT L. P. FLAG
2478	023170	017737	157072	001126		MOV	@CONS,\$BDDAT	:READ REG 22
2479	023176	104001				ERROR	1	:L.P. FLAG INTR FAILED USING MAINT MODE 3
2480	023200	000455				BR	7\$:NEXT TEST ON INTR FAILURE
2481	023202	022626			3\$:	CMP	(SP)+,(SP)+	:FIX STACK SINCE NO RTI ON INTR
2482	023204	017437	000000	001122	4\$:	MOV	@0(R4),\$BDADR	:GET BUS ADRS WHERE DATA IS
2483	023212	017737	155704	001126		MOV	@\$BDADR,\$BDDAT	:GET DATA FROM REG
2484	023220	011237	001124			MOV	(R2),\$GDDAT	:GET EXPECTED DATA FROM SILO TABLE
2485	023224	023737	001124	001126		CMP	\$GDDAT,\$BDDAT	:CORRECT?
2486	023232	001401				BEQ	5\$:BR IF SO
2487	023234	104002				ERROR	2	:SILO FAILURE AT LEVEL INDICATED
2488	023236	062702	000002		5\$:	ADD	#2,R2	:BUMP ADRS PTR OF EXPECTED SILO RESULTS
2489	023242	062704	000002			ADD	#2,R4	:BUMP ADRS PTR OF REG ADRS WHERE DATA IS READ
2490	023246	005714				TST	(R4)	:DONE CHECKS?
2491	023250	001355				BNE	4\$:BR IF NOT
2492	023252	012704	023416			MOV	#BADR,R4	:RESET REG ADRS PTR
2493	023256	005712				TST	(R2)	:AT END OF RESULT TABLE?
2494	023260	001002				BNE	6\$:BR IF NOT
2495	023262	012702	023344			MOV	#SILOR,R2	:RESET ADRS PTR OF EXPECTED RESULTS
2496	023266	062703	000002		6\$:	ADD	#2,R3	:POINT TO NEXT RESUME CNT FOR NEXT SILO LEVEL
2497	023272	005237	001164			INC	\$TMP0	:ADVANCE TO NEXT SILO LEVEL
2498	023276	022737	000004	001164		CMP	#4,\$TMP0	:ALL 4 LEVELS TESTED AT THIS STARTING ADRS?
2499	023304	001267				BNE	1\$:BR IF NOT - REPEAT TEST CHECKING NEXT SILO LEVEL
2500	023306	005037	001164			CLR	\$TMP0	:RESET SILO LEVEL FOR TESTING WITH DIFF DATA
2501	023312	012703	023444			MOV	#RCNT,R3	:RESET RESUME CNT ADRS PTR
2502	023316	062705	000012			ADD	#12,R5	:NEW RESULT ADRS FOR NEXT BUF START ADRS
2503	023322	010502				MOV	R5,R2	:UPDATE RESULT PTR
2504	023324	062701	000002			ADD	#2,R1	:BUMP BUFFER STARTING ADRS PTR - THIS CAUSES
2505								:DIFFERENT DATA PATTERNS THRU SILO
2506	023330	005711				TST	(R1)	:ALL 4 BUFFER ADRS STARTS BEEN DONE?
2507	023332	001254				BNE	1\$:BR IF NOT
2508	023334	004737	024646		7\$:	JSR	PC,RSTVEC	:GO RESTORE VECTOR WITH HALT
2509	023340	000005				RESET		:CLR VS60 BEFORE ADVANCING
2510	023342	000445				BR	TST111	:TO NEXT TEST
2511								

2512	023344	032416	SILOR:	BUFFER+22	:DPC RETURN ADRS
2513	023346	010631		10631	:MODE=2,INT=1,L.P. FLAG,ITALICS,BLINK,LINE=1
2514	023350	002501		2501	:ROTATE,CHAR SC=1,MENU,VCT CS=1
2515	023352	147004		147004	:CONSO=INT,L.P. FLG,L.P. INTR EN,L.P. SW EN,CONS1=INT,COLOR=1
2516	023354	002525		2525	:NAME=2525
2517	023356	032442		BUFFER+46	:DPC RETURN ADRS
2518	023360	045202		45202	:MODE=11,INT=2,L.P. FLG,LINE=2
2519	023362	001002		1002	:CHAR SC=2,VCT SC=2
2520	023364	044070		44070	:CONSO=L.P.FLG,L.P. INTR EN,CONS1=L.P. FLG INTR EN,L.P. SW EN,COLOR=2
2521	023366	001252		1252	:NAME=1252
2522	023370	032466		BUFFER+72	:DPC RETURN ADRS
2523	023372	012231		12231	:MODE=2,INT=3,L.P. FLG,ITALICS,BLINK,LINE=1
2524	023374	002504		2504	:ROTATE,CHAR SC=1,MENU,VEC SC=4
2525	023376	147004		147004	:CONSO=INT,L.P. FLG,L.P. INTR EN,L.P. SW EN,CONS1=INT,COLOR=1
2526	023400	003070		3070	:NAME=3070
2527	023402	032512		BUFFER+116	:DPC RETURN ADRS
2528	023404	044202		44202	:MODE=11,INT=0,L.P. FLG,LINE=2
2529	023406	001010		1010	:CHAR SC=2,VCT SC=4
2530	023410	044070		44070	:CONSO=L.P. FLG,L.P. INTR EN,CONS1=L.P. FLG FLG EN,L.P. SE EN,COLOR=2
2531	023412	000707		707	:NAME=707
2532	023414	000000		0	:TERMINATOR

2533			BADR:	DPC	:THIS TABLE CONTAINS REGS ADRS WHERE DATA IS EXPECTED
2534	023416	002244		SREG0	
2535	023420	002246		SREG1	
2536	023422	002256		CONS	
2537	023424	002266		DNAME	
2538	023426	002270		0	
2539	023430	000000			

2540			BSTART:	BUFFER	:THIS TABLE CONTAINS DIFFERENT STARTING ADRS FOR TESTING
2541	023432	032374			:EACH SILO LEVEL
2542				BUFFER+24	
2543	023434	032420		BUFFER+50	
2544	023436	032444		BUFFER+74	
2545	023440	032470		0	
2546	023442	000000			

2547			RCNT:	17	:THIS TABLE CONTROLS THE AMOUNT OF RESUMES NEEDED TO
2548	023444	000017			:CYCLE THRU ALL FOUR LEVELS OF SILO
2549				31	
2550	023446	000031		43	
2551	023450	000043		55	
2552	023452	000055		0	
2553	023454	000000			

```

*****
*TEST 111      SILO TEST 2 - ALL STATUS VERIFIED ON STACK
*****
TST111: SCOPE
MOV #40,$TIMES      ;;DO 40 ITERATIONS
MOV #111,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX
MOV #BUFFER,RO     ;GET ADRS WHERE INSTR'S GO
MOV #171600,(RO)+  ;STOP INTR EN,-L.P. HIT EN
MOV #176357,(RO)+  ;QUE CNTRL,-EDGE FLG INTR EN,QUE,CHAR STRING ESC
MOV #164770,(RO)+  ;CONS1=INT,L.P. INTR EN
MOV #102200,(RO)+  ;CHAR INSTR,INT=1
MOV #7015,(RO)+    ;SHIFT OUT & 'CR'
MOV #164000,(RO)+  ;NOP OR JSR REL +1 WHEN CHECKING SILO
    
```


2563	023530	012720	164000			MOV	#164000,(R0)+	:NOP
2564	023534	012720	171300			MOV	#171300,(R0)+	:-STOP INTR EN,L.P. HIT EN
2565	023540	012720	176272			MOV	#176272,(R0)+	:-QUE CNTRL,EDGE FLG INTR EN,-QUE,-CHAR STRING ESC
2566	023544	012720	164770			MOV	#164770,(R0)+	:CONS1=INT,L.P. INTR EN
2567	023550	012720	102400			MOV	#102400,(R0)+	:CHAR INSTR,INT=2
2568	023554	012720	006417			MOV	#6417,(R0)+	:SHIFT OUT OFF & 'CR'
2569	023560	012720	164000			MOV	#164000,(R0)+	:NOP OR JSR REL +1 WHEN CHECKING SILO
2570	023564	012720	164000			MOV	#164000,(R0)+	:NOP
2571	023570	012720	171600			MOV	#171600,(R0)+	:STOP INTR EN,-L.P. HIT EN
2572	023574	012720	176357			MOV	#176357,(R0)+	:QUE CNTRL,-EDGE FLG INTR EN,QUE,CHAR STRING ESC
2573	023600	012720	164770			MOV	#164770,(R0)+	:CONS1=INT,L.P. INTR EN
2574	023604	012720	102600			MOV	#102600,(R0)+	:CHAR INSTR,INT=3
2575	023610	012720	007015			MOV	#7015,(R0)+	:SHIFT OUT & 'CR'
2576	023614	012720	164000			MOV	#164000,(R0)+	:NOP OR JSR REL +1 WHEN CHECKING SILO
2577	023620	012720	164000			MOV	#164000,(R0)+	:NOP
2578	023624	012720	171300			MOV	#171300,(R0)+	:-STOP INTR EN,L.P. HIT EN
2579	023630	012720	176272			MOV	#176272,(R0)+	:-QUE CNTRL,EDGE FLG INTR EN,-QUE,-CHAR STRING ESC
2580	023634	012720	164770			MOV	#164770,(R0)+	:CONS1=INT,L.P. INTR EN
2581	023640	012720	103000			MOV	#103000,(R0)+	:CHAR INSTR,INT=4
2582	023644	012720	006417			MOV	#6417,(R0)+	:SHIFT OUT OFF & 'CR'
2583	023650	012720	164000			MOV	#164000,(R0)+	:NOP OR JSR REL +1 WHEN CHECKING SILO
2584	023654	012720	161744			MOV	#161744,(R0)+	:JMP REL TO BUFFER START
2585	023660	013700	001252			MOV	\$VECT1,R0	:GET BASIC VECTOR ADRS
2586	023664	042700	160000			BIC	#160000,R0	: CLR PSW BITS ** C **
2587	023670	012760	024050	000004		MOV	#3\$,4(R0)	:SET UP INTR RETURN ADRS
2588	023676	012760	000340	000006		MOV	#340,6(R0)	:HIGHEST PRIORITY ON INTR
2589	023704	012737	023732	001110		MOV	#1\$, \$LPERR	:SET UP SCOPE LOOP ADRS
2590	023712	012701	024256			MOV	#BSTR1,R1	:R1 CONTAINS ADRS PTR OF DISPLAY STARTS
2591	023716	012702	024250			MOV	#SILOR1,R2	:R2 CONTAINS ADRS PTR OF EXPECTED SILO DATA
2592	023722	012703	024270			MOV	#RCNT1,R3	:R3 CONTAINS ADRS PTR OF # OF RESUMES FOR EA SILO LEVEL
2593	023726	005037	001164			CLR	\$TMP0	: \$TMP0 CONTAINS SILO LEVEL UNDER TEST
2594	023732	012777	020040	156336	1\$:	MOV	#20040,@STKPT	:SET MAINT SW 2 & TOP OF STACK
2595	023740	012737	000340	177776		MOV	#340,PSW	:WANT PRIORITY AT TOP
2596	023746	011177	156272			MOV	(R1),@DPC	:START
2597	023752	011300				MOV	(R3),R0	:SET UP RESUME CNTR
2598	023754	005277	156264		2\$:	INC	@DPC	:RESUME
2599	023760	004537	024446			JSR	R5,DELAY	:STALL
2600	023764	000004				BIT2		:COUNT TO 4
2601	023766	005300				DEC	R0	:COUNT RESUME
2602	023770	001371				BNE	2\$:BR IF COUNT NOT TO ZERO
2603	023772	052777	040000	156276		BIS	#40000,@STKPT	:SET MAINT SW 3
2604	024000	052777	000400	156260		BIS	#400,@CONS	:SET L.P. FLAG 01
2605	024006	005037	177776			CLR	PSW	:ALLOW INTR
2606	024012	021616				CMP	(SP),(SP)	:LET CPU GRANT REQ
2607	024014	021616				CMP	(SP),(SP)	:
2608	024016	021616				CMP	(SP),(SP)	:
2609	024020	021616				CMP	(SP),(SP)	:
2610	024022	013737	002266	001122		MOV	CONS,\$BDADR	:SET UP ADRS REG 22
2611	024030	012737	101440	001124		MOV	#101440,\$GDDAT	:EXPECT L.P. FLAG 01,INTS,L.P. EN
2612	024036	017737	156224	001126		MOV	@CONS,\$BDDAT	:READ REG 22
2613	024044	104001				ERROR	1	:L.P. FLAG 01 FAILED TO INTR USING MAINT MODE 3
2614	024046	000474				BR	7\$:NEXT TEST ON INTR FAILURE
2615	024050	022626			3\$:	CMP	(SP)+,(SP)+	:FIX STACK SINCE NO RTI
2616	024052	017737	156166	024246		MOV	@DPC,DPCSAV	:GET DPC ADRS
2617	024060	012777	163000	000160		MOV	#163000,@DPCSAV	:SET UP JSR REL AT SILO RESTORED DPC
2618	024066	013777	024246	156150		MOV	DPCSAV,@DPC	:SHOULD DO A JSR NOW(RESTORED SILO DATA TO STACK)


```

2619 024074 004537 024446 JSR R5,DELAY ;STALL FOR STACKING
2620 024100 000001 BIT0 ;COUNT TO 1
2621 024102 012777 164000 000136 MOV #164000,@DPCSAV ;RESTORE NOP INSTR FOR NEXT STARTS
2622 024110 013737 002272 001122 MOV STKVAL,$BDADR ;SET UP REG ADRS 26
2623 024116 052777 000037 156152 BIS #37,@STKPT ;DATA IS IN BYTE 3 OF STACK LEVEL 1
2624 024124 017737 156142 001126 MOV @STKVAL,$BDDAT ;READ SAVE STATUS FROM STACK
2625 024132 011237 001124 MOV (R2),$GDDAT ;GET EXPECTED STATUS
2626 024136 023737 001124 001126 CMP $GDDAT,$BDDAT ;CORRECT?
2627 024144 001401 BEQ 4$ ;BR IF SO
2628 024146 104002 ERROR 2 ;SILO FAILED AT LEVEL INDICATED - DATA VERIFIED FROM STK
2629 024150 062702 000002 4$: ADD #2,R2 ;BUMP ADRS PTR OF EXPECTED SILO RESULTS
2630 024154 005712 TST (R2) ;AT END OR RESULT TABLE?
2631 024156 001002 BNE 5$ ;BR IF NOT
2632 024160 012702 024250 MOV #SILOR1,R2 ;RESET ADRS PTR OF EXPECTED RESULTS
2633 024164 062703 000002 5$: ADD #2,R3 ;POINT TO NEXT RESUME CNT FOR NEXT SILO LEVEL
2634 024170 005237 001164 INC $TMP0 ;ADVANCE TO NEXT SILO LEVEL
2635 024174 022737 000004 001164 CMP #4,$TMP0 ;ALL 4 LEVELS TESTED AT THIS STARTING ADRS?
2636 024202 001253 BNE 1$ ;BR IF NOT - REPEAT TEST CHECKING NEXT SILO LEVEL
2637 024204 005037 001164 CLR $TMP0 ;RESET SILO LEVEL FOR TESTING WITH DIFF DAT
2638 024210 012703 024270 MOV #RCNT1,R3 ;RESET RESUME CNT ADRS PTR
2639 024214 062702 000002 ADD #2,R2 ;NEW RESULT ADRS FOR NEXT BUF STARTING ADRS
2640 024220 005712 TST (R2) ;END OF TABLE?
2641 024222 001002 BNE 6$ ;BR IF NOT
2642 024224 012702 024250 MOV #SILOR1,R2 ;RESET RESULT ADRS
2643 024230 062701 000002 6$: ADD #2,R1 ;BUMP BUFFER STARTING ADRS PTR - THIS
2644 ;CAUSES DIFFERNT DATA PATTERNS THRU SILO
2645 024234 005711 TST (R1) ;ALL 4 BUFFER ADRS STARTS BEEN DONE?
2646 024236 001235 BNE 1$ ;BR IF NOT
2647 024240 004737 024646 7$: JSR PC,RSTVEC ;GO RESTORE VECTOR WITH HALT
2648 024244 000416 BR TST112 ;GO TO NEXT TEST
2649
2650 024246 000000 DPCSAV: 0 ;THIS LOCATION SAVES THE DPC THAT WAS RESTORED FROM THE SILO
2651
2652 024250 053465 SILOR1: 53465 ;SHIFT OUT,CHAR STRING ESC,-EDGE FLG INTR EN,QUE,QUE CNTRL
2653 ;L.P. INTR EN 01,INT 00&01,-L.P. HIT DIS,STOP INTR EN
2654 024252 005066 5066 ;-SHIFT OUT,-CHAR STRING ESC,EDGE FLG INTR EN,-QUE,-QUE CNTRL,
2655 ;L.P. INTR EN 01,INT 00&01,L.P. HIT DIS,-STOP INTR EN
2656 024254 000000 0 ;TERMINATOR
2657
2658 024256 032374 BSTRT: BUFFER ;THIS TABLE CONTAINS DIFFERENT STARTING ADRS FOR TESTING
2659 ;EACH SILO LEVEL
2660 024260 032412 BUFFER+16
2661 024262 032430 BUFFER+34
2662 024264 032446 BUFFER+52
2663 024266 000000 0
2664
2665 024270 000011 RCNT1: 11 ;THIS TABLE CONTROLS THE AMOUNT OF RESUMES NEEDED TO
2666 024272 000020 20 ;CYCLE THRU ALL FOUR LEVELS OF SILO
2667 024274 000027 27
2668 024276 000036 36
2669 024300 000000 0
2670
2671
(3) ;*****
(3) ;*TEST 112 TEST FOR HALT AT END OF DIAGNOSTIC (SW12 SET)
(2) 024302 000004 ;*****
TST112: SCOPE
    
```


(2)	024304	012737	000112	001206	MOV	#112,\$TESTN	::SET TEST NUMBER IN APT MAIL BOX
2672	024312	032777	010000	154620	BIT	#BIT12,@SWR	::IS SR12 SET?
2673	024320	001401			BEQ	\$EOP	::BR IF NOT
2674	024322	000000			HALT		::COMPLETED PASS - SW12 SAYS HALT

END OF PASS ROUTINE

```

2678      ;:*****
2679      ;THIS ROUTINE WILL STALL FOR THE NO OF COUNTS IN THE ADRS OF R5
2680      ;:*****
2681 024446 012537 002206 DELAY: MOV (R5)+,DLYCNT ;GET DELAY COUNT
2682 024452 005337 002206 1$: DEC DLYCNT ;START COUNTING
2683 024456 001375 BNE 1$ ;BR IF MORE COUNTS
2684 024460 000205 RTS R5 ;EXIT DELAY ROUTINE
2685
2686      ;:*****
2687      ;THIS ROUTINE SETS UP JSR, POP & TEST INSTR FOR POP-RESTORE TESTS
2688      ;:*****
2689 024462 012777 020040 155606 POPSET: MOV #20040,@STKPT ;SET TOP OF STK
2690 024470 012737 163000 032376 MOV #163000,BUFFER+2 ;SET UP JSR REL INSTR
2691 024476 012737 166000 032402 MOV #166000,BUFFER+6 ;SET UP POP-RESTORE INSTR
2692 024504 012437 032400 MOV (R4)+,BUFFER+4 ;SET UP INSTRUCTION UNDER TEST
2693 024510 000204 RTS R4 ;RETURN
2694
2695      ;:*****
2696      ;THIS ROUTINE CONTROLS JSR, POP & TEST INSTR SEQUENCE FOR POP-RESTORE TESTS
2697      ;:*****
2698 024512 012777 020040 155556 DO: MOV #20040,@STKPT ;SET TOP OF STK
2699 024520 012777 032374 155516 MOV #BUFFER,@DPC ;START -SET BITS UNDER TEST
2700 024526 052777 020000 155542 BIS #20000,@STKPT ;FUMBLE
2701 024534 005277 155504 INC @DPC ;ADVANCE TO JSR INSTR
2702 024540 004537 024446 JSR R5,DELAY ;STALL FOR STACKING
2703 024544 000004 BIT2 ;COUNT TO 4
2704 024546 012777 032400 155470 MOV #BUFFER+4,@DPC ;START -RESET BITS UNDER TEST
2705 024554 052777 020000 155514 BIS #20000,@STKPT ;FUMBLE
2706 024562 005277 155456 INC @DPC ;ADVANCE TO POP INSTR
2707 024566 004537 024446 JSR R5,DELAY ;STALL FOR RESTORING
2708 024572 000004 BIT2 ;COUNT TO 4
2709 024574 000207 RTS PC ;RETURN
2710
2711      ;:*****
2712      ;THIS ROUTINE CONVERTS A KT11 PAGE ADRS TO A 18 BIT ADRS
2713      ;:*****
2714 024576 005001 DPCONV: CLR R1 ;CLR HI ORDER ADRS
2715 024600 006300 ASL R0 ;START SHIFTING LEFT
2716 024602 006300 ASL R0
2717 024604 006300 ASL R0
2718 024606 006300 ASL R0
2719 024610 100002 DPCON1: BPL 1$ ;BR IF ADRS BIT 17 IS CLR
2720 024612 012701 000002 MOV #2,R1 ;SET ADRS BIT 17 INDICATION IN BIT 1 - R1
2721 024616 006300 1$: ASL R0 ;LOOK AT ADRS BIT 16
2722 024620 100001 BPL 2$ ;BR IF ADRS BIT 16 IS CLR
2723 024622 005201 INC R1 ;SET ADRS BIT 16 INDICATION IN BIT 0 - R1
2724 024624 006300 2$: ASL R0 ;COMPLETE LEFT JUSTIFICATION
2725 024626 000207 RTS PC ;RETURN
2726
    
```



```
2728 ;:*****  
2729 ;THIS CODE REPORTS ANY KT11 ERROR AND HALTS  
2730 ;:*****  
2731 024630 042737 001400 177572 KTSER: BIC #1400,@#KTSRO ;DISABLE KT11  
2732 024636 104401 027511 TYPE ,MSG2 ;GO REPORT KT11 THAT A ERROR TRAP OCCURRED  
2733 024642 000000 1$: HALT ;KT11 ERROR TRAP - RUN KT11 DIAG OR  
2734 024644 000776 BR 1$ ;RESTART  
2735 ;:*****  
2736 ;THIS CODE RESETS ALL VS60 VECTORS WITH HALTS  
2737 ;:*****  
2738 RSTVEC: MOV #340,PSW ;RESET PRIORITY TO HIGHEST LEVEL  
2739 024646 012737 000340 177776 MOV #4,R1 ;SET UP VECTOR LOCATION COUNT  
2740 024654 012701 000004 MOV $VECT1,R0 ;GET 1ST VS60 VECTOR ADRS  
2741 024660 013700 001252 BIC #160000,R0 ; CLR PSW BITS ** C **  
2742 024664 042700 160000 1$: MOV R0,(R0) ;SET UP ADRS TO HALT  
2743 024670 010010 ADD #2,(R0)+ ;POINT IT TO HALT  
2744 024672 062720 000002 CLR (R0)+ ;SET UP HALT  
2745 024676 005020 DEC R1 ;COUNT THIS VECTOR RESTORE  
2746 024700 005301 BNE 1$ ;BR IF MORE TO RESTORE  
2747 024702 001372 RTS PC ;RETURN IF ALL DONE  
2748 024704 000207  
2749 ;:*****  
2750 ;THIS ROUTINE MAKES UP A 12 BIT TANGENT FROM THE X OR Y POS  
2751 ;REGS AND THE X OR Y DYNAMIC OFFSET REGS (HI ORDER 2 BITS) AND  
2752 ;LEAVES THE RESULT IN $BDDAT  
2753 ;:*****  
2754 TANCON: BIC #176000,$BDDAT ;SAVE LOW ORDER BITS ONLY  
2755 024706 042737 176000 001126 BIC #147777,R5 ;ONLY WANT BITS 10 & 11  
2756 024714 042705 147777 ASR R5 ;ROTATE 2 RIGHT  
2757 024720 006205 ASR R5 ;  
2758 024722 006205 ADD R5,$BDDAT ;MAKE UP 12 BIT TANGENT  
2759 024724 060537 001126 RTS PC ;RETURN  
2760 024730 000207  
2761
```



```

2763
2764
2765
2766
2767 024732 001010
2768 024734 012703 000400
2769 024740 012737 000001 001124
2770 024746 005037 025042
2771 024752 000432
2772 024754 013737 025042 001124 1$:
2773 024762 062737 000005 001124
2774 024770 062737 000004 025042
2775 024776 005303
2776 025000 001010
2777 025002 062737 000001 001124
2778 025010 062737 000001 025042
2779 025016 012703 000400
2780 025022 032737 010000 001124 2$:
2781 025030 001403
2782 025032 012737 007777 001124
2783 025040 000207 3$:
2784
2785 025042 000000
2786
2787
2788
2789
2790
2791
2792 025044
2793 025044 012537 025114
2794 025050 012777 020040 155220
2795 025056 012777 032374 155160
2796 025064 052777 040000 155204
2797 025072 052777 040000 155176
2798 025100 005277 155140
2799 025104 005337 025114
2800 025110 001365
2801 025112 000205
2802
2803 025114 000000
2804

```

```

:*****
:THIS ROUTINE UPDATES THE TANGENT IN & GDDAT FOR EVERY INCREASE
: IN VECTOR OF X OR Y
:*****
CALTAN: BNE 1$ ;BR AND SET UP TANGENT IF VECTOR NON-ZERO
MOV #400,R3 ;R3 COUNTS EVERY 256+4 ADDS TO TANGENT
MOV #1,$GDDAT ;TANGENT WILL BE 1 WHEN VECTOR LENGTH 0
CLR TANGNT ;TANGENT HOLDING LOC
BR 3$ ;RETURN WITH ZERO TANGENT
1$: MOV TANGNT,$GDDAT ;GET LAST VALUE
ADD #5,$GDDAT ;ADD 4 AND 1 FOR FRACTIONAL ROUNDING IN HARDWARE
ADD #4,TANGNT ;ADD 4 ON EVERY COUNT OF VECTOR LENGTH
DEC R3 ;ROUND UP EVERY 11.25 DEGREES
BNE 2$ ;BR IF NOT REQUIRED
ADD #1,$GDDAT ;ROUND UP EVERY 256
ADD #1,TANGNT ;SAME
MOV #400,R3 ;RESET 256 COUNT
2$: BIT #10000,$GDDAT ;TEST TANGENT FOR GREATER THAN 12 BITS
BEQ 3$ ;BR IF NOT
MOV #7777,$GDDAT ;CAN'T GET GREATER THAN 7777
3$: RTS PC ;RETURN WITH TANGENT IN $GDDAT

TANGNT: 0 ;LOC MAINTAINS TANGENT MINUS 1
:*****
:THIS ROUTINE STARTS THE DISPLAY WITH MAINT. SW 2, THEN SETS
:MAINT. SW 3, AND THEN ISSUES A # OF RESUMES SPECIFIED
:BY R5 AT WHICH TIME IT WILL EXIT
:*****
EXECUTE:
MOV (R5)+,CNTR ;SET UP THE RESUME COUNTER
MOV #20040,@STKPT ;SET MAINT SW 2 AND TOP OF STACK
MOV #BUFFER,@DPC ;START DISPLAY
1$: BIS #40000,@STKPT ;SET MAINT SW 3
BIS #40000,@STKPT ;AGAIN
INC @DPC ;RESUME
DEC CNTR ;COUNT RESUME
BNE 1$ ;BR IF MORE RESUMES TO FOLLOW
RTS R5 ;EXIT

CNTR: 0 ;CNTR USED ABOVE

```



```

2806      .SBTTL  SCOPE HANDLER ROUTINE
(1)
(2)      ::*****
(1)      ::*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
(1)      ::*AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
(1)      ::*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
(1)      ::*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
(1)      ::*SW14=1      LOOP ON TEST
(1)      ::*SW11=1      INHIBIT ITERATIONS
(1)      ::*SW09=1      LOOP ON ERROR
(1)      ::*SW08=1      LOOP ON TEST IN SWR<7:0>
(1)      ::*CALL
(1)      ::*      SCOPE      ;;SCOPE=IOT
(1)
(1)      $SCOPE:
(1)      025116 032777 040000 154014 1$: BIT    #BIT14,@SWR      ;;LOOP ON PRESENT TEST?
(1)      025124 001114      BNE    $OVER        ;;YES IF SW14=1
(1)      ::#####START OF CODE FOR THE XOR TESTER#####
(1)      025126 000416      $XTSTR: BR    6$      ;;IF RUNNING ON THE 'XOR' TESTER CHANGE
(1)      025130 013746 000004      MOV    @WERRVEC,-(SP)  ;;SAVE THE CONTENTS OF THE ERROR VECTOR
(1)      025134 012737 025154 000004      MOV    #5$,@WERRVEC  ;;SET FOR TIMEOUT
(1)      025142 005737 177060      TST   @#177060      ;;TIME OUT ON XOR?
(1)      025146 012637 000004      MOV    (SP)+,@WERRVEC ;;RESTORE THE ERROR VECTOR
(1)      025152 000463      BR    $$VLAD        ;;GO TO THE NEXT TEST
(1)      025154 022626      5$:  CMP    (SP)+,(SP)+  ;;CLEAR THE STACK AFTER A TIME OUT
(1)      025156 012637 000004      MOV    (SP)+,@WERRVEC ;;RESTORE THE ERROR VECTOR
(1)      025162 000423      BR    7$            ;;LOOP ON THE PRESENT TEST
(1)      025164      6$:;#####END OF CODE FOR THE XOR TESTER#####
(1)      025164 032777 000400 153746      BIT    #BIT08,@SWR   ;;LOOP ON SPEC. TEST?
(1)      025172 001404      BEQ    2$            ;;BR IF NO
(1)      025174 127737 153740 001102      CMPB  @SWR,$TSTNM   ;;ON THE RIGHT TEST?  SWR<7:0>
(1)      025202 001465      BEQ    $OVER        ;;BR IF YES
(1)      025204 105737 001103      2$:  TSTB  $ERFLG     ;;HAS AN ERROR OCCURRED?
(1)      025210 001421      BEQ    3$            ;;BR IF NO
(1)      025212 123737 001115 001103      CMPB  $ERMAX,$ERFLG ;;MAX. ERRORS FOR THIS TEST OCCURRED?
(1)      025220 101015      BHI    3$            ;;BR IF NO
(1)      025222 032777 001000 153710      BIT    #BIT09,@SWR   ;;LOOP ON ERROR?
(1)      025230 001404      BEQ    4$            ;;BR IF NO
(1)      025232 013737 001110 001106      7$:  MOV    $LPERR,$LPADR ;;SET LOOP ADDRESS TO LAST SCOPE
(1)      025240 000446      BR    $OVER
(1)      025242 105037 001103      4$:  CLRB  $ERFLG     ;;ZERO THE ERROR FLAG
(1)      025246 005037 001166      CLR   $TIMES       ;;CLEAR THE NUMBER OF ITERATIONS TO MAKE
(1)      025252 000415      BR    1$            ;;ESCAPE TO THE NEXT TEST
(1)      025254 032777 004000 153656      3$:  BIT    #BIT11,@SWR  ;;INHIBIT ITERATIONS?
(1)      025262 001011      BNE    1$            ;;BR IF YES
(1)      025264 005737 001210      TST   $PASS        ;;IF FIRST PASS OF PROGRAM
(1)      025270 001406      BEQ    1$            ;;      INHIBIT ITERATIONS
(1)      025272 005237 001104      INC   $ICNT        ;;INCREMENT ITERATION COUNT
(1)      025276 023737 001166 001104      CMP   $TIMES,$ICNT  ;;CHECK THE NUMBER OF ITERATIONS MADE
(1)      025304 002024      BGE    $OVER        ;;BR IF MORE ITERATION REQUIRED
(1)      025306 012737 000001 001104      1$:  MOV    #1,$ICNT    ;;REINITIALIZE THE ITERATION COUNTER
(1)      025314 013737 025372 001166      MOV   $MXCNT,$TIMES ;;SET NUMBER OF ITERATIONS TO DO
(1)      025322 105237 001102      $SVLAD: INCB  $TSTNM  ;;COUNT TEST NUMBERS
(1)      025326 113737 001102 001206      MOVB  $TSTNM,$TESTN ;;SET TEST NUMBER IN APT MAILBOX
(1)      025334 011637 001106      MOV   (SP),$LPADR  ;;SAVE SCOPE LOOP ADDRESS
    
```


(1)	025340	011637	001110		MOV	(SP), \$LPERR	::SAVE ERROR LOOP ADDRESS
(1)	025344	005037	001170		CLR	\$ESCAPE	::CLEAR THE ESCAPE FROM ERROR ADDRESS
(1)	025350	112737	000001	001115	MOVB	#1, \$ERMAX	::ONLY ALLOW ONE(1) ERROR ON NEXT TEST
(1)	025356	013777	001102	153556	\$OVER: MOV	\$TSTNM, @DISPLAY	::DISPLAY TEST NUMBER
(1)	025364	013716	001106		MOV	\$LPADR, (SP)	::FUDGE RETURN ADDRESS
(1)	025370	000002			RTI		::FIXES PS
(1)	025372	003720			\$MXCNT: 2000.		::MAX. NUMBER OF ITERATIONS

2808

.SBTTL APT COMMUNICATIONS ROUTINE

```

(1)
(2)
(1) 025374 112737 000001 025640 $ATY1: MOVB #1,$FFLG ;;TO REPORT FATAL ERROR
(1) 025402 112737 000001 025636 $ATY3: MOVB #1,$MFLG ;;TO TYPE A MESSAGE
(1) 025410 000403 BR $ATYC
(1) 025412 112737 000001 025640 $ATY4: MOVB #1,$FFLG ;;TO ONLY REPORT FATAL ERROR
(1) 025420 $ATYC:
(3) 025420 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
(3) 025422 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
(1) 025424 105737 025636 TSTB $MFLG ;;SHOULD TYPE A MESSAGE?
(1) 025430 001450 BEQ 5$ ;;IF NOT: BR
(1) 025432 122737 000001 001222 CMPB #APTENV,$ENV ;;OPERATING UNDER APT?
(1) 025440 001031 BNE 3$ ;;IF NOT: BR
(1) 025442 132737 000100 001223 BITB #APTPOOL,$ENVM ;;SHOULD SPOOL MESSAGES?
(1) 025450 001425 BEQ 3$ ;;IF NOT: BR
(1) 025452 017600 000004 MOV @4(SP),R0 ;;GET MESSAGE ADDR.
(1) 025456 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
(1) 025464 005737 001202 1$: TST $MSGTYPE ;;SEE IF DONE W/ LAST XMISSION?
(1) 025470 001375 BNE 1$ ;;IF NOT: WAIT
(1) 025472 010037 001216 MOV R0,$MSGAD ;;PUT ADDR IN MAILBOX
(1) 025476 105720 2$: TSTB (R0)+ ;;FIND END OF MESSAGE
(1) 025500 001376 BNE 2$
(1) 025502 163700 001216 SUB $MSGAD,R0 ;;SUB START OF MESSAGE
(1) 025506 006200 ASR R0 ;;GET MESSAGE LNTH IN WORDS
(1) 025510 010037 001220 MOV R0,$MSGLGT ;;PUT LENGTH IN MAILBOX
(1) 025514 012737 000004 001202 MOV #4,$MSGTYPE ;;TELL APT TO TAKE MSG.
(1) 025522 000413 BR 5$
(1) 025524 017637 000004 025550 3$: MOV @4(SP),4$ ;;PUT MSG ADDR IN JSR LINKAGE
(1) 025532 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDRESS
(3) 025540 013746 177776 MOV 177776,-(SP) ;;PUSH 177776 ON STACK
(1) 025544 004737 026200 JSR PC,$TYPE ;;CALL TYPE MACRO
(1) 025550 000000 4$: .WORD 0
(1) 025552 5$:
(1) 025552 105737 025640 10$: TSTB $FFLG ;;SHOULD REPORT FATAL ERROR?
(1) 025556 001416 BEQ 12$ ;;IF NOT: BR
(1) 025560 005737 001222 TST $ENV ;;RUNNING UNDER APT?
(1) 025564 001413 BEQ 12$ ;;IF NOT: BR
(1) 025566 005737 001202 11$: TST $MSGTYPE ;;FINISHED LAST MESSAGE?
(1) 025572 001375 BNE 11$ ;;IF NOT: WAIT
(1) 025574 017637 000004 001204 MOV @4(SP),$FATAL ;;GET ERROR #
(1) 025602 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
(1) 025610 005237 001202 INC $MSGTYPE ;;TELL APT TO TAKE ERROR
(1) 025614 105037 025640 12$: CLRB $FFLG ;;CLEAR FATAL FLAG
(1) 025620 105037 025637 CLRB $LFLG ;;CLEAR LOG FLAG
(1) 025624 105037 025636 CLRB $MFLG ;;CLEAR MESSAGE FLAG
(3) 025630 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
(3) 025632 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
(1) 025634 000207 RTS PC ;;RETURN
(1) 025636 000 $MFLG: .BYTE 0 ;;MESSG. FLAG
(1) 025637 000 $LFLG: .BYTE 0 ;;LOG FLAG
(1) 025640 000 $FFLG: .BYTE 0 ;;FATAL FLAG
(1) 025642 .EVEN
(1) 000200 APTSIZE=200
(1) 000001 APTENV=001
(1) 000100 APTPOOL=100
    
```



```

(1)          000040          APTCSUP=040
2809          .SBTTL  ERROR HANDLER ROUTINE
(1)
(2)          ::*****
(1)          ::THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
(1)          ::SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
(1)          ::AND GO TO $ERRTYP ON ERROR
(1)          ::THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
(1)          ::*SW15=1          HALT ON ERROR
(1)          ::*SW13=1          INHIBIT ERROR TYPEOUTS
(1)          ::*SW10=1          BELL ON ERROR
(1)          ::*SW09=1         LOOP ON ERROR
(1)          ::*CALL
(1)          ::*          ERROR      N          ;;ERROR=EMT AND N=ERROR ITEM NUMBER
(1)
(1) 025642          $ERROR:
(2) 025642 113737 001102 002204      MOVB $STNM,TSTNUM
(1) 025650 105237 001103          7$:      INCB  $ERFLG          ;;SET THE ERROR FLAG
(1) 025654 001775          BEQ    7$          ;;DON'T LET THE FLAG GO TO ZERO
(1) 025656 013777 001102 153256      MOV    $STNM,@DISPLAY  ;;DISPLAY TEST NUMBER AND ERROR FLAG
(1) 025664 032777 002000 153246      BIT    #BIT10,@SWR    ;;BELL ON ERROR?
(1) 025672 001402          BEQ    1$          ;;NO - SKIP
(1) 025674 104401 001172          TYPE  , $BELL        ;;RING BELL
(1) 025700 005237 001112          1$:      INC    $ERTTL        ;;COUNT THE NUMBER OF ERRORS
(1) 025704 011637 001116          MOV    (SP), $ERRPC   ;;GET ADDRESS OF ERROR INSTRUCTION
(1) 025710 162737 000002 001116      SUB    #2, $ERRPC
(1) 025716 117737 153174 001114      MOVB  @$ERRPC, $ITEMB ;;STRIP AND SAVE THE ERROR ITEM CODE
(1) 025724 032777 020000 153206      BIT    #BIT13,@SWR   ;;SKIP TYPEOUT IF SET
(1) 025732 001004          BNE   20$          ;;SKIP TYPEOUTS
(1) 025734 004737 026044          JSR   PC, $ERRTYP    ;;GO TO USER ERROR ROUTINE
(1) 025740 104401 001177          TYPE  , $CRLF
(1) 025744          20$:
(1) 025744 122737 000001 001222      CMPB  #APTENV, $ENV   ;;RUNNING IN APT MODE
(1) 025752 001007          BNE   2$          ;;NO, SKIP APT ERROR REPORT
(1) 025754 113737 001114 025766      MOVB  $ITEMB, 21$    ;;SET ITEM NUMBER AS ERROR NUMBER
(1) 025762 004737 025412          JSR   PC, $ATY4     ;;REPORT FATAL ERROR TO APT
(1) 025766 000          21$:      .BYTE 0
(1) 025767 000          .BYTE 0
(1) 025770 000777          22$:      BR    22$          ;;APT ERROR LOOP
(1) 025772 005777 153142          2$:      TST  @SWR          ;;HALT ON ERROR
(1) 025776 100001          BPL  3$          ;;SKIP IF CONTINUE
(1) 026000 000000          HALT          ;;HALT ON ERROR!
(1) 026002 032777 001000 153130      3$:      BIT  #BIT09,@SWR   ;;LOOP ON ERROR SWITCH SET?
(1) 026010 001402          BEQ  4$          ;;BR IF NO
(1) 026012 013716 001110          MOV  $LPERR, (SP)   ;;FUDGE RETURN FOR LOOPING
(1) 026016 005737 001170          4$:      TST  $ESCAPE      ;;CHECK FOR AN ESCAPE ADDRESS
(1) 026022 001402          BEQ  5$          ;;BR IF NONE
(1) 026024 013716 001170          MOV  $ESCAPE, (SP) ;;FUDGE RETURN ADDRESS FOR ESCAPE
(1) 026030          5$:
(1) 026030 022737 024412 000042      CMP  #$ENDAD, @#42  ;;ACT-11 AUTO-ACCEPT?
(1) 026036 001001          BNE  6$          ;;BRANCH IF NO
(1) 026040 000000          HALT          ;;YES
(1) 026042          6$:
(1) 026042 000002          RTI          ;;RETURN
    
```



```

(1) 026364 000770          BR      7$          ;;LOOP
(1)
(1)          ;HORIZONTAL TAB PROCESSOR
(1)
(1) 026366 112716 000040      8$:   MOVB   #' (SP)          ;;REPLACE TAB WITH SPACE
(1) 026372 004737 026412      9$:   JSR    PC,$TYPEC          ;;TYPE A SPACE
(1) 026376 132737 000007 026456  BITB   #7,$CHARCNT          ;;BRANCH IF NOT AT
(1) 026404 001372          BNE    9$          ;;TAB STOP
(1) 026406 005726          TST   (SP)+          ;;POP SPACE OFF STACK
(1) 026410 000724          BR     2$          ;;GET NEXT CHARACTER
(1) 026412 105777 152532      $TYPEC: TSTB  @ $TPS          ;;WAIT UNTIL PRINTER IS READY
(1) 026416 100375          BPL   $TYPEC
(1) 026420 116677 000002 152524  MOVB   2(SP),@ $TPB          ;;LOAD CHAR TO BE TYPED INTO DATA REG.
(1) 026426 122766 000015 000002  CMPB   #CR,2(SP)          ;;IS CHARACTER A CARRIAGE RETURN?
(1) 026434 001003          BNE   1$          ;;BRANCH IF NO
(1) 026436 105037 026456          CLRB  $CHARCNT          ;;YES--CLEAR CHARACTER COUNT
(1) 026442 000406          BR    $TYPEX          ;;EXIT
(1) 026444 122766 000012 000002  1$:   CMPB   #LF,2(SP)          ;;IS CHARACTER A LINE FEED?
(1) 026452 001402          BEQ   $TYPEX          ;;BRANCH IF YES
(1) 026454 105227          INCB  (PC)+          ;;COUNT THE CHARACTER
(1) 026456 000000      $CHARCNT: .WORD 0          ;;CHARACTER COUNT STORAGE
(1) 026460 000207      $TYPEX: RTS   PC
(1)
    
```



```
(1) 026624 005204          4$:  INC      R4          ;;DON'T SUPPRESS ANYMORE 0'S
(1) 026626 052703 000060  BIS      #'0,R3      ;;MAKE THIS DIGIT ASCII
(1) 026632 052703 000040  5$:  BIS      #' ,R3      ;;MAKE ASCII IF NOT ALREADY
(1) 026636 110337 026702  MOVB     R3,8$        ;;SAVE FOR TYPING
(1) 026642 104401 026702  TYPE     ,8$         ;;GO TYPE THIS DIGIT
(1) 026646 105337 026704  7$:  DECB     $OCNT      ;;COUNT BY 1
(1) 026652 003347          BGT      2$          ;;BR IF MORE TO DO
(1) 026654 002402          BLT      6$          ;;BR IF DONE
(1) 026656 005204          INC      R4          ;;INSURE LAST DIGIT ISN'T A BLANK
(1) 026660 000744          BR       2$          ;;GO DO THE LAST DIGIT
(1) 026662 012605          6$:  MOV      (SP)+,R5  ;;RESTORE R5
(1) 026664 012604          MOV      (SP)+,R4  ;;RESTORE R4
(1) 026666 012603          MOV      (SP)+,R3  ;;RESTORE R3
(1) 026670 016666 000002 000004 MOV      2(SP),4(SP) ;;SET THE STACK FOR RETURNING
(1) 026676 012616          MOV      (SP)+,(SP)
(1) 026700 000002          RTI                    ;;RETURN
(1) 026702 000          8$:  .BYTE   0          ;;STORAGE FOR ASCII DIGIT
(1) 026703 000          .BYTE   0          ;;TERMINATOR FOR TYPE ROUTINE
(1) 026704 000          $OCNT: .BYTE   0     ;;OCTAL DIGIT COUNTER
(1) 026705 000          $OFILL: .BYTE   0     ;;ZERO FILL SWITCH
(1) 026706 000000          $OMODE: .WORD   0     ;;NUMBER OF DIGITS TO TYPE
```



```
(3) 027072 012601      MOV      (SP)+,R1      ;;POP STACK INTO R1
(3) 027074 012600      MOV      (SP)+,R0      ;;POP STACK INTO R0
(1) 027076 104401 027124  TYPE      .SDBLK      ;;NOW TYPE THE NUMBER
(1) 027102 016666 000002 000004  MOV      2(SP),4(SP)   ;;ADJUST THE STACK
(1) 027110 012616      MOV      (SP)+,(SP)
(1) 027112 000002      RTI                      ;;RETURN TO USER
(1) 027114 023420      $DTBL: 10000.
(1) 027116 001750      1000.
(1) 027120 000144      100.
(1) 027122 000012      10.
(1) 027124 000004      $DBLK: .BLKW 4
```



```

2821          .SBTTL  POWER DOWN AND UP ROUTINES
(1)
(2)          ::*****
(1)          :POWER DOWN ROUTINE
(1) 027204 012737 027350 000024 $PWRDN: MOV  #ILLUP,@PWRVEC  ;;SET FOR FAST UP
(1) 027212 012737 000340 000026      MOV  #340,@PWRVEC+2  ;;PRIO:7
(3) 027220 010046              MOV  R0,-(SP)      ;;PUSH R0 ON STACK
(3) 027222 010146              MOV  R1,-(SP)      ;;PUSH R1 ON STACK
(3) 027224 010246              MOV  R2,-(SP)      ;;PUSH R2 ON STACK
(3) 027226 010346              MOV  R3,-(SP)      ;;PUSH R3 ON STACK
(3) 027230 010446              MOV  R4,-(SP)      ;;PUSH R4 ON STACK
(3) 027232 010546              MOV  R5,-(SP)      ;;PUSH R5 ON STACK
(3) 027234 017746 151700      MOV  @SWR,-(SP)    ;;PUSH @SWR ON STACK
(1) 027240 010637 027354      MOV  SP,$SAVR6    ;;SAVE SP
(1) 027244 012737 027256 000024      MOV  #PWRUP,@PWRVEC ;;SET UP VECTOR
(1) 027252 000000              HALT
(1) 027254 000776              BR    -2          ;;HANG UP
(1)
(2)          ::*****
(1)          :POWER UP ROUTINE
(1) 027256 012737 027350 000024 $PWRUP: MOV  #ILLUP,@PWRVEC  ;;SET FOR FAST DOWN
(1) 027264 013706 027354      MOV  $SAVR6,SP    ;;GET SP
(1) 027270 005037 027354      CLR  $SAVR6      ;;WAIT LOOP FOR THE TTY
(1) 027274 005237 027354      1$: INC  $SAVR6   ;;WAIT FOR THE INC
(1) 027300 001375              BNE  1$         ;;OF WORD
(3) 027302 012677 151632      MOV  (SP)+,@SWR  ;;POP STACK INTO @SWR
(3) 027306 012605              MOV  (SP)+,R5   ;;POP STACK INTO R5
(3) 027310 012604              MOV  (SP)+,R4   ;;POP STACK INTO R4
(3) 027312 012603              MOV  (SP)+,R3   ;;POP STACK INTO R3
(3) 027314 012602              MOV  (SP)+,R2   ;;POP STACK INTO R2
(3) 027316 012601              MOV  (SP)+,R1   ;;POP STACK INTO R1
(3) 027320 012600              MOV  (SP)+,R0   ;;POP STACK INTO R0
(1) 027322 012737 027204 000024      MOV  #PWRDN,@PWRVEC ;;SET UP THE POWER DOWN VECTOR
(1) 027330 012737 000340 000026      MOV  #340,@PWRVEC+2 ;;PRIO:7
(1) 027336 104401              TYPE  PWRMSG     ;;REPORT THE POWER FAILURE
(1) 027340 027356          $PWRMG: .WORD  PWRMSG  ;;POWER FAIL MESSAGE POINTER
(1) 027342 012716              MOV  (PC)+,(SP)  ;;RESTART AT RSTART
(1) 027344 003244          $PWRAD: .WORD  RSTART  ;;RESTART ADDRESS
(1) 027346 000002              RTI
(1) 027350 000000          $ILLUP: HALT     ;;THE POWER UP SEQUENCE WAS STARTED
(1) 027352 000776              BR    -2          ;; BEFORE THE POWER DOWN WAS COMPLETE
(1) 027354 000000          $SAVR6: 0        ;;PUT THE SP HERE
2822 027356 005015 042522 052123      PWRMSG: .ASCIZ <15><12>/RESTARTED AFTER A POWER FAILURE/<15><12><12>
2823
    
```


2825					.SBTTL	ASCII MESSAGES
2826						
2827	027423	015	051412	040524	MSG1:	.ASCIZ <15><12>/START OF CZVSC-C VS60 INSTRUCTION TEST PART III/<15><12>
2828	027511	015	045412	030524	MSG2:	.ASCIZ <15><12>/KT11 ER TRAP/
2829	027530	005015	042515	047515	MSG3:	.ASCIZ <15><12>/MEMORY SIZE =/
2830	027550	006513	000012		MSG4:	.ASCIZ /K/<15><12>
2831	027554	027114	027120	043040	EM1:	.ASCIZ /L.P. FLAG INTR FAILURE/
2832	027603	123	046111	020117	EM2:	.ASCIZ /SILO FAILURE AT LEVEL INDICATED/
2833	027643	123	045524	050040	EM3:	.ASCIZ /STK PTR DEC ER/
2834	027662	052123	041501	020113	EM4:	.ASCIZ /STACK OVERFLOW ER/
2835	027704	050104	020103	052123	EM5:	.ASCIZ /DPC STKING ER/
2836	027722	050104	020125	040516	EM6:	.ASCIZ /DPU NAME STKING ER/
2837	027745	115	042117	020105	EM7:	.ASCIZ /MODE STKING ER/
2838	027764	042526	052103	051117	EM10:	.ASCIZ /VECTOR SCALE STKING ER/
2839	030013	103	040510	040522	EM11:	.ASCIZ /CHARACTER SCALE STKING ER/
2840	030045	103	040510	040522	EM12:	.ASCIZ /CHARACTER ROTATE STKING ER/
2841	030100	047111	042524	051516	EM13:	.ASCIZ /INTENSITY LEVEL STKING ER/
2842	030132	047503	047514	020122	EM14:	.ASCIZ /COLOR LEVEL STKING ER/
2843	030160	052111	046101	041511	EM15:	.ASCIZ /ITALICS STKING ER/
2844	030202	042515	052516	051440	EM16:	.ASCIZ /MENU STKING ER/
2845	030221	102	044514	045516	EM17:	.ASCIZ /BLINK ENA STKING ER/
2846	030245	123	047524	020120	EM20:	.ASCIZ /STOP INT ENA STKING ER/
2847	030274	050114	044040	052111	EM21:	.ASCIZ /LP HIT DISABLE STKING ER/
2848	030325	114	020104	052123	EM22:	.ASCIZ /LD STAUTS ENA STKING ER/
2849	030355	105	043504	020105	EM23:	.ASCIZ /EDGE INT ENA STKING ER/
2850	030404	044103	051101	051440	EM24:	.ASCIZ /CHAR STRING ESCAPE STKING ER/
2851	030441	104	050105	044124	EM25:	.ASCIZ /DEPTH QUE STKING ER/
2852	030465	114	047111	020105	EM26:	.ASCIZ /LINE TYPE STKING ER/
2853	030511	111	052116	047105	EM27:	.ASCIZ /INTENSITY ENA STKING ER/
2854	030541	114	050056	020056	EM30:	.ASCIZ /L.P. INTR ENA STKING ER/
2855	030571	114	050056	020056	EM31:	.ASCIZ /L.P. SW INTR ENA STKING ER/
2856	030624	044123	043111	020124	EM32:	.ASCIZ /SHIFT OUT STKING ER/
2857	030650	052123	020113	052120	EM33:	.ASCIZ /STK PTR INC ER/
2858	030667	123	045524	052440	EM34:	.ASCIZ /STK UNDERFLOW ER/
2859	030710	050104	020103	047520	EM35:	.ASCIZ /DPC POP ER/
2860	030723	116	046501	020105	EM36:	.ASCIZ /NAME POP ER/
2861	030737	126	041505	047524	EM37:	.ASCIZ /VECTOR SCALE POP ER/
2862	030763	103	040510	020122	EM40:	.ASCIZ /CHAR SCALE POP ER/
2863	031005	103	040510	020122	EM41:	.ASCIZ /CHAR ROTATE POP ER/
2864	031030	047503	047514	020122	EM42:	.ASCIZ /COLOR LEVEL POP ER/
2865	031053	111	040524	044514	EM43:	.ASCIZ /ITALICS POP ER/
2866	031072	042515	052516	050040	EM44:	.ASCIZ /MENU POP ER/
2867	031106	047111	042524	051516	EM45:	.ASCIZ /INTENSITY ENA POP ER/
2868	031133	114	050056	020056	EM46:	.ASCIZ /L.P. INTR ENA POP ER/
2869	031160	027114	027120	051440	EM47:	.ASCIZ /L.P. SW INTR ENA POP ER/
2870	031210	044514	042516	052040	EM50:	.ASCIZ /LINE TYPE POP ER/
2871	031231	111	052116	047105	EM51:	.ASCIZ /INTENSITY LEVEL POP ER/
2872	031260	046102	047111	020113	EM52:	.ASCIZ /BLINK POP ER/
2873	031275	115	042117	020105	EM53:	.ASCIZ /MODE POP ER/
2874	031311	123	047524	020120	EM54:	.ASCIZ /STOP INTR ENA POP ER/
2875	031336	042504	052120	020110	EM55:	.ASCIZ /DEPTH QUE POP ER/
2876	031357	105	043504	020105	EM56:	.ASCIZ /EDGE INTR ENA POP ER/
2877	031404	044103	051101	051440	EM57:	.ASCIZ /CHAR STRING ESC POP ER/
2878	031433	114	050056	020056	EM60:	.ASCIZ /L.P. HIT DISABLE POP ER/
2879	031463	123	044510	052106	EM61:	.ASCIZ /SHIFT OUT POP ER/
2880	031504	042524	046522	047111	EM62:	.ASCIZ /TERMINATE CHAR POP ER/

2881 031532 052123 020113 053117 EM63: .ASCIZ /STK OVFL0 INT ER/
2882 031553 123 045524 052440 EM64: .ASCIZ /STK UNFLO INT ER/
2883 031574 042504 052114 020101 EM65: .ASCIZ /DELTA LENGTH ER/
2884 031614 040524 043516 047105 EM66: .ASCIZ /TANGENT ER/
2885 031627 104 041520 030440 EM67: .ASCIZ /DPC 16-17 ER/
2886 031644 051526 030066 046440 EM70: .ASCIZ /VS60 MEM ADRS FAILURE/
2887 031672 052123 050117 043040 EM71: .ASCIZ /STOP FLAG FAILED TO SET/
2888 031722 052123 051101 020124 EM72: .ASCIZ /START FAILED TO SET 'TOP OF STK'/
2889 031763 105 051122 041520 DH1: .ASCIZ /ERRPC TSTNUM BUSADRS EXPCT RCVD/
2890 032030 051105 050122 020103 DH2: .ASCIZ /ERRPC TSTNUM BUSADRS EXPCT RCVD STK SEL/
2891 032110 051105 050122 020103 DH3: .ASCIZ /ERRPC TSTNUM GDPC-HI GDPC BDPC-HI BDPC/
2892 032165 105 051122 041520 DH4: .ASCIZ /ERRPC TSTNUM VECTOR EXPCT RCVD/
2893 032232 051105 050122 020103 DH5: .ASCIZ /ERRPC TSTNUM BUSADRS EXPCT RCVD LEVEL/
2894 .EVEN
2895 032310 001116 002204 001122 DT1: .WORD \$ERRPC,TSTNUM,\$BDADR,\$GDDAT,\$BDDAT,0
2896 032324 001116 002204 001122 DT2: .WORD \$ERRPC,TSTNUM,\$BDADR,\$GDDAT,\$BDDAT,\$TMP0,0
2897 032342 001116 002204 002224 DT3: .WORD \$ERRPC,TSTNUM,G1716,\$GDDAT,B1716,\$BDDAT,0
2898 032360 001116 002204 001164 DT4: .WORD \$ERRPC,TSTNUM,\$TMP0,\$GDDAT,\$BDDAT,0
2899

2900
2901
2902
2903
2904 032374 000000
2905 000001

```
;;*****  
;THIS IS THE WORKING AREA FOR ALL VS60 NPR'S (INSTR & DATA)  
;FROM HERE TO THE END OF MEMORY  
;;*****  
BUFFER: 0 ;LOCATIONS START HERE FOR TESTING  
.END ;END OF PROGRAM
```


ABASE = 172000	17#	29																		
ACDW1 = 000000	29																			
ACDW2 = 000000	29																			
ACPUOP= 000000	29																			
ADDW0 = 000000	29																			
ADDW1 = 000000	29																			
ADDW10= 000000	29																			
ADDW11= 000000	29																			
ADDW12= 000000	29																			
ADDW13= 000000	29																			
ADDW14= 000000	29																			
ADDW15= 000000	29																			
ADDW2 = 000000	29																			
ADDW3 = 000000	29																			
ADDW4 = 000000	29																			
ADDW5 = 000000	29																			
ADDW6 = 000000	29																			
ADDW7 = 000000	29																			
ADDW8 = 000000	29																			
ADDW9 = 000000	29																			
ADEVCT= 000000	29																			
ADEVN = 000000	29																			
AENV = 000000	29																			
AENVN = 000000	29																			
AFATAL= 000000	29																			
AMADR1= 000000	29																			
AMADR2= 000000	29																			
AMADR3= 000000	29																			
AMADR4= 000000	29																			
AMAMS1= 000000	29																			
AMAMS2= 000000	29																			
AMAMS3= 000000	29																			
AMAMS4= 000000	29																			
AMSGAD= 000000	29																			
AMSGLG= 000000	29																			
AMSGTY= 000000	29																			
AMTYP1= 000000	29																			
AMTYP2= 000000	29																			
AMTYP3= 000000	29																			
AMTYP4= 000000	29																			
ANAME 002264	480#																			
APASS = 000000	29																			
APRIOR= 000000	29																			
APTCU= 000040	2808#	2813																		
APTENV= 000001	2808#	2809	2813																	
APTSIZ= 000200	492	2808#																		
APTSPO= 000100	2808#	2813																		
ASWREG= 000000	29																			
ATESTN= 000000	29																			
AUNIT = 000000	29																			
AUSWR = 000000	29																			
AVECT1= 100320	18#	29																		
AVECT2= 000000	29																			
BADR 023416	2458	2492	2534#																	
BIT0 = 000001	16#	595	614	648	651	670	673	676	698	728	757	785	813							
	840	867	894	921	948	975	1002	1025	1051	1078	1105	1132	1157							

	1183	1210	1238	1265	1292	1319	1346	1377	1435	1438	1791	1814	1837
	1860	1883	1906	1964	1988	2012	2047	2275	2319	2322	2385	2388	2620
BIT00 = 000001	16#												
BIT01 = 000002	16#												
BIT02 = 000004	16#												
BIT03 = 000010	16#												
BIT04 = 000020	16#												
BIT05 = 000040	16#												
BIT06 = 000100	16#												
BIT07 = 000200	16#												
BIT08 = 000400	16#	2806											
BIT09 = 001000	16#	2806	2809										
BIT1 = 000002	16#												
BIT10 = 002000	16#	2809											
BIT11 = 004000	16#	2806											
BIT12 = 010000	16#	2672											
BIT13 = 020000	16#	2809											
BIT14 = 040000	16#	2806											
BIT15 = 100000	16#												
BIT2 = 000004	16#	1937	2600	2703	2708								
BIT3 = 000010	16#	1374											
BIT4 = 000020	16#	1969	1993										
BIT5 = 000040	16#												
BIT6 = 000100	16#												
BIT7 = 000200	16#												
BIT8 = 000400	16#												
BIT9 = 001000	16#												
BPTVEC = 000014	16#												
BSTART 023432	2455	2541#											
BSTRT 024256	2590	2658#											
BUFFER 032374	591*	593	611*	612	640*	643	646	662*	663	668	687*	688*	694
	711*	717*	722*	723*	724	747*	748*	753	770*	775*	776*	781	798*
	803*	804*	809	824*	830*	831*	836	838	851*	857*	858*	863	878*
	884*	885*	890	905*	911*	912*	917	932*	938*	939*	944	946	959*
	965*	966*	971	986*	992*	993*	998	1013*	1018*	1019*	1021	1033	1035*
	1041*	1042*	1047	1062*	1068*	1069*	1074	1089*	1095*	1096*	1101	1116*	1122*
	1123*	1128	1143*	1149*	1150*	1152	1165	1167*	1173*	1174*	1179	1181	1194*
	1200*	1201*	1206	1221*	1228*	1229*	1234	1249*	1255*	1256*	1261	1276*	1282*
	1283*	1288	1303*	1309*	1310*	1315	1330*	1336*	1337*	1342	1357*	1363*	1364*
	1365*	1370	1388*	1395*	1396	1411*	1412	1429	1431*	1432*	1433	1436	1450*
	1451*	1461*	1470*	1471*	1481*	1491*	1492*	1503*	1512*	1521*	1522*	1532*	1533*
	1544*	1553*	1554*	1563*	1572*	1581*	1582*	1591*	1600*	1601*	1610*	1619*	1620*
	1627*	1638*	1639*	1646*	1657*	1658*	1665*	1676*	1677*	1684*	1695*	1696*	1705*
	1706*	1716*	1726*	1727*	1738*	1745*	1754*	1757*	1766*	1767*	1768*	1770*	1785*
	1789	1800*	1801*	1808*	1812	1823*	1824*	1831*	1835	1846*	1847*	1854*	1858
	1869*	1870*	1877*	1881	1892*	1893*	1900*	1904	1915*	1916*	1924	1933	1946*
	1947*	1952	1953*	1954*	1955*	1959*	1960	1978	1979*	1980*	1981*	1984	1985*
	2008*	2010	2043*	2045	2073	2084*	2101	2112*	2129	2141*	2142*	2167	2177*
	2202	2212*	2305*	2313	2408	2512	2517	2522	2527	2541	2543	2544	2545
	2556	2658	2660	2661	2662	2690*	2691*	2692*	2699	2704	2795	2904#	
	459#	2396*	2399	2897									
B1716 002226	2178	2213	2767#										
CALTAN 024732	455#	503*	522*	2257	2297								
CENAB 002216	2793*	2799*	2803#										
CNTR 025114	481#	1527	1535	1587	1593	1606	1612	1625	1631	1644	1650	1663	1669
CONS 002266	1682	1688	2470*	2476	2478	2537	2604*	2610	2612				

TST105	021516	2256#		
TST106	021732	2258	2292	2296#
TST107	022204	2298	2339	2343#
TST11	004744	769	773#	
TST110	022546	2354	2407#	
TST111	023456	2510	2555#	
TST112	024302	2648	2671#	
TST12	005144	797	801#	
TST13	005334	828#		
TST14	005534	855#		
TST15	005732	882#		
TST16	006122	909#		
TST17	006310	936#		
TST2	003412	605#		
TST20	006502	963#		
TST21	006670	990#		
TST22	007060	1016#		
TST23	007230	1034	1039#	
TST24	007420	1066#		
TST25	007606	1093#		
TST26	007776	1120#		
TST27	010166	1147#		
TST3	003546	622	627#	
TST30	010346	1171#		
TST31	010534	1198#		
TST32	010724	1225#		
TST33	011122	1253#		
TST34	011312	1280#		
TST35	011502	1307#		
TST36	011672	1334#		
TST37	012062	1361#		
TST4	003632	635	638#	
TST40	012272	1392#		
TST41	012404	1407#		
TST42	012534	1427#		
TST43	012652	1441	1444#	
TST44	013006	1459	1464#	
TST45	013142	1479	1484#	
TST46	013300	1501	1506#	
TST47	013426	1520	1525#	
TST5	003772	560#		
TST50	013564	1542	1547#	
TST51	013712	1562	1566#	
TST52	014040	1580	1585#	
TST53	014166	1599	1604#	
TST54	014314	1618	1623#	
TST55	014442	1637	1642#	
TST56	014570	1656	1661#	
TST57	014716	1675	1680#	
TST6	004144	686#		
TST60	015044	1694	1699#	
TST61	015172	1714	1719#	
TST62	015330	1736	1741#	
TST63	015456	1756	1760#	
TST64	015624	1781#		
TST65	015772	1799	1804#	

COMMEN	16#														
ENDCOM	16#														
ERROR	16#	600	620	625	636	655	680	705	735	764	792	820	847	874	901
	928	955	982	1009	1032	1058	1085	1112	1139	1164	1190	1217	1245	1272	1299
	1326	1353	1384	1402	1419	1424	1442	1457	1477	1498	1518	1539	1560	1578	1597
	1616	1635	1654	1673	1692	1712	1733	1753	1777	1797	1820	1843	1866	1889	1912
	1945	1973	1997	2018	2024	2031	2053	2059	2066	2092	2120	2151	2189	2224	2241
	2253	2280	2326	2401	2479	2487	2613	2628							
ESCAPE	16#														
GETPRI	16#														
GETSWR	16#														
MULT	16#														
NEWTST	16#	586	605	627	638	660	686	714	745	773	801	828	855	882	909
	936	963	990	1016	1039	1066	1093	1120	1147	1171	1198	1225	1253	1280	1307
	1334	1361	1392	1407	1427	1444	1464	1484	1506	1525	1547	1566	1585	1604	1623
	1642	1661	1680	1699	1719	1741	1760	1781	1804	1827	1850	1873	1896	1919	1951
	1977	1999	2034	2069	2098	2126	2163	2198	2229	2256	2296	2343	2407	2555	2671
POP	16#	2808	2817	2821											
PUSH	16#	2808	2817	2821											
REPORT	16#														
SCOPE	16#	586	605	627	638	660	686	714	745	773	801	828	855	882	909
	936	963	990	1016	1039	1066	1093	1120	1147	1171	1198	1225	1253	1280	1307
	1334	1361	1392	1407	1427	1444	1464	1484	1506	1525	1547	1566	1585	1604	1623
	1642	1661	1680	1699	1719	1741	1760	1781	1804	1827	1850	1873	1896	1919	1951
	1977	1999	2034	2069	2098	2126	2163	2198	2229	2256	2296	2343	2407	2555	2671
	2676														
SETPRI	16#														
SETTRA	2819#														
SETUP	16#	492													
SKIP	16#	622	635	710	740	769	797	1034	1441	1459	1479	1501	1520	1542	1562
	1580	1599	1618	1637	1656	1675	1694	1714	1736	1756	1799	1822	1845	1868	1891
	1914	1996	2153	2193	2258	2292	2298	2339	2354	2510	2648				
SLASH	16#														
SPACE	16#														
STARS	16#	24	27	29	586	605	627	638	660	686	714	745	773	801	828
	855	882	909	936	963	990	1016	1039	1066	1093	1120	1147	1171	1198	1225
	1253	1280	1307	1334	1361	1392	1407	1427	1444	1464	1484	1506	1525	1547	1566
	1585	1604	1623	1642	1661	1680	1699	1719	1741	1760	1781	1804	1827	1850	1873
	1896	1919	1951	1977	1999	2034	2069	2098	2126	2163	2198	2229	2256	2296	2343
	2407	2555	2671	2676	2678	2680	2686	2688	2695	2697	2711	2713	2728	2730	2736
	2738	2750	2754	2763	2766	2787	2791	2806	2808	2809	2811	2813	2815	2817	2819
	2821	2900	2903												
SWRSU	16#														
TRMTRP	2819#	492#													
TYPBIN	16#														
TYPDEC	16#	2676													
TYPNAM	16#														
TYPNUM	16#														
TYPOCS	16#														
TYPOCT	16#	2811													
TYPTXT	16#														
\$\$CMRE	29#														
\$\$CMTM	29#														
\$\$ESCA	16#														
\$\$NEWT	16#	586	605	627	638	660	686	714	745	773	801	828	855	882	909
	936	963	990	1016	1039	1066	1093	1120	1147	1171	1198	1225	1253	1280	1307

	1334	1361	1392	1407	1427	1444	1464	1484	1506	1525	1547	1566	1585	1604	1623
	1642	1661	1680	1699	1719	1741	1760	1781	1804	1827	1850	1873	1896	1919	1951
	1977	1999	2034	2069	2098	2126	2163	2198	2229	2256	2296	2343	2407	2555	2671
\$\$SET	2819#														
\$\$SETM	492#														
\$\$SKIP	16#	622	635	710	740	769	797	1034	1441	1459	1479	1501	1520	1542	1562
	1580	1599	1618	1637	1656	1675	1694	1714	1736	1756	1799	1822	1845	1868	1891
	1914	1996	2153	2193	2258	2292	2298	2339	2354	2510	2648				
.EQUAT	5#	16													
.HEADE	5#	12													
.SETUP	5#	491													
.SWRHI	5#	20													
.SWRLO	20#														
.SACT1	8#	24													
.SAPT8	8#	29#													
.SAPTH	8#	27													
.SAPTY	8#	2808													
.SCATC	5#	21													
.SCMTA	5#	29													
.SEOP	6#	2676													
.SERRO	6#	2809													
.SERRT	7#	2811													
.SPOWE	6#	2821													
.SSCOP	6#	2806													
.STRAP	6#	2819													
.STYPD	7#	2817													
.STYPE	7#	2813													
.STYPO	7#	2815													

. ABS. 032376 000 OVR RO REL GBL D

ERRORS DETECTED: 0
 CZVSCC,CZVSCC/CRF=CZVSCC
 RUN-TIME: 31 20 1 SECONDS
 RUN-TIME RATIO: 107/54=1.9
 CORE USED: 26K (51 PAGES)