

RH70

CONTROLLER DIAGNOSTIC
MD-11-DERHA-C

EP DERHA C DL B
COPYRIGHT 1977
FICHE 1 OF 2

MAR 1977
digital
MADE IN USA

The main body of the document consists of a grid of 140 small diagnostic charts or tables, arranged in 10 rows and 14 columns. Each cell contains technical data, likely related to the MD-11-DERHA-C controller diagnostic. The content is too small to read in detail but appears to be organized into a structured format, possibly a table of contents or a series of test procedures.

This section contains a grid of 150 small diagnostic data tables, arranged in 10 columns and 15 rows. Each table appears to be a structured list of parameters, possibly including test results, error codes, or system status indicators. The text within these tables is too small to be legible, but they follow a consistent layout across the grid.

A small, isolated table located in the bottom right corner of the page. It contains a few lines of text, but the content is illegible due to the low resolution of the scan.

B01

EOF1DDGTBDSEQ

00010000

770224

PDP10 411

HDR1DERHACSEQ

00010000

770224

.REM %

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45

IDENTIFICATION

PRODUCT CODE:	MAINDEC-11-DERHA-C-D
PRODUCT NAME:	RH70 FUNCTIONAL CONTROLLER TEST
DATE RELEASED:	JANUARY 1977
MAINTAINER:	DIAGNOSTIC GROUP

COPYRIGHT (C) 1975, 1977, DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.
 THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT
 NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL
 EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES
 NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS
 DOCUMENT.
 THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A
 LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH
 THE TERMS OF SUCH LICENSE.
 DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY
 FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT
 THAT IS NOT SUPPLIED BY DIGITAL.

46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98

1. ABSTRACT

THIS PROGRAM TESTS THE RH70 IN THE PDP11/70 SUBSYSTEM. IT USES ANY WORKING RH70 PERIPHERAL CONNECTED TO THE RH70 UNDER TEST. IT CAN TEST UP TO FOUR RH70S CONNECTED ON THE SUBSYSTEM. ALTHOUGH THE PERIPHERAL CONNECTED IS USED, THE PERIPHERAL IS NOT TESTED BY THIS PROGRAM.

2. REQUIREMENTS

2.1 EQUIPMENT

PDP11/70 COMPUTER WITH CONSOLE TELETYPE, AND ANY ONE OF THE RH70 PERIPHERALS, (FOR EXAMPLE RPO4, RSO3, RSO4, TU16). THE PERIPHERAL MUST BE COMPLETE AND WORKING. FOR EXAMPLE THE RPO4, RSO3, RSO4 MUST HAVE A SCRATCH PACK ON IT. THE TU MUST HAVE A SCRATCH TAPE.

2.2 STORAGE

THIS PROGRAM HAS 16K WORDS OF MEMORY.

2.3 PRELIMINARY PROGRAMS

ALL PDP11/70 CPU DIAGNOSTICS MUST BE RUN ERROR FREE BEFORE THIS DIAGNOSTIC IS RUN.

3. LOADING PROCEDURE

USE STANDARD LOADING PROCEDURES FOR .BIN TAPES.

4. STARTING PROCEDURE

4.1 OPERATIONAL SWITCH SETTINGS

SWITCH	USE
15	HALT ON ERROR
14	LOOP ON TEST
13	INHIBIT ERROR TYPEOUTS
11	INHIBIT ITERATIONS
10	BELL ON ERROR
9	LOOP ON ERROR
8	LOOP ON TEST IN SWR<7:0>

4.2 STARTING ADDRESS

START AT ADDRESS 200 --- FOR STANDARD RH70.
START AT ADDRESS 210 --- FOR NONSTANDARD RH70.
STARTING ADDRESS 210 SHOULD BE USED TO TEST ANY ONE RH INSTEAD OF ALL THE RH GIVEN BY 200 START

99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128

4.3 PROGRAM AND/OR OPERATOR ACTION

BEFORE STARTING THE PROGRAM, MAKE SURE THAT THE MAGNETIC MEDIUM IS PROPERLY POSITIONED:

- 1.) TU16 - MAGTAPE MUST BE AT LOAD POINT.
- 2.) RP - HEADS MUST BE IN HOME POSITION.

ON STARTING FROM 210 OPERATOR MUST CHOOSE BETWEEN THE RH70 PERIPHERALS AND TYPE THE BASE ADDRESS OF ANY OR ALL OF THE PERIPHERALS CONNECTED TO THE RH70.

5. OPERATING PROCEDURE

5.1 OPERATIONAL SWITCH SETTINGS

SEE SECTION 4.1

5.2 SUB-ROUTINE ABSTRACTS

SEE SECTION 9 "SUBROUTINES"

6. ERRORS

6.1 ERROR HALTS AND DESCRIPTION

ON DETECTION OF AN ERROR THE PROGRAM WILL PRINT ALL RELEVANT INFORMATION AND THEN PROCEED ACCORDING TO THE SWITCH SETTINGS GIVEN IN 4.1. IF ALL SWITCHES ARE DOWN THE PROGRAM WILL CONTINUE.

129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174

DOCUMENT

MAINDEC-11-DERHAC-A

COPYRIGHT 1975, 1977
DIGITAL EQUIPMENT CORPORATION
MAYNARD, MASS. 01754

175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219

2 COPYRIGHT (C) 1975, 1977
DIGITAL EQUIPMENT CORP.
MAYNARD, MASS. 01754

THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
PACKAGE (MAINDEC-11-DZQAC-A4).

13

OPERATIONAL SWITCH SETTINGS

14

SWITCH	USE
15	HALT ON ERROR
14	LOOP ON TEST
13	INHIBIT ERROR TYPEOUTS
11	INHIBIT ITERATIONS
10	BELL ON ERROR
9	LOOP ON ERROR
8	LOOP ON TEST IN SWR<7:0>
7	STOP FURTHER COMPARES IF SW08 IS LOW
6	TYPE ALL REG. WITH ERROR IF SW8 LOW

27

BASIC DEFINITIONS

- 29 INITIAL ADDRESS OF THE STACK POINTER *** 1000 ***
- 40 MISCELLANEOUS DEFINITIONS
- 46 GENERAL PURPOSE REGISTER DEFINITIONS
- 59 PRIORITY LEVEL DEFINITIONS
- 68 "SWITCH REGISTER" SWITCH DEFINITIONS
- 96 DATA BIT DEFINITIONS (BIT00 TO BIT15)
- 124 BASIC "CPU" TRAP VECTOR ADDRESSES

220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257

173

TRAP CATCHER

142 ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS

146

STARTING ADDRESS(ES)

152 STARTING ADDRESS 200 FOR NORMAL STARTS
THIS WILL TEST ALL RPO4'S ON THE SYSTEM A SINGLE DRIVE AT A TIME
STARTING ADDRESS 210 WILL TEST ONLY ONE SPECIFIED DRIVE

160

MEMORY MANAGEMENT DEFINITIONS

162 KT11 VECTOR ADDRESS

166 KT11 STATUS REGISTER ADDRESSES

173 KERNEL "I" PAGE DESCRIPTOR REGISTERS

184 KERNEL "I" PAGE ADDRESS REGISTERS

199

COMMON TAGS

201 THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
USED IN THE PROGRAM.

MAINDEC-11-DERHAC-A

258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311

252

ERROR POINTER TABLE

254 THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCU
THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE I
NOTE1: IF \$ITEMB IS C THE ONLY PERTINENT DATA IS (\$ERRPC).
NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS

260 EM ;;POINTS TO THE ERROR MESSAGE
DH ;;POINTS TO THE DATA HEADER
DT ;;POINTS TO THE DATA
DF ;;POINTS TO THE DATA FORMAT

269 *****

1587

REGISTER ADDRESSES

1834

REGISTER TEST

1899 TEST 1 SIZE FOR RH DEVICES
THIS TEST DETERMINS WHICH RH DEVICE IS ON THE SYSTEM.
IF THE SYSTEM HAS MORE THAN ONE RH DEVICE THEN ONLY ONE
THE DEVICES WILL BE USED IN THE FOLLOWING TESTS.
THE ONE THAT WILL BE USED IS THE FIRST ONE THAT IS PRESE
IN THE FOLLOWING LIST
RS
RP
TM

THE WAY THE TEST WORKS IS AS FOLLOWS:-
A REFERENCE IS MADE TO THE CONTROL AND STATUS REGISTER 1
FOR THE RS BY A TST INSTRUCTION. IF IT RESPONDS THEN IT
ASSUMED PRESENT AND THE LOCATIONS FOR THE I/O REGISTERS
FILLED WITH THE APPROPRIATE ADDRESSES.
THEN THE DRIVE TYPE REGISTER IS CHECKED TO HAVE GOOD
VALUES.
IF THE TST INSTRUCTION TRAPS TO A NON EXISTANT VECTOR
THEN A SIMILAR ATTEMPT IS MADE TO A RP CONTROL AND STATU
REGISTER 1.
THEN A TM IS TRYED.
THEN A MIXED SYSTEM WITH MORE THAN ONE RH DEVICES IS TRYE

2195 TEST 2

UNIT UNDER TEST
THIS TYPES THE UNIT TO BE TESTED
AND IS THE FIRST TEST AFTER THE END OF THE PROGRAM

312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366

MAINDEC-11-DERHAC-A

2302

TEST 3 BIT BANG RHCS1

2304

TEST LOADING AND READING OF ALL POSSIBLE BITS
IN RHCS1 REGISTER.
USE A PATTERN OF WALKING 1'S (1,2,4,10 ETC)
AND WALKING 0'S (-2,-3,-5 ETC)
IN THIS TEST SC!TRE!MCPE!DVA!BIT12!BIT10!RDY!GO BITS WIL
AND RDY!DVA BITS WILL ALWAYS BE SET
AND BIT10 BITS WILL ALWAYS BE CLEARED
IF SWITCH 14 OR 9 OR 8 ARE SET FOR DEBUGGING
THEN A RH CLEAR (RHCS2 BIT #5) WILL BE
GIVEN TO AID SCOPE SYNC'S ON THE CLEAR
SIGNAL.

2383

TEST 4 BIT BANG RHCS2

2385

TEST LOADING AND READING OF ALL POSSIBLE BITS
IN RHCS2 REGISTER.
USE A PATTERN OF WALKING 1'S (1,2,4,10 ETC)
AND WALKING 0'S (-2,-3,-5 ETC)
IN THIS TEST 177740 BITS WILL NOT BE WRITTEN INTO
AND IR BITS WILL ALWAYS BE SET
IF SWITCH 14 OR 9 OR 8 ARE SET FOR DEBUGGING
THEN A RH CLEAR (RHCS2 BIT #5) WILL BE
GIVEN TO AID SCOPE SYNC'S ON THE CLEAR
SIGNAL.

2460

TEST 5 BIT BANG RHCS3

2462

TEST LOADING AND READING OF ALL POSSIBLE BITS
IN RHCS3 REGISTER.
USE A PATTERN OF WALKING 1'S (1,2,4,10 ETC)
AND WALKING 0'S (-2,-3,-5 ETC)
IN THIS TEST 177660 BITS WILL NOT BE WRITTEN INTO
AND 0 BITS WILL ALWAYS BE SET
AND BIT9!BIT8!BIT7!BIT5!BIT4 BITS WILL ALWAYS BE CLEARED
IF SWITCH 14 OR 9 OR 8 ARE SET FOR DEBUGGING
THEN A RH CLEAR (RHCS2 BIT #5) WILL BE
GIVEN TO AID SCOPE SYNC'S ON THE CLEAR
SIGNAL.

2541

TEST 6 BIT BANG RHWC

2543

TEST LOADING AND READING OF ALL POSSIBLE BITS
IN RHWC REGISTER.
USE A PATTERN OF WALKING 1'S (1,2,4,10 ETC)
AND WALKING 0'S (-2,-3,-5 ETC)
IN THIS TEST 0 BITS WILL NOT BE WRITTEN INTO
AND 0 BITS WILL ALWAYS BE SET
IF SWITCH 14 OR 9 OR 8 ARE SET FOR DEBUGGING
THEN A RH CLEAR (RHCS2 BIT #5) WILL BE
GIVEN TO AID SCOPE SYNC'S ON THE CLEAR
SIGNAL.

367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422

MAINDEC-11-DERHAC-A

2618

TEST 7 BIT BANG RHBA

2620

TEST LOADING AND READING OF ALL POSSIBLE BITS
IN RHBA REGISTER.
USE A PATTERN OF WALKING 1'S (1,2,4,10 ETC)
AND WALKING 0'S (-2,-3,-5 ETC)
IN THIS TEST 0 BITS WILL NOT BE WRITTEN INTO
AND 0 BITS WILL ALWAYS BE SET
AND BIT00 BITS WILL ALWAYS BE CLEARED
IF SWITCH 14 OR 9 OR 8 ARE SET FOR DEBUGGING
THEN A RH CLEAR (RHCS2 BIT #5) WILL BE
GIVEN TO AID SCOPE SYNC'S ON THE CLEAR
SIGNAL.

2699

TEST 10 BIT BANG RHBAE

2701

TEST LOADING AND READING OF ALL POSSIBLE BITS
IN RHBAE REGISTER.
USE A PATTERN OF WALKING 1'S (1,2,4,10 ETC)
AND WALKING 0'S (-2,-3,-5 ETC)
IN THIS TEST 177700 BITS WILL NOT BE WRITTEN INTO
AND 0 BITS WILL ALWAYS BE SET
AND 177700 BITS WILL ALWAYS BE CLEARED
IF SWITCH 14 OR 9 OR 8 ARE SET FOR DEBUGGING
THEN A RH CLEAR (RHCS2 BIT #5) WILL BE
GIVEN TO AID SCOPE SYNC'S ON THE CLEAR
SIGNAL.

2784

TEST 11 SILO TEST 1 (ONE WORD WRITE)

AFTER A RH CLEAR IS GIVEN (SET BIT #5 IN RHCS2)
RHCS2 IS CHECKED TO HAVE "IR" (BIT #6) HIGH
TOGETHER WITH UNIT NUMBER
ONE WORD OF ALL ZEROS IS WRITTEN INTO RHDB
BY "CLR"
"OR" (BIT #7) IS WAITED FOR BY A TRAP INSTRUCTION
CALLED "WAT" (NO TIMING IS DONE)
HOWEVER IF "OR" DOES NOT SET WITHIN "WAT" COUNT
DOWN AN ERROR IS REPORTED
RHDB IS READ AND CHECKED TO CONTAIN ZEROS
RHCS2 WILL BE CHECKED TO HAVE "IR" AND UNIT NUMBER
RHCS1, RHCS3, RHBA, RHBAE, RHWC, WILL BE CHECKED TO HAVE
APPROPRIATE VALUES

2973

TEST 12 SILO TEST 2 (ONE WORD WRITE)

AFTER A RH CLEAR IS GIVEN (SET BIT #5 IN RHCS2)
RHCS2 IS CHECKED TO HAVE "IR" (BIT #6) HIGH
TOGETHER WITH UNIT NUMBER
ONE WORD OF ALL ONES IS WRITTEN INTO RHDB
BY "CLR"
"OR" (BIT #7) IS WAITED FOR BY A TRAP INSTRUCTION
CALLED "WAT" (NO TIMING IS DONE)
HOWEVER IF "OR" DOES NOT SET WITHIN "WAT" COUNT
DOWN AN ERROR IS REPORTED
RHDB IS READ AND CHECKED TO CONTAIN ALL ONES

MAINDEC-11-DERHAC-A

RHCS2 WILL BE CHECKED TO HAVE "IR" AND UNIT NUMBER
RHCS1, RHCS3, RHBA, RHBAE, RHWC, WILL BE CHECKED TO HAVE
APPROPRIATE VALUES

3144 TEST 13 SILO TEST 3 (TWO WORD WRITE)

3146 AFTER A RH CLEAR IS GIVEN (SET BIT #5 IN RHCS2)
RHCS2 IS CHECKED TO HAVE "IR" (BIT #6) HIGH,
TOGETHER WITH UNIT NUMBER
ONE WORD = 52525 IS WRITTEN INTO RHDB
RHCS2 IS CHECKED TO HAVE "IR" AND UNIT NUMBER
A SECOND WORD = 12525 IS WRITTEN INTO RHDB
"OR" (BIT #7 IN RHCS2) IS WAITED FOR BY A TRAP
INSTRUCTION CALLED "WAT"
RHDB IS READ AND CHECKED TO CONTAIN 52525
RHCS2 IS CHECKED TO HAVE "IR", "OR" AND UNIT NUMBER
RHDB IS READ A SECOND TIME AND CHECKED TO
CONTAIN 125252
RHCS2 IS CHECKED TO HAVE "IR" AND UNIT NUMBER
THEN ALL REGISTERS RHCS1, RHCS3, RHBA, RHBAE, RHWC
ARE CHECKED TO HAVE APPROPRIATE VALUE

3416 TEST 14 SILO TEST 4 (COUNT PATTERN)

3418 AFTER A RH CLEAR IS GIVEN (SET BIT #5 IN RHCS2)
RHCS2 IS CHECKED TO HAVE "IR" (BIT #6) HIGH, TOGETHER
WITH UNIT NUMBER
EIGHT WORDS, A COUNT PATTERN 0 THRU 7 IS WRITTEN
INTO RHDB
"OR" (BIT #7 IN RHCS2) IS WAITED FOR BY A TRAP
INSTRUCTION CALLED "WAT"
THEN RHCS2 IS CHECKED TO HAVE "IR" LOW AND
"OR" HIGH TOGETHER WITH THE UNIT NUMBER
THEN RHDB IS READ AND COMPARED TO HAVE THE RIGHT VALUE
EIGHT TIES
THEN RHCS2, RHCS1, RHCS3, RHBA, RHBAE, RHWC ARE
CHECKED TO HAVE THE APPROPRIATE VALUE

3808 TEST 15 SILO TEST 5 (FLOATING ONES)

3810 AFTER ARH CLEAR IS GIVEN (SET BIT #5 IN RHCS2)
RHCS2 IS CHECKED TO HAVE "IR" (BIT #6) HIGH,
TOGETHER WITH UNIT NUMBER
EIGHT WORDS, A PATTERN OF FLOATING ONES (1,2,4,10,20,40,
IS WRITTEN INTO RHDB
"OR" (BIT #7 IN RHCS2) IS WAITED FOR BY A TRAP
INSTRUCTION CALLED "WAT"
THEN RHCS2 IS CHECKED TO HAVE "IR" LOW AND
"OR" HIGH TOGETHER WITH THE UNIT NUMBER
THEN RHDB IS READ AND COMPARED TO HAVE THE
RIGHT VALUE AFTER EACH OF THE EIGHT READS.
THEN RHCS2 IS CHECKED TO HAVE "IR"

423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477

MAINDEC-11-DERHAC-A

AND UNIT NUMBER
THEN RHCS1, RHCS3, RHBA, RHBAE, RHWC ARE
CHECKED TO HAVE THE APPROPRIATE VALUE

478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532

4227 TEST 16 SILO TEST 6 (FLOATING ONES IN UPPER BYTE)

4229 AFTER A RH CLEAR IS GIVEN (SET BIT #5 IN RHCS2)
RHCS2 IS CHECKED TO HAVE "IR" (BIT #6) HIGH,
TOGETHER WITH UNIT NUMBER
EIGHT WORDS, A PATTERN OF FLOATING ONES IN UPPER BYTE
400,1000,2000,4000,10000,20000,40000,100000
IS WRITTEN INTO RHDB
"OR" (BIT #7 IN RHCS2) IS WAITED FOR BY A TRAP
INSTRUCTION CALLED "WAT"
THEN RHCS2 IS CHECKED TO HAVE "IR" LOW AND
"OR" HIGH TOGETHER WITH THE UNIT NUMBER
THEN RHDB IS READ AND COMPARED TO HAVE THE
RIGHT VALUE AFTER EACH OF THE EIGHT READS.
THEN RHCS2 IS CHECKED TO HAVE "IR"
AND UNIT NUMBER
THEN RHCS1, RHCS3, RHBA, RHBAE, RHWC ARE
CHECKED TO HAVE THE APPROPRIATE VALUE

4649 TEST 17 SILO TEST 7 (FLOATING 0 IN LOWER BYTE)

4651 AFTER A RH CLEAR IS GIVEN (SET BIT #5 IN RHCS2)
RHCS2 IS CHECKED TO HAVE "IR" (BIT #6) HIGH,
TOGETHER WITH UNIT NUMBER
EIGHT WORDS OF FLOATING ZEROS 177776, 177775, 177773,
177767, 177757, 177737, 177677, 177577
IS WRITTEN INTO RHDB
"OR" (BIT #7 IN RHCS2) IS WAITED FOR BY A TRAP
INSTRUCTION CALLED "WAT"
THEN RHCS2 IS CHECKED TO HAVE "IR" LOW AND
"OR" HIGH TOGETHER WITH THE UNIT NUMBER
THEN RHDB IS READ AND COMPARED TO HAVE THE
RIGHT VALUE AFTER EACH OF THE EIGHT READS.
THEN RHCS2 IS CHECKED TO HAVE "IR"
AND UNIT NUMBER
THEN RHCS1, RHCS3, RHBA, RHBAE, RHWC ARE
CHECKED TO HAVE THE APPROPRIATE VALUE

5070 TEST 20 SILO TEST 8 (FLOATING ZEROS IN UPPER BYTE)

5072 AFTER A RH CLEAR IS GIVEN (SET BIT #5 IN RHCS2)
RHCS2 IS CHECKED TO HAVE "IR" (BIT #6) HIGH,
TOGETHER WITH UNIT NUMBER
5074 EIGHT WORDS, A PATTERN OF FLOATING ZEROS IN UPPER BYTE
177377, 177677, 175777, 173777, 167777, 157777, 137777,
IS WRITTEN INTO RHDB
"OR" (BIT #7 IN RHCS2) IS WAITED FOR BY A TRAP
INSTRUCTION CALLED "WAT"
THEN RHCS2 IS CHECKED TO HAVE "IR" LOW AND

MAINDEC-11-DERHAC-A

"OR" HIGH TOGETHER WITH THE UNIT NUMBER
THEN RHDB IS READ AND COMPARED TO HAVE THE
RIGHT VALUE AFTER EACH OF THE EIGHT READS.
THEN RHCS2 IS CHECKED TO HAVE "IR"
AND UNIT NUMBER
THEN RHCS1, RHCS3, RHBA, RHBAE, RHWC ARE
CHECKED TO HAVE THE APPROPRIATE VALUE

533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586

5508 TEST 21 RHCS1 - MCPE BIT #13 (PARITY LINE = 0)

5510 AN RH CLEAR (SET BIT #5 IN RHCS2) IS GIVEN TO
CLEAR ALL DEVICE REGISTERS
THEN RHER1 (ERROR REGISTER 1) IS CHECKED TO HAVE
ZEROS
SET "PAT" (BIT #4 IN RHCS2) TO INVERT PARITY CHECKING
READ ANY DEVICE REGISTER - HERE RHER1
READ AND CHECK RHCS1 TO CONTAIN SC (BIT #15)
AND MCPE (BIT #13)
WRITE "1" INTO TRE (BIT #14 IN RHCS1)
READ RHCS1 SC, MCPE, AND RDY SHOULD BE SET
GIVE AN RH CLEAR (CLR - BIT #5 IN RHCS2)
CHECK RHCS1 TO HAVE RDY
CHECK RHCS2 TO HAVE ONLY IR AND UNIT NUMBER
CHECK RHCS3, RHBA, RHBAE, RHWC TO HAVE APPROPRIATE
VALUES.

5785 TEST 22 RHCS1 - MCPE BIT #13 (PARITY LINE = 1)

5787 AN RH CLEAR (SET BIT #5 IN RHCS2) IS GIVEN TO CLEAR
ALL DEVICE REGISTERS
WRITE A ONE INTO DISK ADDRESS REGISTER (RHDA)
(IN TAPE DRIVES CALLED REGISTER)
SET "PAT" (RHCS2 BIT #4) THIS WILL INVERT THE PARITY CHE
READ RHDA AND COMPARE IT HAS ONE IN IT
THIS READING SHOULD SET SC, MCPE IN RHCS1
CHECK RHCS1 TO HAVE ONLY RDY SET
CHECK RHCS2, RHCS3, RHBA, RHBAE, RHWC TO HAVE APPROPRIATE
VALUES

5959 TEST 23 TEST DUPLICATED A16 (RHCS1 BIT #8)

5961 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
MOVE 400 (ONE INTO A16) IN RHCS1
READ RHCS1 TO CONTAIN 600 (BIT #8 AND RDY)
READ RHBAE TO CONTAIN "1" (BIT #0 HIGH)

MOVE 0 INTO RHBAE (WRITING 0 INTO RHBAE BIT #0)
READ RHBAE TO CONTAIN 0
READ RHCS1 TO CONTAIN ONLY RDY (BIT #8 IN RHCS1 IS ZERO)

587
 588
 589
 590
 591
 592
 593
 594
 595
 596
 597
 598
 599
 600
 601
 602
 603
 604
 605
 606
 607
 608
 609
 610
 611
 612
 613
 614
 615
 616
 617
 618
 619
 620
 621
 622
 623
 624
 625
 626
 627
 628
 629
 630
 631
 632
 633
 634
 635
 636
 637
 638
 639
 640
 641

MAINDEC-11-DERHAC-A
 6079 TEST 24 TEST DUPLICATED A17 (RHCS1 BIT #9)
 6081 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
 MOVE 400 (ONE INTO A17) IN RHCS1
 READ RHCS1 TO CONTAIN 1200 (BIT #9 AND RDY)
 READ RHBAE TO CONTAIN "2" (BIT #1 HIGH)

 MOVE 0 INTO RHBAE (WRITING 0 INTO RHBAE BIT #1)
 READ RHBAE TO CONTAIN 2
 READ RHCS1 TO CONTAIN ONLY RDY (BIT #9 IN RHCS1 IS ZERO)

 6199 TEST 25 TEST DUPLICATED IE (RHCS1 BIT #6)
 6201 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
 MOVE 100 (ONE INTO IE) IN RHCS1
 READ RHCS1 TO CONTAIN 300 (BIT #6 AND RDY)
 READ RHCS3 TO CONTAIN "100" (BIT #6 HIGH)

 MOVE 0 INTO RHCS3 (WRITING 0 INTO RHCS3 BIT #6)
 6208 READ RHCS3 TO CONTAIN 100
 READ RHCS1 TO CONTAIN ONLY RDY (BIT #6 IN RHCS1 IS ZERO)

 6319 TEST 26 RHCS1 PROGRAM ERROR (PGE BIT #10)
 6321 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
 SET UP FOR A 10 WORD WRITE
 SET "GO" (RHCS1 BIT #0) TWICE IN TWO SUCCESSIVE
 INSTRUCTIONS
 THIS SHOULD SET, SC AND TRE IN RHCS1
 AND PGE SHOULD BE SET IN RHCS2
 RHCS3, ARE CHECKED
 THE NUMBER OF WORDS ARE LARGE ENOUGH SO THAT AFTER
 ONE "BIS" INSTRUCTION TO SET "GO" IN RHCS1
 THERE IS SUFFICIENT TIME TO GIVE ANOTHER "BIS" INSTRUCTI
 TO SET "GO" BEFORE THE FIRST "GO" HAS TIME TO COMPLETE

 6415 TEST 27 RHCS2 - BUS ADDRESS INHIBIT BIT #3
 6417 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #6)
 SET UP FOR A 2 WORD WRITE FROM A BUFFER TAGGED "WRFROM"
 SET BUS ADDRESS INHIBIT RHCS2 BIT #3 "BAI"
 AT THE END OF WRITE CHECK
 RHCS1 TO HAVE ONLY RDY AND COMMAND
 RHCS2 TO HAVE BAI
 RHCS3 TO HAVE 0

MAINDEC-11-DERHAC-A
6424

642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697

RHBA TO HAVE ADDRESS OF "WRFROM"
RHBAE AND RHWC TO HAVE ZEROS

NOW SET UP READ FOR THE SAME DATA WITH
BAI SET TO READ INTO A BUFFER TAGGED "REINTO"
AFTER READ CHECK

RHCS1 TO HAVE ONLY RDY AND COMMAND
RHCS2 TO HAVE BAI
RHCS3 TO HAVE 0

RHBA TO HAVE ADDRESS OF "REINTO"
RHBAE AND RHWC TO HAVE ZEROS
DATA IN REINTO BUFFER IS CHECKED WITH DATA IN
WRFROM BUFFER

6571 TEST 30 RHSC2 MDPE BIT #8 AND RHCS3 IPCK0 BIT #0
CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
SET IPCK0 (RHCS3 BIT #0)
MOVE ALL ZEROS INTO RHDB ONCE
THIS SHOULD SET TRE SC IN RHCS1
READ RHDB ONCE THIS SHOULD SET MDPE (RHCS2 BIT #8)
CHECK RHCS1 FOR RDY (BIT #7), TRE (BIT #14), SC (BIT #15)
"CLR" (RHCS2 BIT #5) IS GIVEN
ALL ERRORS ARE CLEARED
CHECK RHCS1, RHCS2, RHCS3, RHBA, RHBAE, RHWC

6807 TEST 31 RHSC2 MDPE BIT #8 AND RHCS3 IPCK1 BIT #1
CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
SET IPCK1 (RHCS3 BIT #1)
MOVE ALL ZEROS INTO RHDB ONCE
THIS SHOULD SET TRE SC IN RHCS1
READ RHDB ONCE THIS SHOULD SET MDPE (RHCS2 BIT #8)
CHECK RHCS1 FOR RDY (BIT #7), TRE (BIT #14), SC (BIT #15)
"CLR" (RHCS2 BIT #5) IS GIVEN
ALL ERRORS ARE CLEARED
CHECK RHCS1, RHCS2, RHCS3, RHBA, RHBAE, RHWC

7043 TEST 32 RHSC2 MDPE BIT #8 AND RHCS3 IPCK2 BIT #2
CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
SET IPCK2 (RHCS3 BIT #2)
MOVE ALL ZEROS INTO RHDB TWICE
THIS SHOULD NOT SET TRE SC IN RHCS1
READ RHDB ONCE THIS SHOULD SET MDPE (RHCS2 BIT #8)
CHECK RHCS1 FOR RDY (BIT #7), TRE (BIT #14), SC (BIT #15)
READ RHDB A SECOND TIME. CHECK RHCS1, RHCS2, RHCS3
"CLR" (RHCS2 BIT #5) IS GIVEN
ALL ERRORS ARE CLEARED
CHECK RHCS1, RHCS2, RHCS3, RHBA, RHBAE, RHWC

7345 TEST 33 RHSC2 MDPE BIT #8 AND RHCS3 IPCK3 BIT #3
CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
SET IPCK3 (RHCS3 BIT #3)
MOVE ALL ZEROS INTO RHDB TWICE
THIS SHOULD NOT SET TRE SC IN RHCS1
READ RHDB ONCE THIS SHOULD SET MDPE (RHCS2 BIT #8)

MAINDEC-11-DERHAC-A

698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748

CHECK RHCS1 FOR RDY (BIT #7), TRE (BIT #14), SC (BIT #15)
 READ RHDB A SECOND TIME. CHECK RHCS1, RHCS2, RHCS3
 "CLR" (RHCS2 BIT #5) IS GIVEN
 ALL ERRORS ARE CLEARED
 CHECK RHCS1, RHCS2, RHCS3, RHBA, RHBAE, RHWC

7648 TEST 34 RHCS2-WCE BIT #14 AND RHCS3-WCE OW BIT #12

7650 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
 WRITE NINE WORD OF ALL NINES ON TO THE DEVICE
 SET UP TO DO WRITE CHECK ON THAT WORD FROM AN
 ODD WORD BOUNDARY
 DO A ONE WORD WRITE CHECK WITH RHBA FROM AN
 ODD WORD BOUNDARY
 THIS SHOULD SET WCE OW (RHCS3 BIT #12)
 AND WCE (RHCS2 BIT #14)
 "CLR" (RHCS2 BIT #5) IS GIVEN
 ALL ERRORS ARE CLEARED
 CHECK RHCS1, RHCS2, RHCS3, RHBA, RHBAE, RHWC

7881 TEST 35 RHCS2-WCE BIT #14 AND RHCS3-WCE OW BIT #12

7883 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
 WRITE NINE WORD OF ALL NINES ON TO THE DEVICE
 SET UP TO DO WRITE CHECK ON THAT WORD FROM AN
 ODD WORD BOUNDARY
 DO A ONE WORD WRITE CHECK WITH RHBA FROM AN
 ODD WORD BOUNDARY
 THIS SHOULD SET WCE OW (RHCS3 BIT #12)
 AND WCE (RHCS2 BIT #14)
 "CLR" (RHCS2 BIT #5) IS GIVEN
 ALL ERRORS ARE CLEARED
 CHECK RHCS1, RHCS2, RHCS3, RHBA, RHBAE, RHWC

8114 TEST 36 RHCS2-WCE BIT #14 AND RHCS3-WCE EW BIT #11

8116 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
 WRITE NINE WORD OF ALL NINES ON TO THE DEVICE
 SET UP TO DO WRITE CHECK ON THAT WORD FROM AN
 EVEN WORD BOUNDARY
 DO A ONE WORD WRITE CHECK WITH RHBA FROM AN
 EVEN WORD BOUNDARY
 THIS SHOULD SET WCE EW (RHCS3 BIT #11)
 AND WCE (RHCS2 BIT #14)
 "CLR" (RHCS2 BIT #5) IS GIVEN
 ALL ERRORS ARE CLEARED
 CHECK RHCS1, RHCS2, RHCS3, RHBA, RHBAE, RHWC

8347 TEST 37 RHCS2-WCE BIT #14 AND RHCS3-WCE EW BIT #11

MAINDEC-11-DERHAC-A
8349749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798

8349

CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
 WRITE NINE WORD OF ALL NINES ON TO THE DEVICE
 SET UP TO DO WRITE CHECK ON THAT WORD FROM AN
 EVEN WORD BOUNDARY
 DO A ONE WORD WRITE CHECK WITH RHBA FROM AN
 EVEN WORD BOUNDARY
 THIS SHOULD SET WCE EW (RHCS3 BIT #11)
 AND WCE (RHCS2 BIT #14)
 "CLR" (RHCS2 BIT #5) IS GIVEN
 ALL ERRORS ARE CLEARED
 CHECK RHCS1, RHCS2, RHCS3, RHBA, RHBAE, RHWC

8581 TEST 40 TEST DBL (RHCS3 BIT #10) TEST A

8583 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)

8584 SET UP FOR A NINE WORD WRITE FROM AN EVEN WORD BOUNDARY
 DO A NINE WORD WRITE FROM AN EVEN WORD BOUNDARY
 THIS SHOULD NOT SET RHCS3 BIT #10 DBL
 CHECK RHCS3
 CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC

9694 TEST 41 TEST DBL (RHCS3 BIT #10) TEST B

8696 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
 SET UP FOR A TEN WORD WRITE FROM AN EVEN WORD BOUNDARY
 DO A TEN WORD WRITE FROM AN EVEN WORD BOUNDARY
 THIS SHOULD SET RHCS3 BIT #10 DBL
 CHECK RHCS3
 CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC

8808 TEST 42 TEST DBL (RHCS3 BIT #10) TEST C

8810 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
 SET UP FOR A TEN WORD WRITE FROM AN ODD WORD BOUNDARY
 DO A TEN WORD WRITE FROM AN ODD WORD BOUNDARY
 THIS SHOULD NOT SET RHCS3 BIT #10 DBL
 CHECK RHCS3
 CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC

8921 TEST 43 TEST DBL (RHCS3 BIT #10) TEST D

8923 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
 SET UP FOR A ELEVEN WORD WRITE FROM AN EVEN WORD BOUNDARY
 DO A ELEVEN WORD WRITE FROM AN EVEN WORD BOUNDARY
 THIS SHOULD NOT SET RHCS3 BIT #10 DBL
 CHECK RHCS3
 CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC

799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848

MAINDEC-11-DERHAC-A

9034 TEST 44 TEST DBL (RHCS3 BIT #10) TEST E

9036 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
SET UP FOR A TEN WORD WRITE FROM AN EVEN WORD BOUNDARY
WITH BAI IN RHCS2 BIT #3 SET
DO A TEN WORD WRITE FROM AN EVEN WORD BOUNDARY
THIS SHOULD NOT SET RHCS3 BIT #10 DBL
CHECK RHCS3
CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC

9153 TEST 45 TEST DBL (RHCS3 BIT #10) TEST F

9155 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
SET UP FOR A ELEVEN WORD WRITE FROM AN ODD WORD BOUNDARY
DO A ELEVEN WORD WRITE FROM AN ODD WORD BOUNDARY
THIS SHOULD SET RHCS3 BIT #10 DBL
CHECK RHCS3
CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC

9268 TEST 46 TEST DBL (RHCS3 BIT #10) TEST G

9270 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
SET UP FOR A NINE WORD READ FROM AN EVEN WORD BOUNDARY
DO A NINE WORD READ FROM AN EVEN WORD BOUNDARY
THIS SHOULD NOT SET RHCS3 BIT #10 DBL
CHECK RHCS3
CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC

9381 TEST 47 TEST DBL (RHCS3 BIT #10) TEST H

9383 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
SET UP FOR A TEN WORD READ FROM AN EVEN WORD BOUNDARY
DO A TEN WORD READ FROM AN EVEN WORD BOUNDARY
THIS SHOULD SET RHCS3 BIT #10 DBL
CHECK RHCS3
CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC

9495 TEST 50 TEST DBL (RHCS3 BIT #10) TEST I

9497 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
SET UP FOR A TEN WORD READ FROM AN ODD WORD BOUNDARY
DO A TEN WORD READ FROM AN ODD WORD BOUNDARY
THIS SHOULD NOT SET RHCS3 BIT #10 DBL
CHECK RHCS3

9502 CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC

9608 TEST 51 TEST DBL (RHCS3 BIT #10) TEST J

849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902

MAINDEC-11-DERHAC-A
9610

CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
SET UP FOR A ELEVEN WORD READ FROM AN EVEN WORD BOUNDARY
DO A ELEVEN WORD READ FROM AN EVEN WORD BOUNDARY
THIS SHOULD NOT SET RHCS3 BIT #10 DBL
CHECK RHCS3
CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC

9721 TEST 52 TEST DBL (RHCS3 BIT #10) TEST K

9723 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
SET UP FOR A ELEVEN WORD READ FROM AN ODD WORD BOUNDARY
DO A ELEVEN WORD READ FROM AN ODD WORD BOUNDARY
THIS SHOULD SET RHCS3 BIT #10 DBL
CHECK RHCS3
CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC

9835 TEST 53 TEST DBL (RHCS3 BIT #10) TEST L

9837 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
SET UP FOR A TEN WORD READ FROM AN EVEN WORD BOUNDARY
WITH BAI IN RHCS2 BIT #3 SET
DO A TEN WORD READ FROM AN EVEN WORD BOUNDARY
THIS SHOULD NOT SET RHCS3 BIT #10 DBL
CHECK RHCS3
CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC

9955 TEST 54 TEST DBL (RHCS3 BIT #10) TEST M

9957 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
SET UP FOR A ONE WORD WRITE REVERSE FROM AN EVEN WORD BO
DO A ONE WORD WRITE REVERSE FROM AN EVEN WORD BOUNDARY
THIS SHOULD NOT SET RHCS3 BIT #10 DBL
CHECK RHCS3
CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC

10068 TEST 55 TEST DBL (RHCS3 BIT #10) TEST N

10070 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
SET UP FOR A TWO WORD WRITE REVERSE FROM AN EVEN WORD BO
DO A TWO WORD WRITE REVERSE FROM AN EVEN WORD BOUNDARY
THIS SHOULD NOT SET RHCS3 BIT #10 DBL
CHECK RHCS3
CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC

10181 TEST 56 TEST DBL (RHCS3 BIT #10) TEST O

10183 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
SET UP FOR A TWO WORD WRITE REVERSE FROM AN ODD WORD BOU
DO A TWO WORD WRITE REVERSE FROM AN ODD WORD BOUNDARY
THIS SHOULD SET RHCS3 BIT #10 DBL
CHECK RHCS3
CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC

903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952

MAINDEC-11-DERHAC-A

10295 TEST 57 TEST DBL (RHCS3 BIT #10) TEST P

10297 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
SET UP FOR A THREE WORD WRITE REVERSE FROM AN EVEN WORD
DO A THREE WORD WRITE REVERSE FROM AN EVEN WORD BOUNDARY
THIS SHOULD SET RHCS3 BIT #10 DBL
CHECK RHCS3
CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC

10409 TEST 60 TEST DBL (RHCS3 BIT #10) TEST Q

10411 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
SET UP FOR A THREE WORD WRITE REVERSE FROM AN ODD WORD B
DO A THREE WORD WRITE REVERSE FROM AN ODD WORD BOUNDARY
THIS SHOULD NOT SET RHCS3 BIT #10 DBL
CHECK RHCS3
CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC

10522 TEST 61 TEST DBL (RHCS3 BIT #10) TEST R

10524 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
SET UP FOR A TWO WORD WRITE REVERSE FROM AN EVEN WORD BO
WITH BAI IN RHCS2 BIT #3 SET
DO A TWO WORD WRITE REVERSE FROM AN EVEN WORD BOUNDARY

10528 THIS SHOULD NOT SET RHCS3 BIT #10 DBL
CHECK RHCS3
CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC

10642 TEST 62 TEST DBL (RHCS3 BIT #10) TEST S

10644 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
SET UP FOR A NINE WORD READ REVERSE FROM AN EVEN WORD BO
DO A NINE WORD READ REVERSE FROM AN EVEN WORD BOUNDARY
THIS SHOULD SET RHCS3 BIT #10 DBL
CHECK RHCS3
CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC
IF MAG. TAPE NOT USED. THIS TEST IS NOT DONE

10761 TEST 63 TEST DBL (RHCS3 BIT #10) TEST T

10763 CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
SET UP FOR A TEN WORD READ REVERSE FROM AN EVEN WORD BOU
DO A TEN WORD READ REVERSE FROM AN EVEN WORD BOUNDARY
THIS SHOULD NOT SET RHCS3 BIT #10 DBL
CHECK RHCS3
CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC
IF MAG. TAPE NOT USED. THIS TEST IS NOT DONE

```

953          MAINDEC-11-DERHAC-A
954          10879  TEST 64 TEST DBL (RHCS3 BIT #10) TEST U
955
956          10881          CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
957          SET UP FOR A TEN WORD READ REVERSE FROM AN ODD WORD BOUN
958          DO A TEN WORD READ REVERSE FROM AN ODD WORD BOUNDARY
959          THIS SHOULD SET RHCS3 BIT #10 DBL
960          CHECK RHCS3
961          CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC
962          IF MAG. TAPE NOT USED. THIS TEST IS NOT DONE
963
964          10998  TEST 65 TEST DBL (RHCS3 BIT #10) TEST V
965
966          11000          CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
967          SET UP FOR A ELEVEN WORD READ REVERSE FROM AN EVEN WORD
968          DO A ELEVEN WORD READ REVERSE FROM AN EVEN WORD BOUNDARY
969          THIS SHOULD SET RHCS3 BIT #10 DBL
970          CHECK RHCS3
971          CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC
972          IF MAG. TAPE NOT USED. THIS TEST IS NOT DONE
973
974          11117  TEST 66 TEST DBL (RHCS3 BIT #10) TEST W
975
976          11119          CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
977          SET UP FOR A ELEVEN WORD READ REVERSE FROM AN ODD WORD B
978          DO A ELEVEN WORD READ REVERSE FROM AN ODD WORD BOUNDARY
979
980          11122          THIS SHOULD NOT SET RHCS3 BIT #10 DBL
981          CHECK RHCS3
982          CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC
983          IF MAG. TAPE NOT USED. THIS TEST IS NOT DONE
984
985          11235  TEST 67 TEST DBL (RHCS3 BIT #10) TEST X
986
987          11237          CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
988          SET UP FOR A TEN WORD READ REVERSE FROM AN ODD WORD BOUN
989          WITH BAI IN RHCS2 BIT #3 SET
990          DO A TEN WORD READ REVERSE FROM AN ODD WORD BOUNDARY
991          THIS SHOULD NOT SET RHCS3 BIT #10 DBL
992          CHECK RHCS3
993          CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC
994          IF MAG. TAPE NOT USED. THIS TEST IS NOT DONE
995
996          11362  TEST 70 END OF ONE RH
997          THIS IS THE END OF TEST FOR ONE RH
998          IF THERE ARE MORE RH THEN THE PROGRAM
999          JUMPS TO TEST 2 FOR NEXT RH TEST
1000          END PASS IS REACHED ONLY AFTER ALL RH ARE COMPLETE
1001

```

1002
 1003
 1004
 1005
 1006
 1007
 1008
 1009
 1010
 1011
 1012
 1013
 1014
 1015
 1016
 1017
 1018
 1019
 1020
 1021
 1022
 1023
 1024
 1025
 1026
 1027
 1028
 1029
 1030
 1031
 1032
 1033
 1034
 1035
 1036
 1037
 1038
 1039
 1040
 1041

MAINDEC-11-DERHAC-A

```

11400 *****
      END OF PASS ROUTINE
      *****

11402 INCREMENT THE PASS NUMBER ($PASS)
      TYPE "END PASS #XXXXX" (WHERE XXXXX IS A DECIMAL NUMBER)
      IF THERES A MONITOR GO TO IT
      IF THERE ISN'T JUMP TO TST2

11439 *****
      SUBROUTINES
      *****

11655 *****
      RS DATA TRANSFER SUBROUTINE
      *****

11657          THIS SUBROUTINE WRITES OR READS OR DOES A
      WRITE CHECK ON CYLINDER 0 TRACK 0 SECTOR 0
      IT ASSUMES THE RH REGISTERS ARE APPROPRIATELY
      FILLED
      WHEN IT RETURNS FROM THIS SUBROUTINE TO THE
      MAIN PROGRAM IT MEANS THE TRANSFER IS COMPLETE

      THE CALL IS BY A JSR RD, @COMND COMAND

11704 *****
      RPO4 DATA TRANSFER SUBROUTINE
      *****

11706          THIS SUBROUTINE WRITE/READ/WRITE CHECK ON THE RPO4 CYLIN
      TRACK 0, SECTOR 0.

11708          IT ASSUMES THE RH REGISTERS ARE APPROPRIATELY FILLED.
      WHEN IT RETURNS FROM THIS SUBROUTINE TO THE MAIN
      PROGRAM IT MEANS THE COMMAND IS COMPLETE

      THE CALL IS BY A JSR RD, @COMND COMMAND.

```


1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1060
1061
1062
1063
1064
1065
1066
1067
1068
1069
1070
1071
1072
1073
1074
1075
1076
1077
1078
1079
1080
1081
1082
1083
1084
1085
1086
1087
1088
1089

MAINDEC-11-DERHAC-A

```
*****  
11758 TMO2 DATA TRANSFER SUBROUTINE  
*****  
11760 THIS SUBROUTINE WRITES/READS/WRITE CHECKS ON THE TMO2-TU  
ON THE FIRST BLOCK FROM BEGINNING OF TAPE (BOT)  
11762 IT ASSUMES THE RH REGISTERS ARE APPROPRIATELY FILLED.  
WHEN IT RETURNS FROM THIS SUBROUTINE TO THE  
MAIN PROGRAM IT MEANS THE COMMAND IS COMPLETE.  
THE CALL IS  
JSR RO, @COMND  
11915 THIS ROUTINE WILL ALLOW THE CHANGE OF THE BASE  
ADDRESS FROM 176700 TO ANY TYPED VALUE  
11982 *****  
11995 *****  
SCOPE HANDLER ROUTINE  
*****  
11987 THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT  
AND LOAD THE TEST NUMBER($STNM) INTO THE DISPLAY REG.(DISPLAY<7  
AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>  
THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:  
SW14=1 LOOP ON TEST  
SW11=1 INHIBIT ITERATIONS  
SW09=1 LOOP ON ERROR  
SW08=1 LOOP ON TEST IN SWR<7:0>  
CALL SCOPE ;;SCOPE=IOT  
12051 *****  
CONVERT BINARY TO DECIMAL AND TYPE ROUTINE  
*****  
12053 THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIG  
SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER  
NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE T  
BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS  
REPLACED WITH SPACES.  
CALL:  
MOV NUM,-(SP) ;;PUT THE BINARY NUMBER ON THE S  
TYPDS ;;GO TO THE ROUTINE
```


1143
1144
1145
1146
1147
1148
1149
1150
1151
1152
1153
1154
1155
1156
1157
1158
1159
1160
1161
1162
1163
1164
1165
1166
1167
1168
1169
1170
1171
1172
1173
1174
1175
1176
1177
1178
1179
1180
1181
1182
1183
1184
1185
1186
1187
1188
1189
1190
1191
1192
1193

MAINDEC-11-DERHAC-A

```

*****
12303 READ AN OCTAL NUMBER FROM THE TTY
*****

12305 THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
CHANGE IT TO BINARY.
THE INPUT CHARACTERS WILL BE CHECKED TO INSURED THEY ARE LEGAL
OCTAL DIGITS. IF AN ILLEGAL CHARACTER IS READ A "?" WILL BE TYPE
FOLLOWED BY A CARRIAGE RETURN-LINE FEED. THE COMPLETE NUMBER MUS
THEN BE RETYPED. THE INPUT IS TERMINATED BY TYPING A CARRIAGE RE
CALL:
RD OCT          ;;READ AN OCTAL NUMBER
RETURN HERE    ;;LOW ORDER BITS ARE ON TOP OF T
               ;;HIGH ORDER BITS ARE IN $HI OCT

*****
12357 ERROR HANDLER ROUTINE
*****

12359 THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
AND GO TO $ERRTYP ON ERROR
THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
SW15=1 HALT ON ERROR
                HALT CAN OCCUR BEFORE AND AFTER THE ERROR TYPEOU
SW13=1 INHIBIT ERROR TYPEOUTS
SW10=1 BELL ON ERROR
SW09=1 LOOP ON ERROR
CALL      ERROR  N      ;;ERROR=EMT AND N=ERROR ITEM NUMBER

*****
12401 ERROR MESSAGE TYPEOUT ROUTINE
*****

12402 THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE
ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE
AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.
IT IS A COPY OF THE $ERRTYP SUBROUTINE FROM SYSMAC.
WITH ONLY MINOR CHANGES
FIRST IF SWITCH 6 IS SET AND SWITCH 8 RESET THEN
ALL REGISTER CONTENTS WILL BE TYPED BEFOR REPORTING THE ERROR

12409 SECOND IF THE CURRENT ERROR HAS THE SAME ITEM NUMBER
AS THE PREVIOUS ERROR THEN ONLY THE DATA WILL BE TYPED
AND NOT THE ERROR MESSAGE AND HEADER.

12627 *****
*****

```

1194
1195
1196
1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236

MAINDEC-11-DERHAC-A

12631 *****
BINARY TO OCTAL (ASCII) AND TYPE

12633 THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIG
OCTAL (ASCII) NUMBER AND TYPE IT.
\$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS
CALL:

```
MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
TYPOS   ;;CALL FOR TYPEOUT
.BYTE  N               ;;N=1 TO 6 FOR NUMBER OF DIGITS
.BYTE  M               ;;M=1 OR 0
                        ;;1=TYPE LEADING ZEROS
                        ;;0=SUPPRESS LEADING ZER
```

\$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE
\$TYPOS OR \$TYPOC
CALL:

```
MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
TYPON   ;;CALL FOR TYPEOUT
```

\$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
CALL:

```
MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
TYPOC   ;;CALL FOR TYPEOUT
```

12709 *****
TRAP DECODER

12711 THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTIO
AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDR
OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
GO TO THAT ROUTINE.

12724 *****
TRAP TABLE

12726 THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLE
BY THE "TRAP" INSTRUCTION.

1237
1238
1239
1240
1241
1242
1243
1244
1245

MAINDEC-11-DERHAC-A

12746

POWER DOWN AND UP ROUTINES

12786

%

1246
1247
1248
1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296
1297
1298
1299
1300
1301

001000

000011
000012
000015
000200
177776

177774
177772
177570
177570

000000
000001
000002
000003
000004
000005
000006
000007

000000

```

.TITLE MAINDEC-11-DERHAC-A
;*COPYRIGHT (C) 1975-1976
;*DIGITAL EQUIPMENT CORP.
;*MAYNARD, MASS. 01754
;*
;*
;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
;*PACKAGE (MAINDEC-11-DZQAC-C1),MAR 24, 1976.
;*
.SBTTL OPERATIONAL SWITCH SETTINGS
;*
;*      SWITCH          USE
;*      -----          -
;*      15             HALT ON ERROR
;*      14             LOOP ON TEST
;*      13             INHIBIT ERROR TYPEOUTS
;*      11             INHIBIT ITERATIONS
;*      10             BELL ON ERROR
;*      9              LOOP ON ERROR
;*      8              LOOP ON TEST IN SWR<7:0>
;*      7              STOP FURTHER COMPARES IF SW08 IS LOW
;*      6              TYPE ALL REG. WITH ERROR IF SW8 LOW
.SBTTL BASIC DEFINITIONS
;*INITIAL ADDRESS OF THE STACK POINTER *** 1000 ***
STACK= 1000
.EQUIV EMT,ERROR      ;;BASIC DEFINITION OF ERROR CALL
.EQUIV IOT,SCOPE      ;;BASIC DEFINITION OF SCOPE CALL

;*MISCELLANEOUS DEFINITIONS
HT= 11                ;;CODE FOR HORIZONTAL TAB
LF= 12                ;;CODE FOR LINE FEED
CR= 15                ;;CODE FOR CARRIAGE RETURN
CRLF= 200             ;;CODE FOR CARRIAGE RETURN-LINE FEED
PS= 177776           ;;PROCESSOR STATUS WORD
.EQUIV PS,PSW
STKLMT= 177774        ;;STACK LIMIT REGISTER
PIRG= 177772         ;;PROGRAM INTERRUPT REQUEST REGISTER
DSWR= 177570         ;;HARDWARE SWITCH REGISTER
DDISP= 177570        ;;HARDWARE DISPLAY REGISTER

;*GENERAL PURPOSE REGISTER DEFINITIONS
R0= %0                ;;GENERAL REGISTER
R1= %1                ;;GENERAL REGISTER
R2= %2                ;;GENERAL REGISTER
R3= %3                ;;GENERAL REGISTER
R4= %4                ;;GENERAL REGISTER
R5= %5                ;;GENERAL REGISTER
R6= %6                ;;GENERAL REGISTER
R7= %7                ;;GENERAL REGISTER
.EQUIV R6,SP          ;;STACK POINTER
.EQUIV R7,PC          ;;PROGRAM COUNTER

;*PRIORITY LEVEL DEFINITIONS
PRO= 0                ;;PRIORITY LEVEL 0

```

1302	000040	PR1=	40	:::PRIORITY LEVEL	1
1303	000100	PR2=	100	:::PRIORITY LEVEL	2
1304	000140	PR3=	140	:::PRIORITY LEVEL	3
1305	000200	PR4=	200	:::PRIORITY LEVEL	4
1306	000240	PR5=	240	:::PRIORITY LEVEL	5
1307	000300	PR6=	300	:::PRIORITY LEVEL	6
1308	000340	PR7=	340	:::PRIORITY LEVEL	7

:::"SWITCH REGISTER" SWITCH DEFINITIONS

1310		SW15=	100000		
1311	100000	SW14=	40000		
1312	040000	SW13=	20000		
1313	020000	SW12=	10000		
1314	010000	SW11=	4000		
1315	004000	SW10=	2000		
1316	002000	SW09=	1000		
1317	001000	SW08=	400		
1318	000400	SW07=	200		
1319	000200	SW06=	100		
1320	000100	SW05=	40		
1321	000040	SW04=	20		
1322	000020	SW03=	10		
1323	000010	SW02=	4		
1324	000004	SW01=	2		
1325	000002	SW00=	1		
1326	000001	.EQUIV	SW09, SW9		
1327		.EQUIV	SW08, SW8		
1328		.EQUIV	SW07, SW7		
1329		.EQUIV	SW06, SW6		
1330		.EQUIV	SW05, SW5		
1331		.EQUIV	SW04, SW4		
1332		.EQUIV	SW03, SW3		
1333		.EQUIV	SW02, SW2		
1334		.EQUIV	SW01, SW1		
1335		.EQUIV	SW00, SW0		

:::DATA BIT DEFINITIONS (BIT00 TO BIT15)

1338		BIT15=	100000		
1339	100000	BIT14=	40000		
1340	040000	BIT13=	20000		
1341	020000	BIT12=	10000		
1342	010000	BIT11=	4000		
1343	004000	BIT10=	2000		
1344	002000	BIT09=	1000		
1345	001000	BIT08=	400		
1346	000400	BIT07=	200		
1347	000200	BIT06=	100		
1348	000100	BIT05=	40		
1349	000040	BIT04=	20		
1350	000020	BIT03=	10		
1351	000010	BIT02=	4		
1352	000004	BIT01=	2		
1353	000002	BIT00=	1		
1354	000001	.EQUIV	BIT09, BIT9		
1355		.EQUIV	BIT08, BIT8		
1356		.EQUIV	BIT07, BIT7		
1357					

```

1358 .EQUIV BIT06,BIT6
1359 .EQUIV BIT05,BIT5
1360 .EQUIV BIT04,BIT4
1361 .EQUIV BIT03,BIT3
1362 .EQUIV BIT02,BIT2
1363 .EQUIV BIT01,BIT1
1364 .EQUIV BIT00,BIT0
1365
1366 ;*BASIC "CPU" TRAP VECTOR ADDRESSES
1367 000004 ERRVEC= 4 ;: TIME OUT AND OTHER ERRORS
1368 000010 RESVEC= 10 ;: RESERVED AND ILLEGAL INSTRUCTIONS
1369 000014 TBITVEC=14 ;: "T" BIT
1370 000014 TRTVEC= 14 ;: TRACE TRAP
1371 000014 BPTVEC= 14 ;: BREAKPOINT TRAP (BPT)
1372 000020 IOTVEC= 20 ;: INPUT/OUTPUT TRAP (IOT) **SCOPE**
1373 000024 PWRVEC= 24 ;: POWER FAIL
1374 000030 EMTVEC= 30 ;: EMULATOR TRAP (EMT) **ERROR**
1375 000034 TRAPVEC=34 ;: "TRAP" TRAP
1376 000060 TKVEC= 60 ;: TTY KEYBOARD VECTOR
1377 000064 TPVEC= 64 ;: TTY PRINTER VECTOR
1378 000240 PIRQVEC=240 ;: PROGRAM INTERRUPT REQUEST VECTOR
1379
1380 .SBTTL TRAP CATCHER
1381
1382 000000 .=0
1383 ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
1384 ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
1385 ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
1386 .=174
1387 000174 000000 DISPREG: .WORD 0 ;: SOFTWARE DISPLAY REGISTER
1388 000176 000000 SWREG: .WORD 0 ;: SOFTWARE SWITCH REGISTER
1389
1390 000200 000137 005522 .SBTTL STARTING ADDRESS(ES)
1391 000046 000046 JMP @#BEGIN ;: JUMP TO STARTING ADDRESS OF PROGRAM
1392 000046 037554 .=46
1393 000052 000052 $ENDAD
1394 000052 000000 .=52
1395 000210 000210 000000
1396 000210 000137 005532 .=210
1397 JMP @#BEGIN2 ;: JUMP SELECT TEST
1398 ;*STARTING ADDRESS 200 FOR NORMAL STARTS
1399 ;*THIS WILL TEST ALL RPO4'S ON THE SYSTEM A SINGLE DRIVE AT A TIME
1400 ;*
1401 ;*STARTING ADDRESS 210 WILL TEST ONLY ONE SPECIFIED DRIVE
1402 ;*
1403 ;*STARTING ADDRESS 220 WILL JUMP OVER THE TESTS REQUIRING AN OPERATOR
1404 ;*AT THE DRIVE
1405 .SBTTL MEMORY MANAGEMENT DEFINITIONS
1406
1407 ;*KT11 VECTOR ADDRESS
1408 000250 MMVEC= 250
1409
1410 ;*KT11 STATUS REGISTER ADDRESSES
1411
1412 177572 SRO= 177572
1413 177574 SRI= 177574

```



```

1414      177576      SR2=   177576
1415      172516      SR3=   172516
1416
1417      ;*KERNEL "I" PAGE DESCRIPTOR REGISTERS
1418
1419      172300      KIPDR0= 172300
1420      172302      KIPDR1= 172302
1421      172304      KIPDR2= 172304
1422      172306      KIPDR3= 172306
1423      172310      KIPDR4= 172310
1424      172312      KIPDR5= 172312
1425      172314      KIPDR6= 172314
1426      172316      KIPDR7= 172316
1427
1428      ;*KERNEL "I" PAGE ADDRESS REGISTERS
1429
1430      172340      KIPAR0= 172340
1431      172342      KIPAR1= 172342
1432      172344      KIPAR2= 172344
1433      172346      KIPAR3= 172346
1434      172350      KIPAR4= 172350
1435      172352      KIPAR5= 172352
1436      172354      KIPAR6= 172354
1437      172356      KIPAR7= 172356
1438
1439      ;*****
1440      001110      .=1110

```

1441
1442
1443
1444
1445
1446
1447 001100
1448 001100
1449 001100 000000
1450 001102 000
1451 001103 000
1452 001104 000000
1453 001106 000000
1454 001110 000000
1455 001112 000000
1456 001114 000
1457 001115 001
1458 001116 000000
1459 001120 000000
1460 001122 000000
1461 001124 000000
1462 001126 000000
1463 001130 000000
1464 001132 000000
1465 001134 000
1466 001135 000
1467 001136 000000
1468 001140 177570
1469 001142 177570
1470 001144 177560
1471 001146 177562
1472 001150 177564
1473 001152 177566
1474 001154 000
1475 001155 002
1476 001156 012
1477 001157 000
1478 001160 000000
1479
1480 001162 000000
1481 001164 000000
1482 001166 000000
1483 001170 000000
1484 001172 000000
1485 001174 000000
1486 001176 000000
1487 001200 000000
1488 001202 000000
1489 001204 000000
1490 001206 000000
1491 001210 000000
1492 001212 000000
1493 001214 000000
1494 001216 177607 000377
1495 001222 077
1496 001223 015

.SBTTL COMMON TAGS

*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
*USED IN THE PROGRAM.

.=1100
\$CMTAG: .WORD 0
\$PASS: .WORD 0
\$STNM: .BYTE 00
\$ERFLG: .BYTE 00
\$ICNT: .WORD 00
\$LPADR: .WORD 00
\$LPERR: .WORD 00
\$ERTTL: .WORD 00
\$ITEMB: .BYTE 00
\$ERMAX: .BYTE 1
\$ERRPC: .WORD 00
\$GDADR: .WORD 00
\$BDADR: .WORD 00
\$GDDAT: .WORD 00
\$BDDAT: .WORD 00
\$AUTOB: .BYTE 0
\$INTAG: .BYTE 0
\$SWR: .WORD DSWR
\$DISPLAY: .WORD DDISP
\$TKS: 177560
\$TKB: 177562
\$TPS: 177564
\$TPB: 177566
\$NULL: .BYTE 0
\$FILLS: .BYTE 2
\$FILLC: .BYTE 12
\$TPFLG: .BYTE 0
\$REGAD: .WORD 0
\$REG0: .WORD 0
\$REG1: .WORD 0
\$REG2: .WORD 0
\$REG3: .WORD 0
\$REG4: .WORD 0
\$REG5: .WORD 0
\$TMP0: .WORD 0
\$TMP1: .WORD 0
\$TMP2: .WORD 0
\$TMP3: .WORD 0
\$TMP4: .WORD 0
\$TMP5: .WORD 0
\$TIMES: 0
\$ESCAPE: 0
\$BELL: .ASCIZ <207><377><377>
\$QUES: .ASCII /?/
\$CRLF: .ASCII <15>

START OF COMMON TAGS
CONTAINS PASS COUNT
CONTAINS THE TEST NUMBER
CONTAINS ERROR FLAG
CONTAINS SUBTEST ITERATION COUNT
CONTAINS SCOPE LOOP ADDRESS
CONTAINS SCOPE RETURN FOR ERRORS
CONTAINS TOTAL ERRORS DETECTED
CONTAINS ITEM CONTROL BYTE
CONTAINS MAX. ERRORS PER TEST
CONTAINS PC OF LAST ERROR INSTRUCTION
CONTAINS ADDRESS OF 'GOOD' DATA
CONTAINS ADDRESS OF 'BAD' DATA
CONTAINS 'GOOD' DATA
CONTAINS 'BAD' DATA
RESERVED--NOT TO BE USED
AUTOMATIC MODE INDICATOR
INTERRUPT MODE INDICATOR
ADDRESS OF SWITCH REGISTER
ADDRESS OF DISPLAY REGISTER
TTY KBD STATUS
TTY KBD BUFFER
TTY PRINTER STATUS REG. ADDRESS
TTY PRINTER BUFFER REG. ADDRESS
CONTAINS NULL CHARACTER FOR FILLS
CONTAINS # OF FILLER CHARACTERS REQUIRED
INSERT FILL CHARS. AFTER A "LINE FEED"
"TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
CONTAINS THE ADDRESS FROM WHICH (\$REG0) WAS OBTAINED
CONTAINS ((\$REGAD)+0)
CONTAINS ((\$REGAD)+2)
CONTAINS ((\$REGAD)+4)
CONTAINS ((\$REGAD)+6)
CONTAINS ((\$REGAD)+10)
CONTAINS ((\$REGAD)+12)
USER DEFINED
USER DEFINED
USER DEFINED
USER DEFINED
USER DEFINED
USER DEFINED
USER DEFINED
MAX. NUMBER OF ITERATIONS
ESCAPE ON ERROR ADDRESS
CODE FOR BELL
QUESTION MARK
CARRIAGE RETURN

H03

MAINDEC-11-DERHAC-A MACY11 27(732) 09-SEP-76 07:55 PAGE 33
DERHAC.P11 COMMON TAGS

1497 001224 000012
1498

\$LF: .ASCIZ <12> ;;LINE FEED
;*****

1499
1500
1501
1502
1503
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522
1523
1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547
1548
1549
1550
1551
1552
1553
1554

.SBTTL ERROR POINTER TABLE

;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
;*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
;*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;* EM ;;POINTS TO THE ERROR MESSAGE
;* DH ;;POINTS TO THE DATA HEADER
;* DT ;;POINTS TO THE DATA
;* DF ;;POINTS TO THE DATA FORMAT

001226

\$ERRTB:

;ITEM 1

001226 046712

EM1

;;THE RH BASE ADDRESS WAS 772040
;;INDICATING A R504 OR R503
;;BUT THE DRIVE TYPE DID NOT
;;CONTAIN 0,1,2,3 OR 4
;;PC
;;RHDT
;;\$ERRPC,\$BDDAT,0
;;0

DH1

001230 065133

DT1

001232 066566

DF1

001234 066750

;ITEM 2

001236 047064

EM2

;;THE RH BASE ADDRESS WAS 776700
;;INDICATING AN RPO4, RPO5, OR RPO6
;;BUT THE DRIVE TYPE DID NOT
;;CONTAIN 20020 24020, 20021, 24021,
;;20022, OR 24022

DH1

001240 065133

DT1

001242 066566

DF1

001244 066750

;;PC
;;RHDT
;;\$ERRPC,\$BDDAT,0
;;0

;ITEM 3

001246 047266

EM3

;;THE RH BASE ADDRESS WAS 772440
;;INDICATING A TMO2, BUT THE
;;DRIVE TYPE DID NOT CONTAIN
;;142010 INDICATING NO
;;TMO2
;;PC
;;RHDT
;;\$ERRPC,\$BDDAT,0
;;0,0

DH1

001250 065133

DT1

001252 066566

DF1

001254 066750

;ITEM 4

1555	001256	047422	EM4	: THE RH BASE ADDRESS WAS 776300
1556				: INDICATING MORE THAN ONE
1557				: RH DEVICE. BUT THE DRIVE
1558				: TYPE DID NOT CONTAIN
1559				: 0, 1, 2, 3, 4, 20020, 24020, 20021, 24021,
1560				: 20022, 24022, OR 142010 INDICATING NO
1561				: RH DEVICE IS PRESENT
1562	001260	065133	DH1	: PC
1563				: RHDT
1564	001262	066566	DT1	: \$ERRPC, \$BDDAT, 0
1565	001264	066750	DF1	: 0, 0
1566				
1567				: ITEM 5
1568	001266	047721	EMS	: THE UNIBUS TIMED OUT
1569				: FOR EACH OF THE FOLLOWING
1570				: ADDRESSES, INDICATING
1571				: NO RH ON THE SYSTEM
1572				
1573				: SO ABORT PROGRAM
1574	001270	065142	DH5	: PC
1575				: UNIBUS ADDRESSES ON WHICH
1576				: TIME OUT OCCURRED
1577	001272	066574	DT5	: \$ERRPC, RSCS1, RPCS1, TMCS1, MIXCS1
1578	001274	066752	DF5	: 0, 0, 0, 0, 0
1579				
1580				: ITEM 6
1581	001276	050074	EM6	: AFTER AN RH CLEAR (BIT #5
1582				: IN RHCS2) RHCS2 DOES NOT
1583				: HAVE ONLY IR AND UNIT
1584				: NUMBER
1585	001300	065216	DH6	: PC
1586				: TEST NO
1587				: RHCS2 GOOD
1588				: RHCS2 BAD
1589	001302	066610	DT6	: \$ERRPC, TSTNM, \$GDDAT, \$BDDAT
1590	001304	066757	DF6	: 0, 0, 0, 0
1591				
1592				: ITEM 7
1593	001306	050212	EM7	: AFTER CLEARING THE RH AND
1594				: WRITING ONE WORD INTO
1595				: RHDB AND READING IT
1596				: BACK CAUSED RHDB TO
1597				: HAVE WRONG VALUE GIVEN IN BAD RHDB
1598	001310	065261	DH7	: PC
1599				: TEST NO
1600				: RHDB GOOD
1601				: RHDB BAD
1602	001312	066610	DT6	: \$ERRPC, TSTNM, \$GDDAT, \$BDDAT
1603	001314	066757	DF6	: 0, 0, 0, 0
1604				
1605				: ITEM 10
1606	001316	050404	EM10	: AFTER CLEARING THE RH AND
1607				: WRITING ONE WORD INTO
1608				: RHDB AND READING IT
1609				: BACK, CAUSED RHCS2 TO
1610				: HAVE WRONG DATA

1611					: GIVEN IN BAD RHCS2
1612	001320	065216		DH6	: PC
1613					: TEST NUMBER
1614					: RHCS2 GOOD
1615					: RHCS2 BAD
1616	001322	066610		DT6	: \$ERRPC, TSTNM, \$GDDAT, \$BDDAT
1617	001324	066757		DF6	: 0,0,0,0
1618					
1619					: ITEM 11
1620	001326	050577		EM11	: AFTER CLEARING THE RH AND
1621					: WRITING ONE WORD INTO
1622					: RHDB AND READING IT
1623					: BACK, CAUSED RHCS1 TO
1624					: HAVE WRONG DATA
1625					: GIVEN IN BAD RHCS1
1626	001330	065321		DH11	: PC
1627					: TEST NUMBER
1628					: RHCS1 GOOD
1629					: RHCS1 BAD
1630	001332	066610		DT6	: \$ERRPC, TSTNM, \$GDDAT, \$BDDAT
1631	001334	066757		DF6	: 0,0,0,0
1632					
1633					: ITEM 12
1634	001336	050772		EM12	: AFTER CLEARING THE RH AND
1635					: WRITING ONE WORD INTO
1636					: RHDB AND READING IT
1637					: BACK, CAUSED RHCS3 TO
1638					: HAVE WRONG DATA
1639					: GIVEN IN BAD RHCS3
1640	001340	065363		DH12	: PC
1641					: TEST NUMBER
1642					: RHCS3 GOOD
1643					: RHCS3 BAD
1644	001342	066610		DT6	: \$ERRPC, TSTNM, \$GDDAT, \$BDDAT
1645	001344	066757		DF6	: 0,0,0,0
1646					
1647					: ITEM 13
1648	001346	051165		EM13	: AFTER CLEARING THE RH AND
1649					: WRITING ONE WORD INTO
1650					: RHDB AND READING IT
1651					: BACK, CAUSED RHBA TO
1652					: HAVE WRONG DATA
1653					: GIVEN IN BAD RHBA
1654	001350	065425		DH13	: PC
1655					: TEST NUMBER
1656					: RHBA GOOD
1657					: RHBA BAD
1658	001352	066610		DT6	: \$ERRPC, TSTNM, \$GDDAT, \$BDDAT
1659	001354	066757		DF6	: 0,0,0,0
1660					
1661					: ITEM 14
1662	001356	051357		EM14	: AFTER CLEARING THE RH AND
1663					: WRITING ONE WORD INTO
1664					: RHDB AND READING IT
1665					: BACK, CAUSED RHBAE TO
1666					: HAVE WRONG DATA

1667					: GIVEN IN BAD RHBAE
1668	001360	065465		DH14	: PC
1669					: TEST NUMBER
1670					: RHBAE GOOD
1671					: RHBAE BAD
1672	001362	066610		DT6	: SERRPC, TSTNM, \$GDDAT, \$BDDAT
1673	001364	066757		DF6	: 0,0,0,0
1674					
1675					: ITEM 15
1676	001366	051552		EM15	: AFTER CLEARING THE RH AND
1677					: WRITING ONE WORD INTO
1678					: RHDB AND READING IT
1679					: BACK, CAUSED RHWC TO
1680					: HAVE WRONG DATA
1681					: GIVEN IN BAD RHWC
1682	001370	065527		DH15	: PC
1683					: TEST NUMBER
1684					: RHWC GOOD
1685					: RHWC BAD
1686	001372	066610		DT6	: SERRPC, TSTNM, \$GDDAT, \$BDDAT
1687	001374	066757		DF6	: 0,0,0,0
1688					
1689					: ITEM 16
1690	001376	051744		EM16	: AFTER CLEARING THE RH AND
1691					: WRITING ONE WORD INTO
1692					: RHDB
1693					: CAUSED RHCS2 TO
1694					: HAVE WRONG DATA
1695					: GIVEN IN BAD RHCS2
1696	001400	065216		DH6	: PC
1697					: TEST NUMBER
1698					: RHCS2 GOOD
1699					: RHCS2 BAD
1700	001402	066610		DT6	: SERRPC, TSTNM, \$GDDAT, \$BDDAT
1701	001404	066757		DF6	: 0,0,0,0
1702					
1703					: ITEM 17
1704	001406	052137		EM17	: AFTER CLEARING THE RH AND
1705					: WRITING TWO WORD INTO
1706					: RHDB AND READING IT
1707					: BACK, CAUSED RHDB TO
1708					: HAVE WRONG DATA
1709					: GIVEN IN BAD RHDB
1710	001410	065261		DH7	: PC
1711					: TEST NUMBER
1712					: RHDB GOOD
1713					: RHDB BAD
1714	001412	066610		DT6	: SERRPC, TSTNM, \$GDDAT, \$BDDAT
1715	001414	066757		DF6	: 0,0,0,0
1716					
1717					: ITEM 20
1718	001416	052331		EM20	: AFTER CLEARING THE RH AND
1719					: WRITING TWO WORD INTO
1720					: RHDB AND READING ONE
1721					: BACK, CAUSED RHCS2 TO
1722					: HAVE WRONG DATA

1723				: GIVEN IN BAD RHCS2
1724	001420	065216	DH6	: PC
1725				: TEST NUMBER
1726				: RHCS2 GOOD
1727				: RHCS2 BAD
1728	001422	066610	DT6	: \$ERRPC, TSTNM, \$GDDAT, \$BDDAT
1729	001424	066757	DF6	: 0,0,0,0
1730				
1731				: ITEM 21
1732	001426	052525	EM21	: AFTER CLEARING THE RH AND
1733				: WRITING TWO WORD INTO
1734				: RHDB AND READING IT
1735				: BACK TWICE, CAUSED RHDB TO
1736				: HAVE WRONG DATA
1737				: GIVEN IN BAD RHDB
1738	001430	065261	DH7	: PC
1739				: TEST NUMBER
1740				: RHDB GOOD
1741				: RHDB BAD
1742	001432	066610	DT6	: \$ERRPC, TSTNM, \$GDDAT, \$BDDAT
1743	001434	066757	DF6	: 0,0,0,0
1744				
1745				: ITEM 22
1746	001436	052725	EM22	: AFTER CLEARING THE RH AND
1747				: WRITING TWO WORD INTO
1748				: RHDB AND READING IT
1749				: BACK TWICE, CAUSED RHCS2 TO
1750				: HAVE WRONG DATA
1751				: GIVEN IN BAD RHCS2
1752	001440	065216	DH6	: PC
1753				: TEST NUMBER
1754				: RHCS2 GOOD
1755				: RHCS2 BAD
1756	001442	066610	DT6	: \$ERRPC, TSTNM, \$GDDAT, \$BDDAT
1757	001444	066757	DF6	: 0,0,0,0
1758				
1759				: ITEM 23
1760	001446	053126	EM23	: AFTER CLEARING THE RH AND
1761				: WRITING EIGHT WORD INTO
1762				: RHDB
1763				: CAUSED RHCS2 TO
1764				: HAVE WRONG DATA
1765				: GIVEN IN BAD RHCS2
1766	001450	065216	DH6	: PC
1767				: TEST NUMBER
1768				: RHCS2 GOOD
1769				: RHCS2 BAD
1770	001452	066610	DT6	: \$ERRPC, TSTNM, \$GDDAT, \$BDDAT
1771	001454	066757	DF6	: 0,0,0,0
1772				
1773				: ITEM 24
1774	001456	053323	EM24	: THE RH WAS CLEARED
1775				: AND A PATTERN OF 8 WORDS
1776				: WERE WRITTEN INTO RHDB
1777				: READING RHDB FOR THE
1778				: "N" TH. TIME GAVE WRONG

1779				: VALUE IN RHDB
1780				: N IS GIVEN IN "WORD NO"
1781	001460	065567	DH24	: PC
1782				: TEST NO
1783				: WORD NO
1784				: RHDB GOOD
1785				: RHDB BAD
1786	001462	066622	DT24	: \$ERRPC, TSTNM, \$GDDAT, \$BDDAT
1787	001464	066763	DF24	: 0,0,0,0
1788				
1789				
1790	001466	053553	; ITEM 25 EM25	: THE RH WAS CLEARED AND
1791				: A PATTERN OF 8 WORDS WERE
1792				: WRITTEN INTO RHDB
1793				: AFTER READING ALL 8 WORDS
1794				: FOLLOWING REGISTER CONTAINED WRONG
1795				: VALUE
1796	001470	065216	DH6	: PC
1797				: TEST NO
1798				: RHCS2 GOOD
1799				: RHCS2 BAD
1800	001472	066610	DT6	: \$ERRPC, TSTNM, \$GDDAT, \$BDDAT
1801	001474	066757	DF6	: 0,0,0,0
1802				
1803				
1804	001476	053553	; ITEM 26 EM25	
1805	001500	065321	DH11	
1806	001502	066610	DT6	
1807	001504	066757	DF6	: 0,0
1808				
1809				
1810	001506	053553	; ITEM 27 EM25	
1811	001510	065363	DH12	: PC
1812				: TEST NO
1813				: RHCS3 GOOD
1814				: RHCS3 BAD
1815	001512	066610	DT6	: \$ERRPC, TSTNM, \$GDDAT, \$BDDAT
1816	001514	066757	DF6	: 0,0,0,0
1817				
1818				
1819	001516	053553	; ITEM 30 EM25	
1820	001520	065425	DH13	: PC
1821				: TEST NO
1822				: RHBA GOOD
1823				: RHBA BAD
1824	001522	066610	DT6	: \$ERRPC, TSTNM, \$GDDAT, \$BDDAT
1825	001524	066757	DF6	: 0,0,0,0
1826				
1827				
1828	001526	053553	; ITEM 31 EM25	
1829	001530	065465	DH14	: PC
1830				: TEST NO
1831				: RHBAE GOOD
1832				: RHBAE BAD
1833	001532	066610	DT6	: \$ERRPC, TSTNM, \$GDDAT, \$BDDAT
1834	001534	066757	DF6	: 0,0,0,0

1835					
1836					
1837	001536	053553			
1838	001540	065527			
1839					
1840					
1841					
1842	001542	066610			
1843	001544	066757			
1844					
1845					
1846	001546	054002			
1847					
1848					
1849					
1850	001550	065637			
1851					
1852					
1853					
1854	001552	066610			
1855	001554	066757			
1856					
1857					
1858	001556	054116			
1859					
1860					
1861					
1862					
1863					
1864	001560	065637			
1865					
1866					
1867					
1868	001562	066610			
1869	001564	066757			
1870					
1871					
1872	001566	054360			
1873					
1874					
1875					
1876					
1877					
1878	001570	065321			
1879					
1880					
1881					
1882	001572	066610			
1883	001574	066757			
1884					
1885					
1886	001576	054556			
1887					
1888					
1889					
1890					

; ITEM 32

EM25
DH15

; PC
; TEST NO
; RHC GOOD
; RHC BAD
; SERRPC, TSTNM, \$GDDAT, \$BDDAT
; 0,0,0,0

; ITEM 33

EM33

; SETTING RH CLEAR BIT #5
; IN RHCS2 CAUSED
; ERROR REGISTER 1 TO HAVE
; WRONG VALUE

DH33

; PC
; TEST NO
; RHER1 GOOD
; RHER1 BAD
; SERRPC, TSTNM, \$GDDAT, \$BDDAT

; ITEM 34

EM34

; AN RH LCLEAR WAS GIVEN
; RHER1 WAS CHECKED TO HAVE ZERO
; PAT (BIT #4 RHCS2) WAS SET
; TO INVERT PARITY CHECKING
; RHER1 WAS READ BUT DID NOT
; CONTAIN WHAT IS IN RHER1 GOOD

DH33

; PC
; TEST NO
; RHER1 GOOD
; RHER1 BAD
; SERRPC, TSTNM, \$GDDAT, \$BDDAT
; 0,0,0,0

; ITEM 35

EM35

; RH CLEAR WAS GIVEN
; RHER1 WAS CHECKED
; PAT (BIT #4 RHCS2) WAS SET
; AND RHER1 WAS READ
; RHCS1 SHOULD HAVE RDY
; SC AND MCPE SET

DH11

; PC
; TEST NO
; RHCS1 GOOD
; RHCS1 BAD
; SERRPC, TSTNM, \$GDDAT, \$BDDAT
; 0,0,0,0

; ITEM 36

EM36

; RH CLEAR WAS GIVEN
; RHER1 WAS CHECKED
; PAT (RHCS2-BIT #4) WAS SET
; RHER1 WAS READ AND CHECKED
; "1" WAS WRITTEN INTO "TRE"-RHCS1

1891				: ON CHECKING RHCS1
1892				: IT DID NOT CONTAIN SC,MCPE
1893				: AND RDY
1894	001600	065321	DH11	: PC
1895				: TEST NUMBER
1896				: RHCS1 GOOD
1897				: RHCS1 BAD
1898	001602	066610	DT6	: \$ERRPC, TSTNM, \$GDDAT, \$BDDAT
1899	001604	066757	DF6	: 0,0,0,0
1900				
1901				
1902	001606	055033	EM37	: RH WAS CLEARED
1903				: RHER1 WAS CHECKED
1904				: PAT (RHCS2-BIT #4) WAS SET
1905				: RHER1 WAS READ
1906				: "1" WAS WRITTEN IN "TRE" RHCS1
1907				: AN RH CLEAR WAS TO
1908				: GIVE WHAT IS IN "GOOD"
1909				: BUT GAVE WHAT IS IN "BAD"
1910	001610	065321	DH11	: PC
1911				: TEST NO
1912				: RHCS1 GOOD
1913				: RHCS1 BAD
1914	001612	066610	DT6	: \$ERRPC, TSTNM, \$GDDAT, \$BDDAT
1915	001614	066757	DF6	: 0,0,0,0
1916				
1917				
1918	001616	055033	EM37	
1919	001620	065216	DH6	
1920	001622	066610	DT6	
1921	001624	066757	DF6	
1922				
1923				
1924	001626	055033	EM37	
1925	001630	065363	DH12	
1926	001632	066610	DT6	
1927	001634	066757	DF6	
1928				
1929				
1930	001636	055033	EM37	
1931	001640	065425	DH13	
1932	001642	066610	DT6	
1933	001644	066757	DF6	
1934				
1935				
1936	001646	055033	EM37	
1937	001650	065465	DH14	
1938	001652	066610	DT6	
1939	001654	066757	DF6	
1940				
1941				
1942	001656	055033	EM37	
1943	001660	065527	DH15	
1944	001662	066610	DT6	
1945	001664	066757	DF6	
1946				

1947			
1948	001666	055335	; ITEM 45 EM45
1949			
1950			
1951			
1952			
1953			
1954			
1955			
1956			
1957	001670	065701	DH45
1958			
1959			
1960			
1961	001672	066610	DT6
1962	001674	066757	DF6
1963			
1964			; ITEM 46 EM46
1965	001676	055573	
1966			
1967			
1968			
1969			
1970			
1971			
1972			
1973			
1974	001700	065321	DH11
1975			
1976			
1977			
1978	001702	066610	DT6
1979	001704	066757	DF6
1980			
1981			; ITEM 47 EM46
1982	001706	055573	
1983	001710	065216	DH6
1984	001712	066610	DT6
1985	001714	066757	DF6
1986			
1987			; ITEM 50 EM46
1988	001716	055573	
1989	001720	065363	DH12
1990	001722	066610	DT6
1991	001724	066757	DF6
1992			
1993			; ITEM 51 EM46
1994	001726	055573	
1995	001730	065425	DH13
1996	001732	066610	DT6
1997	001734	066757	DF6
1998			
1999			; ITEM 52 EM46
2000	001736	055573	
2001	001740	065465	DH14
2002	001742	066610	DT6

```

; AFTER AN RH CLEAR
; "1" WAS WRITTEN IN THE DISK
; ADDRESS REGISTER (IN TAPE
; DRIVES CALLED FRAME COUNT )
; PAT IN RHCSI WAS SET
; ON READING RHDA (IN TAPE
; DRIVES RHFC ) IT DID NOT
; CONTAIN "1"
; RHDA=RHFC
; PC
; TEST NO
; RHDA GOOD
; RHDA BAD
; SERRPC, TSTNM, $GDDAT, $BDDAT
; 0,0,0,0

```

```

; AFTER AN RH CLEAR
; "1" WAS WRITTEN IN THE
; DISK ADDRESS REGISTER (IN
; TAPE
; PAT IN RHCSI WAS SET
; ON READING RHDA (IN TAPE
; ) FOLLOWING
; REGISTER DID NOT CONTAIN
; WHAT IS IN "GOOD"
; PC
; TEST NO
; RHCSI GOOD
; RHCSI BAD
; SERRPC, TSTNM, $GDDAT, $BDDAT

```

2003 001744 066757
 2004
 2005
 2006 001746 055573
 2007 001750 065527
 2008 001752 066610
 2009 001754 066757
 2010
 2011
 2012 001756 056074
 2013
 2014
 2015
 2016
 2017
 2018 001760 065321
 2019 001762 066610
 2020 001764 066757
 2021
 2022
 2023 001766 056074
 2024 001770 065465
 2025 001772 066610
 2026 001774 066757
 2027
 2028
 2029 001776 056305
 2030
 2031
 2032
 2033
 2034
 2035 002000 065465
 2036 002002 066610
 2037 002004 066757
 2038
 2039
 2040 002006 056305
 2041 002010 065321
 2042 002012 066610
 2043 002014 066757
 2044
 2045
 2046 002016 056543
 2047
 2048
 2049
 2050
 2051
 2052 002020 065321
 2053 002022 066610
 2054 002024 066757
 2055
 2056
 2057 002026 056543
 2058 002030 065465

DF6
 ; ITEM 53
 EM46
 DH15
 DT6
 DF6
 ; ITEM 54
 EM54
 DH11
 DT6
 DF6
 ; ITEM 55
 EM54
 DH14
 DT6
 DF6
 ; ITEM 56
 EM56
 DH14
 DT6
 DF6
 ; ITEM 57
 EM56
 DH11
 DT6
 DF6
 ; ITEM 60
 EM60
 DH11
 DT6
 DF6
 ; ITEM 61
 EM60
 DH14

; AN RH CLEAR (RHCS2 BIT #5)
 ; WAS GIVEN
 ; A16 (RHCS1 BIT #8) WAS SET
 ; ON READING THE FOLLOWING
 ; REGISTER IT DID NOT
 ; CONTAIN WHAT IS IN "GOOD"

; AN RH CLEAR (RHCS2 BIT #5)
 ; WAS GIVEN
 ; A16 WAS WRITTEN IN RHCS1
 ; ALL ZEROS WERE WRITTEN IN RHBAE
 ; THE FOLLOWING REGISTER DID
 ; NOT CONTAIN WHAT IS IN "GOOD"

; AN RH CLEAR (RHCS2 BIT #5)
 ; WAS GIVEN
 ; A17 (RHCS1 BIT #9) WAS SET
 ; ON READING THE FOLLOWING
 ; REGISTER IT DID NOT
 ; CONTAIN WHAT IS IN "GOOD"

2059	002032	066610	DT6		
2060	002034	066757	DF6		
2061					
2062				: ITEM 62	
2063	002036	056754	EM62		: AN RH CLEAR (RHCS2 BIT #5)
2064					: WAS GIVEN
2065					: A17 WAS WRITTEN IN RHCS1
2066					: ALL ZEROS WERE WRITTEN IN RHBAE
2067					: THE FOLLOWING REGISTER DID
2068					: NOT CONTAIN WHAT IS IN "GOOD"
2069	002040	065465	DH14		
2070	002042	066610	DT6		
2071	002044	066757	DF6		
2072					
2073				: ITEM 63	
2074	002046	056754	EM62		
2075	002050	065321	DH11		
2076	002052	066610	DT6		
2077	002054	066757	DF6		
2078					
2079				: ITEM 64	
2080	002056	057211	EM64		: AN RH CLEAR (RHCS2 BIT #5)
2081					: WAS GIVEN
2082					: IE (RHCS1 BIT #6) WAS SET
2083					: ON READING THE FOLLOWING
2084					: REGISTER IT DID NOT
2085					: CONTAIN WHAT IS IN "GOOD"
2086	002060	065321	DH11		
2087	002062	066610	DT6		
2088	002064	066757	DF6		
2089					
2090				: ITEM 65	
2091	002066	057211	EM64		
2092	002070	065363	DH12		
2093	002072	066610	DT6		
2094	002074	066757	DF6		
2095					
2096				: ITEM 66	
2097	002076	057211	EM64		: AN RH CLEAR (RHCS2 BIT #5)
2098					: WAS GIVEN
2099					: A16 WAS WRITTEN IN RHCS1
2100					: ALL ZEROS WERE WRITTEN IN RHBAE
2101					: THE FOLLOWING REGISTER DID
2102					: NOT CONTAIN WHAT IS IN "GOOD"
2103	002100	065363	DH12		
2104	002102	066610	DT6		
2105	002104	066757	DF6		
2106					
2107				: ITEM 67	
2108	002106	057211	EM64		
2109	002110	065321	DH11		
2110	002112	066610	DT6		
2111	002114	066757	DF6		
2112					
2113				: ITEM 70	
2114	002116	057660	EM70		: RH CLEAR WAS GIVEN

: TWO SUCCESSIVE "GO" (RHCS1 BIT #0)
: WAS GIVEN WITHOUT GIVING
: TIME FOR FIRST "GO" TO
: COMPLETE
: THE FOLLOWING REGISTER
: DID NOT CONTAIN WHAT IS
: IN "GOOD"

2115			
2116			
2117			
2118			
2119			
2120			
2121			
2122	002120	065321	DH11
2123	002122	066610	DT6
2124	002124	066757	DF6
2125			
2126			: ITEM 71
2127	002126	057660	EM70
2128	002130	065216	DH6
2129	002132	066610	DT6
2130	002134	066757	DF6
2131			
2132			: ITEM 72
2133	002136	057660	EM70
2134	002140	065363	DH12
2135	002142	066610	DT6
2136	002144	066757	DF6
2137			
2138			: ITEM 73
2139	002146	057660	EM70
2140	002150	065425	DH13
2141	002152	066610	DT6
2142	002154	066757	DF6
2143			
2144			: ITEM 74
2145	002156	057660	EM70
2146	002160	065465	DH14
2147	002162	066610	DT6
2148	002164	066757	DF6
2149			
2150			: ITEM 75
2151	002166	057660	EM70
2152	002170	065527	DH15
2153	002172	066610	DT6
2154	002174	066757	DF6
2155			
2156			: ITEM 76
2157	002176	060134	EM76
2158			
2159			
2160			
2161			
2162			
2163			
2164			
2165	002200	065321	DH11
2166	002202	066610	DT6
2167	002204	066757	DF6
2168			
2169			: ITEM 77
2170	002206	060134	EM76

: RH CLEAR WAS GIVEN A 2 WORD
: WRITE WAS DONE FROM A
: LOCATION TAGED WRFROM
: AND WITH BAI BIT SET
: AT THE END OF THE WRITE
: THE FOLLOWING REGISTER DID
: NOT CONTAIN WHAT IS
: IN GOOD

2171	002210	065216	DH6
2172	002212	066610	DT6
2173	002214	066757	DF6
2174			
2175			; ITEM 100
2176	002216	060134	EM76
2177	002220	065363	DH12
2178	002222	066610	DT6
2179	002224	066757	DF6
2180			
2181			; ITEM 101
2182	002226	060134	EM76
2183	002230	065425	DH13
2184	002232	066610	DT6
2185	002234	066757	DF6
2186			
2187			; ITEM 102
2188	002236	060134	EM76
2189	002240	065465	DH14
2190	002242	066610	DT6
2191	002244	066757	DF6
2192			
2193			; ITEM 103
2194	002246	060134	EM76
2195	002250	065527	DH15
2196	002252	066610	DT6
2197	002254	066757	DF6
2198			
2199			; ITEM 104
2200	002256	060427	EM104
2201			
2202			
2203			
2204			
2205			
2206			
2207	002260	065741	DH104
2208	002262	066636	DT104
2209	002264	066770	DF104
2210			
2211			; ITEM 105
2212	002266	060427	EM104
2213	002270	066011	DH105
2214	002272	066652	DT105
2215	002274	066775	DF105
2216			
2217			; ITEM 106
2218	002276	060665	EM106
2219			
2220			
2221			
2222			
2223			
2224			
2225			
2226			

```

;RH CLEAR WAS GIVEN AN
;IPCK BIT SHOWN IN "IPCK" WAS SET
;ZEROS WERE MOVED INTO RHDB
;ON READING RHDB
;THE FOLLOWING REGISTER
;DID NOT CONTAIN WHAT
;IS IN GOOD
;PC TEST NO, IPCK, RHCS3 GOOD, RHCS3 BAD
;$ERRPC, TSTNM, IP, $GDDAT, $BDDAT
;0,0,0,0,0

```

```

;PC TST NO, IPCK, RHCS2 GOOD, RHCS2 BAD
;$ERRPC, TSTNM, IP, $GDDAT, $BDDAT
;0,0,0,0,0

```

```

;RH CLEAR WAS GIVEN AN
;IPCK BIT SHOWN IN "IPCK" WAS SET
;ZEROS WERE MOVED INTO
;RHDB FROM AN ODD WORD
;RHDB WAS READ
;AN RH CLEAR WAS GIVEN
;TO CLEAR ALL ERRORS
;THE FOLLOWING REGISTER
;DID NOT CONTAIN WHAT

```


2227					: IS IN GOOD
2228	002300	066061		DH106	: PC, TSTNM, IPCK, RHCS1 GOOD, RHCS1 BAD
2229	002302	066666		DT106	: \$ERRPC, TSTNM, IP, \$GDDAT, \$BDDAT
2230	002304	067002		DF106	: 0, 0, 0, 0, 0
2231					
2232				: ITEM 107	
2233	002306	060665		EM106	
2234	002310	066011		DH105	: PC, TSTNM, IPCK, RHCS2 GOOD, RHCS2 BAD
2235	002312	066652		DT105	
2236	002314	066775		DF105	
2237					
2238				: ITEM 110	
2239	002316	060665		EM106	
2240	002320	065741		DH104	
2241	002322	066636		DT104	
2242	002324	066770		DF104	
2243					
2244				: ITEM 111	
2245	002326	060665		EM106	
2246	002330	066131		DH111	: PC, TSTNM, IPCK, RHBA GOOD, RHBA BAD
2247	002332	066636		DT104	: \$ERRPC, TSTNM, IP, \$GDDAT, \$BDDAT
2248	002334	066770		DF104	: 0, 0, 0, 0, 0
2249					
2250				: ITEM 112	
2251	002336	060665		EM106	
2252	002340	066177		DH112	: PC, TSTNM, IPCK, RHBAE GOOD, RHBAE BAD
2253	002342	066636		DT104	: \$ERRPC, TSTNM, IP, \$GDDAT, \$BDDAT
2254	002344	066770		DF104	: 0, 0, 0, 0, 0
2255					
2256				: ITEM 113	
2257	002346	060665		EM106	
2258	002350	066247		DH113	: PC, TSTNM, IPCK, RHWC GOOD, RHWC BAD
2259	002352	066636		DT104	: \$ERRPC, TSTNM, IP, \$GDDAT, \$BDDAT
2260	002354	066770		DF104	: 0, 0, 0, 0, 0
2261					
2262				: ITEM 114	
2263	002356	061156		EM114	: RH CLEAR WAS GIVEN AN
2264					: A WRITE CHECK WAS DONE
2265					: THE FOLLOWING REGISTER
2266					: DID NOT CONTAIN WHAT IS
2267					: IN "GOOD"
2268	002360	065216		DH6	
2269	002362	066610		DT6	
2270	002364	066757		DF6	
2271					
2272				: ITEM 115	
2273	002366	061156		EM114	: RH CLEAR WAS GIVEN AN
2274					: A WRITE CHECK WAS DONE
2275					: THE FOLLOWING REGISTER
2276					: DID NOT CONTAIN WHAT IS
2277					: IN "GOOD"
2278	002370	065363		DH12	
2279	002372	066610		DT6	
2280	002374	066757		DF6	
2281					
2282				: ITEM 116	

2283	002376	061325	EM116
2284			
2285			
2286			
2287			
2288			
2289	002400	065321	DH11
2290	002402	066610	DT6
2291	002404	066757	DF6
2292			
2293			; ITEM 117
2294	002406	061325	EM116
2295	002410	065216	DH6
2296	002412	066610	DT6
2297	002414	066757	DF6
2298			
2299			; ITEM 120
2300	002416	061325	EM116
2301	002420	065363	DH12
2302	002422	066610	DT6
2303	002424	066757	DF6
2304			
2305			; ITEM 121
2306	002426	061325	EM116
2307	002430	065425	DH13
2308	002432	066610	DT6
2309	002434	066757	DF6
2310			
2311			; ITEM 122
2312	002436	061325	EM116
2313	002440	065465	DH14
2314	002442	066610	DT6
2315	002444	066757	DF6
2316			
2317			; ITEM 123
2318	002446	061325	EM116
2319	002450	065527	DH15
2320	002452	066610	DT6
2321	002454	066757	DF6
2322			
2323			; ITEM 124
2324	002456	061535	EM124
2325			
2326			
2327			
2328			
2329	002460	065363	DH12
2330	002462	066610	DT6
2331	002464	066757	DF6
2332			
2333			; ITEM 125
2334	002466	061535	EM124
2335	002470	065321	DH11
2336	002472	066610	DT6
2337	002474	066757	DF6
2338			

;RH CLEAR WAS GIVEN AN
;A WRITE CHECK WAS DONE
;THEN ANOTHER RH CLEAR WAS
;GIVEN TO CLEAR ALL ERRORS
;THE FOLLOWING REGISTER DID
;NOT CONTAIN WHAT IS IN "GOOD"

;ON A SILO TEST TO
;TEST DBL RHCS3-BIT #10
;THE FOLLOWING REGISTER
;DID NOT CONTAIN WHAT
;IS IN "GOOD"

2339			; ITEM 126	
2340	00276	061535	EM124	
2341	00280	065216	DH6	
2342	00282	066610	DT6	
2343	00254	066757	DF6	
2344				
2345			; ITEM 127	
2346	002506	061535	EM124	
2347	002510	065425	DH13	
2348	002512	066610	DT6	
2349	002514	066757	DF6	
2350				
2351			; ITEM 130	
2352	002516	061535	EM124	
2353	002520	065465	DH14	
2354	002522	066610	DT6	
2355	002524	066757	DF6	
2356				
2357			; ITEM 131	
2358	002526	061535	EM124	
2359	002530	065527	DH15	
2360	002532	066610	DT6	
2361	002534	066757	DF6	
2362			; ITEM 132	
2363	002536	061700	EM132	; BEFORE DATA TRANSFER ; COMMAND WAS TO BE GIVEN ; THE RP DRIVE ; STATUS REGISTER DID NOT ; CONTAIN WHAT IS IN GOOD
2364				
2365				
2366				
2367				
2368				
2369	002540	066315	DH132	; PC ; TEST NO. ; RHDS1 GOOD ; RHDS1 BAD
2370				
2371				
2372				
2373	002542	066610	DT6	
2374	002544	066757	DF6	
2375			; ITEM 133	
2376	002546	062056	EM133	; BEFORE DATA TRANSFER ; COMMAND WAS TO BE GIVEN ; THE RS DRIVE ; STATUS REGISTER DID NOT ; CONTAIN WHAT IS IN GOOD
2377				
2378				
2379				
2380				
2381				
2382	002550	066315	DH132	; PC ; TEST NO. ; RHDS1 GOOD ; RHDS1 BAD
2383				
2384				
2385				
2386	002552	066610	DT6	
2387	002554	066757	DF6	
2388			; ITEM 134	
2389	002556	062234	EM134	; BEFORE DATA TRANSFER COMMAND ; WAS TO BE GIVEN THE ; MAG TAPE DRIVE STATUS ; REGISTER DID NOT CONTAIN WHAT ; IS IN GOOD
2390				
2391				
2392				
2393				
2394				

2395	002560	066315		DH132	
2396	002562	066610		DT6	
2397	002564	066757		DF6	
2398			; ITEM135		
2399	002566	062424		EM135	: WAS WAITING FOR A BIT TO SET
2400					: BIT IN QUESTION IS IN "BIT WAITED FOR"
2401					: REGISTER IN QUESTION IN "REG ADDR"
2402	002570	066357		DH135	: PC
2403					: TEST NO
2404					: PC OF WAT
2405					: BIT
2406					: REG ADDR
2407	002572	066702		DT135	: \$ERRPC, TSTNM, WATIPC, WAITBT, WAITRE
2408	002574	067007		DF135	: 0,0,0,0,0
2409			; ITEM136		
2410	002576	062624		EM136	: WAS WAITING FOR A BIT TO RESET
2411					: BIT IN QUESTION IS IN "BIT WAITED FOR"
2412					: REGISTER IN QUESTION IN "REG ADDR"
2413	002600	066357		DH135	: PC
2414					: TEST NO
2415					: PC OF WAT
2416					: BIT
2417					: REG ADDR
2418	002602	066702		DT135	: \$ERRPC, TSTNM, WATIPC, WAITBT, WAITRE
2419	002604	067007		DF135	: 0,0,0,0,0
2420			; ITEM 137		
2421	002606	063026		EM137	: ON WRITING AND READING
2422					: THE REGISTER # IN "REG. ADDR"
2423					: IT DID NOT CONTAIN
2424					: EXPECTED VALUE.
2425	002610	066437		DH137	: PC
2426					: TEST NO
2427					: REG ADDR
2428					: GOOD DATA
2429					: BAD DATA
2430	002612	066716		DT137	: \$ERRPC, TSTNM, \$BDADR, \$GDDAT, \$BDDAT
2431	002614	067014		DF137	: 0,0,0,0,0
2432					
2433					
2434			; ITEM 140		
2435	002616	063154		EM140	
2436	002620	066061		DH106	
2437	002622	066666		DT106	
2438	002624	067002		DF106	
2439			; ITEM 141		
2440	002626	063406		EM141	: AFTER CLEARING THE RH AND
2441					: WRITING TWO WORD INTO
2442					: RHDB AND READING IT
2443					: BACK TWICE, CAUSED RHCS1 TO
2444					: HAVE WRONG DATA,
2445					: GIVEN IN BAD RHCS1
2446	002630	065321		DH11	: PC
2447					: TEST NUMBER
2448					: RHCS1 GOOD
2449					: RHCS1 BAD
2450	002632	066610		DT6	: \$ERRPC, TSTNM, \$GDDAT, \$BDDAT

2451	002634	066757	DF6	:0,0,0,0
2452				
2453				
2454				
2455	002636	063607	; ITEM 142 EM142	: AFTER CLEARING THE RH AND : WRITING TWO WORD INTO : RHDB AND READING IT : BACK TWICE, CAUSED RHCS3 TO : HAVE WRONG DATA : GIVEN IN BAD RHCS3 : PC : TEST NUMBER : RHCS3 GOOD : RHCS3 BAD : \$ERRPC, TSTNM, \$GDDAT, \$BDDAT : 0,0,0,0
2456				
2457				
2458				
2459				
2460				
2461	002640	065363	DH12	
2462				
2463				
2464				
2465	002642	066610	DT6	
2466	002644	066757	DF6	
2467				
2468				
2469				
2470	002646	064010	; ITEM 143 EM143	: AFTER CLEARING THE RH AND : WRITING TWO WORD INTO : RHDB AND READING IT : BACK TWICE, CAUSED RHBA TO : HAVE WRONG DATA : GIVEN IN BAD RHBA : PC : TEST NUMBER : RHBA GOOD : RHBA BAD : \$ERRPC, TSTNM, \$GDDAT, \$BDDAT : 0,0,0,0
2471				
2472				
2473				
2474				
2475				
2476	002650	065425	DH13	
2477				
2478				
2479				
2480	002652	066610	DT6	
2481	002654	066757	DF6	
2482				
2483				
2484				
2485	002656	064210	; ITEM 144 EM144	: AFTER CLEARING THE RH AND : WRITING TWO WORD INTO : RHDB AND READING IT : BACK TWICE, CAUSED RHBAE TO : HAVE WRONG DATA : GIVEN IN BAD RHBAE : PC : TEST NUMBER : RHBAE GOOD : RHBAE BAD : \$ERRPC, TSTNM, \$GDDAT, \$BDDAT : 0,0,0,0
2486				
2487				
2488				
2489				
2490				
2491	002660	065465	DH14	
2492				
2493				
2494				
2495	002662	066610	DT6	
2496	002664	066757	DF6	
2497				
2498				
2499				
2500	002666	064411	; ITEM 145 EM145	: AFTER CLEARING THE RH AND : WRITING TWO WORD INTO : RHDB AND READING IT : BACK TWICE, CAUSED RHWC TO : HAVE WRONG DATA : GIVEN IN BAD RHWC : PC
2501				
2502				
2503				
2504				
2505				
2506	002670	065527	DH15	

2507
2508
2509
2510
2511
2512
2513
2514
2515
2516
2517
2518
2519
2520
2521
2522
2523
2524
2525
2526
2527
2528
2529
2530

002672 066610
002674 066757

002676 064611

002700 066511

002702 066732
002704 067021

002706 065003

002710 066540

002712 066742
002714 067024

DT6
DF6
; ITEM146
EM146

DH146

DT146
DF146
; ITEM147
EM147

DH147

DT147
DF147

; TEST NUMBER
; RHC GOOD
; RHC BAD
; \$ERRPC, TSTNM, \$GDDAT, \$BDDAT
; 0,0,0,0

; A DEVICE BASE ADDRESS DID NOT
; TIME OUT BUT CORRESPONDING
; VECTOR ADDRESS DID TIME OUT
; PC
; BASE
; VECTOR
; \$ERRPC, TESTDV, TESTVC, 0
; 0,0,0

; A DEVICE ADDRESS DID NOT
; TIME OUT BUT NO UNITS HAD
; APPROPRIATE DRIVE TYPE
; PC
; BASE ADDRESS
; \$ERRPC, TESTDV

2531
2532
2533
2534
2535
2536
2537
2538
2539
2540
2541
2542
2543
2544
2545
2546
2547
2548
2549
2550
2551
2552
2553
2554
2555
2556
2557
2558
2559
2560
2561
2562
2563
2564
2565
2566
2567
2568
2569
2570
2571
2572
2573
2574
2575
2576
2577
2578
2579
2580
2581
2582
2583
2584
2585
2586

002716 000254

000001
000002
000004
000010
000020
000040
000100
000200
000400
000400
001000
002000
004000
010000
020000
040000
100000

;RH70 REGISTERS

RPVEC: 254 ;RP VECTOR ADDRESS

;WORD COUNT REGISTER (RHWC)
;EACH BIT IS CALLED BY BIT NUMBER

;BUS ADDRESS REGISTER (RHBA)
;EACH BIT IS CALLED BY BIT NUMBER

;CONTROL AND STATUS REGISTER 2 (RHCS2)

US1= 1 ;UNIT SELECT (BIT #0)
US2= 2 ;UNIT SELECT (BIT #1)
US4= 4 ;UNIT SELECT (BIT #2)
BAI= 10 ;BUS ADDRESS INCREMENT INHIBIT (BIT #3)
PAT= 20 ;INVERT PARITY
CLR= 40 ;CLEAR (BIT #5)
IR= 100 ;INPUT READY (BIT #6)
OR= 200 ;OUTPUT READY (BIT #7)
MPE= 400 ;MASS BUS PARITY ERROR (BIT #9)
MDPE= 400 ;MASS BUS PARITY ERROR (BIT #8)
MXF= 1000 ;MISSED TRANSFER ERROR (BIT #9)
PGE= 2000 ;PROGRAM ERROR (BIT #10)
NEM= 4000 ;NON EXISTANT MEMORY (BIT #11)
NED= 10000 ;NON EXISTANT DRIVE (BIT #12)
PE= 20000 ;UNIBUS PARITY ERROR (BIT #13)
WCE= 40000 ;WRITE CHECK ERROR (BIT #14)
DLT= 100000 ;DATA LATE (BIT #15)

;CONTROL AND STATUS REGISTER 3 (RHCS3)

IPCK0= 1 ;INVERT PARITY CHECK BIT 0
IPCK1= 2 ;INVERT PARITY CHECK BIT 1
IPCK2= 4 ;INVERT PARITY CHECK BIT 2
IPCK3= 10 ;INVERT PARITY CHECK BIT 3
IE= 100 ;INTERRUPT ENABLE (BIT #6)
DBL= 2000 ;DOUBLE WORD BOUNDARY (BIT #10)
WCEEW= 4000 ;WRITE CHECK EVEN WORD (BIT #11)
WCEOW= 10000 ;WRITE CHECK ODD WORD (BIT #12)
DPEEW= 20000 ;DATA PARITY ERROR EVEN WORD (BIT #13)
DPEOW= 40000 ;DATA PARITY ERROR ODD WORD (BIT #14)
APE= 100000 ;ADDRESS PARITY ERROR (BIT #15)

;DATA BUFFER REGISTER (RHDB)

2587
2588
2589
2590
2591
2592
2593
2594
2595
2596
2597
2598
2599
2600
2601
2602
2603
2604
2605
2606
2607
2608
2609
2610
2611
2612
2613
2614
2615
2616
2617
2618
2619
2620
2621
2622
2623
2624
2625
2626
2627
2628
2629
2630
2631
2632
2633
2634
2635
2636
2637
2638
2639
2640
2641
2642

000001
000100
000200
000400
001000
002000
004000
020000
040000
100000

000001
000002
000002
000004
000010
000020
000040
000100
000200
000400
001000
002000
004000
010000
020000
040000
100000

000001
000002
000004
000010
000020
000040
000100
000200
000400
001000
002000
004000
010000

;EACH BIT IS CALLED BY BIT NUMBER

;;*****
 ;RPO4 REGISTERS
 ;;*****

;CONTROL AND STATUS 1 REGISTER. (#00)

GO=	1	;GO (BIT #0)
IE=	100	;INTERRUPT ENABLE (BIT #6)
RDY=	200	;READY (BIT #7)
A16=	400	;HIGH ORDER UNIBUS BITS (BIT #8)
A17=	1000	;HIGH ORDER UNIBUS BITS (BIT #9)
PSEL=	2000	;PORT SELECT (BIT #10)
DVA=	4000	;DEVICE AVAILABLE (BIT #11)
MCPE=	20000	;MASSBUSS PARITY ERROR (BIT #13)
TRE=	40000	;TRANSFER ERROR (BIT #14)
SC=	100000	;SPECIAL CONDITION (BIT #15)

;STATUS REGISTER (RHDS1) (#01)

DFF5=	1	;DRIVE FORWARD 5"/SEC. (BIT #0)
BOT=	2	;BEGINING OF TAPE (BIT #1)
DFF20=	2	;DRIVE FORWARD 20"/SEC. (BIT #1)
DIGB=	4	;DRIVE TO INNER GAVRD BAND (BIT #2)
GRV=	10	;GO REVERSE (BIT #3)
DL64=	20	;DIFFERENCE LESS THAN 64 (BIT #4)
DE1=	40	;DIFFERENCE EQUALS 1 (BIT #5)
VV=	100	;VOLUME VALID (BIT #6)
DRY=	200	;DRIVE READY (BIT #7)
DPR=	400	;DRIVE PRESENT (BIT #8)
PROG=	1000	;PROGRAMABLE (BIT #9)
LBT=	2000	;LAST SECTOR TRANSFERRED (BIT #10)
WRL=	4000	;WRITE LOCK (BIT #11)
MOL=	10000	;MEDIUM ON-LINE (BIT #12)
PIP=	20000	;POSITIONING OPERATION IN PROGRESS (BIT #13)
ERR=	40000	;COMPOSIT ERROR. (BIT #14)
ATA=	100000	;ATTENTION ACTIVE (BIT #15)

;ERROR REGISTER #01 (RHER1) (#02)

ILF=	1	;ILLEGAL FUNCTION (BIT #0)
ILR=	2	;ILLEGAL REGISTER (BIT #1)
RMR=	4	;REGISTER MODIFICATION REFUSED (BIT #2)
PAR=	10	;PARITY ERROR (BIT #3)
FER=	20	;FORMAT ERROR (BIT #4)
WCF=	40	;WRITE CLOCK FAIL (BIT #5)
ECH=	100	;ECC HARD ERROR (BIT #6)
HCE=	200	;HEADER COMPARE ERROR (BIT #7)
HCRC=	400	;HEADER CRC ERROR (BIT #8)
AOE=	1000	;ADDRESS OVERFLOW ERROR (BIT #9)
IAE=	2000	;INVALID ADDRESS ERROR (BIT #10)
WLE=	4000	;WRITE LOCK ERROR (BIT #11)
DTE=	10000	;DRIVE TIMING ERROR (BIT #12)

2643	020000	OPI= 20000	; OPERATION INCOMPLETE (BIT #13)
2644	040000	UNS= 40000	; DRIVE UNSAFE (BIT #14)
2645	100000	DCK= 100000	; DATA CHECK ERROR (BIT 15)
2646			
2647		; MAINTAINABILITY REGISTER (RHMR) (#03)	
2648			
2649	000001	DMD= 1	; DIAGINOSTIC MODE (BIT #0)
2650	000002	MCLK= 2	; MAINTAINABILITY CLOCK (BIT #1)
2651	000004	MINX= 4	; MAINTAINABILITY INDEX (BIT #2)
2652	000010	MSTCK= 10	; MAINTAINABILITY SECTOR CLOCK (BIT #3)
2653	000020	MRD= 20	; MAINTAINABILITY READ (BIT #4)
2654	000040	MWR= 40	; MAINTAINABILITY WRITE (BIT #5)
2655	001000	DTSY= 1000	; MAINTAINABILITY SYNC DETECTED (BIT #9)
2656			
2657		; ATTENTION SUMMARY PSEUDO-REGISTER (RHAS) (#04)	
2658			
2659	000001	ATO= 1	; DEVICE 0 (BIT #0)
2660	000002	AT1= 2	; DEVICE 1 (BIT #1)
2661	000004	AT2= 4	; DEVICE 2 (BIT #2)
2662	000010	AT3= 10	; DEVICE 3 (BIT #3)
2663	000020	AT4= 20	; DEVICE 4 (BIT #4)
2664	000040	AT5= 40	; DEVICE 5 (BIT #5)
2665	000100	AT6= 100	; DEVICE 6 (BIT #6)
2666	000200	AT7= 200	; DEVICE 7 (BIT #7)
2667			
2668		; DESIRED SECTOR/TRACK ADDRESS REGISTER (RHDST) (#1)	
2669		; EACH BIT IS CALLED BY BIT NUMBER	
2670		; DRIVE TYPE REGISTER (RHDT) (#06)	
2671		; EACH BIT IS CALLED BY BIT NUMBER	
2672		; LOOK-AHEAD REGISTER (RHLA) (#07)	
2673			
2674	000001	EXT1= 1	; EXTENSION 1 (BIT #0)
2675	000002	EXT2= 2	; EXTENSION 2 (BIT #1)
2676	000004	EXT4= 4	; EXTENSION 3 (BIT #2)
2677	000010	EXT10= 10	; EXTENSION 4 (BIT #3)
2678	000020	EXT20= 20	; EXTENSION 5 (BIT #4)
2679	000040	EXT40= 40	; EXTENSION 6 (BIT #5)
2680	000100	SC1= 100	; SECTOR COUNT FIELD 0 (BIT #6)
2681	000200	SC2= 200	; SECTOR COUNT FIELD 1 (BIT #7)
2682	000400	SC4= 400	; SECTOR COUNT FIELD 2 (BIT #8)
2683	001000	SC10= 1000	; SECTOR COUNT FIELD 3 (BIT #9)
2684	002000	SC20= 2000	; SECTOR COUNT FIELD 4 (BIT #10)
2685	004000	TRK1= 4000	; TRACK FIELD 1 (BIT #11)
2686	010000	TRK2= 10000	; TRACK FIELD 2 (BIT #12)
2687	020000	TRK4= 20000	; TRACK FIELD 3 (BIT #13)
2688	040000	TRK10= 40000	; TRACK FIELD 4 (BIT #14)
2689	100000	TRK20= 100000	; TRACK FIELD 5 (BIT #15)
2690			
2691		; ERROR REGISTER #2 (RHER2) (#10)	
2692			
2693	000001	WCU= 1	; WRITE CURRENT UNSAFE (BIT #0)
2694	000002	CSF= 2	; CURRENT SINK FAILURE (BIT #1)
2695	000004	WSU= 4	; WRITE SELECT UNSAFE (BIT #2)
2696	000010	CSU= 10	; CURRENT SWITCH UNSAFE (BIT #3)
2697	000020	MSE= 20	; MOTOR SEQUENCE ERROR (BIT #4)
2698	000040	TDF= 40	; TRANSITIONS DETECTOR FAILURE (BIT #5)

2699	000100	TUF=	100	; TRANSITIONS UNSAFE (BIT #6)
2700	000200	FEN=	200	; FAILSAFE ENABLED (BIT #7)
2701	000400	WRU=	400	; WRITE READY UNSAFE (BIT #8)
2702	001000	MHS=	1000	; MULTIPLE HEAD SELECT (BIT #9)
2703	002000	NHS=	2000	; NO HEAD SELECTION (BIT #10)
2704	004000	IXE=	4000	; INDEX ERROR (BIT #11)
2705	010000	VU30=	10000	; 30VOLT UNSAFE (BIT #12)
2706	020000	PLU=	20000	; PLO UNSAFE (BIT #13)
2707	100000	ACU=	100000	; ACUNSAFE (BIT #15)
2708				
2709		; OFFSET REGISTER (RHOF) (#11)		
2710				
2711	000001	OF25=	1	; OFFSET 25 MICRO INCHES (BIT #0)
2712	000002	OF50=	2	; OFFSET 50 MICRO INCHES (BIT #1)
2713	000004	OF100=	4	; OFFSET 100 MICRO INCHES (BIT #2)
2714	000010	OF200=	10	; OFFSET 200 MICRO INCHES (BIT #3)
2715	000020	OF400=	20	; OFFSET 400 MICRO INCHES (BIT #4)
2716	000040	OF800=	40	; OFFSET 800 MICRO INCHES (BIT #5)
2717				
2718	000200	OFREV=	200	; OFFSET NEGATIVE (REVERSE) (BIT #5)
2719	002000	HCI=	2000	; HEADER COMPARE INHIBIT (BIT #10)
2720	004000	ECI=	4000	; ERROR CORRECTION CODE INHIBIT (BIT #11)
2721	010000	FMT22=	10000	; FORMAT BIT (BIT #12)
2722				
2723		; TAPE CONTROL REGISTER (RHTC)		
2724				
2725	000001	S1=	1	; SLAVE NUMBER
2726	000002	S2=	2	; SLAVE NUMBER
2727	000004	S4=	4	; SLAVE NUMBER
2728	000010	EPAR=	10	; EVEN PARITY
2729	000020	FMT1=	20	; FORMAT
2730	000040	FMT2=	40	; FORMAT
2731	000100	FMT4=	100	; FORMAT
2732	000200	FMT8=	200	; FORMAT
2733	000400	DEN1=	400	; DENSITY
2734	001000	DEN2=	1000	; DENSITY
2735	002000	DEN4=	2000	; DENSITY
2736	001400	BPI8=	1400	; 800 BPI
2737	000300	NML=	300	; NORMAL - 2 FRAMES PER WORD
2738				
2739				
2740				
2741				
2742				
2743		; DRIVE TYPE REGISTER		
2744				
2745	002000	SLVPR=	2000	; SLAVE PRESENT (BIT #10)
2746	010000	CH7=	10000	; CHANNEL 7 (BIT #12)
2747				
2748		; DESIRED CYLINDER ADDRESS (RHCA) (#12)		
2749		; EACH BIT IS CALLED BY BIT NUMBER.		
2750				
2751				
2752				
2753				
2754		; CURRENT CYLINDER ADDRESS (RHCC) (#13)		

2755
2756
2757
2758
2759
2760
2761
2762
2763
2764
2765
2766
2767
2768
2769
2770
2771
2772
2773
2774
2775
2776
2777
2778
2779
2780
2781
2782
2783
2784
2785
2786
2787
2788
2789
2790
2791
2792

000001
000002
000010
000020
000040
000100
040000
100000

;EACH BIT IS CALLED BY BIT NUMBER

;SERIAL NUMBER REGISTER (RHSN) (#14)
;EACH IS CALLED BY BIT NUMBER

;ERROR REGISTER #03 (RHER3) (#15)

PSU=	1	;PACK SPEED UNSAFE (BIT #0)
VUF=	2	;VELOCITY UNSAFE (BIT #1)
UWR=	10	;ANY UNSAFE EXCEPT READ/WRITE (BIT #3)
PRE=	20	;DISK PACK ROTATION ERROR (BIT #4)
ACL=	40	;AC LOW (BIT #5)
DCL=	100	;DC LOW (BIT #6)
SKI=	40000	;SEEK INCOMPLETE (BIT #14)
OCYL=	100000	;OFF CYLINDER (BIT #15)

;ECC POSITION REGISTER (RHEC1) (#16)
;EACH BIT IS CALLED BY BIT NUMBER

;ECC PATTERN REGISTER (RHEC2) (#17)
;EACH BIT IS CALLED BY BIT NUMBER

::*****

2793
2794
2795
2796
2797
2798
2799
2800
2801
2802
2803
2804
2805
2806
2807
2808
2809
2810
2811
2812
2813
2814
2815
2816
2817
2818
2819
2820
2821
2822
2823
2824
2825
2826
2827
2828
2829
2830
2831
2832
2833
2834
2835
2836

000000
000002
000004
000006
000006
000010
000012
000014
000016
000020
000022
000024
000026
000030
000032
000032
000034
000036
000040
000042
000044
000046

003000
003000
003002
000422

004046 172040
004050 176700
004052 172440
004054 176300
004056 000000

CS1= 0
WC= 2
BA= 4
FC= 6
DA= 6
CS2= 10
DS= 12
ER1= 14
AS= 16
LA= 20
DB= 22
MR= 24
DT= 26
SN= 30
OF= 32
TC= 32
DC= 34
CC= 36
ER2= 40
ER3= 42
EC1= 44
EC2= 46

;BUFFERS
.=3000
BUFEW:
BFEVEN: 0
BUFOW:
BFODD: .BLKW 274
;STARTING ADDRESS OF REGISTERS

RSCS1: 172040
RPCS1: 176700
TMCS1: 172440
MIXCS1: 176300
PRESENT: 0

;CONTROL STATUS 1
;WORD COUNT
;BUS ADDRESS
;FRAME COUNT
;DESIRED SECTOR/TRACK
;CONTROL STATUS 2
;DRIVE STATUS
;ERROR 1
;ATTENTION SUMMERY
;LOOK AHEAD
;DATA BUFFER
;MAINTENANCE REGISTER
;DRIVE TYPE
;SERIAL NUMBER
;OFFSET
;TAPE CONTROL
;DESIRED CYLINDER
;CURRENT CYLINDER
;ERROR 2
;ERROR 3
;ECC 1
;ECC 2

;BUFFER

;RS ALONG
;RP ALONE
;TM ALONE
;MIXED SYSTEM

.SBTTL REGISTER ADDRESSES

```

2837
2838
2839
2840
2841
2842
2843
2844
2845
2846
2847
2848
2849
2850
2851
2852
2853 004060 000000
2854 004062 000000
2855 004064 000000
2856 004066
2857 004066
2858 004066 000000
2859 004070 000000
2860 004072 000000
2861 004074 000000
2862 004076 000000
2863 004100
2864 004100 000000
2865 004102 000000
2866 004104 000000
2867 004106 000000
2868 004110 000000
2869 004112
2870 004112 000000
2871 004114 000000
2872 004116 000000
2873 004120 000000
2874 004122 000000
2875 004124 000000
2876 004126 000000
2877 004130 000000
2878 004132 000000
2879
2880
2881
2882
2883
2884
2885
2886
2887 004134
2888 004134 000000
2889 004136 000002
2890 004140 000006
2891 004142 000010
2892 004144 000012

```

```

;THE FOLLOWING ARE THE I/O REGISTERS FOR THE DEVICE UNDER TEST
;THEY WILL BE FILLED WITH ADDRESSES DEPENDING ON WHAT DEVICE IS ON
;THE SYSTEM.
;IN THE CASE OF A MIXED SYSTEM THAT IS WITH MORE THAN ONE RH DEVICE
;THE FIRST ONE THAT EXISTS IN THE FOLLOWING LIST WILL BE PICKED
;AND THE OTHERS WILL NOT BE USED.

```

- ```

;LIST:-
;1) RS03
;2) RS04
;3) RPO4,5,6
;4) TMO2

```

```

;THE CONTENTS OF RHCS1 WHICH IS THE BASE ADDRESS IS
;172040 FOR RS03/04
;176700 FOR RPO4,5,6
;172440 FOR TMO2

```

```

;THE REST OF THE LOCATIONS WILL BE FILLED BY THE PROGRAM
RHCS1: 0 ;CONTROL AND STATUS 1
RHWC: 0 ;WORD COUNT
RHBA: 0 ;BUS ADDRESS
RHFC: 0 ;FRAME COUNT
RHDA: 0 ;DISK ADDRESS
RHDST: 0 ;DESIRED SECTOR/TRACK ADDRESS
RHCS2: 0 ;CONTROL AND STATUS 2
RHDS1: 0 ;DRIVE STATUS
RHER1: 0 ;ERROR #1
RHAS: 0 ;ATTENTION SUMMARY
RHCC: 0 ;CHECK CHARACTER
RHLA: 0 ;LOOK-AHEAD
RHDB: 0 ;DATA BUFFER
RHMR: 0 ;MAINTAINABILITY
RHDT: 0 ;DRIVE TYPE
RHSN: 0 ;SERIAL NUMBER
RHTC: 0 ;TAPE CONTROL
RHOF: 0 ;OFFSET
RHCA: 0 ;DESIRED CYLINDER ADDRESS
RHCCA: 0 ;CURRENT CYLINDER ADDRESS
RHER2: 0 ;ERROR #2
RHER3: 0 ;ERROR #3
RHEC1: 0 ;ECC POSITION
RHEC2: 0 ;ECC PATTERN
RHBAE: 0 ;BUS ADDRESS EXTENSION
RHCS3: 0 ;CONTROL AND STATUS 3

```

;FUNCTION EQUATES

```

;TABLE OF FUNCTIONS FOR RHCS1 THEN "GO" BIT HAS TO BE SET
FUTABL:
NOPERA: 0 ;NO OPERATION
UNLOAD: 2 ;UNLOAD (STAND BY)
RECALI: 6 ;RECALIBRATE
DCLEAR: 10 ;DRIVE CLEAR
RELEAS: 12 ;RELEASE (DUAL-PORT OPERATION)

```

|      |        |        |         |           |                                                    |                                      |
|------|--------|--------|---------|-----------|----------------------------------------------------|--------------------------------------|
| 2893 | 004146 | 000030 | SERCH:  | 30        | ; SEARCH COMMAND                                   |                                      |
| 2894 | 004150 | 000050 | WRCHK:  | 50        | ; WRITE CHECK DATA                                 |                                      |
| 2895 | 004152 | 000052 | WRCHDT: | 52        | ; WRITE CHECK HEADER AND DATA                      |                                      |
| 2896 | 004154 | 000060 | WRIDAT: | 60        | ; WRITE DATA                                       |                                      |
| 2897 | 004156 | 000062 | WRIFOR: | 62        | ; WRITE HEADER AND DATA (FORMAT)                   |                                      |
| 2898 | 004160 | 000070 | READAT: | 70        | ; READ DATA                                        |                                      |
| 2899 | 004162 | 000072 | REFOR:  | 72        | ; READ HEADER AND DATA                             |                                      |
| 2900 | 004164 | 000004 | SEECOM: | 4         | ; SEEK COMMAND                                     |                                      |
| 2901 | 004166 | 000014 | OFSETC: | 14        | ; OFFSET COMMAND                                   |                                      |
| 2902 | 004170 | 000016 | RETCL:  | 16        | ; RETURN TO CENTERLINE                             |                                      |
| 2903 | 004172 | 000022 | PKACK:  | 22        | ; PACK ACKNOWLEDGE                                 |                                      |
| 2904 | 004174 | 000020 | READIN: | 20        | ; READ IN                                          |                                      |
| 2905 | 004176 | 000006 | REWIND: | 6         | ; REWIND                                           |                                      |
| 2906 | 004200 | 000076 | REVRED: | 76        | ; REVERSE READ                                     |                                      |
| 2907 | 004202 | 000030 | SPACFD: | 30        | ; SPACE FORWARD                                    |                                      |
| 2908 | 004204 | 000066 | REVRT:  | 66        | ; REVERSE WRITE                                    |                                      |
| 2909 | 004206 | 000000 | ILLEGL: | .WORD 0   | ; COMPUTED ILLEGAL FUNCTION                        |                                      |
| 2910 |        |        |         |           |                                                    |                                      |
| 2911 |        |        |         |           | ; DATA BUFFER FOR READ WRITE                       |                                      |
| 2912 | 004210 | 000106 | WRFROM: | .BLKW 70. | ; WRITE FROM THIS BUFFER                           |                                      |
| 2913 | 004424 | 000106 | REINTO: | .BLKW 70. | ; READ INTO THIS BUFFER                            |                                      |
| 2914 | 004640 | 000000 | COMND:  | 0         | ; STORE COMMAND FOR COMMAND ROUTINE                |                                      |
| 2915 | 004642 | 000000 | COMAND: | 0         | ; STORE COMMACD                                    |                                      |
| 2916 | 004644 | 000000 | NOGO:   | 0         | ; IF ZERO GO IS TO BE GIVEN IN COMMAND ROUTINE     |                                      |
| 2917 |        |        |         |           | ; IF ONES GO IS NOT TO BE GIVEN IN COMMAND ROUTINE |                                      |
| 2918 |        |        |         |           | ; USED IN PGE TEST                                 |                                      |
| 2919 | 004646 | 000000 | WATO:   | 0         | ; IF ZERO WAIT FOR BIT TO SET                      |                                      |
| 2920 |        |        |         |           | ; IF ONES WAIT FOR BIT TO RESET                    |                                      |
| 2921 |        |        |         |           | ; USED IN WAIT TRAP                                |                                      |
| 2922 | 004650 | 000000 | WRBIT:  | 0         | ; BITS NOT WRITTEN INTO                            |                                      |
| 2923 | 004652 | 000000 | SETBIT: | 0         | ; BITS ALWAYS SET                                  |                                      |
| 2924 | 004654 | 000000 | CLRBIT: | 0         | ; BITS ALWAYS CLEARED                              |                                      |
| 2925 |        |        |         |           |                                                    |                                      |
| 2926 |        |        |         |           |                                                    |                                      |
| 2927 |        |        |         |           |                                                    |                                      |
| 2928 |        |        |         |           | ; RESERVED LOCATIONS                               |                                      |
| 2929 | 004656 | 000000 | TSTNM:  | 0         | ; TEST NUMBER                                      |                                      |
| 2930 | 004660 | 000000 | SLAVE:  | 0         | ; KEEP SLAVE NO.                                   |                                      |
| 2931 | 004662 | 000000 | IP:     | 0         | ; IPCK NUMBER FOR ERROR PRINTOUT                   |                                      |
| 2932 | 004664 | 000000 | SILONM: | 0         | ; SILO WORD NUMBER FOR ERROR PRINT OUT             |                                      |
| 2933 | 004666 | 000000 | WAITPC: | 0         | ; WAIT TRAP PC                                     |                                      |
| 2934 | 004670 | 000000 | WAITRE: | 0         | ; WAITING FOR REGISTER ADDRESS IN WAIT TRAP        |                                      |
| 2935 | 004672 | 000000 | WAITBT: | 0         | ; WAITING FOR BIT IN WAIT TRAP                     |                                      |
| 2936 |        |        |         |           |                                                    |                                      |
| 2937 |        |        |         |           |                                                    |                                      |
| 2938 |        |        |         |           | ; TABLE FOR ATTENTION BITS                         |                                      |
| 2939 | 004674 | 001    |         | 002       | 004                                                | ; ATTENTION TABLE                    |
| 2940 | 004677 | 010    |         | 020       | 040                                                | ATABLE: .BYTE 1,2,4,10,20,40,100,200 |
| 2941 | 004702 | 100    |         | 200       |                                                    |                                      |
| 2942 |        |        |         |           |                                                    |                                      |
| 2943 |        |        |         |           |                                                    |                                      |
| 2944 |        |        |         |           |                                                    |                                      |
| 2945 |        |        |         |           |                                                    | ; RESERVED LOCATIONS FOR UNIT SELECT |
| 2946 | 004704 | 172040 | BASEAD: | 172040    |                                                    | ; RS BASE ADDRESS                    |
| 2947 | 004706 | 176700 | BASPAD: | 176700    |                                                    | ; RP BASE ADDRESS                    |
| 2948 | 004710 | 172440 | BASTAD: | 172440    |                                                    | ; TU BASE ADDRESS                    |

|      |        |        |                                  |          |                                                     |
|------|--------|--------|----------------------------------|----------|-----------------------------------------------------|
| 2949 | 004712 | 176300 | BASEMAD:                         | 176300   | ; MIXED SYSTEM BASE ADDRESS                         |
| 2950 |        |        |                                  |          |                                                     |
| 2951 |        |        |                                  |          |                                                     |
| 2952 | 004714 | 000000 | BASEVC:                          | 0        | ; RS VECTOR                                         |
| 2953 | 004716 | 000254 | BASP:                            | 254      | ; RP VECTOR                                         |
| 2954 | 004720 | 000001 | BAST:                            | 1        | ; TU VECTOR                                         |
| 2955 | 004722 | 000002 | BASM:                            | 2        | ; MIXED VECTOR                                      |
| 2956 |        |        |                                  |          |                                                     |
| 2957 |        |        |                                  |          |                                                     |
| 2958 | 004724 | 000010 | ; TABLE FOR GIVEN BASE ADDRESSES |          |                                                     |
| 2959 |        |        | BSGIVA:                          | .BLKW 8. |                                                     |
| 2960 |        |        |                                  |          |                                                     |
| 2961 |        |        | ; TABLE FOR GIVEN VECTOR         |          |                                                     |
| 2962 | 004744 | 000010 | BSGIVV:                          | .BLKW 8. |                                                     |
| 2963 |        |        |                                  |          |                                                     |
| 2964 |        |        |                                  |          |                                                     |
| 2965 | 004764 | 000004 | NMRHS:                           | 4        | ; NUMBER OF RH                                      |
| 2966 | 004766 | 000000 | BASINX:                          | 0        | ; INDEX FOR BASE                                    |
| 2967 | 004770 | 000000 | WORKBS:                          | 0        | ; WORKING BASE                                      |
| 2968 | 004772 | 000000 | WORKNM:                          | 0        | ; WORKING NUMBER FOR RH                             |
| 2969 | 004774 | 000000 | WORKVC:                          | 0        | ; WORKING VECTOR FOR RH                             |
| 2970 | 004776 | 000000 | FORBAE:                          | 0        | ; TOTAL NO. OF REG. FOR BAE CALCULATION             |
| 2971 | 005000 | 000000 | LOPCT:                           | 0        | ; LOOP COUNT FOR 200 START                          |
| 2972 | 005002 | 000000 | LOPCT1:                          | 0        | ; LOOP COUNT FOR 210 START                          |
| 2973 | 005004 | 000000 | USEVEC:                          | 0        | ; USE VECTOR                                        |
| 2974 |        |        |                                  |          |                                                     |
| 2975 |        |        |                                  |          |                                                     |
| 2976 |        |        |                                  |          |                                                     |
| 2977 | 005006 | 000000 | GIVE:                            | 0        | ; IF ONES OPERATOR WILL GIVE ADDRESSES              |
| 2978 | 005010 | 000000 | UNIT:                            | 0        | ; UNIT UNDER TEST                                   |
| 2979 | 005012 | 000000 | ST200:                           | 0        | ; ALL ONES INDICATE STARTING FROM 200               |
| 2980 |        |        | ; TESTING TABLE                  |          |                                                     |
| 2981 | 005014 | 000010 | TSRHNO:                          | .BLKW 8. | ; RH NO TO BE TESTED IN ORDER OF TEST               |
| 2982 |        |        |                                  |          |                                                     |
| 2983 | 005034 | 000010 | TSDEVICE:                        | .BLKW 8. | ; DEVICE TO BE TESTED IN ORDER OF TEST              |
| 2984 |        |        |                                  |          | ; 1=RS03,3/L,3/LA 2=RS04,4/L 4=RPO4,5,6 SINGLE PORT |
| 2985 |        |        |                                  |          | ; 10=RPO4,5,6 DUAL PORT 20=TM02                     |
| 2986 |        |        |                                  |          |                                                     |
| 2987 |        |        |                                  |          |                                                     |
| 2988 | 005054 | 000010 | TSUNIT:                          | .BLKW 8. | ; UNIT NO. TO BE TESTED IN ORDER OF TEST            |
| 2989 |        |        |                                  |          |                                                     |
| 2990 |        |        |                                  |          |                                                     |
| 2991 | 005074 | 000010 | TSSLAV:                          | .BLKW 8. | ; SLAVE NO TO BE TESTED IN ORDER OF TEST            |
| 2992 |        |        |                                  |          |                                                     |
| 2993 |        |        |                                  |          |                                                     |
| 2994 | 005114 | 000000 | TSTOTL:                          | 0        | ; TOTAL NO. OF UNITS TO BE TESTED                   |
| 2995 | 005116 | 000000 | TSINDX:                          | 0        | ; INDEX TO ONE UNDER TEST                           |
| 2996 |        |        |                                  |          |                                                     |
| 2997 |        |        |                                  |          |                                                     |
| 2998 | 005120 | 000010 | TSVEC:                           | .BLKW 8. | ; VECTOR ADDRESS IN ORDER OF TEST                   |
| 2999 |        |        |                                  |          |                                                     |
| 3000 |        |        |                                  |          |                                                     |
| 3001 | 005140 | 000010 | TSBAE:                           | .BLKW 8. | ; RHBAE ADDRESS IN ORDER OF TEST                    |
| 3002 |        |        |                                  |          |                                                     |
| 3003 |        |        |                                  |          |                                                     |
| 3004 | 005160 | 000010 | TSCS3:                           | .BLKW 8. | ; RHCS3 ADDRESS IN ORDER OF TEST                    |

```

3005
3006
3007 005200 000010 TSCOMD: .BLKW 8. ;COMMAND ADDRESS IN ORDER OF TEST
3008
3009
3010 005220 000010 TSBASE: .BLKW 8. ;BASE ADDRESS IN ORDER OF TEST
3011
3012
3013
3014
3015
3016
3017 005240 000000 ERFLGS: 0 ;ERROR FLAG
3018 005242 000000 FIRST: 0 ;IF ZERO WILL TYPE HEADER
3019 ;IF ONES WILL NOT TYPE HEADER
3020
3021
3022
3023 005244 000000 ATTENT: 0 ;ATTENTION BIT FOR PRESENT UNIT
3024 005246 000000 TOTALAT: 0 ;TATAL ATTENTION BITS
3025
3026 005250 000000 TMP0: .WORD 0 ;TEMP STORAGE
3027 005252 000000 TMP1: .WORD 0 ;TEMP STORAGE
3028 005254 000000 TMP4: .WORD 0 ;TEMP STORAGE
3029 ;PERMANENT TABLE
3030 005256 172040 PERRS: 172040 ;RS BASE ADDRESS
3031 005260 176700 PERRP: 176700 ;RP BASE ADDRESS
3032 005262 172440 PERTU: 172440 ;TU BASE ADDRESS
3033 005264 176300 PERMX: 176300 ;MIXED BASE ADDRESS
3034
3035 005266 000204 PERRSV: 204 ;RS VECTOR ADDRESS
3036 005270 000254 PERRPV: 254 ;RP VECTOR ADDRESS
3037 005272 000224 PERTUV: 224 ;TU VECTOR ADDRESS
3038 005274 000000 PERMXV: 0 ;MIXED VECTOR ADDRESS
3039
3040 005276 000004 PERNUM: 4 ;NUMBER OF RH
3041
3042 ;WORKING TABLE
3043
3044 005300 000004 DEVPNT: .BLKW 4 ;BASE ADDRESS TO BE TESTED
3045 005310 000004 VECPNT: .BLKW 4 ;VECTOR ADDRESS TO BE TESTED
3046 005320 000000 LTRY: 0 ;NO. OF UNITS TO BE TESTED
3047 005322 000000 TFOUND: 0 ;TWICE NUMBER OF RH FOUND
3048 005324 000000 TESTDV: 0 ;STORES BASE ADDRESS OF TEST DEVICE
3049 005326 000000 TESTVC: 0 ;STORES VECTOR OF TEST DEVICE
3050 ;THE ABOVE TWO IS BEFORE ANY
3051 ;DEVICE IS FOUND.
3052 ;TABLE FOR DRIVE TYPES
3053 ;0=RS03, 1=RS03/L, 2=RS04, 3=RS04/L, 4=RS03/LA
3054 ;20020=SINGLE PORT RPO4, 24020=DUAL PORT RPO4
3055 ;20021=SINGLE PORT RPO5, 24021=DUAL PORT RPO5
3056 ;20022=SINGLE PORT RPO6, 24022=DUAL PORT RPO6
3057 ;142010=TU16
3058
3059 005330 000000 000001 000002 TYPNT: .WORD 0,1,2,3,4,20020,24020,20021,24021,20022,24022,142010
3060 005336 000003 000004 020020

```



|      |        |        |        |        |                 |                                                                                                    |
|------|--------|--------|--------|--------|-----------------|----------------------------------------------------------------------------------------------------|
| 3061 | 005344 | 024020 | 020021 | 024021 |                 |                                                                                                    |
| 3062 | 005352 | 020022 | 024022 | 142010 |                 |                                                                                                    |
| 3063 | 005360 | 000000 |        |        | POINTT: 0       | ;POITER TO ABOVE TABLE                                                                             |
| 3064 | 005362 | 000014 |        |        | NTYPNT: 14      | ;NUMBER OF ABOVE TYPES                                                                             |
| 3065 |        |        |        |        |                 |                                                                                                    |
| 3066 | 005364 | 000000 |        |        | TMPSLV: 0       | ;TEMPORARY SLAVE COUNTER                                                                           |
| 3067 |        |        |        |        |                 |                                                                                                    |
| 3068 |        |        |        |        |                 |                                                                                                    |
| 3069 | 005366 | 000004 |        |        | FDEVIC: .BLKW 4 | ;TABLE OF DATA FOR DEVICES FOUND<br>;DEVICE FOUND, 1=TU, 2=RP DUAL<br>;3=RP SINGLE, 4=RS04, 5=RS03 |
| 3070 |        |        |        |        |                 |                                                                                                    |
| 3071 | 005376 | 000004 |        |        | FUNITN: .BLKW 4 | ;UNIT NUMBER FOUND                                                                                 |
| 3072 | 005406 | 000004 |        |        | FTYPE: .BLKW 4  | ;DDRIVE TYPE FOUND                                                                                 |
| 3073 | 005416 | 000004 |        |        | FVECTR: .BLKW 4 | ;VECTOR FOUND                                                                                      |
| 3074 | 005426 | 000004 |        |        | FBASEA: .BLKW 4 | ;BASE ADDRESS FOUND                                                                                |
| 3075 | 005436 | 000004 |        |        | FRHNM: .BLKW 4  | ;RH NUMBER FOUND                                                                                   |
| 3076 | 005446 | 000004 |        |        | FSLAVE: .BLKW 4 | ;TU16 SLAVE NUMBER FOUND                                                                           |
| 3077 | 005456 | 000004 |        |        | FDRIVR: .BLKW 4 | ;DRIVER ADDRESS FOUND                                                                              |
| 3078 | 005466 | 000004 |        |        | FBAE: .BLKW 4   | ;BAE ADDRESS FOUND                                                                                 |
| 3079 | 005476 | 000004 |        |        | FCS3: .BLKW 4   | ;CS3 ADDRESS FOUND                                                                                 |
| 3080 |        |        |        |        |                 |                                                                                                    |
| 3081 | 005506 | 000000 |        |        | TSTUNT: 0       | ;TOTAL NUMBER OF RH FOUND AT<br>;END OF SIZE                                                       |
| 3082 |        |        |        |        |                 |                                                                                                    |
| 3083 | 005510 | 000000 |        |        | WORUNT: 0       | ;SAME AS ABOVE BUT TO BE<br>;DECREASED AT END PROGRAM                                              |
| 3084 |        |        |        |        |                 |                                                                                                    |
| 3085 |        |        |        |        |                 |                                                                                                    |
| 3086 | 005512 | 000000 |        |        | VECTOR: 0       | ;VECTOR UNDER TEST                                                                                 |
| 3087 | 005514 | 177740 |        |        | LERADD: 177740  | ;LOW ERROR ADDRESS REG.                                                                            |
| 3088 | 005516 | 177742 |        |        | HERADD: 177742  | ;HIGH ERROR ADDRESS REG                                                                            |
| 3089 | 005520 | 177744 |        |        | MEMERR: 177744  | ;MEMORY SYSTEM ADDRESS REG                                                                         |
| 3090 |        | 000114 |        |        | PARE70=114      | ;PARITY ERROR VECTOR FOR 70                                                                        |

```

3091 .SBTTL REGISTER TEST
3092 005522 012737 177777 005012 BEGIN: MOV #-1,ST200
3093 005530 000402 BR START
3094 005532 005037 005012 BEGIN2: CLR ST200
3095
3096 005536 START:
3097 .SBTTL INITIALIZE THE COMMON TAGS
3098 ;;CLEAR THE COMMON TAGS ($CMTAG) AREA
3099 005536 012706 001100 MOV $CMTAG,R6 ;;FIRST LOCATION TO BE CLEARED
3100 005542 005026 CLR (R6)+ ;;CLEAR MEMORY LOCATION
3101 005544 022706 001140 CMP $SWR,R6 ;;DONE?
3102 005550 001374 BNE -6 ;;LOOP BACK IF NO
3103 005552 012706 001000 MOV $STACK,SP ;;SETUP THE STACK POINTER
3104 ;;INITIALIZE A FEW VECTORS
3105 005556 012737 043120 000020 MOV $$SCOPE,@#IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE
3106 005564 012737 000340 000022 MOV #340,@#IOTVEC+2 ;;LEVEL 7
3107 005572 012737 044744 000030 MOV $ERROR,@#EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
3108 005600 012737 000340 000032 MOV #340,@#EMTVEC+2 ;;LEVEL 7
3109 005606 012737 046450 000034 MOV $TRAP,@#TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
3110 005614 012737 000340 000036 MOV #340,@#TRAPVEC+2;LEVEL 7
3111 005622 012737 046530 000024 MOV $PWRDN,@#PWRVEC ;;POWER FAILURE VECTOR
3112 005630 012737 000340 000026 MOV #340,@#PWRVEC+2 ;;LEVEL 7
3113 005636 005037 001212 CLR $TIMES ;;INITIALIZE NUMBER OF ITERATIONS
3114 005642 005037 001214 CLR $ESCAPE ;;CLEAR THE ESCAPE ON ERROR ADDRESS
3115 005646 112737 000001 001115 MOVB #1,$SERMAX ;;ALLOW ONE ERROR PER TEST
3116 005654 012737 005654 001106 MOV #,$SLPADR ;;INITIALIZE THE LOOP ADDRESS FOR SCOPE
3117 005662 012737 005662 001110 MOV #,$SLPERR ;;SETUP THE ERROR LOOP ADDRESS
3118 ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
3119 ;;EQUAL TO A "-1" SETUP FOR A SOFTWARE SWITCH REGISTER.
3120 005670 013746 000004 MOV @#ERRVEC, -(SP) ;;SAVE ERROR VECTOR
3121 005674 012737 005730 000004 MOV #64,$@#ERRVEC ;;SET UP ERROR VECTOR
3122 005702 012737 177570 001140 MOV #DSWR,$SWR ;;SETUP FOR A HARDWARE SWICH REGISTER
3123 005710 012737 177570 001142 MOV #DDISP,$DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
3124 005716 022777 177777 173214 CMP #-1,@$SWR ;;TRY TO REFERENCE HARDWARE SWR
3125 005724 001012 BNE 66$;;BRANCH IF NO TIMEOUT TRAP OCCURRED
3126 ;;AND THE HARDWARE SWR IS NOT = -1
3127 005726 000403 BR 65$;;BRANCH IF NO TIMEOUT
3128 005730 012716 005736 64$: MOV #65$, (SP) ;;SET UP FOR TRAP RETURN
3129 005734 000002 RTI
3130 005736 012737 000176 001140 65$: MOV $SWREG,$SWR ;;POINT TO SOFTWARE SWR
3131 005744 012737 000174 001142 MOV $DISPREG,$DISPLAY
3132 005752 012637 000004 66$: MOV (SP)+,@#ERRVEC ;;RESTORE ERROR VECTOR
3133
3134
3135
3136 005756 012737 000000 177776 MOV #0,$PS ;;SET PROCESSOR STATUS TO 0
3137 005764 012737 000200 000036 MOV #200,@#TRAPVEC+2 ;;TRAP PRIORITY = 4
3138 005772 013700 002716 MOV @#RPVEC,$RO ;;GET RP VECTOR ADDRESS
3139 005776 012720 043056 MOV #RPVECT, (RO)+ ;;THIS IS FOR UNTIMELY INTERRUPTS
3140 006002 012710 000340 MOV #340, (RO) ;;RPO4 INTERRUPT SERVICE ROUTINE
3141 ;;PRIORITY = 7
3142 006006 004737 044064 JSR PC,@#$TKINT ;;INITILIZE THE TK
3143 006012 005037 045100 CLR $PRITEM ;;CLEAR FOR ERROR MESSAGE PRINTOUT
3144 006016 005737 005242 TST @#FIRST ;;IS THIS FIRST TIME ROUND
3145 006022 001001 BNE 1$;;BRANCH IF NOT
3146 006024 000402 BR 2$

```

```

3147 006026 000137 006124 1$: JMP @#SND1
3148 006032 023737 000042 000046 2$: CMP @#42,@#46 ;ARE WE IN QV OR AUTO ACCEPT MODE?
3149 006040 001431 BEQ SND1 ;IF YES, SKIP HEADER
3150 006042 104401 006050 TYPE ,68$;TYPE ASCIZ STRING
3151 006046 000426 BR 67$;GET OVER THE ASCIZ
3152 ;:68$: .ASCIZ <15><12>/RH70 FUNCTIONAL CONTROLLER TEST DERHA-C/
3153 006124 67$:
3154 006124 012737 177777 005242 SND1: MOV #-1,@#FIRST ;NEXT TIME DO NOT GIVE HEADER
3155 006132 012737 037746 000114 MOV #PARITY,@#PARE70 ;PARITY VECTOR
3156 006140 012737 000340 000116 MOV #340,@#PARE70+2 ;PRIORITY 7
3157 006146 012737 037610 000004 MOV #TIEOUT,@#ERRVEC ;TIMEOUT VECTOR
3158 006154 012737 000340 000006 MOV #340,@#ERRVEC+2 ;PRIORITY 7
3159
3160
3161
3162
3163
3164
3165
3166
3167
3168
3169
3170
3171
3172
3173
3174
3175
3176
3177
3178
3179
3180
3181
3182
3183
3184
3185
3186
3187
3188
3189
3190
3191
3192
3193
3194
3195
3196
3197
3198
3199
3200
3201
3202

```

```

*TEST 1 SIZE FOR RH DEVICES
* THIS TEST DETERMINS WHICH RH DEVICE IS ON THE SYSTEM.
* IF THE SYSTEM HAS MORE THAN ONE RH DEVICE THEN ONLY ONE OF
* THE DEVICES WILL BE USED IN THE FOLLOWING TESTS.
* THE ONE THAT WILL BE USED IS THE FIRST ONE THAT IS PRESENT
* IN THE FOLLOWING LIST
* RS
* RP
* TM
*
* THE WAY THE TEST WORKS IS AS FOLLOWS:-
* A REERENCE IS MADE TO THE CONTROL AND STATUS REGISTER 1
* FOR THE RS BY A TST INSTRUCTION. IF IT RESPONDS THEN IT IS
* ASSUMED PRESENT AND THE LOCATIONS FOR THE I/O REGISTERS ARE
* FILLED WITH THE APPROPRIATE ADDRESSES.
* THEN THE DRIVE TYPE REGISTER IS CHECKED TO HAVE GOOD
* VALUES.
* IF THE TST INSTRUCTION TRAPS TO A NON EXISTANT VECTOR
* THEN A SIMILAR ATTEMPT IS MADE TO A RP CONTROL AND STATUS
* REGISTER 1.
* THEN A TM IS TRYED.
* THEN A MIXED SYSTEM WITH MORE THAN ONE RH DEVICES IS TRYED.

```

```

3203 006162 000004 TST1: SCOPE
3204 006164 012737 000001 001212 MOV #1,STIMES ;;DO 1 ITERATION
3205 006172 005737 005012 TST ST200 ;;IS IT A 200 START
3206 006173 001413 BEQ 2$;;BRANCH IF NOT 200 START
3207 006200 012700 005256 MOV #PERRS,RO ;;POINTER TO MOVE 9 WMRDS FROM
3208 006204 012701 000011 MOV #9,R1 ;;NUMBER TO MOVE
3209 006210 012702 005300 MOV #DEVPNT,R2 ;;POINTER TO MOVE 9 TORDS TO
3210 006214 012022 1$: MOV (RO)+,(R2)+ ;;FILL WORK TABLE
3211 006216 005301 DEC R1
3212 006220 001375 BNE 1$;;BRANCH IF 9 NOT DONE
3213 006222 000137 006522 JMP SETSIZ
3214 006226
3215 006226 104401 006234 2$: TYPE 65$;;TYPE ASCIZ STRING
3216 006232 000417 BR 64$;;GET OVER THE ASCIZ
3217 ;;65$: .ASCIZ <15><12>/HOW MANY RH TO BE TESTED /
3218 64$:
3219 006272 104401 006300 TYPE 67$;;TYPE ASCIZ STRING
3220 006276 000402 BR 66$;;GET OVER THE ASCIZ
3221 ;;67$: .ASCIZ <15><12>/ /
3222 66$:
3223 006304 104410 RDOCT
3224 006306 011637 005320 MOV (SP),LTRY ;;GET NUMBER OF RH TO BE TESTED
3225 006312 012637 005250 MOV (SP)+,TMP0 ;;WORKING NUMBER OF RH
3226 006316 012737 000001 005252 MOV #1,TMP1 ;;RH NUMBER TO BE TYPED
3227 006324 005000 CLR RO ;;INDEX TO WORKING TABLE
3228
3229 006326 104401 006334 3$: TYPE 69$;;TYPE ASCIZ STRING
3230 006326 000417 BR 68$;;GET OVER THE ASCIZ
3231 ;;69$: .ASCIZ <15><12>/TYPE BASE ADDRESS OF RH NO/
3232 68$:
3233 006372 013746 005252 MOV TMP1,-(SP)
3234 006372 104405 TYPDS
3235 006376 104401 006406 TYPE 71$;;TYPE ASCIZ STRING
3236 006400 000402 BR 70$;;GET OVER THE ASCIZ
3237 006404
3238 ;;71$: .ASCIZ <15><12>/ /
3239 70$:
3240 006412 104410 RDOCT
3241 006414 012660 005300 MOV (SP)+,DEVPNT(RO) ;;FILL WORKING TABLE WITH BASE ADDRESS
3242 006420 104401 006426 TYPE 73$;;TYPE ASCIZ STRING
3243 006424 000420 BR 72$;;GET OVER THE ASCIZ
3244 ;;73$: .ASCIZ <15><12>/TYPE VECTOR ADDRESS OF RH NO/
3245 72$:
3246 006466 013746 005252 MOV TMP1,-(SP)
3247 006472 104405 TYPDS
3248 006474 104401 000200 TYPE ,CRLF
3249 006500 104410 RDOCT
3250 006502 012660 005310 MOV (SP)+,VECPNT(RO) ;;FILL WORKING TABLE WITH VECTOR ADDRESS
3251 006506 005720 TST (RO)+ ;;ADD 2 TO RO
3252 006510 005237 005252 INC TMP1 ;;GET NEXT RH NUMBER
3253 006514 005337 005250 DEC TMP0 ;;COUNT DOWN RH TO BE TESTED
3254 006520 001302 BNE 3$;;BRANCH IF ALL NOT DONE
3255
3256 ;RO WILL HAVE DEVICE POINTER, R1 WILL HAVE VECTOR POINTER
3257 006522 012700 005300 SETSIZ: MOV #DEVPNT,RO ;;DEVICE POINTER
3258 006526 012701 005310 MOV #VECPNT,R1 ;;VECTOR PMINTER

```

```

3259 006532 005037 005322 CLR TFOUND ;WILL BE USED AS POINTER
3260 006536 SS2: ;TO FOUND TABLE.
3261 006536 012737 010530 000004 1$: MOV #SS4,ERRVEC ;TIME OUT VECTOR TO REDUCE LTRY
3262 006544 012037 005324 MOV (R0)+,TESTDV ;ADDRESS OF DEVICE TO BE TESTED
3263 006550 012137 005326 MOV (R1)+,TESTVC ;VECTOR TO BE TESTED
3264 006554 005777 176544 TST @TESTDV ;TRY TIME OUT ON DEVICE BASE
3265 ;IF NO TIME OUT OCCURS THEN DEVICE IN TESTDV IS PRESENT
3266 ;NOW FILL ALL REGISTER ADDRESS TABLE
3267 006560 012702 000026 MOV #22,R2 ;COUNT 22
3268 006564 012703 004060 MOV #RHCS1,R3 ;GET BASE LOCATION
3269 006570 013704 005324 MOV TESTDV,R4 ;GET BASE ADDRESS
3270 006574 010423 2$: MOV R4,(R3)+ ;FILL PROPER ADDRESS
3271 006576 062704 000002 ADD #2,R4 ;INCREMENT ADDRESS BY 2
3272 006602 005302 DEC R2 ;COUNT DOWN
3273 006604 001373 BNE 2$;BRANCH IF 22 NOT DONE.
3274 006606 005077 175256 CLR @RHCS2 ;SET UNIT NUMBER
3275 006612 SS6:
3276 006612 012737 005330 005360 3$: MOV #TYPNT,POINTT ;POINTER TO DRIVE TYPE
3277 006620 012737 000014 005362 MOV #14,NTYPNT ;NUMBER OF DRIVE TYPES
3278
3279 006626 SS7:
3280 006626 022737 000001 005362 4$: CMP #1,NTYPNT ;IS IT FOR TU
3281 006634 001424 BEQ 5$;IF FOR TU BRANCH
3282 006636 017737 175244 001126 MOV @RHDT,$BDDAT ;READ DRIVE TYPE
3283 006644 012702 000014 MOV #14,R2 ;GET NUMBER FOR DT NOT DONE
3284 006650 163702 005362 SUB NTYPNT,R2 ;GET DT TO DO
3285 006654 006302 ASL R2 ;MULTIPLY R2 BY 2
3286 006656 026237 005330 001126 CMP TYPNT(R2),$BDDAT ;IS DRIVE TYPE FOUND
3287 006664 001402 BEQ 16$;DRIVE TYPE FOUND SO BRANCH
3288 006666 000137 010554 JMP 5$8
3289 006672 032777 010000 175170 16$: BIT #NED,@RHCS2 ;IS IT NON EXISTANT DRIVE
3290 006700 001437 BEQ 8$;NED NOT SET, DRIVE TYPE FOUND SO BRANCH
3291 ;A DEVICE HAS NOT BEEN FOUND
3292 006702 000137 010546 JMP 5$5 ;A DEVICE HAS NOT BEEN FOUND SO BRANCH
3293
3294 ;TRYING THE TU16 DRIVE TYPE
3295 006706 005037 005364 5$: CLR TMPSLV ;SLAVE 0
3296 006712 013777 005364 175172 6$: MOV TMPSLV,@RHCT ;MOVE SLAVE NUMBER IN TAPE CONTROL
3297 006720 017737 175162 001126 MOV @RHDT,$BDDAT ;READ DRIVE TYPE
3298 006726 032737 002000 001126 BIT #SLVPR,$BDDAT ;IS SLAVE PRESENT
3299 006734 001014 BNE 7$
3300 006736 022737 000007 005364 CMP #7,TMPSLV ;IS 7 DONE
3301 006744 001002 BNE 17$;BRANCH IF 7 DONE AND NONE FOUND
3302 006746 000137 010554 JMP 5$8
3303 006752 005237 005364 17$: INC TMPSLV ;GET NEXT SLAVE
3304 006756 012777 040000 175074 MOV #TRE,@RHCS1 ;CLEAR CONTROLLER ERRORS
3305 006764 000752 BR 6$;TRY NEXT SLAVE
3306 ;A DEVICE HAS BEEN FOUND SAVE SLAVE
3307 006766 013702 005322 7$: MOV TFOUND,R2 ;GET NO OF RH FOUND X2 FOR INDEX
3308 006772 013762 005364 005446 MOV TMPSLV,FSLAVE(R2)
3309 ;A DEVICE HAS BEEN FOUND TEST VECTOR
3310 007000 012737 007014 000004 8$: MOV #9$,ERRVEC ;TIME OUT VECTOR TO REPORT ERROR
3311 007006 005777 176314 TST @TESTVC ;TRY TIME OUT ON VECTOR
3312 007012 000403 BR 10$;A VECTOR EXISTS SO CONTINUE
3313 007014 104146 9$: ERROR 146 ;A DEVICE BASE ADDRESS DID NOT
3314 ;TIME OUT BUT ITS CORRESPONDING

```

```

3315 ;VECTOR ADDRESS TIMED OUT
3316 ;HIT CONTINUE TO REPEAT THIS
3317 ;TEST
3318 007016 000000 HALT
3319 007020 000767 BR 8$;REPEAT THIS TEST
3320 ;A DEVICE HAS BEEN FOUND AND VECTOR RESPONDS SO STORE RESULTS
3321 007022 013702 005322 10$: MOV TFOUND,R2 ;GET NO OF RH FOUND X2 FOR INDEX
3322 007026 013762 005362 005366 MOV NTYPNT,FDEVIC(R2) ;DEVICE 1=TU; 2,3,4,5,6,7=RP;
3323 ;10,11,12,13,14=RS
3324 007034 017762 175030 005376 MOV @RHCS2,FUNITN(R2) ;GET RHCS2
3325 007042 042762 177770 005376 BIC #177770,FUNITN(R2) ;KEEP UNIT NUMBER
3326 007050 017762 175032 005406 MOV @RHDT,FTYPE(R2) ;DRIVE BYTE
3327 007056 013762 005326 005416 MOV TESTVC,FVECTR(R2) ;VECTOR
3328 007064 013762 005324 005426 MOV TESTDV,FBASEA(R2) ;BASE ADDRESS
3329 007072 013762 005322 005436 MOV TFOUND,FRHNM(R2) ;RH NUMBER X2 MINUS ONE
3330 007100 006262 005436 ASR FRHNM(R2) ;RH NUMBER MINUS ONE
3331 007104 005262 005436 INC FRHNM(R2) ;RH NUMBER
3332 007110 022762 000001 005366 CMP #1,FDEVIC(R2) ;IS IT TU
3333 007116 001016 BNE 11$;BRANCH IF NOT TU
3334 007120 012762 041710 005456 MOV #CMNDTM,FDRIVR(R2) ;DRIVER ADDRESS FOR TU
3335 007126 013746 005324 MOV TESTDV,-(SP) ;BASE ADDRESS
3336 007132 062716 000034 ADD #<2*14.>(SP) ;15TH ADDRESS IS BAE FOR TU
3337 007136 011662 005466 MOV (SP),FBAE(R2) ;SAVE BAE FOR TU
3338 007142 062716 000002 ADD #2,(SP) ;16TH ADDRESS IS CS3 FOR TU
3339 007146 012662 005476 MOV (SP)+,FCS3(R2) ;SAVE CS3 FOR TU
3340
3341 007152 000511 BR SS1
3342 007154 022762 000002 005366 11$: CMP #2,FDEVIC(R2) ;IS IT RP DUAL PORT
3343 007162 001424 BEQ 12$;BRANCH IF RP FOUND
3344 007164 022762 000003 005366 CMP #3,FDEVIC(R2) ;IS IT RP
3345 007172 001420 BEQ 12$;BRANCH IF RP FOUND
3346 007174 022762 000004 005366 CMP #4,FDEVIC(R2) ;IS IT RP DUAL PORT
3347 007202 001414 BEQ 12$;BRANCH IF RP FOUND
3348 007204 022762 000005 005366 CMP #5,FDEVIC(R2) ;IS IT RP
3349 007212 001410 BEQ 12$;BRANCH IF RP FOUND
3350 007214 022762 000006 005366 CMP #6,FDEVIC(R2) ;IS IT RP DUAL PORT
3351 007222 001404 BEQ 12$;BRANCH IF RP FOUND
3352 007224 022762 000007 005366 CMP #7,FDEVIC(R2) ;IS IT RP
3353 007232 001016 BNE 13$;BRANCH IF NO RP
3354 007234 012762 041572 005456 12$: MOV #CMNDRP,FDRIVR(R2) ;DRIVER ADDRESS FOR RP
3355 007242 013746 005324 MOV TESTDV,-(SP) ;BASE ADDRESS
3356 007246 062716 000050 ADD #<2*20.>(SP) ;21ST ADDRESS IS BAE FOR RP
3357 007252 011662 005466 MOV (SP),FBAE(R2) ;SAVE BAE FOR RP
3358 007256 062716 000002 ADD #2,(SP) ;22ND ADDRESS IS CS3 FOR RP
3359 007262 012662 005476 MOV (SP)+,FCS3(R2) ;SAVE CS3 FOR RP
3360
3361 007266 000443 BR SS1
3362 007270 022762 000010 005366 13$: CMP #10,FDEVIC(R2) ;IS IT RS03/LA
3363 007276 001420 BEQ 14$;BRANCH IF RS03/LA
3364 007300 022762 000011 005366 CMP #11,FDEVIC(R2) ;IS IT RS04/L
3365 007306 001414 BEQ 14$;BRANCH IF RS04/L
3366 007310 022762 000012 005366 CMP #12,FDEVIC(R2) ;IS IT RS04
3367 007316 001410 BEQ 14$;BRANCH IF RS04
3368 007320 022762 000013 005366 CMP #13,FDEVIC(R2) ;IS IT RS03/L
3369 007326 001404 BEQ 14$;BRANCH IF RS03/L
3370 007330 022762 000014 005366 CMP #14,FDEVIC(R2) ;IS IT RS03

```

```

3371 007336 001016 BNE 15$;BRANCH IF NOT RS03
3372 007340 012762 041502 005456 14$: MOV #CMNDRS,FDRIVR(R2) ;DRIVER ADDRESS FOR RS
3373 007346 013746 005324 MOV TESTDV,-(SP) ;BASE ADDRESS
3374 007352 062716 000030 ADD #<2*12>,(SP) ;13TH ADDRESS IS BAE FOR RS
3375 007356 011662 005466 MOV (SP),FBAE(R2) ;SAVE BAE FOR RS
3376 007362 062716 000002 ADD #2,(SP) ;14TH ADDRESS IS CS3 FOR RS
3377 007366 012662 005476 MOV (SP)+,FCS3(R2) ;SAVE CS3 FOR RS
3378 007372 000401 BR SS1 ;CONTINUE
3379 007374 000000 15$: HALT ;PROGRAM ERROR
3380
3381
3382
3383
3384 007376 104401 007404 SS1: TYPE 65$;:TYPE ASCIZ STRING
3385 007402 000406 BR 64$;:GET OVER THE ASCIZ
3386
3387 007420 65$: .ASCIZ <15><12>/ON RH NO/
3388 007420 016246 005436 64$: MOV FRHNM(R2),-(SP) ;TYPE RH NUMBER
3389 007424 104405 TYPDS
3390 007426 104401 007434 TYPE 67$;:TYPE ASCIZ STRING
3391 007432 000411 BR 66$;:GET OVER THE ASCIZ
3392
3393 67$: .ASCIZ / BASE /
3394 007456 016246 005426 66$: MOV FBASEA(R2),-(SP) ;TYPE BASE ADDRESS
3395 007462 104402 TYPOC
3396 007464 104401 007472 TYPE 69$;:TYPE ASCIZ STRING
3397 007470 000404 BR 68$;:GET OVER THE ASCIZ
3398
3399 69$: .ASCIZ / FOUND/
3400 007502 022762 000001 005366 68$: CMP #1,FDEVIC(R2) ;IS IT TU
3401 007510 001020 BNE 1$;BRANCH IF NOT TU
3402 007512 104401 007520 TYPE 71$;:TYPE ASCIZ STRING
3403 007516 000410 BR 70$;:GET OVER THE ASCIZ
3404
3405 71$: .ASCIZ / TU16 AT SLAVE/
3406 007540 016246 005446 70$: MOV FSLAVE(R2),-(SP) ;TYPE SLAVE NUMBER
3407 007544 104405 TYPDS
3408 007546 000137 010346 JMP 6$
3409
3410
3411
3412
3413
3414
3415 007552 022762 000002 005366 1$: CMP #2,FDEVIC(R2) ;THE FOLLOWING TYPES OUT
3416 007560 001016 BNE 2$;THE DEVICE AND REDEFINES
3417 007562 104401 007570 TYPE 73$;FDEVIC: 1=TU, 2=RP DUAL PORT
3418 007566 000411 BR 72$;3=RP SINGLE PORT
3419
3420 73$: .ASCIZ / RPO6 DUAL PORT /
3421 007612 000137 010346 72$: JMP 6$
3422 007616 022762 000003 005366 2$: CMP #3,FDEVIC(R2) ;IS IT RPO6 SINGLE PORT
3423 007624 001016 BNE 3$;BRANCH IF NOT RPO6 SINGLE PORT
3424 007626 104401 007634 TYPE 75$;:TYPE ASCIZ STRING
3425 007632 000411 BR 74$;:GET OVER THE ASCIZ
3426
3427 75$: .ASCIZ / RPO6 SINGLE PORT/

```

```

3427 007656 74$:
3428 007656 000137 010346 JMP 6$
3429 007662 022762 000004 005366 3$: CMP #4,FDEVIC(R2) ;IS IT RPO5 DUAL PORT
3430 007670 001020 BNE 4$;BRANCH IF NOT RPO5 DUAL PORT
3431 007672 012762 000002 005366 MOV #2,FDEVIC(R2)
3432 007700 104401 007706 TYPE 77$;:TYPE ASCIZ STRING
3433 007704 000410 BR 76$;:GET OVER THE ASCIZ
3434 ;:77$: .ASCIZ / RPO5 DUAL PORT/
3435 76$:
3436 007726 000137 010346 JMP 6$
3437 007732 022762 000005 005366 4$: CMP #5,FDEVIC(R2) ;IS IT RPO5 SINGLE PORT
3438 007740 001020 BNE 8$;BRANCH IF NOT RPO5 SINGLE PORT
3439 007742 012762 000003 005366 MOV #3,FDEVIC(R2)
3440 007750 104401 007756 TYPE 79$;:TYPE ASCIZ STRING
3441 007754 000411 BR 78$;:GET OVER THE ASCIZ
3442 ;:79$: .ASCIZ / RPO5 SINGLE PORT/
3443 78$:
3444 010000
3445 010000 000562
3446 010002 022762 000006 005366 8$: BR 6$
3447 010010 001017 CMP #6,FDEVIC(R2) ;IS IT RPO4 DUAL PORT
3448 010012 012762 000002 005366 BNE 9$;BRANCH IF NOT RPO4 DUAL PORT
3449 010020 104401 010026 MOV #2,FDEVIC(R2)
3450 010024 000410 TYPE 81$;:TYPE ASCIZ STRING
3451 BR 80$;:GET OVER THE ASCIZ
3452 ;:81$: .ASCIZ / RPO4 DUAL PORT/
3453 80$:
3454 010046
3455 010046 000537
3456 010050 022762 000007 005366 9$: BR 6$
3457 010056 001020 CMP #7,FDEVIC(R2) ;IS IT RPO4 SINGLE PORT
3458 010060 012762 000003 005366 BNE 10$;BRANCH IF NOT RPO4 SINGLE PORT
3459 010066 104401 010074 MOV #3,FDEVIC(R2)
3460 010072 000411 TYPE 83$;:TYPE ASCIZ STRING
3461 BR 82$;:GET OVER THE ASCIZ
3462 ;:83$: .ASCIZ / RPO4 SINGLE PORT/
3463 82$:
3464 010116
3465 010116 000513
3466 010120 022762 000010 005366 10$: BR 6$
3467 010126 001014 CMP #10,FDEVIC(R2) ;IS IT RS03-LA
3468 010130 012762 000005 005366 BNE 11$;BRANCH IF NOT RS03-LA
3469 010136 104401 010144 MOV #5,FDEVIC(R2)
3470 010142 000405 TYPE 85$;:TYPE ASCIZ STRING
3471 BR 84$;:GET OVER THE ASCIZ
3472 ;:85$: .ASCIZ / RS03-LA/
3473 84$:
3474 010156
3475 010156 000473
3476 010160 022762 000011 005366 11$: BR 6$
3477 010166 001013 CMP #11,FDEVIC(R2) ;IS IT RS04-L
3478 010170 012762 000004 005366 BNE 12$;BRANCH IF NOT RS04-L
3479 010176 104401 010204 MOV #4,FDEVIC(R2)
3480 010202 000404 TYPE 87$;:TYPE ASCIZ STRING
3481 BR 86$;:GET OVER THE ASCIZ
3482 ;:87$: .ASCIZ / RS04-L/
3483 86$:
3484 010214
3485 010214 000454
3486 010216 022762 000012 005366 12$: BR 6$
3487 010224 001012 CMP #12,FDEVIC(R2) ;IS IT RS04
3488 010226 012762 000004 005366 BNE 13$;BRANCH IF NOT RS04
3489 010234 104401 010242 MOV #4,FDEVIC(R2)
3490 010240 000403 TYPE 89$;:TYPE ASCIZ STRING
3491 BR 88$;:GET OVER THE ASCIZ
3492 ;:89$: .ASCIZ / RS04/

```



```

3483 010250 88$:
3484 010250 000436
3485 010252 022762 000013 005366 13$: BR 6$
3486 010260 001013 :CMP #13,FDEVIC(R2) ;IS IT RS03-L
3487 010262 012762 000005 005366 :BNE 14$;BRANCH IF NOT RS03-L
3488 010270 104401 010276 :MOV #5,FDEVIC(R2)
3489 010274 000404 :TYPE 91$;;TYPE ASCIZ STRING
3490 :BR 90$;;GET OVER THE ASCIZ
3491 010306 :.ASCIZ / RS03-L/
3492 010306 000417 90$:
3493 010310 022762 000014 005366 14$: BR 6$
3494 010316 001012 :CMP #14,FDEVIC(R2) ;IS IT RS03
3495 010320 012762 000005 005366 :BNE 5$;BRANCH IF NOT RS03
3496 010326 104401 010334 :MOV #5,FDEVIC(R2)
3497 010332 000403 :TYPE 93$;;TYPE ASCIZ STRING
3498 :BR 92$;;GET OVER THE ASCIZ
3499 010342 92$:
3500 010342 000401 :.ASCIZ / RS03/
3501 010344 000000 5$: BR 6$
3502 010346 6$: HALT ;PROGRAM ERROR
3503 010346 104401 010354 :TYPE 95$;;TYPE ASCIZ STRING
3504 010352 000411 :BR 94$;;GET OVER THE ASCIZ
3505 :.ASCIZ <15><12>/AT UNIT NUMBER/
3506 010376 94$:
3507 010376 016246 005376 :MOV FUNITN(R2),-(SP) ;TYPE UNIT NUMBER
3508 010402 104405 :TYPDS
3509 010404 104401 010412 :TYPE 97$;;TYPE ASCIZ STRING
3510 010410 000411 :BR 96$;;GET OVER THE ASCIZ
3511 :.ASCIZ / VECTOR /
3512 010434 96$:
3513 010434 016246 005416 :MOV FVECTR(R2),-(SP) ;TYPE VECTOR
3514 010440 104402 :TYPDC
3515 010442 104401 010450 :TYPE 99$;;TYPE ASCIZ STRING
3516 010446 000402 :BR 98$;;GET OVER THE ASCIZ
3517 :.ASCIZ <15><12>/ /
3518 010454 98$:
3519 010454 104401 010462 :TYPE 101$;;TYPE ASCIZ STRING
3520 010460 000402 :BR 100$;;GET OVER THE ASCIZ
3521 :.ASCIZ <15><12>/ /
3522 010466 100$:
3523 :
3524 :UPDATE TFOUND
3525 010466 062737 000002 005322 :ADD #2,TFOUND ;GET READY FOR NEXT DEVICE
3526 :
3527 :ALL UNITS DONE? IF LTRY BECOMES ZERO YES ALL DONE
3528 010474 005337 005320 :DEC LTRY ;REDUCE DEVICES LEFT TO TRY
3529 010500 001402 :BEQ 7$;BRANCH IF ALL COMPLETE
3530 010502 000137 006536 :JMP SS2 ;ALL NOT DONE
3531 010506 7$:
3532 010506 013746 005322 :MOV TFOUND,-(SP) ;GET TWICE NUMBER OF RH FOUND
3533 010512 006216 :ASR (SP) ;DIVIDE BY 2
3534 010514 011637 005506 :MOV (SP),TSTUNT
3535 010520 012637 005510 :MOV (SP)+,WORUNT
3536 010524 000137 010632 :JMP TST2 ;JUMP TO NEXT TEST
3537 :
3538 :A RH TIMED OUT SO TRY NEXT UNIT OR END TRYING

```

```

3539 010530 005337 005320 SS4: DEC LTRY ;RH TIMES OUT SO DECREASE RH TYPED
3540 010534 001402 BEQ 1$;BRANCH IF ALL DONE
3541 010536 000137 006536 JMP SS2 ;ALL NOT DONE SO JUMP.
3542 010542 000137 010506 1$: JMP SS3 ;ALL DONE SO STORE NUMBER OF RH FOUND
3543
3544
3545 010546 012777 040000 173304 SS5: MOV #TRE, @RHCS1 ;A DRIVE TYPE DID NOT MATCH SO TRY NEXT
3546 010554 005337 005362 SS8: DEC NTYPNT ;CLEAR NED ERROR
3547 010560 001402 BEQ 1$;DECREASE NUMBER OF DRIVE TYPES TRIED
3548 010562 000137 006626 JMP SS7 ;BRANCH IF ALL DONE
3549 010566 005277 173276 1$: INC @RHCS2 ;ALL NOT DONE
3550 010572 012777 040000 173260 MOV #TRE, @RHCS1 ;GET NEXT UNIT NO.
3551 010600 017746 173264 MOV @RHCS2, -(SP) ;CLEAR NED ERROR
3552 010604 042716 177770 BIC #177770, (SP) ;GET RHCS2
3553 010610 022726 000010 CMP #8., (SP)+ ;GET UNIT NO
3554 010614 001402 BEQ 2$;ARE 7 DONE
3555 010616 000137 006612 JMP SS6 ;BRANCH IF 7 DONE
3556
3557 010622 104147 2$: ERROR 147 ;7 NOT DONE SO TRY NEXT UNIT NO
3558 010624 000000 HALT
3559
3560 010626 000137 010530 JMP SS4
3561
3562
3563
3564
3565
3566
3567
3568
3569
3570
3571
3572

```

```

*TEST 2 UNIT UNDER TEST
* THIS TYPES THE UNIT TO BE TESTED
* AND IS THE FIRST TEST AFTER THE END OF THE PROGRAM

```

```

3573 010632 000004 TST2: SCOPE
3574 010634 012737 000001 001212 MOV #1, $TIMES ;DO 1 ITERATION
3575 010642 012737 037610 000004 MOV #TIMEOUT, @ERRVEC ;TIMEOUT VECTOR
3576 010650 012737 000340 000006 MOV #340, @ERRVEC+2 ;PRIORITY 7
3577
3578 010656 013746 005510 MOV WORUNT, -(SP) ;GET WORKING RH NUMBER LEFT
3579 010662 013702 005506 MOV TSTUNT, R2 ;GET TOTAL NO OF RH FOUND
3580 010666 162602 SUB (SP)+, R2 ;NO OF RH TO BE TESTED
3581 010670 006302 ASL R2 ;INDEX FOR RH TO BE TESTED.
3582 010672 104401 010700 TYPE ,65$;TYPE ASCIZ STRING
3583 010676 000402 BR 64$;GET OVER THE ASCIZ
3584
3585 010704 65$: .ASCIZ <15><12>/ /
3586 010704 104401 010712 64$: TYPE ,67$;TYPE ASCIZ STRING
3587 010710 000410 BR 66$;GET OVER THE ASCIZ
3588
3589 010732 67$: .ASCIZ <15><12>/TESTING RH NO/
3590 010732 016246 005436 66$: MOV FRHNM(R2), -(SP) ;TYPE RH NO.
3591 010736 104405 TYPDS
3592
3593 010740 104401 010746 TYPE ,69$;TYPE ASCIZ STRING
3594 010744 000410 BR 68$;GET OVER THE ASCIZ

```

```

3595 ::69$: .ASCIZ / USING /
3596 010766 68$:
3597 010766 104401 010774 TYPE 71$;;TYPE ASCIZ STRING
3598 010772 000404 BR 70$;;GET OVER THE ASCIZ
3599 ::71$: .ASCIZ / BASE /
3600 011004 70$:
3601 011004 016246 005426 MOV FBASE(R2),-(SP) ;TYPE BASE ADDRESS
3602 011010 104402 TYPDS
3603 011012 022762 000001 005366 CMP #1,FDEVIC(R2) ;IS IT TU
3604 011020 001017 BNE 1$;BRANCH IF NOT TU
3605 011022 104401 011030 TYPE 73$;;TYPE ASCIZ STRING
3606 011026 000410 BR 72$;;GET OVER THE ASCIZ
3607 ::73$: .ASCIZ / TU16 AT SLAVE/
3608 011050 72$:
3609 011050 016246 005446 MOV FSLAVE(R2),-(SP) ;TYPE SLAVE NUMBER
3610 011054 104405 TYPDS
3611 011056 000467 BR 6$
3612 011060 022762 000002 005366 1$: CMP #2,FDEVIC(R2) ;IS IT RP DUAL PORT
3613 011066 001014 BNE 2$;BRANCH IF NOT RP DUAL PORT
3614 011070 104401 011076 TYPE 75$;;TYPE ASCIZ STRING
3615 011074 000410 BR 74$;;GET OVER THE ASCIZ
3616 ::75$: .ASCIZ / RP DUAL PORT /
3617 011116 74$:
3618 011116 000447 BR 6$
3619 011120 022762 000003 005366 2$: CMP #3,FDEVIC(R2) ;IS IT RO SINGLE PORT
3620 011126 001014 BNE 3$;BRANCH IF NOT RP
3621 011130 104401 011136 TYPE 77$;;TYPE ASCIZ STRING
3622 011134 000410 BR 76$;;GET OVER THE ASCIZ
3623 ::77$: .ASCIZ / RP SINGLE PORT/
3624 011156 76$:
3625 011156 000427 BR 6$
3626 011160 022762 000004 005366 3$: CMP #4,FDEVIC(R2) ;IS IT RS04
3627 011166 001007 BNE 4$;BRANCH IF NOT RS04
3628 011170 104401 011176 TYPE 79$;;TYPE ASCIZ STRING
3629 011174 000403 BR 78$;;GET OVER THE ASCIZ
3630 ::79$: .ASCIZ / RS04/
3631 011204 78$:
3632 011204 000414 BR 6$
3633 011206 022762 000005 005366 4$: CMP #5,FDEVIC(R2) ;IS IT RS03
3634 011214 001007 BNE 5$;BRANCH IF NOT RS03
3635 011216 104401 011224 TYPE 81$;;TYPE ASCIZ STRING
3636 011222 000403 BR 80$;;GET OVER THE ASCIZ
3637 ::81$: .ASCIZ / RS03/
3638 011232 80$:
3639 011232 000401 BR 6$
3640 011234 000000 5$: HALT ;PROGRAM ERROR
3641
3642 011236 6$:
3643 011236 104401 011244 TYPE 83$;;TYPE ASCIZ STRING
3644 011242 000411 BR 82$;;GET OVER THE ASCIZ
3645 ::83$: .ASCIZ <15><12>/AT UNIT NUMBER/
3646 011266 82$:
3647 011266 016246 005376 MOV FUNITN(R2),-(SP) ;TYPE UNIT NUMBER
3648 011272 104405 TYPDS
3649 011274 104401 011302 TYPE 85$;;TYPE ASCIZ STRING
3650 011300 000411 BR 84$;;GET OVER THE ASCIZ

```

```

3651 ;:85$: .ASCIZ / VECTOR /
3652 84$:
3653 011324 016246 005416 MOV FVECTR(R2),-(SP) ;TYPE VECTOR
3654 011330 104402 TYPOC
3655 011332 012703 000024 MOV #20,R3 ;COUNT 20
3656 011336 012704 004060 MOV #RHCS1,R4 ;GET BASE LOCATION
3657 011342 016205 005426 MOV FBASEA(R2),R5 ;GET BASE ADDRESS
3658 011346 010524 7$: MOV R5,(R4)+ ;FILL PROPER ADDRESS
3659 011350 062705 000002 ADD #2,R5 ;INCREMENT BY 2
3660 011354 005303 DEC R3 ;COUNT DOWN
3661 011356 001373 BNE 7$;BRANCH IF 20 NOT DONE
3662
3663 011360 016237 005376 005010 MOV FUNITN(R2),UNIT ;UNIT NUMBER
3664 011366 016237 005416 005512 MOV FVECTR(R2),VECTOR ;VECTOR
3665 011374 016237 005446 004660 MOV FSLAVE(R2),SLAVE ;SLAVE NO
3666 011402 016237 005456 004640 MOV FDRIVR(R2),COMND ;DRIVER ADDRESS
3667 011410 016237 005466 004130 MOV FBAE(R2),RHBAE ;BAE ADDRESS
3668 011416 016237 005476 004132 MOV FCS3(R2),RHCS3 ;CS3 ADDRESS
3669
3670 011424 005037 045100 CLR PRITEM
3671
3672
3673
3674
3675
3676
3677
3678
3679
3680 ;:*****
3681 ;*TEST 3 BIT BANG RHCS1
3682
3683 ;*
3684 ;* TEST LOADING AND READING OF ALL POSSIBLE BITS
3685 ;* IN RHCS1 REGISTER.
3686 ;* USE A PATTERN OF WALKING 1'S (1,2,4,10 ETC)
3687 ;* AND WALKING 0'S (-2,-3,-5 ETC)
3688 ;* IN THIS TEST SC!TRE!MCPE!DVA!BIT12!BIT10!RDY!GO BITS WILL NOT BE WRITTEN INTO
3689 ;* AND RDY!DVA BITS WILL ALWAYS BE SET
3690 ;* AND BIT10 BITS WILL ALWAYS BE CLEARED
3691 ;* IF SWITCH 14 OR 9 OR 8 ARE SET FOR DEBUGGING
3692 ;* THEN A RH CLEAR (RHCS2 BIT #5) WILL BE
3693 ;* GIVEN TO AID SCOPE SYNC'S ON THE CLEAR
3694 ;* SIGNAL.
3695 ;:*****
3696 TST3: SCOPE
3697 011430 000004 MOV #STACK,SP ;RESET STACK
3698 011432 012706 001000 MOV #3,@#TSTNM ;SAVE TEST NUMBER
3699 011436 012737 000003 004656
3700 011444 004737 040322 JSR PC,@#CLDISK ;GIVE RH INITIALIZE
3701 ;SETUP UNIT NUBER
3702 ;CLEAR RHWC AND FUNCTION BITS IN RHCS1
3703
3704 011450 012737 176201 004650 MOV #SC!TRE!MCPE!DVA!BIT12!BIT10!RDY!GO,WRTBIT ;SC!TRE!MCPE!DVA!BIT12!B
3705 011456 012737 004200 004652 MOV #RDY!DVA,SETBIT ;RDY!DVA ARE BITS ALWAYS SET
3706 011464 012737 002000 004654 MOV #BIT10,CLRBIT ;BIT10 ARE BITS ALWAYS CLEARED

```

```

3707
3708
3709 011472 012737 011516 001110 ;FLOAT 1'S THRU THE RHCS1 REGISTER
3710 011500 012705 000001 MOV #2$, $LPERR ;SET LOOP ON ERROR ADDRESS
3711 011504 010537 001124 MOV #1, R5 ;GETTING READY TO FLOAT A ONE
3712 011510 042737 176201 001124 1$: MOV R5, $GDDAT ;START WITH DATA
3713 011516 032737 041400 001140 2$: BIC #SC!TRE!MCPE!DVA!BIT12!BIT10!RDY!GO, $GDDAT ;CLEAR BITS NOT WRITTEN
3714 011524 001403 BIT #BIT14!BIT9!BIT8, SWR ;ARE SWITCHES 14 OR 9 OR 8 SET
3715 011526 052777 000040 172334 3$: BEQ 3$;BRANCH IF ANY ONE SET
3716 BIS #CLR, $RHCS2 ;GIVE CLEAR FOR SCOPE
3717 011534 013777 001124 172316 3$: MOV $GDDAT, $RHCS1 ;WRITE RHCS1 REGISTER
3718 011542 017737 172312 001126 MOV $RHCS1, $BDDAT ;READ RHCS1 REGISTER
3719 011550 043737 004654 001124 BIC CLRBIT, $GDDAT ;CLEAR ALWAYS CLEARED BITS
3720 011556 053737 004652 001124 BIS SETBIT, $GDDAT ;SET ALWAYS SET BITS
3721 011564 023737 001124 001126 CMP $GDDAT, $BDDAT ;TEST
3722 011572 001404 BEQ 4$;BRANCH IF GOOD
3723 011574 013737 004060 001122 MOV RHCS1, $BDADR ;GET REGISTER ADDRESS
3724 011602 104137 ERROR 137 ;ONE WAS BEING FLOATED
3725 ;THRU RHCS1 REGISTER
3726 ;ON READING RHCS1 BACK
3727 ;IT DID NOT CONTAIN WHAT
3728 ;WAS EXPECTED.
3729 011604 000241 4$: CLC ;CLEAR CARRY
3730 011606 006305 ASL R5 ;GET 1 ONE LEFT
3731 011610 103335 BCC 1$;BRANCH IF 16 NOT DONE
3732
3733 ;FLOAT A ZERO THRU RHCS1 REGISTER.
3734
3735 011612 012737 011636 001110 MOV #6$, $LPERR ;SET LOOP BACK POINT.
3736 011620 012705 177776 MOV #177776, R5 ;GET READY TO FLOAT A ZERO
3737 011624 010537 001124 MOV R5, $GDDAT ;GET READY TO WRITE DATA
3738 011630 042737 176201 001124 5$: BIC #SC!TRE!MCPE!DVA!BIT12!BIT10!RDY!GO, $GDDAT ;CLEAR BITS NOT WRITTEN
3739 011636 032737 041400 001140 6$: BIT #BIT14!BIT9!BIT8, SWR ;ARE SWITCHES 14 OR 9 OR 8 SET
3740 011644 001403 BEQ 7$;BRANCH IF ANY OF THE ABOVE SET
3741 011646 012777 000040 172214 MOV #CLR, $RHCS2 ;CLEAR FOR SCOPE AID TO
3742 ;SYNC IF IN DEBUG
3743 011654 013777 001124 172176 7$: MOV $GDDAT, $RHCS1 ;WRITE INTO RH'XA.
3744 011662 017737 172172 001126 MOV $RHCS1, $BDDAT ;READ RHCS1
3745 011670 053737 004652 001124 BIS SETBIT, $GDDAT ;SET BITS ALWAYS SET
3746 011676 043737 004654 001124 BIC CLRBIT, $GDDAT ;CLEAR BITS ALWAYS 0
3747 011704 023737 001124 001126 CMP $GDDAT, $BDDAT ;TEST
3748 011712 001404 BEQ 8$;BRANCH IF GOOD
3749 011714 013737 004060 001122 MOV RHCS1, $BDADR ;GET REGISTER ADDRESS
3750 011722 104137 ERROR 137 ;ZERO WAS BEING FLOATED
3751 ;THRU RHCS1 REGISTER
3752 ;ON READING IT BACK IT
3753 ;DID NOT CONTAIN WHAT
3754 ;WAS EXPECTED
3755
3756 011724 000261 8$: SEC ;
3757 011726 006105 ROL R5 ;
3758 011730 103735 BCS 5$;
3759
3760
3761
3762
:*****
:*TEST 4 BIT BANG RHCS2

```

```

3763
3764
3765
3766
3767
3768
3769
3770
3771
3772
3773
3774
3775
3776 011732 000004
3777 011734 012706 001000
3778 011740 012737 000004 004656
3779
3780 011746 004737 040322
3781
3782
3783
3784 011752 012737 177740 004650
3785 011760 012737 000100 004652
3786
3787
3788 011766 012737 012012 001110
3789 011774 012705 000001
3790 012000 010537 001124 1$:
3791 012004 042737 177740 001124
3792 012012 032737 041400 001140 2$:
3793 012020 001403
3794 012022 052777 000040 172040
3795
3796 012030 013777 001124 172032 3$:
3797 012036 017737 172026 001126
3798 012044 053737 004652 001124
3799 012052 023737 001124 001126
3800 012060 001404
3801 012062 013737 004070 001122
3802 012070 104137
3803
3804
3805
3806
3807 012072 000241 4$:
3808 012074 006305
3809 012076 103340
3810
3811
3812
3813 012100 012737 012124 001110
3814 012106 012705 177776
3815 012112 010537 001124 5$:
3816 012116 042737 177740 001124
3817 012124 032737 041400 001140 6$:
3818 012132 001403

```

```

;* TEST LOADING AND READING OF ALL POSSIBLE BITS
;* IN RHCS2 REGISTER.
;* USE A PATTERN OF WALKING 1'S (1,2,4,10 ETC)
;* AND WALKING 0'S (-2,-3,-5 ETC)
;* IN THIS TEST 177740 BITS WILL NOT BE WRITTEN INTO
;* AND IR BITS WILL ALWAYS BE SET
;* IF SWITCH 14 OR 9 OR 8 ARE SET FOR DEBUGGING
;* THEN A RH CLEAR (RHCS2 BIT #5) WILL BE
;* GIVEN TO AID SCOPE SYNC'S ON THE CLEAR
;* SIGNAL.
:*****
TST4: SCOPE
MOV #STACK,SP ;RESET STACK
MOV #4,@#TSTNM ;SAVE TEST NUMBER
JSR PC,@#CLDISK ;GIVE RH INITIALIZE
;SETUP UNIT NUBER
;CLEAR RHWC AND FUNCTION BITS IN RHCS1
MOV #177740,WRTBIT ;177740 ARE BITS NOT WRITTEN INTO
MOV #IR,SETBIT ;IR ARE BITS ALWAYS SET
;FLOAT 1'S THRU THE RHCS2 REGISTER
MOV #2$, $LPERR ;SET LOOP ON ERROR ADDRESS
MOV #1,R5 ;GETTING READY TO FLOAT A ONE
1$: MOV R5,$GDDAT ;START WITH DATA
BIC #177740,$GDDAT ;CLEAR BITS NOT WRITTEN INTO
2$: BIT #BIT14!BIT9!BIT8,SWR ;ARE SWITCHES 14 OR 9 OR 8 SET
BEQ 3$;BRANCH IF ANY ONE SET
BIS #CLR,@RHCS2 ;GIVE CLEAR FOR SCOPE
;SYNC IF IN DEBUG:
3$: MOV $GDDAT,@RHCS2 ;WRITE RHCS2 REGISTER
MOV @RHCS2,$BDDAT ;READ RHCS2 REGISTER
BIS SETBIT,$GDDAT ;SET ALWAYS SET BITS
CMP $GDDAT,$BDDAT ;TEST
BEQ 4$;BRANCH IF GOOD
MOV RHCS2,$BDDADR ;GET REGISTER ADDRESS
ERROR 137 ;ONE WAS BEING FLOATED
;THRU RHCS2 REGISTER
;ON READING RHCS2 BACK
;IT DID NOT CONTAIN WHAT
;WAS EXPECTED.
4$: CLC ;CLEAR CARRY
ASL R5 ;GET 1 ONE LEFT
BCC 1$;BRANCH IF 16 NOT DONE
;FLOAT A ZERO THRU RHCS2 REGISTER.
MOV #6$, $LPERR ;SET LOOP BACK POINT.
MOV #177776,R5 ;GET READY TO FLOAT A ZERO
5$: MOV R5,$GDDAT ;GET READY TO WRITE DATA
BIC #177740,$GDDAT ;CLEAR BITS NOT WRITTEN INTO
6$: BIT #BIT14!BIT9!BIT8,SWR ;ARE SWITCHES 14 OR 9 OR 8 SET
BEQ 7$;BRANCH IF ANY OF THE ABOVE SET

```



```

3875 012316 013777 001124 171606 3$: MOV $GDDAT, @RHCS3 ;WRITE RHCS3 REGISTER
3876 012324 017737 171602 001126 MOV @RHCS3, $BDDAT ;READ RHCS3 REGISTER
3877 012332 043737 004654 001124 BIC CLRBIT, $GDDAT ;CLEAR ALWAYS CLEARED BITS
3878 012340 053737 004652 001124 BIS SETBIT, $GDDAT ;SET ALWAYS SET BITS
3879 012346 023737 001124 001126 CMP $GDDAT, $BDDAT ;TEST
3880 012354 001404 BEQ 4$;BRANCH IF GOOD
3881 012356 013737 004132 001122 MOV RHCS3, $BDADR ;GET REGISTER ADDRESS
3882 012364 104137 ERROR 137 ;ONE WAS BEING FLOATED
3883 ;THRU RHCS3 REGISTER
3884 ;ON READING RHCS3 BACK
3885 ;IT DID NOT CONTAIN WHAT
3886 ;WAS EXPECTED.
3887 012366 000241 4$: CLC ;CLEAR CARRY
3888 012370 006305 ASL R5 ;GET 1 ONE LEFT
3889 012372 103335 BCC 1$;BRANCH IF 16 NOT DONE
3890 ;
3891 ;FLOAT A ZERO THRU RHCS3 REGISTER.
3892 ;
3893 012374 012737 012420 001110 MOV #6$, $LPERR ;SET LOOP BACK POINT.
3894 012402 012705 177776 MOV #177776, R5 ;GET READY TO FLOAT A ZERO
3895 012406 010537 001124 5$: MOV R5, $GDDAT ;GET READY TO WRITE DATA
3896 012412 042737 177660 001124 BIC #177660, $GDDAT ;CLEAR BITS NOT WRITTEN INTO
3897 012420 032737 041400 001140 6$: BIT #BIT14!BIT9!BIT8, SWR ;ARE SWITCHES 14 OR 9 OR 8 SET
3898 012426 001403 BEQ 7$;BRANCH IF ANY OF THE ABOVE SET
3899 012430 012777 000040 171432 MOV #CLR, @RHCS2 ;CLEAR FOR SCOPE AID TO
3900 ;SYNC IF IN DEBUG
3901 012436 013777 001124 171466 7$: MOV $GDDAT, @RHCS3 ;WRITE INTO RH'XA.
3902 012444 017737 171462 001126 MOV @RHCS3, $BDDAT ;READ RHCS3
3903 012452 053737 004652 001124 BIS SETBIT, $GDDAT ;SET BITS ALWAYS SET
3904 012460 043737 004654 001124 BIC CLRBIT, $GDDAT ;CLEAR BITS ALWAYS 0
3905 012466 023737 001124 001126 CMP $GDDAT, $BDDAT ;TEST
3906 012474 001404 BEQ 8$;BRANCH IF GOOD
3907 012476 013737 004132 001122 MOV RHCS3, $BDADR ;GET REGISTER ADDRESS
3908 012504 104137 ERROR 137 ;ZERO WAS BEING FLOATED
3909 ;THRU RHCS3 REGISTER
3910 ;ON READING IT BACK IT
3911 ;DID NOT CONTAIN WHAT
3912 ;WAS EXPECTED
3913 ;
3914 012506 000261 8$: SEC
3915 012510 006105 ROL R5
3916 012512 103735 BCS 5$
3917 ;
3918 ;
3919 ;*****
3920 ;*TEST 6 BIT BANG RHWC
3921 ;
3922 ;*
3923 ;* TEST LOADING AND READING OF ALL POSSIBLE BITS
3924 ;* IN RHWC REGISTER.
3925 ;* USE A PATTERN OF WALKING 1'S (1,2,4,10 ETC)
3926 ;* AND WALKING 0'S (-2,-3,-5 ETC)
3927 ;* IN THIS TEST 0 BITS WILL NOT BE WRITTEN INTO
3928 ;* AND 0 BITS WILL ALWAYS BE SET
3929 ;* IF SWITCH 14 OR 9 OR 8 ARE SET FOR DEBUGGING
3930 ;* THEN A RH CLEAR (RHCS2 BIT #5) WILL BE
;* GIVEN TO AID SCOPE SYNC'S ON THE CLEAR

```



```

3931 ;* SIGNAL.
3932
3933 :*****
3934 012514 000004 TSTB: SCOPE
3935 012516 012706 001000 MOV #STACK,SP ;RESET STACK
3936 012522 012737 000006 004656 MOV #6,#TSTNM ;SAVE TEST NUMBER
3937
3938 012530 004737 040322 JSR PC,#CLDISK ;GIVE RH INITIALIZE
3939 ;SETUP UNIT NUBER
3940 ;CLEAR RHC AND FUNCTION BITS IN RHCS1
3941
3942 012534 012737 000000 004650 MOV #0,WRTBIT ;0 ARE BITS NOT WRITTEN INTO
3943 012542 012737 000000 004652 MOV #0,SETBIT ;0 ARE BITS ALWAYS SET
3944
3945 ;FLOAT 1'S THRU THE RHC REGISTER
3946 012550 012737 012574 001110 MOV #2$,SLPERR ;SET LOOP ON ERROR ADDRESS
3947 012556 012705 000001 MOV #1,R5 ;GETTING READY TO FLOAT A ONE
3948 012562 010537 001124 1$: MOV R5,$GDDAT ;START WITH DATA
3949 012566 042737 000000 001124 BIC #0,$GDDAT ;CLEAR BITS NOT WRITTEN INTO
3950 012574 032737 041400 001140 2$: BIT #BIT14!BIT9!BIT8,SWR ;ARE SWITCHES 14 OR 9 OR 8 SET
3951 012602 001403 BEQ 3$;BRANCH IF ANY ONE SET
3952 012604 052777 000040 171256 BIS #CLR,#RHCS2 ;GIVE CLEAR FOR SCOPE
3953 ;SYNC IF IN DEBUG:
3954 012612 013777 001124 171242 3$: MOV $GDDAT,#RHWC ;WRITE RHC REGISTER
3955 012620 017737 171236 001126 MOV #RHWC,$BDDAT ;READ RHC REGISTER
3956 012626 053737 004652 001124 BIS SETBIT,$GDDAT ;SET ALWAYS SET BITS
3957 012634 023737 001124 001126 CMP $GDDAT,$BDDAT ;TEST
3958 012642 001404 BEQ 4$;BRANCH IF GOOD
3959 012644 013737 004062 001122 MOV RHC,$BADDR ;GET REGISTER ADDRESS
3960 012652 104137 ERROR 137 ;ONE WAS BEING FLOATED
3961 ;THRU RHC REGISTER
3962 ;ON READING RHC BACK
3963 ;IT DID NOT CONTAIN WHAT
3964 ;WAS EXPECTED.
3965 012654 000241 4$: CLC ;CLEAR CARRY
3966 012656 006305 ASL R5 ;GET 1 ONE LEFT
3967 012680 103340 BCC 1$;BRANCH IF 16 NOT DONE
3968
3969 ;FLOAT A ZERO THRU RHC REGISTER.
3970
3971 012662 012737 012706 001110 MOV #6$,SLPERR ;SET LOOP BACK POINT.
3972 012670 012705 177776 MOV #177776,R5 ;GET READY TO FLOAT A ZERO
3973 012674 010537 001124 5$: MOV R5,$GDDAT ;GET READY TO WRITE DATA
3974 012700 042737 000000 001124 BIC #0,$GDDAT ;CLEAR BITS NOT WRITTEN INTO
3975 012706 032737 041400 001140 6$: BIT #BIT14!BIT9!BIT8,SWR ;ARE SWITCHES 14 OR 9 OR 8 SET
3976 012714 001403 BEQ 7$;BRANCH IF ANY OF THE ABOVE SET
3977 012716 012777 000040 171144 MOV #CLR,#RHCS2 ;CLEAR FOR SCOPE AID TO
3978 ;SYNC IF IN DEBUG
3979 012724 013777 001124 171130 7$: MOV $GDDAT,#RHWC ;WRITE INTO RH'XA.
3980 012732 017737 171124 001126 MOV #RHWC,$BDDAT ;READ RHC
3981 012740 053737 004652 001124 BIS SETBIT,$GDDAT ;SET BITS ALWAYS SET
3982 012746 023737 001124 001126 CMP $GDDAT,$BDDAT ;TEST
3983 012754 001404 BEQ 8$;BRANCH IF GOOD
3984 012756 013737 004062 001122 MOV RHC,$BADDR ;GET REGISTER ADDRESS
3985 012764 104137 ERROR 137 ;ZERO WAS BEING FLOATED
3986 ;THRU RHC REGISTER

```

:ON READING IT BACK IT  
:DID NOT CONTAIN WHAT  
:WAS EXPECTED

3987  
3988  
3989  
3990  
3991 012766 000261  
3992 012770 006105  
3993 012772 103740  
3994  
3995  
3996  
3997  
3998  
3999  
4000  
4001  
4002  
4003  
4004  
4005  
4006  
4007  
4008  
4009  
4010  
4011  
4012 012774 000004  
4013 012776 012706 001000  
4014 013002 012737 000007 004656  
4015  
4016 013010 004737 040322  
4017  
4018  
4019  
4020 013014 012737 000000 004650  
4021 013022 012737 000000 004652  
4022 013030 012737 000001 004654  
4023  
4024  
4025 013036 012737 013062 001110  
4026 013044 012705 000001  
4027 013050 010537 001124 1\$:  
4028 013054 042737 000000 001124  
4029 013062 032737 041400 001140 2\$:  
4030 013070 001403  
4031 013072 052777 000040 170770  
4032  
4033 013100 013777 001124 170756 3\$:  
4034 013106 017737 170752 001126  
4035 013114 043737 004654 001124  
4036 013122 053737 004652 001124  
4037 013130 023737 001124 001126  
4038 013136 001404  
4039 013140 013737 004064 001122  
4040 013146 104137  
4041  
4042

8\$: SEC  
ROL R5  
BCS 5\$

::\*\*\*\*\*  
:TEST 7 BIT BANG RHBA

::\* TEST LOADING AND READING OF ALL POSSIBLE BITS  
:IN RHBA REGISTER.  
:USE A PATTERN OF WALKING 1'S (1,2,4,10 ETC)  
:AND WALKING 0'S (-2,-3,-5 ETC)  
:IN THIS TEST 0 BITS WILL NOT BE WRITTEN INTO  
:AND 0 BITS WILL ALWAYS BE SET  
:AND BIT00 BITS WILL ALWAYS BE CLEARED  
:IF SWITCH 14 OR 9 OR 8 ARE SET FOR DEBUGGING  
:THEN A RH CLEAR (RHCS2 BIT #5) WILL BE  
:GIVEN TO AID SCOPE SYNC'S ON THE CLEAR  
:SIGNAL.

::\*\*\*\*\*  
TST7: SCOPE

MOV #STACK,SP ;RESET STACK  
MOV #7,#TSTNM ;SAVE TEST NUMBER  
JSR PC,#CLDISK ;GIVE RH INITIALIZE  
;SETUP UNIT NUBER  
;CLEAR RHWC AND FUNCTION BITS IN RHCS1  
MOV #0,WRTBIT ;0 ARE BITS NOT WRITTEN INTO  
MOV #0,SETBIT ;0 ARE BITS ALWAYS SET  
MOV #BIT00,CLRBIT ;BIT00 ARE BITS ALWAYS CLEARED  
;FLOAT 1'S THRU THE RHBA REGISTER  
MOV #2\$, \$LPERR ;SET LOOP ON ERROR ADDRESS  
MOV #1,R5 ;GETTING READY TO FLOAT A ONE  
1\$: MOV R5,\$GDDAT ;START WITH DATA  
BIC #0,\$GDDAT ;CLEAR BITS NOT WRITTEN INTO  
2\$: BIT #BIT14!BIT9!BIT8,SWR ;ARE SWITCHES 14 OR 9 OR 8 SET  
BEQ 3\$ ;BRANCH IF ANY ONE SET  
BIS #CLR,#RHCS2 ;GIVE CLEAR FOR SCOPE  
;SYNC IF IN DEBUG:  
3\$: MOV \$GDDAT,#RHBA ;WRITE RHBA REGISTER  
MOV #RHBA,\$BDDAT ;READ RHBA REGISTER  
BIC CLRBIT,\$GDDAT ;CLEAR ALWAYS CLEARED BITS  
BIS SETBIT,\$GDDAT ;SET ALWAYS SET BITS  
CMP \$GDDAT,\$BDDAT ;TEST  
BEQ 4\$ ;BRANCH IF GOOD  
MOV RHBA,\$BDDADR ;GET REGISTER ADDRESS  
4\$: ERROR 137 ;ONE WAS BEING FLOATED  
;THRU RHBA REGISTER  
;ON READING RHBA BACK



```

4099 ;CLEAR RHWC AND FUNCTION BITS IN RHCS1
4100
4101 013316 012737 177700 004650 MOV #177700,WRTBIT ;177700 ARE BITS NOT WRITTEN INTO
4102 013324 012737 000000 004652 MOV #0,SETBIT ;0 ARE BITS ALWAYS SET
4103 013332 012737 177700 004654 MOV #177700,CLRBIT ;177700 ARE BITS ALWAYS CLEARED
4104
4105 ;FLOAT 1'S THRU THE RHBAE REGISTER
4106 013340 012737 013364 001110 MOV #2$,SLPERR ;SET LOOP ON ERROR ADDRESS
4107 013346 012705 000001 MOV #1,R5 ;GETTING READY TO FLOAT A ONE
4108 013352 010537 001124 MOV R5,$GDDAT ;START WITH DATA
4109 013356 042737 177700 001124 BIC #177700,$GDDAT ;CLEAR BITS NOT WRITTEN INTO
4110 013364 032737 041400 001140 BIT #BIT14!BIT9!BIT8,SWR ;ARE SWITCHES 14 OR 9 OR 8 SET
4111 013372 001403 BEQ 3$;BRANCH IF ANY ONE SET
4112 013374 052777 000040 170466 BIS #CLR,$RHCS2 ;GIVE CLEAR FOR SCOPE
4113 ;SYNC IF IN DEBUG:
4114 013402 013777 001124 170520 MOV $GDDAT,$RHBAE ;WRITE RHBAE REGISTER
4115 013410 017737 170514 001126 MOV $RHBAE,$BDDAT ;READ RHBAE REGISTER
4116 013416 043737 004654 001124 BIC CLRBIT,$GDDAT ;CLEAR ALWAYS CLEARED BITS
4117 013424 053737 004652 001124 BIS SETBIT,$GDDAT ;SET ALWAYS SET BITS
4118 013432 023737 001124 001126 CMP $GDDAT,$BDDAT ;TEST
4119 013440 001404 BEQ 4$;BRANCH IF GOOD
4120 013442 013737 004130 001122 MOV RHBAE,$BDADR ;GET REGISTER ADDRESS
4121 013450 104137 ERROR 137 ;ONE WAS BEING FLOATED
4122 ;THRU RHBAE REGISTER
4123 ;ON READING RHBAE BACK
4124 ;IT DID NOT CONTAIN WHAT
4125 ;WAS EXPECTED.
4126 013452 000241 CLC ;CLEAR CARRY
4127 013454 006305 ASL R5 ;GET 1 ONE LEFT
4128 013456 103335 BCC 1$;BRANCH IF 16 NOT DONE
4129
4130 ;FLOAT A ZERO THRU RHBAE REGISTER.
4131
4132 013460 012737 013504 001110 MOV #6$,SLPERR ;SET LOOP BACK POINT.
4133 013466 012705 177776 MOV #177776,R5 ;GET READY TO FLOAT A ZERO
4134 013472 010537 001124 MOV R5,$GDDAT ;GET READY TO WRITE DATA
4135 013476 042737 177700 001124 BIC #177700,$GDDAT ;CLEAR BITS NOT WRITTEN INTO
4136 013504 032737 041400 001140 BIT #BIT14!BIT9!BIT8,SWR ;ARE SWITCHES 14 OR 9 OR 8 SET
4137 013512 001403 BEQ 7$;BRANCH IF ANY OF THE ABOVE SET
4138 013514 012777 000040 170346 MOV #CLR,$RHCS2 ;CLEAR FOR SCOPE AID TO
4139 ;SYNC IF IN DEBUG
4140 013522 013777 001124 170400 MOV $GDDAT,$RHBAE ;WRITE INTO RH'XA.
4141 013530 017737 170374 001126 MOV $RHBAE,$BDDAT ;READ RHBAE
4142 013536 053737 004652 001124 BIS SETBIT,$GDDAT ;SET BITS ALWAYS SET
4143 013544 043737 004654 001124 BIC CLRBIT,$GDDAT ;CLEAR BITS ALWAYS 0
4144 013552 023737 001124 001126 CMP $GDDAT,$BDDAT ;TEST
4145 013560 001404 BEQ 8$;BRANCH IF GOOD
4146 013562 013737 004130 001122 MOV RHBAE,$BDADR ;GET REGISTER ADDRESS
4147 013570 104137 ERROR 137 ;ZERO WAS BEING FLOATED
4148 ;THRU RHBAE REGISTER
4149 ;ON READING IT BACK IT
4150 ;DID NOT CONTAIN WHAT
4151 ;WAS EXPECTED
4152
4153 013572 000261 SEC ;
4154 013574 006105 ROL R5

```

4155 013576 103735  
 4156  
 4157  
 4158  
 4159  
 4160  
 4161  
 4162  
 4163  
 4164  
 4165  
 4166  
 4167  
 4168  
 4169  
 4170  
 4171  
 4172  
 4173  
 4174  
 4175  
 4176  
 4177  
 4178 013600 000004  
 4179 013602 012706 001000  
 4180 013606 012737 000011 004656  
 4181  
 4182 013614 004737 040322  
 4183  
 4184  
 4185  
 4186  
 4187 013620 012737 000100 001124  
 4188 013626 053737 005010 001124  
 4189  
 4190 013634 017737 170230 001126  
 4191 013642 023737 001124 001126  
 4192  
 4193  
 4194 013650 001401  
 4195 013652 104006  
 4196  
 4197  
 4198  
 4199  
 4200  
 4201  
 4202  
 4203  
 4204 013654  
 4205  
 4206  
 4207 013654 005077 170222  
 4208  
 4209  
 4210 013660 104411

BCS 5\$

```

*TEST 11 SILO TEST 1 (ONE WORD WRITE)
* AFTER A RH CLEAR IS GIVEN (SET BIT #5 IN RHCS2)
* RHCS2 IS CHECKED TO HAVE "IR" (BIT #6) HIGH
* TOGETHER WITH UNIT NUMBER
* ONE WORD OF ALL ZEROS IS WRITTEN INTO RHDB
* BY "CLR"
* "OR" (BIT #7) IS WAITED FOR BY A TRAP INSTRUCTION
* CALLED "WAT" (NO TIMING IS DONE)
* HOWEVER IF "OR" DOES NOT SET WITHIN "WAT" COUNT
* DOWN AN ERROR IS REPORTED
* RHDB IS READ AND CHECKED TO CONTAIN ZEROS
* RHCS2 WILL BE CHECKED TO HAVE "IR" AND UNIT NUMBER
* RHCS1, RHCS3, RHBA, RHBAE, RHWC, WILL BE CHECKED TO HAVE
* APPROPRIATE VALUES

```

```

†ST11: SCOPE
MOV #STACK, SP ;RESET STACK
MOV #11, @#TSTNM ;SAVE TEST NUMBER
JSR PC, @#CLDISK ;GIVE RH INITIALIZE
 ;SETUP UNIT NUMBER
 ;CLEAR RHWC AND FUNCTION BITS IN RHCS1
;CHECK THAT RHCS2 HAS IR
MOV #IR, $GDDAT ;GET GOOD = 100
BIS UNIT, $GDDAT ;INCLUDE UNIT NUMBER
MOV @RHCS2, $BDDAT ;READ RHCS2 FOR COMPARISON
CMP $GDDAT, $BDDAT ;COMPARE EXPECTED
 ;DATA WITH DATA READ FROM
 ;RHCS2
BEQ 65$;BRANCH IF GOOD
ERROR 6
 ;AFTER SETTING CLR BIT #5
 ;IN RHCS2 TO INIT THE RH
 ;AND HAVING DONE NOTHING ELSE
 ;RHCS2 SHOULD HAVE IR
 ;=100
 ;TOGETHER WITH UNIT NUMBER
 ;BUT CONTAINED WHAT IS
 ;GIVEN IN BAD RHCS2
65$:
;WRITE ONE WORD OF ALL ZEROS INTO RHDB
CLR @RHDB ;WRITE 0 IN RHDB
;WAIT FOR OR BIT IN RHCS2 REGISTER TO SET
WAT
;TRAP TO WAIT.T SUBROUTINE

```

```

4211 013662 004070 RHCS2
4212 013664 000200 OR
4213
4214
4215
4216
4217
4218
4219
4220
4221
4222 013666 012737 000000 001124 ;CHECK THAT RHDB HAS 0
 MOV #0,$GDDAT ;GET GOOD =
4223
4224 013674 017737 170202 001126 MOV @RHDB,$BDDAT ;READ RHDB FOR COMPARISON
4225 013702 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
4226
4227
4228 013710 001401 BEQ 67$;DATA WITH DATA READ FROM
4229 013712 104007 ERROR 7 ;RHDB
4230
4231
4232
4233
4234
4235
4236
4237
4238 013714
4239
4240 013714 012737 000100 001124 ;CHECK THAT RHCS2 HAS IR
 MOV #IR,$GDDAT ;GET GOOD = 100
4241 013722 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
4242
4243 013730 017737 170134 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
4244 013736 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
4245
4246
4247 013744 001401 BEQ 69$;DATA WITH DATA READ FROM
4248 013746 104010 ERROR 10 ;RHCS2
4249
4250
4251
4252
4253
4254
4255
4256
4257
4258 013750
4259
4260 013750 012737 004200 001124 ;CHECK THAT RHCS1 HAS DVA:RDY
 MOV #DVA:RDY,$GDDAT ;GET GOOD = 4200
4261
4262 013756 017737 170076 001126 MOV @RHCS1,$BDDAT ;READ RHCS1 FOR COMPARISON
4263 013764 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
4264
4265
4266 013772 001401 BEQ 71$;DATA WITH DATA READ FROM
 ;RHCS1
 ;BRANCH IF GOOD

```

```

;AND WAIT FOR OR BIT IN
;RHCS2 REGISTER
;IF ERROR OCCURS HERE
;IT MEANS "OR" DID NOT
;SET FOR THE FULL COUNT
;DOWN OF THE WAIT.T SUBROUTINE
;THIS TIME IS APPROXIMATELY
;LARGER THAN 500 MILLISECONDS

```

```

;CHECK THAT RHDB HAS 0
;GET GOOD =
;READ RHDB FOR COMPARISON
;COMPARE EXPECTED
;DATA WITH DATA READ FROM
;RHDB
;BRANCH IF GOOD
;AFTER CLEARING THE RH
;AND WRITING ALL ZEROS
;INTO RHDB
;THEN READING IT BACK
;RHDB SHOULD HAVE 0
;=
;BUT CONTAINED WHAT IS
;GIVEN IN BAD RHDB

```

```

67$:
;CHECK THAT RHCS2 HAS IR
;GET GOOD = 100
;INCLUDE UNIT NUMBER
;READ RHCS2 FOR COMPARISON
;COMPARE EXPECTED
;DATA WITH DATA READ FROM
;RHCS2
;BRANCH IF GOOD
;AFTER CLEARING THE RH
;AND WRITING ALL ZEROS
;INTO RHDB
;THEN READING IT BACK
;RHCS2 SHOULD HAVE IR
;=100
;TOGETHER WITH UNIT NUMBER
;BUT CONTAINED WHAT IS
;GIVEN IN BAD RHCS2

```

```

69$:
;CHECK THAT RHCS1 HAS DVA:RDY
;GET GOOD = 4200
;READ RHCS1 FOR COMPARISON
;COMPARE EXPECTED
;DATA WITH DATA READ FROM
;RHCS1
;BRANCH IF GOOD

```



```

4323 ; INTO RHDB
4324 ; THEN READING IT BACK
4325 ; RHBAE SHOULD HAVE 0
4326 ; =
4327 ; BUT CONTAINED WHAT IS
4328 ; GIVEN IN BAD RHBAE
4329 014100 77$:
4330 ; CHECK THAT RHWC HAS 0
4331 014100 012737 000000 001124 MOV #0,$GDDAT ; GET GOOD =
4332
4333 014106 017737 167750 001126 MOV @RHWC,$BDDAT ; READ RHWC FOR COMPARISON
4334 014114 023737 001124 001126 CMP $GDDAT,$BDDAT ; COMPARE EXPECTED
4335 ; DATA WITH DATA READ FROM
4336 ; RHWC
4337 014122 001401 BEQ 79$; BRANCH IF GOOD
4338 014124 104015 ERROR 15
4339 ; AFTER CLEARING THE RH
4340 ; AND WRITING ALL ZEROS
4341 ; INTO RHDB
4342 ; THEN READING IT BACK
4343 ; RHWC SHOULD HAVE 0
4344 ; =
4345 ; BUT CONTAINED WHAT IS
4346 ; GIVEN IN BAD RHWC
4347 014126 79$:
4348
4349
4350
4351
4352
4353
4354
4355
4356
4357
4358
4359
4360
4361
4362
4363
4364
4365
4366
4367 014126 000004
4368 014130 012706 001000
4369 014134 012737 000012 004656
4370
4371 014142 004737 040322
4372
4373
4374
4375
4376
4377 014146 012737 000100 001124
4378 014154 053737 005010 001124

```

\*\*\*\*\*  
\*TEST 12 SILO TEST 2 (ONE WORD WRITE)  
\* AFTER A RH CLEAR IS GIVEN (SET BIT #5 IN RHCS2)  
\* RHCS2 IS CHECKED TO HAVE "IR" (BIT #6) HIGH  
\* TOGETHER WITH UNIT NUMBER  
\* ONE WORD OF ALL ONES IS WRITTEN INTO RHDB  
\* BY "CLR"  
\* "OR" (BIT #7) IS WAITED FOR BY A TRAP INSTRUCTION  
\* CALLED "WAT" (NO TIMING IS DONE)  
\* HOWEVER IF "OR" DOES NOT SET WITHIN "WAT" COUNT  
\* DOWN AN ERROR IS REPORTED  
\* RHDB IS READ AND CHECKED TO CONTAIN ALL ONES  
\* RHCS2 WILL BE CHECKED TO HAVE "IR" AND UNIT NUMBER  
\* RHCS1,RHCS3,RHBA,RHBAE,RHWC, WILL BE CHECKED TO HAVE  
\* APPROPRIATE VALUES  
\*\*\*\*\*  
†ST12: SCOPE  
MOV #STACK.SP ; RESET STACK  
MOV #12,@†STNM ; SAVE TEST NUMBER  
JSR PC,@CLDISK ; GIVE RH INITIALIZE  
; SETUP UNIT NUBER  
; CLEAR RHWC AND FUNCTION BITS IN RHCS1  
; CHECK THAT RHCS2 HAS IR  
MOV #IR,\$GDDAT ; GET GOOD = 100  
BIS UNIT,\$GDDAT ; INCLUDE UNIT NUMBER





```

4435
4436 014274 001401
4437 014276 104010
4438
4439
4440
4441
4442
4443
4444
4445
4446
4447 014300
4448
4449 014300 012737 000000 001124
4450
4451 014306 017737 167620 001126
4452 014314 023737 001124 001126
4453
4454
4455 014322 001401
4456 014324 104012
4457
4458
4459
4460
4461
4462
4463
4464
4465 014326
4466
4467 014326 012737 000000 001124
4468
4469 014334 017737 167524 001126
4470 014342 023737 001124 001126
4471
4472
4473 014350 001401
4474 014352 104013
4475
4476
4477
4478
4479
4480
4481
4482
4483 014354
4484
4485 014354 012737 000000 001124
4486
4487 014362 017737 167542 001126
4488 014370 023737 001124 001126
4489
4490

```

BEQ 69\$  
 ERROR 10

69\$:  
 ;CHECK THAT RHCS3 HAS 0  
 MOV #0,\$GDDAT ;GET GOOD =  
 MOV @RHCS3,\$BDDAT ;READ RHCS3 FOR COMPARISON  
 CMP \$GDDAT,\$BDDAT ;COMPARE EXPECTED  
 ;DATA WITH DATA READ FROM  
 ;RHCS3  
 ;BRANCH IF GOOD

BEQ 71\$  
 ERROR 12

71\$:  
 ;CHECK THAT RHBA HAS 0  
 MOV #0,\$GDDAT ;GET GOOD =  
 MOV @RHBA,\$BDDAT ;READ RHBA FOR COMPARISON  
 CMP \$GDDAT,\$BDDAT ;COMPARE EXPECTED  
 ;DATA WITH DATA READ FROM  
 ;RHBA  
 ;BRANCH IF GOOD

BEQ 73\$  
 ERROR 13

73\$:  
 ;CHECK THAT RHBAE HAS 0  
 MOV #0,\$GDDAT ;GET GOOD =  
 MOV @RHBAE,\$BDDAT ;READ RHBAE FOR COMPARISON  
 CMP \$GDDAT,\$BDDAT ;COMPARE EXPECTED  
 ;DATA WITH DATA READ FROM  
 ;RHBAE

;RHCS2  
 ;BRANCH IF GOOD  
 ;AFTER CLEARING THE RH  
 ;AND WRITING ALL ONES  
 ;INTO RHDB  
 ;THEN READING IT BACK  
 ;RHCS2 SHOULD HAVE IR  
 ;=100  
 ;TOGETHER WITH UNIT NUMBER  
 ;BUT CONTAINED WHAT IS  
 ;GIVEN IN BAD RHCS2

;AFTER CLEARING THE RH  
 ;AND WRITING ALL ONES  
 ;INTO RHDB  
 ;THEN READING IT BACK  
 ;RHCS3 SHOULD HAVE 0  
 ;=  
 ;BUT CONTAINED WHAT IS  
 ;GIVEN IN BAD RHCS3

;AFTER CLEARING THE RH  
 ;AND WRITING ALL ONES  
 ;INTO RHDB  
 ;THEN READING IT BACK  
 ;RHBA SHOULD HAVE 0  
 ;=  
 ;BUT CONTAINED WHAT IS  
 ;GIVEN IN BAD RHBA

```

4491 014376 001401 BEQ 75$;BRANCH IF GOOD
4492 014400 104014 ERROR 14 ;
4493 ;AFTER CLEARING THE RH
4494 ;AND WRITING ALL ONES
4495 ;INTO RHDB
4496 ;THEN READING IT BACK
4497 ;RHBAE SHOULD HAVE 0
4498 ;=
4499 ;BUT CONTAINED WHAT IS
4500 ;GIVEN IN BAD RHBAE
4501 014402 75$:
4502 ;CHECK THAT RHWC HAS 0
4503 014402 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD =
4504 ;
4505 014410 017737 167446 001126 MOV @RHWC,$BDDAT ;READ RHWC FOR COMPARISON
4506 014416 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
4507 ;DATA WITH DATA READ FROM
4508 ;RHWC
4509 014424 001401 BEQ 77$;BRANCH IF GOOD
4510 014426 104015 ERROR 15 ;
4511 ;AFTER CLEARING THE RH
4512 ;AND WRITING ALL ONES
4513 ;INTO RHDB
4514 ;THEN READING IT BACK
4515 ;RHWC SHOULD HAVE 0
4516 ;=
4517 ;BUT CONTAINED WHAT IS
4518 ;GIVEN IN BAD RHWC

```

```

4519 014430 77$:
4520
4521
4522
4523
4524
4525
4526
4527
4528
4529
4530
4531
4532
4533
4534
4535
4536
4537
4538
4539
4540
4541
4542

```

```

;*TEST 13 SILO TEST 3 (TWO WORD WRITE)

;*
;* AFTER A RH CLEAR IS GIVEN (SET BIT #5 IN RHCS2)
;* RHCS2 IS CHECKED TO HAVE "IR" (BIT #6) HIGH,
;* TOGETHER WITH UNIT NUMBER
;* ONE WORD = 52525 IS WRITTEN INTO RHDB
;* RHCS2 IS CHECKED TO HAVE "IR" AND UNIT NUMBER
;* A SECOND WORD = 12525 IS WRITTEN INTO RHDB
;* "OR" (BIT #7 IN RHCS2) IS WAITED FOR BY A TRAP
;* INSTRUCTION CALLED "WAT"
;* RHDB IS READ AND CHECKED TO CONTAIN 52525
;* RHCS2 IS CHECKED TO HAVE "IR", "OR" AND UNIT NUMBER
;* RHDB IS READ A SECOND TIME AND CHECKED TO
;* CONTAIN 125252
;* RHCS2 IS CHECKED TO HAVE "IR" AND UNIT NUMBER
;* THEN ALL REGISTERS RHCS1, RHCS3, RHB, RHBAE, RHWC
;* ARE CHECKED TO HAVE APPROPRIATE VALUE

```

```

4543 014430 000004 TST13: SCOPE
4544 014432 012706 001000 MOV #STACK,SP ;RESET STACK
4545 014436 012737 000013 004656 MOV #13,@#TSTNM ;SAVE TEST NUMBER
4546

```

```

4547 014444 004737 040322 JSR PC, @#CLDISK ;GIVE RH INITIALIZE
4548 ;SETUP UNIT NUBER
4549 ;CLEAR RHWC AND FUNCTION BITS IN RHCS1
4550
4551 ;CHECK THAT RHCS2 HAS IR
4552 014450 012737 000100 001124 MOV #IR, $GDDAT ;GET GOOD = 100
4553 014456 053737 005010 001124 BIS UNIT, $GDDAT ;INCLUDE UNIT NUMBER
4554
4555 014464 017737 167400 001126 MOV @RHCS2, $BDDAT ;READ RHCS2 FOR COMPARISON
4556 014472 023737 001124 001126 CMP $GDDAT, $BDDAT ;COMPARE EXPECTED
4557 ;DATA WITH DATA READ FROM
4558 ;RHCS2
4559 014500 001401 BEQ 65$;BRANCH IF GOOD
4560 014502 104006 ERROR 6
4561 ;AFTER SETTING "CLR" BIT #5
4562 ;IN RHCS2 TO INIT THE RH
4563 ;AND HAVING DONE NOTHING ELSE
4564
4565 ;RHCS2 SHOULD HAVE IR
4566 ;=100
4567 ;TOGETHER WITH UNIT NUMBER
4568 ;BUT CONTAINED WHAT IS
4569 ;GIVEN IN BAD RHCS2
4570 014504 65$:
4571
4572 ;WRITE ONE WORD = 52525 INTO RHDB
4573 014504 012777 052525 167370 MOV #52525, @RHDB ;WRITE IN RHDB
4574
4575 ;WAIT FOR OR BIT IN RHCS2 REGISTER TO SET
4576 014512 104411 WAT ;TRAP TO WAIT.T SUBROUTINE
4577 014514 004070 RHCS2 ;AND WAIT FOR OR BIT IN
4578 014516 000200 OR ;RHCS2 REGISTER
4579 ;IF ERROR OCCURS HERE
4580 ;IT MEANS "OR" DID NOT
4581 ;SET FOR THE FULL COUNT
4582 ;DOWN OF THE WAIT.T SUBROUTINE
4583 ;THIS TIME IS APPROXIMATELY
4584 ;LARGER THAN 500 MILLISECONDS
4585
4586
4587 ;CHECK THAT RHCS2 HAS IR!OR
4588 014520 012737 000300 001124 MOV #IR!OR, $GDDAT ;GET GOOD = 300
4589 014526 053737 005010 001124 BIS UNIT, $GDDAT ;INCLUDE UNIT NUMBER
4590
4591 014534 017737 167330 001126 MOV @RHCS2, $BDDAT ;READ RHCS2 FOR COMPARISON
4592 014542 023737 001124 001126 CMP $GDDAT, $BDDAT ;COMPARE EXPECTED
4593 ;DATA WITH DATA READ FROM
4594 ;RHCS2
4595 014550 001401 BEQ 67$;BRANCH IF GOOD
4596 014552 104016 ERROR 16
4597 ;AFTER SETTING "CLR" BIT #5
4598 ;IN RHCS2 TO INIT THE RH
4599 ;THEN WRITING 52525 INTO
4600 ;RHDB
4601 ;RHCS2 SHOULD HAVE IR!OR
4602 ;=300

```

```

4603 ; TOGETHER WITH UNIT NUMBER
4604 ; BUT CONTAINED WHAT IS
4605 ; GIVEN IN BAD RHCS2
4606 014554 67$:
4607
4608 ; WRITE A SECOND WORD = 125252 INTO RHDB
4609 014554 012777 125252 167320 MOV #125252, @RHDB ; WRITE 125252 INTO RHDB
4610
4611 ; WAIT FOR OR BIT IN RHCS2 REGISTER TO SET
4612 014562 104411 WAT ; TRAP TO WAIT.T SUBROUTINE
4613 014564 004070 RHCS2 ; AND WAIT FOR OR BIT IN
4614 014566 000200 OR ; RHCS2 REGISTER
4615 ; IF ERROR OCCURS HERE
4616 ; IT MEANS "OR" DID NOT
4617 ; SET FOR THE FULL COUNT
4618 ; DOWN OF THE WAIT.T SUBROUTINE
4619 ; THIS TIME IS APPROXIMATELY
4620 ; LARGER THAN 500 MILLISECONDS
4621
4622 ; CHECK THAT RHDB HAS 52525
4623 014570 012737 052525 001124 MOV #52525, $GDDAT ; GET GOOD = 0
4624
4625 014576 017737 167300 001126 MOV @RHDB, $BDDAT ; READ RHDB FOR COMPARISON
4626 014604 023737 001124 001126 CMP $GDDAT, $BDDAT ; COMPARE EXPECTED
4627 ; DATA WITH DATA READ FROM
4628 ; RHDB
4629 014612 001401 BEQ 69$; BRANCH IF GOOD
4630 014614 104017
4631
4632 ; AFTER CLEARING THE RH THEN
4633 ; WRITING TWO WORDS INTO
4634 ; RHDB 52525 ND 125252
4635 ; THEN READING RHDB ONCE
4636 ; RHDB SHOULD HAVE 52525
4637 ; BUT CONTAINED WHAT IS
4638 ; GIVEN IN BAD RHDB
4638 014616 69$:
4639
4640 014616 012737 000300 001124 MOV #IR!OR, $GDDAT ; GET GOOD = 300
4641 014624 053737 005010 001124 BIS UNIT, $GDDAT ; INCLUDE UNIT NUMBER
4642
4643 014632 017737 167232 001126 MOV @RHCS2, $BDDAT ; READ RHCS2 FOR COMPARISON
4644 014640 023737 001124 001126 CMP $GDDAT, $BDDAT ; COMPARE EXPECTED
4645 ; DATA WITH DATA READ FROM
4646 ; RHCS2
4647 014646 001401 BEQ 71$; BRANCH IF GOOD
4648 014650 104020
4649
4650 ; AFTER CLEARING THE RH THEN
4651 ; WRITING TWO WORDS INTO
4652 ; RHDB 52525 ND 125252
4653 ; THEN READING RHDB ONCE
4654 ; RHCS2 SHOULD HAVE IR!OR
4655 ; =300
4656 ; TOGETHER WITH UNIT NUMBER
4657 ; BUT CONTAINED WHAT IS
4658 014652 71$:

```

```

4659
4660
4661
4662
4663 014652 012737 125252 001124
4664
4665 014660 017737 167216 001126
4666 014666 023737 001124 001126
4667
4668
4669 014674 001401
4670 014676 104021
4671
4672
4673
4674
4675
4676
4677
4678
4679 014700
4680
4681 014700 012737 000100 001124
4682 014706 053737 005010 001124
4683
4684 014714 017737 167150 001126
4685 014722 023737 001124 001126
4686
4687
4688 014730 001401
4689 014732 104022
4690
4691
4692
4693
4694
4695
4696
4697
4698
4699
4700 014734
4701
4702 014734 012737 004200 001124
4703
4704 014742 017737 167112 001126
4705 014750 023737 001124 001126
4706
4707
4708 014756 001401
4709 014760 104141
4710
4711
4712
4713
4714

```

;READ RHDB A SECOND TIME  
;CHECK THAT RHDB HAS 125252  
MOV #125252,\$GDDAT ;GET GOOD = 0  
MOV @RHDB,\$BDDAT ;READ RHDB FOR COMPARISON  
CMP \$GDDAT,\$BDDAT ;COMPARE EXPECTED  
;DATA WITH DATA READ FROM  
;RHDB  
BEQ 73\$ ;BRANCH IF GOOD  
ERROR 21  
;AFTER CLEARING RH THEN  
;WRITING TWO WORDS INTO  
;RHDB 52525 AND 125252  
;THEN READING RHDB THE  
;SECOND TIME  
;RHDB SHOULD HAVE 125252  
;BUT CONTAINED WHAT IS  
;GIVEN IN BAD RHDB  
73\$:  
;CHECK THAT RHCS2 HAS IR  
MOV #IR,\$GDDAT ;GET GOOD = 100  
BIS UNIT,\$GDDAT ;INCLUDE UNIT NUMBER  
MOV @RHCS2,\$BDDAT ;READ RHCS2 FOR COMPARISON  
CMP \$GDDAT,\$BDDAT ;COMPARE EXPECTED  
;DATA WITH DATA READ FROM  
;RHCS2  
BEQ 75\$ ;BRANCH IF GOOD  
ERROR 22  
;AFTER CLEARING RH THEN  
;WRITING TWO WORDS INTO  
;RHDB 52525 AND 125252  
;THEN READING RHDB THE  
;SECOND TIME  
;RHCS2 SHOULD HAVE IR  
;=100  
;TOGETHER WITH UNIT NUMBER  
;BUT CONTAINED WHAT IS  
;GIVEN IN BAD RHCS2  
75\$:  
;CHECK THAT RHCS1 HAS DVA!RDY  
MOV #DVA!RDY,\$GDDAT ;GET GOOD = 4200  
MOV @RHCS1,\$BDDAT ;READ RHCS1 FOR COMPARISON  
CMP \$GDDAT,\$BDDAT ;COMPARE EXPECTED  
;DATA WITH DATA READ FROM  
;RHCS1  
BEQ 77\$ ;BRANCH IF GOOD  
ERROR 141  
;AFTER CLEARING RH THEN  
;WRITING TWO WORDS INTO  
;RHDB 52525 AND 125252  
;THEN READING RHDB THE  
;SECOND TIME

```
4715 ;RHCS1 SHOULD HAVE DVA:RDY
4716 ;=4200
4717 ;BUT CONTAINED WHAT IS
4718 ;GIVEN IN BAD RHCS1
4719 014762 77$:
4720 ;CHECK THAT RHCS3 HAS 0
4721 014762 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
4722
4723 014770 017737 167136 001126 MOV @RHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON
4724 014776 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
4725 ;DATA WITH DATA READ FROM
4726 ;RHCS3
4727 015004 001401 BEQ 79$;BRANCH IF GOOD
4728 015006 104142 ERROR 142
4729 ;AFTER CLEARING RH THEN
4730 ;WRITING TWO WORDS INTO
4731 ;RHDB 52525 AND 125252
4732 ;THEN READING RHDB THE
4733 ;SECOND TIME
4734 ;RHCS3 SHOULD HAVE 0
4735 ;BUT CONTAINED WHAT IS
4736 ;GIVEN IN BAD RHCS3
4737 015010 79$:
4738 ;CHECK THAT RHBA HAS 0
4739 015010 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
4740
4741 015016 017737 167042 001126 MOV @RHBA,$BDDAT ;READ RHBA FOR COMPARISON
4742 015024 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
4743 ;DATA WITH DATA READ FROM
4744 ;RHBA
4745 015032 001401 BEQ 81$;BRANCH IF GOOD
4746 015034 104143 ERROR 143
4747 ;AFTER CLEARING RH THEN
4748 ;WRITING TWO WORDS INTO
4749 ;RHDB 52525 AND 125252
4750 ;THEN READING RHDB THE
4751 ;SECOND TIME
4752 ;RHBA SHOULD HAVE 0
4753 ;BUT CONTAINED WHAT IS
4754 ;GIVEN IN BAD RHBA
4755 015036 81$:
4756 ;CHECK THAT RHBAE HAS 0
4757 015036 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
4758
4759 015044 017737 167060 001126 MOV @RHBAE,$BDDAT ;READ RHBAE FOR COMPARISON
4760 015052 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
4761 ;DATA WITH DATA READ FROM
4762 ;RHBAE
4763 015060 001401 BEQ 83$;BRANCH IF GOOD
4764 015062 104144 ERROR 144
4765 ;AFTER CLEARING RH THEN
4766 ;WRITING TWO WORDS INTO
4767 ;RHDB 52525 AND 125252
4768 ;THEN READING RHDB THE
4769 ;SECOND TIME
4770 ;RHBAE SHOULD HAVE 0
```

```

4771 ;BUT CONTAINED WHAT IS
4772 ;GIVEN IN BAD RHBAE
4773 015064 83$:
4774 ;CHECK THAT RHWC HAS 0
4775 015064 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
4776
4777 015072 017737 166764 001126 MOV @RHWC,$BDDAT ;READ RHWC FOR COMPARISON
4778 015100 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
4779 ;DATA WITH DATA READ FROM
4780 ;RHWC
4781 015106 001401 BEQ 85$;BRANCH IF GOOD
4782 015110 104145
4783
4784 ;AFTER CLEARING RH THEN
4785 ;WRITING TWO WORDS INTO
4786 ;RHDB 52525 AND 125252
4787 ;THEN READING RHDB THE
4788 ;SECOND TIME
4789 ;RHWC SHOULD HAVE 0
4790 ;BUT CONTAINED WHAT IS
4791 015112 85$:
4792 ;GIVEN IN BAD RHWC
4793
4794 ;*****
4795 ;*TEST 14 SILO TEST 4 (COUNT PATTERN)
4796 ;*****
4797 ;*
4798 ;* AFTER A RH CLEAR IS GIVEN (SET BIT #5 IN RHCS2)
4799 ;* RHCS2 IS CHECKED TO HAVE "IR" (BIT #6) HIGH, TOGETHER
4800 ;* WITH UNIT NUMBER
4801 ;* EIGHT WORDS, A COUNT PATTERN 0 THRU 7 IS WRITTEN
4802 ;* INTO RHDB
4803 ;* "OR" (BIT #7 IN RHCS2) IS WAITED FOR BY A TRAP
4804 ;* INSTRUCTION CALLED "WAT"
4805 ;* THEN RHCS2 IS CHECKED TO HAVE "IR" LOW AND
4806 ;* "OR" HIGH TOGETHER WITH THE UNIT NUMBER
4807 ;* THEN RHBIS READ AND COMPARED TO HAVE THE RIGHT VALUE
4808 ;* EIGHT TIES
4809 ;* THEN RHCS2, RHCS1, RHCS3, RHBA, RHBAE, RHWC ARE
4810 ;* CHECKED TO HAVE THE APPROPRIATE VALUE
4811 ;*****
4812 015112 000004 †ST14: SCOPE
4813 015114 012706 001000 MOV #STACK,SP ;RESET STACK
4814 015120 012737 000014 004656 MOV #14,@#TSTNM ;SAVE TEST NUMBER
4815
4816 015126 004737 040322 JSR PC,@#CLDISK ;GIVE RH INITIALIZE
4817 ;SETUP UNIT NUBER
4818 ;CLEAR RHWC AND FUNCTION BITS IN RHCS1
4819
4820 ;CHECK THAT RHCS2 HAS IR
4821 015132 012737 000100 001124 MOV #IR,$GDDAT ;GET GOOD = 100
4822 015140 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
4823
4824 015146 017737 166716 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
4825 015154 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
4826 ;DATA WITH DATA READ FROM
4827 ;RHCS2

```



```

4827 015162 001401 BEQ 65$;BRANCH IF GOOD
4828 015164 104006 ERROR 6
4829
4830
4831
4832
4833
4834
4835
4836
4837 015166 65$:
4838
4839
4840
4841 015166 012702 000010 MOV #8.,R2 ; 8 NUMBERS TO BE WRITTEN
4842 015172 005001 CLR R1 ; FIRST WORD TO BE WRITTEN = 0
4843 015174 010177 166702 1$: MOV R1, @RHDB ; WRITE INTO RHDB - A COUNT
4844 015200 005201 INC R1 ; GET NEXT WORD
4845 015202 005302 DEC R2 ; COUNT TO 8
4846 015204 001373 BNE 1$; BRANCH IF 8 NOT DONE
4847
4848
4849 015206 104411 ;WAIT FOR OR BIT IN RHCS2 REGISTER TO SET
4850 015210 004070 WAT
4851 015212 000200 RHCS2
4852
4853
4854
4855
4856
4857
4858
4859
4860 015214 012737 000200 001124 ;CHECK THAT RHCS2 HAS OR
4861 015222 053737 005010 001124 MOV #OR,$GDDAT ; GET GOOD = 200
4862
4863 015230 017737 166634 001126 BIS UNIT,$GDDAT ; INCLUDE UNIT NUMBER
4864 015236 023737 001124 001126 MOV @RHCS2,$BDDAT ; READ RHCS2 FOR COMPARISON
4865
4866
4867 015244 001401 CMP $GDDAT,$BDDAT ; COMPARE EXPECTED
4868 015246 104023 ; DATA WITH DATA READ FROM
4869
4870
4871
4872
4873
4874
4875
4876
4877
4878
4879 015250 67$:
4880
4881
4882

```

```

;AFTER SETTING "CLR" BIT #5
;IN RHCS2 TO INIT THE RH
;AND HAVING DONE NOTHING ELSE
;RHCS2 SHOULD HAVE IR
;=100
;TOGETHER WITH UNIT NUMBER
;BUT CONTAINED WHAT IS
;GIVEN IN BAD RHCS2

```

```

;WRITE EIGHT WORDS INTO RHDB TO FILL IT
;THIS IS A COUNT PATTERN 0 THRU 7
MOV #8.,R2 ; 8 NUMBERS TO BE WRITTEN
CLR R1 ; FIRST WORD TO BE WRITTEN = 0
MOV R1, @RHDB ; WRITE INTO RHDB - A COUNT
INC R1 ; GET NEXT WORD
DEC R2 ; COUNT TO 8
BNE 1$; BRANCH IF 8 NOT DONE

```

```

;WAIT FOR OR BIT IN RHCS2 REGISTER TO SET
WAT
RHCS2
OR
;TRAP TO WAIT.T SUBROUTINE
;AND WAIT FOR OR BIT IN
;RHCS2 REGISTER
;IF ERROR OCCURS HERE
;IT MEANS "OR" DID NOT
;SET FOR THE FULL COUNT
;DOWN OF THE WAIT.T SUBROUTINE
;THIS TIME IS APPROXIMATELY
;LARGER THAN 500 MILLISECONDS

```

```

;CHECK THAT RHCS2 HAS OR
MOV #OR,$GDDAT ; GET GOOD = 200
BIS UNIT,$GDDAT ; INCLUDE UNIT NUMBER
MOV @RHCS2,$BDDAT ; READ RHCS2 FOR COMPARISON
CMP $GDDAT,$BDDAT ; COMPARE EXPECTED
; DATA WITH DATA READ FROM
;RHCS2

```

```

;AFTER SETTING "CLR" BIT #5
;IN RHCS2 TO INIT THE RH
;AND HAVING WRITTEN A
;COUNT PATTERN 0 THRU 7
;INTO RHDB TO FILL IT
;RHCS2 SHOULD HAVE OR
;=200
;TOGETHER WITH UNIT NUMBER
;BUT CONTAINED WHAT IS
;GIVEN IN BAD RHCS2

```



;AND WRITING A  
;COUNT PATTERN 0 THRU 7  
;INTO RHDB TO FILL IT  
;THEN ON READING RHDB THE  
;THIRD TIME  
;RHDB SHOULD HAVE 2  
;BUT CONTAINED WHAT IS  
;GIVEN IN BAD RHDB

4939  
4940  
4941  
4942  
4943  
4944  
4945  
4946  
4947 015374 73\$:

4948 015374 012737 000004 004664 MOV #4,SILONM ;FOURTH WORD TO BE READ  
4949 ;CHECK THAT RHDB HAS 3  
4950 MOV #3,\$GDDAT ;GET GOOD = 0  
4951 015402 012737 000003 001124  
4952  
4953 015410 017737 166466 001126 MOV @RHDB,\$BDDAT ;READ RHDB FOR COMPARISON  
4954 015416 023737 001124 001126 CMP \$GDDAT,\$BDDAT ;COMPARE EXPECTED  
4955 ;DATA WITH DATA READ FROM  
4956 ;RHDB  
4957 015424 001401 BEQ 75\$ ;BRANCH IF GOOD  
4958 015426 104024 ERROR 24

;READ RHDB FOR COMPARISON  
;COMPARE EXPECTED  
;DATA WITH DATA READ FROM  
;RHDB  
;BRANCH IF GOOD

;AFTER SETTING "CLR" BIT #5  
;IN RHCS2 TO INIT THE RH  
;AND WRITING A  
;COUNT PATTERN 0 THRU 7  
;INTO RHDB TO FILL IT  
;THEN ON READING RHDB THE  
;FOURTH TIME  
;RHDB SHOULD HAVE 3  
;BUT CONTAINED WHAT IS  
;GIVEN IN BAD RHDB

4959  
4960  
4961  
4962  
4963  
4964  
4965  
4966  
4967  
4968  
4969 015430 75\$:  
4970

4971 015430 012737 000005 004664 MOV #5,SILONM ;FIFTH WORD TO BE READ  
4972 ;CHECK THAT RHDB HAS 4  
4973 015436 012737 000004 001124 MOV #4,\$GDDAT ;GET GOOD = 0  
4974  
4975 015444 017737 166432 001126 MOV @RHDB,\$BDDAT ;READ RHDB FOR COMPARISON  
4976 015452 023737 001124 001126 CMP \$GDDAT,\$BDDAT ;COMPARE EXPECTED  
4977 ;DATA WITH DATA READ FROM  
4978 ;RHDB  
4979 015460 001401 BEQ 77\$ ;BRANCH IF GOOD  
4980 015462 104024 ERROR 24

;READ RHDB FOR COMPARISON  
;COMPARE EXPECTED  
;DATA WITH DATA READ FROM  
;RHDB  
;BRANCH IF GOOD

;AFTER SETTING "CLR" BIT #5  
;IN RHCS2 TO INIT THE RH  
;AND WRITING A  
;COUNT PATTERN 0 THRU 7  
;INTO RHDB TO FILL IT  
;THEN ON READING RHDB THE  
;FIFTH TIME  
;RHDB SHOULD HAVE 4  
;BUT CONTAINED WHAT IS  
;GIVEN IN BAD RHDB

4981  
4982  
4983  
4984  
4985  
4986  
4987  
4988  
4989  
4990  
4991 015464 77\$:  
4992

4993 015464 012737 000006 004664 MOV #6,SILONM ;SIXTH WORD TO BE READ  
4994 ;CHECK THAT RHDB HAS 5

;SIXTH WORD TO BE READ



; INTO RHDB TO FILL IT  
; THEN ON READING RHDB THE  
; EIGHTH TIME  
; RHDB SHOULD HAVE 7  
; BUT CONTAINED WHAT IS  
; GIVEN IN BAD RHDB

5051  
5052  
5053  
5054  
5055  
5056  
5057 015610 83\$:

5058  
5059  
5060 ; CHECK THAT RHCS2 HAS IR  
5061 015610 012737 000100 001124 MOV #IR,\$GDDAT  
5062 015616 053737 005010 001124 BIS UNIT,\$GDDAT  
5063  
5064 015624 017737 166240 001126 MOV @RHCS2,\$BDDAT  
5065 015632 023737 001124 001126 CMP \$GDDAT,\$BDDAT  
5066  
5067  
5068 015640 001401 BEQ 85\$  
5069 015642 104025 ERROR 25

; GET GOOD = 100  
; INCLUDE UNIT NUMBER  
; READ RHCS2 FOR COMPARISON  
; COMPARE EXPECTED  
; DATA WITH DATA READ FROM  
; RHCS2  
; BRANCH IF GOOD

; AFTER SETTING "CLR" BIT #5  
; IN RHCS2 TO INIT THE RH  
; AND WRITING A  
; COUNT PATTERN 0 THRU 7  
; INTO RHDB TO FILL IT  
; THEN ON READING RHDB THE  
; TOTAL 8 TIMES  
; RHCS2 SHOULD HAVE IR  
; =100  
; TOGETHER WITH UNIT NUMBER  
; BUT CONTAINED WHAT IS  
; GIVEN IN BAD RHCS2

5070  
5071  
5072  
5073  
5074  
5075  
5076  
5077  
5078  
5079  
5080  
5081  
5082 015644 85\$:

5083 ; CHECK THAT RHCS1 HAS DVA!RDY  
5084 015644 012737 004200 001124 MOV #DVA!RDY,\$GDDAT  
5085  
5086 015652 017737 166202 001126 MOV @RHCS1,\$BDDAT  
5087 015660 023737 001124 001126 CMP \$GDDAT,\$BDDAT  
5088  
5089  
5090 015666 001401 BEQ 87\$  
5091 015670 104026 ERROR 26

; GET GOOD = 4200  
; READ RHCS1 FOR COMPARISON  
; COMPARE EXPECTED  
; DATA WITH DATA READ FROM  
; RHCS1  
; BRANCH IF GOOD

; AFTER SETTING "CLR" BIT #5  
; IN RHCS2 TO INIT THE RH  
; AND WRITING A  
; COUNT PATTERN 0 THRU 7  
; INTO RHDB TO FILL IT  
; THEN ON READING RHDB THE  
; TOTAL 8 TIMES  
; RHCS1 SHOULD HAVE DVA!RDY  
; =4200  
; BUT CONTAINED WHAT IS  
; GIVEN IN BAD RHCS1

5092  
5093  
5094  
5095  
5096  
5097  
5098  
5099  
5100  
5101  
5102  
5103 015672 87\$:

5104 ; CHECK THAT RHCS3 HAS 0  
5105 015672 012737 000000 001124 MOV #0,\$GDDAT  
5106

; GET GOOD = 0



```

5163 015774 93$:
5164 ;CHECK THAT RHWC HAS 0
5165 015774 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
5166 ;
5167 016002 017737 166054 001126 MOV @RHWC,$BDDAT ;READ RHWC FOR COMPARISON
5168 016010 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
5169 ;DATA WITH DATA READ FROM
5170 ;RHWC
5171 016016 001401 BEQ 95$;BRANCH IF GOOD
5172 016020 104032 ERROR 32
5173 ;
5174 ;AFTER SETTING "CLR" BIT #5
5175 ;IN RHCS2 TO INIT THE RH
5176 ;AND WRITING A
5177 ;COUNT PATTERN 0 THRU 7
5178 ;INTO RHDB TO FILL IT
5179 ;THEN ON READING RHDB THE
5180 ;TOTAL 8 TIMES
5181 ;RHWC SHOULD HAVE 0
5182 ;BUT CONTAINED WHAT IS
5183 ;GIVEN IN BAD RHWC

```

```

5183 016022 95$:

```

```

5184 ;*****
5185 ;*TEST 15 SILO TEST 5 (FLOATING ONES)
5186 ;
5187 ;*
5188 ;* AFTER ARH CLEAR IS GIVEN (SET BIT #5 IN RHCS2)
5189 ;* RHCS2 IS CHECKED TO HAVE "IR" (BIT #6) HIGH,
5190 ;* TOGETHER WITH UNIT NUMBER
5191 ;* EIGHT WORDS, A PATTERN OF FLOATING ONES (1,2,4,10,20,40,100,200)
5192 ;* IS WRITTEN INTO RHDB
5193 ;* "OR" (BIT #7 IN RHCS2) IS WAITED FOR BY A TRAP
5194 ;* INSTRUCTION CALLED "WAT"
5195 ;* THEN RHCS2 IS CHECKED TO HAVE "IR" LOW AND
5196 ;* "OR" HIGH TOGETHER WITH THE UNIT NUMBER
5197 ;* THEN RHDB IS READ AND COMPARED TO HAVE THE
5198 ;* RIGHT VALUE AFTER EACH OF THE EIGHT READS.
5199 ;* THEN RHCS2 IS CHECKED TO HAVE "IR"
5200 ;* AND UNIT NUMBER
5201 ;* THEN RHCS1, RHCS3, RHBA, RHBAE, RHWC ARE
5202 ;* CHECKED TO HAVE THE APPROPRIATE VALUE
5203 ;*****

```

```

5204 ;*****
5205 016022 000004 TST15: SCOPE
5206 016024 012706 001000 MOV #STACK,SP ;RESET STACK
5207 016030 012737 000015 004656 MOV #15,@TSTNM ;SAVE TEST NUMBER
5208 ;
5209 016036 004737 040322 JSR PC,@#CLDISK ;GIVE RH INITIALIZE
5210 ;SETUP UNIT NUBER
5211 ;CLEAR RHWC AND FUNCTION BITS IN RHCS1
5212 ;
5213 ;
5214 ;CHECK THAT RHCS2 HAS IR
5215 016042 012737 000100 001124 MOV #IR,$GDDAT ;GET GOOD = 100
5216 016050 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
5217 ;
5218 016056 017737 166006 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON

```





```

5275 ;GIVEN IN BAD RHCS2
5276 016162 67$:
5277
5278
5279
5280 016162 012737 000001 004664 MOV #1,SILONM ;FIRST WORD TO BE READ
5281 ;CHECK THAT RHDB HAS 1
5282 016170 012737 000001 001124 MOV #1,$GDDAT ;GET GOOD = 0
5283
5284 016176 017737 165700 001126 MOV @RHDB,$BDDAT ;READ RHDB FOR COMPARISON
5285 016204 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
5286 ;DATA WITH DATA READ FROM
5287 ;RHDB
5288
5289 016212 001401 BEQ 69$;BRANCH IF GOOD
5290 016214 104024 ERROR 24
5291
5292 ;AFTER SETTING "CLR" BIT #5
5293 ;IN RHCS2 TO INIT THE RH
5294 ;AND WRITING A PATTERN OF
5295 ;FLOATING ONES (WHICH IS
5296 ;1,2,4,10,20,40,100,200)
5297 ;INTO RHDB TO FILL IT
5298 ;THEN ON READING RHDB THE
5299 ;FIRST TIME
5300 ;RHDB SHOULD HAVE 1
5301 016216 69$:
5302 ;BUT CONTAINED WHAT IS
5303 ;GIVEN IN BAD RHDB
5304 016216 012737 000002 004664 MOV #2,SILONM ;SECOND WORD TO BE READ
5305 ;CHECK THAT RHDB HAS 2
5306 016224 012737 000002 001124 MOV #2,$GDDAT ;GET GOOD = 0
5307
5308 016232 017737 165644 001126 MOV @RHDB,$BDDAT ;READ RHDB FOR COMPARISON
5309 016240 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
5310 ;DATA WITH DATA READ FROM
5311 ;RHDB
5312 016246 001401 BEQ 71$;BRANCH IF GOOD
5313 016250 104024 ERROR 24
5314
5315 ;AFTER SETTING "CLR" BIT #5
5316 ;IN RHCS2 TO INIT THE RH
5317 ;AND WRITING A PATTERN OF
5318 ;FLOATING ONES (WHICH IS
5319 ;1,2,4,10,20,40,100,200)
5320 ;INTO RHDB TO FILL IT
5321 ;THEN ON READING RHDB THE
5322 ;SECOND TIME
5323 ;RHDB SHOULD HAVE 2
5324 ;BUT CONTAINED WHAT IS
5325 016252 71$:
5326 ;GIVEN IN BAD RHDB
5327
5328 016252 012737 000003 004664 MOV #3,SILONM ;THIRD WORD TO BE READ
5329 ;CHECK THAT RHDB HAS 4
5330 016260 012737 000004 001124 MOV #4,$GDDAT ;GET GOOD = 0

```



```
5387 ; IN RHCS2 TO INIT THE RH
5388 ; AND WRITING A PATTERN OF
5389 ; FLOATING ONES (WHICH IS
5390 ; 1, 2, 4, 10, 20, 40, 100, 200)
5391 ; INTO RHDB TO FILL IT
5392 ; THEN ON READING RHDB THE
5393 ; FIFTH TIME
5394 ; RHDB SHOULD HAVE 20
5395 ; BUT CONTAINED WHAT IS
5396 ; GIVEN IN BAD RHDB
5397 016376 77$:
5398
5399
5400 016376 012737 000006 004664 MOV #6,SILONM ;SIXTH WORD TO BE READ
5401 ;CHECK THAT RHDB HAS 40
5402 016404 012737 000040 001124 MOV #40,$GDDAT ;GET GOOD = 0
5403
5404 016412 017737 165464 001126 MOV @RHDB,$BDDAT ;READ RHDB FOR COMPARISON
5405 016420 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
5406 ;DATA WITH DATA READ FROM
5407 ;RHDB
5408 016426 001401 BEQ 79$;BRANCH IF GOOD
5409 016430 104024
5410
5411 ; AFTER SETTING "CLR" BIT #5
5412 ; IN RHCS2 TO INIT THE RH
5413 ; AND WRITING A PATTERN OF
5414 ; FLOATING ONES (WHICH IS
5415 ; 1, 2, 4, 10, 20, 40, 100, 200)
5416 ; INTO RHDB TO FILL IT
5417 ; THEN ON READING RHDB THE
5418 ; SIXTH TIME
5419 ; RHDB SHOULD HAVE 40
5420 ; BUT CONTAINED WHAT IS
5421 ; GIVEN IN BAD RHDB
5422 016432 79$:
5423
5424 016432 012737 000007 004664 MOV #7,SILONM ;SEVENTH WORD TO BE READ
5425 ;CHECK THAT RHDB HAS 100
5426 016440 012737 000100 001124 MOV #100,$GDDAT ;GET GOOD = 0
5427
5428 016446 017737 165430 001126 MOV @RHDB,$BDDAT ;READ RHDB FOR COMPARISON
5429 016454 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
5430 ;DATA WITH DATA READ FROM
5431 ;RHDB
5432 016462 001401 BEQ 81$;BRANCH IF GOOD
5433 016464 104024
5434
5435 ; AFTER SETTING "CLR" BIT #5
5436 ; IN RHCS2 TO INIT THE RH
5437 ; AND WRITING A PATTERN OF
5438 ; FLOATING ONES (WHICH IS
5439 ; 1, 2, 4, 10, 20, 40, 100, 200)
5440 ; INTO RHDB TO FILL IT
5441 ; THEN ON READING RHDB THE
5442 ; SEVENTH TIME
5443 ; RHDB SHOULD HAVE 100
```

```

5443 ;BUT CONTAINED WHAT IS
5444 ;GIVEN IN BAD RHDB
5445 016466 81$:
5446
5447
5448 016466 012737 000010 004664 MOV #8, $ILONM ;EIGHTH WORD TO BE READ
5449 ;CHECK THAT RHDB HAS 200
5450 016474 012737 000200 001124 MOV #200, $GDDAT ;GET GOOD = 0
5451
5452 016502 017737 165374 001126 MOV @RHDB, $BDDAT ;READ RHDB FOR COMPARISON
5453 016510 023737 001124 001126 CMP $GDDAT, $BDDAT ;COMPARE EXPECTED
5454 ;DATA WITH DATA READ FROM
5455 ;RHDB
5456 016516 001401 BEQ 83$;BRANCH IF GOOD
5457 016520 104024 ERROR 24
5458 ;AFTER SETTING "CLR" BIT #5
5459 ;IN RHCS2 TO INIT THE RH
5460 ;AND WRITING A PATTERN OF
5461 ;FLOATING ONES (WHICH IS
5462 ;1, 2, 4, 10, 20, 40, 100, 200)
5463 ;INTO RHDB TO FILL IT
5464 ;THEN ON READING RHDB THE
5465 ;EIGHTH TIME
5466 ;RHDB SHOULD HAVE 200
5467 ;BUT CONTAINED WHAT IS
5468 ;GIVEN IN BAD RHDB
5469 016522 83$:
5470
5471
5472 ;CHECK THAT RHCS2 HAS IR
5473 016522 012737 000100 001124 MOV #IR, $GDDAT ;GET GOOD = 100
5474 016530 053737 005010 001124 BIS UNIT, $GDDAT ;INCLUDE UNIT NUMBER
5475
5476 016536 017737 165326 001126 MOV @RHCS2, $BDDAT ;READ RHCS2 FOR COMPARISON
5477 016544 023737 001124 001126 CMP $GDDAT, $BDDAT ;COMPARE EXPECTED
5478 ;DATA WITH DATA READ FROM
5479 ;RHCS2
5480 016552 001401 BEQ 85$;BRANCH IF GOOD
5481 016554 104025 ERROR 25
5482 ;AFTER SETTING "CLR" BIT #5
5483 ;IN RHCS2 TO INIT THE RH
5484 ;AND WRITING A PATTERN OF
5485 ;FLOATING ONES (WHICH IS
5486 ;1, 2, 4, 10, 20, 40, 100, 200)
5487 ;INTO RHDB TO FILL IT
5488 ;THEN ON READING RHDB THE
5489 ;TOTAL 8 TIMES
5490 ;RHCS2 SHOULD HAVE IR
5491 ;=100
5492 ;TOGETHER WITH UNIT NUMBER
5493 ;BUT CONTAINED WHAT IS
5494 ;GIVEN IN BAD RHCS2
5495 016556 85$:
5496
5497 016556 012737 004200 001124 MOV #DVA!RDY, $GDDAT ;GET GOOD = 4200
5498

```





```

5611 : * EIGHT WORDS, A PATTERN OF FLOATING ONES IN UPPER BYTE
5612 : * 400,1000,2000,4000,10000,20000,40000,100000
5613 : * IS WRITTEN INTO RHDB
5614 : * "OR" (BIT #7 IN RHCS2) IS WAITED FOR BY A TRAP
5615 : * INSTRUCTION CALLED "WAT"
5616 : * THEN RHCS2 IS CHECKED TO HAVE "IR" LOW AND
5617 : * "OR" HIGH TOGETHER WITH THE UNIT NUMBER
5618 : * THEN RHDB IS READ AND COMPARED TO HAVE THE
5619 : * RIGHT VALUE AFTER EACH OF THE EIGHT READS.
5620 : * THEN RHCS2 IS CHECKED TO HAVE "IR"
5621 : * AND UNIT NUMBER
5622 : * THEN RHCS1, RHCS3, RHBA, RHBAE, RHWC ARE
5623 : * CHECKED TO HAVE THE APPROPRIATE VALUE
5624 : * *****
5625 016734 000004 †ST16: SCOPE
5626 016736 012706 001000 MOV #STACK,SP ;RESET STACK
5627 016742 012737 000016 004656 MOV #16,#TSTNM ;SAVE TEST NUMBER
5628
5629 016750 004737 040322 JSR PC,#CLDISK ;GIVE RH INITIALIZE
5630
5631
5632
5633
5634
5635 016754 012737 000100 001124 ;CHECK THAT RHCS2 HAS IR
5636 016762 053737 005010 001124 MOV #IR,$GDDAT ;GET GOOD = 100
5637
5638 016770 017737 165074 001126 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
5639 016776 023737 001124 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
5640
5641
5642 017004 001401 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
5643 017006 104006 BEQ 65$;DATA WITH DATA READ FROM
5644
5645
5646
5647
5648
5649
5650
5651
5652
5653 017010 BEQ 65$;RHCS2
5654
5655
5656
5657
5658 017010 012701 000400 ;AFTER SETTING "CLR" BIT #5
5659
5660
5661
5662
5663
5664
5665
5666 017032 104411 ;IN RHCS2 TO INIT THE RH
5667
5668
5669
5670
5671
5672
5673
5674
5675
5676
5677
5678
5679
5680
5681
5682
5683
5684
5685
5686
5687
5688
5689
5690
5691
5692
5693
5694
5695
5696
5697
5698
5699
5700
5701
5702
5703
5704
5705
5706
5707
5708
5709
5710
5711
5712
5713
5714
5715
5716
5717
5718
5719
5720
5721
5722
5723
5724
5725
5726
5727
5728
5729
5730
5731
5732
5733
5734
5735
5736
5737
5738
5739
5740
5741
5742
5743
5744
5745
5746
5747
5748
5749
5750
5751
5752
5753
5754
5755
5756
5757
5758
5759
5760
5761
5762
5763
5764
5765
5766
5767
5768
5769
5770
5771
5772
5773
5774
5775
5776
5777
5778
5779
5780
5781
5782
5783
5784
5785
5786
5787
5788
5789
5790
5791
5792
5793
5794
5795
5796
5797
5798
5799
5800
5801
5802
5803
5804
5805
5806
5807
5808
5809
5810
5811
5812
5813
5814
5815
5816
5817
5818
5819
5820
5821
5822
5823
5824
5825
5826
5827
5828
5829
5830
5831
5832
5833
5834
5835
5836
5837
5838
5839
5840
5841
5842
5843
5844
5845
5846
5847
5848
5849
5850
5851
5852
5853
5854
5855
5856
5857
5858
5859
5860
5861
5862
5863
5864
5865
5866
5867
5868
5869
5870
5871
5872
5873
5874
5875
5876
5877
5878
5879
5880
5881
5882
5883
5884
5885
5886
5887
5888
5889
5890
5891
5892
5893
5894
5895
5896
5897
5898
5899
5900
5901
5902
5903
5904
5905
5906
5907
5908
5909
5910
5911
5912
5913
5914
5915
5916
5917
5918
5919
5920
5921
5922
5923
5924
5925
5926
5927
5928
5929
5930
5931
5932
5933
5934
5935
5936
5937
5938
5939
5940
5941
5942
5943
5944
5945
5946
5947
5948
5949
5950
5951
5952
5953
5954
5955
5956
5957
5958
5959
5960
5961
5962
5963
5964
5965
5966
5967
5968
5969
5970
5971
5972
5973
5974
5975
5976
5977
5978
5979
5980
5981
5982
5983
5984
5985
5986
5987
5988
5989
5990
5991
5992
5993
5994
5995
5996
5997
5998
5999
6000

```





:GIVEN IN BAD RHDB

5723  
5724 017130 69\$:

5725  
5726  
5727 017130 012737 000002 004664

MOV #2,SILONM ;SECOND WORD TO BE READ

5728  
5729 017136 012737 001000 001124

:CHECK THAT RHDB HAS 1000  
MOV #1000,\$GDDAT ;GET GOOD = 0

5730  
5731 017144 017737 164732 001126  
5732 017152 023737 001124 001126

MOV @RHDB,\$BDDAT ;READ RHDB FOR COMPARISON  
CMP \$GDDAT,\$BDDAT ;COMPARE EXPECTED

5733  
5734  
5735 017160 001401  
5736 017162 104024

BEQ 71\$ ;BRANCH IF GOOD  
ERROR 24

:AFTER SETTING "CLR" BIT #5  
:IN RHCS2 TO INIT THE RH  
:AND WRITING A PATTERN OF FLOATING  
:ONES (WHICH IS 400,1000,2000,4000,  
:10000,20000,40000,100000)  
:INTO RHDB TO FILL IT  
:THEN ON READING RHDB THE  
:SECOND TIME  
:RHDB SHOULD HAVE 1000  
:BUT CONTAINED WHAT IS  
:GIVEN IN BAD RHDB

5737  
5738  
5739  
5740  
5741  
5742  
5743  
5744  
5745  
5746  
5747

5748 017164 71\$:  
5749  
5750  
5751 017164 012737 000003 004664

MOV #3,SILONM ;THIRD WORD TO BE READ  
:CHECK THAT RHDB HAS 2000

5752 017172 012737 002000 001124

MOV #2000,\$GDDAT ;GET GOOD = 0

5753  
5754  
5755 017200 017737 164676 001126  
5756 017206 023737 001124 001126

MOV @RHDB,\$BDDAT ;READ RHDB FOR COMPARISON  
CMP \$GDDAT,\$BDDAT ;COMPARE EXPECTED

5757  
5758  
5759 017214 001401  
5760 017216 104024

BEQ 73\$ ;BRANCH IF GOOD  
ERROR 24

:AFTER SETTING "CLR" BIT #5  
:IN RHCS2 TO INIT THE RH  
:AND WRITING A PATTERN OF FLOATING  
:ONES (WHICH IS 400,1000,2000,4000,  
:10000,20000,40000,100000)  
:INTO RHDB TO FILL IT  
:THEN ON READING RHDB THE  
:THIRD TIME  
:RHDB SHOULD HAVE 2000  
:BUT CONTAINED WHAT IS  
:GIVEN IN BAD RHDB

5761  
5762  
5763  
5764  
5765  
5766  
5767  
5768  
5769  
5770  
5771

5772 017220 73\$:  
5773  
5774  
5775 017220 012737 000004 004664

MOV #4,SILONM ;FOURTH WORD TO BE READ  
:CHECK THAT RHDB HAS 4000

5776 017226 012737 004000 001124

MOV #4000,\$GDDAT ;GET GOOD = 0

5777  
5778



;AND WRITING A PATTERN OF FLOATING  
;ONES (WHICH IS 400,1000,2000,4000,  
;10000,20000,40000,100000)  
;INTO RHDB TO FILL IT  
;THEN ON READING RHDB THE  
;SIXTH TIME  
;RHDB SHOULD HAVE 20000  
;BUT CONTAINED WHAT IS  
;GIVEN IN BAD RHDB

;AFTER SETTING "CLR" BIT #5  
;IN RHCS2 TO INIT THE RH  
;AND WRITING A PATTERN OF FLOATING  
;ONES (WHICH IS 400,1000,2000,4000,  
;10000,20000,40000,100000)  
;INTO RHDB TO FILL IT  
;THEN ON READING RHDB THE  
;SEVENTH TIME  
;RHDB SHOULD HAVE 40000  
;BUT CONTAINED WHAT IS  
;GIVEN IN BAD RHDB

;AFTER SETTING "CLR" BIT #5  
;IN RHCS2 TO INIT THE RH  
;AND WRITING A PATTERN OF FLOATING  
;ONES (WHICH IS 400,1000,2000,4000,  
;10000,20000,40000,100000)  
;INTO RHDB TO FILL IT  
;THEN ON READING RHDB THE  
;EIGHTH TIME  
;RHDB SHOULD HAVE 100000  
;BUT CONTAINED WHAT IS

5835  
5836  
5837  
5838  
5839  
5840  
5841  
5842  
5843

5844 017344 79\$:

5845

5846 017344 012737 000007 004664

5847 ;CHECK THAT RHDB HAS 40000

5848 017352 012737 040000 001124

5849 MOV #40000,\$GDDAT ;GET GOOD = 0

5850

5851 017360 017737 164516 001126

5852 017366 023737 001124 001126

5853 MOV @RHDB,\$BDDAT ;READ RHDB FOR COMPARISON

5854 CMP \$GDDAT,\$BDDAT ;COMPARE EXPECTED

5855 017374 001401 BEQ 81\$ ;BRANCH IF GOOD

5856 017376 104024 ERROR 24

5857

5858

5859

5860

5861

5862

5863

5864

5865

5866

5867

5868 017400 81\$:

5869

5870

5871 017400 012737 000010 004664

5872 MOV #8,\$SILONM ;EIGHTH WORD TO BE READ

5873 ;CHECK THAT RHDB HAS 100000

5874 017406 012737 100000 001124

5875 MOV #100000,\$GDDAT ;GET GOOD = 0

5876

5877 017414 017737 164462 001126

5878 017422 023737 001124 001126

5879 MOV @RHDB,\$BDDAT ;READ RHDB FOR COMPARISON

5880 CMP \$GDDAT,\$BDDAT ;COMPARE EXPECTED

5881 017430 001401 BEQ 83\$ ;BRANCH IF GOOD

5882 017432 104024 ERROR 24

5883

5884

5885

5886

5887

5888

5889

5890



```

5947
5948 017540 001401 BEQ 89$
5949 017542 104027 ERROR 27
5950
5951
5952
5953
5954
5955
5956
5957
5958
5959
5960
5961 017544 89$:
5962
5963 017544 012737 000000 001124 ;CHECK THAT RHBA HAS 0
5964
5965 017552 017737 164306 001126 MOV #0,$GDDAT
5966 017560 023737 001124 001126 CMP $RHBA,$BDDAT
5967
5968
5969 017566 001401 BEQ 91$
5970 017570 104030 ERROR 30
5971
5972
5973
5974
5975
5976
5977
5978
5979
5980
5981
5982 017572 91$:
5983
5984 017572 012737 000000 001124 ;CHECK THAT RHBAE HAS 0
5985
5986 017600 017737 164324 001126 MOV $RHBAE,$BDDAT
5987 017606 023737 001124 001126 CMP $GDDAT,$BDDAT
5988
5989
5990 017614 001401 BEQ 93$
5991 017616 104031 ERROR 31
5992
5993
5994
5995
5996
5997
5998
5999
6000
6001
6002

```

```

;RHCS3
;BRANCH IF GOOD

;AFTER SETTING "CLR" BIT #5
;IN RHCS2 TO INIT THE RH
;AND WRITING A PATTERN OF FLOATING
;ONES (WHICH IS 400,1000,2000,4000,
;10000,20000,40000,100000)
;INTO RHDB TO FILL IT
;THEN ON READING RHDB THE
;TOTAL 8 TIMES
;RHCS3 SHOULD HAVE 0
;BUT CONTAINED WHAT IS
;GIVEN IN BAD RHCS3

;GET GOOD = 0

;READ RHBA FOR COMPARISON
;COMPARE EXPECTED
;DATA WITH DATA READ FROM
;RHBA
;BRANCH IF GOOD

;AFTER SETTING "CLR" BIT #5
;IN RHCS2 TO INIT THE RH
;AND WRITING A PATTERN OF FLOATING
;ONES (WHICH IS 400,1000,2000,4000,
;10000,20000,40000,100000)
;INTO RHDB TO FILL IT
;THEN ON READING RHDB THE
;TOTAL 8 TIMES
;RHBA SHOULD HAVE 0
;BUT CONTAINED WHAT IS
;GIVEN IN BAD RHBA

;GET GOOD = 0

;READ RHBAE FOR COMPARISON
;COMPARE EXPECTED
;DATA WITH DATA READ FROM
;RHBAE
;BRANCH IF GOOD

;AFTER SETTING "CLR" BIT #5
;IN RHCS2 TO INIT THE
;AND WRITING A PATTERN OF FLOATING
;ONES (WHICH IS 400, 1000,2000,4000,
;10000,20000,40000,10000)
;INTO RHDB TO FILL
;THEN ON READING R 3 THE
;TOTAL 8 TIMES
;RHBAE SHOULD HA 0
;BUT CONTAINED W T IS
;GIVEN IN BAD R E

```

```

6003 017620 93$:
6004 ;CHECK THAT RHWC HAS 0
6005 017620 012737 000000 001124 MOV #0,$GDDAT ;GET .000 = 0
6006
6007 017626 017737 164230 001126 MOV @RHWC,$BDDAT ;R J RHWC FOR COMPARISON
6008 017634 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
6009 ;DATA WITH DATA READ FROM
6010 ;RHWC
6011 017642 001401 BEQ 95$;BRANCH IF GOOD
6012 017644 104032 ERROR 32
6013
6014 ;AFTER SETTING "CLR" BIT #5
6015 ;IN RHCS2 TO INIT THE RH
6016 ;AND WRITING A PATTERN OF FLOATING
6017 ;ONES (WHICH IS 400,1000,2000,4000,
6018 ;10000,20000,40000,100000)
6019 ;INTO RHDB TO FILL IT
6020 ;THEN ON READING RHDB THE
6021 ;TOTAL 8 TIMES
6022 ;RHWC SHOULD HAVE 0
6023 ;BUT CONTAINED WHAT IS
6024 017646 95$:
6025
6026
6027 ;*****
6028 ;*TEST 17 SILO TEST 7 (FLOATING 0 IN LOWER BYTE)
6029
6030 ;*
6031 ;* AFTER A RH CLEAR IS GIVEN (SET BIT #5 IN RHCS2)
6032 ;* RHCS2 IS CHECKED TO HAVE "IR" (BIT #6) HIGH,
6033 ;* TOGETHER WITH UNIT NUMBER
6034 ;* EIGHT WORDS OF FLOATING ZEROS 177776, 177775, 177773,
6035 ;* 177767, 177757, 177737, 177677, 177577
6036 ;* IS WRITTEN INTO RHDB
6037 ;* "OR" (BIT #7 IN RHCS2) IS WAITED FOR BY A TRAP
6038 ;* INSTRUCTION CALLED "WAT"
6039 ;* THEN RHCS2 IS CHECKED TO HAVE "IR" LOW AND
6040 ;* "OR" HIGH TOGETHER WITH THE UNIT NUMBER
6041 ;* THEN RHDB IS READ AND COMPARED TO HAVE THE
6042 ;* RIGHT VALUE AFTER EACH OF THE EIGHT READS.
6043 ;* THE RHCS2 IS CHECKED TO HAVE "IR"
6044 ;* AND UNIT NUMBER
6045 ;* THEN RHCS1, RHCS3, RHBA, RHBAE, RHWC ARE
6046 ;* CHECKED TO HAVE THE APPROPRIATE VALUE
6047 ;*****
6047 017646 000004 ST17: SCOPE
6048 017650 012706 001000 MOV #STACK,SP ;RESET STACK
6049 017654 012737 000017 004656 MOV #17,@#TSTNM ;SAVE TEST NUMBER
6050
6051 017662 004737 040322 JSR PC,@#CLDISK ;GIVE RH INITIALIZE
6052 ;SETUP UNIT NUMBER
6053 ;CLEAR RHWC AND FUNCTION BITS IN RHCS1
6054
6055
6056 ;CHECK THAT RHCS2 HAS IR
6057 017666 012737 000100 001124 MOV #IR,$GDDAT ;GET GOOD = 100
6058 017674 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER

```



```

6115 ;RHCS2 SHOULD HAVE OR
6116 ;=200
6117 ;TOGETHER WITH UNIT NUMBER
6118 ;BUT CONTAINED WHAT IS
6119 ;GIVEN IN BAD RHCS2
6120 020010 67$:
6121
6122
6123
6124 020010 012737 000001 004664 MOV #1,SILONM ;FIRST WORD TO BE READ
6125 ;CHECK THAT RHDB HAS 177776
6126 020016 012737 177776 001124 MOV #177776,$GDDAT ;GET GOOD = 0
6127
6128 020024 017737 164052 001126 MOV @RHDB,$BDDAT ;READ RHDB FOR COMPARISON
6129 020032 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
6130 ;DATA WITH DATA READ FROM
6131 ;RHDB
6132 020040 001401 BEQ 69$;BRANCH IF GOOD
6133 020042 104024 ERROR 24
6134
6135 ;AFTER SETTING "CLR" BIT #5
6136 ;IN RHCS2 TO INIT THE RH
6137 ;AND WRITING A PATTERN OF FLOATING
6138 ;ZEROS - 177776, 177775, 177773, 177767,
6139 ;177757, 177737, 177677, 177577
6140 ;INTO RHDB TO FILL IT
6141 ;THEN ON READING RHDB THE
6142 ;FIRST TIME
6143 ;RHDB SHOULD HAVE 177776
6144 ;BUT CONTAINED WHAT IS
6145 ;GIVEN IN BAD RHDB
6146
6147
6148 020044 69$:
6149
6150 020044 012737 000002 004664 MOV #2,SILONM ;SECOND WORD TO BE READ
6151 ;CHECK THAT RHDB HAS 177775
6152 020052 012737 177775 001124 MOV #177775,$GDDAT ;GET GOOD = 0
6153
6154 020060 017737 164016 001126 MOV @RHDB,$BDDAT ;READ RHDB FOR COMPARISON
6155 020066 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
6156 ;DATA WITH DATA READ FROM
6157 ;RHDB
6158 020074 001401 BEQ 71$;BRANCH IF GOOD
6159 020076 104024 ERROR 24
6160
6161 ;AFTER SETTING "CLR" BIT #5
6162 ;IN RHCS2 TO INIT THE RH
6163 ;AND WRITING A PATTERN OF FLOATING
6164 ;ZEROS - 177776, 177775, 177773, 177767,
6165 ;177757, 177737, 177677, 177577
6166 ;INTO RHDB TO FILL IT
6167 ;THEN ON READING RHDB THE
6168 ;SECOND TIME
6169 ;RHDB SHOULD HAVE 177775
6170 ;BUT CONTAINED WHAT IS
 ;GIVEN IN BAD RHDB
020100 71$:

```



```

6171
6172 020100 012737 000003 004664 MOV #3,SILONM ;THIRD WORD TO BE READ
6173 ;CHECK THAT RHDB HAS 177773
6174 020106 012737 177773 001124 MOV #177773,$GDDAT ;GET GOOD = 0
6175
6176 020114 017737 163762 001126 MOV @RHDB,$BDDAT ;READ RHDB FOR COMPARISON
6177 020122 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
6178 ;DATA WITH DATA READ FROM
6179 ;RHDB
6180 020130 001401 BEQ 73$;BRANCH IF GOOD
6181 020132 104024 ERROR 24
6182 ;AFTER SETTING "CLR" BIT #5
6183 ;IN RHCS2 TO INIT THE RH
6184 ;AND WRITING A PATTERN OF FLOATING
6185 ;ZEROS - 177776, 177775, 177773, 177767,
6186 ;177757, 177737, 177677, 177577
6187 ;INTO RHDB TO FILL IT
6188 ;THEN ON READING RHDB THE
6189 ;THIRD TIME
6190 ;RHDB SHOULD HAVE 177773
6191 ;BUT CONTAINED WHAT IS
6192 ;GIVEN IN BAD RHDB
6193 020134 73$:
6194
6195
6196 020134 012737 000004 004664 MOV #4,SILONM ;FOURTH WORD TO BE READ
6197 ;CHECK THAT RHDB HAS 177767
6198 020142 012737 177767 001124 MOV #177767,$GDDAT ;GET GOOD = 0
6199
6200 020150 017737 163726 001126 MOV @RHDB,$BDDAT ;READ RHDB FOR COMPARISON
6201 020156 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
6202 ;DATA WITH DATA READ FROM
6203 ;RHDB
6204 020164 001401 BEQ 75$;BRANCH IF GOOD
6205 020166 104024 ERROR 24
6206 ;AFTER SETTING "CLR" BIT #5
6207 ;IN RHCS2 TO INIT THE RH
6208 ;AND WRITING A PATTERN OF FLOATING
6209 ;ZEROS - 177776, 177775, 177773, 177767,
6210 ;177757, 177737, 177677, 177577
6211 ;INTO RHDB TO FILL IT
6212 ;THEN ON READING RHDB THE
6213 ;FOURTH TIME
6214 ;RHDB SHOULD HAVE 177767
6215 ;BUT CONTAINED WHAT IS
6216 ;GIVEN IN BAD RHDB
6217 020170 75$:
6218
6219
6220 020170 012737 000005 004664 MOV #5,SILONM ;FIFTH WORD TO BE READ
6221 ;CHECK THAT RHDB HAS 177757
6222 020176 012737 177757 001124 MOV #177757,$GDDAT ;GET GOOD = 0
6223
6224 020204 017737 163672 001126 MOV @RHDB,$BDDAT ;READ RHDB FOR COMPARISON
6225 020212 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
6226 ;DATA WITH DATA READ FROM

```

```

6227
6228 020220 001401 BEQ 77$
6229 020222 104024 ERROR 24 ;RHDB
;BRANCH IF GOOD
6230
6231
6232
6233
6234
6235
6236
6237
6238
6239
6240
6241 020224 77$:
6242
6243
6244 020224 012737 000006 004664 MOV #6,SILONM ;SIXTH WORD TO BE READ
;CHECK THAT RHDB HAS 177737
6245
6246 020232 012737 177737 001124 MOV #177737,$GDDAT ;GET GOOD = 0
6247
6248 020240 017737 163636 001126 MOV @RHDB,$BDDAT ;READ RHDB FOR COMPARISON
6249 020246 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
;DATA WITH DATA READ FROM
6250
6251
6252 020254 001401 BEQ 79$
6253 020256 104024 ERROR 24 ;RHDB
;BRANCH IF GOOD
6254
6255
6256
6257
6258
6259
6260
6261
6262
6263
6264
6265 020260 79$:
6266
6267
6268 020260 012737 000007 004664 MOV #7,SILONM ;SEVENTH WORD TO BE READ
;CHECK THAT RHDB HAS 177677
6269
6270 020266 012737 177677 001124 MOV #177677,$GDDAT ;GET GOOD = 0
6271
6272 020274 017737 163602 001126 MOV @RHDB,$BDDAT ;READ RHDB FOR COMPARISON
6273 020302 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
;DATA WITH DATA READ FROM
6274
6275
6276 020310 001401 BEQ 81$
6277 020312 104024 ERROR 24 ;RHDB
;BRANCH IF GOOD
6278
6279
6280
6281
6282

```

```

;AFTER SETTING "CLR" BIT #5
;IN RHCS2 TO INIT THE RH
;AND WRITING A PATTERN OF FLOATING
;ZEROS - 177776, 177775, 177773, 177767,
;177757, 177737, 177677, 177577
;INTO RHDB TO FILL IT
;THEN ON READING RHDB THE
;FIFTH TIME
;RHDB SHOULD HAVE 177757
;BUT CONTAINED WHAT IS
;GIVEN IN BAD RHDB

;AFTER SETTING "CLR" BIT #5
;IN RHCS2 TO INIT THE RH
;AND WRITING A PATTERN OF FLOATING
;ZEROS - 177776, 177775, 177773, 177767,
;177757, 177737, 177677, 177577
;INTO RHDB TO FILL IT
;THEN ON READING RHDB THE
;SIXTH TIME
;RHDB SHOULD HAVE 177737
;BUT CONTAINED WHAT IS
;GIVEN IN BAD RHDB

;AFTER SETTING "CLR" BIT #5
;IN RHCS2 TO INIT THE RH
;AND WRITING A PATTERN OF FLOATING
;ZEROS - 177776, 177775, 177773, 177767,
;177757, 177737, 177677, 177577

```

6283  
6284  
6285  
6286  
6287  
6288  
6289  
6290  
6291  
6292  
6293  
6294  
6295  
6296  
6297  
6298  
6299  
6300  
6301  
6302  
6303  
6304  
6305  
6306  
6307  
6308  
6309  
6310  
6311  
6312  
6313  
6314  
6315  
6316  
6317  
6318  
6319  
6320  
6321  
6322  
6323  
6324  
6325  
6326  
6327  
6328  
6329  
6330  
6331  
6332  
6333  
6334  
6335  
6336  
6337  
6338

020314

81\$:

020314 012737 000010 004664  
020322 012737 177577 001124  
020330 017737 163546 001126  
020336 023737 001124 001126  
020344 001401  
020346 104024

MOV #8,SILONM  
;CHECK THAT RHDB HAS 177577  
MOV #177577,\$GDDAT  
MOV @RHDB,\$BDDAT  
CMP \$GDDAT,\$BDDAT  
BEQ 83\$  
ERROR 24

; INTO RHDB TO FILL IT  
; THEN ON READING RHDB THE  
; SEVENTH TIME  
; RHDB SHOULD HAVE 177677  
; BUT CONTAINED WHAT IS  
; GIVEN IN BAD RHDB

; EIGHTH WORD TO BE READ  
; GET GOOD = 0

; READ RHDB FOR COMPARISON  
; COMPARE EXPECTED  
; DATA WITH DATA READ FROM  
; RHDB  
; BRANCH IF GOOD

; AFTER SETTING "CLR" BIT #5  
; IN RHCS2 TO INIT THE RH  
; AND WRITING A PATTERN OF FLOATING  
; ZEROS - 177776, 177775, 177773, 177767,  
; 177757, 177737, 177677, 177577  
; INTO RHDB TO FILL IT  
; THEN ON READING RHDB THE  
; EIGHTH TIME  
; RHDB SHOULD HAVE 177577  
; BUT CONTAINED WHAT IS  
; GIVEN IN BAD RHDB

020350

83\$:

020350 012737 000100 001124  
020356 053737 005010 001124  
020364 017737 163500 001126  
020372 023737 001124 001126  
020400 001401  
020402 104025

;CHECK THAT RHCS2 HAS IR  
MOV #IR,\$GDDAT  
BIS UNIT,\$GDDAT  
MOV @RHCS2,\$BDDAT  
CMP \$GDDAT,\$BDDAT  
BEQ 85\$  
ERROR 25

; GET GOOD = 100  
; INCLUDE UNIT NUMBER

; READ RHCS2 FOR COMPARISON  
; COMPARE EXPECTED  
; DATA WITH DATA READ FROM  
; RHCS2  
; BRANCH IF GOOD

; AFTER SETTING "CLR" BIT #5  
; IN RHCS2 TO INIT THE RH  
; AND WRITING A PATTERN OF FLOATING  
; ZEROS - 177776, 177775, 177773, 177767,  
; 177757, 177737, 177677, 177577  
; INTO RHDB TO FILL IT  
; THEN ON READING RHDB THE  
; TOTAL 8 TIMES  
; RHCS2 SHOULD HAVE IR  
; =100  
; TOGETHER WITH UNIT NUMBER  
; BUT CONTAINED WHAT IS  
; GIVEN IN BAD RHCS2

```

6339 020404 85$:
6340 ;CHECK THAT RHCS1 HAS DVA!RDY
6341 020404 012737 004200 001124 MOV #DVA!RDY,$GDDAT ;GET GOOD = 4200
6342 ;
6343 020412 017737 163442 001126 MOV @RHCS1,$BDDAT ;READ RHCS1 FOR COMPARISON
6344 020420 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
6345 ;DATA WITH DATA READ FROM
6346 ;RHCS1
6347 020426 001401 BEQ 87$;BRANCH IF GOOD
6348 020430 104026 ERROR 26
6349 ;
6350 ;AFTER SETTING "CLR" BIT #5
6351 ;IN RHCS2 TO INIT THE RH
6352 ;AND WRITING A PATTERN OF FLOATING
6353 ;ZEROS - 177776, 177775, 177773, 177767,
6354 ;177757, 177737, 177677, 177577
6355 ;INTO RHDB TO FILL IT
6356 ;THEN ON READING RHDB THE
6357 ;TOTAL 8 TIMES
6358 ;RHCS1 SHOULD HAVE DVA!RDY
6359 ;=4200
6360 ;BUT CONTAINED WHAT IS
6361 ;GIVEN IN BAD RHCS1
6361 020432 87$:
6362 ;CHECK THAT RHCS3 HAS 0
6363 020432 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
6364 ;
6365 020440 017737 163466 001126 MOV @RHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON
6366 020446 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
6367 ;DATA WITH DATA READ FROM
6368 ;RHCS3
6369 020454 001401 BEQ 89$;BRANCH IF GOOD
6370 020456 104027 ERROR 27
6371 ;
6372 ;AFTER SETTING "CLR" BIT #5
6373 ;IN RHCS2 TO INIT THE RH
6374 ;AND WRITING A PATTERN OF FLOATING
6375 ;ZEROS - 177776, 177775, 177773, 177767,
6376 ;177757, 177737, 177677, 177577
6377 ;INTO RHDB TO FILL IT
6378 ;THEN ON READING RHDB THE
6379 ;TOTAL 8 TIMES
6380 ;RHCS3 SHOULD HAVE 0
6381 ;BUT CONTAINED WHAT IS
6382 ;GIVEN IN BAD RHCS3
6382 020460 89$:
6383 ;CHECK THAT RHBA HAS 0
6384 020460 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
6385 ;
6386 020466 017737 163372 001126 MOV @RHBA,$BDDAT ;READ RHBA FOR COMPARISON
6387 020474 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
6388 ;DATA WITH DATA READ FROM
6389 ;RHBA
6390 020502 001401 BEQ 91$;BRANCH IF GOOD
6391 020504 104030 ERROR 30
6392 ;
6393 ;AFTER SETTING "CLR" BIT #5
6394 ;IN RHCS2 TO INIT THE RH
6394 ;AND WRITING A PATTERN OF FLOATING

```

6395.  
6396  
6397  
6398  
6399  
6400  
6401  
6402  
6403  
6404  
6405  
6406  
6407  
6408  
6409  
6410  
6411  
6412  
6413  
6414  
6415  
6416  
6417  
6418  
6419  
6420  
6421  
6422  
6423  
6424  
6425  
6426  
6427  
6428  
6429  
6430  
6431  
6432  
6433  
6434  
6435  
6436  
6437  
6438  
6439  
6440  
6441  
6442  
6443  
6444  
6445  
6446  
6447  
6448  
6449  
6450

020506 91\$:  
020506 012737 000000 001124  
020514 017737 163410 001126  
020522 023737 001124 001126  
020530 001401  
020532 104031  
  
020534 93\$:  
020534 012737 000000 001124  
020542 017737 163314 001126  
020550 023737 001124 001126  
020556 001401  
020560 104032  
  
020562 95\$:

91\$:  
;CHECK THAT RHBAE HAS 0  
MOV #0,\$GDDAT  
MOV \$RHBAE,\$BDDAT  
CMP \$GDDAT,\$BDDAT  
BEQ 93\$  
ERROR 31  
  
93\$:  
;CHECK THAT RHWC HAS 0  
MOV #0,\$GDDAT  
MOV \$RHWC,\$BDDAT  
CMP \$GDDAT,\$BDDAT  
BEQ 95\$  
ERROR 32

;ZEROS - 177776, 177775, 177773, 177767,  
;177757, 177737, 177677, 177577  
;INTO RHDB TO FILL IT  
;THEN ON READING RHDB THE  
;TOTAL 8 TIMES  
;RHBA SHOULD HAVE 0  
;BUT CONTAINED WHAT IS  
;GIVEN IN BAD RHBA  
  
;GET GOOD = 0  
;READ RHBAE FOR COMPARISON  
;COMPARE EXPECTED  
;DATA WITH DATA READ FROM  
;RHBAE  
;BRANCH IF GOOD  
  
;AFTER SETTING "CLR" BIT #5  
;IN RHCS2 TO INIT THE RH  
;AND WRITING A PATTERN OF FLOATING  
;ZEROS - 177776, 177775, 177773, 177767,  
;177757, 177737, 177677, 177577  
;INTO RHDB TO FILL IT  
;THEN ON READING RHDB THE  
;TOTAL 8 TIMES  
;RHBAE SHOULD HAVE 0  
;BUT CONTAINED WHAT IS  
;GIVEN IN BAD RHBAE  
  
;GET GOOD = 0  
;READ RHWC FOR COMPARISON  
;COMPARE EXPECTED  
;DATA WITH DATA READ FROM  
;RHWC  
;BRANCH IF GOOD  
  
;AFTER SETTING "CLR" BIT #5  
;IN RHCS2 TO INIT THE RH  
;AND WRITING A PATTERN OF FLOATING  
;ZEROS - 177776, 177775, 177773, 177767,  
;177757, 177737, 177677, 177577  
;INTO RHDB TO FILL IT  
;THEN ON READING RHDB THE  
;TOTAL 8 TIMES  
;RHWC SHOULD HAVE 0  
;BUT CONTAINED WHAT IS  
;GIVEN IN BAD RHWC

\*\*\*\*\*  
;\*TEST 20 SILO TEST 8 (FLOATING ZEROS IN UPPER BYTE)  
\*\*\*\*\*

```

6451 : * AFTER A RH CLEAR IS GIVEN (SET BIT #5 IN RHCS2)
6452 : * RHCS2 IS CHECKED TO HAVE "IR" (BIT #6) HIGH,
6453 : * TOGETHER WITH UNIT NUMBER
6454 : * EIGHT WORDS, A PATTERN OF FLOATING ZEROS IN UPPER BYTE
6455 : * 177377, 177677, 175777, 173777, 167777, 157777, 137777, 77777
6456 : * IS WRITTEN INTO RHDB
6457 : * "OR" (BIT #7 IN RHCS2) IS WAITED FOR BY A TRAP
6458 : * INSTRUCTION CALLED "WAT"
6459 : * THEN RHCS2 IS CHECKED TO HAVE "IR" LOW AND
6460 : * "OR" HIGH TOGETHER WITH THE UNIT NUMBER
6461 : * THEN RHDB IS READ AND COMPARED TO HAVE THE
6462 : * RIGHT VALUE AFTER EACH OF THE EIGHT READS.
6463 : * THEN RHCS2 IS CHECKED TO HAVE "IR"
6464 : * AND UNIT NUMBER
6465 : * THEN RHCS1, RHCS3, RHBA, RHBAE, RHWC ARE
6466 : * CHECKED TO HAVE THE APPROPRIATE VALUE
6467 : * *****
6468 020562 000004 †ST20: SCOPE
6469 020564 012706 001000 MOV #STACK,SP ;RESET STACK
6470 020570 012737 000020 004656 MOV #20,#†STNM ;SAVE TEST NUMBER
6471
6472 020576 004737 040322 JSR PC,#CLDISK ;GIVE RH INITIALIZE
6473 ;SETUP UNIT NUBER
6474 ;CLEAR RHWC AND FUNCTION BITS IN RHCS1
6475
6476
6477 ;CHECK THAT RHCS2 HAS IR
6478 020602 012737 000100 001124 MOV #IR,$GDDAT ;GET GOOD = 100
6479 020610 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
6480
6481 020616 017737 163246 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
6482 020624 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
6483 ;DATA WITH DATA READ FROM
6484 ;RHCS2
6485 020632 001401 BEQ 65$;BRANCH IF GOOD
6486 020634 104006 ERROR 6
6487 ;AFTER SETTING "CLR" BIT #5
6488 ;IN RHCS2 TO INIT THE RH
6489 ;AND HAVING DONE NOTHING
6490 ;ELSE
6491 ;RHCS2 SHOULD HAVE IR
6492 ;=100
6493 ;TOGETHER WITH UNIT NUMBER
6494 ;BUT CONTAINED WHAT IS
6495 ;GIVEN IN BAD RHCS2
6496 020636 65$:
6497
6498 ;WRITE EIGHT WORDS INTO RHDB TO FILL IT
6499 ;A PATTERN OF FLOATING ZEROS IN UPPER BYTE
6500 ;DATA IS - 177377, 176777, 175777, 173777, 167777,
6501 ;157777, 137777, 77777
6502 020636 012701 177377 MOV #177377,R1 ;GETTING READY TO FLOAT ZEROS
6503 ;IN UPPER BYTE
6504 020642 012702 000010 MOV #8,R2 ;COUNTER -8 DATA WORDS
6505 020646 010177 163230 1$: MOV R1,@RHDB ;WRITE INTO RHDB
6506 020652 000261 SEC ;SET CARRY

```



:167777, 157777, 137777, 77777  
:INTO RHDB TO FILL IT  
:THEN ON READING RHDB THE  
:FIRST TIME  
:RHDB SHOULD HAVE 177377  
:BUT CONTAINED WHAT IS  
:GIVEN IN BAD RHDB

:SECOND WORD TO BE READ  
:CHECK THAT RHDB HAS 176777  
:GET GOOD = 0

:READ RHDB FOR COMPARISON  
:COMPARE EXPECTED  
:DATA WITH DATA READ FROM  
:RHDB  
:BRANCH IF GOOD

:AFTER SETTING "CLR" BIT #5  
:IN RHCS2 TO INIT THE RH  
:AND WRITING A PATTERN OF FLOATING  
:ZEROS IN UPPER BYTE  
:177377, 176777, 175777, 173777,  
:167777, 157777, 137777, 77777  
:INTO RHDB TO FILL IT  
:THEN ON READING RHDB THE  
:SECOND TIME  
:RHDB SHOULD HAVE 176777  
:BUT CONTAINED WHAT IS  
:GIVEN IN BAD RHDB

:THIRD WORD TO BE READ  
:CHECK THAT RHDB HAS 175777  
:GET GOOD = 0

:READ RHDB FOR COMPARISON  
:COMPARE EXPECTED  
:DATA WITH DATA READ FROM  
:RHDB  
:BRANCH IF GOOD

:AFTER SETTING "CLR" BIT #5  
:IN RHCS2 TO INIT THE RH  
:AND WRITING A PATTERN OF FLOATING  
:ZEROS IN UPPER BYTE  
:177377, 176777, 175777, 173777,  
:167777, 157777, 137777, 77777  
:INTO RHDB TO FILL IT  
:THEN ON READING RHDB THE  
:THIRD TIME  
:RHDB SHOULD HAVE 175777  
:BUT CONTAINED WHAT IS

6563  
6564  
6565  
6566  
6567  
6568  
6569  
6570 020760 69\$:

6571  
6572  
6573 020760 012737 000002 004664  
6574  
6575 020766 012737 176777 001124  
6576  
6577 020774 017737 163102 001126  
6578 021002 023737 001124 001126  
6579

6580  
6581 021010 001401  
6582 021012 104034

6583  
6584  
6585  
6586  
6587  
6588  
6589  
6590  
6591  
6592  
6593  
6594  
6595 021014 71\$:  
6596

6597  
6598 021014 012737 000003 004664  
6599  
6600 021022 012737 175777 001124  
6601  
6602 021030 017737 163046 001126  
6603 021036 023737 001124 001126  
6604

6605  
6606 021044 001401  
6607 021046 104024

6608  
6609  
6610  
6611  
6612  
6613  
6614  
6615  
6616  
6617  
6618

MOV #2,SILONM  
:CHECK THAT RHDB HAS 176777  
MOV #176777,\$GDDAT

MOV @RHDB,\$BDDAT  
CMP \$GDDAT,\$BDDAT

BEG 71\$  
ERROR 34

MOV #3,SILONM  
:CHECK THAT RHDB HAS 175777  
MOV #175777,\$GDDAT

MOV @RHDB,\$BDDAT  
CMP \$GDDAT,\$BDDAT

BEG 73\$  
ERROR 24





```

6675 021146 012737 157777 001124 MOV #157777,$GDDAT ;GET GOOD = 0
6676
6677 021154 017737 162722 001126 MOV @RHDB,$BDDAT ;READ RHDB FOR COMPARISON
6678 021162 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
6679 ;DATA WITH DATA READ FROM
6680 ;RHDB
6681 021170 001401 BEQ 79$;BRANCH IF GOOD
6682 021172 104024 ERROR 24
6683 ;AFTER SETTING "CLR" BIT #5
6684 ;IN RHCS2 TO INIT THE RH
6685 ;AND WRITING A PATTERN OF FLOATING
6686 ;ZEROS IN UPPER BYTE
6687 ;177377, 176777, 175777, 173777,
6688 ;167777, 157777, 137777, 77777,
6689 ;INTO RHDB TO FILL IT
6690 ;THEN ON READING RHDB THE
6691 ;SIXTH TIME
6692 ;RHDB SHOULD HAVE 157777
6693 ;BUT CONTAINED WHAT IS
6694 ;GIVEN IN BAD RHDB
6695 021174 79$:
6696
6697
6698 021174 012737 000007 004664 MOV #7,SILONM ;SEVENTH WORD TO BE READ
6699 ;CHECK THAT RHDB HAS 137777
6700 021202 012737 137777 001124 MOV #137777,$GDDAT ;GET GOOD = 0
6701
6702 021210 017737 162666 001126 MOV @RHDB,$BDDAT ;READ RHDB FOR COMPARISON
6703 021216 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
6704 ;DATA WITH DATA READ FROM
6705 ;RHDB
6706 021224 001401 BEQ 81$;BRANCH IF GOOD
6707 021226 104024 ERROR 24
6708 ;AFTER SETTING "CLR" BIT #5
6709 ;IN RHCS2 TO INIT THE RH
6710 ;AND WRITING A PATTERN OF FLOATING
6711 ;ZEROS IN UPPER BYTE
6712 ;177377, 176777, 175777, 173777,
6713 ;167777, 157777, 137777, 77777,
6714 ;INTO RHDB TO FILL IT
6715 ;THEN ON READING RHDB THE
6716 ;SEVENTH TIME
6717 ;RHDB SHOULD HAVE 137777
6718 ;BUT CONTAINED WHAT IS
6719 ;GIVEN IN BAD RHDB
6720 021230 81$:
6721
6722
6723 021230 012737 000010 004664 MOV #8,SILONM ;EIGHTH WORD TO BE READ
6724 ;CHECK THAT RHDB HAS 77777
6725 021236 012737 077777 001124 MOV #77777,$GDDAT ;GET GOOD = 0
6726
6727 021244 017737 162632 001126 MOV @RHDB,$BDDAT ;READ RHDB FOR COMPARISON
6728 021252 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
6729 ;DATA WITH DATA READ FROM
6730 ;RHDB

```



```

6787
6788
6789
6790
6791
6792
6793
6794
6795 021346 87$:
6796
6797 021346 012737 000000 001124 :CHECK THAT RHCS3 HAS 0
6798
6799 021354 017737 162552 001126 MOV #0,$GDDAT ;GET GOOD = 0
6800 021362 023737 001124 001126 MOV @RHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON
6801
6802
6803 021370 001401 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
6804 021372 104027 ;DATA WITH DATA READ FROM
6805
6806
6807
6808
6809
6810
6811
6812
6813
6814
6815
6816
6817 021374 89$:
6818
6819 021374 012737 000000 001124 :CHECK THAT RHBA HAS 0
6820
6821 021402 017737 162456 001126 MOV #0,$GDDAT ;GET GOOD = 0
6822 021410 023737 001124 001126 MOV @RHBA,$BDDAT ;READ RHBA FOR COMPARISON
6823
6824
6825 021416 001401 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
6826 021420 104030 ;DATA WITH DATA READ FROM
6827
6828
6829
6830
6831
6832
6833
6834
6835
6836
6837
6838
6839 021422 91$:
6840
6841 021422 012737 000000 001124 :CHECK THAT RHBAE HAS 0
6842

```

```

;167777, 157777, 137777, 77777
;INTO RHDB TO FILL IT
;THEN ON READING RHDB THE
;TOTAL 8 TIMES
;RHCS1 SHOULD HAVE DVA!RDY
;=4200
;BUT CONTAINED WHAT IS
;GIVEN IN BAD RHCS1

;AFTER SETTING "CLR" BIT #5
;IN RHCS2 TO INIT THE RH
;AND WRITING A PATTERN OF FLOATING
;ZEROS IN UPPER BYTE
;177377, 176777, 175777, 173777,
;167777, 157777, 137777, 77777
;INTO RHDB TO FILL IT
;THEN ON READING RHDB THE
;TOTAL 8 TIMES
;RHCS3 SHOULD HAVE 0
;BUT CONTAINED WHAT IS
;GIVEN IN BAD RHCS3

;AFTER SETTING "CLR" BIT #5
;IN RHCS2 TO INIT THE RH
;AND WRITING A PATTERN OF FLOATING
;ZEROS IN UPPER BYTE
;177377, 176777, 175777, 173777,
;167777, 157777, 137777, 77777
;INTO RHDB TO FILL IT
;THEN ON READING RHDB THE
;TOTAL 8 TIMES
;RHBA SHOULD HAVE 0
;BUT CONTAINED WHAT IS
;GIVEN IN BAD RHBA

```

```

6843 021430 017737 162474 001126 MOV @RHBAE,$BDDAT ;READ RHB AE FOR COMPARISON
6844 021436 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
6845 ;DATA WITH DATA READ FROM
6846 ;RHB AE
6847 021444 001401 BEQ 93$;BRANCH IF GOOD
6848 021446 104031 ERROR 31
6849 ;AFTER SETTING "CLR" BIT #5
6850 ;IN RHCS2 TO INIT THE RH
6851 ;AND WRITING A PATTERN OF FLOATING
6852 ;ZEROS IN UPPER BYTE
6853 ;177377, 176777, 175777, 173777,
6854 ;167777, 157777, 137777, 77777
6855 ;INTO RHDB TO FILL IT
6856 ;THEN ON READING RHDB THE
6857 ;TOTAL 8 TIMES
6858 ;RHB AE SHOULD HAVE 0
6859 ;BUT CONTAINED WHAT IS
6860 ;GIVEN IN BAD RHB AE
6861 021450 93$:
6862 ;CHECK THAT RHWC HAS 0
6863 021450 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
6864
6865 021456 017737 162400 001126 MOV @RHWC,$BDDAT ;READ RHWC FOR COMPARISON
6866 021464 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
6867 ;DATA WITH DATA READ FROM
6868 ;RHWC
6869 021472 001401 BEQ 95$;BRANCH IF GOOD
6870 021474 104032 ERROR 32
6871 ;AFTER SETTING "CLR" BIT #5
6872 ;IN RHCS2 TO INIT THE RH
6873 ;AND WRITING A PATTERN OF FLOATING
6874 ;ZEROS IN UPPER BYTE
6875 ;177377, 176777, 175777, 173777,
6876 ;167777, 157777, 137777, 77777
6877 ;INTO RHDB TO FILL IT
6878 ;THEN ON READING RHDB THE
6879 ;TOTAL 8 TIMES
6880 ;RHWC SHOULD HAVE 0
6881 ;BUT CONTAINED WHAT IS
6882 ;GIVEN IN BAD RHWC
6883 021476 95$:
6884
6885
6886 ;:*****
6887 ;*TEST 21 RHCS1 - MCPE BIT #13 (PARITY LINE = 0)
6888
6889 ;*
6890 ;* AN RH CLEAR (SET BIT #5 IN RHCS2) IS GIVEN TO
6891 ;* CLEAR ALL DEVICE REGISTERS
6892 ;* THEN RHER1 (ERROR REGISTER 1) IS CHECKED TO HAVE
6893 ;* ZEROS
6894 ;* SET "PAT" (BIT #4 IN RHCS2) TO INVERT PARITY CHECKING
6895 ;* READ ANY DEVICE REGISTER - HERE RHER1
6896 ;* READ AND CHECK RHCS1 TO CONTAIN SC (BIT #15)
6897 ;* AND MCPE (BIT #13)
6898 ;* WRITE "1" INTO TRE (BIT #14 IN RHCS1)
6899 ;* READ RHCS1 SC, MCPE, AND RDY SHOULD BE SET

```

```

6899 : * GIVE AN RH CLEAR (CLR - BIT #5 IN RHCS2)
6900 : * CHECK RHCS1 TO HAVE RDY
6901 : * CHECK RHCS2 TO HAVE ONLY IR AND UNIT NUMBER
6902 : * CHECK RHCS3, RHBA, RHBAE, RHWC TO HAVE APPROPRIATE
6903 : * VALUES.
6904 : *****
6905 021476 000004 TST21: SCOPE
6906 021500 012706 001000 MOV #STACK,SP ;RESET STACK
6907 021504 012737 000021 004656 MOV #21,#TSTNM ;SAVE TEST NUMBER
6908
6909 021512 004737 040322 JSR PC,#CLDISK ;GIVE RH INITIALIZE
6910 ;SETUP UNIT NUBER
6911 ;CLEAR RHWC AND FUNCTION BITS IN RHCS1
6912
6913
6914 :CHECK THAT RHER1 HAS 0
6915 021516 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
6916
6917 021524 017737 162344 001126 MOV @RHER1,$BDDAT ;READ RHER1 FOR COMPARISON
6918 021532 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
6919 ;DATA WITH DATA READ FROM
6920 ;RHER1
6921 021540 001401 BEQ 65$;BRANCH IF GOOD
6922 021542 104033 ERROR 33
6923 ;AFTER SETTING "CLR" BIT #15
6924 ;IN RHCS2 TO INIT THE RH
6925 ;AND HAVING DONE NOTHING ELSE
6926 ;RHER1 SHOULD HAVE 0
6927 ;BUT CONTAINED WHAT IS
6928 ;GIVEN IN BAD RHER1
6929 021544 65$:
6930
6931 :TO INVERT THE PARITY CHECKING ON THE CONTROL BUS
6932 : "PAT" BIT #4 IN RHCS2 IS SET
6933 021544 052777 000020 162316 BIS #PAT,@RHCS2 ;SET PAT = 20 IN RHCS2
6934
6935
6936 :CHECK THAT RHER1 HAS 0
6937 021552 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
6938
6939 021560 017737 162310 001126 MOV @RHER1,$BDDAT ;READ RHER1 FOR COMPARISON
6940 021566 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
6941 ;DATA WITH DATA READ FROM
6942 ;RHER1
6943 021574 001401 BEQ 67$;BRANCH IF GOOD
6944 021576 104034 ERROR 34
6945 ;AFTER CLEARING THE RH AND
6946 ;DEVICE BY AN RH CLEAR
6947 ;AND READING RHER1 WITH
6948 ;WRONG PARITY CHECKING
6949 ;RHER1 SHOULD HAVE 0
6950 ;BUT CONTAINED WHAT IS
6951 ;GIVEN IN BAD RHER1
6952 021600 67$:
6953
6954 ;HAVING READ RHER1 WITH WRONG PARITY BEING

```

```

6955 ;CHECKED MCPE - BIT #13 AND SC BIT #15 IN RHCSI SHOULD BE SET
6956
6957 ;CHECK THAT RHCSI HAS 4200
6958 021600 012737 004200 001124 MOV #4200,$GDDAT ;GET GOOD = 124200
6959
6960 021606 017737 162246 001126 MOV @RHCSI,$BDDAT ;READ RHCSI FOR COMPARISON
6961 021614 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
6962 ;DATA WITH DATA READ FROM
6963 ;RHCSI
6964 021622 001401 BEQ 69$;BRANCH IF GOOD
6965 021624 104035 ERROR 35
6966 ;AFTER CLEARING THE RH AND
6967 ;DEVICE BY AN RH CLEAR
6968 ;AND READING RHER1 WITH
6969 ;WRONG PARITY CHECKING
6970 ;RHCSI SHOULD HAVE 4200
6971 ;=124200
6972 ;BUT CONTAINED WHAT IS
6973 ;GIVEN IN BAD RHCSI
6974 021626 69$:
6975
6976 ;WRITE A ONE INTO TRE (RHCSI - BIT #14)
6977 ;THIS SHOULD NOT CLEAR MCPE OR SC
6978 021626 012777 040000 162224 MOV #TRE,@RHCSI ;WRITE "1" INTO TRE IN RHCSI
6979
6980
6981
6982 ;CHECK THAT RHCSI HAS 104200
6983 021634 012737 104200 001124 MOV #104200,$GDDAT ;GET GOOD = 124200
6984
6985 021642 017737 162212 001126 MOV @RHCSI,$BDDAT ;READ RHCSI FOR COMPARISON
6986 021650 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
6987 ;DATA WITH DATA READ FROM
6988 ;RHCSI
6989 021656 001401 BEQ 71$;BRANCH IF GOOD
6990 021660 104036 ERROR 36
6991 ;AFTER CLEARING THE RH AND
6992 ;DEVICE REGISTERS BY AN
6993 ;RH CLEAR
6994 ;RHER1 WAS CHECKED TO HAVE
6995 ;ZEROS
6996 ;WRONG PARITY CHECKING WAS
6997 ;SET BY "PAT" BIT IN RHCS2
6998 ;RHER1 WAS READ TO SET
6999 ;MCPE AND SC IN RHCSI
7000 ;ON WRITING "1" INTO TRE
7001 ;RHCSI SHOULD HAVE 104200
7002 ;=124200
7003 ;BUT CONTAINED WHAT IS
7004 ;GIVEN IN BAD RHCSI
7005 021662 71$:
7006
7007 ;NOW ERRORS WILL BE CLEARED BY RH CLEAR
7008 ;SET "CLR" BIT #5 IN RHCS2
7009 021662 012777 000040 162200 MOV #CLR,@RHCS2 ;CLEAR BY RH INIT
7010 021670 013777 005010 162172 MOV UNIT,@RHCS2 ;REINSTATE UNIT NUMBER

```

```

7011
7012
7013
7014 021676 012737 004200 001124 ;CHECK THAT RHCS1 HAS DVA!RDY
 MOV #DVA!RDY,$GDDAT ;GET GOOD = 4200
7015
7016 021704 017737 162150 001126 MOV @RHCS1,$BDDAT ;READ RHCS1 FOR COMPARISON
7017 021712 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
7018 ;DATA WITH DATA READ FROM
7019 ;RHCS1
7020 021720 001401 ;BRANCH IF GOOD
7021 021722 104037 BEQ 73$
 ERROR 37
7022 ;AFTER CLEARING THE RH AND
7023 ;DEVICE REGISTERS BY AN
7024 ;RH CLEAR
7025 ;RHER1 WAS CHECKED TO HAVE
7026 ;ZEROS
7027 ;WRONG PARITY CHECKING WAS
7028 ;SET BY "PAT" BIT IN RHCS2
7029 ;RHER1 WAS READ TO SET
7030 ;MCPE AND SC IN RHCS1
7031 ;ON WRITING "1" INTO TRE
7032 ;THEN SETTING "CLR" IN RHCS1
7033 ;RHCS1 SHOULD HAVE DVA!RDY
7034 ;=4200
7035 ;BUT CONTAINED WHAT IS
7036 ;GIVEN IN BAD RHCS1
7037 021724 73$:
7038 ;CHECK THAT RHCS2 HAS IR
7039 021724 012737 000100 001124 MOV #IR,$GDDAT ;GET GOOD = 100
7040 021732 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
7041
7042 021740 017737 162124 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
7043 021746 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
7044 ;DATA WITH DATA READ FROM
7045 ;RHCS2
7046 021754 001401 ;BRANCH IF GOOD
7047 021756 104040 BEQ 75$
 ERROR 40
7048 ;AFTER CLEARING THE RH AND
7049 ;DEVICE REGISTERS BY AN
7050 ;RH CLEAR
7051 ;RHER1 WAS CHECKED TO HAVE
7052 ;ZEROS
7053 ;WRONG PARITY CHECKING WAS
7054 ;SET BY "PAT" BIT IN RHCS2
7055 ;RHER1 WAS READ TO SET
7056 ;MCPE AND SC IN RHCS1
7057 ;ON WRITING "1" INTO TRE
7058 ;THEN SETTING "CLR" IN RHCS1
7059 ;RHCS2 SHOULD HAVE IR
7060 ;=100
7061 ;TOGETHER WITH UNIT NUMBER
7062 ;BUT CONTAINED WHAT IS
7063 ;GIVEN IN BAD RHCS2
7064 021760 75$:
7065 ;CHECK THAT RHCS3 HAS 0
7066 021760 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0

```



|      |        |        |        |        |       |                 |  |  |  |                                |
|------|--------|--------|--------|--------|-------|-----------------|--|--|--|--------------------------------|
| 7067 |        |        |        |        |       |                 |  |  |  |                                |
| 7068 | 021766 | 017737 | 162140 | 001126 | MOV   | DRHCS3,\$BDDAT  |  |  |  | ; READ RHCS3 FOR COMPARISON    |
| 7069 | 021774 | 023737 | 001124 | 001126 | CMP   | \$GDDAT,\$BDDAT |  |  |  | ; COMPARE EXPECTED             |
| 7070 |        |        |        |        |       |                 |  |  |  | ; DATA WITH DATA READ FROM     |
| 7071 |        |        |        |        |       |                 |  |  |  | ; RHCS3                        |
| 7072 | 022002 | 001401 |        |        | BEQ   | 77\$            |  |  |  | ; BRANCH IF GOOD               |
| 7073 | 022004 | 104041 |        |        | ERROR | 41              |  |  |  |                                |
| 7074 |        |        |        |        |       |                 |  |  |  | ; AFTER CLEARING THE RH AND    |
| 7075 |        |        |        |        |       |                 |  |  |  | ; DEVICE REGISTERS BY AN       |
| 7076 |        |        |        |        |       |                 |  |  |  | ; RH CLEAR                     |
| 7077 |        |        |        |        |       |                 |  |  |  | ; RHER1 WAS CHECKED TO HAVE    |
| 7078 |        |        |        |        |       |                 |  |  |  | ; ZEROS                        |
| 7079 |        |        |        |        |       |                 |  |  |  | ; WRONG PARITY CHECKING WAS    |
| 7080 |        |        |        |        |       |                 |  |  |  | ; SET BY "PAT" BIT IN RHCS2    |
| 7081 |        |        |        |        |       |                 |  |  |  | ; RHER1 WAS READ TO SET        |
| 7082 |        |        |        |        |       |                 |  |  |  | ; MCPE AND SC IN RHCS1         |
| 7083 |        |        |        |        |       |                 |  |  |  | ; ON WRITING "1" INTO TRE      |
| 7084 |        |        |        |        |       |                 |  |  |  | ; THEN SETTING "CLR" IN RHCS1  |
| 7085 |        |        |        |        |       |                 |  |  |  | ; RHCS3 SHOULD HAVE 0          |
| 7086 |        |        |        |        |       |                 |  |  |  | ; BUT CONTAINED WHAT IS        |
| 7087 |        |        |        |        |       |                 |  |  |  | ; GIVEN IN BAD RHCS3           |
| 7088 | 022006 |        |        |        |       |                 |  |  |  |                                |
| 7089 |        |        |        |        |       |                 |  |  |  | 77\$: ; CHECK THAT RHBA HAS 0  |
| 7090 | 022006 | 012737 | 000000 | 001124 | MOV   | #0,\$GDDAT      |  |  |  | ; GET GOOD = 0                 |
| 7091 |        |        |        |        |       |                 |  |  |  |                                |
| 7092 | 022014 | 017737 | 162044 | 001126 | MOV   | DRHBA,\$BDDAT   |  |  |  | ; READ RHBA FOR COMPARISON     |
| 7093 | 022022 | 023737 | 001124 | 001126 | CMP   | \$GDDAT,\$BDDAT |  |  |  | ; COMPARE EXPECTED             |
| 7094 |        |        |        |        |       |                 |  |  |  | ; DATA WITH DATA READ FROM     |
| 7095 |        |        |        |        |       |                 |  |  |  | ; RHBA                         |
| 7096 | 022030 | 001401 |        |        | BEQ   | 79\$            |  |  |  | ; BRANCH IF GOOD               |
| 7097 | 022032 | 104042 |        |        | ERROR | 42              |  |  |  |                                |
| 7098 |        |        |        |        |       |                 |  |  |  | ; AFTER CLEARING THE RH AND    |
| 7099 |        |        |        |        |       |                 |  |  |  | ; DEVICE REGISTERS BY AN       |
| 7100 |        |        |        |        |       |                 |  |  |  | ; RH CLEAR                     |
| 7101 |        |        |        |        |       |                 |  |  |  | ; RHER1 WAS CHECKED TO HAVE    |
| 7102 |        |        |        |        |       |                 |  |  |  | ; ZEROS                        |
| 7103 |        |        |        |        |       |                 |  |  |  | ; WRONG PARITY CHECKING WAS    |
| 7104 |        |        |        |        |       |                 |  |  |  | ; SET BY "PAT" BIT IN RHCS2    |
| 7105 |        |        |        |        |       |                 |  |  |  | ; RHER1 WAS READ TO SET        |
| 7106 |        |        |        |        |       |                 |  |  |  | ; MCPE AND SC IN RHCS1         |
| 7107 |        |        |        |        |       |                 |  |  |  | ; ON WRITING "1" INTO TRE      |
| 7108 |        |        |        |        |       |                 |  |  |  | ; THEN SETTING "CLR" IN RHCS1  |
| 7109 |        |        |        |        |       |                 |  |  |  | ; RHBA SHOULD HAVE 0           |
| 7110 |        |        |        |        |       |                 |  |  |  | ; BUT CONTAINED WHAT IS        |
| 7111 |        |        |        |        |       |                 |  |  |  | ; GIVEN IN BAD RHBA            |
| 7112 | 022034 |        |        |        |       |                 |  |  |  |                                |
| 7113 |        |        |        |        |       |                 |  |  |  | 79\$: ; CHECK THAT RHBAE HAS 0 |
| 7114 | 022034 | 012737 | 000000 | 001124 | MOV   | #0,\$GDDAT      |  |  |  | ; GET GOOD = 0                 |
| 7115 |        |        |        |        |       |                 |  |  |  |                                |
| 7116 | 022042 | 017737 | 162062 | 001126 | MOV   | DRHBAE,\$BDDAT  |  |  |  | ; READ RHBAE FOR COMPARISON    |
| 7117 | 022050 | 023737 | 001124 | 001126 | CMP   | \$GDDAT,\$BDDAT |  |  |  | ; COMPARE EXPECTED             |
| 7118 |        |        |        |        |       |                 |  |  |  | ; DATA WITH DATA READ FROM     |
| 7119 |        |        |        |        |       |                 |  |  |  | ; RHBAE                        |
| 7120 | 022056 | 001401 |        |        | BEQ   | 81\$            |  |  |  | ; BRANCH IF GOOD               |
| 7121 | 022060 | 104043 |        |        | ERROR | 43              |  |  |  |                                |
| 7122 |        |        |        |        |       |                 |  |  |  | ; AFTER CLEARING THE RH AND    |

7123  
7124  
7125  
7126  
7127  
7128  
7129  
7130  
7131  
7132  
7133  
7134  
7135  
7136  
7137  
7138  
7139  
7140  
7141  
7142  
7143  
7144  
7145  
7146  
7147  
7148  
7149  
7150  
7151  
7152  
7153  
7154  
7155  
7156  
7157  
7158  
7159  
7160  
7161  
7162  
7163  
7164  
7165  
7166  
7167  
7168  
7169  
7170  
7171  
7172  
7173  
7174  
7175  
7176  
7177  
7178

022062

022062

022070

022076

022104

022106

022110

012737

017737

023737

001401

104044

000000

161766

001124

001124

001126

000004

001000

81\$:

83\$:

;CHECK THAT RHC HAS 0  
MOV #0,\$GDDAT

MOV 2RHWC,\$BDDAT  
CMP \$GDDAT,\$BDDAT

BEQ 83\$  
ERROR 44

\*\*\*\*\*  
\*TEST 22 RHCS1 - MCPE BIT #13 (PARITY LINE = 1)

\* AN RH CLEAR (SET BIT #5 IN RHCS2) IS GIVEN TO CLEAR  
\* ALL DEVICE REGISTERS  
\* WRITE A ONE INTO DISK ADDRESS REGISTER (RHDA)  
\* (IN TAPE DRIVES CALLED REGISTER)  
\* SET "PAT" (RHCS2 BIT #4) THIS WILL INVERT THE PARITY CHECKING  
\* READ RHDA AND COMPARE IT HAS ONE IN IT  
\* THIS READING SHOULD SET SC, MCPE IN RHCS1  
\* CHECK RHCS1 TO HAVE ONLY R0Y SET  
\* CHECK RHCS2, RHCS3, RHBA, RHBAE, RHC TO HAVE APPROPRIATE  
\* VALUES

\*\*\*\*\*  
\*ST22: SCOPE  
MOV #STACK,SP ;RESET STACK

;DEVICE REGISTERS BY AN  
;RH CLEAR  
;RHER1 WAS CHECKED TO HAVE  
;ZEROS  
;WRONG PARITY CHECKING WAS  
;SET BY "PAT" BIT IN RHCS2  
;RHER1 WAS READ TO SET  
;MCPE AND SC IN RHCS1  
;ON WRITING "1" INTO TRE  
;THEN SETTING "CLR" IN RHCS1  
;RHBAE SHOULD HAVE 0  
;BUT CONTAINED WHAT IS  
;GIVEN IN BAD RHBAE

;GET GOOD = 0

;READ RHC FOR COMPARISON  
;COMPARE EXPECTED  
;DATA WITH DATA READ FROM  
;RHC  
;BRANCH IF GOOD

;AFTER CLEARING THE RH AND  
;DEVICE REGISTERS BY AN  
;RH CLEAR  
;RHER1 WAS CHECKED TO HAVE  
;ZEROS  
;WRONG PARITY CHECKING WAS  
;SET BY "PAT" BIT IN RHCS2  
;RHER1 WAS READ TO SET  
;MCPE AND SC IN RHCS1  
;ON WRITING "1" INTO TRE  
;THEN SETTING "CLR" IN RHCS1  
;RHC SHOULD HAVE 0  
;BUT CONTAINED WHAT IS  
;GIVEN IN BAD RHC





7291  
7292  
7293  
7294  
7295  
7296  
7297  
7298  
7299  
7300  
7301  
7302  
7303  
7304  
7305  
7306  
7307  
7308  
7309  
7310  
7311  
7312  
7313  
7314  
7315  
7316  
7317  
7318  
7319  
7320  
7321  
7322  
7323  
7324  
7325  
7326  
7327  
7328  
7329  
7330  
7331  
7332  
7333  
7334  
7335  
7336  
7337  
7338  
7339  
7340  
7341  
7342  
7343  
7344  
7345  
7346

022330

022330

022336

022344

022352

022354

022356

022356

022364

022372

022400

022402

022404

73\$:

;CHECK THAT RHBAE HAS 0  
MOV #0,\$GDDAT

MOV @RHBAE,\$BDDAT  
CMP \$GDDAT,\$BDDAT

BEQ 75\$  
ERROR 52

75\$:

;CHECK THAT RHC HAS 0  
MOV #0,\$GDDAT

MOV @RHC,\$BDDAT  
CMP \$GDDAT,\$BDDAT

BEQ 77\$  
ERROR 53

77\$:

::\*\*\*\*\*  
:\*TEST 23 TEST DUPLICATED A16 (RHCS1 BIT #8)

::\* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)  
:\* MOVE 400 (ONE INTO A16) IN RHCS1  
:\* READ RHCS1 TO CONTAIN 600 (BIT #8 AND RDY)  
:\* READ RHBAE TO CONTAIN "1" (BIT #0 HIGH)

::\* MOVE 0 INTO RHBAE (WRITING 0 INTO RHBAE BIT #0)

; THEN THE ADDRESS REGISTER  
; WAS READ BACK  
; RHBA SHOULD HAVE 0  
; BUT CONTAINED WHAT IS  
; GIVEN IN BAD RHBA

; GET GOOD = 0

; READ RHBAE FOR COMPARISON  
; COMPARE EXPECTED  
; DATA WITH DATA READ FROM  
; RHBAE  
; BRANCH IF GOOD

; AFTER AN RH CLEAR "1"  
; WAS WRITTEN INTO ADDRESS REGISTER  
; (FRAME COUNT IN TAPE)  
; PAT IN RHCS2 WAS SET  
; THEN THE ADDRESS REGISTER  
; WAS READ BACK  
; RHBAE SHOULD HAVE 0  
; BUT CONTAINED WHAT IS  
; GIVEN IN BAD RHBAE

; GET GOOD = 0

; READ RHC FOR COMPARISON  
; COMPARE EXPECTED  
; DATA WITH DATA READ FROM  
; RHC  
; BRANCH IF GOOD

; AFTER AN RH CLEAR "1"  
; WAS WRITTEN INTO ADDRESS REGISTER  
; (FRAME COUNT IN TAPE)  
; PAT IN RHCS2 WAS SET  
; THEN THE ADDRESS REGISTER  
; WAS READ BACK  
; RHC SHOULD HAVE 0  
; BUT CONTAINED WHAT IS  
; GIVEN IN BAD RHC



```

7403 022506 67$:
7404
7405 ;NOW MOVE 0 INTO RHBAE (WRITING 0 INTO RHBAE BIT #0)
7406 022506 005077 161416 CLR @RHBAE ;WRITE ZERO INTO RHBAE
7407
7408
7409 ;CHECK THAT RHBAE HAS 0
7410 022512 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
7411
7412 022520 017737 161404 001126 MOV @RHBAE,$BDDAT ;READ RHBAE FOR COMPARISON
7413 022526 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
7414 ;DATA WITH DATA READ FROM
7415 ;RHBAE
7416 022534 001401 BEQ 69$;BRANCH IF GOOD
7417 022536 104056 ERROR 56
7418 ;AFTER SETTING "CLR" BIT #5
7419 ;IN RHCS2 TO INIT THE RH
7420 ;A16 WAS WRITTEN INTO RHCS1
7421 ;RHCS1 WAS READ
7422 ;RHBAE WAS READ
7423 ;THEN ZERO WAS WRITTEN
7424 ;INTO RHBAE
7425 ;ON READING RHBAE
7426 ;RHBAE SHOULD HAVE 0
7427 ;BUT CONTAINED WHAT IS
7428 ;GIVEN IN BAD RHBAE
7429 022540 69$:
7430
7431
7432 ;CHECK THAT RHCS1 HAS DVA!RDY
7433 022540 012737 004200 001124 MOV #DVA!RDY,$GDDAT ;GET GOOD = 4200
7434
7435 022546 017737 161306 001126 MOV @RHCS1,$BDDAT ;READ RHCS1 FOR COMPARISON
7436 022554 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
7437 ;DATA WITH DATA READ FROM
7438 ;RHCS1
7439 022562 001401 BEQ 71$;BRANCH IF GOOD
7440 022564 104057 ERROR 57
7441 ;AFTER SETTING "CLR" BIT #5
7442 ;IN RHCS2 TO INIT THE RH
7443 ;A16 WAS WRITTEN INTO RHCS1
7444 ;RHCS1 WAS READ
7445 ;RHBAE WAS READ
7446 ;THEN ZERO WAS WRITTEN
7447 ;INTO RHBAE
7448 ;RHBAE WAS READ
7449 ;ON READING RHCS1
7450 ;RHCS1 SHOULD HAVE DVA!RDY
7451 ;=4200
7452 ;BUT CONTAINED WHAT IS
7453 ;GIVEN IN BAD RHCS1
7454 022566 71$:
7455
7456
7457 ;*****
7458 ;*TEST 24 TEST DUPLICATED A17 (RHCS1 BIT #9)

```

```

7459
7460
7461
7462
7463
7464
7465
7466
7467
7468
7469
7470
7471
7472 022566 000004
7473 022570 012706 001000
7474 022574 012737 000024 004656
7475
7476 022602 004737 040322
7477
7478
7479
7480
7481 022606 012777 001000 161244
7482
7483
7484
7485
7486 022614 012737 005200 001124
7487
7488 022622 017737 161232 001126
7489 022630 023737 001124 001126
7490
7491
7492 022636 001401
7493 022640 104060
7494
7495
7496
7497
7498
7499
7500
7501
7502 022642
7503
7504
7505
7506 022642 012737 000002 001124
7507
7508 022650 017737 161254 001126
7509 022656 023737 001124 001126
7510
7511
7512 022664 001401
7513 022666 104061
7514

```

```

: * CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
: * MOVE 400 (ONE INTO A17) IN RHCSI
: * READ RHCSI TO CONTAIN 1200 (BIT #9 AND RDY)
: * READ RHBAE TO CONTAIN "2" (BIT #1 HIGH)

: * MOVE 0 INTO RHBAE (WRITING 0 INTO RHBAE BIT #1)
: * READ RHBAE TO CONTAIN 2
: * READ RHCSI TO CONTAIN ONLY RDY (BIT #9 IN RHCSI IS ZERO)

: *****
: ST24: SCOPE
: MOV #STACK, SP ; RESET STACK
: MOV #24, @#TSTNM ; SAVE TEST NUMBER

: JSR PC, @#CLDISK ; GIVE RH INITIALIZE
: ; SETUP UNIT NUMBER
: ; CLEAR RHC AND FUNCTION BITS IN RHCSI

: WRITE "1" INTO A17 IN RHCSI
: MOV #A17, @RHCSI ; MOVE 1200 INTO RHCSI

: CHECK THAT RHCSI HAS A17!DVA!RDY
: MOV #A17!DVA!RDY, $GDDAT ; GET GOOD = 4600

: MOV @RHCSI, $BDDAT ; READ RHCSI FOR COMPARISON
: CMP $GDDAT, $BDDAT ; COMPARE EXPECTED
: ; DATA WITH DATA READ FROM
: ; RHCSI
: BEQ 65$; BRANCH IF GOOD
: ERROR 60

: AFTER SETTING "CLR" BIT #5
: IN RHCS2 TO INIT THE RH
: A17 WAS WRITTEN INTO RHCSI
: RHCSI WAS READ
: RHCSI SHOULD HAVE A17!DVA!RDY
: =4600
: BUT CONTAINED WHAT IS
: GIVEN IN BAD RHCSI

: CHECK THAT RHBAE HAS BIT1
: MOV #BIT1, $GDDAT ; GET GOOD = 2

: MOV @RHBAE, $BDDAT ; READ RHBAE FOR COMPARISON
: CMP $GDDAT, $BDDAT ; COMPARE EXPECTED
: ; DATA WITH DATA READ FROM
: ; RHBAE
: BEQ 67$; BRANCH IF GOOD
: ERROR 61

: AFTER SETTING "CLR" BIT #5

```





7571  
7572  
7573  
7574 022750  
7575  
7576  
7577  
7578  
7579  
7580  
7581  
7582  
7583  
7584  
7585  
7586  
7587  
7588  
7589  
7590  
7591  
7592 022750 000004  
7593 022752 012706 001000  
7594 022756 012737 000025 004656  
7595  
7596 022764 004737 040322  
7597  
7598  
7599  
7600  
7601 022770 012777 000100 161062  
7602  
7603  
7604  
7605  
7606 022776 012737 004300 001124  
7607  
7608 023004 017737 161050 001126  
7609 023012 023737 001124 001126  
7610  
7611  
7612 023020 001401  
7613 023022 104064  
7614  
7615  
7616  
7617  
7618  
7619  
7620  
7621  
7622 023024  
7623  
7624  
7625  
7626 023024 012737 000100 001124

71\$:  
;=4200  
;BUT CONTAINED WHAT IS  
;GIVEN IN BAD RHCS1  
;\*\*\*\*\*  
;\*TEST 25 TEST DUPLICATED IE (RHCS1 BIT #6)  
;\* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)  
;\* MOVE 100 (ONE INTO IE) IN RHCS1  
;\* READ RHCS1 TO CONTAIN 300 (BIT #6 AND RDY)  
;\* READ RHCS3 TO CONTAIN "100" (BIT #6 HIGH)  
;\*  
;\* MOVE 0 INTO RHCS3 (WRITING 0 INTO RHCS3 BIT #6)  
;\* READ RHCS3 TO CONTAIN 100  
;\* READ RHCS1 TO CONTAIN ONLY RDY (BIT #6 IN RHCS1 IS ZERO)  
;\*  
;\*\*\*\*\*  
TST25: SCOPE  
MOV #STACK,SP ;RESET STACK  
MOV #25,#TSTNM ;SAVE TEST NUMBER  
JSR PC,#CLDISK ;GIVE RH INITIALIZE  
;SETUP UNIT NUBER  
;CLEAR RHWC AND FUNCTION BITS IN RHCS1  
;WRITE "1" INTO IE IN RHCS1  
MOV #IE,#RHCS1 ;MOVE 100 INTO RHCS1  
;CHECK THAT RHCS1 HAS IE!DVA!RDY  
MOV #IE!DVA!RDY,\$GDDAT ;GET GOOD = 4300  
MOV #RHCS1,\$BDDAT ;READ RHCS1 FOR COMPARISON  
CMP \$GDDAT,\$BDDAT ;COMPARE EXPECTED  
;DATA WITH DATA READ FROM  
;RHCS1  
BEQ 65\$ ;BRANCH IF GOOD  
ERROR 64  
;AFTER SETTING "CLR" BIT #5  
;IN RHCS2 TO INIT THE RH  
;IE WAS WRITTEN INTO RHCS1  
;RHCS1 WAS READ  
;RHCS1 SHOULD HAVE IE!DVA!RDY  
;=4300  
;BUT CONTAINED WHAT IS  
;GIVEN IN BAD RHCS1  
65\$:  
;CHECK THAT RHCS3 HAS IE  
MOV #IE,\$GDDAT ;GET GOOD = 1



7683  
7684  
7685  
7686  
7687  
7688  
7689  
7690  
7691  
7692  
7693  
7694  
7695  
7696  
7697  
7698  
7699  
7700  
7701  
7702  
7703  
7704  
7705  
7706  
7707  
7708  
7709  
7710  
7711  
7712  
7713  
7714  
7715  
7716  
7717  
7718  
7719  
7720  
7721  
7722  
7723  
7724  
7725  
7726  
7727  
7728  
7729  
7730  
7731  
7732  
7733  
7734  
7735  
7736  
7737  
7738

023132

715:

; IE WAS WRITTEN INTO RHCSI  
; RHCSI WAS READ  
; RHCS3 WAS READ  
; THEN ZERO WAS WRITTEN  
; INTO RHCS3  
; RHCS3 WAS READ  
; ON READING RHCSI  
; RHCSI SHOULD HAVE DVA!RDY  
; =4200  
; BUT CONTAINED WHAT IS  
; GIVEN IN BAD RHCSI

\*\*\*\*\*  
; \*TEST 26 RHCSI PROGRAM ERROR (PGE BIT #10)

;\* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)  
;\* SET UP FOR A 10 WORD WRITE  
;\* SET "GO" (RHCSI BIT #0) TWICE IN TWO SUCCESSIVE  
;\* INSTRUCTIONS  
;\* THIS SHOULD SET, SC AND TRE IN RHCSI  
;\* AND PGE SHOULD BE SET IN RHCS2  
;\* RHCS3, ARE CHECKED  
;\* THE NUMBER OF WORDS ARE LARGE ENOUGH SO THAT AFTER  
;\* ONE "BIS" INSTRUCTION TO SET "GO" IN RHCSI  
;\* THERE IS SUFFICIENT TIME TO GIVE ANOTHER "BIS" INSTRUCTION  
;\* TO SET "GO" BEFORE THE FIRST "GO" HAS TIME TO COMPLETE

\*\*\*\*\*

†ST26: SCOPE  
MOV #STACK, SP ; RESET STACK  
MOV #26, #†STNM ; SAVE TEST NUMBER  
JSR PC, #CLDISK ; GIVE RH INITIALIZE  
; SETUP UNIT NUBER  
; CLEAR RHWC AND FUNCTION BITS IN RHCSI

; SET UP RH FOR A 10 WORD WRITE  
MOV #-10, #RHWC ; WORD COUNT REGISTER=10  
MOV #WRFROM, #RHBA ; BUS ADDRESS REGISTER=WRITBUF  
; WRITE 10 WORDS FROM "WRFROM" INTO  
; WHAT EVER RH DEVICE IS AVAILABLE  
MOV #-1, #NOGO ; DO NOT GIVE GO IN COMMAND ROUTINE  
JSR RO, #COMND ; GO TO DO COMMAND  
WRIDAT ; WRITE DATA  
BIS #GO, #RHCSI ; SET GO  
BIS #GO, #RHCSI ; SET GO WITHOUT TIME TO COMPLET LAST GO

; CHECK THAT RHCSI HAS SC!DVA!TRE!61  
MOV #SC!DVA!TRE!61, #GDDAT ; GET GOOD = 144000

MOV #RHCSI, #BDDAT ; READ RHCSI FOR COMPARISON  
CMP #GDDAT, #BDDAT ; COMPARE EXPECTED  
; DATA WITH DATA READ FROM

```

7739 ;RHCS1
7740 023240 001401 BEQ 65$
7741 023242 104070 ERROR 70
7742 ;AFTER SETTING "CLR" BIT #5
7743 ;IN RHCS2 TO INIT THE RH
7744 ;AND GIVING TWO SUCCESSIVE
7745 ;"GO" WITHOUT GIVING TIME FOR
7746 ;THE FIRST TO COMPLETE
7747 ;RHCS1 SHOULD HAVE SC!DVA!TRE!5!
7748 ;=144000
7749 ;BUT CONTAINED WHAT IS
7750 ;GIVEN IN BAD RHCS1
7751 023244 65$:
7752 ;CHECK THAT RHCS2 HAS PGE!OR
7753 023244 012737 002200 001124 MOV #PGE!OR,$GDDAT ;GET GOOD = 2000
7754 023252 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
7755
7756 023260 017737 160604 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
7757 023266 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
7758 ;DATA WITH DATA READ FROM
7759 ;RHCS2
7760 023274 001401 BEQ 67$
7761 023276 104071 ERROR 71
7762 ;AFTER SETTING "CLR" BIT #5
7763 ;IN RHCS2 TO INIT THE RH
7764 ;AND GIVING TWO SUCCESSIVE
7765 ;"GO" WITHOUT GIVING TIME FOR
7766 ;THE FIRST TO COMPLETE
7767 ;RHCS2 SHOULD HAVE PGE!OR
7768 ;=2000
7769 ;TOGETHER WITH UNIT NUMBER
7770 ;BUT CONTAINED WHAT IS
7771 ;GIVEN IN BAD RHCS2
7772 023300 67$:
7773 ;CHECK THAT RHCS3 HAS DBL
7774 023300 012737 002000 001124 MOV #DBL,$GDDAT ;GET GOOD = 0
7775
7776 023306 017737 160620 001126 MOV @RHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON
7777 023314 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
7778 ;DATA WITH DATA READ FROM
7779 ;RHCS3
7780 023322 001401 BEQ 69$
7781 023324 104072 ERROR 72
7782 ;AFTER SETTING "CLR" BIT #5
7783 ;IN RHCS2 TO INIT THE RH
7784 ;AND GIVING TWO SUCCESSIVE
7785 ;"GO" WITHOUT GIVING TIME FOR
7786 ;THE FIRST TO COMPLETE
7787 ;RHCS3 SHOULD HAVE DBL
7788 ;BUT CONTAINED WHAT IS
7789 ;GIVEN IN BAD RHCS3
7790 023326 69$:
7791
7792
7793 ;*****
7794 ;*TEST 27 RHCS2 - BUS ADDRESS INHIBIT BIT #3

```

```

7795
7796
7797
7798
7799
7800
7801
7802
7803
7804
7805
7806
7807
7808
7809
7810
7811
7812
7813
7814
7815
7816
7817 023326 000004
7818 023330 012706 001000
7819 023334 012737 000027 004656
7820
7821 023342 004737 040322
7822
7823
7824
7825
7826
7827 023346 012777 177766 160506
7828 023354 052777 000010 160506
7829 023362 012777 004210 160474
7830 023370 004077 161244
7831 023374 004154
7832
7833
7834
7835 023376 012737 004260 001124
7836
7837 023404 017737 160450 001126
7838 023412 023737 001124 001126
7839
7840
7841 023420 001401
7842 023422 104076
7843
7844
7845
7846
7847
7848
7849
7850

```

```

: * CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #6)
: * SET UP FOR A 2 WORD WRITE FROM A BUFFER TAGGED "WRFROM"
: * SET BUS ADDRESS INHIBIT RHCS2 BIT #3 "BAI"
: * AT THE END OF WRITE CHECK
: * RHCS1 TO HAVE ONLY RDY AND COMMAND
: * RHCS2 TO HAVE BAI
: * RHCS3 TO HAVE 0
: * RHBA TO HAVE ADDRESS OF "WRFROM"
: * RHBAE AND RHWC TO HAVE ZEROS

: * NOW SET UP READ FOR THE SAME DATA WITH
: * BAI SET TO READ INTO A BUFFER TAGGED "REINTO"
: * AFTER READ CHECK
: * RHCS1 TO HAVE ONLY RDY AND COMMAND
: * RHCS2 TO HAVE BAI
: * RHCS3 TO HAVE 0
: * RHBA TO HAVE ADDRESS OF "REINTO"
: * RHBAE AND RHWC TO HAVE ZEROS
: * DATA IN REINTO BUFFER IS CHECKED WITH DATA IN
: * WRFROM BUFFER
: *****
†ST27: SCOPE
MOV #STACK,SP ;RESET STACK
MOV #27,‡#†STNM ;SAVE TEST NUMBER
JSR PC,‡#CLDISK ;GIVE RH INITIALIZE
;SETUP UNIT NUBER
;CLEAR RHWC AND FUNCTION BITS IN RHCS1

;SET UP 10 WORD WRITE FROM BUFFER TAGGED "WRFROM"
;WITH BAI IN RHCS2
MOV #-10,‡RHWC ;WORD COUNT REGISTER=10
BIS #BAI,‡RHCS2 ;BUS ADDRESS INHIBIT IN RHCS2
MOV #WRFROM,‡RHBA ;BUS ADDRESS REGISTER=WRFROM
JSR RO,‡COMND ;GO TO DO COMMAND
WRIDAT ;WRITE DATA

;CHECK THAT RHCS1 HAS DVA!RDY!60
MOV #DVA!RDY!60,$GDDAT ;GET GOOD = 4252

MOV ‡RHCS1,$BDDAT ;READ RHCS1 FOR COMPARISON
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
;DATA WITH DATA READ FROM
;RHCS1
;BRANCH IF GOOD

;AFTER SETTING "CLR" BIT #5
;IN RHCS2 TO INIT THE RH
;A 2 WORD WRITE WAS DONE
;WITH BAI BIT IN RHCS2 SET
;AT END OF WRITE
;RHCS1 SHOULD HAVE DVA!RDY!60
;=4252
;BUT CONTAINED WHAT IS

```



```

7907 ;BUT CONTAINED WHAT IS
7908 ;GIVEN IN BAD RHBA
7909 023534 71$:
7910 ;CHECK THAT RHBAE HAS 0
7911 023534 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
7912
7913 023542 017737 160362 001126 MOV @RHBAE,$BDDAT ;READ RHBAE FOR COMPARISON
7914 023550 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
7915 ;DATA WITH DATA READ FROM
7916 ;RHBAE
7917 023556 001401 BEQ 73$;BRANCH IF GOOD
7918 023560 104102 ERROR 102
7919
7920 ;AFTER SETTING "CLR" BIT #5
7921 ;IN RHCS2 TO INIT THE RH
7922 ;A 2 WORD WRITE WAS DONE
7923 ;WITH BAI BIT IN RHCS2 SET
7924 ;AT END OF WRITE
7925 ;RHBAE SHOULD HAVE 0
7926 ;BUT CONTAINED WHAT IS
7927 023562 73$:
7928 ;CHECK THAT RHWC HAS 0
7929 023562 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
7930
7931 023570 017737 160266 001126 MOV @RHWC,$BDDAT ;READ RHWC FOR COMPARISON
7932 023576 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
7933 ;DATA WITH DATA READ FROM
7934 ;RHWC
7935 023604 001401 BEQ 75$;BRANCH IF GOOD
7936 023606 104103 ERROR 103
7937
7938 ;AFTER SETTING "CLR" BIT #5
7939 ;IN RHCS2 TO INIT THE RH
7940 ;A 2 WORD WRITE WAS DONE
7941 ;WITH BAI BIT IN RHCS2 SET
7942 ;AT END OF WRITE
7943 ;RHWC SHOULD HAVE 0
7944 ;BUT CONTAINED WHAT IS
7945 023610 75$:
7946 ;GIVEN IN BAD RHWC
7947
7948
7949
7950 ;*****
7951 *TEST 30 RHCS2 MDPE BIT #8 AND RHCS3 IPCKO BIT #0
7952 * CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
7953 * SET IPCKO (RHCS3 BIT #0)
7954 * MOVE ALL ZEROS INTO RHDB ONCE
7955 * THIS SHOULD SET TRE SC IN RHCS1
7956 * READ RHDB ONCE THIS SHOULD SET MDPE (RHCS2 BIT #9)
7957 * CHECK RHCS1 FOR RDY (BIT #7), TRE (BIT #14), SC (BIT #15)
7958 * "CLR" (RHCS2 BIT #5) IS GIVEN
7959 * ALL ERRORS ARE CLEARED
7960 * CHECK RHCS1, RHCS2, RHCS3, RHBA, RHBAE, RHWC
7961 * *****
7962 023610 000004 ;TST30: SCOPE

```



MAINDEC-11-DEHAC-A  
 DEHAC.P11 T30

MACY11 27(732) 09-SEP-76 07:55 PAGE 151  
 RHSC2 MDPE BIT #8 AND RHCS3 IPCKO BIT #0

```

7963 023612 012706 001000 MOV #STACK,SP ;RESET STACK
7964 023616 012737 000030 004656 MOV #30,#TSTNM ;SAVE TEST NUMBER
7965
7966 023624 004737 040322 JSR PC,#CLDISK ;GIVE RH INITIALIZE
7967 ;SETUP UNIT NUBER
7968 ;CLEAR RHWC AND FUNCTION BITS IN RHCS1
7969 023630 012737 000000 004662 MOV #0,IP ;IPCK BIT NO. FOR PRINTOUT
7970
7971 023636 052777 000001 160266 BIS #IPCKO,#RHCS3 ;SET IPCKO IN RHCS3-BIT #0
7972 023644 005037 004210 CLR WRFROM ;WRITE ZERO INTO LOCATION
7973 023650 013777 004210 160224 MOV WRFROM,#RHDB ;WRITE ZEROS INTO RHDB ONCE
7974
7975 ;CHECK THAT RHCS1 HAS SC!TRE!DVA!RDY
7976 023656 012737 144200 001124 MOV #SC!TRE!DVA!RDY,$GDDAT ;GET GOOD = 144200
7977
7978 023664 017737 160170 001126 MOV #RHCS1,$BDDAT ;READ RHCS1 FOR COMPARISON
7979 023672 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
7980 ;DATA WITH DATA READ FROM
7981 ;RHCS1
7982 023700 001401 BEQ 65$;BRANCH IF GOOD
7983 023702 104140 ERROR 140
7984 ;AFTER SETTING "CLR" BIT #5
7985 ;IN RHCS2 TO INIT THE RH
7986 ;IPCKO BIT #0 RHCS3 WAS SET
7987 ;ZEROS WERE MOVED INTO RHDB
7988 ;RHCS1 SHOULD HAVE SC!TRE!DVA!RDY
7989 ;=144200
7990 ;BUT CONTAINED WHAT IS
7991 ;GIVEN IN BAD RHCS1
7992 023704
7993 023704 017737 160172 001200 65$: MOV #RHDB,$TMP1 ;READ RHDB ONCE
7994
7995
7996 ;CHECK THAT RHCS3 HAS 1
7997 023712 012737 000001 001124 MOV #1,$GDDAT ;GET GOOD = 1
7998
7999 023720 017737 160206 001126 MOV #RHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON
8000 023726 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
8001 ;DATA WITH DATA READ FROM
8002 ;RHCS3
8003 023734 001401 BEQ 67$;BRANCH IF GOOD
8004 023736 104104 ERROR 104
8005 ;AFTER SETTING "CLR" BIT #5
8006 ;IN RHCS2 TO INIT THE RH
8007 ;IPCKO BIT #0 RHCS3 WAS SET
8008 ;ZEROS WERE MOVED INTO
8009 ;RHDB
8010 ;RHDB WAS READ THEN
8011 ;RHCS3 SHOULD HAVE 1
8012 ;=1
8013 ;BUT CONTAINED WHAT IS
8014 ;GIVEN IN BAD RHCS3
8015 023740
8016 67$:
8017
8018 023740 012737 000500 001124 ;CHECK THAT RHCS2 HAS MDPE!IR
 MOV #MDPE!IR,$GDDAT ;GET GOOD = 500

```

```

8019 023746 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
8020
8021 023754 017737 160110 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
8022 023762 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
8023
8024
8025 023770 001401 BEQ 69$;DATA WITH DATA READ FROM
8026 023772 104105 ERROR 105 ;RHCS2
 ;BRANCH IF GOOD
8027
8028
8029
8030
8031
8032
8033
8034
8035
8036
8037
8038 023774 69$:
8039
8040
8041 023774 004737 040322 JSR PC,@#CLDISK ;GIVE RH INITIALIZE
8042
8043
8044
8045
8046
8047 024000 012737 004200 001124 MOV #RDY!DVA,$GDDAT ;CHECK THAT RHCS1 HAS RDY!DVA
 ;GET GOOD = 4200
8048
8049 024006 017737 160046 001126 MOV @RHCS1,$BDDAT ;READ RHCS1 FOR COMPARISON
8050 024014 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
8051
8052
8053 024022 001401 BEQ 71$;DATA WITH DATA READ FROM
8054 024024 104106 ERROR 106 ;RHCS1
 ;BRANCH IF GOOD
8055
8056
8057
8058
8059
8060
8061
8062
8063
8064
8065
8066
8067
8068 024026 71$:
8069
8070 024026 012737 000100 001124 MOV #IR,$GDDAT ;CHECK THAT RHCS2 HAS IR
8071 024034 053737 005010 001124 BIS UNIT,$GDDAT ;GET GOOD = 100
 ;INCLUDE UNIT NUMBER
8072
8073 024042 017737 160022 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
8074 024050 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED

```



```

8131 ; AN RH CLEAR (RHCS2 BIT #5)
8132 ; WAS GIVEN THIS SHOULD
8133 ; CLEAR ALL ERRORS
8134 ; RHBA SHOULD HAVE 0
8135 ; BUT CONTAINED WHAT IS
8136 ; GIVEN IN BAD RHBA
8137 024136 77$:
8138 ; CHECK THAT RHBAE HAS 0
8139 024136 012737 000000 001124 MOV #0,$GDDAT ; GET GOOD = 0
8140
8141 024144 017737 157760 001126 MOV @RHBAE,$BDDAT ; READ RHBAE FOR COMPARISON
8142 024152 023737 001124 001126 CMP $GDDAT,$BDDAT ; COMPARE EXPECTED
8143 ; DATA WITH DATA READ FROM
8144 ; RHBAE
8145 024160 001401 BEQ 79$; BRANCH IF GOOD
8146 024162 104112
8147
8148 ; AFTER SETTING "CLR" BIT #5
8149 ; IN RHCS2 TO INIT THE RH
8150 ; IPCKO BIT #0 RHCS3 WAS SET
8151 ; ZEROS WERE MOVED INTO
8152 ; RHDB
8153 ; RHDB WAS READ THEN
8154 ; AN RH CLEAR (RHCS2 BIT #5)
8155 ; WAS GIVEN THIS SHOULD
8156 ; CLEAR ALL ERRORS
8157 ; RHBAE SHOULD HAVE 0
8158 ; BUT CONTAINED WHAT IS
8159 ; GIVEN IN BAD RHBAE
8159 024164 79$:
8160 ; CHECK THAT RHWC HAS 0
8161 024164 012737 000000 001124 MOV #0,$GDDAT ; GET GOOD = 0
8162
8163 024172 017737 157664 001126 MOV @RHWC,$BDDAT ; READ RHWC FOR COMPARISON
8164 024200 023737 001124 001126 CMP $GDDAT,$BDDAT ; COMPARE EXPECTED
8165 ; DATA WITH DATA READ FROM
8166 ; RHWC
8167 024206 001401 BEQ 81$; BRANCH IF GOOD
8168 024210 104113
8169
8170 ; AFTER SETTING "CLR" BIT #5
8171 ; IN RHCS2 TO INIT THE RH
8172 ; IPCKO BIT #0 RHCS3 WAS SET
8173 ; ZEROS WERE MOVED INTO
8174 ; RHDB
8175 ; RHDB WAS READ THEN
8176 ; AN RH CLEAR (RHCS2 BIT #5)
8177 ; WAS GIVEN THIS SHOULD
8178 ; CLEAR ALL ERRORS
8179 ; RHWC SHOULD HAVE 0
8180 ; BUT CONTAINED WHAT IS
8181 ; GIVEN IN BAD RHWC
8181 024212 81$:
8182
8183
8184
8185
8186

```

```

;*****
; *TEST 31 RHSC2 MDPE BIT #8 AND RHCS3 IPCK1 BIT #1

```

```

8187 : * CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
8188 : * SET IPCK1 (RHCS3 BIT #1)
8189 : * MOVE ALL ZEROS INTO RHDB ONCE
8190 : * THIS SHOULD SET TRE SC IN RHCS1
8191 : * READ RHDB ONCE THIS SHOULD SET MDPE (RHCS2 BIT #8)
8192 : * CHECK RHCS1 FOR RDY (BIT #7), TRE (BIT #14), SC (BIT #15)
8193 : * "CLR" (RHCS2 BIT #5) IS GIVEN
8194 : * ALL ERRORS ARE CLEARED
8195 : * CHECK RHCS1, RHCS2, RHCS3, RHBA, RHBAE, RHW
8196
8197 : *****
8198 024212 000004 TST31: SCOPE
8199 024214 012706 001000 MOV #STACK,SP ;RESET STACK
8200 024220 012737 000031 004656 MOV #31,#TSTNM ;SAVE TEST NUMBER
8201
8202 024226 004737 040322 JSR PC,#CLDISK ;GIVE RH INITIALIZE
8203 ;SETUP UNIT NUBER
8204 ;CLEAR RHW AND FUNCTION BITS IN RHCS1
8205 024232 012737 000001 004662 MOV #1,IP ;IPCK BIT NO. FOR PRINTOUT
8206
8207 024240 052777 000002 157664 BIS #IPCK1,#RHCS3 ;SET IPCK1 IN RHCS3-BIT #1
8208 024246 005037 004210 CLR WRFROM ;WRITE ZERO INTO LOCATION
8209 024252 013777 004210 157622 MOV WRFROM,#RHDB ;WRITE ZEROS INTO RHDB ONCE
8210
8211 ;CHECK THAT RHCS1 HAS SC!TRE!DVA!RDY
8212 024260 012737 144200 001124 MOV #SC!TRE!DVA!RDY,$GDDAT ;GET GOOD = 144200
8213
8214 024266 017737 157566 001126 MOV #RHCS1,$BDDAT ;READ RHCS1 FOR COMPARISON
8215 024274 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
8216 ;DATA WITH DATA READ FROM
8217 ;RHCS1
8218 024302 001401 BEQ 65$;BRANCH IF GOOD
8219 024304 104140 ERROR 140
8220
8221 ;AFTER SETTING "CLR" BIT #5
8222 ;IN RHCS2 TO INIT THE RH
8223 ;IPCK1 BIT #1 RHCS3 WAS SET
8224 ;ZEROS WERE MOVED INTO RHDB
8225 ;RHCS1 SHOULD HAVE SC!TRE!DVA!RDY
8226 ;=144200
8227 ;BUT CONTAINED WHAT IS
8228 ;GIVEN IN BAD RHCS1
8228 024306 65$:
8229 024306 017737 157570 001200 MOV #RHDB,$TMP1 ;READ RHDB ONCE
8230
8231
8232 ;CHECK THAT RHCS3 HAS 2
8233 024314 012737 000002 001124 MOV #2,$GDDAT ;GET GOOD = 2
8234
8235 024322 017737 157604 001126 MOV #RHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON
8236 024330 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
8237 ;DATA WITH DATA READ FROM
8238 ;RHCS3
8239 024336 001401 BEQ 67$;BRANCH IF GOOD
8240 024340 104104 ERROR 104
8241
8242 ;AFTER SETTING "CLR" BIT #5
 ;IN RHCS2 TO INIT THE RH

```

; IPCK1 BIT #1 RHCS3 WAS SET  
; ZEROS WERE MOVED INTO  
; RHDB  
; RHDB WAS READ THEN  
; RHCS3 SHOULD HAVE 2  
; =2  
; BUT CONTAINED WHAT IS  
; GIVEN IN BAD RHCS3

8243  
8244  
8245  
8246  
8247  
8248  
8249  
8250  
8251 024342 67\$:  
8252  
8253

; CHECK THAT RHCS2 HAS MDPE!IR

8254 024342 012737 000500 001124  
8255 024350 053737 005010 001124  
8256  
8257 024356 017737 157506 001126  
8258 024364 023737 001124 001126  
8259

MOV #MDPE!IR,\$GDDAT ; GET GOOD = 500  
BIS UNIT,\$GDDAT ; INCLUDE UNIT NUMBER

MOV @RHCS2,\$BDDAT ; READ RHCS2 FOR COMPARISON  
CMP \$GDDAT,\$BDDAT ; COMPARE EXPECTED  
; DATA WITH DATA READ FROM  
; RHCS2

8260  
8261 024372 001401  
8262 024374 104105  
8263  
8264  
8265  
8266  
8267  
8268  
8269  
8270  
8271  
8272  
8273  
8274 024376 69\$:  
8275  
8276

BEQ 69\$  
ERROR 105

; AFTER SETTING "CLR" BIT #5  
; IN RHCS2 TO INIT THE RH  
; IPCK1 BIT #1 RHCS3 WAS SET  
; ZEROS WERE MOVED INTO  
; RHDB  
; RHDB WAS READ THEN  
; RHCS2 SHOULD HAVE MDPE!IR  
; =500  
; TOGETHER WITH UNIT NUMBER  
; BUT CONTAINED WHAT IS  
; GIVEN IN BAD RHCS2

8277 024376 004737 040322  
8278  
8279  
8280  
8281  
8282

JSR PC,@#CLDISK ; GIVE RH INITIALIZE  
; SETUP UNIT NUBER  
; CLEAR RHWC AND FUNCTION BITS IN RHCS1

8283 024402 012737 004200 001124  
8284  
8285 024410 017737 157444 001126  
8286 024416 023737 001124 001126  
8287  
8288  
8289 024424 001401  
8290 024426 104106  
8291  
8292  
8293  
8294  
8295  
8296  
8297  
8298

; CHECK THAT RHCS1 HAS RDY!DVA  
MOV #RDY!DVA,\$GDDAT ; GET GOOD = 4200

MOV @RHCS1,\$BDDAT ; READ RHCS1 FOR COMPARISON  
CMP \$GDDAT,\$BDDAT ; COMPARE EXPECTED  
; DATA WITH DATA READ FROM  
; RHCS1

BEQ 71\$  
ERROR 106

; AFTER SETTING "CLR" BIT #5  
; IN RHCS2 TO INIT THE RH  
; IPCK1 BIT #1 RHCS3 WAS SET  
; ZEROS WERE MOVED INTO  
; RHDB  
; RHDB WAS READ THEN  
; AN RH CLEAR (RHCS2 BIT #5)  
; WAS GIVEN THIS SHOULD

```

8299 ;CLEAR ALL ERRORS
8300 ;RHCS1 SHOULD HAVE RDY!DVA
8301 ;=4200
8302 ;BUT CONTAINED WHAT IS
8303 ;GIVEN IN BAD RHCS1
8304 024430 71$:
8305 ;CHECK THAT RHCS2 HAS IR
8306 024430 012737 000100 001124 MOV #IR,$GDDAT ;GET GOOD = 100
8307 024436 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
8308
8309 024444 017737 157420 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
8310 024452 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
8311 ;DATA WITH DATA READ FROM
8312 ;RHCS2
8313 024460 001401 BEQ 73$;BRANCH IF GOOD
8314 024462 104107 ERROR 107
8315
8316 ;AFTER SETTING "CLR" BIT #5
8317 ;IN RHCS2 TO INIT THE RH
8318 ;IPCK1 BIT #1 RHCS3 WAS SET
8319 ;ZEROS WERE MOVED INTO
8320 ;RHDB
8321 ;RHDB WAS READ THEN
8322 ;AN RH CLEAR (RHCS2 BIT #5)
8323 ;WAS GIVEN THIS SHOULD
8324 ;CLEAR ALL ERRORS
8325 ;RHCS2 SHOULD HAVE IR
8326 ;=100
8327 ;TOGETHER WITH UNIT NUMBER
8328 ;BUT CONTAINED WHAT IS
8329 ;GIVEN IN BAD RHCS2
8329 024464 73$:
8330 ;CHECK THAT RHCS3 HAS 0
8331 024464 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
8332
8333 024472 017737 157434 001126 MOV @RHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON
8334 024500 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
8335 ;DATA WITH DATA READ FROM
8336 ;RHCS3
8337 024506 001401 BEQ 75$;BRANCH IF GOOD
8338 024510 104110 ERROR 110
8339
8340 ;AFTER SETTING "CLR" BIT #5
8341 ;IN RHCS2 TO INIT THE RH
8342 ;IPCK1 BIT #1 RHCS3 WAS SET
8343 ;ZEROS WERE MOVED INTO
8344 ;RHDB
8345 ;RHDB WAS READ THEN
8346 ;AN RH CLEAR (RHCS2 BIT #5)
8347 ;WAS GIVEN THIS SHOULD
8348 ;CLEAR ALL ERRORS
8349 ;RHCS3 SHOULD HAVE 0
8350 ;BUT CONTAINED WHAT IS
8351 ;GIVEN IN BAD RHCS3
8351 024512 75$:
8352 ;CHECK THAT RHBA HAS 0
8353 024512 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
8354

```





;AN RH CLEAR (RHCS2 BIT #5)  
;WAS GIVEN THIS SHOULD  
;CLEAR ALL ERRORS  
;RHC SHOULD HAVE 0  
;BUT CONTAINED WHAT IS  
;GIVEN IN BAD RHC

8411  
8412  
8413  
8414  
8415  
8416  
8417  
8418  
8419  
8420  
8421  
8422  
8423  
8424  
8425  
8426  
8427  
8428  
8429  
8430  
8431  
8432  
8433  
8434  
8435  
8436  
8437  
8438  
8439  
8440  
8441  
8442  
8443  
8444  
8445  
8446  
8447  
8448  
8449  
8450  
8451  
8452  
8453  
8454  
8455  
8456  
8457  
8458  
8459  
8460  
8461  
8462  
8463  
8464  
8465  
8466

024614

815:

```

:TEST 32 RHSC2 MDPE BIT #8 AND RHCS3 IPCK2 BIT #2
: CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
: SET IPCK2 (RHCS3 BIT #2)
: MOVE ALL ZEROS INTO RHDB TWICE
: THIS SHOULD NOT SET TRE SC IN RHCS1
: READ RHDB ONCE THIS SHOULD SET MDPE (RHCS2 BIT #8)
: CHECK RHCS1 FOR RDY (BIT #7), TRE (BIT #14), SC (BIT #15)
: READ RHDB A SECOND TIME. CHECK RHCS1, RHCS2, RHCS3
: "CLR" (RHCS2 BIT #5) IS GIVEN
: ALL ERRORS ARE CLEARED
: CHECK RHCS1, RHCS2, RHCS3, RHBA, RHBAE, RHC
```

```

:ST32: SCOPE
:MOV #STACK, SP ;RESET STACK
:MOV #32, @#STNM ;SAVE TEST NUMBER
:JSR PC, @#CLDISK ;GIVE RH INITIALIZE
: ;SETUP UNIT NUBER
: ;CLEAR RHC AND FUNCTION BITS IN RHCS1
:MOV #2, IP ;IPCK BIT NO. FOR PRINTOUT
:BIS #IPCK2, @RHCS3 ;SET IPCK2 IN RHCS3-BIT #2
:CLR WRFROM ;WRITE ZERO INTO LOCATION
:MOV WRFROM, @RHDB ;WRITE ZEROS INTO RHDB ONCE
:MOV WRFROM, @RHDB ;WRITE ZERO SECOND TIME
:CHECK THAT RHCS1 HAS DVA!RDY
:MOV #DVA!RDY, $GDDAT ;GET GOOD = 4200
:MOV @RHCS1, $BDDAT ;READ RHCS1 FOR COMPARISON
:CMP $GDDAT, $BDDAT ;COMPARE EXPECTED
: ;DATA WITH DATA READ FROM
: ;RHCS1
:BEQ 65$;BRANCH IF GOOD
:ERROR 140
```

;AFTER SETTING "CLR" BIT #5  
;IN RHCS2 TO INIT THE RH  
;IPCK2 BIT #2 RHCS3 WAS SET  
;ZEROS WERE MOVED INTO RHDB  
;TWICE  
;RHCS1 SHOULD HAVE DVA!RDY  
;=4200  
;BUT CONTAINED WHAT IS  
;GIVEN IN BAD RHCS1

MAINDEC-11-DERHAC-A  
DERHAC.P11 T32MACY11 27(732) 09-SEP-76 07:55 PAGE 160  
RHSC2 MDPE BIT #8 AND RHCS3 IPCK2 BIT #2

```

8467 024716 65$:
8468 024716 017737 157160 001200 MOV @RHDB,$TMP1 ;READ RHDB ONCE
8469
8470
8471 ;CHECK THAT RHCS3 HAS 4
8472 024724 012737 000004 001124 MOV #4,$GDDAT ;GET GOOD = 4
8473
8474 024732 017737 157174 001126 MOV @RHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON
8475 024740 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
8476 ;DATA WITH DATA READ FROM
8477 ;RHCS3
8478 024746 001401 BEQ 67$;BRANCH IF GOOD
8479 024750 104104 ERROR 104
8480
8481 ;AFTER SETTING "CLR" BIT #5
8482 ;IN RHCS2 TO INIT THE RH
8483 ;IPCK2 BIT #2 RHCS3 WAS SET
8484 ;ZEROS WERE MOVED INTO
8485 ;RHDB
8486 ;RHDB WAS READ THEN
8487 ;RHCS3 SHOULD HAVE 4
8488 ;=4
8489 ;BUT CONTAINED WHAT IS
8490 024752 67$:
8491
8492 ;CHECK THAT RHCS2 HAS MDPE!OR!IR
8493 024752 012737 000700 001124 MOV #MDPE!OR!IR,$GDDAT ;GET GOOD = 700
8494 024760 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
8495
8496 024766 017737 157076 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
8497 024774 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
8498 ;DATA WITH DATA READ FROM
8499 ;RHCS2
8500 025002 001401 BEQ 69$;BRANCH IF GOOD
8501 025004 104105 ERROR 105
8502
8503 ;AFTER SETTING "CLR" BIT #5
8504 ;IN RHCS2 TO INIT THE RH
8505 ;IPCK2 BIT #2 RHCS3 WAS SET
8506 ;ZEROS WERE MOVED INTO
8507 ;RHDB
8508 ;RHDB WAS READ THEN
8509 ;RHCS2 SHOULD HAVE MDPE!OR!IR
8510 ;=700
8511 ;TOGETHER WITH UNIT NUMBER
8512 ;BUT CONTAINED WHAT IS
8513 025006 69$:
8514
8515 025006 017737 157070 001202 MOV @RHDB,$TMP2 ;READ RHDB SECOND TIME
8516 ;CHECK THAT RHCS1 HAS SC!TRE!DVA!RDY
8517 025014 012737 144200 001124 MOV #SC!TRE!DVA!RDY,$GDDAT ;GET GOOD = 144200
8518
8519 025022 017737 157032 001126 MOV @RHCS1,$BDDAT ;READ RHCS1 FOR COMPARISON
8520 025030 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
8521 ;DATA WITH DATA READ FROM
8522 ;RHCS1

```

MAINDEC-11-DERHAC-A  
DERHAC.P11 T32

MACY11 27(732) 09-SEP-76 07:55 PAGE 161  
RHSC2 MDPE BIT #8 AND RHCS3 IPCK2 BIT #2

```

8523 025036 001401 BEQ 71$;BRANCH IF GOOD
8524 025040 104140 ERROR 140
8525 ;AFTER SETTING "CLR" BIT #5
8526 ;IN RHCS2 TO INIT THE RH
8527 ;IPCK2 BIT #2 RHCS3 WAS SET
8528 ;ZEROS WERE MOVED INTO
8529 ;RHDB
8530 ;RHDB WAS READ THEN
8531 ;RHCS1 SHOULD HAVE SC!TRE!DVA!RDY
8532 ;=144200
8533 ;BUT CONTAINED WHAT IS
8534 ;GIVEN IN BAD RHCS1
8535 025042 71$:
8536 ;CHECK THAT RHCS2 HAS MDPE!IR
8537 025042 012737 000500 001124 MOV #MDPE!IR,$GDDAT ;GET GOOD = 500
8538 025050 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
8539
8540 025056 017737 157006 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
8541 025064 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
8542 ;DATA WITH DATA READ FROM
8543 ;RHCS2
8544 025072 001401 BEQ 73$;BRANCH IF GOOD
8545 025074 104105 ERROR 105
8546 ;AFTER SETTING "CLR" BIT #5
8547 ;IN RHCS2 TO INIT THE RH
8548 ;IPCK2 BIT #2 RHCS3 WAS SET
8549 ;ZEROS WERE MOVED INTO
8550 ;RHDB
8551 ;RHDB WAS READ THEN
8552 ;RHCS2 SHOULD HAVE MDPE!IR
8553 ;=500
8554 ;TOGETHER WITH UNIT NUMBER
8555 ;BUT CONTAINED WHAT IS
8556 ;GIVEN IN BAD RHCS2
8557 025076 73$:
8558 ;CHECK THAT RHCS3 HAS 4
8559 025076 012737 000004 001124 MOV #4,$GDDAT ;GET GOOD = 4
8560
8561 025104 017737 157022 001126 MOV @RHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON
8562 025112 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
8563 ;DATA WITH DATA READ FROM
8564 ;RHCS3
8565 025120 001401 BEQ 75$;BRANCH IF GOOD
8566 025122 104104 ERROR 104
8567 ;AFTER SETTING "CLR" BIT #5
8568 ;IN RHCS2 TO INIT THE RH
8569 ;IPCK2 BIT #2 RHCS3 WAS SET
8570 ;ZEROS WERE MOVED INTO
8571 ;RHDB
8572 ;RHDB WAS READ THEN
8573 ;RHCS3 SHOULD HAVE 4
8574 ;=4
8575 ;BUT CONTAINED WHAT IS
8576 ;GIVEN IN BAD RHCS3
8577 025124 75$:
8578

```

MAINDEC-11-DERHAC-A  
DERHAC.P11 T32

MACY11 27(732) 09-SEP-76 07:55 PAGE 162  
RHSC2 MDPE BIT #8 AND RHCS3 IPCK2 BIT #2

```

9579 025124 004737 040322 JSR PC, @#CLDISK ;GIVE RH INITIALIZE
9580 ;SETUP UNIT NUBER
9581 ;CLEAR RHWC AND FUNCTION BITS IN RHCS1
9582
9583
9584 ;CHECK THAT RHCS1 HAS RDY!DVA
9585 025130 012737 004200 001124 MOV #RDY!DVA, $GDDAT ;GET GOOD = 4200
9586
9587 025136 017737 156716 001126 MOV @RHCS1, $BDDAT ;READ RHCS1 FOR COMPARISON
9588 025144 023737 001124 001126 CMP $GDDAT, $BDDAT ;COMPARE EXPECTED
9589 ;DATA WITH DATA READ FROM
9590 ;RHCS1
9591 025152 001401 BEQ 77$;BRANCH IF GOOD
9592 025154 104106 ERROR 106
9593 ;AFTER SETTING "CLR" BIT #5
9594 ;IN RHCS2 TO INIT THE RH
9595 ;IPCK2 BIT #2 RHCS3 WAS SET
9596 ;ZEROS WERE MOVED INTO
9597 ;RHDB
9598 ;RHDB WAS READ THEN
9599 ;AN RH CLEAR (RHCS2 BIT #5)
9600 ;WAS GIVEN THIS SHOULD
9601 ;CLEAR ALL ERRORS
9602 ;RHCS1 SHOULD HAVE RDY!DVA
9603 ;=4200
9604 ;BUT CONTAINED WHAT IS
9605 ;GIVEN IN BAD RHCS1
9606 025156 77$:
9607 ;CHECK THAT RHCS2 HAS IR
9608 025156 012737 000100 001124 MOV #IR, $GDDAT ;GET GOOD = 100
9609 025164 053737 005010 001124 BIS UNIT, $GDDAT ;INCLUDE UNIT NUMBER
9610
9611 025172 017737 156672 001126 MOV @RHCS2, $BDDAT ;READ RHCS2 FOR COMPARISON
9612 025200 023737 001124 001126 CMP $GDDAT, $BDDAT ;COMPARE EXPECTED
9613 ;DATA WITH DATA READ FROM
9614 ;RHCS2
9615 025206 001401 BEQ 79$;BRANCH IF GOOD
9616 025210 104107 ERROR 107
9617 ;AFTER SETTING "CLR" BIT #5
9618 ;IN RHCS2 TO INIT THE RH
9619 ;IPCK2 BIT #2 RHCS3 WAS SET
9620 ;ZEROS WERE MOVED INTO
9621 ;RHDB
9622 ;RHDB WAS READ THEN
9623 ;AN RH CLEAR (RHCS2 BIT #5)
9624 ;WAS GIVEN THIS SHOULD
9625 ;CLEAR ALL ERRORS
9626 ;RHCS2 SHOULD HAVE IR
9627 ;=100
9628 ;TOGETHER WITH UNIT NUMBER
9629 ;BUT CONTAINED WHAT IS
9630 ;GIVEN IN BAD RHCS2
9631 025212 79$:
9632 ;CHECK THAT RHCS3 HAS 0
9633 025212 012737 000000 001124 MOV #0, $GDDAT ;GET GOOD = 0
9634

```



```

8691 ;AN RH CLEAR (RHCS2 BIT #5)
8692 ;WAS GIVEN THIS SHOULD
8693 ;CLEAR ALL ERRORS
8694 ;RHBAE SHOULD HAVE 0
8695 ;BUT CONTAINED WHAT IS
8696 ;GIVEN IN BAD RHBAE
8697 025314 85$:
8698 ;CHECK THAT RHW C HAS 0
8699 025314 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
8700
8701 025322 017737 156534 001126 MOV @RHW C,$BDDAT ;READ RHW C FOR COMPARISON
8702 025330 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
8703 ;DATA WITH DATA READ FROM
8704 ;RHW C
8705 025336 001401 BEQ 87$;BRANCH IF GOOD
8706 025340 104113 ERROR 113
8707 ;AFTER SETTING "CLR" BIT #5
8708 ;IN RHCS2 TO INIT THE RH
8709 ;IPCK2 BIT #2 RHCS3 WAS SET
8710 ;ZEROS WERE MOVED INTO
8711 ;RHDB
8712 ;RHDB WAS READ THEN
8713 ;AN RH CLEAR (RHCS2 BIT #5)
8714 ;WAS GIVEN THIS SHOULD
8715 ;CLEAR ALL ERRORS
8716 ;RHW C SHOULD HAVE 0
8717 ;BUT CONTAINED WHAT IS
8718 ;GIVEN IN BAD RHW C
8719 025342 87$:
8720
8721
8722
8723 ;*****
8724 ;*TEST 33 RHSC2 MDPE BIT #8 AND RHCS3 IPCK3 BIT #3
8725 ;* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
8726 ;* SET IPCK3 (RHCS3 BIT #3)
8727 ;* MOVE ALL ZEROS INTO RHDB TWICE
8728 ;* THIS SHOULD NOT SET TRE SC IN RHCS1
8729 ;* READ RHDB ONCE THIS SHOULD SET MDPE (RHCS2 BIT #8)
8730 ;* CHECK RHCS1 FOR RDY (BIT #7), TRE (BIT #14), SC (BIT #15)
8731 ;* READ RHDB A SECOND TIME. CHECK RHCS1, RHCS2, RHCS3
8732 ;* "CLR" (RHCS2 BIT #5) IS GIVEN
8733 ;* ALL ERRORS ARE CLEARED
8734 ;* CHECK RHCS1, RHCS2, RHCS3, RHBA, RHBAE, RHW C
8735 ;*****
8736 ;*****
8737 025342 000004 ST33: SCOPE
8738 025344 012706 001000 MOV #STACK,SP ;RESET STACK
8739 025350 012737 000033 004656 MOV #33,@#STNM ;SAVE TEST NUMBER
8740
8741 025356 004737 040322 JSR PC,@#CLDISK ;GIVE RH INITIALIZE
8742 ;SETUP UNIT NUBER
8743 ;CLEAR RHW C AND FUNCTION BITS IN RHCS1
8744 025362 012737 000003 004662 MOV #3,IP ;IPCK BIT NO. FOR PRINTOUT
8745
8746 025370 052777 000010 156534 BIS #IPCK3,@RHCS3 ;SET IPCK3 IN RHCS3-BIT #3

```

```

8747 025376 005037 004210 CLR WRFROM ;WRITE ZERO INTO LOCATION
8748 025402 013777 004210 156472 MOV WRFROM, @RHDB ;WRITE ZEROS INTO RHDB ONCE
8749 025410 013777 004210 156464 MOV WRFROM, @RHDB ;WRITE ZERO SECOND TIME
8750
8751 ;CHECK THAT RHCS1 HAS DVA!RDY
8752 025416 012737 004200 001124 MOV #DVA!RDY,$GDDAT ;GET GOOD = 4200
8753
8754 025424 017737 156430 001126 MOV @RHCS1,$BDDAT ;READ RHCS1 FOR COMPARISON
8755 025432 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
8756 ;DATA WITH DATA READ FROM
8757 ;RHCS1
8758 025440 001401 BEQ 65$;BRANCH IF GOOD
8759 025442 104140 ERROR 140
8760 ;AFTER SETTING "CLR" BIT #5
8761 ;IN RHCS2 TO INIT THE RH
8762 ;IPCK3 BIT #3 RHCS3 WAS SET
8763 ;ZEROS WERE MOVED INTO RHDB
8764 ;TWICE
8765 ;RHCS1 SHOULD HAVE DVA!RDY
8766 ;=4200
8767 ;BUT CONTAINED WHAT IS
8768 ;GIVEN IN BAD RHCS1
8769 025444 65$:
8770 025444 017737 156432 001200 MOV @RHDB,$TMP1 ;READ RHDB ONCE
8771
8772
8773 ;CHECK THAT RHCS3 HAS 10
8774 025452 012737 000010 001124 MOV #10,$GDDAT ;GET GOOD = 10
8775
8776 025460 017737 156446 001126 MOV @RHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON
8777 025466 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
8778 ;DATA WITH DATA READ FROM
8779 ;RHCS3
8780 025474 001401 BEQ 67$;BRANCH IF GOOD
8781 025476 104104 ERROR 104
8782 ;AFTER SETTING "CLR" BIT #5
8783 ;IN RHCS2 TO INIT THE RH
8784 ;IPCK3 BIT #3 RHCS3 WAS SET
8785 ;ZEROS WERE MOVED INTO
8786 ;RHDB
8787 ;RHDB WAS READ THEN
8788 ;RHCS3 SHOULD HAVE 10
8789 ;=10
8790 ;BUT CONTAINED WHAT IS
8791 ;GIVEN IN BAD RHCS3
8792 025500 67$:
8793
8794 ;CHECK THAT RHCS2 HAS MDPE!OR!IR
8795 025500 012737 000700 001124 MOV #MDPE!OR!IR,$GDDAT ;GET GOOD = 700
8796 025506 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
8797
8798 025514 017737 156350 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
8799 025522 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
8800 ;DATA WITH DATA READ FROM
8801 ;RHCS2
8802 025530 001401 BEQ 69$;BRANCH IF GOOD

```

8803 025532 104105

ERROR 105

: AFTER SETTING "CLR" BIT #5  
: IN RHCS2 TO INIT THE RH  
: IPCK3 BIT #3 RHCS3 WAS SET  
: ZEROS WERE MOVED INTO  
: RHDB  
: RHDB WAS READ THEN  
: RHCS2 SHOULD HAVE MDPE!OR!IR  
: =700  
: TOGETHER WITH UNIT NUMBER  
: BUT CONTAINED WHAT IS  
: GIVEN IN BAD RHCS2

8815 025534

69\$:

8816  
8817 025534 017737 156342 001202

MOV @RHDB,\$TMP2 ; READ RHDB SECOND TIME  
; CHECK THAT RHCS1 HAS SC!TRE!DVA!RDY  
MOV #SC!TRE!DVA!RDY,\$GDDAT ; GET GOOD = 144200

8818  
8819 025542 012737 144200 001124

8820  
8821 025550 017737 156304 001126

MOV @RHCS1,\$BDDAT ; READ RHCS1 FOR COMPARISON  
CMP \$GDDAT,\$BDDAT ; COMPARE EXPECTED

8822 025556 023737 001124 001126

8823  
8824

; DATA WITH DATA READ FROM  
: RHCS1  
BEQ 71\$ ; BRANCH IF GOOD

8825 025564 001401

BEQ 71\$

8826 025566 104140

ERROR 140

: AFTER SETTING "CLR" BIT #5  
: IN RHCS2 TO INIT THE RH  
: IPCK3 BIT #3 RHCS3 WAS SET  
: ZEROS WERE MOVED INTO  
: RHDB  
: RHDB WAS READ THEN  
: RHCS1 SHOULD HAVE SC!TRE!DVA!RDY  
: =144200  
: BUT CONTAINED WHAT IS  
: GIVEN IN BAD RHCS1

8827

8828

8829

8830

8831

8832

8833

8834

8835

8836

8837 025570

71\$:

; CHECK THAT RHCS2 HAS MDPE!IR  
MOV #MDPE!IR,\$GDDAT ; GET GOOD = 500  
BIS UNIT,\$GDDAT ; INCLUDE UNIT NUMBER

8838  
8839 025570 012737 000500 001124

8840 025576 053737 005010 001124

8841

8842 025604 017737 156260 001126

MOV @RHCS2,\$BDDAT ; READ RHCS2 FOR COMPARISON  
CMP \$GDDAT,\$BDDAT ; COMPARE EXPECTED

8843 025612 023737 001124 001126

8844

8845

8846 025620 001401

; DATA WITH DATA READ FROM  
: RHCS2  
BEQ 73\$ ; BRANCH IF GOOD

8847 025622 104105

BEQ 73\$

8848

ERROR 105

: AFTER SETTING "CLR" BIT #5  
: IN RHCS2 TO INIT THE RH  
: IPCK3 BIT #3 RHCS3 WAS SET  
: ZEROS WERE MOVED INTO  
: RHDB  
: RHDB WAS READ THEN  
: RHCS2 SHOULD HAVE MDPE!IR  
: =500  
: TOGETHER WITH UNIT NUMBER  
: BUT CONTAINED WHAT IS  
: GIVEN IN BAD RHCS2

8849

8850

8851

8852

8853

8854

8855

8856

8857

8858



MAINDEC-11-DERHAC-A  
DERHAC.P11 T33

MACY11 27(732) 09-SEP-76 07:55 PAGE 167  
RHSC2 MOPE BIT #8 AND RHCS3 IPCK3 BIT #3

```

8859 025624 73$:
8860 :CHECK THAT RHCS3 HAS 10
8861 025624 012737 000010 001124 MOV #10,$GDDAT ;GET GOOD = 10
8862
8863 025632 017737 156274 001126 MOV @RHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON
8864 025640 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
8865 ;DATA WITH DATA READ FROM
8866 ;RHCS3
8867 025646 001401 BEQ 75$;BRANCH IF GOOD
8868 025650 104104 ERROR 104
8869
8870 ;AFTER SETTING "CLR" BIT #5
8871 ;IN RHCS2 TO INIT THE RH
8872 ;IPCK3 BIT #3 RHCS3 WAS SET
8873 ;ZEROS WERE MOVED INTO
8874 ;RHDB
8875 ;RHDB WAS READ THEN
8876 ;RHCS3 SHOULD HAVE 10
8877 ;=10
8878 ;BUT CONTAINED WHAT IS
8879 ;GIVEN IN BAD RHCS3
8879 025652 75$:
8880
8881 025652 004737 040322 JSR PC,@#CLDISK ;GIVE RH INITIALIZE
8882 ;SETUP UNIT NUBER
8883 ;CLEAR RHWC AND FUNCTION BITS IN RHCS1
8884
8885
8886 :CHECK THAT RHCS1 HAS RDY!DVA
8887 025656 012737 004200 001124 MOV #RDY!DVA,$GDDAT ;GET GOOD = 4200
8888
8889 025664 017737 156170 001126 MOV @RHCS1,$BDDAT ;READ RHCS1 FOR COMPARISON
8890 025672 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
8891 ;DATA WITH DATA READ FROM
8892 ;RHCS1
8893 025700 001401 BEQ 77$;BRANCH IF GOOD
8894 025702 104106 ERROR 106
8895
8896 ;AFTER SETTING "CLR" BIT #5
8897 ;IN RHCS2 TO INIT THE RH
8898 ;IPCK3 BIT #3 RHCS3 WAS SET
8899 ;ZEROS WERE MOVED INTO
8900 ;RHDB
8901 ;RHDB WAS READ THEN
8902 ;AN RH CLEAR (RHCS2 BIT #5)
8903 ;WAS GIVEN THIS SHOULD
8904 ;CLEAR ALL ERRORS
8905 ;RHCS1 SHOULD HAVE RDY!DVA
8906 ;=4200
8907 ;BUT CONTAINED WHAT IS
8908 ;GIVEN IN BAD RHCS1
8908 025704 77$:
8909
8910 025704 012737 000100 001124 MOV #IR,$GDDAT ;CHECK THAT RHCS2 HAS IR
8911 025712 053737 005010 001124 BIS UNIT,$GDDAT ;GET GOOD = 100
8912 ;INCLUDE UNIT NUMBER
8913 025720 017737 156144 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
8914 025726 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED

```

8915  
8916  
8917  
8918  
8919  
8920  
8921  
8922  
8923  
8924  
8925  
8926  
8927  
8928  
8929  
8930  
8931  
8932  
8933  
8934  
8935  
8936  
8937  
8938  
8939  
8940  
8941  
8942  
8943  
8944  
8945  
8946  
8947  
8948  
8949  
8950  
8951  
8952  
8953  
8954  
8955  
8956  
8957  
8958  
8959  
8960  
8961  
8962  
8963  
8964  
8965  
8966  
8967  
8968  
8969  
8970

025734 001401  
025736 104107

BEQ 79\$  
ERROR 107

;DATA WITH DATA READ FROM  
;RHCS2  
;BRANCH IF GOOD

;AFTER SETTING "CLR" BIT #5  
;IN RHCS2 TO INIT THE RH  
;IPCK3 BIT #3 RHCS3 WAS SET  
;ZEROS WERE MOVED INTO  
;RHDB  
;RHDB WAS READ THEN  
;AN RH CLEAR (RHCS2 BIT #5)  
;WAS GIVEN THIS SHOULD  
;CLEAR ALL ERRORS  
;RHCS2 SHOULD HAVE IR  
;=100  
;TOGETHER WITH UNIT NUMBER  
;BUT CONTAINED WHAT IS  
;GIVEN IN BAD RHCS2

025740

79\$:

;CHECK THAT RHCS3 HAS 0  
MOV #0,\$GDDAT

;GET GOOD = 0

025740 012737 000000 001124

025746 017737 156160 001126  
025754 023737 001124 001126

MOV @RHCS3,\$BDDAT  
CMP \$GDDAT,\$BDDAT

;READ RHCS3 FOR COMPARISON  
;COMPARE EXPECTED  
;DATA WITH DATA READ FROM  
;RHCS3  
;BRANCH IF GOOD

025762 001401  
025764 104110

BEQ 81\$  
ERROR 110

;AFTER SETTING "CLR" BIT #5  
;IN RHCS2 TO INIT THE RH  
;IPCK3 BIT #3 RHCS3 WAS SET  
;ZEROS WERE MOVED INTO  
;RHDB  
;RHDB WAS READ THEN  
;AN RH CLEAR (RHCS2 BIT #5)  
;WAS GIVEN THIS SHOULD  
;CLEAR ALL ERRORS  
;RHCS3 SHOULD HAVE 0  
;BUT CONTAINED WHAT IS  
;GIVEN IN BAD RHCS3

025766

81\$:

;CHECK THAT RHBA HAS 0  
MOV #0,\$GDDAT

;GET GOOD = 0

025766 012737 000000 001124

025774 017737 156064 001126  
026002 023737 001124 001126

MOV @RHBA,\$BDDAT  
CMP \$GDDAT,\$BDDAT

;READ RHBA FOR COMPARISON  
;COMPARE EXPECTED  
;DATA WITH DATA READ FROM  
;RHBA  
;BRANCH IF GOOD

026010 001401  
026012 104111

BEQ 83\$  
ERROR 111

;AFTER SETTING "CLR" BIT #5  
;IN RHCS2 TO INIT THE RH  
;IPCK3 BIT #3 RHCS3 WAS SET  
;ZEROS WERE MOVED INTO  
;RHDB  
;RHDB WAS READ THEN

```

8971 ;AN RH CLEAR (RHCS2 BIT #5)
8972 ;WAS GIVEN THIS SHOULD
8973 ;CLEAR ALL ERRORS
8974 ;RHBA SHOULD HAVE 0
8975 ;BUT CONTAINED WHAT IS
8976 ;GIVEN IN BAD RHBA
8977 026014 83$:
8978 ;CHECK THAT RHBAE HAS 0
8979 026014 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
8980
8981 026022 017737 156102 001126 MOV @RHBAE,$BDDAT ;READ RHBAE FOR COMPARISON
8982 026030 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
8983 ;DATA WITH DATA READ FROM
8984 ;RHBAE
8985 026036 001401 BEQ 85$;BRANCH IF GOOD
8986 026040 104112 ERROR 112
8987
8988 ;AFTER SETTING "CLR" BIT #5
8989 ;IN RHCS2 TO INIT THE RH
8990 ;IPCK3 BIT #3 RHCS3 WAS SET
8991 ;ZEROS WERE MOVED INTO
8992 ;RHDB
8993 ;RHDB WAS READ THEN
8994 ;AN RH CLEAR (RHCS2 BIT #5)
8995 ;WAS GIVEN THIS SHOULD
8996 ;CLEAR ALL ERRORS
8997 ;RHBAE SHOULD HAVE 0
8998 ;BUT CONTAINED WHAT IS
8999 ;GIVEN IN BAD RHBAE
9000
9001 026042 85$:
9002 ;CHECK THAT RHWC HAS 0
9003 026042 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
9004 026050 017737 156006 001126 MOV @RHWC,$BDDAT ;READ RHWC FOR COMPARISON
9005 026056 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
9006 ;DATA WITH DATA READ FROM
9007 ;RHWC
9008 026064 001401 BEQ 87$;BRANCH IF GOOD
9009 026066 104113 ERROR 113
9010
9011 ;AFTER SETTING "CLR" BIT #5
9012 ;IN RHCS2 TO INIT THE RH
9013 ;IPCK3 BIT #3 RHCS3 WAS SET
9014 ;ZEROS WERE MOVED INTO
9015 ;RHDB
9016 ;RHDB WAS READ THEN
9017 ;AN RH CLEAR (RHCS2 BIT #5)
9018 ;WAS GIVEN THIS SHOULD
9019 ;CLEAR ALL ERRORS
9020 ;RHWC SHOULD HAVE 0
9021 ;BUT CONTAINED WHAT IS
9022 ;GIVEN IN BAD RHWC
9023
9024 026070 87$:
9025
9026

```

::\*\*\*\*\*

```

9027 ;*TEST 34 RHCS2-WCE BIT #14 AND RHCS3-WCE OW BIT #12
9028
9029 ;* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
9030 ;* WRITE NINE WORD OF ALL NINES ON TO THE DEVICE
9031 ;* SET UP TO DO WRITE CHECK ON THAT WORD FROM AN
9032 ;* ODD WORD BOUNDARY
9033 ;* DO A ONE WORD WRITE CHECK WITH RHBA FROM AN
9034 ;* ODD WORD BOUNDARY
9035 ;* THIS SHOULD SET WCE OW (RHCS3 BIT #12)
9036 ;* AND WCE (RHCS2 BIT #14)
9037 ;* "CLR" (RHCS2 BIT #5) IS GIVEN
9038 ;* ALL ERRORS ARE CLEARED
9039 ;* CHECK RHCS1, RHCS2, RHCS3, RHBA, RHBAE, RHWC
9040
9041 ;*****
9042 026070 000004 ;†ST34: SCOPE
9043 026072 012706 001000 MOV #STACK, SP ;RESET STACK
9044 026076 012737 000034 004656 MOV #34, †STNM ;SAVE TEST NUMBER
9045
9046 026104 004737 040322 JSR PC, †CLDISK ;GIVE RH INITIALIZE
9047 ;SETUP UNIT NUBER
9048 ;CLEAR RHWC AND FUNCTION BITS IN RHCS1
9049
9050 ;WRITE ONE WORD OF ALL ONES ON THE DEVICE
9051 026110 012737 177777 004210 MOV #-1, WRFROM ;ALL ONES INTO WRITE FROM
9052 026116 012777 177767 155736 MOV #-9, †RHWC ;NINE WORD FOR WORD COUNT REGISTER
9053 026124 012777 004210 155736 MOV #WRFROM, †RHBA ;WRITE FROM BUFFER INTO BUS ADDRESS
9054
9055 026132 004077 156502 JSR RD, †COMND ;GO TO DO COMMAND
9056 026136 004154 WRIDAT ;WRITE DATA
9057
9058 ;SET UP FOR WRITE CHECK
9059 026140 005037 003002 CLR BUFOW ;WRITE DATA FOR WRITE CHECK ERROR
9060 026144 012777 177767 155710 MOV #-9, †RHWC ;NINE WORD FOR WORD COUNT REGISTER
9061 026152 012777 003002 155704 MOV #BUFOW, †RHBA ;WRITE FROM BUFFER INTO BUS ADDRESS
9062 ;FROM ODD WORD BOUNDARY
9063 ;WRITE CHECK ON ODD WORD BOUNDARY
9064 026160 004077 156454 JSR RD, †COMND ;GO TO DC COMMAND
9065 026164 004150 WRCHEK ;WRITE CHECK DATA
9066
9067
9068
9069
9070 ;CHECK THAT RHCS2 HAS WCE!OR!IR
9071 026166 012737 040300 001124 MOV #WCE!OR!IR, $GDDAT ;GET GOOD = 40300
9072 026174 053737 005010 001124 BIS UNIT, $GDDAT ;INCLUDE UNIT NUMBER
9073
9074 026202 017737 155662 001126 MOV †RHCS2, $BDDAT ;READ RHCS2 FOR COMPARISON
9075 026210 023737 001124 001126 CMP $GDDAT, $BDDAT ;COMPARE EXPECTED
9076 ;DATA WITH DATA READ FROM
9077 ;RHCS2
9078 026216 001401 BEQ 65$;BRANCH IF GOOD
9079 026220 104114 ERROR 114
9080 ;AFTER SETTING "CLR" BIT #5
9081 ;IN RHCS2 TO INIT THE RH
9082 ;ONE WORD OF ALL ONES IS

```



```

9139 :=4200
9140 ;BUT CONTAINED WHAT IS
9141 ;GIVEN IN BAD RHCS1
9142 026302 69$:
9143 ;CHECK THAT RHCS2 HAS IR
9144 026302 012737 000100 001124 MOV #IR,$GDDAT ;GET GOOD = 100
9145 026310 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
9146
9147 026316 017737 155546 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
9148 026324 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
9149 ;DATA WITH DATA READ FROM
9150 ;RHCS2
9151 026332 001401 BEQ 71$;BRANCH IF GOOD
9152 026334 104117 ERROR 117
9153
9154 ;AFTER SETTING "CLR" BIT #5
9155 ;IN RHCS2 TO INIT THE RH
9156 ;ONE WORD OF ALL ONES IS
9157 ;WRITTEN ON THE DEVICE
9158 ;A WRITE CHECK WAS DONE
9159 ;ON AN ODD WORD BOUNDARY THEN
9160 ;AN RH CLEAR (RHCS2 BIT #5)
9161 ;WAS GIVEN THIS SHOULD
9162 ;CLEAR ALL ERRORS
9163 ;RHCS2 SHOULD HAVE IR
9164 ;=100
9165 ;TOGETHER WITH UNIT NUMBER
9166 ;BUT CONTAINED WHAT IS
9167 026336 71$:
9168 ;CHECK THAT RHCS3 HAS 0
9169 026336 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
9170
9171 026344 017737 155562 001126 MOV @RHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON
9172 026352 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
9173 ;DATA WITH DATA READ FROM
9174 ;RHCS3
9175 026360 001401 BEQ 73$;BRANCH IF GOOD
9176 026362 104120 ERROR 120
9177
9178 ;AFTER SETTING "CLR" BIT #5
9179 ;IN RHCS2 TO INIT THE RH
9180 ;ONE WORD OF ALL ONES IS
9181 ;WRITTEN ON THE DEVICE
9182 ;A WRITE CHECK WAS DONE
9183 ;ON AN ODD WORD BOUNDARY THEN
9184 ;AN RH CLEAR (RHCS2 BIT #5)
9185 ;WAS GIVEN THIS SHOULD
9186 ;CLEAR ALL ERRORS
9187 ;RHCS3 SHOULD HAVE 0
9188 ;BUT CONTAINED WHAT IS
9189 026364 73$:
9190 ;CHECK THAT RHBA HAS 0
9191 026364 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
9192
9193 026372 017737 155466 001126 MOV @RHBA,$BDDAT ;READ RHBA FOR COMPARISON
9194 026400 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED

```

```

9195 ;DATA WITH DATA READ FROM
9196 ;RHBA
9197 026406 001401 BEQ 75$;BRANCH IF GOOD
9198 026410 104121 ERROR 121
9199 ;AFTER SETTING "CLR" BIT #5
9200 ;IN RHCS2 TO INIT THE RH
9201 ;ONE WORD OF ALL ONES IS
9202 ;WRITTEN ON THE DEVICE
9203 ;A WRITE CHECK WAS DONE
9204 ;ON AN ODD WORD BOUNDARY THEN
9205 ;AN RH CLEAR (RHCS2 BIT #5)
9206 ;WAS GIVEN THIS SHOULD
9207 ;CLEAR ALL ERRORS
9208 ;RHBA SHOULD HAVE 0
9209 ;BUT CONTAINED WHAT IS
9210 ;GIVEN IN BAD RHBA
9211 026412 75$:
9212 ;CHECK THAT RHBAE HAS 0
9213 026412 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
9214
9215 026420 017737 155504 001126 MOV @RHBAE,$BDDAT ;READ RHBAE FOR COMPARISON
9216 026426 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
9217 ;DATA WITH DATA READ FROM
9218 ;RHBAE
9219 026434 001401 BEQ 77$;BRANCH IF GOOD
9220 026436 104122 ERROR 122
9221 ;AFTER SETTING "CLR" BIT #5
9222 ;IN RHCS2 TO INIT THE RH
9223 ;ONE WORD OF ALL ONES IS
9224 ;WRITTEN ON THE DEVICE
9225 ;A WRITE CHECK WAS DONE
9226 ;ON AN ODD WORD BOUNDARY THEN
9227 ;AN RH CLEAR (RHCS2 BIT #5)
9228 ;WAS GIVEN THIS SHOULD
9229 ;CLEAR ALL ERRORS
9230 ;RHBAE SHOULD HAVE 0
9231 ;BUT CONTAINED WHAT IS
9232 ;GIVEN IN BAD RHBAE
9233 026440 77$:
9234 ;CHECK THAT RHWC HAS 0
9235 026440 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
9236
9237 026446 017737 155410 001126 MOV @RHWC,$BDDAT ;READ RHWC FOR COMPARISON
9238 026454 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
9239 ;DATA WITH DATA READ FROM
9240 ;RHWC
9241 026462 001401 BEQ 79$;BRANCH IF GOOD
9242 026464 104123 ERROR 123
9243 ;AFTER SETTING "CLR" BIT #5
9244 ;IN RHCS2 TO INIT THE RH
9245 ;ONE WORD OF ALL ONES IS
9246 ;WRITTEN ON THE DEVICE
9247 ;A WRITE CHECK WAS DONE
9248 ;ON AN ODD WORD BOUNDARY THEN
9249 ;AN RH CLEAR (RHCS2 BIT #5)
9250 ;WAS GIVEN THIS SHOULD

```

```

9251 ;CLEAR ALL ERRORS
9252 ;RHW C SHOULD HAVE 0
9253 ;BUT CONTAINED WHAT IS
9254 ;GIVEN IN BAD RHW C
026466 79$:
9255
9256
9257
9258
9259 ::*****
9260 :*TEST 35 RHCS2-WCE BIT #14 AND RHCS3-WCE OW BIT #12
9261
9262 :* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
9263 :* WRITE NINE WORD OF ALL NINES ON TO THE DEVICE
9264 :* SET UP TO DO WRITE CHECK ON THAT WORD FROM AN
9265 :* ODD WORD BOUNDARY
9266 :* DO A ONE WORD WRITE CHECK WITH RHBA FROM AN
9267 :* ODD WORD BOUNDARY
9268 :* THIS SHOULD SET WCE OW (RHCS3 BIT #12)
9269 :* AND WCE (RHCS2 BIT #14)
9270 :* "CLR" (RHCS2 BIT #5) IS GIVEN
9271 :* ALL ERRORS ARE CLEARED
9272 :* CHECK RHCS1, RHCS2, RHCS3, RHBA, RHBAE, RHW C
9273
9274 ::*****
9275 026466 000004 †ST35: SCOPE
9276 026470 012706 MOV #STACK,SP ;RESET STACK
9277 026474 012737 000035 004656 MOV #35,‡†STNM ;SAVE TEST NUMBER
9278
9279 026502 004737 040322 JSR PC,‡#CLDISK ;GIVE RH INITIALIZE
9280 ;SETUP UNIT NUBER
9281 ;CLEAR RHW C AND FUNCTION BITS IN RHCS1
9282
9283 :WRITE ONE WORD OF ALL ONES ON THE DEVICE
9284 026506 012737 177777 004210 MOV #-1,‡RFROM ;ALL ONES INTO WRITE FROM
9285 026514 012777 177767 155340 MOV #-9,‡RHW C ;NINE WORD FOR WORD COUNT REGISTER
9286 026522 012777 004210 155334 MOV #‡RFROM,‡RHBA ;WRITE FROM BUFFER INTO BUS ADDRESS
9287
9288 026530 004077 156104 JSR RD,‡COMND ;GO TO DO COMMAND
9289 026534 004154 WRIDAT ;WRITE DATA
9290
9291 :SET UP FOR WRITE CHECK
9292 026536 005037 003002 CLR BUFOW ;WRITE DATA FOR WRITE CHECK ERROR
9293 026542 012777 177767 155312 MOV #-9,‡RHW C ;NINE WORD FOR WORD COUNT REGISTER
9294 026550 012777 003002 155306 MOV #BUFOW,‡RHBA ;WRITE FROM BUFFER INTO BUS ADDRESS
9295 ;FROM ODD WORD BOUNDRY
9296 :WRITE CHECK ON ODD WORD BOUNDARY
9297 026556 004077 156056 JSR RD,‡COMND ;GO TO DO COMMAND
9298 026562 004150 WRCHK ;WRITE CHECK DATA
9299
9300
9301
9302
9303 :CHECK THAT RHCS2 HAS WCE!OR!IR
9304 026564 012737 040300 001124 MOV #WCE!OR!IR,$GDDAT ;GET GOOD = 40300
9305 026572 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
9306

```





9363  
9364  
9365  
9366  
9367  
9368  
9369  
9370  
9371  
9372  
9373  
9374  
9375  
9376  
9377  
9378  
9379  
9380  
9381  
9382  
9383  
9384  
9385  
9386  
9387  
9388  
9389  
9390  
9391  
9392  
9393  
9394  
9395  
9396  
9397  
9398  
9399  
9400  
9401  
9402  
9403  
9404  
9405  
9406  
9407  
9408  
9409  
9410  
9411  
9412  
9413  
9414  
9415  
9416  
9417  
9418

026700

69\$:

026700 012737 000100 001124  
026706 053737 005010 001124  
026714 017737 155150 001126  
026722 023737 001124 001126  
026730 001401  
026732 104117

;CHECK THAT RHCS2 HAS IR  
MOV #IR,\$GDDAT  
BIS UNIT,\$GDDAT  
MOV 2RHCS2,\$BDDAT  
CMP \$GDDAT,\$BDDAT  
BEG 71\$  
ERROR 117

; IN RHCS2 TO INIT THE RH  
; ONE WORD OF ALL ONES IS  
; WRITTEN ON THE DEVICE  
; A WRITE CHECK WAS DONE  
; ON AN ODD WORD BOUNDARY THEN  
; AN RH CLEAR (RHCS2 BIT #5)  
; WAS GIVEN THIS SHOULD  
; CLEAR ALL ERRORS  
; RHCS1 SHOULD HAVE RDY!DVA  
; =4200  
; BUT CONTAINED WHAT IS  
; GIVEN IN BAD RHCS1

;GET GOOD = 100  
;INCLUDE UNIT NUMBER  
;READ RHCS2 FOR COMPARISON  
;COMPARE EXPECTED  
;DATA WITH DATA READ FROM  
;RHCS2  
;BRANCH IF GOOD

; AFTER SETTING "CLR" BIT #5  
; IN RHCS2 TO INIT THE RH  
; ONE WORD OF ALL ONES IS  
; WRITTEN ON THE DEVICE  
; A WRITE CHECK WAS DONE  
; ON AN ODD WORD BOUNDARY THEN  
; AN RH CLEAR (RHCS2 BIT #5)  
; WAS GIVEN THIS SHOULD  
; CLEAR ALL ERRORS  
; RHCS2 SHOULD HAVE IR  
; =100  
; TOGETHER WITH UNIT NUMBER  
; BUT CONTAINED WHAT IS  
; GIVEN IN BAD RHCS2

026734

71\$:

026734 012737 000000 001124  
026742 017737 155164 001126  
026750 023737 001124 001126  
026756 001401  
026760 104120

;CHECK THAT RHCS3 HAS 0  
MOV #0,\$GDDAT  
MOV 2RHCS3,\$BDDAT  
CMP \$GDDAT,\$BDDAT  
BEG 73\$  
ERROR 120

;READ RHCS3 FOR COMPARISON  
;COMPARE EXPECTED  
;DATA WITH DATA READ FROM  
;RHCS3  
;BRANCH IF GOOD

; AFTER SETTING "CLR" BIT #5  
; IN RHCS2 TO INIT THE RH  
; ONE WORD OF ALL ONES IS  
; WRITTEN ON THE DEVICE  
; A WRITE CHECK WAS DONE  
; ON AN ODD WORD BOUNDARY THEN  
; AN RH CLEAR (RHCS2 BIT #5)  
; WAS GIVEN THIS SHOULD  
; CLEAR ALL ERRORS



9475 027062 104123  
9476  
9477  
9478  
9479  
9480  
9481  
9482  
9483  
9484  
9485  
9486  
9487  
9488 027064  
9489  
9490  
9491  
9492  
9493  
9494  
9495  
9496  
9497  
9498  
9499  
9500  
9501  
9502  
9503  
9504  
9505  
9506  
9507  
9508 027064 000004  
9509 027066 012706 001000  
9510 027072 012737 000036 004656  
9511  
9512 027100 004737 040322  
9513  
9514  
9515  
9516  
9517 027104 012737 177777 004210  
9518 027112 012777 177767 154742  
9519 027120 012777 004210 154736  
9520  
9521 027126 004077 155506  
9522 027132 004154  
9523  
9524  
9525 027134 005037 003000  
9526 027140 012777 177767 154714  
9527 027146 012777 003000 154710  
9528  
9529  
9530 027154 004077 155460

ERROR 123

; AFTER SETTING "CLR" BIT #5  
; IN RHCS2 TO INIT THE RH  
; ONE WORD OF ALL ONES IS  
; WRITTEN ON THE DEVICE  
; A WRITE CHECK WAS DONE  
; ON AN ODD WORD BOUNDARY THEN  
; AN RH CLEAR (RHCS2 BIT #5)  
; WAS GIVEN THIS SHOULD  
; CLEAR ALL ERRORS  
; RHWC SHOULD HAVE 0  
; BUT CONTAINED WHAT IS  
; GIVEN IN BAD RHWC

79\$:

\*\*\*\*\*  
; \*TEST 36 RHCS2-WCE BIT #14 AND RHCS3-WCE EW BIT #11

; \* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)  
; \* WRITE NINE WORD OF ALL NINES ON TO THE DEVICE  
; \* SET UP TO DO WRITE CHECK ON THAT WORD FROM AN  
; \* EVEN WORD BOUNDARY  
; \* DO A ONE WORD WRITE CHECK WITH RHBA FROM AN  
; \* EVEN WORD BOUNDARY  
; \* THIS SHOULD SET WCE EW (RHCS3 BIT #11)  
; \* AND WCE (RHCS2 BIT #14)  
; \* "CLR" (RHCS2 BIT #5) IS GIVEN  
; \* ALL ERRORS ARE CLEARED  
; \* CHECK RHCS1, RHCS2, RHCS3, RHBA, RHBAE, RHWC

\*\*\*\*\*  
†ST36:

SCOPE  
MOV #STACK, SP ; RESET STACK  
MOV #36, @†STNM ; SAVE TEST NUMBER  
JSR PC, @CLDISK ; GIVE RH INITIALIZE  
; SETUP UNIT NUBER  
; CLEAR RHWC AND FUNCTION BITS IN RHCS1  
; WRITE ONE WORD OF ALL ONES ON THE DEVICE  
MOV #-1, WRFROM ; ALL ONES INTO WRITE FROM  
MOV #-9, @RHWC ; NINE WORD FOR WORD COUNT REGISTER  
MOV #WRFROM, @RHBA ; WRITE FROM BUFFER INTO BUS ADDRESS  
JSR RO, @COMND ; GO TO DO COMMAND  
WRIDAT ; WRITE DATA  
; SET UP FOR WRITE CHECK  
CLR BUFEW ; WRITE DATA FOR WRITE CHECK ERROR  
MOV #-9, @RHWC ; NINE WORD FOR WORD COUNT REGISTER  
MOV #BUFEW, @RHBA ; WRITE FROM BUFFER INTO BUS ADDRESS  
; FROM EVEN WORD BOUNDARY  
; WRITE CHECK ON EVEN WORD BOUNDARY  
JSR RO, @COMND ; GO TO DO COMMAND



```

9587 027250 012737 004200 001124 MOV #RDY!DVA,$GDDAT ;GET GOOD = 4200
9588
9589 027256 017737 154576 001126 MOV @RHCS1,$BDDAT ;READ RHCS1 FOR COMPARISON
9590 027264 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
9591 ;DATA WITH DATA READ FROM
9592 ;RHCS1
9593 027272 001401 BEQ 69$;BRANCH IF GOOD
9594 027274 104116 ERROR 116
9595 ;AFTER SETTING "CLR" BIT #5
9596 ;IN RHCS2 TO INIT THE RH
9597 ;ONE WORD OF ALL ONES IS
9598 ;WRITTEN ON THE DEVICE
9599 ;A WRITE CHECK WAS DONE
9600 ;ON AN EVEN WORD BOUNDARY THEN
9601 ;AN RH CLEAR (RHCS2 BIT #5)
9602 ;WAS GIVEN THIS SHOULD
9603 ;CLEAR ALL ERRORS
9604 ;RHCS1 SHOULD HAVE RDY!DVA
9605 ;=4200
9606 ;BUT CONTAINED WHAT IS
9607 ;GIVEN IN BAD RHCS1
9608 027276 69$:
9609 ;CHECK THAT RHCS2 HAS IR
9610 027276 012737 000100 001124 MOV #IR,$GDDAT ;GET GOOD = 100
9611 027304 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
9612
9613 027312 017737 154552 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
9614 027320 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
9615 ;DATA WITH DATA READ FROM
9616 ;RHCS2
9617 027326 001401 BEQ 71$;BRANCH IF GOOD
9618 027330 104117 ERROR 117
9619 ;AFTER SETTING "CLR" BIT #5
9620 ;IN RHCS2 TO INIT THE RH
9621 ;ONE WORD OF ALL ONES IS
9622 ;WRITTEN ON THE DEVICE
9623 ;A WRITE CHECK WAS DONE
9624 ;ON AN EVEN WORD BOUNDARY THEN
9625 ;AN RH CLEAR (RHCS2 BIT #5)
9626 ;WAS GIVEN THIS SHOULD
9627 ;CLEAR ALL ERRORS
9628 ;RHCS2 SHOULD HAVE IR
9629 ;=100
9630 ;TOGETHER WITH UNIT NUMBER
9631 ;BUT CONTAINED WHAT IS
9632 ;GIVEN IN BAD RHCS2
9633 027332 71$:
9634 ;CHECK THAT RHCS3 HAS 0
9635 027332 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
9636
9637 027340 017737 154566 001126 MOV @RHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON
9638 027346 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
9639 ;DATA WITH DATA READ FROM
9640 ;RHCS3
9641 027354 001401 BEQ 73$;BRANCH IF GOOD
9642 027356 104120 ERROR 120

```

; AFTER SETTING "CLR" BIT #5  
; IN RHCS2 TO INIT THE RH  
; ONE WORD OF ALL ONES IS  
; WRITTEN ON THE DEVICE  
; A WRITE CHECK WAS DONE  
; ON AN EVEN WORD BOUNDARY THEN  
; AN RH CLEAR (RHCS2 BIT #5)  
; WAS GIVEN THIS SHOULD  
; CLEAR ALL ERRORS  
; RHCS3 SHOULD HAVE 0  
; BUT CONTAINED WHAT IS  
; GIVEN IN BAD RHCS3

; GET GOOD = 0

; READ RHBA FOR COMPARISON  
; COMPARE EXPECTED  
; DATA WITH DATA READ FROM  
; RHBA  
; BRANCH IF GOOD

; AFTER SETTING "CLR" BIT #5  
; IN RHCS2 TO INIT THE RH  
; ONE WORD OF ALL ONES IS  
; WRITTEN ON THE DEVICE  
; A WRITE CHECK WAS DONE  
; ON AN EVEN WORD BOUNDARY THEN  
; AN RH CLEAR (RHCS2 BIT #5)  
; WAS GIVEN THIS SHOULD  
; CLEAR ALL ERRORS  
; RHBA SHOULD HAVE 0  
; BUT CONTAINED WHAT IS  
; GIVEN IN BAD RHBA

; GET GOOD = 0

; READ RHBAE FOR COMPARISON  
; COMPARE EXPECTED  
; DATA WITH DATA READ FROM  
; RHBAE  
; BRANCH IF GOOD

; AFTER SETTING "CLR" BIT #5  
; IN RHCS2 TO INIT THE RH  
; ONE WORD OF ALL ONES IS  
; WRITTEN ON THE DEVICE  
; A WRITE CHECK WAS DONE  
; ON AN EVEN WORD BOUNDARY THEN  
; AN RH CLEAR (RHCS2 BIT #5)  
; WAS GIVEN THIS SHOULD  
; CLEAR ALL ERRORS  
; RHBAE SHOULD HAVE 0  
; BUT CONTAINED WHAT IS  
; GIVEN IN BAD RHBAE

9643  
9644  
9645  
9646  
9647  
9648  
9649  
9650  
9651  
9652  
9653  
9654  
9655 027360 73\$:  
9656  
9657 027360 012737 000000 001124  
9658  
9659 027366 017737 154472 001126  
9660 027374 023737 001124 001126  
9661  
9662  
9663 027402 001401  
9664 027404 104121  
9665  
9666  
9667  
9668  
9669  
9670  
9671  
9672  
9673  
9674  
9675  
9676  
9677 027406 75\$:  
9678  
9679 027406 012737 000000 001124  
9680  
9681 027414 017737 154510 001126  
9682 027422 023737 001124 001126  
9683  
9684  
9685 027430 001401  
9686 027432 104122  
9687  
9688  
9689  
9690  
9691  
9692  
9693  
9694  
9695  
9696  
9697  
9698  
9699

; CHECK THAT RHBA HAS 0  
MOV #C,\$GDDAT  
MOV @RHBA,\$BDDAT  
CMP \$GDDAT,\$BDDAT  
BEQ 75\$  
ERROR 121

; CHECK THAT RHBAE HAS 0  
MOV #0,\$GDDAT  
MOV @RHBAE,\$BDDAT  
CMP \$GDDAT,\$BDDAT  
BEQ 77\$  
ERROR 122

```

9699 027434 77$:
9700 ;CHECK THAT RHWC HAS 0
9701 027434 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
9702 ;
9703 027442 017737 154414 001126 MOV @RHWC,$BDDAT ;READ RHWC FOR COMPARISON
9704 027450 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
9705 ;DATA WITH DATA READ FROM
9706 ;RHWC
9707 027456 001401 BEG 79$;BRANCH IF GOOD
9708 027460 104123 ERROR 123
9709 ;
9710 ;AFTER SETTING "CLR" BIT #5
9711 ;IN RHCS2 TO INIT THE RH
9712 ;ONE WORD OF ALL ONES IS
9713 ;WRITTEN ON THE DEVICE
9714 ;A WRITE CHECK WAS DONE
9715 ;ON AN EVEN WORD BOUNDARY THEN
9716 ;AN RH CLEAR (RHCS2 BIT #5)
9717 ;WAS GIVEN THIS SHOULD
9718 ;CLEAR ALL ERRORS
9719 ;RHWC SHOULD HAVE 0
9720 ;BUT CONTAINED WHAT IS
9721 ;GIVEN IN BAD RHWC
9721 027462 79$:
9722
9723
9724
9725 ;*****
9726 ;*TEST 37 RHCS2-WCE BIT #14 AND RHCS3-WCE EW BIT #11
9727
9728 ;*
9729 ;* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
9730 ;* WRITE NINE WORD OF ALL NINES ON TO THE DEVICE
9731 ;* SET UP TO DO WRITE CHECK ON THAT WORD FROM AN
9732 ;* EVEN WORD BOUNDARY
9733 ;* DO A ONE WORD WRITE CHECK WITH RHBA FROM AN
9734 ;* EVEN WORD BOUNDARY
9735 ;* THIS SHOULD SET WCE EW (RHCS3 BIT #11)
9736 ;* AND WCE (RHCS2 BIT #14)
9737 ;* "CLR" (RHCS2 BIT #5) IS GIVEN
9738 ;* ALL ERRORS ARE CLEARED
9739 ;* CHECK RHCS1, RHCS2, RHCS3, RHBA, RHBAE, RHWC
9740 ;*****
9741 027462 000004 TST37: SCOPE
9742 027464 012706 001000 MOV #STACK SP ;RESET STACK
9743 027470 012737 000037 004656 MOV #37,@#TSTNM ;SAVE TEST NUMBER
9744
9745 027476 004737 040322 JSR PC,@#CLDISK ;GIVE RH INITIALIZE
9746 ;SETUP UNIT NUBER
9747 ;CLEAR RHWC AND FUNCTION BITS IN RHCS1
9748
9749 ;WRITE ONE WORD OF ALL ONES ON THE DEVICE
9750 027502 012737 177777 004210 MOV #-1,WRFROM ;ALL ONES INTO WRITE FROM
9751 027510 012777 177767 154344 MOV #-9,@RHWC ;NINE WORD FOR WORD COUNT REGISTER
9752 027516 012777 004210 154340 MOV #WRFROM,@RHBA ;WRITE FROM BUFFER INTO BUS ADDRESS
9753
9754 027524 004077 155110 JSR RD,@COMND ;GO TO DO COMMAND

```



```

9755 027530 004154 WRIDAT ;WRITE DATA
9756
9757 ;SET UP FOR WRITE CHECK
9758 027532 005037 003000 CLR BUFEW ;WRITE DATA FOR WRITE CHECK ERROR
9759 027536 012777 177767 154316 MOV #-9,DRHWC ;NINE WORD FOR WORD COUNT REGISTER
9760 027544 012777 003000 154312 MOV #BUFEW,DRHBA ;WRITE FROM BUFFER INTO BUS ADDRESS
9761 ;FROM EVEN WORD BOUNDARY
9762 ;WRITE CHECK ON EVEN WORD BOUNDARY
9763 027552 004077 155062 JSR RD,DCOMND ;GO TO DO COMMAND
9764 027556 004150 WRCHEK ;WRITE CHECK DATA
9765
9766
9767
9768
9769 ;CHECK THAT RHCS2 HAS WCE!OR!IR
9770 027563 012737 040300 001124 MOV #WCE!OR!IR,$GDDAT ;GET GOOD = 40300
9771 027565 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
9772
9773 027574 017737 154270 001126 MOV DRHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
9774 027602 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
9775 ;DATA WITH DATA READ FROM
9776 ;RHCS2
9777 027610 001401 BEQ 65$;BRANCH IF GOOD
9778 027612 104114 ERROR 114
9779 ;AFTER SETTING "CLR" BIT #5
9780 ;IN RHCS2 TO INIT THE RH
9781 ;ONE WORD OF ALL ONES IS
9782 ;WRITTEN ON THE DEVICE
9783 ;A WRITE CHECK WAS DONE
9784 ;ON AN EVEN WORD BOUNDARY THEN
9785 ;RHCS2 SHOULD HAVE WCE!OR!IR
9786 ;=40300
9787 ;TOGETHER WITH UNIT NUMBER
9788 ;BUT CONTAINED WHAT IS
9789 ;GIVEN IN BAD RHCS2
9790 027614 65$:
9791
9792 ;CHECK THAT RHCS3 HAS DBL!WCEEW
9793 027614 012737 006000 001124 MOV #DBL!WCEEW,$GDDAT ;GET GOOD = 6000
9794
9795 027622 017737 154304 001126 MOV DRHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON
9796 027630 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
9797 ;DATA WITH DATA READ FROM
9798 ;RHCS3
9799 027636 001401 BEQ 67$;BRANCH IF GOOD
9800 027640 104115 ERROR 115
9801 ;AFTER SETTING "CLR" BIT #5
9802 ;IN RHCS2 TO INIT THE RH
9803 ;ONE WORD OF ALL ONES IS
9804 ;WRITTEN ON THE DEVICE
9805 ;A WRITE CHECK WAS DONE
9806 ;ON AN EVEN WORD BOUNDARY THEN
9807 ;RHCS3 SHOULD HAVE DBL!WCEEW
9808 ;=6000
9809 ;BUT CONTAINED WHAT IS
9810 ;GIVEN IN BAD RHCS3

```

```

9811 027642 67$:
9812
9813
9814 027642 004737 040322 JSR PC, @#CLDISK ;GIVE RH INITIALIZE
9815 ;SETUP UNIT NUBER
9816 ;CLEAR RHWC AND FUNCTION BITS IN RHCS1
9817
9818
9819 ;CHECK THAT RHCS1 HAS RDY!DVA
9820 027646 012737 004200 001124 MOV #RDY!DVA, $GDDAT ;GET GOOD = 4200
9821
9822 027654 017737 154200 001126 MOV @RHCS1, $BDDAT ;READ RHCS1 FOR COMPARISON
9823 027662 023737 001124 001126 CMP $GDDAT, $BDDAT ;COMPARE EXPECTED
9824 ;DATA WITH DATA READ FROM
9825 ;RHCS1
9826 027670 001401 BEQ 69$;BRANCH IF GOOD
9827 027672 104116 ERROR 116
9828
9829 ;AFTER SETTING "CLR" BIT #5
9830 ;IN RHCS2 TO INIT THE RH
9831 ;ONE WORD OF ALL ONES IS
9832 ;WRITTEN ON THE DEVICE
9833 ;A WRITE CHECK WAS DONE
9834 ;ON AN EVEN WORD BOUNDARY THEN
9835 ;AN RH CLEAR (RHCS2 BIT #5)
9836 ;WAS GIVEN THIS SHOULD
9837 ;CLEAR ALL ERRORS
9838 ;RHCS1 SHOULD HAVE RDY!DVA
9839 ;=4200
9840 ;BUT CONTAINED WHAT IS
9841 ;GIVEN IN BAD RHCS1
9841 027674 69$:
9842
9843 027674 012737 000100 001124 MOV #IR, $GDDAT ;GET GOOD = 100
9844 027702 053737 005010 001124 BIS UNIT, $GDDAT ;INCLUDE UNIT NUMBER
9845
9846 027710 017737 154154 001126 MOV @RHCS2, $BDDAT ;READ RHCS2 FOR COMPARISON
9847 027716 023737 001124 001126 CMP $GDDAT, $BDDAT ;COMPARE EXPECTED
9848 ;DATA WITH DATA READ FROM
9849 ;RHCS2
9850 027724 001401 BEQ 71$;BRANCH IF GOOD
9851 027726 104117 ERROR 117
9852
9853 ;AFTER SETTING "CLR" BIT #5
9854 ;IN RHCS2 TO INIT THE RH
9855 ;ONE WORD OF ALL ONES IS
9856 ;WRITTEN ON THE DEVICE
9857 ;A WRITE CHECK WAS DONE
9858 ;ON AN EVEN WORD BOUNDARY THEN
9859 ;AN RH CLEAR (RHCS2 BIT #5)
9860 ;WAS GIVEN THIS SHOULD
9861 ;CLEAR ALL ERRORS
9862 ;RHCS2 SHOULD HAVE IR
9863 ;=100
9864 ;TOGETHER WITH UNIT NUMBER
9865 ;BUT CONTAINED WHAT IS
9866 027730 71$:
9866 ;GIVEN IN BAD RHCS2

```



```

9923 ;WRITTEN ON THE DEVICE
9924 ;A WRITE CHECK WAS DONE
9925 ;ON AN EVEN WORD BOUNDARY THEN
9926 ;AN RH CLEAR (RHCS2 BIT #5)
9927 ;WAS GIVEN THIS SHOULD
9928 ;CLEAR ALL ERRORS
9929 ;RHBAE SHOULD HAVE 0
9930 ;BUT CONTAINED WHAT IS
9931 ;GIVEN IN BAD RHBAE
9932 030032 77$:
9933 ;CHECK THAT RHCW HAS 0
9934 030032 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
9935
9936 030040 017737 154016 001126 MOV @RHCW,$BDDAT ;READ RHCW FOR COMPARISON
9937 030046 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
9938 ;DATA WITH DATA READ FROM
9939 ;RHCW
9940 030054 001401 BEQ 79$;BRANCH IF GOOD
9941 030056 104123 ERROR 123
9942
9943 ;AFTER SETTING "CLR" BIT #5
9944 ;IN RHCS2 TO INIT THE RH
9945 ;ONE WORD OF ALL ONES IS
9946 ;WRITTEN ON THE DEVICE
9947 ;A WRITE CHECK WAS DONE
9948 ;ON AN EVEN WORD BOUNDARY THEN
9949 ;AN RH CLEAR (RHCS2 BIT #5)
9950 ;WAS GIVEN THIS SHOULD
9951 ;CLEAR ALL ERRORS
9952 ;RHCW SHOULD HAVE 0
9953 ;BUT CONTAINED WHAT IS
9954 030060 79$:
9955 ;GIVEN IN BAD RHCW
9956
9957
9958
9959 ;*****
9960 ;*TEST 40 TEST DBL (RHCS3 BIT #10) TEST A
9961
9962 ;*
9963 ;* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
9964 ;* SET UP FOR A NINE WORD WRITE FROM AN EVEN WORD BOUNDARY
9965 ;* DO A NINE WORD WRITE FROM AN EVEN WORD BOUNDARY
9966 ;* THIS SHOULD NOT SET RHCS3 BIT #10 DBL
9967 ;* CHECK RHCS3
9968 ;* CHECK RHCS1,RHCS2,RHBA,RHBAE,RHCW
9969 ;*****
9970 030060 000004 †ST40: SCOPE
9971 030062 012706 001000 MOV #STACK,SP ;RESET STACK
9972 030066 012737 000040 004656 MOV #40,@†STNM ;SAVE TEST NUMBER
9973
9974 030074 004737 040322 JSR PC,@#CLDISK ;GIVE RH INITIALIZE
9975 ;SETUP UNIT NUBER
9976 ;CLEAR RHCW AND FUNCTION BITS IN RHCS1
9977
9978 ;SET UP FOR A NINE WORD WRITE FROM AN EVEN WORD BOUNDARY

```

```

9979 030100 012701 000003 MOV #3,R1 ;COUNT OF THREE
9980 030104 012702 003000 MOV #BFEVEN,R2 ;START THREE WORD BUFFER
9981 ;FROM AN EVEN WORD BOUNDARY
9982 030110 012722 052525 1$: MOV #52525,(R2)+ ;MOVE THREE 52525 INTO BUFFER
9983 030114 005301 DEC R1 ;COUNT
9984 030116 001374 BNE 1$;BRANCH IF THREE NOT DONE
9985 030120 012777 003000 153736 MOV #BFEVEN,ARHBA ;SET BUS ADDRESS TO START
9986 ;FROM AN EVEN WORD BOUNDARY
9987 030126 012777 177767 153726 MOV #-9,ARHWC ;WORD COUNT NINE
9988 030134 004077 154500 JSR RO,ACOMND ;GO TO DO COMMAND
9989 030140 004154 WRIDAT ;WRITE DATA
9990
9991
9992 ;CHECK THAT RHCS3 HAS 0
9993 030142 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
9994
9995 030150 017737 153756 001126 MOV ARHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON
9996 030156 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
9997 ;DATA WITH DATA READ FROM
9998 ;RHCS3
9999 030164 001401 BEQ 65$;BRANCH IF GOOD
10000 030166 104124 ERROR 124
10001 ;AFTER SETTING "CLR" BIT #5
10002 ;IN RHCS2 TO INIT THE RH
10003 ;A NINE WORD WRITE FROM AN
10004 ;EVEN WORD BOUNDARY WAS DONE
10005 ;THEN
10006 ;RHCS3 SHOULD HAVE 0
10007 ;BUT CONTAINED WHAT IS
10008 ;GIVEN IN BAD RHCS3
10009 030170 65$:
10010 030170 042777 000076 153662 BIC #76,ARHCS1 ;CLEAR FUNCTION BITS
10011 ;CHECK THAT RHCS1 HAS RDY!DVA
10012 030176 012737 004200 001124 MOV #RDY!DVA,$GDDAT ;GET GOOD = 4200
10013
10014 030204 017737 153650 001126 MOV ARHCS1,$BDDAT ;READ RHCS1 FOR COMPARISON
10015 030212 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
10016 ;DATA WITH DATA READ FROM
10017 ;RHCS1
10018 030220 001401 BEQ 67$;BRANCH IF GOOD
10019 030222 104125 ERROR 125
10020 ;AFTER SETTING "CLR" BIT #5
10021 ;IN RHCS2 TO INIT THE RH
10022 ;A NINE WORD WRITE FROM AN
10023 ;EVEN WORD BOUNDARY WAS DONE
10024 ;THEN
10025 ;RHCS1 SHOULD HAVE RDY!DVA
10026 ;=4200
10027 ;BUT CONTAINED WHAT IS
10028 ;GIVEN IN BAD RHCS1
10029 030224 67$:
10030 ;CHECK THAT RHCS2 HAS IR
10031 030224 012737 000100 001124 MOV #IR,$GDDAT ;GET GOOD = 100
10032 030232 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
10033
10034 030240 017737 153624 001126 MOV ARHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON

```

```

10035 030246 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
10036 ;DATA WITH DATA READ FROM
10037 ;RHCS2
10038 030254 001401 BEQ 69$;BRANCH IF GOOD
10039 030256 104126 ERROR 126
10040 ;AFTER SETTING "CLR" BIT #5
10041 ;IN RHCS2 TO INIT THE RH
10042 ;A NINE WORD WRITE FROM AN
10043 ;EVEN WORD BOUNDARY WAS DONE
10044 ;THEN
10045 ;RHCS2 SHOULD HAVE IR
10046 ;=100
10047 ;TOGETHER WITH UNIT NUMBER
10048 ;BUT CONTAINED WHAT IS
10049 ;GIVEN IN BAD RHCS2
10050 030260 69$:
10051 ;CHECK THAT RHC HAS 0
10052 030260 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
10053
10054 030266 017737 153570 001126 MOV @RHC,$BDDAT ;READ RHC FOR COMPARISON
10055 030274 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
10056 ;DATA WITH DATA READ FROM
10057 ;RHC
10058 030302 001401 BEQ 71$;BRANCH IF GOOD
10059 030304 104131 ERROR 131
10060 ;AFTER SETTING "CLR" BIT #5
10061 ;IN RHCS2 TO INIT THE RH
10062 ;A NINE WORD WRITE FROM AN
10063 ;EVEN WORD BOUNDARY WAS DONE
10064 ;THEN
10065 ;RHC SHOULD HAVE 0
10066 ;BUT CONTAINED WHAT IS
10067 ;GIVEN IN BAD RHC
10068 030306 71$:
10069
10070
10071
10072 ;*****
10073 ;*TEST 41 TEST DBL (RHCS3 BIT #10) TEST B
10074
10075 ;*
10076 ;* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
10077 ;* SET UP FOR A TEN WORD WRITE FROM AN EVEN WORD BOUNDARY
10078 ;* DO A TEN WORD WRITE FROM AN EVEN WORD BOUNDARY
10079 ;* THIS SHOULD SET RHCS3 BIT #10 DBL
10080 ;* CHECK RHCS3
10081 ;* CHECK RHCS1,RHCS2,RHBA,RHBAE,RHC
10082 ;*****
10083 030306 000004 †ST41: SCOPE
10084 030310 012706 001000 MOV #STACK,SP ;RESET STACK
10085 030314 012737 000041 004656 MOV #41,@†STNM ;SAVE TEST NUMBER
10086
10087 030322 004737 040322 JSR PC,@CLDISK ;GIVE RH INITIALIZE
10088 ;SETUP UNIT NUMBER
10089 ;CLEAR RHC AND FUNCTION BITS IN RHCS1
10090

```

```

10091 ;SET UP FOR A TEN WORD WRITE FROM AN EVEN WORD BOUNDARY
10092 030326 012701 000003 MOV #3,R1 ;COUNT OF THREE
10093 030332 012702 003000 MOV #BFEVEN,R2 ;START THREE WORD BUFFER
10094 ;FROM AN EVEN WORD BOUNDARY
10095 030336 012722 052525 1$: MOV #52525,(R2)+ ;MOVE THREE 52525 INTO BUFFER
10096 030342 005301 DEC R1 ;COUNT
10097 030344 001374 BNE 1$;BRANCH IF THREE NOT DONE
10098 030346 012777 003000 153510 MOV #BFEVEN,ARHBA ;SET BUS ADDRESS TO START
10099 ;FROM AN EVEN WORD BOUNDARY
10100 030354 012777 177766 153500 MOV #-10,ARHWC ;WORD COUNT TEN
10101 030362 004077 154252 JSR R0,ACOMND ;GO TO DO COMMAND
10102 030366 004154 WRIDAT ;WRITE DATA
10103
10104
10105 ;CHECK THAT RHCS3 HAS DBL
10106 030370 012737 002000 001124 MOV #DBL,$GDDAT ;GET GOOD = 2000
10107
10108 030376 017737 153530 001126 MOV ARHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON
10109 030404 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
10110 ;DATA WITH DATA READ FROM
10111 ;RHCS3
10112 030412 001401 BEQ 65$;BRANCH IF GOOD
10113 030414 104124 ERROR 124
10114 ;AFTER SETTING "CLR" BIT #5
10115 ;IN RHCS2 TO INIT THE RH
10116 ;A TEN WORD WRITE FROM AN
10117 ;EVEN WORD BOUNDARY WAS DONE
10118 ;THEN
10119 ;RHCS3 SHOULD HAVE DBL
10120 ;=2000
10121 ;BUT CONTAINED WHAT IS
10122 ;GIVEN IN BAD RHCS3
10123 030416 65$: BIC #76,ARHCS1 ;CLEAR FUNCTION BITS
10124 030416 042777 000076 153434 ;CHECK THAT RHCS1 HAS RDY!DVA
10125 MOV #RDY!DVA,$GDDAT ;GET GOOD = 4200
10126 030424 012737 004200 001124
10127
10128 030432 017737 153422 001126 MOV ARHCS1,$BDDAT ;READ RHCS1 FOR COMPARISON
10129 030440 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
10130 ;DATA WITH DATA READ FROM
10131 ;RHCS1
10132 030446 001401 BEQ 67$;BRANCH IF GOOD
10133 030450 104125 ERROR 125
10134 ;AFTER SETTING "CLR" BIT #5
10135 ;IN RHCS2 TO INIT THE RH
10136 ;A TEN WORD WRITE FROM AN
10137 ;EVEN WORD BOUNDARY WAS DONE
10138 ;THEN
10139 ;RHCS1 SHOULD HAVE RDY!DVA
10140 ;=4200
10141 ;BUT CONTAINED WHAT IS
10142 ;GIVEN IN BAD RHCS1
10143 030452 67$: ;CHECK THAT RHCS2 HAS IR
10144 MOV #IR,$GDDAT ;GET GOOD = 100
10145 030452 012737 000100 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
10146 030460 053737 005010 001124

```

```

10147
10148 030466 017737 153376 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
10149 030474 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
10150 ;DATA WITH DATA READ FROM
10151 ;RHCS2
10152 030502 001401 BEQ 69$;BRANCH IF GOOD
10153 030504 104126 ERROR 126
10154 ;AFTER SETTING "CLR" BIT #5
10155 ;IN RHCS2 TO INIT THE RH
10156 ;A TEN WORD WRITE FROM AN
10157 ;EVEN WORD BOUNDARY WAS DONE
10158 ;THEN
10159 ;RHCS2 SHOULD HAVE IR
10160 ;=100
10161 ;TOGETHER WITH UNIT NUMBER
10162 ;BUT CONTAINED WHAT IS
10163 ;GIVEN IN BAD RHCS2
10164 030506 69$:
10165 ;CHECK THAT RHC HAS 0
10166 030506 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
10167
10168 030514 017737 153342 001126 MOV @RHC,$BDDAT ;READ RHC FOR COMPARISON
10169 030522 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
10170 ;DATA WITH DATA READ FROM
10171 ;RHC
10172 030530 001401 BEQ 71$;BRANCH IF GOOD
10173 030532 104131 ERROR 131
10174 ;AFTER SETTING "CLR" BIT #5
10175 ;IN RHCS2 TO INIT THE RH
10176 ;A TEN WORD WRITE FROM AN
10177 ;EVEN WORD BOUNDARY WAS DONE
10178 ;THEN
10179 ;RHC SHOULD HAVE 0
10180 ;BUT CONTAINED WHAT IS
10181 ;GIVEN IN BAD RHC
10182 030534 71$:
10183
10184
10185
10186
10187
10188
10189
10190
10191
10192
10193
10194
10195
10196
10197 030534 000004 TST42: SCOPE
10198 030536 012706 001000 MOV #STACK,SP ;RESET STACK
10199 030542 012737 000042 004656 MOV #42,@TSTNM ;SAVE TEST NUMBER
10200
10201 030550 004737 040322 JSR PC,@CLDISK ;GIVE RH INITIALIZE
10202 ;SETUP UNIT NUBER

```

::\*\*\*\*\*  
;\*TEST 42 TEST DBL (RHCS3 BIT #10) TEST C

;\* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)  
;\* SET UP FOR A TEN WORD WRITE FROM AN ODD WORD BOUNDARY  
;\* DO A TEN WORD WRITE FROM AN ODD WORD BOUNDARY  
;\* THIS SHOULD NOT SET RHCS3 BIT #10 DBL  
;\* CHECK RHCS3  
;\* CHECK RHCS1,RHCS2,RHBA,RHBAE,RHC

::\*\*\*\*\*



```

10203 ;CLEAR RHWC AND FUNCTION BITS IN RHCS1
10204
10205 ;SET UP FOR A TEN WORD WRITE FROM AN ODD WORD BOUNDARY
10206 030554 012701 000003 MOV #3,R1 ;COUNT OF THREE
10207 030560 012702 003002 MOV #BF0DD,R2 ;START THREE WORD BUFFER
10208 ;FROM AN ODD WORD BOUNDARY
10209 030564 012722 052525 1$: MOV #52525,(R2)+ ;MOVE THREE 52525 INTO BUFFER
10210 030570 005301 DEC R1 ;COUNT
10211 030572 001374 BNE 1$;BRANCH IF THREE NOT DONE
10212 030574 012777 003002 153262 MOV #BF0DD,DRHBA ;SET BUS ADDRESS TO START
10213 ;FROM AN ODD WORD BOUNDARY
10214 030602 012777 177766 153252 MOV #-10,DRHWC ;WORD COUNT TEN
10215 030610 004077 154024 JSR RD,DCOMND ;GO TO DO COMMAND
10216 030614 004154 WRIDAT ;WRITE DATA
10217
10218
10219 ;CHECK THAT RHCS3 HAS 0
10220 030616 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
10221
10222 030624 017737 153302 001126 MOV DRHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON
10223 030632 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
10224 ;DATA WITH DATA READ FROM
10225 ;RHCS3
10226 030640 001401 BEQ 65$;BRANCH IF GOOD
10227 030642 104124 ERROR 124
10228
10229 ;AFTER SETTING "CLR" BIT #5
10230 ;IN RHCS2 TO INIT THE RH
10231 ;A TEN WORD WRITE FROM AN
10232 ;ODD WORD BOUNDARY WAS DONE
10233 ;THEN
10234 ;RHCS3 SHOULD HAVE 0
10235 ;BUT CONTAINED WHAT IS
10236 ;GIVEN IN BAD RHCS3
10236 030644 042777 000076 153206 65$: BIC #76,DRHCS1 ;CLEAR FUNCTION BITS
10237 030644 ;CHECK THAT RHCS1 HAS RDY!DVA
10238 MOV #RDY!DVA,$GDDAT ;GET GOOD = 4200
10239 030652 012737 004200 001124
10240
10241 030660 017737 153174 001126 MOV DRHCS1,$BDDAT ;READ RHCS1 FOR COMPARISON
10242 030666 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
10243 ;DATA WITH DATA READ FROM
10244 ;RHCS1
10245 030674 001401 BEQ 67$;BRANCH IF GOOD
10246 030676 104125 ERROR 125
10247
10248 ;AFTER SETTING "CLR" BIT #5
10249 ;IN RHCS2 TO INIT THE RH
10250 ;A TEN WORD WRITE FROM AN
10251 ;ODD WORD BOUNDARY WAS DONE
10252 ;THEN
10253 ;RHCS1 SHOULD HAVE RDY!DVA
10254 ;=4200
10255 ;BUT CONTAINED WHAT IS
10256 ;GIVEN IN BAD RHCS1
10256 030700 67$:
10257
10258 030700 012737 000100 001124 ;CHECK THAT RHCS2 HAS IR
MOV #IR,$GDDAT ;GET GOOD = 100

```

```

10259 030706 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
10260
10261 030714 017737 153150 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
10262 030722 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
10263 ;DATA WITH DATA READ FROM
10264 ;RHCS2
10265 030730 001401 BEQ 69$;BRANCH IF GOOD
10266 030732 104126 ERROR 126
10267 ;AFTER SETTING "CLR" BIT #5
10268 ;IN RHCS2 TO INIT THE RH
10269 ;A TEN WORD WRITE FROM AN
10270 ;ODD WORD BOUNDARY WAS DONE
10271 ;THEN
10272 ;RHCS2 SHOULD HAVE IR
10273 ;=100
10274 ;TOGETHER WITH UNIT NUMBER
10275 ;BUT CONTAINED WHAT IS
10276 ;GIVEN IN BAD RHCS2
10277 030734 69$:
10278 ;CHECK THAT RHWC HAS 0
10279 030734 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
10280
10281 030742 017737 153114 001126 MOV @RHWC,$BDDAT ;READ RHWC FOR COMPARISON
10282 030750 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
10283 ;DATA WITH DATA READ FROM
10284 ;RHWC
10285 030756 001401 BEQ 71$;BRANCH IF GOOD
10286 030760 104131 ERROR 131
10287 ;AFTER SETTING "CLR" BIT #5
10288 ;IN RHCS2 TO INIT THE RH
10289 ;A TEN WORD WRITE FROM AN
10290 ;ODD WORD BOUNDARY WAS DONE
10291 ;THEN
10292 ;RHWC SHOULD HAVE 0
10293 ;BUT CONTAINED WHAT IS
10294 ;GIVEN IN BAD RHWC
10295 030762 71$:
10296
10297
10298
10299
10300 ;*****
10301 ;*TEST 43 TEST DBL (RHCS3 BIT #10) TEST D
10302
10303 ;* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
10304 ;* SET UP FOR A ELEVEN WORD WRITE FROM AN EVEN WORD BOUNDARY
10305 ;* DO A ELEVEN WORD WRITE FROM AN EVEN WORD BOUNDARY
10306 ;* THIS SHOULD NOT SET RHCS3 BIT #10 DBL
10307 ;* CHECK RHCS3
10308 ;* CHECK RHCS1,RHCS2,RHBA,RHBAE,RHWC
10309 ;*****
10310 030762 000004 TST43: SCOPE
10311 030764 012706 001000 MOV #STACK,SP ;RESET STACK
10312 030770 012737 000043 004656 MOV #43,@TSTNM ;SAVE TEST NUMBER
10313
10314 030776 004737 040322 JSR PC,@CLDISK ;GIVE RH INITIALIZE

```



```

10371 031126 012737 000100 001124 MOV #IR,$GDDAT ;GET GOOD = 100
10372 031134 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
10373
10374 031142 017737 152722 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
10375 031150 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
10376 ;DATA WITH DATA READ FROM
10377 ;RHCS2
10378 031156 001401 BEQ 69$;BRANCH IF GOOD
10379 031160 104126 ERROR 126
10380 ;AFTER SETTING "CLR" BIT #5
10381 ;IN RHCS2 TO INIT THE RH
10382 ;A ELEVEN WORD WRITE FROM AN
10383 ;EVEN WORD BOUNDARY WAS DONE
10384 ;THEN
10385 ;RHCS2 SHOULD HAVE IR
10386 ;=100
10387 ;TOGETHER WITH UNIT NUMBER
10388 ;BUT CONTAINED WHAT IS
10389 ;GIVEN IN BAD RHCS2
10390 031162 69$:
10391 ;CHECK THAT RHC HAS 0
10392 031162 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
10393
10394 031170 017737 152666 001126 MOV @RHC,$BDDAT ;READ RHC FOR COMPARISON
10395 031176 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
10396 ;DATA WITH DATA READ FROM
10397 ;RHC
10398 031204 001401 BEQ 71$;BRANCH IF GOOD
10399 031206 104131 ERROR 131
10400 ;AFTER SETTING "CLR" BIT #5
10401 ;IN RHCS2 TO INIT THE RH
10402 ;A ELEVEN WORD WRITE FROM AN
10403 ;EVEN WORD BOUNDARY WAS DONE
10404 ;THEN
10405 ;RHC SHOULD HAVE 0
10406 ;BUT CONTAINED WHAT IS
10407 ;GIVEN IN BAD RHC
10408 031210 71$:

```

```

*TEST 44 TEST DBL (RHCS3 BIT #10) TEST E

```

```

* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
* SET UP FOR A TEN WORD WRITE FROM AN EVEN WORD BOUNDARY
* WITH BAI IN RHCS2 BIT #3 SET
* DO A TEN WORD WRITE FROM AN EVEN WORD BOUNDARY
* THIS SHOULD NOT SET RHCS3 BIT #10 DBL
* CHECK RHCS3
* CHECK RHCS1,RHCS2,RHBA,RHBAE,RHC

```

```

```

```

10424 031210 000004 TST44: SCOPE
10425 031212 012706 001000 MOV #STACK,SP ;RESET STACK
10426 031216 012737 000044 004656 MOV #44,@TSTNM ;SAVE TEST NUMBER

```

```

10427
10428 031224 004737 040322 JSR PC, @CLDISK ;GIVE RH INITIALIZE
10429 ;SETUP UNIT NUBER
10430 ;CLEAR RHWC AND FUNCTION BITS IN RHCS1
10431
10432 ;SET UP FOR A TEN WORD WRITE FROM AN EVEN WORD BOUNDARY
10433 031230 012701 000003 MOV #3,R1 ;COUNT OF THREE
10434 031234 012702 003000 MOV #BFEVEN,R2 ;START THREE WORD BUFFER
10435 ;FROM AN EVEN WORD BOUNDARY
10436 031240 012722 052525 1$: MOV #52525,(R2)+ ;MOVE THREE 52525 INTO BUFFER
10437 031244 005301 DEC R1 ;COUNT
10438 031246 001374 BNE 1$;BRANCH IF THREE NOT DONE
10439 031250 012777 003000 152606 MOV #BFEVEN,@RHBA ;SET BUS ADDRESS TO START
10440 ;FROM AN EVEN WORD BOUNDARY
10441 031256 012777 177766 152576 MOV #-10,@RHWC ;WORD COUNT TEN
10442 031264 052777 000010 152576 BIS #BAI,@RHCS2 ;SET BAI IN RHCS2
10443 031272 004077 153342 JSR @COMND ;GO TO DO COMMAND
10444 031276 004154 WRIDAT ;WRITE DATA
10445
10446
10447 ;CHECK THAT RHCS3 HAS 0
10448 031300 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
10449
10450 031306 017737 152620 001126 MOV @RHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON
10451 031314 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
10452 ;DATA WITH DATA READ FROM
10453 ;RHCS3
10454 031322 001401 BEQ 65$;BRANCH IF GOOD
10455 031324 104124 ERROR 124
10456 ;AFTER SETTING "CLR" BIT #5
10457 ;IN RHCS2 TO INIT THE RH
10458 ;A TEN WORD WRITE FROM AN
10459 ;EVEN WORD BOUNDARY WAS DONE
10460 ;WITH BAI IN RHCS2 SET
10461 ;THEN
10462 ;RHCS3 SHOULD HAVE 0
10463 ;BUT CONTAINED WHAT IS
10464 ;GIVEN IN BAD RHCS3
10465 031326 65$: BIC #76,@RHCS1 ;CLEAR FUNCTION BITS
10466 031326 042777 000076 152524 ;CHECK THAT RHCS1 HAS RDY!DVA
10467 MOV #RDY!DVA,$GDDAT ;GET GOOD = 4200
10468 031334 012737 004200 001124
10469
10470 031342 017737 152512 001126 MOV @RHCS1,$BDDAT ;READ RHCS1 FOR COMPARISON
10471 031350 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
10472 ;DATA WITH DATA READ FROM
10473 ;RHCS1
10474 031356 001401 BEQ 67$;BRANCH IF GOOD
10475 031360 104125 ERROR 125
10476 ;AFTER SETTING "CLR" BIT #5
10477 ;IN RHCS2 TO INIT THE RH
10478 ;A TEN WORD WRITE FROM AN
10479 ;EVEN WORD BOUNDARY WAS DONE
10480 ;WITH BAI IN RHCS2 SET
10481 ;THEN
10482 ;RHCS1 SHOULD HAVE RDY!DVA

```





```

10595 ;A ELEVEN WORD WRITE FROM AN
10596 ;ODD WORD BOUNDARY WAS DONE
10597 ;THEN
10598 ;RHCS1 SHOULD HAVE RDY!DVA
10599 ;=4200
10600 ;BUT CONTAINED WHAT IS
10601 ;GIVEN IN BAD RHCS1
10602 031610 67$:
10603 ;CHECK THAT RHCS2 HAS IR
10604 031610 012737 000100 001124 MOV #IR,$GDDAT ;GET GOOD = 100
10605 031616 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
10606
10607 031624 017737 152240 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
10608 031632 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
10609 ;DATA WITH DATA READ FROM
10610 ;RHCS2
10611 031640 001401 BEQ 69$;BRANCH IF GOOD
10612 031642 104126 ERROR 126
10613 ;AFTER SETTING "CLR" BIT #5
10614 ;IN RHCS2 TO INIT THE RH
10615 ;A ELEVEN WORD WRITE FROM AN
10616 ;ODD WORD BOUNDARY WAS DONE
10617 ;THEN
10618 ;RHCS2 SHOULD HAVE IR
10619 ;=100
10620 ;TOGETHER WITH UNIT NUMBER
10621 ;BUT CONTAINED WHAT IS
10622 ;GIVEN IN BAD RHCS2
10623 031644 69$:
10624 ;CHECK THAT RHWC HAS 0
10625 031644 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
10626
10627 031652 017737 152204 001126 MOV @RHWC,$BDDAT ;READ RHWC FOR COMPARISON
10628 031660 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
10629 ;DATA WITH DATA READ FROM
10630 ;RHWC
10631 031666 001401 BEQ 71$;BRANCH IF GOOD
10632 031670 104131 ERROR 131
10633 ;AFTER SETTING "CLR" BIT #5
10634 ;IN RHCS2 TO INIT THE RH
10635 ;A ELEVEN WORD WRITE FROM AN
10636 ;ODD WORD BOUNDARY WAS DONE
10637 ;THEN
10638 ;RHWC SHOULD HAVE 0
10639 ;BUT CONTAINED WHAT IS
10640 ;GIVEN IN BAD RHWC
10641 031672 71$:
10642
10643
10644
10645
10646 ;*****
10647 ;*TEST 46 TEST DBL (RHCS3 BIT #10) TEST G
10648
10649 ;* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
10650 ;* SET UP FOR A NINE WORD READ FROM AN EVEN WORD BOUNDARY

```



```

10651 : * DO A NINE WORD READ FROM AN EVEN WORD BOUNDARY
10652 : * THIS SHOULD NOT SET RHCS3 BIT #10 DBL
10653 : * CHECK RHCS3
10654 : * CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC
10655
10656 : *****
10657 031672 000004 TST46: SCOPE
10658 031674 012706 001000 MOV #STACK, SP ; RESET STACK
10659 031700 012737 000046 004656 MOV #46, @#TSTNM ; SAVE TEST NUMBER
10660
10661 031706 004737 040322 JSR PC, @#CLDISK ; GIVE RH INITIALIZE
10662 ; SETUP UNIT NUBER
10663 ; CLEAR RHWC AND FUNCTION BITS IN RHCS1
10664
10665 : SET UP FOR A NINE WORD READ FROM AN EVEN WORD BOUNDARY
10666 031712 012701 000003 MOV #3, R1 ; COUNT OF THREE
10667 031716 012702 003000 MOV #BFEVEN, R2 ; START THREE WORD BUFFER
10668 ; FROM AN EVEN WORD BOUNDARY
10669 031722 012722 052525 1$: MOV #52525, (R2)+ ; MOVE THREE 52525 INTO BUFFER
10670 031726 005301 ; COUNT
10671 031730 001374 ; BRANCH IF THREE NOT DONE
10672 031732 012777 003000 152124 MOV #BFEVEN, @RHBA ; SET BUS ADDRESS TO START
10673 ; FROM AN EVEN WORD BOUNDARY
10674 031740 012777 177767 152114 MOV #-9, @RHWC ; WORD COUNT NINE
10675 031746 004077 152666 JSR RO, @COMND ; GO TO DO COMMAND
10676 031752 004160 READAT ; READ DATA
10677
10678
10679 : CHECK THAT RHCS3 HAS 0
10680 031754 012737 000000 001124 MOV #0, $GDDAT ; GET GOOD = 0
10681
10682 031762 017737 152144 001126 MOV @RHCS3, $BDDAT ; READ RHCS3 FOR COMPARISON
10683 031770 023737 001124 001126 CMP $GDDAT, $BDDAT ; COMPARE EXPECTED
10684 ; DATA WITH DATA READ FROM
10685 ; RHCS3
10686 031776 001401 BEQ 65$; BRANCH IF GOOD
10687 032000 104124 ERROR 124
10688
10689 : AFTER SETTING "CLR" BIT #5
10690 : IN RHCS2 TO INIT THE RH
10691 : A NINE WORD READ FROM AN
10692 : EVEN WORD BOUNDARY WAS DONE
10693 : THEN
10694 : RHCS3 SHOULD HAVE 0
10695 : BUT CONTAINED WHAT IS
10696 : GIVEN IN BAD RHCS3
10696 032002 65$: BIC #76, @RHCS1 ; CLEAR FUNCTION BITS
10697 032002 042777 000076 152050 : CHECK THAT RHCS1 HAS RDY!DVA
10698 MOV #RDY!DVA, $GDDAT ; GET GOOD = 4200
10699 032010 012737 004200 001124
10700
10701 032016 017737 152036 001126 MOV @RHCS1, $BDDAT ; READ RHCS1 FOR COMPARISON
10702 032024 023737 001124 001126 CMP $GDDAT, $BDDAT ; COMPARE EXPECTED
10703 ; DATA WITH DATA READ FROM
10704 ; RHCS1
10705 032032 001401 BEQ 67$; BRANCH IF GOOD
10706 032034 104125 ERROR 125

```

```

10707 ;AFTER SETTING "CLR" BIT #5
10708 ;IN RHCS2 TO INIT THE RH
10709 ;A NINE WORD READ FROM AN
10710 ;EVEN WORD BOUNDARY WAS DONE
10711 ;THEN
10712 ;RHCS1 SHOULD HAVE RDY!DVA
10713 ;=4200
10714 ;BUT CONTAINED WHAT IS
10715 ;GIVEN IN BAD RHCS1
10716 032036 67$:
10717 ;CHECK THAT RHCS2 HAS IR
10718 032036 012737 000100 001124 MOV #IR,$GDDAT ;GET GOOD = 100
10719 032044 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
10720
10721 032052 017737 152012 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
10722 032060 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
10723 ;DATA WITH DATA READ FROM
10724 ;RHCS2
10725 032066 001401 BEQ 69$;BRANCH IF GOOD
10726 032070 104126
10727
10728 ;AFTER SETTING "CLR" BIT #5
10729 ;IN RHCS2 TO INIT THE RH
10730 ;A NINE WORD READ FROM AN
10731 ;EVEN WORD BOUNDARY WAS DONE
10732 ;THEN
10733 ;RHCS2 SHOULD HAVE IR
10734 ;=100
10735 ;TOGETHER WITH UNIT NUMBER
10736 ;BUT CONTAINED WHAT IS
10737 032072 69$:
10738 ;CHECK THAT RHWC HAS 0
10739 032072 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
10740
10741 032100 017737 151756 001126 MOV @RHWC,$BDDAT ;READ RHWC FOR COMPARISON
10742 032106 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
10743 ;DATA WITH DATA READ FROM
10744 ;RHWC
10745 032114 001401 BEQ 71$;BRANCH IF GOOD
10746 032116 104131
10747
10748 ;AFTER SETTING "CLR" BIT #5
10749 ;IN RHCS2 TO INIT THE RH
10750 ;A NINE WORD READ FROM AN
10751 ;EVEN WORD BOUNDARY WAS DONE
10752 ;THEN
10753 ;RHWC SHOULD HAVE 0
10754 ;BUT CONTAINED WHAT IS
10755 032120 71$:
10756 ;GIVEN IN BAD RHWC
10757
10758
10759 ;*****
10760 ;*TEST 47 TEST DBL (RHCS3 BIT #10) TEST H
10761
10762 ;* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)

```

```

10763 : * SET UP FOR A TEN WORD READ FROM AN EVEN WORD BOUNDARY
10764 : * DO A TEN WORD READ FROM AN EVEN WORD BOUNDARY
10765 : * THIS SHOULD SET RHCS3 BIT #10 DBL
10766 : * CHECK RHCS3
10767 : * CHECK RHCS1, RHCS2, RHBA, RHBAE, RHC
10768
10769 : *****
10770 032120 000004 TST47: SCOPE
10771 032122 012706 001000 MOV #STACK, SP ; RESET STACK
10772 032126 012737 000047 004656 MOV #47, @#TSTNM ; SAVE TEST NUMBER
10773
10774 032134 004737 040322 JSR PC, @#CLDISK ; GIVE RH INITIALIZE
10775 ; SETUP UNIT NUMBER
10776 ; CLEAR RHC AND FUNCTION BITS IN RHCS1
10777
10778 : SET UP FOR A TEN WORD READ FROM AN EVEN WORD BOUNDARY
10779 032140 012701 000003 MOV #3, R1 ; COUNT OF THREE
10780 032144 012702 003000 MOV #BFEVEN, R2 ; START THREE WORD BUFFER
10781 ; FROM AN EVEN WORD BOUNDARY
10782 032150 012722 052525 1$: MOV #52525, (R2)+ ; MOVE THREE 52525 INTO BUFFER
10783 032154 005301 DEC R1 ; COUNT
10784 032156 001374 BNE 1$; BRANCH IF THREE NOT DONE
10785 032160 012777 003000 151676 MOV #BFEVEN, @RHBA ; SET BUS ADDRESS TO START
10786 ; FROM AN EVEN WORD BOUNDARY
10787 032166 012777 177766 151666 MOV #-10, @RHWC ; WORD COUNT TEN
10788 032174 004077 152440 JSR RD, @COMND ; GO TO DO COMMAND
10789 032200 004160 READAT ; READ DATA
10790
10791
10792 : CHECK THAT RHCS3 HAS DBL
10793 032202 012737 002000 001124 MOV #DBL, $GDDAT ; GET GOOD = 2000
10794
10795 032210 017737 151716 001126 MOV @RHCS3, $BDDAT ; READ RHCS3 FOR COMPARISON
10796 032216 023737 001124 001126 CMP $GDDAT, $BDDAT ; COMPARE EXPECTED
10797 ; DATA WITH DATA READ FROM
10798 ; RHCS3
10799 032224 001401 BEQ 65$; BRANCH IF GOOD
10800 032226 104124
10801
10802 : AFTER SETTING "CLR" BIT #5
10803 : IN RHCS2 TO INIT THE RH
10804 : A TEN WORD READ FROM AN
10805 : EVEN WORD BOUNDARY WAS DONE
10806 : THEN
10807 : RHCS3 SHOULD HAVE DBL
10808 : =2000
10809 : BUT CONTAINED WHAT IS
10810 : GIVEN IN BAD RHCS3
10811 032230 042777 000076 151622 65$: BIC #76, @RHCS1 ; CLEAR FUNCTION BITS
10812 : CHECK THAT RHCS1 HAS RDY!DVA
10813 032236 012737 004200 001124 MOV #RDY!DVA, $GDDAT ; GET GOOD = 4200
10814
10815 032244 017737 151610 001126 MOV @RHCS1, $BDDAT ; READ RHCS1 FOR COMPARISON
10816 032252 023737 001124 001126 CMP $GDDAT, $BDDAT ; COMPARE EXPECTED
10817 ; DATA WITH DATA READ FROM
10818 ; RHCS1

```

```

10819 032260 001401 BEQ 67$;BRANCH IF GOOD
10820 032262 104125 ERROR 125
10821 ;AFTER SETTING "CLR" BIT #5
10822 ;IN RHCS2 TO INIT THE RH
10823 ;A TEN WORD READ FROM AN
10824 ;EVEN WORD BOUNDARY WAS DONE
10825 ;THEN
10826 ;RHCS1 SHOULD HAVE RDY!DVA
10827 ;=4200
10828 ;BUT CONTAINED WHAT IS
10829 ;GIVEN IN BAD RHCS1
10830 032264 67$:
10831 ;CHECK THAT RHCS2 HAS IR
10832 032264 012737 000100 001124 MOV #IR,$GDDAT ;GET GOOD = 100
10833 032272 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
10834
10835 032300 017737 151564 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
10836 032306 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
10837 ;DATA WITH DATA READ FROM
10838 ;RHCS2
10839 032314 001401 BEQ 69$;BRANCH IF GOOD
10840 032316 104126 ERROR 126
10841 ;AFTER SETTING "CLR" BIT #5
10842 ;IN RHCS2 TO INIT THE RH
10843 ;A TEN WORD READ FROM AN
10844 ;EVEN WORD BOUNDARY WAS DONE
10845 ;THEN
10846 ;RHCS2 SHOULD HAVE IR
10847 ;=100
10848 ;TOGETHER WITH UNIT NUMBER
10849 ;BUT CONTAINED WHAT IS
10850 ;GIVEN IN BAD RHCS2
10851 032320 69$:
10852 ;CHECK THAT RHWC HAS 0
10853 032320 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
10854
10855 032326 017737 151530 001126 MOV @RHWC,$BDDAT ;READ RHWC FOR COMPARISON
10856 032334 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
10857 ;DATA WITH DATA READ FROM
10858 ;RHWC
10859 032342 001401 BEQ 71$;BRANCH IF GOOD
10860 032344 104131 ERROR 131
10861 ;AFTER SETTING "CLR" BIT #5
10862 ;IN RHCS2 TO INIT THE RH
10863 ;A TEN WORD READ FROM AN
10864 ;EVEN WORD BOUNDARY WAS DONE
10865 ;THEN
10866 ;RHWC SHOULD HAVE 0
10867 ;BUT CONTAINED WHAT IS
10868 ;GIVEN IN BAD RHWC
10869 032346 71$:
10870
10871
10872
10873
10874

```

```

;*****
;*TEST 50 TEST DBL (RHCS3 BIT #10) TEST I

```

```

10875
10876
10877
10878
10879
10880
10881
10882
10883
10884 032346 000004
10885 032350 012706 001000
10886 032354 012737 000050 004656
10887
10888 032362 004737 040322
10889
10890
10891
10892
10893 032366 012701 000003
10894 032372 012702 003002
10895
10896 032376 012722 052525
10897 032402 005301
10898 032404 001374
10899 032406 012777 003002 151450
10900
10901 032414 012777 177766 151440
10902 032422 004077 152212
10903 032426 004160
10904
10905
10906
10907 032430 012737 000000 001124
10908
10909 032436 017737 151470 001126
10910 032444 023737 001124 001126
10911
10912
10913 032452 001401
10914 032454 104124
10915
10916
10917
10918
10919
10920
10921
10922
10923 032456
10924 032456 042777 000076 151374
10925
10926 032464 012737 004200 001124
10927
10928 032472 017737 151362 001126
10929 032500 023737 001124 001126
10930

; * CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
; * SET UP FOR A TEN WORD READ FROM AN ODD WORD BOUNDARY
; * DO A TEN WORD READ FROM AN ODD WORD BOUNDARY
; * THIS SHOULD NOT SET RHCS3 BIT #10 DBL
; * CHECK RHCS3
; * CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC

; *****
TST50: SCOPE
MOV #STACK, SP ; RESET STACK
MOV #50, @#TSTNM ; SAVE TEST NUMBER
JSR PC, @#CLDISK ; GIVE RH INITIALIZE
; SETUP UNIT NUMBER
; CLEAR RHWC AND FUNCTION BITS IN RHCS1

; SET UP FOR A TEN WORD READ FROM AN ODD WORD BOUNDARY
MOV #3, R1 ; COUNT OF THREE
MOV #BF0DD, R2 ; START THREE WORD BUFFER
; FROM AN ODD WORD BOUNDARY
1$: MOV #52525, (R2)+ ; MOVE THREE 52525 INTO BUFFER
DEC R1 ; COUNT
BNE 1$; BRANCH IF THREE NOT DONE
MOV #BF0DD, @RHBA ; SET BUS ADDRESS TO START
; FROM AN ODD WORD BOUNDARY
MOV #-10, @RHWC ; WORD COUNT TEN
JSR RD, @COMND ; GO TO DO COMMAND
READAT ; READ DATA

; CHECK THAT RHCS3 HAS 0
MOV #0, $GDDAT ; GET GOOD = 0
MOV @RHCS3, $BDDAT ; READ RHCS3 FOR COMPARISON
CMP $GDDAT, $BDDAT ; COMPARE EXPECTED
; DATA WITH DATA READ FROM
; RHCS3
BEQ 65$; BRANCH IF GOOD
ERROR 124

; AFTER SETTING "CLR" BIT #5
; IN RHCS2 TO INIT THE RH
; A TEN WORD READ FROM AN
; ODD WORD BOUNDARY WAS DONE
; THEN
; RHCS3 SHOULD HAVE 0
; BUT CONTAINED WHAT IS
; GIVEN IN BAD RHCS3
65$: BIC #76, @RHCS1 ; CLEAR FUNCTION BITS
; CHECK THAT RHCS1 HAS RDY!DVA
MOV #RDY!DVA, $GDDAT ; GET GOOD = 4200
MOV @RHCS1, $BDDAT ; READ RHCS1 FOR COMPARISON
CMP $GDDAT, $BDDAT ; COMPARE EXPECTED
; DATA WITH DATA READ FROM

```

```

10931 ;RHCS1
10932 032506 001401 BEQ 67$;BRANCH IF GOOD
10933 032510 104125 ERROR 125
10934 ;AFTER SETTING "CLR" BIT #5
10935 ;IN RHCS2 TO INIT THE RH
10936 ;A TEN WORD READ FROM AN
10937 ;ODD WORD BOUNDARY WAS DONE
10938 ;THEN
10939 ;RHCS1 SHOULD HAVE RDY!DVA
10940 ;=4200
10941 ;BUT CONTAINED WHAT IS
10942 ;GIVEN IN BAD RHCS1
10943 032512 67$:
10944 ;CHECK THAT RHCS2 HAS IR
10945 032512 012737 000100 001124 MOV #IR,$GDDAT ;GET GOOD = 100
10946 032520 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
10947
10948 032526 017737 151336 001126 MOV RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
10949 032534 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
10950 ;DATA WITH DATA READ FROM
10951 ;RHCS2
10952 032542 001401 BEQ 69$;BRANCH IF GOOD
10953 032544 104126 ERROR 126
10954 ;AFTER SETTING "CLR" BIT #5
10955 ;IN RHCS2 TO INIT THE RH
10956 ;A TEN WORD READ FROM AN
10957 ;ODD WORD BOUNDARY WAS DONE
10958 ;THEN
10959 ;RHCS2 SHOULD HAVE IR
10960 ;=100
10961 ;TOGETHER WITH UNIT NUMBER
10962 ;BUT CONTAINED WHAT IS
10963 ;GIVEN IN BAD RHCS2
10964 032546 69$:
10965 ;CHECK THAT RHWC HAS 0
10966 032546 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
10967
10968 032554 017737 151302 001126 MOV RHWC,$BDDAT ;READ RHWC FOR COMPARISON
10969 032562 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
10970 ;DATA WITH DATA READ FROM
10971 ;RHWC
10972 032570 001401 BEQ 71$;BRANCH IF GOOD
10973 032572 104131 ERROR 131
10974 ;AFTER SETTING "CLR" BIT #5
10975 ;IN RHCS2 TO INIT THE RH
10976 ;A TEN WORD READ FROM AN
10977 ;ODD WORD BOUNDARY WAS DONE
10978 ;THEN
10979 ;RHWC SHOULD HAVE 0
10980 ;BUT CONTAINED WHAT IS
10981 ;GIVEN IN BAD RHWC
10982 032574 71$:
10983
10984
10985
10986

```

\*\*\*\*\*

```

10987 ;*TEST 51 TEST DBL (RHCS3 BIT #10) TEST J
10988
10989
10990
10991
10992
10993
10994
10995
10996
10997 032574 000004
10998 032576 012706 001000
10999 032602 012737 000051 004656
11000
11001 032610 004737 048322
11002
11003
11004
11005
11006 032614 012701 000003
11007 032620 012702 003000
11008
11009 032624 012722 052525
11010 032630 005301
11011 032632 001374
11012 032634 012777 003000 151222
11013
11014 032642 012777 177765 151212
11015 032650 004077 151764
11016 032654 004160
11017
11018
11019
11020 032656 012737 000000 001124
11021
11022 032664 017737 151242 001126
11023 032672 023737 001124 001126
11024
11025
11026 032700 001401
11027 032702 104124
11028
11029
11030
11031
11032
11033
11034
11035
11036 032704
11037 032704 042777 000076 151146
11038
11039 032712 012737 004200 001124
11040
11041 032720 017737 151134 001126
11042 032726 023737 001124 001126

```

```

;*****
†ST51: SCOPE
MOV #STACK,SP ;RESET STACK
MOV #51,2#†STNM ;SAVE TEST NUMBER
JSR PC,2#CLDISK ;GIVE RH INITIALIZE
;SETUP UNIT NUBER
;CLEAR RHWC AND FUNCTION BITS IN RHCS1
;SET UP FOR A ELEVEN WORD READ FROM AN EVEN WORD BOUNDARY
MOV #3,R1 ;COUNT OF THREE
MOV #BFEBVEN,R2 ;START THREE WORD BUFFER
;FROM AN EVEN WORD BOUNDARY
1$: MOV #52525,(R2)+ ;MOVE THREE 52525 INTO BUFFER
DEC R1 ;COUNT
BNE 1$;BRANCH IF THREE NOT DONE
MOV #-11,2#RHWC ;WORD COUNT ELEVEN
JSR R0,2#COMND ;GO TO DO COMMAND
READAT ;READ DATA
;CHECK THAT RHCS3 HAS 0
MOV #0,$GDDAT ;GET GOOD = 0
MOV 2#RHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
;DATA WITH DATA READ FROM
;RHCS3
;BRANCH IF GOOD
BEQ 65$
ERROR 124
;AFTER SETTING "CLR" BIT #5
;IN RHCS2 TO INIT THE RH
;A ELEVEN WORD READ FROM AN
;EVEN WORD BOUNDARY WAS DONE
;THEN
;RHCS3 SHOULD HAVE 0
;BUT CONTAINED WHAT IS
;GIVEN IN BAD RHCS3
65$: BIC #76,2#RHCS1 ;CLEAR FUNCTION BITS
;CHECK THAT RHCS1 HAS RDY!DVA
MOV #RDY!DVA,$GDDAT ;GET GOOD = 4200
MOV 2#RHCS1,$BDDAT ;READ RHCS1 FOR COMPARISON
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED

```





11099  
11100  
11101  
11102  
11103  
11104  
11105  
11106  
11107  
11108  
11109  
11110  
11111  
11112  
11113  
11114  
11115  
11116  
11117  
11118  
11119  
11120  
11121  
11122  
11123  
11124  
11125  
11126  
11127  
11128  
11129  
11130  
11131  
11132  
11133  
11134  
11135  
11136  
11137  
11138  
11139  
11140  
11141  
11142  
11143  
11144  
11145  
11146  
11147  
11148  
11149  
11150  
11151  
11152  
11153  
11154

033000 000004  
033024 012706 001000  
033030 012737 000052 004656  
033036 004737 040322  
033042 012701 000003  
033046 012702 003002  
033052 012722 052525  
033056 005301  
033060 001374  
033062 012777 003002 150774  
033070 012777 177765 150764  
033076 004077 151536  
033102 004160  
033104 012737 002000 001124  
033112 017737 151014 001126  
033120 023737 001124 001126  
033126 001401  
033130 104124  
033132 000076 150720  
033140 012737 004200 001124

```

*TEST 52 TEST DBL (RHCS3 BIT #10) TEST K

* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
* SET UP FOR A ELEVEN WORD READ FROM AN ODD WORD BOUNDARY
* DO A ELEVEN WORD READ FROM AN ODD WORD BOUNDARY
* THIS SHOULD SET RHCS3 BIT #10 DBL
* CHECK RHCS3
* CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC

T52: SCOPE
MOV #STACK, SP ;RESET STACK
MOV #52, 2#TSTNM ;SAVE TEST NUMBER
JSR PC, 2#CLDISK ;GIVE RH INITIALIZE
;SETUP UNIT NUBER
;CLEAR RHWC AND FUNCTION BITS IN RHCS1

;SET UP FOR A ELEVEN WORD READ FROM AN ODD WORD BOUNDARY
MOV #3, R1 ;COUNT OF THREE
MOV #BFODD, R2 ;START THREE WORD BUFFER
;FROM AN ODD WORD BOUNDARY
1$: MOV #52525, (R2)+ ;MOVE THREE 52525 INTO BUFFER
DEC R1 ;COUNT
BNE 1$;BRANCH IF THREE NOT DONE
MOV #BFODD, 2#RHBA ;SET BUS ADDRESS TO START
;FROM AN ODD WORD BOUNDARY
MOV #-11, 2#RHWC ;WORD COUNT ELEVEN
JSR R0, 2#COMND ;GO TO DO COMMAND
READAT ;READ DATA

;CHECK THAT RHCS3 HAS DBL
MOV #DBL, $GDDAT ;GET GOOD = 2000
MOV 2#RHCS3, $BDDAT ;READ RHCS3 FOR COMPARISON
CMP $GDDAT, $BDDAT ;COMPARE EXPECTED
;DATA WITH DATA READ FROM
;RHCS3
BEQ 65$;BRANCH IF GOOD
ERROR 124

;AFTER SETTING "CLR" BIT #5
;IN RHCS2 TO INIT THE RH
;A ELEVEN WORD READ FROM AN
;ODD WORD BOUNDARY WAS DONE
;THEN
;RHCS3 SHOULD HAVE DBL
;=2000
;BUT CONTAINED WHAT IS
;GIVEN IN BAD RHCS3
65$: BIC #76, 2#RHCS1 ;CLEAR FUNCTION BITS
;CHECK THAT RHCS1 HAS RDY!DVA
MOV #RDY!DVA, $GDDAT ;GET GOOD = 4200
```

```

11155 033146 017737 150706 001126 MOV @RHCS1,$BDDAT ;READ RHCS1 FOR COMPARISON
11156 033154 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
11157 ;DATA WITH DATA READ FROM
11158 ;RHCS1
11159 033162 001401 BEQ 67$;BRANCH IF GOOD
11160 033164 104125 ERROR 125
11161 ;AFTER SETTING "CLR" BIT #5
11162 ;IN RHCS2 TO INIT THE RH
11163 ;A ELEVEN WORD READ FROM AN
11164 ;ODD WORD BOUNDARY WAS DONE
11165 ;THEN
11166 ;RHCS1 SHOULD HAVE RDY!DVA
11167 ;=4200
11168 ;BUT CONTAINED WHAT IS
11169 ;GIVEN IN BAD RHCS1
11170 033166 67$:
11171 ;CHECK THAT RHCS2 HAS IR
11172 033166 012737 000100 001124 MOV #IR,$GDDAT ;GET GOOD = 100
11173 033174 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
11174
11175 033202 017737 150662 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
11176 033210 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
11177 ;DATA WITH DATA READ FROM
11178 ;RHCS2
11179 033216 001401 BEQ 69$;BRANCH IF GOOD
11180 033220 104126 ERROR 126
11181 ;AFTER SETTING "CLR" BIT #5
11182 ;IN RHCS2 TO INIT THE RH
11183 ;A ELEVEN WORD READ FROM AN
11184 ;ODD WORD BOUNDARY WAS DONE
11185 ;THEN
11186 ;RHCS2 SHOULD HAVE IR
11187 ;=100
11188 ;TOGETHER WITH UNIT NUMBER
11189 ;BUT CONTAINED WHAT IS
11190 ;GIVEN IN BAD RHCS2
11191 033222 69$:
11192 ;CHECK THAT RHWC HAS 0
11193 033222 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
11194
11195 033230 017737 150626 001126 MOV @RHWC,$BDDAT ;READ RHWC FOR COMPARISON
11196 033236 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
11197 ;DATA WITH DATA READ FROM
11198 ;RHWC
11199 033244 001401 BEQ 71$;BRANCH IF GOOD
11200 033246 104131 ERROR 131
11201 ;AFTER SETTING "CLR" BIT #5
11202 ;IN RHCS2 TO INIT THE RH
11203 ;A ELEVEN WORD READ FROM AN
11204 ;ODD WORD BOUNDARY WAS DONE
11205 ;THEN
11206 ;RHWC SHOULD HAVE 0
11207 ;BUT CONTAINED WHAT IS
11208 ;GIVEN IN BAD RHWC
11209 033250 71$:
11210

```

11211  
11212  
11213  
11214  
11215  
11216  
11217  
11218  
11219  
11220  
11221  
11222  
11223  
11224  
11225  
11226  
11227  
11228  
11229  
11230  
11231  
11232  
11233  
11234  
11235  
11236  
11237  
11238  
11239  
11240  
11241  
11242  
11243  
11244  
11245  
11246  
11247  
11248  
11249  
11250  
11251  
11252  
11253  
11254  
11255  
11256  
11257  
11258  
11259  
11260  
11261  
11262  
11263  
11264  
11265  
11266

033250 000004  
033252 012706 001000  
033256 012737 000053 004656  
033264 004737 040322  
033270 012701 000003  
033274 012702 003000  
033300 012722 052525  
033304 005301  
033306 001374  
033310 012777 003000 150546  
033316 012777 177766 150536  
033324 052777 000010 150536  
033332 004077 151302  
033336 004160  
033340 012737 000000 001124  
033346 017737 150560 001126  
033354 023737 001124 001126  
033362 001401  
033364 104124  
033366

```

; *TEST 53 TEST DBL (RHCS3 BIT #10) TEST L
; * CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
; * SET UP FOR A TEN WORD READ FROM AN EVEN WORD BOUNDARY
; * WITH BAI IN RHCS2 BIT #3 SET
; * DO A TEN WORD READ FROM AN EVEN WORD BOUNDARY
; * THIS SHOULD NOT SET RHCS3 BIT #10 DBL
; * CHECK RHCS3
; * CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC

TST53: SCOPE
MOV #STACK, SP ;RESET STACK
MOV #53, #TSTNM ;SAVE TEST NUMBER
JSR PC, #CLDISK ;GIVE RH INITIALIZE
;SETUP UNIT NUBER
;CLEAR RHWC AND FUNCTION BITS IN RHCS1
;SET UP FOR A TEN WORD READ FROM AN EVEN WORD BOUNDARY
MOV #3, R1 ;COUNT OF THREE
MOV #BFEVEN, R2 ;START THREE WORD BUFFER
;FROM AN EVEN WORD BOUNDARY
1$: MOV #52525, (R2)+ ;MOVE THREE 52525 INTO BUFFER
DEC R1 ;COUNT
BNE 1$;BRANCH IF THREE NOT DONE
MOV #BFEVEN, #RHBA ;SET BUS ADDRESS TO START
;FROM AN EVEN WORD BOUNDARY
MOV #-10, #RHWC ;WORD COUNT TEN
BIS #BAI, #RHCS2 ;SET BAI IN RHCS2
JSR #0, #COMND ;GO TO DO COMMAND
READAT ;READ DATA
;CHECK THAT RHCS3 HAS 0
MOV #0, #GDDAT ;GET GOOD = 0
MOV #RHCS3, #BDDAT ;READ RHCS3 FOR COMPARISON
CMP #GDDAT, #BDDAT ;COMPARE EXPECTED
;DATA WITH DATA READ FROM
;RHCS3
BEQ 65$;BRANCH IF GOOD
ERROR 124
;AFTER SETTING "CLR" BIT #5
;IN RHCS2 TO INIT THE RH
;A TEN WORD READ FROM AN
;EVEN WORD BOUNDARY WAS DONE
;WITH BAI IN RHCS2 SET
;THEN
;RHCS3 SHOULD HAVE 0
;BUT CONTAINED WHAT IS
;GIVEN IN BAD RHCS3
65$:
```



;WITH BAI IN RHCS2 SET  
;THEN  
;RHW C SHOULD HAVE 0  
;BUT CONTAINED WHAT IS  
;GIVEN IN BAD RHW C

11323  
11324  
11325  
11326  
11327  
11328  
11329  
11330  
11331  
11332  
11333  
11334  
11335  
11336  
11337  
11338  
11339  
11340  
11341  
11342  
11343  
11344  
11345  
11346  
11347  
11348  
11349  
11350  
11351  
11352  
11353  
11354  
11355  
11356  
11357  
11358  
11359  
11360  
11361  
11362  
11363  
11364  
11365  
11366  
11367  
11368  
11369  
11370  
11371  
11372  
11373  
11374  
11375  
11376  
11377  
11378

033504

71\$:

::\*\*\*\*\*  
;\*TEST 54 TEST DBL (RHCS3 BIT #10) TEST M

::\* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)  
:\* SET UP FOR A ONE WORD WRITE REVERSE FROM AN EVEN WORD BOUNDARY  
:\* DO A ONE WORD WRITE REVERSE FROM AN EVEN WORD BOUNDARY  
:\* THIS SHOULD NOT SET RHCS3 BIT #10 DBL  
:\* CHECK RHCS3  
:\* CHECK RHCS1, RHCS2, RHBA, RHBAE, RHW C

::\*\*\*\*\*  
†T54:

033504 000004  
033506 012706 001000  
033512 012737 000054 004656  
033520 004737 040322  
033524 012701 000003  
033530 012702 003000  
033534 012722 052525  
033540 005301  
033542 001374  
033544 012777 003000 150312  
033552 012777 177777 150302  
033560 004077 151054  
033564 004204

SCOPE  
MOV #STACK, SP ;RESET STACK  
MOV #54, @†TSTNM ;SAVE TEST NUMBER  
JSR PC, @#CLDISK ;GIVE RH INITIALIZE  
;SETUP UNIT NUBER  
;CLEAR RHW C AND FUNCTION BITS IN RHCS1  
;SET UP FOR A ONE WORD WRITE REVERSE FROM AN EVEN WORD BOUNDARY  
MOV #3, R1 ;COUNT OF THREE  
MOV #BFEVEN, R2 ;START THREE WORD BUFFER  
;FROM AN EVEN WORD BOUNDARY  
1\$: MOV #52525, (R2)+ ;MOVE THREE 52525 INTO BUFFER  
DEC R1 ;COUNT  
BNE 1\$ ;BRANCH IF THREE NOT DONE  
MOV #BFEVEN, @RHBA ;SET BUS ADDRESS TO START  
;FROM AN EVEN WORD BOUNDARY  
MOV #-1, @RHW C ;WORD COUNT ONE  
JSR RO, @COMND ;GO TO DO COMMAND  
REVWRT ;REVERSEWRITE DATA  
;CHECK THAT RHCS3 HAS 0  
MOV #0, \$GDDAT ;GET GOOD = 0  
MOV @RHCS3, \$BDDAT ;READ RHCS3 FOR COMPARISON  
CMP \$GDDAT, \$BDDAT ;COMPARE EXPECTED  
;DATA WITH DATA READ FROM  
;RHCS3  
BEQ 65\$ ;BRANCH IF GOOD  
ERROR 124

;AFTER SETTING "CLR" BIT #5  
;IN RHCS2 TO INIT THE RH  
;A ONE WORD WRITE REVERSE FROM AN  
;EVEN WORD BOUNDARY WAS DONE



; IN RHCS2 TO INIT THE RH  
; A ONE WORD WRITE REVERSE FROM AN  
; EVEN WORD BOUNDARY WAS DONE  
; THEN  
; RHCW SHOULD HAVE 0  
; BUT CONTAINED WHAT IS  
; GIVEN IN BAD RHCW

11435  
11436  
11437  
11438  
11439  
11440  
11441  
11442 033732 71\$:  
11443  
11444  
11445

::\*\*\*\*\*  
:\*TEST 55 TEST DBL (RHCS3 BIT #10) TEST N

11448  
11449  
11450  
11451  
11452  
11453  
11454  
11455  
11456  
11457 033732 000004  
11458 033734 012706 001000  
11459 033740 012737 000055 004656  
11460  
11461 033746 004737 040322  
11462  
11463  
11464  
11465  
11466 033752 012701 000003  
11467 033756 012702 003000  
11468  
11469 033762 012722 052525 1\$:  
11470 033766 005301  
11471 033770 001374  
11472 033772 012777 003000 150064  
11473  
11474 034000 012777 177776 150054  
11475 034006 004077 150626  
11476 034012 004204  
11477  
11478  
11479  
11480 034014 012737 000000 001124  
11481  
11482 034022 017737 150104 001126  
11483 034030 023737 001124 001126  
11484  
11485  
11486 034036 001401  
11487 034040 104124  
11488  
11489  
11490

;\* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)  
;\* SET UP FOR A TWO WORD WRITE REVERSE FROM AN EVEN WORD BOUNDARY  
;\* DO A TWO WORD WRITE REVERSE FROM AN EVEN WORD BOUNDARY  
;\* THIS SHOULD NOT SET RHCS3 BIT #10 DBL  
;\* CHECK RHCS3  
;\* CHECK RHCS1, RHCS2, RHBA, RHBAE, RHCW

::\*\*\*\*\*

TST55: SCOPE  
MOV #STACK, SP ; RESET STACK  
MOV #55, @TSTNM ; SAVE TEST NUMBER  
JSR PC, @CLDISK ; GIVE RH INITIALIZE  
; SETUP UNIT NUMBER  
; CLEAR RHCW AND FUNCTION BITS IN RHCS1  
; SET UP FOR A TWO WORD WRITE REVERSE FROM AN EVEN WORD BOUNDARY  
MOV #3, R1 ; COUNT OF THREE  
MOV #BFEVEN, R2 ; START THREE WORD BUFFER  
; FROM AN EVEN WORD BOUNDARY  
MOV #52525, (R2)+ ; MOVE THREE 52525 INTO BUFFER  
DEC R1 ; COUNT  
BNE 1\$ ; BRANCH IF THREE NOT DONE  
MOV #BFEVEN, @RHBA ; SET BUS ADDRESS TO START  
; FROM AN EVEN WORD BOUNDARY  
MOV #-2, @RHCW ; WORD COUNT TWO  
JSR RO, @COMND ; GO TO DO COMMAND  
REVWRT ; REVERSEWRITE DATA

; CHECK THAT RHCS3 HAS 0  
MOV #0, \$GDDAT ; GET GOOD = 0  
MOV @RHCS3, \$BDDAT ; READ RHCS3 FOR COMPARISON  
CMP \$GDDAT, \$BDDAT ; COMPARE EXPECTED  
; DATA WITH DATA READ FROM  
; RHCS3  
BEQ 65\$ ; BRANCH IF GOOD  
ERROR 124

; AFTER SETTING "CLR" BIT #5  
; IN RHCS2 TO INIT THE RH  
; A TWO WORD WRITE REVERSE FROM AN

```

11491 ;EVEN WORD BOUNDARY WAS DONE
11492 ;THEN
11493 ;RHCS3 SHOULD HAVE 0
11494 ;BUT CONTAINED WHAT IS
11495 ;GIVEN IN BAD RHCS3
11496 034042 65$: BIC #76, @RHCS1 ;CLEAR FUNCTION BITS
11497 034042 042777 000076 150010 ;CHECK THAT RHCS1 HAS SC!RDY!DVA
11498 ;RDY!DVA
11499 034050 012737 104200 001124 MOV #SC!RDY!DVA, $GDDAT ;GET GOOD = 104200
11500
11501 034056 017737 147776 001126 MOV @RHCS1, $BDDAT ;READ RHCS1 FOR COMPARISON
11502 034064 023737 001124 001126 CMP $GDDAT, $BDDAT ;COMPARE EXPECTED
11503 ;DATA WITH DATA READ FROM
11504 ;RHCS1
11505 034072 001401 BEQ 67$;BRANCH IF GOOD
11506 034074 104125 ERROR 125
11507 ;AFTER SETTING "CLR" BIT #5
11508 ;IN RHCS2 TO INIT THE RH
11509 ;A TWO WORD WRITE REVERSE FROM AN
11510 ;EVEN WORD BOUNDARY WAS DONE
11511 ;THEN
11512 ;RHCS1 SHOULD HAVE SC!RDY!DVA
11513 ;=104200
11514 ;BUT CONTAINED WHAT IS
11515 ;GIVEN IN BAD RHCS1
11516 034076 67$: ;CHECK THAT RHCS2 HAS IR!OR
11517 ;IR!OR
11518 034076 012737 000300 001124 MOV #IR!OR, $GDDAT ;GET GOOD = 300
11519 034104 053737 005010 001124 BIS UNIT, $GDDAT ;INCLUDE UNIT NUMBER
11520
11521 034112 017737 147752 001126 MOV @RHCS2, $BDDAT ;READ RHCS2 FOR COMPARISON
11522 034120 023737 001124 001126 CMP $GDDAT, $BDDAT ;COMPARE EXPECTED
11523 ;DATA WITH DATA READ FROM
11524 ;RHCS2
11525 034126 001401 BEQ 69$;BRANCH IF GOOD
11526 034130 104126 ERROR 126
11527 ;AFTER SETTING "CLR" BIT #5
11528 ;IN RHCS2 TO INIT THE RH
11529 ;A TWO WORD WRITE REVERSE FROM AN
11530 ;EVEN WORD BOUNDARY WAS DONE
11531 ;THEN
11532 ;RHCS2 SHOULD HAVE IR!OR
11533 ;=300
11534 ;TOGETHER WITH UNIT NUMBER
11535 ;BUT CONTAINED WHAT IS
11536 ;GIVEN IN BAD RHCS2
11537 034132 69$: ;CHECK THAT RHWC HAS 0
11538 ;0, $GDDAT
11539 034132 012737 000000 001124 MOV #0, $GDDAT ;GET GOOD = 0
11540
11541 034140 017737 147716 001126 MOV @RHWC, $BDDAT ;READ RHWC FOR COMPARISON
11542 034146 023737 001124 001126 CMP $GDDAT, $BDDAT ;COMPARE EXPECTED
11543 ;DATA WITH DATA READ FROM
11544 ;RHWC
11545 034154 001401 BEQ 71$;BRANCH IF GOOD
11546 034156 104131 ERROR 131

```



; AFTER SETTING "CLR" BIT #5  
; IN RHCS2 TO INIT THE RH  
; A TWO WORD WRITE REVERSE FROM AN  
; EVEN WORD BOUNDARY WAS DONE  
; THEN  
; RHWC SHOULD HAVE 0  
; BUT CONTAINED WHAT IS  
; GIVEN IN BAD RHWC

11547  
11548  
11549  
11550  
11551  
11552  
11553  
11554  
11555  
11556  
11557  
11558  
11559  
11560  
11561  
11562  
11563  
11564  
11565  
11566  
11567  
11568  
11569  
11570  
11571  
11572  
11573  
11574  
11575  
11576  
11577  
11578  
11579  
11580  
11581  
11582  
11583  
11584  
11585  
11586  
11587  
11588  
11589  
11590  
11591  
11592  
11593  
11594  
11595  
11596  
11597  
11598  
11599  
11600  
11601  
11602

034160

71\$:

\*\*\*\*\*  
\*TEST 56 TEST DBL (RHCS3 BIT #10) TEST 0

\* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)  
\* SET UP FOR A TWO WORD WRITE REVERSE FROM AN ODD WORD BOUNDARY  
\* DO A TWO WORD WRITE REVERSE FROM AN ODD WORD BOUNDARY  
\* THIS SHOULD SET RHCS3 BIT #10 DBL  
\* CHECK RHCS3  
\* CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC

\*\*\*\*\*  
TST56: SCOPE

034160 000004  
034162 012706 001000  
034166 012777 000056 004656

MOV #STACK, SP ; RESET STACK  
MOV #56, @#1STNM ; SAVE TEST NUMBER

034174 004737 040322

JSR PC, @#CLDISK ; GIVE RH INITIALIZE  
; SETUP UNIT NUBER  
; CLEAR RHWC AND FUNCTION BITS IN RHCS1

034200 012701 000003  
034204 012702 003002

; SET UP FOR A TWO WORD WRITE REVERSE FROM AN ODD WORD BOUNDARY  
MOV #3, R1 ; COUNT OF THREE  
MOV #BFODD, R2 ; START THREE WORD BUFFER

034210 012722 052525  
034214 005301  
034216 001374  
034220 012777 003002 147636

1\$: MOV #52525, (R2)+ ; MOVE THREE 52525 INTO BUFFER  
DEC R1 ; COUNT  
BNE 1\$ ; BRANCH IF THREE NOT DONE  
MOV #BFODD, @RHBA ; SET BUS ADDRESS TO START

034226 012777 177776 147626  
034234 004077 150400  
034240 004204

MOV #-2, @RHWC ; WORD COUNT TWO  
JSR RO, @COMND ; GO TO DO COMMAND  
REVWRT ; REVERSEWRITE DATA

034242 012737 002000 001124

; CHECK THAT RHCS3 HAS DBL  
MOV #DBL, \$GDDAT ; GET GOOD = 2000

034250 017737 147656 001126  
034256 023737 001124 001126

MOV @RHCS3, \$BDDAT ; READ RHCS3 FOR COMPARISON  
CMP \$GDDAT, \$BDDAT ; COMPARE EXPECTED  
; DATA WITH DATA READ FROM  
; RHCS3

034264 001401  
034266 104124

BEQ 65\$ ; BRANCH IF GOOD  
ERROR 124

; AFTER SETTING "CLR" BIT #5  
; IN RHCS2 TO INIT THE RH

```

11603 ;A TWO WORD WRITE REVERSE FROM AN
11604 ;ODD WORD BOUNDARY WAS DONE
11605 ;THEN
11606 ;RHCS3 SHOULD HAVE DBL
11607 ;=2000
11608 ;BUT CONTAINED WHAT IS
11609 ;GIVEN IN BAD RHCS3
11610 034270 65$:
11611 034270 042777 000076 147562 BIC #76, @RHCS1 ;CLEAR FUNCTION BITS
11612 ;CHECK THAT RHCS1 HAS SC!RDY!DVA
11613 034276 012737 104200 001124 MOV #SC!RDY!DVA, $GDDAT ;GET GOOD = 104200
11614
11615 034304 017737 147550 001126 MOV @RHCS1, $BDDAT ;READ RHCS1 FOR COMPARISON
11616 034312 023737 001124 001126 CMP $GDDAT, $BDDAT ;COMPARE EXPECTED
11617 ;DATA WITH DATA READ FROM
11618 ;RHCS1
11619 034320 001401 BEQ 67$;BRANCH IF GOOD
11620 034322 104125 ERROR 125
11621
11622 ;AFTER SETTING "CLR" BIT #5
11623 ;IN RHCS2 TO INIT THE RH
11624 ;A TWO WORD WRITE REVERSE FROM AN
11625 ;ODD WORD BOUNDARY WAS DONE
11626 ;THEN
11627 ;RHCS1 SHOULD HAVE SC!RDY!DVA
11628 ;=104200
11629 ;BUT CONTAINED WHAT IS
11630 ;GIVEN IN BAD RHCS1
11630 034324 67$:
11631 ;CHECK THAT RHCS2 HAS IR!OR
11632 034324 012737 000300 001124 MOV #IR!OR, $GDDAT ;GET GOOD = 300
11633 034332 053737 005010 001124 BIS UNIT, $GDDAT ;INCLUDE UNIT NUMBER
11634
11635 034340 017737 147524 001126 MOV @RHCS2, $BDDAT ;READ RHCS2 FOR COMPARISON
11636 034346 023737 001124 001126 CMP $GDDAT, $BDDAT ;COMPARE EXPECTED
11637 ;DATA WITH DATA READ FROM
11638 ;RHCS2
11639 034354 001401 BEQ 69$;BRANCH IF GOOD
11640 034356 104126 ERROR 126
11641
11642 ;AFTER SETTING "CLR" BIT #5
11643 ;IN RHCS2 TO INIT THE RH
11644 ;A TWO WORD WRITE REVERSE FROM AN
11645 ;ODD WORD BOUNDARY WAS DONE
11646 ;THEN
11647 ;RHCS2 SHOULD HAVE IR!OR
11648 ;=300
11649 ;TOGETHER WITH UNIT NUMBER
11650 ;BUT CONTAINED WHAT IS
11651 ;GIVEN IN BAD RHCS2
11651 034360 69$:
11652 ;CHECK THAT RHWC HAS 0
11653 034360 012737 000000 001124 MOV #0, $GDDAT ;GET GOOD = 0
11654
11655 034366 017737 147470 001126 MOV @RHWC, $BDDAT ;READ RHWC FOR COMPARISON
11656 034374 023737 001124 001126 CMP $GDDAT, $BDDAT ;COMPARE EXPECTED
11657 ;DATA WITH DATA READ FROM
11658 ;RHWC

```

```

11659 034402 001401 BEQ 71$;BRANCH IF GOOD
11660 034404 104131 ERROR 131
11661 ;AFTER SETTING "CLR" BIT #5
11662 ;IN RHCS2 TO INIT THE RH
11663 ;A TWO WORD WRITE REVERSE FROM AN
11664 ;ODD WORD BOUNDARY WAS DONE
11665 ;THEN
11666 ;RHW C SHOULD HAVE 0
11667 ;BUT CONTAINED WHAT IS
11668 ;GIVEN IN BAD RHW C
11669 034406 71$:
11670
11671
11672
11673 ;*****
11674 ;*TEST 57 TEST DBL (RHCS3 BIT #10) TEST P
11675
11676 ;*
11677 ;* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
11678 ;* SET UP FOR A THREE WORD WRITE REVERSE FROM AN EVEN WORD BOUNDARY
11679 ;* DO A THREE WORD WRITE REVERSE FROM AN EVEN WORD BOUNDARY
11680 ;* THIS SHOULD SET RHCS3 BIT #10 DBL
11681 ;* CHECK RHCS3
11682 ;* CHECK RHCS1 ,RHCS2 ,RHBA ,RHBAE ,RHW C
11683 ;*****
11684 034406 000004 †ST57: SCOPE
11685 034410 012706 001000 MOV #STACK,SP ;RESET STACK
11686 034414 012737 000057 004656 MOV #57,#TSTNM ;SAVE TEST NUMBER
11687
11688 034422 004737 040322 JSR PC,#CLDISK ;GIVE RH INITIALIZE
11689 ;SETUP UNIT NUBER
11690 ;CLEAR RHW C AND FUNCTION BITS IN RHCS1
11691
11692 ;SET UP FOR A THREE WORD WRITE REVERSE FROM AN EVEN WORD BOUNDARY
11693 034426 012701 000003 MOV #3,R1 ;COUNT OF THREE
11694 034432 012702 003000 MOV #8FEVEN,R2 ;START THREE WORD BUFFER
11695 ;FROM AN EVEN WORD BOUNDARY
11696 034436 012722 052525 1$: MOV #52525,(R2)+ ;MOVE THREE 52525 INTO BUFFER
11697 034442 005301 DEC R1 ;COUNT
11698 034444 001374 BNE 1$;BRANCH IF THREE NOT DONE
11699 034446 012777 003000 147410 MOV #8FEVEN,#RHBA ;SET BUS ADDRESS TO START
11700 ;FROM AN EVEN WORD BOUNDARY
11701 034454 012777 177775 147400 MOV #-3,#RHW C ;WORD COUNT THREE
11702 034462 004077 150152 JSR R0,#COMND ;GO TO DO COMMAND
11703 034466 004204 REVWRT ;REVERSEWRITE DATA
11704
11705
11706 ;CHECK THAT RHCS3 HAS DBL
11707 034470 012737 002000 001124 MOV #DBL,#GDDAT ;GET GOOD = 2000
11708
11709 034476 017737 147430 001126 MOV #RHCS3,#SDDAT ;READ RHCS3 FOR COMPARISON
11710 034504 023737 001124 001126 CMP #GDDAT,#SDDAT ;COMPARE EXPECTED
11711 ;DATA WITH DATA READ FROM
11712 ;RHCS3
11713 034512 001401 BEQ 65$;BRANCH IF GOOD
11714 034514 104124 ERROR 124

```

```

11715 ;AFTER SETTING "CLR" BIT #5
11716 ;IN RHCS2 TO INIT THE RH
11717 ;A THREE WORD WRITE REVERSE FROM AN
11718 ;EVEN WORD BOUNDARY WAS DONE
11719 ;THEN
11720 ;RHCS3 SHOULD HAVE DBL
11721 ;=2000
11722 ;BUT CONTAINED WHAT IS
11723 ;GIVEN IN BAD RHCS3
11724 034516 65$: BIC #76,2RHCS1 ;CLEAR FUNCTION BITS
11725 034516 042777 000076 147334 ;CHECK THAT RHCS1 HAS SC:RDY:DVA
11726 MOV #SC:RDY:DVA,$GDDAT ;GET GOOD = 104200
11727 034524 012737 104200 001124
11728 MOV 2RHCS1,$BDDAT ;READ RHCS1 FOR COMPARISON
11729 034532 017737 147322 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
11730 034540 023737 001124 001126 ;DATA WITH DATA READ FROM
11731 ;RHCS1
11732 BEQ 67$, ;BRANCH IF GOOD
11733 034546 001401
11734 034550 104125
11735 ;AFTER SETTING "CLR" BIT #5
11736 ;IN RHCS2 TO INIT THE RH
11737 ;A THREE WORD WRITE REVERSE FROM AN
11738 ;EVEN WORD BOUNDARY WAS DONE
11739 ;THEN
11740 ;RHCS1 SHOULD HAVE SC:RDY:DVA
11741 ;=104200
11742 ;BUT CONTAINED WHAT IS
11743 ;GIVEN IN BAD RHCS1
11744 034552 67$: ;CHECK THAT RHCS2 WAS IR:OR
11745 MOV #IR:OR,$GDDAT ;GET GOOD = 300
11746 034552 012737 000300 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
11747 034560 053737 005010 001124
11748 MOV 2RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
11749 034566 017737 147276 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
11750 034574 023737 001124 001126 ;DATA WITH DATA READ FROM
11751 ;RHCS2
11752 BEQ 69$, ;BRANCH IF GOOD
11753 034602 001401
11754 034604 104126
11755 ;AFTER SETTING "CLR" BIT #5
11756 ;IN RHCS2 TO INIT THE RH
11757 ;A THREE WORD WRITE REVERSE FROM AN
11758 ;EVEN WORD BOUNDARY WAS DONE
11759 ;THEN
11760 ;RHCS2 SHOULD HAVE IR:OR
11761 ;=300
11762 ;TOGETHER WITH UNIT NUMBER
11763 ;BUT CONTAINED WHAT IS
11764 ;GIVEN IN BAD RHCS2
11765 034606 69$: ;CHECK THAT RHWC HAS 0
11766 MOV #0,$GDDAT ;GET GOOD = 0
11767 034606 012737 000000 001124
11768 MOV 2RHWC,$BDDAT ;READ RHWC FOR COMPARISON
11769 034614 017737 147242 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
11770 034622 023737 001124 001126

```

```

11771
11772
11773 034630 001401
11774 034632 104131
11775
11776
11777
11778
11779
11780
11781
11782
11783 034634
11784
11785
11786
11787
11788
11789
11790
11791
11792
11793
11794
11795
11796
11797
11798 034634 000004
11799 034636 012706 001000
11800 034642 012737 000060 004656
11801
11802 034650 004737 040322
11803
11804
11805
11806
11807 034654 012701 000003
11808 034660 012702 003002
11809
11810 034664 012722 052525
11811 034670 005301
11812 034672 001374
11813 034674 012777 003002 147162
11814
11815 034702 012777 177775 147152
11816 034710 004077 147724
11817 034714 004204
11818
11819
11820
11821 034716 012737 000000 001124
11822
11823 034724 017737 147202 001126
11824 034732 023737 001124 001126
11825
11826

```

```

;DATA WITH DATA READ FROM
;RHWC
;BRANCH IF GOOD

;AFTER SETTING "CLR" BIT #5
;IN RHCS2 TO INIT THE RH
;A THREE WORD WRITE REVERSE FROM AN
;EVEN WORD BOUNDARY WAS DONE
;THEN
;RHWC SHOULD HAVE 0
;BUT CONTAINED WHAT IS
;GIVEN IN BAD RHWC

71$:

;TEST 60 TEST DBL (RHCS3 BIT #10) TEST Q

;
; CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
; SET UP FOR A THREE WORD WRITE REVERSE FROM AN ODD WORD BOUNDARY
; DO A THREE WORD WRITE REVERSE FROM AN ODD WORD BOUNDARY
; THIS SHOULD NOT SET RHCS3 BIT #10 DBL
; CHECK RHCS3
; CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC

TST60: SCOPE
MOV #STACK, SP ;RESET STACK
MOV #60, #TSTNM ;SAVE TEST NUMBER
JSR PC, #CLDISK ;GIVE RH INITIALIZE
;SETUP UNIT NUBER
;CLEAR RHWC AND FUNCTION BITS IN RHCS1
;SET UP FOR A THREE WORD WRITE REVERSE FROM AN ODD WORD BOUNDARY
MOV #3, R1 ;COUNT OF THREE
MOV #BF0DD, R2 ;START THREE WORD BUFFER
;FROM AN ODD WORD BOUNDARY
1$: MOV #52525, (R2)+ ;MOVE THREE 52525 INTO BUFFER
DEC R1 ;COUNT
BNE 1$;BRANCH IF THREE NOT DONE
MOV #BF0DD, #RHBA ;SET BUS ADDRESS TO START
;FROM AN ODD WORD BOUNDARY
MOV #-3, #RHWC ;WORD COUNT THREE
JSR RD, #COMND ;GO TO DO COMMAND
REVWRT ;REVERSEWRITE DATA

;CHECK THAT RHCS3 HAS 0
MOV #0, #GDDAT ;GET GOOD = 0

MOV #RHCS3, #BDDAT ;READ RHCS3 FOR COMPARISON
CMP #GDDAT, #BDDAT ;COMPARE EXPECTED
;DATA WITH DATA READ FROM
;RHCS3

```

|       |        |        |        |        |         |                           |                                      |
|-------|--------|--------|--------|--------|---------|---------------------------|--------------------------------------|
| 11827 | 034740 | 001401 |        |        | BEQ     | 65\$                      | : BRANCH IF GOOD                     |
| 11828 | 034742 | 104124 |        |        | ERROR   | 124                       |                                      |
| 11829 |        |        |        |        |         |                           | : AFTER SETTING "CLR" BIT #5         |
| 11830 |        |        |        |        |         |                           | : IN RHCS2 TO INIT THE RH            |
| 11831 |        |        |        |        |         |                           | : A THREE WORD WRITE REVERSE FROM AN |
| 11832 |        |        |        |        |         |                           | : ODD WORD BOUNDARY WAS DONE         |
| 11833 |        |        |        |        |         |                           | : THEN                               |
| 11834 |        |        |        |        |         |                           | : RHCS3 SHOULD HAVE 0                |
| 11835 |        |        |        |        |         |                           | : BUT CONTAINED WHAT IS              |
| 11836 |        |        |        |        |         |                           | : GIVEN IN BAD RHCS3                 |
| 11837 | 034744 |        |        |        | 65\$:   |                           |                                      |
| 11838 | 034744 | 042777 | 000076 | 147106 | BIC     | #76, @RHCS1               | : CLEAR FUNCTION BITS                |
| 11839 |        |        |        |        | : CHECK | THAT RHCS1 HAS SC:RDY:DVA |                                      |
| 11840 | 034752 | 012737 | 104200 | 001124 | MOV     | #SC:RDY:DVA, \$GDDAT      | : GET GOOD = 104200                  |
| 11841 |        |        |        |        |         |                           |                                      |
| 11842 | 034760 | 017737 | 147074 | 001126 | MOV     | @RHCS1, \$BDDAT           | : READ RHCS1 FOR COMPARISON          |
| 11843 | 034766 | 023737 | 001124 | 001126 | CMP     | \$GDDAT, \$BDDAT          | : COMPARE EXPECTED                   |
| 11844 |        |        |        |        |         |                           | : DATA WITH DATA READ FROM           |
| 11845 |        |        |        |        |         |                           | : RHCS1                              |
| 11846 | 034774 | 001401 |        |        | BEQ     | 67\$                      | : BRANCH IF GOOD                     |
| 11847 | 034776 | 104125 |        |        | ERROR   | 125                       |                                      |
| 11848 |        |        |        |        |         |                           | : AFTER SETTING "CLR" BIT #5         |
| 11849 |        |        |        |        |         |                           | : IN RHCS2 TO INIT THE RH            |
| 11850 |        |        |        |        |         |                           | : A THREE WORD WRITE REVERSE FROM AN |
| 11851 |        |        |        |        |         |                           | : ODD WORD BOUNDARY WAS DONE         |
| 11852 |        |        |        |        |         |                           | : THEN                               |
| 11853 |        |        |        |        |         |                           | : RHCS1 SHOULD HAVE SC:RDY:DVA       |
| 11854 |        |        |        |        |         |                           | : =104200                            |
| 11855 |        |        |        |        |         |                           | : BUT CONTAINED WHAT IS              |
| 11856 |        |        |        |        |         |                           | : GIVEN IN BAD RHCS1                 |
| 11857 | 035000 |        |        |        | 67\$:   |                           |                                      |
| 11858 |        |        |        |        | : CHECK | THAT RHCS2 HAS IR:OR      |                                      |
| 11859 | 035000 | 012737 | 000300 | 001124 | MOV     | #IR:OR, \$GDDAT           | : GET GOOD = 300                     |
| 11860 | 035006 | 053737 | 005010 | 001124 | BIS     | UNIT, \$GDDAT             | : INCLUDE UNIT NUMBER                |
| 11861 |        |        |        |        |         |                           |                                      |
| 11862 | 035014 | 017737 | 147050 | 001126 | MOV     | @RHCS2, \$BDDAT           | : READ RHCS2 FOR COMPARISON          |
| 11863 | 035022 | 023737 | 001124 | 001126 | CMP     | \$GDDAT, \$BDDAT          | : COMPARE EXPECTED                   |
| 11864 |        |        |        |        |         |                           | : DATA WITH DATA READ FROM           |
| 11865 |        |        |        |        |         |                           | : RHCS2                              |
| 11866 | 035030 | 001401 |        |        | BEQ     | 69\$                      | : BRANCH IF GOOD                     |
| 11867 | 035032 | 104126 |        |        | ERROR   | 126                       |                                      |
| 11868 |        |        |        |        |         |                           | : AFTER SETTING "CLR" BIT #5         |
| 11869 |        |        |        |        |         |                           | : IN RHCS2 TO INIT THE RH            |
| 11870 |        |        |        |        |         |                           | : A THREE WORD WRITE REVERSE FROM AN |
| 11871 |        |        |        |        |         |                           | : ODD WORD BOUNDARY WAS DONE         |
| 11872 |        |        |        |        |         |                           | : THEN                               |
| 11873 |        |        |        |        |         |                           | : RHCS2 SHOULD HAVE IR:OR            |
| 11874 |        |        |        |        |         |                           | : =300                               |
| 11875 |        |        |        |        |         |                           | : TOGETHER WITH UNIT NUMBER          |
| 11876 |        |        |        |        |         |                           | : BUT CONTAINED WHAT IS              |
| 11877 |        |        |        |        |         |                           | : GIVEN IN BAD RHCS2                 |
| 11878 | 035034 |        |        |        | 69\$:   |                           |                                      |
| 11879 |        |        |        |        | : CHECK | THAT RHWC HAS 0           |                                      |
| 11880 | 035034 | 012737 | 000000 | 001124 | MOV     | #0, \$GDDAT               | : GET GOOD = 0                       |
| 11881 |        |        |        |        |         |                           |                                      |
| 11882 | 035042 | 017737 | 147014 | 001126 | MOV     | @RHWC, \$BDDAT            | : READ RHWC FOR COMPARISON           |

```

11883 035050 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
11884 ;DATA WITH DATA READ FROM
11885 ;RHC
11886 035056 001401 BEQ 71$;BRANCH IF GOOD
11887 035060 104131 ERROR 131
11888 ;AFTER SETTING "CLR" BIT #5
11889 ;IN RHCS2 TO INIT THE RH
11890 ;A THREE WORD WRITE REVERSE FROM AN
11891 ;ODD WORD BOUNDARY WAS DONE
11892 ;THEN
11893 ;RHC SHOULD HAVE 0
11894 ;BUT CONTAINED WHAT IS
11895 ;GIVEN IN BAD RHC

```

11896 035062 71\$:

```

11900 ;*****
11901 ;*TEST 61 TEST DBL (RHCS3 BIT #10) TEST R
11902

```

```

11903 ;* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
11904 ;* SET UP FOR A TWO WORD WRITE REVERSE FROM AN EVEN WORD BOUNDARY
11905 ;* WITH BAI IN RHCS2 BIT #3 SET
11906 ;* DO A TWO WORD WRITE REVERSE FROM AN EVEN WORD BOUNDARY
11907 ;* THIS SHOULD NOT SET RHCS3 BIT #10 DBL
11908 ;* CHECK RHCS3
11909 ;* CHECK RHCS1,RHCS2,RHBA,RHBAE,RHC
11910

```

```

11911 ;*****
11912 035062 000004 †ST61: SCOPE
11913 035064 012706 001000 MOV #STACK,SP ;RESET STACK
11914 035070 012737 000061 004656 MOV #61,‡#†STNM ;SAVE TEST NUMBER
11915

```

```

11916 035076 004737 040322 JSR PC,‡#CLDISK ;GIVE RH INITIALIZE
11917 ;SETUP UNIT NUBER
11918 ;CLEAR RHC AND FUNCTION BITS IN RHCS1
11919

```

```

11920 ;SET UP FOR A TWO WORD WRITE REVERSE FROM AN EVEN WORD BOUNDARY

```

```

11921 035102 012701 000003 MOV #3,R1 ;COUNT OF THREE
11922 035106 012702 003000 MOV #BFEVEN,R2 ;START THREE WORD BUFFER
11923 ;FROM AN EVEN WORD BOUNDARY
11924 035112 012722 052525 1$: MOV #52525,(R2)+ ;MOVE THREE 52525 INTO BUFFER
11925 035116 005301 DEC R1 ;COUNT
11926 035120 001374 BNE 1$;BRANCH IF THREE NOT DONE
11927 035122 012777 003000 146734 MOV #BFEVEN,‡RHBA ;SET BUS ADDRESS TO START
11928 ;FROM AN EVEN WORD BOUNDARY

```

```

11929 035130 012777 177776 146724 MOV #-2,‡RHC ;WORD COUNT TWO
11930 035136 052777 000010 146724 BIS #BAI,‡RHCS2 ;SET BAI IN RHCS2
11931 035144 004077 147470 JSR ‡R0,‡COMND ;GO TO DO COMMAND
11932 035150 004204 REVWRT ;REVERSEWRITE DATA
11933

```

```

11934 ;CHECK THAT RHCS3 HAS 0
11935
11936 035152 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
11937

```

```

11938 035160 017737 146746 001126 MOV ‡RHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON

```





```

11995 ;GIVEN IN BAD RHCS2
11996 035270 69$:
11997 ;CHECK THAT RHWC HAS 0
11998 035270 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
11999
12000 035276 017737 146560 001126 MOV @RHWC,$BDDAT ;READ RHWC FOR COMPARISON
12001 035304 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
12002 ;DATA WITH DATA READ FROM
12003 ;RHWC
12004 035312 001401 BEQ 71$;BRANCH IF GOOD
12005 035314 104131 ERROR 131
12006 ;AFTER SETTING "CLR" BIT #5
12007 ;IN RHCS2 TO INIT THE RH
12008 ;A TWO WORD WRITE REVERSE FROM AN
12009 ;EVEN WORD BOUNDARY WAS DONE
12010 ;WITH BAI IN RHCS2 SET
12011 ;THEN
12012 ;RHWC SHOULD HAVE 0
12013 ;BUT CONTAINED WHAT IS
12014 ;GIVEN IN BAD RHWC
12015 035316 71$:
12016
12017
12018
12019
12020 ;*****
12021 ;*TEST 62 TEST DBL (RHCS3 BIT #10) TEST S
12022
12023 ;*
12024 ;* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
12025 ;* SET UP FOR A NINE WORD READ REVERSE FROM AN EVEN WORD BOUNDARY
12026 ;* DO A NINE WORD READ REVERSE FROM AN EVEN WORD BOUNDARY
12027 ;* THIS SHOULD SET RHCS3 BIT #10 DBL
12028 ;* CHECK RHCS3
12029 ;* CHECK RHCS1,RHCS2,RHBA,RHBAE,RHWC
12030 ;* IF MAG. TAPE NOT USED.THIS TEST IS NOT DONE
12031 ;*****
12032 035316 000004 TST62: SCOPE
12033 035320 012706 001000 MOV #STACK,SP ;RESET STACK
12034 035324 012737 000062 004656 MOV #62,@TSTNM ;SAVE TEST NUMBER
12035
12036 035332 004737 040322 JSR PC,@CLDISK ;GIVE RH INITIALIZE
12037 ;SETUP UNIT NUBER
12038 ;CLEAR RHWC AND FUNCTION BITS IN RHCS1
12039 035336 022737 041710 004640 CMP #CMNDTM,COMND ;IS TU THERE
12040
12041 035344 001103 BNE TST63 ;BRANCH IF TU NOT THERE
12042
12043
12044 ;SET UP FOR A NINE WORD READ REVERSE FROM AN EVEN WORD BOUNDARY
12045 035346 012701 000003 MOV #3,R1 ;COUNT OF THREE
12046 035352 012702 003000 MOV #BFEBVEN,R2 ;START THREE WORD BUFFER
12047 ;FROM AN EVEN WORD BOUNDARY
12048 035356 012722 052525 1$: MOV #52525,(R2)+ ;MOVE THREE 52525 INTO BUFFER
12049 035362 005301 DEC R1 ;COUNT
12050 035364 001374 BNE 1$;BRANCH IF THREE NOT DONE

```

MAINDEC-11-DERHAC-A  
DERHAC.P11 T62MACY11 27(732) 09-SEP-76 07:55 PAGE 224  
TEST DBL (RHCS3 BIT #10) TEST S

```

12051 035366 012777 003000 146470 MOV #BFEVEN,ARHBA ;SET BUS ADDRESS TO START
12052 ;FROM AN EVEN WORD BOUNDARY
12053 035374 012777 177767 146460 MOV #-9.,ARHWC ;WORD COUNT NINE
12054
12055 035402 004077 147232 JSR RD,ACOMND ;GO TO DO COMMAND
12056 035406 004200 REVRED ;REVERSE READ
12057
12058 ;CHECK THAT RHCS3 HAS DBL
12059 035410 012737 002000 001124 MOV #DBL,$GDDAT ;GET GOOD = 2000
12060
12061 035416 017737 146510 001126 MOV ARHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON
12062 035424 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
12063 ;DATA WITH DATA READ FROM
12064 ;RHCS3
12065 035432 001401 BEQ 65$;BRANCH IF GOOD
12066 035434 104124 ERROR 124
12067 ;AFTER SETTING "CLR" BIT #5
12068 ;IN RHCS2 TO INIT THE RH
12069 ;A NINE WORD READ REVERSE FROM AN
12070 ;EVEN WORD BOUNDARY WAS DONE
12071 ;THEN
12072 ;RHCS3 SHOULD HAVE DBL
12073 ;=2000
12074 ;BUT CONTAINED WHAT IS
12075 ;GIVEN IN BAD RHCS3
12076 035436 65$:
12077 035436 042777 000076 146414 BIC #76,ARHCS1 ;CLEAR FUNCTION BITS
12078 ;CHECK THAT RHCS1 HAS RDY!DVA
12079 035444 012737 004200 001124 MOV #RDY!DVA,$GDDAT ;GET GOOD = 4200
12080
12081 035452 017737 146402 001126 MOV ARHCS1,$BDDAT ;READ RHCS1 FOR COMPARISON
12082 035460 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
12083 ;DATA WITH DATA READ FROM
12084 ;RHCS1
12085 035466 001401 BEQ 67$;BRANCH IF GOOD
12086 035470 104125 ERROR 125
12087 ;AFTER SETTING "CLR" BIT #5
12088 ;IN RHCS2 TO INIT THE RH
12089 ;A NINE WORD READ REVERSE FROM AN
12090 ;EVEN WORD BOUNDARY WAS DONE
12091 ;THEN
12092 ;RHCS1 SHOULD HAVE RDY!DVA
12093 ;=4200
12094 ;BUT CONTAINED WHAT IS
12095 ;GIVEN IN BAD RHCS1
12096 035472 67$:
12097 ;CHECK THAT RHCS2 HAS IR
12098 035472 012737 000100 001124 MOV #IR,$GDDAT ;GET GOOD = 100
12099 035500 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
12100
12101 035506 017737 146356 001126 MOV ARHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
12102 035514 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
12103 ;DATA WITH DATA READ FROM
12104 ;RHCS2
12105 035522 001401 BEQ 69$;BRANCH IF GOOD
12106 035524 104126 ERROR 126

```

; AFTER SETTING "CLR" BIT #5  
; IN RHCS2 TO INIT THE RH  
; A NINE WORD READ REVERSE FROM AN  
; EVEN WORD BOUNDARY WAS DONE  
; THEN  
; RHCS2 SHOULD HAVE IR  
; =100  
; TOGETHER WITH UNIT NUMBER  
; BUT CONTAINED WHAT IS  
; GIVEN IN BAD RHCS2

; AFTER SETTING "CLR" BIT #5  
; IN RHCS2 TO INIT THE RH  
; A NINE WORD READ REVERSE FROM AN  
; EVEN WORD BOUNDARY WAS DONE  
; THEN  
; RHWC SHOULD HAVE 0  
; BUT CONTAINED WHAT IS  
; GIVEN IN BAD RHWC

12107  
12108  
12109  
12110  
12111  
12112  
12113  
12114  
12115  
12116  
12117 035526  
12118  
12119 035526 012737 000000 001124  
12120  
12121 035534 017737 146322 001126  
12122 035542 023737 001124 001126  
12123  
12124  
12125 035550 001401  
12126 035552 104131  
12127  
12128  
12129  
12130  
12131  
12132  
12133  
12134  
12135 035554  
12136  
12137  
12138  
12139  
12140  
12141  
12142  
12143  
12144  
12145  
12146  
12147  
12148  
12149  
12150  
12151 035554 000004  
12152 035556 012706 001000  
12153 035562 012737 000063 004656  
12154  
12155 035570 004737 040322  
12156  
12157  
12158 035574 022737 041710 004640  
12159  
12160 035602 001103  
12161  
12162

69\$:

; CHECK THAT RHWC HAS 0  
MOV #0, \$GDDAT  
MOV @RHWC, \$BDDAT  
CMP \$GDDAT, \$BDDAT  
BEQ 71\$  
ERROR 131

; GET GOOD = 0

; READ RHWC FOR COMPARISON  
; COMPARE EXPECTED  
; DATA WITH DATA READ FROM  
; RHWC  
; BRANCH IF GOOD

71\$:

\*\*\*\*\*  
; \*TEST 63 TEST DBL (RHCS3 BIT #10) TEST T

; \* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)  
; \* SET UP FOR A TEN WORD READ REVERSE FROM AN EVEN WORD BOUNDARY  
; \* DO A TEN WORD READ REVERSE FROM AN EVEN WORD BOUNDARY  
; \* THIS SHOULD NOT SET RHCS3 BIT #10 DBL  
; \* CHECK RHCS3  
; \* CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC  
; \* IF MAG. TAPE NOT USED. THIS TEST IS NOT DONE

\*\*\*\*\*  
; \*T63: SCOPE

MOV #STACK, SP ; RESET STACK  
MOV #63, @TSTNM ; SAVE TEST NUMBER

JSR PC, @CLDISK ; GIVE RH INITIALIZE  
; SETUP UNIT NUMBER

CMP #CMNDTM, COMND ; CLEAR RHWC AND FUNCTION BITS IN RHCS1  
; IS TU THERE

BNE TST64 ; BRANCH IF TU NOT THERE

```

12163 ;SET UP FOR A TEN WORD READ REVERSE FROM AN EVEN WORD BOUNDARY
12164 035604 012701 000003 MOV #3,R1 ;COUNT OF THREE
12165 035610 012702 003000 MOV #BFEVEN,R2 ;START THREE WORD BUFFER
12166 ;FROM AN EVEN WORD BOUNDARY
12167 035614 012722 052525 1$: MOV #52525,(R2)+ ;MOVE THREE 52525 INTO BUFFER
12168 035620 005301 DEC R1 ;COUNT
12169 035622 001374 BNE 1$;BRANCH IF THREE NOT DONE
12170 035624 012777 003000 146232 MOV #BFEVEN,DRHBA ;SET BUS ADDRESS TO START
12171 ;FROM AN EVEN WORD BOUNDARY
12172 035632 012777 177766 146222 MOV #-10.,DRHWC ;WORD COUNT TEN
12173
12174 035640 004077 146774 JSR RO,DRCOMND ;GO TO DO COMMAND
12175 035644 004200 REVRED ;REVERSE READ
12176
12177 ;CHECK THAT RHCS3 HAS 0
12178 035646 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
12179
12180 035654 017737 146252 001126 MOV DRHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON
12181 035662 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
12182 ;DATA WITH DATA READ FROM
12183 ;RHCS3
12184 035670 001401 BEQ 65$;BRANCH IF GOOD
12185 035672 104124
12186 ;AFTER SETTING "CLR" BIT #5
12187 ;IN RHCS2 TO INIT THE RH
12188 ;A TEN WORD READ REVERSE FROM AN
12189 ;EVEN WORD BOUNDARY WAS DONE
12190 ;THEN
12191 ;RHCS3 SHOULD HAVE 0
12192 ;BUT CONTAINED WHAT IS
12193 ;GIVEN IN BAD RHCS3
12194 035674 65$:
12195 035674 042777 000076 146156 BIC #76,DRHCS1 ;CLEAR FUNCTION BITS
12196 ;CHECK THAT RHCS1 HAS RDY!DVA
12197 035702 012737 004200 001124 MOV #RDY!DVA,$GDDAT ;GET GOOD = 4200
12198
12199 035710 017737 146144 001126 MOV DRHCS1,$BDDAT ;READ RHCS1 FOR COMPARISON
12200 035716 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
12201 ;DATA WITH DATA READ FROM
12202 ;RHCS1
12203 035724 001401 BEQ 67$;BRANCH IF GOOD
12204 035726 104125
12205 ;AFTER SETTING "CLR" BIT #5
12206 ;IN RHCS2 TO INIT THE RH
12207 ;A TEN WORD READ REVERSE FROM AN
12208 ;EVEN WORD BOUNDARY WAS DONE
12209 ;THEN
12210 ;RHCS1 SHOULD HAVE RDY!DVA
12211 ;=4200
12212 ;BUT CONTAINED WHAT IS
12213 ;GIVEN IN BAD RHCS1
12214 035730 67$:
12215 ;CHECK THAT RHCS2 HAS IR
12216 035730 012737 000100 001124 MOV #IR,$GDDAT ;GET GOOD = 100
12217 035736 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
12218

```



```

12275 ;CLEAR RHWC AND FUNCTION BITS IN RHCS1
12276 036032 022737 041710 004640 CMP #CMNDTM,COMND ;IS TU THERE
12277 ;
12278 036040 001103 BNE TST65 ;BRANCH IF TU NOT THERE
12279 ;
12280 ;
12281 ;SET UP FOR A TEN WORD READ REVERSE FROM AN ODD WORD BOUNDARY
12282 036042 012701 000003 MOV #3,R1 ;COUNT OF THREE
12283 036046 012702 003002 MOV #BFODD,R2 ;START THREE WORD BUFFER
12284 ;FROM AN ODD WORD BOUNDARY
12285 036052 012722 052525 1$: MOV #52525,(R2)+ ;MOVE THREE 52525 INTO BUFFER
12286 036056 005301 DEC R1 ;COUNT
12287 036060 001374 BNE 1$;BRANCH IF THREE NOT DONE
12288 036062 012777 003002 145774 MOV #BFODD,ARHBA ;SET BUS ADDRESS TO START
12289 ;FROM AN ODD WORD BOUNDARY
12290 036070 012777 177766 145764 MOV #-10.,ARHWC ;WORD COUNT TEN
12291 ;
12292 036076 004077 146536 JSR RD,ACOMND ;GO TO DO COMMAND
12293 036102 004200 REVRED ;REVERSE READ
12294 ;
12295 ;CHECK THAT RHCS3 HAS DBL
12296 036104 012737 002000 001124 MOV #DBL,$GDDAT ;GET GOOD = 2000
12297 ;
12298 036112 017737 146014 001126 MOV ARHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON
12299 036120 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
12300 ;DATA WITH DATA READ FROM
12301 ;RHCS3
12302 036126 001401 BEQ 65$;BRANCH IF GOOD
12303 036130 104124 ERROR 124
12304 ;
12305 ;AFTER SETTING "CLR" BIT #5
12306 ;IN RHCS2 TO INIT THE RH
12307 ;A TEN WORD READ REVERSE FROM AN
12308 ;ODD WORD BOUNDARY WAS DONE
12309 ;THEN
12310 ;RHCS3 SHOULD HAVE DBL
12311 ;=2000
12312 ;BUT CONTAINED WHAT IS
12313 ;GIVEN IN BAD RHCS3
12313 036132 042777 000076 145720 65$: BIC #76,ARHCS1 ;CLEAR FUNCTION BITS
12314 036132 042777 000076 145720 ;CHECK THAT RHCS1 HAS RDY!DVA
12315 ;
12316 036140 012737 004200 001124 MOV #RDY!DVA,$GDDAT ;GET GOOD = 4200
12317 ;
12318 036146 017737 145706 001126 MOV ARHCS1,$BDDAT ;READ RHCS1 FOR COMPARISON
12319 036154 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
12320 ;DATA WITH DATA READ FROM
12321 ;RHCS1
12322 036162 001401 BEQ 67$;BRANCH IF GOOD
12323 036164 104125 ERROR 125
12324 ;
12325 ;AFTER SETTING "CLR" BIT #5
12326 ;IN RHCS2 TO INIT THE RH
12327 ;A TEN WORD READ REVERSE FROM AN
12328 ;ODD WORD BOUNDARY WAS DONE
12329 ;THEN
12330 ;RHCS1 SHOULD HAVE RDY!DVA
12330 ;=4200

```

```

12331 ;BUT CONTAINED WHAT IS
12332 ;GIVEN IN BAD RHCS1
12333 036166 67$:
12334 ;CHECK THAT RHCS2 HAS IR
12335 036166 012737 000100 001124 MOV #IR,$GDDAT ;GET GOOD = 100
12336 036174 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
12337
12338 036202 017737 145662 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
12339 036210 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
12340 ;DATA WITH DATA READ FROM
12341 ;RHCS2
12342 036216 001401 BEQ 69$;BRANCH IF GOOD
12343 036220 104126
12344 ;AFTER SETTING "CLR" BIT #5
12345 ;IN RHCS2 TO INIT THE RH
12346 ;A TEN WORD READ REVERSE FROM AN
12347 ;ODD WORD BOUNDARY WAS DONE
12348 ;THEN
12349 ;RHCS2 SHOULD HAVE IR
12350 ;=100
12351 ;TOGETHER WITH UNIT NUMBER
12352 ;BUT CONTAINED WHAT IS
12353 ;GIVEN IN BAD RHCS2
12354 036222 69$:
12355 ;CHECK THAT RHWC HAS 0
12356 036222 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
12357
12358 036230 017737 145626 001126 MOV @RHWC,$BDDAT ;READ RHWC FOR COMPARISON
12359 036236 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
12360 ;DATA WITH DATA READ FROM
12361 ;RHWC
12362 036244 001401 BEQ 71$;BRANCH IF GOOD
12363 036246 104131
12364 ;AFTER SETTING "CLR" BIT #5
12365 ;IN RHCS2 TO INIT THE RH
12366 ;A TEN WORD READ REVERSE FROM AN
12367 ;ODD WORD BOUNDARY WAS DONE
12368 ;THEN
12369 ;RHWC SHOULD HAVE 0
12370 ;BUT CONTAINED WHAT IS
12371 ;GIVEN IN BAD RHWC
12372 036250 71$:
12373
12374
12375
12376 ;*****
12377 ;*TEST 65 TEST DBL (RHCS3 BIT #10) TEST V
12378
12379 ;*
12380 ;* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)
12381 ;* SET UP FOR A ELEVEN WORD READ REVERSE FROM AN EVEN WORD BOUNDARY
12382 ;* DO A ELEVEN WORD READ REVERSE FROM AN EVEN WORD BOUNDARY
12383 ;* THIS SHOULD SET RHCS3 BIT #10 DBL
12384 ;* CHECK RHCS3
12385 ;* CHECK RHCS1,RHCS2,RHBA,RHBAE,RHWC
12386 ;* IF MAG. TAPE NOT USED.THIS TEST IS NOT DONE

```

```

12387
12388 036250 000004
12389 036252 012706 001000
12390 036256 012737 000065 004656
12391
12392 036264 004737 040322
12393
12394
12395 036270 022737 041710 004640
12396
12397 036276 001103
12398
12399
12400
12401 036300 012701 000003
12402 036304 012702 003000
12403
12404 036310 012722 052525
12405 036314 005301
12406 036316 001374
12407 036320 012777 003000 145536
12408
12409 036326 012777 177765 145526
12410
12411 036334 004077 146300
12412 036340 004200
12413
12414
12415 036342 012737 002000 001124
12416
12417 036350 017737 145556 001126
12418 036356 023737 001124 001126
12419
12420
12421 036364 001401
12422 036366 104124
12423
12424
12425
12426
12427
12428
12429
12430
12431
12432 036370
12433 036370 042777 000076 145462
12434
12435 036376 012737 004200 001124
12436
12437 036404 017737 145450 001126
12438 036412 023737 001124 001126
12439
12440
12441 036420 001401
12442 036422 104125

```

```

:*****
TST65: SCOPE
MOV #STACK,SP ;RESET STACK
MOV #65,#TSTNM ;SAVE TEST NUMBER
JSR PC,#CLDISK ;GIVE RH INITIALIZE
;SETUP UNIT NUBER
;CLEAR RHWC AND FUNCTION BITS IN RHCS1
CMP #CMNDTM,COMND ;IS TU THERE
BNE TST66 ;BRANCH IF TU NOT THERE

;SET UP FOR A ELEVEN WORD READ REVERSE FROM AN EVEN WORD BOUNDARY
MOV #3,R1 ;COUNT OF THREE
MOV #BFEVEN,R2 ;START THREE WORD BUFFER
;FROM AN EVEN WORD BOUNDARY
1$: MOV #52525,(R2)+ ;MOVE THREE 52525 INTO BUFFER
DEC R1 ;COUNT
BNE 1$;BRANCH IF THREE NOT DONE
MOV #BFEVEN,#RHBA ;SET BUS ADDRESS TO START
;FROM AN EVEN WORD BOUNDARY
MOV #-11.,#RHWC ;WORD COUNT ELEVEN
JSR RD,#COMND ;GO TO DO COMMAND
REVRED ;REVERSE READ

;CHECK THAT RHCS3 HAS DBL
MOV #DBL,#GDDAT ;GET GOOD = 2000
MOV #RHCS3,#BDDAT ;READ RHCS3 FOR COMPARISON
CMP #GDDAT,#BDDAT ;COMPARE EXPECTED
;DATA WITH DATA READ FROM
;RHCS3
BEQ 65$;BRANCH IF GOOD
ERROR 124

;AFTER SETTING "CLR" BIT #5
;IN RHCS2 TO INIT THE RH
;A ELEVEN WORD READ REVERSE FROM AN
;EVEN WORD BOUNDARY WAS DONE
;THEN
;RHCS3 SHOULD HAVE DBL
;=2000
;BUT CONTAINED WHAT IS
;GIVEN IN BAD RHCS3
65$: BIC #76,#RHCS1 ;CLEAR FUNCTION BITS
;CHECK THAT RHCS1 HAS RDY!DVA
MOV #RDY!DVA,#GDDAT ;GET GOOD = 4200
MOV #RHCS1,#BDDAT ;READ RHCS1 FOR COMPARISON
CMP #GDDAT,#BDDAT ;COMPARE EXPECTED
;DATA WITH DATA READ FROM
;RHCS1
BEQ 67$;BRANCH IF GOOD
ERROR 125

```



```

12443 ; AFTER SETTING "CLR" BIT #5
12444 ; IN RHCS2 TO INIT THE RH
12445 ; A ELEVEN WORD READ REVERSE FROM AN
12446 ; EVEN WORD BOUNDARY WAS DONE
12447 ; THEN
12448 ; RHCS1 SHOULD HAVE RDY!DVA
12449 ; =4200
12450 ; BUT CONTAINED WHAT IS
12451 ; GIVEN IN BAD RHCS1
12452 036424 67$:
12453 ; CHECK THAT RHCS2 HAS IR
12454 036424 012737 000100 001124 MOV #IR,$GDDAT ; GET GOOD = 100
12455 036432 053737 005010 001124 BIS UNIT,$GDDAT ; INCLUDE UNIT NUMBER
12456
12457 036440 017737 145424 001126 MOV @RHCS2,$BDDAT ; READ RHCS2 FOR COMPARISON
12458 036446 023737 001124 001126 CMP $GDDAT,$BDDAT ; COMPARE EXPECTED
12459 ; DATA WITH DATA READ FROM
12460 ; RHCS2
12461 036454 001401 BEQ 69$; BRANCH IF GOOD
12462 036456 104126 ERROR 126
12463 ; AFTER SETTING "CLR" BIT #5
12464 ; IN RHCS2 TO INIT THE RH
12465 ; A ELEVEN WORD READ REVERSE FROM AN
12466 ; EVEN WORD BOUNDARY WAS DONE
12467 ; THEN
12468 ; RHCS2 SHOULD HAVE IR
12469 ; =100
12470 ; TOGETHER WITH UNIT NUMBER
12471 ; BUT CONTAINED WHAT IS
12472 ; GIVEN IN BAD RHCS2
12473 036460 69$:
12474 ; CHECK THAT RHWC HAS 0
12475 036460 012737 000000 001124 MOV #0,$GDDAT ; GET GOOD = 0
12476
12477 036466 017737 145370 001126 MOV @RHWC,$BDDAT ; READ RHWC FOR COMPARISON
12478 036474 023737 001124 001126 CMP $GDDAT,$BDDAT ; COMPARE EXPECTED
12479 ; DATA WITH DATA READ FROM
12480 ; RHWC
12481 036502 001401 BEQ 71$; BRANCH IF GOOD
12482 036504 104131 ERROR 131
12483 ; AFTER SETTING "CLR" BIT #5
12484 ; IN RHCS2 TO INIT THE RH
12485 ; A ELEVEN WORD READ REVERSE FROM AN
12486 ; EVEN WORD BOUNDARY WAS DONE
12487 ; THEN
12488 ; RHWC SHOULD HAVE 0
12489 ; BUT CONTAINED WHAT IS
12490 ; GIVEN IN BAD RHWC
12491 036506 71$:
12492
12493
12494
12495 ; *****
12496 ; *TEST 66 TEST DBL (RHCS3 BIT #10) TEST W
12497
12498 ; * CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)

```

```

12499 ;* SET UP FOR A ELEVEN WORD READ REVERSE FROM AN ODD WORD BOUNDARY
12500 ;* DO A ELEVEN WORD READ REVERSE FROM AN ODD WORD BOUNDARY
12501 ;* THIS SHOULD NOT SET RHCS3 BIT #10 DBL
12502 ;* CHECK RHCS3
12503 ;* CHECK RHCS1,RHCS2,RHBA,RHBAE,RHWC
12504 ;* IF MAG. TAPE NOT USED.THIS TEST IS NOT DONE
12505
12506 ;*****
12507 036506 000004 †T66: SCOPE
12508 036510 012706 001000 MOV #STACK,SP ;RESET STACK
12509 036514 012737 000066 004656 MOV #66,‡#†STNM ;SAVE TEST NUMBER
12510
12511 036522 004737 040322 JSR PC,‡#CLDISK ;GIVE RH INITIALIZE
12512 ;SETUP UNIT NUBER
12513 ;CLEAR RHWC AND FUNCTION BITS IN RHCS1
12514 036526 022737 041710 004640 CMP #CMNDTM,COMND ;IS TU THERE
12515
12516 036534 001103 BNE TST67 ;BRANCH IF TU NOT THERE
12517
12518
12519 ;SET UP FOR A ELEVEN WORD READ REVERSE FROM AN ODD WORD BOUNDARY
12520 036536 012701 000003 MOV #3,R1 ;COUNT OF THREE
12521 036542 012702 003002 MOV #BF0DD,R2 ;START THREE WORD BUFFER
12522 ;FROM AN ODD WORD BOUNDARY
12523 036546 012722 052525 1$: MOV #52525,(R2)+ ;MOVE THREE 52525 INTO BUFFER
12524 036552 005301 DEC R1 ;COUNT
12525 036554 001374 BNE 1$;BRANCH IF THREE NOT DONE
12526 036556 012777 003002 145300 MOV #BF0DD,‡RHBA ;SET BUS ADDRESS TO START
12527 ;FROM AN ODD WORD BOUNDARY
12528 036564 012777 177765 145270 MOV #-11.,‡RHWC ;WORD COUNT ELEVEN
12529
12530 036572 004077 146042 JSR RO,‡COMND ;GO TO DO COMMAND
12531 036576 004200 REVRED ;REVERSE READ
12532
12533 ;CHECK THAT RHCS3 HAS 0
12534 036600 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
12535
12536 036606 017737 145320 001126 MOV ‡RHCS3,$BDDAT ;READ RHCS3 FOR COMPARISON
12537 036614 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
12538 ;DATA WITH DATA READ FROM
12539 ;RHCS3
12540 036622 001401 BEQ 65$;BRANCH IF GOOD
12541 036624 104124 ERROR 124
12542
12543 ;AFTER SETTING "CLR" BIT #5
12544 ;IN RHCS2 TO INIT THE RH
12545 ;A ELEVEN WORD READ REVERSE FROM AN
12546 ;ODD WORD BOUNDARY WAS DONE
12547 ;THEN
12548 ;RHCS3 SHOULD HAVE 0
12549 ;BUT CONTAINED WHAT IS
12550 ;GIVEN IN BAD RHCS3
12550 036626 65$:
12551 036626 042777 000076 145224 BIC #76,‡RHCS1 ;CLEAR FUNCTION BITS
12552 ;CHECK THAT RHCS1 HAS RDY!DVA
12553 036634 012737 004200 001124 MOV #RDY!DVA,$GDDAT ;GET GOOD = 4200
12554

```

```

12555 036642 017737 145212 001126 MOV @RHCS1,$BDDAT ;READ RHCS1 FOR COMPARISON
12556 036650 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
12557 ;DATA WITH DATA READ FROM
12558 ;RHCS1
12559 036656 001401 BEQ 67$;BRANCH IF GOOD
12560 036660 104125 ERROR 125
12561 ;AFTER SETTING "CLR" BIT #5
12562 ;IN RHCS2 TO INIT THE RH
12563 ;A ELEVEN WORD READ REVERSE FROM AN
12564 ;ODD WORD BOUNDARY WAS DONE
12565 ;THEN
12566 ;RHCS1 SHOULD HAVE RDY!DVA
12567 ;=4200
12568 ;BUT CONTAINED WHAT IS
12569 ;GIVEN IN BAD RHCS1
12570 036662 67$:
12571 ;CHECK THAT RHCS2 HAS IR
12572 036662 012737 000100 001124 MOV #IR,$GDDAT ;GET GOOD = 100
12573 036670 053737 005010 001124 BIS UNIT,$GDDAT ;INCLUDE UNIT NUMBER
12574 ;
12575 036676 017737 145166 001126 MOV @RHCS2,$BDDAT ;READ RHCS2 FOR COMPARISON
12576 036704 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
12577 ;DATA WITH DATA READ FROM
12578 ;RHCS2
12579 036712 001401 BEQ 69$;BRANCH IF GOOD
12580 036714 104126 ERROR 126
12581 ;AFTER SETTING "CLR" BIT #5
12582 ;IN RHCS2 TO INIT THE RH
12583 ;A ELEVEN WORD READ REVERSE FROM AN
12584 ;ODD WORD BOUNDARY WAS DONE
12585 ;THEN
12586 ;RHCS2 SHOULD HAVE IR
12587 ;=100
12588 ;TOGETHER WITH UNIT NUMBER
12589 ;BUT CONTAINED WHAT IS
12590 ;GIVEN IN BAD RHCS2
12591 036716 69$:
12592 ;CHECK THAT RHWC HAS 0
12593 036716 012737 000000 001124 MOV #0,$GDDAT ;GET GOOD = 0
12594 ;
12595 036724 017737 145132 001126 MOV @RHWC,$BDDAT ;READ RHWC FOR COMPARISON
12596 036732 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED
12597 ;DATA WITH DATA READ FROM
12598 ;RHWC
12599 036740 001401 BEQ 71$;BRANCH IF GOOD
12600 036742 104131 ERROR 131
12601 ;AFTER SETTING "CLR" BIT #5
12602 ;IN RHCS2 TO INIT THE RH
12603 ;A ELEVEN WORD READ REVERSE FROM AN
12604 ;ODD WORD BOUNDARY WAS DONE
12605 ;THEN
12606 ;RHWC SHOULD HAVE 0
12607 ;BUT CONTAINED WHAT IS
12608 ;GIVEN IN BAD RHWC
12609 036744 71$:
12610

```

12611  
12612  
12613  
12614  
12615  
12616  
12617  
12618  
12619  
12620  
12621  
12622  
12623  
12624  
12625  
12626  
12627  
12628  
12629  
12630  
12631  
12632  
12633  
12634  
12635  
12636  
12637  
12638  
12639  
12640  
12641  
12642  
12643  
12644  
12645  
12646  
12647  
12648  
12649  
12650  
12651  
12652  
12653  
12654  
12655  
12656  
12657  
12658  
12659  
12660  
12661  
12662  
12663  
12664  
12665  
12666

\*\*\*\*\*  
; \*TEST 67 TEST DBL (RHCS3 BIT #10) TEST X

; \* CLEAR THE SUBSYSTEM BY A CONTROLLER CLEAR (RHCS2 BIT #5)  
; \* SET UP FOR A TEN WORD READ REVERSE FROM AN ODD WORD BOUNDARY  
; \* WITH BAI IN RHCS2 BIT #3 SET  
; \* DO A TEN WORD READ REVERSE FROM AN ODD WORD BOUNDARY  
; \* THIS SHOULD NOT SET RHCS3 BIT #10 DBL  
; \* CHECK RHCS3  
; \* CHECK RHCS1, RHCS2, RHBA, RHBAE, RHWC  
; \* IF MAG. TAPE NOT USED. THIS TEST IS NOT DONE

\*\*\*\*\*

TST67: SCOPE  
MOV #STACK, SP ; RESET STACK  
MOV #67, #TSTNM ; SAVE TEST NUMBER  
JSR PC, #CLDISK ; GIVE RH INITIALIZE  
; SETUP UNIT NUMBER  
; CLEAR RHWC AND FUNCTION BITS IN RHCS1  
CMP #CMNDTM, COMND ; IS TU THERE  
BNE TST70 ; BRANCH IF TU NOT THERE

; SET UP FOR A TEN WORD READ REVERSE FROM AN ODD WORD BOUNDARY  
MOV #3, R1 ; COUNT OF THREE  
MOV #BF0DD, R2 ; START THREE WORD BUFFER  
; FROM AN ODD WORD BOUNDARY  
1\$: MOV #52525, (R2)+ ; MOVE THREE 52525 INTO BUFFER  
DEC R1 ; COUNT  
BNE 1\$ ; BRANCH IF THREE NOT DONE  
MOV #BF0DD, #RHBA ; SET BUS ADDRESS TO START  
; FROM AN ODD WORD BOUNDARY  
MOV #-10, #RHWC ; WORD COUNT TEN  
BIS #BAI, #RHCS2 ; SET BAI IN RHCS2

JSR RO, #COMND ; GO TO DO COMMAND  
REVRED ; REVERSE READ

; CHECK THAT RHCS3 HAS 0  
MOV #0, #GDDAT ; GET GOOD = 0

MOV #RHCS3, #BDDAT ; READ RHCS3 FOR COMPARISON  
CMP #GDDAT, #BDDAT ; COMPARE EXPECTED  
; DATA WITH DATA READ FROM  
; RHCS3  
BEQ 65\$ ; BRANCH IF GOOD

ERROR 124

; AFTER SETTING "CLR" BIT #5  
; IN RHCS2 TO INIT THE RH  
; A TEN WORD READ REVERSE FROM AN  
; ODD WORD BOUNDARY WAS DONE  
; WITH BAI IN RHCS2 SET

```

12667 ; THEN
12668 ; RHCS3 SHOULD HAVE 0
12669 ; BUT CONTAINED WHAT IS
12670 ; GIVEN IN BAD RHCS3
12671 037072 65$:
12672 037072 042777 000076 144760 BIC #76, @RHCS1 ; CLEAR FUNCTION BITS
12673 ; CHECK THAT RHCS1 HAS RDY!DVA
12674 037100 012737 004200 001124 MOV #RDY!DVA, $GDDAT ; GET GOOD = 4200
12675
12676 037106 017737 144746 001126 MOV @RHCS1, $BDDAT ; READ RHCS1 FOR COMPARISON
12677 037114 023737 001124 001126 CMP $GDDAT, $BDDAT ; COMPARE EXPECTED
12678 ; DATA WITH DATA READ FROM
12679 ; RHCS1
12680 037122 001401 BEQ 67$; BRANCH IF GOOD
12681 037124 104125 ERROR 125
12682
12683 ; AFTER SETTING "CLR" BIT #5
12684 ; IN RHCS2 TO INIT THE RH
12685 ; A TEN WORD READ REVERSE FROM AN
12686 ; ODD WORD BOUNDARY WAS DONE
12687 ; WITH BAI IN RHCS2 SET
12688 ; THEN
12689 ; RHCS1 SHOULD HAVE RDY!DVA
12690 ; =4200
12691 ; BUT CONTAINED WHAT IS
12692 ; GIVEN IN BAD RHCS1
12692 037126 67$:
12693 ; CHECK THAT RHCS2 HAS IR!BAI
12694 037126 012737 000110 001124 MOV #IR!BAI, $GDDAT ; GET GOOD = 110
12695 037134 053737 005010 001124 BIS UNIT, $GDDAT ; INCLUDE UNIT NUMBER
12696
12697 037142 017737 144722 001126 MOV @RHCS2, $BDDAT ; READ RHCS2 FOR COMPARISON
12698 037150 023737 001124 001126 CMP $GDDAT, $BDDAT ; COMPARE EXPECTED
12699 ; DATA WITH DATA READ FROM
12700 ; RHCS2
12701 037156 001401 BEQ 69$; BRANCH IF GOOD
12702 037160 104126 ERROR 126
12703
12704 ; AFTER SETTING "CLR" BIT #5
12705 ; IN RHCS2 TO INIT THE RH
12706 ; A TEN WORD READ REVERSE FROM AN
12707 ; ODD WORD BOUNDARY WAS DONE
12708 ; WITH BAI IN RHCS2 SET
12709 ; THEN
12710 ; RHCS2 SHOULD HAVE IR!BAI
12711 ; =110
12712 ; TOGETHER WITH UNIT NUMBER
12713 ; BUT CONTAINED WHAT IS
12714 ; GIVEN IN BAD RHCS2
12714 037162 69$:
12715 ; CHECK THAT RHWC HAS 0
12716 037162 012737 000000 001124 MOV #0, $GDDAT ; GET GOOD = 0
12717
12718 037170 017737 144666 001126 MOV @RHWC, $BDDAT ; READ RHWC FOR COMPARISON
12719 037176 023737 001124 001126 CMP $GDDAT, $BDDAT ; COMPARE EXPECTED
12720 ; DATA WITH DATA READ FROM
12721 ; RHWC
12722 037204 001401 BEQ 71$; BRANCH IF GOOD

```

12723 037206 104131  
 12724  
 12725  
 12726  
 12727  
 12728  
 12729  
 12730  
 12731  
 12732  
 12733 037210  
 12734  
 12735  
 12736  
 12737  
 12738  
 12739  
 12740  
 12741  
 12742  
 12743  
 12744  
 12745  
 12746  
 12747 037210 000004  
 12748 037212 012737 000001 001212  
 12749 037220 005037 177776  
 12750 037224 104401 037232  
 12751 037230 000414  
 12752  
 12753 037262  
 12754 037262 013746 005510  
 12755 037266 013702 005506  
 12756 037272 162602  
 12757 037274 006302  
 12758 037276 016246 005436  
 12759 037302 104405  
 12760 037304 104401 037312  
 12761 037310 000410  
 12762  
 12763 037332  
 12764 037332 013746 004060  
 12765 037336 104402  
 12766 037340 104401 037346  
 12767 037344 000421  
 12768  
 12769 037410  
 12770 037410 013746 001112  
 12771 037414 104405  
 12772 037416 104401 037424  
 12773 037422 000402  
 12774  
 12775 037430  
 12776 037430 104401 037436  
 12777 037434 000402  
 12778

ERROR 131

```

;AFTER SETTING "CLR" BIT #5
;IN RHCS2 TO INIT THE RH
;A TEN WORD READ REVERSE FROM AN
;ODD WORD BOUNDARY WAS DONE
;WITH BAI IN RHCS2 SET
;THEN
;RHWC SHOULD HAVE 0
;BUT CONTAINED WHAT IS
;GIVEN IN BAD RHWC

```

71\$:

```

;*****
;TEST 70 END OF ONE RH
; THIS IS THE END OF TEST FOR ONE RH
; IF THERE ARE MORE RH THEN THE PROGRAM
; JUMPS TO TEST 2 FOR NEXT RH TEST
; END PASS IS REACHED ONLY AFTER ALL RH ARE COMPLETE
;*****
TST70: SCOPE
 MOV #1,$TIMES ;;DO 1 ITERATION
 CLR PS ;;REINSTATE PS TO 0
 TYPE 65$;;TYPE ASCIZ STRING
 BR 64$;;GET OVER THE ASCIZ
;;65$: .ASCIZ <15><12>/END OF TEST FOR RH NO/
64$: MOV WORUNT,-(SP) ;;GET WORKING RH NUMBER LEFT
 MOV TSTUNT,R2 ;;GET TOTAL NO OF RH FOUND
 SUB (SP)+,R2 ;;NO OF RH TESTED
 ASL R2 ;;INDEX FOR RH TESTED
 MOV FRHNM(R2),-(SP) ;;TYPE OF RH NO.
 TYPDS
 TYPE 67$;;TYPE ASCIZ STRING
 BR 66$;;GET OVER THE ASCIZ
;;67$: .ASCIZ / BASE /
66$: MOV RHCS1,-(SP) ;;TYPE BASE ADDRESS
 TYPOC
 TYPE 69$;;TYPE ASCIZ STRING
 BR 68$;;GET OVER THE ASCIZ
;;69$: .ASCIZ <15><12>/TOTAL NO OF ERRORS ON THIS PASS/
68$: MOV $ERTTL,-(SP) ;;TYPE TOTAL NO OF ERRORS
 TYPDS
 TYPE 71$;;TYPE ASCIZ STRING
 BR 70$;;GET OVER THE ASCIZ
;;71$: .ASCIZ <15><12>/ /
70$: TYPE 73$;;TYPE ASCIZ STRING
 BR 72$;;GET OVER THE ASCIZ
;;73$: .ASCIZ <15><12>/ /

```



```

12786
12787
12788
12789
12790
12791
12792
12793
12794 037466
12795 037466 000004
12796 037470 005037 001102
12797 037474 005037 001212
12798 037500 005237 001100
12799 037504 042737 100000 001100
12800 037512 005327
12801 037514 000001
12802 037516 003022
12803 037520 012737
12804 037522 000001
12805 037524 037514
12806 037526 104401 037573
12807 037532 013746 001100
12808 037536 104405
12809 037540 104401 037570
12810 037544 013700 000042
12811 037550 001405
12812 037552 000005
12813 037554 004710
12814 037556 000240
12815 037560 000240
12816 037562 000240
12817 037564
12818 037564 000137
12819 037566 010632
12820 037570 377 377 000
12821 037573 015 042412 042116
12822 037600 050040 051501 020123
12823 037606 000043
12824
12825
12826
12827
12828
12829
12830
12831
12832
12833
12834
12835
12836
12837
12838 037610
12839 037610 104401 037616
12840 037614 000433
12841

```

.SBTTL END OF PASS ROUTINE

```

;*****
;*INCREMENT THE PASS NUMBER ($PASS)
;*TYPE "END PASS #XXXXX" (WHERE XXXXX IS A DECIMAL NUMBER)
;*IF THERES A MONITOR GO TO IT
;*IF THERE ISN'T JUMP TO TST2

```

\$EOP:

```

SCOPE
CLR $TSTNM ;;ZERO THE TEST NUMBER
CLR $TIMES ;;ZERO THE NUMBER OF ITERATIONS
INC $PASS ;;INCREMENT THE PASS NUMBER
BIC #100000,$PASS ;;DON'T ALLOW A NEG. NUMBER
DEC (PC)+ ;;LOOP?
$EOPCT: .WORD 1
BGT $DOAGN ;;YES
MOV (PC)+,a(PC)+ ;;RESTORE COUNTER
$ENDCT: .WORD 1
TYPE $ENDMG ;;TYPE "END PASS #"
MOV $PASS,-(SP) ;;SAVE $PASS FOR TYPEOUT
TYPDS ;;GO TYPE--DECIMAL ASCII WITH SIGN
TYPE $ENULL ;;TYPE A NULL CHARACTER
$GET42: MOV a#42,RO ;;GET MONITOR ADDRESS
BEQ $DOAGN ;;BRANCH IF NO MONITOR
RESET ;;CLEAR THE WORLD
$ENDAD: JSR PC,(RO) ;;GO TO MONITOR
NOP ;;SAVE ROOM
NOP ;;FOR
NOP ;;ACT11
$DOAGN: JMP a(PC)+ ;;RETURN
$RTNAD: .WORD TST2
$ENULL: .BYTE -1,-1,0 ;;NULL CHARACTER STRING
$ENDMG: .ASCIZ <15><12>/END PASS #/

```

.SBTTL SUBROUTINES

```

;*****
;* THIS ROUTINE HANDLES TIME OUT TRAPS THROUGH LOC. 4
;*****

```

TIEOUT:

```

TYPE 65$;;TYPE ASCIZ STRING
BR 64$;;GET OVER THE ASCIZ
;;65$: .ASCIZ <15><12>/TIMEOUT OCCURED THROUGH LOCATION 4 FROM PROGRAM PC/

```



```

12842 037704
12843 037704 162716 000002
12844 037710 104402
12845 037712 104401 037720
12846 037716 000410
12847
12848 037740
12849 037740 104402
12850 037742 000137 043120
12851
12852
12853
12854
12855
12856
12857
12858
12859
12860
12861
12862 037746
12863 037746 104401 037754
12864 037752 000417
12865
12866 040012
12867 040012 104401 040020
12868 040016 000413
12869
12870 040046
12871 040046 162716 000002
12872 040052 104402
12873 040054 104401 040062
12874 040060 000407
12875
12876 040100
12877 040100 104402
12878 040102 104401 040110
12879 040106 000421
12880
12881 040152
12882 040152 017746 145340
12883 040156 104402
12884 040160 104401 040166
12885 040164 000421
12886
12887 040230
12888 040230 017746 145260
12889 040234 104402
12890 040236 104401 040244
12891 040242 000422
12892
12893 040310
12894 040310 017746 145204
12895 040314 104402
12896 040316 000137 043120
12897

```

```

64$: SUB #2,(SP) ;TYPE PC
 TYPOC
 TYPE ,67$;;TYPE ASCIZ STRING
 BR ,66$;;GET OVER THE ASCIZ
;;67$: .ASCIZ <15><12>/PSW WAS /
66$: TYPOC
 JMP $SCOPE ;RETURN TO TEST

```

```

* THIS ROUTINE HANDLES PARITY ERRORS

```

```

PARITY:
 TYPE ,65$;;TYPE ASCIZ STRING
 BR ,64$;;GET OVER THE ASCIZ
;;65$: .ASCIZ <15><12>/PARITY TRAP THRU VECTOR 114/
64$: TYPE ,67$;;TYPE ASCIZ STRING
 BR ,66$;;GET OVER THE ASCIZ
;;67$: .ASCIZ <15><12>/FROM PROGRAM PC /
66$: SUB #2,(SP) ;TYPE PC
 TYPOC
 TYPE ,69$;;TYPE ASCIZ STRING
 BR ,68$;;GET OVER THE ASCIZ
;;69$: .ASCIZ <15><12>/PSW WAS /
68$: TYPOC
 TYPE ,71$;;TYPE ASCIZ STRING
 BR ,70$;;GET OVER THE ASCIZ
;;71$: .ASCIZ <15><1>/HIGH ERROR ADDRESS REGISTER /
70$: MOV @HERADD,-(SP) ;TYPE HIGH ERROR
 TYPOC
 TYPE ,73$;;TYPE ASCIZ STRING
 BR ,72$;;GET OVER THE ASCIZ
;;73$: .ASCIZ <15><12>/LOW ERROR ADDRESS REGISTER /
72$: MOV @LERADD,-(SP) ;TYPE LOW ERROR
 TYPOC
 TYPE ,75$;;TYPE ASCIZ STRING
 BR ,74$;;GET OVER THE ASCIZ
;;75$: .ASCIZ <15><12>/MEMORY SYSTEM ERROR REGISTER /
74$: MOV @MEMERR,-(SP)
 TYPOC
 JMP $SCOPE

```

12898  
12899  
12900  
12901  
12902  
12903  
12904  
12905  
12906  
12907  
12908

040322 012777 000040 143540  
040330 013777 005010 143532  
040336 042777 000077 143514  
040344 005077 143512  
040350 000207

CLDISK: MOV  
MOV  
BIC  
CLR  
RTS

#CLR,@RHCS2  
@#UNIT,@RHCS2  
#77,@RHCS1  
@RHWC  
PC

;CLEAR ALL REG.  
;REINSTATE UNIT NO.  
;CLEAR FUNCTION BITS  
;CLEAR RHWC

```

12909
12910
12911
12912
12913 ;THIS CHECKS DEVICE AVAILABLE (DVA) AND READY (RDY) IN RHCS1
12914 ;AND CHECKS MEDIUM ON LINE (MOL), DEVICE PRESENT (DPR), DEVICE READY (DRY) IN RHDS1
12915 040352 000000 PCJSR: 0 ;PC OF JSR
12916
12917
12918
12919
12920 040354 011637 040352 CHECK: MOV (SP), @#PCJSR ;SAVE PC OF JSR+4
12921 040360 162737 000004 040352 SUB #4, @#PCJSR ;GET PC OF JSR
12922 040366 011346 MOV @R3, -(SP) ;GET RHDS1
12923 040370 052716 000100 BIS #VV, (SP) ;DONT CHECK VV BIT
12924 040374 000406 BR CHECKC ;GOTO COMMON CHECK ROUTINE
12925 040376 011637 040352 CHECKT: MOV (SP), @#PCJSR ;SAVE PC OF JSR+4
12926 040402 162737 000004 040352 SUB #4, @#PCJSR ;GET PC OF JSR
12927 040410 011346 MOV @R3, -(SP) ;GET RHDS1 & DO VV CHECK AT 3$
12928 040412 011146 CHECKC: MOV @R1, -(SP) ;GET CS1
12929 040414 042716 173577 BIC #173577, (SP) ;CLEAR UNWANTED BITS
12930 040420 022726 004200 CMP #DVA!RDY, (SP)+ ;RHCS1 SHOULD HAVE DEVICE AVAILABLE
12931
12932 040424 001403 BEQ 3$;AND BE READY
12933 040426 011137 001122 MOV @R1, @#SBDADR ;BRANCH IF GOOD
12934 040432 104062 ERROR 62 ;BAD DATA REGISTER (RHCS1)
12935 ;RHCS1 DID NOT HAVE DEVICE
12936 ;AVAILABLE RIGHT AT THE START
12937 040434 042716 102000 3$: BIC #ATA!LBT, (SP) ;ALL OTHER BITS SHOULD BE 0
12938 040440 022726 010700 CMP #MOL!DPR!DRY!VV, (SP)+ ;CLEAR UNWANTED BITS
12939 040444 001403 BEQ 7$;RHDS1 SHOULD HAVE THESE SET
12940 040446 011337 001122 MOV @R3, @#SBDADR ;BRANCH IF GOOD
12941 040452 104061 ERROR 61 ;BAD DATA IN REGISTER (RHDS1)
12942 ;RHDS1 HAS SOME BITS OTHER
12943 ;THAN MOL, DRY, DPR, VV SET
12944 040454 000207 7$: RTS PC ;ALL OTHER BITS SHOULD BE 0
12945 ;RETURN TO TEST NO.

```

12946  
12947  
12948  
12949  
12950  
12951  
12952  
12953  
12954  
12955  
12956  
12957  
12958  
12959  
12960  
12961  
12962  
12963  
12964  
12965  
12966  
12967  
12968  
12969  
12970  
12971  
12972  
12973  
12974  
12975  
12976  
12977  
12978  
12979  
12980  
12981  
12982  
12983  
12984  
12985  
12986  
12987  
12988  
12989  
12990  
12991  
12992  
12993  
12994  
12995  
12996  
12997  
12998  
12999  
13000  
13001

040456 177777  
040460  
040460 010046  
040462 010346  
040464 016600 000004  
040470 010037 004666  
040474 162737 000002 004666  
040502 013037 004670  
040506 012037 004672  
040512 010066 000004  
040516 005737 004646  
040522 001025  
040524 013703 040456  
040530 033777 004672 144132 1\$:  
040536 001042  
040540 005303  
040542 001372  
040544 013703 040456  
040550 033777 004672 144112 2\$:  
040556 001032  
040560 005303  
040562 001372  
040564 017737 144100 001126  
040572 104135  
040574 000423  
040576 013703 040456 4\$:  
040602 012700 000020  
040606 033777 004672 144054 5\$:

; THIS IS A WAIT LOOP WHEN NO P-CLOCK IS AVAILABLE  
; NO TIMING IS DONE  
; CALL IS

WAT  
A ; POINTER TO REGISTER ADDRESS  
B ; BIT WAITED FOR  
; R3-IS A TEMPORARY COUNTER  
TIMCNT: 177777 ; COUNT FOR WAIT LOOP

WAIT.T:

MOV R0,-(SP) ; PUSH R0 ON STACK  
MOV R3,-(SP) ; PUSH R3 ON STACK  
MOV 4(SP),R0 ; R0 HAS ADDRESS OF NEXT LOCATION  
MOV R0,@WAITPC ; WAT PC +2 IS IN WAITPC  
SUB #2,@WAITPC ; WAT PC IS IN WAITPC  
MOV @R0+,@WAITRE ; WAIT ON REGISTER ADDRESS  
MOV (R0)+,@WAITBT ; WAIT ON BIT  
MOV R0,4(SP) ; RESTORE RETURN ON STACK

; THIS HAS THE TWO COUNT DOWNS FROM 177777  
; FOR WAITING FOR A BIT TO SET

TST WAT0 ; WAITING FOR 1?  
BNE 4\$ ; BRANCH IF WAITING FOR 0  
MOV @TIMCNT,R3 ; R3 HAS TEMPORARY COUNT  
BIT @WAITBT,@WAITRE ; IS REQUIRED BIT THERE  
BNE 3\$ ; BRANCH IF YES  
DEC R3 ; COUNT IF REQUIRED BIT NOT THERE  
BNE 1\$  
MOV @TIMCNT,R3 ; SECOND COUNT DOWN FROM 177777  
BIT @WAITBT,@WAITRE ; IS REQUIRED BIT THERE  
BNE 3\$ ; BRANCH IF YES  
DEC R3 ; COUNT IF REQUIRED BIT NOT THERE  
BNE 2\$

MOV @WAITRE,@\$BDDAT ; REGISTER CONTENTS FOR TYPEOUT  
ERROR 135 ; WAS WAITING FOR A BIT TO SET  
; BIT IN QUESTION IS IN "BIT WAITED"  
; REGISTER IN QUESTION IS IN "REG ADDR"  
BR 3\$ ; BRANCH OUT

; THIS HAS THE TWO COUNT DOWNS FROM 177777  
; FOR WAITING FOR A BIT TO RESET

MOV @TIMCNT,R3 ; R3 HAS TEMPORARY COUNT  
MOV #20,R0 ; R0 HAS TEMPORARY COUNT  
BIT @WAITBT,@WAITRE ; IS REQUIRED BIT RESET?

|       |        |        |        |        |       |                   |      |                                          |
|-------|--------|--------|--------|--------|-------|-------------------|------|------------------------------------------|
| 13002 | 040614 | 001413 |        |        | BEQ   | 3\$               |      | ; BRANCH IF YES                          |
| 13003 | 040616 | 005303 |        |        | DEC   | R3                |      | ; COUNT IF REQUIRED BIT HASN'T RESET YET |
| 13004 | 040620 | 001372 |        |        | BNE   | 5\$               |      | ; TRY AGAIN                              |
| 13005 | 040622 | 005300 |        |        | DEC   | R0                |      | ; DECREMENT R0 COUNT                     |
| 13006 | 040624 | 001370 |        |        | BNE   | 5\$               |      | ; START OVER IF COUNT ISN'T ZERO YET     |
| 13007 | 040626 | 017737 | 144036 | 001126 | MOV   | @WAITRE,@#\$BDDAT |      | ; REGISTER CONTENTS FOR TYPEOUT          |
| 13008 | 040634 | 104136 |        |        | ERROR | 136               |      | ; WAS WAITING FOR A BIT TO RESET         |
| 13009 |        |        |        |        |       |                   |      | ; BIT IN QUESTION IS IN "BIT WAITED"     |
| 13010 |        |        |        |        |       |                   |      | ; REGISTER IN QUESTION IS IN "REG ADDR"  |
| 13011 | 040636 | 017737 | 144026 | 001126 | MOV   | @WAITRE,@#\$BDDAT |      | ; REGISTER CONTENTS FOR TYPEOUT          |
| 13012 | 040644 |        |        |        |       |                   | 3\$: |                                          |
| 13013 | 040644 | 012603 |        |        | MOV   | (SP)+,R3          |      | ; POP STACK INTO R3                      |
| 13014 | 040646 | 012600 |        |        | MOV   | (SP)+,R0          |      | ; POP STACK INTO R0                      |
| 13015 | 040650 | 000002 |        |        | RTI   |                   |      | ; RETURN TO MAIN TEST                    |

```

13016
13017
13018
13019
13020
13021
13022
13023
13024
13025
13026
13027
13028
13029
13030
13031
13032
13033
13034
13035
13036
13037
13038 040652 000000
13039 040654
13040 040654 005037 177776
13041 040660 012737 177777 045100
13042 040666 104401 040674
13043 040672 000421
13044
13045 040736
13046 040736 013746 004656
13047 040742 104402
13048 040744 104401 040752
13049 040750 000414
13050
13051 041002
13052 041002 013746 001110
13053 041006 104402
13054 041010 104401 001223
13055 041014 104401 041022
13056 041020 000430
13057
13058 041102
13059 041102 104401 041110
13060 041106 000430
13061
13062 041170
13063 041170 104401 041176
13064 041174 000422
13065
13066 041242
13067 041242 104410
13068 041244 062716 000002
13069 041250 012637 001106
13070 041254 104401 041262
13071 041260 000417

```

```

;HERE IS A DETAILED EXPLANATION OF HOW THE LOOP ON ERROR WORKS.
;ON HITTING AN ERROR IF THE LOOP ON ERROR SWITCH IS SET, THE
;PROGRAM GOES BACK - USUALLY BACK TO THE BEGINNING OF THE TEST.

;WHEN THIS OPERATOR SELECTABLE SCOPE LOOP IS USED THEN THE POINT
;THE PROGRAM GOES BACK TO CAN BE CHANGED.
;THE RESTRICTIONS TO THE POINT WHERE THE PROGRAM CAN GO ARE: -
;1. IT MUST BE WITHIN THE TEST UNDER CONSIDERATION
;2. LOOP ON ERROR SWITCH MUST BE SET
;3. THE ERROR MUST OCCUR WITHIN THE TEST UNDER CONSIDERATION
;IF THE ERROR DOES NOT OCCUR WITHIN THE TEST UNDER CONSIDERATION
;THE PROGRAM WILL REVERT TO NORMAL OPERATION. HOWEVER, IF LOOP ON
;TEST SWITCH IS SET AND THIS OPERATOR SELECTABLE SCOPE LOOP IS USED
;THEN THE PROGRAM WILL LOOP BACK TO THE SELECTED POINT WHEN IT
;COMES TO THE END OF THE TEST UNDER CONSIDERATION.

;AFTER LOOPING FOR SOME TIME IF THE LOOP SWITCH IS PUT DOWN THEN
;NORMAL OPERATION WILL CONTINUE.

```

```

TESTAD: 0 ;FIRST ADDRESS OF TEST
OPERSEL:
CLR PS ;MAKE PROCESSOR STATUS ZERO
MOV #-1, @#PRITEM ;CLEAR PREVIOUS ITEM NUMBER
TYPE ,65$;:TYPE ASCIZ STRING
BR ,64$;:GET OVER THE ASCIZ
;;65$: .ASCIZ <15><12>/THE PROGRAM WAS IN TEST NUMBER /
64$:
MOV @#TSTNM, -(SP) ;GET READY TO TYPE TEST
TYPOC ;NUMBER
TYPE ,67$;:TYPE ASCIZ STRING
BR ,66$;:GET OVER THE ASCIZ
;;67$: .ASCIZ <15><12>/THE LOOP BACK PC WAS /
66$:
MOV @#$LPERR, -(SP) ;GET READY TO TYPE LOOP BACK PC
TYPOC
TYPE , $CRLF
TYPE ,69$;:TYPE ASCIZ STRING
BR ,68$;:GET OVER THE ASCIZ
;;69$: .ASCIZ <15><12>/SET SWITCH FOR LOOP ON ERROR OR LOOP ON TEST/
68$:
TYPE ,71$;:TYPE ASCIZ STRING
BR ,70$;:GET OVER THE ASCIZ
;;71$: .ASCIZ <15><12>/TYPE THE FIRST PC OF THE TEST TO BE LOOPED ON/
70$:
TYPE ,73$;:TYPE ASCIZ STRING
BR ,72$;:GET OVER THE ASCIZ
;;73$: .ASCIZ <15><12>/ FOLLOWED BY A CARRIAGE RETURN /<15><12>
72$:
RDOCT
ADD #2, (SP) ;GET LPADR
MOV (SP)+, @#$LPADR
TYPE ,75$;:TYPE ASCIZ STRING
BR ,74$;:GET OVER THE ASCIZ

```

```

13072 ::75$: .ASCIZ <15><12>/TYPE THE PC WHERE YOU WANT/
13073 041320 74$:
13074 041320 104401 041326 TYPE ,77$;;TYPE ASCIZ STRING
13075 041324 000440 BR 76$;;GET OVER THE ASCIZ
13076
13077 041426 76$: .ASCIZ <15><12>/ THE PROGRAM TO LOOP BACK TO FOLLOWED BY A CARRIAGE RETURN /<15
13078 041426 104410 RDOCT
13079 041430 012637 001110 MOV (SP)+, @#SLPERR ;GET LPERR
13080 041434 013746 001106 MOV @#SLPADR, -(SP)
13081 041440 000002 RTI

```

```

; THIS SAVES THE CONTENTS OF ALL HARDWARE REGISTERS
; IN MEMORY LOCATIONS TAGED FROM "WC" TO "EC2"
; THIS IS DONE SO THAT COMPARES ARE DONE WITH SAVED LOCATIONS
; AND NOT THE REGISTERS THEMSELVES. THIS WILL MAKE
; ERROR PRINTOUTS FOR GOOD AND BAD DATA ALWAYS DIFFRENT

```

```

13095 041442 010046 PUTREG:
13096 041442 010146 MOV R0, -(SP) ;; PUSH R0 ON STACK
13097 041444 010246 MOV R1, -(SP) ;; PUSH R1 ON STACK
13098 041446 012700 004062 MOV R2, -(SP) ;; PUSH R2 ON STACK
13099 041450 012701 000002 MOV #RHWC, R0 ;; STARTING ADDRESS OF REG
13100 041454 012702 000010 MOV #WC, R1 ;; STARTING ADDRESS OF WERE SAVED
13101 041460 013021 10$: MOV #RHCC-RHWC+2/2, R2 ;NUMBER OF REG. INTO R2
13102 041464 005302 MOV @ (R0)+, (R1)+ ;SAVE HARDWARE REG.
13103 041470 001375 DEC R2
13104 041472 012602 BNE 10$
13105 041474 012601 MOV (SP)+, R2 ;; POP STACK INTO R2
13106 041476 012600 MOV (SP)+, R1 ;; POP STACK INTO R1
13107 041500 000207 MOV (SP)+, R0 ;; POP STACK INTO R0
13108 RTS PC

```

13109  
 13110  
 13111  
 13112  
 13113  
 13114  
 13115  
 13116  
 13117  
 13118  
 13119  
 13120  
 13121  
 13122  
 13123  
 13124  
 13125  
 13126  
 13127  
 13128  
 13129  
 13130  
 13131  
 13132  
 13133  
 13134  
 13135  
 13136  
 13137  
 13138  
 13139  
 13140  
 13141  
 13142  
 13143  
 13144  
 13145  
 13146  
 13147  
 13148  
 13149  
 13150  
 13151  
 13152  
 13153  
 13154  
 13155  
 13156  
 13157  
 13158  
 13159  
 13160  
 13161  
 13162  
 13163  
 13164

.SBTTL RS DATA TRANSFER SUBROUTINE

```

 ;* THIS SUBROUTINE WRITES OR READS OR DOES A
 ;* WRITE CHECK ON CYLINDER 0 TRACK 0 SECTOR 0
 ;* IT ASSUMES THE RH REGISTERS ARE APPROPRIATELY
 ;* FILLED
 ;* WHEN IT RETURNS FROM THIS SUBROUTINE TO THE
 ;* MAIN PROGRAM IT MEANS THE TRANSFER IS COMPLETE
 ;*
 ;* THE CALL IS BY A JSR R0, @COMND COMAND
 CMNDRS: MOV (R0)+, COMAND ;GET COMMAND
 ;CHECK THAT RHDS1 HAS DRY!DPR!MOL
 MOV #DRY!DPR!MOL, $GDDAT ;GET GOOD = 10300
 MOV @RHDS1, $BDDAT ;READ RHDS1 FOR COMPARISON
 CMP $GDDAT, $BDDAT ;COMPARE EXPECTED
 ;DATA WITH DATA READ FROM
 ;RHDS1
 BEQ 65$;BRANCH IF GOOD
 ERROR 133 ;BEFORE ANY COMMAND IS GIVEN
 ;RHDS1 SHOULD HAVE DRY!DPR!MOL
 ;=10300
 ;BUT CONTAINED WHAT IS
 ;GIVEN IN BAD RHDS1
 65$:
 CLR @RHDA ;TRANSFER ON CYLINDER 0
 ;TRANSFER ON SECTOR 0
 ;TRACK 0
 MOV @COMAND, @RHCS1 ;SET UP COMMAND
 TST NOGO ;IS GO TO BE GIVEN
 BNE 1$;BRANCH IF NO
 BIS #GO, @RHCS1 ;SET GO
 ;WAIT FOR RDY BIT IN RHCS1 REGISTER TO SET
 WAT ;TRAP TO WAIT.T SUBROUTINE
 RHCS1 ;AND WAIT FOR RDY BIT IN
 RDY ;RHCS1 REGISTER
 ;IF ERROR OCCURS HERE
 ;IT MEANS "RDY" DID NOT
 ;SET FOR THE FULL COUNT
 ;DOWN OF THE WAIT.T SUBROUTINE
 ;THIS TIME IS APPROXIMATELY
 ;LARGER THAN 500 MILLISECONDS
 1$: RTS R0

```

.SBTTL RPO4 DATA TRANSFER SUBROUTINE

```

 ;* THIS SUBROUTINE WRITE/READ/WRITE CHECK ON THE RPO4 CYLINDER 0,
 ;* TRACK 0, SECTOR 0.
 ;* IT ASSUMES THE RH REGISTERS ARE APPROPRIATELY FILLED.
 ;* WHEN IT RETURNS FROM THIS SUBROUTINE TO THE MAIN

```



```

13165 ;* PROGRAM IT MEANS THE COMMAND IS COMPLETE
13166 ;*
13167 ;* THE CALL IS BY A JSR RD, @COMND COMMAND.
13168
13169 041572 012037 004642 CMNDRP: MOV (RD)+, COMAND ;GET COMMAND
13170
13171 041576 013746 004172 MOV PKACK, -(SP) ;GET READY TO SET VV
13172 041602 052716 000001 BIS #GO, (SP) ;GET PACK ACKNOWLEDGE COMMAND
13173 041606 012677 142246 MOV (SP)+, @RHCS1 ;SET VV
13174
13175 ;CHECK THAT RHDS1 HAS VV! DRY! DPR! MOL
13176 041612 012737 010700 001124 MOV #VV! DRY! DPR! MOL, $GDDAT ;GET GOOD = 10700
13177
13178 041620 017737 142246 001126 MOV @RHDS1, $BDDAT ;READ RHDS1 FOR COMPARISON
13179 041626 023737 001124 001126 CMP $GDDAT, $BDDAT ;COMPARE EXPECTED
13180 ;DATA WITH DATA READ FROM
13181 ;RHDS1
13182 041634 001401 BEQ 65$;BRANCH IF GOOD
13183 041636 104132 ERROR 132
13184 ;BEFORE ANY COMMAND IS GIVEN
13185 ;RHDS1 SHOULD HAVE VV! DRY! DPR! MOL
13186 ;=10700
13187 ;BUT CONTAINED WHAT IS
13188 ;GIVEN IN BAD RHDS1
13189 041640 65$:
13190
13191 041640 005077 142250 CLR @RHCA ;TRANSFER ON CYLINDER 0
13192 041644 005077 142216 CLR @RHDS1 ;TRANSFER ON SECTOR 0
13193 ;TRACK 0
13194 041650 012777 014000 142234 MOV #ECI! FMT22, @RHOF ;INHIBIT ECC
13195 ;FORMAT 16 BIT PER WORD
13196 041656 017777 142760 142174 MOV @COMAND, @RHCS1 ;SET UP COMMAND
13197 041664 005737 004644 TST NOGO ;IS GO TO BE GIVEN
13198 041670 001006 BNE 1$;BRANCH IF NO
13199 041672 052777 000001 142160 BIS #GO, @RHCS1 ;SET GO
13200
13201 ;WAIT FOR RDY BIT IN RHCS1 REGISTER TO SET
13202 041700 104411 WAT ;TRAP TO WAIT.T SUBROUTINE
13203 041702 004060 RHCS1 ;AND WAIT FOR RDY BIT IN
13204 041704 000200 RDY ;RHCS1 REGISTER
13205 ;IF ERROR OCCURS HERE
13206 ;IT MEANS "RDY" DID NOT
13207 ;SET FOR THE FULL COUNT
13208 ;DOWN OF THE WAIT.T SUBROUTINE
13209 ;THIS TIME IS APPROXIMATELY
13210 ;LARGER THAN 500 MILLISECONDS
13211 041706 000200 1$: RTS RD
13212
13213 .SBTTL TMO2 DATA TRANSFER SUBROUTINE
13214
13215 ;* THIS SUBROUTINE WRITES/READS/WRITE CHECKS ON THE TMO2-TU16
13216 ;* ON THE FIRST BLOCK FROM BEGINNING OF TAPE (BOT)
13217 ;* IT ASSUMES THE RH REGISTERS ARE APPROPRIATELY FILLED.
13218 ;* WHEN IT RETURNS FROM THIS SUBROUTINE TO THE
13219 ;* MAIN PROGRAM IT MEANS THE COMMAND IS COMPLETE.
13220 ;*

```

```

13221 ;* THE CALL IS
13222 ;* JSR RO, @COMND
13223
13224 041710 012037 004642 CMNDTM: MOV (RO)+, COMAND
13225 041714 013777 004660 142170 MOV SLAVE, @RHTC ; GET SLAVE NUMBER
13226 041722 012737 010600 001124 MOV #MOL!OPR!DRY, $GDDAT ; GET GOOD DATA
13227 041730 017737 142136 001126 MOV @RHDS1, $BDDAT ; GET RHDS1
13228 041736 042737 000062 001126 BIC #BOT!BIT05!BIT04, $BDDAT ; DISREGARD BOT
13229 041744 023737 001124 001126 CMP $GDDAT, $BDDAT ; COMPARE EXPECTED DATA WITH
13230 ; DATA READ FROM RHDS1
13231 041752 001401 BEQ 1$; BRANCH IF GOOD
13232 041754 104134 ERROR 134 ; BEFORE ANY COMMAND
13233 ; IS GIVEN DRIVE STATUS REGISTER
13234 ; DID NOT CONTAIN WHAT IS IN
13235 ; GOOD
13236 041756 032777 000002 142106 1$: BIT #BOT, @RHDS1 ; IS IT ALREADY AT BOT
13237 041764 001035 BNE 2$; BRANCH IF YES
13238 ; IF NOT AT BOT GIVE A REWIND COMMAND
13239 041766 013777 004176 142064 MOV REWIND, @RHCS1 ; LOAD RHCS1 WITH REWIND COMMAND
13240 041774 052777 000001 142056 BIS #GO, @RHCS1
13241 ; WAIT FOR PIP BIT IN RHDS1 REGISTER TO SET
13242 042002 104411 WAT ; TRAP TO WAIT.T SUBROUTINE
13243 042004 004072 RHDS1 ; AND WAIT FOR PIP BIT IN
13244 042006 020000 PIP ; RHDS1 REGISTER
13245 ; IF ERROR OCCURS HERE
13246 ; IT MEANS "PIP" DID NOT
13247 ; SET FOR THE FULL COUNT
13248 ; DOWN OF THE WAIT.T SUBROUTINE
13249 ; THIS TIME IS APPROXIMATELY
13250 ; LARGER THAN 500 MILLISECONDS
13251 ; WAIT FOR PIP BIT IN RHDS1 REGISTER TO SET
13252 042010 012737 177777 004646 MOV #-1, WATO ; WAIT FOR PIP TO GO FROM 1 TO 0
13253 042016 104411 WAT ; TRAP TO WAIT.T SUBROUTINE
13254 042020 004072 RHDS1 ; AND WAIT FOR PIP BIT IN
13255 042022 020000 PIP ; RHDS1 REGISTER
13256 ; IF ERROR OCCURS HERE
13257 ; IT MEANS "PIP" DID NOT
13258 ; SET FOR THE FULL COUNT
13259 ; DOWN OF THE WAIT.T SUBROUTINE
13260 ; THIS TIME IS APPROXIMATELY
13261 ; LARGER THAN 500 MILLISECONDS
13262 042024 005037 004646 CLR WATO
13263 ; WAIT FOR BOT BIT IN RHDS1 REGISTER TO SET
13264 042030 104411 WAT ; TRAP TO WAIT.T SUBROUTINE
13265 042032 004072 RHDS1 ; AND WAIT FOR BOT BIT IN
13266 042034 000002 BOT ; RHDS1 REGISTER
13267 ; IF ERROR OCCURS HERE
13268 ; IT MEANS "BOT" DID NOT
13269 ; SET FOR THE FULL COUNT
13270 ; DOWN OF THE WAIT.T SUBROUTINE
13271 ; THIS TIME IS APPROXIMATELY
13272 ; LARGER THAN 500 MILLISECONDS
13273
13274 ; CLEAR ATTENTIONS
13275 042036 013746 004142 MOV DCLEAR, -(SP)
13276 042042 052716 000001 BIS #GO, (SP)

```

```

13277 042046 012677 142006 MOV (SP)+, @RHCS1
13278
13279 ;WAIT FOR DRY BIT IN RHDS1 REGISTER TO SET
13280 042052 104411 WAT ;TRAP TO WAIT.T SUBROUTINE
13281 042054 004072 RHDS1 ;AND WAIT FOR DRY BIT IN
13282 042056 000200 DRY ;RHDS1 REGISTER
13283 ;IF ERROR OCCURS HERE
13284 ;IT MEANS "DRY" DID NOT
13285 ;SET FOR THE FULL COUNT
13286 ;DOWN OF THE WAIT.T SUBROUTINE
13287 ;THIS TIME IS APPROXIMATELY
13288 ;LARGER THAN 500 MILLISECONDS
13289 042060 2$: ;CHECK IF COMMAND IS REVERSE READ
13290 ;IF IT IS REVERSE READ, SPACE FORWARD ONE BLOCK
13291 042060 023777 004200 142554 CMP REVRED, @COMAND ;IS IT REVERSE READ
13292 042066 001035 BNE 3$;BRANCH IF NOT
13293 042070 052777 001700 142014 BIS #BPI@NML, @RHTC ;800 BPI, NORMAL
13294 042076 042777 000010 142006 BIC #EPAR, @RHTC ;ODD PARITY
13295
13296 042104 012777 177777 141754 MOV #-1, @RHFC ;FRAME COUNT 1
13297 ;FOR SPACE FORWARD ONE BLOCK
13298 042112 013777 004202 141740 MOV SPACFD, @RHCS1 ;SPACE FORWARD
13299 042120 052777 000001 141732 BIS #GO, @RHCS1 ;GO
13300 ;WAIT FOR PIP BIT IN RHDS1 REGISTER TO SET
13301 042126 104411 WAT ;TRAP TO WAIT.T SUBROUTINE
13302 042130 004072 RHDS1 ;AND WAIT FOR PIP BIT IN
13303 042132 020000 PIP ;RHDS1 REGISTER
13304 ;IF ERROR OCCURS HERE
13305 ;IT MEANS "PIP" DID NOT
13306 ;SET FOR THE FULL COUNT
13307 ;DOWN OF THE WAIT.T SUBROUTINE
13308 ;THIS TIME IS APPROXIMATELY
13309 ;LARGER THAN 500 MILLISECONDS
13310 ;WAIT FOR PIP BIT IN RHDS1 REGISTER TO SET
13311 042134 012737 177777 004646 MOV #-1, WATO ;WAIT FOR PIP TO GO FROM 1 TO 0
13312 042142 104411 WAT ;TRAP TO WAIT.T SUBROUTINE
13313 042144 004072 RHDS1 ;AND WAIT FOR PIP BIT IN
13314 042146 020000 PIP ;RHDS1 REGISTER
13315 ;IF ERROR OCCURS HERE
13316 ;IT MEANS "PIP" DID NOT
13317 ;SET FOR THE FULL COUNT
13318 ;DOWN OF THE WAIT.T SUBROUTINE
13319 ;THIS TIME IS APPROXIMATELY
13320 ;LARGER THAN 500 MILLISECONDS
13321 042150 005037 004646 CLR WATO
13322 ;WAIT FOR DRY BIT IN RHDS1 REGISTER TO SET
13323 042154 104411 WAT ;TRAP TO WAIT.T SUBROUTINE
13324 042156 004072 RHDS1 ;AND WAIT FOR DRY BIT IN
13325 042160 000200 DRY ;RHDS1 REGISTER
13326 ;IF ERROR OCCURS HERE
13327 ;IT MEANS "DRY" DID NOT
13328 ;SET FOR THE FULL COUNT
13329 ;DOWN OF THE WAIT.T SUBROUTINE
13330 ;THIS TIME IS APPROXIMATELY
13331 ;LARGER THAN 500 MILLISECONDS
13332 042162 3$: ;NOW GIVE COMMAND

```

|       |        |        |        |        |       |                  |                                            |
|-------|--------|--------|--------|--------|-------|------------------|--------------------------------------------|
| 13333 | 042162 | 052777 | 001700 | 141722 | BIS   | #BPIB!NML, @RHTC | ;800 BPI, NORMAL                           |
| 13334 | 042170 | 042777 | 000010 | 141714 | BIC   | #EPAR, @RHTC     | ;ODD PARITY                                |
| 13335 | 042176 | 017746 | 141660 |        | MOV   | @RHWC, -(SP)     | ;GET WORD COUNT                            |
| 13336 | 042202 | 005416 |        |        | NEG   | (SP)             | ;GET POSITIVE NUMBER                       |
| 13337 | 042204 | 061616 |        |        | ADD   | (SP), (SP)       | ;DOUBLE WORD COUNT                         |
| 13338 | 042206 | 005416 |        |        | NEG   | (SP)             | ;GET NEGATIVE NUMBER FOR                   |
| 13339 |        |        |        |        |       |                  | ;FRAME COUNT REGISTER                      |
| 13340 | 042210 | 012677 | 141652 |        | MOV   | (SP)+, @RHFC     | ;FILL FRAME COUNT                          |
| 13341 | 042214 | 017777 | 142422 | 141636 | MOV   | @COMAND, @RHCS1  | ;GET COMMAND                               |
| 13342 |        |        |        |        |       |                  |                                            |
| 13343 | 042222 | 005737 | 004644 |        | TST   | NOGO             | ;IS GO TO BE GIVEN                         |
| 13344 | 042226 | 001006 |        |        | BNE   | 4\$              | ;BRANCH IF NO                              |
| 13345 | 042230 | 052777 | 000001 | 141622 | BIS   | #GO, @RHCS1      | ;GO                                        |
| 13346 |        |        |        |        |       |                  |                                            |
| 13347 |        |        |        |        |       |                  | ;WAIT FOR DRY BIT IN RHDS1 REGISTER TO SET |
| 13348 | 042236 | 104411 |        |        | WAT   |                  | ;TRAP TO WAIT.T SUBROUTINE                 |
| 13349 | 042240 | 004072 |        |        | RHDS1 |                  | ;AND WAIT FOR DRY BIT IN                   |
| 13350 | 042242 | 000200 |        |        | DRY   |                  | ;RHDS1 REGISTER                            |
| 13351 |        |        |        |        |       |                  | ;IF ERROR OCCURS HERE                      |
| 13352 |        |        |        |        |       |                  | ;IT MEANS "DRY" DID NOT                    |
| 13353 |        |        |        |        |       |                  | ;SET FOR THE FULL COUNT                    |
| 13354 |        |        |        |        |       |                  | ;DOWN OF THE WAIT.T SUBROUTINE             |
| 13355 |        |        |        |        |       |                  | ;THIS TIME IS APPROXIMATELY                |
| 13356 |        |        |        |        |       |                  | ;LARGER THAN 500 MILLISECONDS              |
| 13357 | 042244 |        |        |        |       |                  |                                            |
| 13358 |        |        |        |        |       |                  |                                            |
| 13359 | 042244 | 104411 |        |        |       |                  |                                            |
| 13360 | 042246 | 004060 |        |        |       |                  |                                            |
| 13361 | 042250 | 000200 |        |        |       |                  |                                            |
| 13362 |        |        |        |        |       |                  |                                            |
| 13363 |        |        |        |        |       |                  |                                            |
| 13364 |        |        |        |        |       |                  |                                            |
| 13365 |        |        |        |        |       |                  |                                            |
| 13366 |        |        |        |        |       |                  |                                            |
| 13367 |        |        |        |        |       |                  |                                            |
| 13368 | 042252 | 000200 |        |        | RTS   | RO               |                                            |

4\$:

```

13369
13370
13371
13372
13373 042254
13374 042254 104401 042262
13375 042260 000424
13376
13377 042332
13378 042332 013746 004060
13379 042336 104402
13380 042340 104401 042346
13381 042344 000425
13382
13383 042420
13384 042420 104410
13385 042422 012700 004102
13386 042426 012701 000024
13387 042432 042710 177700
13388 042436 051620
13389 042440 005301
13390 042442 001373
13391 042444 104401 042452
13392 042450 000417
13393
13394 042510
13395 042510 013746 002716
13396 042514 104402
13397 042516 104401 042524
13398 042522 000437
13399
13400 042622
13401 042622 104410
13402 042624 012637 002716
13403 042630 104401 042636
13404 042634 000421
13405
13406 042700
13407 042700 104401 042706
13408 042704 000414
13409
13410 042736
13411 042736 013746 004060
13412 042742 104402
13413 042744 104401 042752
13414 042750 000415
13415
13416 043004
13417 043004 013746 002716
13418 043010 104402
13419 043012 104401 043020
13420 043016 000416
13421
13422 043054
13423 043054 000000
13424

```

```

;* THIS ROUTINE WILL ALLOW THE CHANGE OF THE BASE
;* ADDRESS FROM 176700 TO ANY TYPED VALUE
BASECH:
TYPE ,65$;;TYPE ASCIZ STRING
BR 64$;;GET OVER THE ASCIZ
;;65$: .ASCIZ <15><12>/PRESENT BASE ADDRESS OF REGISTERS IS /
64$:
MOV @#RHCS1,-(SP) ;GET READY TO TYPE OLD BASE
TYPOC
TYPE ,67$;;TYPE ASCIZ STRING
BR 66$;;GET OVER THE ASCIZ
;;67$: .ASCIZ <15><12>/TYPE NEW BASE ADDRESS FOLLOWED BY 'CR'/
66$:
RDOCT
MOV #RHDB,R0 ;GET STARTING ADDRESS OF RGISTERS
MOV #20,R1 ;NUMBER OF REGISTERS
1$: BIC #1C77,(R0) ;CLEAR OLD BASE
BIS (SP),(R0)+ ;SET NEW BASE
DEC R1 ;COUNT
BNE 1$;BRANCH IF 20 NOT DONE
TYPE ,69$;;TYPE ASCIZ STRING
BR 68$;;GET OVER THE ASCIZ
;;69$: .ASCIZ <15><12>/PRESENT VECTOR ADDRESS IS /
68$:
MOV @#RPVEC,-(SP) ;GET READY TO TYPE OLD VECTOR ADDRESS
TYPOC
TYPE ,71$;;TYPE ASCIZ STRING
BR 70$;;GET OVER THE ASCIZ
;;71$: .ASCIZ <15><12>/TYPE NEW VECTOR ADDRESS OR RETYPE OLD ONE FOLLOWED BY "CR"/
70$:
RDOCT
MOV (SP)+,@#RPVEC ;SETUP VECTOR ADDRESS
TYPE ,73$;;TYPE ASCIZ STRING
BR 72$;;GET OVER THE ASCIZ
;;73$: .ASCIZ <15><12>/RESTART PROGRAM FROM 200 OR 210/
72$:
TYPE ,75$;;TYPE ASCIZ STRING
BR 74$;;GET OVER THE ASCIZ
;;75$: .ASCIZ <15><12>/NEW BASE WILL REMAIN/
74$:
MOV @#RHCS1,-(SP)
TYPOC
TYPE ,77$;;TYPE ASCIZ STRING
BR 76$;;GET OVER THE ASCIZ
;;77$: .ASCIZ <15><12>/NEW VECTOR WILL REMAIN /
76$:
MOV @#RPVEC,-(SP)
TYPOC
TYPE ,79$;;TYPE ASCIZ STRING
BR 78$;;GET OVER THE ASCIZ
;;79$: .ASCIZ <15><12>/UNTIL PROGRAM IS RELOADED/
78$:
HALT

```

G04

|       |        |        |        |          |        |                 |    |                           |
|-------|--------|--------|--------|----------|--------|-----------------|----|---------------------------|
| 13425 | 043056 |        |        | RPVECT:  |        |                 |    |                           |
| 13426 | 043056 | 104401 | 043064 |          | TYPE   | .65\$           | :: | TYPE ASCIZ STRING         |
| 13427 | 043062 | 000411 |        |          | BR     | .64\$           | :: | GET OVER THE ASCIZ        |
| 13428 |        |        |        | ::.65\$: | .ASCIZ | /TRAPED FROM PC | =  | /                         |
| 13429 | 043106 |        |        | .64\$:   |        |                 |    |                           |
| 13430 | 043106 | 104402 |        |          | TYP0C  |                 |    | :TYPE FROM PC             |
| 13431 | 043110 | 012777 | 043056 | 137600   | MOV    | #RPVECT, JRPVEC |    | :RESTORE TRAP RPO4 VECTOR |
| 13432 | 043116 | 000000 |        |          | HALT   |                 |    | :CHANGE TO CONTINUE       |
| 13433 |        |        |        |          |        |                 |    |                           |
| 13434 |        |        |        |          |        |                 |    |                           |
| 13435 |        |        |        |          |        |                 |    |                           |
| 13436 |        |        |        |          |        |                 |    |                           |

\*\*\*\*\*

13437  
13438  
13439  
13440  
13441  
13442  
13443  
13444  
13445  
13446  
13447  
13448  
13449  
13450  
13451  
13452  
13453  
13454  
13455  
13456  
13457  
13458  
13459  
13460  
13461  
13462  
13463  
13464  
13465  
13466  
13467  
13468  
13469  
13470  
13471  
13472  
13473  
13474  
13475  
13476  
13477  
13478  
13479  
13480  
13481  
13482  
13483  
13484  
13485  
13486  
13487  
13488  
13489  
13490  
13491  
13492

043120  
043120 005037 004646  
043124 005037 004644  
043130 032777 040000 136002  
043136 001111  
043140 000416  
043142 013746 000004  
043146 012737 043166 000004  
043154 005737 177060  
043160 012637 000004  
043164 000463  
043166 022626  
043170 012637 000004  
043174 000423  
043176  
043176 032777 000400 135734  
043204 001404  
043206 127737 135726 001102  
043214 001462  
043216 105737 001103  
043222 001421  
043224 123737 001115 001103  
043232 101015  
043234 032777 001000 135676  
043242 001404  
043244 013737 001110 001106  
043252 000443  
043254 105037 001103  
043260 005037 001212  
043264 000415  
043266 032777 004000 135644  
043274 001011  
043276 005737 001100  
043302 001406  
043304 005237 001104  
043310 023737 001212 001104  
043316 002021  
043320 012737 000001 001104

.SBTTL SCOPE HANDLER ROUTINE

```

; THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
; AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
; AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
; THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
; *SW14=1 LOOP ON TEST
; *SW11=1 INHIBIT ITERATIONS
; *SW09=1 LOOP ON ERROR
; *SW08=1 LOOP ON TEST IN SWR<7:0>
; *CALL SCOPE ; SCOPE=IOT
; *
$SCOPE:
CLR WATO ; WAIT FOR BIT TO SET
; USED IN "WAT" WAIT ROUTINE
CLR NOGO ; DO GIVE GO IN COMMAND ROUTINE
1$: BIT #BIT14, $SWR ; LOOP ON PRESENT TEST?
BNE $OVER ; YES IF SW14=1
; *****START OF CODE FOR THE XOR TESTER*****
$XTSTR: BR 6$; IF RUNNING ON THE "XOR" TESTER CHANGE
; THIS INSTRUCTION TO A "NOP" (NOP=240)
MOV @#ERRVEC, -(SP) ; SAVE THE CONTENTS OF THE ERROR VECTOR
MOV #5, @#ERRVEC ; SET FOR TIMEOUT
TST @#177060 ; TIME OUT ON XOR?
MOV (SP)+, @#ERRVEC ; RESTORE THE ERROR VECTOR
BR $SVLAD ; GO TO THE NEXT TEST
5$: CMP (SP)+, (SP)+ ; CLEAR THE STACK AFTER A TIME OUT
MOV (SP)+, @#ERRVEC ; RESTORE THE ERROR VECTOR
BR 7$; LOOP ON THE PRESENT TEST
6$; *****END OF CODE FOR THE XOR TESTER*****
BIT #BIT08, $SWR ; LOOP ON SPEC. TEST?
BEQ 2$; BR IF NO
CMPB $SWR, $TSTNM ; ON THE RIGHT TEST? SWR<7:0>
BEQ $OVER ; BR IF YES
2$: TSTB $ERFLG ; HAS AN ERROR OCCURRED?
BEQ 3$; BR IF NO
CMPB $ERMAX, $ERFLG ; MAX. ERRORS FOR THIS TEST OCCURRED?
BHI 3$; BR IF NO
BIT #BIT09, $SWR ; LOOP ON ERROR?
BEQ 4$; BR IF NO
7$: MOV $LPERR, $LPADR ; SET LOOP ADDRESS TO LAST SCOPE
BR $OVER
4$: CLRB $ERFLG ; ZERO THE ERROR FLAG
CLR $TIMES ; CLEAR THE NUMBER OF ITERATIONS TO MAKE
BR 1$; ESCAPE TO THE NEXT TEST
3$: BIT #BIT11, $SWR ; INHIBIT ITERATIONS?
BNE 1$; BR IF YES
TST $PASS ; IF FIRST PASS OF PROGRAM
BEQ 1$; INHIBIT ITERATIONS
INC $ICNT ; INCREMENT ITERATION COUNT
CMP $TIMES, $ICNT ; CHECK THE NUMBER OF ITERATIONS MADE
BGE $OVER ; BR IF MORE ITERATION REQUIRED
1$: MOV #1, $ICNT ; REINITIALIZE THE ITERATION COUNTER
```

|       |        |        |        |        |          |      |                  |                                        |
|-------|--------|--------|--------|--------|----------|------|------------------|----------------------------------------|
| 13493 | 043326 | 013737 | 043376 | 001212 |          | MOV  | \$MXCNT,\$TIMES  | ::SET NUMBER OF ITERATIONS TO DO       |
| 13494 | 043334 | 105237 | 001102 |        | \$SVLAD: | INCB | \$STNM           | ::COUNT TEST NUMBERS                   |
| 13495 | 043340 | 011637 | 001106 |        |          | MOV  | (SP),\$LPADR     | ::SAVE SCOPE LOOP ADDRESS              |
| 13496 | 043344 | 011637 | 001110 |        |          | MOV  | (SP),\$LPERR     | ::SAVE ERROR LOOP ADDRESS              |
| 13497 | 043350 | 005037 | 001214 |        |          | CLR  | \$ESCAPE         | ::CLEAR THE ESCAPE FROM ERROR ADDRESS  |
| 13498 | 043354 | 112737 | 000001 | 001115 |          | MOVB | #1,\$ERMAX       | ::ONLY ALLOW ONE(1) ERROR ON NEXT TEST |
| 13499 | 043362 | 013777 | 001102 | 135552 | \$OVER:  | MOV  | \$STNM,\$DISPLAY | ::DISPLAY TEST NUMBER                  |
| 13500 | 043370 | 013716 | 001106 |        |          | MOV  | \$LPADR,(SP)     | ::FUDGE RETURN ADDRESS                 |
| 13501 | 043374 | 000002 |        |        |          | RTI  |                  | ::FIXES PS                             |
| 13502 | 043376 | 000004 |        |        | \$MXCNT: | 4    |                  | ::MAX. NUMBER OF ITERATIONS            |



```

13503 .SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
13504
13505 ;*****
13506 ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
13507 ;*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
13508 ;*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
13509 ;*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
13510 ;*REPLACED WITH SPACES.
13511 ;*CALL:
13512 ;* MOV NUM,-(SP) ;;PUT THE BINARY NUMBER ON THE STACK
13513 ;* TYPDS ;;GO TO THE ROUTINE
13514
13515 $TYPDS:
13516 043400 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
13517 043402 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
13518 043404 010246 MOV R2,-(SP) ;;PUSH R2 ON STACK
13519 043406 010346 MOV R3,-(SP) ;;PUSH R3 ON STACK
13520 043410 010546 MOV R5,-(SP) ;;PUSH R5 ON STACK
13521 043412 012746 020200 MOV #20200,-(SP) ;;SET BLANK SWITCH AND SIGN
13522 043416 016605 000020 MOV 20(SP),R5 ;;GET THE INPUT NUMBER
13523 043422 100004 BPL 1$;;BR IF INPUT IS POS.
13524 043424 005405 NEG R5 ;;MAKE THE BINARY NUMBER POS.
13525 043426 112766 000055 000001 MOVVB #'-,1(SP) ;;MAKE THE ASCII NUMBER NEG.
13526 043434 005000 CLR R0 ;;ZERO THE CONSTANTS INDEX
13527 043436 012703 043614 MOV #SDBLK,R3 ;;SETUP THE OUTPUT POINTER
13528 043442 112723 000040 MOVVB #' ,(R3)+ ;;SET THE FIRST CHARACTER TO A BLANK
13529 043446 005002 CLR R2 ;;CLEAR THE BCD NUMBER
13530 043450 016001 043604 MOV $DTBL(R0),R1 ;;GET THE CONSTANT
13531 043454 160105 SUB R1,R5 ;;FORM THIS BCD DIGIT
13532 043456 002402 BLT 4$;;BR IF DONE
13533 043460 005202 INC R2 ;;INCREASE THE BCD DIGIT BY 1
13534 043462 000774 BR 3$
13535 043464 060105 ADD R1,R5 ;;ADD BACK THE CONSTANT
13536 043466 005702 TST R2 ;;CHECK IF BCD DIGIT=0
13537 043470 001002 BNE 5$;;FALL THROUGH IF 0
13538 043472 105716 TSTB (SP) ;;STILL DOING LEADING 0'S?
13539 043474 100407 BMI 7$;;BR IF YES
13540 043476 106316 ASLB (SP) ;;MSD?
13541 043500 103003 BCC 6$;;BR IF NO
13542 043502 116663 000001 177777 MOVVB 1(SP),-1(R3) ;;YES--SET THE SIGN
13543 043510 052702 000060 BIS #'0,R2 ;;MAKE THE BCD DIGIT ASCII
13544 043514 052702 000040 BIS #' ,R2 ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
13545 043520 110223 MOVVB R2,(R3)+ ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
13546 043522 005720 TST (R0)+ ;;JUST INCREMENTING
13547 043524 020027 000010 CMP R0,#10 ;;CHECK THE TABLE INDEX
13548 043530 002746 BLT 2$;;GO DO THE NEXT DIGIT
13549 043532 003002 BGT 8$;;GO TO EXIT
13550 043534 010502 MOV R5,R2 ;;GET THE LSD
13551 043536 000764 BR 6$;;GO CHANGE TO ASCII
13552 043540 105726 TSTB (SP)+ ;;WAS THE LSD THE FIRST NON-ZERO?
13553 043542 100003 BPL 9$;;BR IF NO
13554 043544 116663 177777 177776 MOVVB -1(SP),-2(R3) ;;YES--SET THE SIGN FOR TYPING
13555 043552 105013 CLRB (R3) ;;SET THE TERMINATOR
13556 043554 012605 MOV (SP)+,R5 ;;POP STACK INTO R5
13557 043556 012603 MOV (SP)+,R3 ;;POP STACK INTO R3
13558 043560 012602 MOV (SP)+,R2 ;;POP STACK INTO R2

```

```

13559 043562 012601 MOV (SP)+,R1 ;; POP STACK INTO R1
13560 043564 012600 MOV (SP)+,RO ;; POP STACK INTO RO
13561 043566 104401 043614 TYPE $DBLK ;; NOW TYPE THE NUMBER
13562 043572 016666 000002 000004 MOV 2(SP),4(SP) ;; ADJUST THE STACK
13563 043600 012616 MOV (SP)+,(SP)
13564 043602 000002 RTI ;; RETURN TO USER
13565 043604 023420 $DTBL: 10000.
13566 043606 001750 1000.
13567 043610 000144 100.
13568 043612 000012 10.
13569 043614 000004 $DBLK: .BLKW 4
13570 .SBTTL TYPE ROUTINE
13571
13572 ;*****
13573 ;*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
13574 ;*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
13575 ;*NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
13576 ;*NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
13577 ;*NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
13578 ;*
13579 ;*CALL:
13580 ;*1) USING A TRAP INSTRUCTION
13581 ;* TYPE ,MESADR ;; MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
13582 ;*OR
13583 ;* TYPE
13584 ;* MESADR
13585 ;*
13586
13587 043624 105737 001157 $TYPE: TSTB $TFPLG ;; IS THERE A TERMINAL?
13588 043630 100002 BPL 1$;; BR IF YES
13589 043632 000000 HALT ;; HALT HERE IF NO TERMINAL
13590 043634 000407 BR 3$;; LEAVE
13591 043636 010046 1$: MOV RO,-(SP) ;; SAVE RO
13592 043640 017600 000002 MOV 2(SP),RO ;; GET ADDRESS OF ASCIZ STRING
13593 043644 112046 2$: MOV (RO)+,-(SP) ;; PUSH CHARACTER TO BE TYPED ONTO STACK
13594 043646 001005 BNE 4$;; BR IF IT ISN'T THE TERMINATOR
13595 043650 005726 TST (SP)+ ;; IF TERMINATOR POP IT OFF THE STACK
13596 043652 012600 60$: MOV (SP)+,RO ;; RESTORE RO
13597 043654 062716 000002 3$: ADD #2,(SP) ;; ADJUST RETURN PC
13598 043660 000002 RTI ;; RETURN
13599 043662 122716 000011 4$: CMP #HT,(SP) ;; BRANCH IF <HT>
13600 043666 001430 BEQ 8$;; BRANCH IF NOT <CRLF>
13601 043670 122716 000200 CMP #CRLF,(SP)
13602 043674 001006 BNE 5$;; POP <CR><LF> EQUIV
13603 043676 005726 TST (SP)+ ;; TYPE A CR AND LF
13604 043700 104401 TYPE
13605 043702 001223 $CRLF
13606 043704 105037 044040 CLRB $CHARCNT ;; CLEAR CHARACTER COUNT
13607 043710 000755 BR 2$;; GET NEXT CHARACTER
13608 043712 004737 043774 5$: JSR PC,$TYPEC ;; GO TYPE THIS CHARACTER
13609 043716 123726 001156 6$: CMP $FILLC,(SP)+ ;; IS IT TIME FOR FILLER CHARS.?
13610 043722 001350 BNE 2$;; IF NO GO GET NEXT CHAR.
13611 043724 013746 001154 MOV $NULL,-(SP) ;; GET # OF FILLER CHARS. NEEDED
13612 AND THE NULL CHAR.
13613 043730 105366 000001 7$: DECB 1(SP) ;; DOES A NULL NEED TO BE TYPED?
13614 043734 002770 BLT 6$;; BR IF NO--GO POP THE NULL OFF OF STACK

```

```

13615 043736 004737 043774 JSR PC,$TYPEC ;;GO TYPE A NULL
13616 043742 105337 044040 DECB $CHARCNT ;;DO NOT COUNT AS A COUNT
13617 043746 000770 BR 7$;;LOOP
13618
13619 ;HORIZONTAL TAB PROCESSOR
13620
13621 043750 112716 000040 8$: MOVB #' (SP) ;;REPLACE TAB WITH SPACE
13622 043754 004737 043774 9$: JSR PC,$TYPEC ;;TYPE A SPACE
13623 043760 132737 000007 044040 BITB #7,$CHARCNT ;;BRANCH IF NOT AT
13624 043766 001372 BNE 9$;;TAB STOP
13625 043770 005726 TST (SP)+ ;;POP SPACE OFF STACK
13626 043772 000724 BR 2$;;GET NEXT CHARACTER
13627 043774 105777 135150 $TYPEC: TSTB @STPS ;;WAIT UNTIL PRINTER IS READY
13628 044000 100375 BPL $TYPEC
13629 044002 116677 000002 135142 MOVB 2(SP),@STPB ;;LOAD CHAR TO BE TYPED INTO DATA REG.
13630 044010 122766 000015 000002 CMPB #CR,2(SP) ;;IS CHARACTER A CARRIAGE RETURN?
13631 044016 001003 BNE 1$;;BRANCH IF NO
13632 044020 105037 044040 CLRB $CHARCNT ;;YES--CLEAR CHARACTER COUNT
13633 044024 000406 BR $TYPEX ;;EXIT
13634 044026 122766 000012 000002 1$: CMPB #LF,2(SP) ;;IS CHARACTER A LINE FEED?
13635 044034 001402 BEQ $TYPEX ;;BRANCH IF YES
13636 044036 105227 INCB (PC)+ ;;COUNT THE CHARACTER
13637 044040 000000 $CHARCNT: .WORD 0 ;;CHARACTER COUNT STORAGE
13638 044042 000207 $TYPEX: RTS PC
13639
13640 .SBTTL TTY INPUT ROUTINE
13641
13642 ;*****
13643 ;ENABL LSB
13644 044044 000000 $TKCNT: .WORD 0 ;;NUMBER OF ITEMS IN QUEUE
13645 044046 000000 $TKQIN: .WORD 0 ;;INPUT POINTER
13646 044050 000000 $TKQOUT: .WORD 0 ;;OUTPUT POINTER
13647 044052 000011 $TKQSRT: .BLKB 9. ;;TTY KEYBOARD QUEUE
13648 044063 $TKQEND=.
13649 044064 .EVEN
13650
13651 ;*TK INITIALIZE ROUTINE
13652 ;*THIS ROUTINE WILL INITIALIZE THE TTY KEYBOARD INPUT QUEUE
13653 ;*SETUP THE INTERRUPT VECTOR AND TURN ON THE KEYBOARD INTERRUPT
13654
13655 ;*CALL:
13656 ;* JSR PC,$TKINT
13657 ;* RETURN
13658
13659 044064 005037 044044 $TKINT: CLR $TKCNT ;;CLEAR COUNT OF ITEMS IN QUEUE
13660 044070 012737 044052 044046 MOV #TKQSRT,$TKQIN ;;MOVE THE STARTING ADDRESS OF THE
13661 044076 013737 044046 044050 MOV $TKQIN,$TKQOUT ;;QUEUE INTO THE INPUT & OUTPUT POINTERS.
13662 044104 012737 044134 000060 MOV #TKSRV,@TKVEC ;;INITIALIZE THE KEYBOARD VECTOR
13663 044112 012737 000200 000062 MOV #200,@TKVEC+2 ;;"BR" LEVEL 4
13664 044120 005777 135022 TST @TKB ;;CLEAR DONE FLAG
13665 044124 012777 000100 135012 MOV #100,@STKS ;;ENABLE TTY KEYBOARD INTERRUPT
13666 044132 000207 RTS PC ;;RETURN TO CALLER
13667
13668 ;*TK SERVICE ROUTINE
13669 ;*THIS ROUTINE WILL SERVICE THE TTY KEYBOARD INTERRUPT
13670 ;*BY READING THE CHARACTER FROM THE INPUT BUFFER AND PUTTING

```

```

13671 ;*IT IN THE QUEUE.
13672 ;*IF THE CHARACTER IS A "CONTROL-C" (↑C) $TKINT IS CALLED AND
13673 ;*UPON RETURN EXIT IS MADE TO THE "CONTROL-C" RESTART ADDRESS (OPERSEL)
13674
13675 044134 117746 135006 $TKSRV: MOVB @STKB,-(SP) ;; PICKUP THE CHARACTER
13676 044140 042716 177600 BIC #↑C177,(SP) ;; STRIP THE JUNK
13677 044144 021627 000003 CMP (SP),#3 ;; IS IT A CONTROL C?
13678 044150 001007 BNE 1$;; BRANCH IF NO
13679 044152 104401 044543 TYPE ,SCNTLC ;; TYPE A CONTROL-C (↑C)
13680 044156 004737 044064 JSR PC,$TKINT ;; INIT THE KEYBOARD
13681 044162 005726 TST (SP)+ ;; CLEAN UP STACK
13682 044164 000137 040654 JMP OPERSEL ;; CONTROL C RESTART
13683
13684 044170 1$:
13685 044170 022737 000011 044044 CMP #9,,$TKCNT ;; IS THE QUEUE FULL?
13686 044176 001004 BNE 3$;; BRANCH IF NO
13687 044200 104401 001216 TYPE ,SBELL ;; RING THE TTY BELL
13688 044204 005726 TST (SP)+ ;; CLEAN CHARACTER OFF OF STACK
13689 044206 000451 BR 5$;; EXIT
13690 044210 021627 000023 3$: CMP (SP),#23 ;; IS IT A CONTROL-S?
13691 044214 001021 BNE 32$;; BRANCH IF NO
13692 044216 005077 134722 CLR @STKS ;; DISABLE TTY KEYBOARD INTERRUPTS
13693 044222 005726 TST (SP)+ ;; CLEAN CHAR OFF STACK
13694 044224 105777 134714 31$: TSTB @STKS ;; WAIT FOR A CHAR
13695 044230 100375 BPL 31$;; LOOP UNTIL ITS THERE
13696 044232 117746 134710 MOVB @STKB,-(SP) ;; GET THE CHARACTER
13697 044236 042716 177600 BIC #↑C177,(SP) ;; MAKE IT 7-BIT ASCII
13698 044242 022627 000021 CMP (SP)+,#21 ;; IS IT A CONTROL-Q?
13699 044246 001366 BNE 31$;; BRANCH IF NO
13700 044250 012777 000100 134666 MOV #100,@STKS ;; REENABLE TTY KEYBOARD INTERRUPTS
13701 044256 000002 RTI ;; RETURN
13702 044260 005237 044044 32$: INC $TKCNT ;; COUNT THIS CHARACTER
13703 044264 021627 000140 CMP (SP),#140 ;; IS IT UPPER CASE?
13704 044270 002405 BLT 4$;; BRANCH IF YES
13705 044272 021627 000175 CMP (SP),#175 ;; IS IT A SPECIAL CHAR?
13706 044276 003002 BGT 4$;; BRANCH IF YES
13707 044300 042716 000040 BIC #40,(SP) ;; MAKE IT UPPER CASE
13708 044304 112677 177536 4$: MOVB (SP)+,@STKQIN ;; AND PUT IT IN QUEUE
13709 044310 005237 044046 INC $TKQIN ;; UPDATE THE POINTER
13710 044314 023727 044046 044063 CMP $TKQIN,$STKQEND ;; GO OFF THE END?
13711 044322 001003 BNE 5$;; BRANCH IF NO
13712 044324 012737 044052 044046 MOV #$STKQSRST,$TKQIN ;; RESET THE POINTER
13713 044332 000002 5$: RTI ;; RETURN
13714
13715 .DSABL LSB
13716
13717
13718 ;*****
13719 ;THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
13720 ;CALL:
13721 ;
13722 ; RDCHR ;; GET A CHARACTER FROM THE QUEUE
13723 ; RETURN HERE ;; CHARACTER IS ON THE STACK
13724 ; ;; WITH PARITY BIT STRIPPED OFF
13725
13726 044334 011646 $RDCHR: MOV (SP),-(SP) ;; PUSH DOWN THE PC AND

```

```

13727 044336 016666 000004 000002 MOV 4(SP),2(SP) ;; THE PS
13728 044344 005066 000004 CLR 4(SP) ;; GET READY FOR A CHARACTER
13729 044350 005046 CLR -(SP) ;; PUT NEW PS ON STACK
13730 044352 012746 044360 MOV #64$,-(SP) ;; PUT NEW PC ON STACK
13731 044356 000002 RTI ;; POP NEW PC AND PS
13732 044360 64$:
13733 044360 005737 044044 1$: TST $TKCNT ;; WAIT ON A CHARACTER
13734 044364 001775 BEQ 1$;;
13735 044366 005337 044044 DEC $TKCNT ;; DECREMENT THE COUNTER
13736 044372 117766 177452 000004 MOV 2($TKQOUT,4(SP) ;; GET ONE CHARACTER
13737 044400 005237 044050 INC $TKQOUT ;; UPDATE THE POINTER
13738 044404 023727 044050 044063 CMP $TKQOUT,#$TKQEND ;; DID IT GO OFF OF THE END?
13739 044412 001003 BNE 2$;; BRANCH IF NO
13740 044414 012737 044052 044050 MOV #$TKQSRT,$TKQOUT ;; RESET THE POINTER
13741 044422 000002 RTI ;; RETURN
13742 *****
13743 ;*THIS ROUTINE WILL INPUT A STRING FROM THE TTY
13744 ;*CALL:
13745 ;* RDLIN ;; INPUT A STRING FROM THE TTY
13746 ;* RETURN HERE ;; ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
13747 ;* ;; TERMINATOR WILL BE A BYTE OF ALL 0'S
13748
13749 044424 010346 $RDLIN: MOV R3,-(SP) ;; SAVE R3
13750 044426 012703 044532 1$: MOV #$TTYIN,R3 ;; GET ADDRESS
13751 044432 022703 044543 2$: CMP #$TTYIN+9.,R3 ;; BUFFER FULL?
13752 044436 101405 BLOS 4$;; BR IF YES
13753 044440 104406 RDCHR ;; GO READ ONE CHARACTER FROM THE TTY
13754 044442 112613 MOV (SP)+,(R3) ;; GET CHARACTER
13755 044444 122713 000177 10$: CMP #177,(R3) ;; IS IT A RUBOUT
13756 044450 001003 BNE 3$;; SKIP IF NOT
13757 044452 104401 001222 4$: TYPE $QUES ;; TYPE A '?'
13758 044456 000763 BR 1$;; CLEAR THE BUFFER AND LOOP
13759 044460 111337 044530 3$: MOV (R3),9$;; ECHO THE CHARACTER
13760 044464 104401 044530 TYPE 9$
13761 044470 122723 000015 CMP #15,(R3)+ ;; CHECK FOR RETURN
13762 044474 001356 BNE 2$;; LOOP IF NOT RETURN
13763 044476 105063 177777 CLRB -1(R3) ;; CLEAR RETURN (THE 15)
13764 044502 104401 001224 TYPE $LF ;; TYPE A LINE FEED
13765 044506 012603 MOV (SP)+,R3 ;; RESTORE R3
13766 044510 011646 MOV (SP),-(SP) ;; ADJUST THE STACK AND PUT ADDRESS OF THE
13767 044512 016666 000004 000002 MOV 4(SP),2(SP) ;; FIRST ASCII CHARACTER ON IT
13768 044520 012766 044532 000004 MOV #$TTYIN,4(SP)
13769 044526 000002 RTI ;; RETURN
13770 044530 000 9$: .BYTE 0 ;; STORAGE FOR ASCII CHAR. TO TYPE
13771 044531 000 .BYTE 0 ;; TERMINATOR
13772 044532 000011 $TTYIN: .BLKB 9. ;; RESERVE 9. BYTES FOR TTY INPUT
13773 044543 136 006503 000012 $CNTLC: .ASCIZ /tC/<15><12> ;; CONTROL "C"
13774 044550 052536 005015 000 $CNTLU: .ASCIZ /tU/<15><12> ;; CONTROL "U"
13775 044555 136 006507 000012 $CNTLG: .ASCIZ /tG/<15><12> ;; CONTROL "G"
13776 044562 005015 053523 020122 $MSWR: .ASCIZ <15><12>/SWR = /
13777 044570 020075 000
13778 044573 040 047040 053505 $MNEW: .ASCIZ / NEW = /
13779 044600 036440 000040
13780
13781
13782

```

;FROM THE TTY

```

13783
13784
13785
13786
13787
13788
13789
13790
13791
13792
13793
13794
13795
13796
13797
13798 044604 011646
13799 044606 016666 000004 000002
13800 044614 010046
13801 044616 010146
13802 044620 010246
13803 044622 104407
13804 044624 012600
13805 044626 010037 044732
13806 044632 005001
13807 044634 005002
13808 044636 112046
13809 044640 001420
13810 044642 122716 000060
13811 044646 003026
13812 044650 122716 000067
13813 044654 002423
13814 044656 006301
13815 044660 006102
13816 044662 006301
13817 044664 006102
13818 044666 006301
13819 044670 006102
13820 044672 042716 177770
13821 044676 062601
13822 044700 000756
13823 044702 005726
13824 044704 010166 000012
13825 044710 010237 044742
13826 044714 012602
13827 044716 012601
13828 044720 012600
13829 044722 000002
13830 044724 005726
13831 044726 105010
13832 044730 104401
13833 044732 000000
13834 044734 104401 001222
13835 044740 000730
13836 044742 000000

```

.SBTTL READ AN OCTAL NUMBER FROM THE TTY

```

; THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
; CHANGE IT TO BINARY.
; THE INPUT CHARACTERS WILL BE CHECKED TO INSURED THEY ARE LEGAL
; OCTAL DIGITS. IF AN ILLEGAL CHARACTER IS READ A "?" WILL BE TYPED
; FOLLOWED BY A CARRIAGE RETURN-LINE FEED. THE COMPLETE NUMBER MUST
; THEN BE RETYPED. THE INPUT IS TERMINATED BY TYPING A CARRIAGE RETURN.
; CALL:
; * RDOCT ; READ AN OCTAL NUMBER
; * RETURN HERE ; LOW ORDER BITS ARE ON TOP OF THE STACK
; * ; HIGH ORDER BITS ARE IN $HIOCT

```

```

$RDOCT: MOV (SP), -(SP) ; PROVIDE SPACE FOR THE
MOV 4(SP), 2(SP) ; INPUT NUMBER
MOV RO, -(SP) ; PUSH RO ON STACK
MOV R1, -(SP) ; PUSH R1 ON STACK
MOV R2, -(SP) ; PUSH R2 ON STACK
1$: RDLIN ; READ AN ASCII LINE
MOV (SP)+, RO ; GET ADDRESS OF 1ST CHARACTER
MOV RO, 5$; AND SAVE IT
CLR R1 ; CLEAR DATA WORD
CLR R2
2$: MOVB (RO)+, -(SP) ; PICKUP THIS CHARACTER
BEQ 3$; IF ZERO GET OUT
CMPB #'0, (SP) ; MAKE SURE THIS CHARACTER
BGT 4$; IS AN OCTAL DIGIT
CMPB #'7, (SP)
BLT 4$
ASL R1 ; *2
ROL R2 ; *4
ASL R1 ; *8
ROL R2
BIC #'C7, (SP) ; STRIP THE ASCII JUNK
ADD (SP)+, R1 ; ADD IN THIS DIGIT
BR 2$; LOOP
3$: TST (SP)+ ; CLEAN TERMINATOR FROM STACK
MOV R1, 12(SP) ; SAVE THE RESULT
MOV R2, $HIOCT
MOV (SP)+, R2 ; POP STACK INTO R2
MOV (SP)+, R1 ; POP STACK INTO R1
MOV (SP)+, RO ; POP STACK INTO RO
RTI ; RETURN
4$: TST (SP)+ ; CLEAN PARTIAL FROM STACK
CLRB (RO) ; SET A TERMINATOR
TYPE ; TYPE UP THRU THE BAD CHAR.
5$: .WORD 0 ; "?" "CR" & "LF"
TYPE $QUES ; TRY AGAIN
BR 1$; HIGH ORDER BITS GO HERE
$HIOCT: .WORD 0

```

```

13837
13838
13839
13840
13841
13842
13843
13844
13845
13846
13847
13848
13849
13850
13851 044744
13852 044744 105237 001103
13853 044750 001775
13854 044752 013777 001102 134162
13855 044760 032777 002000 134152
13856 044766 001402
13857 044770 104401 001216
13858 044774 005237 001112
13859 045000 011637 001116
13860 045004 162737 000002 001116
13861 045012 117737 134100 001114
13862 045020 032777 020000 134112
13863 045026 001004
13864 045030 004737 045102
13865 045034 104401 001223
13866 045040
13867 045040 005777 134074
13868 045044 100001
13869 045046 000000
13870 045050 032777 001000 134062
13871 045056 001402
13872 045060 013716 001110
13873 045064 005737 001214
13874 045070 001402
13875 045072 013716 001214
13876 045076
13877 045076 000002
13878
13879
13880
13881
13882
13883
13884
13885
13886
13887
13888
13889
13890 045100 000000
13891 045102 013746 001140
13892 045106 042716 177277

```

.SBTTL ERROR HANDLER ROUTINE

```

;*****
;THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
;SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
;AND GO TO $ERRTYP ON ERROR
;THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
;SW15=1 HALT ON ERROR
;SW13=1 INHIBIT ERROR TYPEOUTS
;SW10=1 BELL ON ERROR
;SW09=1 LOOP ON ERROR
;CALL
;* ERROR N ;;ERROR=EMT AND N=ERROR ITEM NUMBER

```

```

$ERROR:
7$: INCB $ERFLG ;;SET THE ERROR FLAG
 BEQ 7$;;DON'T LET THE FLAG GO TO ZERO
 MOV $STNM,$DISPLAY ;;DISPLAY TEST NUMBER AND ERROR FLAG
 BIT #BIT10,$SWR ;;BELL ON ERROR?
 BEQ 1$;;NO - SKIP
 TYPE $BELL ;;RING BELL
1$: INC $ERTTL ;;COUNT THE NUMBER OF ERRORS
 MOV (SP),$ERRPC ;;GET ADDRESS OF ERROR INSTRUCTION
 SUB #2,$ERRPC
 MOVB @($ERRPC,$ITEMB) ;;STRIP AND SAVE THE ERROR ITEM CODE
 BIT #BIT13,$SWR ;;SKIP TYPEOUT IF SET
 BNE 20$;;SKIP TYPEOUTS
 JSR PC,$ERRTYP ;;GO TO USER ERROR ROUTINE
 TYPE , $CRLF
20$:
2$: TST @SWR ;;HALT ON ERROR
 BPL 3$;;SKIP IF CONTINUE
 HALT ;;HALT ON ERROR!
3$: BIT #BIT09,$SWR ;;LOOP ON ERROR SWITCH SET?
 BEQ 4$;;BR IF NO
 MOV $LPERR,(SP) ;;FUDGE RETURN FOR LOOPING
4$: TST $ESCAPE ;;CHECK FOR AN ESCAPE ADDRESS
 BEQ 5$;;BR IF NONE
 MOV $ESCAPE,(SP) ;;FUDGE RETURN ADDRESS FOR ESCAPE
5$:
 RTI ;;RETURN
;*****

```

.SBTTL ERROR MESSAGE TYPEOUT ROUTINE

```

;THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE WHICH
;ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" ($ERRTB),
;AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.
;IT IS A COPY OF THE $ERRTYP SUBROUTINE FROM SYSMAC.
;WITH ONLY MINOR CHANGES
;FIRST IF SWITCH 6 IS SET AND SWITCH 8 RESET THEN
;ALL REGISTER CONTENTS WILL BE TYPED BEFOR REPORTING THE ERROR
;SECOND IF THE CURRENT ERROR HAS THE SAME ITEM NUMBER
;AS THE PREVIOUS ERROR THEN ONLY THE DATA WILL BE TYPED
;AND NOT THE ERROR MESSAGE AND HEADER.
PRITEM: 0 ;PREVIOUS ITEM NO. LOCATION
$ERRTYP: MOV @SWR,-(SP) ;GET SWITCH SETTING
 BIC #1C500,(SP) ;KEEP ONLY SWITCH 8 AND 6

```

```

13893 045112 022726 000100 CMP #SW06,(SP)+ ;IS 6 SET AND 8 RESET
13894 045116 001001 BNE 1$;IF NOT BRANCH
13895 045120 000402 BR 2$;BRANCH IF SW 6 IS SET AND 8 RESET
13896 045122 000137 046022 1$: JMP @#TYPERR ;JUMP IF SW 8 IS SET
13897 ;OR IF SW 8 IS RESET AND SW 6 IS RESET
13898 045126 104401 000200 2$: TYPE ,CRLF
13899
13900 045132 104401 045140 TYPE ,65$;;TYPE ASCIZ STRING
13901 045136 000405 BR 64$;;GET OVER THE ASCIZ
13902 ;;65$: .ASCIZ / RHWC= /
13903 64$:
13904 045152 017746 136704 MOV @RHWC,-(SP) ;GET READY TO TYPE RHWC CONTENTS
13905 045156 104402 TYPOC
13906
13907
13908 045160 104401 045166 TYPE ,67$;;TYPE ASCIZ STRING
13909 045164 000405 BR 66$;;GET OVER THE ASCIZ
13910 ;;67$: .ASCIZ / RHBA= /
13911 66$:
13912 045200 017746 136660 MOV @RHBA,-(SP) ;GET READY TO TYPE RHBA CONTENTS
13913 045204 104402 TYPOC
13914
13915
13916 045206 104401 045214 TYPE ,69$;;TYPE ASCIZ STRING
13917 045212 000406 BR 68$;;GET OVER THE ASCIZ
13918 ;;69$: .ASCIZ / RHCS2= /
13919 68$:
13920 045230 017746 136634 MOV @RHCS2,-(SP) ;GET READY TO TYPE RHCS2 CONTENTS
13921 045234 104402 TYPOC
13922
13923
13924 045236 104401 045244 TYPE ,71$;;TYPE ASCIZ STRING
13925 045242 000406 BR 70$;;GET OVER THE ASCIZ
13926 ;;71$: .ASCIZ / RHCS1= /
13927 70$:
13928 045260 017746 136574 MOV @RHCS1,-(SP) ;GET READY TO TYPE RHCS1 CONTENTS
13929 045264 104402 TYPOC
13930
13931
13932 045266 104401 045274 TYPE ,73$;;TYPE ASCIZ STRING
13933 045272 000406 BR 72$;;GET OVER THE ASCIZ
13934 ;;73$: .ASCIZ / RHDS1= /
13935 72$:
13936 045310 017746 136556 MOV @RHDS1,-(SP) ;GET READY TO TYPE RHDS1 CONTENTS
13937 045314 104402 TYPOC
13938
13939
13940 045316 104401 045324 TYPE ,75$;;TYPE ASCIZ STRING
13941 045322 000406 BR 74$;;GET OVER THE ASCIZ
13942 ;;75$: .ASCIZ / RHER1= /
13943 74$:
13944 045340 017746 136530 MOV @RHER1,-(SP) ;GET READY TO TYPE RHER1 CONTENTS
13945 045344 104402 TYPOC
13946
13947
13948 045346 104401 045354 TYPE ,77$;;TYPE ASCIZ STRING

```



|       |        |        |        |         |              |            |                                   |
|-------|--------|--------|--------|---------|--------------|------------|-----------------------------------|
| 13949 | 045352 | 000406 |        | BR      | 76\$         |            | ;;GET OVER THE ASCIZ              |
| 13950 |        |        |        | ;;77\$: | .ASCIZ       | / RHER2= / |                                   |
| 13951 | 045370 |        |        | 76\$:   |              |            |                                   |
| 13952 | 045370 | 017746 | 136524 | MOV     | QRHER2,-(SP) |            | ;GET READY TO TYPE RHER2 CONTENTS |
| 13953 | 045374 | 104402 |        | TYPOC   |              |            |                                   |
| 13954 |        |        |        |         |              |            |                                   |
| 13955 |        |        |        |         |              |            |                                   |
| 13956 | 045376 | 104401 | 045404 | TYPE    | 79\$         |            | ;;TYPE ASCIZ STRING               |
| 13957 | 045402 | 000406 |        | BR      | 78\$         |            | ;;GET OVER THE ASCIZ              |
| 13958 |        |        |        | ;;79\$: | .ASCIZ       | / RHER3= / |                                   |
| 13959 | 045420 |        |        | 78\$:   |              |            |                                   |
| 13960 | 045420 | 017746 | 136476 | MOV     | QRHER3,-(SP) |            | ;GET READY TO TYPE RHER3 CONTENTS |
| 13961 | 045424 | 104402 |        | TYPOC   |              |            |                                   |
| 13962 |        |        |        |         |              |            |                                   |
| 13963 |        |        |        |         |              |            |                                   |
| 13964 | 045426 | 104401 | 045434 | TYPE    | 81\$         |            | ;;TYPE ASCIZ STRING               |
| 13965 | 045432 | 000406 |        | BR      | 80\$         |            | ;;GET OVER THE ASCIZ              |
| 13966 |        |        |        | ;;81\$: | .ASCIZ       | / RHDST= / |                                   |
| 13967 | 045450 |        |        | 80\$:   |              |            |                                   |
| 13968 | 045450 | 017746 | 136412 | MOV     | QRHDST,-(SP) |            | ;GET READY TO TYPE RHDST CONTENTS |
| 13969 | 045454 | 104402 |        | TYPOC   |              |            |                                   |
| 13970 |        |        |        |         |              |            |                                   |
| 13971 |        |        |        |         |              |            |                                   |
| 13972 | 045456 | 104401 | 045464 | TYPE    | 83\$         |            | ;;TYPE ASCIZ STRING               |
| 13973 | 045462 | 000405 |        | BR      | 82\$         |            | ;;GET OVER THE ASCIZ              |
| 13974 |        |        |        | ;;83\$: | .ASCIZ       | / RHCA= /  |                                   |
| 13975 | 045476 |        |        | 82\$:   |              |            |                                   |
| 13976 | 045476 | 017746 | 136412 | MOV     | QRHCA,-(SP)  |            | ;GET READY TO TYPE RHCA CONTENTS  |
| 13977 | 045502 | 104402 |        | TYPOC   |              |            |                                   |
| 13978 |        |        |        |         |              |            |                                   |
| 13979 |        |        |        |         |              |            |                                   |
| 13980 | 045504 | 104401 | 045512 | TYPE    | 85\$         |            | ;;TYPE ASCIZ STRING               |
| 13981 | 045510 | 000405 |        | BR      | 84\$         |            | ;;GET OVER THE ASCIZ              |
| 13982 |        |        |        | ;;85\$: | .ASCIZ       | / RHAS= /  |                                   |
| 13983 | 045524 |        |        | 84\$:   |              |            |                                   |
| 13984 | 045524 | 017746 | 136346 | MOV     | QRHAS,-(SP)  |            | ;GET READY TO TYPE RHAS CONTENTS  |
| 13985 | 045530 | 104402 |        | TYPOC   |              |            |                                   |
| 13986 |        |        |        |         |              |            |                                   |
| 13987 |        |        |        |         |              |            |                                   |
| 13988 | 045532 | 104401 | 045540 | TYPE    | 87\$         |            | ;;TYPE ASCIZ STRING               |
| 13989 | 045536 | 000405 |        | BR      | 86\$         |            | ;;GET OVER THE ASCIZ              |
| 13990 |        |        |        | ;;87\$: | .ASCIZ       | / RHOF= /  |                                   |
| 13991 | 045552 |        |        | 86\$:   |              |            |                                   |
| 13992 | 045552 | 017746 | 136334 | MOV     | QRHOF,-(SP)  |            | ;GET READY TO TYPE RHOF CONTENTS  |
| 13993 | 045556 | 104402 |        | TYPOC   |              |            |                                   |
| 13994 |        |        |        |         |              |            |                                   |
| 13995 |        |        |        |         |              |            |                                   |
| 13996 | 045560 | 104401 | 045566 | TYPE    | 89\$         |            | ;;TYPE ASCIZ STRING               |
| 13997 | 045564 | 000405 |        | BR      | 88\$         |            | ;;GET OVER THE ASCIZ              |
| 13998 |        |        |        | ;;89\$: | .ASCIZ       | / RHMR= /  |                                   |
| 13999 | 045600 |        |        | 88\$:   |              |            |                                   |
| 14000 | 045600 | 017746 | 136300 | MOV     | QRHMR,-(SP)  |            | ;GET READY TO TYPE RHMR CONTENTS  |
| 14001 | 045604 | 104402 |        | TYPOC   |              |            |                                   |
| 14002 |        |        |        |         |              |            |                                   |
| 14003 |        |        |        |         |              |            |                                   |
| 14004 | 045606 | 104401 | 045614 | TYPE    | 91\$         |            | ;;TYPE ASCIZ STRING               |



```

14061 046044 104402 TYPOC ;GO TYPE--OCTAL ASCII(ALL DIGITS)
14062 046046 000454 BR 10$;GET OUT
14063 046050 005300 1$: DEC RO ;ADJUST THE INDEX SO THAT IT WILL
14064 046052 006300 ASL RO ; WORK FOR THE ERROR TABLE
14065 046054 006300 ASL RO
14066 046056 006300 ASL RO
14067 046060 062700 001226 ADD #SERRTB,RO ;FORM TABLE POINTER
14068 046064 020037 045100 CMP RO,2#PRITEM ;WAS PREVIOUS ERROR SAME
14069 046070 001002 BNE 13$;BRANCH IF NOT
14070 046072 022020 CMP (RO)+,(RO)+ ;POP RO OVER EM AND DH
14071 046074 000420 BR 5$
14072 046076 010037 045100 13$: MOV RO,2#PRITEM ;SAVE NEW ERROR ITEM
14073 046102 012037 046112 MOV (RO)+,2$;PICKUP "ERROR MESSAGE" POINTER
14074 046106 001404 BEQ 3$;SKIP TYPEOUT IF NO POINTER
14075 046110 104401 TYPE ;TYPE THE "ERROR MESSAGE"
14076 046112 000000 .WORD 0 ;"ERROR MESSAGE" POINTER GOES HERE
14077 046114 104401 001223 TYPE , $CRLF ;"CARRIAGE RETURN" & "LINE FEED"
14078 046120 012037 046130 3$: MOV (RO)+,4$;PICKUP "DATA HEADER" POINTER
14079 046124 001404 BEQ 5$;SKIP TYPEOUT IF 0
14080 046126 104401 TYPE ;TYPE THE "DATA HEADER"
14081 046130 000000 .WORD 0 ;"DATA HEADER" POINTER GOES HERE
14082 046132 104401 001223 TYPE , $CRLF ;"CARRIAGE RETURN" & "LINE FEED"
14083 046136 010146 5$: MOV R1,-(SP) ;SAVE R1
14084 046140 012001 MOV (RO)+,R1 ;PICKUP "DATA TABLE" POINTER
14085 046142 001415 BEQ 9$;BR IF NO DATA TO BE TYPED
14086 046144 012000 MOV (RO)+,RO ;PICKUP "DATA FORMAT" POINTER
14087 046146 105720 6$: TSTB (RO)+ ;"OCTAL" OR "DECIMAL"
14088 046150 001003 BNE 7$;BR IF DECIMAL
14089 046152 013146 MOV 2(R1)+,-(SP) ;SAVE 2(R1)+ FOR TYPEOUT
14090 046154 104402 TYPOC ;GO TYPE--OCTAL ASCII(ALL DIGITS)
14091 046156 000402 BR 8$
14092 046160 7$:
14093 046160 013146 MOV 2(R1)+,-(SP) ;SAVE 2(R1)+ FOR TYPEOUT
14094 046162 104405 TYPDS ;GO TYPE--DECIMAL ASCII WITH SIGN
14095 046164 005711 8$: TST (R1) ;IS THERE ANOTHER NUMBER?
14096 046166 001403 BEQ 9$;BR IF NO
14097 046170 104401 046216 TYPE ,11$;TYPE TWO(2) SPACES
14098 046174 000764 BR 6$;LOOP
14099
14100 046176 012601 9$: MOV (SP)+,R1 ;RESTORE R1
14101 046200 012600 10$: MOV (SP)+,RO ;"CARRIAGE RETURN" & "LINE FEED"
14102 046202 023737 000042 000046 CMP 2#42,2#46 ;ARE WE IN QV OR AUTO ACCEPT MODE?
14103 046210 001001 BNE .+4 ;BRANCH OVER HALT IF NOT
14104 046212 000000 HALT ;HALT AFTER ERROR MESSAGE
14105 046214 000207 RTS PC ;RETURN
14106 046216 020040 000 11$: .ASCIZ / / ;TWO(2) SPACES
14107 .EVEN
14108 ;*****
14109 ;*****
14110 .SBTTL BINARY TO OCTAL (ASCII) AND TYPE
14111
14112 ;*****
14113 ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
14114 ;*OCTAL (ASCII) NUMBER AND TYPE IT.
14115 ;*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
14116 ;*CALL:

```

```

14117 * MOV NUM,-(SP) ;;NUMBER TO BE TYPED
14118 * TYPON ;;CALL FOR TYPEOUT
14119 * .BYTE N ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
14120 * .BYTE M ;;M=1 OR 0
14121 * ;;1=TYPE LEADING ZEROS
14122 * ;;0=SUPPRESS LEADING ZEROS
14123 *
14124 *$TYPON----ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
14125 *$TYPON OR $TYPON
14126 *CALL:
14127 * MOV NUM,-(SP) ;;NUMBER TO BE TYPED
14128 * TYPON ;;CALL FOR TYPEOUT
14129 *
14130 *$TYPON----ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
14131 *CALL:
14132 * MOV NUM,-(SP) ;;NUMBER TO BE TYPED
14133 * TYPON ;;CALL FOR TYPEOUT
14134 *
14135 046222 017646 000000 $TYPON: MOV 2(SP),-(SP) ;;PICKUP THE MODE
14136 046226 116637 000001 046445 MOVVB 1(SP),$OFILL ;;LOAD ZERO FILL SWITCH
14137 046234 112637 046447 MOVVB (SP)+,$SOMODE+1 ;;NUMBER OF DIGITS TO TYPE
14138 046240 062716 000002 ADD #2,(SP) ;;ADJUST RETURN ADDRESS
14139 046244 000406 BR $TYPON
14140 046246 112737 000001 046445 $TYPON: MOVVB #1,$OFILL ;;SET THE ZERO FILL SWITCH
14141 046254 112737 000006 046447 MOVVB #6,$SOMODE+1 ;;SET FOR SIX(6) DIGITS
14142 046262 112737 000005 046444 $TYPON: MOVVB #5,$OCNT ;;SET THE ITERATION COUNT
14143 046270 010346 MOV R3,-(SP) ;;SAVE R3
14144 046272 010446 MOV R4,-(SP) ;;SAVE R4
14145 046274 010546 MOV R5,-(SP) ;;SAVE R5
14146 046276 113704 046447 MOVVB $SOMODE+1,R4 ;;GET THE NUMBER OF DIGITS TO TYPE
14147 046302 005404 NEG R4
14148 046304 062704 000006 ADD #6,R4 ;;SUBTRACT IT FOR MAX. ALLOWED
14149 046310 110437 046446 MOVVB R4,$SOMODE ;;SAVE IT FOR USE
14150 046314 113704 046445 MOVVB $OFILL,R4 ;;GET THE ZERO FILL SWITCH
14151 046320 016605 000012 MOV 12(SP),R5 ;;PICKUP THE INPUT NUMBER
14152 046324 005003 CLR R3 ;;CLEAR THE OUTPUT WORD
14153 046326 006105 1$: ROL R5 ;;ROTATE MSB INTO "C"
14154 046330 000404 BR 3$;;GO DO MSB
14155 046332 006105 2$: ROL R5 ;;FORM THIS DIGIT
14156 046334 006105 ROL R5
14157 046336 006105 ROL R5
14158 046340 010503 MOV R5,R3
14159 046342 006103 3$: ROL R3 ;;GET LSB OF THIS DIGIT
14160 046344 105337 046446 DECB $SOMODE ;;TYPE THIS DIGIT?
14161 046350 100016 BPL 7$;;BR IF NO
14162 046352 042703 177770 BIC #177770,R3 ;;GET RID OF JUNK
14163 046356 001002 BNE 4$;;TEST FOR 0
14164 046360 005704 TST R4 ;;SUPPRESS THIS 0?
14165 046362 001403 BEQ 5$;;BR IF YES
14166 046364 005204 4$: INC R4 ;;DON'T SUPPRESS ANYMORE 0'S
14167 046366 052703 000060 BIS #'0,R3 ;;MAKE THIS DIGIT ASCII
14168 046372 052703 000040 5$: BIS #' ,R3 ;;MAKE ASCII IF NOT ALREADY
14169 046376 110337 046442 MOVVB R3,8$;;SAVE FOR TYPING
14170 046402 104401 046442 TYPE 8$;;GO TYPE THIS DIGIT
14171 046406 105337 046444 7$: DECB $OCNT ;;COUNT BY 1
14172 046412 003347 BGT 2$;;BR IF MORE TO DO

```

|       |        |        |               |       |             |                                   |
|-------|--------|--------|---------------|-------|-------------|-----------------------------------|
| 14173 | 046414 | 002402 |               | BLT   | 6\$         | ::BR IF DONE                      |
| 14174 | 046416 | 005204 |               | INC   | R4          | ::INSURE LAST DIGIT ISN'T A BLANK |
| 14175 | 046420 | 000744 |               | BR    | 2\$         | ::GO DO THE LAST DIGIT            |
| 14176 | 046422 | 012605 | 6\$:          | MOV   | (SP)+,R5    | ::RESTORE R5                      |
| 14177 | 046424 | 012604 |               | MOV   | (SP)+,R4    | ::RESTORE R4                      |
| 14178 | 046426 | 012603 |               | MOV   | (SP)+,R3    | ::RESTORE R3                      |
| 14179 | 046430 | 016666 | 000002 000004 | MOV   | 2(SP),4(SP) | ::SET THE STACK FOR RETURNING     |
| 14180 | 046436 | 012616 |               | MOV   | (SP)+,(SP)  |                                   |
| 14181 | 046440 | 000002 |               | RTI   |             | ::RETURN                          |
| 14182 | 046442 | 000    | 8\$:          | .BYTE | 0           | ::STORAGE FOR ASCII DIGIT         |
| 14183 | 046443 | 000    |               | .BYTE | 0           | ::TERMINATOR FOR TYPE ROUTINE     |
| 14184 | 046444 | 000    | \$OCNT:       | .BYTE | 0           | ::OCTAL DIGIT COUNTER             |
| 14185 | 046445 | 000    | \$OFILL:      | .BYTE | 0           | ::ZERO FILL SWITCH                |
| 14186 | 046446 | 000000 | \$OMODE:      | .WORD | 0           | ::NUMBER OF DIGITS TO TYPE        |

14197  
14188  
14189  
14190  
14191  
14192  
14193  
14194  
14195  
14196  
14197  
14198  
14199  
14200  
14201  
14202  
14203  
14204  
14205  
14206  
14207  
14208  
14209  
14210  
14211  
14212  
14213  
14214  
14215  
14216  
14217  
14218  
14219  
14220  
14221  
14222  
14223  
14224  
14225  
14226  
14227  
14228  
14229  
14230  
14231

.SBTTL TRAP DECODER

\*\*\*\*\*  
\*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION  
\*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS  
\*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL  
\*GO TO THAT ROUTINE.

```
$TRAP: MOV RO, -(SP) ;; SAVE RO
 MOV 2(SP), RO ;; GET TRAP ADDRESS
 TST -(RO) ;; BACKUP BY 2
 MOVB (RO), RO ;; GET RIGHT BYTE OF TRAP
 ASL RO ;; POSITION FOR INDEXING
 MOV $TRPAD(RO), RO ;; INDEX TO TABLE
 RTS RO ;; GO TO ROUTINE
```

;; THIS IS USE TO HANDLE THE "GETPRI" MACRO

```
$TRAP2: MOV (SP), -(SP) ;; MOVE THE PC DOWN
 MOV 4(SP), 2(SP) ;; MOVE THE PSW DOWN
 RTI ;; RESTORE THE PSW
```

.SBTTL TRAP TABLE

\*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED  
\*BY THE "TRAP" INSTRUCTION.

|          | ROUTINE |               |                                                       |
|----------|---------|---------------|-------------------------------------------------------|
| \$TRPAD: | WORD    | \$TRAP2       |                                                       |
|          | \$TYPE  | ;; CALL=TYPE  | TRAP+1(104401) TTY TYPEOUT ROUTINE                    |
|          | \$TYPOC | ;; CALL=TYPOC | TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS) |
|          | \$TYPOS | ;; CALL=TYPOS | TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)   |
|          | \$TYPON | ;; CALL=TYPON | TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)   |
|          | \$TYPDS | ;; CALL=TYPDS | TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)        |
|          | \$RDCHR | ;; CALL=RDCHR | TRAP+6(104406) TTY TYPEIN CHARACTER ROUTINE           |
|          | \$RDLIN | ;; CALL=RDLIN | TRAP+7(104407) TTY TYPEIN STRING ROUTINE              |
|          | \$RDOCT | ;; CALL=RDOCT | TRAP+10(104410) READ AN OCTAL NUMBER FROM TTY         |
|          | WAIT.T  | ;; CALL=WAT   | TRAP+11(104411) DONT ADD ABOVE THIS TRAP              |

```

14232 .SBTTL POWER DOWN AND UP ROUTINES
14233
14234 ;;*****
14235 :POWER DOWN ROUTINE
14236 046530 012737 046674 000024 $PWRDN: MOV $SILLUP, @#PWRVEC ;;SET FOR FAST UP
14237 046536 012737 000340 000026 MOV #340, @#PWRVEC+2 ;;PRIO:7
14238 046544 010046 MOV R0, -(SP) ;;PUSH R0 ON STACK
14239 046546 010146 MOV R1, -(SP) ;;PUSH R1 ON STACK
14240 046550 010246 MOV R2, -(SP) ;;PUSH R2 ON STACK
14241 046552 010346 MOV R3, -(SP) ;;PUSH R3 ON STACK
14242 046554 010446 MOV R4, -(SP) ;;PUSH R4 ON STACK
14243 046556 010546 MOV R5, -(SP) ;;PUSH R5 ON STACK
14244 046560 017746 132354 MOV @SWR, -(SP) ;;PUSH @SWR ON STACK
14245 046564 010637 046700 MOV SP, $SAVR6 ;;SAVE SP
14246 046570 012737 046602 000024 MOV $PWRUP, @#PWRVEC ;;SET UP VECTOR
14247 046576 000000 HALT
14248 046600 000776 BR .-2 ;;HANG UP
14249
14250 ;;*****
14251 :POWER UP ROUTINE
14252 046602 012737 046674 000024 $PWRUP: MOV $SILLUP, @#PWRVEC ;;SET FOR FAST DOWN
14253 046610 013706 046700 MOV $SAVR6, SP ;;GET SP
14254 046614 005037 046700 CLR $SAVR6 ;;WAIT LOOP FOR THE TTY
14255 046620 005237 046700 1$: INC $SAVR6 ;;WAIT FOR THE INC
14256 046624 001375 BNE 1$;;OF WORD
14257 046626 012677 132306 MOV (SP)+, @SWR ;;POP STACK INTO @SWR
14258 046632 012605 MOV (SP)+, R5 ;;POP STACK INTO R5
14259 046634 012604 MOV (SP)+, R4 ;;POP STACK INTO R4
14260 046636 012603 MOV (SP)+, R3 ;;POP STACK INTO R3
14261 046640 012602 MOV (SP)+, R2 ;;POP STACK INTO R2
14262 046642 012601 MOV (SP)+, R1 ;;POP STACK INTO R1
14263 046644 012600 MOV (SP)+, R0 ;;POP STACK INTO R0
14264 046646 012737 046530 000024 MOV $PWRDN, @#PWRVEC ;;SET UP THE POWER DOWN VECTOR
14265 046654 012737 000340 000026 MOV #340, @#PWRVEC+2 ;;PRIO:7
14266 046662 104401 TYPE ;;REPORT THE POWER FAILURE
14267 046664 046702 $PWRMG: .WORD $POWER ;;POWER FAIL MESSAGE POINTER
14268 046666 012716 MOV (PC)+, (SP) ;;RESTART AT BEGIN
14269 046670 005522 $PWRAD: .WORD BEGIN ;;RESTART ADDRESS
14270 046672 000002 RTI
14271 046674 000000 $SILLUP: HALT ;;THE POWER UP SEQUENCE WAS STARTED
14272 046676 000776 BR .-2 ;;BEFORE THE POWER DOWN WAS COMPLETE
14273 046700 000000 $SAVR6: 0 ;;PUT THE SP HERE
14274 046702 005015 047520 042527 $POWER: .ASCIZ <15><12>"POWER"
14275 046710 000122
14276 .EVEN

```

```

14277
14278
14279
14280
14281
14282
14283 046712 044124 020105 044122
14284 046720 041040 051501 020105
14285 046726 042101 051104 051505
14286 046734 020123 040527 020123
14287 046742 033461 030062 030064
14288 046750 044440 042116 041511
14289 046756 052101 047111 020107
14290 046764 047101 051040 020123
14291 046772 052502 020124 044124
14292 047000 020105 051104 053111
14293 047006 020105 054524 042520
14294 047014 005015
14295 047016 044504 020104 047516
14296 047024 020124 047503 052116
14297 047032 044501 020116 020060
14298 047040 051117 030440 047440
14299 047046 020122 020062 051117
14300 047054 031440 047440 020122
14301 047062 000064
14302
14303 047064 044124 020105 044122
14304 047072 041040 051501 020105
14305 047100 042101 051104 051505
14306 047106 020123 040527 020123
14307 047114 033461 033466 030060
14308 047122 044440 042116 041511
14309 047130 052101 047111 020107
14310 047136 047101 051040 030120
14311 047144 026064 026065 020066
14312 047152 052502 020124 044124
14313 047160 020105 051104 053111
14314 047166 020105 054524 042520
14315 047174 005015
14316 047176 044504 020104 047516
14317 047204 020124 047503 052116
14318 047212 044501 020116 031062
14319 047220 031060 026060 032062
14320 047226 031060 026060 030062
14321 047234 031060 026061 032062
14322 047242 031060 026061 030062
14323 047250 031060 026062 047440
14324 047256 020122 032062 031060
14325 047264 000062
14326
14327 047266 044124 020105 044122
14328 047274 041040 051501 020105
14329 047302 042101 051104 051505
14330 047310 020123 040527 020123
14331 047316 033461 032062 030064
14332 047324 044440 042116 041511

```

```

:*****
:ERROR AND MESSAGE TABLE CONDIMENTS
:*****

```

EM1: .ASCII /THE RH BASE ADDRESS WAS 172040 INDICATING AN RS BUT THE DRIVE TYPE/<15>

.ASCIZ /DID NOT CONTAIN 0 OR 1 OR 2 OR 3 OR 4/

EM2: .ASCII /THE RH BASE ADDRESS WAS 176700 INDICATING AN RPO4,5,6 BUT THE DRIVE TYP

.ASCIZ /DID NOT CONTAIN 20020,24020,20021,24021,20022, OR 24022/

EM3: .ASCII /THE RH BASE ADDRESS WAS 172440 INDICATING A TMO2 BUT THE DRIVE TYPE/<15>



|       |        |        |        |        |                                                                                      |
|-------|--------|--------|--------|--------|--------------------------------------------------------------------------------------|
| 14333 | 047332 | 052101 | 047111 | 020107 |                                                                                      |
| 14334 | 047340 | 020101 | 046524 | 031060 |                                                                                      |
| 14335 | 047346 | 041040 | 052125 | 052040 |                                                                                      |
| 14336 | 047354 | 042510 | 042040 | 044522 |                                                                                      |
| 14337 | 047362 | 042526 | 052040 | 050131 |                                                                                      |
| 14338 | 047370 | 006505 | 012    |        |                                                                                      |
| 14339 | 047373 | 104    | 042111 | 047040 | .ASCIZ /DID NOT CONTAIN 142010/                                                      |
| 14340 | 047400 | 052117 | 041440 | 047117 |                                                                                      |
| 14341 | 047406 | 040524 | 047111 | 030440 |                                                                                      |
| 14342 | 047414 | 031064 | 030460 | 000060 |                                                                                      |
| 14343 |        |        |        |        |                                                                                      |
| 14344 | 047422 | 044124 | 020105 | 044122 | EM4: .ASCII /THE RH BASE ADDRESS WAS 176300 INDICATING MORE THAN ONE RH DEVICE BUT/  |
| 14345 | 047430 | 041040 | 051501 | 020105 |                                                                                      |
| 14346 | 047436 | 042101 | 051104 | 051505 |                                                                                      |
| 14347 | 047444 | 020123 | 040527 | 020123 |                                                                                      |
| 14348 | 047452 | 033461 | 031466 | 030060 |                                                                                      |
| 14349 | 047460 | 044440 | 042116 | 041511 |                                                                                      |
| 14350 | 047466 | 052101 | 047111 | 020107 |                                                                                      |
| 14351 | 047474 | 047515 | 042522 | 052040 |                                                                                      |
| 14352 | 047502 | 040510 | 020116 | 047117 |                                                                                      |
| 14353 | 047510 | 020105 | 044122 | 042040 |                                                                                      |
| 14354 | 047516 | 053105 | 041511 | 020105 |                                                                                      |
| 14355 | 047524 | 052502 | 006524 | 012    |                                                                                      |
| 14356 | 047531 | 124    | 042510 | 042040 | .ASCII /THE DRIVE TYPE DID NOT CONTAIN 0,1,2,3,4,20020,24020,/<15><12>               |
| 14357 | 047536 | 044522 | 042526 | 052040 |                                                                                      |
| 14358 | 047544 | 050131 | 020105 | 044504 |                                                                                      |
| 14359 | 047552 | 020104 | 047516 | 020124 |                                                                                      |
| 14360 | 047560 | 047503 | 052116 | 044501 |                                                                                      |
| 14361 | 047566 | 020116 | 026060 | 026061 |                                                                                      |
| 14362 | 047574 | 026062 | 026063 | 026064 |                                                                                      |
| 14363 | 047602 | 030062 | 031060 | 026060 |                                                                                      |
| 14364 | 047610 | 032062 | 031060 | 026060 |                                                                                      |
| 14365 | 047616 | 005015 |        |        |                                                                                      |
| 14366 | 047620 | 030062 | 031060 | 026061 | .ASCIZ /20021,24021,20022,24022,142010/<15><12>                                      |
| 14367 | 047626 | 032062 | 031060 | 026061 |                                                                                      |
| 14368 | 047634 | 030062 | 031060 | 026062 |                                                                                      |
| 14369 | 047642 | 032062 | 031060 | 026062 |                                                                                      |
| 14370 | 047650 | 032061 | 030062 | 030061 |                                                                                      |
| 14371 | 047656 | 005015 | 000    |        |                                                                                      |
| 14372 | 047661 | 111    | 042116 | 041511 | .ASCIZ /INDICATING NO RH DEVICE PRESENT/                                             |
| 14373 | 047666 | 052101 | 047111 | 020107 |                                                                                      |
| 14374 | 047674 | 047516 | 051040 | 020110 |                                                                                      |
| 14375 | 047702 | 042504 | 044526 | 042503 |                                                                                      |
| 14376 | 047710 | 050040 | 042522 | 042523 |                                                                                      |
| 14377 | 047716 | 052116 | 000    |        |                                                                                      |
| 14378 |        |        |        |        |                                                                                      |
| 14379 | 047721 | 124    | 042510 | 052440 | EMS: .ASCII /THE UNIBUS TIMED OUT FOR EACH OF THE FOLLOWING ADDRESSES, INDICATING/<1 |
| 14380 | 047726 | 044516 | 052502 | 020123 |                                                                                      |
| 14381 | 047734 | 044524 | 042515 | 020104 |                                                                                      |
| 14382 | 047742 | 052517 | 020124 | 047506 |                                                                                      |
| 14383 | 047750 | 020122 | 040505 | 044103 |                                                                                      |
| 14384 | 047756 | 047440 | 020106 | 044124 |                                                                                      |
| 14385 | 047764 | 020105 | 047506 | 046114 |                                                                                      |
| 14386 | 047772 | 053517 | 047111 | 020107 |                                                                                      |
| 14387 | 050000 | 042101 | 051104 | 051505 |                                                                                      |
| 14388 | 050006 | 042523 | 026123 | 044440 |                                                                                      |

|       |        |        |        |        |                                                                                    |
|-------|--------|--------|--------|--------|------------------------------------------------------------------------------------|
| 14389 | 050014 | 042116 | 041511 | 052101 |                                                                                    |
| 14390 | 050022 | 047111 | 006507 | 012    |                                                                                    |
| 14391 | 050027 | 116    | 020117 | 044122 | .ASCIZ /NO RH ON THE SYSTEM SO ABORT PROGRAM/                                      |
| 14392 | 050034 | 047440 | 020116 | 044124 |                                                                                    |
| 14393 | 050042 | 020105 | 054523 | 052123 |                                                                                    |
| 14394 | 050050 | 046505 | 051440 | 020117 |                                                                                    |
| 14395 | 050056 | 041101 | 051117 | 020124 |                                                                                    |
| 14396 | 050064 | 051120 | 043517 | 040522 |                                                                                    |
| 14397 | 050072 | 000115 |        |        |                                                                                    |
| 14398 |        |        |        |        |                                                                                    |
| 14399 | 050074 | 043101 | 042524 | 020122 | EM6: .ASCII /AFTER AN RH CLEAR (RHCS2-BIT #5) RHCS2 DOES NOT HAVE ONLY IR/<15><12> |
| 14400 | 050102 | 047101 | 051040 | 020110 |                                                                                    |
| 14401 | 050110 | 046103 | 040505 | 020122 |                                                                                    |
| 14402 | 050116 | 051050 | 041510 | 031123 |                                                                                    |
| 14403 | 050124 | 041055 | 052111 | 021440 |                                                                                    |
| 14404 | 050132 | 024465 | 051040 | 041510 |                                                                                    |
| 14405 | 050140 | 031123 | 042040 | 042517 |                                                                                    |
| 14406 | 050146 | 020123 | 047516 | 020124 |                                                                                    |
| 14407 | 050154 | 040510 | 042526 | 047440 |                                                                                    |
| 14408 | 050162 | 046116 | 020131 | 051111 |                                                                                    |
| 14409 | 050170 | 005015 |        |        |                                                                                    |
| 14410 | 050172 | 047101 | 020104 | 047125 | .ASCIZ /AND UNIT NUMBER/                                                           |
| 14411 | 050200 | 052111 | 047040 | 046525 |                                                                                    |
| 14412 | 050206 | 042502 | 000122 |        |                                                                                    |
| 14413 |        |        |        |        |                                                                                    |
| 14414 | 050212 | 043101 | 042524 | 020122 | EM7: .ASCII /AFTER CLEARING THE RH AND WRITING ONE WORD INTO RHDB AND/<15><12>     |
| 14415 | 050220 | 046103 | 040505 | 044522 |                                                                                    |
| 14416 | 050226 | 043516 | 052040 | 042510 |                                                                                    |
| 14417 | 050234 | 051040 | 020110 | 047101 |                                                                                    |
| 14418 | 050242 | 020104 | 051127 | 052111 |                                                                                    |
| 14419 | 050250 | 047111 | 020107 | 047117 |                                                                                    |
| 14420 | 050256 | 020105 | 047527 | 042122 |                                                                                    |
| 14421 | 050264 | 044440 | 052116 | 020117 |                                                                                    |
| 14422 | 050272 | 044122 | 041104 | 040440 |                                                                                    |
| 14423 | 050300 | 042116 | 005015 |        |                                                                                    |
| 14424 | 050304 | 042522 | 042101 | 047111 | .ASCIZ /READING IT BACK, CAUSED RHDB TO HAVE WRONG VALUE GIVEN IN "BAD"/           |
| 14425 | 050312 | 020107 | 052111 | 041040 |                                                                                    |
| 14426 | 050320 | 041501 | 026113 | 041440 |                                                                                    |
| 14427 | 050326 | 052501 | 042523 | 020104 |                                                                                    |
| 14428 | 050334 | 044122 | 041104 | 052040 |                                                                                    |
| 14429 | 050342 | 020117 | 040510 | 042526 |                                                                                    |
| 14430 | 050350 | 053440 | 047522 | 043516 |                                                                                    |
| 14431 | 050356 | 053040 | 046101 | 042525 |                                                                                    |
| 14432 | 050364 | 043440 | 053111 | 047105 |                                                                                    |
| 14433 | 050372 | 044440 | 020116 | 041042 |                                                                                    |
| 14434 | 050400 | 042101 | 000042 |        |                                                                                    |
| 14435 |        |        |        |        |                                                                                    |
| 14436 | 050404 | 043101 | 042524 | 020122 | EM10: .ASCII /AFTER CLEARING THE RH AND WRITING ONE WORD INTO RHDB AND/<15><12>    |
| 14437 | 050412 | 046103 | 040505 | 044522 |                                                                                    |
| 14438 | 050420 | 043516 | 052040 | 042510 |                                                                                    |
| 14439 | 050426 | 051040 | 020110 | 047101 |                                                                                    |
| 14440 | 050434 | 020104 | 051127 | 052111 |                                                                                    |
| 14441 | 050442 | 047111 | 020107 | 047117 |                                                                                    |
| 14442 | 050450 | 020105 | 047527 | 042122 |                                                                                    |
| 14443 | 050456 | 044440 | 052116 | 020117 |                                                                                    |
| 14444 | 050464 | 044122 | 041104 | 040440 |                                                                                    |

|       |        |        |        |        |                                                                                 |
|-------|--------|--------|--------|--------|---------------------------------------------------------------------------------|
| 14445 | 050472 | 042116 | 005015 |        |                                                                                 |
| 14446 | 050476 | 042522 | 042101 | 047111 | .ASCIZ /READING IT BACK, CAUSED RHCS2 TO HAVE WRONG VALUE GIVEN IN "BAD"/       |
| 14447 | 050504 | 020107 | 052111 | 041040 |                                                                                 |
| 14448 | 050512 | 041501 | 026113 | 041440 |                                                                                 |
| 14449 | 050520 | 052501 | 042523 | 020104 |                                                                                 |
| 14450 | 050526 | 044122 | 051503 | 020062 |                                                                                 |
| 14451 | 050534 | 047524 | 044040 | 053101 |                                                                                 |
| 14452 | 050542 | 020105 | 051127 | 047117 |                                                                                 |
| 14453 | 050550 | 020107 | 040526 | 052514 |                                                                                 |
| 14454 | 050556 | 020105 | 044507 | 042526 |                                                                                 |
| 14455 | 050564 | 020116 | 047111 | 021040 |                                                                                 |
| 14456 | 050572 | 040502 | 021104 | 000    |                                                                                 |
| 14457 |        |        |        |        |                                                                                 |
| 14458 | 050577 | 101    | 052106 | 051105 | EM11: .ASCII /AFTER CLEARING THE RH AND WRITING ONE WORD INTO RHDB AND/<15><12> |
| 14459 | 050604 | 041440 | 042514 | 051101 |                                                                                 |
| 14460 | 050612 | 047111 | 020107 | 044124 |                                                                                 |
| 14461 | 050620 | 020105 | 044122 | 040440 |                                                                                 |
| 14462 | 050626 | 042116 | 053440 | 044522 |                                                                                 |
| 14463 | 050634 | 044524 | 043516 | 047440 |                                                                                 |
| 14464 | 050642 | 042516 | 053440 | 051117 |                                                                                 |
| 14465 | 050650 | 020104 | 047111 | 047524 |                                                                                 |
| 14466 | 050656 | 051040 | 042110 | 020102 |                                                                                 |
| 14467 | 050664 | 047101 | 006504 | 012    |                                                                                 |
| 14468 | 050671 | 122    | 040505 | 044504 | .ASCIZ /READING IT BACK, CAUSED RHCS1 TO HAVE WRONG VALUE GIVEN IN "BAD"/       |
| 14469 | 050676 | 043516 | 044440 | 020124 |                                                                                 |
| 14470 | 050704 | 040502 | 045503 | 020054 |                                                                                 |
| 14471 | 050712 | 040503 | 051525 | 042105 |                                                                                 |
| 14472 | 050720 | 051040 | 041510 | 030523 |                                                                                 |
| 14473 | 050726 | 052040 | 020117 | 040510 |                                                                                 |
| 14474 | 050734 | 042526 | 053440 | 047522 |                                                                                 |
| 14475 | 050742 | 043516 | 053040 | 046101 |                                                                                 |
| 14476 | 050750 | 042525 | 043440 | 053111 |                                                                                 |
| 14477 | 050756 | 047105 | 044440 | 020116 |                                                                                 |
| 14478 | 050764 | 041042 | 042101 | 000042 |                                                                                 |
| 14479 |        |        |        |        |                                                                                 |
| 14480 | 050772 | 043101 | 042524 | 020122 | EM12: .ASCII /AFTER CLEARING THE RH AND WRITING ONE WORD INTO RHDB AND/<15><12> |
| 14481 | 051000 | 046103 | 040505 | 044522 |                                                                                 |
| 14482 | 051006 | 043516 | 052040 | 042510 |                                                                                 |
| 14483 | 051014 | 051040 | 020110 | 047101 |                                                                                 |
| 14484 | 051022 | 020104 | 051127 | 052111 |                                                                                 |
| 14485 | 051030 | 047111 | 020107 | 047117 |                                                                                 |
| 14486 | 051036 | 020105 | 047527 | 042122 |                                                                                 |
| 14487 | 051044 | 044440 | 052116 | 020117 |                                                                                 |
| 14488 | 051052 | 044122 | 041104 | 040440 |                                                                                 |
| 14489 | 051060 | 042116 | 005015 |        |                                                                                 |
| 14490 | 051064 | 042522 | 042101 | 047111 | .ASCIZ /READING IT BACK, CAUSED RHCS3 TO HAVE WRONG VALUE GIVEN IN "BAD"/       |
| 14491 | 051072 | 020107 | 052111 | 041040 |                                                                                 |
| 14492 | 051100 | 041501 | 026113 | 041440 |                                                                                 |
| 14493 | 051106 | 052501 | 042523 | 020104 |                                                                                 |
| 14494 | 051114 | 044122 | 051503 | 020063 |                                                                                 |
| 14495 | 051122 | 047524 | 044040 | 053101 |                                                                                 |
| 14496 | 051130 | 020105 | 051127 | 047117 |                                                                                 |
| 14497 | 051136 | 020107 | 040526 | 052514 |                                                                                 |
| 14498 | 051144 | 020105 | 044507 | 042526 |                                                                                 |
| 14499 | 051152 | 020116 | 047111 | 021040 |                                                                                 |
| 14500 | 051160 | 040502 | 021104 | 000    |                                                                                 |

|       |        |        |        |        |       |                                                                           |
|-------|--------|--------|--------|--------|-------|---------------------------------------------------------------------------|
| 14501 |        |        |        |        |       |                                                                           |
| 14502 | 051165 | 101    | 052106 | 051105 | EM13: | .ASCII /AFTER CLEARING THE RH AND WRITING ONE WORD INTO RHDB AND/<15><12> |
| 14503 | 051172 | 041440 | 042514 | 051101 |       |                                                                           |
| 14504 | 051200 | 047111 | 020107 | 044124 |       |                                                                           |
| 14505 | 051206 | 020105 | 044122 | 040440 |       |                                                                           |
| 14506 | 051214 | 042116 | 053440 | 044522 |       |                                                                           |
| 14507 | 051222 | 044524 | 043516 | 047440 |       |                                                                           |
| 14508 | 051230 | 042516 | 053440 | 051117 |       |                                                                           |
| 14509 | 051236 | 020104 | 047111 | 047524 |       |                                                                           |
| 14510 | 051244 | 051040 | 042110 | 020102 |       |                                                                           |
| 14511 | 051252 | 047101 | 006504 | 012    |       |                                                                           |
| 14512 | 051257 | 122    | 040505 | 044504 |       | .ASCIZ /READING IT BACK, CAUSED RHBA TO HAVE WRONG VALUE GIVEN IN "BAD"/  |
| 14513 | 051264 | 043516 | 044440 | 020124 |       |                                                                           |
| 14514 | 051272 | 040502 | 045503 | 020054 |       |                                                                           |
| 14515 | 051300 | 040503 | 051525 | 042105 |       |                                                                           |
| 14516 | 051306 | 051040 | 041110 | 020101 |       |                                                                           |
| 14517 | 051314 | 047524 | 044040 | 053101 |       |                                                                           |
| 14518 | 051322 | 020105 | 051127 | 047117 |       |                                                                           |
| 14519 | 051330 | 020107 | 040526 | 052514 |       |                                                                           |
| 14520 | 051336 | 020105 | 044507 | 042526 |       |                                                                           |
| 14521 | 051344 | 020116 | 047111 | 021040 |       |                                                                           |
| 14522 | 051352 | 040502 | 021104 | 000    |       |                                                                           |
| 14523 |        |        |        |        |       |                                                                           |
| 14524 | 051357 | 101    | 052106 | 051105 | EM14: | .ASCII /AFTER CLEARING THE RH AND WRITING ONE WORD INTO RHDB AND/<15><12> |
| 14525 | 051364 | 041440 | 042514 | 051101 |       |                                                                           |
| 14526 | 051372 | 047111 | 020107 | 044124 |       |                                                                           |
| 14527 | 051400 | 020105 | 044122 | 040440 |       |                                                                           |
| 14528 | 051406 | 042116 | 053440 | 044522 |       |                                                                           |
| 14529 | 051414 | 044524 | 043516 | 047440 |       |                                                                           |
| 14530 | 051422 | 042516 | 053440 | 051117 |       |                                                                           |
| 14531 | 051430 | 020104 | 047111 | 047524 |       |                                                                           |
| 14532 | 051436 | 051040 | 042110 | 020102 |       |                                                                           |
| 14533 | 051444 | 047101 | 006504 | 012    |       |                                                                           |
| 14534 | 051451 | 122    | 040505 | 044504 |       | .ASCIZ /READING IT BACK, CAUSED RHBAE TO HAVE WRONG VALUE GIVEN IN "BAD"/ |
| 14535 | 051456 | 043516 | 044440 | 020124 |       |                                                                           |
| 14536 | 051464 | 040502 | 045503 | 020054 |       |                                                                           |
| 14537 | 051472 | 040503 | 051525 | 042105 |       |                                                                           |
| 14538 | 051500 | 051040 | 041110 | 042501 |       |                                                                           |
| 14539 | 051506 | 052040 | 020117 | 040510 |       |                                                                           |
| 14540 | 051514 | 042526 | 053440 | 047522 |       |                                                                           |
| 14541 | 051522 | 043516 | 053040 | 046101 |       |                                                                           |
| 14542 | 051530 | 042525 | 043440 | 053111 |       |                                                                           |
| 14543 | 051536 | 047105 | 044440 | 020116 |       |                                                                           |
| 14544 | 051544 | 041042 | 042101 | 000042 |       |                                                                           |
| 14545 |        |        |        |        |       |                                                                           |
| 14546 | 051552 | 043101 | 042524 | 020122 | EM15: | .ASCII /AFTER CLEARING THE RH AND WRITING ONE WORD INTO RHDB AND/<15><12> |
| 14547 | 051560 | 046103 | 040505 | 044522 |       |                                                                           |
| 14548 | 051566 | 043516 | 052040 | 042510 |       |                                                                           |
| 14549 | 051574 | 051040 | 020110 | 047101 |       |                                                                           |
| 14550 | 051602 | 020104 | 051127 | 052111 |       |                                                                           |
| 14551 | 051610 | 047111 | 020107 | 047117 |       |                                                                           |
| 14552 | 051616 | 020105 | 047527 | 042122 |       |                                                                           |
| 14553 | 051624 | 044440 | 052116 | 020117 |       |                                                                           |
| 14554 | 051632 | 044122 | 041104 | 040440 |       |                                                                           |
| 14555 | 051640 | 042116 | 005015 |        |       |                                                                           |
| 14556 | 051644 | 042522 | 042101 | 047111 |       | .ASCIZ /READING IT BACK, CAUSED RHWC TO HAVE WRONG VALUE GIVEN IN "BAD"/  |

|       |        |        |        |        |                                                                                 |
|-------|--------|--------|--------|--------|---------------------------------------------------------------------------------|
| 14557 | 051652 | 020107 | 052111 | 041040 |                                                                                 |
| 14558 | 051660 | 041501 | 026113 | 041440 |                                                                                 |
| 14559 | 051666 | 052501 | 042523 | 020104 |                                                                                 |
| 14560 | 051674 | 044122 | 041527 | 052040 |                                                                                 |
| 14561 | 051702 | 020117 | 040510 | 042526 |                                                                                 |
| 14562 | 051710 | 053440 | 047522 | 043516 |                                                                                 |
| 14563 | 051716 | 053040 | 046101 | 042525 |                                                                                 |
| 14564 | 051724 | 043440 | 053111 | 047105 |                                                                                 |
| 14565 | 051732 | 044440 | 020116 | 041042 |                                                                                 |
| 14566 | 051740 | 042101 | 000042 |        |                                                                                 |
| 14567 |        |        |        |        |                                                                                 |
| 14568 | 051744 | 043101 | 042524 | 020122 | EM16: .ASCII /AFTER CLEARING THE RH AND WRITING ONE WORD INTO RHDB AND/<15><12> |
| 14569 | 051752 | 046103 | 040505 | 044522 |                                                                                 |
| 14570 | 051760 | 043516 | 052040 | 042510 |                                                                                 |
| 14571 | 051766 | 051040 | 020110 | 047101 |                                                                                 |
| 14572 | 051774 | 020104 | 051127 | 052111 |                                                                                 |
| 14573 | 052002 | 047111 | 020107 | 047117 |                                                                                 |
| 14574 | 052010 | 020105 | 047527 | 042122 |                                                                                 |
| 14575 | 052016 | 044440 | 052116 | 020117 |                                                                                 |
| 14576 | 052024 | 044122 | 041104 | 040440 |                                                                                 |
| 14577 | 052032 | 042116 | 005015 |        |                                                                                 |
| 14578 | 052036 | 042522 | 042101 | 047111 | .ASCIZ /READING IT BACK, CAUSED RHCS2 TO HAVE WRONG VALUE GIVEN IN "BAD"/       |
| 14579 | 052044 | 020107 | 052111 | 041040 |                                                                                 |
| 14580 | 052052 | 041501 | 026113 | 041440 |                                                                                 |
| 14581 | 052060 | 052501 | 042523 | 020104 |                                                                                 |
| 14582 | 052066 | 044122 | 051503 | 020062 |                                                                                 |
| 14583 | 052074 | 047524 | 044040 | 053101 |                                                                                 |
| 14584 | 052102 | 020105 | 051127 | 047117 |                                                                                 |
| 14585 | 052110 | 020107 | 040526 | 052514 |                                                                                 |
| 14586 | 052116 | 020105 | 044507 | 042526 |                                                                                 |
| 14587 | 052124 | 020116 | 047111 | 021040 |                                                                                 |
| 14588 | 052132 | 040502 | 021104 | 000    |                                                                                 |
| 14589 |        |        |        |        |                                                                                 |
| 14590 | 052137 | 101    | 052106 | 051105 | EM17: .ASCII /AFTER CLEARING THE RH AND WRITING TWO WORD INTO RHDB AND/<15><12> |
| 14591 | 052144 | 041440 | 042514 | 051101 |                                                                                 |
| 14592 | 052152 | 047111 | 020107 | 044124 |                                                                                 |
| 14593 | 052160 | 020105 | 044122 | 040440 |                                                                                 |
| 14594 | 052166 | 042116 | 053440 | 044522 |                                                                                 |
| 14595 | 052174 | 044524 | 043516 | 052040 |                                                                                 |
| 14596 | 052202 | 047527 | 053440 | 051117 |                                                                                 |
| 14597 | 052210 | 020104 | 047111 | 047524 |                                                                                 |
| 14598 | 052216 | 051040 | 042110 | 020102 |                                                                                 |
| 14599 | 052224 | 047101 | 006504 | 012    |                                                                                 |
| 14600 | 052231 | 122    | 040505 | 044504 | .ASCIZ /READING IT BACK, CAUSED RHDB TO HAVE WRONG VALUE GIVEN IN "BAD"/        |
| 14601 | 052236 | 043516 | 044440 | 020124 |                                                                                 |
| 14602 | 052244 | 040502 | 045503 | 020054 |                                                                                 |
| 14603 | 052252 | 040503 | 051525 | 042105 |                                                                                 |
| 14604 | 052260 | 051040 | 042110 | 020102 |                                                                                 |
| 14605 | 052266 | 047524 | 044040 | 053101 |                                                                                 |
| 14606 | 052274 | 020105 | 051127 | 047117 |                                                                                 |
| 14607 | 052302 | 020107 | 040526 | 052514 |                                                                                 |
| 14608 | 052310 | 020105 | 044507 | 042526 |                                                                                 |
| 14609 | 052316 | 020116 | 047111 | 021040 |                                                                                 |
| 14610 | 052324 | 040502 | 021104 | 000    |                                                                                 |
| 14611 |        |        |        |        |                                                                                 |
| 14612 | 052331 | 101    | 052106 | 051105 | EM20: .ASCII /AFTER CLEARING THE RH AND WRITING TWO WORD INTO RHDB AND/<15><12> |

|       |        |        |        |        |
|-------|--------|--------|--------|--------|
| 14613 | 052336 | 041440 | 042514 | 051101 |
| 14614 | 052344 | 047111 | 020107 | 044124 |
| 14615 | 052352 | 020105 | 044122 | 040440 |
| 14616 | 052360 | 042116 | 053440 | 044522 |
| 14617 | 052366 | 044524 | 043516 | 052040 |
| 14618 | 052374 | 047527 | 053440 | 051117 |
| 14619 | 052402 | 020104 | 047111 | 047524 |
| 14620 | 052410 | 051040 | 042110 | 020102 |
| 14621 | 052416 | 047101 | 006504 | 012    |
| 14622 | 052423 | 122    | 040505 | 044504 |
| 14623 | 052430 | 043516 | 047440 | 042516 |
| 14624 | 052436 | 041040 | 041501 | 026113 |
| 14625 | 052444 | 041440 | 052501 | 042523 |
| 14626 | 052452 | 020104 | 044122 | 051503 |
| 14627 | 052460 | 020062 | 047524 | 044040 |
| 14628 | 052466 | 053101 | 020105 | 051127 |
| 14629 | 052474 | 047117 | 020107 | 040526 |
| 14630 | 052502 | 052514 | 020105 | 044507 |
| 14631 | 052510 | 042526 | 020116 | 047111 |
| 14632 | 052516 | 021040 | 040502 | 021104 |
| 14633 | 052524 | 000    |        |        |
| 14634 |        |        |        |        |
| 14635 | 052525 | 101    | 052106 | 051105 |
| 14636 | 052532 | 041440 | 042514 | 051101 |
| 14637 | 052540 | 047111 | 020107 | 044124 |
| 14638 | 052546 | 020105 | 044122 | 040440 |
| 14639 | 052554 | 042116 | 053440 | 044522 |
| 14640 | 052562 | 044524 | 043516 | 052040 |
| 14641 | 052570 | 047527 | 053440 | 051117 |
| 14642 | 052576 | 020104 | 047111 | 047524 |
| 14643 | 052604 | 051040 | 042110 | 020102 |
| 14644 | 052612 | 047101 | 006504 | 012    |
| 14645 | 052617 | 122    | 040505 | 044504 |
| 14646 | 052624 | 043516 | 044440 | 020124 |
| 14647 | 052632 | 040502 | 045503 | 052040 |
| 14648 | 052640 | 044527 | 042503 | 020054 |
| 14649 | 052646 | 040503 | 051525 | 042105 |
| 14650 | 052654 | 051040 | 042110 | 020102 |
| 14651 | 052662 | 047524 | 044040 | 053101 |
| 14652 | 052670 | 020105 | 051127 | 047117 |
| 14653 | 052676 | 020107 | 040526 | 052514 |
| 14654 | 052704 | 020105 | 044507 | 042526 |
| 14655 | 052712 | 020116 | 047111 | 021040 |
| 14656 | 052720 | 040502 | 021104 | 000    |
| 14657 |        |        |        |        |
| 14658 | 052725 | 101    | 052106 | 051105 |
| 14659 | 052732 | 041440 | 042514 | 051101 |
| 14660 | 052740 | 047111 | 020107 | 044124 |
| 14661 | 052746 | 020105 | 044122 | 040440 |
| 14662 | 052754 | 042116 | 053440 | 044522 |
| 14663 | 052762 | 044524 | 043516 | 052040 |
| 14664 | 052770 | 047527 | 053440 | 051117 |
| 14665 | 052776 | 020104 | 047111 | 047524 |
| 14666 | 053004 | 051040 | 042110 | 020102 |
| 14667 | 053012 | 047101 | 006504 | 012    |
| 14668 | 053017 | 122    | 040505 | 044504 |

.ASCIZ /READING ONE BACK, CAUSED RHCS2 TO HAVE WRONG VALUE GIVEN IN "BAD"/

EM21: .ASCII /AFTER CLEARING THE RH AND WRITING TWO WORD INTO RHDB AND/<15><12>

.ASCIZ /READING IT BACK TWICE, CAUSED RHDB TO HAVE WRONG VALUE GIVEN IN "BAD"/

EM22: .ASCII /AFTER CLEARING THE RH AND WRITING TWO WORD INTO RHDB AND/<15><12>

.ASCIZ /READING IT BACK TWICE, CAUSED RHCS2 TO HAVE WRONG VALUE GIVEN IN "BAD"/

|       |        |        |        |        |
|-------|--------|--------|--------|--------|
| 14669 | 053024 | 043516 | 044440 | 020124 |
| 14670 | 053032 | 040502 | 045503 | 052040 |
| 14671 | 053040 | 044527 | 042503 | 020054 |
| 14672 | 053046 | 040503 | 051525 | 042105 |
| 14673 | 053054 | 051040 | 041510 | 031123 |
| 14674 | 053062 | 052040 | 020117 | 040510 |
| 14675 | 053070 | 042526 | 053440 | 047522 |
| 14676 | 053076 | 043516 | 053040 | 046101 |
| 14677 | 053104 | 042525 | 043440 | 053111 |
| 14678 | 053112 | 047105 | 044440 | 020116 |
| 14679 | 053120 | 041042 | 042101 | 000042 |
| 14680 |        |        |        |        |
| 14681 | 053126 | 043101 | 042524 | 020122 |
| 14682 | 053134 | 046103 | 040505 | 044522 |
| 14683 | 053142 | 043516 | 052040 | 042510 |
| 14684 | 053150 | 051040 | 020110 | 047101 |
| 14685 | 053156 | 020104 | 051127 | 052111 |
| 14686 | 053164 | 047111 | 020107 | 044505 |
| 14687 | 053172 | 044107 | 020124 | 047527 |
| 14688 | 053200 | 042122 | 044440 | 052116 |
| 14689 | 053206 | 020117 | 044122 | 041104 |
| 14690 | 053214 | 040440 | 042116 | 005015 |
| 14691 | 053222 | 042522 | 042101 | 047111 |
| 14692 | 053230 | 020107 | 052111 | 041040 |
| 14693 | 053236 | 041501 | 026113 | 041440 |
| 14694 | 053244 | 052501 | 042523 | 020104 |
| 14695 | 053252 | 044122 | 051503 | 020062 |
| 14696 | 053260 | 047524 | 044040 | 053101 |
| 14697 | 053266 | 020105 | 051127 | 047117 |
| 14698 | 053274 | 020107 | 040526 | 052514 |
| 14699 | 053302 | 020105 | 044507 | 042526 |
| 14700 | 053310 | 020116 | 047111 | 021040 |
| 14701 | 053316 | 040502 | 021104 | 000    |
| 14702 |        |        |        |        |
| 14703 | 053323 | 124    | 042510 | 051040 |
| 14704 | 053330 | 020110 | 040527 | 020123 |
| 14705 | 053336 | 046103 | 040505 | 042522 |
| 14706 | 053344 | 020104 | 047101 | 020104 |
| 14707 | 053352 | 020101 | 040520 | 052124 |
| 14708 | 053360 | 051105 | 020116 | 043117 |
| 14709 | 053366 | 034040 | 053440 | 051117 |
| 14710 | 053374 | 051504 | 053440 | 051105 |
| 14711 | 053402 | 020105 | 051127 | 052111 |
| 14712 | 053410 | 042524 | 020116 | 047111 |
| 14713 | 053416 | 047524 | 051040 | 042110 |
| 14714 | 053424 | 006502 | 012    |        |
| 14715 | 053427 | 122    | 040505 | 044504 |
| 14716 | 053434 | 043516 | 051040 | 042110 |
| 14717 | 053442 | 020102 | 047506 | 020122 |
| 14718 | 053450 | 044124 | 020105 | 047042 |
| 14719 | 053456 | 020042 | 044124 | 020056 |
| 14720 | 053464 | 044524 | 042515 | 043440 |
| 14721 | 053472 | 053101 | 020105 | 051127 |
| 14722 | 053500 | 047117 | 020107 | 040526 |
| 14723 | 053506 | 052514 | 020105 | 047111 |
| 14724 | 053514 | 051040 | 042110 | 006502 |

EM23: .ASCII /AFTER CLEARING THE RH AND WRITING EIGHT WORD INTO RHDB AND/&lt;15&gt;&lt;12&gt;

.ASCIZ /READING IT BACK, CAUSED RHCS2 TO HAVE WRONG VALUE GIVEN IN "BAD"/

EM24: .ASCII /THE RH WAS CLEARED AND A PATTERN OF 8 WORDS WERE WRITTEN INTO RHDB/&lt;15&gt;

.ASCII /READING RHDB FOR THE "N" TH. TIME GAVE WRONG VALUE IN RHDB/&lt;15&gt;&lt;12&gt;

|       |        |        |        |        |                                                                                       |
|-------|--------|--------|--------|--------|---------------------------------------------------------------------------------------|
| 14725 | 053522 | 012    |        |        |                                                                                       |
| 14726 | 053523 | 042    | 021116 | 044440 | .ASCIZ /"N" IS GIVEN IN WORD NO/                                                      |
| 14727 | 053530 | 020123 | 044507 | 042526 |                                                                                       |
| 14728 | 053536 | 020116 | 047111 | 053440 |                                                                                       |
| 14729 | 053544 | 051117 | 020104 | 047516 |                                                                                       |
| 14730 | 053552 | 000    |        |        |                                                                                       |
| 14731 |        |        |        |        |                                                                                       |
| 14732 | 053553 | 124    | 042510 | 051040 | EM25: .ASCII /THE RH WAS CLEARED AND A PATTERN OF 8 WORDS WERE WRITTEN INTO RHDB/<15> |
| 14733 | 053560 | 020110 | 040527 | 020123 |                                                                                       |
| 14734 | 053566 | 046103 | 040505 | 042522 |                                                                                       |
| 14735 | 053574 | 020104 | 047101 | 020104 |                                                                                       |
| 14736 | 053602 | 020101 | 040520 | 052124 |                                                                                       |
| 14737 | 053610 | 051105 | 020116 | 043117 |                                                                                       |
| 14738 | 053616 | 034040 | 053440 | 051117 |                                                                                       |
| 14739 | 053624 | 051504 | 053440 | 051105 |                                                                                       |
| 14740 | 053632 | 020105 | 051127 | 052111 |                                                                                       |
| 14741 | 053640 | 042524 | 020116 | 047111 |                                                                                       |
| 14742 | 053646 | 047524 | 051040 | 042110 |                                                                                       |
| 14743 | 053654 | 006502 | 012    |        |                                                                                       |
| 14744 | 053657 | 101    | 052106 | 051105 | .ASCIZ /AFTER READING ALL 8 WORDS, FOLLOWING REGISTER CONTAINED WRONG VALUE GIV       |
| 14745 | 053664 | 051040 | 040505 | 044504 |                                                                                       |
| 14746 | 053672 | 043516 | 040440 | 046114 |                                                                                       |
| 14747 | 053700 | 034040 | 053440 | 051117 |                                                                                       |
| 14748 | 053706 | 051504 | 020054 | 047506 |                                                                                       |
| 14749 | 053714 | 046114 | 053517 | 047111 |                                                                                       |
| 14750 | 053722 | 020107 | 042522 | 044507 |                                                                                       |
| 14751 | 053730 | 052123 | 051105 | 041440 |                                                                                       |
| 14752 | 053736 | 047117 | 040524 | 047111 |                                                                                       |
| 14753 | 053744 | 042105 | 053440 | 047522 |                                                                                       |
| 14754 | 053752 | 043516 | 053040 | 046101 |                                                                                       |
| 14755 | 053760 | 042525 | 043440 | 053111 |                                                                                       |
| 14756 | 053766 | 047105 | 044440 | 020116 |                                                                                       |
| 14757 | 053774 | 041042 | 042101 | 000042 |                                                                                       |
| 14758 |        |        |        |        |                                                                                       |
| 14759 | 054002 | 042523 | 052124 | 047111 | EM33: .ASCIZ /SETTING RH CLEAR (RHCS2-BIT #5) CAUSED ERROR REGISTER 1 TO HAVE WRONG V |
| 14760 | 054010 | 020107 | 044122 | 041440 |                                                                                       |
| 14761 | 054016 | 042514 | 051101 | 024040 |                                                                                       |
| 14762 | 054024 | 044122 | 051503 | 026462 |                                                                                       |
| 14763 | 054032 | 044502 | 020124 | 032443 |                                                                                       |
| 14764 | 054040 | 020051 | 040503 | 051525 |                                                                                       |
| 14765 | 054046 | 042105 | 042440 | 051122 |                                                                                       |
| 14766 | 054054 | 051117 | 051040 | 043505 |                                                                                       |
| 14767 | 054062 | 051511 | 042524 | 020122 |                                                                                       |
| 14768 | 054070 | 020061 | 047524 | 044040 |                                                                                       |
| 14769 | 054076 | 053101 | 020105 | 051127 |                                                                                       |
| 14770 | 054104 | 047117 | 020107 | 040526 |                                                                                       |
| 14771 | 054112 | 052514 | 000105 |        |                                                                                       |
| 14772 |        |        |        |        |                                                                                       |
| 14773 | 054116 | 047101 | 051040 | 020110 | EM34: .ASCII /AN RH CLEAR WAS GIVEN RHER1 WAS CHECKED TO HAVE ZERO. PAT (RHCS2-BIT #4 |
| 14774 | 054124 | 046103 | 040505 | 020122 |                                                                                       |
| 14775 | 054132 | 040527 | 020123 | 044507 |                                                                                       |
| 14776 | 054140 | 042526 | 020116 | 044122 |                                                                                       |
| 14777 | 054146 | 051105 | 020061 | 040527 |                                                                                       |
| 14778 | 054154 | 020123 | 044103 | 041505 |                                                                                       |
| 14779 | 054162 | 042513 | 020104 | 047524 |                                                                                       |
| 14780 | 054170 | 044040 | 053101 | 020105 |                                                                                       |



|       |        |        |        |        |
|-------|--------|--------|--------|--------|
| 14781 | 054176 | 042532 | 047522 | 020056 |
| 14782 | 054204 | 040520 | 020124 | 051050 |
| 14783 | 054212 | 041510 | 031123 | 041055 |
| 14784 | 054220 | 052111 | 021440 | 024464 |
| 14785 | 054226 | 053440 | 051501 | 051440 |
| 14786 | 054234 | 052105 | 005015 |        |
| 14787 | 054240 | 047524 | 044440 | 053116 |
| 14788 | 054246 | 051105 | 020124 | 040520 |
| 14789 | 054254 | 044522 | 054524 | 041440 |
| 14790 | 054262 | 042510 | 045503 | 047111 |
| 14791 | 054270 | 027107 | 051040 | 042510 |
| 14792 | 054276 | 030522 | 053440 | 051501 |
| 14793 | 054304 | 051040 | 040505 | 020104 |
| 14794 | 054312 | 052502 | 020124 | 044504 |
| 14795 | 054320 | 020104 | 047516 | 020124 |
| 14796 | 054326 | 047503 | 052116 | 044501 |
| 14797 | 054334 | 020116 | 044127 | 052101 |
| 14798 | 054342 | 044440 | 020123 | 047111 |
| 14799 | 054350 | 021040 | 047507 | 042117 |
| 14800 | 054356 | 000042 |        |        |
| 14801 |        |        |        |        |
| 14802 | 054360 | 044122 | 041440 | 042514 |
| 14803 | 054366 | 051101 | 053440 | 051501 |
| 14804 | 054374 | 043440 | 053111 | 047105 |
| 14805 | 054402 | 020056 | 044122 | 051105 |
| 14806 | 054410 | 020061 | 040527 | 020123 |
| 14807 | 054416 | 044103 | 041505 | 042513 |
| 14808 | 054424 | 027104 | 050040 | 052101 |
| 14809 | 054432 | 024040 | 044122 | 051503 |
| 14810 | 054440 | 026462 | 044502 | 020124 |
| 14811 | 054446 | 032043 | 020051 | 040527 |
| 14812 | 054454 | 020123 | 042523 | 006524 |
| 14813 | 054462 | 012    |        |        |
| 14814 | 054463 | 101    | 042116 | 051040 |
| 14815 | 054470 | 042510 | 030522 | 053440 |
| 14816 | 054476 | 051501 | 051040 | 040505 |
| 14817 | 054504 | 027104 | 051040 | 041510 |
| 14818 | 054512 | 030523 | 051440 | 047510 |
| 14819 | 054520 | 046125 | 020104 | 040510 |
| 14820 | 054526 | 042526 | 051040 | 054504 |
| 14821 | 054534 | 020054 | 041523 | 040440 |
| 14822 | 054542 | 042116 | 046440 | 050103 |
| 14823 | 054550 | 020105 | 042523 | 000124 |
| 14824 |        |        |        |        |
| 14825 | 054556 | 044122 | 041440 | 042514 |
| 14826 | 054564 | 051101 | 053440 | 051501 |
| 14827 | 054572 | 043440 | 053111 | 047105 |
| 14828 | 054600 | 020056 | 044122 | 051105 |
| 14829 | 054606 | 020061 | 040527 | 020123 |
| 14830 | 054614 | 044103 | 041505 | 042513 |
| 14831 | 054622 | 027104 | 050040 | 052101 |
| 14832 | 054630 | 024040 | 044122 | 051503 |
| 14833 | 054636 | 026462 | 044502 | 020124 |
| 14834 | 054644 | 032043 | 020051 | 040527 |
| 14835 | 054652 | 020123 | 042523 | 006524 |
| 14836 | 054660 | 012    |        |        |

.ASCIZ /TO INVERT PARITY CHECKING. RHER1 WAS READ BUT DID NOT CONTAIN WHAT IS I

EM35: .ASCII /RH CLEAR WAS GIVEN. RHER1 WAS CHECKED. PAT (RHCS2-BIT #4) WAS SET/<15><

.ASCIZ /AND RHER1 WAS READ. RHCS1 SHOULD HAVE RDY, SC AND MCPE SET/

EM36: .ASCII /RH CLEAR WAS GIVEN. RHER1 WAS CHECKED. PAT (RHCS2-BIT #4) WAS SET/<15><

|       |        |        |        |        |                                                                                      |
|-------|--------|--------|--------|--------|--------------------------------------------------------------------------------------|
| 14837 | 054661 | 122    | 042510 | 030522 | .ASCII /RHER1 WAS READ. "1" WAS WRITTEN INTO "TRE" IN RHCS1/<15><12>                 |
| 14838 | 054666 | 053440 | 051501 | 051040 |                                                                                      |
| 14839 | 054674 | 040505 | 027104 | 021040 |                                                                                      |
| 14840 | 054702 | 021061 | 053440 | 051501 |                                                                                      |
| 14841 | 054710 | 053440 | 044522 | 052124 |                                                                                      |
| 14842 | 054716 | 047105 | 044440 | 052116 |                                                                                      |
| 14843 | 054724 | 020117 | 052042 | 042522 |                                                                                      |
| 14844 | 054732 | 020042 | 047111 | 051040 |                                                                                      |
| 14845 | 054740 | 041510 | 030523 | 005015 |                                                                                      |
| 14846 | 054746 | 047117 | 041440 | 042510 | .ASCIZ /ON CHECKING RHCS1 IT DID NOT CONTAIN WHAT IS IN GOOD/                        |
| 14847 | 054754 | 045503 | 047111 | 020107 |                                                                                      |
| 14848 | 054762 | 044122 | 051503 | 020061 |                                                                                      |
| 14849 | 054770 | 052111 | 042040 | 042111 |                                                                                      |
| 14850 | 054776 | 047040 | 052117 | 041440 |                                                                                      |
| 14851 | 055004 | 047117 | 040524 | 047111 |                                                                                      |
| 14852 | 055012 | 053440 | 040510 | 020124 |                                                                                      |
| 14853 | 055020 | 051511 | 044440 | 020116 |                                                                                      |
| 14854 | 055026 | 047507 | 042117 | 000    |                                                                                      |
| 14855 |        |        |        |        |                                                                                      |
| 14856 | 055033 | 122    | 020110 | 040527 | EM37: .ASCII /RH WAS CLEARED. RHER1 WAS CHECKED. PAT (RHCS2-BIT #4) WAS SET/<15><12> |
| 14857 | 055040 | 020123 | 046103 | 040505 |                                                                                      |
| 14858 | 055046 | 042522 | 027104 | 051040 |                                                                                      |
| 14859 | 055054 | 042510 | 030522 | 053440 |                                                                                      |
| 14860 | 055062 | 051501 | 041440 | 042510 |                                                                                      |
| 14861 | 055070 | 045503 | 042105 | 020056 |                                                                                      |
| 14862 | 055076 | 040520 | 020124 | 051050 |                                                                                      |
| 14863 | 055104 | 041510 | 031123 | 041055 |                                                                                      |
| 14864 | 055112 | 052111 | 021440 | 024464 |                                                                                      |
| 14865 | 055120 | 053440 | 051501 | 051440 |                                                                                      |
| 14866 | 055126 | 052105 | 005015 |        |                                                                                      |
| 14867 | 055132 | 044122 | 051105 | 020061 | .ASCII /RHER1 WAS READ. "1" WAS WRITTEN IN "TRE" IN RHCS1/<15><12>                   |
| 14868 | 055140 | 040527 | 020123 | 042522 |                                                                                      |
| 14869 | 055146 | 042101 | 020056 | 030442 |                                                                                      |
| 14870 | 055154 | 020042 | 040527 | 020123 |                                                                                      |
| 14871 | 055162 | 051127 | 052111 | 042524 |                                                                                      |
| 14872 | 055170 | 020116 | 047111 | 021040 |                                                                                      |
| 14873 | 055176 | 051124 | 021105 | 044440 |                                                                                      |
| 14874 | 055204 | 020116 | 044122 | 051503 |                                                                                      |
| 14875 | 055212 | 006461 | 012    |        |                                                                                      |
| 14876 | 055215 | 101    | 020116 | 044122 | .ASCII /AN RH CLEAR WAS GIVEN BUT FOLLOWING REGISTER DID NOT/<15><12>                |
| 14877 | 055222 | 041440 | 042514 | 051101 |                                                                                      |
| 14878 | 055230 | 053440 | 051501 | 043440 |                                                                                      |
| 14879 | 055236 | 053111 | 047105 | 041040 |                                                                                      |
| 14880 | 055244 | 052125 | 043040 | 046117 |                                                                                      |
| 14881 | 055252 | 047514 | 044527 | 043516 |                                                                                      |
| 14882 | 055260 | 051040 | 043505 | 051511 |                                                                                      |
| 14883 | 055266 | 042524 | 020122 | 044504 |                                                                                      |
| 14884 | 055274 | 020104 | 047516 | 006524 |                                                                                      |
| 14885 | 055302 | 012    |        |        |                                                                                      |
| 14886 | 055303 | 103    | 047117 | 040524 | .ASCIZ /CONTAIN WHAT IS IN "GOOD"/                                                   |
| 14887 | 055310 | 047111 | 053440 | 040510 |                                                                                      |
| 14888 | 055316 | 020124 | 051511 | 044440 |                                                                                      |
| 14889 | 055324 | 020116 | 043442 | 047517 |                                                                                      |
| 14890 | 055332 | 021104 | 000    |        |                                                                                      |
| 14891 |        |        |        |        |                                                                                      |
| 14892 | 055335 | 101    | 052106 | 051105 | EM45: .ASCII /AFTER AN RH CLEAR "1" WAS WRITTEN IN THE DISK (TAPE) ADDRESS/<15><12>  |

|       |        |        |        |        |
|-------|--------|--------|--------|--------|
| 14893 | 055342 | 040440 | 020116 | 044122 |
| 14894 | 055350 | 041440 | 042514 | 051101 |
| 14895 | 055356 | 021040 | 021061 | 053440 |
| 14896 | 055364 | 051501 | 053440 | 044522 |
| 14897 | 055372 | 052124 | 047105 | 044440 |
| 14898 | 055400 | 020116 | 044124 | 020105 |
| 14899 | 055406 | 044504 | 045523 | 024040 |
| 14900 | 055414 | 040524 | 042520 | 020051 |
| 14901 | 055422 | 042101 | 051104 | 051505 |
| 14902 | 055430 | 006523 | 012    |        |
| 14903 | 055433 | 122    | 043505 | 051511 |
| 14904 | 055440 | 042524 | 027122 | 050040 |
| 14905 | 055446 | 052101 | 044440 | 020116 |
| 14906 | 055454 | 044122 | 051503 | 020061 |
| 14907 | 055462 | 040527 | 020123 | 042523 |
| 14908 | 055470 | 027124 | 047440 | 020116 |
| 14909 | 055476 | 042522 | 042101 | 047111 |
| 14910 | 055504 | 020107 | 044504 | 045523 |
| 14911 | 055512 | 024040 | 040524 | 042520 |
| 14912 | 055520 | 020051 | 042101 | 051104 |
| 14913 | 055526 | 051505 | 006523 | 012    |
| 14914 | 055533 | 122    | 043505 | 051511 |
| 14915 | 055540 | 042524 | 020122 | 052111 |
| 14916 | 055546 | 042040 | 042111 | 047040 |
| 14917 | 055554 | 052117 | 041440 | 047117 |
| 14918 | 055562 | 040524 | 047111 | 021040 |
| 14919 | 055570 | 021061 | 000    |        |
| 14920 |        |        |        |        |
| 14921 | 055573 | 101    | 052106 | 051105 |
| 14922 | 055600 | 040440 | 020116 | 044122 |
| 14923 | 055606 | 041440 | 042514 | 051101 |
| 14924 | 055614 | 021040 | 021061 | 053440 |
| 14925 | 055622 | 051501 | 053440 | 044522 |
| 14926 | 055630 | 052124 | 047105 | 044440 |
| 14927 | 055636 | 020116 | 044124 | 020105 |
| 14928 | 055644 | 044504 | 045523 | 024040 |
| 14929 | 055652 | 040524 | 042520 | 020051 |
| 14930 | 055660 | 042101 | 051104 | 051505 |
| 14931 | 055666 | 020123 | 042522 | 044507 |
| 14932 | 055674 | 052123 | 051105 | 005015 |
| 14933 | 055702 | 040520 | 020124 | 047111 |
| 14934 | 055710 | 051040 | 041510 | 030523 |
| 14935 | 055716 | 053440 | 051501 | 051440 |
| 14936 | 055724 | 052105 | 040440 | 052106 |
| 14937 | 055732 | 051105 | 051040 | 040505 |
| 14938 | 055740 | 044504 | 043516 | 042040 |
| 14939 | 055746 | 051511 | 020113 | 052050 |
| 14940 | 055754 | 050101 | 024505 | 040440 |
| 14941 | 055762 | 042104 | 042522 | 051523 |
| 14942 | 055770 | 051040 | 043505 | 051511 |
| 14943 | 055776 | 042524 | 020122 | 044124 |
| 14944 | 056004 | 020105 | 047506 | 046114 |
| 14945 | 056012 | 053517 | 047111 | 006507 |
| 14946 | 056020 | 012    |        |        |
| 14947 | 056021 | 122    | 043505 | 051511 |
| 14948 | 056026 | 042524 | 020122 | 044504 |

.ASCII /REGISTER. PAT IN RHCSI WAS SET. ON READING DISK (TAPE) ADDRESS/<15><12>

.ASCIZ /REGISTER IT DID NOT CONTAIN "1"/

EM46: .ASCII /AFTER AN RH CLEAR "1" WAS WRITTEN IN THE DISK (TAPE) ADDRESS REGISTER/<

.ASCII /PAT IN RHCSI WAS SET AFTER READING DISK (TAPE) ADDRESS REGISTER THE FOL

.ASCIZ /REGISTER DID NOT CONTAIN WHAT IS IN "GOOD"/

|       |        |        |        |        |
|-------|--------|--------|--------|--------|
| 14949 | 056034 | 020104 | 047516 | 020124 |
| 14950 | 056042 | 047503 | 052116 | 044501 |
| 14951 | 056050 | 020116 | 044127 | 052101 |
| 14952 | 056056 | 044440 | 020123 | 047111 |
| 14953 | 056064 | 021040 | 047507 | 042117 |
| 14954 | 056072 | 000042 |        |        |
| 14955 |        |        |        |        |
| 14956 | 056074 | 047101 | 051040 | 020110 |
| 14957 | 056102 | 046103 | 040505 | 020122 |
| 14958 | 056110 | 051050 | 041510 | 031123 |
| 14959 | 056116 | 041040 | 052111 | 021440 |
| 14960 | 056124 | 024465 | 053440 | 051501 |
| 14961 | 056132 | 043440 | 053111 | 047105 |
| 14962 | 056140 | 020056 | 030501 | 020066 |
| 14963 | 056146 | 051050 | 041510 | 030523 |
| 14964 | 056154 | 041040 | 052111 | 021440 |
| 14965 | 056162 | 024470 | 053440 | 051501 |
| 14966 | 056170 | 051440 | 052105 | 005015 |
| 14967 | 056176 | 047117 | 051040 | 040505 |
| 14968 | 056204 | 044504 | 043516 | 052040 |
| 14969 | 056212 | 042510 | 043040 | 046117 |
| 14970 | 056220 | 047514 | 044527 | 043516 |
| 14971 | 056226 | 051040 | 043505 | 051511 |
| 14972 | 056234 | 042524 | 020122 | 052111 |
| 14973 | 056242 | 042040 | 042111 | 047040 |
| 14974 | 056250 | 052117 | 041440 | 047117 |
| 14975 | 056256 | 040524 | 047111 | 053440 |
| 14976 | 056264 | 040510 | 020124 | 051511 |
| 14977 | 056272 | 044440 | 020116 | 043442 |
| 14978 | 056300 | 047517 | 021104 | 000    |
| 14979 |        |        |        |        |
| 14980 | 056305 | 101    | 020116 | 044122 |
| 14981 | 056312 | 041440 | 042514 | 051101 |
| 14982 | 056320 | 024040 | 044122 | 051503 |
| 14983 | 056326 | 020062 | 044502 | 020124 |
| 14984 | 056334 | 032443 | 020051 | 040527 |
| 14985 | 056342 | 020123 | 044507 | 042526 |
| 14986 | 056350 | 027116 | 040440 | 033061 |
| 14987 | 056356 | 024040 | 044122 | 051503 |
| 14988 | 056364 | 020061 | 044502 | 020124 |
| 14989 | 056372 | 034043 | 020051 | 040527 |
| 14990 | 056400 | 020123 | 042523 | 006524 |
| 14991 | 056406 | 012    |        |        |
| 14992 | 056407 | 101    | 046114 | 055040 |
| 14993 | 056414 | 051105 | 051517 | 053440 |
| 14994 | 056422 | 051105 | 020105 | 051127 |
| 14995 | 056430 | 052111 | 042524 | 020116 |
| 14996 | 056436 | 047111 | 051040 | 041110 |
| 14997 | 056444 | 042501 | 020056 | 044124 |
| 14998 | 056452 | 047105 | 052040 | 042510 |
| 14999 | 056460 | 043040 | 046117 | 047514 |
| 15000 | 056466 | 044527 | 043516 | 051040 |
| 15001 | 056474 | 043505 | 051511 | 042524 |
| 15002 | 056502 | 020122 | 044504 | 020104 |
| 15003 | 056510 | 047516 | 020124 | 040510 |
| 15004 | 056516 | 042526 | 053440 | 040510 |

EM54: .ASCII /AN RH CLEAR (RHCS2 BIT #5) WAS GIVEN. A16 (RHCS1 BIT #8) WAS SET/<15><1

.ASCIZ /ON READING THE FOLLOWING REGISTER IT DID NOT CONTAIN WHAT IS IN "GOOD"/

EM56: .ASCII /AN RH CLEAR (RHCS2 BIT #5) WAS GIVEN. A16 (RHCS1 BIT #8) WAS SET/<15><1

.ASCIZ /ALL ZEROS WERE WRITTEN IN RHBAE. THEN THE FOLLOWING REGISTER DID NOT HA

|       |        |        |        |        |
|-------|--------|--------|--------|--------|
| 15005 | 056524 | 020124 | 051511 | 044440 |
| 15006 | 056532 | 020116 | 043442 | 047517 |
| 15007 | 056540 | 021104 | 000    |        |
| 15008 |        |        |        |        |
| 15009 | 056543 | 101    | 020116 | 044122 |
| 15010 | 056550 | 041440 | 042514 | 051101 |
| 15011 | 056556 | 024040 | 044122 | 051503 |
| 15012 | 056564 | 020062 | 044502 | 020124 |
| 15013 | 056572 | 032443 | 020051 | 040527 |
| 15014 | 056600 | 020123 | 044507 | 042526 |
| 15015 | 056606 | 027116 | 040440 | 033461 |
| 15016 | 056614 | 024040 | 044122 | 051503 |
| 15017 | 056622 | 020061 | 044502 | 020124 |
| 15018 | 056630 | 034443 | 020051 | 040527 |
| 15019 | 056636 | 020123 | 042523 | 006524 |
| 15020 | 056644 | 012    |        |        |
| 15021 | 056645 | 117    | 020116 | 042522 |
| 15022 | 056652 | 042101 | 047111 | 020107 |
| 15023 | 056660 | 044124 | 020105 | 047506 |
| 15024 | 056666 | 046114 | 053517 | 047111 |
| 15025 | 056674 | 020107 | 042522 | 044507 |
| 15026 | 056702 | 052123 | 051105 | 044440 |
| 15027 | 056710 | 020124 | 044504 | 020104 |
| 15028 | 056716 | 047516 | 020124 | 047503 |
| 15029 | 056724 | 052116 | 044501 | 020116 |
| 15030 | 056732 | 044127 | 052101 | 044440 |
| 15031 | 056740 | 020123 | 047111 | 021040 |
| 15032 | 056746 | 047507 | 042117 | 000042 |
| 15033 |        |        |        |        |
| 15034 | 056754 | 047101 | 051040 | 020110 |
| 15035 | 056762 | 046103 | 040505 | 020122 |
| 15036 | 056770 | 051050 | 041510 | 031123 |
| 15037 | 056776 | 041040 | 052111 | 021440 |
| 15038 | 057004 | 024470 | 053440 | 051501 |
| 15039 | 057012 | 043440 | 053111 | 047105 |
| 15040 | 057020 | 020056 | 030501 | 020067 |
| 15041 | 057026 | 051050 | 041510 | 030523 |
| 15042 | 057034 | 041040 | 052111 | 021440 |
| 15043 | 057042 | 024471 | 053440 | 051501 |
| 15044 | 057050 | 051440 | 052105 | 005015 |
| 15045 | 057056 | 046101 | 020114 | 042532 |
| 15046 | 057064 | 047522 | 020123 | 042527 |
| 15047 | 057072 | 042522 | 053440 | 044522 |
| 15048 | 057100 | 052124 | 047105 | 044440 |
| 15049 | 057106 | 020116 | 044122 | 040502 |
| 15050 | 057114 | 020105 | 044124 | 047105 |
| 15051 | 057122 | 052040 | 042510 | 043040 |
| 15052 | 057130 | 046117 | 047514 | 044527 |
| 15053 | 057136 | 043516 | 051040 | 043505 |
| 15054 | 057144 | 051511 | 042524 | 020122 |
| 15055 | 057152 | 044504 | 020104 | 047516 |
| 15056 | 057160 | 020124 | 040510 | 042526 |
| 15057 | 057166 | 053440 | 040510 | 020124 |
| 15058 | 057174 | 051511 | 044440 | 020116 |
| 15059 | 057202 | 047507 | 042117 | 005015 |
| 15060 | 057210 | 000    |        |        |

EM60: .ASCII /AN RH CLEAR (RHCS2 BIT #5) WAS GIVEN. A17 (RHCS1 BIT #9) WAS SET/<15><1

.ASCIZ /ON READING THE FOLLOWING REGISTER IT DID NOT CONTAIN WHAT IS IN "GOOD"/

EM62: .ASCII /AN RH CLEAR (RHCS2 BIT #8) WAS GIVEN. A17 (RHCS1 BIT #9) WAS SET/<15><1

.ASCIZ /ALL ZEROS WERE WRITTEN IN RHBAE THEN THE FOLLOWING REGISTER DID NOT HAV

|       |        |        |        |        |
|-------|--------|--------|--------|--------|
| 15061 |        |        |        |        |
| 15062 | 057211 | 101    | 020116 | 044122 |
| 15063 | 057216 | 041440 | 042514 | 051101 |
| 15064 | 057224 | 024040 | 044122 | 051503 |
| 15065 | 057232 | 026462 | 044502 | 020124 |
| 15066 | 057240 | 032443 | 020051 | 040527 |
| 15067 | 057246 | 020123 | 044507 | 042526 |
| 15068 | 057254 | 027116 | 044440 | 020105 |
| 15069 | 057262 | 051050 | 041510 | 030523 |
| 15070 | 057270 | 041040 | 052111 | 021440 |
| 15071 | 057276 | 024466 | 053440 | 051501 |
| 15072 | 057304 | 051440 | 052105 | 005015 |
| 15073 | 057312 | 047117 | 051040 | 040505 |
| 15074 | 057320 | 044504 | 043516 | 052040 |
| 15075 | 057326 | 042510 | 043040 | 046117 |
| 15076 | 057334 | 047514 | 044527 | 043516 |
| 15077 | 057342 | 051040 | 043505 | 051511 |
| 15078 | 057350 | 042524 | 020122 | 052111 |
| 15079 | 057356 | 042040 | 042111 | 047040 |
| 15080 | 057364 | 052117 | 041440 | 047117 |
| 15081 | 057372 | 040524 | 047111 | 053440 |
| 15082 | 057400 | 040510 | 020124 | 051511 |
| 15083 | 057406 | 044440 | 020116 | 043442 |
| 15084 | 057414 | 047517 | 021104 | 000    |
| 15085 |        |        |        |        |
| 15086 | 057421 | 101    | 020116 | 044122 |
| 15087 | 057426 | 041440 | 042514 | 051101 |
| 15088 | 057434 | 024040 | 044122 | 051503 |
| 15089 | 057442 | 026462 | 044502 | 020124 |
| 15090 | 057450 | 032443 | 020051 | 040527 |
| 15091 | 057456 | 020123 | 044507 | 042526 |
| 15092 | 057464 | 027116 | 044440 | 020105 |
| 15093 | 057472 | 051050 | 041510 | 030523 |
| 15094 | 057500 | 041040 | 052111 | 021440 |
| 15095 | 057506 | 024466 | 053440 | 051501 |
| 15096 | 057514 | 051440 | 052105 | 005015 |
| 15097 | 057522 | 046101 | 020114 | 042532 |
| 15098 | 057530 | 047522 | 020123 | 042527 |
| 15099 | 057536 | 042522 | 053440 | 044522 |
| 15100 | 057544 | 052124 | 047105 | 044440 |
| 15101 | 057552 | 020116 | 044122 | 051503 |
| 15102 | 057560 | 020063 | 044124 | 047105 |
| 15103 | 057566 | 052040 | 042510 | 043040 |
| 15104 | 057574 | 046117 | 047514 | 044527 |
| 15105 | 057602 | 043516 | 051040 | 043505 |
| 15106 | 057610 | 051511 | 042524 | 020122 |
| 15107 | 057616 | 044504 | 020104 | 047516 |
| 15108 | 057624 | 020124 | 047503 | 052116 |
| 15109 | 057632 | 044501 | 020116 | 044127 |
| 15110 | 057640 | 052101 | 044440 | 020123 |
| 15111 | 057646 | 047111 | 021040 | 047507 |
| 15112 | 057654 | 042117 | 000042 |        |
| 15113 |        |        |        |        |
| 15114 | 057660 | 044122 | 041440 | 042514 |
| 15115 | 057666 | 051101 | 053440 | 051501 |
| 15116 | 057674 | 043440 | 053111 | 047105 |

EM64: .ASCII /AN RH CLEAR (RHCS2-BIT #5) WAS GIVEN. IE (RHCS1 BIT #6) WAS SET/<15><12

.ASCIZ /ON READING THE FOLLOWING REGISTER IT DID NOT CONTAIN WHAT IS IN "GOOD"/

EM66: .ASCII /AN RH CLEAR (RHCS2-BIT #5) WAS GIVEN. IE (RHCS1 BIT #6) WAS SET/<15><12

.ASCIZ /ALL ZEROS WERE WRITTEN IN RHCS3 THEN THE FOLLOWING REGISTER DID NOT CON

EM70: .ASCII /RH CLEAR WAS GIVEN. TWO SUCCESSIVE "GO" (RHCS1-BIT #0) WAS GIVEN/<15><1

|       |        |        |        |        |
|-------|--------|--------|--------|--------|
| 15117 | 057702 | 020056 | 053524 | 020117 |
| 15118 | 057710 | 052523 | 041503 | 051505 |
| 15119 | 057716 | 044523 | 042526 | 021040 |
| 15120 | 057724 | 047507 | 020042 | 051050 |
| 15121 | 057732 | 041510 | 030523 | 041055 |
| 15122 | 057740 | 052111 | 021440 | 024460 |
| 15123 | 057746 | 053440 | 051501 | 043440 |
| 15124 | 057754 | 053111 | 047105 | 005015 |
| 15125 | 057762 | 044527 | 044124 | 052517 |
| 15126 | 057770 | 020124 | 040527 | 052111 |
| 15127 | 057776 | 047111 | 020107 | 047506 |
| 15128 | 060004 | 020122 | 044124 | 020105 |
| 15129 | 060012 | 044506 | 051522 | 020124 |
| 15130 | 060020 | 043442 | 021117 | 052040 |
| 15131 | 060026 | 020117 | 047503 | 050115 |
| 15132 | 060034 | 042514 | 042524 | 020056 |
| 15133 | 060042 | 044124 | 020105 | 047506 |
| 15134 | 060050 | 046114 | 053517 | 047111 |
| 15135 | 060056 | 020107 | 042522 | 044507 |
| 15136 | 060064 | 052123 | 051105 | 005015 |
| 15137 | 060072 | 044504 | 020104 | 047516 |
| 15138 | 060100 | 020124 | 047503 | 052116 |
| 15139 | 060106 | 044501 | 020116 | 044127 |
| 15140 | 060114 | 052101 | 044440 | 020123 |
| 15141 | 060122 | 047111 | 021040 | 047507 |
| 15142 | 060130 | 042117 | 000042 |        |
| 15143 |        |        |        |        |
| 15144 | 060134 | 044122 | 041440 | 042514 |
| 15145 | 060142 | 051101 | 053440 | 051501 |
| 15146 | 060150 | 043440 | 053111 | 047105 |
| 15147 | 060156 | 040440 | 031040 | 053440 |
| 15148 | 060164 | 051117 | 020104 | 051127 |
| 15149 | 060172 | 052111 | 020105 | 040527 |
| 15150 | 060200 | 020123 | 047504 | 042516 |
| 15151 | 060206 | 043040 | 047522 | 020115 |
| 15152 | 060214 | 020101 | 047514 | 040503 |
| 15153 | 060222 | 044524 | 047117 | 005015 |
| 15154 | 060230 | 040524 | 042507 | 020104 |
| 15155 | 060236 | 051127 | 051106 | 046517 |
| 15156 | 060244 | 040440 | 042116 | 053440 |
| 15157 | 060252 | 052111 | 020110 | 040502 |
| 15158 | 060260 | 020111 | 051050 | 041510 |
| 15159 | 060266 | 031123 | 041040 | 052111 |
| 15160 | 060274 | 021440 | 024463 | 051440 |
| 15161 | 060302 | 052105 | 040440 | 020124 |
| 15162 | 060310 | 044124 | 020105 | 047105 |
| 15163 | 060316 | 006504 | 012    |        |
| 15164 | 060321 | 117    | 020106 | 044124 |
| 15165 | 060326 | 020105 | 051127 | 052111 |
| 15166 | 060334 | 020105 | 044124 | 020105 |
| 15167 | 060342 | 047506 | 046114 | 053517 |
| 15168 | 060350 | 047111 | 020107 | 042522 |
| 15169 | 060356 | 044507 | 052123 | 051105 |
| 15170 | 060364 | 042040 | 042111 | 047040 |
| 15171 | 060372 | 052117 | 041440 | 047117 |
| 15172 | 060400 | 040524 | 047111 | 053440 |

.ASCII /WITHOUT WAITING FOR THE FIRST "GO" TO COMPLETE. THE FOLLOWING REGISTER/

.ASCIZ /DID NOT CONTAIN WHAT IS IN "GOOD"/

EM76: .ASCII /RH CLEAR WAS GIVEN A 2 WORD WRITE WAS DONE FROM A LOCATION/<15><12>

.ASCII /TAGED WRFROM AND WITH BAI (RHCS2 BIT #3) SET AT THE END/<15><12>

.ASCIZ /OF THE WRITE THE FOLLOWING REGISTER DID NOT CONTAIN WHAT IS IN "GOOD"/

|       |        |        |        |        |
|-------|--------|--------|--------|--------|
| 15173 | 060406 | 040510 | 020124 | 051511 |
| 15174 | 060414 | 044440 | 020116 | 043442 |
| 15175 | 060422 | 047517 | 021104 | 000    |
| 15176 |        |        |        |        |
| 15177 | 060427 | 122    | 020110 | 046103 |
| 15178 | 060434 | 040505 | 020122 | 040527 |
| 15179 | 060442 | 020123 | 044507 | 042526 |
| 15180 | 060450 | 020116 | 047101 | 044440 |
| 15181 | 060456 | 041520 | 020113 | 044502 |
| 15182 | 060464 | 020124 | 044123 | 053517 |
| 15183 | 060472 | 020116 | 047111 | 021040 |
| 15184 | 060500 | 050111 | 045503 | 020042 |
| 15185 | 060506 | 040527 | 020123 | 042523 |
| 15186 | 060514 | 006524 | 012    |        |
| 15187 | 060517 | 132    | 051105 | 051517 |
| 15188 | 060524 | 053440 | 051105 | 020105 |
| 15189 | 060532 | 047515 | 042526 | 020104 |
| 15190 | 060540 | 047111 | 047524 | 051040 |
| 15191 | 060546 | 042110 | 027102 | 047440 |
| 15192 | 060554 | 020116 | 042522 | 042101 |
| 15193 | 060562 | 047111 | 020107 | 044122 |
| 15194 | 060570 | 041104 | 052040 | 042510 |
| 15195 | 060576 | 043040 | 046117 | 047514 |
| 15196 | 060604 | 044527 | 043516 | 005015 |
| 15197 | 060612 | 042522 | 044507 | 052123 |
| 15198 | 060620 | 051105 | 042040 | 042111 |
| 15199 | 060626 | 047040 | 052117 | 041440 |
| 15200 | 060634 | 047117 | 040524 | 047111 |
| 15201 | 060642 | 053440 | 040510 | 020124 |
| 15202 | 060650 | 051511 | 044440 | 020116 |
| 15203 | 060656 | 043442 | 047517 | 021104 |
| 15204 | 060664 | 000    |        |        |
| 15205 |        |        |        |        |
| 15206 | 060665 | 122    | 020110 | 046103 |
| 15207 | 060672 | 040505 | 020122 | 040527 |
| 15208 | 060700 | 020123 | 044507 | 042526 |
| 15209 | 060706 | 020116 | 047101 | 044440 |
| 15210 | 060714 | 041520 | 020113 | 044502 |
| 15211 | 060722 | 020124 | 044123 | 053517 |
| 15212 | 060730 | 020116 | 047111 | 021040 |
| 15213 | 060736 | 050111 | 045503 | 020042 |
| 15214 | 060744 | 040527 | 020123 | 042523 |
| 15215 | 060752 | 006524 | 012    |        |
| 15216 | 060755 | 132    | 051105 | 051517 |
| 15217 | 060762 | 053440 | 051105 | 020105 |
| 15218 | 060770 | 047515 | 042526 | 020104 |
| 15219 | 060776 | 047111 | 047524 | 051040 |
| 15220 | 061004 | 042110 | 027102 | 051040 |
| 15221 | 061012 | 042110 | 020102 | 040527 |
| 15222 | 061020 | 020123 | 042522 | 042101 |
| 15223 | 061026 | 020056 | 047101 | 051040 |
| 15224 | 061034 | 020110 | 046103 | 040505 |
| 15225 | 061042 | 020122 | 040527 | 020123 |
| 15226 | 061050 | 044507 | 042526 | 006516 |
| 15227 | 061056 | 012    |        |        |
| 15228 | 061057 | 124    | 042510 | 043040 |

EM104: .ASCII /RH CLEAR WAS GIVEN AN IPCK BIT SHOWN IN "IPCK" WAS SET/<15><12>

.ASCII /ZEROS WERE MOVED INTO RHDB. ON READING RHDB THE FOLLOWING/<15><12>

.ASCIZ /REGISTER DID NOT CONTAIN WHAT IS IN "GOOD"/

EM106: .ASCII /RH CLEAR WAS GIVEN AN IPCK BIT SHOWN IN "IPCK" WAS SET/<15><12>

.ASCII /ZEROS WERE MOVED INTO RHDB. RHDB WAS READ. AN RH CLEAR WAS GIVEN/<15><1

.ASCIZ /THE FOLLOWING REGISTER DID NOT CONTAIN WHAT IS GIVEN IN "GOOD"/



|       |        |        |        |        |
|-------|--------|--------|--------|--------|
| 15229 | 061064 | 046117 | 047514 | 044527 |
| 15230 | 061072 | 043516 | 051040 | 043505 |
| 15231 | 061100 | 051511 | 042524 | 020122 |
| 15232 | 061106 | 044504 | 020104 | 047516 |
| 15233 | 061114 | 020124 | 047503 | 052116 |
| 15234 | 061122 | 044501 | 020116 | 044127 |
| 15235 | 061130 | 052101 | 044440 | 020123 |
| 15236 | 061136 | 044507 | 042526 | 020116 |
| 15237 | 061144 | 047111 | 021040 | 047507 |
| 15238 | 061152 | 042117 | 000042 |        |
| 15239 |        |        |        |        |
| 15240 | 061156 | 044122 | 041440 | 042514 |
| 15241 | 061164 | 051101 | 053440 | 051501 |
| 15242 | 061172 | 043440 | 053111 | 047105 |
| 15243 | 061200 | 020056 | 040440 | 053440 |
| 15244 | 061206 | 044522 | 042524 | 041440 |
| 15245 | 061214 | 042510 | 045503 | 005015 |
| 15246 | 061222 | 040527 | 020123 | 047504 |
| 15247 | 061230 | 042516 | 020056 | 044124 |
| 15248 | 061236 | 020105 | 047506 | 046114 |
| 15249 | 061244 | 053517 | 047111 | 020107 |
| 15250 | 061252 | 042522 | 044507 | 052123 |
| 15251 | 061260 | 051105 | 042040 | 042111 |
| 15252 | 061266 | 047040 | 052117 | 041440 |
| 15253 | 061274 | 047117 | 040524 | 047111 |
| 15254 | 061302 | 053440 | 040510 | 020124 |
| 15255 | 061310 | 051511 | 044440 | 020116 |
| 15256 | 061316 | 043442 | 047517 | 021104 |
| 15257 | 061324 | 000    |        |        |
| 15258 |        |        |        |        |
| 15259 | 061325 | 122    | 020110 | 046103 |
| 15260 | 061332 | 040505 | 020122 | 040527 |
| 15261 | 061340 | 020123 | 044507 | 042526 |
| 15262 | 061346 | 027116 | 020040 | 020101 |
| 15263 | 061354 | 051127 | 052111 | 020105 |
| 15264 | 061362 | 044103 | 041505 | 006513 |
| 15265 | 061370 | 012    |        |        |
| 15266 | 061371 | 127    | 051501 | 042040 |
| 15267 | 061376 | 047117 | 020105 | 044124 |
| 15268 | 061404 | 047105 | 040440 | 047516 |
| 15269 | 061412 | 044124 | 051105 | 051040 |
| 15270 | 061420 | 020110 | 046103 | 040505 |
| 15271 | 061426 | 020122 | 040527 | 020123 |
| 15272 | 061434 | 044507 | 042526 | 027116 |
| 15273 | 061442 | 052040 | 042510 | 043040 |
| 15274 | 061450 | 046117 | 047514 | 044527 |
| 15275 | 061456 | 043516 | 051040 | 043505 |
| 15276 | 061464 | 051511 | 042524 | 006522 |
| 15277 | 061472 | 012    |        |        |
| 15278 | 061473 | 104    | 042111 | 047040 |
| 15279 | 061500 | 052117 | 041440 | 047117 |
| 15280 | 061506 | 040524 | 047111 | 053440 |
| 15281 | 061514 | 040510 | 020124 | 051511 |
| 15282 | 061522 | 044440 | 020116 | 043442 |
| 15283 | 061530 | 047517 | 021104 | 000    |
| 15284 |        |        |        |        |

EM114: .ASCII /RH CLEAR WAS GIVEN. A WRITE CHECK/<15><12>

.ASCIZ /WAS DONE. THE FOLLOWING REGISTER DID NOT CONTAIN WHAT IS IN "GOOD"/

EM116: .ASCII /RH CLEAR WAS GIVEN. A WRITE CHECK/<15><12>

.ASCII /WAS DONE THEN ANOTHER RH CLEAR WAS GIVEN. THE FOLLOWING REGISTER/<15><1

.ASCIZ /DID NOT CONTAIN WHAT IS IN "GOOD"/

|       |        |        |        |        |                                                                                |
|-------|--------|--------|--------|--------|--------------------------------------------------------------------------------|
| 15285 | 061535 | 117    | 020116 | 020101 | EM124: .ASCII /ON A SILO TEST TO TEST DBL RHCS3 BIT #10 THE FOLLOWING/<15><12> |
| 15286 | 061542 | 044523 | 047514 | 052040 |                                                                                |
| 15287 | 061550 | 051505 | 020124 | 047524 |                                                                                |
| 15288 | 061556 | 052040 | 051505 | 020124 |                                                                                |
| 15289 | 061564 | 041104 | 020114 | 044122 |                                                                                |
| 15290 | 061572 | 051503 | 020063 | 044502 |                                                                                |
| 15291 | 061600 | 020124 | 030443 | 020060 |                                                                                |
| 15292 | 061606 | 044124 | 020105 | 047506 |                                                                                |
| 15293 | 061614 | 046114 | 053517 | 047111 |                                                                                |
| 15294 | 061622 | 006507 | 012    |        |                                                                                |
| 15295 | 061625 | 122    | 043505 | 051511 | .ASCIZ /REGISTER DID NOT CONTAIN WHAT IS IN "GOOD"/                            |
| 15296 | 061632 | 042524 | 020122 | 044504 |                                                                                |
| 15297 | 061640 | 020104 | 047516 | 020124 |                                                                                |
| 15298 | 061646 | 047503 | 052116 | 044501 |                                                                                |
| 15299 | 061654 | 020116 | 044127 | 052101 |                                                                                |
| 15300 | 061662 | 044440 | 020123 | 047111 |                                                                                |
| 15301 | 061670 | 021040 | 047507 | 042117 |                                                                                |
| 15302 | 061676 | 000042 |        |        |                                                                                |
| 15303 | 061700 | 042502 | 047506 | 042522 | EM132: .ASCII /BEFORE DATA TRANSFER COMMAND WAS TO/<15><12>                    |
| 15304 | 061706 | 042040 | 052101 | 020101 |                                                                                |
| 15305 | 061714 | 051124 | 047101 | 043123 |                                                                                |
| 15306 | 061722 | 051105 | 041440 | 046517 |                                                                                |
| 15307 | 061730 | 040515 | 042116 | 053440 |                                                                                |
| 15308 | 061736 | 051501 | 052040 | 006517 |                                                                                |
| 15309 | 061744 | 012    |        |        |                                                                                |
| 15310 | 061745 | 102    | 020105 | 044507 | .ASCII /BE GIVEN THE RP DRIVE STATUS REGISTER DID/<15><12>                     |
| 15311 | 061752 | 042526 | 020116 | 044124 |                                                                                |
| 15312 | 061760 | 020105 | 050122 | 042040 |                                                                                |
| 15313 | 061766 | 044522 | 042526 | 051440 |                                                                                |
| 15314 | 061774 | 040524 | 052524 | 020123 |                                                                                |
| 15315 | 062002 | 042522 | 044507 | 052123 |                                                                                |
| 15316 | 062010 | 051105 | 042040 | 042111 |                                                                                |
| 15317 | 062016 | 005015 |        |        |                                                                                |
| 15318 | 062020 | 047516 | 020124 | 047503 | .ASCIZ /NOT CONTAIN WHAT IS IN "GOOD"/                                         |
| 15319 | 062026 | 052116 | 044501 | 020116 |                                                                                |
| 15320 | 062034 | 044127 | 052101 | 044440 |                                                                                |
| 15321 | 062042 | 020123 | 047111 | 021040 |                                                                                |
| 15322 | 062050 | 047507 | 042117 | 000042 |                                                                                |
| 15323 | 062056 | 042502 | 047506 | 042522 | EM133: .ASCII /BEFORE DATA TRANSFER COMMAND WAS TO/<15><12>                    |
| 15324 | 062064 | 042040 | 052101 | 020101 |                                                                                |
| 15325 | 062072 | 051124 | 047101 | 043123 |                                                                                |
| 15326 | 062100 | 051105 | 041440 | 046517 |                                                                                |
| 15327 | 062106 | 040515 | 042116 | 053440 |                                                                                |
| 15328 | 062114 | 051501 | 052040 | 006517 |                                                                                |
| 15329 | 062122 | 012    |        |        |                                                                                |
| 15330 | 062123 | 102    | 020105 | 044507 | .ASCII /BE GIVEN THE RS DRIVE STATUS REGISTER DID/<15><12>                     |
| 15331 | 062130 | 042526 | 020116 | 044124 |                                                                                |
| 15332 | 062136 | 020105 | 051522 | 042040 |                                                                                |
| 15333 | 062144 | 044522 | 042526 | 051440 |                                                                                |
| 15334 | 062152 | 040524 | 052524 | 020123 |                                                                                |
| 15335 | 062160 | 042522 | 044507 | 052123 |                                                                                |
| 15336 | 062166 | 051105 | 042040 | 042111 |                                                                                |
| 15337 | 062174 | 005015 |        |        |                                                                                |
| 15338 | 062176 | 047516 | 020124 | 047503 | .ASCIZ /NOT CONTAIN WHAT IS IN "GOOD"/                                         |
| 15339 | 062204 | 052116 | 044501 | 020116 |                                                                                |
| 15340 | 062212 | 044127 | 052101 | 044440 |                                                                                |

|       |        |        |        |        |                                                                      |
|-------|--------|--------|--------|--------|----------------------------------------------------------------------|
| 15341 | 062220 | 020123 | 047111 | 021040 |                                                                      |
| 15342 | 062226 | 047507 | 042117 | 000042 |                                                                      |
| 15343 | 062234 | 042502 | 047506 | 042522 | EM134: .ASCII /BEFORE DATA TRANSFER COMMAND WAS TO BE GIVEN/<15><12> |
| 15344 | 062242 | 042040 | 052101 | 020101 |                                                                      |
| 15345 | 062250 | 051124 | 047101 | 043123 |                                                                      |
| 15346 | 062256 | 051105 | 041440 | 046517 |                                                                      |
| 15347 | 062264 | 040515 | 042116 | 053440 |                                                                      |
| 15348 | 062272 | 051501 | 052040 | 020117 |                                                                      |
| 15349 | 062300 | 042502 | 043440 | 053111 |                                                                      |
| 15350 | 062306 | 047105 | 005015 |        |                                                                      |
| 15351 | 062312 | 044124 | 020105 | 040515 | .ASCII /THE MAG TAPE DRIVE STATUS REGISTER DID NOT/<15><12>          |
| 15352 | 062320 | 020107 | 040524 | 042520 |                                                                      |
| 15353 | 062326 | 042040 | 044522 | 042526 |                                                                      |
| 15354 | 062334 | 051440 | 040524 | 052524 |                                                                      |
| 15355 | 062342 | 020123 | 042522 | 044507 |                                                                      |
| 15356 | 062350 | 052123 | 051105 | 042040 |                                                                      |
| 15357 | 062356 | 042111 | 047040 | 052117 |                                                                      |
| 15358 | 062364 | 005015 |        |        |                                                                      |
| 15359 | 062366 | 047503 | 052116 | 044501 | .ASCIZ /CONTAIN WHAT IS IN RHDS1-GOOD/                               |
| 15360 | 062374 | 020116 | 044127 | 052101 |                                                                      |
| 15361 | 062402 | 044440 | 020123 | 047111 |                                                                      |
| 15362 | 062410 | 051040 | 042110 | 030523 |                                                                      |
| 15363 | 062416 | 043455 | 047517 | 000104 |                                                                      |
| 15364 | 062424 | 040527 | 020123 | 040527 | EM135: .ASCII /WAS WAITING FOR A BIT TO SET IN A REGISTER/<15><12>   |
| 15365 | 062432 | 052111 | 047111 | 020107 |                                                                      |
| 15366 | 062440 | 047506 | 020122 | 020101 |                                                                      |
| 15367 | 062446 | 044502 | 020124 | 047524 |                                                                      |
| 15368 | 062454 | 051440 | 052105 | 044440 |                                                                      |
| 15369 | 062462 | 020116 | 020101 | 042522 |                                                                      |
| 15370 | 062470 | 044507 | 052123 | 051105 |                                                                      |
| 15371 | 062476 | 005015 |        |        |                                                                      |
| 15372 | 062500 | 044507 | 020124 | 047111 | .ASCIZ /BIT IN QUESTION IS IN "BIT WAITED"/<15><12>                  |
| 15373 | 062506 | 050440 | 042525 | 052123 |                                                                      |
| 15374 | 062514 | 047511 | 020116 | 051511 |                                                                      |
| 15375 | 062522 | 044440 | 020116 | 041042 |                                                                      |
| 15376 | 062530 | 052111 | 053440 | 044501 |                                                                      |
| 15377 | 062536 | 042524 | 021104 | 005015 |                                                                      |
| 15378 | 062544 | 000    |        |        |                                                                      |
| 15379 | 062545 | 122    | 043505 | 051511 | .ASCIZ /REGISTER ADDRESS IN QUESTION IS IN "REG. ADDR"/              |
| 15380 | 062552 | 042524 | 020122 | 042101 |                                                                      |
| 15381 | 062560 | 051104 | 051505 | 020123 |                                                                      |
| 15382 | 062566 | 047111 | 050440 | 042525 |                                                                      |
| 15383 | 062574 | 052123 | 047511 | 020116 |                                                                      |
| 15384 | 062602 | 051511 | 044440 | 020116 |                                                                      |
| 15385 | 062610 | 051042 | 043505 | 020056 |                                                                      |
| 15386 | 062616 | 042101 | 051104 | 000042 |                                                                      |
| 15387 | 062624 | 040527 | 020123 | 040527 | EM136: .ASCII /WAS WAITING FOR A BIT TO RESET IN A REGISTER/<15><12> |
| 15388 | 062632 | 052111 | 047111 | 020107 |                                                                      |
| 15389 | 062640 | 047506 | 020122 | 020101 |                                                                      |
| 15390 | 062646 | 044502 | 020124 | 047524 |                                                                      |
| 15391 | 062654 | 051040 | 051505 | 052105 |                                                                      |
| 15392 | 062662 | 044440 | 020116 | 020101 |                                                                      |
| 15393 | 062670 | 042522 | 044507 | 052123 |                                                                      |
| 15394 | 062676 | 051105 | 005015 |        |                                                                      |
| 15395 | 062702 | 044502 | 020124 | 047111 | .ASCIZ /BIT IN QUESTION IS IN "BIT WAITED"/<15><12>                  |
| 15396 | 062710 | 050440 | 042525 | 052123 |                                                                      |

|       |        |        |        |        |
|-------|--------|--------|--------|--------|
| 15397 | 062716 | 047511 | 020116 | 051511 |
| 15398 | 062724 | 044440 | 020116 | 041042 |
| 15399 | 062732 | 052111 | 053440 | 044501 |
| 15400 | 062740 | 042524 | 021104 | 005015 |
| 15401 | 062746 | 000    |        |        |
| 15402 | 062747 | 122    | 043505 | 051511 |
| 15403 | 062754 | 042524 | 020122 | 042101 |
| 15404 | 062762 | 051104 | 051505 | 020123 |
| 15405 | 062770 | 047111 | 050440 | 042525 |
| 15406 | 062776 | 052123 | 047511 | 020116 |
| 15407 | 063004 | 051511 | 044440 | 020116 |
| 15408 | 063012 | 051042 | 043505 | 020056 |
| 15409 | 063020 | 042101 | 051104 | 000042 |
| 15410 | 063026 | 047117 | 053440 | 044522 |
| 15411 | 063034 | 044524 | 043516 | 040440 |
| 15412 | 063042 | 042116 | 051040 | 040505 |
| 15413 | 063050 | 044504 | 043516 | 052040 |
| 15414 | 063056 | 042510 | 051040 | 043505 |
| 15415 | 063064 | 051511 | 042524 | 020122 |
| 15416 | 063072 | 047111 | 021040 | 042522 |
| 15417 | 063100 | 027107 | 040440 | 042104 |
| 15418 | 063106 | 021122 | 005015 |        |
| 15419 | 063112 | 052111 | 042040 | 042111 |
| 15420 | 063120 | 047040 | 052117 | 041440 |
| 15421 | 063126 | 047117 | 040524 | 047111 |
| 15422 | 063134 | 042440 | 050130 | 041505 |
| 15423 | 063142 | 042524 | 020104 | 040526 |
| 15424 | 063150 | 052514 | 000105 |        |
| 15425 | 063154 | 044122 | 041440 | 042514 |
| 15426 | 063162 | 051101 | 053440 | 051501 |
| 15427 | 063170 | 043440 | 053111 | 047105 |
| 15428 | 063176 | 040440 | 020116 | 050111 |
| 15429 | 063204 | 045503 | 041040 | 052111 |
| 15430 | 063212 | 051440 | 047510 | 047127 |
| 15431 | 063220 | 044440 | 020116 | 044442 |
| 15432 | 063226 | 041520 | 021113 | 053440 |
| 15433 | 063234 | 051501 | 051440 | 052105 |
| 15434 | 063242 | 005015 |        |        |
| 15435 | 063244 | 042532 | 047522 | 020123 |
| 15436 | 063252 | 042527 | 042522 | 046440 |
| 15437 | 063260 | 053117 | 042105 | 044440 |
| 15438 | 063266 | 052116 | 020117 | 044122 |
| 15439 | 063274 | 041104 | 020056 | 047117 |
| 15440 | 063302 | 051040 | 040505 | 044504 |
| 15441 | 063310 | 043516 | 020040 | 044124 |
| 15442 | 063316 | 020105 | 047506 | 046114 |
| 15443 | 063324 | 053517 | 047111 | 006507 |
| 15444 | 063332 | 012    |        |        |
| 15445 | 063333 | 122    | 043505 | 051511 |
| 15446 | 063340 | 042524 | 020122 | 044504 |
| 15447 | 063346 | 020104 | 047516 | 020124 |
| 15448 | 063354 | 047503 | 052116 | 044501 |
| 15449 | 063362 | 020116 | 044127 | 052101 |
| 15450 | 063370 | 044440 | 020123 | 047111 |
| 15451 | 063376 | 021040 | 047507 | 042117 |
| 15452 | 063404 | 000042 |        |        |

.ASCIZ /REGISTER ADDRESS IN QUESTION IS IN "REG. ADDR"/

EM137: .ASCII /ON WRITING AND READING THE REGISTER IN "REG. ADDR"/&lt;15&gt;&lt;12&gt;

.ASCIZ /IT DID NOT CONTAIN EXPECTED VALUE/

EM140: .ASCII /RH CLEAR WAS GIVEN AN IPCK BIT SHOWN IN "IPCK" WAS SET/&lt;15&gt;&lt;12&gt;

.ASCII /ZEROS WERE MOVED INTO RHDB. ON READING THE FOLLOWING/&lt;15&gt;&lt;12&gt;

.ASCIZ /REGISTER DID NOT CONTAIN WHAT IS IN "GOOD"/

|       |        |        |        |        |                                                                                  |
|-------|--------|--------|--------|--------|----------------------------------------------------------------------------------|
| 15453 | 063406 | 043101 | 042524 | 020122 | EM141: .ASCII /AFTER CLEARING THE RH AND WRITING TWO WORD INTO RHDB AND/<15><12> |
| 15454 | 063414 | 046103 | 040505 | 044522 |                                                                                  |
| 15455 | 063422 | 043516 | 052040 | 042510 |                                                                                  |
| 15456 | 063430 | 051040 | 020110 | 047101 |                                                                                  |
| 15457 | 063436 | 020104 | 051127 | 052111 |                                                                                  |
| 15458 | 063444 | 047111 | 020107 | 053524 |                                                                                  |
| 15459 | 063452 | 020117 | 047527 | 042122 |                                                                                  |
| 15460 | 063460 | 044440 | 052116 | 020117 |                                                                                  |
| 15461 | 063466 | 044122 | 041104 | 040440 |                                                                                  |
| 15462 | 063474 | 042116 | 005015 |        |                                                                                  |
| 15463 | 063500 | 042522 | 042101 | 047111 | .ASCIZ /READING IT BACK TWICE, CAUSED RHCS1 TO HAVE WRONG VALUE GIVEN IN "BAD"/  |
| 15464 | 063506 | 020107 | 052111 | 041040 |                                                                                  |
| 15465 | 063514 | 041501 | 020113 | 053524 |                                                                                  |
| 15466 | 063522 | 041511 | 026105 | 041440 |                                                                                  |
| 15467 | 063530 | 052501 | 042523 | 020104 |                                                                                  |
| 15468 | 063536 | 044122 | 051503 | 020061 |                                                                                  |
| 15469 | 063544 | 047524 | 044040 | 053101 |                                                                                  |
| 15470 | 063552 | 020105 | 051127 | 047117 |                                                                                  |
| 15471 | 063560 | 020107 | 040526 | 052514 |                                                                                  |
| 15472 | 063566 | 020105 | 044507 | 042526 |                                                                                  |
| 15473 | 063574 | 020116 | 047111 | 021040 |                                                                                  |
| 15474 | 063602 | 040502 | 021104 | 000    |                                                                                  |
| 15475 | 063607 | 101    | 052106 | 051105 | EM142: .ASCII /AFTER CLEARING THE RH AND WRITING TWO WORD INTO RHDB AND/<15><12> |
| 15476 | 063614 | 041440 | 042514 | 051101 |                                                                                  |
| 15477 | 063622 | 047111 | 020107 | 044124 |                                                                                  |
| 15478 | 063630 | 020105 | 044122 | 040440 |                                                                                  |
| 15479 | 063636 | 042116 | 053440 | 044522 |                                                                                  |
| 15480 | 063644 | 044524 | 043516 | 052040 |                                                                                  |
| 15481 | 063652 | 047527 | 053440 | 051117 |                                                                                  |
| 15482 | 063660 | 020104 | 047111 | 047524 |                                                                                  |
| 15483 | 063666 | 051040 | 042110 | 020102 |                                                                                  |
| 15484 | 063674 | 047101 | 006504 | 012    |                                                                                  |
| 15485 | 063701 | 122    | 040505 | 044504 | .ASCIZ /READING IT BACK TWICE, CAUSED RHCS3 TO HAVE WRONG VALUE GIVEN IN "BAD"/  |
| 15486 | 063706 | 043516 | 044440 | 020124 |                                                                                  |
| 15487 | 063714 | 040502 | 045503 | 052040 |                                                                                  |
| 15488 | 063722 | 044527 | 042503 | 020054 |                                                                                  |
| 15489 | 063730 | 040503 | 051525 | 042105 |                                                                                  |
| 15490 | 063736 | 051040 | 041510 | 031523 |                                                                                  |
| 15491 | 063744 | 052040 | 020117 | 040510 |                                                                                  |
| 15492 | 063752 | 042526 | 053440 | 047522 |                                                                                  |
| 15493 | 063760 | 043516 | 053040 | 046101 |                                                                                  |
| 15494 | 063766 | 042525 | 043440 | 053111 |                                                                                  |
| 15495 | 063774 | 047105 | 044440 | 020116 |                                                                                  |
| 15496 | 064002 | 041042 | 042101 | 000042 |                                                                                  |
| 15497 | 064010 | 043101 | 042524 | 020122 | EM143: .ASCII /AFTER CLEARING THE RH AND WRITING TWO WORD INTO RHDB AND/<15><12> |
| 15498 | 064016 | 046103 | 040505 | 044522 |                                                                                  |
| 15499 | 064024 | 043516 | 052040 | 042510 |                                                                                  |
| 15500 | 064032 | 051040 | 020110 | 047101 |                                                                                  |
| 15501 | 064040 | 020104 | 051127 | 052111 |                                                                                  |
| 15502 | 064046 | 047111 | 020107 | 053524 |                                                                                  |
| 15503 | 064054 | 020117 | 047527 | 042122 |                                                                                  |
| 15504 | 064062 | 044440 | 052116 | 020117 |                                                                                  |
| 15505 | 064070 | 044122 | 041104 | 040440 |                                                                                  |
| 15506 | 064076 | 042116 | 005015 |        |                                                                                  |
| 15507 | 064102 | 042522 | 042101 | 047111 | .ASCIZ /READING IT BACK TWICE, CAUSED RHBA TO HAVE WRONG VALUE GIVEN IN "BAD"/   |
| 15508 | 064110 | 020107 | 052111 | 041040 |                                                                                  |

|       |        |        |        |        |
|-------|--------|--------|--------|--------|
| 15509 | 064116 | 041501 | 020113 | 053524 |
| 15510 | 064124 | 041511 | 026105 | 041440 |
| 15511 | 064132 | 052501 | 042523 | 020104 |
| 15512 | 064140 | 044122 | 040502 | 052040 |
| 15513 | 064146 | 020117 | 040510 | 042526 |
| 15514 | 064154 | 053440 | 047522 | 043516 |
| 15515 | 064162 | 053040 | 046101 | 042525 |
| 15516 | 064170 | 043440 | 053111 | 047105 |
| 15517 | 064176 | 044440 | 020116 | 041042 |
| 15518 | 064204 | 042101 | 000042 |        |
| 15519 | 064210 | 043101 | 042524 | 020122 |
| 15520 | 064216 | 046103 | 040505 | 044522 |
| 15521 | 064224 | 043516 | 052040 | 042510 |
| 15522 | 064232 | 051040 | 020110 | 047101 |
| 15523 | 064240 | 020104 | 051127 | 052111 |
| 15524 | 064246 | 047111 | 020107 | 053524 |
| 15525 | 064254 | 020117 | 047527 | 042122 |
| 15526 | 064262 | 044440 | 052116 | 020117 |
| 15527 | 064270 | 044122 | 041104 | 040440 |
| 15528 | 064276 | 042116 | 005015 |        |
| 15529 | 064302 | 042522 | 042101 | 047111 |
| 15530 | 064310 | 020107 | 052111 | 041040 |
| 15531 | 064316 | 041501 | 020113 | 053524 |
| 15532 | 064324 | 041511 | 026105 | 041440 |
| 15533 | 064332 | 052501 | 042523 | 020104 |
| 15534 | 064340 | 044122 | 040502 | 020105 |
| 15535 | 064346 | 047524 | 044040 | 053101 |
| 15536 | 064354 | 020105 | 051127 | 047117 |
| 15537 | 064362 | 020107 | 040526 | 052514 |
| 15538 | 064370 | 020105 | 044507 | 042526 |
| 15539 | 064376 | 020116 | 047111 | 021040 |
| 15540 | 064404 | 040502 | 021104 | 000    |
| 15541 | 064411 | 101    | 052106 | 051105 |
| 15542 | 064416 | 041440 | 042514 | 051101 |
| 15543 | 064424 | 047111 | 020107 | 044124 |
| 15544 | 064432 | 020105 | 044122 | 040440 |
| 15545 | 064440 | 042116 | 053440 | 044522 |
| 15546 | 064446 | 044524 | 043516 | 052040 |
| 15547 | 064454 | 047527 | 053440 | 051117 |
| 15548 | 064462 | 020104 | 047111 | 047524 |
| 15549 | 064470 | 051040 | 042110 | 020102 |
| 15550 | 064476 | 047101 | 006504 | 012    |
| 15551 | 064503 | 122    | 040505 | 044504 |
| 15552 | 064510 | 043516 | 044440 | 020124 |
| 15553 | 064516 | 040502 | 045503 | 052040 |
| 15554 | 064524 | 044527 | 042503 | 020054 |
| 15555 | 064532 | 040503 | 051525 | 042105 |
| 15556 | 064540 | 051040 | 053510 | 020103 |
| 15557 | 064546 | 047524 | 044040 | 053101 |
| 15558 | 064554 | 020105 | 051127 | 047117 |
| 15559 | 064562 | 020107 | 040526 | 052514 |
| 15560 | 064570 | 020105 | 044507 | 042526 |
| 15561 | 064576 | 020116 | 047111 | 021040 |
| 15562 | 064604 | 040502 | 021104 | 000    |
| 15563 |        |        |        |        |
| 15564 | 064611 | 101    | 042040 | 053105 |

EM144: .ASCII /AFTER CLEARING THE RH AND WRITING TWO WORD INTO RHDB AND/<15><12>

.ASCIZ /READING IT BACK TWICE, CAUSED RHBAE TO HAVE WRONG VALUE GIVEN IN "BAD"/

EM145: .ASCII /AFTER CLEARING THE RH AND WRITING TWO WORD INTO RHDB AND/<15><12>

.ASCIZ /READING IT BACK TWICE, CAUSED RHWC TO HAVE WRONG VALUE GIVEN IN "BAD"/

EM146: .ASCII /A DEVICE BASE ADDRESS DID NOT TIME OUT BUT/<15><12>

|       |        |        |        |        |                                                                 |
|-------|--------|--------|--------|--------|-----------------------------------------------------------------|
| 15565 | 064616 | 041511 | 020105 | 040502 |                                                                 |
| 15566 | 064624 | 042523 | 040440 | 042104 |                                                                 |
| 15567 | 064632 | 042522 | 051523 | 042040 |                                                                 |
| 15568 | 064640 | 042111 | 047040 | 052117 |                                                                 |
| 15569 | 064646 | 052040 | 046511 | 020105 |                                                                 |
| 15570 | 064654 | 052517 | 020124 | 052502 |                                                                 |
| 15571 | 064662 | 006524 | 012    |        |                                                                 |
| 15572 | 064665 | 124    | 042510 | 041440 | .ASCII /THE CORRESPONDING VECTOR DID TIME OUT/<<15><12>         |
| 15573 | 064672 | 051117 | 042522 | 050123 |                                                                 |
| 15574 | 064700 | 047117 | 044504 | 043516 |                                                                 |
| 15575 | 064706 | 053040 | 041505 | 047524 |                                                                 |
| 15576 | 064714 | 020122 | 044504 | 020104 |                                                                 |
| 15577 | 064722 | 044524 | 042515 | 047440 |                                                                 |
| 15578 | 064730 | 052125 | 006456 | 012    |                                                                 |
| 15579 | 064735 | 110    | 052111 | 041440 | .ASCIZ /HIT CONTINUE TO REPEAT VECTOR TIMEOUT/                  |
| 15580 | 064742 | 047117 | 044524 | 052516 |                                                                 |
| 15581 | 064750 | 020105 | 047524 | 051040 |                                                                 |
| 15582 | 064756 | 050105 | 040505 | 020124 |                                                                 |
| 15583 | 064764 | 042526 | 052103 | 051117 |                                                                 |
| 15584 | 064772 | 052040 | 046511 | 047505 |                                                                 |
| 15585 | 065000 | 052125 | 000    |        |                                                                 |
| 15586 | 065003 | 101    | 042040 | 053105 | EM147: .ASCII /A DEVICE BASE ADDRESS DID NOT TIME OUT/<<15><12> |
| 15587 | 065010 | 041511 | 020105 | 040502 |                                                                 |
| 15588 | 065016 | 042523 | 040440 | 042104 |                                                                 |
| 15589 | 065024 | 042522 | 051523 | 042040 |                                                                 |
| 15590 | 065032 | 042111 | 047040 | 052117 |                                                                 |
| 15591 | 065040 | 052040 | 046511 | 020105 |                                                                 |
| 15592 | 065046 | 052517 | 006524 | 012    |                                                                 |
| 15593 | 065053 | 102    | 052125 | 047040 | .ASCIZ /BUT NO UNIT NUMBERS HAD APPROPRIATE DRIVE TYPES/        |
| 15594 | 065060 | 020117 | 047125 | 052111 |                                                                 |
| 15595 | 065066 | 047040 | 046525 | 042502 |                                                                 |
| 15596 | 065074 | 051522 | 044040 | 042101 |                                                                 |
| 15597 | 065102 | 040440 | 050120 | 047522 |                                                                 |
| 15598 | 065110 | 051120 | 040511 | 042524 |                                                                 |
| 15599 | 065116 | 042040 | 044522 | 042526 |                                                                 |
| 15600 | 065124 | 052040 | 050131 | 051505 |                                                                 |
| 15601 | 065132 | 000    |        |        |                                                                 |
| 15602 |        |        |        |        |                                                                 |
| 15603 |        |        |        |        |                                                                 |
| 15604 | 065133 | 120    | 004503 | 044122 | DH1: .ASCII /PC RHDT/                                           |
| 15605 | 065140 | 052104 |        |        |                                                                 |
| 15606 |        |        |        |        |                                                                 |
| 15607 | 065142 | 041520 | 052411 | 044516 | DH5: .ASCII /PC UNIBUS ADDRESS ON WHICH TIME OUT OCCURRED/      |
| 15608 | 065150 | 052502 | 020123 | 042101 |                                                                 |
| 15609 | 065156 | 051104 | 051505 | 020123 |                                                                 |
| 15610 | 065164 | 047117 | 053440 | 044510 |                                                                 |
| 15611 | 065172 | 044103 | 052040 | 046511 |                                                                 |
| 15612 | 065200 | 020105 | 052517 | 020124 |                                                                 |
| 15613 | 065206 | 041517 | 052503 | 051122 |                                                                 |
| 15614 | 065214 | 042105 |        |        |                                                                 |
| 15615 |        |        |        |        |                                                                 |
| 15616 | 065216 | 041520 | 052011 | 051505 | DH6: .ASCII /PC TEST NO RHCS2 RHCS2/<<15><12>                   |
| 15617 | 065224 | 020124 | 047516 | 051040 |                                                                 |
| 15618 | 065232 | 041510 | 031123 | 051011 |                                                                 |
| 15619 | 065240 | 041510 | 031123 | 005015 |                                                                 |
| 15620 | 065246 | 004411 | 047507 | 042117 | .ASCIZ / GOOD BAD/                                              |

|       |        |        |        |        |       |        |     |      |       |                |               |
|-------|--------|--------|--------|--------|-------|--------|-----|------|-------|----------------|---------------|
| 15621 | 065254 | 041011 | 042101 | 000    |       |        |     |      |       |                |               |
| 15622 |        |        |        |        |       |        |     |      |       |                |               |
| 15623 | 065261 | 120    | 004503 | 042524 | DH7:  | .ASCII | /PC | TEST | RHDB  | RHDB/<15><12>  |               |
| 15624 | 065266 | 052123 | 051011 | 042110 |       |        |     |      |       |                |               |
| 15625 | 065274 | 004502 | 044122 | 041104 |       |        |     |      |       |                |               |
| 15626 | 065302 | 005015 |        |        |       |        |     |      |       |                |               |
| 15627 | 065304 | 047011 | 004517 | 047507 |       | .ASCIZ | /   | NO   | GOOD  | BAD/           |               |
| 15628 | 065312 | 042117 | 041011 | 042101 |       |        |     |      |       |                |               |
| 15629 | 065320 | 000    |        |        |       |        |     |      |       |                |               |
| 15630 |        |        |        |        |       |        |     |      |       |                |               |
| 15631 | 065321 | 120    | 004503 | 042524 | DH11: | .ASCII | /PC | TEST | RHCS1 | RHCS1/<15><12> |               |
| 15632 | 065326 | 052123 | 051011 | 041510 |       |        |     |      |       |                |               |
| 15633 | 065334 | 030523 | 051011 | 041510 |       |        |     |      |       |                |               |
| 15634 | 065342 | 030523 | 005015 |        |       |        |     |      |       |                |               |
| 15635 | 065346 | 047011 | 004517 | 047507 |       | .ASCIZ | /   | NO   | GOOD  | BAD/           |               |
| 15636 | 065354 | 042117 | 041011 | 042101 |       |        |     |      |       |                |               |
| 15637 | 065362 | 000    |        |        |       |        |     |      |       |                |               |
| 15638 |        |        |        |        |       |        |     |      |       |                |               |
| 15639 | 065363 | 120    | 004503 | 042524 | DH12: | .ASCII | /PC | TEST | RHCS3 | RHCS3/<15><12> |               |
| 15640 | 065370 | 052123 | 051011 | 041510 |       |        |     |      |       |                |               |
| 15641 | 065376 | 031523 | 051011 | 041510 |       |        |     |      |       |                |               |
| 15642 | 065404 | 031523 | 005015 |        |       |        |     |      |       |                |               |
| 15643 | 065410 | 047011 | 004517 | 047507 |       | .ASCIZ | /   | NO   | GOOD  | BAD/           |               |
| 15644 | 065416 | 042117 | 041011 | 042101 |       |        |     |      |       |                |               |
| 15645 | 065424 | 000    |        |        |       |        |     |      |       |                |               |
| 15646 |        |        |        |        |       |        |     |      |       |                |               |
| 15647 | 065425 | 120    | 004503 | 042524 | DH13: | .ASCII | /PC | TEST | RHBA  | RHBA/<15><12>  |               |
| 15648 | 065432 | 052123 | 051011 | 041110 |       |        |     |      |       |                |               |
| 15649 | 065440 | 004501 | 044122 | 040502 |       |        |     |      |       |                |               |
| 15650 | 065446 | 005015 |        |        |       |        |     |      |       |                |               |
| 15651 | 065450 | 047011 | 004517 | 047507 |       | .ASCIZ | /   | NO   | GOOD  | BAD/           |               |
| 15652 | 065456 | 042117 | 041011 | 042101 |       |        |     |      |       |                |               |
| 15653 | 065464 | 000    |        |        |       |        |     |      |       |                |               |
| 15654 |        |        |        |        |       |        |     |      |       |                |               |
| 15655 | 065465 | 120    | 004503 | 042524 | DH14: | .ASCII | /PC | TEST | RHBAE | RHBAE/<15><12> |               |
| 15656 | 065472 | 052123 | 051011 | 041110 |       |        |     |      |       |                |               |
| 15657 | 065500 | 042501 | 051011 | 041110 |       |        |     |      |       |                |               |
| 15658 | 065506 | 042501 | 005015 |        |       |        |     |      |       |                |               |
| 15659 | 065512 | 047011 | 004517 | 047507 |       | .ASCIZ | /   | NO   | GOOD  | BAD/           |               |
| 15660 | 065520 | 042117 | 041011 | 042101 |       |        |     |      |       |                |               |
| 15661 | 065526 | 000    |        |        |       |        |     |      |       |                |               |
| 15662 |        |        |        |        |       |        |     |      |       |                |               |
| 15663 | 065527 | 120    | 004503 | 042524 | DH15: | .ASCII | /PC | TEST | RHWC  | RHWC/<15><12>  |               |
| 15664 | 065534 | 052123 | 051011 | 053510 |       |        |     |      |       |                |               |
| 15665 | 065542 | 004503 | 044122 | 041527 |       |        |     |      |       |                |               |
| 15666 | 065550 | 005015 |        |        |       |        |     |      |       |                |               |
| 15667 | 065552 | 047011 | 004517 | 047507 |       | .ASCIZ | /   | NO   | GOOD  | BAD/           |               |
| 15668 | 065560 | 042117 | 041011 | 042101 |       |        |     |      |       |                |               |
| 15669 | 065566 | 000    |        |        |       |        |     |      |       |                |               |
| 15670 |        |        |        |        |       |        |     |      |       |                |               |
| 15671 | 065567 | 120    | 004503 | 042524 | DH24: | .ASCII | /PC | TEST | WORD  | RHDB           | RHDB/<15><12> |
| 15672 | 065574 | 052123 | 053411 | 051117 |       |        |     |      |       |                |               |
| 15673 | 065602 | 004504 | 044122 | 041104 |       |        |     |      |       |                |               |
| 15674 | 065610 | 051011 | 042110 | 006502 |       |        |     |      |       |                |               |
| 15675 | 065616 | 012    |        |        |       |        |     |      |       |                |               |
| 15676 | 065617 | 011    | 047516 | 047011 |       | .ASCIZ | /   | NO   | NO    | GOOD           | BAD/          |



|       |        |        |        |        |        |        |     |      |       |                |                |  |
|-------|--------|--------|--------|--------|--------|--------|-----|------|-------|----------------|----------------|--|
| 15677 | 065624 | 004517 | 047507 | 042117 |        |        |     |      |       |                |                |  |
| 15678 | 065632 | 041011 | 042101 | 000    |        |        |     |      |       |                |                |  |
| 15679 |        |        |        |        |        |        |     |      |       |                |                |  |
| 15680 | 065637 | 120    | 004503 | 042524 | DH33:  | .ASCII | /PC | TEST | RHER1 | RHER1/<15><12> |                |  |
| 15681 | 065644 | 052123 | 051011 | 042510 |        |        |     |      |       |                |                |  |
| 15682 | 065652 | 030522 | 051011 | 042510 |        |        |     |      |       |                |                |  |
| 15683 | 065660 | 030522 | 005015 |        |        |        |     |      |       |                |                |  |
| 15684 | 065664 | 047011 | 004517 | 047507 |        | .ASCIZ | /   | NO   | GOOD  | BAD/           |                |  |
| 15685 | 065672 | 042117 | 041011 | 042101 |        |        |     |      |       |                |                |  |
| 15686 | 065700 | 000    |        |        |        |        |     |      |       |                |                |  |
| 15687 |        |        |        |        |        |        |     |      |       |                |                |  |
| 15688 | 065701 | 120    | 004503 | 042524 | DH45:  | .ASCII | /PC | TEST | RHDA  | RHDA/<15><12>  |                |  |
| 15689 | 065706 | 052123 | 051011 | 042110 |        |        |     |      |       |                |                |  |
| 15690 | 065714 | 004501 | 044122 | 040504 |        |        |     |      |       |                |                |  |
| 15691 | 065722 | 005015 |        |        |        |        |     |      |       |                |                |  |
| 15692 | 065724 | 047011 | 004517 | 047507 |        | .ASCIZ | /   | NO   | GOOD  | BAD/           |                |  |
| 15693 | 065732 | 042117 | 041011 | 042101 |        |        |     |      |       |                |                |  |
| 15694 | 065740 | 000    |        |        |        |        |     |      |       |                |                |  |
| 15695 |        |        |        |        |        |        |     |      |       |                |                |  |
| 15696 | 065741 | 120    | 004503 | 042524 | DH104: | .ASCII | /PC | TEST | IPCK  | RHCS3          | RHCS3/<15><12> |  |
| 15697 | 065746 | 052123 | 044411 | 041520 |        |        |     |      |       |                |                |  |
| 15698 | 065754 | 004513 | 044122 | 051503 |        |        |     |      |       |                |                |  |
| 15699 | 065762 | 004463 | 044122 | 051503 |        |        |     |      |       |                |                |  |
| 15700 | 065770 | 006463 | 012    |        |        |        |     |      |       |                |                |  |
| 15701 | 065773 | 011    | 047516 | 004411 |        | .ASCIZ | /   | NO   | GOOD  | BAD/           |                |  |
| 15702 | 066000 | 047507 | 042117 | 041011 |        |        |     |      |       |                |                |  |
| 15703 | 066006 | 042101 | 000    |        |        |        |     |      |       |                |                |  |
| 15704 |        |        |        |        |        |        |     |      |       |                |                |  |
| 15705 | 066011 | 120    | 004503 | 042524 | DH105: | .ASCII | /PC | TEST | IPCK  | RHCS2          | RHCS2/<15><12> |  |
| 15706 | 066016 | 052123 | 044411 | 041520 |        |        |     |      |       |                |                |  |
| 15707 | 066024 | 004513 | 044122 | 051503 |        |        |     |      |       |                |                |  |
| 15708 | 066032 | 004462 | 044122 | 051503 |        |        |     |      |       |                |                |  |
| 15709 | 066040 | 006462 | 012    |        |        |        |     |      |       |                |                |  |
| 15710 | 066043 | 011    | 047516 | 004411 |        | .ASCIZ | /   | NO   | GOOD  | BAD/           |                |  |
| 15711 | 066050 | 047507 | 042117 | 041011 |        |        |     |      |       |                |                |  |
| 15712 | 066056 | 042101 | 000    |        |        |        |     |      |       |                |                |  |
| 15713 |        |        |        |        |        |        |     |      |       |                |                |  |
| 15714 | 066061 | 120    | 004503 | 042524 | DH106: | .ASCII | /PC | TEST | IPCK  | RHCS1          | RHCS1/<15><12> |  |
| 15715 | 066066 | 052123 | 044411 | 041520 |        |        |     |      |       |                |                |  |
| 15716 | 066074 | 004513 | 044122 | 051503 |        |        |     |      |       |                |                |  |
| 15717 | 066102 | 004461 | 044122 | 051503 |        |        |     |      |       |                |                |  |
| 15718 | 066110 | 006461 | 012    |        |        |        |     |      |       |                |                |  |
| 15719 | 066113 | 011    | 047516 | 004411 |        | .ASCIZ | /   | NO   | GOOD  | BAD/           |                |  |
| 15720 | 066120 | 047507 | 042117 | 041011 |        |        |     |      |       |                |                |  |
| 15721 | 066126 | 042101 | 000    |        |        |        |     |      |       |                |                |  |
| 15722 |        |        |        |        |        |        |     |      |       |                |                |  |
| 15723 | 066131 | 120    | 004503 | 042524 | DH111: | .ASCII | /PC | TEST | IPCK  | RHBA           | RHBA/<15><12>  |  |
| 15724 | 066136 | 052123 | 044411 | 041520 |        |        |     |      |       |                |                |  |
| 15725 | 066144 | 004513 | 044122 | 040502 |        |        |     |      |       |                |                |  |
| 15726 | 066152 | 051011 | 041110 | 006501 |        |        |     |      |       |                |                |  |
| 15727 | 066160 | 012    |        |        |        |        |     |      |       |                |                |  |
| 15728 | 066161 | 011    | 047516 | 004411 |        | .ASCIZ | /   | NO   | GOOD  | BAD/           |                |  |
| 15729 | 066166 | 047507 | 042117 | 041011 |        |        |     |      |       |                |                |  |
| 15730 | 066174 | 042101 | 000    |        |        |        |     |      |       |                |                |  |
| 15731 |        |        |        |        |        |        |     |      |       |                |                |  |
| 15732 | 066177 | 120    | 004503 | 042524 | DH112: | .ASCII | /PC | TEST | IPCK  | RHBAE          | RHBAE/<15><12> |  |

|       |        |        |        |        |        |            |                                      |          |                |               |
|-------|--------|--------|--------|--------|--------|------------|--------------------------------------|----------|----------------|---------------|
| 15733 | 066204 | 052123 | 044411 | 041520 |        |            |                                      |          |                |               |
| 15734 | 066212 | 004513 | 044122 | 040502 |        |            |                                      |          |                |               |
| 15735 | 066220 | 004505 | 044122 | 040502 |        |            |                                      |          |                |               |
| 15736 | 066226 | 006505 | 012    |        |        |            |                                      |          |                |               |
| 15737 | 066231 | 011    | 047516 | 004411 |        | .ASCIZ /   | NO                                   | GOOD     | BAD/           |               |
| 15738 | 066236 | 047507 | 042117 | 041011 |        |            |                                      |          |                |               |
| 15739 | 066244 | 042101 | 000    |        |        |            |                                      |          |                |               |
| 15740 |        |        |        |        |        |            |                                      |          |                |               |
| 15741 | 066247 | 120    | 004503 | 042524 | DH113: | .ASCII /PC | TEST                                 | IPCK     | RHWC           | RHWC/<15><12> |
| 15742 | 066254 | 052123 | 044411 | 041520 |        |            |                                      |          |                |               |
| 15743 | 066262 | 004513 | 044122 | 041527 |        |            |                                      |          |                |               |
| 15744 | 066270 | 051011 | 053510 | 006503 |        |            |                                      |          |                |               |
| 15745 | 066276 | 012    |        |        |        |            |                                      |          |                |               |
| 15746 | 066277 | 011    | 047516 | 004411 |        | .ASCIZ /   | NO                                   | GOOD     | BAD/           |               |
| 15747 | 066304 | 047507 | 042117 | 041011 |        |            |                                      |          |                |               |
| 15748 | 066312 | 042101 | 000    |        |        |            |                                      |          |                |               |
| 15749 | 066315 | 120    | 004505 | 042524 | DH132: | .ASCII /PE | TEST                                 | RHDS1    | RHDS1/<15><12> |               |
| 15750 | 066322 | 052123 | 051011 | 042110 |        |            |                                      |          |                |               |
| 15751 | 066330 | 030523 | 051011 | 042110 |        |            |                                      |          |                |               |
| 15752 | 066336 | 030523 | 005015 |        |        |            |                                      |          |                |               |
| 15753 | 066342 | 047011 | 004517 | 047507 |        | .ASCIZ /   | NO                                   | GOOD     | BAD/           |               |
| 15754 | 066350 | 042117 | 041040 | 042101 |        |            |                                      |          |                |               |
| 15755 | 066356 | 000    |        |        |        |            |                                      |          |                |               |
| 15756 | 066357 | 120    | 004503 | 042524 | DH135: | .ASCII /PC | TEST                                 | PC OF    | BIT WAIT       | REG/<15><12>  |
| 15757 | 066364 | 052123 | 050011 | 020103 |        |            |                                      |          |                |               |
| 15758 | 066372 | 043117 | 041011 | 052111 |        |            |                                      |          |                |               |
| 15759 | 066400 | 053440 | 044501 | 020124 |        |            |                                      |          |                |               |
| 15760 | 066406 | 051040 | 043505 | 005015 |        |            |                                      |          |                |               |
| 15761 | 066414 | 047011 | 004517 | 040527 |        | .ASCIZ /   | NO                                   | WAT      | FOR            | ADDR/         |
| 15762 | 066422 | 004524 | 047506 | 004522 |        |            |                                      |          |                |               |
| 15763 | 066430 | 020040 | 042101 | 051104 |        |            |                                      |          |                |               |
| 15764 | 066436 | 000    |        |        |        |            |                                      |          |                |               |
| 15765 | 066437 | 120    | 004503 | 042524 | DH137: | .ASCII /PC | TEST                                 | REG.     | GOOD           | BAD/<15><12>  |
| 15766 | 066444 | 052123 | 051011 | 043505 |        |            |                                      |          |                |               |
| 15767 | 066452 | 004456 | 047507 | 042117 |        |            |                                      |          |                |               |
| 15768 | 066460 | 041011 | 042101 | 005015 |        |            |                                      |          |                |               |
| 15769 | 066466 | 047011 | 004517 | 042101 |        | .ASCIZ /   | NO                                   | ADDR     | DATA           | DATA/         |
| 15770 | 066474 | 051104 | 042011 | 052101 |        |            |                                      |          |                |               |
| 15771 | 066502 | 004501 | 040504 | 040524 |        |            |                                      |          |                |               |
| 15772 | 066510 | 000    |        |        |        |            |                                      |          |                |               |
| 15773 |        |        |        |        |        |            |                                      |          |                |               |
| 15774 | 066511 | 120    | 020103 | 020040 | DH146: | .ASCIZ /PC | BASE                                 | VECTOR/  |                |               |
| 15775 | 066516 | 020040 | 041040 | 051501 |        |            |                                      |          |                |               |
| 15776 | 066524 | 020105 | 020040 | 053040 |        |            |                                      |          |                |               |
| 15777 | 066532 | 041505 | 047524 | 000122 |        |            |                                      |          |                |               |
| 15778 | 066540 | 041520 | 020040 | 020040 | DH147: | .ASCIZ /PC | BASE                                 | ADDRESS/ |                |               |
| 15779 | 066546 | 020040 | 040502 | 042523 |        |            |                                      |          |                |               |
| 15780 | 066554 | 040440 | 042104 | 042522 |        |            |                                      |          |                |               |
| 15781 | 066562 | 051523 | 000    |        |        |            |                                      |          |                |               |
| 15782 |        |        |        |        |        |            |                                      |          |                |               |
| 15783 |        |        |        |        |        |            |                                      |          |                |               |
| 15784 |        | 066566 |        |        |        | .EVEN      |                                      |          |                |               |
| 15785 |        |        |        |        |        |            |                                      |          |                |               |
| 15786 | 066566 | 001116 | 001126 | 000000 | DT1:   | .WORD      | \$ERRPC,\$BDDAT,0                    |          |                |               |
| 15787 | 066574 | 001116 | 004046 | 004050 | DTS:   | .WORD      | \$ERRPC,RSCS1,RPCS1, TMCS1, MIXCS1,0 |          |                |               |
| 15788 | 066602 | 004052 | 004054 | 000000 |        |            |                                      |          |                |               |

|       |        |        |        |        |        |       |                                              |
|-------|--------|--------|--------|--------|--------|-------|----------------------------------------------|
| 15789 | 066610 | 001116 | 004656 | 001124 | DT6:   | .WORD | \$ERRPC, TSTNM, \$GDDAT, \$BDDAT, 0          |
| 15790 | 066616 | 001126 | 000000 |        |        |       |                                              |
| 15791 | 066622 | 001116 | 004656 | 004664 | DT24:  | .WORD | \$ERRPC, TSTNM, \$ILONM, \$GDDAT, \$BDDAT, 0 |
| 15792 | 066630 | 001124 | 001126 | 000000 |        |       |                                              |
| 15793 | 066636 | 001116 | 004656 | 004662 | DT104: | .WORD | \$ERRPC, TSTNM, IP, \$GDDAT, \$BDDAT, 0      |
| 15794 | 066644 | 001124 | 001126 | 000000 |        |       |                                              |
| 15795 | 066652 | 001116 | 004656 | 004662 | DT105: | .WORD | \$ERRPC, TSTNM, IP, \$GDDAT, \$BDDAT, 0      |
| 15796 | 066660 | 001124 | 001126 | 000000 |        |       |                                              |
| 15797 | 066666 | 001116 | 004656 | 004662 | DT106: | .WORD | \$ERRPC, TSTNM, IP, \$GDDAT, \$BDDAT, 0      |
| 15798 | 066674 | 001124 | 001126 | 000000 |        |       |                                              |
| 15799 | 066702 | 001116 | 004656 | 004672 | DT135: | .WORD | \$ERRPC, TSTNM, WAITBT, WAITPC, WAITRE, 0    |
| 15800 | 066710 | 004666 | 004670 | 000000 |        |       |                                              |
| 15801 | 066716 | 001116 | 004656 | 001122 | DT137: | .WORD | \$ERRPC, TSTNM, \$BDADR, \$GDDAT, \$BDDAT, 0 |
| 15802 | 066724 | 001124 | 001126 | 000000 |        |       |                                              |
| 15803 | 066732 | 001116 | 005324 | 005326 | DT146: | .WORD | \$ERRPC, TESTDV, TESTVC, 0                   |
| 15804 | 066740 | 000000 |        |        |        |       |                                              |
| 15805 | 066742 | 001116 | 005324 | 000000 | DT147: | .WORD | \$ERRPC, TESTDV, 0                           |
| 15806 |        |        |        |        |        |       |                                              |
| 15807 |        |        |        |        |        |       |                                              |
| 15808 |        |        |        |        |        |       |                                              |
| 15809 | 066750 | 000    | 000    |        | DF1:   | .BYTE | 0,0                                          |
| 15810 | 066752 | 000    | 000    | 000    | DF5:   | .BYTE | 0,0,0,0,0                                    |
| 15811 | 066755 | 000    | 000    |        |        |       |                                              |
| 15812 | 066757 | 000    | 000    | 000    | DF6:   | .BYTE | 0,0,0,0                                      |
| 15813 | 066762 | 000    |        |        |        |       |                                              |
| 15814 | 066763 | 000    | 000    | 000    | DF24:  | .BYTE | 0,0,0,0,0                                    |
| 15815 | 066766 | 000    | 000    |        |        |       |                                              |
| 15816 | 066770 | 000    | 000    | 000    | DF104: | .BYTE | 0,0,0,0,0                                    |
| 15817 | 066773 | 000    | 000    |        |        |       |                                              |
| 15818 | 066775 | 000    | 000    | 000    | DF105: | .BYTE | 0,0,0,0,0                                    |
| 15819 | 067000 | 000    | 000    |        |        |       |                                              |
| 15820 | 067002 | 000    | 000    | 000    | DF106: | .BYTE | 0,0,0,0,0                                    |
| 15821 | 067005 | 000    | 000    |        |        |       |                                              |
| 15822 | 067007 | 000    | 000    | 000    | DF135: | .BYTE | 0,0,0,0,0                                    |
| 15823 | 067012 | 000    | 000    |        |        |       |                                              |
| 15824 | 067014 | 000    | 000    | 000    | DF137: | .BYTE | 0,0,0,0,0                                    |
| 15825 | 067017 | 000    | 000    |        |        |       |                                              |
| 15826 | 067021 | 000    | 000    | 000    | DF146: | .BYTE | 0,0,0                                        |
| 15827 | 067024 | 000    | 000    |        | DF147: | .BYTE | 0,0                                          |
| 15828 |        |        |        |        |        | .EVEN |                                              |
| 15829 |        | 000001 |        |        |        | .END  |                                              |

ACL = 000040  
 ACU = 100000  
 AOE = 001000  
 APE = 100000  
 AS = 000016  
 ATA = 100000  
 ATABLE = 0C4674  
 ATTENT = 005244  
 ATO = 000001  
 ATI = 000002  
 AT2 = 000004  
 AT3 = 000010  
 AT4 = 000020  
 AT5 = 000040  
 AT6 = 000100  
 AT7 = 000200  
 A16 = 000400  
 A17 = 001000  
 BA = 000004  
 BAI = 000010  
 BASEAD = 004704  
 BASECH = 042254  
 BASEMA = 004712  
 BASEVC = 004714  
 BASINX = 004766  
 BASM = 004722  
 BASP = 004716  
 BASPAD = 004706  
 BAST = 004720  
 BASTAD = 004710  
 BEGIN = 005522  
 BEGIN2 = 005532  
 BFEVEN = 003000  
 BFODD = 003002  
 BIT0 = 000001  
 BIT00 = 000001  
 BIT01 = 000002  
 BIT02 = 000004  
 BIT03 = 000010  
 BIT04 = 000020  
 BIT05 = 000040  
 BIT06 = 000100  
 BIT07 = 000200  
 BIT08 = 000400  
 BIT09 = 001000  
 BIT1 = 000002  
 BIT10 = 002000  
 BIT11 = 004000  
 BIT12 = 010000  
 BIT13 = 020000  
 BIT14 = 040000  
 BIT15 = 100000  
 BIT2 = 000004

BIT3 = 000010  
 BIT4 = 000020  
 BIT5 = 000040  
 BIT6 = 000100  
 BIT7 = 000200  
 BIT8 = 000400  
 BIT9 = 001000  
 BOT = 000002  
 BPI8 = 001400  
 BPTVEC = 000014  
 BSGIVA = 004724  
 BSGIVV = 004744  
 BUFEW = 003000  
 BUFOV = 003002  
 CC = 000036  
 CHECK = 040354  
 CHECKC = 040412  
 CHECKT = 040376  
 CH7 = 010000  
 CLDISK = 040322  
 CLR = 000040  
 CLRBIT = 004654  
 CMNDRP = 041572  
 CMNDRS = 041502  
 CMNDTM = 041710  
 COMAND = 004642  
 COMND = 004640  
 CR = 000015  
 CRLF = 000200  
 CSF = 000002  
 CSU = 000010  
 CS1 = 000000  
 CS2 = 000010  
 CA = 000006  
 DB = 000022  
 DBL = 002000  
 DC = 000034  
 DCK = 100000  
 DCL = 000100  
 DCLEAR = 004142  
 DDISP = 177570  
 DEN1 = 000400  
 DEN2 = 001000  
 DEN4 = 002000  
 DEVPNT = 005300  
 DE1 = 000040  
 DFF20 = 000002  
 DFF5 = 000001  
 DF1 = 066750  
 DF104 = 066770  
 DF105 = 066775  
 DF106 = 067002  
 DF135 = 067007

DF137 = 067014  
 DF146 = 067021  
 DF147 = 067024  
 DF24 = 066763  
 DF5 = 066752  
 DF6 = 066757  
 DH1 = 065133  
 DH104 = 065741  
 DH105 = 066011  
 DH106 = 066061  
 DH11 = 065321  
 DH111 = 066131  
 DH112 = 066177  
 DH113 = 066247  
 DH12 = 065363  
 DH13 = 065425  
 DH132 = 066315  
 DH135 = 066357  
 DH137 = 066437  
 DH14 = 065465  
 DH146 = 066511  
 DH147 = 066540  
 DH15 = 065527  
 DH24 = 065567  
 DH33 = 065637  
 DH45 = 065701  
 DHS = 065142  
 DH6 = 065216  
 DH7 = 065261  
 DIGB = 000004  
 DISPLA = 001142  
 DISPRE = 000174  
 DLT = 100000  
 DL64 = 000020  
 DMD = 000001  
 DPEEW = 020000  
 DPEOW = 040000  
 DPR = 000400  
 DRY = 000200  
 DS = 000012  
 DSWR = 177570  
 DT = 000026  
 DTE = 010000  
 DTSY = 001000  
 DT1 = 066566  
 DT104 = 066636  
 DT105 = 066652  
 DT106 = 066666  
 DT135 = 066702  
 DT137 = 066716  
 DT146 = 066732  
 DT147 = 066742  
 DT24 = 066622

DTS = 066574  
 DT6 = 066610  
 DVA = 004000  
 ECH = 000100  
 ECI = 004000  
 EC1 = 000044  
 EC2 = 000046  
 EMTVEC = 000030  
 EM1 = 046712  
 EM10 = 050404  
 EM104 = 060427  
 EM106 = 060665  
 EM11 = 050577  
 EM114 = 061156  
 EM116 = 061325  
 EM12 = 050772  
 EM124 = 061535  
 EM13 = 051165  
 EM132 = 061700  
 EM133 = 062056  
 EM134 = 062234  
 EM135 = 062424  
 EM136 = 062624  
 EM137 = 063026  
 EM14 = 051357  
 EM140 = 063154  
 EM141 = 063406  
 EM142 = 063607  
 EM143 = 064010  
 EM144 = 064210  
 EM145 = 064411  
 EM146 = 064611  
 EM147 = 065003  
 EM15 = 051552  
 EM16 = 051744  
 EM17 = 052137  
 EM2 = 047064  
 EM20 = 052331  
 EM21 = 052525  
 EM22 = 052725  
 EM23 = 053126  
 EM24 = 053123  
 EM25 = 053553  
 EM3 = 047266  
 EM33 = 054002  
 EM34 = 054116  
 EM35 = 054360  
 EM36 = 054556  
 EM37 = 055033  
 EM4 = 047422  
 EM45 = 055335  
 EM46 = 055573  
 EMS = 047721

EM54 = 056074  
 EM56 = 056305  
 EM6 = 050074  
 EM60 = 056543  
 EM62 = 056754  
 EM64 = 057211  
 EM66 = 057421  
 EM7 = 050212  
 EM70 = 057660  
 EM76 = 060134  
 EPAR = 000010  
 ERFLGS = 005240  
 ERR = 040000  
 ERRVEC = 000004  
 ER1 = 000014  
 ER2 = 000040  
 ER3 = 000042  
 EXT1 = 000001  
 EXT10 = 000010  
 EXT2 = 000002  
 EXT20 = 000020  
 EXT4 = 000004  
 EXT40 = 000040  
 FBAE = 005466  
 FBASEA = 005426  
 FC = 000006  
 FCS3 = 005476  
 FDEVIC = 005366  
 FDRIVR = 005456  
 FEN = 000200  
 FER = 000020  
 FIRST = 005242  
 FMT1 = 000020  
 FMT2 = 000040  
 FMT22 = 010000  
 FMT4 = 000100  
 FMT8 = 000200  
 FORBAE = 004776  
 FRHNM = 005436  
 FSLAVE = 005446  
 FTYPE = 005406  
 FUNITN = 005376  
 FUTABL = 004134  
 FVECTR = 005416  
 GIVE = 005006  
 GO = 000001  
 GRV = 000010  
 HCE = 000200  
 HCI = 002000  
 HCRC = 000400  
 HERADD = 005516  
 HT = 000011  
 IAE = 002000

IE = 000100  
ILF = 000001  
ILLEGL 004206  
ILR = 000002  
IOTVEC= 090020  
IP = 004662  
IPCK0 = 000001  
IPCK1 = 000002  
IPCK2 = 000004  
IPCK3 = 000010  
IR = 000100  
IXE = 004000  
KIPAR0= 172340  
KIPAR1= 172342  
KIPAR2= 172344  
KIPAR3= 172346  
KIPAR4= 172350  
KIPAR5= 172352  
KIPAR6= 172354  
KIPAR7= 172356  
KIPDR0= 172300  
KIPDR1= 172302  
KIPDR2= 172304  
KIPDR3= 172306  
KIPDR4= 172310  
KIPDR5= 172312  
KIPDR6= 172314  
KIPDR7= 172316  
LA = 000020  
LBT = 002000  
LERADD 005514  
LF = 000012  
LOPCT 005000  
LOPCT1 005002  
LTRY 005320  
MCLK = 000002  
MCPE = 020000  
MDPE = 000400  
MEMERR 005520  
MHS = 001000  
MINX = 000004  
MIXCS1 004054  
MMVEC = 000250  
MOL = 010000  
MPE = 000400  
MR = 000024  
MRD = 000020  
MSE = 000020  
MSTCK = 000010  
MWR = 000040  
MXF = 001000  
NED = 010000  
NEM = 004000

NHS = 002000  
NML = 000300  
NMRHS 004764  
NOGO 004644  
NOPERA 004134  
NTYPNT 005362  
OCYL = 100000  
OF = 000032  
OFREV = 000200  
OFSETC 004166  
OF100 = 000004  
OF200 = 000010  
OF25 = 000001  
OF400 = 000020  
OF50 = 000002  
OF800 = 000040  
OPERSE 040654  
OPI = 020000  
OR = 000200  
PAR = 000010  
PARE70= 000114  
PARITY 037746  
PAT = 000020  
PC = %000007  
PCJSR 040352  
PE = 020000  
PERMX 005264  
PERMXV 005274  
PERNUM 005276  
PERRP 005260  
PERRPV 005270  
PERRS 005256  
PERRSV 005266  
PERTU 005262  
PERTUV 005272  
PGE = 002000  
PIP = 020000  
PIRQ = 177772  
PIRQVE= 000240  
PKACK 004172  
PLU = 020000  
POINTT 005360  
PRE = 000020  
PRESEN 004056  
PRITEM 045100  
PROG = 001000  
PRO = 000000  
PR1 = 000040  
PR2 = 000100  
PR3 = 000140  
PR4 = 000200  
PR5 = 000240  
PR6 = 000300

PR7 = 000340  
PS = 177776  
PSEL = 002000  
PSU = 000001  
PSW = 177776  
PUTREG 041442  
PWRVEC= 000024  
RDCHR = 104406  
RDLIN = 104407  
RDOCT = 104410  
RDY = 000200  
READAT 004160  
READIN 004174  
RECALI 004140  
REFOR 004162  
REINTO 004424  
RELEAS 004144  
RESVEC= 000010  
RETCL 004170  
REVRED 004200  
REVRT 004204  
REWIND 004176  
RHAS 004076  
RHBA 004064  
RHBAE 004130  
RHCA 004114  
RHCC 004100  
RHCCA 004116  
RHCS1 004060  
RHCS2 004070  
RHCS3 004132  
RHDA 004066  
RHDB 004102  
RHDST 004066  
RHDS1 004072  
RHDT 004106  
RHEC1 004124  
RHEC2 004126  
RHER1 004074  
RHER2 004120  
RHER3 004122  
RHFC 004066  
RHLA 004100  
RHMR 004104  
RHOF 004112  
RHSN 004110  
RHTC 004112  
RHWC 004062  
RMR = 000004  
RPCS1 004050  
RPVEC 002716  
RPVECT 043056  
RSCS1 004046

RO = %000000  
R1 = %000001  
R2 = %000002  
R3 = %000003  
R4 = %000004  
R5 = %000005  
R6 = %000006  
R7 = %000007  
SC = 100000  
SC1 = 000100  
SC10 = 001000  
SC2 = 000200  
SC20 = 002000  
SC4 = 000400  
SEECOM 004164  
SERCH 004146  
SETBIT 004652  
SETSIZ 006522  
SILONM 004664  
SKI = 040000  
SLAVE 004660  
SLVPR = 002000  
SN = 000030  
SND1 006124  
SP = %000006  
SPACFD 004202  
SRO = 177572  
SR1 = 177574  
SR2 = 177576  
SR3 = 172516  
SS1 007376  
SS2 006536  
SS3 010506  
SS4 010530  
SS5 010546  
SS6 006612  
SS7 006626  
SS8 010554  
STACK = 001000  
START 005536  
STKMT= 177774  
ST200 005012  
SWR 001140  
SWREG 000176  
SWO = 000001  
SW00 = 000001  
SW01 = 000002  
SW02 = 000004  
SW03 = 000010  
SW04 = 000020  
SW05 = 000040  
SW06 = 000100  
SW07 = 000200

SW08 = 000400  
SW09 = 001000  
SW1 = 000002  
SW10 = 002000  
SW11 = 004000  
SW12 = 010000  
SW13 = 020000  
SW14 = 040000  
SW15 = 100000  
SW2 = 000004  
SW3 = 000010  
SW4 = 000020  
SW5 = 000040  
SW6 = 000100  
SW7 = 000200  
SW8 = 000400  
SW9 = 001000  
S1 = 000001  
S2 = 000002  
S4 = 000004  
TBITVE= 000014  
TC = 000032  
TDF = 000040  
TESTAD 040652  
TESTDV 005324  
TESTVC 005326  
TFOUND 005322  
TIEOUT 037610  
TIMCNT 040456  
TKVEC = 000060  
TMCS1 004052  
TMPSLV 005364  
TMP0 005250  
TMP1 005252  
TMP4 005254  
TN = 000067  
TOTALA 005246  
TPVEC = 000064  
TRAPVE= 000034  
TRE = 040000  
TRK1 = 004000  
TRK10 = 040000  
TRK2 = 010000  
TRK20 = 100000  
TRK4 = 020000  
TRTVEC= 000014  
TSBAE 005140  
TSBASE 005220  
TSCOMD 005200  
TSCS3 005160  
TSDEVI 005034  
TSINDX 005116  
TSRHNO 005014

|        |          |        |          |         |          |          |          |          |          |
|--------|----------|--------|----------|---------|----------|----------|----------|----------|----------|
| TSSLAV | 005074   | TST54  | 033504   | WCE     | = 040000 | \$ERRPC  | 001116   | \$RTNAD  | 037566   |
| TSTNM  | 004656   | TST55  | 033732   | WCEEW   | = 004000 | \$ERRTB  | 001226   | \$SAVR6  | 046700   |
| TSTOTL | 005114   | TST56  | 034160   | WCEOW   | = 010000 | \$ERRTY  | 045102   | \$SCOPE  | 043120   |
| TSTUNT | 005506   | TST57  | 034406   | WCF     | = 000040 | \$ERTTL  | 001112   | \$SETUP= | 000017   |
| TST1   | 006162   | TST6   | 012514   | WCU     | = 000001 | \$ESCAP  | 001214   | \$SS1    | = 000000 |
| TST10  | 013276   | TST60  | 034634   | WLE     | = 004000 | \$FILLC  | 001156   | \$STUP   | = 177777 |
| TST11  | 013600   | TST61  | 035062   | WORKBS  | 004770   | \$FILLS  | 001155   | \$SVLAD  | 043334   |
| TST12  | 014126   | TST62  | 035316   | WORKNM  | 004772   | \$GDADR  | 001120   | \$SWR    | = 167700 |
| TST13  | 014430   | TST63  | 035554   | WORKVC  | 004774   | \$GDDAT  | 001124   | \$SWRMK= | 000000   |
| TST14  | 015112   | TST64  | 036012   | WORUNT  | 005510   | \$GET42  | 037544   | \$TIMES  | 001212   |
| TST15  | 016022   | TST65  | 036250   | WRCHDT  | 004152   | \$HD     | = 000000 | \$TKB    | 001146   |
| TST16  | 016734   | TST66  | 036506   | WRCHK   | 004150   | \$HIOCT  | 044742   | \$TKCNT  | 044044   |
| TST17  | 017646   | TST67  | 036744   | WRFROM  | 004210   | \$ICNT   | 001104   | \$TKINT  | 044064   |
| TST2   | 010632   | TST7   | 012774   | WRIDAT  | 004154   | \$ILLUP  | 046674   | \$TKQEN= | 044063   |
| TST20  | 020562   | TST70  | 037210   | WRIFOR  | 004156   | \$INTAG  | 001135   | \$TKQIN  | 044046   |
| TST21  | 021476   | TSUNIT | 005054   | WRL     | = 004000 | \$ITEMB  | 001114   | \$TKQOU  | 044050   |
| TST22  | 022110   | TSVEC  | 005120   | WRTBIT  | 004650   | \$LF     | 001224   | \$TKGSR  | 044052   |
| TST23  | 022404   | TUF    | = 000100 | WRU     | = 000400 | \$LPADR  | 001106   | \$TKS    | 001144   |
| TST24  | 022566   | TYPDS  | = 104405 | WSU     | = 000004 | \$LPERR  | 001110   | \$TKSRV  | 044134   |
| TST25  | 022750   | TYPE   | = 104401 | \$AUTOB | 001134   | \$MNEW   | 044573   | \$TMP0   | 001176   |
| TST26  | 023132   | TYPERR | 046022   | \$BDADR | 001122   | \$MSWR   | 044562   | \$TMP1   | 001200   |
| TST27  | 023326   | TYPNT  | 005330   | \$BDDAT | 001126   | \$MXCNT  | 043376   | \$TMP2   | 001202   |
| TST3   | 011430   | TYPOC  | = 104402 | \$BELL  | 001216   | \$NULL   | 001154   | \$TMP3   | 001204   |
| TST30  | 023610   | TYPON  | = 104404 | \$CHARC | 044040   | \$NWTST= | 000001   | \$TMP4   | 001206   |
| TST31  | 024212   | TYPOS  | = 104403 | \$CMTAG | 001100   | \$OCNT   | 046444   | \$TMP5   | 001210   |
| TST32  | 024614   | UNIT   | 005010   | \$CM1   | = 000006 | \$OMODE  | 046446   | \$TN     | = 000071 |
| TST33  | 025342   | UNLOAD | 004136   | \$CM2   | = 000014 | \$OVER   | 043362   | \$TPB    | 001152   |
| TST34  | 026070   | UNS    | = 040000 | \$CM3   | = 000006 | \$PASS   | 001100   | \$TPFLG  | 001157   |
| TST35  | 026466   | USEVEC | 005004   | \$CM4   | = 000006 | \$POWER  | 046702   | \$TPS    | 001150   |
| TST36  | 027064   | US1    | = 000001 | \$CNTLC | 044543   | \$PWRAD  | 046670   | \$TRAP   | 046450   |
| TST37  | 027462   | US2    | = 000002 | \$CNTLG | 044555   | \$PWRDN  | 046530   | \$TRAP2  | 046472   |
| TST4   | 011732   | US4    | = 000004 | \$CNTLU | 044550   | \$PWRMG  | 046664   | \$TRP    | = 000012 |
| TST40  | 030060   | UWR    | = 000010 | \$CRLF  | 001223   | \$PWRUP  | 046602   | \$TRPAD  | 046504   |
| TST41  | 030306   | VECPNT | 005310   | \$DBLK  | 043614   | \$QUES   | 001222   | \$TSTNM  | 001102   |
| TST42  | 030534   | VECTOR | 005512   | \$DOAGN | 037564   | \$RDCHR  | 044334   | \$TTYIN  | 044532   |
| TST43  | 030762   | VUF    | = 000002 | \$DTBL  | 043604   | \$RDLIN  | 044424   | \$TYPDS  | 043400   |
| TST44  | 031210   | VU30   | = 010000 | \$ENDAD | 037554   | \$RDOCT  | 044604   | \$TYPE   | 043624   |
| TST45  | 031444   | VV     | = 000100 | \$ENDCT | 037522   | \$RDSZ   | = 000011 | \$TYPEC  | 043774   |
| TST46  | 031672   | WAITBT | 004672   | \$ENDMG | 037573   | \$REGAD  | 001160   | \$TYPEX  | 044042   |
| TST47  | 032120   | WAITPC | 004666   | \$ENULL | 037570   | \$REG0   | 001162   | \$TYPOC  | 046246   |
| TST5   | 012212   | WAITRE | 004670   | \$EOP   | 037466   | \$REG1   | 001164   | \$TYPON  | 046262   |
| TST50  | 032346   | WAIT.T | 040460   | \$EOPCT | 037514   | \$REG2   | 001166   | \$TYPOS  | 046222   |
| TST51  | 032574   | WAT    | = 104411 | \$ERFLG | 001103   | \$REG3   | 001170   | \$XTSTR  | 043140   |
| TST52  | 033022   | WATO   | 004646   | \$ERMAX | 001115   | \$REG4   | 001172   | \$SET4=  | 000000   |
| TST53  | 033250   | WC     | = 000002 | \$ERROR | 044744   | \$REG5   | 001174   | \$OFILL  | 046445   |
|        | = 067026 |        |          |         |          |          |          |          |          |

ERRORS DETECTED: 0  
DEFAULT GLOBALS GENERATED: 0

\*DERHAC,DERHAC/SOL/PAGNUM=DERHAC.SML(400,4335),DERHAC.P11(400,4355)  
RUN-TIME: 105 157 2 SECONDS  
RUN-TIME RATIO: 327/265=1.2  
CORE USED: 38K (75 PAGES)

