

KW11-L

LINE FREQUENCY CLOCK TEST
MD-11-DZKWA-F

EP-DZKWA-F-DL
COPYRIGHT © 70-78
FICHE 1 OF 1

MAR 1978
digital
MADE IN USA

This microfiche card contains a grid of frames. The leftmost column consists of frames with text, likely test instructions or data tables. The subsequent columns contain waveforms, which appear to be digital signals or clock pulses. The frames are arranged in a regular grid pattern, typical of a microfiche card.

PRODUCT CODE: MAINDEC-11-DZKWA-F-D
PRODUCT NAME: LINE FREQUENCY CLOCK TEST
PRODUCT DATE: FEB 1978
MAINTAINER: DIAGNOSTIC ENGINEERING

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1970, 1978 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL	PDP	UNIBUS	MASSBUS
DEC	DECUS	DECTAPE	

1.0 GENERAL PROGRAM INFORMATION

- 1.1 **ABSTRACT**
THIS PROGRAM TESTS THE KW11 LINE FREQUENCY CLOCK. IT VALIDATES PROPER OPERATION UNDER BOTH INTERRUPT AND NON-INTERRUPT MODES.
- 1.2 **SYSTEM REQUIREMENTS**
THIS PROGRAM IS DESIGNED TO RUN ON ANY PDP-11 WITH 4K OF MEMORY AND A KW11 LINE FREQUENCY CLOCK.
- 1.3 **DEVICE ADDRESSES**
THE DIAGNOSTIC ASSUMES THE LINE CLOCK ADDRESS IS 177546. VARIOUS TESTS IN THE DIAGNOSTIC ENSURE THAT THE LINE CLOCK IS NOT AFFECTED WHEN THE PAPER TAPE PUNCH (ADDRESS 177556) AND TELETYPE (ADDRESS 177566) ARE ACCESSED. THEREFORE, AN OCCASIONAL "3" MAY BE OUTPUT AT THE TELETYPE AND A CHARACTER MAY BE PUNCHED AT THE PAPER TAPE PUNCH. THESE ARE NOT ERRORS.

2.0 OPERATING INSTRUCTIONS

- 2.1 **LOADING**
PROCEDURE FOR NORMAL BINARY TAPES SHOULD BE FOLLOWED
- ABSOLUTE LOADER PROGRAM MUST BE IN MEMORY
 - PLACE THE BINARY TAPE IN THE PAPER TAPE READER
 - LOAD ADDRESS 17500
 - DEPRESS START (TAPE SHOULD READ IN)
- 2.2 **STARTING**
PROGRAM STARTING ADDRESS IS 000200
- LOAD ADDRESS 000200
 - SELECT SWITCH REGISTER OPTIONS (SEE SECTION 2.3)
- NOTE: IF THE PROCESSOR DOES NOT HAVE A HARDWARE SWITCH REGISTER, LOCATION # 176 SHOULD BE LOADED WITH THE APPROPRIATE SWITCH SETTINGS AFTER THE DIAGNOSTIC HAS BEEN LOADED INTO MEMORY. THE PROGRAM IS THEN STARTED AT ADDRESS 200.
- DEPRESS START (PROGRAM SHOULD START RUNNING)
- 2.3 **SWITCH REGISTER OPTIONS**
HERE IS A LIST OF CONSOLE SWITCHES AND THEIR EFFECT ON THE PROGRAM...
- | SWITCH | ACTION IF SET |
|--------|---|
| 15 | HALT ON ERROR |
| 14 | LOOP ON CURRENTLY EXECUTING TEST |
| 13 | INHIBIT ERROR PRINTOUTS |
| 12 | (UNUSED) |
| 11 | INHIBIT ITERATIONS |
| 10 | BELL ON ERROR |
| 9 | LOOP ON ERROR |
| 8 | LOOP ON TEST SPECIFIED IN SWR<7:0> |
| 7-0 | # OF TEST TO LOOP ON (ONLY WHEN SWRB = 1) |
- 2.4 **EXECUTION TIMES**

EXECUTION TIME FOR THIS PROGRAM IS DEPENDENT ON THE MODEL OF PDP-11 IT IS BEING RUN ON. FOR A PDP-11/40 ABOUT 5 SECONDS IS NECESSARY TO DO 1 PASS OF THE PROGRAM WITHOUT ITERATIONS.

3.0 ERROR INFORMATION

3.1 STANDARD ERROR REPORTING PROCEDURES
ERROR PRINTOUTS CONSIST OF FROM 4 TO 8 COLUMNS OF DATA, A DATA HEADER, AND POSSIBLY A SHORT ERROR MESSAGE DESCRIBING THE ERROR. FOR EXAMPLE...

CLOCK FAILED TO INTERRUPT
PC PS SP TEST# LKS
002262 000344 000764 000007 000300

THE FIRST 4 COLUMNS OF OF THE ERROR MESSAGE ALWAYS SHOW THE CONTENTS OF THE PC, PS, SP, AND THE TEST NUMBER. MORE COLUMNS OF DATA ARE ADDED WHERE THEY MIGHT BE RELEVANT TO A PARTICULAR ERROR.

3.2 UNEXPECTED TRAP ERROR REPORTING
AN UNEXPECTED TRAP TO ADDRESS 4 CAUSES THE FOLLOWING MESSAGE TO BE PRINTED OUT...

TRAPPED TO LOC 4 FROM LOCATION "XXXXXX"
RESTARTING PROGRAM

IN THE ACTUAL MESSAGE THE "XXXXXX" IS REPLACED BY THE PC ADDRESS PUSHED ONTO THE STACK WHEN THE UNEXPECTED TRAP OCCURS. THE PROGRAM THEN TRYS TO RESTART ITSELF DESPITE SWITCH REGISTER SETTINGS.

3.3 POWER FAIL
IF A POWER FAIL CONDITION IS DETECTED THE FOLLOWING MESSAGE IS PRINTED...

POWER

AFTER PRINTING OUT THE MESSAGE THE PROGRAM TRYS TO RESTART ITSELF.

5.0 DEVICE INFORMATION

5.1 GENERAL INFORMATION
THE LINE CLOCK INTERRUPT VECTOR ADDRESS IS 100
THE LINE CLOCK PRIORITY LEVEL IS BR6

5.2 REGISTERS

LINE CLOCK STATUS REGISTER (LKS) 777546

! ! ! ! ! ! ! ! ! ! ! ! ! ! !
! ! ! ! ! ! ! ! 7 6 ! ! ! ! ! ! ! !

BIT6 IF SET MONITOR=1 CAUSES AN INTERRUPT

E01

BIT7 MONITOR BIT. SET BY CLOCK, CLEARED BY USER

SEQ 0004

7.0 LISTING

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
00

167400
000000

```

.ABS
.ENABL AMA
.LIST ME
.NLIST MC, MD, CND
$SWR=167400
$TN=0
      .ENABL ABS
.TITLE MAINDEC-11-DZKWA-F LINE FREQUENCY CLOCK PROGRAM
;*COPYRIGHT (C) 1970,1977
;*DIGITAL EQUIPMENT CORP.
;*MAYNARD, MASS. 01754
;*
;*PROGRAM BY J. COMEAU
;*
;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
;*PACKAGE (MAINDEC-11-DZQAC-B1),AUG 29,1975.
;*

.SBTTL OPERATIONAL SWITCH SETTINGS
;*
;*      SWITCH          USE
;*      -----          -
;*      15              HALT ON ERROR
;*      14              LOOP ON TEST
;*      13              INHIBIT ERROR TYPEOUTS
;*      11              INHIBIT ITERATIONS
;*      10              BELL ON ERROR
;*      9               LOOP ON ERROR
;*      8               LOOP ON TEST IN SWR<7:0>
;*      7-0            #OF TEST TO LOOP ON IF SWR<8> IS SET

.SBTTL BASIC DEFINITIONS
;*INITIAL ADDRESS OF THE STACK POINTER *** !100 ***
STACK= 1100
.EQUIV EMT,ERROR          ;;BASIC DEFINITION OF ERROR CALL
.EQUIV IOT,SCOPE          ;;BASIC DEFINITION OF SCOPE CALL
PS= 177776                ;;PROCESSOR STATUS WORD
.EQUIV PS,PSW
STKLMT= 177774            ;;STACK LIMIT REGISTER
PIRQ= 177772              ;;PROGRAM INTERRUPT REQUEST REGISTER
DSWR= 177570              ;;HARDWARE SWITCH REGISTER
DDISP= 177570             ;;HARDWARE DISPLAY REGISTER

;*GENERAL PURPOSE REGISTER DEFINITIONS
R0= %0                    ;;GENERAL REGISTER
R1= %1                    ;;GENERAL REGISTER
R2= %2                    ;;GENERAL REGISTER
R3= %3                    ;;GENERAL REGISTER
R4= %4                    ;;GENERAL REGISTER
R5= %5                    ;;GENERAL REGISTER
R6= %6                    ;;GENERAL REGISTER
R7= %7                    ;;GENERAL REGISTER
SP= %6                    ;;STACK POINTER
PC= %7                    ;;PROGRAM COUNTER

```

001100

177776

177774
177772
177570
177570

000000
000001
000002
000003
000004
000005
000006
000007
000006
000007

BASIC DEFINITIONS

```

57
58 000000
59 000040
60 000100
61 000140
62 000200
63 000240
64 000300
65 000340
66
67
68 100000
69 040000
70 020000
71 010000
72 004000
73 002000
74 001000
75 000400
76 000200
77 000100
78 000040
79 000020
80 000010
81 000004
82 000002
83 000001
84
85
86
87
88
89
90
91
92
93
94
95
96 100000
97 040000
98 020000
99 010000
100 004000
101 002000
102 001000
103 000400
104 000200
105 000100
106 000040
107 000020
108 000010
109 000004
110 000002
111 000001
112

```

```

:*PRIORITY LEVEL DEFINITIONS
PR0= 0      :::PRIORITY LEVEL 0
PR1= 40    :::PRIORITY LEVEL 1
PR2= 100   :::PRIORITY LEVEL 2
PR3= 140   :::PRIORITY LEVEL 3
PR4= 200   :::PRIORITY LEVEL 4
PR5= 240   :::PRIORITY LEVEL 5
PR6= 300   :::PRIORITY LEVEL 6
PR7= 340   :::PRIORITY LEVEL 7

```

:"SWITCH REGISTER" SWITCH DEFINITIONS

```

SW15= 100000
SW14= 40000
SW13= 20000
SW12= 10000
SW11= 4000
SW10= 2000
SW09= 1000
SW08= 400
SW07= 200
SW06= 100
SW05= 40
SW04= 20
SW03= 10
SW02= 4
SW01= 2
SW00= 1
.EQUIV SW09,SW9
.EQUIV SW08,SW8
.EQUIV SW07,SW7
.EQUIV SW06,SW6
.EQUIV SW05,SW5
.EQUIV SW04,SW4
.EQUIV SW03,SW3
.EQUIV SW02,SW2
.EQUIV SW01,SW1
.EQUIV SW00,SW0

```

:*DATA BIT DEFINITIONS (BIT00 TO BIT15)

```

BIT15= 100000
BIT14= 40000
BIT13= 20000
BIT12= 10000
BIT11= 4000
BIT10= 2000
BIT09= 1000
BIT08= 400
BIT07= 200
BIT06= 100
BIT05= 40
BIT04= 20
BIT03= 10
BIT02= 4
BIT01= 2
BIT00= 1
.EQUIV BIT09,BIT9

```

BASIC DEFINITIONS

```

113 .EQUIV BIT08,BIT8
114 .EQUIV BIT07,BIT7
115 .EQUIV BIT06,BIT6
116 .EQUIV BIT05,BIT5
117 .EQUIV BIT04,BIT4
118 .EQUIV BIT03,BIT3
119 .EQUIV BIT02,BIT2
120 .EQUIV BIT01,BIT1
121 .EQUIV BIT00,BIT0

```

;*BASIC "CPU" TRAP VECTOR ADDRESSES

```

123 ERRVEC= 4 ;: TIME OUT AND OTHER ERRORS
124 RESVEC= 10 ;: RESERVED AND ILLEGAL INSTRUCTIONS
125 TBITVEC=14 ;: "T" BIT
126 TRTVEC= 14 ;: TRACE TRAP
127 BPTVEC= 14 ;: BREAKPOINT TRAP (BPT)
128 IOTVEC= 20 ;: INPUT/OUTPUT TRAP (IOT) **SCOPE**
129 PWRVEC= 24 ;: POWER FAIL
130 EMTVEC= 30 ;: EMULATOR TRAP (EMT) **ERROR**
131 TRAPVEC=34 ;: "TRAP" TRAP
132 TKVEC= 60 ;: TTY KEYBOARD VECTOR
133 TPVEC= 64 ;: TTY PRINTER VECTOR
134 PIRQVEC=240 ;: PROGRAM INTERRUPT REQUEST VECTOR
135 ;MISCELLANEOUS EQUATES
136 LKS=177546
137 NOP=240
138 BUF2=774
139 BUF1=776

```

.SBTTL TRAP CATCHER

```

142 .=0
143 ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
144 ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
145 ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS

```

```

148 .=174
149 000174 000000 DISPREG: .WORD 0 ;: SOFTWARE DISPLAY REGISTER
150 000176 000000 SWREG: .WORD 0 ;: SOFTWARE SWITCH REGISTER

```

.SBTTL STARTING ADDRESS(ES)

```

152 000200 000137 001400 JMP @#KSTART ;: JUMP TO STARTING ADDRESS OF PROGRAM
153 ;*****

```

.SBTTL ACT11 HOOKS

```

156 ;HOOKS REQUIRED BY ACT11
157 $SVPC=. ;SAVE PC
158 .=46 ;: 1)SET LOC.46 TO ADDRESS OF $ENDAD IN .$EOP
159 000046 $ENDAD
160 000046 .=52 ;: 2)SET LOC.52 TO ZERO
161 000052 .WORD 0
162 000052 .=$SVPC ;: RESTORE PC
163 000204

```



```

164
165
166
167
168
169
170
171 001100 001100
172 001100 000000
173 001100 000000
174 001102 000
175 001103 000
176 001104 000000
177 001106 000000
178 001110 000000
179 001112 000000
180 001114 000
181 001115 001
182 001116 000000
183 001120 000000
184 001122 000000
185 001124 000000
186 001126 000000
187 001130 000000
188 001132 000000
189 001134 000000
190 001136 177570
191 001140 177570
192 001142 177560
193 001144 177562
194 001146 177564
195 001150 177566
196 001152 000
197 001153 002
198 001154 012
199 001155 000
200 001156 000000
201
202 001160 000000
203 001162 000000
204 001164 000000
205 001166 000000
206 001170 000000
207 001172 000000
208 001174 000000
209 001176 000000
210 001200 000000
211 001202 000000
212 001204 000000
213 001206 000000
214 001210 000000
215 001212 000000
216 001214 000000
217 001216 000000
218 001220 000000
219 001222 000000

```

.SBTTL COMMON TAGS

;*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
;*USED IN THE PROGRAM.

SCMTAG: . =1100

```

SPASS: .WORD 0
STSTNM: .BYTE 0
SERFLG: .BYTE 0
SICNT: .WORD 0
SLPADR: .WORD 0
SLPERR: .WORD 0
SERTTL: .WORD 0
SITEMB: .BYTE 0
SERMAX: .BYTE 1
SERRPC: .WORD 0
SGDADR: .WORD 0
SBDADR: .WORD 0
SGDDAT: .WORD 0
SBDDAT: .WORD 0
SWR: .WORD DSWR
DISPLAY: .WORD DDISP
STKS: 177560
STKB: 177562
STPS: 177564
STPB: 177566
SNL: .BYTE 0
SFILLS: .BYTE 2
SFILLC: .BYTE 12
STPFLG: .BYTE 0
SREGAD: .WORD 0
SREG0: .WORD 0
SREG1: .WORD 0
SREG2: .WORD 0
SREG3: .WORD 0
SREG4: .WORD 0
SREG5: .WORD 0
SREG6: .WORD 0
SREG7: .WORD 0
STMP0: .WORD 0
STMP1: .WORD 0
STMP2: .WORD 0
STMP3: .WORD 0
STMP4: .WORD 0
STMP5: .WORD 0
STMP6: .WORD 0
STMP7: .WORD 0
STIMES: 0
SESCAPE: 0

```

```

:: START OF COMMON TAGS
:: CONTAINS PASS COUNT
:: CONTAINS THE TEST NUMBER
:: CONTAINS ERROR FLAG
:: CONTAINS SUBTEST ITERATION COUNT
:: CONTAINS SCOPE LOOP ADDRESS
:: CONTAINS SCOPE RETURN FOR ERRORS
:: CONTAINS TOTAL ERRORS DETECTED
:: CONTAINS ITEM CONTROL BYTE
:: CONTAINS MAX. ERRORS PER TEST
:: CONTAINS PC OF LAST ERROR INSTRUCTION
:: CONTAINS ADDRESS OF 'GOOD' DATA
:: CONTAINS ADDRESS OF 'BAD' DATA
:: CONTAINS 'GOOD' DATA
:: CONTAINS 'BAD' DATA
:: RESERVED--NOT TO BE USED

:: ADDRESS OF SWITCH REGISTER
:: ADDRESS OF DISPLAY REGISTER
:: TTY KBD STATUS
:: TTY KBD BUFFER
:: TTY PRINTER STATUS REG. ADDRESS
:: TTY PRINTER BUFFER REG. ADDRESS
:: CONTAINS NULL CHARACTER FOR FILLS
:: CONTAINS # OF FILLER CHARACTERS REQUIRED
:: INSERT FILL CHARS. AFTER A "LINE FEED"
:: "TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
:: CONTAINS THE ADDRESS FROM WHICH (SREG0) WAS OBTAINED
:: CONTAINS ((SREGAD)+0)
:: CONTAINS ((SREGAD)+2)
:: CONTAINS ((SREGAD)+4)
:: CONTAINS ((SREGAD)+6)
:: CONTAINS ((SREGAD)+10)
:: CONTAINS ((SREGAD)+12)
:: CONTAINS ((SREGAD)+14)
:: CONTAINS ((SREGAD)+16)
:: USER DEFINED
:: USER DEFINED
:: USER DEFINED
:: USER DEFINED
:: USER DEFINED
:: USER DEFINED
:: USER DEFINED
:: USER DEFINED
:: USER DEFINED
:: MAX. NUMBER OF ITERATIONS
:: ESCAPE ON ERROR ADDRESS

```

J01

MAINDEC-11-DZKWA-F LINE FREQUENCY CLOCK PROGRAM
DZKRAF.P11 09-NOV-77 00:00 COMMON TAGS

MACY11 30(1046) 07-DEC-77 12:50 PAGE 6

SEQ 0009

220 001224 177607 000377
221 001230 077
222 001231 015
223 001232 000012

\$BELL: .ASCIZ <207><377><377> :: CODE FOR BELL
\$QUES: .ASCII /?/ :: QUESTION MARK
\$CRLF: .ASCII <15> :: CARRIAGE RETURN
\$LF: .ASCIZ <12> :: LINE FEED

224
225 001234 000000
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241 001236
242 001236 010454
243 001240 010535
244 001242 010616
245 001244 000000
246
247 001246 010634
248 001250 010666
249 001252 010740
250 001254 000000
251
252 001256 010754
253 001260 011047
254 001262 011120
255 001264 000000
256
257 001266 011134
258 001270 011233
259 001272 011370
260 001274 000000
261
262 001276 011406
263 001300 011457
264 001302 011530
265 001304 000000
266
267 001306 011544
268 001310 011602
269 001312 011654
270 001314 000000
271
272 001316 011670
273 001320 011757
274 001322 012036
275 001324 000000
276
277 001326 012054
278 001330 012130
279 001332 012214

WORD: 000000

.SBTTL ERROR POINTER TABLE

;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
;*LOCATION SITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
;*NOTE1: IF SITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

```

;*      EM      ;;POINTS TO THE ERROR MESSAGE
;*      DH      ;;POINTS TO THE DATA HEADER
;*      DT      ;;POINTS TO THE DATA
;*      DF      ;;POINTS TO THE DATA FORMAT

```

SERRTB:

```

EM1      ;;
DH1      ;;PC      PS      SP      TEST#      LKS      LKS      ;;
DT1      ;;SERRPC,$REG7,$REG6,$REG5,LKS,$GDDAT      S/B      ;;
0

EM2      ;;CLOCK FAILED TO INTERRUPT"
DH2      ;;PC      PS      SP      TEST#      LKS      "
DT2      ;;SERRPC,$REG7,$REG6,$REG5,LKS
0

EM3      ;;CLOCK INTERRUPTED WHEN THE PROCESSOR PRIORITY WAS TOO HIGH"
DH3      ;;PC      PS      SP      TEST#      LKS      "
DT3      ;;SERRPC,$REG7,$REG6,$REG5,LKS
0

EM4      ;;CLOCK GIVES UNEQUAL # OF PULSES OVER TWO EQUAL PERIODS OF TIME"
DH4      ;;PC      PS      SP      TEST#      1ST      2ND"
DT4      ;;SERRPC,$REG7,$REG6,$REG5,$REG1,$REG0
0

EM5      ;;LKS REGISTER RESPONDS TO ANOTHER ADDRESS"
DH5      ;;PC      PS      SP      TEST#      ADDRESS"
DT5      ;;SERRPC,$REG7,$REG6,$REG5,$GDADR
0

EM6      ;;A NO SACK TIMEOUT HAS OCCURED"
DH6      ;;PC      PS      SP      TEST#      LKS      "
DT6      ;;SERRPC,$REG7,$REG6,$REG5,LKS
0

EM7      ;;WRONG CONDITION CODES WERE PUT ONTO STACK BY INTERRUPT"
DH7      ;;PC      PS      SP      TEST#      CC      CC"
DT7      ;;SERRPC,$REG7,$REG6,$REG5,BUF1,$GDDAT
0

EM10     ;;WRONG PC PUT ONTO THE STACK BY AN INTERRUPT"
DH10     ;;PC      PS      SP      TEST#      "
DT10     ;;SERRPC,$REG7,$REG6,$REG5,BUF2,$GDDAT

```

ERROR POINTER TABLE

```

280 001334 000000 0
281
282 001336 012232 EM11 ;"TRAPPED TRYING TO ACCESS LKS REGISTER"
283 001340 012310 DH11 ;"(PC) (PS) (SP) TEST#"
284 001342 012346 DT11 ;$ERRPC,$REG7,$REG6,$REG5
285 001344 000000 0
286
287
288 ;STARTUP CODE
289 =1400
290 001400 012706 001000 KSTART: MOV #1000,SP ;INITIALIZE THE STACK SO WE CAN CALL THE TYPEOUT
291 001404 005046 CLR -(SP)
292 001406 013746 000034 MOV 34, -(SP) ;SAVE CURRENT TRAP VECTOR
293 001412 012737 001422 000034 MOV #64$,34 ;SETUP NEW TRAP VECTOT
294 001420 104400 TRAP ;PUSH OLD PSW AN PC ON STACK
295 001422 016666 000002 000006 64$: MOV 2(SP),6(SP)
296 001430 012716 001436 MOV #65$, (SP) ;REPLACE OLD PC WITH NEW
297 001434 000002 RTI ;RESTORE PSW
298 001436 012637 000034 65$: MOV (SP)+,34 ;RESTORE OLD TRAP VECTOR
299 001442 004737 006576 JSR PC,$TYPE ;PRINTOUT STARTUP MESSAGE
300 001446 010306 STMES ;ADDRESS OF MESSAGE "MAINDEC-11-DZKWA-F"
301 001450
302 001450 012706 001100 START: MOV #SCMTAG,R6 ;FIRST LOCATION TO BE CLEARED
303 001454 005026 CLR (R6)+ ;CLEAR MEMORY LOCATION
304 001456 022706 001126 CMP #SBDDAT,R6 ;DONE?
305 001462 001374 BNE -6 ;LOOP BACK IF NO
306 001464 012706 001000 MOV #1000,SP ;SETUP THE STACK POINTER
307 001470 012737 006324 000020 MOV #SCOPE,$IOTVEC ;IOT VECTOR FOR SCOPE ROUTINE
308 001476 012737 000340 000022 MOV #340,$IOTVEC+2 ;LEVEL 7
309 001504 012737 007620 000030 MOV #ERROR,$EMTVEC ;EMT VECTOR FOR ERROR ROUTINE
310 001512 012737 000340 000032 MOV #340,$EMTVEC+2 ;LEVEL 7
311 001520 012737 010024 000034 MOV #TRAP,$TRAPVEC ;TRAP VECTOR FOR TRAP CALLS
312 001526 012737 000340 000036 MOV #340,$TRAPVEC+2 ;LEVEL 7
313 001534 012737 010060 000024 MOV #SPWRON,$PWAVEC ;POWER FAILURE VECTOR
314 001542 012737 000340 000026 MOV #340,$PWAVEC+2 ;LEVEL 7
315 001550 013737 006164 006156 MOV SENDCT,$EOPCT ;SETUP END-OF-PROGRAM COUNTER
316 001556 005037 001220 CLR STINES ;INITIALIZE NUMBER OF ITERATIONS
317 001562 005037 001222 CLR SESCAPE ;CLEAR THE ESCAPE ON ERROR ADDRESS
318 001566 112737 000001 001115 MOV #1,$ERMAX ;ALLOW ONE ERROR PER TEST
319 001574 012737 001574 001106 MOV #,$SLPADR ;INITIALIZE THE LOOP ADDRESS FOR SCOPE
320 001602 012737 001602 001110 MOV #,$SLPERR ;SETUP THE ERROR LOOP ADDRESS
321 001610 013746 000004 MOV #4, -(SP) ;SAVE ERROR VECTOR
322 001614 013746 000006 MOV #6, -(SP)
323 001620 012737 001634 000004 MOV #64$,4 ;SET UP TIME OUT VECTOR
324 001626 005777 177304 TST $SWR ;TRY TO REFERENCE HARDWARE SWR
325 001632 000407 BR 65$ ;BRANCH IF NO TIMEOUT TRAP OCCURS
326 001634 012737 000176 001136 64$: MOV #SWREG,$SWR ;POINT TO SOFTWARE SWR
327 001642 012737 000174 001140 MOV #DISPREG,$DISPLAY ;POINT TO SOFTWARE DISPLAY REG
328 001650 022626 CMP (SP)+,(SP)+ ;RESTORE STACK
329 001652 012637 000006 65$: MOV (SP)+,$#6 ;RESTORE ERROR VECTOR
330 001656 012637 000004 MOV (SP)+,$#4
331 001662 005737 000042 TST 42 ;LOADED BY A MONITOR
332 001666 001401 BEQ T0001 ;BR IF NO
333 001670 000005 RESET ;YES--GENERATE AN INIT
334
335

```

```

336
337
338 .SBTTL TEST THAT THE LKS CAN BE REFERENCED WITHOUT A BUS ERROR
339 :LKS ACCESS TEST
340 001672 000004 001730 000004 T0001: SCOPE
341 001674 012737 000340 000006 MOV #E0001, J#4 ;PREPARE FOR ADDRESSING THE LKS REGISTER. BAD HARDWARE
342 001702 012737 000340 000006 MOV #340, J#6 ;COULD CAUSE A TRAP TO 4
343 001710 012737 001716 001106 MOV #R0001, $LPADR ;TIGHTEN UP THE SCOPE LOOP A BIT IN CASE OF AN ERROR
344 001716 012706 001000 R0001: MOV #1000, SP ;SETUP THE STACK POINTER IN CASE OF AN ERROR
345 001722 005037 177546 I0001: CLR #LKS ;JUST REFERENCE LKS. DONT WORRY IF IT DIDNT CLEAR YET
346 001730 104011 BR T0002 ;WE DIDNT TRAP IF WE REACH HERE. GO ON TO NEXT TEST
347 E0001: ERROR 11 ;ERROR:::TRAPED TRYING TO ACCESS THE LKS REGISTER
348
349
350 .SBTTL TEST THAT START CLEARS LINE CLOCK INTERRUPT ENABLE BIT
351 :TEST THAT START CLEARS LINE CLOCK INTERRUPT ENABLE BIT
352 001732 000004 T0002: SCOPE
353 001734 012737 006252 000004 MOV #TRAPO, J#4 ;SETUP VECOR IN CASE OF UNFORSEEN PROBLEMS
354 001742 012737 000340 000006 MOV #340, J#6 ;NO INTERRUPTS WHILE PRINTING FATAL MESSAGE
355 001750 012737 001756 001106 MOV #R0002, $LPADR ;SETUP LOOPBACK ADDRESS IN CASE OF AN ERROR
356 001756 000005 R0002: RESET
357 001760 012737 000200 001124 MOV #200, $GDDAT ;HAVE GOOD DATA INFO READY FOR TYPEOUT IN CASE OF AN ERR
358 001766 032737 000100 177546 BIT #100, LKS ;TEST THE INTERRUPT ENABLE BIT
359 001774 001401 BEQ T0003
360 001776 104001 E0002: ERROR 1 ;ERROR, CLOCK INTERRUPT ENABLE NOT CLEARED BY INIT
361
362
363 .SBTTL TEST THAT START SETS CLOCK FLAG
364 :TEST THAT START SETS CLOCK FLAG
365 002000 000004 T0003: SCOPE
366 002002 012737 006252 000004 MOV #TRAPO, J#4 ;SETUP VECOR IN CASE OF UNFORSEEN PROBLEMS
367 002010 012737 000340 000006 MOV #340, J#6 ;NO INTERRUPTS WHILE PRINTING FATAL MESSAGE
368 002016 012737 000200 001124 MOV #200, $GDDAT ;HAVE GOOD DATA INFO READY FOR TYPEOUT IN CASE OF AN ERR
369 002024 012737 002032 001106 MOV #R0003, $LPADR ;SETUP LOOPBACK ADDRESS IN CASE OF AN ERROR
370 002032 000005 R0003: RESET ;SHOULD SET THE CLOCK FLAG
371 002034 105737 177546 TSTB LKS ;FIND OUT IF IT DID
372 002040 100401 BMI T0004 ;GO ON TO THE NEXT TEST IF IT SET THE CLOCK FLAG
373 002042 104001 E0003: ERROR 1 ;ERROR, CLOCK FLAG NOT SET BY INIT
374
375
376 .SBTTL TEST THAT CLOCK FLAG WILL SET AFTER SUFFICIENT PERIOD OF TIME (20 MS MIN)
377 :TEST THAT CLOCK FLAG WILL SET AFTER SUFFICIENT PERIOD OF TIME (20 MS MIN)
378 002044 000004 T0004: SCOPE
379 002046 012737 006252 000004 MOV #TRAPO, J#4 ;SETUP VECOR IN CASE OF UNFORSEEN PROBLEMS
380 002054 012737 000340 000006 MOV #340, J#6 ;NO INTERRUPTS WHILE PRINTING FATAL MESSAGE
381 002062 012737 002070 001106 MOV #R0004, $LPADR ;SETUP LOOPBACK ADDRESS IN CASE OF AN ERROR
382 002070 012737 000200 001124 R0004: MOV #200, $GDDAT ;HAVE GOOD DATA INFO READY FOR TYPEOUT IN CASE OF AN ERR
383 002076 005037 177546 CLR LKS ;CLEAR THE CLOCK FLAG
384 002102 005000 CLR RO ;AND A TIMER LOCATION
385 002104 105737 177546 A0004: TSTB LKS ;IS CLOCK FLAG SET
386 002110 100403 BMI T0005
387 002112 005200 INC RO ;NO INCREMENT COUNT 003 WAIT FOR SOMEMORE
388 002114 001373 BNE A0004 ;WAIT SUFFICIENT AMOUNT OF TIME FOR CLOCK
389 002116 104001 E0004: ERROR 1 ;ERROR, CLOCK FLAG FAILED TO SET
390
391

```

NO1

```

392
393
394
395      .SBTTL TEST THAT INTERRUPT ENABLE BIT MAY BE SET
396      :TEST THAT INTERRUPT ENABLE BIT MAY BE SET
397      T0005: SCOPE
398      002120 000004          MOV      #TRAPO,2#4      ;SETUP VECOR IN CASE OF UNFORSEEN PROBLEMS
399      002122 012737 006252 000004      MOV      #340,2#6      ;NO INTERRUPTS WHILE PRINTING FATAL MESSAGE
400      002130 012737 000340 000006      MOV      #100,$GDDAT    ;HAVE GOOD DATA INFO READY FOR TYPEOUT IN CASE OF AN ERR
401      002136 012737 000100 001124      MOV      #R0005,$LPAOR  ;SETUP LOOP BACK ADDRESS IN CASE OF ERROR
402      002144 012737 002164 001106      MOV      PR7,-(SP)      ;PUT NEW PS ON STACK
403      002152 013746 000340          MOV      #64$,-(SP)    ;PUT NEW PC ON STACK
404      002156 012746 002164          RTI                          ;POP NEW PC AND PS
405      002162 000002
406      002164 005037 177546      64$:
407      002170 005003          R0005: CLR      LKS
408      002172 105737 177546      R3                          ;INITIALIZE A COUNTER LOCATION
409      002176 100404          A0005: CLR      R3
410      002200 005203          TSTB     LKS              ;IS THE CLOCK FLAG SET?
411      002202 001373          BMI      B0005           ;IF SO, CONTINUE ON WITH THE TEST
412      002204 104001          INC      R3              ;IF NOT INCREMENT THE COUNTER LOCATION
413      002206 000410          BNE     A0005           ;AND GO TEST THE CLOCK FLAG AGAIN. UNLESS...
414      002210          E0005: ERROR 1
415      002210 012737 000100 177546      BR      T0006           ;CLOCK FLAG DID NOT SET AFTER A WAITING PERIOD > 20 MS
416      002216 032737 000100 177546      B0005: MOV      #100,LKS
417      002224 001001          BIT      #100,LKS
418      002226 104001          BNE     T0006           ;CLEAR CLOCK FLAG AND SET INTERRUPT ENABLE
419          E1005: ERROR 1      ;IS INTERRUPT ENABLE SET?
420          ;ERROR INTERRUPT ENABLE NOT SET
421
422      .SBTTL TEST THAT INTERRUPT ENABLE BIT MAY BE CLEARED
423      :TEST THAT INTERRUPT ENABLE BIT MAY BE CLEARED
424      T0006: SCOPE
425      002230 000004          MOV      #TRAPO,2#4      ;SETUP VECOR IN CASE OF UNFORSEEN PROBLEMS
426      002232 012737 006252 000004      MOV      #340,2#6      ;NO INTERRUPTS WHILE PRINTING FATAL MESSAGE
427      002240 012737 000340 000006      MOV      #0,$GDDAT     ;INITIALIZE THE LOOPBACK ADDRESS IN CASE OF AN ERROR
428      002246 012737 000000 001124      MOV      #R0006,$LPAOR  ;SETUP LOOP BACK ADDRESS IN CASE OF AN ERROR
429      002254 012737 002274 001106      MOV      PR7,-(SP)      ;PUT NEW PS ON STACK
430      002256 013746 000340          MOV      #64$,-(SP)    ;PUT NEW PC ON STACK
431      002262 012746 002274          RTI                          ;POP NEW PC AND PS
432      002272 000002
433      002274 005037 177546      64$:
434      002300 005003          R0006: CLR      LKS
435      002302 105737 177546      R3                          ;INITIALIZE A COUNTER LOCATION
436      002306 100404          A0006: CLR      R3
437      002310 005203          TSTB     LKS              ;IS THE CLOCK FLAG SET?
438      002312 001373          BMI      B0006           ;IF SO, CONTINUE ON WITH THE TEST
439      002314 104001          INC      R3              ;IF NOT INCREMENT THE COUNTER LOCATION
440      002316 000412          BNE     A0006           ;AND GO TEST THE CLOCK FLAG AGAIN. UNLESS...
441      002320          E0006: ERROR 1
442      002320 012737 000100 177546      BR      T0007           ;CLOCK FLAG DID NOT SET AFTER A WAITING PERIOD > 20 MS
443      002326 005037 177546      B0006: MOV      #100,LKS
444      002332 032737 000100 177546      CLR      LKS
445      002340 001401          BIT      #100,LKS
446      002342 104001          BEQ     T0007           ;CLEAR CLOCK FLAG AND SET INTERRUPT ENABLE
447          E10006: ERROR 1  ;CLEAR INTERRUPT ENABLE
448          ;TEST THE INTERRUPT ENABLE BIT
449          ;IS INTERRUPT ENABLE CLEARED
450          ;ERROR, ERROR INTERRUPT BIT CAN NOT BE CLEARED

```

```

448
449
450
451
452 002344 000004
453 002346 012737 006252 000004
454 002354 012737 000340 000006
455 002362 012737 000300 001124
456 002370 012737 002412 001106
457 002376 012737 002474 000100
458 002404 012737 000340 000102
459 002412 012706 001000
460 002416 005046
461 002420 012746 002426
462 002424 000002
463 002426 005037 177546
464 002432 005003
465 002434 105737 177546
466 002440 100404
467 002442 005203
468 002444 001373
469 002446 104001
470 002450 000415
471 002452
472 002452 012737 000100 177546
473 002460 005000
474 002462 005200
475 002464 000240
476 002466 001375
477 002470 104002
478 002472 000404
479 002474 105737 177546
480 002500 100401
481 002502 104001
482
483
484
485
486
487
488 002504 000004
489 002506 012737 006252 000004
490 002514 012737 000340 000006
491 002522 012737 002544 001106
492 002530 012737 002654 000100
493 002536 012737 000340 000102
494 002544 005037 177546
495 002550 013746 000004
496 002554 012737 002572 000004
497 002562 012737 000240 177776
498 002570 000404
499 002572 022626
500 002574 012637 000004
501 002600 000431
502 002602 012637 000004
503 002606 012706 001000

.SBTTL TEST THAT CLOCK INTERRUPTS TO CORRECT VECTOR ADDRESS
:TEST THAT CLOCK INTERRUPTS TO CORRECT VECTOR ADDRESS
T0007: SCOPE
MOV #TRAPO,2#4 ;SETUP VECOR IN CASE OF UNFORSEEN PROBLEMS
MOV #340,2#6 ;NO INTERRUPTS WHILE PRINTING FATAL MESSAGE
MOV #300,$GDDAT ;HAVE GOOD DATA INFO READY FOR TYPEOUT IN CASE OF AN ERR
MOV #R0007,$LPADR ;INITIALIZE THE LOOPBACK ADDRESS IN CASE OF AN ERROR
MOV #00007,100 ;SET UP VECTOR RETURN POINTER
MOV #340,2#102 ;1 INTERRUPT IS ENOUGH
R0007: MOV #1000,$P ;GET STACK READY FOR INTERRUPTS
CLR -(SP) ;DROP CPU PRIORITY LEVEL
MOV #1$,-(SP) ;SET RETURN ADDRESS ON STACK FROM 'RTI'
RTI ;RETURN TO NEXT INSTRUCTION

1$: CLR LKS ;INITIALIZE A COUNTER LOCATION
CLR R3 ;IS THE CLOCK FLAG SET?
A0007: TSTB LKS ;IF SO, CONTINUE ON WITH THE TEST
BMI B0007 ;IF NOT INCREMENT THE COUNTER LOCATION
INC R3 ;AND GO TEST THE CLOCK FLAG AGAIN. UNLESS...
BNE A0007 ;CLOCK FLAG DID NOT SET AFTER A WAITING PERIOD > 20 MS
E0007: ERROR 1
BR T0010
B0007: MOV #100,LKS ;ENABLE INTERRUPT
CLR RO
C0007: INC RO
NOP ;STALL FOR TIME
BNE C0007 ;WAIT FOR INTERRUPT
E10007: ERROR 2
BR T0010
D0007: TSTB LKS ;ENTER HERE IF INTERRUPTED
BMI T0010
E20007: ERROR 1 ;ERROR, INTERRUPT NOT CAUSED BY CLOCK

.SBTTL TEST THAT CLOCK WILL INTERRUPT WITH PROCESSOR AT PRIORITY 5
:TEST THAT CLOCK WILL INTERRUPT WITH PROCESSOR AT PRIORITY 5
:NOTE: IF THERE IS NO HARDWARE 'PSW' THIS TEST WILL BE SKIPPED
T0010: SCOPE
MOV #TRAPO,2#4 ;SETUP VECOR IN CASE OF UNFORSEEN PROBLEMS
MOV #340,2#6 ;NO INTERRUPTS WHILE PRINTING FATAL MESSAGE
MOV #R0010,$LPADR ;INITIALIZE THE LOOPBACK ADDRESS IN CASE OF AN ERROR
MOV #00010,100 ;SET UP VECTOR RETURN POINTER
MOV #340,2#102 ;NO INTERRUPTS ALLOWED AFTER THE FIRST ONE
R0010: CLR LKS
MOV 4,-(SP) ;SAVE BUS TIMEOUT VECTOR CONTENTS
MOV #1$,4 ;SET A SERVICE 'PC' IN CASE TIMEOUT OCCURS
MOV #PR5,$P ;DO WE HAVE A HARDWARE 'PSW'?
BR 2$ ;BRANCH IF YES
1$: CMP (SP)+,(SP)+ ;RESTORE STACK FROM TIMEOUT
MOV (SP)+,4 ;RESTORE BUS TIMEOUT VECTOR CONTENTS
BR T0011
2$: MOV (SP)+,4 ;RESTORE BUS TIMEOUT VECTOR CONTENTS
MOV #1000,$P ;INITIALIZE THE STACK POINTER

```

```

504 002612 005003          CLR      R3          ;INITIALIZE A COUNTER LOCATION
505 002614 105737 177546 A0010: TSTB     LKS          ;IS THE CLOCK FLAG SET?
506 002620 100404          BMI      B0010        ;IF SO, CONTINUE ON WITH THE TEST
507 002622 005203          INC      R3          ;IF NOT INCREMENT THE COUNTER LOCATION
508 002624 001373          BNE      A0010        ;AND GO TEST THE CLOCK FLAG AGAIN. UNLESS...
509 002626 104001          E0010: ERROR 1      ;CLOCK FLAG DID NOT SET AFTER A WAITING PERIOD > 20 MS
510 002630 000415          BR       T0011
511 002632
512 002634 012737 000100 177546 B0010: MOV      #100,LKS      ;ENABLE INTERRUPT
513 002640 005000          CLR      R0
514 002642 005200          C0010: INC      R0
515 002644 000240          NOP
516 002646 001375          BNE      C0010        ;STALL FOR SOME TIME
517 002650 104002          E10010: ERROR 2      ;WAIT FOR INTERRUPT
518 002652 000404          BR       T0011        ;ERROR, INTERRUPT FAILED TO OCCUR
519 002654 105737 177546 D0010: TSTB     LKS          ;ENTER HERE IF INTERRUPTED
520 002660 100401          BMI      T0011
521 002662 104001          E20010: ERROR 1      ;ERROR, INTERRUPT DID NOT CLEAR THE CLOCK FLAG
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
002664 000004          .SBTTL  TEST THAT CLOCK WILL NOT INTERRUPT WITH PROCESSOR PRIORITY 6
002666 012737 006252 000004 ;TEST THAT CLOCK WILL NOT INTERRUPT WITH PROCESSOR PRIORITY 6
002674 012737 000340 000006 ;NOTE: IF THERE IS NO HARDWARE 'PSW' THIS TEST WILL BE SKIPPED
002702 012737 002710 001106 T0011: SCOPE
002710 005037 177546          MOV      #TRAPO,2#4    ;SETUP VECOR IN CASE OF UNFORSEEN PROBLEMS
002714 005003          MOV      #340,2#6     ;NO INTERRUPTS WHILE PRINTING FATAL MESSAGE
002716 105737 177546          MOV      #R0011,SLPADR ;SETUP LOOPBACK ADDRESS IN CASE OF AN ERROR
002722 100404          R0011: CLR      LKS
002724 005203          CLR      R3          ;INITIALIZE A COUNTER LOCATION
002726 001373          A0011: TSTB     LKS          ;IS THE CLOCK FLAG SET?
002730 104001          BMI      B0011        ;IF SO, CONTINUE ON WITH THE TEST
002732 000443          INC      R3          ;IF NOT INCREMENT THE COUNTER LOCATION
002734          BNE      A0011        ;AND GO TEST THE CLOCK FLAG AGAIN. UNLESS...
002736          E0011: ERROR 1      ;CLOCK FLAG DID NOT SET AFTER A WAITING PERIOD > 20 MS
002738          BR       T0012
002740          B0011: MOV      #1000,SP      ;INITIALIZE THE STACK POINTER
002742          MOV      4-(SP)      ;SAVE BUS TIMEOUT VECTOR CONTENTS
002744          MOV      #1$ 4      ;SET SERVICE 'PC' IN CASE TIMEOUT OCCURS
002746          MOV      #PR6,PS    ;DO WE HAVE A HARDWARE 'PSW'?
002748          BR       2$
002750          CMP      (SP)+,(SP)+ ;BRANCH IF YES
002752          MOV      (SP)+,4    ;RESTORE STACK FROM BUS TIMEOUT
002754          BR       T0012    ;RESTORE BUS TIMEOUT VECTOR CONTENTS
002756          MOV      (SP)+,4
002758          MOV      #E1011,100 ;RESTORE BUS TIMEOUT VECTOR CONTENTS
002760          MOV      #100,LKS  ;SET UP VECTOR RETURN
002762          CLR      R3          ;ENABLE INTERRUPT
002764          TSTB     LKS          ;INITIALIZE A COUNTER LOCATION
002766          BMI      D0011        ;IS THE CLOCK FLAG SET?
002768          INC      R3          ;IF SO, CONTINUE ON WITH THE TEST
002770          BNE      C0011        ;IF NOT INCREMENT THE COUNTER LOCATION
002772          E1011: ERROR 1      ;AND GO TEST THE CLOCK FLAG AGAIN. UNLESS...
002774          BR       T0011        ;CLOCK FLAG DID NOT SET AFTER A WAITING PERIOD > 20 MS
002776          D0011:
003004          MOV      #100,LKS
003012          CLR      R3
003014          TSTB     LKS
003020          BMI      D0011
003022          INC      R3
003024          BNE      C0011
003026          E1011: ERROR 1
003030          BR       T0011
003032          D0011:

```



```

560 003032 000240      NOP
561 003034 000240      NOP
562 003036 000401      BR
563 003040 104003      E20011: ERROR 3
564
565
566
567 .SBTTL TEST THAT RESET SETS CLOCK FLAG
568 :TEST THAT RESET SETS CLOCK FLAG
569 003042 000004      T0012: SCOPE
570 003044 012737 000200 001124      MOV #200,$GDDAT ;HAVE GOOD DATA INFO READY FOR TYPEOUT IN CASE OF AN ERR
571 003052 012737 006252 000004      MOV #TRAP0,2#4 ;SETUP VECOR IN CASE OF UNFORSEEN PROBLEMS
572 003060 012737 000340 000006      MOV #340,2#6 ;NO INTERRUPTS WHILE PRINTING FATAL MESSAGE
573 003066 012737 003074 001106      MOV #R0012,$LPADR ;SETUP LOOPBACK ADDRESS IN CASE OF AN ERROR
574 003074 005037 177546      R0012: CLR LKS ;CLEAR CLOCK FLAG
575 003100 005003      CLR R3 ;INITIALIZE A COUNTER LOCATION
576 003102 105737 177546      A0012: TSTB LKS ;IS THE CLOCK FLAG SET?
577 003106 100404      BMI B0012 ;IF SO, CONTINUE ON WITH THE TEST
578 003110 005203      INC R3 ;IF NOT INCREMENT THE COUNTER LOCATION
579 003112 001373      BNE A0012 ;AND GO TEST THE CLOCK FLAG AGAIN. UNLESS...
580 003114 104001      E0012: ERROR 1 ;CLOCK FLAG DID NOT SET AFTER A WAITING PERIOD > 20 MS
581 003116 000407      BR T0013
582 003120
583 003120 005037 177546      B0012: CLR LKS
584 003124 000005      RESET ;SHOULD SET CLOCK FLAG
585 003126 105737 177546      TSTB LKS
586 003132 100401      BMI T0013
587 003134 104001      E10012: ERROR 1 ;ERROR, RESET DIDN'T SET CLOCK FLAG
588
589
590
591 .SBTTL TEST LINE CLOCK REPEATABILITY
592 :TEST LINE CLOCK REPEATABILITY
593 :MAKE SURE THAT OVER TWO EQUAL PERIODS OF TIME
594 :THE CLOCK PUTS OUT THE SAME NUMBER OF PULSES
595 003136 000004      T0013: SCOPE
596 003140 005000      R0013: CLR R0 ;CLEAR 1ST TIME COUNT
597 003142 005001      CLR R1 ;CLEAR 1ST CLOCK COUNT
598 003144 013746 000340      MOV PR7,-(SP) ;PUT NEW PS ON STACK
599 003150 012746 003156      MOV #64$,-(SP) ;PUT NEW PC ON STACK
600 003154 000002      RTI ;POP NEW PC AND PS
601 003156
602 003156 012737 003156 001106      64$: R1013: MOV #R1013,$LPADR ;ERROR IN NEXT FEW INSTRUCTIONS CAUSES A SHORT SCOPE LO
603 003164 005037 177546      CLR LKS
604
605 003170 005003      CLR R3 ;SYNC ON CLOCK FLAG A COUPLE OF TIMES
606 003172 105737 177546      A0013: TSTB LKS ;INITIALIZE A COUNTER LOCATION
607 003176 100404      BMI B0013 ;IS THE CLOCK FLAG SET?
608 003200 005203      INC R3 ;IF SO, CONTINUE ON WITH THE TEST
609 003202 001373      BNE A0013 ;IF NOT INCREMENT THE COUNTER LOCATION
610 003204 104001      E0013: ERROR 1 ;AND GO TEST THE CLOCK FLAG AGAIN. UNLESS...
611 003206 000524      BR T0014 ;CLOCK FLAG DID NOT SET AFTER A WAITING PERIOD > 20 MS
612 003210
613 003210 012737 003210 001106      B0013: MOV #R2013,$LPADR ;MAKE SCOPE LOOP SHORT IN CASE OF AN ERROR
614 003216 005037 177546      CLR LKS
615 003222 005003      CLR R3 ;INITIALIZE A COUNTER LOCATION

```

616	003224	105737	177546		C0013:	TSTB	LKS		: IS THE CLOCK FLAG SET?
617	003230	100404				BMI	D0013		: IF SO, CONTINUE ON WITH THE TEST
618	003232	005203				INC	R3		: IF NOT INCREMENT THE COUNTER LOCATION
619	003234	001373				BNE	C0013		: AND GO TEST THE CLOCK FLAG AGAIN. UNLESS...
620	003236	104001			E10013:	ERROR 1			: CLOCK FLAG DID NOT SET AFTER A WAITING PERIOD > 20 MS
621	003240	000507				BR	T0014		
622	003242				D0013:				
623	003242	005037	177546			CLR	LKS		
624	003246	032737	000200	177546	1\$:	BIT	#200,LKS		: IS THE CLOCK FLAG SET ?
625	003254	001374				BNE	1\$: NO, WAIT FOR IT
626	003256	005037	177546			CLR	LKS		
627	003262	105737	177546		F0013:	TSTB	LKS		: IS CLOCK FLAG SET
628	003266	100003				BPL	G0013		: NO
629	003270	005201				INC	R1		: +1 TO CLOCK COUNT
630	003272	005037	177546			CLR	LKS		: CLEAR CLOCK IF SET
631	003276	005200			G0013:	INC	R0		: +1 TO TIME COUNT
632	003300	001370				BNE	F0013		: REPEAT UNTIL R0=0
633	003302	005000				CLR	R0		: CLEAR 2ND TIME COUNT
634	003304	005002				CLR	R2		: CLEAR 2ND CLOCK COUNT
635	003306	012737	003306	001106	R3013:	MOV	#R3013,\$LPADR		: INSURE A SHORT SCOPE LOOP
636	003314	005037	177546			CLR	LKS		
637									: SYNC ON CLOCK FLAG TWICE
638	003320	005003				CLR	R3		: INITIALIZE A COUNTER LOCATION
639	003322	105737	177546		H0013:	TSTB	LKS		: IS THE CLOCK FLAG SET?
640	003326	100404				BMI	J0013		: IF SO, CONTINUE ON WITH THE TEST
641	003330	005203				INC	R3		: IF NOT INCREMENT THE COUNTER LOCATION
642	003332	001373				BNE	H0013		: AND GO TEST THE CLOCK FLAG AGAIN. UNLESS...
643	003334	104001			E20013:	ERROR 1			: CLOCK FLAG DID NOT SET AFTER A WAITING PERIOD > 20 MS
644	003336	000450				BR	T0014		
645	003340				J0013:				
646	003340	012737	003340	001106	R4013:	MOV	#R4013,\$LPADR		: INSURE A SHORT SCOPE LOOP
647	003346	005037	177546			CLR	LKS		
648	003352	005003				CLR	R3		: INITIALIZE A COUNTER LOCATION
649	003354	105737	177546		K0013:	TSTB	LKS		: IS THE CLOCK FLAG SET?
650	003360	100404				BMI	L0013		: IF SO, CONTINUE ON WITH THE TEST
651	003362	005203				INC	R3		: IF NOT INCREMENT THE COUNTER LOCATION
652	003364	001373				BNE	K0013		: AND GO TEST THE CLOCK FLAG AGAIN. UNLESS...
653	003366	104001			E30013:	ERROR 1			: CLOCK FLAG DID NOT SET AFTER A WAITING PERIOD > 20 MS
654	003370	000433				BR	T0014		
655	003372				L0013:				
656	003372	012737	003140	001106		MOV	#R0013,\$LPADR		: MUST LOOP BACK TO BEGINING OF TEST IF EEROR COMES NOW
657	003400	005037	177546			CLR	LKS		
658	003404	032737	000200	177546	1\$:	BIT	#200,LKS		: IS CLOCK FLAG SET ?
659	003412	001374				BNE	1\$: NO, WAIT
660	003414	005037	177546			CLR	LKS		
661	003420	105737	177546		M0013:	TSTB	LKS		: IS CLOCK FLAG SET
662	003424	100003				BPL	N0013		: NO
663	003426	005202				INC	R2		: +1 TO CLOCK COUNT
664	003430	005037	177546			CLR	LKS		: CLEAR CLOCK IF SET
665	003434	005200			N0013:	INC	R0		: +1 TO TIME COUNT
666	003436	001370				BNE	M0013		: REPEAT UNTIL R0=0
667	003440	020102				CMP	R1,R2		: IS 1ST CLOCK COUNT EQUAL TO 2ND CLOCK COUNT?
668	003442	001406				BEG	T0014		: YES
669	003444	010137	001162		E40013:	MOV	R1,\$REG1		: GET R1 READY FOR PRINTOUT
670	003450	010237	001164			MOV	R2,\$REG2		: GET R2 READY FOR PRINTOUT
671	003454	104004				ERROR 4			: ERROR, CLOCK FLAG OCCURRED DIFFERENT

672 003456 000240 NOP ;NUMBER OF TIMES IN EQUAL PERIODS

673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727

003460 000004
003462 005037 001124
003466 012737 003530 001106
003474 012737 157546 001120
003502 012737 003546 000004
003510 012737 000340 000006
003516 013746 000340
003522 012746 003530
003526 000002
003530 012706 001000
003534 005037 177546
003540 012777 000100 175352
003546 032737 000100 177546
003554 001401
003556 104005
003560 005037 177546
003564 012737 003576 000004
003572 005077 175322

```
.SBTTL LINE CLOCK REGISTER ADDRESSING TEST
:LINE CLOCK REGISTER ADDRESSING TEST
:TEST THAT THE "LKS" REGISTER CAN NOT BE ADDRESSED AS ANYTHING BUT 177546
:SET A LOCATION THAT IS CLOSE(DIFFERS BY 1 BIT) TO THE LKS REGISTER
:TO 100. IF THE LKS ALSO CHANGES, THEN SIGNAL AN ERROR
T0014: SCOPE
      CLR      $GDDAT
      MOV      #R0014,$LPADR ;INITIALIZE THE LOOPBACK ADDRESS IN CASE OF AN ERROR
      MOV      #157546,$GDADR ;SAME AS "LKS" ADDRESS EXCEPT WITH BIT 13 CLEAR
      MOV      #A0014,4 ;SETUP VECTOR IN CASE IT IS NONEXISTANT
      MOV      #340,6
      MOV      PR7,-(SP) ;:PUT NEW PS ON STACK
      MOV      #64$,-(SP) ;:PUT NEW PC ON STACK
      RTI ;:POP NEW PC AND PS

64$:
R0014: MOV      #1000,SP ;SETUP THE STACK
      CLR      LKS
I0014: MOV      #100,$SGDADR ;SET THE "CLOSE" ADDRESS TO = 100
A0014: BIT      #100,LKS ;MAKE SURE THAT "LKS" WAS NOT AFFECTED
      BEQ      B0014
E0014: ERROR 5 ;IT AFFECTED "LKS" -- ERROR
B0014: CLR      LKS
      MOV      #T0015,4
      CLR      $SGDADR ;CLEAR OUT THE "CLOSE" ADDRESS
```

```
.SBTTL LINE CLOCK REGISTER ADDRESSING TEST
:LINE CLOCK REGISTER ADDRESSING TEST
T0015: SCOPE
      MOV      #A0015,4 ;SETUP VECTOR IN CASE IT IS NONEXISTANT
      MOV      #340,6
      CLR      $GDDAT
      MOV      #R0015,$LPADR ;INITIALIZE THE LOOPBACK ADDRESS IN CASE OF AN ERROR
      MOV      #177146,$GDADR ;SAME AS "LKS" ADDRESS EXCEPT WITH BIT 8 CLEAR
      MOV      PR7,-(SP) ;:PUT NEW PS ON STACK
      MOV      #64$,-(SP) ;:PUT NEW PC ON STACK
      RTI ;:POP NEW PC AND PS

64$:
R0015: MOV      #1000,SP ;SETUP THE STACK
      CLR      LKS
I0015: MOV      #100,$SGDADR ;SET THE "CLOSE" ADDRESS TO = 100
A0015: BIT      #100,LKS ;MAKE SURE THAT "LKS" WAS NOT AFFECTED
      BEQ      B0015
E0015: ERROR 5 ;IT AFFECTED "LKS" -- ERROR
B0015: CLR      LKS
      MOV      #T0016,4
      CLR      $SGDADR ;CLEAR OUT THE "CLOSE" ADDRESS
```

.SBTTL LINE CLOCK REGISTER ADDRESSING TEST

LINE CLOCK REGISTER ADDRESSING TEST

```

728 ;LINE CLOCK REGISTER ADDRESSING TEST
729 003714 000004 10016: SCOPE
730 003716 012737 004002 000004 MOV #A0016,4 ;SETUP VECTOR IN CASE IT IS NONEXISTANT
731 003724 012737 000340 000006 MOV #340,6
732 003732 005037 001124 CLR $GDDAT
733 003736 012737 003764 001106 MOV #R0016,$LPADR ;INITIALIZE THE LOOPBACK ADDRESS IN CASE OF AN ERROR
734 003744 012737 177446 001120 MOV #177446,$GDADR ;SAME AS "LKS" ADDRESS EXCEPT WITH BIT 6 CLEAR
735 003752 013746 000340 MOV PR7,-(SP) ;PUT NEW PS ON STACK
736 003756 012746 003764 MOV #64$,-(SP) ;PUT NEW PC ON STACK
737 003762 000002 RTI ;POP NEW PC AND PS
738 003764
739 003764 012706 001000 64$: MOV #1000,SP ;SETUP THE STACK
740 003770 005037 177546 R0016: CLR LKS
741 003774 012777 000100 175116 I0016: MOV #100,$SGDADR ;SET THE "CLOSE" ADDRESS TO = 100
742 004002 032737 000100 177546 A0016: BIT #100,LKS ;MAKE SURE THAT "LKS" WAS NOT AFFECTED
743 004010 001401 BEQ B0016
744 004012 104005 E0016: ERROR 5 ;IT AFFECTED "LKS" -- ERROR
745 004014 005037 177546 B0016: CLR LKS
746 004020 012737 004032 000004 MOV #T0017,4
747 004026 005077 175066 CLR $SGDADR ;CLEAR OUT THE "CLOSE" ADDRESS
748
749
750
751
752

```

.SBTTL LINE CLOCK REGISTER ADDRESSING TEST

```

753 004032 000004 ;LINE CLOCK REGISTER ADDRESSING TEST
754 004034 012737 004120 000004 10017: SCOPE
755 004042 012737 000340 000006 MOV #A0017,4 ;SETUP VECTOR IN CASE IT IS NONEXISTANT
756 004050 005037 001124 CLR $GDDAT
757 004054 012737 004102 001106 MOV #R0017,$LPADR ;INITIALIZE THE LOOPBACK ADDRESS IN CASE OF AN ERROR
758 004062 012737 177556 001120 MOV #177556,$GDADR ;SAME AS "LKS" ADDRESS EXCEPT WITH BIT 3 SET
759 004070 013746 000340 MOV PR7,-(SP) ;PUT NEW PS ON STACK
760 004074 012746 004102 MOV #64$,-(SP) ;PUT NEW PC ON STACK
761 004100 000002 RTI ;POP NEW PC AND PS
762 004102
763 004102 012706 001000 64$: MOV #1000,SP ;SETUP THE STACK
764 004106 005037 177546 R0017: CLR LKS
765 004112 012777 000100 175000 I0017: MOV #100,$SGDADR ;SET THE "CLOSE" ADDRESS TO = 100
766 004120 032737 000100 177546 A0017: BIT #100,LKS ;MAKE SURE THAT "LKS" WAS NOT AFFECTED
767 004126 001401 BEQ B0017
768 004130 104005 E0017: ERROR 5 ;IT AFFECTED "LKS" -- ERROR
769 004132 005037 177546 B0017: CLR LKS
770 004136 012737 004150 000004 MOV #T0020,4
771 004144 005077 174750 CLR $SGDADR ;CLEAR OUT THE "CLOSE" ADDRESS
772
773
774
775
776

```

.SBTTL LINE CLOCK REGISTER ADDRESSING TEST

```

777 004150 000004 ;LINE CLOCK REGISTER ADDRESSING TEST
778 004152 012737 004236 000004 10020: SCOPE
779 004160 012737 000340 000006 MOV #A0020,4 ;SETUP VECTOR IN CASE IT IS NONEXISTANT
780 004166 005037 001124 CLR $GDDAT
781 004172 012737 004220 001106 MOV #R0020,$LPADR ;INITIALIZE THE LOOPBACK ADDRESS IN CASE OF AN ERROR
782 004200 012737 177566 001120 MOV #177566,$GDADR ;SAME AS "LKS" ADDRESS EXCEPT WITH BIT 4 SET
783 004206 013746 000340 MOV PR7,-(SP) ;PUT NEW PS ON STACK

```

```

784 004212 012746 004220      MOV      #64$,-(SP)      ;;PUT NEW PC ON STACK
785 004216 000002              RTI                    ;; POP NEW PC AND PS
786 004220                    64$:
787 004220 012706 001000      R0020:  MOV      #1000,SP      ;SETUP THE STACK
788 004224 005037 177546      CLR      LKS
789 004230 012777 000100 174662 I0020:  MOV      #100,JSGDADR      ;SET THE "CLOSE" ADDRESS TO = 100
790 004236 032737 000100 177546 A0020:  BIT      #100,LKS        ;MAKE SURE THAT "LKS" WAS NOT AFFECTED
791 004244 001401              BEQ      B0020
792 004246 104005      E0020:  ERROR 5      ;IT AFFECTED "LKS" -- ERROR
793 004250 005037 177546      B0020:  CLR      LKS
794 004254 012737 004266 000004  MOV      #T0021 ,4
795 004262 005077 174632      CLR      JSGDADR      ;CLEAR OUT THE "CLOSE" ADDRESS

```

.SBTTL LINE CLOCK REGISTER ADDRESSING TEST

:LINE CLOCK REGISTER ADDRESSING TEST

```

800
801 004266 000004      T0021:  SCOPE
802 004270 012737 004354 000004  MOV      #A0021,4      ;SETUP VECTOR IN CASE IT IS NONEXISTANT
803 004276 012737 000340 000006  MOV      #340,6
804 004304 005037 001124      CLR      SGGADR
805 004310 012737 004336 001106  MOV      #R0021,SLPADR ;INITIALIZE THE LOOPBACK ADDRESS IN CASE OF AN ERROR
806 004316 012737 177746 001120  MOV      #177746,SGDADR ;SAME AS "LKS" ADDRESS EXCEPT WITH BIT 7 SET
807 004324 013746 000340      MOV      PR7 -(SP)
808 004330 012746 004336      MOV      #64$,-(SP)    ;PUT NEW PC ON STACK
809 004334 000002              RTI                    ;POP NEW PC AND PS
810 004336                    64$:
811 004336 012706 001000      R0021:  MOV      #1000,SP      ;SETUP THE STACK
812 004342 005037 177546      CLR      LKS
813 004346 012777 000100 174544 I0021:  MOV      #100,JSGDADR      ;SET THE "CLOSE" ADDRESS TO = 100
814 004354 032737 000100 177546 A0021:  BIT      #100,LKS        ;MAKE SURE THAT "LKS" WAS NOT AFFECTED
815 004362 001401              BEQ      B0021
816 004364 104005      E0021:  ERROR 5      ;IT AFFECTED "LKS" -- ERROR
817 004366 005037 177546      B0021:  CLR      LKS
818 004372 012737 004404 000004  MOV      #T0022 ,4
819 004400 005077 174514      CLR      JSGDADR      ;CLEAR OUT THE "CLOSE" ADDRESS

```

.SBTTL LINE CLOCK REGISTER HIGH BYTE TEST

:LINE CLOCK REGISTER HIGH BYTE TEST

:MAKE SURE THE LKS REGISTER LOW BYTE RESPONDS TO THE HIGH BYTES ADDRESS

```

820
821
822
823
824
825
826 004404 000004      T0022:  SCOPE
827 004406 000137 004520      JMP      T0023
828 004412 012737 006252 000004  MOV      #TRAPO,2#4    ;SETUP VECOR IN CASE OF UNFORSEEN PROBLEMS
829 004420 012737 000340 000006  MOV      #340,2#6     ;NO INTERRUPTS WHILE PRINTING FATAL MESSAGE
830 004426 012737 000100 001124  MOV      #100,SGGADR
831 004434 012737 004462 001106  MOV      #R0022,SLPADR ;INITIALIZE THE LOOPBACK ADDRESS IN CASE OF AN ERROR
832 004442 012737 177547 001120  MOV      #177547,SGDADR ;HIGH BYTE OF THE LKS REGISTER
833 004450 013746 000340      MOV      PR7 -(SP)
834 004454 012746 004462      MOV      #64$,-(SP)    ;PUT NEW PC ON STACK
835 004460 000002              RTI                    ;POP NEW PC AND PS
836 004462                    64$:
837 004462 012706 001000      R0022:  MOV      #1000,SP      ;SETUP THE STACK
838 004466 005037 177546      CLR      LKS
839 004472 112777 000100 174420 I0022:  MOVB   #100,JSGDADR      ;SET THE HIGH BYTE ADDRESS TO = 100

```

LINE CLOCK REGISTER HIGH BYTE TEST

```

840 004500 032737 000100 177546 BIT #100,LKS ;MAKE SURE THAT "LKS" LOW BYTE WAS AFFECTED
841 004506 001001 BNE A0022
842 004510 104005 E0022: ERROR 5 ;SHOULD HAVE SET BIT 7. ERROR
843 004512 005037 177546 A0022: CLR LKS
844 004516 000005 RESET
845
846
847
848 .SBTTL CLOCK FLAG BIT TEST
849 :CLOCK FLAG BIT TEST
850 004520 000004 T0023: SCOPE
851 004522 012737 006252 000004 MOV #TRAP0,2#4 ;SETUP VECOR IN CASE OF UNFORSEEN PROBLEMS
852 004530 012737 000340 000006 MOV #340,2#6 ;NO INTERRUPTS WHILE PRINTING FATAL MESSAGE
853 004536 012737 000200 001124 MOV #200,$GDDAT
854 004544 012737 004552 001106 MOV #R0023,$LPADR ;INITIALIZE THE LOOPBACK ADDRESS IN CASE OF AN ERROR
855 004552 005037 177546 R0023: CLR LKS
856 004556 005003 CLR R3 ;INITIALIZE A COUNTER LOCATION
857 004560 105737 177546 A0023: TSTB LKS ;IS THE CLOCK FLAG SET?
858 004564 100404 BMI B0023 ;IF SO, CONTINUE ON WITH THE TEST
859 004566 005203 INC R3 ;IF NOT INCREMENT THE COUNTER LOCATION
860 004570 001373 BNE A0023 ;AND GO TEST THE CLOCK FLAG AGAIN. UNLESS...
861 004572 104001 E0023: ERROR 1 ;CLOCK FLAG DID NOT SET AFTER A WAITING PERIOD > 20 MS
862 004574 000410 BR T0024
863 004576
864 004576 012737 000200 177546 I0023: MOV #200,LKS ;MOVE A 1 INTO THE CLOCK FLAG BIT
865 004604 023737 177546 001124 CMP LKS,$GDDAT ;SHOULD NOT AFFECT THE FLAG BIT
866 004612 001401 BEQ T0024
867 004614 104001 E10023: ERROR 1 ;CLOCK FLAG DID NOT CLEAR
868
869
870
871 .SBTTL INTERRUPT TEST
872 004616 000004 T0024: SCOPE
873 004620 012737 006252 000004 MOV #TRAP0,2#4 ;SETUP VECOR IN CASE OF UNFORSEEN PROBLEMS
874 004626 012737 000340 000006 MOV #340,2#6 ;NO INTERRUPTS WHILE PRINTING FATAL MESSAGE
875 004634 012737 000200 001124 MOV #200,$GDDAT ;HAVE GOOD DATA INFO READY FOR TYPEOUT IN CASE OF AN ERR
876 004642 012737 004662 001106 MOV #R0024,$LPADR ;INITIALIZE THE LOOPBACK ADDRESS IN CASE OF AN ERROR
877 004650 012737 004722 000100 MOV #E0024,100
878 004656 005037 177546 R0024: CLR LKS ;ALLOW CLOCK INTERRUPTS
879 004662
880 004662 013746 000340 MOV PR7,-(SP) ;;PUT NEW PS ON STACK
881 004666 012746 004674 MOV #64$,-(SP) ;;PUT NEW PC ON STACK
882 004672 000002 RTI ;;POP NEW PC AND PS
883 004674
884 004674 012737 000300 177546 64$: MOV #300,LKS
885 004702 005227 000000 A0024: INC #0 ;WAIT FOR 20+ MS
886 004706 001375 BNE A0024 ;LOOP BACK IF NOT DONE WAITING
887 004710 000005 RESET ;RESET SHOULD CLEAR INTERRUPT ENABLE
888 004712 023737 001124 177546 CMP $GDDAT,LKS ;AND LEAVE THE CLOCK FLAG SET
889 004720 001401 BEQ T0025 ;GO ON TO THE NEXT TEST IF IT DID
890 004722 104001 E0024: ERROR 1 ;RESET SET INTERRUPT ENABLE OR CLEARED CLOCK FLAG
891
892
893
894 .SBTTL NO SACK TIMEOUT TEST
895 :NO SACK TIMEOUT TEST

```

```

896 004724 000004 T0025: SCOPE
897 004726 012737 006252 000004 MOV #TRAP0,2#4 ;SETUP VECOR IN CASE OF UNFORSEEN PROBLEMS
898 004734 012737 000340 000006 MOV #340,2#6 ;NO INTERRUPTS WHILE PRINTING FATAL MESSAGE
899 004742 012737 000300 001124 MOV #300,$GDDAT ;HAVE GOOD DATA INFO READY FOR TYPEOUT IN CASE OF AN ERR
900 004750 012737 004772 001106 MOV #R0025,$LPADR ;INITIALIZE THE LOOPBACK ADDRESS IN CASE OF AN ERROR
901 004756 012737 000340 000102 MOV #340,102 ;NO INTERRUPTS AFTER THE FIRST ONE
902 004764 012737 005054 000100 MOV #C0025,100
903 004772 005037 177546 R0025: CLR LKS
904 004776 013746 000340 MOV PR7,-(SP) ;;PUT NEW PS ON STACK
905 005002 012746 005010 MOV #64$,-(SP) ;;PUT NEW PC ON STACK
906 005006 000002 RTI ;;POP NEW PC AND PS
907 005010
908 005010 005003 64$: CLR R3 ;INITIALIZE A COUNTER LOCATION
909 005012 105737 177546 A0025: TSTB LKS ;IS THE CLOCK FLAG SET?
910 005016 100404 BMI B0025 ;IF SO, CONTINUE ON WITH THE TEST
911 005020 005203 INC R3 ;IF NOT INCREMENT THE COUNTER LOCATION
912 005022 001373 BNE A0025 ;AND GO TEST THE CLOCK FLAG AGAIN. UNLESS...
913 005024 104001 E0025: ERROR 1 ;CLOCK FLAG DID NOT SET AFTER A WAITING PERIOD > 20 MS
914 005026 000417 BR T0026
915 005030
916 005030 005046 B0025: CLR -(SP) ;DROP CPU PRIORITY LEVEL
917 005032 012746 005040 MOV #1$,-(SP) ;SET RETURN 'PC' FROM THE RTI
918 005036 000002 RTI ;RETURN TO NEXT INSTRUCTION
919 005040 012737 000100 177546 1$: MOV #100,LKS ;ENABLE CLOCK INTERRUPTS
920 005046 000001 WAIT ;THE ONLY WAY TO LEAVE HERE WITHOUT ERROR IS TO INTERRUPT
921 005050 104006 E10025: ERROR 6 ;IF IT ERROR IS HERE ITS BECAUSE OF A "NO-SACK" TIMEOUT
922 005052 000405 BR T0026
923 005054 022737 000300 177546 C0025: CMP #300,LKS
924 005062 001401 BEQ T0026 ;FIND OUT WHAT THE INTERRUPT DID TO THE CLOCK STATUS REG
925 005064 104001 E20025: ERROR 1 ;IT CLEARED THE INTERRUPT ENABLE OR THE FLAG BIT
926
927
928
929
930 .SBTTL RESET TEST
931 005066 000004 :RESET TEST
932 005070 012737 006252 000004 T0026: SCOPE
933 005076 012737 000340 000006 MOV #TRAP0,2#4 ;SETUP VECOR IN CASE OF UNFORSEEN PROBLEMS
934 005104 012737 000200 001124 MOV #340,2#6 ;NO INTERRUPTS WHILE PRINTING FATAL MESSAGE
935 005112 012737 005146 001106 MOV #200,$GDDAT ;HAVE GOOD DATA INFO READY FOR TYPEOUT IN CASE OF AN ERR
936 005120 013746 000340 MOV #R0025,$LPADR ;INITIALIZE THE LOOPBACK ADDRESS IN CASE OF AN ERROR
937 005124 012746 005132 MOV PR7,-(SP) ;;PUT NEW PS ON STACK
938 005130 000002 MOV #64$,-(SP) ;;PUT NEW PC ON STACK
939 005132 RTI ;;POP NEW PC AND PS
940 005132 012737 005204 000100 64$: MOV #E0026,100
941 005140 012737 000140 000102 MOV #140,102 ;SETUP STATUS FOR AFTER THE INTERRUPT
942 005146 005037 177546 R0026: CLR LKS
943 005152 012706 001000 MOV #1000,SP ;SETUP THE STACK
944 005156 012737 000100 177546 MOV #100,LKS ;SET INTERRUPT ENABLE BIT NOW
945 005164 005227 000000 A0026: INC #0 ;WAIT FOR CLOCK FLAG TO SET
946 005170 001375 BNE A0026
947 005172 000005 I0026: RESET ;RESET SHOULD NOT CLEAR THE FLAG
948 005174 023737 177546 001124 CMP LKS,$GDDAT ;FIND OUT IF ID DIT DID OR NOT
949 005202 001401 BEQ T0027
950 005204 104001 E0026: ERROR 1 ;RESET DID NOT INITIALIZE THE LKS WORD CORRECTLY
951

```

```

952
953
954 .SBTTL CLOCK FLAG BIT TEST
955 ;CLOCK FLAG BIT TEST
956 ;MAKE SURE IT DOESNT CLEAR WHEN YOU TRY TO SET IT VIA A 'MOV' INSTRUCTION
957 005206 000004 T0027: SCOPE
958 005210 012737 006252 000004 MOV #TRAP0,2#4 ;SETUP VECOR IN CASE OF UNFORSEEN PROBLEMS
959 005216 012737 000340 000006 MOV #340,2#6 ;NO INTERRUPTS WHILE PRINTING FATAL MESSAGE
960 005224 012737 000200 001124 MOV #200,$GDDAT ;HAVE GOOD DATA INFO READY FOR TYPEOUT IN CASE OF AN ERR
961 005232 012737 005252 001106 MOV #R0027,$LPADR ;INITIALIZE THE LOOPBACK ADDRESS IN CASE OF AN ERROR
962 005240 005037 000102 CLR 102
963 005244 012737 005334 000100 R0027: MOV #T0030,100
964 005252 005037 177546 CLR LKS
965 005256 013746 000340 MOV PR7,-(SP) ;;PUT NEW PS ON STACK
966 005262 012746 005270 MOV #64$,-(SP) ;;PUT NEW PC ON STACK
967 005266 000002 RTI ;;POP NEW PC AND PS
968 005270 64$:
969 005270 012706 001000 MOV #1000,SP ;SETUP THE STACK
970 005274 005037 001234 CLR WORD ;SETUP A COUNTER LOCATION TO = 0
971 005300 005237 001234 A0027: INC WORD
972 005304 001375 BNE A0027 ;WASTE TIME LOOPING UNTIL THE COUNTER REACHES 0
973 005306 012737 000300 177546 MOV #300,LKS ;SET INTERRUPT ENABLE AND TRY TO SET THE CLOCK FLAG
974 005314 012737 000200 177546 MOV #200,LKS ;TRY TO SET IT AGAIN
975 005322 023737 177546 001124 CMP LKS,$GDDAT ;DID THE CLOCK FLAG STAY SET?
976 005330 001401 BEQ T0030 ;IF NOT GO ON TO THE NEXT TEST
977 005332 104001 E0027: ERROR 1 ;ERROR - MOVED A '1' INTO THE CLOCK FLAG BIT AND IT STAY
978
979
980
981 .SBTTL CLOCK FLAG AFTER INTERRUPT TEST
982 ;SEE IF AN INTERRUPT CLEARS THE CLOCK FLAG
983 005334 000004 T0030: SCOPE
984 005336 012737 006252 000004 MOV #TRAP0,2#4 ;SETUP VECOR IN CASE OF UNFORSEEN PROBLEMS
985 005344 012737 000340 000006 MOV #340,2#6 ;NO INTERRUPTS WHILE PRINTING FATAL MESSAGE
986 005352 005037 177546 CLR LKS ;NO CLOCK INTERRUPTS BEFORE WE ARE READY
987 005356 012737 000100 001124 MOV #100,$GDDAT ;HAVE GOOD DATA INFO READY FOR TYPEOUT IN CASE OF AN ERR
988 005364 012737 005372 001106 MOV #R0030,$LPADR ;INITIALIZE THE LOOPBACK ADDRESS IN CASE OF AN ERROR
989 005372 012737 005440 000100 R0030: MOV #A0030,100 ;SETUP CLOCK INTERRUPT VECTOR
990 005400 005037 000102 CLR 102 ;PRIORITY LEVEL WILL ALLOW FURTHER INTERRUPTS
991 005404 005046 CLR -(SP) ;DROP CPU PRIORITY LEVEL
992 005406 012746 005414 MOV #1$,-(SP) ;SET RETURN 'PC' FROM THE RTI
993 005412 000002 RTI ;RETURN TO NEXT INSTRUCTION
994 005414 012706 001000 1$: MOV #1000,SP ;SETUP THE STACK
995 005420 005037 177546 CLR LKS
996 005424 105037 001234 CLR WORD ;CLEAR OUT A COUNTER LOCATION
997 005430 012737 000100 177546 MOV #100,LKS ;ENABLE CLOCK INTERRUPTS NOW
998 005436 000001 WAIT ;WAIT FOR AN INTERRUPT
999 005440 012737 005472 000100 A0030: MOV #E0030,100 ;ERROR IF WE INTERRUPT AGAIN
1000 005446 005046 CLR -(SP) ;DROP CPU PRIORITY LEVEL
1001 005450 012746 005456 MOV #B0030,-(SP) ;SET RETURN 'PC' FROM THE RTI
1002 005454 000002 RTI ;RETURN TO NEXT INSTRUCTION
1003 005456 105237 001234 B0030: INCB WORD ;DO A NOTHING LOOP FOR A VERY SHORT PERIOD OF TIME
1004 005462 001375 BNE B0030 ;WE SHOULD INCREMENT TO 0 LONG BEFORE AN INTERRUPT COMES
1005 005464 005037 177546 CLR LKS
1006 005470 000401 BR T0031
1007 005472 104001 E0030: ERROR 1 ;INTERRUPT DID NOT CLEAR THE CLOCK FLAG

```



```

1008
1009
1010
1011 .SBTTL NO INTERRUPT AT PRIORITY 7 TEST
1012 :TEST THAT CLOCK WILL NOT INTERRUPT WITH PROCESSR AT PRIORITY 7
1013 005474 000004 T0031: SCOPE
1014 005476 012737 006252 000004 MOV #TRAP0,2#4 ;SETUP VECOR IN CASE OF UNFORSEEN PROBLEMS
1015 005504 012737 000340 000006 MOV #340,2#6 ;NO INTERRUPTS WHILE PRINTING FATAL MESSAGE
1016 005512 012737 005520 001106 MOV #R0031,$LPADR ;SETUP LOOPBACK ADDRESS IN CASE OF AN ERROR
1017 005520 005037 177546 R0031: CLR LKS
1018 005524 005003 CLR R3 ;INITIALIZE A COUNTER LOCATION
1019 005526 105737 177546 A0031: TSTB LKS ;IS THE CLOCK FLAG SET?
1020 005532 100404 BMI B0031 ;IF SO, CONTINUE ON WITH THE TEST
1021 005534 005203 INC R3 ;IF NOT INCREMENT THE COUNTER LOCATION
1022 005536 001373 BNE A0031 ;AND GO TEST THE CLOCK FLAG AGAIN. UNLESS...
1023 005540 104001 E0031: ERROR 1 ;CLOCK FLAG DID NOT SET F..TER A WAITING PERIOD > 20 MS
1024 005542 000431 BR T0032
1025 005544
1026 005544 012706 001000 B0031: MOV #1000,SP ;INITIALIZE THE STACK POINTER
1027 005550 013746 000340 MOV PR7,-(SP) ;PUT NEW PS ON STACK
1028 005554 012746 005562 MOV #64$,-(SP) ;PUT NEW PC ON STACK
1029 005560 000002 RTI ;POP NEW PC AND PS
1030 005562
1031 005562 012737 005540 000100 64$: MOV #E0031,100 ;SET UP VECTOR RETURN
1032 005570 012737 000100 177546 MOV #100,LKS ;ENABLE INTERRUPT
1033 005576 005003 CLR R3 ;INITIALIZE A COUNTER LOCATION
1034 005600 105737 177546 C0031: TSTB LKS ;IS THE CLOCK FLAG SET?
1035 005604 100404 BMI D0031 ;IF SO, CONTINUE ON WITH THE TEST
1036 005606 005203 INC R3 ;IF NOT INCREMENT THE COUNTER LOCATION
1037 005610 001373 BNE C0031 ;AND GO TEST THE CLOCK FLAG AGAIN. UNLESS...
1038 005612 104001 E10031: ERROR 1 ;CLOCK FLAG DID NOT SET AFTER A WAITING PERIOD > 20 MS
1039 005614 000404 BR T0032
1040 005616
1041 005616 000240 D0031: NOP
1042 005620 000240 NOP ;GIVE CLOCK EXTRA TIME TO INTERRUPT
1043 005622 000401 BR T0032
1044 005624 104003 E20031: ERROR 3 ;ERROR, CLOCK INTERRUPTED WITHOUT HAVING PRIORITY
1045
1046
1047
1048 .SBTTL CC PUSH TEST FOR CLOCK INTERRUPTS
1049 :TEST THAT CLOCK INTERRUPT PUSHES CONDITION CODES ONTO STACK
1050 005626 000004 T0032: SCOPE
1051 005630 012737 006252 000004 MOV #TRAP0,2#4 ;SETUP VECOR IN CASE OF UNFORSEEN PROBLEMS
1052 005636 012737 000340 000006 MOV #340,2#6 ;NO INTERRUPTS WHILE PRINTING FATAL MESSAGE
1053 005644 012737 005652 001106 MOV #R0032,$LPADR ;SETUP LOOPBACK ADDRESS IN CASE OF AN ERROR
1054 005652 005037 177546 R0032: CLR LKS
1055 005656 005003 CLR R3 ;INITIALIZE A COUNTER LOCATION
1056 005660 105737 177546 A0032: TSTB LKS ;IS THE CLOCK FLAG SET?
1057 005664 100404 BMI B0032 ;IF SO, CONTINUE ON WITH THE TEST
1058 005666 005203 INC R3 ;IF NOT INCREMENT THE COUNTER LOCATION
1059 005670 001373 BNE A0032 ;AND GO TEST THE CLOCK FLAG AGAIN. UNLESS...
1060 005672 104001 E0032: ERROR 1 ;CLOCK FLAG DID NOT SET AFTER A WAITING PERIOD > 20 MS
1061 005674 000433 BR T0033
1062 005676
1063 005676 012706 001000 B0032: MOV #1000,SP ;INITIALIZE THE STACK POINTER

```

DZKWA.F.P11 09-NOV-77 00:00

CC PUSH TEST FOR CLOCK INTERRUPTS

```

1064 005702 005037 000776 CLR BUF1
1065 005706 005037 000774 CLR BUF2
1066 005712 012737 005742 000100 MOV #C0032,100 ;SET UP VECTOR RETURN
1067 005720 012737 000100 177546 MOV #100,LKS ;ENABLE INTERRUPT
1068 005726 005046 CLR -(SP) ;DROP CPU PRIORITY LEVEL
1069 005730 012746 005736 MOV #1$,-(SP) ;SET RETURN 'PC' FROM THE RTI
1070 005734 000002 RTI ;RETURN TO NEXT INSTRUCTION
1071 005736 000277 1$: +SEC!SEV!SEZ!SEN ;SET ALL CONDITION CODES
1072 005740 000001 WAIT ;WAIT FOR INTERRUPT
1073 005742 022737 000017 000776 C0032: CMP #17,BUF1
1074 005750 001405 BEQ T0033
1075 005752 012737 000017 001124 MOV #17,$GDDAT ;ERROR DID NOT PUSH CORRECT PS ONTO STACK
1076 005760 104007 ERROR 7
1077 005762 000721 BR T0032

1080
1081 .SBTTL PC PUSH TEST FOR CLOCK INTERRUPTS
1082 ;TEST THAT CLOCK INTERRUPT PUSHES THE PROGRAM COUNTER ONTO STACK
1083 005764 000004 T0033: SCOPE
1084 005766 012737 006252 000004 MOV #TRAP0,2#4 ;SETUP VECOR IN CASE OF UNFORSEEN PROBLEMS
1085 005774 012737 000340 000006 MOV #340,2#6 ;NO INTERRUPTS WHILE PRINTING FATAL MESSAGE
1086 006002 012737 006010 001106 MOV #R0033,$LPADR ;SETUP LOOPBACK ADDRESS IN CASE OF AN ERROR
1087 006010 005037 177546 R0033: CLR LKS
1088 006014 005003 CLR R3 ;INITIALIZE A COUNTER LOCATION
1089 006016 105737 177546 A0033: TSTB LKS ;IS THE CLOCK FLAG SET?
1090 006022 100404 BMI B0033 ;IF SO, CONTINUE ON WITH THE TEST
1091 006024 005203 INC R3 ;IF NOT INCREMENT THE COUNTER LOCATION
1092 006026 001373 BNE A0033 ;AND GO TEST THE CLOCK FLAG AGAIN, UNLESS...
1093 006030 104001 E0033: ERROR 1 ;CLOCK FLAG DID NOT SET AFTER A WAITING PERIOD > 20 MS
1094 006032 000432 BR T0034
1095 006034 B0033:
1096 006034 012706 001000 MOV #1000,SP ;INITIALIZE THE STACK POINTER
1097 006040 005037 000776 CLR BUF1
1098 006044 005037 000774 CLR BUF2
1099 006050 012737 006100 000100 MOV #C0033,100 ;SET UP VECTOR RETURN
1100 006056 012737 000100 177546 MOV #100,LKS ;ENABLE INTERRUPT
1101 006064 005046 CLR -(SP) ;DROP CPU PRIORITY LEVEL
1102 006066 012746 006074 MOV #1$,-(SP) ;SET RETURN 'PC' FROM THE RTI
1103 006072 000002 RTI ;RETURN TO NEXT INSTRUCTION
1104 006074 000277 1$: +SEC!SEV!SEZ!SEN ;SET ALL CONDITION CODES
1105 006076 000001 WAIT ;WAIT FOR INTERRUPT
1106 006100 022737 006100 000774 C0033: CMP #C0033,BUF2
1107 006106 001404 BEQ T0034
1108 006110 012737 006100 001124 E10033: MOV #C0033,$GDDAT ;ERROR, DID NOT PUSH CORRECT PC ONTO STACK
1109 006116 104010 ERROR 10
1110
1111
1112
1113 .SBTTL END OF PASS INDICATING
1114 006120 000004 T0034: SCOPE
1115 006122 005037 177546 CLR LKS ;TURN THE CLOCK OFF
1116 006126 000005 RESET ;TURN EVERYTHING OFF
1117
1118 ;*****
1119

```

END OF PASS ROUTINE

.SBTTL END OF PASS ROUTINE

;; INCREMENT THE PASS NUMBER (\$PASS)
;; TYPE "END PASS #XXXXX" (WHERE XXXXX IS A DECIMAL NUMBER)
;; IF THERES A MONITOR GO TO IT
;; IF THERE ISN'T JUMP TO T0001

1120
1121
1122
1123
1124
1125
1126
1127 006130
1128 006130 000004
1129 006132 005037 001102
1130 006136 005037 001220
1131 006142 005237 001100
1132 006146 042737 100000 001100
1133 006154 005327
1134 006156 000001
1135 006160 003022
1136 006162 012737
1137 006164 000001
1138 006166 006156
1139 006170 104400 006232
1140 006174 013746 001100
1141 006200 104404
1142 006202 104400 006247
1143 006206
1144
1145 006206 013700 000042
1146 006212 001405
1147 006214 000005
1148 006216 004710
1149 006220 000240
1150 006222 000240
1151 006224 000240
1152 006226
1153 006226 000137 001672
1154 006232 005015 047105 020104
1155 006240 040520 051523 021440
1156 006246 000
1157 006247 377 377 000
1158 006252 005046
1159 006254 004737 006576
1160 006260 010363
1161 006262 011646
1162 006264 162716 000002
1163 006270 104401
1164 006272 104400 001231
1165 006276 005046
1166 006300 004737 006576
1167 006304 010424
1168 006306 000240
1169 006310 000240
1170 006312 000240
1171 006314 000240
1172 006316 000005
1173 006320 000137 001450
1174
1175

SEOP: SCOPE
CLR \$STSTM ;; ZERO THE TEST NUMBER
CLR \$TIMES ;; ZERO THE NUMBER OF ITERATIONS
INC \$PASS ;; INCREMENT THE PASS NUMBER
BIC #100000,\$PASS ;; DON'T ALLOW A NEG. NUMBER
DEC (PC)+ ;; LOOP?
SEOPCT: .WORD 1
BGT \$DOAGN ;; YES
MOV (PC)+,\$(PC)+ ;; RESTORE COUNTER
SENDCT: .WORD 1
SEOPCT
TYPE \$SENDMG ;; TYPE "END PASS #"
MOV \$PASS,-(SP) ;; SAVE \$PASS FOR TYPEOUT
TYPDS
TYPE ,SENULL ;; GO TYPE--DECIMAL ASCII WITH SIGN
;; TYPE A NULL CHARACTER
SGET42:
MOV \$42,R0 ;; GET MONITOR ADDRESS
BEQ \$DOAGN ;; BRANCH IF NO MONITOR
RESET
SENDAD: JSR PC,(R0) ;; CLEAR THE WORLD
;; GO TO MONITOR
NOP
NOP
NOP
NOP
NOP
SDOAGN:
JMP \$T0001 ;; RETURN
SENDMG: .ASCIZ <15><12>/END PASS #/
SENULL: .BYTE -1,-1,0 ;; NULL CHARACTER STRING
TRAPD: CLR -(SP)
JSR PC,\$TYPE ;; PRINTOUT "TRAPPED TO 4 FROM "
TRPM2S
MOV (SP),-(SP) ;; ADDRESS OF THE MESSAGE
SLE #2,(SP) ;; GET THE ADDRESS WHERE THE TRAP OCCURED
TYPDC
TYPE ,\$CRLF ;; MAKE IT RIGHT
CLR -(SP) ;; TYPE OUT ADDRESS IN OCTAL
JSR PC,\$TYPE ;; PRINTOUT A CARRIAGE RETURN-LINE FEED
TRPM2S
NOP
NOP
NOP
NOP
RESET
JMP START

SCOPE HANDLER ROUTINE

.SBTTL SCOPE HANDLER ROUTINE

1176
1177
1178
1179
1180
1181
1182
1183
1184
1185
1186
1187
1188
1189
1190
1191
1192
1193
1194
1195
1196
1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231

006324
006324 000240
006324 032777 040000 172602
006334 001111
006336 000416
006340 013746 000004
006344 012737 006364 000004
006352 005737 177060
006356 012637 000004
006362 000463
006364 022626
006366 012637 000004
006372 000423
006374
006374 032777 000400 172534
006402 001404
006404 127737 172526 001102
006412 001464
006414 105737 001103
006420 001421
006422 123737 001115 001103
006430 101015
006432 032777 001000 172476
006440 001404
006442 013737 001110 001106
006450 000443
006452 105037 001103
006456 005037 001220
006462 000415
006464 032777 004000 172444
006472 001011
006474 005737 001100
006500 001406
006502 005237 001104
006506 023737 001220 001104
006514 002021
006516 012737 000001 001104
006524 013737 006574 001220
006532 105237 001102
006536 011637 001106
006542 011637 001110

```

; *THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
; *AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
; *AND LOAD THE ERROR FLAG (SERFLG) INTO DISPLAY<15:08>
; *THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
; *SW14=1      LOOP ON TEST
; *SW11=1      INHIBIT ITERATIONS
; *SW09=1      LOOP ON ERROR
; *SW08=1      LOOP ON TEST IN SWR<7:0>
; *CALL
; *          SCOPE          ;;SCOPE=IOT

$SCOPE:
1$:      NOP
          BIT          $BIT14,$SWR          ;;LOOP ON PRESENT TEST?
          BNE          $OVER                ;;YES IF SW14=1
; *****START OF CODE FOR THE XOR TESTER*****
$XTSTR:  BR          6$
          MOV          $ERRVEC,-($SP)       ;;IF RUNNING ON THE "XOR" TESTER CHANGE
          MOV          $5,$ERRVEC          ;;THIS INSTRUCTION TO A "NOP" (NOP=240)
          TST          $177060             ;;SAVE THE CONTENTS OF THE ERROR VECTOR
          MOV          ($SP)+,$ERRVEC      ;;SET FOR TIMEOUT
          BR           $SVLAD              ;;TIME OUT ON XOR?
          CMP          ($SP)+,($SP)+       ;;RESTORE THE ERROR VECTOR
          MOV          ($SP)+,$ERRVEC      ;;GO TO THE NEXT TEST
          BR           7$                  ;;CLEAR THE STACK AFTER A TIME OUT
          BR           7$                  ;;RESTORE THE ERROR VECTOR
          BR           7$                  ;;LOOP ON THE PRESENT TEST
6$:; *****END OF CODE FOR THE XOR TESTER*****
          BIT          $BIT08,$SWR          ;;LOOP ON SPEC. TEST?
          BEQ          2$                  ;;BR IF NO
          CMPB        $SWR,$TSTNM         ;;ON THE RIGHT TEST? SWR<7:0>
          BEQ          $OVER              ;;BR IF YES
          TSTB        $SERFLG             ;;HAS AN ERROR OCCURRED?
          BEQ          3$                  ;;BR IF NO
          CMPB        $SERMAX,$SERFLG     ;;MAX. ERRORS FOR THIS TEST OCCURRED?
          BHI          3$                  ;;BR IF NO
          BIT          $BIT09,$SWR          ;;LOOP ON ERROR?
          BEQ          4$                  ;;BR IF NO
          MOV          $LPERR,$LPADR       ;;SET LOOP ADDRESS TO LAST SCOPE
          BR           $OVER
          CLR          $SERFLG             ;;ZERO THE ERROR FLAG
          CLR          $TIMES              ;;CLEAR THE NUMBER OF ITERATIONS TO MAKE
          BR           1$                  ;;ESCAPE TO THE NEXT TEST
          BIT          $BIT11,$SWR          ;;INHIBIT ITERATIONS?
          BNE          1$                  ;;BR IF YES
          TST          $PASS               ;;IF FIRST PASS OF PROGRAM
          BEQ          1$                  ;;INHIBIT ITERATIONS
          INC          $ICNT               ;;INCREMENT ITERATION COUNT
          CMP          $TIMES,$ICNT        ;;CHECK THE NUMBER OF ITERATIONS MADE
          BGE          $OVER              ;;BR IF MORE ITERATION REQUIRED
          MOV          $1,$ICNT            ;;REINITIALIZE THE ITERATION COUNTER
          MOV          $MXCNT,$TIMES      ;;SET NUMBER OF ITERATIONS TO DO
          INCB        $TSTNM              ;;COUNT TEST NUMBERS
          MOV          ($SP),$LPADR        ;;SAVE SCOPE LOOP ADDRESS
          MOV          ($SP),$LPERR        ;;SAVE ERROR LOOP ADDRESS

```

SCOPE HANDLER ROUTINE

```

1232 006546 005037 001222          CLR          $ESCAPE          ;; CLEAR THE ESCAPE FROM ERROR ADDRESS
1233 006552 112737 000001 001115  MOV          #1,$ERMAX        ;; ONLY ALLOW ONE(1) ERROR ON NEXT TEST
1234 006560 013777 001102 172352 $OVER:  MOV          $STNM,$DISPLAY  ;; DISPLAY TEST NUMBER
1235 006566 013716 001106          MOV          $LPADR,(SP)      ;; FUDGE RETURN ADDRESS
1236 006572 000002          RTI          ;; FIXES PS
1237 006574 000010 $MXCNT: 10          ;; MAX. NUMBER OF ITERATIONS
1238 ;*****
1239
1240 .SBTTL  TYPE ROUTINE
1241
1242 ;*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
1243 ;*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
1244 ;*NOTE1:          $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
1245 ;*NOTE2:          $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
1246 ;*NOTE3:          $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
1247 ;*
1248 ;*CALL:
1249 ;*1) USING A TRAP INSTRUCTION
1250 ;*      TYPE      ,MESADR          ;; MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
1251 ;*OR
1252 ;*      TYPE
1253 ;*      MESADR
1254 ;*
1255
1256 006576 105737 001155 $TYPE:  TST          $TPFLG          ;; IS THERE A TERMINAL?
1257 006602 100002          BPL          1$                    ;; BR IF YES
1258 006604 000000          HALT          ;; HALT HERE IF NO TERMINAL
1259 006606 000407          BR          3$                    ;; LEAVE
1260 006610 010046          1$:  MOV          RO,-(SP)          ;; SAVE RO
1261 006612 017600 000002          MOV          @2(SP),RO          ;; GET ADDRESS OF ASCIZ STRING
1262 006616 112046          2$:  MOV          (RO)+,-(SP)      ;; PUSH CHARACTER TO BE TYPED ONTO STACK
1263 006620 001005          BNE          4$                    ;; BR IF IT ISN'T THE TERMINATOR
1264 006622 005726          TST          (SP)+              ;; IF TERMINATOR POP IT OFF THE STACK
1265 006624 012600          60$: MOV          (SP)+,RO          ;; RESTORE RO
1266 006626 062716 000002          3$:  ADD          #2,(SP)          ;; ADJUST RETURN PC
1267 006632 000002          RTI          ;; RETURN
1268 006634 122716 000011          4$:  CMP          #THT,(SP)        ;; BRANCH IF <HT>
1269 006640 001426          BEQ          8$                    ;; BRANCH IF NOT <CRLF>
1270 006642 122716 000200          CMP          #TCRLF,(SP)
1271 006646 001004          BNE          5$                    ;; POP <CR><LF> EQUIV
1272 006650 005726          TST          (SP)+              ;; TYPE A CR AND LF
1273 006652 104400          TYPE
1274 006654 001231          SCRLF
1275 006656 000757          BR          2$                    ;; GET NEXT CHARACTER
1276 006660 004737 006742          5$:  JSR          PC,$TYPEC          ;; GO TYPE THIS CHARACTER
1277 006664 123726 001154          6$:  CMP          $FILLC,(SP)+      ;; IS IT TIME FOR FILLER CHARS.?
1278 006670 001352          BNE          2$                    ;; IF NO GO GET NEXT CHAR.
1279 006672 013746 001152          MOV          $NULL,-(SP)        ;; GET # OF FILLER CHARS. NEEDED
1280 ;*AND THE NULL CHAR.
1281 006676 105366 000001          7$:  DECB          1(SP)            ;; DOES A NULL NEED TO BE TYPED?
1282 006702 002770          BLT          6$                    ;; BR IF NO--GO POP THE NULL OFF OF STACK
1283 006704 004737 006742          JSR          PC,$TYPEC          ;; GO TYPE A NULL
1284 006710 105337 007006          DECB          $CHARCNT          ;; DO NOT COUNT AS A COUNT
1285 006714 000770          BR          7$                    ;; LOOP
1286
1287 ;HORIZONTAL TAB PROCESSOR

```

```

1288
1289 006716 112716 000040 8$: MOVB #40,(SP) ;;REPLACE TAB WITH SPACE
1290 006722 004737 006742 9$: JSR PC,$TYPEC ;;TYPE A SPACE
1291 006726 132737 000007 007006 BITB #7,$CHARCNT ;;BRANCH IF NOT AT
1292 006734 001372 BNE 9$ ;;TAB STOP
1293 006736 005726 TST (SP)+ ;;POP SPACE OFF STACK
1294 006740 000726 BR 2$ ;;GET NEXT CHARACTER
1295 006742 105777 172200 $TYPEC: TSTB @STPS ;;WAIT UNTIL PRINTER IS READY
1296 006746 100375 BPL $TYPEC
1297 006750 116677 000002 172172 MOVB 2(SP),@STPB ;;LOAD CHAR TO BE TYPED INTO DATA REG.
1298 006756 122766 000015 000002 CMPB #15,2(SP) ;;BRANCH IF
1299 006764 001003 BNE 1$ ;;NOT <CR>
1300 006766 105037 007006 CLRB $CHARCNT
1301 006772 000406 BR $TYPEX ;;EXIT
1302 006774 122766 000012 000002 1$: CMPB #12,2(SP) ;;BRANCH IF
1303 007002 002002 BGE $TYPEX ;;<LF>
1304 007004 105227 INCB (PC)+ ;;INC SPACE
1305 007006 000000 $CHARCNT: WORD 0 ;;COUNT
1306 007010 000207 $TYPEX: RTS PC
1307 ;; EQUATES
1308 000011 THT=11
1309 000200 TCRLF=200
1310
1311 ;*****
1312
1313 .SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
1314
1315 ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
1316 ;*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
1317 ;*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
1318 ;*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
1319 ;*REPLACED WITH SPACES.
1320 ;*CALL:
1321 ;* MOV NUM,-(SP) ;;PUT THE BINARY NUMBER ON THE STACK
1322 ;* TYPDS ;;GO TO THE ROUTINE
1323
1324 $TYPDS:
1325 007012 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
1326 007014 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
1327 007016 010246 MOV R2,-(SP) ;;PUSH R2 ON STACK
1328 007020 010346 MOV R3,-(SP) ;;PUSH R3 ON STACK
1329 007022 010546 MOV R5,-(SP) ;;PUSH R5 ON STACK
1330 007024 012746 020200 MOV #20200,-(SP) ;;SET BLANK SWITCH AND SIGN
1331 007030 016605 000020 MOV 20(SP),R5 ;;GET THE INPUT NUMBER
1332 007034 100004 BPL 1$ ;;BR IF INPUT IS POS.
1333 007036 005405 NEG R5 ;;MAKE THE BINARY NUMBER POS.
1334 007040 112766 000055 000001 1$: MOVB #'-',1(SP) ;;MAKE THE ASCII NUMBER NEG.
1335 007046 005000 CLR R0 ;;ZERO THE CONSTANTS INDEX
1336 007050 012703 007226 MOV #SDBLK,R3 ;;SETUP THE OUTPUT POINTER
1337 007054 112723 000040 MOVB #'',(R3)+ ;;SET THE FIRST CHARACTER TO A BLANK
1338 007060 005002 2$: CLR R2 ;;CLEAR THE BCD NUMBER
1339 007062 016001 007216 3$: MOV $DTBL(R0),R1 ;;GET THE CONSTANT
1340 007066 160105 SUB R1,R5 ;;FORM THIS BCD DIGIT
1341 007070 002402 BLT 4$ ;;BR IF DONE
1342 007072 005202 INC R2 ;;INCREASE THE BCD DIGIT BY 1
1343 007074 000774 BR 3$

```

E03

MAINDEC-11-DZKWA-F LINE FREQUENCY CLOCK PROGRAM
DZKWA.F.P11 09-NOV-77 00:00

MACY11 30(1046) 07-DEC-77 12:50 PAGE 27
CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

SEQ 0030

```

1344 007076 060105          4S:  ADD    R1,R5          ;; ADD BACK THE CONSTANT
1345 007100 005702          TST    R2              ;; CHECK IF BCD DIGIT=0
1346 007102 001002          BNE    5S              ;; FALL THROUGH IF 0
1347 007104 105716          TSTB   (SP)            ;; STILL DOING LEADING 0'S?
1348 007106 100407          BMI    7S              ;; BR IF YES
1349 007110 106316          5S:  ASLB   (SP)            ;; MSD?
1350 007112 103003          BCC    6S              ;; BR IF NO
1351 007114 116663 000001 177777  MOVB   1(SP),-1(R3)    ;; YES--SET THE SIGN
1352 007122 052702 000060 6S:  BIS    #'0,R2          ;; MAKE THE BCD DIGIT ASCII
1353 007126 052702 000040 7S:  BIS    #' R2           ;; MAKE IT A SPACE IF NOT ALREADY A DIGIT
1354 007132 110223          MOVB   R2,(R3)+        ;; PUT THIS CHARACTER IN THE OUTPUT BUFFER
1355 007134 005720          TST    (R0)+           ;; JUST INCREMENTING
1356 007136 020027 000010  CMP    R0,#10          ;; CHECK THE TABLE INDEX
1357 007142 002746          BLT    2S              ;; GO DO THE NEXT DIGIT
1358 007144 003002          BGT    8S              ;; GO TO EXIT
1359 007146 010502          MOV    R5,R2           ;; GET THE LSD
1360 007150 000764          BR     6S              ;; GO CHANGE TO ASCII
1361 007152 105726          8S:  TSTB   (SP)+         ;; WAS THE LSD THE FIRST NON-ZERO?
1362 007154 100003          BPL    9S              ;; BR IF NO
1363 007156 116663 177777 177776  MOVB   -1(SP),-2(R3)  ;; YES--SET THE SIGN FOR TYPING
1364 007164 105013          9S:  CLRB   (R3)           ;; SET THE TERMINATOR
1365 007166 012605          MOV    (SP)+,R5        ;; POP STACK INTO R5
1366 007170 012603          MOV    (SP)+,R3        ;; POP STACK INTO R3
1367 007172 012602          MOV    (SP)+,R2        ;; POP STACK INTO R2
1368 007174 012601          MOV    (SP)+,R1        ;; POP STACK INTO R1
1369 007176 012600          MOV    (SP)+,R0        ;; POP STACK INTO R0
1370 007200 104400 007226 000002 000004  TYPE   $DBLK          ;; NOW TYPE THE NUMBER
1371 007204 016666          MOV    2(SP),4(SP)     ;; ADJUST THE STACK
1372 007212 012616          MOV    (SP)+,(SP)
1373 007214 000002          RTI                    ;; RETURN TO USER
1374 007216 023420          SDTBL: 10000.
1375 007220 001750          1000.
1376 007222 000144          100.
1377 007224 000012          10.
1378 007226 000004          $DBLK: .BLKW 4
1379 *****
1380
1381 .SBTTL BINARY TO OCTAL (ASCII) AND TYPE
1382
1383 ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
1384 ;*OCTAL (ASCII) NUMBER AND TYPE IT.
1385 ;*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
1386 ;*CALL:
1387 ;*      MOV    NUM,-(SP)          ;; NUMBER TO BE TYPED
1388 ;*      TYPOS          ;; CALL FOR TYPEOUT
1389 ;*      .BYTE  N          ;; N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
1390 ;*      .BYTE  M          ;; M=1 OR 0
1391 ;*
1392 ;*
1393 ;*
1394 ;*$TYPON----ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
1395 ;*$TYPOS OR $TYPOC
1396 ;*CALL:
1397 ;*      MOV    NUM,-(SP)          ;; NUMBER TO BE TYPED
1398 ;*      TYPON          ;; CALL FOR TYPEOUT
1399 ;*

```

F03

MAINDEC-11-DZKWA-F LINE FREQUENCY CLOCK PROGRAM
DZKWA.F11 09-NOV-77 00:00

MACY11 30(1046) 07-DEC-77 12:50 PAGE 28
BINARY TO OCTAL (ASCII) AND TYPE

SEQ 0031

```

1400      ;*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
1401      ;*$CALL:
1402      ;*$      MOV      NUM,-(SP)      ;:NUMBER TO BE TYPED
1403      ;*$      TYPOC      ;:CALL FOR TYPEOUT
1404
1405      007236 017646 000000      007461  $TYPOS: MOV      2(SP),-(SP)      ;: PICKUP THE MODE
1406      007242 116637 000001      MOVVB   1(SP),%OFILL      ;: LOAD ZERO FILL SWITCH
1407      007250 112637 007463      MOVVB   (SP)+,%SOMODE+1 ;: NUMBER OF DIGITS TO TYPE
1408      007254 062716 000002      ADD     #2,(SP)      ;: ADJUST RETURN ADDRESS
1409      007260 000406      BR      $TYPON
1410      007262 112737 000001      007461  $TYPOC: MOVVB   #1,%OFILL      ;: SET THE ZERO FILL SWITCH
1411      007270 112737 000006      007463  MOVVB   #6,%SOMODE+1 ;: SET FOR SIX(6) DIGITS
1412      007276 112737 000005      007460  $TYPON: MOVVB   #5,%SOCNT ;: SET THE ITERATION COUNT
1413      007304 010346      MOV     R3,-(SP)      ;: SAVE R3
1414      007306 010446      MOV     R4,-(SP)      ;: SAVE R4
1415      007310 010546      MOV     R5,-(SP)      ;: SAVE R5
1416      007312 113704 007463      MOVVB   %SOMODE+1,R4 ;: GET THE NUMBER OF DIGITS TO TYPE
1417      007316 005404      NEG     R4
1418      007320 062704 000006      ADD     #6,R4      ;: SUBTRACT IT FOR MAX. ALLOWED
1419      007324 110437 007462      MOVVB   R4,%SOMODE ;: SAVE IT FOR USE
1420      007330 113704 007461      MOVVB   %OFILL,R4 ;: GET THE ZERO FILL SWITCH
1421      007334 016605 000012      MOV     12(SP),R5 ;: PICKUP THE INPUT NUMBER
1422      007340 005003      CLR     R3      ;: CLEAR THE OUTPUT WORD
1423      007342 006105      1$:    ROL     R5      ;: ROTATE MSB INTO "C"
1424      007344 000404      BR      3$      ;: GO DO MSB
1425      007346 006105      2$:    ROL     R5      ;: FORM THIS DIGIT
1426      007350 006105      ROL     R5
1427      007352 006105      ROL     R5
1428      007354 010503      MOV     R5,R3
1429      007356 006103      3$:    ROL     R3      ;: GET LSB OF THIS DIGIT
1430      007360 105337 007462      DECB   %SOMODE ;: TYPE THIS DIGIT?
1431      007364 100016      BPL    7$      ;: BR IF NO
1432      007366 042703 177770      BIC    #177770,R3 ;: GET RID OF JUNK
1433      007372 001002      BNE    4$      ;: TEST FOR 0
1434      007374 005704      TST    R4      ;: SUPPRESS THIS 0?
1435      007376 001403      BEQ    5$      ;: BR IF YES
1436      007400 005204      4$:    INC     R4      ;: DON'T SUPPRESS ANYMORE 0'S
1437      007402 052703 000060      BIS    #'0,R3 ;: MAKE THIS DIGIT ASCII
1438      007406 052703 000040      5$:    BIS    #' ,R3 ;: MAKE ASCII IF NOT ALREADY
1439      007412 110337 007456      MOVVB   R3,%S ;: SAVE FOR TYPING
1440      007416 104400 007456      TYPE   #S ;: GO TYPE THIS DIGIT
1441      007422 105337 007460      7$:    DECB   %SOCNT ;: COUNT BY 1
1442      007426 003347      BGT    2$      ;: BR IF MORE TO DO
1443      007430 002402      BLT    6$      ;: BR IF DONE
1444      007432 005204      INC     R4      ;: INSURE LAST DIGIT ISN'T A BLANK
1445      007434 000744      BR      2$      ;: GO DO THE LAST DIGIT
1446      007436 012605      6$:    MOV     (SP)+,R5 ;: RESTORE R5
1447      007440 012604      MOV     (SP)+,R4 ;: RESTORE R4
1448      007442 012603      MOV     (SP)+,R3 ;: RESTORE R3
1449      007444 016666 000002 000004      MOV     2(SP),4(SP) ;: SET THE STACK FOR RETURNING
1450      007452 012616      MOV     (SP)+,(SP)
1451      007454 000002      RTI
1452      007456 000      8$:    .BYTE 0 ;: STORAGE FOR ASCII DIGIT
1453      007457 000      .BYTE 0 ;: TERMINATOR FOR TYPE ROUTINE
1454      007460 000      $SOCNT: .BYTE 0 ;: OCTAL DIGIT COUNTER
1455      007461 000      $OFILL: .BYTE 0 ;: ZERO FILL SWITCH

```



```

1456 007462 000000
1457
1458
1459
1460
1461
1462
1463
1464
1465 007464
1466 007464 104400 001231
1467 007470 010046
1468 007472 005000
1469 007474 153700 001114
1470 007500 001004
1471
1472 007502 013746 001116
1473
1474 007506 104401
1475 007510 000426
1476 007512 005300
1477 007514 006300
1478 007516 006300
1479 007520 006300
1480 007522 062700 001236
1481 007526 012037 007536
1482 007532 001404
1483 007534 104400
1484 007536 000000
1485 007540 104400 001231
1486 007544 012037 007554
1487 007550 001404
1488 007552 104400
1489 007554 000000
1490 007556 104400 001231
1491 007562 011000
1492 007564 001004
1493 007566 012600
1494 007570 104400 001231
1495 007574 000207
1496 007576
1497 007576 013046
1498 007600 104401
1499 007602 005710
1500 007604 001770
1501 007606 104400 007614
1502 007612 000771
1503 007614 020040 000
1504 007620
1505
1506
1507
1508
1509
1510
1511
    
```

```

$OMODE: .WORD 0 ;:NUMBER OF DIGITS TO TYPE
;*****
.SBTTL ERROR MESSAGE TIMEOUT ROUTINE
;:THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE WHICH
;:ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" ($ERRTB),
;:AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.

$ERRTYP:
    TYPE      $SCLF      ;:"CARRIAGE RETURN" & "LINE FEED"
    MOV       RO,-(SP)   ;:SAVE RO
    CLR       RO        ;:PICKUP THE ITEM INDEX
    BISB     @($ITEMB,RO
    BNE      1$        ;:IF ITEM NUMBER IS ZERO, JUST
                        ;:TYPE THE PC OF THE ERR...
    MOV       $ERRPC,-(SP) ;:SAVE $ERRPC FOR TIMEOUT
                        ;:ERROR ADDRESS
    TYPOC    6$        ;:GO TYPE--OCTAL ASCII(ALL DIGITS)
    BR       6$        ;:GET OUT
    1$:      DEC        ;:ADJUST THE INDEX SO THAT IT WILL
    ASL      RO        ;:WORK FOR THE ERROR TABLE
    ASL      RO
    ASL      RO
    ADD      @($ERRTB,RO ;:FORM TABLE POINTER
    MOV      (RO)+,2$   ;:PICKUP "ERROR MESSAGE" POINTER
    BEQ     3$        ;:SKIP TIMEOUT IF NO POINTER
    TYPE    0          ;:TYPE THE "ERROR MESSAGE"
    .WORD   0          ;:"ERROR MESSAGE" POINTER GOES HERE
    2$:      TYPE      $SCLF ;:"CARRIAGE RETURN" & "LINE FEED"
    MOV     (RO)+,4$   ;:PICKUP "DATA HEADER" POINTER
    BEQ    5$        ;:SKIP TIMEOUT IF 0
    TYPE   0          ;:TYPE THE "DATA HEADER"
    .WORD  0          ;:"DATA HEADER" POINTER GOES HERE
    3$:      TYPE      $SCLF ;:"CARRIAGE RETURN" & "LINE FEED"
    MOV     (RO),RO   ;:PICKUP "DATA TABLE" POINTER
    BNE    7$        ;:GO TYPE THE DATA
    MOV     (SP)+,RO  ;:RESTORE RO
    TYPE   $SCLF     ;:"CARRIAGE RETURN" & "LINE FEED"
    RTS    PC        ;:RETURN
    4$:      .WORD     0
    5$:      MOV       (RO),RO
    6$:      MOV       (SP)+,RO
    7$:      TYPE      $SCLF ;:"CARRIAGE RETURN" & "LINE FEED"
    MOV     @2(RO)+,-(SP) ;:SAVE @2(RO)+ FOR TIMEOUT
    TYPOC  6$        ;:GO TYPE--OCTAL ASCII(ALL DIGITS)
    TST    (RO)      ;:IS THERE ANOTHER NUMBER?
    BEQ    6$        ;:BR IF NO
    TYPE   8$        ;:TYPE TWO(2) SPACES
    BR     7$        ;:LOOP
    8$:      .ASCIZ   / / ;:TWO(2) SPACES
    .EVEN

;*****
.SBTTL ERROR HANDLER ROUTINE
;:THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT.
;:SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
;:AND GO TO $ERRTYP ON ERROR
    
```

ERROR HANDLER ROUTINE

```

1512      ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
1513      ;*SW15=1      HALT ON ERROR
1514      ;*SW13=1      INHIBIT ERROR TYPEOUTS
1515      ;*SW10=1      BELL ON ERROR
1516      ;*SW09=1      LOOP ON ERROR
1517      ;*CALL
1518      ;*
1519      ERROR      N      ;;ERROR=EMT AND N=ERROR ITEM NUMBER
1520
1521      ;ERROR:
1521      007620      010637      001174      MOV      SP,$REG6      ;GET THE CURRENT STACK POINTER VALUE
1522      007624      162737      000004      001174      SUB      #4,$REG6      ;RESTORE IT TO ITS "PRE ERROR TRAP" VALUE FOR PR
1523      007632      016637      000002      001176      MOV      2(SP),$REG7      ;GET THE PS OFF OF THE STACK
1524      007640      005037      001172      CLR      $REG5      ;PREPARE "$REG5" TO HOLD THE TEST #
1525      007644      113737      001102      001172      MOV      $TSTNM,$REG5      ;TEST # IS HELD IN THE LOW BYTE OF "$TSTNM"
1526      007652      010037      001160      MOV      RO,$REG0      ;MOST OF THE TIME RO HAS GOOD STUFF IN IT ALSO
1527      007656      105237      001103      7$:      INCB     $ERFLG      ;;SET THE ERROR FLAG
1528      007662      001775      BEQ      7$      ;;DON'T LET THE FLAG GO TO ZERO
1529      007664      013777      001102      171246      MOV      $TSTNM,$DISPLAY      ;DISPLAY TEST NUMBER AND ERROR FLAG
1530      007672      032777      002000      171236      BIT      #BIT10,$SWR      ;BELL ON ERROR?
1531      007700      001402      BEQ      1$      ;NO - SKIP
1532      007702      104400      001224      TYPE     $BELL      ;RING BELL
1533      007706      005237      001112      1$:      INC      $ERTTL      ;COUNT THE NUMBER OF ERRORS
1534      007712      011637      001116      MOV      (SP),$ERRPC      ;GET ADDRESS OF ERROR INSTRUCTION
1535      007716      162737      000002      001116      SUB      #2,$ERRPC
1536      007724      117737      171166      001114      MOV      $ERRPC,$ITEMB      ;STRIP AND SAVE THE ERROR ITEM CODE
1537      007732      032777      020000      171176      BIT      #BIT13,$SWR      ;SKIP TYPEOUT IF SET
1538      007740      001004      BNE      20$      ;SKIP TYPEOUTS
1539      007742      004737      007464      JSR      PC,$ERRTYP      ;GO TO USER ERROR ROUTINE
1540      007746      104400      001231      TYPE     $CRLF
1541      007752
1542      007752      005777      171160      20$:      TST      $SWR      ;HALT ON ERROR
1543      007756      100001      BPL      31$      ;SKIP IF CONTINUE
1544      007760      000000      HALT
1545      007762      022737      006216      000042      31$:      CMP      #SENDAD,$#42      ;HALT ON ERROR!
1546      007770      001001      BNE      3$      ;ACT-11 AUTO-ACCEPT?
1547      007772      000000      HALT      ;BRANCH IF NO
1548      007774      032777      001000      171134      3$:      BIT      #BIT09,$SWR      ;YES
1549      010002      001402      BEQ      4$      ;LOOP ON ERROR SWITCH SET?
1550      010004      013716      001110      MOV      $LPERR,(SP)      ;BR IF NO
1551      010010      005737      001222      4$:      TST      $ESCAPE      ;FUDGE RETURN FOR LOOPING
1552      010014      001402      BEQ      5$      ;CHECK FOR AN ESCAPE ADDRESS
1553      010016      013716      001222      MOV      $ESCAPE,(SP)      ;BR IF NONE
1554      010022
1555      010022      000002      5$:      RTI      ;FUDGE RETURN ADDRESS FOR ESCAPE
1556      ;*****
1557
1558      .SBTTL TRAP DECODER
1559
1560      ;*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
1561      ;*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
1562      ;*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
1563      ;*GO TO THAT ROUTINE.
1564
1565      $TRAP:      MOV      RO,-(SP)      ;;SAVE RO
1566      010026      016600      000002      MOV      2(SP),RO      ;;GET TRAP ADDRESS
1567      010032      005740      TST      -(RO)      ;;BACKUP BY 2

```

```

1568 010034 111000          MOVB   (R0),R0          ;; GET RIGHT BYTE OF TRAP
1569 010036 006300          ASL    R0              ;; POSITION FOR INDEXING
1570 010040 016000 010046  MOV    $TRPAD(R0),R0   ;; INDEX TO TABLE
1571 010044 000200          RTS     R0              ;; GO TO ROUTINE
1572
1573
1574          .SBTTL  TRAP TABLE
1575
1576          ;*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
1577          ;*BY THE "TRAP" INSTRUCTION.
1578
1579          :          ROUTINE
1580          :          -----
1581 010046          $TRPAD:
1582 010046 006576          $TYPE  ;; CALL=TYPE      TRAP+0(104400)  TTY TYPEOUT ROUTINE
1583 010050 007262          $TYPOC ;; CALL=TYPOC     TRAP+1(104401)  TYPE OCTAL NUMBER (WITH LEADING ZEROS)
1584 010052 007236          $TYPOS ;; CALL=TYPOS     TRAP+2(104402)  TYPE OCTAL NUMBER (NO LEADING ZEROS)
1585 010054 007276          $TYPON ;; CALL=TYPON     TRAP+3(104403)  TYPE OCTAL NUMBER (AS PER LAST CALL)
1586 010056 007012          $TYPDS ;; CALL=TYPDS     TRAP+4(104404)  TYPE DECIMAL NUMBER (WITH SIGN)
1587          ;*****
1588
1589          .SBTTL  POWER DOWN AND UP ROUTINES
1590
1591          :POWER DOWN ROUTINE
1592 010060 012737 010222 000024 $PWRDN: MOV    $SILLUP,2,$PWRVEC ;; SET FOR FAST UP
1593 010066 012737 000340 000026  MOV    #340,2,$PWRVEC+2 ;; PRIO:7
1594 010074 010046          MOV    R0,-(SP)        ;; PUSH R0 ON STACK
1595 010076 010146          MOV    R1,-(SP)        ;; PUSH R1 ON STACK
1596 010100 010246          MOV    R2,-(SP)        ;; PUSH R2 ON STACK
1597 010102 010346          MOV    R3,-(SP)        ;; PUSH R3 ON STACK
1598 010104 010446          MOV    R4,-(SP)        ;; PUSH R4 ON STACK
1599 010106 010546          MOV    R5,-(SP)        ;; PUSH R5 ON STACK
1600 010110 013746 010450          MOV    POWPUS,-(SP)    ;; PUSH POWPUS ON STACK
1601 010114 013746 010452          MOV    POWPOP,-(SP)    ;; PUSH POWPOP ON STACK
1602 010120 013746 010240          MOV    POWMES,-(SP)    ;; PUSH POWMES ON STACK
1603 010124 013746 001672          MOV    T0001,-(SP)    ;; PUSH T0001 ON STACK
1604 010130 010637 010226          MOV    SP,$SAVR6      ;; SAVE SP
1605 010134 012737 010146 000024  MOV    $PWRUP,2,$PWRVEC ;; SET UP VECTOR
1606 010142 000000          HALT
1607 010144 000776          BR     .-2            ;; HANG UP
1608
1609          :POWER UP ROUTINE
1610 010146 013706 010226          $PWRUP: MOV    $SAVR6,SP    ;; GET SP
1611 010152 005037 010226          CLR    $SAVR6        ;; WAIT LOOP FOR THE TTY
1612 010156 005237 010226          1$:  INC    $SAVR6        ;; WAIT FOR THE INC
1613 010162 001375          BNE    1$            ;; OF <POWPUS>,<POWPOP>,<POWMES>,<T0001> WORD
1614 010164 012605          MOV    (SP)+,R5      ;; POP STACK INTO R5
1615 010166 012604          MOV    (SP)+,R4      ;; POP STACK INTO R4
1616 010170 012603          MOV    (SP)+,R3      ;; POP STACK INTO R3
1617 010172 012602          MOV    (SP)+,R2      ;; POP STACK INTO R2
1618 010174 012601          MOV    (SP)+,R1      ;; POP STACK INTO R1
1619 010176 012600          MOV    (SP)+,R0      ;; POP STACK INTO R0
1620 010200 012737 010060 000024  MOV    $PWRDN,2,$PWRVEC ;; SET UP THE POWER DOWN VECTOR
1621 010206 012737 000340 000026  MOV    #340,2,$PWRVEC+2 ;; PRIO:7
1622 010214 104400          TYPE
1623 010216 010230          $PWRMG: .WORD $POWER ;; REPORT THE POWER FAILURE
;; POWER FAIL MESSAGE POINTER

```

```

1624 010220 000002          RTI
1625 010222 000000          $ILLUP: HALT
1626 010224 000776          BR          .-2          ;; THE POWER UP SEQUENCE WAS STARTED
1627 010226 000000          $SAVR6: 0          ;; BEFORE THE POWER DOWN WAS COMPLETE
1628 010230 005015 047520 042527 $POWER: .ASCIZ <15><12>"POWER" ;; PUT THE SP HERE
1629 010236 000122
1630
1631 010240 005015 042522 052123 POWMES: .EVEN
1632 010246 051101 044524 043516          .ASCIZ <15> <12> "RESTARTING AFTER A POWER FIALURE" <15> <12> <12>
1633 010254 040440 052106 051105
1634 010262 040440 050040 053517
1635 010270 051105 043040 040511
1636 010276 052514 042522 005015
1637 010304 000012
1638 010306 005015 046412 026504 STMES: .ASCIZ <15><12><12>"MD-11-DZKWA-F LINE FREQUENCY CLOCK TEST"<15><12>
1639 010314 030461 042055 045532
1640 010322 040527 043055 046040
1641 010330 047111 020105 051106
1642 010336 050505 042525 041516
1643 010344 020131 046103 041517
1644 010352 020113 042524 052123
1645 010360 005015          000
1646
1647 010363          124 040522 050120 TRPMES: .ASCIZ "TRAPPED TO LOC 4 FROM LOCATION "
1648 010370 042105 052040 020117
1649 010376 047514 020103 020064
1650 010404 051106 046517 046040
1651 010412 041517 052101 047511
1652 010420 020116 000040
1653 010424 042522 052123 051101 TRPM2S: .ASCIZ "RESTARTING PROGRAM"
1654 010432 044524 043516 050040
1655 010440 047522 051107 046501
1656 010446          000
1657
1658 010450          001234          .EVEN
1659 010452          001234          POWPUS: WORD
1660 010454 020040 020040 020040          POWPOP: WORD
1661 010462 020040 020040 020040          EM1: .ASCIZ "          LKS          LKS          "
1662 010470 020040 020040 020040
1663 010476 020040 020040 020040
1664 010504 020040 020040 020040
1665 010512 020040 045514 020123
1666 010520 020040 020040 045514
1667 010526 020123 020040 020040
1668 010534          000
1669 010535          050 041520 020051 DH1: .ASCIZ "(PC) (PS) (SP) TEST# WAS S/B "
1670 010542 020040 024040 051520
1671 010550 020051 020040 024040
1672 010556 050123 020051 020040
1673 010564 052040 051505 021524
1674 010572 020040 053440 051501
1675 010600 020040 020040 051440
1676 010606 041057 020040 020040
1677 010614 000040
1678
1679 010616 001116 001176 001174          .EVEN
          DT1: $ERRPC,$REG7,$REG6,$REG5,LKS,$GDDAT

```

K03

1680	010624	001172	177546	001124	
1681	010632	000000			0
1682	010634	046103	041517	020113	EM2: .ASCIZ "CLOCK FAILED TO INTERRUPT"
1683	010642	040506	046111	042105	
1684	010650	052040	020117	047111	
1685	010656	042524	051122	050125	
1686	010664	000124			
1687	010666	050050	024503	020040	DH2: .ASCIZ "(PC) (PS) (SP) TEST# (LKS) "
1688	010674	020040	050050	024523	
1689	010702	020040	020040	051450	
1690	010710	024520	020040	020040	
1691	010716	042524	052123	020043	
1692	010724	020040	046050	051513	
1693	010732	020051	020040	000	
1694		010740			.EVEN
1695	010740	001116	001176	001174	DT2: \$ERRPC,\$REG7,\$REG6,\$REG5,LKS
1696	010746	001172	177546		
1697	010752	000000			0
1698	010754	046103	041517	020113	EM3: .ASCIZ "CLOCK INTERRUPTED WHEN THE PROCESSOR PRIORITY WAS TOO HIGH"
1699	010762	047111	042524	051122	
1700	010770	050125	042524	020104	
1701	010776	044127	047105	052040	
1702	011004	042510	050040	047522	
1703	011012	042503	051523	051117	
1704	011020	050040	044522	051117	
1705	011026	052111	020131	040527	
1706	011034	020123	047524	020117	
1707	011042	044510	044107	000	
1708	011047	050	041520	020051	DH3: .ASCIZ "(PC) (PS) (SP) TEST# (LKS) "
1709	011054	020040	024040	051520	
1710	011062	020051	020040	024040	
1711	011070	050123	020051	020040	
1712	011076	052040	051505	021524	
1713	011104	020040	024040	045514	
1714	011112	024523	020040	000040	
1715					.EVEN
1716	011120	001116	001176	001174	DT3: \$ERRPC,\$REG7,\$REG6,\$REG5,LKS
1717	011126	001172	177546		
1718	011132	000000			0
1719	011134	046103	041517	020113	EM4: .ASCIZ "CLOCK GIVES UNEQUAL # OF PULSES OVER TWO EQUAL PERIODS OF TIME"
1720	011142	044507	042526	020123	
1721	011150	047125	050505	040525	
1722	011156	020114	020043	043117	
1723	011164	050040	046125	042523	
1724	011172	020123	053117	051105	
1725	011200	052040	047527	042440	
1726	011206	052521	046101	050040	
1727	011214	051105	047511	051504	
1728	011222	047440	020106	044524	
1729	011230	042515	000		
1730	011233	050	041520	020051	DH4: .ASCIZ "(PC) (PS) (SP) TEST# 1ST 2ND"<15><12>"
1731	011240	020040	024040	051520	
1732	011246	020051	020040	024040	
1733	011254	050123	020051	020040	
1734	011262	052040	051505	021524	
1735	011270	020040	030440	052123	

1736	011276	020040	020040	031040	
1737	011304	042116	005015	020040	
1738	011312	020040	020040	020040	
1739	011320	020040	020040	020040	
1740	011326	020040	020040	020040	
1741	011334	020040	020040	020040	
1742	011342	020040	020040	020040	
1743	011350	042520	044522	042117	
1744	011356	020040	042520	044522	
1745	011364	042117	000		
1746		011370			
1747	011370	001116	001176	001174	.EVEN
1748	011376	001172	001162	001164	DT4: \$ERRPC,\$REG7,\$REG6,\$REG5,\$REG1,\$REG2
1749	011404	000000			0
1750	011406	045514	020123	042522	EMS: .ASCIZ "LKS REGISTER RESPONDS TO ANOTHER ADDRESS"
1751	011414	044507	052123	051105	
1752	011422	051040	051505	047520	
1753	011430	042116	020123	047524	
1754	011436	040440	047516	044124	
1755	011444	051105	040440	042104	
1756	011452	042522	051523	000	
1757	011457	050	041520	020051	DH5: .ASCIZ "(PC) (PS) (SP) TEST# ADDRESS"
1758	011464	020040	024040	051520	
1759	011472	020051	020040	024040	
1760	011500	050123	020051	020040	
1761	011506	052040	051505	021524	
1762	011514	020040	040440	042104	
1763	011522	042522	051523	000	
1764		011530			.EVEN
1765	011530	001116	001176	001174	DT5: \$ERRPC,\$REG7,\$REG6,\$REG5,\$GDADR
1766	011536	001172	001120		0
1767	011542	000000			EM6: .ASCIZ "A NO SACK TIMEOUT HAS OCCURED"
1768	011544	020101	047516	051440	
1769	011552	041501	020113	044524	
1770	011560	042515	052517	020124	
1771	011566	040510	020123	041517	
1772	011574	052503	042522	000104	
1773	011602	050050	024503	020040	DH6: .ASCIZ "(PC) (PS) (SP) TEST# (LKS) "
1774	011610	020040	050050	024523	
1775	011616	020040	020040	051450	
1776	011624	024520	020040	020040	
1777	011632	042524	052123	020043	
1778	011640	020040	046050	051513	
1779	011646	020051	020040	000	
1780		011654			.EVEN
1781	011654	001116	001176	001174	DT6: \$ERRPC,\$REG7,\$REG6,\$REG5,LKS
1782	011662	001172	177546		0
1783	011666	000000			EM7: .ASCIZ "WRONG CONDITION CODES WERE PUT ONTO STACK BY INTERRUPT"
1784	011670	051127	047117	020107	
1785	011676	047503	042116	052111	
1786	011704	047511	020116	047503	
1787	011712	042504	020123	042527	
1788	011720	042522	050040	052125	
1789	011726	047440	052116	020117	
1790	011734	052123	041501	020113	
1791	011742	054502	044440	052116	

```

1792 011750 051105 052522 052120
1793 011756 000
1794 011757 050 041520 020051 DH7: .ASCIZ "(PC) (PS) (SP) TEST# CC WAS CC S/B"
1795 011764 020040 024040 051520
1796 011772 020051 020040 024040
1797 012000 050123 020051 020040
1798 012006 052040 051505 021524
1799 012014 020040 041440 020103
1800 012022 040527 020123 041440
1801 012030 020103 027523 000102
1802
1803 012036 001116 001176 001174 .EVEN
DT7: $ERRPC,$REG7,$REG6,$REG5,BUF1,$GDDAT
1804 012044 001172 000776 001124
1805 012052 000000
1806 012054 051127 047117 020107
1807 012062 041520 050040 052125
1808 012070 047440 052116 020117
1809 012076 044124 020105 052123
1810 012104 041501 020113 054502
1811 012112 040440 020116 047111
1812 012120 042524 051122 050125
1813 012126 000124
1814 012130 050050 024503 020040 DH10: .ASCIZ "(PC) (PS) (SP) TEST# a(SP)WAS a(SP)S/B "
1815 012136 020040 050050 024523
1816 012144 020040 020040 051450
1817 012152 024520 020040 020040
1818 012160 042524 052123 020043
1819 012166 040040 051450 024520
1820 012174 040527 020123 024100
1821 012202 050123 051451 041057
1822 012210 020040 000
1823 012214 012214 .EVEN
1824 012214 001116 001176 001174 DT10: $ERRPC,$REG7,$REG6,$REG5,BUF2,$GDDAT
1825 012222 001172 000774 001124
1826 012230 000000
1827 012232 051124 042531 020104
1828 012240 047524 040440 041503
1829 012246 051505 020123 044124
1830 012254 020105 045514 020123
1831 012262 042522 044507 052123
1832 012270 051105 020054 047101
1833 012276 020104 051124 050101
1834 012304 042520 000104
1835 012310 050050 024503 020040 DH11: .ASCIZ "(PC) (PS) (SP) TEST#"
1836 012316 020040 050050 024523
1837 012324 020040 020040 051450
1838 012332 024520 020040 020040
1839 012340 042524 052123 000043
1840
1841 012346 001116 001176 001174 .EVEN
DT11: $ERRPC,$REG7,$REG6,$REG5
1842 012354 001172
1843 012356 000000
1844 000001 .END

```

A0004	002104	387#	390				
A0005	002172	408#	411				
A0006	002302	435#	438				
A0007	002434	465#	468				
A0010	002614	505#	508				
A0011	002716	534#	537				
A0012	003102	576#	579				
A0013	003172	606#	609				
A0014	003546	685	694#				
A0015	003664	706	718#				
A0016	004002	730	742#				
A0017	004120	754	766#				
A0020	004236	778	790#				
A0021	004354	802	814#				
A0022	004512	841	843#				
A0023	004560	857#	860				
A0024	004702	885#	886				
A0025	005012	909#	912				
A0026	005164	945#	946				
A0027	005300	971#	972				
A0030	005440	989	999#				
A0031	005526	1019#	1022				
A0032	005660	1056#	1059				
A0033	006016	1089#	1092				
BIT0	= 000001	121#					
BIT00	= 000001	111#	121				
BIT01	= 000002	110#	120				
BIT02	= 000004	109#	119				
BIT03	= 000010	108#	118				
BIT04	= 000020	107#	117				
BIT05	= 000040	106#	116				
BIT06	= 000100	105#	115				
BIT07	= 000200	104#	114				
BIT08	= 000400	103#	113	1205			
BIT09	= 001000	102#	112	1213	1548		
BIT1	= 000002	120#					
BIT10	= 002000	101#	1530				
BIT11	= 004000	100#	1220				
BIT12	= 010000	99#					
BIT13	= 020000	98#	1537				
BIT14	= 040000	97#	1191				
BIT15	= 100000	96#					
BIT2	= 000004	119#					
BIT3	= 000010	118#					
BIT4	= 000020	117#					
BIT5	= 000040	116#					
BIT6	= 000100	115#					
BIT7	= 000200	114#					
BIT8	= 000400	113#					
BIT9	= 001000	112#					
BPTVEC	= 000014	128#					
BUF1	= 000776	140#	1064*	1073	1097*	1803	
BUF2	= 000774	139#	1065*	1098*	1106	1824	
B0005	002210	409	414#				
B0006	002320	436	441#				
B0007	002452	466	471#				

B0010	002632	506	511#		
B0011	002734	535	540#		
B0012	003120	577	582#		
B0013	003210	607	612#		
B0014	003560	695	697#		
B0015	003676	719	721#		
B0016	004014	743	745#		
B0017	004132	767	769#		
B0020	004250	791	793#		
B0021	004366	815	817#		
B0023	004576	858	863#		
B0025	005030	910	915#		
B0030	005456	1001	1003#	1004	
B0031	005544	1020	1025#		
B0032	005676	1057	1062#		
B0033	006034	1090	1095#		
C0007	002462	474#	476		
C0010	002642	514#	516		
C0011	003014	553#	556		
C0013	003224	616#	619		
C0025	005054	902	923#		
C0031	005600	1034#	1037		
C0032	005742	1066	1073#		
C0033	006100	1099	1106#	1108	
DISP =	177570	43#	191		
DH1	010535	243	1669#		
DH10	012130	278	1814#		
DH11	012310	283	1835#		
DH2	010666	248	1687#		
DH3	011047	253	1708#		
DH4	011233	258	1730#		
DH5	011457	263	1757#		
DH6	011602	268	1773#		
DH7	011757	273	1794#		
DISPLA	001140	191#	327#	1234*	1529*
DISPRE	000174	149#	327		
DSMR =	177570	42#	190		
DT1	010616	244	1679#		
DT10	012214	279	1824#		
DT11	012346	284	1841#		
DT2	010740	249	1695#		
DT3	011120	254	1716#		
DT4	011370	259	1747#		
DT5	011530	264	1765#		
DT6	011654	269	1781#		
DT7	012036	274	1803#		
D0007	002474	457	479#		
D0010	002654	492	519#		
D0011	003032	554	559#		
D0013	003242	617	622#		
D0031	005616	1035	1040#		
EMTVEC=	000030	131#	309#	310*	
EM1	010454	242	1660#		
EM10	012054	277	1806#		
EM11	012232	282	1827#		
EM2	010634	247	1682#		

EM3	010754	252	1698#				
EM4	011134	257	1719#				
EM5	011406	262	1750#				
EM6	011544	267	1768#				
EM7	011670	272	1784#				
ERRVEC=	000004	124#	1196#	1197*	1199*	1202*	
E0001	001730	340	346#				
E0002	001776	360#					
E0003	002042	374#					
E0004	002116	391#					
E0005	002204	412#					
E0006	002314	439#					
E0007	002446	469#					
E0010	002626	509#					
E0011	002730	538#					
E0012	003114	580#					
E0013	003204	610#					
E0014	003556	696#					
E0015	003674	720#					
E0016	004012	744#					
E0017	004130	768#					
E0020	004246	792#					
E0021	004364	816#					
E0022	004510	842#					
E0023	004572	861#					
E0024	004722	877	890#				
E0025	005024	913#					
E0026	005204	940	950#				
E0027	005332	977#					
E0030	005472	999	1007#				
E0031	005540	1023#	1031				
E0032	005672	1060#					
E0033	006030	1093#					
E10006	002342	446#					
E10007	002470	477#					
E10010	002650	517#					
E10012	003134	587#					
E10013	003236	620#					
E10023	004614	867#					
E10025	005050	921#					
E10031	005612	1038#					
E10033	006110	1108#					
E1005	002226	418#					
E1011	003026	550	557#				
E20007	002502	481#					
E20010	002662	521#					
E20011	003040	563#					
E20013	003334	643#					
E20025	005064	925#					
E20031	005624	1044#					
E30013	003366	653#					
E40013	003444	669#					
F0013	003262	627#	632				
GNS =	***** U	148	1582	1583	1584	1585	1586
G0013	003276	628	631#				
H0013	003322	639#	642				

SENDCT	006164	315	1137#																		
SENDMG	006232	1139	1154#																		
SENULL	006247	1142	1157#																		
SEOP	006130	1127#																			
SEOPCT	006156	315*	1134#	1138																	
SERFLG	001103	175#	1180	1209	1211	1217*	1238	1527*	1556												
SERMAX	001115	181#	318*	1211	1233*	1238															
SERROR	007620	309	1520#																		
SERRPC	001116	182#	1472	1534*	1535*	1536	1556	1679	1695	1716	1747	1765	1781	1803							
		1824	1841																		
SERRTB	001236	241#	1480																		
SERTY	007464	1465#	1539																		
SERTTL	001112	179#	1533*	1556																	
SESCAP	001222	219#	317*	1232*	1551	1553	1556														
SFILLC	001154	198#	1277	1311																	
SFILLS	001153	197#	1311																		
SGDADR	001120	183#	684*	693*	699*	710*	717*	723*	734*	741*	747*	758*	765*	771*							
		782*	789*	795*	806*	813*	819*	832*	839*	1765											
SGDDAT	001124	185#	357*	369*	384*	400*	427*	455*	457*	682*	708*	732*	756*	780*							
		804*	830*	853*	865	875*	888	899*	934*	948	960*	975	987*	1075*							
		1108*	1679	1803	1824																
		1143#																			
SGET42	006206	18																			
SHD =	000000	18																			
SICNT	001104	176#	1224*	1225	1227*	1237															
SILLUP	010222	1592	1625#																		
SITEMB	001114	180#	1469	1536*	1556																
SLF	001232	223#	1311	1556																	
SLPADR	001106	177#	319*	342*	355*	370*	383*	401*	428*	456*	491*	531*	573*	602*							
		613*	635*	646*	656*	683*	709*	733*	757*	781*	805*	831*	854*	876*							
		900*	935*	961*	988*	1016*	1053*	1086*	1215*	1230*	1235	1237									
SLPERR	001110	178#	320*	1215	1231*	1237	1550														
SMAIL =	*****	331	1230	1262	1542																
SMXCNT	006574	1228	1237#																		
SNULL	001152	196#	1279	1311																	
SNCNT	007460	1412*	1441*	1454#																	
SOMODE	007462	1407*	1411*	1416	1419*	1430*	1456#														
SOVER	006560	1192	1208	1216	1226	1234#															
SPASS	001100	173#	1131*	1132*	1140	1154	1222	1238													
SPMER	010230	1623	1628#																		
SPWRDN	010060	313	1592#	1620																	
SPWRMG	010216	1623#																			
SPWRUP	010146	1605	1610#																		
SQUES	001230	221#	1311	1556																	
SROCHR=	*****	1587																			
SRODEC=	*****	1587																			
SROLIN=	*****	1587																			
SRODOCT=	*****	1587																			
SREGAD	001156	200#																			
SREG0	001160	202#	1526*																		
SREG1	001162	203#	669*	1747																	
SREG2	001164	204#	670*	1747																	
SREG3	001166	205#																			
SREG4	001170	206#																			
SREG5	001172	207#	1524*	1525*	1679	1695	1716	1747	1765	1781	1803	1824	1841								
SREG6	001174	208#	1521*	1522*	1679	1695	1716	1747	1765	1781	1803	1824	1841								
SREG7	001176	209#	1523*	1679	1695	1716	1747	1765	1781	1803	1824	1841									

U

U
U
U

.SCMTA	1#	8#	164
.SDB2D	1#		
.SDB20	1#		
.SDIV	1#		
.SEOP	1#	8#	1118
.SERRO	1#	8#	1505
.SERRT	1#	8#	1457
.SMULT	1#		
.SPOWE	1#	8#	1587
.SRAND	1#		
.SRDE	1#		
.SRDOC	1#		
.SREAD	1#		
.SR2AZ	1#		
.SSAVE	1#		
.SSB2D	1#		
.SSB20	1#		
.SSCOP	1#	8#	1174
.SSIZE	1#		
.SSUPR	1#		
.STRAP	1#	8#	1556
.STYPB	1#		
.STYPD	1#	8#	1311
.STYPE	1#	8#	1238
.STYPO	1#	8#	1379
.S4OCA	1#		

. ABS. 012360 000

ERRORS DETECTED: 0

DZKWF.BIN, DZKWF.LST/CRF/SOL/NL: TOC=DZKWF.SML, DZKWF.P11

RUN-TIME: 8 10 .8 SECONDS

RUN-TIME RATIO: 88/20=4.3

CORE USED: 28K (55 PAGES)

K04