

RP04/05/06

CONTROLLER LOGIC PART 2
MD-11-DZRJF-A

EP-DZRJF-A-DL-A


NOV 1978

COPYRIGHT © 1978



FICHE 1 OF 1

MADE IN U.S.A.



CONTENTS

- 1. ABSTRACT
- 2. REQUIREMENTS
 - 2.1 EQUIPMENT
 - 2.2 PRELIMINARY PROGRAMS
 - 2.3 OTHER PROGRAMS
- 3. LOADING PROCEDURES
- 4. STARTING PROCEDURES
 - 4.1 STARTING ADDRESSES
 - 4.2 UNIBUS & VECTOR ADDRESSES
 - 4.3 OPERATOR ACTION
- 5. OPERATING PROCEDURES
 - 5.1 OPERATIONAL SWITCH SETTINGS
 - 5.2 'SOFTWARE' SWITCH REGISTER
 - 5.3 TEST SELECTION
 - 5.4 DUAL PORT TEST CABLE CONNECTION
- 6. ERRORS
- 7. MISCELLANEOUS
 - 7.1 RESTRICTIONS
 - 7.2 LIMITATIONS
 - 7.3 EXECUTION TIME
 - 7.4 STACK POINTER
 - 7.5 SUBROUTINE CALLS
 - 7.6 REQUIRED TESTS
 - 7.7 DISK SURFACE USAGE
 - 7.8 LOOP ON ERROR OPTION
 - 7.9 SPINDLE MOTOR 'COOL DOWN' STALL
- 8. TEST DESCRIPTIONS
- 9. PROGRAM LISTING

41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83

94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139

1. ABSTRACT

THE RPO4/5/6 DUAL CONTROLLER OPTION LOGIC TEST PERFORMS A SERIES OF TESTS WHICH VERIFY THAT THE RPO4/5/6 DUAL CONTROLLER LOGIC IS FUNCTIONING PROPERLY. ONLY THE CONTROL LOGIC IS TESTED BY THIS PROGRAM; DATA HANDLING IN THE DUAL CONTROLLER MODE IS NOT TESTED BY THIS PROGRAM.

BOTH PORTS OF THE DRIVE ARE CABLED TO THE SAME MASSBUS BY A SPECIAL ADAPTER CABLE. THIS ARRANGEMENT ALLOWS THE DUAL CONTROLLER LOGIC TO BE TESTED FROM ONE PDP-11/RH11 OR RH70.

THIS PROGRAM IS THE SECOND PART OF THE RPO4 DUAL CONTROLLER OPTION LOGIC TEST. ONLY THE CONTROL LOGIC ASSOCIATED WITH THE UNLOAD COMMAND AND 'CONTROLLER SELECT' SWITCH IS TEST BY THIS PROGRAM.

2. REQUIREMENTS

2.1 EQUIPMENT

PDP-11 PROCESSOR
16K OF MEMORY
KW11-L OR KW11-P CLOCK
TELETYPE
RH11 OR RH70 WITH AN RPO4/5/6
RPO4/5/6 DUAL CONTROLLER OPTION TEST CABLE

2.2 PRELIMINARY PROGRAMS

A. RPO4/5/6 DISKLESS CONTROLLER TEST
PART 1 (MAINDEC-11-DZRJG)
PART 2 (MAINDEC-11-DZRJH)

B. RPO4/5/6 FUNCTIONAL CONTROLLER TEST
PART 1 (MAINDEC-11-DZRJI)
PART 2 (MAINDEC-11-DZRJJ)

THE PRELIMINARY PROGRAMS MUST BE RUN TWICE: ONCE FROM EACH CONTROLLER (PORT).

C. RPO4 DUAL CONTROLLER LOGIC TEST
PART 1 (MAINDEC-11-DZRJE)

2.3 OTHER PROGRAMS

DYNAMIC OPERATION OF THE DUAL CONTROLLER OPTION IS TESTED BY THE RPO4/5/6 MULTIDRIVE EXERCISER PROGRAM (MAINDEC-11-DZRJD).

140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195

3. LOADING PROCEDURES

THE PROGRAM MAY BE LOADED BY THE ABSOLUTE PAPER TAPE LOADER OR IT MAY BE LOADED FROM THE APPROPRIATE MEDIA USING THE ASSOCIATED 'XXDP' LOADER. THE PROGRAM MAY NOT BE INCLUDED IN AN 'XXDP' CHAIN.

4. STARTING PROCEDURES

4.1 STARTING ADDRESSES

- A. THE NORMAL STARTING ADDRESS OF THE PROGRAM IS LOCATION 200(B). STARTING AT THIS ADDRESS ALLOWS THE OPERATOR TO SELECT (OR RESELECT) THE ADDRESS OF THE DRIVE TO BE TESTED.
- B. THE RESTART ADDRESS IS LOCATION 204(B). THE PROGRAM WILL USE THE CURRENT DRIVE (DCL) ADDRESS.
- C. THE PROGRAM CAN BE STARTED AT LOCATION 210(B) TO ALLOW THE RH11 OR RH70 ADDRESS TO BE CHANGED.

4.2 UNIBUS & VECTOR ADDRESS

THE PROGRAM ASSUMES THE FOLLOWING UNIBUS AND VECTOR ADDRESSES. THESE ADDRESSES MAY BE CHANGED PRIOR TO STARTING THE PROGRAM FROM ANY OF THE STARTING LOCATIONS.

<u>MEMORY LOCATION</u>	<u>CONTENTS</u>	<u>FUNCTION</u>
1142	177560	TTY KEYBOARD STATUS REG
1144	177562	TTY KEYBOARD BUFFER REG
1146	177564	TTY PRINTER STATUS REG
1150	177566	TTY PRINTER BUFFER REG
1210	172540	KW11-P STATUS REG
1212	172542	KW11-L COUNTER BUFFER
1214	104	KW11-P VECTOR ADDRESS
1216	177546	KW11-L STATUS REGISTER
1220	100	KW11-L VECTOR ADDRESS

4.3 OPERATOR ACTION

- A. CONNECT THE DUAL CONTROLLER TEST CABLE BETWEEN BUS A & BUS B ON THE DRIVE BEING TESTED. (SEE SECTION 5.4)
- B. LOAD THE PROGRAM INTO MEMORY IN THE PROCESSOR CONTROLLING THE MASSBUS USED FOR TESTING.
- C. SWITCH THE 'CONTROLLER SELECT' SWITCH ON THE DRIVE TO BE TESTED TO THE 'A/B' POSITION. CYCLE THE DRIVE UP.
- D. LOAD THE APPROPRIATE STARTING ADDRESS (200(B) OR 210(B)) INTO THE SWITCH REGISTER (OR THE 'SOFTWARE' SWITCH REGISTER,

196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251

- SEE SECTION 5.2.)
- E. PRESS START.
- F. ENTER THE DRIVE NUMBER. (THIS MUST BE THE NUMBER DISPLAYED BY THE DRIVE, IF AN RPO4, OR THE NUMBER OF ADDRESS PLUG IF THE DRIVE IS AN RPO5/6.)
- G. ENTER THE NUMBER OF THE TEST TO BE RUN. ('CARRIAGE RETURN' OR '0' WILL RUN ALL TESTS.)
- H. THE PROGRAM MAY BE STOPPED AT ANY TIME AND RESTARTED FROM LOCATION 204.

5. OPERATING PROCEDURES

5.1 OPERATIONAL SWITCH SETTINGS

WITH ALL SWITCHES SET TO ZERO, THE PROGRAM WILL TYPE ALL ERRORS AND CONTINUE TESTING.

THE SWITCH SETTINGS ARE:

- SW<15>=1...HALT ON ERROR
- SW<14>=1...LOOP ON TEST
- SW<13>=1...INHIBIT ERROR TYPEOUTS
- SW<11>=1...INHIBIT TEST ITERATIONS
- SW<10>=1...RING TTY BELL ON ERROR
- SW<09>=1...LOOP ON ERROR

5.2 'SOFTWARE' SWITCH REGISTER

IF THE PROGRAM IS BEING RUN ON A SWITCHLESS PROCESSOR (I.E. AN 11/34) THE PROGRAM WILL DETERMINE THAT THE HARDWARE SWITCH REGISTER IS NOT PRESENT AND WILL USE A 'SOFTWARE' SWITCH REGISTER. THE 'SOFTWARE' SWITCH REGISTER IS LOCATED AT LOCATION 176 (8). THE SETTINGS OF THE 'SOFTWARE' SWITCHES ARE CONTROLLED THROUGH A KEYBOARD ROUTINE WHICH IS CALLED BY TYPING A 'CONTROL G'. THE PROGRAM WILL RECOGNIZE THE 'CONTROL G' AT ANY TIME EXCEPT WHEN THE PROGRAM IS AT A HIGHER PRIORITY PROCESSING AN RPO4/5/6 INTERRUPT. THE 'SOFTWARE' SWITCH VALUES ARE ENTERED AS AN OCTAL NUMBER IN RESPONSE TO THE PROMPT FROM THE SWITCH ENTRY ROUTINE:

'SWR = NNNNNN NEW ='

EACH TIME SWITCH SETTING ARE ENTERED, THE ENTIRE SWITCH REGISTER IMAGE MUST BE ENTERED. LEADING ZEROS ARE NOT REQUIRED. 'RUBOUT' AND 'CONTROL U' FUNCTIONS MAY BE USED TO CORRECT TYPING ERRORS DURING SWITCH ENTRY.

ON PROCESSORS WITH HARDWARE SWITCH REGISTERS, THE 'SOFTWARE' SWITCH REGISTER MAY BE USED. IF THE PROGRAM FINDS ALL 16 SWITCHES IN THE 'UP' POSITION, ALL SWITCH REGISTER REFERENCES WILL BE TO THE 'SOFTWARE' REGISTER AND THE PROCEDURES DESCRIBED ABOVE MUST BE FOLLOWED.

5.3 TEST SELECTION

253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307

INDIVIDUAL TESTS ARE SELECTED IN RESPONSE TO THE 'ENTER TEST NUMBER:' MESSAGE. ANY VALID TEST NUMBER CAN BE ENTERED. EACH ENTRY MUST BE TERMINATED BY A CARRIAGE RETURN (CR). THE LOOP ON TEST SWITCH, SW<15>, MUST BE SET TO ALL CONTINUOUS EXECUTION OF THE SELECTED TEST.

TO RUN ALL TESTS IN SEQUENCE, ENTER EITHER A '0' FOLLOWED BY A CARRIAGE RETURN OR A CARRIAGE RETURN BY ITSELF. THE PROGRAM WILL THEN EXECUTE ALL TESTS IN SEQUENCE.

THE 'RUBOUT KEY' (RO) CAN BE USED TO DELETE THE LAST CHARACTER ENTERED. SUCCESSIVELY STRIKING THE RO KEY WILL DELETE CHARACTERS UNTIL THE PREVIOUS CHARACTERS HAVE BEEN DELETED. CHARACTERS DELETED BY THE RO KEY WILL BE TYPED AND WILL BE SEPARATED BY '\ ' FROM THE CHARACTERS ENTERED BY THE OPERATOR.

THE OPERATOR CAN DELETE AN ENTIRE ENTRY BY TYPING A 'CONTROL U' (↑U).

5.4 TEST CABLE CONNECTION

TO TEST THE RPO4/5/6 DUAL CONTROLLER OPTION WITH THIS PROGRAM, A SPECIAL TEST CABLE MUST BE USED. (THE TEST CABLE IS P/N 7010507-02). THE TEST CABLE CONNECTS MASSBUS A & MASSBUS B TOGETHER AT THE DRIVE BEING TESTED AND IS CONSTRUCTED SO THAT BIT 0 OF THE MASSBUS UNIT SELECT LINES IS COMPLEMENTED.

WITH THE TEST CABLE CONNECTED TO THE DRIVE UNDER TEST, THE DRIVE APPEARS AS TWO UNITS ON THE MASSBUS: EACH PORT OF THE RPO4 WILL RESPOND TO A DIFFERENT MASSBUS ADDRESS.

THE ADDRESS OF EACH PORT WILL DEPEND UPON THE DRIVE'S ADDRESS (THE ADDRESS SELECTED BY THE SWITCHES ON THE 'DP' BOARD - MODULE M7775 FOR RPO4'S, OR BY THE ADDRESS PLUG FOR RPO5/6'S).

THE PROGRAM WILL TYPEOUT THE APPARENT ADDRESSES OF BOTH PORTS. (ONE PORT WILL HAVE THE ADDRESS OF THE DRIVE; THE OTHER PORT WILL HAVE THE ADDRESS DEVELOPED BY THE CABLE).

* ANY OTHER DRIVE ON THE MASSBUS WHICH HAS AN ADDRESS IN *
* CONFLICT WITH EITHER OF THE TEST ADDRESSES MUST BE *
* POWERED DOWN. *

THE TEST CABLE CONNECTION TO THE DRIVE UNDER TEST WILL DEPEND ON WHICH PROCESSOR/RH11 IS TO TEST THE DRIVE. IF THE DRIVE IS TO BE TESTED BY THE PROCESSOR ON PORT A, THE TEST CABLE IS CONNECTED FROM 'BUS A OUT' TO 'BUS B IN'. IF THE DRIVE IS TO BE TESTED BY THE PORT B PROCESSOR, THE TEST CABLE IS CONNECTED FROM 'BUS B OUT' TO 'BUS A IN'.

WHEN THE DUAL PORT TEST CABLE IS CONNECTED, THE ATTENTION

308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360

BITS FOR PORTS A & B ARE ASSERTED IN THE SAME BIT POSITION WHEN 'RPAS' (ATTENTION SUMMARY REGISTER) IS READ. THE ATTENTION BIT POSITION IS DETERMINED BY THE ADDRESS OF THE DRIVE. THE ATTENTION BIT THAT APPEARS FOR THE DRIVE IS THE INCLUSIVE 'OR' OF THE PORT A & PORT B ATTENTION BITS. BECAUSE OF THIS, THE PROGRAM LOOKS AT ONLY THE ATTENTION BIT IN 'RPSI' (DRIVE STATUS REGISTER) TO DETERMINE THE STATE OF THE SELECTED PORT'S ATTENTION BIT.

6. ERRORS

WHEN THE PROGRAM ENCOUNTERS AN ERROR, THE ERROR ROUTINE IS CALLED AND IF SW(13) IS NOT SET, THE ERROR MESSAGE PERTAINING TO THE ERROR WILL BE TYPED. EACH ERROR TYPEOUT WILL CONTAIN THE FOLLOWING:

- A. AN ERROR MESSAGE
- B. A DATA HEADER LINE
- C. A DATA LINE CONTAINING:
 - 1. THE TEST NUMBER
 - 2. THE PC (PROGRAM COUNTER VALUE) WHERE THE ERROR CALL WAS MADE
 - 3. CONTENTS OF THE APPROPRIATE REGISTERS

7. MISCELLANEOUS

7.1 RESTRICTIONS

TO RUN THIS PROGRAM, THE SYSTEM MUST HAVE EITHER A KW11-P OR A KW11-L CLOCK. ADDITIONALLY, THE RPO4 UNDER TEST MUST HAVE THE DUAL PORT TEST CABLE CONNECTED.

7.2 LIMITATIONS

THIS PROGRAM DOES NOT TEST DATA TRANSFERS THROUGH EITHER PORT AND DOES NOT TEST THE DYNAMIC OPERATION OF THE DUAL CONTROLLER OPTION.

7.3 EXECUTION TIME

THE PROGRAM TAKES ABOUT 60 SECONDS PER PASS (DEPENDING ON OPERATOR INTERVENTION EFFICIENCY).

7.4 STACK POINTER

THE STACK IS INITIALLY SET TO 1100 AND EXTENDS DOWNWARD IN MEMORY.

7.5 SUBROUTINE CALLS

364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419

THE SUBROUTINE CALLS USED BY THE PROGRAM ARE:

- A. 'SCOPE' (IOT INSTRUCTION). THIS CALL IS PLACED BETWEEN EACH TEST IN THE INSTRUCTION. THIS ROUTINE ESTABLISHES THE ITERATION COUNT AND THE LOOP ON TEST AND LOOP ON ERROR ADDRESSES.
- B. 'ERROR' (EMT INSTRUCTION). THIS CALL IS USED TO REPORT ALL ERRORS. THE CALL IS FOLLOWED BY A NUMBER WHICH IDENTIFIES THE ERROR MESSAGE WHICH WILL BE TYPED.

THE TRAP INSTRUCTION IS USED FOR THE FOLLOWING SUBROUTINE CALLS:

TYPE - TTY TYPEOUT ROUTINE
 TYPOC - TYPE OCTAL NUMBER (WITH LEADING ZERO)
 TYPOS - TYPE OCTAL NUMBER (NO LEADING ZEROS)
 TYPON - TYPE OCTAL NUMBER PER LAST CALL
 TYPS - TYPE DECIMAL NUMBER WITH SIGN
 RDCHR - READ CHARACTER FROM TTY KEYBOARD
 RDLIN - READ A LINE FROM THE TTY KEYBOARD.
 RDOCT - READ AN OCTAL NUMBER FROM THE TTY KEYBOARD
 SAVREG - ROUTINE TO SAVE RO-RS
 RESREG - ROUTINE TO RESTORE RO-RS

7.6 REQUIRED TESTS

IF THE PROGRAM IS BEING EXECUTED IN SINGLE TEST MODE, THE OPERATOR MUST CALL AND RUN THE FOLLOWING TESTS BEFORE OTHER TESTS ARE RUN:

- A. TEST 2 AND TEST 3. THESE TESTS SET 'VV-A' AND 'VV-B' RESPECTIVELY. THESE TESTS MUST BE PERFORMED AT LEAST ONCE BEFORE TESTS 4 - 14 ARE RUN.
- B. TEST 4 AND TEST 5. THESE TESTS DETERMINE AND STORE FOR LATER USE THE TIMEOUT ONE-SHOT VALUE MEASURED THROUGH EACH PORT. THESE TESTS MUST BE PERFORMED AT LEAST ONCE BEFORE TESTS 6 - 14 ARE RUN.

7.7 DISK SURFACE USAGE

THE DIAGNOSTIC DOES NOT USE THE DISK SURFACE. HOWEVER, THE DRIVE MUST BE CYCLED UP AND ON LINE FOR THE DIAGNOSTIC TO BE RUN.

7.8 LOOP ON ERROR OPTION

IF SW<09> IS SET, THE PROGRAM WILL LOOP ON A FAILING TEST UNTIL EITHER THE SWITCH IS RESET OR THE ERROR STOPS OCCURRING. BECAUSE THE PROGRAM MUST RESET THE RPO4 TO A KNOWN STATE BEFORE LOOPING ON THE ERROR, THE TEST FOR SW<09> IS PERFORMED AT THE END OF THE TEST - NOT AT THE POINT WHERE THE ERROR WAS DETECTED.

420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475

7.9 SPINDLE MOTOR 'COOL DOWN' STALL

THE PROGRAM STALLS FOR 5 SECONDS AFTER THE SPINDLE MOTOR ON THE DRIVE BEING TESTED HAS BEEN CYCLED UP. THIS STALL ALLOWS THE MOTOR TO COOL DOWN AND WAS INCLUDED TO MINIMIZE THE NUMBER OF TIME THAT THE THERMAL BREAKER ON THE MOTOR WILL TRIP DURING TESTING.

8. TEST DESCRIPTIONS

8.1 METHOD USED TO VERIFY THAT DRIVE IS IN NEUTRAL

THE PROGRAM DETERMINES THE THE DRIVE IS IN NEUTRAL BY CHECKING THE CONTENTS OF THE DRIVE STATUS REGISTER (RPDS1) THROUGH BOTH PORTS. THE PROGRAM MASKS OUT THE PORT DEPENDENT BITS ('ATA' & 'VV') AND VERIFIES THAT CORRECT STATUS IS READ THROUGH BOTH PORTS. (THE CORRECT STATUS IS 'MOL', 'PGM', 'DPR', & 'DRY'.) IF NEITHER PORT SEES ALL ZEROS FROM RPDS1, THE PROGRAM CONCLUDES THAT THE DRIVE IS IN NEUTRAL AND THAT ANY BIT DISCREPANCY BETWEEN PORTS INDICATES A FAILURE IN THE PATH FOR THAT BIT.

8.2 METHOD USED TO VERIFY THAT THE DRIVE HAS BEEN SEIZED

THE PROGRAM VERIFIES THAT THE DRIVE HAS BEEN SEIZED BY CHECKING THE DRIVE STATUS REGISTER (RPDS1) THROUGH THE SEIZING PORT AND VERIFYING THAT CORRECT STATUS IS SEEN. WHEN RPDS1 IS READ THROUGH THE OPPOSITE PORT, ZEROS SHOULD BE SEEN. IF BOTH CONDITIONS EXIST, (I.E. THE OPPOSITE PORT), THE PROGRAM CONCLUDES THAT THE DRIVE HAS BEEN SEIZED BY THE SPECIFIED PORT.

8.3 TEST 1 - DRIVE ACCESS TEST

VERIFY THAT THE DRIVE CAN BE ACCESSED THROUGH BOTH PORTS

- A. SELECT DRIVE, VERIFY THAT THE DRIVE IS PRESENT, THAT THE DRIVE IS A DUAL PORT RPO4, THAT THE DRIVE IS ONLINE (RPDS1 HAS 'MOL', 'PGM', 'DPR', & 'DRY' BITS SET), AND THE DRIVE SERIAL NUMBER READ THROUGH BOTH PORTS IS THE SAME.
- B. THE TEST IS REPEATED THROUGH BOTH PORTS.

8.4 TEST 2 - SET 'VV' FOR PORT 'A'

SET VOLUME VALID

- A. ISSUE A DRIVE CLEAR COMMAND THROUGH PORT 'A'.
- B. ISSUE A READIN PRESET COMMAND THROUGH PORT 'A'. VERIFY THAT THE 'VV' BIT IS SET FOR PORT 'A'.
- C. ISSUE A RELEASE COMMAND THROUGH PORT 'A'. VERIFY THAT THE DRIVE RETURNED TO NEUTRAL AND THAT NEITHER ATTENTION

476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531

BIT IS SET.

- B.5 TEST 3 - SET 'VV' FOR PORT 'B'
SET VOLUME VALID
 - A. ISSUE A DRIVE CLEAR COMMAND THROUGH PORT 'B'.
 - B. ISSUE A READIN PRESET COMMAND THROUGH PORT 'B'. VERIFY THAT THE 'VV' BIT IS SET FOR PORT 'B'.
 - C. ISSUE A RELEASE COMMAND THROUGH PORT 'B'. VERIFY THAT THE DRIVE RETURNED TO NEUTRAL AND THAT NEITHER ATTENTION BIT IS SET.

- B.6 TEST 4 - MEASURE THE TIMEOUT ONE-SHOT THROUGH PORT 'A'
MEASURE THE TIMEOUT ONE-SHOT VALUE THROUGH PORT 'A'
 - A. WRITE 0'S INTO RPS1 THROUGH PORT 'A' AND VERIFY THAT THE DRIVE HAS BEEN SEIZED.
 - B. WAIT FOR TIMEOUT TO OCCUR. MEASURE THE DURATION OF THE TIMEOUT ONE-SHOT AND SAVE THE VALUE FOR LATER USE.
 - C. VERIFY THAT THE TIMEOUT OCCURED AND THAT THE DRIVE RETURNS TO NEUTRAL.

- B.7 TEST 5 - MEASURE THE TIMEOUT ONE-SHOT THROUGH PORT 'B'
MEASURE THE TIMEOUT ONE-SHOT VALUE THROUGH PORT 'B'
 - A. WRITE 0'S INTO RPS1 THROUGH PORT 'B' AND VERIFY THAT THE DRIVE HAS BEEN SEIZED.
 - B. WAIT FOR TIMEOUT TO OCCUR. MEASURE THE DURATION OF THE TIMEOUT ONE-SHOT AND SAVE THE VALUE FOR LATER USE.
 - C. VERIFY THAT THE TIMEOUT OCCURED AND THAT THE DRIVE RETURNS TO NEUTRAL.

- B.8 TEST 6 - TEST UNLOAD COMMAND THROUGH PORT 'A'
VERIFY THAT THE UNLOAD COMMAND FUNCTIONS PROPERLY AND THAT A PORT TIMEOUT WILL NOT OCCUR WHILE THE 'GO' BIT IS SET.
 - A. ISSUE AN UNLOAD COMMAND THROUGH PORT 'A'; VERIFY THAT THE DRIVE IS SEIZED.
 - B. WAIT THE MEASURED TIMEOUT INTERVAL + 25%; VERIFY THAT THE DRIVE DOES NOT TIME OUT. VERIFY THAT THE 'GO' BIT IS STILL SET AND THAT 'DRY' AND 'PIP' ARE NOT SET.
 - C. REQUEST THAT THE OPERATOR PRESS THE 'STANDBY' BUTTON ON THE DRIVE.
 - D. WHEN THE DRIVE CYCLES UP, VERIFY THAT THE DRIVE IS STILL SEIZED

532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587

BY PORT A, THAT THE 'VV' BIT FOR PORT A IS RESET, THAT THE ATTENTION BIT FOR PORT 'A' IS SET, AND THAT THE ATTENTION BIT FOR PORT 'B' IS NOT SET.

- E. WAIT FOR THE PORT TIMEOUT TO RELEASE THE DRIVE. WHEN THE TIMEOUT OCCURS, VERIFY THAT THE DRIVE RETURNED TO NEUTRAL, THAT THE ATTENTION BIT FOR PORT 'A' IS SET, AND THAT THE ATTENTION BIT FOR PORT 'B' IS NOT SET.
- F. VERIFY THAT THE 'VV' BIT FOR PORT 'B' IS NOT SET.
- G. ISSUE A PACK ACKNOWLEDGE INSTRUCTION THROUGH BOTH PORTS.

B.9 TEST 7 - TEST UNLOAD COMMAND THROUGH PORT 'B'

VERIFY THAT THE UNLOAD COMMAND FUNCTIONS PROPERLY AND THAT A PORT TIMEOUT WILL NOT OCCUR WHILE THE 'GO' BIT IS SET.

- A. ISSUE AN UNLOAD COMMAND THROUGH PORT 'B'; VERIFY THAT THE DRIVE IS SEIZED.
- B. WAIT THE MEASURED TIMEOUT INTERVAL + 25%; VERIFY THAT THE DRIVE DOES NOT TIME OUT. VERIFY THAT THE 'GO' BIT IS STILL SET AND THAT 'DRY' AND 'PIP' ARE NOT SET.
- C. REQUEST THAT THE OPERATOR PRESS THE 'STANDBY' BUTTON ON THE DRIVE.
- D. WHEN THE DRIVE CYCLES UP, VERIFY THAT THE DRIVE IS STILL SEIZED BY PORT B, THAT THE 'VV' BIT FOR PORT B IS RESET, THAT THE ATTENTION BIT FOR PORT 'B' IS SET, AND THAT THE ATTENTION BIT FOR PORT 'A' IS NOT SET.
- E. WAIT FOR THE PORT TIMEOUT TO RELEASE THE DRIVE. WHEN THE TIMEOUT OCCURS, VERIFY THAT THE DRIVE RETURNED TO NEUTRAL, THAT THE ATTENTION BIT FOR PORT 'B' IS STILL SET, AND THAT THE ATTENTION BIT FOR PORT 'A' IS NOT SET.
- F. VERIFY THAT THE 'VV' BIT FOR PORT 'A' IS NOT SET.
- G. ISSUE A PACK ACKNOWLEDGE INSTRUCTION THROUGH BOTH PORTS.

B.10 TEST 10 - TEST THE CONTROLLER SELECT SWITCH THROUGH PORT 'A' DURING UNLOAD

VERIFY THAT THE 'CONTROLLER SELECT' SWITCH IS INHIBITED WHEN THE RP04 IS CYCLED DOWN BY AN UNLOAD COMMAND.

- A. ISSUE AN UNLOAD COMMAND THROUGH PORT 'A'.
- B. REQUEST THAT THE OPERATOR SWITCH THE 'CONTROLLER SELECT' SWITCH TO 'A' AND THEN PRESS THE 'STANDBY' BUTTON.
- C. WAIT FOR 'MOL' TO SET BY MONITORING RPDS1 THROUGH PORT 'A'. WHEN THE DRIVE HAS CYCLED UP ('MOL' HAS SET), ISSUE A RELEASE COMMAND THROUGH PORT 'A'.

588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643

- D. VERIFY THAT THE DRIVE CAN BE ACCESSED BY BOTH PORTS AND THAT THE DRIVE IS STILL IN NEUTRAL.
- E. REQUEST THAT THE OPERATOR RETURN THE 'CONTROLLER SELECT' SWITCH TO 'A/B'.

8.11 TEST 11 - TEST 'CONTROLLER SELECT' SWITCH THROUGH PORT 'B' DURING UNLOAD

VERIFY THAT THE 'CONTROLLER SELECT' SWITCH IS INHIBITED WHEN THE RPO4 IS CYCLED DOWN BY AN UNLOAD COMMAND.

- A. ISSUE AN UNLOAD COMMAND THROUGH PORT 'B'.
- B. REQUEST THAT THE OPERATOR SWITCH THE 'CONTROLLER SELECT' SWITCH TO 'B' AND THEN PRESS THE 'STANDBY' BUTTON.
- C. WAIT FOR 'MOL' TO SET BY MONITORING RPDS1 THROUGH PORT 'B'. WHEN THE DRIVE HAS CYCLED UP ('MOL' HAS SET), ISSUE A RELEASE COMMAND THROUGH PORT 'B'.
- D. VERIFY THAT THE DRIVE CAN BE ACCESSED BY BOTH PORTS AND THAT THE DRIVE IS STILL IN NEUTRAL.
- E. REQUEST THAT THE OPERATOR RETURN THE 'CONTROLLER SELECT' SWITCH TO 'A/B'.

8.12 TEST 12 - TEST 'CONTROLLER SELECT' SWITCH, DRIVE CYCLED UP

TEST THE OPERATION OF THE 'CONTROLLER SELECT' SWITCH (DRIVE CYCLED UP).

- A. SWITCH TO CONTROLLER 'A' POSITION. VERIFY THAT THE DRIVE IS IN NEUTRAL AND THAT THE STATUS BITS IN RPDS1, AS READ THROUGH BOTH PORTS, ARE CORRECT.
- B. SWITCH TO CONTROLLER 'B' POSITION. VERIFY THAT THE DRIVE IS IN NEUTRAL AND THAT THE STATUS BITS IN RPDS1, AS READ THROUGH BOTH PORTS, ARE CORRECT.
- C. RETURN THE 'CONTROLLER SELECT' SWITCH LOCKED ON PORT 'A'

TEST THE OPERATION OF THE 'CONTROLLER SELECT' SWITCH (DRIVE CYCLED DOWN).

- A. CYCLE THE DRIVE DOWN.
- B. SWITCH TO CONTROLLER 'A' POSITION. VERIFY THAT THE DRIVE IS IN NEUTRAL AND THAT THE STATUS BITS IN RPDS1, AS READ THROUGH BOTH PORTS, ARE CORRECT.
- C. SWITCH THE 'CONTROLLER SELECT' SWITCH TO 'A'; CYCLE THE DRIVE UP.
- D. WHEN THE DRIVE CYCLES UP, VERIFY THAT 'VV-A' IS RESET, AND THAT 'ATA-A' IS SET.
- E. ISSUE A DRIVE CLEAR COMMAND AND A READIN PRESET COMMAND THROUGH PORT 'A'.

644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699

F. VERIFY THAT THE DRIVE CANNOT BE ACCESSED THROUGH PORT 'B' AND 'NED' DOES NOT SET WHEN ATTEMPTING TO ACCESS THE DRIVE THROUGH PORT 'B' ATTEMPT TO SET PORT REQUEST BY WRITING 0'S INTO RPDS1 THROUGH PORT 'B'.

G. ISSUE A RELEASE COMMAND THROUGH PORT 'A'. VERIFY THAT THE DRIVE REMAINS LOCKED ON PORT 'A'.

8.14 TEST 14 - TEST 'CONTROLLER SELECT' SWITCH, LOCKED ON PORT 'B'
TEST THE OPERATION OF THE 'CONTROLLER SELECT' SWITCH (DRIVE CYCLED DOWN).

A. CYCLE THE DRIVE DOWN.

B. SWITCH TO CONTROLLER 'B' POSITION. VERIFY THAT THE DRIVE IS IN NEUTRAL AND THAT THE STATUS BITS IN RPDS1, AS READ THROUGH BOTH PORTS, ARE CORRECT.

C. SWITCH THE 'CONTROLLER SELECT' SWITCH TO 'B'; CYCLE THE DRIVE UP.

D. WHEN THE DRIVE CYCLES UP, VERIFY THAT 'VV-B' IS RESET, AND THAT 'ATA-B' IS SET.

E. ISSUE A DRIVE CLEAR COMMAND AND A READIN PRESET COMMAND THROUGH PORT 'B'.

F. VERIFY THAT THE DRIVE CANNOT BE ACCESSED THROUGH PORT 'A' AND 'NED' DOES NOT SET WHEN ATTEMPTING TO ACCESS THE DRIVE THROUGH PORT 'A'. ATTEMPT TO SET PORT REQUEST BY WRITING 0'S INTO RPDS1 THROUGH PORT 'A'.

G. ISSUE A RELEASE COMMAND THROUGH PORT 'B'. VERIFY THAT THE DRIVE REMAINS LOCKED ON PORT 'B'.

H. CYCLE THE DRIVE DOWN. CHANGE THE 'CONTROLLER SELECT' TO 'A/B'; CYCLE THE DRIVE UP.

I. VERIFY THAT BOTH PORTS CAN ACCESS THE DRIVE, THAT BOTH ATTENTION BITS ARE SET, AND THAT BOTH 'VV' BITS ARE RESET.

9. PROGRAM LISTING

3

.TITLE MD-11-DZRJF-A, RP04/5/6 DUAL CONTRLR LOGIC TEST - PART 2
: #COPYRIGHT (C) 1976
: #DIGITAL EQUIPMENT CORP.
: #MAYNARD, MASS. 01754
: #
: #PROGRAM BY C. HESS
: #

700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755

```

;#THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
;#PACKAGE (MAINDEC-11-DZQAC-C2), SEPT 14, 1976.
;#
    
```

.SBTTL OPERATIONAL SWITCH SETTINGS

```

;#
;# SWITCH USE
;# -----
;# 15 HALT ON ERROR
;# 14 LOOP ON TEST
;# 13 INHIBIT ERROR TYPEOUTS
;# 11 INHIBIT ITERATIONS
;# 10 BELL ON ERROR
;# 9 LOOP ON ERROR
    
```

.SBTTL BASIC DEFINITIONS

```

;#INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
STACK= 1100
.EQUIV ENT,ERROR ;;BASIC DEFINITION OF ERROR CALL
.EQUIV IOT,SCOPE ;;BASIC DEFINITION OF SCOPE CALL
    
```

;#MISCELLANEOUS DEFINITIONS

```

HT= 11 ;;CODE FOR HORIZONTAL TAB
LF= 12 ;;CODE FOR LINE FEED
CR= 15 ;;CODE FOR CARRIAGE RETURN
CRLF= 200 ;;CODE FOR CARRIAGE RETURN-LINE FEED
PS= 177776 ;;PROCESSOR STATUS WORD
.EQUIV PS,PSW
STKLMT= 177774 ;;STACK LIMIT REGISTER
PIRQ= 177772 ;;PROGRAM INTERRUPT REQUEST REGISTER
DSMR= 177570 ;;HARDWARE SWITCH REGISTER
DDISP= 177570 ;;HARDWARE DISPLAY REGISTER
    
```

;#GENERAL PURPOSE REGISTER DEFINITIONS

```

R0= %0 ;;GENERAL REGISTER
R1= %1 ;;GENERAL REGISTER
R2= %2 ;;GENERAL REGISTER
R3= %3 ;;GENERAL REGISTER
R4= %4 ;;GENERAL REGISTER
R5= %5 ;;GENERAL REGISTER
R6= %6 ;;GENERAL REGISTER
R7= %7 ;;GENERAL REGISTER
SP= %6 ;;STACK POINTER
PC= %7 ;;PROGRAM COUNTER
    
```

;#PRIORITY LEVEL DEFINITIONS

```

PR0= 0 ;;PRIORITY LEVEL 0
PR1= 40 ;;PRIORITY LEVEL 1
PR2= 100 ;;PRIORITY LEVEL 2
PR3= 140 ;;PRIORITY LEVEL 3
PR4= 200 ;;PRIORITY LEVEL 4
PR5= 240 ;;PRIORITY LEVEL 5
PR6= 300 ;;PRIORITY LEVEL 6
PR7= 340 ;;PRIORITY LEVEL 7
    
```

001100

000011
000012
000015
000200
177776
177774
177772
177570
177570

000000
000001
000002
000003
000004
000005
000006
000007
000006
000007

000000
000040
000100
000140
000200
000240
000300
000340

756
757
758 100000
759 040000
760 020000
761 010000
762 004000
763 002000
764 001000
765 000400
766 000200
767 000100
768 000040
769 000020
770 000010
771 000004
772 000002
773 000001
774
775
776
777
778
779
780
781
782
783
784
785
786 100000
787 040000
788 020000
789 010000
790 004000
791 002000
792 001000
793 000400
794 000200
795 000100
796 000040
797 000020
798 000010
799 000004
800 000002
801 000001
802
803
804
805
806
807
808
809
810
811

:"SWITCH REGISTER" SWITCH DEFINITIONS

SW15= 100000
SW14= 40000
SW13= 20000
SW12= 10000
SW11= 4000
SW10= 2000
SW09= 1000
SW08= 400
SW07= 200
SW06= 100
SW05= 40
SW04= 20
SW03= 10
SW02= 4
SW01= 2
SW00= 1
.EQUIV SW09,SW9
.EQUIV SW08,SW8
.EQUIV SW07,SW7
.EQUIV SW06,SW6
.EQUIV SW05,SW5
.EQUIV SW04,SW4
.EQUIV SW03,SW3
.EQUIV SW02,SW2
.EQUIV SW01,SW1
.EQUIV SW00,SW0

:"DATA BIT DEFINITIONS (BIT00 TO BIT15)

BIT15= 100000
BIT14= 40000
BIT13= 20000
BIT12= 10000
BIT11= 4000
BIT10= 2000
BIT09= 1000
BIT08= 400
BIT07= 200
BIT06= 100
BIT05= 40
BIT04= 20
BIT03= 10
BIT02= 4
BIT01= 2
BIT00= 1
.EQUIV BIT09,BIT9
.EQUIV BIT08,BIT8
.EQUIV BIT07,BIT7
.EQUIV BIT06,BIT6
.EQUIV BIT05,BIT5
.EQUIV BIT04,BIT4
.EQUIV BIT03,BIT3
.EQUIV BIT02,BIT2
.EQUIV BIT01,BIT1
.EQUIV BIT00,BIT0


```
812  
813  
814      000004  
815      000010  
816      000014  
817      000014  
818      000014  
819      000020  
820      000024  
821      000030  
822      000034  
823      000060  
824      000064  
825      000240  
826  
827  
828  
829  
830  
831  
832  
833  
834  
835      000100  
836      000200  
837      000400  
838      001000  
839      002000  
840      020000  
841      040000  
842      100000  
843  
844  
845  
846  
847  
848  
849  
850  
851  
852      000001  
853      000002  
854      000004  
855      000010  
856      000020  
857      000040  
858      000100  
859      000200  
860      000400  
861      001000  
862      002000  
863      004000  
864      010000  
865      020000  
866      040000  
867      100000
```

```
      ;#BASIC "CPU" TRAP VECTOR ADDRESSES  
ERRVEC= 4      ;: TIME OUT AND OTHER ERRORS  
RESVEC= 10     ;: RESERVED AND ILLEGAL INSTRUCTIONS  
TBITVEC=14     ;: "T" BIT  
TRTVEC= 14     ;: TRACE TRAP  
BPTVEC= 14     ;: BREAKPOINT TRAP (BPT)  
IOTVEC= 20     ;: INPUT/OUTPUT TRAP (IOT) **SCOPE**  
PMRVEC= 24     ;: POWER FAIL  
EMTVEC= 30     ;: EMULATOR TRAP (EMT) **ERROR**  
TRAPVEC=34     ;: "TRAP" TRAP  
TKVEC= 60      ;: TTY KEYBOARD VECTOR  
TPVEC= 64      ;: TTY PRINTER VECTOR  
PIRQVEC=240    ;: PROGRAM INTERRUPT REQUEST VECTOR  
  
;:*****  
  
.SBTTL RH11 REGISTERS  
  
;:*****  
  
;CONTROL AND STATUS REGISTER 1 (RPCS1)  
IE= 100      ;: INTERRUPT ENABLE (BIT #6)  
RDY= 200     ;: READY (BIT #7)  
A16= 400     ;: HIGH ORDER BUS ADDRESS BIT (BIT #8)  
A17= 1000    ;: HIGH ORDER BUS ADDRESS BIT (BIT #9)  
PSEL= 2000   ;: PORT SELECT (BIT #10)  
MCPE= 20000  ;: MASSBUS PARITY ERROR (BIT #13)  
TRE= 40000   ;: TRANSFER ERROR (BIT #14)  
SC= 100000   ;: SPECIAL CONDITION (BIT #15)  
  
;WORD COUNT REGISTER (RPWC)  
;(EACH BIT IS CALLED BY BIT NUMBER)  
  
;BUS ADDRESS REGISTER (RPBA)  
;(EACH BIT IS CALLED BY BIT NUMBER)  
  
;CONTROL AND STATUS REGISTER 2 (RPCS2)  
US1= 1        ;: UNIT SELECT (BIT #0)  
US2= 2        ;: UNIT SELECT (BIT #1)  
US4= 4        ;: UNIT SELECT (BIT #2)  
BAI= 10       ;: BUS ADDRESS INCREMENT INHIBIT (BIT #3)  
PAT= 20       ;: MASSBUS PARITY TEST (BIT #4)  
CLR= 40       ;: CLEAR (BIT #5)  
IR= 100       ;: INPUT READY (BIT #6)  
OR= 200       ;: OUTPUT READY (BIT #7)  
MPE= 400      ;: MASS BUS PARITY ERROR (BIT #8)  
MXF= 1000     ;: MISSED TRANSFER ERROR (BIT #9)  
PGE= 2000     ;: PROGRAM ERROR (BIT #10)  
NEM= 4000     ;: NON EXISTENT MEMORY (BIT #11)  
NED= 10000    ;: NON EXISTENT DRIVE (BIT #12)  
LPE= 20000    ;: UNIBUS PARITY ERROR (BIT #13)  
MCE= 40000    ;: WRITE CHECK ERROR (BIT #14)  
DLT= 100000   ;: DATA LATE (BIT #15)
```


868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923

000001
000002
000004
000010
000020
000040
004000

000002
000004
000010
000020
000040
000100
000200
000400
001000
002000
004000
010000
020000
040000
100000

000001
000002
000004
000010
000020
000040
000100
000200
000400
001000
002000
004000
010000
020000

;DATA BUFFER REGISTER (RPDB)
;(EACH BIT IS CALLED BY BIT NUMBER)

;;*****

.SBTTL RP04/5/6 REGISTERS

;;*****

;CONTROL AND STATUS 1 REGISTER. (#00)

GO= 1 ;GO BIT (BIT #0)
F1= 2 ;FUNCTION CODE BIT #1
F2= 4 ;FUNCTION CODE BIT #2
F3= 10 ;FUNCTION CODE BIT #3
F4= 20 ;FUNCTION CODE BIT #4
F5= 40 ;FUNCTION CODE BIT #5
DVA= 4000 ;DEVICE AVAILABLE (BIT #11)

;DRIVE STATUS REGISTER (RPOS1) (#01)

DFS= 1 ;DRIVE FORWARD 5"/SEC. (BIT #0)
DF20= 2 ;DRIVE FORWARD 20"/SEC. (BIT #1)
DIGB= 4 ;DRIVE TO INNER GUARD BAND (BIT #2)
GRV= 10 ;GO REVERSE (BIT #3)
DL64= 20 ;DIFFERENCE LESS THAN 64 (BIT #4)
DE1= 40 ;DIFFERENCE EQUALS 1 (BIT #5)
VV= 100 ;VOLUME VALID (BIT #6)
DRY= 200 ;DRIVE READY (BIT #7)
DPR= 400 ;DRIVE PRESENT (BIT #8)
PGM= 1000 ;PROGRAMABLE (BIT #9)
LST= 2000 ;LAST SECTOR TRANSFERRED (BIT #10)
WRL= 4000 ;WRITE LOCK (BIT #11)
MOL= 10000 ;MEDIUM ON-LINE (BIT #12)
PIP= 20000 ;POSITIONING OPERATION IN PROGRESS (BIT #13)
ERR= 40000 ;COMPOSITE ERROR (BIT #14)
ATA= 100000 ;ATTENTION ACTIVE (BIT #15)

;ERROR REGISTER #01 (RPER1) (#02)

ILF= 1 ;ILLEGAL FUNCTION (BIT #0)
ILR= 2 ;ILLEGAL REGISTER (BIT #1)
RMR= 4 ;REGISTER MODIFICATION REFUSED (BIT #2)
PAR= 10 ;PARITY ERROR (BIT #3)
FER= 20 ;FORMAT ERROR (BIT #4)
WCF= 40 ;WRITE CLOCK FAIL (BIT #5)
ECH= 100 ;ECC HARD ERROR (BIT #6)
HCE= 200 ;HEADER COMPARE ERROR (BIT #7)
HCRC= 400 ;HEADER CRC ERROR (BIT #8)
AOE= 1000 ;ADDRESS OVERFLOW ERROR (BIT #9)
IAE= 2000 ;INVALID ADDRESS ERROR (BIT #10)
WLE= 4000 ;WRITE LOCK ERROR (BIT #11)
DTE= 10000 ;DRIVE TIMING ERROR (BIT #12)
OPI= 20000 ;OPERATION INCOMPLETE (BIT #13)

924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
970
971
972
973
974
975
976
977
978
979

040000
100000

000001
000002
000004
000010
000020
000040
000200

000001
000002
000004
000010
000020
000040
000100
000200

000001
000002
000004
000010
000020
000040
000100
000200
000400
004000
020000
040000
100000

000001
000002
000004
000010
000020
000040
000100
000200
000400
000200
001000
002000

UNS= 40000 ;DRIVE UNSAFE (BIT #14)
DCK= 100000 ;DATA CHECK ERROR (BIT 15)

;MAINTAINABILITY REGISTER (RPMR)(#03)
DMD= 1 ;DIAGINOSTIC MODE (BIT #0)
MCLK= 2 ;MAINTAINABILITY CLOCK (BIT #1)
MINX= 4 ;MAINTAINABILITY INDEX (BIT #2)
MSTCK= 10 ;MAINTAINABILITY SECTOR CLOCK (BIT #3)
MRD= 20 ;MAINTAINABILITY READ (BIT #4)
MWR= 40 ;MAINTAINABILITY WRITE (BIT #5)
DTSY= 200 ;MAINTAINABILITY SYNC DETECTED (BIT #7)

;ATTENTION SUMMARY PSEUDO-REGISTER (RPAS) (#04)
AT0= 1 ;DEVICE 0 (BIT #0)
AT1= 2 ;DEVICE 1 (BIT #1)
AT2= 4 ;DEVICE 2 (BIT #2)
AT3= 10 ;DEVICE 3 (BIT #3)
AT4= 20 ;DEVICE 4 (BIT #4)
AT5= 40 ;DEVICE 5 (BIT #5)
AT6= 100 ;DEVICE 6 (BIT #6)
AT7= 200 ;DEVICE 7 (BIT #7)

;DESIRED SECTOR/TRACK ADDRESS REGISTER (RPDA) (#05)
;(EACH BIT IS CALLED BY BIT NUMBER)

;DRIVE TYPE REGISTER (RPDT) (#06)
DT00= 1 ;DRIVE TYPE NUMBER BIT 1
DT01= 2 ;DRIVE TYPE NUMBER BIT 2
DT02= 4 ;DRIVE TYPE NUMBER BIT 3
DT03= 10 ;DRIVE TYPE NUMBER BIT 4
DT04= 20 ;DRIVE TYPE NUMBER BIT 5
DT05= 40 ;DRIVE TYPE NUMBER BIT 6
DT06= 100 ;DRIVE TYPE NUMBER BIT 7
DT07= 200 ;DRIVE TYPE NUMBER BIT 8
DT08= 400 ;DRIVE TYPE NUMBER BIT 9
DRQ= 4000 ;DRIVE REQUEST REQUIRED (BIT #11)
MOH= 20000 ;MOVING HEAD (BIT #13)
TAP= 40000 ;TAPE DRIVE (BIT #14)
NBA= 100000 ;NOT BLOCK ADDRESSED (BIT #15)

;LOOK-AHEAD REGISTER (RPLA) (#07)
EXT1= 1 ;EXTENSION 1 (BIT #0)
EXT2= 2 ;EXTENSION 2 (BIT #1)
EXT4= 4 ;EXTENSION 3 (BIT #2)
EXT10= 10 ;EXTENSION 4 (BIT #3)
EXT20= 20 ;EXTENSION 5 (BIT #4)
EXT40= 40 ;EXTENSION 6 (BIT #5)
SC1= 100 ;SECTOR COUNT FIELD 0 (BIT #6)
SC2= 200 ;SECTOR COUNT FIELD 1 (BIT #7)
SC4= 400 ;SECTOR COUNT FIELD 2 (BIT #8)
SC10= 1000 ;SECTOR COUNT FIELD 3 (BIT #9)
SC20= 2000 ;SECTOR COUNT FIELD 4 (BIT #10)

MD-11-DZRJF-A, RP04/5/6 DUAL CONTRLR LOGIC TEST - PART 2
DZRJFA.CMB 02-NOV-76 19:11 RP04/5/6 REGISTERS

```

980      004000      TRK1=  4000      ; TRACK FIELD 1 (BIT #11)
981      010000      TRK2= 10000      ; TRACK FIELD 2 (BIT #12)
982      020000      TRK4= 20000      ; TRACK FIELD 3 (BIT #13)
983      040000      TRK10= 40000     ; TRACK FIELD 4 (BIT #14)
984      100000      TRK20= 100000    ; TRACK FIELD 5 (BIT #15)
985
986      ;RP04 ERROR REGISTER #2 (RPER2) (#10)
987
988      000001      WCU=  1      ; WRITE CURRENT UNSAFE (BIT #0)
989      000002      CSF=  2      ; CURRENT SINK FAILURE (BIT #1)
990      000004      WSU=  4      ; WRITE SELECT UNSAFE (BIT #2)
991      000010      CSU= 10      ; CURRENT SWITCH UNSAFE (BIT #3)
992      000020      MSE= 20      ; MOTOR SEQUENCE ERROR (BIT #4)
993      000040      TDF= 40      ; TRANSITIONS DETECTOR FAILURE (BIT #5)
994      000100      TUF= 100     ; TRANSITIONS UNSAFE (BIT #6)
995      000200      FEN= 200     ; FAILSAFE ENABLED (BIT #7)
996      000400      WRU= 400     ; WRITE READY UNSAFE (BIT #8)
997      001000      MHS= 1000    ; MULTIPLE HEAD SELECT (BIT #9)
998      002000      NHS= 2000    ; NO HEAD SELECTION (BIT #10)
999      004000      IXE= 4000    ; INDEX ERROR (BIT #11)
1000     010000      VU30= 10000   ; 30VOLT UNSAFE (BIT #12)
1001     020000      PLU= 20000   ; PLO UNSAFE (BIT #13)
1002     100000      ACU= 100000  ; AC UNSAFE (BIT #15)
1003
1004     ;RP05/6 ERROR REGISTER #02 (RPER2) (#10)
1005
1006     000001      WCU=  1      ; WRITE CURRENT UNSAFE (BIT #0)
1007     000002      CSF=  2      ; CURRENT SINK FAILURE (BIT #1)
1008     000004      WSU=  4      ; WRITE SELECT UNSAFE (BIT #2)
1009     000010      CSU= 10      ; CURRENT SWITCH UNSAFE (BIT #3)
1010     000020      RAW= 20      ; READ AND WRITE (BIT #4)
1011     000040      TDF= 40      ; TRANSITIONS DETECTOR FAILURE (BIT #5)
1012     000100      TUF= 100     ; TRANSITIONS UNSAFE (BIT #6)
1013     000200      ABS= 200     ; ABNORMAL STOP (BIT #7)
1014     000400      WRU= 400     ; WRITE READY UNSAFE (BIT #8)
1015     001000      MHS= 1000    ; MULTIPLE HEAD SELECT (BIT #9)
1016     002000      NHS= 2000    ; NO HEAD SELECTION (BIT #10)
1017     004000      IXE= 4000    ; INDEX ERROR (BIT #11)
1018     020000      PLU= 20000   ; PLO UNSAFE (BIT #12)
1019
1020     ;OFFSET REGISTER (RPOF) (#11)
1021
1022     000001      OF25=  1      ; OFFSET 25 MICRO INCHES (BIT #0)
1023     000002      OF50=  2      ; OFFSET 50 MICRO INCHES (BIT #1)
1024     000004      OF100= 4      ; OFFSET 100 MICRO INCHES (BIT #2)
1025     000010      OF200= 10     ; OFFSET 200 MICRO INCHES (BIT #3)
1026     000020      OF400= 20     ; OFFSET 400 MICRO INCHES (BIT #4)
1027     000040      OF800= 40     ; OFFSET 800 MICRO INCHES (BIT #5)
1028     000200      OFREV= 200    ; OFFSET NEGATIVE (REVERSE) (BIT #5)
1029     002000      HCI=  2000    ; HEADER COMPARE INHIBIT (BIT #10)
1030     004000      ECI=  4000    ; ERROR CORRECTION CODE INHIBIT (BIT #11)
1031     010000      FMT22= 10000   ; FORMAT BIT (BIT #12)
1032
1033     ;DESIRED CYLINDER ADDRESS (RPCA) (#12)
1034     ;(EACH BIT IS CALLED BY BIT NUMBER)
1035

```



```

1036 ;CURRENT CYLINDER ADDRESS (RPCC) (#13)
1037 ;(EACH BIT IS CALLED BY BIT NUMBER)
1038
1039 ;SERIAL NUMBER REGISTER (RPSN) (#14)
1040 ;(EACH IS CALLED BY BIT NUMBER)
1041
1042 ;RPO4 ERROR REGISTER #03 (RPER3) (#15)
1043
1044 000001 PSU= 1 ;PACK SPEED UNSAFE (BIT #0)
1045 000002 VUF= 2 ;VELOCITY UNSAFE (BIT #1)
1046 000010 UMR= 10 ;ANY UNSAFE EXCEPT READ/WRITE (BIT #3)
1047 000040 ACL= 40 ;AC LOW (BIT #5)
1048 000100 DCL= 100 ;DC LOW (BIT #6)
1049 040000 SKI= 40000 ;SEEK INCOMPLETE (BIT #14)
1050 100100 OCYL= 100000 ;OFF CYLINDER (BIT #15)
1051
1052 ;RPO5/6 ERROR REGISTER #03 (RPER3) (#15)
1053
1054 000001 DCU= 1 ;DC UNSAFE (BIT #0)
1055 000002 WAO= 2 ;WRITE AND OFFSET (BIT #1)
1056 000040 ACL= 40 ;AC LOW (BIT #5)
1057 000100 DCL= 100 ;DC LOW (BIT #6)
1058 020000 OPE= 20000 ;OPERATOR PLUG ERROR (BIT #13)
1059 040000 SKI= 40000 ;SEEK INCOMPLETE (BIT #14)
1060 100000 OCYL= 100000 ;OFF CYLINDER ERROR (BIT #15)
1061
1062 ;ECC POSITION REGISTER (RPEC1) (#16)
1063 ;(EACH BIT IS CALLED BY BIT NUMBER)
1064
1065 ;ECC PATTERN REGISTER (RPEC2) (#17)
1066 ;(EACH BIT IS CALLED BY BIT NUMBER)
1067
1068 ;*****
1069
1070 .SBTTL DEFINITIONS OF THE RH11/RPO4/5/6 ADDRESS INDEXES
1071
1072 ;*****
1073
1074 000000 RPCS1=0 ;CONTROL AND STATUS REGISTER #1 (DRIVE REG. 00)
1075 000002 RPWC=2 ;WORD COUNT REGISTER (NOT A DRIVE REG)
1076 000004 RPBA=4 ;UNIBUS ADDRESS REGISTER (NOT A DRIVE REG)
1077 000006 RPDA=6 ;DESIRED SECTOR/TRACK ADDRESS REGISTER (DRIVE REG. 05)
1078 000010 RPCS2=10 ;CONTROL AND STATUS REGISTER #2 (NOT A DRIVE REG)
1079 000012 RPDS1=12 ;DRIVE STATUS REGISTER (DRIVE REG 01)
1080 000014 RPER1=14 ;ERROR REGISTER #1 (DRIVE REG. 02)
1081 000016 RPAS=16 ;ATTENTION SUMMARY PSEUDO REGISTER (DRIVE REG. 04)
1082 000020 RPLA=20 ;LOOK AHEAD REGISTER (DRIVE REG. 07)
1083 000022 RPDB=22 ;DATA BUFFER REGISTER (NOT A DRIVE REG.)
1084 000024 RPMR=24 ;MAINTAINABILITY REGISTER (DRIVE REG. 03)
1085 000026 RPDT=26 ;DRIVE TYPE REGISTER (DRIVE REG. 06)
1086 000030 RPSN=30 ;SERIAL NUMBER REGISTER (DRIVE REG. 10)
1087 000032 RPOF=32 ;OFFSET REGISTER (DRIVE REG. 11)
1088 000034 RPCA=34 ;DESIRED CYLINDER ADDRESS REGISTER (DRIVE REG. 12)
1089 000036 RPCC=36 ;CURRENT CYLINDER ADDRESS REGISTER (DRIVE REG. 13)
1090 000040 RPER2=40 ;ERROR REGISTER #2 (DRIVE REG. 14)
1091 000042 RPER3=42 ;ERROR REGISTER #3 (DRIVE REG. 15)

```


DEFINITIONS OF THE RH11/RPO4/5/6 ADDRESS INDEXES

```

1092          000044      RPEC1=44          ;ECC POSITION REGISTER (DRIVE REG. 16)
1093          000046      RPEC2=46          ;ECC PATTERN REGISTER (DRIVE REG. 17)
1094
1095          .SBTTL TRAP CATCHER
1096
1097          000000
1098          ;=0
1099          ;#ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
1100          ;#SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
1101          ;#LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
1102          000174      000174      ;=174
1103          000176      000000      DISPREG: .WORD 0          ;;SOFTWARE DISPLAY REGISTER
1104          000176      000000      SWREG:   .WORD 0          ;;SOFTWARE SWITCH REGISTER
1105
1106          .SBTTL ACT11 HOOKS
1107
1108          ;*****
1109          ;HOOKS REQUIRED BY ACT11
1110          000200      000046      $SVPC=.          ;SAVE PC
1111          000046      017724      .=46            SENDAD          ;;1)SET LOC.46 TO ADDRESS OF SENDAD IN .SEOP
1112          000052      000052      .=52
1113          000052      020000      .WORD 20000    ;;2)SET LOC.52 TO 20000
1114          000200      000200      .=$SVPC        ;; RESTORE PC
1115
1116          .SBTTL STARTING ADDRESS = 200
1117
1118          000200      000137      001706      JMP START          ;START THE PROGRAM
1119
1120          .SBTTL START THE PROGRAM AND CHANGE THE RH11 ADDRESS = 204
1121
1122          000204      000137      001714      JMP START1         ;START AND CHANGE THE RH11 ADDRESS
1123
1124

```


COMMON TAGS

.SBTTL COMMON TAGS

```

1125
1126
1127
1128
1129
1130
1131      001100
1132 001100 000000
1133 001100 000000
1134 001102 000
1135 001103 000
1136 001104 000000
1137 001106 000000
1138 001110 000000
1139 001112 000000
1140 001114 000
1141 001115 001
1142 001116 000000
1143 001120 000000
1144 001122 000000
1145 001124 000000
1146 001126 000000
1147 001130 000000
1148 001132 000000
1149 001134 000
1150 001135 000
1151 001136 000000
1152 001140 177570
1153 001142 177570
1154 001144 177560
1155 001146 177562
1156 001150 177564
1157 001152 177566
1158 001154 000
1159 001155 002
1160 001156 012
1161 001157 000
1162 001160 000000
1163
1164 001162 000000
1165 001164 000000
1166 001166 000000
1167 001170 000000
1168 001172 000000
1169 001174 000000
1170 001176 000000
1171 001200 000000
1172 001202 177607 000377
1173 001206 077
1174 001207 015
1175 001210 000012
1176
1177      000015
1178      000012
1179 001212 172540
1180 001214 172542

```

```

*****
*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
*USED IN THE PROGRAM.

```

. = 1100

```

SCMTAG:      .WORD      0
SPASS:       .BYTE      00
STSTNM:      .BYTE      00
SERFLG:      .BYTE      00
SICNT:       .WORD      00
SLPADR:      .WORD      00
SLPERR:      .WORD      00
SERTTL:      .WORD      00
SITEMB:      .BYTE      00
SERMAX:      .BYTE      1
SERRPC:      .WORD      00
SGDADR:      .WORD      00
SBDADR:      .WORD      00
SGDDAT:      .WORD      00
SBDDAT:      .WORD      00
SAUTOB:      .BYTE      00
SINTAG:      .BYTE      00
SWR:         .WORD      DSWR
DISPLAY:     .WORD      DDISP
STKS:        177560
STKB:        177562
STPS:        177564
STPB:        177566
SNLL:        .BYTE      0
SFILLS:      .BYTE      2
SFILLC:      .BYTE      12
STPFLG:      .BYTE      0
SREGAD:      .WORD      0
SREGO:       .WORD      0
STMP0:       .WORD      0
STMP1:       .WORD      0
STMP2:       .WORD      0
STMP3:       .WORD      0
STMP4:       .WORD      0
STIMES:      0
SESCAPE:     0
SBELL:       .ASCIZ    <207><377><377>
SQUES:       .ASCII    /?/
SCRLF:       .ASCII    <15>
SLF:         .ASCIZ    <12>
CA           =          15
LF           =          12
SLKCSR:      .WORD      172540
SLKCSB:      .WORD      172542

```

```

: START OF COMMON TAGS
: CONTAINS PASS COUNT
: CONTAINS THE TEST NUMBER
: CONTAINS ERROR FLAG
: CONTAINS SUBTEST ITERATION COUNT
: CONTAINS SCOPE LOOP ADDRESS
: CONTAINS SCOPE RETURN FOR ERRORS
: CONTAINS TOTAL ERRORS DETECTED
: CONTAINS ITEM CONTROL BYTE
: CONTAINS MAX. ERRORS PER TEST
: CONTAINS PC OF LAST ERROR INSTRUCTION
: CONTAINS ADDRESS OF 'GOOD' DATA
: CONTAINS ADDRESS OF 'BAD' DATA
: CONTAINS 'GOOD' DATA
: CONTAINS 'BAD' DATA
: RESERVED--NOT TO BE USED

: AUTOMATIC MODE INDICATOR
: INTERRUPT MODE INDICATOR

: ADDRESS OF SWITCH REGISTER
: ADDRESS OF DISPLAY REGISTER
: TTY KBD STATUS
: TTY KBD BUFFER
: TTY/PRINTER STATUS REG. ADDRESS
: TTY PRINTER BUFFER REG. ADDRESS
: CONTAINS NULL CHARACTER FOR FILLS
: CONTAINS # OF FILLER CHARACTERS REQUIRED
: INSERT FILL CHARS. AFTER A "LINE FEED"
: "TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
: CONTAINS THE ADDRESS FROM
: WHICH (SREGO) WAS OBTAINED
: CONTAINS ((SREGAD)+0)
: USER DEFINED
: USER DEFINED
: USER DEFINED
: USER DEFINED
: USER DEFINED
: MAX. NUMBER OF ITERATIONS
: ESCAPE ON ERROR ADDRESS
: CODE FOR BELL
: QUESTION MARK
: CARRIAGE RETURN
: LINE FEED

*****

: ADDR OF KW11-P STATUS REGISTER
: ADDR OF KW11-P COUNTER BUFFER

```



```

1181 001216 000104      $L/VEC: .WORD 104      ; ADDR OF KW11-P VECTOR
1182 001220 177546      $LKS: .WORD 177546    ; ADDR OF KW11-L STATUS REGISTER
1183 001222 000100      $LLVEC: .WORD 100    ; ADDR OF KW11-L VECTOR
1184 001224 000000      PORTA: .WORD 0       ; ADDRESS OF PORT A
1185 001226 000000      PORTB: .WORD 0       ; ADDRESS OF PORT B
1186 001230 000000      PORTC: .WORD 0       ; ADDRESS OF DIFFERENT DRIVE
1187 001232 000000      ASR1: .WORD 0        ; ATA-A OR ATA-B = 1
1188 001234 000000      PTNBR: .WORD 0       ; CONTAINS THE PORT ADDRESS FOR ERROR TYPEOUTS
1189 001236 000000      SEIZPT: .WORD 0      ; CONTAINS THE ADDRESS OF THE SEIZING PORT
1190 001240 000000      OPPRT: .WORD 0       ; CONTAINS THE ADDRESS OF THE 'OPPOSITE' PORT
1191 001242 000000      TSTNUM: .WORD 0      ; NUMBER OF THE CURRENT TEST
1192 001244 000000      CKERR: .WORD 0       ; IF -1, A REGISTER MISCOMPARISON OCCURRED
1193 001246 000000      NOSEIZ: .WORD 0     ; IF -1, THE PORT IN 'SEIZPT' DID NOT SEIZE THE DRIVE
1194 001250 000000      RELERR: .WORD 0     ; IF -1, THE PORT IN 'SEIZPT' DID NOT RELEASE THE DRIVE
1195 001252 000000      TIME: .WORD 0       ; ELAPSED TIME COUNTER
1196 001254 000000      WATCH: .WORD 0     ; WATCH DOG TIMER LOCATION
1197 001256 000000      TIMEA: .WORD 0     ; THE TIMEOUT ONE-SHOT VALUE MEASURED THROUGH PORT A
1198 001260 000000      TIMEAP: .WORD 0    ; PORT A TIMEOUT VALUE + 25%
1199 001262 000000      TIMEB: .WORD 0     ; THE TIMEOUT ONE-SHOT VALUE MEASURED THROUGH PORT B
1200 001264 000000      TIMEBP: .WORD 0    ; PORT B TIMEOUT VALUE + 25%
1201 001266 000000      KYBCTL: .WORD 0    ; SINGLE TEST INDICATOR
1202 001270 000000      CHGADR: .WORD 0    ; CHANGE THE R'11 ADDRESS INDICATOR
1203
1204      ;;*****
1205      .SBTTL RH11/RP04/5/6 UNIBUS AND VECTOR ADDRESSES
1206
1207      ;;*****
1208
1209
1210 001272 176700      SRPADR: .WORD 176700 ; RH11/RP04/5/6 UNIBUS ADDRESS
1211 001274 000254      SRPVEC: .WORD 254   ; RH11 INTERRUPT VECTOR ADDRESS
1212

```


1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268

.SBTTL ERROR POINTER TABLE

;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
 ;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
 ;*LOCATION SITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
 ;*NOTE1: IF SITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
 ;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;* EM ;;POINTS TO THE ERROR MESSAGE
 ;* DH ;;POINTS TO THE DATA HEADER
 ;* DT ;;POINTS TO THE DATA
 ;* DF ;;POINTS TO THE DATA FORMAT

SERRTB:

;ERROR 1

EM1 ;DRIVE IS NON-EXISTENT ('NED' BIT SET)
 DH1
 DT1
 DF1

;ERROR 2

EM2 ;WRONG DRIVE TYPE
 DH2
 DT2
 DF2

;ERROR 3

EM3 ;CONTROLLER SELECT SWITCH ON DRIVE NOT IN 'A/B'
 DH1
 DT1
 DF1

;ERROR 4

EM4 ;DRIVE NOT ON LINE
 DH2
 DT2
 DF2

;ERROR 5

EM5 ;SERIAL NUMBER READ THROUGH EACH PORT NOT THE SAME
 DH5
 DT5
 DF5

;ERROR 6

EM6 ;TIMEOUT HAS NOT OCCURRED WITHIN 2 SECONDS
 DH6

001276

001276 024457
001300 027227
001302 030610
001304 031030

001306 024525
001310 027300
001312 030624
001314 031035

001316 024546
001320 027227
001322 030610
001324 031030

001326 024625
001330 027300
001332 030624
001334 031035

001336 024647
001340 027354
001342 030642
001344 031043

001346 024731
001350 027423

MD-11-DZRJF-A, RPO4/S/6 DUAL CONTRLR LOGIC TEST - PART 2
 DZRJFA.CMB 02-NOV-76 19:11 ERROR POINTER TABLE

1269	001352	030656	DT6	
1270	001354	031050	DF6	
1271				
1272				;ERROR 7
1273				
1274	001356	025003	EM7	;TIMEOUT ONE-SHOT IS LESS THAN 500 MS
1275	001360	027452	DH7	
1276	001362	030666	DT7	
1277	001364	031053	DF7	
1278				
1279				;ERROR 10
1280				
1281	001366	025050	EM10	;READIN PRESET DOES NOT SET VOLUME VALID FOR THE PORT
1282	001370	027227	DH1	
1283	001372	030610	DT1	
1284	001374	031030	DF1	
1285				
1286				;ERROR 11
1287				
1288	001376	025135	EM11	; 'GO' BIT RESET DURING UNLOAD COMMAND
1289	001400	027227	DH1	
1290	001402	030610	DT1	
1291	001404	031030	DF1	
1292				
1293				;ERROR 12
1294				
1295	001406	025202	EM12	; INCORRECT STATUS DURING UNLOAD COMMAND
1296	001410	027227	DH1	
1297	001412	030610	DT1	
1298	001414	031030	DF1	
1299				
1300				;ERROR 13
1301				
1302	001416	025251	EM13	;DRIVE DID NOT RETURN TO NEUTRAL AFTER UNLOAD COMMAND
1303	001420	027517	DH13	
1304	001422	030700	DT13	
1305	001424	031050	DF6	
1306				
1307				;ERROR 14
1308				
1309	001426	025336	EM14	;ATTENTION BIT SET ON 'OPPOSITE PORT' AFTER UNLOAD
1310	001430	027575	DH14	
1311	001432	030710	DT14	
1312	001434	031057	DF14	
1313				
1314				;ERROR 15
1315				
1316	001436	025420	EM15	;ATTENTION BIT NOT SET ON PORT WHICH ISSUED 'UNLOAD'
1317	001440	027227	DH1	
1318	001442	030610	DT1	
1319	001444	031030	DF1	
1320				
1321				;ERROR 16
1322				
1323	001446	025504	EM16	;DRIVE NOT IN NEUTRAL AFTER UNLOAD WITH 'CONTROLLER ;SELECT' SWITCH MOVED FROM 'A/B'
1324				

1325	001450	027517	DH13	
1326	001452	030700	DT13	
1327	001454	031050	DF6	
1328				;ERROR 17
1329				
1330	001456	025630	EM17	;DRIVE LOCKED ON PORT 'A' BY SWITCH WHILE CYCLED UP
1331	001460	027715	DH17	
1332	001462	030726	DT17	
1333	001464	031065	DF17	
1334				
1335				;ERROR 20
1336				
1337	001466	025713	EM20	;DRIVE LOCKED ON PORT 'B' BY SWITCH WHILE CYCLED UP
1338	001470	027715	DH17	
1339	001472	030726	DT17	
1340	001474	031065	DF17	
1341				
1342				;ERROR 21
1343				
1344	001476	025776	EM21	;STATUS INCORRECT FOR PORT AFTER CYCLE UP
1345	001500	027227	DH1	
1346	001502	030610	DT1	
1347	001504	031030	DF1	
1348				
1349				;ERROR 22
1350				
1351	001506	026047	EM22	;REGISTER CONTENTS SEEN WHEN DRIVE SWITCHED ON 'OPPOSITE' PORT
1352	001510	027227	DH1	
1353	001512	030610	DT1	
1354	001514	031030	DF1	
1355				
1356				;ERROR 23
1357				
1358	001516	026145	EM23	; 'NED' SET WHEN RPDS1 ACCESSED THROUGH PORT NOT SWITCHED
1359	001520	027227	DH1	
1360	001522	030610	DT1	
1361	001524	031030	DF1	
1362				
1363				;ERROR 24
1364				
1365	001526	026235	EM24	;DRIVE SWITCHED TO LOCKED OUT PORT WHEN RELEASED/
1366	001530	027734	DH24	
1367	001532	030734	DT24	
1368	001534	031053	DF7	
1369				
1370				;ERROR 25
1371				
1372	001536	026315	EM25	;RH11 DIDN'T RESPOND TO ADDRESSING
1373	001540	030040	DH25	
1374	001542	030746	DT25	
1375	001544	031067	DF25	
1376				
1377				;ERROR 26
1378				
1379	001546	000000	0	;UNUSED ERROR MESSAGES
1380	001550	000000	0	

1381	001552	000000	0	
1382	001554	000000	0	
1383				
1384				;ERROR 27
1385				
1386	001556	000000	0	;UNUSED ERROR MESSAGES
1387	001560	000000	0	
1388	001562	000000	0	
1389	001564	000000	0	
1390				
1391				;ERROR 30
1392				
1393	001566	026357	EM30	;DRIVE NOT SEIZED BY PORT 'N'
1394	001570	030047	DH30	
1395	001572	030752	DT30	
1396	001574	031070	DF30	
1397				
1398				;ERROR 31
1399				
1400	001576	026410	EM31	;WRONG STATUS SEEN BY THE SEIZING PORT
1401	001600	027300	DH2	
1402	001602	030624	DT2	
1403	001604	031035	DF2	
1404				
1405				;ERROR 32
1406				
1407	001606	026456	EM32	;REGISTER CONTENTS INCORRECT
1408	001610	027300	DH2	
1409	001612	030624	DT2	
1410	001614	031035	DF2	
1411				
1412				;ERROR 33
1413				
1414	001616	026506	EM33	;CONTROL BUS PARITY ERROR WHILE READING REGISTER
1415	001620	027227	DH1	
1416	001622	030610	DT1	
1417	001624	031030	DF1	
1418				
1419				;ERROR 34
1420				
1421	001626	026572	EM34	;CAN'T ACCESS DRIVE THROUGH EITHER PORT
1422	001630	030172	DH34	
1423	001632	030772	DT34	
1424	001634	031077	DF34	
1425				
1426				;ERROR 35
1427				
1428	001636	026641	EM35	;DRIVE NOT IN NEUTRAL AFTER RELEASE, REQUEST NOT SET
1429	001640	030270	DH35	
1430	001642	031004	DT35	
1431	001644	031053	DF7	
1432				
1433				;ERROR 36
1434				
1435	001646	026726	EM36	;DRIVE NOT IN NEUTRAL AFTER TIMEOUT, REQUEST NOT SET
1436	001650	030270	DH35	

1437	001652	031004	DT35	
1438	001654	031053	DF7	
1439				
1440				;ERROR 37
1441				
1442	001656	027013	EM37	;REGISTER CONTENTS INCORRECT AFTER RELEASE/TIMEOUT
1443	001660	030366	DH37	
1444	001662	030752	DT30	
1445	001664	031070	DF30	
1446				
1447				;ERROR 40
1448				
1449	001666	027074	EM40	;DRIVE NOT SEIZED BY PORT AFTER RELEASE WITH REQUEST SET
1450	001670	030511	DH40	
1451	001672	031016	DT40	
1452	001674	031053	DF7	
1453				
1454				;ERROR 41
1455				
1456	001676	027151	EM41	;REGISTER WRONG AFTER RELEASE WITH REQUEST SET
1457	001700	030047	DH30	
1458	001702	030752	DT30	
1459	001704	031070	DF30	

```

1460
1461
1462
1463
1464
1465
1466
1467
1468
1469
1470 001706 005037 001270 START: CLR CHGADR ;CLEAR THE 'CHANGE RH11 ADDRESS' INDICATOR
1471 001712 000403 BR START2 ;GO TO THE START
1472 001714 012737 177777 001270 START1: MOV #-1,CHGADR ;SET THE 'CHANGE RH11 ADDRESS' INDICATOR
1473 001722 000005 START2: RESET ;CLEAR THE BUS
1474 .SBTTL INITIALIZE THE COMMON TAGS
1475 ;;CLEAR THE COMMON TAGS (SCNTAG) AREA
1476 001724 012706 001100 MOV #SCNTAG,R6 ;FIRST LOCATION TO BE CLEARED
1477 001730 005026 CLR (R6)+ ;CLEAR MEMORY LOCATION
1478 001732 022706 001140 CMP #SMR,R6 ;;DONE?
1479 001736 001374 BNE -6 ;LOOP BACK IF NO
1480 001740 012706 001100 MOV #STACK_SP ;SETUP THE STACK POINTER
1481 ;;INITIALIZE A FEW VECTORS
1482 001744 012737 020156 000020 MOV #SSCOPE,#IOTVEC ;IOT VECTOR FOR SCOPE ROUTINE
1483 001752 012737 000340 000022 MOV #340,#IOTVEC+2 ;LEVEL 7
1484 001760 012737 020340 000030 MOV #ERROR,#EMTVEC ;EMT VECTOR FOR ERROR ROUTINE
1485 001766 012737 000340 000032 MOV #340,#EMTVEC+2 ;LEVEL 7
1486 001774 012737 023140 000034 MOV #STRAP,#TRAPVEC ;TRAP VECTOR FOR TRAP CALLS
1487 002002 012737 000340 000036 MOV #340,#TRAPVEC+2 ;LEVEL 7
1488 002010 013737 017570 017562 MOV SENDCT,SEOPCT ;SETUP END-OF-PROGRAM COUNTER
1489 002016 005037 001176 CLR STIMES ;INITIALIZE NUMBER OF ITERATIONS
1490 002022 005037 001200 CLR SESCAPE ;CLEAR THE ESCAPE ON ERROR ADDRESS
1491 002026 112737 000001 001115 MOVB #1,SERMAX ;ALLOW ONE ERROR PER TEST
1492 002034 012737 002034 001106 MOV #.,SLPADR ;INITIALIZE THE LOOP ADDRESS FOR SCOPE

```


1493	002042	012737	002042	001110		MOV	#, \$LPERR	:: SETUP THE ERROR LOOP ADDRESS
1494								:: SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
1495								:: EQUAL TO A "-1" SETUP FOR A SOFTWARE SWITCH REGISTER.
1496	002050	013746	000004			MOV	\$ERRVEC, -(SP)	:: SAVE ERROR VECTOR
1497	002054	012737	002110	000004		MOV	\$65\$, \$ERRVEC	:: SET UP ERROR VECTOR
1498	002062	012737	177570	001140		MOV	\$DSMR, SMR	:: SETUP FOR A HARDWARE SWICH REGISTER
1499	002070	012737	177570	001142		MOV	\$DDISP, DISPLAY	:: AND A HARDWARE DISPLAY REGISTER
1500	002076	022777	177777	177034		CMP	\$-1, \$SMR	:: TRY TO REFERENCE HARDWARE SMR
1501	002104	001012				BNE	\$65\$:: BRANCH IF NO TIMEOUT TRAP OCCURRED
1502								:: AND THE HARDWARE SMR IS NOT = -1
1503	002106	000403				BR	\$65\$:: BRANCH IF NO TIMEOUT
1504	002110	012716	002116		64\$:	MOV	\$65\$, (SP)	:: SET UP FOR TRAP RETURN
1505	002114	000002				RTI		
1506	002116	012737	000176	001140	65\$:	MOV	\$SMREG, SMR	:: POINT TO SOFTWARE SMR
1507	002124	012737	000174	001142		MOV	\$DISPREG, DISPLAY	
1508	002132	012637	000004		66\$:	MOV	(SP)+, \$ERRVEC	:: RESTORE ERROR VECTOR
1509								
1510	002136	005227	177777			INC	\$-1	:: FIRST START ?
1511	002142	001002				BNE	\$:: BR IF NOT
1512	002144	104401	023226			TYPE	TITLE	:: TYPE PROGRAM NAME
1513	002150	004737	021550		1\$:	JSR	PC, \$TKINT	:: SETUP THE TTY KEYBOARD
1514					.SBTTL	GET	VALUE FOR SOFTWARE SWITCH REGISTER	
1515	002154	005737	000042			TST	\$42	:: ARE WE RUNNING UNDER XDP/ACT?
1516	002160	001006				BNE	\$7\$:: BRANCH IF YES
1517	002162	023727	001140	000176		CMP	\$SMR, \$SMREG	:: SOFTWARE SWITCH REG SELECTED?
1518	002170	001005				BNE	\$68\$:: BRANCH IF NO
1519	002172	104406				GTSMR		:: GET SOFT-SMR SETTINGS
1520	002174	000403				BR	\$68\$	
1521	002176	112737	000001	001134	67\$:	MOV	\$1, \$AUTOB	:: SET AUTO-MODE INDICATOR
1522	002204				68\$:			
1523	002204	004737	002576			JSR	PC, CHANGE	:: CHECK/CHANGE THE RH11 ADDRESS
1524	002210	104401	023335			TYPE	, ENTERA	:: ENTER DRIVE ADDRESS
1525	002214	104412				RDOCT		:: GET THE ADDRESS
1526	002216	012637	001224			MOV	(SP)+, PORTA	:: STORE THE ADDRESS
1527	002222	023727	001224	000007		CMP	PORTA, \$7	:: SEE IF ADDRESS TOO LARGE
1528	002230	101403				BLOS	\$2\$:: BR IF NOT
1529	002232	104401	023365			TYPE	, ADRERR	:: TYPE ADDRESS ERROR MESSAGE
1530	002236	000744				BR	\$:: TRY AGAIN
1531	002240	013737	001224	001226	2\$:	MOV	PORTA, PORTB	:: GENERATE THE PORT B ADDRESS
1532	002246	005237	001226			INC	PORTB	:: INCREMENT THE ADDRESS
1533	002252	042737	000016	001226		BIC	\$16, PORTB	:: LEAVE BIT 0
1534	002260	013746	001224			MOV	PORTA, -(SP)	:: PUT PORT A ADDRESS ON THE STACK
1535	002264	042716	177771			BIC	\$16, (SP)	:: SAVE BITS 1 & 2
1536	002270	052637	001226			BIS	(SP)+, PORTB	:: SET BITS 1 & 2 IN PORT B ADDRESS
1537	002274	104401	023407			TYPE	PORTA IS	:: PORT A ADDRESS IS
1538	002300	013746	001224			MOV	PORTA, -(SP)	:: SAVE PORTA FOR TYPEOUT
1539								:: TYPE PORT A ADDRESS
1540	002304	104403				TYPOS		:: GO TYPE--OCTAL ASCII
1541	002306	001				.BYTE	1	:: TYPE 1 DIGIT(S)
1542	002307	000				.BYTE	0	:: SUPPRESS LEADING ZEROS
1543	002310	104401	023435			TYPE	PORTB IS	:: PORT B ADDRESS IS
1544	002314	013746	001226			MOV	PORTB, -(SP)	:: SAVE PORTB FOR TYPEOUT
1545								:: TYPE PORT B ADDRESS
1546	002320	104403				TYPOS		:: GO TYPE--OCTAL ASCII
1547	002322	001				.BYTE	1	:: TYPE 1 DIGIT(S)
1548	002323	000				.BYTE	0	:: SUPPRESS LEADING ZEROS

E03

```

1549 002324 104401 001207          TYPE      $CRLF      ;ANOTHER CR-LF
1550 002330 013737 001224 001230      MOV      PORTA,PORTC ;GENERATE ADDRESS OF DRIVE NOT TESTED
1551 002336 062737 000006 001230      ADD      #6,PORTC    ;COMPLEMENT SOME BITS
1552 002344 042737 177770 001230      BIC      #1C7,PORTC  ;SAVE ONLY LOWER BITS
1553 002352 013701 001224          MOV      PORTA,R1    ;USE PORT A ADDRESS AS INDEX
1554 002356 116137 031134 001232      MOVB    ATABIT(R1),ASR1 ;GET ATTENTION BIT FOR DRIVE
1555 002364 005037 001256          CLR      TIMEA      ;CLEAR TIMEOUT ONE-SHOT VALUE LOCATION
1556 002370 005037 001260          CLR      TIMEAP     ;CLEAR TIMEOUT ONE-SHOT VALUE LOCATION
1557 002374 005037 001262          CLR      TIMEB     ;CLEAR TIMEOUT ONE-SHOT VALUE LOCATION
1558 002400 005037 001264          CLR      TIMEBP     ;CLEAR TIMEOUT ONE-SHOT VALUE LOCATION
1559 002404 004737 017744          JSR      PC,CKCLK   ;SETUP CLOCK
1560 002410 000137 002424          JMP      EXEC       ;CLOCK HAS BEEN STARTED
1561 002414 104401 023463          TYPE      ,NOCLOCK  ;NO CLOCK ON SYSTEM
1562 002420 000000          HALT     ;FATAL ERROR
1563 002422 000776          BR      3$         ;INTERLOCK THE HALT
1564
1565          ;ROUTINE TO GET THE TEST NUMBER FROM THE OPERATOR
1566
1567 002424 000005          EXEC:   RESET      ;CLEAR EVERYTHING
1568 002426 005037 177776          CLR      PS        ;CLEAR THE PROCESSOR STATUS WORD
1569 002432 104401 001207          TYPE      $CRLF    ;CR-LF
1570 002436 013700 001272          MOV      $RPADR,RO  ;RH11 ADDRESS FOR INDEXING
1571 002442 012706 001100          MOV      $STACK,SP ;LOAD STACK POINTER
1572 002446 004737 017744          JSR      PC,CKCLK   ;START THE CLOCK
1573 002452 000240          NOP              ;RETURN IF NO CLOCK
1574 002454 004737 021550          JSR      PC,STKINT  ;INITIALIZE THE KEYBOARD
1575 002460 005037 001266          CLR      KYBCTL     ;CLEAR SINGLE TEST INDICATOR
1576 002464 005037 001100          CLR      SPASS      ;CLEAR THE PASS COUNT
1577 002470 112737 000001 001115      MOVB    #1,$ERMAX   ;SET ERROR MAX TO 1
1578 002476 012737 002476 001106      MOV      #.,$LPADR  ;INITIAL SETTING FOR LOOP ADDRESS
1579 002504 012737 002504 001110      MOV      #.,$LPERR  ;INITIAL SETTING FOR LOOP ON ERROR ADDRESS
1580 002512 104401 023532          1$:     TYPE      ,TESTNO ;ASK FOR TEST NUMBER
1581 002516 104412          RDOCT          ;GET THE NUMBER
1582 002520 012601          MOV      (SP)+,R1   ;PUT ENTRY INTO R1
1583 002522 001002          BNE     2$         ;BR IF NOT ZERO
1584 002524 000137 002712          JMP     TST1       ;ENTER ZERO - PERFORM ALL TESTS
1585 002530 020137 031144          2$:     CMP      R1,MAXTN ;SEE IF NUMBER GREATER THAN MAXIMUM
1586 002534 003403          BLE     3$         ;BR IF LESS OR EQUAL
1587 002536 104401 023552          TYPE      ,BADNO    ;BAD ENTRY
1588 002542 000763          BR      1$         ;TRY AGAIN
1589 002544 005301          3$:     DEC      R1    ;DECREMENT ENTRY
1590 002546 006301          ASL     R1         ;SHIFT IT LEFT
1591 002550 016137 031104 002574      MOV     TSTADR(R1),4$ ;GET THE TEST ADDRESS
1592 002556 005237 001266          INC     KYBCTL     ;SET SINGLE TEST INDICATOR
1593 002562 012737 000001 001104      MOV     #1,$ICNT   ;PRESET ITERATION COUNT
1594 002570 000177 000000          JMP     24$        ;GO TO THE SELECTED TEST
1595 002574 000000          4$:     .WORD    0   ;TEST ADDRESS GOES HERE
1596
1597          ;CHANGE THE RH11 UNIBUS ADDRESS USED BY THE PROGRAM
1598
1599 002576 005737 001270          CHANGE: TST      CHGADR ;CHANGE THE ADDRESS ?
1600 002602 001421          BEQ     3$         ;BR IF NOT
1601 002604 005037 001270          CLR     CHGADR     ;CLEAR THE INDICATOR
1602 002610 104401 023600          1$:     TYPE      ,ADDRIS ;TYPE OUT WHAT THE PRESENT ADDRESS IS
1603 002614 013746 001272          MOV     $RPADR,-(SP) ;PUT THE ADDRESS ON THE STACK
1604 002620 104402          TYPOC          ;TYPE THE ACTUAL ADDRESS

```



```

1605 002622 104401 001207 TYPE ,SCRLF ;CR-LF
1606 002626 104401 023660 TYPE ,NTRH11 ;ASK FOR NEW ADDRESS
1607 002632 104412 RDOCT
1608 002634 005716 TST (SP) ;0 OR 'CR' ENTERED ?
1609 002636 001402 BEQ 2$ ;BR IF EITHER ENTERED (NO ADDRESS CHANGE)
1610 002640 011637 001272 MOV (SP),SRPADR ;NEW RH11 ADDRESS
1611 002644 005726 2$: TST (SP)+ ;CORRECT THE STACK POINTER
1612 002646 012737 002666 000004 3$: MOV #4$,2#4 ;LOAD TRAP ADDRESS
1613 002654 013700 001272 MOV SRPADR,RO ;RH11 ADDRESS
1614 002660 005760 000002 TST RPMC(RO) ;SEE IF RH11 RESPONDS AT THAT ADDRESS
1615 002664 000404 BR 5$ ;BR, RH11 ALIVE AT PRESENT ADDRESS
1616 002666 104025 4$: ERROR 25 ;NO RESPONSE TO ADDRESS
1617 002670 062706 000004 ADD #4,SP ;RESET THE STACK POINTER
1618 002674 000745 BR 1$ ;GET ADDRESS AGAIN
1619 002676 012737 000006 000004 5$: MOV #6,2#4 ;RESTORE THE VECTOR
1620 002704 000207 RTS PC ;RETURN

```

;;*****

.SBTTL *** TESTS ***

;;*****

```

1629 002706 013700 001272 TST1AA: MOV SRPADR,RO ;;RESTORE RO AFTER END OF PASS

```

;;*****

*TEST 1 DRIVE ACCESS TEST

*VERIFY THAT THE DRIVE CAN BE ACCESSED THROUGH BOTH PORTS

* A. SELECT DRIVE, VERIFY THAT THE DRIVE IS PRESENT, THAT THE DRIVE IS A DUAL PORT RPO4/5/6, THAT THE DRIVE IS ONLINE (RPOS1 HAS 'MOL', 'PGM', 'DPR', & 'DRY' BITS SET), AND THE THE DRIVE SERIAL NUMBER READ THROUGH BOTH PORTS IS THE SAME.

* B. THE TEST IS REPEATED THROUGH BOTH PORTS.

;;*****

```

1644 002712 TST1: TST KYBCTL ;PERFORMING ONLY SINGLE TESTS ?
1645 002712 005737 001266 BEQ 2$ ;BR IF NOT
1646 002716 001406 BPL 1$ ;BR IF JUST ENTERED TEST
1647 002720 100002 JMP EXEC ;RETURN & GET NEXT TEST NUMBER
1648 002722 000137 002424 1$: MOV #-1,KYBCTL ;SET SINGLE TEST INDICATOR
1649 002726 012737 177777 001266 2$: MOV #1,$STNM ;TEST NUMBER
1650 002734 112737 000001 001102 MOV #TEST1,$LPADR ;LOAD LOOP ON TEST ADDRESS
1651 002742 012737 002764 001106 MOV #TEST1,$LPERR ;LOAD LOOP ON ERROR ADDRESS
1652 002750 012737 002764 001110 MOV #1,$TIMES ;DO 1 ITERATION
1653 002756 012737 000001 001176 TEST1: MOV #STACK,SP ;SETUP THE STACK POINTER
1654 002764 012706 001100

```

;;*****

;;VERIFY THAT DRIVE IS PRESENT THROUGH PORTS A & B

```

1659 002770 113760 001224 000010 MOV#B PORTA,RPCS2(RO) ;SELECT PORT A
1660 002776 013737 001224 001234 MOV PORTA,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT

```



```

1661 003004 005760 000012 TST RPDS1(RO) ;SEE IF DRIVE (PORT A) PRESENT
1662 003010 005037 001244 CLR CKERR ;CLEAR THE 'CHECK ERROR' INDICATOR
1663 003014 016037 000010 001126 MOV RPCS2(RO),SBDAT ;GET CONTENTS OF RPCS2
1664 003022 012737 000010 001122 MOV #RPCS2,SBDADR ;FORM REGISTER ADDRESS OF ERROR MESSAGE
1665 003030 060037 001122 ADD RO,SBDADR ;ADD RH11 BASE ADDRESS
1666 003034 005037 001124 CLR SGDDAT ;WHAT REGISTER SHOULD BE
1667 003040 013737 001126 001164 MOV SBDAT,STMP0 ;MOVE REGISTER CONTENTS TO 'STMP0'
1668 003046 042737 167777 001164 BIC #1CNED,STMP0 ;SAVE SPECIFIED BITS
1669 003054 023737 001124 001164 CMP SGDDAT,STMP0 ;COMPARE THE BITS
1670 003062 001414 BEQ 645 ;BR IF OK
1671 003064 013737 001126 001174 MOV SBDAT,STMP4 ;COPY 'BAD DATA'
1672 003072 042737 010000 001174 BIC #NED,STMP4 ;CLEAR THE MASKED BITS
1673 003100 053737 001174 001124 BIS STMP4,SGDDAT ;'OR' WITH GOOD DATA FOR TYPEOUT
1674 003106 104001 ERROR 1 ;TYPE MESSAGE 1
1675 003110 005137 001244 COM CKERR ;SET THE REGISTER COMPARE ERROR INDICATOR
1676 003114 000240 645: NOP
1677 003116 005737 001244 TST CKERR ;WAS 'NED' SET ?
1678 003122 001403 BEQ .+10 ;BR IF NOT
1679 003124 012760 000040 000010 MOV #CLR,RPCS2(RO) ;ISSUE MASSBUS INIT TO CLEAR 'NED'
1680 003132 113760 001226 000010 MOVB PORTB,RPCS2(RO) ;SELECT PORT B
1681 003140 013737 001226 001234 MOV PORTB,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
1682 003146 005760 000012 TST RPDS1(RO) ;SEE IF DRIVE (PORT B) PRESENT
1683 003152 005037 001244 CLR CKERR ;CLEAR THE 'CHECK ERROR' INDICATOR
1684 003156 016037 000010 001126 MOV RPCS2(RO),SBDAT ;GET CONTENTS OF RPCS2
1685 003164 012737 000010 001122 MOV #RPCS2,SBDADR ;FORM REGISTER ADDRESS OF ERROR MESSAGE
1686 003172 060037 001122 ADD RO,SBDADR ;ADD RH11 BASE ADDRESS
1687 003176 005037 001124 CLR SGDDAT ;WHAT REGISTER SHOULD BE
1688 003202 013737 001126 001164 MOV SBDAT,STMP0 ;MOVE REGISTER CONTENTS TO 'STMP0'
1689 003210 042737 167777 001164 BIC #1CNED,STMP0 ;SAVE SPECIFIED BITS
1690 003216 023737 001124 001164 CMP SGDDAT,STMP0 ;COMPARE THE BITS
1691 003224 001414 BEQ 665 ;BR IF OK
1692 003226 013737 001126 001174 MOV SBDAT,STMP4 ;COPY 'BAD DATA'
1693 003234 042737 010000 001174 BIC #NED,STMP4 ;CLEAR THE MASKED BITS
1694 003242 053737 001174 001124 BIS STMP4,SGDDAT ;'OR' WITH GOOD DATA FOR TYPEOUT
1695 003250 104001 ERROR 1 ;TYPE MESSAGE 1
1696 003252 005137 001244 COM CKERR ;SET THE REGISTER COMPARE ERROR INDICATOR
1697 003256 000240 665: NOP
1698 003260 005737 001244 TST CKERR ;WAS 'NED' SET ?
1699 003264 001403 BEQ .+10 ;BR IF NOT
1700 003266 012760 000040 000010 MOV #CLR,RPCS2(RO) ;ISSUE MASSBUS INIT TO CLEAR 'NED'
1701
1702 ;:*****
1703 ;:CONFIRM THAT DRIVE IS AN RPO4/5/6 AND IS DUAL PORT
1704
1705 003274 113760 001224 000010 MOVB PORTA,RPCS2(RO) ;SELECT PORT A
1706 003302 013737 001224 001234 MOV PORTA,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
1707 003310 005037 001244 CLR CKERR ;CLEAR THE 'CHECK ERROR' INDICATOR
1708 003314 016037 000026 001126 MOV RPDT(RO),SBDAT ;GET CONTENTS OF RPDT
1709 003322 012737 000026 001122 MOV #RPDT,SBDADR ;FORM REGISTER ADDRESS OF ERROR MESSAGE
1710 003330 060037 001122 ADD RO,SBDADR ;ADD RH11 BASE ADDRESS
1711 003334 012737 024020 001124 MOV #24020,SGDDAT ;WHAT REGISTER SHOULD BE
1712 003342 013737 001126 001164 MOV SBDAT,STMP0 ;MOVE REGISTER CONTENTS TO 'STMP0'
1713 003350 042737 000003 001164 BIC #1C177774,STMP0 ;SAVE SPECIFIED BITS
1714 003356 023737 001124 001164 CMP SGDDAT,STMP0 ;COMPARE THE BITS
1715 003364 001414 BEQ 685 ;BR IF OK
1716 003366 013737 001126 001174 MOV SBDAT,STMP4 ;COPY 'BAD DATA'

```


H03

```
1717 003374 042737 177774 001174 BIC #177774,STMP4 ;CLEAR THE MASKED BITS
1718 003402 053737 001174 001124 BIS STMP4,$GDDAT ;'OR' WITH GOOD DATA FOR TYPEOUT
1719 003410 104002 ERROR 2 ;TYPE MESSAGE 2
1720 003412 005137 001244 COM CKERR ;SET THE REGISTER COMPARE ERROR INDICATOR
1721 003416 000240 66S: NOP
1722 003420 113760 001226 000010 MOVB PORTB,RPCS2(RO) ;SELECT PORT B
1723 003426 013737 001226 001234 MOV PORTB,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
1724 003434 005037 001244 CLR CKERR ;CLEAR THE 'CHECK ERROR' INDICATOR
1725 003440 016037 000026 001126 MOV RPDT(RO),SBDDAT ;GET CONTENTS OF RPDT
1726 003446 012737 000026 001122 MOV #RPDT,SBADR ;FORM REGISTER ADDRESS OF ERROR MESSAGE
1727 003454 060037 001122 ADD RO,SBADR ;ADD RH11 BASE ADDRESS
1728 003460 012737 024020 001124 MOV #24020,$GDDAT ;WHAT REGISTER SHOULD BE
1729 003466 013737 001126 001164 MOV SBDDAT,STMP0 ;MOVE REGISTER CONTENTS TO 'STMP0'
1730 003474 042737 000003 001164 BIC #1C177774,STMP0 ;SAVE SPECIFIED BITS
1731 003502 023737 001124 001164 CMP $GDDAT,STMP0 ;COMPARE THE BITS
1732 003510 001414 BEQ 70S ;BR IF OK
1733 003512 013737 001126 001174 MOV SBDDAT,STMP4 ;COPY 'BAD DATA'
1734 003520 042737 177774 001174 BIC #177774,STMP4 ;CLEAR THE MASKED BITS
1735 003526 053737 001174 001124 BIS STMP4,$GDDAT ;'OR' WITH GOOD DATA FOR TYPEOUT
1736 003534 104002 ERROR 2 ;TYPE MESSAGE 2
1737 003536 005137 001244 COM CKERR ;SET THE REGISTER COMPARE ERROR INDICATOR
1738 003542 000240 70S: NOP
1739
1740 ;*****
1741 ;VERIFY THROUGH BOTH PORTS THAT THE DRIVE IS ON LINE AND IN NEUTRAL
1742
1743 003544 113760 001224 000010 MOVB PORTA,RPCS2(RO) ;SELECT PORT A
1744 003552 013737 001224 001234 MOV PORTA,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
1745 003560 005037 001244 CLR CKERR ;CLEAR THE 'CHECK ERROR' INDICATOR
1746 003564 016037 000012 001126 MOV RPDS1(RO),SBDDAT ;GET CONTENTS OF RPDS1
1747 003572 012737 000012 001122 MOV #RPDS1,SBADR ;FORM REGISTER ADDRESS OF ERROR MESSAGE
1748 003600 060037 001122 ADD RO,SBADR ;ADD RH11 BASE ADDRESS
1749 003604 012737 001000 001124 MOV #PGM,$GDDAT ;WHAT REGISTER SHOULD BE
1750 003612 013737 001126 001164 MOV SBDDAT,STMP0 ;MOVE REGISTER CONTENTS TO 'STMP0'
1751 003620 042737 176777 001164 BIC #1CPGM,STMP0 ;SAVE SPECIFIED BITS
1752 003626 023737 001124 001164 CMP $GDDAT,STMP0 ;COMPARE THE BITS
1753 003634 001414 BEQ 72S ;BR IF OK
1754 003636 013737 001126 001174 MOV SBDDAT,STMP4 ;COPY 'BAD DATA'
1755 003644 042737 001000 001174 BIC #PGM,STMP4 ;CLEAR THE MASKED BITS
1756 003652 053737 001174 001124 BIS STMP4,$GDDAT ;'OR' WITH GOOD DATA FOR TYPEOUT
1757 003660 104003 ERROR 3 ;TYPE MESSAGE 3
1758 003662 005137 001244 COM CKERR ;SET THE REGISTER COMPARE ERROR INDICATOR
1759 003666 000240 72S: NOP
1760 003670 005037 001244 CLR CKERR ;CLEAR THE 'CHECK ERROR' INDICATOR
1761 003674 016037 000012 001126 MOV RPDS1(RO),SBDDAT ;GET CONTENTS OF RPDS1
1762 003702 012737 000012 001122 MOV #RPDS1,SBADR ;FORM REGISTER ADDRESS OF ERROR MESSAGE
1763 003710 060037 001122 ADD RO,SBADR ;ADD RH11 BASE ADDRESS
1764 003714 012737 010600 001124 MOV #MOL!DPR!DRY,$GDDAT ;WHAT REGISTER SHOULD BE
1765 003722 013737 001126 001164 MOV SBDDAT,STMP0 ;MOVE REGISTER CONTENTS TO 'STMP0'
1766 003730 042737 167177 001164 BIC #1C10600,STMP0 ;SAVE SPECIFIED BITS
1767 003736 023737 001124 001164 CMP $GDDAT,STMP0 ;COMPARE THE BITS
1768 003744 001414 BEQ 74S ;BR IF OK
1769 003746 013737 001126 001174 MOV SBDDAT,STMP4 ;COPY 'BAD DATA'
1770 003754 042737 010600 001174 BIC #10600,STMP4 ;CLEAR THE MASKED BITS
1771 003762 053737 001174 001124 BIS STMP4,$GDDAT ;'OR' WITH GOOD DATA FOR TYPEOUT
1772 003770 104004 ERROR 4 ;TYPE MESSAGE 4
```



```

1773 003772 005137 001244          COM      CKERR          ;SET THE REGISTER COMPARE ERROR INDICATOR
1774 003776 000240          NOP
1775 004000 113760 001226 000010 745:  MOVB     PORTB,RPCS2(RO) ;SELECT PORT B
1776 004006 013737 001226 001234  MOV     PORTB,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
1777 004014 005037 001244          CLR      CKERR          ;CLEAR THE 'CHECK ERROR' INDICATOR
1778 004020 016037 000012 001126  MOV     RPDS1(RO),SDDAT ;GET CONTENTS OF RPDS1
1779 004026 012737 000012 001122  MOV     #RPDS1,SDDADR ;FORM REGISTER ADDRESS OF ERROR MESSAGE
1780 004034 060037 001122          ADD     RO,SDDADR      ;ADD RH11 BASE ADDRESS
1781 004040 012737 001000 001124  MCV     #PGM,SGDAT     ;WHAT REGISTER SHOULD BE
1782 004046 013737 001126 001164  MOV     SDDAT,STMP0    ;MOVE REGISTER CONTENTS TO 'STMP0'
1783 004054 042737 176777 001164  BIC     #1CPGM,STMP0   ;SAVE SPECIFIED BITS
1784 004062 023737 001124 001164  CMP     SGDAT,STMP0    ;COMPARE THE BITS
1785 004070 001414          BEQ     765           ;BR IF OK
1786 004072 013737 001126 001174  MOV     SDDAT,STMP4    ;COPY 'BAD DATA'
1787 004100 042737 001000 001174  BIC     #PGM,STMP4    ;CLEAR THE MASKED BITS
1788 004106 053737 001174 001124  BIS     STMP4,SGDAT    ;'OR' WITH GOOD DATA FOR TYPEOUT
1789 004114 104003          ERROR   3            ;TYPE MESSAGE 3
1790 004116 005137 001244          COM      CKERR          ;SET THE REGISTER COMPARE ERROR INDICATOR
1791 004122 000240          NOP
1792 004124 005037 001244          CLR      CKERR          ;CLEAR THE 'CHECK ERROR' INDICATOR
1793 004130 016037 000012 001126  MOV     RPDS1(RO),SDDAT ;GET CONTENTS OF RPDS1
1794 004136 012737 000012 001122  MOV     #RPDS1,SDDADR ;FORM REGISTER ADDRESS OF ERROR MESSAGE
1795 004144 060037 001122          ADD     RO,SDDADR      ;ADD RH11 BASE ADDRESS
1796 004150 012737 010600 001124  MOV     #MOL!DPR!DRY,SGDAT ;WHAT REGISTER SHOULD BE
1797 004156 013737 001126 001164  MOV     SDDAT,STMP0    ;MOVE REGISTER CONTENTS TO 'STMP0'
1798 004164 042737 167177 001164  BIC     #1C10600,STMP0 ;SAVE SPECIFIED BITS
1799 004172 023737 001124 001164  CMP     SGDAT,STMP0    ;COMPARE THE BITS
1800 004200 001414          BEQ     785           ;BR IF OK
1801 004202 013737 001126 001174  MOV     SDDAT,STMP4    ;COPY 'BAD DATA'
1802 004210 042737 010600 001174  BIC     #10600,STMP4   ;CLEAR THE MASKED BITS
1803 004216 053737 001174 001124  BIS     STMP4,SGDAT    ;'OR' WITH GOOD DATA FOR TYPEOUT
1804 004224 104004          ERROR   4            ;TYPE MESSAGE 4
1805 004226 005137 001244          COM      CKERR          ;SET THE REGISTER COMPARE ERROR INDICATOR
1806 004232 000240          NOP
1807
1808
1809 ;:*****
1810 ;:VERIFY THAT DRIVE SERIAL NUMBER SEEN THROUGH BOTH PORTS IS THE SAME
1811 004234 113760 001224 000010  MOVB     PORTA,RPCS2(RO) ;SELECT PORT A
1812 004242 016037 000030 001124  MOV     RPSN(RO),SGDAT ;STORE THE PORT A SERIAL NUMBER
1813 004250 113760 001226 000010  MOVB     PORTB,RPCS2(RO) ;SELECT PORT B
1814 004256 016037 000030 001126  MOV     RPSN(RO),SDDAT ;STORE THE PORT B SERIAL NUMBER
1815 004264 023737 001124 001126  CMP     SGDAT,SDDAT    ;ARE THEY THE SAME ?
1816 004272 001406          BEQ     15           ;BR IF THEY ARE
1817 004274 104005          ERROR   5            ;REPORT THE ERROR
1818 004276 032777 100000 174634  BIT     #SW15,2SWR     ;HALT ON ERROR ?
1819 004304 001001          BNE     15           ;BR IF SET - PROGRAM HAS ALREADY HALTED
1820 004306 000000          HALT
1821 004310 000004 15:  SCOPE          ;HALT, POSSIBLE CABLE CONNECTION PROBLEM
1822
1823
1824
1825 ;:*****
1826 ;:TEST 2          SET 'VV' FOR PORT A
1827 ;:
1828 ;:SET VOLUME VALID

```


1829
1830
1831
1832
1833
1834
1835
1836
1837
1838
1839
1840
1841
1842
1843
1844
1845
1846
1847
1848
1849
1850
1851
1852
1853
1854
1855
1856
1857
1858
1859
1860
1861
1862
1863
1864
1865
1866
1867
1868
1869
1870
1871
1872
1873
1874
1875
1876
1877
1878
1879
1880
1881
1882
1883
1884

004312
004312 005737 001266
004316 001406
004320 100002
004322 000137 002424
004326 012737 177777 001266
004334 112737 000002 001102
004342 012737 004364 001106
004350 012737 004364 001110
004356 012737 000001 001176
004364 012706 001100
004370 113760 001224 000010
004376 013737 001224 001231

004404 012760 000011 000000
004412 012760 000021 000000
004420 012760 010000 000032

004426 005037 001244
004432 016037 000012 001126
004440 012737 000012 001122
004446 060037 001122
004452 012737 011700 001124
004460 013737 001126 001164
004466 042737 106077 001164
004474 023737 001124 001164
004502 001414
004504 013737 001126 001174
004512 042737 071700 001174
004520 053737 001174 001124
004526 104010
004530 005137 001244
004534 000240

004536 113760 001224 000010

```

;
; A. ISSUE A DRIVE CLEAR COMMAND THROUGH PORT A.
;
; B. ISSUE A READIN PRESET COMMAND THROUGH PORT A. VERIFY
; THAT THE 'VV' BIT IS SET FOR PORT A.
;
; C. ISSUE A RELEASE COMMAND THROUGH PORT A. VERIFY THAT
; THE DRIVE RETURNED TO NEUTRAL AND THAT NEITHER ATTENTION
; BIT IS SET.
;
;*****
TST2:
TST      KYBCTL      ;PERFORMING ONLY SINGLE TESTS ?
BEQ      25          ;BR IF NOT
BPL      15          ;BR IF JUST ENTERED TEST
JMP      EXEC        ;RETURN & GET NEXT TEST NUMBER
15:      MOV      #-1,KYBCTL ;SET SINGLE TEST INDICATOR
25:      MOV      #2,$STNM  ;TEST NUMBER
        MOV      #TEST2,$LPADR ;LOAD LOOP ON TEST ADDRESS
        MOV      #TEST2,$LPERR ;LOAD LOOP ON ERROR ADDRESS
        MOV      #1,$TIMES  ;DO 1 ITERATION
TEST2:   MOV      #STACK,$SP ;SETUP THE STACK POINTER
        MOV      PORTA,$PC2(R0) ;SELECT PORT A
        MOV      PORTA,$PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
;*****
;SET VOLUME VALUE FOR PORT
        MOV      #11,$PC1(R0) ;ISSUE A DRIVE CLEAR
        MOV      #21,$PC1(R0) ;ISSUE A READIN PRESET
        MOV      #FMT22,$RPOF(R0) ;SET FMT22
;*****
;VERIFY THAT THE DRIVE STATUS IS CORRECT
        CLR      CKERR      ;CLEAR THE 'CHECK ERROR' INDICATOR
        MOV      $RPDS1(R0),$SDDAT ;GET CONTENTS OF RPDS1
        MOV      #RPDS1,$SDDADR ;FORM REGISTER ADDRESS OF ERROR MESSAGE
        ADD      $R0,$SDDADR ;ADD RH11 BASE ADDRESS
        MOV      #MOL!PGM!DPR!DRY!VV,$GDDAT ;WHAT REGISTER SHOULD BE
        MOV      $SDDAT,$STMP0 ;MOVE REGISTER CONTENTS TO 'STMP0'
        BIC      #1C71700,$STMP0 ;SAVE SPECIFIED BITS
        CMP      $GDDAT,$STMP0 ;COMPARE THE BITS
        BEQ      645        ;BR IF OK
        MOV      $SDDAT,$STMP4 ;COPY 'BAD DATA'
        BIC      #71700,$STMP4 ;CLEAR THE MASKED BITS
        BIS      $STMP4,$GDDAT ;'OR' WITH GOOD DATA FOR TYPEOUT
        ERROR    10         ;TYPE MESSAGE 10
        COM      CKERR      ;SET THE REGISTER COMPARE ERROR INDICATOR
645:     NOP
;*****
;RELEASE THE DRIVE FROM PORT A
        MOV      PORTA,$PC2(R0) ;SELECT PORT A

```


K03

MD-11-DZRJF-A, RPO4/5/6 DUAL CONTRLR LOGIC TEST - PART 2
DZRJFA.CMB 02-NOV-76 19:11 T2 SET 'VV' FOR PORT A

MACY11 27(1006) 02-NOV-76 19:12 PAGE 36

```
1885 004544 013737 001224 001234 MOV PORTA,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
1886 004552 012760 000013 000000 MOV #13,RPCS1(RO) ;ISSUE RELEASE THROUGH PORT A
1887
1888 ;VERIFY THAT THE DRIVE IS IN NEUTRAL
1889
1890 004560 005037 001250 CLR RELERR ;CLEAR THE 'RELEASE ERROR' INDICATOR
1891 004564 012737 000012 001122 MOV #RPDS1,$BDDADR ;FORM THE ADDRESS OF RPDS1 FOR TYPEOUT
1892 004572 060037 001122 ADD RO,$BDDADR ;ADD THE I/O BASE ADDRESS
1893 004576 012737 011600 001124 MOV #MOL!PGM!DPR!DRY,$GDDAT ;COMPARISON CONSTANT
1894 004604 113760 001224 000010 MOVB PORTA,RPCS2(RO) ;SELECT PORT A.
1895 004612 016037 000012 001170 MOV RPDS1(RO),$TMP2 ;GET THE DRIVE STATUS REGISTER FROM PORT A.
1896 004620 013737 001170 001164 MOV $TMP2,$TMP0 ;COPY IT INTO '$TMP0'
1897 004626 042737 100100 001164 BIC #ATA!VV,$TMP0 ;CLEAR PORT DEPENDENT BITS FROM THE COPY
1898 004634 113760 001226 000010 MOVB PORTB,RPCS2(RO) ;SELECT PORT B.
1899 004642 016037 000012 001172 MOV RPDS1(RO),$TMP3 ;GET THE DRIVE STATUS REGISTER FROM PORT B.
1900 004650 013737 001172 001166 MOV $TMP3,$TMP1 ;COPY IT INTO '$TMP1'
1901 004656 042737 100100 001166 BIC #ATA!VV,$TMP1 ;CLEAR PORT DEPENDENT BITS FROM THE COPY
1902 004664 023737 001164 001166 CMP $TMP0,$TMP1 ;IS THE STATUS REGISTER THE SAME FROM BOTH PORTS ?
1903 004672 001006 BNE 66$ ;BR IF NOT
1904 004674 005737 001164 TST $TMP0 ;REGISTERS ARE THE SAME: ARE THEY ZERO ?
1905 004700 001037 BNE 68$ ;BR IF NOT
1906 004702 104034 ERROR 34 ;REPORT DRIVE NOT IN NEUTRAL OR NOT SEIZED
1907 004704 000137 005070 JMP 70$ ;BYPASS THE REST OF THE CHECKS
1908 004710 013737 001170 001126 66$: MOV $TMP2,$BDDAT ;SET UP POSSIBLE BAD DATA FOR ERROR MESSAGE
1909 004716 013737 001226 001234 MOV PORTB,PTNBR ;SEIZING PORT IF TEST SHOWS DRIVE NOT IN NEUTRAL
1910 004724 113760 001226 000010 MOVB PORTB,RPCS2(RO) ;SELECT PORT B.
1911 004732 005737 001164 TST $TMP0 ;SEE IF STATUS EQ 0 FROM PORT A.
1912 004736 001414 BEQ 67$ ;BR IF ZERO
1913 004740 013737 001224 001234 MOV PORTA,PTNBR ;SEIZING PORT IF TEST SHOWS DRIVE NOT IN NEUTRAL
1914 004746 013737 001172 001126 MOV $TMP3,$BDDAT ;'BAD DATA' FOR ERROR TYPE OUT
1915 004754 113760 001224 000010 MOVB PORTA,RPCS2(RO) ;SELECT PORT A.
1916 004762 005737 001166 TST $TMP1 ;SEE IF STATUS EQ ZERO FROM PORT B.
1917 004766 001004 BNE 68$ ;BR IF NOT
1918 004770 012737 177777 001250 67$: MOV #-1,RELERR ;SET 'RELEASE ERROR' INDICATOR
1919 004776 104036 ERROR 36 ;TYPE ERROR MESSAGE 36
1920 005000 013737 001170 001126 68$: MOV $TMP2,$BDDAT ;LOOK FOR BIT FAILURES WHEN RPDS1 READ
1921 005006 013737 001224 001234 MOV PORTA,PTNBR ;CHANGE PORT NUMBER
1922 005014 042737 100100 001170 BIC #ATA!VV,$TMP2 ;DON'T CHECK ATTN BIT OR VV BIT
1923 005022 023737 001124 001170 CMP $GDDAT,$TMP2 ;ALL BITS OK ?
1924 005030 001401 BEQ 69$ ;BR IF OK FROM PORT A.
1925 005032 104037 ERROR 37 ;REPORT ERROR
1926 005034 013737 001172 001126 69$: MOV $TMP3,$BDDAT ;CHECK RPDS1 FOR BIT FAILURES - FROM PORT B.
1927 005042 013737 001226 001234 MOV PORTB,PTNBR ;CHANGE PORT NUMBER
1928 005050 042737 100100 001172 BIC #ATA!VV,$TMP3 ;DON'T CHECK ATTN BIT OR VV BIT
1929 005056 023737 001124 001172 CMP $GDDAT,$TMP3 ;SEE IF READ OK FROM PORT B.
1930 005064 001401 BEQ 70$ ;BR IF OK
1931 005066 104037 ERROR 37 ;REPORT THE ERROR
1932 005070 000240 70$: NOP
1933 005072 000004 SCOPE ;LOOP ?
1934
1935 ;*****
1936 ;*TEST 3 SET 'VV' FOR PORT B
1937 ;*
1938 ;*SET VOLUME VALID
1939 ;*
1940 ;* A. ISSUE A DRIVE CLEAR COMMAND THROUGH PORT B.
```


L03

1941
1942
1943
1944
1945
1946
1947
1948
1949
1950
1951
1952
1953
1954
1955
1956
1957
1958
1959
1960
1961
1962
1963
1964
1965
1966
1967
1968
1969
1970
1971
1972
1973
1974
1975
1976
1977
1978
1979
1980
1981
1982
1983
1984
1985
1986
1987
1988
1989
1990
1991
1992
1993
1994
1995
1996

005074
005074 005737 001266
005100 001406
005102 100002
005104 000137 002424
005110 012737 177777 001266
005116 112737 000003 001102
005124 012737 005146 001106
005132 012737 005146 001110
005140 012737 000001 001176
005146 012706 001100
005152 113760 001226 000010
005160 013737 001226 001234

005166 012760 000011 000000
005174 012760 000021 000000
005202 012760 010000 000032

005210 005037 001244
005214 016037 000012 001126
005222 012737 000012 001122
005230 060037 001122
005234 012737 011700 001124
005242 013737 001126 001164
005250 042737 106077 001164
005256 023737 001124 001164
005264 001414
005266 013737 001126 001174
005274 042737 071700 001174
005302 053737 001174 001124
005310 104010
005312 005137 001244
005316 000240

005320 113760 001226 000010
005326 013737 001226 001234
005334 012760 000013 000000

```

;*
;* B. ISSUE A READIN PRESET COMMAND THROUGH PORT B. VERIFY
;* THAT THE 'VV' BIT IS SET FOR PORT B.
;*
;* C. ISSUE A RELEASE COMMAND THROUGH PORT B. VERIFY THAT
;* THE DRIVE RETURNED TO NEUTRAL AND THAT NEITHER ATTENTION
;* BIT IS SET.
*****
TST3:
TST KYBCTL ;PERFORMING ONLY SINGLE TESTS ?
BEQ 25 ;BR IF NOT
BPL 15 ;BR IF JUST ENTERED TEST
JMP EXEC ;RETURN & GET NEXT TEST NUMBER
15: MOV #-1,KYBCTL ;SET SINGLE TEST INDICATOR
25: MOVB #3,$STNM ;TEST NUMBER
MOV #TEST3,$LPADR ;LOAD LOOP ON TEST ADDRESS
MOV #TEST3,$LPERR ;LOAD LOOP ON ERROR ADDRESS
MOV #1,$TIMES ;DO 1 ITERATION
TEST3: MOV #STACK,$SP ;SETUP THE STACK POINTER
MOVB PORTB,$PC52(RO) ;SELECT PORT B
MOV PORTB,$PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
*****
;SET VOLUME VALUE FOR PORT
MOV #11,$RPCS1(RO) ;ISSUE A DRIVE CLEAR
MOV #21,$RPCS1(RO) ;ISSUE A READIN PRESET
MOV #FMT22,$RPOF(RO) ;SET FMT22
*****
;VERIFY THAT THE DRIVE STATUS IS CORRECT
CLR CKERR ;CLEAR THE 'CHECK ERROR' INDICATOR
MOV $RPCS1(RO),$SDDAT ;GET CONTENTS OF $RPCS1
MOV #RPCS1,$SDDADR ;FORM REGISTER ADDRESS OF ERROR MESSAGE
ADD $R0,$SDDADR ;ADD RHI1 BASE ADDRESS
MOV #MOL!PGM!DPR!DRY!VV,$GDDAT ;WHAT REGISTER SHOULD BE
MOV $SDDAT,$STMP0 ;MOVE REGISTER CONTENTS TO 'STMP0'
BIC #1C71700,$STMP0 ;SAVE SPECIFIED BITS
CMP $GDDAT,$STMP0 ;COMPARE THE BITS
BEQ 645 ;BR IF OK
MOV $SDDAT,$STMP4 ;COPY 'BAD DATA'
BIC #71700,$STMP4 ;CLEAR THE MASKED BITS
BIS $STMP4,$GDDAT ;'OR' WITH GOOD DATA FOR TYPEOUT
ERROR 10 ;TYPE MESSAGE 10
COM CKERR ;SET THE REGISTER COMPARE ERROR INDICATOR
645: NOP
*****
;RELEASE THE DRIVE FROM PORT B
MOVB PORTB,$PC52(RO) ;SELECT PORT B
MOV PORTB,$PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
MOV #13,$RPCS1(RO) ;ISSUE RELEASE THROUGH PORT B

```


M03

```

1997
1998
1999
2000 005342 005037 001250 CLR RELERR ;CLEAR THE 'RELEASE ERROR' INDICATOR
2001 005346 012737 000012 001122 MOV #RPDS1,$BDDADR ;FORM THE ADDRESS OF RPDS1 FOR TYPEOUT
2002 005354 060037 001122 ADD RO,$BDDADR ;ADD THE I/O BASE ADDRESS
2003 005360 012737 011600 001124 MOV #MOL!PGM!DPR!DRY,$GDDAT ;COMPARISON CONSTANT
2004 005366 113760 001224 000010 MOV#B PORTA,RPCS2(RO) ;SELECT PORT A.
2005 005374 016037 000012 001170 MOV RPDS1(RO),$TMP2 ;GET THE DRIVE STATUS REGISTER FROM PORT A.
2006 005402 013737 001170 001164 MOV $TMP2,$TMP0 ;COPY IT INTO '$TMP0'
2007 005410 042737 100100 001164 BIC #ATA!VV,$TMP0 ;CLEAR PORT DEPENDENT BITS FROM THE COPY
2008 005416 113760 001226 000010 MOV#B PORTB,RPCS2(RO) ;SELECT PORT B.
2009 005424 016037 000012 001172 MOV RPDS1(RO),$TMP3 ;GET THE DRIVE STATUS REGISTER FROM PORT B.
2010 005432 013737 001172 001166 MOV $TMP3,$TMP1 ;COPY IT INTO '$TMP1'
2011 005440 042737 100100 001166 BIC #ATA!VV,$TMP1 ;CLEAR PORT DEPENDENT BITS FROM THE COPY
2012 005446 023737 001164 001166 CMP $TMP0,$TMP1 ;IS THE STATUS REGISTER THE SAME FROM BOTH PORTS ?
2013 005454 001006 BNE 66$ ;BR IF NOT
2014 005456 005737 001164 TST $TMP0 ;REGISTERS ARE THE SAME: ARE THEY ZERO ?
2015 005462 001037 BNE 68$ ;BR IF NOT
2016 005464 104034 ERROR 34 ;REPORT DRIVE NOT IN NEUTRAL OR NOT SEIZED
2017 005466 000137 005652 JMP 70$ ;BYPASS THE REST OF THE CHECKS
2018 005472 013737 001170 001126 66$: MOV $TMP2,$BDDAT ;SET UP POSSIBLE BAD DATA FOR ERROR MESSAGE
2019 005500 013737 001226 001234 MOV PORTB,PTNBR ;SEIZING PORT IF TEST SHOWS DRIVE NOT IN NEUTRAL
2020 005506 113760 001226 000010 MOV#B PORTB,RPCS2(RO) ;SELECT PORT B.
2021 005514 005737 001164 TST $TMP0 ;SEE IF STATUS EQ 0 FROM PORT A.
2022 005520 001414 BEQ 67$ ;BR IF ZERO
2023 005522 013737 001224 001234 MOV PORTA,PTNBR ;SEIZING PORT IF TEST SHOWS DRIVE NOT IN NEUTRAL
2024 005530 013737 001172 001126 MOV $TMP3,$BDDAT ;'BAD DATA' FOR ERROR TYPE OUT
2025 005536 113760 001224 000010 MOV#B PORTA,RPCS2(RO) ;SELECT PORT A.
2026 005544 005737 001166 TST $TMP1 ;SEE IF STATUS EQ ZERO FROM PORT B.
2027 005550 001004 BNE 68$ ;BR IF NOT
2028 005552 012737 177777 001250 67$: MOV #1,RELERR ;SET 'RELEASE ERROR' INDICATOR
2029 005560 104036 ERROR 36 ;TYPE ERROR MESSAGE 36
2030 005562 013737 001170 001126 68$: MOV $TMP2,$BDDAT ;LOOK FOR BIT FAILURES WHEN RPDS1 READ
2031 005570 013737 001224 001234 MOV PORTA,PTNBR ;CHANGE PORT NUMBER
2032 005576 042737 100100 001170 BIC #ATA!VV,$TMP2 ;DON'T CHECK ATTN BIT OR VV BIT
2033 005604 023737 001124 001170 CMP $GDDAT,$TMP2 ;ALL BITS OK ?
2034 005612 001401 BEQ 69$ ;BR IF OK FROM PORT A.
2035 005614 104037 ERROR 37 ;REPORT ERROR
2036 005616 013737 001172 001126 69$: MOV $TMP3,$BDDAT ;CHECK RPDS1 FOR BIT FAILURES - FROM PORT B.
2037 005624 013737 001226 001234 MOV PORTB,PTNBR ;CHANGE PORT NUMBER
2038 005632 042737 100100 001172 BIC #ATA!VV,$TMP3 ;DON'T CHECK ATTN BIT OR VV BIT
2039 005640 023737 001124 001172 CMP $GDDAT,$TMP3 ;SEE IF READ OK FROM PORT B.
2040 005646 001401 BEQ 70$ ;BR IF OK
2041 005650 104037 ERROR 37 ;REPORT THE ERROR
2042 005652 000240 70$: NOP
2043 005654 000004 SCOPE ;LOOP ?
2044
2045
2046
2047
2048
2049 *****
2050 *TEST 4 MEASURE THE TIMEOUT ONE-SHOT THROUGH PORT A
2051 *
2052 *MEASURE THE TIMEOUT ONE-SHOT VALUE THROUGH PORT A
*
```


N03

2053
2054
2055
2056
2057
2058
2059
2060
2061
2062
2063
2064
2065
2066
2067
2068
2069
2070
2071
2072
2073
2074
2075
2076
2077
2078
2079
2080
2081
2082
2083
2084
2085
2086
2087
2088
2089
2090
2091
2092
2093
2094
2095
2096
2097
2098
2099
2100
2101
2102
2103
2104
2105
2106
2107
2108

005656
005656 005737 001266
005656 001406
005664 100002
005666 000137 002424
005672 012737 177777 001266
005700 112737 000004 001102
005706 012737 005730 001106
005714 012737 005730 001110
005722 012737 000001 001176
005730 012706 001100
005734 005037 001256
005740 005037 001260

005744 005037 001252
005750 012737 003720 001254

005756 113760 001224 000010
005764 013737 001224 001236
005772 005060 000012
005776 113760 001226 000010
006004 013737 001226 001234
006012 013737 001226 001240
006020 016037 000012 001126
006026 010037 001122
006032 062737 000012 001122
006040 005037 001124
006044 023737 001124 001126
006052 001403
006054 104030
006056 000137 006572
006062
006062 113760 001224 000010
006070 013737 001224 001234
006076 016037 000012 001126
006104 012737 011700 001124
006112 013737 001124 001166
006120 005137 001166
006124 013737 001126 001164

- *** A. WRITE 0'S INTO RPDS1 THROUGH PORT A AND VERIFY THAT THE DRIVE HAS BEEN SEIZED.
- *** B. WAIT FOR TIMEOUT TO OCCUR. MEASURE THE DURATION OF THE TIMEOUT ONE-SHOT AND SAVE THE VALUE FOR LATER USE.
- *** C. VERIFY THAT THE TIMEOUT OCCURRED AND THAT THE DRIVE RETURNS TO NEUTRAL

TST4:

```
TST KYBCTL ;PERFORMING ONLY SINGLE TESTS ?
BEQ 25 ;BR IF NOT
BPL 15 ;BR IF JUST ENTERED TEST
JMP EXEC ;RETURN & GET NEXT TEST NUMBER
15: MOV #-1,KYBCTL ;SET SINGLE TEST INDICATOR
25: MOVB #4,$STNM ;TEST NUMBER
MOV #TEST4,$LPADR ;LOAD LOOP ON TEST ADDRESS
MOV #TEST4,$LPERR ;LOAD LOOP ON ERROR ADDRESS
MOV #1,$TIMES ;DO 1 ITERATION
TEST4: MOV #STACK,$SP ;SETUP THE STACK POINTER
CLR TIMEA ;CLEAR THE TIMEOUT VALUE STORAGE LOCATION
CLR TIMEAP ;CLEAR THE + 25% TOLERANCE LOCATION
```

;START THE TIMER

```
CLR TIME ;CLEAR THE ELAPSED TIME COUNTER
MOV #2000.,WATCH ;SET WATCH TO 2000 MS
```

;SEIZE THE DRIVE THROUGH PORT A

```
MOVB PORTA,$RPCS2($R0) ;SELECT PORT A
MOV PORTA,$SEIZPT ;STORE SEIZING PORT'S ADDRESS
CLR RPDS1($R0) ;WRITE RPDS1
MOVB PORTB,$RPCS2($R0) ;SELECT PORT B
MOV PORTB,$PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
MOV PORTB,$OPPR ;'OPPOSITE' PORT ADDRESS
MOV RPDS1($R0),$SBDAT ;SEE IF DRIVE SEIZED BY PORT A
MOV $R0,$SBDADR ;RHI1 BASE ADDRESS
ADD #RPDS1,$SBDADR ;GENERATE BAD REGISTER ADDRESS
CLR $GDDAT ;REGISTER SHOULD BE ZERO
CMP $GDDAT,$SBDAT ;IS THE REGISTER ZERO
BEQ 645 ;BR IF IT IS
ERROR 30 ;REPORT THE ERROR
JMP 45 ;BYPASS REST OF THE SUBTEST

645: MOVB PORTA,$RPCS2($R0) ;SELECT PORT A
MOV PORTA,$PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
MOV RPDS1($R0),$SBDAT ;SEE IF SEIZING PORT SEES CORRECT STATUS
MOV #MOL!PGH!DPR!DRY!VV,$GDDAT ;EXPECTED STATUS
MOV $GDDAT,$STMP1 ;USE GOOD DATA AS A MASK
COM $STMP1 ;COMPLEMENT THE EXPECTED STATUS
MOV $SBDAT,$STMP0 ;SAVE THE ACTUAL STATUS
```



```

2109 006132 043737 001166 001164      BIC      STMP1,STMP0      ;CLEAR UNWANTED BITS
2110 006140 023737 001124 001164      CMP      $GDDAT,STMP0    ;ARE THE EXPECTED STATUS BITS SET ?
2111 006146 001401                      BEQ      65$             ;BR IF THEY ARE
2112 006150 104031                      ERROR    31             ;REPORT THE ERROR
2113 006152 000240      65$:      NOP
2114
2115      ;:*****
2116      ;WAIT FOR PORT A TO TIMEOUT
2117
2118 006154 113760 001226 000010      MOVB     PORTB,RPCS2(RO) ;SELECT PORT B
2119 006162 013737 001226 001234      MOV      PORTB,PTNBR    ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
2120 006170 005760 000012      1$:      TST      RPDS1(RO)      ;WAIT FOR THE DRIVE TO TIMEOUT
2121 006174 001006                      BNE      2$             ;BR WHEN TIMEOUT OCCURS
2122 006176 005737 001254      TST      WATCH          ;CHECK WATCH
2123 006202 001372                      BNE      1$             ;BR IF NOT ZERO
2124 006204 104006                      ERROR    6              ;NO TIMEOUT WITHIN 2 SECONDS
2125 006206 000137 006244                      JMP      3$             ;BYPASS THE REST OF THE TEST
2126 006212 013737 001252 001256      2$:      MOV      TIME,TIMEA     ;SAVE THE ELAPSED TIME FOR PORT A
2127 006220 004537 020130      JSR      R5,TOLER       ;CALCULATE THE TOLERANCE
2128 006224 001256                      .WORD   TIMEA           ;TIMEOUT VALUE FOR PORT A
2129 006226 012637 001260      MOV      (SP)+,TIMEAP   ;+25% TOLERANCE
2130
2131      ;:*****
2132      ;VERIFY THAT THE TIMEOUT ONE-SHOT VALUE IS AT LEAST 500 MS
2133
2134 006232 023727 001256 000764      CMP      TIMEA,#500.    ;IS TIMEOUT VALUE AT LEAST 500 MS ?
2135 006240 103001                      BHS     3$             ;BR IF IT IS
2136 006242 104007                      ERROR    7             ;TIMEOUT LESS THAN 500 MS
2137
2138      ;:*****
2139      ;VERIFY THAT THE DRIVE RETURNED TO NEUTRAL AFTER PORT A TIMED OUT
2140
2141 006244      3$:
2142
2143      ;VERIFY THAT THE DRIVE IS IN NEUTRAL
2144
2145 006244 005037 001250                      CLR      RELERR         ;CLEAR THE 'RELEASE ERROR' INDICATOR
2146 006250 012737 000012 001122      MOV      #RPDS1,$BDADR  ;FORM THE ADDRESS OF RPDS1 FOR TYPEOUT
2147 006256 060037 001122                      ADD      RO,$BDADR      ;ADD THE I/O BASE ADDRESS
2148 006262 012737 011700 001124      MOV      #MOL!PGM!DPR!DRY!VV,$GDDAT ;COMPARISON CONSTANT
2149 006270 113760 001224 000010      MOVB     PORTA,RPCS2(RO) ;SELECT PORT A.
2150 006276 016037 000012 001170      MOV      RPDS1(RO),STMP2 ;GET THE DRIVE STATUS REGISTER FROM PORT A.
2151 006304 013737 001170 001164      MOV      STMP2,STMP0    ;COPY IT INTO 'STMP0'
2152 006312 042737 100100 001164      BIC      #ATA!VV,STMP0  ;CLEAR PORT DEPENDENT BITS FROM THE COPY
2153 006320 113760 001226 000010      MOVB     PORTB,RPCS2(RO) ;SELECT PORT B.
2154 006326 016037 000012 001172      MOV      RPDS1(RO),STMP3 ;GET THE DRIVE STATUS REGISTER FROM PORT B.
2155 006334 013737 001172 001166      MOV      STMP3,STMP1    ;COPY IT INTO 'STMP1'
2156 006342 042737 100100 001166      BIC      #ATA!VV,STMP1  ;CLEAR PORT DEPENDENT BITS FROM THE COPY
2157 006350 023737 001164 001166      CMP      STMP0,STMP1    ;IS THE STATUS REGISTER THE SAME FROM BOTH PORTS ?
2158 006356 001006                      BNE     66$            ;BR IF NOT
2159 006360 005737 001164                      TST     STMP0          ;REGISTERS ARE THE SAME: ARE THEY ZERO ?
2160 006364 001045                      BNE     68$            ;BR IF NOT
2161 006366 104034                      ERROR    34           ;REPORT DRIVE NOT IN NEUTRAL OR NOT SEIZED
2162 006370 000137 006570                      JMP     70$            ;BYPASS THE REST OF THE CHECKS
2163 006374 013737 001170 001126      66$:      MOV     STMP2,$BDADR   ;SET UP POSSIBLE BAD DATA FOR ERROR MESSAGE
2164 006402 013737 001226 001234      MOV     PORTB,PTNBR   ;SEIZING PORT IF TEST SHOWS DRIVE NOT IN NEUTRAL
    
```



```

2165 006410 113760 001226 000010      MOVB  PORTB,RPCS2(RO) ;SELECT PORT B.
2166 006416 005737 001164              TST   $TMP0           ;SEE IF STATUS EQ 0 FROM PORT A.
2167 006422 001414 67$              BEQ   67$             ;BR IF ZERO
2168 006424 013737 001224 001234      MOV   PORTA,PTNBR    ;SEIZING PORT IF TEST SHOWS DRIVE NOT IN NEUTRAL
2169 006432 013737 001172 001126      MOV   $TMP3,$BDDAT  ;'BAD DATA' FOR ERROR TYPE OUT
2170 006440 113760 001224 000010      MOVB  PORTA,RPCS2(RO) ;SELECT PORT A.
2171 006446 005737 001166              TST   $TMP1           ;SEE IF STATUS EQ ZERO FROM PORT B.
2172 006452 001012 68$              BNE   68$            ;BR IF NOT
2173 006454 012737 177777 001250 67$:      MOV   #-1,RELEERR   ;SET 'RELEASE ERROR' INDICATOR
2174 006462 012760 000011 000000      MOV   #11,RPCS1(RO) ;CLEAR THE DRIVE
2175 006470 012760 000013 000000      MOV   #13,RPCS1(RO) ;RELEASE THE DRIVE
2176 006476 104035 68$:      ERROR 35           ;TYPE ERROR MESSAGE 35
2177 006500 013737 001170 001126      MOV   $TMP2,$BDDAT  ;LOOK FOR BIT FAILURES WHEN RPDS1 READ
2178 006506 013737 001224 001234      MOV   PORTA,PTNBR   ;CHANGE PORT NUMBER
2179 006514 042737 100000 001170      BIC   #ATA,$TMP2    ;DON'T CHECK THE ATTN BIT
2180 006522 023737 001124 001170      CMP   $GDDAT,$TMP2  ;ALL BITS OK ?
2181 006530 001401 69$:      BEQ   69$            ;BR IF OK FROM PORT A.
2182 006532 104037 69$:      ERROR 37           ;REPORT ERROR
2183 006534 013737 001172 001126      MOV   $TMP3,$BDDAT  ;CHECK RPDS1 FOR BIT FAILURES - FROM PORT B.
2184 006542 013737 001226 001234      MOV   PORTB,PTNBR   ;CHANGE PORT NUMBER
2185 006550 042737 100000 001172      BIC   #ATA,$TMP3    ;DON'T CHECK THE ATTN BIT
2186 006556 023737 001124 001172      CMP   $GDDAT,$TMP3  ;SEE IF READ OK FROM PORT B.
2187 006564 001401 70$:      BEQ   70$            ;BR IF OK
2188 006566 104037 70$:      ERROR 37           ;REPORT THE ERROR
2189 006570 000240 4$:      NOP
2190 006572 000004 4$:      SCOPE ;LOOP ?

```

```

*****
*TEST 5      MEASURE THE TIMEOUT ONE-SHOT THROUGH PORT B
*
*MEASURE THE TIMEOUT ONE-SHOT VALUE THROUGH PORT B
*
* A. WRITE 0'S INTO RPDS1 THROUGH PORT B AND VERIFY THAT THE
*     DRIVE HAS BEEN SEIZED.
*
* B. WAIT FOR TIMEOUT TO OCCUR. MEASURE THE DURATION OF THE TIMEOUT
*     ONE-SHOT AND SAVE THE VALUE FOR LATER USE.
*
* C. VERIFY THAT THE TIMEOUT OCCURRED AND THAT THE DRIVE RETURNS
*     TO NEUTRAL
*****

```

```

2208 006574 005737 001266      TST5:  TST   KYBCTL      ;PERFORMING ONLY SINGLE TESTS ?
2209 006574 001406 2$:      BEQ   2$             ;BR IF NOT
2210 006600 100002 1$:      BPL   1$             ;BR IF JUST ENTERED TEST
2211 006602 000137 002424      JMP   EXEC           ;RETURN & GET NEXT TEST NUMBER
2212 006604 012737 177777 001266 1$:      MOV   #-1,KYBCTL    ;SET SINGLE TEST INDICATOR
2213 006610 012737 000005 001102 2$:      MOVB  #5,$STSTNM    ;TEST NUMBER
2214 006616 012737 006646 001106      MOV   #TEST5,$LPADR ;LOAD LOOP ON TEST ADDRESS
2215 006624 012737 006646 001110      MOV   #TEST5,$LPERR ;LOAD LOOP ON ERROR ADDRESS
2216 006632 012737 000001 001176      MOV   #1,$TIMES     ;DO 1 ITERATION
2217 006640 012737 001100      MOV   #STACK,$SP    ;SETUP THE STACK POINTER
2218 006646 005037 001262      CLR   TIMEB         ;CLEAR THE TIMEOUT VALUE STORAGE LOCATION
2219 006652 005037 001264      CLR   TIMEBP        ;CLEAR THE + 25% TOLERANCE LOCATION
2220 006656 005037 001264

```



```

2221
2222
2223
2224
2225 006662 005037 001252          CLR    TIME          ;CLEAR THE ELAPSED TIME COUNTER
2226 006666 012737 003720 001254  MOV    #2000.,WATCH  ;SET WATCH TO 2000 MS
2227
2228
2229
2230
2231
2232
2233 006674 113760 001226 000010  MOVB   PORTB,RPCS2(RO) ;SELECT PORT B
2234 006702 013737 001226 001236  MOV    PORTB,SEIZPT ;STORE SEIZING PORT'S ADDRESS
2235 006710 005060 000012          CLR    RPDS1(RO)      ;WRITE RPDS1
2236 006714 113760 001224 000010  MOVB   PORTA,RPCS2(RO) ;SELECT PORT A
2237 006722 013737 001224 001234  MOV    PORTA,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
2238 006730 013737 001224 001240  MOV    PORTA,OPPRT ;'OPPOSITE' PORT ADDRESS
2239 006736 016037 000012 001126  MOV    RPDS1(RO),SBDAT ;SEE IF DRIVE SEIZED BY PORT B
2240 006744 010037 001122          MOV    RO,SBDADR ;R#11 BASE ADDRESS
2241 006750 062737 000012 001122  ADD    #RPDS1,SBDADR ;GENERATE BAD REGISTER ADDRESS
2242 006756 005037 001124          CLR    SGDAT ;REGISTER SHOULD BE ZERO
2243 006762 023737 001124 001126  CMP    SGDAT,SBDAT ;IS THE REGISTER ZERO
2244 006770 001403          BEQ    64$ ;BR IF IT IS
2245 006772 104030          ERROR  30 ;REPORT THE ERROR
2246 006774 100137 007510          JMP    4$ ;BYPASS REST OF THE SUBTEST
2247 007000          64$:
2248 007000 113760 001226 000010  MOVB   PORTB,RPCS2(RO) ;SELECT PORT B
2249 007006 013737 001226 001234  MOV    PORTB,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
2250 007014 016037 000012 001126  MOV    RPDS1(RO),SBDAT ;SEE IF SEIZING PORT SEES CORRECT STATUS
2251 007022 012737 011700 001124  MOV    #MOL!PGM!DPR!DRY!VV,SGDAT ;EXPECTED STATUS
2252 007030 013737 001124 001166  MOV    SGDAT,STMP1 ;USE GOOD DATA AS A MASK
2253 007036 005137 001166          COM    STMP1 ;COMPLEMENT THE EXPECTED STATUS
2254 007042 013737 001126 001164  MOV    SBDAT,STMP0 ;SAVE THE ACTUAL STATUS
2255 007050 043737 001166 001164  BIC    STMP1,STMP0 ;CLEAR UNWANTED BITS
2256 007056 023737 001124 001164  CMP    SGDAT,STMP0 ;ARE THE EXPECTED STATUS BITS SET ?
2257 007064 001401          BEQ    65$ ;BR IF THEY ARE
2258 007066 104031          ERROR  31 ;REPORT THE ERROR
2259 007070 000240          65$:
2260          NOP
2261
2262
2263
2264 007072 113760 001224 000010  MOVB   PORTA,RPCS2(RO) ;SELECT PORT A
2265 007100 013737 001224 001234  MOV    PORTA,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
2266 007106 005760 000012          TST    RPDS1(RO) ;WAIT FOR THE DRIVE TO TIMEOUT
2267 007112 001006          BNE    2$ ;BR WHEN TIMEOUT OCCURS
2268 007114 005737 001254          TST    WATCH ;CHECK WATCH
2269 007120 001372          BNE    1$ ;BR IF NOT ZERO
2270 007122 104005          ERROR  6 ;NO TIMEOUT WITHIN 2 SECONDS
2271 007124 000137 007162          JMP    3$ ;BYPASS THE REST OF THE TEST
2272 007130 013737 001252 001262 2$: MOV    TIME,TIMEB ;SAVE THE ELAPSED TIME FOR PORT B
2273 007136 004537 020130          JSR    RS,TOLER ;CALCULATE THE TOLERANCE
2274 007142 001262          WORD  TIMEB ;TIMEOUT VALUE FOR PORT B
2275 007144 012637 001264          MOV    (SP)+,TIMEBP ;+25% TOLERANCE
2276

```


E04

```
2277 ;VERIFY THAT THE TIMEOUT ONE-SHOT VALUE IS AT LEAST 500 MS
2278
2279 007150 023727 001262 000764      CMP      TIMEB,#500.      ;IS TIMEOUT VALUE AT LEAST 500 MS ?
2280 007156 103001                    BHIS     35                ;BR IF IT IS
2281 007160 104007                    ERROR    7                ;TIMEOUT LESS THAN 500 MS
2282
2283 ::*****
2284 ;VERIFY THAT THE DRIVE RETURNED TO NEUTRAL AFTER PORT B TIMED OUT
2285
2286 007162      35:
2287
2288 ;VERIFY THAT THE DRIVE IS IN NEUTRAL
2289
2290 007162 005037 001250      CLR      RELERR          ;CLEAR THE 'RELEASE ERROR' INDICATOR
2291 007166 012737 000012 001122      MOV      #RPDS1,$BDDADR ;FORM THE ADDRESS OF RPDS1 FOR TYPEOUT
2292 007174 060037 001122      ADD      R0,$BDDADR     ;ADD THE I/O BASE ADDRESS
2293 007200 012737 011700 001124      MOV      #M0L!PGM!DPR!DRY!VV,$GDDAT ;COMPARISON CONSTANT
2294 007206 113760 001224 000010      MOV      PORTA,RPDS2(R0) ;SELECT PORT A.
2295 007214 016037 000012 001170      MOV      RPDS1(R0),STMP2 ;GET THE DRIVE STATUS REGISTER FROM PORT A.
2296 007222 013737 001170 001164      MOV      STMP2,STMP0     ;COPY IT INTO 'STMP0'
2297 007230 042737 100100 001164      BIC      #ATA!VV,STMP0   ;CLEAR PORT DEPENDENT BITS FROM THE COPY
2298 007236 113760 001226 000010      MOV      PORTB,RPDS2(R0) ;SELECT PORT B.
2299 007244 016037 000012 001172      MOV      RPDS1(R0),STMP3 ;GET THE DRIVE STATUS REGISTER FROM PORT B.
2300 007252 013737 001172 001166      MOV      STMP3,STMP1     ;COPY IT INTO 'STMP1'
2301 007260 042737 100100 001166      BIC      #ATA!VV,STMP1   ;CLEAR PORT DEPENDENT BITS FROM THE COPY
2302 007266 023737 001164 001166      CMP      STMP0,STMP1     ;IS THE STATUS REGISTER THE SAME FROM BOTH PORTS ?
2303 007274 001006                    BNE      66$             ;BR IF NOT
2304 007276 005737 001164                    TST      STMP0           ;REGISTERS ARE THE SAME: ARE THEY ZERO ?
2305 007302 001045                    BNE      68$             ;BR IF NOT
2306 007304 104034                    ERROR    34             ;REPORT DRIVE NOT IN NEUTRAL OR NOT SEIZED
2307 007306 000137 007506                    JMP      70$             ;BYPASS THE REST OF THE CHECKS
2308 007312 013737 001170 001126 66$:      MOV      STMP2,$BDDAT    ;SET UP POSSIBLE BAD DATA FOR ERROR MESSAGE
2309 007320 013737 001226 001234      MOV      PORTB,PTNBR     ;SEIZING PORT IF TEST SHOWS DRIVE NOT IN NEUTRAL
2310 007326 113760 001226 000010      MOV      PORTB,RPDS2(R0) ;SELECT PORT B.
2311 007334 005737 001164                    TST      STMP0           ;SEE IF STATUS EQ 0 FROM PORT A.
2312 007340 001414                    BEQ      67$             ;BR IF ZERO
2313 007342 013737 001224 001234      MOV      PORTA,PTNBR     ;SEIZING PORT IF TEST SHOWS DRIVE NOT IN NEUTRAL
2314 007350 013737 001172 001126      MOV      STMP3,$BDDAT    ;'BAD DATA' FOR ERROR TYPE OUT
2315 007356 113760 001224 000010      MOV      PORTA,RPDS2(R0) ;SELECT PORT A.
2316 007364 005737 001166                    TST      STMP1           ;SEE IF STATUS EQ ZERO FROM PORT B.
2317 007370 001012                    BNE      68$             ;BR IF NOT
2318 007372 012737 177777 001250 67$:      MOV      #-1,RELERR      ;SET 'RELEASE ERROR' INDICATOR
2319 007400 012760 000011 000000      MOV      #11,RPDS1(R0)   ;CLEAR THE DRIVE
2320 007406 012760 000013 000000      MOV      #13,RPDS1(R0)   ;RELEASE THE DRIVE
2321 007414 104035                    ERROR    35             ;TYPE ERROR MESSAGE 35
2322 007416 013737 001170 001126 68$:      MOV      STMP2,$BDDAT    ;LOOK FOR BIT FAILURES WHEN RPDS1 READ
2323 007424 013737 001224 001234      MOV      PORTA,PTNBR     ;CHANGE PORT NUMBER
2324 007432 042737 100000 001170      BIC      #ATA,STMP2      ;DON'T CHECK THE ATTN BIT
2325 007440 023737 001124 001170      CMP      $GDDAT,STMP2    ;ALL BITS OK ?
2326 007446 001401                    BEQ      69$             ;BR IF OK FROM PORT A.
2327 007450 104037                    ERROR    37             ;REPORT ERROR
2328 007452 013737 001172 001126 69$:      MOV      STMP3,$BDDAT    ;CHECK RPDS1 FOR BIT FAILURES - FROM PORT B.
2329 007460 013737 001226 001234      MOV      PORTB,PTNBR     ;CHANGE PORT NUMBER
2330 007466 042737 100000 001172      BIC      #ATA,STMP3      ;DON'T CHECK THE ATTN BIT
2331 007474 023737 001124 001172      CMP      $GDDAT,STMP3    ;SEE IF READ OK FROM PORT B.
2332 007502 001401                    BEQ      70$             ;BR IF OK
```


F04

```

2333 007504 104037      ERROR    37                    ;REPORT THE ERROR
2334 007506 000240      70$:    NOP
2335 007510 000004      4$:     SCOPE               ;LOOP ?
  
```

```

2336
2337
2338
2339 *****
2340 *TEST 6            TEST UNLOAD COMMAND THROUGH PORT A
2341 *
2342 *VERIFY THAT THE UNLOAD COMMAND FUNCTIONS PROPERLY AND THAT A PORT
2343 *            TIMEOUT WILL NOT OCCUR WHILE THE 'GO' BIT IS SET.
2344 *
2345 *    A.    ISSUE AN UNLOAD COMMAND THROUGH PORT A; VERIFY THAT THE
2346 *            DRIVE IS SEIZED.
2347 *
2348 *    B.    WAIT THE MEASURED TIMEOUT INTERVAL + 25%; VERIFY THAT THE DRIVE
2349 *            DOES NOT TIME OUT. VERIFY THAT THE 'GO' BIT IS STILL SET AND
2350 *            THAT 'DRY' AND 'PIP' ARE NOT SET.
2351 *
2352 *    C.    REQUEST THAT THE OPERATOR PRESS THE 'STANDBY' BUTTON ON THE DRIVE.
2353 *
2354 *    D.    WHEN THE DRIVE CYCLES UP, VERIFY THAT THE DRIVE IS STILL SEIZED
2355 *            BY PORT A, THAT THE 'VV' BIT FOR PORT A IS RESET, THAT THE
2356 *            ATTENTION BIT FOR PORT A IS SET, AND THAT THE ATTENTION BIT
2357 *            FOR PORT B IS NOT SET.
2358 *
2359 *    E.    WAIT FOR THE PORT TIMEOUT TO RELEASE THE DRIVE. WHEN THE TIMEOUT
2360 *            OCCURS, VERIFY THAT THE DRIVE RETURNED TO NEUTRAL, THAT THE
2361 *            ATTENTION BIT FOR PORT A IS STILL SET, AND THAT THE ATTENTION
2362 *            BIT FOR PORT B IS NOT SET.
2363 *
2364 *    F.    VERIFY THAT THE 'VV' BIT FOR PORT B IS NOT SET.
2365 *
2366 *    G.    ISSUE A PACK ACKNOWLEDGE INSTRUCTION THROUGH BOTH PORTS.
  
```

```

2367 *****
2368 T5T6:            TST            KYBCTL            ;PERFORMING ONLY SINGLE TESTS ?
2369 007512 005737 001266    BEQ            2$            ;BR IF NOT
2370 007516 001406    BPL            1$            ;BR IF JUST ENTERED TEST
2371 007520 100002    JMP            EXEC           ;RETURN & GET NEXT TEST NUMBER
2372 007522 000137 002424    MOV            0-1, KYBCTL       ;SET SINGLE TEST INDICATOR
2373 007526 012737 177777 001266 1$:    MOV            06, $TSTNM       ;TEST NUMBER
2374 007534 112737 000006 001102 2$:    MOV            0TEST6, $LPADR   ;LOAD LOOP ON TEST ADDRESS
2375 007542 012737 007564 001106    MOV            0TEST6, $LPERR   ;LOAD LOOP ON ERROR ADDRESS
2376 007550 012737 007564 001110    MOV            01, $TIMES       ;DO 1 ITERATION
2377 007556 012737 000001 001176    MOV            0STACK, SP       ;SETUP THE STACK POINTER
2378 007564 012706 001100
2379
2380                   ;CLEAR ATTENTION BITS FOR BOTH PORTS
2381
2382 007570 113760 001224 000010    MOV            PORTA, RPCS2(RO) ;SELECT PORT #A
2383 007576 005060 000012    CLR            RPS1(RO)       ;SEIZE THE DRIVE
2384 007602 012760 000011 000000    MOV            011, RPCS1(RO)   ;ISSUE DRIVE CLEAR
2385 007610 012760 000013 000000    MOV            013, RPCS1(RO)   ;RELEASE THE DRIVE
2386 007616 113760 001226 000010    MOV            PORTB, RPCS2(RO) ;SELECT PORT #B
2387 007624 005060 000012    CLR            RPS1(RO)       ;SEIZE THE DRIVE THROUGH PORT 'B'
2388 007630 012760 000011 000000    MOV            011, RPCS1(RO)   ;ISSUE DRIVE CLEAR
  
```


G04

```

2389 007636 012760 000013 000000      MOV      #13,RPCS1(RO) ;RELEASE THE DRIVE
2390 007644 113760 001224 000010      MOV     PORTA,RPCS2(RO) ;SELECT PORT A
2391 007652 013737 001224 001234      MOV     PORTA,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
2392 007660 013737 001224 001236      MOV     PORTA,SEIZPT ;SEIZING PORT'S ADDRESS
2393
2394
2395
2396
2397 007666 012760 000003 000000      MOV      #3,RPCS1(RO) ;ISSUE AN UNLOAD COMMAND THROUGH PORT A
2398 007674 013737 001260 001254      MOV     TIMEAP,WATCH ;TIMEOUT ONSHOT VALUE + 25%
2399 007702 005737 001254      IS:     TST      WATCH ;FINISHED TIMEOUT ?
2400 007706 001375      BNE     IS ;BR IF NOT
2401
2402
2403
2404
2405
2406
2407
2408
2409
2410
2411
2412
2413
2414
2415
2416
2417
2418
2419
2420
2421
2422
2423
2424
2425
2426
2427
2428
2429
2430
2431
2432
2433
2434
2435
2436
2437
2438
2439
2440
2441
2442
2443
2444
2445
2446
2447
2448
2449
2450
2451
2452
2453
2454
2455
2456
2457
2458
2459
2460
2461
2462
2463
2464
2465
2466
2467
2468
2469
2470
2471
2472
2473
2474
2475
2476
2477
2478
2479
2480
2481
2482
2483
2484
2485
2486
2487
2488
2489
2490
2491
2492
2493
2494
2495
2496
2497
2498
2499
2500

```

;DO AN UNLOAD COMMAND THROUGH PORT A

;IS THE STATUS OK ?

```

64S: CLR      CKERR ;CLEAR THE 'CHECK ERROR' INDICATOR
      MOV     RPCS1(RO),SBDAT ;GET CONTENTS OF RPCS1
      MOV     #RPCS1,SBDADR ;FORM REGISTER ADDRESS OF ERROR MESSAGE
      ADD     RO,SBDADR ;ADD RH11 BASE ADDRESS
      MOV     #DVA!GO,SGDAT ;WHAT REGISTER SHOULD BE
      MOV     SBDAT,STMP0 ;MOVE REGISTER CONTENTS TO 'STMP0'
      BIC     #1C4001,STMP0 ;SAVE SPECIFIED BITS
      CMP     SGDAT,STMP0 ;COMPARE THE BITS
      BEQ     64S ;BR IF OK
      MOV     SBDAT,STMP4 ;COPY 'BAD DATA'
      BIC     #4001,STMP4 ;CLEAR THE MASKED BITS
      BIS     STMP4,SGDAT ;'OR' WITH GOOD DATA FOR TYPEOUT
      ERROR  11 ;TYPE MESSAGE 11
      COM     CKERR ;SET THE REGISTER COMPARE ERROR INDICATOR

```

```

66S: CLR      CKERR ;CLEAR THE 'CHECK ERROR' INDICATOR
      MOV     RPDS1(RO),SBDAT ;GET CONTENTS OF RPDS1
      MOV     #RPDS1,SBDADR ;FORM REGISTER ADDRESS OF ERROR MESSAGE
      ADD     RO,SBDADR ;ADD RH11 BASE ADDRESS
      MOV     #PIP!PGM!DPR,SGDAT ;WHAT REGISTER SHOULD BE
      MOV     SBDAT,STMP0 ;MOVE REGISTER CONTENTS TO 'STMP0'
      BIC     #1C177600,STMP0 ;SAVE SPECIFIED BITS
      CMP     SGDAT,STMP0 ;COMPARE THE BITS
      BEQ     66S ;BR IF OK
      MOV     SBDAT,STMP4 ;COPY 'BAD DATA'
      BIC     #177600,STMP4 ;CLEAR THE MASKED BITS
      BIS     STMP4,SGDAT ;'OR' WITH GOOD DATA FOR TYPEOUT
      ERROR  12 ;TYPE MESSAGE 12
      COM     CKERR ;SET THE REGISTER COMPARE ERROR INDICATOR

```

```

66S: NOP
      TYPE   STANDBY ;TYPE THE STANDBY MESSAGE
      MOV     PORTA,-(SP) ;SAVE PORTA FOR TYPEOUT
      ;TYPE THE PORT NUMBER
      ;GO TYPE--OCTAL ASCII
      ;TYPE 1 DIGIT(S)
      ;SUPPRESS LEADING ZEROS
      TYPE   ,SCLF ;CR-LF

```

;WAIT FOR 'MOL' TO SET

H04

```
2445 010150 032760 010000 000012 25: BIT #MOL,RPDS1(RO) ;WAIT FOR MOL TO SET
2446 010156 001774 BEQ 25 ;LOOP UNTIL 'MOL' SETS
2447 010160 012737 003720 001254 MOV #2000, WATCH ;SETUP A 2 SECOND STALL
2448 010166 113760 001226 000010 MOV#B PORTB,RPDS2(RO) ;SELECT PORT B
2449 010174 013737 001226 001234 MOV PORTB,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
2450 010202 005760 000012 35: TST RPDS1(RO) ;DRIVE TIMEDOUT ?
2451 010206 001004 BNE 45 ;BR IF IT HAS
2452 010210 005737 001254 TST WATCH ;2 SECONDS ELAPSED ?
2453 010214 001372 BNE 35 ;BR IF NOT
2454 010216 104006 ERROR 6 ;NO TIMEOUT AFTER 2 SECONDS
2455
2456
2457
2458 010220 ;*****
2459 45: ;VERIFY THAT THE DRIVE IS IN NEUTRAL
2460
2461
2462 010220 005037 001250 CLR RELERR ;CLEAR THE 'RELEASE ERROR' INDICATOR
2463 010224 012737 000012 001122 MOV #RPDS1,SBDADR ;FORM THE ADDRESS OF RPDS1 FOR TYPEOUT
2464 010232 060037 001122 ADD RO,SBDADR ;ADD THE I/O BASE ADDRESS
2465 010236 012737 011600 001124 MOV #MOL!PGM!DPR!DRY,$GDDAT ;COMPARISON CONSTANT
2466 010244 113760 001224 000010 MOV#B PORTA,RPDS2(RO) ;SELECT PORT A.
2467 010252 016037 000012 001170 MOV RPDS1(RO),STMP2 ;GET THE DRIVE STATUS REGISTER FROM PORT A.
2468 010260 013737 001170 001164 MOV STMP2,STMP0 ;COPY IT INTO 'STMP0'
2469 010266 042737 100100 001164 BIC #ATA!VV,STMP0 ;CLEAR PORT DEPENDENT BITS FROM THE COPY
2470 010274 113760 001226 000010 MOV#B PORTB,RPDS2(RO) ;SELECT PORT B.
2471 010302 016037 000012 001172 MOV RPDS1(RO),STMP3 ;GET THE DRIVE STATUS REGISTER FROM PORT B.
2472 010310 013737 001172 001166 MOV STMP3,STMP1 ;COPY IT INTO 'STMP1'
2473 010316 042737 100100 001166 BIC #ATA!VV,STMP1 ;CLEAR PORT DEPENDENT BITS FROM THE COPY
2474 010324 023737 001164 001166 CMP STMP0,STMP1 ;IS THE STATUS REGISTER THE SAME FROM BOTH PORTS ?
2475 010332 001006 BNE 685 ;BR IF NOT
2476 010334 005737 001164 TST STMP0 ;REGISTERS ARE THE SAME: ARE THEY ZERO ?
2477 010340 001037 BNE 705 ;BR IF NOT
2478 010342 104034 ERROR 34 ;REPORT DRIVE NOT IN NEUTRAL OR NOT SEIZED
2479 010344 000137 010530 JMP 725 ;BYPASS THE REST OF THE CHECKS
2480 010350 013737 001170 001126 685: MOV STMP2,SBDAT ;SET UP POSSIBLE BAD DATA FOR ERROR MESSAGE
2481 010356 013737 001226 001234 MOV PORTB,PTNBR ;SEIZING PORT IF TEST SHOWS DRIVE NOT IN NEUTRAL
2482 010364 113760 001226 000010 MOV#B PORTB,RPDS2(RO) ;SELECT PORT B.
2483 010372 005737 001164 TST STMP0 ;SEE IF STATUS EQ 0 FROM PORT A.
2484 010376 001414 BEQ 695 ;BR IF ZERO
2485 010400 013737 001224 001234 MOV PORTA,PTNBR ;SEIZING PORT IF TEST SHOWS DRIVE NOT IN NEUTRAL
2486 010406 013737 001172 001126 MOV STMP3,SBDAT ;'BAD DATA' FOR ERROR TYPE OUT
2487 010414 113760 001224 000010 MOV#B PORTA,RPDS2(RO) ;SELECT PORT A.
2488 010422 005737 001166 TST STMP1 ;SEE IF STATUS EQ ZERO FROM PORT B.
2489 010426 001004 BNE 705 ;BR IF NOT
2490 010430 012737 177777 001250 695: MOV #1,RELERR ;SET 'RELEASE ERROR' INDICATOR
2491 010436 104013 ERROR 13 ;TYPE ERROR MESSAGE 13
2492 010440 013737 001170 001126 705: MOV STMP2,SBDAT ;LOOK FOR BIT FAILURES WHEN RPDS1 READ
2493 010446 013737 001224 001234 MOV PORTA,PTNBR ;CHANGE PORT NUMBER
2494 010454 042737 100100 001170 BIC #ATA!VV,STMP2 ;DON'T CHECK ATTN BIT OR VV BIT
2495 010462 023737 001124 001170 CMP $GDDAT,STMP2 ;ALL BITS OK ?
2496 010470 001401 BEQ 715 ;BR IF OK FROM PORT A.
2497 010472 104037 ERROR 37 ;REPORT ERROR
2498 010474 013737 001172 001126 715: MOV STMP3,SBDAT ;CHECK RPDS1 FOR BIT FAILURES - FROM PORT B.
2499 010502 013737 001226 001234 MOV PORTB,PTNBR ;CHANGE PORT NUMBER
2500 010510 042737 100100 001172 BIC #ATA!VV,STMP3 ;DON'T CHECK ATTN BIT OR VV BIT
```


2501 010516 023737 001124 001172
2502 010524 001401
2503 010526 104037
2504 010530 000240
2505
2506
2507
2508 010532 113760 001226 000010
2509 010540 013737 001226 001234
2510 010546 005037 001244
2511 010552 016037 000012 001126
2512 010560 012737 000012 001122
2513 010566 060037 001122
2514 010572 005037 001124
2515 010576 013737 001126 001164
2516 010604 042737 077777 001164
2517 010612 023737 001124 001164
2518 010620 001414
2519 010622 013737 001126 001174
2520 010630 042737 100000 001174
2521 010636 053737 001174 001124
2522 010644 104014
2523 010646 005137 001244
2524 010652 000240
2525 010654 113760 001224 000010
2526 010662 013737 001224 001234
2527 010670 005037 001244
2528 010674 016037 000012 001126
2529 010702 012737 000012 001122
2530 010710 060037 001122
2531 010714 012737 100000 001124
2532 010722 013737 001126 001164
2533 010730 042737 077777 001164
2534 010736 023737 001124 001164
2535 010744 001414
2536 010746 013737 001126 001174
2537 010754 042737 100000 001174
2538 010762 053737 001174 001124
2539 010770 104015
2540 010772 005137 001244
2541 010776 000240
2542
2543
2544
2545
2546 011000 012760 000011 000000
2547 011006 012760 000021 000000
2548 011014 012760 000013 000000
2549 011022 113760 001226 000010
2550 011030 012760 000021 000000
2551 011036 012760 010000 000032
2552 011044 012760 000013 000000
2553 011052 012737 011610 001254
2554 011060 005737 001254
2555 011064 001375
2556 011066 000004

CMP SGDDAT,STMP3 ;SEE IF READ OK FROM PORT B.
BEQ 72\$;BR IF OK
ERROR 37 ;REPORT THE ERROR
NOP
72\$:
;*****
;CHECK THE ATTENTION BITS
MOVB PORTB,RPCS2(RO) ;SELECT PORT B
MOV PORTB,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
CLR CKERR ;CLEAR THE 'CHECK ERROR' INDICATOR
MOV RPDS1(RO),SBDDAT ;GET CONTENTS OF RPDS1
MOV #RPDS1,SBADR ;FORM REGISTER ADDRESS OF ERROR MESSAGE
ADD RO,SBADR ;ADD R#11 BASE ADDRESS
CLR SGDDAT ;WHAT REGISTER SHOULD BE
MOV SBDDAT,STMP0 ;MOVE REGISTER CONTENTS TO 'STMP0'
BIC #1CATA,STMP0 ;SAVE SPECIFIED BITS
CMP SGDDAT,STMP0 ;COMPARE THE BITS
BEQ 73\$;BR IF OK
MOV SBDDAT,STMP4 ;COPY 'BAD DATA'
BIC #ATA,STMP4 ;CLEAR THE MASKED BITS
BIS STMP4,SGDDAT ;'OR' WITH GOOD DATA FOR TYPEOUT
ERROR 14 ;TYPE MESSAGE 14
COM CKERR ;SET THE REGISTER COMPARE ERROR INDICATOR
NOP
73\$:
MOVB PORTA,RPCS2(RO) ;SELECT PORT A
MOV PORTA,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
CLR CKERR ;CLEAR THE 'CHECK ERROR' INDICATOR
MOV RPDS1(RO),SBDDAT ;GET CONTENTS OF RPDS1
MOV #RPDS1,SBADR ;FORM REGISTER ADDRESS OF ERROR MESSAGE
ADD RO,SBADR ;ADD R#11 BASE ADDRESS
MOV #ATA,SGDDAT ;WHAT REGISTER SHOULD BE
MOV SBDDAT,STMP0 ;MOVE REGISTER CONTENTS TO 'STMP0'
BIC #1CATA,STMP0 ;SAVE SPECIFIED BITS
CMP SGDDAT,STMP0 ;COMPARE THE BITS
BEQ 75\$;BR IF OK
MOV SBDDAT,STMP4 ;COPY 'BAD DATA'
BIC #ATA,STMP4 ;CLEAR THE MASKED BITS
BIS STMP4,SGDDAT ;'OR' WITH GOOD DATA FOR TYPEOUT
ERROR 15 ;TYPE MESSAGE 15
COM CKERR ;SET THE REGISTER COMPARE ERROR INDICATOR
NOP
75\$:
;*****
;SET 'VV' FOR EACH PORT
MOV #11,RPCS1(RO) ;CLEAR THE DRIVE
MOV #21,RPCS1(RO) ;DO A READIN PRESET THROUGH PORT A
MOV #13,RPCS1(RO) ;RELEASE THE DRIVE
MOVB PORTB,RPCS2(RO) ;SELECT PORT B
MOV #21,RPCS1(RO) ;DO A READIN PRESET THROUGH PORT B
MOV #FMT22,RPOF(RO) ;SET 'FMT22'
MOV #13,RPCS1(RO) ;RELEASE THE DRIVE
MOV #5000.,WATCH ;MOTOR 'COOL DOWN' DELAY
TST WATCH ;FINISHED ?
BNE 5\$;BR IF NOT
SCOPE 5\$;LOOP ?

2557
2558
2559
2560
2561
2562
2563
2564
2565
2566
2567
2568
2569
2570
2571
2572
2573
2574
2575
2576
2577
2578
2579
2580
2581
2582
2583
2584
2585
2586
2587
2588
2589
2590
2591
2592
2593
2594
2595
2596
2597
2598
2599
2600
2601
2602
2603
2604
2605
2606
2607
2608
2609
2610
2611
2612

```

*****
*TEST 7          TEST UNLOAD COMMAND THROUGH PORT B
*
*VERIFY THAT THE UNLOAD COMMAND FUNCTIONS PROPERLY AND THAT A PORT
*TIMEOUT WILL NOT OCCUR WHILE THE 'GO' BIT IS SET.
*
*  A.  ISSUE AN UNLOAD COMMAND THROUGH PORT B; VERIFY THAT THE
*      DRIVE IS SEIZED.
*
*  B.  WAIT THE MEASURED TIMEOUT INTERVAL + 25%; VERIFY THAT THE DRIVE
*      DOES NOT TIME OUT. VERIFY THAT THE 'GO' BIT IS STILL SET AND
*      THAT 'DRY' AND 'PIP' ARE NOT SET.
*
*  C.  REQUEST THAT THE OPERATOR PRESS THE 'STANDBY' BUTTON ON THE DRIVE.
*
*  D.  WHEN THE DRIVE CYCLES UP, VERIFY THAT THE DRIVE IS STILL SEIZED
*      BY PORT B, THAT THE 'VV' BIT FOR PORT B IS RESET, THAT THE
*      ATTENTION BIT FOR PORT B IS SET, AND THAT THE ATTENTION BIT
*      FOR PORT A IS NOT SET.
*
*  E.  WAIT FOR THE PORT TIMEOUT TO RELEASE THE DRIVE. WHEN THE TIMEOUT
*      OCCURS, VERIFY THAT THE DRIVE RETURNED TO NEUTRAL, THAT THE
*      ATTENTION BIT FOR PORT B IS STILL SET, AND THAT THE ATTENTION
*      BIT FOR PORT A IS NOT SET.
*
*  F.  VERIFY THAT THE 'VV' BIT FOR PORT A IS NOT SET.
*
*  G.  ISSUE A PACK ACKNOWLEDGE INSTRUCTION THROUGH BOTH PORTS.

```

```

011070
011070 005737 001266
011074 001406
011076 100002
011100 000137 002424
011104 012737 177777 001266
011112 112737 000007 001102
011120 012737 011142 001106
011126 012737 011142 001110
011134 012737 000001 001176
011142 012706 001100

```

```

*****
TST7:
TST      KYBCTL      ;PERFORMING ONLY SINGLE TESTS ?
BEQ      25          ;BR IF NOT
BPL      15          ;BR IF JUST ENTERED TEST
JMP      EXEC        ;RETURN & GET NEXT TEST NUMBER
15:      MOV      #-1,KYBCTL ;SET SINGLE TEST INDICATOR
25:      MOV      #7,$TSTNM ;TEST NUMBER
        MOV      #TEST7,$LPADR ;LOAD LOOP ON TEST ADDRESS
        MOV      #TEST7,$LPERR ;LOAD LOOP ON ERROR ADDRESS
        MOV      #1,$TIMES ;DO 1 ITERATION
TEST7:   MOV      #STACK,SP ;SETUP THE STACK POINTER

;CLEAR ATTENTION BITS FOR BOTH PORTS
MOV      PORTA,APCS2(RO) ;SELECT PORT #A
CLR      RPDS1(RO)      ;SEIZE THE DRIVE
MOV      #11,APCS1(RO)  ;ISSUE DRIVE CLEAR
MOV      #13,APCS1(RO)  ;RELEASE THE DRIVE
MOV      PORTB,APCS2(RO) ;SELECT PORT #B
CLR      RPDS1(RO)      ;SEIZE THE DRIVE THROUGH PORT 'B'
MOV      #11,APCS1(RO)  ;ISSUE DRIVE CLEAR
MOV      #13,APCS1(RO)  ;RELEASE THE DRIVE
MOV      PORTB,APCS2(RO) ;SELECT PORT B
MOV      PORTB,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
MOV      PORTB,SEIZPT ;SEIZING PORT'S ADDRESS

```


K04

```

2613
2614
2615      ;:*****
2616      ;DO AN UNLOAD COMMAND THROUGH PORT B
2617 011244 012760 000003 000000      MOV      #3,RPDS1(RO)      ;ISSUE AN UNLOAD COMMAND THROUGH PORT B
2618 011252 013737 001264 001254      MOV      TIMEBP,WATCH      ;TIMEOUT ONESHOT VALUE + 25%
2619 011260 005737 001254      15:     TST      WATCH      ;FINISHED TIMEOUT ?
2620 011264 001375      BNE      15      ;BR IF NOT
2621
2622      ;:*****
2623      ;IS THE STATUS OK ?
2624
2625 011266 005037 001244      CLR      CKERR      ;CLEAR THE 'CHECK ERROR' INDICATOR
2626 011272 016037 000000 001126      MOV      RPDS1(RO),SBDAT ;GET CONTENTS OF RPDS1
2627 011300 012737 000000 001122      MOV      #RPDS1,SBDADR ;FORM REGISTER ADDRESS OF ERROR MESSAGE
2628 011306 060037 001122      ADD      RO,SBDADR      ;ADD RH11 BASE ADDRESS
2629 011312 012737 004001 001124      MOV      #DVA!GO,$GDDAT ;WHAT REGISTER SHOULD BE
2630 011320 013737 001126 001164      MOV      SBDAT,$TMP0 ;MOVE REGISTER CONTENTS TO 'TMP0'
2631 011326 042737 173776 001164      BIC      #1C4001,$TMP0 ;SAVE SPECIFIED BITS
2632 011334 023737 001124 001164      CMP      $GDDAT,$TMP0 ;COMPARE THE BITS
2633 011342 001414      BEQ      64$      ;BR IF OK
2634 011344 013737 001126 001174      MOV      SBDAT,$TMP4 ;COPY 'BAD DATA'
2635 011352 042737 004001 001174      BIC      #4001,$TMP4 ;CLEAR THE MASKED BITS
2636 011360 053737 001174 001124      BIS      $TMP4,$GDDAT ;'OR' WITH GOOD DATA FOR TYPEOUT
2637 011366 104011      ERROR   11 ;TYPE MESSAGE 11
2638 011370 005137 001244      COM      CKERR      ;SET THE REGISTER COMPARE ERROR INDICATOR
2639 011374 000240      64$:   NOP
2640 011376 005037 001244      CLR      CKERR      ;CLEAR THE 'CHECK ERROR' INDICATOR
2641 011402 016037 000012 001126      MOV      RPDS1(RO),SBDAT ;GET CONTENTS OF RPDS1
2642 011410 012737 000012 001122      MOV      #RPDS1,SBDADR ;FORM REGISTER ADDRESS OF ERROR MESSAGE
2643 011416 060037 001122      ADD      RO,SBDADR      ;ADD RH11 BASE ADDRESS
2644 011422 012737 021400 001124      MOV      #PIP!PGM!DPR,$GDDAT ;WHAT REGISTER SHOULD BE
2645 011430 013737 001126 001164      MOV      SBDAT,$TMP0 ;MOVE REGISTER CONTENTS TO 'TMP0'
2646 011436 042737 000177 001164      BIC      #1C177600,$TMP0 ;SAVE SPECIFIED BITS
2647 011444 023737 001124 001164      CMP      $GDDAT,$TMP0 ;COMPARE THE BITS
2648 011452 001414      BEQ      66$      ;BR IF OK
2649 011454 013737 001126 001174      MOV      SBDAT,$TMP4 ;COPY 'BAD DATA'
2650 011462 042737 177600 001174      BIC      #177600,$TMP4 ;CLEAR THE MASKED BITS
2651 011470 053737 001174 001124      BIS      $TMP4,$GDDAT ;'OR' WITH GOOD DATA FOR TYPEOUT
2652 011476 104012      ERROR   12 ;TYPE MESSAGE 12
2653 011500 005137 001244      COM      CKERR      ;SET THE REGISTER COMPARE ERROR INDICATOR
2654 011504 000240      66$:   NOP
2655 011506 104401 023712      TYPE     STANDBY ;TYPE THE STANDBY MESSAGE
2656 011512 013746 001226      MOV      PORTB,-(SP) ;SAVE PORTB FOR TYPEOUT
2657
2658      TYPOS ;TYPE THE PORT NUMBER
2659      .BYTE 1 ;GO TYPE--OCTAL ASCII
2660      .BYTE 0 ;TYPE 1 DIGIT(S)
2661 011522 104401 001207      TYPE     ,SCRLF ;SUPPRESS LEADING ZEROS
2662
2663      ;:*****
2664      ;WAIT FOR 'MOL' TO SET
2665
2666 011526 032760 010000 000012 25:     BIT      #MOL,RPDS1(RO) ;WAIT FOR MOL TO SET
2667 011534 001774      BEQ      25 ;LOOP UNTIL 'MOL' SETS
2668 011536 012737 003720 001254      MOV      #2000.,WATCH ;SETUP A 2 SECOND STALL

```


L04

```

2669 011544 113760 001224 000010      MOVB   PORTA,RPCS2(RO) ;SELECT PORT A
2670 011552 013737 001224 001234      MOV    PORTA,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
2671 011560 005760 000012      3$:   TST    RPDS1(RO) ;DRIVE TIMEOUT ?
2672 011564 001004      BNE    4$ ;BR IF IT HAS
2673 011566 005737 001254      TST    WATCH ;2 SECONDS ELAPSED ?
2674 011572 001372      BNE    3$ ;BR IF NOT
2675 011574 104006      ERROR  6 ;NO TIMEOUT AFTER 2 SECONDS
2676
2677
2678 011576      4$:   *****
2679
2680      ;VERIFY THAT THE DRIVE IS IN NEUTRAL
2681
2682 011576 005037 001250      CLR    RELERR ;CLEAR THE 'RELEASE ERROR' INDICATOR
2683 011602 012737 000012 001122      MOV    #RPDS1,SBDDAR ;FORM THE ADDRESS OF RPDS1 FOR TYPEOUT
2684 011610 060037 001122      ADD    RO,SBDDAR ;ADD THE I/O BASE ADDRESS
2685 011614 012737 011600 001124      MOV    #MOL:PGM:DPR:DRY,$GDDAT ;COMPARISON CONSTANT
2686 011622 113760 001224 000010      MOVB   PORTA,RPCS2(RO) ;SELECT PORT A.
2687 011630 016037 000012 001170      MOV    RPDS1(RO),$TMP2 ;GET THE DRIVE STATUS REGISTER FROM PORT A.
2688 011636 013737 001170 001164      MOV    $TMP2,$TMP0 ;COPY IT INTO '$TMP0'
2689 011644 042737 100100 001164      BIC    #ATA!VV,$TMP0 ;CLEAR PORT DEPENDENT BITS FROM THE COPY
2690 011652 113760 001226 000010      MOVB   PORTB,RPCS2(RO) ;SELECT PORT B.
2691 011660 016037 000012 001172      MOV    RPDS1(RO),$TMP3 ;GET THE DRIVE STATUS REGISTER FROM PORT B.
2692 011666 013737 001172 001166      MOV    $TMP3,$TMP1 ;COPY IT INTO '$TMP1'
2693 011674 042737 100100 001166      BIC    #ATA!VV,$TMP1 ;CLEAR PORT DEPENDENT BITS FROM THE COPY
2694 011702 023737 001164 001166      CMP    $TMP0,$TMP1 ;IS THE STATUS REGISTER THE SAME FROM BOTH PORTS ?
2695 011710 001006      BNE    68$ ;BR IF NOT
2696 011712 005737 001164      TST    $TMP0 ;REGISTERS ARE THE SAME: ARE THEY ZERO ?
2697 011716 001037      BNE    70$ ;BR IF NOT
2698 011720 104034      ERROR  34 ;REPORT DRIVE NOT IN NEUTRAL OR NOT SEIZED
2699 011722 000137 012106      JMP    72$ ;BYPASS THE REST OF THE CHECKS
2700 011726 013737 001170 001126 68$:   MOV    $TMP2,$BDDAT ;SET UP POSSIBLE BAD DATA FOR ERROR MESSAGE
2701 011734 013737 001226 001234      MOV    PORTB,PTNBR ;SEIZING PORT IF TEST SHOWS DRIVE NOT IN NEUTRAL
2702 011742 113760 001226 000010      MOVB   PORTB,RPCS2(RO) ;SELECT PORT B.
2703 011750 005737 001164      TST    $TMP0 ;SEE IF STATUS EQ 0 FROM PORT A.
2704 011754 001414      BEQ    69$ ;BR IF ZERO
2705 011756 013737 001224 001234      MOV    PORTA,PTNBR ;SEIZING PORT IF TEST SHOWS DRIVE NOT IN NEUTRAL
2706 011764 013737 001172 001126      MOV    $TMP3,$BDDAT ;'BAD DATA' FOR ERROR TYPE OUT
2707 011772 113760 001224 000010      MOVB   PORTA,RPCS2(RO) ;SELECT PORT A.
2708 012000 005737 001166      TST    $TMP1 ;SEE IF STATUS EQ ZERO FROM PORT B.
2709 012004 001004      BNE    70$ ;BR IF NOT
2710 012006 012737 177777 001250 69$:   MOV    #-1,RELERR ;SET 'RELEASE ERROR' INDICATOR
2711 012014 104013      ERROR  13 ;TYPE ERROR MESSAGE 13
2712 012016 013737 001170 001126 70$:   MOV    $TMP2,$BDDAT ;LOOK FOR BIT FAILURES WHEN RPDS1 READ
2713 012024 013737 001224 001234      MOV    PORTA,PTNBR ;CHANGE PORT NUMBER
2714 012032 042737 100100 001170      BIC    #ATA!VV,$TMP2 ;DON'T CHECK ATTN BIT OR VV BIT
2715 012040 023737 001124 001170      CMP    $GDDAT,$TMP2 ;ALL BITS OK ?
2716 012046 001401      BEQ    71$ ;BR IF OK FROM PORT A.
2717 012050 104037      ERROR  37 ;REPORT ERROR
2718 012052 013737 001172 001126 71$:   MOV    $TMP3,$BDDAT ;CHECK RPDS1 FOR BIT FAILURES - FROM PORT B.
2719 012060 013737 001226 001234      MOV    PORTB,PTNBR ;CHANGE PORT NUMBER
2720 012066 042737 100100 001172      BIC    #ATA!VV,$TMP3 ;DON'T CHECK ATTN BIT OR VV BIT
2721 012074 023737 001124 001172      CMP    $GDDAT,$TMP3 ;SEE IF READ OK FROM PORT B.
2722 012102 001401      BEQ    72$ ;BR IF OK
2723 012104 104037      ERROR  37 ;REPORT THE ERROR
2724 012106 000240      72$:   NOP

```



```

2725
2726
2727
2728 012110 113760 001224 000010
2729 012116 013737 001224 001234
2730 012124 005037 001244
2731 012130 016037 000012 001126
2732 012136 012737 000012 001122
2733 012144 060037 001122
2734 012150 005037 001124
2735 012154 013737 001126 001164
2736 012162 042737 077777 001164
2737 012170 023737 001124 001164
2738 012176 001414
2739 012200 013737 001126 001174
2740 012206 042737 100000 001174
2741 012214 053737 001174 001124
2742 012222 104014
2743 012224 005137 001244
2744 012230 000240
2745 012232 113760 001226 000010
2746 012240 013737 001226 001234
2747 012246 005037 001244
2748 012252 016037 000012 001126
2749 012260 012737 000012 001122
2750 012266 060037 001122
2751 012272 012737 100000 001124
2752 012300 013737 001126 001164
2753 012306 042737 077777 001164
2754 012314 023737 001124 001164
2755 012322 001414
2756 012324 013737 001126 001174
2757 012332 042737 100000 001174
2758 012340 053737 001174 001124
2759 012346 104015
2760 012350 005137 001244
2761 012354 000240
2762
2763
2764
2765
2766 012356 012760 000011 000000
2767 012364 012760 000021 000000
2768 012372 012760 000013 000000
2769 012400 113760 001224 000010
2770 012406 012760 000021 000000
2771 012414 012760 010000 000032
2772 012422 012760 000013 000000
2773 012430 012737 011610 001254
2774 012436 005737 001254
2775 012442 001375
2776 012444 000004
2777
2778
2779
2780

```

```

;*****
;CHECK THE ATTENTION BITS
MOV  PORTA,RPCS2(RO) ;SELECT PORT A
MOV  PORTA,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
CLR  CKERR ;CLEAR THE 'CHECK ERROR' INDICATOR
MOV  RPDS1(RO),SDDAT ;GET CONTENTS OF RPDS1
MOV  #RPDS1,SBDADR ;FORM REGISTER ADDRESS OF ERROR MESSAGE
ADD  RO,SBDADR ;ADD RH11 BASE ADDRESS
CLR  SGDDAT ;WHAT REGISTER SHOULD BE
MOV  SDDAT,STMP0 ;MOVE REGISTER CONTENTS TO 'STMP0'
BIC  #1CATA,STMP0 ;SAVE SPECIFIED BITS
CMP  SGDDAT,STMP0 ;COMPARE THE BITS
BEQ  73$ ;BR IF OK
MOV  SDDAT,STMP4 ;COPY 'BAD DATA'
BIC  #ATA,STMP4 ;CLEAR THE MASKED BITS
BIS  STMP4,SGDDAT ;'OR' WITH GOOD DATA FOR TYPEOUT
ERROR 14 ;TYPE MESSAGE 14
COM  CKERR ;SET THE REGISTER COMPARE ERROR INDICATOR
73$:
NOP
MOV  PORTB,RPCS2(RO) ;SELECT PORT B
MOV  PORTB,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
CLR  CKERR ;CLEAR THE 'CHECK ERROR' INDICATOR
MOV  RPDS1(RO),SDDAT ;GET CONTENTS OF RPDS1
MOV  #RPDS1,SBDADR ;FORM REGISTER ADDRESS OF ERROR MESSAGE
ADD  RO,SBDADR ;ADD RH11 BASE ADDRESS
MOV  #ATA,SGDDAT ;WHAT REGISTER SHOULD BE
MOV  SDDAT,STMP0 ;MOVE REGISTER CONTENTS TO 'STMP0'
BIC  #1CATA,STMP0 ;SAVE SPECIFIED BITS
CMP  SGDDAT,STMP0 ;COMPARE THE BITS
BEQ  75$ ;BR IF OK
MOV  SDDAT,STMP4 ;COPY 'BAD DATA'
BIC  #ATA,STMP4 ;CLEAR THE MASKED BITS
BIS  STMP4,SGDDAT ;'OR' WITH GOOD DATA FOR TYPEOUT
ERROR 15 ;TYPE MESSAGE 15
COM  CKERR ;SET THE REGISTER COMPARE ERROR INDICATOR
75$:
NOP
;*****
;SET 'VV' FOR EACH PORT
MOV  #11,RPCS1(RO) ;CLEAR THE DRIVE
MOV  #21,RPCS1(RO) ;DO A READIN PRESET THROUGH PORT B
MOV  #13,RPCS1(RO) ;RELEASE THE DRIVE
MOV  PORTA,RPCS2(RO) ;SELECT PORT A
MOV  #21,RPCS1(RO) ;DO A READIN PRESET THROUGH PORT A
MOV  #FMT22,RPOF(RO) ;SET 'FMT22'
MOV  #13,RPCS1(RO) ;RELEASE THE DRIVE
MOV  #5000.,WATCH ;MOTOR 'COOL DOWN' DELAY
5$:
TST  WATCH ;FINISHED ?
BNE  5$ ;BR IF NOT
SCOPE ;LOOP ?
;*****

```


2781
2782
2783
2784
2785
2786
2787
2788
2789
2790
2791
2792
2793
2794
2795
2796
2797
2798
2799
2800
2801
2802
2803
2804
2805
2806
2807
2808
2809
2810
2811
2812
2813
2814
2815
2816
2817
2818
2819
2820
2821
2822
2823
2824
2825
2826
2827
2828
2829
2830
2831
2832
2833
2834
2835
2836

```
*TEST 10 TEST 'CONTROLLER SELECT' SWITCH THROUGH PORT A DURING UNLOAD
*
*VERIFY THAT THE 'CONTROLLER SELECT' SWITCH IS INHIBITED WHEN THE
* RPO4 IS CYCLED DOWN BY AN UNLOAD COMMAND.
*
* A. ISSUE AN UNLOAD COMMAND THROUGH PORT A.
*
* B. REQUEST THAT THE OPERATOR SWITCH THE 'CONTROLLER SELECT' SWITCH
* TO A AND THEN PRESS THE 'STANDBY' BUTTON.
*
* C. WAIT FOR 'MOL' TO SET BY MONITORING RPDS1 THROUGH PORT
* A. WHEN THE DRIVE HAS CYCLED UP ('MOL' HAS SET), ISSUE
* RELEASE COMMAND THROUGH PORT A.
*
* D. VERIFY THAT THE DRIVE CAN BE ACCESSED BY BOTH PORTS AND THAT
* THE DRIVE IS STILL IN NEUTRAL.
*
* E. REQUEST THAT THE OPERATOR RETURN THE 'CONTROLLER SELECT' SWITCH
* TO A/B'.
```

```
TST10: TST KYBCTL ;PERFORMING ONLY SINGLE TESTS ?
BEQ 25 ;BR IF NOT
BPL 15 ;BR IF JUST ENTERED TEST
JMP EXEC ;RETURN & GET NEXT TEST NUMBER
15: MOV #-1,KYBCTL ;SET SINGLE TEST INDICATOR
25: MOVB #10,STSTNM ;TEST NUMBER
MOV #TEST10,$LPADR ;LOAD LOOP ON TEST ADDRESS
MOV #TEST10,$LPERR ;LOAD LOOP ON ERROR ADDRESS
MOV #1,STIMES ;DO 1 ITERATION
TEST10: MOV #STACK,SP ;SETUP THE STACK POINTER

;CLEAR ATTENTION BITS FOR BOTH PORTS
MOVB PORTA,RPCS2(RO) ;SELECT PORT #A
CLR RPDS1(RO) ;SEIZE THE DRIVE
MOV #11,RPCS1(RO) ;ISSUE DRIVE CLEAR
MOV #13,RPCS1(RO) ;RELEASE THE DRIVE
MOVB PORTB,RPCS2(RO) ;SELECT PORT #B
CLR RPDS1(RO) ;SEIZE THE DRIVE THROUGH PORT 'B'
MOV #11,RPCS1(RO) ;ISSUE DRIVE CLEAR
MOV #13,RPCS1(RO) ;RELEASE THE DRIVE
MOVB PORTA,RPCS2(RO) ;SELECT PORT A
MOV PORTA,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
MOV PORTA,SEIZPT ;SEIZING PORT'S ADDRESS
MOV #3,RPCS1(RO) ;ISSUE AN UNLOAD COMMAND THROUGH PORT A
TYPE ,SWTCHA ;SWITCH TO PORT A MESSAGE
TYPE ,STANDBY ;TYPE PRESS STANDBY
MOV PORTA,-(SP) ;SAVE PORTA FOR TYPEOUT
;TYPE THE PORT NUMBER
;GO TYPE--OCTAL ASCII
;TYPE 1 DIGIT(S)
;SUPPRESS LEADING ZEROS
;CR-LF
15: BIT #MOL,RPDS1(RO) ;TEST 'MOL'
```

```
012446
012446 005737 001266
012452 001406
012454 100002
012456 000137 002424
012462 012737 177777 001266
012470 112737 000010 001102
012476 012737 012520 001106
012504 012737 012520 001110
012512 012737 000001 001176
012520 012706 001100

012524 113760 001224 000010
012532 005060 000012
012536 012760 000011 000000
012544 012760 000013 000000
012552 113760 001226 000010
012560 005060 000012
012564 012760 000011 000000
012572 012760 000013 000000
012600 113760 001224 000010
012606 013737 001224 001234
012614 013737 001224 001236
012622 012760 000003 000000
012630 104401 024124
012634 104401 023712
012640 013746 001224

012644 104403
012646 001
012647 000
012650 104401 001207
012654 032760 010000 000012 15:
```



```

2837 012662 001774 BEQ 15 ;BR IF NOT SET
2838 012664 012760 000011 000000 MOV #11,RPDS1(RO) ;ISSUE A DRIVE CLEAR
2839 012672 012760 000021 000000 MOV #21,RPDS1(RO) ;ISSUE A READIN PRESET
2840 012700 012760 000013 000000 MOV #13,RPDS1(RO) ;RELEASE THE DRIVE
2841
2842 ;VERIFY THAT THE DRIVE IS IN NEUTRAL
2843
2844 012706 005037 001250 CLR RELERR ;CLEAR THE 'RELEASE ERROR' INDICATOR
2845 012712 012737 000012 001122 MOV #RPDS1,SBDADR ;FORM THE ADDRESS OF RPDS1 FOR TYPEOUT
2846 012720 060737 001122 ADD RO,SBDADR ;ADD THE I/O BASE ADDRESS
2847 012724 012737 011600 001124 MOV #MOL!PGM!DPR!DRY,SGDDAT ;COMPARISON CONSTANT
2848 012732 113760 001224 000010 MOVB PORTA,RPDS2(RO) ;SELECT PORT A.
2849 012740 016037 000012 001170 MOV RPDS1(RO),STMP2 ;GET THE DRIVE STATUS REGISTER FROM PORT A.
2850 012746 013737 001170 001164 MOV STMP2,STMP0 ;COPY IT INTO 'STMP0'
2851 012754 042737 100100 001164 BIC #ATA!VV,STMP0 ;CLEAR PORT DEPENDENT BITS FROM THE COPY
2852 012762 113760 001224 000010 MOVB PORTB,RPDS2(RO) ;SELECT PORT B.
2853 012770 016037 000012 001172 MOV RPDS1(RO),STMP3 ;GET THE DRIVE STATUS REGISTER FROM PORT B.
2854 012776 013737 001172 001166 MOV STMP3,STMP1 ;COPY IT INTO 'STMP1'
2855 013004 042737 100100 001166 BIC #ATA!VV,STMP1 ;CLEAR PORT DEPENDENT BITS FROM THE COPY
2856 013012 023737 001164 001166 CMP STMP0,STMP1 ;IS THE STATUS REGISTER THE SAME FROM BOTH PORTS ?
2857 013020 001006 BNE 64$ ;BR IF NOT
2858 013022 005737 001164 TST STMP0 ;REGISTERS ARE THE SAME: ARE THEY ZERO ?
2859 013026 001037 BNE 66$ ;BR IF NOT
2860 013030 104034 ERROR 34 ;REPORT DRIVE NOT IN NEUTRAL OR NOT SEIZED
2861 013032 000137 013216 JMP 68$ ;BYPASS THE REST OF THE CHECKS
2862 013036 013737 001170 001126 64$: MOV STMP2,SBDAT ;SET UP POSSIBLE BAD DATA FOR ERROR MESSAGE
2863 013044 013737 001226 001234 MOV PORTB,PTNBR ;SEIZING PORT IF TEST SHOWS DRIVE NOT IN NEUTRAL
2864 013052 113760 001226 000010 MOVB PORTB,RPDS2(RO) ;SELECT PORT B.
2865 013060 005737 001164 TST STMP0 ;SEE IF STATUS EQ 0 FROM PORT A.
2866 013064 001414 BEQ 65$ ;BR IF ZERO
2867 013066 013737 001224 001234 MOV PORTA,PTNBR ;SEIZING PORT IF TEST SHOWS DRIVE NOT IN NEUTRAL
2868 013074 013737 001172 001126 MOV STMP3,SBDAT ;'BAD DATA' FOR ERROR TYPE OUT
2869 013102 113760 001224 000010 MOVB PORTA,RPDS2(RO) ;SELECT PORT A.
2870 013110 005737 001166 TST STMP1 ;SEE IF STATUS EQ ZERO FROM PORT B.
2871 013114 001004 BNE 66$ ;BR IF NOT
2872 013116 012737 177777 001250 65$: MOV #1,RELERR ;SET 'RELEASE ERROR' INDICATOR
2873 013124 104016 ERROR 16 ;TYPE ERROR MESSAGE 16
2874 013126 013737 001170 001126 66$: MOV STMP2,SBDAT ;LOOK FOR BIT FAILURES WHEN RPDS1 READ
2875 013134 013737 001224 001234 MOV PORTA,PTNBR ;CHANGE PORT NUMBER
2876 013142 042737 000100 001170 BIC #VV,STMP2 ;DON'T CHECK THE VV BIT
2877 013150 023737 001124 001170 CMP SGDDAT,STMP2 ;ALL BITS OK ?
2878 013156 001401 BEQ 67$ ;BR IF OK FROM PORT A.
2879 013160 104037 ERROR 37 ;REPORT ERROR
2880 013162 013737 001172 001126 67$: MOV STMP3,SBDAT ;CHECK RPDS1 FOR BIT FAILURES - FROM PORT B.
2881 013170 013737 001226 001234 MOV PORTB,PTNBR ;CHANGE PORT NUMBER
2882 013176 042737 000100 001172 BIC #VV,STMP3 ;DON'T CHECK THE VV BIT
2883 013204 023737 001124 001172 CMP SGDDAT,STMP3 ;SEE IF READ OK FROM PORT B.
2884 013212 001401 BEQ 68$ ;BR IF OK
2885 013214 104037 ERROR 37 ;REPORT THE ERROR
2886 013216 000240 68$: NOP
2887
2888 ;IF ERROR OCCURRED, CHECK FOR LOOP ON TEST
2889
2890 013220 105737 001103 TSTB SERFLG ;DID AN ERROR OCCUR
2891 013224 001412 BEQ 25 ;BR IF NOT
2892 013226 032777 001000 165704 BIT #SM09,SMR ;SEE IF LOOP ON ERROR (SMR9=1)

```


C05

```

2893 013234 001406 BEQ 25 ;BR IF NOT
2894 013236 105037 001103 CLR8 SERFLG ;CLEAR THE ERROR FLAG
2895 013242 005037 001176 CLR $TIMES ;CLEAR THE MAX ITERATION COUNT
2896 013246 000177 165636 JMP $SLPERR ;GO TO THE LOOP ADDRESS
2897 013252 005737 001266 25: TST KYBCTL ;SINGLE TEST MODE ?
2898 013256 001406 BEQ 35 ;BR IF NOT
2899 013260 032777 040000 165652 BIT #SW14,$SWR ;LOOP ON TEST ?
2900 013266 001002 BNE 35 ;BR IF LOOPING
2901 013270 104401 024035 TYPE ,SWTCHN ;RETURN CONTROLLER SELECT SWITCH TO 'A/B'
2902 013274 35:
2903 013274 113760 001226 000010 MOVB PORTB,RPCS2(RO) ;SELECT PORT B
2904 013302 013737 001226 001234 MOV PORTB,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
2905 013310 012760 000011 000000 MOV #11,RPCS1(RO) ;ISSUE A DRIVE CLEAR
2906 013316 012760 000021 000000 MOV #21,RPCS1(RO) ;ISSUE A READIN PRESET
2907 013324 012760 010000 000032 MOV #FMT22,RPOF(RO) ;SET 'FMT22'
2908 013332 012760 000013 000000 MOV #13,RPCS1(RO) ;RELEASE PORT B
2909 013340 012737 011610 001254 MOV #5000.,WATCH ;SPINDLE MOTOR 'COOL DOWN' DELAY
2910 013346 005737 001254 45: TST WATCH ;FINISHED ?
2911 013352 001375 BNE 45 ;BR IF NOT
2912 013354 000004 SCOPE ;LOOP ?
2913 013356 000400 BR TST11 ;GO TO NEXT TEST

```

```

*****
*TEST 11 TEST 'CONTROLLER SELECT' SWITCH THROUGH PORT B DURING UNLOAD
*
*VERIFY THAT THE 'CONTROLLER SELECT' SWITCH IS INHIBITED WHEN THE
* RPO4 IS CYCLED DOWN BY AN UNLOAD COMMAND.
*
* A. ISSUE AN UNLOAD COMMAND THROUGH PORT B.
*
* B. REQUEST THAT THE OPERATOR SWITCH THE 'CONTROLLER SELECT' SWITCH
* TO B AND THEN PRESS THE 'STANDBY' BUTTON.
*
* C. WAIT FOR 'MOL' TO SET BY MONITORING RPO51 THROUGH PORT
* B. WHEN THE DRIVE HAS CYCLED UP ('MOL' HAS SET), ISSUE
* RELEASE COMMAND THROUGH PORT B.
*
* D. VERIFY THAT THE DRIVE CAN BE ACCESSED BY BOTH PORTS AND THAT
* THE DRIVE IS STILL IN NEUTRAL.
*
* E. REQUEST THAT THE OPERATOR RETURN THE 'CONTROLLER SELECT' SWITCH
* TO 'A/B'.
*
*****

```

```

2937 013360 TST11: TST KYBCTL ;PERFORMING ONLY SINGLE TESTS ?
2938 013360 005737 001266 BEQ 25 ;BR IF NOT
2939 013364 001406 BPL 15 ;BR IF JUST ENTERED TEST
2940 013366 100002 JMP EXEC ;RETURN & GET NEXT TEST NUMBER
2941 013370 000137 002424 MOV #0-1,KYBCTL ;SET SINGLE TEST INDICATOR
2942 013374 012737 177777 001266 15: MOVB #11,$STSTNH ;TEST NUMBER
2943 013402 112737 000011 001102 25: MOV #TEST11,$SLPADR ;LOAD LOOP ON TEST ADDRESS
2944 013410 012737 013432 001106 MOV #TEST11,$SLPERR ;LOAD LOOP ON ERROR ADDRESS
2945 013416 012737 013432 001110 MOV #1,$TIMES ;DO 1 ITERATION
2946 013424 012737 000001 001176 MOV #STACK,$SP ;SETUP THE STACK POINTER
2947 013432 012706 001100 TEST11: MOV
2948

```


DOS

```

2949 ;CLEAR ATTENTION BITS FOR BOTH PORTS
2950
2951 013436 113760 001224 000010 MOVB PORTA,RPCS2(RO) ;SELECT PORT #A
2952 013444 005060 000012 CLR RPDS1(RO) ;SEIZE THE DRIVE
2953 013450 012760 000011 000000 MOV #11,RPCS1(RO) ;ISSUE DRIVE CLEAR
2954 013456 012760 000013 000000 MOV #13,RPCS1(RO) ;RELEASE THE DRIVE
2955 013464 113760 001226 000010 MOVB PORTB,RPCS2(RO) ;SELECT PORT #B
2956 013472 005060 000012 CLR RPDS1(RO) ;SEIZE THE DRIVE THROUGH PORT 'B'
2957 013476 012760 000011 000000 MOV #11,RPCS1(RO) ;ISSUE DRIVE CLEAR
2958 013504 012760 000013 000000 MOV #13,RPCS1(RO) ;RELEASE THE DRIVE
2959 013512 113760 001226 000010 MOVB PORTB,RPCS2(RO) ;SELECT PORT B
2960 013520 013737 001226 001234 MOV PORTB,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
2961 013526 013737 001226 001236 MOV PORTB,SEIZPT ;SEIZING PORT'S ADDRESS
2962 013534 012760 000003 000000 MOV #3,RPCS1(RO) ;ISSUE AN UNLOAD COMMAND THROUGH PORT B
2963 013542 104401 024207 TYPE ,SWTCHB ;SWITCH TO PORT B MESSAGE
2964 013546 104401 023712 TYPE ,STANDBY ;TYPE PRESS STANDBY
2965 013552 013746 001226 MOV PORTB,-(SP) ;SAVE PORTB FOR TYPEOUT
2966 ;TYPE THE PORT NUMBER
2967 013556 104403 TYPOS ;GO TYPE--OCTAL ASCII
2968 013560 001 .BYTE 1 ;TYPE 1 DIGIT(S)
2969 013561 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
2970 013562 104401 001207 TYPE ,SCRLF ;CR-LF
2971 013566 032760 010000 000012 15: BIT #MOL,RPDS1(RO) ;TEST 'MOL'
2972 013574 001774 BEQ 15 ;BR IF NOT SET
2973 013576 012760 000011 000000 MOV #11,RPCS1(RO) ;ISSUE A DRIVE CLEAR
2974 013604 012760 000021 000000 MOV #21,RPCS1(RO) ;ISSUE A READIN PRESET
2975 013612 012760 000013 000000 MOV #13,RPCS1(RO) ;RELEASE THE DRIVE
2976
2977 ;VERIFY THAT THE DRIVE IS IN NEUTRAL
2978
2979 013620 005037 001250 CLR RELERR ;CLEAR THE 'RELEASE ERROR ' INDICATOR
2980 013624 012737 000012 001122 MOV #RPDS1,$BDDADR ;FORM THE ADDRESS OF RPDS1 FOR TYPEOUT
2981 013632 060037 001122 ADD RO,$BDDADR ;ADD THE I/O BASE ADDRESS
2982 013636 012737 011600 001124 MOV #MOL!PGH!DPR!DRY,$GDDAT ;COMPARISON CONSTANT
2983 013644 113760 001224 000010 MOVB PORTA,RPCS2(RO) ;SELECT PORT A.
2984 013652 016037 000012 001170 MOV RPDS1(RO),STMP2 ;GET THE DRIVE STATUS REGISTER FROM PORT A.
2985 013660 013737 001170 001164 MOV STMP2,STMP0 ;COPY IT INTO 'STMP0'
2986 013666 042737 100100 001164 BIC #ATA!VV,STMP0 ;CLEAR PORT DEPENDENT BITS FROM THE COPY
2987 013674 113760 001226 000010 MOVB PORTB,RPCS2(RO) ;SELECT PORT B.
2988 013702 016037 000012 001172 MOV RPDS1(RO),STMP3 ;GET THE DRIVE STATUS REGISTER FROM PORT B.
2989 013710 013737 001172 001166 MOV STMP3,STMP1 ;COPY IT INTO 'STMP1'
2990 013716 042737 100100 001166 BIC #ATA!VV,STMP1 ;CLEAR PORT DEPENDENT BITS FROM THE COPY
2991 013724 023737 001164 001166 CMP STMP0,STMP1 ;IS THE STATUS REGISTER THE SAME FROM BOTH PORTS ?
2992 013732 001006 BNE 645 ;BR IF NOT
2993 013734 005737 001164 TST STMP0 ;REGISTERS ARE THE SAME: ARE THEY ZERO ?
2994 013740 001037 BNE 665 ;BR IF NOT
2995 013742 104034 ERROR 34 ;REPORT DRIVE NOT IN NEUTRAL OR NOT SEIZED
2996 013744 000137 014130 JMP 685 ;BYPASS THE REST OF THE CHECKS
2997 013750 013737 001170 001126 645: MOV STMP2,$BDDAT ;SET UP POSSIBLE BAD DATA FOR ERROR MESSAGE
2998 013756 013737 001226 001234 MOV PORTB,PTNBR ;SEIZING PORT IF TEST SHOWS DRIVE NOT IN NEUTRAL
2999 013764 113760 001226 000010 MOVB PORTB,RPCS2(RO) ;SELECT PORT B.
3000 013772 005737 001164 TST STMP0 ;SEE IF STATUS EQ 0 FROM PORT A.
3001 013776 001414 BEQ 655 ;BR IF ZERO
3002 014000 013737 001224 001234 MOV PORTA,PTNBR ;SEIZING PORT IF TEST SHOWS DRIVE NOT IN NEUTRAL
3003 014006 013737 001172 001126 MOV STMP3,$BDDAT ;'BAD DATA' FOR ERROR TYPE OUT
3004 014014 113760 001224 000010 MOVB PORTA,RPCS2(RO) ;SELECT PORT A.
    
```


E05

MD-11-DZRJF-A, RPO4/5/6 DUAL CONTRLR LOGIC TEST - PART 2 MACY11 27(1006) 02-NOV-76 19:12 PAGE 56
 DZRJFA.CMB 02-NOV-76 19:11 T11 TEST 'CONTROLLER SELECT' SWITCH THROUGH PORT B DURING UNLOAD

```

3005 014022 005737 001166          TST      $TMP1          ;SEE IF STATUS EG ZERO FROM PORT B.
3006 014026 001004          BNE      66$          ;BR IF NOT
3007 014030 012737 177777 001250 65$:  MOV      #-1,RELERR   ;SET 'RELEASE ERROR' INDICATOR
3008 014036 104016          ERROR   16          ;TYPE ERROR MESSAGE 16
3009 014040 013737 001170 001126 66$:  MOV      $TMP2,$BDDAT ;LOOK FOR BIT FAILURES WHEN RPDS1 READ
3010 014046 013737 001224 001234      MOV      PORTA,PTNBR  ;CHANGE PORT NUMBER
3011 014054 042737 000100 001170      BIC      #VV,$TMP2    ;DON'T CHECK THE VV BIT
3012 014062 023737 001124 001170      CMP      $GDDAT,$TMP2 ;ALL BITS OK ?
3013 014070 001401          BEQ      67$          ;BR IF OK FROM PORT A.
3014 014072 104037          ERROR   37          ;REPORT ERROR
3015 014074 013737 001172 001126 67$:  MOV      $TMP3,$BDDAT ;CHECK RPDS1 FOR BIT FAILURES - FROM PORT B.
3016 014102 013737 001226 001234      MOV      PORTB,PTNBR  ;CHANGE PORT NUMBER
3017 014110 042737 000100 001172      BIC      #VV,$TMP3    ;DON'T CHECK THE VV BIT
3018 014116 023737 001124 001172      CMP      $GDDAT,$TMP3 ;SEE IF READ OK FROM PORT B.
3019 014124 001401          BEQ      68$          ;BR IF OK
3020 014126 104037          ERROR   37          ;REPORT THE ERROR
3021 014130 000240          68$:  NOP
3022
3023          ;IF ERROR OCCURRED, CHECK FOR LOOP ON TEST
3024
3025 014132 105737 001103          TSTB    SERFLG        ;DID AN ERROR OCCUR
3026 014136 001412          BEQ      2$          ;BR IF NOT
3027 014140 032777 001000 164772      BIT     #SW09,$SWR    ;SEE IF LOOP ON ERROR (SWR9=1)
3028 014146 001406          BEQ      2$          ;BR IF NOT
3029 014150 105037 001103          CLRB    SERFLG        ;CLEAR THE ERROR FLAG
3030 014154 005037 001176          CLR     $TIMES        ;CLEAR THE MAX ITERATION COUNT
3031 014160 000177 164724          JMP     $SLPERR        ;GO TO THE LOOP ADDRESS
3032 014164 005737 001266          2$:  TST     KYBCTL        ;SINGLE TEST MODE ?
3033 014170 001406          BEQ      3$          ;BR IF NOT
3034 014172 032777 040000 164740      BIT     #SW14,$SWR    ;LOOP ON TEST ?
3035 014200 001002          BNE     3$          ;BR IF LOOPING
3036 014202 104401 024035          TYPE    ,SWTCHN      ;RETURN CONTROLLER SELECT SWITCH TO 'A/B'
3037 014206
3038 014206 113760 001224 000010      3$:  MOVB   PORTA,RPCS2(RO) ;SELECT PORT A
3039 014214 013737 001224 001234      MOV     PORTA,PTNBR   ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
3040 014222 012760 000011 000000      MOV     #11,RPCS1(RO) ;ISSUE A DRIVE CLEAR
3041 014230 012760 000021 000000      MOV     #21,RPCS1(RO) ;ISSUE A READIN PRESET
3042 014236 012760 010000 000032      MOV     #FMT22,RPOF(RO) ;SET 'FMT22'
3043 014244 012760 000013 000000      MOV     #13,RPCS1(RO) ;RELEASE PORT A
3044 014252 012737 011610 001254      MOV     #5000.,WATCH ;SPINDLE MOTOR 'COOL DOWN' DELAY
3045 014260 005737 001254          4$:  TST     WATCH        ;FINISHED ?
3046 014264 001375          BNE     4$          ;BR IF NOT
3047 014266 000004          SCOPE
3048 014270 000400          BR     TST12        ;GO TO NEXT TEST
3049
3050
3051          ;*****
3052          ;TEST 12      TEST 'CONTROLLER SELECT' SWITCH, DRIVE CYCLED UP
3053          ;
3054          ;TEST THE OPERATION OF THE 'CONTROLLER SELECT' SWITCH (DRIVE CYCLED UP).
3055          ;
3056          ; A. SWITCH TO CONTROLLER 'A' POSITION. VERIFY THAT THE DRIVE IS IN
3057          ; NEUTRAL AND THAT THE STATUS BITS IN RPDS1, AS READ THROUGH BOTH
3058          ; PORTS, ARE CORRECT.
3059          ;
3060          ; B. SWITCH TO CONTROLLER 'B' POSITION. VERIFY THAT THE DRIVE IS IN
  
```


F05

```

3061
3062
3063
3064
3065
3066
3067
3068 014272
3069 014272 005737 001266
3070 014276 001406
3071 014300 100002
3072 014302 000137 002424
3073 014306 012737 177777 001266
3074 014314 112737 000012 001102
3075 014322 012737 014344 001106
3076 014330 012737 014344 001110
3077 014336 012737 000001 001176
3078 014344 012706 001100
3079
3080
3081
3082 014350 113760 001224 000010
3083 014356 005060 000012
3084 014362 012760 000011 000000
3085 014370 012760 000013 000000
3086 014376 113760 001226 000010
3087 014404 005060 000012
3088 014410 012760 000011 000000
3089 014416 012760 000013 000000
3090 014424 104401 024124
3091 014430 104401 024272
3092 014434 000000
3093
3094
3095
3096 014436 005037 001250
3097 014442 012737 000012 001122
3098 014450 060037 001122
3099 014454 012737 011700 001124
3100 014462 113760 001224 000010
3101 014470 016037 000012 001170
3102 014476 013737 001170 001164
3103 014504 042737 100100 001164
3104 014512 113760 001226 000010
3105 014520 016037 000012 001172
3106 014526 013737 001172 001166
3107 014534 042737 100100 001166
3108 014542 023737 001164 001166
3109 014550 001006
3110 014552 005737 001164
3111 014556 001045
3112 014560 104034
3113 014562 000137 014746
3114 014566 013737 001170 001126
3115 014574 013737 001226 001234
3116 014602 113760 001226 000010
    
```

```

; * NEUTRAL AND THAT THE STATUS BITS IN RPDS1, AS READ THROUGH BOTH
; * PORTS, ARE CORRECT.
; * C. RETURN THE 'CONTROLLER SELECT' SWITCH TO THE 'A/B' POSITION. VERIFY
; * THE DRIVE STATE.
; * *****
; * TST12:
; *
; * TST KYBCTL ;PERFORMING ONLY SINGLE TESTS ?
; * BEQ 25 ;OR IF NOT
; * BPL 15 ;OR IF JUST ENTERED TEST
; * JMP EXEC ;RETURN & GET NEXT TEST NUMBER
; * MOV #-1, KYBCTL ;SET SINGLE TEST INDICATOR
; * MOV #12, STSTNM ;TEST NUMBER
; * MOV #TEST12, SLPADR ;LOAD LOOP ON TEST ADDRESS
; * MOV #TEST12, SLPERR ;LOAD LOOP ON ERROR ADDRESS
; * MOV #1, STIMES ;DO 1 ITERATION
; * MOV #STACK, SP ;SETUP THE STACK POINTER
; *
; * ;CLEAR ATTENTION BITS FOR BOTH PORTS
; *
; * MOVB PORTA, RPCS2(RO) ;SELECT PORT #A
; * CLR RPDS1(RO) ;SEIZE THE DRIVE
; * MOV #11, RPCS1(RO) ;ISSUE DRIVE CLEAR
; * MOV #13, RPCS1(RO) ;RELEASE THE DRIVE
; * MOVB PORTB, RPCS2(RO) ;SELECT PORT #B
; * CLR RPDS1(RO) ;SEIZE THE DRIVE THROUGH PORT 'B'
; * MOV #11, RPCS1(RO) ;ISSUE DRIVE CLEAR
; * MOV #13, RPCS1(RO) ;RELEASE THE DRIVE
; * TYPE ,SWTCHA ;SWITCH TO 'A'
; * TYPE ,CONTUE ;PRESS 'CONTINUE'
; * HALT
; *
; * ;VERIFY THAT THE DRIVE IS IN NEUTRAL
; *
; * CLR RELERR ;CLEAR THE 'RELEASE ERROR' INDICATOR
; * MOV #RPDS1, SBDADR ;FORM THE ADDRESS OF RPDS1 FOR TYPEOUT
; * ADD RO, SBDADR ;ADD THE I/O BASE ADDRESS
; * MOV #MOL!PGH!DPR!DRY!VV, SGO DAT ;COMPARISON CONSTANT
; * MOVB PORTA, RPCS2(RO) ;SELECT PORT A.
; * MOV RPDS1(RO), STMP2 ;GET THE DRIVE STATUS REGISTER FROM PORT A.
; * MOV STMP2, STMP0 ;COPY IT INTO 'STMP0'
; * BIC #ATA!VV, STMP0 ;CLEAR PORT DEPENDENT BITS FROM THE COPY
; * MOVB PORTB, RPCS2(RO) ;SELECT PORT B.
; * MOV RPDS1(RO), STMP3 ;GET THE DRIVE STATUS REGISTER FROM PORT B.
; * MOV STMP3, STMP1 ;COPY IT INTO 'STMP1'
; * BIC #ATA!VV, STMP1 ;CLEAR PORT DEPENDENT BITS FROM THE COPY
; * CMP STMP0, STMP1 ;IS THE STATUS REGISTER THE SAME FROM BOTH PORTS ?
; * BNE 645 ;OR IF NOT
; * TST STMP0 ;REGISTERS ARE THE SAME: ARE THEY ZERO ?
; * BNE 665 ;OR IF NOT
; * ERROR 34 ;REPORT DRIVE NOT IN NEUTRAL OR NOT SEIZED
; * JMP 685 ;BYPASS THE REST OF THE CHECKS
; * MOV STMP2, SBDAT ;SET UP POSSIBLE BAD DATA FOR ERROR MESSAGE
; * MOV PORTB, PTNBR ;SEIZING PORT IF TEST SHOWS DRIVE NOT IN NEUTRAL
; * MOVB PORTB, RPCS2(RO) ;SELECT PORT B.
; *
; * 645:
; *
; * 665:
; *
; * 685:
    
```


G05

3117	014610	005737	001164			TST	\$TMP0	;SEE IF STATUS EQ 0 FROM PORT A.
3118	014614	001414				BEQ	65\$;BR IF ZERO
3119	014616	013737	001224	001234		MOV	PORTA,PTNBR	;SEIZING PORT IF TEST SHOWS DRIVE NOT IN NEUTRAL
3120	014624	013737	001172	001126		MOV	\$TMP3,\$BDDAT	; 'BAD DATA' FOR ERROR TYPE OUT
3121	014632	113760	001224	000010		MOV	PORTA,RPCS2(RO)	;SELECT PORT A.
3122	014640	005737	001166			TST	\$TMP1	;SEE IF STATUS EQ ZERO FROM PORT B.
3123	014644	001012				BNE	66\$;BR IF NOT
3124	014646	012737	177777	001250	65\$:	MOV	8-1,RELERR	;SET 'RELEASE ERROR' INDICATOR
3125	014654	012760	000011	000000		MOV	811,RPCS1(RO)	;CLEAR THE DRIVE
3126	014662	012760	000013	000000		MOV	813,RPCS1(RO)	;RELEASE THE DRIVE
3127	014670	104017				ERROR	17	;TYPE ERROR MESSAGE 17
3128	014672	013737	001170	001126	66\$:	MOV	\$TMP2,\$BDDAT	;LOOK FOR BIT FAILURES WHEN RPOS1 READ
3129	014700	013737	001224	001234		MOV	PORTA,PTNBR	;CHANGE PORT NUMBER
3130	014706	023737	001124	001170		CMP	\$GDDAT,\$TMP2	;ALL BITS OK ?
3131	014714	001401				BEQ	67\$;BR IF OK FROM PORT A.
3132	014716	104037				ERROR	37	;REPORT ERROR
3133	014720	013737	001172	001126	67\$:	MOV	\$TMP3,\$BDDAT	;CHECK RPOS1 FOR BIT FAILURES - FROM PORT B.
3134	014726	013737	001226	001234		MOV	PORTB,PTNBR	;CHANGE PORT NUMBER
3135	014734	023737	001124	001172		CMP	\$GDDAT,\$TMP3	;SEE IF READ OK FROM PORT B.
3136	014742	001401				BEQ	68\$;BR IF OK
3137	014744	104037				ERROR	37	;REPORT THE ERROR
3138	014746	000240			68\$:	NOP		
3139	014750	104401	024207			TYPE	,SWTCHB	;SWITCH TO 'B'
3140	014754	104401	024272			TYPE	,CONTUE	;PRESS 'CONTINUE'
3141	014760	000000				HALT		
3142								
3143								;VERIFY THAT THE DRIVE IS IN NEUTRAL
3144								
3145	014762	005037	001250			CLR	RELERR	;CLEAR THE 'RELEASE ERROR' INDICATOR
3146	014766	012737	000012	001122		MOV	\$RPOS1,\$BDDADR	;FORM THE ADDRESS OF RPOS1 FOR TYPEOUT
3147	014774	060037	001122			ADD	RO,\$BDDADR	;ADD THE I/O BASE ADDRESS
3148	015000	012737	011700	001124		MOV	\$MOL!PGM!DPR!DRY!VV,\$GDDAT	;COMPARISON CONSTANT
3149	015006	113760	001224	000010		MOV	PORTA,RPCS2(RO)	;SELECT PORT A.
3150	015014	016037	000012	001170		MOV	RPOS1(RO),\$TMP2	;GET THE DRIVE STATUS REGISTER FROM PORT A.
3151	015022	013737	001170	001164		MOV	\$TMP2,\$TMP0	;COPY IT INTO '\$TMP0'
3152	015030	042737	100100	001164		BIC	\$ATA!VV,\$TMP0	;CLEAR PORT DEPENDENT BITS FROM THE COPY
3153	015036	113760	001226	000010		MOV	PORTB,RPCS2(RO)	;SELECT PORT B.
3154	015044	016037	000012	001172		MOV	RPOS1(RO),\$TMP3	;GET THE DRIVE STATUS REGISTER FROM PORT B.
3155	015052	013737	001172	001166		MOV	\$TMP3,\$TMP1	;COPY IT INTO '\$TMP1'
3156	015060	042737	100100	001166		BIC	\$ATA!VV,\$TMP1	;CLEAR PORT DEPENDENT BITS FROM THE COPY
3157	015066	023737	001164	001166		CMP	\$TMP0,\$TMP1	;IS THE STATUS REGISTER THE SAME FROM BOTH PORTS ?
3158	015074	001006				BNE	69\$;BR IF NOT
3159	015076	005737	001164			TST	\$TMP0	;REGISTERS ARE THE SAME: ARE THEY ZERO ?
3160	015102	001045				BNE	71\$;BR IF NOT
3161	015104	104034				ERROR	34	;REPORT DRIVE NOT IN NEUTRAL OR NOT SEIZED
3162	015106	000137	015272			JMP	73\$;BYPASS THE REST OF THE CHECKS
3163	015112	013737	001170	001126	69\$:	MOV	\$TMP2,\$BDDAT	;SET UP POSSIBLE BAD DATA FOR ERROR MESSAGE
3164	015120	013737	001226	001234		MOV	PORTB,PTNBR	;SEIZING PORT IF TEST SHOWS DRIVE NOT IN NEUTRAL
3165	015126	113760	001226	000010		MOV	PORTB,RPCS2(RO)	;SELECT PORT B.
3166	015134	005737	001164			TST	\$TMP0	;SEE IF STATUS EQ 0 FROM PORT A.
3167	015140	001414				BEQ	70\$;BR IF ZERO
3168	015142	013737	001224	001234		MOV	PORTA,PTNBR	;SEIZING PORT IF TEST SHOWS DRIVE NOT IN NEUTRAL
3169	015150	013737	001172	001126		MOV	\$TMP3,\$BDDAT	; 'BAD DATA' FOR ERROR TYPE OUT
3170	015156	113760	001224	000010		MOV	PORTA,RPCS2(RO)	;SELECT PORT A.
3171	015164	005737	001166			TST	\$TMP1	;SEE IF STATUS EQ ZERO FROM PORT B.
3172	015170	001012				BNE	71\$;BR IF NOT

H05

```

3173 015172 012737 177777 001250 70S: MOV 8-1,RELEA ;SET 'RELEASE ERROR' INDICATOR
3174 015200 012760 000011 000000 MOV 811,RPCS1(RO) ;CLEAR THE DRIVE
3175 015206 012760 000013 000000 MOV 813,RPCS1(RO) ;RELEASE THE DRIVE
3176 015214 104020 ERROR 20 ;TYPE ERROR MESSAGE 20
3177 015216 013737 001170 001126 71S: MOV STMP2,SDDAT ;LOOK FOR BIT FAILURES WHEN RPDS1 READ
3178 015224 013737 001224 001234 MOV PORTA,PTNBR ;CHANGE PORT NUMBER
3179 015232 023737 001124 001170 CMP SGDDAT,STMP2 ;ALL BITS OK ?
3180 015240 001401 BEQ 72S ;BR IF OK FROM PORT A.
3181 015242 104037 ERROR 37 ;REPORT ERROR
3182 015244 013737 001172 001126 72S: MOV STMP3,SDDAT ;CHECK RPDS1 FOR BIT FAILURES - FROM PORT B.
3183 015252 013737 001226 001234 MOV PORTB,PTNBR ;CHANGE PORT NUMBER
3184 015260 023737 001124 001172 CMP SGDDAT,STMP3 ;SEE IF READ OK FROM PORT B.
3185 015266 001401 BEQ 73S ;BR IF OK
3186 015270 104037 ERROR 37 ;REPORT THE ERROR
3187 015272 000240 73S: NOP
3188 015274 005737 001266 TST KYBCTL ;SINGLE TEST MODE ?
3189 015300 001402 BEQ 1S ;BR IF NOT
3190 015302 104401 TYPE ,SWTCHN ;RETURN SWITCH TO 'A/B'
3191 015306 000004 1S: SCOPE ;LOOP ?

```

```

*****
*TEST 13 TEST 'CONTROLLER SELECT' SWITCH LOCKED ON PORT A
*
*TEST THE OPERATION OF THE 'CONTROLLER SELECT' SWITCH (DRIVE CYCLED DOWN).
*
* A. CYCLE THE DRIVE DOWN.
*
* B. SWITCH TO CONTROLLER A POSITION. VERIFY THAT THE DRIVE IS IN
* NEUTRAL AND THAT THE STATUS BITS IN RPDS1, AS READ THROUGH BOTH
* PORTS, ARE CORRECT.
*
* C. SWITCH THE 'CONTROLLER SELECT' SWITCH TO A; CYCLE THE DRIVE UP.
*
* D. WHEN THE DRIVE CYCLES UP, VERIFY THAT 'VV-A IS RESET, AND
* THAT 'ATA-A IS SET.
*
* E. ISSUE A DRIVE CLEAR COMMAND AND A READIN PRESET COMMAND THROUGH
* PORT A.
*
* F. VERIFY THAT THE DRIVE CANNOT BE ACCESSED THROUGH PORT B AND
* 'NED' DOES NOT SET WHEN ATTEMPTING TO ACCESS THE DRIVE THROUGH
* PORT B. ATTEMPT TO SET PORT REQUEST BY WRITING 0'S
* INTO RPDS1 THROUGH PORT B.
*
* G. ISSUE A RELEASE COMMAND THROUGH PORT A. VERIFY THAT THE
* DRIVE REMAINS LOCKED ON PORT A.
*
*****

```

```

3223 015310 005737 001266 TST13: TST KYBCTL ;PERFORMING ONLY SINGLE TESTS ?
3224 015310 001406 BEQ 2S ;BR IF NOT
3225 015314 100002 BPL 1S ;BR IF JUST ENTERED TEST
3226 015320 000137 002424 JMP EXEC ;RETURN & GET NEXT TEST NUMBER
3227 015324 012737 177777 001266 1S: MOV 8-1,KYBCTL ;SET SINGLE TEST INDICATOR

```



```

3229 015332 112737 000013 001102 2S:   MOVB   #13,STSTNM   ;TEST NUMBER
3230 015340 012737 015362 001106   MOV   #TEST13,$LPADR ;LOAD LOOP ON TEST ADDRESS
3231 015346 012737 015362 001110   MOV   #TEST13,$LPERR ;LOAD LOOP ON ERROR ADDRESS
3232 015354 012737 000001 001176   MOV   #1,$TIMES      ;DO 1 ITERATION
3233 015362 012706 001100   TEST13: MOV  #STACK,$P     ;SETUP THE STACK POINTER
3234 015366 113760 001224 000010   MOVB  PORTA,$PCS2(RO) ;SELECT PORT A
3235 015374 013737 001224 001234   MOV   PORTA,$PTNBR   ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
3236 015402 104401 024341   TYPE  ,CYCLED       ;'CYCLE DOWN THE DRIVE'
3237
3238 ;:*****
3239 ;WAIT FOR 'MOL' TO RESET
3240
3241 015406 032760 010000 000012 1S:   BIT    #MOL,$RPS1(RO) ;TEST 'MOL'
3242 015414 001374   BNE   IS            ;BR IF IT IS STILL SET
3243 015416 104401 024124   TYPE  ,SWTCHA       ;SWITCH TO 'A'
3244 015422 104401 024363   TYPE  ,CYCLEU       ;'CYCLE UP THE DRIVE'
3245
3246 ;:*****
3247 ;WAIT FOR DRIVE TO CYCLE UP AFTER SWITCH CHANGED
3248
3249 015426 032760 010000 000012 2S:   BIT    #MOL,$RPS1(RO) ;TEST 'MOL' AGAIN
3250 015434 001774   BEQ   2S           ;BR IF NOT SET
3251
3252 ;:*****
3253 ;DRIVE IS CYCLED UP, CHECK STATUS THROUGH PORT A
3254
3255 015436 005037 001244   CLR   CKERR         ;CLEAR THE 'CHECK ERROR' INDICATOR
3256 015442 016037 000012 001126   MOV   $RPS1(RO),$SDDAT ;GET CONTENTS OF $RPS1
3257 015450 012737 000012 001122   MOV   #RPS1,$SDDADR  ;FORM REGISTER ADDRESS OF ERROR MESSAGE
3258 015456 060037 001122   ADD   $R0,$SDDADR    ;ADD R#11 BASE ADDRESS
3259 015462 012737 110600 001124   MOV   #ATA!MOL!DPR!DRY,$SGDDAT ;WHAT REGISTER SHOULD BE
3260 015470 013737 001126 001164   MOV   $SDDAT,$STMP0  ;MOVE REGISTER CONTENTS TO 'STMP0'
3261 015476 042737 066077 001164   BIC   #1C111700,$STMP0 ;SAVE SPECIFIED BITS
3262 015504 023737 001124 001164   CMP   $SGDDAT,$STMP0 ;COMPARE THE BITS
3263 015512 001414   BEQ   64S          ;BR IF OK
3264 015514 013737 001126 001174   MOV   $SDDAT,$STMP4  ;COPY 'BAD DATA'
3265 015522 042737 111700 001174   BIC   #111700,$STMP4 ;CLEAR THE MASKED BITS
3266 015530 053737 001174 001124   BIS   $STMP4,$SGDDAT ;'OR' WITH GOOD DATA FOR TYPEOUT
3267 015536 104021   ERROR 21           ;TYPE MESSAGE 21
3268 015540 005137 001244   COM   CKERR         ;SET THE REGISTER COMPARE ERROR INDICATOR
3269 015544 000240 64S:   NOP
3270
3271 ;:*****
3272 ;SET VOLUME VALID FOR PORT A
3273
3274 015546 012760 000011 000000   MOV   #11,$RPCS1(RO) ;ISSUE A DRIVE CLEAR
3275 015554 012760 000021 000000   MOV   #21,$RPCS1(RO) ;ISSUE A READIN PRESET
3276 015562 012760 010000 000032   MOV   #FMT22,$RPOF(RO) ;SET FMT22
3277
3278 ;:*****
3279 ;CHECK THE DRIVE STATUS THROUGH PORT B; VERIFY THAT 'NED' DOES NOT
3280 ;SET WHEN THE DRIVE IS ACCESSED THROUGH PORT B.
3281
3282 015570 113760 001226 000010   MOVB  PORTB,$RPCS2(RO) ;SELECT PORT B
3283 015576 013737 001226 001234   MOV   PORTB,$PTNBR   ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
3284 015604 005037 001244   CLR   CKERR         ;CLEAR THE 'CHECK ERROR' INDICATOR

```


J05

MD-11-DZRJF-A, RPO4/5/6 DUAL CONTRLR LOGIC TEST - PART 2
DZRJFA.CMB 02-NOV-76 19:11 T13

MAY11 27(1006) 02-NOV-76 19:12 PAGE 61
TEST 'CONTROLLER SELECT' SWITCH LOCKED ON PORT A

3285	015610	016037	000012	001126	MOV	RPDS1(RO),SDDAT	:GET CONTENTS OF RPDS1
3286	015616	012737	000012	001122	MOV	#RPDS1,SBDADR	:FORM REGISTER ADDRESS OF ERROR MESSAGE
3287	015624	060037	001122		ADD	RO,SBDADR	:ADD RH11 BASE ADDRESS
3288	015630	005037	001124		CLR	SGDDAT	:WHAT REGISTER SHOULD BE
3289	015634	013737	001126	001164	MOV	SDDAT,STMP0	:MOVE REGISTER CONTENTS TO 'STMP0'
3290	015542	042737	000077	001164	BIC	#1C177700,STMP0	:SAVE SPECIFIED BITS
3291	015650	023737	001124	001164	CMP	SGDDAT,STMP0	:COMPARE THE BITS
3292	015656	001414			BEQ	66\$:BR IF OK
3293	015660	013737	001126	001174	MOV	SDDAT,STMP4	:COPY 'BAD DATA'
3294	015666	042737	177700	001174	BIC	#177700,STMP4	:CLEAR THE MASKED BITS
3295	015674	053737	001174	001124	BIS	STMP4,SGDDAT	: 'OR' WITH GOOD DATA FOR TYPEOUT
3296	015702	104022			ERROR	22	:TYPE MESSAGE 22
3297	015704	005137	001244		COM	CKERR	:SET THE REGISTER COMPARE ERROR INDICATOR
3298	015710	000240			NOP		
3299	015712	005037	001244		66\$: CLR	CKERR	:CLEAR THE 'CHECK ERROR' INDICATOR
3300	015716	016037	000010	001126	MOV	RPCS2(RO),SDDAT	:GET CONTENTS OF RPCS2
3301	015724	012737	000010	001122	MOV	#RPCS2,SBDADR	:FORM REGISTER ADDRESS OF ERROR MESSAGE
3302	015732	060037	001122		ADD	RO,SBDADR	:ADD RH11 BASE ADDRESS
3303	015736	005037	001124		CLR	SGDDAT	:WHAT REGISTER SHOULD BE
3304	015742	013737	001126	001164	MOV	SDDAT,STMP0	:MOVE REGISTER CONTENTS TO 'STMP0'
3305	015750	042737	167777	001164	BIC	#1CNE0,STMP0	:SAVE SPECIFIED BITS
3306	015756	023737	001124	001164	CMP	SGDDAT,STMP0	:COMPARE THE BITS
3307	015764	001414			BEQ	68\$:BR IF OK
3308	015766	013737	001126	001174	MOV	SDDAT,STMP4	:COPY 'BAD DATA'
3309	015774	042737	010000	001174	BIC	#NE0,STMP4	:CLEAR THE MASKED BITS
3310	016002	053737	001174	001124	BIS	STMP4,SGDDAT	: 'OR' WITH GOOD DATA FOR TYPEOUT
3311	016010	104023			ERROR	23	:TYPE MESSAGE 23
3312	016012	005137	001244		COM	CKERR	:SET THE REGISTER COMPARE ERROR INDICATOR
3313	016016	000240			68\$: NOP		
3314	016020	005060	000012		CLR	RPDS1(RO)	:TRY TO SET REQUEST BY WRITING THROUGH :THE LOCKED OUT PORT (PORT 'B')
3315							
3316							
3317							
3318							
3319							
3320	016024	113760	001224	000010	MOV	PORTA,RPCS2(RO)	:SELECT PORT A
3321	016032	013737	001224	001234	MOV	PORTA,PTNBR	:MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
3322	016040	012760	000013	000012	MOV	#13,RPDS1(RO)	:ISSUE A RELEASE THROUGH PORT A
3323	016046	013737	001224	001236	MOV	PORTA,SEIZPT	:ADDRESS OF 'LOCKED ON' PORT
3324	016054	113760	001226	000010	MOV	PORTB,RPCS2(RO)	:SELECT PORT B
3325	016062	013737	001226	001234	MOV	PORTB,PTNBR	:MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
3326	016070	005037	001244		CLR	CKERR	:CLEAR THE 'CHECK ERROR' INDICATOR
3327	016074	016037	000012	001126	MOV	RPDS1(RO),SDDAT	:GET CONTENTS OF RPDS1
3328	016102	012737	000012	001122	MOV	#RPDS1,SBDADR	:FORM REGISTER ADDRESS OF ERROR MESSAGE
3329	016110	060037	001122		ADD	RO,SBDADR	:ADD RH11 BASE ADDRESS
3330	016114	005037	001124		CLR	SGDDAT	:WHAT REGISTER SHOULD BE
3331	016120	013737	001126	001164	MOV	SDDAT,STMP0	:MOVE REGISTER CONTENTS TO 'STMP0'
3332	016126	042737	000077	001164	BIC	#1C177700,STMP0	:SAVE SPECIFIED BITS
3333	016134	023737	001124	001164	CMP	SGDDAT,STMP0	:COMPARE THE BITS
3334	016142	001414			BEQ	70\$:BR IF OK
3335	016144	013737	001126	001174	MOV	SDDAT,STMP4	:COPY 'BAD DATA'
3336	016152	042737	177700	001174	BIC	#177700,STMP4	:CLEAR THE MASKED BITS
3337	016160	053737	001174	001124	BIS	STMP4,SGDDAT	: 'OR' WITH GOOD DATA FOR TYPEOUT
3338	016166	104024			ERROR	24	:TYPE MESSAGE 24
3339	016170	005137	001244		COM	CKERR	:SET THE REGISTER COMPARE ERROR INDICATOR
3340	016174	000240			70\$: NOP		

K05

```

3341
3342
3343
3344 016176 105737 001103          TSTB   SERFLG          ;DID AN ERROR OCCUR
3345 016202 001412          BEQ    3$              ;BR IF NOT
3346 016204 032777 001000 162726  BIT    #SW09,2SWR     ;SEE IF LOOP ON ERROR (SWR9=1)
3347 016212 001406          BEQ    3$              ;BR IF NOT
3348 016214 105037 001103          CLRB   SERFLG          ;CLEAR THE ERROR FLAG
3349 016220 005037 001176          CLR    $TIMES         ;CLEAR THE MAX ITERATION COUNT
3350 016224 000177 162660          JMP    2$LPERR        ;GO TO THE LOOP ADDRESS
3351 016230 005737 001266          3$:   TST    KYBCTL      ;IN SINGLE TEST MODE ?
3352 016234 001460          BEQ    6$              ;BR IF NOT
3353 016236 032777 040000 162674  BIT    #SW14,2SWR     ;LOOP ON TEST ?
3354 016244 001054          BNE    6$              ;BR IF LOOPING
3355 016246 104401 024341          TYPE  ,CYCLED         ;TYPE 'CYCLE DOWN'
3356 016252 104401 024035          TYPE  ,SWTCHN        ;'SWITCH TO A/B'
3357 016256 104401 024363          TYPE  ,CYCLEU        ;'CYCLE THE DRIVE UP'
3358 016262 113760 001224 000010  MOVB   PORTA,RPCS2(RO) ;SELECT PORT A
3359 016270 013737 001224 001234  MOV    PORTA,PTNBR    ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
3360 016276 032760 010000 000012  4$:   BIT    #MOL,RPDS1(RO) ;CHECK 'MOL'
3361 016304 001374          BNE    4$              ;BR IF SET (DRIVE NOT CYCLED DOWN)
3362 016306 032760 010000 000012  5$:   BIT    #MOL,RPDS1(RO) ;CHECK 'MOL' AGAIN
3363 016314 001774          BEQ    5$              ;BR IF NOT SET (DRIVE NOT CYCLED UP)

```

 ;SET VOLUME VALID FOR BOTH PORTS

```

3367
3368 016316 012760 000011 000000  MOV    #11,RPCS1(RO)  ;ISSUE A DRIVE CLEAR THROUGH PORT A
3369 016324 012760 000021 000000  MOV    #21,RPCS1(RO)  ;ISSUE A READIN PRESET THROUGH PORT A
3370 016332 012760 000013 000000  MOV    #13,RPCS1(RO)  ;RELEASE PORT A
3371 016340 113760 001226 000010  MOVB   PORTB,RPCS2(RO) ;SELECT PORT B
3372 016346 013737 001226 001234  MOV    PORTB,PTNBR    ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
3373 016354 012760 000021 000000  MOV    #21,RPCS1(RO)  ;ISSUE A READIN PRESET THROUGH PORT B
3374 016362 012760 010000 000032  MOV    #FMT22,RPOF(RO) ;SET FMT22
3375 016370 012760 000013 000000  MOV    #13,RPCS1(RO)  ;RELEASE PORT B
3376 016376 104401 001207          6$:   TYPE  ,SCALF        ;CR-LF
3377 016402 012737 011610 001254  MOV    #5000.,WATCH   ;SPINDLE MOTOR 'COOL DOWN' DELAY
3378 016410 005737 001254          7$:   TST    WATCH        ;FINISHED ?
3379 016414 001375          BNE    7$              ;BR IF NOT
3380 016416 000004          SCOPE
3381 016420 000400          BR     TST14          ;GO TO NEXT TEST

```

 ;TEST 14 TEST 'CONTROLLER SELECT' SWITCH LOCKED ON PORT B

 ;TEST THE OPERATION OF THE 'CONTROLLER SELECT' SWITCH (DRIVE CYCLED DOWN).

- *****
- ***** A. CYCLE THE DRIVE DOWN.
- *****
- ***** B. SWITCH TO CONTROLLER B POSITION. VERIFY THAT THE DRIVE IS IN NEUTRAL AND THAT THE STATUS BITS IN RPDS1, AS READ THROUGH BOTH PORTS, ARE CORRECT.
- *****
- ***** C. SWITCH THE 'CONTROLLER SELECT' SWITCH TO B; CYCLE THE DRIVE UP.
- *****
- ***** D. WHEN THE DRIVE CYCLES UP, VERIFY THAT 'VV-B IS RESET, AND
- *****

3396

L05

3397
3398
3399
3400
3401
3402
3403
3404
3405
3406
3407
3408
3409
3410
3411
3412
3413
3414
3415
3416
3417
3418
3419
3420
3421
3422
3423
3424
3425
3426
3427
3428
3429
3430
3431
3432
3433
3434
3435
3436
3437
3438
3439
3440
3441
3442
3443
3444
3445
3446
3447
3448
3449
3450
3451
3452

- * THAT 'ATA-B IS SET.
- * **
- * E. ISSUE A DRIVE CLEAR COMMAND AND A READIN PRESET COMMAND THROUGH PORT B.
- * **
- * F. VERIFY THAT THE DRIVE CANNOT BE ACCESSED THROUGH PCRT A AND 'NED' DOES NOT SET WHEN ATEMPTING TO ACCESS THE DRIVE THROUGH PORT A. ATTEMPT TO SET PORT REQUEST BY WRITING 0'S INTO RPDS1 THROUGH PORT A.
- * **
- * G. ISSUE A RELEASE COMMAND THROUGH PORT B. VERIFY THAT THE DRIVE REMAINS LOCKED ON PORT B.
- * **
- * H. CYCLE THE DRIVE DOWN. CHANGE THE 'CONTROLLER SELECT' SWITCH TO A/B; CYCLE THE DRIVE UP.
- * **
- * I. VERIFY THAT BOTH PORTS CAN ACCESS THE DRIVE, THAT BOTH ATTENTION BITS ARE SET, AND THAT BOTH 'VV' BITS ARE RESET.
- * **

TST14:

016422			
016422	005737	001266	
016426	001406		
016430	100002		
016432	000137	002424	
016436	012737	177777	001266
016444	112737	000014	001102
016452	012737	016474	001106
016460	012737	016474	001110
016466	012737	000001	001176
016474	012706	001100	
016500	113760	001226	000010
016506	013737	001226	001234
016514	104401	024341	

```

TST14:      TST      KYBCTL      ;PERFORMING ONLY SINGLE TESTS ?
            BEQ      2$          ;BR IF NOT
            BPL      1$          ;BR IF JUST ENTERED TEST
            JMP      EXEC        ;RETURN & GET NEXT TEST NUMBER
1$:         MOV      #-1,KYBCTL  ;SET SINGLE TEST INDICATOR
2$:         MOV      #14,$STSTM  ;TEST NUMBER
            MOV      #TEST14,$LPADR ;LOAD LOOP ON TEST ADDRESS
            MOV      #TEST14,$LPERR ;LOAD LOOP ON ERROR ADDRESS
            MOV      #1,$TIMES   ;DO 1 ITERATION
TEST14:    MOV      #STACK,$SP  ;SETUP THE STACK POINTER
            MOV      PORTB,$PCS2(R0) ;SELECT PORT B
            MOV      PORTB,$PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
            TYPE     ,CYCLED     ;'CYCLE DOWN THE DRIVE'

```

;WAIT FOR 'MOL' TO RESET

016520	032760	010000	000012
016526	001374		
016530	104401	024207	
016534	104401	024363	

```

1$:         BIT      #MOL,$RPDS1(R0) ;TEST 'MOL'
            BNE      1$          ;BR IF IT IS STILL SET
            TYPE     ,SWTCHB     ;SWITCH TO 'B'
            TYPE     ,CYCLEU     ;'CYCLE UP THE DRIVE'

```

;WAIT FOR DRIVE TO CYCLE UP AFTER SWITCH CHANGED

016540	032760	010000	000012
016546	001774		

```

2$:         BIT      #MOL,$RPDS1(R0) ;TEST 'MOL' AGAIN
            BEQ      2$          ;BR IF NOT SET

```

;DRIVE IS CYCLED UP, CHECK STATUS THROUGH PORT B

016550	005037	001244	
016554	016037	000012	001126
016562	012737	000012	001122
016570	060037	001122	

```

            CLR      CKERR      ;CLEAR THE 'CHECK ERROR' INDICATOR
            MOV      $RPDS1(R0),$SDDAT ;GET CONTENTS OF RPDS1
            MOV      #RPDS1,$SDDADR ;FORM REGISTER ADDRESS OF ERROR MESSAGE
            ADD      R0,$SDDADR  ;ADD RH11 BASE ADDRESS

```


M05

```

3453 016574 012737 110600 001124      MOV      #ATA!MOL!DPR!DRY,$GDDAT ;WHAT REGISTER SHOULD BE
3454 016602 013737 001126 001164      MOV      $BDDAT,$STMP0 ;MOVE REGISTER CONTENTS TO 'STMP0'
3455 016610 042737 066077 001164      BIC      #1C111700,$STMP0 ;SAVE SPECIFIED BITS
3456 016616 023737 001124 001164      CMP      $GDDAT,$STMP0 ;COMPARE THE BITS
3457 016624 001414                BEQ      64$ ;BR IF OK
3458 016626 013737 001126 001174      MOV      $BDDAT,$STMP4 ;COPY 'BAD DATA'
3459 016634 042737 111700 001174      BIC      #111700,$STMP4 ;CLEAR THE MASKED BITS
3460 016642 053737 001174 001124      BIS      $STMP4,$GDDAT ;'OR' WITH GOOD DATA FOR TYPEOUT
3461 016650 104021                ERROR    21 ;TYPE MESSAGE 21
3462 016652 005137 001244                COM      CKERR ;SET THE REGISTER COMPARE ERROR INDICATOR
3463 016656 000240                64$:    NOP
3464
3465 ;:*****
3466 ;SET VOLUME VALID FOR PORT B
3467
3468 016660 012760 000011 000000      MOV      #11,$RPCS1(RO) ;ISSUE A DRIVE CLEAR
3469 016666 012760 000021 000000      MOV      #21,$RPCS1(RO) ;ISSUE A READIN PRESET
3470 016674 012760 010000 000032      MOV      #FMT22,$RPOF(RO) ;SET FMT22
3471
3472 ;:*****
3473 ;CHECK THE DRIVE STATUS THROUGH PORT A; VERIFY THAT 'NED' DOES NOT
3474 ;SET WHEN THE DRIVE IS ACCESSED THROUGH PORT A.
3475
3476 016702 113760 001224 000010      MOV      PORTA,$RPCS2(RO) ;SELECT PORT A
3477 016710 013737 001224 001234      MOV      PORTA,$PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
3478 016716 005037 001244                CLR      CKERR ;CLEAR THE 'CHECK ERROR' INDICATOR
3479 016722 016037 000012 001126      MOV      $RPDS1(RO),$SBDDAT ;GET CONTENTS OF $RPDS1
3480 016730 012737 000012 001122      MOV      #RPDS1,$SBADR ;FORM REGISTER ADDRESS OF ERROR MESSAGE
3481 016736 060037 001122                ADD      RO,$SBADR ;ADD RH11 BASE ADDRESS
3482 016742 005037 001124                CLR      $GDDAT ;WHAT REGISTER SHOULD BE
3483 016746 013737 001126 001164      MOV      $BDDAT,$STMP0 ;MOVE REGISTER CONTENTS TO 'STMP0'
3484 016754 042737 000077 001164      BIC      #1C177700,$STMP0 ;SAVE SPECIFIED BITS
3485 016762 023737 001124 001164      CMP      $GDDAT,$STMP0 ;COMPARE THE BITS
3486 016770 001414                BEQ      66$ ;BR IF OK
3487 016772 013737 001126 001174      MOV      $BDDAT,$STMP4 ;COPY 'BAD DATA'
3488 017000 042737 177700 001174      BIC      #177700,$STMP4 ;CLEAR THE MASKED BITS
3489 017006 053737 001174 001124      BIS      $STMP4,$GDDAT ;'OR' WITH GOOD DATA FOR TYPEOUT
3490 017014 104022                ERROR    22 ;TYPE MESSAGE 22
3491 017016 005137 001244                COM      CKERR ;SET THE REGISTER COMPARE ERROR INDICATOR
3492 017022 000240                66$:    NOP
3493 017024 005037 001244                CLR      CKERR ;CLEAR THE 'CHECK ERROR' INDICATOR
3494 017030 016037 000010 001126      MOV      $RPCS2(RO),$SBDDAT ;GET CONTENTS OF $RPCS2
3495 017036 012737 000010 001122      MOV      #RPCS2,$SBADR ;FORM REGISTER ADDRESS OF ERROR MESSAGE
3496 017044 060037 001122                ADD      RO,$SBADR ;ADD RH11 BASE ADDRESS
3497 017050 005037 001124                CLR      $GDDAT ;WHAT REGISTER SHOULD BE
3498 017054 013737 001126 001164      MOV      $BDDAT,$STMP0 ;MOVE REGISTER CONTENTS TO 'STMP0'
3499 017062 042737 167777 001164      BIC      #1CNED,$STMP0 ;SAVE SPECIFIED BITS
3500 017070 023737 001124 001164      CMP      $GDDAT,$STMP0 ;COMPARE THE BITS
3501 017076 001414                BEQ      68$ ;BR IF OK
3502 017100 013737 001126 001174      MOV      $BDDAT,$STMP4 ;COPY 'BAD DATA'
3503 017106 042737 010000 001174      BIC      #NED,$STMP4 ;CLEAR THE MASKED BITS
3504 017114 053737 001174 001124      BIS      $STMP4,$GDDAT ;'OR' WITH GOOD DATA FOR TYPEOUT
3505 017122 104023                ERROR    23 ;TYPE MESSAGE 23
3506 017124 005137 001244                COM      CKERR ;SET THE REGISTER COMPARE ERROR INDICATOR
3507 017130 000240                68$:    NOP
3508 017132 005060 000012                CLR      $RPDS1(RO) ;TRY TO SET REQUEST BY WRITING THROUGH

```


N05

MD-11-DZRJF-A, RPO4/5/6 DUAL CONTRLR LOGIC TEST - PART 2
DZRJFA.CMB 02-NOV-76 19:11

MACY11 27(1006) 02-NOV-76 19:12 PAGE 65
T14 TEST 'CONTROLLER SELECT' SWITCH LOCKED ON PORT B

```

;THE LOCKED OUT PORT (PORT 'A')
3509
3510
3511 ;:*****
3512 ;VERIFY THAT DRIVE STAYS LOCKED ON PORT B
3513
3514 017136 113760 001226 000010      MOV      PORTB,RPCS2(RO) ;SELECT PORT B
3515 017144 013737 001226 001234      MOV      PORTB,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
3516 017152 012760 000013 000012      MOV      #13,RPDS1(RO) ;ISSUE A RELEASE THROUGH PORT B
3517 017160 013737 001226 001236      MOV      PORTB,SEIZPT ;ADDRESS OF 'LOCKED ON' PORT
3518 017166 113760 001224 000010      MOV      PORTA,RPCS2(RO) ;SELECT PORT A
3519 017174 013737 001224 001234      MOV      PORTA,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
3520 017202 005037 001244          CLR      CKERR ;CLEAR THE 'CHECK ERROR' INDICATOR
3521 017206 016037 000012 001126      MOV      RPDS1(RO),SBDAT ;GET CONTENTS OF RPDS1
3522 017214 012737 000012 001122      MOV      #RPDS1,SBDADR ;FORM REGISTER ADDRESS OF ERROR MESSAGE
3523 017222 060037 001122          ADD      RO,SBDADR ;ADD RH11 BASE ADDRESS
3524 017226 005037 001124          CLR      $GDDAT ;WHAT REGISTER SHOULD BE
3525 017232 013737 001126 001164      MOV      SBDAT,$TMPD ;MOVE REGISTER CONTENTS TO '$TMPD'
3526 017240 042737 000077 001164      BIC      #1C17700,$TMPD ;SAVE SPECIFIED BITS
3527 017246 023737 001124 001164      CMP      $GDDAT,$TMPD ;COMPARE THE BITS
3528 017254 001414          BEQ      70$ ;BR IF OK
3529 017256 013737 001126 001174      MOV      SBDAT,$TMP4 ;COPY 'BAD' DATA
3530 017264 042737 177700 001174      BIC      #177700,$TMP4 ;CLEAR THE MASKED BITS
3531 017272 053737 001174 001124      BIS      $TMP4,$GDDAT ;'OR' WITH GOOD DATA FOR TYPEOUT
3532 017300 104024          ERROR   24 ;TYPE MESSAGE 24
3533 017302 005137 001244          COM      CKERR ;SET THE REGISTER COMPARE ERROR INDICATOR
3534 017306 000240          70$:   NOP
3535
3536 ;IF ERROR OCCURRED, CHECK FOR LOOP ON TEST
3537
3538 017310 105737 001103          TSTB    $ERFLG ;DID AN ERROR OCCUR
3539 017314 001412          BEQ      3$ ;BR IF NOT
3540 017316 032777 001000 161614      BIT     #SW09,$SWR ;SEE IF LOOP ON ERROR (SWR9=1)
3541 017324 001406          BEQ      3$ ;BR IF NOT
3542 017326 105037 001103          CLRB    $ERFLG ;CLEAR THE ERROR FLAG
3543 017332 005037 001176          CLR     $TIMES ;CLEAR THE MAX ITERATION COUNT
3544 017336 000177 161546          JMP     $SLPERR ;GO TO THE LOOP ADDRESS
3545 017342 032777 040000 161570 3$:   BIT     #SW14,$SWR ;LOOP ON TEST ?
3546 017350 001054          BNE     6$ ;BR IF LOOPING
3547 017352 104401 024341          TYPE   ,CYCLED ;TYPE 'CYCLE DOWN'
3548 017356 104401 024035          TYPE   ,SWTCHN ;'SWITCH TO A/B'
3549 017362 104401 024363          TYPE   ,CYCLEU ;'CYCLE THE DRIVE UP'
3550 017366 113760 001226 000010      MOV      PORTB,RPCS2(RO) ;SELECT PORT B
3551 017374 013737 001226 001234      MOV      PORTB,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT
3552 017402 032760 010000 000012 4$:   BIT     #MOL,RPDS1(RO) ;CHECK 'MOL'
3553 017410 001374          BNE     4$ ;BR IF SET (DRIVE NOT CYCLED DOWN)
3554 017412 032760 010000 000012 5$:   BIT     #MOL,RPDS1(RO) ;CHECK 'MOL' AGAIN
3555 017420 001774          BEQ     5$ ;BR IF NOT SET (DRIVE NOT CYCLED UP)
3556
3557 ;:*****
3558 ;SET VOLUME VALID FOR BOTH PORTS
3559
3560 017422 012760 000011 000000      MOV      #11,RPCS1(RO) ;ISSUE A DRIVE CLEAR THROUGH PORT B
3561 017430 012760 000021 000000      MOV      #21,RPCS1(RO) ;ISSUE A READIN PRESET THROUGH PORT B
3562 017436 012760 000013 000000      MOV      #13,RPCS1(RO) ;RELEASE PORT B
3563 017444 113760 001224 000010      MOV      PORTA,RPCS2(RO) ;SELECT PORT A
3564 017452 013737 001224 001234      MOV      PORTA,PTNBR ;MOVE PORT ADDRESS TO LOCATION FOR TYPEOUT

```


B06

3565	017460	012760	000021	000000		MOV #21,RPCS1(RO)	;ISSUE A READIN PRESET THROUGH PORT A
3566	017466	012760	010000	000032		MOV #FMT22,RPOF(RO)	;SET FMT22
3567	017474	012760	000013	000000		MOV #13,RPCS1(RO)	;RELEASE PORT A
3568	017502	012737	011610	001254	65:	MOV #5000.,WATCH	;SPINDLE MOTOR 'COOL DOWN' DELAY
3569	017510	005737	001254		75:	TST WATCH	;FINISHED ?
3570	017514	001375				BNE 75	;BR IF NOT
3571	017516	000004				SCOPE	;LOOP ?
3572	017520	000137	017524			JMP SEOP	;GO TO THE END OF PASS ROUTINE
3573							
3574						.SBTTL	END OF PASS ROUTINE
3575							
3576						*****	
3577						;	INCREMENT THE PASS NUMBER (\$PASS)
3578						;	INDICATE END-OF-PROGRAM AFTER 1 PASSES THRU THE PROGRAM
3579						;	TYPE "END PASS #XXXXX TOTAL NUMBER OF ERRORS SINCE LAST REPORT YYYY"
3580						;	WHERE XXXX AND YYYY ARE DECIMAL NUMBERS
3581						;	IF THERES A MONITOR GO TO IT
3582						;	IF THERE ISN'T JUMP TO TSTIAA
3583							
3584	017524					SEOP:	
3585	017524	005737	001266			TST KYBCTL	;ENTERED TEST VIA KEYBOARD COMMAND ?
3586	017530	001402				BEQ .+6	;BR IF NOT
3587	017532	000137	002424			JMP EXEC	;RETURN TO KEYBOARD CONTROL
3588	017536	005037	001102			CLR \$TSTNM	;ZERO THE TEST NUMBER
3589	017542	005037	001176			CLR \$TIMES	;ZERO THE NUMBER OF ITERATIONS
3590	017546	005237	001100			INC \$PASS	;INCREMENT THE PASS NUMBER
3591	017552	042737	100000	001100		BIC #100000,\$PASS	;DON'T ALLOW A NEG. NUMBER
3592	017560	005327				DEC (PC)+	;LOOP?
3593	017562	000001			SEOPCT:	.WORD 1	
3594	017564	003063				BGT \$DOAGN	;YES
3595	017566	012737				MOV (PC)+,\$(PC)+	;RESTORE COUNTER
3596	017570	000001			SENDCT:	.WORD 1	
3597	017572	017562				SEOPCT	
3598	017574	104401	017602			TYPE ,65\$;TYPE ASCIZ STRING
3599	017600	000407				BR ,64\$;GET OVER THE ASCIZ
3600					;;65\$:	.ASCIZ <12><15>/END PASS #/	
3601	017620				64\$:		
3602	017620	013746	001100			MOV \$PASS,-(\$P)	;SAVE \$PASS FOR TYPEOUT
3603							;TYPE PASS NUMBER
3604	017624	104405				TYPDS	;GO TYPE--DECIMAL ASCII WITH SIGN
3605	017626	104401	017634			TYPE ,67\$;TYPE ASCIZ STRING
3606	017632	000421				BR ,66\$;GET OVER THE ASCIZ
3607					;;67\$:	.ASCIZ / TOTAL ERRORS SINCE LAST REPORT /	
3608	017676				66\$:		
3609	017676	013746	001112			MOV \$ERTTL,-(\$P)	;SAVE \$ERTTL FOR TYPEOUT
3610							;TOTAL NUMBER OF ERRORS
3611	017702	104405				TYPDS	;GO TYPE--DECIMAL ASCII WITH SIGN
3612	017704	104401	001207			TYPE	;TYPE CARRIAGE RETURN, LINE FEED
3613	017710	005037	001112			CLR \$ERTTL	;CLEAR ERROR TOTAL
3614	017714	013700	000042		SGET42:	MOV #42,RO	;GET MONITOR ADDRESS
3615	017720	001405				BEQ \$DOAGN	;BRANCH IF NO MONITOR
3616	017722	000005				RESET	;CLEAR THE WORLD
3617	017724	004710			SENDAD:	JSR PC,(RO)	;GO TO MONITOR
3618	017726	000240				NOP	;SAVE ROOM
3619	017730	000240				NOP	;FOR
3620	017732	000240				NOP	;ACT11

END OF PASS ROUTINE

```

3621 017734 SDOAGN:
3622 017734 000137 JMP @PC)+ ;;RETURN
3623 017736 002706 SRTNAD: .WORD TST1AA
3624 017740 377 377 000 SENULL: .BYTE -1,-1,0 ;;NULL CHARACTER STRING
3625 017744 .EVEN
3626
3627 ;;*****
3628
3629 .SBTTL *** SUBROUTINES ***
3630
3631 ;;*****
3632
3633 ;ROUTINE TO CHECK FOR KW11-L OR KW11-P CLOCKS
3634
3635 017744 012737 020014 000004 CKCLK: MOV @CKCLK1,@ERRVEC ;SET UP VECTOR FOR CLOCK CHECK
3636 017752 005037 000006 CLR @ERRVEC+2 ;NEW PSW
3637 017756 005777 161230 TST @SLKCSR ;CHECK FOR KW11-P
3638 017762 013701 001216 MOV SLPVEC,R1 ;KW11-P VECTOR ADDRESS
3639 017766 012721 020076 MOV @CLOCK,(R1)+ ;SET UP KW11-P VECTOR
3640 017772 012711 000300 MOV #300,(R1) ;PSW - PRI 6
3641 017776 012777 177777 161210 MOV @-1,@SLKCSB ;LOAD COUNTER BUFFER WITH 1'S
3642 020004 012777 000135 161200 MOV @135,@SLKCSR ;SET CLOCK - CNT UP, 16MS, CONT INT
3643 020012 000425 BR CKCLK3
3644 020014 062706 000004 CKCLK1: ADD #4,SP ;RESTORE THE STACK POINTER
3645 020020 012737 020056 000004 MOV @CKCLK2,@ERRVEC ;CHANGE ERROR VECTOR TO CHECK FOR KW11-L
3646 020026 005777 161166 TST @SLKS ;LOOK FOR KW11-L
3647 020032 013701 001222 MOV SLLVEC,R1 ;KW11-L VECTOR ADDRESS
3648 020036 012721 020076 MOV @CLOCK,(R1)+ ;SET UP KW11-L VECTOR
3649 020042 012711 000300 MOV #300,(R1) ;PSW - PRI 6
3650 020046 012777 000100 161144 MOV @100,@SLKS ;SET KW11-L INTERRUPT
3651 020054 000404 BR CKCLK3
3652 020056 062706 000004 CKCLK2: ADD #4,SP ;RESTORE THE STACK POINTER
3653 020062 062716 000002 ADD #2,(SP) ;INCREMENT RETURN, NO CLOCK
3654 020066 012737 000006 000004 CKCLK3: MOV #6,@ERRVEC ;RESTORE THE ERROR VECTOR
3655 020074 000207 RTS PC
3656
3657 ;ROUTINE TO COUNT CLOCK TICKS
3658
3659 020076 062737 000021 001252 CLOCK: ADD #17,TIME ;ADD 17 MS TO ELAPSED TIME COUNTER
3660 020104 005737 001254 TST WATCH ;IS WATCH ALREADY ZERO ?
3661 020110 001406 BEQ IS ;BR IF IT IS
3662 020112 162737 000021 001254 SUB #17,WATCH ;SUBTRACT 17 MS FROM WATCH DOG COUNTER
3663 020120 100002 BPL IS ;BR IF NOT MINUS
3664 020122 005037 001254 CLR WATCH ;CLEAR WATCH DOG COUNTER
3665 020126 000002 IS: RTI ;RETURN
3666
3667 ;ROUTINE TO CALCULATE + 25% TIME TOLERANCE VALUES
3668
3669 020130 005746 TOLER: TST -(SP) ;MAKE ROOM ON THE STACK
3670 020132 016616 000002 MOV 2(SP),(SP) ;SAVE STACK
3671 020136 013546 MOV @R5+,-(SP) ;GET TIME VALUE
3672 020140 011666 000004 MOV (SP),4(SP) ;MOVE TIME VALUE
3673 020144 006216 ASR (SP) ;DIVIDE BY 2
3674 020146 006216 ASR (SP) ;DIVIDE BY 2 AGAIN (FOR A TOTAL OF 4)
3675 020150 062666 000002 ADD (SP)+,2(SP) ;CALCULATE UPPER LIMIT FOR TIMEOUT

```


*** SUBROUTINES ***

```

3677 020154 000205          RTS      R5          ;RETURN WITH TOLERANCES ON THE STACK
3678
3679 ;;*****
3680
3681 .SBTTL 'SYSMAC' UTILITY ROUTINES
3682
3683 .SBTTL SCOPE HANDLER ROUTINE
3684
3685 ;;*****
3686 ;:THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
3687 ;:AND LOAD THE TEST NUMBER($STNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
3688 ;:AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
3689 ;:THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
3690 ;:SW14=1      LOOP ON TEST
3691 ;:SW11=1      INHIBIT ITERATIONS
3692 ;:CALL
3693 ;:*          SCOPE          ;;SCOPE=IOT
3694
3695 020156          $SCOPE:
3696 020156 104407          CKSWR
3697 020160 032777 040000 160752 1$: BIT      @BIT14,@SWR      ;;TEST FOR CHANGE IN SOFT-SWR
3698 020166 001055          BNE      $OVER      ;;LOOP ON PRESENT TEST?
3699 ;:*****START OF CODE FOR THE XOR TESTER*****
3700 020170 000416          $XTSTR: BR      6$      ;;YES IF SW14=1
3701 ;:IF RUNNING ON THE "XOR" TESTER CHANGE
3702 020172 013746 000004          MOV      @ERRVEC,-(SP) ;;THIS INSTRUCTION TO A "NOP" (NOP=240)
3703 020176 012737 020216 000004          MOV      @SS,@ERRVEC ;;SAVE THE CONTENTS OF THE ERROR VECTOR
3704 020204 005737 177060          TST     @177060      ;;SET FOR TIMEOUT
3705 020210 012637 000004          MOV      (SP)+,@ERRVEC ;;TIME OUT ON XOR?
3706 020214 000436          BR      $SVLAD      ;;RESTORE THE ERROR VECTOR
3707 020216 022626          5$: CMP     (SP)+,(SP)+ ;;GO TO THE NEXT TEST
3708 020220 012637 000004          MOV      (SP)+,@ERRVEC ;;CLEAR THE STACK AFTER A TIME OUT
3709 020224 000436          BR      $OVER      ;;RESTORE THE ERROR VECTOR
3710 020226          6$:;*****END OF CODE FOR THE XOR TESTER***** ;;LOOP ON THE PRESENT TEST
3711 020226 105737 001103          2$: TSTB   $ERFLG      ;;HAS AN ERROR OCCURRED?
3712 020232 001404          BEQ     3$          ;;BR IF NO
3713 020234 105037 001103          4$: CLRB   $ERFLG      ;;ZERO THE ERROR FLAG
3714 020240 005037 001176          CLR     $TIMES      ;;CLEAR THE NUMBER OF ITERATIONS TO MAKE
3715 020244 032777 004000 160666          3$: BIT     @BIT11,@SWR ;;INHIBIT ITERATIONS?
3716 020252 001011          BNE     1$          ;;BR IF YES
3717 020254 005737 001100          TST     $PASS      ;;IF FIRST PASS OF PROGRAM
3718 020260 001406          BEQ     1$          ;;INHIBIT ITERATIONS
3719 020262 005237 001104          INC     $ICNT      ;;INCREMENT ITERATION COUNT
3720 020266 023737 001176 001104          CMP     $TIMES,$ICNT ;;CHECK THE NUMBER OF ITERATIONS MADE
3721 020274 002012          BGE     $OVER      ;;BR IF MORE ITERATION REQUIRED
3722 020276 012737 000001 001104 1$: MOV     @1,$ICNT      ;;REINITIALIZE THE ITERATION COUNTER
3723 020304 013737 020336 001176          MOV     @SMXCNT,$TIMES ;;SET NUMBER OF ITERATIONS TO DO
3724 020312 105237 001102          $SVLAD: INCB   $STNM      ;;COUNT TEST NUMBERS
3725 020316 011637 001106          MOV     (SP),$LPADR ;;SAVE SCOPE LOOP ADDRESS
3726 020322 013777 001102 160612 $OVER: MOV     $STNM,@DISPLAY ;;DISPLAY TEST NUMBER
3727 020330 013716 001106          MOV     $LPADR,(SP) ;;FUDGE RETURN ADDRESS
3728 020334 000002          RTI      ;;FIXES PS
3729 020336 000004          $MXCNT: 4          ;;MAX. NUMBER OF ITERATIONS
3730 .SBTTL ERROR HANDLER ROUTINE
3731
3732 ;;*****

```


E06

ERROR HANDLER ROUTINE

```
3733 ;*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,  
3734 ;*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL  
3735 ;*AND GO TO SERRTYP ON ERROR  
3736 ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:  
3737 ;*SW15=1 HALT ON ERROR  
3738 ;*SW13=1 INHIBIT ERROR TYPEOUTS  
3739 ;*SW10=1 BELL ON ERROR  
3740 ;*CALL  
3741 ;* ERROR N ;;ERROR=EMT AND N=ERROR ITEM NUMBER  
3742  
3743 SERROR:  
3744 020340 104407 CKSWR ;;TEST FOR CHANGE IN SOFT-SWR  
3745 020342 113737 001102 001242 MOVB STSTNM,TSTNUM  
3746 020350 105237 001103 7S: INCB SERFLG ;;SET THE ERROR FLAG  
3747 020354 001775 BEQ 7S ;;DON'T LET THE FLAG GO TO ZERO  
3748 020356 013777 001102 160556 MOV STSTNM,@DISPLAY ;;DISPLAY TEST NUMBER AND ERROR FLAG  
3749 020364 032777 002000 160546 BIT @BIT10,@SWR ;;BELL ON ERROR?  
3750 020372 001402 BEQ 1S ;;NO - SKIP  
3751 020374 104401 001202 TYPE SBELL ;;RING BELL  
3752 020400 005237 001112 1S: INC SERTTL ;;COUNT THE NUMBER OF ERRORS  
3753 020404 011637 001116 MOV (SP),SERRPC ;;GET ADDRESS OF ERROR INSTRUCTION  
3754 020410 162737 000002 001116 SUB #2,SERRPC  
3755 020416 117737 160474 001114 MOVB @SERRPC,$ITEMB ;;STRIP AND SAVE THE ERROR ITEM CODE  
3756 020424 032777 020000 160506 BIT @BIT13,@SWR ;;SKIP TYPEOUT IF SET  
3757 020432 001004 BNE 20S ;;SKIP TYPEOUTS  
3758 020434 004737 020472 JSR PC,SERRTYP ;;GO TO USER ERROR ROUTINE  
3759 020440 104401 001207 TYPE ,SCLF  
3760 020444 20S:  
3761 020444 005777 160470 2S: TST @SWR ;;HALT ON ERROR  
3762 020450 100002 BPL 3S ;;SKIP IF CONTINUE  
3763 020452 000000 HALT ;;HALT ON ERROR!  
3764 020454 104407 CKSWR ;;TEST FOR CHANGE IN SOFT-SWR  
3765 020456 3S:  
3766 020456 022737 017724 000042 CMP #SENDAD,@#42 ;;ACT-11 AUTO-ACCEPT?  
3767 020464 001001 BNE 6S ;;BRANCH IF NO  
3768 020466 000000 HALT ;;YES  
3769 020470 6S:  
3770 020470 000002 RTI ;;RETURN  
3771 .SBTTL ERROR MESSAGE TYPEOUT ROUTINE  
3772  
3773 ;******  
3774 ;*THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE WHICH  
3775 ;*ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" (SERRTB),  
3776 ;*AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.  
3777  
3778 SERRTYP:  
3779 020472 104401 001207 TYPE ,SCLF ;;"CARRIAGE RETURN" & "LINE FEED"  
3780 020476 010046 MOV RO,-(SP) ;;SAVE RO  
3781 020500 005000 CLR RO ;;PICKUP THE ITEM INDEX  
3782 020502 153700 001114 BISB @SITEMB,RO  
3783 020506 001004 BNE 1S ;;IF ITEM NUMBER IS ZERO, JUST  
3784 3784: TYPE THE PC OF THE ERROR  
3785 020510 013746 001116 MOV SERRPC,-(SP) ;;SAVE SERRPC FOR TYPEOUT  
3786 3786: ERROR ADDRESS  
3787 020514 104402 TYPOC ;;GO TYPE--OCTAL ASCII(ALL DIGITS)  
3788 020516 000445 BR 10S ;;GET OUT
```



```

3789 020520 005300          1$: DEC      RO          ;; ADJUST THE INDEX SO THAT IT WILL
3790 020522 006300          ASL      RO          ;; WORK FOR THE ERROR TABLE
3791 020524 006300          ASL      RO
3792 020526 006300          ASL      RO
3793 020530 062700 001276  ADD      #SERRTB,RO  ;; FORM TABLE POINTER
3794 020534 012037 020544  MOV      (RO)+,2$  ;; PICKUP "ERROR MESSAGE" POINTER
3795 020540 001404          BEQ      3$          ;; SKIP TYPEOUT IF NO POINTER
3796 020542 104401          TYPE     "ERROR MESSAGE"  ;; TYPE THE "ERROR MESSAGE"
3797 020544 000000          .WORD   0          ;; "ERROR MESSAGE" POINTER GOES HERE
3798 020546 104401 001207  TYPE     ,SCRLF      ;; "CARRIAGE RETURN" & "LINE FEED"
3799 020552 012037 020562  3$: MOV      (RO)+,4$  ;; PICKUP "DATA HEADER" POINTER
3800 020556 001404          BEQ      5$          ;; SKIP TYPEOUT IF 0
3801 020560 104401          TYPE     "DATA HEADER"  ;; TYPE THE "DATA HEADER"
3802 020562 000000          .WORD   0          ;; "DATA HEADER" POINTER GOES HERE
3803 020564 104401 001207  TYPE     ,SCRLF      ;; "CARRIAGE RETURN" & "LINE FEED"
3804 020570 010146          5$: MOV      R1,-(SP)  ;; SAVE R1
3805 020572 012001          MOV      (RO)+,R1  ;; PICKUP "DATA TABLE" POINTER
3806 020574 001415          BEQ      9$          ;; BR IF NO DATA TO BE TYPED
3807 020576 012000          MOV      (RO)+,RO  ;; PICKUP "DATA FORMAT" POINTER
3808 020600 105720          6$: TSTB    (RO)+      ;; "OCTAL" OR "DECIMAL"
3809 020602 001003          BNE      7$          ;; BR IF DECIMAL
3810 020604 013146          MOV      2(R1)+,-(SP)  ;; SAVE 2(R1)+ FOR TYPEOUT
3811 020606 104402          TYPOC   8$          ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
3812 020610 000402          BR       8$
3813 020612 000000          7$: MOV      2(R1)+,-(SP)  ;; SAVE 2(R1)+ FOR TYPEOUT
3814 020612 013146          MOV      TYPDS      ;; GO TYPE--DECIMAL ASCII WITH SIGN
3815 020614 104405          TST     (R1)        ;; IS THERE ANOTHER NUMBER?
3816 020616 005711          BEQ      9$          ;; BR IF NO
3817 020620 001403          TYPE     ,11$      ;; TYPE TWO(2) SPACES
3818 020622 104401 020642  BR       6$          ;; LOOP
3819 020626 000764          9$: MOV      (SP)+,R1  ;; RESTORE R1
3820 020630 012601          10$: MOV     (SP)+,RO  ;; RESTORE RO
3821 020632 012600          TYPE     ,SCRLF      ;; "CARRIAGE RETURN" & "LINE FEED"
3822 020634 104401 001207  RTS      PC          ;; RETURN
3823 020640 000207          11$: .ASCIZ  / /      ;; TWO(2) SPACES
3824 020642 020040 000          .EVEN
3825 020646 020646          .SBTTL  TYPE ROUTINE
3826
3827
3828
3829
3830
3831
3832
3833
3834
3835
3836
3837
3838
3839
3840
3841
3842
3843
3844 020646 105737 001157  STYPE:  TSTB    STPLG  ;; IS THERE A TERMINAL?

```

#ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
#THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
#NOTE1: SNUL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
#NOTE2: SFILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
#NOTE3: SFILLC CONTAINS THE CHARACTER TO FILL AFTER.

#CALL:
#1) USING A TRAP INSTRUCTION
TYPE ,MESADR ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
#OR
TYPE
MESADR
#


```

3845 020652 100002      BPL      1$      ;; BR IF YES
3846 020654 000000      HALT      ;; HALT HERE IF NO TERMINAL
3847 020656 000407      BR      3$      ;; LEAVE
3848 020660 010046      1$: MOV    RD, -(SP)  ;; SAVE RD
3849 020662 017600 000002  MOV    2(SP), RD    ;; GET ADDRESS OF ASCIZ STRING
3850 020666 112046      2$: MOVB  (RD)+, -(SP)  ;; PUSH CHARACTER TO BE TYPED ONTO STACK
3851 020670 001005      BNE     4$      ;; BR IF IT ISN'T THE TERMINATOR
3852 020672 005726      TST    (SP)+      ;; IF TERMINATOR POP IT OFF THE STACK
3853 020674 012600      60$: MOV  (SP)+, RD    ;; RESTORE RD
3854 020676 062716 000002  3$: ADD  #2, (SP)    ;; ADJUST RETURN PC
3855 020702 000002      RTI      ;; RETURN
3856 020704 122716 000011  4$: CMPB  #HT, (SP)   ;; BRANCH IF <HT>
3857 020710 001430      BEQ     8$      ;;
3858 020712 122716 000200  CMPB  #CRLF, (SP)  ;; BRANCH IF NOT <CRLF>
3859 020716 001006      BNE     5$      ;;
3860 020720 005726      TST    (SP)+      ;; POP <CR><LF> EQUIV
3861 020722 104401      TYPE    ;; TYPE A CR AND LF
3862 020724 001207      SCRLF   ;;
3863 020726 105037 021062  CLRB   $CHARCNT    ;; CLEAR CHARACTER COUNT
3864 020732 000755      BR      2$      ;; GET NEXT CHARACTER
3865 020734 004737 021016  5$: JSR   PC, $TYPEC  ;; GO TYPE THIS CHARACTER
3866 020740 123726 001156  6$: CMPB  $FILLC, (SP)+  ;; IS IT TIME FOR FILLER CHARS.?
3867 020744 001350      BNE     2$      ;; IF NO GO GET NEXT CHAR.
3868 020746 013746 001154  MOV    $NULL, -(SP)  ;; GET # OF FILLER CHARS. NEEDED
3869                                AND THE NULL CHAR.
3870 020752 105366 000001  7$: DECB  1(SP)      ;; DOES A NULL NEED TO BE TYPED?
3871 020756 002770      BLT     6$      ;; BR IF NO--GO POP THE NULL OFF OF STACK
3872 020760 004737 021016  JSR   PC, $TYPEC  ;; GO TYPE A NULL
3873 020764 105337 021062  DECB  $CHARCNT    ;; DO NOT COUNT AS A COUNT
3874 020770 000770      BR      7$      ;; LOOP
3875
3876                                ;HORIZONTAL TAB PROCESSOR
3877
3878 020772 112716 000040  8$: MOVB  #' (SP)    ;; REPLACE TAB WITH SPACE
3879 020776 004737 021016  9$: JSR   PC, $TYPEC  ;; TYPE A SPACE
3880 021002 132737 000007 021062  BITB  #7, $CHARCNT  ;; BRANCH IF NOT AT
3881 021010 001372      BNE     9$      ;; TAB STOP
3882 021012 005726      TST    (SP)+      ;; POP SPACE OFF STACK
3883 021014 000724      BR      2$      ;; GET NEXT CHARACTER
3884 021016 105777 160126  $TYPEC: TSTB  $STPS   ;; WAIT UNTIL PRINTER IS READY
3885 021022 100375      BPL    $TYPEC    ;;
3886 021024 116677 000002 160120  MOVB  2(SP), $STPB  ;; LOAD CHAR TO BE TYPED INTO DATA REG.
3887 021032 122766 000015 000002  CMPB  #CR, 2(SP)   ;; IS CHARACTER A CARRIAGE RETURN?
3888 021040 001003      BNE     1$      ;; BRANCH IF NO
3889 021042 105037 021062  CLRB   $CHARCNT    ;; YES--CLEAR CHARACTER COUNT
3890 021046 000406      BR      $TYPEC   ;; EXIT
3891 021050 122766 000012 000002  1$: CMPB  #LF, 2(SP)  ;; IS CHARACTER A LINE FEED?
3892 021056 001402      BEQ     $TYPEC   ;; BRANCH IF YES
3893 021060 105227      INCB  (PC)+      ;; COUNT THE CHARACTER
3894 021062 000000  $CHARCNT: .WORD 0  ;; CHARACTER COUNT STORAGE
3895 021064 000207  $TYPEC: RTS    PC

```

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

;; *****
;; THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT

H06

```

3901      ;#OCTAL (ASCII) NUMBER AND TYPE IT.
3902      ;#STYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
3903      ;#CALL:
3904      ;#      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
3905      ;#      TYPOS      ;;CALL FOR TYPEOUT
3906      ;#      .BYTE  N      ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
3907      ;#      .BYTE  M      ;;M=1 OR 0
3908      ;#      ;;I=TYPE LEADING ZEROS
3909      ;#      ;;O=SUPPRESS LEADING ZEROS
3910
3911      ;#STYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
3912      ;#STYPOS OR STYPOC
3913      ;#CALL:
3914      ;#      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
3915      ;#      TYPON      ;;CALL FOR TYPEOUT
3916
3917      ;#STYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
3918      ;#CALL:
3919      ;#      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
3920      ;#      TYPYC      ;;CALL FOR TYPEOUT
3921
3922 021066 017646 000000      STYPOS: MOV      3(SP),-(SP)      ;;PICKUP THE MODE
3923 021072 116637 000001 021311 MOVVB   1(SP),SOFILL      ;;LOAD ZERO FILL SWITCH
3924 021100 112637 021313 MOVVB   (SP)+,SOMODE+1      ;;NUMBER OF DIGITS TO TYPE
3925 021104 062716 000002 ADD      #2,(SP)      ;;ADJUST RETURN ADDRESS
3926 021110 000406 BR      STYPON
3927 021112 112737 000001 021311 STYPOC: MOVVB   #1,SOFILL      ;;SET THE ZERO FILL SWITCH
3928 021120 112737 000006 021313 MOVVB   #6,SOMODE+1      ;;SET FOR SIX(6) DIGITS
3929 021126 112737 000005 021310 STYPON: MOVVB   #5,SOCNT      ;;SET THE ITERATION COUNT
3930 021134 010346 MOV      R3,-(SP)      ;;SAVE R3
3931 021136 010446 MOV      R4,-(SP)      ;;SAVE R4
3932 021140 010546 MOV      R5,-(SP)      ;;SAVE R5
3933 021142 113704 021313 MOVVB   SOMODE+1,R4      ;;GET THE NUMBER OF DIGITS TO TYPE
3934 021146 005404 NEG      R4
3935 021150 062704 000006 ADD      #6,R4      ;;SUBTRACT IT FOR MAX. ALLOWED
3936 021154 110437 021312 MOVVB   R4,SOMODE      ;;SAVE IT FOR USE
3937 021160 113704 021311 MOVVB   SOFILL,R4      ;;GET THE ZERO FILL SWITCH
3938 021164 016605 000012 MOV      12(SP),R5      ;;PICKUP THE INPUT NUMBER
3939 021170 005003 CLR      R3      ;;CLEAR THE OUTPUT WORD
3940 021172 006105 1S: ROL      R5      ;;ROTATE MSB INTO "C"
3941 021174 000404 BR      3S      ;;GO DO MSB
3942 021176 006105 2S: ROL      R5      ;;FORM THIS DIGIT
3943 021200 006105 ROL      R5
3944 021202 006105 ROL      R5
3945 021204 010503 MOV      R5,R3
3946 021206 006103 3S: ROL      R3      ;;GET LSB OF THIS DIGIT
3947 021210 105337 021312 DECB   SOMODE      ;;TYPE THIS DIGIT?
3948 021214 100016 BPL      7S      ;;BR IF NO
3949 021216 042703 177770 BIC      #177770,R3      ;;GET RID OF JUNK
3950 021222 001002 BNE      4S      ;;TEST FOR 0
3951 021224 005704 TST      R4      ;;SUPPRESS THIS 0?
3952 021226 001403 BEQ      5S      ;;BR IF YES
3953 021230 005204 4S: INC      R4      ;;DON'T SUPPRESS ANYMORE 0'S
3954 021232 052703 000060 BIS      #'0,R3      ;;MAKE THIS DIGIT ASCII
3955 021236 052703 000040 5S: BIS      #' ,R3      ;;MAKE ASCII IF NOT ALREADY
3956 021242 110337 021306 MOVVB   R3,#S      ;;SAVE FOR TYPING

```


BINARY TO OCTAL (ASCII) AND TYPE

```

3957 021246 104401 021306          TYPE      BS          ;;GO TYPE THIS DIGIT
3958 021252 105337 021310 7$:  DECB      $OCNT      ;;COUNT BY 1
3959 021256 003347          BGT       2$          ;;BR IF MORE TO DO
3960 021260 002402          BLT       6$          ;;BR IF DONE
3961 021262 005204          INC       R4          ;;INSURE LAST DIGIT ISN'T A BLANK
3962 021264 000744          BR        2$          ;;GO DO THE LAST DIGIT
3963 021266 012605 6$:  MOV      (SP)+,R5      ;;RESTORE R5
3964 021270 012604          MOV      (SP)+,R4      ;;RESTORE R4
3965 021272 012603          MOV      (SP)+,R3      ;;RESTORE R3
3966 021274 016666 000002 000004  MOV      2(SP),4(SP)    ;;SET THE STACK FOR RETURNING
3967 021302 012616          MOV      (SP)+,(SP)
3968 021304 000002          RTI
3969 021306          000          ;;RETURN
3970 021307          000          ;;STORAGE FOR ASCII DIGIT
3971 021310          000          ;;TERMINATOR FOR TYPE ROUTINE
3972 021311          000          ;;OCTAL DIGIT COUNTER
3973 021312 000000  $OFILL: .BYTE 0        ;;ZERO FILL SWITCH
          $OMODE: .WORD 0      ;;NUMBER OF DIGITS TO TYPE
          .SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

*****
;THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
;SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
;NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
;BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
;REPLACED WITH SPACES.
;CALL:
;#   MOV      NUM,-(SP)      ;;PUT THE BINARY NUMBER ON THE STACK
;#   TYPDS
;#
;STYPDS:
MOV      R0,-(SP)          ;;PUSH R0 ON STACK
MOV      R1,-(SP)          ;;PUSH R1 ON STACK
MOV      R2,-(SP)          ;;PUSH R2 ON STACK
MOV      R3,-(SP)          ;;PUSH R3 ON STACK
MOV      R5,-(SP)          ;;PUSH R5 ON STACK
MOV      #20200,-(SP)      ;;SET BLANK SWITCH AND SIGN
MOV      20(SP),R5        ;;GET THE INPUT NUMBER
BPL      1$                ;;BR IF INPUT IS POS.
NEG      R5                ;;MAKE THE BINARY NUMBER POS.
MOVB    #'-,1(SP)         ;;MAKE THE ASCII NUMBER NEG.
1$:  CLR      R0            ;;ZERO THE CONSTANTS INDEX
MOV      #50BLK,R3        ;;SETUP THE OUTPUT POINTER
MOVB    #' ,(R3)+         ;;SET THE FIRST CHARACTER TO A BLANK
2$:  CLR      R2            ;;CLEAR THE BCD NUMBER
MOV      $DTBL(R0),R1     ;;GET THE CONSTANT
3$:  SUB      R1,R5        ;;FORM THIS BCD DIGIT
BLT     4$                ;;BR IF DONE
INC     R2                ;;INCREASE THE BCD DIGIT BY 1
BR      3$
4$:  ADD      R1,R5        ;;ADD BACK THE CONSTANT
TST     R2                ;;CHECK IF BCD DIGIT=0
BNE     5$                ;;FALL THROUGH IF 0
TSTB   (SP)              ;;STILL DOING LEADING 0'S?
BMI     7$                ;;BR IF YES
5$:  ASLB    (SP)          ;;MSD?
BCC     6$                ;;BR IF NO

```


JOB

MD-11-DZRJF-A, RPO4/5/6 DUAL CONTRLR LOGIC TEST - PART 2
 DZRJFA.CMB 02-NOV-76 19:11

MACY11 27(1006) 02-NOV-76 19:12 PAGE 74

CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

```

4013 021416 116663 000001 177777      MOVB    1(SP),-1(R3)      ;;YES--SET THE SIGN
4014 021424 052702 000060          6S:    BIS      #'0,R2      ;;MAKE THE BCD DIGIT ASCII
4015 021430 052702 000040          7S:    BIS      #' ,R2      ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
4016 021434 110223          MOVB    R2,(R3)+        ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
4017 021436 005720          TST     (R0)+          ;;JUST INCREMENTING
4018 021440 020027 000010          CMP     R0,#10        ;;CHECK THE TABLE INDEX
4019 021444 002746          BLT     2S            ;;GO DO THE NEXT DIGIT
4020 021446 003002          BGT     8S            ;;GO TO EXIT
4021 021450 010502          MOV     R5,R2         ;;GET THE LSD
4022 021452 000764          BR      6S            ;;GO CHANGE TO ASCII
4023 021454 105726          8S:    TSTB    (SP)+      ;;WAS THE LSD THE FIRST NON-ZERO?
4024 021456 100003          BPL     9S            ;;BR IF NO
4025 021460 116663 177777 177776      MOVB    -1(SP),-2(R3)   ;;YES--SET THE SIGN FOR TYPING
4026 021466 105013          9S:    CLRB    (R3)      ;;SET THE TERMINATOR
4027 021470 012605          MOV     (SP)+,R5      ;;POP STACK INTO R5
4028 021472 012603          MOV     (SP)+,R3      ;;POP STACK INTO R3
4029 021474 012602          MOV     (SP)+,R2      ;;POP STACK INTO R2
4030 021476 012601          MOV     (SP)+,R1      ;;POP STACK INTO R1
4031 021500 012600          MOV     (SP)+,R0      ;;POP STACK INTO R0
4032 021502 104401 021530          TYPE    $DBLK         ;;NOW TYPE THE NUMBER
4033 021506 016666 000002 000004      MOV     2(SP),4(SP)    ;;ADJUST THE STACK
4034 021514 012616          MOV     (SP)+,(SP)
4035 021516 000002          RTI
4036 021520 023420          SOTBL: 10000.         ;;RETURN TO USER
4037 021522 001750          1000.
4038 021524 000144          100.
4039 021526 000012          10.
4040 021530 000004          SDBLK: .BLKW 4
4041          .SBTTL TTY INPUT ROUTINE
4042
4043          ;;*****
4044          .ENABL LSB
4045 021540 000000      $TKCNT: .WORD 0        ;;NUMBER OF ITEMS IN QUEUE
4046 021542 000000      $TKQIN: .WORD 0       ;;INPUT POINTER
4047 021544 000000      $TKQOUT: .WORD 0      ;;OUTPUT POINTER
4048 021546 000001      $TKQSRT: .BLKB 1     ;;TTY KEYBOARD QUEUE
4049          021547
4050          021550
4051          .EVEN
4052          ;;*TK INITIALIZE ROUTINE
4053          ;;*THIS ROUTINE WILL INITIALIZE THE TTY KEYBOARD INPUT QUEUE
4054          ;;*SETUP THE INTERRUPT VECTOR AND TURN ON THE KEYBOARD INTERRUPT
4055
4056          ;;*CALL:
4057          ;;*
4058          JSR    PC,$TKINT
4059          RETURN
4060 021550 005037 021540      $TKINT: CLR     $TKCNT   ;;CLEAR COUNT OF ITEMS IN QUEUE
4061 021554 012737 021546 021542      MOV     $TKQSRT,$TKQIN ;;MOVE THE STARTING ADDRESS OF THE
4062 021562 013737 021542 021544      MOV     $TKQIN,$TKQOUT ;;QUEUE INTO THE INPUT & OUTPUT POINTERS.
4063 021570 012737 021620 000060      MOV     $TKSRV,$TKVEC ;;INITIALIZE THE KEYBOARD VECTOR
4064 021576 012737 000200 000062      MOV     #200,$TKVEC+2 ;;"BR" LEVEL 4
4065 021604 005777 157336          TST     $TKCB         ;;CLEAR DONE FLAG
4066 021610 012777 000100 157326      MOV     #100,$TKS     ;;ENABLE TTY KEYBOARD INTERRUPT
4067 021616 000207          RTS     PC            ;;RETURN TO CALLER
4068

```



```

4069      ;*TK SERVICE ROUTINE
4070      ;*THIS ROUTINE WILL SERVICE THE TTY KEYBOARD INTERRUPT
4071      ;*BY READING THE CHARACTER FROM THE INPUT BUFFER AND PUTTING
4072      ;*IT IN THE QUEUE.
4073
4074      021620 117746 157322 $TKSRV: MOVB  @STKB, -(SP)      ;: PICKUP THE CHARACTER
4075      021624 042716 177600      BIC  #1C177, (SP)      ;: STRIP THE JUNK
4076      021630 021627 000007      15:  CMP  (SP), #7      ;: IS IT A CONTROL G?
4077      021634 001004      BNE  2$      ;: BRANCH IF NO
4078      021636 022737 000176 001140      CMP  #SWREG, SWR      ;: IS SOFT-SWR SELECTED?
4079      021644 001500      BEQ  6$      ;: GO TO SWR CHANGE
4080
4081      021646      2$:      CMP  #1, STKCNT      ;: IS THE QUEUE FULL?
4082      021646 022737 000001 021540      BNE  3$      ;: BRANCH IF NO
4083      021654 001004      TYPE  $BELL      ;: RING THE TTY BELL
4084      021656 104401 001202      TST  (SP)+      ;: CLEAN CHARACTER OFF OF STACK
4085      021662 005726      BR   5$      ;: EXIT
4086      021664 000451      3$:  CMP  (SP), #23      ;: IS IT A CONTROL-S?
4087      021666 021627 000023      BNE  32$      ;: BRANCH IF NO
4088      021672 001021      CLR  @STKS      ;: DISABLE TTY KEYBOARD INTERRUPTS
4089      021674 005077 157244      TST  (SP)+      ;: CLEAN CHAR OFF STACK
4090      021700 005726      31$: TSTB @STKS      ;: WAIT FOR A CHAR
4091      021702 105777 157236      BPL  31$      ;: LOOP UNTIL ITS THERE
4092      021706 100375      MOVB @STKB, -(SP)      ;: GET THE CHARACTER
4093      021710 117746 157232      BIC  #1C177, (SP)      ;: MAKE IT 7-BIT ASCII
4094      021714 042716 177600      CMP  (SP)+, #21      ;: IS IT A CONTROL-Q?
4095      021720 022627 000021      BNE  31$      ;: BRANCH IF NO
4096      021724 001366      MOV  #100, @STKS      ;: REENABLE TTY KEYBOARD INTERRUPTS
4097      021726 012777 000100 157210      RTI      ;: RETURN
4098      021734 000002      32$: INC  STKCNT      ;: COUNT THIS CHARACTER
4099      021736 005237 021540      CMP  (SP), #140      ;: IS IT UPPER CASE?
4100      021742 021627 000140      BLT  4$      ;: BRANCH IF YES
4101      021746 002405      CMP  (SP), #175      ;: IS IT A SPECIAL CHAR?
4102      021750 021627 000175      BGT  4$      ;: BRANCH IF YES
4103      021754 003002      BIC  #40, (SP)      ;: MAKE IT UPPER CASE
4104      021756 042716 000040      4$: MOVB (SP)+, @STKQIN      ;: AND PUT IT IN QUEUE
4105      021762 112677 177554      INC  STKQIN      ;: UPDATE THE POINTER
4106      021766 005237 021542      CMP  STKQIN, #STKGEND      ;: GO OFF THE END?
4107      021772 023727 021542 021547      BNE  5$      ;: BRANCH IF NO
4108      022000 001003      MOV  #STKQSRT, STKQIN      ;: RESET THE POINTER
4109      022002 012737 021546 021542      5$: RTI      ;: RETURN
4110      022010 000002
4111
4112      ;: *****
4113      ;: *SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
4114      ;: *ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
4115      ;: *SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP
4116      ;: *CALL WHEN OPERATING IN TTY INTERRUPT MODE.
4117      022012 022737 000176 001140 $CKSWR: CMP  #SWREG, SWR      ;: IS THE SOFT-SWR SELECTED
4118      022020 001104      BNE  15$      ;: EXIT IF NOT
4119      022022 105777 157116      TSTB @STKS      ;: IS A CHAR WAITING?
4120      022026 100101      BPL  15$      ;: IF NOT, EXIT
4121      022030 117746 157112      MOVB @STKB, -(SP)      ;: YES
4122      022034 042716 177600      BIC  #1C177, (SP)      ;: MAKE IT 7-BIT ASCII
4123      022040 021627 000007      CMP  (SP), #7      ;: IS IT A CONTROL-G?
4124      022044 001300      BNE  2$      ;: IF NOT, PUT IT IN THE TTY QUEUE

```



```

4125                                     ;;AND EXIT
4126
4127                                     ;:*****
4128                                     ;:#CONTROL IS PASSED TO THIS POINT FROM EITHER THE TTY INTERRUPT SERVICE
4129                                     ;:#ROUTINE OR FROM THE SOFTWARE SWITCH REGISTER TRAP CALL, AS A RESULT OF A
4130                                     ;:#CONTROL-G BEING TYPED, AND THE SOFTWARE SWITCH REGISTER BEING SELECTED.
4131 022046 123727 001134 000001 6$:  CMPB  $AUTOB,#1      ;:ARE WE RUNNING IN AUTO-MODE?
4132 022054 001674                BEQ    2$          ;:BRANCH IF YES
4133 022056 005726                TST   (SP)+       ;:CLEAR CONTROL-G OFF STACK
4134 022060 004737 021550        JSR   PC,$TKINT   ;:FLUSH THE TTY INPUT QUEUE
4135 022064 005077 157054        CLR   %STKS      ;:DISABLE TTY KEYBOARD INTERRUPTS
4136 022070 112737 000001 001135  MOVB  #1,$INTAG   ;:SET INTERRUPT MODE INDICATOR
4137
4138 022076 104401 022654                TYPE  ,%CNTLG    ;:ECHO THE CONTROL-G (↑G)
4139 022102 104401 022661  SGTSWR: TYPE  ,%MSWR    ;:TYPE CURRENT CONTENTS
4140 022106 013746 000176        MOV   $WREG,-(SP) ;:SAVE SWREG FOR TYPEOUT
4141 022112 104402                TYPE  ,%MNEW     ;:GO TYPE--OCTAL ASCII(ALL DIGITS)
4142 022114 104401 022672                TYPE  ,%MNEW     ;:PROMPT FOR NEW SWR
4143 022120 005046                CLR   -(SP)      ;:CLEAR COUNTER
4144 022122 005046                CLR   -(SP)      ;:THE NEW SWR
4145 022124 105777 157014        7$:  TSTB %STKS   ;:CHAR THERE?
4146 022130 100375                BPL   7$         ;:IF NOT TRY AGAIN
4147
4148 022132 117746 157010        MOVB  %STKB,-(SP) ;:PICK UP CHAR
4149 022136 042716 177600        BIC   #↑C177,(SP) ;:MAKE IT 7-BIT ASCII
4150
4151
4152
4153 022142 021627 000025        9$:  CMP   (SP),#25 ;:IS IT A CONTROL-U?
4154 022146 001005                BNE   10$        ;:BRANCH IF NOT
4155 022150 104401 022647                TYPE  ,%CNTLU    ;:YES, ECHO CONTROL-U (↑U)
4156 022154 062706 000006        20$: ADD   #6,SP   ;:IGNORE PREVIOUS INPUT
4157 022160 000757                BR    19$        ;:LET'S TRY IT AGAIN
4158
4159
4160 022162 021627 000015        10$: CMP   (SP),#15 ;:IS IT A <CR>?
4161 022166 001022                BNE   16$        ;:BRANCH IF NO
4162 022170 005766 000004                TST   4(SP)      ;:YES, IS IT THE FIRST CHAR?
4163 022174 001403                BEQ   11$        ;:BRANCH IF YES
4164 022176 016677 000002 156734  MOV   2(SP),%SWR ;:SAVE NEW SWR
4165 022204 062706 000006        11$: ADD   #6,SP   ;:CLEAR UP STACK
4166 022210 104401 001207        14$: TYPE  ,%CRLF  ;:ECHO <CR> AND <LF>
4167 022214 123727 001135 000001  CMPB  $INTAG,#1 ;:RE-ENABLE TTY KBD INTERRUPTS?
4168 022222 001003                BNE   15$        ;:BRANCH IF NOT
4169 022224 012777 000100 156712  MOV   #100,%STKS ;:RE-ENABLE TTY KBD INTERRUPTS
4170 022232 000002                RTI                    ;:RETURN
4171 022234 004737 021016        15$: JSR   PC,$TYPEC  ;:ECHO CHAR
4172 022240 021627 000060        16$: CMP   (SP),#60 ;:CHAR < D?
4173 022244 002420                BLT   18$        ;:BRANCH IF YES
4174 022246 021627 000067                CMP   (SP),#67   ;:CHAR > 7?
4175 022252 003015                BGT   18$        ;:BRANCH IF YES
4176 022254 042726 000060        BIC   #60,(SP)+ ;:STRIP-OFF ASCII
4177 022260 005766 000002                TST   2(SP)      ;:IS THIS THE FIRST CHAR
4178 022264 001403                BEQ   17$        ;:BRANCH IF YES
4179 022266 006316                ASL   (SP)       ;:NO, SHIFT PRESENT
4180 022270 006316                ASL   (SP)       ;:CHAR OVER TO MAKE

```



```

4181 022272 006316          ASL      (SP)          ;; ROOM FOR NEW ONE.
4182 022274 005266 000002 17$: INC      2(SP)          ;; KEEP COUNT OF CHAR
4183 022300 056616 177776   BIS      -2(SP), (SP)  ;; SET IN NEW CHAR
4184 022304 000707          BR       7$           ;; GET THE NEXT ONE
4185 022306 104401 001206   18$: TYPE  $QUES      ;; TYPE ?<CR><LF>
4186 022312 000720          BR       20$          ;; SIMULATE CONTROL-U
4187 .DSABL  LSB
4188
4189
4190
4191
4192
4193
4194
4195
4196
4197
4198 022314 011646          SRDCHR: MOV      (SP), -(SP)  ;; PUSH DOWN THE PC AND
4199 022316 016666 000004 000002 MOV      4(SP), 2(SP)  ;; THE PS
4200 022324 005066 000004          CLR      4(SP)        ;; GET READY FOR A CHARACTER
4201 022330 005046          CLR      -(SP)        ;; PUT NEW PS ON STACK
4202 022332 012746 022340          MOV      #64$, -(SP)  ;; PUT NEW PC ON STACK
4203 022336 000002          RTI                    ;; POP NEW PC AND PS
4204 022340
4205 022340 005737 021540   64$: TST      $TKCNT      ;; WAIT ON A CHARACTER
4206 022344 001775          BEQ      1$           1$:
4207 022346 005337 021540          DEC      $TKCNT      ;; DECREMENT THE COUNTER
4208 022352 117766 177166 000004 MOVB     2($TKQOUT, 4(SP) ;; GET ONE CHARACTER
4209 022360 005237 021544          INC      $TKQOUT      ;; UPDATE THE POINTER
4210 022364 023727 021544 021547 CMP      $TKQOUT, # $TKQEND ;; DID IT GO OFF OF THE END?
4211 022372 001003          BNE      2$           2$:
4212 022374 012737 021546 021544 MOV      # $TKQSRT, $TKQOUT ;; RESET THE POINTER
4213 022402 000002          RTI                    ;; RETURN
4214
4215
4216
4217
4218
4219
4220
4221 022404 010346          SRDLIN: MOV      R3, -(SP)  ;; SAVE R3
4222 022406 005046          CLR      -(SP)        ;; CLEAR THE RUBOUT KEY
4223 022410 012703 022640   1$: MOV      # $TTYIN, R3  ;; GET ADDRESS
4224 022414 022703 022647   2$: CMP      # $TTYIN+7, R3 ;; BUFFER FULL?
4225 022420 101456          BLOS     4$           4$:
4226 022422 104410          RDCHR    ;; GO READ ONE CHARACTER FROM THE TTY
4227 022424 112613          MOVB     (SP)+, (R3)  ;; GET CHARACTER
4228 022426 122713 000177   10$: CMPB     #177, (R3)  ;; IS IT A RUBOUT
4229 022432 001022          BNE      5$           5$:
4230 022434 005716          TST      (SP)        ;; IS THIS THE FIRST RUBOUT?
4231 022436 001007          BNE      6$           6$:
4232 022440 112737 000134 022636 MOVB     #' \, 9$      ;; TYPE A BACK SLASH
4233 022446 104401 022636          TYPE     9$
4234 022452 012716 177777          MOV      #-1, (SP)  ;; SET THE RUBOUT KEY
4235 022456 005303          DEC      R3          ;; BACKUP BY ONE
4236 022460 020327 022640   6$: CMP      R3, # $TTYIN ;; STACK EMPTY?
    
```



```

4237 022464 103434          BLO      4$          ;;BR IF YES
4238 022466 111337 022636  MOVB    (R3),9$    ;;SETUP TO TYPEOUT THE DELETED CHAR.
4239 022472 104401 022636  TYPE    9$          ;;GO TYPE
4240 022476 000746          BR      2$          ;;GO READ ANOTHER CHAR.
4241 022500 005716          5$:     TST    (SP)      ;;RUBOUT KEY SET?
4242 022502 001406          BEQ    7$          ;;BR IF NO
4243 022504 112737 000134 022636  MOVB    #' \,9$    ;;TYPE A BACK SLASH
4244 022512 104401 022636  TYPE    9$          ;;
4245 022516 005016          CLR    (SP)        ;;CLEAR THE RUBOUT KEY
4246 022520 122713 000025  7$:     CMPB   #25,(R3)  ;;IS CHARACTER A CTRL U?
4247 022524 001003          BNE    8$          ;;BR IF NO
4248 022526 104401 022647  TYPE    SCNTLU     ;;TYPE A CONTROL "U"
4249 022532 000726          BR      1$          ;;GO START OVER
4250 022534 122713 000022  8$:     CMPB   #22,(R3)  ;;IS CHARACTER A "r"?
4251 022540 001011          BNE    3$          ;;BRANCH IF NO
4252 022542 105013          CLRB   (R3)        ;;CLEAR THE CHARACTER
4253 022544 104401 001207  TYPE    ,SCRLF     ;;TYPE A "CR" & "LF"
4254 022550 104401 022640  TYPE    ,STTYIN    ;;TYPE THE INPUT STRING
4255 022554 000717          BR      2$          ;;GO PICKUP ANOTHER CHARACTER
4256 022556 104401 001206  4$:     TYPE    $QUES   ;;TYPE A '?'
4257 022562 000712          BR      1$          ;;CLEAR THE BUFFER AND LOOP
4258 022564 111337 022636  3$:     MOVB   (R3),9$    ;;ECHO THE CHARACTER
4259 022570 104401 022636  TYPE    9$          ;;
4260 022574 122723 000015  CMPB   #15,(R3)+  ;;CHECK FOR RETURN
4261 022600 001305          BNE    2$          ;;LOOP IF NOT RETURN
4262 022602 105063 177777  CLRB   -1(R3)     ;;CLEAR RETURN (THE 15)
4263 022606 104401 001210  TYPE    $LF        ;;TYPE A LINE FEED
4264 022612 005726          TST    (SP)+      ;;CLEAN RUBOUT KEY FROM THE STACK
4265 022614 012603          MOV    (SP)+,R3   ;;RESTORE R3
4266 022616 011646          MOV    (SP)-,(SP) ;;ADJUST THE STACK AND PUT ADDRESS OF THE
4267 022620 016666 000004 000002  MOV    4(SP),2(SP) ;;FIRST ASCII CHARACTER ON IT
4268 022626 012766 022640 000004  MOV    #STTYIN,4(SP)
4269 022634 000002          RTI                    ;;RETURN
4270 022636 000          9$:     .BYTE   0          ;;STORAGE FOR ASCII CHAR. TO TYPE
4271 022637 000          .BYTE   0          ;;TERMINATOR
4272 022640 000007          STTYIN: .BLKB   7          ;;RESERVE 7 BYTES FOR TTY INPUT
4273 022647 136 006525 000012 SCNTLU: .ASCIZ  /?U/<15><12> ;;CONTROL "U"
4274 022654 043536 005015 000 SCNTLG: .ASCIZ  /?G/<15><12> ;;CONTROL "G"
4275 022661 015 051412 051127 SMSWR:  .ASCIZ  <15><12>/SWR = /
4276 022666 036440 000040          SMNEW:  .ASCIZ  / NEW = /
4277 022672 020040 042516 020127
4278 022700 020075 000
4279 022704
4280          .EVEN
4281          .SBTTL READ AN OCTAL NUMBER FROM THE TTY
4282          ;;*****
4283          ;;THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
4284          ;;CHANGE IT TO BINARY.
4285          ;;THE INPUT CHARACTERS WILL BE CHECKED TO INSURED THEY ARE LEGAL
4286          ;;OCTAL DIGITS. IF AN ILLEGAL CHARACTER IS READ A "?" WILL BE TYPED
4287          ;;FOLLOWED BY A CARRIAGE RETURN-LINE FEED. THE COMPLETE NUMBER MUST
4288          ;;THEN BE RETYPED. THE INPUT IS TERMINATED BY TYPING A CARRIAGE RETURN.
4289          ;;CALL:
4290          ;;      RDOCT          ;;READ AN OCTAL NUMBER
4291          ;;      RETURN HERE  ;;LOW ORDER BITS ARE ON TOP OF THE STACK
4292          ;;                    ;;HIGH ORDER BITS ARE IN SHIOCT

```


READ AN OCTAL NUMBER FROM THE TTY

```

4293
4294 022704 011546
4295 022706 016666 000004 000002
4296 022714 010046
4297 022716 010146
4298 022720 010246
4299 022722 104411
4300 022724 012600
4301 022726 010037 023032
4302 022732 005001
4303 022734 005002
4304 022736 112046
4305 022740 001420
4306 022742 122716 000060
4307 022746 003026
4308 022750 122716 000067
4309 022754 002423
4310 022756 006301
4311 022760 006102
4312 022762 006301
4313 022764 006102
4314 022766 006301
4315 022770 006102
4316 022772 042716 177770
4317 022776 062601
4318 023000 000756
4319 023002 005726
4320 023004 010166 000012
4321 023010 010237 023042
4322 023014 012602
4323 023016 012601
4324 023020 012600
4325 023022 000002
4326 023024 005726
4327 023026 105010
4328 023030 104401
4329 023032 000000
4330 023034 104401 001206
4331 023040 000730
4332 023042 000000
4333
4334
4335
4336
4337
4338
4339
4340
4341
4342
4343
4344
4345
4346
4347
4348

SRDOCT: MOV (SP),-(SP) ;; PROVIDE SPACE FOR THE
MOV 4(SP),2(SP) ;; INPUT NUMBER
MOV RO,-(SP) ;; PUSH RO ON STACK
MOV R1,-(SP) ;; PUSH R1 ON STACK
MOV R2,-(SP) ;; PUSH R2 ON STACK
1$: RDLIN ;; READ AN ASCII LINE
MOV (SP)+,RO ;; GET ADDRESS OF 1ST CHARACTER
MOV RO,5$ ;; AND SAVE IT
CLR R1 ;; CLEAR DATA WORD
CLR R2
2$: MOVB (RO)+,-(SP) ;; PICKUP THIS CHARACTER
BEQ 3$ ;; IF ZERO GET OUT
CMPB #'0,(SP) ;; MAKE SURE THIS CHARACTER
BGT 4$ ;; IS AN OCTAL DIGIT
CMPB #'7,(SP)
BLT 4$
ASL R1 ;; #2
ROL R2
ASL R1 ;; #4
ROL R2
ASL R1 ;; #8
ROL R2
BIC #'C7,(SP) ;; STRIP THE ASCII JUNK
ADD (SP)+,R1 ;; ADD IN THIS DIGIT
BR 2$ ;; LOOP
3$: TST (SP)+ ;; CLEAN TERMINATOR FROM STACK
MOV R1,12(SP) ;; SAVE THE RESULT
MOV R2,$HI OCT
MOV (SP)+,R2 ;; POP STACK INTO R2
MOV (SP)+,R1 ;; POP STACK INTO R1
MOV (SP)+,RO ;; POP STACK INTO RO
RTI ;; RETURN
4$: TST (SP)+ ;; CLEAN PARTIAL FROM STACK
CLRB (RO) ;; SET A TERMINATOR
TYPE ;; TYPE UP THRU THE BAD CHAR.
5$: .WORD 0
TYPE 0 SQUES ;; "?" "CR" & "LF"
BR 1$ ;; TRY AGAIN
$HI OCT: .WORD 0 ;; HIGH ORDER BITS GO HERE
.SBTL SAVE AND RESTORE RO-R5 ROUTINES

*****
;SAVE RO-R5
;CALL:
; SAVREG
;UPON RETURN FROM SSAVEG THE STACK WILL LOOK LIKE:
;
;TOP---(+16)
; +2---(+18)
; +4---R5
; +6---R4
; +8---R3
;+10---R2
;+12---R1
;+14---RO

```


SAVE AND RESTORE RO-R5 ROUTINES

4349
4350 023044
4351 023044 010046
4352 023046 010146
4353 023050 010246
4354 023052 010346
4355 023054 010446
4356 023056 010546
4357 023060 016646 000022
4358 023064 016646 000022
4359 023070 016646 000022
4360 023074 016646 000022
4361 023100 000002
4362
4363
4364
4365
4366 023102
4367 023102 012666 000022
4368 023106 012666 000022
4369 023112 012666 000022
4370 023116 012666 000022
4371 023122 012605
4372 023124 012604
4373 023126 012603
4374 023130 012602
4375 023132 012601
4376 023134 012600
4377 023136 000002
4378
4379
4380
4381
4382
4383
4384
4385
4386 023140 010046
4387 023142 016600 000002
4388 023146 005740
4389 023150 111000
4390 023152 006300
4391 023154 016000 023174
4392 023160 000200
4393
4394
4395
4396
4397 023162 011646
4398 023164 016666 000004 000002
4399 023172 000002
4400
4401
4402
4403
4404

```

SSAVREG:
MOV RO,-(SP)      ;; PUSH RO ON STACK
MOV R1,-(SP)      ;; PUSH R1 ON STACK
MOV R2,-(SP)      ;; PUSH R2 ON STACK
MOV R3,-(SP)      ;; PUSH R3 ON STACK
MOV R4,-(SP)      ;; PUSH R4 ON STACK
MOV R5,-(SP)      ;; PUSH R5 ON STACK
MOV 22(SP),-(SP)  ;; SAVE PS OF MAIN FLOW
MOV 22(SP),-(SP)  ;; SAVE PC OF MAIN FLOW
MOV 22(SP),-(SP)  ;; SAVE PS OF CALL
MOV 22(SP),-(SP)  ;; SAVE PC OF CALL
RTI

; *RESTORE RO-R5
; *CALL:
; * RESREG
$RESREG:
MOV (SP)+,22(SP)  ;; RESTORE PC OF CALL
MOV (SP)+,22(SP)  ;; RESTORE PS OF CALL
MOV (SP)+,22(SP)  ;; RESTORE PC OF MAIN FLOW
MOV (SP)+,22(SP)  ;; RESTORE PS OF MAIN FLOW
MOV (SP)+,R5      ;; POP STACK INTO R5
MOV (SP)+,R4      ;; POP STACK INTO R4
MOV (SP)+,R3      ;; POP STACK INTO R3
MOV (SP)+,R2      ;; POP STACK INTO R2
MOV (SP)+,R1      ;; POP STACK INTO R1
MOV (SP)+,RO      ;; POP STACK INTO RO
RTI

.SBTTL TRAP DECODER

; *****
; *THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
; *AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
; *OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
; *GO TO THAT ROUTINE.
STRAP: MOV RO,-(SP)      ;; SAVE RO
MOV 2(SP),RO          ;; GET TRAP ADDRESS
TST -(RO)            ;; BACKUP BY 2
MOV B(RO),RO         ;; GET RIGHT BYTE OF TRAP
ASL RO               ;; POSITION FOR INDEXING
MOV STRPAD(RO),RO    ;; INDEX TO TABLE
RTS RO               ;; GO TO ROUTINE

; ; THIS IS USE TO HANDLE THE "GETPRI" MACRO
STRAP2: MOV (SP),-(SP)  ;; MOVE THE PC DOWN
MOV 4(SP),2(SP)       ;; MOVE THE PSM DOWN
RTI                   ;; RESTORE THE PSM

.SBTTL TRAP TABLE

; *THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
; *BY THE "TRAP" INSTRUCTION.

```


E07

MD-11-DZRJF-A, RPO4/5/6 DUAL CONTRLR LOGIC TEST - PART 2
DZRJFA.CMB 02-NOV-76 19:11 TELETYPE MESSAGES

MACY11 27(1006) 02-NOV-76 19:12 PAGE 82

4461	023470	042524	020115	052515
4462	023476	052123	044040	053101
4463	023504	020105	046047	020047
4464	023512	051117	023440	023520
4465	023520	041440	047514	045503
4466	023526	005015	000012	
4467	023532	042412	052116	051105
4468	023540	052040	051505	020124
4469	023546	035043	000040	
4470	023552	047111	040526	044514
4471	023560	020104	042524	052123
4472	023566	047040	046525	042502
4473	023574	006522	000012	
4474	023600	005015	052012	042510
4475	023606	050040	042522	042523
4476	023614	052116	040440	042104
4477	023622	042522	051523	047440
4478	023630	020106	044124	020105
4479	023636	044122	030461	024040
4480	023644	050122	051503	024461
4481	023652	044440	035123	000040
4482	023660	042412	052116	051105
4483	023666	047040	053505	051040
4484	023674	030510	020061	042101
4485	023702	051104	051505	035123
4486	023710	000040		
4487	023712	005015	050012	042522
4488	023720	051523	023440	052123
4489	023726	047101	041104	023531
4490	023734	047440	020116	051104
4491	023742	053111	105	
4492	023745	015	050012	047522
4493	023752	051107	046501	053440
4494	023760	046111	020114	047514
4495	023766	050117	053440	044501
4496	023774	044524	043516	043040
4497	024002	051117	023440	047515
4498	024010	023514	052040	020117
4499	024016	042523	020124	051106
4500	024024	046517	050040	051117
4501	024032	020124	000	
4502	024035	015	005012	042522
4503	024042	052524	047122	023440
4504	024050	047503	052116	047522
4505	024056	046114	051105	051440
4506	024064	046105	041505	023524
4507	024072	051440	044527	041524
4508	024100	020110	047117	042040
4509	024106	044522	042526	052040
4510	024114	020117	040447	041057
4511	024122	000047		
4512	024124	005015	052012	051125
4513	024132	020116	041447	047117
4514	024140	051124	046117	042514
4515	024146	020122	042523	042514
4516	024154	052103	020047	053523

TESTNO: .ASCIZ <LF>/ENTER TEST #: /

BADNO: .ASCIZ /INVALID TEST NUMBER/<CR><LF>

ADDRIS: .ASCIZ <CR><LF><LF>/THE PRESENT ADDRESS OF THE RH11 (RPCS1) IS: /

NTRH11: .ASCIZ <LF>/ENTER NEW RH11 ADDRESS: /

STANDBY: .ASCII <CR><LF><LF>/PRESS 'STANDBY' ON DRIVE/

.ASCIZ <CR><LF>/PROGRAM WILL LOOP WAITING FOR 'MOL' TO SET FROM PORT /

SWTCHN: .ASCIZ <CR><LF><LF>/RETURN 'CONTROLLER SELECT' SWITCH ON DRIVE TO 'A/B'&

SWTCHA: .ASCIZ <CR><LF><LF>/TURN 'CONTROLLER SELECT' SWITCH ON DRIVE TO 'A'//

4517	024162	052111	044103	047440
4518	024170	020116	051104	053111
4519	024176	020105	047524	023440
4520	024204	023501	000	
4521	024207	015	005012	052524
4522	024214	047122	023440	047503
4523	024222	052116	047522	046114
4524	024230	051105	051440	046105
4525	024236	041505	023524	051440
4526	024244	044527	041524	020110
4527	024250	047117	042040	044522
4528	024256	042526	052040	020117
4529	024266	041047	000047	
4530	024272	005015	044124	047105
4531	024300	050040	042522	051523
4532	024306	023440	047503	052116
4533	024314	020047	047117	052040
4534	024322	042510	050040	047522
4535	024330	042503	051523	051117
4536	024336	005015	000	
4537	024341	015	005012	052123
4538	024346	050117	052040	042510
4539	024354	042040	044522	042526
4540	024362	000		
4541	024363	015	005012	052123
4542	024370	051101	020124	044124
4543	024376	020105	051104	053111
4544	024404	020105	020055	044124
4545	024412	020105	051120	043517
4546	024420	040522	020115	044527
4547	024426	046114	053440	044501
4548	024434	020124	047506	020122
4549	024442	046447	046117	020047
4550	024450	047524	051440	052105
4551	024456	000		

SWTCHB: .ASCIZ <CR><LF><LF>/TURN 'CONTROLLER SELECT' SWITCH ON DRIVE TO 'B'/'

CONTUE: .ASCIZ <CR><LF>/THEN PRESS 'CONT' ON THE PROCESSOR/<CR><LF>

CYCLED: .ASCIZ <CR><LF><LF>/STOP THE DRIVE/'

CYCLEU: .ASCIZ <CR><LF><LF>/START THE DRIVE - THE PROGRAM WILL WAIT FOR 'MOL' TO SET/'

;;*****

.SBTTL TEST ERROR MESSAGES

;;*****

EM1: .ASCIZ /DRIVE IS NON-EXISTENT ('NED' BIT SET)/

EM2: .ASCIZ /WRONG DRIVE TYPE/'

EM3: .ASCIZ @CONTROLLER SELECT SWITCH ON DRIVE NOT IN 'A/B'@

4573	024562	046105	041505	020124		
4574	024570	053523	052111	044103		
4575	024576	047440	020116	051104		
4576	024604	053111	020105	047516		
4577	024612	020124	047111	023440		
4578	024620	027501	023502	000		
4579						
4580	024625	104	044522	042526	EM4:	.ASCIZ /DRIVE NOT ON LINE/
4581	024632	047040	052117	047440		
4582	024640	020116	044514	042516		
4583	024646	000				
4584						
4585	024647	123	051105	040511	EM5:	.ASCIZ /SERIAL NUMBER READ THROUGH EACH PORT NOT THE SAME/
4586	024654	020114	052516	041115		
4587	024662	051105	051040	040505		
4588	024670	020104	044124	047522		
4589	024676	043525	020110	040505		
4590	024704	044103	050040	051117		
4591	024712	020124	047516	020124		
4592	024720	044124	020105	040523		
4593	024726	042515	000			
4594						
4595	024731	124	046511	047505	EM6:	.ASCIZ /TIMEOUT HAS NOT OCCURRED WITHIN 2 SECONDS/
4596	024736	052125	044040	051501		
4597	024744	047040	052117	047440		
4598	024752	041503	051125	042522		
4599	024760	020104	044527	044124		
4600	024766	047111	031040	051440		
4601	024774	041505	047117	051504		
4602	025002	000				
4603						
4604	025003	124	046511	047505	EM7:	.ASCIZ /TIMEOUT ONE-SHOT IS LESS THAN 500 MS/
4605	025010	052125	047440	042516		
4606	025016	051455	047510	020124		
4607	025024	051511	046040	051505		
4608	025032	020123	044124	047101		
4609	025040	032440	030060	046440		
4610	025046	000123				
4611						
4612	025050	042522	042101	047111	EM10:	.ASCIZ /READIN PRESET DOES NOT SET VOLUME VALID FOR THE PORT/
4613	025056	050040	042522	042523		
4614	025064	020124	047504	051505		
4615	025072	047040	052117	051440		
4616	025100	052105	053040	046117		
4617	025106	046525	020105	040526		
4618	025114	044514	020104	047506		
4619	025122	020122	044124	020105		
4620	025130	047520	052122	000		
4621						
4622	025135	047	047507	020047	EM11:	.ASCIZ /'GO' BIT RESET DURING UNLOAD COMMAND/
4623	025142	044502	020124	042522		
4624	025150	042523	020124	052504		
4625	025156	044522	043516	052440		
4626	025164	046116	040517	020104		
4627	025172	047503	046515	047101		
4628	025200	000104				

4629					
4630	025202	047111	047503	051122	EM12: .ASCIZ /INCORRECT STATUS DURING UNLOAD COMMAND/
4631	025210	041505	020124	052123	
4632	025216	052101	051525	042040	
4633	025224	051125	047111	020107	
4634	025232	047125	047514	042101	
4635	025240	041440	046517	040515	
4636	025246	042116	000		
4637					
4638	025251	104	044522	042526	EM13: .ASCIZ /DRIVE DID NOT RETURN TO NEUTRAL AFTER UNLOAD COMMAND/
4639	025256	042040	042111	047040	
4640	025264	052117	051040	052105	
4641	025272	051125	020116	047524	
4642	025300	047040	052505	051124	
4643	025306	046101	040440	052106	
4644	025314	051105	052440	046116	
4645	025322	040517	020104	047503	
4646	025330	046515	047101	000104	
4647					
4648	025336	052101	042524	052116	EM14: .ASCIZ /ATTENTION BIT SET ON 'OPPOSITE PORT' AFTER UNLOAD/
4649	025344	047511	020116	044502	
4650	025352	020124	042523	020124	
4651	025360	047117	023440	050117	
4652	025366	047520	044523	042524	
4653	025374	050040	051117	023524	
4654	025402	040440	052106	051105	
4655	025410	052440	046116	040517	
4656	025416	000104			
4657					
4658	025420	052101	042524	052116	EM15: .ASCIZ /ATTENTION BIT NOT SET ON PORT WHICH ISSUED 'UNLOAD'/
4659	025426	047511	020116	044502	
4660	025434	020124	047516	020124	
4661	025442	042523	020124	047117	
4662	025450	050040	051117	020124	
4663	025456	044127	041511	020110	
4664	025464	051511	052523	042105	
4665	025472	023440	047125	047514	
4666	025500	042101	000047		
4667					
4668	025504	051104	053111	020105	EM16: .ASCII /DRIVE NOT IN NEUTRAL AFTER UNLOAD WITH 'CONTROLLER/<CR><LF>
4669	025512	047516	020124	047111	
4670	025520	047040	052505	051124	
4671	025526	046101	040440	052106	
4672	025534	051105	052440	046116	
4673	025542	040517	020104	044527	
4674	025550	044124	023440	047503	
4675	025556	052116	047522	046114	
4676	025564	051105	005015		
4677	025570	042523	042514	052103	.ASCIZ @SELECT' SWITCH MOVED FROM 'A/B'@
4678	025576	020047	053523	052111	
4679	025604	044103	046440	053117	
4680	025612	042105	043040	047522	
4681	025620	020115	040447	041057	
4682	025626	000047			
4683					
4684	025630	051104	053111	020105	EM17: .ASCIZ /DRIVE LOCKED ON PORT 'A' BY SWITCH WHILE CYCLED UP/

4685	025636	047514	045503	042105	
4686	025644	047440	020116	047520	
4687	025652	052122	023440	023501	
4688	025660	041040	020131	053523	
4689	025666	052111	044103	053440	
4690	025674	044510	042514	041440	
4691	025702	041531	042514	020104	
4692	025710	050125	000		
4693					
4694	025713	104	044522	042526	EM20: .ASCIZ /DRIVE LOCKED ON PORT 'B' BY SWITCH WHILE CYCLED UP/
4695	025720	046040	041517	042513	
4696	025726	020104	047117	050040	
4697	025734	051117	020124	041047	
4698	025742	020347	054502	051440	
4699	025750	044527	041524	020110	
4700	025756	044127	046111	020105	
4701	025764	054503	046103	042105	
4702	025772	052440	000120		
4703					
4704	025776	052123	052101	051525	EM21: .ASCIZ /STATUS INCORRECT FOR PORT AFTER CYCLE UP/
4705	026004	044440	041516	051117	
4706	026012	042522	052103	043040	
4707	026020	051117	050040	051117	
4708	026026	020124	043101	042524	
4709	026034	020122	054503	046103	
4710	026042	020105	050125	000	
4711					
4712	026047	122	043505	051511	EM22: .ASCIZ /REGISTER CONTENTS SEEN WHEN DRIVE SWITCHED ON 'OPPOSITE' PORT/
4713	026054	042524	020122	047503	
4714	026062	052116	047105	051524	
4715	026070	051440	042505	020116	
4716	026076	044127	047105	042040	
4717	026104	044522	042526	051440	
4718	026112	044527	041524	042510	
4719	026120	020104	047117	023440	
4720	026126	050117	047520	044523	
4721	026134	042524	020047	047520	
4722	026142	052122	000		
4723					
4724	026145	047	042516	023504	EM23: .ASCIZ /'NED' SET WHEN RPDS1 ACCESSED THROUGH PORT NOT SWITCHED/
4725	026152	051440	052105	053440	
4726	026160	042510	020116	050122	
4727	026166	051504	020061	041501	
4728	026174	042503	051523	042105	
4729	026202	052040	051110	052517	
4730	026210	044107	050040	051117	
4731	026216	020124	047516	020124	
4732	026224	053523	052111	044103	
4733	026232	042105	000		
4734					
4735	026235	104	044522	042526	EM24: .ASCIZ /DRIVE SWITCHED TO LOCKED OUT PORT WHEN RELEASED/
4736	026242	051440	044527	041524	
4737	026250	042510	020104	047524	
4738	026256	046040	041517	042513	
4739	026264	020104	052517	020124	
4740	026272	047520	052122	053440	

4741	026300	042510	020116	042522	
4742	026306	042514	051501	042105	
4743	026314	000			
4744					
4745	026315	122	030510	020061	EM25: .ASCIZ /RH11 DIDN'T RESPOND TO ADDRESSING/
4746	026322	044504	047104	052047	
4747	026330	051040	051505	047520	
4748	026336	042116	052040	020117	
4749	026344	042101	051104	051505	
4750	026352	044523	043516	000	
4751					
4752	026357	104	044522	042526	EM30: .ASCIZ /DRIVE NOT SEIZED BY PORT/
4753	026364	047040	052117	051440	
4754	026372	044505	042532	020104	
4755	026400	054502	050040	051117	
4756	026406	000124			
4757					
4758	026410	051127	047117	020107	EM31: .ASCIZ /WRONG STATUS SEEN BY THE SEIZING PORT/
4759	026416	052123	052101	051525	
4760	026424	051440	042505	020116	
4761	026432	054502	052040	042510	
4762	026440	051440	044505	044532	
4763	026446	043516	050040	051117	
4764	026454	000124			
4765					
4766	026456	042522	044507	052123	EM32: .ASCIZ /REGISTER CONTENTS WRONG/
4767	026464	051105	041440	047117	
4768	026472	042524	052116	020123	
4769	026500	051127	047117	000107	
4770					
4771	026506	047503	052116	047522	EM33: .ASCIZ /CONTROL BUS PARITY ERROR READING INDICATED REGISTER/
4772	026514	020114	052502	020123	
4773	026522	040520	044522	054524	
4774	026530	042440	051122	051117	
4775	026536	051040	040505	044504	
4776	026544	043516	044440	042116	
4777	026552	041511	052101	042105	
4778	026560	051040	043505	051511	
4779	026566	042524	000122		
4780					
4781	026572	040503	023516	020124	EM34: .ASCIZ /CAN'T ACCESS DRIVE THROUGH EITHER PORT/
4782	026600	041501	042503	051523	
4783	026606	042040	044522	042526	
4784	026614	052040	051110	052517	
4785	026622	044107	042440	052111	
4786	026630	042510	020122	047520	
4787	026636	052122	000		
4788					
4789	026641	104	044522	042526	EM35: .ASCIZ /DRIVE NOT IN NEUTRAL AFTER RELEASE - REQUEST NOT SET/
4790	026646	047040	052117	044440	
4791	026654	020116	042516	052125	
4792	026662	040522	020114	043101	
4793	026670	042524	020122	042522	
4794	026676	042514	051501	020105	
4795	026704	020055	042522	052521	
4796	026712	051505	020124	047516	

K07

4797	026720	020124	042523	000124	
4798					
4799	026726	051104	053111	020105	EM36: .ASCIZ /DRIVE NOT IN NEUTRAL AFTER TIMEOUT - REQUEST NOT SET/
4800	026734	047516	020124	047111	
4801	026742	047040	052505	051124	
4802	026750	046101	040440	052106	
4803	026756	051105	052040	046511	
4804	026764	047505	052125	026440	
4805	026772	051040	050505	042525	
4806	027000	052123	047040	052117	
4807	027006	051440	052105	000	
4808					
4809	027013	122	043505	051511	EM37: .ASCIZ /REGISTER CONTENTS WRONG AFTER RELEASE OR TIMEOUT/
4810	027020	042524	020122	047503	
4811	027026	052116	047105	051524	
4812	027034	053440	047522	043516	
4813	027042	040440	052106	051105	
4814	027050	051040	046105	040505	
4815	027056	042523	047440	020122	
4816	027064	044524	042515	052517	
4817	027072	000124			
4818					
4819	027074	051104	053111	020105	EM40: .ASCIZ /DRIVE IN NEUTRAL AFTER RELEASE - REQUEST SET/
4820	027102	047111	047040	052505	
4821	027110	051124	046101	040440	
4822	027116	052106	051105	051040	
4823	027124	046105	040505	042523	
4824	027132	026440	051040	050505	
4825	027140	042525	052123	051440	
4826	027146	052105	000		
4827					
4828	027151	122	043505	051511	EM41: .ASCIZ /REGISTER WRONG AFTER RELEASE WITH REQUEST SET/
4829	027156	042524	020122	051127	
4830	027164	047117	020107	043101	
4831	027172	042524	020122	042522	
4832	027200	042514	051501	020105	
4833	027206	044527	044124	051040	
4834	027214	050505	042525	052123	
4835	027222	051440	052105	000	
4836					
4837					
4838	027227	124	051505	020124	DH1: .ASCIZ /TEST # ERR PC PORT # REG ADR CONTENTS/
4839	027234	020043	042440	051122	
4840	027242	050040	020103	050040	
4841	027250	051117	020124	020043	
4842	027256	051040	043505	040440	
4843	027264	051104	041440	047117	
4844	027272	042524	052116	000123	
4845	027300	042524	052123	021440	DH2: .ASCIZ /TEST # ERR PC PORT # REG ADR GOOD BAD/
4846	027306	020040	051105	020122	
4847	027314	041520	020040	047520	
4848	027322	052122	021440	020040	
4849	027330	042522	020107	042101	
4850	027336	020122	047507	042117	
4851	027344	020040	020040	040502	
4852	027352	000104			

4853	027354	042524	052123	021440	DH5:	.ASCIZ /TEST #	ERR PC	REG ADR	PORT A	PORT B/
4854	027362	020040	051105	020122						
4855	027370	041520	020040	042522						
4856	027376	020107	042101	020122						
4857	027404	047520	052122	040440						
4858	027412	020040	047520	052122						
4859	027420	041040	000							
4860	027423	124	051505	020124	DH6:	.ASCIZ /TEST #	ERR PC	PORT #/		
4861	027430	020043	042440	051122						
4862	027436	050040	020103	050040						
4863	027444	051117	020124	000043						
4864	027452	042524	052123	021440	DH7:	.ASCIZ /TEST #	ERR PC	PORT #	TIME (IN MS)/	
4865	027460	020040	051105	020122						
4866	027466	041520	020040	047520						
4867	027474	052122	021440	020040						
4868	027502	044524	042515	024040						
4869	027510	047111	046440	024523						
4870	027516	000								
4871	027517	040	020040	020040	DH13:	.ASCII /		SEIZE/	<CR><LF>	
4872	027524	020040	020040	020040						
4873	027532	020040	020040	051440						
4874	027540	044505	042532	005015						
4875	027546	042524	052123	021440		.ASCIZ /TEST #	ERR PC	PORT #/		
4876	027554	020040	051105	020122						
4877	027562	041520	020040	047520						
4878	027570	052122	021440	000						
4879	027575	040	020040	020040	DH14:	.ASCII /		SEIZE	ERROR/	<CR><LF>
4880	027602	020040	020040	020040						
4881	027610	020040	020040	051440						
4882	027616	044505	042532	020040						
4883	027624	042440	051122	051117						
4884	027632	005015								
4885	027634	042524	052123	021440		.ASCIZ /TEST #	ERR PC	PORT #	PORT #	REG ADR CONTENTS/
4886	027642	020040	051105	020122						
4887	027650	041520	020040	047520						
4888	027656	052122	021440	020040						
4889	027664	047520	052122	021440						
4890	027672	020040	042522	020107						
4891	027700	042101	020122	047503						
4892	027706	052116	047105	051524						
4893	027714	000								
4894	027715	124	051505	020124	DH17:	.ASCIZ /TEST #	ERR PC/			
4895	027722	020043	042440	051122						
4896	027730	050040	000103							
4897	027734	020040	020040	020040	DH24:	.ASCII /		LOCKED	SWITCHED TO/	<CR><LF>
4898	027742	020040	020040	020040						
4899	027750	020040	020040	047514						
4900	027756	045503	042105	020040						
4901	027764	053523	052111	044103						
4902	027772	042105	052040	006517						
4903	030000	012								
4904	030001	124	051505	020124		.ASCIZ /TEST #	ERR PC	PORT #	PORT #/	
4905	030006	020043	042440	051122						
4906	030014	050040	020103	050040						
4907	030022	051117	020124	020043						
4908	030030	050040	051117	020124						

N07

4965	030511	040	020040	020040	DH40:	.ASCII /	RELSNG	RQSTNG/<CR><LF>
4966	030516	020040	020040	020040				
4967	030524	020040	020040	051040				
4968	030532	046105	047123	020107				
4969	030540	051040	051521	047124				
4970	030546	006507	012					
4971	030551	124	051505	020124		.ASCIZ /TEST #	ERR PC	PORT # PORT #/
4972	030556	020043	042440	051122				
4973	030564	050040	020103	050040				
4974	030572	051117	020124	020043				
4975	030600	050040	051117	020124				
4976	030606	000043						
4977								
4978						.EVEN		
4979								
4980	030610	001242	001116	001234	DT1:	.WORD	TSTNUM, SERRPC, PTNBR, SBDADR, SBDDAT, 0	
4981	030616	001122	001126	000000				
4982	030624	001242	001116	001234	DT2:	.WORD	TSTNUM, SERRPC, PTNBR, SBDADR, SGDDAT, SBDDAT, 0	
4983	030632	001122	001124	001126				
4984	030640	000000						
4985	030642	001242	001116	001122	DT5:	.WORD	TSTNUM, SERRPC, SBDADR, SGDDAT, SBDDAT, 0	
4986	030650	001124	001126	000000				
4987	030656	001242	001116	001234	DT6:	.WORD	TSTNUM, SERRPC, PTNBR, 0	
4988	030664	000000						
4989	030666	001242	001116	001234	DT7:	.WORD	TSTNUM, SERRPC, PTNBR, TIME, 0	
4990	030674	001252	000000					
4991	030700	001242	001116	001236	DT13:	.WORD	TSTNUM, SERRPC, SEIZPT, 0	
4992	030706	000000						
4993	030710	001242	001116	001236	DT14:	.WORD	TSTNUM, SERRPC, SEIZPT, PTNBR, SBDADR, SBDDAT, 0	
4994	030716	001234	001122	001126				
4995	030724	000000						
4996	030726	001242	001116	000000	DT17:	.WORD	TSTNUM, SERRPC, 0	
4997	030734	001242	001116	001236	DT24:	.WORD	TSTNUM, SERRPC, SEIZPT, PTNBR, 0	
4998	030742	001234	000000					
4999	030746	001272	000000		DT25:	.WORD	SRPADR, 0	
5000	030752	001242	001116	001236	DT30:	.WORD	TSTNUM, SERRPC, SEIZPT, PTNBR, SBDADR, SGDDAT, SBDDAT, 0	
5001	030760	001234	001122	001124				
5002	030766	001126	000000					
5003	030772	001242	001116	001170	DT34:	.WORD	TSTNUM, SERRPC, STMP2, STMP3, 0	
5004	031000	001172	000000					
5005	031004	001242	001116	001236	DT35:	.WORD	TSTNUM, SERRPC, SEIZPT, PTNBR, 0	
5006	031012	001234	000000					
5007	031016	001242	001116	001236	DT40:	.WORD	TSTNUM, SERRPC, SEIZPT, OPPRT, 0	
5008	031024	001240	000000					
5009								
5010	031030	000	000	001	DF1:	.BYTE	0,0,1,0,0	
5011	031033	000	000					
5012	031035	000	000	001	DF2:	.BYTE	0,0,1,0,0,0	
5013	031040	000	000	000				
5014	031043	000	000	000	DF5:	.BYTE	0,0,0,0,0	
5015	031046	000	000					
5016	031050	000	000	001	DF6:	.BYTE	0,0,1	
5017	031053	000	000	001	DF7:	.BYTE	0,0,1,1	
5018	031056	001						
5019	031057	000	000	001	DF14:	.BYTE	0,0,1,1,0,0	
5020	031062	001	000	000				

5021	031065	000	000		DF17:	.BYTE	0,0
5022	031067	000			DF25:	.BYTE	0
5023	031070	000	000	001	DF30:	.BYTE	0,0,1,1,0,0,0
5024	031073	001	000	000			
5025	031076	000					
5026	031077	000	000	000	DF34:	.BYTE	0,0,0,0
5027	031102	000					

031104 .EVEN

;;*****

.SBTTL CONSTANTS, TABLES, ETC

;;*****

;TABLE OF TEST STARTING ADDRESSES

5040	031104	002714	TSTADR:	.WORD	TST1+2	: STARTING ADDRESS OF TEST	1
5041	031106	004314		.WORD	TST2+2	: STARTING ADDRESS OF TEST	2
5042	031110	005076		.WORD	TST3+2	: STARTING ADDRESS OF TEST	3
5043	031112	005660		.WORD	TST4+2	: STARTING ADDRESS OF TEST	4
5044	031114	006576		.WORD	TST5+2	: STARTING ADDRESS OF TEST	5
5045	031116	007514		.WORD	TST6+2	: STARTING ADDRESS OF TEST	6
5046	031120	011072		.WORD	TST7+2	: STARTING ADDRESS OF TEST	7
5047	031122	012450		.WORD	TST10+2	: STARTING ADDRESS OF TEST	10
5048	031124	013362		.WORD	TST11+2	: STARTING ADDRESS OF TEST	11
5049	031126	014274		.WORD	TST12+2	: STARTING ADDRESS OF TEST	12
5050	031130	015312		.WORD	TST13+2	: STARTING ADDRESS OF TEST	13
5051	031132	016424		.WORD	TST14+2	: STARTING ADDRESS OF TEST	14

;ATTENTION BIT TABLE

5055	031134	001	ATABIT:	.BYTE	1	: ATTENTION BIT FOR DRIVE	0
5056	031135	002		.BYTE	2	: ATTENTION BIT FOR DRIVE	1
5057	031136	004		.BYTE	4	: ATTENTION BIT FOR DRIVE	2
5058	031137	010		.BYTE	10	: ATTENTION BIT FOR DRIVE	3
5059	031140	020		.BYTE	20	: ATTENTION BIT FOR DRIVE	4
5060	031141	040		.BYTE	40	: ATTENTION BIT FOR DRIVE	5
5061	031142	100		.BYTE	100	: ATTENTION BIT FOR DRIVE	6
5062	031143	200		.BYTE	200	: ATTENTION BIT FOR DRIVE	7

MAXTN: .WORD STN-1 ;MAXIMUM TEST NUMBER

5066 000001 .END

MOH = 020000	963#												
MOL = 010000	903#	1764	1796	1868	1893	1978	2003	2105	2148	2250	2293	2446	2465
	2666	2685	2836	2847	2971	2982	3099	3148	3241	3249	3259	3360	3362
	3435	3443	3453	3552	3554								
MPE = 000400	860#												
MRD = 000020	933#												
MSE = 000020	992#												
MSTCK = 000010	932#												
MNR = 000040	934#												
MXF = 001000	861#												
NBA = 100000	965#												
NED = 010000	864#	1668	1672	1689	1693	3305	3309	3499	3503				
NEM = 004000	863#												
NHS = 002000	998#	1016#											
NOATA = 000001	1463#	1922	1928	2032	2038	2179	2185	2324	2330	2456#	2494	2500	2505#
	2676#	2714	2720	2725#	2876	2882	3011	3017	3130	3135	3179	3184	
	1561	4460#											
NOCLOC 023463	1193#												
NOSEIZ 001246	1606	4482#											
NTRH11 023660	1050#	1060#											
OCYL = 100000	1028#												
OFREV = 000200	1024#												
OF100 = 000004	1025#												
OF200 = 000010	1022#												
OF25 = 000001	1026#												
OF400 = 000020	1023#												
OF50 = 000002	1027#												
OF800 = 000040	1058#												
OPE = 020000	923#												
OPI = 020000	1190#	2092#	2237#	5007									
OPRT 001240	859#												
OR = 000200	913#												
PAR = 000010	856#												
PAT = 000020	862#												
PGE = 002000	900#	1749	1751	1755	1781	1783	1787	1868	1893	1978	2003	2105	2148
PGM = 001000	2250	2293	2424	2465	2644	2685	2847	2982	3099	3148			
	904#	2424	2644										
PIP = 020000	731#												
PIR0 = 177772	825#												
PIR0VE = 000240	1001#	1018#											
PLU = 020000	1184#	1526#	1527	1531	1534	1538	1550	1553	1659	1660	1705	1706	1743
PORTA 001224	1744	1811	1851	1852	1884	1885	1894	1913	1915	1921	2004	2023	2025
	2031	2087	2088	2102	2103	2149	2168	2170	2178	2235	2236	2237	2263
	2264	2294	2313	2315	2323	2382	2390	2391	2392	2436	2466	2485	2487
	2493	2525	2526	2602	2669	2670	2686	2705	2707	2713	2728	2729	2769
	2816	2824	2825	2826	2830	2848	2867	2869	2875	2951	2983	3002	3004
	3010	3038	3039	3082	3100	3119	3121	3129	3149	3168	3170	3178	3234
	3235	3320	3321	3323	3358	3359	3476	3477	3518	3519	3563	3564	
	1537	4452#											
PORTAI 023407	1185#	1531#	1532#	1533#	1536#	1544	1680	1681	1722	1723	1775	1776	1813
PORTB 001226	1898	1909	1910	1927	1961	1962	1994	1995	2008	2019	2020	2037	2090
	2091	2092	2118	2119	2153	2164	2165	2184	2232	2233	2247	2248	2298
	2309	2310	2329	2386	2449	2450	2470	2481	2482	2499	2508	2509	2549
	2606	2610	2611	2612	2656	2690	2701	2702	2719	2745	2746	2820	2852
	2863	2864	2881	2903	2904	2955	2959	2960	2961	2965	2987	2998	2999
	3016	3086	3104	3115	3116	3134	3153	3164	3165	3183	3282	3283	3324

L08

MD-11-DZRJF-A, RPO4/5/6 DUAL CONTRLR LOGIC TEST - PART 2
 DZRJFA.CMB 02-NOV-76 19:11

MACY11 27(1006) 02-NOV-76 19:12 PAGE 103

CROSS REFERENCE TABLE -- USER SYMBOLS

		2030*	2036*	2093*	2097	2104*	2108	2163*	2169*	2177*	2183*	2238*	2242	2249*
		2253	2308*	2314*	2322*	2328*	2406*	2410	2414	2421*	2425	2429	2480*	2486*
		2492*	2498*	2511*	2515	2519	2528*	2532	2536	2626*	2630	2634	2641*	2645
		2649	2700*	2706*	2712*	2718*	2731*	2735	2739	2748*	2752	2756	2862*	2868*
		2874*	2880*	2997*	3003*	3009*	3015*	3114*	3120*	3128*	3133*	3163*	3169*	3177*
		3182*	3256*	3260	3264	3285*	3289	3293	3300*	3304	3308	3327*	3331	3335
		3450*	3454	3458	3479*	3483	3487	3494*	3498	3502	3521*	3525	3529	4980
		4982	4985	4993	5000									
SBELL	001202	1172#	3751	3771	4084	4273								
SCHARC	021062	3863*	3873*	3880	3889*	3894#								
SCKSWR	022012	4117#	4417											
SCMTAG	001100	1132#	1475	1476	1484	1488	1489	1490						
SCM1	= 000001	1164#	1165#											
SCM2	= 000002	1164#	1165#											
SCM3	= 000001	1162#	1164											
SCM4	= 000005	1165#	1166#	1167#	1168#	1169#	1170#							
SCNTLG	022654	4138	4274#											
SCNTLU	022647	4155	4248	4273#										
SCRFLF	001207	1174#	1549	1569	1605	2441	2661	2835	2970	3376	3612	3759	3771	3779
		3798	3803	3823	3862	3897	4166	4253	4273	4333				
SDBLK	021530	3998	4032	4040#										
SDOAGN	017734	3594	3615	3621#										
SDTBL	021520	4001	4036#											
SENDAD	017724	1111	3617#	3766										
SENDCT	017570	1488	3596#											
SENULL	017740	3624#												
SEOP	017524	3572	3584#											
SEOPCT	017562	1488*	3593#	3597										
SERFLG	001103	1135#	2890	2894*	3025	3029*	3344	3348*	3538	3542*	3688	3711	3713*	3730
		3746*	3771											
SERMAX	001115	1141#	1491*	1577*	3730									
SERROR	020340	1484	3743#											
SERRPC	001116	1142#	3753*	3754*	3755	3771	3785	4980	4982	4985	4987	4989	4991	4993
		4996	4997	5000	5003	5005	5007							
SERRTB	001276	1227#	3793											
SERRTY	020472	3758	3778#											
SERTTL	001112	1139#	3609	3613*	3752*	3771								
SESCAP	001200	1171#	1490*											
SFILLC	001156	1160#	3866	3897										
SFILLS	001155	1159#	3897											
SGOADR	001120	1143#												
SGODAT	001124	1145#	1666*	1669	1673*	1687*	1690	1694*	1711*	1714	1718*	1728*	1731	1735*
		1749*	1752	1756*	1764*	1767	1771*	1781*	1784	1788*	1796*	1799	1803*	1812*
		1815	1868*	1871	1875*	1893*	1923	1929	1978*	1981	1985*	2003*	2033	2039
		2096*	2097	2105*	2106	2110	2148*	2180	2186	2241*	2242	2250*	2251	2255
		2293*	2325	2331	2409*	2412	2416*	2424*	2427	2431*	2465*	2495	2501	2514*
		2517	2521*	2531*	2534	2538*	2629*	2632	2636*	2644*	2647	2651*	2685*	2715
		2721	2734*	2737	2741*	2751*	2754	2758*	2847*	2877	2883	2982*	3012	3018
		3099*	3130	3135	3148*	3179	3184	3259*	3262	3266*	3288*	3291	3295*	3303*
		3306	3310*	3330*	3333	3337*	3453*	3456	3460*	3482*	3485	3489*	3497*	3500
		3504*	3524*	3527	3531*	4982	4985	5000						
SGET42	017714	3614#												
SGTSWR	022102	4139#	4415											
SHD	= 000000	703												
SHIOCT	023042	4321*	4332#											
SICNT	001104	1136#	1593*	3719*	3720	3722*	3729							

