

.REM %

IDENTIFICATION

PRODUCT CODE: AC-E490B-MC
PRODUCT NAME: CZTUPB0 TM03/TU45 LGC PRT 2
DATE CREATED: 25 MAY 1978
MAINTAINER: CSS - NASHUA
AUTHOR: J. G. ADAMS/R. J. COLLINS
UPDATE INFORMATION: DATE AUTHOR
 29-FEB-1980 VIJAY ANANDWALA

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDE IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBLILTY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

(COPYRIGHT (c) 1975, 1980 BY DIGITAL EQUIPMENT CORPORATION

TABLE OF CONTENTS

PARAGRAPH	SUBJECT	PAGE
1.	ABSTRACT	3
2.	REQUIREMENTS	3
3.	LOADING PROCEDURE	3
4.	STARTING PROCEDURE	3
5.	SWITCH SETTINGS	5
6.	ERROR PRINTOUTS	5
7.	OPERATION	7
8.	SUBTEST SUMMARIES	8
9.	LISTING	15

1. ABSTRACT

THIS PROGRAM IS DESIGNED TO SEQUENTIALLY TEST THE DATA FORMATTING FUNCTIONALITY OF THE TM03 FORMATTER. EACH TEST WILL ATTEMPT TO ISOLATE FAILURES TO THE MODULE LEVEL AND PROVIDE PRINTOUT INFORMATION WHICH WILL IDENTIFY THE FAILING MODULE. THE LEVEL OF FAULT ISOLATION IS POSSIBLE BECAUSE OF TM03 THE STRUCTURE AND ITS MAINTAINENCE MODES.

2. REQUIREMENTS (HARDWARE)

- A. ANY PDP-11 PROCESSOR
- B. 8K OF CORE
- C. CONSOLE TTY
- D. TM03 MAGTAPE CONTROLLER
- E. MASSBUS CONTROLLER (RH)
- F. TU45 MAGTAPE TRANSPORT

3. LOADING PROCEDURE

USE STANDARD PROCEDURE FOR LOADING BINARY PAPER TAPE.

4. STARTING PROCEDURE

THERE ARE TWO (2) STARTING ADDRESSES THAT MAY BE USED:
200(8) AND 210(8).

- A. 200(8): STARTING AT THIS ADDRESS WILL CAUSE A PROGRAM IDENTIFICATION HEADER TO BE PRINTED BEFORE TESTING IS BEGUN.
- B. 210(8): STARTING AT THIS ADDRESS WILL NOT PRINT THE IDENTIFICATION HEADER AND IS THEREFORE GENERALLY TO BE USED FOR RESTARTS RATHER THAN INITIAL START.

** NOTE: SEE ALSO SEC 5. CONSOLE SWITCH SETTINGS
** TYPE ^C TO RESTART PROGRAM (@200)

4.1 AUTOMATIC MODE OPERATION

IF THIS PROGRAM IS LOADED AND RUN IN AUTOMATIC (CHAIN) MODES
DEFAULT RESPONSES TO OPERATOR REQUESTS ARE USED. THE SOFTWARE
SWR IS INVOKED WITH A SWITCH SETTING OF 100000 (HALT ON ERROR)
IF IN ACT11 CHAIN MODE. NO OPERATOR INTERVENTION IS REQUIRED.

**EXCEPTION: IF THIS PROGRAM IS LOADED VIA TMDP CHAIN MODE THE
PROGRAM WILL NOT TEST TM03 DRIVE #0, TU45 SLAVE #0.

4.2 SAMPLE START AT 200

NOTE: DEFAULT RESPONSES ARE SHOWN IN ANGLE BRACKETS <>,
OPERATOR RESPONSES ARE SHOWN IN PARENTESES (), AND
MEMORY LOCATIONS CONTAINING THE DEFAULT ARE SHOWN IN
SQUARE BRACKETS [].

PARAMETER REQUEST: <DEFAULT> (RESPONSE) [LOCATION:]

TM03-TU45 CONTROL LOGIC TEST PART 11 (CZTUPB0)
ASSURE TAPE IS AT BOT
TYPE ^C TO RESTART

REGISTER START: <172440> (CR) [REGS:]
VECTOR ADDRESS: <224> (CR) [VECT:]
TM03 DRIVE: <0> (CR) [DRVN:]
TU45 SLAVE: <0> (CR) [SLVN:]
IF THE SOFTWARE SWR IS INVOKED:
SWR = <000000> NEW = (CR) [SWREG:]

5. CONSOLE SWITCH SETTINGS

CONTROL:

- 1) CONTROL G <^G>:
SELECTS THE SOFTWARE SWR AND ALLOWS NEW SWITCH SETTINGS.

THE MACHINE WILL THEN TYPE: SWR=XXXXXXNEW=
WHERE: XXXXXX IS THE OCTAL CONTENTS OF THE SOFTWARE SWR.
AFTER 'NEW=' HAS BEEN TYPED THEN THE OPERATOR CAN DO ONE
OF THE FOLLOWING AT THE TTY:
A) TYPE AN OCTAL NUMBER TO BE LOADED INTO THE SOFTWARE SWR.
B) IF A <CR> IS THE FIRST KEY DEPRESSED THE SOFTWARE SWITCH
REGISTER CONTENTS WILL NOT BE CHANGED.
- 2) CONTROL A <^A>:
ALTERNATES THE SWITCH REGISTER FROM HARDWARE TO SOFTWARE & VICE VERSA.
- 3) CONTROL C <^C>:
RESTART PROGRAM AT 200
- 4) CONTROL U <^U>:
DELETES ALL CHARACTERS TYPED IN RESPONSE TO A REQUEST.

ALL SWITCHES ARE USED (0-15) AND THE NORMAL, OR DEFAULT, RUN
IS DONE WITH ALL SWITCHES SET TO ZERO (0).
ALL SWITCHES ARE DYNAMIC AND MAY BE CHANGED AT ANY TIME.

- SW15: 1=HALT ON ERROR
0=CONTINUE
- SW14: 1=LOOP ON ERROR (SCOPE)
0=CONTINUE
- SW13: 1=DO NOT PRINT ERRORS
0=PRINT ALL ERRORS
- SW12: 1=DO CONTINUOUS CYCLE
0=HALT AT END OF PASS
- SW11: 1=INHIBIT ITERATIONS
0=ITERATE EACH TEST ITS ASSIGNED AMOUNT
- SW10: 1=HALT AT END OF CURRENT TEST
0=CONTINUE TO NEXT TEST
- SW8: 1=INHIBIT WRAP AROUND DATA CHECK
0=DO DATA CHECKS
- SW7: 1=INHIBIT WRAP AROUND STATUS CHECK
0=DO STATUS CHECK
- SW6: 1=SELECTABLE WRAP DATA PATTERN (IN SINGLE TEST)
0=AUTO PATTERN
- SW5-0: SELECT INDIVIDUAL TEST ** 00=DO ALL TESTS

6. ERROR PRINTOUTS

ERROR PRINTOUTS WILL APPEAR IN TWO FORMS, ONE FOR THE CONTROL LOGIC TESTS AND ANOTHER FOR THE DATA TESTS.

CONTROL LOGIC PRINTOUTS WILL CONTAIN A HEADER WHICH CALLS OUT THE TEST NUMBER, FUNCTION BEING TESTED, AND THE SUSPECT MODULE, OR MODULES ON THE FIRST LINE. THE SECOND LINE WILL CONTAIN INFORMATION AS TO THE ACTUAL ERROR. BOTH THE EXPECTED RESULT AND THE ACTUAL RESULT OF THE TEST WILL BE GIVEN. LINE THREE WILL SHOW THE CONTENTS OF THE MAJOR REGISTERS AT THE TIME OF THE ERROR AND LINE FOUR WILL PRINT THE ITERATION NUMBER WHEN APPLICABLE.

DATA TESTS WILL PRINT A HEADER CONTAINING THE TEST NUMBER, AND A DESCRIPTION OF THE WRAP AROUND FUNCTION UNDER TEST. FOLLOWING THE HEADER WILL BE A LIST OF THE MAJOR REGISTERS WITH THE EXPECTED AND ACTUAL VALUES. ANY BAD DATA WILL BE PRINTED (PER CHARACTER) FOLLOWING THE REGISTER INFORMATION OR FOLLOWING THE HEADER IF NO STATUS ERRORS WERE ENCOUNTERED.

5. THE FOLOWING ARE TWO EXAMPLES OF ERRORS DETECTED BY THE WRAP AROUND DATA TESTS. NOTE THAT EACH WRAP AROUND TEST MAY BE ACCOMPANIED BY EITHER A STATUS ERROR OF A DATA ERROR OR BOTH.

LOGIC TEST 1: WRAP 3, NRZ, NORMAL, ODD
BAD STATUS
CS1 EXPT 004270 RCVD 144270
CS2 EXPT 000100 RCVD 000100
DS EXPT 010600 RCVD 150600
ER EXPT 000000 RCVD 000100

THIS MESSAGE INDICATES BAD STATUS OF VPE (BIT 6 OF ER)

LOGIC TEST 3: WRAP 2, NRZ, NORMAL, ODD
BAD DATA
CN:0
G: 11111111
B: 11111011
CN:10
G: 00000000
B: 00001000

THIS MESSAGE SHOWS THAT DATA RECEIVED WAS NOT AS EXPECTED. CHARACTER ZERO (CN: 0) SHOWS THAT BIT TWO (2) WAS DROPPED, WHILE CHARACTER TEN (CN: 10) SHOWS BIT THREE (3) HAS BEEN PICKED UP
G: = EXPECTED DATA (GOOD)
B: - ACTUAL DATA (BAD)

7. OPERATION

THE PROCEDURES FOR OPERATING THIS PROGRAM ARE QUITE SIMPLE AND REQUIRE ONLY A FEW STEPS:

1. LOAD ADDRESS 200 OR 210
2. SET SWITCHES FOR DESIRED TEST CYCLE
3. PRESS START

ALL CONSOLE SWITCHES ARE DYNAMIC AND MAY BE CHANGED AT ANY TIME. THE NORMAL OPERATING SEQUENCE IS ALL SWITCHES DOWN (0). THE TEST WILL TAKE APPROXIMATELY 3 MINUTES TO RUN; HOWEVER, IF ITERATIONS ARE INHIBITED (SW11=1) THE TEST WILL RUN IN ABOUT 30 SECONDS. THE END OF PASS IS NOTED BY A PRINTOUT STATING END OF PASS, AND THE NUMBER OF THAT PASS.

SINGLE TEST SELECTION: (SW0-SW5)

WHEN SW0-SW5 ARE SET TO ZERO (00), THE SCHEDULAR WILL EXECUTE ALL TESTS IN SEQUENCE. IF SW0-SW5 ARE SET TO SOME SPECIFIC TEST NUMBER THEN THAT PARTICULAR TEST ONLY WILL BE EXECUTED UNTIL THE TEST SELECT NUMBER IS CHANGED. WHEN YOU WISH TO SELECT A PARTICULAR TEST, SET SW10 TO A ONE (1) IN ORDER TO STOP AT THE END OF THE CURRENT TEST BEFORE SELECTING A DIFFERENT TEST NUMBER. YOU MAY SELECT THAT NUMBER IN ANY DIRECTION (HIGHER OR LOWER) BECAUSE EACH TEST IS SELF CONTAINED.

WRAP AROUND DATA PATTERNS MAY BE SELECTED VIA SW6 WHEN IN SINGLE TEST MODE. A TELETYPE REQUEST IS MADE FOR THE DESIRED DATA PATTERN WHENEVER SWITCH TEN (SW10) AND SWITCH SIX (SW6) ARE SET TO A ONE (1) WHILE ONE OF THE WRAP TESTS IS SELECTED IN SW0-SW5.

8. SUBTEST SUMMARIES

NOTE: FOR TESTS 1-15

FOR THE MOST PART, THIS DIAGNOSTIC TESTS PARTICULAR AREAS OF THE TM03 LOGIC INDEPENDENT OF THE TU45. HOWEVER THERE ARE A FEW SIGNALS WHICH ARE REQUIRED FROM THE TU45 TO COMPLETE THE TESTS, AND AT LEAST ONE CASE WHERE TU45 FAILURES INTERFERE WITH THE TESTS. THE KNOWN CASES ARE LISTED HERE AND SHOULD BE CHECKED AS PART OF THE DEBUGGING.

1. MOL(SB)L: REQUIRED TO ENABLE CLOCK
2. CLOCK(SB)L: REQUIRED TO GENERATE ACCELERATION AND SHUTDOWN.
3. WRITE CLCK(SB)L: USED IN WAMO TO GENERATE DATA AND REC(SB)L
4. RSDO(SB)L: SHOULD NOT OCCUR DURING WRAP AROUND TESTS, BUT WILL INTERFERE WITH THEIR OPERATION IF CAUSED BY A FAILURE SUCH AS A GROUNDED OUTPUT FROM THE G056.

LOGIC TEST 1: WRP3, NRZ, NORMAL, ODD (BIT FIDDLER READ)

PROGRAMMED SEQUENCE:

TAPE CONTROL REGISTER IS LOADED WITH DENSITY 3, FORMAT 14, ODD PARITY WRP3 IS LOADED IN MAINT. REGISTER. READ FUNCTION IS LOADED, EXECUTING WRAP3 CONSISTS LOADING DATA CHARACTERS INTO MAINT. REGISTER DATA FIELD, WHERE THERE ARE MULTI- PLEXERS TO BIT FIDDLER, MM CLK IS TOGGLED TO CREATE RDS. THE BIT FIDDLER TRANSMIT DATA ACCESS MASSBUS DATA LINES. WHEN ALL THE DATA HAS BEEN TRANSMITTED AN EOR CLK IS TRANSMITTED TO N REGISTER WHICH BRINGS OPERATION TO A CLOSE.

LIKELY FAULT LOCATIONS: M8906, M8905-YB, MASSBUS P-LINES

CIRCUITS

PRINT REFERENCES

MASSBUS CHAR. ASSEMBLE
CLR. GENERATOR
MAINT. REGISTER DATA FIELD
RDS GENERATION

BF5
BF2
MR2, MR3
MR5

LOGIC TEST 2: WARP3, PE, NORMAL, ODD

JUST LIKE TEST 1 EXCEPT FOR DENSITY BITS.

LOGIC TEST 3: WRAP2, NRZ, NORMAL, ODD

PROGRAMMED SEQUENCE:

WRAP2 IS BIT FIDDLER WRITE. MM CLOCK IS MULTIPLEXED INTO WRT CLK SO THAT IT FORMS WRT STROBE. THE OUTPUT OF THE BIT FIDDLER IS CLOCKED INTO THE DATA FIELD OF THE MAINTENANCE REGISTER. SET UP CONSISTS OF MOVING NRZ, NORMAL FORMAT, ODD PARITY TO UNIT DESCRIPTION MAINT. REGISTER IS LOADED WITH WAM2 WRITE COMMAND IS ISSUED. AFTER THE ACCELERATION DELAY, MM CLOCK ARE GENERATED UNTIL ALL THE DATA HAS BEEN CLOCKED. SEQUENCE IS COMPLETED BY LOADING MAINTENANCE REGISTER WITH EOR CLR. THE SEQUENCE IS REPEATED WITH VARYING DATA PATTERNS.

LIKELY FAULT LOCATIONS: M8906, M8905-YB, M8933

CIRCUITS

PRINT REFERENCES

BIT FIDDLER CHAR UNPACK
BIT FIDDLER DATA REQUEST
WRT STRB.
MAINT. REG. DATA FIELD

BF4
BF2
TCCM4
MR2, MR3

LOGIC TEST 4: WRP2, PE, NORMAL, ODD

THE TEST IS EXACTLY LIKE TEST 43 EXCEPT THAT PE WRT CLK ENBL L MUST BE ASSERTED BY M8932 TO ENABLE WR TO STROBE. THIS DOES NOT APPEAR UNTIL THE PE WRITE CONTROL CIRCUIT HAS CLOCKED THROUGH THE PREAMBLE.

CIRCUITS

PRINT REFERENCES

(IN ADDITION TO TEST 44)
PE WRITE CONTROL

TCPE3

LOGIC TEST 5: WRP1, NRZ, NORMAL, ODD

THIS TEST IS EXACTLY LIKE TEST 43 EXCEPT THAT WRITE BUFFER (TCCM2) IS MULTIPLEXED TO THE MAINTENANCE REGISTER.

LIKELY FAULT LOCATIONS: M8933, M8934 (CRC GENERATOR)

CIRCUITS

PRINT REFERENCES

WRITE BUFFER
CRC GENERATOR

TCCM2
CNR22

LOGIC TEST 6: WRAP1, PE, NORMAL, ODD

IN PE MODE BOTH THE PREAMBLE AND POSAMBLE ARE CLOCKED THROUGH THE WRITE BUFFER IN ADDITION TO PHASE ENCODED DATA.

LIKELY FAULT LOCATIONS: M8932 (WRITE CONTROL STATES), M8933

CIRCUITS

PRINT REFERENCE

WRITE BUFFER
WRITE CONTROL

TCCM2
TCPE3

LOGIC TEST 7: WRAP0, NORMAL, ODD

WRAP 0 IS THE MOST COMPLETE OF THE TM03 WRAPAROUND DATA PATH. IT CONSISTS OF A WRITE OPERATION IN WHICH THE OUTPUT OF THE WRITE DATA BUFFER IS MULTIPLEXED TO THE READ DATA INPUTS, CHECKED AND LOADED INTO THE MAINTENANCE REGISTER FOR RETRIEVAL BY THE PROCESSOR. THE WHOLE OPERATION USES THE TYPE SYSTEM CLOCKS AND HAPPENS AT THE PROPER DATA RATES. MM CLK SERVES AS A FLAG ANNOUNCING WHEN A NEW CHARACTER HAS BEEN LOADED INTO THE MAINTENANCE REGISTER. IN PE MODE EVERY OTHER CHARACTER IS READ TO ALLOW SUFFICIENT PROCESSOR LOOP TIME. IN NRZ WRAP 0 IS EXPECTED TO PRODUCE LRC ERRORS BECAUSE THE TM03 DOES NOT WRITE THE LRC CHARACTER.

LIKELY FAULT LOCATIONS: M8934, M8933

CIRCUITS

PRINT REFERENCES

CRC GENERATOR	CNR22
CRC CHECKOUT	CNR23
CRC, CRC STROBE	TCCM4
READ LINE MULTIPLEXERS	TCCM6
MM CLK	MR5
CRC READ TIMING	CNR24
SHUTDOWN CIRCUITRY	TCCM5

LOGIC TEST 10: WRP0, PE, NORMAL, ODD

REPEAT OF TEST 7 IN PE MODE.

LIKELY FAULT LOCATIONS: M8901, M8932, M8933

CIRCUITS

PRINT REFERENCES

DATA DISCRIMINATOR	DS2, DS4, DS6
PHASE LOCKED CLOCK	DS3, DS5, DS7
SKEW BUFFER	DS3, DS5, DS7
PE WRITE MAJOR STATES	TCPE3
PE READ MAJOR STATES	TCPE5
WRAP 0 CIRCUIT TO BLOCK RLT RDS	TCPE3
DESKEW BUFFER READ COUNTER	TCPE4

LOGIC TEST 11: CORE DUMP WRITE, WAM2

REPEAT OF TEST 3 EXCEPT BIT FIDDLER OPERATES IN CORE DUMP
MODE!

LIKELY FAULT LOCATION: M8906

LOGIC TEST 12: CORE DUMP READ, WAM3

REPEAT OF TEST 1 EXCEPT BIT FIDDLER OPERATES IN CORE DUMP
MODE!

LIKELY FAULT LOCATION: M8906

LOGIC TEST 13: EVEN PARITY WRITE - WAM1

REPEAT OF TEST 5 EXCEPT EVEN PARITY IS SPECIFIED.

LIKELY FAULT LOCATION: M8933

LOGIC TEST 14: EVEN PARITY READ: WAM0,

REPEAT OF TEST 7 EXCEPT EVEN PARITY IS USED.

LIKELY FAULT LOCATIONS: M8933, M8934

LOGIC TEST 15: READ REVERSE, WAM3 (M8906)

REPEAT OF TEST 2 EXCEPT READ REVERSE COMMAND IS ISSUED.

LIKELY FAULT LOCATIONS: M8908, M8939

LOGIC TEST 16: CRC ERROR CORRECTION

THIS TEST SIMULATES A BAD TRACK ON TAPE RESULTING IN A CRC ERROR &
SUBSEQUENT CORRECTION OF DATA IN THE FAILING TRACK.
THE TEST PROCEEDS THROUGH THE FOLLOWING STEPS:

A:WRITE DATA USING WRAP 0
B:REWRITE DATA WITH DATA BITS IN ONE TRACK ALTERED USING WRAP 4
C:READ REVERSE USING WRAP3
D:REWRITE DATA AS IN STEPB USING WRAP4
AT THIS POINT THE DATA READ BACK HAS BEEN CORRECTED TO MATCH
THE DATA WRITTEN IN STEP A
E:REPEAT STEPS A-D ABOVE FOR EACH TRACK
F:REPEAT STEPS A-E ABOVE FOR ALL 1'S,ALL 0'S &
125125 DATA PATTERNS.

LOGIC TEST 17: CRC ERROR CORRECTION

THIS TEST SIMULATES MULTIPLE FAILING TRACKS & TEST THAT
NO ERROR CORRECTION IS PERFORMED. THE TEST SEQUENCE IS THE
SAME AS TEST 16 STEP A--STEP E. THE DATA PATTERN USED IS
125125.

LOGIC TEST 20: READ REVERSE WAM3 NRZ

REPEAT OF TEST 15 ABOVE (SEE ALSO TEST 2) EXCEPT THE TEST IS
PERFORMED IN NRZ MODE.

1844

x

.LIST BIN,LOC,SEQ

1848
1849
1850
1851
1852
1853
1854
1855
1856
1857
1858
1859
1860
1861
1862
1863
1864
1865
1866
1867
1868
1869
1870
1871
1872
1873
1874
1875
1876
1877
1878
1879
1880
1881
1882

```
.TITLE TM03-TU45 CONTROL LOGIC TEST-PART 11
:CZTUPB0
:25 MAY 78
:J.G. ADAMS/R. J. COLLINS
:REVISED JUN 1977 BY J.G.ADAMS ;++B CHANGED MODULE TYPEOUTS TO
;++B REFLECT TM03 REGISTER SET
.MCALL .SACT11,.$EOP,$CATCH,$SAVE,$RESTORE,$CHAIN,$SCHNMODE
.NLIST MC
.LIST ME
.ENABLE ABS,AMA

:CONSOLE SWITCHES*****
:SW15: 1=HALT ON ERROR
:      0=CONTINUE
:SW14: 1=LOOP ON ERROR
:      0=CONTINUE
:SW13: 1=DO NOT PRINT ERRORS
:      0=PRINT ERRORS
:SW12: 1=HALT AT END OF PASS
:      0=CONTINUOUS CYCLE
:SW11: 1=INHIBIT ITERATIONS
:      0=DO ITERATIONS
:SW10: 1=HALT AT END OF EACH TEST
:      0=CONTINUE
:SW8:  1=NO WRAP DATA CHECK
:      0=DO WRAP DATA CHECK
:SW7:  1=NO WRAP STATUS CHECK
:      0=DO WRAP STATUS CHECK
:SW6:  1=SELECTABLE WRAP DATA PATTERN (IN SINGLE TEST)
:      0=AUTO PATTERNS
:SW0-5: SELECT TEST NUMBER :: 00=ALL TESTS
:IF HARDWARE SWR <15::00> = 177777 OR NOT AVAILABLE USE SOFTWARE SWR
```



```

1931                ;REGISTER EQUIVS*****
1932
1933                R0=%0
1934                R1=%1
1935                R2=%2
1936                R3=%3
1937                R4=%4
1938                R5=%5
1939                SP=%6
1940                PC=%7
1941
1943
1944
(1)                ;ACT11 HOOK *****
(1)                $SVPC=.                ;SAVE CURRENT LOCATION CTR
(1)                .=46
(1) 000046         .WORD SENDAD          ;SET LOCATION 46
(1)                .=52
(1) 000052         .WORD 0                ;SET LOCATION 52 = 0
(1)                .=$SVPC              ;RESTORE LOCATION CTR
(1)
1945                ;TTY INTERRUPT VECTOR*****
1946
1947                .=60
1948 000060         .WORD TTINT          ;TTY INTERRUPT HANDLER ADDRESS
1949 000062         .WORD 340           ;PRIORITY LEVEL 7
1950
1951                ;SOFTWARE SWITCH REGISTER*****
1952                ;USED IF HARDWARE SWR = 177777, OR NOT AVAIL.
1953                .=176
1954 000176         SWREG: .WORD 0
1955
1956
1957                ;START ADDRESS*****
1958                .=200
1959 000200         JMP START           ;PROGRAM START
1960
1961                ;RESTART ADDRESS*****
1962                .=210
1963 000210         JMP ST2
1964
1965                ;TM03 INTERRUPT VECTOR*****
1966
1967                .=224
1968 000224         MTINT                ;TAPE INTERRUPT HANDLER ADDRESS
1969 000226         340
1970

```



```
1972
1973      000510      . = 510
1974      ; MASS BUS REGISTER EQUIVS*****
1975
1976 000510 172440   C1: 172440
1977 000512 172442   WC: 172442
1978 000514 172444   BA: 172444
1979 000516 172446   FC: 172446
1980 000520 172450   CS: 172450
1981 000522 172452   DS: 172452
1982 000524 172454   ER: 172454
1983 000526 172456   AS: 172456
1984 000530 172460   CC: 172460
1985 000532 172462   DB: 172462
1986 000534 172464   MR: 172464
1987 000536 172466   DT: 172466
1988 000540 172470   SN: 172470
1989 000542 172472   TC: 172472
1990
1991      ; ILLEGAL FUNCTION CODES
1992
1993 000544 005405   ILFT: 5405
1994 000546 007415      7415
1995 000550 016423      16423
1996 000552 020437      20437
1997 000554 022443      22443
1998 000556 025447      25447
1999 000560 031455      31455
2000 000562 033465      33465
2001 000564 036473      36473
2002
2003      ; CONSTANTS*****
2004
2005 000566 177776   PSW: 177776      ; PROCESSOR STATUS
2006 000570 177570   SWR: 177570      ; SWITCH REGISTER
2007 000572 177560   TKS: 177560      ; TTY READER STATUS
2008 000574 177562   TKB: 177562      ; TTY READ BUFFER
2009 000576 177564   TPS: 177564      ; TTY PUNCH STATUS
2010 000600 177566   TPB: 177566      ; TTY PUNCH BUFFER
2011 000602 177777   SERNUM: 177777   ; SERIAL NUMBER
2012 000604 000011   DRVTP: 011       ; DRIVE TYPE
2013 000606 000020   ITAMT: 20        ; ITERATION AMOUNT
2014 000610 000224   VECT: 224        ; INTERRUPT VECTOR(RH)
2015 000612 172440   REGS: 172440     ; STARTING REGISTER ADDRESS
```

2017
2018
2019
2020
2021
2022 000614
2023 000614 000000
2024 000616 000000
2025 000620 000000
2026 000622 000000
2027 000624 000000
2028 000626 000000
2029 000630 000000
2030 000632 000000
2031 000634 000000
2032 000636 000000
2033 000640 000000
2034 000642 000000
2035 000644 000000
2036 000646 000000
2037 000650 000000
2038 000652 000000
2039 000654 000000
2040 000656 000000
2041 000660 000000
2042 000662 000000
2043 000664 000000
2044 000666 000000
2045 000670 000000
2046 000672 000000
2047 000674 000000
2048 000676 000000
2049 000700 000000
2050 000702 000000
2051 000704 000000
2052 000706 000000
2053 000710 000000
2054 000712 000000
2055 000714 000000
2056 000716 000000
2057 000720 000000
2058 000722 000000
2059 000724 000000
2060 000726 000000
2061 000730 000000
2062 000732 000000
2063 000734 000000
2064 000736 000000
2065 000740 000000
2066 000742 000000
2067 000744 000000
2068 000746 000000
2069 000750 000000
2070 000752 000000
2071 000754 000000
2072 000756 000000

:FLAGS AND COUNTERS*****
:NOTE ALL FLAGS AND COUNTERS ARE CLEARED ON STARTUP. PUT ANY
:ADDITIONAL FLAGS BETWEEN STFLGS (START OF FLAGS) AND ENDFLG
:(END OF FLAGS)

STFLGS:
TOB: 0
TIB: 0
HDRFL: 0
EMADDR: 0
DRVN: 0
TR00: 0
TR01: 0
TR02: 0
TR03: 0
TR04: 0
TR05: 0
TR06: 0
TR07: 0
TR10: 0
TR11: 0
TR12: 0
TR13: 0
TR14: 0
TR15: 0
NRZOF: 0
SLVN: 0
PFLG: 0
RTRN: 0
ERADD: 0
TEMP1: 0
TEMP2: 0
TEMP3: 0
ITCNT: 0
SAV1: 0
SAV2: 0
SAV3: 0
SCOLP: 0
ITRLP: 0
EXFL: 0
ATAF: 0
SLAF: 0
SSCF: 0
ERRF: 0
ASF: 0
SCF: 0
TREF: 0
PEXFL: 0
STFLG: 0
LTADD: 0
T24FL: 0
ADDFL: 0
WAM: 0
FUN: 0
DATC: 0
WTAD: 0

2073 000760 000000
2074 000762 000000
2075 000764 000000
2076 000766 000000
2077 000770 000000
2078 000772 000000
2079 000774 000000
2080 000776 000000
2081 001000 000000
2082 001002 000000
2083 001004 000000
2084 001006 000000
2085 001010 000000
2086 001012 000000
2087 001014 000000
2088 001016 000000
2089 001020 000000
2090 001022 000000
2091 001024
2092
2093
2094
2095 001024 000000
2096 001026 000000
2097 001030 000000
2098 001032 000000
2099
2100
2101
2102 001034
2103 001034 005162
2104 001036 005202
2105 001040 005206
2106 001042 005214
2107
2108
2109
2110 001044 000005
2111 001046 000005
2112 001050 000012
2113 001052 000012
2114 001054 000000
2115 001056 000017
2116 001060 000017
2117 001062 000017
2118 001064 000017
2119 001066 000000

DATAD: 0
RDAD: 0
W2FLG: 0
DERFL: 0
PREFL: 0
SERFL: 0
CRCNT: 0
UDES: 0
WPGFL: 0
PATRN: 0
STATF: 0
RDRVF: 0
RCDP: 0
STATC: 0
SKAT: 0
PCNTR: 0
DCMKFL: .WORD 0
CRCFLG: .WORD 0
ENDFLG: 0

;PASS COUNTER
;DATA CHECK FLAG 0/1 = CHECK/DO NOT CHECK
;CRC CORRECTION TEST IN PROGRESS

;EXPT WRAP STATUS*****

WCS1: 0
WCS2: 0
WDS: 0
WER: 0

;DATA PATTERN GENERATORS*****

DATBL:
DATA0: DAT1 ;ALL ONE BITS
DATA1: DAT2 ;ALL ZERO BITS
DATA2: DAT3 ;ALTERNATING ONE/ZERO BITS
DATA3: DAT4 ;ALTERNATING PARITY CHARACTERS

;CORE DUMP PATTERNS*****

WCDP2: 5
5
12
12
0
WCDP0: 17
17
17
17
0

2121
2122
2123
2124 001070 000000
2125 001072 000000
2126 001074 002436
2127 001076 002436
2128 001100 002550
2129 001102 002550
2130 001104 002622
2131 001106 002622
2132 001110 002730
2133 001112 002730
2134 001114 003002
2135 001116 003002
2136 001120 003110
2137 001122 003110
2138 001124 003166
2139 001126 003166
2140 001130 003274
2141 001132 003274
2142 001134 003346
2143 001136 003346
2144 001140 003460
2145 001142 003460
2146 001144 003606
2147 001146 003606
2148 001150 003656
2149 001152 003656
2150 001154 003726
2151 001156 003726
2152 001160 004010
2153 001162 004010
2154 001164 004376
2155 001166 004376
2156 001170 004710
2157 001172 004710
2158 001174 002330
2159 001176 000020

:LOGIC TEST ENTRY TABLE*****

TSTTBL: 0
0
LT1
LT1
LT2
LT2
LT3
LT3
LT4
LT4
LT5
LT5
LT6
LT6
LT7
LT7
LT10
LT10
LT11
LT11
LT12
LT12
LT13
LT13
LT14
LT14
LT15
LT15
LT16
LT16
LT17
LT17
LT20
LT20

TADX: .WORD TEND
TLAST: .WORD 20

:CONTAINS # OF TESTS

```

2161 .EVEN
2162 ;PROGRAM START AND HOUSEKEEPING*****
2163
2164 001200 012706 000500 START: MOV #500,SP ;SET STACK POINTER
2165 001204 013746 000004 MOV @#4,-(SP) ;SAVE ERROR TRAP
2166 001210 013746 000006 MOV @#6,-(SP)
2167 001214 012737 001040 000004 MOV #1$,@#4 ;SET TIME OUT TRAP TO GO TO 1$
2168 001222 005037 000006 CLR @#6
2169 001226 022777 177777 177334 CMP #177777,@SWR ;USE SOFTWARE SWITCH,IF SWR - 177777
2170 001234 001402 BEQ 2$ ;OR TIMES OUT
2171 001236 000404 BR 3$ ;OTHERWISE USE HARDWARE SWR
2172 001240 022626 1$: CMP (SP)+,(SP)+ ;RESET STACK
2173 001242 012737 000176 000570 2$: MOV #SWREG,SWR ;SET SWR = TO ADDRESS OF SOFTWARE SWR
2174 001250 012637 000006 3$: MOV (SP)+,@#6 ;RESTORE ERROR TRAP
2175 001254 012637 000004 MOV (SP)+,@#4
2176 001260 005027 CLR (PC)+ ;:CLEAR CHAIN INDICATOR
(1) 001262 000000 CHNFLG: .WORD 0 ;:CHAIN MODE INDICATOR
(1) ;:1/0 = CHAIN/NOT CHAIN MODE
(1) 001264 022737 002374 000042 CMP #SENDAD,@#42 ;:BRANCH IF LOADED VIA ACT11 CHAIN MODE
(1) 001272 001404 BEQ 50$
(1) 001274 005737 000042 TST @#42 ;:BRANCH IF IN DUMP MODE
(1) 001300 001413 BEQ 52$
(1) 001302 000406 BR 51$
(1) 001304 012737 000176 000570 50$: MOV #SWREG,SWR ;:INVOKE SOFTWARE SWR
(1) 001312 012777 100000 177250 MOV #100000,@SWR ;:WITH HALT ON ERROR SET
(1) 001320 005237 001262 51$: INC CHNFLG ;:SET CHNFLG = CHAIN MODE
(1) 001324 000137 001714 JMP TSCD ;:GO TO CHAIN ADDRESS
(1) 001330 52$:
2177 001330 122737 000006 000041 4$: CMPB #6,@#41 ;BRANCH IF NOT LOADED VIA TMDP
2178 001336 001004 BNE 5$
2179 001340 012704 014573 MOV #MSG62,R4 ;ADVISE USER TO REMOVE MEDIA FROM OUT
2180 001344 004737 013054 JSR PC,T1OUT
2181 001350 012704 013776 5$: MOV #MSG1,R4
2182 001354 004737 013054 JSR PC,T1OUT ;PRINT TITLE
2183 001360 112737 000043 013776 MOVB #'#,MSG1 ;DO NOT PRINT TITLE ON RESTART
2184 001366 012704 014467 MOV #MSG44,R4
2185 001372 004737 013054 JSR PC,T1OUT ;REQUEST REGISTER ADDRESS
2186 001376 013703 000612 MOV REGS,R3
2187 001402 004737 013202 JSR PC,OCTP ;PRINT CURRENT ADDRESS
2188 001406 012705 000612 MOV #REGS,R5 ;SET ADDRESS SAVE LOC
2189 001412 012701 000007 MOV #7,R1 ;SET SIZE OF RESPONSE
2190 001416 012702 176400 MOV #176400,R2 ;SET UPPER LIMIT
2191 001422 012703 172300 MOV #172300,R3 ;SET LOWER LIMIT
2192 001426 004737 012514 JSR PC,TTR ;GO GET RESPONSE
2193 001432 012704 014511 MOV #MSG45,R4
2194 001436 004737 013054 JSR PC,T1OUT ;REQUEST VECTOR
2195 001442 013703 000610 MOV VECT,R3
2196 001446 004737 013202 JSR PC,OCTP ;PRINT CURRENT VECTOR
2197 001452 012705 000610 MOV #VECT,R5 ;SET ADDRESS SAVE LOC
2198 001456 012701 000004 MOV #4,R1 ;SET SIZE OF RESPONSE
2199 001462 012702 000224 MOV #224,R2 ;SET UPPER LIMIT
2200 001466 012703 000150 MOV #150,R3 ;SET LOWER LIMIT
2201 001472 004737 012514 JSR PC,TTR ;GO GET RESPONSE
2202 001476 013700 000610 MOV VECT,R0 ;GET VECTOR
2203 001502 012720 012362 MOV #MTINT,(R0)+ ;LOAD INTERRUPT ADDRESS IN VECTOR
2204 001506 012710 000340 MOV #340,(R0) ;LOAD PRIORITY
    
```

2205	001512	013700	000612	MOV	REGS,R0	;GET START OF REGS
2206	001516	012701	000016	MOV	#16,R1	;SET NUMBER OF REGS
2207	001522	012702	000510	MOV	#C1,R2	;GET START OF TABLE
2208	001526	010022		6\$: MOV	R0,(R2)+	;BUILD TABLE
2209	001530	062700	000002	ADD	#2,R0	;BUMP ADDRESS
2210	001534	005301		DEC	R1	;SEE IF DONE
2211	001536	001373		BNE	6\$;IF NOT: BR
2212	001540	012702	000614	MOV	#STFLGS,R2	
2213	001544	012700	000210	MOV	#ENDFLG-STFLGS,R0	;GET # OF FLAGS TO CLEAR
2214	001550	006200		ASR	R0	;FORM COUNT
2215	001552	005022		7\$: CLR	(R2)+	;CLEAR FLAGS + COUNTERS
2216	001554	005300		DEC	R0	
2217	001556	001375		BNE	7\$	
2218	001560	012704	014533	MOV	#MSG57,R4	;REQUEST TM03 DRIVE #
2219	001564	004737	013054	JSR	PC,TTOUT	
2220	001570	013703	000624	MOV	DRVN,R3	;GET CURRENT DRIVE
2221	001574	004737	013202	JSR	PC,OCTP	;AND TYPE IT
2222	001600	012705	000624	MOV	#DRVN,R5	;TTR ROUTINE RETURNS DRIVE TO (R5)
2223	001604	012701	000002	MOV	#2,R1	;LIMIT RESPONSE TO 1 CHARACTER
2224	001610	012702	000007	MOV	#7,R2	;BETWEEN 0 AND 7
2225	001614	012703	000000	MOV	#0,R3	
2226	001620	004737	012514	JSR	PC,TTR	;GET RESPONSE & PUT IN DRVN
2227	001624	012704	014551	MOV	#MSG58,R4	;REQUEST SLAVE #
2228	001630	004737	013054	JSR	PC,TTOUT	
2229	001634	013703	000664	MOV	SLVN,R3	;GET CURRENT SLAVE #
2230	001640	004737	013202	JSR	PC,OCTP	;AND TYPE IT
2231	001644	012705	000664	MOV	#SLVN,R5	;TTR ROUTINE RETURNS REPONSE TO (R5)
2232	001650	012701	000002	MOV	#2,R1	;LIMIT RESPONSE TO 1 CHARACTER
2233	001654	012702	000007	MOV	#7,R2	;BETWEEN 0-7
2234	001660	012703	000000	MOV	#0,R3	
2235	001664	004737	012514	JSR	PC,TTR	;GET RESPONSE & PUT IT IN SLVN
2236						
2237				:START 210		
2238	001670	012706	000500	ST2: MOV	#500,SP	;SET STACK PTR
2239	001674	005037	001006	CLR	RDRVF	;CLEAR READ REVERSE FLAG
2240	001700	005037	001016	CLR	PCNTR	
2241	001704	005037	001022	CLR	CRCFLG	;SET CRC FLAG = CRC NOT IN PROGRESS
2242	001710	004737	013634	JSR	PC,GTSWR	;GET SOFTWARE SWITCHES

```

2244
2245           ;TEST SCHEDULAR*****
2246
2247 001714 052777 000100 176650 TSCD: BIS #100,@TKS ;SET KEYBOARD IE BIT
2248 001722 005037 001000 CLR WPGFL ;CLEAR WRAP PATRN FLAG
2249 001726 005037 000740 CLR STFLG ;CLEAR SINGLE TEST FLAG
2250 001732 017700 176632 MOV @SWR,RO
2251 001736 042700 177700 BIC #177700,RO ;BRANCH IF SINGLF TEST SELECTED
2252 001742 001154 BNE STSCD ;GO SELECT SINGLE TEST
2253 001744 005737 001262 TST CHNFLG ;;BRANCH IF NOT IN CHAIN MODE
(1) 001750 001511 BEQ TSCDA
(1) 001752 012737 177777 000624 MOV #-1,DRVN ;;INITIALIZE DRIVE #
(1) 001760 012737 177777 000664 NXTDRV: MOV #-1,SLVN ;;INITIALIZE SLAVE #
(1) 001766 012777 000040 176524 1$: MOV #40,@CS ;;INIT CONTROLLER
(1) 001774 005237 000624 INC DRVN ;;STEP DRIVE #
(1) 002000 022737 00C010 000624 CMP #10,DRVN ;;EXIT IF ALL DRIVES TESTED
(1) 002006 001553 BEQ $DONE ;:FOR AVAILABILITY
(1) 00201C 013777 000624 176502 MOV DRVN,@CS ;:LOAD DRIVE #
(1) 002016 005777 176466 TST @C1 ;:ACCESS DRIVE
(1) 002022 032777 010000 176470 BIT #10000,@CS ;BRANCH IF DRIVE NON EXISTANT
(1) 002030 001356 BNE 1$ ;:(NED = 1)
(1) 002032 005237 000664 NXTSLV: INC SLVN ;:STEP SLAVE # AND BRANCH
(1) 002036 001011 BNE 1$ ;:IF NOT SLAVE 0
(1) 002040 005737 000624 TST DRVN ;:BRANCH IF NOT DRIVE # 0
(1) 002044 001006 BNE 1$
(1) 002046 122737 000006 000041 CMPB #6,@#41 ;:BRANCH IF NOT TMDP
(1) 002054 001002 BNE 1$
(1) 002056 005237 000664 INC SLVN ;:STEP TO SLAVE # 1
(1) 002062 022737 000010 000664 1$: CMP #10,SLVN ;:BRANCH IF ALL SLAVES TESTED
(1) 002070 001733 BEQ NXTDRV ;:FOR AVAILABILITY
(1) 002072 013777 000664 176442 MOV SLVN,@TC ;:LOAD SLAVE UNIT #
(1) 002100 032777 002000 176430 BIT #2000,@DT ;:BRANCH IF SLAVE NOT
(1) 002106 001751 BEQ NXTSLV ;:PRESENT (SPR = 0)
2254 002110 032777 010000 176404 BIT #10000,@DS ; TEST FOR MOL
2255 002116 001026 BNE TSCDA ;BRANCH IF MOL
2256 002120 012704 014667 MOV #MSG64,R4 ;ELSE PRINT NOT ON LINE
2257 002124 004737 013054 JSR PC,TTOUT ;PRINT MESSAGE
2258 002130 013703 000624 MOV DRVN,R3 ;DRIVE NUMBER
2259 002134 004737 013202 JSR PC,OCTP ;PRINT NUMBER
2260 002140 012704 014701 MOV #MSG65,R4 ;ADDRESS OF MESSAGE
2261 002144 004737 013054 JSR PC,TTOUT ;PRINT MESSAGE
2262 002150 013703 000664 MOV SLVN,R3 ;SLAVE NUMBER
2263 002154 004737 013202 JSR PC,OCTP ;PRINT NUMBER
2264 002160 012704 014711 MOV #MSG66,R4 ;ADDR OF MESSAGE
2265 002164 004737 013054 JSR PC,TTOUT ;PRINT IT
2266 002170 000137 002032 JMP NXTSLV
2267 002174 012737 001070 000742 TSCDA: MOV #TSTTBL,LTADD
2268 002202 062737 000004 000742 TSCD0: ADD #4,LTADD
2269 002210 013737 000742 000714 TSCD1: MOV LTADD,ITRLP
2270 002216 062737 000002 000714 ADD #2,ITRLP ;SET ITERATION ADDRESS
2271 002224 005037 000620 CLR HDRFL ;CLEAR PRINT HEADER FLAG
2272 002230 017700 176506 MOV @LTADD,RO ;SET POINTER TO TEST
2273 002234 000110 JMP (RO) ;GO TO TEST
2274 002236 032777 002000 176324 TSCD2: BIT #2000,@SWR ;SEE IF HALT ON TEST
2275 002244 001403 BEQ TSCD3 ;IF NOT: BR
2276 002246 000000 HALT
    
```

```

2277 002250 005037 001000          CLR      WPGFL      ;CLEAR WRAP DATA GENERATOR FLAG
2278 002254 005737 000740          TSCD3:  TST      STFLG      ;SE IF SINGLE TEST
2279 002260 001750          BEQ      TSCD0      ;IF NOT: BR
2280 002262 017700 176302          MOV      @SWR,RO
2281 002266 042700 177700          BIC      #177700,RO ;MASK TEST NUMBER
2282 002272 001610          BEQ      TSCD      ;IF SO: BR
2283 002274 012737 000001 000740 STSCD:  MOV      #1,STFLG    ;SET SINGLE TEST FLAG
2284 002302 023700 001176          CMP      TLAST,RO  ;SEE IF EXCEEDED TESTS
2285 002306 002410          BLT     TEND      ;IF SO: BR
2286 002310 006300          ASL     RO
2287 002312 006100          ROL     RO        ;SET TABLE MODIFIER
2288 002314 012737 001070 000742          MOV      #TSTTBL,LTADD
2289 002322 060037 000742          ADD     RO,LTADD  ;SET TEST POINTER
2290 002326 000730          BR     TSCD1
2291 002330 005737 001262          TEND:   TST      CHNFLG   ;BRANCH IF IN CHAIN MODE
2292 002334 001236          BNE     NXTSLV
2293 002336 012704 014450          $DONE:  MOV      #MSG41,R4
2294 002342 004737 013054          JSR     PC,T1OUT  ;PRINT END OF PASS
2295 002346 013703 001016          MOV     PCNTR,R3
2296 002352 004737 013202          JSR     PC,OC1P   ;PRINT PASS NUMBER
2297 002356 005000          CLR     RO
2298 002360 005300          1$:    DEC     RO    ;DELAY WAITING FOR
2299 002362 001376          BNE     1$       ;TTY TO FINISH
2300 002364 013700 000042          MOV     @#42,RO  ;GET ACT11 RETURN ADDRESS
2300 002370 001405          BEQ     HERE     ;BRANCH IF NOT ACT11
2300 002372 000005          RESET
2300 002374 004710          $ENDAD: JSR     PC,(RO)
2300 002376 000240          NOP
2300 002400 000240          NOP
2300 002402 000240          NOP
2300 002404 000240          HERE:  NOP
2301 002406 005737 001262          TST     CHNFLG   ;BRANCH IF IN CHAIN MODE
2302 002412 001005          BNE     TENDX
2303 002414 032777 010000 176146          BIT     #10000,@SWR ;SEE IF HALT ON PASS
2304 002422 001001          BNE     TENDX    ;IF NOT: BR
2305 002424 000000          HALT
2306 002426 005237 001016          TENDX:  INC     PCNTR   ;BUMP PASS COUNTER
2307 002432 000137 001714          JMP     TSCD     ;RESTART
2308
    
```



```

2310          :THESE TESTS CHECK DATA FORMATTING
2311          :AND TRANSFER THROUGH THE TM03 WRAP AROUND MODFS
2312
2313          :LOGIC TEST 1: WRAP 3, NRZ, NORMAL ODD *****
2314
2315 002436 012737 004270 001024 LT1:  MOV    #4270,WCS1      ;SET EXPT CS1
2316 002444 012737 000100 001026      MOV    #100,WCS2      ;SET EXPT CS2
2317 002452 012737 010600 001030      MOV    #10600,WDS     ;SET EXPT DS
2318 002460 012737 000000 001032      MOV    #0,WER         ;SET EXPT ER
2319 002466 012737 014726 000622      MOV    #MSLT1,EMADDR  ;SET HEADER
2320 002474 012737 001700 000776      MOV    #1700,UDES     ;SET NRZ,NORMAL, ODD
2321 002502 005037 001002          LT1A: CLR    PATRN       ;POINT TO PATTERN 0
2322 002506 012737 002514 000712      MOV    #LT1B,SCOLP    ;SET SCOPE ADDRESS
2323 002514 004737 005342          LT1B: JSR    PC,WAM3    ;GO DO WRAP 3
2324 002520 005237 001002          INC    PATRN          ;BUMP PATTERN POINTER
2325 002524 032737 000004 001002      BIT    #4,PATRN       ;SEE IF DONE
2326 002532 001770          BEQ    LT1B           ;IF NOT: BR
2327 002534 004737 011136          JSR    PC,ITER        ;GO SEE IF ITERATIONS
2328 002540 005037 001006          CLR    RDRVF          ;CLEAR READ REVERSE FLAG
2329 002544 000137 002236          JMP    TSCD2          ;RETURN TO SCHEDULAR
2330
2331          :LOGIC TEST 2: WRAP 3, PE, NORMAL, ODD*****
2332
2333 002550 000240          LT2:  NOP
2334 002552 012737 004270 001024 LT2A:  MOV    #4270,WCS1      ;SET EXPT CS1
2335 002560 012737 000100 001026      MOV    #100,WCS2      ;SET EXPT CS2
2336 002566 012737 010640 001030      MOV    #10640,WDS     ;SET EXPT DS
2337 002574 012737 000000 001032      MOV    #0,WER         ;SET EXPT WER
2338 002602 012737 014774 000622      MOV    #MSLT2,EMADDR  ;SET HEADER
2339 002610 012737 002300 000776      MOV    #2300,UDES     ;SET PE, NORMAL, ODD
2340 002616 000137 002502          JMP    LT1A           ;EXECUTE TEST SEQUENCE
2341
2342          :LOGIC TEST 3: WRAP 2, NRZ, NORMAL, ODD*****
2343
2344 002622 012737 004260 001024 LT3:  MOV    #4260,WCS1      ;SET EXPT CS1
2345 002630 012737 000100 001026      MOV    #100,WCS2      ;SET EXPT CS2
2346 002636 012737 010600 001030      MOV    #10600,WDS     ;SET EXPT DS
2347 002644 012737 000000 001032      MOV    #0,WER         ;SET EXPT WER
2348 002652 012737 015041 000622      MOV    #MSLT3,EMADDR  ;SET HEADER
2349 002660 012737 001700 000776      MOV    #1700,UDES     ;SET TO NRZ,NORMAL, ODD
2350 002666 005037 001002          LT3A: CLR    PATRN       ;POINT TO PATTERN 0
2351 002672 012737 002700 000712      MOV    #LT3B,SCOLP    ;SET SCOPE ADDRESS
2352 002700 004737 005276          LT3B: JSR    PC,WAM2    ;GO DO WRAP 2
2353 002704 005237 001002          INC    PATRN          ;BUMP POINTER
2354 002710 032737 000004 001002      BIT    #4,PATRN       ;SEE IF DONE
2355 002716 001770          BEQ    LT3B           ;IF NOT: BR
2356 002720 004737 012136          JSR    PC,ITER        ;GO SEE IF ITERATIONS
2357 002724 000137 002236          JMP    TSCD2          ;RETURN TO SCHEDULAR

```

```

2359
2360           ;LOGIC TEST 4: WRAP 2, PE, NORMAL, ODD*****
2361
2362 002730 000240          LT4:  NOP
2363 002732 012737 004260 001024  LT4A: MOV #4260,WCS1 ;SET EXPT CS1
2364 002740 012737 000100 001026  MOV #100,WCS2 ;SET EXPT CS2
2365 002746 012737 010640 001030  MOV #10640,WDS ;SET EXPT DS
2366 002754 012737 000000 001032  MOV #0,WER ;SET EXPT WER
2367 002762 012737 015107 000622  MOV #MSLT4,EMADDR ;SET HEADER
2368 002770 012737 002300 000776  MOV #2300,UDES ;SET PE, NORMAL, ODD
2369 002776 000137 002666          JMP LT3A ;GO EXECUTE TEST SEQUENCES
2370
2371           ;LOGIC TEST 5: WRAP 1, NRZ, NORMAL, ODD*****
2372
2373 003002 012737 004260 001024  LT5:  MOV #4260,WCS1 ;SET EXPT CS1
2374 003010 012737 000100 001026  MOV #100,WCS2 ;SET EXPT CS2
2375 003016 012737 010600 001030  MOV #10600,WDS ;SET EXPT DS
2376 003024 012737 000000 001032  MOV #0,WER ;SET EXPT WER
2377 003032 012737 015154 000622  MOV #MSLT5,EMADDR ;SET HEADER
2378 003040 012737 001700 000776  MOV #1700,UDES ;SET NRZ, NORMAL, ODD
2379 003046 005037 001002          LT5A: CLR PATRN ;POINT TO PATTERN ZERO
2380 003052 012737 003060 000712  MOV #LT5B,SCOLP ;SET SCOPE ADDRESS
2381 003060 004737 005266          LT5B: JSR PC,WAM1 ;GO DO WRAP 1
2382 003064 005237 001002          INC PATRN ;BUMP POINTER
2383 003070 032737 000004 001002  BIT #4,PATRN ;SEE IF DONE
2384 003076 001770          BEQ LT5B ;IF NOT: BR
2385 003100 004737 012136          JSR PC,ITER ;GO SEE IF ITERATIONS
2386 003104 000137 002236          JMP TSCD2 ;RETURN TO SCHEDULAR
2387
2388           ;LOGIC TEST 6: WRAP 1, PE, NORMAL, ODD*****
2389
2390 003110 000240          LT6:  NOP
2391 003112 004737 011634          LT6A: JSR PC,PPGEN ;GO GENERATE PRE/POSTAMBLE
2392 003116 012737 004260 001024  MOV #4260,WCS1 ;SET EXPT CS1
2393 003124 012737 000100 001026  MOV #100,WCS2 ;SET EXPT CS2
2394 003132 012737 010640 001030  MOV #10640,WDS ;SET EXPT DS
2395 003140 012737 000000 001032  MOV #0,WER ;SET EXPT WER
2396 003146 012737 015222 000622  MOV #MSLT6,EMADDR ;SET HEADER
2397 003154 012737 002300 000776  MOV #2300,UDES ;SET PE, NORMAL, ODD
2398 003162 000137 003046          JMP LT5A ;GO EXECUTE TEST SEQUENCE
  
```

```
2400
2401 ;LOGIC TEST 7: WRAP 0, NRZ,NORMAL, ODD*****
2402
2403 003166 012737 144260 001024 LT7: MOV #144260,WCS1 ;SET EXPT CS1
2404 003174 012737 000100 001026 MOV #100,WCS2 ;SET EXPT CS2
2405 003202 012737 150600 001030 MOV #150600,WDS ;SET EXPT DS
2406 003210 012737 000200 001032 MOV #200,WER ;SET EXPT ER
2407 003216 012737 015267 000622 MOV #MSLT7,EMADDR ;SET HEADER
2408 003224 012737 001700 000776 MOV #1700,UDES ;SET NRZ, NORMAL, ODD
2409 003232 005037 001002 LT7A: CLR PATRN ;POINT TO PATTERN 0
2410 003236 012737 003244 000712 MOV #LT7B,SCOLP ;SET SCOPE ADDRESS
2411 003244 004737 005222 LT7B: JSR PC,WAMO ;GO DO WRAP 0
2412 003250 005237 001002 INC PATRN ;BUMP POINTER
2413 003254 032737 000004 001002 BIT #4,PATRN ;SEE IF DONE
2414 003262 001770 BEQ LT7B ;IF NOT: BR
2415 003264 004737 012136 JSR PC,ITER ;GO SEE IF ITERATIONS
2416 003270 000137 002236 JMP TSCD2 ;RETURN TO SCHEDULAR
2417
2418 ;LOGIC TEST 10: WRAP 0, PE, NORMAL, ODD*****
2419
2420 003274 000240 LT10: NOP
2421 003276 012737 004260 001024 LT10A: MOV #4260,WCS1 ;SET EXPT CS1
2422 003304 012737 000100 001026 MOV #100,WCS2 ;SET EXPT CS2
2423 003312 012737 010640 001030 MOV #10640,WDS ;SET EXPT DS
2424 003320 012737 000000 001032 MOV #0,WER ;SET EXPT ER
2425 003326 012737 015335 000622 MOV #MSLT10,EMADDR ;SET HEADER
2426 003334 012737 002300 000776 MOV #2300,UDES ;SET PE, NORMAL, ODD
2427 003342 000137 003232 JMP LT7A ;GO EXECUTE TEST SEQUENCE
```

```

2429                ;LOGIC TEST 11: CORE DUMP WRITE, WAM2*****
2430
2431 003346 012737 004260 001024 LT11:  MOV    #4260,WCS1    ;SET EXPT CS1
2432 003354 012737 000100 001026      MOV    #100,WCS2      ;SET EXPT CS2
2433 003367 012737 010600 001030      MOV    #10600,WDS    ;SET EXPT DS
2434 003370 012737 000000 001032      MOV    #0,WER        ;SET EXPT ER
2435 003376 012737 015403 000622      MOV    #MSLT11,EMADDR ;SET HEADER
2436 003404 012737 001720 000776      MOV    #1720,UDES    ;SET NRZ, CORE DUMP, ODD
2437 003412 005037 001002                CLR    PATRN         ;POINT TO PATTERN 0
2438 003416 012737 003424 000712      MOV    #LT11A,SCOLP  ;SET SCOPE ADDRESS
2439 003424 004737 005276                JSR    PC,WAM2       ;GO DO WAM 2
2440 003430 022737 000002 001002 LT11A: CMP    #2,PATRN     ;SEE IF DONE
2441 003436 001404                BEQ    LT11X        ;IF SO: BR
2442 003440 012737 000002 001002      MOV    #2,PATRN     ;SELECT PATTERN 2
2443 003446 000766                BR     LT11A        ;CONTINUE
2444 003450 004737 012136                JSR    PC,ITER      ;GO SEE IF ITERATIONS
2445 003454 000137 002236                JMP    TSCD2        ;RETURN TO SCHEDULES
2446
2447                ;LOGIC TEST 12: CORE DUMP READ, WAM 3*****
2448
2449 003460 012737 004270 001024 LT12:  MOV    #4270,WCS1    ;SET EXPT CS1
2450 003466 012737 000100 001026      MOV    #100,WCS2      ;SET EXPT CS2
2451 003474 012737 010600 001030      MOV    #10600,WDS    ;SET EXPT DS
2452 003502 012737 000000 001032      MOV    #0,WER        ;SET EXPT ER
2453 003510 012737 015454 000622      MOV    #MSLT12,EMADDR ;SET HEADER
2454 003516 012737 001720 000776      MOV    #1720,UDES    ;SELECT NRZ, CORE DUMP, ODD
2455 003524 005037 001002                CLR    PATRN         ;SELECT PATTERN 0
2456 003530 012737 003544 000712      MOV    #LT12A,SCOLP  ;SET SCOPE ADDRESS
2457 003536 012737 001056 001010      MOV    #WCDP0,RCDP   ;POINT TO PATTERN 0
2458 003544 004737 005342                JSR    PC,WAM3       ;GO DO WAM3
2459 003550 022737 000002 001002 LT12A: CMP    #2,PATRN     ;SEE IF DONE
2460 003556 001407                BEQ    LT12X        ;IF SO: BR
2461 003560 012737 000002 001002      MOV    #2,PATRN     ;SELECT PATTERN 2
2462 003566 012737 001044 001010      MOV    #WCDP2,RCDP   ;POINT TO PATTERN 2
2463 003574 000763                BR     LT12A        ;CONTINUE
2464 003576 004737 012136                JSR    PC,ITER      ;GO SEE IF ITERATION
2465 003602 000137 002236                JMP    TSCD2        ;RETURN TO SCHEDULE

```

```
2467
2468
2469
2470 003606 012737 004260 001024 LT13: MOV #4260,WCS1 ;SET EXPT CS1
2471 003614 012737 000100 001026 MOV #100,WCS2 ;SET EXPT CS2
2472 003622 012737 010600 001030 MOV #10600,WDS ;SET EXPT DS
2473 003630 012737 000000 001032 MOV #0,WER ;SET EXPT ER
2474 003636 012737 015524 000622 MOV #MSLT13,EMADDR ;SET HEADER
2475 003644 012737 001710 000776 MOV #1710,UDES ;SET NRZ, NORMAL, EVEN
2476 003652 000137 003046 JMP LT5A ;GO EXECUTE WAM 1
2477
2478 ;LOGIC TEST 14: EVEN PARITY READ: WAM 0(MB933 MB934)*****
2479
2480 003656 012737 144260 001024 LT14: MOV #144260,WCS1 ;SET EXPT CS1
2481 003664 012737 000100 001026 MOV #100,WCS2 ;SET EXPT CS2
2482 003672 012737 150600 001030 MOV #150600,WDS ;SET EXPT DS
2483 003700 012737 000200 001032 MOV #200,WER ;SET EXPT ER
2484 003706 012737 015605 000622 MOV #MSLT14,EMADDR ;SET HEADER
2485 003714 012737 001710 000776 MOV #1710,UDES ;SET NRZ, NORMAL, EVEN
2486 003722 000137 003232 JMP LT7A ;GO DO WAM 0
2487
2488 ;LOGIC TEST 15: READ REVERSE: WAM 3(MB906)*****
2489
2490 003726 012737 004276 001024 LT15: MOV #4276,WCS1 ;SET EXPT CS1
2491 003734 012737 000100 001026 MOV #100,WCS2 ;SET EXPT CS2
2492 003742 012737 010640 001030 MOV #10640,WDS ;SET EXPT DS
2493 003750 012737 000000 001032 MOV #0,WER ;SET EXPT ER
2494 003756 012737 015664 000622 MOV #MSLT15,EMADDR ;SET HEADER
2495 003764 012737 002300 000776 MOV #2300,UDES ;SELECT PE,NORMAL,ODD
2496 003772 000240 NOP
2497 003774 000240 NOP
2498 003776 012737 000001 001006 MOV #1,RDRVF ;SET READ REVERSE FLAG
2499 004004 000137 002502 JMP LT1A ;GO DO WAM 3, REVERSE
2500
```

```

2502
2503 ;LOGIC TEST 16: CRC CORRECTION-SINGLE TRACK,EVERY FRAME
2504 ;THIS IS A TEST OF THE CRC CORRECTION LOGIC. THE TEST WRITES
2505 ;A KNOWN PATTERN (ALL 1'S , ALL 0'S & 125252) WITH A DATA BIT
2506 ;ALTERED IN EACH OF THE DATA TRACKS. THIS TEST INSURES THAT A
2507 ;CRC CORRECTABLE ERROR IS CORRECTED.
2508 ;THE TEST PROCEEDS AS FOLLOWS:
2509
2510 ; STEP A WRITE A KNOWN PATTERN USING WRAP AROUND MODE 0
2511 ;
2512 ; STEP B REWRITE THE PATTERN ABOVE WITH DATA BIT(S) MODIFIED
2513 ; IN TRACKS SPECIFIED BY CRCPAT USING WRAP AROUND MODE 4
2514 ; THIS WILL GENERATE A CRC ERROR
2515 ;
2516 ; STEP C EXECUTE A READ REVERSE USING WRAP AROUND MODE 3
2517 ;
2518 ; STEP D REPEAT STEP B ABOVE. UPON COMPLETION THE DATA READ
2519 ; BACK WILL MATCH THE DATA WRITTEN IN STEP A.
2520
2521
2522 004010 005037 001002 LT16: CLR PATRN ;SELECT PATTERN # 0 (ALL 1'S)
2523 004014 012737 000401 004366 MOV #401,CRCPAT ;SELECT BITS TO BE ALTERED (TRACK 1)
2524 004022 012737 015731 000622 MOV #MSLT16,EMADDR ;SET ERROR MESSAGE HEADER
2525 004030 012737 004036 000712 MOV #LT16A,SCOLP ;SET SCOPE LOOP
2526
2527 004036 012737 144260 001024 LT16A: MOV #144260,WCS1 ;SET EXPECTED VALUES UPON COMPLETION
2528 004044 012737 000100 001026 MOV #100,WCS2
2529 004052 012737 150600 001030 MOV #150600,WDS
2530 004060 012737 000200 001032 MOV #200,WER
2531 004066 012737 001700 000776 MOV #1700,UDES ;SET UNIT DESCRIPTION-NRZ,800BPI,ODD
2532 ;PARITY & PDP11 NORMAL MODE
2533 004074 005037 001022 CLR CRCFLG ;CLEAR CRC CORRECTION FLAG
2534 004100 004737 005222 JSR PC,WAM0 ;DO A WRAP 0 --- STEP A
2535 004104 012737 000001 001022 MOV #1,CRCFLG ;SET CRC ERROR CORRECTION IN PROGRESS
2536 004112 013737 017474 004370 MOV WBUFF,CRCDAT ;GET DATA WRITTEN BY WRAP 0
2537 ;XOR CRCPAT WITH CRCDAT
2538 004120 013737 004370 004372 MOV CRCDAT,XORDAT ;GET DATA TO BE MODIFIED
2539 004126 013737 004366 004374 MOV CRCPAT,XORPAT ;GET MODIFIER
2540 004134 043737 004366 004372 BIC CRCPAT,XORDAT ;CLEAR SET BITS IN DATA TO BE MODIFIED
2541 004142 043737 004370 004374 BIC CRCDAT,XORPAT ;CLEAR SETTING BITS
2542 004150 053737 004374 004372 BIS XORPAT,XORDAT ;SET CLEAR BITS IN DATA TO BE MODIFIED
2543 004156 013737 004372 004370 MOV XORDAT,CRCDAT ;RESTORE MODIFIED DATA
2544
2545 004164 012737 144260 001024 MOV #144260,WCS1 ;SET EXPECTED VALUES UPON COMPLETION
2546 004172 012737 000110 001026 MOV #110,WCS2 ;OF WRAP 4
2547 004200 012737 150600 001030 MOV #150600,WDS
2548 004206 012737 100300 001032 MOV #100300,WER
2549 004214 004737 005450 JSR PC,WAM4 ;DO A WRAP 4 --- STEP B
2550 004220 000240 NOP
2551 004222 012737 000001 001006 MOV #1,RDRVF ;SET TO READ REVERSE
2552 004230 012737 144276 001024 MOV #144276,WCS1 ;SET EXPECTED VALUES UPON COMPLETION
2553 004236 012737 000110 001026 MOV #110,WCS2
2554 004244 012737 150600 001030 MOV #150600,WDS
2555 004252 012737 001000 001032 MOV #1000,WER
2556 004260 004737 005342 JSR PC,WAM3 ;DO A WRAP 3 --- STEP C
2557 004264 000240 NOP
  
```

2558	004266	012737	004260	001024	MOV	#4260,WCS1	
2559	004274	012737	000110	001026	MOV	#110,WCS2	
2560	004302	012737	010600	001030	MOV	#10600,WDS	
2561	004310	012737	000000	001032	MOV	#0,WER	
2562	004316	005037	001022		CLR	CRCFLG	;CLEAR CRC CORRECTION IN PROGRESS FLAG
2563	004322	004737	005450		JSR	PC,WAM4	;GO TO WRAP 4 --- STEP D
2564							
2565	004326	006337	004366		ASL	CRCPAT	;SELECT NEXT TRACK TO BE ALTERED
2566	004332	103241			BCC	LT16A	;CONTINUE FOR ALL TRACKS
2567	004334	012737	000401	004366	MOV	#401,CRCPAT	;RESET BITS TO TRACK 1
2568	004342	005237	001002		INC	PATRN	;SELECT NEXT PATTERN
2569	004346	022737	000003	001002	CMP	#3,PATRN	;BRANCH IF NOT DONE
2570	004354	001230			BNE	LT16A	
2571	004356	004737	012136		JSR	PC,ITER	;ITERATION LOOP
2572	004362	000137	002236		JMP	TSCD2	;RETURN TO SCHEDULER
2573							
2574							
2575	004366	000000			CRCPAT: .WORD	0	;CONTAINS BITS TO BE ALTERED
2576	004370	000000			CRCDAT: .WORD	0	;CONTAINS DATA TO BE WRITTEN BY WRAP4
2577	004372	000000			XORDAT: .WORD	0	;TEMPRARY STORAGE FOR XOR
2578	004374	000000			XORPAT: .WORD	0	;TEMPOARY STORAGE FOR XOR
2579							

```

2581
2582
2583 ;LOGIC TEST 17: CRC CORRECTION - MULTIPLE BAD TRACKS
2584 ;THIS TEST CHECKS THAT CRC ERROR CORRECTION IS NOT PERFORMED WHEN
2585 ;MULTIPLE BAD TRACKS ARE DETECTED.
2586
2587 004376 012737 000002 001002 LT17: MOV #2,PATRN ;SELECT PATTERN #2 (125125)
2588 004404 012737 001001 004366 MOV #1001,CRCPAT ;SELECT 2 BAD TRACKS
2589 004412 012737 016021 000622 MOV #MSLT17,EMADDR ;SET ERROR MESSAGE HEADER
2590 004420 012737 004426 000712 MOV #LT17A,SCOLP ;SET SCOPE LOOP ADDRESS
2591 004426 012737 144260 001024 LT17A: MOV #144260,WCS1 ;SET EXPECTED VALUES ON COMPLETION
2592 004434 012737 000100 001026 MOV #100,WCS2 ;OF WRAP 0 BELOW
2593 004442 012737 150600 001030 MOV #150600,WDS
2594 004450 012737 000200 001032 MOV #200,WER
2595 004456 012737 001700 000776 MOV #1700,UDES ;SET UNIT DESCRIPTION
2596 004464 005037 001022 CLR CRCFLG ;SET CRC CORRECTION NOT IN PROGRESS
2597 004470 004737 005222 JSR PC,WAM0 ;DO A WRAP 0 --- STEP A
2598 004474 000240 NOP
2599 004476 012737 000002 001022 MOV #2,CRCFLG ;SET CRC CORRECTION IN PROGRESS
2600 004504 013737 017474 004370 MOV WBUF,CRCDAT ;GET DATA TO BE WRITTEN
2601 004512 043737 004366 004370 BIC CRCPAT,CRCDAT ;MODIFY DATA TO BE WRITTEN
2602 004520 012737 144260 001024 MOV #144260,WCS1 ;SET EXPECTED VALUES ON COMPLETION
2603 004526 012737 000110 001026 MOV #110,WCS2 ;OF WRAP 4 BELOW
2604 004534 012737 150600 001030 MOV #150600,WDS
2605 004542 012737 100300 001032 MOV #100300,WER
2606 004550 004737 005450 JSR PC,WAM4 ;DO A WRAP 4 --- STEP B
2607 004554 000240 NOP
2608 004556 012737 000001 001006 MOV #1,RDRVF ;SET READ REVERSE FLAG
2609 004564 012737 144276 001024 MOV #144276,WCS1 ;SET EXPECTED VALUES ON COMPLETION
2610 004572 012737 000110 001026 MOV #110,WCS2 ;OF WRAP 3 BELOW
2611 004600 012737 150600 001030 MOV #150600,WDS
2612 004606 012737 001000 001032 MOV #1000,WER
2613 004614 004737 005342 JSR PC,WAM3 ;DO A WRAP 3 --- STEP C
2614 004620 000240 NOP
2615 004622 012737 144260 001024 MOV #144260,WCS1 ;SET EXPECTED VALUES ON COMPLETION
2616 004630 012737 000110 001026 MOV #110,WCS2 ;OF WRAP 4 BELOW
2617 004636 012737 150600 001030 MOV #150600,WDS
2618 004644 012737 100100 001032 MOV #100100,WER
2619 004652 005037 001022 CLR CRCFLG ;CLEAR CRC IN PROGRESS FLAG
2620 004656 013701 004370 MOV CRCDAT,R1 ;GET DATA THAT WAS WRITTEN IN STEP B
2621 004662 012703 017474 MOV #WBUF,R3 ;SET START OF WRITE BUFFER
2622 004666 004737 005166 JSR PC,DAT1A ;GO SET WRITE BUFFER
2623 004672 004737 005450 JSR PC,WAM4 ;GO DO A WRAP 4 --- STEP D
2624 004676 000240 NOP
2625 004700 004737 012136 JSR PC,ITER ;ITERATE TEST
2626 004704 000137 002236 JMP TSCD2 ;RETURN TO SCHEDULER

```



```
2628  
2629 ;LOGIC TEST 20: READ REVERSE,NRZ,W2AP 3  
2630 ;THIS TEST TESTS THAT A CRC ERROR OCCURS AFTER A READ REVERSE USING  
2631 ;WRAP AROUND MODE 3 IN NRZ MODE  
2632  
2633 004710 005037 001002 LT20: CLR PATRN ;SET PATTERN # 0 (ALL 1'S)  
2634 004714 012737 144276 001024 MOV #144276,WCS1 ;SET EXPECTED VALUES ON COMPLETION  
2635 004722 012737 000100 001026 MOV #100,WCS2  
2636 004730 012737 150600 001030 MOV #150600,WDS  
2637 004736 012737 100000 001032 MOV #100000,WER  
2638 004744 012737 016105 000622 MOV #MSLT20,EMADDR ;SET ERROR MESSAGE ADDRESS  
2639 004752 012737 001700 000776 MOV #1700,UDES ;SET UNIT DESCRIPTION  
2640 004760 012737 004766 000712 MOV #LT20A,SCOLP ;SET SCOPE LOOP ADDRESS  
2641 004766 012737 000001 001006 LT20A: MOV #1,RDRVF ;SET READ REVERSE FLAG  
2642 004774 012737 000001 001020 MOV #1,DCHKFL ;SET DATA CHECK FLAG TO NOT CHECK DATA  
2643 005002 004737 005342 JSR PC,WAM3  
2644 005006 005037 001006 CLR RDRVF ;CLEAR READ REVERSE FLAG  
2645 005012 005037 001020 CLR DCHKFL ;CLEAR DATA CHECK FLAG  
2646 005016 004737 012136 JSR PC,ITER  
2647 005022 000137 002236 JMP TSCD2 ;RETURN TO SCHEDULE  
2648
```

```

2650
2651
2652
2653
2654
2655
2656
2657
2658
2659
2660
2661
2662
2663 005026 005737 000740
2664 005032 001434
2665 005034 032777 000100 173526
2666 005042 001430
2667 005044 012704 016614
2668 005050 004737 013054
2669 005054 013703 001002
2670 005060 004737 013202
2671 005064 012705 001002
2672 005070 012701 000002
2673 005074 012702 000003
2674 005100 012703 006000
2675 005104 004737 012514
2676 005110 112737 000001 001001
2677 005116 113737 001002 001000
2678 005124 012703 017474
2679 005130 013701 001002
2680 005134 006301
2681 005136 004771 001034
2682 005142 012702 000202
2683 005146 012701 020106
2684 005152 005021
2685 005154 005302
2686 005156 001375
2687 005160 000207
2688
2689
2690
2691 005162 012701 177777
2692 005166 012702 000202
2693 005172 010123
2694 005174 005302
2695 005176 001375
2696 005200 000207
2697
2698
2699
2700 005202 005001
2701 005204 000770
2702
2703
2704
2705 005206 012701 125125

```

```

:*****
:DATA SETUP ROUTINE:
:
:THIS ROUTINE IS USED TO GENERATE THE DATA PATTERNS
:THE PATTERN TO BE WRITTEN IS SPECIFIED BY:
:PATRN =0      ALL 1'S
:       =1      ALL 0'S
:       =2      ALTERNATE 1'S & 0'S (125125)
:       =3      ALTERNATING PARITY (177377)
:*****
DSUP:  TST      STFLG      ;SEE IF SINGLE TEST
      BEQ      DSO        ;IF NOT: BR
      BIT      #100,@SWR  ;SEE IF SELECT PATTERN
      BEQ      DSO        ;IF NOT: BR
      MOV      #WMSG3,R4
      JSR      PC,TOUT    ;REQUEST PATTERN NUMBER
      MOV      PATRN,R3
      JSR      PC,OCTP    ;PRINT PATTERN NUMBER
      MOV      #PATRN,R5  ;GET ADDRESS OF PATRN ENTRY
      MOV      #2,R1     ;SET SIZE OF ENTRY
      MOV      #3,R2     ;SET UPPER LIMIT
      MOV      #0,R3     ;SET LOWER LIMIT
      JSR      PC,TTR     ;GO GET PATTERN NUMBER
      MOVB     #1,WPGFL+1 ;SET FLAG
      MOVB     PATRN,WPGFL ;SET PATTERN NUMBER
DSO:   MOV      #WBUF,R3  ;R3 = ADDR OF WRITE BUFFER
      MOV      PATRN,R1  ;R1 = PATTERN SELECTOR
      ASL      R1        ;MAKE PATTERN SELECTOR EVEN
      JSR      PC,@DATBL(R1) ;GO GENERATE PATTERN
DS3:   MOV      #202,R2  ;R2=BUFFER SIZE +2
      MOV      #RBUF,R1  ;R1=READ DATA START
DS4:   CLR      (R1)+    ;CLEAR BUFFER
      DEC      R2        ;SEE IF DONE ALL
      BNE     DS4        ;IF NOT: BR
      RTS      PC       ;EXIT

;ALL ONES*****
DAT1:  MOV      #-1,R1   ;R1=DATA
DAT1A: MOV      #202,R2  ;R2=WORD COUNT +2
1$:    MOV      R1,(R3)+ ;LOAD BUFFER
      DEC      R2        ;SEE IF DONE
      BNE     1$        ;IF NOT: BR
      RTS      PC       ;RETURN TO CALLER

;ALL ZEROS*****
DAT2:  CLR      R1       ;R1=DATA
      BR      DAT1A    ;LOAD BUFFER

;ONE/ZERO IN ALTERNATING CHARACTERS*****
DAT3:  MOV      #125125,R1 ;R1=DATA

```

2706 005212 000765
2707
2708
2709
2710 005214 012701 177377
2711 005220 000762
2712

BR DAT1A ;LOAD BUFFER
;ALTERNATING PARITY CHARACTERS*****
DAT4: MOV #177377,R1 ;R1=ALTERNATING PARITY DATA
BR DAT1A ;GO LOAD BUFFER

```

2714
2715 ;WRAP AROUND MODE 0 GLOBAL*****
2716
2717 005222 012737 000006 000750 WAM0: MOV #6,WAM ;SET WAM NUMBER
2718 005230 012737 000060 000752 WAM01: MOV #60,FUN
2719 005236 005037 000754 CLR DATC
2720 005242 012737 017474 000760 MOV #WBUFF,DATAD ;SET BUFFER ADDRESS
2721 005250 012737 020106 000762 MOV #RBUFF,RDAD ;SET POINTER TO READ BUFFER
2722 005256 004737 005514 JSR PC,SETUP ;GO SET UP
2723 005262 000137 006074 JMP EXEC
2724
2725 ;WRAP AROUND MODE 1 WRITE BUFFER*****
2726
2727 005266 012737 000010 000750 WAM1: MOV #10,WAM
2728 005274 000755 BR WAM01
2729
2730 ;WRAP AROUND MODE 2 BIT FIDDLER WRITE*****
2731
2732 005276 012737 000012 000750 WAM2: MOV #12,WAM
2733 005304 012737 000060 000752 MOV #60,FUN
2734 005312 005037 000754 CLR DATC
2735 005316 012737 017474 000760 MOV #WBUFF,DATAD
2736 005324 012737 020106 000762 MOV #RBUFF,RDAD
2737 005332 004737 005514 WAM2A: JSR PC,SETUP
2738 005336 000137 006074 JMP EXEC
2739
2740 ;WRAP AROUND MODE 3 BIT FIDDLER READ*****
2741
2742 005342 012737 000014 000750 WAM3: MOV #14,WAM ;SET WAM NUMBER
2743 005350 012737 000070 000752 MOV #70,FUN ;SET FUNCTION
2744 005356 012737 020106 000760 MOV #RBUFF,DATAD ;SET BUFFER ADDRESS
2745 005364 012737 017474 000756 MOV #WBUFF,WTAD ;SET POINTER TO WRITE BUFFER
2746 005372 005737 001006 TST RDRVF
2747 005376 001411 BEQ WAM3A
2748 005400 062737 000376 000760 ADD #376,DATAD
2749 005406 062737 000377 000756 ADD #377,WTAD
2750 005414 012737 000076 000752 MOV #76,FUN ;SET READ REVERSE CODE
2751 005422 032737 000020 000776 WAM3A: BIT #20,UDES
2752 005430 001403 BEQ WAM3B
2753 005432 013737 001010 000756 WAM3B: MOV RCDP,WTAD
2754 005440 004737 005514 WAM3B: JSR PC,SETUP ;GO SET UP
2755 005444 000137 006074 JMP EXEC ;GO EXECUTE
2756
2757 ;WRAP AROUND MODE 4 CRC CORRECTION
2758 ;CALL: JSR PC,WAM4
2759
2760 005450 012737 000030 000750 WAM4: MOV #30,WAM ;SET MAINTENANCE MODE FUNCTION WRAP 4
2761 005456 012737 000060 000752 MOV #60,FUN ;SET TAPE FUNCTION = WRITE FWD
2762 005464 005037 000754 CLR DATC
2763 005470 012737 004370 000760 MOV #CRCDAT,DATAD ;SET ADRS OF WRITE BUFFER
2764 005476 012737 020106 000762 MOV #RBUFF,RDAD ;SET READ BUFFER ADDRESS
2765 005504 004737 005514 JSR PC,SETUP ;GO SETUP REGISTERS
2766 005510 000137 006074 JMP EXEC ;GO EXECUTE

```

```

;REGISTER SETUP ROUTINE*****
2768
2769
2770 005514 005737 001022      SETUP:  TST      CRCFLG      ;DO NOT DO DATA SETUP NOR INIT
2771 005520 001004              BNE      1$              ;IF CRC CORRECTION IS IN PROGRESS
2772 005522 022737 000030 000750  CMP      #30,WAM        ;DO NOT INIT IF DOING WAM 4 --- STEP D
2773 005530 001004              BNE      2$              ;DO DRIVE CLEAR IF WAM4---STEP D
2774 005532 012777 000011 172750  1$:     MOV      #11,@C1
2775 005540 000412              BR       SET1A
2776 005542 005737 000740      2$:     TST      STFLG      ;SEE IF SINGLE TEST
2777 005546 001403              BEQ     SET0              ;IF NOT: BR
2778 005550 005737 001000      TST      WPGFL          ;SEE IF HAVE SELECTED PATTERN
2779 005554 001002              BNE     SET1              ;IF SO: BR
2780 005556 004737 005026      SET0:   JSR      PC,DSUP   ;GO DO DATA SETUP
2781 005562 004737 012206      SET1:   JSR      PC,INIT   ;INIT CONTROLLER,SELECT UNIT & DRIVE
2782                                     ;LOAD SLAVE DESC AND MOVE OFF BOT
2783 005566 012777 177400 172722  SET1A:  MOV      #400,@FC      ;SET FC=WCX2
2784 005574 032737 000020 000776  BIT      #20,UDES       ;SEE IF CORE DUMP
2785 005602 001403              BEQ     SET2              ;IF NOT: BR
2786 005604 012777 177000 172704  MOV      #1000,@FC      ;SET FC=WCX4
2787 005612 012777 177600 172672  SET2:   MOV      #200,@WC     ;SET WC
2788 005620 013777 000760 172666  MOV      DATAD,@BA      ;SET BUS ADDRESS
2789 005626 032777 010000 172664  BIT      #10000,@CS     ;ASSURE DRIVE THERE
2790 005634 001417              BEQ     SP1              ;IF SO: BR
2791 005636 032777 020000 172724  BIT      #20000,@SWR     ;SEE IF PRINT ERRORS
2792 005644 001004              BNE     SPO1             ;IF NOT: BR
2793 005646 012704 016635              MOV      #WMSG4,R4
2794 005652 004737 013054              JSR      PC,TIOUT        ;PRINT NON-EXISTANT DRIVE
2795 005656 032777 100000 172704  SPO1:  BIT      #100000,@SWR   ;SEE IF HALT ON ERROR
2796 005664 001401              BEQ     SPO              ;IF NOT: BR
2797 005666 000000              HALT
2798 005670 000137 005562              SPO:   JMP      SET1            ;RESETUP
2799 005674 022737 000014 000750  SP1:   CMP      #14,WAM       ;SEE IF WAM 3
2800 005702 001031              BNE     SP1B             ;IF NOT: BR
2801 005704 117737 173046 000754  MOVB    @WTAD,DATC      ;GET FIRST CHAR
2802 005712 042737 177400 000754  BIC     #177400,DATC
2803 005720 000337 000754              SWAB    DATC
2804 005724 052737 000200 000754  BIS     #200,DATC       ;SET PARITY
2805 005732 005737 001006              TST     RDRVF           ;SEE IF READ REVERSE
2806 005736 001403              BEQ     SP1A            ;IF NOT: BR
2807 005740 005337 000756              DEC     WTAD            ;DECREMENT POINTER
2808 005744 000410              BR     SP1B
2809 005746 005237 000756              SP1A:  INC     WTAD          ;BUMP POINTER
2810 005752 032737 000020 000776  BIT      #20,UDES       ;SEE IF CORE DUMP
2811 005760 001402              BEQ     SP1B            ;IF NOT: BR
2812 005762 005237 000756              INC     WTAD          ;BUMP POINTER AGAIN
2813 005766 053777 000776 172546  SP1B:  BIS     UDES,@TC       ;SET UNIT DESCRIPTION (DEN,PAR,FMT)
2814 005774 052777 000001 172532  BIS     #1,@MR          ;SET MAINT MODE
2815 006002 053777 000750 172524  BIS     WAM,@MR         ;SET WAM
2816 006010 053777 000754 172516  BIS     DATC,@MR        ;SET DATA
2817 006016 013777 000752 172464  MOV     FUN,@C1         ;SET FUNCTION
2818 006024 032777 040000 172470  BIT     #40000,@DS      ;ASSURE NO ERROR
2819 006032 001002              BNE     SP3            ;IF ERROR: BR
2820 006034 000240              NOP
2821 006036 000207              RTS     PC              ;RETURN
2822 006040 032777 020000 172522  SP3:  BIT     #20000,@SWR     ;SEE IF PRINT ERRORS
2823 006046 001004              BNE     SP4            ;IF NOT: BR
    
```

2824	006050	012704	016576			MOV	#WMSG2,R4	
2825	006054	004737	013054			JSR	PC,TIOUT	:PRINT SETUP ERROR
2826	006060	032777	100000	172502	SP4:	BIT	#100000,@SWR	:SEE IF HAL* ON ERROR
2827	006066	001401				BEQ	SP5	:IF NOT: BR
2828	006070	000000				HALT		
2829	006072	000207			SP5:	RTS	PC	:RETURN

```

2831                                     ;EXECUTE WAM ROUTINE*****
2832
2833 006074 000240 EXEC: NOP
2834 006076 000240 NOP
2835 006100 C32777 000040 172426 BIT #40,@MR
2836 006106 001403 BEQ EX0 ;ASSURE MAINT CLOCK IS ZERO
2837 006110 042777 000040 172416 BIC #40,@MR ;IF NOT: CLEAR IT
2838 006116 022737 000010 000750 EX0: CMP #10,WAM ;SEE IF WAM 1 OR 2 OR 3
2839 006124 003402 BLE 2$
2840 006126 000137 006540 1$: JMP EXW2 ;GO DO WAM 0
2841 006132 022737 000030 000750 2$: CMP #30,WAM ;BRANCH IF WRAP AROUND MODE 4
2842 006140 001772 BEQ 1$
2843 006142 052777 000001 172340 EX1: BIS #1,@C1 ;SET GO BIT
2844 006150 005000 CLR RO
2845 006152 012701 000002 MOV #2,R1 ;SET DELAY
2846 006156 032777 100000 172356 EX1A: BIT #100000,@TC ;SEE IF ALPHA
2847 006164 001404 BEQ EX2 ;IF SO: BR
2848 006166 005300 DEC RO
2849 006170 001372 BNE EX1A ;AWAIT ALPHA
2850 006172 005301 DEC R1
2851 006174 001370 BNE EX1A
2852 006176 005077 172364 EX2: CLR @PSW
2853 006202 012701 000400 MOV #400,R1 ;SET NUMBER OF CLKS
2854 006206 032737 000020 000776 BIT #20,UDES ;SEE IF CORE DUMP
2855 006214 001402 BEQ EX3 ;IF NOT: BR
2856 006216 012701 001000 MOV #1000,R1 ;SET CLOCKS LWCX4
2857 006222 022737 000014 000750 EX3: CMP #14,WAM ;SEE IF WAM 3
2858 006230 001010 BNE 1$ ;IF NOT: BR
2859 006232 032737 002000 000776 BIT #2000,UDES ;IS IT PE?
2860 006240 001016 BNE EX5A ;IF YES: BR
2861 006242 052777 000040 172264 BIS #40,@MR ;CLOCK UP
2862 006250 000412 BR EX5A
2863 006252 032737 002000 000776 1$: BIT #2000,UDES ;SEE IF PE
2864 006260 001404 BEQ EX5 ;IF NOT PE: BR
2865 006262 006301 ASL R1
2866 006264 062701 000246 ADD #246,R1 ;SET TO ALLOW FOR PRE/POSTAMBLE
2867 006270 000402 BR EX5A
2868 006272 062701 000010 EX5: ADD #10,R1 ;ADD CLOCKS FOR CRC AND LRC
2869 006276 022737 000014 000750 EX5A: CMP #14,WAM ;SEE IF WAM 3
2870 006304 001053 BNE EX5C ;IF NOT: BR
2871 006306 117700 172444 MOVB @WTAD,RO
2872 006312 042700 177400 BIC #177400,RO
2873 006316 005737 001006 TST RDRVF ;SEE IF REVERSE
2874 006322 001403 BEQ EX5A1 ;IF NOT: BR
2875 006324 005337 000756 DEC WTAD ;DEC POINTER
2876 006330 000416 BR EX5B
2877 006332 005237 000756 EX5A1: INC WTAD
2878 006336 032737 000020 000776 BIT #20,UDES ;SEE IF CORE DUMP
2879 006344 001410 BEQ EX5B ;IF NOT: BR
2880 006346 005237 000756 INC WTAD ;BUMP POINTER
2881 006352 005777 172400 TST @WTAD ;SEE IF END
2882 006356 001003 BNE EX5B ;IF NOT: BR
2883 006360 162737 000010 000756 SUB #10,WTAD ;RESTORE POINTER
2884 006366 052777 000040 172140 EX5B: BIS #40,@MR ;CLOCK UP
2885 006374 017702 172134 MOV @MR,R2 ;READ MR
2886 006400 042702 177600 BIC #177600,R2 ;MASK OUT DATA

```

2887	006404	000300				SWAB	RO		; POSITION DATA
2888	006406	022700	177000			CMP	#177000,RO		; SEE IF PATTERN 3
2889	006412	001404				BEQ	2\$; IF SO: BR
2890	006414	000240				NOP			
2891	006416	000240				NOP			
2892	006420	052700	000200		1\$:	BIS	#200,RO		; SET ODD PARITY
2893	006424	050002			2\$:	BIS	RO,R2		; LOAD NEW DATA
2894	006426	010277	172102			MOV	R2,@MR		; CLOCK DOWN AND LOAD NEW DATA
2895	006432	000426				BR	EX5D		
2896	006434	052777	000040	172072	EX5C:	BIS	#40,@MR		; CLOCK UP
2897	006442	042777	000040	172064		BIC	#40,@MR		; CLOCK DOWN
2898	006450	017700	172060			MOV	@MR,RO		; GET MR
2899	006454	000300				SWAB	RO		
2900	006456	032737	000010	000776		BIT	#10,UDES		; SEE IF EVEN PAR
2901	006464	001405				BEQ	EX5C0		; IF NOT: BR
2902	006466	010077	172270			MOV	RO,@RDAD		
2903	006472	005237	000762			INC	RDAD		
2904	006476	000402				BR	EX5C1		
2905	006500	110077	172256		EX5C0:	MOVB	RO,@RDAD		; PUT CHAR IN CORE
2906	006504	005237	000762		EX5C1:	INC	RDAD		
2907	006510	000240			EX5D:	NOP			
2908	006512	005301				DEC	R1		; SEE IF DONE CLKS
2909	006514	001270				BNE	EX5A		; IF NOT: BR
2910	006516	032777	000040	172010		BIT	#40,@MR		; CLOCK UP?
2911	006524	001403				BEQ	1\$; IF NOT: BR
2912	006526	042777	000040	172000		BIC	#40,@MR		; CLOCK DOWN
2913	006534	000137	011712		1\$:	JMP	EORP		; GO DO EOR


```

2915                                     ;EXECUTE WAM 0*****
2916
2917 006540 000240                      EXW2:  NOP
2918 006542 012737 006726 000670      MOV    #EXW2H,RTRN      ;SET INTERRUPT RETURN ADDRESS
2919 006550 012701 000200                MOV    #200,R1          ;SET NUMBER OF CLOCKS = FC/2
2920 006554 032737 002000 000776      BIT    #2000,UDES      ;SEE IF PE
2921 006562 001402                        BEQ    EXW2A            ;IF NOT: BR
2922 006564 012701 000100                MOV    #100,R1         ;ELSE SET CLKS = FC/4
2923 006570 012702 020106                EXW2A: MOV    #RBUFF,R2  ;SET BUFFER ADDRESS
2924 006574 022737 000030 000750      CMP    #30,WAM         ;BRANCH IF NOT WRAP 4
2925 006602 001003                        BNE    1$              ;
2926 006604 052777 000010 171706      BIS    #10,@CS         ;SET INHIBIT BUS ADDRESS INCREMENT
2927 006612 012777 000161 171670      1$:   MOV    #161,@C1   ;SET WRITE COMMAND AND GO
2928 006620 005077 171742                CLR    @PSW            ;ALLOW INTERRUPT
2929 006624 032777 000040 171702      EXW2B: BIT    #40,@MR   ;
2930 006632 001774                        BEQ    EXW2B            ;AWAIT CLOCK UP
2931 006634 017722 171674                MOV    @MR,(R2)+       ;GET DATA
2932 006640 032777 000040 171666      EXW2C: BIT    #40,@MR   ;
2933 006646 001374                        BNE    EXW2C            ;AWAIT CLOCK DOWN
2934 006650 017722 171660                MOV    @MR,(R2)+       ;GET DATA
2935 006654 005301                        DEC    R1               ;SEE IF DONE ALL
2936 006656 001362                        BNE    EXW2B            ;IF NOT: BR
2937 006660 012701 000003                EXW2E: MOV    #3,R1     ;
2938 006664 005000                        CLR    R0                ;SET DELAY
2939 006666 005300                        EXW2F: DEC    R0         ;
2940 006670 001376                        BNE    EXW2F            ;
2941 006672 005301                        DEC    R1                ;
2942 006674 001374                        BNE    EXW2F            ;DELAY
2943 006676 032777 020000 171664      BIT    #20000,@SWR     ;SEE IF ERROR PRINT
2944 006704 001004                        BNE    EXW2G            ;IF NOT: BR
2945 006706 012704 017040                MOV    #WMSG24,R4      ;
2946 006712 004737 013054                JSR    PC,TTOUT         ;PRINT NO INTERRUPT
2947 006716 005777 171646                EXW2G: TST    @SWR     ;SEE IF HALT ON ERROR
2948 006722 100001                        BPL    EXW2H            ;IF NOT: BR
2949 006724 000000                        HALT
2950 006726 000240                        EXW2H: NOP
2951 006730 012701 020106                MOV    #RBUFF,R1       ;GET START OF READ BUFFER
2952 006734 012700 000400                MOV    #400,R0         ;SET SIZE
2953 006740 010102                        MOV    R1,R2            ;
2954 006742 012203                        EXW2J: MOV    (R2)+,R3  ;
2955 006744 000303                        SWAB   R3                ;
2956 006746 032737 000010 000776      BIT    #10,UDES        ;SEE IF EVEN PAR
2957 006754 001402                        BEQ    EXW2J0           ;IF NOT: BR
2958 006756 010321                        MOV    R3,(R1)+        ;SAVE PAR + DATA
2959 006760 000401                        BR     EXW2J1           ;
2960 006762 110321                        EXW2J0: MOVB   R3,(R1)+ ;ASSEMBLE DATA IN BYTES
2961 006764 005300                        EXW2J1: DEC    R0        ;
2962 006766 001365                        BNE    EXW2J            ;CONTINUE FOR ALL
2963 006770 032777 000200 171572      BIT    #200,@SWR       ;SEE IF STATUS CHECK
2964 006776 001002                        BNE    EXW2K            ;IF NOT: BR
2965 007000 004737 007026                JSR    PC,WSTCK        ;ELSE GO CHECK STATUS
2966 007004 000240                        EXW2K: NOP
2967 007006 032777 000400 171554      BIT    #400,@SWR       ;SEE IF DATA CHECK
2968 007014 001002                        BNE    EXW2X            ;IF NOT: BR
2969 007016 004737 007416                JSR    PC,DCHK         ;ELSE GO CHECK DATA
2970 007022 000240                        EXW2X: NOP

```

TMO3-TU45 CONTROL LOGIC TEST-PART II
CZTUPB.P11 13-MAY-80 15:06

MACY11 30A(1052) 13-MAY-80^{D 4} 15:09 PAGE 36-1

DEU 14

2971 007024 000207

RTS PC

:EXIT

```

2973
2974 ;WRAP AROUND STATUS CHECK ROUTINE*****
2975
2976 007026 000240 WSTCK: NOP
2977 007030 005037 000772 CLR SERFL ;CLEAR ERROR FLAG
2978 007034 005037 000620 CLR HDRFL ;CLEAR HEADER FLAG
2979 007040 022737 014774 000622 CMP #MSLT2,EMADDR ;SEE IF TEST 2
2980 007046 001404 BEQ 2$ ;IF SO: BR
2981 007050 022737 015664 000622 CMP #MSLT15,EMADDR ;SEE IF TEST 15
2982 007056 001025 BNE 5$ ;IF NOT: BR
2983 007060 005737 001000 2$: TST WPGFL ;SEE IF SINGLE PATTERN
2984 007064 001405 BEQ 3$ ;IF NOT: BR
2985 007066 122737 000003 001000 CMPB #3,WPGFL ;SEE IF PATTERN 3
2986 007074 001016 BNE 5$ ;IF NOT: BR
2987 007076 000404 BR 4$ ;ELSE GO DO EXPT CHANGE
2988 007100 022737 000003 001002 3$: CMP #3,PATRN ;SEE IF PATTERN 3
2989 007106 001011 BNE 5$ ;IF NOT: BR
2990 007110 052737 140000 001024 4$: BIS #140000,WCS1
2991 007116 052737 140000 001030 BIS #140000,WDS
2992 007124 052737 000100 001032 BIS #100,WER ;SET EXPT PARITY ERROR
2993 007132 012737 016662 000672 5$: MOV #WMSG6,ERADD ;SET CODE=CS1
2994 007140 017702 171344 MOV @C1,R2 ;GET RCVD CS1
2995 007144 013705 001024 MOV WCS1,R5 ;GET EXPT CS1
2996 007150 004737 007272 JSR PC,WSTG ;GO CHK
2997 007154 012737 016707 000672 MOV #WMSG6D,ERADD ;SET CODE=CS2
2998 007162 017702 171332 MOV @CS,R2 ;SET RCVD CS2
2999 007166 013705 001026 MOV WCS2,R5 ;GET EXPT CS2
3000 007172 053705 000624 BIS DRVN,R5 ;SET DRIVE NUMBER IN EXPT CS2
3001 007176 004737 007272 JSR PC,WSTG ;GO CHK
3002 007202 012737 016715 000672 MOV #WMSG6E,ERADD ;SET CODE=DS
3003 007210 017702 171306 MOV @DS,R2 ;SET RCVD DS
3004 007214 013705 001030 MOV WDS,R5 ;GET EXPT DS
3005 007220 004737 007272 1$: JSR PC,WSTG ;GO CHK
3006 007224 012737 016722 000672 MOV #WMSG6F,ERADD ;SET CODE=ER
3007 007232 017702 171266 MOV @ER,R2 ;GET RCVD ER
3008 007236 000240 NOP
3009 007240 000240 NOP
3010 007242 013705 001032 MOV WER,R5 ;GET EXPT ER
3011 007246 004737 007272 JSR PC,WSTG ;GO CHK
3012 007252 005737 000772 TST SERFL ;SEE IF ANY ERRORS
3013 007256 001456 BEQ WSTX ;IF NOT: BR
3014 007260 005777 171304 TST @SWR ;SEE IF HALT ON ERROR
3015 007264 100053 BPL WSTX ;IF NOT: BR
3016 007266 000000 HALT
3017 007270 000451 BR WSTX ;CONTINUE
3018 007272 000240 WSTG: NOP
3019 007274 020205 CMP R2,R5 ;SEE IF EXPT=RCVD
3020 007276 001446 BEQ WSTX ;IF SO: BR
3021 007300 005237 000772 I%I SERFL ;SET ERROR FLAG
3022 007304 032777 020000 171256 B,T #20000,@SWR ;SEE IF PRINT ERRORS
3023 007312 001040 BNE WSTX ;IF NOT: BR
3024 007314 005737 000620 TST HDRFL ;SEE IF DONE HEADER
3025 007320 001010 BNE WSTG ;IF SO: BR
3026 007322 013704 000622 MOV EMADDR,R4
3027 007326 004737 013054 JSR PC,TTOUT ;PRINT TEST HEADER
3028 007332 012704 017024 MOV #WMSG23,R4

```

3029	007336	004737	013054		JSR	PC,TTOUT	;PRINT STATUS TAG
3030	007342	012737	000001	000620	WSTGO:	MOV #1,HDRFL	;SET HEADER FLAG
3031	007350	013704	000672		MOV	ERADD,R4	
3032	007354	004737	013054		JSR	PC,TTOUT	;PRINT CODE
3033	007360	012704	014325		MOV	#MSG12,R4	
3034	007364	004737	013054		JSR	PC,TTOUT	;PRINT EXPT TAG
3035	007370	010503			MOV	R5,R3	
3036	007372	004737	013202		JSR	PC,OCTP	;PRINT EXPT STATUS
3037	007376	012704	014334		MOV	#MSG13,R4	
3038	007402	004737	013054		JSR	PC,TTOUT	;PRINT RCVD TAG
3039	007406	010203			MOV	R2,R3	
3040	007410	004737	013202		JSR	PC,OCTP	;PRINT RCVD STATUS
3041	007414	000207			WSTX:	RTS	;RETURN
3042							

```
3044
3045 ;DATA CHECK ROUTINE*****
3046
3047 007416 000240 DCHK: NOP
3048 007420 005737 001022 TST CRCFLG ;DO NOT DO A DATA CHACK
3049 007424 001402 BEQ 2$ ;IF CRC CORRECTION IN PROGRESS
3050 007426 000137 010256 1$: JMP DCHKX1
3051 007432 005737 001020 2$: TST DCHKFL ;BRANCH IF DATA IS NOT TO BE CHECKED
3052 007436 001373 BNE 1$
3053 007440 005037 000620 CLR HDRFL ;CLEAR HEADER FLAG
3054 007444 005037 000766 CLR DERFL ;CLEAR DATA ERROR FLAG
3055 007450 005037 000774 CLR CRCNT ;CLEAR CHAR CNTR
3056 007454 032737 000010 000776 BIT #10,UDES ;SEE IF EVEN PARITY
3057 007462 001402 BEQ DCHKA0 ;IF NOT: BR
3058 007464 000137 010300 JMP DCHKE ;ELSE GO CHECK EVEN
3059 007470 022737 000010 000750 DCHKA0: CMP #10,WAM ;SEE IF WAM 1
3060 007476 001006 BNE DCHKA ;IF NOT: BR
3061 007500 032737 002000 000776 BIT #2000,UDES ;SEE IF PE
3062 007506 001402 BEQ DCHKA ;IF NOT: BR
3063 007510 000137 011002 JMP PRCHK ;GO CHK DATA
3064 007514 012700 177400 DCHKA: MOV #400,R0 ;SET NUMBER OF CHARACTERS
3065 007520 022737 000012 000750 CMP #12,WAM
3066 007526 001006 BNE DCHKA1 ;IF NOT WRAP 2: BR
3067 007530 032737 000020 000776 BIT #20,UDES
3068 007536 001402 BEQ DCHKA1 ;IF NOT CORE DUMP: BR
3069 007540 012700 177000 MOV #1000,R0
3070 007544 022737 000030 000750 DCHKA1: CMP #30,WAM ;BRANCH IF WRAP 4
3071 007552 001404 BEQ 1$
3072 007554 022737 000006 000750 CMP #6,WAM ;SEE IF WRAP 0
3073 007562 001007 BNE DCHKA2 ;IF NOT: BR
3074 007564 012700 177744 1$: MOV #34,R0 ;SET NUMBER OF CHARACTERS READ
3075 007570 012701 017504 MOV #WBUFF+10,R1 ;SET POINTER
3076 007574 005037 000766 CLR DERFL ;CLEAR DATA ERROR FLAG
3077 007600 000431 BR DCHKB0
3078 007602 022737 000012 000750 DCHKA2: CMP #12,WAM ;SEE IF WRAP 2
3079 007610 001021 BNE DCHKB ;IF NOT: BR
3080 007612 032737 002000 000776 BIT #2000,UDES ;SEE IF PE
3081 007620 001415 BEQ DCHKB ;IF NOT: BR
3082 007622 012700 177653 MOV #125,R0 ;POINT TO START OF DATA
3083 007626 012737 000001 000764 MOV #1,W2FLG ;SET WRAP 2 FLAG
3084 007634 004737 007654 JSR PC,DCHKB ;GO CHECK DATA
3085 007640 004737 011302 JSR PC,W1DCHK ;GO CHECK WRAP 1 DATA
3086 007644 005037 000764 CLR W2FLG
3087 007650 000137 010240 JMP DCHKX
3088 007654 005037 000766 DCHKB: CLR DERFL
3089 007660 012701 017474 MOV #WBUFF,R1 ;SET GOOD POINTER
3090 007664 012702 020106 DCHKB0: MOV #RBUFF,R2 ;SET READ POINTER
3091 007670 032737 000020 000776 BIT #20,UDES ;SEE IF CORE DUMP
3092 007676 001416 BEQ DCHK0 ;IF NOT: BR
3093 007700 022737 000012 000750 CMP #12,WAM ;SEE IF WAM 2
3094 007706 001011 BNE DCHKD ;IF NOT: BR
3095 007710 005737 001002 TST PATRN ;SEE IF PATTERN 0
3096 007714 001003 BNE DCHKC ;IF NOT: BR
3097 007716 012701 001056 MOV #WCDP0,R1 ;SET CORE DUMP PATTERN 0
3098 007722 000404 BR DCHK0 ;GO CHECK DATA
3099 007724 012701 001044 DCHKC: MOV #WCDP2,R1 ;SET CORE DUMP WRITE PATTERN 2
```

3100	007730	000401				BR	DCHK0		;GO CHECK DATA
3101	007732	000240				DCHKD: NOP			
3102	007734	121112				DCHK0: CMPB	(R1), (R2)		;SEE IF DATA OK
3103	007736	001466				BEQ	DCHK2		;IF SO: BR
3104	007740	032777	020000	170622		BIT	#20000,@SWR		;SEE IF PRINT ERRORS
3105	007746	001062				BNE	DCHK2		;IF NOT: BR
3106	007750	005737	000620			TST	HDRFL		;SEE IF DONE HEADER
3107	007754	001004				BNE	DCHK1		;IF SO: BR
3108	007756	013704	000622			MOV	EMADDR,R4		
3109	007762	004737	013054			JSR	PC,TTOUT		;PRINT HEADER
3110	007766	005737	000766			DCHK1: TST	DERFL		;SEE IF FIRST ERROR
3111	007772	001014				BNE	DCHK1A		;IF NOT: BR
3112	007774	012704	016772			MOV	#WMSG16,R4		
3113	010000	004737	013054			JSR	PC,TTOUT		;PRINT DATA ERROR TAG
3114	010004	012704	017217			MOV	#WMSG32,R4		
3115	010010	004737	013054			JSR	PC,TTOUT		;PRINT PATRN TAG
3116	010014	013703	001002			MOV	PATRN,R3		
3117	010020	004737	013202			JSR	PC,OCIP		;PRINT PATTERN NUMBER
3118	010024	012737	000001	000620		DCHK1A: MOV	#1,HDRFL		;SET HEADER FLAG
3119	010032	012737	000001	000766		MOV	#1,DERFL		;SET DATA ERROR FLAG
3120	010040	012704	017016			MOV	#WMSG21,R4		
3121	010044	004737	013054			JSR	PC,TTOUT		;PRINT CHARACTER NUMBER TAG
3122	010050	013703	000774			MOV	CRCNT,R3		
3123	010054	004737	013202			JSR	PC,OCIP		;PRINT CHARACTER NUMBER
3124	010060	012704	017004			MOV	#WMSG17,R4		
3125	010064	004737	013054			JSR	PC,TTOUT		;PRINT GOOD TAG
3126	010070	111103				MOVB	(R1),R3		
3127	010072	004737	013430			JSR	PC,DOUT		;PRINT GOOD DATA
3128	010076	012704	017011			MOV	#WMSG20,R4		
3129	010102	004737	013054			JSR	PC,TTOUT		;PRINT BAD TAG
3130	010106	111203				MOVB	(R2),R3		
3131	010110	004737	013430			JSR	PC,DOUT		;PRINT BAD DATA
3132	010114	005737	000764			DCHK2: TST	W2FLG		;SEE IF WRAP 2 NRZ
3133	010120	001020				BNE	DCHK2B		;IF SO: BR
3134	010122	005201				INC	R1		;BUMP POINTER
3135	010124	032737	000020	000776		BIT	#20,UDES		;SEE IF CORE DUMP
3136	010132	001413				BEQ	DCHK2B		;IF NOT: BR
3137	010134	022737	000012	000750		CMP	#12,WAM		;SEE IF WAM 2
3138	010142	001006				BNE	DCHK2A		;IF NOT: BR
3139	010144	005201				INC	R1		;BUMP POINTER
3140	010146	005711				TST	(R1)		;SEE IF END OF PATTERN
3141	010150	001004				BNE	DCHK2B		;IF NOT: BR
3142	010152	162701	000010			SUB	#10,R1		;RESET POINTER TO START OF PATTERN
3143	010156	000401				BR	DCHK2B		;CONTINUE CHECK
3144	010160	000240				DCHK2A: NOP			
3145	010162	005202				DCHK2B: INC	R2		
3146	010164	022737	000030	000750		CMP	#30,WAM		;BRANCH IF WAM 4
3147	010172	001404				BEQ	1\$		
3148	010174	022737	000006	000750		CMP	#6,WAM		;SEE IF WAM 0
3149	010202	001002				BNE	DCHK3		;IF NOT: BR
3150	010204	062701	000010			1\$: ADD	#10,R1		;BUMP POINTER
3151	010210	005237	000774			DCHK3: INC	CRCNT		;BUMP CHAR CNTR
3152	010214	032777	000400	170346		BIT	#400,@SWR		;SEE IF CONT DATA CHK
3153	010222	001006				BNE	DCHKX		;IF NOT: BR
3154	010224	005200				INC	R0		;SEE IF DONE
3155	010226	001242				BNE	DCHK0		;IF NOT: BR

3156	010230	005737	000764		TST	W2FLG		
3157	010234	001401			BEQ	DCHKX		
3158	010236	000207			RTS	PC		
3159	010240	005777	170324	DCHKX:	TST	@SWR		;SEE IF HALT CN ERROR
3160	010244	100004			BPL	DCHKX1		;IF NOT: BR
3161	010246	005737	000766		TST	DERFL		;SEE IF DATA EPROR OCCURED
3162	010252	001401			BEQ	DCHKX1		;IF NOT: BR
3163	010254	000000			HALT			
3164	010256	005037	000774	DCHKX1:	CLR	CRCNT		;CLEAR CHAR CNTR
3165	010262	005037	000620		CLR	HDRFL		;CLEAR HEADER FLAG
3166	010266	005037	000766		CLR	DERFL		;CLEAR DATA ERROR FLAG
3167	010272	005037	000770		CLR	PREFL		;CLEAR PREAMBLE FLAG
3168	010276	000207			RTS	PC		;RETURN

```

3170
3171                ;EVEN PARITY DATA CHECK*****
3172
3173 010300 000240      DCKE:  NOP
3174 010302 022737 000006 000750  CMP      #6,WAM          ;SEE IF WRAP 0
3175 010310 001005      BNE      1$          ;IF NOT: BR
3176 010312 012700 177744  MOV      #-34,R0      ;SET NUMBER OF CHARACTERS READ
3177 010316 012701 017504  MOV      #WBUF+10,R1 ;SET POINTER
3178 010322 000404      BR       2$
3179 010324 012700 177400  1$:  MOV      #-400,R0      ;SET NUMBER OF CHARACTERS
3180 010330 012701 017474  MOV      #WBUF,R1     ;R1=START OF WRITE BUFFER
3181 010334 012702 020106  2$:  MOV      #RBUF,R2     ;R2=START OF READ BUFFER
3182 010340 111105      DCKE0:  MOVB     (R1),R5 ;GET EXPT DATA
3183 010342 005003      CLR      R3
3184 010344 012704 000010  MOV      #10,R4      ;SET NUMBER OF BITS
3185 010350 032705 000001  DCKE1:  BJT      #1,R5      ;SEE IF ONE BIT
3186 010354 001401      BEQ     DCKE2        ;IF NOT: BR
3187 010356 005203      INC     R3          ;COUNT ONE BITS FOR PARITY CHECK
3188 010360 005304      DCKE2:  DEC     R4          ;SEE IF DONE
3189 010362 001402      BEQ     DCKE3        ;IF SO: BR
3190 010364 006005      ROR    R5          ;POINT TO NEXT BIT
3191 010366 000770      BR     DCKE1
3192 010370 000240      DCKE3:  NOP
3193 010372 111105      MOVB     (R1),R5      ;GET EXPT DATA
3194 010374 042705 177400  BIC     #177400,R5    ;MASK DATA FIELD
3195 010400 005703      TSI     R3
3196 010402 001003      BNE     DCKE4        ;IF NO ONE BITS SET: BR
3197 010404 012705 100020  MOV     #100020,R5
3198 010410 000405      BR     DCKE5
3199 010412 032703 000001  DCKE4:  BIT     #1,R3      ;SEE IF ODD NUMBER OF ONE BITS
3200 010416 001402      BEQ     DCKE5        ;IF NOT: BR
3201 010420 052705 100000  BIS     #100000,R5    ;SET EVEN PARITY BIT=1
3202 010424 042712 077400  DCKE5:  BIC     #77400,(R2) ;MASK DATA FIELD
3203 010430 020512      CMP     R5,(R2)      ;SEE IF DATA + PARITY GOOD
3204 010432 001477      BEQ     DCKE10       ;IF SO: BR
3205 010434 032777 020000 170126  BIT     #20000,@SWR   ;SEE IF ERROR PRINT
3206 010442 001073      BNE     DCKE10       ;IF NOT: BR
3207 010444 005737 000620  TST     HDRFL        ;SEE IF DONE HEADER
3208 010450 001004      BNE     DCKE6        ;IF SO: BR
3209 010452 013704 000622  MOV     EMADDR,R4
3210 010456 004737 013054  JSR     PC,TTOUT      ;PRINT HEADER
3211 010462 005737 000766  DCKE6:  TST     DERFL        ;SEE IF FIRST BAD CHAR
3212 010466 001014      BNE     DCKE7        ;IF NOT: BR
3213 010470 012704 016772  MOV     #WMSG16,R4
3214 010474 004737 013054  JSR     PC,TTOUT      ;PRINT BAD DATA TAG
3215 010500 012704 017217  MOV     #WMSG32,R4
3216 010504 004737 013054  JSR     PC,TTOUT      ;PRINT PATTERN TAG
3217 010510 013703 001002  MOV     PATRN,R3
3218 010514 004737 013202  JSR     PC,OCIP       ;PRINT PATTERN NUMBER
3219 010520 000240      DCKE7:  NOP
3220 010522 012737 000001 000766  MOV     #1,DERFL      ;SET DATA ERROR FLAG
3221 010530 012737 000001 000620  MOV     #1,HDRFL      ;SET HEADER FLAG
3222 010536 012704 017016  MOV     #WMSG21,R4
3223 010542 004737 013054  JSR     PC,TTOUT      ;PRINT CHAR NUMBER TAG
3224 010546 013703 000774  MOV     CRCNT,R3
3225 010552 004737 013202  JSR     PC,OCIP       ;ORINT CHAR NUMBER
    
```



```

3226 010556 012704 017004      MOV      #WMSG17,R4
3227 010562 004737 013004      JSR      PC,T1OUT      ;PRINT GOOD DATA TAG
3228 010566 110503              MOVVB    R5,R3
3229 010570 004737 013430      JSR      PC,DOUT      ;PRINT EXPT DATA
3230 010574 010503              MOV      R5,R3
3231 010576 004737 010706      JSR      PC,DCKEP     ;GO PRINT PARITY BIT
3232 010602 000240              NOP
3233 010604 012704 017011      MOV      #WMSG20,R4
3234 010610 004737 013054      JSR      PC,T1OUT     ;PRINT BAD TAG
3235 010614 111203              MOVVB    (R2),R3
3236 010616 004737 013430      JSR      PC,DOUT     ;PRINT BAD DATA
3237 010622 011203              MOV      (R2),R3
3238 010624 004737 010706      JSR      PC,DCKEP     ;GO PRINT PARITY BIT
3239 010630 000240              NOP
3240 010632 005201              DCKE10: INC      R1
3241 010634 022737 000006 000750  CMP      #6,WAM      ;SEE IF WRAP 0
3242 010642 001002              BNE     1$          ;IF NOT: BR
3243 010644 062701 000010              ADD     #10,R1      ;BUMP POINTER
3244 010650 005722              1$:     TST      (R2)+ ;BUMP POINTERS
3245 010652 005237 000774              INC     CRCNT      ;BUMP CHAR CNTR
3246 010656 032777 000400 167704  BIT      #400,@SWR  ;SEE IF CONTINUE DATA CHECK
3247 010664 001402              BEQ     DCKE11     ;IF SO: BR
3248 010666 000137 010240              JMP     DCHKX      ;GO TO END OF DATA CHECK
3249 010672 005200              DCKE11: INC     R0   ;SEE IF DONE
3250 010674 001402              BEQ     DCKE12     ;IF SO: BR
3251 010676 000137 010340              JMP     DCKE0      ;ELSE CONTINUE
3252 010702 000137 010240              DCKE12: JMP     DCHKX ;GO TO END OF DATA CHECK
3253 010706 000240              DCKEP:  NOP
3254 010710 012737 000240 000614  MOV     #240,TOB
3255 010716 004737 013154              JSR     PC,TOG     ;SPACE
3256 010722 012737 000260 000614  MOV     #260,TOB  ;SET PAR=0
3257 010730 005703              TST     R3         ;SEE IF PARITY REALLY=0
3258 010732 100002              BPL     DCKEPO     ;IF SO: BR
3259 010734 005237 000614              INC     TOB        ;ELSE SET TO 1
3260 010740 004737 013154              DCKEPO: JSR     PC,TOG ;PRINT PARITY BIT
3261 010744 000207              RTS      PC        ;RETURN
3262
  
```

```

3264
3265          ;PREAMBLE/POSTAMBLE CHECK*****
3266
3267 010746 012700 000051 PSCHK: MOV #51,R0 ;SET SIZE OF POSTAMBLE
3268 010752 012701 017352 MOV #POST,R1 ;SET POINTER TO POSTAMBLE
3269 010756 005037 000620 CLR HDRFL ;CLEAR HEADER FLAG
3270 010762 005037 000774 CLR CRCNT ;CLEAR CHAR CNTR
3271 010766 005037 000766 CLR DERFL ;CLEAR DATA ERROR FLAG
3272 010772 000240 NOP
3273 010774 000240 NOP
3274 010776 000137 011020 JMP PDO ;GO CHECK POSTAMBLE
3275
3276 011002 012700 000051 PRCHK: MOV #51,R0 ;SET SIZE OF PREAMBLE
3277 011006 012701 017230 MOV #PRE,R1 ;SET POINTER TO PREAMBLE
3278 011012 012702 020106 MOV #RBUF,R2 ;SET POINTER TO START OF READ BUFFER
3279 011016 022122 CMP (R1)+,(R2)+ ;BUMP ADDRESS POINTERS
3280 011020 121112 PDO: CMPB (R1),(R2) ;CHECK DATA
3281 011022 001004 BNE PD1 ;IF NOT GOOD: BR
3282 011024 126162 0C0001 000001 CMPB 1(R1),1(R2) ;COMPARE COMPLIMENT BYTE
3283 011032 001477 BEQ PD5 ;IF GOOD: BR
3284 011034 032777 020000 167526 PD1: BIT #20000,@SWR ;SEE IF PRINT INHIBIT
3285 011042 001073 BNE PD5 ;IF SO: BR
3286 011044 005737 000620 TST HDRFL ;SEE IF DONE HEADER
3287 011050 001020 BNE PD4 ;IF SO: BR
3288 011052 013704 000622 MOV EMADDR,R4
3289 011056 004737 013054 JSR PC,TTOUT ;PRINT TEST HEADER
3290 011062 005737 000770 TST PREFL ;SEE IF PREAMBLE CHECK
3291 011066 001403 BEQ PD2 ;IF NOT: BR
3292 011070 012704 017143 MOV #WMSG29,R4 ;SET POSTAMBLE HEADER
3293 011074 000402 BR PD3
3294 011076 012704 017125 PD2: MOV #WMSG28,R4 ;SET PREAMBLE HEADER
3295 011102 004737 013054 PD3: JSR PC,TTOUT ;PRINT HEADER
3296 011106 005237 000620 INC HDRFL
3297 011112 012704 017016 PD4: MOV #WMSG21,R4
3298 011116 004737 013054 JSR PC,TTOUT ;PRINT CHAR NUMBER TAG
3299 011122 013703 000774 MOV CRCNT,R3
3300 011126 004737 013202 JSR PC,OCTP ;PRINT CHAR NUMBER
3301 011132 012704 017004 MOV #WMSG17,R4
3302 011136 004737 013054 JSR PC,TTOUT ;PRINT GOOD TAG
3303 011142 116103 000001 MOVB 1(R1),R3
3304 011146 004737 013430 JSR PC,DOUT ;PRINT GOOD CHAR
3305 011152 012737 000240 000614 MOV #240,TOB
3306 011160 004737 013154 JSR PC,TOG
3307 011164 111103 MOVB (R1),R3
3308 011166 004737 013430 JSR PC,DOUT ;PRINT COMPLEMENT
3309 011172 012704 017011 MOV #WMSG20,R4
3310 011176 004737 013054 JSR PC,TTOUT ;PRINT BAD TAG
3311 011202 116203 000001 MOVB 1(R2),R3
3312 011206 004737 013430 JSR PC,DOUT ;PRINT BAD CHAR
3313 011212 012737 000240 000614 MOV #240,TOB
3314 011220 004737 013154 JSR PC,TOG
3315 011224 111203 MOVB (R2),R3
3316 011226 004737 013430 JSR PC,DOUT ;PRINT COMPLEMENT
3317 011232 022122 PD5: CMP (R1)+,(R2)+ ;BUMP ADDRESS POINTERS
3318 011234 005237 000774 INC CRCNT ;BUMP CHAR NUMBER
3319 011240 005300 DEC R0 ;SEE IF DONE
  
```

3320	011242	001266		BNE	PDO	:IF NOT: BR
3321	011244	005737	000770	TST	PREFL	:SEE IF PREAMBLE
3322	011250	001402		BEQ	PD6	:IF SO: BR
3323	011252	000137	010240	JMP	DCHKX	:GO TO EXIT ROUTINE
3324	011256	005237	000770	PD6:	INC	:SET PREAMBLE FLAG
3325	011262	005037	000620	CLR	HDRFL	:CLEAR HEADER FLAG
3326	011266	005037	000774	CLR	CRCNT	:CLEAR CHAR CNTR
3327	011272	005037	000766	CLR	DERFL	:CLEAR DATA ERROR FLAG
3328	011276	000137	011302	JMP	WIDCHK	:GO CHECK WRAP 1 DATA
3329						

```

3331
3332 ;WAM 1 PE DATA CHECK*****
3333
3334 011302 012700 177400 WIDCHK: MOV #-400,R0 ;SET NUMBER OF CHAR TO CHECK
3335 011306 012701 017474 MOV #WBUF,R1 ;SET WRITE DATA POINTER
3336 011312 012702 020106 MOV #RBUF,R2 ;SET READ DATA POINTER
3337 011316 062702 000124 ADD #124,R2 ;POINT TO START OF DATA
3338 011322 005737 000764 TST W2FLG ;SEE IF WRAP 2
3339 011326 001401 BEQ W1D0 ;IF NOT WAM 2: BR
3340 011330 005302 DEC R2 ;RESET POINTER
3341 011332 111105 W1D0: MOVB (R1),R5
3342 011334 120512 CMPB R5,(R2) ;CHECK DATA
3343 011336 001007 BNE W1D1 ;IF NOT GOOD:BR
3344 011340 005737 000764 TST W2FLG ;SEE IF WRAP 2
3345 011344 001001 BNE W1DOA ;IF SO: BR
3346 011346 105105 COMB R5 ;COMPLIMENT EXPT DATA
3347 011350 120562 000001 W1DOA: CMPB R5,1(R2) ;CHECK COMPLIMENT DATA
3348 011354 001510 BEQ W1D3 ;IF GOOD: BR
3349 011356 032777 020000 167204 W1D1: BIT #20000,@SWR ;SEE IF PRINT INHIBIT
3350 011364 001104 BNE W1D3 ;IF SO BR
3351 011366 005737 000620 TST HDRFL ;SEE IF DONE HEADER
3352 011372 001020 BNE W1D2 ;IF SO: BR
3353 011374 013704 000622 MOV EMADDR,R4
3354 011400 004737 013054 JSR PC,TIOUT ;PRINT TEST HEADER
3355 011404 012704 016772 MOV #WMSG16,R4
3356 011410 004737 013054 JSR PC,TIOUT ;PRINT BAD DATA TAG
3357 011414 012704 017217 MOV #WMSG32,R4
3358 011420 004737 013054 JSR PC,TIOUT ;PRINT PATRN TAG
3359 011424 013703 001002 MOV PATRN,R3
3360 011430 004737 013202 JSR PC,OCTP ;PRINT PATTERN NUMBER
3361 011434 012737 000001 000620 W1D2: MOV #1,HDRFL ;SET HEADER FLAG
3362 011442 012704 017016 MOV #WMSG21,R4
3363 011446 004737 013054 JSR PC,TIOUT ;PRINT CHAR NUMBER TAG
3364 011452 013703 000774 MOV CRCNT,R3
3365 011456 004737 013202 JSR PC,OCTP ;PRINT CHAR NUMBER
3366 011462 012704 017004 MOV #WMSG17,R4
3367 011466 004737 013054 JSR PC,TIOUT ;PRNT GOOD TAG
3368 011472 111105 MOVB (R1),R5
3369 011474 110503 MOVB R5,R3 ;GET GOOD CHAR
3370 011476 005737 000764 TST W2FLG ;SEE IF WRAP 2
3371 011502 001001 BNE W1D2A ;IF SO: BR
3372 011504 105103 COMB R3 ;ELSE COMPLIMENT CHAR
3373 011506 004737 013430 W1D2A: JSR PC,DOUT ;PRINT CHARACTER
3374 011512 012737 000240 000614 MOV #240,TOB
3375 011520 004737 013154 JSR PC,TOG ;SPACE
3376 011524 110503 MOVB R5,R3
3377 011526 004737 013430 JSR PC,DOUT ;PRINT CHAR
3378 011532 012704 017011 MOV #WMSG20,R4
3379 011536 004737 013054 JSR PC,TIOUT ;PRINT BAD TAG
3380 011542 116203 MOVB 1(R2),R3
3381 011546 004737 013430 JSR PC,DOUT ;PRINT BAD CHAR
3382 011552 012737 000240 000614 MOV #240,TOB
3383 011560 004737 013154 JSR PC,TOG ;SPACE
3384 011564 111203 MOVB (R2),R3
3385 011566 004737 013430 JSR PC,DOUT ;PRINT CHAR
3386 011572 005237 000766 INC DERFL ;SET DATA ERROR FLAG

```

3387 011576 122122
3388 011600 105722
3389 011602 005237 000774
3390 011606 000406
3391 011610 005737 000764
3392 011614 001401
3393 011616 000207
3394 011620 000137 010746
3395 011624 005200
3396 011626 001770
3397 011630 000137 011332
3398
3399
3400
3401 011634 000240
3402 011636 012700 000050
3403 011642 012701 017230
3404 011646 005721
3405 011650 012721 177400
3406 011654 005300
3407 011656 001374
3408 011660 012701 017352
3409 011664 012700 000050
3410 011670 012721 000377
3411 011674 012721 177400
3412 011700 005300
3413 011702 001374
3414 011704 000207

W1D3: CMPB (R1)+,(R2)+ ;BUMP ADDRESS
TSTB (R2)+ ;BUMP ADDRESS
INC CRCNT ;BUMP CHAR CNTR
BR W1D5
W1D4: TST W2FLG ;SEE IF WRAP 2
BEQ W1D4A ;IF NOT: BR
RTS PC ;ELSE RETURN
W1D4A: JMP PSCHK ;GO CHECK POSTAMBLE
W1D5: INC R0
BEQ W1D4
JMP W1D0
;PREAMBLE/POSTAMBLE GENERATE SUBROUTINE*****
PPGEN: NOP
MOV #50,R0 ;SET SIZE OF PREAMBLE
MOV #PRE,R1
TST (R1)+ ;SET ADDRESS OF PRE
1\$: MOV #177400,(R1)+ ;FILL TABLE
DEC R0 ;SEE IF DONE
BNE 1\$;IF NOT: BR
MOV #POST,R1 ;SET ADDRESS OF POST
MOV #50,R0 ;SET SIZE OF POST
MOV #377,(R1)+ ;SET SYNC CHAR
2\$: MOV #177400,(R1)+ ;FILL TABLE
DEC R0 ;SEE IF DONE
BNE 2\$;IF NOT: BR
RTS PC ;RETURN

```

3416
3417
3418 ;END OF RECORD FORCE SUBROUTINE*****
3419 011706 005237 000676 EORPA: INC TEMP2 ;SET WRAP FLAG
3420 011712 017700 166616 EORP: MOV @MR,R0 ;GET MAINT REG
3421 011716 042700 000036 BIC #36,R0 ;CLEAR CURRENT OP CODE
3422 011722 052700 000024 BIS #24,R0 ;SET EOR CLEAR OP CODE
3423 011726 010077 166602 MOV R0,@MR ;DO EOR
3424 011732 042777 000037 166574 BIC #37,@MR ;CLEAR EOR AND MM
3425 011740 005000 CLR R0
3426 011742 012701 000002 MOV #2,R1
3427 011746 032777 000001 166534 EORP1: BIT #1,@C1 ;SEE IF GO GONE
3428 011754 001427 BEQ EORP2 ;IF SO: BR
3429 011756 005300 DEC R0
3430 011760 001372 BNE EORP1 ;AWAIT GO RESET
3431 011762 005301 DEC R1
3432 011764 001370 BNE EORP1
3433 011766 032777 020000 166574 BIT #20000,@SWR ;SEE IF ERROR PRINT INHIBIT
3434 011774 001017 BNE EORP2 ;IF SO: BR
3435 011776 005737 000620 TST HDRFL ;SEE IF DONE HEADER
3436 012002 001004 BNE EORP1A ;IF SO: BR
3437 012004 013704 000622 MOV EMADDR,R4
3438 012010 004737 013054 JSR PC,TTOUT ;PRINT HEADER
3439 012014 012704 017162 EORP1A: MOV #WMSG31,R4
3440 012020 004737 013054 JSR PC,TTOUT ;PRINT EOR GO BIT ERROR
3441 012024 005777 166540 TST @SWR ;SEE IF HALT ON ERROR
3442 012030 100001 BPL EORP2 ;IF NOT: BR
3443 012032 000000 HALT
3444 012034 000240 EORP2: NOP
3445 012036 005737 000676 TST TEMP2 ;SEE IF WAM
3446 012042 001015 BNE EORPX ;IF NOT: BR
3447 012044 032777 000200 166516 BIT #200,@SWR ;SEE IF STATUS CHECK
3448 012052 001002 BNE EORP3 ;IF NOT: BR
3449 012054 004737 007026 JSR PC,WSTCK ;ELSE GO CHECK STATUS
3450 012060 000240 EORP3: NOP
3451 012062 032777 000400 166500 BIT #400,@SWR ;SEE IF DATA CHECK
3452 012070 001002 BNE EORPX ;IF NOT: BR
3453 012072 004737 007416 JSR PC,DCHK ;ELSE GO CHECK DATA
3454 012076 000240 EORPX: NOP
3455 012100 005037 000676 CLR TEMP2 ;CLEAR FLAG
3456 012104 000207 RTS PC ;RETURN
3457
  
```

```

3459
3460
3461           ;SCOPE LOOP ON ERROR SUBROUTINE*****
3462 012106 000240 SCOPE: NOP
3463 012110 032777 040000 166452 BIT #40000,@SWR ;SEE IF LOOP ON ERROR
3464 012116 001001 BNE 1$ ;IF SO: BR
3465 012120 000207 RTS PC ;ELSE EXIT
3466 012122 000240 1$: NOP
3467 012124 005726 TST (SP)+ ;RESET STACK
3468 012126 000240 NOP
3469 012130 000240 NOP
3470 012132 000177 166554 JMP @SCOLP ;LOOP ON ERROR
3471
3472           ;TEST ITERATION SUBROUTINE*****
3473
3474 012136 032777 004000 166424 ITER: BIT #4000,@SWR ;SEE IF ITERATIONS
3475 012144 001403 BEQ 2$ ;IF SO: BR
3476 012146 005037 000702 1$: CLR ITCNT ;CLEAR ITERATION COUNTER
3477 012152 000207 RTS PC ;ELSE EXIT
3478 012154 005737 001016 2$: TST @#PCNTR ;DO SINGLE SUBTEST ITERATION
3479 012160 001772 BEQ 1$ ;ON FIRST PASS
3480 012162 005237 000702 INC ITCNT ;BUMP COUNTER
3481 012166 023737 000702 000606 CMP ITCNT,ITAMT ;SEE IF DONE ALL
3482 012174 001764 BEQ 1$ ;IF SO: BR
3483 012176 005726 TST (SP)+ ;RESET STACK
3484 012200 017700 166510 MOV @ITRLP,R0 ;SET ITERATION POINTER
3485 012204 000110 JMP (R0) ;GO ITERATE
3486
    
```

```

3488
3489
3490
3491 012206 012777 000040 166304 INIT: MOV #40,@CS ;INIT
3492 012214 013777 000624 166276 MOV DRVN,@CS ;SELECT DRIVE
3493 012222 013777 000664 166312 MOV SLVN,@TC ;SELECT SLAVE
3494 012230 013746 000776 MOV UDES,-(SP) ;GET TEST'S UNIT DESCRIPTION
3495 012234 042716 174377 BIC #174377,(SP) ;CLEAR ALL BUT DENSITY SELECT BITS
3496 012240 022726 001400 CMP #1400,(SP)+ ;BRANCH IF NOT NRZ (800 BPI)
3497 012244 001005 BNE 1$
3498 012246 032777 000040 166246 BIT #40,@DS ;BRANCH IF SLAVE IS IN NRZ MODE
3499 012254 001420 BEQ 4$ ;(PES = 0)
3500 012256 000404 BR 2$ ;GO CHANGE DENSITY
3501 012260 032777 000040 166234 1$: BIT #40,@DS ;BRANCH IF SLAVE IS IN PE MODE
3502 012266 001013 BNE 4$ ;(PES = 1)
3503 012270 012777 000007 166212 2$: MOV #7,@C1 ;REWIND SLAVE
3504 012276 032777 000200 166216 20$: BIT #200,@DS ;WAIT FOR READY
3505 012304 001774 BEQ 20$
3506 012306 032777 020000 166206 3$: BIT #20000,@DS ;LOOP UNTIL REWIND IS COMPLETE
3507 012314 001374 BNE 3$ ;(PIP = 0)
3508 012316 053777 000776 166216 4$: BIS UDES,@TC ;LOAD UNIT DESCRIPTION
3509 012324 032777 000002 166170 BIT #2,@DS ;BRANCH IF NOT AT BOT
3510 012332 001407 BEQ 6$
3511 012334 012777 000025 166146 MOV #25,@C1 ;ERASE TO GET OFF BOT
3512 012342 032777 000200 166152 5$: BIT #200,@DS ;LOOP UNTIL DONE
3513 012350 001774 BEQ 5$
3514 012352 012777 000011 166130 6$: MOV #11,@C1 ;DO A DRIVE CLFAR
3515 012360 000207 RTS PC ;RETURN TO CALLER
3516
3517
3518
3519 012362 000240 MTINT: NOP
3520 012364 013716 000670 MOV RTRN,(SP) ;SET RETURN TO (RTRN)
3521 012370 000002 RTI ;RETURN
3522
3523
3524
3525 012372 017746 166176 TTINT: MOV @TKB,-(SP) ;GET CHARACTER
3526 012376 042716 000200 BIC #200,(SP) ;CLEAR PARITY BIT
3527 012402 122716 000003 CMPB #3,(SP) ;BRANCH IF NOT CONTROL C
3528 012406 001006 BNE 1$
3529 012410 005737 001262 TST CHNFLG ;INHIBIT ^C IF CHAIN MODE
3530 012414 001003 BNE 1$
3531 012416 000005 RESET
3532 012420 000137 000200 JMP #200 ;RESTART PROGRAM
3533 012424 122716 000001 1$: CMPB #1,(SP) ;BRANCH IF NOT ^A
3534 012430 001017 BNE 2$
3535 012432 022737 000176 000570 CMP #SWREG,SWR ;BRANCH IF HARDWARE SWR INVOKED
3536 012440 001016 BNE 3$
3537 012442 012737 177570 000570 MOV #177570,SWR ;INVOKE HARDWARE SWR
3538 012450 004737 013732 JSR PC,SAVE ;SAVE REGISTERS ON THE STACK
3539 012454 012704 014641 MOV #MSG63,R4 ;TYPE 'HARDWARE SWR IN USE'
3540 012460 004737 013054 JSR PC,TTOUT
3541 012464 004737 013754 JSR PC,RESTORE ;RESTORE REGISTERS
3542 012470 022716 000007 2$: CMP #7,(SP) ;BRANCH IF NOT ^G
3543 012474 001005 BNE 4$
  
```



```

3550
3551
3552
3553
3554
3555
3556
3557
3558
3559
3560
3561
3562
3563
3564
3565
3566
3567 012514 010146
3568 012516 011601
3569 012520 005037 000674
3570 012524 005000
3571 012526 004737 012774
3572 012532 122737 000003 000616
3573 012540 001003
3574 012542 000005
3575 012544 000137 000200
3576 012550 122737 000015 000616
3577 012556 001004
3578 012560 005737 000674
3579 012564 001471
3580 012566 000457
3581 012570 122737 000025 000616
3582 012576 001005
3583 012600 012704 014567
3584 012604 004737 013054
3585 012610 000742
3586 012612 122737 000177 000616
3587 012620 001012
3588 012622 000241
3589 012624 006000
3590 012626 006200
3591 012630 006200
3592 012632 012704 014571
3593 012636 004737 013054
3594 012642 005201
3595 012644 000730
3596 012646 122737 000060 000616
3597 012654 101402
3598 012656 000137 012754
3599 012662 122737 000070 000616
3600 012670 101002
3601 012672 000137 012754
3602 012676 005237 000674
3603 012702 006300
3604 012704 006300
3605 012706 006300

```

```

:*****
:TTY ENTRY SUBROUTINE:
:
:THIS SUBROUTINE IS USED BY THE TEST CONDITION
:ENTRY ROUTINE TO READ THE RESPONSE ENTERED
:AT THE TTY AND CHECK THEM FOR LEGALITY AND
:LIMITS. ALL RESPONSE MUST BE TYPED IN OCTAL
:(0-7) AND MUST FALL WITHIN THE LIMITS SET BY
:THE CALLING ROUTINE.
:IF AN ENTRY IS ILLEGAL OR OUTSIDE THE LIMITS,
:A QUESTION MARK IS TYPED (?) AND THE RESPONSE
:MAY BE REENTERED.
:ENTRIES MAY NOT EXCEED SIX (6) CHARACTERS AND
:MAY BE TERMINATED AT LESS THAN SIX BY TYPING A
:CARRIAGE RETURN
:*****

```

```

TTR: MOV R1,-(SP) ;SAVE CHAR COUNT
10$: MOV (SP),R1 ;RESET CHAR COUNT (FOR ^U)
CLR TEMP1 ;CLEAR FIRST CHARACTER FLAG
CLR RO
1$: JSR PC,TTIN ;GO READ CHARACTER
CMPB #3,TIB ;BRANCH IF NOT ^C
BNE 11$
RESET
JMP @#200 ;RESTART AT 200
11$: CMPB #15,TIB ;SEE IF CR
BNE 2$ ;IF NOT: BR
TST TEMP1 ;SEE IF FIRST CHARACTER
BEQ 9$ ;IF SO: BR
BR 6$ ;ELSE GO LOAD VALUE
2$: CMPB #25,TIB ;BRANCH IF NOT CONTROL U
BNE 21$
MOV #MSG59,R4 ;TYPE<CR><LF>
JSR PC,TTOUT
BR 10$
21$: CMPB #177,TIB ;BRANCH IF NOT 'RUBOUT'
BNE 3$
CLC ;REMOVE LAST TYPED CHAR
ROR RO
ASR RO
ASR RO
MOV #MSG60,R4 ;TYPE '\ '
JSR PC,TTOUT
INC R1 ;DECREMENT CHAR RECEIVED COUNT
BR 1$ ;GET NEXT CHAR
3$: CMPB #60,TIB ;SEE IF CHAR IS LESS THAN 0
BLOS 4$ ;IF NOT: BR
JMP T1NER ;ELSE GO TO ERROR
4$: CMPB #70,TIB ;SEE IF CHAR IS GREATER THAN 7
BHI 5$ ;IF NOT: BR
JMP T1NER ;ELSE GO TO ERROR
5$: INC TEMP1 ;SET FIRST CHARACTER FLAG
ASL RO
ASL RO ;SHIFT 3 LEFT
ASL RO

```

```
3606 012710 042737 177770 000616      BIC    #177770,T1B    ;STRIP ASCII
3607 012716 053700 000616      BIS    T1B,R0        ;LOAD CHARACTER
3608 012722 005301              DEC    R1            ;SEE IF DONE
3609 012724 001300              BNE    1$           ;IF NOT: BR
3610 012726 020002      6$:    CMP    R0,R2        ;SEE IF EXCEEDED MAXIMUM LIMIT
3611 012730 101402              BLOS   7$           ;IF NOT: BR
3612 012732 000137 012754      JMP    T1NER        ;ELSE GO TO ERROR
3613 012736 020300      7$:    CMP    R3,R0        ;SEE IF BELOW MINIMUM LIMIT
3614 012740 101402              BLOS   8$           ;IF NOT: BR
3615 012742 000137 012754      JMP    T1NER        ;ELSE GO TO ERROR
3616 012746 010015      8$:    MOV    R0,(R5)    ;LOAD VALUE
3617 012750 005726      9$:    TST    (SP)+      ;POP CHAR COUNT OFF STACK
3618 012752 000207              RTS    PC           ;EXIT
```

```

3620
3621
3622
3623 012754 012704 014444
3624 012760 004737 013054
3625 012764 005726
3626 012766 162716 000020
3627 012772 000207
3628
3629
3630
3631 012774 017746 165566
3632 013000 052777 000340 165560
3633 013006 005277 165560
3634 013012 105777 165554
3635 013016 100375
3636 013020 012677 165542
3637 013024 017737 165544 000616
3638 013032 042737 000200 000616
3639 013040 013737 000616 000614
3640 013046 004737 013154
3641 013052 000207
3642
3643
3644
3645 013054 112437 000614
3646 013060 122737 000043 000614
3647 013066 001440
3648 013070 122737 000045 000614
3649 013076 001403
3650 013100 004737 013154
3651 013104 000763
3652 013106 112737 000015 000614
3653 013114 004737 013154
3654 013120 012703 000004
3655 013124 005037 000614
3656 013130 004737 013154
3657 013134 005303
3658 013136 001372
3659 013140 112737 000012 000614
3660 013146 004737 013154
3661 013152 000740
3662 013154 105777 165416
3663 013160 100375
3664 013162 113777 000614 165410
3665 013170 000207
3666
3667
3668
3669
3670 013172 012737 000001 013426
3671 013200 000402
3672 013202 005037 013426
3673 013206 010304
3674 013210 001007
3675 013212 005737 013426

;TTY ENTRY ERROR SUBROUTINE*****
TINER: MOV #MSG40,R4
        JSR PC,TTOUT ;PRINT?
        TST (SP)+ ;POP CHAR COUNT OFF STACK
        SUB #20,(SP) ;RESET SP TO START OF VALUE ROUTINE
        RTS PC ;REDO VALUE ENTRY

;TTY READ SUBROUTINE*****
TTIN: MOV @PSW, -(SP) ;SAVE CURRENT PSW
       BIS #340, @PSW ;SET TO BR7 TO PREVENT INTRPT
       INC @TKS
1$: TSTB @TKS
    BPL 1$
    MOV (SP)+, @PSW ;RESTORE PSW ,OK TO INTRPT NOW
    MOV @TKB,TIB
    BIC #200,TIB
    MOV TIB,TOB ;MOVE CHAR TO TTY OUPUT BFR
    JSR PC,TOG ;ECHO CHARACTER
    RTS PC

;TTY OUTPUT SUBROUTINE*****
TTOUT: MOVB (R4)+,TOB
        CMPB #43,TOB
        BEQ TEX
        CMPB #45,TOB
        BEQ 1$
        JSR PC,TOG
        BR TTOUT
1$: MOVB #15,TOB
    JSR PC,TOG
    MOV #4,R3
2$: CLR TOB
    JSR PC,TOG
    DEC R3
    BNE 2$ ;DO FILLERS
    MOVB #12,TOB
    JSR PC,TOG
    BR TTOUT
TOG: TSTB @TPS
     BPL TOG
     MOVB TOB,@TPB
     RTS PC
TEX:

;OCTAL OUTPUT SUBROUTINE*****
OCTPE: MOV #1,OFL
        BR OCTPE1
OCTP: CLR OFL ;CLEAR FLAG FOR LEADING ZERO
OCTPE1: MOV R3,R4 ;SEE IF NUMBER IS ZERO
        BNE OCTPO ;IF NOT ZERO: BR
        TST OFL ;SEE IF PRINT ALL 0

```

```

3676 013216 001004
3677 013220 004737 013406
3678 013224 000137 013350
3679 013230 032704 100000
3680 013234 001406
3681 013236 012704 000001
3682 013242 004737 013364
3683 013246 000137 013260
3684 013252 005004
3685 013254 004737 013364
3686 013260 010304
3687 013262 006004
3688 013264 006004
3689 013266 006004
3690 013270 006004
3691 013272 000304
3692 013274 004737 013364
3693 013300 010304
3694 013302 006004
3695 013304 000304
3696 013306 004737 013364
3697 013312 010304
3698 013314 006104
3699 013316 006104
3700 013320 000304
3701 013322 004737 013364
3702 013326 010304
3703 013330 006004
3704 013332 006004
3705 013334 006004
3706 013336 004737 013364
3707 013342 010304
3708 013344 004737 013364
3709 013350 012737 000240
3710 013356 004737 013154
3711 013362 000207
3712 013364 042704 177770
3713 013370 001004
3714 013372 005737 013426
3715 013376 001001
3716 013400 000207
3717
3718 013402 005237 013426
3719 013406 052704 000260
3720 013412 010437 000614
3721 013416 004737 013154
3722 013422 010304
3723 013424 000207
3724 013426 000000
3725

      BNE OCTP0
      JSR PC,OCTPG1
      JMP OCTP3
OCTP0: BIT #100000,R4
      BEQ OCTP1
      MOV #1,R4
      JSR PC,OCTPG
      JMP OCTP2
OCTP1: CLR R4
      JSR PC,OCTPG
OCTP2: MOV R3,R4
      ROR R4
      ROR R4
      ROR R4
      ROR R4
      SWAB R4
      JSR PC,OCTPG
      MOV R3,R4
      ROR R4
      SWAB R4
      JSR PC,OCTPG
      MOV R3,R4
      ROL R4
      ROL R4
      SWAB R4
      JSR PC,OCTPG
      MOV R3,R4
      ROR R4
      ROR R4
      JSR PC,OCTPG
      MOV R3,R4
      JSR PC,OCTPG
      MOV #240,TOB
      RTS PC
OCTP3: MOV #240,TOB
      JSR PC,TOG
      RTS PC
OCTPG: BIC #177770,R4
      BNE OCTPG0
      TST OFL
      BNE OCTPG0
      RTS PC
OCTPG0: INC OFL
OCTPG1: BIS #260,R4
      MOV R4,TOB
      JSR PC,TOG
      MOV R3,R4
      RTS PC
OFL: 0
  
```

```

;IF SO: BR
;ELSE PRINT ZERO
;SPACE AND EXIT
;SEE IF MSD = 1
;IF NOT: BR
;PRINT 1
;PRINT 0
;POSITION DIGIT
;PRINT DIGIT 2
;PRINT DIGIT 3
;PRINT DIGIT 4
;PRINT DIGIT 5
;PRINT SPACE
;EXIT
;FIRST CHAR FLAG
  
```

```

3727
3728                ;DATA CHARACTER OUTPUT SUBROUTINE*****
3729
3730 013430 012704 000010 DOUT:  MOV    #10,R4          ;SET NUMBER TO PRINT
3731 013434 110337 000614      MOVB   R3,TOB
3732 013440 105777 165132 1$:   TSTB  @TPS
3733 013444 100375          BPL    1$
3734 013446 132737 000200 000614 BITB   #200,TOB
3735 013454 001404          BEQ    2$
3736 013456 012777 000061 165114 MOV    #061,@TPB
3737 013464 000403          BR     3$
3738 013466 012777 000060 165104 2$:  MOV    #060,@TPB
3739 013474 006337 000614 3$:   ASL    TOB
3740 013500 005304          DEC    R4
3741 013502 001356          BNE   1$
3742 013504 000207          RTS    PC
3743
3744 013506 013703 000700 DOUTD: MOV   TEMP3,R3
3745 013512 000303          SWAB  R3
3746 013514 004737 013430      JSR   PC,DOUT
3747 013520 013703 000700      MOV   TEMP3,R3
3748 013524 004737 013430      JSR   PC,DOUT
3749 013530 000207          RTS    PC
3750
3751                ;TU45 SERIAL NUMBER PRINT SUBROUTINE*****
3752
3753 013532 010304 SNPT:  MOV    R3,R4
3754 013534 000304          SWAB  R4
3755 013536 006004          ROR   R4
3756 013540 006004          ROR   R4
3757 013542 006004          ROR   R4
3758 013544 006004          ROR   R4
3759 013546 004737 013610      JSR   PC,SNPG          ;GET FIRST DIGIT
3760 013552 010304          MOV   R3,R4          ;PRINT
3761 013554 000304          SWAB  R4
3762 013556 004737 013610      JSR   PC,SNPG          ;GET SECOND DIGIT
3763 013562 010304          MOV   R3,R4          ;PRINT
3764 013564 006004          ROR   R4
3765 013566 006004          ROR   R4
3766 013570 006004          ROR   R4
3767 013572 006004          ROR   R4
3768 013574 004737 013610      JSR   PC,SNPG          ;PRINT THIRD DIGIT
3769 013600 010304          MOV   R3,R4
3770 013602 004737 013610      JSR   PC,SNPG          ;PRINT FOURTH DIGIT
3771 013606 000207          RTS    PC          ;EXIT
3772 013610 012737 000260 000614 SNPG: MOV   #260,TOB          ;SET BASE = 0
3773 013616 042704 177760      BIC   #177760,R4      ;MASK DIGIT
3774 013622 050437 000614      BIS   R4,TOB          ;SET ASCII
3775 013626 004737 013154      JSR   PC,TOG          ;TYPE DIGIT
3776 013632 000207          RTS    PC          ;RETURN
    
```

```

3778
3779 ;THIS ROUTINE GETS THE NEW VALUE FOR THE SOFTWARE SWITCH REG
3780
3781 013634 022737 000176 000570 GTSWR: CMP #SWREG,SWR ;BRANCH IF SOFTWARE SWR NOT
3782 013642 001032 BNE 1$ ;INVOKED
3783 013644 004737 013732 JSR PC,SAVE ;SAVE REGISTERS ON THE STACK
3784 013650 012704 016156 MOV #MSWR,R4 ;TYPE 'SWR = '
3785 013654 004737 013054 JSR PC,TTOUT
3786 013660 017703 164704 MOV @SWR,R3 ;GET CURRENT SETTING
3787 013664 004737 013172 JSR PC,OCTPE ;AND TYPE THEM
3788 013670 012704 016166 MOV #MNEW,R4 ;TYPE 'NEW = '
3789 013674 004737 013054 JSR PC,TTOUT
3790 013700 013705 000570 MOV SWR,R5 ;TTR ROUTINE RETURN NEW VALUE TO (R5)
3791 013704 012701 000007 MOV #7,R1 ;LIMIT RESPONSE TO 7 CHARS
3792 013710 012702 177777 MOV #177777,R2 ;BETWEEN 0 AND 177777
3793 013714 012703 000000 MOV #0,R3
3794 013720 004737 012514 JSR PC,TTR ;GET RESPONSE
3795 013724 004737 013754 JSR PC,RESTORE ;RESTORE REGISTERS
3796 013730 000207 1$: RTS PC ;RETURN TO CALLER
3797
3798 ;;ROUTINE TO SAVE REGISTERS ON THE STACK
(1) 013732 010546 .SAVE: MOV %5,-(SP) ;;R5 IS SAVED AT 12(SP)
(1) 013734 010446 MOV %4,-(SP) ;;R4 IS SAVED AT 10(SP)
(1) 013736 010346 MOV %3,-(SP) ;;R3 IS SAVED AT 6(SP)
(1) 013740 010246 MOV %2,-(SP) ;;R2 IS SAVED AT 4(SP)
(1) 013742 010146 MOV %1,-(SP) ;;R1 IS SAVED AT 2(SP)
(1) 013744 010046 MOV %0,-(SP) ;;R0 IS SAVED AT (SP)
(1) 013746 016646 000014 MOV 14(SP),-(SP) ;;PUSH RETURN PC ON THE STACK
(1) 013752 000207 RTS PC ;;RETURN TO CALLER
(1)
3799 ;;ROUTINE TO RESTORE REGISTERS SAVED ON THE STACK
(1) 013754 012666 000014 .RESTORE:MOV (SP)+,14(SP) ;;STORE RETURN PC ON STACK
(1) 013760 012600 MOV (SP)+,%0
(1) 013762 012601 MOV (SP)+,%1
(1) 013764 012602 MOV (SP)+,%2
(1) 013766 012603 MOV (SP)+,%3
(1) 013770 012604 MOV (SP)+,%4
(1) 013772 012605 MOV (SP)+,%5
(1) 013774 000207 RTS PC ;;RETURN
(1)

```

```

3801
3802          :MESSAGE TABLE*****
3803
3804 013776 022445 046524 031460 MSG1: .ASCII'%XTM03-TU45 CONTROL LOGIC TEST PART II (CZTUPB0)';*+B
      014004 052055 032125 020065
      014012 047503 052116 047522
      014020 020114 047514 044507
      014026 020103 042524 052123
      014034 050040 051101 020124
      014042 044511 020040 041450
      014050 052132 050125 030102
      014056      051
3805 014057      045 025052 040452 .ASCII /%***ASSURE TAPE IS AT BOT***/
      014064 051523 051125 020105
      014072 040524 042520 044440
      014100 020123 052101 041040
      014106 052117 025052      052
3806 014113      045 054524 042520 .ASCII /%TYPE <CR> TO TERMINATE RESPONSE & ^C TO RESTART%/
      014120 036040 051103 020076
      014126 047524 052040 051105
      014134 044515 040516 042524
      014142 051040 051505 047520
      014150 051516 020105 020046
      014156 041536 052040 020117
      014164 042522 052123 051101
      014172 022524      043
3807 014175      105 050130 026524 MSG6: .ASCII /EXPT-NOT RECVD#/
      014202 047516 020124 042522
      014210 053103 021504
3808 014214 041522 042126 047055 MSG7: .ASCII /RCVD-NOT EXPT#/
      014222 052117 042440 050130
      014230 021524
3809 014232 047045 047117 042455 MSG9: .ASCII /%NON-EXIST SLAVE #/
      014240 044530 052123 051440
      014246 040514 042526 021440
3810 014254 051045 040505 020104 MSG10: .ASCII /%READ CONT BUS PAR #/
      014262 047503 052116 041040
      014270 051525 050040 051101
      014276 021440
3811 014300 ^53445 044522 042524 MSG11: .ASCII /%WRITE CONT BUS PAR #/
      014306 041440 047117 020124
      014314 052502 020123 040520
      014322 020122      043
3812 014325      040 054105 052120 MSG12: .ASCII / EXPT #/
      014332 021440
3813 014334 05 040 053103 020104 MSG13: .ASCII / RCVD #/
      014342      043
3814 014343      045 051115 041040 MSG14: .ASCII /%MR BITS 4-0#/
      014350 052111 020123 026464
      014356 021460
3815 014360 046445 020122 044502 MSG15: .ASCII /%MR BITS 15-7#/
      014366 051524 030440 026465
      014374 021467
3816 014376 044445 042524 035122 MSG16: .ASCII /%ITER: #/
      014404 021440
3817 014406 052045 020103 044502 MSG18: .ASCII /%TC BITS 12-0 #/
  
```


	014414	051524	030440	026462		
	014422	020060	043			
3818	014425	045	041506	041040	MSG19:	.ASCII /%FC BITS 15-0 #/
	014432	052111	020123	032461		
	014440	030055	021440			
3819	014444	037440	021440		MSG40:	.ASCII / ? #/
3820	014450	022445	047105	020104	MSG41:	.ASCII /%END OF PASS #/
	014456	043117	050040	051501		
	014464	020123	043			
3821	014467	045	042522	044507	MSG44:	.ASCII /%REGISTER START: #/
	014474	052123	051105	051440		
	014502	040524	052122	020072		
	014510	043				
3822	014511	045	042526	052103	MSG45:	.ASCII /%VECTOR ADDRESS: #/
	014516	051117	040440	042104		
	014524	042522	051523	020072		
	014532	043				
3823	014533	045	046524	031460	MSG57:	.ASCII /%TMO3 DRIVE: #/
	014540	042040	044522	042526		
	014546	020072	043			
3824	014551	045	052524	032464	MSG58:	.ASCII /%TU45 SLAVE: #/
	014556	051440	040514	042526		
	014564	020072	043			
3825	014567	045	043		MSG59:	.ASCII /%#/
3826	014571	134	043		MSG60:	.ASCII /\#/
3827	014573	045	042522	047515	MSG62:	.ASCII /%REMOVE TMDP FROM SLAVE TO BE TESTED%/
	014600	042526	052040	042115		
	014606	020120	051106	046517		
	014614	051440	040514	042526		
	014622	052040	020117	042502		
	014630	052040	051505	042524		
	014636	022504	043			
3828	014641	045	040510	042122	MSG63:	.ASCII /%HARDWARE SWR IN USE%/
	014646	040527	042522	051440		
	014654	051127	044440	020116		
	014662	051525	022505	043		
3829	014667	045	020045	051104	MSG64:	.ASCII /% DRIVE #/
	014674	053111	020105	043		
3830	014701	054	046123	053101	MSG65:	.ASCII /,SLAVE #/
	014706	020105	043			
3831	014711	116	052117	047440	MSG66:	.ASCII /NOT ON LINE #/
	014716	020116	044514	042516		
	014724	021440				

```

3833                                     ;TEST HEADER*****
3834
3835 014726 022445 047514 044507 MSLT1: .ASCII /%%LOGIC TEST 1: WRAP 3,NRZ,NORMAL,ODD#/
    014734 020103 042524 052123
    014742 030440 020072 051127
    014750 050101 031440 047054
    014756 055122 047054 051117
    014764 040515 026114 042117
    014772 021504
3836 014774 022445 047514 044507 MSLT2: .ASCII /%%LOGIC TEST 2: WRAP 3,PE,NORMAL,ODD#/
    015002 020103 042524 052123
    015010 031040 020072 051127
    015016 021101 031440 050054
    015022 021505 047516 046522
    015032 046101 047454 042104
    015040 043
3837 015041 045 046045 043517 MSLT3: .ASCII /%%LOGIC TEST 3: WRAP 2,NRZ,NORMAL,ODD#/
    015046 041511 052040 051505
    015054 020124 035063 053440
    015062 040522 020120 026062
    015070 051116 026132 047516
    015076 046522 046101 047454
    015104 042104 043
3838 015107 045 046045 043517 MSLT4: .ASCII /%%LOGIC TEST 4: WRAP 2,PE,NORMAL,ODD#/
    015114 041511 052040 051505
    015122 020124 035064 053440
    015130 040522 020120 026062
    015136 042520 047054 051117
    015144 040515 026114 042117
    015152 021504
3839 015154 022445 047514 044507 MSLT5: .ASCII /%%LOGIC TEST 5: WRAP 1,NRZ,NORMAL,ODD#/
    015162 020103 042524 052123
    015170 032440 020072 051127
    015176 050101 030440 047054
    015204 055122 047054 051117
    015212 040515 026114 042117
    015220 021504
3840 015222 022445 047514 044507 MSLT6: .ASCII /%%LOGIC TEST 6: WRAP 1,PE,NORMAL,ODD#/
    015230 020103 042524 052123
    015236 033040 020072 051127
    015244 050101 030440 050054
    015252 026105 047516 046522
    015260 046101 047454 042104
    015266 043
3841 015267 045 046045 043517 MSLT7: .ASCII /%%LOGIC TEST 7: WRAP 0,NRZ,NORMAL,ODD#/
    015274 041511 052040 051505
    015302 020124 035067 053440
    015310 040522 020120 026060
    015316 051116 026132 047516
    015324 046522 046101 047454
    015332 042104 043
3842 015335 045 046045 043517 MSLT10: .ASCII /%%LOGIC TEST 10: WRAP 0,PE,NORMAL,ODD#/
    015342 041511 052040 051505
    015350 020124 030061 020072
    015356 051127 050101 030040
    015364 050054 026105 047516
    
```

	015372	046522	046101	047454	
	015400	042104	043		
3843	015403	045	046045	043517	MSLT11: .ASCII /%%LOGIC TEST 11: CORE DUMP WRITE (M8906)##/
	015410	041511	052040	051505	
	015416	020124	030461	020072	
	015424	047503	042522	042040	
	015432	046525	020120	051127	
	015440	052111	020105	046450	
	015446	034470	033060	021451	
3844	015454	022445	047514	044507	MSLT12: .ASCII /%%LOGIC TEST 12: CORE DUMP READ (M8906)##/
	015462	020103	042524	052123	
	015470	030440	035062	041440	
	015476	051117	020105	052504	
	015504	050115	051040	040505	
	015512	020104	046450	034470	
	015520	033060	021451		
3845	015524	022445	047514	044507	MSLT13: .ASCII /%%LOGIC TEST 13: EVEN PARITY WRITE (M8933 M8934)##/
	015532	020103	042524	052123	
	015540	030440	035063	042440	
	015546	042526	020116	040520	
	015554	044522	054524	053440	
	015562	044522	042524	024040	
	015570	034115	031471	020063	
	015576	034115	031471	024464	
	015604	043			
3846	015605	045	046045	043517	MSLT14: .ASCII /%%LOGIC TEST 14: EVEN PARITY READ(M8933 M8934)##/
	015612	041511	052040	051505	
	015620	020124	032061	020072	
	015626	053105	047105	050040	
	015634	051101	052111	020131	
	015642	042522	042101	046450	
	015650	034470	031463	046440	
	015656	034470	032063	021451	
3847	015664	022445	047514	044507	MSLT15: .ASCII /%%LOGIC TEST 15: READ REVERSE(M8906)##/
	015672	020103	042524	052123	
	015700	030440	035065	051040	
	015706	040505	020104	042522	
	015714	042526	051522	024105	
	015722	034115	030071	024466	
	015730	043			
3848	015731	045	046045	043517	MSLT16: .ASCII /%%LOGIC TEST 16: CRC CORRECTION SINGLE TRACK,ALL FRAMES##/
	015736	041511	052040	051505	
	015744	020124	033061	020072	
	015752	051103	020103	047503	
	015760	051122	041505	044524	
	015766	047117	051440	047111	
	015774	046107	020105	051124	
	016002	041501	026113	046101	
	016010	020114	051106	046501	
	016016	051505	043		
3849	016021	045	046045	043517	MSLT17: .ASCII /%%LOGIC TEST 17: CRC CORRECTION MULTIPLE BAD TRACKS##/
	016026	041511	052040	051505	
	016034	020124	033461	020072	
	016042	051103	020103	047503	
	016050	051122	041505	044524	
	016056	047117	046440	046125	

016064 044524 046120 020105
016072 040502 020104 051124
016100 041501 051513 043
3850 016105 045 046045 043517
016112 041511 052040 051505
016120 020124 030062 020072
016126 042522 042101 051040
016134 053105 051105 042523
016142 047054 055122 053454
016150 040522 020120 021463

MSLT20: .ASCII /%%LOGIC TEST 20: READ REVERSE,NRZ,WRAP 3#/
/

3852
3853 :TAG MESSAGE
3854
3855 016156 051445 051127 036440 \$MSWR: .ASCII /%SWR = #/
016164 021440
3856 016166 047040 053505 036440 \$MNEW: .ASCII / NEW = #/
016174 021440

3857
3858 .EVEN
3859 ;WRITE BUFFER
3860

3861 WDATA: 016176 000100
3863 016176 177777 -1
(1) 016200 177777 -1
(1) 016202 177777 -1
(1) 016204 177777 -1
(1) 016206 177777 -1
(1) 016210 177777 -1
(1) 016212 177777 -1
(1) 016214 177777 -1
(1) 016216 177777 -1
(1) 016220 177777 -1
(1) 016222 177777 -1
(1) 016224 177777 -1
(1) 016226 177777 -1
(1) 016230 177777 -1
(1) 016232 177777 -1
(1) 016234 177777 -1
(1) 016236 177777 -1
(1) 016240 177777 -1
(1) 016242 177777 -1
(1) 016244 177777 -1
(1) 016246 177777 -1
(1) 016250 177777 -1
(1) 016252 177777 -1
(1) 016254 177777 -1
(1) 016256 177777 -1
(1) 016260 177777 -1
(1) 016262 177777 -1
(1) 016264 177777 -1
(1) 016266 177777 -1
(1) 016270 177777 -1
(1) 016272 177777 -1
(1) 016274 177777 -1
(1) 016276 177777 -1
(1) 016300 177777 -1
(1) 016302 177777 -1
(1) 016304 177777 -1
(1) 016306 177777 -1
(1) 016310 177777 -1
(1) 016312 177777 -1
(1) 016314 177777 -1
(1) 016316 177777 -1
(1) 016320 177777 -1
(1) 016322 177777 -1
(1) 016324 177777 -1

(1)	016326	177777	-1
(1)	016330	177777	-1
(1)	016332	177777	-1
(1)	016334	177777	-1
(1)	016336	177777	-1
(1)	016340	177777	-1
(1)	016342	177777	-1
(1)	016344	177777	-1
(1)	016346	177777	-1
(1)	016350	177777	-1
(1)	016352	177777	-1
(1)	016354	177777	-1
(1)	016356	177777	-1
(1)	016360	177777	-1
(1)	016362	177777	-1
(1)	016364	177777	-1
(1)	016366	177777	-1
(1)	016370	177777	-1
(1)	016372	177777	-1
(1)	016374	177777	-1

3864
3865
3866
3867

;READ BUFFER

3868	016376	000100	RDATA:	0
3870	016376	000000		0
(1)	016400	000000		0
(1)	016402	000000		0
(1)	016404	000000		0
(1)	016406	000000		0
(1)	016410	000000		0
(1)	016412	000000		0
(1)	016414	000000		0
(1)	016416	000000		0
(1)	016420	000000		0
(1)	016422	000000		0
(1)	016424	000000		0
(1)	016426	000000		0
(1)	016430	000000		0
(1)	016432	000000		0
(1)	016434	000000		0
(1)	016436	000000		0
(1)	016440	000000		0
(1)	016442	000000		0
(1)	016444	000000		0
(1)	016446	000000		0
(1)	016450	000000		0
(1)	016452	000000		0
(1)	016454	000000		0
(1)	016456	000000		0
(1)	016460	000000		0
(1)	016462	000000		0
(1)	016464	000000		0
(1)	016466	000000		0
(1)	016470	000000		0
(1)	016472	000000		0

```
(1) 016474 000000 0
(1) 016476 000000 0
(1) 016500 000000 0
(1) 016502 000000 0
(1) 016504 000000 0
(1) 016506 000000 0
(1) 016510 000000 0
(1) 016512 000000 0
(1) 016514 000000 0
(1) 016516 000000 0
(1) 016520 000000 0
(1) 016522 000000 0
(1) 016524 000000 0
(1) 016526 000000 0
(1) 016530 000000 0
(1) 016532 000000 0
(1) 016534 000000 0
(1) 016536 000000 0
(1) 016540 000000 0
(1) 016542 000000 0
(1) 016544 000000 0
(1) 016546 000000 0
(1) 016550 000000 0
(1) 016552 000000 0
(1) 016554 000000 0
(1) 016556 000000 0
(1) 016560 000000 0
(1) 016562 000000 0
(1) 016564 000000 0
(1) 016566 000000 0
(1) 016570 000000 0
(1) 016572 000000 0
(1) 016574 000000 0
```

:WRAP AROUND MESSAGES*****

```
3871
3872
3873
3874 016576 051445 052105 050125 WMSG2: .ASCII /%SETUP ERROR%/
      016604 042440 051122 051117
      016612 021445
3875 016614 050045 052101 047122 WMSG3: .ASCII /%PATRN NUMBER = %/
      016622 047040 046525 042502
      016630 020122 020075 043
3876 016635 045 047516 026516 WMSG4: .ASCII /%NON-EXISTANT DRIVE%/
      016642 054105 051511 040524
      016650 052116 042040 044522
      016656 042526 021445
3877 016662 041445 030523 021440 WMSG6: .ASCII /%CS1 %/
3878 016670 053445 020103 043 WMSG6A: .ASCII /%WC %/
3879 016675 045 040502 021440 WMSG6B: .ASCII /%BA %/
3880 016702 043045 020103 043 WMSG6C: .ASCII /%FC %/
3881 016707 045 051503 020062 WMSG6D: .ASCII /%CS2 %/
      016714 043
3882 016715 045 051504 021440 WMSG6E: .ASCII /%DS %/
3883 016722 042445 020122 043 WMSG6F: .ASCII /%ER %/
3884 016727 045 051501 021440 WMSG6G: .ASCII /%AS %/
3885 016734 041445 020103 043 WMSG6H: .ASCII /%CC %/
```

3886	016741	045	041104	021440	WMSG6I:	.ASCII	/XDB #/
3887	016746	046445	020122	043	WMSG6J:	.ASCII	/XMR #/
3888	016753	045	052104	021440	WMSG6K:	.ASCII	/XDT #/
3889	016760	052045	020103	043	WMSG6L:	.ASCII	/XTC #/
3890	016765	045	047123	021440	WMSG6M:	.ASCII	/XSN #/
3891	016772	041045	042101	042040	WMSG16:	.ASCII	/XBAD DATA#/
	017000	052101	021501				
3892	017004	043445	020072	043	WMSG17:	.ASCII	/XG: #/
3893	017011	045	035102	021440	WMSG20:	.ASCII	/XB: #/
3894	017016	041445	035116	021440	WMSG21:	.ASCII	/XCN: #/
3895	017024	041045	042101	051440	WMSG23:	.ASCII	/XBAD STATUS#/
	017032	040524	052524	021523			
3896	017040	047045	020117	047111	WMSG24:	.ASCII	/XNO INTERRUPT#/
	017046	042524	051122	050125			
	017054	021524					
3897	017056	047045	020117	046103	WMSG25:	.ASCII	/XNO CLOCK UP#/
	017064	041517	020113	050125			
	017072	043					
3898	017073	045	047516	041440	WMSG26:	.ASCII	/XNO CLOCK DOWN#/
	017100	047514	045503	042040			
	017106	053517	021516				
3899	017112	042045	052101	020101	WMSG27:	.ASCII	/XDATA PAT: #/
	017120	040520	035124	043			
3900	017125	045	040502	020104	WMSG28:	.ASCII	/XBAD PREAMBLE#/
	017132	051120	040505	041115			
	017140	042514	043				
3901	017143	045	040502	020104	WMSG29:	.ASCII	/XBAD POSTAMBLE#/
	017150	047520	052123	046501			
	017156	046102	021505				
3902	017162	042445	051117	041440	WMSG31:	.ASCII	/XEOR CLEAR DID NOT CLEAR GOX#/
	017170	042514	051101	042040			
	017176	042111	047040	052117			
	017204	041440	042514	051101			
	017212	043440	022517	043			
3903	017217	040	040520	051124	WMSG32:	.ASCII	/ PATRN #/
	017224	020116	043				
3904							
3905		017230					
3906	017230	000000			PRE:	.EVEN	0
3909	017232	000000					0
(1)	017234	000000					0
(1)	017236	000000					0
(1)	017240	000000					0
(1)	017242	000000					0
(1)	017244	000000					0
(1)	017246	000000					0
(1)	017250	000000					0
(1)	017252	000000					0
(1)	017254	000000					0
(1)	017256	000000					0
(1)	017260	000000					0
(1)	017262	000000					0
(1)	017264	000000					0
(1)	017266	000000					0
(1)	017270	000000					0
(1)	017272	000000					0

(1)	017274	000000	0
(1)	017276	000000	0
(1)	017300	000000	0
(1)	017302	000000	0
(1)	017304	000000	0
(1)	017306	000000	0
(1)	017310	000000	0
(1)	017312	000000	0
(1)	017314	000000	0
(1)	017316	000000	0
(1)	017320	000000	0
(1)	017322	000000	0
(1)	017324	000000	0
(1)	017326	000000	0
(1)	017330	000000	0
(1)	017332	000000	0
(1)	017334	000000	0
(1)	017336	000000	0
(1)	017340	000000	0
(1)	017342	000000	0
(1)	017344	000000	0
(1)	017346	000000	0
(1)	017350	000000	0
3910	017352	000000	0
3913	017354	000000	0
(1)	017356	000000	0
(1)	017360	000000	0
(1)	017362	000000	0
(1)	017364	000000	0
(1)	017366	000000	0
(1)	017370	000000	0
(1)	017372	000000	0
(1)	017374	000000	0
(1)	017376	000000	0
(1)	017400	000000	0
(1)	017402	000000	0
(1)	017404	000000	0
(1)	017406	000000	0
(1)	017410	000000	0
(1)	017412	000000	0
(1)	017414	000000	0
(1)	017416	000000	0
(1)	017420	000000	0
(1)	017422	000000	0
(1)	017424	000000	0
(1)	017426	000000	0
(1)	017430	000000	0
(1)	017432	000000	0
(1)	017434	000000	0
(1)	017436	000000	0
(1)	017440	000000	0
(1)	017442	000000	0
(1)	017444	000000	0
(1)	017446	000000	0
(1)	017450	000000	0
(1)	017452	000000	0

POST:

(1)	017454	000000	0
(1)	017456	000000	0
(1)	017460	000000	0
(1)	017462	000000	0
(1)	017464	000000	0
(1)	017466	000000	0
(1)	017470	000000	0
(1)	017472	000000	0
3914	017474	000000	WBUFF: 0
3915		020106	:=.+410
3916	02C106	000000	RBUFF: 0
3917			
3918		000001	.END

DTBOOT	1243#		
GETANS	767#		
LDPDR	515#		
LPDP11	1268#		
PSPTAG	746#		
REGBOX	132#		
RESLDR	873#		
SAVLDR	855#		
SVTK\$	1141#		
\$CATCH	1124#	1855#	1942
\$CHAIN	89#	1855#	2176
\$CHNMO	105#	1855#	2253
\$CNV16	606#		
\$CNV18	635#		
\$CNV48	704#		
\$CPCHK	897#		
\$CPREG	17#		
\$CPVEC	167#		
\$FPREG	46#		
\$GETAN	771#		
\$KMMRE	347#		
\$KWDR	998#		
\$KW11	929#		
\$LCTRL	2#		
\$LPREG	186#		
\$MAMFO	1176#		
\$MMBIT	207#		
\$MMREG	264#		
\$PDRBI	385#		
\$POWER	433#		
\$PSWBI	147#		
\$RECO	795#		
\$RESLD	876#		
\$RESTO	476#	1855#	3799
\$SAVE	464#	1855#	3798
\$SAVLD	858#		
\$SETTB	508#		
\$SHIFT	489#		
\$SMRE	309#		
\$STINS	8#		
\$STKPT	202#		
\$ST200	1136#		
\$SVTK	1146#		
\$SWOPT	56#		
\$TCDRV	1029#		
\$TCREG	192#		
\$TRAPS	402#		
\$TYPE	518#		
\$TYPEF	592#		
\$UMRE	272#		
\$VECTA	1163#		
.\$ACT1	67#	1855#	1944
.\$EOP	78#	1855#	2300

. ABS. 020110 000

TMO3-TU45 CONTROL LOGIC TEST-PART 11
CZTUPB.P11 13-MAY-80 15:06

MACY11 30A(1052) 13-MAY-80^{6 7} 15:09 PAGE 53-1
CROSS REFERENCE TABLE -- MACRO NAMES

SEQ 0084

ERRORS DETECTED: 0

CZTUPB.CZTUPB/CRF=CZTUPB.P11
RUN-TIME: 14 23 2 SECONDS
RUN-TIME RATIO: 101/41-2.4
CORE USED: 14K (27 PAGES)