EXPLORER 85

LEVEL D ASSEMBLY MANUAL

COPYRIGHT © 1979

BY NETRONICS RESEARCH AND DEVELOPMENT LTD.

RT. 202 NEW MILFORD, CT 06776

ALL RIGHTS RESERVED

SPECIFICATIONS

Level D provides 4K of 2114 RAM, power supply regulation, filtering decoupling components and sockets to expand the "EXPLORER 85" memory to 4K plus the original 256 bytes located in the 8155A. This memory can be located in 4K Blocks from 0000 to EFFF. Level D requires Level B as well as +8VDC C600 MA (unregulated).

Check your kit against the following parts list:

DESCRIPTION	QUANTITY		
Integrated Circuit 2114	8		
IC Socket 18 pin	8		
.01 Disc Capacitor	8		
10 uF Electrolytic Capacitor	1		
Regulator LM340T-5 (or 7805)	1		
Heat Sink	1		
Screw 6-32 x 3/8"	1		
Nut 6-32	1		
Schematic & parts layout information	1		

ASSEMBLY INSTRUCTIONS

- (V V. Install 18 Pin sockets in locations U304-311 (Solder)
- 2. Install the 5Volt regulator (LM340T-5 or 7805) in location Q300. Position the Heat Sink as shown. Secure with 6-32 screw and nut.
- (y) 3. Install 10uF Capacitor in location C300, note polarity (Solder)
- (W) 4. Install .01 Disc Capacitors in locations C306-313 (Solder)
- () 5. Insert the 2114's into IC Sockets U304-311. Note direction of Pin #1
- () 6. The following chart describes the address selection jumpers required in position SW201. The address selections are valid in 4K Blocks. An optional 8 position dip switch may be installed at location SW201 if these addresses are to be modified frequently.

Note: There are two address charts. The first is for Revision B Mother Boards and the other is for all subsequent revisions.

FOR REVISION B MOTHERBOARDS

FOR ALL SUBSEQUENT REVISION MOTHER BOARDS

FOR PC BOARDS - REVISION B

SW201	JUMPERS

ADDRESS (8K Block)	8	7	6	5	4	3	2	1
0000-0FFF	TAI			TN	7.3.1			7.1
1000-1FFF	IN	-	-	IN	IN		-	IN
2000-2FFF	IN IN	-	-	IN	IN	 T.M	IN	-
3000-3FFF	IN	-	-	IN	-	IN	-	IN
4000-4FFF	IN	-	- IN	ĮΝ	11.	IN	IN	
5000-5FFF	I N	-	IN	-	IN	-		LN
6000-6FFF	1 N	-	IN	-	IN	- TAT	IN	~
7000-7FFF	IN	_	IN IN	-	b***	IN	~: TN:	IN
8000-8FFF	1 :N -	IN		- T.N.	 T N	P_{λ}	IN	- T 4 1
9000-9FFF	-	IN	-	IN	IN	-	- T N 1	IN
A000-AFFF	-	IN	-	IN	$1\mathrm{N}$	- TM	IN	- T):
B000-BFFF	-		-	IN	~	IN	- T.11	IN
COOO-CFFF	-	IN	7.1.	IN	-	IN	IN	-
DOOO-DFFF	-	IN	IN		1.//	-	-	IN
E000-EFFF	-	IN	IN	-	IN	731	IN	-
		IN	IN	CVCTEM	E COM	IN	-	IN
	NOT A	IBSEQUEN				SW201	JUMPER	lS.
<u>FOI</u>						<u>SW201</u>	JUMPER 2	S1
FOOO-FFFF FOO ADDRESS (8K Block)	R ALL SU	IBSEQUEN	T REVIS	SION PC	BOARDS			
FOI ADDRESS (8K Block)	R ALI. SU	IBSEQUEN	T REVIS	SION PC	BOARDS	3		1
ADDRESS (8K Block) 0000-0FFF	R ALL SU 8 IN	IBSEQUEN	T REVIS	SION PC 5 IN	BOARDS 4	3 IN	2	1
ADDRESS (8K Block) 0000-0FFF 1000-1FFF	R ALL SU 8 IN IN	IBSEQUEN	T REVIS	SION PC 5 IN IN	BOARDS 4	3		1 IN
FOI ADDRESS (8K Block) 0000-0FFF 1000-1FFF 2000-2FFF	R ALL SU 8 IN IN IN	IBSEQUEN	6 -	SION PC 5 IN IN IN	BOARDS 4 - - IN	IN IN	2 - 1N -	1 IN
ADDRESS (8K Block) 0000-0FFF 1000-1FFF 2000-2FFF 3000-3FFF	R ALL SU 8 IN IN IN IN IN	IBSEQUEN	6	SION PC 5 IN IN	BOARDS 4	IN IN	2	IN -
ADDRESS (8K Block) 0000-0FFF 1000-1FFF 2000-2FFF 3000-3FFF 4000-4FFF	R ALL SU 8 IN IN IN IN IN IN	IBSEQUEN	6	SION PC 5 IN IN IN IN	BOARDS 4 IN IN	IN IN -	2 - 1N - IN	IN -
ADDRESS (8K Block) 0000-0FFF 1000-1FFF 2000-2FFF 3000-3FFF 4000-4FFF 5000-5FFF	IN IN IN IN IN IN IN	IBSEQUEN	6	SION PC 5 IN IN IN IN	BOARDS 4 IN IN -	IN IN	2 - 1N - IN	IN - IN - IN -
FOI ADDRESS (8K Block) 0000-0FFF 1000-1FFF 2000-2FFF 3000-3FFF 4000-4FFF 5000-5FFF 6000-6FFF	R ALL SU 8 IN	IBSEQUEN	6	SION PC 5 IN IN IN IN	BOARDS 4 IN IN IN IN	IN IN - IN IN	2 - 1N - IN - IN	IN - IN - IN -
ADDRESS (8K Block) 0000-0FFF 1000-1FFF 2000-2FFF 3000-3FFF 4000-4FFF 5000-5FFF 6000-6FFF 7000-7FFF	IN IN IN IN IN IN IN	7	6	SION PC 5 IN IN IN IN	BOARDS 4 IN IN -	3 IN IN	2 - 1N - IN	IN IN IN IN
ADDRESS (8K Block) 0000-0FFF 1000-1FFF 2000-2FFF 3000-3FFF 4000-4FFF 5000-5FFF 6000-6FFF 7000-7FFF	IN I	7 IN	6	SION PC 5 IN IN IN IN	BOARDS 4 IN IN IN IN IN IN	3 IN IN - IN IN - IN IN	2 - 1N - IN - IN -	IN IN IN IN IN
ADDRESS (8K Block) 0000-0FFF 1000-1FFF 2000-2FFF 3000-3FFF 4000-4FFF 5000-5FFF 6000-6FFF 7000-7FFF 8000-8FFF 9000-9FFF	IN	IBSEQUEN 7 IN IN	6	SION PC 5 IN IN IN IN IN IN	BOARDS 4 IN IN IN IN IN IN IN	3 IN IN	2 - 1N - IN - IN	IN - IN - IN - IN - IN -
ADDRESS (8K Block) 0000-0FFF 1000-1FFF 2000-2FFF 3000-3FFF 4000-4FFF 5000-5FFF 6000-6FFF 7000-7FFF 8000-8FFF	IN	JESEQUEN 7 IN IN	6	SION PC 5 IN IN IN IN	BOARDS 4 IN IN IN IN IN IN IN IN IN	3 IN IN IN IN IN IN -	2 - 1N - IN - IN - IN	IN - IN - IN - IN - IN -
ADDRESS (8K Block) 0000-0FFF 1000-1FFF 2000-2FFF 3000-3FFF 4000-4FFF 5000-5FFF 6000-6FFF 7000-7FFF 8000-8FFF 9000-9FFF A000-AFFF B000-BFFF	IN	IBSEQUEN 7 IN IN IN	6	SION PC 5 IN IN IN IN IN IN IN	BOARDS 4 IN	3 IN IN - IN IN - IN IN - IN - IN IN	2 - 1N - IN - IN - IN	IN -
ADDRESS (8K Block) 0000-0FFF 1000-1FFF 2000-2FFF 3000-3FFF 4000-4FFF 5000-5FFF 6000-6FFF 7000-7FFF 8000-8FFF 9000-9FFF A000-AFFF B000-BFFF C000-CFFF	IN	JESEQUEN 7 IN IN IN IN	6	SION PC 5 IN IN IN IN IN IN IN	BOARDS 4 IN IN IN IN IN IN IN IN	3 IN IN IN IN IN IN IN - IN IN	2	IN -
ADDRESS (8K Block) 0000-0FFF 1000-1FFF 2000-2FFF 3000-3FFF 4000-4FFF 5000-5FFF 6000-6FFF 7000-7FFF 8000-8FFF 9000-9FFF A000-AFFF	IN	IBSEQUEN 7 IN IN IN IN IN IN	6	SION PC 5 IN IN IN IN IN IN IN	BOARDS 4 IN IN IN IN IN IN IN IN	3 IN IN - IN IN - IN IN - IN - IN IN	2 - 1N - IN - IN - IN	IN IN IN IN IN IN IN IN

| ტ 6

SW201

The following additional wire jumpers are required to be added to your Level A kit if your mother board is labled Revision B. Use the #30 gauge wire and stripping tool supplied with your Level A kit to make the connections on the bottom of the board. Strip the insulation about 3/16" and wrap the wire around the appropriate terminal and solder dress the wire as neatly as possible (i.e. square corners, etc.).

- (1) Connect U205 pin 4 to U115 pin 8.
- (2) Connect SW201 pin 14 to U115 pin 10.
- (3) Connect U210 pin 8 to U115 pin 9.
- (4) Connect U115 pin 11 to U115 pin 12.

These changes are reflected in your schematics.

WARRANTY: All components of this kit are warranteed for six months from the date of shipment. Defective components will be replaced free of charge if returned within six months with \$1.00 each to cover testing and return postage. Return parts in a suitable package and ship insured to Netronics Research & Development Limited Route 202, New Milford, Connecticut 06776, attention: Service Department, with a letter explaining the defect. Any parts received damaged due to poor packaging will be returned. (i.e., DO NOT ship IC's in envelopes via the mail).

IN CASE OF DIFFICULTY: After having carefully checked your work and you still have difficulty getting your Explorer to work, the Factory Service Department will repair, fully test, and return your system for a flat fee (see below). This covers all parts, except parts destroyed by your negligence, (i.e., IC's installed backwards, broken, etc.), and return postage. Package the unit (less cabinet) carefully and return insured with a letter describing the difficulty.

If your system includes other level components, please see the instruction book for fees which apply to the further expanded systems. If any components are added which are not part of a Netronics kit you will be advised of the service charge prior to any work being done. If you have added any "Levels" to your system (using your own parts) it would be advisable to purchase the appropriate assembly manual, which will contain any factory modifications or updates, prior to returning your unit.

SCHEDULE OF IN WARRANTY FACTORY TROUBLE SHOOTING PRICES*

Level A	\$12.50	Flat	Fee
Hex Keypad/Display	7.00	11	**
Level A & B	16.50	11	**
Level A & B & D and/or E	20.00	**	11
Power Supply	6.50	11	11
ASCII Keyboard	7.00	11	11
Video Display Board	9.50	11	11

*Covers cost of all parts except those destroyed by the customer.

These prices are not valid for levels added using parts not obtained from Netronics. If you have parts not supplied by Netronics, send your unit and ask for a quotation.





