

11/21+
RL01/02

RL01/02 DRIVE TEST 2
CNRLJAO

COPYRIGHT (c) 1979-83
AH-T750A-MC
FICHE 1 OF 1

APR 1984
digital
Made In USA

This microfiche card contains a grid of frames. The frames are arranged in approximately 15 rows and 10 columns. Each frame contains a different view of data, likely from a drive test. The data is presented in a structured format, often with columns and rows of text or numbers. Some frames include diagrams or graphs, such as a graph with a curve in the lower right quadrant of the grid. The overall appearance is that of a technical report or test log.

11/21+
RL01/02

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53

000001

000000

.TITLE CNRLJA RLO1/2 DRIVE TEST 2
.PART2**1
.ENABLE ABS
.ENABLE AMA
.NLIST TOC
.REM @

IDENTIFICATION

PRODUCT CODE: AC T749A MC
PRODUCT NAME: CNRLJAO RLO1/2 DRIVE TEST 2
PRODUCT DATE: DECEMBER 19, 1983
MAINTAINER: ISS DIAGNOSTIC SERVICES
AUTHOR: JAMES S. DOUCETTE

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1983, DIGITAL EQUIPMENT CORPORATION

REVISION HISTORY

CHANGES MADE TO CZRLJBO IN PRODUCING CNRLJAO FOR THE SBC-11/21. (FALCON-PLUS).
DEC. 19, 1983. CHANGES ARE IDENTIFIED BY ";JSD REV A'.

1. CHANGED THE FORM OF THE ARGUMENT TO ALL "DELAY" MACRO CALLS FROM @<VALUE> TO <VALUE>. THE FORMER GAVE ASSEMBLY ERRORS UNDER THE VAX/VMS DEVELOPMENT ENVIRONMENT (MCR MAC).
2. CHANGED THE GENERAL OPERATING PRIORITY OF THE PROGRAM FROM LEVEL 7 TO LEVEL 6 TO ALLOW THE "BREAK" KEY TO INVOKE ODT. (THE TRAP HANDLER AND DEVICE INTERRUPT SERVICE ROUTINES STILL RUN BRIEFLY AT LEVEL 7).
3. SET VECTOR 140 WITH THE ADDRESS OF ODT IN ROM (170000).

67
68
69
70
71
72
73
74
75
76

TABLE OF CONTENTS

78		
79		
80		
81		
82		
83		
84		
85		
86		
87		
88		
89		
90		
91		
92		
93		
94		
95		
96		
97		
98		
99		
100		
101		
102		
103		
104		
105		
106		
107		
108		
109		
110		
111		
112		
113		
114		
115		
116		
117		
118		
119		
120		
121		
122		
123		
124		
	1.0	GENERAL INFORMATION
	1.1	PROGRAM ABSTRACT
	1.1.1	STRUCTURE OF PROGRAM
	1.1.2	DIAGNOSTIC INFORMATION
	1.2	SYSTEM REQUIREMENTS
	1.2.1	HARDWARE REQUIREMENTS
	1.2.2	SOFTWARE REQUIREMENTS
	1.3	RELATED DOCUMENTS AND STANDARDS
	1.4	DIAGNOSTIC HIERARCHY PREREQUISITES
	1.5	ASSUMPTIONS
	2.0	OPERATING INSTRUCTIONS
	2.1	HOW TO RUN THIS DIAGNOSTIC
	2.1.1	THE FIVE STEPS OF EXECUTION
	2.1.2	SAMPLE RUN-THROUGH
	2.2	CHAIN MODE OPERATION
	2.3	DETAILS OF COMMANDS AND SYNTAX
	2.3.1	TABLE OF COMMAND VALIDITY
	2.3.2	COMMAND SYNTAX
	2.4	EXTENDED P-TABLE DIALOGUE
	2.5	HARDWARE PARAMETERS
	2.6	SOFTWARE PARAMETERS
	3.0	ERROR INFORMATION
	3.1	ERROR REPORTING
	3.1.2	SPECIFIC RESULT MESSAGES
	3.1.3	OTHER MESSAGES
	3.2	ERROR HALTS
	4.0	PERFORMANCE AND PROGRESS REPORTS
	4.1	PERFORMANCE REPORTS
	4.2	PROGRESS REPORTS
	5.0	DEVICE INFORMATION TABLES
	6.0	TEST SUMMARIES

1.0 GENERAL INFORMATION

1.1 PROGRAM ABSTRACT

1.1.1 STRUCTURE OF PROGRAM

THIS DIAGNOSTIC COMPATIBLE WITH BOTH CNDP+ AND ACT. IT CAN BE RUN STANDALONE UNDER CNDP+, AND CAN BE CHAINED UNDER CNDP+, ACT AND APT IN ACT MODE (SEE 2.2 "CHAIN MODE OPERATION" FOR DETAILS OF CHAINING PROCEDURE). IT IS A SINGLE PROGRAM FROM THE STANDPOINT OF THE DIAGNOSTIC USER, WHICH AT RUN TIME IS APPENDED TO A COMMON FRONT-END PIECE OF SUPERVISOR SOFTWARE THROUGH WHICH THE DIAGNOSTICS PROGRAM INTERFACES TO THE ENVIRONMENT AS IT EXECUTES. (IN THIS DOCUMENT, "CNDP+" REFERS TO THE FALCON SPECIFIC XXDP+ SYSTEM).

WHEN THIS DIAGNOSTIC IS STARTED AT ADDRESS 200, CONTROL GOES FIRST TO THE SUPERVISOR PORTION, WHICH WILL ASK CERTAIN "HARD CORE" QUESTIONS ABOUT THE ENVIRONMENT. THEN IT WILL ENTER COMMAND MODE, INDICATED BY A PROMPT CHARACTER (DR>). AT COMMAND MODE THE OPERATOR MAY ENTER ANY OF SEVERAL COMMANDS AS DESCRIBED IN 2.0 "OPERATING INSTRUCTIONS".

THE DIAGNOSTIC PROGRAM IS LOADED IN THE LOWER 8K OF MEMORY. THE DIAGNOSTIC SUPERVISOR CODING OCCUPIES 6.25K OF THE UPPER PART OF MEMORY JUST BELOW THE CNDP+ MONITOR WHICH RESIDES IN THE UPPERMOST 1.5K OF MEMORY SPACE.

1.1.2 DIAGNOSTIC INFORMATION

THIS PROGRAM TESTS AND EXERCISES RL01/02 DISK DRIVES RL11/RLV11 CONTROLLERS (4 DRIVES PER CONTROLLER). THE ENTIRE PROGRAM IS RUN ON THE FIRST DRIVE BEFORE STARTING ON THE SECOND. THE PROGRAM STARTS BY TESTING THE SIMPLEST FUNCTIONS FIRST USING THE LOGIC TESTED IN EARLIER TESTS TO TEST MORE COMPLEX FUNCTIONS.

THIS PROGRAM TESTS THE RL01/02 OUTER AND INNER GUARD BAND DETECTION. SEEK OPERATIONS UNDERGO A BROAD RANGE OF TESTING USING SINGLE DIFFERENCES, PROCEEDING TO SEEKS OF GREATER DIFFERENCES.

1.2 SYSTEM REQUIREMENTS

126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177

179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233

1.2.1 HARDWARE REQUIREMENTS

- * SBC-11/21+ PROCESSOR, 28KW MEMORY, JUMPERED FOR MEMORY MAP C
- * CONSOLE DEVICE (LA30,LA36,VT50,ETC.)
- * 1 OR 2 RL11/RLV11 CONTROLLER(S) WITH:
 - 1 - 8 RL01 DRIVES WITH RL01K CARTRIDGES CONTAINING A 'BAD SECTOR FILE'
 - 1 - 8 RL02 DRIVES WITH RL02K CARTRIDGES CONTAINING A 'BAD SECTOR FILE'
- * CNDP+ (XXDP+) LOAD DEVICE (RL02, RX02, ETC.)
- * LINE PRINTER (OPTIONAL)

1.2.2 SOFTWARE REQUIREMENTS

CNRLJAO RL01/02 DRIVE TEST PART 2 (FORMERLY CZRLDB0)

1.3 RELATED DOCUMENTS AND STANDARDS

RL01/02 DISK SUBSYSTEM USER'S GUIDE (EK-RL01 UG 002)
XXDP+/SUPERVISOR USER'S MANUAL

1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

THE RL01/02 SUBSYSTEM SHOULD HAVE SUCCESSFULLY RUN THE FOLLOWING PROGRAMS:

CVRLAB0	RLV11 RL01 DISKLESS TEST (RLV11 ONLY)
CNRLGA0	RL11/RLV11 RL01/02 CONTROLLER TEST (PART 1)
CNRLMA0	RL11/RLV11 RL01/02 CONTROLLER TEST (PART 2)
CNRLIA0	RL01/02 DRIVE TEST (PART 1)

1.5 ASSUMPTIONS

THE HARDWARE OTHER THAN THE RL01/02 SUBSYSTEM IS ASSUMED TO WORK PROPERLY. FALSE ERRORS MAY BE REPORTED IF THE PROCESSOR, ETC., DO NOT FUNCTION PROPERLY.

2.0 OPERATING INSTRUCTIONS

2.1 HOW TO RUN THIS DIAGNOSTIC

2.1.1 THE FIVE STEPS OF EXECUTION

THIS DIAGNOSTIC PROGRAM SHOULD BE LOADED AND STARTED USING NORMAL XXDP+ PROCEDURES. START THE EXECUTION OF THE CNDP+ MONITOR BY USING THE APPROPRIATE BOOTSTRAP PROGRAM. THE MONITOR WILL PRINT A MESSAGE IDENTIFYING ITSELF AND REQUESTING THAT THE CURRENT DATE BE ENTERED. AN EXAMPLE OF THIS MESSAGE IS GIVEN BELOW FOR THE CNDP+ MONITOR:

```
CNMDYAO CNDP+ DY MONITOR
BOOTED VIA UNIT 0
ENTER DATE (DD-MMM-YY):
```

AFTER THE DATE HAS BEEN ACCEPTED BY THE MONITOR THE RESTART ADDRESS OF THE MONITOR IS PRINTED. THEN THE FOLLOWING TWO QUESTIONS ARE ASKED:

```
50 HZ ? N
LSI ? N
```

THE DEFAULTS ARE BOTH "NO". TYPE "R" AND THE PROGRAM NAME TO RUN THE PROGRAM. DO NOT TYPE THE EXTENSION.

WHEN THIS DIAGNOSTIC IS STARTED THE FOLLOWING STEPS WILL OCCUR:

```
*****
* STEP 1 *
*****
```

THE DIAGNOSTIC WILL ISSUE THE PROMPT "DR>". FROM THIS POINT UNTIL THE TIME WHEN YOU RESTART CNDP+, YOU WILL BE TALKING TO THE DIAGNOSTIC NOT CNDP+. WE WILL REFER TO THE PRESENCE OF THIS PROMPT AS BEING IN DIAGNOSTIC COMMAND MODE, AS OPPOSED TO CNDP+ COMMAND MODE.

AT THIS POINT YOU WILL ENTER A "START" COMMAND. THIS IS NOT THE SAME AS THE CNDP+ "START" COMMAND, WHICH YOU ALREADY ISSUED IN RESPONSE TO THE CNDP+ DOT PROMPT. THIS "START" COMMAND CAN TAKE A NUMBER OF SWITCHES AND FLAGS (ALL OPTIONAL) AND THE DETAILS OF THESE ARE SET FORTH IN 2.3 "DETAILS OF COMMANDS AND SYNTAX". HOWEVER, IN ORDER TO USE THE PROGRAM, ALL YOU NEED TO SAY IS SOMETHING LIKE THIS:

```
STA/PASS:1/FLAGS:HOE
```

235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285

287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341

THINGS TO NOTE HERE:

1. ONLY THE FIRST THREE CHARACTERS OF THIS OR ANY COMMAND AT THE "DR>" LEVEL NEED TO BE TYPED.
2. THE "PASS" SWITCH SPECIFIES HOW MANY PASSES YOU DESIRE. A PASS CONSISTS OF RUNNING THE FULL DIAGNOSTIC AGAINST ALL UNITS BEING TESTED (THIS WILL BE EXPLAINED SHORTLY). ONE PASS IS SPECIFIED IN THE ABOVE EXAMPLE.
3. THE "FLAGS" SWITCH MAY SPECIFY ANY OF A NUMBER OF FLAGS, BUT THE MAIN USEFUL ONES ARE:

PNT	PRINT NUMBER OF TEST BEING EXECUTED
LOE	LOOP ON ERROR
HOE	HALT ON ERROR
IER	INHIBIT ERROR PRINTOUT

THE HOE FLAG IS SPECIFIED IN THE ABOVE EXAMPLE (WE'LL SEE WHY SHORTLY).

* STEP 2 *

WHEN YOU HAVE TYPED IN A "START" COMMAND, THE DIAGNOSTIC WILL COME BACK WITH THE QUESTION "# UNITS?" TO WHICH YOU SHOULD RESPOND BY TYPING IN THE NUMBER OF DEVICES YOU WISH TO TEST.

A WORD OF WARNING HERE: THE NUMBER OF UNITS DEPENDS ON THE TARGET DEVICE OF THE DIAGNOSTIC. FOR EXAMPLE, IF THE DIAGNOSTIC IS DIRECTED AT A DISK DRIVE, THEN THE NUMBER OF UNITS WOULD BE THE NUMBER OF DRIVES TO BE TESTED. WHEREAS IF THE DIAGNOSTIC WAS DIRECTED AT THE DISK CONTROLLER, THEN THE NUMBER OF UNITS WOULD BE THE NUMBER OF CONTROLLERS. THE TARGET DEVICE OF A DIAGNOSTIC CAN ALWAYS BE DETERMINED BY INSPECTING THE "HEADER" STATEMENT NEAR THE BEGINNING OF THE SOURCE CODE. ONE OF THE OPERANDS OF THIS "HEADER" STATEMENT SHOULD BE THE DEVICE TYPE OF THE DIAGNOSTIC.

* STEP 3 *

WHEN YOU HAVE TYPED IN THE NUMBER OF UNITS TO BE TESTED, THE DIAGNOSTIC WILL ASK YOU THE "HARDWARE QUESTIONS". THE ANSWERS TO THESE QUESTIONS ARE USED TO BUILD TABLES IN CORE, CALLED "HARDWARE P-TABLES". ONE HARDWARE P-TABLE WILL BE BUILT FOR EACH UNIT TO BE TESTED.

THERE ARE SEVERAL HARDWARE QUESTIONS AND THE ENTIRE SERIES WILL BE POSED N TIMES, WHERE N IS THE NUMBER OF UNITS.

11
343 THIS REPRESENTS A NEW PHILOSOPHY IN DIAGNOSTIC ENGINEERING.
344 DIAGNOSTICS IN THE FUTURE WILL NOT BE WRITTEN TO AUTOSIZE OR ASSUME
345 STANDARD ADDRESSES: INSTEAD, THEY WILL ASK THE OPERATOR FOR ALL
346 THE INFORMATION THEY NEED TO TEST THE DEVICE.
347
348
349

350 *****
351 * STEP 4 *
352 *****

353 AFTER YOU HAVE ANSWERED ALL THE HARDWARE QUESTIONS (SEC 2.5) FOR
354 ALL THE UNITS, YOU WILL BE ASKED "CHANGE SW?" IF YOU WANT TO BE
355 ASKED THE SOFTWARE QUESTIONS THAT DETERMINE THE BEHAVIOR OF THIS
356 PROGRAM, TYPE "Y". IF YOU WANT TO TAKE ALL THE DEFAULTS TO THESE
357 QUESTIONS, TYPE "N". IF YOU TYPE "Y" YOU WILL BE ASKED THE
358 SOFTWARE QUESTIONS (SEC 2.6), AND THE ANSWERS WILL BE PUT INTO THE
359 SOFTWARE P-TABLE IN THE PROGRAM. THE SERIES OF QUESTIONS WILL BE
360 ASKED JUST ONCE, REGARDLESS OF THE NUMBER OF UNITS TO BE TESTED.
361
362
363

364 *****
365 * STEP 5 *
366 *****
367

368 AFTER YOU HAVE ANSWERED THE SOFTWARE QUESTIONS, THE DIAGNOSTIC WILL
369 BEGIN TO EXECUTE THE HARDWARE TEST CODE. THERE ARE SEVERAL THINGS
370 THAT CAN HAPPEN NEXT, DEPENDING ON WHETHER A HARDWARE ERROR IS
371 ENCOUNTERED AND ALSO ON WHAT SWITCH VALUES YOU SELECTED ON THE
372 START COMMAND. CONSIDER THE POSSIBILITIES:
373

- 374 1. IF NO ERROR IS ENCOUNTERED, THEN THE DIAGNOSTIC WILL SIMPLY
375 EXECUTE THE DESIRED NUMBER OF PASSES AND RETURN TO COMMAND
376 MODE (PROMPT DR>).
377
- 378 2. IF AN ERROR IS ENCOUNTERED, THEN ONE OF THREE THINGS
379 HAPPENS, DEPENDING ON THE SETTINGS OF THE HOE AND LOE
380 FLAGS.
381

382 HOE SET: THE ERROR WILL BE REPORTED ON THE CONSOLE AND THE
383 DIAGNOSTIC WILL RETURN TO COMMAND MODE.
384

385 LOE SET: THE DIAGNOSTIC WILL LOOP ENDLESSLY ON THE BLOCK
386 OF CODE THAT DETECTED THE ERROR.
387

388 NEITHER HOE NOR LOE SET: THE ERROR WILL BE REPORTED ON THE
389 CONSOLE AND NORMAL EXECUTION WILL RESUME AS IF NO ERROR HAD
390 OCCURRED.
391
392

2.1.2 SAMPLE RUN THROUGH

394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442

LET'S SEE HOW ALL THIS WORKS IN A REAL SITUATION. RECALL THAT WE ENTERED THE COMMAND 'STA/PASS:1/FLAGS:HOE'. THIS WOULD BE A VERY TYPICAL WAY TO RUN THE DIAGNOSTIC. IF NO ERRORS ARE ENCOUNTERED, THE SINGLE REQUESTED PASS WILL BE EXECUTED AND THE PROMPT WILL BE RE ISSUED.

IF AN ERROR IS ENCOUNTERED, THE ERROR WILL BE REPORTED AND THE PROMPT WILL BE REISSUED (BECAUSE THE HOE FLAG IS SET). AT THIS POINT THERE ARE FOUR DIFFERENT WAYS YOU CAN GET THE PROGRAM GOING AGAIN:

1. ISSUE ANOTHER "START" COMMAND (THUS GOING THRU ALL OF STEPS 1, 2, 3, 4, AND 5 AGAIN)
2. ISSUE A "RESTART" COMMAND (SAME AS START COMMAND EXCEPT THAT THE HARDWARE QUESTIONS ARE NOT ASKED)
3. ISSUE A "CONTINUE" COMMAND (EXECUTION WILL RESUME AT THE BEGINNING OF THE PARTICULAR HARDWARE TEST (MOST DIAGNOSTICS CONSIST OF A NUMBER OF THESE) THAT IT WAS IN WHEN THE ERROR HALT OCCURRED. NO QUESTIONS ASKED.
4. ISSUE A "PROCEED" COMMAND: EXECUTION WILL RESUME AT THE INSTRUCTION FOLLOWING THE ERROR REPORT (THIS IS A SPECIAL COMMAND AND CAN BE ISSUED ONLY AT A HALT ON ERROR).

THE MOST TYPICAL THING TO DO HERE IS TO ISSUE THE PROCEED, BUT WITH DIFFERENT FLAG SETTINGS. PROBABLY YOU WOULD WANT TO SAY:

PRO/FLAGS:IER:LOE:HOE=0

THIS WILL DO THE FOLLOWING:

1. TURN ON THE IER (INHIBIT ERROR PRINTOUT) FLAG
2. TURN ON THE LOE FLAG
3. TURN OFF THE HOE FLAG
4. RESUME EXECUTION AT INSTRUCTION AFTER ERROR REPORT

THE DIAGNOSTIC WILL NOW LOOP ON THE BLOCK OF CODE THAT DETECTED AND REPORTED THE ERROR, BUT NO ERROR PRINTOUT WILL OCCUR. THUS YOU CAN STUDY THE ERROR OR SCOPE IT OR WHATEVER.

444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476

WHEN YOU'VE SEEN ENOUGH, YOU MAY HIT CONTROL/C. THIS WILL TAKE YOU OUT OF THE LOOP AND PUT YOU BACK INTO COMMAND MODE. YOU NOW HAVE THREE CHOICES:

1. START
2. RESTART
3. CONTINUE

LET'S SAY YOU'VE REPAIRED THE DEFECT FOUND ABOVE AND WANT TO FINISH RUNNING THE DIAGNOSTIC. YOU WOULD TYPE

CON/FLAGS:HOE:IER=0:LOE=0

THIS WILL RESTORE THE FLAGS TO THEIR ORIGINAL VALUES AND RESUME EXECUTION AT THE BEGINNING OF THE HARDWARE TEST YOU WERE IN. IF THE ERROR DOES NOT RECUR, THE EXECUTION WILL FLOW RIGHT ON THRU TO THE NEXT ERROR OR TO END OF PASS.

IF AT END OF PASS YOU WANT TO RUN THE DIAGNOSTIC AGAIN, YOU HAVE TWO CHOICES:

1. START
2. RESTART

YOU WOULD CHOOSE ONE, DEPENDING ON WHETHER YOU WANTED TO ANSWER THE HARDWARE QUESTIONS AGAIN.

478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529

THE FULL PRINT OUT FROM THE ABOVE DIALOGUE MIGHT LOOK LIKE THIS
(O=OPERATOR, D=DIAGNOSTIC):

	BY WHOM ENTERED:
.R CNRLJAO	O
DRS LOADED	D
DIAG. RUN-TIME SERVICES REV. D APR 79	D
CNRLJ-A-0	D
CNRLJ TESTS OUTER & INNER GUARD	D
BAND DETECTION AND SEEK OPERATIONS	
UNIT IS RLO1, RLO2	D
DR>STA/PASS:1/FLAGS:HOE	C.O
 # UNITS (D) ? 2	 D.O
UNIT 0	D
RL11 (L) Y ?	D.O
BUS ADDRESS (O) 174400 ?	D.O
VECTOR (O) 160 ?	D.O
DRIVE (O) 0 ?	D.O
DRIVE TYPE = RLO1 (L) Y ?	D.O
BR LEVEL (O) 5 ?	D.O
 UNIT 1	 D
RL11 (L) Y ?	D.O
BUS ADDRESS (O) 174400 ?	D.O
VECTOR (O) 160 ?	D.O
DRIVE (O) 0 ? 1	D.O
DRIVE TYPE = RLO1 (L) ? N	D.O (N=RLO2)
BR LEVEL (O) 5 ?	D.O
 CHANGE SW (L) ? Y	 D.O
USE ALL CYL (L) N ?	D.O
USE ALL SECT (L) N ?	D.O
LOW SEEK LIMIT (L) N ?	D.O
UPPER SEEK LIMIT (L) N ?	D.O
USE ONLY ONE SURF (L) N ?	D.O
INPUT ERROR LIMIT (D) 20 ?	D.O
DATA CMP ERR 1T (D) 10 ?	D.O
 CNRLJ HRD ERR 00004 TST J03 SUB 002 PC:004130	
ERR HLT	
 DR>PRO/FLAGS:IER:LOE:HOE=0	 D.O

531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583

AT THIS POINT THE DIAGNOSTIC IS LOOPING ON THE
ERROR WITHOUT PRINTING ANYTHING. YOU CAN SCOPE
THE ERROR UNTIL YOU HAVE LOCATED IT, THEN ↑C OUT.

```
↑C                                0
DR>CON/FLAGS:HOE:IER:LOE=0      D.0
CHANGE SW (L) ? N                D.0
CNRLJ EOP 1                       D
↑C
DR>RESTART/PASS:1                D.0
CHANGE SW (L) ? N                D.0
-----
-----
-----
-----
```

2.2 CHAIN MODE OPERATION

CHAIN MODE OPERATION CONSISTS OF THE SEQUENTIAL EXECUTION OF PROGRAMS WITHOUT OPERATOR INTERVENTION. ONLY PROGRAMS THAT HAVE BEEN MODIFIED TO RUN IN CHAIN MODE CAN BE CHAINED. CHAINABLE PROGRAMS ARE IDENTIFIED IN THE DIRECTORY BY A BIC EXTENSION.

TO RUN CHAIN MODE, THE CNDP+ MONITOR USES AN ASCII FILE (KNOWN AS A CHAIN FILE) LISTING THE PROGRAMS TO BE RUN AND THE NUMBER OF PASSES EACH PROGRAM SHOULD RUN. THIS FILE MUST BE ON THE SYSTEM DEVICE.

A CHAIN FILE MAY BE GENERATED BY USE OF THE XTECO TEXT EDITOR. THIS FILE MUST HAVE A CCC EXTENSION. THE CHAIN FILE MAY CONTAIN ANY OF THE COMMANDS SUPPORTED BY THE CNDP+ MONITOR. THE COMMANDS IN THE ASCII FILE ARE EXECUTED IN THE ORDER IN WHICH THEY ARE ENCOUNTERED.

TO EXECUTE A CHAIN FILE THE USER TYPES:

```
C FILNAM <CR> OR
C FILNAM/QV <CR>
```

IN THE FIRST CASE THE PASS COUNT SPECIFIED IN THE CHAIN FILE IS USED BY THE CNDP+ MONITOR TO DETERMINE THE NUMBER OF PASSES TO EXECUTE EACH PROGRAM. IN THE SECOND CASE THE PROGRAM COUNT IS NOT USED AND EACH PROGRAM IS EXECUTED ONLY ONCE. THE /QV SWITCH PROVIDES A SINGLE EXECUTION MODE OF OPERATION OF QUICK VERIFY.

587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636

WHEN PROGRAMS ARE RUN IN CHAIN MODE, THE SOFTWARE SWITCH REGISTER SHOULD BE SET TO 00000. THE CNDP+ MONITOR PRINTS EACH COMMAND TAKEN FROM THE CHAIN FILE AND THEN EXECUTES THE COMMAND. WHEN THE LAST COMMAND OTHER THAN ANOTHER C COMMAND HAS BEEN EXECUTED THE CNDP+ MONITOR TERMINATES CHAIN MODE AND TYPES A PROMPT (.). IT IS READY TO ACCEPT ANOTHER COMMAND FROM THE CONSOLE. IF THE LAST COMMAND IS ANOTHER C COMMAND, THE CHAIN MODE WILL CONTINUE AND THE CHAIN FILE SPECIFIED BY THIS NEW C COMMAND WILL BE USED.

IF THE USER WISHES TO TERMINATE CHAIN MODE BEFORE ITS NORMAL TERMINATION HE MAY DO SO BY TYPING A CONTROL/C. HOWEVER, THE MONITOR WILL NOT ABORT THE CHAIN MODE UNTIL IT RECEIVES PROGRAM CONTROL FROM THE PROGRAM CURRENTLY RUNNING.

2.3 DETAILS OF COMMANDS AND SYNTAX

2.3.1 TABLE OF COMMAND VALIDITY

THERE ARE FOUR WAYS OF ENTERING DIAGNOSTIC COMMAND MODE, AND DIFFERENT SUBSETS OF THE DIAG COMMAND SET ARE AVAILABLE WITH EACH:

HOW ENTERED	LEGAL COMMANDS
1. OPERATOR ENTERED RUN DIAG'	START PRINT DISPLAY FLAGS ZFLAGS EXIT
2. DIAGNOSTIC HAS FINISHED ALL ITS REQUESTED PASSES	START RESTART PRINT DISPLAY FLAGS ZFLAGS EXIT
3. OPERATOR INTERRUPTED THE	START PRINT DISPLAY FLAGS ZFLAGS EXIT

638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692

4. AN ERROR WAS ENCOUNTERED WITH THE MOE FLAG SET

START
RESTART
CONTINUE
PROCEED
PRINT
DISPLAY
FLAGS
ZFLAGS
EXIT

2.3.2 COMMAND SYNTAX

STA(RT)/TESTS:TEST-LIST/PASS:PASS-CNT/FLAGS:FLAG LIST/EOP:EOP INCR

THE DIAGNOSTIC IN CORE IS EXECUTED IN ACCORDANCE WITH THE SWITCHES SPECIFIED. THE MESSAGE "0 UNITS?" IS PRINTED. THE START COMMAND MAY BE ISSUED WHEN DIAGNOSTIC COMMAND MODE HAS BEEN ENTERED VIA ONE OF THE FOLLOWING: A) OPERATOR TYPED "RUN DIAGNOSTIC" B) DIAGNOSTIC FINISHED EXECUTING C) ERROR WAS ENCOUNTERED WITH MOE FLAG SET D) OPERATOR ENTERED CONTROL/C. AFTER THE OPERATOR RESPONDS TO "0 UNITS?", THE HARDWARE DIALOGUE IS INITIATED. WHEN IT IS COMPLETED, THE QUESTIONS "CHANGE SW?" IS ISSUED, AND THE ANSWERS, IF GIVEN, BECOME THE NEW DEFAULTS. THEREFORE IT IS NECESSARY TO RELOAD THE PROGRAM IN ORDER TO RETURN TO THE LOAD DEFAULTS.

THE SWITCH ARGUMENTS ARE AS FOLLOWS:

"TEST-LIST" IS A SEQUENCE OF DECIMAL NUMBERS (1:2 ETC.) OR RANGES OF DECIMAL NUMBERS (1-5:8-10 ETC.) THAT SPECIFY THE TESTS TO BE EXECUTED. THE NUMBERS ARE SEPARATED BY COLONS. THE NUMBERS RANGE FROM 1 TO THE LARGEST TEST NUMBER IN THE DIAGNOSTIC. THEY MAY BE SPECIFIED IN ANY ORDER. TESTS WILL BE EXECUTED IN NUMERICAL ORDER REGARDLESS OF THE ORDER OF SPECIFICATION. THE DEFAULT IS TO EXECUTE ALL TESTS.

"PASS-CNT" IS A DECIMAL NUMBER INDICATING THE DESIRED NUMBER OF PASSES. A PASS IS DEFINED AS THE EXECUTION OF THE FULL DIAGNOSTIC (ALL SELECTED TESTS) AGAINST ALL UNITS SUBMITTED. THE DEFAULT IS NON-ENDING TEST EXECUTION. "FLAG-LIST" IS A SEQUENCE OF ELEMENTS OF THE FORM <FLAG>, <FLAG=1>, OR <FLAG=0>, SEPARATED BY COLONS. WHERE <FLAG> HAS ONE OF THE FOLLOWING VALUES:

MOE HALT ON ERROR, CAUSING COMMAND MODE TO BE ENTERED WHEN AN ERROR IS ENCOUNTERED

LOE LOOP ON ERROR, CAUSING THE DIAGNOSTIC TO LOOP CONTINUOUSLY WITHIN THE SMALLEST DEFINED BLOCK OF CODING (SEGMENT, SUBTEST, OR TEST) CONTAINING THE ERROR

IER INHIBIT ERROR REPORTING

694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749

IBE INHIBIT BASIC ERROR REPORTS

IXE INHIBIT EXTENDED ERROR REPORTS

PRI DIRECT ALL MESSAGES TO A LINE PRINTER

PNT PRINT NUMBER OF TEST BEING EXECUTED

BOE BELL ON ERROR

UAM RUN IN UNATTENDED MODE, BYPASSING MANUAL INTERVENTION TESTS

ISR INHIBIT STATISTICAL REPORTS

IDU INHIBIT DROPPING OF UNITS BY DIAGNOSTIC

ADR EXECUTE AUTODROP CODE

LOT LOOP ON TEST

EVL EVALUATE

THE FLAGS NAMED OR EQUATED TO 1 ARE SET, THOSE EQUATED TO 0 ARE CLEARED. A FLAG NOT SPECIFIED IS CLEARED. IF THE FLAGS SWITCH IS NOT GIVEN ALL FLAGS ARE CLEARED.

"EOP-INCR" IS A DECIMAL NUMBER INDICATING HOW OFTEN (IN TERMS OF PASSES) IT IS DESIRED THAT THE END OF PASS MESSAGE BE PRINTED. THE DEFAULT IS AT THE END OF EVERY PASS.

RES(TART)/TEST;TEST-LIST/PASS:PASS-CNT/FLAGS:FLAG-LIST/EOP:EOP-INCR/UNITS:UNIT LIST

THE DIAGNOSTIC IN CORE IS EXECUTED IN ACCORDANCE WITH THE SWITCHES SPECIFIED. HOWEVER, NEW "P-TABLES" ARE NOT BUILT. INSTEAD, THE ONES IN CORE ARE USED.

THE QUESTION "CHANGE SW?" IS ASKED AND THE ANSWERS GIVEN BECOME THE NEW DEFAULTS. THE COMMAND MAY BE ISSUED WHEN COMMAND MODE HAS BEEN ENTERED VIA A) DIAGNOSTIC IS FINISHED B) HALT ON ERROR C) CONTROL/C.

THE SWITCH ARGUMENTS ARE AS IN THE START COMMAND EXCEPT:

1. "UNIT-LIST" IS A SEQUENCE OF LOGICAL UNIT NUMBERS RANGING FROM 1 THRU N (N = NUMBER OF UNITS BEING TESTED) SPECIFYING WHICH UNITS ARE TO BE TESTED. THE LOGICAL UNIT NUMBER DESIGNATES THE POSITION OF THE P-TABLE IN CORE, ACCORDING TO THE ORDER IN WHICH THEY WERE BUILT. THE UNITS SPECIFIED MUST NOT HAVE BEEN DROPPED BY THE OPERATOR DROP COMMAND. THE UNIT-LIST DEFAULTS TO "ALL THAT HAVE NOT BEEN DROPPED BY OPERATOR COMMAND". THE EFFECT OF THE UNIT-LIST LASTS UNTIL THE NEXT START (WHERE IT IS AUTOMATICALLY RESET TO "ALL") OR THE NEXT RESTART.

2. ALL UNSPECIFIED FLAG SETTINGS ARE UNCHANGED.

CON(TINUE)/PASS:<PASS-CNT/FLAGS:<FLAG-LIST>

COMMAND MODE MUST HAVE BEEN ENTERED DUE TO A HALT ON ERROR OR A CONTROL/C. THE EFFECT OF THE COMMAND IS TO GO TO THE BEGINNING OF THE TEST THAT WAS BEING EXECUTED WHEN THE HALT OR CONTROL/C TOOK PLACE. SOFTWARE DIALOGUE MAY OPTIONALLY BE RE-EXECUTED. HARDWARE PARAMETERS MAY NOT BE CHANGED.

THE SWITCH ARGUMENTS ARE AS IN THE START COMMAND EXCEPT:

1. DEFAULT FOR PASS-CNT IS THE UNSATISFIED PASS-CNT FROM THE PREVIOUS START OR RESTART
2. UNSPECIFIED FLAG SETTINGS ARE UNCHANGED

PRO(CEED)/FLAGS:<FLAG-LIST>

COMMAND MODE MUST HAVE BEEN ENTERED VIA A HALT ON ERROR. THE EFFECT OF THE COMMAND IS TO BEGIN EXECUTION AT THE LOCATION FOLLOWING THE ERROR CALL. NEITHER HARDWARE NOR SOFTWARE PARAMETERS MAY BE ALTERED.

THE SWITCH ARGUMENTS ARE THE SAME AS THE START COMMAND EXCEPT:

1. UNSPECIFIED FLAG SETTINGS ARE UNCHANGED

EXIT

RETURN TO CNDP. PROMPT MODE.

DRO(P)/UNITS:UNIT-LIST

THE UNITS SPECIFIED ARE DROPPED FROM TESTING UNTIL THEY ARE ADDED BACK OR UNTIL A START COMMAND IS GIVEN. A DROP CANNOT BE FOLLOWED BY A PROCEED.

THERE IS ALSO A "DROP" MACRO INTERNAL TO THE DIAGNOSTIC, WHICH GIVES THE FACILITY OF AUTO-DROPPING. THE DURATION OF A PROGRAM DROP, HOWEVER, IS ONLY UNTIL THE NEXT START OR RESTART.

751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806

808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862

```
*****  
ADD/UNITS:UNIT-LIST  
*****  
  
THE UNITS SPECIFIED ARE ADDED BACK (THEY MUST HAVE BEEN PREVIOUSLY  
DROPPED BY THE DROP COMMAND) TO THE TEST SEQUENCE. AN ADD CANNOT  
BE FOLLOWED BY A PROCEED.  
  
*****  
PRI(NT)  
*****  
  
ALL STATISTICS TABLES ACCUMULATED BY THE DIAGNOSTIC ARE PRINTED.  
THE ISR (INHIBIT STATISTICAL REPORTING) FLAG IS CLEARED.  
  
*****  
DIS(PLAY)/UNITS:<UNIT-LIST>  
*****  
  
THE HARDWARE P-TABLES FOR ALL UNITS UNDER TEST ARE PRINTED OUT IN  
THE FORMAT IN WHICH THEY WERE ENTERED. ANY UNITS THAT WERE DROPPED  
BY THE OPERATOR "DROP" COMMAND ARE SO DESIGNATED.  
  
*****  
FLA(GS)  
*****  
  
THE CURRENT SETTINGS OF ALL FLAGS ARE PRINTED.  
  
*****  
ZFL(AGS)  
*****  
  
ALL FLAGS ARE CLEARED.
```

2.4 EXTENDED P-TABLE DIALOGUE

THE FULL CAPABILITY OF THE HARDWARE DIALOGUE IS REVEALED BY THE
FOLLOWING DISCUSSION OF WHAT HAPPENS INTERNALLY.

AS SOON AS THE QUESTION "# UNITS?" IS ANSWERED (WITH THE NUMBER N),
SPACE IN CORE IS ALLOCATED FOR "N" P-TABLES. ALL OF THE P-TABLES
ARE OF THE SAME FORMAT, AND THERE IS A ONE-TO-ONE CORRESPONDENCE
BETWEEN THE HARDWARE PARAMETER QUESTIONS AND THE SLOTS IN THE
P-TABLE FORMAT.

IN GIVING A STRING OF VALUES, COMMAS WITHOUT INTERVENING VALUES MAY
BE USED TO INDICATE A REPETITION OF THE LAST NAMED VALUE.

864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915

A STRING OF VALUES MAY BE GIVEN AS A RANGE (6 10 FOR EXAMPLE). IF THE VALUES REPRESENT PURE NUMERICAL DATA, THIS SAMPLE RANGE TRANSLATES TO THE STRING 6,7,8,9,10 (AN INCREMENT OF 1). IF THE VALUES ARE ADDRESSES, THE SAMPLE RANGE TRANSLATES TO THE STRING 6,8,10 (AN INCREMENT OF 2).

NOW LET US SEE HOW WE COULD USE THESE CAPABILITIES TO CONSTRUCT A SET OF P-TABLES. ASSUME THAT WE HAVE 8 RL UNITS, AND THAT THERE ARE FIVE (5) HARDWARE PARAMETERS FOR EACH (5 SLOTS IN THE P-TABLE, 5 HARDWARE QUESTIONS IN THE DIALOGUE).

FOLLOWING IS THE DIALOGUE FOR THIS 8 RLOX DRIVE SYSTEM. THIS SYSTEM HAS TWO (2) RL11 TYPE CONTROLLERS ALL TO BE SET AT "BR LEVEL" 5. THE FIRST 4 DRIVES ARE RL01'S AND THE LAST 4 DRIVES ARE RL02'S (ON THE SECOND CONTROLLER):

UNITS (0) ? 8

UNIT 0

RL11 (L) Y ?
BUS ADDRESS (0) 174400 ?
VECTOR (0) 160 ?
DRIVE (0) 0 ? 0-3
DRIVE TYPE = RL01 (L) Y ?
BR LEVEL (0) 5 ?

UNIT 4

RL11 (L) Y ?
BUS ADDRESS (0) 174400 ? 175400
VECTOR (0) 160 ? 164
DRIVE (0) 0 ? 0-3
DRIVE TYPE = RL01 (L) Y ? N
BR LEVEL (0) 5 ?

THE FIRST TIME THRU THE P-TABLE QUESTIONS THE DEFAULT VALUES ARE USED FOR THE CONTROLLER TYPE (QUESTION #1), CSR ADDRESS OF THE CONTROLLER (QUESTION #2), THE CONTROLLER VECTOR ASSIGNMENT (QUESTION #3), THE DRIVE TYPE (QUESTION #5), AND THE "BR LEVEL" (QUESTION #6). THE ACTUAL UNIT NUMBERS OF THE RL01'S FOR QUESTION #4 WAS ASSIGNED 0 THRU 3 FOR THE FIRST 4 P-TABLE SLOTS.

THE SECOND TIME THRU THE P-TABLE QUESTIONS (FOR THE RL02 ASSIGNMENT ON THE SECOND CONTROLLER), THE FIRST QUESTION DEFAULTED TO "RL11" TYPE CONTROLLER. THE SECOND QUESTION WAS ANSWERED TO REFLECT THE CHANGE IN CSR ADDRESS FOR THE RL02 CONTROLLER (175400). THE SECOND CONTROLLER'S VECTOR WAS ALSO CHANGED TO 164 IN QUESTION #3. THE RL02 TEST UNIT NUMBERS WERE ASSIGNED VALUES 0 TO 3 IN QUESTION #4 AND THE DRIVE TYPE WAS SET FOR RL02'S FOR THE REMAINING 4 UNITS IN QUESTION #5. THE LAST QUESTION WAS DEFAULTED USING THE "BR LEVEL" FROM THE FIRST PASS.

91
418
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971

2.5 HARDWARE PARAMETERS

THE FOLLOWING QUESTIONS WILL BE ASKED ON A START COMMAND. THE VALUE LOCATED TO THE LEFT OF THE QUESTION MARK IS THE DEFAULT VALUE THAT WILL BE TAKEN ON A CARRIAGE RETURN RESPONSE.

RL11 (L) Y?

ANSWER YES(Y) IF YOU HAVE AN RL11 CONTROLLER, NO(N) IF YOU HAVE AN RLV11 CONTROLLER.

BUS ADDRESS (O) 174400?

ANSWER WITH THE BUS ADDRESS OF THE CONTROLLER.

VECTOR (O) 160?

ANSWER WITH THE INTERRUPT VECTOR OF THE CONTROLLER.

DRIVE (O) 0?

ANSWER WITH THE DRIVE(S) CONNECTED TO THE CONTROLLER

DRIVE TYPE = RLO1 (L) ?

ANSWER NO (N) IF DRIVE IS AN RLO2

BR LEVEL (O) 5?

ANSWER WITH THE INTERRUPT PRIORITY OF THE CONTROLLER.

2.6 SOFTWARE PARAMETERS

THE FOLLOWING QUESTIONS ARE ASKED IF REQUESTED ON A START, RESTART, OR CONTINUE. THEY ALLOW FLEXIBILITY IN THE WAY THE PROGRAM BEHAVES. THE SOFTWARE PARAMETERS GIVE THE PROGRAM FLEXIBILITY IN THE WAY IT RUNS. THE PARAMETERS CAN BE MODIFIED ON A START, RESTART, OR CONTINUE BY ANSWERING (Y)ES TO THE FOLLOWING QUESTION:

CHANGE S.W. ?

A YES ANSWER WILL ASK THE FOLLOWING SOFTWARE PARAMETER QUESTIONS, WITH THE PRESENT DEFAULT VALUE PRINTED TO THE LEFT OF THE QUESTION MARK. (THE LAST ANSWER GIVEN IS THE DEFAULT) THE DEFAULT IS TAKEN ON A <CR>. CONTROL Z (^Z) WILL DEFAULT ALL REMAINING QUESTIONS AND START THE TEST.

USE ALL CYLINDERS (N)?

IF "YES", THOSE TESTS THAT NORMALLY USE A SELECTED SET OF CYLINDERS WILL TEST EVERY CYLINDER ON THE CARTRIDGE.

973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999
1000
1001
1002
1003
1004
1005
1006
1007
1008
1009
1010
1011
1012
1013
1014
1015
1016
1017
1018
1019
1020
1021
1022
1023
1024
1025

USE ALL SECTORS (N)?

IF "YES", THOSE TESTS THAT NORMALLY USE A SINGLE SECTOR TO TEST A GIVEN OPERATION (SUCH AS SEEK DESTINATION) WILL READ AND VERIFY EVERY SECTOR HEADER.

LOWER SEEK LIMIT (N)?

IF "YES", THE NEXT PARAMETER IS REQUESTED.

ENTER VALUE (DECIMAL) (0)?

THIS LIMIT IS IMPOSED ON ALL SEEK OPERATIONS SUCH THAT TESTING IS NOT DONE BELOW THAT LIMIT. IN ADDITION, SETTING THIS LIMIT (OR THE UPPER LIMIT, SEE BELOW) CAUSES THE FORWARD AND REVERSE OSCILLATING SEEK TESTS TO PERFORM DIFFERENTLY (SEE TEST DESCRIPTION). TESTS THAT REQUIRE ACCESS TO A SPECIFIC CYLINDER THAT FALLS BELOW THE SPECIFIED LIMIT WILL IGNORE THE LIMIT (SEE WRITE/READ TEST PART 1).

UPPER SEEK LIMIT (N)?

IF "YES", AN UPPER CYLINDER LIMIT IS IMPOSED IN THE SAME MANNER AS THE LOWER SEEK LIMIT. A "YES" RESPONSE WILL CAUSE THE FOLLOWING PARAMETER REQUEST.

ENTER VALUE (DECIMAL) (255)?

USE ONLY ONE SURFACE (N)?

IF "YES", THE NEXT PARAMETER IS REQUESTED.

SPECIFY SURFACE (0 OR 1) (DECIMAL) (0)?

WHICHEVER SURFACE IS SPECIFIED IS THE ONLY SURFACE TESTED IN THE ENTIRE PROGRAM. ANY TEST THAT IS DESIGNED TO TEST THE OTHER SURFACE IS AUTOMATICALLY BYPASSED. THE PROGRAM DOES NOT PRINT ANY INDICATION THAT A TEST IS BYPASSED IN THIS CASE.

SPECIFY ERROR LIMIT (DECIMAL) (20)?

THIS PARAMETER SPECIFIES THE MAXIMUM NUMBER OF ERRORS ALLOWED. THIS LIMIT IS ON A PER DRIVE BASIS IN A SINGLE PASS. IF THE ERROR LIMIT IS EXCEEDED, THE DRIVE IS DROPPED FROM FURTHER TESTING.

DATA COMPARE ERROR LIMIT (DECIMAL) (20)?

THIS PARAMETER SPECIFIES THE NUMBER OF DATA COMPARE ERRORS THAT WILL BE LISTED FOR A GIVEN COMPARE OPERATION. AFTER THE LIMIT IS REACHED, THE DATA ERRORS ARE NOT PRINTED BUT THE COMPARE CONTINUES UNTIL THE END OF THE DATA FIELD. A TOTAL IS REPORTED AT THE END OF THE COMPARE.

1027
1028
1029
1030
1031
1032
1033
1034
1035
1036
1037
1038
1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1060
1061
1062
1063
1064
1065
1066
1067
1068
1069
1070
1071
1072
1073
1074
1075
1076
1077
1078
1079
1080
1081
1082

3.0 ERROR INFORMATION

ALL ERRORS ARE PRINTED VIA CONSOLE DEVICE. THE ERROR INCLUDES ERROR NUMBER, TYPE AND PROGRAM LOCATION. ERRORS INCLUDE REGISTERS BEFORE AND AT ERROR WITH RELEVANT DATA.

3.1 ERROR REPORTING

THE OPERATION MESSAGE (LINE 4) IS GENERATED IN A DYNAMIC MANNER BASED ON THE SUBSYSTEM FUNCTION BEING EXECUTED AT THE TIME OF THE ERROR AND THE STATE OF THE FLAGS IN THE LOCATION TAGGED 'OPFLAGS'. THE POSSIBLE OPERATION MESSAGES ARE GIVEN BELOW.

SEEK - FROM (CYL NUM) DIFF (CYL DIFF) SGN (0 OR 1) HD (0 OR 1) WHERE THE VALUES ARE GIVEN IN OCTAL. THIS MESSAGE IS THE RESULT OF A SEEK OPERATION THAT WAS VERIFIED BY A READ HEADER AND THE HEAD POSITION AFTER A SEEK IS IN ERROR. (THE ACTUAL HEAD POSITION IN THIS ERROR SITUATION IS GIVEN IN THE RESULT LINE, LINE 5.)

READ DATA - IS A READ DATA OPERATION WHERE SOME FORM OF ERROR WAS DETECTED IN THE ACTUAL READ OPERATION. THIS ERROR COULD BE HARDWARE DETECTED SUCH AS DATA CRC, HEADER CRC, HEADER NOT FOUND, ETC., OR A SOFTWARE DETECTED ERROR SUCH AS DRIVE READY RESET AFTER A READ DATA COMPLETED.

READ DATA WITH DATA COMPARE - IS AN ERROR THAT WAS DETECTED AS BAD DATA IN THE BUFFER AFTER

A READ DATA OPERATION. WHEN THIS OPERATION IS REPORTED IT INDICATES THE ACTUAL READ DATA OPERATION COMPLETED WITH NO DETECTED ERRORS BUT THE DATA WAS WRONG.

READ HEADER - READ HEADER FOR 40 HEADERS - READ HEADER FOR 40 HEADERS WITH HEADER COMPARE - HAVE THE SAME GENERAL MEANING AS THE READ DATA AND READ DATA WITH DATA COMPARE. MESSAGES HAVING THE OPERATION OF READ HEADER OR READ HEADER FOR 40 HEADERS ARE THE RESULT OF ERRORS DETECTED IN THE ACTUAL OPERATION WHILE THE READ HEADER FOR 40 HEADERS WITH HEADER COMPARE INDICATES NO ERROR IN THE ACTUAL OPERATION BUT THE HEADER DATA ITSELF WAS IN ERROR.

WRITE DATA - RESET - GET STATUS - GET STATUS WITH RESET - ARE ALL BASIC OPERATIONS. AS BEFORE, THE ERROR DETECTION CAN BE EITHER HARDWARE OR SOFTWARE. THE RESULT LINE (LINE 5) WILL DEFINE THE REASON FOR THE REPORT.

LD DRV - UNLD DRV - ARE OPERATION MESSAGES THAT WILL APPEAR IN THE REPORT WHEN THE DRIVE LOAD AND UNLOAD SEQUENCE IS BEING TESTED.

ANOTHER GROUP OF OPERATION QUALIFIERS WILL BE REPORTED FOR OPERATIONS THAT FAIL IN SPECIFIC TESTS. THESE TESTS ARE THE WRITE/READ TEST PART 2, OVERWRITE TEST, AND THE ADJACENT CYLINDER INTERFERENCE TEST.

1084
1085
1086
1087
1088
1089
1090
1091
1092
1093
1094
1095
1096
1097
1098
1099
1100
1101
1102
1103
1104
1105
1106
1107
1108
1109
1110
1111
1112
1113
1114
1115
1116
1117
1118
1119
1120
1121
1122
1123
1124
1125
1126
1127
1128
1129
1130
1131
1132
1133
1134

OPERATION	QUALIFIER
READ DATA WITH DATA COMPARE	FOL 0 TO CC SEEK
READ DATA	FOL 255 TO CC SEEK
WRITE DATA	FOL WRITE (NO SEEK)
READ HEADER	ADJ. CYL WRITTEN AFTER FWD SK
	ADJ. CYL WRITTEN AFTER REV SK
	SK FWD, WRT-SK REV, OVERWRT
	SK REV, WRT-SK FWD, OVERWRT

THE ABOVE OPERATIONS CAN BE REPORTED WITH ANY OF THE QUALIFIERS. THE QUALIFIERS IN THESE TESTS ARE AN ATTEMPT TO MAKE THE REPORT MORE MEANINGFUL BY PROVIDING INFORMATION ABOUT THE SEQUENCE OF OPERATIONS BEING DONE.

THE QUALIFIERS "FOL 0 TO CC SEEK" AND "FOL 255 TO CC SEEK" INDICATE THAT THE SEQUENCE OF OPERATIONS INCLUDED A SEEK OF A GIVEN DIRECTION TO THE CYLINDER WHERE THE TEST IS BEING PERFORMED.

THE "FOL WRITE (NO SEEK)" QUALIFIER MEANS THAT THE OPERATION WAS DONE AFTER A WRITE WITH NO HEAD MOVEMENT BETWEEN THE WRITE AND READ.

THE QUALIFIER "ADJ CYL WRITTEN AFTER FWD SK" AND "ADJ CYL WRITTEN AFTER REV SK" WILL BE REPORTED ONLY IN THE ADJACENT CYLINDER INTERFERENCE TEST. THESE QUALIFIERS ARE USED WHEN THE ERROR OCCURS ON THE CYLINDER UNDER TEST AND DEFINE THE DIRECTION THE HEADS WERE MOVED WHEN THE ADJACENT CYLINDER WAS WRITTEN.

THE QUALIFIERS "SK FWD, WRT-SK REV, OVERWRT" AND "SK REV, WRT-SK FWD, OVERWRT" WILL BE REPORTED ONLY IN THE OVERWRITE TEST. THESE QUALIFIERS DEFINE THE DIRECTION OF HEAD MOTION BEFORE THE INITIAL WRITE AND THE OVERWRITE.

THE QUALIFIER "ON BAD SEC FILES" WILL BE REPORTED WITH THE WRITE DATA COMMAND IF THE PROGRAM ABORTS THAT COMMAND BECAUSE THE WRITE WOULD BE ON THE BAD SECTOR FILES.

3.1.2 SPECIFIC RESULT MESSAGES

THE RESULT MESSAGE (LINE 5) IS GENERATED DYNAMICALLY BASED ON THE EXPECTED RESULT OF THE OPERATION BEING TESTED. SINCE OPERATIONS ARE MONITORED DURING EXECUTION THE RESULT MESSAGE MAY REPORT AN ERROR DETECTED DURING THE OPERATION AS WELL AS THE ERRORS SEEN AT THE END OF THE OPERATION. ONLY THE FIRST ERROR SEEN IS REPORTED IN ALL CASES.

THE GENERAL FORMAT FOR THE RESULT LINE IS:

1136
1137
1138
1139
1140
1141
1142
1143
1144
1145
1146
1147
1148
1149
1150
1151
1152
1153
1154
1155
1156
1157
1158
1159
1160
1161
1162
1163
1164
1165
1166
1167
1168
1169
1170
1171
1172
1173
1174
1175
1176
1177
1178
1179
1180
1181
1182
1183
1184
1185
1186
1187
1188
1189

RESULT:(VAR 1) IS (VAR 2) SB (VAR 3) (OPTIONAL QUALIFIER)
WHERE VARIABLE 1 CAN BE ONE OF THE FOLLOWING:

CONT ERR	(CONTROLLER ERROR)
DRV ERR	(DRIVE ERROR)
NON-EXSTNT MEM	(NON EXISTANT MEMORY)
HDR CRC	(HEADER CRC ERROR)
DATA CRC	
HDR NOT FND	(HEADER NOT FOUND)
DATA LATE	
HDR NOT FND/HDR CRC/OPI	(ALL 3 BITS SET)
DRV RDY	(DRIVE READY)
SELECTED HEAD	
VOL CHK	(VOLUME CHECK)
COVER OPEN	
BRUSH HME	(BRUCH HOME)
WRT LCK	(WRITE LOCK)
HDS OUT	(HEADER OUT)
DRV SEL ERR	(DRIVE SELECT ERROR)
DRV STATE	(DRIVE STATE)
SPIN TIMEOUT	(SPINDLE TIMEOUT SPD ERROR)
WRT GAT ERR	(WRITE GATE ERROR)
SEEK TIMEOUT	(SKTO ERROR)
CUR HEAD ERR	(CURRENT IN HEAD ERROR)
WRT DAT ERR	(WRITE DATA ERROR)
OP INCOMPLETE	(OPI ERROR)
HDR/DAT ERR	(HDR CRC OR DATA CRC ERROR BIT 11 OF CS REGISTER)
HDR NOT FND/DAT LATE	(HDR NOT FOUND OR DATA LATE ERROR BIT 12 OF CS REGISTER)
CYL	(CYLINDER WHEN REPORTING A SEEK ERROR)

VARIABLE 2 WILL BE A VALUE THAT DEFINES WHAT THE RESULT ACTUALLY IS. THIS CAN BE A 1 OR 0 TO INDICATE A SET OF RESULT CONDITIONS, A NUMBER 0 TO 7 TO INDICATE THE DRIVE STATE, OR A NUMBER 0 TO 377 (OCTAL) TO IDENTIFY A CYLINDER NUMBER.

VARIABLE 3 DEFINES THAT THE VALUE GIVEN IS VARIABLE 2 SHOULD BE. THE OPTIONAL QUALIFIER IS PROVIDED WHEN IT IS USEFUL TO KNOW WHEN THE ERROR WAS DETECTED IN THE OPERATION BEING PERFORMED. THIS QUALIFIER IS USED TO REPORT RESULTS SUCH AS:

BRUSH HME IS 1 SB 0	IN STATE 2
HEADS OUT IS 0 SB 1	IN STATE 3
DRV RDY IS 0 SB 1	IN DATA XFER
SELECTED HEAD IS 1 SB 0	IN CYCLE UP
DRV RDY IS 0 SB 1	IN STATE 5
DRV RDY IS 1 SB 0	IN SEEK W/O MOTION
DRV RDY IS 0 SB 1	IN 10MS
DRV RDY IS 0 SB 1	IN 500MS
DRV RDY IS 0 SB 1	IN 5SECONDS

1191
1192
1193
1194
1195
1196
1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246

THESE RESULTS, WHEN SEEN WITH THE OPERATION MESSAGE, WILL BE SELF EXPLANATORY

OTHER RESULT MESSAGES THAT CAN BE PART OF AN ERROR REPORT ARE:

"INTERRUPT TOO LATE"

WHICH INDICATES THAT THE OPERATION BEING PERFORMED DID NOT COMPLETE IN THE EXPECTED AMOUNT OF TIME. THIS RESULT CAN BE CAUSED BY THE DRIVE LOSING READY BEFORE STARTING A READ HEADER AND THEREFORE NOT COMPLETING THE READ HEADER IN 1MS.

"FAIL TO RELOAD HEADS AFTER ERR CLEAR"

THIS IS REPORTED WHEN AN ERROR CAUSES HEADS TO UNLOAD AND AFTER THE ERROR IS CLEARED THE HEADS DO NOT RELOAD.

"UNKN DRV STATE-NO RDY, NO ERR, HDS OUT"

THIS IS REPORTED WHEN THE PROGRAM CANNOT DETERMINE THE DRIVE STATE OR STATUS.

"WRITE ABORTED"

THIS IS REPORTED WHEN THE PROGRAM ABORTS A WRITE TO PROTECT THE BAD SECTOR FILES.

"COULD NOT RETRIEVE DRIVE STATUS"

THIS IS REPORTED IF THE GET STATUS COMMAND DOES NOT COMPLETE SUCCESSFULLY WHEN THE STATUS IS REQUIRED TO REPORT AN ERROR.

"OPI SET-NO DRIVE RESPONSE"

THIS IS REPORTED AS THE RESULT WHEN THE GET STATUS COMMAND IS TIMED OUT (OPI SETS) WHEN THAT COMMAND IS BEING USED IN THE EARLY TESTS TO CHECK THE DRIVE INTERFACE.

"NO INTERRUPT ON CMND COMPLETE"

THIS IS REPORTED WHEN THE COMMAND SUCCESSFULLY COMPLETES BUT THE CONTROLLER HAS NOT GENERATED AN INTERRUPT.

"ERR DID NOT CLEAR"

THIS IS REPORTED WHEN THE RESET COMMAND DOES NOT CLEAR THE CONTROLLER ERRORS THIS IS A CONTROLLER RELATED PROBLEM BUT IS REPORTED IF SEEN IN THE DRIVE TEST PROGRAMS.

1248
1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296
1297
1298
1299
1300
1301
1302

"DRV ERR IS NOT CLEARED"

THIS IS REPORTED WHEN THE GET STATUS W/RESET COMMAND DOES NOT CLEAR ALL DRIVE ERRORS.

"UNEXPECTED ERR"

THIS IS REPORTED WHEN THE CONTROLLER SENSES AN ERROR BUT NO ERROR BITS ARE SET.

"BAD SEC FILE FMT ERR"

THIS IS REPORTED IF THE CONTENTS OF THE FILES DO NOT CORRESPOND TO THE EXPECTED FORMAT. (REFER TO DEC STANDARD 144 FOR FORMAT SPECIFICS.)

3.1.3 OTHER MESSAGES

OTHER INFORMATION IS REPORTED UNDER VARIOUS CIRCUMSTANCES. THESE ARE:

"BAD SEC FILES NOT STRD. ALL SEC ASSUMED GOOD."

THIS MESSAGE IS PRINTED WHEN A PARTICULAR TEST REQUIRES THE BAD SECTOR FILES BUT THEY HAVE NOT BEEN STORED. THIS SITUATION WILL OCCUR IF THIS TEST IS STARTED OUT OF THE NORMAL PROGRAM SEQUENCE OR IF THE BAD SECTOR FILES COULD NOT BE READ.

"ERROR LIMIT EXCEEDED-UNIT DROPPED"

THIS IS REPORTED (WITH THE UNIT NUMBER) WHEN MORE THAN THE SPECIFIED NUMBER OF ERRORS (DEFAULT 20) HAVE OCCURED IN ANY SINGLE PASS.

MOST ERROR REPORTS HAVE THE FOLLOWING FORMAT.

(1)	PROG NAME	ERR NUM	TEST NUM	SUBTEST NUM	ERR PC
(2)	ROUTINE TRACE SEQ (IN SEQ CALLED)	(ADDRESS)	(ADDRESS)	.	
		(ADDRESS)			
(3)	TEST DESCRIPTION				
(4)	OPERATION:				
(5)	RESULT:				
(6)	ADDRESS OF UNIT UNDER TEST				

1304
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356

```

(7)          RLCS  RLDA  RLBA  RLMP  Cyl  HD
(8)  OP INIT
(9)  OP DONE
(10)         DRIVE STATUS
(11)         WORD NUM IS (XXXXXX) SB (YYYYYY)
(12)  TOTAL COMPARE ERRS: (ZZZ) OF (128)

```

THE ONLY EXCEPTION TO THE ABOVE FORMAT IS PURE DATA COMPARE ERRORS (NOT DETECTED BY READ ERROR). THEN THE FORMAT DOES NOT INCLUDE LINES 5 THROUGH 10.

LINE 1 IS THE ERROR HEADER AND IS PROVIDED BY THE SUPERVISOR. THE PROGRAM IS IDENTIFIED BY NAME WITH THE NUMBER OF TEST AND SUBTEST PRESENTLY BEING EXECUTED.

THE SUBTEST NUMBER IS UNIQUE IN THIS PROGRAM IN THAT IT DOES NOT REFER TO A PHYSICAL SUBTEST WITHIN A GIVEN TEST. RATHER IT REFLECTS THE NUMBER OF TIMES A SUBTEST HAS BEEN EXECUTED WITHIN A TEST. CONSEQUENTLY, ON A TEST THAT TESTS AN INCREMENTAL TYPE OF OPERATION (SUCH A INCREMENTAL SEEKS, READ ALL HEADERS FROM BOTH SURFACES, ETC.) THE SUBTEST WILL BE DESCRIPTIVE OF WHERE IN THE TEST THE ERROR OCCURRED.

THE ERROR P.C. IS THE PHYSICAL MEMORY LOCATION WHERE THE ERROR REPORT WAS INITIATED. SINCE MANY FUNCTIONS ARE SUBROUTINED, AND ERRORS ARE REPORTED FROM SUBROUTINES, THE ERROR P.C. IS NOT SUFFICIENT TO IDENTIFY THE LOCATION OF THE ERROR CALL AND THE ROUTINE TRACE SEQUENCE IS PROVIDED.

LINE 2 IS THE ROUTINE TRACE SEQUENCE. IF THE ERROR CALL IS INITIATED FROM WITHIN THE TEST (AS OPPOSED TO WITHIN A ROUTINE), THIS PORTION OF THE REPORT IS OMITTED. IF THE CALL IS INITIATED FROM A ROUTINE (WHICH MAY BE CALLED BY ANOTHER ROUTINE, WHICH MAY BE CALLED BY ANOTHER ROUTINE, ETC. SEVERAL LEVELS DEEP) THE ROUTINE TRACE SEQUENCE PROVIDES A TRAIL TO THE ACTUAL LOCATION WITHIN THE TEST THAT CALLED THE FIRST ROUTINE. THE FIRST ENTRY LISTED IS THE LOCATION WHERE THE FIRST ROUTINE WAS CALLED.

LINE 3 IS THE TEST DESCRIPTION AND IS ROUGHLY IDENTICAL TO THE NAME OF THE TEST BEING PERFORMED.

LINE 4 IDENTIFIES THE ACTUAL HARDWARE FUNCTION THAT IS BEING PERFORMED. ADDITIONAL INFORMATION ON THIS LINE IS DESCRIPTIVE OF SPECIFIC USE OF THE FUNCTION. FOR EXAMPLE, THE OPERATION LINE WILL READ "READ HEADERS FOR 40 HEADERS" WHEN ALL HEADERS ARE BEING READ FROM A TRACK.

LINE 5 IDENTIFIES THE ERROR THAT HAS BEEN DETECTED. THE CONTENT OF LINE 5 IDENTIFIES WHAT WAS BEING TESTED (SUCH AS DRIVE READY, CONTROLLER ERROR, DRIVE STATE, ETC.), WHAT IT IS AND WHAT IT SHOULD BE. LINE 5 MAY BE REPEATED IF MORE THAN ONE TESTED ITEM IS FOUND IN ERROR.

1358
1359
1360
1361
1362
1363
1364
1365
1366
1367
1368
1369
1370
1371
1372
1373
1374
1375
1376
1377
1378
1379
1380
1381
1382
1383
1384
1385
1386
1387
1388
1389
1390
1391
1392
1393
1394
1395
1396
1397
1398
1399
1400
1401
1402
1403
1404
1405
1406
1407
1408
1409
1410
1411
1412
1413

IN ADDITION LINE 5 WILL REPORT ANY HARDWARE DETECTED ERRORS SUCH AS OPERATION INCOMPLETE, HEADER CRC, ETC. IN THIS CASE THE FIRST LINE PRINTED AS RESULT WILL BE DETERMINED BY THE THREE ERROR BITS OPI, MNF/DLT, AND MCRC/DCRC. THE LINE WILL BE DETERMINED AS IN THE FOLLOWING TRUTH TABLE:

MNF/DLT	DCRC/MCRC	OPI	MESSAGE
1	1	1	HDR NOT FND/HDR CRC/OPI ERROR
0	1	1	HDR CRC ERROR
1	0	1	HDR NOT FND ERROR
0	1	0	DATA CRC ERROR
1	0	0	DATA LATE ERROR

LINE 6 IDENTIFIES THE PHYSICAL ADDRESS OF THE UNIT UNDER TEST. THIS ADDRESS IS BY UNIBUS ADDRESS OF THE CONTROLLER AND DRIVE NUMBER.

LINE 7 NAMES THE CONTROLLER REGISTER, (AND CYLINDER AND HEAD WHERE THESE ARE APPLICABLE IN THE REPORT) TO BE REPORTED.

LINE 8 PROVIDES THE CONTENTS OF CONTROLLER REGISTERS WHEN THE OPERATION WAS INITIATED.

LINE 9 PROVIDES THE CONTENTS OF THE CONTROLLER REGISTERS WHEN THE ERROR BEING REPORTED WAS DETECTED. FREQUENTLY THE REGISTER CONTENTS OF OP INIT AND OP DONE WILL BE DIFFERENT. OP INIT MAY INDICATE A SEEK WAS BEING PERFORMED BUT OP DONE MAY INDICATE THE ERROR WAS DETECTED BY A READ HEADER. THE REASON IS THAT A SEEK WAS EXECUTED AND DID NOT PROPERLY POSITION HEADS AND WHEN THE READ HEADER WAS DONE THE HEADS WERE ON THE WRONG CYLINDER.

LINE 10 IS THE DRIVE STATUS. THIS LINE IS ONLY REPORTED IF THE RLMP REGISTER DOES NOT CONTAIN THE ACTUAL DRIVE STATUS.

LINE 11 AND LINE 12 ARE REPORTED IF THE ERROR WAS DETECTED AS A COMPARE OPERATION, EITHER DATA OR HEADERS. IN ADDITION, GOOD AND BAD DATA IS REPORTED FOR ALL READ ERRORS.

3.2 ERROR HALTS

ERROR HALTS ARE SUPPORTED PER DESCRIBED IN THE PREVIOUS SECTION WITH /FLAG:MOE. THERE ARE NO OTHER HALTS.

4.0 PERFORMANCE AND PROGRESS REPORTS

4.1 PERFORMANCE REPORTS

THIS PROGRAM WILL NOT GIVE ANY PERFORMANCE REPORTS.

1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437
1438
1439
1440
1441
1442
1443
1444
1445
1446
1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465

4.2 PROGRESS REPORTS

THIS PROGRAM WILL NOT GIVE ANY PROGRESS REPORTS.

5.0 DEVICE INFORMATION TABLES

THE RL11/RLV11 CONTROLLER HAS THE FOLLOWING FOUR(4) REGISTERS FOR CONTROL OF THE SUBSYSTEM.

RLCS CONTROL AND STATUS REGISTER (XXXXX0)

- BIT 15 COMPOSITE ERROR
- BIT 14 DRIVE ERROR
- BIT 13 - NON EXISTANT MEMORY ERROR
- BIT 12 HEADER NOT FOUND (WITH BIT 10 SET)
- DATA LATE (WITH BIT 10 CLEAR)
- BIT 11 - HEADER CRC (WITH BIT 10 SET)
DATA CRC (WITH BIT 10 CLEAR)
- BIT 10 - OPERATION INCOMPLETE
- BIT 9/8 - DRIVE SELECT (0-3)
- BIT 7 - CONTROLLER READY
- BIT 6 - INTERRUPT ENABLE
- BIT 5 EXTENDED BUS ADDRESS (BIT 17)
- BIT 4 - EXTENDED BUS ADDRESS (BIT 16)
- BIT 3-1 - FUNCTION CODE
 - 0 - NOP (PDP-11) MAINT (LSI-11)
 - 1 - WRITE CHECK
 - 2 - GET DRIVE STATUS
 - 3 - SEEK
 - 4 - READ HEADER
 - 5 - WRITE DATA
 - 6 - READ DATA
 - 7 - READ WITHOUT HEADER COMPARE

BIT 0 - DRIVE READY

RLBA - BUS ADDRESS REGISTER (XXXXX2)

BITS 15-1 BUS ADDRESS OF DATA TRANSFER
BIT 0 SHOULD BE 0

RLDA - DISK ADDRESS REGISTER (XXXXX4)

1467
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479
1480
1481
1482
1483
1484
1485
1486
1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497
1498
1499
1500
1501
1502
1503
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521

FOR READ/WRITE FUNCTIONS

BIT 15 7 CYLINDER ADDRESS FOR TRANSFER
BIT 6 SURFACE FOR TRANSFER
BIT 5-0 SECTOR FOR TRANSFER (1-40.)

FOR SEEK FUNCTION

BIT 15 7 DIFFERENCE TO NEW CYLINDER
BIT 6-5 - MUST BE ZERO (0)
BIT 4 - SURFACE (0=UPPER, 1=LOWER)
BIT 3 MUST BE ZERO (0)
BIT 2 - SEEK DIRECTION(1=IN / 0=OUT)
BIT 1 MUST BE ZERO (0)
BIT 0 - MUST BE ONE (1)

FOR GET STATUS FUNCTION

BIT 15-4 - IGNORED SHOULD BE ZERO (0)
BIT 3 - DRIVE RESET
BIT 2 - MUST BE ZERO (0)
BIT 1 - MUST BE ONE (1)
BIT 0 MUST BE ONE (1)

RLMP - MULTIPURPOSE REGISTER
-----FOR READ/WRITE FUNCTION

BIT 15 - 0 - WORD COUNT (TWO'S COMPLIMENT)

FOR READ HEADER FUNCTION

BIT 15-0 - DISK HEADER OF SECTOR (FIRST READ)
- ZERO WORD (SECOND READ)
- HEADER CRC (THIRD READ)

FOR GET STATUS FUNCTION

HAS DRIVE STATUS

BIT 15 - WRITE DATA ERROR
BIT 14 - CURRENT HEAD ERROR (CHE)
BIT 13 - WRITE LOCK STATUS (WL)
BIT 12 - SEEK TIME OUT (SKTO)
BIT 11 - SPIN ERROR (SPE)
BIT 10 - WRITE GATE ERROR (WGE)
BIT 9 - VOLUME CHECK (VC)

1523
1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547
1548
1549
1550
1551
1552
1553
1554
1555
1556
1557
1558
1559
1560
1561
1562
1563
1564
1565
1566
1567
1568
1569
1570
1571

BIT 8 DRIVE SELECT ERROR (DSE)
BIT 7 DRIVE TYPE IS RLO2 IF SET
BIT 6 SURFACE (0=UPPPER, 1=LOWER)
BIT 5 COVER OPEN
BIT 4 HEADS HOME
BIT 3 BRUSHES HOME
BIT 2 0 -STATE BITS
0 LOAD STATE
1 - SPIN UP
2 - BRUSH CYCLE
3 LOAD HEADS
4 - SEEK - TRACK COUNTING
5 SEEK LINEAR MODE
6 - UNLOAD HEADS
7 SPIN DOWN

6.0 TEST SUMMARIES

TEST 1 OUTER GUARD BAND DETECTION TEST

DO READ HEADER, WAIT FOR INTERRUPT. CHECK IF AT CYLINDER 0.
IF NOT, SEEK REVERSE 1 CYLINDER AT A TIME UNTIL CYLINDER 0 IS
REACHED. IF ANY REVERSE SEEK FAILS TO MOVE THE HEADS IN 10
TRIES:

DETECTION OF GUARD BAND PREMATURE.

WHEN AT CYLINDER 0, DO SEEK DIFFERENCE OF 1, SIGN 0, HEAD 0.
WAIT FOR INTERRUPT, WAIT FOR READY. READY SHOULD SET IN
20MS>T>15MS. IF NOT:

FAILED TO DETECT GUARD BAND

DO READ HEADER. WAIT FOR INTERRUPT. CHECK FOR CYLINDER 0.
IF NOT:

FAILED TO SEEK BACK TO ZERO

DO SEEK WITH DIFFERENCE OF 1, SIGN 0, HEAD 1. DO SAME TESTS
AS ABOVE WITH REGARD TO READY VS TIME AND CYLINDER FOUND IN
HEADER.

NOTE: CHOOSING A SINGLE SURFACE WILL LIMIT THE TESTING TO
THAT SURFACE.

1573
1574
1575
1576
1577
1578
1579
1580
1581
1582
1583
1584
1585
1586
1587
1588
1589
1590
1591
1592
1593
1594
1595
1596
1597
1598
1599
1600
1601
1602
1603
1604
1605
1606
1607
1608
1609
1610
1611
1612
1613
1614
1615
1616
1617
1618
1619
1620
1621
1622
1623
1624

TEST 2 INCREMENTAL FORWARD SEEK HEAD 0 TEST

POSITION HEADS AT CYLINDER "LOLIMIT" USING SEEKS WITH
DIFFERENCE OF ONE, HEAD 0.

DO SEEK WITH DIFFERENCE OF 1, SIGN 1, HEAD 0. WAIT FOR
INTERRUPT, WAIT FOR DRIVE READY. CHECK READY IS SET IN 15 MS.
IF NOT:

POSITIONING PROBLEM AT A SPECIFIC CYLINDER
MECHANICAL OBSTRUCTION

CHECK THAT THIS CYLINDER IS OLD CYLINDER + 1. IF NOT:

DIFFERENCE REGISTER OR COUNT LOGIC FAILURE
TRACK CROSSING DETECTION FAILURE

REPEAT SEEKS AND READS UNTIL CYLINDER READ IS "HILIMIT".

NOTE 1: IF THE "USE ALL SECTORS" PARAMETER IS SPECIFIED AS
"Y", THE TEST WILL READ AND TEST ALL 40 HEADERS
(CARTRIDGE VERIFY).

NOTE 2: TESTING WILL BE DONE BETWEEN UPPER AND LOWER CYLINDER
LIMITS. CHOOSING A SINGLE SURFACE WILL LIMIT TESTING
TO THAT SURFACE. THIS TEST WILL BE BYPASSED IF
SURFACE 1 IS CHOSEN.

TEST 3 INCREMENTAL REVERSE SEEK HEAD 0 TEST

POSITION HEADS AT CYLINDER "HILIMIT" USING SEEKS WITH
DIFFERENCE OF 1, HEAD 0.

DO SEEK WITH DIFFERENCE OF 1, SIGN 0, HEAD 0. WAIT FOR
INTERRUPT, WAIT FOR DRIVE READY. CHECK READY SET IN 15 MS:

POSITIONING PROBLEM AT A SPECIFIC CYLINDER
DO READ HEADER, WAIT FOR INTERRUPT. CHECK THAT THIS CYLINDER
IS OLD CYLINDER - 1. IF NOT:

DIFFERENCE REGISTER OR COUNT LOGIC FAILURE
TRACK CROSSING DETECTION FAILURE

REPEAT SEEK AND CHECKS UNTIL CYLINDER IS "LOLIMIT".

NOTE: IF THE "USE ALL SECTORS" PARAMETER IS SPECIFIED AS
"Y", THE TEST WILL READ AND TEST ALL 40 HEADERS
(CARTRIDGE VERIFY).

1626
1627
1628
1629
1630
1631
1632
1633
1634
1635
1636
1637
1638
1639
1640
1641
1642
1643
1644
1645
1646
1647
1648
1649
1650
1651
1652
1653
1654
1655
1656
1657
1658
1659
1660
1661
1662
1663
1664
1665
1666
1667
1668
1669
1670
1671
1672
1673
1674
1675
1676
1677
1678
1679
1680
1681

NOTE: TESTING WILL BE DONE BETWEEN UPPER AND LOWER CYLINDER LIMITS. CHOOSING A SINGLE SURFACE WILL LIMIT TESTING TO THAT SURFACE. THIS TEST WILL BE BYPASSED IF SURFACE 1 IS CHOSEN.

TEST 4 INCREMENTAL FORWARD SEEK HEAD 1 TEST

POSITION HEADS AT CYLINDER "HILIMIT" USING SEEKS WITH DIFFERENCE OF ONE, HEAD 0.

DO SEEK WITH DIFFERENCE OF 1, SIGN 1, HEAD 1. WAIT FOR INTERRUPT, WAIT FOR DRIVE READY. CHECK READY IS SET IN 15 MS. IF NOT:

POSITIONING PROBLEM AT A SPECIFIC CYLINDER

DO READ HEADER, WAIT FOR INTERRUPT. CHECK THAT THIS CYLINDER IS OLD CYLINDER + 1. IF NOT:

DIFFERENCE REGISTER OR COUNT LOGIC FAILURE
TRACK CROSSING DETECTION FAILURE

REPEAT SEEKS AND READS UNTIL CYLINDER READ IS "HILIMIT".

NOTE 1: IF THE "USE ALL SECTORS" PARAMETER IS SPECIFIED AS "Y", THE TEST WILL READ AND TEST ALL 40 HEADERS (CARTRIDGE VERIFY).

NOTE 2: TESTING WILL BE DONE BETWEEN UPPER AND LOWER CYLINDER LIMITS. CHOOSING A SINGLE SURFACE WILL LIMIT TESTING TO THAT SURFACE. THIS TEST WILL BE BYPASSED IF SURFACE 0 IS CHOSEN.

TEST 5 INNER GUARD BAND DETECTION TEST

POSITION HEADS AT CYLINDER "HILIMIT" USING SEEK WITH DIFFERENCE OF 1, HEAD 0.

WHEN AT MAX CYLINDER, DO SEEK WITH DIFFERENCE OF 1, SIGN 1, HEAD 0. WAIT FOR INTERRUPT, WAIT FOR DRIVE READY. READY SHOULD SET IN 20MS>T>15MS. IF NOT:

FAILED TO DETECT GUARD BAND

DO READ HEADER. WAIT FOR INTERRUPT. CHECK FOR MAX. CYLINDER IF NOT:

FAILED TO SEEK BACK TO MAX CYLINDER

DO SEEK WITH DIFFERENCE OF 1, SIGN 1, HEAD 1. DO SAME TESTS AS ABOVE.

NOTE: CHOOSING A SINGLE SURFACE WILL LIMIT THE TESTING TO

1683
1684
1685
1686
1687
1688
1689
1690
1691
1692
1693
1694
1695
1696
1697
1698
1699
1700
1701
1702
1703
1704
1705
1706
1707
1708
1709
1710
1711
1712
1713
1714
1715
1716
1717
1718
1719
1720
1721
1722
1723
1724
1725
1726
1727
1728
1729
1730
1731
1732
1733
1734
1735
1736
1737
1738

THAT SURFACE.

TEST 6 INCREMENTAL REVERSE SEEK HEAD 1 TEST

POSITION HEADS AT CYLINDER "HILIMIT" USING SEEKS WITH DIFFERENCE OF 1, HEAD 0.

DO SEEK WITH DIFFERENCE OF 1, SIGN 0, HEAD 1. WAIT FOR INTERRUPT, WAIT FOR DRIVE READY. CHECK READY SET IN 15 MS:

POSITIONING PROBLEM AT A SPECIFIC CYLINDER

DO READ HEADER, WAIT FOR INTERRUPT. CHECK THAT THIS CYLINDER IS OLD CYLINDER - 1. IF NOT:

DIFFERENCE REGISTER OR COUNT LOGIC FAILURE
TRACK CROSSING DETECTION FAILURE

REPEAT SEEK AND CHECKS UNTIL CYLINDER IS "LOLIMIT".

NOTE 1: IF PROGRAM MODE 2 IS USED AND THE "USE ALL SECTORS" PARAMETER IS SPECIFIED AS "Y", THE TEST WILL READ AND TEST ALL 40 HEADERS (CARTRIDGE VERIFY).

NOTE 2: TESTING WILL BE DONE BETWEEN UPPER AND LOWER CYLINDER LIMITS. CHOOSING A SINGLE SURFACE WILL LIMIT TESTING TO THAT SURFACE. THIS TEST WILL BE BYPASSED IF SURFACE 0 IS CHOSEN.

TEST 7 SEEK TESTS

POSITION HEADS AT CYLINDER "LOLIMIT" USING SEEKS WITH DIFFERENCE OF 1, HEAD 0.

DO READ HEADER, RECORD POSITION. DO SEEK WITH DIFFERENCE OF 2 (MAX DISTANCE AT 3 IPS), SIGN 1, HEAD 0. DO READ HEADER, CHECK NEW CYLINDER IS OLD CYLINDER + DISTANCE. IF NOT:

TRACK CROSSING DETECTION FAILURE
DIFFERENCE COUNTER FAILURE
COUNT PULSE GENERATION FAILURE
VELOCITY ROM FAILURE

REPEAT ABOVE UNTIL OLD CYLINDER + DISTANCE > MAX POSITION AT MAX.

DO READ HEADER, RECORD POSITION. DO SEEK WITH DIFFERENCE OF 2 (MAX DISTANCE AT 3 IPS), SIGN 0, HEAD 0. DO READ HEADER, CHECK NEW CYLINDER IS OLD CYLINDER - DISTANCE. IF NOT:

TRACK CROSSING DETECTION FAILURE

1740
1741
1742
1743
1744
1745
1746
1747
1748
1749
1750
1751
1752
1753
1754
1755
1756
1757
1758
1759
1760
1761
1762
1763
1764
1765
1766
1767
1768
1769
1770
1771
1772
1773
1774
1775
1776
1777
1778
1779
1780
1781
1782
1783
1784
1785
1786
1787

REPEAT UNTIL OLD CYLINDER DISTANCE < 0. REPEAT ALL OF THE ABOVE USING HEAD 1.

REPEAT ALL OF THE ABOVE TESTS USING THE FOLLOWING DISTANCES: 2, 6, 9, 12, 17, 22, 27, 34, 41, 128, 256 FOR RLO1 OR 4, 12, 18, 24, 34, 44, 54, 68, 82, 256, 512 FOR RLO2. THESE DISTANCES ARE SPECIFIED BECAUSE THEY REPRESENT THE MAXIMUM DISTANCE FOR EACH VELOCITY LEVEL USED IN THE DRIVE.

NOTE: TESTING WILL BE DONE BETWEEN UPPER AND LOWER CYLINDER LIMITS. CHOOSING A SINGLE SURFACE WILL LIMIT TESTING TO THAT SURFACE.

TEST 8 FORWARD OSCILLATING SEEK TEST

POSITION HEADS AT CYLINDER 0.

DO OSCILLATING SEEK USING HEAD 0 (SEEK FROM 0 TO 1 TO 0, 0 TO 2 TO 0, 0 TO 3 TO 0, ... 0 TO MAX CYL TO 0). AFTER EACH SEEK READ HEADER AND VERIFY POSITION.

REPEAT TEST USING HEAD 1.

NOTE: IF EITHER CYLINDER LIMIT IS SPECIFIED, THE TEST WILL SEEK BETWEEN UPPER AND LOWER LIMITS FOR EACH SURFACE. CHOOSING A SINGLE SURFACE WILL LIMIT TESTING TO THAT SURFACE. NOTE THAT LOOPING ON TEST THEN PROVIDES A FIXED DISTANCE SEEK LOOP.

TEST 9 REVERSE OSCILLATING SEEK TEST

POSITION HEADS AT MAX CYLINDER. DO OSCILLATING SEEK USING HEAD 0. (IF RLO1 SEEK FROM 255 TO 254 TO 255, 255 TO 253 TO 255, ... 255 TO 0 TO 255.) AFTER EACH SEEK READ HEADER AND VERIFY POSITION.

REPEAT TEST USING HEAD 1.

NOTE: IF EITHER CYLINDER LIMIT IS SPECIFIED, THE TEST WILL SEEK BETWEEN UPPER AND LOWER LIMITS FOR EACH SURFACE. CHOOSING A SINGLE SURFACE WILL LIMIT TESTING TO THAT SURFACE. NOTE THAT LOOPING ON TEST THEN PROVIDES A FIXED DISTANCE SEEK LOOP.

```

1789          002000          .-2000
1790          .MCALL  SVC
1791
1792 002000          SVC
1793          000001          SVCTST=1
1794          000001          SVCSUB=1
1795          000001          SVCBGL=1
1796          000000          SVCINS=0
1797          000000          SVCTAG=0
1798
1799          .SBTTL  MACRO DEFINITIONS
1800
1801          .MACRO  WAITUS  ARG          ;MACRO MICRO-SEC WAIT
1802          MOV      ARG,XDELAY        ;SAVE ARGUMENT
1803          JSR      PC,TIME           ;CALL TIMING ROUTINE
1804          .ENDM
1805
1806          .MACRO  WAITMS  ARG          ;MACRO MILLI-SEC WAIT
1807          MOV      ARG,YDELAY        ;SAVE ARGUMENT
1808          JSR      PC,XTIME          ;CALL TIMING ROUTINE
1809          .ENDM
1810
1811          .MACRO  ABORTWAIT          ;MACRO CLEAR UNELAPSED TIME
1812          MOV      XDELAY,TEMPO      ;SAVE MICRO-SEC RUN TIME
1813          MOV      YDELAY,TEMP      ;SAVE MILLI-SEC RUN TIME
1814          CLR      XDELAY            ;ABORT MICRO-SEC WAIT
1815          CLR      YDELAY            ;ABORT MILLI-SEC WAIT
1816          .ENDM
1817
1818          .MACRO  GETTIM  ARG          ;MACRO GET ELAPSED TIME
1819          MOV      @CLKCTR,ARG        ;STORE CLOCK COUNTER CONTENTS
1820          CLR      @CLKCSR           ;EVENT FINISHED, STOP CLOCK
1821          .ENDM
1822
1823          .MACRO  STCLK          ;MACRO START P-CLOCK
1824          CLR      @CLKCSB           ;CLEAR CLOCK COUNT SET BUFFER
1825          CLR      @CLKCTR           ;CLEAR CLOCK COUNTER
1826          MOV      @23,@CLKCSR       ;INITIALIZE CLOCK FOR COUNT-UP MODE,
1827          ;/10 KHZ RATE, AND START CLOCK
1828          .ENDM
1829
1830          .NLIST  CND,MD,ME
1831
1832 002000          POINTER  BGNSW,BGNSFT,BGNDU
1833
1834 002000          BGNMOD  MDHEDR
1839 002000          HEADER  CNRLJ,A,0,30000,0,PRI06          ;JSD REV A - ADDED PRI06
          002000          103          .ASCII  /C/
          002001          116          .ASCII  /N/
          002002          122          .ASCII  /R/
          002003          114          .ASCII  /L/
          002004          112          .ASCII  /J/
          002005          000          .BYTE   0
          002006          000          .BYTE   0
          002007          000          .BYTE   0
          002010          101          .ASCII  /A/
          002011          060          .ASCII  /O/
    
```

MACRO DEFINITIONS

002012	000000	.WORD	0
002014	030000	.WORD	30000
002016	030652	.WORD	L\$HARD
002020	031026	.WORD	L\$SOFT
002022	013540	.WORD	L\$HW
002024	013556	.WORD	L\$SW
002026	031370	.WORD	L\$LAST
002030	000000	.WORD	0
002032	000000	.WORD	0
002034	000000	.WORD	0
002036	000000	.WORD	0
002040	013574	.WORD	L\$DISPATCH
002042	000300	.WORD	PRI06
002044	000000	.WORD	0
002046	000000	.WORD	0
002050	003	.BYTE	C\$REVISION
002051	003	.BYTE	C\$EDIT
002052	000000	.WORD	0
002054	000000	.WORD	0
002056	000000	.WORD	0
002060	002226	.WORD	L\$DVTYP
002062	000000	.WORD	0
002064	000000	.WORD	0
002066	000000	.WORD	0
002070	000000	.WORD	0
002072	015300	.WORD	L\$DU
002074	000000	.WORD	0
002076	002122	.WORD	L\$DESC
002100	104035	EMT	E\$LOAD
002102	000000	.WORD	0
002104	013616	.WORD	L\$INIT
002106	015152	.WORD	L\$CLEAN
002110	014614	.WORD	L\$AUTO
002112	013530	.WORD	L\$PROT
002114	000000	.WORD	0
002116	000000	.WORD	0
002120	000000	.WORD	0

1841 002122
 1842
 1843

ENDMOD

DESCRIPT <CNRLJ TESTS OUTER & INNER GUARD BAND DETECTION AND SEEK OPERATIONS>
 .ASCIZ /CNRLJ TESTS OUTER & INNER GUARD BAND DETECTION AND SEEK OPERATIONS/

002122	103	116	122
002125	114	112	040
002130	124	105	123
002133	124	123	040
002136	117	125	124
002141	105	122	040
002144	046	040	111
002147	116	116	105
002152	122	040	107
002155	125	101	122
002160	104	040	102
002163	101	116	104
002166	040	104	105
002171	124	105	103
002174	124	111	117
002177	116	040	101
002202	116	104	040

MACRO DEFINITIONS

```

002205 123 105 105
002210 113 040 117
002213 120 105 122
002216 101 124 111
002221 117 116 123
002224 000

                                .EVEN
1844
1845 002226 DEVTYP <RLO1,RLO2>
                                .ASCIZ *RLO1,RLO2*
002226 122 114 060
002231 061 054 122
002234 114 060 062
002237 000

                                .EVEN
1846
1847 .SBTTL GLOBAL DATA SECTION
1848
1849 002240 BGNMOD GLBEQAT
1850
1851 002240 EQUALS
;
; BIT DIFINITIONS
;
100000 BIT15-- 100000
040000 BIT14-- 40000
020000 BIT13-- 20000
010000 BIT12-- 10000
004000 BIT11-- 4000
002000 BIT10-- 2000
001000 BIT09-- 1000
000400 BIT08-- 400
000200 BIT07-- 200
000100 BIT06-- 100
000040 BIT05-- 40
000020 BIT04-- 20
000010 BIT03-- 10
000004 BIT02-- 4
000002 BIT01-- 2
000001 BIT00-- 1
;
001000 BIT9-- BIT09
000400 BIT8-- BIT08
000200 BIT7-- BIT07
000100 BIT6-- BIT06
000040 BIT5-- BIT05
000020 BIT4-- BIT04
000010 BIT3-- BIT03
000004 BIT2-- BIT02
000002 BIT1-- BIT01
000001 BIT0-- BIT00
;
; EVENT FLAG DEFINITIONS
; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
;
;
; BIT POSITION IN SECOND STATUS WORD
000040 EF.START-- 32. ; (100000) START COMMAND WAS ISSUED
000037 EF.RESTART-- 31. ; (040000) RESTART COMMAND WAS ISSUED

```

GLOBAL DATA SECTION

```

000036 EF.CONTINUE = 30. ; (020000) CONTINUE COMMAND WAS ISSUED
000035 EF.NEW== 29. ; (010000) A NEW PASS HAS BEEN STARTED
000034 EF.PWR== 28. ; (004000) A POWER FAIL/POWER UP OCCURRED

```

; PRIORITY LEVEL DEFINITIONS

```

000340 PRI07== 340
000300 PRI06== 300
000240 PRI05== 240
000200 PRI04== 200
000140 PRI03== 140
000100 PRI02== 100
000040 PRI01== 40
000000 PRI00== 0

```

; OPERATOR FLAG BITS

```

000004 EVL== 4
000010 LOT== 10
000020 ADR== 20
000040 IDU== 40
000100 ISR== 100
000200 UAM== 200
000400 BOE== 400
001000 PNT== 1000
002000 PRI== 2000
004000 IXE== 4000
010000 IBE== 10000
020000 IER== 20000
040000 LOE== 40000
100000 HOE== 100000

```

; OFFSETS FOR HARDWARE P-TABLE

```

1852 000000 CSR =0 ;BUS ADDRESS
1853 000002 VECT =2 ;VECTOR ADDRESS
1854 000004 PRIOR =4 ;PRIORITY
1855 000006 TYPDR=6
1856 000010 DRSB =10 ;DRIVE SELECT BIT
1857 000012 CNT =12 ;CONTROLLER TYPE

```

; OFFSET FOR SOFTWARE P-TABLE

```

1860 000000 MISWI =0 ;SOFTWARE PARAMETERS SWITCHES
1861 000002 LOLIM =2 ;CYLINDER LOWER LIMIT
1862 000004 HILIM =4 ;CYLINDER HIGH LIMIT
1863 000006 HEAD =6 ;SELECTED HEAD FOR RUNNING TESTS
1864 000010 ERLIM =10 ;ERROR LIMIT
1865 000012 DCLIM =12 ;DATA COMPARE ERROR LIMIT

```

; BIT ASSIGNMENT FOR SOFTWARE P-TABLE SWITCHES

```

1868 000001 ALLCYL =BIT00 ;USE ALL CYLINDERS
1869 000002 ALLSEC =BIT01 ;USE ALL SECTORS
1870 000004 DRSELT =BIT02 ;EXECUTE DRIVE SELECT TEST
1871 000010 HDALIGN =BIT03 ;EXECUTE HEAD ALIGNMENT TEST
1872 010000 HEADLM =BIT12 ;HEAD LIMIT SPECIFIED FLAG
1873 020000 HICYL =BIT13 ;HI LIMIT SPECIFIED FLAG
1874 040000 LOCYL =BIT14 ;LO LIMIT SPECIFIED
1875 100000 MITEST =BIT15 ;EXECUTE MANUAL INTERVENTION TESTS
1876

```


GLOBAL DATA SECTION

```

1877
1878
1879      000102      ; SUBSYSTEM FUNCTIONS
1880      000104      CKDATA =102      ;WRITE CHECK
1881      000106      GTSTAT =104      ;GET STATUS
1882      000110      SEEK =106      ;SEEK
1883      000112      RDHEAD =110      ;READ HEADER
1884      000114      WTDATA =112      ;WRITE DATA
1885      000116      RDATA =114      ;READ DATA
1886      000100      RDNOMR =116      ;READ DATA, IGNORE HEADERS
1887      NOOP =100      ;NO OPERATION
1888
1889      007777      ; OPERATION FLAGS
1890      000002      COMPOP =7777      ;COMPOSITE OPERATION FLAGS
1891      000001      HDRCMP =BIT01      ;HEADER COMPARE OPERATION
1892      000004      DATACMP =BIT00      ;DATA COMPARE OPERATION
1893      000010      CYLUP =BIT02      ;CYCLE UP OPERATION
1894      000020      ULOAD =BIT03      ;UNLOAD OPERATION
1895      000040      INOUTS =BIT04      ;IN-OUT SEEK OPERATION
1896      000100      OUTINS =BIT05      ;OUT-IN SEEK OPERATION
1897      000200      FOLWRT =BIT06      ;FOLLOWING WRITE OPERATION
1898      000400      REVSKS =BIT07      ;REV SEEK SEQ (ADJ INTERFERENCE)
1899      001000      FWDSKS =BIT08      ;FWD SEEK SEQ (ADJ INTERFERENCE)
1900      002000      REVSKO =BIT09      ;REV SEEK SEQ (OVERWRITE)
1901      004000      FWDSKO =BIT10      ;FWD SEEK SEQ (OVERWRITE)
1902      010000      BADADD =BIT11      ;BAD DISK ADDRESS
1903      020000      SEEKOP =BIT12      ;SEEK OPERATION
1904      040000      RORWOP =BIT13      ;READ OR WRITE OPERATION
1905      100000      RELDWT =BIT14      ;RELOAD WAIT
1906      003760      HDR40 =BIT15      ;40 HEADER OPERATION
1907      MQUALS =OUTINS!INOUTS!FOLWRT!REVSKS!FWDSKS!REVSKO!FWDSKO
1908      ;MESSAGE QUALIFIER BITS
1909
1910      000001      ; ERROR FLAGS FROM SUBROUTINES
1911      000002      TOSLOW =BIT00      ;OPERATION TOOK TOO LONG
1912      000004      NOIRPT =BIT01      ;NO INTERRUPT FROM OPERATION
1913      000010      CONHNG =BIT02      ;CONTROLLER HUNG
1914      NOCLR =BIT03      ;BAD CONTROLLER CLEAR
1915
1916      000000      RLCS =0      ;CONTROL AND STATUS REGISTER
1917      000002      RLBA =2      ;BUS ADDRESS REGISTER
1918      000004      RLDA =4      ;DISK ADDRESS REGISTER
1919      000006      RLMP =6      ;MULTI-PURPOSE REGISTER
1920
1921      000000      ; REGISTER BIT DEFINITIONS - CONTROL STATUS REGISTER
1922      100000      RLCSR =0      ;CONTROL AND STATUS REGISTER
1923      040000      ANYERR =100000      ;ANY ERROR BIT
1924      020000      DRVERR =40000      ;DRIVE ERROR BIT
1925      010000      NXMERR =20000      ;NON-EXISTANT MEMORY ERROR
1926      010000      DLTERR =10000      ;DATA LATE ERROR
1927      004000      HNFERR =10000      ;HEADER NOT FOUND ERROR
1928      004000      DCKERR =4000      ;DATA CHECK ERROR
1929      002000      HCRCERR =4000      ;HEADER CHECK ERROR
1930      001400      OPIERR =2000      ;OPERATION INCOMPLETE ERROR
1931      000200      DSMSK =1400      ;DRIVE SELECT MASK
1932      000100      CRDYMSK =200      ;CONTROLLER READY MASK
1933      000060      INTEBL =100      ;INTERRUPT ENABLE MASK
1934      BMSK =60      ;BUS ADDRESS UPPER MASK

```

GLOBAL DATA SECTION

```

1934      000001      DRDYMSK  =1          ;DRIVE READY MASK
1935
1936      ;          REGISTER BIT DEFINITIONS  DISK ADDRESS FOR DATA XFER
1937      SAMS  =77          ;SECTOR ADDRESS MASK
1938      000077      MSMSK   =100         ;HEAD SELECT MASK
1939
1940      ;          REGISTER BIT DEFINITIONS  DISK ADDRESS FOR SEEK
1941      MBSETO =1          ;MUST BE SET, BIT 0
1942      000004      DIRBIT  =4          ;DIRECTION BIT
1943      000020      HDSEL   =20         ;HEAD SELECT BIT
1944
1945      ;          REGISTER BIT DEFINITIONS  DISK ADDRESS FOR GET STATUS
1946      GETSTAT =3          ;GET STATUS SETUP
1947      000010      DRSET   =10        ;DRIVE RESET MASK
1948
1949      ;          REGISTER BIT DEFINITIONS  - MP FOR DATA XFER
1950      WCMSK   =17777     ;WORD COUNT MASK
1951      160000   WCRNG    =160000    ;WORD COUNT RANGE MASK
1952
1953      ;          REGISTER BIT DEFINITIONS  - MP FOR READ HEADER
1954      HDSEC   =77          ;SECTOR MASK
1955      000100   HDHSEL   =100        ;HEAD SELECT MASK
1956
1957      ;          REGISTER BIT DEFINITIONS  - MP FOR GET STATUS
1958      STAMSK  =7          ;STATE MASK
1959      000010   BHSTAT   =10         ;BRUSH HOME STATUS
1960      000020   HOSTAT   =20         ;HEADS OUT STATUS
1961      000040   COSTAT   =40         ;COVER OPEN STATUS
1962      000100   HSSTAT   =100        ;HEAD SELECT STATUS
1963      000400   DSESTAT  =400        ;DRIVE SELECT ERROR STATUS
1964      001000   VCSTAT   =1000       ;VOLUME CHECK STATUS
1965      002000   WGESTAT  =2000       ;WRITE GATE ERROR STATUS
1966      004000   SPDSTAT  =4000       ;SPIN ERROR STATUS
1967      010000   STOSTAT  =10000      ;SEEK TIMEOUT ERROR STATUS
1968      020000   WLSTAT   =20000      ;WRITE LOCK STATUS
1969      040000   HCESTAT  =40000      ;HEAD CURRENT ERROR STATUS
1970      100000   WDESTAT  =100000     ;WRITE DATA ERROR STATUS
1971
1972      ;          P-CLOCK REGISTERS
1973      172540   CLKCSR   =172540     ;CLOCK CONTROL AND STATUS REGISTER
1974      172542   CLKCSB  =172542     ;CLOCK COUNT SET BUFFER
1975      172544   CLKCTR  =172544     ;CLOCK COUNTER
1976
1977 002240      ENDMOD
1978
1979      .SBTTL  GLOBAL DATA SECTION
1980
1981 002240      BGNMOD  GLBDAT
1982
1983      ;          TABLE OF OPERATION MESSAGES
1984
1985 002240 000000  OPMSG0: .WORD 0          ;FILLER
1986 002242 005405  .WORD MWRCHK      ;MESSAGE FOR WRITE CHECK
1987 002244 005430  .WORD MGTSTA      ;
1988 002246 005360  .WORD MSEEK       ;
1989 002250 005375  .WORD MREADH      ;
1990 002252 005416  .WORD MWRITE      ;

```

GLOBAL DATA SECTION

1991	002254	005364	.WORD	MREAD	:	READ DATA
1992	002256	005513	.WORD	MWRSET	:	WITH RESET
1993	002260	005442	.WORD	MDATCP	:	WITH DATA COMPARE
1994	002262	005461	.WORD	MMDRCP	:	WITH HEADER COMPARE
1995	002264	005560	.WORD	MCYLUP	:	LOAD HEADS
1996	002266	005547	.WORD	MULOAD	:	UNLOAD HEADS
1997	002270	005607	.WORD	MINOUT	:	IN-OUT SEQ
1998	002272	005570	.WORD	MOUTIN	:	OUT IN SEQ
1999	002274	005630	.WORD	MFOLWRT	:	FOLLOWING WRITE
2000	002276	005650	.WORD	MREVSK	:	REV SEEK
2001	002300	005701	.WORD	MFWDISK	:	FWD SEEK
2002	002302	005766	.WORD	MRESKO	:	REV SEEK
2003	002304	005732	.WORD	MFWSKO	:	FWD SEEK
2004	002306	006022	.WORD	MBADAD	:	BAD DISK ADD FOR WRITE
2005	002310	005477	.WORD	M40HDR	:	40 HEADER OPERATION
2006	002312	000000	T.DRIVE: .WORD	0		
2007	002314	000000	JJJ: .WORD	0		
2008	002316	000000	HLMTW: .WORD	0		
2009	002320	000000	CLRBYT: .WORD	0		
2010	002322	000000	NXTHL: .WORD	0		
2011	002324	000000	GBND: .WORD	0		
2012	002326	000000	CAMSK: .WORD	0		
2013	002330	000000	DIRMSK: .WORD	0		
2014	002332	000000	HDCYL: .WORD	0		
2015						
2016						
2017	002334	007771	: .WORD	TABLE OF RESULT NAME MESSAGE ADDRESSES		
2018	002336	010102	RFSTBL: .WORD	MCERR	:	CONTROLLER ERROR
2019	002340	010320	.WORD	MDRERR	:	DRIVE ERROR
2020	002342	010272	.WORD	MNEERR	:	NON-EXISTANT MEMORY ERROR
2021	002344	010255	.WORD	MFLERR	:	HEADER NOT FOUND-DATA LATE
2022	002346	010245	.WORD	MHDERR	:	HEADER OR DATA ERROR
2023	002350	010352	.WORD	MOPERR	:	OPERATION INCOMPLETE
2024	002352	000000	.WORD	MMDRST	:	NO DRIVE STATUS AVAILABLE
2025	002354	010230	.WORD	0		
2026	002356	010212	.WORD	MWDERR	:	WRITE DATA ERROR
2027	002360	000000	.WORD	MHCERR	:	HEAD CURRENT ERROR
2028	002362	010176	.WORD	0		
2029	002364	010143	.WORD	MSTERR	:	SEEK TIMEOUT ERROR
2030	002366	010161	.WORD	MSPERR	:	SPINDLE ERROR
2031	002370	000000	.WORD	MWGERR	:	WRITE GATE ERROR
2032	002372	010113	.WORD	0		
2033			.WORD	MDSERR	:	DRIVE SELECT ERROR
2034						
2035	002374	005102	: .WORD	PATTERN TABLE		
2036	002376	005104	PATTBL: .WORD	PAT1		
2037	002400	005144	.WORD	PAT2		
2038	002402	005204	.WORD	PAT3		
2039	002404	005244	.WORD	PAT4		
2040	002406	005252	.WORD	PAT5		
2041	002410	005312	.WORD	PAT6		
2042	002412	005314	.WORD	PAT7		
2043	002414	005354	.WORD	PAT8		
2044	002416	005356	.WORD	PAT9		
2045			.WORD	PAT10		
2046						
2047	002420	000000	: .WORD	SUBROUTINE CALLING STACK		
			SUBSTK: .WORD	0	:	STACK IS 12 WORDS LONG

GLOBAL DATA SECTION

2048 002422 000000
 2049 002424 000000
 2050 002426 000000
 2051 002430 000000
 2052 002432 000000
 2053 002434 000000
 2054 002436 000000
 2055 002440 000000
 2056 002442 000000
 2057
 2058
 2059 002444 000002
 2060 002446 000006
 2061 002450 000011
 2062 002452 000014
 2063 002454 000021
 2064 002456 000026
 2065 002460 000033
 2066 002462 000042
 2067 002464 000051
 2068 002466 000200
 2069 002470 000377
 2070
 2071
 2072 002472 000004
 2073 002474 000014
 2074 002476 000022
 2075 002500 000030
 2076 002502 000042
 2077 002504 000054
 2078 002506 000066
 2079 002510 000104
 2080 002512 000122
 2081 002514 000400
 2082 002516 000777
 2083
 2084
 2085
 2086 002520
 2087 002560
 2088
 2089 002620 002
 2090 002621 007
 2091 002622 016
 2092 002623 024
 2093 002624 033
 2094 002625 041
 2095 002626 046
 2096 002627 055
 2097 002630 064
 2098 002631 072
 2099 002632 101
 2100 002633 110
 2101 002634 115
 2102 002635 124
 2103 002636 133
 2104 002637 141

.WORD 0
 .WORD 0
 .WORD 0
 .WORD 0
 .WORD 0
 .WORD 0
 .WORD 0
 .WORD 0
 .WORD 0
 .WORD 0

;RLO1 TABLE OF CYLINDERS

T25TBL: .WORD 2
 .WORD 6
 .WORD 9.
 .WORD 12.
 .WORD 17.
 .WORD 22.
 .WORD 27.
 .WORD 34.
 .WORD 41.
 .WORD 128.
 .WORD 255.

;TABLE OF DIFFERENCES

;RLO2 TABLE OF CYLINDERS

T25T82: .WORD 4
 .WORD 12.
 .WORD 18.
 .WORD 24.
 .WORD 34.
 .WORD 44.
 .WORD 54.
 .WORD 68.
 .WORD 82.
 .WORD 256.
 .WORD 511.

; TABLE TO BE USED TO BUILD AND STORE THE CYLINDERS

T33TBL: .BLKW 16.
 TBT: .BLKW 16.

CYLTBL: .BYTE 2 ;TABLE OF DEFAULT CYLINDERS

.BYTE 7.
 .BYTE 14.
 .BYTE 20.
 .BYTE 27.
 .BYTE 33.
 .BYTE 38.
 .BYTE 45.
 .BYTE 52.
 .BYTE 58.
 .BYTE 65.
 .BYTE 72.
 .BYTE 77.
 .BYTE 84.
 .BYTE 91.
 .BYTE 97.

GLOBAL DATA SECTION

2105	002640	146	.BYTE	102.
2106	002641	154	.BYTE	108.
2107	002642	161	.BYTE	113.
2108	002643	170	.BYTE	120.
2109	002644	177	.BYTE	127.
2110	002645	206	.BYTE	134.
2111	002646	213	.BYTE	139.
2112	002647	222	.BYTE	146.
2113	002650	230	.BYTE	152.
2114	002651	235	.BYTE	157.
2115	002652	244	.BYTE	164.
2116	002653	252	.BYTE	170.
2117	002654	261	.BYTE	177.
2118	002655	270	.BYTE	184.
2119	002656	275	.BYTE	189.
2120	002657	303	.BYTE	195.
2121	002660	312	.BYTE	202.
2122	002661	317	.BYTE	207.
2123	002662	326	.BYTE	214.
2124	002663	334	.BYTE	220.
2125	002664	343	.BYTE	227.
2126	002665	352	.BYTE	234.
2127	002666	361	.BYTE	241.
2128	002667	367	.BYTE	247.
2129	002670	375	.BYTE	253.
2130	002671	000	.BYTE	0
2131	002672	000401	.WORD	257.
2132	002674	000406	.WORD	262.
2133	002676	000415	.WORD	269.
2134	002700	000423	.WORD	275.
2135	002702	000432	.WORD	282.
2136	002704	000445	.WORD	293.
2137	002706	000454	.WORD	300.
2138	002710	000463	.WORD	307.
2139	002712	000471	.WORD	313.
2140	002714	000500	.WORD	320.
2141	002716	000507	.WORD	327.
2142	002720	000514	.WORD	332.
2143	002722	000523	.WORD	339.
2144	002724	000532	.WORD	346.
2145	002726	000540	.WORD	352.
2146	002730	000545	.WORD	357.
2147	002732	000553	.WORD	363.
2148	002734	000560	.WORD	368.
2149	002736	000567	.WORD	375.
2150	002740	000576	.WORD	382.
2151	002742	000605	.WORD	389.
2152	002744	000612	.WORD	394.
2153	002746	000621	.WORD	401.
2154	002750	000627	.WORD	407.
2155	002752	000634	.WORD	412.
2156	002754	000643	.WORD	419.
2157	002756	000651	.WORD	425.
2158	002760	000660	.WORD	432.
2159	002762	000667	.WORD	439.
2160	002764	000674	.WORD	444.
2161	002766	000702	.WORD	450.

GLOBAL DATA SECTION

2162	002770	000711	.WORD	457.	
2163	002772	000716	.WORD	462.	
2164	002774	000725	.WORD	469.	
2165	002776	000733	.WORD	475.	
2166	003000	000742	.WORD	482.	
2167	003002	000751	.WORD	489.	
2168	003004	000760	.WORD	496.	
2169	003006	000766	.WORD	502.	
2170	003010	000774	.WORD	508.	
2171	003012	000774	.WORD	508.	
2172	003014	000000	.WORD	0	
2173	003016	000000	SSINDX: .WORD	0	;SUBROUTINE STACK INDEX POINTER
2174					
2175					
2176	003020	000000	OPFLAG: .WORD	0	;OPERATION FLAGS
2177	003022	000000	DONE: .WORD	0	;OPERATION COMPLETE FLAG
2178	003024	000000	HADONE: .WORD	0	;HEAD ALIGNMENT DONE FLAG
2179	003026	000000	ERHEAD: .WORD	0	;ADDRESS OF ERROR HEADER
2180	003030	000000	MORECE: .WORD	0	;MORE THAN 1 COMPARE ERROR
2181	003032	000000	ERRSWI: .WORD	0	;ERROR RETURN SWITCH
2182	003034	000000	BSFLAG: .WORD	0	;BAD SECTOR FLAGS
2183	003036	000000	WRTSWI: .WORD	0	;WRITE SWITCH
2184	003040	000000	TBLSTR: .WORD	0	;TABLE STORAGE
2185					
2186	003042	000000	RLBAS: .WORD	0	;RL11 BASE ADDRESS
2187	003044	000000	RLVEC: .WORD	0	;RL11 VECTOR ADDRESS
2188	003046	000000	RLDRV: .WORD	0	;DRIVE NUMBER UNDER TEST
2189					
2190	003050	000000	L.CS: .WORD	0	;CONTROLLER REGISTER STORAGE
2191	003052	000000	L.BA: .WORD	0	;BEFORE OPERATION
2192	003054	000000	L.DA: .WORD	0	
2193	003056	000000	L.MP: .WORD	0	
2194	003060	000000	T.CS: .WORD	0	;CONTROLLER REGISTER STORAGE
2195	003062	000000	T.BA: .WORD	0	; AFTER OPERATION
2196	003064	000000	T.DA: .WORD	0	
2197	003066	000000	T.MP: .WORD	0	
2198	003066	000000	HWORD1: .WORD	0	;HEADER WORD STORAGE
2199	003070	000000	HWORD2: .WORD	0	
2200	003072	000000	HWORD3: .WORD	0	
2201					
2202	003074	000000	T.STAT: .WORD	0	;DRIVE STATE STORAGE
2203					
2204	003076	000000	RESPARM: .WORD	0	;PARAM BLOCK FOR REASON REPORT
2205	003100	000000	.WORD	0	
2206	003102	000000	.WORD	0	
2207	003104	000000	.WORD	0	
2208	003106	000000	.WORD	0	
2209					
2210	003110	000000	DRVCNT: .WORD	0	;DRIVE COUNT FOR DRIVES UNDER TEST
2211	003112	000000	DIFAUG: .WORD	0	;DIFFERENCE AUGMENT FOR SEEK
2212	003114	000000	OLDCYL: .WORD	0	;OLD CYLINDER
2213	003116	000000	NEWCYL: .WORD	0	;NEW CYLINDER
2214	003120	000000	CURCYL: .WORD	0	;CURRENT CYLINDER
2215	003122	000000	DESDIF: .WORD	0	;DESIRED DIFFERENCE
2216	003124	000000	DESSGN: .WORD	0	;DESIRED SIGN
2217	003126	000000	DESHD: .WORD	0	;DESIRED HEAD
2218	003130	000000	DESSEC: .WORD	0	;DESIRED SECTOR

GLOBAL DATA SECTION

2219	003132	000000	TEMPO:	.WORD	0	; TEMPORARY STORAGE
2220	003134	000000	TEMP1:	.WORD	0	; TEMPORARY STORAGE
2221	003136	000000	TEMP2:	.WORD	0	; TEMPORARY STORAGE
2222	003140	000000	TEMP3:	.WORD	0	; TEMPORARY STORAGE
2223	003142	000000	TEMP4:	.WORD	0	; TEMPORARY STORAGE
2224	003144	000000	TEMP5:	.WORD	0	; TEMPORARY STORAGE
2225	003146	000000	TEMP6:	.WORD	0	; TEMPORARY STORAGE
2226	003150	000000	TEMP7:	.WORD	0	; TEMPORARY STORAGE
2227	003152	000000	TEMP8:	.WORD	0	; TEMPORARY STORAGE
2229			:	TIMER STORAGE		
2230	003154	000000	OFIN:	.WORD	0	; ONE CYLINDER FORWARD INNER
2231	003156	000000	OFINU:	.WORD	0	; UPPER
2232	003160	000000	OFMID:	.WORD	0	; ONE CYLINDER FORWARD MIDDLE
2233	003162	000000	OFMIDU:	.WORD	0	; UPPER
2234	003164	000000	OFOUT:	.WORD	0	; ONE CYLINDER FORWARD OUTER
2235	003166	000000	OFOUTU:	.WORD	0	; UPPER
2236	003170	000000	ORIN:	.WORD	0	; ONE CYLINDER REVERSE INNER
2237	003172	000000	ORINU:	.WORD	0	; UPPER
2238	003174	000000	ORMID:	.WORD	0	; ONE CYLINDER REVERSE MIDDLE
2239	003176	000000	ORMIDU:	.WORD	0	; UPPER
2240	003200	000000	OROUT:	.WORD	0	; ONE CYLINDER REVERSE OUTER
2241	003202	000000	OROUTU:	.WORD	0	; UPPER
2242	003204	000000	HFIN:	.WORD	0	; 128 CYLINDER FORWARD INNER
2243	003206	000000	HFINU:	.WORD	0	; UPPER
2244	003210	000000	HFOUT:	.WORD	0	; 128 CYLINDER FORWARD OUTER
2245	003212	000000	HFOUTU:	.WORD	0	; UPPER
2246	003214	000000	HRIN:	.WORD	0	; 128 CYLINDER REVERSE INNER
2247	003216	000000	HRINU:	.WORD	0	; UPPER
2248	003220	000000	HROUT:	.WORD	0	; 128 CYLINDER REVERSE OUTER
2249	003222	000000	HROUTU:	.WORD	0	; UPPER
2250	003224	000000	AFMID:	.WORD	0	; 256 CYLINDER FORWARD
2251	003226	000000	AFMIDU:	.WORD	0	; UPPER
2252	003230	000000	ARMID:	.WORD	0	; 256 CYLINDER REVERSE
2253	003232	000000	ARMIDU:	.WORD	0	; UPPER
2254						
2255	003234	000226	EXOCYL:	.WORD	150.	; EXPECTED TIME ONE CYLINDER
2256	003236	001046	EXHCYL:	.WORD	550.	; EXPECTED TIME 128 CYLINDER
2257	003240	001750	EXACYL:	.WORD	1000.	; EXPECTED TIME 256 CYLINDER
2258	003242	000372	EXROT:	.WORD	250.	; EXPECTED ROTATION TIME
2260	003244	000004	ERRVEC:	.WORD	4	; ERROR VECTOR
2261						
2262			:	MISCELLANEOUS COUNTERS		
2263	003246	000000	PASCNT:	.WORD	0	; PASS COUNTER (LOCAL TO A TEST)
2264	003250	000000	COUNT:	.WORD	0	; A COUNTER (LOCAL TO A TEST)
2265	003252	000000	ERRPOINT:	.WORD	0	; ERROR POINTER
2266	003254		ERRCNT:	.BLKW	64.	; ERROR COUNTER FOR PROGRAM
2267	003454	000000	PASNUM:	.WORD	0	; PASS NUMBER FOR PROGRAM
2268	003456	000000	PSETNM:	.WORD	0	; COUNTER FOR PARAMETER SET NUMBER IN USE
2269	003460	000	LOCERR:	.BYTE	0	; LOCAL ERROR COUNTER
2270	003461	000	NOERCT:	.BYTE	0	; INHIBIT ERROR COUNTING FLAG
2271	003462	000000	TRPFLG:	.WORD	0	; HARDWARE TRAP OCCURANCE
2272	003464	000000	PWRFLG:	.WORD	0	; POWER FAILURE OCCURANCE
2273	003466	000000	XDELAY:	.WORD	0	
2274	003470	000000	YDELAY:	.WORD	0	
2275	003472	000000	MININC:	.WORD	0	
2276	003474	000000	TEMP:	.WORD	0	
2277	003476	000000	TIM.US:	.WORD	0	

GLOBAL DATA SECTION

2278	003500	000000	TAG:	.WORD	0	
2279	003502	000000	MAJINC:	.WORD	0	
2280	003504	000000	CLKFLG:	.WORD	0	;FLAG INDICATING PRESENCE OF A P-CLOCK
2281	003506	000000	CLKADR:	.WORD	0	;POINTER TO DIAGNOSTIC MONITOR CLOCK TABLE
2282						
2283			:			BAD SECTOR TABLES AND POINTERS
2284	003510	000000	BSFVAL:	.WORD	0	;BAD SECTORS FILES VALID FLAG
2285						
2286	003512		SBSFIL:	.BLKW	76	;SOFTWARE BAD SECTOR FILE
2287	003706		FBSFIL:	.BLKW	76	;FACTORY BAD SECTOR FILE
2288						
2289	004102		IBUFF:	.BLKW	200	;INPUT BUFFER
2290	004502		OBUFF:	.BLKW	200	;OUTPUT BUFFER
2291						
2292	005102	000000	PAT1:	.WORD	0	;PATTERN 1 (ALL ZEROS)
2293	005104	177772	PAT2:	.WORD	177772	
2294	005106	177777		.WORD	177777	
2295	005110	177777		.WORD	177777	
2296	005112	052525		.WORD	052525	
2297	005114	052525		.WORD	052525	
2298	005116	052525		.WORD	052525	
2299	005120	177777		.WORD	177777	
2300	005122	177777		.WORD	177777	
2301	005124	052525		.WORD	052525	
2302	005126	052525		.WORD	052525	
2303	005130	177777		.WORD	177777	
2304	005132	052525		.WORD	052525	
2305	005134	177252		.WORD	177252	
2306	005136	177252		.WORD	177252	
2307	005140	172765		.WORD	172765	
2308	005142	172765		.WORD	172765	
2309						
2310	005144	000003	PAT3:	.WORD	000003	
2311	005146	000000		.WORD	000000	
2312	005150	000000		.WORD	000000	
2313	005152	177777		.WORD	177777	
2314	005154	177777		.WORD	177777	
2315	005156	177777		.WORD	177777	
2316	005160	000000		.WORD	000000	
2317	005162	000000		.WORD	000000	
2318	005164	177777		.WORD	177777	
2319	005166	177777		.WORD	177777	
2320	005170	000000		.WORD	000000	
2321	005172	177777		.WORD	177777	
2322	005174	000000		.WORD	000000	
2323	005176	177777		.WORD	177777	
2324	005200	000000		.WORD	000000	
2325	005202	177777		.WORD	177777	
2326						
2327	005204	025252	PAT4:	.WORD	025252	
2328	005206	052525		.WORD	052525	
2329	005210	052525		.WORD	052525	
2330	005212	125252		.WORD	125252	
2331	005214	125252		.WORD	125252	
2332	005216	125252		.WORD	125252	
2333	005220	052525		.WORD	052525	
2334	005222	052525		.WORD	052525	

GLOBAL DATA SECTION

2335	005224	125252	.WORD	125252
2336	005226	125252	.WORD	125252
2337	005230	052525	.WORD	052525
2338	005232	125252	.WORD	125252
2339	005234	052525	.WORD	052525
2340	005236	125252	.WORD	125252
2341	005240	052525	.WORD	052525
2342	005242	125252	.WORD	125252
2343				
2344	005244	155555	PAT5: .WORD	155555
2345	005246	133333	.WORD	133333
2346	005250	066666	.WORD	066666
2347				
2348	005252	121105	PAT6: .WORD	121105
2349	005254	150442	.WORD	150442
2350	005256	064221	.WORD	064221
2351	005260	132110	.WORD	132110
2352	005262	055044	.WORD	055044
2353	005264	026442	.WORD	026442
2354	005266	013211	.WORD	013211
2355	005270	105504	.WORD	105504
2356	005272	042642	.WORD	042642
2357	005274	021321	.WORD	021321
2358	005276	110550	.WORD	110550
2359	005300	044264	.WORD	044264
2360	005302	022132	.WORD	022132
2361	005304	011055	.WORD	011055
2362	005306	104426	.WORD	104426
2363	005310	042213	.WORD	042213
2364				
2365	005312	177777	PAT7: .WORD	177777
2366				
2367	005314	045513	PAT8: .WORD	045513
2368	005316	122645	.WORD	122645
2369	005320	151322	.WORD	151322
2370	005322	064551	.WORD	064551
2371	005324	132264	.WORD	132264
2372	005326	055132	.WORD	055132
2373	005330	026455	.WORD	026455
2374	005332	113226	.WORD	113226
2375	005334	045513	.WORD	045513
2376	005336	122645	.WORD	122645
2377	005340	151322	.WORD	151322
2378	005342	064551	.WORD	064551
2379	005344	132264	.WORD	132264
2380	005346	055132	.WORD	055132
2381	005350	026455	.WORD	026455
2382	005352	113226	.WORD	113226
2383				
2384	005354	125252	PAT9: .WORD	125252
2385				
2386	005356	155555	PAT10: .WORD	155555
2387				
2388	005360		ENDMOD	
2389				
2393				
2394			.SBTTL	GLOBAL MESSAGES

GLOBAL MESSAGES

J4

			BGNMOD	GLBTXT
2395				
2396	005360			
2397				
2398	005360	123	113	040 MSEEK: .ASCIZ /SK /
2399	005364	122	104	040 MREAD: .ASCIZ /RD DATA /
2400	005375	122	104	040 MREADH: .ASCIZ /RD HDR /
2401	005405	127	122	124 MWRCHK: .ASCIZ /WRT CHCK/
2402	005416	127	122	124 MWRITE: .ASCIZ /WRT DATA /
2403	005430	107	105	124 MGTSTA: .ASCIZ /GET STAT /
2404	005442	127	111	124 MDATCP: .ASCIZ /WITH DATA CMP /
2405	005461	127	111	124 MHDRCP: .ASCIZ /WITH HDR CMP /
2406	005477	106	117	122 M40HDR: .ASCIZ /FOR 40 HDRS/
2407	005513	127	111	124 MWRSET: .ASCIZ /WITH RESET /
2408	005527	117	120	105 MOPER: .ASCIZ /OPER: /
2409	005536	122	105	123 MRSLT: .ASCIZ /RESULT: /
2410	005547	125	116	114 MLOAD: .ASCIZ /UNLD DRV/
2411	005560	114	104	040 MCYLUP: .ASCIZ /LD DRV /
2412	005570	106	117	114 MOUTIN: .ASCIZ /FOL 0 TO CC SK/
2413	005607	106	117	114 MINOUT: .ASCIZ /FOL 255 TO CC SK/
2414	005630	106	117	114 MFOLWRT: .ASCIZ /FOL WRT (NO SK)/
2415	005650	101	104	112 MREVSX: .ASCIZ /ADJ CYL WRTTN AFT REV SK/
2416	005701	101	104	112 MFWSK: .ASCIZ /ADJ CYL WRTTN AFT FWD SK/
2417	005732	123	113	040 MFWSKO: .ASCIZ /SK FWD,WRT - SK REV.OVERWRT/
2418	005766	123	113	040 MRESKO: .ASCIZ /SK REV,WRT - SK FWD.OVERWRT/
2419	006022	117	116	040 MBADAD: .ASCIZ /ON BAD SEC FILES/
2420	006043	103	101	116 MBADSF: .ASCIZ /CAN'T GET BAD SEC FILES/
2421	006073	102	101	104 MFMTERR: .ASCIZ /BAD SEC FILE FMT ERR/
2422	006120	124	117	040 MTHBS: .ASCIZ /TO MANY BAD SEC /
2423	006141	102	125	123 BASADD: .ASCIZ /BUS ADD=/
2424	006152	104	122	126 DRVNAM: .ASCIZ /DRV=/
2425	006157	116	117	040 DRVNAV: .ASCIZ /NO DRV FOR TST/
2426	006176	104	122	126 NOPWR: .ASCIZ /DRV DID NOT REC'R FROM PWR FAIL/
2427	006236	122	114	103 CSNAM: .ASCIZ /RLCS/
2428	006243	122	114	102 BANAM: .ASCIZ /RLBA/
2429	006250	122	114	104 DANAM: .ASCIZ /RLDA/
2430	006255	122	114	115 MPNAM: .ASCIZ /RLMP/
2431	006262	117	120	040 LAB1: .ASCIZ /OP INIT = /
2432	006275	117	120	040 LAB2: .ASCIZ /OP DONE = /
2433	006310	127	117	122 MWORD: .ASCIZ /WORD /
2434	006316	111	116	124 MTOSLOW: .ASCIZ /INTRPT TOO LATE/
2435	006336	116	117	040 MDRRES: .ASCIZ /NO DRV RSPNSE/
2436	006354	116	117	040 MNOINT: .ASCIZ /NO INTRPT ON CMND COMPLETE/
2437	006407	103	116	124 MCONHNG: .ASCIZ /CNTLR HUNG /
2438	006423	105	122	122 MNOCLR: .ASCIZ /ERR DID NOT CLR/
2439	006443	126	117	114 VCNRST: .ASCIZ /VOL CHK NOT RSET/
2440	006464	125	116	130 UNXERR: .ASCIZ /UNXPCTED ERR/
2441	006501	040	124	105 TSTLAB: .ASCIZ /TEST/
2459	006507	117	125	124 P2T03E: .ASCIZ /OUT GRD BAND /
2460	006525	111	116	103 P2T04E: .ASCIZ /INC SK FWD HD 0/
2461	006545	111	116	103 P2T05E: .ASCIZ /INC SK REV HD 0/
2462	006565	111	116	103 P2T06E: .ASCIZ /INC SK FWD HD 1/
2463	006605	111	116	116 P2T07E: .ASCIZ /INN GRD BAND /
2464	006623	111	116	103 P2T08E: .ASCIZ /INC SK REV HD 1/
2465	006643	123	113	000 P2T09E: .ASCIZ /SK/
2466	006646	106	127	104 P2T10E: .ASCIZ /FWD OSC SK/
2467	006661	122	105	126 P2T11E: .ASCIZ /REV OSC SK/
2468	006674	123	113	040 P2T12E: .ASCIZ /SK TIMING/

GLOBAL MESSAGES

2469	006706	102	123	103	P2T13E: .ASCIZ /BSC RD DATA/
2470	006722	127	122	124	P2T14E: .ASCIZ &WRT/RD DATA (P1)&
2471	006743	123	120	111	P2T15E: .ASCIZ /SPINDLE ROT TIMING/
2472	006766	127	122	124	P2T16E: .ASCIZ &WRT/RD DATA (P2)&
2473	007007	127	122	124	P2T17E: .ASCIZ /WRT LCK ERR AND DATA PROT/
2474	007041	101	104	112	P2T18E: .ASCIZ /ADJ CYL INTERFNCE/
2475	007063	117	126	105	P2T19E: .ASCIZ /OVERWRT/
2476	007073	123	113	040	SKTMES: .ASCIZ /SK TIMES /
2477	007105	123	120	111	SRTMES: .ASCIZ /SPINDLE ROT TIME /
2478	007127	050	111	116	VALDES: .ASCIZ /(IN 100'S OF U SEC)/
2479	007153	101	120	120	MAPROX: .ASCIZ /APPROX /
2480	007163	111	116	116	LABIN: .ASCIZ /INNER/
2481	007171	115	111	104	LABMID: .ASCIZ /MIDDLE/
2482	007200	117	125	124	LABOUT: .ASCIZ /OUTER/
2483	007206	115	101	130	LABEXP: .ASCIZ /MAX TIME/
2484	007217	061	040	103	LABOCF: .ASCIZ /1 CYL FWD/
2485	007231	061	040	103	LABOCR: .ASCIZ /1 CYL REV/
2486	007243	115	111	104	LABHCF: .ASCIZ /MID CYL FWD/
2487	007257	115	111	104	LABHCR: .ASCIZ /MID CYL REV/
2488	007273	115	101	130	LABACF: .ASCIZ /MAX CYL FWD/
2489	007307	115	101	130	LABACR: .ASCIZ /MAX CYL REV/
2491	007323	110	104	123	HDMOVF: .ASCIZ /HDS FAILED TO MV IN 10 TRYS/
2509	007357	122	105	123	OPR12: .ASCIZ /RESET WRT LCK /
2510	007376	117	116	040	OPR1A: .ASCIZ /ON /
2511	007402	117	116	040	OPR1B: .ASCIZ /ON DRV /
2512	007412	125	116	104	UNDTST: .ASCIZ /UNDER TEST/
2513	007425	123	105	124	OPR004: .ASCIZ /SET WRT LCK /
2514	007442	104	111	106	DIFWD: .ASCIZ /DIFF /
2515	007450	123	107	116	SGNWD: .ASCIZ /SGN /
2516	007455	110	104	040	HDWD: .ASCIZ /HD /
2517	007461	123	105	103	SECWD: .ASCIZ /SEC /
2518	007466	103	131	114	CYLWD: .ASCIZ /CYL /
2519	007473	106	122	117	FRMWD: .ASCIZ /FROM /
2520	007501	040	102	131	BYPSNM: .ASCIZ / BYPASSED /
2521	007514	122	117	125	SEQMES: .ASCIZ /ROUTINE TRACE SEQ:/
2522	007537	104	122	126	STAMES: .ASCIZ /DRV STAT/
2523	007550	102	101	104	BSNSTR: .ASCIZ /BAD SEC FILES NOT STRD. ALL SEC ASSUMED OK./
2524	007624	124	117	124	TCERR: .ASCIZ /TOTAL CMP ERRS: /
2525	007645	104	122	111	NOCTLR: .ASCIZ /DRIVE DROPPED NO CONTROLLER/
2526	007703	104	122	111	NOTRDY: .ASCIZ /DRIVE DROPPED - DID NOT RESPOND WITH "READY"/
2527					
2528					RESULT NAMES
2529	007760	104	122	126	MDRDY: .ASCIZ /DRV RDY /
2530	007771	103	117	116	MCERR: .ASCIZ /CONT ERR /
2531	010003	110	104	122	MHCRC: .ASCIZ /HDR CRC/
2532	010013	104	101	124	MDCRC: .ASCIZ /DATA CRC/
2533	010024	110	104	122	MHNF: .ASCIZ /HDR NOT FND/
2534	010040	104	101	124	MDLT: .ASCIZ /DATA LATE/
2535	010052	110	104	122	MHFCRC: .ASCIZ &HDR NOT FND/HDR CRC/OPI&
2536	010102	104	122	126	MDRERR: .ASCIZ /DRV ERR /
2545	010113	104	122	126	MDSERR: .ASCIZ /DRV SEL ERR /
2546	010130	104	122	126	MDRVST: .ASCIZ /DRV STATE /
2547	010143	123	120	111	MSPERR: .ASCIZ /SPIN TIMEOUT /
2548	010161	127	122	124	MWGERR: .ASCIZ /WRT GAT ERR /
2549	010176	123	113	040	MSTERR: .ASCIZ /SK TIMEOUT /
2550	010212	110	105	101	MHCERR: .ASCIZ /HEAD CUR ERR /
2551	010230	127	122	124	MWDERR: .ASCIZ /WRT DAT ERR /

GLOBAL MESSAGES

2552	010245	117	120	122	MOPERR:	.ASCIZ	/OPR INC/
2553	010255	110	104	122	MHDERR:	.ASCIZ	EMDR/DAT ERR &
2554	010272	110	104	122	MFLERR:	.ASCIZ	EMDR NOT FND/DAT LATE &
2555	010320	116	117	116	MNEERR:	.ASCIZ	/NON-EXISTENT MEMORY /
2556	010345	103	131	114	MCYLOC:	.ASCIZ	/CYL /
2557	010352	103	101	116	MNDRST:	.ASCIZ	/CAN'T GET DRV STAT/
2558	010375	125	116	113	MUNDEF:	.ASCIZ	/UNKN DRV STATE NO RDY,NO ERR,HDS OUT/
2559	010442	106	101	111	MRLFAL:	.ASCIZ	/FAIL TO RELD HDS AFTER ERR CLR/
2560	010501	127	122	124	MWRTAB:	.ASCIZ	/WRT ABRTD/
2561	010513	040	117	126	MEXERS:	.ASCIZ	/ OVR ERR LIMIT UNIT DRPPD /
2562	010550	040	105	122	MERRS:	.ASCIZ	/ ERR/
2563	010555	207	377	377	BELL:	.ASCIZ	<207><377><377>
2564							
2565					:	RESULT SETTINGS	
2566	010561	111	123	040	RESE3:	.ASCIZ	/IS /
2567	010565	040	123	102	RESE4:	.ASCIZ	/ SB /
2568							
2569					:	RESULT CONDITIONS	
2570	010572	040	111	116	RESE5:	.ASCIZ	/ IN /
2571	010577	040	117	106	RESE6:	.ASCIZ	/ OF /
2572	010604	123	124	101	STATE2:	.ASCIZ	/STATE 2/
2573	010614	123	124	101	STATE3:	.ASCIZ	/STATE 3/
2574	010624	123	124	101	STATE5:	.ASCIZ	/STATE 5/
2578	010634	061	123	124	C10MS:	.ASCIZ	/1ST 3 MS/
2579	010645	065	060	060	C500MS:	.ASCIZ	/500MS/
2580	010653	103	131	103	CCYLUP:	.ASCIZ	/CYC UP/
2581	010662	104	101	124	CAFDT:	.ASCIZ	/DATA XFR/
2582	010673	065	040	123	C5SEC:	.ASCIZ	/5 SEC/
2583							
2584	010701	045	116	045	FMTOP1:	.ASCIZ	/#N#T#N#T#T#06#S#T#01#N/
2585	010730	045	116	045	FMTOP2:	.ASCIZ	/#N#T#01#S1#T#01#N/
2586	010752	045	116	045	FMTOP3:	.ASCIZ	/#N#T#01#S1#T#T#N/
2587	010773	045	124	045	FMT1:	.ASCIZ	/#T#T/
2588	011000	045	116	045	FMT1.1:	.ASCIZ	/#N#T#T/
2589	011007	045	124	000	FMT2:	.ASCIZ	/#T/
2590	011012	045	116	000	FMT3:	.ASCIZ	/#N/
2591	011015	045	116	045	FMT4:	.ASCIZ	/#N#T#T#N/
2592	011026	045	116	045	FMT5:	.ASCIZ	/#N#T#06#S1#T#01/
2593	011046	045	116	045	FMT6:	.ASCIZ	/#N#S11#T#S4#T#S4#T#S4#T#S4#T#S2#T/
2594	011110	045	116	045	FMT7:	.ASCIZ	/#N#T#06#S2#06#S2#06#S2#06#S3#03#S2#01#N/
2595	011160	045	116	045	FMT8:	.ASCIZ	/#N#T#06#S2#06#S2#06#S2#06/
2596	011212	045	116	045	FMT9:	.ASCIZ	/#N#T/
2597	011217	045	124	045	FMT11:	.ASCIZ	/#T#01/
2598	011225	045	124	045	FMT12:	.ASCIZ	/#T#03/
2599	011233	045	116	045	FMT13:	.ASCIZ	/#N#S11#T#03#S1#T#03#S1#T#01#S1#T#01/
2600	011277	045	116	045	FMT14:	.ASCIZ	/#N#T#T#03#S1#T#06#S1#T#06/
2601	011331	045	116	045	FMT15:	.ASCIZ	/#N#S11#T#03#S1#T#06#S1#T#06/
2602	011365	045	116	045	FMT16:	.ASCIZ	/#N#S5#06/
2603	011376	045	123	061	FMT17:	.ASCIZ	/#S10#T#N#S11#06#N/
2604	011420	045	116	045	FMT18:	.ASCIZ	/#N#S15#T#S5#T#S4#T#S5#T#N/
2605	011452	045	124	045	FMT19:	.ASCIZ	/#T#S4#06#S4#06#S4#06#S4#06#N/
2606	011507	045	124	045	FMT20:	.ASCIZ	/#T#S2#06#S14#06#S4#06#N/
2607	011537	045	124	045	FMT21:	.ASCIZ	/#T#S12#06#S14#06#N/
2608	011562	045	116	045	FMT22:	.ASCIZ	/#N#S11#T#03#S1#T#01#S1#T#02/
2609	011616	045	124	045	FMT23:	.ASCIZ	/#T#T#T#01#N/
2610	011632	045	116	045	FMT24:	.ASCIZ	/#N#T/
2611	011637	045	116	045	FMT25:	.ASCIZ	/#N#D2#T/

GLOBAL MESSAGES

```

2612 011647 045 116 045 FMT26: .ASCIZ /#N#S1#T#D4#T#T#D3#N/
2613 011673 045 116 045 FMT27: .ASCIZ /#N#T#D3#T#D3#N/
2614 011712 045 116 045 FMT28: .ASCIZ /#N#T#T#T/
2615
2616 011723 ENDMOD
2617
2622
2623 .SBTTL ERROR MESSAGES
2624 011724 BGNMOD GLBERR
2625 : ERR1 R3 POINTS TO RESULT MESSAGE
2626 : RESULT: (R3)
2627
2628 : ERR2 R3 POINTS TO RESULT NAME
2629 : RESULT: (R3) IS 1 SB 0
2630
2631 : ERR3 R3 POINTS TO RESULT NAME
2632 : RESULT: (R3) IS 0 SB 1
2633
2634 : ERR4 R3 POINTS TO RESULT NAME
2635 : R4 POINTS TO RESULT CONDITIONS
2636 : RESULT: (R3) IS 1 SB 0 (R4)
2637
2638 : ERR5 R3 POINTS TO RESULT NAME
2639 : R4 POINTS TO RESULT CONDITIONS
2640 : RESULT: (R3) IS 0 SB 1 (R4)
2641
2642 : ERR6 RESULT ROUTINE DETERMINES WHICH ERROR(S) ARE SET AND
2643 : REPORTS ALL
2644 : RESULT: "ERROR" IS 1 SB 0
2645
2646 : ERR7 DRIVE STATE ERROR REPORT
2647 : R3 CONTAINS EXPECTED STATE
2648 : T.STAT CONTAINS BAD STATE
2649 : RESULT: DRIVE STATE IS (T.STAT) SB (R3)
2650
2651 : ERR8 HEAD POSITIONING ERROR REPORT
2652 : NEWCYL CONTAINS EXPECTED CYLINDER
2653 : HDWRD1 CONTAINS BAD CYLINDER
2654 : RESULT: CYLINDER IS (HDWRD1) SB (NEWCYL)
2655
2656 : ERR9 UTILITY RESULT REPORT
2657 : R3 POINTS TO RESULT NAME
2658 : R4 POINTS TO VALUE 1
2659 : R5 POINTS TO VALUE 2
2660 : RESULT: (R3-NAME) IS (R4 VALUE 1) SB (R5 VALUE 2)
2661
2662 : ERR10 COMPARE ERROR REPORT
2663 : R3 CONTAINS THE BAD WORD NUMBER
2664 : R4 POINTS TO BAD WORD
2665 : R5 POINTS TO GOOD WORD
2666 : RESULT: WORD (R3) IS (R4) SB (R5)
2667
2668 011724 BGNMSG ERR1
2669 011724 105737 003461 TSTB NOERCT ;TEST IF ERROR COUNTING INHIBITED
2670 011730 001002 BNE 1# ;YES - SKIP
2671 011732 005277 171314 INC @ERRPOINT ;ELSE BUMP ERROR COUNT
2672 011736 010146 1#: MOV R1, (SP) ;STORE R1

```

ERROR MESSAGES

2673	011740	004737	024542	JSR	PC,RPTOP	;REPORT OPERATION
2674	011744	012721	000001	MOV	#1,(R1)+	;SET PARAM NUMBER
2675	011750	010321		MOV	R3,(R1)+	;INSERT MESSAGE ADDRESS POINTER
2676	011752	004737	025330	JSR	PC,RPTRES	;REPORT RESULTS
2677	011756	004737	025536	JSR	PC,RPTREM	;REPORT REMAINDER
2678	011762	012601		MOV	(SP)+,R1	;RESTORE R1
2679	011764	004737	015712	JSR	PC,CKERLM	;GO CHECK IF ERROR COUNT EXCEEDED
2680	011770			ENDMSG		
	011770			L10000:		
	011770	104423		TRAP	C#MSG	
2681				BGNMSG	ERR2	
2682	011772			INC	@ERRPOINT	;BUMP ERROR COUNT
2683	011772	005277	171254	MOV	R1,(SP)	;STORE R1
2684	011776	010146		JSR	PC,RPTOP	;REPORT OPERATION
2685	012000	004737	024542	MOV	#3,(R1)+	;SET PARAM NUMBER
2686	012004	012721	000003	MOV	R3,(R1)+	;INSERT NAME ADD POINTER
2687	012010	010321		MOV	#1,(R1)+	;SET IS VALUE
2688	012012	012721	000001	CLR	(R1)+	;SET SB VALUE
2689	012016	005021		JSR	PC,RPTRES	;REPORT RESULTS
2690	012020	004737	025330	JSR	PC,RPTREM	;REPORT REMAINDER
2691	012024	004737	025536	MOV	(SP)+,R1	;RESTORE R1
2692	012030	012601		JSR	PC,CKERLM	;GO CHECK IF ERROR COUNT EXCEEDED
2693	012032	004737	015712	ENDMSG		
2694	012036			L10001:		
	012036	104423		TRAP	C#MSG	
2695				BGNMSG	ERR3	
2696	012040			INC	@ERRPOINT	;BUMP ERROR COUNT
2697	012040	005277	171206	MOV	R1,-(SP)	;STORE R1
2698	012044	010146		JSR	PC,RPTOP	;REPORT OPERATION
2699	012046	004737	024542	MOV	#3,(R1)+	;SET PARAM NUMBER
2700	012052	012721	000003	MOV	R3,(R1)+	;INSERT NAME ADD POINTER
2701	012056	010321		CLR	(R1)+	;SET IS VALUE
2702	012060	005021		MOV	#1,(R1)+	;SET SB VALUE
2703	012062	012721	000001	JSR	PC,RPTRES	;REPORT RESULTS
2704	012066	004737	025330	JSR	PC,RPTREM	;REPORT REMAINDER
2705	012072	004737	025536	MOV	(SP)+,R1	;RESTORE R1
2706	012076	012601		JSR	PC,CKERLM	;GO CHECK IF ERROR COUNT EXCEEDED
2707	012100	004737	015712	ENDMSG		
2708	012104			L10002:		
	012104	104423		TRAP	C#MSG	
2709				BGNMSG	ERR4	
2710	012106			INC	@ERRPOINT	;BUMP ERROR COUNT
2711	012106	005277	171140	MOV	R1,-(SP)	;STORE R1
2712	012112	010146		JSR	PC,RPTOP	;REPORT OPERATION
2713	012114	004737	024542	MOV	#4,(R1)+	;SET PARAM NUMBER
2714	012120	012721	000004	MOV	R3,(R1)+	;INSERT NAME ADD POINTER
2715	012124	010321		MOV	#1,(R1)+	;SET IS VALUE
2716	012126	012721	000001	CLR	(R1)+	;SET SB VALUE
2717	012132	005021		MOV	R4,(R1)	;INSERT ADD OF CONDITION POINTER
2718	012134	010411		JSR	PC,RPTRES	;REPORT RESULTS
2719	012136	004737	025330	JSR	PC,RPTREM	;REPORT REMAINDER
2720	012142	004737	025536	MOV	(SP)+,R1	;RESTORE R1
2721	012146	012601		JSR	PC,CKERLM	;GO CHECK IF ERROR COUNT EXCEEDED
2722	012150	004737	015712	ENDMSG		
2723	012154					

ERROR MESSAGE

012154				L10003:	TRAP	CMSG	
012154	104423						
2724							
2725	012156			BGNMSG	ERR5		
2726	012156	005277	171070		INC	@ERRPOINT	;BUMP ERROR COUNT
2727	012162	010146			MOV	R1,(SP)	;STORE R1
2728	012164	004737	024542		JSR	PC,RPTOP	;REPORT OPERATION
2729	012170	012721	000004		MOV	@4,(R1)	;SET PARAM NUMBER
2730	012174	010321			MOV	R3,(R1)	;INSERT NAME ADD POINTER
2731	012176	005021			CLR	(R1)	;SET IS VALUE
2732	012200	012721	000001		MOV	@1,(R1)	;SET SB VALUE
2733	012204	010411			MOV	R4,(R1)	;INSERT ADD OF CONDITION POINTER
2734	012206	004737	025330		JSR	PC,RPTRES	;REPORT RESULTS
2735	012212	004737	025536		JSR	PC,RPTREM	;REPORT REMAINDER
2736	012216	012601			MOV	(SP),R1	;RESTORE R1
2737	012220	004737	015712		JSR	PC,CKERLM	;GO CHECK IF ERROR COUNT EXCEEDED
2738	012224			ENDMSG			
	012224			L10004:	TRAP	CMSG	
	012224	104423					
2739							
2740	012226			BGNMSG	ERR6		
2741	012226	105737	003461		TSTB	NOERCT	;TEST IF ERROR COUNTING INHIBITED
2742	012232	001002			BNE	17:	;YES SKIP
2743	012234	005277	171012		INC	@ERRPOINT	;ELSE BUMP ERROR COUNT
2744	012240	010146		17:	MOV	R1,(SP)	;STORE R1
2745	012242	010346			MOV	R3,(SP)	;STORE R3
2746	012244	010446			MOV	R4,(SP)	;STORE R4
2747	012246	010546			MOV	R5,(SP)	;STORE R5
2748	012250	004737	024542		JSR	PC,RPTOP	;REPORT OPERATION
2749	012254	012721	000003		MOV	@3,(R1)	;SET PARAM NUMBER
2750	012260	012761	000001	000002	MOV	@1,2(R1)	;INSERT IS VALUE
2751	012266	005037	003140		CLR	TEMP3	;CLEAR FOR STATUS STORAGE
2752	012272	013703	003060		MOV	T,CS,R3	;GET T.CS
2753	012276	042703	177761		BIC	@177761,R3	;AND CLEAR ALL BUT FUNCTION
2754	012302	022703	000004		CMP	@4,R3	;CHECK IF IT WAS GET STATUS
2755	012306	001434			BEQ	1:	;YES - STATUS IS IN T.MP. SKIP
2756	012310	012762	000003	000004	MOV	@GETSTAT,RLDA(R2)	;ELSE DO GET STATUS
2757	012316	012703	000004		MOV	@4,R3	
2758	012322	053703	003046		BIS	RLDRV,R3	
2759	012326	010362	000000		MOV	R3,RLCS(R2)	
2760	012332				WAITUS	@10.	;WAIT FOR CONTROLLER READY
2761	012344	032762	000200	000000	BIT	@CRDYMSK,RLCS(R2)	;TEST IF READY
2762	012352	001003			BNE	10:	;YES - SKIP
2763	012354	012703	001000	9:	MOV	@BIT9,R3	;ELSE SET NO DRIVE STATUS BIT
2764	012360	000413			BR	2:	;IN MESSAGE WORD AND SKIP
2765	012362	016203	000006	10:	MOV	RLMP(R2),R3	;STORE STATUS FOR REPORT
2766	012366	010337	003140		MOV	R3,TEMP3	
2767	012372	113703	003141		MOVB	TEMP3+1,R3	;GET ERROR BITS IN PROPER POSITION
2768	012376	000402			BR	13:	
2769	012400	113703	003067	1:	MOVB	T.MP+1,R3	;GET ERROR BITS FROM MP REG
2770	012404	042703	177442	13:	BIC	@177442,R3	;CLEAR UNUSED BITS
2771	012410	013704	003060	2:	MOV	T,CS,R4	;GET ERROR BITS FROM CS REG
2772	012414	042704	001777		BIC	@1777,R4	;CLEAR UNUSED BITS
2773	012420	050403			BIS	R4,R3	;MAKE ONE WORD OF POSSIBLE ERRORS
2774	012422	032703	002000		BIT	@OPIERR,R3	;TEST IF OPI SET
2775	012426	001442			BEQ	115:	;NO - SKIP
2776	012430	032703	010000		BIT	@MNFERR,R3	;TEST IF HDR NOT FOUND ERROR

ERROR MESSAGES

2777	012434	001026		BNE	1078		;YES SKIP	
2778	012436	032703	004000	BIT	#HRCERR,R3		;TEST IF HDR CRC ERR	
2779	012442	001020		BNE	1058		;YES SKIP	
2780	012444	012704	010245	MOV	#MOPERR,R4		;SET OPI ALONE MESSAGE	
2781	012450			1008:	PRINTB	#FMT28,#MRSLT,R4,#MERRS	;REPORT ERROR	
	012450	012746	010550	MOV	#MERRS,-(SP)			
	012454	010446		MOV	R4,-(SP)			
	012456	012746	005536	MOV	#MRSLT,-(SP)			
	012462	012746	011712	MOV	#FMT28,-(SP)			
	012466	012746	000004	MOV	#4,-(SP)			
	012472	010600		MOV	SP,R0			
	012474	104414		TRAP	C#PNTB			
	012476	062706	000012	ADD	#12,SP			
2782	012502	000430		BR	1208		;SKIP	
2783	012504	012704	010003	1058:	MOV	#HRCRC,R4	;HDR CRC MESSAGE	
2784	012510	000757		BR	1008			
2785	012512	032703	004000	1078:	BIT	#HRCRCERR,R3	;TEST IF HRCRC WITH HDR NOT FND	
2786	012516	001003		BNE	1098		;YES SKIP	
2787	012520	012704	010024	MOV	#MNF,R4		;MESSAGE HEADER NOT FOUND	
2788	012524	000751		BR	1008			
2789	012526	012704	010052	1098:	MOV	#MNFRCRC,R4	;MNF AND HRCRC MESSAGE	
2790	012532	000746		BR	1008		;SKIP	
2791	012534	032703	004000	1158:	BIT	#DCKERR,R3	;TEST IF DATA CHECK SET, NOT OPI	
2792	012540	001403		BEQ	1188		;NO - SKIP	
2793	012542	012704	010013	MOV	#MDCRC,R4		;SET MESSAGE DATA CHECK	
2794	012546	000740		BR	1008		;SKIP	
2795	012550	032703	010000	1188:	BIT	#DLTERR,R3	;TEST IF DATA LATE ERROR	
2796	012554	001403		BEQ	1208		;NO - SKIP	
2797	012556	012704	010040	MOV	#MDLT,R4		;SET MESSAGE DATA LATE	
2798	012562	000732		BR	1008		;SKIP	
2799	012564	012705	100000	1208:	MOV	#BIT15,R5	;SET BIT POINTER FOR TEST	
2800	012570	005004		CLR	R4		;CLEAR R4 FOR TABLE COUNT	
2801	012572	030503		38:	BIT	R5,R3	;TEST IF BIT IS SET	
2802	012574	001005		BNE	68		;YES - SKIP TO REPORT	
2803	012576	005724		48:	TST	(R4).	;ELSE BUMP TABLE POINTER	
2804	012600	000241		CLC			;CLEAR CARRY	
2805	012602	006005		ROR	R5		;SHIFT BIT POINTER TO NEXT BIT	
2806	012604	001372		BNE	38		;LOOP IF NOT 0	
2807	012606	000405		BR	78		;ELSE REPORT REMAINDER	
2808	012610	016411	002334	68:	MOV	RESTBL(R4),(R1)	;INSERT NAME ADDRESS	
2809	012614	004737	025330	JSR	PC,RPTRES		;REPORT RESULTS	
2810	012620	000766		BR	48		;GET NEXT BIT	
2811	012622	004737	025536	78:	JSR	PC,RPTREM	;REPORT REMAINDER	
2812	012626	005737	003140	TST	TEMP3		;TEST IF ANY NEW STATUS	
2813	012632	001414		BEQ	158		;NO SKIP	
2814	012634			PRINTB	#FMT17,#STAMES,TEMP3			
	012634	013746	003140	MOV	TEMP3,-(SP)			
	012640	012746	007537	MOV	#STAMES,-(SP)			
	012644	012746	011376	MOV	#FMT17,-(SP)			
	012650	012746	000003	MOV	#3,-(SP)			
	012654	010600		MOV	SP,R0			
	012656	104414		TRAP	C#PNTB			
	012660	062706	000010	ADD	#10,SP			
2815	012664	032737	004000	003060	158:	BIT	#DCKERR,T.CS	;TEST IF DATA CHECK ERROR
2816	012672	001453		BEQ	258		;NO - SKIP	
2817	012674	032737	002000	003060	BIT	#OPIERR,T.CS	;TEST IF OPI SET	
2818	012702	001047		BNE	258		;YES SKIP	

ERROR MESSAGES

```

2819 012704 005037 003030      CLR      MORECE      ;CLEAR COMPARE ERROR COUNT
2820 012710 012701 000200      MOV      @128.,R1    ;SET COMPARE LENGTH
2821 012714 012703 000001      MOV      @1,R3       ;SET WORD COUNT
2822 012720 012705 004502      MOV      @0BUFF,R5   ;SET GOOD WORD POINTER
2823 012724 012704 004102      MOV      @1BUFF,R4   ;SET TEST WORD POINTER
2824 012730 021514              18$:    CMP      (R5),(R4)   ;CHECK WORD
2825 012732 001427              BEQ      19$         ;GOOD SKIP
2826 012734 023727 003030 000012  CMP      MORECE,@10. ;TEST IF COMPARE LIMIT REACHED
2827 012742 003021              BGT      20$         ;YES - SKIP
2828 012744              PRINTB  @FMT15,@MWORD,R3,@RESE3,(R4),@RESE4,(R5)
      012744 011546              MOV      (R5),(SP)
      012746 012746 010565              MOV      @RESE4,(SP)
      012752 011446              MOV      (R4),-(SP)
      012754 012746 010561              MOV      @RESE3, -(SP)
      012760 010346              MOV      R3, -(SP)
      012762 012746 006310              MOV      @MWORD, -(SP)
      012766 012746 011331              MOV      @FMT15, -(SP)
      012772 012746 000007              MOV      @7, -(SP)
      012776 010600              MOV      SP,R0
      013000 104414              TRAP    C#PNTB
      013002 062706 000020              ADD     @20,SP
2829 013006 005237 003030              20$:    INC     MORECE      ;BUMP ERROR COUNTER
2830 013012 022524              19$:    CMP     (R5), (R4)  ;BUMP POINTERS
2831 013014 005203              INC     R3           ;BUMP COUNTER
2832 013016 005301              DEC     R1           ;DEC LENGTH COUNT
2833 013020 001343              BNE    18$          ;LOOP IF NOT DONE
2834 013022 005737 003030              25$:    TST     MORECE      ;TEST IF ANY COMPARE ERRORS
2835 013026 001421              BEQ     27$         ;NO SKIP
2836 013030 012701 000200              MOV     @128.,R1    ;SET COMPARE LENGTH
2837 013034              PRINTB  @FMT27,@TCERR,MORECE,@RESE6,R1
      013034 010146              MOV     R1, -(SP)
      013036 012746 010577              MOV     @RESE6, -(SP)
      013042 013746 003030              MOV     MORECE, -(SP)
      013044 012746 007624              MOV     @TCERR, -(SP)
      013052 012746 011673              MOV     @FMT27, -(SP)
      013056 012746 000005              MOV     @5, -(SP)
      013062 010600              MOV     SP,R0
      013064 104414              TRAP    C#PNTB
      013066 062706 000014              ADD     @14,SP
2838 013072 012605              27$:    MOV     (SP),R5      ;RESTORE R5, 4, 3, 1
2839 013074 012604              MOV     (SP),R4
2840 013076 012603              MOV     (SP),R3
2841 013100 012601              MOV     (SP),R1
2842 013102 004737 015712              JSR     PC,CKERLM   ;GO CHECK IF ERROR COUNT EXCEEDED
2843 013106              ENDMSG
      013106              L10005:
      013106 104423              TRAP    C#MSG
2844
2845 013110              BGNMSG  ERR7
2846 013110 005277 170136              INC     @ERRPOINT   ;BUMP ERROR COUNT
2847 013114 010146              MOV     R1, -(SP)   ;STORE R1
2848 013116 004737 024542              JSR     PC,RPTOP    ;REPORT OPERATION
2849 013122 012721 000003              MOV     @3,(R1)    ;SET PARAM NUMBER
2850 013126 012721 010130              MOV     @MDRVST,(R1);INSERT NAME ADD POINTER
2851 013132 013721 003074              MOV     T,STAT,(R1);INSERT IS VALUE
2852 013136 010311              MOV     R3,(R1) ;INSERT SB VALUE
2853 013140 004737 025330              JSR     PC,RPTRES   ;REPORT RESULTS

```

ERROR MESSAGES

2854	013144	004737	025536	JSR	PC,RPTREM	;REPORT REMAINDER
2855	013150	012601		MOV	(SP),R1	;RESTORE R1
2856	013152	004737	015712	JSR	PC,CKERLM	;GO CHECK IF ERROR COUNT EXCEEDED
2857	013156			ENDMSG		
	013156			L10006:		
	013156	104423		TRAP	C#MSG	
2858				BGNMSG	ERR8	
2859	013160			INC	BERRPOINT	;BUMP ERROR COUNT
2860	013160	005277	170066	MOV	R1,-(SP)	;STORE R1
2861	013164	010146		MOV	R3,(SP)	;STORE R3
2862	013166	010346		JSR	PC,RPTOP	;REPORT OPERATION
2863	013170	004737	024542	MOV	#3,(R1)	;SET PARAM NUMBER
2864	013174	012721	000003	MOV	#MCYLOC,(R1)	;INSERT NAME ADD POINTER
2865	013200	012721	010345	MOV	HWORD1,(R1)	;GET HEADER WORD
2866	013204	013711	003066	MOV	#7,R3	;SET SHIFT COUNT
2867	013210	012703	000007	3#:	CLC	
2868	013214	000241		ROR	(R1)	;ALIGN CHAR FOR PRINTING
2869	013216	006011		DEC	R3	; AS IS VALUE
2870	013220	005303		BNE	3#	
2871	013222	001374		TST	(R1)	;BUMP PARAM POINTER
2872	013224	005721		MOV	NEWCYL,(R1)	;INSERT SB VALUE
2873	013226	013711	003116	JSR	PC,RPTRES	;REPORT RESULTS
2874	013232	004737	025330	JSR	PC,RPTREM	;REPORT REMAINDER
2875	013236	004737	025536	MOV	(SP),R3	;RESTORE R3
2876	013242	012603		MOV	(SP),R1	;RESTORE R1
2877	013244	012601		JSR	PC,CKERLM	;GO CHECK IF ERROR COUNT EXCEEDED
2878	013246	004737	015712	ENDMSG		
2879	013252			L10007:		
	013252			TRAP	C#MSG	
	013252	104423		BGNMSG	ERR9	
2880				INC	BERRPOINT	;BUMP ERROR COUNT
2881	013254			MOV	R1,-(SP)	;STORE R1
2882	013254	005277	167772	JSR	PC,RPTOP	;REPORT OPERATION
2883	013260	010146		MOV	#3,(R1)	;SET PARAM NUMBER
2884	013262	004737	024542	MOV	R3,(R1)	;INSERT NAME ADD POINTER
2885	013266	012721	000003	MOV	R4,(R1)	;SET IS VALUE
2886	013272	010321		MOV	R5,(R1)	;SET SB VALUE
2887	013274	010421		JSR	PC,RPTRES	;REPORT RESULTS
2888	013276	010521		JSR	PC,RPTREM	;REPORT REMAINDER
2889	013300	004737	025330	MOV	(SP),R1	;RESTORE R1
2890	013304	004737	025536	JSR	PC,CKERLM	;GO CHECK IF ERROR COUNT EXCEEDED
2891	013310	012601		ENDMSG		
2892	013312	004737	015712	L10010:		
2893	013316			TRAP	C#MSG	
	013316			BGNMSG	ERR10	
	013316	104423		MOV	R1,-(SP)	;STORE R1
2894	013320			TST	MORECE	;TEST IF 2ND BAD LINE
2895	013320	010146		BNE	3#	;YES - SKIP
2896	013322	005737	003030	INC	BERRPOINT	;BUMP ERROR COUNT
2897	013326	001051		JSR	PC,RPTOP	;REPORT OPERATION
2898	013330	005277	167716	PRINTB	#FMT5,#BASADD,RLBAS,#DRVNAM,<B,RLDRV+1>	;REPORT ID
2899	013334	004737	024542	CLR	-(SP)	
2900	013340	005046		BISB	RLDRV+1,(SP)	
	013342	153716	003047	MOV	#DRVNAM,-(SP)	
	013346	012746	006152	MOV	RLBAS,-(SP)	
	013352	013746	003042			

ERROR MESSAGES

013356	012746	006141	MOV	#BASADD, -(SP)	
013362	012746	011026	MOV	#FMT5, (SP)	
013366	012746	000005	MOV	#5, (SP)	
013372	010600		MOV	SP, R0	
013374	104414		TRAP	C#PNTB	
2901 013376	062706	000014	ADD	#14, SP	
013402			PRINTB	#FMT14, #MRSLT, #MWORD, R3, #RESE3, (R4), #RESE4, (R5)	
013402	011546		MOV	(R5), (SP)	
013404	012746	010565	MOV	#RESE4, -(SP)	
013410	011446		MOV	(R4), (SP)	
013412	012746	010561	MOV	#RESE3, (SP)	
013416	010346		MOV	R3, (SP)	
013420	012746	006310	MOV	#MWORD, (SP)	
013424	012746	005536	MOV	#MRSLT, -(SP)	
013430	012746	011277	MOV	#FMT14, (SP)	
013434	012746	000010	MOV	#10, (SP)	
013440	010600		MOV	SP, R0	
013442	104414		TRAP	C#PNTB	
013444	062706	000022	ADD	#22, SP	
2902 013450	000421		BR	#	
2903 013452			3\$: PRINTB	#FMT15, #MWORD, R3, #RESE3, (R4), #RESE4, (R5) ;REPORT DATA	
013452	011546		MOV	(R5), -(SP)	
013454	012746	010565	MOV	#RESE4, -(SP)	
013460	011446		MOV	(R4), -(SP)	
013462	012746	010561	MOV	#RESE3, -(SP)	
013466	010346		MOV	R3, -(SP)	
013470	012746	006310	MOV	#MWORD, -(SP)	
013474	012746	011331	MOV	#FMT15, -(SP)	
013500	012746	000007	MOV	#7, (SP)	
013504	010600		MOV	SP, R0	
013506	104414		TRAP	C#PNTB	
013510	062706	000020	ADD	#20, SP	
2904 013514	005237	003030	4\$: INC	MORECE ;INC COMPARE ERROR COUNT	
2905 013520	012601		MOV	(SP)+, R1 ;RESTORE R1	
2906 013522	004737	015712	JSR	PC, CKERLM ;GO CHECK IF ERROR COUNT EXCEEDED	
2907 013526			ENDMSG		
013526			L10011:		
013526	104423		TRAP	C#MSG	
2908 013530			ENDMOD		
2909					
2910					
2911 013530					
2912 013530	000000				
2913 013532	177777				
2914 013534	000010				
2915 013536					
2916					
2917					
2918					
2919 013536			BGNMOD	HPTCODE	
2920 013536			BGNMW		
013536	000006		.WORD	L10013-L#HW/2	
2921 013540	174400		.WORD	174400 ;CSR BASE ADDRESS DEFAULT	
2922 013542	000160		.WORD	160 ;VECTOR DEFAULT	
2923 013544	000240		.WORD	240 ;PRIORITY DEFAULT	
2924 013546	000001		.WORD	1 ;TYPE OF DRIVE	
2925 013550	000000		.WORD	0 ;DRIVE NUMBER DEFAULT	

ERROR MESSAGES

```

2926 013552 000001          .WORD 1          ;RL11 CONTROLLER
2927 013554          ENDMW
      013554          L10013:
2928 013554          ENDMOD
2929
2930 013554          BGNMOD SPTCODE
2931 013554          BGNSW
      013554 000006          .WORD L10014 1$SW/2
2932 013556 000000          MISWIW: .WORD 0          ;BIT 0 = USE ALL CYLINDERS
2933                                     ;BIT 1 = USE ALL SECTORS
2934                                     ;BIT 2 = EXECUTE DRIVE SELECT TEST
2935                                     ;BIT 3 = EXECUTE HEAD ALIGNMENT
2936                                     ;BIT 12 = HEAD SELECT SUPPLIED FLAG
2937                                     ;BIT 13 = HILIMIT SPECIFIED FLAG
2938                                     ;BIT 14 = LO LIMIT SPECIFIED FLAG
2939 013560 000000          LOLIMW: .WORD 0
2940 013562 000377          HILIMW: .WORD 255.
2941 013564 000000          HEADW: .WORD 0
2942 013566 000024          ERLIMW: .WORD 20.          ;ERROR LIMIT
2943 013570 000012          DCLIMW: .WORD 10.          ;COMPARE ERROR LIMIT
2944 013572          ENDSW
      013572          L10014:
2945 013572          ENDMOD
2946
2947 013572          BGNMOD DSPCODE
2952 013572          DISPATCH 9
      013572 000011          .WORD 9
      013574 026022          .WORD T1
      013576 026244          .WORD T2
      013600 026454          .WORD T3
      013602 026664          .WORD T4
      013604 027110          .WORD T5
      013606 027316          .WORD T6
      013610 027544          .WORD T7
      013612 030054          .WORD T8
      013614 030352          .WORD T9
2954 013616          ENDMOD
2955
2956          .SBTTL INITIALIZATION SECTION
2957
2958 013616          BGNMOD INITCODE
2959 013616          BGNINIT
2960 013616          SETVEC #140,#170000,#340          ;ODT STARTING ADDR          ;JSD REV A
      013616 012746 000340          MOV #340,-(SP)
      013622 012746 170000          MOV #170000,-(SP)
      013626 012746 000140          MOV #140,-(SP)
      013632 012746 000003          MOV #3,-(SP)
      013636 104437          TRAP C$SVEC
      013640 062706 000010          ADD #10,SP
2961          ;CHECK FOR PRESENCE OF A P-CLOCK
2962 013644 005037 003504          CLR CLKFLG          ;CLEAR CLOCK FLAG
2963 013650          CLOCK P,CLKADR          ;P-CLOCK?
      013650 012700 000120          MOV #'P,RO
      013654 104462          TRAP C$CLCK
      013656 010037 003506          MOV RO,CLKADR
2964 013662          BNCOMPLETE 1$          ;BRANCH IF NO P-CLOCK
      013662 103002          BCC 1$
    
```

INITIALIZATION SECTION

```

2965 013664 005237 003504      INC      CLKFLG      ;INDICATE PRESENCE OF A P CLOCK
2966      ;1$:      SETPRI    #340      ;SET PRI TO 7 TO INHIBIT ALL INT'S      ;JSD REV A
2967 013670      ;1$:      SETPRI    #300      ;SET PRI TO 6 TO INHIBIT MOST INT'S      ;JSD REV A
      013670 012700 000300      MOV      #300,RO
      013674 104441      TRAP    C$SPRI
2968 013676      BRESET          ;FOR LSI 11 CPU'S
      013676 104433      TRAP    C$RESET
2969 013700 042737 10001' 013556      BIC      #MITEST!DRSELT!MDALIGN,MISWIW ;CLEAR ALL MANUAL
      ;INTERVENTION FLAGS
2970      CLR      SSINDX      ;CLEAR SUBROUTINE STACK INDEX
2971 013706 005037 003016      READEF   #EF.PWR      ;POWER FAILURE
2972 013712      MOV      #EF.PWR,RO
      013712 012700 000034      TRAP    C$REFG
      013716 104447      BNCOMPLETE 4$      ;NO. GO CHECK NEW PASS
2973 013720      BCC      4$
      013720 103005      MOV      L$UNIT,PWRFLG ;SET POWER FAIL FLAG
2974 013722 013737 002012 003464      JMP      PWCON        ;GO SERVICE POWER FAIL
2975 013730 000137 014342      4$:      READEF   #EF.START ;CHECK IF START
2976 013734      MOV      #EF.START,RO
      013734 012700 000040      TRAP    C$REFG
2977 013742      BNCOMPLETE RESTART ;NO SKIP
      013742 103034      BCC      RESTART
2978
2979      ; ON START INITIALIZE TO START AT FIRST DRIVE, CLEAR INTERNAL
2980      ; PASS COUNT, AND ERROR COUNT.
2981
2982 013744 013737 002012 003110      MOV      L$UNIT,DRVCNT ;SET UP UNIT COUNT
2983 013752 005037 003454      RSTRT:  CLR      PASNUM  ;CLEAR PASS NUMBER
2984 013756 012700 003254      MOV      #ERRCNT,RO
2985 013762 012701 000100      MOV      #64.,R1      ;GET A COUNT
2986 013766 005020      1$:      CLR      (RO)+      ;CLEAR AN ERROR COUNTER STORAGE AREA
2987 013770 005301      DEC     R1
2988 013772 001375      BNE     1$          ;LOOP TILL ALL CLEARED
2989 013774 012737 003252 003252      MOV      #ERRCNT-2,ERRPOINT ;INIT ERROR POINTER
2990 014002 012737 177777 003456      MOV      #-1,PSETNM   ;SET PARAM SELECT TO INITIAL VALUE
2991 014010 012737 177777 003024      MOV      #-1,MADONE   ;PRESET HEAD ALIGN DONE FLAG
2992 014016 032737 040000 013556      LAB:    BIT      #LOCYL,MISWIW ;TEST IF LO LIMIT SET
2993 014024 001002      BNE     5$          ;YES - SKIP
2994 014026 005037 013560      CLR     LOLIMW     ;ELSE CLEAR LO LIMIT
2995 014032 000432      5$:      BR       SETDON
2996 014034      RSTRT:
2997 014034      READEF   #EF.RESTART ;CHECK IF RESTART
      014034 012700 000037      MOV      #EF.RESTART,RO
      014040 104447      TRAP    C$REFG
2998 014042      BCOMPLETE RSTRT ;NO - SKIP
      014042 103743      BCS     RSTRT
2999 014044      CONTINUE:
3000 014044      READEF   #EF.CONTINUE ;TEST IF CONTINUE
      014044 012700 000036      MOV      #EF.CONTINUE,RO
      014050 104447      TRAP    C$REFG
3001 014052      BCOMPLETE PWCON
      014052 103533      BCS     PWCON
3002      ; ON CONTINUE PICK UP UNIT LAST UNDER TEST
3003 014054      READEF   #EF.NEW     ;CHECK IF STARTING NEW PASS
      014054 012700 000035      MOV      #EF.NEW,RO
      014060 104447      TRAP    C$REFG
3004 014062      BCOMPLETE PASNEW

```

INITIALIZATION SECTION

```

014062 103403
3005 014064
3006 014064 005737 003110
3007 014070 001013
3008 014072 005237 003454
3009 014076 012737 003252 003252
3010 014104 013737 002012 003110
3011 014112 012737 177777 003456
3012 014120 005237 003456
3013 014124 005337 003110
3014 014130 062737 000002 003252
3015 014136 013700 003456
3016 014142 012702 003042
3017 014146
      014146 104442
      014150 010001
3018 014152
      014152 103406
3019 014154 005737 003464
3020 014160 001741
3021 014162 005337 003464
3022 014166 000736
3023 014170 012122
3024 014172 012122
3025 014174 005721
3026 014176 012137 002312
3027 014202 012122
3028 014204 022737 000001 002312
3029 014212 001426
3030 014214 012737 000776 002322
3031 014222 012737 000777 002316
3032 014230 012737 001000 002324
3033 014236 012737 177600 002326
3034 014244 012737 177600 002330
3035 014252 012737 177600 002332
3036 014260 012737 177000 002320
3037 014266 000425
3038
3039 014270 012737 000377 002316 65:
3040 014276 012737 000400 002324
3041 014304 012737 077600 002326
3042 014312 012737 077600 002330
3043 014320 012737 077600 002332
3044 014326 012737 000376 002322
3045 014334 012737 177400 002320
3046
3047 014342 032737 020000 013556 PWCON:
3048 014350 001003
3049 014352 013737 002316 013562
3050 014360
      014360 012746 000340
      014364 012746 015632
      014370 013746 003044
      014374 012746 000003
      014400 104437
      014402 062706 000010
3051 014406

```

```

BCS PASNEW
NXTPAS: TST DRVCNT ;TEST IF ALL UNITS CHECKED
          BNE SETDON ;NO - SKIP
          INC PASNUM ;ELSE BUMP PASS COUNT
          MOV #ERRCNT-2,ERRPOINT ;INIT ERROR POINTER
          MOV L#UNIT,DRVCNT ;GET ALL DRIVES
          MOV #-1,PSETNM ;SET PARAM SELECT TO INITIAL
SETDON: INC PSETNM ;NEXT SET OF PARAMETERS
          DEC DRVCNT ;DOWN COUNT DRIVE TOTAL
          ADD #2,ERRPOINT ;UPDATE THE ERROR POINTER
          MOV PSETNM,R0 ;SET UP TO GET PARAMETERS
          MOV #RLBAS,R2
          GPHARD R0,R1
          TRAP C#GPHRD
          MOV R0,R1
BCOMplete 7: ;SKIP IF GOOD PARAM
BCS 7:
TST PWRFLG ;RECENT POWER FAILURE
BEQ NXTPAS ;NO
DEC PWRFLG ;ACCOUNT FOR DRIVE
BR NXTPAS
7: MOV (R1)+,(R2)+ ;STORE PARAMETERS CSR
    MOV (R1)+,(R2)+ ; VECTOR
    TST (R1)+ ;BUMP PAST PRIORITY
    MOV (R1)+,T.DRIVE
    MOV (R1)+,(R2)+
    CMP #1,T.DRIVE
    BEQ 65:
    MOV #510.,NXTML
    MOV #511.,HLMTW
    MOV #512.,GBND
    MOV #177600,CAMSK
    MOV #177600,DIRMSK
    MOV #177600,HDCYL
    MOV #177000,CLRBYT
    BR PWCON
65: MOV #255.,HLMTW
    MOV #256.,GBND
    MOV #77600,CAMSK
    MOV #77600,DIRMSK
    MOV #77600,HDCYL
    MOV #254.,NXTML
    MOV #177400,CLRBYT
PWCON: BIT #HICYL,MISWIW
        BNE 1:
        MOV HLMTW,HLIMW
1: SETVEC RLVEC,#INTHLR,#340 ;SET UP VECTOR
    MOV #340,-(SP)
    MOV #INTHLR,-(SP)
    MOV RLVEC,-(SP)
    MOV #3,-(SP)
    TRAP C#SVEC
    ADD #10,SP
    SETPRI #0 ;SET PRIORITY

```

INITIALIZATION SECTION

```

014406 012700 000000      MOV      #0,R0
014412 104441      TRAP     C#SPRI
3052 014414 013702 003042      MOV      RLBAS,R2      ;SET RL11 BASE ADDRESS POINTER
3063      ;CHECK IF POWER FAILURE WAIT IS NEEDED
3064
3065 014420 005737 003464      TST      PWRFLG      ;NEEDED???
3066 014424 001472      BEQ      B#          ;NO, SKIP
3067
3068 014426 013705 003046      MOV      RLDRV,R5      ;DRIVE SELECT
3069 014432 052705 000200      BIS      #CRDYMSK,R5   ;SET CRDY
3070 014436 010562 000000      MOV      R5,RLCS(R2)   ;SELECT DRIVE
3071 014442 012701 000170      MOV      #120.,R1     ;INITIALIZE WAIT COUNT
3072 014446 032762 000001 000000 9#:      BIT      #DRDYMSK,RLCS(R2) ;DRIVE UP YET?
3073 014454 001056      BNE      B#          ;YES START TEST
3074
3075 014456      WAITMS  #10.         ;WAIT A SECOND
3076 014470 005301      DEC      R1           ;SIXTY GONE BY
3077 014472 001365      BNE      9#          ;NO
3078 014474      PRINTF  #FMT24,#NOPWR
014474 012746 006176      MOV      #NOPWR,-(SP)
014500 012746 011632      MOV      #FMT24,-(SP)
014504 012746 000002      MOV      #2,-(SP)
014510 010600      MOV      SP,R0
014512 104417      TRAP     C#PNTF
014514 062706 000006      ADD      #6,SP
3079 014520      PRINTF  #FMT5,#BASADD,RLBAS,#DRVNM,<B,RLDRV+1>
014520 005046      CLR      -(SP)
014522 153716 003047      BISB    RLDRV+1,(SP)
014526 012746 006152      MOV      #DRVNM,-(SP)
014532 013746 003042      MOV      RLBAS,-(SP)
014536 012746 006141      MOV      #BASADD,-(SP)
014542 012746 011026      MOV      #FMT5,-(SP)
014546 012746 000005      MOV      #5,-(SP)
014552 010600      MOV      SP,R0
014554 104417      TRAP     C#PNTF
014556 062706 000014      ADD      #14,SP
3080 014562      PRINTF  #FMT3
014562 012746 011012      MOV      #FMT3,-(SP)
014566 012746 000001      MOV      #1,-(SP)
014572 010600      MOV      SP,R0
014574 104417      TRAP     C#PNTF
0145  062706 000004      ADD      #4,SP
3081 014602      DODU    PSETNM      ;DROP DRIVE
014602 013700 003456      MOV      PSETNM,R0
014606 104451      TRAP     C#DODU
3082 014610      DOCLN
014610 104444      TRAP     C#DCLN
3083 014612      B#:
3084
3085 014612      ENDINIT
014612      L10015:
014612 104411      TRAP     C#INIT
3086 014614      ENDMOD
3087
3088      .SBTTL  AUTO DROP SECTION
3089
3090      ;THE AUTO DROP SECTION IS INVOKED BY THE DIAGNOSTIC SUPERVISOR WHENEVER THE

```

AUTO DROP SECTION

```

3091
3092
3093
3094
3095
3096
3097 014614
3098 014614 005037 003462
3099 014620
      014620 012746 000340
      014624 012746 015624
      014630 013746 003244
      014634 012746 000003
      014640 104437
      014642 062706 000010
3100
3101 014646 013702 003042
3102 014652 005762 000000
3103 014656 005737 003462
3104 014662 001447
3105 014664
      014664 012746 007645
      014670 012746 011632
      014674 012746 000002
      014700 010600
      014702 104417
      014704 062706 000006
3106 014710
      014710 005046
      014712 153716 003047
      014716 012746 006152
      014722 013746 003042
      014726 012746 006141
      014732 012746 011026
      014736 012746 000005
      014742 010600
      014744 104417
      014746 062706 000014
3107
3108 014752
      014752 012746 011012
      014756 012746 000001
      014762 010600
      014764 104417
      014766 062706 000004
3109
3110 014772
      014772 013700 003456
      014776 104451
3111 015000 000460
3112 015002 013705 003046
3113 015006 052705 000200
3114 015012 010562 000000
3115 015016 032762 000001 000000
3116 015024 001046
3117 015026
      015026 012746 007703

```

```

; "ADR" FLAG IS SET BY THE OPERATOR. IT IS EXECUTED AFTER THE INITIALIZATION
; CODE AND CHECKS THE DRIVE TO DETERMINE IF IT IS READY TO RECEIVE A COMMAND.
; IF THE DRIVE IS NOT READY IT IS DROPPED FROM THE TEST CYCLE AND THE NEXT
; DRIVE IS ACCESSED. IF THE DRIVE IS READY THE HARDWARE TESTS ARE PERFORMED
; AFTER WHICH THE NEXT DRIVE IS ACCESSED.

BGNAUTO
CLR      TRPFLG          ;CLEAR TRAP FLAG
SETVEC  ERRVEC, #TRPHAN, #340 ;SET UP TRAP VECTOR TO DETECT
MOV     #340, -(SP)
MOV     #TRPHAN, (SP)
MOV     ERRVEC, -(SP)
MOV     #3, -(SP)
TRAP   C#SVEC
ADD     #10, SP

; /NON-EXISTENT CONTROLLER
MOV     RLBAS, R2        ;GET RL11 BASE ADDRESS
TST     RLCS(R2)        ;ACCESS DRIVE CONTROLLER ADDRESS
TST     TRPFLG          ;DID TRAP OCCUR?
BEQ     1$              ;BRANCH TO CHECK DRIVE IF TRAP DID NOT OCCUR
PRINTF  #FMT24, #NOCTLR ;ELSE, PRINT MSG. "DRIVE DROPPED NO CONTROLLER
MOV     #NOCTLR, -(SP)
MOV     #FMT24, -(SP)
MOV     #2, -(SP)
MOV     SP, R0
TRAP   C#PNTF
ADD     #6, SP
PRINTF  #FMT5, #BASADD, RLBAS, #DRVNAM, <B, RLDRV+1>
CLR     -(SP)
BISB   RLDRV+1, (SP)
MOV     #DRVNAM, -(SP)
MOV     RLBAS, -(SP)
MOV     #BASADD, -(SP)
MOV     #FMT5, (SP)
MOV     #5, -(SP)
MOV     SP, R0
TRAP   C#PNTF
ADD     #14, SP

;PRINT DRIVE INFORMATION
PRINTF  #FMT3
MOV     #FMT3, -(SP)
MOV     #1, -(SP)
MOV     SP, R0
TRAP   C#PNTF
ADD     #4, SP

DODU   PSETNM          ;DO DROP UNIT ON DRIVE
MOV     PSETNM, R0
TRAP   C#DODU
BR     2$              ;BRANCH TO EXIT
1$:    MOV     RLDRV, R5 ;ELSE, GET DRIVE NUMBER
BIS     #CRDYMSK, R5   ;SET CONTROLLER READY
MOV     R5, RLCS(R2)  ;LOAD IN THE DRIVE NUMBER
BIT     #DRDYMSK, RLCS(R2) ;IS DRIVE READY?
BNE     2$              ;BRANCH TO PERFORM TESTS IF DRIVE IS READ
PRINTF  #FMT24, #NOTRDY ;PRINT MSG. "DRIVE DROPPED - DID NOT RESPOND
MOV     #NOTRDY, -(SP)

```


AUTO DROP SECTION

```

015032 012746 011632      MOV    #FMT24,(SP)
015036 012746 000002      MOV    #2,(SP)
015042 010600              MOV    SP,RO
015044 104417              TRAP   C$PNTF
015046 062706 000006      ADD    #6,SP
3118                                     ;/WITH 'READY' "
3119 015052              PRINTF #FMT5,#BASADD,RLBAS,#DRVNAM,<B,RLDRV.1>
015052 005046              CLR    -(SP)
015054 153716 003047      BISB  RLDRV+1,(SP)
015060 012746 006152      MOV    #DRVNAM,-(SP)
015064 013746 003042      MOV    RLBAS,-(SP)
015070 012746 006141      MOV    #BASADD,-(SP)
015074 012746 011026      MOV    #FMT5,-(SP)
015100 012746 000005      MOV    #5,-(SP)
015104 010600              MOV    SP,RO
015106 104417              TRAP   C$PNTF
015110 062706 000014      ADD    #14,SP
3120                                     ;PRINT DRIVE INFORMATION
3121 015114              PRINTF #FMT3
015114 012746 011012      MOV    #FMT3,-(SP)
015120 012746 000001      MOV    #1,-(SP)
015124 010600              MOV    SP,RO
015126 104417              TRAP   C$PNTF
015130 062706 000004      ADD    #4,SP
3122 015134              DODU   PSETNM          ;DO DROP UNIT ON DRIVE
015134 013700 003456      MOV    PSETNM,RO
015140 104451              TRAP   C$DODU
3123 015142              2$:   CLRVEC  ERRVEC          ;RELEASE ERROR VECTOR
015142 013700 003244      MOV    ERRVEC,RO
015146 104436              TRAP   C$CVEC
3124 015150              ENDAUTO
015150              L10016:
015150 104461              TRAP   C$AUTO
3125
3126              .SBTTL  CLEANUP CODE SECTION
3127
3128 015152              BGNMOD  CLNCODE
3129 015152              BGNCLN
3130
3131 015152              SETVEC  ERRVEC,#TRPHAN,#340
015152 012746 000340      MOV    #340,-(SP)
015156 012746 015624      MOV    #TRPHAN,-(SP)
015162 013746 003244      MOV    ERRVEC,-(SP)
015166 012746 000003      MOV    #3,-(SP)
015172 104437              TRAP   C$SVEC
015174 062706 000010      ADD    #10,SP
3132
3133              ;
3134 015200              SETPRI #7          ;SET PRIORITY TO 7          ;JSD REV A
015200 012700 000300      SETPRI #PRI06      ;SET PRIORITY TO 6          ;JSD REV A
015204 104441              MOV    #PRI06,RO
015206 032762 000200 0'0000 2$:  TRAP   C$SPRI
3135 015214 001407              BIT    #CRDYMSK,RLCS(R2) ;TEST IF CONTROLLER READY
3136 015216 053762 003046 000000 3$:  BEQ    3$          ;NO LOOP UNTIL READY
3137 015224 032762 000001 000000  BIS    RLDRV,RLCS(R2) ;SET DRIVE NUMBER
3138 015232 001005              BIT    #DRDYMSK,RLCS(R2) ;TEST IF DRIVE BUSY
3139 015234              BNE    5$          ;NO - SKIP
3140              WAITMS #3          ;WAIT 300 MS

```

CLEANUP CODE SECTION

```

3141 015246          5$: CLRVEC  RLVEC      ;RELEASE VEC
      015246 013700 003044  MOV     RLVEC,RO
      015252 104436      TRAP    C$CVEC
3142 015254 005737 003464  TST     PWRFLG      ;PWR FAIL SFT
3143 015260 001402      BEQ     7$          ;NO
3144 015262 005337 003464  DEC     PWRFLG
3145 015266          7$: CLRVEC  ERRVEC
      015266 013700 003244  MOV     ERRVEC,RO
      015272 104436      TRAP    C$CVEC
3146 015274          BRESET  ;TAKE CARE OF LSI 11
      015274 104433      TRAP    C$RESET

3147
3148 015276          ENDCLN
      015276          L10017:
      015276 104412      TRAP    C$CLEAN

3149
3150 015300          BGNDU
3151 015300 000240      NOP
3152 015302          ENDDU
      015302          L10020:
      015302 104453      TRAP    C$DU

3153
3154 015304          ENDMOD
3155
3156          .SBTTL  GLOBAL SUBROUTINES
3157
3158 015304          BGNMOD  GLBSUB
3159
3160 015304 012737 000160 002116 TIME:  MOV     #160,L$DLY      ;GET OUTER DELAY LOOP
3161 015312 005237 003476      INC     TIM.US        ;US-WAIT ROUTINE INDICATOR
3162 015316 013737 003466 003472  MOV     XDELAY,MININC ;SAVE ORIGINAL US-WAIT
3163 015324 005437 003466      NEG     XDELAY        ;GET NEGATIVE OF FACTOR
3164 015330          READBUS ;Q - BUS?
      015330 104407      TRAP    C$RDBU
3165 015332          BCOMPLETE 2$ ;BRANCH IF YES
      015332 103420      BCS     2$
3166          ;1$: DELAY  #1. ;WAIT ;JSD REV A
3167 015334          ;2$: DELAY  1. ;WAIT ;JSD REV A
      015334 012727 000001  MOV     #1.,(PC)+
      015340 000000      .WORD  0
      015342 013727 002116  MOV     L$DLY,(PC)+
      015346 000000      .WORD  0
      015350 005367 177772  DEC     -6(PC)
      015354 001375      BNE     .-4
      015356 005367 177756  DEC     -22(PC)
      015362 001367      BNE     .-20
3168 015364 005237 003466  INC     XDELAY        ;WAIT FACTOR EXPIRED?
3169 015370 002761      BLT     1$           ;BRANCH - IF NO
3170 015372 000422      BR      4$           ;GET TIME
3171 015374 012737 000065 002116 2$: MOV     #65,L$DLY      ;GET OUTER DELAY LOOP
3172          ;3$: DELAY  #1. ;WAIT WITH RESPECT TO FONZ BUS ;JSD REV A
3173          ;4$: DELAY  1. ;WAIT WITH RESPECT TO FONZ BUS ;JSD REV A
      015402          MOV     #1.,(PC)+
      015402 012727 000001  .WORD  0
      015406 000000      MOV     L$DLY,(PC)+
      015410 013727 002116  .WORD  0
      015414 000000      DEC     -6(PC)
      015416 005367 177772

```

GLOBAL SUBROUTINES

```

015422 001375      BNE      . 4
015424 005367 177756 DEC      -22(PC)
015430 001367      BNE      . 20
3174 015432 005237 003466 INC      XDELAY      ;WAIT FACTOR EXPIRED?
3175 015436 002761      BLT      3$          ;BRANCH - IF NO
3176 015440 063737 003472 003132 4$: ADD      MININC,TEMPO ;GET TIME EXPIRED
3177 015446 000207      RTS      PC          ;RETURN
3178
3179 015450 012737 000160 002116 XTIME: MOV      @160,L$DLY    ;GET OUTER DELAY LOOP
3180 015456 005037 003476      CLR      TIM,US      ;MS. WAIT INDICATOR
3181 015462 013737 003470 003502 MOV      YDELAY,MAJINC ;SAVE ORIGINAL WAIT MS
3182 015470 006337 003470      ASL      YDELAY      ;MULTIPLY BY FACTOR 4
3183 015474 006337 003470      ASL      YDELAY
3184 015500 005437 003470      NEG      YDELAY      ; -- ----
3185 015504      READBUS ;GET NEGATIVE OF RESULT
015504 104407      TRAP     C$RDBU    ;Q - BUS?
3186 015506      BNCOMPLETE 1$ ;BRANCH IF NO
015506 103023      BCC      1$
3187 015510 012737 000150 002116 MOV      @150,L$DLY    ;GET OUTER DELAY LOOP
3188      ;2$: DELAY     @20      ;WAIT WITH RESPECT TO FONZ BUS ;JSD REV A
3189      2$: DELAY     20      ;WAIT WITH RESPECT TO FONZ BUS ;JSD REV A
015516 012727 000020      MOV      @20,(PC)+
015522 000000      .WORD   0
015524 013727 002116      MOV      L$DLY,(PC)+
015530 000000      .WORD   0
015532 005367 177772      DEC      -6(PC)
015536 001375      BNE      . 4
015540 005367 177756      DEC      -22(PC)
015544 001367      BNE      . 20
3190 015546 005237 003470      INC      YDELAY      ;WAIT FACTOR EXPIRED
3191 015552 002761      BLT      2$          ;BRANCH - IF NO
3192 015554 000417      BR       3$          ;GET TIME
3193      ;1$: DELAY     @10      ;WAIT ;JSD REV A
3194      1$: DELAY     10      ;WAIT ;JSD REV A
015556 012727 000010      MOV      @10,(PC)+
015562 000000      .WORD   0
015564 013727 002116      MOV      L$DLY,(PC)+
015570 000000      .WORD   0
015572 005367 177772      DEC      -6(PC)
015576 001375      BNE      .-4
015600 005367 177756      DEC      -22(PC)
015604 001367      BNE      .-20
3195 015606 005237 003470      INC      YDELAY      ;WAIT FACTOR EXPIRED?
3196 015612 002761      BLT      1$          ;BRANCH - IF NO
3197 015614 063737 003502 003474 3$: ADD      MAJINC,TEMP ;GET EXPIRED TIME
3198 015622 000207      RTS      PC          ;RETURN
3199
3200 015624      BGNSRV
3201
3202      ;TRAP HANDLER. INDICATES OCCURRENCE OF A TRAP.
3203
3204 015624 005237 003462      TRPHAN: INC      TRPFLG
3205
3206 015630      ENDSRV
015630 L10021:
015630 000002      RTI
3207

```

GLOBAL SUBROUTINES

```

3208 015632          BGNSRV
3209
3210          ; INTERRUPT HANDLER. ABORTS WAIT TIMER AND STORES RL11 REGISTERS.
3211
3212 015632          INTMR:
3213
3214 015632 012237 003060          MOV      (R2),T.CS          ;STORE RL REGISTERS
3215 015636 012237 003062          MOV      (R2),T.BA
3216 015642 012237 003064          MOV      (R2),T.DA
3217 015646 011237 003066          MOV      (R2),T.MP
3218 015652 012737 177777          MOV      # 1,DONE          ;SET DONE FLAG
3219 015660 013702 003042          MOV      RLBAS,R2          ;RESTORE R2
3220 015664          ABORTWAIT
3221
3222 015710          ENDSRV
          L10022:
          RTI
3223
3224          ; ERROR LIMIT CHECKING ROUTINE
3225          ; DROPS DRIVE IF ERROR LIMIT EXCEEDED
3226
3227 015712 027737 165334 013566 CKERLM: CMP      @ERRPOINT,ERLIMW          ;TEST IF ERROR LIMIT EXCEEDED
3228 015720 002453          BLT      1$                ;NO SKIP
3229 015722          INLOOP          ;CHECK IF IN ERROR LOOP
          TRAP      C@INLP
3230 015724          BCOMPLETE 1$          ;YES SKIP
          BCS      1$
3231 015726          PRINTF      @FMT25,ERLIMW,@MEXERS
          MOV      @MEXERS,-(SP)
          MOV      ERLIMW,(SP)
          MOV      @FMT25,(SP)
          MOV      @3,(SP)
          MOV      SP,R0
          TRAP      C@PNTF
          ADD      @10,SP
3232 015756          PRINTF      @FMT5,@BASADC,RLBAS,@DRVNAM,<B,RLDRV+1>
          CLR      -(SP)
          BISB     RLDRV+1,(SP)
          MOV      @DRVNAM,-(SP)
          MOV      RLBAS,-(SP)
          MOV      @BASADD,-(SP)
          MOV      @FMT5,-(SP)
          MOV      @5,-(SP)
          MOV      SP,R0
          TRAP      C@PNTF
          ADD      @14,SP
3233 016020          PRINTF      @FMT3
          MOV      @FMT3,-(SP)
          MOV      @1,-(SP)
          MOV      SP,R0
          TRAP      C@PNTF
          ADD      @4,SP
3234 016040          DODU          PSETNM          ;DROP DRIVE
          MOV      PSETNM,R0
          TRAP      C@DODU
3235 016046          DOCLN          ;GO TO CLEAN UP
          TRAP      C@DCLN
          
```

GLOBAL SUBROUTINES

```

3236 016050 000207      1$:   RTS      PC
3237
3238      ; READ AND STORE ALL RL11 REGISTERS
3239 016052 016237 000000 003060 READRL: MOV      RLCSR(R2),T.CS ;GET CS REG
3240 016060 016237 000002 003062      MOV      RLBA(R2),T.BA ;GET BUS ADDRESS REG
3241 016066 016237 000004 003064      MOV      RLDA(R2),T.DA ;GET DISK ADDRESS
3242 016074 016237 000006 003066      MOV      RLMP(R2),T.MP ;GET MULTI-PURPOSE REG.
3243 016102 000207      RTS      PC ;RETURN
3244
3245      ; WAIT FOR CONTROLLER TIMEOUT TO FORCE INTERRUPT ROUTINE
3246 016104 011646      WAITIN: MOV      (SP), (SP) ;MAKE ROOM FOR ERROR POINTER
3247 016106 005066 000002      CLR      2(SP) ;CLEAR FOR POINTER
3248 016112 032762 000200 000000      BIT      @CRDYMSK,RLCSR(R2) ;TEST IF CONTROLLER READY
3249 016120 001420      BEQ      4$ ;NO - SKIP TO WAIT
3250 016122 004737 016052      JSR      PC,READRL ;READ ALL RL REGS
3251 016126 005737 003022      TST      DONE ;TEST IF INTERRUPT OCCURRED
3252 016132 001435      BEQ      5$ ;NO - GO SET NO INTERRUPT ERR FLAG
3253 016134 012766 006316 000002 1$:   MOV      @MTOSLOW,2(SP) ;ELSE SET TOO SLOW ERROR POINTER
3254 016142 032737 002000 003060      BIT      @OPIERR,T.CS ;TEST IF OPI SET
3255 016150 001403      BEQ      2$ ;NO - SKIP
3256 016152 012766 006336 000002      MOV      @MORRES,2(SP) ;SET MESSAGE FOR NO DRIVE RESPONSE
3257 016160 000207      2$:   RTS      PC ;RETURN
3258 016162      4$:   WAITMS  #3 ;WAIT 300 MS FOR TIMEOUT
3259 016174 032762 000200 000000      BIT      @CRDYMSK,RLCS(R2) ;TEST IF READY NOW SET
3260 016202 001006      BNE      3$ ;YES - SKIP
3261 016204 004737 016052      JSR      PC,READRL ;READ RL REGS
3262 016210 012766 006407 000002      MOV      @MCONHNG,2(SP) ;SET MESSAGE FOR CONTROLLER HUNG
3263 016216 000760      BR      2$ ;SKIP
3264 016220 005737 003022      3$:   TST      DONE ;ELSE CHECK IF INTERRUPT OCCURRED
3265 016224 001343      BNE      1$ ;YES - SKIP TO SET TOO SLOW
3266 016226 004737 016052      5$:   JSR      PC,READRL ;READ RL REGS
3267 016232 012766 006354 000002      MOV      @MNOINT,2(SP) ;ELSE SET NO INTERRUPT FLAG
3268 016240 000747      BR      2$ ;GO TO RETURN
3269
3270      ; OPERATION AND TEST INITIALIZE ROUTINE
3271 016242 005037 003020      TSTINT: CLR      OPFLAG ;CLEAR OPERATION FLAGS
3272 016246 105057 003461      CLR      NOERCT ;RESET INHIBIT ERROR COUNTING
3273 016252 005037 003030      CLR      MORECE ;RESET MORE COMPARE ERRORS
3274 016256 000207      RTS      PC
3275
3276      ; GET STATUS AND GET STATUS WITH RESET ROUTINE
3277 016260 013746 003142      GSTATR: MOV      TEMP4,-(SP) ;STORE TEMP4
3278 016264 012737 000013 003142      MOV      @GETSTAT!DRSET,TEMP4 ;SET FOR RESET
3279 016272 000412      BR      GSTATG
3280 016274 013746 003142      GSTATC: MOV      TEMP4,-(SP) ;STORE TEMP4
3281 016300 012737 000003 003142      MOV      @GETSTAT,TEMP4 ;SET FOR NO RESET
3282 016306 000404      BR      GSTATG
3283 016310 013746 003142      GSTAT:  MOV      TEMP4,-(SP) ;STORE TEMP4
3284 016314 005037 003142      CLR      TEMP4 ;SET FOR SAVE L. AND T. REGS
3285 016320 010346      GSTATG: MOV      R3,-(SP) ;STORE R3
3286 016322 013703 003016      MOV      SSINDEX,R3 ;GET SUBROUTINE INDEX
3287 016326 005723      TST      (R3)+ ;BUMP IT FOR NEXT ENTRY
3288 016330 016663 000004 002420      MOV      4(SP),SUBSTK(R3) ;INSERT THIS CALL
3289 016336 162763 000004 002420      SUB      #4,SUBSTK(R3) ;ADJUST IT TO CALLING LOCATION
3290 016344 010337 003016      MOV      R3,SSINDEX ;STORE IT BACK
3291 016350 010046      MOV      R0,-(SP) ;STORE R0
3292 016352 010146      MOV      R1,(SP) ;STORE R1

```

GLOBAL SUBROUTINES

```

3293 016354 012737 000002 003032      MOV      #2,ERRSWI      ;SET FOR NO ERROR RETURN
3294 016362 032737 000010 003142      BIT      #DRSET,TEMP4   ;TEST IF DRIVE RESET
3295 016370 001460                BEQ      11#            ;NO - SKIP
3296 016372 032762 040000 000000      BIT      #DRVERR,RLCS(R2) ;TEST IF DRIVE ERROR SET
3297 016400 001405                BEQ      49#            ;NO - SKIP
3298 016402                WAITMS  #3              ;WAIT FOR 300 MS FOR DRIVE TO SETTLE
3299 016414 012701 000062                MOV      #50.,R1        ;INITIALIZE WAIT COUNT
3300 016420 004737 016310      49#:   JSR      PC,GSTAT      ;GET DRIVE STATUS
3301 016424 017110                50#:   3#
3302 016426 032737 000001 003060      BIT      #DRDYMSK,T.CS  ;TEST IF DRIVE READY
3303 016434 001054                BNE      5#            ;YES - GO DO CLEAR
3304 016436 032737 000020 003066      BIT      #HOSTAT,T.MP   ;ELSE TEST IF HEADS OUT
3305 016444 001010                BNE      51#           ;YES - BYPASS RELOAD WAIT FLAG SETTING
3306 016446 032737 144000 003066      BIT      #SPDSTAT!HCESTAT!WDESTAT,T.MP ;TEST IF DRIVE HAS ERROR
3307                                ;THAT CAUSED HEADS TO
3308                                ;UNLOAD
3309 016454 001444                BEQ      5#            ;NO - SKIP
3310 016456 052737 040000 003020      BIS      #RELDWT,OPFLAG ;ELSE SET WAIT FLAG
3311 016464 000440                BR       5#            ;SKIP TO CLEAR
3312 016466 032737 040000 003060      51#:   BIT      #DRVERR,T.CS ;TEST IF DRIVE ERROR NOW
3313 016474 001034                BNE      5#            ;YES - SKIP TO CLEAR
3314 016476                WAITMS  #1              ;WAIT FOR DRIVE TO GET ERROR, RDY, OR HEADS OUT
3315 016510 005301                DEC      R1            ;DEC WAIT COUNTER
3316 016512 001342                BNE      50#           ;IF NOT DONE, LOOP
3317 016514 012703 010375      MOV      #UNDEF,R3      ;MESSAGE FOR UNDEFINED STATE
3318 016520      ERRHRD 10001.,,ERR1
3318 016520      TRAP  C!ERRHRD
3318 016520      .WORD 10001
3318 016522 104456      .WORD 0
3318 016524 023421      .WORD ERR1
3318 016526 000000      .WORD 14#
3319 016530 000565      BR       14#           ;EXIT
3320 016532 005737 003142      11#:   TST      TEMP4         ;TEST IF SAVE REGISTERS
3321 016536 001013                BNE      5#            ;NO SKIP
3322 016540 012701 000004                MOV      #4,R1         ;SET SAVE COUNT
3323 016544 012703 003060                MOV      #L.MP+2,R3    ;SET ADDRESS OF FIRST SAVE
3324 016550 014346      8#:   MOV      -(R3),-(SP)   ;PUT REG ON STACK
3325 016552 005301                DEC      R1            ;DEC COUNT
3326 016554 001375                BNE      8#            ;LOOP UNTIL ALL SAVED
3327 016556 012737 000003 003054      MOV      #GETSTAT,L.DA ;SET FOR GET STATUS
3328 016564 000403                BR       6#            ;SKIP
3329 016566 013737 003142 003054      5#:   MOV      TEMP4,L.DA   ;INSERT PRESET FOR STATUS
3330 016574                6#:
3331 016574 005037 003022      CLR      DONE          ;CLEAR INTERRUPT FLAG
3332 016600 013737 003046 003050      MOV      RLDRV,L.CS    ;SET UP TO GET STATUS
3333 016606 042737 002000 003050      BIC      #BIT10,L.CS   ;CLEAR FOR DRIVE 4 - 7 SPEC'D
3334 016614 052737 000104 003050      BIS      #GTSTAT,L.CS
3335 016622 013762 003054 000004      MOV      L.DA,RLDA(R2) ;LOAD RL REGS
3336 016630 013762 003050 000000      MOV      L.CS,RLCSR(R2) ;LOAD CS REG
3337 016636                WAITUS  #1              ;WAIT 100 US FOR INTERRUPT
3338 016650 005737 003022      TST      DONE          ;CHECK IF INTERRUPT OCCURRED
3339 016654 001504                BEQ      1#            ;NO - SKIP
3340 016656 013737 003066 003074      4#:   MOV      T.MP,T.STAT  ;STORE MP REGISTER
3341 016664 042737 177770 003074      BIC      #C<STAMSK>,T.STAT ;CLEAR ALL BUT STATE
3342 016672 032737 000010 003054      BIT      #DRSET,L.DA   ;TEST IF RESET WAS SPECIFIED
3343 016700 001503                BEQ      3#            ;NO - SKIP TO EXIT
3344 016702 032737 040000 003020      BIT      #RELDWT,OPFLAG ;TEST IF RELOAD WAIT FLAG SET
3345 016710 001427                BEQ      12#           ;NO SKIP

```

GLOBAL SUBROUTINES

```

3346 016712 012701 001130      MOV      #600.,R1      ;SET WAIT COUNT FOR 60 SECONDS
3347 016716 032762 000001 000000 13:  BIT      #DRDYMSK,RLCS(R2) ;TEST IF DRIVE NOW READY
3348 016724 001021      BNE      12:          ;YES - SKIP
3349 016726      WAITMS  #1          ;CALL WAIT
3350 016740 005301      DEC      R1          ;DEC COUNT
3351 016742 001365      BNE      13:          ;LOOP IF NOT 0
3352 016744 004737 016310      JSR      PC,GSTAT    ;GET DRIVE STATUS
3353 016750 017110      3:          ;ERROR RETURN
3354 016752 012703 010442      MOV      #MRLFAL,R3   ;SET RESULT MESSAGE POINTER
3355 016756      ERRHRD 10003.,,ERR1
      016756 104456      TRAP    C:ERRHRD
      016760 023423      .WORD  10003
      016762 000000      .WORD  0
      016764 011724      .WORD  ERR1
3356 016766 000446      BR       14:          ;GO TO EXIT
3357 016770      WAITUS #10.        ;WAIT FOR 1MS
3358 017002 004737 016310      JSR      PC,GSTAT    ;GET DRIVE STATUS
3359 017006 017110      3:          ;TEST IF ANY ERROR
3360 017010 032737 100000 003060      BIT      #ANYERR,T.CS ;NO - SKIP
3361 017016 001434      BEQ     3:          ;CHECK IF VOLUME CHECK RESET
3362 017020 032737 001000 003066      BIT      #VCSTAT,T.MP ;YES SKIP
3363 017026 001403      BEQ     7:          ;SET REASON POINTER
3364 017030 012703 006443      MOV      #VCNRST,R3  ;EXIT
3365 017034 000417      BR       2:          ;CHECK IF DRIVE ERROR
3366 017036 032737 040000 003060 7:  BIT      #DRVERR,T.CS ;NO - SKIP
3367 017044 001405      BEQ     9:          ;EXIT
3368 017046      ERRHRD 10004.,,ERR6
      017046 104456      TRAP    C:ERRHRD
      017050 023424      .WORD  10004
      017052 000000      .WORD  0
      017054 012226      .WORD  ERR6
3369 017056 000412      BR       14:          ;SET REASON POINTER
3370 017060 012703 006464      9:  MOV      #UNXERR,R3  ;EXIT
3371 017064 000403      BR       2:          ;WAIT FOR INTERRUPT
3372 017066 004737 016104      1:  JSR      PC,WAITIN   ;STORE REASON POINTER FOR RETURN
3373 017072 012603      MOV      (SP)+,R3
3374 017074      2:  ERRHRD 10002.,,ERR1
      017074 104456      TRAP    C:ERRHRD
      017076 023422      .WORD  10002
      017100 000000      .WORD  0
      017102 011724      .WORD  ERR1
3375 017104 005037 003032      14: CLR      ERRSWI     ;CLEAR FOR ERROR RETURN
3376 017110 005737 003142      3:  TST      TEMP4      ;TEST IF REGISTERS WERE SAVED
3377 017114 001007      BNE     22:          ;NO - SKIP
3378 017116 012703 003050      MOV      #L.CS,R3   ;SET POINTER TO RESTORE
3379 017122 012701 000004      MOV      #4,R1      ;SET REGISTER COUNT
3380 017126 012623      20: MOV      (SP)+,(R3)+ ;RESTORE REG
3381 017130 005301      DEC      R1          ;DEC COUNT
3382 017132 001375      BNE     20:          ;LOOP UNTIL ALL ARE RESTORED
3383 017134 162737 000002 003016 22: SUB      #2,SSINDEX  ;REMOVE ENTRY FROM SUBROUT STACK
3384 017142 012601      MOV      (SP)+,R1   ;RESTORE R1
3385 017144 012600      MOV      (SP)+,R0   ;RESTORE R0
3386 017146 012603      MOV      (SP)+,R3   ;RESTORE R3
3387 017150 012637 003142      MOV      (SP)+,TEMP4 ;RESTORE TEMP4
3388 017154 005737 003032      TST      ERRSWI     ;TEST IF ERROR RETURN
3389 017160 001403      BEQ     99:          ;YES - SKIP
3390 017162 063716 003032      ADD     ERRSWI,(SP) ;ADD IN ERROR RETURN

```

GLOBAL SUBROUTINES

```

3391 017166 000207          RTS      PC
3392 017170 017616 000000 99#:   MOV      @ (SP), (SP)      ;SET ERROR RETURN ADDRESS
3393 017174 000207          RTS      PC
3394
3395          ;      SEEK ROUTINE
3396 017176 012737 177777 003134 XSEEK:  MOV      @ 1,TEMP1      ;SET SPECIAL TIMING SEEK FLAG
3397 017204 000402          BR       XSEEK1
3398 017206 005037 003134 XSEEK:  CLR       TEMP1        ;CLEAR SPECIAL SEEK FOR TIMING FLAG
3399 017212 010346 XSEEK1: MOV      R3, (SP)      ;STORE R3
3400 017214 013703 003016          MOV      SSINDX,R3      ;GET SUBROUTINE INDEX
3401 017220 005723          TST      (R3)+          ;BUMP IT FOR NEXT ENTRY
3402 017222 016663 000002 002420 MOV      2(SP),SUBSTK(R3) ;INSERT THIS CALL
3403 017230 162763 000004 002420 SUB      @4,SUBSTK(R3)    ;ADJUST IT TO CALLING LOCATION
3404 017236 010337 003016          MOV      R3,SSINDX      ;STORE IT BACK
3405 017242 010046          MOV      R0,-(SP)
3406 017244 010146          MOV      R1,(SP)
3407 017246 010546          MOV      R5,-(SP)      ;STORE REG
3408 017250 012737 000002 003032 MOV      @2,ERRSWI      ;SET FOR NO ERROR RETURN
3409 017256 005037 003112          CLR      DIFAUG        ;CLEAR DIFFERENCE AUGMENT (FOR SEEKING
3410          ;      PAST GUARD BAND)
3411 017262 004737 022366          JSR      PC,GETPOS      ;GET PRESENT POSITION
3412 017266 017720          65#
3413 017270 013737 003120 003114 MOV      CURCYL,OLDCYL  ;MOVE CURRENT TO OLD CYLINDER
3414 017276 023737 003116 002316 CMP      NEWCYL,HLMTW   ;TEST IF NEW IS GREATER THAN 255
3415 017304 003427          BLE      3#           ;NO - SKIP
3416 017306 163737 002316 003116 SUB      HLMTW,NEWCYL   ;ELSE SUBTRACT 255.
3417 017314 013737 003116 003112 MOV      NEWCYL,DIFAUG ;STORE DIFFERENCE AS AUGMENT
3418 017322 013737 002316 003116 MOV      HLMTW,NEWCYL  ;SET NEWCYL AS 255.
3419 017330 022737 000001 002312 CMP      @1,T.DRIVE
3420 017336 001424          BEQ      6#
3421 017340 162737 000001 003116 SUB      @1,NEWCYL
3422 017346 012737 000001 003124 MOV      @1,DESSGN
3423 017354 012737 000001 003122 MOV      @1,DESDIF
3424 017362 000451          BR       18#
3425 017364 005737 003116 3#:   TST      NEWCYL        ;TEST IF NEWCYL HAS NEGATIVE VALUE
3426 017370 100007          BPL      6#           ;NO - SKIP
3427 017372 005437 003116          NEG      NEWCYL        ;ELSE MAKE IT POSITIVE
3428 017376 013737 003116 003112 MOV      NEWCYL,DIFAUG ;AND STORE IT AS AUGMENT
3429 017404 005037 003116          CLR      NEWCYL        ;AND SET NEWCYL TO 0
3430 017410 013705 003120 6#:   MOV      CURCYL,R5     ;COMPUTE DIFFERENCE AND NEW CYLINDER
3431 017414 163705 003116          SUB      NEWCYL,R5     ;SUB NEWCYL FROM CURCYL
3432 017420 100005          BPL      13#          ;IF DIFF IS POSITIVE - SKIP(REV SEEK)
3433 017422 012737 000001 003124 MOV      @1,DESSGN     ;ELSE SET SIGN FOR FORWARD
3434 017430 005405          NEG      R5           ;MAKE DIFFERENCE POSITIVE
3435 017432 000402          BR       14#          ;SKIP
3436 017434 005037 003124 13#:  CLR      DESSGN        ;SET SIGN FOR REVERSE
3437 017440 010537 003122 14#:  MOV      R5,DESDIF     ;STORE DIFFERENCE
3438 017444 005737 003112          TST      DIFAUG        ;IS THERE A DIFFERENCE AUGMENT
3439 017450 001416          BEQ      18#          ;NO - SKIP
3440 017452 023737 003116 002316 CMP      NEWCYL,HLMTW  ;CHECK IF NEW CYL IS 255.
3441 017460 001007          BNE      17#          ;NO - SKIP
3442 017462 012737 000001 003124 MOV      @1,DESSGN     ;ELSE FORCE SIGN FOR FORWARD
3443          ;      (INNER GUARD BAND)
3444 017470 022737 000001 002312 CMP      @1,T.DRIVE
3445 017476 001003          BNE      18#
3446 017500 063737 003112 003122 17#:  ADD      DIFAUG,DESDIF
3447 017506          18#:

```


GLOBAL SUBROUTINES

```

3448 017506 012705 003050      MOV      #L.CS,R5      ;GET L REG ADDRESS
3449 017512 012715 000106      MOV      #SEEK,(R5)   ;SET FOR SEEK
3450 017516 053715 003046      BIS      RLDRV,(R5)   ;INSERT DRIVE NUMBER
3451 017522 042725 002000      BIC      #BIT10,(R5)  ;CLEAR IF DRIVE 4 - 7 SPEC D
3452 017526 005025              CLR      (R5)        ;CLEAR BUS ADDRESS
3453 017530 013715 003122      MOV      DESDIF,(R5)  ;LOAD DIFFERENCE
3454 017534 012700 000007      MOV      #7,R0      ;SET TO SHIFT DIFFERENCE
3455 017540 006315              21$:  ASL      (R5)
3456 017542 005300              DEC      R0
3457 017544 001375              BNE      21$         ;LOOP UNTIL ALIGNED
3458 017546 005737 003124      TST      DESSGN      ;TEST SIGN
3459 017552 001402              BEQ      23$         ;SKIP IF 0
3460 017554 052715 000004      BIS      #DIRBIT,(R5) ;ELSE INSERT SIGN
3461 017560 005737 003126      23$:  TST      DESHD      ;TEST IF HEAD 0
3462 017564 001402              BEQ      25$         ;YES - SKIP
3463 017566 052715 000020      BIS      #H0SEL,(R5) ;ELSE SET HEAD BIT
3464 017572 052725 000001      25$:  BIS      #M0SET0,(R5) ;INSERT MARKER BIT
3465 017576 004737 020324      JSR      PC,RDYCHK   ;CHECK IF DRIVE READY
3466 017602 017720              65$:  CLR      DONE        ;CLEAR INTERRUPT FLAG
3467 017604 005037 003022      TST      TEMP1       ;CHECK IF SPECIAL SEEK FLAG SET
3468 017610 005737 003134      BNE      65$         ;YES - SKIP, DO NOT START SEEK
3469 017614 001041              MOV      -(R5),RLDA(R2) ;LOAD RL REGISTERS
3470 017616 014562 000004      MOV      -(R5),RLBA(R2)
3471 017622 014562 000002      MOV      -(R5),RLCS(R2)
3472 017626 014562 000000      30$:  WAITUS  #10.
3473 017632              TST      DONE        ;TEST IF INTERRUPT DONE
3474 017644 005737 003022      BNE      32$         ;YES - SKIP
3475 017650 001012              JSR      PC,WAITIN   ;GO WAIT FOR INTERRUPT
3476 017652 004737 016104      MOV      (SP)+,R3    ;GET RESULT MESSAGE POINTER
3477 017656 012603      ERRHRD  10005...ERR1
3478 017660      TRAP   C#ERRRD
          .WORD  10005
          .WORD  0
          .WORD  ERR1
3479 017670 005037 003032      CLR      ERRSWI      ;CLEAR FOR ERROR RETURN
3480 017674 000411      BR      65$
3481 017676 005737 003060      32$:  TST      T.CS      ;TEST IF ANY ERROR
3482 017702 100006      BPL      65$         ;NO - SKIP
3483 017704      ERRHRD  10006...ERR6
          .WORD  10006
          .WORD  0
          .WORD  ERR6
3484 017714 005037 003032      CLR      ERRSWI      ;CLEAR FOR ERROR RETURN
3485 017720 162737 000002 003016 65$:  SUB      #2,SSINDEX  ;REMOVE ENTRY FROM SUBROUT STACK
3486 017726 012605      MOV      (SP)+,R5    ;RESTORE REGISTERS
3487 017730 012601      MOV      (SP)+,R1
3488 017732 012600      MOV      (SP)+,R0
3489 017734 012603      MOV      (SP)+,R3
3490 017736 005737 003032      TST      ERRSWI      ;TEST IF ERROR RETURN
3491 017742 001403      BEQ      99$         ;YES - SKIP
3492 017744 063716 003032      ADD      ERRSWI,(SP) ;ADD IN ERROR RETURN
3493 017750 000207      RTS      PC
3494 017752 017616 000000      99$:  MOV      @ (SP),(SP) ;SET ERROR RETURN ADDRESS
3495 017756 000207      RTS      PC
3496

```

GLOBAL SUBROUTINES

```

3553
3555      ; POSITION HEADS ROUTINE. POSITIONS HEADS USING 1 CYLINDER SEEKS
3556      ; TO CYLINDER SPECIFIED IN R5 BY THE CALLING ROUTINE
3557 017760 010346      POSHDS: MOV R3,-(SP)      ;SAVE REGS
3558 017762 013703 003016  MOV SSINDEX,R3      ;GET SUBROUTINE INDEX
3559 017766 005723      TST (R3)+           ;BUMP IT FOR NEXT ENTRY
3560 017770 016663 000002 002420  MOV 2(SP),SUBSTK(R3) ;INSERT THIS CALL
3561 017776 162763 000004 002420  SUB #4,SUBSTK(R3)   ;ADJUST IT TO CALLING LOCATION
3562 020004 010337 003016      MOV R3,SSINDEX     ;STORE IT BACK
3563 020010 010346      MOV R3,-(SP)
3564 020012 010446      MOV R4,(SP)
3565 020014 012737 000002 003032  MOV #2,ERRSWI      ;SET FOR NO ERROR RETURN
3566 020022 004737 022366      JSR PC,GETPOS      ;GET CURRENT POSITION
3567 020026 020266      PH65#
3568 020030 012704 000012      MOV #10.,R4        ;SET RETRY COUNT
3569 020034      BGNSEG
      020034 104404      TRAP C#BSEG
3570 020036      1# : INLOOP      ;CHECK IF IN ERROR LOOP
      020036 104420      TRAP C#INLP
3571 020040      BNCOMPLETE 5#      ;NO - SKIP
      020040 103012      BCC 5#
3572 020042 004737 022366      JSR PC,GETPOS      ;ELSE GET POSITION
3573 020046 020264      60#
3574 020050 023737 003120 003116  CMP CURCYL,NEWCYL  ;CHECK IF AT INTENDED POSITION
3575 020056 001017      BNE 8#           ;NO - SKIP
3576 020060 004737 020664      JSR PC,ONSWAP     ;SWAP OLDCYL AND NEWCYL
3577 020064 000414      BR 8#           ;SKIP
3578 020066 013737 003120 003114 5# : MOV CURCYL,OLDCYL  ;IN NOT LOOPING, STORE CURCYL AS OLDCYL
3579 020074 023705 003120      CMP CURCYL,R5      ;CHECK IF HDS AT FINAL POSITION
3580 020100 001471      BEQ 60#         ;YES - GO TO EXIT
3581 020102 003003      BGT 7#         ;IF CURCYL > FINAL POSITION SKIP
3582 020104 005237 003116      INC NEWCYL        ;ELSE BUMP NEWCYL (MOVE HDS IN)
3583 020110 000402      BR 8#           ;SKIP
3584 020112 005337 003116 7# : DEC NEWCYL        ;DEC NEWCYL (MOVE HDS OUT)
3585 020116 004737 017206 8# : JSR PC,XSEEK     ;DO SEEK
3586 020122 020264      60#
3587 020124 012701 005670      MOV #3000.,R1     ;SET WAIT COUNT 300 MS
3588 020130 004737 022102      JSR PC,RDYWAIT   ;WAIT FOR DRIVE READY
3589 020134 020264      60#
3590 020136 005737 003060      TST T.CS        ;TEST IF ANY ERROR
3591 020142 100007      BPL 10#         ;NO - SKIP
3592 020144      ERRHRD 10008.,,ERR6
      020144 104456      TRAP C#ERRRD
      020146 023430      .WORD 10008
      020150 000000      .WORD 0
      020152 012226      .WORD ERR6
3593 020154 005037 003032      CLR ERRSWI      ;CLEAR FOR ERROR ERROR RETURN
3594 020160 000441      BR 60#
3595 020162 004737 022366 10# : JSR PC,GETPOS     ;GET POSITION
3596 020166 020264      60#
3597 020170 023737 003120 003116  CMP CURCYL,NEWCYL ;CHECK IF ARRIVED AT DESIRED PLACE
3598 020176 001003      BNE 15#         ;NO - SKIP
3599 020200 012704 000012 14# : MOV #10.,R4        ;ELSE INIT RETRY COUNT
3600 020204 000714      BR 1#           ;GO DO NEXT SEEK
3601 020206 005737 003124 15# : TST DESSGN      ;TEST IF GOING IN
3602 020212 001017      BNE 17#         ;YES - SKIP
3603 020214 023737 003120 003116  CMP CURCYL,NEWCYL ;CHECK IF HEADS DID NOT MOVE IN

```

GLOBAL SUBROUTINES

```

3604 020222 003366          BGT      14$      ;YES - SKIP
3605 020224 005304          16$:    DEC      R4        ;DEC RETRY COUNT
3606 020226 001333          BNE      8$        ;DO ANOTHER SEEK IF NOT 0
3607 020230 012703 007323  MOV      #MDMOVF,R3 ;ELSE SET RESULT MESSAGE POINTER
3608 020234          ERRHRD 10009.,,ERR1
      020234 104456      TRAP    C$ERHRD
      020236 023431      .WORD  10009
      020240 000000      .WORD  0
      020242 011724      .WORD  ERR1
3609 020244 005037 003032  CLR      ERRSWI    ;CLEAR FOR ERROR ERROR RETURN
3610 020250 000405          BR       60$
3611 020252 023737 003120 003116 17$:    CMP      CURCYL,NEWCYL ;HDS SHOULD MOVE OUT, CHK THEY DID
3612 020260 002747          BLT     14$      ;YES SKIP
3613 020262 000760          BR       16$      ;ELSE GO DEC AND RETRY
3614 020264          20$:
3615 020264          60$:
3616 020264          ENDSEG
      020264 10000$:
3617 020266 104405          TRAP    C$ESEG
3618 020274 012604 000002 003016 PH65$: SUB      #2,SSINDEX ;REMOVE ENTRY FROM SUBROUT STACK
3619 020276 012600          MOV     (SP)+,R4   ;RESTORE REGISTERS
3620 020300 012603          MOV     (SP)+,R0
3621 020302 005737 003032  MOV     (SP)+,R3
3622 020306 001403          TST     ERRSWI    ;TEST IF ERROR RETURN
3623 020310 063716 00^032  BEQ     99$      ;YES - SKIP
3624 020314 000207          ADD     ERRSWI,(SP) ;ADD IN ERROR RETURN
3625 020316 017616 000000 99$:    RTS      PC
3626 020322 000207          MOV     @ (SP),(SP) ;SET ERROR RETURN ADDRESS
3627
3629          ;
3630          ; DRIVE READY TEST ROUTINE. CHECKS DRIVE IS READY. IF NOT, WAIT
      ; 500MS FOR READY TO SET.
3631 020324 010346          RDYCHK: MOV     R3,-(SP)   ;STORE REGS
3632 020326 013703 003016  MOV     SSINDEX,R3 ;GET SUBROUTINE INDEX
3633 020332 005723          TST     (R3)+     ;BUMP IT FOR NEXT ENTRY
3634 020334 016663 000002 002420  MOV     2(SP),SUBSTK(R3) ;INSERT THIS CALL
3635 020342 162763 000004 002420  SUB     #4,SUBSTK(R3) ;ADJUST IT TO CALLING LOCATION
3636 020350 010337 003016  MOV     R3,SSINDEX ;STORE IT BACK
3637 020354 010046          MOV     R0,-(SP)
3638 020356 010146          MOV     R1,-(SP)
3639 020360 010446          MOV     R4,-(SP)
3640 020362 012737 000002 003032  MOV     #2,ERRSWI   ;SET FOR NO ERROR RETURN
3641 020370 012701 011610  MOV     #5000.,R1   ;SET WAIT COUNT
3642 020374 004737 016310 1$:    JSR     PC,GSTAT   ;GET DRIVE STATUS
3643 020400 020534          4$
3644 020402 032737 000001 003060  BIT     #DRDYMSK,T.CS ;TEST IF DRIVE READY
3645 020410 001053          BNE     5$        ;YES - EXIT
3646 020412          WAITUS #1
3647 020424 005301          DEC     R1        ;DEC WAIT COUNT
3648 020426 001362          BNE     14$      ;LOOP IF NOT 0
3649 020430 012703 007760  MOV     #MDRDY,R3   ;SET RESULT MESSAGE POINTER
3650 020434 012704 010645  MOV     #C500MS,R4 ;SET CONDITION MESSAGE POINTER
3651 020440          ERRHRD 10010.,,ERR5
      020440 104456      TRAP    C$ERHRD
      020442 023432      .WORD  10010
      020444 000000      .WORD  0
      020446 012156      .WORD  ERR5

```

GLOBAL SUBROUTINES

```

3652 020450 012701 000062      MOV      #50.,R1      ;SET WAIT COUNT FOR 5 SECONDS
3653 020454 004737 016310      JSR      PC,GSTAT    ;GET DRIVE STATUS
3654 020460 020534                2$:      4$
3655 020462 032737 000001 003060      BIT      #DRDYMSK,T.CS ;TEST IF DRIVE READY
3656 020470 001007                BNE      3$          ;YES - SKIP
3657 020472                WAITMS  #1            ;WAIT FOR 100MS
3658 020504 005301                DEC      R1          ;DEC WAIT COUNTER
3659 020506 001362                BNE      2$          ;LOOP UNTIL TIME DONE
3660 020510 032737 100000 003060 3$:      BIT      #ANYERR,T.CS ;TEST IF ANYERR SET
3661 020516 001406                BEQ      4$          ;NO - SKIP
3662 020520                ERRHRD  10011.,,ERR6 ;REPORT ALL ERRORS
      020520 104456                TRAP    C$ERRHRD
      020522 023433                .WORD  10011
      020524 000000                .WORD  0
      020526 012226                .WORD  ERR6
3663 020530 005337 003254                DEC      ERRCNT      ;REDUCE ERROR COUNT FOR DUAL ERRORS
3664 020534 005037 003032                CLR      ERRSWI      ;CLEAR FOR ERROR RETURN
3665 020540 162737 000002 003016 4$:      5$:      SUB      #2,SSINDEX ;REMOVE ENTRY FROM SUBROUT STACK
3666 020546 012604                MOV      (SP)+,R4    ;RESTORE REGS
3667 020550 012601                MOV      (SP)+,R1
3668 020552 012600                MOV      (SP)+,R0
3669 020554 012603                MOV      (SP)+,R3
3670 020556 005737 003032                TST      ERRSWI      ;TEST IF ERROR RETURN
3671 020562 001403                BEQ      99$         ;YES - SKIP
3672 020564 063716 003032                ADD      ERRSWI,(SP) ;ADD IN ERROR RETURN
3673 020570 000207                RTS      PC
3674 020572 017616 000000 99$:      MOV      @ (SP),(SP) ;SET ERROR RETURN ADDRESS
3675 020576 000207                RTS      PC
3676
3677                ;      CHOOSE HEAD ROUTINE. PICKS HEAD 0 UNLESS SPECIFIC HEAD IS
3678                ;      SELECTED BY SOFTWARE PARAMETER.
3679 020600 005037 003126      ;CHOSH0: CLR      DESHD    ;CLEAR TO HEAD 0
3680 020604 032737 010000 013556      BIT      #HEADLM,MISWIW ;TEST IF HEAD SPECIFIED
3681 020612 001403                BEQ      1$          ;NO - SKIP
3682 020614 013737 013564 003126      MOV      HEADW,DESHD  ;INSERT SPECIFIED HEAD
3683 020622 000207                1$:      RTS      PC
3684
3685                ;      SWAP HEAD ROUTINE. CHANGES SELECTED HEAD TO HEAD 1
3686                ;      UNLESS HEAD 0 SPECIFICALLY SELECTED BY SOFTWARE PARAMETER.
3687 020624 032737 010000 013556      ;SWAPH0: BIT      #HEADLM,MISWIW ;TEST IF HEAD SPECIFIED
3688 020632 001011                BNE      2$          ;YES - TAKE ABORT EXIT
3689 020634 005737 003126                TST      DESHD      ;TEST IF HEAD ONE USED
3690 020640 001006                BNE      2$          ;YES - TAKE ABORT EXIT
3691 020642 012737 000001 003126      MOV      #1,DESHD    ;ELSE SET FOR HEAD ONE
3692 020650 062716 000002                ADD      #2,(SP)     ;BUMP PAST ABORT RETURN
3693 020654 000207                RTS      PC          ;RETURN
3694 020656 017616 000000 2$:      MOV      @ (SP),(SP) ;GET ABORT DESTINATION
3695 020662 000207                3$:      RTS      PC
3696
3697                ;      SWAP OLD CYLINDER AND NEW CYLINDER ROUTINE.
3698 020664 010046      ;ONSWAP: MOV      RO,-(SP)    ;STORE RO
3699 020666 013700                MOV      OLDCYL,RO   ;MOVE OLD TO RO
3700 020672 013737 003114 003114      MOV      NEWCYL,OLDCYL ;MOVE NEW TO OLD
3701 020700 010037 003116                MOV      RO,NEWCYL  ;PUT OLD IN NEW
3702 020704 012600                MOV      (SP)+,RO    ;RESTORE RO
3703 020706 000207                RTS      PC
3704

```

GLOBAL SUBROUTINES

```

3706 ; BAD SECTOR FILES VALID CHECK ROUTINE. CHECKS IF BAD SECTOR
3707 ; FILES HAVE BEEN READ AND STORED. IF NOT, REPORT AND FORCE
3708 ; FILES TO LOOK LIKE ALL SECTORS OK.
3709 CKBSVD: TST BSFVAL ;TEST IF BAD SECTORS STORED
3710 BNE 5# ;YES - EXIT
3711 PRINTF #FMT9,#BSNSTR ;REPORT
020716 012746 007550 MOV #BSNSTR,-(SP)
020722 012746 011212 MOV #FMT9,-(SP)
020726 012746 000002 MOV #2,-(SP)
020732 010600 MOV SP,R0
020734 104417 TRAP C#PNTF
020736 062706 000006 ADD #6,SP
3712 020742 PRINTF #FMT5,#BASADD,RLBAS,#DRVNAM,<B,RLDRV+1>
020742 005046 CLR -(SP)
020744 153716 003047 BISR RLDRV+1,(SP)
020750 012746 006152 MOV #DRVNAM,-(SP)
020754 013746 003042 MOV RLBAS,-(SP)
020760 012746 006141 MOV #BASADD,-(SP)
020764 012746 011026 MOV #FMT5,-(SP)
020770 012746 000005 MOV #5,-(SP)
020774 010600 MOV SP,R0
020776 104417 TRAP C#PNTF
021000 062706 000014 ADD #14,SP
3713 021004 PRJNTF #FMT3
021004 012746 011012 MOV #FMT3,-(SP)
021010 012746 000001 MOV #1,-(SP)
021014 010600 MOV SP,R0
021016 104417 TRAP C#PNTF
021020 062706 000004 ADD #4,SP
3714 021024 012737 177777 003512 MOV #-1,SBSFIL ;FORCE FILES TO NO ENTRIES
3715 021032 012737 177777 003706 MOV #-1,FBSFIL
3716 021040 000207 5#: RTS PC
3717
3719 ; READ HEADERS ROUTINE.
3720 XRDHDC: MOV #1,TEMP4 ;SET FLAG TO BYPASS REG STORAGE
3721 BR XRDHDG ;GO DO IT
3722 XRDHD: CLR TEMP4 ;SET FLAG TO SAVE T. AND L. REGS
3723 XRDHDG: MOV R3,-(SP) ;STORE REGISTERS
3724 MOV SSINDEX,R3 ;GET SUBROUTINE INDEX
3725 TST (R3)+ ;BUMP IT FOR NEXT ENTRY
3726 MOV 2(SP),SUBSTK(R3) ;INSERT THIS CALL
3727 SUB #4,SUBSTK(R3) ;ADJUST IT TO CALLING LOCATION
3728 MOV R3,SSINDEX ;STORE IT BACK
3729 MOV R0,-(SP)
3730 MOV R1,-(SP)
3731 MOV R4,-(SP)
3732 MOV #2,ERRSWI ;SET FOR NO ERROR RETURN
3733 TST TEMP4 ;TEST IF REGISTERS TO BE SAVED
3734 BNE 2# ;NO - SKIP
3735 MOV #L.MP+2,R3 ;SET POINTER FOR REGS
3736 MOV #4,R1 ;SET COUNT
3737 1#: MOV -(R3),-(SP) ;SAVE REGISTER
3738 DEC R1 ;DEC COUNT
3739 BNE 1# ;LOOP UNTIL ALL ARE SAVED
3740 2#: JSR PC,RDYCHK ;CHECK DRIVE READY
3741 65#
3742 CLR DONE ;CLEAR INTERRUPT FLAG

```

GLOBAL SUBROUTINES

3743	021160	012701	003050		MOV	#L,CS,R1	;GET ADDRESS OF LOAD REGS	
3744	021164	013711	003046		MOV	RLDRV,(R1)	;LOAD DRIVE NUMBER	
3745	021170	042711	002000		BIC	#BIT10,(R1)	;CLEAR FOR DRIVE 4 7 SPEC D	
3746	021174	052721	000110		BIS	#RDHEAD,(R1)+	;INSERT COMMAND	
3747	021200	005021			CLR	(R1)+	;CLEAR BA	
3748	021202	005021			CLR	(R1)+	;CLEAR DA	
3749	021204	014162	000004		MOV	-(R1),RLDA(R2)	;LOAD RL11 REGS	
3750	021210	014162	000002		MOV	-(R1),RLBA(R2)		
3751	021214	014162	000000		MOV	-(R1),RLCSR(R2)		
3752	021220			3#:	WAITUS	#10.	;WAIT 1MS FOR INTERRUPT	
3753	021232	005737	003022		TST	DONE	;TEST IN INTERRUPT FLAG SET	
3754	021236	001460			BEQ	14#	;NO - SKIP	
3755	021240	032737	000001	003060	5#:	BIT	#DRDYMSK,T.CS	;TEST IF DRIVE READY
3756	021246	001035			BNE	10#	;YES - SKIP	
3757	021250	012703	007760		MOV	#MDRDY,R3	;SET NO READY MESSAGE	
3758	021254	012704	010662		MOV	#CAFDT,R4	;CONDITION OF AFTER DATA XFER	
3759	021260				ERRHRD	10017...ERR5		
	021260	104456			TRAP	C#ERHRD		
	021262	023441			.WORD	10017		
	021264	000000			.WORD	0		
	021266	012156			.WORD	ERR5		
3760	021270	012701	000062		MOV	#50.,R1	;SET WAIT COUNT FOR 5 SECONDS	
3761	021274	004737	016310		4#:	JSR	PC,GSTAT	;GET STATUS
3762	021300	021416			60#			
3763	021302	032737	000001	003060	BIT	#DRDYMSK,T.CS	;TEST IF DRIVE HAS COME READY	
3764	021310	001403			BEQ	11#	;NO - SKIP	
3765	021312	005037	003032		CLR	ERRSWI	;CLEAR ERROR SWITCH	
3766	021316	000411			BR	10#	;SKIP	
3767	021320	005301			11#:	DEC	R1	;DEC WAIT COUNT
3768	021322	001364			BNE	4#	;LOOP UNTIL TIME DONE	
3769	021324	012704	010673		MOV	#C5SEC,R4	;SET CONDITION AFTER 5 SECONDS	
3770	021330				ERRHRD	10014...ERR5		
	021330	104456			TRAP	C#ERHRD		
	021332	023436			.WORD	10014		
	021334	000000			.WORD	0		
	021336	012156			.WORD	ERR5		
3771	021340	000426			BR	60#	;EXIT	
3772	021342	005737	003060		10#:	TST	T.CS	;CHECK FOR ANY ERRORS
3773	021346	100005			BPL	12#	;NO - SKIP	
3774	021350				ERRHRD	10016...ERR6	;REPORT ALL ERRORS	
	021350	104456			TRAP	C#ERHRD		
	021352	023440			.WORD	10016		
	021354	000000			.WORD	0		
	021356	012226			.WORD	ERR6		
3775	021360	000416			BR	60#		
3776	021362	012701	003070		12#:	MOV	#DWRD2,R1	;GET POINTER
3777	021366	016221	000006		MOV	RLMP(R2),(R1)+	;STORE LAST TWO HEADER WORDS	
3778	021372	016221	000006		MOV	RLMP(R2),(R1)+		
3779	021376	000411			BR	65#	;EXIT	
3780	021400	004737	016104		14#:	JSR	PC,WAITIN	;WAIT FOR INTERRUPT
3781	021404	012603			MOV	(SP)+,R3	;GET RESULTS	
3782	021406				ERRHRD	10015...ERR1	;REPORT	
	021406	104456			TRAP	C#ERHRD		
	021410	023437			.WORD	10015		
	021412	000000			.WORD	0		
	021414	011724			.WORD	ERR1		
3783	021416	005037	003032		60#:	CLR	ERRSWI	;CLEAR FOR ERROR ERROR RETURN

GLOBAL SUBROUTINES

```

3784 021422 005737 003142      65$:  TST      TEMP4      ;TEST IF REGISTERS WERE SAVED
3785 021426 001007              BNE      22$      ;NO SKIP
3786 021430 012703 003050      MOV      @L.CS,R3  ;SET POINTER TO RESTORE REGS
3787 021434 012701 000004      MOV      @4,R1    ;SET COUNT
3788 021440 012623      20$:  MOV      (SP)+,(R3)+ ;RESTORE REGISTER
3789 021442 005301              DEC      R1      ;DEC COUNT
3790 021444 001375              BNE      20$      ;LOOP UNTIL ALL ARE RESTORED
3791 021446 162737 000002 003016 22$:  SUB      @2,SSINDX ;REMOVE ENTRY FROM SUBROUT STACK
3792 021454 012604              MOV      (SP)+,R4 ;RESTORE REGS
3793 021456 012601              MOV      (SP)+,R1
3794 021460 012600              MOV      (SP)+,R0
3795 021462 012603              MOV      (SP)+,R3
3796 021464 005737 003032      TST      ERRSWI    ;TEST IF ERROR RETURN
3797 021470 001403              BEQ      99$      ;YES - SKIP
3798 021472 063716 003032      ADD      ERRSWI,(SP) ;ADD IN ERROR RETURN
3799 021476 000207              RTS      PC
3800 021500 017616 000000      99$:  MOV      @ (SP),(SP) ;SET ERROR RETURN ADDRESS
3801 021504 000207              RTS      PC
3802
3804      ;
3805      ; VERIFY HEADERS ROUTINE. COMPARES 40 HEADERS FOR CONTENT AND
3806 021506 010346      ; VERHDR: MOV      R3,-(SP)      ;STORE REGS
3807 021510 013703 003016      MOV      SSINDX,R3 ;GET SUBROUTINE INDEX
3808 021514 005723              TST      (R3)+     ;BUMP IT FOR NEXT ENTRY
3809 021516 016663 000002 002420  MOV      2(SP),SUBSTK(R3) ;INSERT THIS CALL
3810 021524 162763 000004 002420  SUB      @4,SUBSTK(R3) ;ADJUST IT TO CALLING LOCATION
3811 021532 010337 003016      MOV      R3,SSINDX ;STORE IT BACK
3812 021536 010046              MOV      R0,-(SP)
3813 021540 010146              MOV      R1,-(SP)
3814 021542 010446              MOV      R4,-(SP)
3815 021544 010546              MOV      R5,-(SP)
3816 021546 012737 000002 003032  MOV      @2,ERRSWI  ;SET FOR NO ERROR RETURN
3817 021554 052737 000002 003020  BIS      @HDRCMP,OPFLAG ;SET HEADER COMPARE FLAG
3818 021562 005037 003030      CLR      MORECE    ;CLEAR MORE ERRORS FLAG
3819 021566 012704 004102      MOV      @IBUFF,R4 ;SET POINTER TO HEADERS
3820 021572 012705 003132      MOV      @TEMPO,R5 ;SET POINTER TO WORK AREA
3821 021576 005003              CLR      R3      ;CLEAR FOR WORD COUNTER
3822 021600 011415              MOV      (R4),(R5) ;MOVE HDR WORD TO WORK AREA
3823 021602 011401              MOV      (R4),R1  ;PUT WORD IN REG 1
3824 021604 042701 000177      BIC      @177,R1 ;CLEAR ALL BUT CYLINDER
3825 021610 012700 000007      MOV      @7,R0   ;SET SHIFT COUNT
3826 021614 006201      3$:  ASR      R1      ;SHIFT
3827 021616 005300              DEC      R0      ;DEC
3828 021620 001375              BNE      3$      ;LOOP
3829 021622 020137 003116      CMP      R1,NEWCYL ;CHECK IF CYLINDER PART GOOD
3830 021626 001407              BEQ      4$      ;YES - SKIP
3831 021630              ERRHRD 10018,,,ERR10 ;REPORT ERROR
3831 021630              TRAP   C$ERRHRD
3831 021632              .WORD 10018
3831 021634              .WORD 0
3831 021636              .WORD ERR10
3832 021640 005037 003032      CLR      ERRSWI  ;CLEAR FOR ERROR ERROR RETURN
3833 021644 000456              BR      65$
3834 021646 012701 000050      4$:  MOV      @40,R1   ;SET HEADER COUNT
3835 021652 042715 000100      BIC      @HDHSEL,(R5) ;CLEAR HEAD SELECT AND 0 BIT
3836 021656 005737 003126      TST      DESHD   ;ARE WE USING HD 0?
3837 021662 001402              BEQ      5$      ;YES - SKIP

```

GLOBAL SUBROUTINES

```

3838 021664 052715 000100      BIS      #HDHSEL,(R5)      ;INSERT HEAD BIT
3839 021670 005065 000002      5$: CLR      2(R5)        ;CLEAR 2ND WORD OF WORK AREA
3840 021674 021524      6$: CMP      (R5),(R4)+    ;TEST FIRST WORD OK
3841 021676 001410      BEQ      8$              ;YES - SKIP
3842 021700 005744      TST      (R4)            ;ELSE SET POINTER FOR ERROR
3843 021702      ERRHRD  10018,,ERR10   ;REPORT
      021702 104456      TRAP     C$ERHRD
      021704 023442      .WORD   10018
      021706 000000      .WORD   0
      021710 013320      .WORD   ERR10
3844 021712 005037 003032      CLR      ERRSWI          ;CLEAR FOR ERROR RETURN
3845 021716 005724      8$: TST      (R4)+        ;RESET POINTER
3846 021720 005203      INC      R3              ;BUMP WORD COUNTER
3847 021722 005724      TST      (R4)+        ;TEST 2ND WORD IS 0
3848 021724 001410      BEQ      12$            ;YES - SKIP
3849 021726 022544      CMP      (R5)+,(R4)     ;ADJUST POINTERS FOR REPORT
3850 021730      ERRHRD  10018,,ERR10   ;REPORT
      021730 104456      TRAP     C$ERHRD
      021732 023442      .WORD   10018
      021734 000000      .WORD   0
      021736 013320      .WORD   ERR10
3851 021740 005037 003032      CLR      ERRSWI          ;CLEAR FOR ERROR RETURN
3852 021744 024524      12$: CMP     -(R5),(R4)+  ;RESET POINTERS
3853 021746 005724      TST      (R4)+        ;BUMP PAST ECC WORD
3854 021750 005203      INC      R3              ;BUMP WORD COUNTER
3855 021752 005215      INC      (R5)           ;BUMP SECTOR OF EXPECTED HEADER
3856 021754 011500      MOV      (R5),R0        ;MOVE EXPECTED HDR TO R0
3857 021756 042700 177700      BIC      #+CHDSEC,R0    ;CLEAR ALL BUT SECTOR
3858 021762 022700 000050      CMP      #40.,R0       ;TEST IF AT SECTOR 40
3859 021766 001002      BNE      15$            ;NO - SKIP
3860 021770 042715 000077      BIC      #HDSEC,(R5)    ;CLEAR SECTOR TO 0
3861 021774 005203      15$: INC      R3          ;BUMP HDR WORD COUNTER
3862 021776 005301      DEC      R1              ;DEC HEADER COUNT
3863 022000 001335      BNE      6$              ;LOOP IF NOT YET DONE
3864 022002 162737 000002 003016 65$: SUB      #2,SSINDEX      ;REMOVE ENTRY FROM SUBROUT STACK
3865 022010 012605      MOV      (SP)+,R5       ;RESTORE REGISTERS
3866 022012 012604      MOV      (SP)+,R4
3867 022014 012601      MOV      (SP)+,R1
3868 022016 012600      MOV      (SP)+,R0
3869 022020 012603      MOV      (SP)+,R3
3870 022022 005737 003032      TST      ERRSWI          ;TEST IF ERROR RETURN
3871 022026 001403      BEQ      99$            ;YES - SKIP
3872 022030 063716 003032      ADD      ERRSWI,(SP)    ;ADD IN ERROR RETURN
3873 022034 000207      RTS      PC
3874 022036 017616 000000      99$: MOV      @ (SP),(SP) ;SET ERROR RETURN ADDRESS
3875 022042 000207      RTS      PC
3876
3878      ; POSITION HEAD BIT FROM HEADER OR MULTIPURPOSE REGISTER TO LSB.
3879 022044 013705 003066      POSHW1: MOV      HDWRD1,R5 ;START FOR POSITION HD BIT IN WD 1
3880 022050 000402      BR      POSHDO          ;SKIP
3881 022052 013705 003066      POSHSB: MOV      T.MP,R5 ;START FOR POSITION HD BIT IN MP
3882 022056 010146      POSHDO: MOV      R1,(SP)  ;STORE R1
3883 022060 042705 177677      BIC      #+CHSSTAT,R5  ;CLEAR ALL BUT HEAD SEL BIT
3884 022064 012701 000006      MOV      #6,R1          ;SET SHIFT COUNT
3885 022070 006205      1$: ASR      R5           ;SHIFT FOR RIGHT JUSTIFY
3886 022072 005301      DEC      R1
3887 022074 001375      BNE      1$

```


GLOBAL SUBROUTINES

```

3888 022076 012601      MOV      (SP)+,R1      ;RESTORE R1
3889 022100 000207      RTS       PC          ;RETURN
3890
3891      ;          WAIT FOR READY ROUTINE. DURATION OF WAIT PASSED TO THE ROUTINE
3892      ;          FROM THE CALLING ROUTINE IN R1.
3893 022102 010346      RDYWAIT:  MOV      R3,(SP)      ;STORE R3
3894 022104 013703 003016  MOV      SSINDX,R3     ;GET SUBROUTINE INDEX
3895 022110 005723      TST      (R3)         ;BUMP IT FOR NEXT ENTRY
3896 022112 016663 000002 002420  MOV      2(SP),SUBSTK(R3) ;INSERT THIS CALL
3897 022120 162763 000004 002420  SUB      #4,SUBSTK(R3)  ;ADJUST IT TO CALLING LOCATION
3898 022126 010337 003016  MOV      R3,SSINDX     ;STORE IT BACK
3899 022132 010046      MOV      R0,-(SP)
3900 022134 010146      MOV      R1,(SP)
3901 022136 010446      MOV      R4,-(SP)
3902 022140 012737 000002 003032  MOV      #2,ERRSWI     ;SET FOR NO ERROR RETURN
3903 022146 004737 016310 54:    JSR      PC,GSTAT      ;GET DRIVE STATUS
3904 022152 022322      10#
3905 022154 032737 000001 003060  BIT      #DRDYMSK,T.CS ;CHECK IF READY
3906 022162 001061      BNE     9#            ;YES - SKIP
3907 022164 005301      DEC     R1            ;DEC WAIT COUNT
3908 022166 001406      BEQ     7#            ;SKIP IF 0
3909 022170      WAITUS  #1
3910 022202 000761      BR      5#
3911 022204 012703 007760 7#:    MOV      #MDRDY,R3     ;SET NAME MESSAGE PTR
3912 022210 104456      ERRHRD 10020,,ERR3     ;REPORT READY ERROR
3913 022220 012701 000062      TRAP   C#ERRHRD
3914 022224 004737 016310 6#:    .WORD 10020
3915 022230 022322      .WORD 0
3916 022232 032737 000001 003060  .WORD  ERR3
3917 022240 001016      MOV     #50,R1        ;SET WAIT COUNT FOR 5 SECONDS
3918 022242      JSR    PC,GSTAT      ;GET DRIVE STATUS
3919 022254 005301      10#
3920 022256 001362      BIT    #DRDYMSK,T.CS ;TEST IF DRIVE READY
3921 022260 012704 010673 8#:    BNE    8#            ;YES - SKIP
3922 022264 104456      WAITMS #1            ;WAIT 100 MS
3923 022274 000410      DEC    R1            ;DEC WAIT COUNT
3924 022276 032737 100000 003060 8#:    BNE    6#            ;LOOP UNTIL TIME DONE
3925 022304 001406      MOV    #C5SEC,R4     ;SET CONDITION AFTER 5 SECS
3926 022306 104456      ERRHRD 10021,,ERR5
3927 022316 005337 003254 11#:  TRAP   C#ERRHRD
3928 022322 005037 003032 10#:  .WORD 10021
3929 022326 162737 000002 003016 9#:  .WORD 0
3930 022334 012604      .WORD  ERR5
3931 022336 012601      BR     11#           ;EXIT
3932 022340 012600      BIT    #ANYERR,T.CS ;TEST IF ANY ERROR SET
                        BEQ    10#           ;NO - SKIP
                        ERRHRD 10022,,ERR6 ;REPORT ALL ERRORS
                        TRAP   C#ERRHRD
                        .WORD 10022
                        .WORD 0
                        .WORD  ERR6
                        DEC    ERRCNT       ;DEC FOR DOUBLE ERROR REPORT
                        CLR    ERRSWI      ;CLEAR FOR ERROR ERROR RETURN
                        SUB    #2,SSINDX    ;REMOVE ENTRY FROM SUBROUT STACK
                        MOV    (SP)+,R4     ;RESTORE REGISTERS
                        MOV    (SP)+,R1
                        MOV    (SP)+,R0

```

GLOBAL SUBROUTINES

```

3933 022342 012603      MOV      (SP)+,R3      ;RESTORE R3
3934 022344 005737 003032  TST      ERRSWI      ;TEST IF ERROR RETURN
3935 022350 001403      BEQ      99$         ;YES - SKIP
3936 022352 063716 003032  ADD      ERRSWI,(SP)  ;ADD IN ERROR RETURN
3937 022356 000207      RTS      PC
3938 022360 017616 000000  99$:    MOV      @ (SP),(SP) ;SET ERROR RETURN ADDRESS
3939 022364 000207      RTS      PC
3940
3941      ; GET POSITION ROUTINE. READS A HEADER FROM CURRENT CYLINDER
3942      ; (WHERE IT IS PRESENTLY POSITIONED) AND STORES CYLINDER
3943      ; NUMBER IN CURCYL.
3944 022366 010346      GETPOS: MOV      R3,-(SP)    ;STORE REGISTERS
3945 022370 013703 003016  MOV      SSINDEX,R3  ;GET SUBROUTINE INDEX
3946 022374 005723      TST      (R3)+       ;BUMP IT FOR NEXT ENTRY
3947 022376 016663 000002 002420  MOV      2(SP),SUBSTK(R3) ;INSERT THIS CALL
3948 022404 162763 000004 002420  SUB      @4,SUBSTK(R3) ;ADJUST IT TO CALLING LOCATION
3949 022412 010337 003016  MOV      R3,SSINDEX  ;STORE IT BACK
3950 022416 010046      MOV      R0,-(SP)
3951 022420 010546      MOV      R5,(SP)
3952 022422 004737 021052  JSR      PC,XRDHD    ;DO READ HEADER
3953 022426 022456      65$
3954 022430 013703 003066  MOV      HDWRD1,R3   ;GET HEADER WORD
3955 022434 012705 000007  MOV      @7,R5       ;SET SHIFT COUNT
3956 022440 006203      4$:    ASR      R3          ;SHIFT TO RIGHT JUSTIFY
3957 022442 005305      DEC      R5
3958 022444 001375      BNE      4$
3959 022446 042703 177000  BIC      @177000,R3  ;STORE AS CURRENT CYLINDER
3960 022452 010337 003120  MOV      R3,CURCYL  ;REMOVE ENTRY FROM SUBROUT STACK
3961 022456 162737 000002 003016  65$:    SUB      @2,SSINDEX
3962 022464 012605      MOV      (SP)+,R5   ;RESTORE REGISTERS
3963 022466 012600      MOV      (SP)+,R0
3964 022470 012603      MOV      (SP)+,R3
3965 022472 005737 003032  TST      ERRSWI      ;TEST IF ERROR RETURN
3966 022476 001403      BEQ      99$         ;YES - SKIP
3967 022500 063716 003032  ADD      ERRSWI,(SP) ;ADD IN ERROR RETURN
3968 022504 000207      RTS      PC
3969 022506 017616 000000  99$:    MOV      @ (SP),(SP) ;SET ERROR RETURN ADDRESS
3970 022512 000207      RTS      PC
3971
3973      ; VERIFY POSITION ROUTINE. READS A HEADER (USING GETPOS) AND
3974      ; CHECKS HEADS ARE POSITIONED AT NEW CYLINDER (CURCYL = NEWCYL).
3975 022514 010346      VERPOS: MOV      R3,-(SP)    ;STORE R3
3976 022516 013703 003016  MOV      SSINDEX,R3  ;GET SUBROUTINE INDEX
3977 022522 005723      TST      (R3)+       ;BUMP IT FOR NEXT ENTRY
3978 022524 016663 000002 002420  MOV      2(SP),SUBSTK(R3) ;INSERT THIS CALL
3979 022532 162763 000004 002420  SUB      @4,SUBSTK(R3) ;ADJUST IT TO CALLING LOCATION
3980 022540 010337 003016  MOV      R3,SSINDEX  ;STORE IT BACK
3981
3982 022544 012737 000002 003032  MOV      @2,ERRSWI   ;SET FOR NO ERROR RETURN
3983 022552 004737 022366  JSR      PC,GETPOS   ;GET POSITION
3984 022556 022604      65$
3985 022560 023737 003116 003120  CMP      NEWCYL,CURCYL ;CHECK IF CURRENT CYL IS NEW CYL
3986 022566 001406      BEQ      1$         ;YES - SKIP
3987 022570      ERRHRD 10022,,ERRB
      022570 104456  TRAP   C#ERRHD
      022572 023446  .WORD 10022
      022574 000000  .WORD 0

```

GLOBAL SUBROUTINES

```

022576 013160
3988 022600 005037 003032          .WORD  ERR8
                                     CLR      ERRSWI      ;CLEAR FOR ERROR ERROR RETURN
3989 022604
3990 022604 162737 000002 003016 1$:  SUB      @2,SSINDX      ;REMOVE ENTRY FROM SUBROUT STACK
                                     MOV      (SP)+,R3      ;RESTORE R3
3991 022612 012603
3992 022614 005737 003032          TST      ERRSWI      ;TEST IF ERROR RETURN
3993 022620 001403
3994 022622 063716 003032          BEQ      99$
                                     ADD      ERRSWI,(SP)    ;ADD IN ERROR RETURN
3995 022626 000207
3996 022630 017616 000000 99$:  MOV      @ (SP),(SP)    ;SET ERROR RETURN ADDRESS
3997 022634 000207
3998
4000          ; READ ALL HEADERS ROUTINE. 40 HEADERS ARE READ AND STORED
4001          ; IN Ibuff.
RDALHD:  MOV      R3,-(SP)      ;STORE REGISTERS
                                     MOV      SSINDX,R3      ;GET SUBROUTINE INDEX
                                     TST      (R3)+      ;BUMP IT FOR NEXT ENTRY
4002 022636 010346
4003 022640 013703 003016          MOV      2(SP),SUBSTK(R3) ;INSERT THIS CALL
4004 022644 005723
4005 022646 016663 000002 002420  SUB      @4,SUBSTK(R3)    ;ADJUST IT TO CALLING LOCATION
4006 022654 162763 000004 002420  MOV      R3,SSINDX      ;STORE IT BACK
4007 022662 010337 003016
4008 022666 010046
4009 022670 010146
4010 022672 010446
4011 022674 012737 000002 003032  MOV      @2,ERRSWI      ;SET FOR NO ERROR RETURN
4012 022702 012701 000050          MOV      @40.,R1      ;SET HEADER COUNT
4013 022706 052737 100000 003020  BIS      @HDR40,OPFLAG   ;SET 40 HDR OP FLAG
4014 022714 012703 004102          MOV      @IBUFF,R3      ;SET POINTER TO STORE HDRS
4015 022720 013704 003042          MOV      RLBAS,R4      ;GET BASE ADDRESS
4016 022724 062704 000006          ADD      @RLMP,R4      ;MAKE IT POINT TO MP REG
4017 022730 012737 000010 003050  MOV      @10,L.CS      ;LOAD FOR READ HEADER, NO INTERRUPT
4018 022736 053737 003046 003050  BIS      RLDRV,L.CS     ;INSERT DRIVE NUMBER
4019 022744 042737 002000 003050  BIC      @BIT10,L.CS    ;CLEAR FOR DRIVE 4 - 7 SPEC'D
4020 022752 005037 003052          CLR      L.BA          ;CLEAR BA
4021 022756 005037 003054          CLR      L.DA          ;CLEAR DA
4022 022762 005737 003126          TST      DESHD        ;TEST IF HEAD 0
4023 022766 001403
4024 022770 052737 000020 003054  BEQ      3$
                                     BIS      @MSEL,L.DA     ;ELSE INSERT HEAD 0
4025 022776 013762 003054 000004 3$:  MOV      L.DA,RLDA(R2)   ;LOAD RLDA REG
4026 023004 013762 003052 000002  MOV      L.BA,RLBA(R2)   ;LOAD RLBA
4027 023012 032762 000200 000000  BIT      @CRDYMSK,RLCS(R2) ;TEST IF CONTROLLER READY
4028 023020 001003
4029 023022 004737 020324          BNE      6$
                                     JSR      PC,RDYCHK     ;ELSE CHECK READY
4030 023026 023144
4031 023030 013762 003050 000000 6$:  MOV      L.CS,RLCS(R2)   ;LOAD RLCS REG
4032 023036 012700 077777          MOV      @77777,R0     ;SET COUNT FOR WAIT
4033 023042 032762 000200 000000 7$:  BIT      @CRDYMSK,RLCS(R2) ;CHECK THAT OPERATION COMPLETED
4034 023050 001016
4035 023052 005300
4036 023054 001372
4037 023056 004737 016052          BNE      8$
                                     DEC      R0            ;DEC COUNT
4038 023062 004737 016104          BNE      7$
                                     JSR      PC,READRL    ;ELSE GET ALL REGISTERS
4039 023066 012603
4040 023070          JSR      PC,WAITIN     ;ELSE WAIT FOR TIMEOUT
                                     MOV      (SP)+,R3      ;GET RESULT MESSAGE POINTER
                                     ERRHRD 10025.,ERR1
                                     TRAP   C$ERRHRD
                                     .WORD 10025
                                     .WORD 0
                                     .WORD ERR1
023070 104456
023072 023451
023074 000000
023076 011724

```

GLOBAL SUBROUTINES

```

4041 023100 005037 003032      CLR      ERRSWI      ;CLEAR FOR ERROR RETURN
4042 023104 000417              BR        65#
4043 023106 005737 003060      8#:     TST      T.CS      ;TEST FOR ANY ERRORS
4044 023112 100007              BPL      12#         ;NO SKIP
4045 023114              ERRHRD  10026.,ERR6
      023114 104456      TRAP    CERRHRD
      023116 023452      .WORD  10026
      023120 000000      .WORD  0
      023122 012226      .WORD  ERR6
4046 023124 005037 003032      CLR      ERRSWI      ;CLEAR FOR ERROR RETURN
4047 023130 000405              BR        65#
4048 023132 011423      12#:   MOV      (R4),(R3)+ ;STORE HEADER WORDS
4049 023134 011423      MOV      (R4),(R3)+
4050 023136 011423      MOV      (R4),(R3)+
4051 023140 005301              DEC      R1          ;DEC HEADER COUNT
4052 023142 001332      BNE     6#
4053 023144 162737 000002 003016 65#:   SUB      #2,SSINDEX ;REMOVE ENTRY FROM SUBROUT STACK
4054 023152 012604      MOV      (SP)+,R4    ;RESTORE REGISTERS
4055 023154 012601      MOV      (SP)+,R1
4056 023156 012600      MOV      (SP)+,R0
4057 023160 012603      MOV      (SP)+,R3
4058 023162 005737 003032      TST      ERRSWI      ;TEST IF ERROR RETURN
4059 023166 001403      BEQ     99#         ;YES - SKIP
4060 023170 063716 003032      ADD     ERRSWI,(SP) ;ADD IN ERROR RETURN
4061 023174 000207              RTS      PC
4062 023176 017616 000000      99#:   MOV      @8(SP),(SP) ;SET ERROR RETURN ADDRESS
4063 023202 000207              RTS      PC
4064
4066      ; GENERATE DATA ROUTINE. PATTERN TO BE GENERATED IS GIVEN
4067      ; IN THE WORD FOLLOWING THE CALL. 128 WORDS ARE GENERATED
4068      ; IN OBUFF.
4069 023204 010146      DATGEN: MOV     R1,-(SP)    ;STORE REGISTERS
4070 023206 010346      MOV     R3,-(SP)
4071 023210 010446      MOV     R4,-(SP)
4072 023212 012701 004502      MOV     #OBUFF,R1    ;SET POINTER TO OBUFF
4073 023216 012504      MOV     (R5)+,R4     ;GET DATA PATTERN SELECTOR
4074 023220 006304      ASL    R4            ;ADJUST IT FOR INDEXING
4075 023222 016403 002374      MOV     PATTBL(R4),R3 ;GET ADDRESS OF PATTERN
4076 023226 011321      MOV     (R3),(R1)+   ;MOVE FIRST PATTERN WORD
4077 023230 001421      BEQ    5#           ;SKIP IF PATTERN IS 0
4078 023232 021327 177777      CMP     (R3),#-1     ;CHECK IF PATTERN IS ALL 1'S
4079 023236 001416      BEQ    5#           ;YES - SKIP
4080 023240 020427 000010      CMP     R4,#8.      ;TEST IF PATTERN 5
4081 023244 001403      BEQ    3#           ;YES - SKIP
4082 023246 020427 000020      CMP     R4,#16.     ;CHECK IF PATTERN 9 OR 10
4083 023252 002413      BLT    6#           ;NO - SKIP
4084 023254 005723      3#:    TST     (R3)+     ;BUMP SOURCE POINTER
4085 023256 012321      MOV     (R3)+,(R1)+ ;MOVE TWO MORE WORDS FROM SOURCE
4086 023260 012321      MOV     (R3)+,(R1)+
4087 023262 012704 000015      MOV     #13.,R4     ;SET COUNT
4088 023266 012703 004502      MOV     #OBUFF,R3   ;RESET POINTER
4089 023272 000406      BR     8#
4090 023274 012703 004502      5#:    MOV     #OBUFF,R3   ;ELSE SET OBUFF AS PATTERN SOURCE
4091 023300 000401      BR     7#           ;GO TO FILL
4092 023302 005723      6#:    TST     (R3)+     ;BUMP SOURCE POINTER
4093 023304 012704 000017      7#:    MOV     #15.,R4   ;SET MOVE COUNT
4094 023310 012321      8#:    MOV     (R3)+,(R1)+ ;MOVE 15 WORDS INTO BUFFER

```

GLOBAL SUBROUTINES

```

4095 023312 005304          DEC      R4
4096 023314 001375          BNE     8$
4097 023316 012703 004502   MOV     @OBUF,R3          ;SET SOURCE TO TOP OF OBUF
4098 023322 012704 000160   MOV     @112.,R4        ;SET COUNT FOR REST OF BUFFER
4099 023326 012321          10$:   MOV     (R3)+,(R1)+     ;REPEAT PATTERN IN BUFFER
4100 023330 005304          DEC     R4
4101 023332 001375          BNE    10$
4102 023334 012604          MOV     (SP)+,R4        ;RESTORE REGISTERS
4103 023336 012603          MOV     (SP)+,R3
4104 023340 012601          MOV     (SP)+,R1
4105 023342 000205          RTS     R5              ;RETURN
4106
4107
4108
4109 023344 010346          ; DATA COMPARE ROUTINE. COMPARES THE CONTENTS OF Ibuff AND Obuff.
; ERROR REPORTING IS LIMITED BY SOFTWARE PARAMETER.
; DATCOM: MOV     R3,-(SP)          ;STORE R3
4110 023346 013703 003016   MOV     SSINDX,R3       ;GET SUBROUTINE STACK INDEX
4111 023352 005723          TST    (R3)+           ;BUMP INDEX TO NEXT ENTRY
4112 023354 016663 000002 002420   MOV     2(SP),SUBSTK(R3) ;INSERT THIS CALL
4113 023362 162763 000004 002420   SUB     #4,SUBSTK(R3)   ;ADJUST IT TO CALLING LOCATION
4114 023370 010337 003016   MOV     R3,SSINDX      ;STORE IT BACK
4115 023374 010146          MOV     R1,-(SP)       ;STORE OTHER REGISTERS
4116 023376 010446          MOV     R4,-(SP)
4117 023400 010546          MOV     R5,-(SP)
4118 023402 052737 000001 003020   BIS     @DATACMP,OPFLAG ;SET DATA COMPARE FLAG
4119 023410 005037 003030   CLR     MORECE         ;CLEAR MORE ERROR FLAG
4120 023414 012705 004502   MOV     @OBUF,R5       ;SET POINTERS TO DATA FOR COMPARE
4121 023420 012704 004102   MOV     @IBUF,R4
4122 023424 012703 000001   MOV     #1,R3          ;SET WORD COUNTER
4123 023430 012701 000200   MOV     #128.,R1       ;SET COMPARE COUNT
4124 023434 022425          5$:   CMP     (R4)+,(R5)+    ;COMPARE DATA
4125 023436 001052          BNE    10$            ;ERROR - SKIP TO REPORT
4126 023440 005203          7$:   INC     R3            ;BUMP WORD COUNT
4127 023442 005301          DEC     R1            ;DEC COMPARE COUNT
4128 023444 001373          BNE    5$            ;LOOP IF NOT 0
4129 023446 042737 000001 003020  9$:   BIC     @DATACMP,OPFLAG ;CLEAR DATA COMPARE FLAG
4130 023454 005737 003032   TST    ERRSWI         ;TEST IF ANY COMPARE ERRORS
4131 023460 001021          BNE    15$           ;NO - SKIP
4132 023462 012701 000200   MOV     #128.,R1       ;SET REPORT VALUE
4133 023466          PRINTB @FMT27,@TCERR,MORECE,@RESE6,R1
4134 023466 010146          MOV     R1,-(SP)
4135 023470 012746 010577   MOV     @RESE6,-(SP)
4136 023474 013746 003030   MOV     MORECE,-(SP)
4137 023500 012746 007624   MOV     @TCERR,-(SP)
4138 023504 012746 011673   MOV     @FMT27,-(SP)
4139 023510 012746 000005   MOV     #5,-(SP)
4140 023514 010600          MOV     SP,R0
4141 023516 104414          TRAP   C:PNTB
4142 023520 062706 000014          ADD     #14,SP
4143 023524 162737 000002 003016 15$:   SUB     #2,SSINDX      ;REMOVE ENTRY FROM SUBROUT STACK
4144 023532 012605          MOV     (SP)+,R5      ;RESTORE REGS
4145 023534 012604          MOV     (SP)+,R4
4146 023536 012601          MOV     (SP)+,R1
4147 023540 012603          MOV     (SP)+,R3
4148 023542 005737 003032   TST    ERRSWI         ;TEST IF ERROR RETURN
4149 023546 001403          BEQ    99$           ;YES - SKIP
4150 023550 063716 003032   ADD     ERRSWI,(SP)   ;ADD IN ERROR RETURN
4151 023554 000207          RTS     PC

```

GLOBAL SUBROUTINES

```

4143 023556 017616 000000      99$:  MOV      8(SP),(SP)      ;SET ERROR RETURN ADDRESS
4144 023562 000207              RTS      PC
4145 023564 023737 003030 013570 10$:  CMP      MORECE,DCLIMW  ;TEST IF COMPARE ERRORS LIMIT EXCEEDED
4146 023572 002011              BGE      13$            ;YES - SKIP
4147 023574 024445              CMP      -(R4),(R5)    ;SET PTRS BACK TO ERROR WORDS
4148 023576              ERRHRD  10035,,,ERR10 ;REPORT ERROR
              023576 104456      TRAP     C:ERRHRD
              023600 023463      .WORD   10035
              023602 000000      .WORD   0
              023604 013320      .WORD   ERR10
4149 023606 005037 003032      CLR      ERRSWI        ;CLEAR ERROR SWITCH
4150 023612 022425              CMP      (R4)*,(R5)*  ;BUMP PTRS PAST ERROR WORDS
4151 023614 000711              BR       7$            ;DO NEXT COMPARE
4152 023616 005237 003030      13$:  INC      MORECE        ;BUMP ERROR COUNTER
4153 023622 000706              BR       7$            ;DO NEXT COMPARE
4154
4155              ;      WRITE AND READ DATA ROUTINE.
4156
4157 023624 012737 177777 003134 XWRITT: MOV      0-1,TEMP1    ;SET SPECIAL WRITE FOR TIMING FLAG
4158 023632 000402              BR       XWRIT1
4159 023634 005037 003134      XWRITE: CLR      TEMP1    ;CLEAR SPECIAL WRITE FLAG
4160 023640 012737 000112 003150 XWRIT1: MOV      @WTDATA,TEMP7 ;SET FOR WRITE
4161 023646 023737 002316 003120      CMP      HLMTW,CURCYL ;TEST IF CYLINDER 255 (BAD SEC)
4162 023654 001006              BNE      1$            ;NO - SKIP
4163 023656 005737 003126      TST      DESHD        ;TEST IF HEAD 1 (BAD SECTOR FILES)
4164 023662 001403              BEQ      1$            ;NO - SKIP
4165 023664 052737 004000 003020      BIS      @BADADD,OPFLAG ;SET BAD ADDRESS FLAG
4166 023672 000403              BR       XREADG       ;SKIP TO EXECUTE
4167 023674 012737 000114 003150 XREAD:  MOV      @RDDATA,TEMP7 ;SET FOR READ
4168 023702 010346      XREADG: MOV      R3,-(SP)   ;STORE R3
4169 023704 013703 003016      MOV      SSINDX,R3    ;SET SUBROUTINE INDEX
4170 023710 005723              TST      (R3)*        ;BUMP TO NEXT STACK ENTRY
4171 023712 016663 000002 002420      MOV      2(SP),SUBSTK(R3) ;INSERT THIS CALL
4172 023720 162763 000004 002420      SUB      @4,SUBSTK(R3) ;ADJUST TO POINT TO CALL
4173 023726 010337 003016      MOV      R3,SSINDX   ;STORE IT BACK
4174 023732 010046              MOV      R0,-(SP)
4175 023734 010146              MOV      R1,-(SP)    ;STORE OTHER REGISTERS
4176 023736 010446              MOV      R4,-(SP)
4177 023740 004737 020324      JSR      PC,RDYCHK    ;CHECK IF DRIVE READY
4178 023744 024332              65$
4179 023746 012703 003050      MOV      @L_CS,R3     ;GET ADDRESS OF LOAD REGS
4180 023752 013713 003150      MOV      TEMP7,(R3)   ;SET COMMAND
4181 023756 053713 003046      BIS      RLDIV,(R3)   ;INSERT DRIVE NUMBER
4182 023762 042713 002000      BIC      @BIT10,(R3)  ;CLEAR FOR DRIVE 4 - 7 SPEC'D
4183 023766 032723 000004      BIT      @BIT2,(R3)* ;TEST IF WRITE DATA
4184 023772 001403              BEQ      3$            ;YES - SKIP
4185 023774 012723 004102      MOV      @IBUFF,(R3)* ;ELSE SET BA FOR READ
4186 024000 000402              BR       4$
4187 024002 012723 004502      3$:  MOV      @OBUFF,(R3)* ;SET BA FOR WRITE
4188 024006 013713 003120      4$:  MOV      CURCYL,(R3)  ;GET CURRENT CYLINDER
4189 024012 012704 000007              MOV      @7,R4        ;ALIGN IT IN DA
4190 024016 006313      5$:  ASL      (R3)
4191 024020 005304              DEC      R4
4192 024022 001375              BNE      5$
4193 024024 005737 003126      TST      DESHD        ;TEST IF HEAD 0
4194 024030 001402              BEQ      7$            ;YES - SKIP
4195 024032 052713 000100      BIS      @HMSK,(R3)   ;SET FOR HEAD 1

```

GLOBAL SUBROUTINES

```

4196 024036 053723 003130      7$:  BIS      DESSEC,(R3).      ;INSERT DESIRED SECTOR
4197 024042 012713 177600      MOV      #177600,(R3)    ;INSERT WORD COUNT
4198 024046 005737 003134      TST      TEMP1          ;CHECK IF SPECIAL WRITE FOR TIMING
4199 024052 001402                BEQ      8$              ;NO SKIP
4200 024054 012713 177777      MOV      #177777,(R3)    ;ELSE SET FOR 1 WORD TRANSFER
4201 024060 032737 004000      003020 8$:  BIT      #BADADD,OPFLAG ;TEST IF BAD ADDRESS FLAG SET
4202 024066 001414                BEQ      2$              ;NO - SKIP
4203 024070 042737 173777      063020 BIC      #+CBADADD,OPFLAG ;CLEAR ALL BUT THIS FLAG
4204 024076 012703 010501      MOV      #MWRTAB,R3     ;SET RESULT MESSAGE POINTER
4205 024102      ERRHRD 10032...ERR1
      024102 104456      TRAP   C$ERHRD
      024104 023460      .WORD 10032
      024106 000000      .WORD 0
      024110 011724      .WORD ERR1
4206 024112 005037 003020      CLR      OPFLAG        ;CLEAR ALL FLAGS
4207 024116 000503                BR       64$
4208 024120 065037 003022      2$:  CLR      DONE          ;CLEAR INTERRUPT FLAG
4209 024124 005737 003134      TST      TEMP1          ;CHECK IF SPECIAL WRITE FLAG SET
4210 024130 001100                BNE      65$            ;YES - DO NOT START WRITE
4211 024132 011362 000006      MOV      (R3),RLMP(R2)  ;LOAD RL REGS
4212 024136 014362 000004      MOV      -(R3),RLDA(R2)
4213 024142 014362 000002      MOV      -(R3),RLBA(R2)
4214 024146 014362 000000      MOV      -(R3),RLCS(R2)
4215 024152                10$:  WAITUS  #3000.         ;WAIT 300MS FOR INTERRUPT
4216 024164 005737 003022      TST      DONE          ;CHECK IF INTERRUPT
4217 024170 001010                BNE      14$            ;YES - SKIP
4218 024172 004737 016104      JSR      PC,WAITIN      ;WAIT FOR INTERRUPT
4219 024176 012603      MOV      (SP)+,R3      ;GET RESULT MESSAGE
4220 024200      ERRHRD 10030...ERR1
      024200 104456      TRAP   C$ERHRD
      024202 023456      .WORD 10030
      024204 000000      .WORD 0
      024206 011724      .WORD ERR1
4221 024210 000446                BR       64$
4222 024212 032737 000001      003060 14$:  BIT      #DRDYMSK,T.CS ;TEST IF DRIVE READY
4223 024220 001033                BNE      20$            ;YES - SKIP
4224 024222 012703 007760      MOV      #MDRDY,R3     ;SET RESULT MESSAGE
4225 024226 012704 010662      MOV      #CAFDT,R4     ;CONDITION AFTER DATA XFER
4226 024232      ERRHRD 10032...ERR5
      024232 104456      TRAP   C$ERHRD
      024234 023460      .WORD 10032
      024236 000000      .WORD 0
      024240 012156      .WORD ERR5
4227 024242 012701 000062      MOV      #50.,R1       ;SET WAIT COUNT FOR 5 SECDS
4228 024246 004737 016310      17$:  JSR      PC,GSTAT      ;GET DRIVE STATUS
4229 024252 024326                64$
4230 024254 032737 000001      003060 BIT      #DRDYMSK,T.CS ;TEST IF DRIVE READY NOW
4231 024262 001012                BNE      20$            ;YES - SKIP
4232 024264 005301                DEC      R1             ;DEC WAIT COUNT
4233 024266 001367                BNE      17$            ;LOOP IF NOT TIME DONE
4234 024270 012704 010673      MOV      #C5SEC,R4     ;SET CONDITION 5 SECONDS
4235 024274      ERRHRD 10033...ERR5
      024274 104456      TRAP   C$ERHRD
      024276 023461      .WORD 10033
      024300 000000      .WORD 0
      024302 012156      .WORD ERR5
4236 024304 005037 003032      CLR      ERRSWI        ;CLEAR ERROR SWITCH
    
```

GLOBAL SUBROUTINES

```

4237 024310 005737 003060      20#: TST      T.CS          ;CHECK IF ANY ERROR
4238 024314 100006                BPL      65#          ;NO - SKIP
4239 024316                ERRHRD  10031...ERR6
      024316 104456                TRAP    C1ERRHRD
      024320 023457                WORD   10031
      024322 000000                .WORD  0
      024324 012226                .WORD  ERR6
4240 024326 005037 003032      64#: CLR      ERRSWI        ;CLEAR ERROR SWITCH
4241 024332 162737 000002 003016 65#: SUB      #2,SSINDEX    ;REMOVE ENTRY FROM SUBROUT STACK
4242 024340 012604                MOV     (SP)+,R4      ;RESTORE REGISTERS
4243 024342 012601                MOV     (SP)+,R1
4244 024344 012600                MOV     (SP)+,R0
4245 024346 012603                MOV     (SP)+,R3
4246 024350 005737 003032                TST     ERRSWI        ;TEST IF ERROR RETURN
4247 024354 001403                BEQ     99#          ;YES - SKIP
4248 024356 063716 003032                ADD     ERRSWI,(SP)   ;ELSE ADD IN ERROR RETURN
4249 024362 000207                RTS     PC
4250 024364 017616 000000      99#: MOV     @ (SP),(SP)   ;ADJUST FOR ERROR RETURN
4251 024370 000207                RTS     PC
4252
4253 ;
4254 ;
4255 024372 010046      BSCHK: MOV     R0,-(SP)      ;STORE REGISTERS
4256 024374 010146      MOV     R1,-(SP)
4257 024376 010346      MOV     R3,-(SP)
4258 024400 005037 003034      CLR     BSFLAG        ;CLEAR FLAG
4259 024404 012703 003706      MOV     #FBSFIL,R3    ;GET POINTER TO FACTORY FILE
4260 024410 022713 177777      CMP     #-1,(R3)      ;CHECK IF ALL ONES
4261 024414 001005                BNE     4#           ;NO SKIP TO TEST
4262 024416 012703 003512      2#: MOV     #SBSFIL,R3  ;ELSE SET POINTER TO SOFTWARE FILE
4263 024422 022713 177777      CMP     #-1,(R3)      ;CHECK IF ALL ONES
4264 024426 001431                BEQ     20#          ;YES - EXIT
4265 024430 013700 003116      4#: MOV     NEWCYL,R0    ;BUILD HEADER OF ADDRESS IN QUESTION
4266 024434 012701 000007      MOV     #7,R1         ;POSITION CYLINDER
4267 024440 006300      5#: ASL     R0
4268 024442 005301      DEC     R1
4269 024444 001375      BNE     5#
4270 024446 005737 003126      TST     DESHD         ;CHECK IF HEAD 0
4271 024452 001402      BEQ     7#           ;YES - SKIP
4272 024454 052700 000100      BIS     #BIT6,R0      ;INSERT HEAD 1
4273 024460 053700 003130      7#: BIS     DESSEC,R0   ;INSERT SECTOR
4274 024464 022300      8#: CMP     (R3)+,R0    ;CHECK THIS WORD IN FILE
4275 024466 001402      BEQ     12#          ;YES - EXIT,ERROR
4276 024470 101005      BHI     15#          ;EXIT- NO ERROR
4277 024472 000774      BR      8#
4278 024474 012737 000001 003034 12#: MOV     #1,BSFLAG    ;SET ERROR FLAG
4279 024502 000403      BR      20#         ;GO TO EXIT
4280 024504 020327 003706      15#: CMP     R3,#FBSFIL  ;DONE BOTH FILES?
4281 024510 003342                BGT     2#           ;NO GO DO SOFTWARE FILE
4282 024512 012603      20#: MOV     (SP)+,R3    ;ELSE RESTORE REGISTERS
4283 024514 012601      MOV     (SP)+,R1
4284 024516 012600      MOV     (SP)+,R0
4285 024520 005737 003034      TST     BSFLAG        ;CHECK IF ERROR
4286 024524 001003      BNE     99#          ;YES - SKIP
4287 024526 062716 000002      ADD     #2,(SP)      ;ELSE BUMP ERROR RETURN
4288 024532 000207      RTS     PC
4289 024534 017616 000000      99#: MOV     @ (SP),(SP) ;SET FOR ERROR RETURN

```


GLOBAL SUBROUTINES

Address	Hex	Hex	Hex	Label	Code	Comment
4290	024540	000207			RTS	PC
4291						
4293						
4294						
4295						
4296	024542	010446				
4297	024544	005737	003016			
4298	024550	001433				
4299	024552	012704	000002			
4300	024556					
	024556	012746	007514			
	024562	012746	011212			
	024566	012746	000002			
	024572	010600				
	024574	104414				
	024576	062706	000006			
4301	024602			3#:	PRINTB	#FMT16,SUBSTK(R4) ;PRINT CALLING LOCATION
	024602	016446	002420		MOV	SUBSTK(R4),-(SP)
	024606	012746	011365		MOV	#FMT16,-(SP)
	024612	012746	000002		MOV	#2,-(SP)
	024616	010600			MOV	SP,R0
	024620	104414			TRAP	C#PNTB
	024622	062706	000006		ADD	#6,SP
4302	024626	062704	000002		ADD	#2,R4 ;BUMP INDEX
4303	024632	020437	003016		CMF	R4,SSINDX ;CHECK IF ALL PRINTED
4304	024636	003761			BLE	3# ;LOOP IF NOT ALL PRINTED YET
4305	024640			1#:	PRINTB	#FMT4,ERHEAD,#TSTLAB ;PRINT ERROR HEADER
	024640	012746	006501		MOV	#TSTLAB,(SP)
	024644	013746	003026		MOV	ERHEAD,-(SP)
	024650	012746	011015		MOV	#FMT4,-(SP)
	024654	012746	000003		MOV	#3,-(SP)
	024660	010600			MOV	SP,R0
	024662	104414			TRAP	C#PNTB
	024664	062706	000010		ADD	#10,SP
4306	024670	042737	030000	003020	BIC	#SEEKOP#RORWOP,OPFLAG ;CLEAR SK & RD OR WRT FLAG
4307	024676	013701	003050		MOV	L.CS,R1 ;GET COMMAND EXECUTED
4308	024702	042701	177741		BIC	#177741,R1 ;STRIP ALL BUT FUNCTION CODE
4309	024706	022701	000006		CMF	#6,R1 ;TEST IF SEEK OPERATION
4310	024712	001003			BNE	2# ;NO - SKIP
4311	024714	052737	010000	003020	BIS	#SEEKOP,OPFLAG ;ELSE SET SEEK FLAG
4312	024722	022701	000012		CMF	#12,R1 ;TEST IF WRITE
4313	024726	001003			BNE	20# ;NO - SKIP
4314	024730	052737	020000	003020	BIS	#RORWOP,OPFLAG ;SET RD OR WRT FLAG
4315	024736	022701	000014		CMF	#14,R1 ;TEST IF READ
4316	024742	001003			BNE	22# ;NO - SKIP
4317	024744	052737	020000	003020	BIS	#RORWOP,OPFLAG ;SET RD OR WRT FLAG
4318	024752			22#:	PRINTB	#FMT1,#OPER,OPMSG(S(R1)) ;PRINT OPERATION
	024752	016146	002240		MOV	OPMSG(S(R1)),-(SP)
	024756	012746	005527		MOV	#OPER,-(SP)
	024762	012746	010773		MOV	#FMT1,-(SP)
	024766	012746	000003		MOV	#3,-(SP)
	024772	010600			MOV	SP,R0
	024774	104414			TRAP	C#PNTB
	024776	062706	000010		ADD	#10,SP
4319	025002	020127	000004		CMF	R1,#4 ;CHECK IF GET STATUS
4320	025006	001007			BNE	4# ;NO - SKIP
4321	025010	032737	000010	003054	BIT	#DRSET,L.DA ;TEST IF RESET INCLUDED

GLOBAL SUBROUTINES

```

4322 025016 001403          BEQ      4$          ;NO - SKIP
4323 025020 012701 000016    BR       #16,R1     ;SET TO PRINT WITH RESET
4324 025024 000436          BR       9$
4325 025026 032737 007777 003020 4$:  BIT     #COMPOP,OPFLAG ;TEST IF ANY OTHER OPERATION
4326 025034 001424          BEQ      8$          ;NO - SKIP
4327 025036 013704 003020    MOV     OPFLAG,R4   ;SET UP TO DETERMINE WHICH ONE
4328 025042 012701 000020    MOV     #20,R1     ;PRESET THE POINTER
4329 025046 032704 000001          BIT     #BIT00,R4   ;CHECK THE BIT
4330 025052 001003          BNE     6$          ;IF SET - SKIP
4331 025054 005721          TST     (R1),      ;BUMP POINTER
4332 025056 006204          ASR     R4
4333 025060 000772          BR      5$
4334 025062          6$:  PRINTB #FMT2,OPMSG$(R1)
      025062 016146 002240    MOV     OPMSG$(R1),-(SP)
      025066 012746 011007    MOV     #FMT2,-(SP)
      025072 012746 000002    MOV     #2,-(SP)
      025076 010600          MOV     SP,R0
      025100 104414          TRAP   C$PNTB
      025102 062706 000006          ADD     #6,SP
4335 025106 032737 100000 003020 8$:  BIT     #HDR40,OPFLAG ;TEST IF 40 HEADER OPERATION
4336 025114 001415          BEQ     10$         ;NO - SKIP
4337 025116 012701 000050          MOV     #50,R1     ;ELSE PRINT IT
4338 025122          9$:  PRINTB #FMT2,OPMSG$(R1)
      025122 016146 002240    MOV     OPMSG$(R1),-(SP)
      025126 012746 011007    MOV     #FMT2,-(SP)
      025132 012746 000002    MOV     #2,-(SP)
      025136 010600          MOV     SP,R0
      025140 104414          TRAP   C$PNTB
      025142 062706 000006          ADD     #6,SP
4339 025146 000434          BR      15$        ;SKIP
4340 025150 032737 010000 003020 10$: BIT     #SEEKOP,OPFLAG ;TEST IF SEEK
4341 025156 001430          BEQ     15$        ;NO - SKIP
4342 025160          PRINTB #FMT13,#FRMWD,OLDCYL,#DIFWD,DESDIF,#SGNWD,DESSGN,#HDWD,DESHD
      025160 013746 003126    MOV     DESHD,-(SP)
      025164 012746 007455    MOV     #HDWD,-(SP)
      025170 013746 003124    MOV     DESSGN,-(SP)
      025174 012746 007450    MOV     #SGNWD,-(SP)
      025200 013746 003122    MOV     DESDIF,-(SP)
      025204 012746 007442    MOV     #DIFWD,-(SP)
      025210 013746 003114    MOV     OLDCYL,-(SP)
      025214 012746 007473    MOV     #FRMWD,-(SP)
      025220 012746 011233    MOV     #FMT13,-(SP)
      025224 012746 000011    MOV     #11,-(SP)
      025230 010600          MOV     SP,R0
      025232 104414          TRAP   C$PNTB
      025234 062706 000024          ADD     #24,SP
4343 025240 032737 020000 003020 15$: BIT     #RORWOP,OPFLAG ;TEST IF READ OR WRITE SET
4344 025246 001424          BEQ     17$        ;NO - SKIP
4345 025250          PRINTB #FMT22,#CYLWD,CURCYL,#HDWD,DESHD,#SECWD,DESSEC
      025250 013746 003130    MOV     DESSEC,-(SP)
      025254 012746 007461    MOV     #SECWD,-(SP)
      025260 013746 003126    MOV     DESHD,-(SP)
      025264 012746 007455    MOV     #HDWD,-(SP)
      025270 013746 003120    MOV     CURCYL,-(SP)
      025274 012746 007466    MOV     #CYLWD,-(SP)
      025300 012746 011562    MOV     #FMT22,-(SP)
      025304 012746 000007    MOV     #7,-(SP)

```

GLOBAL SUBROUTINES

```

025310 010600      MOV      SP,R0
025312 104414      TRAP     C:PNTB
025314 062706 000020  ADD      #20,SP
4346 025320 004737 025772 17$:     JSR      PC,CLRPARM      ;CLEAR PARAM TABLE
4347 025324 012604      MOV      (SP)+,R4      ;RESTORE R4
4348 025326 000207      RTS      PC

4349
4350
4351      ;      REPORT REASON ROUTINE
4352 025330 010146      ;PRINTS REASON PORTION FOR ALL ERROR REPORTS.
4353 025332 010346      RPTRES: MOV      R1,-(SP)      ;STORE R1
4354 025334 010446      MOV      R3,-(SP)      ;STORE R3
4355 025336 012701 003076  MOV      R4,-(SP)      ;STORE R4
4356 025342 012103      MOV      #RESPARM,R1    ;GET START OF PARAM
4357 025344      MOV      (R1)+,R3      ;GET NUMBER OF PARAM
025344 011146      PRINTB  #FMT1.1,#MRSLT,(R1) ;PRINT NAME
025346 012746 005536  MOV      (R1),-(SP)
025352 012746 011000  MOV      #MRSLT,-(SP)
025356 012746 000003  MOV      #FMT1.1,-(SP)
025362 010600      MOV      #3,-(SP)
025364 104414      MOV      SP,R0
025366 062706 000010  TRAP     C:PNTB
4358 025372 021127 010352  ADD      #10,SP
4359 025376 001453      CMP      (R1),#MNRST    ;TEST IF MESSAGE IS NO DRV STATUS
4360 025400 012704 011217  BEQ      6$             ;YES - SKIP REST OF REPORT
4361 025404 022127 010345  MOV      #FMT11,R4      ;PRISET FOR FORMAT 11
4362 025410 001002      CMP      (R1)+,#MCYLOC  ;CHECK IF REPORTING CYLINDER LOC
4363 025412 012704 011225  BNE      3$             ;NO - SKIP
4364 025416 005303      MOV      #FMT12,R4     ;ELSE CHANGE TO FORMAT 12
4365 025420 001442      DEC      R3             ;DEC PARAM COUNT
4366 025422      BEQ      6$             ;IF 0 - EXIT
025422 012146      PRINTB  R4,#RESE3,(R1)+ ;REPORT IS VALUE
025424 012746 010561  MOV      (R1)+,-(SP)
025430 010446      MOV      #RESE3,-(SP)
025432 012746 000003  MOV      R4,-(SP)
025436 010600      MOV      #3,-(SP)
025440 104414      MOV      SP,R0
025442 062706 000010  TRAP     C:PNTB
4367 025446      ADD      #10,SP
025446 012146      PRINTB  R4,#RESE4,(R1)+ ;REPORT SB VALUE
025450 012746 010565  MOV      (R1)+,-(SP)
025454 010446      MOV      #RESE4,-(SP)
025456 012746 000003  MOV      R4,-(SP)
025462 010600      MOV      #3,-(SP)
025464 104414      MOV      SP,R0
025466 062706 000010  TRAP     C:PNTB
4368 025472 162703 000002  ADD      #10,SP
4369 025476 001413      SUB      #2,R3          ;DEC PARAM COUNT
4370 025500      BEQ      6$             ;IF 0 - EXIT
025500 012146      PRINTB  #FMT1,#RESE5,(R1)+ ;REPORT CONDITION
025502 012746 010572  MOV      (R1)+,-(SP)
025506 012746 010773  MOV      #RESE5,-(SP)
025512 012746 000003  MOV      #FMT1,-(SP)
025516 010600      MOV      #3,-(SP)
025520 104414      MOV      SP,R0
025522 062706 000010  TRAP     C:PNTB
4371 025526 012604      ADD      #10,SP
6$:     MOV      (SP)+,R4      ;RESTORE REGS
    
```

GLOBAL SUBROUTINES

```

4372 025530 012603      MOV      (SP)+,R3
4373 025532 012601      MOV      (SP)+,R1
4374 025534 000207      RTS       PC                ;RETURN
4375
4376                    ;      REPORT PHYSICAL ADDRESS OF DEVICE UNDER TEST
4377                    ;      AND ALL REGISTER CONTENTS.
4378 025536 005046      RPTREM: PRINTB  #FMT5,#BASADD,RLBAS,#DRVNAM,<B,RLDRV+1>
      025536 005046      CLR       (SP)
      025540 153716 003047      BISB     RLDRV+1,(SP)
      025544 012746 006152      MOV      #DRVNAM,(SP)
      025550 013746 003042      MOV      RLBAS,-(SP)
      025554 012746 006141      MOV      #BASADD,-(SP)
      025560 012746 011026      MOV      #FMT5,-(SP)
      025564 012746 000005      MOV      #5,-(SP)
      025570 010600      MOV      SP,RO
      025572 104414      TRAP     C#PNTB
      025574 062706 000014      ADD      #14,SP
4379                    ;      REPORT RL11 REGISTERS
4380 025600 007455      PRINTB  #FMT6,#CSNAM,#DANAM,#BANAM,#MPNAM,#CYLWD,#HDWD
      025600 012746 007455      MOV      #HDWD,-(SP)
      025604 012746 007466      MOV      #CYLWD,-(SP)
      025610 012746 006255      MOV      #MPNAM,-(SP)
      025614 012746 006243      MOV      #BANAM,-(SP)
      025620 012746 006250      MOV      #DANAM,-(SP)
      025624 012746 006236      MOV      #CSNAM,-(SP)
      025630 012746 011046      MOV      #FMT6,-(SP)
      025634 012746 000007      MOV      #7,(SP)
      025640 010600      MOV      SP,RO
      025642 104414      TRAP     C#PNTB
      025644 062706 000020      ADD      #20,SP
4381 025650 003056      PRINTB  #FMT8,#LAB1,L.CS,L.DA,L.BA,L.MP
      025650 013746 003056      MOV      L.MP,(SP)
      025654 013746 003052      MOV      L.BA,(SP)
      025660 013746 003054      MOV      L.DA,-(SP)
      025664 013746 003050      MOV      L.CS,-(SP)
      025670 012746 006262      MOV      #LAB1,-(SP)
      025674 012746 011160      MOV      #FMT8,-(SP)
      025700 012746 000006      MOV      #6,-(SP)
      025704 010600      MOV      SP,RO
      025706 104414      TRAP     C#PNTB
      025710 062706 000016      ADD      #16,SP
4382 025714 003126      PRINTB  #FMT7,#LAB2,T.CS,T.DA,T.BA,T.MP,CURCYL,DESHD
      025714 013746 003126      MOV      DESHD,-(SP)
      025720 013746 003120      MOV      CURCYL,-(SP)
      025724 013746 003066      MOV      T.MP,-(SP)
      025730 013746 003062      MOV      T.BA,-(SP)
      025734 013746 003064      MOV      T.DA,-(SP)
      025740 013746 003060      MOV      T.CS,-(SP)
      025744 012746 006275      MOV      #LAB2, )
      025750 012746 011110      MOV      #FMT7,-(SP)
      025754 012746 000010      MOV      #10,-(SP)
      025760 010600      MOV      SP,RO
      025762 104414      TRAP     C#PNTB
      025764 062706 000022      ADD      #22,SP
4383 025770 000207      RTS       PC
4384
4385                    ;      CLEAR PARAMETER BLOCK FOR REPORTING

```

GLOBAL SUBROUTINES

```

4386 025772 010546          CLRPARM:      MOV      R5, (SP)          ;STORE R5
4387 025774 012701 003076    MOV      @RESPARM,R1      ;GET ADDRESS OF BLOCK
4388 026000 012705 000005    MOV      #5,R5            ;SET COUNT
4389 026004 005021          2$:      CLR      (R1)+        ;CLEAR WORD
4390 026006 005305          DEC      R5              ;DEC COUNT
4391 026010 001375          BNE     2$              ;LOOP UNTIL 0
4392 026012 012701 003076    MOV      @RESPARM,R1      ;RESET POINTER
4393 026016 012605          MOV      (SP)+,R5        ;RESTORE R5
4394 026020 000207          RTS      PC
4395
4396 026022          ENDMOD
4397
4398          .TITLE  CNRLJAO RL01/02 DRIVE TEST 2
4399
4400          .SBTTL  *TEST 1          **OUTER GUARD BAND DETECTION
4401
4402 026022          BGNMOD  HRDWTST
4403 026022          BGNST   ;TEST 1
4404
4404          T1::
4405 026022 012737 006507 003026    MOV      @P2T03E,ERHEAD  ;SET ERROR HEADER
4406 026030 004737 016242          JSR     PC,TSTINT        ;INITIALIZE TEST
4407 026034 004737 016260          JSR     PC,GSTATR       ;CLEAR DRIVE
4408 026040 026242          T1965$
4409 026042 004737 020600          JSR     PC,CHOSHD       ;GO CHOSE HEAD
4410 026046 005005          T197$:  CLR      R5          ;CLEAR FOR POSITION TO 0
4411 026050 004737 017760          JSR     PC,POSHDS       ;POSITION HEADS
4412 026054 026242          T1965$
4413 026056          BGNSUB
4414          T1.1:
4414 026056 104402          TRAP   C$BSUB
4415 026060 012737 177777 003116    MOV      #-1,NEWCYL      ;SET FOR GUARD BAND SEEK
4416 026066 004737 017206          JSR     PC,XSEEK        ;DO SEEK
4417 026072 026216          60$
4418 026074 012701 000002          MOV      #2,R1          ;INITIALIZE WAIT COUNT
4419 026100 032762 000001 000000  8$:    BIT     @DRDYMSK,RLCS(R2) ;TEST IF DRIVE READY
4420 026106 001414          BEQ     9$              ;NO-SKIP
4421 026110 004737 016310          JSR     PC,GSTAT        ;GET DRIVE STATUS
4422 026114 026216          60$
4423 026116 012703 007760          MOV      @MORDY,R3       ;SET NAME MESSAGE PTR
4424 026122 012704 010634          MOV      @C1OMS,R4       ;SET CONDITION MESSAGE PTR
4425 026126          ERRHRD 301...ERR4    ;REPORT READY ERROR
4426 026126 104456          TRAP   C$ERHRD
4427 026130 000455          .WORD  301
4428 026132 000000          .WORD  0
4429 026134 012106          .WORD  ERR4
4430 026136 000427          BR     60$              ;EXIT TEST
4431 026140 005301          9$:    DEC     R1            ;DEC WAIT COUNT
4432 026142 001406          BEQ     12$             ;SKIP IF 0
4433 026144          WAITUS #10.           ;WAIT 1MS
4434 026156 000750          BR     8$              ;LOOP
4435 026160 012701 000226          12$:  MOV     #150.,R1       ;SET WAIT COUNT FOR 15 MS
4436 026164 004737 022102          JSR     PC,RDYWAIT      ;WAIT FOR READY & REPORT IF NOT READY
4437 026170 026216          60$
4438 026172 004737 022366          JSR     PC,GETPOS       ;GET POSITION
4439 026176 026216          60$

```

*TEST 1

••OUTER GUARD BAND DETECTION

```

4436 026200 005737 003120      TST      CURCYL      ;CHECK IF HEADS STILL AT 0
4437 026204 001404              BEQ      15$         ;YES-SKIP
4438 026206 104456      ERRMRD    302,,ERR8   ;ELSE REPORT CYLINDER ERROR
      026206 000456      TRAP     C$ERRMRD
      026210 000456      .WORD   302
      026212 000000      .WORD   0
      026214 013160      .WORD   ERR8
4439 026216 012737 000002 003032 15$:
4440 026216 012737 000002 003032 60$:
4441 026224 026224 104403      ENDSUB   L10024:
      026224 104403      TRAP     C$ESUB
4442 026226 104410      ESCAPE  TST          ;EXIT TEST IF ERROR
      026226 000012      TRAP     C$ESCAPE
      026230 000737 020624      .WORD   L10023
4443 026232 000737 020624      JSR     PC,SWAPHD   ;GO SWAP TO HEAD 1 OR END TEST
4444 026236 000702      17$
4445 026240 000702      BR      T197$      ;ABORT RETURN
4446 026242 17$:
4447 026242      T1965$:
4448
4449 026242 026242 104401      ENDTST   L10023:
      026242 104401      TRAP     C$ETST
4450
4451      .SBTTL  *TEST 2      ••INCREMENTAL FORWARD SEEK HEAD 0
4452 026244 026244      BGNTST  ;TEST 2
4453 026244 012737 006525 003026      MOV     #P2T04E,ERHEAD ;SET ERROR HEADER
4454 026252 004737 016242      JSR     PC,TSTINT    ;INITIALIZE TEST
4455 026256 004737 016260      JSR     PC,GSTATR    ;CLEAR DRIVE
4456 026262 026452      T2065$
4457 026264 004737 020600      JSR     PC,CHOSHD    ;GO CHOSE HEAD
4458 026270 005737 003126      TST     DESHD        ;TEST IF THIS IS HEAD 0
4459 026274 001402      BEQ     2$           ;YES - SKIP
4460 026276 104432      EXIT    TST          ;ELSE EXIT TEST
      026276 000152      TRAP     C$EXIT
      026300 013705 013560      .WORD   L10025-
4461 026302 004737 017760      2$:      MOV     LOLIMM,R5    ;CLEAR TO POSITION HEADS TO LOLIMIT
4462 026306 004737 017760      JSR     PC,POSHDS    ;POSITION HEADS
4463 026312 026452      T2065$
4464 026314 026314      BGNSUB
4465 026316 004737 022366      206$:   TRAP     C$BSUB
      026316 000402      JSR     PC,GETPOS    ;GET POSITION
4466 026322 026442      60$
4467 026324 104420      INLOOP
      026324 003120 003116      TRAP     C$INLP
4468 026326 103007      BNCOMPLETE 5$      ;NO - SKIP
      026326 001003      BCC     5$
4469 026330 004737 020664      CMP     CURCYL,NEWCYL ;CHECK IF POSITIONED AT DESIRED LOC
4470 026336 000405      BNE     5$          ;NO - SKIP
4471 026340 004737 020664      JSR     PC,ONSWAP    ;ELSE SWAP NEW AND OLD CYLINDERS
4472 026344 000405      BR      7$          ;SKIP
4473 026346 013737 003120 003116 5$:      MOV     CURCYL,NEWCYL ;PLACE CURRENT INTO NEW
4474 026354 005237 003116      INC     NEWCYL       ;BUMP FOR ONE CYLINDER SEEK
4475 026360      7$:

```

*TEST 2

**INCREMENTAL FORWARD SEEK HEAD 0

```

4476 026360 004737 017206      JSR    PC,XSEFK      ;DO SEEK
4477 026364 026442              60$
4478 026366 012701 000226      MOV    #150.,R1     ;SET WAIT TIME 15 MS
4479 026372 004737 022102      JSR    PC,RDYWAIT   ;WAIT FOR READY
4480 026376 026442              60$
4481
4482 026400 004737 022514      JSR    PC,VERPOS    ;GO VERIFY POSITON
4483 026404 026442              60$
4484
4485 026406 032737 000002 013556  BIT    #ALLSEC,MISWIW ;TEST IF CHECK ALL SECTORS
4486 026414 001406              BEQ    11$          ;NO SKIP
4487 026416 004737 022636      JSR    PC,RDALMD    ;GO READ ALL HEADERS
4488 026422 026442              60$
4489 026424 004737 021506      JSR    PC,VERHDR    ;GO VERIFY HEADFR
4490 026430 026442              60$
4491 026432
4492 026432 023737 013562 003116  11$:  CMP    HILIMW,NEWCYL ;CHECK IF HILIMIT REACHED
4493 026440 103726              BLO    T206$      ;NO-LOOP
4494 026442 012737 000002 003032  60$:  MOV    #2.ERRSWI   ;INIT ERROR SWITCH
4495 026450
      ENDSUB
      L10026:
      026450 104403
      TRAP  C#ESUB
4496 026452
      T2065$:
4497 026452
      ENDTST
      L10025:
      026452 104401
      TRAP  C#ETST
4498
4499
      .SBTTL *TEST 3
      BGNTST **INCREMENTAL REVERSE SEEK HEAD 0
      ;TEST 3
4500 026454
      026454
      T3::
4501 026454 012737 006545 003026  MOV    #P2TOSE,ERHEAD ;SET ERROR HEADER
4502 026462 004737 016242      JSR    PC,TSTINT   ;INITIALIZE TEST
4503 026466 004737 016260      JSR    PC,GSTATR   ;CLEAR DRIVE
4504 026472 026662
      T2165$
4505 026474 004737 020600      JSR    PC,CHOSHD   ;GO CHOSE HEAD
4506 026500 005737 003126      TST    DESHD       ;TEST IF HEAD 0 SELECTED
4507 026504 001402              BEQ    2$          ;YES - SKIP
4508 026506
      EXIT
      TRAP  C#EXIT
      .WORD  L10027-.
4509 026512 013705 013562 2$:  MOV    HILIMW,R5    ;SET TO POSITION HDS TO HILIMIT
4510 026516 004737 017760      JSR    PC,POSHDS   ;POSITION HEADS
4511 026522 026662
      T2165$
4512 026524
      BGNSUB
      T3.1:
      026524 104402
      TRAP  C#BSUB
4513 026526 004737 022366  T216$: JSR    PC,GETPOS    ;GET POSITION
4514 026532 026652              60$
4515 026534
      INLOOP
      TRAP  C#INLP
      026534 104420
      BNCOMPLETE 5$ ;NO - SKIP
4516 026536
      BCC  5$
      026536 103007
      CMP    CURCYL,NEWCYL ;CHECK IF POSITIONED AT DES LOC
4517 026540 023737 003120 003116  BNE    5$          ;NO - SKIP
4518 026546 001003
      JSR    PC,ONSWAP ;ELSE SWAP OLD AND NEW CYLINDERS
4519 026550 004737 020664
      BR    7$
4520 026554 000405
      BR    7$
4521 026556 013737 003120 003116  5$:  MOV    CURCYL,NEWCYL ;PUT CURRENT INTO NEW

```

*TEST 3

**INCREMENTAL REVERSE SEEK HEAD 0

```

4522 026564 005337 003116      DEC      NEWCYL      ;DEC FOR ONE CYLINDER REVERSE SEEK
4523 026570 004737 017206      78:     JSR      PC,XSEEK      ;SEEK TO IT
4524 026574 026652                60$
4525 026576 012701 000226      MOV      #150.,R1      ;SET WAIT FOR 15 MS
4526 026602 004737 022102      JSR      PC,RDYWAIT     ;WAIT FOR READY
4527 026606 026652                60$
4528
4529 026610 004737 022514      JSR      PC,VERPOS      ;VERIFY POSITION
4530 026614 026652                60$
4531
4532 026616 032737 000002 003020  BIT      #ALLSEC,OPFLAG ;TEST IF USE ALL SECTORS
4533 026624 001406                BEQ      11$            ;NO-SKIP
4534 026626 004737 022636      JSR      PC,RDALHD      ;ELSE READ ALL THE HDRS
4535 026632 026652                60$
4536 026634 004737 021506      JSR      PC,VERHDR      ;VERIFY THE HEADERS
4537 026640 026652                60$
4538 026642
4539 026642 023737 013560 003116 11$:     CMP      LOLIMW,NEWCYL  ;CHECK IF REACHED LOLIMIT
4540 026650 103726                BLO      T216$         ;NO - LOOP
4541 026652 012737 000002 003032 60$:     MOV      #2,ERRSWI     ;INIT ERROR SWITCH
4542 026660                ENDSUB
4543 026662 104403                L10030: TRAP      C#ESUB
4544 026662                T2165$:
4545 026662 104401                ENDTST
4546 026662                L10027: TRAP      C#ETST

```

.SBTTL *TEST 4

**INCREMENTAL FORWARD SEEK HEAD 1

```

4547 026664                BGNTST      ;TEST 4
4548 026664 012737 006565 003026  MOV      #P2T06E,ERHEAD ;SET ERROR HEADER
4549 026672 004737 016242      JSR      PC,TSTINT      ;INITIALIZE TEST
4550 026676 004737 016260      JSR      PC,GSTATR      ;CLEAR DRIVE
4551 026702 027106                T2265$
4552 026704 005037 003126      CLR      DESHD          ;SET HEAD TO 0
4553 026710 013705 013560      MOV      LOLIMW,R5      ;CLEAR FOR POSITION HDS TO LOLIMIT
4554 026714 004737 017760      JSR      PC,POSHDS      ;POSITION HDS
4555 026720 027106                T2265$
4556 026722 012737 000001 003126  MOV      #1,DESHD        ;SET TO HEAD 1
4557 026730 032737 010000 013556  BIT      #HEADLM,MISWIW ;TEST IF HEAD SPECIFIED
4558 026736 001405                BEQ      2$            ;NO - SKIP
4559 026740 005737 013564      TST      HEADW          ;TEST IF IT IS HEAD 0
4560 026744 001002                BNE      2$            ;NO - SKIP
4561 026746                EXIT      TST           ;ELSE EXIT TEST
4562 026752 104432                TRAP      C#EXIT
4563 026752 000136                .WORD     L10031-.
4564 026754 004737 022366      2$:     BGNSUB
4565 026760 104420                T227$: TRAP      C#BSUB
4566 026762 103007 003120 003116  JSR      PC,GETPOS      ;GET CURRENT POSITION
4567 026764 023737 003120 003116  INLOOP   TRAP      C#INLP    ;CHECK IF IN ERROR LOOP
                                BNCOMPLETE 5$
                                BCC      5$
                                CMP      CURCYL,NEWCYL ;CHECK IF AT DESIRED LOCATION

```


*TEST 4

**INCREMENTAL FORWARD SEEK HEAD 1

```

4568 026772 001003          BNE      5#          ;NO SKIP
4569 026774 004737 020664   JSR      PC,ONSWAP  ;SWAP OLD AND NEW CYLINDER
4570 027000 000405          BR       7#          ;SKIP
4571 027002 013737 003120 003116 5#:   MOV      CURCYL,NEWCYL ;MOVE CURRENT INTO NEW
4572 027010 005237 003116          INC      NEWCYL      ;BUMP NEWCYL FOR ONE CYL FWRD SEEK
4573 027014          7#:
4574 027014 004737 017206   JSR      PC,XSEEK   ;DO SEEK
4575 027020 027076   60#
4576 027022 012701 000226   MOV      #150.,R1   ;SET WAIT COUNT 15 MS
4577 027026 004737 022102   JSR      PC,RDYWAIT ;WAIT FOR READY
4578 027032 027076   60#
4579 027034 004737 022514   JSR      PC,VERPOS  ;VERIFY POSITION IS CORRECT
4580 027040 027076   60#
4581
4582 027042 032737 000002 013556   BIT      #ALLSEC,MISWIW ;CHECK IF USE ALL SECTORS
4583 027050 001406          BEQ      9#          ;NO-SKIP
4584 027052 004737 022636   JSR      PC,RDALHD  ;ELSE READ ALL HEADERS
4585 027056 027076   60#
4586 027060 004737 021506   JSR      PC,VERHDR  ;VERIFY HEADERS
4587 027064 027076   60#
4588 027066          9#:
4589 027066 023737 013562 003116   CMP      HLIMW,NEWCYL ;CHECK IF DONE
4590 027074 101327          BMI      T227#      ;NO LOOP
4591 027076 012737 000002 003032 60#:   MOV      #2,ERRSWI  ;INIT ERROR SWITCH
4592 027104          ENDSUB
         027104          L10032:
         027104 104403          TRAP    C#ESUB
4593 027106          T2265#:
4594 027106          ENDTST
         027106          L10031:
         027106 104401          TRAP    C#ETST
4595
4596          .SBTTL *TEST 5          **INNER GUARD BAND DETECTION
4597
4598 027110          BGNTST          ;TEST 5
         027110          T5::
4599
4600 027110 012737 006605 003026   MOV      #P2T07E,ERHEAD ;SET ERROR HEADER
4601 027116 004737 016242   JSR      PC,TSTINT  ;INITIALIZE TEST
4602 027122 004737 016260   JSR      PC,GSTATR  ;CLEAR DRIVE
4603 027126 027314          T2365#
4604 027130 004737 020600   JSR      PC,CHOSH0  ;GO CHOSE HEAD
4605 027134 013705 002316   T233#:   MOV      HLMTW,R5   ;SET FOR POSITION TO 255.
4606 027140 004737 017760   JSR      PC,POSHDS  ;POSITION HEADS
4607 027144 027314          T2365#
4608 027146          BGNSUB          T5.1:
         027146          104402
         027146 013737 002324 003116   TRAP    C#BSUB
4609 027150 013737 002324 003116   MOV      GBND,NEWCYL ;SET FOR INNER GUARD BAND SEEK
4610 027156 004737 017206   JSR      PC,XSEEK   ;DO IT
4611 027162 027270   60#
4612 027164 012701 000001          MOV      #1.,R1     ;INITIALIZE WAIT COUNT
4613 027170 032762 000001 000000 7#:   BIT      #DRDYMSK,RLCS(R2) ;CHECK IF READY
4614 027176 001414          BEQ      9#          ;NO-SKIP
4615 027200 004737 016310   JSR      PC,GSTAT   ;GET DRIVE STATUS
4616 027204 027270   60#
4617 027206 012703 007760   MOV      #MRDY,R3   ;SET NAME MESSAGE PTR

```

*TEST 5

**INNER GUARD BAND DETECTION

```

4618 027212 012704 010634      MOV      #C10MS,R4      ;SET CONDITION MESSAGE PTR
4619 027216      ERRHRD  701...ERR4    ;REPORT READY ERROR
      027216 104456      TRAP    C#ERRHRD
      027220 001275      .WORD  701
      027222 000000      .WORD  0
      027224 012106      .WORD  ERR4
4620 027226 000420      BR      60$           ;EXIT TEST
4621 027230 005301      9$:    DEC      R1           ;DEC WAIT COUNT
4622 027232 001406      BEQ     11$           ;SKIP IF 0
4623 027234      WAITUS #10.          ;WAIT 1MS
4624 027246 000750      BR      7$           ;LOOP
4625 027250 012701 000226      11$:   MOV      #150.,R1      ;SET WAIT COUNT 15 MS
4626 027254 004737 022102      JSR    PC,RDYWAIT    ;GO WAIT FOR READY
4627 027260 027270      60$:   BR      60$
4628
4629 027262 004737 022514      JSR    PC,VERPOS     ;GO VERIFY POSITION IS 255
4630 027266 027270      60$:   BR      60$
4631 027270 012737 000002 003032 60$:   MOV      #2,ERRSWI    ;INIT ERROR SWITCH
4632 027276      ENDSUB L10034:
      027276 104403      TRAP    C#ESUB
4633 027300      ESCAPE TST           ;EXIT TEST IF ERROR
      027300 104410      TRAP    C#ESCAPE
      027302 000012      .WORD  L10033-
4634 027304 004737 020624      JSR    PC,SWAPHD    ;GO SWAP TO HEAD 1 OR END TEST
4635 027310 027314      15$:   BR      15$
4636 027312 000710      BR      T233$
4637 027314      15$:   BR      T2365$
4638 027314
4639
4640 027314      ENDTST L10033:
      027314 104401      TRAP    C#ETST
4641
4642      .SBTTL *TEST 6      **INCREMENTAL REVERSE SEEK HEAD 1
4643 027316      BGNSTST ;TEST 6
      027316
4644 027316 012737 006623 003026      MOV      #P2TO8E,ERHEAD ;SET ERROR HEADER
4645 027324 004737 016242      JSR    PC,TSTINT     ;INITIALIZE TEST
4646 027330 004737 016260      JSR    PC,GSTATR    ;GET STATUS & CLEAR
4647 027334 027542      T2465$
4648 027336 005037 003126      CLR     DESHD        ;SET TO HEAD 0
4649 027342 013705 013562      MOV     HILIMW,R5    ;SET TO POSITION HDS AT HILIMIT
4650 027346 004737 017760      JSR    PC,POSHDS    ;POSITION HDS
4651 027352 027542      T2465$
4652 027354 012737 000001 003126      MOV     #1,DESHD     ;SET TO SELECT HD 1
4653 027362 032737 010000 013556      BIT     #HEADLM,MISWIW ;TEST IF HEAD SPECIFIED
4654 027370 001405      BEQ     2$           ;NO - SKIP
4655 027372 005737 013564      TST    HEADW        ;TEST IF HEAD SPECIFIED IS 0
4656 027376 001002      BNE     2$           ;NO - SKIP
4657 027400      EXIT  TST           ;ESLE EXIT TEST
      027400 104432      TRAP    C#EXIT
      027402 000140      .WORD  L10035
4658 027404      2$:   BGNSSUB
4659 027404
      027404 104402      TRAP    C#BSUB

```

T6.1:

```

*TEST 6          **INCREMENTAL REVERSE SEEK HEAD 1

4660 027406 004737 022366          T247$: JSR    PC,GETPOS      ;GET CURRENT POSITION
4661 027412 027532                   60$
4662 027414                   INLOOP          ;CHECK IF IN ERROR LOOP
      027414 104420          TRAP    C$INLP
4663 027416                   BNCOMPLETE     5$      ;NO - SKIP
      027416 103007          BCC     5$
4664 027420 023737 003120 003116    CMP     CURCYL,NEWCYL  ;CHECK IF POSITIONED AT DESIRED LOC
4665 027426 001003                   BNE     5$      ;NO - SKIP
4666 027430 004737 020664          JSR    PC,ONSWAP      ;ELSE SWAP OLD AND NEW CYLINDER
4667 027434 000405                   BR     7$      ;SKIP
4668 027436 013737 003120 003116  5$:  MOV    CURCYL,NEWCYL  ;MOV CUR TO NEW
4669 027444 005337 003116          DEC    NEWCYL        ;DEC NEWCYL FOR 1 CYL REV SEEK
4670 027450 004737 017206          7$:  JSR    PC,XSEEK    ;DO SEEK
4671 027454 027532                   60$
4672 027456 012701 000226          MOV    #150.,R1      ;SET WAIT FOR 15 MS
4673 027462 004737 022102          JSR    PC,RDYWAIT    ;WAIT FOR READY
4674 027466 027532                   60$
4675 027470 004737 022514          JSR    PC,VERPOS     ;VERIFY POSITION
4676 027474 027532                   60$
4677 027476 032737 000002 013556    BIT    #ALLSEC,MISWIW ;TEST IF ALL SECTORS
4678 027504 001406                   BEQ    9$      ;NO-EXIT
4679 027506 004737 022636          JSR    PC,RDALHD     ;READ ALL HEADERS
4680 027512 027532                   60$
4681 027514 004737 021506          JSR    PC,VERHDR     ;VERIFY HEADER
4682 027520 027532                   60$
4683 027522                   9$:
4684 027522 023737 013560 003116    CMP    LOLIMW,NEWCYL ;CHECK IF AT LOLIMIT
4685 027530 103726                   BLO    T247$       ;NO - LOOP
4686 027532 012737 000002 003032  60$:  MOV    #2,ERRSWI     ;INIT ERROR SWITCH
4687 027540                   ENDSUB
      027540 L10036:
4688 027542                   TRAP    C$ESUB
      027542 104403
4689 027542                   T2465$:
      027542 L10035:
      027542 104401          TRAP    C$ETST

4690
4691          .SBTTL *TEST 7          **SEEK TESTS
4692 027544          BGNTST          ;TEST 7
      027544
4693 027544 012737 006643 003026    MOV    #P2T09E,ERHEAD ;SET ERROR HEADER
4694 027552 004737 016242          JSR    PC,TSTINT     ;INITIALIZE TEST
4695 027556 004737 016260          JSR    PC,GSTATR     ;CLEAR DRIVE
4696 027562 030052          T2565$
4697 027564 004737 020600          JSR    PC,CHOSHMD    ;GO CHOSE HEAD
4698 027570 013705 013560          MOV    LOLIMW,R5     ;SET TO POSTION HEADS TO LOLIMIT
4699 027574 004737 017760          JSR    PC,POSHMS     ;POSITION HDS TO LOWLIMIT
4700 027600 030052          T2565$
4701 027602 004737 022366          T256$: JSR    PC,GETPOS    ;GET CURRENT POSITION
4702 027606 030052          T2565$
4703 027610 013737 003120 003116    MOV    CURCYL,NEWCYL ;PUT CURRENT INTO NEW
4704 027616 012704 002444          MOV    #T25TBL,R4    ;SET POINTER TO TABLE OF SEEK DIFF FOR RLO1
4705 027622 022737 000001 002312  T258$: CMP    #1,T.DRIVE    ;CHECK TYPE OF DRIVE
4706 027630 001402          BEQ    T2588$       ;BRANCH IF RLO1
4707 027632 012704 002472          MOV    #T25TB2,R4    ;POINT TO THE RLO2 TABLE OF CYLINDERS
4708
4709 027636 012405          T2588$: MOV    (R4)+,R5    ;PUT FIRST IN R5

```

*TEST 7

**SEEK TESTS

```

4710 027640 013701 013562      MOV      HILIMW,R1      ;GET HILIMIT
4711 027644 163701 013560      SUB      LOLIMW,R1      ;SUBTRACT LOLIMIT
4712 027650 021401              CMP      (R4),R1        ;CHECK IF NEW DIFFERENCE IS IN BOUNDS
4713 027652 101073              BHI      T2517##        ;NO - SKIP TEST
4714 027654 060537 003116      ADD      R5,NEWCYL      ;ADD TO PRESENT POSITION
4715 027660 023737 003116 013560  T257##:  CMP      NEWCYL,LOLIMW  ;CHECK IF AT OR PAST LOLIMIT
4716 027666 002004              BGE      9#             ;NO - SKIP
4717 027670 013737 013560 003116      MOV      LOLIMW,NEWCYL ;ELSE SET TO LOLIMIT
4718 027676 000407              BR       11#           ;
4719 027700 023737 003116 013562 9#:      CMP      NEWCYL,HILIMW ;CHECK IF AT HILIMIT OR GREATER
4720 027706 003403              BLE      11#           ;NO - SKIP
4721 027710 013737 013562 003116      MOV      HILIMW,NEWCYL ;ELSE SET FOR HILIMIT
4722 027716              11#:
4723 027716              BGNSUB
                                T7.1:
                                TRAP      C#BSUB
4724 027716 104402              INLOOP              ;CHECK IF IN ERROR LOOP
                                TRAP      C#INLP
4725 027722 104420              BNCOMPLETE 13#      ;NO - SKIP
                                BCC      13#
4726 027724 004737 022366      JSR      PC,GETPOS    ;GET CURRENT POSITION
4727 027730 027774              60#
4728 027732 023737 003120 003116      CMP      CURCYL,NEWCYL ;CHECK IF HEADS AT DESIRED POSITION
4729 027740 001002              BNE      13#          ;NO - SKIP
4730 027742 004737 020664      JSR      PC,ONSWAP    ;ELSE SWAP CURRENT AND NEW CYLINDERS
4731 027746 004737 017206      JSR      PC,XSEEK     ;DO SEEK
4732 027752 027774              60#
4733 027754 012701 005670      MOV      #3000.,R1    ;SET WAIT COUNT
4734 027760 004737 022102      JSR      PC,RDYWAIT   ;WAIT FOR READY
4735 027764 027774              60#
4736 027766 004737 022514      JSR      PC,VERPOS    ;VERIFY POSITION
4737 027772 027774              60#
4738 027774 012737 000002 003032 60#:      MOV      #2,ERRSWI    ;INITIALIZE ERROR SWITCH
4739 030002              ENDSUB
                                L10040:
                                TRAP      C#ESUB
4740 030004 104403              ESCAPE  TST             ;EXIT TEST IF ERROR
                                TRAP      C#ESCAPE
                                .WORD    L10037-.
4741 030010 023737 013562 003116      CMP      HILIMW,NEWCYL ;CHECK IF SEEK WAS TO HILIMIT
4742 030016 001002              BNE      15#          ;NO - SKIP
4743 030020 005405              NEG      R5           ;ELSE SET R5 TO REPEAT DIFF IN REVERSE
4744 030022 000714              BR       T257#
4745 030024 023737 013560 003116 15#:      CMP      LOLIMW,NEWCYL ;TEST IF LAST SEEK WAS TO LOLIMIT
4746 030032 001310              BNE      T257#        ;NO - GO DO SEEK TEST
4747 030034 021437 002316      CMP      (R4),HLMTW   ;CHECK IF ALL TABLE DIFF USED
4748 030040 001276              BNE      T2# R'       ;NO - SKIP
4749 030042 004737 020624      T2517#: JSR      PC, L10040   ;GO SWAP TO HEAD 1 OR END TEST
4750 030046 030052              T2565#
4751 030050 000654              BR       T256#        ;ABORT RETURN
4752 030052              T2565#:
4753 030052              ENDTST
                                L10037:
                                TRAP      C#ETST
4754
4755              .SBTTL *TEST 8      **FORWARD OSCILLATING SEEK
4756 030054              BGNTST              ;TEST 8
    
```

*TEST 8 **FORWARD OSCILLATING SEEK

```

030054
4757 030054 012737 006646 003026      MOV      #P2T10E,ERHEAD ;SET ERROR HEADER
4758 030062 004737 016242                JSR      PC,TSTINT    ;INITIALIZE TEST
4759 030066 004737 016260                JSR      PC,GSTATR   ;CLEAR DRIVE
4760 030072 030350                T2665$
4761 030074 004737 020600                JSR      PC,CHOSHD   ;GO CHOSE HEAD
4762 030100 012705 000001                T266$: MOV      #1,R5      ;LOAD R5 FOR FIRST SEEK
4763 030104 032737 020000 013556      BIT      #MICYL,MISWIW ;TEST IF HI CYLINDER SPECED
4764 030112 001402                BEQ      2$          ;NO - SKIP
4765 030114 013705 013562                MOV      HILIMW,R5   ;ELSE SET UPPER LIMIT
4766 030120 005037 003116                2$: CLR      NEWCYL   ;SET TO SEEK TO CYL 0
4767 030124 032737 040000 013556      BIT      #LOCYL,MISWIW ;CHECK IF LO CYL SPEC'D
4768 030132 001403                BEQ      5$          ;NO - SKIP
4769 030134 013737 013560 003116      MOV      LOLIMW,NEWCYL ;ELSE SET LOWER LIMIT
4770 030142 004737 017206                5$: JSR      PC,XSEEK  ;DO SEEK
4771 030146 030350                T2665$
4772 030150 012701 005670                MOV      #3000.,R1   ;SET WAIT COUNT FOR 120 MS
4773 030154 004737 022102                JSR      PC,RDYWAIT  ;WAIT FOR READY
4774 030160 030350                T2665$
4775 030162 004737 022366                T267$: JSR      PC,GETPOS ;GET HEAD POSITION
4776 030166 030350                T2665$
4777 030170 010537 003116                MOV      R5,NEWCYL  ;LOAD NEW CYLINDER INTO NEWCYL
4778 030174                BGNSUB
                                T8.1:
030174 104402                TRAP     C#BSUB
4779 030176 030174 104402                INLOOP   ;CHECK IF IN ERROR LOOP
030176 104420                TRAP     C#INLP
4780 030200                BNCOMPLETE 18$      ;NO - SKIP
030200 103011                BCC     18$
4781 030202 004737 022366                JSR      PC,GETPOS  ;GET POSITION
4782 030206 030304                60$
4783 030210 023737 003120 003116      CMP      CURCYL,NEWCYL ;CHECK IF HEADS AT DESIRED LOC
4784 030216 001002                BNE     18$          ;NO - SKIP
4785 030220 004737 020664                JSR      PC,ONSWAP   ;SWAP OLD AND NEW
4786 030224 004737 017206                18$: JSR      PC,XSEEK  ;DO SEEK
4787 030230 030304                60$
4788 030232 012701 005670                MOV      #3000.,R1   ;SET WAIT COUNT 120 MS
4789 030236 004737 022102                JSR      PC,RDYWAIT  ;WAIT FOR READY
4790 030242 030304                60$
4791 030244 004737 022514                JSR      PC,VERPOS   ;VERIFY HEAD POSITION
4792 030250 030304                60$
4793 030252 005737 003124                TST      DESSGN      ;TEST IF JUST SEEK REV
4794 030256 001412                BEQ     60$          ;YES - SKIP
4795 030260 005037 003116                CLR      NEWCYL     ;ELSE SET TO SEEK TO 0
4796 030264 032737 040000 013556      BIT      #LOCYL,MISWIW ;CHECK IF LO LIMIT SPEC'D
4797 030272 001754                BEQ     18$          ;NO - SKIP
4798 030274 013737 013560 003116      MOV      LOLIMW,NEWCYL ;ELSE SET LOW LIMIT FOR SEEK
4799 030302 000750                BR      18$
4800 030304 012737 000002 003032 60$: MOV      #2,ERRSWI   ;INIT ERROR SWITCH
4801 030312                ENDSUB
                                L10042:
030312 104403                TRAP     C#ESUB
4802 030314                ESCAPE   TST
030314 104410                TRAP     C#ESCAPE   ;EXIT TEST IF ERROR
030316 000032                .WORD   L10041-
4803 030320 032737 020000 013556      BIT      #MICYL,MISWIW ;TEST IF UPPER LIMIT SPEC D
4804 030326 001004                BNE     20$          ;YES - SKIP

```

*TEST 8

**FORWARD OSCILLATING SEEK

```

4805 030330 005205          INC      R5          ;BUMP R5
4806 030332 020537 002324  CMP      R5,GBND ;ALL CYLINDERS DONE
4807 030336 001311          BNE     T267$      ;NO GO DO NEXT CYLINDER
4808 030340 004737 020624 20$:     JSR     PC,SWAPHD  ;GO SWAP TO HEAD 1 OR END TEST
4809 030344 030350          T2665$          ;ABORT RETURN
4810 030346 000654          BR      T266$     ;GO DO TESTS
4811 030350          T2665$:
4812 030350          ENDTST
         030350          L10041:
         030350 104401          TRAP   C$ETST
    
```

4813

4814

4815 030352
030352

.SBTTL
BGNTST

*TEST 9

**REVERSE OSCILLATING SEEK
;TEST 9

T9::

```

4816 030352 012737 006661 003026  MOV     #P2T11E,ERHEAD ;SET ERROR HEADER
4817 030360 004737 016242          JSR     PC,TSTINT  ;INITIALIZE TEST
4818 030364 004737 016260          JSR     PC,GSTATR  ;CLEAR DRIVE
4819 030370 030646          T2765$
4820 030372 004737 020600          JSR     PC,CHOSHD  ;GO CHOSE HEAD
4821 030376 013737 002316 003116  T275$:  MOV     HLMTW,NEWCYL ;SEEK OUT TO 255.
4822 030404 032737 020000 013556  BIT     #HICYL,MISWIW ;TEST IF UPPER LIMIT SPEC'D
4823 030412 001403          BEQ     2$        ;NO - SKIP
4824 030414 013737 013562 003116  MOV     HILIMW,NEWCYL ;ELSE SET UPPER LIMIT
4825 030422 013705 002322 2$:     MOV     NXTML,R5    ;SET R5 FOR FIRST SEEKS
4826 030426 032737 040000 013556  BIT     #LOCYL,MISWIW ;CHECK IF LO LIMIT SPEC'D
4827 030434 001402          BEQ     5$        ;NO - SKIP
4828 030436 013705 013560          MOV     LOLIMW,R5  ;SET LOWER LIMIT
4829 030442 004737 017206 5$:     JSR     PC,XSEEK   ;DO SEEK
4830 030446 030646          T2765$
4831 030450 012701 005670          MOV     #3000.,R1  ;SET WAIT TO 120 MS
4832 030454 004737 022102          JSR     PC,RDYWAIT ;WAIT FOR DRIVE READY
4833 030460 030646          T2765$
4834 030462 004737 022366  T276$:  JSR     PC,GETPOS  ;GET POSITION
4835 030466 030646          T2765$
4836 030470 010537 003116          MOV     R5,NEWCYL ;SET FOR NEXT SEEK
4837 030474          BGNSUB
    
```

T9.1:

```

4838 030474 104402          TRAP   C$BSUB
4838 030476          INLOOP
4839 030500 104420          TRAP   C$INLP
         030500 103011          RNCOMPLETE 18$   ;NO - SKIP
         030500 004737 022366  BCC     18$
4840 030502 004737 022366          JSR     PC,GETPOS  ;ELSE GET POSITION
4841 030506 030606          60$
4842 030510 023737 003120 003116  CMP     CURCYL,NEWCYL ;CHECK IF AT DESIRED CYL
4843 030516 001002          BNE     18$      ;NO - SKIP
4844 030520 004737 020664          JSR     PC,ONSL?  ;ELSE SWAP OLD AND NEW CYL
4845 030524 004737 017206 18$:     JSR     PC,XSECK   ;DO SEEK
4846 030530 030606          60$
4847 030532 012701 005670          MOV     #3000.,R1  ;SET WAIT FOR 120 MS
4848 030536 004737 022102          JSR     PC,RDYWAIT ;WAIT FOR READY
4849 030542 030606          60$
4850 030544 004737 022514          JSR     PC,VERPOS  ;VERIFY POSITION
4851 030550 030606          60$
4852 030552 005737 003124          TST     DESSGN    ;CHECK IF JUST SEEK FWD
4853 030556 001013          BNE     60$      ;YES - SKIP
4854 030560 013737 002316 003116  MOV     HLMTW,NEWCYL ;ELSE SEEK TO TO 255
    
```

*TEST 9

**REVERSE OSCILLATING SEEK

```

4855 030566 032737 020000 013556          BIT      @#HICYL,MISWIW      ;TEST IF HILIMIT SPEC'D
4856 030574 001753                          BEQ      18$                ;NO - SKIP
4857 030576 013737 013562 003116          MOV      HILIMW,NEWCYL     ;SET TO UPPER LIMIT
4858 030604 000747                          BR       18$
4859 030606 012737 000002 003032 60$:    MOV      @2,ERRSWI        ;INIT ERROR SWITCH
4860 030614
      030614
      030614 104403          ENDSUB
      L10044:
4861 030616
      030616 104410          TRAP     C$ESUB
      030620 000026          ESCAPE   TST                ;EXIT TEST IF ERROR
      .WORD  L10043          TRAP     C$ESCAPE
4862 030622 032737 040000 013556          .WORD   L10043
      BIT      @#LOCYL,MISWIW  ;TEST IF LOLIMIT SPEC'D
4863 030630 001002                          BNE     20$                ;YES - SKIP
4864 030632 005305                          DEC     R5                  ;DEC CYLINDER COUNT
4865 030634 100312                          BPL     T276$              ;IF STILL POSITIVE, DO SEEKS AGAIN
4866 030636 004737 020624 20$:    JSR     PC,SWAPHD          ;GO SWAP TO HEAD 1 OR END TEST
4867 030642 030646                          T2765$
4868 030644 000654                          BR      T275$              ;ABORT RETURN
4869 030646
      T2765$:
4870 030646
      030646
      030646 104401          ENDTST
      L10043:
      TRAP   C$ETST
4871
4872 030650          ENDMOD
4873
4874          .SBTTL  PARAMETER CODING
4875 030650          BGNMOD  HRDPRM
4876 030650          BGNHRD
      .WORD  L10045-L$HARD/2
4877 030652          GPRML  CNTYPE,CNT,1,YES
      .WORD  T$CODE
      .WORD  CNTYPE
      .WORD  1
4878 030660          GPRMA  CSRMSG,CSR,0,160000,177776,YES
      .WORD  T$CODE
      .WORD  CSRMSG
      .WORD  T$LOLIM
      .WORD  T$HILIM
4879 030670          GPRMA  VECMSG,VECT,0,0,776,YES
      .WORD  T$CODE
      .WORD  VECMSG
      .WORD  T$LOLIM
      .WORD  T$HILIM
4880 030700          GPRMD  DRMSG,D .B,0,3400,0,7,YES
      .WORD  T$CODE
      .WORD  DRMSG
      .WORD  3400
      .WORD  T$LOLIM
      .WORD  T$HILIM
4881 030712          GPRML  DRTYPE,TYPDR,1,YES
      .WORD  T$CODE
      .WORD  DRTYPE
      .WORD  1
4882 030720          GPRMD  BRMSG,PRIOR,0,340,0,7,YES
      .WORD  T$CODE
      .WORD  BRMSG
      .WORD  340

```

PARAMETER CODING

	030726	000000				.WORD	T#LOLIM
	030730	000007				.WORD	T#HILIM
4883							
4884	030732				ENDHRD		
						.EVEN	
	030732				L10045:		
4885							
4886	030732	102	125	123	CSRMSG:	.ASCIZ	/BUS ADDRESS/
	030735	040	101	104			
	030740	104	122	105			
	030743	123	123	000			
4887	030746	126	105	103	VECMMSG:	.ASCIZ	/VECTOR/
	030751	124	117	122			
	030754	000					
4888	030755	102	122	040	BRMSG:	.ASCIZ	/BR LEVEL/
	030760	114	105	126			
	030763	105	114	000			
4889	030766	104	122	111	DRTYPE:	.ASCIZ	/DRIVE TYPE = RL01/
	030771	126	105	040			
	030774	124	131	120			
	030777	105	040	075			
	031002	040	122	114			
	031005	060	061	000			
4890	031010	104	122	111	DRMSG:	.ASCIZ	/DRIVE/
	031013	126	105	000			
4891	031016	122	114	061	CNTYPE:	.ASCIZ	/RL11/
	031021	061	000				
4892	031023				ENDMOD		
4893						.EVEN	
4894							
4895	031024				BGNMOD	SFTPRM	
4896	031024				BGNSFT		
	031024	000053				.WORD	L10046-L#SOFT/2
4897							
4899	031026				GPRML	CYLQ,MISWI,1,YES	
	031026	000130				.WORD	T#CODE
	031030	031154				.WORD	CYLQ
	031032	000001				.WORD	1
4900	031034				GPRML	SECQ,MISWI,2,YES	
	031034	000130				.WORD	T#CODE
	031036	031170				.WORD	SECQ
	031040	000002				.WORD	2
4906							
4908	031042				GPRML	LOLIMQ,MISWI,40000,YES	
	031042	000130				.WORD	T#CODE
	031044	031205				.WORD	LOLIMQ
	031046	040000				.WORD	40000
4909	031050				XFERF	1#	
	031050	006044				.WORD	T#CODE
4910	031052				GPRMD	LIMVAL,LOLIM,D,255.,0,253.,YES	
	031052	001052				.WORD	T#CODE
	031054	031224				.WORD	LIMVAL
	031056	000377				.WORD	255.
	031060	000000				.WORD	T#LOLIM
	031062	000375				.WORD	T#HILIM
4911	031064				1#:	GPRML	HILIMQ,MISWI,20000,YES
	031064	000130				.WORD	T#CODE

118

PARAMETER CODING

031066	031232				.WORD	HILIMQ
031070	020000				.WORD	20000
4912 031072					XFERF	28
031072	006044				.WORD	T\$CODE
4913 031074					GPRMD	LIMVAL ,HILIM,D,255.,0,255.,YES
031074	002052				.WORD	T\$CODE
031076	031224				.WORD	LIMVAL
031100	000377				.WORD	255.
031102	000000				.WORD	T\$LOLIM
031104	000377				.WORD	T\$HILIM
4914 031106				28:	GPRML	HEADQ,MISWI,10000,YES
031106	000130				.WORD	T\$CODE
031110	031253				.WORD	HEADQ
031112	010000				.WORD	10000
4915 031114					XFERF	38
031114	006044				.WORD	T\$CODE
4916 031116					GPRMD	HEADV,HEAD,D,17,0,1,YES
031116	003052				.WORD	T\$CODE
031120	031275				.WORD	HEADV
031122	000017				.WORD	17
031124	000000				.WORD	T\$LOLIM
031126	000001				.WORD	T\$HILIM
4918 031130				38:	GPRMD	ERLIMQ,ERLIM,D,377,0,377,YES
031130	004052				.WORD	T\$CODE
031132	031320				.WORD	ERLIMQ
031134	000377				.WORD	377
031136	000000				.WORD	T\$LOLIM
031140	000377				.WORD	T\$HILIM
4920 031142					GPRMD	DCLIMQ,DCLIM,D,377,1,377,YES
031142	005052				.WORD	T\$CODE
031144	031342				.WORD	DCLIMQ
031146	000377				.WORD	377
031150	000001				.WORD	T\$LOLIM
031152	000377				.WORD	T\$HILIM
4922 031154					ENDSFT	
					.EVEN	
031154					L10046:	
4923						
4925 031154	125	123	105	CYLQ:	.ASCIZ	/USE ALL CYL/
031157	040	101	114			
031162	114	040	103			
031165	131	114	000			
4926 031170	125	123	105	SECQ:	.ASCIZ	/USE ALL SECT/
031173	040	101	114			
031176	114	040	123			
031201	105	103	124			
031204	000					
4933 031205	114	117	127	LOLIMQ:	.ASCIZ	/LOW SEEK LIMIT/
031210	040	123	105			
031213	105	113	040			
031216	114	111	115			
031221	111	124	000			
4934 031224	126	101	114	LIMVAL:	.ASCIZ	/VALUE/
31227	125	105	000			
4935 031232	125	120	120	HILIMQ:	.ASCIZ	/UPPER SEEK LIMIT/
031235	105	122	040			
031240	123	105	105			

PARAMETER CODING

	031243	113	040	114	
	031246	111	115	111	
	031251	124	000		
4936	031253	125	123	105	HEADQ: .ASCIZ /USE ONLY ONE SURF/
	031256	040	117	116	
	031261	114	131	040	
	031264	117	116	105	
	031267	040	123	125	
	031272	122	106	000	
4937	031275	127	110	101	HEADV: .ASCIZ /WHAT SURF (0 OR 1)/
	031300	124	040	123	
	031303	125	122	106	
	031306	040	050	060	
	031311	040	117	122	
	031314	040	061	051	
	031317	000			
4939	031320	111	116	120	ERLIMQ: .ASCIZ /INPUT ERROR L MIT/
	031323	125	124	040	
	031326	105	122	122	
	031331	117	122	040	
	031334	114	111	115	
	031337	111	124	000	
4941	031342	104	101	124	DCLIMQ: .ASCIZ /DATA CMP ERR LMT/
	031345	101	040	103	
	031350	115	120	040	
	031353	105	122	122	
	031356	040	114	115	
	031361	124	000		
4943					.EVEN
4944	031364				ENDMOD
4945					
4946	031364				LASTAD
					.EVEN
	031364	000000			.WORD 0
	031366	000000			.WORD 0
	031370				L\$LAST::
4947					
4948		000001			.END

SYMBOL TABLE

ADR	000020	G	CLKCSR	172540	C\$MEM	000031	EF_STA	000040	G	FMT9	011212	
AFMID	003224	CLKCTR	172544	C\$MSG	000023	ERHEAD	003026	FOLWRT	000100	FRMWD	007473	
AFMIDU	003226	CLKFLG	003504	C\$OPEN	000034	ERLIM	000010	FRMWD	007473	FWDSDO	002000	
ALLCYL	000001	CLNCOD	015152	G	C\$PNTB	000014	ERLIMQ	031320	FWDSDO	002000	FWDSDS	000400
ALLSEC	000002	CLRBYT	002320	C\$PNTF	000017	ERLIMW	013566	ERRCNT	003254	F\$AU	000015	
ANERR	100000	CLRPAR	025772	C\$PNTS	000016	ERRPOI	003252	FRRSWI	003032	F\$AUTO	000020	
ARMID	003230	CNT	000012	C\$PNTX	000015	ERRVEC	003244	ERR1	011724	F\$BGN	000040	
ARMIDU	003232	CNTYPE	031016	C\$QIO	000377	ERR10	013320	G	ERR2	011772	F\$CLEA	000007
ASSEMB	000010	COMPDP	007777	C\$RDBU	000007	ERR2	011772	G	ERR3	012040	F\$DU	000016
BADADD	004000	CONING	000004	C\$REFG	000047	ERR3	012040	G	ERR4	012106	F\$END	000041
BAMSK	000060	CONTIN	014044	C\$RESE	000033	ERR4	012106	G	ERR5	012156	F\$HARD	000004
BANAM	006243	COSTAT	000040	C\$REVI	000003	ERR5	012156	G	ERR6	012226	F\$HM	000013
BASADD	006141	COUNT	003250	C\$RFLA	000021	ERR6	012226	G	ERR7	013110	F\$INIT	000006
BELL	010555	CROYMS	000200	C\$RPT	000025	ERR7	013110	G	ERR8	013160	F\$JMP	000050
BHSTAT	000010	CSNAM	006236	C\$SEFG	000046	ERR8	013160	G	ERR9	013254	F\$MOT	000000
BIT0	000001	CSR	000000	C\$SPRI	000041	EVL	000004	G	EXACYL	003240	F\$MS	000011
BIT00	000001	CSRMSG	030732	C\$SVEC	000037	EXACYL	003240	EXOCYL	003234	F\$PROT	000021	
BIT01	000002	CURCYL	003120	C\$TPRI	000013	EXROT	003242	E\$END	002100	F\$PWR	000017	
BIT02	000004	CYLQ	031154	C10MS	010634	E\$LOAD	000035	FBSFIL	003706	F\$RPT	000012	
BIT03	000010	CYLTBL	002620	C5SEC	010673	FMTOP1	010701	FMTOP2	010730	F\$SEG	000003	
BIT04	000020	CYLUP	000004	DANAM	006250	FMTOP3	010752	FMT1	010773	F\$SOFT	000005	
BIT05	000040	CYLD	007466	DATA	000001	FMT1.1	011000	FMT11	011217	F\$SRV	000010	
BIT06	000100	C\$AU	000052	DATACM	023344	FMT12	011225	FMT13	011233	F\$SUB	000002	
BIT07	000200	C\$AUTO	000061	DATCOM	023344	FMT14	011277	FMT15	011331	F\$SW	000014	
BIT08	000400	C\$BRK	000022	DATGEN	023204	FMT16	011365	FMT17	011376	F\$TEST	000001	
BIT09	001000	C\$BSEG	000004	DCKERR	004000	FMT18	011420	FMT19	011452	GBND	002324	
BIT1	000002	C\$BSUB	000002	DCLIM	000012	FMT2	011007	FMT20	011507	GETPOS	022366	
BIT10	002000	C\$CEFG	000045	DCLIMQ	031342	FMT21	011537	FMT22	011562	GETSTA	000003	
BIT11	004000	C\$CLCK	000062	DCLIMW	013570	FMT23	011616	FMT24	011632	GLBDAT	002240	G
BIT12	010000	C\$CLEA	000012	DESDIF	003122	FMT25	011637	FMT26	011647	GLBEQA	002240	G
BIT13	020000	C\$CLOS	000035	DESHD	003126	FMT27	011673	FMT28	011712	GLBERR	011724	G
BIT14	040000	C\$CLP1	000006	DESSEC	003130	FMT3	011012	FMT4	011015	GLBSUB	015304	G
BIT15	100000	C\$CVEC	000036	DESSGN	003124	FMT5	011026	FMT6	011046	GLBTXT	005360	G
BIT2	000004	C\$DCLN	000044	DIAGMC	000000	FMT7	011110	FMT8	011160	GSTAT	016310	
BIT3	000010	C\$DODU	000051	DIFAUG	003112	DRMSG	031010	DRSB	000010	GSTATC	016274	
BIT4	000020	C\$DRPT	000024	DIFWD	007442	DRSEL	000004	DRSET	000010	GSTATG	016320	
BIT5	000040	C\$DU	000053	DIRBIT	000004	DRTYPE	030766	DRVERR	040000	GSTATR	016260	
BIT6	000100	C\$EDIT	000003	DIRMSK	002330	DRVCNT	003110	DRVNAM	006152	GTSTAT	000104	
BIT7	000200	C\$ERDF	000055	DLTERR	010000	DSMSK	001400	DSESTA	000400	G\$CNTD	000200	
BIT8	000400	C\$ERRR	000056	DONE	003022	DSPCOD	013572	EF.CON	000036	G\$DELM	000372	
BIT9	001000	C\$ERRO	000060	DRDYS	000001	EF.CON	000036	G	EF.NEW	000035	G\$DISP	000003
BOE	000400	C\$ERSF	000054	DRMSG	031010	EF.PWR	000034	G	EF.RES	000037	G\$EXCP	000400
BRMSG	030755	C\$ERSO	000057	DRSB	000010	EF.PWR	000034	G	EF.RES	000037	G\$HILI	000002
BSCHK	024372	C\$ESCA	000010	DRSELT	000004	EF.PWR	000034	G	EF.RES	000037	G\$LOLI	000001
BSFLAG	003034	C\$ESEG	000005	DRSET	000010	EF.PWR	000034	G	EF.RES	000037	G\$NO	000000
BSFVAL	003510	C\$ESUB	000003	DRTYPE	030766	EF.PWR	000034	G	EF.RES	000037	G\$OFFS	000400
BSNSTR	007550	C\$ETST	000001	DRVCNT	003110	EF.PWR	000034	G	EF.RES	000037	G\$OFFSI	000376
BYPSPM	007501	C\$EXIT	000032	DRVERR	040000	EF.PWR	000034	G	EF.RES	000037	G\$PRMA	000001
CAFDI	010662	C\$GETB	000026	DRVNAM	006152	EF.PWR	000034	G	EF.RES	000037	G\$PRMD	000002
CAMSK	002326	C\$GETW	000027	DRVNAV	006157	EF.PWR	000034	G	EF.RES	000037	G\$PRML	000000
CCYLUP	010653	C\$GMAN	000043	DSESTA	000400	EF.PWR	000034	G	EF.RES	000037	G\$RADA	000140
CHOSHD	020600	C\$GPHR	000042	DSMSK	001400	EF.PWR	000034	G	EF.RES	000037	G\$RADB	000000
CKBSVD	020710	C\$GPLO	000030	DSPCOD	013572	EF.PWR	000034	G	EF.RES	000037	G\$RADD	000040
CKDATA	000102	C\$GPRI	000040	EF.CON	000036	EF.PWR	000034	G	EF.RES	000037	G\$RADL	000120
CKERLM	015712	C\$INIT	000011	EF.CON	000036	EF.PWR	000034	G	EF.RES	000037	G\$RADO	000020
CLKADR	003506	C\$INLP	000020	EF.CON	000036	EF.PWR	000034	G	EF.RES	000037	G\$XFER	000004
CLKCSB	172542	C\$MANI	000050	EF.CON	000036	EF.PWR	000034	G	EF.RES	000037		

SYMBOL TABLE

G#YES	000010	I#INIT	000041	L#EXP1	002046 G	L10030	026660	MOPERR	010245
HADONE	003024	I#MOD	000041	L#EXP4	002064 G	L10031	027106	MORECE	003030
HCESTA	040000	I#MSG	000041	L#EXP5	002066 G	L10032	027104	MOUTIN	005570
HCR CER	004000	I#PROT	000040	L#HARD	030652 G	L10033	027314	MPNAM	006255
HDA LIG	000010	I#PTAB	000041	L#HIME	002120 G	L10034	027276	MQUALS	003760
HDCYL	002332	I#PWR	000041	L#HPCP	002016 G	L10035	027542	MREAD	005364
HDMSEL	000100	I#RPT	000041	L#HPPT	002022 G	L10036	027540	MREADH	005375
HDMOVF	007323	I#SEG	000041	L#HW	013540 G	L10037	030052	MRESKO	005766
HDRCMP	000002	I#SETU	000041	L#ICP	002104 G	L10040	030002	MREVSK	005650
HDR40	100000	I#SFT	000041	L#INIT	013616 G	L10041	030350	MRLFAL	010442
H0SEC	000077	I#SRV	000041	L#LADP	002026 G	L10042	030312	MRSLT	005536
H0SEL	000020	I#SUB	000041	L#LAST	031370 G	L10043	030646	MSEEK	005360
H0WD	007455	I#TST	000041	L#LOAD	002100 G	L10044	030614	MSPERR	010143
H0WRD1	003066	JJJ	002314	L#LUN	002074 G	L10045	030732	MSTERR	010176
H0WRD2	003070	J#JMP	000167	L#MREV	002050 G	L10046	031154	MTMBS	006120
H0WRD3	003072	LAB	014016	L#NAME	002000 G	MAJINC	003502	MTOSLO	006316
HEAD	000006	LABACF	007273	L#PRIO	002042 G	MAPROX	007153	MLOAD	005547
HEADLM	010000	LABACR	007307	L#PROT	013530 G	MBADAD	006022	MUNDEF	010375
HEADQ	031253	LABEXP	007206	L#PRT	002112 G	MBADSF	006043	MUDERR	010230
HEADV	031275	LABHCF	007243	L#REPP	002062 G	MBSETO	000001	MUGERR	010161
HEADW	013564	LABHCR	007257	L#REV	002010 G	MCERR	007771	MWORD	006310
HFIN	003204	LABIN	007163	L#SOFT	031026 G	MCONHN	006407	MWRCHK	005405
HFINU	003206	LABMID	007171	L#SPC	002056 G	MCYLOC	010345	MWRITE	005416
HFOUT	003210	LABOCF	007217	L#SPCP	002020 G	MCYLUP	005560	MWRSET	005513
HFOUTU	003212	LABOCR	007231	L#SPTP	002024 G	MDATCP	005442	MWRTAB	010501
HICYL	020000	LABOUT	007200	L#STA	002030 G	MDCRC	010013	MACHDR	005477
HILIM	000004	LAB1	006262	L#SW	013556 G	M0HEDR	002000 G	NEWCYL	003116
HILIMQ	031232	LAB2	006275	L#TEST	002114 G	MDLT	010040	NOCLR	000010
HILIMW	013562	LIMVAL	031224	L#TIML	002014 G	MDRDY	007760	NOCTLR	007645
HLMTW	002316	LOCERR	003460	L#UNIT	002012 G	MDRERR	010102	NOERCT	003461
HNFERR	010000	LOCYL	040000	L.BA	003052	MDRRES	006336	NOIRPT	000002
H0E	100000 G	LOE	040000 G	L.CS	003050	MDRVST	010130	NOOP	000100
H0STAT	000020	LOLIM	000002	L.DA	003054	MDSERR	010113	NOPIR	006176
HPTCOD	013536 G	LOLIMQ	031205	L.MP	003056	MERRS	010550	NOTRDY	007703
HRDPRM	030650 G	LOLIMW	013560	L10000	011770	MEXERS	010513	NXMERR	020000
HRDWT	026022 G	LOT	000010 G	L10001	012036	MFLERR	010272	NXTML	002322
HRIN	003214	L#ACP	002110 G	L10002	012104	MFMTER	006073	NXTPAS	014064
HRINW	003216	L#APT	002036 G	L10003	012154	MFLWR	005630	OBUFF	004502
HR0U	003220	L#AUT	002070 G	L10004	012224	MFWDSK	005701	OFIN	003154
HR0JTU	003222	L#AUTO	014614 G	L10005	013106	MFWSKO	005732	OFINU	003156
HMSK	000100	L#CCP	002106 G	L10006	013156	MGTSTA	005430	OFMID	003160
HSSSTAT	000100	L#CLEA	015152 G	L10007	013252	MHCERR	010212	OFMIDU	003162
IBE	010000 G	L#CO	002032 G	L10010	013316	MHDERR	010255	OFOUT	003164
IBUFF	004102	L#DEPO	002011 G	L10011	013526	MMDRCP	005461	OFOUTU	003166
IDU	000040 G	L#DESC	002122 G	L10013	013554	MHFRC	010052	OLDCYL	003114
IER	020000 G	L#DESP	002076 G	L10014	013572	MHW	010024	ONSWAP	020664
INITCO	013616 G	L#DEVP	002060 G	L10015	014612	MININC	003472	OPFLAG	003020
INDUTS	000020	L#DISP	013574 G	L10016	015150	MINOUT	005607	OPIERR	002000
INTEBL	000100	L#DLY	002116 G	L10017	015276	MISWI	000000	OPMSG	002240
INTMLR	015632	L#DTP	002040 G	L10020	015302	MISWIW	013556	OPR004	007425
ISR	000100 G	L#DTYP	002034 G	L10021	015630	MITEST	100000	OPR1A	007376
IXE	004000 G	L#DU	015300 G	L10022	015710	MNDRST	010352	OPR1B	007402
I#AU	000041	L#DUT	002072 G	L10023	026242	MNEERR	010320	OPR12	007357
I#AUTO	000041	L#DVTY	002226 G	L10024	026224	MNOCLR	006423	ORIN	003170
I#CLN	000041	L#EF	002052 G	L10025	026452	MNOINT	006354	ORINU	003172
I#DU	000041	L#ENVI	002044 G	L10026	026450	MOPER	005527	ORMID	003174
I#HRD	000041	L#ETP	002102 G	L10027	026662			ORMIDU	003176

SYMBOL TABLE

OROUT	003200	P2T12E	006674	STATE2	010604	T#TAGL	= 177777	T276#	030462
OROUTL	003202	P2T13E	006706	STATE3	010614	T#TAGN	= 010047	T2765#	030646
OUTINS	= 000040	P2T14E	006722	STATE5	010624	T#TEMP	= 000000	T3	026454 G
O#APTS	= 000000	P2T15E	006743	STOSTA	= 010000	T#TEST	= 000011	T3.1	026524
O#AU	= 000000	P2T16E	006766	SUBSTK	002420	T#TSTM	= 177777	T33TBL	002520
O#BGNR	= 000000	P2T17E	007007	SVCBGL	= 000001	T#TSTS	= 000001	T4	026664 G
O#BGNS	= 000001	P2T18E	007041	SVCGBL	= 000000	T#AUT	= 010016	T4.1	026752
O#DU	= 000001	P2T19E	007063	SVCINS	= 000000	T#CLE	= 010017	T5	027110 G
O#ERRT	= 000000	RDALMD	022636	SVCSUB	= 000001	T#DU	= 010020	T5.1	027146
O#GNSW	= 000001	RDDATA	= 000114	SVCTAG	= 000000	T#HAR	= 010045	T6	027316 G
O#POIN	= 000001	RDHEAD	= 000110	SVCTST	= 000001	T#HM	= 010013	T6.1	027404
O#SETU	= 000000	RDNOHR	= 000116	SWAPHD	020624	T#INI	= 010015	T7	027544 G
PART2	= 000001 G	RDYCHK	020324	S#LSYM	= 010000	T#MSG	= 010011	T7.1	027716
PASCNT	003246	RDYWAI	022102	TAG	003500	T#PRO	= 010012	T8	030054 G
PASNEW	014072	READRL	016052	TBLSTR	003040	T#SEG	= 010000	T8.1	030174
PASNUM	003454	RELDWT	= 040000	TBT	002560	T#SOF	= 010046	T9	030352 G
PATTBL	002374	RESE3	010561	TCERR	007624	T#SRV	= 010022	T9.1	030474
PAT1	005102	RESE4	010565	TEMP	003474	T#SUB	= 010044	UAM	= 000200 G
PAT10	005356	RESE5	010572	TEMPO	003132	T#SW	= 010014	ULCAD	= 000010
PAT2	005104	RESE6	010577	TEMP1	003134	T#TES	= 010043	UNDTST	007412
PAT3	005144	RESPAR	003076	TEMP2	003136	T.BA	003062	UNIXERR	006464
PAT4	005204	RESTAR	014034	TEMP3	003140	T.CS	003060	VALDES	007127
PAT5	005244	RESTBL	002334	TEMP4	003142	T.DA	003064	VCNRST	006443
PAT6	005252	REVSKE	= 001000	TEMP5	003144	T.DRIV	002312	VCSTAT	= 001000
PAT7	005312	REVSKE	= 000200	TEMP6	003146	T.MP	003066	VECMG	030746
PAT8	005314	RLBA	= 000002	TEMP7	003150	T.STAT	003074	VECT	= 000002
PAT9	005354	RLBAS	003042	TEMP8	003152	T1	026022 G	VERHDR	021506
PH65#	020266	RLCS	= 000000	TIME	015304	T1.1	026056	VERPOS	022514
PNT	= 001000 G	RLCSR	= 000000	TIM.US	003476	T1965#	026242	WAITIN	016104
POSHDS	017760	RLDA	= 000004	TOSLOW	= 000001	T197#	026046	WCMASK	= 017777
POSHDO	022056	RLDRV	003046	TRPFLG	003462	T2	026244 G	WCRNG	= 160000
POSHSB	022052	RLMP	= 000006	TRPHAN	015624	T2.1	026314	WDESTA	= 100000
POSHW1	022044	RLVEC	003044	TSTINT	016242	T206#	026316	WGESTA	= 002000
PRI	= 002000 G	RORMOP	= 020000	TSTLAB	006501	T2065#	026452	WLSTAT	= 020000
PRIOR	= 000004	RPTOP	024542	TYPDR	= 000006	T216#	026526	WRTSWI	003036
PRI00	= 000000 G	RPTREM	025536	T#ARGC	= 000010	T2165#	026662	WTDATA	= 000112
PRI01	= 000040 G	RPTRES	025330	T#CODE	= 005052	T2265#	027106	XDELAY	003466
PRI02	= 000100 G	RSTR	013752	T#ERRN	= 001275	T227#	026754	XRDHD	021052
PRI03	= 000140 G	SAMSK	= 000077	T#EXCP	= 000000	T233#	027134	XRDHDC	021042
PRI04	= 000200 G	SBSFIL	003512	T#FLAG	= 000040	T2365#	027314	XRDHDG	021056
PRI05	= 000240 G	SECQ	031170	T#GMAN	= 000000	T2465#	027542	XREAD	023674
PRI06	= 000300 G	SECWD	007461	T#HILI	= 000377	T247#	027406	XREADG	023702
PRI07	= 000340 G	SEEK	= 000106	T#LAST	= 000001	T25TBL	002444	XSEEK	017206
PSETNM	003456	SEEKOP	= 010000	T#LOLI	= 000001	T25TB2	002472	XSEEKT	017176
PWCON	014342	SEQMES	007514	T#LSYM	= 010000	T2517#	030042	XSEEK1	017212
PWRFLG	003464	SETDON	014120	T#LTNO	= 000011	T256#	027602	XTIME	015450
P2T03E	006507	SFTPRM	031024 G	T#NEST	= 177777	T2565#	030052	XWRITE	023634
P2T04E	006525	SGMMD	007450	T#NSO	= 000000	T257#	027654	XWRIT	023624
P2T05E	006545	SKTMES	007073	T#NS1	= 000005	T258#	027622	XWRIT1	023640
P2T06E	006565	SPOSTA	= 004000	T#NS2	= 000002	T258#	027636	X#ALWA	= 000000
P2T07E	006605	SPTCOD	013554 G	T#PTNU	= 000000	T266#	030100	X#FALS	= 000040
P2T08E	006623	SRTMES	007105	T#SAVL	= 177777	T2665#	030350	X#OFFS	= 000400
P2T09E	006643	SSINX	003016	T#SEGL	= 177777	T267#	030162	X#TRUE	= 000020
P2T10E	006646	STAMES	007537	T#SEKO	= 010000	T275#	030376	YDELAY	003470
P2T11E	006661	STAMSK	= 000007	T#SUBN	= 000001				

. ABS. 031370 000

f 1

SYMBOL TABLE

000000 001
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 29072 WORDS (114 PAGES)
DYNAMIC MEMORY: 20060 WORDS (77 PAGES)
ELAPSED TIME: 00:27:14
CNRLJA.BIN,CNRLJA.LST/-SP=SVC34.MLB/ML,CNRLJA.MAC

•