

11/21+  
RL01/02

RL01/2 PERF EXER  
CNRLKAO

COPYRIGHT (c) 1979-83  
AH-T752A-MC  
FICHE 1 OF 1

APR 1984  
digital  
Made In USA

This microfiche card contains a grid of frames. The first three columns of frames contain header information, including the document title 'RL01/2 PERF EXER CNRLKAO' and the document number '11/21+'. The remaining frames contain data organized in columns and rows, likely representing performance metrics or exercise results. The data is presented in a structured, tabular format across the entire card.



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
49  
50  
51

000000

.TITLE CNRLKAO RL01/02 PERF EXER  
.NLIST TOC  
.ENABLE AMA  
.ENABLE ABS  
.REM @

IDENTIFICATION

PRODUCT CODE: AC-T751A-MC  
PRODUCT NAME: CNRLKAO RL01/2 PERFORMANCE EXERCISER  
PRODUCT DATE: DECEMBER 19, 1983  
MAINTAINER: ISS DIAGNOSTIC SERVICES  
AUTHOR: JAMES S. DOUCETTE

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1983, DIGITAL EQUIPMENT CORPORATION

53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87

## REVISION HISTORY

-----

CHANGES MADE TO CZRLKBO IN PRODUCING CNRLKAO FOR THE SBC-11/21+ (FALCON-PLUS),  
DEC. 19, 1983. CHANGES ARE IDENTIFIED BY ";JSD REV A".

1. CHANGED THE FORM OF THE ARGUMENT TO ALL "DELAY" AND "WAITUS" MACRO  
CALLS FROM #<VALUE> TO <VALUE>. THE FORMER GAVE ASSEMBLY ERRORS  
UNDER THE VAX/VMS DEVELOPMENT ENVIRONMENT (MCR MAC).
2. CHANGED THE WAITMS MACRO DEFINITION SO THAT "ARG" IS USED AS A DELAY  
COUNTER, RATHER THAN "#ARG".
3. CHANGED THE GENERAL OPERATING PRIORITY OF THE PROGRAM FROM LEVEL 7 TO  
LEVEL 6 TO ALLOW THE "BREAK" KEY TO INVOKE ODT. (THE TRAP  
HANDLER AND CLOCK INTERRUPT SERVICE ROUTINES STILL RUN BRIEFLY  
AT LEVEL 7).
4. SET VECTOR 140 WITH THE ADDRESS OF ODT IN ROM (170000).
5. FORCED THE PROGRAM TO ASSUME THAT NO CLOCK IS PRESENT. AS A RESULT,  
(A) REMOVED THE ELAPSED TIME FROM ONLY THOSE FORMATTED MESSAGES  
WHICH COULD BE PRINTED (I.E., SOME TIME MESSAGES WILL NEVER  
BE PRINTED), (B) REMOVED THE DROPPED / RUNNING MESSAGE PRINTED  
IN THE STATISTIC REPORT, AND (C) REMOVED THE SW QUESTION  
REGARDING THE TIME BETWEEN REPORTS. REASON: UNDER FALCON-PLUS,  
CLOCK OPERATION IS NOT GUARANTEED. CLOCK INTERRUPTS MAY OR MAY  
NOT BE HARD-ENABLED, AND EVEN IF THEY WERE, THE INTERRUPT RATE  
COULD BE 50, 60, OR 800 HERTZ. FURTHERMORE, THE DRS CLOCK  
MACROS RETURN MISLEADING INFORMATION (UNDER FALCON-PLUS).

D.

89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117  
118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132

TABLE OF CONTENTS

-----

1.0	GENERAL INFORMATION
1.1	PROGRAM ABSTRACT
1.1.1	STRUCTURE OF PROGRAM
1.1.2	DIAGNOSTIC INFORMATION
1.2	SYSTEM REQUIREMENTS
1.2.1	HARDWARE REQUIREMENTS
1.2.2	SOFTWARE REQUIREMENTS
1.3	RELATED DOCUMENTS AND STANDARDS
1.4	DIAGNOSTIC HIERARCHY PREREQUISITES
1.5	ASSUMPTIONS
2.0	OPERATING INSTRUCTIONS
2.1	HOW TO RUN THIS DIAGNOSTIC
2.1.1	THE FIVE STEPS OF EXECUTION
2.1.2	SAMPLE RUN-THROUGH
2.2	CHAIN MODE OPERATION
2.3	DETAILS OF COMMANDS AND SYNTAX
2.3.1	TABLE OF COMMAND VALIDITY
2.3.2	COMMAND SYNTAX
2.4	EXTENDED P-TABLE DIALOGUE
2.5	HARDWARE PARAMETERS
2.6	SOFTWARE PARAMETERS
3.0	ERROR INFORMATION
3.1	ERROR REPORTING
3.2	ERROR HALTS
4.0	PERFORMANCE AND PROGRESS REPORTS
4.1	PERFORMANCE REPRORTS
4.2	PROGRESS REPORTS
5.0	DEVICE INFORMATION TABLES
6.0	TEST SUMMARIES

134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167  
168  
169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190

1.0 GENERAL INFORMATION  
-----

1.1 PROGRAM ABSTRACT  
-----

1.1.1 STRUCTURE OF PROGRAM  
-----

THIS DIAGNOSTIC IS COMPATIBLE WITH BOTH CNDP+ AND ACT. IT CAN BE RUN STANDALONE UNDER CNDP+, AND CAN BE CHAINED UNDER CNDP+, ACT AND APT IN ACT MODE (SEE 2.2 "CHAIN MODE OPERATION" FOR DETAILS OF CHAINING PROCEDURE). IT IS A SINGLE PROGRAM FROM THE STANDPOINT OF THE DIAGNOSTIC USER, WHICH AT RUN TIME IS APPENDED TO A COMMON FRONT-END PIECE OF SUPERVISOR SOFTWARE THROUGH WHICH THE DIAGNOSTIC PROGRAM INTERFACES TO THE ENVIRONMENT AS IT EXECUTES. (IN THIS DOCUMENT, "CNDP+" REFERS TO THE FALCON-SPECIFIC XXDP+ SYSTEM).

WHEN THIS DIAGNOSTIC IS STARTED, CONTROL GOES FIRST TO THE SUPERVISOR PORTION, WHICH WILL ASK CERTAIN "HARD CORE" QUESTIONS ABOUT THE ENVIRONMENT. THEN IT WILL ENTER COMMAND MODE, INDICATED BY A PROMPT CHARACTER (DR>). AT COMMAND MODE THE OPERATOR MAY ENTER ANY OF SEVERAL COMMANDS AS DESCRIBED IN 2.0 "OPERATING INSTRUCTIONS".

THE DIAGNOSTIC PROGRAM IS LOADED IN THE LOWER 8K OF MEMORY. THE DIAGNOSTIC SUPERVISOR CODING OCCUPIES 6.25K OF THE UPPER PART OF MEMORY JUST BELOW THE CNDP+ MONITOR WHICH RESIDES IN THE UPPERMOST 1.5K OF MEMORY SPACE.

1.1.2 DIAGNOSTIC INFORMATION  
-----

THE RL11/RLV11 RL01/02 EXERCISER IS A KXT-11 (SBC-11/21+) BASED PROGRAM. IT WILL RANDOMLY EXERCISE UP TO 2 CONTROLLERS AND 8 DRIVES. AFTER AN INITIAL WRITE OF EACH RL01/02, THE DRIVES ARE RANDOMLY PICKED AND GIVEN A RANDOM STRING FUNCTION OF:

1. SEEK, WRITE, WRITE-CHECK
2. SEEK, READ DATA, DATA COMPARE
3. SEEK, READ HEADERS, READ 1 SECTOR W/NO HEADER COMPARE, GET STATUS
4. SEEK, READ, READ

1.2 SYSTEM REQUIREMENTS  
-----

1.2.1 HARDWARE REQUIREMENTS  
-----

192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217  
218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237  
238  
239  
240  
241  
242  
243  
244  
245  
246

- \* SBC 11/21+ PROCESSOR, 28KW MEMORY, JUMPERED FOR MEMORY MAP 0
- \* CONSOLE DEVICE (LA30,LA36,VT50,ETC.)
- \* 1 OR 2 RL11/RLV11 CONTROLLER(S) WITH:
  - 1 - 8 RL01 DRIVES WITH RL01K CARTRIDGES CONTAINING A 'BAD SECTOR FILE'
  - 1 8 RL02 DRIVES WITH RL02K CARTRIDGES CONTAINING A BAD SECTOR FILE'
- \* CNDP+ (XXDP+) LOAD DEVICE (RL02, RX02, ETC.)
- \* LINE PRINTER (OPTIONAL)

#### 1.2.2 SOFTWARE REQUIREMENTS

-----

CNRLKAO RL11/RLV11 RL01/RL02 PERFORMANCE EXERCISER  
(FORMERLY CZRLEBO)

#### 1.3 RELATED DOCUMENTS AND STANDARDS

-----

RL01 DISK SUBSYSTEM USER'S GUIDE (EK-RL01-UG-002)  
XXDP+/SUPERVISOR USER'S MANUAL

#### 1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

-----

THE RL01/02 SUBSYSTEM SHOULD HAVE SUCCESSFULLY RUN THE FOLLOWING PROGRAMS:

CVRLABC	RLV11 RL01 DISKLESS TEST (RLV11 ONLY)
CNRLGAO	RL11/RLV11 RL01/02 CONTROLLER TEST (PART 1)
CNRLHAO	RL11/RLV11 RL01/02 CONTROLLER TEST (PART 2)
CNRLIAO	RL01/02 DRIVE TEST (PART 1)
CNRLJAO	RL01/02 DRIVE TEST (PART 2)

#### 1.5 ASSUMPTIONS

-----

THE HARDWARE OTHER THAN THE RL01 SUBSYSTEM IS ASSUMED TO WORK PROPERLY. FALSE ERRORS MAY BE REPORTED IF THE PROCESSOR, ETC., DO NOT FUNCTION PROPERLY.

#### 2.0 OPERATING INSTRUCTIONS

-----

248  
249  
250  
251  
252  
253  
254  
255  
256  
257  
258  
259  
260  
261  
262  
263  
264  
265  
266  
267  
268  
269  
270  
271  
272  
273  
274  
275  
276  
277  
278  
279  
280  
281  
282  
283  
284  
285  
286  
287  
288  
289  
290  
291  
292  
293  
294  
295  
296  
297  
298  
299  
300  
301  
302  
303  
304

## 2.1 HOW TO RUN THIS DIAGNOSTIC

### 2.1.1 THE FIVE STEPS OF EXECUTION

THIS DIAGNOSTIC PROGRAM SHOULD BE LOADED AND STARTED USING NORMAL XXDP+ PROCEDURES. START THE EXECUTION OF THE CNDP+ MONITOR BY USING THE APPROPRIATE BOOTSTRAP PROGRAM. THE MONITOR WILL PRINT A MESSAGE IDENTIFYING ITSELF AND REQUESTING THAT THE CURRENT DATE BE ENTERED. AN EXAMPLE OF THIS MESSAGE IS GIVEN BELOW FOR THE CNDP+ MONITOR:

```
CNDP+ CNDP+ BY MONITOR
BOOTED VIA UNIT 0
ENTER DATE (DD-MMM-YY):
```

AFTER THE DATE HAS BEEN ACCEPTED BY THE MONITOR THE RESTART ADDRESS OF THE MONITOR IS PRINTED. THEN THE FOLLOWING TWO QUESTIONS ARE ASKED:

```
50 HZ ? N
LSI ? N
```

THE DEFAULTS ARE BOTH "NO". TYPE "R" AND THE PROGRAM NAME TO RUN THE PROGRAM. DO NOT TYPE THE EXTENSION.

WHEN THIS DIAGNOSTIC IS STARTED THE FOLLOWING STEPS WILL OCCUR:

```
*****
* STEP 1 *
*****
```

THE DIAGNOSTIC WILL ISSUE THE PROMPT "DR>". FROM THIS POINT UNTIL THE TIME WHEN YOU RESTART CNDP+, YOU WILL BE TALKING TO THE DIAGNOSTIC, NOT CNDP+. WE WILL REFER TO THE PRESENCE OF THIS PROMPT AS BEING IN DIAGNOSTIC COMMAND MODE, AS OPPOSED TO CNDP+ COMMAND MODE.

AT THIS POINT YOU WILL ENTER A "START" COMMAND. THIS IS NOT THE SAME AS THE CNDP+ "START" COMMAND, WHICH YOU ALREADY ISSUED IN RESPONSE TO THE CNDP+ DOT PROMPT. THIS "START" COMMAND CAN TAKE A NUMBER OF SWITCHES AND FLAGS (ALL OPTIONAL) AND THE DETAILS OF THESE ARE SET FORTH IN 2.3 "DETAILS OF COMMANDS AND SYNTAX". HOWEVER, IN ORDER TO USE THE PROGRAM, ALL YOU NEED TO SAY IS SOMETHING LIKE THIS:

```
STA/PASS:1/FLAGS:HOE
```

THINGS TO NOTE HERE:

1. ONLY THE FIRST THREE CHARACTERS OF THIS OR ANY COMMAND AT THE "DR>" LEVEL NEED TO BE TYPED.

306  
307  
308  
309  
310  
311  
312  
313  
314  
315  
316  
317  
318  
319  
320  
321  
322  
323  
324  
325  
326  
327  
328  
329  
330  
331  
332  
333  
334  
335  
336  
337  
338  
339  
340  
341  
342  
343  
344  
345  
346  
347  
348  
349  
350  
351  
352  
353  
354  
355  
356  
357  
358  
359  
360

2. THE "PASS" SWITCH SPECIFIES HOW MANY PASSES YOU DESIRE. A PASS CONSISTS OF RUNNING THE FULL DIAGNOSTIC AGAINST ALL UNITS BEING TESTED (THIS WILL BE EXPLAINED SHORTLY). ONE PASS IS SPECIFIED IN THE ABOVE EXAMPLE.

3. THE "FLAGS" SWITCH MAY SPECIFY ANY OF A NUMBER OF FLAGS, BUT THE MAIN USEFUL ONES ARE:

PNT	PRINT NUMBER OF TEST BEING EXECUTED
LOE	LOOP ON ERROR
HOE	HALT ON ERROR
IER	INHIBIT ERROR PRINTOUT

THE HOE FLAG IS SPECIFIED IN THE ABOVE EXAMPLE (WE'LL SEE WHY SHORTLY).

\*\*\*\*\*  
\* STEP 2 \*  
\*\*\*\*\*

WHEN YOU HAVE TYPED IN A "START" COMMAND, THE DIAGNOSTIC WILL COME BACK WITH THE QUESTION "# UNITS?" TO WHICH YOU SHOULD RESPOND BY TYPING IN THE NUMBER OF DEVICES YOU WISH TO TEST.

A WORD OF WARNING HERE: THE NUMBER OF UNITS DEPENDS ON THE TARGET DEVICE OF THE DIAGNOSTIC. FOR EXAMPLE, IF THE DIAGNOSTIC IS DIRECTED AT A DISK DRIVE, THEN THE NUMBER OF UNITS WOULD BE THE NUMBER OF DRIVES TO BE TESTED. WHEREAS IF THE DIAGNOSTIC WAS DIRECTED AT THE DISK CONTROLLER, THEN THE NUMBER OF UNITS WOULD BE THE NUMBER OF CONTROLLERS. THE TARGET DEVICE OF A DIAGNOSTIC CAN ALWAYS BE DETERMINED BY INSPECTING THE "HEADER" STATEMENT NEAR THE BEGINNING OF THE SOURCE CODE. ONE OF THE OPERANDS OF THIS "HEADER" STATEMENT SHOULD BE THE DEVICE TYPE OF THE DIAGNOSTIC.

\*\*\*\*\*  
\* STEP 3 \*  
\*\*\*\*\*

WHEN YOU HAVE TYPED IN THE NUMBER OF UNITS TO BE TESTED, THE DIAGNOSTIC WILL ASK YOU THE "HARDWARE QUESTIONS". THE ANSWERS TO THESE QUESTIONS ARE USED TO BUILD TABLES IN CORE, CALLED "HARDWARE P-TABLES". ONE HARDWARE P-TABLE WILL BE BUILT FOR EACH UNIT TO BE TESTED.

THERE ARE SEVERAL HARDWARE QUESTIONS AND THE ENTIRE SERIES WILL BE POSED N TIMES, WHERE N IS THE NUMBER OF UNITS.

THIS REPRESENTS A NEW PHILOSOPHY IN DIAGNOSTIC ENGINEERING. DIAGNOSTICS IN THE FUTURE WILL NOT BE WRITTEN TO AUTOSIZE OR ASSUME STANDARD ADDRESSES: INSTEAD, THEY WILL ASK THE OPERATOR FOR ALL THE INFORMATION THEY NEED TO TEST THE DEVICE.



362  
363  
364  
365  
366  
367  
368  
369  
370  
371  
372  
373  
374  
375  
376  
377  
378  
379  
380  
381  
382  
383  
384  
385  
386  
387  
388  
389  
390  
391  
392  
393  
394  
395  
396  
397  
398  
399  
400  
401  
402  
403  
404  
405

\*\*\*\*\*  
\* STEP 4 \*  
\*\*\*\*\*

AFTER YOU HAVE ANSWERED ALL THE HARDWARE QUESTIONS (SEC 2.5) FOR ALL THE UNITS, YOU WILL BE ASKED "CHANGE SW? IF YOU WANT TO BE ASKED THE SOFTWARE QUESTIONS THAT DETERMINE THE BEHAVIOR OF THIS PROGRAM, TYPE "Y". IF YOU WANT TO TAKE ALL THE DEFAULTS TO THESE QUESTIONS, TYPE "N". IF YOU TYPE "Y" YOU WILL BE ASKED THE SOFTWARE QUESTIONS (SEC 2.6), AND THE ANSWERS WILL BE PUT INTO THE SOFTWARE P-TABLE IN THE PROGRAM. THE SERIES OF QUESTIONS WILL BE ASKED JUST ONCE, REGARDLESS OF THE NUMBER OF UNITS TO BE TESTED.

\*\*\*\*\*  
\* STEP 5 \*  
\*\*\*\*\*

AFTER YOU HAVE ANSWERED THE SOFTWARE QUESTIONS, THE DIAGNOSTIC WILL BEGIN TO EXECUTE THE HARDWARE TEST CODE. THERE ARE SEVERAL THINGS THAT CAN HAPPEN NEXT, DEPENDING ON WHETHER A HARDWARE ERROR IS ENCOUNTERED AND ALSO ON WHAT SWITCH VALUES YOU SELECTED ON THE START COMMAND. CONSIDER THE POSSIBILITIES:

1. IF NO ERROR IS ENCOUNTERED, THEN THE DIAGNOSTIC WILL SIMPLY EXECUTE THE DESIRED NUMBER OF PASSES AND RETURN TO COMMAND MODE (PROMPT DR>).
2. IF AN ERROR IS ENCOUNTERED, THEN ONE OF THREE THINGS HAPPENS, DEPENDING ON THE SETTINGS OF THE HOE AND LOE FLAGS.

HOE SET: THE ERROR WILL BE REPORTED ON THE CONSOLE AND THE DIAGNOSTIC WILL RETURN TO COMMAND MODE.

LOE SET: THE DIAGNOSTIC WILL LOOP ENDLESSLY ON THE BLOCK OF CODE THAT DETECTED THE ERROR.

NEITHER HOE NOR LOE SET: THE ERROR WILL BE REPORTED ON THE CONSOLE AND NORMAL EXECUTION WILL RESUME AS IF NO ERROR HAD OCCURRED.

407  
408  
409  
410  
411  
412  
413  
414  
415  
416  
417  
418  
419  
420  
421  
422  
423  
424  
425  
426  
427  
428  
429  
430  
431  
432  
433  
434  
435  
436  
437  
438  
439  
440  
441  
442  
443  
444  
445  
446  
447  
448  
449  
450  
451  
452  
453

2.1.2 SAMPLE RUN THROUGH  
- - - - -

LET'S SEE HOW ALL THIS WORKS IN A REAL SITUATION. RECALL THAT WE ENTERED THE COMMAND "STA/PASS:1/FLAGS:HOE". THIS WOULD BE A VERY TYPICAL WAY TO RUN THE DIAGNOSTIC. IF NO ERRORS ARE ENCOUNTERED, THE SINGLE REQUESTED PASS WILL BE EXECUTED AND THE PROMPT WILL BE RE-ISSUED.

IF AN ERROR IS ENCOUNTERED, THE ERROR WILL BE REPORTED AND THE PROMPT WILL BE REISSUED (BECAUSE THE HOE FLAG IS SET). AT THIS POINT THERE ARE FOUR DIFFERENT WAYS YOU CAN GET THE PROGRAM GOING AGAIN:

1. ISSUE ANOTHER "START" COMMAND (THUS GOING THRU ALL OF STEPS 1, 2, 3, 4, AND 5 AGAIN)
2. ISSUE A "RESTART" COMMAND (SAME AS START COMMAND EXCEPT THAT THE HARDWARE QUESTIONS ARE NOT ASKED)
3. ISSUE A "CONTINUE" COMMAND (EXECUTION WILL RESUME AT THE BEGINNING OF THE PARTICULAR HARDWARE TEST (MOST DIAGNOSTICS CONSIST OF A NUMBER OF THESE) THAT IT WAS IN WHEN THE ERROR HALT OCCURRED. NO QUESTIONS ASKED.
4. ISSUE A "PROCEED" COMMAND: EXECUTION WILL RESUME AT THE INSTRUCTION FOLLOWING THE ERROR REPORT (THIS IS A SPECIAL COMMAND AND CAN BE ISSUED ONLY AT A HALT ON ERROR).

THE MOST TYPICAL THING TO DO HERE IS TO ISSUE THE PROCEED, BUT WITH DIFFERENT FLAG SETTINGS. PROBABLY YOU WOULD WANT TO SAY:

PRO/FLAGS:IER:LOE:HOE=0

THIS WILL DO THE FOLLOWING:

1. TURN ON THE IER (INHIBIT ERROR PRINTOUT) FLAG
2. TURN ON THE LOE FLAG
3. TURN OFF THE HOE FLAG
4. RESUME EXECUTION AT INSTRUCTION AFTER ERROR REPORT

455  
456  
457  
458  
459  
460  
461  
462  
463  
464  
465  
466  
467  
468  
469  
470  
471  
472  
473  
474  
475  
476  
477  
478  
479  
480  
481  
482  
483  
484  
485  
486  
487  
488  
489  
490

THE DIAGNOSTIC WILL NOW LOOP ON THE BLOCK OF CODE THAT DETECTED AND REPORTED THE ERROR, BUT NO ERROR PRINTOUT WILL OCCUR. THUS YOU CAN STUDY THE ERROR OR SCOPE IT OR WHATEVER.

WHEN YOU VE SEEN ENOUGH, YOU MAY HIT CONTROL/C. THIS WILL TAKE YOU OUT OF THE LOOP AND PUT YOU BACK INTO COMMAND MODE. YOU NOW HAVE THREE CHOICES:

1. START
2. RESTART
3. CONTINUE

LET'S SAY YOU'VE REPAIRED THE DEFECT FOUND ABOVE AND WANT TO FINISH RUNNING THE DIAGNOSTIC. YOU WOULD TYPE

CON/FLAGS:HOE:IER=0:LOE=0

THIS WILL RESTORE THE FLAGS TO THEIR ORIGINAL VALUES AND RESUME EXECUTION AT THE BEGINNING OF THE HARDWARE TEST YOU WERE IN. IF THE ERROR DOES NOT RECUR, THE EXECUTION WILL FLOW RIGHT ON THRU TO THE NEXT ERROR OR TO END OF PASS.

IF AT END OF PASS YOU WANT TO RUN THE DIAGNOSTIC AGAIN, YOU HAVE TWO CHOICES:

1. START
2. RESTART

YOU WOULD CHOOSE ONE, DEPENDING ON WHETHER YOU WANTED TO ANSWER THE HARDWARE QUESTIONS AGAIN.

492  
493  
494  
495  
496  
497  
498  
499  
500  
501  
502  
503  
504  
505  
506  
507  
508  
509  
510  
511  
512  
513  
514  
515  
516  
517  
518  
519  
520  
521  
522  
523  
524  
525  
526  
527  
528  
529  
530  
531  
532  
533  
534  
535  
536  
537  
538  
539  
540  
541  
542  
543  
544  
545  
546  
547  
548

THE FULL PRINT-OUT FROM THE ABOVE DIALOGUE MIGHT LOOK LIKE THIS  
(O=OPERATOR, D=DIAGNOSTIC):

	BY WHOM ENTERED: -----
.R NRLKAO	O
DRS LOADED	D
DIAG. RUN-TIME SERVICES REV. D APR-79	D
CNRLK-A-0	D
CNRLK RANDOMLY PERFORMS DRIVE SEEK, READ, AND WRITE FUNCTIONS	D
UNIT IS RLO1, RLO2	D
DR>STA/PASS:1/FLAGS:HOE	D.O
CHANGE HW (L) ? Y	D.O
* UNITS (D) ? 2	D.O
UNIT 0	D
RL11 (L) Y ?	D.O
BUS ADDRESS (O) 174400 ?	D.O
VECTOR (O) 160 ?	D.O
DRIVE (O) 0 ?	D.O
DRIVE TYPE = RLO1 (L) Y ?	D.O
BR LEVEL (O) 5 ?	D.O
UNIT 1	D
RL11 (L) Y ?	D.O
BUS ADDRESS (O) 174400 ?	D.O
VECTOR (O) 160 ?	D.O
DRIVE (O) 0 ? 1	D.O
DRIVE TYPE = RLO1 (L) ? N	D.O (N=RLO2)
BR LEVEL (O) 5 ?	D.O
CHANGE SW (L) ? N	D.O
CNRLK HRD ERR 00004 TST 003 SUB 002 PC:004130 ERR HLT	
DR>PRO/FLAGS:IER:LOE:HOE=0	D.O
***** AT THIS POINT THE DIAGNOSTIC IS LOOPING ON THE ERROR WITHOUT PRINTING ANYTHING. YOU CAN SCOPE THE ERROR UNTIL YOU HAVE LOCATED IT, THEN ↑C OUT. *****	
↑C	O

```

550
551 DR>CON/FLAGS:MOE:IER:LOE=0 D,0
552
553 CHANGE SW (L) ? N D,0
554
555 CNRLK EOP 1 D
556 ^C
557
558 DR>RESTART/PASS:1 D,0
559
560 CHANGE SW (L) ? N D,0
561 -
562 -
563 -
564 -
565

```

2.2 CHAIN MODE OPERATION

CHAIN MODE OPERATION CONSISTS OF THE SEQUENTIAL EXECUTION OF PROGRAMS WITHOUT OPERATOR INTERVENTION. ONLY PROGRAMS THAT HAVE BEEN MODIFIED TO RUN IN CHAIN MODE CAN BE CHAINED. CHAINABLE PROGRAMS ARE IDENTIFIED IN THE DIRECTORY BY A BIC EXTENSION.

TO RUN CHAIN MODE, THE CNDP+ MONITOR USES AN ASCII FILE (KNOWN AS A CHAIN FILE) LISTING THE PROGRAMS TO BE RUN AND THE NUMBER OF PASSES EACH PROGRAM SHOULD RUN. THIS FILE MUST BE ON THE SYSTEM DEVICE.

A CHAIN FILE MAY BE GENERATED BY USE OF THE XTECO TEXT EDITOR. THIS FILE MUST HAVE A CCC EXTENSION. THE CHAIN FILE MAY CONTAIN ANY OF THE COMMANDS SUPPORTED BY THE CNDP+ MONITOR. THE COMMANDS IN THE ASCII FILE ARE EXECUTED IN THE ORDER IN WHICH THEY ARE ENCOUNTERED. COMMENTS MAY BE INCLUDED IN THE FILE.

TO EXECUTED A CHAIN FILE THE USER TYPES:

```

C FILNAM <CR> OR
C FILNAM/QV <CR>

```

IN THE FIRST CASE THE PASS COUNT SPECIFIED IN THE CHAIN FILE IS USED BY THE CNDP+ MONITOR TO DETERMINE THE NUMBER OF PASSES TO EXECUTE EACH PROGRAM. IN THE SECOND CASE THE PROGRAM COUNT IS NOT USED AND EACH PROGRAM IS EXECUTED ONLY ONCE. THE /QV SWITCH PROVIDES A SINGLE EXECUTION MODE OF OPERATION OF QUICK VERIFY.

WHEN PROGRAMS ARE RUN IN CHAIN MODE, THE SOFTWARE SWITCH REGISTER SHOULD BE SET TO 000000. THE CNDP+ MONITOR PRINTS EACH COMMAND TAKEN FROM THE CHAIN FILE AND THEN EXECUTES THE COMMAND. WHEN THE LAST COMMAND OTHER THAN ANOTHER C COMMAND HAS BEEN EXECUTED THE CNDP+ MONITOR TERMINATES CHAIN MODE AND TYPES A PROMPT (.). IT IS READY TO ACCEPT ANOTHER COMMAND FROM THE CONSOLE. IF THE LAST COMMAND IS ANOTHER C COMMAND, THE CHAIN MODE WILL CONTINUE AND THE CHAIN FILE SPECIFIED BY THIS NEW C COMMAND WILL BE USED.

550  
551  
552  
553  
554  
555  
556  
557  
558  
559  
560  
561  
562  
563  
564  
565  
566  
567  
568  
569  
570  
571  
572  
573  
574  
575  
576  
577  
578  
579  
580  
581  
582  
583  
584  
585  
586  
587  
588  
589  
590  
591  
592  
593  
594  
595  
596  
597  
598  
599  
600  
601  
602  
603



605  
606  
607  
608  
609  
610  
611  
612  
613  
614  
615  
616  
617  
618  
619  
620  
621  
622  
623  
624  
625  
626  
627  
628  
629  
630  
631  
632  
633  
634  
635  
636  
637  
638  
639  
640  
641  
642  
643  
644  
645  
646  
647  
648  
649  
650  
651  
652  
653  
654  
655  
656  
657

IF THE USER WISHES TO TERMINATE CHAIN MODE BEFORE ITS NORMAL TERMINATION HE MAY DO SO BY TYPING A CONTROL/C. HOWEVER, THE MONITOR WILL NOT ABORT THE CHAIN MODE UNTIL IT RECEIVES PROGRAM CONTROL FROM THE PROGRAM CURRENTLY RUNNING.

## 2.3 DETAILS OF COMMANDS AND SYNTAX

### 2.3.1 TABLE OF COMMAND VALIDITY

THERE ARE FOUR WAYS OF ENTERING DIAGNOSTIC COMMAND MODE, AND DIFFERENT SUBSETS OF THE DIAG COMMAND SET ARE AVAILABLE WITH EACH:

HOW ENTERED	LEGAL COMMANDS
-----	-----
1. OPERATOR ENTERED 'RUN DIAG'	START PRINT DISPLAY FLAGS ZFLAGS EXIT
2. DIAGNOSTIC HAS FINISHED ALL ITS REQUESTED PASSES	START RESTART PRINT DISPLAY FLAGS ZFLAGS EXIT
3. OPERATOR INTERRUPTED THE DIAGNOSTIC WITH CTRL/C	START RESTART CONTINUE PRINT DISPLAY FLAGS ZFLAGS EXIT
4. AN ERROR WAS ENCOUNTERED WITH THE HOE FLAG SET SET	START RESTART CONTINUE PROCEED PRINT DISPLAY FLAGS ZFLAGS EXIT

B.

659  
660  
661  
662  
663  
664  
665  
666  
667  
668  
669  
670  
671  
672  
673  
674  
675  
676  
677  
678  
679  
680  
681  
682  
683  
684  
685  
686  
687  
688  
689  
690  
691  
692  
693  
694  
695  
696  
697  
698  
699  
700  
701  
702  
703  
704  
705  
706  
707  
708  
709  
710  
711

2.3.2 COMMAND SYNTAX

\*\*\*\*\*  
STA(RT)/TESTS:TEST-LIST/PASS:PASS-CNT/FLAGS:FLAG-LIST/EOP:EOP-INCR  
\*\*\*\*\*

THE DIAGNOSTIC IN CORE IS EXECUTED IN ACCORDANCE WITH THE SWITCHES SPECIFIED. THE MESSAGE "0 UNITS?" IS PRINTED. THE START COMMAND MAY BE ISSUED WHEN DIAGNOSTIC COMMAND MODE HAS BEEN ENTERED VIA ONE OF THE FOLLOWING: A) OPERATOR TYPED "RUN DIAGNOSTIC" B) DIAGNOSTIC FINISHED EXECUTING C) ERROR WAS ENCOUNTERED WITH MOE FLAG SET D) OPERATOR ENTERED CONTROL/C. AFTER THE OPERATOR RESPONDS TO "0 UNITS?", THE HARDWARE DIALOGUE IS INITIATED. WHEN IT IS COMPLETED, THE QUESTIONS "CHANGE SW?" IS ISSUED, AND THE ANSWERS, IF GIVEN, BECOME THE NEW DEFAULTS. THEREFORE IT IS NECESSARY TO RELOAD THE PROGRAM IN ORDER TO RETURN TO THE LOAD DEFAULTS.

THE SWITCH ARGUMENTS ARE AS FOLLOWS:

"TEST-LIST" IS A SEQUENCE OF DECIMAL NUMBERS (1:2 ETC.) OR RANGES OF DECIMAL NUMBERS (1-5:8-10 ETC.) THAT SPECIFY THE TESTS TO BE EXECUTED. THE NUMBERS ARE SEPARATED BY COLONS. THE NUMBERS RANGE FROM 1 TO THE LARGEST TEST NUMBER IN THE DIAGNOSTIC. THEY MAY BE SPECIFIED IN ANY ORDER. TESTS WILL BE EXECUTED IN NUMERICAL ORDER REGARDLESS OF THE ORDER OF SPECIFICATION. THE DEFAULT IS TO EXECUTE ALL TESTS.

"PASS-CNT" IS A DECIMAL NUMBER INDICATING THE DESIRED NUMBER OF PASSES. A PASS IS DEFINED AS THE EXECUTION OF THE FULL DIAGNOSTIC (ALL SELECTED TESTS) AGAINST ALL UNITS SUBMITTED. THE DEFAULT IS NON-ENDING TEST EXECUTION. "FLAG-LIST" IS A SEQUENCE OF ELEMENTS OF THE FORM <FLAG>, <FLAG=1>, OR <FLAG=0>, SEPARATED BY COLONS. WHERE <FLAG> HAS ONE OF THE FOLLOWING VALUES:

MOE HALT ON ERROR, CAUSING COMMAND MODE TO BE ENTERED WHEN AN ERROR IS ENCOUNTERED

LOE LOOP ON ERROR, CAUSING THE DIAGNOSTIC TO LOOP CONTINUOUSLY WITHIN THE SMALLEST DEFINED BLOCK OF CODING (SEGMENT, SUBTEST, OR TEST) CONTAINING THE ERROR

IER INHIBIT ERROR REPORTING

IBE INHIBIT BASIC ERROR REPORTS

IXE INHIBIT EXTENDED ERROR REPORTS

PRI DIRECT ALL MESSAGES TO A LINE PRINTER

PNT PRINT NUMBER OF TEST BEING EXECUTED

713  
714  
715  
716  
717  
718  
719  
720  
721  
722  
723  
724  
725  
726  
727  
728  
729  
730  
731  
732  
733  
734  
735  
736  
737  
738  
739  
740  
741  
742  
743  
744  
745  
746  
747  
748  
749  
750  
751  
752  
753  
754  
755  
756  
757  
758  
759  
760  
761  
762  
763

BOE BELL ON ERROR

UAM RUN IN UNATTENDED MODE, BYPASSING MANUAL INTERVENTION TESTS

ISR INHIBIT STATISTICAL REPORTS

IDU INHIBIT DROPPING OF UNITS BY DIAGNOSTIC

ADR EXECUTE AUTODROP CODE

LOT LOOP ON TEST

EVL EVALUATE

THE FLAGS NAMED OR EQUATED TO 1 ARE SET, THOSE EQUATED TO 0 ARE CLEARED. A FLAG NOT SPECIFIED IS CLEARED. IF THE FLAGS SWITCH IS NOT GIVEN ALL FLAGS ARE CLEARED.

"EOP-INCR" IS A DECIMAL NUMBER INDICATING HOW OFTEN (IN TERMS OF PASSES) IT IS DESIRED THAT THE END OF PASS MESSAGE BE PRINTED. THE DEFAULT IS AT THE END OF EVERY PASS.

\*\*\*\*\*  
RES(TART)/TEST:TEST-LIST/PASS:PASS-CNT/FLAGS:FLAG-LIST/EOP:EOP-INCR/UNITS:UNIT-LIST  
\*\*\*\*\*

THE DIAGNOSTIC IN CORE IS EXECUTED IN ACCORDANCE WITH THE SWITCHES SPECIFIED. HOWEVER, NEW "P-TABLES" ARE NOT BUILT. INSTEAD, THE ONES IN CORE ARE USED.

THE QUESTION "CHANGE SW?" IS ASKED AND THE ANSWERS GIVEN BECOME THE NEW DEFAULTS. THE COMMAND MAY BE ISSUED WHEN COMMAND MODE HAS BEEN ENTERED VIA A) DIAGNOSTIC IS FINISHED B) HALT ON ERROR C) CONTROL/C.

THE SWITCH ARGUMENTS ARE AS IN THE START COMMAND EXCEPT:

1. "UNIT-LIST" IS A SEQUENCE OF LOGICAL UNIT NUMBERS RANGING FROM 1 THRU N (N = NUMBER OF UNITS BEING TESTED) SPECIFYING WHICH UNITS ARE TO BE TESTED. THE LOGICAL UNIT NUMBER DESIGNATES THE POSITION OF THE P-TABLE IN CORE, ACCORDING TO THE ORDER IN WHICH THEY WERE BUILT. THE UNITS SPECIFIED MUST NOT HAVE BEEN DROPPED BY THE OPERATOR DROP COMMAND. THE UNIT-LIST DEFAULTS TO "ALL THAT HAVE NOT BEEN DROPPED BY OPERATOR COMMAND". THE EFFECT OF THE UNIT-LIST LASTS UNTIL THE NEXT START (WHERE IT IS AUTOMATICALLY RESET TO "ALL") OR THE NEXT RESTART.
2. ALL UNSPECIFIED FLAG SETTINGS ARE UNCHANGED.

765  
766  
767  
768  
769  
770  
771  
772  
773  
774  
775  
776  
777  
778  
779  
780  
781  
782  
783  
784  
785  
786  
787  
788  
789  
790  
791  
792  
793  
794  
795  
796  
797  
798  
799  
800  
801  
802  
803  
804  
805  
806  
807  
808  
809  
810  
811  
812  
813  
814  
815

\*\*\*\*\*  
CON(TINUE)/PASS:<PASS-CNT/FLAGS:<FLAG LIST>  
\*\*\*\*\*

COMMAND MODE MUST HAVE BEEN ENTERED DUE TO A HALT ON ERROR OR A CONTROL/C. THE EFFECT OF THE COMMAND IS TO GO TO THE BEGINNING OF THE TEST THAT WAS BEING EXECUTED WHEN THE HALT OR CONTROL/C TOOK PLACE. SOFTWARE DIALOGUE MAY OPTIONALLY BE RE-EXECUTED. HARDWARE PARAMETERS MAY NOT BE CHANGED.

THE SWITCH ARGUMENTS ARE AS IN THE START COMMAND EXCEPT:

1. DEFAULT FOR PASS-CNT IS THE UNSATISFIED PASS-CNT FROM THE PREVIOUS START OR RESTART
2. UNSPECIFIED FLAG SETTINGS ARE UNCHANGED

\*\*\*\*\*  
PRO(CEED)/FLAGS:<FLAG-LIST>  
\*\*\*\*\*

COMMAND MODE MUST HAVE BEEN ENTERED VIA A HALT ON ERROR. THE EFFECT OF THE COMMAND IS TO BEGIN EXECUTION AT THE LOCATION FOLLOWING THE ERROR CALL. NEITHER HARDWARE NOR SOFTWARE PARAMETERS MAY BE ALTERED.

THE SWITCH ARGUMENTS ARE THE SAME AS THE START COMMAND EXCEPT:

1. UNSPECIFIED FLAG SETTINGS ARE UNCHANGED

\*\*\*\*  
EXIT  
\*\*\*\*

RETURN TO CNDP. PROMPT MODE.

\*\*\*\*\*  
DRO(P)/UNITS:UNIT-LIST  
\*\*\*\*\*

THE UNITS SPECIFIED ARE DROPPED FROM TESTING UNTIL THEY ARE ADDED BACK OR UNTIL A START COMMAND IS GIVEN. A DROP CANNOT BE FOLLOWED BY A PROCEED.

THERE IS ALSO A "DROP" MACRO INTERNAL TO THE DIAGNOSTIC, WHICH GIVES THE FACILITY OF AUTO-DROPPING. THE DURATION OF A PROGRAM DROP, HOWEVER, IS ONLY UNTIL THE NEXT START OR RESTART.

817  
818  
819  
820  
821  
822  
823  
824  
825  
826  
827  
828  
829  
830  
831  
832  
833  
834  
835  
836  
837  
838  
839  
840  
841  
842  
843  
844  
845  
846  
847  
848  
849  
850  
851  
852  
853  
854  
855  
856  
857  
858  
859  
860  
861  
862  
863  
864  
865  
866  
867  
868  
869  
870

\*\*\*\*\*  
ADD/UNITS:UNIT-LIST  
\*\*\*\*\*

THE UNITS SPECIFIED ARE ADDED BACK (THEY MUST HAVE BEEN PREVIOUSLY DROPPED BY THE DROP COMMAND) TO THE TEST SEQUENCE. AN ADD CANNOT BE FOLLOWED BY A PROCEED.

\*\*\*\*\*  
PRI(NT)  
\*\*\*\*\*

ALL STATISTICS TABLES ACCUMULATED BY THE DIAGNOSTIC ARE PRINTED. THE ISR (INHIBIT STATISTICAL REPORTING) FLAG IS CLEARFD.

\*\*\*\*\*  
DIS(PLAY)/UNITS:<UNIT-LIST>  
\*\*\*\*\*

THE HARDWARE P-TABLES FOR ALL UNITS UNDER TEST ARE PRINTED OUT IN THE FORMAT IN WHICH THEY WERE ENTERED. ANY UNITS THAT WERE DROPPED BY THE OPERATOR "DROP" COMMAND ARE SO DESIGNATED.

\*\*\*\*\*  
FLA(GS)  
\*\*\*\*\*

THE CURRENT SETTINGS OF ALL FLAGS ARE PRINTED.

\*\*\*\*\*  
ZFL(AGS)  
\*\*\*\*\*

ALL FLAGS ARE CLEARED.

#### 2.4 EXTENDED P-TABLE DIALOGUE

THE FULL CAPABILITY OF THE HARDWARE DIALOGUE IS REVEALED BY THE FOLLOWING DISCUSSION OF WHAT HAPPENS INTERNALLY.

AS SOON AS THE QUESTION "# UNITS?" IS ANSWERED (WITH THE NUMBER N), SPACE IN CORE IS ALLOCATED FOR "N" P-TABLES. ALL OF THE P-TABLES ARE OF THE SAME FORMAT, AND THERE IS A ONE-TO-ONE CORRESPONDENCE BETWEEN THE HARDWARE PARAMETER QUESTIONS AND THE SLOTS IN THE P-TABLE FORMAT.

IN GIVING A STRING OF VALUES, COMMAS WITHOUT INTERVENING VALUES MAY BE USED TO INDICATE A REPETITION OF THE LAST NAMED VALUE.



872  
873  
874  
875  
876  
877  
878  
879  
880  
881  
882  
883  
884  
885  
886  
887  
888  
889  
890  
891  
892  
893  
894  
895  
896  
897  
898  
899  
900  
901  
902  
903  
904  
905  
906  
907  
908  
909  
910  
911  
912  
913  
914  
915  
916  
917  
918  
919  
920  
921  
922  
923

A STRING OF VALUES MAY BE GIVEN AS A RANGE (6 10 FOR EXAMPLE). IF THE VALUES REPRESENT PURE NUMERICAL DATA, THIS SAMPLE RANGE TRANSLATES TO THE STRING 6,7,8,9,10 (AN INCREMENT OF 1). IF THE VALUES ARE ADDRESSES, THE SAMPLE RANGE TRANSLATES TO THE STRING 6,8,10 (AN INCREMENT OF 2).

NOW LET US SEE HOW WE COULD USE THESE CAPABILITIES TO CONSTRUCT A SET OF P-TABLES. ASSUME THAT WE HAVE 8 RL UNITS, AND THAT THERE ARE FIVE (5) HARDWARE PARAMETERS FOR EACH (5 SLOTS IN THE P TABLE, 5 HARDWARE QUESTIONS IN THE DIALOGUE).

FOLLOWING IS THE DIALOGUE FOR THIS 8 RLOX DRIVE SYSTEM. THIS SYSTEM HAS TWO (2) RL11 TYPE CONTROLLERS ALL TO BE SET AT "BR LEVEL" 5. THE FIRST 4 DRIVES ARE RLO1'S AND THE LAST 4 DRIVES ARE RLO2'S (ON THE SECOND CONTROLLER):

\* UNITS (D) ? 8

UNIT 0  
RL11 (L) Y ?  
BUS ADDRESS (D) 174400 ?  
VECTOR (D) 160 ?  
DRIVE (D) 0 ? 0-3  
DRIVE TYPE = RLO1 (L) Y ?  
BR LEVEL (D) 5 ?

UNIT 4  
RL11 (L) Y ?  
BUS ADDRESS (D) 174400 ? 175400  
VECTOR (D) 160 ? 164  
DRIVE (D) 0 ? 0-3  
DRIVE TYPE = RLO1 (L) Y ? N  
BR LEVEL (D) 5 ?

THE FIRST TIME THRU THE P-TABLE QUESTIONS THE DEFAULT VALUES ARE USED FOR THE CONTROLLER TYPE (QUESTION #1), CSR ADDRESS OF THE CONTROLLER (QUESTION #2), THE CONTROLLER VECTOR ASSIGNMENT (QUESTION #3), THE DRIVE TYPE (QUESTION #5), AND THE "BR LEVEL" (QUESTION #6). THE ACTUAL UNIT NUMBERS OF THE RLO1'S FOR QUESTION #4 WAS ASSIGNED 0 THRU 3 FOR THE FIRST 4 P-TABLE SLOTS.

THE SECOND TIME THRU THE P-TABLE QUESTIONS (FOR THE RLO2 ASSIGNMENT ON THE SECOND CONTROLLER), THE FIRST QUESTION DEFAULTED TO "RL11" TYPE CONTROLLER. THE SECOND QUESTION WAS ANSWERED TO REFLECT THE CHANGE IN CSR ADDRESS FOR THE RLO2 CONTROLLER (175400). THE SECOND CONTROLLER'S VECTOR WAS ALSO CHANGED TO 164 IN QUESTION #3. THE RLO2 TEST UNIT NUMBERS WERE ASSIGNED VALUES 0 TO 3 IN QUESTION #4 AND THE DRIVE TYPE WAS SET FOR RLO2'S FOR THE REMAINING 4 UNITS IN QUESTION #5. THE LAST QUESTION WAS DEFAULTED USING THE "BR LEVEL" FROM THE FIRST PASS.

925  
926  
927  
928  
929  
930  
931  
932  
933  
934  
935  
936  
937  
938  
939  
940  
941  
942  
943  
944  
945  
946  
947  
948  
949  
950  
951  
952  
953  
954  
955  
956  
957  
958  
959  
960  
961  
962  
963  
964  
965  
966  
967  
968  
969  
970  
971  
972  
973  
974  
975  
976  
977  
978  
979  
980  
981

## 2.5 HARDWARE PARAMETERS

THE FOLLOWING QUESTIONS WILL BE ASKED ON A START COMMAND. THE VALUE LOCATED TO THE LEFT OF THE QUESTION MARK IS THE DEFAULT VALUE THAT WILL BE TAKEN ON A CARRIAGE RETURN RESPONSE.

RL11 (L) Y?

ANSWER YES(Y) IF YOU HAVE AN RL11 CONTROLLER, NO(N) IF YOU HAVE AN RLV11 CONTROLLER.

BUS ADDRESS (0) 174400?

ANSWER WITH THE BUS ADDRESS OF THE CONTROLLER.

VECTOR (0) 160?

ANSWER WITH THE INTERRUPT VECTOR OF THE CONTROLLER.

DRIVE (0) 0?

ANSWER WITH THE DRIVE(S) CONNECTED TO THE CONTROLLER

DRIVE TYPE = RLO1 (L) ?

ANSWER NO (N) IF DRIVE IS AN RLO2

BR LEVEL (0) 5?

ANSWER WITH THE INTERRUPT PRIORITY OF THE CONTROLLER.

## 2.6 SOFTWARE PARAMETERS

THE FOLLOWING QUESTIONS ARE ASKED IF REQUESTED ON A START, RESTART, OR CONTINUE. THEY ALLOW FLEXIBILITY IN THE WAY THE PROGRAM BEHAVES. THE SOFTWARE PARAMETERS GIVE THE PROGRAM FLEXIBILITY IN THE WAY IT RUNS. THE PARAMETERS CAN BE MODIFIED ON A START, RESTART, OR CONTINUE BY ANSWERING (Y)ES TO THE FOLLOWING QUESTION:

"CHANGE S.W. ?"

A YES ANSWER WILL ASK THE FOLLOWING SOFTWARE PARAMETER QUESTIONS. WITH THE PRESENT DEFAULT VALUE PRINTED TO THE LEFT OF THE QUESTION MARK. (THE LAST ANSWER GIVEN IS THE DEFAULT) THE DEFAULT IS TAKEN ON A <CR>. CONTROL Z (^Z) WILL DEFAULT ALL REMAINING QUESTIONS AND START THE TEST.

"RETRY LMT (0) 1 ?"

THIS IS THE NUMBER OF TIMES THE PROGRAM WILL ATTEMPT A COMMAND BEFORE IT QUILTS AND REPORTS A HARD ERROR. IF THE RETRY IS SUCCESSFUL BEFORE THE RETRY LIMIT IS EXCEEDED IT WILL PRINT AND LOG A SOFT ERROR.

LIMITS 0 - 65,535

983  
984  
985  
986  
987  
988  
989  
990  
991  
992  
993  
994  
995  
996  
997  
998  
999  
1000  
1001  
1002  
1003  
1004  
1005  
1006  
1007  
1008  
1009  
1010  
1011  
1012  
1013  
1014  
1015  
1016  
1017  
1018  
1019  
1020  
1021  
1022  
1023  
1024  
1025  
1026  
1027  
1028  
1029  
1030  
1031  
1032  
1033  
1034  
1035  
1036  
1037

"SEEK RETRY LMT (D) 1 ?"

THIS IS THE NUMBER OF RETRYS THAT WILL BE ATTEMPTED TO SEEK TO A CYLINDER ON A MIS-SEEK. AFTER RETRY IS EXHAUSTED, WE WILL NOT TRY FOR THAT CYLINDER BUT CONTINUE WITH A NEW CYLINDER.

LIMITS 0 - 65,535

"DATA DMP ON DCK ERR (L) Y ?"

GIVES THE ABILITY TO SEE THE 1 SECTOR BUFFER THAT HAD A DATA CRC ERROR. THE RESULTS OF THE PRINTOUT ARE ONE OF TWO POSSIBILITIES.

1. ONLY THOSE WORDS OF THE SECTOR THAT WERE BAD ARE PRINTED WITH WHAT WAS EXPECTED.
2. IF ONE OF THE 1ST TWO WORDS IS BAD (USED TO KEY) THE ENTIRE BUFFER IS DUMPED.

LIMITS Y OR N

"# OF ERR DUMPED (D) 128 ?"

THIS IS THE NUMBER OF MISCOMPARES THAT WILL BE PRINTED.

LIMITS 0 - 128

\*\*\*\*\*  
 \*\*\* THE FOLLOWING QUESTION, ORIGINALLY PART OF CZRLKB, HAS BEEN \*  
 \*\*\* REMOVED FROM CNRLK. STATISTICAL REPORTS WILL ONLY BE PRINTED \*  
 \*\*\* IF THE OPERATOR ISSUES THE DRS "PRINT" COMMAND. ;JSD REV A \*  
 \*\*\*\*\*

"TIME BETW REPORTS (MIN) (D) 240 ?"

THIS IS THE INTERVAL BETWEEN AUTOMATIC STATISTICAL REPORTS ON ALL DRIVES IF A CLOCK IS PRESENT AND WAS ANSWERED SO IN THE INITIAL DIALOGUE.

LIMITS 1 - 65,535

"DROP DR ON ERR LMTS REACHED (L) Y ?"

GIVES THE ABILITY TO AUTOMATICALLY STOP TESTING ON A DRIVE ONCE ONE OF THE ERROR LIMITS HAVE BEEN EXCEEDED (SEEK, DRIVE, HARD, SOFT). IF THE ANSWER IS YES THEN THE FOLLOWING FOUR QUESTIONS WILL BE ASKED, IF NO THEN THE NEXT QUESTION WILL BE 2.3.13.11.

LIMITS Y OR N

1039  
1040 'HRD ERR LMT (D) 3 ?"  
1041  
1042 THIS IS THE LIMIT OF HARD ERRORS THAT A DRIVE WILL BE DROPPED ON.  
1043 A HARD ERROR IS ONE ON WHICH THE RETRY HAS BEEN EXHAUSTED.  
1044  
1045 LIMITS 1 65,535  
1046  
1047  
1048 "SFT ERR LMT (D) 10 ?"  
1049  
1050 THIS IS THE LIMIT OF SOFT ERRORS THAT A DRIVE WILL BE DROPPED ON.  
1051 A SOFT ERROR IS AN ERROR ON AN OPERATION THAT WAS SUCCESSFUL WITHIN  
1052 THE RETRY LIMIT.  
1053  
1054 LIMITS 1 - 65,535  
1055  
1056  
1057 "DATA MISCOMPARE LIMIT (D) 10 ?"  
1058  
1059 THIS IS THE LIMIT OF IN CORE MISCOMPARES THAT THE DRIVE WILL BE  
1060 DROPPED ON.  
1061  
1062 LIMITS 1 - 65,535  
1063  
1064  
1065 "SK ERR LMT (D) 3 ?"  
1066  
1067 THIS IS THE LIMIT OF MIS-SEEK AND TRACKING ERRORS THAT A DRIVE WILL  
1068 BE DROPPED.  
1069  
1070 LIMITS 1 - 65,535  
1071  
1072  
1073 "DR ERR LMT (D) 3 ?"  
1074  
1075 THIS IS THE LIMIT OF DRIVE ERRORS THAT A DRIVE WILL BE DROPPED ON.  
1076  
1077 LIMITS 1 - 65,535  
1078  
1079  
1080 "DROP DR ON OPER LMTS REACHED (L) N ?"  
1081  
1082 GIVES THE ABILITY TO STOP TESTING ON A DRIVE THAT HAS EXCEEDED  
1083 CERTAIN OPERATION LIMITS (SEEK, BITS TRANSFERRED). THE DRIVE WILL  
1084 BE DROPPED ONLY WHEN BOTH HAVE BEEN EXCEEDED. IF THE ANSWER IS YES  
1085 THEN THE NEXT TWO QUESTIONS WILL BE ASKED.  
1086  
1087 LIMITS Y OR N  
1088  
1089  
1090 "DATA XFER LMT (\*10(10)) (D) 25000 ?"

1092  
1093  
1094  
1095  
1096  
1097  
1098  
1099  
1100  
1101  
1102  
1103  
1104  
1105  
1106  
1107  
1108  
1109  
1110  
1111  
1112  
1113  
1114  
1115  
1116  
1117  
1118  
1119  
1120  
1121  
1122  
1123  
1124  
1125  
1126  
1127  
1128  
1129  
1130  
1131  
1132  
1133  
1134  
1135  
1136  
1137  
1138  
1139  
1140  
1141  
1142

J.  
THIS IS THE LIMIT OF COMBINED BITS READ/WITTEN (\*10(10)) ON WHICH THE DRIVE WILL BE DROPPED.

LIMITS 1 65,535

"SK LMT (\*10(3)) (D) 10000 ?"

THIS IS THE LIMIT OF SEEK OPERATIONS (\*10(3)) ON WHICH THE DRIVE WILL BE DROPPED.

LIMITS 1 - 65,535 (\*10(3))

"DO YOU WANT TO CHANGE SEEK, R/W PARAMETERS (L) N ?"

THE NORMAL OPERATION IS TO SEEK AND TRANSFER ON THE ENTIRE CARTRIDGE, CYLINDERS 0 - 255. (RL01) OR 511. (RL02), SECTORS 0 - 39 AND BOTH SURFACES. THE NORMAL TRANSFER IS RANDOM BETWEEN 3 AND 1280 WORDS.

THE NEXT 8 PARAMETERS WILL ALLOW THE USER TO CONFINE THE TESTING TO ANY CONTIGUOUS SECTION OF THE CARTRIDGE AND CONTROL THE SIZE OF THE TRANSFERS.

A YES ANSWER WILL ASK THE NEXT 13 QUESTIONS.

"STIPULATE R/W XFER SIZE (L) N ?"

THE PROGRAM WILL NORMALLY MAXIMIZE THE TRANSFER SIZE BY USING ALL OF MEMORY (<28K) AVAILABLE. THIS QUESTION IF ANSWERED YES WILL RESTRICT THE BUFFER TO THOSE VALUES GIVEN IN NEXT TWO QUESTIONS. QUESTION IS 2.3.13.19.

LIMITS Y OR N

"MAX XFER (D) 2560 ?"

REPRESENTS THE MAXIMUM AMOUNT OF WORDS TO READ OR WRITE

LIMITS 3 - 5120

"MIN XFER (D) 3 ?"

REPRESENTS THE MINIMUM AMOUNT OF WORDS TO READ OR WRITE

LIMITS 3 - 5120



1144  
1145  
1146  
1147  
1148  
1149  
1150  
1151  
1152  
1153  
1154  
1155  
1156  
1157  
1158  
1159  
1160  
1161  
1162  
1163  
1164  
1165  
1166  
1167  
1168  
1169  
1170  
1171  
1172  
1173  
1174  
1175  
1176  
1177  
1178  
1179  
1180  
1181  
1182  
1183  
1184  
1185  
1186  
1187  
1188  
1189  
1190  
1191  
1192  
1193  
1194  
1195  
1196  
1197

"RD ONLY (L) N ?"

GIVES THE ABILITY TO INHIBIT WRITING THE PACK WHILE TESTING, THE INITIAL WRITE OF THE PACK FROM THE START COMMAND WILL STILL OCCUR.

LIMITS Y OR N

"RAN PAT (L) Y ?"

NORMAL OPERATION SHOULD BE YES, BUT THIS PARAMETER WILL ALLOW THE WRITING OF ONLY ONE PATTERN OF EIGHT NORMAL PATTERNS. THE PATTERNS IN NEXT QUESTION.

LIMITS Y OR N

"WHICH ONE (0) 4 ?"

IT IS NOW POSSIBLE TO CONTAIN THE EXERCISER IN WRITING ONLY ONE OF THE FOLLOWING EIGHT PATTERNS:

- 0 - ALL 0'S
- 1 - 177777,177777,177777,52525,52525,52525  
177777,177777,52525,52525,177777,52525  
177252,177252,172765,172765
- 2 - 0,0,0,177777,177777,177777  
0,0,177777,177777,0,177777,0,177777  
0,177777
- 3 - 25252,52525,52525,125252,125252,125252  
52525,52525,125252,125252,52525,125252  
52525,125252,52525,125252
- 4 - WORST CASE DATA  
155555,133333,66666,155555,133333,66666  
155555,133333,66666,155555,133333,66666  
155555,133333,66666,155555
- 5 - 121105,150442,64221,132110,55044,26422  
13211,105504,42642,21321,110550,44264  
22132,11055,104426,42213
- 6 - ALL 1'S
- 7 - 45513,122645,151322,64551,132264,55132  
26455,113226,45513,122645,151322,64551  
132264,55132,26455,113226

LIMITS 0 - 7

"WORDS PER SECTOR COMPARED ON READ (D) 16 ?"

1199  
1200  
1201  
1202  
1203  
1204  
1205  
1206  
1207  
1208  
1209  
1210  
1211  
1212  
1213  
1214  
1215  
1216  
1217  
1218  
1219  
1220  
1221  
1222  
1223  
1224  
1225  
1226  
1227  
1228  
1229  
1230  
1231  
1232  
1233  
1234  
1235  
1236  
1237  
1238  
1239  
1240  
1241  
1242  
1243  
1244  
1245  
1246  
1247

NORMAL TRANSFERS ARE RANDOM BETWEEN 3 AND 1280 WORDS, THIS PARAMETER WILL ALLOW YOU TO SPECIFY HOW MANY WORDS SHOULD BE COMPARED PER SECTOR IN CORE AFTER EACH READ. IF THE VALUE SPECIFIED IS GREATER THAN THAT READ IN ONLY THE NUMBER READ IN ARE COMPARED. THE FEWER WORDS COMPARED IN CORE ON EACH READ THE FASTER THROUGHPUT THE EXERCISER WILL HAVE.

LIMITS 0 - 128

"# OF DATA ERR RPT'D PER BUF (D) 3 ?"

THIS PARAMETER WILL LIMIT THE NUMBER OF IN CORE MISCOMPARES PRINTED. THE PROGRAM WILL CONTINUE TO COMPARE AS MANY WORDS AS SPECIFIED BUT WILL INHIBIT THE PRINTOUT ONCE THIS LIMIT IS REACHED. AFTER ALL WORDS ARE CHECKED A SUMMARY WILL BE PRINTED:

X WORDS BAD OUT OF 128 WORDS READ

LIMITS 0 126

"MAX HD (D) 1 ?"

REPRESENTS MAXIMUM HEAD TO USE IN SEEK OPERATIONS.

LIMITS 0 - 1

"MIN HD (D) 0 ?"

REPRESENTS MINIMUM HEAD TO USE IN SEEK OPERATIONS

LIMITS 0 - 1

"CHANGE VALUES OF MXCYL & MINCYL (L) Y ?"

IF NO THEN THE NEXT TWO QUESTIONS WILL BE SKIPPED

"MAX CYL (D) 511 ?"

MAXIMUM INNER CYLINDER TO BE USED IN SEEK OPERATIONS.

LIMITS 0 - 255. (RL01) OR 511. (RL02)

1249  
1250  
1251  
1252  
1253  
1254  
1255  
1256  
1257  
1258  
1259  
1260  
1261  
1262  
1263  
1264  
1265  
1266  
1267  
1268  
1269  
1270  
1271  
1272  
1273  
1274  
1275  
1276  
1277  
1278  
1279  
1280  
1281  
1282  
1283  
1284  
1285  
1286  
1287  
1288  
1289  
1290  
1291  
1292  
1293  
1294  
1295  
1296  
1297

"MIN CYL (D) 0 ?"

MINIMUM OUTER CYLINDER TO BE USED IN SEEK OPERATIONS.

LIMITS 0 - 255. (RL01) OR 511. (RL02)

"MAX SEC (D) 0 ?"

MAXIMUM SECTOR TO START TRANSFER ON

LIMITS 0 - 39

"MIN SEC (D) 0 ?"

MINIMUM SECTOR TO START TRANSFER ON

LIMITS 0 - 39

AFTER ANSWERING THE LAST SOFTWARE PARAMETER THE PROGRAM WILL START THE TESTING.

### 3.0 ERROR INFORMATION

-----  
ALL ERRORS ARE PRINTED VIA CONSOLE DEVICE. THE ERROR INCLUDES ERROR NUMBER, TYPE AND PROGRAM LOCATION. ERRORS INCLUDE REGISTERS BEFORE AND AT ERROR WITH RELEVANT DATA.

### 3.1 ERROR REPORTING

-----  
THE FOLLOWING ARE ERROR HEADINGS THAT MAY BE ENCOUNTERED WHILE RUNNING. A BRIEF DESCRIPTION IS GIVEN.

"SFT ERROR"

AN ERROR WAS DISCOVERED, BUT ON RETRY THE ERROR DID NOT PERSIST. INFO GIVEN IS ERROR, RLCS, RLBA, AND RLDA

"EXH'D RETRY ON SEEK"

THE NUMBER OF RETRIES GIVEN HAVE FAILED TO POSITION DRIVE TO THE GIVEN TRACK. INFO GIVEN IS RLCS,RLDA,RLBA, LAST POSITION,PRESENT POSITION, AND DRIVE STATUS

1299  
1300 "VOL CHK WILL NOT RESET"  
1301  
1302 A DRIVE RESET WILL NOT RESET VOLUME CHECK BIT  
1303  
1304 "DID NOT REC'R FROM PWR UP"  
1305  
1306 DRIVE DID NOT COME BACK UP AFTER A POWER FAILURE  
1307  
1308 "DATA DMP - DATA CHECK/GARBBLED DATA"  
1309  
1310 THE PROGRAM ENCOUNTERED A DATA CHECK ERROR BUT WAS UNABLE TO MAKE  
1311 SENSE OUT OF THE FIRST TWO WORDS, WHICH ARE USED TO KEY OFF OF.  
1312 THEREFORE ALL WORDS OF SECTOR ARE DUMPED.(REFER TO SECTION  
1313 2.3.13.21)  
1314  
1315  
1316 "LIMITS EXCEEDED! HIGH - X LOW - Y"  
1317  
1318 ANSWER GIVEN IS NOT WITHIN LIMITS FOR QUESTION.  
1319  
1320  
1321 "NO DEFAULT PROVIDED!"  
1322  
1323 CANNOT <CR> TO THIS QUESTION  
1324  
1325  
1326 "ILLEGAL COMMAND"  
1327  
1328 START, RESTART, CONTINUE, PRINT TYPED IN WRONG FORM  
1329  
1330  
1331 "ILL ENTRY IN P-TABLE"  
1332  
1333 ANSWERS IN HARDWARE SECTION THAT ARE NOT LEGAL (I.E., MORE THAN TWO  
1334 CONTROLLERS)  
1335  
1336  
1337 "CAN'T READ FACTORY BAD SECTOR FILE"  
1338  
1339 PROGRAM IS UNABLE TO READ ANY OF THE FACTORY FILES  
1340  
1341  
1342 "CAN'T READ FIELD BAD SECTOR FILE"  
1343  
1344 PROGRAM IS UNABLE TO READ ANY OF THE FIELD FILES  
1345  
1346  
1347 "MORE THAN 16 BAD SECTORS"  
1348  
1349 PROGRAM LIMITS EXERCISING CARTRIDGES TO THOSE WITH LESS THAN 16 BAD  
1350 SECTORS.

1352  
1353  
1354  
1355  
1356  
1357  
1358  
1359  
1360  
1361  
1362  
1363  
1364  
1365  
1366  
1367  
1368  
1369  
1370  
1371  
1372  
1373  
1374  
1375  
1376  
1377  
1378  
1379  
1380  
1381  
1382  
1383  
1384  
1385  
1386  
1387  
1388  
1389  
1390  
1391  
1392  
1393  
1394  
1395  
1396  
1397  
1398  
1399  
1400  
1401  
1402  
1403  
1404  
1405  
1406

NO DRIVES ENTERED

EITHER NO DRIVES WERE ENTERED OR ALL DRIVES THAT WERE ENTERED WERE DROPPED FOR ONE REASON OR ANOTHER. THE PROGRAM WILL LOOP AFTER PRINTING THE ERROR, WAITING FOR ^C. A START COMMAND IS NOW NECESSARY.

'DRV NOT RDY W/O DRV ERR"

ON COMPLETION OF A COMMAND, DRIVE READY IS CHECKED FOR A POSSIBLE TRACKING DRIFT PROBLEM. IF THERE IS NO DRIVE READY A GET STATUS IS DONE TO VERIFY THAT THE DRIVE IS NOT IN PROCESS OF SEEKING. IF IT IS SEEKING THE CONDITION IS LEGAL. THIS TYPEOUT IMPLIES THERE WERE NO DRIVE ERRORS WHICH MAY HAVE CAUSED DRIVE READY TO GO AWAY.

'TRCK ERR"

THIS ERROR MEANS THAT THE DRIVE IS NO LONGER ON THE TRACK SELECTED. ANY SUBSEQUENT READ HEADER, READ OR WRITE COMMANDS WILL PRINT THIS ERROR IF THE TRACK IS NOT CORRECT. THIS ERROR WILL PRINT THE POSITION BEFORE THE LAST SEEK, THE PRESENT POSITION AND THE EXPECTED POSITION.

"MIS-SK ERR"

AFTER A SEEK WAS DONE, READ HEADER IS DONE TO VERIFY THE SEEK. THE ERROR PRINTOUT WILL INCLUDE THE LAST POSITION BEFORE THE SEEK, THE PRESENT POSITION AND THE EXPECTED POSITION.

"DRV STAT ERR"

THE RESULT OF A GET STATUS OPERATION IS INCORRECT. EITHER A ERROR BIT IS SET OR THE STATE IS WRONG

"MRD ERR"

THE NUMBER OF RETRIES WERE EXHAUSTED WITH OUT SUCCESS THE ERROR PRINTOUT CONSISTS OF ALL REGISTERS BEFORE COMMAND AND AT TIME OF ERROR.

"INIT WR OF SEC BAD"

WHILE WRITING THE PACK INITIALLY, THE SECTOR INDICATED COULD NOT BE WRITTEN AND VERIFIED. THIS SECTOR WAS NOT IN THE BAD SECTOR FILE. ONE OF THE FOLLOWING STEPS SHOULD BE ISSUED: A) STOP THE EXERCISER AND CHANGE CARTRIDGE, B) STOP THE EXERCISER AND VERIFY THE CARTRIDGE ON A PDP-11 (USE THE BAD SECTOR FILE TOOL - CZRLMA) OR C) IGNORE ALL ERRORS FROM THAT SECTOR.

1408  
1409  
1410  
1411  
1412  
1413  
1414  
1415  
1416  
1417  
1418  
1419  
1420  
1421  
1422  
1423  
1424  
1425  
1426  
1427  
1428  
1429  
1430  
1431  
1432  
1433  
1434  
1435  
1436  
1437  
1438  
1439  
1440  
1441  
1442  
1443  
1444  
1445  
1446  
1447  
1448

3.2 ERROR HALTS

ERROR HALTS ARE SUPPORTED PER DESCRIBED IN THE PREVIOUS SECTION WITH /FLAG:MOE. THERE ARE NO OTHER HALTS.

4.0 PERFORMANCE AND PROGRESS REPORTS

4.1 PERFORMANCE REPORTS

PERFORMANCE REPORTS ARE PRINTED BY OPERATOR REQUEST THROUGH THE DRS "PRINT" COMMAND. THE FORMAT IS:

\*\*\* RLO1 PERFORMANCE REPORT \*\*\*

RLCS: XXXXXX DRIVE: Y DRIVE TYPE = RLOX  
PACK SERIAL #: DDDDDDDDD  
TOTAL SEEKS: I IIII  
WORDS READ: JJJJJJJJJ  
WORDS WRITTEN: KKKKKKKKK

ERRORS  
DRV-ER: N SEEK: N TRACK: N DATA: N  
HARD: N SOFT: N  
DCK: N MCRC: N NXM: N MRF: N  
DLT: N OPI: N

WHERE:

XXXXXX IS ADDRESS OF CONTROLLER  
Y IS DRIVE NUMBER  
DDDDDDDD - IS 10 DIGIT OCTAL SERIAL NUMBER OF PACK  
IIII IS TOTAL NUMBER OF SEEKS SINCE START  
JJJJ IS TOTAL NUMBER OF WORDS READ SINCE START  
KKKK IS TOTAL NUMBER OF WORDS WRITTEN SINCE START  
N IS NUMBER OF THAT TYPE ERROR SINCE START

D:

1450  
1451  
1452  
1453  
1454  
1455  
1456  
1457  
1458  
1459  
1460  
1461  
1462  
1463  
1464  
1465  
1466  
1467  
1468  
1469  
1470  
1471  
1472  
1473  
1474  
1475  
1476  
1477  
1478  
1479  
1480  
1481  
1482  
1483  
1484  
1485  
1486  
1487  
1488  
1489  
1490  
1491  
1492  
1493  
1494  
1495  
1496  
1497  
1498  
1499  
1500  
1501  
1502  
1503  
1504  
1505  
1506

4.2 PROGRESS REPORTS

THE ONLY PROGRESS REPORT IS THE PERFORMANCE REPORT.

5.0 DEVICE INFORMATION TABLES

THE RL11/RLV11 CONTROLLER HAS THE FOLLOWING FOUR(4) REGISTERS FOR CONTROL OF THE SUBSYSTEM.

RLCS CONTROL AND STATUS REGISTER (XXXXX0)

- BIT 15 - COMPOSITE ERROR
- BIT 14 - DRIVE ERROR
- BIT 13 - NON EXISTANT MEMORY ERROR
- BIT 12 - HEADER NOT FOUND (WITH BIT 10 SET)  
- DATA LATE (WITH BIT 10 CLEAR)
- BIT 11 - HEADER CRC (WITH BIT 10 SET)  
- DATA CRC (WITH BIT 10 CLEAR)
- BIT 10 - OPERATION INCOMPLETE
- BIT 9/8 - DRIVE SELECT (0-3)
- BIT 7 - CONTROLLER READY
- BIT 6 - INTERRUPT ENABLE
- BIT 5 - EXTENDED BUS ADDRESS (BIT 17)
- BIT 4 - EXTENDED BUS ADDRESS (BIT 16)
- BIT 3-1 - FUNCTION CODE
  - 0 - NOP (POP-11) MAINT (LSI-11)
  - 1 - WRITE CHECK
  - 2 - GET DRIVE STATUS
  - 3 - SEEK
  - 4 - READ HEADER
  - 5 - WRITE DATA
  - 6 - READ DATA
  - 7 - READ WITHOUT HEADER COMPARE

BIT 0 - DRIVE READY

RLBA - BUS ADDRESS REGISTER (XXXXX2)

BITS 15-1 BUS ADDRESS OF DATA TRANSFER  
BIT 0 SHOULD BE 0

RLDA - DISK ADDRESS REGISTER (XXXXX4)

FOR READ/WRITE FUNCTIONS

- BIT 15-7 - CYLINDER ADDRESS FOR TRANSFER
- BIT 6 - SURFACE FOR TRANSFER
- BIT 5-0 - SECTOR FOR TRANSFER (1-40.)

1508  
1509  
1510  
1511  
1512  
1513  
1514  
1515  
1516  
1517  
1518  
1519  
1520  
1521  
1522  
1523  
1524  
1525  
1526  
1527  
1528  
1529  
1530  
1531  
1532  
1533  
1534  
1535  
1536  
1537  
1538  
1539  
1540  
1541  
1542  
1543  
1544  
1545  
1546  
1547  
1548  
1549  
1550  
1551  
1552  
1553  
1554  
1555  
1556  
1557  
1558  
1559  
1560  
1561  
1562  
1563  
1564

## FOR SEEK FUNCTION

BIT 15-7 - DIFFERENCE TO NEW CYLINDER  
BIT 6-5 - MUST BE ZERO (0)  
BIT 4 - SURFACE (0=UPPER, 1=LOWER)  
BIT 3 - MUST BE ZERO (0)  
BIT 2 - SEEK DIRECTION( 1=IN / 0=OUT )  
BIT 1 - MUST BE ZERO (0)  
BIT 0 - MUST BE ONE (1)

## FOR GET STATUS FUNCTION

-----  
BIT 15-4 - IGNORED SHOULD BE ZERO (0)  
BIT 3 - DRIVE RESET  
BIT 2 - MUST BE ZERO (0)  
BIT 1 - MUST BE ONE (1)  
BIT 0 - MUST BE ONE (1)

## RLMP - MULTIPURPOSE REGISTER

## FOR READ/WRITE FUNCTION

-----  
BIT 15 - 0 WORD COUNT (TWO'S COMPLEMENT)

## FOR READ HEADER FUNCTION

-----  
BIT 15-0 - DISK HEADER OF SECTOR (FIRST READ)  
- ZERO WORD (SECOND READ)  
- HEADER CRC (THIRD READ)

## FOR GET STATUS FUNCTION

## HAS DRIVE STATUS

-----  
BIT 15 - WRITE DATA ERROR  
BIT 14 - CURRENT HEAD ERROR (CHE)  
BIT 13 - WRITE LOCK STATUS (WL)  
BIT 12 - SEEK TIME OUT (SKTO)  
BIT 11 - SPI,1 ERROR (SPE)  
BIT 10 - WRITE GATE ERROR (WGE)  
BIT 9 - VOLUME CHECK (VC)  
BIT 8 - DRIVE SELECT ERROR (DSE)  
BIT 7 - DRIVE TYPE IS RL02 IF SET  
BIT 6 - SURFACE (0=UPPPER, 1=LOWER)  
BIT 5 - COVER OPEN  
BIT 4 - HEADS HOME  
BIT 3 - BRUSHES HOME  
BIT 2-0 - STATE BITS  
0 - LOAD STATE  
1 - SPIN UP  
2 - BRUSH CYCLE



1566  
1567  
1568  
1569  
1570  
1571  
1572  
1573  
1574  
1575  
1576  
1577  
1578  
1579  
1580  
1581  
1582  
1583  
1584  
1585  
1586  
1587  
1588  
1589  
1590  
1591  
1592  
1593  
1594  
1595  
1596  
1597  
1598  
1599  
1600  
1601  
1602  
1603  
1604  
1605  
1606  
1607  
1608  
1609  
1610  
1611  
1612  
1613  
1614  
1615  
1616  
1617  
1618  
1619  
1620  
1621  
1622

3 LOAD HEADS  
4 - SEEK TRACK COUNTING  
5 SEEK LINEAR MODE  
6 UNLOAD HEADS  
7 SPIN DOWN

## 6.0 TEST SUMMARIES

### PROGRAM DESCRIPTION

THE PROGRAM WILL TRY TO SIMULATE A USER ENVIRONMENT WITH RANDOM SELECTION OF DRIVES PERFORMING RANDOM OPERATIONS OF GET STATUS, SEEK, READ AND WRITE.

INITIALLY THE BAD SECTOR FILE IS RECOVERED FROM EACH DRIVE AND STORED, THEN EACH PACK IS ENTIRELY WRITTEN RANDOMLY WITH ONE OF EIGHT PREDETERMINED PATTERNS.

THE MAIN LOOP IS A CONTINUOUS LOOP OF THE FOLLOWING STEPS

1. RANDOMLY SELECT A DRIVE
2. CHECK CONTROLLER OF SELECTED DRIVE IS NOT BUSY;
3. THEN STEP 3; ELSE STEP 1
4. RANDOMLY SELECT FUNCTION FOR DRIVE  
IF SEEK/WRITE/WRITE CHECK - THEN GO TO STEP 5  
IF SEEK/READ - THEN GO TO STEP 11  
IF SEEK/READ/READ - THEN GO TO STEP 15  
IF SEEK/READ HDRS/READ W/NO HDR COMPARE/GET STATUS THEN  
GO TO STEP 21
5. GET A RANDOM CYLINDER ADDRESS (NOT THE BAD SECTOR FILE)
6. SEEK TO THE SELECTED CYLINDER AND WAIT TILL COMPLETED
7. GET A RANDOM WORD COUNT FOR THE WRITE FUNCTION - MAKE SURE THAT IT WON'T OVERFLOW THE TRACK
8. GET A RANDOM DATA PATTERN TO WRITE ON THE TRACK POINTED TO
9. ISSUE THE WRITE FUNCTION AND WAIT TILL COMPLETED
10. ISSUE A WRITE CHECK FUNCTION ON THE SAME DISK ADDRESS TO COMPARE THE DATA JUST WRITTEN BY THE WRITE FUNCTION THEN GO TO STEP #1
11. GET A RANDOM CYLINDER # FOR THE SEEK
12. SEEK TO THE SELECTED CYLINDER AND WAIT TILL COMPLETED
13. GET A RANDOM WORD COUNT FOR THE READ FUNCTION - MAKE SURE IT WILL NOT OVERFLOW THE SELECTED TRACK

1624  
1625  
1626  
1627  
1628  
1629  
1630  
1631  
1632  
1633  
1634  
1635  
1636  
1637  
1638  
1639  
1640  
1641  
1642  
1643  
1644  
1645  
1646  
1647  
1648  
1649  
1650  
1651  
1652  
1653  
1654  
1655  
1656  
1657  
1658  
1659  
1660  
1661  
1662  
1663  
1664  
1665  
1666  
1667  
1668  
1669  
1670  
1671  
1672  
1673  
1674  
1675  
1676  
1677  
1678  
1679  
1680

14. ISSUE THE READ FUNCTION AND WAIT TILL COMPLETED ...THE INTERRUPT SERVICE WILL INITIATE A DATA COMPARE ON THE DATA READ (IF THE FUNCTION IS ENABLED) THEN GO TO STEP #1
15. GET A RANDOM CYLINDER FOR THE SEEK
16. SEEK AND WAIT TILL COMPLETED
17. GET A RANDOM WORD COUNT FOR THE READ COMMAND
18. ISSUE A READ COMMAND AND WAIT TILL COMPLETED
19. GET ANOTHER RANDOM WORD COUNT FOR SAME TRACK SELECTED
20. ISSUE A SECOND READ FUNCTION AND WAIT TILL COMPLETED THEN GOTO STEP #1
21. ISSUE A SEEK TO A RANDOM CYLINDER AND WAIT TILL COMPLETED
22. ISSUE A READ HEADER FUNCTION AND WAIT TILL COMPLETED
23. ISSUE A READ DATA WITH NO HEADER COMPARE (1 SECTOR TO BE READ) AND WAIT TILL COMPLETED
24. ISSUE A GET STATUS FUNCTION THEN GO TO STEP #1

THE PROGRAM WILL STAY WITHIN THAT MAIN LOOP UNTIL INTERRUPTED OUT BY A FUNCTION FINISHING AT WHICH TIME THE INTERRUPT SERVICE ROUTINE WILL START EXECUTION.

1. READ ALL REGISTERS OF CONTROLLER THAT INTERRUPTED AND SAVE IMAGES
2. IF NO ERROR SET; THEN STEP 3; ELSE STEP 14
3. CHECK FUNCTION WHICH CAUSED INTERRUPT  
IF WRITE CHECK; THEN STEP 3A  
IF GET STATUS; THEN STEP 5  
IF SEEK; THEN STEP 4A.  
IF READ HEADER; THEN STEP 7  
IF READ; THEN STEP 9  
IF WRITE; THEN STEP 3B
- 3A. CLEAR WRITE CHECK NEEDED FLAG, THEN STEP 4
- 3B. SET WRITE CHECK NEEDED FLAG IF REQUESTED THEN STEP 4
4. IF RETRY > 0 THEN REPORT SOFT ERROR, ELSE STEP 4A
- 4A. EXIT TO MAIN PROGRAM
5. CHECK STATUS FOR:
  - NO ERRORS
  - COVER CLOSED
  - BRUSHES HOME
  - HEADS OUT

1682  
1683  
1684  
1685  
1686  
1687  
1688  
1689  
1690  
1691  
1692  
1693  
1694  
1695  
1696  
1697  
1698  
1699  
1700  
1701  
1702  
1703  
1704  
1705  
1706  
1707  
1708  
1709  
1710  
1711  
1712  
1713  
1714  
1715  
1716  
1717  
1718  
1719  
1720  
1721  
1722  
1723  
1724  
1725  
1726  
1727  
1728  
1729  
1730  
1731  
1732  
1733  
1734  
1735  
1736  
1737

## SEEK LINEAR/TRACKING

- IF THEN STEP 4; ELSE STEP 6
6. REPORT STATUS ERROR; GO TO STEP 4A
  7. SET VERIFICATION DONE FLAG COMPARE PRESENT POSITION WITH  
HEADER WORD IF THEN STEP 4A; ELSE STEP 8
  8. REPORT MIS-SEEK, SET NEW POSITION; GO TO STEP 4
  9. IF DATA TO BE COMPARED; THEN STEP 10; ELSE STEP 4
  10. CHECK VALIDITY OF FIRST TWO WORDS; IF THEN STEP 12; ELSE  
STEP 11.
  11. REPORT GARBLED DATA; GO TO STEP 4
  12. CHECK WORDS READ IN IF OKAY THEN STEP 4A ELSE STEP 13
  13. REPORT DATA ERROR, GO TO STEP 4
  14. IF DRIVE ERROR; THEN STEP 33; ELSE STEP 15
  15. IF NXM; THEN STEP 18; ELSE STEP 16
  16. IF OPI; THEN STEP 18; ELSE STEP 17
  17. IF DLT; THEN STEP 18; ELSE STEP 20
  18. IF RETRY < LIMIT THEN STEP 4A, ELSE STEP 19
  19. REPORT HARD ERROR; CLEAR FLAGS; GO TO STEP 4A
  20. IF MCRC; THEN STEP 24; ELSE STEP 21
  21. IF DCRC, THEN STEP 29; ELSE STEP 22
  22. IF MNF, THEN STEP 30; ELSE STEP 23
  23. YOU SHOULD NEVER GET HERE
  24. IF DOING READ/WRITE THEN STEP 25 IF DOING READ HEADER THEN  
STEP 26
  25. CHECK IF DA IS BAD SECTOR THEN STEP 4A; ELSE STEP 18.
  26. READ 40 HEADERS, IF ALL GOOD THEN STEP 27; ELSE STEP 28
  27. REPORT SOFT HEADER CRC; GO TO 4A
  28. FIGURE OUT BAD HEADER IF IN FILE THEN STEP 4A; ELSE STEP  
18
  29. CHECK IF DA-1 IS IN FILE IF THEN STEP 4A; ELSE STEP 18

1739  
1740  
1741  
1742  
1743  
1744  
1745  
1746  
1747  
1748  
1749  
1750  
1751  
1752  
1753  
1754  
1755  
1756

- 30. READ HEADER. IF ON CORRECT TRACK THEN STEP 31; ELSE STEP 32
- 31. CHECK IF DA IS IN FILE IF THEN STEP 4A, ELSE STEP 18
- 32. REPORT TRACKING; FIX POSITION, GO TO STEP 4
- 33. ACT UPON: VC  
SKTO  
SPE  
WGE  
WDE  
CHE
- 34. GO TO STEP 4

8

HEADER

```

1758          .SBTTL  HEADER
1759
1760          002000          . *2000
1761
1762          .MCALL  SVC
1763
1764 002000          SVC
1765          000000          SVCINS=0
1766          000000          SVCTAG=0
1767
1768 002000          POINTER BGNRPT,BGNSW,BGNSFT,BGNAU,BGNDU
1769
1770 002000          BGNMOD  MDHEDR
1771 002000          HEADER  CNRLK,A,0,0,1,PRI06
002000          103          .ASCII /C/
002001          116          .ASCII /N/
002002          122          .ASCII /R/
002003          114          .ASCII /L/
002004          113          .ASCII /K/
002005          000          .BYTE 0
002006          000          .BYTE 0
002007          000          .BYTE 0
002010          101          .ASCII /A/
002011          060          .ASCII /O/
002012          000000          .WORD 0
002014          000000          .WORD 0
002016          031646          .WORD L$HARD
002020          032022          .WORD L$SOFT
002022          010560          .WORD L$HW
002024          010576          .WORD L$SW
002026          033406          .WORD L$LAST
002030          000000          .WORD 0
002032          000000          .WORD 0
002034          000001          .WORD 1
002036          000000          .WORD 0
002040          010676          .WORD L$DISPATCH
002042          000300          .WORD PRI06
002044          000000          .WORD 0
002046          000000          .WORD 0
002050          003          .BYTE C$REVISION
002051          003          .BYTE C$EDIT
002052          000000          .WORD 0
002054          000000          .WORD 0
002056          000000          .WORD 0
002060          002230          .WORD L$DVTYP
002062          010700          .WORD L$RPT
002064          000000          .WORD 0
002066          000000          .WORD 0
002070          013314          .WORD L$AU
002072          013400          .WORD L$DU
002074          000000          .WORD 0
002076          002122          .WORD L$DESC
002100          104035          EMT  E$LOAD
002102          000000          .WORD 0
002104          010764          .WORD L$INIT
002106          013116          .WORD L$CLEAN
002110          012644          .WORD L$AUTO

```

;JSD REV A - ADDED PRI06

HEADER

002112	010756	.WORD	L\$PROT
002114	000000	.WORD	0
002116	000000	.WORD	0
002120	000000	.WORD	0

1772  
1773 002122  
1774  
1775

ENDMOD

DESCRPT <CNRLK PERFORMS RANDOM OPERATIONS OF GET STATUS, SEEK, READ, AND WRITE>  
.ASCIZ /CNRLK PERFORMS RANDOM OPERATIONS OF GET STATUS, SEEK, READ, AND WRITE/

002122	103	116	122
002125	114	113	040
002130	120	105	122
002133	106	117	122
002136	115	123	040
002141	122	101	116
002144	104	117	115
002147	040	117	120
002152	105	122	101
002155	124	111	117
002160	116	123	040
002163	117	106	040
002166	107	105	124
002171	040	123	124
002174	101	124	125
002177	123	054	040
002202	123	105	105
002205	113	054	040
002210	122	105	101
002213	104	054	040
002216	101	116	104
002221	040	127	122
002224	111	124	105
002227	000		

.EVEN

1776				DEVTYP	<RL01,RL02>
1777 002230				.ASCIZ	RL01,RL02
002230	122	114	060		
002233	061	054	122		
002236	114	060	062		
002241	000				

.EVEN

1778  
1779 .SBTTL BIT AND OFFSET DEFINITIONS

1780 ;DEFINITIONS  
1781 ;DEFINITIONS  
1782 ;DEFINITIONS  
1783 002242 BGNMOD GLBEQAT  
1784  
1785 002242 EQUALS  
;  
; BIT DIFINITIONS  
;  
BIT15== 100000  
BIT14== 40000  
BIT13== 20000  
BIT12== 10000  
BIT11== 4000  
BIT10== 2000

100000
040000
020000
010000
004000
002000

## BIT AND OFFSET DEFINITIONS

```

001000 BIT09== 1000
000400 BIT08== 400
000200 BIT07== 200
000100 BIT06== 100
000040 BIT05== 40
000020 BIT04== 20
000010 BIT03== 10
000004 BIT02== 4
000002 BIT01== 2
000001 BIT00== 1

;
;
001000 BIT9== BIT09
000400 BIT8== BIT08
000200 BIT7== BIT07
000100 BIT6== BIT06
000040 BIT5== BIT05
000020 BIT4== BIT04
000010 BIT3== BIT03
000004 BIT2== BIT02
000002 BIT1== BIT01
000001 BIT0== BIT00

;
; EVENT FLAG DEFINITIONS
; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
;
;
; BIT POSITION IN SECOND STATUS WORD
000040 EF.START== 32. ; (100000) START COMMAND WAS ISSUED
000037 EF.RESTART== 31. ; (040000) RESTART COMMAND WAS ISSUED
000036 EF.CONTINUE== 30. ; (020000) CONTINUE COMMAND WAS ISSUED
000035 EF.NEW== 29. ; (010000) A NEW PASS HAS BEEN STARTED
000034 EF.PWR== 28. ; (004000) A POWER-FAIL/POWER-UP OCCURRED

;
; PRIORITY LEVEL DEFINITIONS
;
000340 PRI07== 340
000300 PRI06== 300
000240 PRI05== 240
000200 PRI04== 200
000140 PRI03== 140
000100 PRI02== 100
000040 PRI01== 40
000000 PRI00== 0

; OPERATOR FLAG BITS
;
000004 EVL== 4
000010 LOT== 10
000020 ADR== 20
000040 IDU== 40
000100 ISR== 100
000200 UAM== 200
000400 BOE== 400
001000 PNT== 1000
002000 PRI== 2000
004000 IXE== 4000
010000 IBE== 10000

```

BIT AND OFFSET DEFINITIONS

	020000	IER==	20000	
	040000	LOE==	40000	
	100000	HOE==	100000	
1786				
1787	000000	CS=0		;CONTROL AND STATUS OFFSET
1788	000002	BA=2		;BUSADDRESS OFFSET
1789	000004	DA=4		;DISK ADDRESS OFFSET
1790	000006	MP=6		;MULTI PURPOSE OFFSET
1791				;CONSTANT OFFSETS FOR INDIVIDUAL DRIVE BUFFERS
1792				;THE ONLY POSITION THAT IS CRITICAL IS THAT OF
1793				;""PRPOS"" IT M U S T (MUST) BE THE LAST ENTRY OF THE BUFFER
1794				
1795	000000	SKCNT=0		;SEEK OPERATION COUNT
1796	000002	RXFR1=2		;READ OPERATION COUNT (BITS) LOW ORDER
1797	000004	RXFR2=4		; " " " " HIGH ORDER
1798	000006	WXFR1=6		;WRITE OPERATION COUNT (BITS) LOW ORDER
1799	000010	WXFR2=10		; " " " " HIGH ORDER
1800	000012	ERRCNT=12		;ERROR COUNT HARD
1801	000014	SFTCNT=14		;ERROR COUNT - SOFT
1802	000016	SKECNT=16		;SEEK ERROR COUNT
1803	000020	DERCNT=20		;DRIVE ERROR COUNT
1804	000022	DCRCER=22		;DATA CRC ERROR COUNT
1805	000024	HCRCER=24		;HEADER CRC ERROR COUNT
1806	000026	DLTCNT=26		;DATA LATE ERROR COUNT
1807	000030	OPICNT=30		;OPERATION INCOMPLETE ERROR COUNT
1808	000032	HNFERR=32		;HEADER NOT FOUND ERROR COUNT
1809	000034	NXMCNT=34		;NON EXISTENT MEMORY ERROR COUNT
1810	000036	RETRY=36		;PRESENT RETRY NUMBER
1811	000040	BDA=40		; " DISK ADDRESS CONTENTS
1812	000042	BMP=42		;PRESENT MULTIPURPOSE CONTENTS
1813	000044	FUNC=44		;LAST FUNCTION LOADED
1814	000046	BCSADR=46		;CSR IMAGE OF LAST COMMAND
1815	000050	LSTHDR=50		;LAST POSITION ON DISK
1816	000052	RTYPE=52		;ERROR ON WHICH RECOVERY IS BEING TRIED
1817	000054	SKCNT1=54		;LOW SEEK COUNT
1818	000056	PRFLGS=56		;INTERNAL FLAGS
1819	000060	RXFR3=60		;THIRD ORDER READ COUNT
1820	000062	WXFR3=62		;THIRD ORDER WRITE COUNT
1821	000064	LSTDA=64		;DISK ADDRESS AT SOFT ERROR
1822	000066	DIFWD=66		;LAST DIFFERENCE WORD OF SEEK
1823	000070	DPHOUR=70		;HOUR OF DRIVE DROPPED
1824	000071	DPHIN=71		;MINUTE OF DRIVE DROPPED
1825	000072	TRERR=72		;TRACKING ERRORS COUNT
1826	000074	DATCER=74		;DATA CMP ERRORS
1827	000076	DOMCK=76		;PERFORM WRITE CHECK
1828	000100	SERNM1=100		;SERIAL NUMBER OF CARTRIDGE
1829	000102	SERNM2=102		;SERIAL NUMBER OF CARTRIDGE
1830	000104	DCS=104		;CSR ADDRESS
1831	000106	DRSEL=106		;DRIVE SELECT BITS(8,9,10)
1832	000110	BBA=110		;PRESENT BUS ADDRESS CONTENTS
1833	000112	BSECPT=112		;POINTER TO BAD SECTOR FILE
1834	000114	RSEEK=114		;SEEK IN PROCESS OF RECOVERY
1835	000116	SOFTCS=116		;CSR OF SOFT ERROR
1836	000120	TDR=120		
1837	000122	WRIPG=122		;WRITE IN PROGRESS FLAG
1838	000124	PRPOS=124		;PRESENT POSITION ON DISK
1839				



## BIT AND OFFSET DEFINITIONS

1840	000001	SKDON=BIT0	
1841	000001	DRDY=BIT0	;DRIVE PEADY
1842	000100	INTEN=BIT6	;INTERRUPT ENABLE
1843	100000	ERR=BIT15	;COMPOSITE ERROR
1844	040000	DERR=BIT14	;DRIVE ERROR
1845	100000	WDE=BIT15	;WRITE DATA ERROR
1846	040000	HCE=BIT14	;HEAD CURRENT ERROR
1847	020000	WL=BIT13	;WRITE LOCK
1848	010000	SKT0=BIT12	;SEEK TIMEOUT ERROR
1849	004000	SPE=BIT11	;SPINDLE TIMEOUT/UNDER/OVER SPEED
1850	002000	WGE=BIT10	;WRITE GATE ERROR
1851	001000	VC=BIT9	;VOLUME CHECK
1852	000400	DSE=BIT8	;DRIVE SELECT ERROR
1853	020000	NXM=BIT13	;NON-EXISTENT MEMORY ERROR
1854	010000	DLT=BIT12	;DATA LATE
1855	004000	DCRC=BIT11	;DATA CRC ERROR
1856	004000	HCRC=BIT11	;HEADER CRC ERROR
1857	010000	HNF=BIT12	;HEADER NOT FOUND ERROR
1858	002000	OPI=BIT10	;OPERATION INCOMPLETE ERROR
1859	000200	CRDY=BIT7	;CONTROLLER READY
1860	000040	BA17=BIT5	;EXTENDED BUS ADDRESS BIT 17
1861	000020	BA16=BIT4	;EXTENDED BUS ADDRESS BIT 16
1862	000002	WRCHK=BIT1	;WRITE CHECK FUNCTION CODE
1863	000004	GSTAT=BIT2	;GET DRIVE STATUS FUNCTION CODE
1864	000006	SEEK=BIT1!BIT2	;SEEK FUNCTION CODE
1865	000010	RDHDR=BIT3	;READ HEADER FUNCTION CODE
1866	000012	WRITE=BIT3!BIT1	;WRITE FUNCTION CODE
1867	000014	READ=BIT3!BIT2	;READ FUNCTION CODE
1868	000013	DRST=BIT3!BIT1!BIT0	;DRIVE RESET COMMAND CODE FOR DRIVE COMMAND WORD
1869	000003	GSBIT=BIT1!BIT0	;GET STATUS COMMAND CODE FOR DRIVE COMMAND WORD
1870	000001	MK=BIT0	;MARKER BIT FOR DRIVE COMMAND WORD(SEEK,GET STATUS)
1871	000004	SIGN=BIT2	;DIRECTION FOR SEEK(0=AWAY FROM SPINDLE)
1872	000020	SKHS=BIT4	;HEAD SELECT FOR SEEK
1873	000100	HEAD=BIT6	;HEAD SELECT FOR READ,WRITE,GET STATUS
1874			
1875			
1876			
1877	000000	CSR=0	
1878	000002	VECT=2	
1879	000004	PRIOR=4	
1880	000006	TYPDR=6	
1881	000010	DRBT=10	
1882	000012	CNT=12	
1883			
1884			
1885			
1886	000000	RLT=0	
1887	000002	ELT=2	
1888	000004	SET=4	
1889	000006	DAT=6	
1890	000010	SKT=10	
1891	000012	TYT=12	
1892	000014	RDT=14	
1893	000016	DDT=16	
1894	000020	CHFLG=20	
1895	000022	MXB=22	
1896	0C0024	MXH=24	

BIT AND OFFSET DEFINITIONS

1897	000026	MNH=26
1898	000030	MXC=30
1899	000032	MNC=32
1900	000034	MXS=34
1901	000036	MNS=36
1902	000040	DCKFG=40
1903	000042	DRFLG=42
1904	000044	MNB=44
1905	000046	SEL=46
1906	000050	OPFLG=50
1907	000052	DET=52
1908	000054	ROF=54
1909	000056	RAN=56
1910	000060	PAT=60
1911	000062	SRLT=62
1912	000064	CLMT=64
1913	000066	AUTO=66
1914	000070	STIP=70
1915	000072	WCK=72
1916	000074	DCD=74
1917	000076	ANS=76

1918  
1919 002242

ENDMOD

.SBTTL MACRO DEFINITIONS

;DELAY EXECUTION OF PROGRAM A SPECIFIED NUMBER OF 100-MILLISECOND TIME COUNTS

```

.MACRO WAITMS ARG,?WAIT
;
;   MOV     @ARG,DLYCNT      ;INITIALIZE DELAY COUNTER           ;JSD REV A
;   MOV     ARG,DLYCNT       ;INITIALIZE DELAY COUNTER           ;JSD REV A
;   ASL     DLYCNT           ;MULTIPLY ARGUMENT BY 2
;   ASL     DLYCNT           ;MULTIPLY ARGUMENT BY 2 AGAIN
;WAIT: DELAY @250.           ;IMPLEMENT 25-MS TIME DELAY       ;JSD REV A
WAIT:  DELAY 250.           ;IMPLEMENT 25-MS TIME DELAY       ;JSD REV A
;   DEC     DLYCNT           ;DECREMENT DELAY COUNT
;   BNE     WAIT             ;BRANCH IF TIME DELAY NOT EXPIRED
    
```

.ENDM

;DELAY EXECUTION OF PROGRAM A SPECIFIED NUMBER OF 100-MICROSECOND TIME COUNTS

```

.MACRO WAITUS ARG
;
;   DELAY @ARG               ;IMPLEMENT 100-US TIME DELAY, ARGUMENT SPECIFIES ;JSD REV A
;   DELAY ARG                ;IMPLEMENT 100-US TIME DELAY, ARGUMENT SPECIFIES ;JSD REV A
;                           ;/THE NUMBER OF 100-US TIME COUNTS
    
```

.ENDM

;ACTIVATE THE CLOCK TO INITIATE THE GENERATION OF CLOCK INTERRUPTS

```

.MACRO CLKON
;   JSR     PC,CLKINI        ;ACTIVATE CLOCK WITH 1-SEC INCREMENTS
;   JSR     PC,CLKST        ;INITIALIZE CLOCK
;                           ;START CLOCK
    
```

.ENDM

;DEACTIVATE THE CLOCK TO HALT THE GENERATION OF CLOCK INTERRUPTS

```

.MACRO CLKOFF
;   CLR     CLKSON           ;INDICATE "CLOCK OFF"
;   CMP     @1,CLKTYP        ;P-CLOCK?
;   BNE     11$              ;BRANCH TO CHECK FOR L CLOCK
;   CLR     @0172540         ;CLEAR P-CLOCK
    
```

1953

## MACRO DEFINITIONS

```

1954      118:   CMP      #2,CLKTYP      ;L CLOCK?
1955      BNE      128      ;BRANCH FOR NO CLOCK
1956      CLR      @#177546      ;CLEAR L-CLOCK
1957
1958      128:
1959      .ENDM
1960
1961      ;REQUEST ELAPSED TIME IN SECONDS OCCURRING BETWEEN SUPERVISOR INITIATION
1962      ;AND THE GENERATION OF THE REQUEST
1963      .MACRO REQTIM ARG
1964      MOV      CLKACC,ARG
1965      .ENDM
1966
1967      .SBTTL GLOBAL DATA AND CONSTANTS
1968
1969      BGNMOD GLBDAT
1970      002242 000000      RECNT:  .WORD  0      ;READ ERROR COUNT
1971      002244 000070      RWCNT:  .WORD  0      ;R/W ERROR COUNT
1972      002246 000000      WHY:    .WORD  0      ;REASON FOR DROPPING DRIVE
1973      002250 000000      TSTDRV: .WORD  0      ;COPY OF SELECTED DRIVE FOR TESTING
1974      002252 000      DRUT:   .BYTE  0      ;DRIVES UNDER TEST
1975      002253 000      DRPRS:  .BYTE  0      ;DRIVES PRESENT
1976      002254 000000      T.DRIVE: .WORD  0      ;TYPE OF DRIVE FROM P-TABLE
1977      002256 000000      SYSMSK: .WORD  0      ;MASK FOR 0-7 DRIVES
1978      002260 176543      MINUM:  .WORD  176543 ;PRIME FOR RANDOM
1979      002262 123456      LONUM:  .WORD  123456 ;NUMBER GENERATOR
1980      002264 100177      CYLMSK: .WORD  100177 ;MASK FOR CYLINDER ONLY
1981      002266 100077      SECMASK: .WORD  100077 ;MASK OUT SECTOR BITS
1982      002270 000177      CMSK:   .WORD  000177
1983      002272 000077      SMSK:   .WORD  000077
1984      002274 000000      WRINIT: .WORD  0      ;WRITE INIT FLAG
1985      002276 000000      WRPOS:  .WORD  0      ;WRITE UNIT FLAG
1986      002300 000000      CYL:    .WORD  0      ;CYLINDER #
1987      002302 000000      SUR:    .WORD  0      ;SURFACE #
1988      002304 000000      SEC:    .WORD  0      ;SECTOR #
1989      002306 000000      REGEN:  .WORD  0      ;REGEN FLAG FOR BUFFERS
1990      002310 000000      KILLDC: .WORD  0      ;INHIBIT DATA COMP FLAG
1991      002312 000000      CLKFRQ: .WORD  0      ;CLOCK FREQUENCY FLAG, 1=60 HZ, 2=50 HZ
1992      002314 000000      CLKTYP: .WORD  0      ;CLOCK TYPE FLAG, 1=P-CLOCK, 2=L-CLOCK
1993      002316 000000      CLKADR: .WORD  0      ;POINTER TO ADDRESS OF SUPERVISOR CLOCK TABLE
1994
1995
1996      ;THE FOLLOWING LOCATIONS ARE CLEARED AS A GROUP (DOWN TO 'STFLG')
1997      ;THEREFORE DON'T INSERT ANY CONSTANTS
1998
1999      002320 174400      CNTLR1: .WORD  174400 ;CSR OF CONTROLLER 1 (LUN 0-3)
2000      002322 000000      CNTLR2: .WORD  0      ;CSR OF CONTROLLER 2 (LUN 4-7)
2001      002324 000000      LSTDR1: .WORD  0      ;BUFFER POINTER OF DRIVE
2002      002326 000000      LSTDR2: .WORD  0      ;BUFFER POINTER OF DRIVE
2003      002330 000000      BCSR:   .WORD  0      ;CSR FROM P-TABLE
2004      002332 000000      BVEC:   .WORD  0      ;VECTOR " "
2005      002334 000000      BPRIOR: .WORD  0      ;PRIORITY " "
2006      002336 000000      BDRSEL: .WORD  0      ;DRIVE " "
2007      002340 000000      HDRFND: .WORD  0      ;FLAG TO INDICATE HDR IN BAD LIST
2008      002342 000000      CHKSEC: .WORD  0      ;SECTOR OF ERROR - USED BY BAD SECTOR LOCATION
2009      002344 000000      DECNT:  .WORD  0      ;DATA ERROR COUNT
2010      002346 000000      TEMPO:  .WORD  0      ;TEMP LOCATION

```

GLOBAL DATA AND CONSTANTS

2011	002350	000000	TEMP1:	.WORD	0	;TEMP LOCATION
2012	002352	000000	TEMP2:	.WORD	0	;TEMP LOCATION
2013	002354	000000	TEMP3:	.WORD	0	; " "
2014	002356	000000	TEMP4:	.WORD	0	; " "
2015	002360	000000	TEMP5:	.WORD	0	; " "
2016	002362	000000	TEMP6:	.WORD	0	; " "
2017	002364	000000	TEMP7:	.WORD	0	; " "
2018	002366	000000	TEMP8:	.WORD	0	; " "
2019	002370	000000	TEMP9:	.WORD	0	; " "
2020	002372	000160	VECT1:	.WORD	160	;VECTOR OF FIRST CONTROLLER
2021	002374	000000	VECT2:	.WORD	0	;VECTOR " 2ND
2022	002376	000000	PRIOR1:	.WORD	0	
2023	002400	000000	PRIOR2:	.WORD	0	
2024	002402	000000	GDDAT:	.WORD	0	
2025	002404	000000	RNTEMP:	.WORD	0	
2026	002406	000000	INTERVAL:	.WORD	0	;KEEPS TRACK OF TIME BETWEEN STATISTICAL REPORTS
2027						;(MINUTES RUNNING TIME)
2028	002410	000000	TICK:	.WORD	0	;STORAGE FOR TICK COUNT
2029	002412	000000	SECOND:	.WORD	0	;SECONDS OF SYSTEM CLOCK
2030	002414	000000	MINUTE:	.WORD	0	;MINUTES OF SYSTEM CLOCK
2031	002416	000000	HOUR:	.WORD	0	;HOURS OF SYSTEM CLOCK
2032	002420	000000	E.CS:	.WORD	0	;IMAGES OF REGISTERS
2033	002422	000000	E.BA:	.WORD	0	;ON INTERRUPT
2034	002424	000000	E.DA:	.WORD	0	
2035	002426	000000	E.MP:	.WORD	0	
2036	002430	000000	E.MP1:	.WORD	0	
2037	002432	000000	E.MP2:	.WORD	0	
2038	002434	000000	C.HDR:	.WORD	0	;CURRENT HEADER - FOR ERROR REPORT
2039	002436	000000	BUF1:	.WORD	0	;BUFFER FOR FIRST CONTROLLER
2040	002440	000000	BUF2:	.WORD	0	;BUFFER FOR SECOND CONTROLLER
2041	002442	000000	MAXWC:	.WORD	0	;MAX WORD COUNT DETERMINED BY CORE
2042	002444	000000	UUT:	.WORD	0	;NUMBER OF UNITS ON SYSTEM
2043	002446	000000	PMRFLG:	.WORD	0	;POWER FAIL INDICATOR
2044	002450	000000	TRPFLG:	.WORD	0	;INDICATES OCCURRENCE OF A TIME-OUT TRAP
2045	002452	000000	STFLG:	.WORD	0	;START FLAG
2046						
2047			;END OF MASS CLEAR			
2048						
2049	002454	000000	CNTFLG:	.WORD	0	;CONTINUE FLAG
2050	002456	000000	FASCII:	.WORD	0	;ASCII MESSAGE OF FUNCTION
2051	002460	000000	FASPNT:	.WORD	0	;POINTER
2052	002462	000000	DMCNT:	.WORD	0	;ERROR COUNT
2053	002464	000000	DMCNT1:	.WORD	0	;ERROR COUNT
2054	002466	000004	ERRVEC:	.WORD	4	;ERROR VECTOR
2055	002470	000034	ST1:	.WORD	34	;STATES ALLOWED
2056	002472	000035	ST2:	.WORD	35	;STATES ALLOWED
2057	002474	000000	OPCALL:	.WORD	0	
2058	002476	000000	INCALL:	.WORD	0	
2059	002500	000000	DLYCNT:	.WORD	0	;DELAY COUNTER FOR WAITMS TIMING MACRO
2060	002502	000000	SYSCLK:	.WORD	0	;FLAG INDICATING PRESENCE OF A SYSTEM CLOCK
2061	002504	000000	CLKSON:	.WORD	0	; "CLOCK ON" INDICATOR
2062	002506	000000	CLKCNT:	.WORD	0	;CLOCK COUNTER TO STORE TICK VALUE
2063	002510	000000	CLKBFR:	.WORD	0	;CLOCK BUFFER TO STORE CLOCK TICK COUNT
2064	002512	000000	CLKACC:	.WORD	0	;CLOCK ACCUMULATOR TO STORE ELAPSED TIME IN
2065						;/SECONDS OF SUPERVISOR TIME
2066	002514	000000	CLKFLD:	.WORD	0	;CLOCK FIELD USED TO CHECK IF LSI-11 CLOCK
2067						;/IS "TICKING"

## GLOBAL DATA AND CONSTANTS

```

2068
2069 002516          ENDMOD
2070
2071          .SBTTL  GLOBAL MESSAGES
2072
2073 002516          BGNMOD  GLBTXT
2074
2075          ;GLOBAL TEXT
2076
2080
2081 002516          124      111      115  TIME:      .ASCIZ  "TIME: "
2082 002525          040      122      114  MRLCS:     .ASCIZ  " RLCS: "
2083 002535          040      050      122  CRLCS:     .ASCIZ  " (RLCS): "
2084 002547          076      076      040  MFUNC:     .ASCIZ  ">> FUNCTION: "
2085 002565          040      050      122  CRLBA:     .ASCIZ  " RLBA): "
2086 002577          040      050      122  CRLDA:     .ASCIZ  " (RLDA): "
2087 002611          040      050      122  CRLMP:     .ASCIZ  " (RLMP): "
2088
2089 002623          104      111      106  DIFMSG:    .ASCIZ  /DIF WD: /
2090 002634          120      101      103  CART:      .ASCIZ  /PACK SERIAL #: /
2091 002654          116      117      040  NOCRDY:    .ASCIZ  /NO CRDY/
2092 002664          104      122      111  DNROY:     .ASCIZ  /DRIVE NOT READY/
2093 002704          104      122      040  NORDY:     .ASCIZ  /DR NOT RDY W/O DR ERR/
2094 002732          102      125      107  PRGER:     .ASCIZ  /BUG/
2095 002736          111      116      111  NMRTS:     .ASCIZ  /INIT JR OF SEC BAD/
2096 002761          040      123      105  SMSG:      .ASCIZ  / SECTOR: /
2097 002773          116      117      040  EXHAUS:    .ASCIZ  /NO GOOD HDR/
2098 003007          125      116      104  UDERR:     .ASCIZ  /UNDIAGNOSABLE ERR/
2099 003031          123      105      105  MSKER:     .ASCIZ  /SEEK ERR/
2100 003042          123      117      106  MSFER:     .ASCIZ  /SOFT ERR ENC'D/
2101 003061          104      122      040  DRIVER:    .ASCIZ  /DR ERR/
2102 003070          104      122      040  MDERS:     .ASCIZ  /DR ERR WILL NOT RESET/
2103 003116          104      122      040  MDSER:     .ASCIZ  /DR STAT ERR/
2104 003132          126      117      114  MVCER:     .ASCIZ  /VOL CHK WILL NOT CLR/
2105 003157          127      122      040  MGEST:     .ASCIZ  /MR GATE ERR WILL NOT RESET/
2106 003212          104      122      040  MRDER:     .ASCIZ  /DR ERR - RECOVERED/
2107 003235          104      101      124  MD CER:    .ASCIZ  /DATA CMP ERR/
2108 003252          110      101      122  MDER:      .ASCIZ  /HARD ERROR/
2109 003265          104      101      124  DMPDCK:    .ASCIZ  /DATA DUMP - DCK/
2110 003305          124      122      101  TRACK:     .ASCIZ  /TRACKING ERR/
2111 003322          110      122      104  ERLMT:     .ASCIZ  /HRD ERR LMT EXC'D/
2112 003344          123      113      040  SERLMT:    .ASCIZ  /SK ERR LMT EXC'D/
2113 003365          123      106      124  SFMSG:     .ASCIZ  /SFT ERR LMT EXC'D/
2114 003407          104      101      124  DCDMSG:    .ASCIZ  /DATA ERR LMT EXC'D/
2115 003432          104      122      040  DERMSG:    .ASCIZ  /DR ERR LMT EXC'D/
2116 003453          102      125      106  OVER:      .ASCIZ  /BUFFER CHOSEN TOO BIG  WAS /
2117 003510          122      105      121  REQ:       .ASCIZ  /REQ BY OPR/
2118 003523          105      130      110  SEXHAU:    .ASCIZ  /EXH'D RETRY ON SEEK/
2119 003547          110      104      123  UNLOAD:    .ASCIZ  /HDS NOT UNLD ON ERR/
2120 003573          104      122      040  NOLOAD:    .ASCIZ  /DR WLD NOT LD/
2121 003611          117      120      105  SOPLMT:    .ASCIZ  /OPER LMTS EXC'D/
2122 003631          107      101      122  NOREV:     .ASCIZ  /GARBLED DATA - CAN'T CHECK IT/
2123 003667          115      117      122  HBDMSG:    .ASCIZ  /MORE THAN 16 BAD SECTORS/
2124 003720          116      117      040  MWSEC:     .ASCIZ  /NO FACTORY FILE/
2125 003740          116      117      040  SWSEC:     .ASCIZ  /NO FIELD FILE/
2126 003756          120      055      124  MPT:       .ASCIZ  /P-TABLE: /
2127 003770          111      114      114  ILLEG:     .ASCIZ  /ILL P-TABLE/

```

GLOBAL MESSAGES

```

2128 004004      040      126      105 MVEC:  .ASCIZ  / VECTOR: /
2129 004016      116      117      040 NODRIV: .ASCIZ  /NO DRIVES/
2130 004030      040      104      122 DRNM:  .ASCIZ  / DRIVE: /
2131 004041      040      114      123 LPS:   .ASCIZ  / LST POS: /
2132 004054      105      130      120 EPS:   .ASCIZ  /EXP POS: /
2133 004066      040      122      105 RPS:   .ASCIZ  / REC POS: /
2134 004101      104      122      040 NOPWR: .ASCIZ  /DR DID REC'R FROM PWR UP/
2135 004132      101      124      040 BUSAD: .ASCIZ  /AT BUS ADDR: /
2136 004150      122      105      124 MRT:   .ASCIZ  /RETRYS: /
2137 004161      040      105      122 ERT:   .ASCIZ  / ERROR TYPE: /
2138 004177      123      124      101 MST:   .ASCIZ  /STATUS WAS: /
2139 004214      040      123      110 MST1:  .ASCIZ  / SHOULD BE: /
2140 004231      040      122      105 RT1:   .ASCIZ  / RETRIES ATTEMPTED/
2141 004254      040      105      130 EXP:   .ASCIZ  / EXP'D: /
2142 004265      040      122      105 RCD:   .ASCIZ  / REC'D: /
2143 004276      104      122      111 DROP: .ASCIZ  /DRIVE DROPPED/
2144 004314      040      110      116 MTHNF: .ASCIZ  / HNF/
2145 004321      040      110      103 MTHCRC: .ASCIZ  / HCRC/
2146 004327      040      104      103 MTDRC: .ASCIZ  / DCK/
2147 004334      040      104      114 MTDLT: .ASCIZ  / DLT/
2148 004341      040      117      120 MTOPI: .ASCIZ  / OPI/
2149 004346      040      116      130 MTNXM: .ASCIZ  / NXM/
2150 004353      040      104      122 MTDV:  .ASCIZ  / DRV/
2151 004360      124      105      123 MSTART: .ASCIZ  /TESTING STARTED/
2152 004400      127      122      111 MSWRPK: .ASCIZ  /WRITING PACK /
2153 004416      120      101      103 NORDDC: .ASCIZ  /PACK NOT FULLY INIT'D...DATA COMPARE INHIBITED/
2154 004476      103      125      122 ERRHDR: .ASCIZ  /CURRENT POSITION (HDR) = /
2155 004530      123      131      123 NOCLK:  .ASCIZ  /SYSTEM CLOCK IS NOT AVAILABLE/
2156 004566      120      105      122 NOREPT: .ASCIZ  /PERFORMANCE REPORTS WILL NOT BE PRINTED/
2157 004636      104      111      104 NOTRDY: .ASCIZ  /DID NOT RESPOND WITH "READY"/
2158 004673      116      117      040 NOCTLR: .ASCIZ  /NO CONTROLLER/
2159 004711      123      131      123 INSMEM: .ASCIZ  /SYSTEM FATAL ERROR - INSUFFICIENT MEMORY BUFFER SPACE/
2160
2161      ; THIS LIST OF ASCII TEXT IS USED AS A TABLE FOR PRINTING
2162      ; FUNCTIONS IN ERROR MESSAGES  TABLE IS "MTCR - MTRD".
2163      ; THE ORDER IS IMPORTANT AS WELL AS THE LENGTH OF EACH
2164      ; ASCII STRING. EACH STRING IS SEVEN(10) BYTES PLUS ZERO
2165      ; FILL BYTE (TOTAL 8(EIGHT) BYTES) LONG.  USED IN LINE1
2166      ; SUBROUTINE.....
2167      ;.....
2168
2169 004777      040      127      122 MTCR:  .ASCIZ  / WRCHK /
2170 005007      040      107      124 MTGS:  .ASCIZ  / GTSTAT/
2171 005017      040      123      105 MTSK:  .ASCIZ  / SEEK /
2172 005027      040      122      104 MTRH:  .ASCIZ  / RDHDR /
2173 005037      040      127      122 MTRW:  .ASCIZ  / WRITE /
2174 005047      040      122      105 MTRD:  .ASCIZ  / READ /
2175 005057      040      122      104 MTRNH: .ASCIZ  / RD-NHD/
2176
2177      ;.....
2178      ;END OF LIST - YOU CAN PUT ANYTHING YOU WANT HERE
2179      ;.....
2180
2181      .NLIST  CND,MD,ME
2182
2183      .EVEN
2184

```

## GLOBAL MESSAGES

```

2185 005070          ENDMOD
2186
2187          .SBTTL  ERROR MESSAGES
2188
2189 005070          BGNMOD  GLBERR
2190
2191                                     ;GENERAL ERROR REPORT
2192
2193 005070          BGNMSG  ERR1
2194 005070 004737 006270          JSR      PC,LINE3
2195 005074          ENDMSG
2196 005074          L10000:
2197 005074 104423          TRAP    C#MSG
2198
2199                                     ;MIS-SEEK ERROR REPORT
2200 005076          BGNMSG  ERR2
2201 005102 004737 006270          JSR      PC,LINE3
2202 005102 010146          PRINTB  #FMT4,#DIFMSG,DIFWD(R4),#LPS,LSTHDR(R4),#EPS,PRPOS(R4),#RPS,R1
2203 005104 012746 004066          MOV     R1,-(SP)
2204 005110 016446 000124          MOV     #RPS,-(SP)
2205 005114 012746 004054          MOV     PRPOS(R4),-(SP)
2206 005120 016446 000050          MOV     #EPS,-(SP)
2207 005124 012746 004041          MOV     LSTHDR(R4),-(SP)
2208 005130 016446 000066          MOV     #LPS,-(SP)
2209 005134 012746 002623          MOV     DIFWD(R4),-(SP)
2210 005140 012746 007044          MOV     #DIFMSG,-(SP)
2211 005144 012746 000011          MOV     #FMT4,-(SP)
2212 005150 010600          MOV     #11,-(SP)
2213 005152 104414          MOV     SP,R0
2214 005154 062706 000024          TRAP   C#PNTB
2215 005160          ADD     #24,SP
2216 005160          ENDMSG
2217 005160          L10001:
2218 005160 104423          TRAP    C#MSG
2219
2220                                     ;SOFT ERROR RECOVERABLE ERROR REPORT
2221 005162          BGNMSG  ERR3
2222 005162 004737 006014          JSR      PC,LINE1
2223 005166 016446 000064          PRINTB  #FMT2A,#CRLCS,SOFTCS(R4),#CRLBA,#BBA(R4),#CRLDA,LSTDA(R4)
2224 005172 012746 002577          MOV     LSTDA(R4),-(SP)
2225 005176 017446 000110          MOV     #CRLDA,-(SP)
2226 005202 012746 002565          MOV     #BBA(R4),-(SP)
2227 005206 016446 000116          MOV     #CRLBA,-(SP)
2228 005212 012746 002535          MOV     SOFTCS(R4),-(SP)
2229 005216 012746 006675          MOV     #CRLCS,-(SP)
2230 005222 012746 000007          MOV     #FMT2A,-(SP)
2231 005226 010600          MOV     #7,-(SP)
2232 005230 104414          MOV     SP,R0
2233 005232 062706 000020          TRAP   C#PNTB
2234 005236 016437 000064          ADD     #20,SP
2235 005244 004537 006450          MOV     LSTDA(R4),TEMPO ;GET THE ADDRESS TO PRINT
2236 005250          JSR      R5,TELCYL ;CONVERT FOR PRINTING
2237 005250 016446 000052          PRINTB  #FMT5,#MRT,RETRY(R4),#ERT,RTYPE(R4)
2238 005254 012746 004161          MOV     RTYPE(R4),-(SP)
2239 005260 016446 000036          MOV     #ERT,-(SP)
2240          MOV     RETRY(R4),-(SP)

```

ERROR MESSAGES

005264	012746	004150	MOV	#MRT, (SP)	
005270	012746	007077	MOV	#FMT5, -(SP)	
005274	012746	000005	MOV	#5, (SP)	
005300	010600		MOV	SP, R0	
005302	104414		TRAP	C#PNTB	
005304	062706	000014	ADD	#14, SP	
2211	005310		ENDMSG		
	005310		L10002:	TRAP	C#MSG
	005310	104423			
2212					
2213					;GET STATUS ERROR REPORT
2214					
2215	005312		BGNMSG	ERR4	
2216	005312	004737	JSR	PC, LINE3	
2217	005316		PRINTB	#FMT6, #MST, E.MP, #MST1, ST1, ST2	
	005316	013746	MOV	ST2, -(SP)	
	005322	013746	MOV	ST1, (SP)	
	005326	012746	MOV	#MST1, -(SP)	
	005332	013746	MOV	E.MP, -(SP)	
	005336	012746	MOV	#MST, -(SP)	
	005342	012746	MOV	#FMT6, -(SP)	
	005346	012746	MOV	#6, -(SP)	
	005352	010600	MOV	SP, R0	
	005354	104414	TRAP	C#PNTB	
	005356	062706	ADD	#16, SP	
2218	005362		ENDMSG		
	005362		L10003:	TRAP	C#MSG
	005362	104423			
2219					
2220					;DATA ERROR SUMMARY
2221					
2222	005364		BGNMSG	ERR6	
2223	005364	004737	JSR	PC, LINE2	
2224	005370	016400	MOV	BMP(R4), R0	
2225	005374		PRINTB	#FMT9A, DECNT, R0	
	005374	010046	MOV	R0, -(SP)	
	005376	013746	MOV	DECNT, -(SP)	
	005402	012746	MOV	#FMT9A, -(SP)	
	005406	012746	MOV	#3, -(SP)	
	005412	010600	MOV	SP, R0	
	005414	104414	TRAP	C#PNTB	
	005416	062706	ADD	#10, SP	
2226	005422		ENDMSG		
	005422		L10004:	TRAP	C#MSG
	005422	104423			
2227					
2228					;NON-RECOVERABLE ERROR REPORT
2229					
2230	005424		BGNMSG	ERR7	
2231	005424		PRINTB	#FMT8, RETRY(R4), #RT1	
	005424	012746	MOV	#RT1, -(SP)	
	005430	016446	MOV	RETRY(R4), -(SP)	
	005434	012746	MOV	#FMT8, -(SP)	
	005440	012746	MOV	#3, -(SP)	
	005444	010600	MOV	SP, R0	
	005446	104414	TRAP	C#PNTB	
	005450	062706	ADD	#10, SP	



ERROR MESSAGES

2232 005454 004737 006270

2233 005460

005460

005460

104423

L10005:

JSR PC,LINE3

ENDMSG

TRAP C#MSG

2234

2235

2236

2237 005462

2238 005462

2239 005466

2240 005474

2241 005500

005500 011246

005502 012746

005506 013746

005512 012746

005516 016446

005522 012746

005526 017446

005532 012746

005536 012746

005542 012746

005546 016500

005550 104414

005552 062706

2242 005556

005556 010246

005560 012746

005564 012746

005570 010600

005572 104414

005574 062706

2243 005600

005600

005600

104423

L10006:

TRAP C#MSG

2244

2245

2246 005602

2247

2248 005602

2249 005606

005606 016446

005612 012746

005616 010146

005620 012746

005624 012746

005630 012746

005634 010600

005636 104414

005640 062706

2250 005644

005644

005644

104423

L10007:

TRAP C#MSG

2251

2252

2253

2254 005646

BGNMSG

ERR10

;BAD DATA COMPARE ERROR REPORT

002346

ERR8

JSR PC,LINE2

MOV BDA(R4),TEMPO

JSR R5,TELCYL

PRINTB

#FMT10A,#CRLBA,#BBA(R4),#CRLDA,BDA(R4),#EXP,GDDAT,#RCD,(R2)

MOV (R2),-(SP)

MOV #RCD,-(SP)

MOV GDDAT,-(SP)

MOV #EXP,-(SP)

MOV BDA(R4),-(SP)

MOV #CRLDA,-(SP)

MOV #BBA(R4),-(SP)

MOV #CRLBA,-(SP)

MOV #FMT10A,-(SP)

MOV #11,-(SP)

MOV SP,R0

TRAP C#PNTB

ADD #24,SP

PRINTB #FMT10B,R2

MOV R2,-(SP)

MOV #FMT10B,-(SP)

MOV #2,-(SP)

MOV SP,R0

TRAP C#PNTB

ADD #6,SP

ENDMSG

;REPORT THE CYL # & SECTOR/HEAD

;DRIVE ERROR

;INVALID ENTRY IN P-TABLE REPORT

ERROR MESSAGES

```

2255 005646          PRINTB  #FMT11,#MPT,R1,#MRLCS,BCSR,#MVEC,BVEC
      005646 013746 002332      MOV    BVEC,-(SP)
      005652 012746 004004      MOV    #MVEC,-(SP)
      005656 013746 002330      MOV    BCSR,-(SP)
      005662 012746 002525      MOV    #MRLCS,(SP)
      005666 010146          MOV    R1,-(SP)
      005670 012746 003756      MOV    #MPT,-(SP)
      005674 012746 007371      MOV    #FMT11,-(SP)
      005700 012746 000007      MOV    #7,-(SP)
      005704 010600          MOV    SP,R0
      005706 104414          TRAP   C#PNTB
      005710 062706 000020      ADD    #20,SP
2256 005714          L10010: TRAP   C#MSG
      005714          TRAP   C#MSG
      005714 104423          TRAP   C#MSG
2257 005716          BGNMSG ERR12
2258 005716          JSR    PC,LINE3
2259 005716          ENDMSG
2260 005716 004737 006270          JSR    PC,LINE3
2261 005722          L10011: TRAP   C#MSG
2262 005722 104423          TRAP   C#MSG
2263 005724          BGNMSG ERR13
2264 005724          JSR    PC,LINE3
2265 005724 004737 006270          MOV    DCS(R4),R3
2266 005730 016403 000104          MOV    MP(R3),E.MP      ;GET HEADER
2267 005734 016337 000006 002426      PRINTB #FMT14C          ;CRLF
2268 005742          MOV    #FMT14C,-(SP)
      005742 012746 007501          MOV    #1,-(SP)
      005746 012746 000001          MOV    SP,R0
      005752 010600          TRAP   C#PNTB
      005754 104414          ADD    #4,SP
      005756 062706 000004          PRINTB #FMT12,#ERRHDR,C.HDR ;PRINT THE HEADER MESSAGE
2269 005762          MOV    C.HDR,-(SP)
      005762 013746 002434          MOV    #ERRHDR,-(SP)
      005766 012746 004476          MOV    #FMT12,-(SP)
      005772 012746 007411          MOV    #3,-(SP)
      005776 012746 000003          MOV    SP,R0
      006002 010600          TRAP   C#PNTB
      006004 104414          ADD    #10,SP
      006006 062706 000010          ENDMSG
2270 006012          L10012: TRAP   C#MSG
      006012          TRAP   C#MSG
      006012 104423          TRAP   C#MSG
2271 006014          LINE1: MOV    FUNC(R4),FASPNT      ;GET FUNCTION
2272 006014 016437 000044 002460      MOV    #MTCR,FASCII      ;FIRST FUNCTION ASCIZ
2273 006022 012737 004777 002456      BIC    #INTEN,FASPNT      ;CLEAR INTERRUPT ENABLE
2274 006030 042737 000100 002460      ASR    FASPNT            ;ALIGN - NOW = 1 TO 7
2275 006036 006237 002460          DEC    FASPNT            ;DOWN COUNT FUNCTION
2276 006042 005337 002460          BEQ    2#                ;FOUND?
2277 006046 001404          ADD    #8.,FASCII        ;NO NEXT ONE
2278 006050 062737 000010 002456      BR     1#                ;LOOP
2279 006056 000771          ;2#: PRINTB #FMT10,#TIME,HOUR,MINUTE,SECOND,#MRLCS,DCS(R4),#DRNM,<B,DRSEL+1(R4)> ;JSD
2280 006060          ;2#: PRINTB #FMT10,#MRLCS,DCS(R4),#DRNM,<B,DRSEL+1(R4)> ;JSD
2281 006060          ;JSD
2282 006060          ;JSD
REV A
REV A

```

ERROR MESSAGES

	006060	005046		CLR	(SP)	
	006062	156416	000107	BISB	DRSEL+1(R4),(SP)	
	006066	012746	004030	MOV	#DRNM,-(SP)	
	006072	016446	000104	MOV	DCS(R4),-(SP)	
	006076	012746	002525	MOV	#MRLCS,-(SP)	
	006102	012746	007277	MOV	#FMT10,-(SP)	
	006106	012746	000005	MOV	#5,-(SP)	
	006112	010600		MOV	SP,R0	
	006114	104414		TRAP	C#PNTB	
	006116	062706	000014	ADD	#14,SP	
2283	006122			PRINTB	#FMTDT,TDR(R4)	
	006122	016446	000120	MOV	TDR(R4),-(SP)	
	006126	012746	010103	MOV	#FMTDT,-(SP)	
	006132	012746	000002	MOV	#2,-(SP)	
	006136	010600		MOV	SP,R0	
	006140	104414		TRAP	C#PNTB	
	006142	062706	000006	ADD	#6,SP	
2284	006146			PRINTB	#FMT1A,#FUNC,FASCII	
	006146	013746	002456	MOV	FASCII,-(SP)	
	006152	012746	002547	MOV	#FUNC,-(SP)	
	006156	012746	006645	MOV	#FMT1A,-(SP)	
	006162	012746	000003	MOV	#3,-(SP)	
	006166	010600		MOV	SP,R0	
	006170	104414		TRAP	C#PNTB	
	006172	062706	000010	ADD	#10,SP	
2285	006176	000207		RTS	PC	
2286						
2287						
REV A						
2288	006200			LINE2:	PRINTB #FMT10,#TIME,HOUR,MINUTE,SECOND,#MRLCS,DCS(R4),#DRNM,<B,DRSEL+1(R4)>	:JSD
REV A						
	006200	005046		CLR	-(SP)	
	006202	156416	000107	BISB	DRSEL+1(R4),(SP)	
	006206	012746	004030	MOV	#DRNM,-(SP)	
	006212	016446	000104	MOV	DCS(R4),-(SP)	
	006216	012746	002525	MOV	#MRLCS,-(SP)	
	006222	012746	007277	MOV	#FMT10,-(SP)	
	006226	012746	000005	MOV	#5,-(SP)	
	006232	010600		MOV	SP,R0	
	006234	104414		TRAP	C#PNTB	
	006236	062706	000014	ADD	#14,SP	
2289	006242			PRINTB	#FMTDT,TDR(R4)	
	006242	016446	000120	MOV	TDR(R4),-(SP)	
	006246	012746	010103	MOV	#FMTDT,-(SP)	
	006252	012746	000002	MOV	#2,-(SP)	
	006256	010600		MOV	SP,R0	
	006260	104414		TRAP	C#PNTB	
	006262	062706	000006	ADD	#6,SP	
2290	006266	000207		RTS	PC	
2291						
2292	006270	004737	006014	LINE3:	JSR PC,LINE1	
2293	006274			PRINTB	#FMT2,#CRLCS,BCSADR(R4),#CRLBA,#BBA(R4),#CRLDA,BDA(R4),#CRLMP,BMP(R4)	
	006274	016446	000042	MOV	BMP(R4),-(SP)	
	006300	012746	002611	MOV	#CRLMP,-(SP)	
	006304	016446	000040	MOV	BDA(R4),-(SP)	
	006310	012746	002577	MOV	#CRLDA,-(SP)	
	006314	017446	000110	MOV	#BBA(R4),-(SP)	
	006320	012746	002565	MOV	#CRLBA,-(SP)	
	006324	016446	000046	MOV	BCSADR(R4),-(SP)	

ERROR MESSAGES

```

006330 012746 002535      MOV      @CRLCS, (SP)
006334 012746 006654      MOV      @FMT2, -(SP)
006340 012746 000011      MOV      @11, -(SP)
006344 010600      MOV      SP, R0
006346 104414      TRAP     C#PNTB
006350 062706 000024      ADD      @24, SP
2294 006354      PRINTB  @FMT3, @CRLCS, E.CS, @CRLBA, E.BA, @CRLDA, E.DA, @CRLMP, E.MP
006354 013746 002426      MOV      E.MP, -(SP)
006360 012746 002611      MOV      @CRLMP, -(SP)
006364 013746 002424      MOV      E.DA, -(SP)
006370 012746 002577      MOV      @CRLDA, -(SP)
006374 013746 002422      MOV      E.BA, -(SP)
006400 012746 002565      MOV      @CRLBA, -(SP)
006404 013746 002420      MOV      E.CS, -(SP)
006410 012746 002535      MOV      @CRLCS, -(SP)
006414 012746 006717      MOV      @FMT3, (SP)
006420 012746 000011      MOV      @11, -(SP)
006424 010600      MOV      SP, R0
006426 104414      TRAP     C#PNTB
006430 062706 000024      ADD      @24, SP
2295 006434 013737 002424 002346      MOV      E.DA, TEMPO      ;GET ADDRESS TO PRINT
2296 006442 004537 006450      JSR      R5, TELCYL      ;PRINT IT
2297 006446 000207      RTS      PC              ;EXIT
2298
2299 006450 013737 002346 002300 TELCYL: MOV      TEMPO, CYL      ;GET THE ADDRESS
2300 006456 042737 000177 002300      BIC      @177, CYL      ;SAVE ONLY CYLINDER BITS
2301 006464 000337 002300      SWAB     CYL
2302 006470 000241      CLC
2303 006472 006137 002300      ROL      CYL
2304 006476 103002      BCC      1#
2305 006500 005237 002300      INC      CYL
2306 006504 013737 002346 002304 1#: MOV      TEMPO, SEC      ;GET SECTOR #
2307 006512 042737 177700 002304      BIC      @177700, SEC    ;SAVE ONLY THE SECTOR BITS
2308 006520 005037 002302      CLR      SUR              ;INIT TO HEAD 0
2309 006524 032737 000100 002424      BIT      @100, E.DA      ;HEAD 1?
2310 006532 001405      BEQ      2#              ;NO
2311 006534 005237 002302      INC      SUR              ;YUP
2312 006540 042737 177776 002302      BIC      @177776, SUR
2313 006546      2#: PRINTB @FMT3A, @DRVER, CYL, SUR, SEC
006546 013746 002304      MOV      SEC, -(SP)
006552 013746 002302      MOV      SUR, -(SP)
006556 013746 002300      MOV      CYL, -(SP)
006562 012746 003061      MOV      @DRVER, -(SP)
006566 012746 006760      MOV      @FMT3A, -(SP)
006572 012746 000005      MOV      @5, -(SP)
006576 010600      MOV      SP, R0
006600 104414      TRAP     C#PNTB
006602 062706 000014      ADD      @14, SP
2314 006606 000205      RTS      R5

```

;FORMAT STATEMENTS

```

2321
2322 006610      045      124      045 FMT1:  .ASCIZ  /#T#Z2#A:#Z2#A:#Z2/
2323 006632      045      124      045 FMT17: .ASCIZ  /#T#06#T#01/
2324 006645      045      124      045 FMT1A: .ASCIZ  /#T#T#N/
2325 006654      045      101      102 FMT2:  .ASCII  /#ABEFORE ERR#T#06/

```

ERROR MESSAGES

```

2326 006675      045      124      045  FMT2A:  .ASCIZ  /#T#06#T#06#T#06#N/
2327 006717      045      101      101  FMT3:   .ASCIZ  /#AAT ERR  #T#06#T#06#T#06#T#06/
2328 006760      045      116      045  FMT3A:  .ASCIZ  /#N#T#A ADDR = CYL: #Z3#A. SUR: #01#A SECT: #Z2#A.#N/
2329 007044      045      116      045  FMT4:   .ASCIZ  /#N#T#06#T#06#N#T#06#T#06#N/
2330 007077      045      124      045  FMT5:   .ASCIZ  /#T#06#T#T#N/
2331 007113      045      124      045  FMT6:   .ASCIZ  /#T#06#T#06#A OR #06#N/
2332 007141      045      124      045  FMT7:   .ASCIZ  /#T#A - #T#N/
2333 007155      045      104      066  FMT8:   .ASCIZ  /#D6#T#N/
2334 007165      045      124      045  FMT9:   .ASCIZ  /#T#Z2#A:#Z2#A:#Z2#T#06#T#01#N/
2335 007223      045      104      066  FMT9A:  .ASCIZ  /#D6#A. WORDS BAD OUT OF #D6#A. WORDS READ#N/
2336              ;FMT10: .ASCIZ  /#T#Z2#A:#Z2#A:#Z2#T#06#T#01/           ;JSD REV A
2337 007277      045      124      045  FMT10:  .ASCIZ  /#T#06#T#01/           ;JSD REV A
2338 007312      045      124      045  FMT10A: .ASCIZ  /#T#06#T#06#N#T#06#T#06#A AT BUS ADDRESS /
2339 007363      045      117      066  FMT10B: .ASCIZ  /#06#N/
2340 007371      045      124      045  FMT11:  .ASCIZ  /#T#02#T#06#T#03/
2341 007411      045      124      045  FMT12:  .ASCIZ  /#T#06#N/
2342 007421      045      124      045  FMT13:  .ASCIZ  /#T#06#T#06#N/
2343 007436      045      124      045  FMT13D: .ASCIZ  /#T#Z4#A NOW IS #Z4#N/
2344 007463      045      116      045  FMT14:  .ASCIZ  /#N#T#N/
2345 007472      045      117      066  FMT14A: .ASCIZ  /#06#A /
2346 007501      045      116      000  FMT14C: .ASCIZ  /#N/
2347 007504      045      101      127  FMT14B: .ASCIZ  ?#AWORD #D3#A. S/B #06#A WAS #06#N?
2348 007546      045      101      105  FMT15:  .ASCIZ  /#AERROR(S) SET:#T#N#ARECOVERY BEING ATTEMPTED/
2349 007624      045      116      045  FRMT16: .ASCIZ  /#N#ANDT TESTING CS=#06#A DR=#01#N/
2350 007666      045      116      045  FMT18:  .ASCIZ  /#N#T/
2351 007673      045      116      045  FMTXS:  .ASCIZ  /#N#AXFER SIZE = #Z6#A. WORDS#N/
2352 007732      045      116      045  FMTS1:  .ASCIZ  /#N#S10#A*** RL01-RL02 PERFORMANCE REPORT ***#N#N/
2353 010015      045      101      052  FMTS1A: .ASCIZ  /#A*** RUNNING#N/
2354 010035      045      101      052  FMTS1B: .ASCIZ  /#A*** DROPPED #Z2#A:#Z2#N/
2355 010070      045      124      045  FMTS2:  .ASCIZ  /#T#05#05#N/
2356 010103      045      101      040  FMTDT:  .ASCIZ  /#A DRIVE TYPE = RLO#01#N/
2357 010134      045      101      124  FMTS2A: .ASCIZ  /#ATOTAL SEEKS:  #D6#Z3#N#AWORDS READ:  #D6#Z4#Z4#N/
2358 010223      045      101      127  FMTS2B: .ASCIZ  /#AWORDS WRITTEN: #D6#Z4#Z4#N/
2359 010260      045      116      045  FMTS3:  .ASCIZ  /#N#AERRORS#N#ADRV-ER:#D6#A  SEEK: #D6#A  TRACK: #D6#A  DATA: #D6#N/
2360 010367      045      101      110  FMTS3A: .ASCIZ  /#AHARD:  #D6#A  SOFT: #D6#N/
2361 010424      045      101      104  FMTS4:  .ASCIZ  /#ADCK:  #D6#A  HCRC: #D6#A  NXM:  #D6#A  HNF:  #D6#N/
2362 010517      045      101      104  FMTS5:  .ASCIZ  /#ADLT:  #D6#A  OPI:  #D6#N#N/
2363
2367
2368          .EVEN
2369
2370 010556          ENDMOD
2371
2372          .SBTTL  DEFAULT HARDWARE P-TABLE PARAMETERS
2373
2374 010556          BGNMOD  HPTCODE
2375
2376 010556          BGNHW
2377          .WORD  L10013-L#HW/2
2378 010560          .WORD  174400          ;DRIVE CSR
2379 010562          .WORD  160          ;DRIVE VECTOR
2380 010564          .WORD  240          ;DRIVE PRIORITY
2381 010566          .WORD  1          ;DRIVE TYPE
2382 010570          .WORD  0          ;DRIVE NUMBER
2383 010572          .WORD  1          ;CONTROLLER TYPE
2384

```

DEFAULT HARDWARE P TABLE PARAMETERS

```

2385 010574          ENDDHW
      010574          L10013:
2386
2387 010574          ENDMOD
2388
2389          .SBTTL  DEFAULT SOFTWARE P TABLE PARAMETERS
2390
2391 010574          BGNMOD  SPTCODE
2392
2393 010574          BGNSW   .WORD   L10014-L$SW/2
      010574 000037
2394
2395 010576 000001    LIMIT:  .WORD   1          ;RETRY LIMIT
2396 010600 000003    ERLMT:  .WORD   3          ;ERROR LIMIT
2397 010602 000003    SELMT:  .WORD   3          ;SEEK ERROR LIMIT
2398 010604 060650    DALMT:  .WORD  25000.       ;DATA XFER LIMIT (*(10*3)) (BITS)
2399 010606 023420    SKLMT:  .WORD  10000.       ;SEEK LIMIT
2400 010610 000360    TYINT:  .WORD   240.       ;TIME INTERVAL IN MINS. BETWEEN STATISTICAL
2401                                     ;/REPORTS (4 HRS. TOTAL)
2402 010612 000020    CMRD:   .WORD  16.         ;WORDS TO COMPARE ON READ
2403 010614 000003    DELMT:  .WORD   3          ;ERRORS TO REPORT ON DATA COMPARE
2404 010616 000000    XCHFLG: .WORD   0          ;CHANGE OTHER PARAMETERS
2405 010620 002400    T.MXB:  .WORD  1280.       ;MAXIMUM R/W TRANSFER BUFFER
2406 010622 000100    T.MXH:  .WORD   100        ;MAXIMUM HEAD SELECT
2407 010624 000000    T.MNH:  .WORD   0          ;MINIMUM HEAD SELECT
2408 010626 177600    T.MXC:  .WORD  177600     ;MAXIMUM CYLINDER
2409 010630 000000    T.MNC:  .WORD   0          ;MINIMUM CYLINDER
2410 010632 000000    T.MXS:  .WORD   0          ;MAXIMUM START SECTOR
2411 010634 000000    T.MNS:  .WORD   0          ;MINIMUM START SECTOR
2412 010636 000001    T.DCK:  .WORD   1          ;DATA DUMP ON DATA CHECK ERROR
2413 010640 000001    T.DRP:  .WORD   1          ;DROP ON LIMIT REACHED
2414 010642 000003    T.MNB:  .WORD   3          ;MINIMUM BUFFER TRANSFER SIZE
2415 010644 000012    SFLMT:  .WORD  10.         ;SOFT ERROR LIMIT
2416 010646 000000    T.STA:  .WORD   0          ;DROP DRIVE ON PERFORMANCE REACHED
2417 010650 000003    DRLMT:  .WORD   3          ;DRIVE ERROR LIMIT
2418 010652 000000    T.ROF:  .WORD   0          ;READ ONLY FLAG
2419 010654 000001    T.RAN:  .WORD   1          ;RANDOM SELECT OF PATTERNS
2420 010656 000004    T.PAT:  .WORD   4          ;ONLY ONE PATTERN 4 = WORST CASE
2421 010660 000001    T.SLT:  .WORD   1          ;SEEK RETRY LIMIT
2422 010662 000200    T.CLT:  .WORD  128.       ;NUMBER OF ERRORS ON DCK DUMP
2423 010664 000000    T.STIP: .WORD   0          ;RESTRICT BUFFER SIZE
2424 010666 000001    T.WCK:  .WORD   1          ;DO WRITE CHECK
2425 010670 000012    T.DCD:  .WORD  10.         ;
2426 010672 000001    T.ANS:  .WORD   1          ;
2427
2428 010674          ENDSW
      010674          L10014:
2429
2430 010674          ENDMOD
2431
2432 010674          BGNMOD  DSPCODE
2433
2434 010674          DISPATCH 1
      010674 000001    .WORD   1
      010676 014464    .WORD  T1
2435
2436 010700          ENDMOD

```

DEFAULT SOFTWARE P-TABLE PARAMETERS

```

2437
2438          .SBTTL  STATISTICAL CODE
2439
2440 010700    BGNMOD  RPTCODE
2441
2442 010700    BGNRPT
2443 010700    PRINTS  #FMTS1          ;PRINT STATISTICAL HEADER
          010700    012746  007732    MOV      #FMTS1, (SP)
          010704    012746  000001    MOV      #1, (SP)
          010710    010600    MOV      SP,R0
          010712    104416    TRAP     C1PNTS
          010714    062706  000004    ADD      #4,SP
2444
2445
2446 010720    010446          MOV      R4, -(SP)          ;SAVE PRESENT VALUE OF R4
2447 010722    012704  030362    MOV      #DRBUF,R4        ;START OF DRIVE BUFFER
2448 010726    005764  000104    18:     TST      DCS(R4)    ;IS THERE A DRIVE?
2449 010732    001402          BEQ      28                ;NO, GET NEXT ONE
2450 010734    004737  013772    JSR      PC,REPORT        ;TYPE OUT SUMMARY
2451 010740    062704  000126    28:     ADD      #RPOS*2,R4   ;NEXT DRIVE
2452 010744    020427  031642    CMP      R4,#ENDBUF       ;AT THE END?
2453 010750    001366          BNE     18                ;NO, TRY NEXT
2454 010752    012604          MOV      (SP),R4         ;RESTORE R4
2455 010754    ENDRPT
          010754    L10015:
          010754    104425    TRAP     C1RPT
2456
2457 010756    ENDMOD
2458
2459          .SBTTL  LOAD PROTECTION TABLE
2460 010756    BGNPROT
2461 010756    000000          .WORD   0                ;P-TABLE OFFSET OF CSR
2462 010760    177777          .WORD  -1                ;NOT A MASS-BUS DRIVE
2463 010762    000010          .WORD   10               ;P-TABLE OFFSET OF DRIVE
2464 010764    ENDPROT
2465
2466          .SBTTL  INITIALIZATION CODE
2467
2468 010764    BGNMOD  INITCODE          ;START OF INITIALIZE CODE
2469
2470 010764    BGNINIT
2471
2472 010764    SETVEC  #140,#170000,#340  ;ODT STARTING ADDR          ;JSD REV A
          010764    012746  000340    MOV      #340, -(SP)
          010770    012746  170000    MOV      #170000, -(SP)
          010774    012746  000140    MOV      #140, -(SP)
          011000    012746  000003    MOV      #3, -(SP)
          011004    104437    TRAP     C1SVEC
          011006    062706  000010    ADD      #10,SP
2473
2474 011012    ;
          011012    012700  000300    SETPRI  #340          ;PRI TO 7 TO INHIBIT INT'S    ;JSD REV A
          011016    104441    SETPRI  #300          ;PRI TO 6 TO INHIBIT INT'S    ;JSD REV A
          011016    104441    MOV      #300,R0
          011016    104441    TRAP     C1SPRI
2475
2476 011020    BRESET
          011020    104433    TRAP     C1RESET        ;FOR LSI-11 CPU'S
2477
          ;CLEAR OPERATION FLAGS

```





INITIALIZATION CODE

```

2505 011260 012737 000002 002314 2#: MOV #2,CLKTYP ;IDENTIFY L-CLOCK TYPE
2506 011266 005237 002502 INC SYSCLK ;INDICATE PRESENCE OF A SYSTEM CLOCK
2507 011272 000424 BR PWRCH ;BRANCH TO CHECK POWER
2508 011274 NILCLK: PRINTF #FMT14,#NOCLK ;REPORT "SYSTEM CLOCK IS NOT AVAILABLE"
      011274 012746 004530 MOV #NOCLK,(SP)
      011300 012746 007463 MOV #FMT14,-(SP)
      011304 012746 000002 MOV #2,-(SP)
      011310 010600 MOV SP,R0
      011312 104417 TRAP C:PNTF
      011314 062706 000006 ADD #6,SP
2509 011320 PRINTF #FMT14,#NOREPT ;PRINT 'PERFORMANCE REPORTS WILL NOT BE PRINTED'
      011320 012746 004566 MO# #NOREPT,-(SP)
      011324 012746 007463 MOV #FMT14,-(SP)
      011330 012746 000002 MOV #2,-(SP)
      011334 010600 MOV SP,R0
      011336 104417 TRAP C:PNTF
      011340 062706 000006 ADD #6,SP
2510 ;POWER FAIL SEQUENCE
2511 011344 PWRCH: READEF #EF.PWR ;POWER FAILURE?
      011344 012700 000034 MOV #EF.PWR,R0
      011350 104447 TRAP C:REFG
2512 011352 BNCOMPLETE 3# ;BRANCH IF NO POWER FAILURE
      011352 103121 BCC 3#
2513 011354 005237 002446 INC PWRFLG ;INDICATE POWER FAIL
2514 011360 012704 030362 MOV #DRBUF,R4 ;INITIALIZE POINTER TO DRIVE PARAMETER BUFFERS
2515 011364 012702 000001 MOV #1,R2
2516 011370 130237 002252 11#: BITB R2,DRUT
2517 011374 001471 BEQ 13#
2518 011376 016400 000106 MOV DRSEL(R4),R0
2519 011402 052700 000200 BIS #200,R0
2520 011406 010074 000104 MOV R0,#DCS(R4)
2521 011412 012701 000170 MOV #120,R1 ;INITIALIZE WAIT COUNT
2522 011416 032774 000001 000104 12#: BIT #1,#DCS(R4)
2523 011424 001037 BNF 15#
2524 011426 WAITMS #10 ;IMPLEMENT 1 SECOND TIME DELAY
      011444 012727 000372 MOV #250..(PC),
      011450 000000 .WORD 0
      011452 013727 002116 MOV LIDLY,(PC),
      011456 000000 .WORD 0
      011460 005367 177772 DEC -6(PC)
      011464 001375 BNE -.4
      011466 005367 177756 DEC -22(PC)
      011472 001367 BNE -.20
2525 011502 005301 DEC R1
2526 011504 001344 BNE 12#
2527 011506 012737 004101 002246 MOV #NOPWR,WHY ;MSG. "DR DID REC'R FROM PWR UP"
2528 011514 004537 023450 JSR R5,DRDRV
2529 011520 000137 011560 JMP 13#
2530
2531 011524 004537 024376 15#: JSR R5,ISDRST
2532 011530 004537 025620 JSR R5,HOMOME
2533 011534 005064 000056 CLR PWRFLG(R4)
2534 011540 005064 000036 CLR RETRY(R4)
2535 011544 005064 000076 CLR DOWCK(R4)
2536 011550 005064 000052 CLR RTYPE(R4)
2537 011554 005064 000114 CLR RSEEK(R4)
2538 011560 062704 000126 13#: ADD #PRPOS+2,R4

```

INITIALIZATION CODE

```

2539 011564 106302          ASLB      R2
2540 011566 103300          BCC      11#
2541 011570 005737 002502    TST      SYSCLK          ;SYSTEM CLOCK AVAILABLE?
2542 011574 001406          BEQ      4#
2543 011576          CLKON
2544 011606          REQIM      R0          ;ACTIVATE CLOCK WITH 1-SECOND INCREMENTS
2545 011612 000137 012642    4#:      JMP      INIEND          ;REQUEST ELAPSED SUPERVISOR TIME
2546          ;"CONTINUE" COMMAND SEQUENCE
2547 011616          3#:      REDEF     #EF.CONTINUE          ;CONTINUE FROM CONSOLE?
          011616 012700 000036    MOV      #EF.CONTINUE,R0
          011622 104447          TRAP     C#REFG
2548 011624          BNCOMPLETE      1#          ;NO, CONTINUE W/ INIT CODE
          011624 103004          BCC      1#
2549
2550 011626 005237 002454    INC      CNTFLG          ;YES SET CONT FLAG, GO TO END OF INIT
2551 011632 000137 012170    JMP      END
2552
2553 011636 004537 027124    1#:      JSR      R5,CLEAR          ;CLEAR ALL DRIVE BUFFERS
2554 011642 012737 176543 002260    MOV      #176543,HINUM    ;PRIME RANDOM GENERATOR
2555 011650 012737 123456 002262    MOV      #123456,LONUM    ;
2556 011656 012700 002320    2#:      MOV      #CNTLR1,R0      ;INITIALIZE POINTER TO GLOBAL DATA AREA
2557 011662 005020    CLRDAT: CLR      (R0)      ;MASS CLEAR OF GLOBAL DATA AREA
2558 011664 020027 002454    CMP      R0,#STFLG*2      ;AT END OF GLOBAL DATA AREA?
2559 011670 001374          BNE
2560
2561 011672 012704 030362    MOV      #DRBUF,R4          ;SET UP DRIVE INFORMATION BUFFER POINTER
2562 011676 012702 027314    MOV      #BSECO,R2          ;SET UP BAD SECTOR POINTER
2563 011702 013703 002012    MOV      L#UNIT,R3          ;GET NUMBER OF UNITS
2564 011706 010337 002444    MOV      R3,UJT            ;SAVE L#UNIT
2565 011712 005001          CLR      R1                ;INITIALIZE P-TABLE FOR LOGICAL UNIT
2566 011714 005703    1#:      TST      R3                ;ANY P-TABLES LEFT?
2567 011716 001524          BEQ      END                ;NO,GO TO END
2568 011720          GPHARD      R1,R0          ;REQUEST A P-TABLE FOR DRIVE
          011720 010100          MOV      R1,R0
          011722 104442          TRAP     C#GPHRD
2569 011724          BNCOMPLETE      12#
          011724 103112          BCC      12#
2570          ;MOVE P-TABLE CONTENTS TO LOCAL STORAGE
2571 011726 012037 002330    MOV      (R0)+,BCSR          ;GET CSR
2572 011732 012037 002332    MOV      (R0)+,BVEC          ;GET VECTOR
2573 011736 012037 002334    MOV      (R0)+,BPRIOR        ;GET PRIORITY
2574 011742 012037 002254    MOV      (R0)+,T.DRIVE       ;GET DRIVE TYPE
2575 011746 011037 002336    MOV      (R0),BDRSEL         ;GET DRIVE NUMBER
2576 011752 005737 002320    TST      CNTLR1             ;DO WE HAVE CSR 1 YET?
2577 011756 001011          BNE      2#                ;YES,THEN SEE IF IT THIS DRIVE IS
2578          ;/ASSOCIATED WITH CNTLR1
2579 011760 013737 002334 002376    MOV      BPRIOR,PRIOR1
2580 011766 013737 002330 002320    MOV      BCSR,CNTLR1
2581 011774 013737 002332 002372    MOV      BVEC,VECT1
2582 012002 023737 002330 002320    2#:      CMP      BCSR,CNTLR1      ;IS THIS CSR CNTLR1?
2583 012010 001012          BNE      5#                ;NO,GO CHECK AGAINST #2
2584 012012 023737 002332 002372    CMP      BVEC,VECT1        ;IS VECTOR PROPER?
2585 012020 001050          BNE      10#               ;NO, REPORT ERROR
2586 012022 012737 002436 002350    MOV      #BUF1,TEMP1        ;FIRST CONTROLLER/FIRST BUFFER
2587 012030 004537 013442    JSR      R5,FILINF          ;FILL BUFFER
2588 012034 000450          BR       11#               ;GO GET NEXT P-TABLE
2589 012036 005737 002322    5#:      TST      CNTLR2          ;HAVE WE GOT CSR #2 YET?

```

INITIALIZATION CODE

```

2590 012042 001015          BNE      68
2591 012044 023737 002372 002330  CMP      VECT1,BCSR
2592 012052 001433          BEQ      108
2593 012054 013737 002330 002322  MOV      BCSR,CNTRLR2
2594 012062 013737 002332 002374  MOV      BVEC,VECT2
2595 012070 013737 002334 002400  MOV      BPRIOR,PRIOR2
2596 012076 023737 002330 002322 68:     CMP      BCSR,CNTRLR2
2597 012104 001016          BNE      108
2598 012106 023737 002332 002374  CMP      BVEC,VECT2
2599 012114 001012          BNE      108
2600 012116 023737 002374 002372  CMP      VECT2,VECT1
2601 012124 001406          BEQ      108
2602 012126 012737 002440 002350  MOV      @BUF2,TEMP1
2603 012134 004537 013442  JSR      R5,FILINF
2604 012140 000406          BR       118
2605 012142          108:     ERDF     160.,ILLEG,ERR10
          012142          104455  TRAP    C#ERDF
          012144          000240  .WORD  160
          012146          003770  .WORD  ILLEG
          012150          005646  .WORD  ERR10
2606 012152 005064 000104  128:     CLR      DCS(R4)
2607 012156 005201 118:     INC      R1
2608 012160 005303          DEC      R3
2609 012162 062702 000042  ADD     @34.,R2
2610 012166 000652          BR       18
2611
2612          END:
2613
2614 012170 012737 177770 002256  MOV     @177770,SYSMSK
2615 012176 023727 002444 000004  CMP     UUT,#4
2616 012204 003012          BGT     28
2617 012206 052737 000004 002256  BIS     @4,SYSMSK
2618 012214 023727 002444 000002  CMP     UUT,#2
2619 012222 003003          BGT     28
2620 012224 052737 000002 002256  BIS     @2,SYSMSK
2621
2622
2623 012232          ;"START" COMMAND SEQUENCE
          012232 012700 000040 28:     READEF @EF,START
          012236 104447          MOV     @EF,START,R0
          BNCOMPLETE RESTART
          BCC  RESTART
2624 012240          INC     STFLG
          012240 103006          CLR   WRINIT
2625 012242 005237 002452          CLR   KILLDC
2626 012246 005037 002274
2627 012252 005037 002310
2628
2629 012256          RESTART:
2630 012256 005737 002454          TST   CNTFLG
2631 012262 001047          BNE   38
2632 012264 005737 002274          TST   WRINIT
2633 012270 001420          BEQ   118
2634 012272 005037 002274          CLR   WRINIT
2635 012276 005237 002310          INC   KILLDC
2636 012302 005037 010612          CLR   CMDR
2637 012306          PRINTF @FMT18,@NORDDC
          012306 012746 004416          MOV   @NORDDC,-(SP)
          012312 012746 007666          MOV   @FMT18,-(SP)

```

```

;YES, CHECK THIS ONE AGAINST IT
;IS THIS VECTOR SAME AS CNTRLR1
;IF SO, DON'T ALLOW IT
;MAKE THIS ONE CSR 2
;SETUP SECOND VECTOR

;IS THIS CSR # 2?
;NO, WELL WE DON'T ALLOW 3
;DOES IT HAVE PROPER VECTOR
;NO, GO REPORT ERROR
;IS VECTOR OF FIRST EQUAL TO
;VECTOR OF SECOND, YES REPORT ERROR
;OTHER CNTRLR/OTHER BUFFER
;LOAD BUFFER
;NEXT
;BAD P-TABLE

;POINT TO NEXT
;DOWN COUNT
;NEXT BAD SECTOR FILE
;DO WHILE

;SETUP FOR EIGHT DRIVES
;MORE THAN FOUR
;YES, THEN MASK IS OKAY
;SETUP FOR FOUR DRIVES
;MORE THAN TWO
;YES, IT'S OKAY
;SET FOR ONE OR TWO

;START COMMAND

;NO, CHK RESTART

;SET START INDICATOR
;CLEAR THE WRITE INIT FLAG ON START
;CLEAR DATA COMP FLAG ON START ONLY

;CONTINUING
;YES GO TO 38
;IN PROCESS OF INITTING THE PACK?
;NO
;YES - CLEAR THE FLAG
;INHIBIT DATA COMPARES!
;AND SET DAT COMPARE TO 0 WORDS
;TELL OPR PACK NOT INITTED YET

```

INITIALIZATION CODE

```

012316 012746 000002      MOV      #2,-(SP)
012322 010600             MOV      SP,R0
012324 104417             TRAP    C#PNTF
012326 062706 000006      ADD      #6,SP

2638
2639      ;LET'S CREATE INTERNAL BITMAP
2640
2641 012332 012701 000001  11#:     MOV      #1,R1      ;BIT MASK
2642 012336 105037 002253      CLRB    DRPRS      ;CLEAR OUT DRIVES PRESENT
2643 012342 012704 030362      MOV      #DRBUF,R4  ;START OF DRIVE BUFFERS
2644 012346 005764 000104  1#:     TST      DCS(R4)   ;ANY CSR?
2645 012352 001402             BEQ     2#          ;NO, NO DRIVE THEN
2646 012354 150137 002253      BISB    R1,DRPRS   ;INDICATE DRIVE IN BITMAP
2647 012360 006301             ASL     R1          ;NEXT POSITION
2648 012362 062704 000126      ADD     #PRPOS-2,R4 ;NEXT DRIVE BUFFER
2649 012366 022704 031642      CMP     #ENDBUF,R4 ;DONE
2650 012372 001365             BNE     1#         ;NO
2651
2652 012374 113737 002253 002252  MOVB    DRPRS,DRUT ;SET UP DRIVES UNDER TEST
2653
2654 012402      3#:
2655
2656 012402             SETVEC  VECT1,#INTR1,PRIOR1 ;SET CONTROLLER 1'S VECTOR
012402 013746 002376      MOV     PRIOR1,-(SP)
012406 012746 017046      MOV     #INTR1,-(SP)
012412 013746 002372      MOV     VECT1,-(SP)
012416 012746 000003      MOV     #3,-(SP)
012422 104437             TRAP    C#SVEC
012424 062706 000010      ADD     #10,SP

2657
2658 012430 005737 002322      TST     CNTLR2     ;RUNNING TWO CONTROLLERS?
2659 012434 001413             BEQ     4#         ;NO
2660
2661 012436             SETVEC  VECT2,#INTR2,PRIOR2 ;YES SET CONTROLLER 2'S VECTOR
012436 013746 002400      MOV     PRIOR2,-(SP)
012442 012746 017056      MOV     #INTR2,-(SP)
012446 013746 002374      MOV     VECT2,-(SP)
012452 012746 000003      MOV     #3,-(SP)
012456 104437             TRAP    C#SVEC
012460 062706 000010      ADD     #10,SP

2662
2663 012464 005737 002454  4#:     TST     CNTFLG     ;CONTINUE?
2664 012470 001412             BEQ     FINDBF    ;NO, GO PAST RESTART OF CLOCK
2665
2666 012472 005737 002502      TST     SYSCLK     ;DO WE HAVE SYSTEM CLOCK?
2667 012476 001461             BEQ     INIEND    ;NO
2668
2669 012500             CLKON                    ;ACTIVATE SYSTEM CLOCK
2670 012510             REQTIM R0              ;REQUEST ELAPSED SUPERVISOR TIME
2671 012514 000452             BR      INIEND      ;GO TO END
2672
2673      ;REQUEST MEMORY BUFFER SPACE TO PERFORM READ/WRITE OPERATIONS
2674 012516             FINDBF: MEMORY R2      ;REQUEST MEMORY BUFFER SPACE
012516 104431             TRAP   C#MEM
012520 010002             MOV    R0,R2
2675 012522 022712 002400      CMP    #1280..(R2)   ;DO WE HAVE A MINIMUM OF 1280 WORDS?
2676 012526 003413             BLE    1#           ;YES BRANCH
    
```

INITIALIZATION CODE

```

2677 012530          PRINTF  #FMT14,#INSMEM      ;NO PRINT MSG. "SYSTEM FATAL ERROR
      012530 012746 004711      MOV    #INSMEM,-(SP)
      012534 012746 007463      MOV    #FMT14,(SP)
      012540 012746 000002      MOV    #2,-(SP)
      012544 010600      MOV    SP,R0
      012546 104417      TRAP   C#PNTF
      012550 062706 000006      ADD    #6,SP

2678                                ;/INSUFFICIENT MEMORY BUFFER SPACE"
2679 012554 000000      HALT
2680 012556 010237 002436      1#:  MOV    R2,BUF1      ;GET ADDRESS OF FREE MEMORY
2681 012562 005737 002322      TST   CNTRLR2      ;TWO CONTROLLERS?
2682 012566 001410      BEQ   2#           ;NO - ASSIGN ALL BUFFER TO SINGLE CONTROLLER
2683 012570 042712 000001      BIC   #1,(R2)      ;MAKE LENGTH OF FREE MEMORY EVEN
2684 012574 013737 002436 002440  MOV    BUF1,BUF2      ;SET UP FOR BUFFER 2
2685 012602 061237 002440      ADD    (R2),BUF2    ;ADD HALF OF BUFFER
2686 012606 006212      ASR   (R2)         ;DIVIDE BUFFER SPACE BY 2
2687 012610 011237 002442      2#:  MOV    (R2),MAXWC    ;INITIALIZE MAXIMUM WORD COUNT
2688 012614 023727 002442 012000  CMP   MAXWC,#5120.  ;IS WORD COUNT LESS THAN OR EQUAL TO 5120?
2689 012622 003403      BLE   3#           ;BRANCH IF TRUE
2690 012624 012737 012000 002442  MOV    #5120.,MAXWC ;NO - INITIALIZE VALUE TO 5120 WORDS
2691
2692 012632          3#:  CLKON      ;ACTIVATE SYSTEM CLOCK TO INITIATE GENERATION
2693                                ;/OF TIMING INTERVALS
2694 012642          INIEND:
2695 012642          ENDINIT
      012642          L10017:
      012642 104411      TRAP   C#INIT
2696 012644          ENDMOD
2697
2698          .SBTTL AUTO DROP SECTION
2699
2700          ;THE AUTO DROP SECTION IS CONDITIONALLY EXECUTED AFTER THE INITIALIZATION CODE
2701          ;WHEN THE OPERATOR "ADR" FLAG IS SET. EACH DRIVE IS CHECKED TO DETERMINE IF IT
2702          ;IS READY TO TRANSFER DATA. IF THE DRIVE DOES NOT RESPOND WITH "READY" IT IS
2703          ;DROPPED FROM THE TEST CYCLE. THE HARDWARE TESTS ARE PERFORMED IMMEDIATELY
2704          ;AFTER THE READY STATUS OF ALL DRIVES HAVE BEEN CHECKED.
2705
2706 012644          BGNAUTO
2707 012644 010346      MOV    R3,-(SP)      ;SAVE REGISTERS
2708 012646 010446      MOV    R4,-(SP)
2709 012650 013703 002012      MOV    L#UNIT,R3    ;INITIALIZE NUMBER OF DRIVES UNDER TEST
2710 012654 012704 030362      MOV    #DRBUF,R4    ;INITIALIZE START OF DRIVE BUFFERS
2711 012660 005037 002450      1#:  CLR   TRPFLG      ;CLEAR TRAP FLAG
2712 012664          SETVEC  ERRVEC,#TRPHAN,#340      ;SET UP TIME-OUT VECTOR TO DETECT
      012664 012746 000340      MOV    #340,-(SP)
      012670 012746 013764      MOV    #TRPHAN,-(SP)
      012674 013746 002466      MOV    ERRVEC,-(SP)
      012700 012746 000003      MOV    #3,-(SP)
      012704 104437      TRAP   C#SVEC
      012706 062706 000010      ADD    #10,SP

2713                                ;/NON-EXISTENT CONTROLLER
2714 012712 005774 000104      TST   #DCS(R4)      ;ACCESS CONTROLLER
2715 012716 005737 002450      TST   TRPFLG        ;DID TRAP OCCUR?
2716 012722 001425      BEQ   2#           ;BRANCH TO CHECK DRIVE IF TRAP DID NOT OCCUR
2717 012724          PRINTF  #FMT16,DCS(R4),<B,DRSEL+1(R4)> ;PRINT CONTROL STATUS AND DRIVE
      012724 005046      CLR   -(SP)
      012726 156416 000107      BISB  DRSEL+1(R4),(SP)

```

AUTO DROP SECTION

```

012732 016446 000104      MOV      DCS(R4),-(SP)
012736 012746 007624      MOV      #FRMT16,(SP)
012742 012746 000003      MOV      #3,(SP)
012746 010600      MOV      SP,R0
012750 104417      TRAP     C#PNTF
012752 062706 000010      ADD      #10,SP

2718
2719 012756 012737 004673 002246      MOV      #NOCTLR,WHY      ;/NUMBER INFORMATION
                                ;PROVIDE REASON FOR DROPPING DRIVE
2720                                ;/"NO CONTROLLER"
2721 012764 004537 023450      JSR      R5,DRDRV      ;DO DROP UNIT ON DRIVE FROM TEST CYCLE
2722 012770 005064 000104      CLR      DCS(R4)      ;TAKE DRIVE OUT OF BUFFER
2723 012774 000436      BR       3$           ;BRANCH TO GET NEXT DRIVE
2724 012776 056474 000106 000104 2$:      BIS      DRSEL(R4),@DCS(R4) ;GET SELECTED DRIVE NUMBER
2725 013004 052774 000200 000104      BIS      @200,@DCS(R4) ;SET CONTROLLER READY
2726 013012 032774 000001 000104      BIT      @1,@DCS(R4) ;IS DRIVE READY?
2727 013020 001024      BNE     3$           ;BRANCH TO CHECK NEXT DRIVE IF READY
2728 013022      PRINTF  #FRMT16,DCS(R4),<B,DRSEL+1(R4)> ;PRINT CONTROL STATUS AND DRIVE
                                ;/NUMBER INFORMATION
                                ;PROVIDE REASON FOR DROPPING DRIVE
                                ;/"DID NOT RESPOND WITH "READY"
013022 005046      CLR      -(SP)
013024 156416 000107      BISB    DRSEL+1(R4),(SP)
013030 016446 000104      MOV      DCS(R4),-(SP)
013034 012746 007624      MOV      #FRMT16, -(SP)
013040 012746 000003      MOV      #3, -(SP)
013044 010600      MOV      SP,R0
013046 104417      TRAP     C#PNTF
013050 062706 000010      ADD      #10,SP

2729
2730 013054 012737 004636 002246      MOV      #NOTRDY,WHY
                                ;PROVIDE REASON FOR DROPPING DRIVE
2731                                ;/"DID NOT RESPOND WITH "READY"
2732 013062 004537 023450      JSR      R5,DRDRV      ;DO DROP UNIT ON DRIVE FROM TEST CYCLE
2733 013066 005064 000104      CLR      DCS(R4)      ;TAKE DRIVE OUT OF BUFFER
2734 013072      CLAVEC  ERRVEC      ;RELEASE THE ERROR VECTOR
                                3$:
013072 013700 002466      MOV      ERRVEC,R0
013076 104436      TRAP     C#CVEC
2735 013100 062704 000126      ADD      #PRPOS+2,R4 ;UPDATE POINTER TO ACCESS DRIVE BUFFER
2736                                ;/FOR NEXT DRIVE
2737 013104 005303      DEC      R3           ;DECREMENT DRIVE COUNT
2738 013106 001264      BNE     1$           ;BRANCH TO GET NEXT DRIVE IF MORE
2739 013110 012604      MOV      (SP)+,R4 ;RESTORE REGISTERS
2740 013112 012603      MOV      (SP)+,R3
2741 013114      ENDAUTO
                                L10020:
013114 104461      TRAP     C#AUTO

2742
2743 013116      BGNMOD  CLNCODE
2744
2745 013116      BGNCLN
2746
2747 013116      SETVEC  ERRVEC,@TRPHAN,#340
                                MOV      #340, -(SP)
                                MOV      #TRPHAN, -(SP)
                                MOV      ERRVEC, -(SP)
                                MOV      #3, -(SP)
                                TRAP     C#SVEC
                                ADD      #10,SP
2748 013144      SETPRI  #PRIO0 ;PRIORITY TO ZERO
                                MOV      #PRIO0,R0
                                TRAP     C#SPRI
013144 012700 000000
013150 104441

```

## AUTO DROP SECTION

```

2749
2750 013152 032777 000200 167140 1$: BIT #CRDY, @CNTLR1 ;WAIT FOR CONTROLLER TO FINISH
2751 013160 001774 BEQ 1$ ;
2752 013162 042777 000100 167130 BIC #INTEN, @CNTLR1 ;CLEAR INTERRUPT IF PENDING
2753 013170 CLRVEC VECT1 ;RELEASE VECTOR OF FIRST CONTROLLER
      013170 013700 002372 MOV VECT1, R0
      013174 104436 TRAP C#CVEC

2754
2755 013176 005737 002322 TST CNTLR2 ;TWO CONTROLLERS
2756 013202 001412 BEQ 3$ ;NO
2757
2758 013204 032777 000200 167110 2$: BIT #CRDY, @CNTLR2 ;WAIT FOR OTHER CONTROLLER TO FINISH
2759 013212 001774 BEQ 2$ ;
2760 013214 042777 000100 167100 BIC #INTEN, @CNTLR2 ;CLEAR OUT INTERRUPT ENABLE
2761 013222 CLRVEC VECT2 ;YES, WE'LL RELEASE ITS VECTOR
      013222 013700 002374 MOV VECT2, R0
      013226 104436 TRAP C#CVEC

2762
2763 013230 005037 002476 3$: CLR INCALL
2764 013234 005037 002474 CLR OPCALL
2765 013240 CLRVEC ERRVEC
      013240 013700 002466 MOV ERRVEC, R0
      013244 104436 TRAP C#CVEC
2766 013246 005737 002502 TST SYSCLK
2767 013252 001412 BEQ 4$
2768 013254 CLKOFF ;DEACTIVATE SYSTEM CLOCK
2769 013310 4$: BRESET ;TAKE CARE OF LSI 11
      013310 104433 TRAP C#RESET
2770 013312 ENDCLN
      013312 L10021: TRAP C#CLEAN
      013312 104412

2771
2772 013314 ENDMOD
2773
2774 013314 BGNMOD ADDCODE
2775
2776 013314 BGNAU
2777
2778 013314 012704 030362 MOV #DRBUF, R4 ;START OF DRIVE BUFFERS
2779 013320 012701 000001 MOV #1, R1 ;MASK TO FIND DRIVE
2780 013324 010002 MOV R0, R2 ;SAVE WHICH TO FIND
2781 013326 005700 1$: TST R0 ;THIS ONE
2782 013330 001405 BEQ 2$ ;YES
2783 013332 062704 000126 ADD #PRPOS+2, R4 ;NEXT
2784 013336 006301 ASL R1 ;NEXT MASK
2785 013340 005300 DEC R0
2786 013342 000771 BR 1$
2787 013344 150137 002252 2$: BISB R1, DRUT ;INSERT IN DRIVE UNDER TEST
2788 013350 GPHARD R2, R1
      013350 010200 MOV R2, R0
      013352 104442 TRAP C#GPHARD
      013354 010001 MOV R0, R1
2789 013356 011164 000104 MOV (R1), DCS(R4) ;SETUP TO CLEAR STATUS
2790 013362 012700 000100 MOV #SERNM1, R0
2791 013366 006200 ASR R0
2792 013370 005024 4$: CLR (R4)+
2793 013372 005300 DEC R0

```

AUTO DROP SECTION

```

2794 013374 001375          BNE      4#
2795 013376          5#:
2796
2797 013376          ENDAU
      013376          L10022:
      013376 104452      TRAP      C#AU
2798
2799 013400          ENDMOD
2800
2801 013400          BGNMOD  DROPCODE
2802
2803 013400          BGNDU
2804
2805 013400 005737 002476      TST      INCALL
2806 013404 001015          BNE      3#
2807 013406 012704 030362      MOV      @DRBUF,R4
2808 013412 005700          2#:      TST      R0
2809 013414 001404          BEQ      1#
2810 013416 005300          DEC      R0
2811 013420 062704 000126      ADD      @PRPOS+2,R4
2812 013424 000772          BR       2#
2813
2814 013426 012737 003510 002246 1#:      MOV      @REQ,WHY
2815 013434 004537 023444      JSR      R5,ODRDRV
2816 013440          3#:
2817
2818 013440          ENDDU
      013440          L10023:
      013440 104453      TRAP      C#DU
2819
2820 013442          ENDMOD
2821
2822          .SBTTL  GLOBAL SUBROUTINES
2823
2824 013442          BGNMOD  GLBSUB
2825
2826          ;ROUTINE TO FILL DRIVE PARAMETER BUFFERS WITH INFORMATION
2827
2828 013442 013764 002336 000106  FILINF: MOV      BORSEL,DRSEL(R4)          ;SET DRIVE SELECT BITS
2829 013450 022737 000001 002254      CMP      #1,T.DRIVE          ;DRIVE = RL01?
2830 013456 001403          BEQ      FILTD              ;YES
2831 013460 012737 000002 002254      MOV      #2,T.DRIVE          ;DRIVE IS AN RL02
2832 013466 013764 002254 000120  FILTD: MOV      T.DRIVE,TDR(R4)
2833 013474 013764 002330 000104      MOV      BCSR,DCS(R4)          ;SET CSR
2834 013502 013764 002350 000110      MOV      TEMP1,BBA(R4)        ;SET R/W BUFFER
2835 013510 010264 000112          MOV      R2,BSECPT(R4)        ;SETUP BAD SECTOR POINTER
2836 013514 062704 000126          ADD      @PRPOS+2,R4          ;UPDATE POINTER
2837 013520 000205          RTS      R5
2838
2839          ;SETS UP CLOCK INTERRUPT VECTOR, CLOCK COUNT, AND IDENTIFIES CLOCK FREQUENCY
2840
2841 013522 010346          CLKINI: MOV      R3,-(SP)          ;SAVE R3
2842 013524 022737 000001 002314      CMP      #1,CLKTYP          ;P-CLOCK?
2843 013532 001014          BNE      LCLK              ;BRANCH IF NOT P-CLOCK
2844 013534          SETVEC  #104,@UPDATE,#340  ;SET P-CLOCK INTERRUPT VECTOR
      013534 012746 000340          MOV      #340,-(SP)
      013540 012746 016636          MOV      @UPDATE,-(SP)

```



GLOBAL SUBROUTINES

```

013544 012746 000104      MOV      #104,-(SP)
013550 012746 000003      MOV      #3,-(SP)
013554 104437              TRAP     C#SVEC
013556 062706 000010      ADD      #10,SP
2845 013562 000417      BR       FRQCHK          ;BRANCH FOR SYSTEM FREQUENCY CHECK
2846 013564 022737 000002 002314 LCLK:  CMP      #2,CLKTYP      ;L-CLOCK?
2847 013572 001036      BNE     ENDINI          ;BRANCH IF NO CLOCK
2848 013574              SETVEC   #100,#UPDATE,#340 ;SET L-CLOCK INTERRUPT VECTOR
013574 012746 000340      MOV      #340,-(SP)
013600 012746 016636      MOV      #UPDATE,-(SP)
013604 012746 000100      MOV      #100,-(SP)
013610 012746 000003      MOV      #3,-(SP)
013614 104437              TRAP     C#SVEC
013616 062706 000010      ADD      #10,SP
2849 013622 013703 002316      FRQCHK: MOV      CLKADR,R3      ;GET BASE ADDRESS OF THE SUPERVISOR CLOCK TABLE
2850 013626 022763 000074 000006      CMP      #60,6(R3)      ;60 HZ?
2851 013634 001007      BNE     FRQ50          ;BRANCH FOR 50 HZ
2852 013636 012737 000074 002506      MOV      #60.,CLKCNT    ;INITIALIZE CLOCK COUNT FOR 60 TICKS
2853                          ;/PER SECOND
2854 013644 012737 000001 002312      MOV      #1,CLKFRQ      ;IDENTIFY CLOCK FREQUENCY IS 60 HZ
2855 013652 000406      BR       ENDINI          ;RETURN
2856 013654 012737 000062 002506      FRQ50:  MOV      #50.,CLKCNT    ;INITIALIZE CLOCK COUNT FOR 50 TICKS
2857                          ;/PER SECOND
2858 013662 012737 000002 002312      MOV      #2,CLKFRQ      ;IDENTIFY CLOCK FREQUENCY IS 50 HZ
2859 013670 012603      ENDINI: MOV      (SP)+,R3    ;RESTORE R3
2860 013672 000207      RTS      PC
2861
2862                          ;DETERMINES CLOCK TYPE AND INITIALIZES THE CLOCK FOR OPERATION IN REPEAT
2863                          ;INTERRUPT MODE AT LINE FREQUENCY
2864
2865 013674 005037 002512      CLKST:  CLR      CLKACC      ;CLEAR CLOCK ELAPSED TIME INDICATOR
2866 013700 022737 000002 002314      CMP      #2,CLKTYP      ;L-CLOCK?
2867 013706 001006      BNE     1#            ;BRANCH FOR P-CLOCK
2868 013710 012737 000100 177546      MOV      #100,#0177546  ;SET INTERRUPT ENABLE BIT TO 1
2869 013716 005237 002504      INC      CLKSON          ;INDICATE "CLOCK ON"
2870 013722 000414      BR       2#            ;BRANCH TO SET UP TIME INCREMENTS
2871 013724 022737 000001 002314 1#:  CMP      #1,CLKTYP      ;P-CLOCK?
2872 013732 001013      BNE     3#            ;BRANCH IF NO CLOCK
2873 013734 012737 000001 172542      MOV      #1,#0172542    ;SET UP P-CLOCK FOR 1 INTERRUPT PER TICK
2874 013742 012737 000115 172540      MOV      #115,#0172540  ;SET INTERRUPT ENABLE,REPEAT INTERRUPT MODE,
2875                          ;/LINE FREQUENCY RATE,START CLOCK
2876 013750 005237 002504      INC      CLKSON          ;INDICATE "CLOCK ON"
2877 013754 013737 002506 002510 2#:  MOV      CLKCNT,CLKBFR   ;SET UP TIME INCREMENTS
2878 013762 000207      3#:  RTS      PC            ;RETURN
2879
2880 013764 005237 002450      TRPHAN: INC      TRPFLG
2881 013770 000002      RTI
2882
2883                          .SBTTL  REPORT ROUTINE
2884                          ;ROUTINE TO PRINT STATISTICAL REPORT OF DRIVE(S)
2885
2886                          ;REPORT:PRINTS #FMT10,#TIME,HOUR,MINUTE,SECOND,#MRLCS,DCS(R4),#DRNM,<B,DRSEL+1(R4)> ;JSD
REV A 2887 013772      REPORT: PRINTS #FMT10,#MRLCS,DCS(R4),#DRNM,<B,DRSEL+1(R4)> ;JSD
REV A
013772 005046      CLR      -(SP)
013774 156416 000107      BISB    DRSEL+1(R4),(SP)
014000 012746 004030      MOV      #DRNM,-(SP)
014004 016446 000104      MOV      DCS(R4),-(SP)

```

REPORT ROUTINE

```

014010 012746 002525      MOV      #MRLCS, (SP)
014014 012746 007277      MOV      #FMT10, -(SP)
014020 012746 000005      MOV      #5, (SF)
014024 010600              MOV      SP,RO
014026 104416              TRAP    C#PNTS
014030 062706 000014      ADD      #14, SP
2888 014034              PRINTS #FMTDT, TDR(R4)
014034 016446 000120      MOV      TDR(R4), -(SP)
014040 012746 010103      MOV      #FMTDT, -(SP)
014044 012746 000002      MOV      #2, -(SP)
014050 010600              MOV      SP,RO
014052 104416              TRAP    C#PNTS
014054 062706 000006      ADD      #6, SP
2889 014060 000432      BR       2#
2890
2891 014062 005764 000070      TST     DPHOUR(R4)
2892 014066 001417      BEQ     1#
2893
2894
2895
2896 014070              PRINTS #FMTS1B, <B,DPHOUR(R4)>, <B,DPMIN(R4)>
014070 005046              CLR     -(SP)
014072 156416 000071      BISB   DPMIN(R4), (SP)
014076 005046              CLR     -(SP)
014100 156416 000070      BISB   DPHOUR(R4), (SP)
014104 012746 010035      MOV     #FMTS1B, -(SP)
014110 012746 000003      MOV     #3, -(SP)
014114 010600              MOV     SP,RO
014116 104416              TRAP    C#PNTS
014120 062706 000010      ADD     #10, SP
2897 014124 000410      BR       2#
2898
2899 014126              1#:    PRINTS #FMTS1A
014126 012746 010015      MOV     #FMTS1A, -(SP)
014132 012746 000001      MOV     #1, -(SP)
014136 010600              MOV     SP,RO
014140 104416              TRAP    C#PNTS
014142 062706 000004      ADD     #4, SP
2900
2901 014146              2#:    PRINTS #FMTS2, #CART, SERNM2(R4), SERNM1(R4)
014146 016446 000100      MOV     SERNM1(R4), -(SP)
014152 016446 000102      MOV     SERNM2(R4), -(SP)
014156 012746 002634      MOV     #CART, -(SP)
014162 012746 010070      MOV     #FMTS2, -(SP)
014166 012746 000004      MOV     #4, -(SP)
014172 010600              MOV     SP,RO
014174 104416              TRAP    C#PNTS
014176 062706 000012      ADD     #12, SP
2902 014202              PRINTS #FMTS2A, SKCNT(R4), SKCNT1(R4), RXFR3(R4), RXFR2(R4), RXFR1(R4)
014202 016446 000002      MOV     RXFR1(R4), -(SP)
014206 016446 000004      MOV     RXFR2(R4), -(SP)
014212 016446 000060      MOV     RXFR3(R4), -(SP)
014216 016446 000054      MOV     SKCNT1(R4), -(SP)
014222 016446 000000      MOV     SKCNT(R4), -(SP)
014226 012746 010134      MOV     #FMTS2A, -(SP)
014232 012746 000006      MOV     #6, -(SP)
014236 010600              MOV     SP,RO

```

```

;SKIP THIS BECAUSE DPHOUR(R4) WILL ALWAYS
;...BE ZERO, EVEN FOR DROPPED UNIT
;DO WE HAVE ANY DROPPED TIME
;NO, THEN PRINT 'RUNNING'

```

```

;JSD REV A
;JSD REV A

```

```

;PRINT THE TIME THE DRIVE WAS DROPPED FROM TESTING

```

REPORT ROUTINE

	014240	104416		TRAP	C#PNTS
	014242	062706	000016	ADD	#16,SP
2903	014246			PRINTS	#FMTS2B,WXFR3(R4),WXFR2(R4),WXFR1(R4)
	014246	016446	000006	MOV	WXFR1(R4),-(SP)
	014252	016446	000010	MOV	WXFR2(R4),(SP)
	014256	016446	000062	MOV	WXFR3(R4),-(SP)
	014262	012746	010223	MOV	#FMTS2B, -(SP)
	014266	012746	000004	MOV	#4, (SP)
	014272	010600		MOV	SP,R0
	014274	104416		TRAP	C#PNTS
	014276	062706	000012	ADD	#12,SP
2904	014302			PRINTS	#FMTS3,DERCNT(R4),SKECNT(R4),TRERR(R4),DATCER(R4)
	014302	016446	000074	MOV	DATCER(R4),-(SP)
	014306	016446	000072	MOV	TRERR(R4),-(SP)
	014312	016446	000016	MOV	SKECNT(R4),-(SP)
	014316	016446	000020	MOV	DERCNT(R4),-(SP)
	014322	012746	010260	MOV	#FMTS3, -(SP)
	014326	012746	000005	MOV	#5, -(SP)
	014332	010600		MOV	SP,R0
	014334	104416		TRAP	C#PNTS
	014336	062706	000014	ADD	#14,SP
2905	014342			PRINTS	#FMTS3A,ERRCNT(R4),SFTCNT(R4)
	014342	016446	000014	MOV	SFTCNT(R4),-(SP)
	014346	016446	000012	MOV	ERRCNT(R4),-(SP)
	014352	012746	010367	MOV	#FMTS3A, -(SP)
	014356	012746	000003	MOV	#3, -(SP)
	014362	010600		MOV	SP,R0
	014364	104416		TRAP	C#PNTS
	014366	062706	000010	ADD	#10,SP
2906	014372			PRINTS	#FMTS4,DRCRCER(R4),HRCRCER(R4),NXMCNT(R4),HNFERR(R4)
	014372	016446	000032	MOV	HNFERR(R4),-(SP)
	014376	016446	000034	MOV	NXMCNT(R4),-(SP)
	014402	016446	000024	MOV	HRCRCER(R4),-(SP)
	014406	016446	000022	MOV	DRCRCER(R4),-(SP)
	014412	012746	010424	MOV	#FMTS4, -(SP)
	014416	012746	000005	MOV	#5, -(SP)
	014422	010600		MOV	SP,R0
	014424	104416		TRAP	C#PNTS
	014426	062706	000014	ADD	#14,SP
2907	014432			PRINTS	#FMTS5,DLTCNT(R4),OPICNT(R4)
	014432	016446	000030	MOV	OPICNT(R4),-(SP)
	014436	016446	000026	MOV	DLTCNT(R4),-(SP)
	014442	012746	010517	MOV	#FMTS5, -(SP)
	014446	012746	000003	MOV	#3, (SP)
	014452	010600		MOV	SP,R0
	014454	104416		TRAP	C#PNTS
	014456	062706	000010	ADD	#10,SP
2908	014462	000207		RTS	PC

2909  
2910 014464  
2911  
2912  
2913 014464  
2914 014464

```

ENDMOD
.SBTTL PROGRAM MAIN LOOP
BGNTST
STARS
;*****
;PROGRAM WILL RANDOMLY PICK ONE OF THE DRIVES TO
;PERFORM AN OPERATION. WE WILL ALWAYS PICK ONE OF FOUR

```

2915  
2916

PROGRAM MAIN LOOP

```

2917 ;OR EIGHT DRIVES (ONE OR TWO CONTROLLERS) "DRUT" WILL BE
2918 ;CHECKED TO SEE IF DRIVE IS ON SYSTEM. ONCE DRIVE IS PICKED
2919 ;THEN A FUNCTION WILL BE SELECTED RANDOMLY FOR THAT
2920 ;DRIVE. FUNCTIONS OF CONTROLLER RESET, GET STATUS, SEEK, READ, WRITE
2921 ;WILL BE SELECTED. EACH FUNCTION WILL HAVE ITS OWN ROUTINE
2922 ;TO GET PARAMETERS FOR THE DRIVE.
2923 014464 STARS
;*****
2924
2925 014464 MTEST: SETPRI #240 ;PRIORITY TO 5 TO ALLOW CLOCK INTERRUPTS
014464 MOV #240,R0
014470 TRAP C:SPRI
;*****
2926 ;/AND TO INHIBIT DRIVE INTERRUPTS
2927
2928 014472 005737 002274 TST WRINIT ;HERE AFTER PWR FAIL DURING WRITE
2929 014476 001407 BEQ 1611 ;NO
2930 014500 013704 002274 MOV WRINIT,R4 ;YES - RESET R4
2931 014504 013701 002276 MOV WRPOS,R1 ;AND R1 POINTERS
2932 014510 005237 002452 INC STFLG ;FAKE OUT THE START FLAG
2933 014514 000410 BR 1611 ;AND CONTINUE WRITE INIT CODE
2934 014516 012704 030362 1611: MOV #DRBUF,R4 ;GET DRIVE BUFFERS
2935 014522 012701 000001 MOV #1,R1 ;MASK
2936 014526 010437 002274 MOV R4,WRINIT ;COPY THE R4 AND
2937 014532 010137 002276 MOV R1,WRPOS ;POINTERS
2938
2939 014536 130137 002252 161: BITB R1,DRUT ;DRIVE UNDER TEST
2940 014542 001442 BEQ 151 ;NO
2941
2942 014544 012774 000200 000104 MOV #200,BDCS(R4) ;CHECK IF DRIVE THERE
2943 014552 056474 000106 000104 BIS DRSEL(R4),BDCS(R4)
2944 014560 012700 000000 MOV #0,R0 ;STALL
2945 014564 005300 131: DEC R0
2946 014566 001376 BNE 131
2947 014570 032774 000001 000104 BIT #DRDY,BDCS(R4) ;WAIT FOR DRIVE TO BECOME 'READY'
2948 014576 001006 BNE 141 ;AFTER THE HEADS HOME COMMAND
2949
2950 014600 012737 002664 002246 MOV #DRDY,WHY ;MSG. "DRIVE NOT READY"
2951 014606 004537 023450 JSR R5,DRDRV
2952 014612 000416 BR 151
2953
2954 014614 004537 022604 141: JSR R5,RDBDSC ;GO GET BAD SECTORS
2955 014620 005064 000056 CLR PRFLGS(R4)
2956 014624 005064 000114 CLR RSEEK(R4)
2957 014630 005764 000122 TST WRIPG(R4) ;SEE IF WRITE IN PROGRESS FLAG SET
2958 014634 001003 BNE 991 ;JUMP IF SET
2959 014636 005737 002452 TST STFLG
2960 014642 001402 BEQ 151
2961
2962 014644 004537 024552 991: JSR R5,WRPACK
2963
2964 014650 062704 000126 151: ADD #PRPOS+2,R4 ;NEXT DRIVE
2965 014654 010437 002274 MOV R4,WRINIT ;SAVE CURRENT R4 POINTER
2966 014660 006337 002276 ASL WRPOS ;AND SHIFT COPY OF R1 POINTER
2967 014664 106301 ASLB R1 ;DONE?
2968 014666 103323 BCC 161 ;NO GO FOR NEXT ONE
2969
2970 ;HERE WHEN ALL FINISHED WITH THE WRITE INIT CODE

```

PROGRAM MAIN LOOP

```

2971
2972 014670 005037 002274
2973 014674 012746 004360
      014700 012746 007463
      014704 012746 000002
      014710 010600
      014712 104417
      014714 062706 000006
2974 014720
      014720 012700 000000
      014724 104441
2975
2976
2977 014726 004537 024454
2978 014732 013702 002262
2979 014736 043702 002256
2980 014742 012701 000001
2981 014746 005702
2982 014750 001403
2983 014752 006301
2984 014754 005302
2985 014756 000773
2986 014760 105737 002252
2987 014764 001006
2988
2989 014766
      014766 104454
      014770 000252
      014772 004016
      014774 000000
2990
2991 014776 000137 030354
2992
2993 015002 130137 002252
2994 015006 001747
2995 015010 010137 002250
2996
2997
2998
2999
3000 015014 023737 002406 010610
3001 015022 002403
3002 015024 005037 002406
3003
3004
3005 015030
      015030 104424
3006
3007 015032 012704 030362
3008 015036 013702 002262
3009 015042 043702 002256
3010 015046 005702
3011 015050 001404
3012 015052 062704 000126
3013 015056 005302
3014 015060 000772

      CLR          WRINIT          ;CLEAR THE WRITE INIT FLAG
128: PRINTF      #FMT14,#MSTART    ;MSG. "TESTING STARTED"
      MOV          #MSTART,-(SP)
      MOV          #FMT14,(SP)
      MOV          #2,(SP)
      MOV          SP,R0
      TRAP        C:PNTF
      ADD          #6,SP
      SETPRI      #0                ;PRIORITY TO 0 TO ALLOW BOTH
      MOV          #0,R0
      TRAP        C:SPRI
                                   ;/CLOCK AND DRIVE INTERRUPTS
MAIN: JSR          R5,RAND          ;GET A DRIVE?(LUN)
      MOV          LONUM,R2        ;GET THE SELECTED DRIVE (LUN)
PEROTH: BIC        SYMSK,R2       ;MASK TO DRIVES ON SYSTEM
      MOV          #1,R1          ;LET'S SEE IF DRIVE IS THERE
18:   TST         R2              ;HAVE WE GOT PROPER MASK YET
      BEQ         #1             ;YES, GO TO 28
      ASL         R1              ;NO, SHIFT FOR NEXT DRIVE
      DEC         R2              ;DECREMENT DRIVE NUMBER
      BR          #1             ;GO CHECK NEW DRIVE NUMBER
28:   TSTB        DRUT            ;ANY DRIVES ON LINE
      BNE         #0             ;YES, CHECK
                                   ;NO DRIVES
      ERRSF       170,NODRV
      TRAP        C:ERSF
      .WORD       170
      .WORD       NODRV
      .WORD       0
      JMP         ENDOFPROGRAM
58:   BITB        R1,DRUT         ;IS THIS DRIVE PRESENT?
      BEQ         MAIN           ;NO, GO BACK TRY AGAIN
      MOV         R1,TSTDRV       ;COPY UNIT UNDER TEST FOR LATER CHECK
                                   ;WE NOW HAVE A DRIVE, CHECK TO SEE IF ITS CONTROLLER
                                   ;IS FREE BEFORE WE GO ANY FURTHER
      CMP         INTERVAL,TYINT  ;TIME FOR STATISTICAL REPORT?
      BLT         #6             ;NO, PERFORM FUNCTION
      CLR         INTERVAL       ;CLEAR INTERVAL TO INITIALIZE TIME INTERVAL
                                   ;BEFORE THE NEXT STATISTICAL REPORT
      DORPT
      TRAP        C:DRPT         ;PRINT STATISTICAL REPORT
68:   MOV         #DRBUF,R4       ;GET START OF DRIVE BUFFERS
      MOV         LONUM,R2        ;GET RANDOM DRIVE BACK (LUN)
      BIC        SYMSK,R2       ;MASK TO SYSTEM SYS
38:   TST         R2              ;DO WE HAVE BUFFER FOR THAT DRIVE
      BEQ         #1             ;YES, GO CHECK ITS CONTROLLER
      ADD         #PRPOS+2,R4     ;NO, UPDATE FOR NEXT BUFFER
      DEC         R2              ;DOWN COUNT DRIVE NUMBER (LUN)
      BR          #1             ;GO BACK AND CHECK FOR FOUND

```

PROGRAM MAIN LOOP

```

3015 015062 032774 000200 000104 4: BIT #BIT7,BDCS(R4) ;CONTROLLER ASSOCIATED WITH DRIVE
3016 015070 001716 BEQ MAIN ;BUSY
3017 015072 032774 000100 000104 BIT #BIT6,BDCS(R4) ;INTERRUPT BEEN SERVICED?
3018 015100 001312 BNE MAIN ;NO WAIT FOR THE INTERRUPT
3019
3020 ;WE CAN NOW PROCEED IN GETTING A FUNCTION AND RELATED DATA
3021 ;FOR THE DRIVE RANDOMLY. R4 HAS DRIVE BUFFER POINTER
3022
3023 015102 TAGX:
3024 015102 005737 010640 TST T.DRP ;DROP ON ERROR LIMITS REACHED?
3025 015106 001456 BEQ GETFNC ;NO
3026 015110 026437 000012 010600 CMP ERRCNT(R4),ERLMT ;HARD REACHED?
3027 015116 103404 BLO 9:
3028 015120 012737 003322 002246 MOV #ERLMTM,WHY
3029 015126 000442 BR 11:
3030 015130 026437 000014 010644 9: CMP SFTCNT(R4),SFLMT ;SOFT REACHED?
3031 015136 103404 BLO 10:
3032 015140 012737 003365 002246 MOV #SFEMSG,WHY
3033 015146 000432 BR 11:
3034 015150 026437 000074 010670 10: CMP DATCER(R4),T.DCD
3035 015156 103404 BLO 110:
3036 015160 012737 003407 002246 MOV #DCDMSG,WHY
3037 015166 000422 BR 11:
3038 015170 016401 000016 110: MOV SKECNT(R4),R1
3039 015174 066401 000072 ADD TRERR(R4),R1
3040 015200 020137 010602 CMP R1,SELMT
3041 015204 103404 BLO 7:
3042 015206 012737 003344 002246 MOV #SERLMT,WHY
3043 015214 000407 BR 11:
3044 015216 026437 000020 010650 7: CMP DERCNT(R4),DRLMT ;DRIVE ERROR REACHED?
3045 015224 103407 BLO GETFNC ;NO - TIME TO DO SOMETHING
3046 015226 012737 003432 002246 MOV #DERMSG,WHY
3047
3048 015234 004537 023450 11: JSR R5,DRDRV ;DROP THIS DRIVE!!!
3049 015240 000137 014726 JMP MAIN ;GO GET ANOTHER
3050
3051 ;HERE TO GET A 'STRING' FUNCTION - LIST OF COMMANDS TO ISSUE
3052
3053 015244 GETFNC:
3054 015244 005737 010646 8: TST T.STA ;DO WE WISH TO DROP ON OPR LIMITS
3055 015250 001422 BEQ 98: ;NO
3056
3057 015252 026437 000000 010606 CMP SKCNT(R4),SKLMT ;PAST THE SEEK LIMIT??
3058 015260 103416 BLO 98: ;NO, THEN GO TEST
3059 015262 016400 000060 MOV RXFR3(R4),R0 ;GET READ COUNT
3060 015266 066400 000062 ADD WXFR3(R4),R0 ;ADD IN WRITE COUNT
3061 015272 020037 010604 CMP R0,DALMT ;LIMIT REACHED??
3062 015276 103407 BLO 98: ;NO, THEN GO TEST
3063 015300 012737 003611 002246 MOV #SOPLMT,WHY
3064 015306 004537 023450 JSR R5,DRDRV ;DROP THE DRIVE
3065 015312 000137 014726 JMP MAIN ;GO FOR ANOTHER DRIVE
3066
3067 015316 004537 024454 98: JSR R5,RAND ;GET A RANDOM FUNCTION INDEX NUMBER
3068 ;0 & 7 ARE NOT LEGIT
3069 015322 013702 002262 MOV LONUM,R2 ;GET IT
3070 015326 042702 177770 BIC #177770,R2 ;MASK TO 0-7
3071 015332 001001 BNE 6: ;IF 0, MAKE 1

```

PROGRAM MAIN LOOP

3072 015334 005202  
 3073 015336 022702 000007  
 3074 015342 001001  
 3075 015344 005302  
 3076 015346 006302  
 3077 015350 000172 022566  
 3078  
 3079 015354  
  
 3080  
 3081  
 3082  
 3083  
 3084 015354  
  
 3085  
 3086 015354 004537 015716  
 3087 015360 004537 015470  
 3088 015364 004537 016360  
 3089 015370 004537 015470  
 3090 015374 004537 015654  
 3091 015400 004537 015470  
 3092 015404 000137 014726  
 3093  
 3094 015410  
  
 3095  
 3096  
 3097  
 3098 015410  
  
 3099  
 3100 015410 004537 015716  
 3101 015414 004537 015470  
 3102 015420 004537 016430  
 3103 015424 004537 015470  
 3104 015430 000137 014726  
 3105  
 3106 015434  
  
 3107  
 3108  
 3109  
 3110  
 3111 015434  
  
 3112  
 3113 015434 004537 015716  
 3114 015440 004537 015470  
 3115 015444 004537 016430  
 3116 015450 004537 015470  
 3117 015454 004537 016430  
 3118 015460 004537 015470  
 3119 015464 000137 014726  
 3120  
 3121 015470

```

      INC      R2
68:   CMP      @7,R2      ;IS IT 7?
      BNE     58         ;IF 7, MAKE 6
      DEC     R2
58:   ASL     R2         ;SHIFT LEFT (X2)
      JMP     BLIST(R2)  ;GO TO FUNCTION ROUTINE

STARS
;*****
;SKWRT -- ISSUE:
;   SEEK TO A CYLINDER
;   WRITE DATA
;   WRITE CHECK
STARS
;*****

SKWRT: JSR     R5,SKFNC   ;RANDOM SEEK LOAD
      JSR     R5,OPROK   ;WAIT TILL DONE
      JSR     R5,WRTFNC  ;WRITE DATA LOAD
      JSR     R5,OPROK
      JSR     R5,WRTCKF  ;WRITE CHECK LOAD
      JSR     R5,OPROK
      JMP     MAIN      ;GET NEXT COMMAND

STARS
;*****
;SKRD -- ISSUE:
;   RANDOM SEEK TO A CYLINDER
;   READ DATA
STARS
;*****

SKRD:  JSR     R5,SKFNC   ;LOAD SEEK
      JSR     R5,OPROK
      JSR     R5,RDDFNC  ;LOAD READ DATA CMD
      JSR     R5,OPROK
      JMP     MAIN      ;GET THE NEXT COMMAND

STARS
;*****
;SKRDRD -- ROUTINE TO DO:
;   SEEK TO A CYLINDER
;   READ (AND COMPARE DATA)
;   READ (AGAIN)
STARS
;*****

SKRDRD: JSR     R5,SKFNC   ;LOAD SEEK
      JSR     R5,OPROK
      JSR     R5,RDDFNC  ;LOAD READ
      JSR     R5,OPROK
      JSR     R5,RDDFNC  ;LOAD READ
      JSR     R5,OPROK
      JMP     MAIN      ;EXIT

STARS
;*****

```

PROGRAM MAIN LOOP

```

3122 ;OPROK ROUTINE TO ISSUE THE FUNCTION AND WAIT FOR 'READY'...IF AN
3123 ; ERROR RETRY IS NEEDED THEN ISSUE THE FUNCTION AGAIN.
3124 015470 STARS
;*****
3125
3126 015470 004537 016524 OPROK: JSR R5,LDFUNC ;ISSUE THE FUNCTION
3127 015474 004537 024270 JSR R5,WTRDY ;WAIT TILL READY
3128 015500 133737 002250 002252 BITB TSTDRV,DRUT ;DRIVE STILL AVAILABLE?
3129 015506 001003 BNE 1# ;YUP - CONTINUE
3130 015510 005726 TST (SP), ;NO - FIX THE STACK
3131 015512 000137 014726 JMP MAIN ;BACK TO THE MAIN LOOP FORCED EXIT FROM
3132 ; THE STRING FUNCTION
3133 015516 005764 000036 1#: TST RETRY(R4) ;NEED TO RETRY FUNCTION?
3134 015522 001403 BEQ 3# ;NO
3135 015524 004537 016472 2#: JSR R5,ISSUE ;YES - ISSUE THE FUNCTION AGAIN
3136 015530 000757 BR OPROK ;AND DO IT
3137 015532 005764 000114 3#: TST RSEEK(R4) ;SEEK RETRY?
3138 015536 001403 BEQ 4# ;NO - EXIT NOW
3139 015540 004537 015716 JSR R5,SKFNC ;DO A SEEK AGAIN
3140 015544 000751 BR OPROK ;ISSUE & EXECUTE THE SEEK
3141 015546 000205 4#: RTS R5 ;EXIT
3142
3143 015550 STARS
;*****
3144 ;SKRM -- ISSUE:
3145 ; RANDOM SEEK
3146 ; READ HEADERS
3147 ; READ DATA W/NO HDR CMP
3148 ; GET STATUS
3149 015550 STARS
;*****
3150
3151 015550 004537 015716 SKRM: JSR R5,SKFNC ;LOAD SEEK
3152 015554 004537 016524 JSR R5,LDFUNC ;ISSUE
3153 015560 004537 024270 JSR R5,WTRDY
3154 015564 004537 016346 JSR R5,RDNHC ;LOAD READ HDRS
3155 015570 004537 016524 JSR R5,LDFUNC ;ISSUE
3156 015574 004537 024270 JSR R5,WTRDY
3157 015600 004537 015634 JSR R5,RDNHC ;LOAD READ W/NO HDRS
3158 015604 004537 016524 JSR R5,LDFUNC ;ISSUE
3159 015610 004537 024270 JSR R5,WTRDY
3160 015614 004537 015676 JSR R5,GSTFNC ;LOAD GET STATUS
3161 015620 004537 016524 JSR R5,LDFUNC ;ISSUE
3162 015624 004537 024270 JSR R5,WTRDY
3163 015630 000137 014726 JMP MAIN ;GET THE NEXT COMMAND
3164
3165 015634 STARS
;*****
3166 ;READ DATA W/NO HDR COMPARE
3167 015634 STARS
;*****
3168
3169 015634 012764 177600 000042 RDNHC: MOV #-128.,BMP(R4) ;SET FOR A 1 SECTOR READ
3170 015642 012764 000016 000044 MOV #16,FUNC(R4) ;LOAD THE COMMAND
3171 015650 000137 016472 JMP ISSUE ;PROCESS IT
3172
3173 015654 STARS

```



Gf.

PROGRAM MAIN LOOP

```

3174 ;*****
3175 015654 ;WRTCKF - WRITE CHECK FUNCTION
;*****
3176
3177 015654 005737 010652 WRTCKF: TST T,ROF ;READ ONLY SET?
3178 015660 001401 BEQ 1$ ;NO - DO THE WRITE-CHECK FUNCTION
3179 015662 000205 RTS R5 ;YES - EXIT NOW
3180
3181 015664 012764 000002 000044 1$: MOV #WRCCHK,FUNC(R4) ;SAVE CMD
3182 015672 000137 016472 JMP ISSUE ;PROCESS IT
3183
3184 .SBTTL ROUTINES TO SETUP AND ISSUE GET STATUS & SEEK
3185 015676 STARS
;*****
3186 ;GET STATUS FUNCTION
3187 015676 STARS
;*****
3188
3189 015676 012764 000004 000044 GSTFNC: MOV #GSTAT,FUNC(R4) ;LOAD GET STATUS
3190 015704 012764 000003 000040 MOV #GSBIT,BDA(R4) ;SET GSBIT IN COMMAND WORD
3191 015712 000137 016472 JMP ISSUE ;GO ISSUE FUNCTION
3192
3193 015716 STARS
;*****
3194 ;SEEK FUNCTION
3195 015716 STARS
;*****
3196
3197 ;WE WILL CALL "RAND" FOR A NEW DISK ADDRESS TO SEEK
3198 ;TO. ANY TRACK BUT LAST IS LEGAL. WE WILL ALSO INCREMENT
3199 ;ITS SEEK COUNT
3200
3201 015716 005764 000114 SKFNC: TST RSEEK(R4) ;TRYING TO RECOVER
3202 015722 001003 BNE 10$ ;YES - DO IT
3203 015724 005764 000036 TST RETRY(R4) ;RECOVERY FROM A 'DRIVE' ERROR?
3204 015730 001411 BEQ 98$ ;NO - NORMAL SEEK REQUIRED
3205 015732 016401 000050 10$: MOV LSTHDR(R4),R1 ;YES SET UP FOR RESEEK
3206 015736 016402 000124 MOV PRPOS(R4),R2 ;TO CYLINDER
3207 015742 042701 000100 BIC #100,R1 ;HEAD SET IN LATER
3208 015746 042702 000100 BIC #100,R2
3209 015752 000546 BR 4$ ;SKIP RANDOM PART
3210 015754 004537 024454 98$: JSR R5,RAND ;GET A RANDOM NUMBER
3211 015760 013702 002262 MOV LONUM,R2 ;GET THE RANDOM NUMBER
3212 015764 043702 002272 BIC SMSK,R2 ;LEAVE CYL AND HEAD
3213 015770 020264 000124 CMP R2,PRPOS(R4) ;ON THAT TRACK ALREADY
3214 015774 001767 BEQ 98$ ;YES - RESELECT
3215
3216 015776 022764 000001 000120 980$: CMP #1,TDR(R4) ;THIS DRIVE AN RL01?
3217 016004 001006 BNE 981$ ;NO - MUST BE AN RL02
3218 016006 042702 100000 BIC #BIT15,R2 ;KILL UPPER BIT OF CYL ADDRESS
3219 016012 022702 077700 CMP #077700,R2 ;POINTING TO THE BAD SEC FILE?
3220 016016 001007 BNE 96$ ;NO - PROCEED
3221 016020 000403 BR 982$ ;YUP - CORRECT THE POSITION
3222 016022 022702 177700 981$: CMP #177700,R2 ;RL02 BAD SECTOR FILE?
3223 016026 001003 BNE 96$ ;NO - PROCEED
3224 016030 000240 982$: NOP ;TRAP

```

ROUTINES TO SETUP AND ISSUE GET STATUS & SEEK

```

3225 016032 042702 000100      BIC      #HEAD,R2      ;POINT TO HEAD 0 LAST TRACK
3226
3227 016036 010237 002342      96$:    MOV      R2,CHKSEC      ;SAVE THE ADDRESS FOR THE BAD SEC FILE CHECK
3228 016042 004537 027224      JSR      R5,CKBDTK      ;SEE IF THIS ADDR IN BAD SECTOR FILE
3229 016046 005737 002340      TST      HDRFND        ;WAS IT?
3230 016052 001340      BNE      98$           ;YES - RESELECT THE ADDRESS
3231 016054 005003      90$:    CLR      R3
3232 016056 010200      MOV      R2,R0         ;COPY ADDRESS - NO SECTOR YET
3233 016060 042700 177677      BIC      #1776/7,R0    ;LEAVE ONLY HEAD
3234 016064 023737 010626 010630      CMP      T.MXC,T.MNC   ;MIN AND MAX CYLINDERS THE SAME
3235 016072 001011      BNE      95$           ;NO, BRANCH AND STAY IN LIMITS
3236 016074 013702 010626      MOV      T.MXC,R2     ;MAKE CYLINDER MAX/MIN
3237 016100 022764 000001 000120      CMP      #1,TDR(R4)   ;DRIVE = RLO1?
3238 016106 001031      BNE      92$           ;NO
3239 016110 042702 100000      BIC      #BIT15,R2    ;FORCE CYL TO PROPER LIMIT
3240 016114 000426      BR       92$           ;GO CALCULATE DIFF AND SEEK
3241 016116 042702 000100      95$:    BIC      #HEAD,R2     ;STRIP OUT H.S. BIT
3242 016122 023702 010626      94$:    CMP      T.MXC,R2   ;IS ADDRESS LESS/EQUAL THAN MAX
3243 016126 103010      BHIS    93$           ;YES, CHECK LOW END
3244 016130 005203      INC      R3           ;BUMP A TALLY COUNTER
3245 016132 020327 000012      CMP      R3,#10.     ;IF CAN'T FIND ADDRESS IN 10 TIMES THEN RESELECT
3246 016136 001706      BEQ      98$           ;RESELECT
3247 016140 006202      ASR      R2           ;HALF IT AND CHECK AGAIN
3248 016142 062702 000200      91$:    ADD      #BIT7,R2    ;JUST TO MAKE NON ZERO
3249 016146 000763      BR       95$           ;GO BACK AND CHECK AGAIN
3250 016150 023702 010630      93$:    CMP      T.MNC,R2   ;IS MIN GREATER/EQUAL THAN ADDRESS
3251 016154 101406      BLOS    92$           ;YES, CALCULATE DIFF AND SEEK
3252 016156 005203      INC      R3
3253 016160 020327 000012      CMP      R3,#10.     ;TIME TO RESELECT?
3254 016164 001673      BEQ      98$           ;YUP - DO IT NOW
3255 016166 006302      ASL      R2           ;NO, DOUBLE IT
3256 016170 000764      BR       91$           ;GO CHECK MAX/MIN AGAIN
3257 016172 016401 000124      92$:    MOV      PRPOS(R4),R1 ;GET PRESENT DISK POSITION
3258 016176 042701 000177      BIC      #177,R1
3259 016202 022764 000001 000120      CMP      #1,TDR(R4)   ;RLO1=1
3260 016210 001002      BNE      25$           ;BRANCH...MUST BE RLO2
3261 016212 042702 100000      BIC      #BIT15,R2    ;CLEAR THE HIGH BIT FOR RLO2 CYL #
3262 016216 016464 000124 000050 25$:    MOV      PRPOS(R4),LSTHDR(R4)
3263 016224 010264 000124      MOV      R2,PRPOS(R4) ;NEW HEADER AFTER SEEK
3264 016230 050064 000124      BIS      R0,PRPOS(R4) ;SET IN RANDOM HEAD GOTTEN
3265 016234 023737 010622 010624      CMP      T.MXH,i.MNH ;MIN AND MAX HEAD SELECT THE SAME
3266 016242 001012      BNE      4$           ;NO, THEN WE CAN USE BOTH SURFACES
3267 016244 005737 010622      TST      T.MXH        ;WHICH IS OUR SURFACE FOR USE
3268 016250 001004      BNE      97$           ;TOP SURFACE BRANCH
3269 016252 042764 000100 000124      BIC      #HEAD,PRPOS(R4) ;LOWER SURFACE ONLY
3270 016260 000403      BR       4$
3271 016262 052764 000100 000124 97$:    BIS      #HEAD,PRPOS(R4) ;TOP SURFACE ONLY
3272
3273 016270      STARS
;*****
3274      ;CALCULATE THE DIFFERENCE WORD AND STORE IT IN BDA
3275 016270      STARS
;*****
3276
3277 016270 160102      4$:    SUB      R1,R2       ;SUBTRACT PRESENT FROM NEXT
3278 016272 103002      BCC     1$           ;IF POSITIVE RESULT GO TO 1$
3279 016274 005402      NEG     R2           ;NEG RESULT, NEGATE IT

```

ROUTINES TO SETUP AND ISSUE GET STATUS & SEEK

```

3280 016276 000402          BR      2#           ;GO SET DIRECTION OUT
3281 016300 052702 000004 1# :   BIS      #SIGN,R2      ;DIRECTION OUT, MARKER
3282 016304 052702 000001 2# :   BIS      #MK,R2        ;MARKER BIT
3283 016310 032764 000100 000124 BIT      #HEAD,PRPOS(R4) ;WHICH SURFACE SELECTED?
3284 016316 001402          BEQ      3#           ;TOP, THEN 3#
3285 016320 052702 000020 3# :   BIS      #SKHS,R2      ;BOTTOM SET HEAD BIT
3286 016324 010264 000040 3# :   MOV      R2,BDA(R4)    ;MOVE DIFFERENCE WORD TO DA
3287 016330 010264 000066 3# :   MOV      R2,DIFWD(R4) ;LOAD DIFFERENCE WORD
3288 016334 012764 000006 000044 MOV      #SEEK,FUNC(R4) ;LOAD SEEK
3289 016342 000137 016472 000044 JMP      ISSUE          ;ISSUE
3290
3291          .SBTTL  ROUTINE TO LOAD READ HEADER AND ISSUE IT
3292
3293 016346 012764 000010 000044 RDHFNC: MOV      #RDHDR,FUNC(R4) ;LOAD READ HEADER
3294 016354 000137 016472 000044 JMP      ISSUE          ;ISSUE
3295
3296          .SBTTL  ROUTINE TO LOAD WRITE DATA COMMAND
3297
3298 016360 005737 010652 000044 WRTFNC: TST      T,ROF          ;READ ONLY
3299 016364 001021 010652 000044 BNE      RDDFNC          ;YES
3300 016366 004537 025714 000044 JSR      R5,GWCDA        ;GET WORD COUNT,DA
3301 016372 005737 010612 000044 TST      CHRD           ;COMPARE DATA ON A READ?
3302 016376 001404 010612 000044 BEQ      1#           ;NO - SO DON'T GEN A WRITE BUFFER
3303 016400 005237 002306 000044 INC      REGEN          ;YES - SET THE GENERATE DATA FLAG
3304
3305          ; WE NOW HAVE SECTOR AND WORD COUNT, LET'S WRITE BUFFER IN MEMORY
3306          ; TO WRITE OUT TO DISK
3307          ; FORMAT:      WORD 1 - # OF WORDS IN SECTOR
3308          ;              WORD 2 - ADDRESS OF PATTERN WRITTEN ON SECTOR
3309          ;              WORD 3 - 127 DATA PATTERN
3310          ;
3311
3312 016404 004537 022320 000044 JSR      R5,WRBUF        ;WRITE BUFFER INTO MEMORY
3313 016410 012764 000012 000044 1# :   MOV      #WRITE,FUNC(R4) ;LOAD WRITE
3314 016416 012764 000001 000122 MOV      #1,WRIPG(R4)   ;SET THE WRITE IN PROGRESS FLAG
3315 016424 000137 016472 000122 JMP      ISSUE          ;GO ISSUE FUNCTION
3316
3317          .SBTTL  ROUTINE TO LOAD READ DATA COMMAND
3318
3319          ; THIS ROUTINE WILL FIRST CLEAR OUT THE BUFFER AREA,
3320          ; SELECT A RANDOM NUMBER OF WORDS TO READ AND A
3321          ; RANDOM SECTOR ON THE PRESENT CYLINDER TO READ FROM
3322
3323 016430 004537 025714 000044 RDDFNC: JSR      R5,GWCDA        ;GET WORD COUNT, DA
3324 016434 005737 010612 000044 TST      CHRD           ;GOING TO COMPARE DATA AFTER READING?
3325 016440 001407 010612 000044 BEQ      2#           ;NO - SO SKIP THE CLEAR BUFFER CODE
3326 016442 016402 000042 000044 MOV      BMP(R4),R2     ;CLEAR OUT BUFFER AREA
3327 016446 017401 000110 000044 MOV      BBB(R4),R1    ;SO WE KNOW READ
3328 016452 005021 000110 000044 1# :   CLR      (R1)        ;WORKED!!
3329 016454 005202 000110 000044 INC      R2
3330 016456 001375 000110 000044 BNE      1#
3331 016460 012764 000014 000044 2# :   MOV      #READ,FUNC(R4) ;LOAD READ
3332 016466 000137 016472 000044 JMP      ISSUE          ;ISSUE
3333
3334          .SBTTL  SETUP CONTROLLER AND DRIVE INFO FOR INTERRUPT PROCESSING
3335
3336          ; WE COME HERE BEFORE ISSUING ANY FUNCTION SO THAT ON INTERRUPT

```

SETUP CONTROLLER AND DRIVE INFO FOR INTERRUPT PROCESSING

```

3337 ;WE CAN PROPERLY PROCESS THE INTERRUPT. WE WILL CHECK WHICH
3338 ;CONTROLLER WE ARE WORKING WITH AND STORE OFF THE DRIVE BUFFER
3339 ;POINTER IN ITS "LSTDR"
3340 ;
3341 ;
3342 016472 026437 000104 002320 ISSUE: CMP DCS(R4),CNTLR1 ;DRIVE ON CONTROLLER 1?
3343 016500 001003 BNE 1$ ;NO, ASSUME ON CONTROLLER 2
3344 016502 010437 002324 MOV R4,LSTDR1 ;PUT BUFFER POINTER IN 1
3345 016506 000402 BR 2$ ;SKIP OVER NEXT INSTRUCTION
3346 016510 010437 002326 1$: MOV R4,LSTDR2 ;PUT BUFFER POINTER IN 2
3347 016514 052764 000100 000044 2$: BIS @INTEN,FUNC(R4) ;ALLOW INTERRUPTS
3348 016522 000205 RTS R5 ;EXIT
3349
3350 .SBTTL ROUTINE TO LOAD FUNCTION
3351 016524 STARS
;*****
3352 ;CALL JSR R5,LDFUNC
3353 ;ALL INFORMATION MUST BE SET UP IN DRIVE BUFFER
3354 ;R4 HAS POINTER TO BUFFER
3355 016524 STARS
;*****
3356
3357 016524 016403 000104 LDFUNC: MOV DCS(R4),R3 ;GET CSR FOR DRIVE
3358 016530 032713 000200 BIT @BIT7,(R3) ;CAN WE ISSUE COMMAND?
3359 016534 001004 BNE 1$ ;YES, GO ISSUE COMMAND
3360
3361 016536 ERRSF 200,PRGER ;THIS ERROR SHOULD NEVER PRINT
016536 104454 TRAP C1ERSF
016540 000310 .WORD 200
016542 002732 .WORD PRGER
016544 000000 .WORD 0
3362
3363 016546 017463 000110 000002 1$: MOV @BBA(R4),BA(R3) ;LOAD BUS ADDRESS REGISTER
3364 016554 016463 000040 000004 MOV @BDA(R4),DA(R3) ;LOAD DISK ADDRESS REGISTER
3365 016562 016463 000042 000006 MOV @BMP(R4),MP(R3) ;LOAD MULTI-PURPOSE REGISTER
3366 016570 016464 000044 000046 MOV FUNC(R4),BCSADR(R4) ;GET FUNCTION
3367 016576 056464 000106 000046 BIS @RSEL(R4),BCSADR(R4) ;SET DRIVE SELECT BITS
3368 016604 052764 000201 000046 BIS @CRDY:DRDY,BCSADR(R4) ;SET CRDY:DRDY IN IMAGE
3369 016612 042764 002000 000046 BIC @OPI,BCSADR(R4) ;WE'RE CLEAR BIT 10 FOR DRIVE 7-4 (OKAY?)
3370 016620 016463 000046 000000 MOV BCSADR(R4),CS(R3) ;LOAD CSR
3371 016626 042763 000200 000000 BIC @CRDY,CS(R3) ;ISSUE FUNCTION
3372 016634 000205 RTS R5 ;EXIT
3373
3374 .SBTTL INTERRUPT SERVICE ROUTINES
3375
3376 ;CLOCK INTERRUPT HANDLER
3377 ;UPDATES TIME EVERY 1/60 SECOND (60 HZ) OR EVERY 1/50 SECOND (50 HZ)
3378 016636 BGNSRV UPDATE
3379 016636 010446 MOV R4,-(SP) ;SAVE R4
3380 ;CLEAR CLOCK INTERRUPT ENABLE TO INHIBIT CLOCK INTERRUPTS DURING UPDATING
3381 ;OF TIME FIELDS
3382 016640 022737 000001 002314 CMP #1,CLKTYP ;P-CLOCK?
3383 016646 001004 BNE 1$ ;BRANCH IF NOT P-CLOCK
3384 016650 042737 000100 172540 BIC #100,@172540 ;DISABLE P-CLOCK INTERRUPT FACILITY
3385 ;UPDATE TIME FIELDS
3386 016656 000403 BR 2$
3387 016660 042737 000100 177546 1$: BIC #100,@177546 ;DISABLE L-CLOCK INTERRUPT FACILITY

```

INTERRUPT SERVICE ROUTINES

```

3388 016666 012704 002410      2$:  MOV    #TICK,R4      ;INITIALIZE TICK ADDRESS
3389 016672 005214              INC    (R4)          ;INCREMENT TICK TIME FIELD
3390 016674 023727 002312 000002  CMP    CLKFRQ,#2     ;50 HZ CLOCK?
3391 016702 001005              BNE    3$           ;NO--BRANCH FOR SERVICING 60 MZ CLOCK
3392 016704 021427 000062      CMP    (R4),#50     ;((R4))=50?
3393 016710 001026              BNE    EXIT2        ;IF NOT,UPDATING IS COMPLETE
3394 016712 005014              CLR    (R4)          ;ELSE,((R4))=0 (RESET COUNT)
3395 016714 000404              BR     4$           ;BRANCH TO UPDATE "SECOND" TIME FIELD
3396 016716 021427 000074      3$:  CMP    (R4),#60.   ;((R4))=60?
3397 016722 001021              BNE    EXIT2        ;IF NOT,UPDATING IS COMPLETE
3398 016724 005014              CLR    (R4)          ;ELSE,((R4))=0 (RESET COUNT)
3399 016726 005724              4$:  TST    (R4)+       ;(R4)=(R4)+2 (GO TO NEXT TIME FIELD)
3400 016730 005214              INC    (R4)          ;INCREMENT "SECOND" TIME FIELD
3401 016732 021427 000074      CMP    (R4),#60.   ;((R4))=60?
3402 016736 001013              BNE    EXIT2        ;IF NOT,UPDATING IS COMPLETE
3403 016740 005237 002406      INC    INTERVAL     ;INCREMENT INTERVAL TIME FIELD (STORES
3404                                ;/RUNNING TIME BETWEEN STATISTICAL REPORTS)
3405 016744 005014              CLR    (R4)          ;ELSE,((R4))=0 (RESET COUNT)
3406 016746 005724              TST    (R4)+       ;ACCESS "MINUTE" TIME FIELD
3407 016750 005214              INC    (R4)          ;INCREMENT "MINUTE" TIME FIELD
3408 016752 021427 000074      CMP    (R4),#60.   ;((R4))=60?
3409 016756 001003              BNE    EXIT2        ;IF NOT,UPDATING IS COMPLETE
3410 016760 005014              CLR    (R4)          ;ELSE,((R4))=0 (RESET COUNT)
3411 016762 005724              TST    (R4)+       ;ACCESS "HOUR" TIME FIELD
3412 016764 005214              INC    (R4)          ;INCREMENT "HOUR" TIME FIELD
3413 016766 005337 002510      EXIT2: DEC    CLKBFR ;COUNT CLOCK TICKS
3414 016772 003005              BGT    5$           ;TIME NOT EXPIRED
3415 016774 005237 002512      INC    CLKACC       ;BUMP ELAPSED TIME
3416 017000 013737 002506 002510  MOV    CLKCNT,CLKBFR ;RE-INITIALIZE TIME INCREMENT
3417                                ;RE-ENABLE CLOCK INTERRUPT FACILITY
3418 017006 022737 000001 002314  5$:  CMP    #1,CLKTYP   ;P-CLOCK?
3419 017014 001004              BNE    6$           ;BRANCH IF NOT P-CLOCK
3420 017016 052737 000100 172540  BIS    #100,#0172540 ;SET P-CLOCK INTERRUPT ENABLE BIT
3421 017024 000403              BR     7$           ;EXIT
3422 017026 052737 000100 177546  6$:  BIS    #100,#0177546 ;SET L-CLOCK INTERRUPT ENABLE BIT
3423 017034 012604              7$:  MOV    (SP)+,R4   ;RESTORE R4
3424 017036                                ENDSRV
                                L10025:
                                RTI
3425
3426                                ;L-CLOCK "TICK" CHECK ROUTINE FOR LSI-11
3427 017040                                BGNSRV  CLKTIK
3428
3429 017040 005237 002514              INC    CLKFLD       ;INCREMENT CLOCK FIELD TO INDICATE THAT
3430                                ;/CLOCK IS "TICKING"
3431
3432 017044                                ENDSRV
                                L10026:
                                RTI
3433
3434 017046                                BGNSRV  INTR1
3435
3436                                ;ON INTERRUPT WE CHECK FOR ERRORS FIRST, IF NO ERRORS WE
3437                                ;CHECK FUNCTION PERFORMED, WE ACT ACCORDING IF FUNCTION IS:
3438                                ; 1-  WRITE CHECK - NOTHING IF NO ERROR
3439                                ; 2-  GET STATUS - READ AND CHECK DRIVE STATUS
3440                                ; 3-  SEEK - NOTHING RTI; SET RD HDR AS NEXT COMMAND

```

INTERRUPT SERVICE ROUTINES

```

3441 ; 4 RDHDR COMPARE HEADER TO PRESENT POSITION
3442 ; 5- WRITE UPDATE XFER COUNT, EXIT
3443 ; 6 READ COMPARE DATA IF REQUESTED, UPDATE XFER COUNT, EXIT
3444 ; 7- READ W/NO HDR COMPARE - UPDATE XFER COUNT, EXIT
3445 ;
3446 ;ALL SUCCESSFUL EXITS FROM INTERRUPT ROUTINE TEST RETRY
3447 ;LIMIT IF RETRY IS LESS THEN LIMIT THEN LOG SOFT ERROR, CLEAR RETRY
3448 ;IF RETRY = 0, THEN NOTHING
3449 ;
3450 ;ON ERRORS - IF DRIVE ERROR - UNDER NON-INTERRUPT
3451 ; DO: GET STATUS - INVESTIGATE ERROR TYPE
3452 ;
3453 ; DO: DRIVE RESET - IF ERROR OCCURS AGAIN FATAL ERROR
3454 ; IF NO ERROR, EXIT
3455 ; DRIVE ERROR IS LOGGED UNDER ALL CIRCUMSTANCES
3456 ;
3457 ;
3458 ; IF DCRC, MCRC, MNF CHECK BAD SECTOR LIST, IF IN LIST
3459 ; IGNORE ERROR EXIT AS NORMAL, IF NOT IN LIST
3460 ; INCREMENT RETRY; IF RETRY LIMIT EXCEEDED
3461 ; LOG HARD ERROR, ELSE RETRY FUNCTION
3462 ;
3463 ; IF OPI,NXM INCREMENT RETRY CHECK RETRY LIMIT
3464 ; IF RETRY EXCEEDED LOG HARD ERROR EXIT
3465 ; IF RETRY NOT EXCEEDED RETRY FUNCTION
3466 ;
3467 ;
3468 ;
3469 017046 010446 INTR1: MOV R4, (SP) ;SAVE PRESENT R4 VALUE
3470 017050 013704 002324 MOV LSTDR1,R4 ;GET THE DRIVE BUFFER OF INTERRUPTING DRIVE
3471 017054 000403 BR SAVE ;GO SAVE R0-R3
3472 017056 010446 INTR2: MOV R4, -(SP) ;SAVE PRESENT R4 VALUE
3473 017060 013704 002326 MOV LSTDR2,R4 ;GET THE DRIVE BUFFER OF INTERRUPTING DRIVE
3474 017064 013746 002420 SAVE: MOV E.CS, -(SP)
3475 017070 013746 002422 MOV E.BA, -(SP)
3476 017074 013746 002424 MOV E.DA, -(SP)
3477 017100 013746 002426 MOV E.MP, -(SP)
3478 017104 013746 002430 MOV E.MP1, -(SP)
3479 017110 013746 002432 MOV E.MP2, -(SP)
3480 017114 013746 002342 MOV CHKSEC, -(SP)
3481 017120 013746 002340 MOV HDRFND, -(SP)
3482 017124 013746 002350 MOV TEMP1, -(SP)
3483 017130 013746 002246 MOV WHY, -(SP)
3484 017134 013746 002474 MOV OPCALL, -(SP)
3485 017140 013746 002476 MOV INCALL, -(SP)
3486 017144 010346 MOV R3, -(SP) ;SAVE R3
3487 017146 010246 MOV R2, -(SP) ;R2
3488 017150 010146 MOV R1, -(SP) ;R1
3489 017152 010046 MOV R0, -(SP) ;R0
3490 017154 005064 000122 CLR WRIPG(R4) ;CLEAR THE WRITE IN PROGRESS FLAG
3491 017160 016403 000104 MOV DCS(R4),R3 ;GET CSR FOR INTERRUPT
3492 017164 016337 000000 002420 MOV CS(R3),E.CS ;SAVE ALL REGISTERS NOW!!
3493 017172 016337 000002 002422 MOV BA(R3),E.BA
3494 017200 016337 000004 002424 MOV DA(R3),E.DA
3495 017206 016337 000006 002426 MOV MP(R3),E.MP
3496 017214 016337 000006 002430 MOV MP(R3),E.MP1
3497 017222 016337 000006 002432 MOV MP(R3),E.MP2

```

INTERRUPT SERVICE ROUTINES

```

3498 017230 005737 002420      TST      E.CS          ;ANY ERRORS?
3499 017234 100402              BMI      1$           ;YES, GO SOLVE ERROR MYSTERY
3500 017236 000137 020362      JMP      CHKFUNC      ;NO, GO SEE IF WE HAVE TO DO ANYTHING
3501
3502      .SBTTL  CONTROLLER ERROR CHECK ROUTINE
3503
3504      ;WE HAVE SOME SORT OF ERROR LET'S FIND OUT WHICH ONE
3505      ;IT IS.
3506
3507 017242 013764 002424 000064 1$:  MOV      E.DA,LSTDA(R4) ;SAVE DA FOR SOFT ERROR PRINT
3508 017250 032737 040000 002420      BIT      #DERR,E.CS   ;DRIVE ERROR?
3509 017256 001402              BEQ      2$           ;NO, CONTINUE
3510 017260 000137 021350              JMP      CKDERR       ;YES, GO CHECK DRIVE ERROR
3511 017264 032737 000001 002420 2$:  BIT      #DRDY,E.CS   ;DRIVE READY THERE
3512 017272 001017              BNE      23$          ;YES, CONTINUE CHECKING
3513 017274 004537 024362              JSR      R5,GETDST    ;NO,GET DRIVE STATUS
3514 017300 042701 000100              BIC      #100,R1      ;GET RID OF HEAD
3515 017304 020127 000034              CMP      R1,#34       ;ALLOW ONLY SEEK TRACKING STATE
3516 017310 001410              BEQ      23$          ;WAS 34 SKIP ERROR
3517
3518 017312 005264 000012              INC      ERRCNT(R4)   ;INDICATE HARD ERROR
3519 017316              ERRDF  1000.,NORDY,ERR9
      017316 104455              TRAP    C#ERDF
      017320 001750              .WORD   1000
      017322 002704              .WORD   NORDY
      017324 005602              .WORD   ERR9
3520
3521 017326 000137 021204              JMP      EXIT1
3522
3523 017332 032737 020000 002420 23$: BIT      #NXM,E.CS    ;NON-EXISTENT MEMORY?
3524 017340 001407              BEQ      3$           ;NO, KEEP CHECKING
3525 017342 012764 004346 000052      MOV      #MTNXM,RTYPE(R4) ;ERROR MESSAGE
3526 017350 005264 000034              INC      NXMCNT(R4)   ;LOG ERROR
3527 017354 000137 017766              JMP      111$         ;CHECK RETRY, EXIT BACK
3528
3529 017360 032737 014000 002420 3$:  BIT      #BIT12!BIT11,E.CS ;QUALIFYING BITS SET?
3530 017366 001020              BNE      5$           ;YES, CAN'T BE OPI ALONE
3531
3532 017370 032737 002000 002420      BIT      #OPI,E.CS    ;OPI SET?
3533 017376 001006              BNE      4$           ;YES, CONTINUE
3534
3535 017400              ERRSF  10.,UDERR,ERR1 ;WE HAVE AN UNDIAGNOSABLE CONDITION, ONLY COMPOSITE SET
      017400 104454              TRAP    C#ERSF
      017402 000012              .WORD   10
      017404 003007              .WORD   UDERR
      017406 005070              .WORD   ERR1
3536 017410              33$: BREAK
      017410 104422              TRAP    C#BRK
3537 017412 000776              BR      33$
3538
3539 017414 012764 004341 000052 4$:  MOV      #MTOPI,RTYPE(R4);SET UP FOR "OPI" PRINT
3540 017422 005264 000030              INC      OPICNT(R4)  ;LOG ERROR
3541 017426 000557              BR      111$         ;CHECK RETRY EXIT BACK
3542
3543      ;WE KNOW IT'S NOW EITHER DLT, DCRC,HNF, OR MCRC
3544      ;CHECK FOR EACH
3545

```

CONTROLLER ERROR CHECK ROUTINE

```

3546 017430 032737 002000 002420 5$: BIT #OPI,E.CS ;OPI QUALIFIER SET?
3547 017436 001060 BNE 7$ ;YES, THEN IT S HCRC OR HNF
3548
3549 ;IT'S NOW DOWN TO DLT OR DCRC
3550
3551 017440 032737 010000 002420 BIT #DLT,E.CS ;DATA LATE?
3552 017446 001406 BEQ 6$ ;NO, MUST BE DATA CRC
3553 017450 012764 004334 000052 MOV #MTDLT,RTYPE(R4);SET UP FOR "DLT"PRINT
3554 017456 005264 000026 INC DLTCNT(R4) ;LOG ERROR
3555 017462 000541 BR 111$ ;CHECK RETRY, EXIT
3556
3557 017464 013737 002424 002342 6$: MOV E.DA,CHKSEC ;SET UP SECTOR TO LOOK FOR
3558 017472 005364 000064 DEC LSTDA(R4) ;DOWN CJUNT FOR PRINT OUT
3559 017476 005337 002342 DEC CHKSEC ;DOWN COUNT FOR LOOP UP
3560 017502 004537 027146 JSR R5,CKBDSC ;CHECK BAD SECTOR LIST
3561 017506 005737 002340 TST HDRFND ;WAS HEADER THERE?
3562 017512 001117 BNE 110$ ;IGNORE ERROR, RETURN
3563 017514 005264 000022 117$: INC DCR CER(R4) ;ACCOUNT FOR ERROR
3564 017520 012764 004327 000052 MOV #MTDCRC,RTYPE(R4);SET UP FOR "DCRC" PRINT
3565 017526 022764 000102 000044 CMP #INTEN!WRCHK,FUNC(R4)
3566 017534 001001 BNE 118$
3567 017536 000513 BR 111$
3568
3569 017540 005737 010636 118$: TST T.DCK ;DUMP BUFFER?
3570 017544 001510 BEQ 111$ ;NO. EXIT
3571 017546 PRINTF #FMT14,#DMPDCK
017546 012746 003265 MOV #DMPDCK,-(SP)
017552 012746 007463 MOV #FMT14,-(SP)
017556 012746 000002 MOV #2,-(SP)
017562 010600 MOV SP,R0
017564 104417 TRAP C:PNTF
017566 062706 000006 ADD #6,SP
3572 017572 004537 026222 JSR R5,DMPBUF ;DUMP BUFFER
3573
3574 017576 000473 BR 111$ ;EXIT
3575
3576 ;IT'S NOW EITHER HNF OR HCRC.
3577 ;IF HCRC AND RDHDR, DETERMINE IF BAD SECTOR BY DOING 40 RDHDRS
3578 ;IF HCRC AND R/W, CHECK IF DA IS IN BAD SECTOR FILE
3579 ;IF HNF READ HEADER TO VERIFY IF ON CORRECT CYLINDER
3580 ;THEN IF ON CORRECT CYLINDER SEE IF DA IS A BAD SECTOR
3581 ;IF NOT ON CORRECT CYLINDER REPORT MISSEK, LOG MISEEK
3582 ;AND PRESENT POSITION UPDATE.
3583
3584 017600 032737 010000 002420 7$: BIT #HNF,E.CS ;HEADER NOT FOUND SET?
3585 017606 001470 BEQ 112$ ;NO IT MUST BE HCRC
3586 017610 012701 000051 MOV #41,,R1 ;ALLOW FORTY READ HEADERS TO
3587 017614 004537 024376 8$: JSR R5,ISDRST
3588 017620 016402 000106 MOV DRSEL(R4),R2 ;FIND CYLINDER
3589 017624 052702 000010 BIS #RDHDR,R2 ;READ HEADER
3590 017630 016403 000104 MOV DCS(R4),R3
3591 017634 010263 000000 MOV R2,CS(R3) ;ISSUE READ HEADER
3592 017640 004537 024270 JSR R5,WTRDY ;WAIT
3593 017644 005301 DEC R1 ;DONE 40 OF THESE?
3594 017646 001424 BEQ 9$ ;YES, GIVE UP WE DON'T HAVE ALL DAY!
3595 017650 005763 000000 TST CS(R3) ;IS ERROR SET?
3596 017654 100757 BMI 8$ ;YES, GO DO IT AGAIN

```



## CONTROLLER ERROR CHECK ROUTINE

```

3597
3598 017656 016301 000006      MOV      MP(R3),R1      ;GET HEADER
3599 017662 010137 002434      MOV      R1,C.HDR      ;SAVE FOR ERROR REPORTING
3600 017666 043701 002272      BIC      SMSK,R1       ;MASK OUT SECTOR BITS
3601 017672 020164 000124      CMP      R1,PRPOS(R4)  ;IS CYLINDER HEAD CORRECT?
3602 017676 001415              BEQ      100           ;YES, GO CHECK BAD SECTOR LIST
3603
3604 017700 005264 000072      INC      TRERR(R4)     ;
3605 017704              ERRHRD  20.,TRACK,ERR2 ;TRACKING DRIFT ERROR
      017704 104456      TRAP    C1ERRHRD
      017706 000024      .WORD   20
      017710 003305      .WORD   TRACK
      017712 005076      .WORD   ERR2
3606
3607 017714 000137 020700      JMP      SKRETRY       ;FIX TRACKING ERROR
3608
3609 017720              90:    ERRHRD  30.,EXHAUS,ERR1 ;WE CAN'T FIND GOOD HEADER ON THIS TRACK
      017720 104456      TRAP    C1ERRHRD
      017722 000036      .WORD   30
      017724 002773      .WORD   EXHAUS
      017726 005070      .WORD   ERR1
3610
3611 017730 000410              BR      1100
3612
3613 017732 013737 002424 002342 100:    MOV      E.DA,CHKSEC
3614 017740 004537 027224              JSR      R5,CKBDTK     ;GO CHECK BAD SECTOR FILE
3615 017744 005737 002340              TST      HDRFND        ;WAS IT THERE
3616 017750 001401              BEQ      110           ;NO, LOG IT EXIT
3617 017752 000577              1100:   BR      GOERRX        ;YES IGNORE ERROR
3618
3619 017754 005264 000032              110:    INC      HNFERR(R4)    ;LOG IT
3620 017760 012764 004314 000052              MOV      @MTHNF,RTYPE(R4);SET UP FOR "HNF" PRINT
3621 017766 000573              1110:   BR      GOFIN         ;EXIT
3622
3623              ;
3624              ;IT WAS A HEADER CRC ERROR, FIGURE OUT IF IT WAS
3625              ;ON A READ HEADER OR READ/WRITE
3626              ;
3627
3628 017770 022764 000110 000044 1120:   CMP      @INTEN!RDHDR,FUNC(R4) ;READ HEADER?
3629 017776 001417              BEQ      130           ;YES, GO FIND OUT MORE ABOUT IT
3630              ;NO, IT MUST BE R/W
3631 020000 013737 002424 002342              MOV      E.DA,CHKSEC
3632 020006 004537 027146              JSR      R5,CKBDSC     ;BAD SECTOR SEARCH
3633 020012 005737 002340              TST      HDRFND        ;WAS OUR DA THERE?
3634 020016 001401              BEQ      120           ;NO, MUST BE LEGIT ERROR
3635 020020 000554              BR      GOERRX        ;YES, IGNORE ERROR
3636
3637 020022 005264 000024              120:    INC      HRCRC(R4)     ;LOG ERROR
3638 020026 012764 004321 000052              MOV      @MTHCRC,RTYPE(R4)
3639 020034 000550              BR      GOFIN
3640
3641 020036 017401 000110              130:    MOV      @BBA(R4),R1   ;USE IT'S BUFFER TO STORE HDRS
3642 020042 012737 000050 002350              MOV      @40.,TEMP1    ;40 CONSECUTIVE HEADERS
3643 020050 012702 000010              140:    MOV      @RDHDR,R2     ;READ HEADER
3644 020054 056402 000106              BIS      DRSEL(R4),R2  ;
3645 020060 016403 000104              MOV      DCS(R4),R3   ;

```

## CONTROLLER ERROR CHECK ROUTINE

```

3646 020064 010263 000000      MOV      R2,CS(R3)          ;
3647 020070 004537 024270      JSR      R5,WTRDY          ;WAIT FOR READY
3648 020074 016321 000000      MOV      CS(R3),(R1)       ;READ ALL REGISTERS
3649 020100 016321 000006      MOV      MP(R3),(R1)       ;
3650 020104 016321 000006      MOV      MP(R3),(R1)       ;
3651 020110 016321 000006      MOV      MP(R3),(R1)       ;
3652 020114 005337 002350      DEC      TEMP1             ;DONE 40 YET?
3653 020120 001353              BNE      141                ;NO, GO BACK
3654
3655                          ;WE HAVE 40 HEADERS NOW LETS SEE IF WE CAN VERIFY WHETHER
3656                          ;OR NOT A BAD SECTOR CAUSED THE ERROR. CHECK FIRST TO SEE
3657                          ;IF WE HAVE ANY BAD SECTORS ON THIS TRACK.
3658
3659 020122 017402 000110      991:    MOV      @BBA(R4),R2      ;GET BUFFER START
3660 020126 012701 000050      MOV      #40.,R1           ;FORTY HEADERS
3661 020132 032712 002000      151:    BIT      @OPI,(R2)         ;IS OPI SET IN CS
3662 020136 001403              BEQ      161                ;NO, WELL CAN'T BE MCRC
3663 020140 032712 004000      BIT      @MCRC,(R2)        ;INSURE MCRC W/OPI
3664 020144 001005              BNE      171                ;FOUND GO SEE IF IT COMPARES
3665 020146 062702 000010      161:    ADD      #10,R2            ;NEXT CS IMAGE
3666 020152 005301              DEC      R1                  ;DONE 40
3667 020154 001366              BNE      151                ;
3668 020156 000721              BR       121                ;
3669
3670 020160 020274 000110      171:    CMP      R2,@BBA(R4)       ;IS HEADER FIRST ONE?
3671 020164 001046              BNE      211                ;NO, READ PREVIOUS HEADER
3672                          ;YES, WE'LL HAVE TO GO THRU
3673                          ;AND CHECK OTHERS BEFORE WE
3674                          ;CAN SAFELY CALCULATE
3675                          ;"SUPPOSED" BAD SECTOR
3676 020166 017401 000110      MOV      @BBA(R4),R1
3677 020172 012703 000001      MOV      #1.,R3
3678 020176 062701 000010      181:    ADD      #10,R1
3679 020202 032711 002000      BIT      @OPI,(R1)
3680 020206 001416              BEQ      191
3681 020210 032711 004000      BIT      @MCRC,(R1)
3682 020214 001413              BEQ      191
3683 020216 005203              INC      R3
3684 020220 022703 000017      CMP      #15.,R3
3685 020224 001364              BNE      181
3686
3687 020226 012737 003667 002246      MOV      @MBDMSC,WHY        ;DROP DRIVE DUE TO
3688 020234 004537 023450      JSR      R5,DRDRV          ;MORE THAN 16 BAD SECTORS
3689 020240 000137 021204      JMP      EXIT1
3690
3691 020244 005012              191:    CLR      (R2)               ;CLEAR THIS CS
3692 020246 062701 000002      ADD      #2,R1              ;GET IT'S HEADER ADDRESS
3693 020252 011102              MOV      (R1),R2            ;GET HEADER
3694 020254 010201              MOV      R2,R1              ;SAVE HEADER
3695 020256 042702 177700      BIC      #177700,R2         ;MASK ONLY SECTOR
3696 020262 160301              SUB      R3,R1              ;BACK UP TO SECTOR WHICH IS BAD
3697 020264 100402              BMI     201                ;IF MINUS DO MAGIC
3698 020266 160302              SUB      R3,R2              ;NO THEN SUBTRACT IS LEGAL
3699 020270 000421              BR       221                ;BRANCH TO CHECK FILE
3700 020272 160302              201:    SUB      R3,R2              ;THIS SUB PRODUCES WRONG ANSWER
3701 020274 062702 000050      ADD      #50,R2             ;FIX IT UP
3702 020300 000415              BR       221                ;GO CHECK FILE

```

CONTROLLER ERROR CHECK ROUTINE

```

3703
3704 020302 005012          214: CLR      (R2)          ;CLEAR THIS CS OUT
3705 020304 162702 000006  SUB      #6,R2          ;GET PREVIOUS HEADER
3706 020310 011201          MOV      (R2), R1
3707 020312 005201          INC      R1
3708 020314 010102          MOV      R1,R2
3709 020316 042701 177700  BIC      #177700,R1
3710 020322 022701 000050  CMP      #40.,R1
3711 020326 002402          BLT     224
3712 020330 162702 000050  SUB      #40.,R2
3713 020334 010237 002342  224: MOV      R2,CHKSEC
3714 020340 004537 027146  JSR      R5,CKBUSE
3715 020344 005737 002340  TST     HDRFND
3716 020350 001664          BEQ     994
3717 020352 000137 021210  GOERRX: JMP      ERREX
3718
3719 020356 000137 021312  GOFIN:  JMP      FINERR
3720
3721          .SBTTL  COMMAND SERVICE ROUTINES
3722
3723          ;THERE WAS NO ERROR SO.....
3724          ;NOW WE WILL FIND OUT WHICH FUNCTION WE DID TO CAUSE
3725          ;INTERRUPT AND ACT ACCORDINGLY.
3726          ;
3727
3728 020362 016401 000044  CHKFNC: MOV      FUNC(R4),R1  ;GET FUNCTION OF DRIVE
3729 020366 006201          ASR     R1                ;ALIGN THE FUNCTION CODE
3730 020370 042701 000040  BIC     #40,R1            ;WIPE OUT INT. ENAB (SHIFTED)
3731 020374 005301          DEC     R1                ;WRITE CHECK??
3732 020376 001002          BNE    244                ;NO, BRANCH
3733 020400 000137 020540  JMP     AFWRCK            ;FUNCTION #1
3734
3735 020404 005301          244:  DEC     R1                ;GET STATUS?
3736 020406 001565          BEQ    AGSTAT            ;BRANCH IF SO...FUNCTION #2
3737 020410 005301          DEC     R1                ;SEEK?
3738 020412 001421          BEQ    ASEEK            ;BRANCH IF SO...FUNCTION #3
3739 020414 005301          DEC     R1                ;RDHDR?
3740 020416 001500          BEQ    ARDHDR            ;BRANCH IF SO...FUNCTION #4
3741 020420 005301          DEC     R1                ;WRITE?
3742 020422 001002          BNE    144                ;NO, BRANCH
3743 020424 000137 021066  JMP     AWRITE            ;FUNCTION #5
3744 020430 005301          144:  DEC     R1                ;READ?
3745 020432 001432          BEQ    AFREAD            ;BRANCH IF SO...FUNCTION #6
3746 020434 005301          DEC     R1                ;READ W/NO HDR COMPARE?
3747 020436 001440          BEQ    AFWRCK            ;YES TREAT AS IF WRITE CHECK
3748
3749 020440          ERRSF  210.,PRGER      ;SHOULD NEVER GET HERE!!!
3749 020440 104454          TRAP  CERSF
3749 020442 000322          .WORD 210
3749 020444 002732          .WORD PRGER
3749 020446 000000          .WORD 0
3750 020450 000000
3751 020452 000137 021152  XEXIT:  JMP      EXIT
3752
3753          .SBTTL  SEEK INTERRUPT SERVICE
3754
3755 020456 052764 000001 000056  ASEEK:  BIS     #SKDON,PRFLGS(R4) ;SET SEEK VERIFY NEEDED

```

SEEK INTERRUPT SERVICE

```

3756 020464 005064 000114      CLR      RSEEK(R4)      ;CLEAR THE RETRY FLAG
3757 020470 005264 000054      INC      SKCNT1(R4)    ;INCREMENT COUNT
3758 020474 026427 000054      CMP      SKCNT1(R4),#1000. ;10(3) REACHED
3759 020502 002404          001750      BLT      99#          ;NO, EXIT
3760 020504 005264 000000      INC      SKCNT(R4)    ;YES, BUMP THOUSANDS
3761 020510 005064 000054      CLR      SKCNT1(R4)
3762 020514 000137 021152      99# :    JMP      EXIT
3763
3764          .SBTTL  READ INTERRUPT SERVICE
3765
3766 020520 042764 000001 000056  AFREAD: BIC      #SKDON,PRFLGS(R4)      ;CLEAR THE SEEK VERIFY FLAG
3767          ;      SETPRI  #340          ;JSD REV A
3768 020526 012700 000300      SETPRI  #300          ;JSD REV A
3769 020534 004537 023672      MOV      #300,R0
3770          TRAP   C#SPRI
3771 020540 016401 000042      JSR      R5,CKDATA      ;CHECK DATA
3772 020544 005401          AFWRCK: MOV      BMP(R4),R1      ;BUMP UP XFER COUNT
3773 020546 060164 000002      NEG      R1            ;MAKE POSITIVE
3774 020552 022764 023420 000002      ADD      R1,RXFR1(R4)  ;ADD THE BITS
3775 020560 101016          CMP      #10000.,RXFR1(R4) ;10(8) REACHED YET
3776 020562 005264 000004      BHI      2#          ;NO, EXIT
3777 020566 162764 023420 000002      INC      RXFR2(R4)    ;BUMP 10(10)
3778 020574 022764 023420 000004      SUB      #10000.,RXFR1(R4) ;START 10(8) AT 0
3779 020602 101005          CMP      #10000.,RXFR2(R4) ;10(10) REACHED YET
3780 020604 005264 000060      BHI      2#          ;NO, EXIT
3781 020610 162764 023420 000004      INC      RXFR3(R4)    ;YES BUMP 65K 10(10)
3782 020616 000555      2# :    SUB      #10000.,RXFR2(R4) ;MAKE 10(10) 0
3783          BR      EXIT      ;EXIT
3784          .SBTTL  READ HEADER INTERRUPT SERVICE
3785
3786 020620 013701 002426      ARDHDR: MOV      E.MP,R1      ;GET HEADER
3787 020624 043701 002272      BIC      SMSK,R1      ;MASK OUT SECTOR BITS
3788 020630 026401 000124      CMP      PRPOS(R4),R1 ;IS HEADER CORRECT?
3789 020634 001442          BEQ     1#          ;YES, CONTINUE
3790
3791 020636 032764 000001 000056      BIT      #SKDON,PRFLGS(R4) ;IS THIS MIS-SEEK OR TRACKING ERROR
3792 020644 001407          BEQ     2#          ;BRANCH IF TRACKING
3793
3794 020646 005264 000016          INC      SKECNT(R4)    ;ACCOUNT FOR SEEK ERROR
3795 020652          ERRHRD 50.,MSKER,ERR2
3796          TRAP   C#ERRRD
3797          .WORD 50
3798          .WORD MSKER
3799          .WORD ERR2
3800          BR      3#          ;BRANCH AROUND TRACKING ERROR REPORT
3801
3802 020662 000406          2# :    INC      TRERR(R4)    ;ACCOUNT FOR TRACKING ERROR
3803          ERRHRD 55.,TRACK,ERR2 ;TRACKING ERROR
3804          TRAP   C#ERRRD
3805          .WORD 55
3806          .WORD TRACK
3807          .WORD ERR2
3808
3809          SKRETRY=.
3810
3811          020700
3812

```

READ HEADER INTERRUPT SERVICE

```

3803 020700 005264 000114 38: INC RSEEK(R4) ;SET RETRY IN PROGRESS
3804 020704 026437 000114 010660 CMP RSEEK(R4),T.SLT ;RETRY EXHAUSTED?????
3805 020712 101405 BLOS 4# ;NO, THEN RETRY
3806
3807 020714 ERRHRD 333.,SEXHAU,ERR2
      020714 104456 TRAP C#ERRHRD
      020716 000515 .WORD 333
      020720 003523 .WORD SEXHAU
      020722 005076 .WORD ERR2
3808 020724 000406 BR 1#
3809
3810 020726 010164 000050 48: MOV R1,LSTHDR(R4) ;SET UP RETRY
3811 020732 042764 000001 000056 BIC #SKDON,PRFLGS(R4) ;ALLOW SEEK
3812 020740 000504 BR EXIT ;EXIT
3813 020742 042764 000001 000056 18: BIC #SKDON,PRFLGS(R4) ;SET VERIFICATION DONE
3814 020750 005064 000114 CLR RSEEK(R4)
3815 020754 010164 000124 MOV R1,PRPOS(R4) ;MAKE THIS HEADER PRESENT POSITION
3816 020760 000474 BR EXIT ;EXIT
3817
3818 .SBTTL GET STATUS INTERRUPT SERVICE
3819
3820 020762 013701 002426 AGSTAT: MOV E.MP,R1 ;GET STATUS
3821 020766 042701 000100 BIC #100,R1 ;CLEAR OUT HEAD SELECT
3822 020772 005737 010652 TST T.ROF ;READ ONLY
3823 020776 001402 BEQ 2#
3824 021000 042701 020000 BIC #WL,R1
3825 021004 032701 177400 28: BIT #177400,R1 ;ANY BITS WRONG
3826 021010 001406 BEQ 1# ;NO, CONTINUE
3827
3828 021012 005264 000012 INC ERRCNT(R4) ;STATUS BITS WRONG
3829 021016 ERRHRD 60.,MDSER,ERR4
      021016 104456 TRAP C#ERRHRD
      021020 000074 .WORD 60
      021022 003116 .WORD MDSER
      021024 005312 .WORD ERR4
3830
3831 021026 010102 18: MOV R1,R2 ;COPY STATUS WORD
3832 021030 042702 177700 BIC #177700,R2 ;GET STATE BITS
3833 021034 022702 000034 CMP #34,R2 ;COVER CLSD, HEADS OUT, BRUSHES HOME, SEEK TRACK COUNTING?
3834 021040 001444 BEQ EXIT ;YES, EXIT
3835 021042 022702 000035 CMP #35,R2 ;COVER CLSD, HEADS OUT, BRUSHES HOME, SEEK LINEAR MODE
3836 021046 001441 BEQ EXIT ;YES, EXIT
3837
3838 021050 005264 000012 INC ERRCNT(R4)
3839 021054 ERRHRD 70.,MDSER,ERR4
      021054 104456 TRAP C#ERRHRD
      021056 000106 .WORD 70
      021060 003116 .WORD MDSER
      021062 005312 .WORD ERR4
3840
3841 021064 000432 BR EXIT
3842
3843 .SBTTL WRITE INTERRUPT SERVICE
3844
3845 021066 042764 000001 000056 AWRITE: BIC #SKDON,PRFLGS(R4) ;CLEAR SEEK VERIFY FLAG
3846 021074 016401 000042 MOV BMP(R4),R1 ;GET WORD COUNT
3847 021100 005401 NEG R1 ;MAKE POSITIVE

```

WRITE INTERRUPT SERVICE

```

3848 021102 060164 000006          ADD    R1,WXFR1(R4)      ;ADD THE BITS
3849 021106 022764 023420 000006    CMP    #10000.,WXFR1(R4) ;10(5) YET?
3850 021114 101016                    BHI    EXIT              ;NO - EXIT
3851 021116 005264 000010          INC    WXFR2(R4)        ;YES BUMP 10(10)
3852 021122 162764 023420 000006    SUB    #10000.,WXFR1(R4) ;10(5) GOES TO ZERO
3853 021130 022764 023420 000010    CMP    #10000.,WXFR2(R4) ;10(10) YET?
3854 021136 101005                    BHI    EXIT              ;NO - EXIT
3855 021140 005264 000062          INC    WXFR3(R4)        ;INC 65K (10)(10)
3856 021144 162764 023420 000010    SUB    #10000.,WXFR2(R4) ;MAKE 10(10)
3857
3858 021152 005764 000036          EXIT:  TST    RETRY(R4)   ;IN PROCESS OF RETRYING?
3859 021156 001414                    BEQ    ERREX             ;NO
3860 021160 026427 000052 004353    CMP    RTYPE(R4),#MTDRV
3861 021166 001406                    BEQ    EXIT1
3862 021170 005264 000014          INC    SFTCNT(R4)      ;YES, LOG SOFT ERROR
3863
3864 021174                    ERRSOFT 80.,MSFER,ERR3 ;REPORT SOFT ERROR
      021174 104457          TRAP    C1ERSOFT
      021176 000120          .WORD    80
      021200 003042          .WORD    MSFER
      021202 005162          .WORD    ERR3
3865
3866 021204 005064 000036          EXIT1: CLR    RETRY(R4)   ;CLEAR RETRY
3867
3868                    .SBTTL  EXIT FOR INTERRUPT SERVICE
3869
3870 021210 042774 000100 000104  ERREX: BIC    #INTEN,BDCS(R4)
3871 021216 012600                    MOV    (SP)+,R0
3872 021220 012601                    MOV    (SP)+,R1
3873 021222 012602                    MOV    (SP)+,R2
3874 021224 012603                    MOV    (SP)+,R3
3875 021226 012637 002476          MOV    (SP)+,INCALL
3876 021232 012637 002474          MOV    (SP)+,OPCALL
3877 021236 012637 002246          MOV    (SP)+,WHY
3878 021242 012637 002350          MOV    (SP)+,TEMP1
3879 021246 012637 002340          MOV    (SP)+,HDRFND
3880 021252 012637 002342          MOV    (SP)+,CHKSEC
3881 021256 012637 002432          MOV    (SP)+,E.MP2
3882 021262 012637 002430          MOV    (SP)+,E.MP1
3883 021266 012637 002426          MOV    (SP)+,E.MP
3884 021272 012637 002424          MOV    (SP)+,E.DA
3885 021276 012637 002422          MOV    (SP)+,E.BA
3886 021302 012637 002420          MOV    (SP)+,E.CS
3887 021306 012604                    MOV    (SP)+,R4
3888 021310                    ENDSRV
      021310                    L10027:
      021310                    RTI
3889
3890 021312 004537 022546          FINERR: JSR    R5,RCNT    ;CHECK TO SEE IF WE HAVE EXCEEDED
3891 021316 000405                    BR     1#                ;RETRY LIMIT, IF SO 1# AND REPORT HARD
3892 021320 013764 002420 000116    MOV    E.CS,SOFTCS(R4)
3893 021326 000137 021210          JMP    ERREX             ;NOT EXCEEDED EXIT
3894 021332 005264 000012          1#:   INC    ERRCNT(R4)  ;INDICATE ERROR
3895
3896 021336                    ERRHRD 90.,MHRD,ERR13 ;NON-RECOVERABLE ERROR
      021336 104456          TRAP    C1ERHRD
      021340 000132          .WORD    90

```

EXIT FOR INTERRUPT SERVICE

	021342	003252			.WORD	MHDR	
	021344	005724			.WORD	ERR13	
3897	021346	000716			BR	EXIT1	
3898							
3899					.SBTTL	DRIVE ERROR INTERRUPT SERVICE	
3900							
3901							
3902							
3903	021350	005264	000020		CKDERR: INC	DERCNT(R4)	;ACCOUNT FOR ERROR
3904	021354	004537	024362		JSR	R5,GETDST	;GET DRIVE STATUS
3905							
3906	021360				;REPORT	DRIVE ERROR	
	021360	104456			ERRHRD	224,DRVER,ERR9	;DRIVE ERROR
	021362	000340			TRAP	C\$ERRHRD	
	021364	003061			.WORD	224	
	021366	005602			.WORD	DRVER	
					.WORD	ERR9	
3907							
3908							
3909							
3910	021370	032701	001000		BIT	#VC,R1	;VOLUME CHECK?
3911	021374	001027			BNE	9#	;YES, GO ISSUE RESET
3912	021376	032701	010000		BIT	#SKTO,R1	;SEEK TIME OUT?
3913	021402	001070			BNE	12#	;YES, ISSUE RESET
3914	021404	032701	144000		BIT	#WDE!MCE!SPE,R1	;WRITE DATA, CURRENT HEAD, SPINDLE?
3915	021410	001153			BNE	15#	;GO WAIT FOR HEADS TO UNLOAD
3916	021412	032701	002000		BIT	#WGE,R1	;WRITE GATE ERROR
3917	021416	001003			BNE	20#	;YES, ISSUE RESET
3918	021420	004537	024376		JSR	R5,ISDRST	;ISSUE RESET
3919	021424	000431			BR	10#	;GO CHECK DRIVE READY
3920	021426	004537	024376	20#:	JSR	R5,ISDRST	;ISSUE RESET
3921	021432	004537	024362		JSR	R5,GETDST	;RESET WORK?
3922	021436	032701	002000		BIT	#WGE,R1	;WGE CLEAR
3923	021442	001422			BEQ	10#	;YES GO CHECK DRIVE READY
3924	021444	012737	003157	002246	MOV	#MGEST,WHY	;REPORT WGE DIDN'T CLR
3925	021452	000412			BR	91#	;DROP DRIVE
3926							
3927	021454	004537	024376	9#:	JSR	R5,ISDRST	;ISSUE RESET
3928	021460	004537	024362		JSR	R5,GETDST	;RESET WORK
3929	021464	032701	001000		BIT	#VC,R1	;VOL CHK CLEAR
3930	021470	001407			BEQ	10#	;YES, CHECK DRIVE READY
3931	021472	012737	003132	002246	MOV	#MVCR,WHY	;DROP THE DRIVE
3932							
3933	021500	004537	023450	91#:	JSR	R5,DRDRV	
3934	021504	000137	021204		JMP	EXIT1	
3935	021510	032763	000001	000000	10#:	BIT	#DRDY,CS(R3)
3936	021516	001004			BNE	101#	;DRIVE READY POSTED?
3937							;YES, PRINT RECOVERED
3938	021520	012737	002664	002246	MOV	#DNRDY,WHY	
3939	021526	000764			BR	91#	;NO, DROP DRIVE
3940							
3941	021530			101#:	PRINTB	#FMT14,#MRDR	;PRINT DRIVE RECOVERED
	021530	012746	003212		MOV	#MRDR,-(SP)	
	021534	012746	007463		MOV	#FMT14,-(SP)	
	021540	012746	000002		MOV	#2,-(SP)	
	021544	010600			MOV	SP,R0	
	021546	104414			TRAP	C\$PNTB	
	021550	062706	000006		ADD	#6,SP	

DRIVE ERROR INTERRUPT SERVICE

```

3942 021554 004537 022246      JSR    R5,GHDR      ;GET THE CURRENT DISK POSITION - HEADER
3943 021560 000137 021312      JMP    FINERR
3944 021564 012702 000004      12:   MOV    #4,R2      ;SEEK TIME OUT
3945 021570 004537 024376      13:   JSR    R5,ISDRST  ;ISSUE DRIVE RESET
3946                                     ;FOUR TIMES BEFORE
3947 021574                                     ;DROPPING DRIVE
      021612 012727 000372      WAITMS #15.
      021616 000000      MOV    #250.,(PC)+
      021620 013727 002116      .WORD 0
      021624 000000      MOV    L#DLY,(PC)+
      021626 005367 177772      .WORD 0
      021632 001375      DEC    -6(PC)
      021634 005367 177756      BNE    -.4
      021640 001367      DEC    -22(PC)
      BNE    -.20

3948
3949 021650 032763 000001 000000      BIT    #DRDY,CS(R3)  ;DRIVE READY YET?
3950 021656 001006      BNE    14:          ;YES, CHECK IF ERROR CLEARED
3951 021660 005302      DEC    R2          ;NO, HAVE WE DONE IT FOUR TIMES
3952 021662 001342      BNE    13:          ;YES
3953
3954 021664 012737 003070 002246 141:   MOV    #MDERS,WHY  ;YES, DROP DRIVE
3955 021672 000702      BR     91:
3956
3957 021674 032763 040000 000000 14:   BIT    #DERR,CS(R3) ;DRIVE ERROR SET STILL
3958 021702 001370      BNE    141:        ;YES, DROP DRIVE
3959 021704      PRINTB #FMT14,#MRDER
      021704 012746 003212      MOV    #MRDER,-(SP)
      021710 012746 007463      MOV    #FMT14,-(SP)
      021714 012746 000002      MOV    #2,-(SP)
      021720 010600      MOV    SP,R0
      021722 104414      TRAP  C#PNTB
      021724 062706 000006      ADD    #6,SP
3960 021730 004537 022246      JSR    R5,GHDR
3961 021734 000137 021152      JMP    EXIT
3962
3963 021740 012702 000004      15:   MOV    #4,R2
3964 021744 004537 024362      16:   JSR    R5,GETDST  ;WAIT FOR HEADS TO UNLOAD
3965 021750 032701 000020      BIT    #BIT4,R1    ;GET STATUS
3966 021754 001434      BEQ    17:          ;UNLOAD STATE
3967 021756      WAITMS #15.      ;YES, CONTINUE W/ RECOVERY
      021774 012727 000372      MOV    #250.,(PC)+ ;WAIT A WHILE
      022000 000000      .WORD 0
      022002 013727 002116      MOV    L#DLY,(PC)+
      022006 000000      .WORD 0
      022010 005367 177772      DEC    -6(PC)
      022014 001375      BNE    -.4
      022016 005367 177756      DEC    -22(PC)
      022022 001367      BNE    -.20
3968 022032 005302      DEC    R2          ;WAIT LONG ENOUGH
3969 022034 001343      BNE    16:          ;NO, GO BACK
3970 022036 012737 003547 002246      MOV    #UNLOAD,WHY ;DROP DRIVE
3971 022044 000615      BR     91:
3972
3973 022046 004537 024376      17:   JSR    R5,ISDRST  ;ISSUE RESET
3974 022052      WAITMS #1.
      022070 012727 000372      MOV    #250.,(PC)+
      022074 000000      .WORD 0
    
```



DRIVE ERROR INTERRUPT SERVICE

```

022076 013727 002116      MOV     L#DLY,(PC)+
022102 000000      .WORD  0
022104 005367 177772      DEC     -6(PC)
022110 001375      BNE     .-4
022112 005367 177756      DEC     -22(PC)
022116 001367      BNE     .-20
3975 022126 032763 040000 000000  BIT     #DERR,CS(R3)      ;DRIVE ERROR CLEAR?
3976 022134 001253      BNE     14#              ;NO, DROP DRIVE
3977 022136 012702 000075      MOV     #61.,R2         ;YES, WAIT 60 SECONDS
3978 022142      18# : WAITMS #10.        ;FOR DRIVE READY TO
022160 012727 000372      MOV     #250.,(PC)+
022164 000000      .WORD  0
022166 013727 002116      MOV     L#DLY,(PC)+
022172 000000      .WORD  0
022174 005367 177772      DEC     -6(PC)
022200 001375      BNE     .-4
022202 005367 177756      DEC     -22(PC)
022206 001367      BNE     .-20
3979 022216 032763 000001 000000  BIT     #DRDY,CS(R3)     ;COME BACK
3980 022224 001223      BNE     14#              ;
3981 022226 005302      DEC     R2
3982 022230      BREAK
022230 104422      TRAP   C#BRK            ;INITIATE PROGRAM CALL TO SUPERVISOR
3983 022232 001343      BNE     18#
3984 022234 012737 003573 002246  MOV     #NLOAD,WHY      ;NO READY DROP DRIVE
3985 022242 000137 021500      JMP     91#
3986
3987 022246 012763 000210 000000  GHDR:  MOV     #CRDY!RDHDR,CS(R3)
3988 022254 056463 000106 000000  BIS     DRSEL(R4),CS(R3)
3989 022262 042763 000200 000000  BIC     #200,CS(R3)
3990 022270 004537 024270      JSR     R5,WTDRY
3991 022274 016301 000006      MOV     MP(R3),R1
3992 022300 043701 002272      BIC     SMSK,R1
3993 022304 010164 000124      MOV     R1,PRPOS(R4)
3994 022310 012764 004353 000052  MOV     #MIDRV,RTYPE(R4) ;SETUP DRIVE ERROR
3995 022316 000205      RTS     R5
3996
3997      .SBTTL  BUFFER GENERATION ROUTINE FOR THE 'WRITE' FUNCTION
3998 022320      STARS
3999      ;*****
4000      ;WRBUF -- ROUTINE TO WRITE A BUFFER INTO MEMORY.  USES WORD COUNT AND BUS
4001      ; ADDRESS FROM DRIVE BUFFER (R4).  WILL WRITE RANDOM FROM ONE OF
4002 022320      ; 8 PATTERNS.  USED BY WRITE FUNCTION AND WRPACK ROUTINE.
4003      ;*****
4004 022320 005737 002306  WRBUF:  TST     REGEN          ;REBUILD THE DATA BUFFER?
4005 022324 001507      BEQ     9#              ;NO --EXIT
4006 022326 010346      MOV     R3,-(SP)        ;SAVE REGISTERS
4007 022330 010246      MOV     R2,-(SP)
4008 022332 010146      MOV     R1,-(SP)
4009 022334 010046      MOV     R0,-(SP)
4010 022336 016402 000042  MOV     BMP(R4),R2      ;R2 HAS TOTAL WORDS TO SET UP FOR
4011 022342 005402      NEG     R2              ;POSITIVE NUMBER
4012 022344 017401 000110  MOV     @BBA(R4),R1     ;WHERE BUFFER IS
4013 022350 020227 000200  2# :   CMP     R2,#128.   ;MORE THAN 128 WORDS
4014 022354 002015      BGE     4#              ;YES. BRANCH

```

BUFFER GENERATION ROUTINE FOR THE 'WRITE' FUNCTION

```

4015 022356 020227 000003      CMP      R2,#3      ;GREATER THAN THREE WORDS
4016 022362 002005      BGE      3#        ;YES, BRANCH
4017 022364 062702 000003      ADD      #3,R2     ;ADD 3
4018 022370 162764 000003 000042      SUB      #3,BMP(R4) ;WC UP BY 3
4019 022376 010221      3#:     MOV      R2,(R1)+  ;STORE WC
4020 022400 005302      DEC      R2       ;ACCOUNT FOR WC
4021 022402 010237 002362      MOV      R2,TEMP6 ;LOAD DOWN COUNTER
4022 022406 000405      BR      5#
4023 022410 012737 000177 002362 4#:     MOV      #127.,TEMP6 ;LOAD DOWN COUNTER
4024 022416 012721 000200      MOV      #128.,(R1)+
4025 022422 005737 010654      5#:     TST      T,RAN     ;RANDOM SELECT OF PATTERNS
4026 022426 001003      BNE      55#      ;YEA
4027 022430 013703 010656      MOV      T,PAT,R3 ;NO GET PATTERN OPERATOR
4028 022434 000406      BR      56#      ;WANTS TO USE
4029 022436 004537 024454      55#:    JSR      R5,RAND   ;GET RANDOM # FOR PATTERN
4030 022442 013703 002262      MOV      LONUM,R3 ;GET RANDOM PATTERN
4031 022446 042703 177770      BIC      #177770,R3 ;0,7
4032 022452 006303      56#:    ASL      R3       ;WORD OFFSET
4033 022454 062703 027734      ADD      #PATLST,R3 ;GET PATTERN LIST
4034 022460 011303      MOV      (R3),R3  ;GET LIST ADDRESS
4035 022462 010337 002364      MOV      R3,TEMP7 ;STOR FOR RECALL
4036 022466 010321      MOV      R3,(R1)+ ;LOAD IT
4037 022470 005337 002362      DEC      TEMP6    ;ACCOUNT FOR IT
4038 022474 013703 002364      6#:     MOV      TEMP7,R3 ;PATTERN START
4039 022500 012737 000020 002366 7#:     MOV      #16.,TEMP8 ;16 ENTRIES
4040 022506 012321      7#:     MOV      (R3)+,(R1)+ ;STORE PATTERN
4041 022510 005337 002362      DEC      TEMP6    ;DOWN COUNT
4042 022514 001404      BEQ      8#      ;DONE?
4043 022516 005337 002366      DEC      TEMP8    ;DONE WITH PATTERN
4044 022522 001371      BNE      7#      ;NO, GO BACK
4045 022524 000763      BR      6#      ;RESTART PATTERN
4046 022526 162702 000200      8#:     SUB      #128.,R2 ;ANOTHER SECTOR TO USE
4047 022532 003306      BGT      2#      ;YES GO BACK
4048 022534 012600      MOV      (SP)+,R0 ;RESTORE REGISTERS
4049 022536 012601      MOV      (SP)+,R1
4050 022540 012602      MOV      (SP)+,R2
4051 022542 012603      MOV      (SP)+,R3
4052 022544 000205      9#:     RTS      R5

```

```

4053
4054      .SBTTL  RETRY LIMIT ROUTINE
4055
4056      ;RETRY BUMP, TWO RETURNS - CALL +2 - RETRY EXCEEDED
4057      ;                               CALL +4 - CONTINUE RETRY
4058
4059 022546 026437 000036 010576 RCNT:    CMP      RETRY(R4),LIMIT ;LIMIT REACHED?
4060 022554 001403      BEQ      1#      ;YES TAKE FIRST RETURN
4061 022556 005264 000036      INC      RETRY(R4) ;ACCOUNT FOR RETRY
4062 022562 005725      TST      (R5)+  ;NEXT RETURN
4063 022564 000205      1#:     RTS      R5     ;RETURN
4064
4065      .SBTTL  LIST OF FUNCTION ROUTINES
4066
4067      ;WE GO THRU THIS LIST WHEN CALLED IN "GETFNC"
4068      ;LIST IS IN NUMERICAL ORDER 1-6
4069
4070 022566 000000      LIST:    .WORD 0
4071 022570 015354      SKWRT           ;SEEK - WRITE DATA - WRITE CHECK

```

LIST OF FUNCTION ROUTINES

4072	022572	015410	SKRD	;SEEK - READ DATA
4073	022574	015550	SKRH	;SEEK READ HDR READ W/NO HDR CMP GET STATUS
4074	022576	015354	SKWRT	;SEEK - WRITE DATA WRITE CHECK
4075	022600	015410	SKRD	;SEEK - READ DATA
4076	022602	015434	SKRDRD	;SEEK - READ DATA READ DATA

4077  
4078

4079 022604

.SBTTL BAD SECTOR FILE ROUTINE  
STARS

4080  
4081  
4082  
4083  
4084  
4085  
4086  
4087  
4088  
4089  
4090  
4091  
4092  
4093  
4094  
4095  
4096  
4097  
4098  
4099  
4100  
4101  
4102  
4103  
4104  
4105  
4106  
4107 022604

```

;*****
;RDBDSC -- ROUTINE TO RECOVER BAD SECTOR FILE AND SAVE IT FOR
;COMPARISON UPON ERROR ON READS/WRTES & FOR THE SEEK FUNCTION. WE
;WILL ONLY RESERVE SPACE FOR 16 BAD SECTORS PER DRIVE AND 1 ENTRY FOR
;THE BAD SECTOR FILE AREA POINTER - LAST TRACK ON THE CARTRIDGE.
;WE WILL ISSUE A DRIVE RESET FIRST, READ HEADER, POSITION TO THE LAST
;TRACK (CYLINDER 255. OR 511., SURFACE 1) AND READ IN THE FIRST SECTOR
;FOR FACTORY BAD, AND THE 20TH FOR FIELD BAD SECTORS. R4 WILL CONTAIN
;THE BUFFER POINTER TO THE DRIVE WE WANT TO READ.
;
;CALL JSR R5,RDBDSC ;GET THE BAD SECT FILE ENTRYS
;
;THE BAD SECTOR FILE (BOTH FACTORY AND FIELD) LOOKS LIKE THIS:
;
; SERIAL NUMBER LOW 5 DIGITS (OCTAL SERIAL NUMBER)
; SERIAL NUMBER HIGH 5 DIGITS
;
; 0'S
; 0'S
;
; ENTRY - CYLINDER # FROM 0 TO 1777 MAX (RL02) OR 777 (RL01)
; ENTRY - HEAD & SECTOR NUMBER
;
; ENTRY - CYL
; ENTRY - HEAD & SECTOR
;
; -1 ...END OF ENTRYS
; -1 ...TO WORD 256. (END OF SECOND SECTOR IN PAIR)

```

STARS

4108  
4109 022604 010046  
4110 022606 010146  
4111 022610 010246  
4112 022612 010346  
4113 022614 004537 024376  
4114 022620 012764 000010 000044  
4115 022626 004537 016524  
4116 022632 004537 024270  
4117  
4118 022636 016300 000006  
4119 022642 022764 000001 000120  
4120 022650 001005  
4121 022652 043700 002264  
4122 022656 012701 077600  
4123 022662 000404  
4124 022664 043700 002270  
4125 022670 012701 177600  
4126 022674 160001

```

;*****
RDBDSC: MOV R0,-(SP) ;SAVE REGISTERS
MOV R1,-(SP) ;
MOV R2,-(SP) ;
MOV R3,-(SP) ;
21: JSR R5,ISDRST ;ISSUE A DRIVE RESET
MOV #RDHDR,FUNC (R4);READ HEADER TO FIND POSITION
JSR R5,LDFUNC ;ON DISK
JSR R5,WTRDY ;
;
MOV MP(R3),R0 ;GET HEADER AND CALCULATE
CMP #1,TDR(R4) ;RL02 TYPE DRIVE?
BNE 23: ;JUMP IF RL02
BIC CYLMSK,R0 ;HERE FOR RL01
MOV #77600,R1 ;
BR 25: ;
23: BIC CMSK,R0 ;HERE FOR RL02
MOV #177600,R1 ;
25: SUB R0,R1 ;

```

## BAD SECTOR FILE ROUTINE

```

4127 022676 010164 000040      MOV      R1,BDA(R4)
4128 022702 052764 000025 000040  BIS      #SKHS!SIGN!MK,BDA(R4)
4129 022710 012764 000006 000044  MOV      #SEEK,FUNC(R4)
4130 022716 004537 016524      JSR      R5,LDFUNC      ;SEEK TO THE BAD SECTOR FILE AREA
4131 022722 004537 024270      JSR      R5,WTRDY      ;WAIT FOR DRIVE READY
4132 022726 012764 000010 000044  MOV      #RDHDR,FUNC(R4)
4133 022734 004537 016524      JSR      R5,LDFUNC      ;READ A HEADER ON THE BSF
4134 022740 004537 024270      JSR      R5,WTRDY      ;WAIT FOR DRIVE READY
4135 022744 016300 000006      MOV      MP(R3),R0      ;GET THE HEADER WORD READ
4136 022750 042700 000077      BIC      #77,R0        ;CLEAR SECTOR NUMBER READ
4137 022754 022764 000001 000120  CMP      #1,TDR(R4)    ;DRIVE = RLO1?
4138 022762 001007      BNE      300$          ;NO - MUST BE AN RLO2
4139 022764 022700 077700      CMP      #77700,R0     ;YES - ON BSF AREA?
4140 022770 001311      BNE      21$          ;NO - SEEK AGAIN
4141 022772 012764 077700 000040  MOV      #77700,BDA(R4) ;SAVE THIS HEADER FOR READ COMMAND
4142 023000 000406      BR       555$
4143 023002 022700 177700      300$:  CMP      #177700,R0    ;RLO2 BSF AREA?
4144 023006 001302      BNE      21$          ;NO - SEEK AGAIN
4145 023010 012764 177700 000040  MOV      #177700,BDA(R4) ;YES - SAVE FOR THE READ COMMAND
4146 023016 012764 177400 000042 555$:  MOV      #-256.,BMP(R4) ;SETUP FOR A 2 SECTOR READ IN BSF
4147 023024 012764 000014 000044  MOV      #READ,FUNC(R4) ;GET THE READ FUNCTION #
4148
4149 023032 005037 002354      CLR      TEMP3        ;MANUFACTURING/FIELD FILE SWITCH
4150 023036 012737 003720 002246  MOV      #MWSEC,WHY    ;START WITH MANUFACTURING BAD
4151 023044 016402 000112      MOV      BSECT(R4),R2 ;INITIALIZE LIST TO ALL 1'S
4152 023050 012700 000021      MOV      #17.,R0      ;SIXTEEN ENTRIES + 1 FOR BSF POINTER
4153 023054 012722 177777      11$:  MOV      #-1,(R2).    ;INIT STORAGE TO -1'S
4154 023060 005300      DEC      R0           ;DONE?
4155 023062 001374      BNE      11$          ;NO - DO THE NEXT ONE
4156
4157 023064 016402 000112      MOV      BSECT(R4),R2 ;GET POINTER TO LIST TO STORE BSF ENTRYS
4158 023070 016422 000040      MOV      BDA(R4),(R2). ;SAVE 1ST ENTRY AS BSF POINTER
4159 023074 012700 000020      MOV      #16.,R0      ;SIXTEEN ENTRIES
4160 023100 004537 016524      4$:  JSR      R5,LDFUNC    ;READ THE BSF SECTOR PAIR
4161 023104 004537 024270      JSR      R5,WTRDY     ;WAIT FOR DRIVE READY
4162
4163 023110 005774 000104      TST      BDCS(R4)     ;WAS THE READ GOOD?
4164 023114 100042      BPL      3$           ;YES
4165
4166 023116 004537 024376      JSR      R5,ISDRST    ;NO - ISSUE A DRIVE RESET
4167 023122 062764 000004 000040  ADD      #4,BDA(R4)   ;POINT TO NEXT SECTOR
4168 023130 005737 002354      TST      TEMP3        ;MANUFACTURING OR FIELD BAD
4169 023134 001414      BEQ      5$           ;MANUFACTURING = 0
4170 023136 012737 003740 002246  MOV      #SWSEC,WHY   ;FIELD BAD
4171 023144 022764 000001 000120  CMP      #1,TDR(R4)   ;DRIVE = RLO1?
4172 023152 001011      BNE      400$        ;NO - MUST BE RLO2
4173 023154 022764 077750 000040  CMP      #77750,BDA(R4) ;YES - AT END OF FIELD FILE?
4174 023162 001346      BNE      4$          ;NO - CONTINUE
4175 023164 000516      BR       6$           ;DROP DRIVE AND EXIT
4176
4177 023166 026427 000040 077724 5$:  CMP      BDA(R4),#77724 ;AT END OF MANUFACTURING BAD
4178 023174 000410      BR       55$         ;SEE IF DONE
4179 023176 022764 177750 000040 400$:  CMP      #177750,BDA(R4) ;AT END OF FIELD BAD FOR RLO2
4180 023204 001335      BNE      4$          ;NO GO BACK FOR NEXT
4181 023206 000505      BR       6$          ;DROP THE DRIVE AND EXIT
4182 023210 026427 000040 177724  CMP      BDA(R4),#177724 ;AT END OF MANUFACTURING BAD?
4183 023216 001330      BNE      4$          ;BR IF NOT DONE

```

BAD SECTOR FILE ROUTINE

```

4184 023220 000500          BR      6#          ;YES - REPORT ERROR AND EXIT
4185
4186 023222 017401 000110  3#:    MOV      @BBA(R4),R1      ;START OF BSF ENTRY LIST
4187 023226 012164 000100          MOV      (R1)+,SERNM1(R4)  ;GET LOW PART OF SERIAL #
4188 023232 012164 000102          MOV      (R1)+,SERNM2(R4)  ;GET HIGH PART OF SERIAL #
4189 023236 022121          CMP      (R1)+,(R1)+      ;SKIP PAST JUNK
4190 023240 012137 002350  1#:    MOV      (R1)+,TEMP1      ;GET CYLINDER
4191 023244 100444          BMI      2#          ;END OF THE ENTRYS?
4192 023246 012137 002352          MOV      (R1)+,TEMP2      ;NO - GET HEAD (0 OR 1) & SECTOR NUMBER
4193 023252 000337 002350          SWAB     TEMP1          ;PUT CYLINDER IN HIGH BYTE
4194 023256 000241          CLC
4195 023260 006037 002350          ROR      TEMP1
4196 023264 103003          BCC     111#
4197 023266 052737 100000 002350  111#: BIS      @BIT15,TEMP1
4198 023274 013712 002350          MOV      TEMP1,(R2)      ;STORE THE CYLINDER PART
4199 023300 013737 002352 002350  MOV      TEMP2,TEMP1      ;GET SECTOR
4200 023306 042737 177700 002350  BIC      @177700,TEMP1    ;LEAVE ONLY SECTOR
4201 023314 053712 002350          BIS      TEMP1,(R2)      ;SET IN SECTOR BITS
4202 023320 006237 002352          ASR     TEMP2
4203 023324 006237 002352          ASR     TEMP2          ;POSITION THE HEAD SELECT BIT
4204 023330 042737 177677 002352  BIC      @177677,TEMP2    ;CLEAR ALL OTHER BITS
4205 023336 053722 002352          BIS      TEMP2,(R2)+     ;SET IN HEAD
4206 023342 005300          DEC     R0          ;COUNT THIS ENTRY FROM BSF
4207 023344 001335          BNE     1#          ;ALLOW MORE ENTRYS?
4208 023346 012737 003667 002246  MOV      @MBDMSC,WHY      ;MORE THAN 16 BAD SECTORS
4209 023354 000422          BR      6#          ;DROP THE DRIVE & ERROR EXIT
4210
4211 023356 005737 002354  2#:    TST      TEMP3          ;SWITCH TO FIELD BAD OR QUIT
4212 023362 001021          BNE     7#          ;QUIT, 7#
4213 023364 022764 000001 000120  CMP      @1,TDR(R4)      ;DRIVE = RL01?
4214 023372 001004          BNE     350#         ;NO - MUST BE AN RL02
4215 023374 012764 077724 000040  MOV      @77724,BDA(R4)  ;YES POINT TO FIELD BSF 1ST SECTOR
4216 023402 000403          BR      36#
4217 023404 012764 177724 000040  350#:  MOV      @177724,BDA(R4) ;POINT TO 1ST SECT IN FIELD FILE FOR RL02
4218 023412 012737 000001 002354  36#:  MOV      @1,TEMP3        ;INDICATE NOW DOING FIELD BSF
4219 023420 000627          BR      4#          ;PROCESS THE FIELD BSF
4220
4221          ;HERE TO DROP THE DRIVE IF MORE THAN 16. ENTRYS OR IF CAN'T FIND A BSF
4222
4223 023422 004537 023450  6#:    JSR      R5,DRDRV      ;DROP THE DRIVE
4224
4225          ;HERE TO PUT HEADS 'HOME' AND TO EXIT
4226
4227 023426 004537 025620  7#:    JSR      R5,HOMHOME    ;BRINGS HEADS HOME
4228 023432 012603          MOV      (SP)+,R3
4229 023434 012602          MOV      (SP)+,R2
4230 023436 012601          MOV      (SP)+,R1
4231 023440 012600          MOV      (SP)+,R0
4232 023442 000205          RTS      R5
4233
4234          .SBTTL  ROUTINE TO DROP DRIVE
4235 023444          STARS
;*****
4236          ;DRDRV - ROUTINE TO DROP A DRIVE FROM RUNNING
4237          ; R4 HAS BUFFER POINTER OF DRIVE TO DROP
4238          ; WE CLEAR BIT IN "DRUT", NOT "DRPRS"
4239 023444          STARS

```

ROUTINE 'O DROP DRIVE

```

4240
4241 023444 005237 002474 ODRDRV: INC OPCALL
4242 023450 010146 DRDRV: MOV R1,(SP)
4243 023452 010246 MOV R2,(SP) ;SAVE REGISTERS
4244 023454 010346 MOV R3,(SP)
4245 023456 005237 002476 INC INCALL
4246 023462 005003 CLR R3
4247 023464 012702 030362 MOV @DRBUF,R2 ;START OF DRIVE BUFFERS
4248 023470 012701 000001 MOV @1,R1 ;MASK
4249 023474 020402 18: CMP R4,R2 ;IS THIS THE DRIVE?
4250 023476 001405 BEQ 28 ;YES GO DROP IT
4251 023500 005203 INC R3
4252 023502 006301 ASL R1 ;NO SHIFT MASK
4253 023504 062702 000126 ADD @PRPOS+2,R2 ;NEXT BUFFER
4254 023510 000771 BR 18 ;GO BACK
4255
4256 023512 005737 002474 28: TST OPCALL ;CALLED VIA OPERATOR?
4257 023516 001002 BNE 68 ;YES SKIP CODE
4258 023520 DODU R3 ;NO - CALLED BY DIAGNOSTIC
023520 010300 MOV R3,R0
023522 104451 TRAP C#DODU
4259 023524 005037 002476 68: CLR INCALL
4260 023530 005037 002474 CLR OPCALL
4261 023534 113764 002416 000070 MOVB HOUR,DPHOUR(R4) ;TIME AT WHICH IT WAS DROPPED
4262 023542 113764 002414 000071 MOVB MINUTE,DPMIN(R4) ;HOUR/MINUTE
4263 023550 001002 BNE 38 ;IF MINUTE 0,
4264 023552 105264 000071 INCB DPMIN(R4) ;MAKE 1.
4265 023556 140137 002252 38: BICB R1,DRUT ;CLEAR THE DRIVE FROM BIT MAP
4266 023562 PRINTF @FMT14C ;PRINT A <CR> & <LF>
023562 012746 007501 MOV @FMT14C,-(SP)
023566 012746 000001 MOV @1,-(SP)
023572 010600 MOV SP,R0
023574 104417 TRAP C#PNTF
023576 062706 000004 ADD @4,SP
4267 023602 004737 006200 JSR PC,LINE2
4268 023606 PRINTF @FMT7,@DROP,WHY
023606 013746 002246 MOV WHY,-(SP)
023612 012746 004276 MOV @DROP,-(SP)
023616 012746 007141 MOV @FMT7,-(SP)
023622 012746 000003 MOV @3,-(SP)
023626 010600 MOV SP,R0
023630 104417 TRAP C#PNTF
023632 062706 000010 ADD @10,SP
4269 023636 PRINTF @FMTS1
023636 012746 007732 MOV @FMTS1,-(SP)
023642 012746 000001 MOV @1,-(SP)
023646 010600 MOV SP,R0
023650 104417 TRAP C#PNTF
023652 062706 000004 ADD @4,SP
4270
4271 023656 004737 013772 JSR PC,REPORT
4272
4273 023662 012603 MOV (SP),R3
4274 023664 012602 MOV (SP),R2 ;RESTORE REGISTERS
4275 023666 012601 MOV (SP),R1
4276

```

ROUTINE TO DROP DRIVE

```

4277 023670 000205          RTS      R5
4278
4279          .SBTTL  ROUTINE TO CHECK DATA
4280          ;ROUTINE TO CHECK DATA ON READ
4281
4282
4283 023672 005037 002306    CKDATA: CLR      REGEN          ;CLEAR THE REGENERATE DATA FLAG
4284 023676 005737 010612    TST      CMRD           ;DO WE WANT TO CHECK ANY?
4285 023702 001001          BNE      101           ;YES - SEE IF FORCED EXIT
4286 023704 000205          RTS      R5           ;NO - EXIT NOW
4287 023706 005737 002310    101:   TST      KILLDC        ;INHIBIT FLAG SET?
4288 023712 001401          BEQ      971           ;NOPE OK TO PROCEED
4289 023714 000205          RTS      R5           ;NO, EXIT
4290
4291          ;971:   SETPRI   #340                      ;JSD REV A
4292 023716 000300          971:   SETPRI   #300                      ;JSD REV A
4293 023724 017402 000110    MOV      #300,R0
4294 023730 016437 000042 002350  TRAP    C:SPRI
4295 023736 005437 002350    MOV      @BBA(R4),R2    ;BUFFER START
4296 023742 013737 010614 002352  MOV      BMP(R4),TEMP1  ;WORDS READ IN
4297 023750 005037 002344    NEG      TEMP1          ;MAKE POSITIVE
4298 023754 013737 010612 002354  MOV      DELMT,TEMP2    ;# ERRORS TO BE PRINTED
4299 023762 012737 000176 002346  CLR      DECNT          ;INIT ERROR COUNT
4300 023770 012201          MOV      CMRD,TEMP3     ;# WORDS TO BE COMPARED
4301 023772 005337 002350    961:   MOV      #126.,TEMP0  ;126 WORDS
4302 023776 001522          MOV      (R2)+,R1      ;NON-ZERO WORDS
4303 024000 005301          DEC      TEMP1
4304 024002 012237 002356    BEQ      CEND
4305          DEC      R1
4306          MOV      (R2)+,TEMP4    ;PATTERN ADDRESS
4307          ;MAKE SURE PATTERN ADDRESS IS LEGAL
4308 024006 012700 027734    MOV      @PATLST,R0    ;GET LIST OF PATTERNS
4309 024012 012703 000010    MOV      #8.,R3       ;ONLY EIGHT
4310 024016 022037 002356    981:   CMP      (R0)+,TEMP4   ;FOUND IT YET
4311 024022 001414          BEQ      991           ;YES, CONTINUE
4312 024024 005303          DEC      R3           ;NO, EXHAUST LIST YET
4313 024026 001373          BNE      981          ;NO, GO BACK
4314
4315 024030 005237 002306    INC      REGEN          ;SET THE DATA REGENERATE FLAG
4316 024034 024242          CMP      -(R2),-(R2)
4317 024036 104456          ERRHRD  180.,NOREV,ERR12
4318 024046 004537 026736    TRAP    C:ERRHRD
4319 024052 000205          .WORD   180
4320          .WORD   NOREV
4321 024054 005301          .WORD   ERR12
4322 024056 013703 002356    JSR     R5,STDMP
4323 024062 005337 002350    RTS     R5
4324 024066 012737 000020 002360  991:   DEC      R1           ;ACCOUNT FOR PATTERN ADDRESS
4325 024074 005737 002350    MOV     TEMP4,R3       ;GET ADDRESS
4326 024100 001461          DEC     TEMP1         ;ACCOUNT ONCE AGAIN
4327 024102 005737 002354    MOV     #16.,TEMP5    ;16 ENTRIES TO PATTERN
4328          11:   TST     TEMP1         ;ANY WORDS READIN LEFT?
4329          BEQ     CEND     ;NO, GO TO END
4330          TST     TEMP3         ;HAVE WE EXHAUSTED COMPARE LIMIT?

```

ROUTINE TO CHECK DATA

```

4328 024106 001456      BEQ      CEND      ;YES GO TO END
4329 024110 005701      TST      R1        ;WE CHECKING PATTERN OR ZERO FILL?
4330 024112 001416      BEQ      30        ;ZERO FILL SKIP
4331 024114 005301      DEC      R1        ;PATTERN
4332 024116 005737 002360 TST      TEMP5     ;WITHIN PATTERN
4333 024122 001005      BNE      20        ;YES SKIP
4334 024124 013703 002356 MOV      TEMP4,R3  ;NO, START OVER
4335 024130 012737 000020 002360 MOV      @16.,TEMP5 ;16 ENTRIES
4336 024136 012337 002402 20:      MOV      (R3),GDDAT ;GET PATTERN
4337 024142 005337 002360 DEC      TEMP5     ;DOWN COUNT
4338 024146 000402      BR       40
4339 024150 005037 002402 30:      CLR      GDDAT     ;ZERO FILL
4340 024154 023712 002402 40:      CMP      GDDAT,(R2) ;CORRECT DATA
4341 024160 001417      BEQ      50        ;YES YES NEXT
4342 024162 005237 002306 INC      REGEN     ;NO - SET REGENERATE FLAG FOR WRT OPERATION
4343 024166 005237 002344 INC      DECNT     ;COUNT THE DATA ERROR
4344 024172 005264 000074 INC      DATCER(R4) ;COUNT ERROR FOR THIS DRIVE
4345 024176 005737 002352 TST      TEMP2     ;DO WE WANT TO PRINT IT
4346 024202 001406      BEQ      50        ;NO,SKIP
4347
4348 024204      ERRHRD 185.,MDCER,ERR8
      024204 104456      TRAP    C1ERRHRD
      024206 000271      .WORD  185
      024210 003235      .WORD  MDCER
      024212 005462      .WORD  ERR8
4349 024214 005337 002352 DEC      TEMP2     ;ACCOUNT FOR PRINT
4350
4351 024220 005337 002350 50:      DEC      TEMP1     ;WORDS READ IN
4352 024224 001407      BEQ      CEND     ;NEXT WORD
4353 024226 005722      TST      (R2).
4354 024230 005337 002346 DEC      TEMP0     ;NEXT WORD
4355 024234 001652      BEQ      960
4356 024236 005337 002354 DEC      TEMP3     ;WORDS TO CHECK
4357 024242 000714      BR       10
4358
4359 024244 005737 002344 CEND:   TST      DECNT     ;DO WE WANT TO PRINT SUMMARY
4360 024250 001406      BEQ      10        ;NO,EXIT
4361 024252 005464 000042 NEG      BMP(R4)   ;MAKE POSITIVE WORD COUNT
4362 024256      ERRHRD 190.,MDCER,ERR6 ;DATA ERROR SUMMARY
      024256 104456      TRAP    C1ERRHRD
      024260 000276      .WORD  190
      024262 003235      .WORD  MDCER
      024264 005364      .WORD  ERR6
4363
4364 024266 000205      10:      RTS      R5
4365
4366      .SBTTL  ROUTINE TO WAIT FOR CONTROLLER READY
4367
4368      ;
4369      ;ROUTINE TO WAIT FOR CONTROLLER READY UNDER FLAG
4370      ;MODE. USED IN INITIALIZE PORTION OF PROGRAM, I.E..
4371      ;GETTING BAD SECTOR FILE, WRITING PACK INITIALLY.
4372
4373 024270 010046      WTRDY:  MOV      R0,-(SP) ;SAVE REGISTERS
4374 024272 010146      MOV      R1,-(SP)
4375 024274 012701 001750 MOV      @1000.,R1 ;WAIT A WHILE
4376      10:      WAITUS  @2.

```



ROUTINE TO WAIT FOR CONTROLLER READY

JSD REV A

```

4377 024300      13:  WAITUS  2.
      024300 012727 000002      MOV    #2.,(PC).
      024304 000000      .WORD  0
      024306 013727 002116      MOV    L#DLY,(PC).
      024312 000000      .WORD  0
      024314 005367 177772      DEC    6(PC)
      024320 001375      BNE    .-4
      024322 005367 177756      DEC    -22(PC)
      024326 001367      BNE    .-20
4378 024330 032774 000200 000104  BIT    #CRDY,#DCS(R4) ;READY SET?
4379 024336 001006      BNE    2#           ;YES, EXIT
4380 024340 005301      DEC    R1           ;TIMED OUT?
4381 024342 001356      BNE    1#           ;NO GO BACK
4382
4383 024344      ERRDF  1002.,NOCRDY,ERR12
      024344 104455      TRAP  C#ERDF
      024346 001752      .WORD 1002
      024350 002654      .WORD NOCRDY
      024352 005716      .WORD ERR12
4384
4385 024354 012601      2#:  MOV    (SP)+,R1      ;RESTORE REGISTERS
4386 024356 012600      MOV    (SP)+,R0
4387 024360 000205      RTS    R5
4388
4389      .SBTTL  GET STATUS/DRIVE RESET ROUTINE
4390
4391      ;ROUTINE TO ISSUE DRIVE RESET
4392      ;ALSO GET STATUS, R1 HAS STATUS IF GS
4393      ;USES R3, DOES NOT SAVE IT
4394
4395 024362 016403 000104  GETDST: MOV    DCS(R4),R3
4396 024366 012763 000003 000004  MOV    #GSBIT,DA(R3)
4397 024374 000405      BR     CSTUFF
4398 024376 016403 000104  ISDRST: MOV    DCS(R4),R3
4399 024402 012763 000017 000004  MOV    #DRST,DA(R3)
4400 024410 012763 000204 000000  CSTUFF: MOV    #CRDY!GSTAT,CS(R3)
4401 024416 056463 000106 000000  BIS    DRSEL(R4),CS(R3)
4402 024424 042763 000200 000000  BIC    #CRDY,CS(R3)
4403 024432 004537 024270      JSR    R5,WTRDY
4404 024436 022763 000013 000004  CMP    #DRST,DA(R3)
4405 024444 001402      BEQ    1#
4406 024446 016301 000006      MOV    MP(R3),R1
4407 024452 000205      1#:  RTS    R5
4408
4409 024454      STARS
      ;*****
4410      ;RAND -- ROUTINE TO GENERATE A RANDOM NUMBER
4411 024454      STARS
      ;*****
4412
4413 024454 010146      RAND:  MOV    R1,-(SP)
4414 024456 010246      MOV    R2,-(SP)
4415 024460 010346      MOV    R3,-(SP)
4416
4417 024462 013703 002262      MOV    LONUM,R3
4418 024466 013701 002260      MOV    HINUM,R1
4419 024472 012702 177771      MOV    #-7,R2

```

GET STATUS/DRIVE RESET ROUTINE

```

4420 024476 006303
4421 024500 006101
4422 024502 005202
4423 024504 001374
4424 024506 063703 002262
4425 024512 005501
4426 024514 063701 002260
4427 024520 062703 001057
4428 024524 005501
4429 024526 062701 047401
4430 024532 010337 002260
4431 024536 010137 002262
4432 024542 012603
4433 024544 012602
4434 024546 012601
4435 024550 000205
4436
4437
4438 024552
4439
4440
4441
4442
4443
4444
4445
4446
4447
4448
4449 024552
4450
4451 024552 010046
4452 024554 010146
4453 024556 010246
4454 024560 010346
4455 024562 016446 000110
4456 024566 005764 000122
4457 024572 001016
4458 024574
      024574 012746 004400
      024600 012746 007666
      024604 012746 000002
      024610 010600
      024612 104417
      024614 062706 000006
4459 024620 000240
4460 024622 000240
4461 024624 004737 006200
4462 024630 004537 025620
4463
4464
4465
4466
4467
4468
    
```

```

1$: ASL R3
    ROL R1
    INC R2
    BNE 1$
    ADD LONUM,R3
    ADC R1
    ADD HINUM,R1
    ADD #1057,R3
    ADC R1
    ADD #47401,R1
    MOV R3,HINUM
    MOV R1,LONUM
    MOV (SP)+,R3
    MOV (SP)+,R2
    MOV (SP)+,R1
    RTS R5

.SBTTL ROUTINE TO WRITE PACKS INITIALLY
STARS
;*****
;WRPACK -- ROUTINE TO WRITE PACK WITH PATTERN, ALL TRACKS WILL BE
; WRITTEN (EXCEPT BAD SECTOR TRACK)
; FORMAT IS # OF WORDS (WORD 1), PATTERN ADDRESS (WORD 2)
; PATTERN (WORDS 3 - 128)
; WE WILL ATTEMPT TO WRITE MULTIPLE SECTORS AT A TIME
; (MINIMUM 10 SECTORS) IF AN ERROR OCCURS WE WILL THEN
; WRITE INDIVIDUAL SECTORS FOR THAT TRACK. WE DO WRITES,
; READS AND INCORE COMPARISONS TO VERIFY.
;
; CALL: JSR R5,WRPACK ;WRITE THE PACK SELECTED
STARS
;*****
WRPACK: MOV R0,-(SP) ;SAVE REGISTERS
        MOV R1,-(SP)
        MOV R2,-(SP)
        MOV R3,-(SP)
        MOV BBA(R4),-(SP)
        TST WRIPG(R4) ;SEE IF WRITE IN PROGRESS
        BNE 1$ ;JUMP IF DON'T WANT MESSAGE ON RECOVERY
        PRINTF #FMT18,#MSWRPK ;MSG. "WRITING PACK"
        MOV #MSWRPK,-(SP)
        MOV #FMT18,-(SP)
        MOV #2,-(SP)
        MOV SP,R0
        TRAP C#PNTF
        ADD #6,SP
        NOP
        NOP
        JSR PC,LINE2 ;PRINT TIME-RCLS & DRIVE ID
1$: JSR R5,HDHOME ;HEADS HOME

;
;NOW ACTUALLY WRITE DATA OUT ON PACK, WILL NOT WRITE LAST
;TRACK
;
    
```

ROUTINE TO WRITE PACKS INITIALLY

```

4469 024634 005037 002350          CLR      TEMP1          ;TEMP1=HEAD
4470 024640 005001                   CLR      R1             ;R1=CYL
4471 024642 022764 000001 000120 CONWR: CMP      #1,TDR(R4)
4472 024650 001007                   BNE     454
4473 024652 022701 077600          CMP      #077600,R1
4474 024656 001023                   BNE     STWRT
4475 024660 005737 002350          TST     TEMP1
4476 024664 001420                   BEQ     STWRT
4477 024666 000406                   BR      ENDWR
4478 024670 022701 177600          451:   CMP      #177600,R1
4479 024674 001014                   JE      STWRT          ;NO GO WRITE TRACK
4480 024676 005737 002350          TST     TEMP1          ;YES, CHECK IF HEAD = 1?
4481 024702 001411                   BEQ     STWRT          ;HEAD = 0 GO WRITE
4482 024704 004537 025620          ENDWR: JSR     R5,HOMOME ;HEADS HOME
4483 024710 012664 000110          MOV     (SP)+,BBA(R4)
4484 024714 012603                   MOV     (SP)+,R3
4485 024716 012602                   MOV     (SP)+,R2
4486 024720 012601                   MOV     (SP)+,R1
4487 024722 012600                   MOV     (SP)+,R0
4488 024724 000205                   RTS      R5             ;END EXIT
4489
4490
4491
4492
4493 024726 005002                   STWRT: CLR      R2             ;INITIAL SECTOR 0
4494 024730 012764 002436 000110   MOV     #BUF1,BBA(R4) ;BUFFER START
4495 024736 012764 175400 000042   MOV     #-1280.,BMP(R4) ;10 SECTORS
4496 024744 005237 002306                   INC     REGEN          ;SET THE GENERATE BUFFER FLAG
4497 024750 004537 022320                   JSR     R5,WRBUF       ;WRITE BUFFER INTO MEMORY
4498 024754 010164 000040 2014:   MOV     R1,BDA(R4)     ;SET UP SECTOR
4499 024760 053764 002350 000040   BIS     TEMP1,BDA(R4)
4500 024766 005764 000122                   TST     WRIPG(R4)     ;WRITE IN PROGRESS?
4501 024772 001406                   BEQ     7624           ;NO - JUMP OVER
4502 024774 026464 000124 000040   CMP     PRPOS(R4),BDA(R4) ;YUP - ON CYLINDER NOW?
4503 025002 001402                   BEQ     7624           ;YUP - WRITE THIS AREA
4504 025004 000137 025414                   JMP     9524           ;NO - LOOK AT NEXT AREA ON DRIVE
4505 025010 050264 000040 7624:   BIS     R2,BDA(R4)
4506 025014 012764 002436 000110   MOV     #BUF1,BBA(R4) ;SET UP TO WRITE
4507 025022 012764 000012 000044   MOV     #WRITE,FUNC(R4) ;WRITE
4508 025030 004537 016524                   JSR     R5,LDFUNC
4509 025034 004537 024270                   JSR     R5,WTRDY       ;WAIT FOR READY
4510 025040 005774 000104                   TST     BDCS(R4)     ;ERROR
4511 025044 100003                   BPL     2034
4512 025046 004537 024376 2054:   JSR     R5,ISDRST
4513 025052 000421                   BR      24
4514
4515 025054 012764 000002 000044 2034:   MOV     #WRCHK,FUNC(R4)
4516 025062 004537 016524                   JSR     R5,LDFUNC
4517 025066 004537 024270                   JSR     R5,WTRDY
4518 025072 005774 000104                   TST     BDCS(R4)     ;ERROR
4519 025076 100763                   BMI     2054           ;YES GO DO SECTORS INDIVIDUALLY
4520
4521 025100 062702 000012                   ADD     #10.,R2
4522 025104 022702 000050                   CMP     #40.,R2
4523 025110 001321                   BNE     2014           ;NO, GO BACK
4524 025112 000137 025414                   JMP     9524           ;YES NEXT TRACK
4525

```

## ROUTINE TO WRITE PACKS INITIALLY

```

4526                                     ;IF AN ERROR OCCURS THEN WE COME HERE AND DO THE TRACK SECTOR
4527                                     ;BY SECTOR.
4528
4529 025116 005002 28: CLR R2 ;R2 = SECTOR
4530
4531 025120 012764 177600 000042          MOV #128.,BMP(R4) ;LOAD WORD COUNT
4532 025126 010164 000040 38: MOV R1,BDA(R4) ;SETUP DISK ADDRESS
4533 025132 053764 002350 000040      BIS TEMP1,BDA(R4)
4534 025140 050264 000040      BIS R2,BDA(R4)
4535
4536 025144 012764 002436 000110          MOV #BUF1,BBA(R4)
4537 025152 004537 022320          JSR R5,WRBUF ;WRITE A BUFFER
4538 025156 005037 002244 918: CLR RWCNT ;CLEAR RETRYS OUT
4539 025162 005037 002344 988: CLR DECNT ;
4540 025166 012764 000012 000044 968: MOV #WRITE,FUNC(R4) ;WRITE FUNCTION
4541 025174 004537 016524          JSR R5,LDFUNC
4542 025200 004537 024270          JSR R5,WTRDY ;WAIT FOR WRITE TO FINISH
4543
4544 025204 005774 000104          TST BDCS(R4) ;ERROR ON WRITE?
4545 025210 100021 858: BPL 858 ;NO, GO READ
4546
4547 025212 016437 000040 002342          MOV BDA(R4),CHKSEC ;YES, CHECK IF SECTOR IS IN
4548 025220 004537 027146          JSR R5,CKBDSC ;BAD SECTOR FILE
4549 025224 005737 002340          TST HDRFND ;IF SET, IT WAS
4550 025230 001050 8028: BNE 8028 ;YES GO TO NEXT SECTOR
4551
4552 025232 005237 002344          INC DECNT ;NO, GIVE IT 3 TRYS TOTAL
4553 025236 023727 002344 000003          CMP DECNT,#3. ;IT MAY HAVE BEEN NOISE.
4554 025244 001440 8018: BEQ 8018 ;BR IF AT RETRY LIMIT - BAD SECTOR
4555 025246 004537 024376          JSR R5,ISDRST ;RESET THE DRIVE & TRY AGAIN
4556 025252 000745 968: BR 968 ;TRY RECOVERY AGAIN
4557
4558 025254 005037 002242 858: CLR RECNT ;CLEAR RETRY COUNT
4559 025260 012764 000002 000044 808: MOV #WRCHK,FUNC(R4) ;READ/VERIFY THE 1 SECTOR WRITTEN
4560 025266 004537 016524          JSR R5,LDFUNC ;ISSUE A WRITE-CHECK FUNCTION
4561 025272 004537 024270          JSR R5,WTRDY ;WAIT FOR DRIVE READY
4562
4563 025276 005774 000104          TST BDCS(R4) ;ERROR ON READ?
4564 025302 100025 958: BPL 958 ;BR IF OK ... GET THE NEXT SECTOR
4565
4566 025304 016437 000040 002342          MOV BDA(R4),CHKSEC ;CHECK IF SECTOR IS
4567 025312 004537 027146          JSR R5,CKBDSC ;A KNOWN BAD SECTOR
4568 025316 005737 002340          TST HDRFND ;IT WAS THEN
4569 025322 001013 8028: BNE 8028 ;GO TO NEXT SECTOR
4570
4571 025324 005237 002242          INC RECNT ;GIVE IT ANOTHER CHANCE
4572 025330 023727 002242 000020          CMP RECNT,#16. ;16 RE-READS BEFORE HARD ERROR
4573 025336 001403 8018: BEQ 8018 ;REPORT ERROR IF AT RETRY LIMIT
4574 025340 004537 024376          JSR R5,ISDRST ;RESET THE DRIVE
4575 025344 000745 808: BR 808 ;AND RETRY AGAIN
4576
4577 025346 004537 025500 8018: JSR R5,INBAD ;REPORT THE BAD SECTOR
4578 025352 004537 024376 8028: JSR R5,ISDRST ;RESET THE DRIVE FOR THE NEXT OPERATION
4579
4580 025356 062702 000012 958: ADD #10.,R2 ;NEXT SECTOR (OFFSET BY 10)
4581 025362 020227 000047          CMP R2,#39. ;DONE WITH TRACK?
4582 025366 003002 9518: BGT 9518 ;YES NEXT TRACK

```

ROUTINE TO WRITE PACKS INITIALLY

```

4583 025370 000137 025126          JMP      3#          ;NO GO BACK FOR NEXT SECTOR
4584 025374          951# :          INC      R2          ;NEXT SECTOR
4585 025374 005202          SUB      #40.,R2    ;DONE WITH TRACK?
4586 025376 162702 000050          CMP      R2,#10.   ;
4587 025402 020227 000012          BEQ     952#       ;YES
4588 025406 001402          JMP     3#         ;NO
4589 025410 000137 025126          952# :
4590 025414
4591
4592 025414 005737 002350          TST     TEMP1      ;WHICH SURFACE?
4593 025420 001420          BEQ     5#         ;TOP (0), BRANCH
4594
4595 025422 005037 002350          CLR     TEMP1      ;BOTTOM, SWITCH TO TOP WITH
4596 025426 062701 000200          ADD     #200,R1
4597 025432 012764 000205 000040          MOV     #205,BDA(R4) ;SEEK, GO IN ALSO
4598 025440 012764 000006 000044 4# :          MOV     #SEEK,FUNC(R4) ;GO SEEK
4599 025446 004537 016524          JSR     R5,LDFUNC
4600 025452 004537 024270          JSR     R5,WTRDY
4601
4602 025456 000137 024642          JMP     CONWR
4603
4604 025462 012737 000100 002350 5# :          MOV     #HEAD,TEMP1 ;WAS TOP, MAKE BOTTOM.
4605 025470 012764 000021 000040          MOV     #21,BDA(R4)
4606 025476 000760          BR     4#
4607
4608 025500 010146          INBAD: MOV     R1,-(SP)    ;SAVE R1
4609 025502 016403 000104          MOV     DCS(R4),R3 ;GET THE CSR ADDRESS
4610 025506 016337 000000 002420          MOV     CS(R3),E.CS ;GET THE ERROR INFO FROM CSR
4611 025514 016337 000002 002422          MOV     BA(R3),E.BA
4612 025522 016337 000004 002424          MOV     DA(R3),E.DA
4613 025530 000240          NOP
4614 025532 000240          NOP
4615 025534 004537 024362          JSR     R5,GETDST  ;GET THE CURRENT DRIVE STATUS
4616 025540 010137 002426          MOV     R1,E.MP   ;SAVE IT AS "(RLMP)" DATA
4617 025544          ERRHRD 199.,NMRTS,ERR12
      025544 104456          TRAP   C#ERRRD
      025546 000307          .WORD 199
      025550 002736          .WORD NMRTS
      025552 005716          .WORD ERR12
4618 025554 005264 000012          INC     ERRCNT(R4)
4619 025560 005737 010640          TST     T.DRP     ;ARE WE COUNTING ERRORS
4620 025564 001413          BEQ     2#        ;NO
4621 025566 026437 000012 010600          CMP     ERRCNT(R4),ERLMT ;PAST IT
4622 025574 103407          BLO    2#        ;NO
4623 025576 012737 003322 002246          MOV     #ERLMTM,WHY
4624 025604 004537 023450          JSR     R5,DRDRV
4625 025610 012705 024704          MOV     #ENDWR,R5
4626
4627 025614 012601 2# :          MOV     (SP)+,R1  ;RESET R1
4628 025616 000205          RTS     R5
4629
4630
4631 025620          .SBTTL HEADS HOME ROUTINE
          STARS
          ;*****
          ;HDHOME -- ROUTINE TO BRING HEADS OVER TRACK 0
          STARS
          ;*****

```

HEADS HOME ROUTINE

```

4634
4635 025620 010046
4636 025622 012764 000010 000044
4637 025630 004537 016524
4638 025634 004537 024270
4639
4640 025640 016300 000006
4641 025644 042700 000177
4642 025650 010064 000050
4643 025654 010064 000040
4644 025660 052764 000001 000040
4645 025666 012764 000006 000044
4646 025674 004537 016524
4647 025700 004537 024270
4648 025704 005064 000124
4649 025710 012600
4650 025712 000205
4651
4652
4653 025714
4654
4655
4656
4657
4658
4659
4660
4661 025714
4662
4663 025714 023737 010632 010634
4664 025722 001003
4665 025724 013702 010632
4666 025730 000421
4667 025732 004537 024454
4668 025736 013702 002262
4669 025742 042702 177700
4670 025746 023702 010632
4671 025752 103003
4672 025754 006202
4673 025756 005202
4674 025760 000770
4675 025762 020237 010634
4676 025766 103002
4677 025770 006102
4678 025772 000763
4679
4680
4681
4682 025774 005737 010664
4683 026000 001003
4684 026002 013737 002442 010620
4685 026010 023737 002442 010620
4686 026016 103021
4687
4688 026020

```

```

HDHOME: MOV R0, (SP) ;SAVE R0
MOV #RDHDR, FUNC(R4) ;READ HEADER
JSR R5, LDFUNC ;GO DO IT.
JSR R5, WTRDY

MOV MP(R3), R0 ;GET HEADER
BIC #177, R0 ;ONLY CYLINDER
MOV R0, LSTHDR(R4) ;SAVE THIS CYL # AS THE LAST POSITION
MOV R0, BDA(R4) ;MOVE IT TO BUFFERED DA
BIS #MK, BDA(R4) ;SET MARKER FOR SEEK TO 000
MOV #SEEK, FUNC(R4) ;LOAD SEEK
JSR R5, LDFUNC ;SEEK!
JSR R5, WTRDY ;WAIT.
CLR PRPOS(R4) ;SET BUFFER TO HOME CYLINDER (000)
MOV (SP)+, R0
RTS R5

.SBTTL RANDOM WC AND DA ROUTINE
STARS
;*****
;GWGDA -- ROUTINE TO GET RANDOM SECTOR AND WORD COUNT FOR R/W TRANSFER.
; SECTOR IS CHOSEN BETWEEN MIN/MAX LIMITS, WORD COUNT IS BETWEEN
; MIN/MAX WORD COUNT. WORD COUNT WILL BE ADJUSTED NOT TO CAUSE
; TRACK OVERFLOW IF HIGH SECTORS ARE CHOSEN....
; R4 HAS BUFFER OF DRIVE WE'RE WORKING WITH
; ON EXIT - BMP(R4) HAS WORD COUNT
; - BDA(R4) HAS DISK ADDRESS
STARS
;*****

GWGDA: CMP T.MXS, T.MNS ;MIN MAX SECTORS EQUAL
BNE 99# ;NO, CALCULATE ONE
MOV T.MXS, R2 ;LOAD SECTOR
BR 5# ;GO GET WC
99#: JSR R5, RAND ;GET RANDOM # FOR SECTOR
MOV LONUM, R2
1#: BIC #177700, R2 ;0-77 ONLY
CMP T.MXS, R2 ;R2 LOWER THAN MAX
BHS 3# ;BRANCH IF YES
ASR R2 ;HALF IT
INC R2 ;INC SO NOT 0
BR 1#
3#: CMP R2, T.MNS ;MIN OKAY
BHS 5#
ROL R2
BR 1#

;NOW GET WORD COUNT
5#: TST T.STIP ;RESTRICT THE XFER SIZE?
BNE 95# ;BR IF YES
MOV MAXWC, T.MXB ;NO - MAKE MAXWC = BIGGEST XFER SIZE AVAIL.
95#: CMP MAXWC, T.MXB
BHS 97#
PRINTF #FMT13D, #OVER, T.MXB, MAXWC

```

RANDOM WC AND DA ROUTINE

```

026020 013746 002442      MOV     MAXWC, (SP)
026024 013746 010620      MOV     T.MXB, (SP)
026030 012746 003453      MOV     #OVER, -(SP)
026034 012746 007436      MOV     #FMT13D, -(SP)
026040 012746 000004      MOV     #4, -(SP)
026044 010600      MOV     SP, R0
026046 104417      TRAP   C#PNTF
026050 062706 000012      ADD     #12, SP
4689 026054 013737 002442 010620      MOV     MAXWC, T.MXB
4690
4691 026062 023737 010620 010642 97$:    CMP     T.MXB, T.MNB      ;MIN MAX EQUAL
4692 026070 003006      BGT     6$
4693 026072 013737 010620 010642      MOV     T.MXB, T.MNB
4694
4695 026100 013703 010620      MOV     T.MXB, R3      ;YES SET WC
4696 026104 000421      BR     9$
4697 026106 004537 024454 6$:    JSR     R5, RAND      ;GET RANDOM WORD COUNT
4698 026112 013703 002262      MOV     LONUM, R3
4699 026116 042703 160000 7$:    BIC     #160000, R3      ;MAX!!!!
4700 026122 023703 010620      CMP     T.MXB, R3
4701 026126 103003      BHIS   8$
4702 026130 006203      ASR     R3
4703 026132 005203      INC     R3
4704 026134 000770      BR     7$
4705 026136 020337 010642 8$:    CMP     R3, T.MNB
4706 026142 103002      BHIS   9$
4707 026144 006103      ROL     R3
4708 026146 000763      BR     7$
4709
4710      ;NOW WE HAVE SECTOR AND WORD COUNT. CHECK THAT WORD COUNT WILL FIT ON SECTOR
4711      ;IF NOT LOWER SECTOR START
4712
4713 026150 012701 000050 9$:    MOV     #40., R1      ;SETUP FOR FOURTY SECTORS
4714 026154 005403      NEG     R3      ;MAKE WORD COUNT NEGATIVE
4715 026156 010364 000042      MOV     R3, BNP(R4)   ;LOAD WORD COUNT
4716 026162 005301 11$:    DEC     R1      ;DOWN COUNT MINIMUM START SECT NEEDED
4717 026164 062703 000200      ADD     #128., R3     ;ONE SECTOR'S WORTH
4718 026170 100774      BMI    11$      ;STILL NEED ANOTHER SECTOR
4719 026172 020201      CMP     R2, R1      ;DID RANDOM SECTOR SUFFICE
4720 026174 101401      BLOS   12$      ;BRANCH IF SUFFICED
4721 026176 010102      MOV     R1, R2      ;NO, THEN MAKE IT FIT
4722 026200 016464 000124 000040 12$:    MOV     PRPOS(R4), BDA(R4)
4723 026206 042764 000077 000040      BIC     #77, BDA(R4)
4724 026214 050264 000040      BIS     R2, BDA(R4)
4725 026220 000205      RTS     R5
4726
4727      .SBTTL ROUTINE TO DUMP BUFFER ON DCK
4728 026222      STARS
4729      ;*****
4730      ;DMPBUF -- ROUTINE TO DUMP BUFFER ON DCK ERROR. TWO DUMPS ARE POSSIBLE
4731      ; ONE WHERE WE CAN COMPARE WHAT IT SHOULD BE AND THE OTHER
4732 026222      ; WHEN WE CAN'T.
4733      STARS
4734      ;*****
4734 026222 004737 006270      DMPBUF: JSR     PC, LINE3
4735

```

ROUTINE TO DUMP BUFFER ON DCK

```

4736                                     ;CALCULATE THE STARTING BUS ADDRESS FOR THE COMPARE
4737
4738 026226 012737 000200 002464      MOV     #128.,DWCNT1
4739 026234 016400 000040              MOV     BDA(R4),R0          ;GET STARTING BUS ADDRESS
4740
4741 026240 013701 002424              MOV     E.DA,R1          ;GET PRESENT DISK ADDRESS
4742 026244 042700 177700              BIC     #177700,R0       ;SAVE SECTOR BITS
4743 026250 042701 177700              BIC     #177700,R1
4744 026254 010002                      MOV     R0,R2          ;SAVE A COPY
4745 026256 010103                      MOV     R1,R3          ;SAVE ANOTHER
4746 026260 160203                      SUB     R2,R3          ;GET DIFF OF SECTORS
4747 026262 005002                      CLR     R2             ;CALCULATE WORD COUNT
4748 026264 062702 000200      93$:  ADD     #128.,R2         ;ONE SECTORS WORTH
4749 026270 005303                      DEC     R3             ;DONE
4750 026272 001374                      BNE     93$           ;NO
4751 026274 016403 000042      MOV     BMP(R4),R3      ;GET WORD COUNT
4752 026300 005403                      NEG     R3             ;MAKE IT POSITIVE
4753 026302 020203                      CMP     R2,R3          ;WORKING WITH FULL SECTOR
4754 026304 003005                      BGT     94$           ;NO, GO CALC PARTIAL SECTOR
4755 026306 013702 002422      MOV     E.BA,R2        ;PRESENT BUS ADDRESS
4756 026312 162702 000400      SUB     #400,R2        ;START OF COMPARE
4757 026316 000412                      BR      96$           ;GO COMPARE BUFFER
4758 026320 160302      94$:  SUB     R3,R2          ;GET SECTOR DIFF
4759 026322 012700 000200      MOV     #128.,R0
4760 026326 160200                      SUB     R2,R0
4761 026330 010037 002464      MOV     R0,DWCNT1
4762 026334 006300                      ASL     R0
4763 026336 013702 002422      MOV     E.BA,R2
4764 026342 160002                      SUB     R0,R2
4765 026344      96$:  PRINTB  #FMT13,#BUSAD,R2,#CRLDA,CHKSEC
4765 026344 013746 002342      MOV     CHKSEC,-(SP)
4765 026350 012746 002577      MOV     #CRLDA,-(SP)
4765 026354 010246                      MOV     R2,-(SP)
4765 026356 012746 004132      MOV     #BUSAD,-(SP)
4765 026362 012746 007421      MOV     #FMT13,-(SP)
4765 026366 012746 000005      MOV     #5,-(SP)
4765 026372 010600                      MOV     SP,R0
4765 026374 104414                      TRAP   C#PNTB
4765 026376 062706 000014      ADD     #14,SP
4766 026402 012700 027734      MOV     #PATLST,R0      ;CHECK PATTERN LIST
4767 026406 012701 000010      MOV     #8.,R1
4768 026412 022062 000002      1$:  CMP     (R0)+,2(R2)
4769 026416 001415                      BEQ    2$
4770 026420 005301                      DEC     R1
4771 026422 001373                      BNE    1$
4772
4773 026424      3$:  PRINTB  #FMT14,#NOREV
4773 026424 012746 003631      MOV     #NOREV,-(SP)
4773 026430 012746 007463      MOV     #FMT14,-(SP)
4773 026434 012746 000002      MOV     #2,-(SP)
4773 026440 010600                      MOV     SP,R0
4773 026442 104414                      TRAP   C#PNTB
4773 026444 062706 000006      ADD     #6,SP
4774 026450 000532                      BR      STDMP
4775
4776 026452 021227 000200      2$:  CMP     (R2),#128.
4777 026456 101362                      BHI    3$

```



ROUTINE TO DUMP BUFFER ON DCK

```

4778 026460 005037 002344 CLR DECNT
4779 026464 013701 010662 MOV T,CLT,R1
4780
4781 026470 012237 002346 MOV (R2)+,TEMP0 ;NONZERO WORD COUNT
4782 026474 013737 002346 002462 MOV TEMP0,DWCNT
4783 026502 005437 002462 NEG DWCNT
4784 026506 012237 002350 MOV (R2)+,TEMP1
4785 026512 162737 000002 002346 SUB #2,TEMP0
4786 026520 012737 000002 002352 MOV #2,TEMP2 ;WORD
4787 026526 013703 002350 MOV TEMP1,R3 ;PATTERN ADDRESS
4788 026532 012737 000020 002360 MOV #16.,TEMP5 ;16 ENTRIES
4789 026540 005737 002346 4$: TST TEMP0 ;ZERO OR PATTERN
4790 026544 001417 BEQ 6$ ;ZERO BRANCH
4791 026546 005337 002346 DEC TEMP0
4792 026552 005737 002360 TST TEMP5 ;WITHIN LIST
4793 026556 001005 BNE 5$
4794 026560 012737 000020 002360 MOV #16.,TEMP5
4795 026566 013703 002350 MOV TEMP1,R3
4796 026572 012337 002402 5$: MOV (R3)+,GDDAT
4797 026576 005337 002360 DEC TEMP5
4798 026602 000402 BR 7$
4799 026604 005037 002402 6$: CLR GDDAT
4800 026610 005237 002462 7$: INC DWCNT
4801 026614 021237 002402 CMP (R2),GDDAT
4802 026620 001422 BEQ 8$
4803
4804 026622 005237 002344 INC DECNT
4805 026626 005701 TST R1
4806 026630 001416 BEQ 8$
4807 026632 005301 DEC R1
4808 026634 PRINTB #FMT14B,TEMP2,GDDAT,(R2)
026634 011246 MOV (R2),-(SP)
026636 013746 002402 MOV GDDAT, -(SP)
026642 013746 002352 MOV TEMP2, -(SP)
026646 012746 007504 MOV #FMT14B, -(SP)
026652 012746 000004 MOV #4, -(SP)
026656 010600 MOV SP,R0
026660 104414 TRAP C#PNTB
026662 062706 000012 ADD #12,SP
4809
4810 026666 005237 002352 8$: INC TEMP2
4811 026672 005722 TST (R2)+
4812 026674 023737 002352 002464 CMP TEMP2,DWCNT1
4813 026702 003716 BLE 4$
4814 026704 PRINTB #FMT9A,DECNT,TEMP2
026704 013746 002352 MOV TEMP2, -(SP)
026710 013746 002344 MOV DECNT, -(SP)
026714 012746 007223 MOV #FMT9A, -(SP)
026720 012746 000003 MOV #3, -(SP)
026724 010600 MOV SP,R0
026726 104414 TRAP C#PNTB
026730 062706 000010 ADD #10,SP
4815
4816 026734 000205 RTS R5
4817
4818
4819

```

;ROUTINE TO DUMP THE CONTENTS OF THE READ BUFFER ON ERROR DETECTED  
;WILL ALSO TELL HOW MANY WORDS WERE IN THE XFER

ROUTINE TO DUMP BUFFER ON DCK

```

4820
4821 026736 016437 000042 002346 STDMP: MOV BMP(R4),TEMPO ;GET NEGATIVE WORD COUNT
4822 026744 005437 002346 NEG TEMPO ;MAKE THE # POSITIVE
4823 026750 012737 000200 002464 MOV #128.,DWCNT1 ;SET THE SIZE OF SECTOR
4824 026756 PRINTB #FMTXS,TEMPO ;TELL TRANSFER SIZE
      026756 013746 002346 MOV TEMPO,-(SP)
      026762 012746 007673 MOV #FMTXS,-(SP)
      026766 012746 000002 MOV #2,-(SP)
      026772 010600 MOV SP,R0
      026774 104414 TRAP C#PNTB
      026776 062706 000006 ADD #6,SP
4825 027002 013701 010662 MOV T.CLT,R1 ;GET THE PRINT LIMIT
4826 027006 012703 000012 MOV #10.,R3 ;SETUP LINE LIMIT
4827 027012 1#: PRINTB #FMT14A,(R2) ;PRINT A DATA WORD
      027012 011246 MOV (R2),-(SP)
      027014 012746 007472 MOV #FMT14A,-(SP)
      027020 012746 000002 MOV #2,-(SP)
      027024 010600 MOV SP,R0
      027026 104414 TRAP C#PNTB
      027030 062706 000006 ADD #6,SP
4828 027034 005722 iST (R2)+ ;POINT TO THE NEXT DATA WORD
4829 027036 005303 DEC R3 ;DONE WITH THE LINE?
4830 027040 001012 BNE 2# ;BR IF NO
4831 027042 PRINTB #FMT14C ;YES - PRINT <CR>
      027042 012746 007501 MOV #FMT14C,-(SP)
      027046 012746 000001 MOV #1,-(SP)
      027052 010600 MOV SP,R0
      027054 104414 TRAP C#PNTB
      027056 062706 000004 ADD #4,SP
4832 027062 012703 000012 MOV #10.,R3 ;RESET THE LINE LIMIT
4833 027066 005337 002464 2#: DEC DWCNT1 ;END OF SECTOR?
4834 027072 001001 BNE 3# ;BR IF NO
4835 027074 000402 BR 4# ;YES - EXIT
4836 027076 005301 3#: DEC R1 ;AT PRINT LIMIT?
4837 027100 001344 BNE 1# ;BR IF NO
4838 027102 4#: PRINTB #FMT14C ;PRINT <CR>
      027102 012746 007501 MOV #FMT14C,-(SP)
      027106 012746 000001 MOV #1,-(SP)
      027112 010600 MOV SP,R0
      027114 104414 TRAP C#PNTB
      027116 062706 000004 ADD #4,SP
4839 027122 000205 RTS R5 ;EXIT
4840
4841 ;
4842 ;ROUTINE TO CLEAR ALL DRIVE INFO. USED ON START OR
4843 ;RESTART IF CALLED. CAN BE USED TO CLEAR INDIVIDUAL DRIVE
4844 ;INFO BY BITMAP FOLLOWING CALL
4845 ;CALL JSR R5,CLEAR
4846 ;
4847
4848 027124 010446 CLEAR: MOV R4,-(SP) ;SAVE R4
4849 027126 012704 030362 MOV #DRBUF,R4 ;GET BUFFER STARTS
4850 027132 005024 2#: CLR (R4)+ ;CLEAR
4851 027134 020427 031642 CMP R4,#ENDBUF ;AT END OF BUFFERS
4852 027140 001374 BNE 2# ;NO, GO TO 2#
4853 027142 012604 4#: MOV (SP)+,R4 ;RESTORE CURRENT BUFFER POINTER
4854 027144 000205 RTS R5 ;EXIT

```

ROUTINE TO DUMP BUFFER ON DCK

4855  
 4856  
 4857 027146  
  
 4858  
 4859  
 4860 027146  
  
 4861  
 4862 027146 005037 002340  
 4863 027152 010046  
 4864 027154 010246  
 4865 027156 012700 000021  
 4866 027162 016402 000112  
 4867 027166 022712 177777  
 4868 027172 011411  
 4869 027174 023712 002342  
 4870 027200 001404  
 4871 027202 005722  
 4872 027204 005300  
 4873 027206 001367  
 4874 027210 000402  
 4875 027212 005237 002340  
 4876 027216 012602  
 4877 027220 012600  
 4878 027222 000205  
 4879  
 4880 027224  
  
 4881  
 4882 027224  
  
 4883  
 4884 027224 005037 002340  
 4885 027230 010046  
 4886 027232 010146  
 4887 027234 010246  
 4888 027236 012700 000021  
 4889 027242 016402 000112  
 4890 027246 022712 177777  
 4891 027252 001414  
 4892 027254 011201  
 4893 027256 043701 002272  
 4894 027262 023701 002342  
 4895 027266 001404  
 4896 027270 005722  
 4897 027272 005300  
 4898 027274 001364  
 4899 027276 000402  
 4900 027300 005237 002340  
 4901 027304 012602  
 4902 027306 012601  
 4903 027310 012600  
 4904 027312 000205  
 4905  
 4906 027314

```

.SBTTL ROUTINE TO CHECK FOR BAD SECTOR
STARS
;*****
;CKBDSC ROUTINE TO MATCH BAD SECTOR....BDA(R4) IS SECTOR WE ARE LOOKING
; FOR IN LIST POINTED TO BY BSECT(R4).....MORFND IS SET IF WE FIND IT.
STARS
;*****
CKBDSC: CLR MORFND ;CLEAR FLAG
        MOV RO, (SP) ;SAVE RO
        MOV R2, -(SP) ;SAVE R2
        MOV #17, R0 ;16 ENTRIES + BSF POINTER
18:     MOV BSECT(R4), R2 ;GET WHERE WE'RE LOOKING
28:     CMP #1, (R2) ;END OF ENTRY LIST?
        BEQ 48 ;BRANCH IF END
        CMP CHKSEC, (R2) ;HAVE WE GOT A MATCH
        BFC 38 ;THEN GO SET INDICATOR, ELSE
        TST (R2)
        DEC RO
        BNE 28
        BR 48
38:     INC MORFND ;SET FLAG FOUND
48:     MOV (SP), R2
        MOV (SP), R0
        RTS R5

STARS
;*****
;CKBDTK -- HERE TO CHECK IF CYLINDER & HEAD SELECTED IS IN THE BAD SECTOR FILE
STARS
;*****
CKBDTK: CLR MORFND ;CLEAR FLAG
        MOV RO, -(SP) ;SAVE RO
        MOV R1, -(SP) ;SAVE R1
        MOV R2, -(SP) ;SAVE R2
        MOV #17, R0 ;16 ENTRIES + BSF POINTER
18:     MOV BSECT(R4), R2 ;GET WHERE WE'RE LOOKING
28:     CMP #1, (R2) ;END OF LIST?
        BEQ 48 ;BRANCH IF END
        MOV (R2), R1 ;GET THE ENTRY FROM BAD SECT FILE
        BIC SMSK, R1 ;LEAVE ONLY CYL # & HEAD
        CMP CHKSEC, R1 ;HAVE WE GOT A MATCH
        BEQ 38 ;THEN GO SET INDICATOR, ELSE
        TST (R2)
        DEC RO
        BNE 28
        BR 48
38:     INC MORFND ;SET FLAG FOUND
48:     MOV (SP), R2
        MOV (SP), R1
        MOV (SP), R0
        RTS R5

STARS
;*****
    
```

ROUTINE TO CHECK FOR BAD SECTOR

4907 027314

STARS

;;\*\*\*\*\*

;BUFFER TO STORE BAD SECTOR LISTS

4908

4909

4910 027314

BSECO: .BLKW 17.

4911 027356

BSEC1: .BLKW 17.

4912 027420

BSEC2: .BLKW 17.

4913 027462

BSEC3: .BLKW 17.

4914 027524

BSEC4: .BLKW 17.

4915 027566

BSEC5: .BLKW 17.

4916 027630

BSEC6: .BLKW 17.

4917 027672

BSEC7: .BLKW 17.

4918 027734

STARS

;;\*\*\*\*\*

STARS

;;\*\*\*\*\*

4919 027734

4920

4921

;LIST OF PATTERNS USED IN WRITING

4922

4923 027734 027754

PATLST: PAT0 ;ALL 0'S

4924 027736 030014

PAT1 ;-1'S TO ALT BITS

4925 027740 030054

PAT2 ;0'S TO ALT BITS

4926 027742 030114

PAT3 ;SHIFTING ALT BITS

4927 027744 030154

PAT4 ;WORST CASE DATA

4928 027746 030214

PAT5 ;STRANGE DATA

4929 027750 030254

PAT6 ;ALL 1'S

4930 027752 030314

PAT7 ;STRANGE DATA

4931

4932 027754 000000

PAT0: .WORD 0

4933 027756 000000

.WORD 0

4934 027760 000000

.WORD 0

4935 027762 000000

.WORD 0

4936 027764 000000

.WORD 0

4937 027766 000000

.WORD 0

4938 027770 000000

.WORD 0

4939 027772 000000

.WORD 0

4940 027774 000000

.WORD 0

4941 027776 000000

.WORD 0

4942 030000 000000

.WORD 0

4943 030002 000000

.WORD 0

4944 030004 000000

.WORD 0

4945 030006 000000

.WORD 0

4946 030010 000000

.WORD 0

4947 030012 000000

.WORD 0

4948

4949 030014 177777

PAT1: .WORD 177777

4950 030016 177777

.WORD 177777

4951 030020 177777

.WORD 177777

4952 030022 052525

.WORD 052525

4953 030024 052525

.WORD 052525

4954 030026 052525

.WORD 052525

4955 030030 177777

.WORD 177777

4956 030032 177777

.WORD 177777

4957 030034 052525

.WORD 052525

4958 030036 052525

.WORD 052525

4959 030040 177777

.WORD 177777

4960 030042 052525

.WORD 052525

ROUTINE TO CHECK FOR BAD SECTOR

4961	030044	177252	.WORD	177252
4962	030046	177252	.WORD	177252
4963	030050	172765	.WORD	172765
4964	030052	172765	.WORD	172765
4965				
4966	030054	000000	PAT2: .WORD	0
4967	030056	000000	.WORD	0
4968	030060	000000	.WORD	0
4969	030062	177777	.WORD	177777
4970	030064	177777	.WORD	177777
4971	030066	177777	.WORD	177777
4972	030070	000000	.WORD	0
4973	030072	000000	.WORD	0
4974	030074	177777	.WORD	177777
4975	030076	177777	.WORD	177777
4976	030100	000000	.WORD	0
4977	030102	177777	.WORD	177777
4978	030104	000000	.WORD	0
4979	030106	177777	.WORD	177777
4980	030110	000000	.WORD	0
4981	030112	177777	.WORD	177777
4982				
4983	030114	025252	PAT3: .WORD	25252
4984	030116	052525	.WORD	52525
4985	030120	052525	.WORD	52525
4986	030122	125252	.WORD	125252
4987	030124	125252	.WORD	125252
4988	030126	125252	.WORD	125252
4989	030130	052525	.WORD	52525
4990	030132	052525	.WORD	52525
4991	030134	125252	.WORD	125252
4992	030136	125252	.WORD	125252
4993	030140	052525	.WORD	52525
4994	030142	125252	.WORD	125252
4995	030144	052525	.WORD	52525
4996	030146	125252	.WORD	125252
4997	030150	052525	.WORD	52525
4998	030152	125252	.WORD	125252
4999				
5000	030154	155555	PAT4: .WORD	155555
5001	030156	066666	.WORD	066666
5002	030160	133333	.WORD	133333
5003	030162	155555	.WORD	155555
5004	030164	066666	.WORD	066666
5005	030166	133333	.WORD	133333
5006	030170	155555	.WORD	155555
5007	030172	066666	.WORD	066666
5008	030174	133333	.WORD	133333
5009	030176	155555	.WORD	155555
5010	030200	066666	.WORD	066666
5011	030202	133333	.WORD	133333
5012	030204	155555	.WORD	155555
5013	030206	066666	.WORD	066666
5014	030210	133333	.WORD	133333
5015	030212	155555	.WORD	155555
5016				
5017	030214	121105	PAT5: .WORD	121105

ROUTINE TO CHECK FOR BAD SECTOR

5018	030216	150442	.WORD	150442
5019	030220	064221	.WORD	64221
5020	030222	132110	.WORD	132110
5021	030224	055044	.WORD	55044
5022	030226	026422	.WORD	26422
5023	030230	013211	.WORD	13211
5024	030232	105504	.WORD	105504
5025	030234	042642	.WORD	42642
5026	030236	021321	.WORD	21321
5027	030240	110550	.WORD	110550
5028	030242	044264	.WORD	44264
5029	030244	022132	.WORD	22132
5030	030246	011055	.WORD	11055
5031	030250	104426	.WORD	104426
5032	030252	042213	.WORD	42213
5033				
5034	030254	177777	PAT6: .WORD	177777
5035	030256	177777	.WORD	177777
5036	030260	177777	.WORD	177777
5037	030262	177777	.WORD	177777
5038	030264	177777	.WORD	177777
5039	030266	177777	.WORD	177777
5040	030270	177777	.WORD	177777
5041	030272	177777	.WORD	177777
5042	030274	177777	.WORD	177777
5043	030276	177777	.WORD	177777
5044	030300	177777	.WORD	177777
5045	030302	177777	.WORD	177777
5046	030304	177777	.WORD	177777
5047	030306	177777	.WORD	177777
5048	030310	177777	.WORD	177777
5049	030312	177777	.WORD	177777
5050				
5051	030314	045513	PAT7: .WORD	45513
5052	030316	122645	.WORD	122645
5053	030320	151322	.WORD	151322
5054	030322	064551	.WORD	64551
5055	030324	132264	.WORD	132264
5056	030326	055132	.WORD	55132
5057	030330	026455	.WORD	26455
5058	030332	113226	.WORD	113226
5059	030334	045513	.WORD	45513
5060	030336	122645	.WORD	122645
5061	030340	151322	.WORD	151322
5062	030342	064551	.WORD	64551
5063	030344	132264	.WORD	132264
5064	030346	055132	.WORD	55132
5065	030350	026455	.WORD	26455
5066	030352	113226	.WORD	113226
5067				
5068	030354	000240	ENDOFPROGRAM:	NOP
5069	030356		ENDTST	
	030356		L10024:	
	030356	104401	TRAP	C4ETST
5070	030360	000000	HALT	
5071				
5072			.SBTTL	DRIVE INFORMATION BUFFERS

DRIVE INFORMATION BUFFERS

5073  
5074  
5075  
5076  
5077  
5078  
5079  
5124

;DRIVE INFORMATION BUFFER

.LIST ME

DRBUF:  
.REPT 8.

030362 000000  
030364 000002  
030366 000004  
030370 000006  
030372 000010  
030374 000012  
030376 000014  
030400 000016  
030402 000020  
030404 000022  
030406 000024  
030410 000026  
030412 000030  
030414 000032  
030416 000034  
030420 000036  
030422 000040  
030424 000042  
030426 000044  
030430 000046  
030432 000050  
030434 000052  
030436 000054  
030440 000056  
030442 000060  
030444 000062  
030446 000064  
030450 000066  
030452 000070  
030454 000072  
030456 000074  
030460 000076  
030462 000100  
030464 000102  
030466 000104  
030470 000106  
030472 000110  
030474 000112  
030476 000114  
030500 000116  
030502 000120  
030504 000122  
030506 000124

SKCNT  
RXFR1  
RXFR2  
WXFR1  
WXFR2  
ERRCNT  
SFTCNT  
SKECNT  
DERCNT  
DCRCER  
MCRCER  
DLTCNT  
OPICNT  
MNFERR  
NXMCNT  
RETRY  
BDA  
BMP  
FUNC  
BCSADR  
LSTHDR  
RTYPE  
SKCNT1  
PRFLGS  
RXFR3  
WXFR3  
LSTDA  
DIFWD  
DPHOUR  
TRERR  
DATCER  
DOWCK  
SERNM1  
SERNM2  
DCS  
DRSEL  
BBA  
BSECT  
RSEEK  
SOFTCS  
TDR  
WRIPG  
PRPOS

;SEEK OPERATION COUNT  
;READ OPERATION COUNT (BITS) LOW ORDER  
; " " " " HIGH ORDER  
;WRITE OPERATION COUNT (BITS) LOW ORDER  
; " " " " HIGH ORDER  
;ERROR COUNT - HARD  
;ERROR COUNT - SOFT  
;SEEK ERROR COUNT  
;DRIVE ERROR COUNT  
;DATA CRC ERROR COUNT  
;HEADER CRC ERROR COUNT  
;DATA LATE ERROR COUNT  
;OPERATION INCOMPLETE ERROR COUNT  
;HEADER NOT FOUND ERROR COUNT  
;NON EXISTANT MEMORY ERROR COUNT  
;PRESENT RETRY NUMBER  
; " DISK ADDRESS CONTENTS  
;PRESENT MULTIPURPOSE CONTENTS  
;LAST FUNCTION LOADED  
;CSR IMAGE OF LAST COMMAND  
;LAST POSITION ON DISK  
;ERROR ON WHICH RECOVERY IS IN PROGRESS  
;SEEK COUNT LOW ORDER  
;PROGRAM INTERNAL FLAGS  
;READ COUNT THIRD  
;WRITE COUNT THIRD  
;DISK ADDRESS OF SOFT ERROR  
;LAST DIFFERENCE WORD OF SEEK  
;TIME DRIVE WAS DROPPED  
;TRACKING ERROR COUNT  
  
;WRITE CHECK NECESSARY  
;SERIAL NUMBER OF CARTRIDGE  
;SERIAL NUMBER OF CARTRIDGE  
;CSR ADDRESS  
;DRIVE SELECT BITS(8,9,10)  
;PRESENT BUS ADDRESS CONTENTS  
;POINTER TO BAD SECTOR FILE  
  
;CSR AT TIME OF SOFT ERROR  
;DRIVE TYPE FLAG (RL01 =1)  
;WRITE IN PROGRESS FLAG  
;PRESENT POSITION ON DISK

030510 000000  
030512 000002  
030514 000004  
030516 000006  
030520 000010

SKCNT  
RXFR1  
RXFR2  
WXFR1  
WXFR2

;SEEK OPERATION COUNT  
;READ OPERATION COUNT (BITS) LOW ORDER  
; " " " " HIGH ORDER  
;WRITE OPERATION COUNT (BITS) LOW ORDER  
; " " " " HIGH ORDER

DRIVE INFORMATION BUFFERS

030522	000012	ERRCNT	; ERROR COUNT HARD
030524	000014	SFTCNT	; ERROR COUNT SOFT
030526	000016	SKECNT	; SEEK ERROR COUNT
030530	000020	DERCNT	; DRIVE ERROR COUNT
030532	000022	DCRCER	; DATA CRC ERROR COUNT
030534	000024	HRCRCER	; HEADER CRC ERROR COUNT
030536	000026	DLTCNT	; DATA LATE ERROR COUNT
030540	000030	OPICNT	; OPERATION INCOMPLETE ERROR COUNT
030542	000032	HNFERR	; HEADER NOT FOUND ERROR COUNT
030544	000034	NXMCNT	; NON EXISTANT MEMORY ERROR COUNT
030546	000036	RETRY	; PRESENT RETRY NUMBER
030550	000040	BDA	; " DISK ADDRESS CONTENTS
030552	000042	BMP	; PRESENT MULTIPURPOSE CONTENTS
030554	000044	FUNC	; LAST FUNCTION LOADED
030556	000046	BCSADR	; CSR IMAGE OF LAST COMMAND
030560	000050	LSTHDR	; LAST POSITION ON DISK
030562	000052	RTYPE	; ERROR ON WHICH RECOVERY IS IN PROGRESS
030564	000054	SKCNT1	; SEEK COUNT LOW ORDER
030566	000056	PRFLGS	; PROGRAM INTERNAL FLAGS
030570	000060	RXFR3	; READ COUNT THIRD
030572	000062	WXFR3	; WRITE COUNT THIRD
030574	000064	LSTDA	; DISK ADDRESS OF SOFT ERROR
030576	000066	DIFWD	; LAST DIFFERENCE WORD OF SEEK
030600	000070	DPHOUR	; TIME DRIVE WAS DROPPED
030602	000072	TRERR	; TRACKING ERROR COUNT
030604	000074	DATCER	
030606	000076	DOWCK	; WRITE CHECK NECESSARY
030610	000100	SERNM1	; SERIAL NUMBER OF CARTRIDGE
030612	000102	SERNM2	; SERIAL NUMBER OF CARTRIDGE
030614	000104	DCS	; CSR ADDRESS
030616	000106	DRSEL	; DRIVE SELECT BITS(8,9,10)
030620	000110	BBA	; PRESENT BUS ADDRESS CONTENTS
030622	000112	BSECTP	; POINTER TO BAD SECTOR FILE
030624	000114	RSEK	
030626	000116	SOFTCS	; CSR AT TIME OF SOFT ERROR
030630	000120	TDR	; DRIVE TYPE FLAG (RL01 =1)
030632	000122	WRIPG	; WRITE IN PROGRESS FLAG
030634	000124	PRPOS	; PRESENT POSITION ON DISK
030636	000000	SKCNT	; SEEK OPERATION COUNT
030640	000002	RXFR1	; READ OPERATION COUNT (BITS) LOW ORDER
030642	000004	RXFR2	; " " " HIGH ORDER
030644	000006	WXFR1	; WRITE OPERATION COUNT (BITS) LOW ORDER
030646	000010	WXFR2	; " " " HIGH ORDER
030650	000012	ERRCNT	; ERROR COUNT - HARD
030652	000014	SFTCNT	; ERROR COUNT - SOFT
030654	000016	SKECNT	; SEEK ERROR COUNT
030656	000020	DERCNT	; DRIVE ERROR COUNT
030660	000022	DCRCER	; DATA CRC ERROR COUNT
030662	000024	HRCRCER	; HEADER CRC ERROR COUNT
030664	000026	DLTCNT	; DATA LATE ERROR COUNT
030666	000030	OPICNT	; OPERATION INCOMPLETE ERROR COUNT
030670	000032	HNFERR	; HEADER NOT FOUND ERROR COUNT
030672	000034	NXMCNT	; NON EXISTANT MEMORY ERROR COUNT
030674	000036	RETRY	; PRESENT RETRY NUMBER
030676	000040	BDA	; " DISK ADDRESS CONTENTS
030700	000042	BMP	; PRESENT MULTIPURPOSE CONTENTS



DRIVE INFORMATION BUFFERS

030702	000044	FUNC	;LAST FUNCTION LOADED
030704	000046	BCSADR	;CSR IMAGE OF LAST COMMAND
030706	000050	LSTHDR	;LAST POSITION ON DISK
030710	000052	RTYPE	;ERROR ON WHICH RECOVERY IS IN PROGRESS
030712	000054	SKCNT1	;SEEK COUNT LOW ORDER
030714	000056	PRFLGS	;PROGRAM INTERNAL FLAGS
030716	000060	RXFR3	;READ COUNT THIRD
030720	000062	WXFR3	;WRITE COUNT THIRD
030722	000064	LSTDA	;DISK ADDRESS OF SOFT ERROR
030724	000066	DIFWD	;LAST DIFFERENCE WORD OF SEEK
030726	000070	DPHOUR	;TIME DRIVE WAS DROPPED
030730	000072	TRERR	;TRACKING ERROR COUNT
030732	000074	DATCER	
030734	000076	DOWCK	;WRITE CHECK NECESSARY
030736	000100	SERNM1	;SERIAL NUMBER OF CARTRIDGE
030740	000102	SERNM2	;SERIAL NUMBER OF CARTRIDGE
030742	000104	DCS	;CSR ADDRESS
030744	000106	DRSEL	;DRIVE SELECT BITS(8,9,10)
030746	000110	BBA	;PRESENT BUS ADDRESS CONTENTS
030750	000112	BSECT	;POINTER TO BAD SECTOR FILE
030752	000114	RSEK	
030754	000116	SOFTCS	;CSR AT TIME OF SOFT ERROR
030756	000120	TDR	;DRIVE TYPE FLAG (RL01 =1)
030760	000122	WRIPG	;WRITE IN PROGRESS FLAG
030762	000124	PRPOS	;PRESENT POSITION ON DISK
030764	000000	SKCNT	;SEEK OPERATION COUNT
030766	000002	RXFR1	;READ OPERATION COUNT (BITS) LOW ORDER
030770	000004	RXFR2	; " " " " HIGH ORDER
030772	000006	WXFR1	;WRITE OPERATION COUNT (BITS) LOW ORDER
030774	000010	WXFR2	; " " " " HIGH ORDER
030776	000012	ERRCNT	;ERROR COUNT - HARD
031000	000014	SFTCNT	;ERROR COUNT - SOFT
031002	000016	SKECNT	;SEEK ERROR COUNT
031004	000020	DERCNT	;DRIVE ERROR COUNT
031006	000022	DCRCER	;DATA CRC ERROR COUNT
031010	000024	HRCER	;HEADER CRC ERROR COUNT
031012	000026	DLTCNT	;DATA LATE ERROR COUNT
031014	000030	OPICNT	;OPERATION INCOMPLETE ERROR COUNT
031016	000032	HNFERR	;HEADER NOT FOUND ERROR COUNT
031020	000034	NXMCNT	;NON EXISTANT MEMORY ERROR COUNT
031022	000036	RETRY	;PRESENT RETRY NUMBER
031024	000040	BDA	; " DISK ADDRESS CONTENTS
031026	000042	BMP	;PRESENT MULTIPURPOSE CONTENTS
031030	000044	FUNC	;LAST FUNCTION LOADED
031032	000046	BCSADR	;CSR IMAGE OF LAST COMMAND
031034	000050	LSTHDR	;LAST POSITION ON DISK
031036	000052	RTYPE	;ERROR ON WHICH RECOVERY IS IN PROGRESS
031040	000054	SKCNT1	;SEEK COUNT LOW ORDER
031042	000056	PRFLGS	;PROGRAM INTERNAL FLAGS
031044	000060	RXFR3	;READ COUNT THIRD
031046	000062	WXFR3	;WRITE COUNT THIRD
031050	000064	LSTDA	;DISK ADDRESS OF SOFT ERROR
031052	000066	DIFWD	;LAST DIFFERENCE WORD OF SEEK
031054	000070	DPHOUR	;TIME DRIVE WAS DROPPED
031056	000072	TRERR	;TRACKING ERROR COUNT
031060	000074	DATCER	

## DRIVE INFORMATION BUFFERS

031062	000076	DOWCK	;WRITE CHECK NECESSARY
031064	000100	SERNM1	;SERIAL NUMBER OF CARTRIDGE
031066	000102	SERNM2	;SERIAL NUMBER OF CARTRIDGE
031070	000104	DCS	;CSR ADDRESS
031072	000106	DRSEL	;DRIVE SELECT BITS(8,9,10)
031074	000110	BBA	;PRESENT BUS ADDRESS CONTENTS
031076	000112	BSECPT	;POINTER TO BAD SECTOR FILE
031100	000114	RSEEK	
031102	000116	SOFTCS	;CSR AT TIME OF SOFT ERROR
031104	000120	TDR	;DRIVE TYPE FLAG (RL01 =1)
031106	000122	WRIPG	;WRITE IN PROGRESS FLAG
031110	000124	PRPOS	;PRESENT POSITION ON DISK
031112	000000	SKCNT	;SEEK OPERATION COUNT
031114	000002	RXFR1	;READ OPERATION COUNT (BITS) LOW ORDER
031116	000004	RXFR2	; " " " " HIGH ORDER
031120	000006	WXFR1	;WRITE OPERATION COUNT (BITS) LOW ORDER
031122	000010	WXFR2	; " " " " HIGH ORDER
031124	000012	ERRCNT	;ERROR COUNT - HARD
031126	000014	SFTCNT	;ERROR COUNT - SOFT
031130	000016	SKECNT	;SEEK ERROR COUNT
031132	000020	DERCNT	;DRIVE ERROR COUNT
031134	000022	DCRCER	;DATA CRC ERROR COUNT
031136	000024	HCRCER	;HEADER CRC ERROR COUNT
031140	000026	DLTCNT	;DATA LATE ERROR COUNT
031142	000030	OPICNT	;OPERATION INCOMPLETE ERROR COUNT
031144	000032	HNFERR	;HEADER NOT FOUND ERROR COUNT
031146	000034	NXMCNT	;NON EXISTANT MEMORY ERROR COUNT
031150	000036	RETRY	;PRESENT RETRY NUMBER
031152	000040	BDA	; " DISK ADDRESS CONTENTS
031154	000042	BMP	;PRESENT MULTIPURPOSE CONTENTS
031156	000044	FUNC	;LAST FUNCTION LOADED
031160	000046	BCSADR	;CSR IMAGE OF LAST COMMAND
031162	000050	LSTHDR	;LAST POSITION ON DISK
031164	000052	RTYPE	;ERROR ON WHICH RECOVERY IS IN PROGRESS
031166	000054	SKCNT1	;SEEK COUNT LOW ORDER
031170	000056	PRFLGS	;PROGRAM INTERNAL FLAGS
031172	000060	RXFR3	;READ COUNT THIRD
031174	000062	WXFR3	;WRITE COUNT THIRD
031176	000064	LSTDA	;DISK ADDRESS OF SOFT ERROR
031200	000066	DIFWD	;LAST DIFFERENCE WORD OF SEEK
031202	000070	DPHOUR	;TIME DRIVE WAS DROPPED
031204	000072	TRERR	;TRACKING ERROR COUNT
031206	000074	DATCER	
031210	000076	DOWCK	;WRITE CHECK NECESSARY
031212	000100	SERNM1	;SERIAL NUMBER OF CARTRIDGE
031214	000102	SERNM2	;SERIAL NUMBER OF CARTRIDGE
031216	000104	DCS	;CSR ADDRESS
031220	000106	DRSEL	;DRIVE SELECT BITS(8,9,10)
031222	000110	BBA	;PRESENT BUS ADDRESS CONTENTS
031224	000112	BSECPT	;POINTER TO BAD SECTOR FILE
031226	000114	RSEEK	
031230	000116	SOFTCS	;CSR AT TIME OF SOFT ERROR
031232	000120	TDR	;DRIVE TYPE FLAG (RL01 =1)
031234	000122	WRIPG	;WRITE IN PROGRESS FLAG
031236	000124	PRPOS	;PRESENT POSITION ON DISK

DRIVE INFORMATION BUFFERS

031240	000000	SKCNT	;SEEK OPERATION COUNT
031242	000002	RXFR1	;READ OPERATION COUNT (BITS) LOW ORDER
031244	000004	RXFR2	; " " " " HIGH ORDER
031246	000006	WXFR1	;WRITE OPERATION COUNT (BITS) LOW ORDER
031250	000010	WXFR2	; " " " " HIGH ORDER
031252	000012	ERRCNT	;ERROR COUNT - HARD
031254	000014	SFTCNT	;ERROR COUNT - SOFT
031256	000016	SKECNT	;SEEK ERROR COUNT
031260	000020	DERCNT	;DRIVE ERROR COUNT
031262	000022	DCRCER	;DATA CRC ERROR COUNT
031264	000024	HRCRCR	;HEADER CRC ERROR COUNT
031266	000026	DLTCNT	;DATA LATE ERROR COUNT
031270	000030	OPICNT	;OPERATION INCOMPLETE ERROR COUNT
031272	000032	HNFERR	;HEADER NOT FOUND ERROR COUNT
031274	000034	NXMCNT	;NON EXISTANT MEMORY ERROR COUNT
031276	000036	RETRY	;PRESENT RETRY NUMBER
031300	000040	BDA	; " DISK ADDRESS CONTENTS
031302	000042	BMP	;PRESENT MULTIPURPOSE CONTENTS
031304	000044	FUNC	;LAST FUNCTION LOADED
031306	000046	BCSADR	;CSR IMAGE OF LAST COMMAND
031310	000050	LSTHDR	;LAST POSITION ON DISK
031312	000052	RTYPE	;ERROR ON WHICH RECOVERY IS IN PROGRESS
031314	000054	SKCNT1	;SEEK COUNT LOW ORDER
031316	000056	PRFLGS	;PROGRAM INTERNAL FLAGS
031320	000060	RXFR3	;READ COUNT THIRD
031322	000062	WXFR3	;WRITE COUNT THIRD
031324	000064	LSTDA	;DISK ADDRESS OF SOFT ERROR
031326	000066	DIFWD	;LAST DIFFERENCE WORD OF SEEK
031330	000070	DPHOUR	;TIME DRIVE WAS DROPPED
031332	000072	TRERR	;TRACKING ERROR COUNT
031334	000074	DATCER	
031336	000076	DOWCK	;WRITE CHECK NECESSARY
031340	000100	SERNM1	;SERIAL NUMBER OF CARTRIDGE
031342	000102	SERNM2	;SERIAL NUMBER OF CARTRIDGE
031344	000104	DCS	;CSR ADDRESS
031346	000106	DRSEL	;DRIVE SELECT BITS(8,9,10)
031350	000110	BBA	;PRESENT BUS ADDRESS CONTENTS
031352	000112	BSECP	;POINTER TO BAD SECTOR FILE
031354	000114	RSEEK	
031356	000116	SOFTCS	;CSR AT TIME OF SOFT ERROR
031360	000120	TDR	;DRIVE TYPE FLAG (RL01 =1)
031362	000122	WRIPG	;WRITE IN PROGRESS FLAG
031364	000124	PRPOS	;PRESENT POSITION ON DISK
031366	000000	SKCNT	;SEEK OPERATION COUNT
031370	000002	RXFR1	;READ OPERATION COUNT (BITS) LOW ORDER
031372	000004	RXFR2	; " " " " HIGH ORDER
031374	000006	WXFR1	;WRITE OPERATION COUNT (BITS) LOW ORDER
031376	000010	WXFR2	; " " " " HIGH ORDER
031400	000012	ERRCNT	;ERROR COUNT - HARD
031402	000014	SFTCNT	;ERROR COUNT - SOFT
031404	000016	SKECNT	;SEEK ERROR COUNT
031406	000020	DERCNT	;DRIVE ERROR COUNT
031410	000022	DCRCER	;DATA CRC ERROR COUNT
031412	000024	HRCRCR	;HEADER CRC ERROR COUNT
031414	000026	DLTCNT	;DATA LATE ERROR COUNT
031416	000030	OPICNT	;OPERATION INCOMPLETE ERROR COUNT

## DRIVE INFORMATION BUFFERS

031420	000032	HNFERR	;HEADER NOT FOUND ERROR COUNT
031422	000034	NXMCNT	;NON EXISTANT MEMORY ERROR COUNT
031424	000036	RETRY	;PRESENT RETRY NUMBER
031426	000040	BDA	; " DISK ADDRESS CONTENTS
031430	000042	BMP	;PRESENT MULTIPURPOSE CONTENTS
031432	000044	FUNC	;LAST FUNCTION LOADED
031434	000046	BCSADR	;CSR IMAGE OF LAST COMMAND
031436	000050	LSTHDR	;LAST POSITION ON DISK
031440	000052	RTYPE	;ERROR ON WHICH RECOVERY IS IN PROGRESS
031442	000054	SKCNT1	;SEEK COUNT LOW ORDER
031444	000056	PRFLGS	;PROGRAM INTERNAL FLAGS
031446	000060	RXFR3	;READ COUNT THIRD
031450	000062	WXFR3	;WRITE COUNT THIRD
031452	000064	LSTDA	;DISK ADDRESS OF SOFT ERROR
031454	000066	DIFWD	;LAST DIFFERENCE WORD OF SEEK
031456	000070	DPHOUR	;TIME DRIVE WAS DROPPED
031460	000072	TRERR	;TRACKING ERROR COUNT
031462	000074	DATCER	
031464	000076	DOWCK	;WRITE CHECK NECESSARY
031466	000100	SERNM1	;SERIAL NUMBER OF CARTRIDGE
031470	000102	SERNM2	;SERIAL NUMBER OF CARTRIDGE
031472	000104	DCS	;CSR ADDRESS
031474	000106	DRSEL	;DRIVE SELECT BITS(8,9,10)
031476	000110	BBA	;PRESENT BUS ADDRESS CONTENTS
031500	000112	BSECPT	;POINTER TO BAD SECTOR FILE
031502	000114	RSEEK	
031504	000116	SOFTCS	;CSR AT TIME OF SOFT ERROR
031506	000120	TDR	;DRIVE TYPE FLAG (RL01 =1)
031510	000122	WRIPG	;WRITE IN PROGRESS FLAG
031512	000124	PRPOS	;PRESENT POSITION ON DISK
031514	000000	SKCNT	;SEEK OPERATION COUNT
031516	000002	RXFR1	;READ OPERATION COUNT (BITS) LOW ORDER
031520	000004	RXFR2	; " " " " HIGH ORDER
031522	000006	WXFR1	;WRITE OPERATION COUNT (BITS) LOW ORDER
031524	000010	WXFR2	; " " " " HIGH ORDER
031526	000012	ERRCNT	;ERROR COUNT - HARD
031530	000014	SFTCNT	;ERROR COUNT - SOFT
031532	000016	SKECNT	;SEEK ERROR COUNT
031534	000020	DERCNT	;DRIVE ERROR COUNT
031536	000022	DCRCER	;DATA CRC ERROR COUNT
031540	000024	HRCRCR	;HEADER CRC ERROR COUNT
031542	000026	DLTCNT	;DATA LATE ERROR COUNT
031544	000030	OPICNT	;OPERATION INCOMPLETE ERROR COUNT
031546	000032	HNFERR	;HEADER NOT FOUND ERROR COUNT
031550	000034	NXMCNT	;NON EXISTANT MEMORY ERROR COUNT
031552	000036	RETRY	;PRESENT RETRY NUMBER
031554	000040	BDA	; " DISK ADDRESS CONTENTS
031556	000042	BMP	;PRESENT MULTIPURPOSE CONTENTS
031560	000044	FUNC	;LAST FUNCTION LOADED
031562	000046	BCSADR	;CSR IMAGE OF LAST COMMAND
031564	000050	LSTHDR	;LAST POSITION ON DISK
031566	000052	RTYPE	;ERROR ON WHICH RECOVERY IS IN PROGRESS
031570	000054	SKCNT1	;SEEK COUNT LOW ORDER
031572	000056	PRFLGS	;PROGRAM INTERNAL FLAGS
031574	000060	RXFR3	;READ COUNT THIRD
031576	000062	WXFR3	;WRITE COUNT THIRD

DRIVE INFORMATION BUFFERS

031600	000064	LSTDA	;DISK ADDRESS OF SOFT ERROR
031602	000066	DIFWD	;LAST DIFFERENCE WORD OF SEEK
031604	000070	DPHOUR	;TIME DRIVE WAS DROPPED
031606	000072	TRERR	;TRACKING ERROR COUNT
031610	000074	DATCER	
031612	000076	DOWCK	;WRITE CHECK NECESSARY
031614	000100	SERNM1	;SERIAL NUMBER OF CARTRIDGE
031616	000102	SERNM2	;SERIAL NUMBER OF CARTRIDGE
031620	000104	DCS	;CSR ADDRESS
031622	000106	DRSEL	;DRIVE SELECT BITS(8,9,10)
031624	000110	BBA	;PRESENT BUS ADDRESS CONTENTS
031626	000112	BSECT	;POINTER TO BAD SECTOR FILE
031630	000114	RSEK	
031632	000116	SOFTCS	;CSR AT TIME OF SOFT ERROR
031634	000120	TDR	;DRIVE TYPE FLAG (RL01 =1)
031636	000122	WRIPG	;WRITE IN PROGRESS FLAG
031640	000124	PRPOS	;PRESENT POSITION ON DISK
5125		.NLIST ME	
5126			
5127	031642	000000	ENDBUF: .WORD 0
5128			
5129			;QUESTIONS TO GET PARAMETERS FOR HARDWARE P-TABLE
5130			
5131	031644		BGNMOD HRDPRM
5132	031644		BGNHRD
	031644	000030	.WORD L10030-L#HARD/2
5133			
5134	031646		GPRML CNTYPE,CNT,1,YES
	031646	005130	.WORD T#CODE
	031650	031726	.WORD CNTYPE
	031652	000001	.WORD 1
5135	031654		GPRMA CSMSG,CSR,0,160000,177776,YES
	031654	000031	.WORD T#CODE
	031656	031733	.WORD CSMSG
	031660	160000	.WORD T#LOLIM
	031662	177776	.WORD T#HILIM
5136	031664		GPRMA VECMSG,VECT,0,0,776,YES
	031664	001031	.WORD T#CODE
	031666	032002	.WORD VECMSG
	031670	000000	.WORD T#LOLIM
	031672	000776	.WORD T#HILIM
5137	031674		GPRMD DRMSG,DRBT,0,03400,0,7,YES
	031674	004032	.WORD T#CODE
	031676	032011	.WORD DRMSG
	031700	003400	.WORD 03400
	031702	000000	.WORD T#LOLIM
	031704	000007	.WORD T#HILIM
5138	031706		GPRML DRTYPE,TYPDR,1,YES
	031706	003130	.WORD T#CODE
	031710	031760	.WORD DRTYPE
	031712	000001	.WORD 1
5139	031714		GPRMD BRMSG,PRIOR,0,340,0,7,YES
	031714	002032	.WORD T#CODE
	031716	031747	.WORD BRMSG
	031720	000340	.WORD 340
	031722	000000	.WORD T#LOLIM
	031724	000007	.WORD T#HILIM

DRIVE INFORMATION BUFFERS

5140

5141 031726

ENDHRD  
.EVEN

031726

L10030:

5142

5146

5147 031726 122

114

061

CNTYPE: .ASCIZ /RL11/

5148 031733 102

125

123

CSRMSG: .ASCIZ /BUS ADDRESS/

5149 031747 102

122

040

BRMSG: .ASCIZ /BR LEVEL/

5150 031760 104

122

111

DRTYPE: .ASCIZ /DRIVE TYPE = RL01/

5151 032002 126

105

103

VECMMSG: .ASCIZ /VECTOR/

5152 032011 104

122

111

DRMSG: .ASCIZ /DRIVE/

5153

5157

5158

.EVEN

5159

5160 032020

ENDMOD

5161

5162

:QUESTIONS TO GET PARAMETERS FOR SOFTWARE P-TABLE

5163

5164 032020

BGNMOD SFTPRM

5165

5166 032020

BGNSFT

032020 000210

.WORD L10031-L\$SOFT/2

5167

5168 032022

GPRMD RTMSG,RLT,D,177777,0,177777,YES

032022 000052

.WORD T\$CODE

032024 032707

.WORD RTMSG

032026 177777

.WORD 177777

032030 000000

.WORD T\$LOLIM

032032 177777

.WORD T\$HILIM

5169 032034

GPRMD SRTMSG,SRLT,D,177777,0,177777,YES

032034 031052

.WORD T\$CODE

032036 032532

.WORD SRTMSG

032040 177777

.WORD 177777

032042 000000

.WORD T\$LOLIM

032044 177777

.WORD T\$HILIM

5170 032046

GPRML FDCHK,DCKFG,1,YES

032046 020130

.WORD T\$CODE

032050 033175

.WORD FDCHK

032052 000001

.WORD 1

5171 032054

XFERF 5\$

032054 006044

.WORD T\$CODE

5172 032056

GPRMD CHKLMT,CLMT,D,177777,0,128,YES

032056 032052

.WORD T\$CODE

032060 032551

.WORD CHKLMT

032062 177777

.WORD 177777

032064 000000

.WORD T\$LOLIM

032066 000200

.WORD T\$HILIM

5173 032070

5\$:

GPRMD INMSG,TYT,D,177777,1,177777,YES

:JSD REV A

5174 032070

GPRML DRPMS,DRFLG,1,YES

032070 021130

.WORD T\$CODE

032072 033256

.WORD DRPMS

032074 000001

.WORD 1

5175 032076

XFERF 3\$

032076 032044

.WORD T\$CODE

5176 032100

GPRMD ERMSG,ELT,D,177777,0,177777,YES

DRIVE INFORMATION BUFFERS

	032100	001052		.WORD	T#CODE
	032102	032623		.WORD	ERMSG
	032104	177777		.WORD	177777
	032106	000000		.WORD	T#LOLIM
	032110	177777		.WORD	T#HILIM
5177	032112			GPRMD	SFTMSG,SEL,D,177777,0,177777,YES
	032112	023052		.WORD	T#CODE
	032114	032637		.WORD	SFTMSG
	032116	177777		.WORD	177777
	032120	000000		.WORD	T#LOLIM
	032122	177777		.WORD	T#HILIM
5178	032124			GPRMD	DERPMS,DCD,D,177777,0,177777,YES
	032124	036052		.WORD	T#CODE
	032126	033312		.WORD	DERPMS
	032130	177777		.WORD	177777
	032132	000000		.WORD	T#LOLIM
	032134	177777		.WORD	T#HILIM
5179	032136			GPRMD	SEMSG,SET,D,177777,0,177777,YES
	032136	002052		.WORD	T#CODE
	032140	032721		.WORD	SEMSG
	032142	177777		.WORD	177777
	032144	000000		.WORD	T#LOLIM
	032146	177777		.WORD	T#HILIM
5180	032150			GPRMD	DREMSG,DET,D,177777,0,177777,YES
	032150	025052		.WORD	T#CODE
	032152	032734		.WORD	DREMSG
	032154	177777		.WORD	177777
	032156	000000		.WORD	T#LOLIM
	032160	177777		.WORD	T#HILIM
5181	032162		3#:	GPRML	STLMT,OPFLG,1,YES
	032162	024130		.WORD	T#CODE
	032164	033221		.WORD	STLMT
	032166	000001		.WORD	1
5182	032170			XFERF	2#
	032170	013044		.WORD	T#CODE
5183	032172			GPRMD	DAMSG,DAT,D,177777,1,177776,YES
	032172	003052		.WORD	T#CODE
	032174	032747		.WORD	DAMSG
	032176	177777		.WORD	177777
	032200	000001		.WORD	T#LOLIM
	032202	177776		.WORD	T#HILIM
5184	032204			GPRMD	SKMSG,SKT,D,177777,1,177776,YES
	032204	004052		.WORD	T#CODE
	032206	032777		.WORD	SKMSG
	032210	177777		.WORD	177777
	032212	000001		.WORD	T#LOLIM
	032214	177776		.WORD	T#HILIM
5185	032216		2#:	GPRML	CHANGE,CHFLG,1,YES
	032216	010130		.WORD	T#CODE
	032220	033017		.WORD	CHANGE
	032222	000001		.WORD	1
5186	032224			XFERF	1#
	032224	107044		.WORD	T#CODE
5187	032226			GPRML	STIPMS,STIP,1,YES
	032226	034130		.WORD	T#CODE
	032230	032502		.WORD	STIPMS
	032232	000001		.WORD	1

DRIVE INFORMATION BUFFERS

5188	032234		XFERF	68
	032234	013044	.WORD	T%CODE
5189	032236		GPRMD	MXBUF, MXB, D, 177777, 3, 5120., YES
	032236	011052	.WORD	T%CODE
	032240	033053	.WORD	MXBUF
	032242	177777	.WORD	177777
	032244	000003	.WORD	T%L%L%I%M
	032246	012000	.WORD	T%H%I%L%I%M
5190	032250		GPRMD	MINBUF, MNB, D, 177777, 3., 5120., YES
	032250	022052	.WORD	T%CODE
	032252	033064	.WORD	MINBUF
	032254	177777	.WORD	177777
	032256	000003	.WORD	T%L%L%I%M
	032260	012000	.WORD	T%H%I%L%I%M
5191	032262		68: GPRML	R%O%N%L%Y, R%O%F, 1, YES
	032262	026130	.WORD	T%CODE
	032264	032571	.WORD	R%O%N%L%Y
	032266	000001	.WORD	1
5192	032270		GPRML	RANPAT, RAN, 1, YES
	032270	027130	.WORD	T%CODE
	032272	032601	.WORD	RANPAT
	032274	000001	.WORD	1
5193	032276		XFERT	78
	032276	006024	.WORD	T%CODE
5194	032300		GPRMD	ONLONE, PAT, 0, 17, 0, 7, YES
	032300	050032	.WORD	T%CODE
	032302	032611	.WORD	ONLONE
	032304	000017	.WORD	17
	032306	000000	.WORD	T%L%L%I%M
	032310	000007	.WORD	T%H%I%L%I%M
5195	032312		78: GPRMD	CMMSG, RDT, D, 177777, 0, 128., YES
	032312	006052	.WORD	T%CODE
	032314	033340	.WORD	CMMSG
	032316	177777	.WORD	177777
	032320	000000	.WORD	T%L%L%I%M
	032322	000200	.WORD	T%H%I%L%I%M
5196	032324		GPRMD	DEMSG, DOT, D, 177777, 0, 175, YES
	032324	007052	.WORD	T%CODE
	032326	032653	.WORD	DEMSG
	032330	177777	.WORD	177777
	032332	000000	.WORD	T%L%L%I%M
	032334	000175	.WORD	T%H%I%L%I%M
5197	032336		GPRMD	MXHD, MXH, D, 100, 0, 1, YES
	032336	012052	.WORD	T%CODE
	032340	033075	.WORD	MXHD
	032342	000100	.WORD	100
	032344	000000	.WORD	T%L%L%I%M
	032346	000001	.WORD	T%H%I%L%I%M
5198	032350		GPRMD	MINHD, MNH, D, 100, 0, 1, YES
	032350	013052	.WORD	T%CODE
	032352	033104	.WORD	MINHD
	032354	000100	.WORD	100
	032356	000000	.WORD	T%L%L%I%M
	032360	000001	.WORD	T%H%I%L%I%M
5199	032362		GPRML	ASK, ANS, 1, YES
	032362	037130	.WORD	T%CODE
	032364	032442	.WORD	ASK



DRIVE INFORMATION BUFFERS

```

5200 032366 000001 .WORD 1
      032370 .XFERF 15#
5201 032370 013044 .WORD T#CODE
      032372 014052 GPRMD MXCYL,MXC,D,177600,0,511.,YF5
      032374 033113 .WORD T#CODE
      032376 177600 .WORD MXCYL
      032400 000000 .WORD 177600
      032402 000777 .WORD T#LOLIM
5202 032404 015052 GPRMD MINCYL,MNC,D,177600,0,511.,YES
      032404 033123 .WORD T#CODE
      032406 177600 .WORD MINCYL
      032410 000000 .WORD 177600
      032412 000777 .WORD T#LOLIM
      032414 000777 .WORD T#HILIM
5203 032416 016052 15#: GPRMD MXSEC,MXS,D,77,0,39.,YES
      032416 033133 .WORD T#CODE
      032420 000077 .WORD MXSEC
      032422 000000 .WORD 77
      032424 000000 .WORD T#LOLIM
      032426 000047 .WORD T#HILIM
5204 032430 017052 GPRMD MINSEC,MNS,D,77,0,39.,YES
      032430 033154 .WORD T#CODE
      032432 000077 .WORD MINSEC
      032434 000000 .WORD 77
      032436 000000 .WORD T#LOLIM
      032440 000047 .WORD T#HILIM

```

```

5205 032442 16:
5206
5207 032442 ENDSFT
      .EVEN
      032442 L10031:

```

```

5208
5212
5213 032442 103 110 101 ASK: .ASCIZ /CHANGE VALUES OF MXCYL & MINCYL/
5214 032502 123 124 111 STIPMS: .ASCIZ #STIPULATE R/W XFER SIZE#
5215 032532 123 105 105 SRTMSG: .ASCIZ /SEEK RETRY LMT/
5216 032551 043 040 117 CHKLMT: .ASCIZ /* OF ERR DUMPED/
5217 032571 122 104 040 RDONLY: .ASCIZ /RD ONLY/
5218 032601 122 101 116 RANPAT: .ASCIZ /RAN PAT/
5219 032611 127 110 111 ONLONE: .ASCIZ /WHICH ONE/
5220 032623 110 122 104 ERMSG: .ASCIZ /HRD ERR LMT/
5221 032637 123 106 124 SFTMSG: .ASCIZ /SFT ERR LMT/
5222 032653 043 040 117 DEMSG: .ASCIZ /* OF DATA ERR RPT'D PER BUF/
5223 032707 122 105 124 RTMSG: .ASCIZ /RETRY LMT/
5224 032721 123 113 040 SEMSG: .ASCIZ /SK ERR LMT/
5225 032734 104 122 040 DREMSG: .ASCIZ /DR ERR LMT/
5226 032747 104 101 124 DAMSG: .ASCIZ /DATA XFER LMT (*10(10))/
5227 032777 123 113 040 SKMSG: .ASCIZ /SK LMT (*10(3))/
5228 ;INMSG: .ASCIZ /TIME BETW REPORTS (MIN)/
5229 033017 103 110 101 CHANGE: .ASCIZ #CHANGE SEEK, R/W PARAMETERS#
5230 033053 115 101 130 MXBUF: .ASCIZ /MAX XFER/
5231 033064 115 111 116 MINBUF: .ASCIZ /MIN XFER/
5232 033075 115 101 130 MXHD: .ASCIZ /MAX HD/
5233 033104 115 111 116 MINHD: .ASCIZ /MIN HD/
5234 033113 115 101 130 MXCYL: .ASCIZ /MAX CYL/
5235 033123 115 111 116 MINCYL: .ASCIZ /MIN CYL/

```

:JSD REV A

DRIVE INFORMATION BUFFERS

```

5236 033133      123      124      101  MXSEC:  .ASCIZ  /STARTING MAX SEC/
5237 033154      123      124      101  MINSEC: .ASCIZ  /STARTING MIN SEC/
5238 033175      104      101      124  FDCHK:  .ASCIZ  /DATA DMP ON DCK ERR/
5239 033221      104      122      117  STLMT:  .ASCIZ  /DROP DR ON OPER LMTS REACHED/
5240 033256      104      122      117  DRPMS:  .ASCIZ  /DROP DR ON ERR LMTS REACHED/
5241 033312      104      101      124  DERPMS: .ASCIZ  /DATA MISCOMPARE LIMIT/
5242 033340      127      117      122  CMMSG:  .ASCIZ  /WORDS PER SECTOR COMPARED ON READ/
5243
5244
5248
5249 033402
5250
5251 033402
      033402 000000
      033404 000000
      033406
5252
5253      000001

```

```

      .EVEN
      ENDMOD
LASTAD
      .EVEN
      .WORD  0
      .WORD  0
L$LAST::
      .END

```

SYMBGL TABLE

ADDCOD 013314 G	BSEC6 027630	C#CEFG= 000045	DCRC = 004000	EPS 004054
ADR - 000020 G	BSEC7 027672	C#CLCK= 000062	DCRCER= 000022	ERLMT 010600
AFREAD 020520	BUF1 002436	C#CLEA= 000012	DCS = 000104	ERLMTM 003322
AFWRCK 020540	BUF2 002440	C#CLOS= 000035	DDT = 000016	ERMSG 032623
AGSTAT 020762	BUSAD 004132	C#CLP1= 000006	DECNT 002344	ERR = 100000
ANS = 000076	BVEC 002332	C#CVEC= 000036	DELMT 010614	ERRCNT= 000012
ARDHDR 020620	CART 002634	C#DCLN= 000044	DEMSG 032653	ERREX 021210
ASEEK 020456	CEND 024244	C#DODU= 000051	DERCNT= 000020	ERRHDR 004476
ASK 032442	CHANGE 033017	C#DRPT= 000024	DERMSG 003432	ERRVEC 002466
ASSEMB= 000010	CHFLG = 000020	C#DU = 000053	DERPHS 033312	ERR1 005070 G
AUTO = 000066	CHKFNC 020362	C#EDIT= 000003	DERR = 040000	ERR10 005646 G
AWRTF 021066	CHKLMT 032551	C#ERDF= 000055	DET = 000052	ERR12 005716 G
BA = 000002	CHKSEC 002342	C#ERHR= 000056	DIAGMC= 000000	ERR13 005724 G
BA16 = 000020	CKBDSC 027146	C#ERRO= 000060	DIFMSG 002623	ERR2 005076 G
BA17 = 000040	CKBDTK 027224	C#ERSF= 000054	DIFWD = 000066	ERR3 005162 G
BBA = 000110	CKDATA 023672	C#ERSO= 000057	DLT = 010000	ERR4 005312 G
BCSADR= 000046	CKDERR 021350	C#ESCA= 000010	DLTCNT= 000026	ERR6 005364 G
BCSR 002330	CLEAR 027124	C#ESEG= 000005	DLYCNT 002500	ERR7 005424 G
BDA = 000040	CLKACC 002512	C#ESUB= 000003	DMPBUF 026222	ERR8 005462 G
BDRSEL 002336	CLKADR 002316	C#ETST= 000001	DMPDCK 003265	ERR9 005602 G
BIT0 = 000001 G	CLKBFR 002510	C#EXIT= 000032	DNRDY 002664	ERT 004161
BIT00 = 000001 G	CLKCNT 002506	C#GETB= 000026	DOWCK = 000076	EVL = 000004 G
BIT01 = 000002 G	CLKFLD 002514	C#GETW= 000027	DPHOUR= 000070	EXHAUS 002773
BIT02 = 000004 G	CLKFRQ 002312	C#GMAN= 000043	DPMIN = 000071	EXIT 021152
BIT03 = 000010 G	CLKINI 013522	C#GPHR= 000042	DRBT = 000010	EXIT1 021204
BIT04 = 000020 G	CLKSON 002504	C#GPLO= 000030	DRBUF 030362	EXIT2 016766
BIT05 = 000040 G	CLKST 013674	C#GPRI= 000040	DRDRV 023450	EXP 004254
BIT06 = 000100 G	CLKTIK 017040 G	C#INIT= 000011	DRDY = 000001	E#END = 002100
BIT07 = 000200 G	CLKTYP 002314	C#INLP= 000020	DREMSG 032734	E#LOAD= 000035
BIT08 = 000400 G	CLMT = 000064	C#MANI= 000050	DRFLG = 000042	E.BA 002422
BIT09 = 001000 G	CLNCOD 013116 G	C#MEM = 000031	DRLMT 010650	E.CS 002420
BIT1 = 000002 G	CLRDAT 011662	C#MSG = 000023	DRMSG 032011	E.DA 002424
BIT10 = 002000 G	CMMSG 033340	C#OPEN= 000034	DRNH 004030	E.MP 002426
BIT11 = 004000 G	CMRD 010612	C#PNTB= 000014	DROP 004276	E.MP1 002430
BIT12 = 010000 G	CMSK 002270	C#PNTF= 000017	DROPCO 013400 G	E.MP2 002432
BIT13 = 020000 G	CNT = 000012	C#PNTS= 000016	DRPMS 033256	FASCII 002456
BIT14 = 040000 G	CNTFLG 002454	C#PNTX= 000015	DRPRS 002253	FASPNT 002460
BIT15 = 100000 G	CNTRLR1 002320	C#QIO = 000377	DRSEL = 000106	FDCHK 033175
BIT2 = 000004 G	CNTRLR2 002322	C#RDBU= 000007	DRST = 000013	FILINF 013442
BIT3 = 000010 G	CNTYPE 031726	C#REFG= 000047	DRTYPE 031760	FILTD 013466
BIT4 = 000020 G	CONMR 024642	C#RESE= 000033	DRUT 002252	FINDBF 012516
BIT5 = 000040 G	CRDY = 000200	C#REVI= 000003	DRVER 003061	FINERR 021312
BIT6 = 000100 G	CRLBA 002565	C#RFLA= 000021	DSE = 000400	FMTDT 010103
BIT7 = 000200 G	CRLCS 002535	C#RPT = 000025	DSPCOD 010674 G	FMTS1 007732
BIT8 = 000400 G	CRLDA 002577	C#SEFG= 000046	DMCNT 002462	FMTS1A 010015
BIT9 = 001000 G	CRLMP 002611	C#SPRI= 000041	DMCNT1 002464	FMTS1B 010035
BMP = 000042	CS = 000000	C#SVEC= 000037	EF.CON= 000036 G	FMTS2 010070
BOE = 000400 G	CSR = 000000	C#TPRI= 000013	EF.NEW= 000035 G	FMTS2A 010134
BPRIOR 002334	CSRMSG 031733	C.HDR 002434	EF.PWR= 000034 G	FMTS2B 010223
BRMSG 031747	CSTUFF 024410	DA = 000004	EF.RES= 000037 G	FMTS3 010260
BSECPT= 000112	CYL 002300	DALMT 010604	EF.STA= 000040 G	FMTS3A 010367
BSEC0 027314	CYLMSK 002264	DAMSG 032747	ELT = 000002	FMTS4 010424
BSEC1 027356	C#AU = 000052	DAT = 000006	END 012170	FMTS5 010517
BSEC2 027420	C#AUTO= 000061	DATCER= 000074	ENDBUF 031642	FMTXS 007673
BSEC3 027462	C#BRK = 000022	DCD = 000074	ENDINI 013670	FMT1 006610
BSEC4 027524	C#BSEG= 000004	DCDMSG 003407	ENDOFF 030354	FMT1A 006645
BSEC5 027566	C#BSUB= 000002	DCKFG = 000040	ENDWR 024704	FMT10 007277

SYMBOL TABLE

FMT10A	007312	GLBTXT	002516	G	I\$AU	=	000041	L\$ETP	002102	G	MAIN	014726
FMT10B	007363	GOERRX	020352		I\$AUTO	=	000041	L\$EXP1	002046	G	MAXWC	002442
FMT11	007371	GOFIN	020356		I\$CLN	=	000041	L\$EXP4	002064	G	MBDMSC	003667
FMT12	007411	GSBIT	=	000003	I\$DU	=	000041	L\$EXP5	002066	G	MDCER	003235
FMT13	007421	GSTAT	=	000004	I\$HRD	=	000041	L\$HARD	031646	G	MDERS	003070
FMT13D	007436	GSTFNC	015676		I\$INIT	=	000041	L\$HIME	002120	G	MDHEDR	002000
FMT14	007463	GWCDA	025714		I\$MOD	=	000041	L\$HPCP	002016	G	MDSER	003116
FMT14A	007472	G\$CNT0	=	000200	I\$MSG	=	000041	L\$HPTP	002022	G	MFUNC	002547
FMT14B	007504	G\$DELM	=	000372	I\$PROT	=	000040	L\$HW	010560	G	MHDER	003252
FMT14C	007501	G\$DISP	=	000003	I\$PTAB	=	000041	L\$ICP	002104	G	MINBUF	033064
FMT15	007546	G\$EXCP	=	000400	I\$PWR	=	000041	L\$INIT	010764	G	MINCYL	033123
FMT17	006632	G\$HILI	=	000002	I\$RPT	=	000041	L\$LADP	002026	G	MINMD	033104
FMT18	007666	G\$LOLI	=	000001	I\$SEG	=	000041	L\$LAST	033406	G	MINSEC	033154
FMT2	006654	G\$NO	=	000000	I\$SETU	=	000041	L\$LOAD	002100	G	MINUTE	002414
FMT2A	006675	G\$OFFS	=	000400	I\$SFT	=	000041	L\$LUN	002074	G	MK	=
FMT3	006717	G\$OFFSI	=	000376	I\$SRV	=	000041	L\$MREV	002050	G	MNB	=
FMT3A	006760	G\$PRMA	=	000001	I\$SUB	=	000041	L\$NAME	002000	G	MNC	=
FMT4	007044	G\$PRMD	=	000002	I\$TST	=	000041	L\$PRIO	002042	G	MNH	=
FMT5	007077	G\$PRML	=	000000	J\$JMP	=	000167	L\$PROT	010756	G	MNS	=
FMT6	007113	G\$RADA	=	000140	KILLDC		002310	L\$PRT	002112	G	MP	=
FMT7	007141	G\$RADB	=	000000	LCLK		013564	L\$REPP	002062	G	MPT	003756
FMT8	007155	G\$RADD	=	000040	LCLKCH		011100	L\$REV	002010	G	MROER	003212
FMT9	007165	G\$RADL	=	000120	LDFUNC		016524	L\$RPT	010700	G	MRLCS	002525
FMT9A	007223	G\$RADO	=	000020	LIMIT		010576	L\$SOFT	032022	G	MRT	004150
FRMT16	007624	G\$XFER	=	000004	LINE1		006014	L\$SPC	002056	G	MSFER	003042
FRQCHK	013622	G\$YES	=	000010	LINE2		006200	L\$SPCP	002020	G	MSKER	003031
FRQ50	013654	HCE	=	040000	LINE3		006270	L\$SPTP	002024	G	MST	004177
FUNC	=	HCRC	=	004000	LIST		022566	L\$STA	002030	G	MSTART	004360
F\$AU	=	HCR CER	=	000024	LOE	=	040000	L\$SW	010576	G	MST1	004214
F\$AUTO	=	HDHOME	025620		LONUM		002262	L\$TEST	002114	G	MSWRPK	004400
F\$BGN	=	HDRFND	002340		LOT	=	000010	L\$TIML	002014	G	MTCR	004777
F\$CLEA	=	HEAD	=	000100	LPS		004041	L\$UNIT	002012	G	MTDCRC	004327
F\$DU	=	HINUM	002260		LSTDA	=	000064	L10000	005074		MTDLT	004334
F\$END	=	HNF	=	010000	LSTDR1	002324		L10001	005160		MTDRV	004353
F\$HARD	=	HNFERR	=	000032	LSTDR2	002326		L10002	005310		MTEST	014464
F\$HW	=	HOE	=	100000	LSTHDR	=	000050	L10003	005362		MTGS	005007
F\$INIT	=	HOUR	002416		L\$ACP	002110		L10004	005422		MTHCRC	004321
F\$JMP	=	HPTCOD	010556	G	L\$APT	002036		L10005	005460		MTHNF	004314
F\$MOD	=	HRDPRM	031644	G	L\$AU	013314		L10006	005600		MTNXM	004346
F\$MSG	=	MWSEC	003720		L\$AUT	002070		L10007	005644		MTOPI	004341
F\$PROT	=	IBE	=	010000	L\$AUTO	012644		L10010	005714		MTRD	005047
F\$PWR	=	IDU	=	000040	L\$CCP	002106		L10011	005722		MTRM	005027
F\$RPT	=	IER	=	020000	L\$CLEA	013116		L10012	006012		MTRNH	005057
F\$SEG	=	ILLEG	003770		L\$CO	002032		L10013	010574		MTSK	005017
F\$SOFT	=	INBAD	025500		L\$DEPO	002011		L10014	010674		MTWR	005037
F\$SRV	=	INCALL	002476		L\$DESC	002122		L10015	010754		MVCER	003132
F\$SUB	=	INIEND	012642		L\$DESP	002076		L10017	012642		MVEC	004004
F\$SW	=	INITCO	010764	G	L\$DEVP	002060		L10020	013114		MXB	=
F\$TEST	=	INSMEM	004711		L\$DISP	010676		L10021	013312		MXBUF	033053
GDDAT	002402	INTEN	=	000100	L\$DLY	002116		L10022	013376		MXC	=
GETDST	024362	INTERV	002436		L\$DTP	002040		L10023	013440		MXCYL	033113
GETFNC	015244	INTR1	017046	G	L\$DTYP	002034		L10024	030356		MXH	=
GHDR	022246	INTR2	017056		L\$DU	013400		L10025	017036		MXHD	033075
GLBDAT	002242	ISDRST	024376		L\$DUT	002072		L10026	017044		MXS	=
GLBEQA	002242	ISR	=	000100	L\$DVTY	002230		L10027	021310		MXSEC	033133
GLBERR	005070	ISSUE	016472		L\$EF	002052		L10030	031726		NILCLK	011274
GLBSUB	013442	IXE	=	004000	L\$ENVI	002044		L10031	032442		NOCLK	004530



SYMBOL TABLE

ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 30584 WORDS ( 120 PAGES)

DYNAMIC MEMORY: 20060 WORDS ( 77 PAGES)

ELAPSED TIME: 00:30:10

CNRLKA.BIN,CNRLKA.LST/-SP=SVCS4.MLB/ML,CNRLKA.MAC