





Y W  
A ::

1 COEEGA EEPROM SWED LANG LDR      MACRO Y05.02    Saturday 16-Feb-85 13:57    Page 1

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45

.TITLE COEEGA EEPROM SWED LANG LDR

.REM 6

IDENTIFICATION  
-----

PRODUCT CODE: AC-FF28A-MC  
PRODUCT NAME: COEEGAO EEPROM SWED LANG LDR  
PRODUCT DATE: FEBRUARY, 1985  
MAINTAINER: DIAGNOSTIC ENGINEERING

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1985 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL	PDP	UNIBUS	MASSBUS
DEC	DECUS	DECTAPE	

47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70

TABLE OF CONTENTS

- 1. PROGRAM ABSRACT
- 2. SYSTEM REQUIREMENTS
- 3. LOADING AND STARTING PROCEDURES
- 4. SPECIAL ENVIRONMENTS
- 5. PROGRAM OPTIONS
- 6. EXECUTION TIMES
- 7. ERROR INFORMATION
- 8. EXAMPLES
- 9. PROGRAM DESCRIPTION

72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117  
118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128

### 1. PROGRAM ABSTRACT

The KDJ11-B is a PDP-11 CPU that incorporates the J11 chip set as the heart of the processor. It is a quad height Q22 bus module. The KDJ11-B has two on-board ROM's. One of them, the 16-bit addressable ROM, contains the self-test and the boot codes. The other ROM, the 8-bit addressable one, contains the base area with hardware selection parameters, optional bootstraps, optional UFD (User Friendly Diagnostic) system description area, and optional foreign language text.

On units to be shipped to non-English speaking countries, a dummy or "null" language is loaded into the EEPROM. The purpose of this is to disable English language error messages when the system is first installed. If and when the system passes its internal self tests, the user will be instructed to run a UFD (User Friendly Diagnostics) package which will be part of a "country kit" for each separate language. The UFD package will use the local language for the particular country and, in addition, will load diagnostic and error messages in the local language into the EEPROM, so each subsequent power-up or reboot will have diagnostic and error messages in the user's own language.

The purpose of this program is to load the local language into the EEPROM. If it detects an error, the program will attempt to restore the "old" language, if any and will print a message informing the user of that fact.

### 2. SYSTEM REQUIREMENTS

#### Hardware Requirements

To run successfully this utility needs.

1. KDJ11-B CPU module
2. console terminal
3. at least 28K of memory

### 3. LOADING AND STARTING PROCEDURES

To start-up this program:

1. Boot XXDP.
2. Type "R NAME", where NAME is the name of the BIN or BIC file for this program.

The starting address of the program is 1000.

Note: if trying to restart the program in an arbitrary place after HALT on Break the following registers should be set up:

17777572=0	to disable memory management
17777520=1000	to clear diagnostic mode (bit 8), but still save HALT on Break
1777746=400	to flush the cache

130 4. SPECIAL ENVIRONMENTS  
131  
132 The program is not APT compatible.  
133  
134 5. PROGRAM OPTIONS  
135  
136 None.  
137  
138 6. EXECUTION TIMES  
139  
140 The program runs in under 20 seconds.  
141  
142 7. ERROR INFORMATION  
143  
144 7.1 DEFECTIVE BYTE IN EEPROM  
145  
146 After each write, the Byte which should have been written is  
147 compared to the Byte in the proper location, and if it is not correct,  
148 the following error message is displayed:  
149  
150 EEPROM write error, PCR page n, address mmmmm.  
151 Data written qqq, data read rrr.  
152  
153 where n is the EEPROM page selected by the Page Control Register (PCR),  
154 mmmmm is the physical address of the bad byte in question, qqq is the  
155 byte value that was written out to the address and rrr what was read  
156 back in after the write. (should be identical to qqq)  
157  
158 7.2 PROCESSOR NOT KDJ11-B  
159  
160 The program checks the type of CPU it is running on, which must be a  
161 KDJ11-B processor (MFPT returns 5 in r0). If not, the following message  
162 is printed:  
163  
164 Language area not supported by this processor.  
165  
166 7.3 "OLD" BOOT ROM CODE, LANGUAGE AREA NOT SUPPORTED  
167  
168 The program checks to see if the ROM code version is 7.0 or later.  
169 Earlier versions do not support the language area in the EEPROM  
170 and would print garbage if one was loaded. The program prints the  
171 following message in that case:  
172  
173 Current Boot ROM version does not support language area.  
174  
175 In addition, the language bit in the setup area of the EEPROM is  
176 cleared, to prevent "garbage" from being printed.  
177  
178 7.4 CHECKSUM ERROR IN SETUP AREA  
179  
180 The checksum in the setup area is checked to see if it contains a valid  
181 checksum. Also, bytes 6 and 103 (addresses 17765022 and 17765314,  
182 respectively) are checked to see if they contain 0 and 252 octal,  
183 respectively. If any of these conditions is not met, the following  
184 message is printed:  
185  
186 EEPROM checksum error in setup area.

187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217  
218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232

No attempt is made to correct a checksum error.

#### 7.5 DIFFERENCES BETWEEN UFD "QUIET" MODE AND "STANDALONE" MODE

When this program is run in UFD "Quiet" mode (which will usually be the case) none of the error messages will appear. If no error is detected, no messages whatsoever are printed. If any error is detected, the program will attempt to restore the UFD and language areas to the state they were in when the program was started. If the restoration was successful, the following message is printed in the user's language:

Unable to load <language>

where <language> is the name of the language. If the restoration was not successful, or there was no local language, the following message is printed.

Unable to load <language> - reverting to U.S. English

where <language> is as above. The program then clears the bit in the EEPROM setup area selecting a local language which means that the ROM English will be used from now on.

#### 8. EXAMPLES

After booting XXDP+ and running the program, no message should appear, just the XXDP dot prompt ( . )

If a problem occurred, one of the messages in section 7 should appear.

#### 9. PROGRAM DESCRIPTION

The program consists of a body of code which loads the language into the local language area of the EEPROM. The routine that performs the write first checks the current value of the byte to be written and if it is the same, no write is performed. This is done to extend the life of the EEPROM. The write routine also checks the value in the EEPROM after the write to insure it was written correctly. After a successful run, no message appears, after an unsuccessful attempt to write any of the bytes in the EEPROM, one of the message in section 7 appears. If run under UFD "Quiet" mode, no message is printed if the program was successful, otherwise one of the messages in 7.5 appear. In both cases, the XXDP prompt appears.

ε

## PROGRAM CONSTANTS

```

234
235 000000
236
237
238
239      177520
240      177522
241      177522
242      165000
243      165316
244      165006
245      166000
246      173002
247      025370
248      000140
249      000040
250      000002
251
252      000004
253
254      177524
255      000015
256      000012
257      000200
258      000100
259      000011
260      000010
261      000040
262      000033
263
264      001550
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298

```

```

.SBTTL PROGRAM CONSTANTS
.ENABL ABS
.NLIST MD,CND
.LIST ME

BCSR = 177520
PCR = 177522
PCRLB = 177522
E2PROM = 165000
E2PAR = E2PROM+316 ;E2PROM PARITY BYTE
E2LLB = E2PROM+6 ;LOCAL LANGUAGE BIT IN E2PROM
ENDE2R = E2PROM+1000 ;LAST ADDRESS OF E2PROM+2
RMVST = 173002 ;WORD TO TEST ROM VERSION NUMBER
DELAY = 11000.
LNGHDR = 140 ;I.D. OF A LANGUAGE AREA
UFDHDR = 040 ;I.D. OF A UFD BLOCK
RETRY = 2 ;NUMBER OF ATTEMPTS TO WRITE A
;BYTE IN E2PROM BEFORE GIVING UP
MAXERR = 4 ;NO. OF ERRORS ALLOWED IN LOCAL
;LANGUAGE TEXT BEFORE QUITTING

BDR = 177524
CR = 15
LF = 12
BIT7 = 200
BIT6 = 100
tab = 11
backsp = 10
space = 40
esc = 33

ROMSZ = FLEND-TEXT ;SIZE IN BYTES OF TEXT TO BE
;LOADED INTO EEPROM

```

CHECK FOR CERTAIN EXCEPTIONS FIRST

```

310          .SBTTL CHECK FOR CERTAIN EXCEPTIONS FIRST
311
312          001000          .-1000
313
314 001000 005037 177522          START: CLR      @#PCR          ;SELECT PAGE 0 OF EEPROM
315 001004 013746 177520          MOV      @#BCSR,-(SP)      ;SAVE OLD BCSR VALUE
316 001010 112737 000067 177520  MOVB     #67,@#BCSR      ;WRITE ENABLE THE E2PROM & ENABLE ROM
317
318 001016 000007          MFPT          ;GET PROCESSOR TYPE
319 001020 020027 000005          CMP      R0,#5          ;CHECK TO SEE IF ORION
320 001024 001404          BEQ      1$            ;YES - CONTINUE
321 001026          .TYPMSG #FMSG2          ;FIELD-SERVICE MESSAGE
          .NARG NARGS
          .NTYPE NTYPE,#FMSG2
          MOV      #FMSG2,R0
          EMT      3
322 001034 000443          BR      99$
323
324 001036 012700 165000          1$:  MOV      #E2PROM,R0      ;STARTING ADDRESS TO CHECKSUM
325 001042 005001          CLR      R1            ;INITIALIZE CHECKSUM
326 001044 012703 000151          MOV      #105.,R3       ;NO. OF BYTES TO CKSUM
327 001050 012005          201$: MOV      (R0)+,R5        ;GET A BYTE
328 001052 042705 177400          BIC      #177400,R5     ;NO BUS NOISE, THANK YOU.
329 001056 060501          ADD      R5,R1          ;ACCUMULATE CHECKSUM
330 001060 077305          SOB     R3,201$        ;CONTINUE TILL DONE
331 001062 105701          TSTB    R1            ;IS CKSUM 0?
332 001064 001007          BNE     202$          ;NO, ERROR
333 001066 105737 165022          TSTB    @#E2PROM+22    ;BYTE TO TEST FOR VALID ROM, SHOULD BE 0
334 001072 001004          BNE     202$          ;NO, ERROR
335 001074 123727 165314 000252  CMPB    @#E2PROM+314,#252 ;BYTE TO TEST FOR VALID ROM
336 001102 001404          BEQ     300$          ;GO TO NEXT CHECK IF OK
337 001104          202$: .TYPMSG #FMSG4          ;FIELD SERVICE MESSAGE
          .NARG NARGS
          .NTYPE NTYPE,#FMSG4
          MOV      #FMSG4,R0
          EMT      3
338 001112 000414          BR      99$          ;QUIT
339 001114 005067 001304          300$: CLR      OLDSIZ        ;SET FLAG THAT ROM EXISTS, CURRENTLY NO LANGUAGE
340 001120 012737 000016 177522  MOV      #7*2,@#PCR     ;SEL. LAST PAGE OF 2K E2PROM, PGO OF ROM
341 001126 023727 173002          CMP     @#RMVTST,(PC)+ ;SEE IF ROM VER. 7 OR LATER (CAN SUPPORT LANGUAGE AREA)
342 001132 000250          CLN
343 001134 001405          BEQ     2$            ;YES - CONTINUE
344 001136          .TYPMSG #FMSG3
          .NARG NARGS
          .NTYPE NTYPE,#FMSG3
          MOV      #FMSG3,R0
          EMT      3
345 001144 000167 000636          99$:  JMP      QUIT1
346
347          .SBTTL SAVE OLD LANGUAGE/UPD AREA IN CASE IT MUST BE RESTORED
348
349 001150 012700 165776          2$:  MOV      #ENDE2R-2,R0   ;LAST ADDRESS (CKSUM) OF E2PROM
350 001154 012701 000005          MOV      #5,R1         ;NO. OF BYTES IN HEADER TO CHECKSUM
351 001160 010005          MOV      R0,R5         ;SAVE ADDRESS
352 001162 005003          CLR      R3
353 001164 111004          4$:  MOVB    (R0),R4        ;GET A BYTE
354 001166 060403          ADD     R4,R3          ;ACCUMULATE CHECKSUM

```



SAVE OLD LANGUAGE/UFD AREA IN CASE IT MUST BE RESTORED

```

355 001170 005740          TST      -(R0)          ;CORRECT ADDRESS
356 001172 077104          SOB      R1,4$         ;LOOP FOR 5 BYTES
357 001174 105703          TSTB    R3             ;IF NOT ZERO, NO LANGUAGE LOADED
358 001176 001131          BNE     WRLANG        ;NON-EXISTANT OR CORRUPTED LANGUAGE - SKIP
359
360 001200 014504          MOV     -(R5),R4      ;HIGH BYTE OF BYTE COUNT
361 001202 014546          MOV     -(R5),-(SP)  ;LOW BYTE OF BYTE COUNT
362 001204 110466 000001  MOVB    R4,1(SP)     ;SET UPPER BYTES OF SIZE
363 001210 042704 177437  BIC     #177437,R4    ;EXTRACT ID CODE
364 001214 012601          MOV     (SP)+,R1     ;GET SIZE BACK
365 001216 042701 160000  BIC     #160000,R1    ;R1 NOW CONTAINS SIZE OF BLOCK IN BYTES
366 001222 062701 000005  ADD     #5,R1        ;ADD BYTE COUNT FOR HEADER BLOCK
367 001226 120427 000040  CMPB   R4,#UFDHDR    ;SEE IF IT IS A UFD BLOCK
368 001232 001013          BNE     LANG         ;NO, CHECK FOR A LANGUAGE
369 001234 010104          MOV     R1,R4        ;SAVE SIZE
370 001236 012702 004654  MOV     #BUFF,R2     ;ADDRESS OF SAVE BUFFER
371 001242 004767 000666  CALL    MOVROM       ;MOVE UFD AREA TO MEMORY
372 001246 001105          BNE     WRLANG       ;BAD CKSUM, QUIT
373
374
375
376 001250 010167 001150  MOV     R1,OLDSIZ    ;SAVE TOTAL SIZE
377 001254 010167 001146  MOV     R1,UFDsiz    ;SAVE SIZE OF UFD AREA
378 001260 000500          BR      WRLANG
379
380 001262 120427 000140  LANG:  CMPB   R4,#LNGHDR ;IS THIS A LANGUAGE HEADER?
381 001266 001075          BNE     WRLANG       ;NO - QUIT
382 001270 010167 001130  MOV     R1,OLDSIZ    ;SAVE SIZE FOR NOW
383 001274 062701 000005  ADD     #5,R1        ;ADD SIZE OF (POSSIBLE) UFD HEADER
384 001300 004767 001036  CALL    ROMADR       ;SET UP PCR AND R0
385 001304 005003          CLR     R3           ;INITIALIZE CKSUM
386 001306 004767 001002  CALL    REAROM       ;GET A BYTE
387 001312 004767 000776  CALL    REAROM       ;GET A BYTE
388 001316 004767 000772  CALL    REAROM       ;GET A BYTE
389 001322 010546          MOV     R5, -(SP)    ;SAVE LOW BYTE OF SIZE FOR LATER
390 001324 004767 000764  CALL    REAROM       ;GET A BYTE
391 001330 110566 000001  MOVB    R5,1(SP)     ;SAVE HIGH BYTE OF SIZE AND ID
392 001334 004767 000754  CALL    REAROM       ;GET A BYTE
393 001340 116600 000001  MOVB    1(SP),R0     ;GET I.D.
394 001344 012601          MOV     (SP)+,R1     ;GET SIZE
395 001346 105703          TSTB    R3           ;SEE IF VALID CKSUM
396 001350 001025          BNE     1$          ;NO - WE HAVE LANGUAGE ONLY.
397
398 001352 042700 177437  BIC     #177437,R0   ;GET ID ONLY
399 001356 120027 000040  CMPB   R0,#UFDHDR   ;IS THIS A UFD BLOCK?
400 001362 001020          BNE     1$          ;NO, IGNORE IT.
401
402
403
404 001364 042701 160000  BIC     #160000,R1   ;GET RID OF ID
405 001370 062701 000005  ADD     #5,R1        ;SIZE OF HEADER
406 001374 010104          MOV     R1,R4        ;BYTE COUNT TO MOVE
407 001376 010167 001024  MOV     R1,UFDsiz    ;SAVE UFD SIZE
408 001402 066701 001016  ADD     OLDSIZ,R1    ;ADD SIZE OF LANGUAGE AREA
409 001406 012702 004654  MOV     #BUFF,R2     ;MEMORY ADDRESS TO SAVE TO
410 001412 004767 000516  CALL    MOVROM       ;SAVE UFD AREA
411 001416 001404          BEQ     2$          ;YES, IT IS VALID, CONTINUE

```

SAVE OLD LANGUAGE/UFD AREA IN CASE IT MUST BE RESTORED

```

412 001420 005067 001002          CLR      UFDSIZ          ;NO UFD AREA
413 001424 012702 004654          1$: MOV      #BUFF,R2    ;RESET R2
414 001430 016701 000770          2$: MOV      OLDSIZ,R1   ;SIZE OF LANGUAGE AREA
415 001434 010104                MOV      R1,R4          ;BYTES TO MOVE
416 001436 066767 000764 000760  ADD      UFDSIZ,OLDSIZ   ;OLDSIZ IS THE TOTAL SIZE
417 001444 004767 000464          CALL     MOVROM         ;SAVE LANGUAGE AREA
418 001450 001404                BEQ      WRLANG         ;LANGUAGE IS GOOD
419 001452 005067 000746          CLR      OLDSIZ        ;NO LANGUAGE
420 001456 005067 000744          CLR      UFDSIZ        ;NO UFD AREA
421
422                                ;GENERATE CHECKSUM FOR FOREIGN LANGUAGE TEST FILE & WRITE TO THE MEMORY IMAGE
423
424 001462 012700 003104  WRLANG: MOV     #TEXT,R0  ;ADDRESS OF BEGINNING OF TEXT
425 001466 005001                CLR      R1            ;INIT CHECKSUM
426 001470 112002                25$: MOV     (R0)+,R2    ;READ A BYTE
427 001472 160201                SUB      R2,R1         ;ACCUMULATE CHECKSUM
428 001474 020027 004646          CMP      R0,#CKSUM     ;FINISHED ALL TEXT ?
429 001500 001373                BNE     25$           ;NO-CONTINUE
430 001502 110110                MOV     R1,(R0)       ;WRITE THE CHECKSUM
431
432                                .SBTTL  LOAD LOCAL LANGUAGE INTO E2PROM
433
434                                ;WRITE UFD & LOCAL LANGUAGE BLOCKS
435
436 001504 016701 000716          MOV      UFDSIZ,R1     ;GET THE LENGTH OF THE UFD
437 001510 062701 001550          ADD      #ROMSZ,R1    ;... & THE TEXT AREA
438 001514 004767 000622          JSR      PC,ROMADR    ;COMPUTE E2PROM PAGE AND ADDR
439 001520 016701 000702          MOV      UFDSIZ,R1    ;SIZE OF UFD AREA TO SAVE
440 001524 001406                BEQ     40$           ;NO UFD AREA - SKIP
441 001526 012702 004654          MOV      #BUFF,R2    ;ADDRESS OF BEGINNING OF UFD AREA
442 001532 112205                35$: MOV     (R2)+,R5   ;GET SOME DATA
443 001534 004767 000126          CALL     E2WRIT       ;GO WRITE IT
444 001540 077104                SOB     R1,35$       ;FINISHED UFD?
445                                ;YES-DO LANGUAGE
446 001542 012702 003104          40$: MOV     #TEXT,R2  ;ADDRESS OF EEPROM LANGUAGE TEXT
447 001546 012701 001550          MOV      #ROMSZ,R1   ;BYTES TO MOVE
448 001552 112205                50$: MOV     (R2)+,R5   ;GET SOME DATA
449 001554 004767 000106          CALL     E2WRIT       ;WRITE A BYTE
450 001560 077104                SOB     R1,50$       ;ARE WE DONE?
451                                ;YES - EXIT
452 001562 112705 000200          MOV     #BIT7,R5     ;TURN ON LOCAL LANGUAGE BIT IN
453                                ;SETUP AREA, THEN EXIT
454
455 001566 105037 177522  EXIT:  CLR     @#PCRLB   ;SELECT PAGE 0
456 001572 012700 165006          MOV      #E2LLB,R0   ;E2PROM WORD CONTAINING LOCAL LANG. BIT
457 001576 111001                MOV     (R0),R1
458 001600 142701 177577          BIC     #+CBIT7,R1   ;GET CURRENT LOCAL LANGUAGE BIT
459 001604 120501                CMP     R5,R1         ;SEE IF BIT ALREADY CORRECT
460 001606 001415                BEQ     EXIT1         ;YES, JUST RETURN
461 001610 112701 000200          MOV     #BIT7,R1     ;LOCAL LANGUAGE BIT
462 001614 111005                MOV     (R0),R5     ;GET OLD WORD AGAIN
463 001616 074105                XOR     R1,R5        ;FLIP THE BIT
464 001620 004767 000336          CALL     WRBYTE       ;CHANGE LOCAL LANGUAGE BIT IN E2PROM
465 001624 001006                BNE     EXIT1         ;WOULD NOT WRITE, JUST GIVE UP
466 001626 012700 165316          MOV      #E2PAR,R0   ;ADDRESS OF CKSUM BYTE
467 001632 111005                MOV     (R0),R5     ;GET OLD CKSUM BYTE
468 001634 074105                XOR     R1,R5        ;CORRECT THE CKSUM

```

## LOAD LOCAL LANGUAGE INTO E2PROM

```

469 001636 004767 000320          CALL  WRBYTE          ;UPDATE E2ROM
470
471 001642          EXIT1:  .FRCTYP #CRLF          ;COMPLETE LINE
          .NARG  NARGS
          .NTYPE NTYPE,#CRLF
          MOV   #CRLF,R0
          EMT   44
472 001650 142716 000060          BICB  #60,(SP)          ;BE SURE ROM IS DISABLED
473 001654 012637 177520          MOV   (SP)+,@#BCSR      ;RESTORE BCSR
474 001660 005037 177522          CLR   @#PCR             ;
475 001664 000207          RTS   PC
476
477 001666 004767 000270          E2WRIT: CALL  WRBYTE          ;WRITE THE BYTE TO E2PROM
478 001672 001431          BEQ   3$               ;OK THIS TIME
479 001674 005267 000522          INC   WERR             ;FLAG BAD BYTE
480
481 001700 026727 000516 000004          CMP   WERR,#MAXERR      ;CHECK TO SEE IF PAST THE MAXIMUM ERROR
482 001706 003036          BGT   QUIT             ;LIMIT OF BAD BYTES ALLOWED
483
484 001710 020227 003201          CMP   R2,#M001          ;CHECK TO SEE IF ERROR IS IN MESSAGE
485 001714 101433          BLOS  QUIT             ;BYTE COUNT (MUST BE CORRECT)
486
487 001716 020227 004645          CMP   R2,#MEND1        ;CHECK TO BE SURE DICTIONARY AND UFD
488 001722 101030          BHI   QUIT             ;BLOCKS ARE NOT CORRUPTED
489
490 001724 132705 000140          BITB  #140,R5           ;CHECK TO SEE IF IT SHOULD BE A CONTROL
491 001730 001425          BEQ   QUIT             ;CODE (POSSIBLY DICTIONARY ENTRY)
492
493 001732 132710 000140          BITB  #140,(R0)        ;IF CONTROL CODE (DICTIONARY REFERENCE
494 001736 001422          BEQ   QUIT             ;PERHAPS) CALL IT QUIT
495
496 001740 111004          MOVB  (R0),R4           ;WE WILL LIVE WITH THIS ERROR, CORRECT
497 001742 116703 002700          MOVB  CKSUM,R3         ;THE CHECKSUM TO ACCOUNT FOR NEW VALUE
498 001746 060503          ADD   R5,R3            ;CANCEL OUT WHAT WAS SUPPOSED TO BE
499 001750 160403          SUB   R4,R3            ;CORRECT FOR ERRONEOUS VALUE
500 001752 110367 002670          MOVB  R3,CKSUM         ;PUT BACK CORRECTED VALUE
501
502 001756 062700 000002          3$:  ADD   #2,R0          ;INCREMENT LOCATION
503 001762 020027 166000          CMP   R0,#ENDE2R       ;FINISHED THIS PAGE ?
504 001766 001005          BNE   10$              ;NO-RETURN
505 001770 012700 165000          MOV   #E2PROM,R0       ;YES-RESET ADDRESS
506 001774 062737 000002 177522          ADD   #2,@#PCR         ;INCREMENT PCR TO NEXT PAGE
507 002002 000207          10$: RETURN
508
509 002004 005726          QUIT:  TST  (SP)+        ;CORRECT STACK
510 002006 032737 000100 000052  QUIT1: BIT   #BIT6,@#52      ;SEE IF UFD QUIET
511 002014 001403          BEQ   5$               ;NO
512 002016          .FRCTYP #MSG000        ;MESSAGE FOR USER IN HIS OWN LANGUAGE
          .NARG  NARGS
          .NTYPE NTYPE,#MSG000
          MOV   #MSG000,R0
          EMT   44
          002016 012700 003006
          002022 104044
513 002024 016701 000374          5$:  MOV   OLDSIZ,R1
514 002030 100704          BMI   EXIT1           ;ERROR WAS NOT ORION OR CKSUM ERROR, DO NOT
515
516 002032 001427          BEQ   40$              ;TRY TO CLEAR LANGUAGE BIT
517 002034 004767 000302          JSR   PC,ROMADR        ;IF NO OLD LANGUAGE TO RESTORE
          ;COMPUTE STARTING ADDRESS OF OLD LANG IN E2PROM

```

LOAD LOCAL LANGUAGE INTO E2PROM

```

516 002040 012702 004654      MOV      #BUFF,R2      ;STARTING ADDRESS OF OLD LANGUAGE TEXT
519 002044 112205      10$:  MOVB   (R2)+,R5      ;GET A BYTE
520 002046 004767 000110      CALL   WRBYTE        ;WRITE IT OUT
521 002052 001017      BNE    40$           ;IF ERROR, GIVE UP
522 002054 062700 000002      ADD    #2,R0         ;INCREMENT LOCATION
523 002060 020027 166000      CMP    R0,#EI.      ;FINISHED THIS PAGE ?
524 002064 001005      BNE    20$           ;NO-CONTINUE
525 002066 012700 165000      MOV    #E2PROM,R0   ;YES-RESET ADDRESS
526 002072 062737 000002 177522      ADD    #2,@PCR      ;INCREMENT PCR TO NEXT PAGE
527 002100 077117      20$:  SOB    R1,10$        ;LOOP UNTIL DONE
528 002102 026767 000320 000314      CMP    UFDSIZ,OLDSIZ ;IF THE SAME THEN NO LANGUAGE
529 002110 001254      BNE    EXIT1        ;IF LANGUAGE, LEAVE E2PROM LANG. BIT AS IT WAS
530 002112 005005      40$:  CLR    R5           ;TURN OFF LOCAL LANGUAGE BIT IN E2PROM
531 002114 036737 175760 000052      BIT    BIT6,@#52    ;SEE IF UFD QUIET
532 002122 001621      BEQ    EXIT         ;NO
533 002124      .FRCTYP #MSG001
      .NARG  NARGS
      .NTYPE NTYPE,#MSG001
      MOV    #MSG001,R0
      EMT    44
534 002132 000615      BR     EXIT         ;AND CALL IT A DAY
535
536      .SBTTL  PROGRAM SUBROUTINES
537
538      ;MOVROM - MOVE BYTES FROM EEPROM TO MEMORY
539      ;ENTRY- R1 = STARTING ADDRESS IN EEPROM (# OF BYTES FROM END)
540      ;       R2 = ADDRESS OF MEMORY BUFFER
541      ;       R4 = # OF BYTES TO MOVE
542      ;EXIT  R1 - UNCHANGED
543      ;       R2 - UPDATED MEMORY ADDRESS
544      ;       R3 = (BYTE) 0 IF VALID CKSUM
545      ;       "Z" FLAG SET IF CKSUM VALID
546
547 002134 010403      MOVROM: MOV    R4,R3      ;SAVE R4
548 002136 004767 000200      CALL   ROMADR       ;LOAD PCR AND R0 WITH LANGUAGE START AREA
549 002142 010304      MOV    R3,R4        ;RESTORE BYTE COUNT
550 002144 005003      CLR    R3           ;INIT CHECKSUM
551 002146 004767 000142      5$:  CALL   REAROM       ;GET A BYTE
552 002152 110522      MOVB   R5,(R2)+     ;SAVE IT
553 002154 077404      SOB    R4,5$        ;LOOP TILL DONE
554 002156 105703      TSTB   R3           ;IS CHECKSUM GOOD?
555 002160 000207      RETURN
556
557 002162 120510      WRBYTE: CMPB   R5,(R0)  ;IS THE NEW DATA DIFFERENT ?
558 002164 001452      BEQ    10$         ;NO-DO NOT WRITE OVER
559
560 002166 012703 000002      1$:  MOV    #RETRY,R3
561 002172 010510      MOV    R5,(R0)     ;WRITE A LOCATION
562 002174 012704 025370      MOV    #DELAY,R4   ;11 MS WAIT
563 002200 077401      SOB    R4,.         ;WASTE TIME
564 002202 120510      CMPB   R5,(R0)     ;SEE IF IT TOOK
565 002204 001442      BEQ    10$         ;YES, ALL OKAY
566 002206 077307      SOB    R3,1$       ;IF AT FIRST YOU DON'T SUCCEED...
567 002210 113704 177522      MOVB   @PCRRLB,R4  ;PCR PAGE OF BAD BYTE
568 002214 106204      ASRB   R4          ;CONVERT TO PAGE #
569 002216 062704 000060      ADD    #'0,R4      ;CONVERT TO OCTAL
570 002222 110467 000237      MOVB   R4,FMSG1A   ;STORE IT FOR PRINTING

```

## PROGRAM SUBROUTINES

```

571 002226 010046      MOV     R0,-(SP)           ;SAVE ROM ADDRESS
572 002230             .ITOA    ,#FMSG1B         ;CONVERT ROM ADDRESS TO OCTAL
                    .NARG    NARGS
                    .NTYPE   NTYPE,#FMSG1B
                    MOV     #FMSG1B,R1
                    EMT     30
                    .TYPMSG  #FMSG1           ;PRINT OUT FIRST PART OF MESSAGE
573 002236             .NARG    NARGS
                    .NTYPE   NTYPE,#FMSG1
                    MOV     #FMSG1,R0
                    EMT     3
                    BIC     #177400,R5       ;MAKE SURE R5 IS POSITIVE AND A BYTE
574 002244 042705 177400 .ITOA    R5,#DUMMY1       ;CONVERT TO OCTAL
575 002250             .NARG    NARGS
                    .NTYPE   NTYPE,R5
                    MOV     R5,R0
                    .NTYPE   NTYPE,#DUMMY1
                    MOV     #DUMMY1,R1
                    EMT     30
576 002260             .TYPMSG  #FMSG1C         ;PRINT OUT LAST 3 DIGITS OF NUMBER & MESSAGE
                    .NARG    NARGS
                    .NTYPE   NTYPE,#FMSG1C
                    MOV     #FMSG1C,R0
                    EMT     3
                    MOV     @(SP)+,R0       ;GET BYTE AT ROM ADDRESS
577 002266 013600             BIC     #177400,R0       ;GET RID OF BUS NOISE
578 002270 042700 177400 .ITOA    ,#DUMMY2       ;CONVERT TO OCTAL
579 002274             .NARG    NARGS
                    .NTYPE   NTYPE,#DUMMY2
                    MOV     #DUMMY2,R1
                    EMT     30
580 002302             .TYPMSG  #FMSG1D         ;PRINT LOWER 3 BYTES & REST OF MESSAGE
                    .NARG    NARGS
                    .NTYPE   NTYPE,#FMSG1D
                    MOV     #FMSG1D,R0
                    EMT     3
581 002310 000244             CLZ                    ;COULDN'T DO IT, SET ERROR FLAG
582 002312 000207 10$:      RETURN
583
584 ;REAROM - READS A BYTE FROM E2PROM ADDRESS (R0)+ INTO R5. AUTOMATICLY ADJUSTS
585 ;PCRLB. UPDATES CKSUM IN R3
586 ;
587 ;     ENTRY - R0     ADDRESS IN ROM TO READ FROM
588 ;           R3     PARTIAL CKSUM
589 ;           PCRLB  CORRECT VALUE FOR BYTE TO READ
590 ;     EXIT  R0     ADDRESS OF NEXT BYTE
591 ;           R3     UPDATED CKSUM
592 ;           R5     BYTE READ
593 ;           PCRLB  CORRECT VALUE FOR NEXT BYTE
594 002314 012005 REAROM: MOV     (R0)+,R5       ;GET A BYTE & UPDATE ADDR. BY 2
595 002316 060503      ADD     R5,R3           ;UPDATE CKSUM
596 002320 020027 166000  CMP     R0,#ENDE2R      ;SEE IF WE SHOULD SWITCH PAGES
597 002324 001005      BNE     10$           ;NO
598 002326 012700 165000  MOV     #E2PROM,R0     ;YES - GO TO START OF PAGE
599 002332 062737 000002 177522 ADD     #2,@#PCR       ;ADVANCE A PAGE
600 002340 000207 10$:      RETURN
601

```



PROGRAM SUBROUTINES

```

602
603 ;ROMADR - CALCULATE PAGE OFFSET FROM END OF ROM GIVEN SIZE IN BYTES
604 ; ENTRY - R1 SIZE IN BYTES
605 ; EXIT - R0 INITIAL ADDRESS FOR FIRST BYTE IN ROM
606 ; R1 SIZE IN BYTES
607 ; PCRLB CORRECT VALUE FOR FIRST BYTE IN ROM
608
609 002342 010100 ROMADR: MOV R1,R0 ;COPY BYTE COUNT
610 002344 010105 MOV R1,R5 ;SECOND COPY
611 002346 072527 177770 ASH #8.,R5 ;DIVIDE BYTE COUNT BY 256. BYTE PAGES
612 002352 012704 000010 MOV #7*1,R4 ;LAST PAGE IN 2 K PART + 1
613 002356 160504 SUB R5,R4 ;STARTING PAGE NUMBER
614
615 002360 042700 177400 BIC #177400,R0 ;LEAVE ONLY BITS 7:0
616 002364 006300 ASL R0 ;DOUBLE VALUE
617 002366 001003 BNE 20$
618 002370 012700 165000 MOV #E2PROM,R0
619 002374 000406 BR 30$ ;IF 0
620
621 002376 005400 20$: NEG R0 ;MAKE STARTING ADDRESS BITS 8:0
622 002400 042700 177000 BIC #177000,R0
623 002404 052700 165000 BIS #E2PROM,R0 ;MAKE A E2PROM ADDRESS
624 002410 005304 DEC R4 ;DECREMENT PAGE NUMBER BY 1
625
626 002412 006304 30$: ASL R4 ;MAKE PAGE NUMBER CORRECT FOR PCR
627 002414 110437 177522 MOVB R4,@PCRLB ;CORRECT PAGE IN PCRLB
628 002420 000207 RTS PC ;RETURN
629
630 002422 000000 WERR: 0 ;FLAG FOR BAD BYTE
631 002424 177777 OLDSIZ: -1 ;>0 - SIZE IN BYTES OF OLD LANGUAGE, 0 IF NO
632 ;LANGUAGE, -1 IF E2PROM MAY BE BAD/NONEXISTANT
633 002426 000000 UFDSIZ: 0 ;SIZE IN BYTES OF OLD UFD AREA
634
635 .SBTTL "FIELD SERVICE MODE" ERROR MESSAGES
636
637 .ENABL LC
638 002430 105 105 120 FMSG1: .ASCII /EEPROM write error, PCR page /
002433 122 117 115
002436 040 167 162
002441 151 164 145
002444 040 145 162
002447 162 157 162
002452 054 040 120
002455 103 122 040
002460 160 141 147
002463 145 040
639 002465 130 054 040 FMSG1A: .ASCII /X, address /
002470 141 144 144
002473 162 145 163
002476 163 040
640 002500 FMSG1B: .BLKB 6 ;FOR ADDRESS
641 002506 015 012 104 .ASCIIZ <CR><LF>/Data written /
002511 141 164 141
002514 040 167 162
002517 151 164 164
002522 145 156 040
002525 000

```

"FIELD SERVICE MODE" ERROR MESSAGES

642	002526			
643	002531			
644	002534	054	040	104
	002537	141	164	141
	002542	040	162	145
	002545	141	144	040
	002550	000		

DUMMY1: .BLKB 3 ;3 UPPER BYTES NOT TO BE PRINTED  
 FMSG1C: .BLKB 3  
 .ASCIZ /, Data read /

645	002551			
646	002554			
647	002557	056		
648	002560	015	012	000
649	002563	114	141	156
	002566	147	165	141
	002571	147	145	040
	002574	101	162	145
	002577	141	040	156
	002602	157	164	040
	002605	163	165	160
	002610	160	157	162
	002613	164	145	144
	002616	040	157	156
	002621	040	164	150
	002624	151	163	040
	002627	160	162	157
	002632	143	145	163
	002635	163	157	162
	002640	056	015	012
	002643	000		

DUMMY2: .BLKB 3 ;3 UPPER BYTES NOT TO BE PRINTED  
 FMSG1D: .BLKB 3  
 .ASCII /./  
 CRLF: .ASCIZ <CR><LF>  
 FMSG2: .ASCIZ /Language Area not supported on this processor./<CR><LF>

650	002644	103	165	162
	002647	162	145	156
	002652	164	040	142
	002655	157	157	164
	002660	040	122	117
	002663	115	040	166
	002666	145	162	163
	002671	151	157	156
	002674	040	144	157
	002677	145	163	040
	002702	156	157	164
	002705	040	163	165
	002710	160	160	157
	002713	162	164	140
	002716	154	141	156
	002721	147	165	141
	002724	147	145	040
	002727	141	162	145
	002732	141	056	015
	002735	012	000	

FMSG3: .ASCIZ /Current boot ROM version does not support language area./<CR><LF>

651	002737	103	150	145
	002742	143	153	163
	002745	165	155	040
	002750	145	162	162
	002753	157	162	040
	002756	151	156	040
	002761	105	105	120
	002764	122	117	115
	002767	040	163	145

FMSG4: .ASCIZ /Checksum error in EEPROM setup area./<CR><LF>

## "FIELD SERVICE MODE" ERROR MESSAGES

002772	164	165	160	
002775	040	141	162	
003000	145	141	056	
003003	015	012	000	
652				.SBTTL TRANSLATED LOADER ERROR MESSAGES
653 003006	015	123	171	MSG000: .ASCIZ <CR>!Systemet kan ej ladda Svenska!
003011	163	164	145	
003014	155	145	164	
003017	040	153	141	
003022	156	040	145	
003025	152	040	154	
003030	141	144	144	
003033	141	040	123	
003036	166	145	156	
003041	163	153	141	
003044	000			
654 003045	040	055	040	MSG001: .ASCIZ ! - ]tergOr till U.S. English.!<CR>
003050	135	164	145	
003053	162	147	175	
003056	162	040	164	
003061	151	154	154	
003064	040	125	056	
003067	123	056	040	
003072	105	156	147	
003075	154	151	163	
003100	150	056	015	
003103	000			
655				.SBTTL START OF AREA TO BE LOADED INTO E2PROM
656				
657				.SBTTL Svenska LANGUAGE TEXT
658				
659 003104	075			TEXT: .BYTE M001-TEXT
660 003105	010			.BYTE M002-M001
661 003106	002			.BYTE M003-M002
662 003107	006			.BYTE M004-M003
663 003110	006			.BYTE M005-M004
664 003111	005			.BYTE M006-M005
665 003112	002			.BYTE M007-M006
666 003113	002			.BYTE M010-M007
667 003114	002			.BYTE M011-M010
668 003115	000			.BYTE M012-M011
669 003116	000			.BYTE M013-M012
670 003117	000			.BYTE M014-M013
671 003120	000			.BYTE M015-M014
672 003121	000			.BYTE M016-M015
673 003122	000			.BYTE M017-M016
674 003123	000			.BYTE M020-M017
675 003124	037			.BYTE M021-M020
676 003125	025			.BYTE M022-M021
677 003126	025			.BYTE M023-M022
678 003127	117			.BYTE M024-M023
679 003130	021			.BYTE M025-M024
680 003131	001			.BYTE M026-M025
681 003132	020			.BYTE M027-M026
682 003133	004			.BYTE M030-M027
683 003134	010			.BYTE M031-M030
684 003135	012			.BYTE M032-M031

Svenska LANGUAGE TEXT

685	003136	002				.BYTE	M033-M032	
686	003137	050				.BYTE	M034-M033	
687	003140	000				.BYTE	M035-M034	
688	003141	001				.BYTE	M036-M035	
689	003142	000				.BYTE	M037-M036	
690	003143	002				.BYTE	M040-M037	
691	003144	027				.BYTE	M041-M040	
692	003145	000				.BYTE	M042-M041	
693	003146	017				.BYTE	M043-M042	
694	003147	015				.BYTE	M044-M043	
695	003150	021				.BYTE	M045-M044	
696	003151	036				.BYTE	M046-M045	
697	003152	024				.BYTE	M047-M046	
698	003153	023				.BYTE	M050-M047	
699	003154	020				.BYTE	M051-M050	
700	003155	026				.BYTE	M052-M051	
701	003156	015				.BYTE	M053-M052	
702	003157	021				.BYTE	M054-M053	
703	003160	027				.BYTE	M055-M054	
704	003161	021				.BYTE	M056-M055	
705	003162	060				.BYTE	M057-M056	
706	003163	012				.BYTE	M060-M057	
707	003164	000				.BYTE	M061-M060	
708	003165	013				.BYTE	M062-M061	
709	003166	002				.BYTE	M063-M062	
710	003167	013				.BYTE	M064-M063	
711	003170	031				.BYTE	M065-M064	
712	003171	003				.BYTE	M066-M065	
713	003172	025				.BYTE	M067-M066	
714	003173	060				.BYTE	M070-M067	
715	003174	007				.BYTE	M071-M070	
716	003175	003				.BYTE	M072-M071	
717	003176	066				.BYTE	M073-M072	
718	003177	001				.BYTE	M074-M073	
719	003200	035				.BYTE	MEND1-M074	
720	003201	123	166	145	M001:	.ASCIZ	!Svenska!	
	003204	156	163	153				
	003207	141	000					
721	003211	077	000		M002:	.ASCIZ	!?!	
722	003213	110	112	133	M003:	.ASCIZ	!HJ[LP!	
	003216	114	120	000				
723	003221	114	101	104	M004:	.ASCIZ	!LADDA!	
	003224	104	101	000				
724	003227	126	111	123	M005:	.ASCIZ	!VISA!	
	003232	101	000					
725	003234	177	000		M006:	.ASCIZ	<177>	;Setup command
726	003236	177	000		M007:	.ASCIZ	<177>	;Map command
727	003240	177	000		M010:	.ASCIZ	<177>	;Test command
728	003242				M011:			
729	003242				M012:			
730	003242				M013:			
731	003242				M014:			
732	003242				M015:			
733	003242				M016:			
734	003242				M017:			
735	003242	105	156	150	M020:	.ASCII	!Enhet!<TAB>!Enhetsnummer!<TAB>!Beskrivning!<CR>	
	003245	145	164	011				

## Svenska LANGUAGE TEXT

	003250	105	156	150	
	003253	145	164	163	
	003256	156	165	155	
	003261	155	145	162	
	003264	011	102	145	
	003267	163	153	162	
	003272	151	166	156	
	003275	151	156	147	
	003300	015			
736	003301	126	151	163	M021: .ASCII !Visa startprogrammen!<CR>
	003304	141	040	163	
	003307	164	141	162	
	003312	164	160	162	
	003315	157	147	162	
	003320	141	155	155	
	003323	145	156	015	
737	003326	123	164	141	M022: .ASCII !Startar systemet frOn!
	003331	162	164	141	
	003334	162	040	163	
	003337	171	163	164	
	003342	145	155	145	
	003345	164	040	146	
	003350	162	175	156	
738	003353	015	113	157	M023: .ASCII <CR>!Kommando Beskrivning!<CR><CR>!LADDA!<TAB>! Liser in och !
	003356	155	155	141	
	003361	156	144	157	
	003364	040	102	145	
	003367	163	153	162	
	003372	151	166	156	
	003375	151	156	147	
	003400	015	015	114	
	003403	101	104	104	
	003406	101	011	040	
	003411	114	173	163	
	003414	145	162	040	
	003417	151	156	040	
	003422	157	143	150	
	003425	040			
739	003426	163	164	141	.ASCII !startar systemet frOn enheten!<CR>!VISA!<TAB>! !
	003431	162	164	141	
	003434	162	040	163	
	003437	171	163	164	
	003442	145	155	145	
	003445	164	040	146	
	003450	162	175	156	
	003453	040	145	156	
	003456	150	145	164	
	003461	145	156	015	
	003464	126	111	123	
	003467	101	011	040	
740	003472	015	111	156	M024: .ASCII <CR>!Inllsning p0g0r !
	003475	154	173	163	
	003500	156	151	156	
	003503	147	040	160	
	003506	175	147	175	
	003511	162	040		
741	003513	057			M025: .ASCII '/'



## Svenska LANGUAGE TEXT

742	003514	124	162	171	M026:	.ASCII	!Tryck p0 <ret>: !
	003517	143	153	040			
	003522	160	175	040			
	003525	074	162	145			
	003530	164	076	072			
	003533	040					
743	003534	106	145	154	M027:	.ASCII	!Fel !
	003537	040					
744	003540	040	141	144	M030:	.ASCII	! adress !
	003543	162	145	163			
	003546	163	040				
745	003550	124	145	163	M031:	.ASCII	!Test p0g0r!
	003553	164	040	160			
	003556	175	147	175			
	003561	162					
746	003562	060	055		M032:	.ASCII	/0-/
747	003564	015	123	153	M033:	.ASCII	<CR>!Skriv ett kommando och tryck p0 <ret>: !
	003567	162	151	166			
	003572	040	145	164			
	003575	164	040	153			
	003600	157	155	155			
	003603	141	156	144			
	003606	157	040	157			
	003611	143	150	040			
	003614	164	162	171			
	003617	143	153	040			
	003622	160	175	040			
	003625	074	162	145			
	003630	164	076	072			
	003633	040					
748	003634				M034:		
749	003634	011			M035:	.BYTE	TAB
750	003635				M036:		
751	003635	015	040		M037:	.BYTE	CR,SPACE
752	003637	123	164	141	M040:	.ASCII	!Startar laddning av ROM!
	003642	162	164	141			
	003645	162	040	154			
	003650	141	144	144			
	003653	156	151	156			
	003656	147	040	141			
	003661	166	040	122			
	003664	117	115				
753	003666				M041:		
754	003666	015	115	145	M042:	.ASCII	<CR>!Meddelande 06!<CR>
	003671	144	144	145			
	003674	154	141	156			
	003677	144	145	040			
	003702	060	066	015			
755	003705	105	156	150	M043:	.ASCII	!Enhet ej klar!
	003710	145	164	040			
	003713	145	152	040			
	003716	153	154	141			
	003721	162					
756	003722	115	145	144	M044:	.ASCII	!Med'a ej laddbart!
	003725	151	141	040			
	003730	145	152	040			
	003733	154	141	144			

## Svenska LANGUAGE TEXT

	003736	144	142	141		
	003741	162	164			
757	003743	111	156	147	M045:	.ASCII !Inget media i laddningsenheten!
	003746	145	164	040		
	003751	155	145	144		
	003754	151	141	040		
	003757	151	040	154		
	003762	141	144	144		
	003765	156	151	156		
	003770	147	163	145		
	003773	156	150	145		
	003776	164	145	156		
758	004001	111	156	147	M046:	.ASCII !Inget band i enheten!
	004004	145	164	040		
	004007	142	141	156		
	004012	144	040	151		
	004015	040	145	156		
	004020	150	145	164		
	004023	145	156			
759	004025	123	164	171	M047:	.ASCII !Styrenhet finns ej.!
	004030	162	145	156		
	004033	150	145	164		
	004036	040	146	151		
	004041	156	156	163		
	004044	040	145	152		
	004047	054				
760	004050	105	156	150	M050:	.ASCII !Enheten finns ej!
	004053	145	164	145		
	004056	156	040	146		
	004061	151	156	156		
	004064	163	040	145		
	004067	152				
761	004070	117	147	151	M051:	.ASCII !Ogiltigt enhetsnummer !
	004073	154	164	151		
	004076	147	164	040		
	004101	145	156	150		
	004104	145	164	163		
	004107	156	165	155		
	004112	155	145	162		
	004115	040				
762	004116	117	147	151	M052:	.ASCII !Ogiltig enhet!
	004121	154	164	151		
	004124	147	040	145		
	004127	156	150	145		
	004132	164				
763	004133	106	145	154	M053:	.ASCII !Fel i styrenheten!
	004136	040	151	040		
	004141	163	164	171		
	004144	162	145	156		
	004147	150	145	164		
	004152	145	156			
764	004154	106	145	154	M054:	.ASCII !Fel p0 laddningsenheten!
	004157	040	160	175		
	004162	040	154	141		
	004165	144	144	156		
	004170	151	156	147		
	004173	163	145	156		

## Svenska LANGUAGE TEXT

	004176	150	145	164			
	004201	145	156				
765	004203	015	015	114	M055:	.ASCII	<CR><CR>!Laddning p0g0r !
	004206	141	144	144			
	004211	156	151	156			
	004214	147	040	160			
	004217	175	147	175			
	004222	162	040				
766	004224	015	123	145	M056:	.ASCII	<CR>!Se avsnitt fels)kning i Handledning f)r hjllp!
	004227	040	141	166			
	004232	163	156	151			
	004235	164	164	040			
	004240	146	145	154			
	004243	163	174	153			
	004246	156	151	156			
	004251	147	040	151			
	004254	040	110	141			
	004257	156	144	154			
	004262	145	144	156			
	004265	151	156	147			
	004270	040	146	174			
	004273	162	040	150			
	004276	152	173	154			
	004301	160					
767	004302	015	015			.ASCII	<CR><CR>
768	004304	033	133	062	M057:	.ASCII	<ESC>/[2J/ ;Erase screen
	004307	112					
769	004310	033	133	065		.ASCII	<ESC>/[5;0H/ ;Set cursor to line 5 and col 1
	004313	073	060	110			
770	004316				M060:		
771	004316	115	145	144	M061:	.ASCII	!Meddelande !
	004321	144	145	154			
	004324	141	156	144			
	004327	145	040				
772	004331	015	015		M062:	.BYTE	CR,CR
773	004333	015	015	113	M063:	.ASCII	<CR><CR>/KDJI1-B >/
	004336	104	112	061			
	004341	061	055	102			
	004344	040	076				
774	004346	015	106	145	M064:	.ASCII	<CR>!Fel vid EEPROM laddning!<CR>
	004351	154	040	166			
	004354	151	144	040			
	004357	105	105	120			
	004362	122	117	115			
	004365	040	154	141			
	004370	144	144	156			
	004373	151	156	147			
	004376	015					
775	004377	010	040	010	M065:	.BYTE	BACKSP,SPACE,BACKSP
776	004402	015	106	145	M066:	.ASCII	<CR>!Felaktigt kommando.!<CR>
	004405	154	141	153			
	004410	164	151	147			
	004413	164	040	153			
	004416	157	155	155			
	004421	141	156	144			
	004424	157	056	015			
777	004427	015	015	124	M067:	.ASCII	<CR><CR>!Tillgngliga kommandon: Hjllp, Ladda och Visa.!

## Svenska LANGUAGE TEXT

	004432	151	154	154	
	004435	147	173	156	
	004440	147	154	151	
	004443	147	141	040	
	004446	153	157	155	
	004451	155	141	156	
	004454	144	157	156	
	004457	072	040	110	
	004462	152	173	154	
	004465	160	054	040	
	004470	114	141	144	
	004473	144	141	040	
	004476	157	143	150	
	004501	040	126	151	
	004504	163	141	056	
778	004507	101	144	162	M070: .ASCII !Adress !
	004512	145	163	163	
	004515	040			
779	004516	040	075	040	M071: .ASCII / = /
780	004521	123	153	162	M072: .ASCII !Skriv enhet och enhetsnummer tryck direfter p0 <ret>: !
	004524	151	166	040	
	004527	145	156	150	
	004532	145	164	040	
	004535	157	143	150	
	004540	040	145	156	
	004543	150	145	164	
	004546	163	156	165	
	004551	155	155	145	
	004554	162	040	164	
	004557	162	171	143	
	004562	153	040	144	
	004565	173	162	145	
	004570	146	164	145	
	004573	162	040	160	
	004576	175	040	074	
	004601	162	145	164	
	004604	076	072	040	
781	004607	011			M073: .BYTE TAB
782	004610	015	123	164	M074: .ASCII <CR>!Starter automatisk laddning!<CR>
	004613	141	162	164	
	004616	141	162	040	
	004621	141	165	164	
	004624	157	155	141	
	004627	164	151	163	
	004632	153	040	154	
	004635	141	144	144	
	004640	156	151	156	
	004643	147	015		
783	004645				MEND1:
784					.SBTTL NULL DICTIONARY BLOCK, CHECKSUM AND LANGUAGE HEADER
785	004645				wb:
786	004645	001			ENGWRD: .BYTE ENDBLK-ENGWRD
787	004646				ENDBLK:
788					
789					
790	004646				WEND:
791					

NULL DICTIONARY BLOCK, CHECKSUM AND LANGUAGE HEADER

```

792 004646    000                    CKSUM: .byte 0            ;checksum
793
794
795 004647                    MEND:                    ;END OF NULL TEXT
796
797 004647                    ME:
798 004647                    WE:
799
800                    ;FOREIGN LANGUAGE HEADER
801
802                    000002                    B1        =        WE-WB&377                    ;DICTIONARY BYTE COUNT 7:0
803                    000000                    B2        =        WE-WB&17400/256.                    ;DICTIONARY BYTE COUNT 10:8
804                    000143                    B3        =        MEND-text&377                    ;TEXT BYTE COUNT 7:0
805                    000143                    B4        =        MEND-text&017400/256.!140                    ;TEXT BYTE COUNT 12:8 & ID=011
806
807 004647                    .BYTE B1
808 004650                    .BYTE B2
809 004651                    .BYTE B3
810 004652                    .BYTE B4
811 004653                    .BYTE -<B1+B2+B3+B4>&377                    ;THIS BYTE IS HEADER CHECKSUM
812
813 004654                    FLEND:
814 004654                    BUFF:                    ;TEMPORARY SAVE AREA FOR OLD AREA
815                    001000                    .END                    START

```



Symbol table

BACKSP=	000010	FLEND	004654	M010	003240	M042	003666	M074	004610
BCSR	= 177520	FMSG1	002430	M011	003242	M043	003705	NARGS	= 000001
BDR	= 177524	FMSG1A	002465	M012	003242	M044	003722	NTYPE	= 000027
BIT6	= 000100	FMSG1B	002500	M013	003242	M045	003743	OLDSIZ	002424
BIT7	= 000200	FMSG1C	002531	M014	003242	M046	004001	PCR	= 177522
BUFF	004654	FMSG1D	002554	M015	003242	M047	004025	PCRLB	= 177522
B1	= 000002	FMSG2	002563	M016	003242	M050	004050	QUIT	002004
B2	= 000000	FMSG3	002644	M017	003242	M051	004070	QUIT1	002006
B3	= 000143	FMSG4	002737	M020	003242	M052	004116	REAROM	002314
B4	= 000143	LANG	001262	M021	003301	M053	004133	RETRY	= 000002
CKSUM	004646	LF	= 000012	M022	003326	M054	004154	RMVTST	= 173002
CR	= 000015	LNGHDR	= 000140	M023	003353	M055	004203	ROMADR	002342
CRLF	002560	MAXERR	= 000004	M024	003472	M056	004224	ROMSZ	= 001550
DELAY	= 025370	ME	004647	M025	003513	M057	004304	SPACE	= 000040
DUMMY1	002526	MEND	004647	M026	003514	M060	004316	START	001000
DUMMY2	002551	MEND1	004645	M027	003534	M061	004316	TAB	= 000011
ENDBLK	004646	MOVROM	002134	M030	003540	M062	004331	TEXT	003104
ENDE2R	= 166000	MSG000	003006	M031	003550	M063	004333	UFDHDR	= 000040
ENGWRD	004645	MSG001	003045	M032	003562	M064	004346	UFDISZ	002426
ESC	= 000033	M001	003201	M033	003564	M065	004377	WB	004645
EXIT	001566	M002	003211	M034	003634	M066	004402	WE	004647
EXIT1	001642	M003	003213	M035	003634	M067	004427	WEND	004646
E2LLB	= 165006	M004	003221	M036	003635	M070	004507	WERR	002422
E2PAR	= 165316	M005	003227	M037	003635	M071	004516	WRBYTE	002162
E2PROM	= 165000	M006	003234	M040	003637	M072	004521	WRLANG	001462
E2WRIT	001666	M007	003236	M041	003666	M073	004607		

. ABS. 004654 000 (RW,I,GBL,ABS,OVR)  
 000000 001 (RW,I,LCL,REL,CON)

Errors detected: 0

\*\*\* Assembler statistics

Work file reads: 0  
 Work file writes: 0  
 Size of work file: 8553 Words ( 34 Pages)  
 Size of core pool: 19402 Words ( 74 Pages)  
 Operating system: RSX-11M/PLUS (Under VAX/VMS)

Elapsed time: 00:00:15.04  
 OEEGA0.BIC,COEEGA0/CR/-SP=COEEGA0

SYMBOL CROSS REFERENCE

CREF V02

SYMBOL	VALUE	REFERENCES	CREF	V02						
BACKSP	000010	#5-260	6-775	6-775						
BCSR	177520	#5-239	6-315	*6-316	*6-473					
BDR	177524	#5-254								
BIT6	000100	#5-258	6-510	6-531						
BIT7	000200	#5-257	6-452	6-458	6-461					
BUFF	004654	6-370	6-409	6-413	6-441	6-518	#6-814			
B1	000002	#6-802	6-807	6-811						
B2	000000	#6-803	6-808	6-811						
B3	000143	#6-804	6-809	6-811						
B4	000143	#6-805	6-810	6-811						
CKSUM	004646	6-428	6-497	*6-500	#6-792					
CR	000015	#5-255	6-641	6-648	6-649	6-650	6-651	6-653	6-654	6-735
		6-736	6-738	6-738	6-738	6-739	6-740	6-747	6-751	6-754
		6-754	6-765	6-765	6-766	6-767	6-767	6-772	6-772	6-773
		6-773	6-774	6-774	6-776	6-776	6-777	6-777	6-782	6-782
CRLF	002560	6-471	6-471	#6-648						
DELAY	025370	#5-247	6-562							
DUMMY1	002526	6-575	6-575	#6-642						
DUMMY2	002551	6-579	6-579	#6-645						
ENDBLK	004646	6-786	#6-787							
ENDE2R	166000	#5-245	6-349	6-503	6-523	6-596				
ENGWRD	004645	#6-786	6-786							
ESC	000033	#5-262	6-768	6-769						
EXIT	001566	#6-455	6-532	6-534						
EXIT1	001642	6-460	6-465	#6-471	6-514	6-529				
E2LLB	165006	#5-244	6-456							
E2PAR	165316	#5-243	6-466							
E2PROM	165000	#5-242	5-243	5-244	5-245	6-324	6-333	6-335	6-505	6-525
		6-598	6-618	6-623						
E2WRIT	001666	6-443	6-449	#6-477						
FLEND	004654	5-264	#6-813							
FMSG1	002430	6-573	6-573	#6-638						
FMSG1A	002465	*6-570	#6-639							
FMSG1B	002500	6-572	6-572	#6-640						
FMSG1C	002531	6-576	6-576	#6-643						
FMSG1D	002554	6-580	6-580	#6-646						
FMSG2	002563	6-321	6-321	#6-649						
FMSG3	002644	6-344	6-344	#6-650						
FMSG4	002737	6-337	6-337	#6-651						
LANG	001262	6-368	#6-380							
LF	000012	#5-256	6-641	6-648	6-649	6-650	6-651			
LNGHDR	000140	#5-248	6-380							
MAXERR	000004	#5-252	6-481							
ME	004647	#6-797								
MEND	004647	#6-795	6-804	6-805						
MEND1	004645	6-487	6-719	#6-783						
MOVROM	002134	6-371	6-410	6-417	#6-547					
MSG000	003006	6-512	6-512	#6-653						
MSG001	003045	6-533	6-533	#6-654						
M001	003201	6-484	6-659	6-660	#6-720					
M002	003211	6-660	6-661	#6-721						
M003	003213	6-661	6-662	#6-722						

## SYMBOL CROSS REFERENCE

CREF V02

SYMBOL	VALUE	REFERENCES
M004	003221	6-662 6-663 #6-723
M005	003227	6-663 6-664 #6-724
M006	003234	6-664 6-665 #6-725
M007	003236	6-665 6-666 #6-726
M010	003240	6-666 6-667 #6-727
M011	003242	6-667 6-668 #6-728
M012	003242	6-668 6-669 #6-729
M013	003242	6-669 6-670 #6-730
M014	003242	6-670 6-671 #6-731
M015	003242	6-671 6-672 #6-732
M016	003242	6-672 6-673 #6-733
M017	003242	6-673 6-674 #6-734
M020	003242	6-674 6-675 #6-735
M021	003301	6-675 6-676 #6-736
M022	003326	6-676 6-677 #6-737
M023	003353	6-677 6-678 #6-738
M024	003472	6-678 6-679 #6-740
M025	003513	6-679 6-680 #6-741
M026	003514	6-680 6-681 #6-742
M027	003534	6-681 6-682 #6-743
M030	003540	6-682 6-683 #6-744
M031	003550	6-683 6-684 #6-745
M032	003562	6-684 6-685 #6-746
M033	003564	6-685 6-686 #6-747
M034	003634	6-686 6-687 #6-748
M035	003634	6-687 6-688 #6-749
M036	003635	6-688 6-689 #6-750
M037	003635	6-689 6-690 #6-751
M040	003637	6-690 6-691 #6-752
M041	003666	6-691 6-692 #6-753
M042	003666	6-692 6-693 #6-754
M043	003705	6-693 6-694 #6-755
M044	003722	6-694 6-695 #6-756
M045	003743	6-695 6-696 #6-757
M046	004001	6-696 6-697 #6-758
M047	004025	6-697 6-698 #6-759
M050	004050	6-698 6-699 #6-760
M051	004070	6-699 6-700 #6-761
M052	004116	6-700 6-701 #6-762
M053	004133	6-701 6-702 #6-763
M054	004154	6-702 6-703 #6-764
M055	004203	6-703 6-704 #6-765
M056	004224	6-704 6-705 #6-766
M057	004304	6-705 6-706 #6-768
M060	004316	6-706 6-707 #6-770
M061	004316	6-707 6-708 #6-771
M062	004331	6-708 6-709 #6-772
M063	004333	6-709 6-710 #6-773
M064	004346	6-710 6-711 #6-774
M065	004377	6-711 6-712 #6-775
M066	004402	6-712 6-713 #6-776
M067	004427	6-713 6-714 #6-777

SYMBOL CROSS REFERENCE

CREF V02

SYMBOL	VALUE	REFERENCES
M070	004507	6-714 6-715 #6-778
M071	004516	6-715 6-716 #6-779
M072	004521	6-716 6-717 #6-780
M073	004607	6-717 6-718 #6-781
M074	004610	6-718 6-719 #6-782
NARGS	= 000001	#6-321 6-321 #6-337 6-337 #6-344 6-344 #6-471 6-471 #6-512 6-512 #6-533 6-533 #6-572 6-572 #6-573 6-573 #6-575 6-575 #6-576 6-576 #6-579 6-579 #6-580 6-580 #6-512 6-512 #6-533 6-533 #6-572 6-572 #6-573 6-573 #6-575 6-575 #6-576 6-576 #6-579 6-579 #6-580 6-580 #6-321 6-321 #6-337 6-337 #6-344 6-344 #6-471 6-471 #6-512 6-512 #6-533 6-533 #6-572 6-572 #6-573 6-573 #6-575 6-575 #6-576 6-576 #6-579 6-579 #6-580 6-580
NTYPE	= 000027	#6-321 6-321 #6-337 6-337 #6-344 6-344 #6-471 6-471 #6-512 6-512 #6-533 6-533 #6-572 6-572 #6-573 6-573 #6-575 6-575 #6-576 6-576 #6-579 6-579 #6-580 6-580
OLDSIZ	002424	#6-339 #6-376 #6-382 6-408 6-414 #6-416 #6-419 6-513 6-528
PCR	= 177522	#5-240 #6-314 #6-340 #6-474 #6-506 #6-526 #6-599
PCRLB	= 177522	#5-241 #6-455 6-567 #6-627
QUIT	002004	6-482 6-485 6-488 6-491 6-494 #6-509
QUIT1	002006	6-345 #6-510
REAROM	002314	6-386 6-387 6-388 6-390 6-392 6-551 #6-594
RETRY	= 000002	#5-250 6-560
RMVTST	= 173002	#5-246 6-341
ROMADR	002342	6-384 6-438 6-517 6-548 #6-609
ROMSZ	= 001550	#5-264 6-437 6-447
SPACE	= 000040	#5-261 6-751 6-775
START	001000	#6-314 6-815
TAB	= 000011	#5-259 6-735 6-735 6-738 6-739 6-749 6-781
TEXT	003104	5-264 6-424 6-446 #6-659 6-659 6-804 6-805
UFDHDR	= 000040	#5-249 6-367 6-399
UFDSIZ	002426	#6-377 #6-407 #6-412 6-416 #6-420 6-436 6-439 6-528 #6-633
WB	004645	#6-785 6-802 6-803
WE	004647	#6-798 6-802 6-803
WEND	004646	#6-790
WERF	002422	#6-479 6-481 #6-630
WRBY: E	002162	6-464 6-469 6-477 6-520 #6-557
WRLANG	001462	6-358 6-372 6-378 6-381 6-418 #6-424

MACRO CROSS REFERENCE

CREF V02

MACRO NAME	REFERENCES							
.FRCTY	#5-299	6-471	6-512	6-533				
.ITOA	#5-278	6-572	6-575	6-579				
.TYPMS	#5-267	6-321	6-337	6-344	6-573	6-576	6-580	