

DHU11

DHU-11 FUNC TST PART2  
CZDHWBO

COPYRIGHT (c) 1983-84  
AH-T797B-MC  
FICHE 01 OF 02

JUL 1984  
digital  
Made In USA

This microfiche card contains a grid of 14 columns and 24 rows of frames. Each frame is a small, square image, likely a scan of a document page or a data point. The frames are arranged in a regular grid pattern across the card. The text and images within the frames are too small to be legible. The card is otherwise blank, with the header information at the top.



DHU11

DHU-11 FUNC TST PART2  
CZDHVBO

COPYRIGHT (c) 1983-84  
AH-T797B-MC  
FICHE 02 OF 02

JUL 1984  
digital  
Made In USA



.REM 6

IDENTIFICATION  
-----

PRODUCT CODE: AC-T796B-MC  
PRODUCT NAME: CZDHYBO DHU-11 FUNC TST PART2  
PRODUCT DATE: 3 MARCH 1984  
MAINTAINER: ENE - DIAGNOSTICS GROUP  
AUTHOR: ANTHONY HART  
MODIFIED BY: ANTHONY HART

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1984 BY DIGITAL EQUIPMENT CORPORATION  
THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL  
DEC

PDP  
DECUS

UNIBUS  
DECTAPE

MASSBUS



\*\*\*\*\* MODIFICATION HISTORY \*\*\*\*\*

ORIGINAL RELEASE:	15-DEC-83	ANTHONY HART
VERSION 80	3-MAR-84	ANTHONY HART

THE FOLLOWING MODIFICATIONS HAVE BEEN MADE TO THE OLD CZDHVA:

THE HARDWARE QUESTION "TYPE OF LOOPBACK" HAS BEEN ALTERED TO INCLUDE THE STAGGERED LOOPBACK CONNECTORS ON THE DHU11 DISTRIBUTION PANEL (H3029).

THE HARDWARE QUESTION "BR LEVEL" HAS BEEN REMOVED.

THE MODEM SIGNAL TESTS THAT WERE IN THE OLD VERSION (CZDHVA0) HAVE NOW BEEN REMOVED TO PART CZDHW. THEY WERE TESTS: 16 THRU 23. IN CZDHVA0.

THE FOLLOWING NEW TESTS HAVE BEEN ADDED TO THIS PART:

- TEST 13 - RXTIMER REGISTER TEST
- TEST 14 - TX\_ACTION FIFO TEST
- TEST 15 - TX\_FIFO TEST



TABLE OF CONTENTS

- 1.0 GENERAL PROGRAM CONSIDERATIONS
- 1.1 PROGRAM ABSTRACT
- 1.2 SYSTEM REQUIREMENTS
- 1.3 RELATED DOCUMENTS AND STANDARDS
- 1.4 DIAGNOSTIC HIERARCHY PREREQUISITES
- 2.0 OPERATING INSTRUCTIONS
- 2.1 COMMANDS
- 2.2 SWITCHES
- 2.3 FLAGS
- 2.4 EXTENDED COMMAND SYNTAX
- 2.4.1 START COMMAND
- 2.4.1.1 TESTS SWITCH (/TESTS:<TEST-LIST>)
- 2.4.1.2 PASS SWITCH (/PASS:<PASS-CNT>)
- 2.4.1.3 FLAGS SWITCH (/FLAGS:<FLAG-LIST>)
- 2.4.1.4 END OF PASS SWITCH (/EOP:<INCR>)
- 2.4.1.5 EFFECT OF START COMMAND
- 2.4.2 RESTART COMMAND
- 2.4.2.1 TESTS, PASS, AND FLAGS SWITCHES
- 2.4.2.2 UNITS SWITCH (/UNITS:<UNIT-LIST>)
- 2.4.2.3 EFFECT OF RESTART COMMAND
- 2.4.3 CONTINUE COMMAND
- 2.4.3.1 FLAG SWITCH (/FLAGS:<FLAG-LIST>)
- 2.4.3.2 EFFECT OF CONTINUE COMMAND
- 2.4.4 PROCEED COMMAND
- 2.4.4.1 FLAGS SWITCH (/FLAGS:<FLAG-LIST>)
- 2.4.4.2 EFFECT OF PROCEED COMMAND
- 2.4.5 ADD COMMAND
- 2.4.6 EFFECT OF ADD COMMAND
- 2.4.7 DROP COMMAND
- 2.4.8 EFFECT OF DROP COMMAND
- 2.4.9 PRINT COMMAND
- 2.4.9.1 EFFECT OF PRINT COMMAND
- 2.4.10 DISPLAY COMMAND
- 2.4.10.1 EFFECT OF DISPLAY COMMAND
- 2.4.11 FLAGS COMMAND
- 2.4.11.1 EFFECT OF FLAGS COMMAND
- 2.4.12 ZFLAGS COMMAND
- 2.4.13 ZFLAGS COMMAND
- 2.4.14 CONTROL CHARACTERS
- 2.5 HARDWARE QUESTIONS
- 2.6 SOFTWARE QUESTIONS
- 2.7 EXTENDED P-TABLE DIALOGUE
- 2.8 QUICK START-UP PROCEDURE (XXDP.)
- 3.0 ERROR INFORMATION
- 3.1 TYPES OF ERROR MESSAGES
- 3.2 SPECIFIC ERROR MESSAGES
- 4.0 PERFORMANCE AND PROGRESS REPORTS
- 5.0 TEST SUMMARIES
- 6.0 EXAMPLE ERROR FREE PASS



## 1.0 GENERAL PROGRAM CONSIDERATIONS

### 1.1 PROGRAM ABSTRACT

CZDHVBO IS PART OF THE DHU-11 FUNCTIONAL VERIFICATION TEST. THIS PART OF THE TEST VERIFIES THAT THE MAJOR COMMUNICATIONS FUNCTIONS OF THE BOARD ARE FUNCTIONING CORRECTLY. THIS PROGRAM DOES NOT PERFORM EXTENSIVE DATA TRANSMISSION AND RECEPTION TESTS.

THIS DIAGNOSTIC HAS BEEN WRITTEN FOR USE WITH THE DIAGNOSTIC RUNTIME SERVICES SOFTWARE (SUPERVISOR). THESE SERVICES PROVIDE THE INTERFACE TO THE OPERATOR AND TO THE SOFTWARE ENVIRONMENT. THIS PROGRAM CAN BE USED WITH XXDP+, ACT, APT, SLIDE AND PAPER TAPE. FOR A COMPLETE DESCRIPTION OF THE RUNTIME SERVICES, REFER TO THE XXDP+ USER'S MANUAL. THERE IS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES IN THE OPERATING INSTRUCTIONS-COMMANDS OF THIS DOCUMENT.

### 1.2 SYSTEM REQUIREMENTS

THE FOLLOWING HARDWARE IS REQUIRED TO RUN THE DHU FVT:

- 0 UNIBUS PROCESSOR WITH AT LEAST 32K BYTES OF MEMORY.
- 0 DHU BOARDS INSTALLED ON THE UNIBUS.
- 0 APPROPRIATE PROGRAM LOAD DEVICE SUPPORTING XXDP+ MEDIA OR A DOWN LINE LOADING SYSTEM.

### 1.3 RELATED DOCUMENTS AND STANDARDS

- 0 XXDP+ USER'S MANUAL - DESCRIBES THE RUNNING OF DIAGNOSTICS UNDER THE XXDP+ MONITOR.

### 1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

THE PROCESSOR, THE UNIBUS, THE SYSTEM MEMORY, THE CONSOLE TERMINAL AND THE LOAD MEDIA ARE ASSUMED TO HAVE BEEN TESTED AND FOUND WORKING BEFORE THIS PROGRAM IS RUN.



## 2.0 OPERATING INSTRUCTIONS

THIS SECTION CONTAINS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES.  
 FOR DETAILED INFORMATION, REFER TO THE XXDP+ USER'S MANUAL (CHQUS).

### 2.1 COMMANDS

THERE ARE ELEVEN LEGAL COMMANDS FOR THE DIAGNOSTIC RUNTIME SERVICES  
 (SUPERVISOR). THIS SECTION LISTS THE COMMANDS AND GIVES A VERY  
 BRIEF DESCRIPTION OF THEM. THE XXDP+ USER'S MANUAL HAS MORE DETAILS.

COMMAND	EFFECT
START	START THE DIAGNOSTIC FROM AN INITIAL STATE
RESTART	START THE DIAGNOSTIC WITHOUT INITIALIZING
CONTINUE	CONTINUE AT TEST THAT WAS INTERRUPTED (AFTER +C)
PROCEED	CONTINUE FROM AN ERROR HALT
EXIT	RETURN TO XXDP+ MONITOR (XXDP+ OPERATION ONLY!)
ADD	ACTIVATE A UNIT FOR TESTING (ALL UNITS ARE CONSIDERED TO BE ACTIVE AT START TIME)
DROP	DEACTIVATE A UNIT
PRINT	PRINT STATISTICAL INFORMATION (IF IMPLEMENTED BY THE DIAGNOSTIC - SEE PERFORMANCE AND PROGRESS REPORTS SECTION OF THIS DOCUMENT)
DISPLAY	TYPE A LIST OF ALL DEVICE INFORMATION
FLAGS	TYPE THE STATE OF ALL FLAGS (SEE FLAGS SECTION)
ZFLAGS	CLEAR ALL FLAGS (SEE FLAGS SECTION)

A COMMAND CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. SO  
 YOU MAY, FOR EXAMPLE, TYPE "STA" INSTEAD OF "START".  
 MORE INFORMATION CAN BE FOUND WITHIN THE SECTION LABELLED  
 EXTENDED COMMAND SYNTAX



2.2 SWITCHES

THERE ARE SEVERAL SWITCHES WHICH ARE USED TO MODIFY SUPERVISOR OPERATION. THESE SWITCHES ARE APPENDED TO THE LEGAL COMMANDS. ALL OF THE LEGAL SWITCHES ARE TABULATED BELOW WITH A BRIEF DESCRIPTION OF EACH. IN THE DESCRIPTIONS BELOW, A DECIMAL NUMBER IS DESIGNATED BY "DDDD".

SWITCH	EFFECT
/TESTS:LIST	EXECUTE ONLY THOSE TESTS SPECIFIED IN THE LIST. LIST IS A STRING OF TEST NUMBERS, FOR EXAMPLE - /TESTS:1:5:7-10. THIS LIST WILL CAUSE TESTS 1,5,7,8,9,10 TO BE RUN. ALL OTHER TESTS WILL NOT BE RUN.
/PASS:DDDD	EXECUTE DDDD PASSES (DDDD = 1 TO 64000)
/FLAGS:FLGS	SET SPECIFIED FLAGS. SEE THE FLAGS SECTION OF THIS DOCUMENT.
/EOP:DDDD	REPORT END OF PASS MESSAGE AFTER EVERY DDDD PASSES ONLY. (DDDD = 1 TO 64000)
/UNITS:LIST	TEST/ADD/DROP ONLY THOSE UNITS SPECIFIED IN THE LIST. LIST EXAMPLE - /UNITS:0:5:10-12 USE UNITS 0,5,10,11,12 (UNIT NUMBERS = 0-63)

EXAMPLE OF SWITCH USAGE:

START/TESTS:1-5/PASS:1000/EOP:100

THE EFFECT OF THIS COMMAND WILL BE: 1) TESTS 1 THROUGH 5 WILL BE EXECUTED, 2) ALL UNITS WILL TESTED 1000 TIMES AND 3) THE END OF PASS MESSAGES WILL BE PRINTED AFTER EACH 100 PASSES ONLY. A SWITCH CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. YOU MAY, FOR EXAMPLE, TYPE "/TES:1-5" INSTEAD OF "/TESTS:1-5".

BELOW IS A TABLE THAT SPECIFIES WHICH SWITCHES CAN BE USED BY EACH COMMAND.

	TESTS	PASS	FLAGS	EOP	UNITS
START	X	X	X	X	X
RESTART	X	X	X	X	X
CONTINUE		X	X	X	
PROCEED			X		
DROP					X
ADD					X
PRINT					
DISPLAY					X
FLAGS					
ZFLAGS					
EXIT					



## 2.3 FLAGS

FLAGS ARE USED TO SET UP CERTAIN OPERATIONAL PARAMETERS SUCH AS LOOPING ON ERROR. ALL FLAGS ARE CLEARED AT STARTUP AND REMAIN CLEARED UNTIL EXPLICITLY SET USING THE FLAGS SWITCH. FLAGS ARE ALSO CLEARED AFTER A START COMMAND UNLESS SET USING THE FLAG SWITCH. THE ZFLAGS COMMAND MAY ALSO BE USED TO CLEAR ALL FLAGS. WITH THE EXCEPTION OF THE START AND ZFLAGS COMMANDS, NO COMMANDS AFFECT THE STATE OF THE FLAGS; THEY REMAIN SET OR CLEARED AS SPECIFIED BY THE LAST FLAG SWITCH.

FLAG	EFFECT
-----	-----
MOE	HALT ON ERROR - CONTROL IS RETURNED TO RUNTIME SERVICES COMMAND MODE
LOE	LOOP ON ERROR
IER*	INHIBIT ALL ERROR REPORTS
IBR*	INHIBIT ALL ERROR REPORTS EXCEPT FIRST LEVEL (FIRST LEVEL CONTAINS ERROR TYPE, NUMBER, PC, TEST AND UNIT)
IXR*	INHIBIT EXTENDED ERROR REPORTS (THOSE CALLED BY PRINTX MACRO'S)
PRI	DIRECT MESSAGES TO LINE PRINTER
PNT	PRINT TEST NUMBER AS TEST EXECUTES
BOE	"BELL" ON ERROR
UAM	UNATTENDED MODE (NO MANUAL INTERVENTION)
ISR	INHIBIT STATISTICAL REPORTS (DOES NOT APPLY TO DIAGNOSTICS WHICH DO NOT SUPPORT STATISTICAL REPORTING)
IDR	INHIBIT PROGRAM DROPPING OF UNITS
ADR	EXECUTE AUTODROP CODE
LOT	LOOP ON TEST
EVL	EXECUTE EVALUATION (ON DIAGNOSTICS WHICH HAVE EVALUATION SUPPORT)

\*SEE THE ERROR INFORMATION SECTION OF THIS DOCUMENT.

SEE THE XXDP\* USER'S MANUAL FOR MORE DETAILS ON FLAGS. YOU MAY SPECIFY MORE THAN ONE FLAG WITH THE FLAG SWITCH. FOR EXAMPLE, TO CAUSE THE PROGRAM TO LOOP ON ERROR, INHIBIT ERROR REPORTS AND TYPE A "BELL" ON ERROR, YOU MAY USE THE FOLLOWING STRING:

/FLAGS:LOE:IER:BOE



2.4 EXTENDED COMMAND SYNTAX

2.4.1 START COMMAND -

```
*****
STA(RT)/TESTS:<TEST-LIST>/PASS:<PASS-CNT>/FLAGS:
<FLAG-LIST>/EOP:<INCR>
*****
```

2.4.1.1 TESTS SWITCH (/TESTS:<TEST-LIST>) -

<TEST-LIST> IS A SEQUENCE OF DECIMAL NUMBERS (1:2 ETC.) OR RANGES OF DECIMAL NUMBERS (1-5:8-10 ETC.), SEPERATED BY COLONS, THAT SPECIFY THE TESTS TO BE EXECUTED. TESTS WILL BE EXECUTED IN NUMERICAL ORDER REGARDLESS OF THE ORDER OF SPECIFICATION. THE DEFAULT IS TO EXECUTE ALL TESTS. ON THIS AND ALL SWITCHES, THE ANGLE BRACKETS <> ARE PUNCTUATION USED IN THE DEFINITION ONLY, AND ARE NOT TO BE TYPED BY THE OPERATOR. SEE EXAMPLE AT END OF "EFFECT OF START COMMAND" SECTION.

2.4.1.2 PASS SWITCH (/PASS:<PASS-CNT>) -

<PASS-CNT> IS A DECIMAL NUMBER INDICATING THE DESIRED NUMBER OF PASSES. A PASS IS DEFINED AS THE EXECUTION OF THE FULL DIAGNOSTIC (ALL SELECTED TESTS). THE DEFAULT IS NON-ENDING EXECUTION. IN THIS CASE, EXIT FROM THE PROGRAM IS ACCOMPLISHED EITHER BY TYPING A CONTROL/C OR BY OCCURANCE OF AN ERROR WITH THE HALT ON ERROR FLAG BEING SET. THE EXIT IS A RETURN TO COMMAND MODE. SEE EXAMPLE AT END OF "EFFECT OF START COMMAND" SECTION.

2.4.1.3 FLAGS SWITCH (/FLAGS:<FLAG-LIST>) -

<FLAG-LIST> IS A SEQUENCE OF ELEMENTS OF THE FORM <FLAG>, <FLAG=1>, OR <FLAG=0>, SEPERATED BY COLONS, WHERE <FLAG> HAS ONE OF THE FOLLOWING VALUES:

HOE	HALT ON ERROR, CAUSING COMMAND MODE TO BE ENTERED WHEN AN ERROR IS ENCOUNTERED.
LOE	LOOP ON ERROR, CAUSING THE DIAGNOSTIC TO LOOP CONTINUOUSLY WITHIN THE SMALLEST DEFINED BLOCK OF CODING (SEGMENT, SUBTEST, OR TEST) CONTAINING THE ERROR.
IER	INHIBIT ERROR REPORTING.
IBE	INHIBIT BASIC ERROR REPORTS.
IXE	INHIBIT EXTENDED ERROR REPORTS.
PRI	DIRECT ALL MESSAGES TO A LINE PRINTER.
PNT	PRINT NUMBER OF TEST BEING EXECUTED.
BOE	BELL ON ERROR (NOT RELATED TO BELL PROMPTING).
UAM	RUN IN UNATTENDED MODE, BYPASSING MANUAL INTERVENTION (ILLEGAL FOR THIS DIAGNOSTIC).
ISR	INHIBIT STATISTICAL REPORTS.



IDU INHIBIT DROPPING OF UNITS BY DIAGNOSTIC.  
(HAS NO EFFECT IN THIS DIAGNOSTIC.)

LOT LOOP ON TEST.

THE FLAGS NAMED OR EQUATED TO 1 ARE SET, THOSE EQUATED TO 0 ARE CLEARED. A FLAG NOT SPECIFIED IS CLEARED. IF THE FLAGS SWITCH IS NOT GIVEN ALL FLAGS ARE CLEARED. SEE EXAMPLE AT END OF "EFFECT OF START COMMAND" SECTION.

#### 2.4.1.4 END OF PASS SWITCH (/EOP:<INCR>) -

<INCR> IS A DECIMAL NUMBER INDICATING HOW OFTEN (IN TERMS OF PASSES) IT IS DESIRED THAT THE END OF PASS MESSAGE BE PRINTED. THE DEFAULT IS AT THE END OF EVERY PASS. SEE EXAMPLE AT END OF "EFFECT OF START COMMAND" SECTION.

#### 2.4.1.5 EFFECT OF START COMMAND -

THE EFFECT OF THE START COMMAND IS TO INITIATE THE HARDWARE PARAMETER DIALOGUE, THE SOFTWARE PARAMETER DIALOGUE, THE INITIALIZATION QUESTIONS, AND THEN THE DIAGNOSTIC COMMENCES TESTING.

THE HARDWARE PARAMETER DIALOGUE COMMENCES WITH THE QUESTION "UNITS (D) ?" TO WHICH THE OPERATOR SHOULD REPLY WITH THE NUMBER OF UNITS TO BE TESTED. FOLLOWING THIS ARE THE QUESTIONS WHEREBY THE P-TABLES THEMSELVES ARE BUILT. EACH P-TABLE IS A CORE-RESIDENT TABLE CONTAINING ALL THE HARDWARE INFORMATION FOR ONE COMPLETE UNIT. EACH QUESTION IS FOLLOWED BY THE RESPONSE RADIX (D FOR DECIMAL, B FOR BINARY, O FOR OCTAL, L FOR YES/NO) IN PARENTHESES AND THE DEFAULT VALUE AFTER THE PARENTHESES. FOR THE ACTUAL HARDWARE P-TABLE QUESTIONS SEE THE "HARDWARE PARAMETERS" SECTION.

FOLLOWING THE HARDWARE QUESTIONS ARE THE SOFTWARE QUESTIONS TO BUILD THE SOFTWARE TABLES, WHICH DEFINE OPERATING PARAMETERS OF THE DIAGNOSTIC PROGRAM. THESE QUESTIONS ARE DESCRIBED IN THE "SOFTWARE PARAMETERS" SECTION.

EXAMPLE:

STA/TESTS:1:3-4:/PASS:3/FLAGS:IER:HOE=1

THIS COMMAND WILL CAUSE THREE PASSES TO BE MADE, WITH EACH PASS CONSISTING OF TESTS 1, 3, AND 4. THERE IS NO DIFFERENCE BETWEEN SAYING <FLAG> AND SAYING <FLAG=1>. THE NOTATION <FLAG=0> IS MEANINGFUL ONLY ON A COMMAND OTHER THAN START TO CLEAR A FLAG THAT WAS PREVIOUSLY SET. NOTE THAT ON ALL COMMANDS ONLY THE FIRST THREE LETTERS ARE SCANNED.



2.4.2 RESTART COMMAND -

\*\*\*\*\*  
RES(TART)/TESTS:<TEST-LIST>/PASS:<PASS-CNT>/FLAGS:  
<FLAG-LIST>/UNITS:<UNIT-LIST>  
\*\*\*\*\*

2.4.2.1 TESTS, PASS, AND FLAGS SWITCHES -

<TEST-LIST>, <PASS-CNT>, AND <FLAG-LIST> ARE AS IN THE START  
COMMAND.

2.4.2.2 UNITS SWITCH (/UNITS:<UNIT-LIST>) - <UNIT-LIST> IS A SEQUENCE  
OF DECIMAL NUMBERS (0,1 ETC.) OR RANGES OF DECIMAL NUMBERS (0-5, 8-10  
ETC.) THAT SPECIFY THE UNITS TO BE TESTED. THE NUMBERS ARE SEPARATED  
BY COLONS. THE NUMBERS MAY RANGE FROM 0 THRU N-1 (N IS THE NUMBER OF  
UNITS SPECIFIED IN THE PREVIOUS START COMMAND). THE NUMBER INDICATES  
THE POSITION OF THE P-TABLE AS THE DATA WAS ENTERED DURING THE  
HARDWARE DIAGLOGUE. THE UNITS WHICH ARE SELECTED MUST NOT HAVE BEEN  
DROPPED BY THE DROP COMMAND. SEE THE DISCUSSION OF ADD AND DROP  
COMMANDS BELOW. DEFAULT IS TO TEST ALL UNITS WHICH HAVE NOT BEEN  
DROPPED BY A DROP COMMAND.

2.4.2.3 EFFECT OF RESTART COMMAND -

THE RESTART COMMAND DIFFERS FROM THE START COMMAND IN THAT THE  
P-TABLES FROM THE PREVIOUS START COMMAND (THERE MUST HAVE BEEN ONE)  
ARE USED, INSTEAD OF NEW ONES BEING BUILT. THE UNITS SWITCH SHOULD  
NOT BE USED WITH THIS PROGRAM. THE SOFTWARE DIALOGUE MAY OPTIONALLY  
BE REEXECUTED (OPERATOR WILL BE ASKED). THE COMMAND CAN BE USED AFTER  
COMMAND MODE HAS BEEN REENTERED IN ANY OF THE THREE NORMAL WAYS: A)  
THE REQUESTED NUMBER OF PASSES HAVE BEEN MADE, B) AN ERROR WAS  
ENCOUNTERED WITH THE HALT ON ERROR FLAG SET, OR C) A CONTROL/C WAS  
ENTERED BY THE OPERATOR.

2.4.3 CONTINUE COMMAND -

\*\*\*\*\*  
CON(TINUE)/PASS:<PASS-CNT>/FLAGS:<FLAG-LIST>  
\*\*\*\*\*

2.4.3.1 FLAG SWITCH (/FLAGS:<FLAG-LIST>) -

<FLAG-LIST> IS SAME AS IN THE START COMMAND, BUT UNSPECIFIED  
FLAGS RETAIN THEIR CURRENT VALUE.



2.4.3.2 EFFECT OF CONTINUE COMMAND -

CONTINUE MUST FOLLOW A START OR RESTART, AND COMMAND MODE MUST HAVE BEEN ENTERED DUE TO A HALT ON ERROR OR A CONTROL/C. THE EFFECT OF THE COMMAND IS TO GO TO THE BEGINNING OF THE TEST THAT WAS BEING EXECUTED WHEN THE HALT OR CONTROL/C TOOK PLACE. SOFTWARE DIALOGUE MAY OPTIONALLY BE REEXECUTED. HARDWARE PARAMETERS MAY NOT BE CHANGED.

2.4.4 PROCEED COMMAND -

\*\*\*\*\*  
PRO(CEED)/FLAGS:<FLAG-LIST>  
\*\*\*\*\*

2.4.4.1 FLAGS SWITCH (/FLAGS:<FLAG-LIST>) -

<FLAG-LIST> IS AS IN THE START COMMAND, BUT UNSPECIFIED FLAGS RETAIN THEIR CURRENT VALUE.

2.4.4.2 EFFECT OF PROCEED COMMAND -

PROCEED MUST FOLLOW A START, RESTART, OR CONTINUE. COMMAND MODE MUST HAVE BEEN ENTERED VIA A HALT ON ERROR. THE EFFECT OF THE COMMAND IS TO BEGIN EXECUTION AT THE LOCATION FOLLOWING THE ERROR CALL. NEITHER HARDWARE NOR SOFTWARE PARAMETERS MAY BE ALTERED.

2.4.5 ADD COMMAND -

\*\*\*\*\*  
ADD/UNITS:<UNIT-LIST>  
\*\*\*\*\*

2.4.6 EFFECT OF ADD COMMAND -

THE UNITS SPECIFIED ARE ADDED TO THE TEST SEQUENCE. EACH UNIT MUST HAVE A P-TABLE IN MEMORY DUE TO AN EARLIER HARDWARE DIALOGUE. THIS COMMAND MUST BE FOLLOWED BY A RESTART OR CONTINUE. THE UNITS SWITCH MUST BE SPECIFIED. THE ADD COMMAND IS MEANINGFUL ONLY FOR UNITS THAT WERE PREVIOUSLY DROPPED.

2.4.7 DROP COMMAND -

\*\*\*\*\*  
DRO(P)/UNITS:<UNIT-LIST>  
\*\*\*\*\*



2.4.8 EFFECT OF DROP COMMAND -  
THE UNITS SPECIFIED WILL BE DROPPED FROM TESTING. THE UNITS  
WILL BE RESELECTED ONLY BY THE EXECUTION OF AN ADD OR START  
COMMAND. THE UNITS SWITCH MUST BE ENTERED. THIS COMMAND  
MUST BE FOLLOWED BY A RESTART OR A CONTINUE COMMAND.

2.4.9 PRINT COMMAND -  
\*\*\*\*\*  
PRI(NT)  
\*\*\*\*\*

2.4.9.1 EFFECT OF PRINT COMMAND -  
THE TOTAL NUMBER OF ERRORS FOR EACH UNIT SINCE THE LAST  
START OR RESTART COMMAND ARE PRINTED. THE ISR (INHIBIT  
STATISTICAL REPORTING) FLAG IS CLEARED.

2.4.10 DISPLAY COMMAND -  
\*\*\*\*\*  
DIS(PLAY)/UNITS:<UNIT-LIST>  
\*\*\*\*\*

2.4.10.1 EFFECT OF DISPLAY COMMAND -  
THE HARDWARE P-TABLE FOR THE TEST STATION IS PRINTED IN THE  
FORMAT IN WHICH IT WAS ENTERED.

2.4.11 FLAGS COMMAND -  
\*\*\*\*\*  
FLA(GS)  
\*\*\*\*\*

2.4.11.1 EFFECT OF FLAGS COMMAND -  
THE CURRENT SETTINGS OF ALL FLAGS ARE PRINTED.



2.4.12 ZFLAGS COMMAND -

\*\*\*\*\*  
ZFL(AGS)  
\*\*\*\*\*

2.4.13 ZFLAGS COMMAND -

ALL FLAGS ARE CLEARED.

2.4.14 CONTROL CHARACTERS -

- C A CONTROL/C (C) ENTERED DURING THE EXECUTION OF A DIAGNOSTIC CAUSES A RETURN TO COMMAND MODE.
- Z A CONTROL/Z (Z) ENTERED DURING ONE OF THE TWO OPERATOR DIALOGUES-- HARDWARE P-TABLE DIALOGUE OR SOFTWARE P-TABLE DIALOGUE CAUSES THE DEFAULTS TO BE TAKEN FOR THE REMAINDER OF THAT DIALOGUE.
- O A CONTROL/O (O) ENTERED DURING THE EXECUTION OF A DIAGNOSTIC CAUSES ALL TELETYPE OUTPUT TO BE SURPRESSED FOR THE REMAINDER OF THE DIAGNOSTIC OR UNTIL ANOTHER CONTROL/O IS TYPED, WHICH RESTORES NORMAL TELETYPE OUTPUT.



## 2.5 HARDWARE QUESTIONS

WHEN A DIAGNOSTIC IS STARTED, THE RUNTIME SERVICES WILL PROMPT THE USER FOR HARDWARE INFORMATION BY TYPING "CHANGE HW (L) ?" YOU MUST ANSWER "Y" AFTER A START COMMAND UNLESS THE HARDWARE INFORMATION HAS BEEN "PRELOADED" USING THE SETUP UTILITY (SEE CHAPTER 6 OF THE XXDP. USER'S MANUAL). WHEN YOU ANSWER THIS QUESTION WITH A "Y", THE RUNTIME SERVICES WILL ASK FOR THE NUMBER OF UNITS (IN DECIMAL). YOU WILL THEN BE ASKED THE FOLLOWING QUESTIONS FOR EACH UNIT.

1. CSR ADDRESS - THIS QUESTION REQUESTS THE CSR ADDRESS OF THE SPECIFIED DMU-11. THE DEFAULT ANSWER FOR THIS QUESTION IS ADDRESS 160460 (OCTAL).
2. INTERRUPT VECTOR ADDRESS - THIS QUESTION REQUESTS THE INTERRUPT VECTOR ADDRESS OF THE SPECIFIED DMU-11. THE DEFAULT ANSWER IS 310 (OCTAL).
3. ACTIVE LINES BIT MAP - THIS QUESTION REQUESTS AN OCTAL BIT MAP OF THE SERIAL COMMUNICATION LINES ON THE DMU11 WHICH ARE BEING SELECTED FOR TESTING. IF THE BIT IN THE BIT MAP IS SET WHICH CORRESPONDS TO A PARTICULAR LINE ( I.E. BIT 5 FOR LINE 5 ) THAT LINE WILL BE TESTED BY THE FVT.
4. TYPE OF LOOPBACK (1=INTERNAL, 2=H3029 OR H3277) - THIS QUESTION REQUESTS THE TYPE OF LOOPBACK TO BE USED WHEN TESTING THE DMU-11. THE FOLLOWING TYPES ARE SUPPORTED:
  - 0 INTERNAL - ONLY INTERNAL UART LOOPBACK IS TO BE USED IN TESTING THE DMU-11.
  - 0 H3029 OR H3277 - STAGGERED LOOPBACK CONNECTORS ARE PROVIDED ON THE DMU11 DISTRIBUTION PANEL (H3029) IF THIS DISTRIBUTION PANEL IS NOT PRESENT THEN H3277 STAGGERED BERG CONNECTOR(S) MUST BE INSTALLED ON THE BERG CONNECTOR SOCKETS OF THE DMU11.
  - 0 H325 - SINGLE LINE, 25 PIN LOOPBACK CONNECTORS (TYPE H325) ARE INSTALLED ON THE LINES TO BE TESTED.

## 2.6 SOFTWARE QUESTIONS

AFTER YOU HAVE ANSWERED THE HARDWARE QUESTIONS OR AFTER A RESTART OR CONTINUE COMMAND, THE RUNTIME SERVICES WILL ASK FOR SOFTWARE PARAMETERS. THESE PARAMETERS WILL GOVERN SOME DIAGNOSTIC SPECIFIC OPERATION MODES. YOU WILL BE PROMPTED BY "CHANGE SW (L) ?" IF YOU WISH TO CHANGE ANY PARAMETERS, ANSWER BY TYPING "Y". THE SOFTWARE QUESTIONS AND THE DEFAULT VALUES ARE DESCRIBED IN THE NEXT PARAGRAPH(S).

1. REPORT UNIT NUMBER AS EACH UNIT IS TESTED - THIS QUESTION ASKS WHETHER THE PROGRAM SHOULD REPORT THE NUMBER OF THE UNIT WHICH IT IS TESTING AS IT BEGINS TO TEST THAT UNIT.
2. EXTENDED ERROR REPORTING - THIS QUESTION ASKS WHETHER EXTENDED ERROR INFORMATION IS REQUIRED OTHER THAN THE "TEST FAILED" MESSAGE, ON EACH ERROR REPORTED. THE DEFAULT IS "NO" I.E. ONLY A MESSAGE REPORTING THE FACT THAT THE TEST FAILED WILL BE PRINTED.
3. NUMBER OF INDIVIDUAL DATA ERRORS TO REPORT ON A LINE - THIS QUESTION IS ASKED ONLY IF THE PREVIOUS QUESTION WAS ANSWERED "YES". THE QUESTION ASKS FOR THE NUMBER OF DATA ERRORS WHICH SHOULD BE REPORTED INDIVIDUALLY BY THIS PROGRAM FOR EACH LINE FOR EACH TRANSMISSION TEST. ERRORS WHICH ARE NOT REPORTED INDIVIDUALLY ARE REPORTED IN SUMMARY ERROR REPORTS.



## 2.7 EXTENDED P-TABLE DIALOGUE

WHEN YOU ANSWER THE HARDWARE QUESTIONS, YOU ARE BUILDING ENTRIES IN A TABLE THAT DESCRIBES THE DEVICES UNDER TEST. THE SIMPLEST WAY TO BUILD THIS TABLE IS TO ANSWER ALL QUESTIONS FOR EACH UNIT TO BE TESTED. IF YOU HAVE A MULTIPLEXED DEVICE SUCH AS A MASS STORAGE CONTROLLER WITH SEVERAL DRIVES OR A COMMUNICATION DEVICE WITH SEVERAL LINES, THIS BECOMES TEDIOUS SINCE MOST OF THE ANSWERS ARE REPETITIOUS.

TO ILLUSTRATE A MORE EFFICIENT METHOD, SUPPOSE YOU ARE TESTING A FICTIONAL DEVICE, THE XY11. SUPPOSE THIS DEVICE CONSISTS OF A CONTROL MODULE WITH EIGHT UNITS (SUB-DEVICES) ATTACHED TO IT. THESE UNITS ARE DESCRIBED BY THE OCTAL NUMBERS 0 THROUGH 7. THERE IS ONE HARDWARE PARAMETER THAT CAN VARY AMONG UNITS CALLED THE Q-FACTOR. THIS Q-FACTOR MAY BE 0 OR 1. BELOW IS A SIMPLE WAY TO BUILD A TABLE FOR ONE XY11 WITH EIGHT UNITS.

0 UNITS (D) ? 8<CR>

UNIT 1

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 0<CR>

Q-FACTOR (0) 0 ? 1<CR>

UNIT 2

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 1<CR>

Q-FACTOR (0) 1 ? 0<CR>

UNIT 3

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 2<CR>

Q-FACTOR (0) 0 ? <CR>

UNIT 4

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 3<CR>

Q-FACTOR (0) 0 ? <CR>

UNIT 5

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 4<CR>

Q-FACTOR (0) 0 ? <CR>

UNIT 6

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 5<CR>

Q-FACTOR (0) 0 ? <CR>

UNIT 7

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 6<CR>

Q-FACTOR (0) 0 ? 1<CR>

```
UNIT 8  
CSR ADDRESS (0) 160000<CR>  
SUB-DEVICE # (0) ? 7<CR>  
Q-FACTOR (0) 1 ? <CR>
```

NOTICE THAT THE DEFAULT VALUE FOR THE Q-FACTOR CHANGES WHEN A NON-DEFAULT RESPONSE IS GIVEN. BE CAREFUL WHEN SPECIFYING MULTIPLE UNITS!

AS YOU CAN SEE FROM THE ABOVE EXAMPLE, THE HARDWARE PARAMETERS DO NOT VARY SIGNIFICANTLY FROM UNIT TO UNIT. THE PROCEDURE SHOWN IS NOT VERY EFFICIENT.

THE RUNTIME SERVICES CAN TAKE MULTIPLE UNIT SPECIFICATIONS HOWEVER. LET'S BUILD THE SAME TABLE USING THE MULTIPLE SPECIFICATION FEATURE.

```
# UNITS (0) ? 8<CR>
```

```
UNIT 1  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 0,1<CR>  
Q-FACTOR (0) 0 ? 1,0<CR>
```

```
UNIT 3  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 2-5<CR>  
Q-FACTOR (0) 0 ? 0<CR>
```

```
UNIT 7  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 6,7<CR>  
Q-FACTOR (0) 0 ? 1<CR>
```

AS YOU CAN SEE IN THE ABOVE DIALOGUE, THE RUNTIME SERVICES WILL BUILD AS MANY ENTRIES AS IT CAN WITH THE INFORMATION GIVEN IN ANY ONE PASS THROUGH THE QUESTIONS. IN THE FIRST PASS, TWO ENTRIES ARE BUILT SINCE TWO SUB-DEVICES AND Q-FACTORS WERE SPECIFIED. THE SERVICES ASSUME THAT THE CSR ADDRESS IS 160000 FOR BOTH SINCE IT WAS SPECIFIED ONLY ONCE. IN THE SECOND PASS, FOUR ENTRIES WERE BUILT. THIS IS BECAUSE FOUR SUB-DEVICES WERE SPECIFIED. THE "-" CONSTRUCT TELLS THE RUNTIME SERVICES TO INCREMENT THE DATA FROM THE FIRST NUMBER TO THE SECOND. IN THIS CASE, SUB-DEVICES 2, 3, 4 AND 5 WERE SPECIFIED. (IF THE SUB-DEVICE WERE SPECIFIED BY ADDRESSES, THE INCREMENT WOULD BE BY 2 SINCE ADDRESSES MUST BE ON AN EVEN BOUNDARY.) THE CSR ADDRESSES AND Q-FACTORS FOR THE FOUR ENTRIES ARE ASSUMED TO BE 160000 AND 0 RESPECTIVELY SINCE THEY WERE ONLY SPECIFIED ONCE. THE LAST TWO UNITS ARE SPECIFIED IN THE THIRD PASS.

THE WHOLE PROCESS COULD HAVE BEEN ACCOMPLISHED IN ONE PASS AS SHOWN BELOW.

```
# UNITS (0) ? 8<CR>
```

```
UNIT 1
```



CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 0-7<CR>  
Q-FACTOR (0) 0 ? 0.1,0,...,1.1<CR>

AS YOU CAN SEE FROM THIS EXAMPLE, NULL REPLIES (COMMAS ENCLOSING  
A NULL FIELD) TELL THE RUNTIME SERVICES TO REPEAT THE LAST REPLY.

## 2.8 QUICK START-UP PROCEDURE (XXDP+)

TO START-UP THIS PROGRAM:

1. BOOT XXDP+
2. GIVE THE DATE AND ANSWER THE LSI/UNIBUS AND 50HZ (IF THERE IS A CLOCK) QUESTIONS. NOTE, NOT ALL VERSIONS OF XXDP+ ASK FOR THE CLOCK FREQUENCY
3. TYPE "R NAME", WHERE NAME IS THE NAME OF THE BIN OR BIC FILE FOR THIS PROGRAM
4. TYPE "START"
5. ANSWER THE "CHANGE HW" QUESTION WITH "Y"
6. ANSWER ALL THE HARDWARE QUESTIONS
7. ANSWER THE "CHANGE SW" QUESTION WITH "N"

WHEN YOU FOLLOW THIS PROCEDURE YOU WILL BE USING ONLY THE  
DEFAULTS FOR FLAGS AND SOFTWARE PARAMETERS. FOR DEFAULT INFORMATION  
SEE THE SECTIONS WITHIN THIS DOCUMENT ON FLAGS, AND HARDWARE QUESTIONS.

### 3.0 ERROR INFORMATION

#### 3.1 TYPES OF ERROR MESSAGES

THERE ARE THREE LEVELS OF ERROR MESSAGES THAT MAY BE ISSUED BY A DIAGNOSTIC: GENERAL, BASIC AND EXTENDED. GENERAL ERROR MESSAGES ARE ALWAYS PRINTED UNLESS THE "IER" FLAG IS SET (SEE THE FLAGS SECTION OF THIS DOCUMENT).

THE GENERAL ERROR MESSAGE IS OF THE FORM:

NAME TYPE NUMBER ON UNIT NUMBER TST NUMBER PC:XXXXXX  
ERROR MESSAGE

WHERE: NAME = DIAGNOSTIC NAME  
TYPE = ERROR TYPE (SYS FATAL, DEV FATAL, HARD OR SOFT)  
NUMBER = ERROR NUMBER  
UNIT NUMBER = 0 - N (N IS LAST UNIT IN PTABLE)  
TST NUMBER = TEST AND SUBTEST WHERE ERROR OCCURRED  
PC:XXXXXX = ADDRESS OF ERROR MESSAGE CALL

BASIC ERROR MESSAGES ARE MESSAGES THAT CONTAIN SOME ADDITIONAL INFORMATION ABOUT THE ERROR. THESE ARE ALWAYS PRINTED UNLESS THE "IER" OR "IBR" FLAGS ARE SET (SEE THE FLAGS SECTION OF THIS DOCUMENT).  
THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL MESSAGE.

EXTENDED ERROR MESSAGES CONTAIN SUPPLEMENTARY ERROR INFORMATION SUCH AS REGISTER CONTENTS OR GOOD/BAD DATA. THESE ARE ALWAYS PRINTED UNLESS THE "IER", "IBR" OR "IXR" FLAGS ARE SET (SEE THE FLAGS SECTION OF THIS DOCUMENT).  
THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL ERROR MESSAGE AND ANY ASSOCIATED BASIC ERROR MESSAGES.



### 3.2 SPECIFIC ERROR MESSAGES

THIS PROGRAM IS INTENDED TO PROVIDE A GO/NOGO INDICATION OF THE FUNCTIONALITY OF THE DHU-11 BOARDS. TO EXECUTE THE PROGRAM IN THIS MODE THE OPERATOR NEED ONLY ANSWER THE "EXTENDED ERROR REPORTING" SOFTWARE QUESTION WITH "NO". THE PROGRAM WILL THEN ONLY PRINT THE NAME OF THE FAILING TEST THE TEST AND ERROR NUMBERS. FOR A LIST OF THE TEST NAMES IN THIS PROGRAM SEE THE TEST SUMMARIES SECTION OF THIS DOCUMENT. AN EXAMPLE OF SUCH A AN ERROR MESSAGE IS THE FOLLOWING:

```
CZDHV DVC FTL ERR 04106 ON UNIT 00 TST 003 SUB 000 PC: XXXXXX  
DMA_ABORT BIT TEST FAILED
```

THIS ERROR INDICATES THAT A FATAL ERROR WAS ENCOUNTERED DURING THE TEST WHICH TESTS THE DMA\_ABORT BIT.

IF THE OPERATOR HAD REQUESTED EXTENDED ERROR REPORTING THE SAME ERROR WOULD BE REPORTED AS FOLLOWS:

```
CZDHV DVC FTL ERR 04106 ON UNIT 00 TST 003 SUB C00 PC: XXXXXX  
DMA_ABORT BIT TEST FAILED  
DMA_START BIT FOUND SET AFTER DMA ABORTED ON LINE: 8
```

### 4.0 PERFORMANCE AND PROGRESS REPORTS

AT THE END OF EACH PASS, THE PASS COUNT IS GIVEN ALONG WITH THE TOTAL NUMBER OF ERRORS REPORTED SINCE THE DIAGNOSTIC WAS STARTED. THE "EOP" SWITCH CAN BE USED TO CONTROL HOW OFTEN THE END OF PASS MESSAGE IS PRINTED. FOR FUTHER INFORMATION SEE THE SWITCHES SECTION OF THIS DOCUMENT.

## 5.0 TEST SUMMARIES

THE FOLLOWING ARE INCLUDED WITHIN CZDHVB:

1. DEVICE REGISTER ACCESS TEST - VERIFIES THAT THE UUT REGISTERS WILL RESPOND WITH THE CORRECT UNIBUS HANDSHAKING SIGNALS. VERIFIES THAT THE UUT IS AT THE CORRECT ADDRESS.
2. DMA.START TEST - VERIFIES THAT EACH DMA START BIT WILL INITIATE A DMA TRANSMISSION ON A LINE
3. DMA.ABORT TEST - VERIFIES THAT EACH DMA ABORT BIT WILL STOP A DMA TRANSMISSION, RETURN A TX.ACTION AND SUCCESSFULLY RESTART THE DMA.
4. DMA.ERROR TEST - VERIFIES THAT THE DMA ERROR BIT IN THE CSR REPORTS DMA ERRORS CORRECTLY WHEN THEY OCCUR.
5. O.AUTO INACTIVE TEST - VERIFIES THAT THE DUT WILL NOT RESPOND TO INCOMING XON AND XOFF CHARACTERS WHEN O.AUTO IS CLEAR.
6. O.AUTO ACTIVE TEST - VERIFIES THAT THE DUT RESPONDS CORRECTLY TO INCOMING FLOW CONTROL CHARACTERS WHEN ACTIVE
7. I.AUTO INACTIVE TEST - VERIFIES THAT THE DUT WILL NOT GENERATE XON AND XOFF CHARACTERS IN RESPONSE TO THE APPROPRIATE FIFO CONDITIONS WHEN I.AUTO IS INACTIVE.
8. I.AUTO ACTIVE TEST - VERIFIES THAT THE DUT WILL GENERATE XON AND XOFF CHARACTERS IN RESPONSE TO THE APPROPRIATE FIFO CONDITIONS WHEN I.AUTO IS ACTIVE.
9. FIFO DATA TEST - VERIFIES THAT THE FIFO WILL HOLD 256 CHARACTERS WITHOUT CORRUPTING DATA.
10. FIFO 3/4 LEVEL INACTIVE TEST - VERIFIES THAT THE 3/4 LEVEL ALARM DOES NOT BECOME ACTIVE BELOW THE 3/4 LEVEL.
11. FIFO 3/4 LEVEL ACTIVE TEST - VERIFIES THAT THE 3/4 LEVEL ALARM BECOMES ACTIVE WHEN THE FIFO IS 3/4 FULL.
12. FIFO 3/4 LEVEL ACTIVE/INACTIVE TEST - VERIFIES THAT THE 3/4 LEVEL ALARM, ONCE ACTIVATED, REMAINS ACTIVE UNTIL THE FIFO IS REDUCED BELOW THE 1/2 LEVEL.
13. FIFO 1/2 LEVEL TEST - VERIFIES THAT THE FIFO 1/2 LEVEL ALARM SYSTEM BECOMES ACTIVE AND INACTIVE AT THE CORRECT LEVELS.
14. RXTIMER TEST - VERIFIES THAT THE HOLD OFF TIMER FOR RX INTERRUPTS IS OPERATING CORRECTLY, AND THAT THE 3/4 FULL LEVEL OVERRIDES THE TIMER.



15. TX-ACTION FIFO TEST - VERIFIES THAT THE TX-ACTION FIFO CAN HOLD 16 UNIQUE TX-ACTIONS, AND THAT ONLY ONE TX INTERRUPT OCCURS FOR ALL 16 TX-ACTIONS.
16. TX FIFO TEST - VERIFIES THAT THE FIFO WILL 64 UNIQUE CHARACTERS AND ALSO THAT ONLY ONE INTERRUPT OCCURS FOR ALL 64 CHARACTERS.
17. BREAK GENERATION TEST - VERIFIES THAT ALL SERIAL TRANSMIT LINES CAN GENERATE A BREAK BY SETTING THE BRK BIT IN THE ASSOCIATED LNCTRL REGISTER.
18. NO OVERRUN ERROR TEST - VERIFIES THAT THE DUT WILL NOT REPORT DATA OVERRUN ERRORS WHEN THEY DO NOT OCCUR.
19. OVERRUN ERROR TEST - VERIFIES THAT THE DUT WILL REPORT DATA OVERRUN ERRORS WHEN THEY OCCUR.
20. REPORT BMP CODES TEST - THIS PSEUDO TEST REPORTS THE FIRST 32 CHARACTERS WHICH WERE DISCOVERED IN THE FIFO DURING THE EXECUTION OF THE OTHER TESTS. THIS AVOIDS INTERRUPTION OF THE OTHER TESTS BY THESE CODES IF THEY ARE NOT CRITICAL TO THE PERFORMANCE OF THE TESTS.

6.0 EXAMPLE ERROR FREE PASS

THE FOLLOWING IS AN EXAMPLE OF AN ERROR FREE PASS DIALOGUE:

.R CZDHSVBO  
CZDHSVBO.BIN  
DRS  
CZDHSV-B-0  
DHU-11 FUNC TST PART2  
UNIT IS DHU-11  
RESTRT ADDR: 147670  
DR>STA/PAS:1

CHANGE HW (L) ? Y

\* UNITS (D) ? 2

UNIT 0  
CSR ADDRESS: (0) 160460 ? +Z

UNIT 1  
CSR ADDRESS: (0) 160460 ? 160500  
INTERRUPT VECTOR ADDRESS: (0) 310 ? 320  
ACTIVE LINE BIT MAP: (0) 177777 ? <CR>  
TYPE OF LOOPBACK (1=INTERNAL, 2=H3029 OR H3277): (0) 2 ? 1

CHANGE SW (L) ? Y

REPORT UNIT NUMBER AS EACH UNIT IS TESTED: (L) Y ? <CR>  
EXTENDED ERROR REPORTING: (L) N ? <CR>

TESTING UNIT : 0

TESTING UNIT : 1

CZDHSV EOP 1  
0 TOTAL ERRS

DR>

ε



```

1050                                .LIST SEQ,LOC,BIN,MEB
1051                                .NLIST CND
1059
1060
1061                                .SBTTL PROGRAM HEADER
1062
1063
1064                                .MCALL SVC
1065 000000                          SVC                                ; INITIALIZE SUPERVISOR MACROS
1066
1067                                ;*****
1068                                ; IF STRUCTURED MACROS ARE TO BE USED, ADD ".MCALL STRUCT" AND "STRUCT"
1069                                ; TO INITIALIZE THE STRUCTURED MACROS.
1070
1071                                000001 SVCINS= 1 ; LIST INSTRUCTIONS, SHIFTED RIGHT
1072                                000001 SVCTST= 1 ; LIST TEST TAGS, SHIFTED RIGHT
1073                                000001 SVCSUB= 1 ; LIST SUBTEST TAGS, SHIFTED RIGHT
1074                                000001 SVCGBL= 1 ; LIST GLOBAL TAGS, SHIFTED RIGHT
1075                                000001 SVCTAG= 1 ; LIST OTHER TAGS, SHIFTED RIGHT
1076
1077                                ; CHANGE THE VALUES OF THE SVC... SYMBOLS TO BE ZERO IF YOU WISH
1078                                ; TO ALIGN THE MACRO CALLS AND THEIR EXPANSIONS. CHANGE THE
1079                                ; SYMBOLS TO BE MINUS-ONE TO NOT LIST THE EXPANSIONS. YOU MAY
1080                                ; CHANGE THE SYMBOLS AT ANY POINT IN YOUR PROGRAM.
1081                                ;*****
1082
1083 000000                          .ENABL ABS
1084
1085                                002000 .ENABL AMA
1086
1087 002000                          " 2000
1088
1089                                BGNMOD
1090
1091                                ;**
1092                                ; THE PROGRAM HEADER IS THE INTERFACE BETWEEN
1093                                ; THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
1094                                ;--
1094 002000                          POINTER BGNRPT,BGNSW,BGNSFT,BGNDU,ERRTBL
1095
1112
1113 002000                          HEADER CZDHY,B.0.22.0,PRI07
1113 002000
1113 002000 103
1113 002001 132
1113 002002 104
1113 002003 110
1113 002004 126
1113 002005 000
1113 002006 000
1113 002007 000
1113 002010
1113 002010 102
1113 002011
1113 002011 060
1113 002012
1113 002012 000000
1113 002014

```

```

L$NAME::
        .ASCII /C/
        .ASCII /Z/
        .ASCII /D/
        .ASCII /H/
        .ASCII /V/
        .BYTE 0
        .BYTE 0
        .BYTE 0
L$REV::
        .ASCII /B/
L$DEPO::
        .ASCII /O/
L$UNIT::
        .WORD 0
L$TIML::

```

002014 000022  
 002016  
 002016 035156  
 002020  
 002020 035404  
 002022  
 002022 002176  
 002024  
 002024 002210  
 002026  
 002026 035706  
 002030  
 002030 000000  
 002032  
 002032 000000  
 002034  
 002034 000000  
 002036  
 002036 000000  
 002040  
 002040 002124  
 002042  
 002042 000340  
 002044  
 002044 000000  
 002046  
 002046 000000  
 002050  
 002050 003  
 002051 003  
 002052  
 002052 000000  
 002054 000000  
 002056  
 002056 000000  
 002060  
 002060 004120  
 002062  
 002062 020030  
 002064  
 002064 000000  
 002066  
 002066 000000  
 002070  
 002070 000000  
 002072  
 002072 020704  
 002074  
 002074 000000  
 002076  
 002076 004130  
 002100  
 002100 104035  
 002102  
 002102 004050  
 002104  
 002104 020044

L\$HPCP: .WORD 22  
 L\$SPCP: .WORD L\$HARD  
 L\$HPTP: .WORD L\$SOFT  
 L\$SPTP: .WORD L\$HW  
 L\$LADP: .WORD L\$SW  
 L\$STA: .WORD L\$LAST  
 L\$CO: .WORD 0  
 L\$DTYP: .WORD 0  
 L\$APT: .WORD 0  
 L\$DTP: .WORD 0  
 L\$PRIO: .WORD L\$DISPATCH  
 L\$ENVI: .WORD PRI07  
 L\$EXP1: .WORD 0  
 L\$MREV: .WORD 0  
 L\$EF: .BYTE C\$REVISION  
 .BYTE C\$EDIT  
 L\$SPC: .WORD 0  
 L\$DEVP: .WORD 0  
 L\$REPP: .WORD L\$DVTYP  
 L\$EXP4: .WORD L\$RPT  
 L\$EXP5: .WORD 0  
 L\$AUT: .WORD 0  
 L\$DUT: .WORD L\$DU  
 L\$LUN: .WORD 0  
 L\$DESP: .WORD L\$DESC  
 L\$LOAD: .WORD L\$LOAD  
 L\$ETP: .WORD L\$ERRTBL  
 L\$ICP: .WORD L\$INIT



002106  
002106 020666  
002110  
002110 020664  
002112  
002112 020036  
002114  
002114 000000  
002116  
002116 000000  
002120  
002120 000000

1114

L\$CCP:: .WORD L\$CLEAN  
L\$ACP:: .WORD L\$AUTO  
L\$PRT:: .WORD L\$PROT  
L\$TEST:: .WORD 0  
L\$DLY:: .WORD 0  
L\$HIME:: .WORD 0

1126  
1127  
1128  
1129  
1130  
1131  
1132  
1133

.SBTTL DISPATCH TABLE

\*\*\*  
; THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.  
; IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.  
!--

DISPATCH 20

002122	000024
002124	021022
002126	021304
002130	021710
002132	022346
002134	022674
002136	023474
002140	024274
002142	024716
002144	025410
002146	025716
002150	026226
002152	026726
002154	027424
002156	030102
002160	031152
002162	031740
002164	032766
002166	033412
002170	034130
002172	035074

L\$DISPATCH::	.WORD	20
	.WORD	T1
	.WORD	T2
	.WORD	T3
	.WORD	T4
	.WORD	T5
	.WORD	T6
	.WORD	T7
	.WORD	T8
	.WORD	T9
	.WORD	T10
	.WORD	T11
	.WORD	T12
	.WORD	T13
	.WORD	T14
	.WORD	T15
	.WORD	T16
	.WORD	T17
	.WORD	T18
	.WORD	T19
	.WORD	T20

1134



1149  
1150  
1151  
1152  
1153  
1154  
1155  
1156  
1157  
1158  
1159

.SBTTL DEFAULT HARDWARE P-TABLE

```

***
; THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
; THE TEST-DEVICE PARAMETERS. THE STRUCTURE OF THIS TABLE
; IS IDENTICAL TO THE STRUCTURE OF THE HARDWARE P-TABLES,
; AND IS USED AS A "TEMPLATE" FOR BUILDING THE P-TABLES.
;--
    
```

1160 002174  
002174 000004  
002176  
002176  
1161  
1162 002176 160460  
1163 002200 000310  
1164 002202 177777  
1165 002204 002  
1166  
1167 002206  
002206

BGNHW DFPTBL

```

.WORD 160460 ;DEFAULT CSR ADDRESS
.WORD 310 ;DEFAULT VECTOR ADDRESS
.WORD 177777 ;DEFAULT ACTIVE LINES BIT MAP
.BYTE 2 ;DEFAULT LOOPBACK MODE
.EVEN
ENDHW
    
```

```

.L$HW:: .WORD L10000-L$HW/2
DFPTBL::
    
```

L10000:

1176  
 1177  
 1178  
 1179  
 1180  
 1181  
 1182  
 1183  
 1184  
 1185  
 1186  
 1187  
 1188  
 1189  
 1190  
 1191  
 1192

002206  
 002206 000002  
 002210  
 002210  
 002210 000020  
 002212 000000  
 002214  
 002214

.SBTTL SOFTWARE P-TABLE

```

; **
; THE SOFTWARE TABLE CONTAINS VARIOUS DATA USED BY THE
; PROGRAM AS OPERATIONAL PARAMETERS. THESE PARAMETERS ARE
; SET UP AT ASSEMBLY TIME AND MAY BE VARIED BY THE OPERATOR
; AT RUN TIME.
; --
    
```

BGNSW SFPTBL

```

        .WORD L10001-L$SW/2
L$SW::
SFPTBL::
    
```

```

OPTION:: .WORD 20
NDERPT:: .WORD 0
    
```

```

;BIT MAP OF PROGRAM CONTROL FLAGS
;DEFAULT NUMBER OF INDIVIDUAL DATA ERRORS TO RPT.
    
```

ENDSW

L10001:



1201  
 1202  
 1203  
 1213  
 1214  
 1215  
 1216  
 1217  
 1218  
 1219  
 1220  
 1221  
 1222  
 1223  
 1224  
 1225  
 1226  
 1227  
 1228  
 1229  
 1230  
 1231  
 1232  
 1233  
 1234  
 1235  
 1236  
 1237  
 1238  
 1239  
 1240  
 1241  
 1256 002214

.SBTTL GLOBAL EQUATES SECTION

```

; **
; THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT
; ARE USED IN MORE THAN ONE TEST.
; --
    
```

```

000020          NUMLNS==20      ;NUMBER OF LINES ON DHU11 IS 8.
177777          MAPLNS==177777 ;BIT MAP OF LINES ON DHU11.

;***** DEVICE REGISTER OFFSETS FROM THE CSR'S ADDRESS *****
000000          CSRO==0        ;CSR REGISTER OFFSET FROM THE CSR ADDRESS
000002          RBUFO==2       ;RECEIVE REGISTER OFFSET FROM THE CSR ADDRESS
000002          RXTIMO==2      ;RECIEVE TIMER REGISTER OFFSET FROM THE CSR ADDRESS
000004          LPRO==4        ;LINE PARAMETER REGISTER OFFSET FROM THE CSR ADDRESS
000006          FLSO==6       ;FIFOSIZE/STATUS REGISTER OFFSET FROM THE CSR ADDRESS
000006          FDATO==6      ;FIFODATA REGISTER OFFSET FROM THE CSR ADDRESS
000010          LNCTRO==10     ;LINE CONTROL REGISTER OFFSET FROM THE CSR ADDRESS
000012          TXAD10==12    ;TRANSMIT ADDRESS 1 REGISTER OFFSET FROM THE CSR ADDRESS
000014          TXAD20==14    ;TRANSMIT ADDRESS 2 REGISTER OFFSET FROM THE CSR ADDRESS
000016          TXBFCO==16    ;TRANSMIT COUNT REGISTER OFFSET FROM THE CSR ADDRESS

;***** EQUATES USED WITH RESPECT TO THE RX BUFFER *****
000020          RXBETX==16.    ;LEVEL OF RX BUFFER AT WHICH TO RE-ENABLE TRANSMISSION.
000030          RXBDTX==24.    ;LEVEL OF RX BUFFER AT WHICH TO DISABLE TRANSMISSION.
000100          RXBFUL==64.    ;TOTAL CHARACTER CAPACITY OF THE RX BUFFER.
    
```

EQUALS

```

;
; BIT DIFINITIONS
;
BIT15== 100000
BIT14== 40000
BIT13== 20000
BIT12== 10000
BIT11== 4000
BIT10== 2000
BIT09== 1000
BIT08== 400
BIT07== 200
BIT06== 100
BIT05== 40
BIT04== 20
BIT03== 10
BIT02== 4
BIT01== 2
BIT00== 1

;
BIT9== BIT09
BIT8== BIT08
BIT7== BIT07
BIT6== BIT06
    
```

```

100000
040000
020000
010000
004000
002000
001000
000400
000200
000100
000040
000020
000010
000004
000002
000001

001000
000400
000200
000100
    
```

```

000040      BITS== BIT05
000020      BIT4== BIT04
000010      BIT3== BIT03
000004      BIT2== BIT02
000002      BIT1== BIT01
000001      BIT0== BIT00
;
; EVENT FLAG DEFINITIONS
; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
;
000040      EF.START==      32.      ; START COMMAND WAS ISSUED
000037      EF.RESTART==    31.      ; RESTART COMMAND WAS ISSUED
000036      EF.CONTINUE==   30.      ; CONTINUE COMMAND WAS ISSUED
000035      EF.NEW==        29.      ; A NEW PASS HAS BEEN STARTED
000034      EF.PWR==        28.      ; A POWER-FAIL/POWER-UP OCCURRED
;
; PRIORITY LEVEL DEFINITIONS
;
000340      PRI07== 340
000300      PRI06== 300
000240      PRI05== 240
000200      PRI04== 200
000140      PRI03== 140
000100      PRI02== 100
000040      PRI01== 40
000000      PRI00== 0
;
; OPERATOR FLAG BITS
;
000004      EVL==          4
000010      LOT==         10
000020      ADR==         20
000040      IDU==         40
000100      ISR==        100
000200      UAM==        200
000400      BOE==        400
001000      PNT==       1000
002000      PRI==       2000
004000      IXE==       4000
010000      IBE==      10000
020000      IER==      20000
040000      LOE==      40000
100000      MOE==     100000
    
```



1266  
 1267  
 1268  
 1269  
 1270  
 1271  
 1272  
 1273  
 1274  
 1275  
 1276  
 1277  
 1278  
 1279 002214 000200  
 1280 002216 000204  
 1281 002220 177777  
 1282 002222 000  
 1283 002223 004  
 1284 002224 000000  
 1285  
 1286  
 1287  
 1288  
 1289 002226  
 1290 002226 160020  
 1291 002230 160022  
 1292 002232 160024  
 1293 002234 160026  
 1294  
 1295 002236 160030  
 1296 002240 160032  
 1297 002242 160034  
 1298 002244 160036  
 1299  
 1300  
 1301  
 1302  
 1303 002246 000000  
 1304 002250 000000  
 1305 002252 000000  
 1306 002254 000001  
 1307 002256 000000  
 1308 002260 031463  
 1309 002262 146314  
 1310 002264 000000  
 1311 002266 000000  
 1312 002270 000000  
 1313 002272 000000  
 1314 002274 000000  
 1315 002276 000000  
 1316 002300 000000  
 1317 002302 000000  
 1318  
 1319  
 1320  
 1321 002304 177546  
 1322 002306 000300

.SBTTL GLOBAL DATA SECTION

; \*\*  
 ; THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED  
 ; IN MORE THAN ONE TEST.  
 ; --

\*\*\*\*\*  
 ; UNIT VARIABLE AREA  
 \*\*\*\*\*

RXVECA:: .WORD 200 ;RX VECTOR ADDRESS.  
 TXVECA:: .WORD 204 ;TX VECTOR ADDRESS.  
 ACTLNS:: .WORD 177777 ;ACTIVE LINE BIT MAP.  
 LOPBCK:: .BYTE 0 ;LOOPBACK MODE  
 BRLEVL:: .BYTE 4 ;INTERRUPT BUS REQUEST LEVEL  
 UNITN:: .WORD 0 ;UNIT NUMBER.

\*\*\*\*\*  
 ; DEVICE REGISTER ADDRESS TABLE  
 \*\*\*\*\*

DRADRT::  
 CSRA:: .WORD 160020 ;DHU-11 CSR ADDRESS.  
 RXTMA:: RBUFA:: .WORD 160022 ;DHU-11 RECIEVE BUFFER/TIMER ADDRESS.  
 LPRA:: .WORD 160024 ;DHU-11 LINE PARAMETER REGISTER ADDRESS.  
 FDATA:: FLSA:: .WORD 160026 ;DHU-11 FIFO SIZE/LINE STATUS REGISTER ADDRESS,  
 ;AND FIFO DATA REGISTER ADDRESS.  
 LNCTRA:: .WORD 160030 ;DHU-11 LINE CONTROL REGISTER ADDRESS.  
 TXAD1A:: .WORD 160032 ;DHU-11 TRANSMIT BUFFER 1 REGISTER ADDRESS  
 TXAD2A:: .WORD 160034 ;DHU-11 TRANSMIT BUFFER 2 REGISTER ADDRESS  
 TXBFCA:: .WORD 160036 ;DHU-11 TRANSMIT BUFFER COUNT REGISTER ADDRESS

\*\*\*\*\*  
 ; ASSORTED GLOBAL VARIABLES:  
 \*\*\*\*\*

BUFPTR:: .WORD 0 ;STORAGE FOR RECEIVE CHARACTER BUFFER POINTER.  
 CTRLCF:: .WORD 0 ;STORAGE FOR THE CONTROL-C FLAG.  
 EXOERR:: .WORD 0 ; "EXIT ON ERROR" FLAG.  
 TSTNUM:: .WORD 1 ;STORAGE FOR THE TEST NUMBER.  
 IESTAT:: .WORD 0 ;STORAGE FOR STATES OF THE DUT INT ENABLE BITS.  
 LGRP1M:: .WORD 31463 ;BIT MAP OF LINES IN LINE GROUP I.  
 LGRP2M:: .WORD 146314 ;BIT MAP OF LINES IN LINE GROUP II.  
 PASCNT:: .WORD 0 ;STO'G FOR PASS COUNT USED IN ROM VERSION# TST.  
 RXINTC:: .WORD 0 ;STORAGE FOR RECEIVER INTERRUPT FLAGS.  
 RXINTF:: .WORD 0 ;STORAGE FOR RECEIVER INTERRUPT FLAGS.  
 TXINTC:: .WORD 0 ;STORAGE FOR TRANSMIT INTERRUPT COUNT.  
 TXINTF:: .WORD 0 ;STORAGE FOR TRANSMIT INTERRUPT FLAGS.  
 TP4VEC:: .WORD 0 ;STORAGE FOR THE NORMAL 004 TRAP VECTOR.  
 TP4FLG:: .WORD 0 ;FLAGS SET WHEN AN EXPECTED 004 TRAP OCCURS.  
 WORD1:: .WORD 0 ;LOCATION FOR PASSING INDIRECT PARAMETERS.

\*\*\*\*\*  
 ; LINE TIME CLOCK VARIABLES AND STORAGE.  
 \*\*\*\*\*

CLKCSR:: .WORD 177546 ;CSR ADDRESS OF THE LTC.  
 CLKBRL:: .WORD PRI06 ;INTERRUPT PRIORITY LEVEL OF THE LTC.

1323 002310 000100  
 1324 002312 000074  
 1325 002314 000000  
 1326 002316 000000  
 1327 002320 000170  
 1328 002322 000170  
 1329 002324 000021  
 1330 002326 000062  
 1331  
 1332  
 1333  
 1334  
 1335 002330 177572  
 1336 002332 000000  
 1337 002334 000000  
 1338  
 1339  
 1340  
 1341  
 1342 002336 000001  
 1343 002340 000002  
 1344 002342 000004  
 1345 002344 000010  
 1346 002346 000020  
 1347 002350 000040  
 1348 002352 000100  
 1349 002354 000200  
 1350 002356 000400  
 1351 002360 001000  
 1352 002362 002000  
 1353 002364 004000  
 1354 002366 010000  
 1355 002370 020000  
 1356 002372 040000  
 1357 002374 100000  
 1358  
 1359  
 1360  
 1361  
 1362 002376  
 1363 002376 000000  
 1364 002400 000000  
 1365 002402 000000  
 1366 002404 000000  
 1367 002406 000000  
 1368  
 1369  
 1370  
 1371 002410 000000  
 1372 002412  
 1373 002612  
 1374  
 1375  
 1376  
 1377  
 1378 002612 000000  
 1379 002614

```

CLKVEC:: .WORD 100 ;INTERRUPT VECTOR ADDRESS OF THE LTC.
CLKHRZ:: .WORD 60. ;INTERRUPT FREQUENCY OF THE LTC.
TIMER1:: .WORD 0 ;HARDWARE CLOCK COUNTER #1.
TIMER2:: .WORD 0 ;HARDWARE CLOCK COUNTER #2.
TIMER3:: .WORD 120. ;HARDWARE BREAK COUNTER LOCATION.
BCOUNT:: .WORD 120. ;BREAK COUNT VALUE IN CLOCK TICKS.
MSTICK:: .WORD 17. ;NUMBER OF MILLI-SECONDS PER LTC TICK.
MSLCNT:: .WORD 62 ;LOOP COUNT (USED BY MSLOOP) TO DELAY 1 MS.
;*****
; MEMORY MANAGEMENT VARIABLES AND FLAGS.
;*****
MMSRO:: .WORD 177572 ;ADDRESS OF MEM MGT STATUS REGISTER #0.
MMPRES:: .WORD 0 ;MEM MGT PRESENT FLAG (0 IF MM NOT PRESENT).
MMENAB:: .WORD 0 ;MEM MGT ENABLED FLAG (0 IF MM NOT ENABLED).
;*****
; TABLE OF WORDS WITH CORRESPONDING BIT SET FOR GENERATION OF BIT MAPS.
;*****
BITTBL:: .WORD 1 ;BIT 0 SET.
        .WORD 2 ;BIT 1 SET.
        .WORD 4 ;BIT 2 SET.
        .WORD 10 ;BIT 3 SET.
        .WORD 20 ;BIT 4 SET.
        .WORD 40 ;BIT 5 SET.
        .WORD 100 ;BIT 6 SET.
        .WORD 200 ;BIT 7 SET.
        .WORD 400 ;BIT 8 SET.
        .WORD 1000 ;BIT 9 SET.
        .WORD 2000 ;BIT 10 SET.
        .WORD 4000 ;BIT 11 SET.
        .WORD 10000 ;BIT 12 SET.
        .WORD 20000 ;BIT 13 SET.
        .WORD 40000 ;BIT 14 SET.
        .WORD 100000 ;BIT 15 SET.
;*****
;* GPR SAVE AREAS ZERO AND ONE.
;*****
GPRSOB:: ;BASE OF GPR SAVE AREA NUMBER ZERO.
        .WORD 0 ;WORD 1, STORAGE FOR R1.
        .WORD 0 ;WORD 2, STORAGE FOR R2.
        .WORD 0 ;WORD 3, STORAGE FOR R3.
        .WORD 0 ;WORD 4, STORAGE FOR R4.
        .WORD 0 ;WORD 5, STORAGE FOR R5.
;*****
; STORAGE AREA FOR THE BMP CODE QUEUE.
;*****
BMPCQP:: .WORD 0 ;POINTER USED TO ACCESS THE NEXT CELL IN QUE.
BMPCQB:: .BLKW 64. ;STORAGE FOR 32 CELLS, TEST# PLUS BMP CODE.
BMPCQE:: ;LAST ADDRESS PLUS 2 OF THE BMP CODE QUEUE.
;*****
; STORAGE AREA FOR ERROR SUMMARY TABLE AND FLAGS.
;*****
ERSMRF:: .WORD 0 ;ERROR SUMMARY FLAGS.
ERCNTB:: .BLKW 16 ;TABLE OF ERROR COUNTS.
    
```



1380  
 1381  
 1382  
 1383  
 1384 002650  
 1385 002650  
 1386 003250  
 1387 003450  
 1388 003650  
 1389 003650  
 1390  
 1391  
 1392  
 1393  
 1394 003710  
 1395  
 1396  
 1397  
 1398  
 1399  
 1400  
 1401  
 1402 003750  
 1403 003750 000000  
 1404 003752 000002  
 1405 003754 000004  
 1406 003756 000006  
 1407 003760 000010  
 1408 003762 000012  
 1409 003764 000014  
 1410 003766 000016  
 1411 003770 000020  
 1412 003772 000022  
 1413 003774 000024  
 1414 003776 000026  
 1415 004000 000030  
 1416 004002 000032  
 1417 004004 000034  
 1418 004006 000036  
 1419 004010  
 1420  
 1421  
 1422  
 1423  
 1424  
 1425  
 1426 004010  
 1427 004010 000  
 1428 004011 001  
 1429 004012 002  
 1430 004013 003  
 1431 004014 004  
 1432 004015 005  
 1433 004016 006  
 1434 004017 007  
 1435 004020 010  
 1436 004021 011

```

;*****
; GENERAL TABLE AND BUFFER AREA--513 WORDS.
;*****
BUFBAS:: ;BASE OF MEMORY BUFFER.
ERLTBL:: .BLKW 128. ;FIRST HALF OF GENERAL TABLE OR BUFFER.
BUF MID:: .BLKW 64. ;SECOND HALF OF GENERAL TABLE OR BUFFER.
BUF3QT:: .BLKW 64. ;LAST QUARTER OF THE BUFFER AREA.
BUFEND:: ;END OF GENERAL PURPOSE MEMORY BUFFER.
ENDETB:: .BLKW 16. ;BUFFER OVERFLOW SPACE.

;*****
; RECEPTION TABLE OF COUNTERS
;*****
RXCNTB:: .BLKW 16. ;RECEPTION CHARACTER COUNTERS TABLE.

;*****
;* TABLE FOR STORAGE OF RX/TX LINE NUMBER ASSOCIATIONS.
;* THE ASSOCIATIONS ARE STORED AS LINE NUMBER TIMES 2 FOR USE AS OFFSETS
;* WHEN ACCESSING A TABLE OF WORDS.
;* NOTE: DO NOT WRITE A NON-ZERO VALUE INTO THE UPPER BYTE OF ANY ENTRY.
;*****
TXRXLB:: ;BASE OF TX/RX LINE NUMBER ASSOCIATION TABLE.
        .WORD 0 ;TX/RX LINE OFFSET FOR RX/TX LINE 0.
        .WORD 2. ;TX/RX LINE OFFSET FOR RX/TX LINE 1.
        .WORD 4. ;TX/RX LINE OFFSET FOR RX/TX LINE 2.
        .WORD 6. ;TX/RX LINE OFFSET FOR RX/TX LINE 3.
        .WORD 8. ;TX/RX LINE OFFSET FOR RX/TX LINE 4.
        .WORD 10. ;TX/RX LINE OFFSET FOR RX/TX LINE 5.
        .WORD 12. ;TX/RX LINE OFFSET FOR RX/TX LINE 6.
        .WORD 14. ;TX/RX LINE OFFSET FOR RX/TX LINE 7.
        .WORD 16. ;TX/RX LINE OFFSET FOR RX/TX LINE 8.
        .WORD 18. ;TX/RX LINE OFFSET FOR RX/TX LINE 9.
        .WORD 20. ;TX/RX LINE OFFSET FOR RX/TX LINE 10.
        .WORD 22. ;TX/RX LINE OFFSET FOR RX/TX LINE 11.
        .WORD 24. ;TX/RX LINE OFFSET FOR RX/TX LINE 12.
        .WORD 26. ;TX/RX LINE OFFSET FOR RX/TX LINE 13.
        .WORD 28. ;TX/RX LINE OFFSET FOR RX/TX LINE 14.
        .WORD 30. ;TX/RX LINE OFFSET FOR RX/TX LINE 15.
TXRXLE:: ;END OF TX/RX LINE NUMBER ASSOCIATION TABLE.
        .EVEN ;GUARANTEE THAT NEXT TABLE IS ON WORD BOUNDARY.

;*****
;* TABLE FOR STORAGE OF RX/TX LINE NUMBER ASSOCIATIONS.
;* THE ASSOCIATIONS ARE STORED AS LINE NUMBERS WHICH CAN BE USED AS SUCH OR
;* AS OFFSETS WHEN ACCESSING A TABLE OF BYTES.
;*****
TXRLNB:: ;BASE OF TX/RX LINE NUMBER ASSOCIATION TABLE.
        .BYTE 0 ;TX/RX LINE FOR RX/TX LINE 0.
        .BYTE 1. ;TX/RX LINE FOR RX/TX LINE 1.
        .BYTE 2. ;TX/RX LINE FOR RX/TX LINE 2.
        .BYTE 3. ;TX/RX LINE FOR RX/TX LINE 3.
        .BYTE 4. ;TX/RX LINE FOR RX/TX LINE 4.
        .BYTE 5. ;TX/RX LINE FOR RX/TX LINE 5.
        .BYTE 6. ;TX/RX LINE FOR RX/TX LINE 6.
        .BYTE 7. ;TX/RX LINE FOR RX/TX LINE 7.
        .BYTE 8. ;TX/RX LINE FOR RX/TX LINE 8.
        .BYTE 9. ;TX/RX LINE FOR RX/TX LINE 9.
    
```

1437 004022 012  
 1438 004023 013  
 1439 004024 014  
 1440 004025 015  
 1441 004026 016  
 1442 004027 017  
 1443 004030  
 1444  
 1445  
 1446  
 1447  
 1448  
 1449  
 1450  
 1451  
 1452 004030  
 1453 004030 004  
 1454 004031 006  
 1455 004032 000  
 1456 004033 002  
 1457 004034 014  
 1458 004035 016  
 1459 004036 010  
 1460 004037 012  
 1461 004040 024  
 1462 004041 026  
 1463 004042 020  
 1464 004043 022  
 1465 004044 034  
 1466 004045 036  
 1467 004046 030  
 1468 004047 032  
 1469  
 1482 004050  
 004050  
 004050 000000  
 004052 000000  
 004054 000000  
 004056 000000  
 1483  
 1484

```

        .BYTE 10.      ;TX/RX LINE FOR RX/TX LINE 10.
        .BYTE 11.      ;TX/RX LINE FOR RX/TX LINE 11.
        .BYTE 12.      ;TX/RX LINE FOR RX/TX LINE 12.
        .BYTE 13.      ;TX/RX LINE FOR RX/TX LINE 13.
        .BYTE 14.      ;TX/RX LINE FOR RX/TX LINE 14.
        .BYTE 15.      ;TX/RX LINE FOR RX/TX LINE 15.
TXRLNE::
        .EVEN          ;END OF TX/RX LINE NUMBER ASSOCIATION TABLE.
                    ;GUARANTEE THAT NEXT TABLE IS ON WORD BOUNDARY.
;*****
;* TABLE OF TX/RX LINE NUMBER ASSOCIATIONS IN STAGGERED LOOPBACK.
;* THE ASSOCIATIONS ARE STORED AS LINE NUMBER TIMES 2 FOR USE AS OFFSETS
;* WHEN ACCESSING A TABLE OF WORDS.
;* THIS IS A TABLE OF DATA FOR READING ONLY. USE TO LOAD THE ABOVE TABLE.
;* NOTE: MUST CONVERT FROM BYTES TO WORDS WHEN LOADING ABOVE TABLE.
;*****
STGTRB::
        .BYTE 4.      ;BASE OF STAGGERED TX/RX LINE NUMBER TABLE.
        .BYTE 6.      ;TX/RX LINE OFFSET FOR RX/TX LINE 0.
        .BYTE 0       ;TX/RX LINE OFFSET FOR RX/TX LINE 1.
        .BYTE 2.      ;TX/RX LINE OFFSET FOR RX/TX LINE 2.
        .BYTE 12.     ;TX/RX LINE OFFSET FOR RX/TX LINE 3.
        .BYTE 14.     ;TX/RX LINE OFFSET FOR RX/TX LINE 4.
        .BYTE 14.     ;TX/RX LINE OFFSET FOR RX/TX LINE 5.
        .BYTE 8.      ;TX/RX LINE OFFSET FOR RX/TX LINE 6.
        .BYTE 10.     ;TX/RX LINE OFFSET FOR RX/TX LINE 7.
        .BYTE 20.     ;TX/RX LINE OFFSET FOR RX/TX LINE 8.
        .BYTE 22.     ;TX/RX LINE OFFSET FOR RX/TX LINE 9.
        .BYTE 16.     ;TX/RX LINE OFFSET FOR RX/TX LINE 10.
        .BYTE 18.     ;TX/RX LINE OFFSET FOR RX/TX LINE 11.
        .BYTE 28.     ;TX/RX LINE OFFSET FOR RX/TX LINE 12.
        .BYTE 30.     ;TX/RX LINE OFFSET FOR RX/TX LINE 13.
        .BYTE 24.     ;TX/RX LINE OFFSET FOR RX/TX LINE 14.
        .BYTE 26.     ;TX/RX LINE OFFSET FOR RX/TX LINE 15.
        .EVEN        ;GUARANTEE THAT NEXT TABLE IS ON WORD BOUNDARY.
ERRTBL
ERRTYP::          .WORD 0
ERRNBR::          .WORD 0
ERRMSG::          .WORD 0
ERRBLK::          .WORD 0
        .EVEN
    
```

L\$ERRTBL::



1486  
1487  
1488  
1489  
1490  
1491  
1492  
1493  
1494  
1495  
1496  
1497  
1498  
1499  
1500  
1501  
1502  
1503  
1504  
1505  
1506  
1507  
1508  
1509  
1510  
1511  
1512  
1513  
1514  
1515  
1516  
1517  
1518  
1519  
1520  
1521  
1522

```
.SBTTL GPR HANDLING ROUTINES FOR SUBROUTINE CALLS.  
:*****  
:*  
:* THERE ARE 4 ROUTINES AND MACRO DEFINITIONS USED FOR THE HANDLING OF  
:* GPR VALUES DURING SUBROUTINE CALLS WITHIN THIS PROGRAM. THE FOUR  
:* ROUTINES/MACRO CALLS HAVE THE FOLLOWING NAMES:  
:*  
:* SAVE - MACRO DEFINITION USED AT THE BEGINNING OF A SUBROUTINE TO  
:* SAVE THE GPR CONTENTS FOR LATER RESTORATION.  
:* PASS - MACRO DEFINITION USED AT THE END OF A SUBROUTINE TO RESTORE  
:* THE PREVIOUSLY SAVED GPR CONTENTS AND TO LEAVE THE CONTENTS  
:* OF THE SPECIFIED GPR(S) INTACT (NOT RESTORED).  
:* PREG05 - SUBROUTINE WHICH IS CALLED FROM THE SAVE AND PASS MACRO  
:* EXPANSIONS WHICH ACTUALLY PERFORMS THE ACTIONS ON THE GPRS.  
:*  
:* DURING A SUBROUTINE WHICH USES THESE GPR SAVE ROUTINES THE VALUES  
:* OF THE GPRS ARE STORED ON THE STACK IN THE FOLLOWING STACK FRAME:  
:*  
:* SP -> RET PC INTO PREG05 ROUTINE.  
:* SP+2 -> GPR R0 CONTENTS.  
:* SP+4 -> GPR R1 CONTENTS.  
:* SP+6 -> GPR R2 CONTENTS.  
:* SP+8 -> GPR R3 CONTENTS.  
:* SP+10 -> GPR R4 CONTENTS.  
:* SP+12 -> GPR R5 CONTENTS.  
:* SP+14 -> RET PC INTO CALLER OF SUB'TNE WHICH CALLED PREG05.  
:*  
:* EACH LEVEL OF SUB'TNE CALLING USES 8 WORDS OF STACK OVERHEAD.  
:* THE SAVE AND PASS MACROS CAN ALSO BE USED IN "STRAIGHT LINE CODE"  
:* TO SAVE AND RESTORE THE GPR VALUES. IN ANY CASE, AFTER THE  
:* ISSUING OF A PASS CALL THE GPRS WILL BE RESTORED TO THE VALUES  
:* THEY HAD PRIOR TO THE LAST SAVE CALL (EXCEPT FOR THE EXCEPTED,  
:* OR PASSED INTACT, GPRS SPECIFIED AS PARAMETERS TO THE PASS CALL)  
:* AND THE SP WILL ALSO BE RESTORED TO ITS CONDITION BEFORE THE LAST  
:* SAVE CALL. THE PROGRAMMER MUST BE SURE THAT THE SP HAS THE SAME  
:* VALUE WHEN THE PASS MACRO IS CALLED AS IT HAD IMMEDIATELY AFTER  
:* THE SAVE MACRO WAS CALLED.  
:*****
```

1524  
1525  
1526  
1527  
1528  
1529  
1530  
1531  
1532  
1533  
1534  
1535  
1536  
1537  
1538

.SBTTL GPR FRAME ACCESS EQUATES

;\*\*\*  
;EQUATES THAT ALLOW ACCESS TO THE STACK FRAME. THESE ARE THE  
;OFFSETS INTO THE STACK FOR REGISTERS SAVED DURING THE PREG05  
;ROUTINE.  
;---

000036	LPCSLT==	36	;OFFSET FOR LAST RETURN PC.
000016	PCSLOT==	16	;OFFSET FOR RETURN PC.
000014	R5SLOT==	14	;OFFSET FOR R5.
000012	R4SLOT==	12	;OFFSET FOR R4.
000010	R3SLOT==	10	;OFFSET FOR R3.
000006	R2SLOT==	6	;OFFSET FOR R2.
000004	R1SLOT==	4	;OFFSET FOR R1.
000002	ROSLOT==	2	;OFFSET FOR R0.



1540  
1541  
1542  
1543  
1544  
1545  
1546  
1547  
1548  
1549  
1550  
1551  
1552  
1553  
1554  
1555  
1556  
1557  
1558  
1559  
1560  
1561  
1562  
1563

```
.SBTTL GLOBAL MACRO DEFINITION - SAVE -  
:*****  
:* THIS MACRO IS USED AT THE BEGINNING OF A SUBROUTINE TO SAVE THE  
:* CONTENTS OF THE GPRS R0 THRU R5.  
:*  
:* INPUTS: SP - UNCHANGED SINCE SUBROUTINE WAS ENTERED  
:* R5SLOT - OFFSET TO STACK SLOT FOR R5 (EQUATED TO 14 OCTAL)  
:*  
:* OUTPUTS: GPR SAVE AREA ON THE STACK IS LOADED WITH THE CONTENTS OF GPRS  
:* TOP OF STACK - LOADED WITH THE RETURN ADDRESS INTO PREG05  
:*  
:* CALLING SEQUENCE: SAVE  
:*  
:* COMMENTS: NO ARGUMENTS ARE ALLOWED.  
:* THE PASS MACRO SHOULD BE CALLED TO RESTORE THE GPR VALUES.  
:*  
:* SUBORDINATE ROUTINES CALLED: PREG05.  
:*****  
  
 .MACRO SAVE  
 .LIST JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.  
  
 .NLIST  
 .ENDM SAVE
```

1565  
1566  
1567  
1568  
1569  
1570  
1571  
1572  
1573  
1574  
1575  
1576  
1577  
1578  
1579  
1580  
1581  
1582  
1583  
1584  
1585  
1586  
1587  
1588  
1589  
1590  
1591  
1592  
1593  
1594  
1595  
1596  
1597  
1598  
1599  
1600  
1601  
1602  
1603  
1604  
1605  
1606  
1607  
1608  
1609  
1610  
1611  
1612

```

.SBTTL GLOBAL MACRO DEFINITION - PASS -
*****
;* THIS MACRO IS USED IN CONJUNCTION WITH THE SAVE MACRO. IT IS
;* CALLED AT END OF A SUBROUTINE TO PASS PARAMETERS IN GPRS BACK TO THE
;* CALLING ROUTINE BY ALTERING THE GPR SAVE AREA ON THE STACK AND THEN
;* RETURNING TO PREG05 TO RESTORE THE GPRS TO THEIR SAVED VALUES.
;*
;* INPUTS: ONLY ALLOWED ARGUMENTS ARE "R0" THRU "R5".
;* ROSLOT THRU RSSLOT MUST BE EQUATED TO THEIR RESPECTIVE GPR SAVE
;* SLOT OFFSETS BEFORE CALLING THIS MACRO.
;*
;* OUTPUTS: THE GPR VALUES ARE PUT IN THEIR RESPECTIVE SLOTS ON THE STACK.
;*
;* CALLING SEQUENCE: PASS R0,R1,...
;*
;* COMMENTS: ANY COMBINATION OF GPR ARGUMENTS MAY BE LISTED IN ANY ORDER.
;* FOR EXAMPLE, THE FOLLOWING ARE LEGAL:
;* PASS R1
;* PASS R4,R0,R2
;* THE GPRS LISTED AS ARGUMENTS WILL BE PASSED INTACT TO THE
;* CALLING ROUTINE, ALL OTHER GPRS WILL BE RESTORED.
;* THE SP MUST BE AT ITS ORIGINAL VALUE WHEN PASS IS CALLED.
;*
;* THE MACRO CALL
;* PASS R0,R3
;* EXPANDS INTO THE FOLLOWING ASSEMBLY CODE:
;* MOV R0,ROSLOT(SP) ;PUT R0 IN STACK SLOT.
;* MOV R3,R3SLOT(SP) ;PUT R3 IN STACK SLOT.
;* JSR PC,8(SP) ;RETURN TO PREG05 SUBRT.
;* IN THIS EXAMPLE GPRS R1, R2, R4, AND R5 WILL BE RESTORED TO
;* THEIR VALUES CONTAINED IN THE STACK FRAME AND R0 AND R3
;* WILL BE LEFT AT THEIR VALUES PRIOR TO THIS PASS CALL.
;*
;* SUBORDINATE ROUTINES CALLED: (PREGRT - LABEL WITHIN PREG05, VALUE ON STACK.)
*****

```

```

.MACRO PASS A,B,C,D,E,F
.IRP X,<A,B,C,D,E,F>
.IF NB,X
.LIST
MOV X,X'SLOT(SP) ;PUT X IN STACK SLOT.
.NLIST
.ENDC
.ENDM
.LIST
.NLIST
.ENDM PASS
JSR PC,8(SP) ;RETURN TO PREG05 SUBRT.

```



1614  
1615  
1616  
1617  
1618  
1619  
1620  
1621  
1622  
1623  
1624  
1625  
1626  
1627  
1628  
1629  
1630  
1631  
1632  
1633  
1634  
1635  
1636  
1637  
1638  
1639 004060  
1640 004060 010446  
1641 004062 010346  
1642 004064 010246  
1643 004066 010146  
1644 004070 010046  
1645 004072 010546  
1646 004074 016605 000014  
1647  
1648 004100 004736  
1649  
1650  
1651  
1652  
1653  
1654  
1655  
1656  
1657  
1658 004102 012605  
1659 004104 012600  
1660 004106 012601  
1661 004110 012602  
1662 004112 012603  
1663 004114 012604  
1664  
1665 004116 000205  
1666

```

.SBTTL GLOBAL SUBROUTINE - PREG05
:*****
: PRESERVE REGISTERS R0 THROUGH R5 FOR SUBROUTINE CALLS.
:
: INPUTS: THE RETURN ADDRESS BACK INTO THE CALLING ROUTINE MUST BE IN
: GPR R5. (I.E. - MACROS USE "JSR R5,PREG05".)
:
: OUTPUTS: REGISTERS R0 THROUGH R5 ARE SAVED ON THE STACK.
:
: CALLING SEQUENCE: SAVE ;MACRO EXPANSION CALLS PREG05.
: [SUBROUTINE CODE]...
: PASS ;MACRO EXPANSION RECALLS PREG05.
:
: COMMENTS: THIS ROUTINE IS RE-ENTRANT.
:
: PARAMETERS MAY BE PASSED OUT OF A SUBROUTINE BY MODIFYING THE
: REGISTER SAVE AREA ON THE STACK. USE THE PASS GPRN MACRO
: TO RETURN GPR VALUES INTACT.
: USE THE RNSLOT OFFSETS FROM THE SP TO PASS OTHER PARAMETERS.
: [EXAMPLE: MOV VALUE,R0SLOT(SP) ]
: MAKE SURE THE SP IS AT ITS ORIGINAL VALUE WHEN YOU DO THIS.
:
: SUBORDINATE ROUTINES CALLED: NONE.
:*****
PREG05: ;R5 HAS BEEN LOADED ON THE STACK BY THE SUBROUTINE CALL
MOV R4,-(SP) ;SAVE R4
MOV R3,-(SP) ;SAVE R3
MOV R2,-(SP) ;SAVE R2
MOV R1,-(SP) ;SAVE R1
MOV R0,-(SP) ;SAVE R0
MOV R5,-(SP) ;PUSH RETURN PC ON TOP OF STACK
MOV R5SLOT(SP),R5 ;RESTORE R5 TO VALUE IT HAD BEFORE CALLS
JSR PC,@(SP) ;CALL THE SUBROUTINE AT THE RETURN ADDRESS
;FROM THE PREG05 CALL, PUTTING THE PRESENT
;PC ON THE STACK AS A RETURN ADDRESS INTO
;THIS (PREG05) ROUTINE.
;...
;THE FOLLOWING CODE IS EXECUTED WHEN THE CALLING ROUTINE DOES A
;"RETURN" [JSR PC,@(SP)] USING THE PC DEPOSITED ON THE STACK ABOVE.
;...
PREGRT: MOV (SP),R5 ;PUT RETURN PC IN R5.
MOV (SP),R0 ;RESTORE R0.
MOV (SP),R1 ;RESTORE R1.
MOV (SP),R2 ;RESTORE R2.
MOV (SP),R3 ;RESTORE R3.
MOV (SP),R4 ;RESTORE R4.
RTS R5 ;RETURN TO THE SUBROUTINE WHICH CALLED PREG05.
;RESTORING R5 IN THE PROCESS.

```

```

1668
1676
1677
1678
1679
1680
1681
1682
1683
1684
1685
1686
1687 004120
      004120
      004120    104    110    125
      004123    055    061    061
      004126    000
1688
1694
1695
1696
1697 004130
      004130
      004130    104    110    125
T2/  004133    055    061    061
      004136    040    106    125
      004141    116    103    040
      004144    124    123    124
      004147    040    120    101
      004152    122    124    062
      004155    000
1698
1699
1706

```

.SBTTL GLOBAL TEXT SECTION

```

; **
; THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
; MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
; MORE THAN ONE TEST.
; --
;
; NAMES OF DEVICES SUPPORTED BY PROGRAM
;
      DEVTYP <DHU-11>

```

L\$DVTYP::  
 .ASCIZ /DHU-11/  
 .EVEN

```

; TEST DESCRIPTION
;
      DESCRIPT    <DHU-11 FUNC TST PART2>

```

L\$DESC::  
 .ASCIZ /DHU-11 FUNC TST PAR  
 .EVEN

.EVEN



```

1715
1716      .NLIST BIN
1717
1718
1719      ; ***** FORMAT STATEMENTS USED IN PRINT CALLS *****
1720
1721
1722 004156 EF0503:: .ASCIZ /#T#N/
1723 004163 EF1601:: .ASCIZ /#A #T#A, TEST ABORTED #N/
1724 004215 EF5801:: .ASCIZ /#A      RXTIMER VALUE USED WAS :#D3#A (D)#N/
1725 004270 EF5901:: .ASCIZ /#A      EXPECTED :#D3#A(D)#N/
1726 004320 EF5902:: .ASCIZ /#A      ACTUAL   :#D3#A(D)#N/
1727 004350 EF6401:: .ASCIZ /#A      #D2#N/
1728 004417 EF7801:: .ASCIZ /#T#A ON LINE #D2#A DECIMAL.#N/
1729 004455 EF9001:: .ASCIZ /#A UNEXPECTED #T#A FOUND IN RECEIVE CHAR FIFO:#N/
1730 004537 EF9002:: .ASCIZ /#A      CODE IS ASSOCIATED WITH LINE: #D2#N/
1731 004611 EF9003:: .ASCIZ /#A      CODE IS: #D3#N/
1732 004640 EF9004:: .ASCIZ /#A      #T#A VALUE: #D3#N/
1733 004670 EF9005:: .ASCIZ /#A      #T#A VALUE: NONE#N/
1734 004721 EF9006:: .ASCIZ /#A #T#A #D2#A(D)#N/
1735 004745 EF9010:: .ASCIZ /#A      NUMBER OF ERRORS DETECTED ON LINE #D2#A IS #D5#N/
1736 005034 EF9019:: .ASCIZ /#A #T#A #D6#N/
1737 005053 EF9301:: .ASCIZ /#A #T#D2#A(D). BMP CODE REPORTED :#D3#A(O)#N/
1738 005131 EF9302:: .ASCIZ /#A OVERFLOW OCCURRED (MORE THAN 31 BMP CODES FOUND IN QUEUE)#N/
1739 005231 MFUNIT:: .ASCIZ /#N#A TESTING UNIT :#D4#N/
1740      .EVEN
1741      .LIST BIN

```

```
1750
1751 .NLIST BIN
1752
1753
1754 ;***** GLOBAL ERROR MESSAGES *****
1755
1756 005262 EM0103:: .ASCIZ /DEVICE REGISTER ACCESS ERRORS/
1757 005320 EM1601:: .ASCIZ /TIMEOUT OCCURRED WAITING FOR MASTER RESET TO CLEAR/
1758 005403 EM4001:: .ASCIZ /DMA_START BIT TEST FAILED/
1759 005435 EM4002:: .ASCIZ /DMA_START BIT BAD ON LINE: /
1760 005471 EM4101:: .ASCIZ /DMA_ABORT BIT TEST FAILED/
1761 005523 EM4102:: .ASCIZ /DMA_ABORT BIT BAD ON LINE: /
1762 005557 EM4103:: .ASCIZ /DMA_START BIT FOUND SET AFTER DMA ABORTED ON LINE: /
1763 005643 EM4201:: .ASCIZ /DMA_ERROR BIT TEST FAILED/
1764 005675 EM4202:: .ASCIZ /DMA_ERROR BIT BAD/
1765 005717 EM4901:: .ASCIZ /OAUTO (INACTIVE) BIT TEST FAILED/
1766 005760 EM4902:: .ASCIZ / OAUTO BIT BAD ON LINE: /
1767 006012 EM5001:: .ASCIZ /OAUTO (ACTIVE) BIT TEST FAILED/
1768 006051 EM5101:: .ASCIZ /IAUTO (INACTIVE) TEST FAILED/
1769 006106 EM5102:: .ASCIZ /IAUTO BIT FOUND SET ON LINE: /
1770 006144 EM5103:: .ASCIZ /IAUTO BIT BAD ON LINE: /
1771 006174 EM5201:: .ASCIZ /IAUTO (ACTIVE) TEST FAILED/
1772 006227 EM5202:: .ASCIZ /IAUTO BIT FOUND CLR ON LINE: /
1773 006265 EM5301:: .ASCIZ /FIFO VALID DATA TEST FAILED/
1774 006321 EM5302:: .ASCIZ /FIFO BAD, DATA FIELD CORRUPTED, TEST USED LINE:/
1775 006401 EM5303:: .ASCIZ /BMP CODE FOUND IN FIFO, TEST INVAILEDATED/
1776 006452 EM5401:: .ASCIZ \FIFO 3/4 ALARM (INACTIVE) TEST FAILED\
1777 006520 EM5402:: .ASCIZ /FIFO BAD, ALARM SIGNAL DEFECTIVE/
1778 006561 EM5501:: .ASCIZ \FIFO 3/4 ALARM (ACTIVE) TEST FAILED\
1779 006625 EM5601:: .ASCIZ \FIFO 3/4 ALARM (ACTIVE/INACTIVE) TEST FAILED\
1780 006702 EM5701:: .ASCIZ \FIFO 1/2 LEVEL (ACTIVE/INACTIVE) TEST FAILED\
1781 006757 EM5801:: .ASCIZ /RXTIMER TEST FAILED/
1782 007003 EM5802:: .ASCIZ /RXTIMER BAD, RX-INT DELAYED BY WRONG NUMBER OF MILLISECONDS/
1783 007077 EM5803:: .ASCIZ \RXTIMER BAD, RX-INT DIDN'T OCCUR IMMEDIATELY WITH RXFIFO 3/4 FULL\
1784 007201 EM5804:: .ASCIZ /RXTIMER BAD, RX-INT OCCURED WITH RXTIMER VALUE ZERO/
1785 007265 EM5805:: .ASCIZ /RXTIMER BAD, TIME-OUT OCCURED WAITING FOR RX-INT/
1786 007346 EM5901:: .ASCIZ / TX-ACTION FIFO TEST FAILED/
1787 007402 EM5902:: .ASCIZ / TX_ACTION FIFO BAD, TX-ACTION RECIEVED FROM THE WRONG LINE/
1788 007476 EM5903:: .ASCIZ / TX_ACTION FIFO BAD, INCORRECT NUMBER OF TX-ACTIONS FOUND/
1789 007570 EM5904:: .ASCIZ / TX_ACTION FIFO BAD, TX-ACTION FIFO WOULD NOT EMPTY/
1790 007654 EM5905:: .ASCIZ / TX INTERRUPT OCCURED AFTER THE TX_ACTION FIFO HAD BEEN EMPTIED/
1791 007754 EM6001:: .ASCIZ /TX FIFO TEST FAILED/
1792 010000 EM6002:: .ASCIZ /INCORRECT VALUE IN FIFOSIZE REG/
1793 010040 EM6003:: .ASCIZ /MORE THAN ONE TX-INT OCCURED, FROM A FULL TXFIFO/
1794 010120 EM6004:: .ASCIZ /TX FIFO BAD, RECIEVED CHAR INCORRECT/
1795 010165 EM6005:: .ASCIZ /TX FIFO BAD, CHARACTER RECIEVED ON WRONG LINE/
1796 010243 EM6006:: .ASCIZ /TX FIFO BAD, TOO FEW CHARS RECIEVED/
1797 010307 EM6401:: .ASCIZ /BREAK GENERATION TEST FAILED/
1798 010344 EM6402:: .ASCIZ / BREAK NOT RECEIVED ON LINE(S):/
1799 010405 EM6601:: .ASCIZ /NO OVERRUN ERROR TEST FAILED/
1800 010442 EM6602:: .ASCIZ / OVERRUN ERROR REPORTED WHEN NONE FORCED/
1801 010514 EM6701:: .ASCIZ /OVERRUN ERROR TEST FAILED/
1802 010546 EM6702:: .ASCIZ / NO OVERRUN ERROR REPORTED, OVERRUN FORCED/
1803 010623 EM9009:: .ASCIZ /EXPECTED OR CORRECT/
1804 010647 EM9010:: .ASCIZ /ACTUAL OR MEASURED /
1805 010673 EM9014:: .ASCIZ /SUMMARY REPORTS FOR LINES WITH EXCESSIVE NUMBERS OF ERRORS:/
1806 010767 EM9017:: .ASCII / FIFO WILL NOT PURGE (DATA,VALID STUCK SET),/
```



1807 011044 .ASCIZ / REMAINDER OF TEST SKIPPED./  
1808 011100 EM9026:: .ASCIZ / LPR CONTENTS: /  
1809 011124 EM9104:: .ASCIZ / UNEXPECTED DATA FOUND IN FIFO FROM LINE: /  
1810 011200 EM9301:: .ASCIZ /BMP CODES WERE REPORTED DURING THIS DIAGNOSTIC/  
1811 011257 EM9302:: .ASCIZ /BMP CODE FOUND IN TEST /  
1812 011307 EM9303:: .ASCIZ /THE LAST BMP CODE WAS FOUND IN TEST /  
1813 011354 EM9304:: .ASCIZ /UNEXPECTED BMP CODES FOUND DURING THIS PASS/  
1814 .EVEN  
1815 .LIST BIN

GLOBAL TEXT SECTION

1824  
1825  
1826  
1827  
1828  
1829  
1830  
1831  
1832

.SBTTL GLOBAL ERROR REPORT SECTION

;++  
: THE GLOBAL ERROR REPORT SECTION CONTAINS MESSAGE PRINTING AREAS  
: USED BY MORE THAN ONE TEST TO OUTPUT ADDITIONAL ERROR INFORMATION. PRINTB  
: (BASIC) AND PRINTX (EXTENDED) CALLS ARE USED TO CALL PRINT SERVICES.  
:--



1834  
1835  
1836  
1837  
1838  
1839  
1840  
1841  
1842  
1843  
1844  
1845  
1846  
1847  
1848  
1849  
1850  
1851  
1852  
1853  
1854  
1855  
1856

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER0101 -
;*****
;* THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS ADDITIONAL ERROR
;* INFORMATION IF AN ERROR IS DETECTED IN TEST 1 (REGISTER ADDRESS
;* ACCESS TEST). IF THE "EXTENDED ERROR INFO" OPTION HAS BEEN SELECTED
;* THEN THIS SUBROUTINE WILL REPORT THE TYPE OF ACCESS (READ OR WRITE OR
;* BOTH) WHICH CAUSED A BUS TIME-OUT TRAP (004 TRAP). A MESSAGE INDICATING
;* THAT THE DHU MAY BE AT THE WRONG UNIBUS ADDRESS IS ALSO PRINTED.
;*
;* INPUTS:      R5 - ERROR FLAG WORD.
;*              IF BIT 0 IS SET, A READ ERROR OCCURED.
;*              IF BIT 1 IS SET, A WRITE ERROR OCCURED.
;*
;* OUTPUTS:     MESSAGES ARE PRINTED AT THE OPERATOR CONSOLE.
;*
;* CALLING SEQUENCE:  INCLUDE THE LABEL "ER0101" AS THE MESSAGE POINTER
;*                   PARAMETER IN THE DRS ERROR REPORT MACRO CALL.
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES USED: NONE.
;*****
```

1857 011430  
011430  
1858 011430  
011430 004567 172424  
1859  
1860 011434 012700 000100  
1861 011440 046700 170544  
1862 011444 001036  
1863  
1864  
1865  
1866  
1867 011446 032705 000001  
1868 011452 001410  
1869 011454  
011454 012746 011546  
011460 012746 000001  
011464 010600  
011466 104414  
011470 062706 000004  
1870 011474 032705 000002  
1871 011500 001410  
1872 011502  
011502 012746 011624  
011506 012746 000001  
011512 010600  
011514 104414  
011516 062706 000004  
1873 011522  
011522 012746 011703  
011526 012746 000001  
011532 010600  
011534 104415  
011536 062706 000004

```
BGNMSG ER0101
SAVE                                ER0101::
                                JSR      ;SAVE THE GPR CONTENTS.
                                R5,PREG05 ;CALL REGISTER SAVE SUBRT.

                                MOV      #BIT06,R0 ;SET-UP THE BIT MAP FOR 'REPORT EXT'D ERROR INFO'
                                BIC      OPTION,R0 ;TRY AND CLEAR THE FLAG.
                                BNE      6$ ;EXIT IF OPTION NOT SELECTED.

;+
; REPORT EXTENDED ERROR INFOMATION
;-

                                BIT      #BIT0,R5 ;TEST FOR READ ERROR.
                                BEQ      2$ ;SKIP READ ERROR MSG IF NO READ ERROR.
                                PRINTB  #MSG1 ;PRINT READ ERROR MESSAGE.
                                MOV      #MSG1,-(SP)
                                MOV      #1,-(SP)
                                MOV      SP,R0
                                TRAP     C$PNTB
                                ADD      #4,SP

2$:                                BIT      #BIT1,R5 ;TEST FOR WRITE ERROR.
                                BEQ      4$ ;SKIP WRITE ERROR MSG IF NO WRITE ERROR.
                                PRINTB  #MSG2 ;PRINT WRITE ERROR MESSAGE.
                                MOV      #MSG2,-(SP)
                                MOV      #1,-(SP)
                                MOV      SP,R0
                                TRAP     C$PNTB
                                ADD      #4,SP

4$:                                PRINTX #MSG3 ;SUGGEST THAT DHU MAY BE AT WRONG ADDRESS.
                                MOV      #MSG3,-(SP)
                                MOV      #1,-(SP)
                                MOV      SP,R0
                                TRAP     C$PNTX
                                ADD      #4,SP
```

```

1874 011542          004736          63:  PASS          ;RESTORE THE GPR CONTENTS.
      011542          ;RETURN TO PREG05 SUBRT.
1875 011544          ENDMSG          JSR          PC,@(SP)+
      011544          L10002:
      011544          104423          TRAP      C$MSG
1876
1877 011546          045          101          102  MSG1:: .ASCIZ /#ABUS TIME-OUT TRAP CAUSED BY READ ATTEMPT.#N/
      011551          125          123          040
      011554          124          111          115
      011557          105          055          117
      011562          125          124          040
      011565          124          122          101
      011570          120          040          103
      011573          101          125          123
      011576          105          104          040
      011601          102          131          040
      011604          122          105          101
      011607          104          040          101
      011612          124          124          105
      011615          115          120          124
      011620          056          045          116
      011623          000
1878 011624          045          101          102  MSG2:: .ASCIZ /#ABUS TIME-OUT TRAP CAUSED BY WRITE ATTEMPT.#N/
      011627          125          123          040
      011632          124          111          115
      011635          105          055          117
      011640          125          124          040
      011643          124          122          101
      011646          120          040          103
      011651          101          125          123
      011654          105          104          040
      011657          102          131          040
      011662          127          122          111
      011665          124          105          040
      011670          101          124          124
      011673          105          115          120
      011676          124          056          045
      011701          116          000
1879 011703          045          101          104  MSG3:: .ASCIZ /#ADHU MAY BE AT THE WRONG UNIBUS ADDRESS.#N#N/
      011706          110          125          040
      011711          115          101          131
      011714          040          102          105
      011717          040          101          124
      011722          040          124          110
      011725          105          040          127
      011730          122          117          116
      011733          107          040          125
      011736          116          111          102
      011741          125          123          040
      011744          101          104          104
      011747          122          105          123
      011752          123          056          045
      011755          116          045          116
      011760          000
1880
1881
          .EVEN
    
```



1883  
 1884  
 1885  
 1886  
 1887  
 1888  
 1889  
 1890  
 1891  
 1892  
 1893  
 1894  
 1895  
 1896  
 1897  
 1898  
 1899  
 1900  
 1901

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER0503 -
;*****
;* THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS AN ADDITIONAL ERROR
;* MESSAGE WHOSE ADDRESS IS PASSED AS AN INPUT PARAMETER, PROVIDED
;* EXTENDED ERROR REPORTING HAS BEEN REQUESTED.
;*
;* INPUTS: R1 - ADDRESS OF THE MESSAGE TO PRINT.
;*
;* OUTPUTS: A MESSAGES IS PRINTED AT THE OPERATOR CONSOLE.
;*
;* CALLING SEQUENCE: LOAD THE ADDRESS OF THE MESSAGE IN R1.
;* INCLUDE THE LABEL "ER0503" AS THE MESSAGE POINTER
;* PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
;*
;* COMMENTS: THE MESSAGE IS PRINTED AS BASIC ERROR INFORMATION.
;*
;* SUBORDINATE ROUTINES USED: NONE.
;*****
```

1902 011762  
 011762

BGNMSG ER0503

ER0503::

1903  
 1904 011762 012700 000100  
 1905 011766 046700 170216  
 1906 011772 001011  
 1907  
 1908

```
MOV @BIT06,R0 ;TRY TO CLEAR THE
BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
BNE 2$ ;EXIT IF FLAG NOT SET.
```

1909 011774  
 011774 010146  
 011776 012746 004156  
 012002 012746 000002  
 012006 010600  
 012010 104414  
 012012 062706 000006

PRINTB @EF0503,R1 ;PRINT THE MESSAGE.

```
MOV R1,-(SP)
MOV @EF0503,-(SP)
MOV @2,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD @6,SP
```

1910  
 1911 012016  
 012016  
 012016 104423

2\$: ENDMSG

L10003: TRAP C\$MSG



1913  
1914  
1915  
1916  
1917  
1918  
1919  
1920  
1921  
1922  
1923  
1924  
1925  
1926  
1927  
1928  
1929  
1930  
1931  
1932  
1933  
1934  
1935 012020  
012020  
1936 012020  
012020 004567 172034  
1937  
1938 012024 012700 000100  
1939 012030 046700 170154  
1940 012034 001024  
1941  
1942  
1943 012036  
012036 010146  
012040 012746 004156  
012044 012746 000002  
012050 010600  
012052 104414  
012054 062706 000006  
1944  
1945 012060 016702 171770  
1946 012064  
012064 010246  
012066 012746 004163  
012072 012746 000002  
012076 010600  
012100 104414  
012102 062706 000006  
1947  
1948 012106  
012106 004736  
1949 012110  
012110  
012110 104423

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER1603 -
;*****
;* THIS ERROR REPORTING ROUTINE IS USED TO PRINT OUT A BASIC ERROR
;* MESSAGE, ALONG WITH A MESSAGE INFORMING THE OPERATOR WHICH TEST IS
;* ABOUT TO BE ABORTED, PROVIDED EXTENDED ERROR INFORMATION HAS BEEN
;* REQUESTED, OTHERWISE ONLY A "TEST FAILURE" MESSAGE WILL BE PRINTED.
;*
;* INPUTS: R1 - CONTAINS THE ADDRESS OF THE MESSAGE TO BE PRINTED,
;* ERRMSG - CONTAINS THE ADDRESS OF THE MESSAGE THAT INDICATES
;* THE TEST THAT IS BEING PERFORMED, EG DMA, BREAK ETC.
;*
;* OUTPUTS: MESSAGES ARE PRINTED AT THE OPERATORS CONSOLE.
;* "TESTNAME TEST ABORTED"
;*
;* CALLING SEQUENCE: INCLUDE THE LABEL "ER1603" AS THE MESSAGE POINTER
;* PARAMETER IN THE DRS ERROR REPORT MACRO CALL.
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: NONE.
;*****
```

```
BGNMSG ER1603
SAVE JSR ER1603::
R5,PREG05 ;SAVE THE CONTENTS OF THE GPRS.
;CALL REGISTER SAVE SUBRT.

MOV #BIT06,R0 ;TRY TO CLEAR THE
BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
BNE 2$ ;EXIT IF FLAG NOT SET.

PRINTB #EF0503,R1 ;PRINT BASIC MESSAGE ON OPERATORS CONSOLE.
MOV R1,-(SP)
MOV #EF0503,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP

MOV ERRMSG,R2 ;GET THE "TEST MESSAGE".
PRINTB #EF1601,R2 ;PRINT "TEST ABORTED" MESSAGE.
MOV R2,-(SP)
MOV #EF1601,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP

2$: PASS ;RESTORE THE CONTENTS OF THE GPRS.
JSR PC,0(SP) ;RETURN TO PREG05 SUBRT.

L10004:
TRAP C$MSG
```



1951  
1952  
1953  
1954  
1955  
1956  
1957  
1958  
1959  
1960  
1961  
1962  
1963  
1964  
1965  
1966  
1967  
1968  
1969  
1970  
1971  
1972

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER5801 -
;*****
;* THIS IS AN ERROR REPORTING ROUTINE WHICH PRINTS THE MESSAGE PASSED
;* AS A PARAMETER IN R1, AND THE RXTIMER VALUE IN R2, PROVIDED
;* EXTENDED ERROR REPORTING HAS BEEN REQUESTED.
;* THIS ROUTINE IS USED BY THE RXTIMER TEST.
;*
;* INPUTS: R1 - ADDRESS OF THE MESSAGE TO PRINT.
;* R2 - RXTIMER VALUE.
;*
;* OUTPUTS: THE MESSAGE FOLLOWED BY THE RXTIMER VALUE ARE PRINTED AT
;* THE OPERATOR CONSOLE.
;*
;* CALLING SEQUENCE: INCLUDE THE LABEL ER5801 AS THE MESSAGE POINTER
;* PARAMETER IN THE DRS ERROR REPORT MACRO CALL.
;*
;* COMMENTS: THE MESSAGE IS PRINTED AS BASIC ERROR INFORMATION AND THE
;* RXTIMER VALUE IS PRINTED AS A 3 DIGIT DECIMAL NUMBER.
;*
;* SUBORDINATE ROUTINES USED: NONE.
;*****
```

1973 012112  
012112  
1974 012112 032767 000100 170070  
1975 012120 001422  
1976  
1977 012122  
012122 010146  
012124 012746 004156  
012130 012746 000002  
012134 010600  
012136 104414  
012140 062706 000006  
1978 012144  
012144 010246  
012146 012746 004215  
012152 012746 000002  
012156 010600  
012160 104414  
012162 062706 000006  
1979 012166  
012166  
012166 104423

```
BGNMSG ER5801
BIT #BIT06,OPTION ;HAS EXTENDED ERROR REPORTING BEEN REQUESTED ?
BEQ 2$ ;EXIT WITH "TEST FAILED" MESSAGE IF NOT.
PRINTB #EF0503,R1
MOV R1,-(SP)
MOV #EF0503,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP
PRINTB #EF5801,R2
MOV R2,-(SP)
MOV #EF5801,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP
2$: ENDMSG
L10005: TRAP C$MSG
```

1981  
1982  
1983  
1984  
1985  
1986  
1987  
1988  
1989  
1990  
1991  
1992  
1993  
1994  
1995  
1996  
1997  
1998  
1999  
2000  
2001  
2002  
2003  
2004  
2005  
2006  
2007  
2008  
2009  
2010  
2011  
2012  
2013  
2014  
2015  
2016  
2017

012170  
012170  
012170 004567 171664  
012174 032767 000100 170006  
012202 001433  
  
012204  
012204 010346  
012206 012746 004156  
012212 012746 000002  
012216 010600  
012220 104414  
012222 062706 000006  
012226  
012226 010146  
012230 012746 004270  
012234 012746 000002  
012240 010600  
012242 104415  
012244 062706 000006  
012250  
012250 010246  
012252 012746 004320  
012256 012746 000002  
012262 010600  
012264 104415  
012266 062706 000006

.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER5901 -  
:\*\*\*\*\*  
: \* THIS IS AN ERROR REPORTING ROUTINE WHICH PRINTS AN ADDITIONAL  
: \* MESSAGE IN ADDITION TO THE "TEST FAILED" MESSAGE AND ALSO A  
: \* MESSAGE SHOWING THE EXPECTED VALUE OF A PIECE OF DATA AND THE  
: \* ACTUAL VALUE OF THAT DATA. THE DATA IS PRINTED AS A 3 DIGIT  
: \* DECIMAL NUMBER.  
: \*  
: \* INPUTS : R1 - EXPECTED VALUE OF DATA,  
: \* R2 - ACTUAL VALUE OF DATA,  
: \* R3 - ADDRESS OF THE MESSAGE TO PRINT.  
: \*  
: \* OUTPUTS : MESSAGES ARE PRINTED AT THE OPERATORS CONSOLE.  
: \*  
: \* CALLING SEQUENCE: INCLUDE THE LABEL "ER5901" AS THE MESSAGE POINTER  
: \* PARAMETER IN THE DRS ERROR REPORT MACRO CALL.  
: \*  
: \* COMMENTS :  
: \*  
: \* SUBORDINATE ROUTINES USED : NONE.  
:\*\*\*\*\*

BGNMSG ER5901  
  
ER5901::  
SAVE ;SAVE THE GPR CONTENTS.  
JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.  
BIT #BIT06,OPTION ;EXIT THE ROUTINE IF EXTENDED  
BEQ 60# ;ERROR REPORTING IS NOT REQUESTED.  
  
: \*  
: \* REPORT EXTENDED ERROR INFORMATION  
: \*  
PRINTB #EF0503,R3 ;PRINT THE MESSAGE.  
  
MOV R3,-(SP)  
MOV #EF0503,-(SP)  
MOV #2,-(SP)  
MOV SP,R0  
TRAP C\$PNTB  
ADD #6,SP  
  
PRINTX #EF5901,R1 ;PRINT THE "EXPECTED VALUE" MESSAGE.  
  
MOV R1,-(SP)  
MOV #EF5901,-(SP)  
MOV #2,-(SP)  
MOV SP,R0  
TRAP C\$PNTX  
ADD #6,SP  
  
PRINTX #EF5902,R2 ;PRINT THE "ACTUAL VALUE" MESSAGE.  
  
MOV R2,-(SP)  
MOV #EF5902,-(SP)  
MOV #2,-(SP)  
MOV SP,R0  
TRAP C\$PNTX  
ADD #6,SP



2018 012272  
012272 004736  
2019  
2020 012274  
012274  
012274 104423

60\$: PASS  
ENDMSG

JSR ;RESTORE THE GPR CONTENTS.  
PC,0(SP)+ ;RETURN TO PREG05 SUBRT.

L10006: TRAP C\$MSG

2022  
2023  
2024  
2025  
2026  
2027  
2028  
2029  
2030  
2031  
2032  
2033  
2034  
2035  
2036  
2037  
2038  
2039  
2040  
2041  
2042  
2043  
2044  
2045  
2046  
2047  
2048  
2049  
2050  
2051  
2052  
2053  
2054  
2055  
2056  
2057  
2058

012276  
012276  
012276 032767 000100 167704  
012304 001434  
012306  
012306 010446  
012310 010346  
012312 012746 004417  
012316 012746 000003  
012322 010600  
012324 104414  
012326 062706 000010  
012332  
012332 010146  
012334 012746 004270  
012340 012746 000002  
012344 010600  
012346 104415  
012350 062706 000006  
012354  
012354 010246  
012356 012746 004320  
012362 012746 000002  
012366 010600  
012370 104415  
012372 062706 000006

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER6001 -
;*****
; THIS IS AN ERROR REPORTING ROUTINE WHICH PRINTS OUT A MESSAGE
; AT THE CONSOLE INFORMING THE OPERATOR OF AN ERROR ON A PARTICULAR
; LINE. THE ROUTINE ALSO PRINTS OUT A MESSAGE INFORMING THE OPERATOR
; OF WHAT DATA WAS "EXPECTED" AND WHAT "ACTUAL" DATA WAS FOUND, IN THE
; FORM OF A 3 DIGIT DECIMAL NUMBER.
; IF EXTENDED ERROR REPORTING HAS NOT BEEN REQUESTED THEN ONLY THE
; "TEST FAILED" MESSAGE WILL BE PRINTED.
;
; INPUTS : R1 - EXPECTED DATA
;          R2 - ACTUAL DATA
;          R3 - ADDRESS OF THE MESSAGE TO PRINT
;          R4 - LINE NUMBER ON WHICH THE ERROR OCCURED
;
; OUTPUTS : MESSAGES ARE PRINTED AT THE OPERATOR CONSOLE
;           " MESSAGE' ON LINE #"
;           "EXPECTED : " ##
;           " ACTUAL : " ##
;
; CALLING SEQUENCE : INCLUDE THE LABEL "ER6001" AS THE ERROR ROUTINE
;                    POINTER PARAMETER IN THE DRS ERROR REPORT MACRO CALL.
;
; SUBORDINATE ROUTINES CALLED : NONE
;*****
```

BGNMSG ER6001

ER6001::

```
BIT #BIT06,OPTION ;EXIT THE ROUTINE IF EXTENDED
BEQ 601 ;ERROR REPORTING IS NOT REQUESTED.
```

```
; REPORT EXTENDED ERROR INFORMATION
```

```
PRINTB #EF7801,R3,R4 ;PRINT THE MESSAGE WITH THE LINE NUMBER.
```

```
MOV R4,-(SP)
MOV R3,-(SP)
MOV #EF7801,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C:PNTB
ADD #10,SP
```

```
PRINTX #EF5901,R1 ;PRINT THE "EXPECTED" DATA MESSAGE.
```

```
MOV R1,-(SP)
MOV #EF5901,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C:PNTX
ADD #6,SP
```

```
PRINTX #EF5902,R2 ;PRINT THE "ACTUAL" DATA MESSAGE.
```

```
MOV R2,-(SP)
MOV #EF5902,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C:PNTX
ADD #6,SP
```



2059 012376  
012376  
012376 104423

604: ENDMSG

L10007: TRAP C1MSG

2061  
2062  
2063  
2064  
2065  
2066  
2067  
2068  
2069  
2070  
2071  
2072  
2073  
2074  
2075  
2076  
2077  
2078  
2079  
2080  
2081  
2082  
2083  
2084  
2085  
2086  
2087  
2088  
2089  
2090  
2091  
2092  
2093  
2094  
2095  
2096  
2097  
2098  
2099  
2100  
2101  
2102  
2103  
2104

012400  
012400  
012400 004567 171454  
012404 032767 000100 167576  
012412 001433  
012414 005002  
012416 012703 000020  
012422 010146  
012424 012746 004156  
012430 012746 000002  
012434 010600  
012436 104414  
012440 062706 000006  
012444 000241  
012446 006205  
012450 103011  
012452 010246  
012454 012746 004350  
012460 012746 000002  
012464 010600  
012466 104414

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER6401 -
;*****
;* THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS ADDITIONAL ERROR
;* INFORMATION AFTER THE ERROR MESSAGE HEADER, PROVIDED EXTENDED ERROR
;* REPORTING HAS BEEN ENABLED.
;* THIS SUBROUTINE IS PASSED A GPR CONTAINING FLAGS WHICH INDICATE
;* THE LINE(S) FOR WHICH THE ERROR CONDITION SHOULD BE REPORTED.
;*
;* INPUTS: R1 - ADDRESS OF THE MESSAGE TO BE PRINTED BY THIS ROUTINE.
;* R5 - CONTAINS THE ERROR FLAGS, (1 FLAG PER LINE).
;*
;* OUTPUTS: MESSAGES ARE PRINTED AT THE OPERATOR CONSOLE.
;*
;* CALLING SEQUENCE: LOAD THE ADDRESS OF THE MESSAGE IN R1.
;* INCLUDE THE LABEL "ER6401" AS THE MESSAGE POINTER
;* PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
;*
;* COMMENTS: THE OUTPUT FORMAT OF THIS MESSAGE IS:
;* TEXT MESSAGE
;* @NN
;* @NN
;*
;* WHERE EACH "@NN" IS THE NUMBER OF A LINE WITH THE ERROR.
;*
;* SUBORDINATE ROUTINES USED: NONE.
;*****
```

BGNMSG ER6401

SAVE

```
ER6401::
;SAVE THE CONTENTS OF THE GPRS.
JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
```

```
;*
;* EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
;*
```

```
BIT @BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
BEQ 60; ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
;DURING THE SOFTWARE QUESTIONS.
```

```
CLR R2 ;CLEAR LINE NUMBER TO ZERO.
MOV @NUMLNS,R3 ;SET UP MAX LINE COUNT.
PRINTB @EF0503,R1 ;PRINT MESSAGE.
```

```
MOV R1,-(SP)
MOV @EF0503,-(SP)
MOV @2,-(SP)
MOV SP,R0
TRAP C:PNTB
ADD @6,SP
```

```
24: CLC ;CLEAR CARRY.
ASR R5 ;SHIFT FLAG OUT INTO CARRY BIT.
BCC 4; ;SKIP ERROR REPORT IF CLEAR.
PRINTB @EF6401,R2 ;PRINT MESSAGE.
```

```
MOV R2,-(SP)
MOV @EF6401,-(SP)
MOV @2,-(SP)
MOV SP,R0
TRAP C:PNTB
```



012470 062706 000006  
2105 012474 005202  
2106 012476 020302  
2107 012500 001362  
2108 012502  
012502 004736  
2109 012504  
012504  
012504 104423

4\$: INC R2  
CMP R3,R2  
BNE 2\$  
60\$: PASS  
ENDMSG

JSR

;INCREMENT LINE COUNT. ADD #6,SP  
;CHECK IF MAX LINE COUNT EXCEEDED.  
;LOOP IF NOT DONE.  
;RESTORE THE SAVED CONTENTS OF THE GPRS.  
PC,@(SP)+ ;RETURN TO PREG05 SUBRT.

L10010:  
TRAP C\$MSG

2111  
2112  
2113  
2114  
2115  
2116  
2117  
2118  
2119  
2120  
2121  
2122  
2123  
2124  
2125  
2126  
2127  
2128  
2129  
2130  
2131  
2132  
2133  
2134  
2135  
2136  
2137  
2138  
2139  
2140  
2141  
2142  
2143  
2144

012506  
012506

012516  
012516 010346  
012520 010146  
012522 012746 004417  
012526 012746 000003  
012532 010600  
012534 104414  
012536 062706 000010

012542  
012542  
012542 104423

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER7801 -
;*****
;* THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS AN ADDITIONAL ERROR
;* MESSAGE WHOSE ADDRESS IS PASSED AS AN INPUT PARAMETER. A LINE NUMBER
;* IS INCLUDED AT THE END OF THE MESSAGE. THE MESSAGE IS PRINTED ONLY IF
;* EXTENDED ERROR REPORTING IS REQUESTED.
;*
;* INPUTS: R1 - ADDRESS OF THE MESSAGE TO PRINT.
;* R3 - NUMBER OF LINE ON WHICH ERROR OCCURRED.
;*
;* OUTPUTS: A MESSAGES IS PRINTED AT THE OPERATOR CONSOLE.
;*
;* CALLING SEQUENCE: LOAD THE ADDRESS OF THE MESSAGE IN R1.
;* LOAD THE LINE NUMBER INTO R3.
;* INCLUDE THE LABEL "ER7801" AS THE MESSAGE POINTER
;* PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
;*
;* COMMENTS: THE MESSAGE IS PRINTED AS BASIC ERROR INFORMATION.
;*
;* SUBORDINATE ROUTINES USED: NONE.
;*****
```

BGNMSG ER7801

ER7801::

```
;*
; EXIT IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
;*-
BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
BEQ 2$ ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
;DURING THE SOFTWARE QUESTIONS.
```

PRINTB #EF7801,R1,R3 ;PRINT THE MESSAGE.

```
MOV R3,-(SP)
MOV R1,-(SP)
MOV #EF7801,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #10,SP
```

2\$: ENDMSG

L10011: TRAP C\$MSG



2146  
2147  
2148  
2149  
2150  
2151  
2152  
2153  
2154  
2155  
2156  
2157  
2158  
2159  
2160  
2161  
2162  
2163  
2164  
2165  
2166  
2167  
2168  
2169  
2170  
2171  
2172  
2173  
2174  
2175  
2176  
2177  
2178  
2179

012544  
012544

012544 032767 000100 167436  
012552 001433  
012554 010146 004455  
012554 012746 000002  
012562 012746 000002  
012566 010600  
012570 104414  
012572 062706 000006  
012576 010446  
012600 012746 004537  
012604 012746 000002  
012610 010600  
012612 104415  
012614 062706 000006  
012620 010246  
012622 012746 004611  
012626 012746 000002  
012632 010600  
012634 104415  
012636 062706 000006

012642 104423

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER9001 -
;*****
;* THIS IS AN ERROR REPORTING SUBROUTINE WHICH REPORTS AN UNEXPECTED
;* CODE WHICH HAS BEEN FOUND IN THE DUT CSR. THIS CODE CAN BE A BMP
;* CODE, A SELF-TEST CODE, OR A MODEM STATUS CODE.
;*
;* INPUTS: R1 - ADDRESS OF MESSAGE TO PRINT FIRST.
;* R2 - SINGLE BYTE CODE WHICH HAS BEEN READ FROM THE DUT.
;* R4 - LINE NUMBER ASSOCIATED WITH THE CODE.
;*
;* OUTPUTS: A MESSAGES IS PRINTED AT THE OPERATOR CONSOLE.
;*
;* CALLING SEQUENCE: INCLUDE THE LABEL "ER9001" AS THE MESSAGE POINTER
;* PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
;*
;* COMMENTS: THE MESSAGE IS PRINTED AS BASIC AND EXTENDED ERROR INFORMATION.
;*
;* SUBORDINATE ROUTINES USED: NONE.
;*****
```

BGNMSG ER9001

ER9001::

```
;*
; EXIT IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
;*
```

```
BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
BEQ 2# ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
;DURING THE SOFTWARE QUESTIONS.
```

```
PRINTB #EF9001,R1 ;REPORT TYPE OF CODE FOUND.
```

```
MOV R1,-(SP)
MOV #EF9001,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP
```

```
PRINTX #EF9002,R4 ;REPORT THE LINE NUMBER OF THE CODE.
```

```
MOV R4,-(SP)
MOV #EF9002,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTX
ADD #6,SP
```

```
PRINTX #EF9003,R2 ;REPORT THE CODE WHICH WAS FOUND.
```

```
MOV R2,-(SP)
MOV #EF9003,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTX
ADD #6,SP
```

```
2#: ENDMSG
```

```
L10012: TRAP C$MSG
```

2181  
2182  
2183  
2184  
2185  
2186  
2187  
2188  
2189  
2190  
2191  
2192  
2193  
2194  
2195  
2196  
2197  
2198  
2199  
2200  
2201  
2202  
2203 012644  
012644  
2204  
2205  
2206  
2207  
2208 012644 032767 000100 167336  
2209 012652 001462  
2210  
2211  
2212 012654 006203  
2213 012656 042702 177400  
2214 012662  
012662 010346  
012664 010146  
012666 012746 004721  
012672 012746 000003  
012676 010600  
012700 104414  
012702 062706 000010  
2215 012706  
012706 010246  
012710 012746 010647  
012714 012746 004640  
012720 012746 000003  
012724 010600  
012726 104415  
012730 062706 000010  
2216 012734 005704  
2217 012736 100414  
2218 012740  
012740 010446  
012742 012746 010623  
012746 012746 004640  
012752 012746 000003

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER9002 -
;*****
;* THIS IS AN ERROR REPORTING SUBROUTINE WHICH IS INTENDED FOR USE IN THE
;* TRANSMISSION AND RECEPTION TESTS. IT REPORTS THE TYPE OF ERROR WHICH
;* HAS OCCURRED WHEN INCORRECT DATA IS RECEIVED FROM THE DUT. THIS
;* ROUTINE ALSO REPORTS THE READ AND EXPECTED DATA VALUES.
;*
;* INPUTS: R1 - ADDRESS OF MESSAGE TO PRINT FIRST.
;* R2 - DATA BYTE READ FROM THE DUT.
;* R3 - LINE NUMBER MULTIPLIED BY 2.
;* R4 - EXPECTED DATA BYTE, BIT 15 SET IF "NONE".
;*
;* OUTPUTS: A MESSAGES IS PRINTED AT THE OPERATOR CONSOLE.
;*
;* CALLING SEQUENCE: INCLUDE THE LABEL "ER9002" AS THE MESSAGE POINTER
;* PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
;*
;* COMMENTS: THE MESSAGE IS PRINTED AS BASIC AND EXTENDED ERROR INFORMATION.
;*
;* SUBORDINATE ROUTINES USED: PRTLPR.
;*****
```

```
BGNMSG ER9002
ER9002::
; *
; * EXIT IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
; *
; * BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
; * BEQ 62$ ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
; * ;DURING THE SOFTWARE QUESTIONS.
; *
; * ASR R3 ;CALCULATE THE LINE NUMBER.
; * BIC #177400,R2 ;MASK OUT ALL BUT DATA IN READ CHAR.
; * PRINTB #EF9006,R1,R3 ;PRINT THE FIRST LINE OF THE MESSAGE.
; *
; * MOV R3,-(SP)
; * MOV R1,-(SP)
; * MOV #EF9006,-(SP)
; * MOV #3,-(SP)
; * MOV SP,R0
; * TRAP C$PNTB
; * ADD #10,SP
; *
; * PRINTX #EF9004,#EM9010,R2 ;PRINT ACTUAL DATA.
; *
; * MOV R2,-(SP)
; * MOV #EM9010,-(SP)
; * MOV #EF9004,-(SP)
; * MOV #3,-(SP)
; * MOV SP,R0
; * TRAP C$PNTX
; * ADD #10,SP
; *
; * TST R4 ;CHECK FOR "NONE" CODE SET IN EXPECTED DATA.
; * BMI 2$ ;BRANCH TO PRINT "NONE" MESSAGE IF FLAG SET.
; * PRINTX #EF9004,#EM9009,R4 ;PRINT EXPECTED DATA.
; *
; * MOV R4,-(SP)
; * MOV #EM9009,-(SP)
; * MOV #EF9004,-(SP)
; * MOV #3,-(SP)
```





2224  
2225  
2226  
2227  
2228  
2229  
2230  
2231  
2232  
2233  
2234  
2235  
2236  
2237  
2238  
2239  
2240  
2241  
2242  
2243  
2244  
2245

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER9004 -
;*****
;* THIS IS AN ERROR REPORTING SUBROUTINE WHICH REPORTS ERROR SUMMARIES
;* FOR LINES WHICH HAVE EXCEEDED THE SPECIFIED MAXIMUM NUMBER OF
;* INDIVIDUAL RECEPTION ERRORS, PROVIDED EXTENDED ERROR REPORTING HAS
;* BEEN REQUESTED BY THE OPERATOR.
;*
;* INPUTS: R1 - ADDRESS OF MESSAGE TO PRINT FIRST,
;* ERCNTB - LABEL AT BASE OF LINE ERROR COUNTERS TABLE,
;* ERSMRF - "REPORT ERROR SUMMARY FOR LINE" FLAGS.
;*
;* OUTPUTS: A MESSAGE IS PRINTED AT THE OPERATOR CONSOLE.
;*
;* CALLING SEQUENCE: INCLUDE THE LABEL "ER9004" AS THE MESSAGE POINTER
;* PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
;*
;* COMMENTS: THE MESSAGE IS PRINTED AS BASIC AND EXTENDED ERROR INFORMATION.
;* THE CONTENTS OF GPR'S R2, R3, R4, AND R5 ARE DESTROYED.
;*
;* SUBORDINATE ROUTINES USED: NONE.
;*****
```

2246 013022  
013022  
2247 013022 012700 000100  
2248 013026 046700 167156  
2249 013032 001040  
2250 013034  
013034 012746 010673  
013040 012746 004156  
013044 012746 000002  
013050 010600  
013052 104414  
013054 062706 000006  
2251 013060 005002  
2252 013062 016703 167524  
2253 013066 005004  
2254 013070 000241  
2255 013072 006003  
2256 013074 103013  
2257 013076  
013076 016446 002614  
013102 010246  
013104 012746 004745  
013110 012746 000003  
013114 010600  
013116 104415  
013120 062706 000010  
2258 013124 012405  
2259 013126 005202  
2260 013130 005703  
2261 013132 001356  
2262 013134  
013134  
013134 104423

```
BGNMSG ER9004
ER9004::
MOV #BIT06,R0 ;TRY TO CLEAR THE
BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
BNE 6$ ;EXIT IF FLAG NOT SET.
PRINTB #EF0503,#EM9014 ;REPORT THE SECONDARY ERROR MESSAGE.
MOV #EM9014,-(SP)
MOV #EF0503,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C:PNTB
ADD #6,SP

CLR R2 ;CLEAR THE LINE COUNTER.
MOV ERSMRF,R3 ;GET THE ERROR SUMMARY FLAGS.
CLR R4 ;CLEAR "LINE COUNTER TIMES 2" OFFSET.
2$: CLC ;CLEAR THE CARRY FOR THE FOLLOWING ROTATE.
ROR R3 ;SHIFT ANOTHER ERROR SUMMARY FLAG INTO CARRY.
BCC 4$ ;SKIP PRINTING MESSAGE IF FLAG FOR LINE CLEAR.
PRINTX #EF9010,R2,ERCNTB(R4)
MOV ERCNTB(R4),-(SP)
MOV R2,-(SP)
MOV #EF9010,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C:PNTX
ADD #10,SP

4$: MOV (R4),R5 ;INCREMENT THE LINE OFFSET BY 2.
INC R2 ;INCREMENT THE LINE COUNTER.
TST R3 ;CHECK THE ERROR SUMMARY FLAGS.
BNE 2$ ;IF MORE FLAGS SET, LOOP TO DO OTHER LINES.

6$: ENDMMSG
L10014: TRAP C:MSG
```



2264  
2265  
2266  
2267  
2268  
2269  
2270  
2271  
2272  
2273  
2274  
2275  
2276  
2277  
2278  
2279  
2280  
2281  
2282

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER9101 -
:*****
: THIS IS A GENERAL ERROR REPORTING SUBROUTINE WHICH REPORTS A MESSAGE
: WHICH TAKES A SINGLE, 2 DIGIT DECIMAL ARGUMENT AFTER THE END OF AN
: ASCII MESSAGE.
:
: INPUTS: R1 - VALUE TO BE PRINTED AFTER MSG AS 2 DECIMAL DIGITS.
: R2 - ADDRESS OF MESSAGE TO PRINT FIRST.
:
: OUTPUTS: A MESSAGES IS PRINTED AT THE OPERATOR CONSOLE.
:
: CALLING SEQUENCE: INCLUDE THE LABEL "ER9101" AS THE MESSAGE POINTER
: PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
:
: COMMENTS: THE MESSAGE IS PRINTED AS BASIC ERROR INFORMATION.
:
: SUBORDINATE ROUTINES USED: NONE.
:*****
```

2283 013136  
013136

BGNMSG ER9101

ER9101::

2284  
2285 013136 012700 000100  
2286 013142 046700 167042  
2287 013146 001012

```
MOV #BIT06,R0 ;TRY TO CLEAR THE
BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
BNE 2$ ;EXIT IF FLAG,NOT SET.
```

2288  
2289  
2290 013150  
013150 010146  
013152 010246  
013154 012746 004721  
013160 012746 000003  
013164 010600  
013166 104414  
013170 062706 000010

PRINTB #EF9006,R2,R1 ;REPORT THE STRING FOLLOWED BY THE NUMBER.

```
MOV R1,-(SP)
MOV R2,-(SP)
MOV #EF9006,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #10,SP
```

2291  
2292 013174  
013174  
013174 104423

2\$: ENDMSG

L10015: TRAP C\$MSG

2294  
2295  
2296  
2297  
2298  
2299  
2300  
2301  
2302  
2303  
2304  
2305  
2306  
2307  
2308  
2309  
2310  
2311  
2312  
2313  
2314  
2315 013176  
013176  
2316 013176 004567 170656  
013176  
2317  
2318 013202 012700 000100  
2319 013206 046700 166776  
2320 013212 001064  
2321  
2322 013214  
013214 010146  
013216 012746 004156  
013222 012746 000002  
013226 010600  
013230 104414  
013232 062706 000006  
2323 013236 012703 002412  
2324 013242 012705 011257  
2325 013246 012301  
2326 013250 012304  
2327 013252 004767 000056  
2328 013256 020302  
2329 013260 103772  
2330  
2331  
2332  
2333  
2334  
2335  
2336 013262 020227 002606  
2337 013266 001036  
2338 013270 005762 000002  
2339 013274 001433  
2340 013276 012301  
2341 013300 011304  
2342 013302 012705 011307

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER9301 -
*****
; THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS ANY BMP CODES
; THAT ARE FOUND IN THE BMP CODE QUEUE, TOGETHER WITH THE NUMBER OF
; THE TEST THAT WAS EXECUTING AT THE TIME THE BMP CODE WAS LOGGED.
; PROVIDED EXTENDED ERROR REPORTING HAS BEEN ENABLED.
;
; INPUTS: R1 - THE ADDRESS OF THE FIRST MESSAGE TO BE REPORTED,
; R2 - THE ADDRESS OF THE NEXT EMPTY CELL IN THE QUEUE.
;
; OUTPUTS: THE TEST NUMBER FOLLOWED BY THE BMP CODE ARE PRINTED AT THE
; OPERATOR CONSOLE.
;
; CALLING SEQUENCE: INCLUDE THE LABEL "ER9301" AS THE MESSAGE POINTER
; PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
;
; COMMENTS: THE MESSAGE IS PRINTED AS BASIC ERROR INFORMATION.
;
; SUBORDINATE ROUTINES USED: NONE.
*****
BGNMSG ER9301
ER9301::
SAVE ;SAVE THE GPRS ON THE STACK.
JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.

MOV #BIT06,R0 ;TRY TO CLEAR THE
BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
BNE 60$ ;EXIT IF FLAG NOT SET.

PRINTB #EF0503,R1 ;REPORT UNEXPECTED BMP CODES FOUND.
MOV R1,-(SP)
MOV #EF0503,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP

MOV #BMPCQB,R3 ;GET THE START ADDRESS OF THE BMP CODE QUEUE.
MOV #EM9302,R5 ;GET THE MESSAGE TO BE REPORTED.
2$: MOV (R3)+,R1 ;GET THE NUMBER OF THE TEST THAT WAS EXECUTING.
MOV (R3)+,R4 ;GET BMP CODE THAT WAS REPORTED OFF THE QUEUE.
JSR PC,50$ ;GO REPORT THE BMP CODE.
CMP R3,R2 ;CHECK IF ALL CODES HAVE BEEN REPORTED.
BLO 2$ ;IF IT IS NOT THE LAST BMP CODE THEN LOOP.

;
; CHECK IF OVERFLOW HAS OCCURRED.
; THE CONDITIONS FOR OVERFLOW ARE: THE POINTER CONTAINS THE ADDRESS OF THE
; LAST CELL IN THE QUEUE, AND A BMP CODE HAS ALREADY BEEN WRITTEN INTO THAT
; CELL.
;
;
CMP R2,#BMPCQE-4 ;CHECK IF THE POINTER IS AT THE LAST LOCATION.
BNE 60$ ;EXIT IF NOT AT THE LAST LOCATION.
TST 2(R2) ;CHECK FOR A BMP CODE IN THE LAST CELL
BEQ 60$ ;EXIT IF NO OVERFLOW HAS OCCURED, CELL EMPTY.
MOV (R3)+,R1 ;GET THE TEST NUMBER OFF THE QUEUE.
MOV (R3),R4 ;GET THE BMP CODE OFF THE QUEUE.
MOV #EM9303,R5 ;SELECT THE MESSAGE TO BE REPORTED.
```





2353  
2361  
2362  
2363  
2364  
2365  
2366

.SBTTL GLOBAL SUBROUTINES SECTION

!++  
: THE GLOBAL SUBROUTINES SECTION CONTAINS THE SUBROUTINES  
: THAT ARE USED IN MORE THAN ONE TEST.  
!--



2368  
2369  
2370  
2371  
2372  
2373  
2374  
2375  
2376  
2377  
2378  
2379  
2380  
2381  
2382  
2383  
2384  
2385  
2386  
2387  
2388  
2389  
2390  
2391  
2392  
2393  
2394  
2395  
2396 013370  
013370 004567 170464  
2397  
2398  
2399  
2400  
2401  
2402  
2403 013374 010400  
2404 013376 005100  
2405 013400 040002  
2406 013402 016705 166650  
2407  
2408  
2409  
2410  
2411  
2412  
2413 013406 000241  
2414 013410 006003  
2415 013412 103006  
2416 013414 010577 166606  
2417 013420 011100  
2418 013422 040400  
2419 013424 050200  
2420 013426 010011  
2421 013430 005205  
2422 013432 005703  
2423 013434 001365

```

.SBTTL GLOBAL SUBROUTINE - ALTFLD -
;*****
; - ALTER DEVICE REGISTER FIELDS ROUTINE -
; THIS SUBROUTINE ALTERS THE SPECIFIED FIELD OF THE SPECIFIED DEVICE
; REGISTER FOR THE SPECIFIED LINES. THIS ROUTINE CAN BE USED TO SET
; OR CLEAR BITS WITHIN SELECTED FIELDS OF SELECTED REGISTERS.
; USE EXAMPLES: SET RX.BAUD.RATE FIELDS ON LINES 3 AND 6.
; CLEAR TX.DMA BITS ON ALL LINES.
;
; INPUTS: R1 - ADDRESS OF THE REGISTERS TO ALTER.
; R2 - BIT FIELDS SET TO DESIRED STATES.
; R3 - BIT MAP OF LINES FOR WHICH TO ALTER REGISTER.
; R4 - MASK OF BITS TO ALTER (1 INDICATES CHANGE BIT).
; CSRA - CONTAINS THE ADDRESS OF THE DEVICE CSR.
; IESTAT - SAVED STATES OF THE INTERRUPT ENABLE BITS.
;
; OUTPUTS: DEVICE REGISTERS - SPECIFIED REGISTER FIELDS ALTERED.
; CSR IND.ADR.REG FIELD - DESTROYED.
;
; CALLING SEQUENCE: JSR PC,ALTFLD
;
; COMMENTS: THIS ROUTINE READS THE SPECIFIED REGISTERS FOR ALL LINES
; WITH NUMBERS LOWER THAN THE HIGHEST SPECIFIED LINE.
; THIS ROUTINE DOES NOT READ THE CSR.
;
; SUBROUTINES CALLED: NONE.
;--*****
ALTFLD:: SAVE JSR ;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
;
; SET UP TO LOOP FOR EACH LINE:
; PREPARE THE WORD TO BE ORED INTO THE REGISTER CONTENTS.
; SET UP THE WORD TO WRITE INTO THE IND.ADR.REG FIELD OF THE CSR.
;
; MOV R4,R0 ;CALCULATE THE NEW CONTENTS OF THE
; COM R0 ; REGISTER FIELDS WHICH ARE TO BE
; BIC R0,R2 ; ALTERED BY THIS ROUTINE.
; MOV IESTAT,R5 ;SET UP TO WRITE IND.ADR.REG FIELD TO 0.
;
; LOOP ONCE FOR EACH LINE, ALTERING THE SPECIFIED FIELD IN THE SPECIFIED
; REGISTER IF THE LINE HAS BEEN SELECTED FOR ALTERING.
; EXIT THE LOOP IF NO MORE LINES TO ALTER, OR IF WE HAVE ALTERED THE MAX
; ALLOWABLE NUMBER OF LINES (AS SPECIFIED BY NUMLNS).
;
; CLC ;PREPARE FOR ROTATE, "TST R5" DOES THIS BELOW.
; ROR R3 ;GET THE LINE SELECT BIT FOR THIS LINE.
20: BCC 40 ;SKIP SETUP IF LINE IS NOT SELECTED.
; MOV R5,DCSRA ;SET DUT CSR IND.ADR.REG FIELD TO THIS LINE.
; MOV (R1),R0 ;GET THE PRESENT CONTENTS OF THE REG TO ALTER.
; BIC R4,R0 ;CLEAR THE BIT FIELDS WE ARE TO ALTER.
; BIS R2,R0 ;OR IN THE NEW STATES OF THE FIELDS.
; MOV R0,(R1) ;WRITE THE NEW REGISTER CONTENTS TO THE REG.
40: INC R5 ;SET LINE NUMBER TO THE NEXT LINE.
; TST R3 ;CHECK FOR UNHANDLED LINES, CLEAR CARRY FLAG.
; BNE 20 ;LOOP IF SELECTED LINE(S) IS NOT HANDLED.

```

2424  
2425 013436  
013436 004736  
2426 013440 000207

601: PASS

RTS PC

JSR

;RESTORE GPRS.

PC,B(SP).

;RETURN TO CALLING ROUTNE.

;RETURN TO PREG05 SUBRT.



2428  
2429  
2430  
2431  
2432  
2433  
2434  
2435  
2436  
2437  
2438  
2439  
2440  
2441  
2442  
2443  
2444  
2445  
2446  
2447  
2448  
2449  
2450  
2451  
2452  
2453 013442  
013442 004567 170412  
2454 013446 126727 166550 000002  
2455 013454 001411  
2456  
2457  
2458  
2459 013456 005005  
2460 013460 010565 003750  
2461 013464 005205  
2462 013466 005205  
2463 013470 020527 000040  
2464 013474 002771  
2465 013476 000411  
2466  
2467  
2468  
2469 013500 012701 004030  
2470 013504 012702 003750  
2471 013510 112122  
2472 013512 105022  
2473 013514 020227 004010  
2474 013520 002773  
2475  
2476  
2477  
2478 013522 012701 003750  
2479 013526 012702 004010  
2480 013532 012103  
2481 013534 006203  
2482 013536 110322  
2483 013540 020127 004010

```
.SBTTL GLOBAL SUBROUTINE - ASLNTL -
;*****
;* - SETUP ASSOCIATED LINE NUMBER TABLES ROUTINE -
;* THIS ROUTINE SETS UP THE TWO TABLES WHICH ARE CONTAIN INFORMATION
;* ABOUT THE TX/RX LINE WHICH IS ASSOCIATED WITH A PARTICULAR RX/TX
;* LINE. ONE TABLE IS A TABLE OF WORDS WHICH CONTAINS WORD OFFSET
;* VALUES AND THE OTHER TABLE IS A TABLE OF BYTES WHICH CONTAINS
;* LINE NUMBER VALUES.
;*
;* INPUTS: LOPBCK - STORAGE FOR THE TYPE OF LOOPBACK ON THE DUT.
;* NUMLNS - EQUATED TO THE NUMBER OF LINES ON THE DUT.
;* STGTRB - LABEL AT BASE OF STAGGERED LINE ASSOCIATION TBL.
;* TXRLNB - LABEL AT BASE OF BYTE TX/RX LINE NUMBER TABLE.
;* TXRXLB - LABEL AT BASE OF WORD TX/RX LINE NUMBER TABLE.
;* TXRXLE - LABEL AT END OF WORD TX/RX LINE NUMBER TABLE.
;*
;* OUTPUTS: TXRXL, TXRLN - TABLES INITIALIZED FOR SELECTED LOOPBACK.
;*
;* CALLING SEQUENCE: JSR PC,ASLNTL
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: NONE.
;*****
ASLNTL:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
CMPB LOPBCK,#2 ;TEST FOR STAGGERED LOOPBACK.
BEQ 4$ ;GO SET UP STAGGERED TABLE IF STAGGERED LPBCK.
;*
;* SET UP THE WORD TABLE FOR NON-STAGGERED LOOPBACK.
;*****
2$: CLR R5 ;CLEAR THE LINE COUNTER
MOV R5, TXRXLB(R5) ;SET UP A WORD OF THE TABLE.
INC R5
INC R5 ;SET LINE COUNTER TO NEXT LINE OFFSET.
CMP R5,#2*NUMLNS ;TEST FOR ALL LINES DONE.
BLT 2$ ;LOOP UNTIL ALL LINES DONE.
BR 8$ ;GO SET UP THE BYTE TABLE.
;*
;* SET UP THE WORD TABLE FOR STAGGERED LOOPBACK.
;*****
4$: MOV #STGTRB,R1 ;SET UP THE SOURCE POINTER.
MOV #TXRXLB,R2 ;SET UP THE DESTINATION POINTER.
6$: MOVB (R1)+,(R2)+ ;MOVE A BYTE INTO THE TABLE.
CLRB (R2)+ ;CLEAR THE UPPER BYTE OF WORD TABLE ENTRY.
CMP R2,#TXRXLE ;COMPARE POINTER WITH END ADR OF TABLE.
BLT 6$ ;LOOP IF NOT AT END YET.
;*
;* SET UP THE BYTE TABLE BASED ON THE WORD ASSOCIATION TABLE.
;*****
8$: MOV #TXRXLB,R1 ;SET UP THE SOURCE POINTER.
MOV #TXRLNB,R2 ;SET UP THE DESTINATION POINTER.
10$: MOV (R1)+,R3 ;GET THE WORD OFFSET VALUE FROM WORD TABLE.
ASR R3 ;DIVIDE BY 2 TO GET LINE NUMBER VALUE.
MOVB R3,(R2)+ ;LOAD THE BYTE LINE NUMBER INTO TABLE.
CMP R1,#TXRXLE ;COMPARE SOURCE POINTER WITH ADR OF TABLE END.
```

2484 013544 002772  
2485  
2486 013546 004736  
013546  
2487 013550 000207

BLT 10\$  
60\$: PASS  
RTS PC

JSR

;LOOP IF NOT AT END OF TABLE YET.

;RESTORE GPRS.  
PC,0(SP),

;RETURN TO PREG05 SUBRT.



```

2489 .SBTTL GLOBAL SUBROUTINE - CALMSL -
2490 : * *****
2491 : * - CALIBRATE MILLI SECOND LOOP COUNT SUBROUTINE -
2492 : * THIS SUBROUTINE CALIBRATES THE TIMING LOOP WHICH IS USED IN THE MSLOOP
2493 : * ROUTINE. THIS SUBROUTINE CALCULATES A VALUE FOR THE MSLCNT VARIABLE
2494 : * WHICH IS THE NUMBER OF SOFTWARE LOOPS WHICH TAKES 1 MS TO EXECUTE IN
2495 : * THE MSLOOP ROUTINE. THIS ROUTINE CALIBRATES THE COUNT BY USING THE
2496 : * LINE TIME CLOCK (LTC), SO IF NO LTC IS AVAILABLE THE DEFAULT VALUE FOR
2497 : * THE DELAY COUNT MUST BE USED.
2498 : *
2499 : *
2500 : * INPUTS: MSLCNT - DEFAULT 1 MS DELAY LOOP COUNT VALUE, OR
2501 : * VALUE FROM PREVIOUS CALIBRATION.
2502 : * MSTICK - NUMBER OF MS PER LTC CLOCK TICK.
2503 : * TIMER1 - TIMER COUNTER CHANGED BY LTC INTERRUPT SERVICE RTN.
2504 : * CLKHRZ - NUMBER OF LTC CLICKS PER SECOND (50 OR 60).
2505 : *
2506 : * OUTPUTS: CARRY - SET IF LTC IS AVAILABLE, AND NEW CALIBRATION PERFORMED.
2507 : * MSLCNT - NEW 1 MS DELAY LOOP COUNT VALUE IF LTC AVAILABLE, OR
2508 : * UNCHANGED IF NO LTC IS AVAILABLE.
2509 : *
2510 : * CALLING SEQUENCE: JSR PC,CALMSL
2511 : *
2512 : * COMMENTS:
2513 : *
2514 : * SUBORDINATE ROUTINES CALLED: UNSDIV,OOPS.
2515 : * - - - - -
2516 : *
2517 013552 CALMSL:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
013552 004567 170302 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
2518 013556 005067 000210 CLR 62# ;CLEAR THE 2ND TIME FLAG.
2519 : *
2520 : * SYNCHRONIZE WITH THE LTC.
2521 : *
2522 013562 012705 000001 2# : MOV #1,R5 ;SET OUTER LOOP COUNTER TO 1 LOOP.
2523 : ;INCREASE THE VALUE LOADED INTO THIS COUNTER IF THE CPU
2524 : ;FOLLOWING LOOP FAILS ON FUTURE, FASTER PROCESSORS. CPU
2525 013566 005000 CLR R0 ;CLEAR THE WAIT FOR CLOCK INT COUNTER.
2526 013570 012767 000001 166516 MOV #1,TIMER1 ;SET UP COUNT OF 1 TO SYNCH WITH LTC.
2527 013576 005767 166512 4# : TST TIMER1 ;CHECK FOR COUNTER HAVING GONE TO ZERO.
2528 013602 001410 BEQ 6# ;JUMP OUT OF LOOP IF LTC HAS INTERRUPTED.
2529 013604 005200 INC R0 ;COUNT THIS ITERATION OF THE INNER LOOP.
2530 013606 001373 BNE 4# ;LOOP IF COUNTER HAS NOT TURNED OVER.
2531 013610 005305 DEC R5 ;DECREMENT THE INNER LOOP COUNTER.
2532 013612 003371 BGT 4# ;LOOP IF OUTER LOOP COUNT NOT UP.
2533 : *
2534 : * IF WE GOT NO LTC INTERRUPT, INDICATE THAT THERE IS NO LTC AVAILABLE.
2535 : * LTC MUST BE FLAKEY, OR NOT REALLY AN LTC AT ALL.
2536 : *
2537 013614 005067 166472 CLR CLKHRZ ;CLEAR LTC FREQUENCY WORD TO INDICATE NO LTC.
2538 013620 000241 CLC ;INDICATE FAILURE FOR RETURN.
2539 013622 000461 BR 60# ;BYPASS THE FOLLOWING CALIBRATION PROCEDURES.
2540 : *
2541 : * WE ARE NOW SYNCHRONIZED WITH THE LTC.
2542 : * SET UP FOR THE CALIBRATION LOOP.
2543 : *
2544 013624 012704 002314 6# : MOV #TIMER1,R4 ;WILL TEST TIMER1 IN THE LOOP BELOW.

```

```
2545 013630 005001          CLR    R1          ;CLEAR THE OUTER LOOP COUNTER.
2546 013632 005002          CLR    R2          ;INDICATE TO CHECK ALL BITS OF TIMER1.
2547 013634 005003          CLR    R3          ;INDICATE TO CHECK FOR TIMER1 CLEAR.
2548 013636 012714 000001    MOV    #1,(R4)     ;LOAD TIMER1 WITH COUNT OF 1.
2549
2550 013642 016705 166460    8$:   MOV    MSLCNT,R5 ;LOAD MS LOOP COUNT.
2551 013646 011400 10$:   MOV    (R4),R0     ;GET THE TIMER1 VALUE.
2552 013650 010067 000120    MOV    R0,64$     ;SAVE WORD (LIKE IN THE REAL LOOP).
2553 013654 040200          BIC    R2,R0       ;LEAVE ALL THE BITS.
2554 013656 020003          CMP    R0,R3       ;COMPARE AGAINST ZERO.
2555 013660 000261          SEC          ;SET CARRY IN CASE OF SUCCESS.
2556 013662 001406          BEQ    12$        ;EXIT LOOP IF TIMER1 HAS CLEARED.
2557 013664 005305          DEC    R5          ;COUNT DOWN THE INSIDE MS LOOP COUNT.
2558 013666 001367          BNE    10$        ;LOOP IF MS NOT UP.
2559 013670 005301          DEC    R1          ;DECREMENT THE MS TIME COUNT.
2560 013672 001363          BNE    8$         ;KEEP LOOPING.
2561 013674 004767 001160    JSR    PC,00PS     ;WE OVERFLOWED, SOMETHING IS WRONG, ABORT.
2562
2563          ;*
2564          ; WE HAVE NOW HAVE LOOP COUNT INFORMATION FOR ONE CLOCK TICK.
2565          ; WE HAVE NEGATIVE OF NUMBER OF OUTER LOOPS IN R1, EACH IS MSLCNT INNER LOOPS.
2566          ; WE HAVE THE PORTION OF THE LAST OUTER LOOP NOT EXECUTED, IN R5.
2567          ; NOW WE CALCULATE THE TOTAL NUMBER OF INNER LOOPS EXECUTED.
2568 013700 005401          ;-
2569 013702 016702 166420    12$:  NEG    R1          ;GET NUMBER OF OUTER LOOPS.
2570 013706 010203          MOV    MSLCNT,R2  ;GET THE NUMBER OF INNER LOOPS PER OUTER LOOP.
2571 013710 160502          MOV    R2,R3      ;COPY NUMBER OF LOOPS FOR MULTIPLY.
2572 013712 010204          SUB    R5,R2      ;CALC # OF INNER LOOPS DONE IN LAST OUTER LOOP
2573 013714 005005          MOV    R2,R4      ; AND ADD TO ACCUMULATOR LSWORD.
2574 013716 005301          CLR    R5          ;CLEAR ACCUMULATOR MSWORD.
2575 013720 100403          14$:  DEC    R1          ;CHECK R1 FOR 0 CONDITION
2576 013722 060304          BMI    16$        ; SKIP MULTIPLICATION IF ZERO
2577 013724 005505          ADD    R3,R4      ;MULTIPLY NUMBER OF INNER
2578 013726 000773          ADC    R5          ; LOOPS PER OUTER LOOP BY
2579          BR    14$ ;NUMBER OF OUTER LOOPS PERFORMED.
2580
2581          ;*
2582          ; DIVIDE THE TOTAL NUMBER OF INNER LOOPS BY THE NUMBER OF MS PER LTC TICK.
2583 013730 016701 166370    ;-
2584 013734 010403          16$:  MOV    MSTICK,R1  ;# OF MS PER LTC TICK IS DIVISOR.
2585 013740 004767 003336    MOV    R4,R3      ;LSWORD OF LOOP COUNT IS LSWORD OF DIVIDEND.
2586 013744 103402          MOV    R5,R2      ;MSWORD OF LOOP COUNT IS MSWORD OF DIVIDEND.
2587 013746 004767 001106    JSR    PC,UNSDIV  ;DIVIDE NUMBER OF LOOPS BY MS PER LTC TICK.
2588 013752 010167 166350    BCS    18$        ;BYPASS OOPS IF WE'RE OK.
2589 013756 005167 000010    JSR    PC,00PS   ;CLOCK ROUTINES ARE NOT LONG ENOUGH, OR BUG.
2590 013762 001277          18$:  MOV    R1,MSLCNT ;SET NEW VALUE FOR MS LOOP COUNT.
2591 013764 000261          COM    62$        ;SET THE 2ND ITERATION FLAGS IF 1ST ITERATION.
2592          SEC          ;BRANCH IF ONLY ONE ITERATION DONE.
2593          PASS        ;SET THE SUCCESS FLAG FOR EXIT.
2594 013766 004736          60$:  JSR    PC,0(SP)   ;RESTORE GPRS.
2595 013770 000207          RTS    PC        ;RETURN TO PREG05 SUBRT.
2596          ; CARRY - SUCCESS FLAG, SET IF SUCCESS.
2597 013772 000000          62$:  .WORD 0
2597 013774 000000          64$:  .WORD 0
          ;2ND CALIBRATION ITERATION FLAGS.
          ;DUMMY WORD FOR STORAGE OF THE READ WORD.
```



```

2599 .SBTTL GLOBAL SUBROUTINE - CHKBMP -
2600 ;** *****
2601 ;* - CHECK IF CHARACTER IS A BMP CODE -
2602 ;* THIS SUBROUTINE IS USED TO CHECK FOR BMP CODES.
2603 ;* IF A BMP CODE IS DETECTED, IT WILL BE SAVED ON THE QUEUE TO BE REPORTED
2604 ;* LATER. THE CARRY IS USED AS A FLAG TO INDICATE A CODE HAS BEEN FOUND.
2605 ;*
2606 ;* INPUTS: R2 - CONTAINS THE DATA TO BE CHECKED.
2607 ;*
2608 ;* OUTPUTS: R1 - CONTAINS THE MESSAGE TO BE REPORTED.
2609 ;* ERRBLK - CONTAINS THE ERROR REPORTING ROUTINE.
2610 ;* CARRY BIT IS USED TO INDICATE A BMP CODE FOUND, CARRY SET.
2611 ;*
2612 ;* CALLING SEQUENCE: JSR PC,CHKBMP
2613 ;*
2614 ;* COMMENTS:
2615 ;*
2616 ;* SUBORDINATE ROUTINES CALLED: SAVBMP.
2617 ;-- *****
2618
2619 013776 CHKBMP:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
013776 004567 170056 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
2620 014002 012700 170301 MOV #170301,R0 ;SET UP THE FLAGS OF A BMP CODE.
2621 014006 040200 BIC R2,R0 ;TRY TO CLEAR THE BMP CODE FLAGS.
2622 014010 001011 BNE 2$ ;IF NOT A BMP CODE, EXIT WITH FAILURE.
2623 014012 004767 002462 JSR PC,SAVBMP ;SAVE THE BMP CODE ON THE QUEUE.
2624 014016 012701 006401 MOV #EM5303,R1 ;PASS THE MESSAGE TO BE REPORTED.
2625 014022 012767 012020 170026 MOV #ER1603,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
2626 014030 000261 SEC ;PASS FLAG TO INDICATE SUCCESS, BMP CODE FOUND.
2627 014032 000401 BR 60$ ;EXIT.
2628 014034 000241 2$: CLC ;PASS FLAG TO INDICATE FAILURE.
2629 014036 60$: PASS R1 ;RESTORE GPRS, EXCEPT
014036 010166 000004 MOV R1,R1SLOT(SP) ;PUT R1 IN STACK SLOT.
014042 004736 JSR PC,@(SP) ;RETURN TO PREG05 SUBRT.
2630 ;R1 - CONTAINS THE ADDRESS OF ERROR MESSAGE.
2631 ;CARRY BIT - SET INDICATES SUCCESS.
2632 014044 000207 RTS PC

```

2634  
2635  
2636  
2637  
2638  
2639  
2640  
2641  
2642  
2643  
2644  
2645  
2646  
2647  
2648  
2649  
2650  
2651  
2652  
2653  
2654  
2655  
2656  
2657  
2658  
2659  
2660 014046  
014046 004567 170006  
2661 014052 010204  
2662 014054 005204  
2663 014056 006304  
2664 014060 006304  
2665 014062 160104  
2666  
2667  
2668  
2669 014064 012701 000005  
2670 014070 010203  
2671 014072 005002  
2672 014074 004767 003202  
2673 014100 010302  
2674 014102 010305  
2675 014104 160103  
2676  
2677 014106 060105  
2678 014110 062705 000002  
2679  
2680  
2681  
2682  
2683 014114 020504  
2684 014116 002402  
2685 014120 020304  
2686 014122 002417  
2687  
2688  
2689

```

.SBTTL GLOBAL SUBROUTINE - CKRXTM -
;+ *****
;+ - CHECK RX-INT DELAY TIME -
;+ THIS SUBROUTINE IS USED IN THE RXTIMER TEST AND IT CHECKS THAT THE
;+ RX-INT WAS DELAYED BY +/- 20% OF THE VALUE SET IN THE RXTIMER REG.
;+ IF THE ACTUAL DELAY TIME IS NOT WITHIN THIS MARGIN THEN AN ERROR
;+ IS REPORTED.
;+
;+ INPUTS: R1 - REMAINING NUMBER OF MILLI SECS OF THE TIME-OUT VALUE
;+ THE TIME-OUT VALUE BEING 4*(RXTIMER VALUE + 1).
;+ R2 - RXTIMER VALUE.
;+ ERRNBR - SET TO ERROR NUMBER OF FIRST ERROR IN THIS ROUTINE.
;+ ERRBLK - SET UP BY THIS ROUTINE.
;+ EXOERR - "EXIT ON ERROR" FLAG.
;+
;+ OUTPUTS: ERRBLK - MAY BE ALTERED.
;+ EXOERR - "EXIT ON ERROR" FLAG SET IF AN ERROR DETECTED AND
;+ EXTENDED ERROR REPORTING NOT REQUESTED.
;+
;+ CALLING SEQUENCE: JSR PC,CKRXTM
;+
;+ COMMENTS: THIS ROUTINE REPORTS ONE ERROR WITH THE NUMBER IN ERRNBR.
;+
;+ SUBORDINATE ROUTINES USED: ER5901,UNSDIV.
;+ *****
CKRXTM:: SAVE
;+
;+ JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
;+ MOV R2,R4 ;COPY THE RXTIMER VALUE.
;+ INC R4 ;CALCULATE THE TIME-OUT VALUE.
;+ ASL R4 ; AS 4*(RXTIMER VALUE+1)
;+ ASL R4
;+ SUB R1,R4 ;CALCULATE THE NUMBER OF MS THE RX-INT WAS DELAYED.
;+
;+ ; CALCULATE 20% OF THE RXTIMER VALUE.
;+
;+
;+ MOV #5,R1 ;PASS THE DIVISOR TO THE SUBR.
;+ MOV R2,R3 ;LOAD THE RXTIMER VALUE INTO THE LSW OF THE DIVIDEND.
;+ CLR R2 ;CLEAR THE MSW OF THE DIVIDEND.
;+ JSR PC,UNSDIV ;DIVIDE THE RXTIMER VALUE BY 5.
;+ MOV R3,R2 ;RESTORE THE RXTIMER VALUE.
;+ MOV R3,R5 ;COPY THE RXTIMER VALUE.
;+ SUB R1,R3 ;REDUCE IT BY 20% TO OBTAIN THE LOLIMIT OF THE
;+ ;PERMISSIBLE TIME DELAY.
;+ ADD R1,R5 ;INCREASE THE RXTIMER VALUE BY 20% AND ADD A
;+ ADD #2,R5 ;FURTHER 2 MS TO OBTAIN THE HILIMIT OF THE
;+ ;PERMISSIBLE TIME DELAY.
;+
;+ ; CHECK IF THE RX-INT OCCURED WITHIN THE CALCULATED PERMISSIBLE LIMITS.
;+
;+
;+ CMP R5,R4 ;COMPARE HILIM WITH ACTUAL RX-INT DELAY.
;+ BLT #1 ;REPORT THE ERROR IF THE DELAY WAS TOO LONG.
;+ CMP R3,R4 ;COMPARE LOLIM WITH ACTUAL RX-INT DELAY.
;+ BLT #60 ;AVOID ERROR IF DELAY WAS WITHIN THE LIMITS.
;+
;+ ; REPORT THE ERROR, INCORRECT DELAY ON RX-INT.
;+
;+

```



```

2690 014124 010201          2$:  MOV    R2,R1      ;PASS THE EXPECTED VALUE OF THE RX-INT DELAY.
2691 014126 010402          MOV    R4,R2      ;PASS THE ACTUAL VALUE OF THE RX-INT DELAY.
2692 014130 012703 007003  MOV    @EM5802,R3  ;PASS THE MESSAGE,
2693                                     ; "RXTIMER BAD, INCORRECT MILLI SEC DELAY ON
2694                                     ; RX-INT".
2695 014134 012767 012170 167714  MOV    @ER5901,ERRBLK ;SET UP THE ERROR REPORTING ROUTINE.
2696 014142                                     TRAP   C$ERROR
      014142 104460
2697
2698 014144 032767 000100 166036  BIT    @BIT06,OPTION ;HAS EXTENDED ERROR REPORTING BEEN REQUESTED ?
2699 014152 001003          BNE    60$        ;AVOID SETTING THE FLAG IF IT HAS.
2700 014154 012767 000001 166070  MOV    @1,EXOERR    ;SET THE "EXIT ON ERROR" FLAG.
2701 014162          60$:  PASS
      014162 004736
2702 014164 000207          RTS    PC          JSR    PC,@(SP);RETURN TO PREG05 SUBRT.
;RETURN FROM SUBROUTINE.

```

2704  
2705  
2706  
2707  
2708  
2709  
2710  
2711  
2712  
2713  
2714  
2715  
2716  
2717  
2718  
2719  
2720  
2721  
2722  
2723  
2724  
2725  
2726  
2727  
2728  
2729  
2730  
2731  
2732  
2733  
2734  
2735

014166		
014166	004567	167666
014172	005067	166102
014176	011011	
014200	005767	166074
014204	000261	
014206	001401	
014210	000241	
014212		
014212	004736	
014214	000207	

```

.SBTTL GLOBAL SUBROUTINE - CKTRAP -
;*****
;* CHECK TRAP ROUTINE -
;* THIS SUBROUTINE IS USED TO CHECK FOR A BUS TIME-OUT TRAP (004 TRAP)
;* WHICH IS CAUSED BY AN ACCESS TO A NON-EXISTENT MEMORY OR I/O LOCATION.
;* IF THE TRAP DOES NOT OCCUR, THIS ROUTINE RETURNS A SUCCESS INDICATION.
;*
;* INPUTS: R0 - SOURCE ADDRESS FOR MOVE.
;* R1 - DESTINATION ADDRESS FOR MOVE.
;* (R0) - SOURCE FOR THE MOVE.
;*
;* OUTPUTS: (R1) - WRITTEN TO THE CONTENTS OF (R0).
;* CARRY FLAG - SET ON RETURN IF NO 004 TRAP DETECTED.
;* TP4FLG - NONZERO IF TRAP OCCURRED, CLEARED OTHERWISE.
;*
;* CALLING SEQUENCE: JSR PC,CKTRAP
;*
;* COMMENTS: IF THIS SUBROUTINE CAUSES A TRAP, EITHER THE ADDRESS WHICH
;* IS LABELED ADRPTR WILL BE THE TRAP PC ADDRESS ON THE STACK.
;*
;* SUBORDINATE ROUTINES CALLED: NONE.
;*****
CKTRAP:: SAVE
                CLR TP4FLG JSR
                MOV (R0),(R1)
ADRPTR:: TST TP4FLG
                SEC
                BEQ 60$
                CLC
60$: PASS
                RTS PC JSR
;SAVE CONTENTS OF GPRS R0 THRU R5.
R5,PREG05 ;CALL REGISTER SAVE SUBRT.
;CLEAR THE 004 TRAP FLAGS.
;PERFORM THE MOVE IN QUESTION.
;CHECK FOR OCCURENCE OF TRAP.
;INDICATE SUCCESS.
;EXIT WITH SUCCESS IF TRAP DID NOT OCCUR.
;INDICATE FAILURE.
;RESTORE GPRS.
PC,8(SP) ;RETURN TO PREG05 SUBRT.

```



2737  
2738  
2739  
2740  
2741  
2742  
2743  
2744  
2745  
2746  
2747  
2748  
2749  
2750  
2751  
2752  
2753  
2754  
2755  
2756  
2757  
2758  
2759  
2760  
2761  
2762  
2763  
2764  
2765  
2766  
2767  
2768  
2769  
2770  
2771  
2772  
2773  
2774  
2775  
2776  
2777  
2778  
2779  
2780

014216  
014216 004567 167636  
  
014222 004767 002054  
014226 103002  
  
014230 004767 001134  
014234  
014234 004736  
014236 000207

```

.SBTTL GLOBAL SUBROUTINE - CLNRST -
:*****
: - CLEAN RESET OF THE DEVICE UNDER TEST -
: THIS SUBROUTINE IS USED TO RESET THE DUT TO A KNOWN STATE.
: THE DUT'S SELF-TEST IS SKIPPED, AND THE FIFO IS PURGED OF ANY ERROR
: CODES, ETC.
: IF THE RESET DOES NOT SUCCESSFULLY COMPLETE, THEN THE CARRY BIT IS
: PASSED BACK TO THE CALLING ROUTINE (CLEAR).
:
: INPUTS: CSRA - CONTAINS THE ADDRESS OF THE CSR
: TXBFCA - CONTAINS ADDRESS OF DUT DMA BUFFER COUNT REGISTER.
: ERRNBR - ERROR NUMBER FOR POSSIBLE ERROR REPORT.
: ERTTBL - ERTTYP, ERNBR, AND ERRMSG SET UP CORRECTLY.
:
: OUTPUTS: THE DUT PERFORMS ITS RESET FUNCTION INTO A KNOWN STATE.
: CARRY - CLEAR INDICATES THE TEST IS TO BE ABORTED.
: ERRBLK - VALUE MAY BE DESTROYED.
: IESTAT - TX AND RX INTERRUPT FLAGS ARE CLEARED.
: TX AND RX INTERRUPT ENABLE BITS IN THE DUT'S CSR ARE CLEARED.
:
: CALLING SEQUENCE: JSR PC, CLNRST
:
: COMMENTS: THIS SUBROUTINE CAN REPORT ERRORS WITH NUMBERS ERRNBR.
: THIS ROUTINE DOES NOT DESTROY THE VALUE OF ERRNBR.
:
: SUBORDINATE ROUTINES CALLED: DELAY, MSLGET, PUFIFO, RESETT.
:*****
CLNRST:: SAVE JSR ;SAVE CONTENTS OF GPRS R0 THRU R5.
; R5, PREG05 ;CALL REGISTER SAVE SUBRT.
:
: *
: * RESET THE DUT.
: * THIS ROUTINE REPORTS ERRORS WITH NUMBERS FROM ERRNBR THRU ERRNBR+2.
: *
: * JSR PC, RESETT ;RESET THE DUT TO A KNOWN STATE.
: * BCC 60$ ;EXIT ROUTINE WITH ABORT TEST INDICATOR.
: *
: * PURGE THE FIFO OF ERROR CODES. SAVE ANY BMP CODES FOUND.
: *
: * JSR PC, PUFIFO ;PURGE THE FIFO.
: *
60$: PASS JSR ;EXIT THE TEST USING RESETT OR PUFIFO STATUS.
;RESTORE GPRS. PASS THE FOLLOWING INTACT:
PC, @ (SP). ;RETURN TO PREG05 SUBRT.
;CARRY BIT: IF CLEAR, THEN ABORT THE TEST.
RTS PC

```

```

2782
2783
2784
2785
2786
2787
2788
2789
2790
2791
2792
2793
2794
2795
2796
2797
2798 014240
      014240 004567 167614
2799 014244 012701 000020
2800 014250 005020
2801 014252 005301
2802 014254 001375
2803 014256
      014256 004736
2804 014260 000207
    
```

```

.SBTTL GLOBAL SUBROUTINE - CLR16W -
; * *****
; * - CLEAR SIXTEEN WORDS ROUTINE -
; * THIS SUBROUTINE CLEARS 16 WORDS STARTING WITH THE SPECIFIED WORD.
; *
; * INPUTS: RO - ADDRESS OF THE FIRST WORD TO CLEAR.
; *
; * OUTPUTS: (RO) TO (RO+15) - 16 WORDS OF MEMORY ARE CLEARED TO 0.
; *
; * CALLING SEQUENCE: JSR PC,CLR16W
; *
; * COMMENTS:
; *
; * SUBORDINATE ROUTINES CALLED: NONE.
; - - *****
CLR16W:: SAVE
      JSR      ;SAVE CONTENTS OF GPRS R0 THRU R5.
      R5,PREG05 ;CALL REGISTER SAVE SUBRT.
      MOV     #16.,R1 ;SET THE LOOP COUNTER TO 16.
2$:   CLR     (R0)+ ;CLEAR A WORD OF MEMORY.
      DEC     R1 ;COUNT THIS LOOP.
      BNE    2$ ;LOOP IF NOT 16 WORD CLEARED.
60$:  PASS
      JSR      ;RESTORE GPRS.
      PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
      RTS     PC
    
```



2806  
2807  
2808  
2809  
2810  
2811  
2812  
2813  
2814  
2815  
2816  
2817  
2818  
2819  
2820  
2821  
2822  
2823  
2824 014262  
2825 014266 004567 167572  
2826 014270 012702 177777  
2827 014274 005003  
2828 014276 012704 014320  
2829 014302 004767 000536  
2830 014306 103002  
2831 014310 004767 000544  
2832 014314  
2833 014316 004736  
2834 014316 000207  
2835 014320 177777

```
.SBTTL GLOBAL SUBROUTINE - DELAY -
;*****
;* - DELAY SUBROUTINE -
;* THIS SUBROUTINE IS USED TO DELAY A VARIABLE NUMBER OF MILLI-SECONDS.
;*
;* INPUTS: R4 - CONTAINS THE NUMBER OF MS TO DELAY.
;* MSLCNT.
;*
;* OUTPUTS: NONE.
;*
;* CALLING SEQUENCE: JSR PC,DELAY
;*
;* COMMENTS: IF NO HARDWARE CLOCK INTERRUPTS ARE OCCURRING, CONTROL-CS WILL
;* NOT BE HONORED FOR THE DURATION OF THE DELAY.
;*
;* SUBORDINATE ROUTINES CALLED: NONE.
;*****
DELAY:: SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
R5,PREG05 ;CALL REGISTER SAVE SUBRT.
;PASS NUMBER OF MS DELAY AS TIME-OUT VALUE.
;TELL MSLOOP ROUTINE TO CHECK ALL BITS.
;TELL MSLOOP RTN TO CHECK FOR ALL BITS CLEAR.
;TELL MSLOOP TO CHECK DUMMY NON-ZERO WORD.
;DELAY THE REQUESTED # OF MS.
;EXIT ROUTINE IF WE TIMED-OUT.]
;IF NO TIME-OUT, BAD PROGRAM OR HOST MACHINE.
;RESTORE GPRS.
PC,@(SP)+ ;RETURN TO PREG05 SUBRT.

MOV R4,R1 JSR
MOV #1,R2
CLR R3
MOV #62$,R4
JSR PC,MSLOOP
BCC 60$
JSR PC,OOPS
60$: PASS
RTS PC JSR
62$: .WORD -1 ;DUMMY, NON-ZERO WORD.
```





2886  
2887  
2888  
2889  
2890  
2891  
2892  
2893  
2894  
2895  
2896  
2897  
2898  
2899  
2900  
2901  
2902  
2903  
2904  
2905  
2906  
2907  
2908  
2909  
2910  
2911  
2912  
2913  
2914  
2915  
2916 014400  
014400 004567 167454  
2917 014404 012704 000200  
2918  
2919  
2920  
2921  
2922  
2923  
2924  
2925  
2926  
2927  
2928 014410  
014410 104440  
014412 010005  
2929 014414  
014414 012700 000340  
014420 104441  
2930 014422 056701 165630  
2931 014426 010177 165574  
2932 014432 105777 165604  
2933 014436 000241  
2934 014440 100411  
2935 014442 010377 165576  
2936 014446 010277 165566  
2937 014452 110477 165564

```
.SBTTL GLOBAL SUBROUTINE - DODMA -
;*****
;* - INITIATE DMA TRANSMISSION ROUTINE -
;* THIS ROUTINE WRITES THE DMA PARAMETER TO THE SPECIFIED DEVICE AND
;* INITIATES THE DMA TRANSMISSION.
;*
;* INPUTS: R1 - LINE NUMBER ON WHICH TO INITIATE THE DMA.
;* R2 - START ADDRESS OF THE DMA BUFFER (16 BIT VIRTUAL).
;* R3 - CHARACTER COUNT OF THE DMA BUFFER.
;* CSRA - CONTAINS ADDRESS OF THE DUT CSR.
;* IESTAT - STORAGE FOR STATES OF THE INTERRUPT ENABLE BITS.
;* TXAD1A - CONTAINS ADDRESS OF DMA TX BUFFER ADDRESS REG #1.
;* TXAD2A - CONTAINS ADDRESS OF DMA TX BUFFER ADDRESS REG #2.
;* TXBFCA - CONTAINS ADDRESS OF DMA CHARACTER COUNT REGISTER.
;*
;* OUTPUTS: CARRY - SUCCESS FLAG (SET IF DMA_START FOUND CLEAR).
;* DUT TBUFFAD1 - LS 16 BITS OF DMA BUFFER ADDRESS (INITIALIZED).
;* DUT TBUFFAD2 - MS 6 BITS OF DMA BUFFER ADDRESS (INITIALIZED).
;* DMA_START BIT SET.
;* DUT TBUFFCT - DMA BUFFER CHARACTER COUNT (INITIALIZED).
;*
;* CALLING SEQUENCE: JSR PC,DODMA
;*
;* COMMENTS: THIS ROUTINE ASSUMES MEMORY MANAGEMENT IS DISABLED AND
;* CLEARS THE TWO MSB OF THE DMA ADDRESS, I.E. BITS 0 AND 1
;* OF THE TBUFFAD2 REG.
;*
;* SUBORDINATE ROUTINES CALLED: NONE.
;*- *****
DODMA:: SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
;CALL REGISTER SAVE SUBRT.
;PREPARE TO CLEAR UPPER 6 BITS OF DMA BUFF ADR.
        JSR      R5,PREG05
        MOV     #200,R4

;*
;* WRITE THE DMA PARAMETERS OUT TO THE DUT DMA REGISTERS.
;* DISABLE INTERRUPTS.
;* SET UP DUT CSR IND.ADR.REG FIELD.
;* WRITE THE DMA TRANSMIT CHARACTER COUNT.
;* WRITE THE LEAST SIGNIFICANT 16 BITS OF THE DMA BUFFER START ADDRESS.
;* WRITE THE MOST SIGNIFICANT 6 BITS OF THE ADDRESS.
;* SETTING THE DMA_START BIT, AND INITIATING THE DMA TRANSMISSION.
;*-
68:      GETPRI  R5          ;GET THE PRESENT PROCESSOR PRIORITY.
;TRAP C:SPRI
;MOV RO,R5
        SETPRI  #PRI07     ;DISABLE ALL HARDWARE INTERRUPTS.
;MOV #PRI07,RO
;TRAP C:SPRI
        BIS    IESTAT,R1   ;PREPARE FOR SETUP OF LINE NUMBER IN DUT CSR.
        MOV    R1,@CSRA    ;SET UP THE DUT CSR IND.ADR.REG FIELD.
        TSTB  @TXAD2A     ;TEST THE DUT DMA_START BIT.
        CLC
        BMI   60$         ;INDICATE FAILURE IN CASE DMA.MO BIT IS SET.
        MOV    R3,@TXBFCA  ;EXIT WITH FAILURE IF DMA.MO BIT IS SET.
        MOV    R2,@TXAD1A  ;WRITE THE DMA CHARACTER COUNT.
        MOVB  R4,@TXAD2A  ;WRITE THE LS 16 BITS OF BUFFER ADDRESS.
;WRITE MS 6 BITS OF ADR AND START DMA TX.
```





2944  
 2945  
 2946  
 2947  
 2948  
 2949  
 2950  
 2951  
 2952  
 2953  
 2954  
 2955  
 2956  
 2957  
 2958  
 2959  
 2960  
 2961  
 2962  
 2963 014470  
 014470 004567 167364  
 2964  
 2965  
 2966  
 2967 014474 005001  
 2968 014476 012703 000020  
 2969 014502 016700 165512  
 2970 014506 012705 000001  
 2971 014512 030500  
 2972 014514 001006  
 2973 014516 006305  
 2974 014520 005201  
 2975 014522 020103  
 2976 014524 002772  
 2977 014526 000241  
 2978 014530 000401  
 2979 014532 000261  
 2980  
 2981 014534  
 014534 010166 000004  
 014540 010566 000014  
 014544 004736  
 2982  
 2983  
 2984  
 2985 014546 000207

```

.SBTTL GLOBAL SUBROUTINE - FINACT -
;*****
;* - FIND FIRST ACTIVE LINE -
;* THIS SUBROUTINE CALCULATES THE NUMBER OF THE FIRST ACTIVE LINE THAT
;* IS FOUND IN THE ACTIVE LINE BIT MAP ACTLNS.
;*
;* INPUTS: ACTLNS - CONTAINS THE ACTIVE LINE BIT MAP.
;*
;* OUTPUTS: R1 - CONTAINS THE NUMBER OF THE FIRST ACTIVE LINE.
;*          R5 - CONTAINS THE BIT MAP REPRESENTATION OF THE ACTIVE LINE.
;*          CARRY SET INDICATES SUCCESS.
;*
;* CALLING SEQUENCE: JSR PC,FINACT
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: NONE.
;*****
FINACT:: SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
;CALL REGISTER SAVE SUBRT.
JSR R5,PREG05

;*
;* FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
;*
;*
CLR R1 ;CLEAR THE LINE NUMBER COUNTER.
MOV #NUMLNS,R3 ;GET MAX LINE NUMBER.
MOV ACTLNS,R0 ;GET THE ACTIVE LINE BIT MAP.
MOV #1,R5 ;SET UP A LINE BIT MASK.
2$: BIT R5,R0 ;LOOK FOR AN ACTIVE LINE.
BNE 4$ ;BRANCH TO BEGIN TEST IF A LINE HAS BEEN FOUND.
ASL R5 ;SHIFT THE BIT MASK FOR THE NEXT LINE.
INC R1 ;INCREMENT THE LINE NUMBER COUNTER.
CMP R1,R3 ;CHECK IF ALL LINES HAVE BEEN TRIED.
BLT 2$ ;LOOP TO TRY THE NEXT LINE.
CLC ;CLEAR CARRY BIT, NO ACTIVE LINE FOUND.
BR 60$ ;EXIT WITH FAILURE.
4$: SEC ;SET CARRY, SUCCESS.
60$: PASS R1,R5
MOV R1,R1SLOT(SP) ;PUT R1 IN STACK SLOT.
MOV R5,R5SLOT(SP) ;PUT R5 IN STACK SLOT.
JSR PC,B(SP) ;RETURN TO PREG05 SUBRT.
;R1 - CONTAINS THE NUMBER OF FIRST ACTIVE LINE.
;R5 - CONTAINS THE BIT MAP OF THE ACTIVE LINE.
;CARRY - SET INDICATES SUCCESS.

RTS PC
    
```

2987  
2988  
2989  
2990  
2991  
2992  
2993  
2994  
2995  
2996  
2997  
2998  
2999  
3000  
3001  
3002  
3003  
3004  
3005  
3006 014550  
014550 004567 167304  
3007  
3008 014554 012702 002650  
3009 014560 005003  
3010 014562 110322  
3011 014564 005203  
3012 014566 020227 003250  
3013 014572 103773  
3014  
3015 014574  
014574 004736  
3016 014576 000207

```
.SBTTL GLOBAL SUBROUTINE - INDATP -
; * *****
; * - INITIALISE DATA PATTERN -
; * THIS SUBROUTINE IS USED TO INITIALISE AN INCREMENTAL BYTE DATA PATTERN
; * IN THE GENERAL BUFFER AREA.
; * THE DATA PATTERN WILL BE SEQUENTIAL FROM 0 TO 255 (DECIMAL).
; *
; * INPUTS:      BUFBAS - ADDRESS OF THE START OF THE GENERAL BUFFER AREA,
; *              BUFMID - ADDRESS OF THE 255 TH LOCATION.
; *
; * OUTPUTS:     THE FIRST 255 LOCATIONS OF THE GENERAL BUFFER AREA CONTAIN DATA
; *
; * CALLING SEQUENCE:  JSR      PC,INDATP
; *
; * COMMENTS:
; *
; * SUBORDINATE ROUTINES CALLED: NONE.
; * - - - - -
INDATP:: SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
;CALL REGISTER SAVE SUBRT.
                JSR      R5,PREG05
                MOV     #BUFBAS,R2
                CLR     R3
;INITIALIZE THE DATA PATTERN IN THE GENERAL
; DATA BUFFER TO A 256 BYTE PATTERN.
2$:             MOVB   R3,(R2)+
                INC     R3
;SELECT THE NEXT CHARACTER.
                CMP     R2,#BUFMID
;CHECK IF WE HAVE 256 DATA PATTERNS.
                BLO    2$
;
60$:           PASS
;RESTORE GPRS.
                JSR      PC,B(SP)+
;RETURN TO PREG05 SUBRT.
                RTS     PC
```



3018  
3019  
3020  
3021  
3022  
3023  
3024  
3025  
3026  
3027  
3028  
3029  
3030  
3031  
3032  
3033  
3034  
3035  
3036  
3037  
3038  
3039 014600 004567 167254  
3040 014600 004567 167254  
3041  
3042  
3043  
3044  
3045 014604 012702 002650  
3046 014610 005003  
3047 014612 110322  
3048 014614 105203  
3049 014616 122703 000021  
3050 014622 001001  
3051 014624 105203  
3052 014626 122703 000023  
3053 014632 001001  
3054 014634 105203  
3055 014636 020227 003250  
3056 014642 103763  
3057  
3058 014644 004736  
3059 014646 000207

```
.SBTTL GLOBAL SUBROUTINE - INDTPX -
; * *****
; * - INITIALISE DATA PATTERN WITHOUT XON OR XOFF -
; * THIS SUBROUTINE IS USED TO INITIALISE AN INCREMENTAL BYTE DATA PATTERN
; * IN THE GENERAL BUFFER AREA.
; * THE DATA PATTERN WILL BE FROM 0 TO 255, BUT WILL EXCLUDE THE FOLLOWING
; * TWO CHARACTERS; (ASCII DC1, DC3) XON AND XOFF. THIS WILL CAUSE THE
; * LAST TWO DATA CHARACTERS TO BE THE SAME AS THE FIRST TWO.
; *
; * INPUTS:      BUFBAS - ADDRESS OF THE START OF THE GENERAL BUFFER AREA.
; *             BUFMID - ADDRESS OF THE 255 TH LOCATION.
; *
; * OUTPUTS:     THE FIRST 255 LOCATIONS OF THE GENERAL BUFFER AREA CONTAIN DATA
; *
; * CALLING SEQUENCE:  JSR      PC,INDTPX
; *
; * COMMENTS:
; *
; * SUBORDINATE ROUTINES CALLED: NONE.
; -- *****
INDTPX:: SAVE
; SAVE CONTENTS OF GPRS R0 THRU R5.
; CALL REGISTER SAVE SUBRT.
                JSR      R5,PREG05
; *
; * INITIALIZE THE 256 BYTE DATA PATTERN.
; * ENSURE THE DATA PATTERN IS FREE FROM XON'S OR XOFF'S TO PREVENT ERRORS.
; * NOTE: THE FIRST TWO CHARACTERS AND THE LAST TWO CHARACTERS WILL BE THE SAME.
; -
                MOV     #BUFBAS,R2      ;INITIALIZE THE DATA PATTERN IN THE GENERAL
                CLR     R3              ; DATA BUFFER TO A 256 BYTE PATTERN.
2$:             MOVB   R3,(R2)+
                INCB   R3
                CMPB  #21,R3          ;SELECT THE NEXT CHARACTER.
                BNE   4$              ;CHECK FOR AN XON CHARACTER.
                INCB  R3              ;BRANCH IF CHAR NOT AN XON.
                CMPB  #23,R3          ;FORCE THE NEXT CHARACTER.
                BNE   6$              ;CHECK FOR AN XOFF CHARACTER.
                INCB  R3              ;BRANCH IF NOT AN XOFF CHARACTER.
                CMP   R2,#BUFMID     ;FORCE THE NEXT CHARACTER.
                BLO   2$              ;CHECK IF WE HAVE 256 DATA PATTERNS.
;
6$:             PASS
; RESTORE GPRS.
                JSR      PC,@(SP)+   ;RETURN TO PREG05 SUBRT.
                RTS     PC
```

3061  
3062  
3063  
3064  
3065  
3066  
3067  
3068  
3069  
3070  
3071  
3072  
3073  
3074  
3075  
3076  
3077  
3078  
3079  
3080  
3081  
3082  
3083  
3084  
3085  
3086  
3087  
3088  
3089  
3090

014650		
014650	004567	167204
014654	042701	177760
014660	006301	
014662	016100	002336
014666		
014666	010066	000002
014672	004736	
014674	000207	

```

.SBTTL GLOBAL SUBROUTINE - LINBIT -
; * *****
; * - LINE NUMBER TO BIT MAP CONVERSION SUBROUTINE -
; * THIS SUBROUTINE IS USED TO GENERATE A BIT MAP (ONE BIT OF 16 SET)
; * BASED ON A LINE NUMBER (RANGE: 1 TO 16). ONLY THE LS 4 BITS OF THE
; * LINE NUMBER WORD ARE USED, THE OTHERS ARE MASKED OUT (SO UNMASKED
; * MSBYTES OF DUT CSRS CAN BE PASSED TO THIS ROUTINE WITHOUT ERROR).
; *
; * INPUTS: R1 - LINE NUMBER (ONLY LS 4 BITS USED, OTHERS DISREGARDED).
; * BITTBL - BASE LABEL OF A 16 WORD BIT TABLE.
; *
; * OUTPUTS: R0 - BIT MAP, BIT CORRESPONDING TO LINE NUMBER IS SET:
; * IF LINE NUMBER IS 3, THEN BIT3 IS SET, ETC.
; *
; * CALLING SEQUENCE: JSR PC,LINBIT
; *
; * COMMENTS: NO CHECKING IS PERFORMED TO VERIFY THAT THE LINE NUMBER IS
; * A LEGAL LINE NUMBER FOR THE DUT (IE - LESS THAN NUMLNS).
; * NOTE: THE LINE NUMBER IS NOT DESTROYED OR ALTERED, SO THIS
; * ROUTINE CAN BE USED EASILY IN LOOPS.
; *
; * SUBORDINATE ROUTINES CALLED: NONE.
; - - *****

LINBIT:: SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
;CALL REGISTER SAVE SUBRT.
;MASK OUT ALL BUT 4 LSBITS OF THE LINE #.
;MULTIPLY LINE # BY 2 TO GET WORD TABLE OFFSET.
;GET THE SINGLE BIT BIT MAP.
;RESTORE GPRS, EXCEPT THE FOLLOWING.
;PUT R0 IN STACK SLOT.
;RETURN TO PREG05 SUBRT.
;R0 - BIT MAP WITH LINE # BIT SET.

        JSR      R5,PREG05
        BIC      #177760,R1
        ASL      R1
        MOV      BITTBL(R1),R0
60$:    PASS     R0
        MOV      R0,ROSL0T(SP)
        JSR      PC,B(SP)
        RTS      PC
    
```



3092  
3093  
3094  
3095  
3096  
3097  
3098  
3099  
3100  
3101  
3102  
3103  
3104  
3105  
3106  
3107  
3108 014676  
014676 004567 167156  
3109 014702 010201  
3110 014704 001405  
3111  
3112 014706 005002  
3113 014710 000261  
3114  
3115 014712 005502  
3116 014714 006301  
3117 014716 001375  
3118  
3119 014720  
014720 010266 000006  
014724 004736  
3120 014726 000207

```
.SBTTL GLOBAL SUBROUTINE - MAPCNT -
; ** *****
; * - COUNT BITS IN BIT MAP ROUTINE -
; * THIS SUBROUTINE COUNTS THE NUMBER OF BITS WHICH ARE SET IN A BIT MAP.
; * INPUTS: R2 - THE BIT MAP FOR WHICH TO COUNT THE BITS.
; * OUTPUTS: R2 - COUNT OF THE NUMBER OF BITS THAT WERE SET.
; * CALLING SEQUENCE: JSR PC,MAPCNT
; * COMMENTS:
; * SUBORDINATE ROUTINES CALLED: NONE.
; -- *****

MAPCNT:: SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
R5,PREG05 ;CALL REGISTER SAVE SUBRT.
MOV R2,R1 JSR
BEQ 60$ ;EXIT WITH ZERO IF NO BITS ARE SET IN MAP.
CLR R2 ;CLEAR THE BIT COUNT.
SEC ;COUNT THE LAST BIT TO BE SHIFTED OUT.
2$: ADC R2 ;COUNT THE BIT IF IT WAS SET.
ASL R1 ;SHIFT ANOTHER BIT OUT OF THE MAP.
BNE 2$ ;LOOP IF ALL BITS NOT SHIFTED OUT OF MAP.
60$: PASS R2
MOV ;RESTORE GPRS, EXCEPT THE FOLLOWING:
JSR R2,R2SLOT(SP) ;PUT R2 IN STACK SLOT.
PC,8(SP) ;RETURN TO PREG05 SUBRT.
; R2 - COUNT OF BITS SET IN BIT MAP.
```

3122  
3123  
3124  
3125  
3126  
3127  
3128  
3129  
3130  
3131  
3132  
3133  
3134  
3135  
3136  
3137  
3138  
3139  
3140  
3141  
3142  
3143  
3144  
3145  
3146  
3147  
3148  
3149  
3150  
3151  
3152  
3153  
3154  
3155  
3156  
3157  
3158  
3159  
3160 014730 004567 167124  
3161  
3162  
3163  
3164  
3165 014734 005102  
3166 014736 040203  
3167  
3168  
3169  
3170 014740 005701  
3171 014742 001011  
3172 014744 011400  
3173 014746 010067 000070  
3174 014752 040200  
3175 014754 020003  
3176 014756 000261  
3177 014760 001420

```
.SBTTL GLOBAL SUBROUTINE - MSLGET -
*****
; - MILLI SECONDS LOOP WHICH RETURNS READ WORD AND REMAINING TIME -
; THIS SUBROUTINE IS A GENERAL PURPOSE TEST LOOP SUBROUTINE. IT IS USED
; TO VERIFY THAT A CERTAIN ACTION OCCURS BEFORE A TIME-OUT PERIOD. THE
; CALLING ROUTINE PASSES IN WHICH BITS SHOULD BE SET AND CLEARED FOR THE
; DESIRED CONDITION AND THE TIME-OUT VALUE IN MILLI-SECONDS.
; THIS ROUTINE CHECKS FOR THE DESIRED CONDITION UPON ENTRANCE INTO THE
; ROUTINE AND THEN ONCE EACH MILLI-SECOND THERE AFTER.
; UPON RETURN, THE LAST WORD WHICH WAS READ TO CHECK FOR THE CONDITION
; IS RETURNED BY THIS SUBROUTINE.
;
; INPUTS:      R1 - TIME-OUT VALUE IN MILLI-SECONDS (UP TO 64K MS).
;              R2 - BIT MAP OF BITS TO TEST (1 INDICATES TO TEST THE BIT).
;              R3 - DESIRED STATES OF THE INDICATED FIELDS IN R2.
;              R4 - ADDRESS OF THE WORD TO TEST.
;              MSLCNT - MILLI SECOND SOFTWARE LOOP COUNT.
;
; OUTPUTS:     R0 - THE LAST WORD WHICH WAS READ TO CHECK FOR THE CONDITION.
;              R1 - REMAINING NUMBER OF MS IN TIME-OUT TIME.
;              CARRY - SUCCESS FLAG (SET IF CONDITION IS MET BEFORE TIME-OUT).
;
; CALLING SEQUENCE:  JSR    PC,MSLGET
;
; COMMENTS:      THIS ROUTINE WORKS WITH OR WITHOUT A HARDWARE CLOCK, BUT THE
;                CALIBRATION IS ONLY GUARENTEED WHEN A LINE CLOCK IS AVAILABLE
;                ON THE SYSTEM.
;                THIS ROUTINE CAN BE USED AS A DELAY ROUTINE, BY SPECIFYING THE
;                DESIRED DELAY AS THE TIME-OUT AND SPECIFYING A CONDITION TO
;                LOOK FOR WHICH WILL NOT BE MET DURING THE DELAY.
;                IF A TIME-OUT VALUE OF 0 IS SPECIFIED, THIS ROUTINE CHECKS FOR
;                THE DESIRED CONDITION BEFORE RETURNING. IT INDICATES SUCCESS
;                IF THE CONDITION IS MET, FAILURE OTHERWISE.
;
; SUBORDINATE ROUTINES CALLED: NONE.
*****
MSLGET:: SAVE
;              JSR    ;SAVE CONTENTS OF GPRS R0 THRU R5.
;              R5,PREG05 ;CALL REGISTER SAVE SUBRT.
;
; SET UP MASK FOR REMOVING UNUSED BITS IN THE TEST WORD, AND CLEAR UNUSED
; BITS IN THE DESIRED STATE WORD TO ALLOW DIRECT COMPARISON.
;
;              COM    R2 ;GET MASK OF UNUSED BITS.
;              BIC    R2,R3 ;MASK OUT UNUSED BITS IN DESIRED STATE WORD.
;
; HANDLE THE TEST AND EXIT IF WE HAVE A 0 TIME-OUT VALUE.
;
;              TST    R1 ;TEST THE TIME-OUT VALUE FOR ZERO.
;              BNE    2$ ;IF NON-ZERO TIME-OUT, GO LOOP AND TEST.
;              MOV    (R4),R0 ;GET THE WORD TO TEST BEFORE EXITING.
;              MOV    R0,62$ ;SAVE VALUE SO WE CAN RETURN IT.
;              BIC    R2,R0 ;MASK OUT UNTESTED BITS OF WORD.
;              CMP    R0,R3 ;COMPARE AGAINST DESIRED STATE WORD.
;              SEC    ;INDICATE SUCCESS IN CASE WORDS ARE EQUAL.
;              BEQ    6$ ;EXIT WITH SUCCESS IF WORDS ARE EQUAL.
```



```

3178 014762 000241
3179 014764 000416
3180
3181
3182
3183 014766 016705 165334
3184 014772 011400
3185 014774 010067 000042
3186 015000 040200
3187 015002 020003
3188 015004 000261
3189 015006 001405
3190 015010 005305
3191 015012 001367
3192 015014 005301
3193 015016 001363
3194 015020 000241
3195
3196
3197
3198
3199 015022 016700 000014
3200 015026
    015026 010066 000002
    015032 010166 000004
    015036 004736
3201
3202
3203 015040 000207
3204
3205
3206
3207 015042 000000

          CLC
          BR      6$
; INDICATE FAILURE (TIME-OUT).
; EXIT WITH FAILURE, WORDS AREN'T EQUAL.
;+
; NON-ZERO TIME-OUT VALUE. LOOP, WAITING FOR CONDITION OR TIME-OUT.
;-
2$:      MOV      MSLCNT,R5      ;LOAD MS LOOP COUNT.
4$:      MOV      (R4),R0      ;GET THE WORD TO TEST.
          MOV      R0,62$      ;SAVE WORD IN CASE THIS IS THE LAST.
          BIC      R2,R0      ;MASK OUT UNTESTED BITS OF WORD.
          CMP      R0,R3      ;COMPARE AGAINST DESIRED STATE WORD.
          SEC
          BEQ      6$          ;SET CARRY IN CASE OF SUCCESS.
          DEC      R5          ;EXIT WITH SUCCESS IF WORDS ARE EQUAL.
          BNE      4$          ;COUNT DOWN THE INSIDE MS LOOP COUNT.
          DEC      R1          ;LOOP IF MS NOT UP.
          BNE      2$          ;DECREMENT THE MS TIME COUNT.
          CLC                ;IF TIME NOT UP, LOOP TO COUNT ANOTHER MS.
; CLEAR CARRY, WE TIMED-OUT.

;+
; HAVE EITHER FOUND CONDITION, OR TIMED-OUT (POSSIBLY FROM 0 TIME-OUT VALUE).
; RESTORE THE LAST CONTENTS READ FROM THE TEST WORD. EXIT ROUTINE.
;-
6$:      MOV      62$,R0      ;PASS OUT THE LAST READ WORD.
60$:     PASS      R0,R1      ;RESTORE GPRS, EXCEPT THE FOLLOWING:
          MOV      R0,R0SLOT(SP) ;PUT R0 IN STACK SLOT.
          MOV      R1,R1SLOT(SP) ;PUT R1 IN STACK SLOT.
          JSR      PC,9(SP)     ;RETURN TO PREG05 SUBRT.
; R0 - LAST READ WORD CHECKED FOR CONDITION.
; R1 - REMAINING TIME (0 IF TIME-OUT OCCURED).
; CARRY - SET IF SUCCESS, CLEAR IF TIME-OUT.

          RTS      PC

;+
; LOCAL STORAGE.
;-
62$:     .WORD   0
; STORAGE FOR THE LAST READ WORD.

```

```

3209 .SBTTL GLOBAL SUBROUTINE - MSLOOP -
3210 ;*****
3211 ;* - TEST LOOP SUBROUTINE -
3212 ;* THIS SUBROUTINE IS A GENERAL PURPOSE TEST LOOP SUBROUTINE. IT IS USED
3213 ;* TO VERIFY THAT A CERTAIN ACTION OCCURS BEFORE A TIME-OUT PERIOD. THE
3214 ;* CALLING ROUTINE PASSES IN WHICH BITS SHOULD BE SET AND CLEARED FOR THE
3215 ;* DESIRED CONDITION AND THE TIME-OUT VALUE IN MILLI-SECONDS.
3216 ;* THIS ROUTINE CHECKS FOR THE DESIRED CONDITION UPON ENTRANCE INTO THE
3217 ;* ROUTINE AND THEN ONCE EACH MILLI-SECOND THEREAFTER.
3218 ;*
3219 ;* INPUTS: R1 - TIME-OUT VALUE IN MILLI-SECONDS (UP TO 64K MS).
3220 ;* R2 - BIT MAP OF BITS TO TEST (1 INDICATES TO TEST THE BIT).
3221 ;* R3 - DESIRED STATES OF THE INDICATED FIELDS IN R2.
3222 ;* R4 - ADDRESS OF THE WORD TO TEST.
3223 ;* MSLCNT - MILLI SECOND SOFTWARE LOOP COUNT.
3224 ;*
3225 ;* OUTPUTS: CARRY - SUCCESS FLAG (SET IF CONDITION IS MET BEFORE TIME-OUT).
3226 ;*
3227 ;* CALLING SEQUENCE: JSR PC,MSLOOP
3228 ;*
3229 ;* COMMENTS: THIS ROUTINE WORKS WITH OR WITHOUT A HARDWARE CLOCK, BUT THE
3230 ;* CALIBRATION IS ONLY GUARENTEED WHEN A LINE CLOCK IS AVAILABLE
3231 ;* ON THE SYSTEM.
3232 ;* THIS ROUTINE CAN BE USED AS A DELAY ROUTINE, BY SPECIFYING THE
3233 ;* DESIRED DELAY AS THE TIME-OUT AND SPECIFYING A CONDITION TO
3234 ;* LOOK FOR WHICH WILL NOT BE MET DURING THE DELAY.
3235 ;* IF A TIME-OUT VALUE OF 0 IS SPECIFIED, THIS ROUTINE CHECKS FOR
3236 ;* THE DESIRED CONDITION BEFORE RETURNING. IT INDICATES SUCCESS
3237 ;* IF THE CONDITION IS MET, FAILURE OTHERWISE.
3238 ;*
3239 ;* SUBORDINATE ROUTINES CALLED: MSLGET.
3240 ;*****
3241
3242 015044 015044 004567 167010 MSLOOP:: SAVE JSR ;SAVE CONTENTS OF GPRS R0 THRU R5.
3243 ; R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3244
3245 ;*
3246 ;* CALLING THE MSLGET ROUTINE FROM THE MSLOOP ROUTINE ISOLATES THE CALLER OF
3247 ;* MSLOOP FROM THE RETURNED TEST WORD AND REMAINING TIME-OUT VALUES.
3248 015050 004767 177654 JSR PC,MSLGET ;CALL THE MULTI-PURPOSE MS LOOP AND SEARCH RTN.
3249
3250 015054 015054 004736 60%: PASS JSR ;RESTORE GPRS.
3251 015056 000207 RTS PC JSR PC,8(SP). ;RETURN TO PREG05 SUBRT.
;CARRY - SET IF SUCCESS, CLEAR IF TIME-OUT.

```



```

3253
3254
3255
3256
3257
3258
3259
3260
3261
3262
3263
3264
3265
3266
3267
3268
3269
3270
3271
3272 015060
      015060 004567 166774
3273
3274 015064
      015064 104454
      015066 000145
      015070 015124
      015072 000000
3275
3276 015074
      015074 012746 015210
      015100 012746 000001
      015104 010600
      015106 104417
      015110 062706 000004
3277 015114
      015114 104422
3278 015116 000776
3279 015120
      015120 004736
3280 015122 000207
3281
3282 015124 110 117 123
      015127 124 040 103
      015132 117 115 120
      015135 125 124 105
      015140 122 040 110
      015143 101 122 104
      015146 127 101 122
      015151 105 040 117
      015154 122 040 123
      015157 117 106 124
      015162 127 101 122
      015165 105 040 102
      015170 125 107 040
      015173 105 116 103
      015176 117 125 116
      015201 124 105 122
    
```

```

.SBTTL GLOBAL SUBROUTINE - OOPS -
;+ *****
;* - PROGRAM ABORT SUBROUTINE -
;* THIS SUBROUTINE IS USED TO ABORT THE PROGRAM WHEN A FATAL ERROR IS
;* DETECTED IN THE PROGRAM OR THE HOST SYSTEM HARDWARE. AN ERROR MESSAGE
;* IS PRINTED GIVING SOME INFORMATION ABOUT THE NATURE OF THE ABORT.
;*
;* INPUTS: R1 - ERROR CODE GIVING REASON FOR ABORT.
;*
;* OUTPUTS: AN ERROR MESSAGE IS PRINTED.
;* A LIST OF RETURN PC VALUES FOR ALL SUBROUTINE CALLS IS PRINTED.
;*
;* CALLING SEQUENCE: JSR PC,OOPS
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: NONE.
;-- *****

OOPS:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
      JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
; REPORT "HOST COMPUTER HARDWARE OR SOFTWARE BUG ENCOUNTERED." ERROR.
      ERRSF 101,EM0101
;
;
; REPORT "PROGRAM HUNG. WAITING FOR A CONTROL-C."
      PRINTF #EM0102
;
;
      MOV #EM0102,-(SP)
      MOV #1,-(SP)
      MOV SP,R0
      TRAP C$PNTF
      ADD #4,SP
2$: BREAK ;LOOK FOR OPERATOR CONTROL-C INPUT.
      TRAP C$BRK
60$: BR 2$ ;INFINITE LOOP.
      PASS ;DON'T NEED THIS, BUT SOMEBODY MAY CHANGE THIS
      JSR PC,8(SP) ;RETURN TO PREG05 SUBRT.
      RTS PC ; ROUTINE IN THE FUTURE, SO BE CONSISTANT.

EM0101:: .ASCIZ /HOST COMPUTER HARDWARE OR SOFTWARE BUG ENCOUNTERED./
    
```

	015204	105	104	056
	015207	000		
3283	015210	045	116	045
	015213	101	120	122
	015216	117	107	122
	015221	101	115	040
	015224	110	125	116
	015227	107	054	040
	015232	127	101	111
	015235	124	111	116
	015240	107	040	106
	015243	117	122	040
	015246	101	040	103
	015251	117	116	124
	015254	122	117	114
	015257	055	103	056
	015262	040	074	052
	015265	052	052	052
	015270	052	052	052
	015273	052	052	052
	015276	052	052	052
	015301	045	116	045
3284	015304	116	000	

EM0102:: .ASCIZ /N#APROGRAM HUNG, WAITING FOR A CONTROL-C. <\*\*\*\*\*N#N/

.EVEN



3286  
 3287  
 3288  
 3289  
 3290  
 3291  
 3292  
 3293  
 3294  
 3295  
 3296  
 3297  
 3298  
 3299  
 3300  
 3301  
 3302  
 3303  
 3304  
 3305  
 3306  
 3307  
 3308  
 3309 015306  
 3310 015312 004567 166546  
 3311 015316 016701 164710  
 3312 015322 042703 177760  
 3313 015326 056703 164724  
 3314 015332 010311  
 3315 015334 011204  
 3316  
 3317 015336  
 015336 010446  
 015340 012746 011100  
 015344 012746 005034  
 015350 012746 000003  
 015354 010600  
 015356 104415  
 015360 062706 000010  
 3318 015364  
 015364 004736  
 3319 015366 000207

```
.SBTTL GLOBAL SUBROUTINE - PRTLPR -
;*****
; -PRINT THE CONTENTS OF THE LPR.
; THIS ROUTINE IS USED TO PRINT OUT EXTENDED INFORMATION ON THE
; CONTENTS OF THE LINE PARAMETER REGISTER (LPR).
;
; INPUTS:      R3 - CONTAINS THE NUMBER OF THE LINE YOU WISH TO EXAMINE.
;              CSRA - CONTAINS THE ADDRESS OF THE DUT'S CSR.
;              IESTAT - CONTAINS THE CURRENT STATUS OF THE TX AND RX INTERRUPT
;                  ENABLE BITS IN THE DUT'S CSR.
;              LPRA - CONTAINS THE ADDRESS OF THE DUT'S LPR REGISTER.
;
; OUTPUTS:     AN EXTENDED INFORMATION MESSAGE IS PRINTED ON THE OPERATORS
;              CONSOLE.
;
; CALLING SEQUENCE:  JSR      PC,PRTLPR
;
; COMMENTS:     THIS ROUTINE CHANGES THE INDIRECT ADDRESS FIELD OF THE DEVICE
;              UNDER TEST'S CSR.
;
; SUBORDINATE ROUTINES CALLED: NONE.
;*****
```

```
PRTLPR::SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
R5,PREG05 ;CALL REGISTER SAVE SUBRT.
MOV CSRA,R1 ;GET THE CSR ADDRESS.
MOV LPRA,R2 ;GET THE LPR ADDRESS.
BIC #177760,R3 ;CLEAR ANY UNWANTED BITS.
BIS IESTAT,R3 ;SET STATE OF TX AND RX INTERRUPT ENABLE BITS.
MOV R3,(R1) ;SELECT LINE.
MOV (R2),R4 ;GET CONTENTS OF THE LPR.
;PRINT MESSAGE"CONTENTS OF THE LPR:NNNNN"
PRINTX #EF9019,#EM9026,R4;PRINT OUT MESSAGE ON OPERATORS CONSOLE.
MOV R4,-(SP)
MOV #EM9026,-(SP)
MOV #EF9019,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C:PNTX
ADD #10,SP

601: PASS ;RESTORE GPRS.
RTS PC JSR PC,#(SP). ;RETURN TO PREG05 SUBRT.
```

```

3321 .SBTTL GLOBAL SUBROUTINE - PUFIFO -
3322 ;*****
3323 ;* - PURGE THE FIFO
3324 ;* THIS ROUTINE TRIES TO REMOVE ALL THE CHARACTERS FROM THE FIFO.
3325 ;* ANY BMP CODES THAT ARE FOUND ARE SAVED ON THE BMP CODE QUEUE.
3326 ;*
3327 ;* INPUTS: RBUFA- CONTAINS THE ADDRESS OF THE RECEIVER.
3328 ;*
3329 ;*
3330 ;* OUTPUTS: CARRY BIT - INDICATES THE STATE OF THE FIFO, SET:= PURGED.
3331 ;* BMPCQ - THE CONTENTS OF THE BMP CODE QUEUE MAY BE UPDATED.
3332 ;*
3333 ;* CALLING SEQUENCE: JSR PC,PUFIFO
3334 ;*
3335 ;* COMMENTS:
3336 ;*
3337 ;* SUBORDINATE ROUTINES CALLED: SAVBMP.
3338 ;*****
3339
3340 015370 PUFIFO::SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
015370 004567 166464 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3341 015374 012701 001000 MOV #512.,R1 ;SET MAXIMUM TRY COUNT OF 512.
3342 015400 016704 164624 MOV RBUFA,R4 ;GET ADDRESS OF THE RECEIVER BUFFER REGISTER.
3343
3344 015404 011402 2$: MOV (R4),R2 ;GET THE CONTENTS OF THE RECEIVER BUFFER REG.
3345 015406 100016 BPL 6$ ;EXIT IF THE FIFO IS EMPTY, DATA_VALID CLR.
3346
3347 ;*
3348 ;* CHECK IF THE READ CHARACTER IS ACTUALLY A BMP CODE.
3349 ;* IF IT IS, THEN SAVE IT ON THE BMP CODE QUEUE TO BE REPORTED LATER.
3350 015410 012700 070000 MOV #70000,R0 ;GENERATE A BIT MAP OF CHAR ERROR BITS
3351 015414 040200 BIC R2,R0 ;WHICH ARE NOT SET FOR CHAR.
3352 015416 001006 BNE 4$ ;THROW CHAR AWAY IF NOT BMP OR SELFTEST CODE.
3353
3354 ;*
3355 ;* CHECK IF THE READ DATA IS MODEM STATUS , BMP OR SELFTEST?.
3356 015420 012700 000301 MOV #301,R0 ; CHECK IF BMP.
3357 015424 040200 BIC R2,R0 ;TRY TO CLEAR BMP FLAGS IN THE READ DATA.
3358 015426 001002 BNE 4$ ;IF IT IS MODEM OR SELFTEST CODE THROW IT AWAY.
3359 015430 004767 001044 JSR PC,SAVBMP ;SAVE BMP CODE ON THE QUEUE.
3360
3361 015434 005301 4$: DEC R1 ;DECREMENT THE TRY COUNT.
3362 015436 001362 BNE 2$ ;LOOP TO TRY AGAIN.
3363 015440 000241 CLC ;CLEAR CARRY, TO INDICATE FIFO NOT PURGED.
3364 015442 000401 BR 60$ ;EXIT WITH CARRY CLEAR.
3365 015444 000261 6$: SEC ;SET CARRY, TO INDICATE FIFO PURGED.
3366
3367 015446 60$: PASS ;RESTORE GPRS.
015446 004736 JSR PC,@(SP). ;RETURN TO PREG05 SUBRT.
3368
3369 015450 000207 RTS PC ;CARRY BIT, SET INDICATES FIFO PURGED.

```



3371  
 3372  
 3373  
 3374  
 3375  
 3376  
 3377  
 3378  
 3379  
 3380  
 3381  
 3382  
 3383  
 3384  
 3385  
 3386  
 3387  
 3388  
 3389  
 3390  
 3391  
 3392  
 3393  
 3394  
 3395  
 3396  
 3397  
 3398  
 3399 015452  
 3400 015456 004567 166402  
 3401 015462 016746 166370  
 3402 015462 012705 001000  
 3403  
 3404  
 3405  
 3406 015466 017702 164536  
 3407 015472 100063  
 3408  
 3409  
 3410  
 3411 015474 012700 070000  
 3412 015500 040200  
 3413 015502 001012  
 3414  
 3415  
 3416  
 3417  
 3418 015504 012767 012544 166344  
 3419 015512 012700 000300  
 3420 015516 040200  
 3421 015520 001003  
 3422 015522 004767 000752  
 3423 015526 000430  
 3424  
 3425  
 3426

```

.SBTTL GLOBAL SUBROUTINE - PUFIFR -
;*****
;* - PURGE FIFO REPORT ANY ERRORS FOUND.
;* THIS ROUTINE REMOVES ALL DATA FROM THE FIFO. ANY BMP CODES THAT ARE
;* FOUND ARE SAVE ON THE QUEUE TO BE REPORTED LATER IN THE BMP REPORT TEST.
;* ANY UNEXPECTED DATA (IE ANY NON-STATUS INFORMATION) THAT ARE FOUND,
;* ARE REPORTED AS AN ERROR.
;* IF THE FIFO WILL NOT PURGE AFTER 512 ATTEMPTS, THEN THE CURRENT TEST
;* THAT CALLED THIS ROUTINE RECEIVES A FAILURE FLAG THAT SHOULD BE USED
;* TO ABORT THE TEST.
;*
;* INPUTS: ERRTAB - ERRTYPE, ERRMSG, ERRNBR ARE SET UP CORRECTLY.
;* RBUFA- CONTAINS THE ADDRESS OF THE RECEIVER.
;*
;* OUTPUTS: CARRY BIT - ABORT TEST FLAG, CLR = ABORT TEST, SET = OK.
;* ERRLK - VALUE WILL BE DESTROYED.
;* BMPQOP - THE BMP CODE QUEUE POINTER MAY BE UPDATED.
;* THE CONTENTS OF THE BMP CODE QUEUE MAY BE UDATED.
;*
;* CALLING SEQUENCE: JSR PC,PUFIFR
;*
;* COMMENTS: THIS ROUTINE REPORTS ERRORS WITH NUMBERS INITIAL ERRNBR
;* THRU TO ERRNBR+2.
;* THE ERRNBR IS RESTORED TO ITS INITIAL VALUE BEFORE RETURNING.
;*
;* SUBORDINATE ROUTINES CALLED: ER1603,ER9001,ER9002,SAVBMP.
;*****
PUFIFR::SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
MOV ERRNBR,-(SP) ;SAVE THE CONTENTS OF THE ERROR NUMBER.
MOV #512,R5 ;SET MAXIMUM READ COUNTER TO 2*FIFO SIZE.
;
; READ DATA FROM THE FIFO UNTIL DATA VALID IS CLEAR OF READ COUNTER IS ZERO.
; REPORT ANY BMP OR UNEXPECTED DATA AS ERRORS.
;
2: MOV RBUFA,R2 ;GET THE CONTENTS OF THE RECEIVER BUFFER REG.
BPL B1 ;EXIT IF DATA VALID CLEAR, IE. FIFO PURGED.
;
; CHECK IF READ DATA IS STATUS OR UNEXPECTED CHARACTER.
;
MOV #70000,R0 ;GENERATE A BIT MAP OF CHAR ERROR BITS
BIC R2,R0 ; WHICH ARE NOT SET FOR CHAR.
BNE 48 ;SKIP BMP CHECK IF IT IS UNEXPECTED DATA.
;
; CHECK IF THE READ DATA IS MODEM STATUS , BMP OR SELFTEST?.
; IF IT IS A BMP CODE THEN SAVE IT ON THE QUEUE.
;
MOV #ER9001,ERRBLK ;SET UP THE CORRECT ERROR REPORTING ROUTINE.
MOV #300,R0 ; CHECK IF BMP OR SELFTEST?.
BIC R2,R0 ;TRY TO CLEAR BMP FLAGS IN THE READ DATA.
BNE 48 ;SKIP BMP ERROR REPORT IF MODEM OR SELFTEST?.
JSR PC,SAVBMP ;SAVE THE BMP CODE ON THE QUEUE.
BR 68 ;BRANCH TO CHECK READ COUNT.
;
; CHECK IF THE READ DATA IS MODEM, SELFTEST OR UNEXPECTED DATA.
;

```

```

3427 015530 032702 000001      4:  BIT    #BIT0,R2      ;TEST THE MODEM STATUS INDICATION BIT.
3428 015534 001425              BEQ    6:              ;DO NOT REPORT ANY ERROR IF MODEM STATUS.
3429 015536 012701 011124      MOV    #EM9104,R1     ;PASS THE CORRECT ERROR MESSAGE TO REPORT.
3430 015542 010203              MOV    R2,R3         ;EXTRACT THE LINE NUMBER FROM
3431 015544 000303              SWAB   R3            ; THE READ DATA.
3432 015546 042703 177760      BIC    #177760,R3    ;
3433 015552 006303              ASL    R3            ;FORM LINE NUMBER TIMES 2 FOR ER9002 ROUTINE.
3434 015554 052704 100000      BIS    #BIT15,R4     ;SET THE "NONE" EXPECTED MESSAGE FLAG.
3435 015560 005267 166266      INC    ERRNBR        ;SET ERROR NUMBER TO INTIAL ERRBR+1.
3436 015564 012767 012644 166264 MOV    #ER9002,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
3437                                ;REPORT ERROR "UNEXPECTED DATA FOUND IN FIFO".
3438 015572                                ;ERROR
                                ;          >>>>> ERROR <<<<<<.
                                ;          TRAP    C$ERROR
3439                                ;
3440                                ; EXIT WITH FAILURE IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
3441                                ;
3442 015574 032767 000100 164406  BIT    #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
3443 015602 001415              BEQ    7:              ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
3444                                ; DURING THE SOFTWARE QUESTIONS.
3445                                ;
3446 015604 005367 166242      DEC    ERRNBR        ;RESTORE ERROR NUMBER TO INTIAL ERRNBR.
3447                                ;
3448 015610 005305              6:  DEC    R5          ;DECREMENT READ COUNTER.
3449 015612 001325              BNE    2:              ;LOOP TO READ NEXT CHAR FROM FIFO IF COUNT > 0.
3450                                ;
3451                                ; THE FIFO WILL NOT CLEAR, REPORT THE ERROR AND INDICATE THAT THE TEST IS TO
3452                                ; BE ABORTED.
3453                                ;
3454 015614 062767 000002 166230  ADD    #2,ERRNBR     ;SET ERROR NUMBER TO INTIAL ERRNBR+2.
3455 015622 012767 012020 166226  MOV    #ER1603,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
3456 015630 012701 010767      MOV    #EM9017,R1     ;PASS THE MESSAGE TO BE REPORTED.
3457                                ;REPORT THE ERROR "FIFO WILL NOT PURGE, (DATA VALID STUCK SET)"
3458                                ; "?????? TEST ABORTED".
3459                                ;          >>>>> ERROR <<<<<<.
                                ;          TRAP    C$ERROR
3460 015634 015634 104460              CLC                    ;INDICATE THE TEST IS TO BE ABORTED.
3461 015636 000241              BR     10:            ;EXIT THIS ROUTINE AND ABORT THE CURRENT TEST.
3462 015640 000401              7:  SEC                    ;SET THE CARRY, DO NOT ABORT THE TEST.
3463 015642 000261              8:  SEC                    ;
3464                                ;
3465 015644 012667 166202      10: MOV    (SP)+,ERRNBR  ;RESTORE INITIAL ERROR NUMBER.
3466 015650 004736              60: PASS              ;RESTORE GPRS.
3467                                ; JSR    PC,(SP)+      ;RETURN TO PREG05 SUBRT.
3468                                ; CARRY BIT, SET INDICATES FIFO PURGED, DO NOT
3469 015652 000207      RTS    PC            ; ABORT THE TEST.
    
```



3471  
3472  
3473  
3474  
3475  
3476  
3477  
3478  
3479  
3480  
3481  
3482  
3483  
3484  
3485  
3486  
3487  
3488  
3489  
3490  
3491 015654  
015654 004567 166200  
3492 015660 005001  
3493 015662 016703 164342  
3494 015666 011302  
3495 015670 100015  
3496  
3497  
3498  
3499  
3500  
3501 015672 004767 176100  
3502 015676 103410  
3503 015700 120227 000021  
3504 015704 001003  
3505 015706 012701 006520  
3506 015712 000402  
3507 015714 005300  
3508 015716 001363  
3509 015720 000261  
3510 015722 000401  
3511 015724 000241  
3512  
3513 015726  
015726 010166 000004  
015732 004736  
3514 015734 000207

```

.SBTTL GLOBAL SUBROUTINE - READBX -
;*****
; - READ CHARACTERS FROM THE FIFO AND CHECKS FOR BMPS AND XONS-
; THIS SUBROUTINE IS USED IN THE FIHAVL.TST,
; IT READS THE SPECIFIED NUMBER OF CHARACTERS FROM THE FIFO AND CHECKS
; FOR BMP CODES AND XON CHARACTERS.
;
; INPUTS: R0 - CONTAINS THE NUMBER OF CHARS TO READ FROM THE FIFO.
;
; OUTPUTS: R1 - CONTAINS ADDRESS OF ERROR MESSAGE TO BE REPORTED
; CLEAR IF NO ERROR FOUND.
; CARRY USED TO INDICATE IF FIFO WAS FOUND EMPTY, CARRY CLEAR.
;
; CALLING SEQUENCE: JSR PC,READ
;
; COMMENTS:
;
; SUBORDINATE ROUTINES CALLED: CHKBMP.
;-- *****
READBX:: SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
;CLEAR GPR THAT HOLDS THE ADDRESS OF ERRMSG.
;GET THE ADDRESS OF THE RECEIVER BUFFER REG.
;READ A CHARACTER FROM THE FIFO.
;BRANCH IF FIFO IS EMPTY.
        CLR R1 JSR
        MOV RBUFA,R3
2$: MOV (R3),R2
        BPL 8$ ;CHECK IF THE READ CHARACTER IS A BMP CODE.
; IF IT IS A BMP CODE SAVE IT ON THE QUEUE TO BE REPORTED LATER, AND
; ABORT THE TEST.
;--
        JSR PC,CHKBMP ;CHECK IF CHARACTER IS A BMP CODE.
        BCS 6$ ;BRANCH IF A BMP CODE WAS FOUND.
        CMPB R2,#21 ;CHECK IF IT IS AN XON.
        BNE 4$ ;BRANCH IF NOT AN XON.
        MOV #EM5402,R1 ;PASS THE MESSAGE TO BE REPORTED.
        BR 6$ ;GO EXIT TEST.
4$: DEC R0 ;DECREMENT THE READ COUNT.
        BNE 2$
6$: SEC ;SET CARRY TO INDICATE SUCCESS.
        BR 60$ ;EXIT
8$: CLC ;CLEAR CARRY BIT TO INDICATE FAILURE.
60$: PASS R1 ;RESTORE GPRS.
;R1,R1SLOT(SP) ;PUT R1 IN STACK SLOT.
;PC,8(SP). ;RETURN TO PREG05 SUBRT.
        MOV JSR
        RTS PC
    
```

3516  
3517  
3518  
3519  
3520  
3521  
3522  
3523  
3524  
3525  
3526  
3527  
3528  
3529  
3530  
3531  
3532  
3533  
3534  
3535  
3536  
3537  
3538  
3539  
3540  
3541  
3542  
3543  
3544  
3545  
3546  
3547  
3548  
3549 015736  
015736 004567 166116  
3550 015742 005067 000304  
3551 015746 012705 000200  
3552 015752 000241  
3553 015754 017702 164250  
3554 015760 100132  
3555  
3556  
3557  
3558 015762 012700 170301  
3559 015766 040200  
3560 015770 001004  
3561 015772 004767 000502  
3562 015776 005305  
3563 016000 001364  
3564  
3565  
3566  
3567 016002 010205  
3568 016004 042702 177400  
3569 016010 120203  
3570 016012 001432  
3571 016014 012767 000001 000230

```
.SBTTL GLOBAL SUBROUTINE - REPDER -
; * *****
; * - REPORT DATA ERRORS -
; * THIS SUBROUTINE IS USED TO REPORT INCORRECT CHARACTERS AND LINE
; * NUMBERS IN A WORD OF DATA READ FROM THE RXFIFO. THIS ROUTINE
; * CHECKS FOR THE NUMBER OF INDIVIDUAL DATA ERRORS ON A LINE EXCEEDING
; * THE REQUESTED AMOUNT AND SETS THE APPROPRIATE ERROR SUMMARY FLAG, IT
; * THEN STOPS REPORTING ANY FURTHER ERRORS ON THAT LINE. ANY BMP CODES
; * FOUND ARE SAVED ON THE BMP CODE QUEUE TO BE REPORTED LATER AND ANOTHER
; * CHARACTER IS READ FROM THE RXFIFO.
; *
; * INPUTS: R1 - CONTAINS THE NUMBER OF THE UUT.
; * R3 - LOW BYTE CONTAINS THE EXPECTED CHAR.
; * ERCNTB - ADDRESS OF THE BASE OF THE ERROR SUMMARY TABLE.
; * ERRLK - ADDRESS OF ERROR REPORTING ROUTINE IN ERROR TABLE.
; * ERRNBR - SET TO THE ERROR NUMBER OF THE FIRST ERROR IN THIS ROUTINE.
; * EXOERR - ADDRESS OF "EXIT ON ERROR" FLAG.
; *
; * OUTPUTS: CARRY - CLEAR IF RXFIFO WAS EMPTY, SET OTHERWISE.
; * ERCNTB - CONTENTS UPDATED TO REFLECT THE CURRENT STATE.
; * ERRLK - CONTENTS MAY BE ALTERED.
; * ERSRFB - ERROR SUMMARY FLAGS UPDATED.
; * EXOERR - 1 IF AT LEAST ONE ERROR OCCURED.
; * 0 IF NO ERRORS OCCURED.
; *
; * CALLING SEQUENCE: JSR PC,REPDER
; *
; * COMMENTS: THIS ROUTINE REPORTS ERRORS WITH NUMBERS INITIAL ERRNBR
; * THRU INITIAL ERRNBR+1.
; *
; * SUBORDINATE ROUTINES CALLED: NONE
; * - - - - -
REPDER:: SAVE
; *
; * JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
; * CLR 62# ;CLEAR THE "AN ERROR OCCURED" INDICATOR.
; * MOV #128,,R5 ;SET THE MAX BMP READ COUNT.
2#: CLC ;CLEAR THE CARRY IN CASE THE FIFO IS EMPTY.
; * MOV BRBUFA,R2 ;READ THE RXFIFO.
; * BPL 61# ;EXIT THIS SUBROUTINE WITH CARRY CLEAR IF FIFO EMPTY.
; *
; * CHECK IF THE CHARACTER IS A BMP CODE.
; *
; * MOV #170301,R0 ;SET UP THE BIT MASK FOR A BMP CODE.
; * BIC R2,R0 ;TRY AND CLEAR THE BIT MASK.
; * BNE 4# ;AVOID SAVING THE CODE IF IT IS NOT A BMP CODE.
; * JSR PC,SAVBMP ;SAVE THE BMP CODE ON THE QUEUE.
; * DEC R5 ;DECREMENT THE MAX BMP READ COUNT.
; * BNE 2# ;READ ANOTHER CHARACTER FROM THE RXFIFO.
; *
; * VERIFY THAT THE READ CHARACTER IS CORRECT.
; *
; * MOV R2,R5 ;SAVE THE READ DATA.
; * BIC #177400,R2 ;CLEAR THE CLUTTER FROM THE DATA CHAR.
; * CMPB R2,R3 ;COMPARE THE READ CHAR WITH THE EXPECTED CHAR.
; * BEQ 6# ;AVOID THE ERROR REPORT IF THE DATA IS CORRECT.
; * MOV #1,62# ;INDICATE AN ERROR HAS OCCURED.
```









3637  
3638  
3639  
3640  
3641  
3642  
3643  
3644  
3645  
3646  
3647  
3648  
3649  
3650  
3651  
3652  
3653  
3654  
3655  
3656  
3657  
3658  
3659  
3660  
3661  
3662  
3663  
3664  
3665  
3666  
3667  
3668  
3669  
3670  
3671  
3672  
3673  
3674  
3675  
3676  
3677

016254  
016254 004567 165600  
016260 005767 164326  
016264 001404  
  
016266 012767 013022 165562  
  
016274  
016274 104460  
  
016276  
016276 004736  
016300 000207

```
.SBTTL GLOBAL SUBROUTINE - REPSMR -
; * *****
; * - REPORT ERROR SUMMARY ROUTINE -
; * THIS SUBROUTINE REPORTS AN ERROR SUMMARY FOR THOSE LINES WHICH HAVE
; * EXCEEDED THE NUMBER OF INDIVIDUAL ERRORS TO REPORT FOR A SINGLE LINE
; * IN A SINGLE TEST. THIS PARAMETER CAN BE SPECIFIED BY THE OPERATOR IF
; * HE/SHE ANSWERS THE SOFTWARE PARAMETER QUESTIONS.
; *
; * INPUTS: ERCNTB - LABEL AT BASE OF LINE ERROR COUNTERS TABLE.
; * ERRMSG - ADDRESS OF PRIMARY ERROR MESSAGE.
; * ERRNBR - ERROR NUMBER OF ERRORS IN THIS ROUTINE.
; * ERSMRF - "REPORT ERROR SUMMARY FOR LINE" FLAGS.
; *
; * OUTPUTS: ERRBLK - ADDRESS OF ERROR REPORTING ROUTINE (DESTROYED).
; * SUMMARY MESSAGES MAY BE PRINTED AT THE OPERATOR CONSOLE.
; *
; * CALLING SEQUENCE: JSR PC,REPSMR
; *
; * COMMENTS: IF NO LINES HAVE EXCEEDED THE MAXIMUM NUMBER OF INDIVIDUAL
; * ERRORS TO REPORT, NO MESSAGES ARE PRINTED BY THIS ROUTINE.
; * ERROR SUMMARIES IN THIS ROUTINE ARE REPORTED AS ERRORS.
; * THE CONTENTS OF ERRBLK ARE DESTROYED.
; *
; * SUBORDINATE ROUTINES CALLED:
; * - - - - -
REPSMR:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
;CALL REGISTER SAVE SUBRT.
TST ERSMRF JSR ;CHECK THE "PRINT LINE ERROR SUMMARY" FLAGS.
BEQ 60$ ;EXIT WITHOUT ACTION IF NO SUMMARY FLAGS SET.
; *
; * WE HAVE SOME ERROR SUMMARIES TO REPORT.
; * - - - - -
MOV #ER9004,ERRBLK ;SELECT ERROR REPORTING ROUTINE.
; *
; * REPORT
; * "ERROR SUMMARY REPORT FOR LINES WITH EXCESSIVE NUMBERS OF ERRORS:"
; * - - - - -
ERROR
; *
; * TRAP C$ERROR
60$: PASS ;RESTORE GPRS.
RTS PC JSR PC,0(SP). ;RETURN TO PREG05 SUBRT.
```

3679  
3680  
3681  
3682  
3683  
3684  
3685  
3686  
3687  
3688  
3689  
3690  
3691  
3692  
3693  
3694  
3695  
3696  
3697  
3698  
3699  
3700  
3701  
3702  
3703  
3704 016302  
016302 004567 165552  
3705 016306 012702 000040  
3706  
3707  
3708  
3709  
3710  
3711 016312 016704 163710  
3712 016316 030214  
3713 016320 001406  
3714 016322 005003  
3715 016324 012701 011610  
3716 016330 004767 176374  
3717 016334 103012  
3718  
3719  
3720  
3721  
3722  
3723  
3724 016336 010277 163664  
3725 016342 004767 000246  
3726  
3727  
3728  
3729  
3730  
3731 016346 005003  
3732 016350 012701 011610  
3733 016354 004767 176350  
3734 016360 103410

```
.SBTTL GLOBAL SUBROUTINE - RESETT -
;*****
;* - RESET DEVICE UNDER TEST -
;* THIS SUBROUTINE IS USED TO RESET THE DUT TO A KNOWN STATE,
;* IF RESET DOES NOT SUCCESSFULLY COMPLETE, IE. TIME-OUT OCCURS, THEN
;* AN ABORT TEST ERROR MESSAGE IS REPORTED.
;*
;* INPUTS: CSRA - CONTAINS THE ADDRESS OF THE CSR
;* TXBFCA - CONTAINS ADDRESS OF DUT DMA BUFFER COUNT REGISTER.
;* ERRCTL - ERRCTL,ERNBR,AND ERRMSG SET UP CORRECTLY.
;*
;* OUTPUTS: THE DUT PERFORMS ITS RESET FUNCTION INTO A KNOWN STATE.
;* CARRY - CLEAR INDICATES THE TEST IS TO BE ABORTED.
;* ERRBLK - VALUE MAY BE DESTROYED.
;* IESTAT - TX AND RX INTERRUPT FLAGS ARE CLEARED.
;* TX AND RX INTERRUPT ENABLE BITS IN THE DUT'S CSR ARE CLEARED.
;*
;* CALLING SEQUENCE: JSR PC,RESETT
;*
;* COMMENTS: THIS SUBROUTINE CAN REPORT ERRORS WITH NUMBERS INITIAL ERRNBR
;* THIS ROUTINE DOES NOT DESTROY THE VALUE OF ERRNBR.
;*
;* SUBORDINATE ROUTINES CALLED: DELAY,MSLGET.
;*****
RESETT:: SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
;CALL REGISTER SAVE SUBRT.
MOV #BIT05,R2 ;SET BIT MASK OF MASTER RESET BIT.
;*
;* TEST THE STATE OF THE MASTER RESET BIT IN THE CSR.
;* IF MR IS SET THEN WAIT FOR SELF-TEST TO COMPLETE.
;* IF TIME-OUT OCCURS, REPORT THE ERROR AND PASS-OUT ABORT TEST INDICATOR.
;*-
MOV CSRA,R4 ;GET THE ADDRESS OF THE DUT'S CSR.
BIT R2,(R4) ;CHECK STATE OF MASTER RESET BIT.
BEQ 2$ ;DON'T DELAY IF MR IS ALREADY CLEAR.
CLR R3 ;SET UP DESIRED STATE OF MASTER RESET BIT.
MOV #5000.,R1 ;PASS TIME-OUT VALUE OF 5 SECONDS.
JSR PC,MSLGET ;WAIT FOR SELF-TEST TO COMPLETE, MR CLEAR.
BCC 4$ ;GO REPORT ERROR IF TIMEOUT OCCURRED.
;*
;* SET MASTER RESET BIT IN CSR. CLEAR TX AND RX ENABLE BITS, ETC.
;* SKIP THE SELFTST.
;* TIME-OUT OF 5 SECS, JUST IN CASE THE SELF-TEST EXECUTES.
;*-
2$: MOV R2,BCSRA ;SET MASTER RESET BIT, DISABLE TX AND RX INTS.
JSR PC,SKPSTS ;TRY TO SKIP THE SELFTST.
;*
;* SET SELF-TEST TIME-OUT OF 5 SECONDS, AND WAIT FOR M.R TO CLEAR.
;* IF TIME-OUT OCCURS, THEN REPORT THE FATAL ERROR AND PASS-OUT THE ABORT
;* TEST INDICATOR.
;*-
CLR R3 ;SET UP DESIRED STATE OF MASTER RESET BIT.
MOV #5000.,R1 ;PASS TIME-OUT VALUE OF 5 SECONDS.
JSR PC,MSLGET ;WAIT FOR SELF-TEST TO COMPLETE, MR CLEAR.
BCS 6$ ;SKIP ERROR REPORT IF MR CLEARED IN TIME.
```



```

3735
3736
3737
3738
3739 016362 012701 005320
3740 016366 012767 012020 165462
3741
3742
3743 016374
      016374 104460
3744 016376 000241
3745 016400 000403
3746
3747
3748
3749
3750 016402 005067 163650
3751 016406 000261
3752
3753 016410
      016410 004736
3754
3755 016412 000207
3756
;+
; SET UP ERROR MESSAGE TO REPORT "FATAL ERROR FOUND DURING RESET,TEST ABORTED".
; INDICATE TEST IS TO BE ABORTED BY CLEARING THE CARRY BIT.
;-
4$:   MOV     #EM1601,R1      ;PASS ERROR MESSAGE TO REPORT.
      MOV     #ER1603,ERRBLK ;PASS ADDRESS OF ERROR HANDLING ROUTINE.
      ;REPORT ERROR "TIME-OUT OCCURRED WAITING FOR MASTER RESET TO CLEAR"
      ; "TEST ABORTED"
      ERROR
;
; >>>> ERROR <<<<<
; INDICATE TEST IS TO BE ABORTED. TRAP C$ERROR
; EXIT THIS SUBROUTINE, ABORT TEST INDICATOR.
CLC
BR    60$
;+
; CLEAR TX AND RX INTERRUPT ENABLE STATUS FLAGS IN IESTAT.
; EXIT WITH CONTINUE TEST INDICATOR SET (IE,CARRY SET).
;-
6$:   CLR     IESTAT        ;CLEAR TX AND RX INTERRUPT STATUS FLAGS.
      SEC
; INDICATE SUCCESS, CONTINUE TEST.
60$:  PASS
; RESTORE GPRS, PASS THE FOLLOWING INTACT:
; PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
; CARRY BIT:IF CLEAR,INDICATES ABORT TEST.
      JSR
      RTS     PC

```

3758  
3759  
3760  
3761  
3762  
3763  
3764  
3765  
3766  
3767  
3768  
3769  
3770  
3771  
3772  
3773  
3774  
3775  
3776 016414 010046  
3777 016416 104440  
016416 104440  
016420 010046  
3778 016422 012700 000340  
016422 104441  
016426 104441  
3779 016430 042767 137777 163620  
3780 016436 016777 163614 163562  
3781 016444 012600  
016444 104441  
3782 016450 012600  
3783 016452 000207

```
.SBTTL GLOBAL SUBROUTINE - RXIEO -
;+ *****
;* - RECEIVER INTERRUPT DISABLE -
;* THIS ROUTINE IS USED TO DISABLE RECEIVER INTERRUPTS IN THE DHU11.
;*
;* INPUTS: NONE.
;*
;* OUTPUTS: THE RX.INT.ENBL BIT IS CLEARED IN THE DUT CSR.
;* IESTST -CONTAINS THE UPDATED STATUS OF THE TX AND RX INTERRUPT
;* ENABLE BITS.
;*
;* CALLING SEQUENCE: JSR PC,RXIEO
;*
;* COMMENTS: THE CONTENTS OF THE INDIRECT ADDRESS REGISTER FIELD IN
;* THE DUT CSR ARE DESTROYED.
;*
;* SUBORDINATE ROUTINES CALLED: NONE.
;-- *****
RXIEO:: MOV RO,-(SP) ;SAVE CONTENTS OF RO ON THE STACK.
GETPRI -(SP) ;SAVE PROCESSOR PRIORITY ON STACK.
;
; TRAP C$GPRI
; MOV RO,-(SP)
3778 SETPRI #PRI07 ;IGNORE ANY INTERRUPT THAT MAY BE GENERATED.
; MOV #PRI07,RO
; TRAP C$SPRI
3779 BIC #137777,IESTAT ;CLEAR RX.INT.ENBL BIT IN IESTAT.
3780 MOV IESTAT,@CSRA ;DISABLE RX INTERRUPTS.
3781 SETPRI (SP)+ ;ENABLE INTERRUPTS TO THE PROCESSOR AGAIN.
; MOV (SP)+,RO
; TRAP C$SPRI
;
; MOV (SP)+,RO ;RESTORE RO.
RTS PC
```



3785  
3786  
3787  
3788  
3789  
3790  
3791  
3792  
3793  
3794  
3795  
3796  
3797  
3798  
3799  
3800  
3801  
3802  
3803  
3804  
3805  
3806  
3807

016454 052767 000100 163574  
016462 042767 137677 163566  
016470 016777 163562 163530  
016476 000207

```

.SBTTL GLOBAL SUBROUTINE - RXIE1 -
;+ *****
;* - RECEIVER INTERRUPT ENABLE -
;* THIS ROUTINE IS USED TO ENABLE RECEIVER INTERRUPTS IN THE DHU11.
;*
;* INPUTS: NONE.
;*
;* OUTPUTS: THE RX.INT.ENBL BIT IS SET IN THE DUT CSR.
;* IESTST -CONTAINS THE UPDATED STATUS OF THE TX AND RX INTERRUPT
;* ENABLE BITS.
;*
;* CALLING SEQUENCE: JSR PC,RXIE1
;*
;* COMMENTS: THE CONTENTS OF THE INDIRECT ADDRESS REGISTER FIELD IN
;* THE DUT CSR ARE DESTROYED.
;*
;* SUBORDINATE ROUTINES CALLED: NONE.
;-- *****
RXIE1:: BIS #BIT06,IESTAT ;SET RX.INT.ENBL BIT IN IESTAT.
        BIC #137677,IESTAT ;CLEAR ALL OTHER BITS, EXCEPT TX AND RX I.E.
        MOV IESTAT,@CSRA ;ENABLE RX INTERRUPTS.
        RTS PC

```

3809  
 3810  
 3811  
 3812  
 3813  
 3814  
 3815  
 3816  
 3817  
 3818  
 3819  
 3820  
 3821  
 3822  
 3823  
 3824  
 3825  
 3826  
 3827  
 3828  
 3829  
 3830  
 3831  
 3832  
 3833  
 3834  
 3835  
 3836  
 3837  
 3838  
 3839  
 3840  
 3841  
 3842  
 3843  
 3844

016500	004567	165354
016504	016704	163700
016510	116724	163540
016514	003204	
016516	042702	177400
016522	010224	
016524	020427	002612
016530	103402	
016532	162704	000004
016536	010467	163646
016542		
016542	004736	
016544	000207	

```

.SBTTL GLOBAL SUBROUTINE - SAVBMP -
;*****
; - SAVE BMP CODES ROUTINE -
; THIS ROUTINE SAVES THE PARAMETER PASSED IN, ONTO THE BMP CODE QUEUE
; TOGETHER WITH THE NUMBER OF THE CURRENTLY EXECUTING TEST.
;
; INPUTS:      R2 - CONTAINS THE BMP CODE THAT IS TO BE PLACED ON THE QUEUE.
;              BMPCQP - CONTAINS ADDRESS OF NEXT LOCATION IN THE BMP QUEUE.
;              BMPCQB - LABEL AT BASE OF THE BMP CODE QUEUE.
;              BMPCQE - LABEL OF NEXT LOCATION AFTER THE END OF THE BMP QUEUE.
;              TSTNUM - CONTAINS THE NUMBER OF THE CURRENT TEST.
;
; OUTPUTS:     BMPCQP - INCREMENTED BY 4.
;              THE CONTENTS OF THE BMP CODE QUEUE ARE UPDATED.
;
; CALLING SEQUENCE:  JSR      PC,SAVBMP
;
; COMMENTS:      IF THE OVERFLOW OCCURS THEN THE LAST LOCATION WILL BE
;                OVERWRITTEN BY ANY SUBSEQUENT ATTEMPTS TO UPDATE THE QUEUE.
;
; SUBORDINATE ROUTINES CALLED: NONE.
;--*****
SAVBMP:: SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
;GET THE POINTER TO THE NEXT LOCATION IN QUEUE.
;SAVE THE CURRENT TEST NUMBER ON THE QUEUE.
;INCREMENT THE POINTER TO GIVE AN EVEN ADDRESS.
;CLEAR THE UNWANTED BITS FROM THE BMP CODE.
;SAVE THE BMP CODE ON THE QUEUE.
;CHECK IF OVERFLOW WILL OCCUR THE NEXT TIME.
;GO SAVE THE POINTER IF WE WILL NOT OVERFLOW.
;RESET THE POINTER TO THE LAST LOCATION IN QUE.
;SAVE THE POINTER.
                JSR
                MOV    BMPCQP,R4
                MOV    TSTNUM,(R4)
                INC    R4
                BIC    @177400,R2
                MOV    R2,(R4)
                CMP    R4,@BMPCQE
                BLO    2:
                SUB    @4,R4
                MOV    R4,BMPCQP
2:
60:    PASS
                RTS    PC                JSR
;RESTORE GPRS.
;PC,@(SP)
;RETURN TO PREG05 SUBRT.
    
```



3846  
 3847  
 3848  
 3849  
 3850  
 3851  
 3852  
 3853  
 3854  
 3855  
 3856  
 3857  
 3858  
 3859  
 3860  
 3861  
 3862  
 3863  
 3864  
 3865  
 3866  
 3867  
 3868  
 3869  
 3870  
 3871  
 3872  
 3873  
 3874  
 3875  
 3876

016546		
016546	004567	165306
016552	004767	176072
016556	010005	
016560	012700	000206
016564	004767	000762
016570	012700	177670
016574	004767	001002
016600	012704	000012
016604	004767	175452
016610		
016610	004736	
016612	000207	

```

.SBTTL GLOBAL SUBROUTINE - SETPAR -
;*****
;* - SET TX AND CONTROL PARAMETERS -
;* THIS SURROUTINE IS USED IN THE FIMAVL.TST.
;* IT INITIALISES THE SELECTED LINE TO THE FOLLOWING STATE:
;* INTERNAL LOOPBACK, IAUTO ENABLED, LPR:38.4K, 8 BITS/CHAR, 2 STOP,
;* ODD PARITY.
;*
;* INPUTS: R1 - CONTAINS NUMBER OF THE LINE TO BE INITIALISED.
;*
;* OUTPUTS: LNCTRL AND LPR REGISTERS FOR THE SELECTED LINE ARE DESTROYED.
;*
;* CALLING SEQUENCE: JSR PC,SETPAR
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: DELAY,WTWLNC,WTWLPR.
;*****
SETPAR:: SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
JSR PC,LINBIT ;GET A BIT MAP FOR THIS LINE.
MOV R0,R5 ;COPY THE LINE BIT MAP.
MOV @206,R0 ;PASS INTERNAL LOPBCK, ENABLE RX AND IAUTO.
JSR PC,WTWLNC ;INITILAISE THE LINE CONTROL REGISTER.
MOV @177670,R0 ;PASS THE LPR CONTENTS.
JSR PC,WTWLPR ;SET THE LPR CONTENTS TO 38.4K BAUD.
MOV @10.,R4 ;PASS DELAY TIME OF 10 MILLI SECONDS.
JSR PC,DELAY ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.

608: PASS ;RESTORE GPRS.
;PC,@(SP). ;RETURN TO PREG05 SUBRT.
RTS PC JSR
    
```

3878  
 3879  
 3880  
 3881  
 3882  
 3883  
 3884  
 3885  
 3886  
 3887  
 3888  
 3889  
 3890  
 3891  
 3892  
 3893  
 3894  
 3895  
 3896  
 3897  
 3898 016614  
 016614 004567 165240  
 3899 016620 012704 000012  
 3900 016624 004767 175432  
 3901  
 3902  
 3903  
 3904 016630 012701 000060  
 3905  
 3906  
 3907 016634 012703 052525  
 3908 016640 005301  
 3909 016642 016704 163360  
 3910 016646 010124  
 3911 016650 010324  
 3912 016652 020467 163366  
 3913 016656 103774  
 3914 016660 032701 000017  
 3915 016664 001365  
 3916  
 3917 016666  
 016666 004736  
 3918 016670 000207

```

.SBTTL GLOBAL SUBROUTINE - SKPSTS -
;*****
;* - SKIP SELFTEST ROUTINE -
;* THIS SUBROUTINE IS USED TO SKIP THE SELFTEST AFTER A DUT RESET HAS BEEN
;* INITIATED. IT MUST BE ENTERED IMMEDIATELY AFTER SETTING THE DUT MASTER
;* RESET ROUTINE OR AFTER THE EXECUTION OF A BUS RESET (BECAUSE OF TIMING
;* CONSIDERATIONS).
;*
;* INPUTS: CSRA - CONTAINS ADDRESS OF THE DUT CSR.
;* TXBFCA - CONTAINS ADDRESS OF DUT DMA BUFFER COUNT REGISTER.
;*
;* OUTPUTS: SKIP SELFTEST CODES ARE WRITTEN TO THE DUT REGISTERS.
;*
;* CALLING SEQUENCE: JSR PC,SKPSTS
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: DELAY.
;-- *****
SKPSTS:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
MOV #10,R4 ;PASS DELAY VALUE OF 10 MILLI-SECONDS.
JSR PC,DELAY ;DELAY FOR 10 MILLI-SECONDS.
;
; WRITE SKIP SELF-TEST CODE (52525) TO ALL THE INDEXED DUT REGISTERS.
;
MOV #NUMLNS!BIT05,R1 ;FORM IND.ADR.REG FIELD (PLUS M.R. BIT) WORD.
;THE ABOVE INCLUSION OF THE M.R. BIT IS NECESSARY BECAUSE OF THE
; LACK OF A M.R. BIT WRITE LOCK-OUT ON THE DHU-11.
MOV #52525,R3 ;INITIALISE THE SKIP SELF-TEST CODE.
4$: DEC R1 ;SELECT THE NEXT SET OF DEVICE REGISTERS.
MOV CSRA,R4 ;GET THE ADDRESS OF THE CSR OF THE DUT.
MOV R1,(R4). ;SELECT A BANK OF DUT REGISTERS.
6$: MOV R3,(R4). ;WRITE THE CODE TO A DUT REGISTER.
CMP R4,TXBFCA ;COMPARE POINTER WITH LAST REGISTER ADDRESS.
BLO 6$ ;LOOP IF NOT ALL REGS DONE IN THIS BANK.
BIT #17,R1 ;TEST FOR IND.ADR.REG FIELD DECREMENTED TO 0.
BNE 4$ ;LOOP UNTIL ALL REGISTERS CONTAIN THE CODE.
60$: PASS ;RESTORE GPRS.
;PC,@(SP). ;RETURN TO PREG05 SUBRT.
RTS PC JSR
    
```



```

3920 .SBTTL GLOBAL SUBROUTINE - TSABRT -
3921 ;* *****
3922 ;* - TEST ABORT ROUTINE -
3923 ;* THIS SUBROUTINE IS USED WHEN A NON-TEST RELATED ERROR HAS BEEN FOUND
3924 ;* DURING THE EXECUTION OF THE CURRENT TEST.
3925 ;* IT IS USED TO INFORM THE OPERATOR THAT THE CURRENT TEST HAS BEEN
3926 ;* ABORTED.
3927 ;*
3928 ;* INPUTS: ERRMSG - CONTAINS THE NAME OF THE CURRENT TEST.
3929 ;*          ERRNBR - CONTAINS THE CORRECT ERROR NUMBER.
3930 ;*          THE REMAINDER OF THE ERTB!. IS CORRECTLY INITIALISED.
3931 ;*
3932 ;* OUTPUTS: MESSAGES ARE REPORTED TO THE OPERATOR.
3933 ;*
3934 ;* CALLING SEQUENCE: JSR PC,TSABRT
3935 ;*
3936 ;* COMMENTS:
3937 ;*
3938 ;* SUBORDINATE ROUTINES CALLED: ER1603.
3939 ;* - - - - -
3940
3941 016672 TSABRT:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
3942 016672 004567 165162 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3943 016676 012701 016714 MOV #2,R1 ;PASS ADDRESS OF FIRST MESSAGE TO BE REPORTED.
3944 016702 012767 012020 165146 MOV #ER1603,ERRBLK ;SET-UP THE ERROR REPORTING ROUTINE.
3945 016710 104460 ;
3946 016712 000432 ; >>>> ERROR <<<<. TRAP C$ERROR
3947 016714 040 116 117 28: BR 608 ;
3948 016717 116 055 122 .ASCIZ / NON-RELATED TEST ERROR FOUND DURING TEST EXECUTION/
3949 016722 105 114 101
3950 016725 124 105 104
3951 016730 040 124 105
3952 016733 123 124 040
3953 016736 105 122 122
3954 016741 117 122 040
3955 016744 106 117 125
3956 016747 116 104 040
3957 016752 104 125 122
3958 016755 111 116 107
3959 016760 040 124 105
3960 016763 123 124 040
3961 016766 105 130 105
3962 016771 103 125 124
3963 016774 111 117 116
3964 016777 000
3965
3966 .EVEN
3967 608: PASS
3968 RTS PC JSR ;RESTORE GPRS.
3969 ;RETURN TO PREG05 SUBRT.
    
```

3951  
 3952  
 3953  
 3954  
 3955  
 3956  
 3957  
 3958  
 3959  
 3960  
 3961  
 3962  
 3963  
 3964  
 3965  
 3966  
 3967  
 3968  
 3969  
 3970  
 3971 017004  
 017004 004567 165050  
 3972 017010 010003  
 3973 017012 012702 002650  
 3974 017016 004767 175356  
 3975 017022  
 017022 004736  
 3976 017024 000207

```

.SBTTL GLOBAL SUBROUTINE - TXDATP -
; * *****
; * - TRANSMIT DATA PATTERN -
; * THIS SUBROUTINE IS USED IN THE FIHAVL.TST.
; * IT TRANSMITS A SPECIFIED NUMBER OF DATA BYTES ON THE SPECIFIED LINE.
; *
; * INPUTS: R0 - CONTAINS THE NUMBER OF DATA BYTES TO TX.
; * R1 - CONTAINS LINE NUMB ON WHICH TRANSMISSION IS TO TAKE PLACE.
; * BUFBAS TO BUFMID CONTAINS A 256 BYTE DATA PATTERN.
; *
; * OUTPUTS: DATA IS SENT OUT ON THE SPECIFIED LINE.
; * CARRY SET = TX SUCCESSFUL.
; *
; * CALLING SEQUENCE: TXDATP
; *
; * COMMENTS:
; *
; * SUBORDINATE ROUTINES CALLED: DODMA.
; - - *****
TXDATP:: SAVE
        MOV R0,R3 JSR R5,PREG05 ;SAVE CONTENTS OF GPRS R0 THRU R5.
        MOV @BUFBAS,R2 ;CALL REGISTER SAVE SUBRT.
        JSR PC,DODMA ;PASS THE NUMBER OF CHARS TO TX.
;PASS THE START OF THE DATA PATTERN TO TX.
;TRANSMIT THE DATA PATTERN.
;RESTORE GPRS.
60: PASS PC, @SP) ;RETURN TO PREG05 SUBRT.
        RTS PC JSR
    
```



```

3978
3979
3980
3981
3982
3983
3984
3985
3986
3987
3988
3989
3990
3991
3992
3993
3994
3995
3996
3997
3998
3999
4000
4001 017026
      017026 004567 165026
4002 017032 010500
4003 017034 012701 000001
4004 017040 016702 163176
4005 017044 005202
4006 017046 012703 000020
4007 017052 016704 163200
4008 017056 005005
4009
4010
4011
4012 017060 010477 163142
4013 017064 105712
4014 017066 100001
4015 017070 050105
4016
4017
4018
4019
4020 017072 030100
4021 017074 001402
4022 017076 142712 000200
4023 017102 005204
4024 017104 006301
4025 017106 005303
4026 017110 001363
4027
4028 017112
      017112 010566 000014
      017116 004736
4029
4030 017120 000207
    
```

```

.SBTTL GLOBAL SUBROUTINE - TXDSBL -
; * *****
; * - TRANSMITTER DISABLE -
; * THIS SUBROUTINE IS USED TO DISABLE TRANSMISSION ON SELECTED LINES BY,
; * CLEARING THE ASSOCIATED TX.ENABLE BIT ON THE DUT.
; *
; * INPUTS: R5 - BIT'S SET CORRESPOND TO LINES ON WHICH TO CLEAR TX.ENABLE.
; * CSRA - CONTAINS THE ADDRESS OF THE DUT CSR.
; * IESTAT - CONTAINS THE STATE OF TXIE AND RXIE BITS IN THE CSR.
; * NUMLNS - EQUATED TO BE THE MAXIMUM NUMBER OF LINES AVAILABLE.
; * TXAD2A - CONTAINS THE ADDRESS OF THE TBUFAD2 REGISTER.
; *
; * OUTPUTS: R5 - BIT'S SET INDICATE THE INITIAL STATES OF ALL TX.ENABLE BITS.
; * TBUFAD2 - THE STATE OF THE TX.ENABLE BIT MAY BE ALTERED.
; * THE CONTENTS OF THE IND.ADD.REG FIELD IN THE CSR ARE DESTROYED.
; *
; * CALLING SEQUENCE: JSR PC,TXDSBL
; *
; * COMMENTS:
; *
; * SUBORDINATE ROUTINES CALLED: NONE.
; * - - - - -
TXDSBL:: SAVE
; SAVE CONTENTS OF GPRS R0 THRU R5.
R5,PREG05 ;CALL REGISTER SAVE SUBRT.
; COPY BIT MAP OF LINES TO DISABLE TRANSMISSION.
; INITIALIZE THE SELECTED LINE BIT MASK.
; GET THE ADDRESS OF THE TBUFAD2 REGISTER.
; GET THE ADDRESS OF THE MSBYTE OF TBUFAD2 REG.
; GET MAXIMUM LINE NUMBER PLUS ONE.
; GET THE STATES OF THE INT ENABLE BITS.
; LOG POSSIBLE TX DISABLED ON ALL LINES.
; *
; * SELECT EVERY LINE IN TURN, AND LOG THE STATE OF EACH TX.ENABLE BIT.
; *
; *
2$: MOV R4,BCSRA ;WRITE TO DUT CSR TO SELECT LINE REGISTERS.
TSTB (R2) ;CHECK STATE OF TX.ENABLE BIT ON SELECTED LINE.
BPL 4$ ;SKIP NEXT INSTRUCTION IF TX.ENABLE CLEAR.
BIS R1,R5 ;LOG TX ENABLE BIT SET FOR SELECTED LINE.
; *
; * CLEAR TX.ENABLE ON LINES THAT HAVE A CORRESPONDING BIT SET IN THE TX DISABLE
; * LINE BIT MAP.
; *
4$: BIT R1,R0 ;CHECK STATE OF DISABLE LINE BIT MAP.
BEQ 6$ ;BRANCH IF THIS LINE TO REMAIN UNALTERED.
BICB #BIT7,(R2) ;CLEAR TX.ENABLE BIT ON SELECTED LINE.
; PREPARE TO SELECT REGISTERS FOR NEXT LINE.
6$: INC R4 ;PREPARE TO SELECT REGISTERS FOR NEXT LINE.
ASL R1 ;SHIFT BIT MAP FOR NEXT LINE.
DEC R3 ;DECREMENT LINE NUMBER.
BNE 2$ ;LOOP TO CHECK NEXT LINE.
; *
60$: PASS R5 ;RESTORE GPRS,EXCEPT
MOV R5,R5SLOT(SP) ;PUT R5 IN STACK SLOT.
JSR PC,@(SP) ;RETURN TO PREG05 SUBRT.
; R5 - PREVIOUS STATES OF ALL TX.ENABLE BITS.
RTS PC
    
```

4032  
4033  
4034  
4035  
4036  
4037  
4038  
4039  
4040  
4041  
4042  
4043  
4044  
4045  
4046  
4047  
4048  
4049  
4050  
4051  
4052  
4053  
4054  
4055 017122  
017122 004567 164732  
4056 017126 010500  
4057 017130 012701 000001  
4058 017134 016702 163102  
4059 017140 005202  
4060 017142 012703 000020  
4061 017146 016704 163104  
4062 017152 005005  
4063  
4064  
4065  
4066 017154 010477 163046  
4067 017160 105712  
4068 017162 100401  
4069 017164 050105  
4070  
4071  
4072  
4073  
4074 017166 030100  
4075 017170 001402  
4076 017172 152712 000200  
4077 017176 005204  
4078 017200 006301  
4079 017202 005303  
4080 017204 001363  
4081  
4082 017206  
017206 010566 000014  
017212 004736  
4083  
4084  
4085 017214 000207

```

.SBTTL GLOBAL SUBROUTINE - TXENBL -
;*****
;* - TRANSMITTER ENABLE -
;* THIS SUBROUTINE IS USED TO ENABLE TRANSMISSION ON SELECTED LINES BY
;* SETTING THE ASSOCIATED TX.ENABLE BIT ON THE DUT.
;*
;* INPUTS: R5 - BIT'S SET CORRESPOND TO LINES ON WHICH TO SET TX.ENABLE.
;* CSRA - CONTAINS THE ADDRESS OF THE DUT CSR.
;* IESTAT - CONTAINS THE STATE OF TXIE AND RXIE BITS IN THE CSR.
;* NUMLNS - EQUATED TO BE THE MAXIMUM NUMBER OF LINES AVAILABLE.
;* TXAD2A - CONTAINS THE ADDRESS OF THE TBUFAD2 REGISTER.
;*
;* OUTPUTS: R5 - BIT'S SET INDICATE PREVIOUSLY DISABLED LINES.
;* TBUFAD2 - THE STATE OF THE TX.ENABLE BIT MAY BE ALTERED.
;* THE CONTENTS OF THE IND.ADD.REG FIELD IN THE CSR ARE DESTROYED.
;*
;* CALLING SEQUENCE: JSR PC,TXENBL
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: NONE.
;*****
TXENBL:: SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
R5,PREG05 ;CALL REGISTER SAVE SUBRT.
MOV R5,R0 ;COPY BIT MAP OF LINES TO ENABLE.
MOV #BIT0,R1 ;INITIALIZE THE SELECTED LINE BIT MASK.
MOV TXAD2A,R2 ;GET THE ADDRESS OF THE TBUFAD2 REGISTER.
INC R2 ;GET THE ADDRESS OF THE MSBYTE OF TBUFAD2 REG.
MOV #NUMLNS,R3 ;GET MAXIMUM LINE NUMBER.
MOV IESTAT,R4 ;GET THE STATES OF THE INT ENABLE BITS.
CLR R5 ;CLEAR TX.ENABLE BIT LOG OF DISABLED LINES.
;
; SELECT EVERY LINE IN TURN,AND LOG ANY TX.ENABLE BIT THAT IS CLEAR.
;
2$: MOV R4,BCSRA ;WRITE TO DUT CSR TO SELECT LINE REGISTERS.
TSTB (R2) ;CHECK STATE OF TX.ENABLE BIT ON SELECTED LINE.
BMI 4$ ;SKIP NEXT INSTRUCTION IF TX.ENABLE SET.
BIS R1,R5 ;LOG TX ENABLE BIT CLEAR FOR SELECTED LINE.
;
; SET TX.ENABLE ON LINES THAT HAVE A CORRESPONDING BIT SET IN THE TX ENABLE
; LINE BIT MAP.
;
4$: BIT R1,R0 ;CHECK STATE OF TX.ENABLE LINE BIT MAP.
BEQ 6$ ;BRANCH IF THIS LINE TO REMAIN UNALTERED.
BISB #BIT7,(R2) ;ENABLE TRANSMISSION ON SELECTED LINE.
6$: INC R4 ;PREPARE TO SELECT REGISTERS FOR NEXT LINE.
ASL R1 ;SHIFT BIT MAP FOR NEXT LINE.
DEC R3 ;DECREMENT LINE NUMBER.
BNE 2$ ;LOOP TO CHECK NEXT LINE.
60$: PASS R5 ;RESTORE GPRS,EXCEPT
MOV R5,R5SLOT(SP) ;PUT R5 IN STACK SLOT.
JSR PC,B(SP) ;RETURN TO PREG05 SUBRT.
;R5 - LINE BIT MAP CORRESPONDING TO THE
; PREVIOUS LINES THAT WERE DISABLED.
RTS PC

```



```

4087
4088
4089
4090
4091
4092
4093
4094
4095
4096
4097
4098
4099
4100
4101
4102
4103
4104
4105 017216 010046
4106 017220 104440
      017220 104440
      017222 010046
4107 017224
      017224 012700 000340
      017230 104441
4108 017232 042767 177677 163016
4109 017240 016777 163012 162760
4110 017246
      017246 012600
      017250 104441
4111 017252 012600
4112 017254 000207

```

```

.SBTTL GLOBAL SUBROUTINE - TXIEO -
;*****
;* - TRANSMITTER INTERRUPT DISABLE -
;* THIS ROUTINE IS USED TO DISABLE TRANSMITTER INTERRUPTS IN THE DHU11.
;*
;* INPUTS: NONE.
;*
;* OUTPUTS: THE TX.INT.ENBL BIT IS CLEARED IN THE DUT CSR.
;* IESTST -CONTAINS THE UPDATED STATUS OF THE TX AND RX INTERRUPT
;* ENABLE BITS.
;*
;* CALLING SEQUENCE: JSR PC,TXIEO
;*
;* COMMENTS: THE CONTENTS OF THE INDIRECT ADDRESS REGISTER FIELD IN
;* THE DUT CSR ARE DESTROYED.
;*
;* SUBORDINATE ROUTINES CALLED: NONE.
;*****
TXIEO:: MOV RO,-(SP) ;SAVE CONTENTS OF RO ON THE STACK.
      GETPRI -(SP) ;SAVE CURRENT PROCESSOR PRIORITY ON THE STACK.
;
; TRAP C$GPRI
      MOV RO,-(SP)
; IGNORE ANY INTERRUPTS THAT MAY BE GENERATED.
      MOV @PRI07,RO
      TRAP C$SPRI
; CLEAR TX.INT.ENBL BIT IN IESTAT.
      BIC @177677,IESTAT
; DISABLE TX INTERRUPTS.
      MOV IESTAT,BCSRA
; ENABLE INTERRUPTS TO THE PROCESSOR AGAIN.
      SETPRI (SP),
;
      MOV (SP),RO
      TRAP C$SPRI
; RESTORE RO.
      RTS PC

```

4114  
4115  
4116  
4117  
4118  
4119  
4120  
4121  
4122  
4123  
4124  
4125  
4126  
4127  
4128  
4129  
4130  
4131  
4132  
4133 017256 052767 040000 162772  
4134 017264 042767 137677 162764  
4135 017272 016777 162760 162726  
4136 017300 000207

```
.SBTTL GLOBAL SUBROUTINE - TXIE1 -  
;* *****  
;* - TRANSMITTER INTERRUPT ENABLE -  
;* THIS ROUTINE IS USED TO ENABLE TRANSMITTER INTERRUPTS IN THE DHU11.  
;* INPUTS: NONE.  
;* OUTPUTS: THE TX.INT.ENBL BIT IS SET IN THE DUT CSR,  
;* IESTST -CONTAINS THE UPDATED STATUS OF THE TX AND RX INTERRUPT  
;* ENABLE BITS.  
;* CALLING SEQUENCE: JSR PC,TXIE1  
;* COMMENTS: THE CONTENTS OF THE INDIRECT ADDRESS REGISTER FIELD IN  
;* THE DUT CSR ARE DESTROYED.  
;* SUBORDINATE ROUTINES CALLED: NONE.  
;* - *****  
TXIE1:: BIS @BIT14,IESTAT ;SET TX.INT.ENBL BIT IN IESTAT.  
BIC @137677,IESTAT ;CLEAR ALL BITS EXCEPT TX RX I.E BITS.  
MOV IESTAT,@CSRA ;ENABLE TX INTERRUPTS.  
RTS PC
```



4138  
4139  
4140  
4141  
4142  
4143  
4144  
4145  
4146  
4147  
4148  
4149  
4150  
4151  
4152  
4153  
4154  
4155  
4156  
4157  
4158  
4159  
4160  
4161 017302  
017302 004567 164552  
4162  
4163  
4164  
4165 017306 010204  
4166 017310 160104  
4167 017312 103403  
4168 017314 012701 177777  
4169 017320 000442  
4170  
4171  
4172  
4173 017322 005004  
4174 017324 000241  
4175 017326 006001  
4176 017330 006004  
4177 017332 012700 000020  
4178  
4179  
4180  
4181 017336 010246  
4182 017340 010346  
4183 017342 160403  
4184 017344 005602  
4185 017346 103402  
4186 017350 160102  
4187 017352 103003  
4188  
4189  
4190  
4191  
4192 017354 012603  
4193 017356 012602

```
.SBTTL GLOBAL SUBROUTINE - UNSDIV -
;+ *****
;+ - UNSIGNED DIVIDE ROUTINE -
;+ THIS SUBROUTINE IS USED TO DIVIDE A 32 BIT UNSIGNED DIVIDEND BY A
;+ 16 BIT UNSIGNED DIVISOR GIVING A 16 BIT QUOTIENT. ALL NUMBERS ARE
;+ CONSIDERED TO BE UNSIGNED. A SUCCESS FLAG IS NOT SET ON RETURN IF
;+ THE QUOTIENT WAS TOO BIG TO BE CONTAINED IN 16 BITS.
;+
;+ INPUTS: R1 - THE DIVISOR, UNSIGNED, 16 BITS.
;+ R2 - MOST SIGNIFICANT WORD OF THE DIVIDEND, UNSIGNED, 16 BITS.
;+ R3 - LEAST SIGNIFICANT WORD OF THE DIVIDEND, UNSIGNED, 16 BITS.
;+
;+ OUTPUTS: R1 - QUOTIENT, UNSIGNED, 16 BITS (177777 IF OVERFLOW).
;+ CARRY - SUCCESS FLAG, SET IF COMPLETE QUOTIENT FITS IN 16 BITS.
;+
;+ CALLING SEQUENCE: JSR PC,UNSDIV
;+
;+ COMMENTS: IF THE DIVISOR IS 0 THE QUOTIENT IS RETURNED AS ALL ONES
;+ (177777) AND THE CARRY IS CLEAR REGARDLESS OF THE DIVIDEND.
;+
;+ SUBORDINATE ROUTINES CALLED: NONE.
;+
;+ *****
UNSDIV:: SAVE JSR ;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
;+
;+ CHECK FOR QUOTIENT GREATER THAN 16 BITS CONDITION.
;+
;+ MOV R2,R4 ;GET MSW OF DIVIDEND FOR SUBTRACT.
;+ SUB R1,R4 ;SUBTRACT DIVISOR FROM MSW OF DIVIDEND.
;+ BCS 2$ ;IF IT DIDN'T GO, WE HAVE QUOTIENT < 16 BITS.
;+ MOV @-1,R1 ;SET QUOTIENT TO ALL ONES (177777).
;+ BR 60$ ;EXIT WITH CARRY CLEAR.
;+
;+ SET UP COUNTERS AND VARIOUS WORKING GPRS.
;+
;+ 2$: CLR R4 ;CLEAR THE LSW OF THE DIVISOR.
;+ CLC ;CLEAR CARRY FOR THE SHIFT OF THE DIVISOR.
;+ ROR R1 ;DIVISOR BY
;+ ROR R4 ;2(UNSIGNED)
;+ MOV @16.,R0 ;SET UP INITIAL SHIFT COUNT TO 16.
;+
;+ THE SUBTRACT AND SHIFT LOOP.
;+
;+ 4$: MOV R2,-(SP) ;SAVE MSWORD OF DIVIDEND.
;+ MOV R3,-(SP) ;SAVE LSWORD OF DIVIDEND.
;+ SUB R4,R3 ;LSWORD DIVIDEND - LSWORD OF DIVISOR.
;+ SBC R2 ;MSWORD DIVIDEND - BORROW
;+ BCS 6$ ;IF BORROW FROM BORROW SUBTRACT, IT DIDN'T GO.
;+ SUB R1,R2 ;MSWORD DIVIDEND - MSWORD OF DIVISOR.
;+ BCC 8$ ;IF NO BORROW, IT WENT, CARRY IS CLEAR.
;+
;+ IT DIDN'T GO, SO WE SHIFT A 1 INTO THE QUOTIENT (COMPLEMENTED LATER).
;+ CARRY IS SET.
;+
;+ 6$: MOV (SP)+,R3 ;RESTORE LSWORD OF DIVIDEND.
;+ MOV (SP)+,R2 ;RESTORE MSWORD OF DIVIDEND.
```

```

4194 017360 000401          BR      10$          ;GOTO SHIFT 1 INTO THE QUOTIENT.
4195                          ;*
4196                          ; IT WENT, SO WE RESTORE THE STACK AND SHIFT A 0 INTO QUOTIENT (WILL BE
4197                          ; COMPLEMENTED LATER).  CARRY IS CLEAR.
4198                          ;-
4199 017362 012626      8$:  MOV      (SP)+,(SP)+      ;POP THE SAVED DIVIDEND OFF OF THE STACK.
4200                          ;*
4201                          ; SHIFT THE RESULT OF THE SUBTRACT ATTEMPT INTO THE QUOTIENT SHIFT REG.
4202                          ;-
4203 017364 006105      10$:  ROL      R5          ;SHIFT NEXT BIT INTO THE INVERTED QUOTIENT.
4204 017366 000241          CLC          ;DIVIDE THE
4205 017370 006001          ROR      R1          ; DEVISOR BY
4206 017372 006004          ROR      R4          ; 2 (UNSIGNED).
4207 017374 005300          DEC      R0          ;COUNT THIS SHIFT AND SUBTRACT.
4208 017376 001357          BNE     4$          ;LOOP FOR ANOTHER SHIFT & SUB IF NOT DONE.
4209 017400 005105          COM      R5          ;GET QUOTIENT FROM INVERTED QUOTIENT.
4210                          ;*
4211                          ; NOW WE EITHER ROUND UP OR LEAVE QUOTIENT ALONE.
4212                          ;-
4213 017402 000241          CLC          ;CLEAR THE CARRY FOR THE SHIFT OF THE DIVIDEND.
4214 017404 006103          ROL      R3          ;MULTIPLY LSWORD OF DIVIDEND BY 2, MSWORD IS 0.
4215 017406 103402          BCS     12$          ;IF CARRY FROM SHIFT, ROUND UP.
4216 017410 160403          SUB     R4,R3          ;SUBTRACT DIVISOR FROM DIVIDEND.
4217 017412 103403          BCS     14$          ;IF BORROW, DON'T ROUND UP.
4218                          ;*
4219                          ; ROUND UP, EXTRA SUBTRACT WENT.
4220                          ;-
4221 017414 005205      12$:  INC      R5          ;INCREMENT THE QUOTIENT BY ONE.
4222 017416 001001          BNE     14$          ;IF NO OVERFLOW, WE LEAVE THE ROUND UP.
4223 017420 005305          DEC      R5          ;DON'T LET ROUNDING CAUSE OVERFLOW.
4224                          ;*
4225                          ; ALL DONE, PASS QUOTIENT AND EXIT.
4226                          ;-
4227 017422 010501      14$:  MOV      R5,R1          ;PASS QUOTIENT BACK IN R1.
4228 017424 000261          SEC          ;INDICATE NO OVERFLOW.
4229                          ;-
4230 017426 010166 000004 60$:  PASS     R1          ;RESTORE GPRS. LEAVE THE FOLLOWING INTACT:
                                MOV     R1,R1SLOT(SP) ;PUT R1 IN STACK SLOT.
                                JSR     PC,@(SP)+   ;RETURN TO PREG05 SUBRT.
4231                          ;R1 - 16 BIT, UNSIGNED QUOTIENT.
4232 017434 000207          RTS     PC          ;CARRY - SET INDICATES NO OVERFLOW (SUCCESS).

```



4234  
4235  
4236  
4237  
4238  
4239  
4240  
4241  
4242  
4243  
4244  
4245  
4246  
4247  
4248  
4249  
4250  
4251  
4252  
4253  
4254  
4255  
4256  
4257  
4258  
4259  
4260  
4261  
4262 017436  
017436 004567 164416  
4263 017442 010204  
4264 017444 010102  
4265 017446 042701 170000  
4266 017452 042702 007777  
4267 017456 000302  
4268 017460 006202  
4269 017462 006202  
4270 017464 006202  
4271 017466 016202 002336  
4272 017472 010203  
4273 017474 004767 175230  
4274  
4275 017500 010002  
4276 017502  
017502 010266 000006  
017506 004736  
4277  
4278 017510 000207

```
.SBTTL GLOBAL SUBROUTINE - WAIBIS -
;+ *****
;* - WAIT FOR BIT SET ROUTINE -
;* THIS SUBROUTINE WAITS FOR THE SPECIFIED BIT TO BECOME SET. IF THE
;* SPECIFIED BIT GOES TO A SET STATE WITHIN THE SPECIFIED TIME-OUT
;* PERIOD A SUCCESS INDICATION IS RETURNED BY THIS ROUTINE.
;* THE LAST VALUE WHICH IS READ LOOKING FOR THE CONDITION IS RETURNED TO
;* ALLOW THE USE OF THIS ROUTINE TO LOOK FOR DESTRUCTIVE READ CONDITIONS.
;*
;* INPUTS: R1 - TIME-OUT VALUE AND BIT NUMBER INDICATION:
;* BITS 15 THRU 12 - NUMBER OF BIT TO TEST (RANGE 0 THRU 15).
;* BITS 11 THRU 0 - TIME-OUT VALUE IN MILLI-SECONDS (4095 MAX).
;* R2 - ADDRESS OF WORD CONTAINING THE BIT TO TEST.
;* MSLCNT.
;*
;* OUTPUTS: R2 - THE LAST WORD WHICH WAS READ TO CHECK FOR THE CONDITION.
;* CARRY - SUCCESS FLAG (CARRY SET IF BIT SET BEFORE TIME-OUT).
;*
;* CALLING SEQUENCE: MOV #130040,R1 ;PASS BIT 11 (13 OCTAL) AND
;* ; 32 (40 OCTAL) MS DELAY.
;* MOV #LABEL,R2 ;TEST BIT IN WORD AT "LABEL".
;* JSR PC,WAIBIS ;WAIT 32 MS FOR BIT 11 TO SET.
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: MSLGET.
;-- *****
WAIBIS:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
;SET UP THE ADDRESS PARAMETER FOR MSLGET.
MOV R2,R4 JSR
MOV R1,R2
BIC #170000,R1 ;SEPERATE DELAY COUNT OUT OF PASSED PARAMETER.
BIC #7777,R2 ;SEPERATE LINE NUMBER FIELD OF PASSED PARAM.
SWAB R2 ;PUT LINE NUMBER FIELD IN LSBYTE.
ASR R2 ;SHIFT THE LINE NUMBER FIELD INTO THE PROPER
ASR R2 ; POSITION TO USE IT AS A WORD TABLE OFFSET
ASR R2 ; FOR THE TABLE LOOKUP OF THE LINE BIT MAP.
MOV BITTBL(R2),R2 ;GET BIT MAP OF LINE TO TEST FROM TABLE.
MOV R2,R3 ;INDICATE THAT THE BIT SHOULD BE SET.
JSR PC,MSLGET ;WAIT FOR THE BIT TO BE SET WITHIN TIME-OUT.
; CARRY IS CORRECT UPON MSLGET RETURN.
;PASS LAST VALUE READ AS OUTPUT PARAMETER.
;RESTORE GPRS, EXCEPT THE FOLLOWING:
MOV R2,R2SLOT(SP) ;PUT R2 IN STACK SLOT.
JSR PC,@(SP) ;RETURN TO PREG05 SUBRT.
; R2 - LAST VALUE READ LOOKING FOR CONDITION.
; CARRY - SUCCESS FLAG (SET IF BIT FOUND SET).
```

4280  
4281  
4282  
4283  
4284  
4285  
4286  
4287  
4288  
4289  
4290  
4291  
4292  
4293  
4294  
4295  
4296  
4297  
4298  
4299 017512  
4300 017512 004567 164342  
4301 017516 012701 170536  
4302 017522 016702 162500  
4303 017526 004767 177704  
4304 017532 103005  
4304 017534 012704 000005  
4305 017540 004767 174516  
4306 017544 000261  
4307  
4308 017546  
017546 004736  
4309  
4310 017550 000207

```
.SBTTL GLOBAL SUBROUTINE - WAITTX -
;+* *****
;* - WAIT FOR TX TO FINISH -
;* THIS SUBROUTINE IS USED IN THE FIHAWL.TST.
;* IT WAITS FOR TRANSMISSION TO COMPLETE IE TX_ACTION. THEN DELAYS
;* FOR 5 MILLISECONDS TO ALLOW TIME FOR THE LAST CHARACTER TO GET INTO
;* THE FIFO.
;*
;* INPUTS: CSRA - CONTAINS THE ADDRESS OF THE CSR.
;*
;* OUTPUTS: CARRY - SET INDICATES SUCCESS.
;*
;* CALLING SEQUENCE: JSR PC,WAITTX
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: DELAY,WAIBIS.
;-- *****

WAITTX:: SAVE JSR ;SAVE CONTENTS OF GPRS R0 THRU R5.
MOV #170536,R1 R5,PREG05 ;CALL REGISTER SAVE SUBRT.
MOV CSRA,R2 ;PASS TIME-OUT VALUE OF 350 MILLI SECS.
JSR PC,WAIBIS ;PASS THE ADDRESS OF THE CSR.
BCC 60$ ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
MOV #5,R4 ;BRANCH IF NO TX_ACTION, ABORT THE TEST.
JSR PC,DELAY ;PASS DELAY OF 5 MILLI SECS.
SEC ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
;SET CARRY TO INDICATE SUCCESS.

60$: PASS JSR ;RESTORE GPRS.
PC,8(SP)+ ;RETURN TO PREG05 SUBRT.
RTS PC ;PASS THE CARRY BIT. SET INDICATES SUCCESS.
```



4312  
 4313  
 4314  
 4315  
 4316  
 4317  
 4318  
 4319  
 4320  
 4321  
 4322  
 4323  
 4324  
 4325  
 4326  
 4327  
 4328  
 4329  
 4330  
 4331  
 4332  
 4333  
 4334  
 4335 017552  
 017552 004567 164302  
 4336  
 4337  
 4338  
 4339 017556 016701 162454  
 4340 017562 010002  
 4341 017564 010503  
 4342 017566 012704 177777  
 4343  
 4344  
 4345  
 4346 017572 004767 173572  
 4347  
 4348 017576  
 017576 004736  
 4349 017600 000207

```

.SBTTL GLOBAL SUBROUTINE - WTWLNC -
;*****
; - LINE CONTROL REGISTER SETUP ROUTINE -
; THIS SUBROUTINE IS USED TO SET THE DEVICE UNDER TEST (DUT) LINE
; CONTROL REGISTERS (LNCTRL) TO THE SPECIFIED STATE. ONLY THE LNCTRLS
; FOR THE SPECIFIED LINES ARE ALTERED.
;
; INPUTS:  R0 - NEW LINE PARAMETERS.
;          R5 - BIT MAP OF LINES TO BE ALTERED.
;          CSRA - CONTAINS ADDRESS OF THE DUT CSR.
;          IESTAT - CONTAINS THE CURRENT STATE OF THE TX AND RX INTERRUPT
;          ENABLE BITS IN THE CSR.
;          LNCTRA - CONTAINS ADDRESS OF THE DUT LNCTRL REGISTERS.
;
; OUTPUTS: LNCTRL - SPECIFIED DUT LINE CONTROL REGISTERS ARE ALTERED.
;
; CALLING SEQUENCE: JSR PC,WTWLNC
;
; COMMENTS:
;
; SUBORDINATE ROUTINES CALLED: ALTFLD.
;-----
WTWLNC:: SAVE JSR R5,PREG05 ;SAVE CONTENTS OF GPRS R0 THRU R5.
; ;CALL REGISTER SAVE SUBRT.
;
; SET UP THE PARAMETERS FOR THE CALL TO ALTFLD.
;-----
MOV LNCTRA,R1 ;SET UP THE REGISTER ADDRESS PARAMETER.
MOV R0,R2 ;SET UP THE DESIRED REGISTER CONTENTS.
MOV R5,R3 ;SET UP THE BIT MAP OF LINES TO ALTER.
MOV @-1,R4 ;SELECT ALL REGISTER BITS TO BE ALTERED.
;
; CALL THE SUBROUTINE WHICH ALTERS THE REGISTER CONTENTS.
;-----
JSR PC,ALTFLD ;ALTER THE REGISTER CONTENTS.
;
600: PASS ;RESTORE GPRS.
RTS PC JSR PC,@(SP). ;RETURN TO PREG05 SUBRT.
    
```

4351  
 4352  
 4353  
 4354  
 4355  
 4356  
 4357  
 4358  
 4359  
 4360  
 4361  
 4362  
 4363  
 4364  
 4365  
 4366  
 4367  
 4368  
 4369  
 4370  
 4371  
 4372  
 4373  
 4374 017602  
 017602 004567 164252  
 4375  
 4376  
 4377  
 4378 017606 016701 162420  
 4379 017612 010002  
 4380 017614 010503  
 4381 017616 012704 177777  
 4382  
 4383  
 4384  
 4385 017622 004767 173542  
 4386  
 4387 017626  
 017626 004736  
 4388 017630 000207

```

.SBTTL GLOBAL SUBROUTINE - WTWLPR -
;*****
;* - LINE PARAMETER REGISTER SETUP ROUTINE -
;* THIS SUBROUTINE IS USED TO SET THE DEVICE UNDER TEST (DUT) LINE
;* PARAMETER REGISTERS (LPR) TO THE SPECIFIED STATE. ONLY THE LPRS FOR
;* THE SPECIFIED LINES ARE ALTERED.
;*
;* INPUTS: R0 - NEW LINE PARAMETERS.
;* R5 - BIT MAP OF LINES TO BE ALTERED.
;* CSRA - CONTAINS ADDRESS OF THE DUT CSR.
;* IESTAT - CONTAINS THE CURRENT STATE OF THE TX AND RX INTERRUPT
;* ENABLE BITS IN THE CSR.
;* LPRA - CONTAINS ADDRESS OF THE DUT LPR.
;*
;* OUTPUTS: LPR - SPECIFIED DUT LINE PARAMTER REGISTERS ARE ALTERED.
;*
;* CALLING SEQUENCE: JSR PC,WTWLPR
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: ALTFLD.
;*****
WTWLPR:: SAVE JSR R5,PREG05 ;SAVE CONTENTS OF GPRS R0 THRU R5.
; ;CALL REGISTER SAVE SUBRT.
; SET UP THE PARAMETERS FOR THE CALL TO ALTFLD.
; -
MOV LPRA,R1 ;SET UP THE REGISTER ADDRESS PARAMETER.
MOV R0,R2 ;SET UP THE DESIRED REGISTER CONTENTS.
MOV R5,R3 ;SET UP THE BIT MAP OF LINES TO ALTER.
MOV #-1,R4 ;SELECT ALL REGISTER BITS TO BE ALTERED.
;
; CALL THE SUBROUTINE WHICH ALTERS THE REGISTER CONTENTS.
; -
JSR PC,ALTFLD ;ALTER THE REGISTER CONTENTS.
600: PASS ;RESTORE GPRS.
RTS PC JSR PC,B(SP) ;RETURN TO PREG05 SUBRT.
    
```



4390  
 4391  
 4392  
 4393  
 4394  
 4395  
 4396  
 4397  
 4398  
 4399  
 4400  
 4401  
 4402  
 4403  
 4404  
 4405  
 4406  
 4407  
 4408  
 4409  
 4410  
 4411  
 4412  
 4413 017632 005767 162456  
 4414 017636 001402  
 4415 017640 005367 162450  
 4416 017644 005767 162446  
 4417 017650 001402  
 4418 017652 005367 162440  
 4419 017656 005367 162436  
 4420 017662 001006  
 4421 017664 016767 162432 162426  
 4422 017672 010046  
 4423 017674  
 017674 104422  
 4424 017676 012600  
 4425 017700 000002

```
.SBTTL INTERRUPT SERVICE ROUTINE - CLKINT -
;*****
; THIS ROUTINE IS EXECUTED CLKHRZ TIMES PER SECOND. IT DECREASES THE
; TWO TIMER COUNTERS DOWN TO ZERO.
;
; INPUTS:    TIMER1 - TIMER COUNTER #1.
;            TIMER2 - TIMER COUNTER #2.
;            TIMER3 - TIMER COUNTER FOR CALL OF BREAK MACRO.
;
; OUTPUTS:   THE 2 TIMER COUNTERS ARE DECREMENTED IF THEY ARE NOT ZERO.
;
; CALLING SEQUENCE:  PUT #CLKINT IN THE CLOCK INTERRUPT VECTOR SLOT.
;                    PUT THE DESIRED TIME PERIOD (SECONDS TIMES CLKHRZ) IN
;                    EITHER TIMER1 OR TIMER2 AND POLL THE RESPECTIVE TIMER
;                    COUNTER TO DETECT ITS GOING TO 0 ON TIME-OUT.
;
; COMMENTS:  THE 2 COUNTERS WILL NOT WRAPAROUND BUT WILL STOP AT 0. THIS
;            ALLOWS THE DETECTION OF A TIME-OUT ANY TIME AFTER THE TIME-OUT
;            HAS OCCURRED UNTIL THE TIMER COUNTER IS SET TO ANOTHER VALUE.
;
; SUBORDINATE ROUTINES CALLED: NONE.
;-----
CLKINT:: TST    TIMER1      ;CHECK FOR TIMER1 AT ZERO.
        BEQ    2$          ;BRANCH TO LEAVE IT AT ZERO IF IT IS ZERO.
        DEC    TIMER1      ;DECREMENT TIME COUNT.
2$:     TST    TIMER2      ;CHECK FOR TIMER2 AT ZERO.
        BEQ    4$          ;BRANCH TO LEAVE IT ALONE IF IT'S ALREADY ZERO.
        DEC    TIMER2      ;DECREMENT TIME COUNT.
4$:     DEC    TIMER3      ;DECREMENT THE BREAK COUNT.
        BNE    60$         ;EXIT IF NOT TIME TO CALL BREAK.
        MOV    BCOUNT,TIMER3 ;SET UP TIME TILL NEXT BREAK.
        MOV    RO,-(SP)     ;SAVE CONTENTS OF RO FROM BREAK MACRO.
        BREAK              ;CHECK FOR OPERATOR CONTROL/C.
                                TRAP    C$BRK
60$:   MOV    (SP),RO      ;RESTORE CONTENTS OF RO.
        RTI
```

4427  
4428  
4429  
4430  
4431  
4432  
4433  
4434  
4435  
4436  
4437  
4438  
4439  
4440  
4441  
4442  
4443  
4444  
4445 017702 012767 000001 162356  
4446 017710 000002

```
.SBTTL INTERRUPT SERVICE ROUTINE - RXDECT -  
; * *****  
; * - RX INT DECTION ROUTINE -  
; * THIS ROUTINE DETECTS AN RX INTERRUPT BY SETTING THE RXINTC WORD TO 1.  
; * THIS ROUTINE IS USED IN THE RXTIMER TESTS.  
; *  
; * INPUTS: RXINTC - STORGE FOR THE INTERRUPT COUNT.  
; *  
; * OUTPUTS: RXINTC - SET TO 1.  
; *  
; * CALLING SEQUENCE: PUT THE ADDRESS OF THE LABEL RXDECT IN THE VECTOR  
; * LOCATION.  
; *  
; * COMMENTS: THIS ROUTINE DOES NOT READ THE RXFIFO.  
; *  
; * SUBORDINATE ROUTINES CALLED: NONE.  
; -- *****  
RXDECT:: MOV #1,RXINTC ;INDICATE THAT AN RX-INT HAS OCCURED.  
RTI
```



```

4448 .SBTTL GLOBAL TRAP SERVICE ROUTINE - TP4RTN -
4449 ;*****
4450 ;* BUS TIME-OUT TRAP (004 TRAP) SERVICE ROUTINE -
4451 ;* THIS ROUTINE DETERMINES IF THE 004 TRAP WAS CAUSED BY
4452 ;* AN "EXPECTED" ERROR OR NOT BY EXAMINING THE RETURN PC VALUE ON THE
4453 ;* STACK. IF THE TRAP IS UNEXPECTED, THIS ROUTINE JUMPS TO THE NORMAL
4454 ;* DIAGNOSTIC SUPERVISOR 004 TRAP HANDLING ROUTINE.
4455 ;*
4456 ;*
4457 ;* INPUTS: SP - POINTS TO THE PC WHERE THE TRAP OCCURED.
4458 ;* ADRPTR - LABEL AT THE ADDRESS WHERE "EXPECTED" TRAPS OCCUR.
4459 ;* TP4FLG - 004 TRAP FLAGS.
4460 ;*
4461 ;* OUTPUTS: TP4FLG - BIT 15 IS SET IF "EXPECTED" TRAP OCCURED.
4462 ;*
4463 ;* CALLING SEQUENCE: PUT ADDRESS POINTED TO BY TP4RTN IN 004 VECTOR.
4464 ;* OCCURENCE OF 004 TRAP VECTORS TO THIS ROUTINE.
4465 ;*
4466 ;* COMMENTS: ANY 004 TRAP WHICH OCCURS AT AN ADDRESS OTHER THAN THAT LABELED
4467 ;* ADRPTR WILL BE HANDLED BY THE NORMAL 004 TRAP SERVICE ROUTINE.
4468 ;*
4469 ;* SUBORDINATE ROUTINES CALLED: NONE.
4470 ;*****
4471
4472 017712 021627 014200 TP4RTN:: CMP (SP),@ADRPTR ;COMPARE EXPECTED ADR AGAINST TRAP RET PC.
4473 017716 001402 BEQ 2$ ;IF THEY MATCH, CONTINUE THIS ROUTINE.
4474 017720 000177 162352 JMP @TP4VEC ;IF NOT, JUMP TO NORMAL 004 TRAP SERVICE RTN.
4475 017724 052767 100000 162346 2$: BIS @BIT15,TP4FLG ;SET THE 004 TRAP OCCURED FLAG.
4476 017732 000002 RTI ;ALL DONE, GO BACK TO THE TEST.
    
```

4478  
 4479  
 4480  
 4481  
 4482  
 4483  
 4484  
 4485  
 4486  
 4487  
 4488  
 4489  
 4490  
 4491  
 4492  
 4493  
 4494  
 4495  
 4496  
 4497  
 4498  
 4499  
 4500  
 4501  
 4502  
 4503  
 4504  
 4505  
 4506  
 4507  
 4508  
 4509  
 4510  
 4511  
 4512  
 4513  
 4514  
 4515  
 4516  
 4517  
 4518  
 4519  
 4520  
 4521  
 4522  
 4523  
 4524  
 4525  
 4526  
 4527

017734  
 017734 004567 164120  
 017740 016701 162326  
 017744 005201  
 017746 102001  
 017750 005301  
 017752 010167 162314  
 017756 016703 162312  
 017762 005777 162240  
 017766 100402  
 017770 052703 100000  
 017774 010367 162274  
 020000 012702 000040  
 020004 005777 162216  
 020010 100005  
 020012 005302  
 020014 001373  
 020016 052767 040000 162250  
 020024 004736  
 020026 000002

```

.SBTTL INTERRUPT SERVICE ROUTINE - TXAINT -
; * *****
; * - TRANSMIT ACTION INTERRUPT SERVICE ROUTINE -
; * THIS ROUTINE HANDLES A TX INTERRUPT BY COUNTING THE INTERRUPT,
; * SETTING A FLAG IF THE TX_ACTION BIT IS CLEAR, AND READING THE CSR
; * UNTIL THE TX_ACTION BIT CLEARS OR THE MAXIMUM READ COUNT IS EXCEEDED.
; *
; * INPUTS: CSRA - CONTAINS THE ADDRESS OF THE CSR.
; * TXINTC - HOLDS THE COUNT OF THE NUMBER OF TX INTERRUPTS.
; * TXINTF - TX INTERRUPT FLAGS.
; *
; * OUTPUTS: TXINTC - CONTAINS THE UPDATED TX INTERRUPT COUNT.
; * TXINTF - TX INTERRUPT FLAGS (BIT 15 SET IF TX_ACTION CLEAR
; * BIT 14 SET IF MAX READ COUNT EXCEEDED)
; *
; * CALLING SEQUENCE: PUT THE ADDRESS OF THE LABEL TXAINT IN THE VECTOR
; * LOCATION.
; *
; * COMMENTS:
; *
; * SUBORDINATE ROUTINES CALLED: NONE
; *
; * - - - - -
TXAINT:: SAVE
;CALL REGISTER SAVE SUBRT.
        JSR      R5,PREG05
        MOV      TXINTC,R1      ;GET THE TX-INT COUNT.
        INC      R1             ;INCREMENT THE COUNT.
        BVC     2#             ;BRANCH IF NO OVERFLOW OCCURED.
        DEC      R1             ;RESET THE COUNT TO 177777.
        MOV      R1,TXINTC     ;SAVE THE NEW COUNT.
        MOV      TXINTF,R3     ;GET THE TX-INT FLAGS.
        TST     @CSRA         ;READ THE CSR.
        BMI     4#             ;AVOID SETTING THE ERROR FLAG IF
                                ;THERE IS A TX_ACTION.
        BIS     @BIT15,R3      ;SET THE FLAG.
        MOV      R3,TXINTF     ;UPDATE THE TX-INT FLAGS.
        MOV      @32.,R2      ;SET THE MAX TX_ACTION READ COUNT.
; *
; * READ THE CSR UNTIL THE TX_ACTION FIFO IS EMPTY OR THE MAX READ COUNT
; * IS EXCEEDED.
; *
; * - - - - -
        TST     @CSRA         ;READ THE CSR.
        BPL     60#           ;EXIT IF TX_ACTION FIFO IS EMPTY.
        DEC     R2             ;DECREMENT THE MAX READ COUNT.
        BNE     6#             ;BRANCH TO READ ANOTHER TX_ACTION IF MAX READ
                                ;COUNT IS NOT EXCEEDED.
        BIS     @BIT14,TXINTF ;SET THE "MAX TX_ACTION COUNT EXCEEDED" FLAG.
        PASS
        JSR      PC,@(SP).    ;RETURN TO PREG05 SUBRT.
        RTI
  
```



4536  
4537  
4538  
4539  
4540  
4541  
4542  
4543  
4544  
4545  
4546  
4547  
4548  
4549  
4550  
4551

020030  
020030  
020030 000167  
020032 000000  
020034  
020034  
020034 104425

.SBTTL REPORT CODING SECTION

\*\*\*  
: THE REPORT CODING SECTION CONTAINS THE  
: "PRINTS" CALLS THAT GENERATE STATISTICAL REPORTS.  
:--

BGNRPT

EXIT RPT

.EVEN

ENDRPT

L\$RPT::

.WORD J\$JMP  
.WORD L10017-2-

L10017:

TRAP C\$RPT

4553  
4561  
4562  
4563  
4564  
4565  
4566  
4567  
4568 020036  
020036  
4569  
4570 020036 177777  
4571 020040 177777  
4572 020042 177777  
4573  
4574 020044  
4575

.SBTTL PROTECTION TABLE

;++  
: THIS TABLE IS USED BY THE RUNTIME SERVICES  
: TO PROTECT THE LOAD MEDIA.  
:--

BGNPROT

L\$PROT::

-1  
-1  
-1

: OFFSET INTO P-TABLE FOR CSR ADDRESS  
: OFFSET INTO P-TABLE FOR MASSBUS ADDRESS  
: OFFSET INTO P-TABLE FOR DRIVE NUMBER

ENDPROT



```

4597
4598
4599
4600 .SBTTL INITIALIZE SECTION
4601 ;**
4602 ;*****
4603 ;* THIS SECTION CONTAINS THE CODE WHICH IS PERFORMED AT THE BEGINNING OF
4604 ;* EACH PASS OR AFTER A CONTINUE COMMAND.
4605 ;* THIS CODE PERFORMS THE FOLLOWING ACTIONS:
4606 ;*
4607 ;* MOVES THE INFORMATION HELD IN THE HARDWARE P-TABLE INTO THE GLOBAL
4608 ;* DATA AREA.
4609 ;*
4610 ;*****
4611 ;--
4611 020044 BGNINIT
4611 020044
4612
4613 020044 ;SEE IF PROGRAM JUST STARTED, BR IF YES L$INIT::
4613 020044 012700 000040 READEF @EF.START
4613 020050 104447
4614 020052 BCOMPLETE NEWSTA
4614 020052 103416
4615 ;SEE IF PROGRAM JUST RESTARTED, BR IF YES
4616 020054 012700 000037 READEF @EF.RESTART
4616 020054 104447
4617 020062 BCOMPLETE NEWRES
4617 020062 103556
4618 ;SEE IF THIS IS A NEW PASS, BR IF YES
4619 020064 012700 000035 READEF @EF.NEW
4619 020064 104447
4620 020072 BCOMPLETE NEWPAS
4620 020072 103555
4621 ;SEE IF PROGRAM WAS JUST CONTINUED
4622 020074 012700 000036 READEF @EF.CONTINUE
4622 020074 104447
4623 020102 BNCOMPLETE GETPRM
4623 020102 103161
4624 020104 JMP ENDIT
4624 020104 000167 000540
4625 020110
4626 020110 NEWSTA: BRESET ;RESET THE BUS TO PREVENT ILLEGAL INTERRUPTS.
4626 020110 104433 TRAP C$RESET
4627
4628 ;*
4629 ;* SET UP FOR LINE TIME CLOCK INTERRUPTS.
4630 ;--
4630 020112 CLOCK L,R1 ;GET THE CLOCK PARAMETERS.
4630 020112 012700 000114
4630 020116 104462
4630 020120 010001
4631 020122 012167 162156 MOV (R1)+,CLKCSR ;STORE CLOCK CSR ADDRESS.
4632 020126 012167 162154 MOV (R1)+,CLKBRL ;STORE CLOCK BUS REQ INT LEVEL.
4633 020132 012167 162152 MOV (R1)+,CLKVEC ;STORE CLOCK INTERRUPT VECTOR.
4634 020136 012167 162150 MOV (R1)+,CLKHRZ ;STORE CLOCK FREQUENCY.
4635 020142 026727 162144 000062 CMP CLKHRZ,#50. ;TEST FOR 50HZ LINE FREQUENCY.
4636 020150 001004 BNE 29 ;BRANCH IF CLOCK IS NOT 50HZ.

```

```

4637 020152 012767 000024 162144      MOV    #20.,MSTICK      ;INDICATE 20MS PER CLOCK TICK.
4638 020160 000403                    BR      4$
4639 020162 012767 000021 162134 2$:  MOV    #17.,MSTICK      ;INDICATE 17 MS PER CLOCK TICK.
4640 020170 012746 000300 4$:  SETVEC CLKVEC,#CLKINT,#PRI06 ;INITIALIZE CLOCK INTERRUPT VECTOR.
                                MOV    #PRI06,-(SP)
                                MOV    #CLKINT,-(SP)
                                MOV    CLKVEC,-(SP)
                                MOV    #3,-(SP)
                                TRAP   C$SVEC
                                ADD    #10,SP
4641 020216 016700 162070      MOV    CLKHRZ,RO      ;INITIALIZE THE BREAK COUNT
4642 020222 006300      ASL    RO              ; TO CAUSE A BREAK
4643 020224 010067 162072      MOV    RO,BCOUNT      ; EVERY 2 SECONDS.
4644 020230 012700 000240      SETPRI #PRI05         ;ALLOW CLOCK INTERRUPTS DISABLE OTHERS.
                                MOV    #PRI05,RO
                                TRAP   C$SPRI
4645
4646      ;+
4647      ; ENABLE THE LINE TIME CLOCK (LTC) CHECKING TO MAKE SURE THAT THE CSR
4648      ; IS ACCESSABLE.
4649      ; FIRST SET UP TO CATCH ANY 004 TRAPS WHICH OCCUR:
4650 020236 016767 157542 162032      MOV    4,TP4VEC        ;SAVE THE EXISTING 004 TRAP VECTOR.
4651 020244 012767 017712 157532      MOV    #TP4RTN,4      ;SET 004 TRAP VECTOR TO OUR SERVICE RTN ADR.
4652
4653      ;+
4654      ; ENABLE LTC CHECKING FOR 004 TRAP IN CASE CSR IS NOT THERE.
4655 020252 005067 162022      CLR    TP4FLG          ;CLEAR THE 004 TRAP FLAG.
4656 020256 012767 000100 162016      MOV    #BIT6,WORD1     ;SET UP TO SET BIT6 OF THE LTC CSR.
4657 020264 012700 002302      MOV    #WORD1,RO       ;SET UP WORD1 AS THE CKTRAP MOVE SOURCE.
4658 020270 016701 162010      MOV    CLKCSR,R1       ;SET UP LTC CSR AS DESTINATION FOR CKTRAP MOVE.
4659 020274 004767 173666      JSR    PC,CKTRAP       ;MOVE AND CHECK FOR TRAP.
4660 020300 016767 161772 157476      MOV    TP4VEC,4        ;RESTORE THE NORMAL 004 TRAP VECTOR.
4661 020306 103403      BCS    6$              ;IF NO TRAP, LTC IS THERE SO CONTINUE.
4662 020310 005067 161776      CLR    CLKHRZ          ;CLEAR LTC FREQUENCY WORD TO INDICATE NO LTC.
4663 020314 000402      BR     8$              ;BYPASS THE FOLLOWING CALIBRATION PROCEDURES.
4664
4665      ;+
4666      ; CALIBRATE THE DELAY ROUTINE MILLI-SECOND DELAY COUNT VALUE.
4667 020316 004767 173230 6$:  JSR    PC,CALMSL
4668
4669      ;+
4670      ; CHECK FOR MEMORY MANAGEMENT PRESENT ON THIS MACHINE.
4671      ; IF MEM MGT IS PRESENT, DISABLE IT.
4672 020322 016767 157456 161746 8$:  MOV    4,TP4VEC        ;SAVE THE EXISTING 004 TRAP VECTOR.
4673 020330 012767 017712 157446      MOV    #TP4RTN,4      ;SET 004 TRAP VECTOR TO OUR SERVICE RTN ADR.
4674 020336 005067 161736      CLR    TP4FLG          ;CLEAR THE 004 TRAP FLAG.
4675 020342 005067 161734      CLR    WORD1           ;PREPARE TO CLEAR THE MEM MGT SRO REGISTER.
4676 020346 012700 002302      MOV    #WORD1,RO       ;SELECT CLEARED WORD AS CKTRAP RTN SOURCE.
4677 020352 016701 161752      MOV    MMSRO,R1        ;SELECT MEM MGT SRO REGISTER AS DESTINATION.
4678 020356 005067 161750      CLR    MMPRES          ;INDICATE NO MEM MGT PRESENT IN CASE IT ISN'T.
4679 020362 005067 161746      CLR    MMENAB          ;INDICATE MEM MGT IS NOT ENABLED.
4680 020366 004767 173574      JSR    PC,CKTRAP       ;CLEAR THE MEM MGT SRO REG AND CHECK FOR TRAP.
4681 020372 016767 161700 157404      MOV    TP4VEC,4        ;RESTORE THE NORMAL 004 TRAP VECTOR.
4682 020400 103003      BCC    10$             ;SKIP INDICATING MEM MGT PRESENT IF IT ISN'T.
4683 020402 012767 000001 161722 10$: MOV    #1,MMPRES       ;INDICATE THAT MEM MGT IS PRESENT.
4684 020410 005067 161650      CLR    PASCNT          ;CLR COUNTER USED IN REPORTING ROM VERSION #.
4685 020414 000167 000006      JMP    NEWPAS          ;SKIP AROUND THE BUS RESET, IT'S BEEN DONE.

```



```

4686
4687 020420          NEWRES: BRESET                ;RESET THE BUS TO PREVENT ILLEGAL INTERRUPTS,
          020420    104433                TRAP    C$RESET
4688 020422    005067    161636          CLR    PASCNT                ;CLR COUNTER USED IN REPORTING ROM VERSION #.
4689 020426          NEWPAS: MOV    #-1,UNITN          ;RESET LOGICAL DEVICE TO -1
4690 020426    012767    177777    161570
4691
4692          ;+
4693          ; INCREMENT THE PASS COUNTER, CORRECT FOR ANY OVERFLOW.
4694          ; THIS COUNTER IS USED IN THE ROM VERSION TEST.
          ;-
4695 020434    005267    161624          INC    PASCNT                ;INCREMENT THE PASS COUNTER.
4696 020440    001002          BNE   GETPRM              ;BRANCH IF WE HAVE NOT YET! OVERFLOWED.
4697 020442    005367    161616          DEC    PASCNT              ;SET PASS COUNT TO 177777 OCTAL.
4698
4699          ; GET THE HARDWARE PARAMETERS FOR THIS UNIT.
4700 020446          GETPRM:
4701 020446    005267    161552          INC    UNITN                ;INCREMENT LOGICAL DEVICE NUMBER
4702 020452    026767    161546    161332    CMP    UNITN,L$UNIT        ;SEE IF MAXIMUM UNIT NO. EXCEEDED
4703 020460    002362          BGE   NEWPAS              ;BR IF YES
4704
4705 020462          GPWARD UNITN,R1                ;GET P-TABLE POINTER INTO R1
          020462    016700    161536
          020466    104442
          020470    010001
4706 020472          BCOMPLETE    30$                ;BR IF DEVICE AVAILABLE          MOV    UNITN,R0
          020472    103401                ;BR IF DEVICE AVAILABLE          TRAP  C$GPHRD
          020474    000764                ;BR IF DEVICE AVAILABLE          MOV    RO,R1
4707 020474          BR    GETPRM                    ;SKIP THIS DEVICE          BCS   30$
4708
4709
4710          ;***** HARDWARE PARAMETER MOVING CODE *****
4711 020476    012167    161524    30$:  MOV    (R1)+,CSRA          ;STORE DHU-11 CSR ADDRESS IN DEV.REG.ADDRESS TABLE
4712 020502    012102          MOV    (R1)+,R2            ;GET THE RX INTERRUPT VECTOR ADDRESS.
4713 020504    010267    161504          MOV    R2,RXVECA          ;STORE RX INT VECTOR ADDRESS.
4714 020510    062702    000004          ADD    #4,R2              ;CALCULATE TX INTERRUPT VECTOR ADDRESS.
4715 020514    010267    161476          MOV    R2,TXVECA          ;STORE TX INT VECTOR ADDRESS.
4716 020520    012167    161474          MOV    (R1)+,ACTLNS        ;STORE DHU-11 ACTIVE LINE BIT MAP
4717 020524    111167    161472          MOV    (R1),LOPBACK       ;STORE DHU-11 LOOPBACK MODE
4718
4719          ;+
4720          ; CALCULATE DEVICE REGISTER ADDRESSES,AND PUT THEM IN THE
4721          ; DEVICE REGISTER ADDRESS TABLE.
          ;-
4722 020530    016701    161472          MOV    CSRA,R1            ;COPY CSR ADDRESS
4723 020534    005201          INC    R1                 ;INCREMENT CSR ADDRESS
4724 020536    005201          INC    R1                 ; COPY BY 2.
4725 020540    012703    000007          MOV    #7,R3              ;SET UP REGISTER COUNT
4726 020544    012702    002230          MOV    #RBUFA,R2          ;GET LOCATION WHERE RBUF ADDRESS GOES IN TABLE
4727 020550    010122    12$:  MOV    R1,(R2)+            ;STORE REGISTER ADDRESS IN TABLE
4728 020552    005201          INC    R1                 ;INCREMENT REGISTER ADDRESS
4729 020554    005201          INC    R1                 ; BY 2, FOR THE NEXT DEVICE REGISTER.
4730 020556    005303          DEC    R3                 ;DECREMENT REGISTER COUNT
4731 020560    001373          BNE   12$                ;LOOP IF NOT DONE
4732
4733          ;+
4734          ; INITIALISE THE BMP CODE QUEUE.
          ;-
4735
4736 020562    012700    002412          MOV    #BMPQCB,R0         ;GET THE START ADDRESS OF THE QUEUE.
4737 020566    012701    002612          MOV    #BMPQCE,R1         ;GET THE END ADDRESS OF THE QUEUE.

```

```

INITIALIZE SECTION
4738 020572 010067 161612
4739 020576 005020
4740 020600 020001
4741 020602 103775
4742
4743
4744
4745
4746 020604 032767 000020 161376
4747 020612 001416
4748 020614 026727 161172 000001
4749 020622 003412
4750 020624
    020624 016746 161374
    020630 012746 005231
    020634 012746 000002
    020640 010600
    020642 104417
    020644 062706 000006
4751 020650
4752
4753 020650 005067 161374
4754
4755
4756
4757 020654
    020654 012700 000340
    020660 104441
4758 020662
    020662
    020662 104411
4759
4760 000000

14$: MOV R0,BMPCQP ;SET THE POINTER TO THE START OF THE QUEUE.
      CLR (R0)+ ;CLEAR OUT THE CONTENTS OF THE QUEUE.
      CMP R0,R1 ;CHECK IF END OF QUEUE HAS BEEN REACHED.
      BLO 14$ ;LOOP IF NOT ALL DONE.
;+
; REPORT THE UNIT NUMBER IF THE SOFTWARE P-TABLE QUESTION WAS ANSWERED YES,
; AND THE MAXIMUM UNIT NUMBER IS GREATER THAN 1.
;-
      BIT #BIT4,OPTION ;CHECK IF THE QUESTION WAS ANSWERED YES.
      BEQ 16$ ;SKIP REPORTING UNIT NUMBER IF IT IS DISABLED.
      CMP L$UNIT,#1 ;CHECK MAXIMUM NUMBER OF UNITS SELECTED.
      BLE 16$ ;DO NOT REPORT UNIT NUMBER IF MAX NUMBER < 1.
      PRINTF #MFUNIT,UNITN ;REPORT UNIT NUMBER.
                                MOV UNITN,-(SP)
                                MOV #MFUNIT,-(SP)
                                MOV #2,-(SP)
                                MOV SP,R0
                                TRAP C$PNTF
                                ADD #6,SP

16$:
ENDIT: CLR CTRLCF ;CLR THE CTRL-C TEST ABORT FLAG.
;+
; SET THE PROCESSOR PRIORITY TO DISABLE ALL INTERRUPTS.
;-
      SETPRI #PRI07 ;SET PROCESSOR PRIORITY TO 7.
                                MOV #PRI07,R0
                                TRAP C$SPRI

                                L10021:
                                TRAP C$INIT

TNUM == 0 ;INITIALIZE THE ASSEMBLER TEST NUMBER VARIABLE.

```



INITIALIZE SECTION

4769  
4770  
4771  
4772  
4773  
4774  
4775  
4776  
4777  
4778  
4779  
4780  
4781 020664  
020664  
4782  
4789  
4790 020664  
020664  
020664 104461

.SBTTL AUTODROP SECTION

;++  
: THIS CODE IS EXECUTED IMMEDIATELY AFTER THE INITIALIZE CODE IF  
: THE "ADR" FLAG WAS SET. THE UNIT(S) UNDER TEST ARE CHECKED TO  
: SEE IF THEY WILL RESPOND. THOSE THAT DON'T ARE IMMEDIATELY  
: DROPPED FROM TESTING.  
:--

BGNAUTO

L\$AUTO::

ENDAUTO

L10022: TRAP C\$AUTO

4799  
 4800  
 4801  
 4802  
 4803  
 4804  
 4805  
 4806  
 4807  
 4808 020666  
 4809 020666  
 4810 020666 005767 161356  
 4811 020672 001401  
 4812 020674 104433  
 4813 020676  
 4814  
 4823  
 4824 020676  
 4825 020676 104432  
 4837 020700 000002  
 4838  
 4839  
 4840 020702  
 020702  
 020702 104412

.SBTTL CLEANUP CODING SECTION

```

; **
; THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS PERFORMED
; AFTER THE HARDWARE TESTS HAVE BEEN PERFORMED.
; --
    
```

```

                BGNCLN
                L%CLEAN::
                TST   CTRLCF
                BEQ   2%
                BRESET
                ;DID WE GET HERE BY CTRL-C FROM TEST?
                ;CTRL-C FROM TEST? NO, SKIP BUS RESET.
                ;YES, CLR ANY DMAS OR OUTSTANDING INTERRUPTS.
                TRAP   C%RESET

                2%:
                EXIT   CLN
                TRAP   C%EXIT
                .WORD  L10023.

                .EVEN
                ENDCLN
                L10023:
                TRAP   C%CLEAN
    
```



4849  
 4850  
 4851  
 4852  
 4853  
 4854  
 4855  
 4856  
 4857

.SBTTL DROP UNIT SECTION

\*\*\*  
 ; THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE  
 ; TO NO LONGER BE TESTED.  
 ;--

4858 020704  
 020704

BGNDU

L\$DU::

4859  
 4860

020704 010046  
 020706 012746 020730  
 020712 012746 000002  
 020716 010600  
 020720 104417  
 020722 062706 000006  
 020726 000427

PRINTF #DROP,RO

;REPORT UNIT THAT HAS BEEN DROPPED.

MOV RO,-(SP)  
 MOV #DRGP,-(SP)  
 MOV #2,-(SP)  
 MOV SP,RO  
 TRAP C\$PNTF  
 ADD #6,SP

4861  
 4862

020726 000427

BR EDROP

;BRANCH AROUND THE MESSAGE.

4863

020730 045 101 040  
 020733 125 116 111  
 020736 124 045 104  
 020741 066 045 101  
 020744 040 104 122  
 020747 117 120 120  
 020752 105 104 040  
 020755 106 122 117  
 020760 115 040 106  
 020763 125 122 124  
 020766 110 105 122  
 020771 040 124 105  
 020774 123 124 111  
 020777 116 107 056  
 021002 045 116 000

DROP: .ASCIZ/##A UNIT##D6##A DROPPED FROM FURTHER TESTING.##N/

4864  
 4865

021006

EDROP: .EVEN

4866  
 4867

021006 000167  
 021010 000000

EXIT DU

.WORD JSJMP  
 .WORD L10024-2-

4868  
 4869

021012

ENDDU

4870

021012  
 021012 104453

L10024:  
 TRAP C\$DU

4879  
4880  
4881  
4882  
4883  
4884  
4885  
4886  
4887  
4888  
4889  
4890  
4891  
4892  
4893  
4894  
4895  
4896  
4897

021014  
021014  
021014 000167  
021016 000000  
021020  
021020  
021020 104452

.SBTTL ADD UNIT SECTION

\*\*\*  
; THE ADD-UNIT SECTION CONTAINS ANY CODE THE PROGRAMMER WISHES  
; TO BE EXECUTED IN CONJUNCTION WITH THE ADDING OF A UNIT BACK  
; TO THE TEST CYCLE.  
---

BGNAU

L\$AU::

EXIT AU

.WORD J\$JMP  
.WORD L10025-2-.

.EVEN

ENDAU

L10025: TRAP C\$AU



```

4899 .SBTTL HARDWARE TEST - ADRA -
4900 ;**
4901 ;*****
4902 ;*
4903 ;*
4904 ;*
4905 ;* THIS TEST VERIFIES THAT THE DEVICE REGISTERS WILL RESPOND TO THE PROPER
4906 ;* UNIBUS HANDSHAKING SIGNALS WHEN ACCESSED. IF THE DHU11 DOES NOT RESPOND
4907 ;* TO THE ACCESS ATTEMPTS (IF THE DHU11 IS AT THE WRONG ADDRESS, FOR EXAMPLE)
4908 ;* THE 004 BUS TIME-OUT TRAP IS DETECTED BY THIS ROUTINE AND AN ERROR
4909 ;* IS REPORTED. THIS TEST IS PERFORMED ON LINE 0 ONLY.
4910 ;*
4911 ;*****
4912 ;--
4913 021022 BGNTST
4914 021022
4915 000001 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
4916 012767 000001 161224 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (1)
4917 012767 177777 161212 MOV #-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
4918 012767 000145 163006 MOV #101,ERRNBR ;SET THE TEST ERROR NUMBER IN THE TABLE.
4919 012767 005262 163002 MOV #EM0103,ERRMSG ;SET UP THE TEST FAILURE MESSAGE IN THE TABLE.
4920 012767 011430 162776 MOV #ER0101,ERRBLK ;SET-UP THE ERROR ROUTINE IN THE ERROR TABLE.
4921 ;*
4922 ; SET UP TO CATCH ANY 004 TRAPS WHICH OCCUR:
4923 ;--
4924 021060 016767 156720 161210 MOV 4,TP4VEC ;SAVE THE EXISTING 004 TRAP VECTOR.
4925 021066 012767 017712 156710 MOV #TP4RTN,4 ;SET 004 TRAP VECTOR TO OUR SERVICE RTN ADR.
4926 021074 005005 CLR R5 ;CLEAR THE ERROR FLAGS.
4927 ;*
4928 ; HERE BEGINS THE LOOP TO TEST THE REGISTERS FOR A LINE.
4929 ; FIRST TEST THE CSR AND SET THE IND.ADR.REG (I.A.R) FIELD.
4930 ;--
4931 021076 016700 161124 MOV CSRA,R0 ;SET UP CSR AS THE CKTRAP MOVE SOURCE.
4932 021102 012701 021274 MOV #52#,R1 ;SET UP DESTINATION LOCATION FOR CKTRAP MOVE.
4933 021106 004767 173054 JSR PC,CKTRAP ;MOVE AND CHECK FOR TRAP.
4934 021112 103402 BCS 4# ;IF NO TRAP, BYPASS ERROR.
4935 021114 052705 100001 BIS #100001,R5 ;SET FATAL READ ERROR FLAGS.
4936 021120 042767 000017 000146 4#: BIC #17,52# ;CLEAR THE I.A.R FIELD OF THE CSR DATA.
4937 021126 010100 MOV R1,R0 ;USE OLD DESTINATION FOR SOURCE OF CKTRAP MOVE.
4938 021130 016701 161072 MOV CSRA,R1 ;SET UP CSR AS THE CKTRAP MOVE DESTINATION.
4939 021134 004767 173026 JSR PC,CKTRAP ;MOVE AND CHECK FOR TRAP.
4940 021140 103403 BCS 6# ;IF NO TRAP, BYPASS ERROR.
4941 021142 052705 100002 BIS #100002,R5 ;SET FATAL WRITE ERROR FLAGS.
4942 021146 000434 BR 40# ;EXIT AND REPORT FATAL ERROR.
4943 ;*
4944 ; NOW, WE TEST EACH REGISTER FOR THIS LINE.
4945 ;--
4946 021150 012702 000010 6#: MOV #8#,R2 ;INIT REGISTER COUNTER TO 8.
4947 021154 016767 161046 000110 MOV CSRA,50# ;INITIALIZE THE REGISTER POINTER.
4948 021162 016700 000104 8#: MOV 50#,R0 ;SET UP REGISTER AS THE SOURCE FOR CKTRAP MOVE.
4949 021166 012701 021274 MOV #52#,R1 ;SET UP LOCAL STORAGE AS THE DES FOR CKTRAP.
4950 021172 004767 172770 JSR PC,CKTRAP ;PERFORM THE MOVE, CHECK FOR TRAP.
4951 021176 103402 BCS 10# ;IF NO TRAP, BYPASS THE SETTING OF ERROR FLAGS.
4952 021200 052705 100001 BIS #100001,R5 ;SET FATAL READ ERROR FLAGS.
4953 021204 010100 MOV R1,R0 ;USE OLD DEST AS SRC FOR CKTRAP MOVE.
4954 021206 016701 000060 10#: MOV 50#,R1 ;SET UP REGISTER AS THE DEST FOR CKTRAP MOVE.
    
```

```

4955 021212 004767 172750          JSR    PC,CKTRAP      ;PERFORM THE MOVE, CHECK FOR TRAP.
4956 021216 103402                   BCS    12$            ;IF NO TRAP, BYPASS THE SETTING OF ERROR FLAGS.
4957 021220 052705 100002                   BIS    @100002,R5    ;SET FATAL WRITE ERROR FLAGS.
4958 021224 005267 000042          12$:   INC    50$      ;INCREMENT THE REGISTER
4959 021230 005267 000036          INC    50$            ; POINTER BY 2.
4960 021234 005302                   DEC    R2             ;COUNT THE REGISTER.
4961 021236 001351                   BNE    8$             ;LOOP TO TEST THE NEXT REGISTER ADDRESS.
4962
4963
4964
4965
4966
4967
4968 021240 016767 161032 156536 40$:   MOV    TP4VEC,4      ;RESTORE THE NORMAL 004 TRAP VECTOR.
4969 021246 005705                   TST    R5             ;CHECK THE ERROR FLAGS.
4970 021250 100012                   BPL    60$            ;EXIT ROUTINE IF NO ERRORS.
4971
4972
4973
4974 021252
021252 104460
4975
4976
4977 021254
021254 016700 160744          DODU   UNITN         ;DROP THIS UNIT FROM FUTHER TESTING.
021260 104451                   MOV    UNITN,RO      ;
4978 021262 005067 160762          CLR    CTRLCF        ;INDICATE NO CTRL-C ABORT FROM TEST.
4979 021266
021266 104444                   DOCLN  C$DODU        ;ABORT THIS SUB PASS.
4980 021270 000402                   BR     60$            ;
4981
4982
4983 021272 000000          ;***** LOCAL STORAGE. *****
4984 021274 000000          50$:   .WORD 0         ;STORAGE FOR THE SOURCE OR DEST OF THE CKTRAP MOVE.
4985
4986          52$:   .WORD 0         ;STORAGE FOR THE SOURCE OR DEST OF THE CKTRAP MOVE.
4987 021276 005067 160746          60$:   CLR    CTRLCF        ;INDICATE THAT WE ARE NOT WITHIN A TEST.
4988 021302
021302
021302 104401                   ENDTST
L10026: TRAP    C$ETST
    
```



4990  
 4991  
 4992  
 4993  
 4994  
 4995  
 4996  
 4997  
 4998 021304  
 021304  
 4999 021304  
 021304 012700 000240  
 021310 104441  
 5000 000002  
 5001 021312 012767 000002 160734  
 5002 021320 012767 177777 160722  
 5003 021326 012767 000001 162514  
 5004 021334 012767 007641 162510  
 5005 021342 012767 005403 162504  
 5006 021350 012767 013136 162500  
 5007  
 5008  
 5009  
 5010  
 5011  
 5012 021356 004767 172634  
 5013 021362 103145  
 5014  
 5015 021364 004767 173160  
 5016  
 5017  
 5018  
 5019  
 5020  
 5021  
 5022 021370 016705 160624  
 5023 021374 012700 000204  
 5024 021400 004767 176146  
 5025 021404 012700 177670  
 5026 021410 004767 176166  
 5027 021414 004767 175502  
 5028  
 5029  
 5030  
 5031 021420 016705 160574  
 5032 021424 005001  
 5033 021426 012767 007642 162416 24:  
 5034 021434 000241  
 5035 021436 006005  
 5036 021440 103112  
 5037 021442 004767 173722  
 5038 021446 103113  
 5039  
 5040  
 5041  
 5042  
 5043

```
.SBTTL  HARDWARE TEST          - DMASTA -
; * *****
; *          - DMA START BIT TEST -
; * THIS TEST VERIFIES THAT THE DMA_START BIT IN THE DUT'S LINE CONTROL
; * REGISTERS WILL INITIATE DMA TRANSMISSION ON THE SELECTED LINE.
; * THIS TEST IS PERFORMED IN INTERNAL LOOPBACK, ON ALL ACTIVE LINES.
; * *****
; - - - - -
BGNTST
                T2::
                SETPRI  #PRI05          ;ALLOW LTC INTERRUPTS.
                                MOV      #PRI05,R0
                                TRAP    C$SPRI
TNUM == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
MOV  #TNUM,TSTNUM        ;SET UP THE TEST NUMBER. (40)
MOV  #-1,CTRLCF          ;INDICATE THAT WE ARE IN A TEST.
MOV  #1,ERRTYP           ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
MOV  #4001,ERRNBR        ;SET THE FIRST ERROR NUMBER IN ERROR TABLE.
MOV  #EM4001,ERRMSG      ;SET ERROR MESSAGE ADDRESS IN ERRTABL.
MOV  #ER9101,ERRBLK      ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
; *
; * RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
; * CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
; * THIS SUBROUTINE REPORTS ERROR >>>> 4001 <<<<<.
; - - - - -
                JSR    PC,CLNRST        ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
                BCC   503              ;RESET FAILURE?, ABORT THIS TEST.
                JSR    PC,INDATP        ;INITIALSE THE 256 BYTE DATA PATTERN.
; *
; * SET INTERNAL LOOPBACK,ENABLE RECEIVER FUNCTIONS ON ALL ACTIVE LINES.
; * SET LPR ON ALL LINES TO 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY,
; * 2 STOP BITS.
; * ENABLE TRANSMITTERS ON ALL ACTIVE LINES.
; - - - - -
                MOV   ACTLNS,R5        ;PASS THE ACTIVE LINE BIT MAP.
                MOV   #204,R0         ;PASS THE LNCTRL CONTENTS.
                JSR   PC,WTMLNC        ;INITIALISE THE LNCTRL REGISTERS.
                MOV   #177670,R0      ;PASS THE LPR CONTENTS.
                JSR   PC,WTMLPR        ;INITIALSE THE LPR REGISTERS ON ALL LINES.
                JSR   PC,TXENBL        ;ENABLE TRANSMITTERS ON ALL LINES.
; *
; * SET-UP OUTER LOOP TO TEST THE DMA_START BIT ON ALL ACTIVE LINES.
; - - - - -
                MOV   ACTLNS,R5        ;GET THE ACTIVE LINE BIT MAP.
                CLR   R1              ;CLEAR THE LINE NUMBER COUNTER.
                MOV   #4002,ERRNBR    ;SET THE ERROR NUMBER TO 4002.
                CLC                    ;CLEAR THE CARRY BIT PRIOR TO SHIFTING BIT MAP.
                ROR   R5              ;SHIFT THE BIT MAP INTO THE CARRY BIT.
                BCC  14#              ;DO NOT TEST THE LINE IF IT IS INACTIVE.
                JSR   PC,PUFIFO        ;PURGE THE FIFO.
                BCC  503              ;GO REPORT ERROR IF FIFO WILL NOT CLEAR.
; *
; * PERFORM DMA_START BIT TESTING ON EACH LINE INDIVIDUALLY.
; * TEST EACH DMA_START BIT BEFORE TX'ING DATA PATTERN, REPORT ERROR IF SET.
; * SET DMA_START BIT ON LUT, VERIFY IT IS SET, REPORT ERROR IF CLEAR.
; * WAIT FOR DMA TO COMPLETE.
```

111

```

5044
5045
5046
5047 021450 005267 162376
5048 021454 012702 002650
5049 021460 012703 000144
5050 021464 004767 172710
5051 021470 103067
5052
5053
5054
5055
5056 021472 005267 162354
5057 021476 010177 160524
5058 021502 105777 160534
5059 021506 100060
5060
5061
5062
5063 021510 005267 162336
5064 021514 010103
5065 021516 012701 170226
5066 021522 016702 160500
5067 021526 004767 175704
5068 021532 103045
5069 021534 012704 000005
5070 021540 004767 172516
5071 021544 010301
5072
5073
5074
5075
5076 021546 005267 162300
5077 021552 010177 160450
5078 021556 105777 160460
5079 021562 100432
5080
5081
5082
5083
5084
5085 021564 005003
5086 021566 012704 000200
5087 021572 012767 007647 162252 6:
5088 021600 017702 160424
5089 021604 100021
5090 021606 012700 170301
5091 021612 040200
5092 021614 001007
5093 021616 005267 162230
5094 021622 004767 174652
5095 021626 005304
5096 021630 001422
5097 021632 000757
5098 021634 005203
5099 021636 020327 000144
5100 021642 002753

; VERIFY DMA_START BIT IS CLEAR, REPORT ERROR IF SET.
; VERIFY CORRECT NUMBER OF CHARS WERE RECEIVED, REPORT ERROR IF < EXPECTED.
;
INC ERRNBR ;SET ERROR NUMBER TO 4003.
MOV #BUFBA,R2 ;PASS THE START OF THE DATA PATTERN TO TX.
MOV #100,R3 ;PASS THE LENGTH OF THE DATA PATTERN.
JSR PC,DODMA ;TRANSMIT THE DATA PATTERN.
BCC 12: ;GO REPORT ERROR IF DMA_START BIT SET.
;
; TEST THE STATE OF THE DMA_START BIT ON THE LINE UNDER TEST.
; REPORT ERROR IF DMA_START BIT IS CLEAR.
;
INC ERRNBR ;INCREMENT ERROR NUMBER TO 4004.
MOV R1,@CSRA ;SELECT THE LINE CURRENTLY UNDER TEST.
TSTB @TXAD2A ;TEST THE STATE OF THE DMA_START BIT.
BPL 12: ;GO REPORT ERROR IF BIT IS CLEAR.
;
; WAIT FOR DMA TRANSMISSION TO COMPLETE.
;
INC ERRNBR ;INCREMENT ERROR NUMBER TO 4005.
MOV R1,R3 ;SAVE THE LINE NUMBER.
MOV #170226,R1 ;TEST BIT 15, TIMEOUT OF 150 MILLI SECS.
MOV CSRA,R2 ;PASS THE ADDRESS OF THE REGISTER TO TEST.
JSR PC,WAIBIS ;WAIT FOR DMA TO COMPLETE.
BCC 10: ;GO REPORT ERROR IF TIMEOUT OCCURRED.
MOV #5,R4 ;PASS DELAY OF 5 MILLI SECS.
JSR PC,DELAY ;WAIT FOR CHAR TO BE RECEIVED AND PROCESSED.
MOV R3,R1 ;RESTORE THE CURRENT LINE NUMBER.
;
; TEST THE STATE OF THE DMA_START BIT ON THE LINE UNDER TEST.
; REPORT ERROR IF DMA_START BIT IS SET.
;
INC ERRNBR ;INCREMENT ERROR NUMBER TO 4006.
MOV R1,@CSRA ;SELECT THE LINE CURRENTLY UNDER TEST.
TSTB @TXAD2A ;TEST THE STATE OF THE DMA_START BIT.
BMI 12: ;GO REPORT ERROR IF BIT IS STILL SET.
;
; VERIFY THE NUMBER OF CHARS RECEIVED = NUMBER OF CHARS EXPECTED.
; REPORT ERROR IF COUNT IS INCORRECT.
; IF MORE THAN 128 BMP CODES ARE FOUND THEN REPORT ERROR AND EXIT TEST.
;
CLR R3 ;CLEAR THE READ COUNTER.
MOV #128,R4 ;SET UP MAX BMP CODE READ COUNT.
MOV #4007,ERRNBR ;SET ERROR NUMBER TO 4007.
MOV @RBUFA,R2 ;READ THE CHARACTER FROM THE FIFO.
BPL 12: ;GO REPORT ERROR IF FIFO EMPTY TOO SOON.
MOV #170301,R0 ;SET-UP BIT MASK OF A BMP CODE.
BIC R2,R0 ;TRY TO CLEAR THE BMP CODE MASK.
BNE 8: ;BRANCH IF NOT A BMP CODE.
INC ERRNBR ;INCREMENT ERROR NUMBER TO 4008.
JSR PC,SAVBMP ;SAVE THE BMP CODE ON THE QUEUE.
DEC R4 ;DECREMENT MAX BMP CODE READ COUNT.
BEQ 50: ;GO REPORT ERROR IF TOO MANY BMP CODES FOUND.
BR 6: ;DO NOT COUNT THE BMP CODE AS A VALID CHAR.
INC R3 ;COUNT THIS CHARACTER.
CMP R3,#100. ;HAVE WE RECIEVED 100 CHARACTERS?.
BLT 6: ;LOOP UNTIL 100 (NON-BMP) CHARS ARE READ.

```



```

5101 021644 000410          BR      14$          ;SKIP AROUND THE ERROR REPORT.
5102
5103
5104
5105
5106 021646 010301          10$:   MOV      R3,R1          ;RESTORE THE CURRENT LINE NUMBER.
5107
5108 021650 012702 005435    12$:   MOV      @EM4002,R2      ;PASS THE ERROR MESSAGE TO BE REPORTED.
5109
5110 021654          ERROR          ; "DMA_START BIT BAD ON LINE NN".
5111 021654 104460          ; >>>> ERROR <<<<<.
5112
5113
5114
5115 021656 032767 000100 160324  ;EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
5116 021664 001406          BIT      @BIT06,OPTION      ;EXIT WITH TEST FAILURE MESSAGE IF
5117
5118 021666 005201          BEQ      60$              ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
5119 021670 005705          14$:   INC      R1              ;INCREMENT THE LINE NUMBER COUNTER.
5120 021672 001255          TST      R5              ;ARE THERE ANY MORE ACTIVE LINES TO TEST?.
5121 021674 000402          BNE      2$              ;YES; BRANCH TO TEST THE NEXT LINE.
5122
5123 021676 004767 174770    50$:   BR      60$              ;NO; EXIT THIS TEST.
5124 021702 005067 160342    60$:   JSR      PC,TSABRT      ;REPORT TEST ABORTED. NON-TEST RELATED ERROR.
5125
5126 021706          CLR      CTRLCF          ;INDICATE THAT WE ARE NOT WITHIN A TEST.
5127 021706          ENDTST
5128 021706 104401          L10027: TRAP      C$ETST
    
```

```

5128 .SBTTL  HARDWARE TEST          - DMABRT -
5129 :* *****
5130 :* - DMA ABORT/RESTART TEST -
5131 :* THIS TEST VERIFIES THAT EACH DMA_ABORT BIT WILL CORRECTLY HALT
5132 :* A DMA TRANSMISSION, AND RETURN A TX_ACTION.
5133 :* IT WILL ALSO VERIFY THAT THE ABORTED DMA TRANSMISSION CAN BE RESUMMED,
5134 :* AND THAT A TX_ACTION IS RETURNED UPON COMPLETION.
5135 :* THIS TEST IS PERFORMED IN INTERNAL LOOPBACK, ON ALL ACTIVE LINES.
5136 :*
5137 :*
5138 :* *****
5138 021710 BGNTST
5139 021710 SETPRI @PRI05          ;ALLOW LTC INTERRUPTS.      T3::
5139 021710 012700 000240
5139 021714 104441
5140 000003
5140 021716 012767 000003 160330      TNUM == TNUM + 1      ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5141 021724 012767 177777 160316      MOV @TNUM,TSTNUM      ;SET UP THE TEST NUMBER.      (41)
5142 021732 012767 000001 162110      MOV @-1,CTRLCF        ;INDICATE THAT WE ARE IN A TEST.
5143 021740 012767 010005 162104      MOV @1,ERRTYP         ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
5144 021746 012767 005471 162100      MOV @4101.,ERRNBR     ;SET THE FIRST ERROR NUMBER IN ERROR TABLE.
5145 021754 012767 013136 162074      MOV @EM4101,ERRMSG    ;SET ERROR MESSAGE ADDRESS IN ERRTBL.
5146 013136 162074      MOV @ER9101,ERRBLK    ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
5147
5148 ;*
5148 ; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
5149 ; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
5150 ; THIS SUBROUTINE REPORTS ERROR >>>> 4101 <<<<<.
5151 :*
5152 021762 004767 172230      JSR PC,CLNRST         ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
5153 021766 103164          BCC 60$              ;RESET FAILURE?, ABORT THIS TEST.
5154
5155 021770 004767 172554      JSR PC,INDATP         ;INITIALISE 256 BYTE DATA PATTERN.
5156
5157 ;*
5157 ; SET INTERNAL LOOPBACK,ENABLE RECEIVER FUNCTIONS ON ALL ACTIVE LINES.
5158 ; SET LPR ON ALL LINES TO 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY.
5159 ; 2 STOP BITS.
5160 ; ENABLE TRANSMITTERS ON ALL ACTIVE LINES.
5161 :*
5162 021774 016705 160220      MOV ACTLNS,R5         ;PASS THE ACTIVE LINE BIT MAP.
5163 022000 012700 000204      MOV @204,R0           ;PASS THE LNCTRL CONTENTS.
5164 022004 004767 175542      JSR PC,WTLNLC         ;INITIALISE THE LNCTRL REGISTERS.
5165 022010 012700 177670      MOV @177670,R0        ;PASS THE LPR CONTENTS.
5166 022014 004767 175562      JSR PC,WTLPR          ;INITIALSE THE LPR REGISTERS ON ALL LINES.
5167 022020 004767 175076      JSR PC,TXENBL         ;ENABLE TRANSMITTERS ON ALL LINES.
5168
5169 ;*
5169 ; PERFORM DMA_ABORT BIT TESTING ON EACH INDIVIDUAL (ACTIVE) LINE.
5170 :*
5171 022024 016705 160170      MOV ACTLNS,R5         ;GET THE ACTIVE LINE BIT MAP.
5172 022030 005001          CLR R1                ;CLEAR THE LINE NUMBER COUNTER.
5173 022032 012767 010006 162012 2$:  MOV @4102.,ERRNBR     ;SET THE ERROR NUMBER TO 4102.
5174 022040 000241          CLC                   ;CLEAR THE CARRY BIT PRIOR TO SHIFTING BIT MAP.
5175 022042 006005          ROR R5                ;SHIFT THE BIT MAP INTO THE CARRY BIT.
5176 022044 103127          BCC 10$               ;DO NOT TEST THE LINE IF IT IS INACTIVE.
5177 022046 004767 173316      JSR PC,PUFIFO         ;PURGE THE FIFO.
5178 022052 103130          BCC 50$               ;GO REPORT ERROR IF FIFO WILL NOT CLEAR.
5179
5180 ;*
5181 ; CHECK THE DMA_ABORT BIT BEFORE ENABLING DMA, REPORT ERROR IF SET.

```



```

5182 022054 005267 161772      INC      ERRNBR      ;INCREMENT ERROR NUMBER TO 4103.
5183 022060 010177 160142      MOV      R1,@CSRA   ;SELECT THE LINE CURRENTLY UNDER TEST.
5184 022064 032777 000001 160144 BIT      @BIT0,@LNCTRA ;TEST THE STATE OF THE DMA_ABORT BIT.
5185 022072 001105                BNE      6$         ;GO REPORT ERROR IF BIT IS SET.
5186
5187      ;+
5188      ; ENABLE DMA TX ON SELECTED LINE, WAIT FOR DMA TO TX APPROX 1/4 OF DATA.
5189      ; ABORT THE DMA TRANSMISSION. WAIT FOR TX_ACTION TO BE RETURNED.
5190 022074 005267 161752      INC      ERRNBR      ;SET ERROR NUMBER TO 4104.
5191 022100 012702 002650      MOV      @BUFBA,R2  ;PASS THE START OF THE DATA PATTERN TO TX.
5192 022104 012703 000400      MOV      @256.,R3   ;PASS THE LENGTH OF THE DATA PATTERN.
5193 022110 004767 172264      JSR      PC,DODMA   ;TRANSMIT THE DATA PATTERN.
5194 022114 103107                BCC      50$        ;GO REPORT ERROR IF THERE ARE TX PROBLEMS.
5195
5196      ;+
5197      ; WAIT FOR DMA TO TRANSMIT 1/4 OF THE DATA BEFORE ABORTING.
5198 022116 010177 160104      MOV      R1,@CSRA   ;SELECT THE LINE CURRENTLY UNDER TEST.
5199 022122 012704 000050      MOV      @40.,R4    ;PASS THE DELAY TIME OF 40 MILLI SECONDS.
5200 022126 004767 172130      JSR      PC,DELAY   ;WAIT FOR APPROX 1/4 OF DATA TO BE TX'D.
5201 022132 052777 000001 160076 BIS      @BIT0,@LNCTRA ;ABORT THE DMA TRANSMISSION.
5202
5203      ;+
5204      ; WAIT FOR TX_ACTION TO BE RETURNED, REPORT ERROR IF TIME-OUT OCCURS.
5205 022140 005267 161706      INC      ERRNBR      ;INCREMENT ERROR NUMBER TO 4105.
5206 022144 010103                MOV      R1,R3      ;SAVE THE LINE NUMBER.
5207 022146 012701 170012      MOV      @170012,R1 ;TEST BIT 15, TIMEOUT OF 10 MILLI SECS.
5208 022152 016702 160050      MOV      CSRA,R2    ;PASS THE ADDRESS OF THE REGISTER TO TEST.
5209 022156 004767 175254      JSR      PC,WAIBIS  ;WAIT FOR DMA TO COMPLETE.
5210 022162 103050                BCC      4$         ;GO REPORT ERROR IF TIMEOUT OCCURRED.
5211 022164 010301                MOV      R3,R1      ;RESTORE THE CURRENT LINE NUMBER.
5212
5213      ;+
5214      ; VERIFY DMA_START BIT CLEAR, REPORT ERROR IF SET.
5215 022166 005267 161660      INC      ERRNBR      ;INCREMENT ERROR NUMBER TO 4106.
5216 022172 012702 005557      MOV      @EM4103,R2 ;SELECT MESSAGE TO BE REPORTED.
5217
5218 022176 010177 160024      MOV      R1,@CSRA   ;"DMA_START BIT FOUND SET AFTER DMA ABORTED".
5219 022202 105777 160034      TSTB    @TXAD2A    ;SELECT THE LINE CURRENTLY UNDER TEST.
5220 022206 100441                BMI      8$         ;TEST THE STATE OF THE DMA_START BIT.
5221
5222      ;+
5223      ; RESUME DMA TRANSMISSION BY CLEARING DMA_ABORT AND SETTING DMA_START.
5224 022210 042777 000001 160020 BIC      @BIT0,@LNCTRA ;CLEAR THE DMA_ABORT BIT.
5225 022216 052777 000200 160016 BIS      @BIT7,@TXAD2A ;SET THE DMA_START BIT.
5226
5227      ;+
5228      ; WAIT FOR DMA TRANSMISSION TO COMPLETE.
5229 022224 005267 161622      INC      ERRNBR      ;INCREMENT ERROR NUMBER TO 4107.
5230 022230 010103                MOV      R1,R3      ;SAVE THE LINE NUMBER.
5231 022232 012701 170536      MOV      @170536,R1 ;TEST BIT 15, TIMEOUT OF 350 MILLI SECS.
5232 022236 016702 157764      MOV      CSRA,R2    ;PASS THE ADDRESS OF THE REGISTER TO TEST.
5233 022242 004767 175170      JSR      PC,WAIBIS  ;WAIT FOR DMA TO COMPLETE.
5234 022246 103016                BCC      4$         ;GO REPORT ERROR IF TIMEOUT OCCURRED.
5235 022250 012704 000002      MOV      @2,R4      ;PASS TIME-OUT OF 2 MILLI SECS.
5236 022254 004767 172002      JSR      PC,DELAY   ;WAIT FOR CHAR TO BE RECEIVED AND PROCESSED.
5237 022260 010301                MOV      R3,R1      ;RESTORE THE CURRENT LINE NUMBER.
5238

```

```
5239 ; TEST THE STATE OF THE DMA_ABORT BIT ON THE LINE UNDER TEST.
5240 ; REPORT ERROR IF DMA_ABORT BIT IS SET.
5241 ;-
5242 022262 005267 161564      INC   ERRNBR      ;INCREMENT ERROR NUMBER TO 4108.
5243 022266 010177 157734      MOV   R1,@CSRA   ;SELECT THE LINE CURRENTLY UNDER TEST.
5244 022272 032777 000001 157736 BIT   @BIT0,@LNCTRA ;TEST THE STATE OF THE DMA_ABORT BIT.
5245 022300 001002              BNE   6$         ;GO REPORT ERROR IF BIT IS SET.
5246 022302 000410              BR    10$        ;BRANCH TO CHECK FOR ANY MORE LINES TO TEST.
5247
5248 ;+
5249 ; REPORT ERROR, SKIP FURTHER TESTING ON THIS LINE.
5250 022304 010301              4$:   MOV   R3,R1      ;RESTORE THE CURRENT LINE NUMBER.
5251
5252 022306 012702 005523      6$:   MOV   @EM4102,R2 ;PASS THE ERROR MESSAGE TO BE REPORTED.
5253
5254 022312              8$:   ERROR          ; "DMA_ABORT BIT BAD ON LINE NN".
5255 022312 104460              ;                >>>>> ERROR <<<<<.
5256
5257 ;+
5258 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
5259 022314 032767 000100 157666 BIT   @BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
5260 022322 001406              BEQ   60$         ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
5261
5262 ;+
5263 ; VERIFY ALL ACTIVE LINES HAVE BEEN TESTED.
5264 ;-
5265 022324 005201      10$:  INC   R1          ;INCREMENT THE LINE NUMBER COUNTER.
5266 022326 005705      TST   R5          ;ARE THERE ANY MORE ACTIVE LINES TO TEST?.
5267 022330 001240      BNE   2$         ;YES; BRANCH TO TEST THE NEXT LINE.
5268 022332 000402      BR    60$        ;NO; EXIT THIS TEST.
5269
5270 022334 004767 174332      50$:  JSR   PC,TSABRT   ;REPORT TEST ABORTED. NON-TEST RELATED ERROR.
5271 022340 005067 157704      60$:  CLR   CTRLCF      ;INDICATE THAT WE ARE NOT WITHIN A TEST.
5272
5273 022344              ENDTST
5274 022344
5275 022344 104401              L10030:
5276                                TRAP   C$ETST
```



```

5275 .SBTTL  HARDWARE TEST          - DMAERR -
5276 ;+* *****
5277 ;*          - DMA ERROR BIT TEST -
5278 ;* THIS TEST VERIFIES THAT THE TX.DMA.ERROR BIT IN THE CSR IS
5279 ;* FUNCTIONING CORRECTLY. THE DMA ERROR IS FORCED BY MAKING THE DUT
5280 ;* ATTEMPT TO PERFORM A DMA TRANSFER FROM THE ADDRESS OF ITS OWN CSR.
5281 ;* SINCE THE DEVICE CANNOT BE BOTH A BUS MASTER AND SLAVE AT THE SAME
5282 ;* TIME, TIMEOUT WILL OCCUR WAITING FOR THE APPROPRIATE HANDSHAKE SIGNAL
5283 ;* FROM THE DMA ADDRESS.
5284 ;* THIS TEST IS PERFORMED IN INTERNAL LOOPBACK.
5285 ;*
5286 ;*
5287 ;-- *****
5288 022346          BGNTST
5289 022346          T4::
5290 022346 012700 000240          SETPRI  #PRI05          ;ALLOW LTC INTERRUPTS.
5291 022352 104441          MOV          #PRI05,R0
5292          TRAP          C$SPRI
5293 022354 000004          TNUM == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5294 022362 012767 000004 157672  MOV          #TNUM,TSTNUM          ;SET UP THE TEST NUMBER. (42)
5295 022370 012767 177777 157660  MOV          #-1,CTRLCF          ;INDICATE THAT WE ARE IN A TEST.
5296 022376 012767 000001 161452  MOV          #1,ERRTYP          ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
5297 022404 012767 010151 161446  MOV          #4201,,ERRNBR          ;SET THE FIRST ERROR NUMBER IN ERROR TABLE.
5298 022412 012767 005643 161442  MOV          #EM4201,ERRMSG          ;SET ERROR MESSAGE ADDRESS IN ERRTABL.
5299          MOV          #ER0503,ERRBLK          ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
5300 ;+
5301 ; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
5302 ; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
5303 ; THIS SUBROUTINE REPORTS ERROR >>>> 4201 <<<<<.
5304 022420 004767 171572          JSR          PC,CLNRST          ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
5305 022424 103120          BCC          60$          ;RESET FAILURE?, ABORT THIS TEST.
5306 ;+
5307 ; SET INTERNAL LOOPBACK,ENABLE RECEIVER FUNCTIONS ON ALL LINES.
5308 ; SET LPR ON ALL LINES TO 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY,
5309 ; 2 STOP BITS.
5310 ; ENABLE TRANSMITTERS ON ALL LINES.
5311 ;--
5312 022426 004767 172036          JSR          PC,FINACT          ;FIND AN ACTIVE LINE.
5313 022432 103115          BCC          60$          ;EXIT THE TEST IF NO ACTIVE LINES.
5314 022434 010104          MOV          R1,R4          ;SAVE THE LINE NUMBER.
5315 022436 012700 000204          MOV          #204,R0          ;PASS THE LNCTRL CONTENTS.
5316 022442 004767 175104          JSR          PC,WTWLNLC          ;INITIALISE THE LNCTRL REGISTERS.
5317 022446 012700 177670          MOV          #177670,R0          ;PASS THE LPR CONTENTS.
5318 022452 004767 175124          JSR          PC,WTWLPR          ;INITIALSE THE LPR REGISTERS ON THE ACTIVE LINE.
5319 022456 004767 174440          JSR          PC,TXENBL          ;ENABLE TRANSMITTERS ON THE ACTIVE LINE.
5320 ;+
5321 ; VERIFY THAT THE DMA.START BIT IS CLEAR BEFORE ATTEMPTING THE DMA TRANSFER.
5322 ;--
5323 022462 005267 161364          INC          ERRNBR          ;SET THE ERROR NUMBER TO 4202.
5324 022466 032777 000200 157546  BIT          #BIT07,#TXAD2A          ;TEST THE DMA START BIT.
5325 022474 001072          BNE          50$          ;BRANCH TO REPORT THE ERROR IF THE BIT IS SET.
5326 ;+
5327 ; SET UP THE DMA REGISTERS TO PERFORM THE TRANSFER FROM THE ADDRESS OF THE CSR.
5328 ;--
    
```

```

5329 022476 016777 157524 157534      MOV      CSRA,@TXAD1A      ;SET UP THE LOW 16 BITS OF THE DMA ADDR.
5330 022504 012777 000001 157532      MOV      #1,@TXBFCA      ;SET UP TO DMA ONE CHARACTER.
5331 022512 112777 000203 157522      MOV      #203,@TXAD2A    ;SET UP THE 2 MSB'S AND INITIATE THE DMA.
5332 022520 012701 170012      MOV      #170012,R1      ;TEST BIT 15, TIME OUT OF 10 MS.
5333 022524 016702 157476      MOV      CSRA,R2          ;INDICATE TO TEST THE CSR.
5334 022530 005267 161316      INC      ERRNBR          ;SET THE ERROR NUMBER TO 4203.
5335 022534 004767 174676      JSR      PC,WAIBIS       ;WAIT FOR A TX-ACTION.
5336 022540 103050      BCC      50$            ;REPORT THE ERROR IF NO TX-ACTION.
5337
5338      ;+
5339      ; VERIFY THAT THE DMA ERROR BIT IS SET AND THE DMA START BIT IS CLEAR.
5340 022542 005267 161304      INC      ERRNBR          ;SET THE ERROR NUMBER TO 4204.
5341 022546 032777 010000 157452      BIT      #BIT12,@CSRA    ;TEST THE DMA-ERROR BIT.
5342 022554 001436      BEQ      2$            ;REPORT THE ERROR IF BIT IS CLEAR.
5343 022556 005267 161270      INC      ERRNBR          ;SET THE ERROR NUMBER TO 4205.
5344 022562 032777 000200 157452      BIT      #BIT07,@TXAD2A  ;TEST THE DMA-START BIT.
5345 022570 001034      BNE      50$            ;REPORT THE ERROR IF THE BIT IS SET.
5346
5347      ;+
5348      ; VERIFY THAT THE DMA ERROR BIT CLEARS WHEN A "GOOD" DMA TRANSFER IS PERFORMED.
5349 022572 010401      MOV      R4,R1           ;SET UP THE ACTIVE LINE NUMBER.
5350 022574 012702 002650      MOV      @BUFAS,R2      ;SET UP THE START ADDRESS OF THE DMA BUFFER.
5351 022600 012703 000001      MOV      #1,R3          ;SET UP TO DMA ONE CHARACTER.
5352 022604 005267 161242      INC      ERRNBR          ;SET THE ERROR NUMBER TO 4206.
5353 022610 004767 171564      JSR      PC,DODMA       ;START THE DMA.
5354 022614 103022      BCC      50$            ;REPORT THE ERROR IF ONE OCCURED.
5355 022616 012701 170036      MOV      #170036,R1     ;SET UP TO TEST BIT15 WITH TIMEOUT OF 30 MS.
5356 022622 016702 157400      MOV      CSRA,R2        ;INDICATE TO TEST THE CSR.
5357 022626 005267 161220      INC      ERRNBR          ;SET THE ERROR NUMBER TO 4207.
5358 022632 004767 174600      JSR      PC,WAIBIS       ;WAIT FOR A TX-ACTION.
5359 022636 103011      BCC      50$            ;REPORT THE ERROR IF NO TX-ACTION OCCURED.
5360 022640 005267 161206      INC      ERRNBR          ;SET THE ERROR NUMBER TO 4208.
5361 022644 032702 010000      BIT      #BIT12,R2      ;TEST THE DMA ERROR BIT OF THE LAST CSR WORD READ.
5362 022650 001406      BEQ      60$            ;EXIT THE TEST IF THE BIT IS CLEAR.
5363
5364      ;+
5365      ; REPORT THE ERROR, DMA ERROR BIT BAD.
5366 022652 012701 005675      2$:     MOV      #EM4202,R1  ;SET THE MESSAGE
5367      ; "DMA ERROR BIT BAD".
5368 022656      ERROR
5369 022660 000402      BR      60$            ;EXIT THE TEST.                                TRAP      C$ERROR
5370
5371 022662 004767 174004      50$:   JSR      PC,TSABRT      ;REPORT THE NON-RELATED TEST ERROR.
5372 022666 005067 157356      60$:   CLR      CTRLCF      ;INDICATE THAT WE ARE NOT WITHIN A TEST.
5373
5374 022672      ENDTST
      022672
      022672 104401
      L10031:
      TRAP      C$ETST
    
```



```

5376
5377
5378
5379
5380
5381
5382
5383
5384
5385
5386
5387 022674
      022674
5388 022674 126727 157322 000002
5389 022702 001402
5390 022704 000167 000556
5391 022710
      022710 012700 000240
      022714 104441
5392      000005
5393 022716 012767 000005 157330
5394 022724 012767 177777 157316
5395 022732 012767 000001 161110
5396 022740 012767 011445 161104
5397 022746 012767 005717 161100
5398 022754 012767 013136 161074
5399
5400
5401
5402
5403
5404 022762 004767 171230
5405 022766 103402
5406 022770 000167 000472
5407
5408
5409
5410 022774 004767 170442
5411
5412
5413
5414
5415
5416
5417 023000 016705 157214
5418 023004 012700 000004
5419 023010 004767 174536
5420 023014 012705 177777
5421 023020 012700 177670
5422 023024 004767 174552
5423 023030 004767 174066
5424
5425
5426
5427 023034 012703 100000
5428 023040 016705 157154
5429 023044 046705 157212
    
```

```

.SBTTL HARDWARE TEST - OAUTOI -
;*****
; - OAUTO BIT INACTIVE TEST -
;
; THIS TEST VERIFIES THAT THE DUT'S OAUTO FUNCTION BEHAVES CORRECTLY
; WHEN INACTIVE, IE OAUTO BIT CLEAR.
; THIS TEST WILL ONLY EXECUTE IF STAGGERED LOOPBACK MODE IS SELECTED.
; THE SPECIAL STAGGERED LOOPBACK CONNECTOR MUST BE FITTED.
;*****
      BGNTST
      CMPB LOPBCK,#2      ;CHECK MODE SELECTED.      T5::
      BEQ  .+6            ;DO NOT EXIT IF STAGGERD LOPBCK MODE SELECTED.
      JMP  60#           ;EXIT THIS TEST.
      SETPRI @PRI05      ;ALLOW LTC INTERRUPTS.
                               MOV @PRI05,R0
                               TRAP C@SPRI
      TNUM == TNUM + 1    ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
      MOV @TNUM,TSTNUM   ;SET UP THE TEST NUMBER.      (49)
      MOV @-1,CTRLCF     ;INDICATE THAT WE ARE IN A TEST.
      MOV @1,ERRTYP      ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
      MOV @4901,ERRNBR   ;SET ERROR NUMBER TO 4901.
      MOV @EM4901,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
      MOV @ER9101,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
;
; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
; THIS SUBROUTINE REPORTS ERROR >>>> 4901 <<<<<.
;
      JSR PC,CLRST      ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
      BCS .+6          ;DO NOT EXIT IF RESET WAS SUCCESSFUL.
      JMP  60#         ;EXIT THIS TEST.
;
; SET-UP THE ASSOCIATED TX/RX LINE NUMBER TABLES.
;
      JSR PC,ASLNTL     ;INITIALISE THE ASSOCIATED TX/RX TABLES.
;
; SET EXTERNAL LOOPBACK, DISABLE OAUTO AND ENABLE RECEIVER ON ALL ACTIVE LINES.
; SET LPR ON ALL LINES TO 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY,
; 2 STOP BITS.
; ENABLE TRANSMITTERS ON ALL LINES.
;
      MOV ACTLNS,R5     ;PASS THE ACTIVE LINE BIT MAP.
      MOV @4,R0         ;PASS THE LNCTRL CONTENTS.
      JSR PC,WTLNLC     ;INITIALISE THE LNCTRL REGISTERS.
      MOV @MAPLNS,R5   ;PASS BIT MAP OF ALL LINES.
      MOV @177670,R0   ;PASS THE LPR CONTENTS.
      JSR PC,WTLPR     ;INITIALISE THE LPR REGISTERS ON ALL LINES.
      JSR PC,TXENBL    ;ENABLE TRANSMITTERS ON ALL LINES.
;
; SET UP OUTER LOOP FOR TESTING ACTIVE LINES IN BOTH LINE GROUPS.
;
      MOV @100000,R3    ;SET-UP LOOP CONTROL FLAG.
      MOV ACTLNS,R5    ;GET THE ACTIVE LINE BIT MAP.
      BIC LGRP2M,R5    ;REMOVE LINES IN GROUP 2.
    
```

```

5430 023050 010567 000404      2:  MOV    R5,45:      ;SAVE THE CURRENT LINE GROUP.
5431 023054 005067 000376      CLR    40:      ;CLEAR THE LINE NUMBER COUNTER.
5432 023060 016701 000372      4:  MOV    40:,R1    ;COPY THE LINE NUMBER.
5433 023064 000241      CLC      ;CLEAR CARRY BIT PRIOR TO SHIFTING BIT MAP.
5434 023066 006005      ROR     R5      ;SHIFT ACTIVE LINE BIT MAP INTO CARRY BIT.
5435 023070 103064      BCC     8:      ;SKIP TESTING THIS LINE IF IT IS INACTIVE.
5436
5437      ;
5438      ; TEST THE STATE OF THE OAUTO BIT ON THE LINE UNDER TEST.
5439      ; REPORT ERROR IF IT IS FOUND SET, AND SKIP FURTHER TESTING OF THAT LINE.
5440 023072 012767 011446 160752      MOV    #4902.,ERRNBR ;SET THE ERROR NUMBER TO 4902.
5441 023100 010177 157122      MOV    R1,@CSRA    ;SELECT THE LINE TO BE TESTED.
5442 023104 032777 000020 157124      BIT    @BIT4,@LNCTRA ;TEST THE STATE OF THE OAUTO BIT.
5443 023112 001410      BEQ     6:      ;SKIP ERROR REPORT IF OAUTO BIT IS CLEAR.
5444 023114 012702 005760      MOV    @EM4902,R2  ;PASS THE ERROR MESSAGE.
5445
5446 023120      ERROR      ; "OAUTO BIT BAD ON LINE NN"
5447 023120 104460      ; >>>> ERROR #4902 <<<<<.
5448                                     TRAP    C:ERROR
5449
5450      ;
5451      ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
5452 023122 032767 000100 157060      BIT    @BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
5453 023130 001556      BEQ     60:     ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
5454                                     ;DURING THE SOFTWARE QUESTIONS.
5455 023132 000443      BR     8:      ;SKIP FURTHER TESTING OF THIS LINE.
5456
5457      ;
5458      ; TRANSMIT THE XOFF (ASCII DC3) ON THE ASSOCIATED LINE.
5459 023134 116177 004010 157064 6:  MOVB   TXRLNB(R1),@CSRA ;SELECT THE ASSOCIATED TX LINE.
5460 023142 112777 000023 157064      MOVB   @23,@FDATA  ;TRANSMIT THE XOFF CHARACTER TO THE LUT.
5461
5462      ;
5463      ; WAIT FOR TRANSMISSION TO COMPLETE.
5464 023150 005267 160676      INC    ERRNBR     ;INCREMENT ERROR NUMBER TO 4903.
5465 023154 012701 170012      MOV    @170012,R1 ;TEST BIT 15, TIMEOUT OF 10 MILLI SECS.
5466 023160 016702 157042      MOV    CSRA,R2   ;PASS THE ADDRESS OF THE REGISTER TO TEST.
5467 023164 004767 174246      JSR    PC,WAIBIS ;WAIT FOR TRANSMISSION TO COMPLETE.
5468 023170 103134      BCC     50:     ;ABORT TEST IF TIMEOUT OCCURRED.
5469 023172 012704 000005      MOV    @5,R4     ;PASS TIME-OUT OF 5 MILLI SECS.
5470 023176 004767 171060      JSR    PC,DELAY  ;WAIT FOR CHAR TO BE RECEIVED AND PROCESSED.
5471
5472      ;
5473      ; TEST THE STATE OF THE TX_ENABLE BIT ON THE LINE UNDER TEST.
5474      ; REPORT ERROR IF TX_ENABLE BIT IS CLEAR.
5475 023202 005267 160644      INC    ERRNBR     ;INCREMENT ERROR NUMBER TO 4904.
5476 023206 016701 000244      MOV    40:,R1    ;GET THE NUMBER OF THE LINE TEST.
5477 023212 010177 157010      MOV    R1,@CSRA  ;SELECT THE LINE CURRENTLY UNDER TEST.
5478 023216 005777 157020      TST    @TXAD2A   ;TEST THE STATE OF THE TX_ENABLE BIT.
5479 023222 100407      BMI     8:      ;SKIP ERROR REPORT IF BIT IS SET.
5480 023224 012702 005760      MOV    @EM4902,R2 ;PASS THE MESSAGE TO BE REPORTED.
5481
5482 023230      ERROR      ; "OAUTO BIT BAD ON LINE NN".
5483 023230 104460      ; >>>> ERROR #4904 <<<<<.
5484                                     TRAP    C:ERROR

```



```

5485 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
5486 ;
5487 023232 032767 000100 156750 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
5488 023240 001512 BEQ 60# ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
5489 ;DURING THE SOFTWARE QUESTIONS.
5490
5491 023242 005267 000210 8# INC 40# ;INCREMENT THE LINE NUMBER,
5492 023246 005705 TST R5 ;CHECK IF THERE ARE ANY MORE LINES TO TEST.
5493 023250 001303 BNE 4# ;
5494
5495 ;*
5496 ; DISABLE TRANSMITTERS ON THE SELECTED LINES IN THE CURRENT LINE GROUP.
5497 023252 016705 000202 MOV 45#,R5 ;RESTORE THE CURRENT LINE ACTIVE LINE GROUP.
5498 023256 004767 173544 JSR PC,TXDSBL ;DISABLE TRANSMITTERS ON THE SELECTED LINES.
5499 023262 016705 000172 MOV 45#,R5 ;GET THE CURRENT ACTIVE LINE GROUP AGAIN.
5500 023266 005067 000164 CLR 40# ;CLEAR THE LINE COUNTER.
5501 023272 012767 011451 160552 10# MOV #4905,ERRNBR ;SET ERROR NUMBER TO 4905.
5502 023300 016701 000152 MOV 40#,R1 ;COPY THE LINE NUMBER.
5503 023304 000241 CLC ;CLEAR CARRY BIT PRIOR TO SHIFTING BIT MAP.
5504 023306 006005 ROR R5 ;SHIFT ACTIVE LINE BIT MAP INTO CARRY BIT.
5505 023310 103041 BCC 12# ;SKIP TESTING THIS LINE IF IT IS INACTIVE.
5506 ;*
5507 ; TRANSMIT THE XON (ASCII DC1) ON THE ASSOCIATED LINE.
5508 ;
5509 023312 116177 004010 156706 MOVB TXRLNB(R1),@CSRA ;SELECT THE ASSOCIATED TX LINE.
5510 023320 112777 000021 156706 MOVB #21,@FDATA ;TRANSMIT THE XON CHARACTER TO THE LUT.
5511 ;*
5512 ; WAIT FOR TRANSMISSION TO COMPLETE.
5513 ;
5514 023326 012701 170012 MOV #170012,R1 ;TEST BIT 15, TIMEOUT OF 10 MILLI SECS.
5515 023332 016702 156670 MOV CSRA,R2 ;PASS THE ADDRESS OF THE REGISTER TO TEST.
5516 023336 004767 174074 JSR PC,WAIBIS ;WAIT FOR TRANSMISSION TO COMPLETE.
5517 023342 103047 BCC 50# ;ABORT TEST IF TIMEOUT OCCURRED.
5518 023344 012704 000005 MOV #5,R4 ;PASS TIME-OUT OF 5 MILLI SECS.
5519 023350 004767 170706 JSR PC,DELAY ;WAIT FOR CHAR TO BE RECEIVED AND PROCESSED.
5520 ;*
5521 ; TEST THE STATE OF THE TX_ENABLE BIT ON THE LINE UNDER TEST.
5522 ; REPORT ERROR IF TX_ENABLE BIT IS SET.
5523 ;
5524 023354 005267 160472 INC ERRNBR ;INCREMENT ERROR NUMBER TO 4906.
5525 023360 016701 000072 MOV 40#,R1 ;GET THE NUMBER OF THE LINE UNDER TEST.
5526 023364 010177 156636 MOV R1,@CSRA ;SELECT THE LINE CURRENTLY UNDER TEST.
5527 023370 005777 156646 TST @TXAD2A ;TEST THE STATE OF THE TX_ENABLE BIT.
5528 023374 100007 BPL 12# ;SKIP ERROR REPORT IF BIT IS CLEAR.
5529 023376 012702 005760 MOV #EM4902,R2 ;PASS THE MESSAGE TO BE REPORTED.
5530 ; "OAUTO BIT BAD ON LINE NN".
5531 023402 ERROR ; >>>> ERROR #4906 <<<<<.
5532 023402 104460 TRAP C#ERROR
5533 ;*
5534 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
5535 ;
5536 023404 032767 000100 156576 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
5537 023412 001425 BEQ 60# ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
5538 ;DURING THE SOFTWARE QUESTIONS.
5539
5540 023414 005267 000036 12# INC 40# ;INCREMENT THE LINE NUMBER,

```

```

5541 023420 005705
5542 023422 001323
5543
5544
5545
5546
5547
5548 023424 005703
5549 023426 001417
5550 023430 005003
5551 023432 012705 177777
5552 023436 004767 173460
5553 023442 016705 156552
5554 023446 046705 156606
5555 023452 000167 177372
5556
5557 023456 000000
5558 023460 000000
5559 023462 004767 173204
5560 023466 005067 156556
5561
5562 023472
    023472
    023472 104401
    
```

```

TST R5 ;CHECK IF THERE ARE ANY MORE LINES TO TEST.
BNE 104 ;
;
; CHECK LOOP CONTROL FLAG TO DETERMINE IF BOTH SETS OF LINES HAVE BEEN TESTED
; IF THIS IS THE FIST TIME AROUND, RE-ENABLE TX ON ALL LINES, GENERATE ACTIVE
; BIT MAP FOR SECOND LINE GROUP.
;
TST R3 ;HAVE BOTH LINE GROUPS BEEN TESTED?.
BEQ 604 ;YES; THEN EXIT THIS TEST.
CLR R3 ;NO; CLEAR THE LOOP CONTROL FLAG.
MOV #MAPLNS,R5 ;PASS THE BIT MAP OF ALL AVAILABLE LINE.
JSR PC, TXENBL ;RE-ENABLE TRANSMISSION ON ALL LINES.
MOV ACTLNS,R5 ;GET THE ACTIVE LINE BIT MAP.
BIC LGRP1M,R5 ;REMOVE ALL ACTIVE LINES IN GROUP 1.
JMP 24 ;ONCE MORE AROUND AND WE ARE DONE.

404: .WORD 0 ;STORAGE FOR CURRENT LINE NUMBER.
454: .WORD 0 ;STORAGE FOR CURRENT ACTIVE LINE BIT MAP.
504: JSR PC, TSABRT ;REPORT TEST ABORTED. NON-TEST RELATED ERROR.
604: CLR CTRLCF ;INDICATE THAT WE ARE NOT WITHIN A TEST.

ENDTST
    
```

L10032: TRAP C\$ETST



5564  
 5565  
 5566  
 5567  
 5568  
 5569  
 5570  
 5571  
 5572  
 5573  
 5574  
 5575  
 5576 023474  
 023474  
 5577 023474 126727 156522 000002  
 5578 023502 001402  
 5579 023504 000167 000556  
 5580 023510  
 023510 012700 000240  
 023514 104441  
 5581 000006  
 5582 023516 012767 000006 156530  
 5583 023524 012767 177777 156516  
 5584 023532 012767 000001 160310  
 5585 023540 012767 011611 160304  
 5586 023546 012767 006012 160300  
 5587 023554 012767 013136 160274  
 5588  
 5589  
 5590  
 5591  
 5592  
 5593 023562 004767 170430  
 5594 023566 103402  
 5595 023570 000167 000472  
 5596  
 5597  
 5598  
 5599 023574 004767 167642  
 5600  
 5601  
 5602  
 5603  
 5604  
 5605  
 5606 023600 016705 156414  
 5607 023604 012700 000024  
 5608 023610 004767 173736  
 5609 023614 012705 177777  
 5610 023620 012700 177670  
 5611 023624 004767 173752  
 5612 023630 004767 173266  
 5613  
 5614  
 5615  
 5616 023634 012703 100000  
 5617 023640 016705 156354

```

.SBTTL  HARDWARE TEST          - OAUTOA -
:*****
:
:   - OAUTO BIT ACTIVE TEST -
:
:   THIS TEST VERIFIES THAT THE DUT'S OAUTO FUNCTION BEHAVES CORRECTLY
:   WHEN ACTIVE, IE OAUTO BIT ASSERTED HIGH.
:   THIS TEST WILL ONLY EXECUTE IF THE STAGGERED LOOPBACK MODE IS SELECTED.
:   THE SPECIAL STAGGERED LOOPBACK CONNECTOR MUST BE FITTED.
:*****
:
:   BGNTST
:
:   CMPB  LOPBCK,#2          ;CHECK MODE SELECTED.          TG::
:   BEQ   .+6                ;DO NOT EXIT IF STAGGERD LOPBCK MODE SELECTED.
:   JMP   60$                ;EXIT THIS TEST.
:   SETPRI @PRI05           ;ALLOW LTC INTERRUPTS.
:
:   MOV   @PRI05,R0          ;
:   TRAP  C$SPRI            ;
:   TNUM == TNUM + 1        ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
:   MOV   @TNUM,TSTNUM      ;SET UP THE TEST NUMBER.          (50)
:   MOV   @-1,CTRLCF        ;INDICATE THAT WE ARE IN A TEST.
:   MOV   @1,ERRTYP         ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
:   MOV   @5001,ERRNBR      ;SET ERROR NUMBER TO 5001.
:   MOV   @EM5001,ERRMSG    ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
:   MOV   @ER9101,ERRBLK    ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
:
:   ; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
:   ; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
:   ; THIS SUBROUTINE REPORTS ERROR >>>> 5001 <<<<.
:
:   JSR   PC,CLRST          ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
:   BCS   .+6                ;DO NOT EXIT IF RESET WAS SUCCESSFUL.
:   JMP   60$                ;EXIT THIS TEST.
:
:   ; SET-UP THE ASSOCIATED TX/RX LINE NUMBER TABLES.
:
:   JSR   PC,ASLNTL         ;INITIALISE THE ASSOCIATED TX/RX TABLES.
:
:   ; SET EXTERNAL LOOPBACK,ENABLE OAUTO AND RECEIVER FUNCTIONS ON ALL ACTIVE LINES
:   ; SET LPR ON ALL LINES TO 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY,
:   ; 2 STOP BITS.
:   ; ENABLE TRANSMITTERS ON ALL LINES.
:
:   MOV   ACTLNS,R5         ;PASS THE ACTIVE LINE BIT MAP.
:   MOV   @24,R0            ;PASS THE LNCTRL CONTENTS.
:   JSR   PC,WTMLNC        ;INITIALISE THE LNCTRL REGISTERS.
:   MOV   @MAPLNS,R5       ;PASS BIT MAP OF ALL LINES.
:   MOV   @177670,R0       ;PASS THE LPR CONTENTS.
:   JSR   PC,WTMLPR        ;INITIALISE THE LPR REGISTERS ON ALL LINES.
:   JSR   PC,TXENBL        ;ENABLE TRANSMITTERS ON ALL LINES.
:
:   ; SET UP OUTER LOOP FOR TESTING ACTIVE LINES IN BOTH LINE GROUPS.
:
:   MOV   @100000,R3        ;SET-UP LOOP CONTROL FLAG.
:   MOV   ACTLNS,R5         ;GET THE ACTIVE LINE BIT MAP.
    
```

G12

```

5618 023644 046705 156412
5619 023650 010567 000404
5620 023654 005067 000376
5621 023660 016701 000372
5622 023664 000241
5623 023666 006005
5624 023670 103064
5625
5626
5627
5628
5629 023672 012767 011612 160152
5630 023700 010177 156322
5631 023704 032777 000020 156324
5632 023712 001010
5633 023714 012702 005760
5634
5635 023720
023720 104460
5636
5637
5638
5639
5640 023722 032767 000100 156260
5641 023730 001556
5642
5643
5644 023732 000443
5645
5646
5647
5648 023734 116177 004010 156264
5649 023742 112777 000023 156264
5650
5651
5652
5653 023750 005267 160076
5654 023754 012701 170012
5655 023760 016702 156242
5656 023764 004767 173446
5657 023770 103134
5658 023772 012704 000005
5659 023776 004767 170260
5660
5661
5662
5663
5664 024002 005267 160044
5665 024006 016701 000244
5666 024012 010177 156210
5667 024016 005777 156220
5668 024022 100007
5669 024024 012702 005760
5670
5671 024030
024030 104460
5672

; BIC LGRP2M,R5 ;REMOVE LINES IN GROUP 2.
; MOV R5,45$ ;SAVE THE CURRENT LINE GROUP.
; CLR 40$ ;CLEAR THE LINE NUMBER COUNTER.
; MOV 40$,R1 ;COPY THE LINE NUMBER.
; CLC ;CLEAR CARRY BIT PRIOR TO SHIFTING BIT MAP.
; ROR R5 ;SHIFT ACTIVE LINE BIT MAP INTO CARRY BIT.
; BCC 8$ ;SKIP TESTING THIS LINE IF IT IS INACTIVE.

; TEST THE STATE OF THE OAUTO BIT ON THE LINE UNDER TEST.
; REPORT ERROR IF IT IS FOUND CLEAR, AND SKIP FURTHER TESTING OF THAT LINE.

; MOV #5002,ERRNBR ;SET THE ERROR NUMBER TO 5002.
; MOV R1,@CSRA ;SELECT THE LINE TO BE TESTED.
; BIT @BIT4,@LNCTRA ;TEST THE STATE OF THE OAUTO BIT.
; BNE 6$ ;SKIP ERROR REPORT IF OAUTO BIT IS SET.
; MOV @EM4902,R2 ;PASS THE ERROR MESSAGE.
; ERROR ; "OAUTO BIT BAD ON LINE NN"
; >>>> ERROR #5002 <<<<<.
; TRAP C$ERROR

; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED

; BIT @BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
; BEQ 60$ ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
; DURING THE SOFTWARE QUESTIONS.

; BR 8$ ;SKIP FURTHER TESTING OF THIS LINE.

; TRANSMIT THE XOFF (ASCII DC3) ON THE ASSOCIATED LINE.

; MOVB TXRLNB(R1),@CSRA ;SELECT THE ASSOCIATED TX LINE.
; MOVB @23,@FDATA ;TRANSMIT THE XOFF CHARACTER TO THE LUT.

; WAIT FOR TRANSMISSION TO COMPLETE.

; INC ERRNBR ;INCREMENT ERROR NUMBER TO 5003.
; MOV #170012,R1 ;TEST BIT 15, TIMEOUT OF 10 MILLI SECS.
; MOV CSRA,R2 ;PASS THE ADDRESS OF THE REGISTER TO TEST.
; JSR PC,WAIBIS ;WAIT FOR TRANSMISSION TO COMPLETE.
; BCC 50$ ;ABORT TEST IF TIMEOUT OCCURRED.
; MOV #5,R4 ;PASS TIME-OUT OF 5 MILLI SECS.
; JSR PC,DELAY ;WAIT FOR CHAR TO BE RECEIVED AND PROCESSED.

; TEST THE STATE OF THE TX_ENABLE BIT ON THE LINE UNDER TEST.
; REPORT ERROR IF TX_ENABLE BIT IS SET.

; INC ERRNBR ;INCREMENT ERROR NUMBER TO 5004.
; MOV 40$,R1 ;GET THE NUMBER OF THE LINE TEST.
; MOV R1,@CSRA ;SELECT THE LINE CURRENTLY UNDER TEST.
; TST @TXAD2A ;TEST THE STATE OF THE TX_ENABLE BIT.
; BPL 8$ ;SKIP ERROR REPORT IF BIT IS CLEAR.
; MOV @EM4902,R2 ;PASS THE MESSAGE TO BE REPORTED.
; ERROR ; "OAUTO BIT BAD ON LINE NN"
; >>>> ERROR #5004 <<<<<.
; TRAP C$ERROR
    
```



```

5673
5674
5675
5676 024032 032767 000100 156150
5677 024040 001512
5678
5679
5680 024042 005267 000210 8$:
5681 024046 005705
5682 024050 001303
5683
5684
5685
5686 024052 016705 000202
5687 024056 004767 172744
5688 024062 016705 000172
5689 024066 005067 000164
5690 024072 012767 011615 157752 10$:
5691 024100 016701 000152
5692 024104 000241
5693 024106 006005
5694 024110 103041
5695
5696
5697
5698 024112 116177 004010 156106
5699 024120 112777 000021 156106
5700
5701
5702
5703 024126 012701 170012
5704 024132 016702 156070
5705 024136 004767 173274
5706 024142 103047
5707 024144 012704 000005
5708 024150 004767 170106
5709
5710
5711
5712
5713 024154 005267 157672
5714 024160 016701 000072
5715 024164 010177 156036
5716 024170 005777 156046
5717 024174 100407
5718 024176 012702 005760
5719
5720 024202
024202 104460
5721
5722
5723
5724
5725 024204 032767 000100 155776
5726 024212 001425
5727
5728

```

```

; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
;
; BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
; BEQ 60$ ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
; ;DURING THE SOFTWARE QUESTIONS.
;
; INC 40$ ;INCREMENT THE LINE NUMBER,
; TST R5 ;CHECK IF THERE ARE ANY MORE LINES TO TEST.
; BNE 4$ ;
;
; DISABLE TRANSMITTERS ON THE SELECTED LINES IN THE CURRENT LINE GROUP.
;
; MOV 45$,R5 ;RESTORE THE CURRENT LINE ACTIVE LINE GROUP.
; JSR PC, TXDSBL ;DISABLE TRANSMITTERS ON THE SELECTED LINES.
; MOV 45$,R5 ;GET THE CURRENT LINE ACTIVE LINE GROUP AGAIN.
; CLR 40$ ;CLEAR THE LINE COUNTER.
; MOV #5005.,ERRNBR ;SET ERROR NUMBER TO 5005.
; MOV 40$,R1 ;COPY THE LINE NUMBER.
; CLC ;CLEAR CARRY BIT PRIOR TO SHIFTING BIT MAP.
; ROR R5 ;SHIFT ACTIVE LINE BIT MAP INTO CARRY BIT.
; BCC 12$ ;SKIP TESTING THIS LINE IF IT IS INACTIVE.
;
; TRANSMIT THE XON (ASCII DC1) ON THE ASSOCIATED LINE.
;
; MOVB TXRLNB(R1),@CSRA ;SELECT THE ASSOCIATED TX LINE.
; MOVB #21,@FDATA ;TRANSMIT THE XON CHARACTER TO THE LUT.
;
; WAIT FOR TRANSMISSION TO COMPLETE.
;
; MOV #170012,R1 ;TEST BIT 15, TIMEOUT OF 10 MILLI SECS.
; MOV CSRA,R2 ;PASS THE ADDRESS OF THE REGISTER TO TEST.
; JSR PC,WAIBIS ;WAIT FOR DMA TO COMPLETE.
; BCC 50$ ;ABORT TEST IF TIMEOUT OCCURRED.
; MOV #5,R4 ;PASS TIME-OUT OF 5 MILLI SECS.
; JSR PC,DELAY ;WAIT FOR CHAR TO BE RECEIVED AND PROCESSED.
;
; TEST THE STATE OF THE TX_ENABLE BIT ON THE LINE UNDER TEST.
; REPORT ERROR IF TX_ENABLE BIT IS CLEAR.
;
; INC ERRNBR ;INCREMENT ERROR NUMBER TO 5006.
; MOV 40$,R1 ;GET THE NUMBER OF THE LINE UNDER TEST.
; MOV R1,@CSRA ;SELECT THE LINE CURRENTLY UNDER TEST.
; TST @TXAD2A ;TEST THE STATE OF THE TX_ENABLE BIT.
; BHI 12$ ;SKIP ERROR REPORT IF BIT IS SET.
; MOV #EM4902,R2 ;PASS THE MESSAGE TO BE REPORTED.
; ERROR ; "OAUTO BIT BAD ON LINE NN".
; ; >>>> ERROR #5006 <<<<<.
; ; TRAP C$ERROR
;
; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
;
; BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
; BEQ 60$ ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
; ;DURING THE SOFTWARE QUESTIONS.

```

```
5729 024214 005267 000036      12$:      INC      40$      ;INCREMENT THE LINE NUMBER,  
5730 024220 005705                TST      R5      ;CHECK IF THERE ARE ANY MORE LINES TO TEST.  
5731 024222 001323                BNE      10$      ;  
5732  
5733  
5734  
5735  
5736  
5737 024224 005703                ;*  
5738 024226 001417                ; CHECK LOOP CONTROL FLAG TO DETERMINE IF BOTH SETS OF LINES HAVE BEEN TESTED  
5739 024230 005003                ; IF THIS IS THE FIST TIME AROUND, RE-ENABLE TX ON ALL LINES, GENERATE ACTIVE  
5740 024232 012705 177777                ; BIT MAP FOR SECOND LINE GROUP.  
5741 024236 004767 172660                ;-  
5742 024242 016705 155752                TST      R3      ;HAVE BOTH LINE GROUPS BEEN TESTED?.  
5743 024246 046705 156006                BEQ      60$      ;YES; THEN EXIT THIS TEST.  
5744 024252 000167 177372                CLR      R3      ;NO; CLEAR THE LOOP CONTROL FLAG,  
5745  
5746 024256 000000                MOV      @MAPLNS,R5 ;PASS THE BIT MAP OF ALL AVAILABLE LINE.  
5747 024260 000000                JSR      PC, TXENBL ;RE-ENABLE TRANSMISSION ON ALL LINES.  
5748 024262 004767 172404                MOV      ACTLNS,R5 ;GET THE ACTIVE LINE BIT MAP.  
5749 024266 005067 155756                BIC      LGRP1M,R5 ;REMOVE ALL ACTIVE LINES IN GROUP 1.  
5750  
5751 024272                JMP      2$      ;ONCE MORE AROUND AND WE ARE DONE.  
5751 024272                ;  
5751 024272                40$:      .WORD    0      ;STORAGE FOR CURRENT LINE NUMBER.  
5751 024272                45$:      .WORD    0      ;STORAGE FOR CURRENT ACTIVE LINE BIT MAP.  
5751 024272                50$:      JSR      PC, TSABRT ;REPORT TEST ABORTED, NON-TEST RELATED ERROR.  
5751 024272                60$:      CLR      CTRLCF ;INDICATE THAT WE ARE NOT WITHIN A TEST.  
5751 024272                ENDTST  
024272 104401  
L10033: TRAP C$ETST
```



5753  
 5754  
 5755  
 5756  
 5757  
 5758  
 5759  
 5760  
 5761  
 5762  
 5763  
 5764  
 5765  
 5766  
 5767  
 5768  
 5769  
 5770  
 5771 024274  
 024274  
 5772 024274  
 024274 012700 000240  
 024300 104441  
 5773 000007  
 5774 024302 012767 000007 155744  
 5775 024310 012767 177777 155732  
 5776 024316 012767 000001 157524  
 5777 024324 012767 011755 157520  
 5778 024332 012767 006051 157514  
 5779 024340 012767 013136 157510  
 5780  
 5781  
 5782  
 5783  
 5784  
 5785 024346 004767 167644  
 5786 024352 103156  
 5787  
 5788  
 5789  
 5790  
 5791  
 5792  
 5793 024354 004767 170220  
 5794  
 5795  
 5796  
 5797  
 5798 024360 016705 155634  
 5799 024364 012700 000204  
 5800 024370 004767 173156  
 5801 024374 012700 177670  
 5802 024400 004767 173176  
 5803 024404 012704 000012  
 5804 024410 004767 167646  
 5805  
 5806

```

.SBTTL  HARDWARE TEST          - IAUTOI -
:*****
:
:          - IAUTO BIT INACTIVE TEST -
:
: THIS TEST VERIFIES THAT THE DUT'S IAUTO FUNCTION BEHAVES CORRECTLY
: WHEN INACTIVE, IE. IAUTO BIT CLEAR.
: ALL ACTIVE LINES ARE TESTED INDIVIDUALLY BY FILLING THE FIFO
: THEN READING THE RECEIVED DATA CHECKING FOR THE PRESENCE OF
: XOFF(ASCII DC3) OR XON (ASCII DC1) CHARACTERS.
: IF ANY ARE FOUND THEN APPROPRIATE ERRORS ARE REPORTED.
: ANY BMP CODES THAT ARE FOUND WILL BE PLACED ON THE BMP CODE QUEUE.
: TO BE REPORTED LATER.
: THE CHARACTERS ARE TRANSMITTED ON ALL ACTIVE LINES, IN INTERNAL
: LOOPBACK MODE.
:*****
:-----
BGNTST
:
:          SETPRI  #PRI05          ;ALLOW LTC INTERRUPTS.          T7::
:
:          TNUM  ==  TNUM  + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
:          MOV   #TNUM,TSTNUM          ;SET UP THE TEST NUMBER.          (51)
:          MOV   #-1,CTRLCF          ;INDICATE THAT WE ARE IN A TEST.
:          MOV   #1,ERRTYP          ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
:          MOV   #5101.,ERRNBR        ;SET ERROR NUMBER TO 5101.
:          MOV   #EMS101,ERRMSG        ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
:          MOV   #ER9101,ERRBLK        ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
:
: *
: * RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
: * CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
: * THIS SUBROUTINE REPORTS ERROR >>>> 5101 <<<<.
:
:          JSR   PC,CLNRST          ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
:          BCC   601                ;EXIT TEST IF FATAL ERROR FOUND.
:
: *
: * INITIALIZE THE 256 BYTE DATA PATTERN.
: * ENSURE THE DATA PATTERN IS FREE FROM XON'S OR XOFF'S TO PREVENT ERRORS.
: * NOTE: THE FIRST TWO CHARACTERS AND THE LAST TWO CHARACTERS WILL BE THE SAME.
:
:          JSR   PC,INDTPX          ;INITIALISE DATA PATTERN.
:
: *
: * SET INTERNAL LOOPBACK, DISABLE IAUTO, ENABLE RECEIVER ON THE SELECTED LINE.
: * SET LPR TO 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
:
:          MOV   ACTLNS,R5          ;PASS THE ACTIVE LINE BIT MAP.
:          MOV   #204,R0            ;PASS INT'L LOPBCK, ENABLE RX, DISABLE IAUTO.
:          JSR   PC,WTWLNCR          ;INITIALISE THE LINE CONTROL REGISTER.
:          MOV   #177670,R0         ;PASS THE LPR CONTENTS.
:          JSR   PC,WTWLPR          ;SET THE LPR CONTENTS TO 38.4K BAUD.
:          MOV   #10.,R4            ;PASS DELAY TIME OF 10 MILLI SECONDS.
:          JSR   PC,DELAY           ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
:
: *
    
```

```

5807      ; SET UP LOOP FOR ALL ACTIVE LINES.
5808      ; TEST THE STATE OF THE IAUTO BIT PRIOR TO TRANSMITTING THE DATA PATTERN.
5809      ; IF THE BIT IS SET, THEN REPORT THE ERROR AND SKIP TRANSMITTING
5810      ; THE DATA PATTERN ON THE SELECTED LINE.
5811      ; TRANSMIT A 256 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
5812      ; EMPTY THE FIFO, AND VERIFY NO XOFF OR XON CHARS WERE FOUND.
5813      ;-
5814 024414 005001      CLR      R1      ;CLEAR THE LINE NUMBER COUNTER.
5815 024416 005067 000264  CLR      55$     ;CLEAR STORAGE FOR LINE NUMBER.
5816 024422 012767 011756 157422 2$:  MOV     #5102.,ERRNBR ;SET THE ERROR NUMBER TO 5102.
5817 024430 004767 170734      JSR     PC,PUFIFO  ;PURGE THE FIFO.
5818 024434 103121      BCC     50$     ;GO REPORT ERROR IF FIFO DID NOT PURGE.
5819 024436 000241      CLC      ;CLEAR CARRY PRIOR TO ROTATING BIT MAP.
5820 024440 006005      ROR     R5      ;ROTATE THE BIT MAP INTO THE CARRY BIT.
5821 024442 103107      BCC     12$     ;BRANCH IF LINE IS INACTIVE.
5822
5823      ;+
5824      ; TEST THE IAUTO BIT ON THE SELECTED ACTIVE LINE.
5825      ; REPORT ERROR IF IT IS SET.
5826      ; DO NOT TRANSMIT THE DATA PATTERN ON THE SELECTED LINE.
5827      ;-
5828 024444 005267 157402      INC     ERRNBR   ;SET ERROR NUMBER TO 5103.
5829 024450 010177 155552      MOV     R1,BCSRA ;SELECT LINE TO TEST.
5830 024462 001410 155554      BIT     #BIT1,BLNCTRA ;TEST THE STATE OF THE IAUTO BIT ON THIS LINE.
5831 024464 012702 006106      BEQ     4$      ;SKIP ERROR IF IAUTO BIT CLEAR.
5832 024470      MOV     #EM5102,R2 ;PASS THE CORRECT ERROR MESSAGE.
5833 024470 104460      ERROR      ;
5834                                     >>>> ERROR <<<<<.
5835                                     TRAP   C$ERROR
5836
5837      ;+
5838      ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
5839      ;-
5840 024472 032767 000100 155510  BIT     #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
5841 024500 001503      BEQ     60$     ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
5842                                     ;DURING THE SOFTWARE QUESTIONS.
5843
5844      BR      12$     ;SKIP TRANSMITTING DATA PATTERN.
5845
5846      ;+
5847      ; TRANSMIT DATA PATTERN OF 256 CHARS.
5848      ;-
5849 024504 005267 157342 4$:  INC     ERRNBR   ;SET ERROR NUMBER TO 5104.
5850 024510 012702 002650      MOV     #BUFBAS,R2 ;PASS THE START OF THE DATA PATTERN TO TX.
5851 024514 012703 000400      MOV     #256.,R3  ;PASS THE LENGTH OF THE DATA PATTERN.
5852 024520 004767 167654      JSR     PC,DODMA  ;TRANSMIT THE DATA PATTERN.
5853      BCC     50$     ;ABORT THE TEST IF ERROR FOUND DURING DMA TX.
5854
5855      ;+
5856      ; WAIT FOR DMA TO COMPLETE, THEN WAIT FOR THE LAST CHARACTER PLUS XOFF
5857      ; TO ARRIVE IN THE FIFO.
5858      ;-
5859 024526 005267 157320      INC     ERRNBR   ;SET ERROR NUMBER TO 5105.
5860 024532 012701 170536      MOV     #170536,R1 ;PASS TIME-OUT VALUE OF 350 MILLI SECS.
5861 024536 016702 155464      MOV     CSRA,R2  ;PASS THE ADDRESS OF THE CSR.
5862 024542 004767 172670      JSR     PC,WAIBIS ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
5863 024546 103054      BCC     50$     ;IF NO TX_ACTION WAS RECEIVED, ABORT THE TEST.
5864 024550 012704 000012      MOV     #10.,R4  ;PASS DELAY OF 10 MILLI SECS.
5865 024554 004767 167502      JSR     PC,DELAY  ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
    
```



```

5863
5864
5865
5866
5867
5868 024560 005267 157266
5869 024564 012701 000400
5870 024570 017702 155434
5871 024574 100041
5872
5873
5874
5875 024576 012700 170301
5876 024602 040200
5877 024604 001002
5878 024606 004767 171666
5879
5880
5881
5882 024612 120227 000023
5883 024616 001406
5884 024620 120227 000021
5885 024624 001403
5886 024626 005301
5887 024630 001357
5888 024632 000413
5889
5890 024634 005267 157212
5891 024640 016701 000042
5892 024644 012702 006144
5893 024650
      024650 104460
5894
5895
5896
5897
5898 024652 032767 000100 155330
5899 024660 001413
5900
5901
5902
5903
5904 024662 005267 000020
5905 024666 016701 000014
5906 024672 005705
5907 024674 001252
5908 024676 000404
5909
5910 024700 004767 171766
5911 024704 000401
5912 024706 000000
5913 024710 005067 155334
5914
5915 024714
      024714
      024714 104401

;+
; READ 256 CHARS FROM THE FIFO. REPORT ERROR IF ANY XOFF'S OR XON'S
; ARE FOUND.
;-
      INC ERRNBR ;INCREMENT ERROR NUMBER TO 5106.
      MOV #256,R1 ;INITIALISE THE READ COUNTER.
6$:   MOV @RBUFA,R2 ;READ CHAR FROM THE FIFO.
      BPL 50$ ;GO REPORT ERROR IF FIFO EMPTY.
;+
; CHECK FOR BMP CODE IN THE FIFO. SAVE ANY FOUND ON THE QUEUE.
;-
      MOV #170301,R0 ;SET UP BMP BIT MASK.
      BIC R2,R0 ;TRY TO CLEAR ALL THE BMP BITS.
      BNE 8$ ;SKIP BMPSAV IF NOT A BMP CODE.
      JSR PC,SAVBMP ;SAVE THE BMP CODE ON THE QUEUE.
;+
; CHECK FOR XOFF AND XON CHARACTERS.
;-
8$:   CMPB R2,#23 ;IS IT AN XOFF CHARACTER?.
      BEQ 10$ ;YES; GO REPORT ERROR.
      CMPB R2,#21 ;NO; IS IT AN XON CHARACTER?.
      BEQ 10$ ;YES; GO REPORT ERROR.
      DEC R1 ;DECREMENT THE READ COUNT.
      BNE 6$ ;LOOP TO READ THE NEXT CHAR.
      BR 12$ ;GO CHECK FOR ANY UNTESTED ACTIVE LINES.
10$:  INC ERRNBR ;SET ERROR NUMBER TO 5107.
      MOV 55$,R1 ;PASS THE LINE NUMBER TO BE REPORTED.
      MOV #EM5103,R2 ;PASS THE ERROR MESSAGE TO BE REPORTED.
      ERROR ;
; >>>> ERROR <<<<<.
; TRAP C$ERROR

;+
; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
;-
      BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
      BEQ 60$ ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
; DURING THE SOFTWARE QUESTIONS.
;+
; CHECK IF ALL ACTIVE LINES HAVE BEEN TESTED.
;-
12$:  INC 55$ ;INCREMENT LINE NUMBER.
      MOV 55$,R1 ;GET NUMBER OF THE NEXT LINE TO TEST.
      TST R5 ;ARE THERE ANY MORE ACTIVE LINES TO TEST?.
      BNE 2$ ;LOOP TO CHECK NEXT LINE.
      BR 60$ ;EXIT TEST.
50$:  JSR PC,TSABRT ;REPORT TEST ABORTED. NON-TEST RELATED ERROR.
      BR 60$ ;EXIT THIS TEST.
55$:  .WORD 0 ;STORAGE FOR LINE NUMBER.
60$:  CLR CTRLCF ;INDICATE THAT WE ARE NOT WITHIN A TEST.

      ENDTST

L10034: TRAP C$ETST

```





```

5971 ; TEST THE STATE OF THE OAUTO BIT PRIOR TO TRANSMITTING THE DATA PATTERN.
5972 ; IF THE BIT IS CLEAR, THEN REPORT THE ERROR AND SKIP TRANSMITTING
5973 ; THE DATA PATTERN ON THE SELECTED LINE.
5974 ; TRANSMIT A 224 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
5975 ; EMPTY THE FIFO, AND COUNT THE XOFF AND AN XON CHARS FOUND.
5976 ;
5977 025042 005001          CLR R1          ;CLEAR THE LINE NUMBER COUNTER.
5978 025044 005067 000330 CLR 55$         ;CLEAR STORAGE FOR LINE NUMBER.
5979 025050 012767 012122 156774 2$: MOV #5202.,ERRNBR ;SET THE ERROR NUMBER TO 5202.
5980 025056 004767 170306 JSR PC,PUFIFO   ;PURGE THE FIFO.
5981 025062 103143        BCC 50$         ;GO REPORT ERROR IF FIFO DID NOT PURGE.
5982 025064 000241        CLC          ;CLEAR CARRY PRIOR TO ROTATING BIT MAP.
5983 025066 006005        ROR R5       ;ROTATE THE BIT MAP INTO THE CARRY BIT.
5984 025070 103131        BCC 16$     ;BRANCH IF LINE IS INACTIVE.
5985 ;
5986 ;+
5987 ; TEST THE IAUTO BIT ON THE SELECTED ACTIVE LINE.
5988 ; REPORT ERROR IF IT IS CLEAR.
5989 ; DO NOT TRANSMIT THE DATA PATTERN ON THE SELECTED LINE.
5990 025072 005267 156754          INC ERRNBR      ;SET ERROR NUMBER TO 5203.
5991 025076 010177 155124          MOV R1,CSRA    ;SELECT LINE TO TEST.
5992 025102 032777 000002 155126 BIT #BIT1,SLNCTRA ;TEST THE STATE OF THE IAUTO BIT ON THIS LINE.
5993 025110 001010          BNE 4$      ;SKIP ERROR IF IAUTO BIT SET.
5994 025112 012702 006227          MOV #EM5202.R2 ;PASS THE CORRECT ERROR MESSAGE.
5995 ;
5996 025116          ERROR          ; "IAUTO BIT FOUND CLEAR ON LINE NN"
5997 025116 104460          ; >>>> ERROR <<<<<.
5998 ;
5999 ;+
6000 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
6001 025120 032767 000100 155062 BIT #BIT06.OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
6002 025126 001525          BEQ 60$     ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
6003 ;
6004 ;
6005 025130 000511          BR 16$      ;SKIP TRANSMITTING DATA PATTERN.
6006 ;
6007 ;+
6008 ; TRANSMIT DATA PATTERN TO FILL THE FIFO, 223 CHARS + 32 XOFF'S + XON.
6009 ;
6010 025132 005267 156714          INC ERRNBR      ;SET ERROR NUMBER TO 5204.
6011 025136 012702 002650          MOV #BUFBAS,R2 ;PASS THE START OF THE DATA PATTERN TO TX.
6012 025142 012703 000337          MOV #223.,R3    ;PASS THE LENGTH OF THE DATA PATTERN.
6013 025146 004767 167226          JSR PC,DODMA   ;TRANSMIT THE DATA PATTERN.
6014 025152 103107          BCC 50$     ;ABORT THE TEST IF ERROR FOUND DURING DMA TX.
6015 ;
6016 ;+
6017 ; WAIT FOR DMA TO COMPLETE, THEN WAIT FOR THE LAST CHARACTER PLUS XOFF
6018 ; TO ARRIVE IN THE FIFO.
6019 ;
6020 025154 005267 156672          INC ERRNBR      ;SET ERROR NUMBER TO 5205.
6021 025160 012701 170454          MOV #170454,R1 ;PASS TIME-OUT VALUE OF 300 MILLI SECS.
6022 025164 016702 155036          MOV CSRA,R2    ;PASS THE ADDRESS OF THE CSR.
6023 025170 004767 172242          JSR PC,WAIBIS ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
6024 025174 103076          BCC 50$     ;IF NO TX_ACTION WAS RECEIVED, ABORT THE TEST.
6025 025176 012704 000012          MOV #10.,R4   ;PASS DELAY OF 10 MILLI SECS.
6026 025202 004767 167054          JSR PC,DELAY  ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
    
```

```

6027
6028
6029
6030
6031 025206 005003
6032 025210 005004
6033 025212 005267 156634
6034 025216 012701 000400
6035 025222 017702 155002
6036 025226 100061
6037
6038
6039
6040 025230 012700 170301
6041 025234 040200
6042 025236 001002
6043 025240 004767 171234
6044
6045
6046
6047 025244 120227 000023
6048 025250 001001
6049 025252 005203
6050 025254 120227 000021
6051 025260 001001
6052 025262 005204
6053 025264 005301
6054 025266 001412
6055
6056
6057
6058
6059 025270 020127 000176
6060 025274 001352
6061 025276 010400
6062
6063 025300 012704 000001
6064 025304 004767 166752
6065 025310 010004
6066 025312 000743
6067
6068
6069
6070
6071 025314 005703
6072 025316 001403
6073 025320 020427 000001
6074 025324 001413
6075 025326 005267 156520
6076 025332 016701 000042
6077 025336 012702 006144
6078
6079 025342
        025342 104460
6080
6081
6082

; READ 256 CHARS FROM THE FIFO. COUNT ANY XOFF OR XON CHARS FOUND.
;
; CLR R3 ;CLEAR XOFF COUNTER.
; CLR R4 ;CLEAR XON COUNTER.
; INC ERRNBR ;INCREMENT ERROR NUMBER TO 5206.
; MOV #256,R1 ;INITIALISE THE READ COUNTER.
; MOV BRBUFA,R2 ;READ CHAR FROM THE FIFO.
; BPL 501 ;GO REPORT ERROR IF FIFO EMPTY.
;
; CHECK FOR BMP CODE IN THE FIFO. SAVE ANY FOUND ON THE QUEUE.
;
; MOV #170301,R0 ;SET UP BMP BIT MASK.
; BIC R2,R0 ;TRY TO CLEAR ALL THE BMP BITS.
; BNE 81 ;SKIP BMP SAV IF NOT A BMP CODE.
; JSR PC,SAVBMP ;SAVE THE BMP CODE ON THE QUEUE.
;
; CHECK FOR XOFF AND XON CHARACTERS.
;
; CMPB R2,#23 ;IS IT AN XOFF CHARACTER?.
; BNE 101 ;NO, BRANCH TO SEE IF IT IS AN XON.
; INC R3 ;COUNT THE XOFF CHAR.
; CMPB R2,#21 ;IS IT AN XON CHARACTER?.
; BNE 121 ;NO, SKIP THE NEXT INSTRUCTION.
; INC R4 ;COUNT THE XON.
; DEC R1 ;DECREMENT THE READ COUNT.
; BEQ 131 ;BRANCH IF ALL CHARACTERS READ.
;
; CHECK IF THE FIFO HAS BEEN EMPTIED BELOW THE HALF LEVEL. IF IT
; HAS DELAY FOR 1MS TO ALLOW THE XON TO BE GENERATED.
;
; CMP R1,#126. ;IS THE FIFO LEVEL = 126 ?
; BNE 61 ;LOOP TO READ THE NEXT CHARACTER IF NOT.
; MOV R4,R0 ;SAVE THE XON COUNT, ALTHOUGH THERE SHOULDN'T
; BE ANY.
; MOV #1,R4 ;SET THE DELAY TO 1MS.
; JSR PC,DELAY ;PERFORM THE DELAY.
; MOV R0,R4 ;RESTORE THE XON COUNT.
; BR 61 ;LOOP TO READ THE NEXT CHAR.
;
; VERIFY THAT AT LEAST 1 XOFF AND 1 XON WAS FOUND IN THE FIFO.
; REPORT ERROR IF NONE WERE FOUND.
;
; TST R3 ;CHECK XOFF COUNT.
; BEQ 141 ;GO REPORT ERROR IF NONE FOUND.
; CMP R4,#1 ;CHECK XON COUNT = 1.
; BEQ 161 ;SKIP THE ERROR REPORT IF ONE XON WAS FOUND.
; INC ERRNBR ;SET ERROR NUMBER TO 5207.
; MOV 551,R1 ;PASS THE LINE NUMBER TO BE REPORTED.
; MOV #EM5103,R2 ;PASS THE ERROR MESSAGE TO BE REPORTED.
;
; ERROR ; "IAUTO BIT BAD ON LINE NN".
; >>>> ERROR <<<<<.
; TRAP C!ERROR
;
; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
    
```



```
6083
6084 025344 032767 000100 154636 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
6085 025352 001413 BEQ 60$ ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
6086 ;DURING THE SOFTWARE QUESTIONS.
6087
6088 ;
6089 ; CHECK IF ALL ACTIVE LINES HAVE BEEN TESTED.
6090 025354 005267 000020 16$: INC 55$ ;INCREMENT LINE NUMBER.
6091 025360 016701 000014 MOV 55$,R1 ;GET NUMBER OF THE NEXT LINE TO TEST.
6092 025364 005705 TST R5 ;ARE THERE ANY MORE ACTIVE LINES TO TEST?.
6093 025366 001230 BNE 2$ ;LOOP TO CHECK NEXT LINE.
6094 025370 000404 BR 60$ ;EXIT TEST.
6095
6096 025372 004767 171274 50$: JSR PC,TSABRT ;REPORT TEST ABORTED. NON-TEST RELATED ERROR.
6097 025376 000401 BR 60$ ;EXIT THIS TEST.
6098 025400 000000 55$: .WORD 0 ;STORAGE FOR LINE NUMBER.
6099 025402 005067 154642 60$: CLR CTRLCF ;INDICATE THAT WE ARE NOT WITHIN A TEST.
6100
6101 025406
025406
025406 104401

L10035: TRAP C8ETST
```

```

6103 .SBTTL  HARDWARE TEST          - FIFDAT -
6104 :*****
6105 : - FIFO VALID DATA TEST -
6106 :
6107 :
6108 : THIS TEST VERIFIES THAT THE DUT IS CAPABLE OF HOLDING 256 VALID
6109 : CHARACTERS IN ITS FIFO.
6110 : THE CHARACTERS ARE TRANSMITTED ON THE FIRST AVAILABLE ACTIVE LINE, IN
6111 : INTERNAL LOOPBACK MODE.
6112 : THE DATA FOUND IN THE FIFO IS COMPARED WITH THE EXPECTED DATA, AND ANY
6113 : DISCREPANCIES ARE REPORTED.
6114 : ANY BMP CODE FOUND WILL INVALIDATE THE TEST AND CAUSE IT TO BE ABORTED.
6115 : HOWEVER THE BMP CODE WILL BE PLACED ON THE BMP CODE QUEUE, TO BE
6116 : REPORTED LATER.
6117 :
6118 :*****
6119 025410      BGNTST
        025410
6120 025410      SETPRI  @PRI05          ;ALLOW LTC INTERRUPTS.      T9::
        025410      012700      000240
        025414      104441
6121          000011
6122 025416      012767      000011      154630      TNUM == TNUM + 1      ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
6123 025424      012767      177777      154616      MOV      @TNUM,TSTNUM      ;SET UP THE TEST NUMBER.      (53)
6124 025432      012767      000001      156410      MOV      @-1,CTRLCF      ;INDICATE THAT WE ARE IN A TEST.
6125 025440      012767      012265      156404      MOV      @1,ERRTYP      ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
6126 025446      012767      006265      156400      MOV      @5301.,ERRNBR      ;SET ERROR NUMBER TO 5301.
6127          MOV      @EM5301,ERRMSG      ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
6128 :
6129 : RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
6130 : CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
6131 : THIS SUBROUTINE REPORTS ERROR >>>> 5301 <<<<<.
6132 025454      004767      166536
6133 025460      103113
6134          JSR      PC,CLNRST      ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
6135          BCC      608      ;EXIT TEST IF FATAL ERROR FOUND.
6136 :
6137 : FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
6138 : INITIALISE 256 BYTE DATA PATTERN.
6139 025462      004767      167002
6140 025466      103110
6141          JSR      PC,FINACT      ;FIND AN ACTIVE LINE.
6142          BCC      608      ;EXIT IF NO ACTIVE LINES FOUND.
6143          JSR      PC,INDATP      ;INITIALISE THE DATA PATTERN.
6144 :
6145 : TRANSMIT A 265 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
6146 : AT 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
6147 :
6148 : SET INTERNAL LOOPBACK ON THE SELECTED LINE.
6149 : TRANSMIT THE DATA PATTERN ON THE FIRST AVAILABLE ACTIVE LINE.
6150 025474      012700      000204
6151 025500      004767      172046
6152 025504      012700      177670
6153 025510      004767      172066
6154 025514      012704      000012
6155 025520      004767      166536
6156 025524      012702      002650
        025530      012703      000400
        MOV      @204,R0      ;PASS PARAMETER FOR INTERNAL LOPBCK,ENABLE RX.
        JSR      PC,WTLNC      ;INITILAISE THE LINE CONTROL REGISTER.
        MOV      @177670,R0      ;PASS THE LPR CONTENTS.
        JSR      PC,WTLPR      ;SET THE LPR CONTENTS TO 38.4K BAUD.
        MOV      @10.,R4      ;PASS DELAY TIME OF 10 MILLI SECONDS.
        JSR      PC,DELAY      ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
        MOV      @BUFBAS,R2      ;PASS THE START OF THE DATA PATTERN TO TX.
        MOV      @BUFMID-BUFBAS,R3 ;PASS THE LENGTH OF THE DATA PATTERN.

```



```

6157 025534 005267 156312
6158 025540 004767 166634
6159 025544 103057
6160
6161
6162
6163
6164 025546 005267 156300
6165 025552 010103
6166 025554 012701 170536
6167 025560 016702 154442
6168 025564 004767 171646
6169 025570 103045
6170 025572 012704 000005
6171 025576 004767 166460
6172
6173
6174
6175
6176 025602 006303
6177 025604 005004
6178 025606 016705 154416
6179 025612 012767 012270 156232 2$:
6180 025620 011502
6181 025622 100030
6182
6183
6184
6185
6186
6187 025624 005267 156222
6188 025630 004767 166142
6189 025634 103002
6190 025636 104460
6191
6192 025640 000423
6193
6194 025642 005267 156204 4$:
6195 025646 120402
6196 025650 001412
6197 025652 012767 012644 156176
6198 025660 012701 006321
6199
6200 025664 104460 6$:
6201
6202
6203
6204
6205 025666 032767 000100 154314
6206 025674 001405
6207
6208
6209 025676 105204
6210 025700 001344
6211 025702 000402

```

```

INC ERRNBR ;SET ERROR NUMBER TO 5302.
JSR PC,DODMA ;TRANSMIT THE DATA PATTERN.
BCC 50$ ;ABORT TEST IF ERROR FOUND DURING DMA TX.
;
; *
; WAIT FOR DMA TO COMPLETE. THEN WAIT FOR THE LAST CHARACTER TO ARRIVE IN
; THE FIFO.
;
; -
INC ERRNBR ;SET ERROR NUMBER TO 5303.
MOV R1,R3 ;SAVE THE NUMBER OF THE SELECTED ACTIVE LINE.
MOV #170536,R1 ;PASS TIME-OUT VALUE OF 350 MILLI SECS.
MOV CSRA,R2 ;PASS THE ADDRESS OF THE CSR.
JSR PC,WAIBIS ;WAIT FOR DMA TO COMPLETE, TX ACTION SET.
BCC 50$ ;BRANCH IF FIFO EMPTY, ABORT THE TEST.
MOV #5,R4 ;PASS DELAY OF 5 MILLI SECS.
JSR PC,DELAY ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
;
; *
; READ THE FIFO CHECKING FOR DATA CORRUPTION, REPORT ANY ERRORS FOUND.
; ABORT THE TEST IF A BMP CODE WAS FOUND IN THE FIFO.
;
; -
ASL R3 ;MULTIPLY BY 2.
CLR R4 ;INITIALISE THE EXPECTED DATA.
MOV RBUFA,R5 ;GET THE ADDRESS OF THE RECEIVER BUFFER REG.
MOV #5304,ERRNBR ;SET UP ERROR NUMBER EACH TIME AROUND LOOP.
MOV (R5),R2 ;GET THE ACTUAL DATA FROM THE FIFO.
BPL 50$ ;ABORT THE TEST IF THE FIFO IS EMPTY.
;
; *
; CHECK IF THE READ CHARACTER IS A BMP CODE.
; IF IT IS A BMP CODE SAVE IT ON THE QUEUE TO BE REPORTED LATER, AND
; ABORT THE TEST.
;
; -
INC ERRNBR ;SET ERROR NUMBER TO 5305.
JSR PC,CHKBMP ;CHECK IF CHARACTER IS A BMP CODE.
BCC 4$ ;BRANCH IF NOT A BMP CODE.
ERROR ; >>>> ERROR 5305 <<<<<.
TRAP C$ERROR
BR 60$ ;ABORT THIS TEST.
;
; *
INC ERRNBR ;SET ERROR NUMBER TO 5306.
CMPB R4,R2 ;COMPARE THE EXPECTED WITH THE ACTUAL DATA.
BEQ 8$ ;SKIP ERROR REPORT IF DATA IS OK.
MOV #ER9002,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
MOV #EM5302,R1 ;PASS THE MESSAGE TO BE REPORTED.
;REPORT THE ERROR "FIFO BAD, DATA FIELD CORRUPTED"
ERROR ; >>>> ERROR 5306 <<<<<.
TRAP C$ERROR
;
; *
; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
;
; -
BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
BEQ 60$ ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
;DURING THE SOFTWARE QUESTIONS.
;
; *
INCB R4 ;INCREMENT THE EXPECTED DATA.
BNE 2$ ;LOOP IF NOT DONE.
BR 60$ ;EXIT

```

6212  
6213 025704 004767 170762  
6214 025710 005067 154334  
6215  
6216 025714  
025714  
025714 104401

50%: JSR PC,TSABRT  
60%: CLR CTRLCF  
ENDTST

;ABORT THE TEST, REASON SHOWN BY ERROR NUMBER.  
;INDICATE THAT WE ARE NOT WITHIN A TEST.

L10036: TRAP C\$ETST



G13

6218  
 6219  
 6220  
 6221  
 6222  
 6223  
 6224  
 6225  
 6226  
 6227  
 6228  
 6229  
 6230  
 6231  
 6232  
 6233  
 6234 025716  
 025716  
 6235 025716  
 025716 012700 000240  
 025722 104441  
 6236 000012  
 6237 025724 012767 000012 154322  
 6238 025732 012767 177777 154310  
 6239 025740 012767 000001 156102  
 6240 025746 012767 012431 156076  
 6241 025754 012767 006452 156072  
 6242 025762 012767 011762 156066  
 6243  
 6244  
 6245  
 6246  
 6247  
 6248 025770 004767 166222  
 6249 025774 103111  
 6250  
 6251  
 6252  
 6253 025776 004767 166466  
 6254 026002 103106  
 6255  
 6256  
 6257  
 6258  
 6259  
 6260  
 6261 026004 004767 166570  
 6262  
 6263  
 6264  
 6265  
 6266  
 6267  
 6268  
 6269  
 6270 026010 012700 000206  
 6271 026014 004767 171532

```

.SBTTL  HARDWARE TEST          - FI3QLI -
;*****
;          - FIFO 3/4 LEVEL INACTIVE TEST -
;
; THIS TEST VERIFIES THAT THE DUT'S FIFO 3/4 LEVEL ALARM SYSTEM
; REMAINS INACTIVE WHILE IT CONTAINS 191 CHARACTERS OR LESS.
; THE TEST LOOKS FOR AN XOFF (ASCII DC3) CHARACTER IN THE FIFO.
; IF ANY XOFF'S ARE FOUND AN ERROR WILL BE REPORTED AND THE TEST ABORTED.
; ANY BMP CODE FOUND WILL INVALIDATE THE TEST AND CAUSE IT TO BE ABORTED.
; HOWEVER THE BMP CODE WILL BE PLACED ON THE BMP CODE QUEUE, TO BE
; REPORTED LATER.
; THE CHARACTERS ARE TRANSMITTED ON THE FIRST AVAILABLE ACTIVE LINE, IN
; INTERNAL LOOPBACK MODE.
;*****

BGN1ST

        SETPRI  #PRI05          ;ALLOW LTC INTERRUPTS.      T10::
;
;          MOV      #PRI05,RO    MOV      #PRI05,RO
;          TRAP     C$SPRI      TRAP     C$SPRI

        TNUM  == TNUM + 1      ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
        MOV   #TNUM,TSTNUM     ;SET UP THE TEST NUMBER.      (54)
        MOV   #-1,CTRLCF      ;INDICATE THAT WE ARE IN A TEST.
        MOV   #1,ERRTYP       ;SET FATAL ERROR TYPE IN ERROR TABLE.
        MOV   #5401,ERRNBR    ;SET ERROR NUMBER TO 5401.
        MOV   #EMS401,ERRMSG  ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
        MOV   #ER0503,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.

;
; *
; * RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
; * CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
; * THIS SUBROUTINE REPORTS ERROR >>>> 5401 <<<<<.
; *
        JSR   PC,CLNRST       ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
        BCC  60$             ;EXIT TEST IF FATAL ERROR FOUND.

;
; *
; * FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
; *
        JSR   PC,FINACT       ;FIND THE NUMBER OF THE FIRST ACTIVE LINE.
        BCC  60$             ;EXIT IF NO LINES ARE AVAILABLE.

;
; *
; * INITIALIZE THE 256 BYTE DATA PATTERN.
; * ENSURE THE DATA PATTERN IS FREE FROM XON'S OR XOFF'S TO PREVENT ERRORS.
; * NOTE: THE FIRST TWO CHARACTERS AND THE LAST TWO CHARACTERS WILL BE THE SAME.
; *
        JSR   PC,INDTPX      ;INITIALISE THE DATA PATTERN.

;
; *
; * TRANSMIT A 191 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
; * AT 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
; *
; *
; * SET INTERNAL LOOPBACK, ENABLE IAUTO AND RX ON THE SELECTED LINE.
; * TRANSMIT THE DATA PATTERN ON THE FIRST AVAILABLE ACTIVE LINE.
; *
        MOV   #206,RO        ;PASS INTERNAL LOPBCK, ENABLE RX AND IAUTO.
        JSR   PC,WTWLNLC    ;INITILAISE THE LINE CONTROL REGISTER.
    
```

```

6272 026020 012700 177670      MOV      #177670,R0      ;PASS THE LPR CONTENTS.
6273 026024 004767 171552      JSR      PC,WTWLPR      ;SET THE LPR CONTENTS TO 38.4K BAUD.
6274 026030 012704 000012      MOV      #10.,R4        ;PASS DELAY TIME OF 10 MILLI SECONDS.
6275 026034 004767 166222      JSR      PC,DELAY        ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
6276 026040 012702 002650      MOV      #8UFBAS,R2     ;PASS THE START OF THE DATA PATTERN TO TX.
6277 026044 012703 000277      MOV      #191.,R3       ;PASS THE LENGTH OF THE DATA PATTERN.
6278 026050 004767 166324      JSR      PC,DODMA       ;TRANSMIT THE DATA PATTERN.
6279 026054 103057              BCC      50$            ;IF ERROR FOUND DURING DMA THEN ABORT TEST.
6280
6281
6282
6283
6284
6285 026056 005267 155770      ;+
6286 026062 012701 170454      ; WAIT FOR DMA TO COMPLETE, THEN WAIT FOR THE LAST CHARACTER TO ARRIVE IN
6287 026066 016702 154134      ; THE FIFO.
6288 026072 004767 171340      ;-
6289 026076 103046              INC      ERRNBR         ;SET ERROR NUMBER TO 5402.
6290 026100 012704 000005      MOV      #170454,R1     ;PASS TIME-OUT VALUE OF 300 MILLI SECS.
6291 026104 004767 166152      MOV      CSRA,R2        ;PASS THE ADDRESS OF THE CSR.
6292
6293
6294
6295
6296
6297
6298
6299
6300 026110 005004              JSR      PC,WAIBIS      ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
6301 026112 016705 154112      BCC      50$            ;IF FIFO EMPTY, REPORT ERROR, ABORT THE TEST.
6302 026116 012767 012433      MOV      #5,R4          ;PASS DELAY OF 5 MILLI SECS.
6303 026124 011502              JSR      PC,DELAY        ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
6304 026126 100032              ;+
6305 026130 005204              ; READ THE CONTENTS OF THE FIFO. IF ANY OF THE FOLLOWING CONDITIONS OCCUR
6306
6307
6308
6309
6310
6311 026132 005267 155714      ; REPORT THE ERROR AND ABORT THE TEST;
6312 026136 004767 165634      ; FIFO EMPTY TOO SOON.
6313 026142 103001              ; BMP CODE FOUND.
6314
6315 026144 000421              ; XOFF CODE FOUND.
6316
6317
6318
6319
6320 026146 005267 155700      ; EXTRA (192) CHARACTER FOUND IN FIFO.
6321 026152 122702 000023      ;-
6322 026156 001003              CLR      R4             ;CLEAR THE CHARACTER COUNT.
6323 026160 012701 006520      MOV      RBUFA,R5       ;GET THE ADDRESS OF THE RECEIVER BUFFER REG.
6324
6325 026164 000411              MOV      #5403.,ERRNBR ;SET ERROR NUMBER TO 5403.
6326
6327 026166 005267 155660      MOV      (R5),R2        ;GET THE ACTUAL DATA FROM THE FIFO.
6328 026172 020427 000277      BPL      50$            ;FIFO EMPTY, ABORT TEST.
6329
6330
6331
6332
6333
6334
6335
6336
6337
6338
6339
6340
6341
6342
6343
6344
6345
6346
6347
6348
6349
6350
6351
6352
6353
6354
6355
6356
6357
6358
6359
6360
6361
6362
6363
6364
6365
6366
6367
6368
6369
6370
6371
6372
6373
6374
6375
6376
6377
6378
6379
6380
6381
6382
6383
6384
6385
6386
6387
6388
6389
6390
6391
6392
6393
6394
6395
6396
6397
6398
6399
6400
6401
6402
6403
6404
6405
6406
6407
6408
6409
6410
6411
6412
6413
6414
6415
6416
6417
6418
6419
6420
6421
6422
6423
6424
6425
6426
6427
6428
6429
6430
6431
6432
6433
6434
6435
6436
6437
6438
6439
6440
6441
6442
6443
6444
6445
6446
6447
6448
6449
6450
6451
6452
6453
6454
6455
6456
6457
6458
6459
6460
6461
6462
6463
6464
6465
6466
6467
6468
6469
6470
6471
6472
6473
6474
6475
6476
6477
6478
6479
6480
6481
6482
6483
6484
6485
6486
6487
6488
6489
6490
6491
6492
6493
6494
6495
6496
6497
6498
6499
6500
6501
6502
6503
6504
6505
6506
6507
6508
6509
6510
6511
6512
6513
6514
6515
6516
6517
6518
6519
6520
6521
6522
6523
6524
6525
6526
6527
6528
6529
6530
6531
6532
6533
6534
6535
6536
6537
6538
6539
6540
6541
6542
6543
6544
6545
6546
6547
6548
6549
6550
6551
6552
6553
6554
6555
6556
6557
6558
6559
6560
6561
6562
6563
6564
6565
6566
6567
6568
6569
6570
6571
6572
6573
6574
6575
6576
6577
6578
6579
6580
6581
6582
6583
6584
6585
6586
6587
6588
6589
6590
6591
6592
6593
6594
6595
6596
6597
6598
6599
6600
6601
6602
6603
6604
6605
6606
6607
6608
6609
6610
6611
6612
6613
6614
6615
6616
6617
6618
6619
6620
6621
6622
6623
6624
6625
6626
6627
6628
6629
6630
6631
6632
6633
6634
6635
6636
6637
6638
6639
6640
6641
6642
6643
6644
6645
6646
6647
6648
6649
6650
6651
6652
6653
6654
6655
6656
6657
6658
6659
6660
6661
6662
6663
6664
6665
6666
6667
6668
6669
6670
6671
6672
6673
6674
6675
6676
6677
6678
6679
6680
6681
6682
6683
6684
6685
6686
6687
6688
6689
6690
6691
6692
6693
6694
6695
6696
6697
6698
6699
6700
6701
6702
6703
6704
6705
6706
6707
6708
6709
6710
6711
6712
6713
6714
6715
6716
6717
6718
6719
6720
6721
6722
6723
6724
6725
6726
6727
6728
6729
6730
6731
6732
6733
6734
6735
6736
6737
6738
6739
6740
6741
6742
6743
6744
6745
6746
6747
6748
6749
6750
6751
6752
6753
6754
6755
6756
6757
6758
6759
6760
6761
6762
6763
6764
6765
6766
6767
6768
6769
6770
6771
6772
6773
6774
6775
6776
6777
6778
6779
6780
6781
6782
6783
6784
6785
6786
6787
6788
6789
6790
6791
6792
6793
6794
6795
6796
6797
6798
6799
6800
6801
6802
6803
6804
6805
6806
6807
6808
6809
6810
6811
6812
6813
6814
6815
6816
6817
6818
6819
6820
6821
6822
6823
6824
6825
6826
6827
6828
6829
6830
6831
6832
6833
6834
6835
6836
6837
6838
6839
6840
6841
6842
6843
6844
6845
6846
6847
6848
6849
6850
6851
6852
6853
6854
6855
6856
6857
6858
6859
6860
6861
6862
6863
6864
6865
6866
6867
6868
6869
6870
6871
6872
6873
6874
6875
6876
6877
6878
6879
6880
6881
6882
6883
6884
6885
6886
6887
6888
6889
6890
6891
6892
6893
6894
6895
6896
6897
6898
6899
6900
6901
6902
6903
6904
6905
6906
6907
6908
6909
6910
6911
6912
6913
6914
6915
6916
6917
6918
6919
6920
6921
6922
6923
6924
6925
6926
6927
6928
6929
6930
6931
6932
6933
6934
6935
6936
6937
6938
6939
6940
6941
6942
6943
6944
6945
6946
6947
6948
6949
6950
6951
6952
6953
6954
6955
6956
6957
6958
6959
6960
6961
6962
6963
6964
6965
6966
6967
6968
6969
6970
6971
6972
6973
6974
6975
6976
6977
6978
6979
6980
6981
6982
6983
6984
6985
6986
6987
6988
6989
6990
6991
6992
6993
6994
6995
6996
6997
6998
6999
7000
    
```



```

6329 026176 001347
6330 026200 011502
6331 026202 100006
6332 026204 012701 006520
6333
6334
6335 026210
        026210 104460
6336 026212 000402
6337
6338
6339 026214 004767 170452
6340 026220 005067 154024
6341
6342 026224
        026224
            104401
    
```

```

BNE 2$
MOV (R5),R2
BPL 60$
MOV @EM5402,R1
;REPORT THE ERROR "FIFO BAD, ALARM SIGNAL DEFECTIVE".
8$: ERROR
; >>>> ERRORS 5304 THRU 5306 <<<<<.
BR 60$ TRAP C$ERROR
;EXIT THE TEST.
50$: JSR PC,TSABRT
60$: CLR CTRLCF
; >>>> ERRORS 5402 AND 5403 <<<<<.
;REPORT TEST ABORTED, NON-TEST RELATED ERROR.
;INDICATE THAT WE ARE NOT WITHIN A TEST.
    
```

```

L10037: TRAP C$ETST
    
```

6344  
 6345  
 6346  
 6347  
 6348  
 6349  
 6350  
 6351  
 6352  
 6353  
 6354  
 6355  
 6356  
 6357  
 6358  
 6359  
 6360  
 6361 026226  
 026226  
 6362 026226  
 026226 012700 000240  
 026232 104441  
 6363 000013  
 6364 026234 012767 000013 154012  
 6365 026242 012767 177777 154000  
 6366 026250 012767 000001 155572  
 6367 026256 012767 012575 155566  
 6368 026264 012767 006561 155562  
 6369  
 6370  
 6371  
 6372  
 6373  
 6374 026272 004767 165720  
 6375 026276 103402  
 6376 026300 000167 000414  
 6377  
 6378  
 6379  
 6380 026304 004767 166160  
 6381 026310 103402  
 6382 026312 000167 000402  
 6383  
 6384  
 6385  
 6386  
 6387  
 6388 026316 004767 166256  
 6389  
 6390  
 6391  
 6392  
 6393  
 6394  
 6395  
 6396  
 6397 026322 005267 155524

```

.SBTTL  HARDWARE TEST          - FI3QLA -
:*****
:
:          - FIFO 3/4 LEVEL ACTIVE TEST -
:
: THIS TEST VERIFIES THAT THE DUT'S FIFO 3/4 LEVEL ALARM SYSTEM
: BECOMES ACTIVE WHEN THE FIFO CONTAINS > 192 CHARACTERS.
: THE TEST COMPARES THE ACTUAL NUMBER OF XOFF (ASCII DC3)
: CHARACTERS THAT ARE FOUND IN THE FIFO WITH THE EXPECTED NUMBER.
: AN ERROR WILL BE REPORTED, IF THE COUNTS ARE FOUND TO DIFFER.
: ANY BMP CODE FOUND WILL INVALIDATE THE TEST AND CAUSE IT TO BE ABORTED.
: HOWEVER THE BMP CODE WILL BE PLACED ON THE BMP CODE QUEUE, TO BE
: REPORTED LATER.
: THE CHARACTERS ARE TRANSMITTED ON THE FIRST AVAILABLE ACTIVE LINE, IN
: INTERNAL LOOPBACK MODE.
:
:-----*****
          BGNTST
          SETPRI  #PRI05          ;ALLOW LTC INTERRUPTS.          T11::
                                  MOV          #PRI05,R0
                                  TRAP        C$SPRI
          TNUM  == TNUM + 1      ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
          MOV   #TNUM,TSTNUM    ;SET UP THE TEST NUMBER.          (55)
          MOV   #-1,CTRLCF      ;INDICATE THAT WE ARE IN A TEST.
          MOV   #1,ERRTYP       ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
          MOV   #5501,ERRNBR    ;SET ERROR NUMBER TO 5501.
          MOV   #EMS501,ERRMSG  ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
:
: RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
: CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
: THIS SUBROUTINE REPORTS ERROR >>>> 5501 <<<<.
:
:
          JSR   PC,CLNRST       ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
          BCS   .+6             ;SKIP EXIT OF TEST IF NO FATAL ERROR FOUND.
          JMP   60$             ;EXIT TEST FATAL ERROR FOUND.
:
: FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
:
          JSR   PC,FINACT       ;FIND AN ACTIVE LINE.
          BCS   .+6             ;SKIP EXIT OF TEST IF ACTIVE LINE FOUND.
          JMP   60$             ;EXIT TEST.
:
: INITIALIZE THE 256 BYTE DATA PATTERN.
: ENSURE THE DATA PATTERN IS FREE FROM XON'S OR XOFF'S TO PREVENT ERRORS.
: NOTE: THE FIRST TWO CHARACTERS AND THE LAST TWO CHARACTERS WILL BE THE SAME.
:
          JSR   PC,INDTPX       ;INITIALISE DATA PATTERN.
:
: TRANSMIT A 191 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
: AT 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
:
:
          ; SET INTERNAL LOOPBACK, ENABLE IAUTO AND RECEIVER ON THE SELECTED LINE.
          ; TRANSMIT THE FIRST 191 CHARACTERS ON THE FIRST AVAILABLE ACTIVE LINE.
:
          INC   ERRNBR          ;SET ERROR NUMBER TO 5502.
    
```



```

6398 026326 012700 000206      MOV      #206,R0      ;PASS INTERNAL LOPBCK, ENABLE RX AND IAUTO.
6399 026332 004767 171214      JSR      PC,WTWLNC    ;INITIALISE THE LINE CONTROL REGISTER.
6400 026336 012700 177670      MOV      #177670,R0   ;PASS THE LPR CONTENTS.
6401 026342 004767 171234      JSR      PC,WTWLPR    ;SET THE LPR CONTENTS TO 38.4K BAUD.
6402 026346 012704 000012      MOV      #10.,R4      ;PASS DELAY TIME OF 10 MILLI SECONDS.
6403 026352 004767 165704      JSR      PC,DELAY     ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
6404 026356 010105                MOV      R1,R5        ;COPY THE LINE NUMBER.
6405 026360 012702 002650      MOV      #BUFBAS,R2   ;PASS THE START OF THE DATA PATTERN TO TX.
6406 026364 012703 000277      MOV      #191.,R3     ;PASS THE LENGTH OF THE DATA PATTERN.
6407 026370 004767 166004      JSR      PC,DODMA     ;TRANSMIT THE DATA PATTERN.
6408 026374 103147                BCC      50$          ;ABORT THE TEST IF ERROR FOUND DURING DMA TX.
6409
6410
6411      ;+
6412      ; WAIT FOR DMA TO COMPLETE, THEN WAIT FOR THE LAST CHARACTER TO ARRIVE IN
6413      ; THE FIFO.
6414 026376 005267 155450      INC      ERRNBR       ;SET ERROR NUMBER TO 5503.
6415 026402 012701 170454      MOV      #170454,R1   ;PASS TIME-OUT VALUE OF 300 MILLI SECS.
6416 026406 016702 153614      MOV      CSRA,R2      ;PASS THE ADDRESS OF THE CSR.
6417 026412 004767 171020      JSR      PC,WAIBIS    ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
6418 026416 103136                BCC      50$          ;IF NO TX_ACTION WAS RECEIVED, ABORT THE TEST.
6419 026420 012704 000005      MOV      #5,R4        ;PASS DELAY OF 5 MILLI SECS.
6420 026424 004767 165632      JSR      PC,DELAY     ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
6421
6422
6423      ;+
6424      ; TRANSMIT A NULL CHARACTER WHICH WILL CAUSE AN XOFF TO BE GENERATED.
6425 026430 005267 155416      INC      ERRNBR       ;SET ERROR NUMBER TO 5504.
6426 026434 010501                MOV      R5,R1        ;PASS THE LINE NUMBER.
6427 026436 012702 002650      MOV      #BUFBAS,R2   ;PASS THE START OF THE DATA PATTERN TO TX.
6428 026442 012703 000001      MOV      #1,R3        ;PASS THE NUMBER OF CHARACTERS TO TX.
6429 026446 004767 165726      JSR      PC,DODMA     ;TX A NULL CHARACTER TO CAUSE AN XOFF.
6430 026452 103120                BCC      50$          ;ABORT THE TEST IF ERROR FOUND DURING DMA TX.
6431
6432      ;+
6433      ; WAIT FOR THE DMA TO COMPLETE AND THE LAST CHAR TO ARRIVE IN THE FIFO
6434 026454 005267 155372      INC      ERRNBR       ;SET ERROR NUMBER TO 5505.
6435 026460 012701 170012      MOV      #170012,R1   ;PASS TIME-OUT VALUE OF 10 MILLI SECS.
6436 026464 016702 153536      MOV      CSRA,R2      ;PASS THE ADDRESS OF THE CSR.
6437 026470 004767 170742      JSR      PC,WAIBIS    ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
6438 026474 103107                BCC      50$          ;IF NO TX_ACTION WAS RECEIVED, ABORT THE TEST.
6439 026476 012704 000005      MOV      #5,R4        ;PASS DELAY OF 5 MILLI SECS.
6440 026502 004767 165554      JSR      PC,DELAY     ;WAIT FOR XOFF TO GET INTO THE FIFO.
6441
6442      ;+
6443      ; INITIALISE THE 256 BYTE DATA PATTERN TO ALL NULLS.
6444 026506 012702 002650      MOV      #BUFBAS,R2   ;INITIALIZE THE DATA PATTERN TO BE
6445 026512 105022                CLR      (R2),#0      ; ALL NULLS.
6446 026514 020227 003250      CMP      R2,#BUF MID  ;
6447 026520 103774                BLO      4$           ;
6448
6449
6450      ;+
6451      ; TRANSMIT A FURTHER 31 NULL CHARACTERS WHICH WILL CAUSE 31 XOFF'S TO BE
6452      ; GENERATED.
6453 026522 005267 155324      INC      ERRNBR       ;SET ERROR NUMBER TO 5506.
6454 026526 010501                MOV      R5,R1        ;PASS THE LINE NUMBER.
6455 026530 012702 002650      MOV      #BUFBAS,R2   ;PASS THE START OF THE DATA PATTERN TO TX.

```

```

6455 026534 012703 000037      MOV    #31.,R3      ;PASS THE LENGTH OF THE DATA PATTERN.
6456 026540 004767 165634      JSR    PC,DODMA    ;TRANSMIT THE DATA PATTERN.
6457 026544 103063              BCC    50$         ;ABORT THE TEST IF ERROR FOUND DURING DMA TX.
6458
6459
6460
6461
6462 026546 005267 155300      ;+
; WAIT FOR THE XOFF'S AND THE NULL CHARACTERS TO BE RECEIVED.
; THERE ARE NOW 255 CHARACTERS IN THE FIFO.
6463 026552 012701 170454      ;-
        INC    ERRNBR      ;SET ERROR NUMBER TO 5507.
        MOV    #170454,R1  ;PASS TIME-OUT VALUE OF 300 MILLI SECS.
        MOV    CSRA,R2    ;PASS THE ADDRESS OF THE CSR.
6464 026556 016702 153444      JSR    PC,WAIBIS    ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
6465 026562 004767 170650      BCC    50$         ;IF NO TX_ACTION WAS RECEIVED, ABORT THE TEST.
6466 026566 103052              MOV    #5,R4       ;PASS DELAY OF 5 MILLI SECS.
6467 026570 012704 000005      JSR    PC,DELAY    ;WAIT FOR XOFF TO GET INTO THE FIFO.
6468 026574 004767 165462
6469
6470
6471
6472
6473 026600 005004              ;+
; READ THE FIFO UNTIL EMPTY, COUNTING THE NUMBER OF XOFF CHARACTERS
; THAT ARE FOUND.
6474 026602 005003              ;-
        CLR    R4         ;CLEAR CHARACTER COUNTER.
        CLR    R3         ;CLEAR THE XOFF FOUND COUNTER.
6475 026604 012701 170001      MOV    #170001,R1   ;INDICATE TO TEST DATA.VALID BIT, TIME-OUT 1MS.
6476 026610 012767 012604 155234 6$:  MOV    #5508.,ERRNBR ;SET UP ERROR NUMBER EACH TIME AROUND THE LOOP.
6477 026616 016702 153406      MOV    RBUFA,R2    ;INDICATE TO CHECK RECEIVE BUFFER REGISTER.
6478 026622 004767 170610      JSR    PC,WAIBIS    ;WAIT FOR RECEIVED CHAR OR TIME-OUT.
6479 026626 103032              BCC    50$         ;GO REPORT ERROR IF FIFO EMPTY.
6480 026630 005204              INC    R4         ;COUNT THE CHARACTER.
6481
6482
6483
6484
6485 026632 005267 155214      ;+
; CHECK FOR BMP CODES IN THE FIFO, ABORT THE TEST IF ANY ARE FOUND.
; SAVE THE BMP CODE ON THE QUEUE TO BE REPORTED LATER.
6486 026636 004767 165134      ;-
        INC    ERRNBR      ;SET ERROR NUMBER TO 5509.
        JSR    PC,CHKBMP   ;CHECK IF WE HAVE GOT A BMP CODE.
6487 026642 103422              BCS    12$        ;GO REPORT THE ERROR IF WE FOUND A BMP CODE.
6488
6489
6490
6491 026644 122702 000023      ;+
; CHECK FOR XOFF CHARACTER.
6492 026650 001001 8$:      CMPB   #23,R2      ;CHECK IF THE RECEIVED CHARACTER WAS AN XOFF.
6493 026652 005203              BNE    10$        ;BRANCH IF CHARACTER WAS NOT AN XOFF.
6494
6495
6496
6497 026654 020427 000400      ;+
; CHECK IF ALL THE CHARACTERS INCLUDING THE XON HAVE BEEN REMOVED.
6498 026660 002753 10$:      CMP    R4,#256.   ;CHECK IF WE HAVE REMOVED ALL THE CHARACTERS.
6499
6500
6501
6502
6503
6504 026662 012767 012606 155162      ;-
; CHECK IF THE CORRECT NUMBER OF XOFF'S WERE FOUND IN THE FIFO.
; REPORT ERROR IF COUNT IS INCORRECT.
6505 026670 022703 000040      MOV    #5510.,ERRNBR ;SET UP THE ERROR NUMBER TO 5510.
6506 026674 001411              CMP    #32.,R3     ;COMPARE EXPECTED XOFF COUNT WITH ACTUAL COUNT.
6507 026676 012767 011762 155152      BEQ    60$         ;EXIT TEST IF SUCCESS.
6508 026704 012701 006520      MOV    #ER0503,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
6509
6510 026710 104460 12$:      MOV    #EM5402,R1  ;PASS THE MESSAGE TO BE REPORTED.
;REPORT THE ERROR "FIFO BAD, ALARM SIGNAL DEFECTIVE".
        ERROR
;
; >>>> ERROR <<<<<
; TRAP    C$ERROR

```



6511 026712 000402  
6512  
6513 026714 004767 167752  
6514 026720 005067 153324  
6515  
6516 026724  
026724  
026724 104401

BR 60\$  
50\$: JSR PC.TSABRT  
60\$: CLR CTRLCF  
ENDTST

;ABORT THE TEST.  
;REPORT TEST ABORTED. ERROR # SHOWS REASON.  
;INDICATE THAT WE ARE NOT WITHIN A TEST.

L10040: TRAP C\$ETST

```

6518 .SBTTL HARDWARE TEST - FI3QAI -
6519 ;*****
6520 ; - FIFO 3/4 ALARM LEVEL ACTIVE/INACTIVE TEST -
6521 ;*
6522 ;*
6523 ;* THIS TEST VERIFIES THAT THE DUT'S FIFO 3/4 LEVEL ALARM SYSTEM
6524 ;* BECOMES ACTIVE AND INACTIVE AT THE CORRECT LEVELS.
6525 ;* ANY BMP CODE FOUND WILL INVALIDATE THE TEST AND CAUSE IT TO BE ABORTED.
6526 ;* HOWEVER THE BMP CODE WILL BE PLACED ON THE BMP CODE QUEUE, TO BE
6527 ;* REPORTED LATER.
6528 ;* THE CHARACTERS ARE TRANSMITTED ON THE FIRST AVAILABLE ACTIVE LINE, IN
6529 ;* INTERNAL LOOPBACK MODE.
6530 ;*
6531 ;*****
6532 026726 BGNTST
        026726
6533 026726 SETPRI #PRI05 ;ALLOW LTC INTERRUPTS. T12::
        026726 012700 000240
        026732 104441
6534 000014
        026734 012767 000014 153312 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
6535 026734 012767 177777 153300 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (56)
6536 026742 012767 177777 153300 MOV #-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
6537 026750 012767 000001 155072 MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
6538 026756 012767 012741 155066 MOV #5601,ERRNBR ;SET ERROR NUMBER TO 5601.
6539 026764 012767 006625 155062 MOV #EM5601,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
6540 ;*
6541 ; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
6542 ; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
6543 ; THIS SUBROUTINE REPORTS ERROR >>>> 5601 <<<<<.
6544 ;-
6545 026772 004767 165220 JSR PC,CLNRST ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
6546 026776 103402 BCS 2# ;SKIP EXITING TEST A SUCCESSFUL RESET.
6547 027000 000167 000412 JMP 60# ;EXIT THIS TEST.
6548 027004
6549 2#
6550 ;*
6551 ; FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
6552 ;-
6552 027004 004767 165460 JSR PC,FINACT ;FIND AN ACTIVE LINE.
6553 027010 103402 BCS .+6 ;SKIP EXIT OF TEST IF ACTIVE LINE FOUND.
6554 027012 000167 000400 JMP 60# ;EXIT TEST.
6555
6556 ;*
6557 ; INITIALIZE THE 256 BYTE DATA PATTERN.
6558 ; ENSURE THE DATA PATTERN IS FREE FROM XON'S OR XOFF'S TO PREVENT ERRORS.
6559 ; NOTE: THE FIRST TWO CHARACTERS AND THE LAST TWO CHARACTERS WILL BE THE SAME.
6560 ;-
6560 027016 004767 165556 JSR PC,INDTPX ;INITIALISE THE DATA PATTERN.
6561
6562 ;*
6563 ; TRANSMIT A 256 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
6564 ; AT 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
6565 ;-
6566 ;*
6567 ; SET INTERNAL LOOPBACK, ENABLE IAUTO AND RECEIVER ON THE SELECTED LINE.
6568 ; TRANSMIT THE FIRST 191 CHARACTERS ON THE FIRST AVAILABLE ACTIVE LINE.
6569 ;-
6569 027022 005267 155024 INC ERRNBR ;SET ERROR NUMBER TO 5602.
6570 027026 012700 000206 MOV #206,RO ;PASS INTERNAL LOPBCK, ENABLE RX AND IAUTO.
6571 027032 004767 170514 JSR PC,WTWLNLC ;INITILAISE THE LINE CONTROL REGISTER.
    
```



6572	027036	012700	177670	MOV	#177670,R0	;PASS THE LPR CONTENTS.
6573	027042	004767	170534	JSR	PC,WTWLP	;SET THE LPR CONTENTS TO 38.4K BAUD.
6574	027046	012704	000012	MOV	#10.,R4	;PASS DELAY TIME OF 10 MILLI SECONDS.
6575	027052	004767	165204	JSR	PC,DELAY	;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
6576	027056	010105		MOV	R1,R5	;COPY THE LINE NUMBER.
6577	027060	012702	002650	MOV	#BUFAS,R2	;PASS THE START OF THE DATA PATTERN TO TX.
6578	027064	012703	000277	MOV	#191.,R3	;PASS THE LENGTH OF THE DATA PATTERN.
6579	027070	004767	165304	JSR	PC,DODMA	;TRANSMIT THE DATA PATTERN.
6580	027074	103146		BCC	508	;EXIT IF ERROR FOUND DURING DMA TX.
6581						
6582						
6583						
6584						
6585	027076	005267	154750			
6586	027102	012701	170454	INC	ERRNBR	;SET ERROR NUMBER TO 5603.
6587	027106	016702	153114	MOV	#170454,R1	;PASS TIME-OUT VALUE OF 300 MILLI SECS.
6588	027112	004767	170320	MOV	CSRA,R2	;PASS THE ADDRESS OF THE CSR.
6589	027116	103135		JSR	PC,WAIBIS	;WAIT FOR DMA TO COMPLETE, TX ACTION SET.
6590	027120	012704	000005	BCC	508	;BRANCH IF FIFO EMPTY, ABORT THE TEST.
6591	027124	004767	165132	MOV	#5,R4	;PASS DELAY OF 5 MILLI SECS.
6592				JSR	PC,DELAY	;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
6593						
6594						
6595						
6596	027130	005267	154716			
6597	027134	010501		INC	ERRNBR	;SET ERROR NUMBER TO 5604.
6598	027136	012702	002650	MOV	R5,R1	;PASS THE LINE NUMBER.
6599	027142	012703	000001	MOV	#BUFAS,R2	;PASS THE START OF THE DATA PATTERN TO TX.
6600	027146	004767	165226	MOV	#1,R3	;PASS THE NUMBER OF
6601	027152	103117		JSR	PC,DODMA	;TX A NULL CHARACTER TO CAUSE AN XOFF.
6602				BCC	508	;ABORT THE TEST IF ERROR FOUND DURING DMA TX.
6603						
6604						
6605	027154	005267	154672			
6606	027160	012701	170012	INC	ERRNBR	;SET ERROR NUMBER TO 5605.
6607	027164	016702	153036	MOV	#170012,R1	;PASS TIME-OUT VALUE OF 10 MILLI SECS.
6608	027170	004767	170242	MOV	CSRA,R2	;PASS THE ADDRESS OF THE CSR.
6609	027174	103106		JSR	PC,WAIBIS	;WAIT FOR DMA TO COMPLETE, TX ACTION SET.
6610	027176	012704	000005	BCC	508	;IF NO TX ACTION WAS RECEIVED, ABORT THE TEST.
6611	027202	004767	165054	MOV	#5,R4	;PASS DELAY OF 5 MILLI SECS.
6612				JSR	PC,DELAY	;WAIT FOR XOFF TO GET INTO THE FIFO.
6613	027206	010577	153014	MOV	R5,BCSRA	;SELECT THE LINE READY FOR TRANSMISSION.
6614						
6615						
6616						
6617						
6618						
6619						
6620	027212	005005				
6621	027214	005004		CLR	R5	;CLEAR THE TX FLAG.
6622	027216	012703	000300	CLR	R4	;CLEAR THE CHARACTER COUNTER.
6623				MOV	#192.,R3	;SET UP READ COUNTER FOR THE FIRST 192 CHARS.
6624	027222	012700	000003			
6625	027226	012701	170005	48:	MOV	#3,R0
6626	027232	016702	152772	68:	MOV	#170005,R1
6627	027236	004767	170174		MOV	RBUFA,R2
6628	027242	103046			JSR	PC,WAIBIS
					BCC	148

; WAIT FOR DMA TO COMPLETE. THEN WAIT FOR THE LAST CHARACTER TO ARRIVE IN THE FIFO.

; SET ERROR NUMBER TO 5603.  
 ; PASS TIME-OUT VALUE OF 300 MILLI SECS.  
 ; PASS THE ADDRESS OF THE CSR.  
 ; WAIT FOR DMA TO COMPLETE, TX ACTION SET.  
 ; BRANCH IF FIFO EMPTY, ABORT THE TEST.  
 ; PASS DELAY OF 5 MILLI SECS.  
 ; WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.

; TRANSMIT A NULL CHARACTER WHICH WILL CAUSE AN XOFF TO BE GENERATED.

; SET ERROR NUMBER TO 5604.  
 ; PASS THE LINE NUMBER.  
 ; PASS THE START OF THE DATA PATTERN TO TX.  
 ; PASS THE NUMBER OF  
 ; TX A NULL CHARACTER TO CAUSE AN XOFF.  
 ; ABORT THE TEST IF ERROR FOUND DURING DMA TX.

; WAIT FOR THE XOFF TO BE RECEIVED BEFORE CONTINUING THE TEST.

; SET ERROR NUMBER TO 5605.  
 ; PASS TIME-OUT VALUE OF 10 MILLI SECS.  
 ; PASS THE ADDRESS OF THE CSR.  
 ; WAIT FOR DMA TO COMPLETE, TX ACTION SET.  
 ; IF NO TX ACTION WAS RECEIVED, ABORT THE TEST.  
 ; PASS DELAY OF 5 MILLI SECS.  
 ; WAIT FOR XOFF TO GET INTO THE FIFO.

; SELECT THE LINE READY FOR TRANSMISSION.

; READ THREE CHARACTERS, TRANSMIT ONE CHARACTER UNTIL THE FIRST 192 CHARACTERS HAVE BEEN READ FROM THE FIFO, IE UNTIL THE HALF LEVEL IS REACHED.  
 ; THEN READ THE FIFO UNTIL EMPTY.  
 ; COUNT ALL XOFF'S THAT ARE DETECTED.

; CLEAR THE TX FLAG.  
 ; CLEAR THE CHARACTER COUNTER.  
 ; SET UP READ COUNTER FOR THE FIRST 192 CHARS.

; SET READ COUNTER.  
 ; INDICATE TO TEST DATA VALID BIT, TIME-OUT SMS.  
 ; INDICATE TO CHECK RECEIVE BUFFER REGISTER.  
 ; WAIT FOR RECEIVED CHAR OR TIME-OUT.  
 ; EXIT LOOP IF TIME-OUT, FIFO EMPTY.

```

6629 027244 005300
6630 027246 005303
6631 027250 003002
6632 027252 052705 100000
6633
6634
6635
6636
6637
6638 027256 012767 012746 154566 8:
6639 027264 004767 164506
6640 027270 103446
6641
6642
6643
6644
6645 027272 122702 000023 10:
6646 027276 001001
6647 027300 005204
6648
6649 027302 005700 12:
6650 027304 001350
6651 027306 005705
6652 027310 100744
6653 027312 112777 000000 152714
6654 027320 010446
6655
6656
6657
6658 027322 005267 154524
6659 027326 012701 170012
6660 027332 016702 152670
6661 027336 004767 170074
6662 027342 103023
6663 027344 012704 000005
6664 027350 004767 164706
6665 027354 012604
6666 027356 000721
6667
6668
6669
6670
6671
6672 027360 012767 012750 154464 14:
6673 027366 020427 000077
6674 027372 001411
6675 027374 012767 011762 154454
6676 027402 012701 006520
6677
6678 027406
027406 104460 16:
027410 000402
6679
6680
6681 027412 004767 167254 50:
6682 027416 005067 152626 60:
6683
6684 027422

```

DEC R0 ;DECREMENT READ COUNTER.  
 DEC R3 ;DECREMENT CHAR COUNTER.  
 BGT 8: ;SKIP DISBL'G TX IF FIRST 192 CHARS NOT READ.  
 BIS #BIT15,R5 ;DISABLE ANY FURTHER TRANSMISSIONS.  
 ;  
 ; CHECK IF THE READ CHARACTER IS A BMP CODE.  
 ; IF IT IS A BMP CODE SAVE IT ON THE QUEUE TO BE REPORTED LATER, AND  
 ; ABORT THE TEST.  
 ;  
 8: MOV #5606,,ERRNBR ;SET UP ERROR NUMBER EACH TIME AROUND LOOP.  
 JSR PC,CHKBMP ;CHECK IF CHARACTER IS A BMP CODE.  
 BCS 16: ;GO REPORT ERROR AND ABORT TEST IF BMP FOUND.  
 ;  
 ; CHECK FOR XOFF CHARACTER. IF ONE IS FOUND, COUNT IT.  
 ; TRANSMIT A NULL CHARACTER UNTIL THE FIRST 192 CHARS HAVE BEEN READ.  
 ;  
 10: CMPB #23,R2 ;CHECK IF THE RECEIVED CHARACTER WAS AN XOFF.  
 BNE 12: ;BRANCH IF CHARACTER WAS NOT AN XOFF.  
 INC R4 ;INCREMENT THE XOFF CHAR FOUND COUNTER.  
 ;  
 12: TST R0 ;CHECK READ COUNT, TO SEE IF A CHAR CAN BE TX.  
 BNE 6: ;BRANCH IF 3 CHARS HAVE NOT YET BEEN READ.  
 TST R5 ;CHECK THE TRANSMISSION ENABLED FLAG.  
 BMI 4: ;SKIP TRANSMITTING A CHARACTER IF TX DISABLED.  
 MOVB #0,BFDATA ;TX A NULL CHARACTER.  
 MOV R4,-(SP) ;SAVE THE XOFF COUNT ON THE STACK.  
 ;  
 ; WAIT FOR THE CHARACTER TO BE RECEIVED BEFORE CONTINUING THE TEST.  
 ;  
 INC ERRNBR ;SET ERROR NUMBER TO 5607.  
 MOV #170012,R1 ;PASS TIME-OUT VALUE OF 10 MILLI SECS.  
 MOV CSRA,R2 ;PASS THE ADDRESS OF THE CSR.  
 JSR PC,WAIBIS ;WAIT FOR DMA TO COMPLETE, TX\_ACTION SET.  
 BCC 50: ;IF NO TX\_ACTION WAS RECEIVED, ABORT THE TEST.  
 MOV #5,R4 ;PASS DELAY OF 5 MILLI SECS.  
 JSR PC,DELAY ;WAIT FOR XOFF TO GET INTO THE FIFO.  
 MOV (SP),R4 ;RESTORE THE XOFF COUNT.  
 BR 4: ;GO RESET THE READ COUNT AND GET NEXT CHAR.  
 ;  
 ; CHECK IF THE CORRECT NUMBER OF XOFF'S WERE FOUND IN THE FIFO  
 ; REPORT ERROR IF COUNT IS INCORRECT.  
 ;  
 14: MOV #5608,,ERRNBR ;SET ERROR NUMBER TO 5608.  
 CMP R4,#63. ;COMPARE THE EXPECTED AND ACTUAL XOFF COUNTS.  
 BEQ 60: ;EXIT TEST IF SUCCESS.  
 MOV #ER0503,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.  
 MOV #EM5402,R1 ;PASS THE MESSAGE TO BE REPORTED.  
 ;REPORT THE ERROR "FIFO BAD, ALARM SIGNAL DEFECTIVE".  
 16: ERROR ;  
 ; >>>> ERROR <<<<<<  
 ; TRAP C:ERROR  
 BR 60: ;EXIT THIS TEST.  
 ;  
 50: JSR PC,TSABRT ;REPORT TEST ABORTED. ERROR # INDICATES FAULT.  
 60: CLR CTRLCF ;INDICATE THAT WE ARE NOT WITHIN A TEST.  
 ;  
 ENDTST



027422  
027422 104401

L10041: TRAP C#ETST

6686  
 6687  
 6688  
 6689  
 6690  
 6691  
 6692  
 6693  
 6694  
 6695  
 6696  
 6697  
 6698  
 6699  
 6700 027424  
       027424  
 6701 027424  
       027424 012700 000240  
       027430 104441  
 6702 000015  
 6703 027432 012767 000015 152614  
 6704 027440 012767 177777 152602  
 6705 027446 012767 000001 154374  
 6706 027454 012767 013105 154370  
 6707 027462 012767 006702 154364  
 6708 027470 012767 011762 154360  
 6709  
 6710  
 6711  
 6712  
 6713  
 6714 027476 004767 164514  
 6715 027502 103402  
 6716 027504 000167 000364  
 6717 027510  
 6718  
 6719  
 6720  
 6721 027510 004767 164754  
 6722 027514 103167  
 6723  
 6724  
 6725  
 6726  
 6727  
 6728 027516 004767 165056  
 6729  
 6730  
 6731  
 6732  
 6733  
 6734  
 6735  
 6736  
 6737  
 6738 027522 005267 154324  
 6739 027526 004767 167014

```

.SBTTL  HARDWARE TEST          - FIHAVL -
:*****
:
:          - FIFO HALF LEVEL ACTIVE/INACTIVE TEST -
:
: THIS TEST CHECKS THAT THE DUT'S FIFO HALF LEVEL ALARM SYSTEM
: BECOMES ACTIVE AND INACTIVE AT THE CORRECT LEVELS.
: ANY BMP CODE FOUND WILL INVALIDATE THE TEST AND CAUSE IT TO BE ABORTED.
: HOWEVER THE BMP CODE WILL BE PLACED ON THE BMP CODE QUEUE, TO BE
: REPORTED LATER.
: THE CHARACTERS ARE TRANSMITTED ON THE FIRST AVAILABLE ACTIVE LINE, IN
: INTERNAL LOOPBACK MODE.
:*****
BGNTST
SETPRI  #PRIOS          ;ALLOW LTC INTERRUPTS.      T13::
                                MOV      #PRIOS,RO
                                TRAP    C$SPRI
TNUM == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
MOV     #TNUM,TSTNUM      ;SET UP THE TEST NUMBER.          (57)
MOV     #-1,CTRLCF        ;INDICATE THAT WE ARE IN A TEST.
MOV     #1,ERRTP          ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
MOV     #5701,ERRNBR      ;SET ERROR NUMBER TO 5701.
MOV     #EM5701,ERRMSG    ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
MOV     #ER0503,ERRBLK    ;SELECT THE ERROR REPORTING ROUTINE.
:
: RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
: CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
: THIS SUBROUTINE REPORTS ERROR >>>> 5701 <<<<<.
:
JSR     PC,CLNRST         ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
BCS     2$                ;SKIP EXITING TEST A SUCCESSFUL RESET.
JMP     60$               ;EXIT THIS TEST.
2$:
:
: FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
:
JSR     PC,FINACT         ;FIND AN ACTIVE LINE.
BCC     60$               ;EXIT IF NO ACTIVE LINES AVAILABLE.
:
: INITIALIZE THE 256 BYTE DATA PATTERN.
: ENSURE THE DATA PATTERN IS FREE FROM XON'S OR XOFF'S TO PREVENT ERRORS.
: NOTE: THE FIRST TWO CHARACTERS AND THE LAST TWO CHARACTERS WILL BE THE SAME.
:
JSR     PC,INDTPX         ;INITIALISE THE DATA PATTERN.
:
: FILL THE FIFO AND THE UART'S 3 CHAR BUFFER BY TRANSMITTING 225 CHARS
: (IE 225 + 34 XOFF'S). TRANSMIT DATA PATTERN USING DMA, ON A SINGLE CHANNEL
: AT 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
:
:
: SET INTERNAL LOOPBACK, ENABLE IAUTO AND RECEIVER ON THE SELECTED LINE.
: TRANSMIT THE 225 CHARACTERS ON THE FIRST AVAILABLE ACTIVE LINE.
:
INC     ERRNBR            ;SET ERROR NUMBER TO 5702.
JSR     PC,SETPAR        ;SET UP PARAMETERS FOR TRANSMISSION.
    
```



6740	027532	012700	000341		MOV	#225.,R0		;PASS LENGTH OF DATA PATTERN.
6741	027536	004767	167242		JSR	PC,TXDATP		;TRANSMIT DATA PATTERN.
6742	027542	103152			BCC	50#		;EXIT IF ERROR FOUND DURING TX.
6743	027544	010105			MOV	R1,R5		;COPY THE LINE NUMBER.
6744								
6745								
6746								
6747								
6748	027546	005267	154300					
6749	027552	004767	167734		INC	ERRNBR		;SET ERROR NUMBER TO 5703.
6750	027556	103144			JSR	PC,WAITTX		;WAIT FOR TRANSMISSION TO COMPLETE.
6751					BCC	50#		;GO REPORT ERROR IF TX FAILED TO COMPLETE.
6752								
6753								
6754								
6755								
6756	027560	005267	154266					
6757	027564	012700	000202		INC	ERRNBR		;SET ERROR NUMBER TO 5704.
6758	027570	004767	166060		MOV	#130.,R0		;PASS THE NUMBER OF CHARS TO READ.
6759	027574	103135			JSR	PC,READBX		;READ THE FIRST 130 CHARS FROM THE FIFO.
6760	027576	005267	154250		BCC	50#		;GO REPORT ERROR IF BMP CODE FOUND.
6761	027602	005701			INC	ERRNBR		;SET ERROR NUMBER TO 5705.
6762	027604	001125			TST	R1		;CHECK IF AN XON WAS FOUND.
6763					BNE	30#		;GO REPORT ERROR IF AN XON WAS FOUND.
6764								
6765								
6766								
6767	027606	010577	152414					
6768	027612	112777	000000	152414	MOV	R5,BCSRA		;SELECT THE LINE READY FOR TRANSMISSION.
6769	027620	005267	154226		MOVB	#0,BFDATA		;TRANSMIT A NULL CHARACTER.
6770	027624	004767	167662		INC	ERRNBR		;SET ERROR NUMBER TO 5706.
6771	027630	103117			JSR	PC,WAITTX		;WAIT FOR TX TO COMPLETE.
6772					BCC	50#		;GO REPORT ERROR IF TX DID NOT COMPLETE.
6773								
6774								
6775	027632	005267	154214					
6776	027636	012700	000003		INC	ERRNBR		;SET ERROR NUMBER TO 5707.
6777	027642	004767	166006		MOV	#3,R0		;SET THE READ COUNT TO 3.
6778	027646	103110			JSR	PC,READBX		;READ 3 CHARACTERS FROM THE FIFO.
6779	027650	005267	154176		BCC	50#		;GO REPORT ERROR IF FIFO EMPTY.
6780	027654	005701			INC	ERRNBR		;SET ERROR NUMBER TO 5708.
6781	027656	001102			TST	R1		;CHECK IF AN XON WAS FOUND.
6782					BNE	40#		;GO REPORT ERROR IF AN XON WAS FOUND.
6783								
6784								
6785	027660	012700	000076					
6786	027664	010501			MOV	#62.,R0		;PASS LENGTH OF DATA PATTERN.
6787	027666	005267	154160		MOV	R5,R1		;PASS THE LINE NUMBER.
6788	027672	004767	167106		INC	ERRNBR		;SET ERROR NUMBER TO 5709.
6789	027676	103074			JSR	PC,TXDATP		;TRANSMIT DATA PATTERN.
6790					BCC	50#		;EXIT IF ERROR FOUND DURING TX.
6791								
6792								
6793								
6794								
6795	027700	005267	154146					
6796	027704	004767	167602		INC	ERRNBR		;SET ERROR NUMBER TO 5710.
					JSR	PC,WAITTX		;WAIT FOR TX TO COMPLETE.

```

6797 027710 103067
6798
6799
6800
6801
6802
6803 027712 005267 154134
6804 027716 012700 000176
6805 027722 004767 165726
6806 027726 103060
6807 027730 005267 154116
6808 027734 005701
6809 027736 001052
6810 027740 005267 154106
6811 027744 012701 006520
6812 027750 016703 152254
6813 027754 011302
6814 027756 120227 000000
6815 027762 001040
6816 027764 005267 154062
6817 027770 011302
6818 027772 120227 000023
6819 027776 001032
6820 030000 011302
6821 030002 005267 154044
6822 030006 120227 000021
6823 030012 001024
6824 030014 005267 154032
6825 030020 011302
6826 030022 120227 000000
6827 030026 001016
6828
6829
6830
6831
6832 030030 012700 000075
6833 030034 005267 154012
6834 030040 004767 165610
6835 030044 103011
6836 030046 005267 154000
6837 030052 005701
6838 030054 001003
6839 030056 000406
6840 030060 012701 006520
6841
6842 030064
        030064 104460
6843 030066 000402
6844
6845 030070 004767 166576
6846 030074 005067 152150
6847
6848 030100
        030100
        030100 104401
    
```

```

; GO REPORT ERROR IF TX FAILED TO COMPLETE.
; READ THE FIRST 126 CHARACTERS.
; READ THE NEXT 4 CHARACTERS AND CHECK IF THEY ARE IN THE FOLLOWING ORDER
; NULL, XOFF, XON, NULL.
;
    BCC 50$
    INC ERRNBR ;SET ERROR NUMBER TO 5711.
    MOV #126,,R0 ;SET UP READ COUNTER.
    JSR PC,READBX ;READ THE FIRST 126 CHARS.
    BCC 50$ ;GO REPORT THE ERROR IF FIFO EMPTY.
    INC ERRNBR ;SET ERROR NUMBER TO 5712.
    TST R1 ;CHECK IF AN XON WAS FOUND.
    BNE 40$ ;GO REPORT ERROR IF AN XON WAS FOUND.
    INC ERRNBR ;SET ERROR NUMBER TO 5713.
    MOV #EMS402,R1 ;PASS THE MESSAGE TO BE REPORTED.
    MOV RBUFA,R3 ;GET THE RECEIVER BUFFER ADDRESS.
    MOV (R3),R2 ;READ THE NULL CHARACTER FROM THE FIFO.
    CMPB R2,#0000 ;CHECK IF IT IS A NULL CHARACTER.
    BNE 40$ ;GO REPORT THE ERROR IF NOT THE SAME.
    INC ERRNBR ;SET ERROR NUMBER TO 5714.
    MOV (R3),R2 ;READ THE XOFF FROM THE FIFO.
    CMPB R2,#23 ;CHECK IF THE READ CHAR IS AN XOFF.
    BNE 40$ ;GO REPORT THE ERROR IF NOT THE SAME.
    MOV (R3),R2 ;READ THE XON FROM THE FIFO.
    INC ERRNBR ;SET ERROR NUMBER TO 5715.
    CMPB R2,#21 ;CHECK IF THE READ CHARACTER IS AN XON.
    BNE 40$ ;GO REPORT THE ERROR IF NOT THE SAME.
    INC ERRNBR ;SET ERROR NUMBER TO 5716.
    MOV (R3),R2 ;READ THE NULL CHARACTER FROM THE FIFO.
    CMPB R2,#0000 ;CHECK IF IT IS A NULL CHARACTER.
    BNE 40$ ;GO REPORT THE ERROR IF NOT THE SAME.
;
; READ THE REMAINING CHARACTERS FROM THE FIFO.
;
    6$: MOV #61,,R0 ;SET UP READ COUNTER.
        INC ERRNBR ;SET ERROR NUMBER TO 5717.
        JSR PC,READBX ;READ THE FIRST 61 CHARS.
        BCC 50$ ;GO REPORT THE ERROR IF FIFO EMPTY.
        INC ERRNBR ;SET ERROR NUMBER TO 5718.
        TST R1 ;CHECK IF AN XON WAS FOUND.
        BNE 40$ ;GO REPORT ERROR IF AN XON WAS FOUND.
        BR 60$ ;EXIT THE TEST.
    30$: MOV #EMS402,R1 ;SET UP THE MESSAGE
        ; "FIFO ALARM SIGNAL DEFECTIVE".
        ; >>>> ERROR <<<<<
    40$: ERROR ; TRAP C$ERROR
        BR 60$ ;EXIT THE TEST.
    50$: JSR PC,TSABRT ;REPORT TEST ABORTED. ERROR # INDICATES FAULT.
    60$: CLR CTRLCF ;INDICATE THAT WE ARE NOT WITHIN A TEST.
;
    ENDTST
;
; L10042: TRAP C$ETST
    
```



6850  
 6851  
 6852  
 6853  
 6854  
 6855  
 6856  
 6857  
 6858  
 6859  
 6860  
 6861  
 6862  
 6863 030102  
       030102  
 6864 030102  
       030102 012700 000240  
       030106 104441  
 6865 000016  
 6866 030110 012767 000016 152136  
 6867 030116 012767 177777 152124  
 6868 030124 012767 000001 153716  
 6869 030132 012767 013251 153712  
 6870 030140 012767 006757 153706  
 6871 030146 005067 152100  
 6872  
 6873  
 6874  
 6875 030152 004767 166124  
 6876 030156 103402  
 6877 030160 000167 000732  
 6878  
 6879  
 6880  
 6881 030164  
       030164 012746 000300  
       030170 012746 017702  
       030174 016746 152014  
       030200 012746 000003  
       030204 104437  
       030206 062706 000010  
 6882 030212  
       030212 012700 000200  
       030216 104441  
 6883 030220 005067 152042  
 6884  
 6885  
 6886  
 6887 030224 004767 166224  
 6888 030230 012704 000005  
 6889 030234 004767 164022  
 6890 030240 004767 166150  
 6891 030244 005267 153602  
 6892 030250 005767 152012  
 6893 030254 001002  
 6894 030256 000167 000630  
 6895

```

.SBTTL  HARDWARE TEST          - RXTIMER -
; * *****
; * - RXTIMER REG TEST -
; * THIS TEST VERIFIES THAT THE RXTIMER DELAYS ANY RX-INTS BY THE
; * REQUESTED AMOUNT AND THAT WHEN THE RXFIFO IS MORE THAN 3/4 FULL
; * THE RXTIMER VALUE IS IGNORED AND AN INTERRUPT OCCURS IMMEDIATELY.
; * DUE TO THE DIFFERENCES IN LTC HANDLING OF DIFFERENT VERSIONS OF
; * THE DRS AND LTC AVAILABILITY ON DIFFERENT PDP-11 MACHINES THE
; * RX-INT CAN ONLY BE TIMED TO WITHIN +/- 20% OF THE RXTIMER VALUE.
; * THIS TEST IS PERFORMED IN INTERNAL LOOPBACK ON THE FIRST ACTIVE LINE.
; * *****
; *
; * BGNTST
; *
; * SETPRI @PRI05          ;ALLOW LTC INTERRUPTS.          T14::
; *
; *                               MOV @PRI05,RO
; *                               TRAP C$SPRI
; *
; * TNUM == TNUM + 1      ;INCREMENT ASSEMBLY TIME TEST COUNTER
; * MOV @TNUM,TSTNUM     ;SET UP THE TEST NUMBER.
; * MOV @-1,CTRLCF       ;INDICATE THAT WE ARE IN A TEST.
; * MOV @1,ERRTYP        ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
; * MOV @5801,ERRNBR     ;SET THE ERROR NUMBER TO 5801.
; * MOV @EM5801,ERRMSG   ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
; * CLR EXOERR           ;CLEAR THE "EXIT ON ERROR" FLAG.
; *
; *
; * RESET THE DEVICE AND LEAVE THE SELFTEST CODES IN THE FIFO.
; *
; * JSR PC,RESETT        ;RESET THE DUT.
; * BCS .+6              ;CONTINUE IF FIFO PURGED
; * JMP 60$              ;REPORT THE RESET FAILURE.
; *
; *
; * SET UP THE INTERRUPT SERVICE ROUTINE THAT DETECTS THE RX-INT.
; *
; * SETVEC RXVECA,@RXDECT,@PRI06
; *
; *                               MOV @PRI06,-(SP)
; *                               MOV @RXDECT,-(SP)
; *                               MOV RXVECA,-(SP)
; *                               MOV @3,-(SP)
; *                               TRAP C$SVEC
; *                               ADD @10,SP
; *
; * SETPRI @PRI04          ;ALLOW DEVICE INTERRUPTS.
; *
; * CLR RXINTC           ;CLEAR THE RX-INT COUNT.
; *
; *
; * ENABLE RX-INTS AND WAIT FOR ONE TO OCCUR.
; *
; * JSR PC,RXIE1        ;ENABLE RX-INTS.
; * MOV @5,R4           ;SET THE DELAY OF 5 MILLI SECS.
; * JSR PC,DELAY        ;DELAY WHILE THE INT OCCURS.
; * JSR PC,RXIE0        ;DISABLE RX-INTS.
; * INC ERRNBR          ;SET THE ERROR NUMBER TO 5802.
; * TST RXINTC         ;TEST IF AN INTERRUPT OCCURED.
; * BNE .+6             ;CONTINUE IF AN INTERRUPT OCCURED.
; * JMP 50$             ;REPORT THE ERROR IF NO INTERRUPT.
; *
; *

```

```

6896
6897
6898
6899 030262 004767 164202
6900 030266 103402
6901 030270 000167 000622
6902 030274 012700 000204
6903
6904 030300 004767 167246
6905 030304 012700 177670
6906 030310 004767 167266
6907 030314 012704 000012
6908 030320 004767 163736
6909
6910
6911
6912
6913
6914 030324 010167 000616
6915 030330 012705 000020
6916 030334 012767 013253 153510 24:
6917 030342 004767 165022
6918 030346 103402
6919 030350 000167 000536
6920 030354 016701 000566
6921 030360 012703 000277
6922 030364 005267 153462
6923 030370 004767 163726
6924
6925 030374 103402
6926 030376 000167 000510
6927
6928
6929
6930
6931 030402 010501
6932 030404 006301
6933 030406 006301
6934 030410 105077 151612
6935
6936 030414 010500
6937 030416 005300
6938 030420 110077 151604
6939 030424 012704 000002
6940 030430 004767 163626
6941 030434 012702 000001
6942 030440 010203
6943 030442 012704 002266
6944 030446 005067 151614
6945 030452 012767 000100 151576
6946 030460 016777 151572 151540
6947 030466 004767 164236
6948 030472 103415
6949
6950
6951
6952 030474 010502

; SET INTERNAL LOOPBACK ON THE FIRST ACTIVE LINE AND ENABLE RECIEVERS. SET UP
; THE LPR'S TO 38.4K BAUD, 8 BITS/CHARA, ODD PARITY, 2 STOP BITS.
;-
JSR PC,FINACT ;FIND AN ACTIVE LINE FOR THIS TEST.
BCS .+6 ;CONTINUE IF A LINE HAS BEEN FOUND.
JMP 604 ;EXIT THE TEST IF NO LINES ACTIVE.
MOV #204,R0 ;PASS PARAMETER FOR INTERNAL LOOPBACK,
;ENABLE RECIEVERS.
JSR PC,WTWLNLC ;INITIALISE THE LINE CONTROL REGS.
MOV #177670,R0 ;PASS THE LPR CONTENTS.
JSR PC,WTWLPR ;SET THE LPR'S TO 38.4K BAUD.
MOV #10,R4 ;PASS DELAY TIME OF 10 MILLI SECS.
JSR PC,DELAY ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.

; SET UP THE LOOP TO TEST THE RXTIMER WITH DELAYS OF 15,31,63,127 AND 255 MS.
; DMA 191 CHARACTERS INTO THE FIFO AND THEN ENABLE INTERRUPTS, VERIFY THAT
; THE INTERRUPT OCCURS WITHIN +/- 20% OF THE RXTIMER VALUE.
;-
MOV R1,704 ;SAVE THE LINE NUMBER.
MOV #16,R5 ;SET THE FIRST (RXTIMER VALUE * 1).
MOV #5803,ERRNBR ;SET THE ERROR NUMBER TO 5803.
JSR PC,PUFIFO ;PURGE THE RXFIFO.
BCS .+6 ;CONTINUE IF SUCCESSFUL.
JMP 504 ;REPORT THE ERROR IF FIFO FAILED TO PURGE.
MOV 704,R1 ;PASS THE LINE NUMBER.
MOV #191,R3 ;PASS THE NUMBER OF CHARS TO DMA.
INC ERRNBR ;SET THE ERROR NUMBER TO 5804.
JSR PC,DMABUF ;PERFORM THE DMA FROM ADDR #BUFBAS,THIS SUBR
;PRODUCES ERRORS >>>> 5804 THRU 5805 <<<<.
BCS .+6 ;CONTINUE IF SUCCESSFUL.
JMP 504 ;REPORT THE ERROR IF ONE OCCURED.

; CALCULATE THE TIME-OUT VALUE FOR THE RX-INT. SET UP THE RXTIMER, AND
; WAIT FOR THE RX-INT.
;-
MOV R5,R1 ;COPY THE RXTIMER VALUE * 1.
ASL R1 ;MULTIPLY BY 4 TO OBTAIN,
ASL R1 ;THE TIME-OUT FOR THE RX-INT.
CLRB #CSRA ;CLEAR THE IND.ADDR.REG BITS OF THE CSR READY.
;FOR THE WRITE TO THE RXTIMER REG.
MOV R5,R0 ;COPY THE RXTIMER VALUE *1.
DEC R0 ;GET THE RXTIMER VALUE
MOVB R0,#RXTMA ;LOAD THE RXTIMER REG.
MOV #2,R4 ;SET DELAY OF 2 MS.
JSR PC,DELAY ;DELAY TO ALLOW THE RXTIMER VALUE TO UPDATE.
MOV #BIT0,R2 ;INDICATE TO TEST BIT0.
MOV R2,R3 ;INDICATE TO TEST FOR A "1".
MOV #RXINTC,R4 ;PASS ADDR OF WORD TO TEST.
CLR RXINTC ;CLEAR THE RX-INT COUNT.
MOV #BIT06,IESTAT ;SET THE RX-INT-ENBL BIT IN IESTAT.
MOV IESTAT,#CSRA ;ENABLE RX-INTS.
JSR PC,MSLGET ;WAIT FOR THE INT TO OCCUR.
BCS 44 ;AVOID ERROR REPORT IF THE INTERRUPT OCCURED.

; REPORT THE TIME-OUT ERROR. >>>> 5806 <<<<.
;-
MOV R5,R2 ;PASS THE RXTIMER VALUE TO,

```



```

6953 030476 005302          DEC      R2          ;THE ERROR REPORTING ROUTINE.
6954 030500 012701 007265  MOV      #EM5805,R1   ;PASS THE MESSAGE,
6955                                     ; "RXTIMER BAD, TIME-OUT OCCURED WAITING FOR
6956                                     ; THE RX-INT".
6957
6958 030504          ERRDF   5806,EM5801,ER5801 ;REPORT ERROR 5806.
        030504 104455
        030506 013256          TRAP   C$ERDF
        030510 006757          .WORD  5806
        030512 012112          .WORD  EM5801
6959                                     .WORD  ER5801
6960 030514 032767 000100 151466  BIT      #BIT06,OPTION ;HAS EXTENDED ERROR REPORTING BEEN REQUESTED ?
6961 030522 001575          BEQ      60$
6962 030524 000454          BR       6$           ;EXIT THE TEST IF IT HASN'T.
6963                                     ;BRANCH TO TEST ANOTHER RXTIMER VALUE.
6964
6965 ;+
6966 ; CHECK THAT THE INTERRUPT OCCURED WITHIN +/- 20% OF THE RXTIMER VALUE.
6967 ; THIS SUBROUTINE REPORTS ERROR >>>> 5807 <<<<<.
6968 030526 012767 013257 153316 4$:  MOV      #5807.,ERRNBR ;SET THE ERROR NUMBER TO 5807.
6969 030534 010502          MOV      R5,R2       ;PASS THE RXTIMER VALUE TO,
6970 030536 005302          DEC      R2          ;THE "CHECK TIME" SUBR.
6971 030540 004767 163302  JSR      PC,CKRXTM   ;CHECK THE TIME TAKEN AND REPORT ANY ERROR.
6972 030544 005767 151502  TST      EXOERR      ;TEST THE "EXIT ON ERROR" FLAG.
6973 030550 001162          BNE     60$
6974 030552 004767 165636  JSR      PC,RXIE0    ;DISABLE RX-INTS.
6975
6976 ;+
6977 ; DMA ANOTHER CHARACTER TO FILL THE FIFO TO THE 75% LEVEL, AND CHECK THAT THE
6978 ; RX-INT OCCURS IMMEDIATELY.
6979 ;-
6978 030556 016701 000364  MOV      70$,R1      ;PASS THE LINE NUMBER.
6979 030562 012703 000001  MOV      #1,R3       ;PASS THE NUMBER OF CHARS TO DMA.
6980 030566 005267 153260  INC      ERRNBR      ;SET THE ERROR NUMBER TO 5808.
6981 030572 004767 163524  JSR      PC,DMABUF   ;PERFORM THE DMA FROM ADDR #BUFBAS,THIS SUBR
6982                                     ;PRODUCES ERRORS >>>> 5808 THRU 5809 <<<<<.
6983 030576 103145          BCC     50$
6984 030600 005067 151462  CLR      RXINTC      ;REPORT THE ERROR IF ONE OCCURED.
6985 030604 012701 000005  MOV      #5,R1       ;CLEAR THE RX-INT COUNT.
6986 030610 012702 002266  MOV      #RXINTC,R2  ;SET THE TIME-OUT TO 5 MS.
6987 030614 004767 165634  JSR      PC,RXIE1    ;PASS ADDR OF WORD TO TEST.
6988 030620 004767 166612  JSR      PC,WAIBIS   ;ENABLE INTERRUPTS.
6989 030624 103414          BCS     6$           ;WAIT FOR THE INT TO OCCUR.
6990                                     ;AVOID THE ERROR IF AN INTERRUPT OCCURED.
6991
6992 ;+
6993 ; REPORT THE ERROR, RX-INT DID NOT OCCUR IMMEDIATLEY.>>>> 5810 <<<<<.
6994 ;-
6993 030626 010502          MOV      R5,R2       ;PASS THE RXTIMER VALUE.
6994 030630 005302          DEC      R2
6995 030632 012701 007077  MOV      #EM5803,R1   ;PASS THE MESSAGE,
6996                                     ; "RXTIMER BAD, RX-INT DID NOT OCCUR
6997                                     ; IMMEDIATELY WHEN RXFIFO 3/4 FULL".
6998
6999 030636          ERRDF   5810,EM5801,ER5801 ; REPORT ERROR 5810.
        030636 104455          TRAP   C$ERDF
        030640 013262          .WORD  5810
        030642 006757          .WORD  EM5801
        030644 012112          .WORD  ER5801
7000
7001 030646 032767 000100 151334  BIT      #BIT06,OPTION ;HAS EXTENDED ERROR REPORTING BEEN REQUESTED ?
    
```

```

7002 030654 001520          BEQ      60$          ;EXIT THE TEST IF IT HASN'T.
7003
7004
7005
7006
7007 030656 004767 165532
7008 030662 006305
7009 030664 020527 000400
7010 030670 003621
7011
7012
7013
7014
7015 030672 012767 013263 153152
7016 030700 004767 164464
7017 030704 103102
7018 030706 016701 000234
7019 030712 012703 000277
7020 030716 005267 153130
7021 030722 004767 163374
7022
7023 030726 103071
7024 030730 012701 001750
7025 030734 012702 002266
7026 030740 005067 151322
7027 030744 105077 151256
7028
7029 030750 105077 151254
7030 030754 012704 000002
7031 030760 004767 163276
7032 030764 004767 165464
7033 030770 004767 166442
7034 030774 103007
7035
7036
7037
7038 030776 012701 007201
7039
7040
7041
7042 031002
      031002 104455
      031004 013266
      031006 006757
      031010 011762
7043
7044 031012 000441
7045
7046
7047
7048 031014 004767 165374
7049 031020 012767 013267 153024
7050 031026 016701 000114
7051 031032 012703 000001
7052 031036 004767 163260
7053
7054 031042 103023
    
```

```

;+
; SELECT ANOTHER VALUE FOR THE RXTIMER OR IF ALL VALUES HAVE BEEN TESTED THEN
; TEST THE RXTIMER WITH INDEFINATE DELAY SET.
;-
6$: JSR      PC,RXIE0      ;DISABLE INTERRUPTS.
    ASL      R5            ;MULTIPLY (RXTIMER VALUE + 1) BY 2.
    CMP      R5,#256.     ;HAVE ALL VALUES BEEN TESTED ?
    BLE      2$           ;BRANCH AND TEST ANOTHER VALUE IF NOT.
;+
; VERIFY THAT WHEN RXTIMER VALUE IS 0 THE INTERRUPT IS DELAYED INDEFINITELY,
; UNLESS THE RXFIFO IS 75% FULL OR MORE.
;-
    MOV      #5811.,ERRNBR ;SET THE ERROR NUMBER TO 5811.
    JSR      PC,PUFIFO     ;PURGE THE RXFIFO.
    BCC      50$          ;REPORT THE ERROR IF THE FIFO FAILED TO PURGE.
    MOV      70$,R1       ;PASS THE LINE NUMBER.
    MOV      #191.,R3     ;PASS THE NUMBER OF CHARS TO DMA.
    INC      ERRNBR       ;SET THE ERROR NUMBER TO 5812.
    JSR      PC,DMABUF    ;PERFORM THE DMA FROM ADDR #BUFBAS,THIS SUBR
                          ;PRODUCES ERRORS >>>> 5812 THRU 5813 <<<<.
    BCC      50$          ;REPORT THE ERROR IF ONE OCCURED.
    MOV      #1750,R1     ;INDICATE TO TEST BIT0 WITH TIME OUT OF 1 SEC.
    MOV      #RXINTC,R2  ;PASS THE ADDR OF THE WORD TO TEST.
    CLR      RXINTC      ;CLEAR THE RX-INT COUNT.
    CLRB    #CSRA        ;CLEAR THE IND.ADDR.REG BITS OF THE CSR READY,
                          ;FOR THE WRITE TO THE RXTIMER REG.
    CLRB    #RXTMA       ;SET THE VALUE 0 IN THE RXTIMER.
    MOV      #2,R4        ;SET THE DELAY OF 2 MS.
    JSR      PC,DELAY     ;DELAY TO ALLOW THE RXTIMER VALUE TO UPDATE.
    JSR      PC,RXIE1    ;ENABLE RX-INTS.
    JSR      PC,WAIBIS   ;WAIT FOR THE INTERRUPT TO OCCUR.
    BCC      8$           ;AVOID THE ERROR IF NO INTERRUPT.
;+
; REPORT THE ERROR, RX-INT OCCURED WITH RXTIMER VALUE ZERO.>>>> 5814 <<<<.
;-
    MOV      #EM5804,R1   ;PASS THE MESSAGE.
                          ; "RXTIMER BAD, RX-INT OCCURED WITH RXTIMER
                          ; VALUE ZERO".
ERRDF 5814,EM5801,ER0503 ; REPORT ERROR 5814.
TRAP  C$ERDF
      .WORD 5814
      .WORD EM5801
      .WORD ER0503
    BR      60$          ;EXIT THE TEST.
;+
; VERIFY THAT WHEN THE FIFO IS 75% FULL THE INTERRUPT OCURS IMMEDIATELY.
;-
8$: JSR      PC,RXIE0      ;DISABLE RX-INTS.
    MOV      #5815.,ERRNBR ;SET THE ERROR NUMBER TO 5815.
    MOV      70$,R1       ;PASS THE LINE NUMBER.
    MOV      #1,R3        ;PASS THE NUMBER OF CHARS TO DMA.
    JSR      PC,DMABUF    ;PERFORM THE DMA FROM ADDR #BUFBAS,THIS SUBR
                          ;PRODUCES ERRORS >>>> 5815 THRU 5816 <<<<.
    BCC      50$          ;REPORT THE ERROR IF ONE OCCURED.
    
```



```

7055 031044 005067 151216          CLR    RXINTC          ;CLEAR THE RX-INT COUNT.
7056 031050 012701 000005          MOV    #5,R1          ;SET THE TIME-OUT TO 5 MS.
7057 031054 012702 002266          MOV    #RXINTC,R2     ;PASS ADDR OF WORD TO TEST.
7058 031060 004767 165370          JSR    PC,RXIE1        ;ENABLE INTERRUPTS.
7059 031064 004767 166346          JSR    PC,WAIBIS       ;WAIT FOR THE INT TO OCCUR.
7060 031070 103412          BCS    60$            ;EXIT THE TEST IF AN INTERRUPT OCCURED.
7061
7062          ;*
7063          ; REPORT THE ERROR, RX-INT DID NOT OCCUR IMMEDIATLEY.>>>>> 5817 <<<<<.
7064 031072 005002          ;-
7065 031074 012701 007077          CLR    R2              ;PASS THE RXTIMER VALUE.
7066          MOV    #EM5803,R1    ;PASS THE MESSAGE.
7067 031100          ERRDF 5817,EM5801,ER5801 ; REPORT ERROR 5817.
          031100 104455
          031102 013271          TRAP  C$ERDF
          031104 006757          .WORD 5817
          031106 012112          .WORD  EM5801
          .WORD  ER5801
7068
7069 031110 000402          BR     60$            ;EXIT THE TEST.
7070
7071 031112 004767 165554          50$: JSR    PC,TSABRT    ;REPORT NON-RELATED TEST ERROR.
7072 031116 012700 000340          60$: SETPRI #PRI07     ;DISABLE ALL INTERRUPTS.
          031116 104441          MOV    #PRI07,R0
          031122 104441          TRAP  C$SPRI
7073 031124 004767 165264          JSR    PC,RXIE0        ;DISABLE DEVICE RX-INTS.
7074 031130 016700 151060          CLRVEC RXVECA         ;CLEAR DOWN THE RX VECTOR.
          031130 104436          MOV    RXVECA,R0
          031134 104436          TRAP  C$CVEC
7075 031136 005067 151106          CLR    CTRLCF         ;INDICATE THAT WE ARE NOT WITHIN A TEST.
7076 031142          EXIT TST
          031142 104432          TRAP  C$EXIT
          031144 000004          .WORD L10043-.
7077 031146 000000          70$: .WORD 0          ;LOCAL STORAGE FOR LINE NUMBER USED IN THE TEST.
7078 031150          ENDTST
          031150          L10043:
          031150 104401          TRAP  C$ETST
    
```

```

7080 .SBTTL  HARDWARE TEST          - TXACTF -
7081 ;+* *****
7082 ;*                               - TX ACTION FIFO TEST -
7083 ;*
7084 ;*
7085 ;*   THIS TEST VERIFIES THAT THE DUT'S TX-ACTION FIFO CAN CORRECTLY
7086 ;*   HOLD 16 TX-ACTIONS.  ONE CHARACTER IS TRANSMITTED ON EACH LINE
7087 ;*   USING DMA, THE TX-ACTIONS ARE THEN READ FROM THE FIFO, VERIFYING
7088 ;*   THAT THEY ARE IN THE CORRECT ORDER AND THAT THERE ARE 16 OF THEM.
7089 ;*   THE TEST ALSO VERIFIES THAT THE DUT WILL NOT SEND TX-INTS AFTER
7090 ;*   THE TX ACTION FIFO HAS BEEN EMPTIED.
7091 ;*   THIS TEST IS PERFORMED IN INTERNAL LOOPBACK ON ALL LINES.
7092 ;*
7093 ;- *****
7094 031152      BGNTST
7095 031152
7096 031152      012700  000240      T15::
7097 031156      104441
7098
7099 031160      000017      TNUM == TNUM + 1      ;INCREMENT ASSEMBLY TIME TEST COUNTER
7100 031166      012767  000017  151066      MOV    #TNUM,TSTNUM      ;SET UP THE TEST NUMBER.
7101 031174      012767  177777  151054      MOV    #-1,CTRLCF       ;INDICATE THAT WE ARE IN A TEST.
7102 031202      012767  000001  152646      MOV    #1,ERRTYP        ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
7103 031210      012767  013415  152642      MOV    #5901,ERRNBR     ;SET THE ERROR NUMBER TO 5901.
7104 031216      012767  007346  152636      MOV    #EM5901,ERRMSG   ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
7105
7106
7107
7108
7109
7110
7111 031224      004767  162766      JSR    PC,CLNRST        ;RESET THE DHU-11 REPORT ANY ERRORS FOUND.
7112 031230      103402
7113 031232      000167  000474      BCS    .+6              ;SKIP EXIT OF TEST IF NO FATAL ERROR FOUND.
7114
7115
7116
7117
7118
7119 031236      012705  177777      JMP    60$              ;EXIT THE TEST IF FATAL ERROR FOUND.
7120 031242      012700  000204
7121
7122 031246      004767  166300      ;+
7123 031252      012700  177670      ; SET INTERNAL LOOPBACK ON ALL LINES AND ENABLE RECIEVERS.  SET UP THE
7124 031256      004767  166320      ; LPR'S TO 38.4K BAUD, 8 BITS/CHARA, ODD PARITY, 2 STOP BITS.
7125 031262      012704  000012
7126 031266      004767  162770      ;-
7127
7128
7129
7130
7131 031272      005001      MOV    #MAPLNS,R5       ;INDICATE TO SET UP ALL LINES.
7132 031274      012702  002650      MOV    #204,R0          ;PASS PARAMETER FOR INTERNAL LOOPBACK.
7133 031300      012703  000001      MOV    #204,R0          ;ENABLE RECIEVERS.
7134
7135
7136
7137
7138
7139
7140
7141
7142
7143
7144
7145
7146
7147
7148
7149
7150
7151
7152
7153
7154
7155
7156
7157
7158
7159
7160
7161
7162
7163
7164
7165
7166
7167
7168
7169
7170
7171
7172
7173
7174
7175
7176
7177
7178
7179
7180
7181
7182
7183
7184
7185
7186
7187
7188
7189
7190
7191
7192
7193
7194
7195
7196
7197
7198
7199
7200
7201
7202
7203
7204
7205
7206
7207
7208
7209
7210
7211
7212
7213
7214
7215
7216
7217
7218
7219
7220
7221
7222
7223
7224
7225
7226
7227
7228
7229
7230
7231
7232
7233
7234
7235
7236
7237
7238
7239
7240
7241
7242
7243
7244
7245
7246
7247
7248
7249
7250
7251
7252
7253
7254
7255
7256
7257
7258
7259
7260
7261
7262
7263
7264
7265
7266
7267
7268
7269
7270
7271
7272
7273
7274
7275
7276
7277
7278
7279
7280
7281
7282
7283
7284
7285
7286
7287
7288
7289
7290
7291
7292
7293
7294
7295
7296
7297
7298
7299
7300
7301
7302
7303
7304
7305
7306
7307
7308
7309
7310
7311
7312
7313
7314
7315
7316
7317
7318
7319
7320
7321
7322
7323
7324
7325
7326
7327
7328
7329
7330
7331
7332
7333
7334
7335
7336
7337
7338
7339
7340
7341
7342
7343
7344
7345
7346
7347
7348
7349
7350
7351
7352
7353
7354
7355
7356
7357
7358
7359
7360
7361
7362
7363
7364
7365
7366
7367
7368
7369
7370
7371
7372
7373
7374
7375
7376
7377
7378
7379
7380
7381
7382
7383
7384
7385
7386
7387
7388
7389
7390
7391
7392
7393
7394
7395
7396
7397
7398
7399
7400
7401
7402
7403
7404
7405
7406
7407
7408
7409
7410
7411
7412
7413
7414
7415
7416
7417
7418
7419
7420
7421
7422
7423
7424
7425
7426
7427
7428
7429
7430
7431
7432
7433
7434
7435
7436
7437
7438
7439
7440
7441
7442
7443
7444
7445
7446
7447
7448
7449
7450
7451
7452
7453
7454
7455
7456
7457
7458
7459
7460
7461
7462
7463
7464
7465
7466
7467
7468
7469
7470
7471
7472
7473
7474
7475
7476
7477
7478
7479
7480
7481
7482
7483
7484
7485
7486
7487
7488
7489
7490
7491
7492
7493
7494
7495
7496
7497
7498
7499
7500
7501
7502
7503
7504
7505
7506
7507
7508
7509
7510
7511
7512
7513
7514
7515
7516
7517
7518
7519
7520
7521
7522
7523
7524
7525
7526
7527
7528
7529
7530
7531
7532
7533
7534
7535
7536
7537
7538
7539
7540
7541
7542
7543
7544
7545
7546
7547
7548
7549
7550
7551
7552
7553
7554
7555
7556
7557
7558
7559
7560
7561
7562
7563
7564
7565
7566
7567
7568
7569
7570
7571
7572
7573
7574
7575
7576
7577
7578
7579
7580
7581
7582
7583
7584
7585
7586
7587
7588
7589
7590
7591
7592
7593
7594
7595
7596
7597
7598
7599
7600
7601
7602
7603
7604
7605
7606
7607
7608
7609
7610
7611
7612
7613
7614
7615
7616
7617
7618
7619
7620
7621
7622
7623
7624
7625
7626
7627
7628
7629
7630
7631
7632
7633
7634
7635
7636
7637
7638
7639
7640
7641
7642
7643
7644
7645
7646
7647
7648
7649
7650
7651
7652
7653
7654
7655
7656
7657
7658
7659
7660
7661
7662
7663
7664
7665
7666
7667
7668
7669
7670
7671
7672
7673
7674
7675
7676
7677
7678
7679
7680
7681
7682
7683
7684
7685
7686
7687
7688
7689
7690
7691
7692
7693
7694
7695
7696
7697
7698
7699
7700
7701
7702
7703
7704
7705
7706
7707
7708
7709
7710
7711
7712
7713
7714
7715
7716
7717
7718
7719
7720
7721
7722
7723
7724
7725
7726
7727
7728
7729
7730
7731
7732
7733
7734
7735
7736
7737
7738
7739
7740
7741
7742
7743
7744
7745
7746
7747
7748
7749
7750
7751
7752
7753
7754
7755
7756
7757
7758
7759
7760
7761
7762
7763
7764
7765
7766
7767
7768
7769
7770
7771
7772
7773
7774
7775
7776
7777
7778
7779
7780
7781
7782
7783
7784
7785
7786
7787
7788
7789
7790
7791
7792
7793
7794
7795
7796
7797
7798
7799
7800
7801
7802
7803
7804
7805
7806
7807
7808
7809
7810
7811
7812
7813
7814
7815
7816
7817
7818
7819
7820
7821
7822
7823
7824
7825
7826
7827
7828
7829
7830
7831
7832
7833
7834
7835
7836
7837
7838
7839
7840
7841
7842
7843
7844
7845
7846
7847
7848
7849
7850
7851
7852
7853
7854
7855
7856
7857
7858
7859
7860
7861
7862
7863
7864
7865
7866
7867
7868
7869
7870
7871
7872
7873
7874
7875
7876
7877
7878
7879
7880
7881
7882
7883
7884
7885
7886
7887
7888
7889
7890
7891
7892
7893
7894
7895
7896
7897
7898
7899
7900
7901
7902
7903
7904
7905
7906
7907
7908
7909
7910
7911
7912
7913
7914
7915
7916
7917
7918
7919
7920
7921
7922
7923
7924
7925
7926
7927
7928
7929
7930
7931
7932
7933
7934
7935
7936
7937
7938
7939
7940
7941
7942
7943
7944
7945
7946
7947
7948
7949
7950
7951
7952
7953
7954
7955
7956
7957
7958
7959
7960
7961
7962
7963
7964
7965
7966
7967
7968
7969
7970
7971
7972
7973
7974
7975
7976
7977
7978
7979
7980
7981
7982
7983
7984
7985
7986
7987
7988
7989
7990
7991
7992
7993
7994
7995
7996
7997
7998
7999
8000

```



```

7134 031304 012704 000005      MOV      #5,R4      ;PASS THE DELAY TIME OF 5 MILLI SECS.
7135 031310 005267 152536      INC      ERRNBR     ;SET THE ERROR NUMBER TO 5902.
7136 031314 004767 163060      JSR      PC,DODMA   ;TRANSMIT THE DATA PATTERN.
7137 031320 103402                BCS      .+6        ;CONTINUE IF SUCCESSFUL.
7138 031322 000167 000400      JMP      50$        ;ABORT THE TEST IF ERROR FOUND DURING DMA TX.
7139
7140
7141      ;+
      ; WAIT FOR THE DMA TO COMPLEATE BEFORE INITIATING ANOTHER.
7142 031326 004767 162730      JSR      PC,DELAY   ;WAIT 5 MILLI SECS FOR THE DMA TO COMPLEATE.
7143 031332 005201                INC      R1         ;INCREMENT THE LINE NUMBER.
7144 031334 022701 000020      CMP      #16.,R1   ;BRANCH TO INITIATE ANOTHER DMA IF
7145 031340 001365                BNE      2$         ;NOT ALL LINES SERVED.
7146
7147      ;+
      ; READ THE TX-ACTIONS FROM THE TX_ACTION FIFO AND VERIFY THAT THEY OCCURED
7148      ; IN THE CORRECT ORDER.
7149      ;-
7150 031342 005267 152504      INC      ERRNBR     ;SET THE ERROR NUMBER TO 5903.
7151 031346 012703 007402      MOV      #EM5902,R3 ;SET THE ERROR MESSAGE TO,
7152
7153 031352 005001                CLR      R1         ; "TX-ACTION RECIEVED FROM THE WRONG LINE".
7154 031354 017702 150646      MOV      @CSRA,R2  ;CLEAR THE LINE NUMBER.
7155 031360 100150                BPL      14$        ;READ THE CSR.
7156 031362 000302                SWAB    R2          ;BRANCH TO REPORT ERROR >>5904<<, IF NO TX-ACT.
7157 031364 042702 177760      BIC      #177760,R2 ;PUT THE TX LINE NUMBER IN THE LOW BYTE.
7158 031370 020201                CMP      R2,R1     ;CLEAR THE CLUTTER FROM THE LINE NUMBER.
7159
7160 031372 001405                BEQ      6$         ;COMPARE THE ACTUAL LINE NUMBER OF THE
7161 031374 031374 104460      ERROR    6$        ;TX-ACTION WITH THE EXPECTED NUMBER.
7162 031376 032767 000100 150604  BIT      @BIT06,OPTION ;SKIP THE ERROR REPORT IF CORRECT.
7163 031404 001552                BEQ      60$        ;REPORT THE ERROR >>>>> 5903 <<<<<.
7164 031406 005201                INC      R1         ;EXIT IF EXTENDED ERROR REPORTING HAS NOT
7165 031410 022701 000020      CMP      #16.,R1   ;BEEN REQUESTED.
7166 031414 001357                BNE      4$         ;INCREMENT THE EXPECTED LINE NUMBER.
7167
7168      ;+
7169      ; 16 TX-ACTIONS HAVE BEEN READ, THE TX-ACTION BIT SHOULD NOW BE CLEAR.
7170      ; CHECK THAT IT IS CLEAR, IF IT ISN'T THEN COUNT THE NUMBER OF EXTRA
7171      ; TX-ACTIONS RECIEVED AND REPORT THE ERROR.
7172      ;-
7173 031416 005777 150604      TST      @CSRA     ;READ THE CSR.
7174 031422 100024                BPL      10$        ;BRANCH IF THE TX-ACTION BIT IS CLEAR, TO
7175
7176 031424 012767 013421 152420  MOV      #5905.,ERRNBR ;TEST THE TX-INTERRUPTS.
7177 031432 012702 000021      MOV      #17.,R2   ;SET THE ERROR NUMBER TO 5905.
7178 031436 005777 150564      TST      @CSRA     ;SET R2 TO BE THE NUMBER OF TX-ACTIONS FOUND.
7179 031442 100123                BPL      16$        ;READ THE CSR.
7180
7181 031444 005202                INC      R2         ;BRANCH AND REPORT ERROR IF THE TX-ACTION FIFO,
7182 031446 022702 000145      CMP      #101.,R2  ;FINALLY CLEARED.
7183 031452 001371                BNE      8$         ;INCREMENT THE NUMBER OF TX-ACTIONS FOUND.
7184
7185      ;+
7186      ; REPORT THE ERROR "TX-ACTION FIFO WOULD NOT EMPTY"
7187      ;-
7188 031454 005267 152372      INC      ERRNBR     ;SET THE ERROR NUMBER TO 5906.
7189 031460 012701 007570      MOV      #EM5904,R1 ;SET THE ERROR MESSAGE TO.
    
```

```

7190
7191 031464 012767 011762 152364      MOV    #ER0503,ERRBLK ; "TX-ACTION FIFO WOULD NOT EMPTY"
7192 031472 000513                    BR     188             ;SET UP THE ERROR REPORTING ROUTINE.
7193                                     ;GO REPORT THE ERROR.
7194                                     ;*
7195                                     ; NOW VERIFY THAT NO TX_INTS OCCUR AFTER THE TX_ACTION FIFO HAS BEEN EMPTIED.
7196                                     ; OF TX_ACTIONS, I.E. NO INTERRUPTS OCCUR WITH THE TX_ACTION BIT CLEAR.
7197                                     ;-
7198 031474 005001      108:    CLR    R1                ;PASS THE NUMBER OF THE FIRST LINE
7199
7200                                     ;*
7201                                     ; INITIATE A DMA ON ALL LINES AND WAIT FOR ALL DMA'S TO COMPLETE.
7202                                     ;-
7203 031476 012767 015423 152346      MOV    #5907,ERRNBR   ;SET THE ERROR NUMBER TO 5907.
7204 031504 012702 002650                    MOV    #BUFBA5,R2     ;PASS THE START OF THE DMA PATTERN TO TX.
7205 031510 012703 000001                    MOV    #1,R3          ;PASS THE LENGTH OF THE DATA PATTERN.
7206 031514 004767 162660      128:    JSR    PC,DODMA       ;TRANSMIT THE DATA PATTERNS.
7207 031520 103102                    BCC    508            ;ABORT THE TEST IF ERROR FOUND DURING DMA TX.
7208 031522 005201                    INC    R1             ;INCREMENT THE LINE NUMBER.
7209 031524 022701 000020                    CMP    #16.,R1       ;BRANCH TO INITIATE ANOTHER DMA IF.
7210 031530 001371                    BNE    128           ;ALL LINES NOT SERVED.
7211 031532 012704 000144                    MOV    #100.,R4      ;SET THE DELAY OF 100 MILLI SECS.
7212 031536 004767 162520                    JSR    PC,DELAY      ;WAIT FOR THE DMA'S TO COMPLETE.
7213
7214                                     ;*
7215                                     ; SET UP THE INTERRUPT SERVICE ROUTINE THAT WILL READ THE TX_ACTION FIFO
7216                                     ; UNTIL EMPTY AND CHECK FOR ANY SUBSEQUENT INTERRUPTS WITH NO TX_ACTION.
7217                                     ; ENABLE TX INTERRUPTS.
7218                                     ;-
7218 031542 005067 150524                    CLR    TXINTC        ;CLEAR THE TX INT COUNTER.
7219 031546 005067 150522                    CLR    TXINTF        ;CLEAR THE TX INT FLAGS.
7220
7221                                     SETVEC TXVECA,@TXAINT,@PRI06
7221 031552 012746 000300
7221 031552 012746 017734
7221 031556 016746 150430
7221 031562 016746 000003
7221 031566 012746 000003
7221 031572 104437
7221 031574 062706 000010
7222 031600 012700 000200      SETPRI @PRI04        ;ALLOW DEVICE INTERRUPTS.
7222 031600 104441
7222 031604 004767 165444      JSR    PC,TXIE1     ;ENABLE TX INTERRUPTS.
7223
7224                                     ;*
7225                                     ; WAIT FOR THE INTERRUPTS TO OCCUR
7226                                     ;-
7227 031612 012704 000005                    MOV    #5,R4         ;SET THE DELAY FOR 5 MILLI SECS.
7228 031616 004767 162440                    JSR    PC,DELAY      ;DELAY FOR 5 MS.
7229
7230                                     ;*
7231                                     ; DISABLE INTERRUPTS AND CLEAR DOWN THE INTERRUPT SERVICE ROUTINE.
7232                                     ;-
7232 031622 012700 000340      SETPRI @PRI07        ;DISABLE ALL INTERRUPTS.
7232 031622 104441
7232 031626 004767 165362      JSR    PC,TXIE0     ;DISABLE DUT TX INTERRUPTS
7233 031630 016700 150356      CLRVEC TXVECA       ;CLEAR THE TX INT VECTOR
7234 031634 104436
7234 031634 016700 150356
7234 031640 104436
    
```





7269  
 7270  
 7271  
 7272  
 7273  
 7274  
 7275  
 7276  
 7277  
 7278  
 7279  
 7280  
 7281  
 7282 031740  
 031740  
 7283  
 7284 031740  
 031740 012700 000240  
 031744 104441  
 7285 000020  
 7286 031746 012767 000020 150300  
 7287 031754 012767 177777 150266  
 7288 031762 012767 000001 152060  
 7289 031770 012767 013561 152054  
 7290 031776 012767 007754 152050  
 7291 032004 005067 150602  
 7292 032010 005067 150236  
 7293 032014 012700 002614  
 7294 032020 004767 162214  
 7295  
 7296  
 7297  
 7298  
 7299  
 7300 032024 004767 162166  
 7301 032030 103402  
 7302 032032 000167 000722  
 7303  
 7304  
 7305  
 7306  
 7307  
 7308 032036 012705 177777  
 7309 032042 004767 164760  
 7310 032046 016705 150146  
 7311 032052 012700 000204  
 7312  
 7313 032056 004767 165470  
 7314 032062 012700 177670  
 7315 032066 004767 165510  
 7316 032072 012704 000012  
 7317 032076 004767 162160  
 7318  
 7319  
 7320  
 7321  
 7322

```

.SBTTL  HARDWARE TEST          - TXFIFO -
; ** *****
; *
; *   THIS TEST IS USED TO VERIFY THAT THE DUT'S TRANSMIT FIFO'S CAN HOLD
; *   64 CHARACTERS AND THAT ONLY ONE TX INTERRUPT OCCURS FOR ALL 64
; *   CHARACTERS.  THE TEST ALSO EXERSISES THE BYTE SWAPPER BY USING
; *   ALTERNATE WORD AND BYTE WRITES TO THE TX FIFO, AS WELL AS CHECKING THAT
; *   THE FIFOSIZE REGISTER REPORTS THE NUMBER OF CHARACTERS IN THE FIFO
; *   CORRECTLY.  ANY BMP CODES FOUND ARE SAVED ON THE QUE TO BE REPORTED
; *   LATER.
; *   THE TEST IS PERFORMED IN INTERNAL LOOPBACK ON ALL ACTIVE LINES.
; -- *****

BGNTST

                                T16::
SETPRI  #PRI05                ;ALLOW LTC INTERRUPTS.

                                MOV      #PRI05,R0
                                TRAP    C$SPRI

TNUM  == TNUM + 1              ;INCREMENT ASSEMBLY TIME TEST COUNTER
MOV   #TNUM,TSTNUM            ;SET UP THE TEST NUMBER.
MOV   #-1,CTRLCF              ;INDICATE THAT WE ARE IN A TEST.
MOV   #1,ERRTYP               ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
MOV   #6001,ERRNBR            ;SET THE ERROR NUMBER TO 6001.
MOV   #EM6001,ERRMSG          ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
CLR   ERSMRF                  ;CLEAR THE ERROR SUMMARY FLAGS.
CLR   EXOERR                  ;CLEAR THE "EXIT ON ERROR" FLAG.
MOV   #ERCNTB,R0              ;SET UP THE START ADDRESS FOR THE BLOCK.
JSR   PC,CLR16W               ;CLEAR THE BLOCK OF 16 WORDS.

; *
; *   RESET THE DUT TO A KNOWN STATE, REMOVE ANY STATUS CODES IN THE FIFO.
; *   CLEAR THE RX AND TX ENABLE BITS IN THE CSR.
; *   THIS SUBROUTINE REPORTS ERROR >>>> 6001 <<<<<.
; -
JSR   PC,CLRST                ;RESET THE DHU-11 REPORT ANY ERRORS FOUND.
BCS   .+6                     ;SKIP EXIT OF TEST IF NO FATAL ERROR FOUND.
JMP   62H                     ;EXIT THE TEST IF FATAL ERROR FOUND.

; *
; *   SET INTERNAL LOOPBACK ON ALL ACTIVE LINES AND ENABLE RECIEVERS.  SET UP THE
; *   LPR'S TO 38.4K BAUD, 8 BITS/CHARA, ODD PARITY, 2 STOP BITS.  DISABLE
; *   TRANSMITTERS ON ALL LINES.
; -
MOV   #MAPLNS,R5              ;INDICATE TO DISABLE ALL LINES.
JSR   PC,TXDSBL               ;DISABLE TX ON ALL LINES.
MOV   #ACTLNS,R5              ;INDICATE TO SET UP ACTIVE LINES ONLY.
MOV   #204,R0                 ;PASS PARAMETER FOR INTERNAL LOOPBACK,
                                ;ENABLE RECIEVERS.
JSR   PC,WTWLNLC              ;INITIALISE THE LINE CONTROL REGS.
MOV   #177670,R0              ;PASS THE LPR CONTENTS.
JSR   PC,WTWLPRL              ;SET THE LPR'S TO 38.4K BAUD.
MOV   #10.,R4                 ;PASS DELAY TIME OF 10 MILLI SECS.
JSR   PC,DELAY                ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.

; *
; *   SET UP THE TX INTERRUPT SERVICE ROUTINE AND VECTOR.  THE ROUTINE COUNTS
; *   THE NUMBER OF INTERRUPTS AND CHECKS FOR ANY INTERRUPTS OCCURING WITH
; *   NO TX-ACTION.
; -

```



```

7323 032102
      032102 012746 000300
      032106 012746 017734
      032112 016746 150100
      032116 012746 000003
      032122 104437
      032124 062706 000010
7324 032130 004767 165122
7325
7326
7327
7328
7329
7330
7331 032134 016705 150060
7332 032140 005001
7333
7334 032142 000241
7335 032144 006005
7336 032146 103067
7337 032150 110177 150052
7338 032154 010103
7339 032156 000303
7340
7341
7342
7343
7344 032160 012700 000003
7345 032164 010377 150044
7346 032170 105203
7347 032172 110377 150036
7348 032176 062703 000401
7349 032202 005300
7350 032204 001367
7351 032206 005002
7352 032210 117702 150020
7353 032214 122702 000067
7354 032220 001425
7355
7356
7357
7358 032222 010104
7359 032224 012701 000067
7360 032230 010346
7361 032232 012767 013562 151612
7362 032240 012703 010000
7363
7364 032244 012767 012276 151604
7365 032252
      032252 104460
7366 032254 012603
7367 032256 010401
7368 032260 032767 000100 147722
7369 032266 001002
7370 032270 000167 000444
7371
7372

```

```

      SETVEC TXVECA,@TXAINT,@PRI06
      MOV @PRI06,-(SP)
      MOV @TXAINT,-(SP)
      MOV TXVECA,-(SP)
      MOV @3,-(SP)
      TRAP C#SVEC
      ADD @10,SP
      JSR PC,TXIE1 ;SET THE TX-INT ENABLE BIT IN THE CSR.
;
; WRITE 64 CHARACTERS TO ALL TXFIFO'S USING ALTERNATE WORD/BYTE WRITES
; TO EXERSISE THE BYTE SWAPPER. AFTER THE FIRST 9 CHARACTERS HAVE BEEN
; WRITTEN CHECK THAT THE FIFOSIZE REGISTER SHOWS THE CORRECT NUMBER OF
; FREE BYTES IN THE FIFO.
;
      MOV ACTLNS,R5 ;SET UP THE ACTIVE LINE BIT MAP.
      CLR R1 ;SET UP THE FIRST LINE NUMBER.
2$:
      CLC ;CLEAR THE CARRY BIT READY FOR THE ROTATION.
      ROR R5 ;ROTATE THE ACTIVE LINE BIT MAP INTO THE CARRY.
      BCC 10$ ;AVOID TESTING THIS LINE IF ITS INACTIVE.
      MOVB R1,@CSRA ;LOAD THE LINE NUMBER OF THE UUT INTO THE CSR.
      MOV R1,R3 ;INITIALISE THE DATA PATTERN FOR THIS LINE BY
      SWAB R3 ;PUTTING THE LINE NUMBER IN THE HIBYTE AND
      ;CLEARING THE LOBYTE.
;
; LOAD 9 CHARACTERS INTO THE TXFIFO AND CHECK THE FIFOSIZE REGISTER.
;
      MOV @3,R0 ;LOOP COUNT.
4$:
      MOV R3,@FDATA ;MOVE A WORD OF DATA INTO THE FIFO.
      INCB R3 ;INCREMENT THE LOBYTE OF THE DATA PATTERN.
      MOVB R3,@FDATA ;MOVE A BYTE OF DATA INTO THE FIFO.
      ADD @401,R3 ;INCREMENT THE HIGH AND LOW BYTE OF THE DATA.
      DEC R0 ;DECREMENT THE LOOP COUNT.
      BNE 4$ ;BRANCH IF NOT ALL 9 CHARACTERS WRITTEN.
      CLR R2 ;CLEAR THE UPPER AND LOWER BYTE OF R2.
      MOVB @FSLSA,R2 ;READ THE FIFOSIZE REGISTER.
      CMPB @55.,R2 ;COMPARE THE EXPECTED SIZE WITH THE ACTUAL.
      BEQ 6$ ;AVOID THE ERROR REPORT IF THE SIZE IS CORRECT.
;
; REPORT THE ERROR, INCORRECT VALUE. >>>> 6002 <<<<<.
;
      MOV R1,R4 ;PASS THE LINE NUMBER TO THE ERROR ROUTINE.
      MOV @55.,R1 ;PASS THE EXPECTED FIFO SIZE.
      MOV R3,-(SP) ;SAVE THE DATA PATTERN.
      MOV @6002.,ERRNBR ;SET THE ERROR NUMBER TO 6002.
      MOV @EM6002,R3 ;PASS THE MESSAGE.
      MOV @ER6001,ERRBLK ;"INCORRECT VALUE IN FIFOSIZE REGISTER".
      ERROR ;SET THE ERROR REPORTING ROUTINE.
      TRAP C#ERROR
      MOV (SP),R3 ;RESTORE THE PATTERN.
      MOV R4,R1 ;RESTORE THE LINE NUMBER.
      BIT @BIT06,OPTION ;HAS EXTENDED ERROR REPORTING BEEN REQUESTED ?
      BNE 6$ ;CONTINUE IF IT HAS.
      JMP 60$ ;EXIT THE TEST IF IT HASN'T.
;
; CONTINUE FILLING UP THE FIFC UNTIL 64 CHARACTERS HAVE BEEN LOADED.

```





```

7426 032500 001424          BEQ      16$          ;AVOID THE ERROR IF ONLY ONE INTERRUPT.
7427                          ;*
7428                          ; REPORT THE ERROR, MORE THAN ONE INTERRUPT. >>>> 6006 <<<<<.
7429                          ;-
7430 032502 016702 147564    MOV      TXINTC,R2      ;PASS THE ACTUAL NUMBER OF INTERRUPTS.
7431 032506 010104          MOV      R1,R4         ;PASS THE LINE NUMBER.
7432 032510 012701 000001    MOV      #1,R1        ;PASS THE EXPECTED NUMBER OF INTS.
7433 032514 010346          MOV      R3,-(SP)      ;SAVE THE DATA PATTERN.
7434 032516 012703 010040    MOV      @EM6003,R3   ;PASS THE MESSAGE,
7435                          ; "MORE THAN ONE TX-INT OCCURED FROM A FULL
7436                          ; TX FIFO".
7437 032522 005267 151324    INC      ERRNBR        ;SET THE ERROR NUMBER TO 6006.
7438 032526 012767 012276 151322 MOV      @ER6001,ERRBLK ;SET UP THE ERROR BLOCK.
7439 032534          ERROR
      032534 104460
7440 032536 012603          MOV      (SP)+,R3     ;RESTORE THE DATA PATTERN. TRAP C$ERROR
7441 032540 010401          MOV      R4,R1        ;RESTORE THE LINE NUMBER.
7442 032542 032767 000100 147440 BIT      @BIT06,OPTION ;HAS EXTENDED ERROR REPORTING BEEN REQUESTED ?
7443 032550 001473          BEQ      60$          ;EXIT THE TEST IF IT HAS.
7444
7445
7446
7447                          ;*
7448                          ; READ THE CHARACTERS FROM THE RXFIFO AND VERIFY THEY ARE CORRECT AND WERE
7449                          ; RECIEVED ON THE CORRECT LINE.
7450                          ; THIS SUBROUTINE REPORTS ERRORS. >>>> 6007 THRU 6008 <<<<<.
7451 032552 012767 013567 151272 16$: MOV      @6007.,ERRNBR ;SET UP THE ERROR NUMBER TO 6007.
7452 032560 005000          CLR      R0           ;INITIALISE THE NUMBER OF CHARS READ COUNT.
7453 032562 012704 000025    MOV      @21.,R4      ;SET UP THE OUTER LOOP COUNT.
7454 032566 012702 000003    MOV      @3,R2        ;SET UP THE INNER LOOP COUNT.
7455 032572 004767 163140 20$: JSR      PC,REPDER   ;READ A CHARACTER FROM THE RXFIFO, VERIFY THAT
7456                          ; IT IS CORRECT AND CAME FROM THE UUT. REPORT
7457                          ; ANY ERRORS. >>>> 6007 THRU 6008 <<<<<.
7458 032576 103022          BCC      22$          ;BRANCH TO REPORT THE ERROR IF THE FIFO EMPTY.
7459 032600 005767 147446    TST      EXOERR       ;TEST THE "EXIT ON ERROR" FLAG.
7460 032604 001055          BNE      60$          ;EXIT THE TEST IF SET, I.E. AN ERROR OCCURED,
7461                          ; AND NO EXTENDED ERROR REPORTING WAS REQUESTED.
7462 032606 005200          INC      R0           ;INCREMENT THE READ CHAR COUNT.
7463 032610 105203          INCB    R3           ;INCREMENT THE LOBYTE OF THE DATA PATTERN.
7464 032612 000303          SWAB   R3           ;SWAP BYTES TO PLACE EXPECTED CHAR IN LOBYTE.
7465 032614 005302          DEC      R2         ;DECREMENT THE INNER LOOP COUNTER.
7466 032616 001365          BNE      20$          ;BRANCH TO READ ANOTHER CHAR IF 3 CHARS HAVE
7467                          ; NOT BEEN READ.
7468 032620 000303          SWAB   R3           ;RESTORE THE DATA BYTES TO THE CORRECT POSITION
7469 032622 005304          DEC      R4         ;DECREMENT THE OUTER LOOP COUNTER.
7470 032624 001360          BNE      18$          ;BRANCH TO READ ANOTHER 3 CHARACTERS IF NOT
7471                          ; ALL 63 HAVE BEEN READ.
7472 032626 004767 163104    JSR      PC,REPDER   ;READ AND CHECK THE LAST CHARACTER.
7473 032632 103004          BCC      22$          ;BRANCH TO REPORT THE ERROR IF THE FIFO EMPTY.
7474 032634 005767 147412    TST      EXOERR       ;TEST THE "EXIT ON ERROR" FLAG.
7475 032640 001037          BNE      60$          ;EXIT THE TEST IF SET.
7476 032642 000422          BR      24$          ;OTHERWISE GO AND TEST ANOTHER LINE.
7477
7478                          ;*
7479                          ; REPORT THE ERROR, NOT ALL CHARACTERS TRANSMITTED. >>>> 6009 <<<<<.
7480 032644 012767 013571 151200 22$: MOV      @6009.,ERRNBR ;SET THE ERROR NUMBER TO 6009.
7481 032652 012703 010243    MOV      @EM6006,R3   ;PASS THE MESSAGE.
    
```





7511  
 7512  
 7513  
 7514  
 7515  
 7516  
 7517  
 7518  
 7519  
 7520  
 7521  
 7522 032766  
 032766  
 7523  
 7524 032766 012767 177777 147254  
 7525 000021  
 7526 032774 012767 000021 147252  
 7527 033002 012767 000001 151040  
 7528 033010 012767 014401 151034  
 7529 033016 012767 010307 151030  
 7530  
 7531  
 7532  
 7533  
 7534  
 7535 033024 004767 161166  
 7536 033030 103165  
 7537  
 7538  
 7539  
 7540  
 7541  
 7542 033032 012705 177777  
 7543 033036 012700 000200  
 7544 033042 004767 164504  
 7545 033046 012704 000012  
 7546 033052 004767 161204  
 7547  
 7548  
 7549  
 7550  
 7551 033056 012700 156430  
 7552 033062 004767 164514  
 7553  
 7554  
 7555  
 7556 033066 016705 147126  
 7557 033072 004767 164024  
 7558  
 7559  
 7560  
 7561  
 7562 033076 005267 150750  
 7563 033102 004767 162344  
 7564 033106 103136  
 7565  
 7566

```

.SBTTL  HARDWARE TEST          - BREAKB -
;*****
;*          - BREAK GENERATION TEST -
;*  THIS TEST VERIFIES THAT ALL SERIAL TRANSMIT LINES CAN GENERATE A BREAK
;*  BY SETTING THE BRK BIT IN THE ASSOCIATED LNCTRL REGISTER.
;*  USE OF THE INTERNAL LOOPBACK FEATURE OF THE DUARTS IS MADE TO MINIMIZE
;*  ANY EXTERNAL EFFECTS CAUSED ON THE SERIAL LINES BY THIS TEST.
;*  FRAMING ERROR DETECTION IS USED TO INDICATE THE PRESENCE OF A BREAK,
;*  BY SETTING THE APPROPRIATE BIT IN THE RBUF REGISTER.
;*****
                                BGNTST
                                T17::
MOV    #-1,CTRLCF              ;INDICATE THAT WE ARE IN A TEST.
TNUM  == TNUM + 1              ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
MOV    #TNUM,TSTNUM            ;SET UP THE TEST NUMBER. (64)
MOV    #1,ERRTYP                ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
MOV    #6401,ERRNBR            ;SET THE FIRST ERROR NUMBER IN ERROR TABLE.
MOV    #EM6401,ERRMSG          ;SET ERROR MESSAGE ADDRESS IN ERRTABL.
;
;*  RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
;*  CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
;*  THIS SUBROUTINE REPORTS ERROR >>>> 6401 <<<<<.
;
JSR    PC,CLNRST                ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
BCC    60$                      ;EXIT TEST IF FATAL ERROR FOUND.
;
;*  SET UP DEVICE UNDER TEST (DUT) TO:
;*  DISABLE TRANSMISSION AND RECEPTION INTERRUPTS.
;*  DELAY FOR 10 MILLI-SECONDS TO ALLOW TIME TO CLEAR ANY BREAKS.
;
MOV    #MAPLNS,R5                ;PASS ACTIVE LINE BIT MAP.
MOV    #200,R0                  ;PASS INTERNAL LOOPBACK MODE.
JSR    PC,WTMLNC                ;SELECT INTERNAL LOOPBACK,DISABLE DMA.
MOV    #10,R4                   ;PASS DELAY TIME OF 10 MILLI SECONDS.
JSR    PC,DELAY                 ;DELAY TO ALLOW ANY BREAKS TO BE CLEARED.
;
;*  SET UP TRANSMISSION AN RECEPTION PARAMETERS FOR ALL LINES.
;*  9600 BAUD,8 CHAR,1 STOPBIT,NO PARITY.
;
MOV    #156430,R0               ;SET UP BAUD RATE,ETC.
JSR    PC,WTWLPB                ;SET COMMUNICATION PARAMETERS ON ALL LINES.
;
;*  ENABLE TRANSMITTERS ON ALL ACTIVE LINES.
;
MOV    #ACTLNS,R5                ;PASS ACTIVE LINE BIT MAP.
JSR    PC,TXENBL                ;ENABLE TRANSMISSIONS ON ALL LINES.
;
;*  PURGE THE FIFO OF ANY UNWANTED CHARACTERS.
;*  THIS ROUTINE REPORTS ERRORS WITH NUMBERS >>>> 6402 THRU 6404 <<<<<.
;
INC    ERRNBR                    ;SET ERROR NUMBER TO 6402.
JSR    PC,PUFIFR                ;PURGE FIFO.
BCC    60$                      ;ABORT TEST IF FIFO WILL NOT CLEAR.
;
;*  VERIFY BREAK GENERATION ON INDIVIDUAL LINES.
    
```

```

7567      ; CLEAR BREAKS ON ALL LINES.
7568      ; DELAY FOR 10 MILLI-SECONDS TO ALLOW TIME FOR ANY BREAKS TO BE CLEARED.
7569      ; SELECT LINE,SET BREAK BIT IN LNCTRL REGISTER.
7570      ; TEST FOR A CHARACTER IN THE FIFO WITH FRAME ERROR.
7571      ;-
7572 033110 005002      2$:      CLR      R2          ;CLEAR LINE COUNTER.
7573 033112 012703 000001      MOV      #1,R3       ;SET UP ACTIVE LINE BIT MASK.
7574 033116 030367 147076      4$:      BIT      R3,ACTLNS  ;CHECK IF THIS LINE IS ACTIVE.
7575 033122 001440      BEQ      8$          ;GO SELECT NEXT LINE IF THIS ONE IS INACTIVE.
7576 033124 012700 000200      MOV      #200,R0     ;SET UP PARAMETER TO CLEAR BREAK BITS.
7577 033130 004767 164416      JSR      PC,WTWLNLC  ;CLEAR BREAK BIT,RESELECT INTERNAL LOOPBACK.
7578 033134 012704 000012      MOV      #10.,R4    ;PASS DELAY TIME OF 10 MILLI SECONDS.
7579 033140 004767 161116      JSR      PC,DELAY    ;DELAY TO ALLOW BREAKS TO BE CLEARED.
7580
7581      ;*
7582      ; SET BREAK BIT ON SELECTED LINE.
7583      ; SET UP PARAMETERS TO TEST FOR THE FRAME ERROR BIT SET IN RBUF.
7584      ; TIME-OUT = 5 MILLI SECONDS.
7585      ; CALL ROUTINE TO CHECK FOR CONDITION FOUND.
7586 033144 010305      ;-
7587 033146 012700 000214      6$:      MOV      R3,R5          ;COPY ACTIVE LINE BIT MASK.
7588 033152 004767 164374      MOV      #214,R0    ;SET BREAK,RESELECT LOOPBACK,ENABLE RECEPTION.
7589      JSR      PC,WTWLNLC ;SET BREAK ON SELECTED LINE.
7590      ;*
7591      ; DELAY FOR 5 MS TO ALLOW TIME FOR BREAK TO BE GENERATED AND RECEIVED.
7592      ; VERIFY RECEPTION OF A CHARACTER WITH FRAME ERROR BIT SET.
7593      ;-
7594 033156 012704 000005      MOV      #5.,R4     ;SET DELAY VALUE TO 5 MILLI SECS.
7595 033162 004767 161074      JSR      PC,DELAY   ;ALLOW TIME FOR CHARACTER RECEPTION.
7596 033166 017700 147036      MOV      @RBUFA,R0  ;GET CHARACTER FROM RBUF REGISTER.
7597 033172 032700 020000      BIT      #BIT13,R0  ;CHECK FOR FRAME ERROR BIT.
7598 033176 001012      BNE      8$         ;SKIP ERROR REPORT IF SET.
7599 033200 012701 010344      MOV      #EM6402,R1 ;SELECT MESSAGE TO BE PRINTED.
7600 033204      ;REPORT ERROR"BREAK NOT RECEIVED ON LINE #NN"
7601 033204 104455      ERRDF 6405,EM6401,ER6401 ;
7602 033206 014405      TRAP  C#ERDF
7603 033210 010307      .WORD 6405
7604 033212 012400      .WORD EM6401
7605      .WORD ER6401
7606
7607      ;*
7608      ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
7609      ;-
7610 033214 032767 000100 146766      BIT      #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
7611 033222 001470      BEQ      60$        ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
7612      ;DURING THE SOFTWARE QUESTIONS.
7613      8$:      ASL      R3          ;SHIFT BIT MASK FOR NEXT LINE.
7614      INC      R2          ;NEXT LINE
7615      CMP      R2,#NUMLNS  ;CHECK FOR MAX LINE COUNT.
7616      BNE      4$          ;IF <>,LOOP TO CHECK NEXT LINE
7617      ;*
7618      ; VERIFY BREAK GENERATION ON ALL LINES SIMULTANEOUSLY.
7619      ; CLEAR BREAKS ON ALL LINES.
7620      ; DELAY FOR 10 MILLI-SECONDS TO ALLOW TIME FOR ANY BREAKS TO BE CLEARED.
7621      ; PURGE THE FIFO.
7622      ; SET BREAK BIT IN LNCTRL REGISTERS ON ALL ACTIVE LINES.
7623      ; TEST FOR CHARACTERS IN THE FIFO WITH FRAME ERROR.
    
```





```

7667
7668
7669
7670
7671
7672
7673
7674
7675
7676
7677
7678
7679
7680
7681 033412
      033412
7682 033412
      033412 012700 000240
      033416 104441
7683      000022
7684 033420 012767 000022 146626
7685 033426 012767 177777 146614
7686 033434 012767 000001 150406
7687 033442 012767 014711 150402
7688 033450 012767 010405 150376
7689
7690
7691
7692
7693
7694 033456 004767 160534
7695 033462 103402
7696 033464 000167 000432
7697
7698
7699
7700
7701 033470 004767 160774
7702 033474 103402
7703 033476 000167 000420
7704 033502 004767 161042
7705
7706
7707
7708
7709
7710
7711
7712
7713 033506 005267 150340
7714 033512 012700 000204
7715 033516 004767 164030
7716 033522 012700 177670
7717 033526 004767 164050
7718 033532 012704 000012
7719 033536 004767 160520
7720 033542 012702 002650

```

```

.SBTTL HARDWARE TEST - NORERR -
;*****
;* - NO OVERRUN ERROR TEST -
;*
;* THIS TEST VERIFIES THAT THE DUT WILL NOT REPORT DATA OVERRUN
;* ERRORS WHEN THEY DO NOT OCCUR.
;* THIS TEST PUTS 256 CHARACTERS IN THE DUT FIFO PLUS 4 IN EACH ACTIVE
;* UART AND VERIFIES THAT NO OVERRUN ERRORS ARE REPORTED.
;* ANY BMP CODE FOUND WILL INVALIDATE THE TEST AND CAUSE IT TO BE ABORTED.
;* HOWEVER THE BMP CODE WILL BE PLACED ON THE BMP CODE QUEUE, TO BE
;* REPORTED LATER.
;*
;*****
BGNTST
SETPRI @PRIOS ;ALLOW LTC INTERRUPTS. T18::
MOV @PRIOS,R0
TRAP C$SPRI
TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
MOV @TNUM,TSTNUM ;SET UP THE TEST NUMBER. (66)
MOV @-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
MOV @1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
MOV @6601,ERRNBR ;SET ERROR NUMBER TO 6601.
MOV @EM6601,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
;
; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
; THIS SUBROUTINE REPORTS ERROR >>>> 6601 <<<<.
;
JSR PC,CLRST ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
BCS .+6 ;SKIP EXIT OF TEST IF NO FATAL ERROR FOUND.
JMP 60$ ;EXIT THE TEST, FATAL ERROR WAS FOUND.
;
; FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
; INITIALIZE THE 256 BYTE DATA PATTERN.
;
JSR PC,FINACT ;FIND AN ACTIVE LINE.
BCS .+6 ;SKIP EXIT OF TEST IF NO FATAL ERROR FOUND.
JMP 60$ ;EXIT THE TEST, FATAL ERROR WAS FOUND.
JSR PC,INDATP ;INITIALISE DATA PATTERN.
;
; TRANSMIT A 265 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
; AT 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
;
; SET INTERNAL LOOPBACK ON THE SELECTED LINE.
; TRANSMIT THE DATA PATTERN ON THE FIRST AVAILABLE ACTIVE LINE.
;
INC ERRNBR ;SET THE ERROR REPORT NUMBER TO 6602.
MOV @204,R0 ;PASS PARAMETER FOR INTERNAL LOPBCK,ENABLE RX.
JSR PC,WTWLNLC ;INITILAISE THE LINE CONTROL REGISTER.
MOV @177670,R0 ;PASS THE LPR CONTENTS.
JSR PC,WTWLPR ;SET THE LPR CONTENTS TO 38.4K BAUD.
MOV @10,R4 ;PASS DELAY TIME OF 10 MILLI SECONDS.
JSR PC,DELAY ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
MOV @BUFBAS,R2 ;PASS THE START OF THE DATA PATTERN TO TX.

```



```

7721 033546 012703 000400
7722 033552 004767 160622
7723 033556 103157
7724
7725
7726
7727
7728 033560 005267 150266
7729 033564 012701 170536
7730 033570 016702 146432
7731 033574 004767 163636
7732 033600 103146
7733 033602 012704 000005
7734 033606 004767 160450
7735
7736
7737
7738
7739 033612 016705 146402
7740 033616 012700 000204
7741 033622 004767 163724
7742 033626 012700 177670
7743 033632 004767 163744
7744 033636 012704 000012
7745 033642 004767 160414
7746
7747 033646 012702 002650
7748 033652 012703 000004
7749 033656 005001
7750 033660 005267 150166
7751 033664 010100
7752 033666 006300
7753 033670 036067 002336 146322
7754 033676 001403
7755 033700 004767 160474
7756 033704 103104
7757 033706 005201
7758 033710 020127 000020
7759 033714 002763
7760
7761 033716 005267 150130
7762 033722 012701 170040
7763 033726 016702 146274
7764 033732 004767 163500
7765 033736 103067
7766 033740 012704 000005
7767 033744 004767 160312
7768
7769
7770
7771
7772 033750 016702 146244
7773 033754 004767 160716
7774 033760 006302
7775 033762 006302
7776 033764 012705 000400
7777 033770 060205

;+
; MOV #BUF MID-BUF BAS,R3 ;PASS THE LENGTH OF THE DATA PATTERN.
; JSR PC,DODMA ;TRANSMIT THE DATA PATTERN.
; BCC 50$ ;EXIT IF ERROR FOUND DURING DMA TX.
;+
; WAIT FOR DMA TO COMPLETE, THEN WAIT FOR THE LAST CHARACTER TO ARRIVE IN
; THE FIFO.
;-
; INC ERRNBR ;SET ERROR NUMBER TO 6603.
; MOV #170536,R1 ;PASS TIME-OUT VALUE OF 350 MILLI SECS.
; MOV CSRA,R2 ;PASS THE ADDRESS OF THE CSR.
; JSR PC,WAIBIS ;WAIT FOR DMA TO COMPLETE, TX ACTION SET.
; BCC 50$ ;ABORT THE TEST IF TIME-OUT ON DMA COMPLETION.
; MOV #5,R4 ;PASS DELAY OF 5 MILLI SECS.
; JSR PC,DELAY ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.

;+
; TRANSMIT 4 CHARACTERS ON EACH ACTIVE LINE.
;-
; MOV ACTLNS,R5 ;ALTER PARAMETERS FOR ALL ACTIVE LINES.
; MOV #204,R0 ;PASS PARAMETER FOR INTERNAL LOPBCK,ENABLE RX.
; JSR PC,WTW LNC ;INITIALISE THE LINE CONTROL REGISTER.
; MOV #177670,R0 ;PASS THE LPR CONTENTS.
; JSR PC,WTW LPR ;SET THE LPR CONTENTS TO 38.4K BAUD.
; MOV #10.,R4 ;PASS DELAY TIME OF 10 MILLI SECONDS.
; JSR PC,DELAY ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.

;+
; MOV #BUF BAS,R2 ;PASS THE START OF THE DATA PATTERN TO TX.
; MOV #4,R3 ;PASS THE LENGTH OF THE DATA PATTERN.
; CLR R1 ;CLEAR THE LINE COUNTER.
; INC ERRNBR ;SET ERROR NUMBER TO 6604.
; MOV R1,R0
; ASL R0
; BIT BITTBL(R0),ACTLNS ;CALCULATE THE LINE OFFSET FROM THE LINE #.
; BEQ 4$ ;TEST FOR THIS LINE BEING ACTIVE.
; JSR PC,DODMA ;SKIP THE TX ON THIS LINE IF IT IS NOT ACTIVE.
; BCC 50$ ;TRANSMIT THE 5 CHAR DATA PATTERN.
; INC R1 ;ABORT IF ERROR FOUND DURING DMA TX.
; CMP R1,#NUMLNS ;INCREMENT THE LINE COUNTER.
; BLT 2$ ;TEST FOR ALL POSSIBLE LINES HANDLED
; ;LOOP IF NOT ALL LINES HANDLED.

;+
; INC ERRNBR ;SET ERROR NUMBER TO 6605.
; MOV #170040,R1 ;PASS TIME-OUT VALUE OF 32 MILLI SECS.
; MOV CSRA,R2 ;PASS THE ADDRESS OF THE CSR.
; JSR PC,WAIBIS ;WAIT FOR A DMA TO COMPLETE, TX ACTION SET.
; BCC 50$ ;ABORT THE TEST IF TIME-OUT ON DMA COMPLETION.
; MOV #5,R4 ;PASS DELAY OF 5 MILLI SECS.
; JSR PC,DELAY ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.

;+
; READ THE FIFO CHECKING FOR OVERRUN ERRORS. REPORT ERRORS IF FOUND.
; ABORT THE TEST IF A BMP CODE WAS FOUND IN THE FIFO.
;-
; MOV ACTLNS,R2
; JSR PC,MAPCNT ;GET THE NUMBER OF ACTIVE LINES.
; ASL R2
; ASL R2 ;MULTIPLY NUMBER OF ACTIVE LINES BY 4.
; MOV #256.,R5
; ADD R2,R5 ;CALCULATE NUMBER OF CHARACTERS TO RX.

```

```

7778 033772 005004
7779 033774 012767 014716 150050 6$: CLR R4 ;CLEAR THE CHARACTER COUNTER.
7780 034002 017702 146222 MOV #6606.,ERRNBR ;SET UP ERROR NUMBER EACH TIME AROUND LOOP.
7781 034006 100036 MOV @RBUFA,R2 ;READ A CHARACTER FROM THE FIFO.
7782 BPL 10$ ;EXIT THE READ LOOP IF THE FIFO IS EMPTY.
7783
7784 ;+
7785 ; CHECK IF THE READ CHARACTER IS A BMP CODE.
7786 ; IF IT IS A BMP CODE SAVE IT ON THE QUEUE TO BE REPORTED LATER, AND
7787 ; ABORT THE TEST.
7787 034010 004767 157762 JSR PC,CHKBMP ;CHECK IF CHARACTER IS A BMP CODE.
7788 034014 103002 BCC 8$ ;BRANCH IF NOT A BMP CODE.
7789 034016 104460 ERROR ;
034016 104460 ; >>>> ERROR #6606 <<<<<.
7790 034020 000440 BR 60$ TRAP C$ERROR
7791 ;EXIT THIS TEST.
7792 034022 005267 150024 8$: INC ERRNBR ;SET ERROR NUMBER TO 6607.
7793 034026 005204 INC R4 ;COUNT THIS CHARACTER.
7794 034030 020405 CMP R4,R5 ;COMPARE # OF CHARS WITH MAX # OF CHARS.
7795 034032 003031 BGT 50$ ;ABORT TEST IF TOO MANY VALID CHARS READ.
7796 034034 032702 040000 BIT @BIT14,R2 ;TEST THE OVERRUN BIT OF THE READ CHAR.
7797 034040 001755 BEQ 6$ ;LOOP TO READ THE NEXT CHAR IF NO ERROR.
7798 034042 005267 150004 INC ERRNBR ;SET ERROR NUMBER TO 6608.
7799 034046 012767 012506 150002 MOV @ER7801,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
7800 034054 012701 010442 MOV @EM6602,R1 ;PASS THE MESSAGE TO BE REPORTED.
7801 034060 010203 MOV R2,R3
7802 034062 000303 SWAB R3
7803 034064 042703 177760 BIC @177760,R3 ;GET FAILING LINE NUMBER.
7804 ;REPORT "OVERRUN ERROR REPORTED WHEN NONE FORCED, ON LINE NN ..."
7805 034070 104460 ERROR ;
034070 104460 ; >>>> ERROR #6608 <<<<<.
7806 TRAP C$ERROR
7807
7808 ;+
7809 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
7810 034072 032767 000100 146110 BIT @BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
7811 034100 001410 BEQ 60$ ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
7812 ; DURING THE SOFTWARE QUESTIONS.
7813
7814 034102 000734 BR 6$ ;LOOP TO READ THE NEXT CHAR.
7815
7816 034104 012767 014721 147740 10$: MOV #6609.,ERRNBR ;SET ERROR NUMBER TO 6609.
7817 034112 020405 CMP R4,R5 ;COMPARE NUMBER OF CHARS READ WITH EXPECTED.
7818 034114 001402 BEQ 60$ ;EXIT TEST WITHOUT ABORT IF CORRECT # OF CHARS.
7819
7820 034116 004767 162550 50$: JSR PC,TSABRT ;ABORT THE TEST, NON-RELATED TEST ERROR FOUND.
7821 034122 005067 146122 60$: CLR CTRLCF ;INDICATE THAT WE ARE NOT WITHIN A TEST.
7822 034126
034126
034126 104401 L10047: TRAP C$ETST
    
```



D10

7824  
 7825  
 7826  
 7827  
 7828  
 7829  
 7830  
 7831  
 7832  
 7833  
 7834  
 7835  
 7836  
 7837  
 7838 034130  
 034130  
 7839 034130 012700 000240  
 034130 104441  
 034134 000023  
 7840  
 7841 034136 012767 000023 146110  
 7842 034144 012767 177777 146076  
 7843 034152 012767 000001 147670  
 7844 034160 012767 015055 147664  
 7845 034166 012767 010514 147660  
 7846  
 7847  
 7848  
 7849  
 7850  
 7851 034174 004767 160016  
 7852 034200 103402  
 7853 034202 000167 000660  
 7854  
 7855  
 7856  
 7857  
 7858 034206 004767 160256  
 7859 034212 103402  
 7860 034214 000167 000646  
 7861 034220 004767 160324  
 7862  
 7863  
 7864  
 7865  
 7866  
 7867  
 7868  
 7869  
 7870 034224 005267 147622  
 7871 034230 012700 000204  
 7872 034234 004767 163312  
 7873 034240 012700 177670  
 7874 034244 004767 163332  
 7875 034250 012704 000012  
 7876 034254 004767 160002  
 7877 034260 012702 002650

```

.SBTTL  HARDWARE TEST          - ORERR -
;-----
;                                     - OVERRUN ERROR TEST -
;
; THIS TEST VERIFIES THAT THE DUT WILL REPORT DATA OVERRUN ERRORS WHEN
; THEY OCCUR.
; THIS TEST PUTS 256 CHARACTERS IN THE DUT FIFO PLUS 5 IN EACH ACTIVE
; UART AND VERIFIES THAT OVERRUN ERRORS ARE REPORTED ON ALL ACTIVE LINES.
; ANY BMP CODE FOUND WILL INVALIDATE THE TEST AND CAUSE IT TO BE ABORTED.
; HOWEVER THE BMP CODE WILL BE PLACED ON THE BMP CODE QUEUE, TO BE
; REPORTED LATER.
;-----
BGNTST
SETPRI  @PRI05                ;ALLOW LTC INTERRUPTS.      T19::
                                MOV      @PRI05,R0
                                TRAP    C@SPRI
TNUM  == TNUM + 1             ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
MOV   @TNUM,TSTNUM           ;SET UP THE TEST NUMBER.      (67)
MOV   @-1,CTRLCF             ;INDICATE THAT WE ARE IN A TEST.
MOV   @1,ERRTYP              ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
MOV   @6701,ERRNBR           ;SET ERROR NUMBER TO 6701.
MOV   @EM6701,ERRMSG         ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
;
; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
; THIS SUBROUTINE REPORTS ERROR >>>> 6701 <<<<.
;
JSR   PC,CLRST               ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
BCS   .+6                    ;SKIP EXIT OF TEST IF NO FATAL ERROR FOUND.
JMP   609                     ;EXIT THE TEST, FATAL ERROR WAS FOUND.
;
; FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
; INITIALIZE THE 256 BYTE DATA PATTERN.
;
JSR   PC,FINACT              ;FIND AN ACTIVE LINE.
BCS   .+6                    ;IF ACTIVE LINE IS FOUND, DON'T ABORT TEST.
JMP   609                     ;ABORT THE TEST, NO ACTIVE LINES WERE FOUND.
JSR   PC,INDATP              ;INITIALISE DATA PATTERN.
;
; TRANSMIT A 265 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
; AT 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
;
; SET INTERNAL LOOPBACK ON THE SELECTED LINE.
; TRANSMIT THE DATA PATTERN ON THE FIRST AVAILABLE ACTIVE LINE.
;
INC   ERRNBR                  ;SET ERROR NUMBER TO 6702.
MOV   @204,R0                 ;PASS PARAMETER FOR INTERNAL LOPBCK,ENABLE RX.
JSR   PC,WTMLNC              ;INITIALISE THE LINE CONTROL REGISTER.
MOV   @177670,R0             ;PASS THE LPR CONTENTS.
JSR   PC,WTMLPR              ;SET THE LPR CONTENTS TO 38.4K BAUD.
MOV   @10,R4                  ;PASS DELAY TIME OF 10 MILLI SECONDS.
JSR   PC,DELAY                ;WAIT FOR LNCTAL AND LPR REGS TO BE UPDATED.
MOV   @BUFBAS,R2              ;PASS THE START OF THE DATA PATTERN TO TX.
    
```

```

7878 034264 012703 000400
7879 034270 004767 160104
7880 034274 103402
7881 034276 000167 000560
7882
7883
7884
7885
7886 034302 005267 147544
7887 034306 012701 170536
7888 034312 016702 145710
7889 034316 004767 163114
7890 034322 103402
7891 034324 000167 000532
7892 034330 012704 000005
7893 034334 004767 157722
7894
7895
7896
7897 034340 016705 145654
7898 034344 012700 000204
7899 034350 004767 163176
7900 034354 012700 177670
7901 034360 004767 163216
7902 034364 012704 000012
7903 034370 004767 157666
7904
7905 034374 012702 002650
7906 034400 012703 000005
7907 034404 005001
7908 034406 005267 147440
7909 034412 010100
7910 034414 006300
7911 034416 036067 002336 145574
7912 034424 001405
7913 034426 004767 157746
7914 034432 103402
7915 034434 000167 000422
7916 034440 005201
7917 034442 020127 000020
7918 034446 002761
7919
7920 034450 005267 147376
7921 034454 012701 170040
7922 034460 016702 145542
7923 034464 004767 162746
7924 034470 103174
7925 034472 012704 000005
7926 034476 004767 157560
7927
7928
7929
7930
7931 034502 012704 000400
7932 034506 012767 015062 147336
7933 034514 017702 145510
7934 034520 100160

```

```

MOV #BUFHID-BUFBAS,R3 ;PASS THE LENGTH OF THE DATA PATTERN.
JSR PC,DODMA ;TRANSMIT THE DATA PATTERN.
BCS .+6 ;IF NO ERROR FOUND DURING DMA TX, DON'T ABORT.
JMP 50$ ;ABORT TEST, ERROR FOUND DURING DMA TX.

;
; WAIT FOR DMA TO COMPLETE, THEN WAIT FOR THE LAST CHARACTER TO ARRIVE IN
; THE FIFO.
;
INC ERRNBR ;SET ERROR NUMBER TO 6703.
MOV #170536,R1 ;PASS TIME-OUT VALUE OF 350 MILLI SECS.
MOV CSRA,R2 ;PASS THE ADDRESS OF THE CSR.
JSR PC,WAIBIS ;WAIT FOR DMA TO COMPLETE, TX ACTION SET.
BCS .+6 ;IF NO TIME-OUT ON DMA COMPLETION, DON'T ABORT.
JMP 50$ ;ABORT TEST, TIME-OUT ON DMA COMPLETION.
MOV #5,R4 ;PASS DELAY OF 5 MILLI SECS.
JSR PC,DELAY ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.

;
; TRANSMIT 5 CHARACTERS ON EACH ACTIVE LINE.
;
MOV ACTLNS,R5 ;ALTER PARAMETERS FOR ALL ACTIVE LINES.
MOV #204,R0 ;PASS PARAMETER FOR INTERNAL LOPBCK,ENABLE RX.
JSR PC,WTWLNCR ;INITIALISE THE LINE CONTROL REGISTER.
MOV #177670,R0 ;PASS THE LPR CONTENTS.
JSR PC,WTWLNCR ;SET THE LPR CONTENTS TO 38.4K BAUD.
MOV #10,R4 ;PASS DELAY TIME OF 10 MILLI SECONDS.
JSR PC,DELAY ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.

MOV #BUFBAS,R2 ;PASS THE START OF THE DATA PATTERN TO TX.
MOV #5,R3 ;PASS THE LENGTH OF THE DATA PATTERN.
CLR R1 ;CLEAR THE LINE COUNTER.
INC ERRNBR ;SET ERROR NUMBER TO 6704.
MOV R1,R0
ASL R0 ;CALCULATE LINE OFFSET FROM THE LINE #.
BIT BITTBL(R0),ACTLNS ;TEST FOR THIS LINE BEING ACTIVE.
BEQ 4$ ;SKIP THE TX ON THIS LINE IF IT IS NOT ACTIVE.
JSR PC,DODMA ;TRANSMIT THE 5 CHAR DATA PATTERN.
BCS .+6 ;IF NO TIME-OUT ON DMA COMPLETION, DON'T ABORT.
JMP 50$ ;ABORT TEST, TIME-OUT ON DMA COMPLETION.
INC R1 ;INCREMENT THE LINE NUMBER COUNTER.
CMP R1,#NUMLNS ;TEST FOR ALL POSSIBLE LINES HANDLED
BLT 2$ ;LOOP IF NOT ALL LINES HANDLED.

INC ERRNBR ;SET ERROR NUMBER TO 6705.
MOV #170040,R1 ;PASS TIME-OUT VALUE OF 32 MILLI SECS.
MOV CSRA,R2 ;PASS THE ADDRESS OF THE CSR.
JSR PC,WAIBIS ;WAIT FOR A DMA TO COMPLETE, TX ACTION SET.
BCC 50$ ;ABORT THE TEST IF TIME-OUT ON DMA COMPLETION.
MOV #5,R4 ;PASS DELAY OF 5 MILLI SECS.
JSR PC,DELAY ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.

;
; READ 256 CHARS FROM THE FIFO CHECKING FOR BMP CODES.
; ABORT THE TEST IF A BMP CODE WAS FOUND IN THE FIFO.
;
MOV #256,R4 ;SET UP THE CHARACTER COUNTER.
MOV #6706,ERRNBR ;SET UP ERROR NUMBER EACH TIME AROUND LOOP.
MOV BRBUFA,R2 ;READ A CHARACTER FROM THE FIFO.
BPL 50$ ;ABORT THE TEST IF DATA.VALID IS CLEAR.

```



```

7935 034522 005267 147324
7936 034526 004767 157244
7937 034532 103551
7938 034534 005304
7939 034536 001363
7940
7941
7942
7943 034540 005004
7944 034542 012700 003710
7945 034546 004767 157466
7946 034552 012767 015064 147272 8:
7947 034560 017702 145444
7948 034564 100047
7949 034566 004767 157204
7950 034572 103531
7951 034574 005267 147252
7952 034600 010200
7953 034602 000300
7954 034604 042700 177760
7955 034610 006300
7956 034612 042702 007400
7957 034616 036067 002336 145374
7958 034624 001516
7959 034626 005267 147220
7960 034632 005760 003710
7961 034636 001006
7962 034640 020227 140000
7963 034644 001414
7964 034646 056004 002336
7965 034652 000411
7966 034654 026027 003710 000004 10:
7967 034662 002077
7968 034664 032702 040000
7969 034670 001402
7970 034672 056004 002336
7971 034676 005260 003710 12:
7972 034702 000723
7973
7974
7975
7976
7977
7978 034704 005001
7979 034706 012767 015067 147136
7980 034714 036167 002336 145276
7981 034722 001415
7982 034724 026127 003710 000002
7983 034732 002453
7984 034734 036104 002336
7985 034740 001006
7986 034742 005267 147104
7987 034746 026127 003710 000002
7988 034754 001042
7989 034756 062701 000002 18:
7990 034762 020127 000040
7991 034766 002747

```

```

INC ERRNBR ;SET ERROR NUMBER TO 6707.
JSR PC,CHKBMP ;CHECK IF CHARACTER IS A BMP CODE.
BCS 24: ;REPORT ERROR AND ABORT TEST IF A BMP CODE.
DEC R4 ;COUNT THIS CHARACTER.
BNE 6: ;LOOP IF NOT 256 CHARS READ FROM FIFO.

; READ THE REMAINING AND VERIFY 1 OVERRUN PLUS 1 CHAR FROM EACH LINE.

CLR R4 ;CLEAR THE OVERRUN ERROR FLAGS.
MOV #RXCNTB,R0
JSR PC,CLR16W ;CLEAR RX CHAR COUNT TABLE.
MOV #6708,ERRNBR ;SET UP ERROR NUMBER EACH TIME AROUND LOOP.
MOV #RBUFA,R2 ;READ A CHARACTER FROM THE FIFO.
BPL 14: ;GO ANALYZE THE RESULTS IF ALL CHARS READ.
JSR PC,CHKBMP ;CHECK IF CHAR IS A BMP CODE.
BCS 24: ;REPORT ERROR AND ABORT TEST IF A BMP CODE.
INC ERRNBR ;SET ERROR NUMBER TO 6709.
MOV R2,R0
SWAB R0
BIC #177760,R0 ;CALCULATE THE LINE NUMBER OF THE CHAR.
ASL R0 ;FORM WORD TABLE OFFSET FOR TABLE ACCESS.
BIC #7400,R2 ;REMOVE LINE NUMBER FROM THE READ CHAR.
BIT BITTBL(R0),ACTLNS ;TEST FOR ACTIVE LINE.
BEQ 50: ;ABORT TEST IF FOR INACTIVE LINE.
INC ERRNBR ;SET ERROR NUMBER TO 6710.
TST RXCNTB(R0) ;CHECK THE RX CHAR COUNTER FOR THIS LINE.
BNE 10: ;IS THIS FIRST CHAR ON LINE?
CMP R2,#140000 ;YES, TEST FOR NULL CHAR WITH OVERRUN.
BEQ 12: ;IS CHAR A NULL?
BIS BITTBL(R0),R4 ;NO, SET THE OVERRUN BIT ERROR FLAG FOR LINE.
BR 12: ;GO COUNT THE CHAR AND CONTINUE.
CMP RXCNTB(R0),#4 ;5TH CHAR ON THIS LINE? YES, ABORT.
BGE 50: ;NO, CHECK OVERRUN BIT.
BIT #BIT14,R2 ;IS OVERRUN BIT CLEAR? YES, GO COUNT CHAR.
BEQ 12: ;NO, SET THE OVERRUN BIT ERROR FLAG FOR LINE.
BIS BITTBL(R0),R4 ;COUNT THIS CHARACTER.
BR 8: ;LOOP UNTIL ALL CHARS ARE READ FROM FIFO.

; TEST FOR ABORT CONDITIONS. ONLY NONE ABORT CONDITIONS ARE:
; 1) 2 CHARS RXED ON A LINE AND NO OVERRUN ERROR BIT FAILURE DETECTED.
; 2) 2 TO 4 CHARS RXED ON A LINE AND AN OVERRUN BIT FAILURE DETECTED.

CLR R1 ;INITIALIZE LINE LOOP, CLEAR LINE OFFSET.
MOV #6711,ERRNBR ;SET UP ERROR NUMBER EACH TIME AROUND LOOP.
BIT BITTBL(R1),ACTLNS
BEQ 18: ;LINE ACTIVE? NO, NEXT LINE.
CMP RXCNTB(R1),#2 ;YES.
BLT 50: ;FEWER THAN 2 CHARS RXED? YES, ABORT.
BIT BITTBL(R1),R4 ;NO.
BNE 18: ;OVERRUN BIT ERROR FLAG SET? YES, NEXT LINE.
INC ERRNBR ;SET LINE NUMBER TO 6712.
CMP RXCNTB(R1),#2
BNE 50: ;NOT 2 CHARS RXED? YES, ABORT, NO, NEXT LINE.
ADD #2,R1 ;SET LINE OFFSET TO THE NEXT LINE.
CMP R1,#NUMLNS*2
BLT 16: ;ALL LINES DONE? NO, LOOP. YES, CONTINUE.

```

```

7992
7993
7994
7995 034770 012767 015071 147054
7996 034776 005001
7997 035000 010102
7998 035002 036104 002336
7999 035006 001415
8000 035010 010103
8001 035012 006203
8002 035014 012767 012506 147034
8003 035022 012701 010546
8004
8005 035026
      035026 104460
8006
8007
8008
8009
8010 035030 032767 000100 145152
8011 035036 001413
8012
8013
8014 035040 010201
8015 035042 046104 002336
8016 035046 001407
8017 035050 062701 000002
8018 035054 000751
8019
8020 035056
8021 035056
      035056 104460
8022 035060 000402
8023
8024 035062 004767 161604
8025 035066 005067 145156
8026
8027 035072
      035072
      035072 104401

```

```

; *
; CHECK FOR OVERRUN ERROR BIT FAILURES, PRINT ERROR MESSAGE IF FOUND.
; *
      MOV    #6713.,ERRNBR ;SET UP ERROR NUMBER.
      CLR    R1             ;INITIALIZE LOOP. CLEAR LINE OFFSET.
20$:    MOV    R1,R2        ;COPY THE LINE OFFSET.
      BIT    BITTBL(R1),R4 ;OVERRUN BIT FAILURE FLAGS ARE IN R4.
      BEQ    22$           ;ERROR FLAG CLEAR? YES, NEXT LINE.
      MOV    R1,R3
      ASR    R3             ;CALCULATE LINE NUMBER FROM LINE OFFSET.
      MOV    #ER7801,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
      MOV    #EM6702,R1    ;PASS THE MESSAGE TO BE REPORTED.
;REPORT "OVERRUN ERROR NOT REPORTED CORRECTLY WHEN FORCED, ON LINE NN ..."
      ERROR ;
; >>>> ERROR #6713 <<<<<.
; TRAP    C$ERROR

; *
; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
; *
      BIT    #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
      BEQ    60$           ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
;DURING THE SOFTWARE QUESTIONS.

22$:    MOV    R2,R1        ;RESTORE THE LINE OFFSET THAT WAS DESTROYED.
      BIC    BITTBL(R1),R4 ;CLEAR THE LINE ERROR FLAG WE JUST HANDLED.
      BEQ    60$           ;ALL FAILURE BITS HANDLED? YES, EXIT TEST.
      ADD    #2,R1         ;NO, INCREMENT THE LINE OFFSET.
      BR     20$           ;LOOP TO HANDLE THE NEXT LINE.

24$:    ;REPORT "BMP CODE FOUND IN FIFO, TEST INVAILEDATED."
      ERROR ;
; >>>> ERROR <<<<<.
; TRAP    C$ERROR

      BR     60$           ;EXIT THIS TEST.

50$:    JSR    PC,TSABRT   ;ABORT THE TEST. ERROR # INDICATES FAULT TYPE.
60$:    CLR    CTRLCF     ;INDICATE THAT WE ARE NOT WITHIN A TEST.

      ENDTST

; L10050:
; TRAP    C$ETST

```



```

8029
8030
8031
8032
8033
8034
8035
8036
8037
8038
8039 035074
      035074
8040
8041 035074 000024
8042 035102 012767 000024 145152
8043 035110 016702 177777 145140
8044 035114 012703 145274
8045 035120 020203 002412
8046 035122 001411
8047
8048
8049
8050
8051
8052 035124 012701 011354
8053 035130
      035130 104455
      035132 022125
      035134 011200
      035136 013176
8054
8055 035140 012767 002412 145242
8056
8057 035146 005067 145076
8058 035152
      035152
      035152 104401

.SBTTL  HARDWARE TEST          - REP8MP -
; * *****
; * - REPORT ANY BMP CODES IN THE QUEUE -
; * THIS IS A PSEUDO-TEST USED TO REPORT ANY BMP CODES THAT WERE FOUND
; * IN THE DUT'S FIFO DURING PREVIOUS TEST, AND LOGGED IN THE BMP CODE
; * QUEUE.
; * IT IS UNLIKELY THAT RUNNING THIS PSEUDO-TEST ALONE WILL PRODUCE ANY
; * ERROR REPORTS.
; * *****
; - BGNTST
; *
; * T20::
; * INCREMENT THE ASSEMBLY TIME TEST COUNTER.
; * SET UP THE TEST NUMBER. (93)
; * INDICATE THAT WE ARE IN A TEST.
; * GET THE CONTENTS OF THE POINTER.
; * GET THE START ADDRESS OF THE QUEUE.
; * SEE IF THE POINTER HAS MOVED FROM THE BASE.
; * EXIT NO CODES IN THE QUEUE.
; *
; * THERE IS AT LEAST ONE BMP CODE IN THE QUEUE. REPORT THE ERROR.
; *
; * REPORT ERROR BMP CODE FOUND IN TEST NN, BMP CODE:NNNNNN"
; *
; * PASS THE FIRST MESSAGE TO BE REORTED.
; * >>>> ERROR #9301 <<<<<.
; * TRAP C#ERDF
; * .WORD 9301
; * .WORD EM9301
; * .WORD ER9301
; *
; * SET POINTER BACK TO THE BEGINING OF THE QUE.
; *
; * INDICATE THAT WE ARE NOT WITHIN A TEST.
; *
; * L10051:
; * TRAP C#ETST
    
```

8067  
 8068  
 8069  
 8070  
 8071  
 8072  
 8073  
 8074  
 8075  
 8076  
 8077  
 8078  
 8079  
 8080  
 8081

.SBTTL HARDWARE PARAMETER CODING SECTION

```

; **
; THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
; WITH THE OPERATOR.
; --
    
```

8082 035154  
 035154 000022  
 035156

BGNHRD

.WORD L10052-L\$HARD/2  
 L\$HARD::

8083  
 8093  
 8094 035156  
 035156 000031  
 035160 035222  
 035162 160000  
 035164 177776

```

;DEVICE CSR ADDRESS QUESTION:
GPRMA HWPTQ1,0,0,160000,177776,YES
    
```

.WORD T\$CODE  
 .WORD HWPTQ1  
 .WORD T\$LLOLIM  
 .WORD T\$HILIM

8095  
 8096 035166  
 035166 001031  
 035170 035240  
 035172 000040  
 035174 000776

```

;DEVICE INTERRUPT VECTOR QUESTION:
GPRMA HWPTQ2,2,0,40,776,YES
    
```

.WORD T\$CODE  
 .WORD HWPTQ2  
 .WORD T\$LLOLIM  
 .WORD T\$HILIM

8097  
 8098 035176  
 035176 002032  
 035200 035273  
 035202 177777  
 035204 000000  
 035206 177777

```

;ACTIVE LINES BIT MAP QUESTION:
GPRMD HWPTQ3,4,0,MAPLNS,0,177777,YES
    
```

.WORD T\$CODE  
 .WORD HWPTQ3  
 .WORD MAPLNS  
 .WORD T\$LLOLIM  
 .WORD T\$HILIM

8099  
 8100 035210  
 035210 003032  
 035212 035321  
 035214 000377  
 035216 000001  
 035220 000002

```

;TYPE OF LOOPBACK QUESTION:
GPRMD HWPTQ4,6,0,377,1,2,YES
    
```

.WORD T\$CODE  
 .WORD HWPTQ4  
 .WORD 377  
 .WORD T\$LLOLIM  
 .WORD T\$HILIM

8101  
 8102  
 8103 035222

ENDHRD

.EVEN  
 L10052:

8104  
 8111  
 8112 035222 103 123 122  
 035225 040 101 104  
 035230 104 122 105  
 035233 123 123 072  
 035236 040 000

HWPTQ1: .ASCIZ /CSR ADDRESS: /



8113	035240	111	116	124	
	035243	105	122	122	HWPTQ2: .ASCIZ /INTERRUPT VECTOR ADDRESS: /
	035246	125	120	124	
	035251	040	126	105	
	035254	103	124	117	
	035257	122	040	101	
	035262	104	104	122	
	035265	105	123	123	
	035270	072	040	000	
8114	035273	101	103	124	HWPTQ3: .ASCIZ /ACTIVE LINE BIT MAP: /
	035276	111	126	105	
	035301	040	114	111	
	035304	116	105	040	
	035307	102	111	124	
	035312	040	115	101	
	035315	120	072	040	
	035320	000			
8115	035321	124	131	120	HWPTQ4: .ASCIZ /TYPE OF LOOPBACK (1=INTERNAL, 2=H3029 OR H3277):/
	035324	105	040	117	
	035327	106	040	114	
	035332	117	117	120	
	035335	102	101	103	
	035340	113	040	050	
	035343	061	075	111	
	035346	116	124	105	
	035351	122	116	101	
	035354	114	054	040	
	035357	062	075	110	
	035362	063	060	062	
	035365	071	040	117	
	035370	122	040	110	
	035373	063	062	067	
	035376	067	051	072	
	035401	000			

8116  
8117

.EVEN

8126  
 8127  
 8128  
 8129  
 8130  
 8131  
 8132  
 8133  
 8134  
 8135  
 8136  
 8137  
 8138  
 3139 035402  
       035402 000014  
       035404  
 8140  
 8149  
 8150 035404  
       035404 000130  
       035406 035434  
       035410 000020  
 8151  
 8152 035412  
       035412 000130  
       035414 035510  
       035416 000100  
 8153  
 8154  
 8155  
 8156 035420  
       035420 006044  
 8157  
 8158  
 8159 035422  
       035422 001052  
       035424 035543  
       035426 177777  
       035430 000000  
       035432 177777  
 8160  
 8161  
 8162  
 8163 035434  
       035434  
 8164  
 8165  
 8172 035434 122 105 120  
       035437 117 122 124  
       035442 040 125 116  
       035445 111 124 040  
       035450 116 125 115  
       035453 102 105 122  
       035456 040 101 123  
       035461 040 105 101  
       035464 103 110 040

.SBTTL SOFTWARE PARAMETER CODING SECTION

```

:++
: THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
: THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
: MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
: INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
: MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
: WITH THE OPERATOR.
:--
    
```

BGNSFT

.WORD L10053-L\$SOFT/2  
 L\$SOFT::

```

:UNIT NUMBER PRINTOUT QUESTION:
GPRML SWPTQ1,0,20,YES
    
```

.WORD T\$CODE  
 .WORD SWPTQ1  
 .WORD 20

```

:EXTENDED ERROR REPORTING QUESTION:
GPRML SWPTQ2,0,100,YES
    
```

.WORD T\$CODE  
 .WORD SWPTQ2  
 .WORD 100

```

: IF EXTENDED ERROR REPORTING IS NOT REQUIRED THEN SKIP THE NEXT QUESTION.
    
```

XFERF ENDD

.WORD T\$CODE

```

:NUMBER OF INDIVIDUAL DATA ERRORS TO REPORT ON A LINE QUESTION:
GPRMD SWPTQ3,2,D,177777,0,177777,YES
    
```

.WORD T\$CODE  
 .WORD SWPTQ3  
 .WORD 177777  
 .WORD T\$LOLIM  
 .WORD T\$HILIM

.EVEN

ENDD: ENDSFT

.EVEN  
 L10053:

SWPTQ1: .ASCIZ /REPORT UNIT NUMBER AS EACH UNIT IS TESTED: /



	035467	125	116	111
	035472	124	040	111
	035475	123	040	124
	035500	105	123	124
	035503	105	104	072
	035506	040	000	
8173	035510	105	130	124
	035513	105	116	104
	035516	105	104	040
	035521	105	122	122
	035524	117	122	040
	035527	122	105	120
	035532	117	122	124
	035535	111	116	107
	035540	072	040	000
8174	035543	116	125	115
	035546	102	105	122
	035551	040	117	106
	035554	040	111	116
	035557	104	111	126
	035562	111	104	125
	035565	101	114	040
	035570	104	101	124
	035573	101	040	105
	035576	122	122	117
	035601	122	123	040
	035604	124	117	040
	035607	122	105	120
	035612	117	122	124
	035615	040	117	116
	035620	040	101	040
	035623	114	111	116
	035626	105	072	040
8175	035631	000		

SWPTQ2: .ASCIZ /EXTENDED ERROR REPORTING: /

SWPTQ3: .ASCIZ /NUMBER OF INDIVIDUAL DATA ERRORS TO REPORT ON A LINE: /

.EVEN

8184  
8185  
8186 035632  
8187 035632  
8188  
8195  
8196  
8197  
8198  
8199 035702

\$PATCH::  
.BLKW 24

LASTAD

035702 000000  
035704 000000

.EVEN  
.WORD 0  
.WORD 0

8200 035706  
8201  
8202  
8203  
8204  
8205  
8206  
8207  
8208

L\$LAST::  
ENDMOD

000001

.END



ACTLNS 002220 G	CTRLCF 002250 G	DMABUF 014322 G	EM5804 007201 G	FDATE = 000006 G
ADR = 000020 G	C\$AU = 000052	DODMA 014400 G	EM5805 007265 G	FINACT 014470 G
ADRPTR 014200 G	C\$AUTO= 000061	DRADRT 002226 G	EM5901 007346 G	FLSA 002234 G
ALTFLD 013370 G	C\$BRK = 000022	DROP 020730	EM5902 007402 G	FLSO = 000006 G
ASLNTL 013442 G	C\$BSEG= 000004	EDROP 021006	EM5903 007476 G	F\$AU = 000015
ASSEMB= 000010	C\$BSUB= 000002	EF.CON= 000036 G	EM5904 007570 G	F\$AUTO= 000020
BCOUNT 002322 G	C\$CEFG= 000045	EF.NEW= 000035 G	EM5905 007654 G	F\$BGN = 000040
BITTBL 002336 G	C\$CLCK= 000062	EF.PWR= 000034 G	EM6001 007754 G	F\$CLEA= 000007
BITO = 000001 G	C\$CLEA= 000012	EF.RES= 000037 G	EM6002 010000 G	F\$DU = 000016
BIT00 = 000001 G	C\$CLOS= 000035	EF.STA= 000040 G	EM6003 010040 G	F\$END = 000041
BIT01 = 000002 G	C\$CLP1= 000006	EF0503 004156 G	EM6004 010120 G	F\$HARD= 000004
BIT02 = 000004 G	C\$CVEC= 000036	EF1601 004163 G	EM6005 010165 G	F\$HW = 000013
BIT03 = 000010 G	C\$DCLN= 000044	EF5801 004215 G	EM6006 010243 G	F\$INIT= 000006
BIT04 = 000020 G	C\$DODU= 000051	EF5901 004270 G	EM6401 010307 G	F\$JMP = 000050
BIT05 = 000040 G	C\$DRPT= 000024	EF5902 004320 G	EM6402 010344 G	F\$MOD = 000000
BIT06 = 000100 G	C\$DU = 000053	EF6401 004350 G	EM6601 010405 G	F\$MSG = 000011
BIT07 = 000200 G	C\$EDIT= 000003	EF7801 004417 G	EM6602 010442 G	F\$PROT= 000021
BIT08 = 000400 G	C\$ERDF= 000055	EF9001 004455 G	EM6701 010514 G	F\$PWR = 000017
BIT09 = 001000 G	C\$ERHR= 000056	EF9002 004537 G	EM6702 010546 G	F\$RPT = 000012
BIT1 = 000002 G	C\$ERR0= 000060	EF9003 004611 G	EM9009 010623 G	F\$SEG = 000003
BIT10 = 002000 G	C\$ERSF= 000054	EF9004 004640 G	EM9010 010647 G	F\$SOFT= 000005
BIT11 = 004000 G	C\$ERSO= 000057	EF9005 004670 G	EM9014 010673 G	F\$SRV = 000010
BIT12 = 010000 G	C\$ESCA= 000010	EF9006 004721 G	EM9017 010767 G	F\$SUB = 000002
BIT13 = 020000 G	C\$ESEG= 000005	EF9010 004745 G	EM9026 011100 G	F\$SW = 000014
BIT14 = 040000 G	C\$ESUB= 000003	EF9019 005034 G	EM9104 011124 G	F\$TEST= 000001
BIT15 = 100000 G	C\$ETST= 000001	EF9301 005053 G	EM9301 011200 G	GETPRM 020446
BIT2 = 000004 G	C\$EXIT= 000032	EF9302 005131 G	EM9302 011257 G	GPRSOB 002376 G
BIT3 = 000010 G	C\$GETB= 000026	EM0101 015124 G	EM9303 011307 G	G\$CNT0= 000200
BIT4 = 000020 G	C\$GETW= 000027	EM0102 015210 G	EM9304 011354 G	G\$DELM= 000372
BIT5 = 000040 G	C\$GMAN= 000043	EM0103 005262 G	ENDD 035434	G\$DISP= 000003
BIT6 = 000100 G	C\$GPHR= 000042	EM1601 005320 G	ENDETB 003650 G	G\$EXCP= 000400
BIT7 = 000200 G	C\$GPLO= 000030	EM4001 005403 G	ENDIT 020650	G\$HILI= 000002
BIT8 = 000400 G	C\$GPRI= 000040	EM4002 005435 G	ERCNTB 002614 G	G\$LOLI= 000001
BIT9 = 001000 G	C\$INIT= 000011	EM4101 005471 G	ERLTBL 002650 G	G\$NO = 000000
BMPQCB 002412 G	C\$INLP= 000020	EM4102 005523 G	ERRBLK 004056 G	G\$OFFS= 000400
BMPQCE 002612 G	C\$MANI= 000050	EM4103 005557 G	ERRMSG 004054 G	G\$OFSI= 000376
BMPQCP 002410 G	C\$MEM = 000031	EM4201 005643 G	ERRNBR 004052 G	G\$PRMA= 000001
BOE = 000400 G	C\$MSG = 000023	EM4202 005675 G	ERRTYP 004050 G	G\$PRMD= 000002
BRLEVL 002223 G	C\$OPEN= 000034	EM4901 005717 G	ERSMRF 002612 G	G\$PRML= 000000
BUFBAS 002650 G	C\$PNTB= 000014	EM4902 005760 G	ER0101 011430 G	G\$RADA= 000140
BUFEND 003650 G	C\$PNTF= 000017	EM5001 006012 G	ER0503 011762 G	G\$RADB= 000000
BUF MID 003250 G	C\$PNTS= 000016	EM5101 006051 G	ER1603 012020 G	G\$RADD= 000040
BUFPTR 002246 G	C\$PNTX= 000015	EM5102 006106 G	ER5801 012112 G	G\$RADL= 000120
BUF3QT 003450 G	C\$QIO = 000377	EM5103 006144 G	ER5901 012170 G	G\$RADO= 000020
CALMSL 013552 G	C\$RDBU= 000007	EM5201 006174 G	ER6001 012276 G	G\$XFER= 000004
CHKBMP 013776 G	C\$REFG= 000047	EM5202 006227 G	ER6401 012400 G	G\$YES = 000010
CKRXTM 014046 G	C\$RESE= 000033	EM5301 006265 G	ER7801 012506 G	HELP = 000000
CKTRAP 014166 G	C\$REVI= 000003	EM5302 006321 G	ER9001 012544 G	HOE = 100000 G
CLKBRL 002306 G	C\$RFLA= 000021	EM5303 006401 G	ER9002 012644 G	HWPTQ1 035222
CLKCSR 002304 G	C\$RPT = 000025	EM5401 006452 G	ER9004 013022 G	HWPTQ2 035240
CLKHRZ 002312 G	C\$SEFG= 000046	EM5402 006520 G	ER9101 013136 G	HWPTQ3 035273
CLKINT 017632 G	C\$SPRI= 000041	EM5501 006561 G	ER9301 013176 G	HWPTQ4 035321
CLKVEC 002310 G	C\$SVEC= 000037	EM5601 006625 G	EVL = 000004 G	IBE = 010000 G
CLNRST 014216 G	C\$TPRI= 000013	EM5701 006702 G	EXOERR 002252 G	IDU = 000040 G
CLR16W 014240 G	DELAY 014262 G	EM5801 006757 G	E\$END = 002100	IER = 020000 G
CSRA = 002226 G	DFPTBL 002176 G	EM5802 007003 G	E\$LOAD= 000035	IESTAT 002256 G
CSRO = 000000 G	DIAGMC= 000000	EM5803 007077 G	FDATE 002234 G	INDATP 014550 G



INDTPX	014600	G	L\$EXP4	002064	G	L10034	024714	PRI06	=	000300	G	TXBFCA	002244	G				
ISR	=	000100	G	L\$EXP5	002066	G	L10035	025406	PRI07	=	000340	G	TXBFCO	=	000016	G		
IXE	=	004000	G	L\$HARD	035156	G	L10036	025714	PRTLPR	015306	G	TXDATP	017004	G				
I\$AU	=	000041		L\$HIME	002120	G	L10037	026224	PUFIFO	015370	G	TXDSBL	017026	G				
I\$AUTO	=	000041		L\$HPCP	002016	G	L10040	026724	PUFIFR	015452	G	TXENBL	017122	G				
I\$CLN	=	000041		L\$HPTP	002022	G	L10041	027422	RBUFA	002230	G	TXIEO	017216	G				
I\$DU	=	000041		L\$HW	002176	G	L10042	030100	RBUFO	=	000002	G	TXIE1	017256	G			
I\$HRD	=	000041		L\$ICP	002104	G	L10043	031150	READBX	015654	G	TXINTC	002272	G				
I\$INIT	=	000041		L\$INIT	020044	G	L10044	031736	REPDER	015736	G	TXINTF	002274	G				
I\$MOD	=	000041		L\$LADP	002026	G	L10045	032764	REPSMR	016254	G	TXRLNB	004010	G				
I\$MSG	=	000041		L\$LAST	035706	G	L10046	033410	RESETT	016302	G	TXRLNE	004030	G				
I\$PROT	=	000040		L\$LOAD	002100	G	L10047	034126	RXBDEX	=	000030	G	TXRXLB	003750	G			
I\$PTAB	=	000041		L\$LUN	002074	G	L10050	035072	RXBETX	=	000020	G	TXRXLE	004010	G			
I\$PWR	=	000041		L\$MREV	002050	G	L10051	035152	RXBFUL	=	000100	G	TXVECA	002216	G			
I\$RPT	=	000041		L\$NAME	002000	G	L10052	035222	RXCNTB	003710	G	T\$ARGC	=	000002				
I\$SEG	=	000041		L\$PRIO	002042	G	L10053	035434	RXDECT	017702	G	T\$CODE	=	001052				
I\$SETU	=	000041		L\$PROT	020036	G	MAPCNT	014676	RXIEO	016414	G	T\$ERRN	=	022125				
I\$SFT	=	000041		L\$PRT	002112	G	MAPLNS	=	177777	G	RXIE1	016454	G	T\$EXCP	=	000000		
I\$SRV	=	000041		L\$REPP	002062	G	MFUNIT	005231	RXINTC	002266	G	RXINTF	002270	G	T\$FLAG	=	000040	
I\$SUB	=	000041		L\$REV	002010	G	MMENAB	002334	RXTIMO	=	000002	G	T\$GMAN	=	000000			
I\$TST	=	000041		L\$RPT	020030	G	MMPRES	002332	RXTMA	002230	G	T\$HILI	=	177777				
J\$JMP	=	000167		L\$SOFT	035404	G	MMSRO	002330	RXVECA	002214	G	T\$LAST	=	000001				
LGRP1M	002260	G	L\$SPC	002056	G	MSG1	011546	R0SLOT	=	000002	G	T\$LOLI	=	000000				
LGRP2M	002262	G	L\$SPCP	002020	G	MSG2	011624	R1SLOT	=	000004	G	T\$LSYM	=	010000				
LINBIT	014650	G	L\$SPTP	002024	G	MSG3	011703	R2SLOT	=	000006	G	T\$LTNO	=	000024				
LNCTRA	002236	G	L\$STA	002030	G	MSLCNT	002326	R3SLOT	=	000010	G	T\$NEST	=	177777				
LNCTRO	=	000010	G	L\$SW	002210	G	MSLGET	014730	R4SLOT	=	000012	G	T\$NSO	=	000000			
LOE	=	040000	G	L\$TEST	002114	G	MSLOOP	015044	R5SLOT	=	000014	G	T\$NS1	=	000005			
LOPBCK	002222	G	L\$TIML	002014	G	MSTICK	002324	SAVBMP	016500	G	T\$PTNU	=	000000					
LOT	=	000010	G	L\$UNIT	002012	G	NDERPT	002212	SETPAR	016546	G	T\$SAVL	=	177777				
LPCSLT	=	000036	G	L10000	002206		NEWPAS	020426	SFPTBL	002210	G	T\$SEGL	=	177777				
LPRA	002232	G	L10001	002214		NEWRES	020420	SKPSTS	016614	G	T\$SUBN	=	000000					
LPRO	=	000004	G	L10002	011544		NEWSTA	020110	STGTRB	004030	G	T\$TAGL	=	177777				
L\$ACP	002110	G	L10003	012016		NUMLNS	=	000020	G	SVCGBL	=	000000		T\$TAGN	=	010054		
L\$APT	002036	G	L10004	012110		OOPS	015060	SVCINS	=	000001		T\$TEMP	=	000000				
L\$AU	021014	G	L10005	012166		OPTION	002210	SVCSUB	=	000001		T\$TEST	=	000024				
L\$AUT	002070	G	L10006	012274		O\$APTS	=	000000		SVCTAG	=	000001		T\$TSTM	=	177777		
L\$AUTO	020664	G	L10007	012376		O\$AU	=	000000		SVCTST	=	000001		T\$TSTS	=	000001		
L\$CCP	002106	G	L10010	012504		O\$BGNR	=	000001		SMPTQ1	035434		T\$\$AU	=	010025			
L\$CLEA	020666	G	L10011	012542		O\$BGNS	=	000001		SMPTQ2	035510		T\$\$AUT	=	010022			
L\$CO	002032	G	L10012	012642		O\$DU	=	000001		SMPTQ3	035543		T\$\$CLE	=	010023			
L\$DEPO	002011	G	L10013	013020		O\$ERRT	=	000001		S\$LSYM	010000		T\$\$DU	=	010024			
L\$DESC	004130	G	L10014	013134		O\$GNSW	=	000001		TIMER1	002314	G	T\$\$HAR	=	010052			
L\$DESP	002076	G	L10015	013174		O\$POIN	=	000001		TIMER2	002316	G	T\$\$HW	=	010000			
L\$DEVP	002060	G	L10016	013366		O\$SETU	=	000000		TIMER3	002320	G	T\$\$INI	=	010021			
L\$DISP	002124	G	L10017	020034		PASCNT	002264	G	TNUM	=	000024	G	T\$\$MSG	=	010016			
L\$DLY	002116	G	L10021	020662		PCSLOT	=	000016	G	TP4FLG	002300	G	T\$\$PRO	=	010020			
L\$DTP	002040	G	L10022	020664		PNT	=	001000	G	TP4RTN	017712	G	T\$\$RPT	=	010017			
L\$DTYP	002034	G	L10023	020702		PREGRT	004102	G	TP4VEC	002276	G	T\$\$SOF	=	010053				
L\$DU	020704	G	L10024	021012		PREG05	004060		TSABRT	016672	G	T\$\$SW	=	010001				
L\$DUT	002072	G	L10025	021020		PRI	=	002000	G	TSTNUM	002254	G	T\$\$TES	=	010051			
L\$DVTY	004120	G	L10026	021302		PRI00	=	000000	G	TXAD1A	002240	G	T1	021022	G			
L\$EF	002052	G	L10027	021706		PRI01	=	000040	G	TXAD10	=	000012	G	T10	025716	G		
L\$ENVI	002044	G	L10030	022344		PRI02	=	000100	G	TXAD2A	002242	G	T11	026226	G			
L\$ERRT	004050	G	L10031	022672		PRI03	=	000140	G	TXAD20	=	000014	G	T12	026726	G		
L\$ETP	002102	G	L10032	023472		PRI04	=	000200	G	TXAINT	017734	G	T13	027424	G			
L\$EXP1	002046	G	L10033	024272		PRI05	=	000240	G				T14	030102	G			



T15	031152 G	T20	035074 G	T8	024716 G	WAIBIS	017436 G	X\$ALWA=	000000
T16	031740 G	T3	021710 G	T9	025410 G	WAITTX	017512 G	X\$FALS=	000040
T17	032766 G	T4	022346 G	UAM	000200 G	WORD1	002302 G	X\$OFFS=	000400
T18	033412 G	T5	022674 G	UNITN	002224 G	WTWLNC	017552 G	X\$TRUE=	000020
T19	034130 G	T6	023474 G	UNSDIV	017302 G	WTWLPR	017602 G	\$PATCH	035632 G
T2	021304 G	T7	024274 G						

. ABS. 035706 000  
 000000 001

ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 28661 WORDS ( 112 PAGES)  
 DYNAMIC MEMORY: 20060 WORDS ( 77 PAGES)  
 ELAPSED TIME: 00:05:03  
 CZDHVBO.BIN,CZDHVBO.LST/-SP=SVC34R/ML,CZDHVBO.P11