

LP25, LP26

LP25 DIAGNOSTIC
CZLPLCO

AH-E635C-MC
FICHE 1 OF 1

FEB 1981
COPYRIGHT © 79-80
MADE IN USA



.REM 8

IDENTIFICATION

PRODUCT CODE : AC-E634C-MC
PRODUCT NAME: CZLPLCO LP25, LP25 DIAG
MAINTAINER: SMALL SYSTEMS DIAGNOSTICS
PRODUCT DATE: 23-SEP-80
AUTHOR: JOHN CHATALIAN
DON RICE
RALPH SCHAUBER

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1979,1980 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL
DEC

PDP
DECUS

UNIBUS
DECTAPE

MASSBUS

TABLE OF CONTENTS

1.0	GENERAL INFORMATION
1.1	PROGRAM ABSTRACT
1.2	SYSTEM REQUIREMENTS
1.3	RELATED DOCUMENTS AND STANDARDS
1.4	DIAGNOSTIC HIERARCHY PREREQUISITES
1.5	ASSUMPTIONS
2.0	OPERATING INSTRUCTIONS
2.1	COMMANDS
2.2	SWITCHES
2.3	FLAGS
2.4	HARDWARE QUESTIONS
2.5	SOFTWARE QUESTIONS
2.6	EXTENDED P-TABLE DIALOGUE
2.7	QUICK STARTUP PROCEDURE
3.0	ERROR INFORMATION
4.0	PERFORMANCE AND PROGRESS REPORTS
5.0	DEVICE INFORMATION TABLES
6.0	TEST SUMMARIES

1.0 GENERAL INFORMATION

1.1 PROGRAM ABSTRACT

THIS DIAGNOSTIC PROGRAM VERIFIES PROPER OPERATION OF THE LP25 OR LP26 LINE PRINTER AND ITS ASSOCIATED M7258 CONTROL UNIT WHICH INTERFACES TO THE PDP-11 CPU. THE BROAD RANGE OF TESTS ASSURES A COMPREHENSIVE TEST OF THE FUNCTIONAL CAPABILITY OF THE LINE PRINTER. THE INDIVIDUAL TESTS ARE IDENTIFIED AS FOLLOWS:

TEST 1	INTERFACE LOGIC
TEST 2	READY LINE INTERLOCKS
TEST 3	FORMS LENGTH SELECTION
TEST 4	PRINTING SPEED
TEST 5	DAVFU ERROR DETECTION
TEST 6	DAVFU LINE COUNT PAPER CONTROL
TEST 7	DAVFU CHANNEL SELECTION PAPER CONTROL
TEST 8	DATA TRANSFER PATHS
TEST 9	PRINTABLE CHARACTERS
TEST 10	NON-PRINTABLE CHARACTERS
TEST 11	BAND PATTERN
TEST 12	SPURIOUS HAMMER FIRING
TEST 13	PRINT CONTROL
TEST 14	CRITICAL PATHS
TEST 15	MULTIPLE LINE ADVANCE
TEST 16	CHARACTER ALIGNMENT

ANY MIX OF PRINTER TYPES (LP25 OR LP26) CAN BE TESTED UP TO A TOTAL OF SIXTEEN UNITS. BAND CONFIGURATION (64 OR 96 CHAR) IS HANDELED ON A UNIT BY UNIT BASIS. ALL UNITS NEED NOT HAVE THE SAME BAND.

THIS DIAGNOSTIC HAS BEEN WRITTEN FOR USE WITH THE DIAGNOSTIC RUNTIME SERVICES SOFTWARE (SUPERVISOR). THESE SERVICES PROVIDE THE INTERFACE TO THE OPERATOR AND TO THE SOFTWARE ENVIRONMENT. THIS PROGRAM CAN BE USED WITH XXDP+, ACT, APT, SLIDE AND PAPER TAPE. FOR A COMPLETE DESCRIPTION OF THE RUNTIME SERVICES, REFER TO THE XXDP+ USER'S MANUAL. THERE IS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES IN SECTION 2 OF THIS DOCUMENT.

1.2 SYSTEM REQUIREMENTS

1.2 SYSTEM REQUIREMENTS

A TEST STATION IS REQUIRED CONSISTING OF A PDP-11 CPU WITH A MINIMUM OF 24K WORDS OF MEMORY AND A CONSOLE TERMINAL WITH INTERFACE AT DEVICE ADDRESS 777560. THE SYSTEM ALSO REQUIRES AN XXDP SUPPORTED DEVICE SUCH AS AN RK05/RK11 DISK DRIVE TO AFFORD A MEANS TO LOAD THE DIAGNOSTIC PROGRAM. A KW11-L LINE TIME CLOCK OR A KW11-P PROGRAMMABLE REAL-TIME CLOCK IS NECESSARY FOR MEASURING THE TIME INTERVAL FROM WHICH PRINTING SPEED IS DETERMINED. IF A CLOCK IS NOT INSTALLED IN THE SYSTEM, THE OPERATOR WILL HAVE TO USE MANUAL MODE TO MANUALLY TIME PRINTER OPERATION FOR A FIXED TIME INTERVAL TO CALCULATE THE

PRINTING SPEED.

IN A MANUFACTURING ENVIRONMENT WHERE APT/ACT/SLIDE ARE USED,
THE TEST STATION MUST BE EQUIPPED WITH THE APPROPRIATE INTERFACE
AND A HOST PROCESSOR WITH THE NECESSARY SOFTWARE.

1.3 RELATED DOCUMENTS AND STANDARDS

PROJECT PLAN FOR LP25 DIAGNOSTIC PROGRAM
DOCUMENT: RAS-78-008-00-U
DATE: 6-SEP-78

DIAGNOSTIC ENGINEERING FUNCTIONAL SPECIFICATION
FOR CZLPLAO LP25 DIAGNOSTIC PROGRAM (PRELIMINARY)
DATE: 29-SEP-78

LINE PRINTER, 250 LPM (LP25) PURCHASE SPECIFICATION
(PRELIMINARY)

DATAPRODUCTS 300 LPM LINE PRINTER FIELD MAINTENANCE
GUIDE (PRELIMINARY)

DATAPRODUCTS 300 LPM LINE PRINTER OPERATOR'S GUIDE
(PRELIMINARY)

1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

THIS DIAGNOSTIC IS COMPATIBLE WITH ALL MEMBERS OF THE PDP-11
COMPUTER FAMILY. THE DIAGNOSTIC IS INTERFACED TO THE PDP-11
DIAGNOSTIC SUPERVISOR THROUGH WHICH IT INTERFACES TO THE
ENVIRONMENT.

THE DIAGNOSTIC CAN BE USED IN A VARIETY OF OPERATING SYSTEMS
TO FULFILL DIFFERENT REQUIREMENTS. THE DIAGNOSTIC CAN BE
LOADED USING XXDP IN A FIELD SERVICE OPERATION, LOADED USING
THE APT/ACT/SLIDE DIAGNOSTIC MONITORS IN A MANUFACTURING
ENVIRONMENT, OR MANUALLY LOADED USING PAPER TAPE.

THE APPLICABLE PDP-11 CPU, MEMORY, AND PERIPHERALS SHOULD BE
RUN TO VALIDATE PROPER OPERATION OF THE SYSTEM BEFORE RUNNING
THIS DIAGNOSTIC.

1.5 ASSUMPTIONS

THE LINE PRINTERS UNDER TEST SHOULD HAVE POWER APPLIED AND BE
PLACED ON LINE IN READINESS FOR TESTING. EACH LINE PRINTER
MUST HAVE ITS OWN M7258 CONTROLLER SET UP AT A DIFFERENT DEVICE
ADDRESS. THE DIAGNOSTIC PROVIDES A DEFAULT DEVICE ADDRESS OF
777514 WHICH CAN BE USED WHEN A SINGLE LINE PRINTER IS BEING
TESTED OR FOR THE FIRST UNIT WHEN MULTIPLE LINE PRINTERS ARE
UNDER TEST. IT WILL BE NECESSARY FOR THE OPERATOR TO RUN THE
LINE PRINTER OFF LINE IN THE SELF TEST MODE BEFORE RUNNING THE
DIAGNOSTIC IN ORDER TO DETERMINE WHETHER THE 64 OR 96 CHARACTER

BAND IS INSTALLED.

A PATCH IS REQUIRED IN THE DIAGNOSTIC TO CIRCUMVENT AN INCOMPATIBILITY IN THE DIAGNOSTIC SUPERVISOR. IT IS NECESSARY TO ADD 11236 TO THE CONTENTS OF THE ADDRESS "L\$LAST" WHICH IS FOUND AT THE END OF THE ASSEMBLY LISTING. THIS SUM IS USED AS THE ADDRESS INTO WHICH 42760 IS DEPOSITED. 177777 IS DEPOSITED INTO THE SUBSEQUENT MEMORY ADDRESS.

2.0 OPERATING INSTRUCTIONS .

THIS SECTION CONTAINS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES. FOR DETAILED INFORMATION, REFER TO THE XXDP+ USER'S MANUAL (CHQUS).

2.1 COMMANDS

THERE ARE ELEVEN LEGAL COMMANDS FOR THE DIAGNOSTIC RUNTIME SERVICES (SUPERVISOR). THIS SECTION LISTS THE COMMANDS AND GIVES A VERY BRIEF DESCRIPTION OF THEM. THE XXDP+ USER'S MANUAL HAS MORE DETAILS.

COMMAND	EFFECT
START	START THE DIAGNOSTIC FROM AN INITIAL STATE
RESTART	START THE DIAGNOSTIC WITHOUT INITIALIZING
CONTINUE	CONTINUE AT TEST THAT WAS INTERRUPTED (AFTER ^C)
PROCEED	CONTINUE FROM AN ERROR HALT
EXIT	RETURN TO XXDP+ MONITOR (XXDP+ OPERATION ONLY!)
ADD	ACTIVATE A UNIT FOR TESTING (ALL UNITS ARE CONSIDERED TO BE ACTIVE AT START TIME)
DROP	DEACTIVATE A UNIT
PRINT	PRINT STATISTICAL INFORMATION (IF IMPLEMENTED BY THE DIAGNOSTIC - SECTION 4.0)
DISPLAY	TYPE A LIST OF ALL DEVICE INFORMATION
FLAGS	TYPE THE STATE OF ALL FLAGS (SEE SECTION 2.3)
ZFLAGS	CLEAR ALL FLAGS (SEE SECTION 2.3)

A COMMAND CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. SO YOU MAY, FOR EXAMPLE, TYPE "STA" INSTEAD OF "START".

2.2 SWITCHES

THERE ARE SEVERAL SWITCHES WHICH ARE USED TO MODIFY SUPERVISOR OPERATION. THESE SWITCHES ARE APPENDED TO THE LEGAL COMMANDS. ALL OF THE LEGAL SWITCHES ARE TABULATED BELOW WITH A BRIEF DESCRIPTION OF EACH. IN THE DESCRIPTIONS BELOW, A DECIMAL NUMBER IS DESIGNATED BY "DDDDD".

SWITCH	EFFECT
/TESTS:LIST	EXECUTE ONLY THOSE TESTS SPECIFIED IN THE LIST. LIST IS A STRING OF TEST NUMBERS, FOR EXAMPLE - /TESTS:1:5:7-10. THIS LIST WILL CAUSE TESTS 1,5,7,8,9,10 TO BE RUN. ALL OTHER TESTS WILL NOT BE RUN.
/PASS:DDDDD	EXECUTE DDDDD PASSES (DDDDD = 1 TO 64000).
/FLAGS:FLGS	SET SPECIFIED FLAGS. FLAGS ARE DESCRIBED IN SECTION 2.3.

/EOP:DDDDD REPORT END OF PASS MESSAGE AFTER EVERY
 DDDDD PASSES ONLY. (DDDDD = 1 TO 64000)
 /UNITS:LIST TEST/ADD/DROP ONLY THOSE UNITS SPECIFIED
 IN THE LIST. LIST EXAMPLE - /UNITS:0:5:10-12
 USE UNITS 0,5,10,11,12 (UNIT NUMBERS = 0-63)

EXAMPLE OF SWITCH USAGE:

START/TESTS:1-5/PASS:1000/EOP:100

THE EFFECT OF THIS COMMAND WILL BE: 1) TESTS 1 THROUGH 5 WILL BE EXECUTED, 2) ALL UNITS WILL TESTED 1000 TIMES AND 3) THE END OF PASS MESSAGES WILL BE PRINTED AFTER EACH 100 PASSES ONLY. A SWITCH CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. YOU MAY, FOR EXAMPLE, TYPE '/TES:1-5' INSTEAD OF '/TESTS:1-5'.

BELOW IS A TABLE THAT SPECIFIES WHICH SWITCHES CAN BE USED BY EACH COMMAND.

	TESTS	PASS	FLAGS	EOP	UNITS
START	X	X	X	X	X
RESTART	X	X	X	X	X
CONTINUE		X	X	X	
PROCEED			X		
DROP					X
ADD					X
PRINT					
DISPLAY					X
FLAGS					
ZFLAGS					
EXIT					

2.3 FLAGS

FLAGS ARE USED TO SET UP CERTAIN OPERATIONAL PARAMETERS SUCH AS LOOPING ON ERROR. ALL FLAGS ARE CLEARED AT STARTUP AND REMAIN CLEARED UNTIL EXPLICITLY SET USING THE FLAGS SWITCH. FLAGS ARE ALSO CLEARED AFTER A START COMMAND UNLESS SET USING THE FLAG SWITCH. THE ZFLAGS COMMAND MAY ALSO BE USED TO CLEAR ALL FLAGS. WITH THE EXCEPTION OF THE START AND ZFLAGS COMMANDS, NO COMMANDS AFFECT THE STATE OF THE FLAGS; THEY REMAIN SET OR CLEARED AS SPECIFIED BY THE LAST FLAG SWITCH.

FLAG	EFFECT
HOE	HALT ON ERROR - CONTROL IS RETURNED TO RUNTIME SERVICES COMMAND MODE
LOE	LOOP ON ERROR
IER*	INHIBIT ALL ERROR REPORTS
IBR*	INHIBIT ALL ERROR REPORTS EXCEPT FIRST LEVEL (FIRST LEVEL CONTAINS ERROR TYPE, NUMBER, PC, TEST AND UNIT)
IXR*	INHIBIT EXTENDED ERROR REPORTS (THOSE CALLED BY PRINTX MACRO'S)

PRI	DIRECT MESSAGES TO LINE PRINTER
PNT	PRINT TEST NUMBER AS TEST EXECUTES
BOE	'BELL' ON ERROR
UAM	UNATTENDED MODE (NO MANUAL INTERVENTION)
ISR	INHIBIT STATISTICAL REPORTS (DOES NOT APPLY TO DIAGNOSTICS WHICH DO NOT SUPPORT STATISTICAL REPORTING)
IDR	INHIBIT PROGRAM DROPPING OF UNITS
ADR	EXECUTE AUTODROP CODE
LOT	LOOP ON TEST
EVL	EXECUTE EVALUATION (ON DIAGNOSTICS WHICH HAVE EVALUATION SUPPORT)

*ERROR MESSAGES ARE DESCRIBED IN SECTION 3.1

SEE THE XXDP+ USER'S MANUAL FOR MORE DETAILS ON FLAGS. YOU MAY SPECIFY MORE THAN ONE FLAG WITH THE FLAG SWITCH. FOR EXAMPLE, TO CAUSE THE PROGRAM TO LOOP ON ERROR, INHIBIT ERROR REPORTS AND TYPE A 'BELL' ON ERROR, YOU MAY USE THE FOLLOWING STRING:

/FLAGS:LOE:IER:BOE

2.4 HARDWARE QUESTIONS

WHEN A DIAGNOSTIC IS STARTED, THE RUNTIME SERVICES WILL PROMPT THE USER FOR HARDWARE INFORMATION BY TYPING "CHANGE HW (L) ?" YOU MUST ANSWER "Y" AFTER A START COMMAND UNLESS THE HARDWARE INFORMATION HAS BEEN "PRELOADED" USING THE SETUP UTILITY (SEE CHAPTER 6 OF THE XXDP+ USER'S MANUAL). WHEN YOU ANSWER THIS QUESTION WITH A "Y", THE RUNTIME SERVICES WILL ASK FOR THE NUMBER OF UNITS (IN DECIMAL). YOU WILL THEN BE ASKED THE FOLLOWING QUESTIONS FOR EACH UNIT.

#UNITS (D) ? 1

UNIT 1

LP11 ADDRESS: (0) (177514) ?
INTERRUPT VECTOR : (0) (200) ?
ENTER 0 IF LP25 OR 1 IF LP26 (0) (0) ?
96 CHARACTER BAND (L) ? ANSWER Y OR N.

2.5 SOFTWARE QUESTIONS

AFTER YOU HAVE ANSWERED THE HARDWARE QUESTIONS OR AFTER A RESTART OR CONTINUE COMMAND, THE RUNTIME SERVICES WILL ASK FOR SOFTWARE PARAMETERS. THESE PARAMETERS WILL GOVERN SOME DIAGNOSTIC SPECIFIC OPERATION MODES. YOU WILL BE PROMPTED BY "CHANGE SW (L) ?" IF YOU WISH TO CHANGE ANY PARAMETERS, ANSWER BY TYPING "Y". THE SOFTWARE QUESTIONS AND THE DEFAULT VALUES ARE DESCRIBED IN THE NEXT PARAGRAPH(S).

RIJN MANUAL INTERVENTION TESTS (N) ? DEFAULT IS NO

SUB-DEVICE # (0) ? 5<CR>
Q-FACTOR (0) 0 ? <CR>

UNIT 7
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 6<CR>
Q-FACTOR (0) 0 ? 1<CR>

UNIT 8
CSR ADDRESS (0) 160000<CR>
SUB-DEVICE # (0) ? 7<CR>
Q-FACTOR (0) 1 ? <CR>

NOTICE THAT THE DEFAULT VALUE FOR THE Q-FACTOR CHANGES WHEN A NON-DEFAULT RESPONSE IS GIVEN. BE CAREFUL WHEN SPECIFYING MULTIPLE UNITS!

AS YOU CAN SEE FROM THE ABOVE EXAMPLE, THE HARDWARE PARAMETERS DO NOT VARY SIGNIFICANTLY FROM UNIT TO UNIT. THE PROCEDURE SHOWN IS NOT VERY EFFICIENT.

THE RUNTIME SERVICES CAN TAKE MULTIPLE UNIT SPECIFICATIONS HOWEVER. LET'S BUILD THE SAME TABLE USING THE MULTIPLE SPECIFICATION FEATURE.

UNITS (0) ? 8<CR>

UNIT 1
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0,1<CR>
Q-FACTOR (0) 0 ? 1,0<CR>

UNIT 3
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 2-5<CR>
Q-FACTOR (0) 0 ? 0<CR>

UNIT 7
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 6,7<CR>
Q-FACTOR (0) 0 ? 1<CR>

AS YOU CAN SEE IN THE ABOVE DIALOGUE, THE RUNTIME SERVICES WILL BUILD AS MANY ENTRIES AS IT CAN WITH THE INFORMATION GIVEN IN ANY ONE PASS THROUGH THE QUESTIONS. IN THE FIRST PASS, TWO ENTRIES ARE BUILT SINCE TWO SUB-DEVICES AND Q-FACTORS WERE SPECIFIED. THE SERVICES ASSUME THAT THE CSR ADDRESS IS 160000 FOR BOTH SINCE IT WAS SPECIFIED ONLY ONCE. IN THE SECOND PASS, FOUR ENTRIES WERE BUILT. THIS IS BECAUSE FOUR SUB-DEVICES WERE SPECIFIED. THE "-" CONSTRUCT TELLS THE RUNTIME SERVICES TO INCREMENT THE DATA FROM THE FIRST NUMBER TO THE SECOND. IN THIS CASE, SUB-DEVICES 2, 3, 4 AND 5 WERE SPECIFIED. (IF THE SUB-DEVICE WERE SPECIFIED BY ADDRESSES, THE INCREMENT WOULD BE BY 2 SINCE ADDRESSES MUST BE ON AN EVEN BOUNDARY.) THE CSR ADDRESSES AND Q-FACTORS FOR THE FOUR ENTRIES ARE ASSUMED TO BE 160000 AND 0 RESPECTIVELY SINCE THEY WERE ONLY SPECIFIED ONCE. THE LAST TWO UNITS ARE

SPECIFIED IN THE THIRD PASS.

THE WHOLE PROCESS COULD HAVE BEEN ACCOMPLISHED IN ONE PASS AS SHOWN BELOW.

UNITS (D) ? 8<CR>

UNIT 1

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 0-7<CR>

Q-FACTOR (0) 0 ? 0,1,0,,,,,1,1<CR>

AS YOU CAN SEE FROM THIS EXAMPLE, NULL REPLIES (COMMAS ENCLOSING A NULL FIELD) TELL THE RUNTIME SERVICES TO REPEAT THE LAST REPLY.

2.7 QUICK START-UP PROCEDURE (XXDP+)

TO START-UP THIS PROGRAM:

1. BOOT XXDP+
2. GIVE THE DATE AND ANSWER THE LSI AND 50HZ (IF THERE IS A CLOCK) QUESTIONS
3. TYPE 'R NAME', WHERE NAME IS THE NAME OF THE BIN OR BIC FILE FOR THIS PROGRAM
4. TYPE "START"
5. ANSWER THE "CHANGE HW" QUESTION WITH "Y"
6. ANSWER ALL THE HARDWARE QUESTIONS
7. ANSWER THE "CHANGE SW" QUESTION WITH "N"

WHEN YOU FOLLOW THIS PROCEDURE YOU WILL BE USING ONLY THE DEFAULTS FOR FLAGS AND SOFTWARE PARAMETERS. THESE DEFAULTS ARE DESCRIBED IN SECTIONS 2.3 AND 2.5.

3.0 ERROR INFORMATION

3.1 TYPES OF ERROR MESSAGES

THERE ARE THREE LEVELS OF ERROR MESSAGES THAT MAY BE ISSUED BY A DIAGNOSTIC: GENERAL, BASIC AND EXTENDED. GENERAL ERROR MESSAGES ARE ALWAYS PRINTED UNLESS THE "IER" FLAG IS SET (SECTION 2.3). THE GENERAL ERROR MESSAGE IS OF THE FORM:

NAME TYPE NUMBER ON UNIT NUMBER TST NUMBER PC:XXXXXX
ERROR MESSAGE

WHERE: NAME = DIAGNOSTIC NAME
TYPE = ERROR TYPE (SYS FATAL, DEV FATAL, HARD OR SOFT)
NUMBER = ERROR NUMBER
UNIT NUMBER = 0 - N (N IS LAST UNIT IN PTABLE)
TST NUMBER = TEST AND SUBTEST WHERE ERROR OCCURRED

PC:XXXXXX = ADDRESS OF ERROR MESSAGE CALL

BASIC ERROR MESSAGES ARE MESSAGES THAT CONTAIN SOME ADDITIONAL INFORMATION ABOUT THE ERROR. THESE ARE ALWAYS PRINTED UNLESS THE "IER" OR "IBR" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL MESSAGE.

EXTENDED ERROR MESSAGES CONTAIN SUPPLEMENTARY ERROR INFORMATION SUCH AS REGISTER CONTENTS OR GOOD/BAD DATA. THESE ARE ALWAYS PRINTED UNLESS THE "IER", "IBR" OR "IXR" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL ERROR MESSAGE AND ANY ASSOCIATED BASIC ERROR MESSAGES.

3.2 SPECIFIC ERROR MESSAGES

ERROR	DESCRIPTION
1	'PRINTER ERROR' ERROR CONDITION IN THE PRINTER.
2	'PRINTER NOT READY' PRINTER NOT READY TO ACCEPT DATA.
3	'PRINTER DID NOT INTERRUPT' FAILURE IN INTERFACE LOGIC.
4	'LOADING PRINTER BUFFER DOES NOT CLEAR READY' FAILURE IN INTERFACE LOGIC.
5	'PRINTER INTERRUPTED AT SAME LEVEL AS THE PROCESSOR' FAILURE IN INTERFACE LOGIC.
6	'PRINTER ERROR' ERROR CONDITION IN THE PRINTER.
7	'PRINTER NOT READY' PRINTER NOT READY TO ACCEPT DATA.
8	'PAPER LOW INTERLOCK SWITCH FAILURE' FAULTY INTERLOCK SWITCH.
9	'HAMMER BANK INTERLOCK SWITCH FAILURE' FAULTY INTERLOCK SWITCH.
10	'CHARACTER BAND INTERLOCK SWITCH FAILURE' FAULTY INTERLOCK SWITCH.
11	'DAVFU INCOMPLETE DATA ERROR NOT DETECTED' DAVFU FAILED TO RECOGNIZE RECEIPT OF INCOMPLETE DATA.
12	'DAVFU STOP CODE ERROR NOT DETECTED' DAVFU FAILED TO RECOGNIZE RECEIPT OF DATA THAT DID NOT INCLUDE A STOP BIT

- (ONE) CHARACTER.
- 13 "INTERRUPT SERVICING FOR THE FOLLOWING
DEVICE DID NOT OCCUR"
GLOBAL ERROR INDICATING INTERRUPT FOR
DATA TRANSFER DID NOT OCCUR.
- 14 "PRINTER STATUS ERROR"
GLOBAL ERROR INDICATING PRINTER ERROR
CONDITION.
- 15 "OUTPUT TIMEOUT ERROR"
GLOBAL ERROR INDICATING TRANSMISSION
OF LAST CHARACTER DID NOT OCCUR
WITHIN A GIVEN TIME.

4.0 PERFORMANCE AND PROGRESS REPORTS

PERFORMANCE AND PROGRESS REPORTS ARE NOT SUPPLIED.

5.0 DEVICE INFORMATION TABLES

DEVICE INFORMATION APPEARS IN THE GLOBAL DATA SECTION.

6.0 TEST SUMMARIES

TEST 1
INTERFACE LOGIC
VERIFIES OPERATION OF INTERFACE LOGIC BETWEEN THE PRINTER AND THE CPU.

TEST 2
READY LINE INTERLOCKS
VERIFIES OPERATION OF THE READY INTERLOCK SWITCHES.

TEST 3
FORMS LENGTH SELECTION
VERIFIES ALL POSITIONS OF THE FORM LENGTH SELECT SWITCH FOR PROPER
PAPER MOVEMENT.

TEST 4
PRINTING SPEED MEASUREMENT
DETERMINES PRINTING SPEED ON THE BASIS OF THE PRINTING TIME INTERVAL
AND THE NUMBER OF LINES PRINTED.

TEST 5
DAVFU ERROR DETECTION
CHECKS FOR TWO TYPES OF DAVFU ERRORS:
1. RECEIPT OF INCOMPLETE DATA.
2. RECEIPT OF DATA NOT INCLUDING A STOP BIT (ONE) CHARACTER.

TEST 6

DAVFU LINE COUNT PAPER CONTROL
VERIFIES LINE COUNT METHOD OF PAPER CONTROL USING THE DAVFU.

TEST 7
DAVFU CHANNEL SELECTION PAPER CONTROL
CHECKS DAVFU PAPER ADVANCE BY MEANS OF STOP BITS LOADED IN
DAVFU MEMORY.

TEST 8
DATA TRANSFER PATHS
CHECKS THE DATA TRANSFER PATHS FROM THE PRINTER OUTPUT TO
THE PROCESSOR INTERFACE.

TEST 9
PRINTABLE CHARACTERS
CHECKS FOR PROPER PRINTING OF ALL PRINTABLE CHARACTERS.

TEST 10
NON-PRINTABLE CHARACTERS
CHECKS FOR PROPER DETECTION OF ALL NON-PRINTABLE CHARACTERS.

TEST 11
BAND PATTERN
PRODUCES AN IMAGE OF THE ENTIRE BAND PATTERN.

TEST 12
SPURIOUS HAMMER FIRING
CHECKS FOR SPURIOUS HAMMER FIRINGS BY TAKING NOTE OF ANY
PRINTING THAT MAY OCCUR OUTSIDE A WEDGE PATTERN.

TEST 13
PRINT CONTROL
CHECKS THAT CHARACTERS IN EXCESS OF 132 CHARACTERS ON A LINE
ARE DISREGARDED.

TEST 14
CRITICAL PATH
CHECKS FOR PROPER PRINTER OPERATION WITH A WORST CASE PATTERN.

TEST 15
CHECKS MULTIPLE LINE ADVANCE
CHECKS THE MULTIPLE LINE ADVANCE FOR PROPER PAPER MOVEMENT.

TEST 16
CHARACTER ALIGNMENT
CHECKS CHARACTER ALIGNMENT BY OVERPRINTING EACH LINE.

705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737

.TITLE CZLPLCO LP25, LP26 DIAGNOSTIC
.ENABL AMA
.SBTTL IDENTIFICATION
: PRODUCT CODE: AC-E634A-MC
: PRODUCT NAME: CZLPLCO LP25, LP26 DIAG
: MAINTAINER: SMALL SYSTEMS DIAGNOSTICS
: AUTHORS: JOHN CHATALIAN
: DONALD RICE
: RALPH SCHAUBER
: DATE 13-JUN-80
: COPYRIGHT (C) 1979, 1980
: DIGITAL EQUIPMENT CORPORATION, MAYNARD MASSACHUSETTS 01754
: THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A
: SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLU-
: SION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY
: OTHER COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE
: AVAILABLE TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM
: AND TO ONE WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND
: OWNERSHIP OF THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DEC.
: THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT
: NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL
: EQUIPMENT CORPORATION.
: DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF
: ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.

739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772

:++
: FUNCTIONAL DESCRIPTION
:
: THIS DIAGNOSTIC PROGRAM VERIFIES PROPER OPERATION OF THE LP25 OR LP26
: LINE PRINTER, AND IT'S ASSOCIATED INTERFACE MODULE.
:
: ANY MIX OF LP25 AND LP26 PRINTERS MAY BE TESTED, UP TO A TOTAL OF
: SIXTEEN UNITS.
:
: THE PROGRAM CONSISTS OF SIXTEEN TESTS, THREE OF WHICH ARE FOR THE DAVFU OPTION.
: THREE OF THE PRINTER TESTS INVOLVE MANUAL INTERVENTION. TWO OF THE DAVFU TESTS
: REQUIRE INTERVENTION BY THE OPERATOR.
:
: THE PROGRAM IS COMPATIBLE TO THE PDP-11 DIAGNOSTIC SUPERVISOR, ACT/SLIDE, AND
: XXDP+.
:--

: VERSION A-0 27-SEP-79 R. SCHAUBER

: HISTORY REV. A-0 INITIAL RELEASE
: REV-C SUPERVISOR / XXDP+ COMPATABLE
:
: REV. B-0 DOCUMENTATION CHANGE 29-NOV-79
: CHANGE INIT CODE TO SET PRIO ON NEW PASS
:
: REV. C-0 INCLUDE LP26 SUPPORT 13-JUN-80
: INCLUDE TEST MESSAGES TO THE PRINTERS
: INCLUDES LINE CLOCK SUPPORT FOR LSI-11


```

774          .TITLE CZLPLC0 LP25, LP26 TEST
775          .SBTTL PROGRAM HEADER
776
777          .MCALL SVC
778 000000'   SVC          ;INITIALIZE SUPERVISOR MACROS
779          .MCALL STRUCT
780 000000'   STRUCT      ;STRUCTURED MACRO PACKAGE
781          000000   $LSTIN= 0      ; LIST ASSY CODE LEFT
782          000000   $LSTTAG= 0     ; LIST TAGS LEFT
783          177777   $LOCTAG= -1
784
785          000000   SVCINS= 0      ;LIST INSTRUCTIONS
786          000000   SVCTST= 0     ;LIST TEST TAGS
787          000000   SVCSUB= 0     ;LIST SUBTEST TAGS
788          000000   SVCGBL= 0    ;LIST GLOBAL TAGS
789          000000   SVCTAG= 0    ;LIST OTHER TAGS
790
791          .ENABL AMA
792          .ENABL ABS
793          .ENABL LC
794          002000   .=2000
795
796          002000   BGNMOD
797          002000   POINTER BGNSW,BGNSFT
798
799          002000   HEADER CZLPL,C,0,60,1,340
(4) 002000   L$NAME::      ;DIAGNOSTIC NAME
(4) 002000   103          .ASCII /C/
(4) 002001   132          .ASCII /Z/
(4) 002002   114          .ASCII /L/
(4) 002003   120          .ASCII /P/
(4) 002004   114          .ASCII /L/
(6) 002005   000          .BYTE 0
(6) 002006   000          .BYTE 0
(5) 002007   000          .BYTE 0
(5) 002010   L$REV::      ;REVISION LEVEL
(4) 002010   103          .ASCII /C/
(5) 002011   L$DEPO::    ;0
(4) 002011   060          .ASCII /0/
(5) 002012   L$UNIT::    ;NUMBER OF UNITS
(4) 002012   000000      .WORD 0
(5) 002014   L$TIML::    ;LONGEST TEST TIME
(4) 002014   000060      .WORD 60
(5) 002016   L$HPCP::    ;PTR. TO H.W. PTABLE
(4) 002016   041146      .WORD L$HARD
(5) 002020   L$SPCP::    ;PTR. TO S.W. PTABLE
(4) 002020   041324      .WORD L$SOFT
(5) 002022   L$HPTP::    ;PTR. TO DEF. H.W. PTABLE
(4) 002022   002254      .WORD L$HW
(5) 002024   L$SPTP::    ;PTR. TO S.W. PTABLE
(4) 002024   002272      .WORD L$SW
(5) 002026   L$LADP::    ;DIAG. END ADDRESS
(4) 002026   041736      .WORD L$LAST
(5) 002030   L$STA::     ;RESERVED FOR APT STATS
(4) 002030   000000      .WORD 0
(5) 002032   L$CO::

```

Line	Address	Value	Field	Value	Description
(4)	002032	000000			
(5)	002034		L\$DTYP::	.WORD 0	;DIAGNOSTIC TYPE
(4)	002034	000001			
(5)	002036		L\$APT::	.WORD 1	;APT EXPANSION
(4)	002036	000000			
(5)	002040		L\$DTP::	.WORD 0	;PTR. TO DISPATCH TABLE
(4)	002040	002132			
(5)	002042		L\$PRIO::	.WORD L\$DISPATCH	;DIAGNOSTIC RUN PRIORITY
(4)	002042	000340			
(5)	002044		L\$ENVI::	.WORD 340	;FLAGS DESCRIBE HOW IT WAS SETUP
(4)	002044	000000			
(5)	002046		L\$EXP1::	.WORD 0	;EXPANSION WORD
(4)	002046	000000			
(5)	002050		L\$MREV::	.WORD 0	;SVC REV AND EDIT #
(4)	002050	003			
(3)	002051	003			
(5)	002052		L\$EF::	.BYTE C\$REVISION	;DIAG. EVENT FLAGS
(4)	002052	000000			
(5)	002054	000000			
(5)	002056		L\$SPC::	.WORD 0	
(4)	002056	000000			
(5)	002060		L\$DEVP::	.WORD 0	; POINTER TO DEVICE TYPE LIST
(4)	002060	002240			
(5)	002062		L\$REPP::	.WORD L\$DVTYP	;PTR. TO REPORT CODE
(4)	002062	000000			
(5)	002064		L\$EXP4::	.WORD 0	
(4)	002064	000000			
(5)	002066		L\$EXP5::	.WORD 0	
(4)	002066	000000			
(5)	002070		L\$AUT::	.WORD 0	;PTR. TO ADD UNIT CODE
(4)	002070	000000			
(5)	002072		L\$DUT::	.WORD 0	;PTR. TO DROP UNIT CODE
(4)	002072	000000			
(5)	002074		L\$LUN::	.WORD 0	;LUN FOR EXERCISERS TO FILL
(4)	002074	000000			
(5)	002076		L\$DESP::	.WORD 0	;PTR. TO DIAG. DESCRIPTION
(4)	002076	002172			
(5)	002100		L\$LOAD::	.WORD L\$DESC	;GENERATE SPECIAL AUTOLOAD EMT
(4)	002100	104035			
(5)	002102		L\$ETP::	EMT E\$LOAD	;PTR. TO ERR TBL
(4)	002102	000000			
(5)	002104		L\$IICP::	.WORD 0	;PTR. TO INIT CODE
(4)	002104	005676			
(5)	002106		L\$CCP::	.WORD L\$INIT	;PTR. TO CLEAN-UP CODE
(4)	002106	007352			
(5)	002110		L\$ACP::	.WORD L\$CLEAN	;PTR. TO AUTO CODE
(4)	002110	002264			
(5)	002112		L\$PRT::	.WORD L\$AUTO	;PTR. TO PROTECT TABLE
(4)	002112	002122			
(5)	002114		L\$TEST::	.WORD L\$PROT	;TEST NUMBER
(4)	002114	000000			
(5)	002116		L\$DLY::	.WORD 0	;DELAY COUNT
(4)	002116	000000			
(5)	002120		L\$HIME::	.WORD 0	;PTR. TO HIGH MEM
(4)	002120	000000			

801
802
803
804 002122
(3) 002122
805 002122 000000
806 002124 177777
807 002126 177777
808 002130

: THE FOLLOWING IS A LOAD PROTECTION TABLE
:
: BGNPROT
L\$PROT::
 .WORD 0
 .WORD -1
 .WORD -1
 ENDPROT

810
 811
 812
 813
 814
 815
 816
 817 002130
 (4) 002130 000020
 (3) 002132
 (6) 002132 007546
 (6) 002134 010726
 (6) 002136 013704
 (6) 002140 016162
 (6) 002142 022330
 (6) 002144 023716
 (6) 002146 025422
 (6) 002150 026672
 (6) 002152 027304
 (6) 002154 030132
 (6) 002156 031464
 (6) 002160 033776
 (6) 002162 034446
 (6) 002164 035604
 (6) 002166 037306
 (6) 002170 037764
 818
 819
 820
 821 002172
 (4) 002172
 (3) 002172 055103 050114 041514
 (3) 002200 020060 050114 032462
 (3) 002206 020054 050114 033062
 (3) 002214 050040 044522 052116
 (3) 002222 051105 042040 040511
 (3) 002230 047107 051517 044524
 (3) 002236 000103
 (2)
 822 002240
 (4) 002240
 (3) 002240 050114 032462 046054
 (3) 002246 031120 000066
 (2)
 823
 824
 825

```

.SBTTL DISPATCH TABLE

:++
: THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.
: IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.
:--

DISPATCH      16      ;X= NUMBER OF TESTS
.WORD          16
L$DISPATCH::
.WORD          T1
.WORD          T2
.WORD          T3
.WORD          T4
.WORD          T5
.WORD          T6
.WORD          T7
.WORD          T8
.WORD          T9
.WORD          T10
.WORD          T11
.WORD          T12
.WORD          T13
.WORD          T14
.WORD          T15
.WORD          T16

:FOR USE ON REVISION C OF THE SUPERVISOR
:
DESCRIP        <CZLPLC0 LP25, LP26 PRINTER DIAGNOSTIC>
L$DESC::
.ASCIZ /CZLPLC0 LP25, LP26 PRINTER DIAGNOSTIC/

.EVEN
DEVTYP        <LP25,LP26>
L$DVTYP::
.ASCIZ /LP25,LP26/
.EVEN
  
```

DEFAULT HARDWARE P-TABLE

827
828
829
830
831
832
833
834
835 002252
(3) 002252 000004
(3) 002254
(3) 002254
836 002254 177514
837 002256 000200
838 002260 000000
839
846 002262 000000
847
848
849
850
851
852 002264
(3) 002264
853
854
855
856 002264
(3) 002264
857
858 002264 000240
859
860 002266
(3) 002266
(3) 002266 104461

.SBTTL DEFAULT HARDWARE P-TABLE
:++
: THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
: THE TEST-DEVICE PARAMETERS. THE STRUCTURE OF THIS TABLE
: IS IDENTICAL TO THE RUN-TIME P-TABLE.
:--
BGNHW DFPTBL
.WORD L10001-L\$HW/2
L\$HW::
DFPTBL::
.WORD 177514 ;LP25 REGISTER ADDRESS
.WORD 200 ;LP25 INTERRUPT VECTOR
.WORD 0 ; 0 IF LP25
; 1 IF LP26
.WORD 0 ; 0 IF 64 CHAR BAND
; 1 IF 96 CHAR BAND
: INTERRUPT VECTOR PRIORITY IS 4 AND CANNOT BE CHANGED
L10001: ENDPHW
L\$AUTO: BGAUTO
NOP ; NOT USED
L10002: ENDAUTO
TRAP C\$AUTO

```
862      .SBTTL SOFTWARE P-TABLE
863
864      :++
865      : THE SOFTWARE P-TABLE CONTAINS THE VALUES OF THE PROGRAM
866      : PARAMETERS THAT CAN BE CHANGED BY THE OPERATOR.
867      :--
868
869      002270      BGNSW SFPTBL
      (3) 002270 000006      .WORD L10003-LSSW/2
      (3) 002272
      (3) 002272
870
871      002272 000000      INHINT: .WORD 0      ; 0 IF NO INTERVENTION TESTS
872      ; 1 IF MANUAL INTERVENTION TESTS
873      ; DEFAULT IS NO
874      002274 000000      VFUOPT: .WORD 0      ; 0 IF NO DAVFU OPTION
875      ; 1 IF DAVFU OPTION INSTALLED
876      ; NO DAVFU DEFAULT
877      002276 000000      MANSPPD: .WORD 0      ; 0 FOR AUTOMATIC PRINT SPEED
878      ; 1 FOR MANUAL PRINT SPEED TEST
879      ; AUTOMATIC DEFAULT VALUE
880      002300 000074      PERIOD: .WORD 60.      ; OPERATOR TO SELECT TIMING VALUE
881      ; FROM 4 TO 60 SECONDS. INITIAL
882      ; DEFAULT VALUE IS 60 SECONDS.
883
884      002302 000001      USA: .WORD 1      ; 1 FOR TESTING IN U.S.A.
885      ; 0 FOR TESTING IN G.B./EUROPE
886      ; * DIFFERENT BAND PATTERNS *
887      002304 000005      MAXERR: .WORD 5      ; AUTODROP ERROR COUNT
888      ; IF ERROR COUNT EXCEEDS MAXERR THE UNIT WILL BE DROPPED FROM TEST
889
890      002306      ENDSW
      (5) 002306      L10003:
891
```

```
893 .SBTTL I/O MACRO DEFINITIONS
894
895 .MACRO OUTPUT ADD,BFCNT,ERR,PRINTS
896 MOV ADD,BUFADD ;SAVE THE BUFFER ADDRESS
897 MOV BFCNT,BUFCNT ;BUFFER BYTE COUNT BFCNT
898 MOV #-1,PRINTR ; OUTPUT TO ALL UNITS
899 .IF B ERR
900 MOV #LPERR,ERRSVC
901 .ENDC
902 .IF NB ERR
903 MOV ERR,ERRSVC
904 .ENDC
905 .IF B PRINTS
906 MOV #1,BUFREP ; PRINT ONCE DEFAULT
907 .ENDC
908 .IF NB PRINTS
909 MOV PRINTS,BUFREP ; SUPPLY PRINT COUNT
910 .ENDC
911 JSR PC,IOCTRL ;CALL THE DRIVER
912 .ENDM OUTPUT
913
914
915 .MACRO OUTPUTUI ADD,BFCNT,ERR,UNIT,PRINTS
916 MOV ADD,BUFADD ;SAVE BUFFER ADDRESS
917 MOV BFCNT,BUFCNT ;BUFFER BYTE COUNT BFCNT
918 .IF B ERR
919 MOV #LPERR,ERRSVC
920 .ENDC
921 .IF NB ERR
922 MOV ERR,ERRSVC
923 .ENDC
924 .IF B PRINTS
925 MOV #1,BUFREP ; PRINT ONCE DEFAULT
926 .ENDC
927 .IF NB PRINTS
928 MOV PRINTS,BUFREP ; SUPPLY PRINT COUNT
929 .ENDC
930 MOV UNIT,PRINTR ; SUPPLY UNIT NUMBER
931 JSR PC,IOCTRL ;CALL THE DRIVER
932 .ENDM
933
934
935 ; PRINTS IS A PARAMETER CONTROLLING THE NUMBER IF TIMES THE DATA OR
936 ; MESSAGE IS TO BE PRINTED (SENT TO THE PRINTER). DEFAULT IS 1.
937
938 ; A TIMEOUT OF 20. SECONDS IS FURNISHED BASED ON THE FOLLOWING ASSUMPTIONS :
939 ; 1 A PRINTER SPEED OF 300 LPM
940 ; 2 A REPEAT COUNT OF 88 MAX. ( 1 PAGE OF LINES AT 8 LPI. )
941 ; 3 AN INITIAL BAND STARTUP TIME OF 2.5 SECONDS.
942 .....
943 002306 ENDMOD
```



```

(1)      000200      PRI04== 200
(1)      000140      PRI03== 140
(1)      000100      PRI02== 100
(1)      000040      PRI01== 40
(1)      000000      PRI00== 0
(1)
(1)      ; OPERATOR FLAG BITS
(1)
(1)      000004      EVL==      4
(1)      000010      LOT==      10
(1)      000020      ADR==      20
(1)      000040      IDU==      40
(1)      000100      ISR==     100
(1)      000200      UAM==     200
(1)      000400      BOE==     400
(1)      001000      PNT==    1000
(1)      002000      PRI==    2000
(1)      004000      IXE==    4000
(1)      010000      IBE==   10000
(1)      020000      IER==   20000
(1)      040000      LOE==   40000
(1)      100000      HOE==  100000
958
962      000012      LF==12
963      000014      FF==14
964      000015      CR==15
965      000177      DEL==177
966
967      ; PRIORITY LEVEL DEFINITIONS
968
969      000340      PRI07== 340
970      000300      PRI06== 300
971      000240      PRI05== 240
972      000200      PRI04== 200
973      000140      PRI03== 140
974      000100      PRI02== 100
975      000040      PRI01== 40
976      000000      PRI00== 0
977
978
979      ; GLOBAL ERROR CODES FOR USE BY GENERAL ERROR ROUTINE
980
981      000001      STATER= 1      ; TRANSMITTER STATUS ERROR IN OUTPUT
982      000002      TIMEOUT= 2     ; TIMEOUT ERROR IN IO DRIVER MODULE
983
984
985      000003      NOINTR= 3      ; THIS ERROR INDICATES THE LAST CHARACTER
986
987
988
989      ; SBTTL GENERAL REGISTER USAGE DEFINITIONS
990
991      ; R0      RESERVED FOR USE BY THE MACRO PACKAGES
992      ; R1      MAXIMUM NUMBER OF UNITS TO TEST L$UNIT-1
993      ; R2      UNIT NUMBER BY 2. USED TO CALCULATE OFFSET INTO PROPER
994      ;          PRINTER TABLE
  
```

995		:R3	TEMPORARY STORAGE
996		:R4	
997		:R5	
998		:R6	STACK POINTER
999		:R7	PROGRAM COUNTER
1000		:	

1001
1002
1003
1004
1005
: LP STATUS TABLE BIT DEFINITIONS

1006	100000	ERROR = BIT15	
1007	040000	DROPED = BIT14	
1008	020000	ACTIVE = BIT13	
1009	010000	FLAG96 = BIT12	; 96 CHAR BAND
1010		:BIT11	
1011	002000	FLAG27 = BIT10	; FOR EXPANSION
1012	001000	FLAG26 = BIT9	; 0 IF LP25, 1 IF LP26
1013	000377	LOBYTE = 377	; BIT MASK FOR CLEARING LOBYTE (COUNTER)

1015 .SBTTL GLOBAL DATA SECTION

1016

1017

1018

1019 002306 000000

FLAG: .WORD 0

; <CR> FLAG FOR USE BY SUPERVISOR

1020 002310 000000

LINCNT: .WORD 0

; LINE COUNTER

1021 002312 000000

LSTCNT: .WORD 0

1022 002314 000000

COUNT: .WORD 0

1023 002316 000000

CCNT: .WORD 0

1024 002320 000000

STRCNT: .WORD 0

1025 002322 000000

CHRGEN: .WORD 0

1026 002324 000000

UNIT: .WORD 0

; UNIT COUNTER FOR SINGLE UNIT TESTING

1027 002326 000000

LUNIT: .WORD 0

; UNIT COUNTER FOR ERRORS

1028

; AND TESTS NOT USING THE OUTPUT

1029

; MACROS.

1030 002330 000000

PTABAD: .WORD 0

; P-TABLE ADDRESS RETURNED BY GPHARD

1031 002332 000000

PRINTR: .WORD 0

; SELECTED LINE NO.

1032

; MACRO

1033 002334 000000

CLKTYP: .WORD 0

; CLOCK TYPE CONTROL WORD

1034

; 1= NO CLOCK AVAILABLE

1035

; 2= KW11-L LINE CLOCK

1036

; 3= KW11-P PROGRAMABLE CLOCK

1037 002336 000000

CLOCKP: .WORD 0

; CLOCK P-TABLE ADDRESS

1038 002340 000000

CLKCSR: .WORD 0

; CLOCK CSR ADDRESS

1039 002342 000000

CLKSET: .WORD 0

; CLOCK TIME SET REG ADDRESS

1040 002344 000000

CLKVEC: .WORD 0

; CLOCK VECTOR ADDRESS

1041 002346 000000

CLKENA: .WORD 0

; CLOCK ENABLE BITS

1042 002350 000000

ERRCOD: .WORD 0

; ERROR CODE TYPE FOR GENERAL

1043

; ERROR ROUTINE

1044 002352 000000

ERRFLG: .WORD 0

; EXPECTED ERROR INDICATOR

1045 002354 000000

UUT: .WORD 0

; # UNITS ACTUALLY UNDER TEST

1046

; EXITS BACK TO IO DRIVER EQUAL

1047

; 1 IF ERROR WAS EXPECTED.

1048

1049 002356 000000

INDEX: .WORD 0

1050 002360 000000

VFUCMD: .WORD 0

1051

1052

; MACRO VARIABLES

1053

1054 002362 000000

BUFADD: .WORD 0

; BUFFER ADDRESS OF DATA TO BE SENT

1055

; TO THE PRINTER

1056 002364 000000

BUFCNT: .WORD 0

; NUMBER OF BYTES TO TRANSFER

1057

1058 002366 000000

BUFREP: .WORD 0

; NUMBER OF TIMES TO PRINT

1059

1060

1061

1062

; LP25 PARAMETER WORD TABLES

1063

1064 002370 000020

LPCSR: .REPT 16.
.WORD 0

; ADDRESS OF CSR FOR EACH LP11

1065

1066

1067 002430 000016

LPVEC: .REPT 16
.WORD 0

; INTERRUPT VECTOR ADDRESS

1068

1069

1070 002464 000020

LPBUF: .REPT 16.

; DATA BUFFER REGISTER ADDRESS

```

1071          .WORD 0
1072          .ENDR
1073 002524 000020 STATUS: .REPT 16.          ; UNIT STATUS
1074          .WORD 0
1075          .ENDR
1076 002564 000020 CURADD: .REPT 16.        ; CURRENT ADDRESS OF OUTPUT DATA BYTE
1077          .WORD 0
1078          .ENDR
1079 002624 000020 MSGCNT: .REPT 16.        ; INITIAL BYTE COUNT OF MSG FOR REPEAT RESTORE
1080          .WORD 0
1081          .ENDR
1082 002664 000020 REPCNT: .REPT 16.        ; NO. OF TIMES TO REPEAT MESSAGE
1083          .WORD 0
1084          .ENDR
1085 002724 000020 MSGADR: .REPT 16.        ; ADDRESS OF DATA TO PRINT START OF DATA
1086          .WORD 0
1087          .ENDR
1088 002764 000020 CURCNT: .REPT 16.        ; CURRENT COUNT REMAINING TO OUTPUT
1089          .WORD -1
1090          .ENDR
1091 003024 000020 LPINTR: .REPT 16.        ; INTERRUPT ROUTINE ADDRESS
1092          .WORD 0
1093          .ENDR
1094 003064 000020 DELCNT: .REPT 16.        ; TIMEOUT DELAY COUNTER
1095          .WORD 0
1096          .ENDR
1097 003124 000000 ERRSVC: .WORD 0          ; ERROR ROUTINE DISPATCH ADDRESS
1098 003126 000020 ERRTBL: .REPT 16.        ; ERROR COUNT FOR EACH UNIT
1099          .WORD 0
1100          .ENDR
1101
1102 003166 000000 WORK: .WORD 0          ; WORK AREA
1103 003170 000000 WORK1: .WORD 0
1104
1105
1106          .SBTTL OUTPUT BUFFER
1107          ;
1108          ;150 BYTES IS RESERVED FOR THE OUTPUT BUFFER AREA
1109          ;
1110
1111
1112
1113 003172 000226 OUTBUF: .EVEN
1114          .REPT 150.
1115          .BYTE 0
1116          .ENDR
  
```

```
1118 .SBTTL GLOBAL TEXT SECTION
1119
1120 .NLIST BEX
1121 :++
1122 : THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
1123 : MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
1124 : MORE THAN ONE TEST.
1125 :--
1126 003420 051120 047111 042524 CSRERR: .ASCIZ /PRINTER ERROR/
1127 003436 051120 047111 042524 RDYERR: .ASCIZ /PRINTER NOT READY/
1128 003460 040520 042520 020122 PAPSWI: .ASCIZ /PAPER LOW INTERLOCK SWITCH FAILURE/
1129 003523 110 046501 042515 BNKSWI: .ASCIZ /HAMMER BANK INTERLOCK SWITCH FAILURE/
1130 003570 044103 051101 041501 BNDSWI: .ASCIZ /CHARACTER BAND INTERLOCK SWITCH FAILURE/
1131 003640 051124 047101 046523 INTER1: .ASCIZ /TRANSMIT INTERRUPT TIMEOUT/
1132 003673 120 044522 052116 TXERR: .ASCIZ /PRINTER STATUS ERROR/
1133 003720 052517 050124 052125 OUTTIM: .ASCIZ /OUTPUT TIMEOUT ERROR/
1134 003745 125 044516 020124 TXNOIN: .ASCIZ /UNIT FAILED TO INTERRUPT/
1135 003776 046101 020114 047125 UUTEQO: .ASCIZ /ALL UNITS HAVE BEEN DROPPED..RESTART../
1136 004045 045 022516 044501 VFUSEL: .ASCII /%N%AINSURE THAT VFU-FLS SWITCH ON EACH UNIT IS IN THE /
1137 004133 045 022516 021101 VFUSE1: .ASCIZ /%N%A'VFU' POSITION.%N/
1138 004161 116 020117 046103 NOCLK: .ASCIZ /NO CLOCK AVAILABLE FOR TIMING TESTS/<7><7>
1139 004230 .EVEN
1140
1141
1142 :
1143 :
1144 :
1145 .LIST BEX
1146 :
1147 : FORMAT STATEMENTS USED IN PRINT CALLS
1148 :
1149 :
1150 004230 040445 050114 030461 LPDROP: .ASCIZ /%ALP11 UNIT %D2%A DROPPED FROM TEST%N/
1151 004236 052440 044516 020124
1152 004244 042045 022462 020101
1153 004252 051104 050117 042520
1154 004260 020104 051106 046517
004266 052040 051505 022524
004274 000116
```

1156
1157
1158
1159
1160
1161
1162
1163
1164
1165
1166
1167
1168
1169
1170
1171
1172
1173
1174
1175
1176
1177
1178
1179
1180
1181
1182
1183
1184
1185
1186
1187
1188
1189
1190
1191
1192

.SBTTL GLOBAL SUBROUTINES SECTION

++
 THE GLOBAL SUBROUTINE SECTION CONTAINS THE SUBROUTINES
 THAT ARE USED BY MORE THAN ONE TEST.
 --

++
 FUNCTIONAL DESCRIPTION:
 SUBROUTINE TO PRINT THE GENERAL ERROR INFORMATION.
 PRINTS THE ERROR MESSAGE IN THE FOLLOWING FORMAT:
 "ERROR AT CSR XXXXXX UNIT YY"
 WHERE XXXXXX= DEVICE CSR ADDRESS
 YY= UNIT NUMBER THAT FAILED
 CALLING SEQUENCE
 JSR PC,LPERR
 REQUIRED PARAMETERS
 ERRCOD MUST BE SET TO ONE OF THE ERROR CODES DESCRIBED
 UNDER ERROR CODES.

R2 IS USED INTERNAL TO THE ROUTINE.
 THE ROUTINE DOES A SAVE ON R2
 AND RESTORES IT PRIOR TO EXITING.

004276
 (2) 004276 013746 002350
 (4) 004302 003403
 (3) 004304 021627 000003
 (6) 004310 003402
 (3) 004312
 (3) 004312 012716 000004
 (3) 004316
 (2) 004316 006316
 (2) 004320 060716
 (2) 004322 063607
 (3) 004324
 (4) 004324 000010
 (4) 004326 000036
 (4) 004330 000064
 (3) 004332 000110
 004334
 (4) 004334
 004334
 (6) 004334 005262 003126
 004340
 (4) 004340 010237 002074
 (7) 004344 006237 002074

LPERR: SELECT ERRCOD OF 3 VERIFY ;SELECT PROPER MESSAGE FORMAT
 MOV ERRCOD,-(SP)
 BLE 50000\$
 CMP (SP),#3
 BLE 50001\$
 50000\$: MOV #4,(SP)
 50001\$: ASL (SP)
 ADD PC,(SP)
 ADD @ (SP)+,PC
 50002\$: .WORD 50006\$-50002\$
 .WORD 50005\$-50002\$
 .WORD 50004\$-50002\$
 .WORD 50003\$-50002\$
 50006\$: CASE 1 ;STATUS ERROR
 LET ERRTBL(R2) := ERRTBL(R2) + #1
 INC ERRTBL(R2)
 LET L\$LUN := R2 SHIFT -1
 MOV R2,L\$LUN
 ASR L\$LUN

```

1193 004350          ERRHRD 14, TXERR
(4)  004350 104456   TRAP   C$ERHRD
(5)  004352 000016   .WORD 14
(5)  004354 003673   .WORD TXERR
(5)  004356 000000   .WORD 0
1194
1195 004360          CASE 2          ;OUTPUT TIMEOUT ERROR
(4)  004360 000425   BR     50003$
(4)  004362          50005$:
1196 004362          LET ERRTBL(R2) := ERRTBL(R2) + #1
(6)  004362 005262 003126   INC   ERRTBL(R2)
1197 004366          LET L$LUN := R2 SHIFT -1
(4)  004366 010237 002074   MOV   R2, L$LUN
(7)  004372 006237 002074   ASR   L$LUN
1198 004376          ERRHRD 15, OUTTIM ;
(4)  004376 104456   TRAP   C$ERHRD
(5)  004400 000017   .WORD 15
(5)  004402 003720   .WORD OUTTIM
(5)  004404 000000   .WORD 0
1199
1200 004406          CASE 3
(4)  004406 000412   BR     50004$
(4)  004410          50004$:
1201          ; NEVER RECIEVED THE INTERRUPT
1202 004410          LET ERRTBL(R2) := ERRTBL(R2) + #1
(6)  004410 005262 003126   INC   ERRTBL(R2)
1203 004414          LET L$LUN := R2 SHIFT -1
(4)  004414 010237 002074   MOV   R2, L$LUN
(7)  004420 006237 002074   ASR   L$LUN
1204 004424          ERRHRD 16, TXNOIN
(4)  004424 104456   TRAP   C$ERHRD
(5)  004426 000020   .WORD 16
(5)  004430 003745   .WORD TXNOIN
(5)  004432 000000   .WORD 0
1205
1206
1207
1208 004434          ENDSELECT
(3)  004434          50003$:
1209
1210 004434          IF ERRTBL(R2) GT MAXERR THEN
(6)  004434 026237 003126 002304   CMP   ERRTBL(R2), MAXERR
(9)  004442 003402          BLE   50007$
1211 004444          JSR PC, DROPIE          ; MAXIMUM ERROR COUNT EXCEEDED !
1212 004450          ENDIF
(4)  004450          50007$:
1213 004450          LET STATUS(R2) := STATUS(R2) CLR BY #ERROR
(6)  004450 042762 100000 002524   BIC   #ERROR, STATUS(R2)
1214 004456          LET ERRCOD := #0
(4)  004456 005037 002350   CLR   ERRCOD
1215 004462          LET @LPCSR(R2) := #100          ; CLEAR THE ERROR BIT AND ENABLE INTERRUPTS
(4)  004462 012772 000100 002370   MOV   #100, @LPCSR(R2)
1216 004470          RTS   PC          ;AND EXIT
1217
1218          ;=====
1219          ; BIN2DA          BINARY TO DECIMAL ASCII CONVERSION ROUTINE
    
```

```

1220
1221
1222
1223
1224
1225
1226
1227 004472
   (2) 004472 010446
   (3) 004474 010546
1228 004476
   (4) 004476 016604 000006
1229 004502
   (4) 004502 012705 004664
1230 004506
   (4) 004506 005037 004676
1231 004512
   (4) 004512 005037 004700
1232
1233 004516
   (4) 004516 012737 000004 004702
   (5) 004524 000402
   (4) 004526
   (7) 004526 005337 004702
   (5) 004532
   (5) 004532 005737 004702
   (7) 004536 002435
1234 004540
   (4) 004540
   (6) 004540 026615 000010
   (9) 004544 002405
1235 004546
   (6) 004546 161566 000010
1236 004552
   (6) 004552 005237 004700
1237 004556
   (4) 004556 000770
   (3) 004560
1238
1239 004560
   (6) 004560 005737 004700
   (8) 004564 003003
   (6) 004566 005737 004676
   (9) 004572 003410
   (6) 004574
1240 004574
   (6) 004574 052737 000060 004700
1241 004602
   (4) 004602 113724 004700
1242 004606
   (6) 004606 005237 004676
1243 004612
   (4) 004612 000402
   (3) 004614
1244 004614
   (4) 004614 112724 000040
  
```

```

:
: ENTER WITH NUMBER TO BE CONVERTED ON THE STACK
: FOLLOWED BY THE ADDRESS OF A 5 BYTE BUFFER
: FOR THE ASCII STRING. 5 DIGITS WILL BE CONVERTED
: LEADING ZEROES WILL BE CONVERTED TO SPACES.
: CALL BY JSR PC,BIN2DA
:=====
BIN2DA: PUSH R4,R5
        MOV R4,-(SP)
        MOV R5,-(SP)
        LET R4 := 6(SP) ; GET ADDRESS FOR ASCII STRING
        MOV 6(SP),R4
        LET R5 := #TABLDA ; GET ADDRESS OF DECIMAL TABLE
        MOV #TABLDA,R5
        LET FLAGDA := #0 ; LEADING ZERO FLAG
        CLR FLAGDA
        LET COUNTD := #0
        CLR COUNTD
        ; 8.(SP) HAS NUMBER TO BE CONVERTED
        DECR DIGITS FROM #4 TO #0 BY #1 ; DO 5 DIGITS
        MOV #4,DIGITS
        BR 50010$
50011$: DEC DIGITS
50010$: TST DIGITS
        BLT 50012$
        WHILE 8.(SP) GE (R5) DO ; CREATE A DIGIT
50013$: CMP 8.(SP),(R5)
        BLT 50014$
        LET 8.(SP) := 8.(SP) - (R5)
        SUB (R5),8.(SP)
        LET COUNTD := COUNTD + #1
        INC COUNTD
        ENDDO
        BR 50013$
50014$: ; CONVERT DIGIT TO ASCII OR SUPPLY A SPACE
        IF COUNTD GT #0 OR FLAGDA GT #0 THEN
        TST COUNTD
        BGT 50015$
        TST FLAGDA
        BLE 50016$
50015$: LET COUNTD := COUNTD SET.BY #60
        BIS #60,COUNTD
        LET (R4)+ :B= COUNTD
        MOVB COUNTD,(R4)+
        LET FLAGDA := FLAGDA + #1
        INC FLAGDA
        ELSE
        BR 50017$
50016$: LET (R4)+ :B= #40
        MOVB #40,(R4)+
  
```


1245	004620					50017\$:	ENDIF
(4)	004620						; DO THE NEXT DIGIT
1246							LET R5 := R5 + #2
1247	004620						ADD #2,R5
(6)	004620	062705	000002				LET COUNTD := #0
1248	004624						CLR COUNTD
(4)	004624	005037	004700				ENDDECR
1249	004630						BR 50011\$
(4)	004630	000736				50012\$:	; IF NUMBER WAS A ZERO PRINT A '0'
(3)	004632						IF FLAGDA EQ #0 THEN
1250							TST FLAGDA
1251	004632						BNE 50020\$
(6)	004632	005737	004676				LET -(R4) :B= #60
(9)	004636	001002					MOVB #60,-(R4)
1252	004640						ENDIF
(4)	004640	112744	000060			50020\$:	; CLEAN UP THE STACK AND EXIT
1253	004644						LET 8.(SP) := 4(SP)
(4)	004644						MOV 4(SP),8.(SP)
1254							POP R5,R4
1255	004644	016666	000004	000010			MOV (SP)+,R5
(4)	004644						MOV (SP)+,R4
1256	004652						LET SP := SP + #4
(2)	004652	012605					ADD #4,SP
(3)	004654	012604					RTS PC
1257	004656						
(6)	004656	062706	000004				
1258	004662	000207					
1259							
1260							
1261	004664	023420	001750	000144	TABLDA: .WORD	10000.,1000.,100.,10.,1	
	004672	000012	000001				
1262	004676	000000			FLAGDA: .WORD	0	
1263	004700	000000			COUNTD: .WORD	0	
1264	004702	000000			DIGITS: .WORD	0	
1265							

```

1267 .SBTTL I/O DRIVER
1268
1269
1270
1271
1272 ++
1273 :THE I/O DRIVER ROUTINE IS INVOKED BY MEANS OF THE INTERRUPT SYSTEM.
1274 :CALL TO IT IS JMP IODRV.
1275 :RETURN RTI.
1276 :ENTER ROUTINE WITH R2 SET UP TO DESIRED UNIT *2. R2 IS USED
1277 :TO CALCULATE OFFSET INTO PROPER TABLE.
1278 :R1 EQUALS MAXIMUM NUMBER OF UNITS ON SYSTEM UNDER TEST.
1279
1280
1281 :--
1282 :CHECK FOR ERROR FLAG IN STATUS REG.
1283 IODRV: IF #BIT15 NOTSETIN @LPCSR(R2) THEN
(6) 004704 032772 100000 002370 BIT #BIT15,@LPCSR(R2)
(9) 004712 001061 BNE 50021$
1284
1285 : IF COUNT NOT ZERO SEND NEXT BYTE
1286
1287 IF CURCNT(R2) GT #0 THEN
(6) 004714 005762 002764 TST CURCNT(R2)
(9) 004720 003416 BLE 50022$
1288 004722 LET @LPBUF(R2) :B= @CURADD(R2)
(4) 004722 117272 002564 002464 MOVB @CURADD(R2),@LPBUF(R2)
1289 004730 LET CURADD(R2) := CURADD(R2) + #1
(6) 004730 005262 002564 INC CURADD(R2)
1290
1291 : ENABLE INTERRUPT FOR NEXT BYTE
1292
1293 004734 LET STATUS(R2) := STATUS(R2) SET.BY #ACTIVE
(6) 004734 052762 020000 002524 BIS #ACTIVE,STATUS(R2)
1294 004742 LET CURCNT(R2) := CURCNT(R2) - #1
(6) 004742 005362 002764 DEC CURCNT(R2)
1295 004746 LET @LPCSR(R2) := @LPCSR(R2) SET.BY #100
(6) 004746 052772 000100 002370 BIS #100,@LPCSR(R2)
1296 004754 ELSE
(4) 004754 000437 BR 50023$
(3) 004756
50022$:
1297 : CURRENT MSG DONE, IF PRINT COUNT NOT ZERO SEND AGAIN
1298 004756 LET REPCNT(R2) := REPCNT(R2) - #1
(6) 004756 005362 002664 DEC REPCNT(R2)
1299 004762 IF REPCNT(R2) GT #0 THEN
(6) 004762 005762 002664 TST REPCNT(R2)
(9) 004766 003424 BLE 50024$
1300 004770 LET CURADD(R2) := MSGADR(R2) ; RESTORE THE MSG ADDR
(4) 004770 016262 002724 002564 MOV MSGADR(R2),CURADD(R2)
1301 004776 LET CURCNT(R2) := MSGCNT(R2) ; RESTORE THE BYTE COUNT
(4) 004776 016262 002624 002764 MOV MSGCNT(R2),CURCNT(R2)
1302 005004 LET @LPBUF(R2) :B= @CURADD(R2) ; RESEND THE MESSAGE
(4) 005004 117272 002564 002464 MOVB @CURADD(R2),@LPBUF(R2)
1303 005012 LET CURADD(R2) := CURADD(R2) + #1 ; BUMP THE POINTER
(6) 005012 005262 002564 INC CURADD(R2)
1304 005016 LET CURCNT(R2) := CURCNT(R2) - #1 ; DROP BYTE COUNT

```

```
(6) 005016 005362 002764      DEC    CURCNT(R2)
1305 005022                    LET STATUS(R2) := STATUS(R2) SET.BY #ACTIVE
(6) 005022 052762 020000 002524  BIS    #ACTIVE,STATUS(R2)
1306 005030                    LET @LPCSR(R2) := #100 ; RE-ENABLE INTERRUPTS
(4) 005030 012772 000100 002370  MOV    #100,@LPCSR(R2)
1307 005036                    ELSE
(4) 005036 000406              BR     50025$
(3) 005040                    50024$:
1308                    ; CURRENT MSG DONE, REPEAT COUNT =0
1309                    ; CLEAR ACTIVE AND DISABLE INTERRUPTS.
1310 005040                    LET STATUS(R2) := STATUS(R2) CLR.BY #ACTIVE
(6) 005040 042762 020000 002524  BIC    #ACTIVE,STATUS(R2)
1311 005046                    LET @LPCSR(R2) := #00
(4) 005046 012772 000000 002370  MOV    #00,@LPCSR(R2)
1312 005054                    ENDIF
(4) 005054                    50025$:
1313 005054                    ENDIF
(4) 005054                    50023$:
1314 005054                    ELSE
(4) 005054 000410              BR     50026$
(3) 005056                    50021$:
1315                    ; CLEAR ERROR CONDITION, ENABLE INTERRUPTS
1316                    ; SET ERROR FLAG
1317 005056                    LET STATUS(R2) := STATUS(R2) SET.BY #ERROR
(6) 005056 052762 100000 002524  BIS    #ERROR,STATUS(R2)
1318 005064                    LET ERRCOD := #STATER ; STATUS ERROR
(4) 005064 012737 000001 002350  MOV    #STATER,ERRCOD
1319 005072 004777 176026      JSR PC,@ERRSVC
1320                    ; ERROR SERVICE SHOULD CLEAR ERROR BIT AND ENABLE INTR
1321 005076                    ENDIF
(4) 005076                    50026$:
1322 005076                    POP R2
(2) 005076 012602              MOV    (SP)+,R2
1323 005100 000002              RTI
```

1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339 005102
 (2) 005102 010246
 (3) 005104 010346
1340
1341
1342
1343
1344 005106
 (6) 005106 023727 002332 177777
 (9) 005114 001005
1345 005116
 (4) 005116 013703 002012
1346 005122
 (4) 005122 005037 002074
1347 005126
 (4) 005126 000405
 (3) 005130
1348 005130
 (4) 005130 012703 000001
1349 005134
 (4) 005134 013737 002332 002074
1350 005142
 (4) 005142
1351
1352
1353
1354 005142
1355 005142
 (6) 005142 005703
 (9) 005144 001002
1356 005146
 (2) 005146 000137 005460
1357 005152
 (4) 005152
1358
1359
1360
1361 005152
 (4) 005152 013702 002074
 (7) 005156 006302
1362 005160
 (4) 005160 005037 002350

```
.SBTTL I/O CONTROL
:++
: THE I/O CONTROL SUBROUTINE IS A SINGLE ENTRY QUEUE MANAGER.
: THIS ROUTINE IS INVOKED BY A JSR FROM AN I/O CALL.
: INPUTS:      PRINTR  -1 FOR ALL TERMINALS
:              N      N FOR PRINTER NUMBER 'N'
:              BUFADD ADDRESS OF MESSAGE TO PRINT
:              BUFCNT BYTE COUNT TO TRANSMIT TO PRINTER
:              ERRSVC ADDRESS OF ERROR SERVICE SUBROUTINE
:              BUFREP IS NO. OF TIMES TO PRINT THE MSG
:--

IOCTRL: PUSH R2,R3
        MOV  R2,-(SP)
        MOV  R3,-(SP)

: IF PRINTR IS -1 QUE OUTPUT TO ALL PRINTERS SELECTED
: OTHERWISE TO UNIT NUMBER IN PRINTR.
:
        IF PRINTR EQ #-1 THEN
        CMP  PRINTR,#-1
        BNE  50027$
        LET  R3 := L$UNIT
        MOV  L$UNIT,R3
        LET  L$LUN := #0
        CLR  L$LUN
        ELSE
        BR   50030$
50027$:
        LET  R3 := #1
        MOV  #1,R3
        LET  L$LUN := PRINTR
        MOV  PRINTR,L$LUN
        ENDIF
50030$:
: REPEAT TILL R3 = 0
:
CTLLOP:
        IF R3 EQ #0 THEN
        TST  R3
        BNE  50031$
        INLINE <JMP CTLEND>
        JMP  CTLEND
        ENDIF
50031$:
: USE R2 AS AN INDEX INTO THE UNIT TABLES
:
        LET  R2 := L$LUN SHIFT 1
        MOV  L$LUN,R2
        ASL  R2
        LET  ERRCOD := #0
        CLR  ERRCOD
```

```

1363
1364      ; IF THE UNIT HAS BEEN DROPPED SELECT THE NEXT UNIT
1365      ;
1366 005164      IF #DROPED NOTSETIN STATUS(R2) THEN
(6) 005164 032762 040000 002524      BIT      #DROPED,STATUS(R2)
(9) 005172 001123      BNE      50032$
1367
1368      ; TEST FOR DVC ERROR BIT SET
1369      ;
1370 005174      IF #BIT15 SETIN @LPCSR(R2) THEN
(6) 005174 032772 100000 002370      BIT      #BIT15,@LPCSR(R2)
(9) 005202 001407      BEQ      50033$
1371 005204      LET ERRCOD := #STATER      ; STATUS_REG ERROR BIT 15 SET IN CSR
(4) 005204 012737 000001 002350      MOV      #STATER,ERRCOD
1372 005212      LET STATUS(R2) := STATUS(R2) SET.BY #ERROR
(6) 005212 052762 100000 002524      BIS      #ERROR,STATUS(R2)
1373 005220      ELSE
(4) 005220 000455      BR      50034$
(3) 005222      50033$:
1374      ;
1375      ; MAKE SURE PREVIOUS MSG IS DONE
1376      ;
1377 005222      IF CURCNT(R2) GT #0 THEN
(6) 005222 005762 002764      TST      CURCNT(R2)
(9) 005226 003452      BLE      50035$
1378 005230      IF #ACTIVE NOTSETIN STATUS(R2) THEN
(6) 005230 032762 020000 002524      BIT      #ACTIVE,STATUS(R2)
(9) 005236 001004      BNE      50036$
1379
1380      ; OUTPUT WAS QUEUED BUT I/O DRIVER WAS NEVER INVOKED (VIA INTERRUPT)
1381      ;
1382 005240      LET ERRCOD := #NOINTR      ; NO INTERRUPT
(4) 005240 012737 000003 002350      MOV      #NOINTR,ERRCOD
1383 005246      ELSE
(4) 005246 000442      BR      50037$
(3) 005250      50036$:
1384 005250      WHILE #ACTIVE SETIN STATUS(R2) DO
(4) 005250      50040$:
(6) 005250 032762 020000 002524      BIT      #ACTIVE,STATUS(R2)
(9) 005256 001436      BEQ      50041$
1385
1386 005260      LET DELCNT(R2) := #100.      ; 20 SEC. DELAY MAX
(4) 005260 012762 000144 003064      MOV      #100.,DELCNT(R2)
1387 005266      DELAY 2.      ; 200MS LOOPS
(2) 005266 012727 000002      MOV      #2.,(PC)+
(2) 005272 000000      .WORD 0
(2) 005274 013727 002116      MOV      L$DLY,(PC)+
(2) 005300 000000      .WORD 0
(2) 005302 005367 177772      DEC      -6(PC)
(2) 005306 001375      BNE      -.4
(2) 005310 005367 177756      DEC      -22(PC)
(2) 005314 001367      BNE      -.20
1388 005316      LET DELCNT(R2) := DELCNT(R2) - #1
(6) 005316 005362 003064      DEC      DELCNT(R2)
1389 005322      IF DELCNT(R2) EQ #0 THEN
(6) 005322 005762 003064      TST      DELCNT(R2)

```

```

(9) 005326 001011 BNE 50042$
1390 005330 LET ERRCOD := #TIMOUT
(4) 005330 012737 000002 002350 MOV #TIMOUT,ERRCOD
1391 005336 LET STATUS(R2) := STATUS(R2) CLR.BY #ACTIVE
(6) 005336 042762 020000 002524 BIC #ACTIVE,STATUS(R2)
1392 005344 LET STATUS(R2) := STATUS(R2) SET.BY #ERROR
(6) 005344 052762 100000 002524 BIS #ERROR,STATUS(R2)
1393 005352 ENDF
(4) 005352 50042$: ENDDO
1394 005352 BR 50040$
(4) 005352 000736 50041$: ENDF
(3) 005354 50037$: ENDF
1395 005354 50035$: ENDF
(4) 005354 50034$: ENDF
1396 005354 IF ERRCOD NE #0 THEN
(4) 005354 (6) 005354 005737 002350 TST ERRCOD
(4) 005354 (9) 005360 001403 BEQ 50043$
1399 :
1400 : REPORT THE ERROR
1401 :
1402 005362 004777 175536 JSR PC,@ERRSVC
1403 005366 ELSE
(4) 005366 000425 BR 50044$
(3) 005370 50043$:
1404 :
1405 : Q UP THE MESSAGE AND ENABLE INTERRUPTS
1406 : THE I/O DRIVER WILL PICK UP FROM HERE.
1407 :
1408 005370 LET CURADD(R2) := BUFADD ; BYTE ADDRESS
(4) 005370 013762 002362 002564 MOV BUFADD,CURADD(R2)
1409 005376 LET MSGADR(R2) := BUFADD ; MESSAGE ADDRESS
(4) 005376 013762 002362 002724 MOV BUFADD,MSGADR(R2)
1410 005404 LET CURCNT(R2) := BUFCNT ; OUTPUT COUNT
(4) 005404 013762 002364 002764 MOV BUFCNT,CURCNT(R2)
1411 005412 LET MSGCNT(R2) := BUFCNT ; BYTE COUNT
(4) 005412 013762 002364 002624 MOV BUFCNT,MSGCNT(R2)
1412 005420 LET REPCNT(R2) := BUFREP ; PRINT COUNT
(4) 005420 013762 002366 002664 MOV BUFREP,REPCNT(R2)
1413 005426 IF CURCNT(R2) GT #0 THEN
(6) 005426 005762 002764 TST CURCNT(R2)
(9) 005432 003403 BLE 50045$
1414 005434 LET @LPCSR(R2) := #100 ; ENABLE INTERRUPTS
(4) 005434 012772 000100 002370 MOV #100,@LPCSR(R2)
1415 005442 ENDF
(4) 005442 50045$: ENDF
1416 005442 50044$: ENDF
(4) 005442 50032$: ENDF
1417 005442 :
(4) 005442 : CLEAR OUT ANY TIMEOUT COUNT
1418 :
1419 :
1420 :

```

1421 005442
(4) 005442 005062 003064
1422
1423
1424
1425 005446
(6) 005446 005303
1426 005450
(6) 005450 005237 002074
1427 005454 000137 005142
1428 005460
1429 005460
(2) 005460 012603
(3) 005462 012602
1430 005464 000207
1431
1432
1433
1434
1435
1436
1437
1438
1439
1440 005466
1441 005530 000240
1442 005532 000207
1443

```
      LET DELCNT(R2) := #0
      CLR      DELCNT(R2)
:
: SELECT THE NEXT UNIT AND DECRIMENT THE LINECOUNT
:
      LET R3 := R3 - #1
      DEC   R3
      LET L$LUN := L$LUN + #1
      INC   L$LUN
      JMP   CTLLOP
CTLEND:
      POP  R3,R2
      MOV  (SP)+,R3
      MOV  (SP)+,R2
      RTS  PC

:++++
: SUBROUTINE QUIET
:
: THIS SUBROUTINE WILL EFFECTIVLY DELAY UNTIL ALL QUEUED OUTPUT
: IS FINISHED. THE DELAY IS ACCOMPLISHED BY QUEUEING A NULL
: MESSAGE TO ALL LINES.
:-----
QUIET:  OUTPUT #0,#0      ; NULL MESSAGE OUTPUT
      NOP
      RTS  PC
```

1445
 1446
 1447
 1448
 1449
 1450
 1451
 1452
 1453 005534
 (6) 005534 052762 040000 002524
 1454 005542
 (4) 005542 012762 177777 002764
 1455 005550
 (4) 005550 005072 002370
 1456 005554
 (8) 005554 013746 002074
 (7) 005560 012746 004230
 (6) 005564 012746 000002
 (3) 005570 010600
 (4) 005572 104417
 (4) 005574 062706 000006
 1457 005600
 (4) 005600 005062 003126
 1458 005604
 (6) 005604 005337 002354
 1459 005610
 (6) 005610 005737 002354
 (9) 005614 001011
 1460 005616
 (7) 005616 012746 003776
 (6) 005622 012746 000001
 (3) 005626 010600
 (4) 005630 104417
 (4) 005632 062706 000004
 1461 005636
 (3) 005636 104444
 1462 005640
 (4) 005640
 1463 005640 000207
 1464
 1465
 1466
 1467
 1468
 1469
 1470
 1471
 1472
 1473
 1474 005642
 (4) 005642 005037 002074
 1475 005646
 (4) 005646
 (6) 005646 023737 002074 002012
 (9) 005654 002007
 1476 005656

```

=====
: DROPIT          FUNCTIONAL DESCRIPTION :
:
: THIS SUBROUTINE IS USED TO DROP A BAD PRINTER FROM THE TEST
: DISABLE ANY INTERRUPTS FROM THE PRINTER, AND NOTIFY THE
: OPERATOR THAT THE PRINTER WAS DROPPED.
=====
  
```

```

DROPI: LET STATUS(R2) := STATUS(R2) SET.BY #DROPED
      BIS #DROPED,STATUS(R2)
      LET CURCNT(R2) := #-1
      MOV #-1,CURCNT(R2)
      LET @LPCSR(R2) := #0
      CLR @LPCSR(R2)
      PRINTF "L'DROP, L$LUN
      MOV L$LUN,-(SP)
      MOV #LPDRO,-(SP)
      MOV #2,-(SP)
      MOV SP,RO
      TRAP C$PNTF
      ADD #6,SP
      LET ERRTBL(R2) := #0
      CLR ERRTBL(R2)
      LET UUT := UUT - #1
      DEC UUT
      IF UUT EQ #0 THEN
      TST UUT
      BNE 50046$
      PRINTF #UUTEQO
      MOV #UUTEQO,-(SP)
      MOV #1,-(SP)
      MOV SP,RO
      TRAP C$PNTF
      ADD #4,SP
      DOCLN ; NOTHING TO TEST
      TRAP C$DCLN
      ENDIF
50046$: RTS PC
  
```

```

=====
: FAKE          FUNCTIONAL DESCRIPTION:
:
: THIS SUBROUTINE IS REQUIRED TO INSURE PROPER PASS COUNT REPORTS
: IN A MULTI UNIT MODE OF OPERATION.
=====
  
```

```

FAKE: LET L$LUN := #0
      CLR L$LUN
      WHILE L$LUN LT LSUNIT DO
50047$: CMP L$LUN,LSUNIT
      BGE 50050$
      GPHARD L$LUN, R3
  
```


(3)	005656	013700	002074	MOV	L\$LUN,R0
(3)	005662	104442		TRAP	C\$GPHRD
(3)	005664	010003		MOV	R0,R3
1477	005666			LET	L\$LUN := L\$LUN + #1
(6)	005666	005237	002074	INC	L\$LUN
1478	005672			ENDDO	
(4)	005672	000765		BR	50047\$
(3)	005674				
1479	005674	000207	50050\$:	RTS	PC
1480					
1481					
1482	005676			ENDMOD	

1484
1485
1486
1487
1488
1489
1490
1491
1492 005676
1493 005676
 (3) 005676
1494
1495
1496 005676
 (3) 005676 012700 000040
 (3) 005702 104447
1497 005704
 (2) 005704 103413
1498 005706
 (3) 005706 012700 000037
 (3) 005712 104447
1499 005714
 (2) 005714 103407
1500
1501 005716 004737 005642
1502 005722
 (3) 005722 012700 000000
 (3) 005726 104441
1503 005730
 (3) 005730 104432
 (3) 005732 001332
1504
1505
1506
1507 005734
 (3) 005734 104433
1508 005736
 (6) 005736 023727 002012 000020
 (9) 005744 003420
1509 005746
 (7) 005746 012746 006654
 (6) 005752 012746 000001
 (3) 005756 010600
 (4) 005760 104417
 (4) 005762 062706 000004
1510 005766
 (7) 005766 012746 006737
 (6) 005772 012746 000001
 (3) 005776 010600
 (4) 006000 104417
 (4) 006002 062706 000004
1511 006006
 (4) 006006
1512 006006
 (3) 006006 104450
1513 006010

```
.SBTTL  INITIALIZATION SECTION
:++
:THE INITIALIZE ROUTINE IS EXECUTED AT THE BEGINNING OF EACH SUB-PASS AND IS
:PRIMARILY USED FOR REQUESTING P-TABLE PARAMETERS. INFORMATION REQUESTED FROM
:THE OPERATOR INCLUDE THE NUMBER OF UNITS UNDER TEST, DEVICE ADDRESSES, VECTORS,
:CLOCK TYPE, AUTO OR MANUAL PRINTING SPEED MEASUREMENT, AND WHETHER A DAVFU
:OPTION IS INSTALLED IN THE SYSTEM.
:--
BGNMOD
BGNINIT
L$INIT::
;RESET EXTERNAL BUS IF START EVENT FLAG IS SET
;OR POWER FAIL RESTART
    READEF  #EF.START          ;TEST START EF INDICATOR
    MOV     #EF.START,RO
    TRAP   C$REFG
    BCOMPLETE 1$              ;BRANCH IF FROM START UP
    BCS    1$
    READEF  #EF.RESTART       ;NOW THE RESTARTFLAG
    MOV     #EF.RESTART,RO
    TRAP   C$REFG
    BCOMPLETE 1$              ;IF EITHER START OR POWER FAIL RESTART
    BCS    1$
                                ;DO A BUS RESET
                                ; UPDATE PASS COUNT
                                ; PRIORITY ZERO
    JSR    PC,FAKE
    SETPRI #PRI00
    MOV    #PRI00,RO
    TRAP  C$SPRI
                                ; ELSE EXIT INIT CODE
    EXIT  INIT
    TRAP  C$EXIT
    .WORD L10004-.

;POWER UP RESTART OR START COMMAND ISSUED
1$:  BRESET          ;RESET THE BUS
    TRAP   C$RESET
    IF L$UNIT GT #16. THEN
    CMP    L$UNIT,#16.
    BLE    50051$
        PRINTF #NRGT16
    MOV    #NRGT16,-(SP)
    MOV    #1,-(SP)
    MOV    SP,RO
    TRAP  C$PNTF
    ADD    #4,SP
        PRINTF #NRGT17
    MOV    #NRGT17,-(SP)
    MOV    #1,-(SP)
    MOV    SP,RO
    TRAP  C$PNTF
    ADD    #4,SP
    ENDIF
50051$:
    MANUAL          ; WAIT FOR CR IF IN MANUAL MODE
    TRAP   C$MANI
    BNCOMPLETE 100$
```

```

(2) 006010 103016          BCC      100$
1514
1515 006012          PRINTF  #MRESET          ;PRINT RESET MESSAGE
(7) 006012 012746 006773  MOV      #MRESET,-(SP)
(6) 006016 012746 000001  MOV      #1,-(SP)
(3) 006022 010600          MOV      SP,R0
(4) 006024 104417          TRAP    C$PNTF
(4) 006026 062706 000004  ADD      #4,SP
1516
1517          ;WAIT FOR A "CR" BEFORE GOING ON
1518
1519 006032          LET FLAG := #0
(4) 006032 005037 002306  CLR      FLAG
1520 006036          LET ERRCOD := #0
(4) 006036 005037 002350  CLR      ERRCOD
1521 006042          LET UUT := #0
(4) 006042 005037 002354  CLR      UUT
1522 006046          100$:
1523 006046          GMANIL  READY,FLAG,100000,YES ;GET MANUAL PARAMETERS
(3) 006046 104443          TRAP    C$GMAN
(3) 006050 000404          BR      10000$
(4) 006052 002306          .WORD  FLAG
(5) 006054 000130          .WORD  T$CODE
(5) 006056 007072          .WORD  READY
(5) 006060 100000          .WORD  100000
(3) 006062          10000$:
1524          ;REQUEST P-TABLE FOR PRINTERS UNDER TEST
1525
1526
1527 006062          2$: LET R1 := L$UNIT - #1          ;MAXIMUM NUMBER OF UNITS
(4) 006062 013701 002012  MOV      L$UNIT,R1
(6) 006066 005301          DEC      R1
1528 006070          INCR L$LUN FROM #0 TO R1 BY #1
(4) 006070 005037 002074  CLR      L$LUN
(5) 006074 000402          BR      50052$
(4) 006076          50053$:
(7) 006076 005237 002074  INC      L$LUN
(5) 006102          50052$:
(5) 006102 023701 002074  CMP      L$LUN,R1
(7) 006106 003132          BGT     50054$
1529 006110          GPHARD L$LUN,R3          ;REQUEST P-TABLE ADDRESS
(3) 006110 013700 002074  MOV      L$LUN,R0
(3) 006114 104442          TRAP    C$GPHRD
(3) 006116 010003          MOV     R0,R3
1530 006120          ENCOMPLETE 3$          ;BRANCH IF DEVICE NOT PRESENT
(2) 006120 103121          BCC     3$
1531 006122          LET R2 := L$LUN SHIFT 1
(4) 006122 013702 002074  MOV     L$LUN,R2
(7) 006126 006302          ASL     R2
1532
1533          ; CLEAR ERROR COUNT, OUTPUT COUNT, GET DEVICE TYPE TO STATUS.
1534
1535 006130          IF 4(R3) EQ #0 THEN
(6) 006130 005763 000004  TST     4(R3)
(9) 006134 001004          BNE     50055$
1536 006136          LET STATUS(R2) := STATUS(R2) CLR.BY #FLAG26!FLAG27
  
```

```

(6) 006136 042762 003000 002524      BIC      #FLAG26!FLAG27,STATUS(R2)
1537 006144                                     ELSE
(4) 006144 000416                                     BR      50056$
(3) 006146                                     50055$:
1538 006146                                     IF 4(R3) EQ #1 THEN
(6) 006146 026327 000004 000001      CMP      4(R3),#1
(9) 006154 001007                                     BNE     50057$
1539 006156                                     LET STATUS(R2) := STATUS(R2) SET.BY #FLAG26
(6) 006156 052762 001000 002524      BIS     #FLAG26,STATUS(R2)
1540 006164                                     LET STATUS(R2) := STATUS(R2) CLR.BY #FLAG27
(6) 006164 042762 002000 002524      BIC     #FLAG27,STATUS(R2)
1541 006172                                     ELSE
(4) 006172 000403                                     BR      50060$
(3) 006174                                     50057$:
1542 006174                                     LET STATUS(R2) := STATUS(R2) SET.BY #FLAG26!FLAG27
(6) 006174 052762 003000 002524      BIS     #FLAG26!FLAG27,STATUS(R2)
1543 006202                                     ENDIF
(4) 006202                                     50060$:
1544 006202                                     ENDIF
(4) 006202                                     50056$:
1545 :
1546 : NOW GET THE BAND TYPE 64 OR 96 CHARACTER
1547 :
1548 006202                                     IF 6(R3) EQ #0 THEN
(6) 006202 005763 000006      TST     6(R3)
(9) 006206 001004      BNE     50061$
1549 006210                                     LET STATUS(R2) := STATUS(R2) CLR.BY #FLAG96
(6) 006210 042762 010000 002524      BIC     #FLAG96,STATUS(R2)
1550 006216                                     ELSE
(4) 006216 000403      BR      50062$
(3) 006220                                     50061$:
1551 006220                                     LET STATUS(R2) := STATUS(R2) SET.BY #FLAG96
(6) 006220 052762 010000 002524      BIS     #FLAG96,STATUS(R2)
1552 006226                                     ENDIF
(4) 006226      50062$:
1553 006226      LET ERRTBL(R2) := #0
(4) 006226 005062 003126      CLR     ERRTBL(R2)
1554 006232      LET CURCNT(R2) := #-1
(4) 006232 012762 177777 002764      MOV     #-1,CURCNT(R2)
1555 006240      LET DELCNT(R2) := #0
(4) 006240 005062 003064      CLR     DELCNT(R2)
1556 006244      LET REPCNT(R2) := #0
(4) 006244 005062 002664      CLR     REPCNT(R2)
1557 :
1558 : LOAD CSR ADDRESS INTO TABLE
1559 :
1560 006250      LET LPCSR(R2) := (R3)+ ;SET UP CSR ADDRESS FOR DEVICE
(4) 006250 012362 002370      MOV     (R3)+,LPCSR(R2)
1561 006254      LET LPBUF(R2) := LPCSR(R2) + #2
(4) 006254 016262 002370 002464      MOV     LPCSR(R2),LPBUF(R2)
(6) 006262 062762 000002 002464      ADD     #2,LPBUF(R2)
1562 :
1563 : SET UP VECTOR ADDRESS INTO GIVEN TABLE
1564 :
1565 006270      LET LPVEC(R2) := (R3)+
(4) 006270 012362 002430      MOV     (R3)+,LPVEC(R2)

```

```

1566
1567
1568
1569 006274
(4) 006274 010237 003166
(7) 006300 006337 003166
(7) 006304 006337 003166
(7) 006310 006337 003166
1570 006314
(6) 006314 062737 040466 003166
1571 006322
(4) 006322 013762 003166 003024
1572 006330
(7) 006330 012746 000200
(6) 006334 016246 003024
(5) 006340 016246 002430
(4) 006344 012746 000003
(3) 006350 104437
(2) 006352 062706 000010
1573
1574
1575
1576 006356
(6) 006356 005237 002354
1577 006362 000403
1578
1579
1580
1581 006364
(6) 006364 052762 040000 002524
1582 006372
(4) 006372 000641
(3) 006374
1583
1584
1585
1586
1587 006374
(4) 006374 012737 000001 002334
1588 006402
(3) 006402 012700 000114
(3) 006406 104462
(3) 006410 010004
1589 006412
(6) 006412 103031
1590 006414
(4) 006414 012737 000002 002334
1591 006422
(4) 006422 010437 002336
1592 006426
(4) 006426 017737 173704 002340
1593 006434
(4) 006434 012777 000000 173676
1594
1595 006442
(4) 006442 016437 000004 002344
  
```

```

: SET UP DEVICE INTERRUPT VECTOR INFORMATION
:
LET WORK := R2 SHIFT 3
MOV R2,WORK
ASL WORK
ASL WORK
ASL WORK
LET WORK := WORK + #INT00
ADD #INT00,WORK
LET LPINTR(R2) := WORK
MOV WORK,LPINTR(R2)
SETVEC LPVEC(R2), LPINTR(R2), #PRI04
MOV #PRI04,-(SP)
MOV LPINTR(R2),-(SP)
MOV LPVEC(R2),-(SP)
MOV #3,-(SP)
TRAP C$$VEC
ADD #10,SP

: ADD ONE TO UNIT UNDER TEST COUNT
:
LET UUT := UUT + #1
INC UUT
BR 4$

: INDICATE L$LUN NOT AVAILABLE FOR TESTING
3$: LET STATUS(R2) := STATUS(R2) SET.BY #DROPE
BIS #DROPE,STATUS(R2)
4$: ENDINC ;GO BACK AND DO IT AGAIN
BR 50053$
50054$:

: SETUP TO HANDLE CLOCK INTERRUPTS
: IF AN L-CLOCK IS ON THE SYSTEM THEN SETUP A NOOP INTERRUPT
: HANDLER BECAUSE LSI SYSTEMS MAY HAVE THE CLOCK ENABLED AT ALL TIMES.
LET CLKTYP := #1 ; DEFAULT FOR NO CLOCK ON SYSTEM
MOV #1,CLKTYP
CLOCK L,R4 ; TEST FOR L-CLOCK
MOV #1,R0
TRAP C$CLCK
MOV R0,R4
IFCOND CS THEN ; WE HAVE AN L-CLOCK
BCC 50063$
LET CLKTYP := #2
MOV #2,CLKTYP
LET CLGCKP := R4
MOV R4,CLOCKP
LET CLKCSR := @CLOCKP
MOV @CLOCKP,CLKCSR
LET @CLKCSR := #00 ; TRY TO DISABLE INTERRUPTS
MOV #00,@CLKCSR
; SETUP THE NOOP HANDLER
LET CLKVEC := 4(R4)
MOV 4(R4),CLKVEC
  
```

```

1596 006450          SETVEC CLKVEC,#IGNORE,#PRI06
(7) 006450 012746 000300      MOV #PRI06,-(SP)
(6) 006454 012746 007266      MOV #IGNORE,-(SP)
(5) 006460 013746 002344      MOV CLKVEC,-(SP)
(4) 006464 012746 000003      MOV #3,-(SP)
(3) 006470 104437          TRAP C$$SVEC
(2) 006472 062706 000010      ADD #10,SP
1597 006476          ENDIF
(4) 006476          50063$:
1598          ; IF THE OPERATOR WANTS MANUAL SPEED TEST SET CLOCK TYPE = 4
1599 006476 005737 002276      TST MANSPP
1600 006502 001410          BEQ CK1
1601 006504          LET CLKTYP := #4
(4) 006504 012737 000004 002334  MOV #4,CLKTYP
1602 006512          SETPRI #PRI00          ; START TEST AT PRI 0
(3) 006512 012700 000000      MOV #PRI00,R0
(3) 006516 104441          TRAP C$$SPRI
1603 006520          EXIT INIT
(3) 006520 104432          TRAP C$EXIT
(3) 006522 000542          .WORD L10004-
1604          ; IF A P-CLOCK IS ON THE SYSTEM UPGRADE CLOCK TYPE TO 3
1605 006524          CK1:
(3) 006524 012700 000120      CLOCK P,R4
(3) 006530 104462          MOV #P,R0
(3) 006532 010004          TRAP C$CLCK
1606 006534          MOV R0,R4
(6) 006534 103016          IFCOND CS THEN          ; WE HAVE A P-CLOCK
1607 006536          BCC 50064$
(4) 006536 012737 000004 002334  MOV LET CLKTYP := #4
1608 006544          MOV #4,CLKTYP
(4) 006544 010437 002336      MOV LET CLOCKP := R4
1609 006550          MOV R4,CLOCKP
(4) 006550 017737 173562 002340  MOV LET CLKCSR := @CLOCKP
1610 006556          MOV @CLOCKP,CLKCSR
(4) 006556 016437 000004 002344  MOV LET CLKVEC := 4(R4)
1611          MOV 4(R4),CLKVEC
1612 006564          ; TRY TO DISABLE THE P-CLOCK
(4) 006564 012777 000000 173546  MOV LET @CLKCSR := #00
1613 006572          MOV #00,@CLKCSR
(4) 006572          ENDIF
1614          50064$:
1615 006572          ; IF NO CLOCKS ON THE SYSTEM NOTIFY THE OPERATOR
(6) 006572 023727 002334 000001  IF CLKTYP EQ #1 THEN
(9) 006600 001020          CMP CLKTYP,#1
1616 006602          BNE 50065$
(7) 006602 012746 007127      PRINTF #NOCLCK
(6) 006606 012746 000001      MOV #NOCLCK,-(SP)
(3) 006612 010600          MOV #1,-(SP)
(4) 006614 104417          MOV SP,R0
(4) 006616 062706 000004      TRAP C$PNTF
1617 006622          ADD #4,SP
(7) 006622 012746 007171      PRINTF #NOTIM
(6) 006626 012746 000001      MOV #NOTIM,-(SP)
(3) 006632 010600          MOV #1,-(SP)
(4) 006634 104417          MOV SP,R0
(4) 006636 062706 000004      TRAP C$PNTF
(4) 006636 062706 000004      ADD #4,SP
  
```

```

1618 006642          ENDIF
      (4) 006642          50065$:
1619 006642          SETPRI #PRI00
      (3) 006642 012700 000000      MOV #PRI00, #0
      (3) 006646 104441          TRAP C$SPRI
1620 006650          EXIT INIT
      (3) 006650 104432          TRAP C$EXIT
      (3) 006652 000412          .WORD L10004-.
1621          .NLIST BEX
1622
1623 006654 047045 040445 052516 NRGT16: .ASCIZ /%N%NUMBER OF LINE PRINTERS UNDER TEST EXCEEDS 16./
1624 006737 045 022516 047501 NRGT17: .ASCIZ /%N%ONLY 16 WILL BE TESTED./
1625 006773 045 022516 051101 MRESET: .ASCIZ /%N%ARESET LINE PRINTER(S), DO FORM FEED, AND PLACE ON LINE.%N/
1626
1627 007072 042504 051120 051505 READY: .ASCIZ /DEPRESS "RETURN" WHEN READY./
1628 007127 045 022516 044101 NOCLCK: .ASCIZ /%N%AHARDWARE CLOCK NCT AVAILABLE./
1629 007171 045 022516 040501 NOTIM: .ASCIZ /%N%AAUTO PRINTING SPEED MEASUREMENT CANNOT BE PERFORMED./
1630          .EVEN
1631 007262 000000      PLOC: .WORD 0
1632
1633          .LIST BEX
1634 007264          ENDINIT
      (3) 007264          L10004:
      (3) 007264 104411          TRAP C$INIT
1635
1636          ;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
1637          ; IGNORE          AN INTERRUPT CATCHER FOR THE L-CLOCK
1638          ;          THAT IGNORES THE INTERRUPT.
1639          ;          USED FOR SYSTEMS WHERE CLOCK CANNOT BE TURNED OFF.
1640          ;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
1641
1642 007266          IGNORE:          ; NOOP
1643 007266 000002          RTI
1644
1645
1646
1647
1648          -----
1649          RESVEC          FUNCTIONAL DESCRIPTION
1650
1651          THIS SUBROUTINE WILL SETUP ALL UNITS VECTOR AREAS
1652          TO THE 'NORMAL' INTERRUPT ROUTINES STARTING AT INT00.
1653          -----
1654
1655 007270          RESVEC::          PUSH R3,R4
      (2) 007270 010346          MOV R3,-(SP)
      (3) 007272 010446          MOV R4,-(SP)
1656 007274          LET R4 := #0
      (4) 007274 005004          CLR R4
1657 007276          LET R3 := L$UNIT
      (4) 007276 013703 002012      MOV L$UNIT,R3
1658 007302          WHILE R3 GT #0 DO
      (4) 007302
      (6) 007302 005703          50066$:          TST R3
      (9) 007304 003417          BLE 50067$
1659 007306          SETVEC LPVEC(R4), LPINTR(R4), #PRI04
  
```

```
(7) 007306 012746 000200      MOV    #PRI04,-(SP)
(6) 007312 016446 003024      MOV    LPINTR(R4),-(SP)
(5) 007316 016446 002430      MOV    LPVEC(R4),-(SP)
(4) 007322 012746 000003      MOV    #3,-(SP)
(3) 007326 104437              TRAP   C$$SVEC
(2) 007330 062706 000010      ADD    #10,SP
1660 007334                    LET R4 := R4 + #2
(6) 007334 062704 000002      ADD    #2,R4
1661 007340                    LET R3 := R3 - #1
(6) 007340 005303              DEC    R3
1662 007342                    ENDDO
(4) 007342 000757              BR     50066$
(3) 007344                    50067$:
1663 007344                    POP R4,R3
(2) 007344 012604              MOV    (SP)+,R4
(3) 007346 012603              MOV    (SP)+,R3
1664 007350 000207              RTS   PC
1665
```


1667
1668 007352
 (2)
1669
1670
1671
1672
1673
1674
1675
1676
1677
1678 007352
 (2)
1679 007352
 (3) 007352
1680 007352
 (3) 007352 012700 000340
 (3) 007356 104441
1681 007360
 (3) 007360 104433
1682
1683 007362
 (4) 007362 013701 002012
 (6) 007366 005301
1684 007370
 (4) 007370 005037 002074
 (5) 007374 000402
 (4) 007376
 (7) 007376 005237 002074
 (5) 007402
 (5) 007402 023701 002074
 (7) 007406 003020
1685
1686
1687 007410
 (4) 007410 013702 002074
 (7) 007414 006302
1688
1689 007416
 (6) 007416 042762 160377 002524
1690 007424
 (4) 007424 012762 177777 002764
1691 007432
 (4) 007432 005062 003126
1692 007436
 (4) 007436 005062 003064
1693 007442
 (4) 007442 005062 002664
1694 007446
 (4) 007446 000753
 (3) 007450
1695 007450 004737 007270
1696 007454
 (6) 007454 023727 002334 000003
 (9) 007462 001006

```
.SBTTL CLEANUP CODING SECTION
STARS
:*****
:++
:THE PURPOSE OF THE CLEANUP SECTION IS TO CLEANUP ALL PRINTERS UNDER TEST
:AND RETEST ANY UNITS WHICH HAVE BEEN DROPPED FROM TESTING TO INSURE THAT
:THEY HAVE NOT COME BACK ON LINE. IF THE DEVICE HAS COME BACK ON LINE
:TESTING WILL BE RESTARTED ON THE DEVICE. THIS INSURES THAT
:IN THE EVENT A PAPER OUT OCCURRED AND THE OPERATOR HAS PUT ADDITIONAL PAPER
:INTO THE UNIT UNDER TEST, THE INITIALIZATION SEQUENCE DOES NOT
:HAVE TO BE DONE AGAIN IN ORDER TO GET THE DEVICE ACTIVE.
:--
STARS
:*****
BGNCLN
L$CLEAN::
    SETPRI #PRI07
    MOV     #PRI07,R0
    TRAP   C$SPRI
          BRESET
    TRAP   C$RESET

CLEAN:  LET R1 := L$UNIT - #1 ;NUMBER OF UNITS-1
        MOV     L$UNIT,R1
        DEC     R1
        INCR  L$LUN FROM #0 TO R1 BY #1
        CLR    L$LUN
        BR     50070$
50071$: INC     L$LUN
50070$: CMP    L$LUN,R1
        BGT    50072$
        ; DISABLE ALL INTERRUPTS, SELECT ALL LINES
        ; ZERO ALL ERROR COUNTS
        LET R2 := L$LUN SHIFT 1
        MOV    L$LUN,R2
        ASL   R2
        ; CLEAR ALL BITS IN STATUS EXCEPT DEVICE TYPE
        LET STATUS(R2) := STATUS(R2) CLI:BY #ERROR!DROPE!ACTIVE!LOBYTE
        BIC   #ERROR!DROPE!ACTIVE!LOBYTE,STATUS(R2)
        LET CURCNT(R2) := #-1
        MOV   #-1,CURCNT(R2)
        LET ERRIBL(R2) := #0
        CLR   ERRIBL(R2)
        LET DELCNT(R2) := #0
        CLR   DELCNT(R2)
        LET REPCNT(R2) := #0
        CLR   REPCNT(R2)
        ENDINC
        BR    50071$
50072$: JSR   PC,RESVEC ; RESET THE VECTORS
        IF CLKTYP EQ #3 THEN
        CMP   CLKTYP,#3
        BNE   50073$
```

1697	007464				CLRVEC @CLKVEC
(3)	007464	017700	172654		MOV @CLKVEC,RO
(3)	007470	104436			TRAP C\$CVEC
1698	007472				LET @CLKCSR := #00
(4)	007472	012777	000000	172640	MOV #00,@CLKCSR
1699	007500				ENDIF
(4)	007500			50073\$:	
1700	007500				IF CLKTYP EQ #2 THEN
(6)	007500	023727	002334	000002	CMP CLKTYP,#2
(9)	007506	001013			BNE 50074\$
1701	007510				SETVEC CLKVEC,#IGNORE,#PRI06
(7)	007510	012746	000300		MOV #PRI06,-(SP)
(6)	007514	012746	007266		MOV #IGNORE,-(SP)
(5)	007520	013746	002344		MOV CLKVEC,-(SP)
(4)	007524	012746	000003		MOV #3,-(SP)
(3)	007530	104437			TRAP C\$SVEC
(2)	007532	062706	00001^		ADD #10,SP
1702	007536				ENDIF
(4)	007536			50074\$:	
1703	007536				SETPRI #PRI00
(3)	007536	012700	000000		MOV #PRI00,RO
(3)	007542	104441			TRAP C\$SPRI
1704	007544			ENDCLN	
(3)	007544			L10005:	
(3)	007544	104412			TRAP C\$CLEAN
1705					
1706	007546			ENDMOD	

1708
 1709
 1710 007546
 1711
 1712
 1713
 1714
 1715
 1716
 1717
 1718
 1719
 1720
 1721 007546
 (3) 007546
 1722 007546
 (4) 007546 013701 002012
 (6) 007552 005301
 1723
 1724
 1725
 1726
 1727 007554 005037 002326
 1728 007560 000402
 1729 007562
 1730 007562 005237 002326
 1731 007566
 1732 007566 023701 002326
 1733 007572 003402
 1734 007574 000137 010264
 1735 007600
 1736 007600
 (4) 007600 013702 002326
 (7) 007604 006302
 1737 007606
 (6) 007606 032772 100000 002370
 (9) 007614 001416
 1738 007616
 (6) 007616 052762 100000 002524
 1739 007624
 (6) 007624 005262 003126
 1740 007630
 (4) 007630 013737 002326 002074
 1741 007636
 (4) 007636 104456
 (5) 007640 000001
 (5) 007642 003420
 (5) 007644 000000
 1742 007646
 (4) 007646 005072 002370
 1743 007652
 (4) 007652
 1744
 1745
 1746 007652
 (6) 007652 032772 000200 002370

```
.SBTTL INTERFACE LOGIC
BGNMOD
:++
:THIS TEST VERIFIES THE OPERATION OF THE INTERFACE LOGIC. TESTS ARE
:PERFORMED FOR PRINTER ERROR, PRINTER READY, AND CLEARING PRINTER READY
:BY LOADING A CHARACTER INTO THE OUTPUT BUFFER. ALSO IT IS VERIFIED
:THAT THE PRINTER WILL NOT INTERRUPT IF IT IS AT THE SAME PRIORITY LEVEL
:AS THE PROCESSOR, BUT WILL INTERRUPT IF THE PROCESSOR IS AT A LOWER
:PRIORITY LEVEL. THE PRINTER IS AT PRIORITY LEVEL 4.
:
:--
BGNTST 1
T1::
LET R1 := L$UNIT - #1 ;MAX NUMBER OF UNITS ON SYSTEM
      MOV L$UNIT,R1
      DEC R1
:
:HARD CODED INCREMNT LOOP
:INCR LUNIT FROM #0 TO R1 BY #1 ;START LOOP
:
      CLR LUNIT ;UNIT TO 0
      BR T1C ;DO COMPARE
T1A:
      INC LUNIT ;UPDATE UNIT NUMBER
T1C:
      CMP LUNIT,R1 ;DO COMPARISON OF UNIT NUMBER
      BLE T1$ ;ONTO NEXT UNIT
      JMP T1B ;EXIT LOOP
T1$:
      LET R2 := LUNIT SHIFT 1
      MOV LUNIT,R2
      ASL R2
      IF #BIT15 SETIN @LPCSR(R2) THEN
      BIT #BIT15,@LPCSR(R2)
      BEQ 50075$
      LET STATUS(R2) := STATUS(R2) SET.BY #ERROR
      BIS #ERROR,STATUS(R2)
      LET ERRTBL(R2) := ERRTBL(R2) + #1
      INC ERRTBL(R2)
      LET L$LUN := LUNIT
      MOV LUNIT,L$LUN
      ERRHRD 1,CSRERR ;ERROR BIT WAS SET. SAY SO
      TRAP C$ERHRD
      .WORD 1
      .WORD CSRERR
      .WORD 0
      LET @LPCSR(R2) := #0
      CLR @LPCSR(R2)
      ENDIF
50075$:
;TIME DELAY
; IF NOT READY ALLOW 3 SECONDS TO COME UP
IF #BIT7 NOTSETIN @LPCSR(R2) THEN
BIT #BIT7,@LPCSR(R2)
```

(9) 007660 001014
 1747 007662
 (2) 007662 012727 000036
 (2) 007666 000000
 (2) 007670 013727 002116
 (2) 007674 000000
 (2) 007676 005367 177772
 (2) 007702 001375
 (2) 007704 005367 177756
 (2) 007710 001367
 1748 007712
 (4) 007712
 1749
 1750
 1751
 1752 007712
 (6) 007712 032772 000200 002370
 (9) 007720 001014
 1753 007722
 (6) 007722 052762 100000 002524
 1754 007730
 (4) 007730 013737 002326 002074
 1755 007736
 (6) 007736 005262 003126
 1756 007742
 (4) 007742 104456
 (5) 007744 000002
 (5) 007746 003436
 (5) 007750 000000
 1757 007752
 (4) 007752
 1758
 1759
 1760
 1761 007752
 (4) 007752 012772 000012 002464
 1762 007760
 (6) 007760 032772 000200 002370
 (9) 007766 001416
 1763 007770
 (6) 007770 052762 100000 002524
 1764 007776
 (6) 007776 005262 003126
 1765 010002
 (4) 010002 013737 002326 002074
 1766 010010
 (4) 010010 104456
 (5) 010012 000003
 (5) 010014 010511
 (5) 010016 000000
 1767 010020
 (4) 010020 005072 002370
 1768 010024
 (4) 010024
 1769
 1770

```

BNE 50076$
      DELAY 30.
MOV  #30.,(PC)+
      .WORD 0
MOV  L$DLY,(PC)+
      .WORD 0
DEC  -6(PC)
BNE  -4
DEC  -22(PC)
BNE  -20
ENDIF

50076$:
:
: NOW TEST FOR PRINTER READY
:
      IF #BIT07 NOTSETIN @LPCSR(R2) THEN ;TEST FOR THE READY BIT
      BIT  #BIT07,@LPCSR(R2)
      BNE  50077$
      LET STATUS(R2) := STATUS(R2) SET.BY #ERROR
      BIS  #ERROR,STATUS(R2)
      LET L$LUN := LUNIT
      MOV  LUNIT,L$LUN
      LET ERRTBL(R2) := ERRTBL(R2) + #1
      INC  ERRTBL(R2)
      ERRHRD 2,RDYERR ;REPORT AN ERROR
      TRAP  C$ERHRD
      .WORD 2
      .WORD RDYERR
      .WORD 0
      ENDIF

50077$:
:
: INSURE LOADING CHARACTER CAUSES PRINTER READY TO GO AWAY
:
      LET @LPBUF(R2) := #12
      MOV  #12,@LPBUF(R2)
      IF #BIT07 SETIN @LPCSR(R2) THEN
      BIT  #BIT07,@LPCSR(R2)
      BEQ  50100$
      LET STATUS(R2) := STATUS(R2) SET.BY #ERROR
      BIS  #ERROR,STATUS(R2)
      LET ERRTBL(R2) := ERRTBL(R2) + #1
      INC  ERRTBL(R2)
      LET L$LUN := LUNIT
      MOV  LUNIT,L$LUN
      ERRHRD 3,ERR11 ;REPORT AN ERROR
      TRAP  C$ERHRD
      .WORD 3
      .WORD ERR11
      .WORD 0
      LET @LPCSR(R2) := #0
      CLR  @LPCSR(R2)
      ENDIF

50100$:
:
: VERIFY THAT THE PRINTER WILL NOT INTERRUPT IF IT IS AT A PRIORITY LEVEL

```

```

1771                                     ;THE SAME AS THE CPU
1772                                     ;
1773 010024                               SETPRI #PRI04                               ;CPU TO PRIORITY 4
(3) 010024 012700 000200                MOV #PRI04,R0
(3) 010030 104441                        TRAP C$SPRI
1774 010032                               SETVEC LPVEC(R2),#INTERR,#PRI04           ;LP VECTOR SET UP
(7) 010032 012746 000200                MOV #PRI04,-(SP)
(6) 010036 012746 010422                MOV #INTERR,-(SP)
(5) 010042 016246 002430                MOV LPVEC(R2),-(SP)
(4) 010046 012746 000003                MOV #3,-(SP)
(3) 010052 104437                        TRAP C$SVEC
(2) 010054 062706 000010                ADD #10,SP
1775 010060                               LET @LPCSR(R2) := @LPCSR(R2) SET.BY #100   ;INTERRUPT ENABLE
(6) 010060 052772 000100 002370        BIS #100,@LPCSR(R2)
1776 010066                               DELAY 30.                               ; ALLOW 3 SEC FOR DELAY
(2) 010066 012727 000036                MOV #30.,(PC)+
(2) 010072 000000                        .WORD 0
(2) 010074 013727 002116                MOV L$DLY,(PC)+
(2) 010100 000000                        .WORD 0
(2) 010102 005367 177772                DEC -6(PC)
(2) 010106 001375                        BNE -.4
(2) 010110 005367 177756                DEC -22(PC)
(2) 010114 001367                        BNE .-20
1777                                     ;
1778                                     ;NOW TEST THAT THE PRINTER WILL INTERRUPT IF THE CPU PRIORITY IS LOWER THAN
1779                                     ;THE PRINTER PRIORITY
1780                                     ;
1781 010116                               LET @LPCSR(R2) := @LPCSR(R2) CLR.BY #100   ;CLEAR INTERRUPT ENABLE
(6) 010116 042772 000100 002370        BIC #100,@LPCSR(R2)
1782 010124                               SETPRI #PRI03                               ;CPU TO PRIORITY 3
(3) 010124 012700 000140                MOV #PRI03,R0
(3) 010130 104441                        TRAP C$SPRI
1783 010132                               SETVEC LPVEC(R2),#INTHDL,#PRI04
(7) 010132 012746 000200                MOV #PRI04,-(SP)
(6) 010136 012746 010452                MOV #INTHDL,-(SP)
(5) 010142 016246 002430                MOV LPVEC(R2),-(SP)
(4) 010146 012746 000003                MOV #3,-(SP)
(3) 010152 104437                        TRAP C$SVEC
(2) 010154 062706 000010                ADD #10,SP
1784 010160                               LET @LPCSR(R2) := @LPCSR(R2) SET.BY #100   ;INTERRUPT ENABLE
(6) 010160 052772 000100 002370        BIS #100,@LPCSR(R2)
1785 010166                               DELAY 30.                               ; ALLOW 3 SEC DELAY
(2) 010166 012727 000030                MOV #30,(PC)+
(2) 010172 000000                        .WORD 0
(2) 010174 013727 002116                MOV L$DLY,(PC)+
(2) 010200 000000                        .WORD 0
(2) 010202 005367 177772                DEC -6(PC)
(2) 010206 001375                        BNE -.4
(2) 010210 005367 177756                DEC -22(PC)
(2) 010214 001367                        BNE .-20
1786 010216                               LET ERR_TBL(R2) := ERR_TBL(R2) + #1
(6) 010216 005262 003126                INC ERR_TBL(R2)
1787 010222                               LET L$LUN := LUNIT
(4) 010222 013737 002326 002074        MOV LUNIT,L$LUN
1788 010230                               ERRPRD 4,ERR13
(4) 010230 104456                        TRAP C$ERHRD
  
```

```

(5) 010232 000004          .WORD 4
(5) 010234 010650          .WORD ERR13
(5) 010236 000000          .WORD 0
1789 010240                END2: LET @LPCSR(R2) := #00          ; CLEAR THE LPCSR
(4) 010240 012772 000000 002370 MOV #00,@LPCSR(R2)
1790 010246                LET STATUS(R2) := STATUS(R2) CLR.BY #ERROR!DROPE!ACTIVE
(6) 010246 042762 160000 002524 BIC #ERROR!DROPE!ACTIVE,STATUS(R2)
1791 010254                LET DELCNT(R2) := #0
(4) 010254 005062 003064 CLR DELCNT(R2)
1792
1793                ;:END OF HARD CODED INCREMENT LOOP
1794                ;:ENDINC
1795
1796 010260 000137 007562          JMP T1A          ;UPDATE UNIT #
1797 010264 004737 007270          T1B: JSR PC,RESVEC ; RESET STANDARD VECTORS
1798 010270                SETPRI #PRI00
(3) 010270 012700 000000          MOV #PRI00,R0
(3) 010274 104441                TRAP C$SPRI
1799 010276                OUTPUT #INTFAC,#24.
1800 010340                DECR WORK FROM #12. TO #1 BY #1
(4) 010340 012737 000014 003166 MOV #12,WORK
(5) 010346 000402                BR 50101$
(4) 010350                50102$: DEC WORK
(7) 010350 005337 003166          50101$: CMP WORK,#1
(5) 010354                BLT 50103$
(5) 010354 023727 003166 000001 DELAY 250
(7) 010362 002415                MOV #250,(PC)+
1801 010364                .WORD 0
(2) 010364 012727 000250          MOV L$DLY,(PC)+
(2) 010370 000000                .WORD 0
(2) 010372 013727 002116          MOV -6(PC)
(2) 010376 000000                BNE -.4
(2) 010400 005367 177772          DEC -22(PC)
(2) 010404 001375                BNE -.20
(2) 010406 005367 177756          ENDDEC
(2) 010412 001367                BR 50102$
1802 010414                50103$: EXIT TST          ;EXIT THE TEST
(4) 010414 000755                TRAP C$EXIT
(3) 010416                .WORD L10006-.
1803 010416                ;: INTERRUPT HANDLER TO SERVICE FAULTY INTERRUPT FROM LP INTERFACE.
(3) 010416 104432                ;: THIS ROUTINE IS ENTERED ONLY WHEN THE LP INTERRUPTS AT THE SAME LEVEL AS
(3) 010420 000304                ;: THE CPU AND IS CONSIDERED AN ERROR.
1804
1805                ;:
1806                ;:
1807                ;:
1808                ;:
1809 010422                BGNSRV
1810 010422                INTERR: LET ERRTBL(R2) := ERRTBL(R2) + #1
(6) 010422 005262 003126          INC ERRTBL(R2)
1811 010426                LET L$LUN := LUNIT
(4) 010426 013737 002326 002074 MOV LUNIT,L$LUN
1812 010434                ERRHRD 5,ERR12
(4) 010434 104456                TRAP C$ERHRD
(5) 010436 000005                .WORD 5
(5) 010440 010565                .WORD ERR12
    
```

```

(5) 010442 000000          .WORD 0
1813 010444          LET (SP) := #END2
(4) 010444 012716 010240  MOV #END2,(SP)
1814 010450          ENDSRV
(3) 010450          L10007:
(2) 010450 000002          RTI
1815
1816          ; INTERRUPT HANDLER FOR EXPECTED INTERRUPT
1817          ;
1818 010452          BGNSRV
1819          ;
1820 010452          INTHDL: LET (SP) := #END2
(4) 010452 012716 010240  MOV #END2,(SP)
1821 010456          ENDSRV
(3) 010456          L10010:
(2) 010456 000002          RTI
1822
1823 010460 047111 042524 043122 INTFAC: .ASCIZ /INTERFACE LOGIC TEST 1/<12><12>
      010466 041501 020105 047514
      010474 044507 020103 042524
      010502 052123 030440 005012
      010510 000
1824
1825          ; ERROR MESSAGES ASSOCIATED WITH THIS TEST
1826          ;
1827          .NLIST BEX
1828 010511 114 040517 044504 ERR11: .ASCIZ /LOADING PRINTER BUFFER DOES NOT CLEAR READY/
1829 010565 120 044522 052116 ERR12: .ASCIZ /PRINTER INTERRUPTED AT SAME LEVEL AS THE PROCESSOR/
1830 010650 051120 047111 042524 ERR13: .ASCIZ /PRINTER DID NOT INTERRUPT AT CPU PRIORITY 3/
1831          .EVEN
1832 010724          ENDTST
(3) 010724          L10006:
(5) 010724 104401          TRAP C$ETST
1833          .LIST BEX
1834 010726          ENDMOD
1835
    
```

```

1837 .SBTTL READY LINE INTERLOCKS TEST 2
1838
1839 010726 BGNMOD
1840 :++
1841 :THIS TEST CHECKS THE OPERATION OF THE
1842 :PRINTER READY INTERLOCK SWITCHES.
1843 :MANUAL INTERVENTION IS USED TO
1844 :OPEN THE INTERLOCKS TO PRODUCE FAULTS
1845 :IN THE PRINTER AFTER WHICH THE RESULTANT ERROR
1846 :INDICATION IS VERIFIED.
1847 :--
1848
1849 010726 BGNTST 2
      (3) 010726 T2::
1850 :DETERMINE IF MANUAL INTERVENTION IS ALLOWED
1851 010726 MANUAL
      (3) 010726 104450 TRAP C$MANI
1852 010730 BCOMPLETE 11$
      (2) 010730 103402 BCS 11$
1853 010732 EXIT TST
      (3) 010732 104432 TRAP C$EXIT
      (3) 010734 002746 .WORD L10011-.
1854 :EXIT TEST IF MANUAL INTERVENTION TESTS ARE NOT SPECIFIED
1855 010736 11$: IF INHINT EQ #0 THEN
      (6) 010736 005737 002272 TST INHINT
      (9) 010742 001002 BNE 50104$
1856 010744 EXIT TST
      (3) 010744 104432 TRAP C$EXIT
      (3) 010746 002734 .WORD L10011-.
1857
1858 010750 ENDF
      (4) 010750 50104$:
1859 010750 LET FLAG := #0
      (4) 010750 005037 002306 CLR FLAG
1860 010754 LET R1 := L$UNIT - #1
      (4) 010754 013701 002012 MOV L$UNIT,R1
      (6) 010760 005301 DEC R1
1861
1862 :CHECK FOR ERROR IN EACH PRINTER UNDER TEST
1863 010762 INCR LUNIT FROM #0 TO R1 BY #1
      (4) 010762 005037 002326 CLR LUNIT
      (5) 010766 000402 BR 50105$
1864 010770 50106$: INC LUNIT
      (7) 010770 005237 002326 50105$:
      (5) 010774 CMP LUNIT,R1
      (5) 010774 023701 002326 BGT 50107$
      (7) 011000 003020 LET R2 := LUNIT SHIFT 1
1864 011002 MOV LUNIT,R2
      (4) 011002 013702 002326 ASL R2
      (7) 011006 006302 IF #BIT15 SET IN @LPCSR(R2) THEN
1865 011010 BIT #BIT15,@LPCSR(R2)
      (6) 011010 032772 100000 002370 BEQ 50110$
      (9) 011016 001410 LET ERRTBL(R2) := ERRTBL(R2) + #1
1866 011020 INC ERRTBL(R2)
      (6) 011020 005262 003126 ERRHRD 6, CSRERR
1867 011024
  
```


(4)	011024	104456			TRAP	C\$ERHRD
(5)	011026	000006			.WORD	6
(5)	011030	003420			.WORD	CSRERR
(5)	011032	000000			.WORD	0
1868	011034					LET @LPCSR(R2) := #0
(4)	011034	005072	002370		CLR	@LPCSR(R2)
1869	011040				ENDIF	
(4)	011040			50110\$:		
1870	011040				ENDINC	
(4)	011040	000753			BR	50106\$
(3)	011042			50107\$:		
1871					;CHECK FOR READY IN EACH PRINTER UNDER TEST	
1872	011042				INCR LUNIT FROM #0 TO R1 BY #1	
(4)	011042	005037	002326		CLR	LUNIT
(5)	011046	000402			BR	50111\$
(4)	011050			50112\$:		
(7)	011050	005237	002326		INC	LUNIT
(5)	011054			50111\$:		
(5)	011054	023701	002326		CMP	LUNIT,R1
(7)	011060	003021			BGT	50113\$
1873	011062				LET R2 := LUNIT SHIFT 1	
(4)	011062	013702	002326		MOV	LUNIT,R2
(7)	011066	006302			ASL	R2
1874	011070				LET L\$LUN := LUNIT	
(4)	011070	013737	002326	002074	MOV	LUNIT,L\$LUN
1875	011076				IF #BIT07 NOTSETIN @LPCSR(R2) THEN	
(6)	011076	032772	000200	002370	BIT	#BIT07,@LPCSR(R2)
(9)	011104	001006			BNE	50114\$
1876	011106				LET ERRTBL(R2) := ERRTBL(R2) + #1	
(6)	011106	005262	003126		INC	ERRTBL(R2)
1877	011112				ERRHRD 7, RDYERR	
(4)	011112	104456			TRAP	C\$ERHRD
(5)	011114	000007			.WORD	7
(5)	011116	003436			.WORD	RDYERR
(5)	011120	000000			.WORD	0
1878	011122				ENDIF	
(4)	011122			50114\$:		
1879	011122				ENDINC	
(4)	011122	000752			BR	50112\$
(3)	011124			50113\$:		
1880					; PRINT TEST NAME	
1881					; OUTPUT #INTLK,#29.	
1882					;VERIFY OPERATION OF PAPER LOW INTERLOCK SWITCH	
1883	011124				;HARD CODED INCREMENT LOOP	
1884					; :	
1885					LET ERRFLG := #0	
1886					CLR	ERRFLG
1887	011166				; :	
(4)	011166	005037	002352		CLR	LUNIT
1888	011172	005037	002326		BR	1\$
1889	011176	000405		2\$:		
1890	011200				INC	LUNIT
1891	011200	005237	002326		LET R2 := LUNIT SHIFT 1	
1892	011204				MOV	LUNIT,R2
(4)	011204	013702	002326		ASL	R2
(7)	011210	006302				

1893	011212			1\$:	
1894	011212	023701	002326		CMP LUNIT,R1
1895	011216	003402			BLE 3\$
1896	011220	000137	011560		JMP 4\$
1897	011224			3\$:	
1898	011224				LET FLAG := #0
(4)	011224	005037	002306		CLR FLAG
1899	011230				PRINTF #PAPRSW,LUNIT
(8)	011230	013746	002326		MOV LUNIT,-(SP)
(7)	011234	012746	012256		MOV #PAPRSW,-(SP)
(6)	011240	012746	000002		MOV #2,-(SP)
(3)	011244	010600			MOV SP,R0
(4)	011246	104417			TRAP C\$PNTF
(4)	011250	062706	000006		ADD #6,SP
1900	011254				PRINTF #PAPSW1
(7)	011254	012746	012326		MOV #PAPSW1,-(SP)
(6)	011260	012746	000001		MOV #1,-(SP)
(3)	011264	010600			MOV SP,R0
(4)	011266	104417			TRAP C\$PNTF
(4)	011270	062706	000004		ADD #4,SP
1901	011274				GMANIL READY, FLAG, 100000, YES
(3)	011274	104443			TRAP C\$GMAN
(3)	011276	000404			BR 10000\$
(4)	011300	002306			.WORD FLAG
(5)	011302	000130			.WORD T\$CODE
(5)	011304	007072			.WORD READY
(5)	011306	100000			.WORD 100000
(3)	011310			10000\$:	
1902	011310				LET LINCNT := #400. ; ALLOW FOR ABOUT 6 PAGES OF PAPER
(4)	011310	012737	000620 002310		MOV #400.,LINCNT
1903	011316				LET ERRFLG := #0
(4)	011316	005037	002352		CLR ERRFLG
1904	011322				REPEAT
(3)	011322			50115\$:	
1905	011322				OUTPUT #PAPTST,#25.,#5\$,LUNIT
1906	011364				LET LINCNT := LINCNT - #1
(6)	011364	005337	002310		DEC LINCNT
1907	011370				UNTIL LINCNT EQ #0 OR ERRFLG NE #0
(4)	011370	005737	002310		TST LINCNT
(6)	011374	001403			BEQ 50116\$
(4)	011376	005737	002352		TST ERRFLG
(7)	011402	001747			BEQ 50115\$
(4)	011404			50116\$:	
1908	011404				IF ERRFLG EQ #0 THEN
(6)	011404	005737	002352		TST ERRFLG
(9)	011410	001011			BNE 50117\$
1909	011412				ERRHRD 8,PAPSWI
(4)	011412	104456			TRAP C\$ERHRD
(5)	011414	000010			.WORD 8
(5)	011416	003460			.WORD PAPSWI
(5)	011420	000000			.WORD 0
1910	011422				LET ERRTBL(R2) := ERRTBL(R2) + #1
(6)	011422	005262	003126		INC ERRTBL(R2)
1911	011426				INLINE <JMP 11002\$>
(2)	011426	000137	011440		JMP 11002\$
1912	011432				ELSE

(4) 011432 000402
 (3) 011434
 1913 011434
 (4) 011434 005037 002352
 1914 011440
 (4) 011440
 1915 011440
 (8) 011440 013746 002326
 (7) 011444 012746 012404
 (6) 011450 012746 000002
 (3) 011454 010600
 (4) 011456 104417
 (4) 011460 062706 000006
 1916 011464
 (4) 011464 005037 002306
 1917 011470
 (3) 011470 104443
 (3) 011472 000404
 (4) 011474 002306
 (5) 011476 000130
 (5) 011500 007072
 (5) 011502 100000
 (3) 011504
 1918 011504
 (4) 011504 013702 002326
 (7) 011510 006302
 1919 011512
 (4) 011512 005072 002370
 1920 011516 000137 011200
 1921
 1922
 1923
 1924 011522
 (4) 011522 012737 000001 002352
 1925 011530
 (4) 011530 005037 002350
 1926 011534
 (6) 011534 042762 120000 002524
 1927 011542
 (4) 011542 005062 002764
 1928 011546
 (4) 011546 005062 002564
 1929 011552
 (4) 011552 005062 002664
 1930 011556 000207
 1931
 1932 011560
 (4) 011560 005037 002326
 (5) 011564 000402
 (4) 011566
 (7) 011566 005237 002326
 (5) 011572
 (5) 011572 023701 002326
 (7) 011576 003077
 1933 011600
 (4) 011600 013702 002326

```

50117$: BR 50120$
        LET ERRFLG := #0
        CLR ERRFLG
        ENDIF
50120$: PRINTF #PAPRDY,LUNIT
11002$: MOV LUNIT,-(SP)
        MOV #PAPRDY,-(SP)
        MOV #2,-(SP)
        MOV SP,R0
        TRAP C$PNTF
        ADD #6,SP
        LET FLAG := #0
        CLR FLAG
        GMANIL READY,FLAG,100000,YES
        TRAP C$GMAN
        BR 10001$
        .WORD FLAG
        .WORD T$CODE
        .WORD READY
        .WORD 100000
10001$: LET R2 := LUNIT SHIFT 1
        MOV LUNIT,R2
        ASL R2
        LET @LPCSR(R2) := #0 ; RESET THE LP CSR
        CLR @LPCSR(R2)
        JMP 2$
;EXPECTED ERROR HANDLER.
;JUST SET EXPECTED ERROR INDICATOR.
5$: LET ERRFLG := #1
   MOV #1,ERRFLG
   LET ERRCOD := #0
   CLR ERRCOD
   LET STATUS(R2) := STATUS(R2) CLR.BY #ERROR!ACTIVE
   BIC #ERROR!ACTIVE,STATUS(R2)
   LET CURCNT(R2) := #0 ; CLEAN UP THE DRIVER PARAMETERS
   CLR CURCNT(R2)
   LET CURADD(R2) := #0
   CLR CURADD(R2)
   LET REPCNT(R2) := #0
   CLR REPCNT(R2)
   RTS PC ;AND RETURN
;VERIFY OPERATION OF HAMMER BANK INTERLOCK SWITCH
4$: INCR LUNIT FROM #0 TO R1 BY #1
   CLR LUNIT
   BR 50121$
50122$: INC LUNIT
50121$: CMP LUNIT,R1
   BGT 50123$
   LET R2 := LUNIT SHIFT 1
   MOV LUNIT,R2
  
```

(7)	011604	006302			ASL R2
1934	011606				LET L\$LUN := LUNIT
(4)	011606	013737	002326	002074	MOV LUNIT,L\$LUN
1935	011614				LET FLAG := #0
(4)	011614	005037	002306		CLR FLAG
1936	011620				PRINTF #HAMRSW,LUNIT
(8)	011620	013746	002326		MOV LUNIT,-(SP)
(7)	011624	012746	013147		MOV #HAMRSW,-(SP)
(6)	011630	012746	000002		MOV #2,-(SP)
(3)	011634	010600			MOV SP,R0
(4)	011636	104417			TRAP C\$PNTF
(4)	011640	062706	000006		ADD #6,SP
1937	011644				PRINTF #HAMSW1
(7)	011644	012746	013233		MOV #HAMSW1,-(SP)
(6)	011650	012746	000001		MOV #1,-(SP)
(3)	011654	010600			MOV SP,R0
(4)	011656	104417			TRAP C\$PNTF
(4)	011660	062706	000004		ADD #4,SP
1938	011664				GMANIL READY, FLAG, 100000, YES
(3)	011664	104443			TRAP C\$GMAN
(3)	011666	000404			BR 10002\$
(4)	011670	002306			.WORD FLAG
(5)	011672	000130			.WORD T\$CODE
(5)	011674	007072			.WORD READY
(5)	011676	100000			.WORD 100000
(3)	011700				10002\$:
1939	011700				IF #BIT15 SETIN @LPCSR(R2) THEN
(6)	011700	032772	100000	002370	BIT #BIT15,@LPCSR(R2)
(9)	011706	001421			BEQ 50124\$
1940	011710				PRINTF #HAMRDY,LUNIT
(8)	011710	013746	002326		MOV LUNIT,-(SP)
(7)	011714	012746	013310		MOV #HAMRDY,-(SP)
(6)	011720	012746	000002		MOV #2,-(SP)
(3)	011724	010600			MOV SP,R0
(4)	011726	104417			TRAP C\$PNTF
(4)	011730	062706	000006		ADD #6,SP
1941	011734				GMANIL READY, FLAG, 100000, YES
(3)	011734	104443			TRAP C\$GMAN
(3)	011736	000404			BR 10003\$
(4)	011740	002306			.WORD FLAG
(5)	011742	000130			.WORD T\$CODE
(5)	011744	007072			.WORD READY
(5)	011746	100000			.WORD 100000
(3)	011750				10003\$:
1942	011750				ELSE
(4)	011750	000411			BR 50125\$
(3)	011752				50124\$:
1943	011752				LET ERRTBL(R2) := ERRTBL(R2) + #1
(6)	011752	005262	003126		INC ERRTBL(R2)
1944	011756				LET L\$LUN := LUNIT
(4)	011756	013737	002326	002074	MOV LUNIT,L\$LUN
1945					
1946	011764				ERRHRD 9, BNKSWI
(4)	011764	104456			TRAP C\$ERHRD
(5)	011766	000011			.WORD 9
(5)	011770	003523			.WORD BNKSWI

(5) 011772 000000
 1947 011774
 (4) 011774
 1948 011774
 (4) 011774 000674
 (3) 011776
 1949
 1950 011776
 (4) 011776 005037 002326
 (5) 012002 000402
 (4) 012004
 (7) 012004 005237 002326
 (5) 012010
 (5) 012010 023701 002326
 (7) 012014 003077
 1951 012016
 (4) 012016 013702 002326
 (7) 012022 006302
 1952 012024
 (4) 012024 005037 002306
 1953 012030
 (8) 012030 013746 002326
 (7) 012034 012746 013425
 (6) 012040 012746 000002
 (3) 012044 010600
 (4) 012046 104417
 (4) 012050 062706 000006
 1954 012054
 (7) 012054 012746 013513
 (6) 012060 012746 000001
 (3) 012064 010600
 (4) 012066 104417
 (4) 012070 062706 000004
 1955 012074
 (3) 012074 104443
 (3) 012076 000404
 (4) 012100 002306
 (5) 012102 000130
 (5) 012104 007072
 (5) 012106 100000
 (3) 012110
 1956 012110
 (6) 012110 032772 100000 002370
 (9) 012116 001421
 1957 012120
 (8) 012120 013746 002326
 (7) 012124 012746 013562
 (6) 012130 012746 000002
 (3) 012134 010600
 (4) 012136 104417
 (4) 012140 062706 000006
 1958 012144
 (3) 012144 104443
 (3) 012146 000404
 (4) 012150 002306
 (5) 012152 000130

```

        .WORD 0
        ENDIF
50125$:
        ENDINC
        BR 50122$
50123$:
;VERIFY OPERATION OF CHARACTER BAND INTERLOCK SWITCH
        INCR LUNIT FROM #0 TO R1 BY #1
        CLR LUNIT
        BR 50126$
50127$:
        INC LUNIT
50126$:
        CMP LUNIT,R1
        BGT 50130$
        LET R2 := LUNIT SHIFT 1
        MOV LUNIT,R2
        ASL R2
        LET FLAG := #0
        CLR FLAG
        PRINTF #BANDSW,LUNIT
        MOV LUNIT,-(SP)
        MOV #BANDSW,-(SP)
        MOV #2,-(SP)
        MOV SP,R0
        TRAP C$PNTF
        ADD #6,SP
        PRINTF #BNDW1
        MOV #BNDW1,-(SP)
        MOV #1,-(SP)
        MOV SP,R0
        TRAP C$PNTF
        ADD #4,SP
        GMANIL READY, FLAG, 100000, YES
        TRAP C$GMAN
        BR 10004$
        .WORD FLAG
        .WORD T$CODE
        .WORD READY
        .WORD 100000
10004$:
        IF #BIT15 SET IN @LPCSR(R2) THEN
        BIT #BIT15,@LPCSR(R2)
        BEQ 50131$
        PRINTF #BNDRDY,LUNIT
        MOV LUNIT,-(SP)
        MOV #BNDRDY,-(SP)
        MOV #2,-(SP)
        MOV SP,R0
        TRAP C$PNTF
        ADD #6,SP
        GMANIL READY, FLAG, 100000, YES
        TRAP C$GMAN
        BR 10005$
        .WORD FLAG
        .WORD T$CODE
  
```

```

(5) 012154 007072 .WORD READY
(5) 012156 100000 .WORD 100000
(3) 012160 10005$:
1959 012160 ELSE
(4) 012160 000411 BR 50132$
(3) 012162 50131$:
1960 012162 LET ERRTBL(R2) := ERRTBL(R2) + #1
(6) 012162 005262 003126 INC ERRTBL(R2)
1961 012166 LET L$LUN := LUNIT
(4) 012166 013737 002326 002074 MOV LUNIT,L$LUN
1962 012174 ERRHRD 10, BNDSWI
(4) 012174 104456 TRAP C$ERHRD
(5) 012176 000012 .WORD 10
(5) 012200 003570 .WORD BNDSWI
(5) 012202 000000 .WORD 0
1963 012204 ENDIF
(4) 012204 50132$:
1964 012204 LET @LPCSR(R2) := #00
(4) 012204 012772 000000 002370 MOV #00,@LPCSR(R2)
1965 012212 ENDINC
(4) 012212 000674 BR 50127$
(3) 012214 50130$:
1966 012214 EXIT TST
(3) 012214 104432 TRAP C$EXIT
(3) 012216 001464 .WORD L10011-.

1967
1968 .NLIST BEX
1969
1970 012220 042522 042101 020131 INTLK: .ASCIZ /READY LINE INTERLOCK TEST 2/<12><12>
1971 012256 047045 040445 042524 PAPRSW: .ASCIZ /%N%ATEAR OFF PAPER JUST BELOW LUNIT %D2/
1972 012326 040445 052040 020117 PAPSW1: .ASCIZ /%A TO CHECK PAPER LOW %N%INTERLOCK SWITCH.%N/
1973 012404 047045 040445 042522 PAPRDY: .ASCIZ /%N%ARESTORE PAPER, ALARM CLEAR, AND PLACE LUNIT %D2%A ON LINE.%N/
1974 012506 040520 042520 020122 PAPTST: .ASCIZ /PAPER LOW INTERLOCK TEST/<12>
1975 012540 054130 054130 054130 PAPOUT: .ASCIZ /XXXXXXXXXXXXXXXXXXXXXXXXXXXX/<12>
1976 012572 047045 040445 051120 PRINT4: .ASCII /%N%APRESS ON-LINE SW OF UNIT %D2%A 4 TIMES /
1977 012645 054 030440 046040 .ASCIZ /, 1 LINE SHOULD BE PRINTED AFTER EACH PRESS%N/
1978 012723 045 022516 050101 DOTOF: .ASCIZ /%N%APRESS ON-LINE SW OF UNIT %D2%A FORM FEED SHOULD OCCUR%N/
1979 013017 045 022516 052101 LN3EX: .ASCII /%N%ATHE LAST 3 LINES PRINTED SHOULD BE X'S%N/
1980 013073 045 050101 042522 .ASCIZ /%APRESSING ON-LINE AGAIN SHOULD NOT PRINT%N/
1981 013147 045 022516 042101 HAMRSW: .ASCIZ /%N%ADISENGAGE HAMMER BANK LATCH SWITCH ON LUNIT %D2/
1982 013233 045 022516 052101 HAMSW1: .ASCIZ /%N%ATO CHECK HAMMER BANK INTERLOCK SWITCH.%N/
1983 013310 047045 040445 047105 HAMRDY: .ASCIZ /%N%AENGAGE HAMMER BANK LATCH, ALARM CLEAR, AND PLACE LUNIT %D2%A ON LI
1984 013425 045 022516 047501 BANDSW: .ASCIZ /%N%AOPEN CHARACTER BAND COVER ON LUNIT %D2%A TO CHECK/
1985 013513 045 022516 041501 BNDSW1: .ASCIZ /%N%ACHARACTER BAND INTERLOCK SWITCH.%N/
1986 013562 047045 040445 046103 BNRDY: .ASCIZ/%N%ACLOSE CHARACTER BAND COVER ON LUNIT %D2%A, ALARM CLEAR, AND PLACE ON
1987 .EVEN
1988
1989 .LIST BEX
1990 013702 ENDTST
(3) 013702 L10011:
(3) 013702 104401 TRAP C$ETST
1991
1992 013704 ENDMOD
1993

```

1995
 1996 013704
 1997
 1998
 1999
 2000
 2001
 2002
 2003
 2004
 2005
 2006 013704
 (3) 013704
 2007
 2008 013704
 (3) 013704 104450
 2009 013706
 (2) 013706 103402
 2010 013710
 (3) 013710 104432
 (3) 013712 002246
 2011
 2012 013714 005737 002272
 2013 013720 001002
 2014 013722
 (3) 013722 104432
 (3) 013724 002234
 2015
 2016 013726
 2017
 2018
 2019
 2020 013770 005037 002326
 2021 013774 000402
 2022 013776 005237 002326
 2023 014002 023701 002326
 2024 014006 003402
 2025 014010 000137 014566
 2026 014014
 2027 014014
 (4) 014014 013702 002326
 (7) 014020 006302
 2028 014022
 (8) 014022 013746 002326
 (7) 014026 012746 014637
 (6) 014032 012746 000002
 (3) 014036 010600
 (4) 014040 104417
 (4) 014042 062706 000006
 2029 014046
 (7) 014046 012746 014723
 (6) 014052 012746 000001
 (3) 014056 010600
 (4) 014060 104417
 (4) 014062 062706 000004
 2030 014066

```

.SBTTL FORMS LENGTH SELECTION
BGNMOD
:++
;THIS TEST CHECKS ALL POSITIONS OF THE FORM LENGTH SELECT SWITCH. THE
;PROGRAM INDICATES THE SPECIFIED SETTING OF THE FORM LENGTH SELECT SWITCH
;AND WAITS FOR THE OPERATOR TO SET THE SWITCH ON THE PRINTER. THE PAPER
;IS THEN ADVANCED UNDER PROGRAM CONTROL. THE PRINTER OUTPUT IS VISUALLY
;INSPECTED AFTER ALL SWITCH SETTINGS HAVE BEEN RUN THROUGH BY THE OPERATOR
;TO VERIFY THAT THE PROPER PAPER MOVEMENT HAS OCCURRED FOR EACH SWITCH
;SETTING.
:--
BGNTST 3
T3:
;DETERMINE IF MANUAL INTERVENTION IS ALLOWED
    MANUAL
    TRAP C$MANI
    BCOMPLETE 1$
    BCS 1$
    EXIT TST
    TRAP C$EXIT
    .WORD L10012-
;EXIT TEST IF MANUAL INTERVENTION TESTS ARE NOT SPECIFIED
1$: TST INHINT
    BNE 2$
    EXIT TST
    TRAP C$EXIT
    .WORD L10012-
;PRINT TEST IDENTIFICATION
2$: OUTPUT #FRMLTH,#32.
;
;HARD CODE INCREMENT LOOP
;
    CLR LUNIT
    BR 4$ ;COMPARE LOOP
5$: INC LUNIT
4$: CMP LUNIT,R1
    BLE 6$ ;EXIT ONLY IF GREATER THAN
    JMP 7$ ;EXIT
6$: LET R2 := LUNIT SHIFT 1
    MOV LUNIT,R2
    ASL R2
    PRINTF #LINSWI,LUNIT ;PRINT LUNIT MESSAGE
    MOV LUNIT,-(SP)
    MOV #LINSWI,-(SP)
    MOV #2,-(SP)
    MOV SP,R0
    TRAP C$PNTF
    ADD #6,SP
    PRINTF #LINSW1 ;SECOND PART OF MESSAGE
    MOV #LINSW1,-(SP)
    MOV #1,-(SP)
    MOV SP,R0
    TRAP C$PNTF
    ADD #4,SP
    PRINTF #FLSSEL,LUNIT ;SET TO "FLS" POSITION
    
```

(8)	014066	013746	002326		MOV	LUNIT,-(SP)	
(7)	014072	012746	015003		MOV	#FLSSEL,-(SP)	
(6)	014076	012746	000002		MOV	#2,-(SP)	
(3)	014102	010600			MOV	SP,R0	
(4)	014104	104417			TRAP	C\$PNTF	
(4)	014106	062706	000006		ADD	#6,SP	
2031	014112				INCR	R4 FROM #0 TO #20. BY #2	
(4)	014112	005004			CLR	R4	
(5)	014114	000402			BR	50133\$	
(4)	014116			50134\$:			
(7)	014116	062704	000002		ADD	#2,R4	
(5)	014122			50133\$:			
(5)	014122	020427	000024		CMP	R4,#20.	
(7)	014126	003137			BGT	50135\$	
2032	014130				LET	R3 := R4	:INDEX INTO SWITCH SETTING TABLE
(4)	014130	010403			MOV	R4,R3	
2033	014132	006303			ASL	R3	:ACTUAL OFFSET FOR SWITCH SETTINGS
2034	014134				LET	T3SET := #FFSET + R3	
(4)	014134	012737	015474	014572	MOV	#FFSET,T3SET	
(6)	014142	060337	014572		ADD	R3,T3SET	
2035	014146				PRINTF	#FLSMMSG,LUNIT,T3SET	:SELECT MESSAGE
(9)	014146	013746	014572		MOV	T3SET,-(SP)	
(8)	014152	013746	002326		MOV	LUNIT,-(SP)	
(7)	014156	012746	015550		MOV	#FLSMMSG,-(SP)	
(6)	014162	012746	000003		MOV	#3,-(SP)	
(3)	014166	010600			MOV	SP,R0	
(4)	014170	104417			TRAP	C\$PNTF	
(4)	014172	062706	000010		ADD	#10,SP	
2036	014176				PRINTF	#FLSMS1	
(7)	014176	012746	015642		MOV	#FLSMS1,-(SP)	
(6)	014202	012746	000001		MOV	#1,-(SP)	
(3)	014206	010600			MOV	SP,R0	
(4)	014210	104417			TRAP	C\$PNTF	
(4)	014212	062706	000004		ADD	#4,SP	
2037	014216				LET	FLAG := #0	:CLEAR FLAG INDICATOR FOR MANUAL
(4)	014216	005037	002306		CLR	FLAG	
2038	014222				GMANIL	READY,FLAG,100000,YES	:WAIT FOR OPERATOR
(3)	014222	104443			TRAP	C\$GMAN	
(3)	014224	000404			BR	10000\$	
(4)	014226	002306			.WORD	FLAG	
(5)	014230	000130			.WORD	T\$CODE	
(5)	014232	007072			.WORD	READY	
(5)	014234	100000			.WORD	100000	
(3)	014236			10000\$:			
2039	014236				OUTPUT	#REFLIN,#133,,LUNIT	:OUTPUT REFERENCE LINE AND TERMINATOR
2040	014300				OUTPUT	T3SET,#3,,LUNIT	:# OF LINES FOR SPACING
2041	014342				OUTPUT	#MOVMSG,#130,,LUNIT	:FINAL REFERENCE LINE
2042	014404				LET	FLAG := #0	
(4)	014404	005037	002306		CLR	FLAG	
2043	014410				GMANIL	READY,FLAG,100000,YES	
(3)	014410	104443			TRAP	C\$GMAN	
(3)	014412	000404			BR	10001\$	
(4)	014414	002306			.WORD	FLAG	
(5)	014416	000130			.WORD	T\$CODE	
(5)	014420	007072			.WORD	READY	
(5)	014422	100000			.WORD	100000	


```

(3) 014424
2044 014424
(4) 014424 000634
(3) 014426
2045
2046 014426
(8) 014426 013746 002326
(7) 014432 012746 015402
(6) 014436 012746 000002
(3) 014442 010600
(4) 014444 104417
(4) 014446 062706 000006
2047 014452
(4) 014452 012737 000014 003172
2048 014460
(4) 014460 005037 002306
2049 014464
(3) 014464 104443
(3) 014466 000404
(4) 014470 002306
(5) 014472 000130
(5) 014474 007072
(5) 014476 100000
(3) 014500
2050 014500
2051 014542
(7) 014542 012746 015102
(6) 014546 012746 000001
(3) 014552 010600
(4) 014554 104417
(4) 014556 062706 000004
2052 014562 000137 013776
2053 014566
2054 014566
(3) 014566 104432
(3) 014570 001370
2055 014572 000000
2056 014574 000000
2057
2058 014576 047506 046522 020123
2059 014637 045 022516 051501
2060 014723 045 022516 033101
2061 015003 045 031116 040445
2062 015102 047045 040445 042526
2063 015174 042522 042506 042522
2064 015271 056 027056 027056
2065 015366 027056 027056 027056
2066 015402 047045 040445 042523
2067
2068 015474 020063 000040
2069 015500 027063 000065
2070 015504 020064 000040
2071 015510 027065 000065
2072 015514 020066 000040
2073 015520 020067 000040
2074 015524 020070 000040
  
```

```

10001$:
  ENDINC
  BR 50134$
50135$:
;SET FORMS LENGTH SELECT SWITCH TO ITS "REGULAR" SETTING
  PRINTF #NMLFLS,LUNIT
  MOV LUNIT,-(SP)
  MOV #NMLFLS,-(SP)
  MOV #2,-(SP)
  MOV SP,R0
  TRAP C$PNTF
  ADD #6,SP
  LET OUTBUF := #14
  MOV #14,OUTBUF
  LET FLAG := #0 ;CLEAR <CR> FLAG
  CLR FLAG ;AND WAIT FOR RESPONSE
  GMANIL READY,FLAG,100000,YES
  TRAP C$GMAN
  BR 10002$
  .WORD FLAG
  .WORD T$CODE
  .WORD READY
  .WORD 100000
10002$:
  OUTPUTI #OUTBUF,#1,,LUNIT
  PRINTF #PAPCHK ;MAKE SURE MOVEMENT WAS RIGHT
  MOV #PAPCHK,-(SP)
  MOV #1,-(SP)
  MOV SP,R0
  TRAP C$PNTF
  ADD #4,SP
  JMP 5$ ;END OF HARDCODED INCREMENT LOOP
7$:
EXIT TST
  TRAP C$EXIT
  .WORD L10012-.
T3SET: .WORD 0
T3MOV: .WORD 0
.NLIST BEX
FRMLTH: .ASCIZ /FORMS LENGTH SELECTION TEST 3/<12><12><12>
LINSWI: .ASCIZ /%N%ASET LINES SWITCH ON UNIT %D2%A TO "6" TO SELECT/
LINSW1: .ASCIZ /%N%A6 LINES PER INCH VERTICAL PRINTING DENSITY./
FLSSEL: .ASCIZ /%N2%ASET VFU-FLS SWITCH ON UNIT %D2%A TO THE "FLS" POSITION.%N/
PAPCHK: .ASCIZ /%N%AVERIFY PROPER PAPER MOVEMENT FOR EACH SWITCH SETTING./
REFLIN: .ASCIZ /REFERENCE LINE FOR FORMS LENGTH SELECTION...../
REFLI1: .ASCIZ /...../
REFLI2: .ASCIZ /...../<14>
NMLFLS: .ASCIZ /%N%ASET FORMS LENGTH SELECT SWITCH ON UNIT %D2%A TO 11.%N/
;SWITCH SETTINGS FOR FORMS LENGTH MESSAGES
FFSET: .ASCIZ /3 /
      .ASCIZ /3.5/
      .ASCIZ /4 /
      .ASCIZ /5.5/
      .ASCIZ /6 /
      .ASCIZ /7 /
      .ASCIZ /8 /
  
```

2075	015530	027070	000065			.ASCIZ /8.5/
2076	015534	030461	000040			.ASCIZ /11 /
2077	015540	031061	000040			.ASCIZ /12 /
2078	015544	032061	000040			.ASCIZ /14 /
2079	015550	047045	040445	042523	FLMSG:	.ASCIZ /%N%ASET FORMS LENGTH SELECT SWITCH ON UNIT %D2%A TO %T%A, /
2080	015642	047045	040445	042504	FLSMS1:	.ASCIZ /%N%ADEPRESS "ALARM CLEAR", TOP OF FORM, AND PLACE PRINTER BACK ON LINE.%
2081	015754	044440	041516	042510	MOVMSG:	.ASCII / INCHES SHOULD OCCUR BETWEEN THIS AND THE REFERENCE LINE...../
2082	016051	056	027056	027056	MOVMS1:	.ASCII /...../
2083	016147	056	027056	027056	MOVMS2:	.ASCIZ /...../<12>
2084		016160				.EVEN
2085						.LIST BEX
2086	016160					ENDTST
(3)	016160					L10012:
(3)	016160	104401				TRAP C\$ETST
2087	016162					ENDMOD
2088						

2090
2091 016162
2092
2093
2094
2095
2096
2097
2098
2099
2100
2101 016162
(3) 016162
2102
2103 016162
(4) 016162 013701 002012
(6) 016166 005301
2104 016170
(6) 016170 005737 002276
(9) 016174 001416
2105 016176
(3) 016176 104450
2106 016200
(2) 016200 103402
2107 016202
(3) 016202 104432
(3) 016204 004122
2108 016206
(6) 016206 005737 002272
(9) 016212 001403
2109 016214
(3) 016214 104432
(5) 016216 004110
2110 016220
(4) 016220 000403
(3) 016222
2111 016222
(4) 016222 013737 002300 003166
2112 016230
(4) 016230
2113 016230
(4) 016230 000403
(3) 016232
2114 016232
(4) 016232 013737 002300 003166
2115 016240
(4) 016240
2116 016240
2117 016302
(2) 016302 013746 002334
(4) 016306 003403
(3) 016310 021627 000004
(6) 016314 003402
(3) 016316
(3) 016316 012716 000005
(3) 016322

```
.SBTTL PRINTING SPEED MEASUREMENT
BGNMOD
:++
: THE PRINT SPEED TEST WILL REPORT TO THE OPERATOR THE TOTAL NUMBER OF
: LINES PRINTED WITHIN A SPECIFIED TIME PERIOD. THE DATA PATTERN USED
: IS DESIGNED TO CAUSE PRINTING SPEED TO BE MINIMAL AND IS DEPENDENT
: ON PRINTER TYPE AND THE CHARACTER SET (BAND TYPE ) ON EACH PRINTER.
: THE TIME PERIOD CAN BE CONTROLLED THRU MANUAL OPERATION, OR IF THE
: SYSTEM HAS A CLOCK VIA SUPPLYING A COUNT OF SECONDS. ANY TIME INTERVAL OF
: 4 TO 60 SECONDS MAY BE SELECTED. THIS IS ONE OF THE "SW" QUESTIONS .
:--
BGNTST 4
T4::
:
LET R1 := L$UNIT - #1 ;NUMBER OF UNITS TO TEST
MOV L$UNIT,R1
DEC R1
IF MANS PD NE #0 THEN ; DETERMIN IF MANUAL TESTING SELECTED
TST MANS PD
BEQ 50136$
MANUAL ;DETERMINE IF MANUAL INTERVENTION ALLOWED
TRAP C$MANI
BCOMplete 1$
BCS 1$
EXIT TST
TRAP C$EXIT
.WORD L10013-.
1$: IF INHINT NE #0 THEN ; EXIT IF INTERVENTION INHIBITED
TST INHINT
BEQ 50137$
EXIT TST
TRAP C$EXIT
.WORD L10013-.
ELSE
BR 50140$
50137$:
LET WORK := PERIOD
MOV PERIOD,WORK
ENDIF
50140$:
ELSE
BR 50141$
50136$:
LET WORK := PERIOD ; CLOCK TEST TIME
MOV PERIOD,WORK
ENDIF
50141$:
OUTPUT #PRTSPD,#36. ;PRINT TEST ID
SELECT CLK TYP OF 4 VERIFY ;SET UP THE RIGHT CLOCK
MOV CLK TYP,-(SP)
BLE 50142$
CMP (SP),#4
BLE 50143$
50142$:
MOV #5,(SP)
50143$:
```

```

(2) 016322 006316 ASL (SP)
(2) 016324 060716 ADD PC,(SP)
(2) 016326 063607 ADD @ (SP)+,PC
(3) 016330 50144$:
(4) 016330 000012 .WORD 50151$-50144$
(4) 016332 000020 .WORD 50150$-50144$
(4) 016334 000072 .WORD 50147$-50144$
(4) 016336 000160 .WORD 50146$-50144$
(3) 016340 000162 .WORD 50145$-50144$
2118
2119 016342 CASE 1
(4) 016342 50151$:
2120 016342 000137 017514 JMP END4 ;JUST EXIT TEST NO CLOCK AVAILBLE
2121
2122 016346 CASE 2 ;KW11-L LINE CLOCK SELECTED
(4) 016346 000461 BR 50145$
(4) 016350 50150$:
2123 016350 LET CLKENA := #100 ;INTERRUPT ENABLE/ CLR MONITOR
(4) 016350 012737 000100 002346 MOV #100,CLKENA
; SET PRI7 WHILE CHANGING VECTOR ADDRESS
2124 SETPRI #PRI07
2125 016356 MOV #PRI07,R0
(3) 016356 012700 000340 TRAP C$SPRI
(3) 016362 104441 SETVEC CLKVEC,#CLKTCK,#PRI06 ;SET UP INTERRUPT VECTOR
2126 016364 MOV #PRI06,-(SP)
(7) 016364 012746 000300 MOV #CLKTCK,-(SP)
(6) 016370 012746 041066 MOV CLKVEC,-(SP)
(5) 016374 013746 002344 MOV #3,-(SP)
(4) 016400 012746 000003 TRAP C$SVEC
(3) 016404 104437 ADD #10,SP
(2) 016406 062706 000010 SETPRI #PRI00
2127 016412 MOV #PRI00,R0
(3) 016412 012700 000000 TRAP C$SPRI
(3) 016416 104441
2128
2129 016420 CASE 3 ;KW11-P REAL TIME CLOCK
(4) 016420 000434 BR 50145$
(4) 016422 50147$:
2130 016422 LET CLKSET := CLKCSR + #2
(4) 016422 013737 002340 002342 MOV CLKCSR,CLKSET
(6) 016430 062737 000002 002342 ADD #2,CLKSET
2131 016436 LET CLKENA := #111 ;SET UP ENABLE BITS
(4) 016436 012737 000111 002346 MOV #111,CLKENA
; RUN, RATE = 10KHZ, REPEAT INTR, DOWN,INT ENABLE
2132 SETPRI #PRI07
2133 016444 MOV #PRI07,R0
(3) 016444 012700 000340 TRAP C$SPRI
(3) 016450 104441 SETVEC CLKVEC,#CLKTCK,#PRI06 ;INTERRUPT VECTOR
2134 016452 MOV #PRI06,-(SP)
(7) 016452 012746 000300 MOV #CLKTCK,-(SP)
(6) 016456 012746 041066 MOV CLKVEC,-(SP)
(5) 016462 013746 002344 MOV #3,-(SP)
(4) 016466 012746 000003 TRAP C$SVEC
(3) 016472 104437 ADD #10,SP
(2) 016474 062706 000010 SETPRI #PRI00
2135 016500 MOV #PRI00,R0
(3) 016500 012700 000000 TRAP C$SPRI
(3) 016504 104441
    
```

```

2136
2137 016506          CASE 4
(4) 016506 000401    BR          50145$
(4) 016510          50146$:
2138 016510 000240    NOP          ;THIS IS JUST A DUMMY
2139 016512          ENDSELECT
(3) 016512          50145$:
2140 016512          LET OUTBUF :B= #LF
(4) 016512 112737 000012 003172    MOVB #LF,OUTBUF
2141 016520          LET LUNIT := R1
(4) 016520 010137 002326    MOV R1,LUNIT
2142 016524          11$:
2143 016524          LET ERRFLG := #0
(4) 016524 005037 002352    CLR ERRFLG
2144 016530          LET R2 := LUNIT SHIFT 1
(4) 016530 013702 002326    MOV LUNIT,R2
(7) 016534 006302    ASL R2

:
: DETERMIN WHICH BAND, AND SEND APPROPRIATE PATTERN
:
: IF #FLAG96 NOTSETIN STATUS(R2) THEN ; 64 CHAR BAND
(6) 016536 032762 010000 002524    BIT #FLAG96,STATUS(R2)
(9) 016544 001152    BNE 50152$
2149 016546          IF #FLAG26 NOTSETIN STATUS(R2) AND #FLAG27 NOTSETIN STATUS(R2) THEN
(6) 016546 032762 001000 002524    BIT #FLAG26,STATUS(R2)
(9) 016554 001065    BNE 50153$
(6) 016556 032762 002000 002524    BIT #FLAG27,STATUS(R2)
(9) 016564 001061    BNE 50153$
2150 016566          LET BNDPAT := #TAB64 ;64 CHARACTER BAND LP25
(4) 016566 012737 021712 020742    MOV #TAB64,BNDPAT
2151 016574          LET WORK := #133.
(4) 016574 012737 000205 003166    MOV #133.,WORK
2152 016602          PRINTF #LPM64 ; SHOULD BE 285 LPM.
(7) 016602 012746 021406    MOV #LPM64,-(SP)
(6) 016606 012746 000001    MOV #1,-(SP)
(3) 016612 010600    MOV SP,R0
(4) 016614 104417    TRAP C$PNTF
(4) 016616 062706 000004    ADD #4,SP
2153 016622          OUTPUTI #LPM64+4,#42.,LUNIT ; SEND SPEED MSG TO PRINTER TOO
2154 016664          OUTPUTI #OUTBUF,#1.,LUNIT
2155 016726          ELSE ; IT'S AN LP26
(4) 016726 000460    BR 50154$
(3) 016730          50153$:
2156 016730          LET BNDPAT := #TAB64 ; LP26 64 CHAR BAND
(4) 016730 012737 021712 020742    MOV #TAB64,BNDPAT
2157 016736          LET WORK := #133.
(4) 016736 012737 000205 003166    MOV #133.,WORK
2158 016744          PRINTF #L26M64 ; LP26 64 CHAR SPEED MSG. 600 LPM.
(7) 016744 012746 021550    MOV #L26M64,-(SP)
(6) 016750 012746 000001    MOV #1,-(SP)
(3) 016754 010600    MOV SP,R0
(4) 016756 104417    TRAP C$PNTF
(4) 016760 062706 000004    ADD #4,SP
2159 016764          OUTPUTI #L26M64+4,#42.,LUNIT ; SEND SPEED MSG TO PRINTER TOO
2160 017026          OUTPUTI #OUTBUF,#1.,LUNIT
2161 017070          ENDIF
    
```

(4)	017070				50154\$:	
2162	017070				ELSE	: 96 CHAR BAND
(4)	017070	000551			BR	50155\$
(3)	017072				50152\$:	
2163	017072				IF #FLAG26 NOTSETIN STATUS(R2) AND #FLAG27 NOTSETIN STATUS(R2) THEN	
(6)	017072	032762	001000	002524	BIT #FLAG26,STATUS(R2)	
(9)	017100	001065			BNE 50156\$	
(6)	017102	032762	002000	002524	BIT #FLAG27,STATUS(R2)	
(9)	017110	001061			BNE 50156\$	
2164	017112				LET BNDPAT := #TABA96	;96 CHARACTER BAND
(4)	017112	012737	022120	020742	MOV #TABA96,BNDPAT	
2165	017120				LET WORK := #133.	
(4)	017120	012737	000205	003166	MOV #133.,WORK	
2166	017126				PRINTF #LPM96	; SHOULD BE 204 LPM.
(7)	017126	012746	021467		MOV #LPM96,-(SP)	
(6)	017132	012746	000001		MOV #1,-(SP)	
(3)	017136	010600			MOV SP,R0	
(4)	017140	104417			TRAP C\$PNTF	
(4)	017142	062706	000004		ADD #4,SP	
2167	017146				OUTPUT #LPM96+4,#42.,,LUNIT	; SEND SPEED MSG TO PRINTER TOO
2168	017210				OUTPUT #OUTBUF,#1,,LUNIT	
2169	017252				ELSE	
(4)	017252	000460			BR 50157\$	
(3)	017254				50156\$:	
2170	017254				LET BNDPAT := #TABA96	; LP26 96 CHAR BAND
(4)	017254	012737	022120	020742	MOV #TABA96,BNDPAT	
2171	017262				LET WORK := #133.	
(4)	017262	012737	000205	003166	MOV #133.,WORK	
2172	017270				PRINTF #L26M96	; LP26 96 CHAR SPEED MSG. 450 LPM.
(7)	017270	012746	021631		MOV #L26M96,-(SP)	
(6)	017274	012746	000001		MOV #1,-(SP)	
(3)	017300	010600			MOV SP,R0	
(4)	017302	104417			TRAP C\$PNTF	
(4)	017304	062706	000004		ADD #4,SP	
2173	017310				OUTPUT #L26M96+4,#42.,,LUNIT	; SEND SPEED MSG TO PRINTER TOO
2174	017352				OUTPUT #OUTBUF,#1,,LUNIT	
2175	017414				ENDIF	
(4)	017414				50157\$:	
2176	017414				ENDIF	
(4)	017414				50155\$:	
2177	017414				LET LINCNT := #0	;CLEAR LINE COUNTER
(4)	017414	005037	002310		CLR LINCNT	
2178	017420				LET TICK := #60.	;SET UP INITIAL CLOCK VALUE
(4)	017420	012737	000074	041142	MOV #60.,TICK	
2179	017426	004737	017632		JSR PC,REPLUP	;DO THE OUTPUT
2180	017432				LET LUNIT := LUNIT - #1	
(6)	017432	005337	002326		DEC LUNIT	
2181	017436				IFCOND GE THEN	
(6)	017436	002402			BLT 50160\$	
2182	017440	000137	016524		JMP 11\$	
2183	017444				ENDIF	
(4)	017444				50160\$:	
2184						
2185	017444				LET OUTBUF := #14	
(4)	017444	012737	000014	003172	MOV #14,OUTBUF	
2186	017452				OUTPUT #OUTBUF,#1	

```

2187
2188 017514          END4:  IF CLKTYP EQ #3 THEN
(6) 017514 023727 002334 000003  CMP     CLKTYP,#3
(9) 017522 001011          BNE     50161$
2189 017524          SETPRI #PRI07
(3) 017524 012700 000340  MOV     #PRI07,R0
(3) 017530 104441          TRAP   C$SPRI
2190 017532          CLRVEC CLKVEC
(3) 017532 013700 002344  MOV     CLKVEC,R0
(3) 017536 104436          TRAP   C$CVEC
2191 017540          LET @CLKCSR := #00
(4) 017540 012777 000000 162572 MOV     #00,@CLKCSR
2192 017546          ENDIF
(4) 017546          50161$:
2193 017546          IF CLKTYP EQ #2 THEN
(6) 017546 023727 002334 000002  CMP     CLKTYP,#2
(9) 017554 001021          BNE     50162$
2194 017556          SETPRI #PRI07
(3) 017556 012700 000340  MOV     #PRI07,R0
(3) 017562 104441          TRAP   C$SPRI
2195 017564          SETVEC CLKVEC,#IGNORE,#PRI06
(7) 017564 012746 000300  MOV     #PRI06,-(SP)
(6) 017570 012746 007266  MOV     #IGNORE,-(SP)
(5) 017574 013746 002344  MOV     CLKVEC,-(SP)
(4) 017600 012746 000003  MOV     #3,-(SP)
(3) 017604 104437          TRAP   C$SVEC
(2) 017606 062706 000010  ADD     #10,SP
2196 017612          LET @CLKCSR := #00
(4) 017612 012777 000000 162520 MOV     #00,@CLKCSR
2197 017620          ENDIF
(4) 017620          50162$:
2198 017620          SETPRI #PRI00
(5) 017620 012700 000000  MOV     #PRI00,R0
(3) 017624 104441          TRAP   C$SPRI
2199
2200 017626          EXIT TST
(3) 017626 104432          TRAP   C$EXIT
(3) 017630 002476          .WORD  L10013-.
2201
2202
2203          ;THIS IS SUBROUTINED TO DECREASE THE SIZE OF THE INITIAL INCREMENT LOOP.
2204
2205
2206          REPLUP:
2207 017632          IF CLKTYP EQ #4 THEN
(6) 017632 023727 002334 000004  CMP     CLKTYP,#4
(9) 017640 001124          BNE     50163$
2208 017642          PRINTF #OFFLIN          ;TELL OPERATOR TO PLACE PRINTERS OFFLINE
(7) 017642 012746 021051  MOV     #OFFLIN,-(SP)
(6) 017646 012746 000001  MOV     #1,-(SP)
(3) 017652 010600          MOV     SP,R0
(4) 017654 104417          TRAP   C$PNTF
(4) 017656 062706 000004  ADD     #4,SP
2209 017662          LET FLAG := #0
(4) 017662 005037 002306  CLR     FLAG
2210 017666          GMANIL READY,FLAG,100000,YES
    
```

(3)	017666	104443			TRAP	C\$GMAN	
(3)	017670	000404			BR	10000\$	
(4)	017672	002306			.WORD	FLAG	
(5)	017674	000130			.WORD	T\$CODE	
(5)	017676	007072			.WORD	READY	
(5)	017700	100000			.WJRD	100000	
(3)	017702						
2211	017702			10000\$:	PRINTF #ONLIN1,LUNIT		;PUT LUNIT TO TEST ON LINE
(8)	017702	013746	002326		MOV	LUNIT,-(SP)	
(7)	017706	012746	021111		MOV	#ONLIN1,-(SP)	
(6)	017712	012746	000002		MOV	#2,-(SP)	
(3)	017716	010600			MOV	SP,R0	
(4)	017720	104417			TRAP	C\$PNTF	
(4)	017722	062706	000006		ADD	#6,SP	
2212	017726				PRINTF #ONLIN2,LUNIT		;END OF TEST.
(8)	017726	013746	002326		MOV	LUNIT,-(SP)	
(7)	017732	012746	021212		MOV	#ONLIN2,-(SP)	
(6)	017736	012746	000002		MOV	#2,-(SP)	
(3)	017742	010600			MOV	SP,R0	
(4)	017744	104417			TRAP	C\$PNTF	
(4)	017746	062706	000006		ADD	#6,SP	
2213	017752				PRINTF #ONLIN3,LUNIT		
(8)	017752	013746	002326		MOV	LUNIT,-(SP)	
(7)	017756	012746	021310		MOV	#ONLIN3,-(SP)	
(6)	017762	012746	000002		MOV	#2,-(SP)	
(3)	017766	010600			MOV	SP,R0	
(4)	017770	104417			TRAP	C\$PNTF	
(4)	017772	062706	000006		ADD	#6,SP	
2214	017776				WHILE #BIT15 SETIN @LPCSR(R2) DO		; WAIT FOR LP SET ON-LINE
(4)	017776			50164\$:			
(6)	017776	032772	100000	002370	BIT	#BIT15,@LPCSR(R2)	
(9)	020004	001402			BEQ	50165\$	
2215	020006	000240				NOP	
2216	020010					ENDDO	
(4)	020010	000772			BR	50164\$	
(3)	020012			50165\$:			
2217	020012				LET LINCNT := #0		
(4)	020012	005037	002310		CLR	LINCNT	
2218	020016				WHILE #BIT15 NOTSETIN @LPCSR(R2) DO		; REPEAT UNTIL LP GOES OFF-LINE
(4)	020016			50166\$:			
(6)	020016	032772	100000	002370	BIT	#BIT15,@LPCSR(R2)	
(9)	020024	001031			BNE	50167\$	
2219	020026				LET R5 := BNDPAT		
(4)	020026	013705	020742		MOV	BNDPAT,R5	
2220	020032				LET R3 := WORK		
(4)	020032	013703	003166		MOV	WORK,R3	
2221	020036				WHILE R3 GT #0 DO		; PRINT R3 CHARACTERS
(4)	020036			50170\$:			
(6)	020036	005703			TST	R3	
(9)	020040	003417			BLE	50171\$	
2222	020042				WHILE #BIT7 NOTSETIN @LPCSR(R2) DO		; WAIT FOR READY
(4)	020042			50172\$:			
(6)	020042	032772	000200	002370	BIT	#BIT7,@LPCSR(R2)	
(9)	020050	001007			BNE	50173\$	
2223	020052				IF #BIT15 SETIN @LPCSR(R2) THEN		
(6)	020052	032772	100000	002370	BIT	#BIT15,@LPCSR(R2)	


```

(9) 020060 001402          BEQ      50174$
2224 020062 000137 020224          JMP 99$ ; EXIT LOOP IF OFF-LINE AGAIN
2225 020066          ENDIF
(4) 020066          50174$:
2226 020066 000765          ENDDO
(4) 020066 000765          BR      50172$
(3) 020070          50173$:
2227 020070          LET @LPBUF(R2) :B= (R5)+ ; PUT CHAR INTO LP BUFFER
(4) 020070 112572 002464          MOVB   (R5)+,@LPBUF(R2)
2228 020074          LET R3 := R3 - #1 ; DECRIMENT CHAR COUNTER
(6) 020074 005303          DEC    R3
2229 020076          ENDDO
(4) 020076 000757          BR      50170$
(3) 020100          50171$:
2230 020100          BREAK ; ALLOW CTL-C ABORT
(3) 020100 104422          TRAP   C$BRK
2231 020102          LET LINCNT := LINCNT + #1
(6) 020102 005237 002310          INC    LINCNT
2232 020106          ENDDO
(4) 020106 000743          BR      50166$
(3) 020110          50167$:
2233 020110          ELSE
(4) 020110 000445          BR      50175$
(3) 020112          50163$:
2234 020112          IF CLKTYP EQ #3 THEN
(6) 020112 023727 002334 000003          CMP    CLKTYP,#3
(9) 020120 001003          BNE    50176$
2235 020122          LET @CLKSET := #1666. ; 1/60 SEC.
(4) 020122 012777 003202 162212          MOV    #1666.,@CLKSET
2236 020130          ENDIF
(4) 020130          50176$:
2237 020130          LET @CLKCSR := CLKENA ;ENABLE THE CLOCK TO DO ITS THING
(4) 020130 013777 002346 162202          MOV    CLKENA,@CLKCSR
2238 020136          LET TIME := #0
(4) 020136 005037 041140          CLR    TIME
2239 020142          LET LINCNT := #0
(4) 020142 005037 002310          CLR    LINCNT
2240 020146          WHILE TIME LT PERIOD DO ; REPEAT UNTIL TIME EXHAUSTED
(4) 020146          50177$:
(6) 020146 023737 041140 002300          CMP    TIME,PERIOD
(9) 020154 002023          BGE    50200$
2241 020156          LET R5 := BNDPAT
(4) 020156 013705 020742          MOV    BNDPAT,R5
2242 020162          LET R3 := WORK
(4) 020162 013703 003166          MOV    WORK,R3
2243 020166          WHILE R3 GT #0 DO ; SEND R3 CHARACTERS
(4) 020166          50201$:
(6) 020166 005703          TST    R3
(9) 020170 003412          BLE    50202$
2244 020172          WHILE #BIT7 NOTSETIN @LPCSR(R2) DO ; WAIT FOR READY
(4) 020172          50203$:
(6) 020172 032772 000200 002370          BIT    #BIT7,@LPCSR(R2)
(9) 020200 001002          BNE    50204$
2245 020202 000240          NOP
2246 020204          ENDDO
(4) 020204 000772          BR      50203$
    
```

(3) 020206
 2247 020206
 (4) 020206 112572 002464
 2248 020212
 (6) 020212 005303
 2249 020214
 (4) 020214 000764
 (3) 020216
 2250 020216
 (6) 020216 005237 002310
 2251 020222
 (4) 020222 000751
 (3) 020224
 2252 020224
 (4) 020224
 2253 020224
 2254
 2255
 2256
 2257
 2258 020224
 (6) 020224 023727 002334 000004
 (9) 020232 001020
 2259 020234
 (4) 020234 005037 002306
 2260 020240
 (7) 020240 012746 006773
 (6) 020244 012746 000001
 (3) 020250 010600
 (4) 020252 104417
 (4) 020254 062706 000004
 2261 020260
 (5) 020260 104443
 (3) 020262 000404
 (4) 020264 002306
 (5) 020266 000130
 (5) 020270 007072
 (5) 020272 100000
 (3) 020274
 2262 020274
 (4) 020274
 2263 020274 012777 000000 162036
 2264
 2265
 2266
 2267 020302
 (9) 020302 013746 002326
 (8) 020306 013746 002310
 (7) 020312 012746 021004
 (6) 020316 012746 000003
 (3) 020322 010600
 (4) 020324 104414
 (4) 020326 062706 000010
 2268 020332
 (2) 020332 013746 002310
 (3) 020336 012746 003173

```

50204$:
      MOVB      (R5)+,@ALPBUF(R2)      ; PUT DATA INTO BUFFER
      LET R3 := R3 - #1                ; DECREMENT CHAR COUNTER
      DEC       R3
      ENDDO
      BR        50201$

50202$:
      LET LINCNT := LINCNT + #1
      INC       LINCNT
      ENDDO
      BR        50177$

50200$:
      ENDIF

50175$:
99$:
:
: IF MANUAL PRINT SPEED TESTS HAVE BEEN PERFORMED INSURE PRINTERS ARE
: BACK ON LINE WHEN DONE
:
: IF CLKTYP EQ #4 THEN
      CMP       CLKTYP,#4
      BNE      50205$
      LET FLAG := #0                    ; CLEAR <CR> FLAG
      CLR      FLAG
      PRINTF #MRESET
      MOV      #MRESET,-(SP)
      MOV      #1,-(SP)
      MOV      SP,R0
      TRAP    C$PNTF
      ADD     #4,SP
      GMANIL READY,FLAG,100000,YES      ; WAIT FOR OPERATOR
      TRAP    C$GMAN
      BR      10001$
      .WORD   FLAG
      .WORD   T$CODE
      .WORD   READY
      .WORD   100000

10001$:
      ENDIF
50205$:
      MOV      #00,@CLKCSR
:
: REPORT TOTAL NUMBER OF LINES PRINTED
:
      PRINTB   #LINPER,LINCNT,LUNIT
      MOV      LUNIT,-(SP)
      MOV      LINCNT,-(SP)
      MOV      #LINPER,-(SP)
      MOV      #3,-(SP)
      MOV      SP,R0
      TRAP    C$PNTB
      ADD     #10,SP
      PUSH    LINCNT,#OUTBUF+1          ; CONVERT LINE COUNT TO ASCII
      MOV      LINCNT,-(SP)
      MOV      #OUTBUF+1,-(SP)
  
```

```

2269 020342 004737 004472 JSR PC,BIN2DA
2270 020346 OUTPUTI #OUTBUF,#6,,LUNIT ; DISPLAY LINE COUNT ON LP
2271 020410 004737 005466 JSR PC,QUIET
2272 020414 OUTPUTI #SPED1,#19,,LUNIT ; 'LINES PRINTED'
2273 ; IF A CLOCK WAS USED DISPLAY THE TIME USED ALSO
2274 020456 IF CLKTYP EQ #2 OR CLKTYP EQ #3 THEN
(6) 020456 023727 002334 000002 CMP CLKTYP,#2
(8) 020464 001404 BEQ 50206$
(6) 020466 023727 002334 000003 CMP CLKTYP,#3
(9) 020474 001074 BNE 50207$
(6) 020476 50206$:
2275 020476 OUTPUTI #SPED2,#4,,LUNIT ; " IN "
2276 020540 PUSH PERIOD,#OUTBUF+1 ; CONVERT TIME TO ASCII
(2) 020540 013746 002300 MOV PERIOD,-(SP)
(3) 020544 012746 003173 MOV #OUTBUF+1,-(SP)
2277 020550 004737 004472 JSR PC,BIN2DA
2278 020554 OUTPUTI #OUTBUF+3,#3,,LUNIT ; DISPLAY THE TIME IN SECONDS
2279 020616 004737 005466 JSR PC,QUIET
2280 020622 OUTPUTI #SPED3,#9,,LUNIT ; 'SECONDS' <Ff>
2281 020664 ELSE
(4) 020664 000421 BR 50210$
(3) 020666 50207$:
2282 020666 OUTPUTI #SPED4,#1,,LUNIT ; <FF>
2283 020730 ENDIF
(4) 020730 50210$:
2284 020730 000207 RTS PC ;GO BACK AND DO IT AGAIN
2285 ;
2286 ;EXPECTED ERROR HANDLER
2287 ;
2288 020732 LPERR2: LET ERRFLG := #1 ;SET ERROR FOUND
(4) 020732 012737 000001 002352 MOV #1,ERRFLG
2289 020740 000207 RTS PC ;AND EXIT
2290 ;
2291 ;
2292 020742 000000 BNDPAT: .WORD 0 ; CONTAINS ADDRESS OF PRINT PATTERN
2293 .NLIST BEX
2294 ;
2295 ;ASSOCIATED MESSAGES
2296 ;
2297 020744 046040 047111 051505 SPED1: .ASCII / LINES WERE PRINTED/
2298 020767 040 047111 040 SPED2: .ASCII / IN /
2299 020773 040 042523 047503 SPED3: .ASCII / SECONDS/
2300 021003 014 SPED4: .BYTE 14
2301 021004 047045 042045 022463 LINPER: .ASCIZ /%N%D3%A LINES PRINTED ON LUNIT %D2%N/
2302 021051 045 022516 044501 OFFLIN: .ASCIZ /%N%AINSURE PRINTER(S) OFF LINE./
2303 021111 045 022516 050101 ONLIN1: .ASCIZ /%N%APLACE LUNIT %D2%A ON LINE TO INITIATE TIME PERIOD FOR MANUAL/
2304 021212 047045 040445 051120 ONLIN2: .ASCIZ /%N%APRINTING SPEED MEASUREMENT AND BACK OFF LINE TO TERMINATE/
2305 021310 047045 040445 044124 ONLIN3: .ASCIZ /%N%ATHE TIME INTERVAL.%N/
2306 021341 120 044522 052116 PRTSPD: .ASCIZ /PRINTING SPEED MEASUREMENT TEST 4/<12><12><12>
2307 021406 047045 040445 032066 LPM64: .ASCIZ /%N%A64 CHARACTER BAND SHOULD PRINT AT 285 LPM.%N/
2308 021467 045 022516 034501 LPM96: .ASCIZ /%N%A96 CHARACTER BAND SHOULD PRINT AT 204 LPM.%N/
2309 021550 047045 040445 032066 L26M64: .ASCIZ /%N%A64 CHARACTER BAND SHOULD PRINT AT 600 LPM.%N/
2310 021631 045 022516 034501 L26M96: .ASCIZ /%N%A96 CHARACTER BAND SHOULD PRINT AT 450 LPM.%N/
2311 .LIST BEX
2312 .EVEN
2313 ;64 CHARACTER BAND PATTERN 285 LPM / 600 LPM.
  
```

Line	Code	Col 1	Col 2	Col 3	Col 4	Col 5	Col 6
2314							
2315							
2316							
2317	021712	105	061	104	TABA64: .BYTE	105,061,104,075,064,041,103,136,102,060,163	
	021715	075	064	041			
	021720	103	136	102			
	021723	060	163				
2318	021725	042	062	134	.BYTE	042,062,134,054,124,101,133,101,133,043,135	
	021730	054	124	101			
	021733	133	101	133			
	021736	043	135				
2319	021740	041	105	061	.BYTE	041,105,061,100,075,077,041,056,136,074,060	
	021743	100	075	077			
	021746	041	056	136			
	021751	074	060				
2320	021753	076	042	073	.BYTE	076,042,073,042,073,134,055,124,044,133,057	
	021756	042	073	134			
	021761	055	124	044			
	021764	133	057				
2321	021766	135	054	105	.BYTE	135,054,105,072,100,050,077,052,056,051,056	
	021771	072	100	050			
	021774	077	052	056			
	021777	051	056				
2322	022001	051	074	046	.BYTE	051,074,046,076,071,073,045,055,053,044,137	
	022004	076	071	073			
	022007	045	055	053			
	022012	044	137				
2323	022014	057	070	054	.BYTE	057,070,054,132,072,131,072,131,050,067,052	
	022017	132	072	131			
	022022	072	131	050			
	022025	067	052				
2324	022027	130	051	127	.BYTE	130,051,127,046,066,071,126,045,125,053,065	
	022032	046	066	071			
	022035	126	045	125			
	022040	053	065				
2325	022042	137	123	137	.BYTE	137,123,137,123,070,122,132,121,131,064,067	
	022045	123	070	122			
	022050	132	121	131			
	022053	064	067				
2326	022055	120	130	117	.BYTE	120,130,117,124,063,066,116,126,115,126,115	
	022060	124	063	066			
	022063	116	126	115			
	022066	126	115				
2327	022070	125	062	065	.BYTE	125,062,065,114,123,113,122,061,121,112,064	
	022073	114	123	113			
	022076	122	061	121			
	022101	112	064				
2328	022103	111	120	110	.BYTE	111,120,110,117,060,117,060,063,107,116,106,012,015	
	022106	117	060	117			
	022111	060	063	107			
	022114	116	106	012			
	022117	015					

: 96 CHARACTER BAND TABLE 204 LPM. / 450 LPM.
 : MINIMUM PRINT SPEED PATTERN 96 CHARACTER BAND

2329
 2330
 2331
 2332

2333	022120	061	055	144	TABA96: .BYTE	061,055,144,047,143,043,142,041,060,052,100
	022123	047	143	043		
	022126	142	041	060		
	022131	052	100			
2334	022133	075	140	174	.BYTE	075,140,174,176,041,056,054,056,054,136,042
	022136	176	041	056		
	022141	054	056	054		
	022144	136	042			
2335	022146	176	134	173	.BYTE	176,134,173,133,175,135,055,164,047,100,043
	022151	133	175	135		
	022154	055	164	047		
	022157	100	043			
2336	022161	077	041	074	.BYTE	077,041,074,041,074,052,062,075,076,174,073
	022164	041	074	052		
	022167	062	075	076		
	022172	174	073			
2337	022174	041	053	054	.BYTE	041,053,054,071,042,057,134,072,133,050,133
	022177	071	042	057		
	022202	134	072	133		
	022205	050	133			
2338	022207	050	135	051	.BYTE	050,135,051,164,070,100,046,124,045,123,044
	022212	164	070	100		
	022215	046	124	045		
	022220	123	044			
2339	022222	122	067	064	.BYTE	122,067,064,137,073,132,073,132,053,131,071
	022225	137	073	132		
	022230	073	132	053		
	022233	131	071			
2340	022235	066	057	130	.BYTE	066,057,130,072,127,050,120,151,125,070,065
	022240	072	127	050		
	022243	120	151	125		
	022246	070	065			
2341	022250	046	124	046	.BYTE	046,124,046,124,045,123,044,122,067,064,137
	022253	124	045	123		
	022256	044	122	067		
	022261	064	137			
2342	022263	121	132	120	.BYTE	121,132,120,131,117,066,063,130,116,130,116
	022266	131	117	066		
	022271	063	130	116		
	022274	130	116			
2343	022276	127	115	126	.BYTE	127,115,126,114,125,113,065,062,124,112,123
	022301	114	125	113		
	022304	065	062	124		
	022307	112	123			
2344	022311	111	122	110	.BYTE	111,122,110,064,061,064,061,121,107,102,106,012,015
	022314	064	061	064		
	022317	061	121	107		
	022322	102	106	012		
	022325	015				
2345					.EVEN	
2346	022326				ENDTST	
(3)	022326				L10013:	
(3)	022326	104401			TRAP	C\$ETST
2347	022330				ENDMOD	

2349				.SBTTL DAVFU ERROR DETECTION
2350				BGNMOD
2351	022330			:++
2352				:THIS TEST CONSISTS OF TWO PARTS TO VERIFY
2353				:THAT THE DAVFU CAN DETECT ERROR CONDITIONS
2354				:OF TWO TYPES:
2355				:1. DAVFU WILL NOT ACCEPT INCOMPLETE DATA.
2356				:2. DAVFU WILL NOT ACCEPT DATA THAT DOES
2357				: NOT INCLUDE A STOP BIT (ONE) CHARACTER.
2358				:--
2359				BGNTST 5
2360	022330			T5::
(3)	022330			:EXIT TEST IF DAVFU OPTION IS NOT SPECIFIED
2361				IF VFUOPT EQ #0 THEN
2362	022330	005737	002274	TST VFUOPT
(6)	022330			BNE 50211\$
(9)	022334	001002		EXIT TST
2363	022336			TRAP C\$EXIT
(3)	022336	104432		.WORD L10014-.
(3)	022340	001354		ENDIF
2364	022342			50211\$:
(4)	022342			:PRINT TEST IDENTIFICATION
2365				OUTPUT #VFUERR, #32., LPERR
2366	022342			:DETERMINE IF MANUAL INTERVENTION IS ALLOWED
2367				MANUAL
2368	022404			TRAP C\$MANI
(3)	022404	104450		BCOMPLETE 1\$
2369	022406			BCS 1\$
(2)	022406	103402		:EXIT TEST IF NEGATIVE DETERMINATION FOR MANUAL
2370				:INTERVENTION IS MADE
2371				EXIT TST
2372	022410			TRAP C\$EXIT
(5)	022410	104432		.WORD L10014-.
(3)	022412	001302		:DETERMINE IF INTERVENTION IS INHIBITED
2373				1\$:
2374	022414	005737	002272	TST INHINT
2375	022420	001002		BNE 2\$
2376	022422			EXIT TST
(3)	022422	104432		TRAP C\$EXIT
(3)	022424	001270		.WORD L10014-.
2377	022426			2\$:
(3)	022426			BGNSUB
(3)	022426	104402		T5.1:
2378				TRAP C\$BSUB
2379	022430			:SEND MESSAGE TO OPERATOR TO SET VFU-FLS SWITCH(ES)
(7)	022430	012746	004045	PRINTF #VFUSEL
(6)	022434	012746	000001	MOV #VFUSEL, -(SP)
(3)	022440	010600		MOV #1, -(SP)
(4)	022442	104417		MOV SP, R0
(4)	022444	062706	000004	TRAP C\$PNTF
2380				ADD #4, SP
2381	022450			:WAIT FOR OPERATOR RESPONSE
(4)	022450	005037	002306	LET FLAG := #0
2382	022454			CLR FLAG
(3)	022454	104443		GMANIL READY, FLAG, 100000, YES
(3)	022456	000404		TRAP C\$GMAN
				BR 10000\$

(4)	022460	002306			.WORD	FLAG
(5)	022462	000130			.WORD	T\$CODE
(5)	022464	007072			.WORD	READY
(5)	022466	100000			.WORD	100000
(3)	022470					
2383					10000\$:	
2384	022470				;PERFORM	INCOMPLETE DATA ERROR DETECTION TEST
(4)	022470	013701	002012		LET R1 :=	L\$UNIT - #1
(6)	022474	005301			MOV	L\$UNIT,R1
2385	022476				DEC	R1
(4)	022476	005037	002326		INCR	LUNIT FROM #0 TO R1 BY #1
(5)	022502	000402			CLR	LUNIT
(4)	022504				BR	50212\$
(7)	022504	005237	002326		50213\$:	INC LUNIT
(5)	022510				50212\$:	CMP LUNIT,R1
(5)	022510	023701	002326		BGT	50214\$
(7)	022514	003064			LET R2 :=	LUNIT SHIFT 1
2386	022516				MOV	LUNIT,R2
(4)	022516	013702	002326		ASL	R2
(7)	022522	006302			LET FLAG :=	#0
2387	022524				CLR	FLAG
(4)	022524	005037	002306		OUTPUT	#INCDAT, #41,,, LUNIT
2388	022530				OUTPUT	#INCTBL, #5, #GETFLG, LUNIT
2389	022572				IF FLAG EQ	#0 THEN
2390	022634				TST	FLAG
(6)	022634	005737	002306		BNE	50215\$
(9)	022640	001011			LET ERRTBL(R2) :=	ERRTBL(R2) + #1
2391	022642				INC	ERRTBL(R2)
(6)	022642	005262	003126		LET L\$LUN :=	LUNIT
2392	022646				MOV	LUNIT,L\$LUN
(4)	022646	013737	002326	002074	ERRHRD	11, ERR06
2393	022654				TRAP	C\$ERHRD
(4)	022654	104456			.WORD	11
(5)	022656	000013			.WORD	ERR06
(5)	022660	023563			.WORD	0
(5)	022662	000000			ENDIF	
2394	022664				50215\$:	ENDINC
(4)	022664				BR	50213\$
2395	022664				50214\$:	ENDSUB
(4)	022664	000707			L10015:	TRAP C\$ESUB
(3)	022666				BGNSUB	
(3)	022666				T5.2:	TRAP C\$BSUB
(3)	022666	104403			;PERFORM	STOP CODE ERROR DETECTION TEST
2397					INCR	LUNIT FROM #0 TO R1 BY #1
2398	022670				CLR	LUNIT
(3)	022670				BR	50216\$
(3)	022670	104402			50217\$:	INC LUNIT
2399					50216\$:	CMP LUNIT,R1
2400	022672					
(4)	022672	005037	002326			
(5)	022676	000402				
(4)	022700					
(7)	022700	005237	002326			
(5)	022704					
(5)	022704	023701	002326			

(7)	022710	003163			BGT	50220\$	
2401	022712				LET R2 := LUNIT SHIFT 1		
(4)	022712	013702	002326		MOV	LUNIT,R2	
(7)	022716	006302			ASL	R2	
2402	022720				LET FLAG := #0		
(4)	022720	005037	002306		CLR	FLAG	
2403	022724				OUTPUT #NOSTOP, #35, LUNIT		
2404	022766				OUTPUT #NSTTBL, #6, #GETFLG, LUNIT		
2405	023030				INCR VFUCMD FROM #200 TO #213 BY #1		
(4)	023030	012737	000200	002360	MOV	#200,VFUCMD	
(5)	023036	000402			BR	50221\$	
(4)	023040				50222\$:		
(7)	023040	005237	002360		INC	VFUCMD	
(5)	023044				50221\$:		
(5)	023044	023727	002360	000213	CMP	VFUCMD,#213	
(7)	023052	003055			BGT	50223\$	
2406	023054				LET OUTBUF := #15	;'CR' TO OUTPUT BUFFER	
(4)	023054	012737	000015	003172	MOV	#15,OUTBUF	
2407	023062				OUTPUT #OUTBUF, #1, GETFLG, LUNIT		
2408	023124				DELAY 2		
(2)	023124	012727	000002		MOV	#2,(PC)+	
(2)	023130	000000			.WORD	0	
(2)	023132	013727	002116		MOV	L\$DLY,(PC)+	
(2)	023136	000000			.WORD	0	
(2)	023140	005367	177772		DEC	-6(PC)	
(2)	023144	001375			RME	-.4	
(2)	023146	005367	177756		DEC	-22(PC)	
(2)	023152	001367			BNE	-.20	
2409	023154				IF FLAG EQ #0 THEN		
(6)	023154	005737	002306		TST	FLAG	
(9)	023160	001011			BNE	50224\$	
2410	023162				LET ERRTBL(R2) := ERRTBL(R2) + #1		
(6)	023162	005262	003126		INC	ERRTBL(R2)	
2411	023166				LET L\$LUN := LUNIT		
(4)	023166	013737	002326	002074	MOV	LUNIT,L\$LUN	
2412	023174				ERRHRD 12, ERR07		
(4)	023174	104456			TRAP	C\$ERHRD	
(5)	023176	000014			.WORD	12	
(5)	023200	023634			.WORD	ERR07	
(5)	023202	000000			.WORD	0	
2413	023204				ENDIF		
(4)	023204				50224\$:		
2414	023204				ENDINC		
(4)	023204	000715			BR	50222\$	
(3)	023206				50223\$:		
2415	023206				LET OUTBUF := #14	;'FF' TO OUTPUT BUFFER	
(4)	023206	012737	000014	003172	MOV	#14,OUTBUF	
2416	023214				OUTPUT #OUTBUF, #1, LUNIT		
2417	023256				ENDINC		
(4)	023256	000610			BR	50217\$	
(3)	023260				50220\$:		
2418	023260				EXIT TST		
(3)	023260	104432			TRAP	C\$EXIT	
(3)	023262	000432			.WORD	L10014-	
2419	023264				ENDSUB		
(3)	023264				L10016:		


```
(3) 023264 104403          TRAP    C$ESUB
2420
2421          ; EXPECTED ERROR ROUTINE FOR THIS TEST
2422
2423 023266          GETFLG:  GMANIL  RESET, FLAG, 100000, YES
(3) 023266 104443          TRAP    C$GMAN
(3) 023270 000404          BR      10000$
(4) 023272 002306          .WORD  FLAG
(5) 023274 000130          .WORD  T$CODE
(5) 023276 023460          .WORD  RESET
(5) 023300 100000          .WORD  100000
(3) 023302          10000$:
2424 023302 000207          RTS     PC                ;RETURN
2425
2426          ;
2427
2428          .NLIST BEX
2429 023304 040504 043126 020125 VFUERR: .ASCIZ /DAVFU ERROR DETECTION TEST 5/<12><12><12>
2430 023344 040504 043126 020125 INCDAT: .ASCIZ /DAVFU INCOMPLETE DATA ERROR DETECTION/<12><12><12>
2431 023415 104 053101 052506 NOSTOP: .ASCIZ /DAVFU STOP CODE ERROR DETECTION/<12><12><12>
2432 023460 042524 052123 047440 RESET:  .ASCII /TEST O.K. - PLACE PRINTER ON LINE AND DEPRESS/
2433 023535 042 042522 052524  .ASCIZ  /"RETURN" WHEN READY./<12>
2434
2435 023563 104 053101 052506 ERR06:  .ASCIZ /DAVFU INCOMPLETE DATA ERROR NOT DETECTED/
2436 023634 040504 043126 020125 FRR07:  .ASCIZ /DAVFU STOP CODE ERROR NOT DETECTED/
2437 023700 356 001 002 INCTBL: .BYTE 356, 1, 2, 3, 357
2438 023705 356 000 000 NSTTBL: .BYTE 356, 0, 0, 0, 0, 357
2439          023714          .EVEN
2440
2441
2442
2443
2444
2445          .LIST BEX
2446 023714          ENDTST
(3) 023714          L10014:
(3) 023714 104401          TRAP    C$ETST
2447
2448 023716          ENDMOD
```

```

2450 .SBTTL DAVFU LINE COUNT PAPER CONTROL
2451 023716 BGNMOD
2452 :++
2453 :THIS TEST CHECKS THE LINE COUNT METHOD
2454 :OF PAPER ADVANCE USING THE DAVFU. THE
2455 :DAVFU MEMORY IS LOADED WITH DUMMY
2456 :DATA, AND THEN EACH OF THE LINE COUNT
2457 :SLEWING COMMANDS IS TESTED IN SEQUENCE
2458 :IN THE RANGE FROM ZERO TO 15 LINES.
2459 :--
2460
2461 023716 BGNTST 6
   (3) 023716 T6::
2462 :EXIT TEST IF DAVFU OPTION IS NOT SPECIFIED
2463 023716 IF VFUOPT EQ #0 THEN
   (6) 023716 005737 002274 TST VFUOPT
   (9) 023722 001002 BNE 50225$
2464 023724 EXIT TST
   (3) 023724 104432 TRAP C$EXIT
   (3) 023726 001472 .WORD L10017-.
2465 023730 ENDF
   (4) 023730
2466 50225$:
2467 023730 :PRINT TEST IDENTIFICATION
2468 :OUTPUT #VFULCT, #40., LPERR
2469 023772 :SEND MESSAGE TO OPERATOR TO SET VFU-FLS SWITCH(ES)
   (7) 023772 012746 004045 PRINTF #VFUSEL
   (6) 023776 012746 000001 MOV #VFUSEL, -(SP)
   (3) 024002 010600 MOV #1, -(SP)
   (4) 024004 104417 MOV SP, R0
   (4) 024006 062706 000004 TRAP C$PRINTF
   ADD #4, SP
2470 :WAIT FOR OPERATOR RESPONSE
2471 024012 LET FLAG := #0
   (4) 024012 005037 002306 CLR FLAG
2472 024016 GMANIL READY, FLAG, 100000, YES
   (3) 024016 104443 TRAP C$GMAN
   (3) 024020 000404 BR 10000$
   (4) 024022 002306 .WORD FLAG
   (5) 024024 000130 .WORD T$CODE
   (5) 024026 007072 .WORD READY
   (5) 024030 100000 .WORD 100000
   (3) 024032
2473 10000$:
2474 024032 :INITIALIZE PARAMETERS
   (4) 024032 012737 000200 002360 LET VFUCMD := #200
   MOV #200, VFUCMD
2475 024040 LET R4 := #0
   (4) 024040 005004 CLR R4
2476 :LOAD DAVFU MEMORY
2477 024042 OUTPUT #VFUTBL, #18.
2478 :PRINT FIRST PART OF ZERO LINE SLEW MESSAGE
2479 024104 OUTPUT #FSTMSG, #29.
2480 :SEND ZERO LINE SLEW COMMAND
2481 024146 OUTPUT #VFUCMD, #1.
2482 :PRINT SECOND PART OF ZERO LINE SLEW MESSAGE
2483 024210 OUTPUT #SECMSG, #103.
2484 024252 LET OUTBUF := #15 ;'CR' TO OUTPUT BUFFER
  
```

```

(4) 024252 012737 000015 003172      MOV      #15,OUTBUF
2485 024260                               OUTPUT #OUTBUF, #1.
2486                                     ;SEND OTHER DAVFU PAPER ADVANCE COMMANDS
2487 024322                               INCR VFUCMD FROM #221 TO #237 BY #1
(4) 024322 012737 000221 002360      MOV      #221,VFUCMD
(5) 024330 000402                       BR       50226$
(4) 024332                               50227$:
(7) 024332 005237 002360               INC      VFUCMD
(5) 024336                               50226$:
(5) 024336 023727 002360 000237      CMP      VFUCMD,#237
(7) 024344 003115                       BGT     50230$
2488                                     ;PERFORM PAPER MOVEMENT
2489 024346                               OUTPUT #VFUCMD, #1.
2490 024410                               LET OUTBUF := #15
(4) 024410 012737 000015 003172      MOV      #15,OUTBUF
2491 024416                               OUTPUT #OUTBUF, #1.
2492 024460                               LET OUTBUF := LCTTBL(R4)
(4) 024460 016437 024726 003172      MOV      LCTTBL(R4),OUTBUF
2493 024466                               OUTPUT #OUTBUF, #2
2494                                     ;APPEND MESSAGE AND PRINT MOVEMENT MESSAGE
2495 024530                               OUTPUT #LCTMSG, #131.
2496 024572                               LET R4 := R4 + #2
(6) 024572 062704 000002               ADD     #2,R4
2497 024576                               ENDINC
(4) 024576 000655                       BR       50227$
(3) 024600                               50230$:
2498 024600                               LET OUTBUF := #14
(4) 024600 012737 000014 003172      MOV      #14,OUTBUF
2499 024606                               OUTPUT #OUTBUF, #1.
2500 024650                               EXIT TST
(3) 024650 104432                       TRAP    C$EXIT
(3) 024652 000546                       .WORD  L10017-.
2501                                     .NLIST BEX
2502 024654 040504 043126 020125      VFULCT: .ASCIZ /DAVFU LINE COUNT PAPER CONTROL TEST 6/ <12><12><12>
2503                                     .EVEN
2504 024726 030460 031060 031460      LCTTBL: .ASCIZ/010203040506070809101112131415/
2505
2506 024765      356      001      002      VFUTBL: .BYTE 356, 1, 2, 3, 4, 5, 6
2507 024774      007      010      011      .BYTE 7, 10, 11, 12, 13, 14
2508 025002      015      016      017      .BYTE 15, 16, 17, 20, 357
2509
2510 025007      124      044510 020123      FSTMSG: .ASCIZ /THIS LINE SHOULD BE PRINTED /
2511
2512 025044 046101 020114 047117      SECMSG: .ASCII /ALL ON ONE LINE IF SLEWED ZERO LINES/
2513 025110 027056 027056 027056      .ASCII /...../
2514 025206 027056 000056      .ASCIZ /.../
2515 025212 041040 040514 045516      LCTMSG: .ASCII / BLANK LINES SHOULD OCCUR BETWEEN THIS LINE AND THE/
2516 025275      040      051120 053105      .ASCII / PREVIOUS LINE ...../
2517 025336 027056 027056 027056      .ASCII /...../
2518 025402 027056 027056 027056      .ASCIZ /..... / <15>
2519
2520                                     .EVEN
2521 025420                                     .LIST BEX
(3) 025420                               ENDTST
(3) 025420 104401                               L10017:
2522 025422                               TRAP    C$ETST
                                         ENDMOD
  
```

2524				.SBTTL DAVFU CHANNEL SELECTION PAPER CONTROL
2525				BGNMOD
2526	025422			:++
2527				:THIS TEST CHECKS DAVFU PAPER ADVANCE USING
2528				:STOP BITS LOADED IN DAVFU MEMORY. THE
2529				:DATA FORMAT IS SELECTED TO PROVIDE AN
2530				:OUTPUT IN A TRIANGULAR PATTERN.
2531				:--
2532				
2533				
2534	025422			BGNTST 7
(3)	025422			T7::
2535				:EXIT TEST IF DAVFU OPTION IS NOT SPECIFIED
2536	025422			IF VFUGPT EQ #0 THEN
(6)	025422	005737	002274	TST VFUOPT
(9)	025426	001002		BNE 50231\$
2537	025430			EXIT TST
(3)	025430	104432		TRAP C\$EXIT
(3)	025432	001236		.WORD L10020-
2538	025434			ENDIF
(4)	025434			50231\$:
2539				:PRINT TEST IDENTIFICATION
2540	025434			OUTPUT #VFUCL, #47.
2541				:SEND MESSAGE TO OPERATOR TO SET VFU-FLS SWITCH(ES)
2542	025476			PRINTF #VFUSEL
(7)	025476	012746	004045	MOV #VFUSEL, -(SP)
(6)	025502	012746	000001	MOV #1, -(SP)
(3)	025506	010600		MOV SP, R0
(4)	025510	104417		TRAP C\$PNTF
(4)	025512	062706	000004	ADD #4, SP
2543				:WAIT FOR RESPONSE FROM OPERATOR
2544	025516			LET FLAG := #0
(4)	025516	005037	002306	CLR FLAG
2545	025522			GMANIL READY, FLAG, 100000, YES
(3)	025522	104443		TRAP C\$GMAN
(3)	025524	000404		BR 10000\$
(4)	025526	002306		.WORD FLAG
(5)	025530	000130		.WORD T\$CODE
(5)	025532	007072		.WORD READY
(5)	025534	100000		.WORD 100000
(3)	025536			10000\$:
2546				:LOAD DAVFU MEMORY
2547	025536			OUTPUT #VFUDAT, #50.
2548	025600	012704	000002	MOV #2, R4 ;SET UP ITERATION COUNTER
2549	025604	000401		BR 1\$
2550	025606	005304		2\$: DEC R4 ;BACK UP COUNTER
2551	025610	020427	000001	1\$: CMP R4, #1 ;TEST FOR LAST TIME THROUGH
2552	025614	002002		BGE 3\$;BRANCH IF LAST TIME THROUGH FALSE
2553	025616	000137	026446	JMP 4\$;EXIT TEST
2554				:SEND PAPER INSTRUCTIONS TO ALL 12 CHANNELS
2555	025622			3\$: INCR INSTR FROM #200 TO #213 BY #1
(4)	025622	012737	000200 026522	MOV #200, INSTR
(5)	025630	000402		BR 50232\$
(4)	025632			50233\$:
(7)	025632	005237	026522	INC INSTR
(5)	025636			50232\$:

2584	026440				ENDDEC
(4)	026440	000652			BR 50240\$
(3)	026442				50241\$:
2585	026442	000137	025606		JMP 2\$;GO BACK AND TRY IT AGAIN
2586	026446				4\$: LET OUTBUF := #14
(4)	026446	012737	000014	003172	MOV #14,OUTBUF
2587	026454				OUTPUT #OUTBUF, #1
2588	026516				EXIT TST
(3)	026516	104432			TRAP C\$EXIT
(3)	026520	000150			.WORD L10020-
2589					
2590	026522	000000			INSTR: .WORD 0
2591	026524	040504	043126	020125	VFUCL: .ASCIZ /DAVFU CHANNEL SELECTION PAPER CONTROL TEST 7/ <12><12><12>
	026532	044103	047101	042516	
	026540	020114	042523	042514	
	026546	052103	047511	020116	
	026554	040520	042520	020122	
	026562	047503	052116	047522	
	026570	020114	042524	052123	
	026576	033440	005012	000012	
2592					.EVEN
2593	026604	040			CHARSP: .BYTE 40
2594	026605	130			CHARX: .BYTE 130
2595					
2596	026606	356	001	000	VFUDAT: .BYTE 356, 1, 0, 2, 0, 4, 0
	026611	002	000	004	
	026614	000			
2597	026615	010	000	020	.BYTE 10, 0, 20, 0, 40, 0, 0, 1
	026620	000	040	000	
	026623	000	001		
2598	026625	000	002	000	.BYTE 0, 2, 0, 4, 0, 10, 0, 20
	026630	004	000	010	
	026633	000	020		
2599	026635	000	040	000	.BYTE 0, 40, 0, 40, 0, 20, 0, 10
	026640	040	000	020	
	026643	000	010		
2600	026645	000	004	000	.BYTE 0, 4, 0, 2, 0, 1, 40, 0
	026650	002	000	001	
	026653	040	000		
2601	026655	020	000	010	.BYTE 20, 0, 10, 0, 4, 0, 2, 0
	026660	000	004	000	
	026663	002	000		
2602	026665	001	000	357	.BYTE 1, 0, 357
2603					.EVEN
2604	026670				ENDTST
(3)	026670				L10020:
(3)	026670	104401			TRAP C\$ETST
2605					
2606	026672				ENDMOD

2608					.SBTTL DATA TRANSFER PATHS
2609					BGNMOD
2610	026672				:++
2611					:THIS TEST CHECKS THE DATA TRANSFER
2612					:PATHS FROM THE PROCESSOR INTERFACE
2613					:TO THE PRINTER OUTPUT. AN ALTERNATING
2614					:PATTERN OF ONES AND ZEROES CORRESPONDING
2615					:TO AN ALTERNATING STRING OF '*' AND
2616					:'U' CHARACTERS ARE TRANSMITTED ON THE
2617					:FULL 132 COLUMNS. AFTER 16 LINES OF
2618					:THIS PATTERN, THE OUTPUT PATTERN IS
2619					:SWITCHED TO AN ALTERNATING PATTERN
2620					:OF '?' AND 'a' CHARACTERS FOR ANOTHER
2621					:16 LINES.
2622					:--
2623					
2624					
2625	026672				BGNTST 8.
(3)	026672				T8::
2626					:PRINT TEST IDENTIFICATION
2627	026672				OUTPUT #DATPTH,#30.
2628					:PRINT ALTERNATING STRINGS OF CHARACTERS
2629	026734				INCR PATTERN FROM #1 TO #2 BY #1
(4)	026734	012737	000001	027300	MOV #1,PATTERN
(5)	026742	000402			BR 50244\$
(4)	026744				50245\$:
(7)	026744	005237	027300		INC PATTERN
(5)	026750				50244\$:
(5)	026750	023727	027300	000002	CMP PATTERN,#2
(7)	026756	003101			BGT 50246\$
2630	026760				IF PATTERN EQ #1 THEN
(6)	026760	023727	027300	000001	CMP PATTERN,#1
(4)	026766	001004			BNE 50247\$
2631	026770				LET CHAR :B= #'U
(4)	026770	112737	000125	027236	MOVB #'U,CHAR
2632	026776				ELSE
(4)	026776	000403			BR 50250\$
(3)	027000				50247\$:
2633	027000				LET CHAR :B= #'?
(4)	027000	112737	000077	027236	MOVB #'?,CHAR
2634	027006				ENDIF
(4)	027006				50250\$:
2635	027006				LET R4 := #OUTBUF
(4)	027006	012704	003172		MOV #OUTBUF,R4
2636	027012				INCR CCNT FROM #1 TO #66. BY #1
(4)	027012	012737	000001	002316	MOV #1,CCNT
(5)	027020	000402			BR 50251\$
(4)	027022				50252\$:
(7)	027022	005237	002316		INC CCNT
(5)	027026				50251\$:
(5)	027026	023727	002316	000102	CMP CCNT,#66.
(7)	027034	003011			BGT 50253\$
2637	027036				LET (R4)+ :B= CHAR
(4)	027036	113724	027236		MOVB CHAR,(R4)+
2638	027042	105137	027236		COMB CHAR
2639	027046				LET (R4)+ :B= CHAR

```

(4) 027046 113724 027236      MOVB CHAR,(R4)+
2640 027052 105137 027236      COMB CHAR
2641 027056      ENDINC
(4) 027056 000761      BR 50252$
(3) 027060      50253$:
2642 027060      LET (R4)+ :B= #15
(4) 027060 112724 000015      MOVB #15,(R4)+
2643 027064      LET (R4) :B= #12
(4) 027064 112714 000012      MOVB #12,(R4)
2644 027070      INCR LINCNT FROM #1 TO #16. BY #1
(4) 027070 012737 000001 002310      MOV #1,LINCNT
(5) 027076 000402      BR 50254$
(4) 027100      50255$:
(7) 027100 005237 002310      INC LINCNT
(5) 027104      50254$:
(5) 027104 023727 002310 000020      CMP LINCNT,#16.
(7) 027112 003022      BGT 50256$
2645 027114      OUTPUT #OUTBUF, #134.
2646 027156      ENDINC
(4) 027156 000750      BR 50255$
(3) 027160      50256$:
2647 027160      ENDINC
(4) 027160 000671      BR 50245$
(3) 027162      50245$:
2648 027162      IET OUTBUF :B= #14
(4) 027162 112737 000014 003172      MOVB #14,OUTBUF
2649 027170      OUTPUT #OUTBUF, #1
2650 027232      EXIT TST
(3) 027232 104432      TRAP C$EXIT
(3) 027234 000046      .WORD L10021-.
2651      CHAR: .WORD 0
2652 027236 000000      DATPTH: .ASCIZ <14>/DATA TRANSFER PATHS TEST 8/ <12><12><12>
2653 027240 042014 052101 020101
      027246 051124 047101 043123
      027254 051105 050040 052101
      027262 051510 052040 051505
      027270 020124 005070 005012
      027276 000
2654
2655      .EVEN
2656 027300 000000      PATTERN: .WORD 0
2657      .EVEN
2658
2659      .EVEN
2660 027302      ENDTST
(3) 027302      L10021:
(3) 027302 104401      TRAP C$TST
2661
2662 027304      ENDMOD
  
```


2664
 2665 027304
 2666
 2667
 2668
 2669
 2670
 2671
 2672
 2673 027304
 (3) 027304
 2674 027304
 2675
 2676
 2677
 2678 027346
 (4) 027346 012737 000040 003166
 (5) 027354 000402
 (4) 027356
 (7) 027356 005237 003166
 (5) 027362
 (5) 027362 023727 003166 000137
 (7) 027370 003045
 2679 027372
 (4) 027372 012704 003172
 2680 027376
 (4) 027376 012737 000001 002314
 (5) 027404 000402
 (4) 027406
 (7) 027406 005237 002314
 (5) 027412
 (5) 027412 023727 002314 000204
 (7) 027420 003003
 2681 027422
 (4) 027422 113724 003166
 2682 027426
 (4) 027426 000767
 (3) 027430
 2683 027430
 (4) 027430 112724 000012
 2684 027434
 2685 027476 004737 005466
 2686 027502
 (4) 027502 000725
 (3) 027504
 2687
 2688
 2689
 2690
 2691
 2692
 2693
 2694 027504
 (4) 027504 005037 003166
 2695 027510
 (4) 027510 013737 002012 003170

.SBTTL PRINTABLE CHARACTERS
 BGNMOD
 :++
 : THIS TEST WILL PRINT A FULL LINE OF EACH PRINTABLE CHARACTER.
 : BAND TYPE IS CHECKED ON A UNIT BY UNIT BASIS.
 : UNITS WITH 96 CHAR BAND WILL BE SENT THE CHARACTER CODES :
 : 140(8) THRU 176(8).
 :--
 BGNTST 9.
 T9::
 OUTPUT #PRTCHR, #30. ; PRINT TEST ID
 :
 : PRINT ALL UPPER CASE CHARACTERS ON ALL UNITS
 :
 INCR WORK FROM #40 TO #137 BY #1
 MOV #40,WORK
 BR 50257\$
 50260\$: INC WORK
 50257\$: CMP WORK,#137
 BGT 50261\$
 LET R4 := #OUTBUF
 MOV #OUTBUF,R4
 INCR COUNT FROM #1 TO #132. BY #1
 MOV #1,COUNT
 BR 50262\$
 50263\$: INC COUNT
 50262\$: CMP COUNT,#132.
 BGT 50264\$
 LET (R4)+ :B= WORK
 MOVB WORK,(R4)+
 ENDINC
 BR 50263\$
 50264\$: LET (R4)+ :B= #LF
 MOVB #LF,(R4)+
 OUTPUT #OUTBUF,#133.
 JSR PC,QUIET
 ENDINC
 BR 50260\$
 50261\$:
 :
 : NOW DO ALL THE LOWER CASE CHARACTERS ON THOSE UNITS
 : EQUIPPED WITH 96 CHARACTER BANDS.
 :
 : FIRST DETERMIN IF ANY UNITS HAVE 96 CHAR BANDS
 :
 LET WORK := #0 ; COUNTER FOR 96 CHAR UNITS
 CLR WORK
 LET WORK1 := L\$UNIT - #1 ; GET UNIT COUNT
 MOV L\$UNIT,WORK1

```

(6) 027516 005337 003170      DEC      WORK1
2696 027522      INCR LUNIT FROM #0 TO WORK1 BY #1
(4) 027522 005037 002326      CLR      LUNIT
(5) 027526 000402      BR       50265$
(4) 027530      50266$:
(7) 027530 005237 002326      INC      LUNIT
(5) 027534      50265$:
(5) 027534 023737 002326 003170    CMP      LUNIT,WORK1
(7) 027542 003012      BGT      50267$
2697 027544      LET R2 := LUNIT SHIFT 1
(4) 027544 013702 002326      MOV      LUNIT,R2
(7) 027550 006302      ASL      R2
2698 027552      IF #FLAG96 SETIN STATUS(R2) THEN ; IS THIS UNIT 96 CHAR ?
(6) 027552 032762 010000 002524    BIT      #FLAG96,STATUS(R2)
(9) 027560 001402      BEQ      50270$
2699 027562      LET WORK := WORK + #1 ; YES ADD 1 TO COUNT
(6) 027562 005237 003166      INC      WORK
2700 027566      ENDIF
(4) 027566      50270$:
2701 027566      ENDINC
(4) 027566 000760      BR       50266$
(3) 027570      50267$:
2702 027570      IF WORK EQ #0 THEN ; ANY 96 CHAR UNITS ?
(6) 027570 005737 003166      TST      WORK
(9) 027574 001002      BNE      50271$
2703 027576      EXIT TST ; ALL UNITS 64 CHAR...EXIT
(3) 027576 104432      TRAP     C$EXIT
(3) 027600 000330      .WORD   L10022-.
2704 027602      ENDIF
(4) 027602      50271$:
2705      ; SETUP FOR LOWER CASE CHARACTERS DISPLAY
2706      ;
2707 027602      INCR WORK FROM #140 TO #176 BY #1
(4) 027602 012737 000140 003166    MOV      #140,WORK
(5) 027610 000402      BR       50272$
(4) 027612      50273$:
(7) 027612 005237 003166      INC      WORK
(5) 027616      50272$:
(5) 027616 023727 003166 000176    CMP      WORK,#176
(7) 027624 003073      BGT      50274$
2708 027626      LET R4 := #OUTBUF
(4) 027626 012704 003172      MOV      #OUTBUF,R4
2709 027632      INCR COUNT FROM #1 TO #132. BY #1
(4) 027632 012737 000001 002314    MOV      #1,COUNT
(5) 027640 000402      BR       50275$
(4) 027642      50276$:
(7) 027642 005237 002314      INC      COUNT
(5) 027646      50275$:
(5) 027646 023727 002314 000204    CMP      COUNT,#132.
(7) 027654 003003      BGT      50277$
2710 027656      LET (R4)+ :B= WORK
(4) 027656 113724 003166      MOVB    WORK,(R4)+
2711 027662      ENDINC
(4) 027662 000767      BR       50276$
(3) 027664      50277$:
2712 027664      LET (R4)+ :B= #LF
    
```

(4)	027664	112724	000012			MOVB	#LF,(R4)+
2713	027670					LET	WORK1 := L\$UNIT - #1
(4)	027670	013737	002012	003170		MOV	L\$UNIT,WORK1
(6)	027676	005337	003170			DEC	WORK1
2714	027702					INCR	LUNIT FROM #0 TO WORK1 BY #1
(4)	027702	005037	002326			CLR	LUNIT
(5)	027706	000402				BR	50300\$
(4)	027710				50301\$:		
(7)	027710	005237	002326			INC	LUNIT
(5)	027714				50300\$:		
(5)	027714	023737	002326	003170		CMP	LUNIT,WORK1
(7)	027722	003031				BGT	50302\$
2715	027724					LET	R2 := LUNIT SHIFT 1
(4)	027724	013702	002326			MOV	LUNIT,R2
(7)	027730	006302				ASL	R2
2716	027732					IF	#FLAG96 SETIN STATUS(R2) THEN
(6)	027732	032762	010000	002524		BIT	#FLAG96,STATUS(R2)
(9)	027740	001421				BEQ	50303\$
2717	027742					OUTPUT	#OUTBUF,#133.,,LUNIT
2718	030004					ENDIF	
(4)	030004				50303\$:		
2719	030004					ENDINC	
(4)	030004	000741				BR	50301\$
(3)	030006				50302\$:		
2720	030006	004737	005466			JSR	PC,QUIET ; WAIT FOR ALL DONE
2721	030012					ENDINC	
(4)	030012	000677				BR	50273\$
(3)	030014				50274\$:		
2722	030014					LET	OUTBUF :B= #FF
(4)	030014	112737	000014	003172		MOVB	#FF,OUTBUF
2723	030022					OUTPUT	#OUTBUF,#1 ; EXECUTE TOF
2724	030064					EXIT	TST
(5)	030064	104432				TRAP	C\$EXIT
(3)	030066	000042				.WORD	L10022-
2725							
2726	030070	051120	047111	040524		PRTCHR:	.ASCIZ /PRINTABLE CHARACTERS TEST 9/ <12><12><12>
	030076	046102	020105	044103			
	030104	051101	041501	042524			
	030112	051522	052040	051505			
	030120	020124	005071	005012			
	030126	000					
2727		030130				.EVEN	
2728							
2729	030130				ENDTST		
(3)	030130				L10022:		
(3)	030130	104401			TRAP	C\$ETST	
2730							
2731	030132				ENDMOD		
2732							

```

2734 .SBTTL NON-PRINTABLE CHARACTERS
2735
2736 030132 BGNMOD
2737 :++
2738 :THIS TEST CHECKS FOR DETECTION OF ALL NON-PRINTABLE CHARACTERS.
2739 :EACH CHARACTER WILL APPEAR ON THE PRINTER OUTPUT IN THE FORM OF ITS OCTAL
2740 :CODE ACCOMPANIED WITH ITS MNEMONIC.
2741 : 123 OF THE TESTED CODE ARE THEN SENT.
2742 :--
2743
2744 030132 BGNTST 10.
(3) 030132 T10::
2745 :INDICATE TEST CURRENTLY BEING DONE
2746
2747 030132 OUTPUT #NONCHR,#71.
2748 030174 LET R4 := #NONBUF
(4) 030174 012704 031065 MOV #NONBUF,R4
2749 030200 LET WORK1 := #27.
(4) 030200 012737 000033 003170 MOV #27.,WORK1
2750 :
2751 : DO ONE LINE FOR EACH TABLE ENTRY
2752 :
2753 030206 INCR LINCNT FROM #0 TO WORK1 BY #1
(4) 030206 005037 002310 CLR LINCNT
(5) 030212 000402 BR 50304$
(4) 030214 50305$: INC LINCNT
(7) 030214 005237 002310 50304$: CMP LINCNT,WORK1
(5) 030220 023737 002310 003170 BGT 50306$
(7) 030226 003061 LET R3 := #OUTBUF
2754 030230 MOV #OUTBUF,R3
(4) 030230 012703 003172
2755 :
2756 : MOVE CODE AND MNEMONIC TO PRINT BUFFER
2757 :
2758 030234 INCR WORK FROM #1 TO #8. BY #1
(4) 030234 012737 000001 003166 MOV #1,WORK
(5) 030242 000402 BR 50307$
(4) 030244 50310$: INC WORK
(7) 030244 005237 003166 50307$: CMP WORK,#8.
(5) 030250 023727 003166 000010 BGT 50311$
(7) 030256 003002 LET (R3)+ :B= (R4)+
2759 030260 MOVB (R4)+,(R3)+
(4) 030260 112423 ENDDINC
2760 030262 BR 50310$
(4) 030262 000770
(3) 030264 50311$:
2761 :
2762 : PUT 120 BYTES OF CODE INTO PRINT BUFFER
2763 :
2764 :
2765 030264 INCR WORK FROM #1 TO #123. BY #1
(4) 030264 012737 000001 003166 MOV #1,WORK
(5) 030272 000402 BR 50312$
(4) 030274 50313$:

```

```

(7) 030274 005237 003166          INC      WORK
(5) 030300          50312$:      CMP      WORK,#123.
(5) 030300 023727 003166 000173    BGT      50314$
(7) 030306 003002          LET (R3)+ :B= (R4)
2766 030310          MOV      (R4),(R3)+
(4) 030310 111423          ENDINC
2767 030312          BR      50313$
(4) 030312 000770          50314$:
(3) 030314          :
2768          :
2769          : FOLLOWED BY CRLF
2770          :
2771          :
2772 030314          LET (R3)+ :B= #15
(4) 030314 112723 000015          MOV      #15,(R3)+
2773 030320          LET (R3)+ :B= #12
(4) 030320 112723 000012          MOV      #12,(R3)+
2774          :
2775          : PRINT LINE OF OCTAL CODE, MNEMONIC, AND 120 BYTES(NONPRINTABLE CODE)
2776          :
2777 030324          OUTPUT #OUTBUF,#133.
2778 030366          LET R4 := R4 + #1
(6) 030366 005204          INC      R4
2779 030370          ENDINC
(4) 030370 000711          BR      50305$
(3) 030372          50306$:
2780          :
2781          : UNITS WITH 64 CHAR BAND SHOULD STRIP BIT 6 OF DATA
2782          : AND PRINT THE DATA FOR CODES 140(8) THRU 177(8)
2783          : AS IF CODES 100(8) THRU 137(8) WERE RECIEVED.
2784          : **NOTE** DELETE IS PRINTED AS UNDERSCORE '_'
2785          :
2786 030372          LET R3 := #OUTBUF
(4) 030372 012703 003172          MOV      #OUTBUF,R3
2787 030376          INCR R4 FROM #140 TO #177 BY #1
(4) 030376 012704 000140          MOV      #140,R4
(5) 030402 000401          BR      50315$
(4) 030404          50316$:      INC      R4
(7) 030404 005204          50315$:      CMP      R4,#177
(5) 030406 020427 000177          BGT      50317$
(7) 030412 003002          LET (R3)+ :B= R4 ; FILL BUFFER WITH CODES & LF
2788 030414          MOV      R4,(R3)+
(4) 030414 110423          ENDINCR
2789 030416          BR      50316$
(4) 030416 000772          50317$:
(3) 030420          LET (R3)+ :B= #LF
2790 030420          MOV      #LF,(R3)+
(4) 030420 112723 000012          LET WORK := L$UNIT - #1 ; SEND MSG AND BUFFER TO ALL
2791 030424          MOV      L$UNIT,WORK
(4) 030424 013737 002012 003166          DEC      WORK
(6) 030432 005337 003166          INCR LUNIT FROM #0 TO WORK BY #1 ; UNITS WITH 64 CHAR BAND
2792 030436          CLR      LUNIT
(4) 030436 005037 002326          BR      50320$
(5) 030442 000402          50321$:
(4) 030444

```

```

(7) 030444 005237 002326          INC      LUNIT
(5) 030450          50320$: CMP      LUNIT,WORK
(5) 030450 023737 002326 003166  BGT      50322$
(7) 030456 003052          LET R2 := LUNIT SHIFT #1
2793 030460          MOV      LUNIT,R2
(4) 030460 013702 002326          ASL      R2
(7) 030464 006302          IF #FLAG96 NOTSETIN STATUS(R2) THEN
2794 030466          BIT      #FLAG96,STATUS(R2)
(6) 030466 032762 010000 002524  BNE      50323$
(9) 030474 001042          OUTPUT #AUTCON,#61.,,LUNIT
2795 030476          OUTPUT #OUTBUF,#33.,,LUNIT
2796 030540          ENDIF
2797 030602          50323$: ENDINCR
(4) 030602          BR      50321$
2798 030602          50322$: OUTPUT #SKIP3,#4
(4) 030602 000720          EXIT   TST          ;AND EXIT TEST
(3) 030604          TRAP  C$EXIT
2799 030604          .WORD L10023-.
2800 030646          :
(3) 030646 104432          : CHARACTER BUFFER AND TEST HEADER MESSAGE
(3) 030650 000612          :
2801          :
2802          :
2803          :
2804          : NLIST BEX
2805 030652 047516 026516 051120  NONCHR: .ASCII /NON-PRINTABLE CHARACTERS TEST 10/<12>
2806 030713          101 043040 046125  .ASCIZ /A FULL LINE OF EACH CODE WILL BE SENT/<12>
2807 030762 047503 042504 020123  AUTCON: .ASCIZ /CODES 140(8) ..177(8) SHOULD BE CONVERTED TO 100(8)..137(8)/<12><12>
2808 031060 005015 005012 000      SKIP3: .ASCIZ <15><12><12><12>
2809          :
2810 031065          040 030060 020060  NONBUF: .ASCII / 000 NUL/<0>
2811 031076 030040 030460 051440  .ASCII / 001 SOH/<1>
2812 031107          040 030060 020062  .ASCII / 002 STX/<2>
2813 031120 030040 031460 042440  .ASCII / 003 ETX/<3>
2814 031131          040 030060 020064  .ASCII / 004 EOT/<4>
2815 031142 030040 032460 042440  .ASCII / 005 ENQ/<5>
2816 031153          040 030060 020066  .ASCII / 006 ACK/<6>
2817 031164 030040 033460 041040  .ASCII / 007 BEL/<7>
2818 031175          040 030460 020060  .ASCII / 010 BS /<10>
2819 031206 030040 030461 044040  .ASCII / 011 HT /<11>
2820 031217          040 030460 020066  .ASCII / 016 SO /<16>
2821 031230 030040 033461 051440  .ASCII / 017 SI /<17>
2822 031241          040 031060 020060  .ASCII / 020 DLE/<20>
2823 031252 030040 030462 054040  .ASCII / 021 XON/<21>
2824 031263          040 031060 020062  .ASCII / 022 DC2/<22>
2825 031274 030040 031462 054040  .ASCII / 023 XOF/<23>
2826 031305          040 031060 020064  .ASCII / 024 DC4/<24>
2827 031316 030040 032462 047040  .ASCII / 025 NAK/<25>
2828 031327          040 031060 020066  .ASCII / 026 SYN/<26>
2829 031340 030040 033462 042440  .ASCII / 027 ETB/<27>
2830 031351          040 031460 020060  .ASCII / 030 CAN/<30>
2831 031362 030040 030463 042440  .ASCII / 031 EM /<31>
2832 031373          040 031460 020062  .ASCII / 032 SUB/<32>
2833 031404 030040 031463 042440  .ASCII / 033 ESC/<33>
2834 031415          040 031460 020064  .ASCII / 034 FS /<34>
2835 031426 030040 032463 043440  .ASCII / 035 GS /<35>

```

2836	031437	040	031460	020066	.ASCII / 036 RS /<36>
2837	031450	030040	033463	052440	.ASCII / 037 US /<37>
2838		031462			.EVEN
2839					
2840					.LIST BEX
2841	031462				ENDTST
(3)	031462				L10023:
(3)	031462	104401			TRAP C\$ETST
2842					
2843	031464				ENDMOD
2844					

2871 031464
(3) 031464
2872 000014
2873
2874
2875
2876 031464
2877
2878
2879
2880 031526
(6) 031526 005737 002302
(9) 031532 001432
2881 031534
(4) 031534 105037 033143
2882 031540
(4) 031540 112737 000043 033147
2883 031546
(4) 031546 105037 033261
2884 031552
(4) 031552 113737 000043 033266
2885 031560
(4) 031560 105037 033377
2886 031564
(4) 031564 112737 000043 033403
2887 031572
(4) 031572 105037 033521
2888 031576
(4) 031576 112737 000043 033526
2889 031604
(4) 031604 105037 033712
2890 031610
(4) 031610 112737 000043 033717
2891 031616
(4) 031616 000431
(3) 031620
2892 031620
(4) 031620 112737 000043 033143
2893 031626
(4) 031626 105037 033147
2894 031632
(4) 031632 112737 000043 033261
2895 031640
(4) 031640 105037 033266
2896 031644
(4) 031644 112737 000043 033377
2897 031652
(4) 031652 105037 033403
2898 031656
(4) 031656 112737 000043 033521
2899 031664
(4) 031664 105037 033526
2900 031670
(4) 031670 112737 000043 033712
2901 031676
(4) 031676 105037 033717

BGNTST 11.
T11::
TOF = 014
:
: PRINT TEST IDENTIFICATION ON ALL UNITS
:
: OUTPUT #BNDTST,#23.
:
: SETUP PATTERNS FOR EUROPEAN OR AMERICAN PRINTERS
:
IF USA NE #0 THEN ; AMERICAN, PRINT SHARP SIGN '#'
TST USA
BEQ 50324\$
LET BP64Q2+18. :B= #0
CLRB BP64Q2+18.
LET BP64Q2+22. :B= #43
MOVB #43,BP64Q2+22.
LET BP64Q3+35. :B= #0
CLRB BP64Q3+35.
LET BP64Q3+40. :B= 43
MOVB 43,BP64Q3+40.
LET BP64Q4+53. :B= #0
CLRB BP64Q4+53.
LET BP64Q4+57. :B= #43
MOVB #43,BP64Q4+57.
LET BP96Q2+13. :B= #0
CLRB BP96Q2+13.
LET BP96Q2+18. :B= #43
MOVB #43,BP96Q2+18.
LET BP96Q4+13. :B= #0
CLRB BP96Q4+13.
LET BP96Q4+18. :B= #43
MOVB #43,BP96Q4+18.
ELSE ; EUROPEAN, PRINT POUND STERLING SIGN
BR 50325\$
50324\$:
LET BP64Q2+18. :B= #43
MOVB #43,BP64Q2+18.
LET BP64Q2+22. :B= #0
CLRB BP64Q2+22.
LET BP64Q3+35. :B= #43
MOVB #43,BP64Q3+35.
LET BP64Q3+40. :B= #0
CLRB BP64Q3+40.
LET BP64Q4+53. :B= #43
MOVB #43,BP64Q4+53.
LET BP64Q4+57. :B= #0
CLRB BP64Q4+57.
LET BP96Q2+13. :B= #43
MOVB #43,BP96Q2+13.
LET BP96Q2+18. :B= #0
CLRB BP96Q2+18.
LET BP96Q4+13. :B= #43
MOVB #43,BP96Q4+13.
LET BP96Q4+18. :B= #0
CLRB BP96Q4+18.

2902	031702				ENDIF
(4)	031702				50325\$:
2903					:
2904					: PRINT PROPER BAND IDENTIFICATION MSG. ON EACH PRINTER
2905					:
2906	031702				LET R1 := L\$UNIT - #1
(4)	031702	013701	002012		MOV L\$UNIT,R1
(6)	031706	005301			DEC R1
2907	031710				INCR LUNIT FROM #0 TO R1 BY #1
(4)	031710	005037	002326		CLR LUNIT
(5)	031714	000402			BR 50326\$
(4)	031716				50327\$:
(7)	031716	005237	002326		INC LUNIT
(5)	031722				50326\$:
(5)	031722	023701	002326		CMP LUNIT,R1
(7)	031726	003135			BGT 50330\$
2908	031730				LET R2 := LUNIT SHIFT 1
(4)	031730	013702	002326		MOV LUNIT,R2
(7)	031734	006302			ASL R2
2909	031736				IF #FLAG26 NOTSETIN STATUS(R2) AND #FLAG27 NOTSETIN STATUS(R2) THEN
(6)	031736	032762	001000	002524	BIT #FLAG26,STATUS(R2)
(9)	031744	001025			BNE 50331\$
(6)	031746	032762	002000	002524	BIT #FLAG27,STATUS(R2)
(9)	031754	001021			BNE 50331\$
2910	031756				OUTPUT #BPID25,#6,,LUNIT ; PRINTER IS LP25
2911	032020				ENDIF
(4)	032020				50331\$:
2912	032020				IF #FLAG26 SETIN STATUS(R2) AND #FLAG27 NOTSETIN STATUS(R2) THEN
(6)	032020	032762	001000	002524	BIT #FLAG26,STATUS(R2)
(9)	032026	001425			BEQ 50332\$
(6)	032030	032762	002000	002524	BIT #FLAG27,STATUS(R2)
(9)	032036	001021			BNE 50332\$
2913	032040				OUTPUT #BPID26,#6,,LUNIT ; PRINTER IS LP26
2914	032102				ENDIF
(4)	032102				50332\$:
2915	032102				IF #FLAG96 SETIN STATUS(R2) THEN
(6)	032102	032762	010000	002524	BIT #FLAG96,STATUS(R2)
(9)	032110	001422			BEQ 50333\$
2916	032112				OUTPUT #BP96ID,#22,,LUNIT ; 96 CHAR BAND
2917	032154				ELSE
(4)	032154	000421			BR 50334\$
(3)	032156				50333\$:
2918	032156				OUTPUT #BP64ID,#22,,LUNIT ; 64 CHAR BAND
2919	032220				ENDIF
(4)	032220				50334\$:
2920	032220				ENDINC
(4)	032220	000636			BR 50327\$
(3)	032222				50330\$:
2921					:
2922					: NOW PRINT 2_LINE PATTERN 15. TIMES, WITH BLANK LINE BETWEEN PATTERNS
2923					:
2924	032222				LET LINCNT := #14.
(4)	032222	012737	000016	002310	MOV #14.,LINCNT
2925	032230				2\$:
2926	032230				INCR LUNIT FROM #0 TO R1 BY #1 ; PRINT QUADRANTS 1 & 2
(4)	032230	005037	002326		CLR LUNIT

```

(5) 032234 000402
(4) 032236
(7) 032236 005237 002326
(5) 032242
(5) 032242 023701 002326
(7) 032246 003101
2927 032250
(4) 032250 013702 002326
(7) 032254 006302
2928 032256
(6) 032256 032762 010000 002524
(9) 032264 001022
2929 032266
2930 032330
(4) 032330 000447
(3) 032332
2931 032332
(6) 032332 032762 003000 002524
(9) 032340 001022
2932 032342
2933 032404
(4) 032404 000421
(3) 032406
2934 032406
2935 032450
(4) 032450
2936 032450
(4) 032450
2937 032450
(4) 032450 000672
(3) 032452
2938
2939 032452
(4) 032452 005037 002326
(5) 032456 000402
(4) 032460
(7) 032460 005237 002326
(5) 032464
(5) 032464 023701 002326
(7) 032470 003053
2940 032472
(4) 032472 013702 002326
(7) 032476 006302
2941 032500
(6) 032500 032762 010000 002524
(9) 032506 001022
2942 032510
2943 032552
(4) 032552 000421
(3) 032554
2944 032554
2945 032616
(4) 032616
2946 032616
(4) 032616 000720
(3) 032620
    BR 50335$
    50336$:
    INC LUNIT
    50335$:
    CMP LUNIT,R1
    BGT 50337$
    LET R2 := LUNIT SHIFT 1 ; INDEX INTO STATUS TABLES
    MOV LUNIT,R2
    ASL R2
    IF #FLAG96 NOTSET IN STATUS(R2) THEN
    BIT #FLAG96,STATUS(R2)
    BNE 50340$
    OUTPUTI #BP64Q1,#121,,,LUNIT ; 64 CHAR PATTERN
    ELSE
    50341$:
    BR
    50340$:
    IF #FLAG26!FLAG27 NOTSET IN STATUS(R2) THEN
    BIT #FLAG26!FLAG27,STATUS(R2)
    BNE 50342$
    OUTPUTI #BP96Q3,#121,,,LUNIT ; LP25 96 CHAR PATTERN
    ELSE
    50343$:
    BR
    50343$:
    OUTPUTI #BP96Q1,#121,,,LUNIT ; LP26 96 CHAR PATTERN
    ENDIF
    50341$:
    ENDIF
    ENDINC
    BR 50336$
    50337$:
    ; NOW DO QUADRANTS 3 & 4
    INCR LUNIT FROM #0 TO R1 BY #1 ; REPEAT FOR ALL UNITS
    CLR LUNIT
    BR 50344$
    50345$:
    INC LUNIT
    50344$:
    CMP LUNIT,R1
    BGT 50346$
    LET R2 := LUNIT SHIFT 1 ; INDEX INTO STATUS TABLES
    MOV LUNIT,R2
    ASL R2
    IF #FLAG96 NOTSET IN STATUS(R2) THEN
    BIT #FLAG96,STATUS(R2)
    BNE 50347$
    OUTPUTI #BP64Q3,#122,,,LUNIT ; 64 CHAR PATTERN
    ELSE
    50350$:
    BR
    50347$:
    OUTPUTI #BP96Q3,#122,,,LUNIT ; 96 CHAR PATTERN
    ENDIF
    50350$:
    ENDINC
    BR 50345$
    50346$:
    
```

2947	032620				LET LINCNT := LINCNT - #1
(6)	032620	005337	002310		DEC LINCNT
2948	032624	001402			BEQ 3\$
2949	032626	000137	032230		JMP 2\$
2950	032632				3\$:
2951					:
2952					: DO TOF THEN EXIT
2953					:
2954	032632				LET OUTBUF :B= #TOF
(4)	032632	112737	000014	003172	MOVB #TOF,OUTBUF
2955	032640				OUTPUT #OUTBUF,#1
2956	032702				EXIT TST
(3)	032702	104432			TRAP C\$EXIT
(3)	032704	001070			.WORD L10024-
2957	032706	040502	042116	050040	BNDTST: .ASCII /BAND PATTERN TEST_11 /
	032714	052101	042524	047122	
	032722	052040	051505	057524	
	032730	030461	020040	040	
2958	032735	114	031120	020065	BP1D25: .ASCII /LP25 /
	032742	040			
2959	032743	114	031120	020066	BP1D26: .ASCII /LP26 /
	032750	040			
2960	032751	066	020064	044103	BP64ID: .ASCII /64 CHAR BAND PATTERN/<12><12>
	032756	051101	041040	047101	
	032764	020104	040520	052124	
	032772	051105	005116	012	
2961	032777	071	020066	044103	BP96ID: .ASCII /96 CHAR BAND PATTERN/<12><12>
	033004	051101	041040	047101	
	033012	020104	040520	052124	
	033020	051105	005116	012	
2962					
2963					: 64 CHAR BAND PATTERN LP25 & LP26
2964					:
2965	033025	040	020040	020040	BP64Q1: .ASCII / /
	033032	020040	040		
2966	033035	101	042502	042103	.ASCII /ABECDTFG0HIJ1KL2MN3OP4QRS5/
	033042	043124	030107	044510	
	033050	030512	046113	046462	
	033056	031516	050117	050464	
	033064	051522	065		
2967	033067	125	033126	054127	.ASCII /UV6WX7YZ8_+%98)*(:,/<57>/!\$-;><./
	033074	054467	034132	025537	
	033102	034445	024446	024052	
	033110	026072	022057	035455	
	033116	036076	056		
2968					
2969	033121	040	020040	020040	BP64Q2: .ASCII / /
	033126	020040	040		
2970	033131	077	042500	055535	.ASCII /?@E][T\'\'C^#=#1!#2'A3BC4DFG5/
	033136	056124	030042	021536	
	033144	030475	021441	023462	
	033152	031501	041502	042064	
	033160	043506	065		
2971	033163	110	033111	045512	.ASCII /HI6JK7LM8NOP9QR*SU,VW-XYZ./<12>
	033170	046067	034115	047516	
	033176	034520	051121	051452	

	033204	026125	053526	054055	
2972	033212	055131	005056		
2973	033216	020040	020040	020040	BP64Q3: .ASCII / /
	033224	020040			
2974	033226	025537	022505	052046	.ASCII /_+EX&T)(0:/<57>/\$1;>2<?3@]4[\`5/
	033234	024051	035060	022057	
	033242	035461	031076	037474	
	033250	040063	032135	056133	
	033256	032442			
2975	033260	021536	036466	033441	.ASCII /^#6=!7#`8ABC9DF*GH,IJ-KLM./
	033266	023443	040470	041502	
	033274	042071	025106	044107	
	033302	044454	026512	046113	
	033310	027115			
2976					
2977	033312	020040	020040	020040	BP64Q4: .ASCII / /
	033320	020040			
2978	033322	047516	050105	052121	.ASCII /NOEPQTRSOUVW1XY2Z_3+%4&)(5/
	033330	051522	052460	053526	
	033336	054061	031131	057532	
	033344	025463	032045	024446	
	033352	032450			
2979	033354	027472	022066	033473	.ASCII _:/6\$;7><8?@]9[*'^,##=-!#'.<12><12>
	033362	036076	037470	056500	
	033370	055471	025134	057042	
	033376	021454	026475	021441	
	033404	027047	005012		
2980					
2981					: 96 CHAR BAND LP25 = 03..04 LP26 = 01..04
2982					: BP96Q1: .ASCII / /
2983	033410	020040	020040	020040	
	033416	020040			
2984	033420	041101	042103	042460	.ASCII /ABCDEFG1HIJ2KLMN3OPQ4RST5/
	033426	043506	044061	045111	
	033434	045462	046514	031516	
	033442	050117	032121	051522	
	033450	032524			
2985	033452	053125	054127	054466	.ASCII (UVWX6YZ_7\$%&8)(:/<57>/9+;>/
	033460	057532	022067	023045	
	033466	024470	035050	034457	
	033474	035453	076		
2986	033477	145			.BYTE 145
2987	033500	037474	100		.ASCII /<?@/
2988	033503	164			.BYTE 164
2989					
2990	033504	020040	020040	020040	BP96Q2: .ASCII / /
	033512	020040			
2991	033514	055535	021134	021454	.ASCII /][\` ,#/
2992	033522	174			.BYTE 174
2993	033523	075	020452	023443	.ASCII /=*:#'-/
	033530	055			
2994	033531	175	173	176	.BYTE 175,173,176,136,56,177,140,141,60,142,143,144,61
	033534	136	056	177	
	033537	140	141	060	
	033542	142	143	144	

2995	033545	061							
	033546	146	147	150	.BYTE	146,147,150,151,62,152,153,154,63,155,156			
	033551	151	062	152					
	033554	153	154	063					
	033557	155	156						
2996	033561	157	064	160	.BYTE	157,64,160,161,162,163,65,165,166,167,66			
	033564	161	162	163					
	033567	065	165	166					
	033572	167	066						
2997	033574	170	171	172	.BYTE	170,171,172,67,12			
	033577	067	012						
2998									
2999	033601	040	020040	020040	BP96Q3:	.ASCII / /			
	033606	020040	040						
3000	033611	101	041502	034104	.ASCII	/ABCDEFGHIJ/			
	033616	043105	034507	044510					
	033624	112							
3001	033625	145			.BYTE	145			
3002	033626	046113	047115		.ASCII	/KLMN/			
3003	033632	164			.BYTE	164			
3004	033633	117	050520	051054	.ASCII	/OPQ,RST*/			
	033640	052123	052						
3005	033643	125	053526	026530	.ASCII	/UVWX-YZ_.\$%&0)(: /<57>/1+;>2<?@3/			
	033650	055131	027137	022444					
	033656	030046	024051	027472					
	033664	025461	037073	036062					
	033672	040077	063						
3006									
3007	033675	040	020040	020040	BP96Q4:	.ASCII / /			
	033702	020040	040						
3008	033705	135	056133	032042	.ASCII	/][\'4#/			
	033712	043							
3009	033713	174			.BYTE	174			
3010	033714	032475	021441	033047	.ASCII	/=5!#*6/			
3011	033722	175	173	176	.BYTE	175,173,176,136,67,177,140,141,70,142,143,144,71			
	033725	136	067	177					
	033730	140	141	070					
	033733	142	143	144					
	033736	071							
3012	033737	146	147	150	.BYTE	146,147,150,151,145,152,153,154,164,155,156,157			
	033742	151	145	152					
	033745	153	154	164					
	033750	155	156	157					
3013	033753	054	160	161	.BYTE	54,160,161,162,163,52,165,166,167,55,170			
	033756	162	163	052					
	033761	165	166	167					
	033764	055	170						
3014	033766	171	172	056	.BYTE	171,172,56,12,12			
	033771	012	012						
3015									
3016		033774			.EVEN				
3017	033774				ENDTST				
(3)	033774				L10024:				
(3)	033774	104401			TRAP	CSETST			
3018	033776				ENDMOD				

```

3020 .SBTTL SPURIOUS HAMMER FIRING
3021
3022 033776 BGNMOD
3023
3024 :++
3025 :THE PURPOSE OF THIS TEST IS TO DETECT SPURIOUS HAMMER FIRINGS AND DEFECTIVE
3026 :HAMMER DRIVERS DURING THE OPERATION OF THE LINE PRINTER. THE PROGRAM
3027 :PRODUCES A LEFT WEDGE PATTERN CONSISTING OF 132 LINES OF PRINT WITH EACH
3028 :LINE BEGINNING WITH A "?" CHARACTER. ANY POINT OUTSIDE THE WEDGE
3029 :BOUNDARIES IS CAUSED BY HAMMER MISFIRES OR BY HAMMER BOUNCE.
3030 :--
3031
3032 033776 BGNTST 12.
(3) 033776 T12::
3033
3034 ;PRINT THE TEST HEADER
3035
3036 033776 OUTPUT #HAMFIR,#33.
3037
3038 ;OUTPUT THE ACTUAL WEDGE AT THIS POINT
3039
3040 034040 INCR WORK FROM #1 TO #132. BY #1 ;NUMBER OF LINES TO OUTPUT
(4) 034040 012737 000001 003166 MOV #1,WORK
(5) 034046 000402 BR 50351$
(4) 034050 50352$:
(7) 034050 005237 003166 INC WORK
(5) 034054 50351$:
(5) 034054 023727 003166 000204 CMP WORK,#132.
(7) 034062 003123 BGT 50353$
3041 ;ALSO NUMBER OF PRINTING CHARACTERS
3042
3043 034064 LET R4 := #OUTBUF ;OUTPUT BUFFER POINTER
(4) 034064 012704 003172 MOV #OUTBUF,R4
3044 034070 LET SPCCNT := #132. - WORK ;NUMBER OF SPACES TO FILL IN
(4) 034070 012737 000204 034400 MOV #132.,SPCCNT
(6) 034076 163737 003166 034400 SUB WORK,SPCCNT
3045
3046 ;FILL THE OUTPUT BUFFER WITH THE REQUIRED NUMBER OF SPACES
3047
3048 034104 WHILE SPCCNT NE #0 DO
(4) 034104 50354$:
(6) 034104 005737 034400 TST SPCCNT
(9) 034110 001405 BEQ 50355$
3049 034112 LET (R4)+ :B= #40 ;SPACE FILL
(4) 034112 112724 000040 MOVB #40,(R4)+
3050 034116 LET SPCCNT := SPCCNT - #1 ;UPDATE FILLER COUNTER
(6) 034116 005337 034400 DEC SPCCNT
3051 034122 ENDDO
(4) 034122 000770 BR 50354$
(3) 034124 50355$:
3052 034124 LET CCNT := #0
(4) 034124 005037 002316 CLR CCNT
3053 034130 LET CHRGEN := #77 ;FIRST CHARACTER A "?"
(4) 034130 012737 000077 002322 MOV #77,CHRGEN
3054 034136 LET STRCNT := #33. ;# OF CHARACTERS IN GROUP
(4) 034136 012737 000041 002320 MOV #33.,STRCNT
  
```

```

3055 034144          WHILE CCNT LT WORK DO          ;NOW FILL IN REST OF BUFFER
(4) 034144          50356$:
(6) 034144 023737 002316 003166      CMP      CCNT,WORK
(9) 034152 002022          BGE      50357$
3056 034154          IF STRCNT EQ #0 THEN
(6) 034154 005737 002320      TST      STRCNT
(9) 034160 001006          BNE      50360$
3057
3058          ;RESET GROUP POINTERS AND COUNTERS
3059
3060 034162          LET STRCNT := #33.
(4) 034162 012737 000041 002320      MOV      #33,STRCNT
3061 034170          LET CHRGEN := #77
(4) 034170 012737 000077 002322      MOV      #77,CHRGEN
3062 034176          ENDF
(4) 034176          50360$:
3063 034176          LET (R4)+ :B= CHRGEN
(4) 034176 113724 002322      MOV      CHRGEN,(R4)+
3064 034202          LET CHRGEN := CHRGEN + #1
(6) 034202 005237 002322      INC      CHRGEN
3065 034206          LET CCNT := CCNT + #1
(6) 034206 005237 002316      INC      CCNT
3066 034212          LET STRCNT := STRCNT - #1          ;UPDATE POINTERS AND COUNTERS
(6) 034212 005337 002320      LET      STRCNT
3067 034216          ENDDO
(4) 034216 000752          BR      50356$
(3) 034220          50357$:
3068
3069          ;NOW SET UP LINE TERMINATOR AND OUTPUT THE LINE.
3070
3071 034220          LET (R4)+ :B= #12
(4) 034220 112724 000012      MOV      #12,(R4)+
3072          ;OUTPUT THE LINE
3073
3074 034224          OUTPUT #OUTBUF,#132.          ; SEND THE DATA, NO LF YET
3075 034266          OUTPUT #OUTBUF+132.,#1          ; THIS MAKES SURE OUTPUT IS SENT
3076          ; BEFORE CHANGING OUTBUF DATA !
3077
3078 034330          ENDINC
(4) 034330 000647          BR      50352$
(3) 034332          50353$:
3079
3080 034332          OUTPUT #SKIP3,#4
3081 034374          EXIT TST
(3) 034374 104432          TRAP    C$EXIT
(3) 034376 000046          .WORD  L10025-.
3082
3083          ;COUNTERS, POINTERS, TEXT BUFFER, AND HEADER FOR TEST PRINTOUT
3084
3085 034400 000000          SPCCNT: .WORD 0
3086
3087          ;TEST HEADER MESSAGE
3088
3089 034402 050123 051125 047511  HAMFIR: .ASCII /SPURIOUS HAMMER FIRING TEST 12/<12><12><12>
      034410 051525 044040 046501
      034416 042515 020122 044506
  
```


034424 044522 043516 052040
034432 051505 020124 031061
034440 005012 000012

3090
3091
3092
3093
3094
3095
(3)
(3)
3096
3097

034444
034444
034444 104401
034446

;
.EVEN
ENDTST
L10025: TRAP C\$ETST
ENDMOD

3099
 3100
 3101 034446
 3102
 3103
 3104
 3105
 3106
 3107
 3108
 3109
 3110
 3111
 3112
 3113
 3114
 3115
 3116 034446
 (3) 034446
 3117
 3118 034446
 3119 034510
 (4) 034510 012737 000020 002314
 3120 034516
 3121 034516
 (4) 034516 012705 035512
 3122 034522
 (4) 034522
 (6) 034522 005715
 (9) 034524 001421
 3123 034526
 3124 034566
 (4) 034566 000755
 (3) 034570
 3125 034570
 (4) 034570 112737 000012 003172
 3126 034576
 3127
 3128 034640
 (4) 034640 012705 035546
 3129 034644
 (4) 034644
 (6) 034644 005715
 (9) 034646 001421
 3130 034650
 3131 034710
 (4) 034710 000755
 (3) 034712
 3132 034712
 3133
 3134 034754
 (4) 034754 012737 000016 002310
 (5) 034762 000402
 (4) 034764
 (7) 034764 005337 002310
 (5) 034770

```
.SBTTL PRINT CONTROL
BGNMOD
:++
:THIS TEST CHECKS THE PRINT CONTROL BY SENDING MORE THAN 132 CHARACTERS
:BEFORE SENDING A PRINT COMMAND. ALL CHARACTERS IN EXCESS OF 132 CHARACTERS
:SHOULD BE DISREGARDED.
:THREE LINES ARE PRINTED PER ITERATION, THESE LINES WILL IDENTIFY THE
: COLUMN NUMBERS ACROSS THE PAGE. EXAMPLE :
:
:      0      0      0.....          1
:      1      2      3.....          3
:123456789012345678901234567890..... 012
:
: NOTICE THAT THE PRINTOUT SHOULD IDENTIFY 132 COLUMNS ACROSS THE PAGE.
:
: THIS OUTPUT IS REPEATED 16 TIMES.
:--
BGNTST 13.
T13::
:PRINT TEST IDENTIFICATION
OUTPUT #PRTCTL, #56.
LET COUNT := #16.
      MOV      #16.,CGUNT
1$:
LET R5 := #TABLE1
      MOV      #TABLE1,R5
WHILE (R5) NE #0 DO
50361$:
      TST      (R5)
      BEQ      50362$
      OUTPUT (R5)+,#10.
ENDDO
      BR      50361$
50362$:
LET OUTBUF :B= #12
      MOVB     #12,OUTBUF
OUTPUT #OUTBUF,#1

LET R5 := #TABLE2
      MOV      #TABLE2,R5
WHILE (R5) NE #0 DO
50363$:
      TST      (R5)
      BEQ      50364$
      OUTPUT (R5)+,#10.
ENDDO
      BR      50363$
50364$:
OUTPUT #OUTBUF,#1

DECR LINCNT FROM #14. TO #1 BY #1
      MOV      #14.,LINCNT
      BR      50365$
50366$:
      DEC      LINCNT
50365$:
```

(5)	034770	023727	002310	000001						
(7)	034776	002422								
3135	035000									
3136	035042									
(4)	035042	000750								
(3)	035044									
3137	035044									
3138	035106									
3139	035150									
(6)	035150	005337	002314							
3140	035154									
(6)	035154	005737	002314							
(9)	035160	003402								
3141	035162	000137	034516							
3142	035166									
(4)	035166									
3143	035166									
(4)	035166	012737	000014	003172						
3144	035174									
3145	035236									
(3)	035236	104432								
(3)	035240	000342								
3146										
3147	035242	051120	047111	020124						
	035250	047503	052116	047522						
	035256	020114	042524	052123						
	035264	030440	005063							
3148	035270	044123	052517	042114						
	035276	051440	047510	020127						
	035304	031461	020062	047503						
	035312	052514	047115	020123						
	035320	051120	047111	042524						
	035326	005104	006412	000						
3149										
3150	035333	040	020040	020040	X0:	.ASCII	/		0/	
	035340	020040	020040	060						
3151	035345	040	020040	020040	X1:	.ASCII	/		1/	
	035352	020040	020040	061						
3152	035357	040	020040	020040	X2:	.ASCII	/		2/	
	035364	020040	020040	062						
3153	035371	040	020040	020040	X3:	.ASCII	/		3/	
	035376	020040	020040	063						
3154	035403	040	020040	020040	X4:	.ASCII	/		4/	
	035410	020040	020040	064						
3155	035415	040	020040	020040	X5:	.ASCII	/		5/	
	035422	020040	020040	065						
3156	035427	040	020040	020040	X6:	.ASCII	/		6/	
	035434	020040	020040	066						
3157	035441	040	020040	020040	X7:	.ASCII	/		7/	
	035446	020040	020040	067						
3158	035453	040	020040	020040	X8:	.ASCII	/		8/	
	035460	020040	020040	070						
3159	035465	040	020040	020040	X9:	.ASCII	/		9/	
	035472	020040	020040	071						
3160										
3161	035477	061	031462	032464	X11:	.ASCII	/1234567890/			

PRTCTL: .ASCII /PRINT CONTROL TEST 13/ <12>

.ASCIZ /SHOULD SHOW 132 COLUMNS PRINTED/<12><12><15>

```
3162 035504 033466 034470 060
3163
3164 035512 035333 035333 035333 .EVEN
      035520 035333 035333 035333 TABLE1: .WORD X0,X0,X0,X0,X0,X0,X0,X0,X1,X1,X1,X1,0
      035526 035333 035333 035333
      035534 035345 035345 035345
      035542 035345 000000
3165 035546 035345 035357 035371 TABLE2: .WORD X1,X2,X3,X4,X5,X6,X7,X8,X9,X0,X1,X2,X3,0
      035554 035403 035415 035427
      035562 035441 035453 035465
      035570 035333 035345 035357
      035576 035371 000000
3166
3167 .EVEN
3168 035602 ENDTST
      (3) 035602 L10026:
      (3) 035602 104401 TRAP C$ETST
3169 035604 ENDMOD
```

3171					.SBTTL CRITICAL PATH
3172	035604				BGNMOD
3173	035604				STARS
(2)					::*****
3174					::++
3175					::THIS TEST ATTAINS THE HIGHEST POSSIBLE PRINTING SPEED BY SELECTING
3176					::A DATA PATTERN WHICH EXERCISES THE PRINTER AT THE MAXIMUM DUTY CYCLE OF
3177					::THE HAMMERS,THE TIMING LOGIC, AND THE POWER SUPPLY. A TOTAL OF 32 LINES
3178					::LINES OF A WORST CASE PATTERN ARE PRINTED.
3179					::
3180					::
3181	035604				STARS
(2)					::*****
3182					::
3183					::--
3184	035604				BGNTST 14.
(3)	035604				T14::
3185					::
3186	035604				OUTPUT #CRTPTH,#24.
3187	035646				LET WORK := L\$UNIT - #1
(4)	035646	013737	002012	003166	MOV L\$UNIT,WORK
(6)	035654	005337	003166		DEC WORK
3188	035660				INCR LUNIT FROM #0 TO WORK BY #1
(4)	035660	005037	002326		CLR LUNIT
(5)	035664	000402			BR 50371\$
(4)	035666				50372\$:
(7)	035666	005237	002326		INC LUNIT
(5)	035672				50371\$:
(5)	035672	023737	002326	003166	CMP LUNIT,WORK
(7)	035700	003143			BGT 50373\$
3189	035702				LET R2 := LUNIT SHIFT #1
(4)	035702	013702	002326		MOV LUNIT,R2
(7)	035706	006302			ASL R2
3190	035710				IF #FLAG26 NOTSETIN STATUS(R2) AND #FLAG27 NOTSETIN STATUS(R2) THEN
(6)	035710	032762	001000	002524	BIT #FLAG26,STATUS(R2)
(9)	035716	001054			BNE 50374\$
(6)	035720	032762	002000	002524	BIT #FLAG27,STATUS(R2)
(9)	035726	001050			BNE 50374\$
3191					: UNIT IS AN LP25
3192	035730				IF #FLAG96 NOTSETIN STATUS(R2) THEN
(6)	035730	032762	010000	002524	BIT #FLAG96,STATUS(R2)
(9)	035736	001022			BNE 50375\$
3193	035740				OUTPUT #TAB64,#110...,LUNIT,#32.
3194	036002				ELSE
(4)	036002	000421			BR 50376\$
(3)	036004				50375\$:
3195	036004				OUTPUT #TAB96,#132...,LUNIT,#32.
3196	036046				ENDIF
(4)	036046				50376\$:
3197	036046				ELSE
(4)	036046	000457			BR 50377\$
(3)	036050				50374\$:
3198	036050				IF #FLAG26 SETIN STATUS(R2) AND #FLAG27 NOTSETIN STATUS(R2) THEN
(6)	036050	032762	001000	002524	BIT #FLAG26,STATUS(R2)
(9)	036056	001453			BEQ 50400\$
(6)	036060	032762	002000	002524	BIT #FLAG27,STATUS(R2)

```

(9) 036066 001047          BNE 50400$
3199          ; UNIT IS AN LP26
3200 036070          IF #FLAG96 NOTSETIN STATUS(R2) THEN
(6) 036070 032762 010000 002524 BIT #FLAG96,STATUS(R2)
(9) 036076 001022          BNE 50401$
3201 036100          OUTPUTI #T2664,#133.,,LUNIT,#32.
3202 036142          ELSE
(4) 036142 000421          BR 50402$
(3) 036144          50401$:
3203 036144          OUTPUTI #T2696,#133.,,LUNIT,#32.
3204 036206          ENDIF
(4) 036206          50402$:
3205 036206          ENDIF
(4) 036206          50400$:
3206 036206          ENDIF
(4) 036206          50377$:
3207 036206          ENDINC
(4) 036206 000627          BR 50372$
(3) 036210          50373$:
3208 036210          LET OUTBUF :B= #FF ; DO A FORM FEED
(4) 036210 112737 000014 003172 MOVB #FF,OUTBUF
3209 036216          OUTPUT #OUTBUF,#1
3210
3211 036260          ;EXIT TST
(3) 036260 104432          TRAP C$EXIT
(3) 036262 001022          .WORD L10027-.
3212
3213 036264 051103 052111 041511 ;CRTPH: .ASCIZ /CRITICAL PATH TEST 14/<12><12><12>
036272 046101 050040 052101
036300 020110 042524 052123
036306 030440 005064 005012
036314 000
3214          .EVEN
3215          ;64 CHARACTER BAND PATTERN
3216          ;
3217          ;
3218 036316 101 064 105 TAB64: .BYTE 101,064,105,122,104,065,106,126,060,127,111
036321 122 104 065
036324 106 126 060
036327 127 111
3219 036331 067 061 132 .BYTE 067,061,132,114,137,115,045,060,127,111,067
036334 114 137 115
036337 045 060 127
036342 111 067
3220 036344 061 132 114 .BYTE 061,132,114,137,115,045,063,046,120,052,121
036347 137 115 045
036352 063 046 120
036355 052 121
3221 036357 072 123 057 .BYTE 072,123,057,115,045,063,046,120,052,121,072
036362 115 045 063
036365 046 120 052
036370 121 072
3222 036372 123 057 125 .BYTE 123,057,125,055,066,076,130,056,131,100,123
036375 055 066 076
036400 130 056 131
036403 100 123
    
```

3223	036405	057	125	055	.BYTE	057,125,055,066,076,130,056,131,100,070,042
	036410	066	076	130		
	036413	056	131	100		
	036416	070	042			
3224	036420	053	124	071	.BYTE	053,124,071,042,051,136,131,100,070,135,053
	036423	042	051	136		
	036426	131	100	070		
	036431	135	053			
3225	036433	124	071	042	.BYTE	124,071,042,051,136,050,075,054,041,044,062
	036436	051	136	050		
	036441	075	054	041		
	036444	044	062			
3226	036446	073	101	051	.BYTE	073,101,051,136,050,075,054,041,044,062,073
	036451	136	050	075		
	036454	054	041	044		
	036457	062	073			
3227	036461	101	074	102	.BYTE	101,074,102,077,064,105,106,133,065,012,012
	036464	077	064	105		
	036467	106	133	065		
	036472	012	012			
3228						
3229						
3230						
3231						
3232						
3233						
3234						
3235	036474	101	064	103		
	036477	123	060	065		
	036502	106	126	061		
	036505	130	111			
3236	036507	131	062	137	.BYTE	131,062,137,114,044,116,046,061,130,111,131
	036512	114	044	116		
	036515	046	061	130		
	036520	111	131			
3237	036522	062	137	114	.BYTE	062,137,114,044,116,046,117,051,121,072,122
	036525	044	116	046		
	036530	117	051	121		
	036533	072	122			
3238	036535	071	124	073	.BYTE	071,124,073,116,046,117,051,121,072,122,071
	036540	116	046	117		
	036543	051	121	072		
	036546	122	071			
3239	036550	124	073	125	.BYTE	124,073,125,145,127,077,066,136,132,133,124
	036553	145	127	077		
	036556	066	136	132		
	036561	133	124			
3240	036563	073	125	145	.BYTE	073,125,145,127,077,066,136,132,133,067,042
	036566	127	077	066		
	036571	136	132	133		
	036574	067	042			
3241	036576	045	040	070	.BYTE	045,040,070,075,050,041,132,133,067,042,045
	036601	075	050	041		
	036604	132	133	067		
	036607	042	045			
3242	036611	040	070	075	.BYTE	040,070,075,050,041,057,047,053,175,076,176

.EVEN

:96 CHARACTER TABLE

: CRITICAL HAMMER FIRE PATTERN 96 CHARACTER BAND
 TAB96: .BYTE 101,064,103,123,060,065,106,126,061,130,111

	036614	050	041	057	
	036617	047	053	175	
	036622	076	176		
3243	036624	074	056	050	.BYTE 074,056,050,041,057,047,053,175,076,176,074
	036627	041	057	047	
	036632	053	175	076	
	036635	176	074		
3244	036637	056	100	140	.BYTE 056,100,140,135,060,134,143,054,061,040,040
	036642	135	060	134	
	036645	143	054	061	
	036650	040	040		
3245	036652	040	040	040	.BYTE 040,040,040,060,040,040,040,040,040,040,040
	036655	060	040	040	
	036660	040	040	040	
	036663	040	040		
3246	036665	150	012	012	.BYTE 150,012,012
3247					
3248					
3249					
3250	036670	041501	030505	046112	T2696: .ASCII /ACE1JL3QR1J2NPRS5W6NP2L36_%)TV6_58:+/<145>
	036676	050463	030522	031112	
	036704	050116	032522	033127	
	036712	050116	046062	033063	
	036720	022537	052051	033126	
	036726	022137	035070	062453	
3251	036734	022132	035070	037053	.ASCII /Z58:++?]'(9?) *'</<164>/\ *'</<173>
	036742	056477	024042	037071	
	036750	056477	025040	036047	
	036756	056164	025040	075447	
3252	036764	023536	036454	076443	.ASCII /^',=#/<175>/^@/<142><144><147><175><176><177>
	036772	040136	062142	076547	
	037000	077576	000		
3253	037003	060	144	147	.BYTE 60,144,147,62,154,155,60,144,146,151,113,155,64
	037006	062	154	155	
	037011	060	144	146	
	037014	151	113	155	
	037017	064			
3254	037020	162	065	151	.BYTE 162,65,151,153,155,157,161,65,167,171,101,157,161
	037023	153	155	157	
	037026	161	065	167	
	037031	171	101	157	
	037034	161			
3255	037035	065	167	170	.BYTE 65,167,170,67,103,105,71,166,170,67,103,105,107
	037040	067	103	105	
	037043	071	166	170	
	037046	067	103	105	
	037051	107			
3256	037052	045511	041116	043470	.ASCII /IKNB8GIKNO,TH/<145>/MO,T/<12><12>
	037060	045511	047516	052054	
	037066	062510	047515	052054	
	037074	005012			

3257
3258
3259
3260

: LP26 64 CHAR PATTERN

3261 037076 042501 030124 046112 T2664: .ASCII /AETOJLNPQOJKMOQ56XMOQSVXZ+8SVXZ+9/

	037104	050116	030121	045512	
	037112	047515	032521	054066	
	037120	047515	051521	054126	
	037126	025532	051446	054126	
	037134	025532	071		
3262	037137	043	026454	057531	.ASCII /#,-Y_9#,\$>?]):\$>?]T0=;.ET0=#'B['!'BDGI!2/
	037144	021471	022054	037476	
	037152	024535	022072	037476	
	037160	052135	036460	027073	
	037166	052105	036460	023443	
	037174	055502	020442	041047	
	037202	043504	020511	062	
3263	037207	063	043464	045511	.ASCII /34GIKMN4GHJLN9-UJLNPRUWY_PRUWX.ETOVX.ET(/
	037214	047115	043464	045110	
	037222	047114	026471	045125	
	037230	047114	051120	053525	
	037236	057531	051120	053525	
	037244	027130	052105	053060	
	037252	027130	052105	050	
3264	037257	057	036073	023053	.ASCIIZ <57>/;<+8(/<57>/;<34'':1234''/<12><12>
	037264	027450	036073	032063	
	037272	035042	031061	032063	
	037300	005042	000012		
3265					.EVEN
3266					
3267	037304				ENDTST
(3)	037304				L10027:
(3)	037304	104401			TRAP C\$ETST
3268	037306				ENDMOD
3269					

```

3271 .SBTTL MULTIPLE LINE ADVANCE
3272
3273 037306 BGNMOD
3274 :++
3275 ;THIS TEST CHECKS THE MULTIPLE LINE ADVANCE OF THE LINE PRINTER. A LINE OF
3276 ;NUMBERS IS PRINTED AND THEN THE PAPER IS ADVANCED THAT NUMBER OF LINES. THUS THE
3277 ;NUMBER PRINTED WILL INDICATE THE NUMBER OF BLANK LINES FOLLOWING THAT
3278 ;LINE. THE NUMBER OF LINES IS VARIED BETWEEN 2 AND 7 AND A LINE OF
3279 ;ALL 0'S WILL INDICATE THE END OF THE TEST SEQUENCE.
3280 ;--
3281
3282
3283 037306 BGNTST 15.
    (3) 037306 T15::
3284
3285 ;PRINT TEST IDENTIFICATION
3286
3287 037306 OUTPUT ,MULINE,#86.
3288
3289 037350 LET STACHR := #TABSTR ;OUTPUT CHARACTERS
    (4) 037350 012737 037616 037614 MOV #TABSTR,STACHR
3290
3291 037356 REPEAT
    (3) 037356 50403$:
3292 037356 LET LINCNT := @STACHR ;GET A CHARACTER TO OUTPUT
    (4) 037356 117737 000232 002310 MOVB @STACHR,LINCNT
3293 037364 LET LINCNT := LINCNT AND #7 ;MAKE THE ASCII TO OCTAL
    (6) 037364 013746 002310 MOV LINCNT,-(SP)
    (6) 037370 042716 000007 BIC #7,(SP)
    (6) 037374 042637 002310 BIC (SP)+,LINCNT
3294 037400 LET R3 := #OUTBUF ;SET UP OUTPUT BUFFER
    (4) 037400 012703 003172 MOV #OUTBUF,R3
3295 037404 INCR CCNT FROM #1 TO #132. BY #1
    (4) 037404 012737 000001 002316 MOV #1,CCNT
    (5) 037412 000402 BR 50404$
    (4) 037414 50405$:
    (7) 037414 005237 002316 INC CCNT
    (5) 037420 50404$:
    (5) 037420 023727 002316 000204 CMP CCNT,#132.
    (7) 037426 003003 BGT 50406$
3296 037430 LET (R3)+ := @STACHR ;PUT CHARACTER IN OUTPUT BUFFER
    (4) 037430 117723 000160 MOVB @STACHR,(R3)+
3297 037434 ENDINC
    (4) 037434 000767 BR 50405$
    (3) 037436 50406$:
3298 037436 LET R4 := #0
    (4) 037436 005004 CLR R4
3299 037440 WHILE R4 NE LINCNT DO
    (4) 037440 50407$:
    (6) 037440 020437 002310 CMP R4,LINCNT
    (9) 037444 001404 BEQ 50410$
3300 037446 LET (R3)+ := #12 ;FILL WITH LINE FEEDS
    (4) 037446 112723 000012 MOVB #12,(R3)+
3301 037452 LET R4 := R4 + #1
    (6) 037452 005204 INC R4
3302 037454 ENDDO
    
```

```

(4) 037454 000771          BR      50407$
(3) 037456          50410$:
3303
3304          ;NOW OUTPUT THE ACTUAL LINE
3305
3306 037456          LET R4 := LINCNT + #132.          ;NUMBER OF CHARACTERS TO OUTPUT
(4) 037456 013704 002310      MOV      LINCNT,R4
(6) 037462 062704 000204      ADD      #132.,R4
3307 037466          LET STACHR := STACHR + #1          ; UPDATE CHARACTER COUNT
(6) 037466 005237 037614      INC      STACHR
3308 037472          OUTPUT #OUTBUF,R4          ;OUTPUT THE LINE
3309
3310 037532          UNTIL LINCNT EQ #0
(3) 037532 005737 002310      TST      LINCNT
(6) 037536 001307          BNE      50403$
3311 037540          LET OUTBUF := #14
(4) 037540 012737 000014 003172  MOV      #14,OUTBUF
3312 037546          OUTPUT #OUTBUF,#1
3313
3314 037610          EXIT TST
(3) 037610 104432          TRAP     C$EXIT
(3) 037612 000150          .WORD   L10030-.
3315
3316
3317 037614 000000          STACHR: .WORD 0
3318
3319 037616 033462 033062 033463  TABSTR: .ASCIZ /272637463540/
      037624 033064 032463 030064
      037632      000
3320 037633      115 046125 044524  MULINE: .ASCII /MULTIPLE LINE ADVANCE TEST 15/<12>
      037640 046120 020105 044514
      037646 042516 040440 053104
      037654 047101 042503 052040
      037662 051505 020124 032461
      037670      012
3321 037671      116 046525 042502  .ASCIZ /NUMBERS PRINTED REPRESENT # LINES TO NEXT LINE PRINTED/<12><12>
      037676 051522 050040 044522
      037704 052116 042105 051040
      037712 050105 042522 042523
      037720 052116 021440 046040
      037726 047111 051505 052040
      037734 020117 042516 052130
      037742 046040 047111 020105
      037750 051120 047111 042524
      037756 005104 000012
3322
3323
3324
3325          .EVEN
3326
3327 037762          ENDTST
(3) 037762          L10030:
(3) 037762 104401          TRAP     C$ETST
3328 037764          ENDMOD
3329
  
```

```

3331          .SBTTL CHARACTER ALIGNMENT
3332 037764    BGNMOD
3333          :++
3334          :THIS TEST CHECKS CHARACTER ALIGNMENT BY OVERPRINTING LINES OF ALTERNATING
3335          :H'S AND SPACES WITH SPACES AND H'S.
3336          :--
3337 037764    BGNTST 16.
          (3) 037764    T16::
3338          :PRINT TEST IDENTIFICATION
3339 037764    OUTPUT #CHRALN,#30. ; PRINT TEST NAME ON LP
3340          :PRINT 24 LINES OF ALTERNATING 'H''S AND 'SPACE''S
3341 040026    1$: LET LINCNT := #24.
          (4) 040026 012737 000030 002310    MOV #24.,LINCNT
3342 040034    2$: IF LINCNT LE #0 THEN
          (6) 040034 005737 002310    TST LINCNT
          (9) 040040 003002    BGT 50411$
3343 040042    INLINE <JMP 3$>
          (2) 040042 000137 040350    JMP 3$
3344 040046    ENDIF
          (4) 040046
3345          50411$: :LOAD BUFFER WITH ALTERNATING STRING OF 'H''S AND 'SPACE''S
3346 040046    LET R4 := #OUTBUF
          (4) 040046 012704 003172    MOV #OUTBUF,R4
3347 040052    INCR WORK FROM #1 TO #66. BY #1 ; 132 CHARACTERS
          (4) 040052 012737 000001 003166    MOV #1,WORK
          (5) 040060 000402    BR 50412$
3348          50413$: INC WORK
          (7) 040062 005237 003166
3349          50412$: CMP WORK,#66.
          (5) 040066 023727 003166 000102    BGT 50414$
          (7) 040074 003005    LET (R4)+ :B= #110 ; PUT PATTERN INTO BUFFER
3348 040076    MOVB #110,(R4)+
          (4) 040076 112724 000110
3349 040102    LET (R4)+ :B= #40
          (4) 040102 112724 000040    MOVB #40,(R4)+
3350 040106    ENDINCR
          (4) 040106 000765    BR 50413$
3351 040110    50414$: LET (R4)+ :B= #CR ; FOLLOWED BY CR
          (4) 040110 112724 000015    MOVB #CR,(R4)+
3352          :
3353          : SEND BASIC PATTERN
3354          :
3355 040114    OUTPUT #OUTBUF,#132.
3356 040156    OUTPUT #OUTBUF+132.,#1
3357          :
3358          : OVERPRINT WITH LINE OF ALTERNATING SPACE AND 'H'
3359          :
3360 040220    LET R4 := #OUTBUF+132. ; FILL BUFFER WITH REVERSE PATTERN
          (4) 040220 012704 003376    MOV #OUTBUF+132.,R4
3361 040224    LET (R4)+ :B= #110 ; H
          (4) 040224 112724 000110    MOVB #110,(R4)+
3362 040230    LET (R4)+ :B= #LF ; FOLLOWED BY A LINEFEED
          (4) 040230 112724 000012    MOVB #LF,(R4)+
3363          :
3364 040234    OUTPUT #OUTBUF+1,#132. ; OVERPRINT
  
```

3365	040276					OUTPUT #OUTBUF+133.,#1
3366	040340					LET LINCNT := LINCNT - #1
(6)	040340	005337	002310			DEC LINCNT
3367	040344					INLINE <JMP 2\$>
(2)	040344	000137	040034			JMP 2\$
3368	040350					3\$:
3369	040350					LET OUTBUF := #14
(4)	040350	012737	000014	003172		MOV #14,OUTBUF
3370	040356					OUTPUT #OUTBUF,#1
3371	040420					EXIT TST
(3)	040420	104432				TRAP C\$EXIT
(3)	040422	000042				.WORD L10031-
3372	040424	044103	051101	041501		CHRALN: .ASCIZ /CHARACTER ALIGNMENT TEST 16/<12><12><12>
	040432	042524	020122	046101		
	040440	043511	046516	047105		
	040446	020124	042524	052123		
	040454	030440	005066	005012		
	040462	000				
3373		040464				.EVEN
3374	040464					ENDTST
(3)	040464					L10031:
(3)	040464	104401				TRAP C\$ETST
3375	040466					ENDMOD

```

3377          .SBTTL  INTERRUPT SERVICE ROUTINES
3378 040466  BGNSRV
3379          :
3380          :++
3381          :INTERRUPT VECTORS ARE ESTABLISHED DURING INITIALIZATION
3382          :POINTING TO THE BASIC ROUTINES WHICH
3383          :SET UP THE UNIT NUMBER CAUSING THE INTERRUPTS.
3384          :LINE NUMBER IS RETURNED IN R2
3385          :
3386          :--
3387          X=0
3388 040466 000000
3389          INT00: .REPT 16.
3390                SETPRI #PRI04
3391                PUSH  R2
3392                LET R2 := #X
3393                INLINE <JMP  IODRV>
3394          X=X+2
          .ENDR
(4) 040466 012700 000200  MOV #PRI04,R0
(4) 040472 104441  TRAP C$SPRI
(3) 040474 010246  MOV R2,-(SP)
(5) 040476 012702 000000  MOV #X,R2
(3) 040502 000137 004704  JMP IODRV
(4) 040506 012700 000200  MOV #PRI04,R0
(4) 040512 104441  TRAP C$SPRI
(3) 040514 010246  MOV R2,-(SP)
(5) 040516 012702 000002  MOV #X,R2
(3) 040522 000137 004704  JMP IODRV
(4) 040526 012700 000200  MOV #PRI04,R0
(4) 040532 104441  TRAP C$SPRI
(3) 040534 010246  MOV R2,-(SP)
(5) 040536 012702 000004  MOV #X,R2
(3) 040542 000137 004704  JMP IODRV
(4) 040546 012700 000200  MOV #PRI04,R0
(4) 040552 104441  TRAP C$SPRI
(3) 040554 010246  MOV R2,-(SP)
(5) 040556 012702 000006  MOV #X,R2
(3) 040562 000137 004704  JMP IODRV
(4) 040566 012700 000200  MOV #PRI04,R0
(4) 040572 104441  TRAP C$SPRI
(3) 040574 010246  MOV R2,-(SP)
(5) 040576 012702 000010  MOV #X,R2
(3) 040602 000137 004704  JMP IODRV
(4) 040606 012700 000200  MOV #PRI04,R0
(4) 040612 104441  TRAP C$SPRI
(3) 040614 010246  MOV R2,-(SP)
(5) 040616 012702 000012  MOV #X,R2
(3) 040622 000137 004704  JMP IODRV
(4) 040626 012700 000200  MOV #PRI04,R0
(4) 040632 104441  TRAP C$SPRI
(3) 040634 010246  MOV R2,-(SP)
(5) 040636 012702 000014  MOV #X,R2
(3) 040642 000137 004704  JMP IODRV
(4) 040646 012700 000200  MOV #PRI04,R0
(4) 040652 104441  TRAP C$SPRI
(3) 040654 010246  MOV R2,-(SP)

```

(5)	040656	012702	000016	MOV	#X,R2
(3)	040662	000137	004704	JMP	IODRV
(4)	040666	012700	000200	MOV	#PRI04,R0
(4)	040672	104441		TRAP	C\$SPRI
(3)	040674	010246		MOV	R2,-(SP)
(5)	040676	012702	000020	MOV	#X,R2
(3)	040702	000137	004704	JMP	IODRV
(4)	040706	012700	000200	MOV	#PRI04,R0
(4)	040712	104441		TRAP	C\$SPRI
(3)	040714	010246		MOV	R2,-(SP)
(5)	040716	012702	000022	MOV	#X,R2
(3)	040722	000137	004704	JMP	IODRV
(4)	040726	012700	000200	MOV	#PRI04,R0
(4)	040732	104441		TRAP	C\$SPRI
(3)	040734	010246		MOV	R2,-(SP)
(5)	040736	012702	000024	MOV	#X,R2
(3)	040742	000137	004704	JMP	IODRV
(4)	040746	012700	000200	MOV	#PRI04,R0
(4)	040752	104441		TRAP	C\$SPRI
(3)	040754	010246		MOV	R2,-(SP)
(5)	040756	012702	000026	MOV	#X,R2
(3)	040762	000137	004704	JMP	IODRV
(4)	040766	012700	000200	MOV	#PRI04,R0
(4)	040772	104441		TRAP	C\$SPRI
(3)	040774	010246		MOV	R2,-(SP)
(5)	040776	012702	000030	MOV	#X,R2
(3)	041002	000137	004704	JMP	IODRV
(4)	041006	012700	000200	MOV	#PRI04,R0
(4)	041012	104441		TRAP	C\$SPRI
(3)	041014	010246		MOV	R2,-(SP)
(5)	041016	012702	000032	MOV	#X,R2
(3)	041022	000137	004704	JMP	IODRV
(4)	041026	012700	000200	MOV	#PRI04,R0
(4)	041032	104441		TRAP	C\$SPRI
(3)	041034	010246		MOV	R2,-(SP)
(5)	041036	012702	000034	MOV	#X,R2
(3)	041042	000137	004704	JMP	IODRV
(4)	041046	012700	000200	MOV	#PRI04,R0
(4)	041052	104441		TRAP	C\$SPRI
(3)	041054	010246		MOV	R2,-(SP)
(5)	041056	012702	000036	MOV	#X,R2
(3)	041062	000137	004704	JMP	IODRV

3395

CLOCK SERVICE ROUTINE

3397
3398
3399
3400
3401
3402
3403 041066
3404 041066
(3) 041066 012700 000300
(3) 041072 104441
3405 041074
(6) 041074 005737 041142
(9) 041100 001005
3406 041102
(4) 041102 012737 000074 041142
3407 041110
(6) 041110 005237 041140
3408 041114
(4) 041114
3409 041114
(6) 041114 005337 041142
3410 041120
(6) 041120 023727 002334 000002
(9) 041126 001003
3411 041130
(4) 041130 012777 000100 141202
3412 041136
(4) 041136
3413
3414 041136
(3) 041136
(2) 041136 000002
3415
3416 041140 000000
3417 041142 000000

.SBTTL CLOCK SERVICE ROUTINE
:++
:UPDATES THE COUNTER AT A RATE OF 16.67 MILLISECONDS PER TICK
:AND UPDATES A SECOND COUNTER WHEN THE FIRST OVERFLOWS.
:--
BGNSRV
CLKTCK: SETPRI #PRI06
MOV #PRI06,R0
TRAP C\$SPRI
IF TICK EQ #0 THEN
TST TICK
BNE 50415\$
LET TICK := #60. ;60 TICKS PER SECOND
MOV #60.,TICK
LET TIME := TIME + #1
INC TIME
ENDIF
50415\$: LET TICK := TICK - #1 ;BACK UP SECOND TIMER
DEC TICK
IF CLKTYP EQ #2 THEN
CMP CLKTYP,#2
BNE 50416\$
LET @CLKCSR := #100
MOV #100,@CLKCSR
ENDIF
50416\$: ENDSRV ;AND EXIT
L10033: RTI
: TIME: .WORD 0
: TICK: .WORD 0

HARDWARE PARAMETER SECTION

```

3419 .SBTTL HARDWARE PARAMETER SECTION
3420 041144 BGNMOD
3421
3422
3423 ;+
3424 ;THIS SECTION INCLUDES THE QUESTIONS WHICH REQUEST THE OPERATOR TO
3425 ;FURNISH THE HARDWARE INFORMATION NECESSARY TO BUILD THE HARDWARE
3426 ;P-TABLES.
3427 ;--
3428 041144 BGNHRD
(3) 041144 000020 ;
(3) 041146 L$HARD: .WORD L10034-L$HARD/2
3429
3430 041146 GPRMA GETADR,0,0,160000,177516,YES
(4) 041146 000031 .WORD T$CODE
(4) 041150 041206 .WORD GETADR
(4) 041152 160000 .WORD T$LLOLIM
(4) 041154 177516 .WORD T$HILIM
3431 041156 GPRMA GETVEC,2,0,110,770,YES
(4) 041156 001031 .WORD T$CODE
(4) 041160 041223 .WORD GETVEC
(4) 041162 000110 .WORD T$LLOLIM
(4) 041164 000770 .WORD T$HILIM
3432 041166 GPRMD GETTYP,4,0,3,0,3,YES
(4) 041166 002032 .WORD T$CODE
(4) 041170 041244 .WORD GETTYP
(4) 041172 000003 .WORD 3
(4) 041174 000000 .WORD T$LLOLIM
(4) 041176 000003 .WORD T$HILIM
3433 041200 GPRML GETBND,6,1,YES
(4) 041200 003130 .WORD T$CODE
(4) 041202 041300 .WORD GETBND
(4) 041204 000001 .WORD 1
3434 041206 ENDHRD
(2) .EVEN
(3) 041206 L10034:
3435
3436 041206 050114 030461 040440 GETADR: .ASCIZ /LP11 ADDRESS/
041214 042104 042522 051523
041222 000
3437 041223 111 052116 051105 GETVEC: .ASCIZ /INTERRUPT VECTOR/
041230 052522 052120 053040
041236 041505 047524 000122
3438 041244 047105 042524 020122 GETTYP: .ASCIZ /ENTER 0 IF LP25, 1 IF LP26 /
041252 020060 043111 046040
041260 031120 026065 030440
041266 044440 020106 050114
041274 033062 000040
3439 041300 033071 041440 040510 GETBND: .ASCIZ /96 CHARACTER BAND/
041306 040522 052103 051105
041314 041040 047101 000104
3443 .EVEN
  
```

```

3445          .SBTTL SOFTWARE PARAMETER SECTION
3446          :
3447          :++
3448          :THIS SECTION INCLUDES THE QUESTIONS WHICH REQUEST THE OPERATOR TO FURNISH
3449          :THE SOFTWARE INFORMATION NECESSARY TO BUILD THE SOFTWARE P-TABLES.
3450          :--
3451          :
3452          BGNSFT
3453          (3) 041322 000026          .WORD L10035-L$SOFT/2
3454          (3) 041324          L$SOFT.:
3455          (4) 041324 000130          GPRML MGTINT,0,1,YES
3456          (4) 041326 041400          .WORD T$CODE
3457          (4) 041330 000001          .WORD MGTINT
3458          (4) 041332          .WORD 1
3459          (4) 041332 001130          GPRML GETDAV,2,1,YES
3460          (4) 041334 041436          .WORD T$CODE
3461          (4) 041336 000001          .WORD GETDAV
3462          (4) 041340          .WORD 1
3463          (4) 041340 002130          GPRML GETMAN,4,1,YES
3464          (4) 041342 041465          .WORD T$CODE
3465          (4) 041344 000001          .WORD GETMAN
3466          (4) 041346          .WORD 1
3467          (4) 041346 003052          GPRMD GETTIM,6,D,377,4,60.,YES
3468          (4) 041350 041537          .WORD T$CODE
3469          (4) 041352 000377          .WORD GETTIM
3470          (4) 041354 000004          .WORD 377
3471          (4) 041356 000074          .WORD T$LLOLIM
3472          (4) 041360          .WORD T$HILIM
3473          (4) 041360 004130          GPRML GETPLA,10,1,YES
3474          (4) 041362 041624          .WORD T$CODE
3475          (4) 041364 000001          .WORD GETPLA
3476          (4) 041366          .WORD 1
3477          (4) 041366 005052          GPRMD GETMAX,12,D,377,1,255.,YES
3478          (4) 041370 041645          .WORD T$CODE
3479          (4) 041372 000377          .WORD GETMAX
3480          (4) 041374 000001          .WORD 377
3481          (4) 041376 000377          .WORD T$LLOLIM
3482          .WORD T$HILIM
3483
3484          ENDSFT
3485          (2) 041400          .EVEN
3486          (3) 041400          L10035:
3487
3488          .NLIST BEX
3489          3464 041400 052522 020116 040515 MGTINT: .ASCIZ /RUN MANUAL INTERVENTION TESTS/
3490          3465 041436 040504 043126 020125 GETDAV: .ASCIZ /DAVFU OPTION INSTALLED/
3491          3466 041465 120 051105 047506 GETMAN: .ASCIZ /PERFORM MANUAL PRINTING SPEED MEASUREMENT/
3492          3467 041537 104 051505 051111 GETTIM: .ASCIZ /DESIRED TIME INTERVAL FOR PRINTING SPEED CALCULATION/
3493          3468 041624 042524 052123 047111 GETPLA: .ASCIZ /TESTING IN U.S.A/
3494          3469 041645 101 052125 042117 GETMAX: .ASCIZ /AUTODROP ERROR COUNT/
3495          3470          .LIST BEX
3496          3471          .EVEN
3497          3472          ;
3498          3473
3499          3474 041672 000020          PATCH: .BLKW 20
  
```

CZLPLC0 LP25, LP26 TEST MACY11 30A(1052) 01-OCT-80 12:06 PAGE 38-1
CZLPLC.P11 01-OCT-80 12:06 SOFTWARE PARAMETER SECTION

SEQ 0122

3475 041732
(2)
(4) 041732 000000
(4) 041734 000000
(3) 041736
3476 041736
3477 000001

LASTAD
.EVEN
.WORD 0
.WORD 0
L\$LAST::
ENDMOD
.END

ACTIVE= 020000	BUFREP 002366	C\$GMAN= 000043	E\$LOAD= 000035	G\$OF SI= 000376
ADR = 000020 G	CCNT 002316	C\$GPHR= 000042	FAKE 005642	G\$PRMA= 000001
ASSEMB= 000010	CHAR 027236	C\$GPLO= 000030	FF = 000014 G	G\$PRMD= 000002
AUTCON 030762	CHARSP 026604	C\$GPRI= 000040	FFSET 015474	G\$PRML= 000000
BANDSW 013425	CHARX 026605	C\$INIT= 000011	FLAG 002306	G\$RADA= 000140
BIN2DA 004472	CHRALN 040424	C\$INLP= 000020	FLAGDA 004676	G\$RADB= 000000
BIT0 = 000001 G	CHRGEN 002322	C\$MANI= 000050	FLAG26= 001000	G\$RADD= 000040
BIT00 = 000001 G	CK1 006524	C\$MEM = 000031	FLAG27= 002000	G\$RADL= 000120
BIT01 = 000002 G	CLEAN 007362	C\$MSG = 000023	FLAG96= 010000	G\$RADO= 000020
BIT02 = 000004 G	CLKCSR 002340	C\$OPEN= 000034	FLMSG 015550	G\$XFER= 000004
BIT03 = 000010 G	CLKENA 002346	C\$PNTB= 000014	FLSMS1 015642	G\$YES = 000010
BIT04 = 000020 G	CLKSET 002342	C\$PNTF= 000017	FLSSEL 015003	HAMFIR 034402
BIT05 = 000040 G	CLKTCK 041066	C\$PNTS= 000016	FRMLTH 014576	HAMRDY 013310
BIT06 = 000100 G	CLKTYP 002334	C\$PNTX= 000015	FSTMSG 025007	HAMRSW 013147
BIT07 = 000200 G	CLKVEC 002344	C\$QIO = 000377	F\$AU = 000015	HAMSW1 013233
BIT08 = 000400 G	CLOCKP 002336	C\$RDBU= 000007	F\$AUTO= 000020	HOE = 100000 G
BIT09 = 001000 G	COUNT 002314	C\$REFG= 000047	F\$BGN = 000040	IBE = 010000 G
BIT1 = 000002 G	COUNTD 004700	C\$RESE= 000033	F\$CLEA= 000007	IDU = 000040 G
BIT10 = 002000 G	CR = 000015 G	C\$REVI= 000003	F\$DU = 000016	IER = 020000 G
BIT11 = 004000 G	CRTPTH 036264	C\$RFLA= 000021	F\$END = 000041	IGNORE 007266
BIT12 = 010000 G	CSRERR 003420	C\$RPT = 000025	F\$HARD= 000004	INCDAT 023344
BIT13 = 020000 G	CTLEND 005460	C\$SEFG= 000046	F\$HW = 000013	INCTBL 023700
BIT14 = 040000 G	CTLLOP 005142	C\$SPRI= 000041	F\$INIT= 000006	INDEX 002356
BIT15 = 100000 G	CURADD 002564	C\$SVEC= 000037	F\$JMP = 000050	INHINT 002272
BIT2 = 000004 G	CURCNT 002764	C\$TPRI= 000013	F\$MOD = 000000	INSTR 026522
BIT3 = 000010 G	C\$AU = 000052	DATPTH 027240	F\$MSG = 000011	INTERR 010422
BIT4 = 000020 G	C\$AUTO= 000061	DEL = 000177 G	F\$PROT= 000021	INTER1 003640
BIT5 = 000040 G	C\$BRK = 000022	DELCNT 003064	F\$PWR = 000017	INTFAC 010460
BIT6 = 000100 G	C\$BSEG= 000004	DFPTBL 002254 G	F\$RPT = 000012	INTHDL 010452
BIT7 = 000200 G	C\$BSUB= 000002	DIAGMC= 000000	F\$SEG = 000003	INTLK 012220
BIT8 = 000400 G	C\$CEFG= 000045	DIGITS 004702	F\$SOFT= 000005	INT00 040466
BIT9 = 001000 G	C\$CLCK= 000062	DOTOF 012723	F\$SRV = 000010	IOCTRL 005102
BNDPAT 020742	C\$CLEA= 000012	DROPED= 040000	F\$SUB = 000002	IODRV 004704
BNDRDY 013562	C\$CLOS= 000035	DROPIT 005534	F\$SW = 000014	ISR = 000100 G
BNSWI 003570	C\$CLP1= 000006	EF.CON= 000036 G	F\$TEST= 000001	IXE = 004000 G
BNSW1 013513	C\$CVEC= 000036	EF.NEW= 000035 G	GETADR 041206	I\$AU = 000041
BNDTST 032706	C\$DCLN= 000044	EF.PWR= 000034 G	GETBND 041300	I\$AUTO= 000041
BNKSWI 003523	C\$DODU= 000051	EF.RES= 000037 G	GETDAV 041436	I\$CLN = 000041
BOE = 000400 G	C\$DRPT= 000024	EF.STA= 000040 G	GETFLG 023266	I\$DU = 000041
BPID25 032735	C\$DU = 000053	END2 010240	GETMAN 041465	I\$HRD = 000041
BPID26 032743	C\$EDIT= 000003	END4 017514	GETMAX 041645	I\$INIT= 000041
BP64ID 032751	C\$ERDF= 000055	ERRCOD 002350	GETPLA 041624	I\$MOD = 000041
BP64Q1 033025	C\$ERHR= 000056	ERRFLG 002352	GETTIM 041537	I\$MSG = 000041
BP64Q2 033121	C\$ERRO= 000060	ERROR = 100000	GETTYP 041244	I\$PROT= 000040
BP64Q3 033216	C\$ERSF= 000054	ERRSVC 003124	GETVEC 041223	I\$PTAB= 000041
BP64Q4 033312	C\$ERSO= 000057	ERRTBL 003126 G	G\$CNTO= 000200	I\$PWR = 000041
BP96ID 032777	C\$ESCA= 000010	ERRO6 023563	G\$DELM= 000372	I\$RPT = 000041
BP96Q1 033410	C\$ESEG= 000005	ERRO7 023634	G\$DISP= 000003	I\$SEG = 000041
BP96Q2 033504	C\$ESUB= 000003	ERR11 010511	G\$EXCP= 000400	I\$SETU= 000041
BP96Q3 033601	C\$ETST= 000001	ERR12 010565	G\$HILI= 000002	I\$SFT = 000041
BP96Q4 033675	C\$EXIT= 000032	ERR13 010650	G\$LOLI= 000001	I\$SRV = 000041
BUFADD 002362	C\$GETB= 000026	EVL = 000004 G	G\$NO = 000000	I\$SUB = 000041
BUFCNT 002364	C\$GETW= 000027	E\$END = 002100	G\$OFFS= 000400	I\$TST = 000041

JSJMP = 000167	L\$LADP 002026 G	MOVMSG 015754	PRI04 = 000200 G	TSEXCP= 000000
LCTMSG 025212	L\$LAST 041736 G	MOVMS1 016051	PRI05 = 000240 G	T\$FLAG= 000040
LCTTBL 024726	L\$LOAD 002100 G	MOVMS2 016147	PRI06 = 000300 G	T\$GMAN= 000000
LF = 000012 G	L\$LUN 002074 G	MRESET 006773	PRI07 = 000340 G	T\$HILI= 000377
LINCNT 002310	L\$MREV 002050 G	MSGADR 002724	PRTCHR 030070	T\$LAST= 000001
LINPER 021004	L\$NAME 002000 G	MSGCNT 002624	PRTCTL 035242	T\$LOLI= 000001
LINSWI 014637	L\$PRIO 002042 G	MULINE 037633	PRTSPD 021341	T\$LSYM= 010000
LINSW1 014723	L\$PROT 002122 G	NMLFLS 015402	PTABAD 002330	T\$LTNO= 000020
LN3EX 013017	L\$PRT 002112 G	NOCLCK 007127	QUIET 005466	T\$NEST= 000000
LOBYTE= 000377	L\$REPP 002062 G	NOCLK 004161	RDYERR 003436	T\$NSO = 000010
LOE = 040000 G	L\$REV 002010 G	NOINTR= 000003	READY 007072	T\$NS1 = 000000
LOT = 000010 G	L\$SOFT 041324 G	NONBUF 031065	REFLIN 015174	T\$NS2 = 000005
LPBUF 002464	L\$SPC 002056 G	NONCHR 030652	REFLI1 015271	T\$PTNU= 000000
LPCSR 002370	L\$SPCP 002020 G	NOSTOP 023415	REFLI2 015366	T\$SAVL= 177777
LPDROP 004230	L\$SPTP 002024 G	NOTIM 007171	REPCNT 002664	T\$SEGL= 177777
LPERR 004276	L\$STA 002030 G	NRGT16 006654	REPLUP 017632	T\$SUBN= 000000
LPERR2 020732	L\$SW 002272 G	NRGT17 006737	RESET 023460	T\$TAGL= 177777
LPINTR 003024	L\$TEST 002114 G	NSTTBL 023705	RESVEC 007270 G	T\$TAGN= 010036
LPM64 021406	L\$TIML 002014 G	OFFLIN 021051	SECMSG 025044	T\$TEMP= 000000
LPM96 021467	L\$UNIT 002012 G	ONEFIL= 000001	SFPTBL 002272 G	T\$TEST= 000020
LPVEC 002430	L10001 002264	ONLIN1 021111	SKIP3 031060	T\$TSTM= 177777
LSTCNT 002312	L10002 002266	ONLIN2 021212	SPCCNT 034400	T\$TSTS= 000001
LUNIT 002326	L10003 002306	ONLIN3 021310	SPED1 020744	T\$\$AUT= 010002
L\$ACP 002110 G	L10004 007264	OUTBUF 003172	SPED2 020767	T\$\$CLE= 010005
L\$APT 002036 G	L10005 007544	OUTTIM 003720	SPED3 020773	T\$\$HAR= 010034
L\$AUT 002070 G	L10006 010724	O\$APTS= 000000	SPED4 021003	T\$\$HW = 010001
L\$AUTO 002264 G	L10007 010450	O\$AU = 000000	STACHR 037614	T\$\$INI= 010004
L\$CCP 002106 G	L10010 010456	O\$BGNR= 000000	STATER= 000001	T\$\$PRO= 010000
L\$CLEA 007352 G	L10011 013702	O\$BGNS= 000001	STATUS 002524	T\$\$SOF= 010035
L\$CO 002032 G	L10012 016160	O\$DU = 000000	STRCNT 002320	T\$\$SRV= 010033
L\$DEPO 002011 G	L10013 022326	O\$ERRT= 000000	SVCGBL= 000000	T\$\$SUB= 010016
L\$DESC 002172 G	L10014 023714	O\$GNSW= 000001	SVCINS= 000000	T\$\$SW = 010003
L\$DESP 002076 G	L10015 022666	O\$POIN= 000001	SVCSUB= 000000	T\$\$TES= 010031
L\$DEVP 002060 G	L10016 023264	O\$SETU= 000000	SVCTAG= 000000	T1 007546 G
L\$DISP 002132 G	L10017 025420	PAPCHK 015102	SVCTST= 000000	T1A 007562
L\$DLY 002116 G	L10020 026670	PAPOUT 012540	S\$LSYM= 010000	T1B 010264
L\$DTP 002040 G	L10021 027302	PAPRDY 012404	TABA64 021712	T1C 007566
L\$DTYP 002034 G	L10022 030130	PAPRSW 012256	TABA96 022120	T10 030132 G
L\$DUT 002072 G	L10023 031462	PAPSWI 003460	TABLDA 004664	T11 031464 G
L\$DVTY 002240 G	L10024 033774	PAPSW1 012326	TABLE1 035512	T12 033776 G
L\$EF 002052 G	L10025 034444	PAPTST 012506	TABLE2 035546	T13 034446 G
L\$ENVI 002044 G	L10026 035602	PATCH 041672	TABSTR 037616	T14 035604 G
L\$ETP 002102 G	L10027 037304	PATTER 027300	TAB64 036316	T15 037306 G
L\$EXP1 002046 G	L10030 037762	PERIOD 002300	TAB96 036474	T16 037764 G
L\$EXP4 002064 G	L10031 040464	PLOC 007262	TICK 041142	T2 010726 G
L\$EXP5 002066 G	L10033 041136	PNT = 001000 G	TIME 041140	T2664 037076
L\$HARD 041146 G	L10034 041206	PRI = 002000 G	TIMOUT= 000002	T2696 036670
L\$HIME 002120 G	L10035 041400	PRINTR 002332	TOF = 000014	T3 013704 G
L\$HPCP 002016 G	L26M64 021550	PRINT4 012572	TXERR 003673	T3MOV 014574
L\$HPTP 002022 G	L26M96 021631	PRI00 = 000000 G	TXNOIN 003745	T3SET 014572
L\$HW 002254 G	MANSPD 002276	PRI01 = 000040 G	T\$ARGC= 000001	T4 016162 G
L\$ICP 002104 G	MAXERR 002304	PRI02 = 000100 G	T\$CODE= 005052	T5 022330 G
L\$INIT 005676 G	MGTINT 041400	PRI03 = 000140 G	T\$ERRN= 000014	T5.1 022426

T5.2	022670	X\$FALS=	000040	\$F\$GOC=	000400	\$LSTTA=	000000	\$SCASE=	000404
T6	023716 G	X\$OFFS=	000400	\$F\$IF =	000110	\$NESTL=	177777	\$SDST =	000037
T7	025422 G	X\$TRUE=	000020	\$F\$INC=	000210	\$NSK0 =	000110	\$SELOC=	000402
T8	026672 G	X0	035333	\$F\$L00=	000200	\$NSK1 =	000120	\$SERFL=	000000
T9	027304 G	X1	035345	\$F\$NAM=	000160	\$NSK2 =	000110	\$FLAG=	000001
UAM	= 000200 G	X11	035477	\$F\$NO =	000403	\$NSK3 =	000110	\$FROM=	000000
UNIT	002324	X2	035357	\$F\$OR =	000320	\$NSK4 =	000110	\$LOC =	041126
USA	002302	X3	035371	\$F\$RTI=	000350	\$NSK5 =	000110	\$LOCN=	000000
UUT	002354	X4	035403	\$F\$RTN=	000300	\$SAVLE=	177777	\$REG =	177777
UUTEQO	003776	X5	035415	\$F\$SEL=	000140	\$SSK0 =	050413	\$RETU=	000000
VFUHL	026524	X6	035427	\$F\$THE=	000330	\$TAGLE=	177777	\$RTN1=	000000
VFUCMD	002360	X7	035441	\$F\$TRU=	000404	\$TAGNU=	050417	\$RTN2=	000000
VFUDAT	026606	X8	035453	\$F\$UNT=	000130	\$TEMP =	050416	\$SRC =	000027
VFUERR	023304	X9	035465	\$F\$WHI=	000120	\$TSK0 =	050416	\$TGSV=	050145
VFULCT	024654	\$BGNLE=	177777	\$F\$YES=	000402	\$TSK1 =	050413	\$TGS1=	000001
VFUOPT	002274	\$ERFLG=	000400	\$IFLEV=	177777	\$TSK2 =	050410	\$TGS2=	000000
VFUSEL	004045	\$F\$AND=	000310	\$ISK0 =	000001	\$TSK3 =	050400	\$TO =	000000
VFUSE1	004133	\$F\$BAD=	000401	\$ISK1 =	000001	\$TSK4 =	050402	\$STAG=	050000
VFUTBL	024765	\$F\$BLA=	000170	\$ISK2 =	000001	\$TSK5 =	050203	. =	041736
WORK	003166 G	\$F\$CAS=	000150	\$ISK3 =	000001	\$TSK6 =	050204		
WORK1	003170	\$F\$DEC=	000220	\$ISK4 =	000001	\$TSK7 =	050174		
X	= 000040	\$F\$DO =	000340	\$LOCTA=	177777	\$ARGC=	000000		
X\$ALWA=	000000	\$F\$FAL=	000405	\$LSTIN=	000000	\$BYTE=	000403		

. ABS. 041736 000

ERRORS DETECTED: 0

CZLPLC,CZLPLC.SEQ/DOC=SVC/ML,SPMAC/ML,CZLPLC.P11
RUN-TIME: 390 369 2 SECONDS
RUN-TIME RATIO: 858/762=1.1
CORE USED: 25K (49 PAGES)

DOCUMENT PAGES: 125