

# PDP11/45

TRAPS TEST  
MD-11-DCKBM-E

EP-DCKBM-E-DL-A  
COPYRIGHT © 1976  
FICHE 1 OF 1

NOV 1976  
**digital**  
MADE IN USA

This microfiche card contains a grid of frames. The frames are arranged in approximately 10 rows and 6 columns. Each frame contains a small, dense grid of characters, likely representing a data table or a series of test results. The characters are small and difficult to read, but they appear to be organized in a structured format. The frames are separated by thin white lines, and the overall layout is typical of a microfiche card used for data storage and retrieval.



48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103

- 1.0 ABSTRACT
- THIS PROGRAM TESTS ALL TRAP INSTRUCTIONS AND ERROR TRAPS. (TIMEOUT, ODD ADDRESS AND OVERFLOW) INTERRUPT LOGIC IS ALSO TESTED USING TELETYPE.
- 2.0 REQUIREMENTS
- 2.1 EQUIPMENT  
BASIC 11/45 SYSTEM
- 2.2 STORAGE  
THIS PROGRAM USES 0 THRU 17500
- 2.3 PRELIMINARY PROGRAMS  
DOAA THRU DOMA
- 3.0 LOADING PROCEDURE  
LOAD PROGRAM USING ABS LOADER
- 4.0 STARTING PROCEDURE  
LOAD ADDRESS 200. PRESS START. THE PROGRAM WILL LOOP AND RING BELL ON PASS COMPLETION.
- 5.0 OPERATING PROCEDURE
- 5.1 SWITCH SETTINGS  
NONE
- 5.2 SUBROUTINE ABSTRACTS
- 5.2.1 SCOPE  
SCOPE IS A MOVE PC,R1 AND STORES THE PC+2 IN R1.  
R1 CONTAINS THE PC OF THE LAST TEST SUCCESSFULLY COMPLETED.
- 5.2.2 HLT  
HLT IS A HALT INSTRUCTION.
- 6.0 ERRORS  
ALL ERRORS WILL CAUSE A HALT  
TRAP AND INTERRUPT ERRORS WILL CAUSE A HALT AT VECTOR+2.
- 6.1 ERROR RECOVERY  
PRESS CONTINUE TO PROCEED TO NEXT TEST
- 6.2 ERROR LOOPING  
TO LOOP ON AN ERROR, PLACE A BRANCH TO THE PREVIOUS SCOPE INSTRUCTION IN PLACE OF THE HALT INSTRUCTION.  
NOTE THAT IF THE ERROR IS INTERMITTANT THAT THE TEST WILL DROP THRU THE HALT AND PROCEED TO THE NEXT TEST.  
THEREFORE, TO LOOP THE TEST CONTINUOUSLY REPLACE THE BEQ .+4 INSTRUCTION IMMEDIATELY PRECEDING THE HALT WITH A BRANCH BACK TO THE PREVIOUS SCOPE.
- TO LOOP ON TRAP FAILURES, PATCH IN THE FOLLOWING ROUTINE AT THE ADDRESS OF THE TRAP VECTOR.
- TRAPVEC:           TRAPVEC+4

104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117  
118  
119  
120  
121  
122  
123

TRAPVEC+2: 0  
 TRAPVEC+4: 012716 ; MOVE SCOPE ADDRESS TO STACK  
 TRAPVEC+6: ADDRESS ; ADDRESS OF PREVIOUS SCOPE  
 TRAPVEC+10: 000006 ; RETURN TO TEST AT SCOPE

RESTORE ALL LOCATIONS BEFORE PROCEEDING TO NEXT TEST.

- 7.0 RESTRICTIONS  
NONE
- 8.0 MISCELLANEOUS  
ON TRAP ERRORS THE STACK POINTER(R6) WILL CONTAIN THE  
ADDRESS WHERE THE TRAP OCCURED.
- 8.1 EXECUTION TIME  
THIS PROGRAM TAKES ABOUT 1 MINUTE.
- 8.2 STACK POINTER  
THIS PROGRAM INITIALLY SETS THE STACK POINTER AT 500.
- !

124  
125

.TITLE MAINDEC-11-DCKBM-E PDP11/45 TRAPS TEST.  
.LIST ME  
.NLIST MC,SEQ  
.ABS

:TEST DCKBME-PDP11/45 TRAPS TEST. ALL PROCESSOR TRAPS INCLUDING ERROR TRAPS ARE  
:TESTED IN THIS PROGRAM (KERNEL MODE ONLY).  
:NOTE: THE SEGMENTATION ABORT TRAPS ARE NOT TESTED.

:STARTING PROCEEDURE  
:LOAD ADDRESS 0200  
:PRESS START  
:STACK POINTER IS AT 500  
:BELL WILL RING WHEN TEST IS COMPLETE  
:TEST WILL TYPE 'NULL' CHARACTERS IN THE FIRST 8. PASSES AND THEN  
:OMIT TYPING 'NULLS' FOR THE REST OF THE TEST.

000500

STKPTR=0500 ;INITIAL STACK POINTER

:MACRO CALL  
.MACR SETTBIT A  
MOV #20,-(6)  
MOV #.+6,-(6)  
'A'  
.ENDM

:PUSH 'T'BIT ON THE STACK  
:PUSH PC ON THE STACK  
:SET 'T' BIT

000000  
000003  
000002  
010701  
000000

TAB=%0  
LAST=%3  
FIRST=%2  
SCOPE=010701 ;MOVE PC TO R1  
HLT=HALT

000004  
000010  
000014  
000014  
000020  
000024  
000030  
000034  
000064  
000240  
000244

:TRAP VECTOR ADDRESSES  
ERRVEC=4  
RESVEC=10  
BPTVEC=14  
TBITVEC=14  
IOTVEC=20  
PFVEC=24  
EMTVEC=30  
TRAPVEC=34  
TPVEC=64  
PIRVEC=240  
FPEVEC=244

:RESERVED INST AND ILLEGAL ADDRESSES  
:RESERVED INSTRUCTION TRAP VECTOR  
:'BREAK-POINT' TRAP VECTOR  
:'T' BIT TRAP VECTOR ADDRESS  
:IOT TRAP VECTOR ADDRESS  
:POWER FAIL TRAP VECTOR ADDRESS  
:EMT TRAP VECTOR ADDRESS  
:TRAP TRAP VECTOR ADDRESS  
:ADDRESS OF TELEPRINTER INT VECTOR  
:PROG INT RQST TRAP VECTOR  
:FLOATING POINT TRAP VECTOR

177564  
177560  
177570  
177570  
177776  
177772  
177770  
010000  
076000  
075000  
004700

:REGISTER ADDRESSES  
TTCSR=177564  
TRCSR=177560  
SWR=177570  
DISPLAY=177570  
PSW=177776  
PIRQ=177772  
UBREAK=177770  
PIR4=10000  
RESINST=76000  
RES=75000  
ILLA=004700

:ADDRESS OF DISPLAY REGISTER  
:ADDRESS OF PROCESSOR STATUS WORD  
:ADDRESS OF PROC. INT. RQST. REGISTER  
:ADDRESS OF MICRO BREAK REGISTER  
:LEVEL 4 REQUEST  
:A RESERVED INSTRUCTION  
:A RESERVED INSTRUCTION  
:AN ILLEGAL INSTRUCTION (JSR 7,%0)

	000100	ILLB=100	;AN ILLEGAL INSTRUCTION (JMP %0)
	000000	.=0	
000000	000002	.+2	
000002	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000004	000006	.+2	
000006	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000010	000012	.+2	
000012	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000014	000016	.+2	
000016	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000020	000022	.+2	
000022	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000024	000026	.+2	
000026	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000030	000032	.+2	
000032	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000034	000036	.+2	
000036	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000040	000042	.+2	
000042	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000044	000046	.+2	
000046	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000050	000052	.+2	
000052	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000054	000056	.+2	
000056	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000060	000062	.+2	
000062	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000064	000066	.+2	
000066	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000070	000072	.+2	
000072	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000074	000076	.+2	
000076	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000100	000102	.+2	
000102	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000104	000106	.+2	
000106	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000110	000112	.+2	
000112	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000114	000116	.+2	
000116	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000120	000122	.+2	
000122	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000124	000126	.+2	
000126	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000130	000132	.+2	
000132	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000134	000136	.+2	
000136	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000140	000142	.+2	
000142	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000144	000146	.+2	
000146	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000150	000152	.+2	
000152	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION

000154	000156	.+2	
000156	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000160	000162	.+2	
000162	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000164	000166	.+2	
000166	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000170	000172	.+2	
000172	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000174	000176	.+2	
000176	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000200	000202	.+2	
000202	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000204	000206	.+2	
000206	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000210	000212	.+2	
000212	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000214	000216	.+2	
000216	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000220	000222	.+2	
000222	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000224	000226	.+2	
000226	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000230	000232	.+2	
000232	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000234	000236	.+2	
000236	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000240	000242	.+2	
000242	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000244	000246	.+2	
000246	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000250	000252	.+2	
000252	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000254	000256	.+2	
000256	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000260	000262	.+2	
000262	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000264	000266	.+2	
000266	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000270	000272	.+2	
000272	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000274	000276	.+2	
000276	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000300	000302	.+2	
000302	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000304	000306	.+2	
000306	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000310	000312	.+2	
000312	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000314	000316	.+2	
000316	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000320	000322	.+2	
000322	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000324	000326	.+2	
000326	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000330	000332	.+2	
000332	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION

H01

000334	000336	.+2	
000336	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000340	000342	.+2	
000342	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000344	000346	.+2	
000346	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000350	000352	.+2	
000352	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000354	000356	.+2	
000356	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000360	000362	.+2	
000362	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000364	000366	.+2	
000366	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000370	000372	.+2	
000372	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000374	000376	.+2	
000376	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000400	000402	.+2	
000402	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000404	000406	.+2	
000406	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000410	000412	.+2	
000412	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000414	000416	.+2	
000416	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000420	000422	.+2	
000422	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000424	000426	.+2	
000426	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000430	000432	.+2	
000432	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000434	000436	.+2	
000436	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000440	000442	.+2	
000442	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000444	000446	.+2	
000446	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000450	000452	.+2	
000452	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000454	000456	.+2	
000456	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000460	000462	.+2	
000462	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000464	000466	.+2	
000466	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000470	000472	.+2	
000472	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000474	000476	.+2	
000476	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000500	000502	.+2	
000502	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000504	000506	.+2	
000506	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000510	000512	.+2	
000512	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION



000514	000516	.+2	
000516	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000520	000522	.+2	
000522	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000524	000526	.+2	
000526	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000530	000532	.+2	
000532	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000534	000536	.+2	
000536	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000540	000542	.+2	
000542	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000544	000546	.+2	
000546	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000550	000552	.+2	
000552	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000554	000556	.+2	
000556	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000560	000562	.+2	
000562	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000564	000566	.+2	
000566	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000570	000572	.+2	
000572	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000574	000576	.+2	
000576	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000600	000602	.+2	
000602	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000604	000606	.+2	
000606	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000610	000612	.+2	
000612	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000614	000616	.+2	
000616	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000620	000622	.+2	
000622	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000624	000626	.+2	
000626	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000630	000632	.+2	
000632	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000634	000636	.+2	
000636	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000640	000642	.+2	
000642	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000644	000646	.+2	
000646	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000650	000652	.+2	
000652	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000654	000656	.+2	
000656	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000660	000662	.+2	
000662	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000664	000666	.+2	
000666	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION
000670	000672	.+2	
000672	000000	HALT	;ERROR! TRAPPED TO PREVIOUS LOCATION

```

000674 000676      .+2
000676 000000      HALT      ;ERROR! TRAPPED TO PREVIOUS LOCATION
000700 000702      .+2
000702 000000      HALT      ;ERROR! TRAPPED TO PREVIOUS LOCATION
000704 000706      .+2
000706 000000      HALT      ;ERROR! TRAPPED TO PREVIOUS LOCATION
000710 000712      .+2
000712 000000      HALT      ;ERROR! TRAPPED TO PREVIOUS LOCATION
000714 000716      .+2
000716 000000      HALT      ;ERROR! TRAPPED TO PREVIOUS LOCATION
000720 000722      .+2
000722 000000      HALT      ;ERROR! TRAPPED TO PREVIOUS LOCATION
000724 000726      .+2
000726 000000      HALT      ;ERROR! TRAPPED TO PREVIOUS LOCATION
000730 000732      .+2
000732 000000      HALT      ;ERROR! TRAPPED TO PREVIOUS LOCATION
000734 000736      .+2
000736 000000      HALT      ;ERROR! TRAPPED TO PREVIOUS LOCATION
000740 000742      .+2
000742 000000      HALT      ;ERROR! TRAPPED TO PREVIOUS LOCATION
000744 000746      .+2
000746 000000      HALT      ;ERROR! TRAPPED TO PREVIOUS LOCATION
000750 000752      .+2
000752 000000      HALT      ;ERROR! TRAPPED TO PREVIOUS LOCATION
000754 000756      .+2
000756 000000      HALT      ;ERROR! TRAPPED TO PREVIOUS LOCATION
000760 000762      .+2
000762 000000      HALT      ;ERROR! TRAPPED TO PREVIOUS LOCATION
000764 000766      .+2
000766 000000      HALT      ;ERROR! TRAPPED TO PREVIOUS LOCATION
000770 000772      .+2
000772 000000      HALT      ;ERROR! TRAPPED TO PREVIOUS LOCATION
000774 000776      .+2
000776 000000      HALT      ;ERROR! TRAPPED TO PREVIOUS LOCATION
                                .NLIST MC

```

```

000046 000046      .=46
000046 016036      LOGICAL
000052 000052      .=52
000052 040000      40000
000200 000200      .=0200
000200 000167 000576 JMP      START
000200 000260      .=260

```

```

001000 001000      =1000
001000 000000      ICNT: 0      ;CONTAINS THE PASS COUNT

001002 005067 177772 START: CLR      ICNT
001006 012706 000500 BEGIN: MOV      #STKPTR,%6      ;SET STACK PTR
001012 016737 177762 177570 MOV      ICNT,a#DISPLAY ;DISPLAY THE PASS COUNT
001020 032737 000400 177570 BIT      #400,a#SWR      ;LOAD MICRO BREAK REGISTER?
001026 001403 BEQ      +10
001030 113737 177570 177770 MOVB    a#SWR,a#UBREAK ;LOAD MICRO BREAK REG WITH SRD-7
001036 010701 SCOPE ;SCOPE STORES PC IN R1

```

;CHECK THAT A TRAP OCCURS ON A RESERVED INSTRUCTION (076000)

## K01

MAINDEC-11-DCKBM-E PDP11/45 TRAPS TEST. MACY11 27(732) 08-APR-76 10:45 PAGE 11  
DCKBME.P11

```

001040 012737 001056 000010      MOV      #RETA, @#RESVEC      ;RETURN LOCATION
001046 005037 000012      CLR      @#RESVEC+2
001052 076000      RESINST      ;RESERVED INSTRUCTION (SHOULT TRAP)
001054 000000      HLT      ;ERROR! RESERVED INSTRUCTION FAILED TO TRAP
001056 010701      RETA:    SCOPE      ;SCOPE STORES PC IN R1

;TEST DECREMENT OF STACK POINTER ON A TRAP OPERATION
001060 012706 000500      MOV      #STKPTR,%6      ;SET STACK PTR
001064 012737 001074 000010      MOV      #RETB, @#RESVEC      ;RETURN POINTER
001072 076000      RESINST      ;RESERVED INSTRUCTION
001074 020627 000474      RETB:    CMP      %6, #STKPTR-4      ;TEST DECREMENT OF %6
001100 001401      BEQ      .+4
001102 000000      HLT
001104 010701      SCOPE      ;NOT DECREMENTED TWO WORDS
;SCOPE STORES PC IN R1

;TEST THAT PROPER P.C. IS SAVED
001106 012706 000500      MOV      #STKPTR,%6      ;SET STACK PTR
001112 012737 001122 000010      MOV      #RETC, @#RESVEC      ;RETURN FROM TRAP POINTER
001120 076000      RESINST      ;TRAP ON THIS INSTRUCTION
001122 022737 001122 000474      RETC:    CMP      #, @#STKPTR-4      ;CHECK RETURN PC ON THE STACK
001130 001401      BEQ      .+4
001132 000000      HLT
001134 010701      SCOPE      ;INCORRECT P.C.
;SCOPE STORES PC IN R1

;TEST THAT "OLD" PSW AND PRIORITY ARE PLACED ON STACK
001136 010701      SCOPE      ;SCOPE STORES PC IN R1
001140 012706 000500      MOV      #STKPTR,%6      ;SET STACK PTR
001144 012737 001160 000010      MOV      #RETD, @#RESVEC      ;SET UP
001152 005037 177776      CLR      @#PSW      ;CLEAR PSW AND PRIORITY
001156 076000      RESINST      ;TRAP ON RESERVED INSTRUCTION
001160 016700 177312      RETD:    MOV      STKPTR-2,%0      ;GET SAVED STATUS & TEST FOR ALL 0'S
001164 001401      BEQ      .+4      ;BRANCH IF 0
001166 000000      HLT      ;ERROR! INCORRECT STATUS SAVED ON STACK
001170 010701      SCOPE      ;SCOPE STORES PC IN R1

001172 012706 000500      MOV      #STKPTR,%6      ;SET STACK PTR
001176 012737 001214 000010      MOV      #RETE, @#RESVEC      ;SET UP
001204 112737 000357 177776      MOVB     #357, @#PSW      ;PRE SET THE STATUS WORD
001212 076000      RESINST      ;RESERVED INSTRUCTION TRAP
001214 016700 177256      RETE:    MOV      STKPTR-2,%0      ;GET SAVED STATUS
001220 122700 000357      CMPB     #357,%0      ;SAVED STATUS CORRECT?
001224 001401      BEQ      .+4      ;BRANCH IF CORRECT
001226 000000      HLT      ;ERROR! INCORRECT STATUS WAS SAVED
001230 010701      SCOPE      ;SCOPE STORES PC IN R1

;TEST THAT "NEW" STATUS IS CORRECT
001232 012706 000500      MOV      #STKPTR,%6      ;INITIALIZE THE STACK POINTER
001236 012737 001260 000010      MOV      #RETF, @#RESVEC      ;SET UP VECTOR
001244 005037 000012      CLR      @#RESVEC+2      ;CLEAR 'NEW' STATUS WORD
001250 112737 000357 177776      MOVB     #357, @#PSW      ;PRE SET THE STATUS WORD
001256 076000      RESINST      ;DO A RESERVED INTRUCTION
001260 013700 177776      RETF:    MOV      @#PSW,%0      ;GET & TEST THE 'NEW' STATUS WORD
001264 001401      BEQ      .+4      ;BRANCH IF ALL 0'S
001266 000000      HLT      ;ERROR! 'NEW' STATUS WAS INCORRECT
001270 005037 177776      CLR      @#PSW
001274 010701      SCOPE      ;SCOPE STORES PC IN R1

```

001276	012706	000500		MOV	#STKPTR,%6	;SET UP THE STACK POINTER	
001302	012737	001324	000010	MOV	#RETG,@#RESVEC		
001310	012737	004357	000012	MOV	#4357,@#RESVEC+2	;LOAD THE NEW STATUS WORD	
001316	005037	177776		CLR	@#PSW	;PRE SET THE STATUS WORD	
001322	076000			RESINST		;DO A RESERVED INSTRUCTION	
					*****NOTE: R0 IS UPPER R0 *****		
001324	013700	177776		RETG:	MOV	@#PSW,%0	;GET THE 'NEW' STATUS WORD
001330	022700	004357			CMP	#4357,%0	;WAS 'NEW' STATUS CORRECTLY LOADED
001334	001401				BEQ	.+4	;BRANCH IF CORRECT
001336	000000				HLT		;ERROR! 'NEW' STATUS WAS INCORRECT
001340	010701				SCOPE		;SCOPE STORES PC IN R1
001342	012737	000006	000010	MOV	#6,@#RESVEC	;RESTORE RESERVED INSTRUCTION	
001350	005037	000012		CLR	@#RESVEC+2	;TO HALT AT 6	

```

;TEST THAT A TRAP OCCURES FOR A "TRAP" INSTRUCTION
001354 010701          SCOPE          ;SCOPE STORES PC IN R1
001356 012706 000500  MOV          #STKPTR,%6          ;STACK POINTER SETUP
001362 012737 001400 000034  MOV          #RETA1,@#TRAPVEC      ;RETURN LOCATION
001370 005037 000036  CLR          @#TRAPVEC+2
001374 104400          TRAP          ;DO A TRAP INSTRUCTION
001376 000000          HLT
001400 010701  RETA1:  SCOPE          ;SCOPE STORES PC IN R1

;TEST DECREMENT OF STACK POINTER ON A TRAP OPERATION
001402 012706 000500          MOV          #STKPTR,%6          ;STACK POINTER SETUP
001406 012737 001416 000034  MOV          #RETB1,@#TRAPVEC      ;RETURN POINTER
001414 104400          TRAP          ;DO A TRAP INSTRUCTION
001416 020627 000474  RETB1:  CMP          %6,#STKPTR-4    ;TEST DECREMENT OF %6
001422 001401          BEQ          .+4
001424 000000          HLT
001426 010701          SCOPE          ;SCOPE STORES PC IN R1

;TEST THAT PROPER P.C. IS SAVED
001430 012706 000500          MOV          #STKPTR,%6          ;STACK POINTER SETUP
001434 012737 001444 000034  MOV          #RETC1,@#TRAPVEC      ;RETURN FROM TRAP POINTER
001442 104400          TRAP          ;TRAP ON THIS INSTRUCTION
001444 022767 001444 177022  RETC1:  CMP          #.#STKPTR-4    ;CHECK INCREMENTED P.C.
001452 001401          BEQ          .+4
001454 000000          HLT
001456 010701          SCOPE          ;INCORRECT P.C.
;SCOPE STORES PC IN R1

;TEST THAT "OLD" PSW & PRIORITY ARE PLACED ON STACK
001460 010701          SCOPE          ;SCOPE STORES PC IN R1
001462 012706 000500          MOV          #STKPTR,%6          ;SET UP
001466 012737 001502 000034  MOV          #RETD1,@#TRAPVEC      ;SET UP
001474 005037 177776  CLR          @#PSW          ;CLEAR PSW AND PRIORITY
001500 104400          TRAP          ;DO A TRAP INSTRUCTION
001502 016700 176770  RETD1:  MOV          STKPTR-2,%0    ;GET & TEST THE SAVED STATUS
001506 001401          BEQ          .+4          ;BRANCH IF ALL 0'S
001510 000000          HLT          ;ERROR! SAVED STATUS IS INCORRECT
001512 010701          SCOPE          ;SCOPE STORES PC IN R1

;INITIALIZE THE STACK POINTER
001514 012706 000500          MOV          #STKPTR,%6          ;INITIALIZE THE STACK POINTER
001520 012737 001536 000034  MOV          #RETE1,@#TRAPVEC      ;SET UP
001526 012737 000357 177776  MOV          #357,@#PSW          ;PRE SET THE STATUS WORD
001534 104400          TRAP          ;DO A TRAP INSTRUCTION
001536 016700 176734  RETE1:  MOV          STKPTR-2,%0    ;GET THE SAVED STATUS WORD
001542 022700 000357  CMP          #357,%0          ;WAS CORRECT STATUS SAVED ON THE STACK
001546 001401          BEQ          .+4          ;BRANCH IF CORRECT
001550 000000          HLT          ;ERROR! INCORRECT STATUS SAVED ON STACK
001552 010701          SCOPE          ;SCOPE STORES PC IN R1

;TEST THAT "NEW" STATUS IS CORRECT
001554 012706 000500          MOV          #STKPTR,%6          ;INITIALIZE THE STACK POINTER
001560 012737 001602 000034  MOV          #RETF1,@#TRAPVEC      ;SET UP
001566 005037 000036  CLR          @#TRAPVEC+2          ;PRE SET THE STATUS WORD
001572 012737 000357 177776  MOV          #357,@#PSW
001600 104400          TRAP
001602 013700 177776  RETF1:  MOV          @#PSW,%0          ;GET THE 'NEW' STATUS WORD
001606 001401          BEQ          .+4          ;BRANCH IF ALL 0'S

```

```

001610 000000          HLT          ;ERROR! INCORRECT 'NEW' STATUS LOADED
001612 005037 177776  CLR          ;SCOPE STORES PC IN R1
001616 010701          SCOPE

001620 012706 000500          MOV          #STKPTR,%6
001624 012737 001646 000034  MOV          #RETG1,%#TRAPVEC
001632 012737 004357 000036  MOV          #4357,%#TRAPVEC+2 ;LOAD 'NEW' STATUS WORD
001640 005037 177776          CLR          ;PRE SET THE STATUS WORD
001644 104400          TRAP        ;DO A TRAP INSTRUCTION
001646 013700 177776          RETG1: MOV      ;GET THE 'NEW' STATUS
001652 022700 004357          CMP          ;IS IT CORRECT?
001656 001401          BEQ          ;BRANCH IF CORRECT
001660 000000          HLT          ;ERROR! 'NEW' STATUS WAS INCORRECT
001662 005037 177776          CLR          ;SCOPE STORES PC IN R1
001666 010701          SCOPE

;TEST THAT ALL COMBINATION OF "TRAP" WILL CAUSE A TRAP
001670 012767 104400 000012  MOV          #TRAP,RB1 ;INITIALIZE BASE TRAP INSTRUCTION
001676 012767 001714 176130  MOV          #RA1,34 ;RETURN FROM TRAP TO RA1
001704 012706 000500          RC1: MOV      ;SET UP STACK POINTER
001710 104400          RB1: TRAP    ;TRAP INST WILL BE MODIFIED TO TRAP+377
001712 000000          HLT        ;PREVIOUS INST FAILED TO TRAP
001714 005267 177770          RA1: INC     ;INCREMENT TRAP INSTRUCTION
001720 022767 104777 177762  CMP          #104777,RB1 ;TRAP+377 TO UPPER LIMIT
001726 103366          BHIS      ;HAVE WE TESTED ALL
001730 010701          SCOPE    ;SCOPE STORES PC IN R1

001732 012737 000036 000034  MOV          #TRAPVEC+2,%#TRAPVEC ;RESTORE TRAP VECTOR TO
001740 005037 000036          CLR          ;HALT AT 36

```

```

;TEST THAT A TRAP OCCURES ON AN "IOT" INSTRUCTION
001744 010701          SCOPE          ;SCOPE STORES PC IN R1
001746 012706 000500  MOV          #STKPTR,%6      ;STACK POINTER SETUP
001752 012737 001770 000020  MOV          #RETA2,%IOTVEC      ;RETURN LOCATION
001760 005037 000022  CLR          %IOTVEC+2
001764 000004  IOT
001766 000000  HLT
001770 010701  RETA2:  SCOPE          ;SCOPE STORES PC IN R1

;TEST DECREMENT OF STACK POINTER ON A TRAP OPERATION
001772 012706 000500  MOV          #STKPTR,%6      ;STACK POINTER SETUP
001776 012737 002006 000020  MOV          #RETB2,%IOTVEC     ;RETURN POINTER
002004 000004  IOT
002006 020627 000474  RETB2:  CMP          %6,#STKPTR-4      ;TEST DECREMENT OF %6
002012 001401  BEQ          .+4
002014 000000  HLT
002016 010701  SCOPE          ;SCOPE STORES PC IN R1

;TEST THAT PROPER P.C. IS SAVED
002020 012706 000500  MOV          #STKPTR,%6      ;STACK POINTER SETUP
002024 012737 002034 000020  MOV          #RETC2,%IOTVEC     ;RETURN FROM TRAP POINTER
002032 000004  IOT          ;TRAP ON THIS INSTRUCTION
002034 022767 002034 176432  RETC2:  CMP          #.STKPTR-4      ;CHECK FOR INCREMENTED P.C.
002042 001401  BEQ          .+4
002044 000000  HLT
002046 010701  SCOPE          ;INCORRECT P.C.
;SCOPE STORES PC IN R1

;TEST THAT "OLD" CC AND PRIORITY ARE PLACED ON STACK
002050 010701          SCOPE          ;SCOPE STORES PC IN R1
002052 012706 000500  MOV          #STKPTR,%6      ;SET UP
002056 012737 002072 000020  MOV          #RETD2,%IOTVEC     ;SET UP
002064 005037 177776  CLR          %PSW          ;CLEAR CC AND PRIORITY
002070 000004  IOT          ;TRAP
002072 016700 176400  RETD2:  MOV          STKPTR-2,%0      ;GET & TEST SAVED STATUS
002076 001401  BEQ          .+4          ;BRANCH IF ALL 0'S
002100 000000  HLT          ;ERROR! INCORRECT STATUS SAVED ON STACK
002102 010701  SCOPE          ;SCOPE STORES PC IN R1

002104 012706 000500  MOV          #STKPTR,%6      ;SET UP
002110 012737 002126 000020  MOV          #RETE2,%IOTVEC     ;SET UP
002116 012737 000357 177776  MOV          #357,%PSW        ;PRE SET STATUS
002124 000004  IOT
002126 016700 176344  RETE2:  MOV          STKPTR-2,%0      ;GET SAVED STATUS
002132 022700 000357  CMP          #357,%0          ;SAVED STATUS CORRECT?
002136 001401  BEQ          .+4          ;BRANCH IF CORRECT
002140 000000  HLT          ;ERROR! INCORRECT STATUS SAVED ON STACK
002142 010701  SCOPE          ;SCOPE STORES PC IN R1

;TEST THAT "NEW" STATUS IS CORRECT
002144 012706 000500  MOV          #STKPTR,%6
002150 012737 002172 000020  MOV          #RETF2,%IOTVEC
002156 005037 000022  CLR          %IOTVEC+2      ;CLEAR FUTURE PSW
002162 012737 004357 177776  MOV          #4357,%PSW      ;PRE SET STATUS
002170 000004  IOT
002172 013700 177776  RETF2:  MOV          %PSW,%0
002176 001401  BEQ          .+4          ;GET & TEST 'NEW' STATUS
;BRANCH IF CORRECT

```

002200	000000			HLT					;ERROR! 'NEW' STATUS IS INCORRECT
002202	005037	177776		CLR	2#PSW				
002206	010701			SCOPE					;SCOPE STORES PC IN R1
002210	012706	000500		MOV	#STKPTR,%6				
002214	012737	002236	000020	MOV	#RETG2,2#IOTVEC				
002222	012737	000357	000022	MOV	#357,2#IOTVEC+2				;LOAD 'NEW' STATUS
002230	005037	177776		CLR	2#PSW				;PRE SET STATUS
002234	000004			IOT					
002236	013700	177776		MOV	2#PSW,%0	RETG2:			;GET THE 'NEW' STATUS
002242	022700	000357		CMP	#357,%0				;IS 'NEW' STATUS CORRECT
002246	001401			BEQ	+.4				;BRANCH IF CORRECT
002250	000000			HLT					;ERROR! 'NEW' STATUS IS INCORRECT
002252	010701			SCOPE					;SCOPE STORES PC IN R1
002254	012737	000022	000020	MOV	#IOTVEC+2,2#IOTVEC				;RESTORE IOT TRAP VECTOR
002262	005037	000022		CLR	2#IOTVEC+2				;TO HALT AT 22



```

;TEST THAT A TRAP OCCURES ON AN EMT INSTRUCTION
002266 012706 000500          MOV      #STKPTR,%6          ;STACK POINTER SETUP
002272 012737 002310 000030  MOV      #RETA3,@#EMTVEC      ;RETURN LOCATION
002300 005037 000032          CLR      @#EMTVEC+2
002304 104000          EMT
002306 000000          HLT
002310 010701          RETA3: SCOPE          ;SCOPE STORES PC IN R1

;TEST DECREMENT OF STACK POINTER ON A TRAP OPERATION
002312 012706 000500          MOV      #STKPTR,%6          ;STACK POINTER SETUP
002316 012737 002326 000030  MOV      #RETB3,@#EMTVEC      ;RETURN POINTER
002324 104000          EMT
002326 020627 000474          RETB3: CMP      %6,#STKPTR-4      ;TEST DECREMENT OF %6
002332 001401          BEQ      .+4
002334 000000          HLT
002336 010701          SCOPE          ;SCOPE STORES PC IN R1

;TEST THAT PROPER P.C IS SAVED
002340 012706 000500          MOV      #STKPTR,%6          ;STACK POINTER SETUP
002344 012737 002354 000030  MOV      #RETC3,@#EMTVEC      ;RETURN FROM TRAP POINTER
002352 104000          EMT          ;TRAP ON THIS INSTRUCTION
002354 022767 002354 176112  RETC3: CMP      #.#STKPTR-4      ;CHECK FOR INCREMENTED P.C.
002362 001401          BEQ      .+4
002364 000000          HLT
002366 010701          SCOPE          ;SCOPE STORES PC IN R1

;TEST THAT "OLD" PSW AND PRIORITY ARE PLACED ON STACK
002370 012706 000500          MOV      #STKPTR,%6          ;SET UP
002374 012737 002410 000030  MOV      #RETD3,@#EMTVEC      ;SET UP
002402 005037 177776          CLR      @#PSW          ;CLEAR PSW
002406 104000          EMT          ;TRAP
002410 016700 176062          RETD3: MOV      STKPTR-2,%0      ;GET THE SAVED STATUS
002414 001401          BEQ      .+4          ;BRANCH IF SAVED STATUS IS CORRECT
002416 000000          HLT          ;ERROR! SAVED STATUS IS INCORRECT
002420 010701          SCOPE          ;SCOPE STORES PC IN R1

;TEST THAT "OLD" PSW AND PRIORITY ARE PLACED ON STACK
002422 012706 000500          MOV      #STKPTR,%6          ;SET UP
002426 012737 002444 000030  MOV      #RETE3,@#EMTVEC      ;SET UP
002434 012737 000357 177776  MOV      #357,@#PSW          ;PRE SET STATUS
002442 104000          EMT
002444 016700 176026          RETE3: MOV      STKPTR-2,%0      ;GET THE SAVED STATUS
002450 022700 000357          CMP      #357,%0          ;SAVED STATUS CORRECT?
002454 001401          BEQ      .+4          ;BRANCH IF CORRECT
002456 000000          HLT          ;ERROR! SAVED STATUS IS INCORRECT
002460 010701          SCOPE          ;SCOPE STORES PC IN R1

;TEST THAT "NEW" STATUS IS CORRECT
002462 012706 000500          MOV      #STKPTR,%6          ;SET UP
002466 012737 002510 000030  MOV      #RETF3,@#EMTVEC      ;SET UP
002474 005037 000032          CLR      @#EMTVEC+2          ;CLEAR FUTURE PSW
002500 012737 000357 177776  MOV      #357,@#PSW          ;PRE SET THE STATUS WORD
002506 104000          EMT
002510 013700 177776          RETF3: MOV      @#PSW,%0          ;GET THE 'NEW' STATUS
002514 001401          BEQ      .+4          ;BRANCH IF 'NEW' STATUS IS CORRECT
002516 000000          HLT          ;ERROR! 'NEW' STATUS IS INCORRECT
002520 010701          SCOPE          ;SCOPE STORES PC IN R1

```

```

002522 012706 000500          MOV      #STKPTR,%6
002526 012737 002550 000030  MOV      #RETG3,%0EMTVEC
002534 012737 000357 000032  MOV      #357,%0EMTVEC+2 ;LOAD 'NEW' STATUS
002542 005037 177776          CLR      @PSW ;PRE SET THE STATUS
002546 104000          EMT
002550 013700 177776          RETG3: MOV      @PSW,%0 ;GET THE 'NEW' STATUS
002554 022700 000357          CMP      #357,%0 ;IS IT CORRECT
002560 001401          BEQ      .+4 ;BRANCH IF CORRECT
002562 000000          HLT
002564 010701          SCOPE ;ERROR! 'NEW' STATUS IS INCORRECT
                                ;SCOPE STORES PC IN R1

                                ;TEST THAT ALL COMBINATION OF EMT WILL CAUSE A TRAP
002566 010701          SCOPE ;SCOPE STORES PC IN R1
002570 012767 104000 000012  MOV      #EMT,RB ;INITIALIZE BASE EMT INSTRUCTION
002576 012767 002614 175224  MOV      #RA,30 ;RETURN FROM TRAP TO RA
002604 012706 000500          RC: MOV      #STKPTR,%6 ;SET UP STACK POINTER
002610 104000          RB: EMT ;TRAP INST. WILL BE MODIFIED TO EMT+377
002612 000000          HLT ;PREVIOUS INST FAILED TO TRAP
002614 005267 177770          RA: INC      RB ;INCREMENT TRAP INSTRUCTION
002620 022767 104377 177762  CMP      #104377,RB ;EMT+377 TO EMT?
002626 103366          BHIS   RC ;HAVE WE TESTED ALL
002630 010701          SCOPE ;SCOPE STORES PC IN R1
002632 012737 000032 000030  MOV      #EMTVEC+2,%0EMTVEC ;RESTORE EMT TRAP TO HALT
002640 005037 000032          CLR      @EMTVEC+2 ;AT 32

```

```

;TEST THAT A TRAP OCCURS ON AN BPT INSTRUCTION
002644 012706 000500          ;TEST THAT A TRAP OCCURS ON AN BPT INSTRUCTION
002650 012767 002666 175136  MOV      #STKPTR,%6          ;STACK POINTER SETUP
002656 005067 175134          MOV      #RETA4,BPTVEC      ;RETURN LOCATION
002662 000003          CLR      BPTVEC+2
002664 000000          BPT                                ;TRACE TRAP
002666 010701          HLT
RETA4: SCOPE                                ;SCOPE STORES PC IN R1

;TEST DECREMENT OF STACK POINTER ON A TRAP OPERATION
002670 012706 000500          ;TEST DECREMENT OF STACK POINTER ON A TRAP OPERATION
002674 012767 002704 175112  MOV      #STKPTR,%6          ;STACK POINTER SETUP
002702 000003          MOV      #RETB4,BPTVEC      ;RETURN POINTER
002704 020627 000474          BPT                                ;RESERVED INSTRUCTION
002710 001401          RETB4: CMP      %6,#STKPTR-4 ;TEST DECREMENT OF %6
002712 000000          BEQ      .+4
002714 010701          HLT                                ;NOT DECREMENTED TWO WORDS
SCOPE                                ;SCOPE STORES PC IN R1

;TEST THAT PROPER P.C. IS SAVED
002716 012706 000500          ;TEST THAT PROPER P.C. IS SAVED
002722 012767 002732 175064  MOV      #STKPTR,%6          ;STACK POINTER SETUP
002730 000003          MOV      #RETC4,BPTVEC      ;RETURN FROM TRAP POINTER
002732 022767 002732 175534  BPT                                ;TRAP ON THIS INSTRUCTION
RETC4: CMP      #.STKPTR-4      ;CHECK FOR INCREMENTED P.C.
002740 001401          BEQ      .+4
002742 000000          HLT                                ;INCORRECT P.C.
002744 010701          SCOPE                            ;SCOPE STORES PC IN R1

;TEST THAT "OLD" PSW IS PLACED ON THE STACK
002746 010701          ;TEST THAT "OLD" PSW IS PLACED ON THE STACK
002750 012706 000500          SCOPE                            ;SCOPE STORES PC IN R1
002754 012767 002770 175032  MOV      #STKPTR,%6          ;SET UP
002762 005037 177776          MOV      #RETD4,BPTVEC      ;LOAD VECTOR
002766 000003          CLR      @#PSW              ;CLEAR PSW
002770 016700 175502          BPT
RETD4: MOV      STKPTR-2,%0      ;GET SAVED STATUS OFF STACK
002774 001401          BEQ      .+4                ;BRANCH IF ALL 0'S
002776 000000          HLT                                ;ERROR! SAVED STATUS IS INCORRECT
003000 010701          SCOPE                            ;SCOPE STORES PC IN R1

;TEST THAT "NEW" STATUS IS CORRECT
003002 012706 000500          ;TEST THAT "NEW" STATUS IS CORRECT
003006 012767 003024 175000  MOV      #STKPTR,%6          ;SET UP
003014 012737 000357 177776  MOV      #RETE4,BPTVEC      ;SET UP
003022 000003          MOV      #357,@#PSW        ;PRE SET STATUS
003024 016700 175446          BPT
RETE4: MOV      STKPTR-2,%0      ;GET THE SAVED STATUS
003030 022700 000357          CMP      #357,%0          ;IS IT CORRECT?
003034 001401          BEQ      .+4                ;BRANCH IF CORRECT
003036 000000          HLT                                ;ERROR! SAVED STATUS IS INCORRECT
003040 010701          SCOPE                            ;SCOPE STORES PC IN R1

;TEST THAT "NEW" STATUS IS CORRECT
003042 012706 000500          ;TEST THAT "NEW" STATUS IS CORRECT
003046 012767 003070 174740  MOV      #STKPTR,%6          ;CLEAR FUTURE PSW
003054 005067 174736          MOV      #RETF4,BPTVEC      ;PRE SET STATUS
003060 012737 000357 177776  CLR      BPTVEC+2
003066 000003          MOV      #357,@#PSW
003070 013700 177776          BPT
RETF4: MOV      @#PSW,%0        ;GET & TEST 'NEW' STATUS
003074 001401          BEQ      .+4                ;BRANCH IF ALL 0'S

```

003076	000000			HLT			;ERROR! 'NEW' STATUS IS INCORRECT
003100	005037	177776		CLR	@#PSW		
003104	010701			SCOPE			;SCOPE STORES PC IN R1
003106	012706	000500		MOV	#STKPTR,%6		
003112	012767	003134	174674	MOV	#RETG4,BPTVEC		
003120	012767	000357	174670	MOV	#357,BPTVEC+2		;LOAD 'NEW' STATUS
003126	005037	177776		CLR	@#PSW		;PRE SET STATUS
003132	000003			BPT			
003134	013700	177776		RETG4: MOV	@#PSW,%0		;GET THE 'NEW' STATUS
003140	022700	000357		CMP	#357,%0		;IS IT CORRECT
003144	001401			BEQ	.+4		;BRANCH IF CORRECT
003146	000000			HLT			;ERROR! 'NEW' STATUS IS INCORRECT
003150	005037	177776		CLR	@#PSW		
003154	010701			SCOPE			;SCOPE STORES PC IN R1
003156	012767	000016	174630	MOV	#BPTVEC+2,BPTVEC		;RESTORE 'BPT' TRAP
003164	005037	000016		CLR	@#BPTVEC+2		

```

;TEST THAT A TRAP OCCURS ON AN ILLEGAL INSTRUCTION
003170 010701          SCOPE          ;SCOPE STORES PC IN R1
003172 012706 000500  MOV          #STKPTR,%6 ;STACK POINTER SETUP
003176 012737 003214 000010 MOV          #RETAS,%RESVEC ;RETURN LOCATION
003204 005037 000012  CLR          @#RESVEC+2
003210 000100  JMP          %0 ;ILLEGAL INSTRUCTION, SHOULD TRAP
003212 000000  HLT
003214 010701  RETAS:  SCOPE          ;SCOPE STORES PC IN R1

;TEST DECREMENT OF STACK POINTER ON A TRAP OPERATION
003216 012706 000500  MOV          #STKPTR,%6 ;STACK POINTER SETUP
003222 012737 003232 000010 MOV          #RETB5,%RESVEC ;RETURN POINTER
003230 000101  JMP          %1 ;RESERVED INSTRUCTION
003232 020627 000474  RETB5:  CMP          %6,#STKPTR-4 ;TEST DECREMENT OF %6
003236 001401  BEQ          .+4
003240 000000  HLT
003242 010701  SCOPE          ;NOT DECREMENTED TWO WORDS
;SCOPE STORES PC IN R1

;TEST THAT PROPER P.C. IS SAVED
003244 012706 000500  MOV          #STKPTR,%6 ;STACK POINTER SETUP
003250 012737 003260 000010 MOV          #RETC5,%RESVEC ;RETURN FROM TRAP POINTER
003256 000102  JMP          %2 ;TRAP ON THIS INSTRUCTION
003260 022767 003260 175206 RETC5:  CMP          #.#STKPTR-4 ;CHECK FOR INCREMENTED P.C.
003266 001401  BEQ          .+4
003270 000000  HLT
003272 010701  SCOPE          ;INCORRECT P.C.
;SCOPE STORES PC IN R1

;TEST THAT "OLD" PSW IS PLACED ON THE STACK
003274 010701          SCOPE          ;SCOPE STORES PC IN R1
003276 012706 000500  MOV          #STKPTR,%6 ;SET UP
003302 012737 003316 000010 MOV          #RETD5,%RESVEC ;SET UP
003310 005037 177776  CLR          @#PSW ;CLEAR PSW
003314 000103  JMP          %3 ;TRAP
003316 016700 175154  RETD5:  MOV          STKPTR-2,%0 ;GET THE SAVED STATUS
003322 001401  BEQ          .+4 ;BRANCH IF ALL 0'S
003324 000000  HLT ;ERROR! SAVED STATUS IS INCORRECT
003326 010701  SCOPE          ;SCOPE STORES PC IN R1

003330 012706 000500  MOV          #STKPTR,%6 ;SET UP
003334 012737 003352 000010 MOV          #RETES,%RESVEC ;SET UP
003342 012737 000357 177776 MOV          #357,@#PSW ;PRE SET STATUS
003350 000104  JMP          %4
003352 016700 175120  RETES:  MOV          STKPTR-2,%0 ;GET THE SAVED STATUS
003356 022700 000357  CMP          #357,%0 ;IS IT CORRECT
003362 001401  BEQ          .+4 ;BRANCH IF SAVED STATUS IS CORRECT
003364 000000  HLT ;ERROR! SAVED STATUS IS INCORRECT
003366 010701  SCOPE          ;SCOPE STORES PC IN R1

;TEST THAT "NEW" STATUS IS CORRECT
003370 012706 000500  MOV          #STKPTR,%6
003374 012737 003416 000010 MOV          #RETF5,%RESVEC
003402 005037 000012  CLR          @#RESVEC+2
003406 012737 000357 177776 MOV          #357,@#PSW ;PRE SET STATUS
003414 000105  JMP          %5
003416 013700 177776  RETF5:  MOV          @#PSW,%0 ;GET & TEST 'NEW' STATUS
003422 001401  BEQ          .+4

```

003424	000000			HLT					;ERROR! 'NEW' STATUS IS INCORRECT
003426	005037	177776		CLR	@#PSW				
003432	010701			SCOPE					;SCOPE STORES PC IN R1
003434	012706	000500		MOV	#STKPTR,%6				
003440	012737	003462	000010	MOV	#RETGS,@#RESVEC				
003446	012737	000357	000012	MOV	#357,@#RESVEC+2				;LOAD 'NEW' STATUS
003454	005037	177776		CLR	@#PSW				;PRE SET STATUS
003460	000106			JMP	%6				
003462	013700	177776		MOV	@#PSW,%0		RETGS:		;GET THE 'NEW' STATUS
003466	022700	000357		CMP	#357,%0				;IS IT CORRECT
003472	001401			BEQ	+.4				;BRANCH IF CORRECT
003474	000000			HLT					;ERROR! 'NEW' STATUS IS INCORRECT
003476	005037	177776		CLR	@#PSW				
003502	010701			SCOPE					;SCOPE STORES PC IN R1

```

;TEST THAT A TRAP OCCURES ON ALL ILLEGAL INSTRUCTION
003504 012706 000500          MOV      #STKPTR,%6      ;STACK POINTER SETUP
003510 012737 003526 000010  MOV      #RETH5,@#RESVEC ;RETURN LOCATION
003516 005037 000012          CLR      @#RESVEC+2
003522 004000          JSR      %0,%0          ;ILLEGAL INSTRUCTION (SHOULD TRAP)
003524 000000          HLT
003526 010701          RETH5:  SCOPE          ;SCOPE STORES PC IN R1

;TEST DECREMENT OF STACK POINTER ON A TRAP OPERATION
003530 012706 000500          MOV      #STKPTR,%6      ;STACK POINTER SETUP
003534 012737 003544 000010  MOV      #RETJ,@#RESVEC ;RETURN POINTER
003542 004101          JSR      %1,%1          ;RESERVED INSTRUCTION
003544 020627 000474          RETJ:  CMP      %6,#STKPTR-4 ;TEST DECREMENT OF %6
003550 001401          BEQ      .+4
003552 000000          HLT
003554 010701          SCOPE          ;NOT DECREMENTED TWO WORDS
;SCOPE STORES PC IN R1

;TEST THAT PROPER P.C. IS SAVED
003556 012706 000500          MOV      #STKPTR,%6      ;STACK POINTER SETUP
003562 012737 003572 000010  MOV      #RETK,@#RESVEC ;RETURN FROM TRAP POINTER
003570 004202          INSTK: JSR      %2,%2          ;TRAP ON THIS INSTRUCTION
003572 022767 003572 174674  RETK:  CMP      #INSTK+2,STKPTR-4 ;CHECK FOR INCREMENTED P.C.
003600 001401          BEQ      .+4
003602 000000          HLT
003604 010701          SCOPE          ;INCORRECT P.C.
;SCOPE STORES PC IN R1

;TEST THAT "OLD" PSW IS SAVED ON THE STACK
003606 010701          SCOPE          ;SCOPE STORES PC IN R1
003610 012706 000500          MOV      #STKPTR,%6      ;SET UP
003614 012737 003630 000010  MOV      #RETL,@#RESVEC ;SET UP
003622 005037 177776          CLR      @#PSW          ;CLEAR PSW
003626 004303          JSR      %3,%3
003630 016700 174642          RETL:  MOV      STKPTR-2,%0 ;GET & TEST SAVED STATUS
003634 001401          BEQ      .+4          ;BRANCH IF ALL 0'S
003636 000000          HLT
003640 010701          SCOPE          ;ERROR! INCORRECT STATUS SAVED ON STACK
;SCOPE STORES PC IN R1

003642 012706 000500          MOV      #STKPTR,%6      ;SET UP
003646 012737 003664 000010  MOV      #RETM,@#RESVEC ;SET UP
003654 012737 000357 177776          MOV      #357,@#PSW      ;PRE SET STATUS
003662 004404          JSR      %4,%4
003664 016700 174606          RETM:  MOV      STKPTR-2,%0 ;GET SAVED STATUS
003670 022700 000357          CMP      #357,%0          ;IS IT CORRECT
003674 001401          BEQ      .+4
003676 000000          HLT
003700 010701          SCOPE          ;ERROR! INCORRECT STATUS SAVED ON STACK
;SCOPE STORES PC IN R1

;TEST THAT "NEW" STATUS IS CORRECT
003702 012706 000500          MOV      #STKPTR,%6
003706 012737 003730 000010  MOV      #RETN,@#RESVEC
003714 005037 000012          CLR      @#RESVEC+2
003720 012737 000357 177776          MOV      #357,@#PSW      ;PRE SET STATUS
003726 004505          JSR      %5,%5
003730 013700 177776          RETN:  MOV      @#PSW,%0
003734 001401          BEQ      .+4          ;BRANCH IF ALL 0'S

```

```

003736 000000          HLT                ;ERROR! 'NEW' STATUS IS INCORRECT
003740 005037 177776  CLR                @#PSW
003744 010701          SCOPE              ;SCOPE STORES PC IN R1

003746 012706 000500  MOV                #STKPTR,%6
003752 012737 003774 000010  MOV                #RETO,@#RESVEC
003760 012737 000357 000012  MOV                #357,@#RESVEC+2 ;LOAD 'NEW' STATUS
003766 005037 177776  CLR                @#PSW          ;PRE SET STATUS
003772 004606          JSR                %6,%6
003774 013700 177776          RETO:  MOV            @#PSW,%0          ;GET THE 'NEW' STATUS
004000 022700 000357          CMP                #357,%0        ;IS IT CORRECT
004004 001401          BEQ                .+4            ;BRANCH IF CORRECT
004006 000000          HLT                ;ERROR! 'NEW' STATUS IS INCORRECT
004010 012737 000012 000010  MOV                #RESVEC+2,@#RESVEC
004016 005037 000012          CLR                @#RESVEC+2
004022 010701          SCOPE              ;SCOPE STORES PC IN R1

```



```

;TEST THAT A TRAP OCCURES ON AN ILLEGAL ADDRESS
004024 012706 000500
004030 012737 004050 000004
004036 005037 000006
004042 005767 173733
004046 000000
004050 010701
MOV #STKPTR,%6 ;STACK POINTER SETUP
MOV #RETP,@ERRVEC ;SET TRAP VECTOR
CLR @ERRVEC+2
TST 1 ;ILL.ADRS. (ODD ADDRESS ON WORD INST.)
HLT ;ILLEGAL ADDRESS DID NOT TRAP
RETP: SCOPE ;SCOPE STORES PC IN R1

;TEST DECREMENT OF STACK POINTER ON A TRAP OPERATION
004052 012706 000500
004056 012737 004070 000004
004064 005767 173711
004070 020627 000474
004074 001401
004076 000000
004100 010701
MOV #STKPTR,%6 ;STACK POINTER SETUP
MOV #RETR,@ERRVEC ;RETURN POINTER
TST 1 ;RESERVED INSTRUCTION
RETR: CMP %6,#STKPTR-4 ;TEST DECREMENT OF %6
BEQ .+4
HLT ;NOT DECREMENTED TWO WORDS
SCOPE ;SCOPE STORES PC IN R1

;TEST THAT PROPER P.C. IS SAVED
004102 012706 000500
004106 012737 004120 000004
004114 005767 173661
004120 022767 004120 174346
004126 001401
004130 000000
004132 010701
MOV #STKPTR,%6 ;STACK POINTER SETUP
MOV #RETR,@ERRVEC ;RETURN FROM TRAP POINTER
TST 1 ;TRAP ON THIS INSTRUCTION
RETR: CMP #.#,STKPTR-4 ;CHECK FOR INCREMENTED P.C.
BEQ .+4
HLT ;INCORRECT P.C.
SCOPE ;SCOPE STORES PC IN R1

;TEST THAT "OLD" PSW IS PLACED ON THE STACK
004134 012706 000500
004140 012737 004156 000004
004146 005037 177776
004152 005767 173623
004156 016700 174314
004162 001401
004164 000000
004166 010701
MOV #STKPTR,%6 ;SET UP
MOV #RETS,@ERRVEC ;SET UP
CLR @PSW
TST 1
RETS: MOV STKPTR-2,%0 ;GET & TEST SAVED STATUS ON STACK
BEQ .+4 ;BRANCH IF SAVED STATUS IS CORRECT
HLT ;ERROR! SAVED STATUS IS INCORRECT
SCOPE ;SCOPE STORES PC IN R1

004170 012706 000500
004174 012737 004214 000004
004202 012737 000357 177776
004210 005767 173565
004214 016700 174256
004220 022700 000357
004224 001401
004226 000000
004230 010701
MOV #STKPTR,%6 ;SET UP
MOV #RETT,@ERRVEC ;SET UP
MOV #357,@PSW ;PRE SET STATUS
TST 1
RETT: MOV STKPTR-2,%0 ;GET THE SAVED STATUS OFF STACK
CMP #357,%0 ;IS IT CORRECT
BEQ .+4 ;BRANCH IF CORRECT
HLT ;ERROR! SAVED STATUS ON STACK IS INC.
SCOPE ;SCOPE STORES PC IN R1

;TEST THAT "NEW" STATUS IS CORRECT
004232 012706 000500
004236 012737 004262 000004
004244 005067 173536
004250 012737 000357 177776
004256 005767 173517
004262 013700 177776
004266 001401
004270 000000
MOV #STKPTR,%6
MOV #RETR,@ERRVEC
CLR ERRVEC+2 ;CLEAR FUTURE PSW
MOV #357,@PSW ;PRE SET STATUS
TST 1
RETR: MOV @PSW,%0 ;GET & TEST THE 'NEW' STATUS
BEQ .+4 ;BRANCH IF CORRECT
HLT ;ERROR! 'NEW' STATUS IS INCORRECT

```

```

004272 005037 177776          CLR      @#PSW
004276 010701                SCOPE          ;SCOPE STORES PC IN R1

004300 012706 000500          MOV      #STKPTR,%6
004304 012737 004324 000004    MOV      #RETV,@#ERRVEC
004312 012737 000357 000006    MOV      #357,@#ERRVEC+2 ;LOAD 'NEW' STATUS
004320 005767 173455          TST      1
004324 013700 177776          RETV:    MOV      @#PSW,%0          ;GET THE 'NEW' STATUS
004330 022700 000357          CMP      #357,%0          ;IS IT CORRECT
004334 001401          BEQ      .+4          ;BRANCH IF CORRECT
004336 000000          HLT
004340 005037 177776          CLR      @#PSW
004344 010701                SCOPE          ;SCOPE STORES PC IN R1

;TEST THAT AN ODDSOURCE INTERMEDIATE ADDRESS CAUSES AN ODDD ADDRESS ERROR
004346 012706 000500          MOV      #STKPTR,%6
004352 012767 004376 173424    MOV      #OAERO,4          ;SET UP STACK POINTER
004360 005067 173422          CLR      6          ;LOAD ERROR VECTOR
004364 012702 000001          MOV      #1,%2          ;LOAD INDEX REGISTER
004370 067200 000000          ADD      @0(2),%0          ;SRC ADRS [0(2)] IS ODD
004374 000000          HLT          ;ERROR! ODD ADRES ERROR FAILED TO TRAP
004376 010701                OAERO:    SCOPE          ;SCOPE STORES PC IN R1

004400 012706 000500          MOV      #STKPTR,%6
004404 012767 004424 173372    MOV      #OAER1,4
004412 012703 000477          MOV      #STKPTR-1,%3
004416 147300 000000          BICB    @0(3),%0          ;DST INT ADRS [0(3)] IS ODD
004422 000000          HLT          ;ERROR! ODD ADRS IN DST FAILED TO TRAP
004424 010701                OAER1:    SCOPE          ;SCOPE STORES PC IN R1

;TEST THAT AN ODD SOURCE FINAL ADRES WILL CAUSE AN ERROR IF A WORD INST.
004426 012706 000500          MOV      #STKPTR,%6
004432 012767 004456 173344    MOV      #OAER2,4
004440 012767 000001 173432    MOV      #1,100
004446 005004          CLR      %4
004450 017400 000100          MOV      @100(4),%0          ;SRC FINAL ADRS IS ODD
004454 000000          HLT          ;ERROR! ODD FINAL SRC ADRS FAILED TO TRAP
004456 010701                OAER2:    SCOPE          ;SCOPE STORES PC IN R1

;TEST THAT AN ODD DEST INTERMEDIATE ADDRESS CAUSES AN ODD ADRS ERROR
004460 012706 000500          MOV      #STKPTR,%6
004464 012767 004504 173312    MOV      #OAER3,4
004472 012705 000001          MOV      #1,%5
004476 074075 000000          XOR      %0,@0(5)          ;DST INT ADRS [0(5)] IS ODD
004502 000000          HLT          ;ERROR! ODD ADRS ERROR FAILED TO TRAP
004504 010701                OAER3:    SCOPE          ;SCOPE STORES PC IN R1

004506 012706 000500          MOV      #STKPTR,%6
004512 012767 004526 173264    MOV      #OAER4,4
004520 005000          CLR      %0
004522 122030          CMPB    (0)+,@(0)+          ;DST INT ADRS IS ODD [(0) =1]
004524 000000          HLT          ;ERROR! ODD ADRS ERROR FAILED TO TRAP
004526 010701                OAER4:    SCOPE          ;SCOPE STORES PC IN R1

;TEST THAT AN ODD DEST FINAL ADRS WILL CAUSE AN ODD ADRS ERROR TRAP
004530 012706 000500          MOV      #STKPTR,%6

```



```

005004 010701          SCOPE          ;SCOPE STORES PC IN R1

005006 012737 000006 000004          MOV      #ERRVEC+2,0#ERRVEC
005014 005037 000006          CLR      0#ERRVEC+2

;TEST THAT THE 'T' BIT CANNOT BE DIRECTLY SET
005020 012737 005046 000014          MOV      #NOTBIT,0#TBITVEC          ;LOAD 'T' BIT TRAP VECTOR
005026 005037 000016          CLR      0#TBITVEC+2
005032 012706 000500          MOV      #STKPTR,%6          ;SET THE STACK PTR
005036 012737 000020 177776          MOV      #20,0#PSW          ;TRY TO SET THE 'T' BIT
005044 000402          BR      .+6
005046 000000          NOTBIT: HLT          ;ERROR! 'T' BIT WAS SET BY MOVE
005050 010701          SCOPE          ;SCOPE STORES PC IN R1

;TEST THAT SETTING THE 'T' BIT WILL CAUSE A TRAP TO 14
005052 012706 000500          MOV      #STKPTR,%6
005056 012767 005104 172730          MOV      #RETAT,0#PTVEC          ;SET UP TO TRAP TO 14
005064 005067 172726          CLR      0#PTVEC+2
005070 012746 000020          MOV      #20,-(6)          ;PUSH 'T' BIT ON THE STACK
005074 012746 005102          MOV      #.+6,-(6)          ;PUSH PC ON THE STACK
005100 000002          RTI          ;SET 'T' BIT
005102 000000          HLT          ;ERROR! 'T' BIT FAILED TO TRAP
005104 010701          RETAT: SCOPE          ;SCOPE STORES PC IN R1

;TEST STACK POINTER DECREMENTS
005106 012706 000500          MOV      #STKPTR,%6
005112 012767 005132 172674          MOV      #RETBT,0#PTVEC
005120 012746 000020          MOV      #20,-(6)          ;PUSH 'T' BIT ON THE STACK
005124 012746 005132          MOV      #.+6,-(6)          ;PUSH PC ON THE STACK
005130 000002          RTI          ;SET 'T' BIT
005132 020627 000474          RETBT: CMP      %6,#STKPTR-4
005136 001401          BEQ      .+4
005140 000000          HLT          ;STACK POINTER WAS NOT PUSHED BY TRAP
005142 010701          SCOPE          ;SCOPE STORES PC IN R1

;TEST FOR PROPER PC ON STACK
005144 012706 000500          MOV      #STKPTR,%6
005150 012767 005172 172636          MOV      #RETCT,0#PTVEC
005156 012746 000020          MOV      #20,-(6)          ;PUSH 'T' BIT ON THE STACK
005162 012746 005170          MOV      #.+6,-(6)          ;PUSH PC ON THE STACK
005166 000002          RTI          ;SET 'T' BIT
005170 000000          HLT          ;ERROR! 'T' BIT TRAP NOT ACKNOWLEDGED
;BEFORE 1ST INST. AFTER AN RTI

005172 022767 005170 173274          RETCT: CMP      #.-2,STKPTR-4
005200 001401          BEQ      .+4
005202 000000          HLT          ;CORRECT PC WAS NOT SAVED ON STACK
005204 010701          SCOPE          ;SCOPE STORES PC IN R1

;TEST FOR PROPER PC ON THE STACK (RTT)
005206 012706 000500          MOV      #STKPTR,%6          ;INITIALIZE THE STACK POINTER
005212 012767 005240 172574          MOV      #RETCT1,0#PTVEC          ;SET UP 'T' BIT TRAP VECTOR
005220 012746 000020          MOV      #20,-(6)          ;PUSH 'T' BIT ON THE STACK
005224 012746 005232          MOV      #.+6,-(6)          ;PUSH PC ON THE STACK
005230 000006          RTT          ;SET 'T' BIT
005232 012707 005236          MOV      #.+4,%7          ;ADVANCE PC TO HLT INSTRUCTION
    
```

```

; 'T' BIT TRAP SHOULD OCCUR HERE
005236 000000
005240 022767 005236 173226 RETCT1: HLT
005246 001401 BEQ #.-2,STKPTR-4 ;ERROR! 'T' BIT TRAP NOT ACKNOWLEDGED
005250 000000 HLT ;PROPER PC ON THE STACK
005252 010701 SCOPE ;SCOPE STORES PC IN R1

005254 012737 000016 000014 MOV #16,0#BPTVEC ;RESTORE 'T' TRAP
005262 005037 000016 CLR 0#BPTVEC+2 ;TO HALT AT 16

;TEST THAT IF FLOATING POINT IS NOT AVAILABLE THAT A TRAP TO 10 (RESVEC)
;OCCURS.
005266 012706 001000
005272 012737 005322 000010 FP: MOV #1000,%6
005300 005002 CLR #FPA,0#RESVEC ;LOAD RESERVED INST TRAP VECTOR
005302 170127 147157 FPAR: LDFPS #147157 ;DO A FLOATING POINT INST.
005306 170202 STFPS %2 ;GET RESULT
005310 022702 147157 CMP #147157,%2 ;CHECK RESULT
005314 001401 BEQ .+4
005316 000000 HLT ;ERROR! EITHER FPU IS AVAILABLE AND NOT
;WORKING OR IS NOT AVAILABLE AND NOT TRAPPING!!!
005320 000405 BR FPB ;EXIT TEST
005322 022767 005304 173444 FPA: CMP #FPA+2,774 ;WAS RETURN PC SAVED ON TRAP
005330 001401 BEQ .+4
005332 000000 HLT ;ERROR! RETURN PC NOT SAVED ON STACK
005334 012737 000012 000010 FPB: MOV #RESVEC+2,0#RESVEC
005342 010701 SCOPE ;SCOPE STORES PC IN R1
    
```

```

;TEST THAT WHEN A DATI TO A STACK LOCATION LESS THAN 400 DOES NOT CAUSE
;AN OVERFLOW TRAP.
005344 012706 000376          MOV      #376,%6          ;SET STACK LESS THAN 400
005350 012737 005366 000004  MOV      #TDEC1,@#ERRVEC
005356 005037 000006          CLR      @#ERRVEC+2
005362 005716          TST      (6)
005364 000401          BR       .+4
005366 000000          TDEC1:  HLT                      ;ERROR! OVERFLOW TRAP
005370 010701          SCOPE                      ;SCOPE STORES PC IN R1

;TEST THAT A DATIP/DATO TO A STACK LOCATION LESS THAN 400 CAUSES AN OVER-
;FLOW TRAP.
005372 012706 000376          MOV      #376,%6
005376 012737 005412 000004  MOV      #TDEC2,@#ERRVEC
005404 005016          CLR      (6)
005406 000240          NOP
005410 000000          HLT
005412 010701          TDEC2:  SCOPE                      ;ERROR! OVERFLOW FAILED TO TRAP
                                           ;SCOPE STORES PC IN R1

;TEST THAT A DATIP/DATOB(EVEN) CAUSES AN OVERFLOW TRAP,
005414 012706 000376          MOV      #376,%6
005420 012737 005434 000004  MOV      #TDEC2A,@#ERRVEC
005426 152716 177777          BISB    #-1,(6)
005432 000000          HLT
005434 010701          TDEC2A: SCOPE                      ;ERROR! NO OVERFLOW TRAP
                                           ;SCOPE STORES PC IN R1

;TEST THAT A SOURCE REFERENCE TO A 'YELLOW' ADDRESS DOES NOT OVERFLOW.
005436 012706 001000          MOV      #1000,%5
005442 012706 000376          MOV      #376,%6
005446 012737 005460 000004  MOV      #TDEC3,@#ERRVEC
005454 124645          CMPB    -(6),-(5)
005456 000401          BR       .+4
005460 000000          TDEC3:  HLT                      ;ERROR! OVERFLOW TRAP
005462 010701          SCOPE                      ;SCOPE STORES PC IN R1

;TEST THAT A DESTINATION DATI (USING A BINARY INST.) DOES NOT OVERFLOW
005464 012706 000400          MOV      #400,%6
005470 012737 005502 000004  MOV      #TDEC4,@#ERRVEC
005476 134546          BITB    -(5),-(6)
005500 000401          BR       .+4
005502 000000          TDEC4:  HLT                      ;ERROR! OVERFLOW TRAP
005504 010701          SCOPE                      ;SCOPE STORES PC IN R1

;TEST THAT OVERFLOW TRAP DOES NOT LOSE INFORMATION
005506 012706 000400          MOV      #400,%6
005512 005067 172660          CLR      376                      ;STATUS WORD OF LOC 10
005516 005067 172652          CLR      374
005522 012737 005544 000004  MOV      #TDEC5,@#ERRVEC
005530 012737 000017 177776  MOV      #17,@#PSW                      ;PRE SET STATUS
005536 005246          INC      -(6)
005540 000000          TDEC5A: HLT                      ;ERROR! TRAP FAILED
005542 000412          BR       TDEC5B                    ;GO TO SCOPE
005544 022767 000001 172624  TDEC5:  CMP      #1,376                ;WAS INC -(6) EXECUTED
005552 001401          BEQ      .+4                      ;SCOPE STORES PC IN R1
    
```

```

005554 000000          HLT          ;ERROR! INC -(6) WAS NOT EXECUTED
005556 022767 000001 172610      CMP          #1,374      ;WAS STATUS SAVED NOTE: INC DOES NOT
                                     ;AFFECT 'C' BIT IN STATUS.

005564 001401          BEQ          .+4
005566 000000          HLT
005570 010701      TDEC5B: SCOPE      ;ERROR! INCORRECT STATUS SAVED
                                     ;SCOPE STORES PC IN R1

      .MACR VTRP INST A,B,DEST
;TEST THAT INST CAUSES AN OVERFLOW TRAP
      MOV          #1000,%6      ;SET UP STACK TO OVERFLOW
      MOV          #VDEC'B,2,#'DEST ;SET TRAP VECTOR
      MOV          #VDEC'A,2,#ERRVEC ;SET UP OVERFLOW VECTOR
      INST
      HLT          ;SHOULD OVERFLOW
                                     ;NO TRAP OCCURRED
VDEC'B':      HLT          ;TRAP FLAG OVERFLOW DID NOT OCCUR
VDEC'A':      CMP          #VDEC'B'-2,4(6) ;CHECK RETURN PC ON THE STACK
      BEQ          .+4
      HLT          ;ERROR! RETURN PC NOT ON THE STACK
      CMP          #770,%6      ;CHECK STACK POINTER
      BEQ          .+4      ;4 PUSHES (2 FOR TRAP & 2 FOR OVERFLOW)
      HLT          ;ERROR! INCORRECT STACK PTR
      MOV          #'DEST+2,2#'DEST
      SCOPE      ;SCOPE STORES PC IN R1

      .ENDM

005572 112737 000001 177775      MOVB         #1,2#177775 ;SET STACK LIMIT =1000
;TEST THAT 75000 CAUSES AN OVERFLOW TRAP
005600 012706 001000          MOV          #1000,%6 ;SET UP STACK TO OVERFLOW
005604 012737 005624 000010      MOV          #VDEC2,2#RESVEC ;SET TRAP VECTOR
005612 012737 005626 000004      MOV          #VDEC1,2#ERRVEC ;SET UP OVERFLOW VECTOR
005620 075000          75000 ;SHOULD OVERFLOW
005622 000000          HLT          ;NO TRAP OCCURRED
005624 000000      VDEC2: HLT          ;TRAP FLAG OVERFLOW DID NOT OCCUR
005626 022766 005622 000004      VDEC1: CMP          #VDEC2-2,4(6) ;CHECK RETURN PC ON THE STACK
005634 001401          BEQ          .+4
005636 000000          HLT          ;ERROR! RETURN PC NOT ON THE STACK
005640 022706 000770          CMP          #770,%6 ;CHECK STACK POINTER
005644 001401          BEQ          .+4 ;4 PUSHES (2 FOR TRAP & 2 FOR OVERFLOW)
005646 000000          HLT          ;ERROR! INCORRECT STACK PTR
005650 012737 000012 000010      MOV          #RESVEC+2,2#RESVEC
005656 010701          SCOPE      ;SCOPE STORES PC IN R1

;TEST THAT IOT CAUSES AN OVERFLOW TRAP
005660 012706 001000          MOV          #1000,%6 ;SET UP STACK TO OVERFLOW
005664 012737 005704 000020      MOV          #VDEC4,2#IOTVEC ;SET TRAP VECTOR
005672 012737 005706 000004      MOV          #VDEC3,2#ERRVEC ;SET UP OVERFLOW VECTOR
005700 000004          IOT          ;SHOULD OVERFLOW
005702 000000          HLT          ;NO TRAP OCCURRED
005704 000000      VDEC4: HLT          ;TRAP FLAG OVERFLOW DID NOT OCCUR
005706 022766 005702 000004      VDEC3: CMP          #VDEC4-2,4(6) ;CHECK RETURN PC ON THE STACK
005714 001401          BEQ          .+4
005716 000000          HLT          ;ERROR! RETURN PC NOT ON THE STACK
005720 022706 000770          CMP          #770,%6 ;CHECK STACK POINTER
005724 001401          BEQ          .+4 ;4 PUSHES (2 FOR TRAP & 2 FOR OVERFLOW)
005726 000000          HLT          ;ERROR! INCORRECT STACK PTR

```

```

005730 012737 000022 000020      MOV      #IOTVEC+2,2#IOTVEC
005736 010701                      SCOPE      ;SCOPE STORES PC IN R1

;TEST THAT EMT CAUSES AN OVERFLOW TRAP
005740 012706 001000                      MOV      #1000,%6      ;SET UP STACK TO OVERFLOW
005744 012737 005764 000030      MOV      #VDEC6,2#EMTVEC ;SET TRAP VECTOR
005752 012737 005766 000004      MOV      #VDEC5,2#ERRVEC ;SET UP OVERFLOW VECTOR
005760 104000                      EMT                      ;SHOULD OVERFLOW
005762 000000                      HLT                      ;NO TRAP OCCURRED
005764 000000                      VDEC6: HLT                ;TRAP FLAG OVERFLOW DID NOT OCCUR
005766 022766 005762 000004      VDEC5: CMP      #VDEC6-2,4(6) ;CHECK RETURN PC ON THE STACK
005774 001401                      BEQ      .+4
005776 000000                      HLT
006000 022706 000770                      CMP      #770,%6      ;ERROR! RETURN PC NOT ON THE STACK
006004 001401                      BEQ      .+4      ;CHECK STACK POINTER
006006 000000                      HLT                      ;4 PUSHES (2 FOR TRAP & 2 FOR OVERFLOW)
006010 012737 000032 000030      MOV      #EMTVEC+2,2#EMTVEC ;ERROR! INCORRECT STACK PTR
006016 010701                      SCOPE      ;SCOPE STORES PC IN R1

;TEST THAT TRAP CAUSES AN OVERFLOW TRAP
006020 012706 001000                      MOV      #1000,%6      ;SET UP STACK TO OVERFLOW
006024 012737 006044 000034      MOV      #VDEC8,2#TRAPVEC ;SET TRAP VECTOR
006032 012737 006046 000004      MOV      #VDEC7,2#ERRVEC ;SET UP OVERFLOW VECTOR
006040 104400                      TRAP                     ;SHOULD OVERFLOW
006042 000000                      HLT                      ;NO TRAP OCCURRED
006044 000000                      VDEC8: HLT                ;TRAP FLAG OVERFLOW DID NOT OCCUR
006046 022766 006042 000004      VDEC7: CMP      #VDEC8-2,4(6) ;CHECK RETURN PC ON THE STACK
006054 001401                      BEQ      .+4
006056 000000                      HLT                      ;ERROR! RETURN PC NOT ON THE STACK
006060 022706 000770                      CMP      #770,%6      ;CHECK STACK POINTER
006064 001401                      BEQ      .+4      ;4 PUSHES (2 FOR TRAP & 2 FOR OVERFLOW)
006066 000000                      HLT                      ;ERROR! INCORRECT STACK PTR
006070 012737 000036 000034      MOV      #TRAPVEC+2,2#TRAPVEC
006076 010701                      SCOPE      ;SCOPE STORES PC IN R1

;TEST THAT BPT CAUSES AN OVERFLOW TRAP
006100 012706 001000                      MOV      #1000,%6      ;SET UP STACK TO OVERFLOW
006104 012737 006124 000014      MOV      #VDEC10,2#BPTVEC ;SET TRAP VECTOR
006112 012737 006126 000004      MOV      #VDEC9,2#ERRVEC ;SET UP OVERFLOW VECTOR
006120 000003                      BPT                      ;SHOULD OVERFLOW
006122 000000                      HLT                      ;NO TRAP OCCURRED
006124 000000                      VDEC10: HLT               ;TRAP FLAG OVERFLOW DID NOT OCCUR
006126 022766 006122 000004      VDEC9: CMP      #VDEC10-2,4(6) ;CHECK RETURN PC ON THE STACK
006134 001401                      BEQ      .+4
006136 000000                      HLT                      ;ERROR! RETURN PC NOT ON THE STACK
006140 022706 000770                      CMP      #770,%6      ;CHECK STACK POINTER
006144 001401                      BEQ      .+4      ;4 PUSHES (2 FOR TRAP & 2 FOR OVERFLOW)
006146 000000                      HLT                      ;ERROR! INCORRECT STACK PTR
006150 012737 000016 000014      MOV      #BPTVEC+2,2#BPTVEC
006156 010701                      SCOPE      ;SCOPE STORES PC IN R1

;TEST THAT ILLA CAUSES AN OVERFLOW TRAP
006160 012706 001000                      MOV      #1000,%6      ;SET UP STACK TO OVERFLOW
006164 012737 006204 000010      MOV      #VDEC11,2#RESVEC ;SET TRAP VECTOR
006172 012737 006206 000004      MOV      #VDEC12,2#ERRVEC ;SET UP OVERFLOW VECTOR
006200 004700                      ILLA                     ;SHOULD OVERFLOW

```



DCKBME.P11

```

006202 000000          HLT                ;NO TRAP OCCURRED
006204 000000          VDEC11: HLT           ;TRAP FLAG OVERFLOW DID NOT OCCUR
006206 022766 006202 000004 VDEC12: CMP      #VDEC11-2,4(6) ;CHECK RETURN PC ON THE STACK
006214 001401          BEQ                .+4
006216 000000          HLT                ;ERROR! RETURN PC NOT ON THE STACK
006220 022706 000770    CMP      #770,%6    ;CHECK STACK POINTER
006224 001401          BEQ                .+4    ;4 PUSHES (2 FOR TRAP & 2 FOR OVERFLOW)
006226 000000          HLT                ;ERROR! INCORRECT STACK PTR
006230 012737 000012 000010 MOV      #RESVEC+2,2#RESVEC
006236 010701          SCOPE              ;SCOPE STORES PC IN R1

```

```

.MACR VTRPO INST,A
;TEST THAT THE INSTRUCTION ('INST') CAUSES AN OVERFLOW CONDITION.
MOV      #1000,%6    ;SET STACK POINTER
MOV      #VDEC'A,2#ERRVEC ;LOAD ERROR VECTOR
INST
HLT
VDEC'A: CMP      #772,%6    ;CAUSE OVERFLOW
BEQ      .+4        ;ERROR! OVERFLOW FAILED TO TRAP
HLT      ;HAS STACK POINTER MOVED BY 6
SCOPE    ;(2 FOR THE AUTO DECREMENT + 4 FOR
          ;THE ERROR TRAP)
          ;SCOPE STORES PC IN R1

```

.ENDM

; INSTRUCTION EQUATE STATEMENTS

```

: 4510 =JSR 5,(0)
: 005046 =CLR -(6)
: 010046 =MOV %0,-(6)
: 006746 =SXT -(6)
: 074046 =XOR %0,-(6)

```

```

;TEST THAT THE INSTRUCTION (4510) CAUSES AN OVERFLOW CONDITION.
006240 012706 001000          MOV      #1000,%6    ;SET STACK POINTER
006244 012737 006256 000004 MOV      #VDEC15,2#ERRVEC ;LOAD ERROR VECTOR
006252 004510          4510          ;CAUSE OVERFLOW
006254 000000          HLT                ;ERROR! OVERFLOW FAILED TO TRAP
006256 022706 000772    VDEC15: CMP      #772,%6    ;HAS STACK POINTER MOVED BY 6
006262 001401          BEQ      .+4        ;(2 FOR THE AUTO DECREMENT + 4 FOR
006264 000000          HLT                ;THE ERROR TRAP)
006266 010701          SCOPE              ;SCOPE STORES PC IN R1

```

```

;TEST THAT THE INSTRUCTION (005046) CAUSES AN OVERFLOW CONDITION.
006270 012706 001000          MOV      #1000,%6    ;SET STACK POINTER
006274 012737 006306 000004 MOV      #VDEC16,2#ERRVEC ;LOAD ERROR VECTOR
006302 005046          005046        ;CAUSE OVERFLOW
006304 000000          HLT                ;ERROR! OVERFLOW FAILED TO TRAP
006306 022706 000772    VDEC16: CMP      #772,%6    ;HAS STACK POINTER MOVED BY 6
006312 001401          BEQ      .+4        ;(2 FOR THE AUTO DECREMENT + 4 FOR
006314 000000          HLT                ;THE ERROR TRAP)
006316 010701          SCOPE              ;SCOPE STORES PC IN R1

```

```

;TEST THAT THE INSTRUCTION (010046) CAUSES AN OVERFLOW CONDITION.
006320 012706 001000          MOV      #1000,%6    ;SET STACK POINTER
006324 012737 006336 000004 MOV      #VDEC17,2#ERRVEC ;LOAD ERROR VECTOR
006332 010046          010046        ;CAUSE OVERFLOW

```

```

006334 000000
006336 022706 000772
006342 001401
006344 000000
006346 010701
VDEC17: HLT
CMP #772,%6
BEQ .+4
HLT
SCOPE
;ERROR! OVERFLOW FAILED TO TRAP
;HAS STACK POINTER MOVED BY 6
;(2 FOR THE AUTO DECREMENT + 4 FOR
;THE ERROR TRAP)
;SCOPE STORES PC IN R1

;TEST THAT THE INSTRUCTION (006746) CAUSES AN OVERFLOW CONDITION.
006350 012706 001000
006354 012737 006366 000004
006362 006746
006364 000000
006366 022706 000772
006372 001401
006374 000000
006376 010701
VDEC18: MOV #1000,%6
MOV #VDEC18,@#ERRVEC
006746
HLT
CMP #772,%6
BEQ .+4
HLT
SCOPE
;SET STACK POINTER
;LOAD ERROR VECTOR
;CAUSE OVERFLOW
;ERROR! OVERFLOW FAILED TO TRAP
;HAS STACK POINTER MOVED BY 6
;(2 FOR THE AUTO DECREMENT + 4 FOR
;THE ERROR TRAP)
;SCOPE STORES PC IN R1

;TEST THAT THE INSTRUCTION (074046) CAUSES AN OVERFLOW CONDITION.
006400 012706 001000
006404 012737 006416 000004
006412 074046
006414 000000
006416 022706 000772
006422 001401
006424 000000
006426 010701
VDEC19: MOV #1000,%6
MOV #VDEC19,@#ERRVEC
074046
HLT
CMP #772,%6
BEQ .+4
HLT
SCOPE
;SET STACK POINTER
;LOAD ERROR VECTOR
;CAUSE OVERFLOW
;ERROR! OVERFLOW FAILED TO TRAP
;HAS STACK POINTER MOVED BY 6
;(2 FOR THE AUTO DECREMENT + 4 FOR
;THE ERROR TRAP)
;SCOPE STORES PC IN R1

;TEST THAT INTERRUPT CAUSES AN OVERFLOW
006430 012706 001000
006434 012737 006500 000004
006442 012737 006526 000064
006450 000237
006452 105737 177564
006456 100375
006460 012737 000100 177564
006466 005037 177776
006472 000237
006474 000000
006476 000754
VDEC20: MOV #1000,%6
MOV #VDC20,@#ERRVEC
MOV #VDC20B,@#TPVEC
SPL 7
IS: TSTB @#TTCSR
BPL IS
MOV #100,@#TTCSR
CLR @#PSW
VDC20A: SPL 7
HLT
BR VDEC20
;SET STACK PTR
;LOAD OVERFLOW VECTOR
;LOAD TTY PRINTER VECTOR
;LOCK OUT INTERRUPTS
;WAIT FOR TTY TO BE READY
;SET IE BIT IN TTY PRINTER
;ALLOW INTERRUPTS
;LOCK OUT INTERRUPTS
;ERROR! NO TTY INTERRUPT
;LOOP TEST IF NO TTY INTERRUPT

;TEST THE STACK
006500 022767 006472 172266
006506 001401
006510 000000
006512 022767 006526 172250
006520 001401
006522 000000
006524 000401
006526 000000
006530 005037 177564
006534 012737 000066 000064
006542 012737 000006 000004
006550 105037 177775
006554 010701
VDC20: CMP #VDC20A,774
BEQ .+4
HLT
VDC20B: CMP #VDC20B,770
BEQ .+4
HLT
BR .+4
CLR @#TTCSR
MOV #TPVEC+2,@#TPVEC
MOV #ERRVEC+2,@#ERRVEC
CLRB @#177775
SCOPE
;IS RETURN PC (FROM INT.) ON THE STACK?
;ERROR!
;IS RETURN PC (FROM OVERFLOW) ON STACK
;ERROR!
;ERROR! NO OVERFLOW
;CLEAR IE BIT
;SET STACK LIMIT =400
;SCOPE STORES PC IN R1

```

```

;TEST FOR FALSE OVERFLOW TRAP
;PROGRAM MAY HAVE RELOADED IF OVERFLOW FAILS

```

```

006556 012767 006632 171220      MOV      #FOVER,4      ;SET UP OVERFLOW POINTER
006564 012706 000402      MOV      #402,%6
006570 014626      MOV      -(6),(6)+    ;SHOULD NOT OVERFLOW
006572 012706 001002      MOV      #1002,%6
006576 014626      MOV      -(6),(6)+    ;SHOULD NOT OVERFLOW
006600 012706 002002      MOV      #2002,%6
006604 014626      MOV      -(6),(6)+    ;SHOULD NOT OVERFLOW
006606 012706 004002      MOV      #4002,%6
006612 014626      MOV      -(6),(6)+    ;SHOULD NOT OVERFLOW
006614 012706 010002      MOV      #10002,%6
006620 014626      MOV      -(6),(6)+    ;SHOULD NOT OVERFLOW
006622 012706 020000      MOV      #20000,%6    ;SHOULD NOT OVERFLOW
006626 005746      TST      -(6)
006630 000401      BR       .+4
006632 000000      FOVER:  HLT
006634 010701      SCOPE   ;FALSE OVERFLOW OCCURRED
                                           ;SCOPE STORES PC IN R1

```

```

: THIS TEST SETS THE STACK IN THE 'YELLOW' ZONE AND THEN DOES EACH OF
: THE TRAP INSTRUCTIONS CAUSING AN OVERFLOW CONDITION AFTER EACH.
: WHAT THE STACK LOOKS LIKE WHEN INSTRUCTION AT 04 IS BEING EXECUTED

```

```

.....
OVFLW  PC=05,STAT=0  04  342
4  344
BPT    PC=04,STAT=4  03A  346
0  350
OVFLW  PC=05,STAT=0  03  352
3  354
IOT    PC=03,STAT=3  02A  356
0  360
OVFLW  PC=05,STAT=0  02  362
2  364
TRAP   PC=02,STAT=2  01A  366
0  370
OVFLW  PC=05,STAT=0  01  372
1  374
EMT    PC=01,STAT=1  00A  376
17  400
402 INITIAL STACK POINTER
;INITIALIZE STACK POINTER

```

```

006636 012706 000402      MOV      #402,%6
006642 012737 006746 000030      MOV      #01,%17
006650 012737 000001 000032      MOV      #1,%17
006656 012737 006752 000034      MOV      #02,%17
006664 012737 000002 000036      MOV      #2,%17
006672 012737 006756 000020      MOV      #03,%17
006700 012737 000003 000022      MOV      #3,%17
006706 012767 006762 171100      MOV      #04,%17
006714 012767 000004 171074      MOV      #4,%17
006722 012737 007200 000004      MOV      #05,%17
006730 005037 000006      CLR      #ERRVEC+2
006734 012737 000017 177776      MOV      #17,%17
006742 104000      EMT
006744 000000      00:    HLT      ;EMT NOT EXECUTED
006746 104400      01:    TRAP
006750 000000      01A:   HLT      ;TRAP NOT EXECUTED
006752 000004      02:    IOT
006754 000000      02A:   HLT      ;IOT NOT EXECUTED
006756 000003      03:    BPT

```

006760	000000		03A:	HLT			
006762	022706	000342	04:	CMP	#342,%6		;BPT NOT EXECUTED
006766	001401			BEQ	.+4		;IS STACK POINTER
006770	000000			HLT			;POSITIONED PROPERLY
006772	012700	000402		MOV	#402,%0		;ERROR! INCORRECT STACK POINTER
006776	022740	000017		CMP	#17,-(0)		
007002	001401			BEQ	.+4		
007004	000000			HLT			;STACK ERROR
007006	022740	006744		CMP	#00A,-(0)		
007012	001401			BEQ	.+4		
007014	000000			HLT			
007016	022740	000001		CMP	#1,-(0)		
007022	001401			BEQ	.+4		
007024	000000			HLT			
007026	022740	006746		CMP	#01,-(0)		
007032	001401			BEQ	.+4		
007034	000000			HLT			
007036	022740	000000		CMP	#0,-(0)		
007042	001401			BEQ	.+4		
007044	000000			HLT			
007046	022740	006750		CMP	#01A,-(0)		
007052	001401			BEQ	.+4		
007054	000000			HLT			
007056	022740	000002		CMP	#2,-(0)		
007062	001401			BEQ	.+4		
007064	000000			HLT			
007066	022740	006752		CMP	#02,-(0)		
007072	001401			BEQ	.+4		
007074	000000			HLT			
007076	022740	000000		CMP	#0,-(0)		
007102	001401			BEQ	.+4		
007104	000000			HLT			
007106	022740	006754		CMP	#02A,-(0)		
007112	001401			BEQ	.+4		
007114	000000			HLT			
007116	022740	000003		CMP	#3,-(0)		
007122	001401			BEQ	.+4		
007124	000000			HLT			
007126	022740	006756		CMP	#03,-(0)		
007132	001401			BEQ	.+4		
007134	000000			HLT			
007136	022740	000000		CMP	#0,-(0)		
007142	001401			BEQ	.+4		
007144	000000			HLT			
007146	022740	006760		CMP	#03A,-(0)		
007152	001401			BEQ	.+4		
007154	000000			HLT			
007156	022740	000004		CMP	#4,-(0)		
007162	001401			BEQ	.+4		
007164	000000			HLT			
007166	022740	006762		CMP	#04,-(0)		
007172	001401			BEQ	.+4		
007174	000000		STKERR:	HLT			; INCORRECT VALUE ON THE STACK
							; R0 GIVES LOCATION OF STACK ERROR
007176	000402			BR	06		
007200	000176	000000	05:	JMP	0(6)		; RETURN FROM ERROR

```

007204 010701          06:  SCOPE                ;SCOPE STORES PC IN R1
;TEST BPT TRAP WHEN STACK IS IN YELLOW AREA.
007206 005067 006704          CLR  TEMP
007212 012706 000400          MOV  #400,%6          ;SET UP STACK POINTER
007216 012767 007342 170570  MOV  #BPTC,BPTVEC    ;LOAD BPT VECTOR
007224 005067 170566          CLR  BPTVEC+2
007230 012737 007266 000004  MOV  #BPTB,2#ERRVEC ;LOAD OVFLW. ERROR VECTOR
007236 005067 170544          CLR  6
007242 016767 000012 006650  MOV  BPTA,TEMP+2     ;SAVE FIRST WORD OF INST. AT BPTA
007250 012767 000003 000002  MOV  #BPT,BPTA      ;REPLACE WITH BPT INSTRUCTION
007256 000277          SCC
007260 005167 006632          BPTA: COM  TEMP      ;NOTE: THIS INSTRUCTION WAS REPLACED BY BPT
007264 000475          BPTAA: BR   BPTF
007266 022767 000017 171102  BPTB: CMP  #17,376   ;WERE CONDITION CODES SAVED
007274 001401          BEQ  .+4
007276 000000          HLT
007300 022767 007262 171066  CMP  #BPTA+2,374    ;ERROR! CONDITION CODES NOT SAVED
007306 001402          BEQ  .+6             ;WAS RETURN FROM BPT SAVED
007310 000000          HLT
007312 000467          BR   BPTEX         ;ERROR! RETURN PC NOT SAVED
007314 005767 171052          TST  372            ;EXIT TEST
007320 001401          BEQ  .+4            ;WAS BPT STATUS SAVED?
007322 000000          HLT
007324 022767 007342 171036  CMP  #BPTC,370      ;ERROR! BPT STATUS (BPTVEC+2) NOT SAVED
007332 001402          BEQ  .+6             ;BPT VECTOR SAVED
007334 000000          HLT
007336 000455          BR   BPTEX         ;ERROR! BPT VECTOR (BPTVEC) NOT SAVED
007340 000002          RTI              ;EXIT TEST
;RETURN FROM OVERFLOW TRAP
007342 010605          BPTC: MOV  %6,%5     ;SAVE STACK POINTER
007344 162715 000002          SUB  #2,(5)         ;POINT PC TO TRAPPED INSTRUCTION
007350 016735 006544          MOV  TEMP+2,2(5)+  ;RESTORE ORIGINAL INSTRUCTION (COM TEMP)
007354 052715 000020          BIS  #20,(5)       ;SET 'T' BIT ON STACK
007360 012737 007376 000004  MOV  #BPTD,2#ERRVEC ;CHANGE ERROR VECTOR
007366 012767 007452 170420  MOV  #BPTD,TBITVEC  ;LOAD 'T' BIT VECTOR
007374 000006          RTT              ;GO DO ORIGINAL INSTRUCTION AND TRAP
;('T' BIT TRAP) WHEN FINISHED
;CHECK THE STACK
007376 022767 000031 170772  BPTD: CMP  #31,376   ;IS 'N', 'C', & 'T' BITS SET ON THE STACK
007404 001401          BEQ  .+4            ;(RESULT OF COM TEMP IN BPTA
007406 000000          HLT
007410 022767 007264 170756  CMP  #BPTAA,374     ;ERROR! STATUS NOT SAVED
007416 001402          BEQ  .+6             ;WAS RETURN PC FROM 'T' TRAP SAVED?
007420 000000          HLT
007422 000423          BR   BPTEX         ;ERROR! RETURN PC NOT SAVED
007424 005767 170742          TST  372            ;EXIT TEST
007430 001401          BEQ  .+4            ;'T' BIT TRAP STATUS SAVED?
007432 000000          HLT
007434 022767 007452 170726  CMP  #BPTD,370      ;ERROR! 'T' BIT STATUS (TBITVEC+2) NOT SAVED
007442 001402          BEQ  .+6             ;'T' BIT VECTOR SAVED (TBITVRC)
007444 000000          HLT
007446 000411          BR   BPTEX         ;ERROR! 'T' BIT VECTOR NOT SAVED
007450 000002          RTI              ;EXIT TEST
;RETURN FROM ERROR TRAP

```

```

007452 005067 170720          BPTC: CLR      376          ;CLEAR SAVED STATUS
007456 000002                RTI                    ;RETURN FROM 'T' BIT TRAP

007460 022767 177777 006430 BPTF: CMP      #-1,TEMP      ;WAS ORIGINAL INSTRUCTION EXECUTED?
007466 001401                BEQ      .+4
007470 000000                HLT
007472 012767 000016 170314 BPTC: MOV      #BPTVEC+2,BPTVEC ;TRACED INSTRUCTION (CCM TEMP) NOT EXEC.
007500 012737 000006 000004 BPTC: MOV      #ERRVEC+2,#ERRVEC ;RESTORE TRAP
007506 010701                SCOPE                ;VECTORS
                                ;SCOPE STORES PC IN R1

                                ;TEST THAT INDEX MODE (6) USING R6 AS THE REGISTER OVERFLOWS IF THE AD-
                                ;DRESS IS BETWEEN 376-340.
007510 012706 001000                INDEX: MOV     #1000,%6      ;SET UP STACK POINTER
007514 012737 007534 000004      MOV     #IND1,#ERRVEC
007522 005067 170260                CLR     6
007526 005066 177340                CLR     -440(6)        ;FINAL ADDRESS IS 340
007532 000000                HLT     ;ERROR! DID NOT TRAP
007534 010701                IND1:  SCOPE          ;SCOPE STORES PC IN R1

                                ;TEST THAT THE TRAP SEQUENCE IS EXECUTED PROPERLY ON OVERFLOW.
007536 012706 001000                MOV     #1000,%6
007542 012737 007600 000004      MOV     #IND2,#ERRVEC
007550 005067 171222                CLR     776
007554 005067 171214                CLR     774
007560 012767 000001 170610      MOV     #1,376          ;PRE SET DEST ADDRESS
007566 012766 000000 177376      MOV     #0,-402(6)     ;FINAL ADDRESS IS 376
007574 000000                IND2A: HLT           ;ERROR! FAILED TO TRAP
007576 000422                BR      IND2X          ;GO TO SCOPE
007600 026727 171172 000004      IND2:  CMP     776,#4    ;STATUS SAVED ON THE STACK (Z BIT SET)
007606 001401                BEQ     .+4            ;[RESULT OF MOV #0,-402(6)]
007610 000000                HLT     ;ERROR! INCORRECT STATUS SAVED
007612 022767 007574 171154      CMP     #IND2A,774     ;RETURN PC SAVED?
007620 001401                BEQ     .+4
007622 000000                HLT
007624 020627 000774                CMP     %6,#774        ;ERROR! RETURN PC NOT SAVED
007630 001401                BEQ     .+4            ;CORRECT STACK POINTER?
007632 000000                HLT
007634 005767 170536                TST     376            ;ERROR! INCORRECT STACK POINTER
007640 001401                BEQ     .+4            ;WAS MOVE INST. EXECUTED
007642 000000                HLT     ;ERROR! MOVE NOT EXECUTED
007644 010701                IND2X: SCOPE         ;SCOPE STORES PC IN R1

                                ;THIS TEST IS THE SAME AS ABOVE EXCEPT THAT THE STACK POINTER IS INIT-
                                ;IALLY IN THE YELLOW ZONE.
007646 012706 000376                MOV     #376,%6        ;SET UP STACK IN 'YELLOW' AREA
007652 012737 007676 000004      MOV     #IND3,#ERRVEC ;SET UP ERROR RETURN
007660 005067 170510                CLR     374
007664 005067 170502                CLR     372
007670 005066 177742                CLR     -36(6)        ;FINAL ADDRESS IS 340 (YELLOW)
007674 000000                IND3A: HLT           ;FAILED TO TRAP
007676 022767 000004 170470      IND3:  CMP     #4,374   ;SAVED STATUS CORRECT?
007704 001401                BEQ     .+4
007706 000000                HLT
007710 022767 007674 170454      CMP     #IND3A,372    ;SAVED STATUS WAS INCORRECT (Z SET)
007716 001401                BEQ     .+4            ;SAVED RETURN ADDRESS CORRECT?
007720 000000                HLT
                                ;ERROR! SAVED RETURN ADDRESS INCORRECT

```

```

007722 022706 000372          CMP      #372,%6          ;STACK POINTER CORRECT
007726 001401          BEQ      .+4
007730 000000          HLT
007732 005767 170402          TST      340          ;ERROR! STACK POINTER INCORRECT
007736 001401          BEQ      .+4          ;WAS CLEAR INSTRUCTION EXECUTED?
007740 000000          HLT          ;ERROR! CLEAR NOT EXECUTED
007742 010701          SCOPE          ;SCOPE STORES PC IN R1

;TEST THAT AN OVERFLOW OCCURS IF THE ADDRESS IS IN THE 'RED' ZONE AND ALSO
;THAT THE INSTRUCTION [CLRB -442(6)] IS ABORTED.
007744 012706 001000          MOV      #1000,%6      ;SET STACK PTR
007750 012737 010016 000004      MOV      #IND4,@#ERRVEC ;SET ERROR TRAP VECTOR
007756 012767 177777 170014      MOV      #-1,0
007764 012767 177777 170010      MOV      #-1,2
007772 005067 171000          CLR      776
007776 005037 177776          CLR      @#PSW
010002 012767 177777 170326      MOV      #-1,336      ;PRE SET 336
010010 105066 177336          CLRB     -442(6)      ;CLEAR 'RED' LOCATION (336)
010014 000000          HLT      ;ERROR! FAILED TO TRAP
010016 005706          IND4A:  TST      %6      ;STACK POINTER CORRECT?
010020 001401          IND4:   BEQ      .+4
010022 000000          HLT      ;ERROR! INCORRECT STACK POINTER
010024 022767 177777 170304      CMP      #-1,336      ;WAS CLEAR INSTRUCTION ABORTED?
010032 001401          BEQ      .+4
010034 000000          HLT      ;ERROR! CLEAR INSTRUCTION NOT ABORTED
010036 022767 000010 167736      CMP      #10,2        ;WAS PROPER STATUS SAVED? (N SET)
010044 001401          BEQ      .+4        ;RESULT OF MOV #-1,336
010046 000000          HLT      ;ERROR! INCORRECT STATUS WAS SAVED
010050 022767 010014 167722      CMP      #IND4A,0     ;WAS RETURN PC SAVED?
010056 001401          BEQ      .+4
010060 000000          HLT
010062 005767 170710          TST      776          ;WAS NOTHING PUT ON THE OLD STACK?
010066 001401          BEQ      .+4
010070 000000          HLT          ;ERROR! RED TRAP DID NOT STACK AT 2 & 0
010072 010701          SCOPE          ;SCOPE STORES PC IN R1

;TEST THAT INDEX MODE USING R6 IN SOURCE DOES NOT TRAP.
010074 012706 001000          MOV      #1000,%6      ;SET UP STACK
010100 012737 010124 000004      MOV      #IND5,@#ERRVEC ;SET UP ERROR TRAP
010106 012767 177777 170234      MOV      #-1,350
010114 016667 177350 005774      MOV      -430(6),TEMP
010122 000401          BR      .+4
010124 000000          IND5:  HLT      ;ERROR! TRAPPED
010126 010701          SCOPE          ;SCOPE STORES PC IN R1

;THIS TEST IS THE SAME AS ABOVE EXCEPT THAT LOCATION IS 'RED'.
010130 012706 001000          MOV      #1000,%6
010134 012737 010152 000004      MOV      #IND6,@#ERRVEC ;SET ERROR TRAP VECTOR
010142 016667 177336 005746      MOV      -442(6),TEMP
010150 000401          BR      .+4
010152 000000          IND6:  HLT      ;ERROR! TRAPPED
010154 010701          SCOPE          ;SCOPE STORES PC IN R1

;TEST THAT TRAP DOES NOT OCCUR IF INDEX DEFERRED USING R6 IN DEST IF
;INTERMEDIATE ADDRESS IS 'YELLOW' AND FINAL ADDRESS IS NOT 'YELLOW' OR 'RED'.
010156 012706 001000          MOV      #1000,%6

```

```

010162 012737 010204 000004      MOV      #IND7,2#ERRVEC ;SET ERROR TRAP VECTOR
010170 012767 016116 170152      MOV      #TEMP,350
010176 005076 177350                CLR      2-430(6)      ;CLEAR TEMP
010202 000401                BR       .+4
010204 000000                IND7:   HLT           ;ERROR! TRAPPED
010206 010701                SCOPE      ;SCOPE STORES PC IN R1

;THIS TEST IS THE SAME AS ABOVE EXCEPT THE INTERMEDIATE ADDRESS IS 'RED'.
010210 012706 001000                MOV      #1000,%6
010214 012737 010240 000004      MOV      #IND10,2#ERRVEC
010222 012767 016116 170106      MOV      #TEMP,336
010230 012776 177777 177336      MOV      #-1,2-442(6) ;MOVE #-1 TO TEMP
010236 000401                BR       .+4
010240 000000                IND10:  HLT           ;ERROR TRAPPED
010242 010701                SCOPE      ;SCOPE STORES PC IN R1

;TEST THAT INDEX DEFERRED DOES NOT OVERFLOW IF THE FINAL ADDRESS IS 'YELLOW'
010244 012706 000776                MOV      #776,%6
010250 012737 010272 000004      MOV      #IND11,2#ERRVEC
010256 012767 000376 170512      MOV      #376,776
010264 005076 000000                CLR      2(6)          ;THIS INSTRUCTION CLEARS 376
010270 000401                BR       .+4          ;ADDRESS MODE 7 USING R6 DOES NOT TRAP
010272 000000                IND11:  HLT           ;ERROR! TRAPPED
010274 010701                SCOPE      ;SCOPE STORES PC IN R1

;THIS TEST IS THE SAME AS ABOVE EXCEPT THAT THE FINAL ADDRESS IS 'RED'.
010276 012706 000776                MOV      #776,%6
010302 012737 010330 000004      MOV      #IND12,2#ERRVEC
010310 012767 000336 170460      MOV      #336,776
010316 005067 170014                CLR      336
010322 005176 000000                COM      2(6)
010326 000401                IND12A: BR       .+4 ;ADDRESS MODE 7 USING R6 DOES NOT TRAP
010330 000000                IND12:  HLT           ;SCOPE STORES PC IN R1
010332 010701                SCOPE

;TEST THAT OVERFLOW OPERATES PROPERLY WHEN THE STACK POINTER IS 'YELLOW'
;AND A 'RED' ADDRESS IS REFERENCED.
010334 012706 000376                MOV      #376,%6      ;SET STACK IN 'YELLOW' ZONE
010340 005067 167772                CLR      336
010344 012737 010360 000004      MOV      #IND13,2#ERRVEC
010352 005166 177740                COM      -40(6)
010356 000000                IND13A: HLT           ;ATTEMPT TO COMPLEMENT 336
010360 022767 010356 167412      IND13:  CMP      #IND13A,0 ;ERROR! NO OVERFLOW TRAP
010366 001401                BEQ      .+4          ;WAS STACK REPOSITIONED
010370 000000                HLT
010372 005767 167740                TST      336          ;WAS INST. COM -40(6) ABORTED?
010376 001401                GEQ      .+4
010400 000000                HLT           ;ERROR! INSTRUCTION NOT ABORTED
010402 010701                SCOPE      ;SCOPE STORES PC IN R1

;TEST THAT ADDRESS MODE 3 USING R6 DOES NOT OVERFLOW IF ADDRESS IS 'YELLOW'
010404 012737 010430 000004      MOV      #IND14,2#ERRVEC
010412 012706 000776                MOV      #776,%6
010416 012767 000376 170352      MOV      #376,776
010424 005036                CLR      2(6)+        ;CLEAR LOCATION 376
010426 000401                BR       .+4
010430 000000                IND14:  HLT           ;ERROR! ADDRESS MODE 3 CAUSED OVERFLOW TRAP

```



```

010432 010701                SCOPE                ;SCOPE STORES PC IN R1

;TEST THAT ADDRESS MODE 5 DOES NOT OVERFLOW
010434 012737 010460 000004  MOV      #IND15,2#ERRVEC
010442 012706 001000          MOV      #1000,%6
010446 012767 000336 170322  MOV      #336,776
010454 005056          CLR      2-(6)                ;CLEAR LOCATION 336 (A 'RED' LOCATION)
010456 000401          BR       .+4
010460 000000  IND15:  HLT                    ;ERROR! TRAPPED
010462 010701          SCOPE                ;SCOPE STORES PC IN R1

;TEST OVERFLOW WITH STACK POINTER IN THE 'RED' ZONE'
010464 012706 000340          MOV      #340,%6                ;SET UP STACK POINTER IN 'RED' AREA
010470 012737 010540 000030  MOV      #RED1,2#EMTVEC
010476 005037 000032          CLR      2#EMTVEC+2
010502 012737 010542 000004  MOV      #RED1A,2#ERRVEC ;SET ERROR TRAP VECTOR
010510 005067 167272          CLR      6
010514 005067 167260          CLR      0
010520 012767 136336 167610  MOV      #136336,336 ;PRESET 'RED' LOCATION
010526 012767 177777 167246  MOV      #-1,2
010534 104000          EMT
010536 000000  RED1B:  HLT
010540 000000  RED1:   HLT                    ;DID NOT ABORT EMT
010542 005767 167234  RED1A:  TST      2                ;WAS STATUS SAVED?
010546 001401          BEQ      .+4                ; (2#EMTVEC+2)
010550 000000          HLT
010552 022767 010540 167220  CMP      #RED1,0                ;WAS RETURN PC SAVED
010560 001401          BEQ      .+4                ; (2#EMTVEC)
010562 000000          HLT
010564 005706          TST      %6                ;STACK POINTER=0?
010566 001401          BEQ      .+4
010570 000000          HLT
010572 022767 136336 167536  CMP      #136336,336 ;WAS 'RED' LOCATION UNDISTURBED?
010600 001401          BEQ      .+4
010602 000000          HLT
010604 013737 000032 000030  MOV      2#EMTVEC+2,2#EMTVEC
010612 010701          SCOPE                ;SCOPE STORES PC IN R1

010614 012706 000200          MOV      #200,%6                ;SET UP STACK IN 'RED' AREA
010620 012767 176176 167350  MOV      #176176,176 ;PRE SET 'RED' LOCATION
010626 012737 010670 000034  MOV      #RED2,2#TRAPVEC
010634 005037 000036          CLR      2#TRAPVEC+2
010640 005067 167142          CLR      6
010644 005067 167130          CLR      0
010650 012737 010672 000004  MOV      #RED2A,2#ERRVEC
010656 012767 177777 167116  MOV      #-1,2
010664 104400          TRAP
010666 000000  RED2B:  HLT                    ;ERROR! FAILED TO TRAP
010670 000000  RED2:   HLT                    ;DID NOT ABORT TRAP
010672 005767 167104  RED2A:  TST      2                ;WAS STATUS SAVED?
010676 001401          BEQ      .+4                ; (TRAPVEC+2)
010700 000000          HLT
010702 022767 010670 167070  CMP      #RED2,0
010710 001401          BEQ      .+4                ; (TRAPVEC)
010712 000000          HLT
010714 005706          TST      %6

```

010716	001401			BEQ	.+4	
010720	000000			HLT		
010722	022767	176176	167246	CMP	#176176,176	; WAS 'RED' LOCATION LEFT UNDISTURBED?
010730	001401			BEQ	.+4	
010732	000000			HLT		; ERROR! 'RED' LOCATION WAS CHANGED
010734	012737	000036	000034	MOV	#TRAPVEC+2, @#TRAPVEC	
010742	010701			SCOPE		; SCOPE STORES PC IN R1
010744	012706	000100		MOV	#100,%6	
010750	012737	011012	000020	MOV	#RED3, @#IOTVEC	
010756	005037	000022		CLR	@#IOTVEC+2	
010762	005067	167020		CLR	6	
010766	012737	011014	000004	MOV	#RED3A, @#ERRVEC	
010774	005067	167000		CLR	0	
011000	012767	177777	166774	MOV	#-1,2	
011006	000004			IOT		
011010	000000			RED3B: HLT		; DID NOT OVERFLOW
011012	000000			RED3: HLT		; DID NOT ABORT IOT
011014	005767	166762		RED3A: TST	2	; WAS STATUS SAVED?
011020	001401			BEQ	.+4	; (@#IOTVEC+2)
011022	000000			HLT		
011024	022767	011012	166746	CMP	#RED3,0	; WAS NEW PC SAVED?
011032	001401			BEQ	.+4	; (@#IOTVEC)
011034	000000			HLT		
011036	005706			TST	%6	
011040	001401			BEQ	.+4	
011042	000000			HLT		
011044	013737	000022	000020	MOV	@#IOTVEC+2, @#IOTVEC	
011052	010701			SCOPE		; SCOPE STORES PC IN R1
011054	005006			CLR	%6	
011056	012767	011120	166730	MOV	#RED4, BPTVEC	
011064	005067	166726		CLR	BPTVEC+2	
011070	005067	166712		CLR	6	
011074	012737	011122	000004	MOV	#RED4A, @#ERRVEC	
011102	005067	166672		CLR	0	
011106	012767	177777	166666	MOV	#-1,2	
011114	000003			BPT		; TRACE TRAP
011116	000000			RED4B: HLT		; DID NOT OVERFLOW
011120	000000			RED4: HLT		; DID NOT ABORT BPT
011122	005767	166654		RED4A: TST	2	; WAS NEW STATUS SAVED?
011126	001401			BEQ	.+4	; (BPTVEC+2)
011130	000000			HLT		
011132	022767	011120	166640	CMP	#RED4,0	; WAS NEW PC SAVED?
011140	001401			BEQ	.+4	; (BPTVEC)
011142	000000			HLT		
011144	005706			TST	%6	
011146	001401			BEQ	.+4	
011150	000000			HLT		
011152	012767	000016	166634	MOV	#BPTVEC+2, BPTVEC	
011160	010701			SCOPE		; SCOPE STORES PC IN R1

; TEST TRANSITION FROM 'YELLOW' TO 'RED' AREAS. THE TRANSITION OCCURS  
; AFTER THE EMT HAS PUSHED ITS RETURN ADDRESS AND STATUS.

011162	012706	000044		MOV	#344,%6	; SET UP STACK TO ALLOW 2 'PUSHES'
011166	012737	011246	000030	MOV	#RED5, @#EMTVEC	; LOAD EMT VECTOR

```

011174 005037 000032          CLR      @#EMTVEC+2      ;AND STATUS
011200 012737 011252 000004  MOV      #REDSA,@#ERRVEC ;LOAD OVERFLOW VECTOR
011206 012767 000001 166572  MOV      #1,6           ;AND STATUS
011214 005067 166562          CLR      2
011220 005067 166554          CLR      0
011224 012767 136336 167104  MOV      #136336,336    ;PRE SET 'RED' LOCATION
011232 012737 000004 177776  MOV      #4,@#PSW
011240 104000          EMT
011242 000000          HLT      RED5B:
011244 000240          NOP
011246 000000          HLT      RED5:
011250 000240          NOP
011252 022767 000004 167062  RED5A:  CMP      #4,342        ;WAS STATUS SAVED?
011260 001401          BEQ      .+4
011262 000000          HLT      ;ERROR! EMT DID NOT SAVE STATUS
011264 022767 011242 167046  CMP      #REDSB,340    ;WAS RETURN PC SAVED?
011272 001401          BEQ      .+4
011274 000000          HLT      ;ERROR! RETURN PC NOT SAVED
011276 022767 136336 167032  CMP      #136336,336  ;WAS 'RED' LOCATION LEFT UNDISTURBED?
011304 001401          BEQ      .+4
011306 000000          HLT      ;ERROR! 'RED' AREA WAS CHANGED
011310 022767 000001 166464  CMP      #1,2         ;WAS OVERFLOW'S STATUS SAVED?
011316 001401          BEQ      .+4
011320 000000          HLT      ;ERROR! OVERFLOW'S STATUS (6) NOT SAVED
011322 022767 011252 166450  CMP      #REDSA,0     ;WAS OVERFLOW'S VECTOR SAVED?
011330 001401          BEQ      .+4
011332 000000          HLT      ;ERROR! OVERFLOW'S VECTOR (4) NOT SAVED
011334 005706          TST      %6
011336 001401          BEQ      .+4
011340 000000          HLT
011342 010701          SCOPE      ;SCOPE STORES PC IN R1

011344 013737 000032 000030  MOV      @#EMTVEC+2,@#EMTVEC
011352 005037 000032          CLR      @#EMTVEC+2

;TEST THAT AN ODD ADDRESS ERROR USING THE STACK POINTER RESULTS IN A 'RED' TRAP
011356 012706 001000          MOV      #1000,%6
011362 012737 011402 000004  MOV      #RED6,@#ERRVEC
011370 005037 000006          CLR      @#ERRVEC+2
011374 005066 177777          CLR      -1(6)        ;-1(6) IS ODD
011400 000000          HLT      ;ERROR! FAILED TO TRAP
011402 022767 011400 166370  RED6A:  CMP      #RED6A,0   ;CHECK RETURN PC IN ADDRESS 0
011410 001401          BEQ      .+4
011412 000000          HLT      ;ERROR! 'RED' TRAP DID NOT SAVE PC IN 0
011414 010701          SCOPE      ;SCOPE STORES PC IN R1

;THIS TEST IS THE SAME AS ABOVE EXCEPT THAT INDEX DEFERRED MODE IS USED.
;NOTE: A 'RED TRAP' SHOULD NOT OCCUR.
011416 012706 001000          MOV      #1000,%6
011422 005067 166352          CLR      0
011426 012767 000777 167342  MOV      #777,776
011434 012737 011450 000004  MOV      #RED7,@#ERRVEC
011442 005076 177776          CLR      @-2(6)
011446 000000          HLT      RED7A:      ;ERROR! FAILED TO TRAP
011450 022767 011446 167316  RED7:  CMP      #RED7A,774  ;RETURN PC IN 774?
011456 001401          BEQ      .+4

```

```

011460 000000          HLT          ;ERROR! RED TRAP FAILED
011462 005767 166312  TST          0          ;TEST THAT RED TRAP DID NOT OCCUR
011466 001401          BEQ          .+4
011470 000000          HLT          ;ERROR! 'RED TRAP' ON STACK RELATED REFERENCE
011472 010701          SCOPE        ;SCOPE STORES PC IN R1

;TEST THAT 'A TIME OUT' WHEN THE STACK POINTER IS USED DOES NOT CAUSE A 'RED' TRAP
;IF MODE 5.
011474 012706 001000  MOV          #1000,%6
011500 005067 166274  CLR          0          ;PRE SET ADDRESS 0
011504 012767 177700 167264  MOV          #177700,776 ;776 CONTAINS ADDRESS OF R0
011512 012737 011524 000004  MOV          #RED10,2#ERRVEC
011520 005056          CLR          2-(6)      ;R0 IS NOT A BUS ADDRESS
011522 000000          HLT          ;ERROR! FAILED TO TRAP
011524 005767 166250  RED10: TST          0          ;WAS ADDRESS 0 UNCHANGED?
011530 001401          BEQ          .+4
011532 000000          HLT          ;ERROR! A 'RED' TRAP OCCURRED
011534 010701          SCOPE        ;SCOPE STORES PC IN R1

;TEST THAT A 'TIME OUT' CAN CAUSE A 'RED' TRAP IF MODE 6.
011536 012706 001000  MOV          #1000,%6
011542 005067 166232  CLR          0          ;PRE SET ADDRESS 0
011546 012737 011562 000004  MOV          #RED11,2#ERRVEC
011554 005066 176700  CLR          176700(6) ;FINAL ADDRESS IS 177700 (R0)
011560 000000          HLT          ;ERROR! NO OVERFLOW TRAP
011562 022767 011560 166210 RED11A: HLT
RED11:  CMP          #RED11A,0 ;WAS 'RED' TRAP TAKEN?
011570 001401          BEQ          .+4
011572 000000          HLT          ;ERROR! NO 'RED' TRAP
011574 010701          SCOPE        ;SCOPE STORES PC IN R1

;CHECK 'T' BIT TRAP IN RED ZONE
011576 012737 011642 000004  MOV          #RED12B,2#ERRVEC ;LOAD ERROR (OVERFLOW) TRAP VECTOR
011604 012737 011634 000014  MOV          #RED12C,2#TBITVEC ;LOAD 'T' BIT TRAP VECTOR
011612 012706 000334          MOV          #334,%6      ;SET STACK IN RED ZONE
011616 010605          MOV          %6,%5
011620 012725 011636          MOV          #RED12A,(5)+ ;SET UP TO SET 'T' BIT
011624 012725 000020          MOV          #20,(5)+
011630 000006          RTT          ;SET 'T' BIT & GO TO RED12A
011632 000000          HLT          ;ERROR! TRAP ON RTT
011634 000000          RED12C: HLT          ;ERROR! NO RED OVERFLOW BEFORE 'T' TRAP
011636 005046          RED12A: CLR          -(6) ;RESULTS IN 'RED' OVERFLOW TRAP
011640 000000          HLT          ;ERROR! NO TRAP
011642 022767 011640 166130 RED12B: CMP          #RED12A+2,0 ;CHECK 'T' BIT TRAP VECTOR ON STACK
011650 001401          BEQ          .+4
011652 000000          HLT          ;ERROR!
011654 022767 000020 166120          CMP          #20,2      ;CHECK 'T' BIT ON STACK
011662 001401          BEQ          .+4
011664 000000          HLT          ;ERROR!
011666 012737 000016 000014  MOV          #TBITVEC+2,2#TBITVEC
011674 010701          SCOPE        ;SCOPE STORES PC IN R1

;TEST TRANSITION FROM 'YELLOW' TO 'RED' ZONES. THE TRANSITION OCCURS AFTER
;THE JSR HAS 'PUSHED' ITS OLD R5.
011676 012706 000342          MOV          #342,%6 ;SET UP STACK ON THE 'HAIRY EDGE'
011702 012737 011764 000004  MOV          #HAIR1,2#ERRVEC ;LOAD OVERFLOW VECTOR

```

```

011710 012737 000357 000006      MOV      #357, @#ERRVEC+2      ;AND OVERFLOW STATUS
011716 005037 000000      CLR      @#0
011722 005037 000002      CLR      @#2
011726 005037 000336      CLR      @#336
011732 005037 000340      CLR      @#340
011736 012705 000007      MOV      #7, %5      ;PRE SET R5
011742 012737 000017 177776      MOV      #17, @#PSW      ;PRE SET THE STATUS WORD
011750 004567 000004      JSR      5, HAIR      ;THIS SHOULD RAISE SOME HAIR
011754 000000      HAIR1B: HLT      ;ERROR! DID NOT TRAP
011756 000240      NOP
011760 000000      HAIR:  HLT      ;ERROR! DID NOT TRAP
011762 000240      NOP
011764 022737 000007 000340  HAIR1:  CMP      #7, @#340      ;WAS R5 SAVED ON THE STACK
011772 001401      BEQ      .+4
011774 000000      HLT      ;ERROR! R5 NOT SAVED ON THE STACK
011776 022705 011754      CMP      #HAIR1B, %5      ;DOES R5 CONTAIN RETURN ADDRESS?
012002 001401      BEQ      .+4
012004 000000      HLT      ;ERROR! R5 DID NOT GET RETURN ADRS.
012006 022737 000357 000002      CMP      #357, @#2      ;DID OVERFLOW SAVE THE STATUS?
012014 001401      BEQ      .+4
012016 000000      HLT      ;OVERFLOW DID NOT SAVE STATUS
012020 022737 011764 000000      CMP      #HAIR1, @#0      ;WAS RETURN ADDRESS SAVED ON THE STACK
012026 001401      BEQ      .+4
012030 000000      HLT      ;OVERFLOW TRAP DID NOT SAVE RETURN PC
012032 005737 000336      TST      @#336      ;CHECK THAT 'RED' LOCATION WAS NOT CHANGED
012036 001401      BEQ      .+4
012040 000000      HLT      ;ERROR! 'RED' LOCATION WAS CHANGED
012042 010701      SCOPE      ;SCOPE STORES PC IN R1

```

; THIS TEST IS THE SAME AS ABOVE EXCEPT THAT THE TRANSITION IS AFTER THE  
; OVERFLOW PUSHES ONE WORD.

```

012044 012706 000344      MOV      #344, %6
012050 012737 012116 000004      MOV      #HAIR2, @#ERRVEC ;SET ERROR TRAP VECTOR
012056 005037 000006      CLR      @#6
012062 005037 000342      CLR      @#342
012066 012737 136336 000336      MOV      #136336, @#336 ;PRE SET 'RED' LOCATION
012074 012705 000007      MOV      #7, %5      ;PRE SET R5
012100 012737 000357 177776      MOV      #357, @#PSW      ;PRE SET STATUS
012106 004567 000002      JSR      5, HAIR2A      ;HERE WE GO AGAIN
012112 000000      HAIR2B: HLT      ;ERROR DID NOT TRAP
012114 000000      HAIR2A: HLT      ;ERROR! DID NOT TRAP
012116 022737 000007 000342  HAIR2:  CMP      #7, @#342      ;WAS R5 SAVED
012124 001401      BEQ      .+4
012126 000000      HLT      ;ERROR! R5 NOT SAVED ON THE STACK
012130 022705 012112      CMP      #HAIR2B, %5      ;DOES R5 CONTAIN RETURN PC?
012134 001401      BEQ      .+4
012136 000000      HLT      ;ERROR! JSR DID NOT LOAD R5
012140 022737 000357 000340      CMP      #357, @#340      ;WAS STATUS SAVED?
012146 001401      BEQ      .+4
012150 000000      HLT      ;ERROR! STATUS NOT SAVED
012152 005737 000002      TST      @#2      ;WAS STATUS SAVED?
012156 001401      BEQ      .+4
012160 000000      HLT      ;ERROR! STATUS NOT SAVED
012162 022737 012116 000000      CMP      #HAIR2, @#0      ;RETURN PC SAVED?
012170 001401      BEQ      .+4
012172 000000      HLT      ;ERROR! RETURN PC NOT SAVED

```

```

012174 022737 136336 000336      CMP      #136336, @#336      ; WAS 'RED' LOCATION UNDISTURBED?
012202 001401                      BEQ      .+4
012204 000000                      HLT
012206 010701                      SCOPE      ; ERROR! 'RED' LOCATION WAS CHANGED
                                           ; SCOPE STORES PC IN R1

; TEST THAT A TTY INTERRUPT CAUSES AN OVERFLOW TRAP
012210 012737 000340 177776      MOV      #340, @#PSW      ; LOCK OUT INTERRUPT
012216 012706 000400                      MOV      #400, %6      ; SET UP STACK TO OVERFLOW
012222 012737 012262 000004      MOV      #TDEC7, @#ERRVEC ; SET UP OVERFLOW TRAP
012230 012737 012260 000064      MOV      #TDEC8, @#TPVEC ; SET UP INTERRUPT VECTOR
012236 105737 177564      1$: TSTB   @#TTCSR      ; WAIT FOR TTY TO BE READY
012242 100375                      BPL      1$
012244 012737 000100 177564      MOV      #100, @#TTCSR   ; SET INTERRUPT ENABLE
012252 005037 177776      CLR      @#PSW          ; ALLOW INTERRUPT TO OCCUR
012256 000000                      HLT      ; NO INTERRUPT OCCURRED
012260 000000      TDEC8: HLT      ; TRAP FLAG OVERFLOW DID NOT OCCUR
012262 005037 177564      TDEC7: CLR      @#TTCSR ; CLEAR INTERRUPT ENABLE
012266 012737 000066 000064      MOV      #TPVEC+2, @#TPVEC
012274 012737 000006 000004      MOV      #ERRVEC+2, @#ERRVEC
012302 010701                      SCOPE      ; SCOPE STORES PC IN R1

; DOES THE PROCESSOR TRAP WHEN %7 IS ODD?
012304 012706 000500                      R7TRX: MOV      #STKPTR, %6      ; SET UP STACK POINTER
012310 012737 012326 000004      MOV      #R7TR1, @#ERRVEC ; RETURN FROM TRAP
012316 012707 000001                      MOV      #1, %7          ; PC EQUALS ONE
012322 000000                      HLT
012324 000000                      HLT
012326 022767 000003 166140      R7TR1: CMP      #3, STKPTR-4
012334 001401                      BEQ      .+4              ; CORRECT PC WAS NOT SAVED ON STACK
012336 000000                      HLT
012340 010701                      SCOPE      ; SCOPE STORES PC IN R1

012342 012706 000500                      MOV      #STKPTR, %6      ; STACK POINTER
012346 012737 012362 000004      MOV      #R7TR2, @#ERRVEC ; PC BECOMES ODD
012354 005207                      INC      %7
012356 000000      R7TR2A: HLT
012360 000000                      HLT
012362 022767 012361 166104      R7TR2: CMP      #R7TR2A+3, STKPTR-4
012370 001401                      BEQ      .+4              ; CORRECT PC NOT ON STACK
012372 000000                      HLT
012374 010701                      SCOPE      ; SCOPE STORES PC IN R1

012376 012706 000500                      MOV      #STKPTR, %6
012402 012737 012414 000004      MOV      #R7TR3, @#ERRVEC ; MAKE PC ODD
012410 005307                      DEC      %7              ; SHOULD TRAP
012412 000000                      HLT                      ; CHECK VALUE OF PC ON STACK
012414 022767 012413 166052      R7TR3: CMP      #.-1, STKPTR-4
012422 001401                      BEQ      .+4
012424 000000                      HLT                      ; WRONG VALUE ON STACK
012426 010701                      SCOPE      ; SCOPE STORES PC IN R1

012430 012706 000500                      MOV      #STKPTR, %6
012434 012737 012452 000004      MOV      #R7TR4, @#ERRVEC ; CARRY EQUALS A 1
012442 000261                      SEC
012444 006107                      ROL      %7              ; PC BECOMES ODD

```

012446	000000			TR4A:	HLT		
012450	000000				HLT		
012452	022767	025117	166014	R7TR4:	CMP	#TR4A+TR4A+3,STKPTR-4	;CHECK FOR VALUE ON STACK
012460	001401				BEG	.+4	
012462	000000				HLT		;WRONG VALUE ON STACK
012464	012737	000006	000004		MOV	#ERRVEC+2,@#ERRVEC	
012472	010701				SCOPE		;SCOPE STORES PC IN R1

```

;TEST THAT THE 'T' BIT WILL CAUSE A TRAP
012474 012706 000500          MOV      #STKPTR,%6          ;SET UP STACK POINTER
012500 012737 012530 000014  MOV      #TRC1,@#TBITVEC    ;TRACE TRAP RETURN
012506 005037 000016          CLR      @#TBITVEC+2
012512 012746 000020          MOV      #20,-(6)          ;PUSH 'T' BIT ON THE STACK
012516 012746 012524          MOV      #.+6,-(6)        ;PUSH PC ON THE STACK
012522 000006          RTT
012524 000240          NOP                        ;SET 'T' BIT
012526 000000          HLT                        ;'T' TRAP ACKNOWLEDGED AFTER NOP
012530 036727 165742 000020  TRC1:  BIT      STKPTR-2,#20    ;ERROR! 'T' TRAP FAILED TO TRAP
012536 001001          BNE      .+4                ;CHECK FOR T BIT ON STACK
012540 000000          HLT
012542 010701          SCOPE                       ;T BIT NOT SAVED ON STACKED
;SCOPE STORES PC IN R1

;TEST THAT AN RTI POPS THE T BIT
012544 012706 000500          MOV      #STKPTR,%6          ;SET UP THE STACK
012550 012746 000020          MOV      #20,-(6)          ;FUTURE T BIT ON STACK
012554 012746 012570          MOV      #TRC2,-(6)        ;RTI RETURN
012560 012737 012574 000014  MOV      #TRC3,@#TBITVEC    ;TRACE TRAP INTERRUPT POINTER
012566 000002          RTI
012570 000000          TRC2: HLT                    ;TRACE IS SET SHOULD TRAP TO 14
012572 000000          HLT                        ;DID NOT TRACE TRAP
012574 010701          TRC3: SCOPE                  ;SCOPE STORES PC IN R1

;TEST RTT POPS TBIT
012576 012706 000500          MOV      #STKPTR,%6
012602 012746 000020          MOV      #20,-(6)
012606 012746 012622          MOV      #TRC4,-(6)
012612 012737 012634 000014  MOV      #TRC5,@#TBITVEC
012620 000006          RTT
012622 000240          TRC4: NOP
012624 000000          HLT                        ;ERROR! 'T' BIT NOT SET
012626 012737 000016 000014  TRC5:  MOV      #TBITVEC+2,@#TBITVEC
012634 010701          TRC5: SCOPE                  ;SCOPE STORES PC IN R1

;TEST THAT INTERRUPT OCCURS BEFORE TRAP
012636 012706 000500          MOV      #STKPTR,%6
012642 012737 000340 177776  MOV      #340,@#PSW          ;HIGHEST PRIORITY LEVEL
012650 012737 000100 177564  MOV      #100,@#TTCSR        ;INTERRUPT FOR TTY PUNCH/PRINTER
012656 012737 012706 000034  MOV      #TR1,@#TRAPVEC      ;TRAP VECTOR
012664 012737 012710 000064  MOV      #TR2,@#TPVEC        ;TTY VECTOR
012672 012737 000340 000036  MOV      #340,@#TRAPVEC+2    ;IF TRAP TRAPS, MOVE 340 TO PRIORITY
012700 005037 177776          CLR      @#PSW              ;SHOULD TRAP AT END OF CLR INST
012704 104400          TRAP                          ;TTY INTERRUPT SHOULD OVERRIDE TRAP
012706 000000          TR1:  HLT                    ;TRAP OCCUR FIRST
012710 005037 177564          TR2:  CLR      @#TTCSR
012714 010701          TR2:  SCOPE                  ;SCOPE STORES PC IN R1

;WILL INTERRUPTS OCCURE BETWEEN TRAPS
012716 012706 000500          MOV      #STKPTR,%6
012722 012737 000340 177776  MOV      #340,@#PSW
012730 012737 000100 177564  MOV      #100,@#TTCSR
012736 012737 012774 000034  MOV      #TR3,@#TRAPVEC      ;TRAP
012744 005037 000036          CLR      @#TRAPVEC+2
012750 012737 013000 000064  MOV      #TR4,@#TPVEC        ;TTY OUTPUT

```



```

012756 012737 012776 000020      MOV      #TR5, @#IOTVEC      ; IOT
012764 012737 000340 000022      MOV      #340, @#IOTVEC+2  ; IOT PRIORITY
012772 104400                      TRAP                      ; THE ACT OF TRAPPING LOWERS PRIORITY
012774 000004                      TR3: IOT                   ; INTERRUPT SHOULD OCCURE INPLACE OF IOT TRAP
012776 000000                      TR5: HLT                   ; NO INTERRUPT BETWEEN TRAPS
013000 005037 177564                      TR4: CLR      @#TTCSR
013004 012737 000036 000034      MOV      #TRAPVEC+2, @#TRAPVEC
013012 012737 000022 000020      MOV      #IOTVEC+2, @#IOTVEC
013020 005037 000022                      CLR      @#IOTVEC+2      ; CLR IOT PRIORITY
013024 010701                      SCOPE                      ; SCOPE STORES PC IN R1

;TEST THAT 'T' BIT TRAP OCCURS AFTER AN INTERRUPT IS ACKNOWLEDGED.
013026 012737 000340 177776      MOV      #340, @#PSW      ; SET PRIORITY =7
013034 012737 000100 177564      MOV      #100, @#TTCSR   ; ENABLE INTERRUPT ON TTY PRINTER
013042 012737 013074 000014      MOV      #INT, @#TBITVEC ; LOAD 'T' BIT VECTOR
013050 012737 013076 000064      MOV      #INT+2, @#TPVEC ; LOAD TTY INT. VECTOR
013056 012706 000500                      MOV      #STKPTR, %6     ; SET STACK POINTER
013062 012746 000020                      MOV      #20, -(6)      ; PUSH 'T' BIT ON THE STACK
013066 012746 013074                      MOV      #.+6, -(6)     ; PUSH PC ON THE STACK
013072 000006                      RTT                      ; SET 'T' BIT
013074 000000                      INT: HLT                 ; ERROR! TTY FAILED TO INTERRUPT BEFORE 'T' TRAP
013076 005037 177564                      CLR      @#TTCSR        ; DISABLE TTY INTERRUPT
013102 012737 000016 000014      MOV      #TBITVEC+2, @#TBITVEC
013110 010701                      SCOPE                      ; SCOPE STORES PC IN R1

;TEST THAT "RESET" GOES TO OUTSIDE WORLD
013112 010701                      SCOPE                      ; SCOPE STORES PC IN R1
013114 012706 000500                      MOV      #STKPTR, %6
013120 012737 000340 177776      MOV      #340, @#PSW      ; LOCK OUT INTERRUPTS
013126 012737 013160 000064      MOV      #TR6, @#TPVEC   ; LOAD TELEPRINTER VECTOR
013134 012737 000100 177564      MOV      #100, @#TTCSR   ; SET INTERRUPT ENABLE
013142 000005                      RESET                     ; SHOULD CLEAR INTERRUPT ENABLE
013144 032737 000100 177564      BIT      #100, @#TTCSR   ; TEST FOR CLEAR
013152 001401                      BEQ      .+4
013154 000000                      HLT
013156 000402                      BR      TR6X             ; RESET FAILED TO CLEAR @#TTCSR
013160 000000                      TR6: HLT                 ; GO TO SCOPE ; SCOPE STORES PC IN R1
                                ; ERROR! TELETYPE INTERRUPTED WHEN
                                ; PROCESSER WAS AT LEVEL 7
013162 022626                      TR6X: CMP      (6)+, (6)+
013164 010701                      SCOPE                      ; SCOPE STORES PC IN R1

;TEST THAT RESET DOES NOT HANG THE SYSTEM
013166 012706 000500                      MOV      #STKPTR, %6     ; SET STACK
013172 005037 177776                      CLR      @#PSW           ; ALLOW INTERRUPT
013176 012737 013212 000064      MOV      #RESET1, @#TPVEC ; TTY INTERRUPT VECTOR
013204 052737 000100 177564      BIS      #100, @#TTCSR   ; SET INTERRUPT ENABLE
013212 000005                      RESET1: RESET            ; IF THIS HANGS CHECK SACK
013214 012737 000066 000064      MOV      #66, @#TPVEC   ; FOR FALSE INTERRUPT
013222 010701                      SCOPE                      ; SCOPE STORES PC IN R1

;TEST RESET WITH TRACE ON
013224 012706 000500                      MOV      #STKPTR, %6     ; SET STACK
013230 012737 013262 000014      MOV      #RESET2, @#TBITVEC ; SET UP TRACE VECTOR
013236 005037 000016                      CLR      @#TBITVEC+2
013242 012746 000020                      MOV      #20, -(6)      ; PUSH 'T' BIT ON THE STACK
013246 012746 013254                      MOV      #.+6, -(6)     ; PUSH PC ON THE STACK

```

```

013252 000006          RIT          ;SET 'T' BIT
013254 000005          RESET        ;SHOULD HAVE NO EFFECT
013256 000005          RESET        ;NO EFFECT
013260 000000          HLT          ;TRACE TRAP FAILED
013262 012737 000016 000014 RESET2: MOV      #TBITVEC+2, @TBITVEC
013270 010701          SCOPE

;TEST THAT WHEN TTY INTERRUPTS IT POPS NEW STATUS
013272 000005          RESET
013274 012706 000500  MOV      #STKPTR,%6          ;SET UP STACK
013300 012737 013324 000064  MOV      #TTY3, @TPVEC      ;INTERRUPT VECTOR
013306 005037 177776  CLR      @PSW              ;DROP PROCESSOR PRIORITY
013312 012767 000357 164546  MOV      #357,66          ;HIGH PRIORITY ON INTERRUPT
013320 005137 177564  COM      @TTCSR          ;SHOULD SET INTERRUPT ENABLE & INTERRUPT
013324 013727 177776  TTY3:  MOV      @PSW,(7)+    ;SAVE PROCESSOR STATUS
013330 000000          .WORD      0          ;IS SAVED HERE
013332 022767 000357 177770  CMP      #357,.-2
013340 001401          BEQ      .+4
013342 000000          HLT
013344 000005          RESET        ;INTERRUPT DID NOT POP CORRECT STATUS
013346 010701          SCOPE        ;CLR INTERRUPT ENABLE
;SCOPE STORES PC IN R1

013350 012706 000500  MOV      #STKPTR,%6          ;STACK SET UP
013354 012737 013400 000064  MOV      #TTY4, @TPVEC      ;INTERRUPT VECTOR
013362 005067 164500  CLR      66              ;CLR NEW STATUS
013366 012737 000157 177776  MOV      #157, @PSW        ;PROCESSOR STATUS
013374 005137 177564  COM      @TTCSR          ;SET INTERRUPT ENABLE
013400 013727 177776  TTY4:  MOV      @PSW,(7)+    ;SAVE NEW STATUS
013404 000000          .WORD      0          ;IS SAVED HERE
013406 005767 177772  TST      .-2
013412 001401          BEQ      .+4
013414 000000          HLT          ;INTERRUPT DID NOT POP NEW STATUS
013416 005037 177564  CLR      @TTCSR
013422 010701          SCOPE        ;SCOPE STORES PC IN R1

;TEST THAT A PROGRAMMED INTERRUPT REQUEST IS HONORED BEFORE A BUS
;REQUEST AT THE SAME INTERRUPT LEVEL
013424 000237          SPL          ;SET PRIORITY LEVEL 7
013426 000005          RESET
013430 012737 013506 000240  MOV      #PIRINT, @PIRVEC    ;SET PIRQ INTERRUPT VECTOR
013436 012737 000340 000242  MOV      #340, @PIRVEC+2    ;ASSUME PRIORITY LEVEL 7 ON INT
013444 012737 013532 000064  MOV      #TTY5, @TPVEC      ;SET TELEPRINTER INT VECTOR
013452 012737 000340 000066  MOV      #340, @TPVEC+2    ;PRIORITY LEVEL 7 ON TTY INT
013460 005137 177564  COM      @TTCSR          ;ENABLE INTERRUPT
013464 005067 002426  CLR      TEMP
013470 012737 010000 177772  MOV      #PIR4, @PIRQ
013476 005037 177776  CLR      @PSW
013502 000000          HLT          ;BOOK REQUEST AT LEVEL 4
013504 000000          HLT          ;ALLOW INTERRUPTS
013506 012737 013542 000064  PIRINT: MOV      #TTY6, @TPVEC    ;ERROR! NO INTERRUPT
013514 005267 002376          INC      TEMP          ;ERROR! TTY DID NOT INTERRUPT AFTER PIRQ
013520 005037 177772          CLR      @PIRQ        ;RESET TTY INTERRUPT VECTOR
013524 062716 000002          ADD      #2,(6)        ;SET INDICATOR
013530 000002          RTI          ;DISABLE REQUEST
013532 000000          TTY5:  HLT          ;ADJUST RETURN PC TO SECOND HLT
013534 005037 177772          CLR      @PIRQ        ;GO HONOR TTY INTERRUPT
;ERROR! DID NOT HONOR PIR
;DISABLE REQUEST

```

```

013540 000406
013542 005367 002350
013546 005767 002344
013552 001401
013554 000000
013556 000005
013560 012737 000242 000240
013566 012706 000500
013572 010701

TTY6: BR TTYEX ;EXIT TEST
DEC TEMP
TST TEMP
BEQ .+4
HLT ;ERROR! BOTH INTERRUPTS WERE NOT HONORED
TTYEX: RESET
MOV #PIRVEC+2, @#PIRVEC
MOV #STKPTR, %6 ;RESTORE STACK POINTER
SCOPE ;SCOPE STORES PC IN R1

;CHECK THAT 'T' BIT DOES NOT TRAP OUT OF WAIT
013574 022767 000010 165176 CMP #8, ICNT ;DO THIS TEST FIRST 8 PASSES ONLY
013602 003457 BLE TTYEND
013604 000230 SPL 0 ;SET PRIORITY LEVEL 0
013606 012706 000500 MOV #STKPTR, %6 ;SET STACK PTR
013612 012737 013650 000064 MOV #TTY7A, @#TPVEC ;LOAD TTY INTERRUPT VECTOR
013620 012737 013644 000014 MOV #TTY7B, @#BPTVEC ;LOAD 'T' BIT TRAP VECTOR
013626 005002 CLR %2 ;CLEAR INDICATOR
013630 052737 000100 177564 BIS #100, @#TTCSR ;ALLOW INTERRUPT INTERRUPT OCCURS AFTER
;THIS INSTRUCTION & BEFORE NEXT
;WAIT FOR AN INTERRUPT
013636 000001 WAITI: WAIT
013640 005202 INC %2 ;INCREMENT INDICATOR
013642 000000 HLT ;ERROR! NO 'T' TRAP AFTER INTERRUPT
013644 000000 TTY7B: HLT ;ERROR! 'T' BIT TRAPPED OUT OF WAIT
013646 000424 BR TTY7EX ;EXIT TEST
013650 012737 000040 177566 TTY7A: MOV #40, @#177566 ;TYPE SPACE CHAR
013656 012737 013674 000064 MOV #TTY7C, @#IPVEC ;REPOSITION TTY INT VECTOR
013664 012766 000020 000002 MOV #20, 2(6) ;PUT 'T' BIT IN RETURN STATUS
013672 000006 RTT ;RETURN TO WAIT WITH 'T' BIT SET
;AND WAIT FOR TTY INTERRUPT WHEN NULL
;CHARACTER IS TYPED.
013674 012737 013716 000014 TTY7C: MOV #TTY7D, @#BPTVEC ;REPOINT 'T' BIT TRAP VECTOR AFTER
;TTY HAS INTERRUPTED
013702 005037 177564 CLR @#TTCSR ;DISABLE INTERRUPT ENABLE
013706 012737 000015 177566 MOV #15, @#177566
013714 000006 RTT ;RETURN TO INST FOLLOWING WAIT WITH 'T'
;BIT SET

013716 000240 TTY7D: NOP
013720 012737 000016 000014 TTY7EX: MOV #BPTVEC+2, @#BPTVEC;RESTORE VECTORS TO HALT AT
013726 012737 000066 000064 MOV #66, @#TPVEC ;VECTOR +2
013734 005302 DEC %2 ;CHECK INDICATOR
013736 001401 BEQ .+4
013740 000000 HLT ;ERROR! DID NOT DO INC INST AFTER INTERRUPT
013742 010701 TTYEND: SCOPE ;SCOPE STORES PC IN R1

;CHECK THAT PIRQ WILL INTERRUPT OUT OF WAIT
013744 012706 000500 MOV #STKPTR, %6 ;SET STACK PTR
013750 000237 SPL 7 ;SET PRIORITY LEVEL 7
013752 012737 010000 177772 MOV #PIR4, @#PIRQ ;BOOK REQUEST AT LEVEL 4
013760 012737 000340 000242 MOV #340, @#PIRVEC+2 ;LEVEL 7 ON INTERRUPT
013766 012737 014002 000240 MOV #PIRQA, @#PIRVEC ;GO TO PIRQ ON INTERRUPT
013774 000230 SPL 0 ;SET PRIORITY LEVEL 0
013776 000001 WAITI: WAIT ;PIRQ SHOULD INTERRUPT OUT OF WAIT
;
;****CAUTION PROGRAM COULD HANG HERE IF TEST FAILS****
014000 000000 HLT ;ERROR!
014002 005037 177772 PIRQA: CLR @#PIRQ ;CLEAR REQUEST

```



014222	010701		SCOPE		;SCOPE STORES PC IN R1
014224	012706	000500	MOV	#STKPTR,%6	
014230	005004		CLR	%4	
014232	122624		CMPB	(6)+,(4)+	;TEST INCREMENT OF R6
014234	020627	000502	CMP	%6,#STKPTR+2	
014240	001401		BEQ	.+4	
014242	000000		HLT		;WRONG INCREMENT OF R6
014244	010701		SCOPE		;SCOPE STORES PC IN R1
014246	012706	000500	MOV	#STKPTR,%6	
014252	005004		CLR	%4	
014254	122426		CMPB	(4)+,(6)+	;TEST INCREMENT OF R6
014256	020627	000502	CMP	%6,#STKPTR+2	
014262	001401		BEQ	.+4	
014264	000000		HLT		;WRONG INCREMENT OF R6
014266	010701		SCOPE		;SCOPE STORES PC IN R1
014270	012706	000500	MOV	#STKPTR,%6	
014274	005004		CLR	%4	
014276	122624		CMPB	(6)+,(4)+	;TEST INCREMENT OF R4
014300	020427	000001	CMP	%4,#1	
014304	001401		BEQ	.+4	
014306	000000		HLT		;WRONG INCREMENT OF R4
014310	010701		SCOPE		;SCOPE STORES PC IN R1

014312	012706	000500		MOV	#STKPTR,%6	
014316	005004			CLR	%4	
014320	122446			CMPB	(4)+-(6)	;TEST DECREMENT OF R6
014322	020627	000476		CMP	%6,#STKPTR-2	
014326	001401			BEQ	+.4	
014330	000000			HLT		;WRONG INCREMENT OF R6
014332	010701			SCOPE		;SCOPE STORES PC IN R1
014334	012706	000500		MOV	#STKPTR,%6	
014340	005004			CLR	%4	
014342	122426			CMPB	(4)+(6)+	;TEST INCREMENT OF R4
014344	020427	000001		CMP	%4,#1	
014350	001401			BEQ	+.4	
014352	000000			HLT		;WRONG INCREMENT OF R4
014354	010701			SCOPE		;SCOPE STORES PC IN R1
014356	012706	010000		MOV	#10000,%6	
014362	124527	000000		CMPB	-(6),#0	;TEST DECREMENT OF R6
014366	022736	007776		CMP	#7776,%6	
014372	001401			BEQ	+.4	
014374	000000			HLT		;WRONG DECREMENT OF R6
014376	010701			SCOPE		;SCOPE STORES PC IN R1
014400	012706	000500		MOV	#STKPTR,%6	;INITIAL POSITION OF R6
014404	012767	177777	164064	MOV	#-1,STKPTR-2	;HIGH BYTE WILL BE DATA
014412	012767	025252	177474	MOV	#25252,K1	
014420	114667	177471		MOVB	-(6),K1+1	;MOV TO ODD ADDRESS
014424	022767	177652	177462	CMP	#177652,K1	;DID MOVB WORK CORRECTLY
014432	001401			BEQ	+.4	
014434	000000			HLT		;MOVB -(6), ODD: FAILED
014436	010701			SCOPE		;SCOPE STORES PC IN R1
014440	012706	000500		MOV	#STKPTR,%6	;INITIAL POSITION OF R6
014444	012767	177777	164024	MOV	#-1,STKPTR-2	;HIGH BYTE SOURCE DATA
014452	012767	125252	177434	MOV	#125252,K1	;INITIAL SET UP OF DESTINATION
014460	114667	177430		MOVB	-(6),K1	;HIGH BYTE OF STKPTR-2, TO LOW BYTE OF K1
014464	022767	125377	177422	CMP	#125377,K1	;TEST RESULTS
014472	001401			BEQ	+.4	
014474	000000			HLT		;MOVB -(6), EVEN, FAILED
014476	010701			SCOPE		;SCOPE STORES PC IN R1

```

;TEST TRANSFER OF .BYTE USING R6
014500 012767 123456 177416      MOV      #123456,K5
014506 012767 050505 177400      MOV      #050505,K1
014514 012705 014114              MOV      #K1,%5          ;%5=(050505)K1
014520 012706 014124              MOV      #K5,%6          ;%6(123456)K5
014524 112625              MOV      (6)+,(5)+      ;LOW .BYTE OF R6 TO R5
014526 022767 050456 177360      CMP      #050456,K1
014534 001401              BEQ
014536 000000              HLT
014540 010701              SCOPE          ;FALSE TRANSFER OF .BYTE
;SCOPE STORES PC IN R1

014542 012767 123456 177354      MOV      #123456,K5
014550 012767 050505 177336      MOV      #050505,K1
014556 012705 014114              MOV      #K1,%5          ;%5(050505)K1
014562 012706 014126              MOV      #K6,%6          ;%6(123456)K5
014566 114625              MOV      -(6),(5)+      ;LOW .BYTE OF R6 TO R5 (DECREMENT)
014570 026727 177320 050456      CMP      K1,#050456
014576 001401              BEQ
014600 000000              HLT
014602 010701              SCOPE          ;FALSE R6 .BYTE TRANSFER
;SCOPE STORES PC IN R1

014604 012767 123456 177302      MOV      #123456,K1
014612 012767 050505 177304      MOV      #050505,K5
014620 012705 014114              MOV      #K1,%5          ;(123456)
014624 012706 014124              MOV      #K5,%6          ;(050505)
014630 112526              MOV      (5)+,(6)+      ;LOW OF R5 TO LOW OF R6
014632 022767 050456 177264      CMP      #050456,K5
014640 001401              BEQ
014642 000000              HLT
014644 010701              SCOPE          ;FALSE R6 .BYTE TRANSFER
;SCOPE STORES PC IN R1

014646 012767 123456 177240      MOV      #123456,K1
014654 012767 050505 177242      MOV      #050505,K5
014662 012705 014115              MOV      #K1+1,%5        ;123456
014666 012706 014124              MOV      #K5,%6          ;050505
014672 112526              MOV      (5)+,(6)+      ;HIGH OF R5 TO LOW OF R6
014674 026727 177224 050647      CMP      K5,#050647
014702 001401              BEQ
014704 000000              HLT
014706 010701              SCOPE          ;FALSE R6 .BYTE TRANSFER
;SCOPE STORES PC IN R1

014710 012767 123456 177176      MOV      #123456,K1
014716 012767 050505 177200      MOV      #050505,K5
014724 012705 014115              MOV      #K1+1,%5        ;R5-123456--ODD ADDRESS
014730 012706 014124              MOV      #K5,%6          ;R6-050505--.EVEN ADDRESS
014734 112625              MOV      (6)+,(5)+      ;LOW OF R6 TO HIGH OF R5
014736 022767 042456 177150      CMP      #042456,K1
014744 001401              BEQ
014746 000000              HLT
014750 010701              SCOPE          ;FAILED LOW OF 6 TO HIGH OF 5
;SCOPE STORES PC IN R1

```

```

;TEST .BYTE OPERATION WITH SEQUENTIAL ODD .EVEN ADDRESS
014752 126767 177152 177151  CMPB  K7,K7+1  ;SAME .WORD LOW TO HIGH
014760 001401  BEQ  .+4
014762 000000  HLT
014764 010701  SCOPE ;SHOULD COMPARE LOW TO HIGH
;SCOPE STORES PC IN R1

014766 126767 177137 177134  CMPB  K7+1,K7  ;COMPARE ODD TO .EVEN SAME .WORD
014774 001401  BEQ  .+4
014776 000000  HLT
015000 010701  SCOPE ;ODD TO .EVEN .BYTE FAILURE
;SCOPE STORES PC IN R1

015002 126767 177125 177120  CMPB  K10+1,K7  ;SEQUENTIAL .BYTES
015010 001401  BEQ  .+4 ;DIFFERENT .WORDS
015012 000000  HLT ;ODD TO .EVEN FAILED
015014 010701  SCOPE ;SCOPE STORES PC IN R1

015016 126767 177110 177102  CMPB  K10,K6
015024 001401  BEQ  .+4
015026 000000  HLT ;.EVEN TO EVEN FAILED
015030 010701  SCOPE ;SCOPE STORES PC IN R1

015032 126767 177073 177073  CMPB  K7+1,K10+1
015040 001401  BEQ  .+4
015042 000000  HLT ;ODD TO ODD FAILED
015044 010701  SCOPE ;SCOPE STORES PC IN R1

015046 126767 177060 177057  CMPB  K10,K10+1
015054 001001  BNE  .+4
015056 000000  HLT ;LOW TO HIGH IN SAME .WORD FAILED
015060 010701  SCOPE ;SCOPE STORES PC IN R1

015062 126767 177045 177042  CMPB  K10+1,K10
015070 001001  BNE  .+4
015072 000000  HLT ;HIGH TO LOW IN SAME .WORD FAILED
015074 010701  SCOPE ;SCOPE STORES PC IN R1

015076 126767 177030 177025  CMPB  K10,K7+1
015104 001001  BNE  .+4
015106 000000  HLT ;.EVEN TO ODD FAILED
015110 010701  SCOPE ;SCOPE STORES PC IN R1

```



```

;TEST THAT MOVB %R MOVES ONLY THE LSH OF THE REGISTER.
015112 012767 177777 177014 MOV #1,K11
015120 012700 000125 MOV #125,%0 ;LOAD R0
015124 110067 177004 MOVB %0,K11
015130 026727 177000 177525 CMP K11,#177525 ;WAS ONLY LSH MOVED?
015136 001401 BEQ .+4
015140 000000 HLT ;ERROR! MOVB %R FAILED
015142 010701 SCOPE ;SCOPE STORES PC IN R1

015144 012700 014134 MOV #K11,%0
015150 010067 176760 MOV %0,K11
015154 110020 MOVB %0,(0)+
015156 022767 014134 176750 CMP #K11,K11
015164 001401 BEQ .+4
015166 000000 HLT
015170 010701 SCOPE ;SCOPE STORES PC IN R1

015172 012706 014134 MOV #K11,%6
015176 010667 176732 MOV %6,K11
015202 110626 MOVB %6,(6)+
015204 026727 176724 014134 CMP K11,#K11
015212 001401 BEQ .+4
015214 000000 HLT ;FAILED MOVB %6,(6)+
015216 010701 SCOPE ;SCOPE STORES PC IN R1

015220 012706 014134 MOV #K11,%6
015224 010626 MOV %6,(6)+
015226 026727 176702 014134 CMP K11,#K11
015234 001401 BEQ .+4
015236 000000 HLT ;FAILED MOV %6,(6)+
015240 010701 SCOPE ;SCOPE STORES PC IN R1

015242 000277 SCC ;SET STATUS
015244 005037 177776 CLR @#PSW ;CLEAR STATUS
015250 103001 BCC .+4
015252 000000 HLT ;C NOT CLEAR
015254 102001 BVC .+4
015256 000000 HLT ;V NOT CLEAR
015260 001001 BNE .+4
015262 000000 HLT ;Z NOT CLEAR
015264 100001 BPL .+4
015266 000000 HLT ;N NOT CLEAR
015270 010701 SCOPE ;SCOPE STORES PC IN R1

015272 000257 CCC ;CLEAR CONDITION CODES
015274 052737 000017 177776 BIS #17,@#PSW ;SET STATUS TO ONES
015302 103401 BCS .+4

015304 000000 HLT ;C NOT SET
015306 102401 BVS .+4
015310 000000 HLT ;V NOT SET
015312 001401 BEQ .+4
015314 000000 HLT ;Z NOT SET
015316 100401 BMI .+4
015320 000000 HLT ;N NOT SET

```

015322	010701			SCOPE		;SCOPE STORES PC IN R1
015324	012706	000500		MOV	#STKPTR,%6	;SET UP STKPTRER POINTER
015330	005067	163146		CLR	STKPTR+2	;SET UP NEW STATUS
015334	012767	015344	163136	MOV	#+10,STKPTR	;SET UP, RETURN
015342	000006			RTT		;RETURN NEXT INSTRUCTION
015344	020627	000504		CMP	%6,#STKPTR+4	;%6 SHOULD BE PLUS 4
015350	001401			BEG	+.4	
015352	000000			HLT		;%6 NOT INCREMENTED
015354	010701			SCOPE		;SCOPE STORES PC IN R1
015356	012767	000357	163116	MOV	#357,STKPTR+2	;RETURN STATUS ALL ONES
015364	012706	000500		MOV	#STKPTR,%6	;SET UP STKPTRER POINTER
015370	012767	015402	163102	MOV	#+12,STKPTR	;SET UP RETURN POINTER
015376	000257			CCC		;CLEAR CONDITION CODES
015400	000006			RTT		;RETURN
015402	001401			BEG	+.4	
015404	000000			HLT		;Z NOT SET
015406	102401			BVS	+.4	
015410	000000			HLT		;V NOT SET
015412	100401			BMI	+.4	
015414	000000			HLT		;N NOT SET
015416	103401			BCS	+.4	
015420	000000			HLT		;C NOT SET
015422	010701			SCOPE		;SCOPE STORES PC IN R1
015424	005067	163052		CLR	STKPTR+2	;ZERO TO STATUS
015430	012706	000500		MOV	#STKPTR,%6	
015434	012767	015446	163036	MOV	#+12,STKPTR	
015442	000277			SCC		;SET CONDITION CODES
015444	000006			RTT		;RETURN
015446	001001			BNE	+.4	
015450	000000			HLT		;Z NOT CLEARED
015452	102001			BVC	+.4	
015454	000000			HLT		;V NOT CLEARED
015456	100001			BPL	+.4	
015460	000000			HLT		;N NOT CLEARED
015462	103001			BCC	+.4	
015464	000000			HLT		;C NOT CLEARED
015466	010701			SCOPE		;SCOPE STORES PC IN R1

```

;TEST THAT ALL RESERVED INSTRUCTIONS TRAP
015470 012700 016052
015474 012002
015476 012003
015500 020267 000376
015504 001440
015506 010267 000372
015512 012737 015534 000010
015520 012706 000500
015524 005037 177776
015530 000167 000350
GIN1: MOV #TABLE,TAB ;TABLE POINTER
MOV (TAB)+,FIRST ;FIRST OR CURRENT INSTRUCTION
MOV (TAB)+,LAST ;LAST INSTRUCTION OR GROUP
CMP FIRST,FINISH ;TESTED ALL
BEQ SINS1 ;GO TO MULT TRAPS TEST IF FIN.
GIN2: MOV FIRST,INST ;SET UP INST
MOV #RET,#RESVEC ;SET UP RETURN FROM TRAP
MOV #STKPTR,%6 ;SET UP STACK POINTER
CLR #PSW ;CLEAR PRIORITY
JMP INST ;EXECUTE RESERVED INSTRUCTION

;TRAPPING SHOULD SEND YOU HERE
015534 020627 000474
015540 001401
015542 000000
015544 026727 162724 016106
015552 001401
015554 000000
015556 005767 162714
015562 001401
015564 000000
015566 005267 000312
015572 005202
015574 026703 000304
015600 001735
015602 000167 177700
RET: CMP %6,#STKPTR-4 ;TEST DECREMENT OF %6
BEQ RET1
HLT
RET1: CMP STKPTR-4,#INST+2 ;WRONG DECREMENT
BEQ RET2 ;LOC OF INST UNINCREMENTED
HLT ;INST INC ON TRAP
RET2: TST STKPTR-2
BEQ .+4 ;CONDITION CODES SET ON TRAP
HLT
INC INST
INC FIRST
CMP INST,LAST
BEQ GIN1 ;SET UP NEW GROUP
JMP GIN2 ;FINISH OLD GROUP
;END OF INSTRUCTION GROUP

;THE FOLOWING TESTS ARE WRITTEN TO CHECK MULTIPLE TRAP CONDITIONS
;TO TEST THAT TRAPS ARE PROCESSED PROPERLY.
015606 010701
015610 012737 000012 000010
015616 012706 000500
015622 012767 015666 162164
015630 012767 015700 162146
015636 012737 015673 000030
015644 005037 000032
015650 005000
015652 012746 000020
015656 012746 015664
015662 000006
015664 104000
015666 000000
015670 000431
015672 000240
015674 000000
015676 000426
015700 012767 015714 162562
015706 000006
015710 000000
015712 000420
015714 012767 015734 162552
015722 012767 015744 162064
015730 000006
SINS1: SCOPE ;SCOPE STORES PC IN R1
MOV #RESVEC+2,#RESVEC
MOV #STKPTR,%6 ;SET UP STACK POINTER
MOV #SINSD,#BITVEC ;LOAD 'T' BIT VECTOR
MOV #SINSE,4 ;LOAD ERROR VECTOR
MOV #SINSF+1,#EMTVEC ;LOAD EMT VECTOR (ODD)
CLR #EMTVEC+2
CLR %0 ;PRE SET R0
MOV #20,-(6) ;SET UP
MOV #SINSDD,-(6) ;TO SET 'T' BIT
RTT ;SET 'T' BIT
SINSDD: EMT ;DO EMT PICK UP ODD PC
SINSD: HLT ;ERROR! 'T' TRAP OCCURRED BEFORE ERROR
BR SINSI ;GO TO SCOPE ;SCOPE STORES PC IN R1
SINSF: NOP ;THE EMT TRIES TO COME HERE
HLT ;ERROR! NO ERROR TRAP ON ODD EMT VECTOR
BR SINSI ;GO TO SCOPE ;SCOPE STORES PC IN R1
SINSE: MOV #SINSG,STKPTR-10 ;CORRECT BAD EMT VECTOR ON THE STACK
RTT ;GO TO SINSG (SERVICE EMT)
HLT ;DIDN'T GO
BR SINSI ;GO TO SCOPE ;SCOPE STORES PC IN R1
SINSG: MOV #SINSH,STKPTR-4 ;RESTORE RETURN FROM EMT (ON STACK)
MOV #SINSJ,#BITVEC ;CHANGE 'T' BIT VECTOR
RTT ;GO TO SINSH

```

015732	000000				HLT				
015734	012700	000001			SINSH: MOV	#1,%0			:LOAD INDICATOR
015740	000000				HLT				:ERROR! SHOULD HAVE 'T' TRAPPED
015742	000404				BR	SINSI			:GO TO SCOPE ;SCOPE STORES PC IN R1
015744	022700	000001			SINSJ: CMP	#1,%0			:WAS INST. AT SINSH EXECUTED?
015750	001401				BEQ	SINSI			
015752	000000				HLT				:ERROR! INST AT SINSH WAS NOT EXECUTED
015754	010701				SINSI: SCOPE				:SCOPE STORES PC IN R1
015756	005267	163016			END: INC	ICNT			
015762	022767	000100	163010		CMP	#100,ICNT			
015770	001402				BEQ	DONE			
015772	000167	163010			JMP	BEGIN			
015776	012737	000007	177566		DONE: MOV	#7,a#177566			
016004	105737	177564			2\$: TSTB	a#177564			
016010	100375				BPL	2\$			
016012	012737	000000	177566		1\$: MOV	#0,a#177566			
016020	105737	177564			TSTB	a#177564			
016024	100375				BPL	1\$			
016026	013702	000042			MOV	a#42,%2			:GET DETAPE MONITOR RETURN ADDRESS
016032	001405				BEQ	DONE1			:DO NOT RETURN TO MON IF (42)=0
016034	000005				RESET				
016036	004712				LOGICAL: JSR	7,(2)			:GO TO MONITOR
016040	000240				NOP				:ACT11
016042	000240				NOP				:OVERLAY
016044	000240				NOP				:AREA
016046	000167	162730			DONE1: JMP	START			:RESTART TEST
016052	000007				TABLE: 7				:START OF RESVD INTRUCTION TABLE
016054	000077				77				
016056	000210				210				:RTS,RT1,JMP
016060	000227				227				
016062	007000				7000				
016064	007777				7777				
016066	075000				75000				
016070	076777				76777				

016072 106400  
016074 106477  
016076 106700  
016100 107777  
016102 016102  
016104 000000  
016106 000000  
016110 000000  
016112 000000  
016114 000000  
016116 000000  
016122  
000001

106400  
106477  
106700  
107777  
FINISH:  
INST: HALT  
HALT  
HALT  
HALT  
HALT  
TEMP: 0  
.+.2  
.END

:END FLAG  
:WILL CONTAIN RESERVED INST  
:SHOULD TRAP TO LOC 10  
:LOC 10 SHOULD SEND YOU TO  
:RET

BEGIN	001006	452#	2801															
BPTA	007260	1642	1643*	1645#	1650													
BPTAA	007264	1646#	1676															
BPTB	007266	1640	1647#															
BPTC	007342	1638	1657	1663#														
BPTD	007376	1667	1673#															
BPTE	007452	1668	1683	1689#														
BPTX	007472	1653	1660	1679	1686	1695#												
BPTF	007460	1646	1692#															
BPTVEC=	000014	158#	773*	774*	781*	790*	800*	809*	820*	821*	831*	832*	842*	843*				
		1172*	1173*	1182*	1193*	1207*	1220*	1221*	1390*	1401*	1565*	1566*	1638*	1639*				
		1695*	1944*	1945*	1962*	2384*	2399*	2406*										
DISPLA=	177570	172#	453*															
DONE	015776	2800	2803#															
DONE1	016046	2810	2816#															
EMTVEC=	000030	162#	691*	692*	699*	708*	717*	726*	737*	738*	747*	748*	768*	769*				
		1358*	1369*	1559*	1560*	1870*	1871*	1892*	1968*	1969*	2001*	2002*	2770*	2771*				
END	015756	2798#																
ERRVEC=	000004	156#	991*	992*	999*	1008*	1017*	1026*	1037*	1038*	1048*	1049*	1134*	1150*				
		1158*	1159*	1246*	1247*	1256*	1264*	1272*	1280*	1290*	1327*	1343*	1359*	1375*				
		1391*	1407*	1443*	1453*	1463*	1473*	1483*	1493*	1514*	1567*	1568*	1640*	1667*				
		1696*	1702*	1710*	1734*	1756*	1783*	1792*	1801*	1810*	1818*	1827*	1839*	1851*				
		1860*	1872*	1901*	1925*	1947*	1970*	2006*	2007*	2020*	2036*	2047*	2056*	2080*				
		2081*	2113*	2145*	2155*	2161*	2171*	2181*	2190*	2198*	2436*	2445*	2446*					
FINISH	016102	2738	2831#															
FIRST	=%000002	151#	2736*	2738	2740	2757*												
FOVER	006632	1521	1535#															
FP	005266	1225#																
FPA	005322	1226	1235#															
FPAA	005302	1228#	1235															
FPB	005334	1234	1238#															
FPEVEC=	000244	166#																
GIN1	015474	2736#	2759															
GIN2	015506	2740#	2760															
HAIR	011760	2088	2091#															
HAIR1	011764	2080	2093#	2102														
HAIR1B	011754	2089#	2096															
HAIR2	012116	2113	2122#	2134														
HAIR2A	012114	2119	2121#															
HAIR2B	012112	2120#	2125															
HLT	= 000000	153#	463	472	481	492	502	513	526	538	547	556	566	576				
		587	599	608	622	631	640	651	661	672	684	694	703	712				
		722	732	743	754	763	775	785	794	805	815	826	838	851				
		860	869	880	890	901	913	922	931	940	951	961	972	984				
		994	1003	1012	1022	1032	1043	1054	1064	1071	1080	1088	1095	1104				
		1117	1120	1122	1129	1137	1140	1143	1146	1152	1155	1167	1177	1188				
		1197	1201	1213	1216	1232	1237	1250	1259	1266	1275	1283	1293	1297				
		1301	1329	1330	1333	1336	1345	1346	1349	1352	1361	1362	1365	1368				
		1377	1378	1381	1384	1393	1394	1397	1400	1409	1410	1413	1416	1445				
		1448	1455	1458	1465	1468	1475	1478	1485	1488	1501	1506	1509	1511				
		1535	1571	1573	1575	1577	1580	1584	1587	1590	1593	1596	1599	1602				
		1605	1608	1611	1614	1617	1620	1623	1626	1629	1649	1652	1656	1659				
		1675	1678	1682	1685	1694	1705	1715	1719	1722	1725	1728	1738	1741				
		1744	1747	1750	1763	1766	1769	1772	1775	1778	1787	1795	1805	1814				
		1822	1832	1841	1844	1847	1856	1865	1878	1879	1882	1885	1888	1891				
		1904	1905	1908	1911	1914	1917	1929	1930	1933	1936	1939	1951	1952				









RE TG	001324	518	523#												
RE TG1	001646	592	596#												
RE TG2	002236	677	681#												
RE TG3	002550	747	751#												
RE TG4	003134	831	835#												
RE TG5	003462	906	910#												
RE TH5	003526	919	923#												
RE TJ	003544	927	929#												
RE TK	003572	936	938#												
RE TL	003630	946	949#												
RE TM	003664	955	958#												
RE TN	003730	966	970#												
RE TO	003774	977	981#												
RE TP	004050	991	995#												
RE TQ	004070	999	1001#												
RE TR	004120	1008	1010#												
RE TS	004156	1017	1020#												
RE TT	004214	1026	1029#												
RE TU	004262	1037	1041#												
RE TV	004324	1048	1051#												
RE T1	015544	2748	2750#												
RE T2	015556	2751	2753#												
R6TST	014140	2449	2461#												
R7TRX	012304	2160#													
R7TR1	012326	2161	2165#												
R7TR2	012362	2171	2175#												
R7TR2A	012356	2173#	2175												
R7TR3	012414	2181	2184#												
R7TR4	012452	2190	2195#												
SCOPE =	010701	152#	457	464	473	482	485	493	503	515	527	533	539	548	
		557	559	567	577	589	601	612	617	623	632	641	644	652	
		662	674	685	695	704	713	723	733	744	755	758	767	777	
		786	795	798	806	816	828	840	846	852	861	870	873	881	
		891	903	915	923	932	941	944	952	962	974	987	995	1004	
		1013	1023	1033	1045	1056	1065	1072	1081	1089	1096	1105	1123	1130	
		1147	1156	1168	1178	1189	1202	1217	1239	1251	1260	1267	1276	1284	
		1302	1338	1354	1370	1386	1402	1418	1449	1459	1469	1479	1489	1516	
		1536	1633	1697	1706	1729	1751	1779	1788	1796	1806	1815	1823	1833	
		1848	1857	1866	1893	1919	1941	1963	1999	2013	2029	2042	2053	2074	
		2108	2140	2156	2168	2178	2187	2199	2213	2223	2234	2247	2265	2279	
		2282	2295	2304	2317	2332	2345	2376	2411	2432	2447	2466	2473	2480	
		2488	2496	2504	2511	2519	2526	2535	2544	2554	2564	2574	2584	2594	
		2600	2605	2610	2615	2620	2625	2630	2635	2645	2653	2661	2668	2680	
		2693	2702	2717	2732	2765	2796								
SINSD	015666	2768	2777#												
SINSD0	015664	2774	2776#												
SINSE	015700	2769	2782#												
SINSF	015672	2770	2779#												
SINSG	015714	2782	2786#												
SINSH	015734	2786	2790#												
SINSI	015754	2778	2781	2785	2792	2794	2796#								
SINSJ	015744	2787	2793#												
SINSI	015606	2739	2765#												
START	001002	445	451#	2816											
STKERR	007174	1629#													
STKPTR=	000500	140#	452	467	470	476	479	486	490	495	499	506	517	534	



TTY4	013400	2335	2339#											
TTY5	013532	2353	2366#											
TTY6	013542	2361	2369#											
TTY7A	013650	2383	2393#											
TTY7B	013644	2384	2391#											
TTY7C	013674	2394	2399#											
TTY7D	013716	2399	2405#											
TTY7EX	013720	2392	2406#											
UBREAK=	177770	175#	456*											
VDC20	006500	1493	1504#											
VDC20A	006472	1500#	1504											
VDC20B	006526	1494	1507	1511#										
VDEC1	005626	1327	1331#											
VDEC10	006124	1390	1394#	1395										
VDEC11	006204	1406	1410#	1411										
VDEC12	006206	1407	1411#											
VDEC15	006256	1443	1446#											
VDEC16	006306	1453	1456#											
VDEC17	006336	1463	1466#											
VDEC18	006366	1473	1476#											
VDEC19	006416	1483	1486#											
VDEC2	005624	1326	1330#	1331										
VDEC20	006430	1492#	1502											
VDEC3	005706	1343	1347#											
VDEC4	005704	1342	1346#	1347										
VDEC5	005766	1359	1363#											
VDEC6	005764	1358	1362#	1363										
VDEC7	006046	1375	1379#											
VDEC8	006044	1374	1378#	1379										
VDEC9	006126	1391	1395#											
WAITI	013636	2388#												
WAITI	013776	2420#	2424											
.	= 016122	181#	182	184	186	188	190	192	194	196	198	200	202	204
		206	208	210	212	214	216	218	220	222	224	226	228	230
		232	234	236	238	240	242	244	246	248	250	252	254	256
		258	260	262	264	266	268	270	272	274	276	278	280	282
		284	286	288	290	292	294	296	298	300	302	304	306	308
		310	312	314	316	318	320	322	324	326	328	330	332	334
		336	338	340	342	344	346	348	350	352	354	356	358	360
		362	364	366	368	370	372	374	376	378	380	382	384	386
		388	390	392	394	396	398	400	402	404	406	408	410	412
		414	416	418	420	422	424	426	428	430	432	434	436	440#
		442#	444#	446#	448#	455	471	479	480	491	501	512	525	546
		554	555	565	575	586	598	630	638	639	650	660	671	683
		702	710	711	721	731	742	753	784	792	793	804	814	825
		837	859	867	868	879	889	900	912	930	939	950	960	971
		983	1002	1010	1011	1021	1031	1042	1053	1116	1119	1121	1139	1142
		1145	1154	1166	1175	1184	1187	1195	1199	1200	1209	1211	1214	1215
		1231	1236	1249	1274	1282	1296	1300	1332	1335	1348	1351	1364	1367
		1380	1383	1396	1399	1412	1415	1447	1457	1467	1477	1487	1505	1508
		1510	1534	1579	1583	1586	1589	1592	1595	1598	1601	1604	1607	1610
		1613	1616	1619	1622	1625	1628	1648	1651	1655	1658	1674	1677	1681
		1684	1693	1718	1721	1724	1727	1740	1743	1746	1749	1765	1768	1771
		1774	1777	1786	1794	1804	1813	1821	1831	1843	1846	1855	1864	1881
		1884	1887	1890	1907	1910	1913	1916	1932	1935	1938	1954	1957	1960
		1982	1985	1988	1991	1994	1997	2011	2024	2027	2040	2051	2068	2071



SETTBI	143#	1174	1183	1194	1208	2205	2273	2310
VTRP	1304#	1324	1340	1356	1372	1388	1404	
VTRPD	1421#	1441	1451	1461	1471	1481		

ADD	1063	2364														
BCC	2672	2730														
BCS	2684	2715														
BEQ	455	471	480	491	501	512	525	546	555	565	575	586	598	630	639	
	650	660	671	683	702	711	721	731	742	753	784	793	804	814	825	
	837	859	868	879	889	900	912	930	939	950	960	971	983	1002	1011	
	1021	1031	1042	1053	1116	1119	1139	1142	1145	1154	1187	1200	1215	1231	1236	
	1296	1300	1332	1335	1348	1351	1364	1367	1380	1383	1396	1399	1412	1415	1447	
	1457	1467	1477	1487	1505	1508	1579	1583	1586	1589	1592	1595	1598	1601	1604	
	1607	1610	1613	1616	1619	1622	1625	1628	1648	1651	1655	1658	1674	1677	1681	
	1684	1693	1718	1721	1724	1727	1740	1743	1746	1749	1765	1768	1771	1774	1777	
	1843	1846	1881	1884	1887	1890	1907	1910	1913	1916	1932	1935	1938	1954	1957	
	1960	1982	1985	1988	1991	1994	1997	2011	2024	2027	2040	2051	2068	2071	2094	
	2097	2100	2103	2106	2123	2126	2129	2132	2135	2138	2166	2176	2185	2196	2289	
	2329	2342	2371	2409	2425	2442	2464	2471	2478	2486	2494	2502	2509	2517	2524	
	2533	2542	2552	2562	2572	2582	2592	2598	2603	2608	2613	2618	2643	2651	2659	
	2666	2689	2700	2709	2739	2748	2751	2754	2759	2794	2800	2810				
BHIS	611	766														
BICB	1070															
BIS	1666	2301	2386	2683												
BISB	1265															
BIT	454	2210	2288													
BITB	1281															
BLE	2380															
BMI	2691	2713														
BNE	2211	2623	2628	2633	2676	2724										
BPL	1497	2148	2427	2678	2728	2805	2808									
BPT	775	782	791	802	811	823	834	1392	1576	1643	1950					
BR	1121	1166	1234	1249	1274	1282	1294	1502	1510	1534	1631	1646	1653	1660	1679	
	1686	1716	1786	1794	1804	1813	1821	1831	1855	1864	2291	2368	2392	2439	2778	
	2781	2785	2792													
BVC	2674	2726														
BVS	2687	2711														
CCC	2682	2707														
CLR	451	461	488	508	514	520	530	536	562	582	588	594	600	615	620	
	647	667	673	679	688	692	718	738	749	769	774	801	821	827	833	
	839	843	849	876	896	902	908	914	920	947	967	973	979	986	992	
	1018	1038	1044	1055	1061	1078	1093	1102	1110	1159	1163	1173	1221	1227	1247	
	1257	1288	1289	1499	1512	1568	1636	1639	1641	1689	1703	1704	1711	1712	1735	
	1736	1737	1759	1760	1803	1820	1829	1838	1854	1863	1871	1873	1874	1898	1899	
	1900	1923	1924	1926	1943	1945	1946	1948	1969	1972	1973	2002	2007	2008	2018	
	2021	2034	2037	2046	2048	2065	2082	2083	2084	2085	2114	2115	2150	2153	2204	
	2243	2246	2254	2261	2264	2277	2299	2309	2323	2336	2344	2356	2358	2363	2367	
	2385	2401	2423	2431	2437	2446	2483	2491	2499	2506	2514	2671	2696	2719	2743	
	2771	2772														
CLRB	1515	1762														
CMP	470	479	524	545	554	574	597	610	629	638	659	682	701	710	730	
	752	765	783	792	813	836	858	867	888	911	929	938	959	982	1001	
	1010	1030	1052	1118	1138	1141	1153	1186	1199	1214	1230	1235	1295	1298	1331	
	1334	1347	1350	1363	1366	1379	1382	1395	1398	1411	1414	1446	1456	1466	1476	
	1486	1504	1507	1578	1582	1585	1588	1591	1594	1597	1600	1603	1606	1609	1612	
	1615	1618	1621	1624	1627	1647	1650	1657	1673	1676	1683	1692	1717	1720	1723	
	1739	1742	1745	1767	1770	1773	1842	1883	1889	1909	1915	1934	1956	1981	1984	
	1987	1990	1993	2010	2023	2050	2067	2070	2093	2096	2099	2102	2122	2125	2128	
	2134	2137	2165	2175	2184	2195	2294	2328	2379	2424	2440	2441	2463	2470	2477	
	2485	2493	2501	2508	2516	2523	2532	2541	2551	2561	2571	2581	2591	2642	2650	

DCKBME.P11 CROSS REFERENCE TABLE -- PERMANENT SYMBOLS

CMPB	2658	2665	2699	2738	2747	2750	2758	2793	2799	2515	2522	2597	2602	2607	2612	
	500	1094	1115	1144	1273	2484	2492	2500	2507							
	2617	2622	2627	2632												
	1645	1830	1840	2325	2338	2355										
	2182	2369	2408													
	693	700	709	719	728	740	750	759	762	1360	1570	1677	1976	2776		
	153	183	185	187	189	191	193	195	197	199	201	203	205	207	209	
	211	213	215	217	219	221	223	225	227	229	231	233	235	237	239	
COM DEC EMT HALT	241	243	245	247	249	251	253	255	257	259	261	263	265	267	269	
	271	273	275	277	279	281	283	285	287	289	291	293	295	297	299	
	301	303	305	307	309	311	313	315	317	319	321	323	325	327	329	
	331	333	335	337	339	341	343	345	347	349	351	353	355	357	359	
	361	363	365	367	369	371	373	375	377	379	381	383	385	387	389	
	391	393	395	397	399	401	403	405	407	409	411	413	415	417	419	
	421	423	425	427	429	431	433	435	437	2444	2832	2833	2834	2835	2836	
	609	764	1292	2172	2362	2389	2756	2757	2798							
	621	628	637	648	657	669	680	680	1344	1574	1928	2259				
	JMP	445	850	857	866	877	886	898	909	1632	2449	2744	2760	2801	2816	
	JSR	921	928	937	948	957	969	980	2088	2119	2812					
	INC IOT MOV	1228														
452		453	460	467	468	476	477	486	487	490	495	496	499	506	507	
511		517	518	519	523	529	534	535	542	543	551	552	560	561	564	
569		570	571	573	580	581	583	585	591	592	593	596	604	605	606	
614		618	619	626	627	635	636	645	646	649	654	655	656	658	665	
666	668	670	676	677	678	681	687	690	691	698	699	707	708	716		
717	720	725	726	727	729	736	737	739	741	746	747	748	751	759		
760	761	768	772	773	780	781	789	790	799	800	803	808	809	810		
812	819	820	822	824	830	831	832	835	842	847	848	855	856	864		
865	874	875	878	883	884	885	887	894	895	897	899	905	906	907		
910	918	919	926	927	935	936	945	946	949	954	955	956	958	965		
966	968	970	976	977	978	981	985	990	991	998	999	1007	1008	1016		
1017	1020	1025	1026	1027	1029	1036	1037	1039	1041	1047	1048	1049	1051	1059		
1060	1062	1067	1068	1069	1075	1076	1077	1079	1084	1085	1086	1091	1092	1099		
1100	1101	1108	1109	1111	1112	1113	1114	1126	1127	1133	1134	1136	1149	1150		
1151	1158	1162	1164	1165	1171	1172	1174	1175	1181	1182	1183	1184	1192	1193		
1194	1195	1206	1207	1208	1209	1211	1220	1225	1226	1238	1245	1246	1255	1256		
1263	1264	1270	1271	1272	1279	1280	1287	1290	1291	1325	1326	1327	1337	1341		
1342	1343	1353	1357	1358	1359	1369	1373	1374	1375	1385	1389	1390	1391	1401		
1405	1406	1407	1417	1442	1443	1452	1453	1462	1463	1472	1473	1482	1483	1492		
1493	1494	1498	1513	1514	1521	1522	1523	1524	1525	1526	1527	1528	1529	1530		
1531	1532	1558	1559	1560	1561	1562	1563	1564	1565	1566	1567	1569	1581	1637		
1638	1640	1642	1643	1663	1665	1667	1668	1695	1696	1701	1702	1709	1710	1713		
1714	1733	1734	1755	1756	1757	1758	1761	1782	1783	1784	1785	1791	1792	1793		
1800	1801	1802	1809	1810	1811	1812	1817	1818	1819	1826	1827	1828	1837	1839		
1851	1852	1853	1860	1861	1862	1869	1870	1872	1875	1876	1892	1895	1896	1897		
1901	1902	1918	1921	1922	1925	1927	1940	1944	1947	1949	1962	1967	1968	1970		
1971	1974	1975	2001	2005	2006	2017	2019	2020	2033	2035	2036	2045	2047	2056		
2057	2058	2059	2060	2061	2073	2079	2080	2081	2086	2087	2112	2113	2116	2117		
2118	2143	2144	2145	2146	2149	2154	2155	2160	2161	2162	2170	2171	2180	2181		
2189	2190	2198	2202	2203	2205	2206	2216	2217	2218	2219	2226	2227	2228	2229		
2233	2237	2238	2239	2240	2241	2242	2250	2251	2252	2253	2255	2256	2257	2262		
2263	2268	2269	2270	2271	2272	2273	2274	2278	2283	2284	2285	2286	2298	2300		
2303	2307	2308	2310	2311	2316	2321	2322	2324	2326	2334	2335	2337	2339	2351		
2352	2353	2354	2357	2361	2374	2375	2382	2383	2384	2393	2394	2395	2399	2402		
2406	2407	2414	2416	2417	2418	2430	2435	2436	2445	2461	2468	2475	2482	2490		
2498	2505	2513	2521	2528	2529	2530	2537	2538	2539	2546	2547	2548	2549	2556		



DCKBME.P11 CROSS REFERENCE TABLE -- PERMANENT SYMBOLS

	2557	2558	2559	2566	2567	2568	2569	2576	2577	2578	2579	2586	2587	2588	2589
	2639	2640	2647	2648	2655	2656	2663	2664	2695	2697	2704	2705	2706	2720	2721
	2735	2736	2737	2740	2741	2742	2766	2767	2768	2769	2770	2773	2774	2782	2786
	2787	2790	2803	2806	2809										
MOVB	456	497	509	1323	2462	2469	2476	2531	2540	2550	2560	2570	2580	2590	2641
	2649	2657													
NOP	1258	1978	1980	2090	2092	2208	2231	2405	2779	2813	2814	2815			
RESET	2287	2302	2313	2314	2320	2331	2350	2373	2811						
ROL	2192														
RTI	1176	1185	1196	1661	1687	1690	2220	2365							
RTT	1210	1669	2062	2207	2230	2275	2312	2396	2403	2658	2708	2723	2775	2783	2789
SCC	1135	1644	2670	2722											
SEC	2191														
SPL	1495	1500	2349	2381	2415	2419									
STFPS	1229														
SUB	1664														
SWAB	1128														
SXT	1103														
TRAP	537	544	553	563	572	584	595	604	607	1376	1572	1903	2244	2258	
TST	993	1000	1009	1019	1028	1040	1050	1248	1533	1654	1680	1726	1748	1764	1776
	1845	1880	1886	1906	1912	1931	1937	1953	1959	1996	2026	2039	2105	2131	2341
	2370	2438	2443	2753											
TSTB	1496	2147	2426	2804	2807										
WAIT	2388	2420													
XOR	1087														
.ABS	127														
.END	2839														
.LIST	125														
.MACR	143	1304	1421												
.NLIST	126	438													
.REM	1														
.REPT	182														
.TITLE	124														
.WORD	2327	2340													

ERRORS DETECTED: 0  
 DEFAULT GLOBALS GENERATED: 0

\*, DCKBME.SEQ/CRF/SOL=DCKBME.DOC, DCKBME.P11/DS:ERFZ  
 RUN-TIME: 7 16 3 SECONDS  
 RUN-TIME RATIO: 122/28=4.2  
 CORE USED: 9K (17 PAGES)

