

# LSI-11

4K SYSTEM EXERCISER  
MD-11-DVKAH-A

EP-DVKAH-A-DL-A

OCT 1976

COPYRIGHT ©1976

**digital**

FICHE 1 OF 1

Made in U.S.A.

This section contains a grid of 100 small tables, arranged in 10 rows and 10 columns. Each table represents a different component or function of the LSI-11 system. The tables contain various types of data, including:

- Pin configurations and electrical characteristics.
- Timing diagrams and waveforms.
- Logic diagrams and truth tables.
- Test procedures and results.
- Component specifications and part numbers.

The text within the tables is small and dense, typical of technical documentation. The overall layout is highly organized and systematic, providing a comprehensive overview of the system's internal components and their interactions.

LSI-11

1-10-76

.REPT 0

IDENTIFICATION

PRODUCT CODE: MAINDEC-11-DVKAH-A-D  
PRODUCT NAME: LSI-11 4K SYSTEM EXERCISER  
DATE : MARCH 21, 1976  
MAINTAINER: DIAGNOSTIC GROUP  
AUTHOR: FRED STRAIGHT

COPYRIGHT (C) 1976 DIGITAL EQUIPMENT CORPORATION,  
MAYNARD, MASS.

THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DEC.

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.

CONTENTS

- 1.0 ABSTRACT
- 2.0 EQUIPMENT
  - 2.1 PROGRAM STORAGE = 0000-17476
- 3.0 START/RESTART ADDRESS = 200
  - 3.1 SOFTWARE SWITCH SETTINGS
- 4.0 OPERATOR ACTION REQUIRED
  - 4.1 CONTROL-C INTERRUPT OPTION
- 5.0 ERROR PRINTOUT FORMAT
  - 5.1 ERROR HALT LOCATIONS
- 6.0 EXECUTION TIME TABLE
  - 6.1 STACK POINTER
  - 6.2 PASS COUNT
  - 6.3 POWER FAIL
- 7.0 PASS PRINTOUT FORMAT
- 8.0 UTILITY ROUTINES
- 9.0 PROGRAM DESCRIPTION
- 10.0 MANUFACTURING NOTES
  - 10.1 ACT11 & RXDP OPERATION

11.01 ABSTRACT

THIS IS AN LSI-11 4K SYSTEMS EXERCISER. IT IS A TEST OF THE PROCESSORS ABILITY TO OPERATE PERIPHERALS IN INTERRUPT MODE. IT IS NOT A COMPLETE TEST OF THE PERIPHERALS THEMSELVES.

THE TEST OCCUPIES LESS THAN 4K OF MEMORY BUT DOES RUN A MEMORY ADDRESS TEST OF ALL AVAILABLE MEMORY ABOVE 4K.

A PROCESSOR INSTRUCTION TEST IS RUN WHILE ALLOWING THE PERIPHERALS TO INTERRUPT AT RANDOM. IF RELOCATION IS ENABLED THE PROCESSOR INSTRUCTION TEST IS RUN IN EACH 4K MEMORY BANK.

IT WILL RUN UNDER ACT-11 OR RXDP MONITORS.  
IT IS NOT APT COMPATIBLE.

12.01 EQUIPMENT

LSI-11 WITH MINIMUM 4K OF MEMORY AND CONSOLE OUTPUT DEVICE.

OPTIONAL:

- A. UP TO 28K OF MEMORY
- B. TELETYPE ASR33 LOW SPEED READER (REQUIRES TEST TAPE)
- B. DRV11-PARALLEL LINE UNIT (REQUIRES TEST CABLE BC08R)
- C. LINE CLOCK
- D. LINE PRINTER
- G. RXV11-FLOPPY DISK SYSTEM  
(REQUIRES A SCRATCH DISKETTE FOR EACH DRIVE TESTED)

12.11 PROGRAM STORAGE = 0000-17476

13.01 START/RESTART ADDRESS = 200

13.11 SWITCH SETTINGS

SOFTWARE SWITCH REGISTER = LOCATION 176  
LOCATION 176 = 114177 WHEN LOADED.

"STATIC" SWITCH SETTINGS CAN ONLY BE MODIFIED IF THE  
TEST IS TO BE RESTARTED AT 200.

"DYNAMIC" SWITCH SETTINGS CAN BE MODIFIED DURING A  
CONTROL-C [↑C] HALT AND THE TEST CONTINUED.

[DYNAMIC SWITCH SETTINGS]

BIT 15 (100000) - HALT ON ERROR  
BIT 14 (040000) - LOOP ON SUBTEST  
BIT 13 (020000) - INHIBIT ERROR PRINTOUTS  
BIT 12 (010000) - INHIBIT T BIT TRAPPING  
  
BIT 11 (004000) - INHIBIT SUB TEST ITERATION  
BIT 10 (002000) - INHIBIT PROCESSOR INSTRUCTION TEST  
BIT 9 (001000) - INHIBIT INSTRUCTION TEST RELOCATION  
BIT 8 (000400) - RESTART PROGRAM ON ERROR.  
BIT 7 (000200) - INHIBIT END OF PASS PRINTOUT

[STATIC SWITCH SETTINGS]

BIT 6 (000100) - INHIBIT ASR33 LOW SPEED READER TEST  
BIT 5 (000040) - INHIBIT LINE PRINTER TEST  
BIT 4 (000020) - INHIBIT DRV11 PARALLEL LINE UNIT TEST  
  
BIT 3 (000010) - INHIBIT EIS/FIS TEST  
BIT 2 (000004) - INHIBIT CONSOLE OUTPUT TEST  
BIT 1 (000002) - INHIBIT FLOPPY UNIT 1 TEST  
BIT 0 (000001) - INHIBIT FLOPPY UNIT 0 TEST

14.01 OPERATOR ACTION REQUIRED

A. LOAD THE PROGRAM INTO MEMORY USING STANDARD  
PROCEDURE FOR PDP-11 BINARY FORMATTED  
PROGRAMS.

B. IF I/O DEVICES SELECTED:

FLOPPY- INSURE SCRATCH DISKETTES INSTALLED

LINEPRINTER- IF 132 COLUMN PRINTER THEN CHANGE  
LOCATION LP80 [542] FROM 117 TO 203

DRV11 (PLU)- INSURE TEST CABLE (BC08R) INSTALLED

ASR33- PLACE BINARY TEST TAPE (SEE SEC. 8.0) IN  
THE LOW SPEED READER. THE TEST WILL ALLOW ANY

NUMBER OF BLANK FRAMES.

- C. SET SOFTWARE SWITCH [ LOCATION 176 ] TO DESIRED OPTIONS. IF AN OPTION IS SELECTED AND ITS ADDRESS FAILS TO ANSWER THE TEST WILL HALT AT PC = 0602. NOTE: LOC 176 = 114177 WHEN THE PROGRAM IS FIRST LOADED.
- D. START THE TEST AT 200. IF THE TEST HALTS AT PC = 602 RECHECK SWITCH OPTIONS IN LOCATION 176 AND RESTART.
- E. THE FOLLOWING PRINTOUTS WILL OCCUR:
- "DVKAH-A"  
"MEMORY= XXXXXX"  
WHERE "XXXX" IS THE HIGHEST MEMORY LOCATION FOUND BY SIZING.
- NOTE: IF RELOCATION INHIBITED OR RUNNING IN MEMORY WILL NOT BE SIZED AND "MEMORY = 17776" WILL BE PRINTED.
- F. CORRECT OPERATION FOR THE LINEPRINTER AND CONSOLE TERMINAL IS VISUAL:
1. LINEPRINTER OUTPUT IS AN INCREMENTING CHARACTER PATTERN THAT INCREMENTS ACROSS LINE BOUNDARIES SO THAT EACH SUCCESSIVE LINE IS DIFFERENT.
  2. CONSOLE OUTPUT IS AN INCREMENTING CHARACTER PATTERN THAT REPEATS EVERY LINE. IN ADDITION 15 NULLS ARE PRINTED AT THE BEGINNING OF EACH LINE.
- G. END OF PASS WILL BE INDICATED BY THE FOLLOWING PRINTOUT.

"PASS= 00001 ERROR= 00000 RXERROR= 00000 TIME= 00000"  
FOR DEFINITION OF ABOVE PRINTOUT SEE SECTION 7.0.

[4.1] CONTROL-C INTERRUPT OPTION

THE TEST CAN BE INTERRUPTED AT ANY TIME BY TYPING CONTROL-C. THE TEST WILL HALT AT PC=172.

THE SWITCH OPTIONS [LOCATION 176] CAN BE MODIFIED AND THE PROGRAM CONTINUED BY TYPING "P". NOTE: IF THE ASR 33 LOW SPEED READER IS UNDER TEST THE CONTROL-C OPTION WILL CAUSE A DATA ERROR.

[5.0] ERROR PRINTOUTS

ERROR PRINTOUT FORMAT:

"PC = 000000 PSW = 000000 RETURN = 000000"

WHERE:

PC = THE PROGRAM COUNTER WHERE ERROR FOUND.

PSW = PROCESSOR STATUS AT TIME OF ERROR

RETURN = THE BEGINNING ADDRESS OF THE INSTRUCTION  
SUBTEST BEING EXECUTED. THE "RETURN" ADDRESS CAN  
BE USED AS THE BEGINNING ADDRESS FOR A LOOP  
ON SUBTEST.

REFER TO LISTING AT FAILING LOCATION FOR DETAILS.

[5.1] ERROR HALTS

IF A HALT OCCURS WITH NO ERROR PRINTOUT, FIRST LOOK  
AT THE LISTING TO DETERMINE IF THE PC POINTS TO A  
HALT INSTRUCTION.

IF THE FAILING ADDRESS DOES NOT CONTAIN A HALT  
INSTRUCTION THE LSI-11 "M" COMMAND CAN DETERMINE  
WHAT CAUSED THE HALT. FOR REFERENCE HERE IS AN  
EXPLANATION OF THE OCTAL DIGITS PRINTED VIA THE  
LSI-11 "M" COMMAND.

NOTE: 6 CHARACTERS ARE PRINTED BUT ONLY THE  
RIGHTMOST OCTAL DIGIT IS USED.

!DIGIT!	!WHAT CAUSED HALT!
0	HALT INSTRUCTION OR BREAK KEY ON TERMINAL.
1	BUS ERROR OCCURRED WHILE GETTING INTERRUPT VECTOR. IT'S POSSIBLE THAT THE OPTION IS IN A SLOT THAT IS NOT WIRED FOR THE IACK SIGNAL.
2	BUS ERROR OCCURRED WHILE DOING REFRESH.
3	DOUBLE BUS ERROR OCCURRED. (STACK (R6) WAS NON-EXISTENT VALUE).
4	NON-EXISTENT MICRO-PC ADDRESS OCCURRED ON INTERNAL CPU BUS.

## [6.0] EXECUTION TIME TABLE

TYPICAL TEST TIMES: (IN FORM - MINUTES:SECONDS)

7:30 = 4K + ALL OPTIONS + ALL I/O DEVICES.  
 5:25 = 4K + NO TBIT + ITERATIONS + ALL I/O DEVICES  
 1:25 = 4K + NO TBIT + NO ITERATIONS + ALL I/O DEVICES.  
 0:50 = 4K + NO OPTIONS + NO I/O DEVICES.

## [6.1] STACK POINTER

THE STACK STARTS AT LOCATION "STACK", WHICH STARTS AT LOCATION 17474. IT IS NEVER RELOCATED. IF STACK PUSHDOWN OVERFLOW OCCURS IT WILL DESTROY THE MESSAGE STORAGE AREA FIRST. IF MESSAGES ARE SUDDENLY GARBLED, SUSPECT STACK PUSHDOWN OVERFLOW. THIS COULD HAPPEN IF A DEVICE'S INTERRUPT CIRCUITRY FAILED.

## [6.2] PASS COUNT

A PASS IS DEFINED AS THE INSTRUCTION TEST MAKING A PASS IN EACH SELECTED 4K MEMORY BANK. IF T BIT TRAPPING IS SELECTED (BIT12=0) THEN ANOTHER TEST PASS IN BANK 0 IS DONE WITH THE T BIT ON BEFORE LOCATION "PASS" [524] IS UPDATED.

## [6.3] POWER FAIL

THE TEST WILL RECOVER FROM A POWER FAILURE IF IT OCCURS IN CORE MEMORY. "PWR" WILL BE TYPED ON POWER UP.

## [7.0] PASS PRINTOUT FORMAT

"PASS= 00000 ERROR= 00000 RXERROR= 00000 TIME= 00000"

WHERE:

PASS = TOTAL NO. OF PASSES LOC. "PASS" [524]

ERROR = TOTAL NO. OF ERRORS. LOC. "ERROR" [526]  
 !THIS IS A RUNNING TOTAL OF ALL ERRORS. IT IS USEFUL TO GET AN ERROR COUNT WHEN ERROR PRINTOUTS ARE INHIBITED.

RXERROR = FLOPPY TOTAL SOFT ERROR COUNT. UNIT 1 AND UNIT 0. LOC. "RXSOFT" [516]. THE FLOPPY TEST IS RETRIED 10 TIMES BEFORE IT IS CONSIDERED A HARD ERROR.

WHILE THE SOFT ERROR COUNT GIVES NO DETAILED ERROR DESCRIPTION, IF IT IS NOT 0000, THE FLOPPY DIAGNOSTIC SHOULD BE RUN.



TIME = TOTAL NO. OF INTERRUPTS FROM THE LINE  
CLOCK, IN OCTAL. LOC. "TIME" [3574]

[8.0] UTILITY ROUTINES

UTILITY #1 - PRINT ERROR REGISTERS - (START LOCATION  
= 410)

THIS ROUTINE WILL PRINT THE VALUE OF ALL REGISTERS  
AT THE TIME OF THE LAST ERROR. THE LOCATIONS  
CONTAINING THE REGISTER VALUES ARE PRINTED IN THE  
FOLLOWING ORDER:

SAVR0	:R0
SAVR1	:R1
SAVR2	:R2
SAVR3	:R3
SAVR4	:R4
SAVR5	:R5
SAVSP	:R6
SAVPC	:R7
SAVPS	:PSW

UTILITY #2 - PUNCH BINARY TEST TAPE - (START  
LOCATION = 400)

THIS ROUTINE PUNCHES A TEST TAPE IN A BINARY COUNT  
PATTERN. THE TAPE CAN THEN BE USED AS AN INPUT TEST  
TAPE FOR THE ASR33 LOW SPEED READER TEST.

THE ROUTINE WILL PUNCH A BINARY PATTERN FROM 0-377  
THEN 15 LINES OF BLANK TAPE, REPEATING THIS SEQUENCE  
UNTIL THE MACHINE IS HALTED.

[9.0] PROGRAM DESCRIPTION

THIS TEST CONSISTS OF A BASIC INSTRUCTION TEST WITH  
I/O INTERRUPT ROUTINES. THE I/O INTERRUPT ROUTINES  
ARE ACTUALLY INDIVIDUAL TEST ROUTINES FOR A GIVEN  
DEVICE.

THE FOLLOWING IS A DETAILED DESCRIPTION OF THE  
PROGRAM AND THE I/O INTERRUPT SERVICE ROUTINES. THE  
DESCRIPTION IS GIVEN IN THE SAME ORDER AS THE  
PROGRAM EXISTS IN MEMORY. THE NAME OF THE ROUTINE  
IS GIVEN IN BRACKETS TO AID IN FOLLOWING THE  
LISTING.

[9.1] TRAPCATCHER [LOC 0-776]

ALL UNUSED LOCATIONS FROM 4 TO 776 ARE SETUP TO HALT IF AN ILLEGAL TRAP OCCURS. EACH POSSIBLE TRAP ADDRESS IS LOADED WITH ITS ADDRESS +2, AND ADDRESS +2 CONTAINS A HALT.

LOCATION 0000 CONTAINS A HALT INSTRUCTION TO CATCH ILLEGAL VECTOR TRAPS.

EXAMPLE:

ASSUME AN ILLEGAL INSTRUCTION TRAP OCCURRED AT LOCATION 1000. THE FOLLOWING DESCRIBES PROGRAM CONTROL AND HOW TO FIND THAT THE TRAP OCCURRED AT LOCATION 1000.

THE ILLEGAL INSTRUCTION CAUSES THE CPU TO PUSH THE CURRENT PC (1002) AND STATUS ONTO THE STACK. THEN THE NEW PC IS PICKED UP AT LOCATION 10. LOCATION 10 CONTAINS A 12 (ADDRESS +2), SO PROGRAM CONTROL GOES TO LOCATION 12.

LOCATION 12 CONTAINS A HALT, SO THE CPU HALTS AND PRINTS PC = 14. AT THIS TIME USING MICRO-ODT THE

LOCATION WHERE THE TRAP OCCURRED (1000) CAN BE FOUND.

DR6/17052       !FINDS THE STACK ADDRESS  
D17052/1000     !FINDS THE TRAPPED PC  
D17054/1000     !FINDS CPU STATUS AT TIME OF TRAP

[9.2] INITIALIZATION AND DEVICE SETUP [START]

SETUP STACK POINTER. IF FIRST TIME CLEAR PASS COUNT ETC. CHECK FOR HARDWARE SWITCH REGISTER.

SETUP CONSOLE OUTPUT TEST. SETUP ASR 33 LOW SPEED READER TEST. SETUP HIGH SPEED READER AND PUNCH TEST. SETUP RXV11 FLOPPY TEST.

SETUP DRV11 PLU TEST. SETUP EIS/FIS TEST. SETUP LINE PRINTER TEST.

SETUP RELOCATION AND RUN MEMORY ADDRESS TEST IF RELOCATION SELECTED. PRINT "MEMORY =". SETUP LOC PASSNO TO NUMBER OF INSTRUCTION TEST PASSES REQUIRED BEFORE "PASS" PRINTED. PASSNO = 2 IF T BIT TRAP OR RELOCATION TEST SELECTED ELSE = 0000.

[9.3] DEVICE INTERRUPT SERVICE ROUTINES

A. ASR 33 LOW SPEED READER INTERRUPT SERVICE/TEST [ASRINR]

THIS ROUTINE ASSUMES A TEST TAPE CONSISTING OF A BINARY COUNT PATTERN FROM 0-377 IS IN THE READER.

THE TEST WILL READ A CHARACTER PER INTERRUPT AND WILL ACCEPT ANY NUMBER OF BLANKS. THE FIRST NON ZERO BYTE MUST BE A 1 AND THEN SEQUENTIAL TO 377.

A TEST TAPE CAN BE GENERATED USING UTILITY #2 SECTION 8.0 OR CAN BE PRODUCED BY RUNNING THE CONSOLE OUTPUT TEST WITH THE PUNCH ENABLED. NOTE IF THE PUNCH IS USED THE TYPEOUTS MUST BE SUPPRESSED.

IF THE TEST IS RESTARTED THE TAPE MUST BE RESTARTED SINCE THERE IS NO RESYNCHRONIZATION.

B. CONSOLE OUTPUT INTERRUPT SERVICE/TEST [TYOUTR]

THIS ROUTINE WILL PUNCH A TAPE OR PRINTOUT A BINARY COUNT PATTERN FROM 0-377 IN INTERRUPT MODE. FIRST 15 BLANK LINES ARE OUTPUT SO THE TAPE CAN BE ALIGNED WHEN RUNNING THE LOW SPEED READER TEST.

TO CHECK THE VALIDITY OF THE DATA, THE TEST TAPE SHOULD BE USED AS AN INPUT TAPE TO THE LOW SPEED READER TEST.

C. HIGH SPEED READER INTERRUPT SERVICE/TEST [HSRINR]

THIS IS FOR MANUFACTURING TO ALLOW TESTING OF THE HIGH SPEED READER. THE TESTING IS IDENTICAL TO THE ASR 33 LOW SPEED READER. SEE STEP A. ABOVE.

D. HIGH SPEED PUNCH INTERRUPT SERVICE/TEST [HSPINR]

THIS IS FOR MANUFACTURING TO ALLOW TESTING OF THE HIGH SPEED PUNCH. THE TESTING IS IDENTICAL TO THE CONSOLE OUTPUT TEST. SEE STEP B. ABOVE.

E. DRV11 PLU INTERRUPT SERVICE/TEST [PLUB,PLUA]

THE TEST REQUIRES A TEST CABLE TO TIE CSR 1 TO REQUEST "B" AND CSR 0 TO REQUEST "A". IT ALSO TIES THE OUTPUT DATA TO THE INPUT.

REQUEST B IS ASSERTED IN DEVICE SETUP AND THE INTERRUPT SERVICE ROUTINE "PLUB" IS CALLED. PLUB COMPARES THE DATA TRANSMITTED AND RECEIVED, IT THEN ENABLES REQUEST "A". PLUB IS ONLY CALLED ONCE.

PLUA IS ENTERED WHEN REQUEST "A" CAUSES AN INTERRUPT. THE TRANSMITTED DATA (252525) IS COMPARED WITH THE RECEIVED. THE DATA PATTERN (LOC PLUDAT) IS INCREMENTED AND THE ROUTINE RETURNS TO THE PROCESSOR INSTRUCTION TEST.

REQUEST "A" IS THEN ASSERTED IN THE "SCOPE" ROUTINE TO REGENERATE INTERRUPTS. THE "SCOPE" ROUTINE IS ENTERED AFTER EACH INSTRUCTION SUBTEST.

TO INSURE THE PLU INTERRUPTED, LOCATION "CHECK" IS SET IN THE PLUA SERVICE ROUTINE. "CHECK" IS TESTED BEFORE END OF PASS AN ERROR HALT OCCURS IF THE PLU WAS SELECTED BUT FAILED TO INTERRUPT. THE MOST LIKELY CAUSE OF THIS ERROR IS THE FAILURE TO INSTALL THE TEST CABLE.

F. LINE PRINTER INTERRUPT SERVICE (LPINTR)

THIS ROUTINE OUTPUTS AN INCREMENTING BINARY COUNT PATTERN TO THE LINE PRINTER. IT INTERRUPTS FOR EVERY CHARACTER OUTPUT.

THE CHARACTER COUNT CAN BE SET FOR AN 80 COLUMN OR 132 COLUMN LINE PRINTER. SET LOCATION LP80 = 117 FOR 80 COLUMN. SET LOCATION LP80 = 203 FOR 132 COLUMN.

G. RXV11 FLOPPY INTERRUPT SERVICE/TEST (RXINT)

THE FLOPPY TESTING POSES A UNIQUE PROBLEM. IT IS NOT AN NPR DEVICE AND IN ADDITION MOST TRANSFERS TO IT ARE DONE IN FLAG MODE.

TO TEST IT IN AN INTERRUPT DRIVEN MODE REQUIRED SERVICING THE INTERRUPTS AND THEN KEEPING CONTROL. TO DO THE FLAG MODE TRANSFERS. IT ALSO REQUIRED A SERVICE ROUTINE DISPATCHER DEPENDING ON WHICH INTERRUPT OCCURRED.

THE NET RESULT IS A NUMBER OF SERVICE ROUTINES WHICH ARE TOO INVOLVED TO DISCUSS HERE. FOR A DETAILED DESCRIPTION REFER TO THE FOLLOWING ROUTINES IN THE LISTING: RXINT, RXINER, RXFRST, RXWSEC, RXRSEC, RXRD, RXWTR, RXWTDN.

H. LINE CLOCK INTERRUPT SERVICE (CLOCK)

THIS ROUTINE SIMPLY INCREMENTS LOCATION "TIME" AND RETURNS VIA RTI. THE TIME IS PRINTED IN OCTAL IN THE END OF PASS PRINTOUT.

[9.4] PROCESSOR INSTRUCTION TEST (BEGIN)

THIS IS A BASIC LSI-11 INSTRUCTION TEST THAT IS RUN WHILE THE I/O DEVICES INTERRUPT AT RANDOM.

ALL LSI-11 INSTRUCTIONS ARE TESTED IN AT LEAST ONE MODE FOR CORRECT OPERATION. THIS IS NOT INTENDED TO REPLACE THE BASIC LSI-11 INSTRUCTION TEST, AND THAT TEST SHOULD ALWAYS BE RUN.

IF RELOCATION IS ENABLED THIS SUBTEST WILL BE RUN IN EACH 4K MEMORY BANK. IT IS RELOCATED TO EACH MEMORY BANK WHEN THE TEST IS STARTED.

LOCATION "LOCATE" CONTAINS THE BEGINNING ADDRESS OF THE INSTRUCTION TEST WHEN IT IS RELOCATED.

SINCE THE TEST IS RELOCATED TO ITS SAME RELATIVE ADDRESS ANOTHER WAY IS TO ADD THE BANK BITS TO ADDRESS "BEGIN". FOR EXAMPLE IF THE INSTRUCTION TEST IS AT 3576 IN BANK 0 IT WILL RELOCATE TO 23576 IN BANK 1, 43576 IN BANK 2 ETC.

THE INSTRUCTION TEST IS IDENTICAL IN EACH BANK EXCEPT FOR LOCATION "TRPA". IF IN BANK 0 TRPA = "JMP @# BANK0" IF IN BANK 1 TRPA = "JMP @#BEGIN + 40000" ETC... UNTIL THE LAST MEMORY BANK WHERE TRPA = "JMP @# BANK0". THIS CAUSES THE END OF PASS ROUTINE TO BE ENTERED..

AN EXAMPLE OF THE INSTRUCTION TEST FLOW FOR 8K IS:

1. EXECUTE INSTRUCTION TEST IN BANK 0
2. EXECUTE THE TEST IN BANK 0  
(IF T BIT SELECTED IT WILL BE ON THIS PASS)
3. JMP TO BANK 1 AND EXECUTE THE INSTRUCTION TEST THERE.
4. PRINT END OF PASS

#### [9.5] END OF SUBTEST CONTROL [SCOPEC]

THIS ROUTINE IS ENTERED AFTER EACH INSTRUCTION SUBTEST VIA TRAP CALL "SCOPE". IT CONTROLS ITERATION AND PLU INTERRUPT RATE.

ROUTINE FLOW:

IF SR BIT 14=1 THEN SET "RETURN" TO BEGINNING OF CURRENT SUBTEST (SCOPE LOOP). IF BIT 11=0 THEN UPDATE ITERATION COUNT AND RETURN TO BEGINNING OF CURRENT SUBTEST. (ITERATION). IN EITHER CASE IF PLU UNDER TEST (BIT04) THEN SET PLU REQUEST "A" TO GENERATE A PLU INTERRUPT.

#### [9.6] END OF TEST CONTROL [BANK0]

THIS ROUTINE DETERMINES IF THE PLU AND FLOPPY HAVE MADE A PASS. AND IF SO THEN PRINTS END OF PASS STATEMENT. IT IS ENTERED AFTER THE INSTRUCTION TEST HAS MADE A PASS IN EACH 4K BANK.

[10.0] MANUFACTURING NOTES

INCLUDED IS AN OPTIONAL TEST OF THE HIGH SPEED READER AND PUNCH, WHICH MAY BE USED IN MANUFACTURING CHECKOUT.

TO ENABLE THE HIGH SPEED READER TEST, SET HSRINH [LOC 544] TO 0.

TO ENABLE THE HIGH SPEED PUNCH TEST, SET HSPINH [LOC 546] TO 0.

[10.1] ACT11 & RXDP OPERATION

RXDP  
-----

IF IN RXDP "CHAIN" MODE THEN NO AUTO-SIZING IS DONE TO PROTECT THE RXDP CHAIN MONITOR.  
SINCE THE SOFTWARE SR IS SET TO 114177 WHEN LOADED ONLY THE PROCESSOR INSTRUCTION TEST IS RUN.  
ALSO WHENEVER THE TEST IS LOADED UNDER RXDP; LOC 41 [HIGH BYTE LOC 40] IS SET = 10. THIS PROTECTS THE DISKETTE USED TO LOAD THE PROGRAM. TO TEST UNIT0 SET LOCATION 41 = 0 BEFORE STARTING.

ACT11  
-----

IF LOADED BY ACT11 THEN AUTO-SIZING IS ENABLED AND SINCE THE SOFTWARE SR=114177 THEN ONLY THE PROCESSOR INSTRUCTION TEST IS RUN.

IF LOADED BY ACT11 "DUMP" MODE, THE USER SHOULD MODIFY LOCATION 176 TO SELECT OPTIONS BEFORE STARTING THE TEST.

ALSO IF IN AUTO MODE UNDER ACT11 (42=SENDAD) THE TITLE PRINTOUT ("DVKAH") IS INHIBITED.

.ENDR

699  
698  
697  
696  
695  
694  
693  
692  
691  
700  
701  
702  
703  
704  
705  
706  
707  
708  
709  
710  
711  
712  
713  
714  
715  
716  
717  
730  
731  
732  
733  
734  
735  
736  
737  
738  
739  
740  
741  
747  
748  
749  
750  
751  
752  
753  
754  
755  
756  
761  
762  
763  
764  
765  
766

.ENABL AMA  
.TITLE MAINDEC-11-DVKAH-A LSI-11 4K SYSTEM TEST

;\*EQUATES

BIT15= 100000  
BIT14= 40000  
BIT13= 20000  
BIT12= 10000  
BIT11= 4000  
BIT10= 2000  
BIT09= 1000  
BIT08= 400  
BIT07= 200  
BIT06= 100  
BIT05= 40  
BIT04= 20  
BIT03= 10  
BIT02= 4  
BIT01= 2  
BIT00= 1

100000  
040000  
020000  
010000  
004000  
002000  
001000  
000400  
000200  
000100  
000040  
000020  
000010  
000004  
000002  
000001

.ENABLE ABS

NOP=240  
HLT=EMT ;TRAP USED FOR ERROR PRINTOUT  
TYPE=EMT+1 ;TRAP USED FOR MESSAGE PRINTOUTS  
SCOPE=TRAP ;TRAP USED SCOPE LOOP AND ITERATION OF SUB PROBLEMS  
PNTCHR=IOT ;IOT TRAP USED TO PRINT A CHARACTER  
CHECKM=BIT04+BIT01+BIT00 ;SR SETTINGS OF DEVICES CHECKED FOR PASSES

000240  
104000  
104001  
104400  
000004  
000023

CWAIT= BIT07+BIT04+BIT03  
SR=SWREG

000230  
000176

XX=0  
XXXXX=0

000000  
000000  
000000  
000000  
000004

.=0  
HALT ;TO CATCH ILLEGAL TRAPS.  
. =4

.LIST ME

000014  
000014 000016  
000016 000000  
000020  
000020 016216

. =14  
. +2  
HALT ;FALSE TRACE TRAP  
. =20

OUTCHR ;PRINT A CHAR. ROUTINE

```

767 000022 000340          340          ;LOCK OUT INTERRUPTS
768          000024          .=24
769 000024 016232          PFAIL
770 000026 000340          340
771          000030          .=30
772 000030 015540          HLTMES          ;FOR HLT/MESSAGE TRAPS
773 000032 000340          340          ;HIGHEST PRIORITY
774          000034          .=34
775 000034 016114          SCOPEC          ;SCOPE LOOP TRAP
776 000036 000340          340
777
778 000040 000000          0          ;ACT11 HOOKS
779 000042 000000          0
780          000046          .=46
791 000046 015516          $ENDAD          ;POINT ACT11 TO EOP LOC.
792          000052          .=52
793 000052 040000          .WORD 40000    ;TELL ACT11 RUNTIME IS MEMORY DEPENDENT
794          000060          .=60
795 000060 001736          ASRINR          ;SLU IN INTERRUPT VECTOR
796 000062 000340          340          ;LOCK OUT INTERRUPTS
797 000064 002062          TYOUTR          ;SLU OUT INTERRUPT VECTOR
798 000066 000000          0
799 000070 002134          HSRINR          ;HSR INTERRUPT VECTOR
800 000072 000000          0          ;ALLOW INTERRUPTS IN HSR ROUTINE
801 000074 002224          HPOUTR          ;HSP INTERRUPT VECTOR
802 000076 000000          0          ;ALLOW INTERRUPTS IN HSP ROUTINE
803          000100          .=100
804 000100 003570          CLOCK          ;CLOCK INTERRUPT VECTOR
805 000102 000340          340          ;STOP INTERRUPTS IN CLOCK ROUTINE
806
807
808
809
810
811
812
813
814
815
816
817          000176 000176          .=176
818 000176 114177          SWREG: 114177  ;SOFTWARE SWITCH REGISTER
819
820
821
822

```

```

*****
.=170
.SBTTL CONTROL-C HALT
*****

```

```

CTCHLT: HALT          ;CNTRL-C PRESSED ON SLU INPUT
RTI                   ;IF PROCEED RETURN TO TEST

```

```

*****
.SBTTL SOFTWARE SWITCH REGISTER
*****

```

```

;SOFTWARE SWITCH REGISTER
;DEFAULTS TO PROCESSOR TEST.
;HALT ON ERROR
;NO EIS/FIS
;NO OPTIONS SELECTED.

```



```

823                                     ;T BIT NOT SELECTED
824                                     ;ENABLE RELOCATION
825                                     ;INHIBIT ITERATIONS
826
827         000200                       . =200
828                                     ;*****
829                                     ;SBTTL LP INTERRUPT VECTOR AND START ADDRESS
830                                     ;*****
831
832         000200   000402               BR      .+6           ;THIS IS LP INTERRUPT VECTOR AND START ADDRESS
833         000202   000340               340           ;LP INTERRUPT PRIORITY
834         000204   000240               NOP           ;THIS IS SKIPPED ON START AT 200
835         000206   000137   000602     JMP      J#START
836                                     .NLIST   MC
837                                     .LIST    MD,ME
838
839
840
841
842
843
844         000244   000244               . =244
845         000244   000246               FISVEC: .+2           ;FIS ABORT TRAP ENTRANCE
846         000246   104000               FISLVL: HLT           ;*ERROR* FIS ABORTED
847                                     ;THE LOOP ADDRESS PRINTED TELLS WHAT FIS ROUTINE ABORTED
848
849
850         000264   000264               . =264
851         000266   000340               RXVEC:  RXINT           ;RX FLOPPY INTERRUPT VECTOR
852                                     RXLVL:  340           ;RX INTERRUPT VECTOR PRIORITY
853
854
855
856
857                                     ;*****
858                                     ;SBTTL ENTRY AT 400 FOR ASR33 TEST TAPE PUNCH ROUTINE
859                                     ;*****
860
861         000400   000400               . =400
862         000400   000405               BR      PASR           ;GO PUNCH ASR33 TEST TAPE.
863                                     ;*****
864         000402   000402               . =402
865                                     ;SBTTL LP INTERRUPT VECTOR ROUTINE DISPATCH
866         000402   000137   002424     JMP      LPINTR       ;GOTO ACTUAL LP SERVICE ROUTINE
867
868                                     ;START AT 410 TO PRINT ERROR REGISTERS
869
870         000410   000410               . =410
871         000414   000137   016762     PREG:   JMP      J#PNTABL       ;PRINT REGISTERS AT LAST ERROR.
872         000414   000137   017030     PASR:   JMP      J#ASRUTL
873
874                                     ;*****
875                                     ;SBTTL BEGIN I/O DEVICE STATUS ADDRESSES
876                                     ;*****
877
878
879
880
881         000420   167770               DRCSR:  167770           ;PLU STATUS
882         000422   167772               DROBUF: 167772           ;PLU OUTPUT BUFFER
883         000424   167774               DRIBUF: 167774           ;PLU INPUT BUFFER

```

884 000426 000300  
 885  
 886  
 887 000430 177560  
 888 000432 177562  
 889 000434 177564  
 890 000436 177566  
 891 000440 177550  
 892 000442 177552  
 893 000444 177554  
 894 000446 177556  
 895 000450 177514  
 896 000452 177516  
 897  
 898  
 899  
 900  
 901  
 902 000454 177170  
 903 000456 177172  
 904 000460 000264  
 905 000462 000000  
 906 000464 000000  
 907 000466 000001  
 908 000470 000001  
 909 000472 000000  
 910 000474 000000  
 911 000476 000000  
 912 000500 000000  
 913 000502 000000  
 914 000504 000000  
 915 000506 000000  
 916 000510 000000  
 917 000512 000000  
 918 000514 000000  
 919 000516 000000  
 920 000520 000000  
 929  
 930  
 931  
 932 000522 000000  
 933 000524 000000  
 934 000526 000000  
 935 000530 000000  
 936 000532 000000  
 937 000534 000000  
 938 000536 000000  
 939 000540 000000  
 940  
 941  
 942  
 943  
 944  
 945  
 946 000542 000117  
 947 000544 177777

DRVECA: 300  
  
 TKS: 177560  
 TKB: 177562  
 TPS: 177564  
 TPB: 177566  
 HRCR: 177550  
 HRDBR: 177552  
 HPCR: 177554  
 HPDBR: 177556  
 LPCR: 177514  
 LPDBR: 177516

;PLU INTERRUPT VECTOR "A"  
 ;VECTOR "B" ASSUMED AT DRVECA+4.

\*\*\*\*\*  
 .SBTTL RX FLOPPY DISK STATUS REGISTERS AND CONSTANTS  
 \*\*\*\*\*

RXCSR: 177170  
 RXDB: 177172  
 RXVECP: RXVEC  
 RXUND: 0  
 RXUNI: 0  
 RXSAB: 1  
 RXTAB: 1  
 RXDAT: 0  
 RXUTT: 0  
 RXSA: 0  
 RXTA: 0  
 RXLCNT: 0  
 RXHCNT: 0  
 SRXES: 0  
 SRXCSR: 0  
 SRXDB: 0  
 SRXSB: 0  
 RXSOFT: 0  
 RXRTRY: 0

;RX FLOPPY CSR REG.  
 ;RX FLOPPY DATA REG.  
 ;RX FLOPPY INTERRUPT VECTOR (LEVEL ASSUMED 340)  
 ;SELECT UNIT0 (LOW BYTE)  
 ;SELECT UNIT1 (HIGH BYTE)  
 ;BEGIN RX SECTOR TEST NO. (VARIES 1-31 BY INCR. OF 3)  
 ;BEGIN RX TRACK TEST NO. (ALWAYS ENDS AT TRACK:114)  
 ;RX FLOPPY WRITE DATA BEGIN (VARIES FROM 0-177)  
 ;CURRENT DRIVE SELECTED. (IF BIT 4=1 DRIVE 1 SELECTED)  
 ;CURRENT SECTOR ADDRESS  
 ;CURRENT TRACK ADDRESS  
 ;DELAY COUNT RX FLAG WAITS  
 ;DELAY COUNT RX FLAG WAITS (HIGH WORD)  
 ;VALUE OF RX ERROR REGISTER WHEN ERROR OCCURRED.  
 ;VALUE OF RX CSR WHEN ERROR OCCURRED.  
 ;VALUE OF RXDB WHEN ERROR OCCURRED  
 ;VALUE OF RX EXTENDED ERROR STATUS WHEN ERROR.  
 ;TOTAL RX SOFT ERRORS(CRC,PARITY,SEEK)  
 ;RX RETRY COUNT. (IF >:11. THEN HALT)

LOCATE: 0  
 PASS: 0  
 ERROR: 0  
 CHECK: 0  
 RETURN: 0  
 PLUDAT: 0  
 OLDRS: 0  
 CHAIN: 0

;ADDRESS OF "BEGIN" EVEN WHEN RELOCATED  
 ;HOLDS PASS COUNT  
 ;HOLDS ERROR COUNT  
 ;BITS SET AS EACH DEVICE INTERRUPTS.  
 ;LOOP ADDRESS  
 ;PLU COMPARE DATA  
 ;SAVES "OLDRS" FOR MARK TTTEST  
 ;SET IF IN RXDP CHAIN MODE

\*\*\*\*\*  
 .SBTTL LOCATIONS MODIFIED BY OPERATOR  
 \*\*\*\*\*

LP80: 117  
 HSRINH: -1

;CHANGE FROM 117 TO 203 IF 132 COLUMN PRINTER.  
 ;IF NOT = 0 THEN INHIBIT HSR TESTING

```

948 000546 177777 HSPINH: -1 ;IF NOT = 0 THEN INHIBIT HSP TESTING
949
950 ;*****
951 .SBTTL LOCATIONS PRINTED VIA START AT 130
952 ;*****
953 000550 EFIRST: ;DEFINES FIRST LOCATION PRINTED AT ST 130
954 000550 000000 SAVR0: 0 ;R0
955 000552 000000 SAVR1: 00 ;R1
956 000554 000000 SAVR2: 00 ;R2
957 000556 000000 SAVR3: 00 ;R3
958 000560 000000 SAVR4: 00 ;R4
959 000562 000000 SAVR5: 00 ;R5
960 000564 000000 SAVSP: 00 ;SP
961 000566 000000 SAVPC: 00 ;PC
962 000570 000000 SAVPS: 0 ;CONDITION CODES.
963 000572 ELAST: ;ENTRY ABOVE IS LAST PRINTED IN PNTABL
964
965 000572 000000 MEMORY: 0 ;MAXIMUM MEMORY FOUND BY SIZING ROUTINE
966 000574 000000 PASSN1: 0 ;HOLDS RUNNING PASSNO COUNT.
967 000576 000000 PASSNO: 0 ;NO. OF PASSES OF INST. TEST BEFORE PASS UPDATED.
968
969
970 .SBTTL DEVICE SELECTED CAUSED TRAP TO LOCATION 4
971
972 000600 000000 NODEVIC: HALT ;DEVICE SELECTED CAUSED BUS ERROR TRAP
973
974
975
976
977
978
979
980
981
982

```

```

984                                     ;*****
985                                     ;SBTTL PROGRAM INITIALIZATION AND DEVICE SETUP
986                                     ;REGISTER USAGE IN DEVICE SETUP
987                                     ;R0= SCRATCH
988                                     ;R1= SCRATCH
989                                     ;R2= HOLDS SWREG VALUE FOR DEVICE SETUP.
990                                     ;R3= 100 ;CONSTANT FOR INTERRUPT ENABLES
991                                     ;R4= 101 ;CONSTANT FOR INTERRUPT ENABLE AND GO.
992                                     ;*****
993
994
995 000602 012706 017474 000532 START: MOV #STACK,SP ;SETUP STACK POINTER
996 000606 012737 000602 000532 MOV #START,RETURN ;IN CASE ERROR TYPED OUT BEFORE BEGIN
997 000614 005037 000524 CLR PASS ;INIT PASS COUNTER
998 000620 005037 000526 CLR ERROR ;INIT ERROR COUNTER
999 000624 005037 000530 CLR CHECK ;INIT DEVICE INTERRUPT CHECKER
1000 000630 005037 000516 CLR RXSOFT ;INIT RX FLOPPY SOFT ERROR COUNT
1001 ;SETUP LOC "CHAIN" FOR RXDP CHAIN MODE OPERATION
1002 000634 005037 000540 CLR CHAIN
1003 000640 105737 000042 TSTB @#42 ;POSSIBLE CHAIN MODE?
1004 000644 001406 BEQ 1$ ;BRANCH IF NO
1005 000646 023727 000042 015516 CMP @#42,#SENDAD ;IS IT CHAIN MODE?
1006 000654 001404 BEQ ESTART ;BRANCH IF NO (MUST BE ACT11 AUTOMODE)
1007 000656 005237 000540 INC @#CHAIN ;SET "CHAIN" MODE OPERATION FLAG
1008 000662 104001 017210 1$: TYPE ,MREV ;PRINT REV
1009
1010 ESTART: CLR ICOUNT ;INIT ITERATION COUNTER.
1011 000672 012706 017474 MOV #STACK,SP ;SET UP STACK
1012 000676 005037 015532 CLR TRPB ;INIT T BIT PASS FLAG
1013 000702 005037 000574 CLR PASSN1 ;INIT RUNNING PASS COUNT
1014 000706 005037 000576 CLR PASSNO ;INIT NO. OF PASSES BEFORE PASS COUNT PRINTED
1015 000712 005037 016214 CLR SCOPEF
1016
1017
1018
1020 000716 106427 000200 MTPS #200 ;LOCK OUT INTERRUPTS
1022
1027
1028                                     ;*****
1029                                     ;SBTTL CHECK FOR HARDWARE SWITCH REGISTER
1030                                     ;*****
1031 000722 012737 000736 000004 MOV #1$,@#4 ;SETUP TIMEOUT VECTOR
1032 000730 005777 014200 TST @SWR ;TRY TO REFERENCE HARDWARE SR.
1033 000734 000403 BR 2$ ;BRANCH IF HARDWARE SR. PRESENT (I.E. NO TRAP OCC.)
1034 000736 012737 000176 015134 1$: MOV #SWREG,SWR ;POINT TO SOFTWARE SWITCH REGISTER
1035 000744 012737 000600 000004 2$: MOV #NODEVIC,4 ;NON EXISTENT DEVICE TRAP
1036 000752 012737 000340 000006 MOV #340,5 ;DON'T ALLOW INTERRUPT
1037 000760 012706 017474 MOV #STACK,SP ;RESTORE STACK POINTER.
1038 000764 017702 014144 MOV @SWR,R2 ;SAVE SWITCHES
1039 000770 012703 000100 MOV #100,R3 ;INTERRUPT ENABLE
1040 000774 012704 000101 MOV #101,R4 ;INTERRUPT ENABLE AND GO
1041
1042
1043 001000 050377 177430 START2: BIS R3,@TPS
1044 001004 000005 RESET
1045 001006 030377 177422 BIT R3,@TPS ;INTERRUPT ENABLE

```

```

1046 001012 001401          BEQ      .+4
1047 001014 104000          HLT
1048
1049
1050          ;DOES "RESET" ON THE BUS LAST TOO LONG
1051 001016 012706 017474      MOV      #STACK,SP      ;SET UP STACK
1052 001022 000005          RESET
1053 001024 050377 177404      BIS      R3,@TPS        ;SET INTERRUPT ENABLE
1054 001030 030377 177400      BIT      R3,@TPS        ;IS IT SET
1055 001034 001001          BNE      .+4            ;BRANCH IF YES
1056 001036 104000          HLT                    ;*ERROR* RESET IS ON BUS TOO LONG
1057
1058          ;SETUP CONSOLE OUTPUT TEST
1059
1060 001040 005037 002130      ASKCON: CLR      TPBDAT      ;INIT CONSOLE OUTPUT DATA
1061 001044 012737 000017 002132  MOV      #15,TPBNUL      ;INIT 15 BLANK LINES OUTPUT
1062 001052 032702 000004      BIT      #BIT02,R2      ;CONSOLE OUTPUT TEST WANTED?
1063 001056 001402          BEQ      ASKASR          ;YES LEAVE INTERRUPT ON
1064 001060 040377 177350      BIC      R3,@TPS        ;CLEAR CONSOLE OUTPUT INTERUPT ENABLE
1065
1066
1067
1068
1069
1070
1071
1072
1073

```

```

1075 ;SETUP ASR 33 LOW SPEED READER TEST
1076
1077 001064 012737 000001 002206 ASKASR: MOV #1,HSRDAT ;INIT BASE DATA FOR HSR TEST
1078 001072 005037 002300 CLR HSPDAT ;INIT BASE DATA FOR HSP TEST
1079 001076 005037 002304 CLR DELAY ;FOR READER STALL - HSR -
1080 001102 005037 002060 CLR KBBDAT ;INIT BASE DATA FOR SLUU SERVICE ROUTINE
1081 001106 050377 177316 BIS R3,ATKS ;SET SLU INIT ENABLE
1082 001112 030227 000100 BIT R2,#BIT06 ;SLU LOW SPEED READER INPUT TEST WANTED?
1083 001116 001004 BNE ASKHSP ;BRANCH IF NO
1084 001120 005237 002060 INC KBBDAT ;SETUP BASE DATA FOR SLU TEST
1085 001124 050477 177300 BIS R4,ATKS ;AND SET READER ENABLE
1086 ;SETUP HSP/HSR TESTING
1087
1088 001130 005737 000546 ASKHSP: TST HSPINH ;HSP TEST WANTED?
1089 001134 001006 BNE ASKHSR ;BRANCH IF NO
1090 001136 005777 177302 TST JHPCSR ;IS HSP OUT OF TAPE?
1091 001142 100001 BPL 1$ ;BRANCH IF NO
1092 001144 104000 HLT ;HSP SELECTED BUT OUT OF TAPE
1093
1094 001146 050377 177272 1$: BIS R3,JHPCSR ;HSP
1095 001152 005737 000544 ASKHSR: TST HSRINH ;HSR TEST WANTED?
1096 001156 001010 BNE SETLK ;BRANCH IF NO
1097 001160 005777 177254 TST JHRCR ;IS THE TEST PATTERN IN HSR?
1098 001164 100001 BPL 1$ ;BRANCH IF YES
1099 001166 104000 HLT ;HSR SELECTED BUT TAPE NOT IN READER.
1100
1101 001170 010337 002304 1$: MOV R3,DELAY ;FOR STALL HSR
1102 001174 050477 177240 BIS R4,JHRCR ;HSR
1103 001200 005037 003576 SETLK: CLR TIME ;INIT LINE CLOCK TIMER
1104
1105 ;SETUP RX FLOPPY TESTING
1106
1107
1108 001204 010200 ASKRX: MOV R2,RO ;GET SR SETTINGS
1109 001206 005100 COM RO ;MAKE RX INHIBITS INTO ENABLES FOR CHECK
1110 001210 042700 177774 BIC #1C<BIT01+BIT00>,RO ;MASK ALL BUT RX FLOPPY BITS
1111 001214 001507 BEQ ASKPLU ;BRANCH IF RX FLOPPY NOT WANTED.
1112
1113 001216 005037 000516 SETRX: CLR RXSOFT ;INIT RXV11 ERROR REGISTER
1114 001222 005037 000472 CLR RXDAT ;INIT RX DATA REGISTER
1115 001226 005037 000462 CLR RXUN0 ;INIT RX UNIT 0 SELECT FLAG
1116 001232 005037 000464 CLR RXUN1 ;INIT RX UNIT 1 SELECT FLAG
1117 001236 030227 000001 BIT R2,#BIT00 ;UNIT 0 WANTED?
1118 001242 001002 BNE 1$ ;BRANCH IF NO
1119 001244 005237 000462 INC RXUN0 ;SET UNIT 0 SELECT FLAG
1120 001250 030227 000002 1$: BIT R2,#BIT01 ;UNIT 1 SELECTED?
1121 001254 001002 BNE 2$ ;BRANCH IF NO
1122 001256 005237 000464 INC RXUN1 ;SET UNIT 1 SELECT FLAG
1123 001262 013737 000470 000500 2$: MOV RXTAB,RXTA ;SETUP TRACK BEGIN
1124 001270 013737 000466 000476 MOV RXSAB,RXSA ;SETUP SECTOR BEGIN
1125 001276 012737 002742 002644 MOV #RXFRST,RXCON ;RXFRST IS FIRST INTERRUPT SERVICE ROUTINE
1126 001304 013700 000460 MOV RXVECP,RO ;SET RO POINT TO RX INTERRUPT VECTOR
1127 001310 012720 002606 MOV #RXINT,(RO)+ ;SETUP INTERRUPT VECTOR ROUTINE
1128 001314 012710 000340 MOV #340,(RO) ;SETUP VECTOR PRIORITY LEVEL
1129 001320 105737 000462 TSTB RXUN0 ;USER WANT UNIT 0?
1130 001324 001422 BEQ 3$ ;BRANCH IF NO

```

1131	001326	122737	000010	000041		CMPB	#10, @#41	; LOADED BY ACT11 OR RXDP?
1132	001334	001004				BNE	5\$	; BRANCH IF NO
1133	001336	005037	000462			CLR	RXUND	; STOP RX UNIT 0 TESTING
1134	001342	104000				HLT		; *OPERATOR ERROR* UNIT 0 SELECTED FOR TEST
1135								; BUT LOADED BY RXDP.
1136								; SET LOCATION 41=0 AND RESTART WITH SCRATCH,
1137								; DISKETTE IN UNIT 0.
1138	001344	000412				BR	3\$	; AND SKIP SETTING UP UNIT 0
1139								
1140								
1141	001346	012777	000113	177100	5\$:	MOV	#113, @RXCSR	; READ STATUS UNIT 0
1142	001354	004737	003522			JSR	PC, RXWTDN	; WAIT FOR RX DONE FLAG
1143	001360	104000				HLT		; *ERROR* RX UNIT 0 SELECTED BUT DONE NOT SET
1144								
1145	001362	105777	177070			TSTB	@RXDB	; IS UNIT 0 READY?
1146	001366	100401				BMI	.+4	; BRANCH IF YES
1147	001370	104000				HLT		; *ERROR* RX- UNIT 0 SELECTED BUT NOT READY.
1148								
1149	001372	105737	000464		3\$:	TSTB	RXUN1	; USER WANT UNIT 1?
1150	001376	001412				BEQ	4\$	; BRANCH IF NO
1151	001400	012777	000133	177046		MOV	#133, @RXCSR	; READ STATUS UNIT 1
1152	001406	004737	003522			JSR	PC, RXWTDN	; WAIT FOR RX DONE FLAG
1153	001412	104000				HLT		; *ERROR* RX UNIT 0 SELECTED BUT DONE NOT SET
1154								
1155	001414	105777	177036			TSTB	@RXDB	; IS UNIT 1 READY?
1156	001420	100401				BMI	.+4	; BRANCH IF YES
1157	001422	104000				HLT		; *ERROR* RX- UNIT 1 SELECTED BUT NOT READY
1158								
1159	001424	005037	000474		4\$:	CLR	RXUTT	; SELECT UNIT 0 FOR FIRST TEST PASS.
1160	001430	005037	000520			CLR	RXRTRY	; INIT RX RETRY ERROR COUNT
1161								; RX SHOULD INTERRUPT SINCE DONE SET BY SELECT UNIT COMMA
1162								
1163								
1164								
1173								
1174								
1175								

```

1177 001434 012737 000600 000004 ASKPLU: MOV #NODEVIC, R4 ;RESTORE NON EXIST DEVICE TRAP
1178 001442 032702 000020 BIT #BIT04, R2 ;PLU TEST WANTED?
1179 001446 001021 BNE ASKEIS ;BRANCH IF NO
1180
1181 ;*****
1182 .SBTTL SETUP PLU TESTING **REQUIRES TEST CABLE**
1183 ;*****
1184
1185 001450 013700 000426 SETPLU: MOV @#DRVECA, R0 ;SETUP FLOATING PLU INTERRUPT VECTOR ADDRESS
1186 001454 012720 002352 MOV #PLUA, (R0)+ ;INIT INT. VECTOR A ROUTINE
1187 001460 005020 CLR (R0)+ ;INIT VECTOR A PRIORITY=0
1188 001462 012720 002306 MOV #PLUB, (R0)+ ;SETUP VECTOR B INTERRUPT
1189 001466 005010 CLR (R0) ;INIT VECTOR B PRIORITY=0
1190 001470 012700 125252 MOV #125252, R0 ;FIRST TEST PATTERN
1191 001474 010037 000534 MOV R0, PLUDAT ;COMPARE LOCATION
1192 001500 010077 176716 MOV R0, @DROBUF ;SEND PLU TEST PATTERN
1193 001504 012777 000042 176706 MOV #BIT05!BIT01, @DRCSR ;ENABLE VECTOR B INTERRUPT AND REQUEST B
1194
1195 ;SETUP EIS/FIS TESTING
1196
1197 001512 032702 000010 ASKEIS: BIT #BIT03, R2 ;EIS/FIS TEST WANTED?
1198 001516 001014 BNE ASKLP ;BRANCH IF NO
1199
1200
1201 001520 012700 000010 MOV #10, R0 ;SET R0=ILLEGAL INST.VECTOR
1202 001524 012720 001546 MOV #1$, (R0)+ ;SET MUL TRAP RETURN
1203 001530 012710 000340 MOV #340, (R0) ;SET MUL TRAP PRIORITY
1204 001534 070101 MUL R1, R1 ;DO A DUMMY MUL AND
1205 ;FALL THRU IF EIS/FIS MICROM PRESENT
1206 001536 005010 CLR (R0) ;RESTORE HALT INSTRUCTION
1207 001540 012740 000012 MOV #12, -(R0) ;RESTORE ILLEGAL INST. TRAP VECTOR.
1208 001544 000401 BR ASKLP ;AND CONTINUE CHECKING.
1209 001546 104000 1$: HLT ;*ERROR* USER SELECTED EIS, BUT MICROM NOT PRESENT
1210
1211 ;SETUP LP TESTING
1212
1213
1214 001550 032702 000040 ASKLP: BIT #BIT05, R2 ;LP TEST WANTED?
1215 001554 001022 BNE SETREL ;BRANCH IF NO
1216
1217 001556 012737 000137 002602 SETLP: MOV #137, SOLPAT ;INIT DATA PATTERN
1218 001564 013737 000542 002604 MOV LP80, CLINCT ;INIT COLUMN COUNT
1219 001572 012737 000040 002600 MOV #40, CURPAT ;"SPACE" IS FIRST CHARACTER
1220 001600 105777 176644 TSTB @LPCSR ;IS LP READY?
1221 001604 100401 BMI 1$ ;BRANCH IF YES
1222 001606 104000 HLT ;LP SELECTED BUT NOT READY.
1223 001610 012777 000014 176634 1$: MOV #14, @LPDDBR ;AFTER A FORMFEED IS SENT
1224 001616 050377 176626 BIS R3, @LPCSR ;LP INTERRUPT ENABLE

```



```

1226 ;*****
1227 .SBTTL CALL "RELOC" TO SETUP RELOCATION AND RUN MEMORY ADDRESS TEST.
1228 ;*****
1229
1230 001622 004737 016332 SETREL: JSR PC,RELOC ;CHECK FOR TEST RELOCATION
1231
1232 ;PRINT MAXIMUM MEMORY AVAILABLE
1233
1234 001626 104001 017124 TYPE MAXM ;TYPE "MEMORY="
1235 001632 013703 000572 MOV MEMORY,R3 ;GET HIGH MEMORY FOUND BY AUTOSIZING
1236 001636 004737 016012 JSR PC,TYP0CT ;TYPE IT.
1237 001642 104001 017146 TYPE ,CR ;TYPE CR/LF
1238
1239 ;SETUP PASSN1 FOR NO. OF INSTRUCTION PASSES REQUIRED
1240 ;BEFORE LOCATION PASS IS INCREMENTED.
1241 001646 005037 000576 CLR PASSNO ;INIT PASS COUNT HOLDER
1242 001652 032777 010000 013254 BIT #BIT12,JSWR ;T BIT TRAP TEST SELECTED?
1243 001660 001404 BEQ 4$ ;BRANCH IF YES
1244 001662 032777 001000 013244 2$: BIT #BIT09,JSWR ;RELOCATION ENABLED?
1245 001670 001003 BNE 3$ ;BRANCH IF NO
1246 001672 012737 000002 000576 4$: MOV #2,PASSNO ;REQUIRE EXTRA PASSES FOR TBIT/RELOCATE.
1247
1248
1249 001700 012737 000006 000004 3$: MOV #6,4 ;FOR USER I/O PROGRAM
1250 001706 005037 000006 CLR 6 ;PUT TRAP HALT IN 6
1251
1253 001712 106427 000000 MTPS #0 ;ALLOW INTERRUPTS
1255
1259
1260 001716 000401 BR .+4
1261 001720 000001 CPUTST: WAIT ;WAIT HERE FOR INTERRUPTS
1262 001722 037727 013206 002000 BIT JSWR,#BIT10 ;INHIBIT PROCESSOR TEST
1263 001730 001373 BNE CPUTST
1264 001732 000137 003600 JMP BEGIN

```

```

1266 ;*****
1267 .SBTTL
1268 .SBTTL ***BEGIN - DEVICE INTERRUPT SERVICE ROUTINES***
1269 .SBTTL REGISTER R2 IS RESERVED FOR RX FLOPPY SERVICE ROUTINES
1270 .SBTTL SLU LOW SPEED READER INTERRUPT SERVICE ROUTINE
1271 ;SLU RECEIVER VALUES 0 TO 377
1272 ;*****
1273
1274
1275 001736 105777 176466 ASRINR: TSTB 2TKS ;IS DONE SET
1276 001742 100401 BMI .+4
1277 001744 104000 HLT ;*ERROR* FALSE INTERRUPT OCCURRED.
1278
1279 001746 005737 002060 TST KBBDAT ;POSSIBLE CONTROL-C?
1280 001752 001021 BNE 1$ ;BRANCH IF NO
1281 001754 127727 176452 000003 CMPB 2TKB,#3 ;CONTROL-C ?
1282 001762 001404 BEQ 5$ ;YES GOTO CTCHLT
1283 001764 127727 176442 000203 CMPB 2TKB,#203 ;CONTROL-C WITH PARITY?
1284 001772 001031 BNE 4$ ;BRANCH IF NO (RTI)
1285 001774 011603 5$: MOV (SP),R3 ;GET PC AT INTERRUPT
1286 001776 104001 017146 TYPE CR ;SEND CRLF
1287 002002 004737 016012 JSR PC,TYPECT ;TYPE PC AT INTERRUPT
1288 002006 104001 017146 TYPE CR ;CR/LF
1289 002012 000137 000170 JMP 2#CTCHLT ; AND HALT.
1290 002016 105777 176410 1$: TSTB 2TKB ;TEST DATA FOR LEADER
1291 002022 001413 BEQ 3$ ;IF LEADER GO BACK
1292 002024 127737 176402 002060 CMPB 2TKB,KBBDAT ;NOT LEADER TEST FOR DATA
1293 002032 001401 BEQ 2$
1294 002034 104000 HLT ;*ERROR* DATA ERROR OR ^C TYPED DURING LSR TEST.
1295
1296 002036 105237 002060 2$: INCB KBBDAT ;INCREMENT DATA
1297 002042 001003 BNE 3$
1298 002044 012737 000001 002060 MOV #1,KBBDAT ;BASE DATA
1299 002052 005277 176352 3$: INC 2TKS ;START READER
1300 002056 000002 4$: RTI ;RETURN TO MAINLINE
1301
1302 002060 000000 KBBDAT: XX ;EXPECTED DATA
1303
1304 ;*****
1305 .SBTTL CONSOLE OUTPUT INTERRUPT SERVICE ROUTINE
1306 ;SLU TRANSMITTER PRINT VALUES 0 TO 377
1307 ;*****
1308
1309 002062 105777 176346 TYOUTR: TSTB 2TPS ;TEST FOR DONE
1310 002066 100401 BMI .+4 ;BRANCH IF FLAG FOUND
1311 002070 104000 HLT ;*ERROR* FALSE INTERRUPT OCCURRED
1312
1313 002072 105737 002130 TSTB TPBDAT ;IN BETWEEN 0-377 SEQUENCES?
1314 002076 001006 BNE 1$ ;BRANCH IF NO
1315 002100 105337 002132 DECB TPBNUL ;DONE 15 BLANKS?
1316 002104 100005 BPL TYOUT1 ;BRANCH IF NO
1317 002106 012737 000017 002132 MOV #15,TPBNUL ;INIT 15. BLANK LINE COUNT FOR NEXT TIME
1318 002114 105237 002130 1$: INCB TPBDAT ;INCREMENT DATA
1319 002120 013777 002130 176310 TYOUT1: MOV TPBDAT,2TPB ;OUTPUT TO DEVICE
1320 002126 000002 RTI ;RETURN TO MAINLINE
1321

```

```

1322 002130 000000 TPBDAT: XX ;TRANSMITTED DATA
1323 002132 000017 TPBNUL: 15. ;NO. OF PRETEST BLANK LINES SENT
1324
1325 ;*****
1326 .SBTTL HIGH SPEED READER INTERRUPT SERVICE ROUTINE
1327 ;HSR SECTION VALUES 0 TO 377
1328 ;*****
1329
1330 002134 105777 176300 HSRINR: TSTB @HRCSR ;IS DONE SET
1331 002140 100401 BMI .+4
1332 002142 104000 HLT ;*ERROR* FALSE INTERRUPT OCCURRED
1333 002144 105777 176272 TSTB @HRDBR ;TEST DATA FOR LEADER
1334
1335 002150 001413 BEQ HSRIN2 ;IF LEADER GO BACK
1336 002152 127737 176264 002206 CMPB @HRDBR,HSRDAT ;NOT LEADER TEST FOR DATA
1337 002160 001401 BEQ .+4
1338 002162 104000 HLT ;*ERROR* DATA COMPARISON ERROR
1339 002164 105237 002206 INCB HSRDAT ;INCREMENT DATA
1340 002170 001003 BNE HSRIN2
1341 002172 012737 000001 002206 HSRIN1: MOV #1,HSRDAT ;BASE DATA
1342 002200 005277 176234 HSRIN2: INC @HRCSR ;START READER
1343 002204 000002 RTI ;RETURN TO MAINLINE
1344
1345 002206 000000 HSRDAT: XX ;EXPECTED DATA
1346
1347 ;*****
1348 .SBTTL HIGH SPEED PUNCH INTERRUPT SERVICE ROUTINE
1349 ;HS PUNCH SECTION, VALUES 0 TO 377
1350 ;*****
1351
1352 ;ENABLE READER ON FIX COUNT OF PUNCH ONLY (14 TIMES)
1353 002210 005037 002300 HPOUT: CLR HSPDAT ;INITAL DATA
1354 002214 013777 002300 176224 HPOUT1: MOV HSPDAT,@HPDBR ;OUTPUT TO DEVICE
1355 002222 000002 RTI ;RETURN TO MAINLINE
1356 002224 105777 176214 HPOUTR: TSTB @HPCSR ;TEST FOR DONE
1357 002230 100401 BMI .+4 ;BRANCH IF FLAG FOUND
1358 002232 104000 HLT ;*ERROR* FALSE INTERRUPT RETURN
1359 002234 043777 002304 176176 BIC DELAY,@HRCSR ;CLEAR HSR INTERRUPT ENABLE
1360 002242 005237 002302 INC INTCNT ;COUNT INTERRUPTS
1361 002246 023727 002302 000014 CMP INTCNT,#14 ;SAVE TO TURN READER ON?
1362 002254 001005 BNE HPOUT2 ;NO-NEED MORE TIME
1363 002256 005037 002302 CLR INTCNT ;YES RESET COUNTER
1364 002262 053777 002304 176150 BIS DELAY,@HRCSR ;SET READER INT ENABLE
1365 002270 105237 002300 HPOUT2: INCB HSPDAT ;INCREMENT DATA
1366 002274 001745 BEQ HPOUT ;AT UPPER LIMIT START OVER
1367 002276 000746 BR HPOUT1 ;FINISH REST OF DATA
1368
1369 002300 000000 HSPDAT: XX
1370 002302 000000 INTCNT: 0
1371 002304 000000 DELAY: 0 ;EQUAL 100 IF HSR RUNNING
1372
1373 ;*****
1374 .SBTTL PLU INTERRUPT SERVICE ROUTINES
1375 ;PLUB IS THE B VECTOR SERVICE ROUTINE AND IS CALLED ONLY ONCE.
1376 ;*****
1377

```

```

1378 002306 005777 176106          PLUB:  TST      @DRCSR      ;REQUEST B ASSERTED?
1379 002312 100401                    BMI      .+4          ;BRANCH IF YES
1380 002314 104000                    HLT                                ;*ERROR* PLU INTERRUPT OCCURRED
1381                                     ;WITH REQUEST B OFF.
1382
1383 002316 023777 000534 176100      CMP      PLUDAT,@DRIBUF ;DATA TRANSMIT EQUAL
1384                                     ;DATA RECEIVED?
1385 002324 001401                    BEQ      .+4          ;BRANCH IF YES
1386 002326 104000                    HLT                                ;*ERROR* PLU OUTPUT BUFFER
1387                                     ;DIDN'T TRANSMIT TO INPUT BUFFER.
1388
1389 002330 005137 000534              COM      PLUDAT        ;SET NEW TEST PATTERN =252525
1390 002334 013777 000534 176060      MOV      PLUDAT,@DROBUF ;AND SEND IT TO PLU
1391 002342 012777 000101 176050      MOV      @BIT06!BIT00,@DRCSR ;CLR INTERRUPT ENB B.
1392                                     ;SET INTERRUPT ENB A AND REQUEST A.
1393
1394 002350 000002                    RTI
1395
1396                                     ;*****
1397                                     ;PLUA IS THE A VECTOR SERVICE ROUTINE AND IS ENABLED AT EACH
1398                                     ;"SCOPE" CALL.
1399                                     ;*****
1400
1401 002352 105777 176042          PLUA:  TSTB     @DRCSR      ;REQUEST A ASSERTED?
1402 002356 100401                    BMI      .+4          ;BRANCH IF YES
1403 002360 104000                    HLT                                ;*ERROR* PLU INTERRUPT OCCURRED
1404                                     ;WITH REQUEST A OFF.
1405 002362 042777 000010 176030      BIC      @BIT03,@DRCSR ;INTERRUPT A ENABLE WILL BE
1406                                     ;SET IN SCOPEG. ROUTINE
1407 002370 023777 000534 176026      CMP      PLUDAT,@DRIBUF ;DATA SENT TO PLU
1408                                     ;EQUAL TO RECEIVED?
1409 002376 001401                    BEQ      .+4          ;BRANCH IF YES
1410 002400 104000                    HLT                                ;*ERROR* PLU DATA FAILED
1411 002402 005237 000534              INC      PLUDAT        ;MAKE NEW TEST PATTERN
1412 002406 052737 000020 000530      BIS      @BIT04,CHECK  ;TELL CHECK ROUTINE PLU ALT 1'S AND 0'S PASSED
1413 002414 013777 000534 176000      MOV      PLUDAT,@DROBUF ;AND SEND TO PLU
1414 002422 000002                    RTI
1415
1416
1417
1418
1419                                     ;*****
1420                                     ;SBTTL LINE PRINTER INTERRUPT SERVICE ROUTINE
1421                                     ;LP INTERRUPT VECTOR IS 200
1422                                     ;*****
1423
1424 002424 105777 176020          LPINTR: TSTB     @LPCSR     ;TEST FOR FLAG
1425 002430 100401                    BMI      .+4
1426 002432 104000                    HLT                                ;*ERROR* FALSE INTERRUPT OCCURRED
1427                                     ;LP INTERRUPTED BUT READY WAS NOT SET
1428
1429 002434 023737 002604 000542      CMP      CLINCT,@#LP80 ;TEST FOR END OF LINE,
1430 002442 002015                    BGE      25           ;GO GENERATE CR/LF
1431 002444 005237 002604              INC      CLINCT        ;INCREMENT LINE POSITION COUNT
1432 002450 023727 002600 000137      CMP      CURPAT,#137  ;TEST FOR MAXIMUM PATTERN
1433 002456 001403                    BEQ      15           ;YES - GO TO LP3 AND RESET
1434 002460 005237 002600              INC      CURPAT        ;NO - INCREMENT TO NEXT PATTERN

```

```

1435 002464 000433 BR 4$ :GO SEND IT TO LINE PRINTER
1436 002466 012737 000040 002600 1$: MOV #40,CURPAT :RESET PATTERN AND SEND TO PRINTER
1437 002474 000427 BR 4$ :SENT TO LINE PRINTER
1439 002476 023737 002604 000542 2$: CMP CLINCT, @#LP80 :TIME FOR THE CR?
1439 002504 003006 BGT 3$ :BRANCH IF YES
1440 002506 005237 002604 INC CLINCT :SET CR FLAG VIA COLUMN COUNT
1441 002512 012777 000012 175732 MOV #12, @LPDBR :SEND LINEFEED TO LP
1442 002520 000426 BR LPEX :RETURN TO MAINLINE TEST
1443 002522 005037 002604 3$: CLR CLINCT :RESET COLUMN COUNT
1444 002526 012777 000015 175716 MOV #15, @LPDBR :SEND CR TO LP
1445 002534 023727 002602 000137 CMP SOLPAT, #137 :END OF PATTERN?
1446 002542 002410 BLT 5$ :BRANCH IF NO
1447 002544 012737 000040 002602 MOV #40, SOLPAT :INIT START OF LINE
1448 002552 000406 BR 6$ :AND EXIT

```

```

1449
1450 002554 013777 002600 175670 4$: MOV CURPAT, @LPDBR :SEND A CHARACTER TO LP.
1451 002562 000405 BR LPEX :RTI
1452 002564 005237 002602 5$: INC SOLPAT :INC. START OF CHARS
1453 002570 013737 002602 002600 6$: MOV SOLPAT, CURPAT :RESET CURRENT PATTERN
1454 002576 000002 LPEX: RTI :RETURN TO MAINLINE TEST
1455
1456 002600 000000 CURPAT: 0 :CURRENT CHARACTER BEING PRINTED
1457 002602 000000 SOLPAT: 0 :START OF LINE CHARACTER
1458 002604 000000 CLINCT: 0 :POSITION OF LINE
1460
1461
1462
1463

```

```

:*****
:SBTTL RX FLOPPY INTERRUPT SERVICE ROUTINES

```

```

: ALL RX INTERRUPTS ENTER AT RXINT FOR FALSE INTERRUPT CHECKING AND THEN
:DISPATCH TO THE CURRENT SERVICE ROUTINE AT RXCON.
: RXCON WILL CONTAIN THE FOLLOWING SERVICE ROUTINES IN SEQUENCE:
:RXFRST; FILL WRITE BUFFER.
:RXWSEC; WRITE BUFFER TO RX DISK
:RXRSEC; READ SECTOR
:RXRD; EMPTY BUFFER AND COMPARE DATA

```

```

:*****

```

```

1477 002606 017702 175642 RXINT: MOV @RXCSR, R2 :GET RX CSR INFO.
1478 002612 010237 000510 MOV R2, SRXCSR :SAVE CURRENT RXCS REGISTER
1479 002616 017737 175634 000506 MOV @RXDB, SRXES :SAVE CURRENT ERROR STATUS
1480 002624 005702 TST R2 :CHECK RX ERROR STATUS BIT
1481 002626 100407 BMI RXINERR :BRANCH IF ERROR BIT SET.
1482 002630 032702 000040 BIT #BIT05, R2 :DONE BIT SET?
1483 002634 001001 BNE .+4 :BRANCH IF YES
1484 002636 :04000 HLT :*ERROR* RX- INTERRUPT WITH DONE NOT SET

```

```

1485
1486
1487 002640 000177 000000 1$: JMP @RXCON :GOTO SERVICE ROUTINE
1488 002644 000000 RXCON: XXXXX :CONTAINS ADDRESS OF SERVICE ROUTINE

```

```

:RX RESTART RX TESTING UNLESS 10 SOFT ERRORS THEN HLT.

```

```

1489
1490
1491

```

```

1492 002646 123727 000520 000012 RXINERR:      CMPB   RXRTRY,#10.      ;HAVE 10 SOFT ERRORS OCCURRED?
1493 002654 002401          BLT     IS              ;BRANCH IF NO- GIVE ANOTHER CHANCE
1494 002656 104000          HLT                    ;*ERROR* RX TESTING FAILED AFTER 10 RETRIES.
1495                                     ;SEE FOLLOW LOCATIONS FOR LAST ERROR INFO.
1496                                     ;SRXCSR- RX STATUS REGISTER AT LAST ERROR
1497                                     ;SRXES- ERROR STATUS AT LAST ERROR
1498                                     ;NOTE; SRXES DOES NOT INCLUDE DRIVE READY STATUS
1499
1500 002660 005237 000516          1$:   INC     RXSOFT      ;UPDATE ERROR COUNT
1501 002664 105237 000520          INCB   RXRTRY         ;UPDATE RETRY COUNTER
1502 002670 012737 002742 002644      MOV    #RXFRST,RXCON ;START AT FIRST TEST ON INTERRUPT.
1503 002676 052777 040000 175550      BIS    #BIT14,SRXCSR ;RX INITIALIZE.
1504 002704 004737 003522          JSR    PC,RXWTDN     ;RX- WAIT FOR DONE FLAG
1505 002710 104000          HLT                    ;*ERROR* RX- DONE FLAG FAILED TO SET
1506
1507 002712 052777 000100 175534      BIS    #BIT06,SRXCSR ;SET RX INTERRUPT ENABLE
1508 002720 005037 000472          CLR    RXDAT         ;INIT RX DATA REGISTER
1509 002724 013737 000470 000500      MOV    RXTAB,RXTA   ;RESET BEGINNING TRACK ADDRESS
1510 002732 013737 000466 000476      MOV    RXSAB,RXSA   ;RESET BEGINNING SECTOR ADDRESS
1511 002740 000002          RTI                    ;RETRURN TO RXFRST ON NEXT RX INTERRUPT.
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522

```

```

:*****
:RXFRST- RX FLOPPY INTERRUPT SERVICE ROUTINE
:      CALLED FIRST TIME AND AFTER EACH DRIVE TESTED.
:*****

```

```

1523 002742 005737 000474      RXFRST: TST    RXUTT      ;UNIT 0 TEST TIME?
1524 002746 001405          BEQ    1$             ;BRANCH IF YES
1525 002750 005737 000464          TST    RXUN1         ;UNIT 1 ON LINE?
1526 002754 001005          BNE    2$             ;BRANCH IF YES
1527 002756 005037 000474          CLR    RXUTT         ;NO-SELECT UNIT 0 BY DEFAULT
1528 002762 005737 000462          1$:   TST    RXUND     ;UNIT 0 ON LINE?
1529 002766 001003          BNE    3$             ;BRANCH IF YES
1530 002770 012737 000020 000474 2$:   MOV    #BIT04,RXUTT ;SELECT UNIT 1 UNDER TEST.
1531
1532          ;FILL RX WRITE BUFFER
1533
1534 002776 012702 000200          3$:   MOV    #128,R2    ;SIZE OF RX BUFFER
1535 003002 012777 000101 175444      MOV    #101,SRXCSR  ;SEND RX FILL BUFFER COMMAND+ INT. ENABLE
1536 003010 004737 003500          4$:   JSR    PC,RXWTR   ;RX- WAIT TRANSFER READY FLAG
1537 003014 104000          HLT                    ;*ERROR* RX- TRANSFER READY FLAG FAILED TO SET
1538
1539 003016 113777 000472 175432      MOVB   RXDAT,SRXDB  ;LOAD RX BUFFER WITH DATA PATTERN
1540 003024 105237 000472          INCB   RXDAT         ;UPDATE WRITE DATA PATTERN
1541 003030 077211          SOB    R2,4$         ;LOOP UNTIL RX BUFFER FULL
1542 003032 012737 003042 002644      MOV    #RXWSEC,RXCON ;SET NEXT INTERRUPT ROUTINE= RXWSEC
1543 003040 000002          RTI                    ;RETURN TO RXWSEC ON NEXT RX INTERRUPT
1544
1545
1546
1547

```

```

:*****
:RXWSEC- RX INTERRUPT SERVICE ROUTINE
:      CALLED AFTER RXFRST AND ITSELF UNTIL EVERY 3RD SECTOR ON TRACKS 1

```

```

1548                                     :AND 114 ARE WRITTEN WITH INCREMENTING DATA PATTERN.
1549                                     :*****
1550
1551
1552 003042 013702 000474          RXWSEC: MOV      RXUTT,R2          ;SELECT DRIVE
1553 003046 052702 000105          BIS      #105,R2         ;SELECT WRITE SECTOR +INTERRUPT ENABLE
1554 003052 010277 175376          MOV      R2,DRXCSR       ;LOAD INTO RX COMMAND REGISTER.
1555 003056 004737 003500          JSR      PC,RXWTR        ;RX- WAIT TRANSFER READY
1556 003062 104000                  HLT                      ;*ERROR* RX- TRANSFER READY FAILED TO SET
1557
1558 003064 013777 000476 175364    MOV      RXSA,DRXDB       ;LOAD RX SECTOR ADDRESS
1559 003072 004737 003500          JSR      PC,RXWTR        ;RX- WAIT TRANSFER READY
1560 003076 104000                  HLT                      ;*ERROR* RX- TRANSFER READY FAILED TO SET
1561
1562 003100 013777 000500 175350    MOV      RXTA,DRXDB      ;LOAD RX TRACK ADDRESS AND INTERRUPT WHEN DONE.
1563
1564                                     ;UPDATE RX SECTOR AND TRACK ADDRESSES.
1565
1566 003106 012737 002742 002644    MOV      #RXFRST,RXCON   ;RETURN TO RXFRST ON NEXT INTERRUPT.
1567 003114 062737 000003 000476    ADD      #3,RXSA         ;UPDATE SECTOR
1568 003122 023727 000476 000031    CMP      RXSA,#31        ;IS THIS LAST SECTOR?
1569 003130 002425                  BLT      4$              ;BRANCH IF NO (RTI)
1570 003132 003005                  BGT      1$              ;BRANCH IF TIME TO SWITCH TRACKS
1571 003134 023737 000470 000500    CMP      RXTAB,RXTA     ;IS THIS FIRST TRACK?
1572 003142 001005                  BNE      2$              ;BRANCH IF NO (ALL WRITES ARE DONE)
1573 003144 000417                  BR       4$              ;RTI
1574
1575 003146 012737 000114 000500 1$: MOV      #114,RXTA       ;SET LAST TRACK ADDRESS
1576 003154 000410                  BR       3$              ;(SET FIRST SECTOR + RTI)
1577 003156 013737 000470 000500 2$: MOV      RXTAB,RXTA     ;SET TRACK BEGIN ADDRESS
1578 003164 005037 000472          CLR      RXDAT           ;RESET INCREMENTING RX DATA PATTERN
1579 003170 012737 003206 002644    MOV      #RXRSEC,RXCON  ;SET NEXT RX INTERRUPT ROUTINE=RXRSEC
1580 003176 013737 000466 000476 3$: MOV      RXSAB,RXSA     ;SET SECTOR BEGIN ADDRESS
1581 003204 000002                  4$: RTI                  ;RETURN TO RXWSEC OR RXRSEC ON NEXT RX INTERRUPT
1582
1583
1584                                     :*****
1585                                     ;RXRSEC- RX INTERRUPT SERVICE ROUTINE
1586                                     ;CALLED AFTER RXWSEC AND RXRD UNTIL EVERY 3RD SECTOR ON
1587                                     ;TRACKS 1 AND 114 ARE READ INTO BUFFER.
1588                                     :*****
1589
1590
1591 003206 013702 000474          RXRSEC: MOV      RXUTT,R2          ;SELECT DRIVE
1592 003212 052702 000107          BIS      #107,R2         ;SELECT READ COMMAND AND INTERRUPT ENABLE
1593 003216 010277 175232          MOV      R2,DRXCSR       ;LOAD RX COMMAND REGISTER
1594 003222 004737 003500          JSR      PC,RXWTR        ;RX- WAIT TRANSFER READY
1595 003226 104000                  HLT                      ;*ERROR* RX- TRANSFER READY FAILED TO SET
1596
1597 003230 013777 000476 175220    MOV      RXSA,DRXDB       ;LOAD SECTOR ADDRESS
1598 003236 004737 003500          JSR      PC,RXWTR        ;RX- WAIT TRANSFER READY
1599 003242 104000                  HLT                      ;*ERROR* RX-TRANSFER READY FAILED TO SET
1600
1601 003244 013777 000500 175204    MOV      RXTA,DRXDB      ;LOAD TRACK ADDRESS AND INITIATE AN INTERRUPT.
1602 003252 012737 003262 002644    MOV      #RXRD,RXCON     ;SET NEXT RX SERVICE ROUTINE= RXRD
1603 003260 000002                  RTI

```

```

1604
1605
1606
1607
1608
1609
1610
1611
1612
1613
1614
1615
1616 003252 010146          RXRD:  MOV     R1,-(SP)      ;SAVE R1 ON STACK
1617 003264 012702 000200    MOV     #128,R2          ;SIZE OF RX BUFFER.
1618 003270 012777 000103 175156  MOV     #103,RXCSR      ;LOAD RX READ BUFFER CMD. + INT. ENABLE
1619
1620
1621 003276 004737 003500    ;*BEGIN READ RX BUFFER LOOP*
1622 003302 104000          1$:   JSR     PC,RXWTR      ;RX- WAIT TRANSFER READY
1623                                     HLT                                     ;*ERROR* RX- TRANSFER READY FAILED TO SET
1624 003304 117701 175146    MOV     @RXDB,R1        ;GET RX BUFFER DATA
1625 003310 120137 000472    CMP     R1,RXDAT        ;IS DATA OK?
1626 003314 001401          BEQ     .+4             ;BRANCH IF YES
1627 003316 104000          HLT                     ;*ERROR* RX DATA BUFFER COMPARE ERROR.
1628
1629 003320 105237 000472    INCB   RXDAT           ;UPDATE COMPARE DATA
1630 003324 077214          SOB    R2,1$          ;LOOP UNTIL BUFFER EMPTY
1631
1632 003326 012601          ;*END READ RX BUFFER LOOP*
1633                                     MOV     (SP)+,R1       ;RESTORE R1
1634 003330 005037 000520    CLR    RXRTY           ;INIT RETRY COUNTER
1635                                     ;UPDATE SECTOR AND TRACK ADDRESSES
1636
1637 003334 012737 003206 002644    MOV     #RXRSEC,RXCON   ;GOTO RXRSEC ON NEXT INTERRUPT FROM RX
1638 003342 062737 000003 000476    ADD    #3,RXSA         ;UPDATE SECTOR ADDRESS
1639 003350 023727 000476 000031    CMP    RXSA,#31        ;IS NEXT SECTOR LAST?
1640 003356 002446          BLT    4$              ;BRANCH IF NO (RTI)
1641 003360 003037          BGT    3$              ;BRANCH IF TIME TO SWITCH TRACKS
1642 003362 023737 000470 000500    CMP    RXTAB,RXTA      ;IS THIS FIRST TRACK?
1643 003370 001441          BEQ    4$              ;BRANCH IF YES (RTI)
1644
1645 003372 013737 000466 000476    ;SELECT DRIVE FOR NEXT TEST PASS
1646 003400 013737 000470 000500    MOV    RXSAB,RXSA      ;RESET TO BEGIN SECTOR
1647 003406 012737 002742 002644    MOV    RXTAB,RXTA      ;RESET TO BEGIN TRACK
1648 003414 005037 000472 002644    MOV    #RXFRST,RXCON   ;SET NEXT RX SERVICE ROUTINE=RXFRST
1649 003420 005737 000474          CLR    RXDAT           ;RESET RX DATA REGISTER
1650 003424 001406          TST    RXUTT           ;JUST TESTED UNIT 0?
1651 003426 052737 000002 000530    BEQ    2$              ;BRANCH IF YES
1652 003434 005037 000474          BIS    #BIT01,CHECK    ;TELL WORLD RX UNIT 1 MADE A PASS
1653 003440 000415          CLR    RXUTT           ;TEST UNIT 0 NEXT PASS
1654 003442 052737 000040 000474 2$:   BR     4$              ;RTI
1655 003450 052737 000001 000530    BIS    #BIT05,RXUTT    ;TEST UNIT 1 NEXT PASS
1656 003456 000406          BR     4$              ;TELL WORLD RX UNIT 0 MADE A PASS
1657 003460 013737 000466 000476 3$:   MOV    RXSAB,RXSA      ;RESET SECTOR FOR LAST TRACK TEST
1658 003466 012737 000114 000500    MOV    #114,RXTA       ;SET LAST TRACK ADDRESS
1659 003474 000002          4$:   RTI                    ;RETURN TO RXRSEC OR RXFRST ON NEXT RX INTERRUPT
    
```





1722  
1723  
1724  
1725  
1726  
1727  
1728  
1729  
1730  
1731  
1732  
1733  
1734  
1735  
1736  
1737

003570 005237 003576  
003574 000002  
003576 000000

```

;*****
;SBTTL LINE CLOCK INTERRUPT SERVICE ROUTINE
;LOCATION TIME IS PRINTED IN OCTAL AT END OF PASS
;*****
CLOCK: INC TIME ;UPDATE TIMER
RTI ;RETURN TO MAINLINE TEST
TIME: 0 ;HOLDS LINE CLOCK INTERRUPT COUNT.

;*****
;SBTTL ***END - DEVICE INTERRUPT SERVICE ROUTINES***
;SBTTL
;*****

```

```

1740 ;*****
1741 ;SBTTL ***BEGIN RELOCATED INSTRUCTION TEST***
1742 ;SBTTL BACKGROUND PROCESSOR INSTRUCTION TESTS
1743 ; REGISTER R2 CANNOT BE USED IN RELOCATED TESTS (RESERVED FOR FLOPPY)
1744 ;DSABL AMA
1745 ;*****
1746
1747
1748 003600 010700 BEGIN: MOV PC,R0 ;SET SCOPE RETURN TO CURRENT BANK
1749 003602 162700 000002 SUB #2,R0 ;POINT TO BEGIN;
1750 003606 010037 000532 MOV R0,#RETURN ;AND SAVE IF SCOPE LOOPING
1751 003612 010037 000522 MOV R0,#LOCATE ;SAVE "BEGIN" ADDRESS EVEN IF RELOCATED
1752
1753
1754 003616 012737 001000 016212 MOV #1000,#ICOUNT ;ITERATION COUNT
1755
1756 ;*****
1757 ;TEST BRANCH INSTRUCTIONS
1758 ;*****
1759
1760 003624 000277 BRXX: SCC ;CC=1111
1761 003626 103003 BCC 1$ ;BRANCH IF C FAILED
1762 003630 102002 BVC 1$ ;BRANCH IF V FAILED
1763 003632 001001 BNE 1$ ;BRANCH IF Z FAILED
1764 003634 100401 BMI .+4 ;BRANCH IF N OK
1765 003636 104000 1$: HLT ;*ERROR* SCC OR BRANCH FAILED
1766
1767 003640 103401 BCS .+4 ;BRANCH IF C OK
1768 003642 104000 HLT ;*ERROR* BCS FAILED
1769 003644 102401 BVS .+4 ;BRANCH IF V OK
1770 003646 104000 HLT ;*ERROR* BVS FAILED
1771 003650 001401 BEQ .+4 ;BRANCH IF Z OK
1772 003652 104000 HLT ;*ERROR* BEQ FAILED
1773 003654 100002 BPL 2$ ;BRANCH IF N FAILED
1774 003656 101001 BHI 2$ ;BRANCH IF C OR Z FAILED
1775 003660 101401 BLOS .+4 ;BRANCH IF C OR Z OK
1776 003662 104000 2$: HLT ;*ERROR* BPL, BHI, BLOS FAILED
1777
1778 003664 000241 CLC ;CC=1110
1779 003666 103402 BCS 3$ ;BRANCH IF C FAILED
1780 003670 103401 BLO 3$ ;BRANCH IF C FAILED
1781 003672 103001 BCC .+4 ;BRANCH IF C OK
1782 003674 104000 3$: HLT ;*ERROR* CLC,BCS,BLO,BCC OR CLC FAILED
1783
1784 003676 000242 CLV ;CC=1100
1785 003700 102403 BVS 4$ ;BRANCH IF V FAILED
1786 003702 003002 BGT 4$ ;BRANCH IF BGT FUNCTION FAILED
1787 003704 002001 BGE 4$ ;BRANCH IF BGE FUNCTION FAILED
1788 003706 003401 BLE .+4 ;BRANCH IF BLE FUNCTION OK
1789 003710 104000 4$: HLT ;*ERROR* CLV,BVS,BGT,BGE OR BLE FAILED
1790
1791 003712 000244 CLZ ;CC=1000
1792 003714 100002 BPL 5$ ;BRANCH IF N FAILED
1793 003716 001401 BEQ 5$ ;BRANCH IF Z FAILED
1794 003720 002401 BLT .+4 ;BRANCH IF BLT FUNTION OK.
1795 003722 104000 5$: HLT ;*ERROR* CLZ,BPL,BEQ,BGT FAILED

```

```

1796
1797 003724 000250          CLN          ;CC=0000
1798 003726 003001          BGT          ;BRANCH IF BGT FUNCTION OK
1799 003730 104000          BREND: HLT   .+4      ;*ERROR* BGT OR CLN FAILED
1800
1801
1802          ;*****
1803          ;TEST COMPARE INSTRUCTION INDEXED
1804          ;*****
1805
1806 003732 012700 177770          MOV      #-10,RO      ;MINUS 10 TO REG 0
1807 003736 026027 015100 125252  CMP      A(0),#125252 ;(A INDEX BY MINUS 10) TO #125252
1808 003744 001401          BEQ      .+4
1809 003746 104000          HLT
1810 003750 104400          SCOPE          ;*ERROR* COMPARE WITH INDEX FAILED
1811
1812
1813
1814 003752 012700 177770          MOV      #-10,RO      ;FOR INDEX
1815 003756 022760 125252 015100  CMP      #125252,A(0) ;A INDEXED
1816 003764 001401          BEQ      .+4
1817 003766 104000          HLT          ;*ERROR* COMPARE FAILED DESTINATION INDEX
1818 003770 104400          SCOPE          ;LOOP ON SUBTEST OR SETUP LOC. RETURN
1819
1831 003772 012700 000010          MOV      #10,RO       ;INDEX
1832 003776 026027 015100 052525  CMP      A(0),#052525
1833 004004 001401          BEQ      .+4
1834 004006 104000          HLT          ;*ERROR* COMPARE FAILED
1835 004010 104400          SCOPE          ;LOOP ON SUBTEST OR SETUP LOC. RETURN
1836
1837
1838
1839 004012 012700 000010          MOV      #10,RO
1840 004016 022760 052525 015100  CMP      #052525,A(0)
1841 004024 001401          BEQ      .+4
1842 004026 104000          HLT          ;*ERROR* COMPARE FAILED
1843 004030 104400          SCOPE          ;LOOP ON SUBTEST OR SETUP LOC. RETURN
1844
1845
1846
1847 004032 012700 177770          MOV      #-10,RO
1848 004036 026060 015100 015100  CMP      A(0),A(0)
1849 004044 001401          BEQ      .+4
1850 004046 104000          HLT          ;*ERROR* COMPARE FAILED
1851 004050 104400          SCOPE          ;LOOP ON SUBTEST OR SETUP LOC. RETURN
1852
1853
1854
1855 004052 012700 000010          MOV      #+10,RO
1856 004056 026060 015100 015100  CMP      A(0),A(0)
1857 004064 001401          BEQ      .+4
1858 004066 104000          HLT          ;*ERROR* COMPARE FAILED
1859 004070 104400          SCOPE          ;LOOP ON SUBTEST OR SETUP LOC. RETURN
1860
1861
1862

```

```

1863 004072 012700 177770      MOV    #-10,RO
1864 004076 012701 000004      MOV    #+4,R1
1865 004102 026061 015100 015100  CMP    A(0),A(1)
1866 004110 001401      BEQ    .+4
1867 004112 104000      HLT
1868 004114 104400      SCOPE      ;*ERROR* COMPARE FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
1869
1870
1871
1872 004116 026160 015100 015100  CMP    A(1),A(0)
1873 004124 001401      BEQ    .+4
1874 004126 104000      HLT
1875 004130 104400      SCOPE      ;*ERROR* COMPARE FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
1876
1877
1878
1879 004132 012700 177774      MOV    #-4,RO
1880 004136 012701 000010      MOV    #+10,R1
1881 004142 026061 015100 015100  CMP    A(0),A(1)
1882 004150 001401      BEQ    .+4
1883 004152 104000      HLT
1884 004154 104400      SCOPE      ;*ERROR* CMP FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
1885
1886
1887 004156 012700 177774      MOV    #-4,RO
1888 004162 012701 000010      MOV    #10,R1
1889 004166 026160 015100 015100  CMP    A(1),A(0)
1890 004174 001401      BEQ    .+4
1891 004176 104000      HLT
1892 004200 104400      SCOPE      ;*ERROR* COMPARE FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
1893
1894
1895 ;*****
1896 ;TEST MOVE ODD BYTE TO REGISTER
1897 ;*****
1898
1899
1900
1901
1902
1903 004202 116700 000007      MOV    1$+1,RO      ;GET HIGH BYTE OF "HLT" INSTRUCTION
1904 004206 122700 000210      CMP    #210,RO      ;DID RO GET ODD BYTE?
1905 004212 001401      BEQ    .+4          ;BRANCH IF YES
1906 004214 104000      HLT
1907 004216 104400      SCOPE      ;LOOP ON SUBTEST OR SETUP LOC. RETURN
1908
1909
1910 ;*****
1911 ;TEST MOVE INSTRUCTION FOR INDEX
1912 ;*****
1913
1914
1915 004220 012700 177770      MOV    #-10,RO
1916 004224 016067 015100 010670  MOV    A(0),TEMP
1917 004232 026727 010664 125252  CMP    TEMP,#125252
1918 004240 001401      BEQ    .+4

```

```

1919 004242 104000          HLT          ;*ERROR* COMPARE FAILED
1920 004244 104400          SCOPE       ;LOOP ON SUBTEST OR SETUP LOC. RETURN
1921
1922
1923
1924 004246 012700 000010      MOV        #+10,RO
1925 004252 016067 015100 010642  MOV        A(0),TEMP
1926 004260 026727 010636 052525  CMP        TEMP,#052525
1927 004266 001401          BEQ        .+4
1928 004270 104000          HLT
1929 004272 104400          SCOPE       ;*ERROR* MOV FAILED
;LOOP ON SUBTEST OR SETUP LOC. RETURN
1930
1931
1932
1933 004274 012700 177770      MOV        #-10,RO
1934 004300 012760 125252 015122  MOV        #125252,TEMP(0)
1935 004306 023727 015112 125252  CMP        @#C,#125252
1936 004314 001401          BEQ        .+4
1937 004316 104000          HLT
1938 004320 104400          SCOPE       ;*ERROR* MOV FAILED
;LOOP ON SUBTEST OR SETUP LOC. RETURN
1939
1940
1941
1942 004322 012700 000010      MOV        #+10,RO
1943 004326 012760 052525 015122  MOV        #052525,TEMP(0)
1944 004334 023727 015132 052525  CMP        @#TEMP+10,#052525
1945 004342 001401          BEQ        .+4
1946 004344 104000          HLT
1947 004346 104400          SCOPE       ;*ERROR* MOV FAILED
;LOOP ON SUBTEST OR SETUP LOC. RETURN
1948
1949
1950
1951
1952 ;*****
;TEST BIC INSTRUCTION FOR INDEXING
;*****
1953
1954
1955 004350 012767 177777 010544  MOV        #-1,TEMP
1956 004356 012700 177770      MOV        #-10,RO
1957 004362 046067 015100 010532  BIC        A(0),TEMP
1958 004370 026727 010526 052525  CMP        TEMP,#052525
1959 004376 001401          BEQ        .+4
1960 004400 104000          HLT
1961 004402 104400          SCOPE       ;*ERROR* BIC FAILED
;LOOP ON SUBTEST OR SETUP LOC. RETURN
1962
1963
1964
1965 004404 012767 177777 010510  MOV        #-1,TEMP
1966 004412 012700 000010      MOV        #10,RO
1967 004416 046067 015100 010476  BIC        A(0),TEMP
1968 004424 026727 010472 125252  CMP        TEMP,#125252
1969 004432 001401          BEQ        .+4
1970 004434 104000          HLT
1971 004436 104400          SCOPE       ;*ERROR* BIC FAILED
;LOOP ON SUBTEST OR SETUP LOC. RETURN
1972
1973
1974

```

```

1975 004440 012737 177777 015132      MOV      #-1,0#TEMP+10
1976 004446 012700 000010      MOV      #10,RO
1977 004452 042760 125252 015122      BIC      #125252,TEMP(0)
1978 004460 023727 015132 052525      CMP      0#TEMP+10,#52525
1979 004466 001401      BEQ      .+4
1980 004470 104000      HLT
1981 004472 104400      SCOPE      ;*ERROR* BIC FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
1982
1983
1984

```

```

1985 004474 012700 177770      MOV      #-10,RO
1986 004500 012767 177777 010404      MOV      #-1,TEMP-10
1987 004506 042767 052525 010376      BIC      #052525,TEMP-10
1988 004514 026727 010372 125252      CMP      TEMP-10,#125252
1989 004522 001401      BEQ      .+4
1990 004524 104000      HLT
1991 004526 104400      SCOPE      ;*ERROR* BIC FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
1992
1993
1994

```

```

;*****
;TEST BIT INSTRUCTION MODE 0
;*****

```

```

1998 004530 012700 125252      BIT0:  MOV      #125252,RO      ;SET RO=ALT 1'S
1999 004534 032700 052525      BIT      #52525,RO      ;125252 ANDED 52525=0
2000 004540 001401      BEQ      .+4      ;BRANCH IF RESULT OK
2001 004542 104000      HLT
2002 004544 104400      SCOPE      ;*ERROR* BIT MODE 0 FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2003
2004
2005

```

```

;*****
;TEST BITB INSTRUCTION MODE NON 0. (27)
;*****

```

```

2009 004546 112767 000200 010347      BITB0: MOVB     #200,TEMP+1
2010 004554 132767 000200 010341      BITB    #200,TEMP+1      ;200 ANDED 200=200
2011 004562 001001      BNE     .+4      ;BRANCH IF OK
2012 004564 104000      HLT
2013 004566 104400      SCOPE      ;*ERROR* BITB MODE 27 FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2014
2015
2016

```

```

;*****
;TEST SUBTRACT INSTRUCTION FOR INDEXING
;*****

```

```

2020 004570 012767 125252 010324      MOV      #125252,TEMP
2021 004576 012700 177770      MOV      #-10,RO
2022 004602 166067 015100 010312      SUB      A(0),TEMP
2023 004610 001401      BEQ      .+4
2024 004612 104000      HLT
2025 004614 104400      SCOPE      ;*ERROR* SUB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2026
2027
2028

```

```

2029 004616 012737 125252 015122      MOV      #125252,0#TEMP
2030 004624 012700 177770      MOV      #-10,RO

```

```

2031 004630 166760 010234 015132      SUB      B,TEMP+10(0)
2032 004636 001401                      BEQ      .+4
2033 004640 104000                      HLT
2034 004642 104400                      SCOPE    ;*ERROR* SUB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2035
2036
2037
2038 004644 012767 052525 010250      MOV      #052525,TEMP
2039 004652 012700 000010                      MOV      #10,RO
2040 004656 166067 015100 010236      SUB      A(0),TEMP
2041 004664 001401                      BEQ      .+4
2042 004666 104000                      HLT
2043 004670 104400                      SCOPE    ;*ERROR* SUB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2044
2045
2046
2047 004672 012737 052525 015122      MOV      #052525,@#TEMP
2048 004700 012700 000010                      MOV      #10,RO
2049 004704 166760 010200 015112      SUB      A+10,C(0)
2050 004712 001401                      BEQ      .+4
2051 004714 104000                      HLT
2052 004716 104400                      SCOPE    ;*ERROR* SUB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2053
2054
2055
2056 ;*****
2057 ;TEST UNARYS INDEXED
2058 ;*****
2059
2060 004720 012737 177777 015122      MOV      #-1,@#TEMP
2061 004726 012700 177770                      MOV      #-10,RO
2062 004732 005060 015132                      CLR      D(0)
2063 004736 005737 015122                      TST      @#TEMP
2064 004742 001401                      BEQ      .+4
2065 004744 104000                      HLT
2066 004746 104400                      SCOPE    ;*ERROR* CLR FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2067
2068
2069
2070 004750 012737 177777 015122      MOV      #-1,@#TEMP
2071 004756 012700 000010                      MOV      #+10,RO
2072 004762 005060 015112                      CLR      C(0)
2073 004766 005737 015122                      TST      @#TEMP
2074 004772 001401                      BEQ      .+4
2075 004774 104000                      HLT
2076 004776 104400                      SCOPE    ;*ERROR* CLR FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2077
2078
2079
2080 005000 012737 177777 015122      MOV      #-1,@#TEMP
2081 005006 012700 177770                      MOV      #-10,RO
2082 005012 005160 015132                      COM      D(0)
2083 005016 005737 015122                      TST      @#TEMP
2084 005022 001401                      BEQ      .+4
2085 005024 104000                      HLT
2086 005026 104400                      SCOPE    ;*ERROR* COM FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN

```



```

2087
2088
2089
2090 005030 012737 177777 015122      MOV      #-1,2#TEMP
2091 005036 012700 000010          MOV      #-10,RO
2092 005042 005160 015112          COM      C(0)
2093 005046 005737 015122          TST     2#TEMP
2094 005052 001401          BEQ     .+4
2095 005054 104000          HLT
2096 005056 104400          SCOPE      ;*ERROR* COM FAILED
                ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2098
2099 005060 012737 177777 015122      MOV      #-1,2#TEMP
2100 005066 012700 177770          MOV      #-10,RO
2101 005072 005260 015132          INC     D(0)
2102 005076 005737 015122          TST     2#TEMP
2103 005102 001401          BEQ     .+4
2104 005104 104000          HLT
2105 005106 104400          SCOPE      ;*ERROR* INC FAILED
                ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2107
2108
2109 005110 012737 177777 015122      MOV      #-1,2#TEMP
2110 005116 012700 000010          MOV      #+10,RO
2111 005122 005260 015112          INC     C(0)
2112 005126 005737 015122          TST     2#TEMP
2113 005132 001401          BEQ     .+4
2114 005134 104000          HLT
2115 005136 104400          SCOPE      ;*ERROR* INC FAILED
                ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2117
2118
2119 005140 012737 000001 015122      MOV      #1,2#TEMP
2120 005146 012700 177770          MOV      #-10,RO
2121 005152 005360 015132          DEC     D(0)
2122 005156 005737 015122          TST     2#TEMP
2123 005162 001401          BEQ     .+4
2124 005164 104000          HLT
2125 005166 104400          SCOPE      ;*ERROR* DEC FAILED
                ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2127
2128
2129 005170 012737 000001 015122      MOV      #1,2#TEMP
2130 005176 012700 000010          MOV      #0,RO
2131 005202 005360 015112          DEC     C(0)
2132 005206 005737 015122          TST     2#TEMP
2133 005212 001401          BEQ     .+4
2134 005214 104000          HLT
2135 005216 104400          SCOPE      ;*ERROR* DEC FAILED
                ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2137
2138
2139 005220 012737 000001 015122      MOV      #1,2#TEMP
2140 005226 012700 177770          MOV      #-10,RO
2141 005232 005460 015132          NEG     D(0)
2142 005236 022737 177777 015122      CMP     #-1,2#TEMP

```

2143	005244	001401			BEQ	.+4	
2144	005246	104000			HLT		;*ERROR* NEG FAILED
2145	005250	104400			SCOPE		;LOOP ON SUBTEST OR SETUP LOC. RETURN
2146							
2147							
2148							
2149	005252	012737	000001	015122	MOV	#1,2#TEMP	
2150	005260	012700	000010		MOV	#+10,RO	
2151	005264	005460	015112		NEG	C(0)	
2152	005270	022737	177777	015122	CMP	#-1,2#TEMP	
2153	005276	001401			BEQ	.+4	
2154	005300	104000			HLT		;*ERROR* NEG FAILED
2155	005302	104400			SCOPE		;LOOP ON SUBTEST OR SETUP LOC. RETURN
2156							
2157							
2158							
2159	005304	012737	177777	015122	MOV	#-1,2#TEMP	
2160	005312	012700	177770		MOV	#-10,RO	
2161	005316	000261			SEC		
2162	005320	005560	015132		ADC	D(0)	
2163	005324	005737	015122		TST	2#TEMP	
2164	005330	001401			BEQ	.+4	
2165	005332	104000			HLT		;*ERROR* ADC FAILED
2166	005334	104400			SCOPE		;LOOP ON SUBTEST OR SETUP LOC. RETURN
2167							
2168							
2169							
2170	005336	012737	177777	015122	MOV	#-1,2#TEMP	
2171	005344	012700	000010		MOV	#+10,RO	
2172	005350	000261			SEC		
2173	005352	005560	015112		ADC	C(0)	
2174	005356	005737	015122		TST	2#TEMP	
2175	005362	001401			BEQ	.+4	
2176	005364	104000			HLT		;*ERROR* ADC FAILED
2177	005366	104400			SCOPE		;LOOP ON SUBTEST OR SETUP LOC. RETURN
2178							
2179							
2180							
2181	005370	012737	000001	015122	MOV	#1,2#TEMP	
2182	005376	012700	177770		MOV	#-10,RO	
2183	005402	000261			SEC		
2184	005404	005660	015132		SBC	D(0)	
2185	005410	005737	015122		TST	2#TEMP	
2186	005414	001401			BEQ	.+4	
2187	005416	104000			HLT		;*ERROR* SBC FAILED
2188	005420	104400			SCOPE		;LOOP ON SUBTEST OR SETUP LOC. RETURN
2189							
2190							
2191							
2192	005422	012737	000001	015122	MOV	#1,2#TEMP	
2193	005430	012700	000010		MOV	#+10,RO	
2194	005434	000261			SEC		
2195	005436	005660	015112		SBC	C(0)	
2196	005442	005737	015122		TST	2#TEMP	
2197	005446	001401			BEQ	.+4	
2198	005450	104000			HLT		;*ERROR* SBC FAILED

2199 005452 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN

2200  
2201  
2202  
2203  
2204 :\*\*\*\*\*  
:TEST JMP INDIRECT  
:\*\*\*\*\*

2207 005454 010700 MOV PC,R0  
2208 005456 062700 000010 ADD #10,R0  
2209 005462 000110 JMP @R0  
2210 005464 104000 HLT ;\*ERROR\* JMP FAILED  
2211 005466 000240 NOP  
2212 005470 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN

2216 005472 010600 MOV SP,R0  
2217 005474 010001 MOV R0,R1  
2218 005476 010103 MOV R1,R3 ;R2 IS NOT TESTED HERE SINCE IT IS USED IN THE FLOPPY

2220 005500 010304 MOV R3,R4  
2221 005502 010405 MOV R4,R5  
2222 005504 020605 CMP SP,R5  
2223 005506 001401 BEQ .+4  
2224 005510 104000 HLT ;\*ERROR\* MOV REGISTER FAILED  
2225 005512 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN

2227 .SBTTL TEST INDIRECT ADDRESSING  
2228 :\*\*\*\*\*  
:TEST COMPARE INSTRUCTION  
:\*\*\*\*\*

2232 005514 023727 015070 125252 CMP @#8,#125252  
2233 005522 001401 BEQ .+4  
2234 005524 104000 HLT ;\*ERROR\* CMP FAILED  
2235 005526 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN

2239 005530 022737 125252 015070 CMP #125252,@#8  
2240 005536 001401 BEQ .+4  
2241 005540 104000 HLT ;\*ERROR\* CMP FAILED  
2242 005542 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN

2246 005544 023737 015070 015070 CMP @#8,@#8  
2247 005552 001401 BEQ .+4  
2248 005554 104000 HLT ;\*ERROR\* CMP FAILED  
2249 005556 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN

2250  
2251  
2252  
2253  
2254 :\*\*\*\*\*  
:TEST MOV INSTRUCTIONS

```

2255                                     :*****
2256                                     :*****
2257 005560 013700 015070                MOV    @#B,RO
2258 005564 022700 125252                CMP    @#125252,RO
2259 005570 001401                        BEQ    .+4
2260 005572 104000                        HLT
2261 005574 104400                        SCOPE                                     :*ERROR* MOV FAILED
                                           :LOOP ON SUBTEST OR SETUP LOC. RETURN
2262
2263
2264
2265 005576 012737 125252 015122          MOV    @#125252,@#TEMP
2266 005604 023737 015070 015122          CMP    @#B,@#TEMP
2267 005612 001401                        BEQ    .+4
2268 005614 104000                        HLT
2269 005616 104400                        SCOPE                                     :*ERROR* MOV FAILED
                                           :LOOP ON SUBTEST OR SETUP LOC. RETURN
2270
2271
2272
2273 005620 013737 015070 015112          MOV    @#B,@#C
2274 005626 023737 015070 015112          CMP    @#B,@#C
2275 005634 001401                        BEQ    .+4
2276 005636 104000                        HLT
2277 005640 104400                        SCOPE                                     :*ERROR* MOV FAILED
                                           :LOOP ON SUBTEST OR SETUP LOC. RETURN
2278
2279
2280                                     :*****
2281 :TEST BIC INSTRUCTION INDIRECT
2282 :*****
2283
2284 005642 012700 177777                MOV    #-1,RO
2285 005646 043700 015070                BIC    @#B,RO
2286 005652 020027 052525                CMP    RO,@#052525
2287 005656 001401                        BEQ    .+4
2288 005660 104000                        HLT
2289 005662 104400                        SCOPE                                     :*ERROR* BIC FAILED
                                           :LOOP ON SUBTEST OR SETUP LOC. RETURN
2290
2291
2292
2293 005664 012737 177777 015122          MOV    #-1,@#TEMP
2294 005672 042737 125252 015122          BIC    @#125252,@#TEMP
2295 005700 022737 052525 015122          CMP    @#052525,@#TEMP
2296 005706 001401                        BEQ    .+4
2297 005710 104000                        HLT
2298 005712 104400                        SCOPE                                     :*ERROR* BIC FAILED
                                           :LOOP ON SUBTEST OR SETUP LOC. RETURN
2299
2300
2301
2302 005714 012737 177777 015112          MOV    #-1,@#C
2303 005722 043737 015070 015112          BIC    @#B,@#C
2304 005730 023727 015112 052525          CMP    @#C,@#52525
2305 005736 001401                        BEQ    .+4
2306 005740 104000                        HLT
2307 005742 104400                        SCOPE                                     :*ERROR* BIC FAILED
                                           :LOOP ON SUBTEST OR SETUP LOC. RETURN
2308
2309
2310

```

```

2311
2312
2313
2314
2315 005744 012700 125252      MOV      #125252,RO
2316 005750 163700 015070      SUB      @#B,RO
2317 005754 020027 000000      CMP      RO,#0
2318 005760 001401      BEQ      .+4
2319 005762 104000      HLT
2320 005754 104400      SCOPE      ;*ERROR* SUB FAILED
                ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2321
2322
2323
2324 005766 012737 125252 015122      MOV      #125252,@#TEMP
2325 005774 166737 007070 015122      SUB      B,@#TEMP
2326 006002 001401      BEQ      .+4
2327 006004 104000      HLT
2328 006006 104400      SCOPE      ;*ERROR* SUB FAILED
                ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2329
2330
2331
2332 006010 012767 125252 007104      MOV      #125252,TEMP
2333 006016 163767 015070 007076      SUB      @#B,TEMP
2334 006024 005767 007072      TST      TEMP
2335 006030 001401      BEQ      .+4
2336 006032 104000      HLT
2337 006034 104400      SCOPE      ;*ERROR* SUB FAILED
                ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2338
2339
2340
2341
2342
2343
2344 006036 012737 177777 015122      MOV      #-1,@#TEMP
2345 006044 005037 015122      CLR      @#TEMP
2346 006050 005737 015122      TST      @#TEMP
2347 006054 001401      BEQ      .+4
2348 006056 104000      HLT
2349 006060 104400      SCOPE      ;*ERROR* TST FAILED
                ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2350
2351
2352
2353 006062 012737 125252 015122      MOV      #125252,@#TEMP
2354 006070 005137 015122      COM      @#TEMP
2355 006074 022737 052525 015122      CMP      #052525,@#TEMP
2356 006102 001401      BEQ      .+4
2357 006104 104000      HLT
2358 006106 104400      SCOPE      ;*ERROR* COM FAILED
                ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2359
2360
2361
2362 006110 005037 015122      CLR      @#TEMP
2363 006114 005237 015122      INC      @#TEMP
2364 006120 022737 000001 015122      CMP      #1,@#TEMP
2365 006126 001401      BEQ      .+4
2366 006130 104000      HLT
                ;*ERROR* INC FAILED

```

```

:*****
:TEST SUBTRACT INSTRUCTION
:*****

```

```

:*****
:TEST UNARYS INDIRECT
:*****

```

```

2367 006132 104400          SCOPE          ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2368
2369
2370
2371 006134 005037 015122    CLR          @#TEMP
2372 006140 005377 006760    DEC          @#TEMP+2
2373 006144 023727 015122 177777  CMP          @#TEMP,#-1
2374 006152 001401          BEQ          .+4
2375 006154 104000          HLT
2376 006156 104400          SCOPE          ;*ERROR* DEC FAILED
;LOOP ON SUBTEST OR SETUP LOC. RETURN
2377
2378
2379
2380 006160 012737 000001 015122    MOV          #1,@#TEMP
2381 006166 005437 015122    NEG          @#TEMP
2382 006172 022737 177777 015122    CMP          #-1,@#TEMP
2383 006200 001401          BEQ          .+4
2384 006202 104000          HLT          ;*ERROR* NEG FAILED
2385 006204 104400          SCOPE          ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2386
2387
2388
2389
2390
2391
2392
2393
2394 006206 027727 006660 125252  ;*****
;TEST INDIRECT ADDRESSING WITH INDEXING
;*****
;TEST COMPARE INSTRUCTION
2395 006214 001401          CMP          @B+2,#125252
2396 006216 104000          BEQ          .+4
2397 006220 104400          HLT          ;*ERROR* CMP FAILED
2398          SCOPE          ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2399
2400
2401 006222 022777 125252 006642    CMP          #125252,@B+2
2402 006230 001401          BEQ          .+4
2403 006232 104000          HLT          ;*ERROR* CMP FAILED
2404 006234 104400          SCOPE          ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2405
2406
2407
2408 006236 027777 006630 006626    CMP          @B+2,@B+2
2409 006244 001401          BEQ          .+4
2410 006246 104000          HLT          ;*ERROR* CMP FAILED
2411 006250 104400          SCOPE          ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2412
2413
2414
2415
2416
2417
2418
2419 006252 017700 006614          MOV          @B+2,R0
2420 006256 022700 125252          CMP          #125252,R0
2421 006262 001401          BEQ          .+4
2422 006264 104000          HLT          ;*ERROR* MOV FAILED

```

```

2423 006266 104400          SCOPE                ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2424
2425
2426
2427 006270 012777 125252 006626      MOV      #125252, @TEMP+2
2428 006276 023737 015070 015122      CMP      @#B, @#TEMP
2429 006304 001401          BEQ      .+4
2430 006306 104000          HLT
2431 006310 104400          SCOPE                ;*ERROR* MOV FAILED
                                     ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2432
2433
2434
2435 006312 017777 006554 006574      MOV      @B+2, @C+2
2436 006320 023737 015070 015112      CMP      @#B, @#C
2437 006326 001401          BEQ      .+4
2438 006330 104000          HLT
2439 006332 104400          SCOPE                ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2440
2441
2442
2443
2444
2445
2446
2447 006334 012700 177777          MOV      #-1, R0
2448 006340 047700 006526          BIC      @B+2, R0
2449 006344 020027 052525          CMP      R0, #52525
2450 006350 001401          BEQ      .+4
2451 006352 104000          HLT
2452 006354 104400          SCOPE                ;*ERROR* BIC FAILED
                                     ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2453
2454
2455
2456 006356 012737 177777 015122      MOV      #-1, @#TEMP
2457 006364 042777 125252 006532      BIC      #125252, @TEMP+2
2458 006372 022737 052525 015122      CMP      #52525, @#TEMP
2459 006400 001401          BEQ      .+4
2460 006402 104000          HLT
2461 006404 104400          SCOPE                ;*ERROR* BIC FAILED
                                     ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2462
2463
2464
2465 006406 012737 177777 015112      MOV      #-1, @#C
2466 006414 047777 006452 006472      BIC      @B+2, @C+2
2467 006422 026737 006462 015112      CMP      A+10, @#C
2468 006430 001401          BEQ      .+4
2469 006432 104000          HLT
2470 006434 104400          SCOPE                ;*ERROR* BIC FAILED
                                     ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2471
2472
2473
2474 006436 012700 125252          MOV      #125252, R0
2475 006442 167700 006424          SUB      @B+2, R0
2476 006446 020027 000000          CMP      R0, #0
2477 006452 001401          BEQ      .+4
2478 006454 104000          HLT
                                     ;*ERROR* SUB FAILED

```

```

:*****
:TEST BIC INSTRUCTION INDIRECT WITH INDEXING
:*****

```

```

2479 006456 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2480
2481
2482
2483 006460 012737 125252 015122 MOV #125252,@#TEMP
2484 006466 166777 006376 006430 SUB @B,@TEMP+2
2485 006474 001401 BEQ .+4
2486 006476 104000 HLT ;*ERROR* SUB FAILED
2487 006500 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2488
2489
2490

```

```

2491 006502 012737 125252 015122 MOV #125252,@#TEMP
2492 006510 167777 006356 006406 SUB @B+2,@TEMP+2
2493 006516 005737 015122 TST @#TEMP
2494 006522 001401 BEQ .+4
2495 006524 104000 HLT ;*ERROR* SUB FAILED
2496 006526 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2497
2498
2499

```

```

:*****
:TEST ADD INDIRECT WITH INDEXING
:*****

```

```

2500
2501
2502
2503
2504 006530 005000 CLR R0
2505 006532 067700 006334 ADD @B+2,R0
2506 006536 022700 125252 CMP #125252,R0
2507 006542 001401 BEQ .+4
2508 006544 104000 HLT ;*ERROR* ADD FAILED
2509 006546 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2510
2511

```

```

2512
2513 006550 005037 015122 CLR @#TEMP
2514 006554 062777 125252 006342 ADD #125252,@TEMP+2
2515 006562 022737 125252 015122 CMP #125252,@#TEMP
2516 006570 001401 BEQ .+4
2517 006572 104000 HLT ;*ERROR* ADD FAILED
2518 006574 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2519

```

```

2520
2521 006576 012737 125252 015122 MOV #125252,@#TEMP
2522 006604 067777 006276 006312 ADD @A+6,@TEMP+2
2523 006612 023727 015122 177777 CMP @#TEMP,#-1
2524 006620 001401 BEQ .+4
2525 006622 104000 HLT ;*ERROR* ADD FAILED
2526 006624 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2527

```

```

:*****
:TEST UNARYS INDIRECT WITH INDEXING
:*****

```

```

2528
2529
2530
2531
2532
2533
2534 006626 012737 177777 015122 MOV #-1,@#TEMP

```



2535	006634	005077	006264		CLR	@TEMP+2	
2536	006640	005737	015122		TST	@TEMP	
2537	006644	001401			BEQ	.+4	
2538	006646	104000			HLT		;*ERROR* TST FAILED
2539	006650	104400			SCOPE		;LOOP ON SUBTEST OR SETUP LOC. RETURN
2540							
2541							
2542							
2543	006652	012737	125252	015122	MOV	#125252,@TEMP	
2544	006660	005177	006240		COM	@TEMP+2	
2545	006664	022737	052525	015122	CMP	#052525,@TEMP	
2546	006672	001401			BEQ	.+4	
2547	006674	104000			HLT		;*ERROR* COM FAILED
2548	006676	104400			SCOPE		;LOOP ON SUBTEST OR SETUP LOC. RETURN
2549							
2550							
2551							
2552	006700	005037	015122		CLR	@TEMP	
2553	006704	005277	006214		INC	@TEMP+2	
2554	006710	022737	000001	015122	CMP	#1,@TEMP	
2555	006716	001401			BEQ	.+4	
2556	006720	104000			HLT		;*ERROR* INC FAILED
2557	006722	104400			SCOPE		;LOOP ON SUBTEST OR SETUP LOC. RETURN
2558							
2559							
2560							
2561	006724	005037	015122		CLR	@TEMP	
2562	006730	005377	006170		DEC	@TEMP+2	
2563	006734	023727	015122	177777	CMP	@TEMP,#-1	
2564	006742	001401			BEQ	.+4	
2565	006744	104000			HLT		;*ERROR* DEC FAILED
2566	006746	104400			SCOPE		;LOOP ON SUBTEST OR SETUP LOC. RETURN
2567							
2568							
2569							
2570	006750	012737	000001	015122	MOV	#1,@TEMP	
2571	006756	005477	006142		NEG	@TEMP+2	
2572	006762	022737	177777	015122	CMP	#-1,@TEMP	
2573	006770	001401			BEQ	.+4	
2574	006772	104000			HLT		;*ERROR* NEG FAILED
2575	006774	104400			SCOPE		;LOOP ON SUBTEST OR SETUP LOC. RETURN
2576							
2577							
2578							
2579	006776	012737	177777	015122	MOV	#-1,@TEMP	
2580	007004	000261			SEC		
2581	007006	005577	006112		ADC	@TEMP+2	
2582	007012	005737	015122		TST	@TEMP	
2583	007016	001401			BEQ	.+4	
2584	007020	104000			HLT		;*ERROR* ADC FAILED
2585	007022	104400			SCOPE		;LOOP ON SUBTEST OR SETUP LOC. RETURN
2586							
2587							
2588							
2589	007024	012737	000001	015122	MOV	#1,@TEMP	
2590	007032	000261			SEC		

2591	007034	005677	006064	SBC	@TEMP+2	
2592	007040	005737	015122	TST	@#TEMP	
2593	007044	001401		BEQ	.+4	
2594	007046	104000		HLT		;*ERROR* SBC FAILED
2595	007050	104400		SCOPE		;LOOP ON SUBTEST OR SETUP LOC. RETURN

```

2596
2597
2598
2599
2600
2601
2602
2603
2604
2605
2606
2607
2608
2609
2610

```

\*\*\*\*\*  
: TEST OF COMBINED INDEXING AND INDIRECT  
\*\*\*\*\*

2603	007052	012700	177772	MOV	#-6, R0	
2604	007056	027027	015100	CMP	@A(0), #125252	
2605	007064	001401		BEQ	.+4	
2606	007066	104000		HLT		;*ERROR* CMP FAILED
2607	007070	104400		SCOPE		;LOOP ON SUBTEST OR SETUP LOC. RETURN

```

2608
2609
2610
2611
2612
2613
2614
2615
2616
2617
2618
2619
2620
2621
2622
2623
2624
2625
2626
2627
2628
2629
2630
2631

```

2611	007072	012700	177772	MOV	#-6, R0	
2612	007076	022770	125252	CMP	#125252, @A(0)	
2613	007104	001401		BEQ	.+4	
2614	007106	104000		HLT		;*ERROR* CMP FAILED
2615	007110	104400		SCOPE		;LOOP ON SUBTEST OR SETUP LOC. RETURN

2619	007112	012700	177772	MOV	#-6, R0	
2620	007116	012701	000002	MOV	#+2, R1	
2621	007122	027071	015100	CMP	@A(0), @A(1)	
2622	007130	001401		BEQ	.+4	
2623	007132	104000		HLT		;*ERROR* CMP FAILED
2624	007134	104400		SCOPE		;LOOP ON SUBTEST OR SETUP LOC. RETURN

```

2625
2626
2627
2628
2629
2630
2631
2632
2633
2634
2635
2636
2637
2638
2639
2640
2641
2642
2643
2644
2645
2646

```

\*\*\*\*\*  
: TEST BIC INSTRUCTION  
\*\*\*\*\*

2632	007136	012700	000006	MOV	#+6, R0	
2633	007142	012767	177777	MOV	#-1, TEMP	
2634	007150	047067	015100	BIC	@A(0), TEMP	
2635	007156	022767	125252	CMP	#125252, TEMP	
2636	007164	001401		BEQ	.+4	
2637	007166	104000		HLT		;*ERROR* BIC FAILED
2638	007170	104400		SCOPE		;LOOP ON SUBTEST OR SETUP LOC. RETURN

2642	007172	012700	177772	MOV	#-6, R0	
2643	007176	012737	177777	MOV	#-1, @#C	
2644	007204	042770	125252	BIC	#125252, @TEMP(0)	
2645	007212	023727	015112	CMP	@#C, #052525	
2646	007220	001401		BEQ	.+4	

```

2647 007222 104000 HLT ;*ERROR* BIC FAILED
2648 007224 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2649
2650
2651 007226 012737 177777 015112 MOV #-1,0#C
2652 007234 012700 177772 MOV #-6,R0
2653 007240 012701 177772 MOV #-6,R1
2654 007244 047071 015100 015122 BIC 0A(0),0TEMP(1)
2655 007252 022737 052525 015112 CMP #052525,0#C
2656 007260 001401 BEQ .+4
2657 007262 104000 HLT ;*ERROR* BIC FAILED
2658 007264 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2659
2660
2661
2662 007266 122727 000000 000001 CMPB #0,#1
2663 007274 002401 BLT .+4
2664 007276 104000 HLT ;*ERROR* CMPB FAILED
2665 007300 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2666
2667
2668
2669
2670
2671
2672 007302 012700 177770 MOV #-10,R0 ;MINUS 10 TO REG 0
2673 007306 126027 015100 000252 CMPB A(0),#000252 ;(A INDEX BY MINUS 10) TO #125252
2674 007314 001401 BEQ .+4
2675 007316 104000 HLT ;*ERROR* COMPARE WITH INDEX FAILED
2676 007320 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2677
2678
2679
2680 007322 012700 177770 MOV #-10,R0 ;FOR INDEX
2681 007326 122760 000252 015100 CMPB #000252,A(0) ;A INDEXED
2682 007334 001401 BEQ .+4
2683 007336 104000 HLT ;*ERROR* CMPB FAILED
2684 007340 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2685
2686
2687
2688 007342 012700 000010 MOV #10,R0 ;INDEX
2689 007346 126027 015100 000125 CMPB A(0),#000125
2690 007354 001401 BEQ .+4
2691 007356 104000 HLT ;*ERROR* CMPB FAILED
2692 007360 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2693
2694
2695
2696 007362 012700 000010 MOV #10,R0
2697 007366 122760 000125 015100 CMPB #000125,A(0)
2698 007374 001401 BEQ .+4
2699 007376 104000 HLT ;*ERROR* CMPB FAILED
2700 007400 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2701
2702

```

```

;*****
;TEST COMPARE INSTRUCTION INDEXED
;*****

```

2703						
2704	007402	012700	177770		MOV	#-10,R0
2705	007406	126060	015100	015100	CMPB	A(0),A(0)
2706	007414	001401			BEQ	.+4
2707	007416	104000			HLT	
2708	007420	104400			SCOPE	;
2709						*ERROR* CMPB FAILED
2710						;LOOP ON SUBTEST OR SETUP LOC. RETURN
2711						
2712	007422	012700	000010		MOV	#+10,R0
2713	007426	126060	015100	015100	CMPB	A(0),A(0)
2714	007434	001401			BEQ	.+4
2715	007436	104000			HLT	
2716	007440	104400			SCOPE	;
2717						*ERROR* CMPB FAILED
2718						;LOOP ON SUBTEST OR SETUP LOC. RETURN
2719						
2720	007442	012700	177770		MOV	#-10,R0
2721	007446	012701	000004		MOV	#+4,R1
2722	007452	126061	015100	015100	CMPB	A(0),A(1)
2723	007460	001401			BEQ	.+4
2724	007462	104000			HLT	
2725	007464	104400			SCOPE	;
2726						*ERROR* CMPB FAILED
2727						;LOOP ON SUBTEST OR SETUP LOC. RETURN
2728						
2729	007466	126160	015100	015100	CMPB	A(1),A(0)
2730	007474	001401			BEQ	.+4
2731	007476	104000			HLT	
2732	007500	104400			SCOPE	;
2733						*ERROR* CMPB FAILED
2734						;LOOP ON SUBTEST OR SETUP LOC. RETURN
2735						
2736	007502	012700	177774		MOV	#-4,R0
2737	007506	012701	000010		MOV	#+10,R1
2738	007512	126061	015100	015100	CMPB	A(0),A(1)

```

2741 007520 001401      BEQ      .+4
2742 007522 104000      HLT
2743 007524 104400      SCOPE      ;*ERROR* CMPB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2744
2745
2746
2747 007526 012700 177774      MOV      #-4,RO
2748 007532 012701 000010      MOV      #10,R1
2749 007536 126160 015100 015100      CMPB     A(1),A(0)
2750 007544 001401      BEQ      .+4
2751 007546 104000      HLT
2752 007550 104400      SCOPE      ;*ERROR* CMPB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2753
2754
2755
2756
2757
2758
2759
2760 007552 012700 177770      MOV      #-10,RO
2761 007556 116067 015100 005336      MOVB     A(0),TEMP
2762 007564 126727 005332 000252      CMPB     TEMP,#000252
2763 007572 001401      BEQ      .+4
2764 007574 104000      HLT
2765 007576 104400      SCOPE      ;*ERROR* MOVB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2766
2767
2768
2769 007600 012700 000010      MOV      #+10,RO
2770 007604 116067 015100 005310      MOVB     A(0),TEMP
2771 007612 126727 005304 000125      CMPB     TEMP,#000125
2772 007620 001401      BEQ      .+4
2773 007622 104000      HLT
2774 007624 104400      SCOPE      ;*ERROR* MOVB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2775
2776
2777
2778 007626 012700 177770      MOV      #-10,RO
2779 007632 112760 125252 015122      MOVB     #125252,TEMP(0)
2780 007640 123727 015112 125252      CMPB     @#C,#125252
2781 007646 001401      BEQ      .+4
2782 007650 104000      HLT
2783 007652 104400      SCOPE      ;*ERROR* MOVB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2784
2785
2786
2787 007654 012700 000010      MOV      #+10,RO
2788 007660 112760 052525 015122      MOVB     #052525,TEMP(0)
2789 007666 123727 015132 052525      CMPB     @#TEMP+10,#052525
2790 007674 001401      BEQ      .+4
2791 007676 104000      HLT
2792 007700 104400      SCOPE      ;*ERROR* MOVB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN

```

```

*****
;TEST MOVE INSTRUCTION FOR INDEX
*****

```

```

2794                                     :*****
2795                                     :TEST BIC INSTRUCTION FOR INDEXING
2796                                     :*****
2797
2798 007702 012767 177777 005212      MOV      #-1,TEMP
2799 007710 012700 177770              MOV      #-10,RO
2900 007714 146067 015100 005200      BICB     A(0),TEMP
2901 007722 126727 005174 177525      CMPB     TEMP,#177525
2902 007730 001401                    BEQ      .+4
2903 007732 104000                    HLT
2904 007734 104400                    SCOPE      ;*ERROR* BICB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2905
2906
2907
2908 007736 012767 177777 005156      MOV      #-1,TEMP
2909 007744 012700 000010              MOV      #10,RO
2910 007750 146067 015100 005144      BICB     A(0),TEMP
2911 007756 126727 005140 007652      CMPB     TEMP,#007652
2912 007764 001401                    BEQ      .+4
2913 007766 104000                    HLT
2914 007770 104400                    SCOPE      ;*ERROR* BICB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2915
2916
2917
2918 007772 012737 177777 015132      MOV      #-1,2#TEMP+10
2919 010000 012700 000010              MOV      #10,RO
2920 010004 142760 125252 015122      BICB     #125252,TEMP(0)
2921 010012 123727 015132 002525      CMPB     2#TEMP+10,#2525
2922 010020 001401                    BEQ      .+4
2923 010022 104000                    HLT
2924 010024 104400                    SCOPE      ;*ERROR* BICB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2925
2926
2927
2928 010026 012700 177770              MOV      #-10,RO
2929 010032 012767 177777 005052      MOV      #-1,TEMP-10
2930 010040 142767 052525 005044      BICB     #052525,TEMP-10
2931 010046 126727 005040 125252      CMPB     TEMP-10,#125252
2932 010054 001401                    BEQ      .+4
2933 010056 104000                    HLT
2934 010060 104400                    SCOPE      ;*ERROR* BICB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2935
2936
2937
2938                                     :*****
2939                                     :TEST UNARYS INDEXED
2940                                     :*****
2941
2942 010062 012737 177777 015122      MOV      #-1,2#TEMP
2943 010070 012700 177770              MOV      #-10,RO
2944 010074 105060 015132              CLRB     D(0)
2945 010100 105737 015122              TSTB     2#TEMP
2946 010104 001401                    BEQ      .+4
2947 010106 104000                    HLT
2948 010110 104400                    SCOPE      ;*ERROR* CLRB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
2949

```

2850						
2851						
2852	010112	012737	177777	015122	MOV	#-1, @TEMP
2853	010120	012700	177770		MOV	#-10, RO
2854	010124	105060	015132		CLRB	D(0)
2855	010130	023727	015122	177400	CMP	@TEMP, #177400
2856	010136	001401			BEQ	.+4
2857	010140	104000			HLT	
2858	010142	104400			SCOPE	:*ERROR* CLRB FAILED
2859						:LOOP ON SUBTEST OR SETUP LOC. RETURN
2860						
2861						
2862	010144	012737	177777	015122	MOV	#-1, @TEMP
2863	010152	012700	177771		MOV	#-7, RO
2864	010156	105060	015132		CLRB	D(0)
2865	010162	023727	015122	000377	CMP	@TEMP, #000377
2866	010170	001401			BEQ	.+4
2867	010172	104000			HLT	
2868	010174	104400			SCOPE	:*ERROR* CLRB FAILED
2869						:LOOP ON SUBTEST OR SETUP LOC. RETURN
2870						
2871						
2872	010176	012737	177777	015122	MOV	#-1, @TEMP
2873	010204	012700	000010		MOV	#+10, RO
2874	010210	105060	015112		CLRB	C(0)
2875	010214	105737	015122		TSTB	@TEMP
2876	010220	001401			BEQ	.+4
2877	010222	104000			HLT	
2878	010224	104400			SCOPE	:*ERROR* CLRB FAILED
2879						:LOOP ON SUBTEST OR SETUP LOC. RETURN
2880						
2881						
2882	010226	012737	177777	015122	MOV	#-1, @TEMP
2883	010234	012700	177770		MOV	#-10, RO
2884	010240	105160	015132		COMB	D(0)
2885	010244	105737	015122		TSTB	@TEMP
2886	010250	001401			BEQ	.+4
2887	010252	104000			HLT	
2888	010254	104400			SCOPE	:*ERROR* COMB FAILED
2889						:LOOP ON SUBTEST OR SETUP LOC. RETURN
2890						
2891						
2892	010256	012737	177777	015122	MOV	#-1, @TEMP
2893	010264	012700	000010		MOV	#10, RO
2894	010270	105160	015112		COMB	C(0)
2895	010274	105737	015122		TSTB	@TEMP
2896	010300	001401			BEQ	.+4
2897	010302	104000			HLT	
2898	010304	104400			SCOPE	:*ERROR* COMB FAILED
2899						:LOOP ON SUBTEST OR SETUP LOC. RETURN
2900						
2901	010306	012737	177777	015122	MOV	#-1, @TEMP
2902	010314	012700	177770		MOV	#-10, RO
2903	010320	105260	015132		INCB	D(0)
2904	010324	105737	015122		TSTB	@TEMP
2905	010330	001401			BEQ	.+4





2962								
2963								
2964	010544	012737	177777	015122	MOV	#-1,@#TEMP		
2965	010552	012700	177770		MOV	#-10,R0		
2966	010556	000261			SEC			
2967	010560	105560	015132		ADCB	D(0)		
2968	010564	023727	015122	177400	CMP	@#TEMP,#177400		
2969	010572	001401			BEQ	+.4		
2970	010574	104000			HLT			:*ERROR* ADCB FAILED
2971	010576	104400			SCOPE			:LOOP ON SUBTEST OR SETUP LOC. RETURN
2972								
2973								
2974								
2975	010600	012737	177777	015122	MOV	#-1,@#TEMP		
2976	010606	012700	000010		MOV	#+10,R0		
2977	010612	000261			SEC			
2978	010614	105560	015112		ADCB	C(0)		
2979	010620	023727	015122	177400	CMP	@#TEMP,#177400		
2980	010626	001401			BEQ	+.4		
2981	010630	104000			HLT			:*ERROR* ADCB FAILED
2982	010632	104400			SCOPE			:LOOP ON SUBTEST OR SETUP LOC. RETURN
2983								
2984								
2985								
2986	010634	012737	000401	015122	MOV	#401,@#TEMP		
2987	010642	012700	177771		MOV	#-7,R0		
2988	010646	000261			SEC			
2989	010650	105660	015132		SBCB	D(0)		
2990	010654	022737	000001	015122	CMP	#1,@#TEMP		
2991	010662	001401			BEQ	+.4		
2992	010664	104000			HLT			:*ERROR* SBCB FAILED
2993	010666	104400			SCOPE			:LOOP ON SUBTEST OR SETUP LOC. RETURN
2994								
2995								
2996								
2997	010670	012737	000001	015122	MOV	#1,@#TEMP		
2998	010676	012700	000010		MOV	#+10,R0		
2999	010702	000261			SEC			
3000	010704	105660	015112		SBCB	C(0)		
3001	010710	005737	015122		TST	@#TEMP		
3002	010714	001401			BEQ	+.4		
3003	010716	104000			HLT			:*ERROR* SBCB FAILED
3004	010720	104400			SCOPE			:LOOP ON SUBTEST OR SETUP LOC. RETURN
3005								
3006								
3007								

```

3009      ;*****
3010      ;TEST INDIRECT ADDRESSING
3011      ;*****
3012
3013      ;TEST COMPARE INSTRUCTION
3014      010722 123727 015070 000252      CMPB   @#B,#000252
3015      010730 001401                      BEQ   .+4
3016      010732 104000                      HLT
3017      010734 104400                      SCOPE      ;*ERROR* CMPB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3018
3019
3020
3021      010736 123727 015071 000252      CMPB   @#B+1,#252
3022      010744 001401                      BEQ   .+4
3023      010746 104000                      HLT
3024      010750 104400                      SCOPE      ;*ERROR* CMPB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3025
3026
3027
3028
3029      010752 122737 125252 015070      CMPB   #125252,@#B
3030      010760 001401                      BEQ   .+4
3031      010762 104000                      HLT
3032      010764 104400                      SCOPE      ;*ERROR* CMPB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3033
3034
3035
3036      010766 123737 015070 015070      CMPB   @#B,@#B
3037      010774 001401                      BEQ   .+4
3038      010776 104000                      HLT
3039      011000 104400                      SCOPE      ;*ERROR* CMPB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3040
3041
3042
3043      ;*****
3044      ;TEST MOVE INSTRUCTIONS
3045      ;*****
3046
3047      011002 113700 015070                MOVB   @#B,R0
3048      011006 122700 000252                CMPB   @000252,R0
3049      011012 001401                      BEQ   .+4
3050      011014 104000                      HLT
3051      011016 104400                      SCOPE      ;*ERROR* MOVB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3052
3053
3054
3055      011020 112737 125252 015122        MOVB   #125252,@#TEMP
3056      011026 126737 004036 015122        CMPB   B,@#TEMP
3057      011034 001401                      BEQ   .+4
3058      011036 104000                      HLT
3059      011040 104400                      SCOPE      ;*ERROR* MOVB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3060
3061
3062
3063      011042 113737 015070 015112        MOVB   @#B,@#C
3064      011050 126737 004014 015112        CMPB   B,@#C

```

```

3065 011056 001401      BEQ      .+4
3066 011060 104000      HLT
3067 011062 104400      SCOPE      ;*ERROR* MOVB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3068
3069
3070
3071      ;*****
3072      ;TEST UNARYS INDIRECT
3073      ;*****
3074 011064 012737 177777 015122      MOV      #-1, @#TEMP
3075 011072 105037 015122      CLRB     @#TEMP
3076 011076 023727 015122 177400      CMP      @#TEMP, #177400
3077 011104 001401      BEQ      .+4
3078 011106 104000      HLT
3079 011110 104400      SCOPE      ;*ERROR* CLRB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3080
3081
3082
3083 011112 012737 125252 015122      MOV      #125252, @#TEMP
3084 011120 105137 015122      COMB     @#TEMP
3085 011124 022737 125125 015122      CMP      #125125, @#TEMP
3086 011132 001401      BEQ      .+4
3087 011134 104000      HLT
3088 011136 104400      SCOPE      ;*ERROR* COMB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3089
3090
3091
3092 011140 012737 125252 015122      MOV      #125252, @#TEMP
3093 011146 105137 015123      COMB     @#TEMP+1
3094 011152 022737 052652 015122      CMP      #052652, @#TEMP
3095 011160 001401      BEQ      .+4
3096 011162 104000      HLT
3097 011164 104400      SCOPE      ;*ERROR* COMB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3098
3099
3100
3101 011166 005037 015122      CLR      @#TEMP
3102 011172 105237 015123      INCB     @#TEMP+1
3103 011176 022737 000400 015122      CMP      #400, @#TEMP
3104 011204 001401      BEQ      .+4
3105 011206 104000      HLT
3106 011210 104400      SCOPE      ;*ERROR* INCB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3107
3108
3109
3110 011212 005037 015122      CLR      @#TEMP
3111 011216 105377 003702      DECB     @#TEMP+2
3112 011222 023727 015122 000377      CMP      @#TEMP, #377
3113 011230 001401      BEQ      .+4
3114 011232 104000      HLT
3115 011234 104400      SCOPE      ;*ERROR* DECB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3116
3117
3118
3119 011236 005037 015122      CLR      @#TEMP
3120 011242 112737 000001 015123      MOVB     #1, @#TEMP+1

```

```

3121 011250 105437 015123      NEGB    @TEMP+1
3122 011254 022737 177400 015122      CMP     #177400,@TEMP
3123 011262 001401      BEQ     .+4
3124 011264 104000      HLT
3125 011266 104400      SCOPE      ;*ERROR* NEGB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3126
3127
3128
3129
3130
3131
3132
3133

```

```

;*****
;TEST INDIRECT ADDRESSING WITH INDEXING
;*****

```

```

3134 011270 127727 003576 125252 ;TEST COMPARE INSTRUCTION
3135 011276 001401      CMPB   @B+2,#125252
3136 011300 104000      BEQ     .+4
3137 011302 104400      HLT
3138                                ;*ERROR* CMPB FAILED
3139                                ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3140

```

```

3141 011304 122777 125252 003560      CMPB   #125252,@B+2
3142 011312 001401      BEQ     .+4
3143 011314 104000      HLT
3144 011316 104400      SCOPE      ;*ERROR* CMPB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3145
3146
3147

```

```

3148 011320 127777 003546 003544      CMPB   @B+2,@B+2
3149 011326 001401      BEQ     .+4
3150 011330 104000      HLT
3151 011332 104400      SCOPE      ;*ERROR* CMPB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3152
3153

```

```

;*****
;TEST MOVE INSTRUCTIONS
;*****

```

```

3154
3155
3156
3157
3158 011334 117700 003532      MOVB   @B+2,R0
3159 011340 122700 125252      CMPB   #125252,R0
3160 011344 001401      BEQ     .+4
3161 011346 104000      HLT
3162 011350 104400      SCOPE      ;*ERROR* MOVB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3163
3164
3165

```

```

3166 011352 112777 125252 003544      MOVB   #125252,@TEMP+2
3167 011360 126737 003504 015122      CMPB   B,@TEMP
3168 011366 001401      BEQ     .+4
3169 011370 104000      HLT
3170 011372 104400      SCOPE      ;*ERROR* MOVB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3171
3172
3173

```

```

3174 011374 117777 003472 003512      MOVB   @B+2,@C+2
3175 011402 126737 003462 015112      CMPB   B,@C
3176 011410 001401      BEQ     .+4

```

3177	011412	104000		HLT		;	*ERROR* MOV9 FAILED
3178	011414	104400		SCOPE		;	LOOP ON SUBTEST OR SETUP LOC. RETURN

```

3179
3180
3181
3182
3183
3184
3185
3186
3187
3188
3189
3190
3191
3192
3193
3194

```

\*\*\*\*\*  
:TEST BIC INSTRUCTION INDIRECT WITH INDEXING  
\*\*\*\*\*

3186	011416	012700	177777	MOV	#-1,RO		
3187	011422	147700	003444	BICB	@B+2,RO		
3188	011426	120027	052525	CMPB	RO,#52525		
3189	011432	001401		BEQ	.+4		
3190	011434	104000		HLT		;	*ERROR* BICB FAILED
3191	011436	104400		SCOPE		;	LOOP ON SUBTEST OR SETUP LOC. RETURN

3195	011440	012737	177777	015122	MOV	#-1,@#TEMP	
3196	011446	142777	125252	003450	BICB	#125252,@TEMP+2	
3197	011454	122737	052525	015122	CMPB	#52525,@#TEMP	
3198	011462	001401			BEQ	.+4	
3199	011464	104000			HLT		;
3200	011466	104400			SCOPE		;

;

\*ERROR\* BICB FAILED  
;LOOP ON SUBTEST OR SETUP LOC. RETURN

3204	011470	012737	177777	015112	MOV	#-1,@#C	
3205	011476	147777	003370	003410	BICB	@B+2,@C+2	
3206	011504	126737	003400	015112	CMPB	A+10,@#C	
3207	011512	001401			BEQ	.+4	
3208	011514	104000			HLT		;
3209	011516	104400			SCOPE		;

;

\*ERROR\* BICB FAILED  
;LOOP ON SUBTEST OR SETUP LOC. RETURN

```

3210
3211
3212
3213
3214
3215

```

\*\*\*\*\*  
:TEST UNARYS INDIRECT WITH INDEXING  
\*\*\*\*\*

3216	011520	012737	177777	015122	MOV	#-1,@#TEMP	
3217	011526	105077	003372		CLRB	@TEMP+2	
3218	011532	105737	015122		TSTB	@#TEMP	
3219	011536	001401			BEQ	.+4	
3220	011540	104000			HLT		;
3221	011542	104400			SCOPE		;

;

\*ERROR\* CLRB FAILED  
;LOOP ON SUBTEST OR SETUP LOC. RETURN

3225	011544	012737	125252	015122	MOV	#125252,@#TEMP	
3226	011552	105177	003346		COMB	@TEMP+2	
3227	011556	122737	052525	015122	CMPB	#052525,@#TEMP	
3228	011564	001401			BEQ	.+4	
3229	011566	104000			HLT		;
3230	011570	104400			SCOPE		;

;

\*ERROR\* COMB FAILED  
;LOOP ON SUBTEST OR SETUP LOC. RETURN

```

3231
3232

```

```

3233
3234 011572 005037 015122 CLR @#TEMP
3235 011576 105277 003322 INCB @TEMP+2
3236 011602 122737 000001 015122 CMPB #1,@#TEMP
3237 011610 001401 BEQ .+4
3238 011612 104000 HLT ;*ERROR* INCB FAILED
3239 011614 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3240
3241
3242

```

```

3243 011616 005037 015122 CLR @#TEMP
3244 011622 105377 003276 DECB @TEMP+2
3245 011626 123727 015122 177777 CMPB @#TEMP,#-1
3246 011634 001401 BEQ .+4
3247 011636 104000 HLT ;*ERROR* DECB FAILED
3248 011640 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3249
3250

```

```

3251
3252 011642 012737 000001 015122 MOV #1,@#TEMP
3253 011650 105477 003250 NEG B @TEMP+2
3254 011654 122737 177777 015122 CMPB #-1,@#TEMP
3255 011662 001401 BEQ .+4
3256 011664 104000 HLT ;*ERROR* NEG B FAILED
3257 011666 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3258
3259

```

```

3260
3261 011670 012737 177777 015122 MOV #-1,@#TEMP
3262 011676 000261 SEC
3263 011700 105577 003220 ADC B @TEMP+2
3264 011704 022737 177400 015122 CMP #177400,@#TEMP
3265 011712 001401 BEQ .+4
3266 011714 104000 HLT ;*ERROR* ADC B FAILED
3267 011716 105737 015122 TST B @#TEMP
3268 011722 001401 BEQ .+4
3269 011724 104000 HLT ;*ERROR* TST B FAILED
3270 011726 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3271
3272

```

```

3273
3274 011730 012737 000001 015122 MOV #1,@#TEMP
3275 011736 000261 SEC
3276 011740 105377 003160 DECB @TEMP+2
3277 011744 005737 015122 TST @#TEMP
3278 011750 001401 BEQ .+4
3279 011752 104000 HLT ;*ERROR* DECB FAILED
3280 011754 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3281
3282

```

```

*****
;TEST OF COMBINED INDEXING AND INDIRECT
*****

```

```

3287
3288 011756 012700 177772 MOV #-6,R0

```

```

3289 011762 127027 015100 125252      CMPB   2A(0),#125252
3290 011770 001401                      BEQ    .+4
3291 011772 104000                      HLT
3292 011774 104400                      SCOPE      ;*ERROR* CMPB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3293
3294
3295
3296 011776 012700 177772      MOV    #-6,RO
3297 012002 122770 125252 015100      CMPB   #125252,2A(0)
3298 012010 001401                      BEQ    .+4
3299 012012 104000                      HLT
3300 012014 104400                      SCOPE      ;*ERROR* CMPB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3301
3302
3303
3304 012016 012700 177772      MOV    #-6,RO
3305 012022 012701 000002      MOV    #+2,R1
3306 012026 127071 015100 015100      CMPB   2A(0),2A(1)
3307 012034 001401                      BEQ    .+4
3308 012036 104000                      HLT
3309 012040 104400                      SCOPE      ;*ERROR* CMPB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3310
3311
3312
3313
3314
3315
3316 012042 012700 000006      MOV    #+6,RO
3317 012046 012767 177777 003046      MOV    #-1,TEMP
3318 012054 147067 015100 003040      BICB   2A(0),TEMP
3319 012062 122767 125252 003032      CMPB   #125252,TEMP
3320 012070 001401                      BEQ    .+4
3321 012072 104000                      HLT
3322 012074 104400                      SCOPE      ;*ERROR* BICB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3323
3324
3325
3326 012076 012700 177772      MOV    #-6,RO
3327 012102 012737 177777 015112      MOV    #-1,2#C
3328 012110 142770 125252 015122      BICB   #125252,2TEMP(0)
3329 012116 123727 015112 000125      CMPB   2#C,#000125
3330 012124 001401                      BEQ    .+4
3331 012126 104000                      HLT
3332 012130 104400                      SCOPE      ;*ERROR* BICB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3333
3334
3335
3336 012132 012700 015072      MOV    #B+2,RO      ;ADDRESS OF ADDRESS OF B
3337 012136 023067 002726      CMP    2(0)+,B
3338 012142 001401                      BEQ    .+4
3339 012144 104000                      HLT
3340 012146 104400                      SCOPE      ;*ERROR* CMP FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3341
3342
3343
3344 012150 012700 015074      MOV    #B+4,RO

```

```

*****
:TEST BIC INSTRUCTION
*****

```

```

3345 012154 025067 002710      CMP      @-(0),B
3346 012160 001401              BEQ      .+4
3347 012162 104000              HLT
3348 012164 104400              SCOPE      ;*ERROR* CMP FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3349
3350
3351
3352 012166 012700 015074      MOV      #B+4,RO
3353 012172 125067 002672      CMPB    @-(0),B
3354 012176 001401              BEQ      .+4
3355 012200 104000              HLT
3356 012202 104400              SCOPE      ;*ERROR* CMPB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3357
3358
3359
3360 012204 012700 015116      MOV      #C+4,RO
3361 012210 012737 177777 015112  MOV      #-1,@#C
3362 012216 105050              CLRB    @-(0)
3363 012220 023727 015112 177400  CMP      @#C,#177400
3364 012226 001401              BEQ      .+4
3365 012230 104000              HLT
3366 012232 104400              SCOPE      ;*ERROR* CLRB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3367
3368
3369 012234 012737 177777 015112  MOV      #-1,@#C
3370 012242 012700 177772              MOV      #-6,RO
3371 012246 012701 177772              MOV      #-6,R1
3372 012252 147071 015100 015122  BICB    @A(0),@TEMP(1)
3373 012260 022737 177525 015112  CMP      #177525,@#C
3374 012266 001401              BEQ      .+4
3375 012270 104000              HLT
3376 012272 104400              SCOPE      ;*ERROR* BICB FAILED
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3377
3378
3379
3380
3381
3382
3383
3384 012274 004767 000002      JSR      PC,TJSR2      ;PLACE PC ON STACK
3385 012300 000405      TJSR1: BR      TJSR3      ;RETURN HERE ON RTS PC
3386 012302 121627 012300      TJSR2: CMPB   @SP,#TJSR1 ;CHECK FOR CORRECT PC ON STACK
3387 012306 001401              BEQ      .+4
3388 012310 104000              HLT
3389 012312 000207              RTS      PC      ;*ERROR* INCORRECT PC ON STACK
3390 012314 104400      TJSR3: SCOPE      ;RETURN TO INST AFTER JSR
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3391
3392
3393
3394 012316 000257      CCC
3395 012320 004717      JSR      PC,@PC      ;INSTRUCTION UNDER TEST
3396 012322 121627 012322      CMPB   @SP,#TJSR3+6 ;TEST THE STACK
3397 012326 001401              BEQ      .+4
3398 012330 104000              HLT
3399 012332 005726      TST     (6)+
3400 012334 104400              SCOPE      ;*ERROR* PC OF JSR DID NOT GO TO STACK
                                           ;REPOSITION THE STACK
                                           ;LOOP ON SUBTEST OR SETUP LOC. RETURN

```

```

*****
;TEST JSR INSTRUCTION
*****

```



3401  
3402  
3403  
3404  
3405  
3406  
3407  
3408  
3409  
3410  
3411  
3412  
3413  
3414  
3415  
3416  
3417  
3418  
3419  
3420  
3421  
3422  
3423  
3424  
3425  
3426  
3427  
3428  
3429  
3430  
3431  
3432  
3433  
3434  
3435  
3436  
3437  
3438  
3439  
3440  
3441  
3442  
3443  
3444  
3445  
3446  
3447  
3448  
3449  
3450  
3451  
3452  
3453  
3454  
3455  
3456

012336 000257  
012340 004767 002622  
012344 100401  
012346 104000  
012350 001401  
012352 104000  
012354 102401  
012356 104000  
012360 103401  
012362 104000  
012364 104400  
  
  
  
  
012366 104400  
  
012370 000257  
012372 012767 123456 002522  
012400 106067 002517  
012404 103401  
012406 104000  
012410 102401  
012412 104000  
012414 022767 051456 002500  
012422 001401  
012424 104000  
012426 104400  
  
  
012430 000277  
012432 012767 123456 002462  
012440 106067 002457  
012444 103401  
012446 104000  
012450 102001  
012452 104000  
012454 022767 151456 002440  
012462 001401  
012464 104000  
012466 104400  
  
  
012470 000257  
012472 012767 123456 002422

\*\*\*\*\*  
:TEST NESTED SUBROUTINES  
\*\*\*\*\*

CCC ;CLEAR CONDITION CODES  
JSR PC, SUBR6  
BMI .+4  
HLT ;\*ERROR\* JSR OR RTS FAILED  
BEQ .+4 ;\*ERROR\* JSR OR RTS FAILED  
HLT ;\*ERROR\* JSR OR RTS FAILED  
BVS .+4 ;\*ERROR\* JSR OR RTS FAILED  
HLT ;\*ERROR\* JSR OR RTS FAILED  
BCS .+4 ;\*ERROR\* JSR OR RTS FAILED  
HLT ;\*ERROR\* JSR OR RTS FAILED  
SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN

\*\*\*\*\*  
:TEST ROTATE ODD BYTE  
\*\*\*\*\*

SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN

CCC ;CLEAR "C"  
MOV #123456, TEMP  
RORB TEMP+1 ;ROTATE ODD BYTE  
BCS .+4  
HLT ;\*ERROR\* C NOT SET  
BVS .+4 ;\*ERROR\* V NOT SET  
HLT  
CMP #051456, TEMP  
BEQ .+4  
HLT ;\*ERROR\* ROTATE FAILED  
SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN

SCC ;SET C  
MOV #123456, TEMP  
RORB TEMP+1  
BCS .+4  
HLT ;\*ERROR\* C NOT SET  
BVC .+4 ;\*ERROR\* V NOT CLEARED  
HLT  
CMP #151456, TEMP  
BEQ .+4  
HLT ;\*ERROR\* ROTATE FAILED  
SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN

CCC  
MOV #123456, TEMP

```

3457 012500 106167 002417      ROLB  TEMP+1
3458 012504 103401             BCS   .+4
3459 012506 104000             HLT                   ;*ERROR* C NOT SET
3460 012510 102401             BVS   .+4
3461 012512 104000             HLT                   ;*ERROR* V NOT SET
3462 012514 022767 047056 002400  CMP   #047056,TEMP
3463 012522 001401             BEQ   .+4
3464 012524 104000             HLT                   ;*ERROR* ROTATE BYTE FAILED
3465 012526 104400             SCOPE                ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3466
3467
3468
3469 012530 000277             SCC
3470 012532 012767 123456 002362  MOV   #123456,TEMP      ;SET C
3471 012540 106167 002357      ROLB  TEMP+1
3472 012544 103401             BCS   .+4
3473 012546 104000             HLT                   ;*ERROR* C NOT SET
3474 012550 102401             BVS   .+4
3475 012552 104000             HLT                   ;*ERROR* V NOT SET
3476 012554 022767 047456 002340  CMP   #047456,TEMP
3477 012562 001401             BEQ   .+4
3478 012564 104000             HLT                   ;*ERROR* ROTATE ODD BYTE FAILED
3479 012566 104400             SCOPE                ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3480
3481
3482
3483
3484
3485

```

```

;*****
;TEST ASL INSTRUCTION MODE 0
;*****

```

```

3486 012570 012700 125252  ASLO:  MOV   #125252,R0      ;SET R0=125252
3487 012574 000277          SCC
3488 012576 006300          ASL   R0                  ;SET R0=52524
3489 012600 103003          BCC  1$                  ;BRANCH IF C FAILED
3490 012602 102002          BVC  1$                  ;BRANCH IF V FAILED
3491 012604 001401          BEQ  1$                  ;BRANCH IF Z FAILED
3492 012606 100001          BPL  .+4                 ;BRANCH IF N OK
3493 012610 104000          1$:  HLT                   ;*ERROR* ASL MODE 0 FLAGS FAILED
3494
3495 012612 020027 052524    CMP   R0,#52524          ;IS ASL RESULT OK?
3496 012616 001401          BEQ   .+4                 ;BRANCH IF YES
3497 012620 104000          HLT                   ;*ERROR* ASL MODE 0 FAILED
3498 012622 104400          SCOPE                ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3499
3500

```

```

;*****
;TEST ASL MODE NON 0 (67)
;*****

```

```

3505 012624 012767 032525 002270  ASL67: MOV   #32525,TEMP      ;TEMP=32525
3506 012632 000257          CCC
3507 012634 006367 002262    ASL   TEMP                ;TEMP=65252
3508 012640 103403          BCS  1$                  ;BRANCH IF C FAILED
3509 012642 102402          BVS  1$                  ;BRANCH IF V FAILED
3510 012644 001401          BEQ  1$                  ;BRANCH IF Z FAILED
3511 012646 100001          BPL  .+4                 ;BRANCH IF N OK
3512 012650 104000          1$:  HLT                   ;*ERROR* ASL MODE 67 FLATS FAILED

```



```

3569 013016 001401 BEQ .+4
3570 013020 104000 HLT
3571 013022 104400 SCOPE ;*ERROR* SHIFT FAILED
3572 ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3573
3574
3575 013024 000277 SCC
3576 013026 012767 177777 002066 MOV #-1,TEMP
3577 013034 106367 002063 ASLB TEMP+1
3578 013040 103401 BCS .+4
3579 013042 104000 HLT ;*ERROR* C NOT SET
3580 013044 102001 BVC .+4
3581 013046 104000 HLT ;*ERROR* V NOT CLEARED
3582 013050 026727 002046 177377 CMP TEMP,#177377
3583 013056 001401 BEQ .+4
3584 013060 104000 HLT ;*ERROR* SHIFT BYTE FAILED
3585 013062 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3586
3613 013064 005037 016212 CLR #ICOUNT ;NO ITERATION

```

```

:*****
:TEST ROTATING NUMBERS
:*****

```

```

3621 013070 012767 177777 000142 MOV #-1,REFF ;INITIALIZE BASE NUMBER
3622 013076 005267 000136 TSROT: INC REFF ;INCREMENT NUMBER
3623 013102 004767 000012 JSR PC,ROTALL ;GO TO COMPARE ROUTINE
3624 013106 026727 000126 100077 CMP REFF,#100077 ;TEST ALL VALUES
3625 013114 001370 BNE TSROT ;NO TEST THEM ALL
3626 013116 000452 BR TSRT2A ;WE ARE DONE
3627
3628 013120 016767 000114 000114 ROTALL: MOV REFF,TEST
3629 013126 006167 000110 ROL TEST
3630 013132 006067 000104 ROR TEST
3631 013136 006067 000100 ROR TEST
3632 013142 006067 000074 ROR TEST
3633 013146 006067 000070 ROR TEST
3634 013152 006167 000064 ROL TEST
3635 013156 006167 000060 ROL TEST
3636 013162 006167 000054 ROL TEST
3637 013166 100004 BPL .+12
(1) 013170 103007 BCC .+20 ;Z=1
(1) 013172 102013 BVC .+30 ;Z=1, C=1
(1) 013174 104000 HLT ;*ERROR* Z=C, BUT V=1
(1) 013176 000411 BR .+24
(1) 013200 103006 BCC .+16 ;Z=0
(1) 013202 102407 BVS .+20 ;Z=0, C=1
(1) 013204 104000 HLT ;*ERROR* Z NOT EQUAL C, V=1
(1) 013206 000405 BR .+14
(1) 013210 102404 BVS .+12 ;Z=1, C=0
(1) 013212 104000 HLT ;*ERROR* Z NOT EQUAL C, V=1
(1) 013214 000402 BR .+6
(1) 013216 102001 BVC .+4 ;Z=0, C=0
(1) 013220 104000 HLT ;*ERROR* Z=C, BUT V=1

```

```

(1) 013222 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
(1)
(1)
3638 013224 026767 000012 000006 CMP TEST,REFF
3639 013232 001401 BEQ .+4
3640 013234 104000 HLT ;*ERROR* INITIAL NOT EQUAL TO FINAL
3641 013236 000207 RTS PC ;ROTATE WORD FAILED
3642 013240 000000 REFF: 0 ;GOOD DATA
3643 013242 000000 TEST: 0 ;BAD DATA
3644 013240 REF=REFF
3645 *****
3646 :TEST ROTATING BYTE EVEN/ODD, ALL NUMBERS
3647 *****
3648
3649 013244 012767 177777 177766 TSRT2A: MOV #-1,REFF
3650 013252 005267 177762 TSROT2: INC REFF
3651 013256 004767 000016 JSR PC,ROTBE
3652 013262 004767 000122 JSR PC,ROTBO
3653 013266 022767 177777 177744 CMP #-1,REFF
3654 013274 001366 BNE TSROT2
3655 013276 000505 BR ROTEN1
3656 013300 016767 177734 177734 ROTBE: MOV REFF,TEST
3657 013306 106067 177730 RORB TEST ;ROTATE BYTE EVEN
3658 013312 106067 177724 RORB TEST
3659 013316 106067 177720 RORB TEST
3660 013322 106167 177714 ROLB TEST
3661 013326 106167 177710 ROLB TEST
3662 013332 106167 177704 ROLB TEST
3663 013336 100004 BPL .+12
(1) 013340 103007 BCC .+20 ;Z=1
(1) 013342 102013 BVC .+30 ;Z=1, C=1
(1) 013344 104000 HLT ;*ERROR* Z=C, BUT V=1
(1) 013346 000411 BR .+24
(1) 013350 103006 BCC .+16 ;Z=0
(1) 013352 102407 BVS .+20 ;Z=0, C=1
(1) 013354 104000 HLT ;*ERROR* Z NOT EQUAL C, V=1
(1) 013356 000405 BR .+14
(1) 013360 102404 BVS .+12 ;Z=1, C=0
(1) 013362 104000 HLT ;*ERROR* Z NOT EQUAL C, V=1
(1) 013364 000402 BR .+6
(1) 013366 102001 BVC .+4 ;Z=0, C=0
(1) 013370 104000 HLT ;*ERROR* Z=C, BUT V=1
(1) 013372 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
(1)
(1)
3664 013374 026767 177642 177636 CMP TEST,REFF ;IS RESULT OK?
3665 013402 001401 BEQ .+4 ;BRANCH IF YES
3666 013404 104000 HLT ;*ERROR* RORB OR ROLB FAILED
3667 013406 000207 RTS PC
3668
3669 013410 106067 177627 ROTBO: RORB TEST+1 ;ROTATE BYTE ODD
3670 013414 106067 177623 RORB TEST+1
3671 013420 106067 177617 RORB TEST+1
3672 013424 106167 177613 ROLB TEST+1
3673 013430 106167 177607 ROLB TEST+1
3674 013434 106167 177603 ROLB TEST+1

```

```

3675 013440 100004 BPL .+12
(1) 013442 103007 BCC .+20 ;Z=1
(1) 013444 102013 BVC .+30 ;Z=1, C=1
(1) 013446 104000 HLT ;*ERROR* Z=C, BUT V=1
(1) 013450 000411 BR .+24
(1) 013452 103006 BCC .+16 ;Z=0
(1) 013454 102407 BVS .+20 ;Z=0, C=1
(1) 013456 104000 HLT ;*ERROR* Z NOT EQUAL C, V=1
(1) 013460 000405 BR .+14
(1) 013462 102404 BVS .+12 ;Z=1, C=0
(1) 013464 104000 HLT ;*ERROR* Z NOT EQUAL C, V=1
(1) 013466 000402 BR .+6
(1) 013470 102001 BVC .+4 ;Z=0, C=0
(1) 013472 104000 HLT ;*ERROR* Z=C, BUT V=1
(1) 013474 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN

```

```

3676 013476 026767 177540 177534 CMP TEST, REFF
3677 013504 001401 BEQ .+4
3678 013506 104000 HLT ;*ERROR* ROTATE BYTE FAILED
3679 013510 000207 RTS PC

```

```

3680
3681
3682
3683
3684
3685 013512 104400 ROTEN1: SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3686
3687

```

```

3688 ;*****
3689 ;TEST MTPS AND MFPS INSTRUCTION MODE 0 ALL 1'S
3690 ;*****
3691
3692 ;DOES NOT TEST INTERRUPT ENABLE.
3693
3694
3695

```

```

3696 013514 012700 000377 MTPSO: MOV #377, RO ;SET SOURCE = 377
3697 013520 106400 MTPS RO ;TEST MTPS 377
3698 013522 103003 BCC 1$ ;BRANCH IF C BIT FAILED
3699 013524 102002 BVC 1$ ;BRANCH IF V BIT FAILED
3700 013526 001001 BNE 1$ ;BRANCH IF Z BIT FAILED
3701 013530 100401 BMI .+4 ;BRANCH IF N BIT OK
3702 013532 104000 1$: HLT ;*ERROR* MTPS MODE 0 1'S FAILED
3703 013534 106700 MFPS RO ;TEST MFPS 377 SIGN EXT
3704 013536 042700 000020 BIC #20, RO ;CLR TBIT IF SET
3705 013542 022700 177757 CMP #177757, RO ;RESULT IS SIGN EXT + NO T BIT
3706 013546 001401 BEQ .+4 ;BRANCH IF RESULT OK.
3707 013550 104000 HLT ;*ERROR* MFPS MODE 0 1'S FAILED
3708
3709 013552 104400 SCOPE ;SAVR0 CONTAINS ERROR PROCESSOR STATUS
3710 ;LOOP ON SUBTEST OR SETUP LOC. RETURN

```

```

3711
3712
3713 ;*****
3714 ;TEST MTPS AND MFPS INSTRUCTION MODE NON 0 (MODE 27)
3715 ;*****
3716
3717
3718
3719

```

```

3734 013554 106427 000000 MTPS27: MTPS #0 ;TEST MTPS 0
3735 013560 103403 BCS 1$ ;BRANCH IF C BIT FAILED
3736 013562 102402 BVS 1$ ;BRANCH IF V BIT FAILED
3737 013564 001401 BEQ 1$ ;BRANCH IF Z BIT FAILED
3738 013566 100001 BPL .+4 ;BRANCH IF N BIT OK
3739 013570 104000 1$: HLT ;*ERROR* MTPS MODE 27 FAILED
3740 013572 012767 000377 001322 MOV #377,TEMP ;INIT TEMP (MFPS IS A BYTE MOVE)
3741 013600 106767 001316 MFPS TEMP ;TEST MFPS 0
3742 013604 042767 000020 001310 BIC #20,TEMP ;CLR TBIT IF SET (DUE TO TBIT PASS)
3743 013612 005767 001304 TST TEMP ;RESULT NO SIGN EXT OR T BIT
3744 013616 001401 BEQ .+4 ;BRANCH IF RESULT OK
3745 013620 104000 HLT ;*ERROR* MFPS MODE 67 FAILED
3746 ;"TEMP" CONTAINS ERROR PROCESSOR STATUS
3747 013622 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3748
3749
3750
3751
3752
3753
3754
3755

```

```

:*****
:TEST SOB INSTRUCTION
:*****

```

```

3756 013624 012701 177776 SOB: MOV #-2,R1 ;LOOP COUNT COMPARE
3757 013630 012700 000002 MOV #2,R0 ;LOOP COUNT FOR SOB
3758 013634 005201 1$: INC R1 ;UPDATE COMPARE COUNT
3759 013636 077002 SOB R0,1$ ;DONE LOOPING?
3760 013640 020001 CMP R0,R1 ;YES-TEST RESULT
3761 013642 001401 BEQ .+4 ;BRANCH IF OK
3762 013644 104000 HLT ;*ERROR* SOB FAILED
3763 013646 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3764
3765
3766
3767
3768

```

```

:*****
:TEST XOR INSTRUCTION MODE 0
:*****

```

```

3769 013650 012700 052525 XOR0: MOV #52525,R0 ;SET SOURCE = 52525
3770 013654 012701 125252 MOV #125252,R1 ;SET DEST = 125252
3771 013660 074001 XOR R0,R1 ;XOR 52525+125252
3772 013662 022701 177777 CMP #177777,R1 ;RESULT = 177777?
3773 013666 001401 BEQ .+4 ;BRANCH IF OK
3774 013670 104000 HLT ;*ERROR* XOR MODE 0 FAILED
3775 013672 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3776
3777
3778
3779
3780

```

```

:*****
:TEST XOR INSTRUCTION MODE NON 0 (MODE 67)
:*****

```

```

3781 013674 005000 XOR67: CLR R0 ;SET SOURCE = 0
3782 013676 005067 001220 CLR TEMP ;SET DEST = 0
3783 013702 074067 001214 XOR R0,TEMP ;XOR 0+0
3784 013706 005767 001210 TST TEMP ;IS RESULT = 0?
3785 013712 001401 BEQ .+4 ;BRANCH IF YES
3786 013714 104000 HLT ;*ERROR* XOR MODE 67 FAILED
3787 013716 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3788
3789
3790

```

```

:*****
:TEST SXT INSTRUCTION MODE 0 SIGN EXTEND 0'S
:*****

```

```

3791                                     ;*****
3792                                     ;*****
3793 013720 012700 177777 SXT00: MOV    #-1,RO      ;SET DEST=177777
3794 013724 000250          CLN                    ;CLEAR N BIT
3795 013726 006700          SXT    RO              ;SIGN EXTEND 0'S
3796 013730 005700          TST    RO              ;IS RESULT = 0?
3797 013732 001401          BEQ    .+4             ;BRANCH IF YES
3798 013734 104000          HLT                    ;*ERROR* SXT MODE 0 0'S FAILED
3799 013736 104400          SCOPE                   ;LOOP ON SUBTEST OR SETUP LOC. RETURN

3814
3829
3830                                     ;*****
3831 ;TEST SXT INSTRUCTION MODE NON 0 SIGN EXTEND 1'S
3832                                     ;*****
3833
3834 013740 005067 001156 SXT61: CLR    TEMP          ;SET DEST = 0
3835 013744 000270          SEN                    ;SET N BIT
3836 013746 006767 001150 SXT    TEMP          ;SIGN EXTEND 1'S
3837 013752 022767 177777 001142 CMP    #-1,TEMP      ;IS RESULT = -1?
3838 013760 001401          BEQ    .+4             ;BRANCH IF YES
3839 013762 104000          HLT                    ;*ERROR* SXT MODE 67 1'S FAILED
3840 013764 104400          SCOPE                   ;LOOP ON SUBTEST OR SETUP LOC. RETURN

3841
3842                                     ;*****
3843 ;TEST MARK INSTRUCTION
3844 ;TESTS SP INCREMENTS CORRECTLY
3845 ;TESTS PC LOADED CORRECT RETURN
3846 ;TESTS R5 LOADED CORRECTLY
3847                                     ;*****
3848
3849 013766 010600 MARK0: MOV    SP,RO      ;SAVE SP FOR COMPARE
3850 013770 012705 000030 MOV    #1$-,-6,R5    ;SET "OLDR5" TO #1$ IN CURRENT BANK
3851 013774 060705          ADD    PC,R5
3852 013776 010537 000536 MOV    R5,#OLDR5    ;SAVE OLDR5 FOR COMPARE
3853 014002 010546          MOV    R5,-(SP)     ;PUSH "OLDR5" ONTO STACK
3854 014004 012746 014042 MOV    #3$,-(SP)    ;PUSH 1 PARAMETER ONTO STACK
3855 014010 012746 006401 MOV    #6401,-(SP)  ;PUSH "MARK 1" INST. ONTO STACK
3856 014014 010605          MOV    SP,R5        ;POINT R5 TO MARK 1 INSTRUCTION
3857 014016 012746 000004 MOV    #2$-,-6,-(SP) ;SETUP GOOD RETURN ADDRESS IN CURRENT BANK
3858 014022 060716          ADD    PC,(SP)
3859 014024 000205          RTS
3860 014026 104000 1$: HLT                    ;DO THE MARK 1 INST. ON THE STACK AND CONT. AT 2$.
                                           ;*ERROR* MARK 1 FAILED
                                           ;RUN BASIC INSTRUCTION TEST TO SAVE YOU GRIEF WITH THIS

3861
3862
3863 014030 020600 2$: CMP    SP,RO      ;WAS SP CORRECTLY RESTORED?
3864 014032 001003          BNE    3$           ;BRANCH IF NO
3865 014034 020537 000536 CMP    R5,#OLDR5    ;WAS R5 CORRECTLY RESTORED (OLDR5)
3866 014040 001404          BEQ    4$           ;BRANCH IF YES
3867 014042 010637 015132 3$: MOV    SP,#MARKSP   ;SAVE FAILURE SP
3868 014046 010006          MOV    RO,SP       ;RESTORE SP
3869 014050 104000          HLT                    ;*ERROR* MARK 1 INST. FAILED
3870 014052 104400 4$: SCOPE                   ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3871

```



```

3873 :*****
3874 :SBTTL EIS /FIS INSTRUCTION TESTS
3875 :*****
3876 014054 032777 000010 001052 BIT #BIT03,ASWR ;EIS/FIS TEST WANTED?
3877 014062 001402 BEQ ASHO ;BRANCH IF YES
3878 014064 000167 000522 JMP MATH ;SKIP EIS/FIS TESTS
3879
3880 :*****
3881 :TEST ASH LEFT SHIFT 00001 BY 16 SETS C.
3882 :*****
3883
3884 014070 012700 000001 ASHO: MOV #1,RO ;INIT DATA=00001
3885 014074 000241 CLC ;C BIT=0
3886 014076 072027 000020 ASH #16.,RO ;SHIFT 00001 LEFT 16.
3887 014102 103001 BCC 1$ ;BRANCH IF C BIT ERROR
3888 014104 001401 BEQ .+4 ;BRANCH IF RESULT 0000
3889 014106 104000 1$: HLT ;*ERROR* ASH LEFT SHIFT FAILED
3890
3891 :*****
3892 :TEST ASH RIGHT SHIFT #100000 BY 16. SETS C.
3893 :*****
3894
3895 014110 012700 100000 ASH1: MOV #100000,RO ;INIT DATA=100000
3896 014114 000241 CLC ;C BIT=0
3897 014116 072027 177760 ASH #-16.,RO ;SHIFT 100000 RIGHT 16
3898 014122 103003 BCC 1$ ;BRANCH IF C BIT ERROR
3899 014124 020027 177777 CMP RO,#177777 ;RESULT OK?
3900 014130 001401 BEQ .+4 ;BRANCH IF YES
3901 014132 104000 1$: HLT ;*ERROR* ASH RIGHT SHIFT FAILED
3902 014134 104400 SCOPE ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3903
3904 :*****
3905 :TEST ASHC LEFT SHIFT 0000,0002 BY 31 SETS C.
3906 :*****
3907
3908 014136 005000 ASHCO: CLR RO ;HIGH ORDER=0 (C BIT=0)
3909 014140 012701 000002 MOV #2,R1 ;LOW ORDER=2
3910 014144 073027 000037 ASHC #31.,RO ;LEFT SHIFT 0002 BY 31
3911 014150 103001 BCC 1$ ;BRANCH IF C BIT ERROR
3912 014152 001401 BEQ .+4 ;BRANCH IF RESULT=0
3913 014154 104000 1$: HLT ;*ERROR* ASHC LEFT SHIFT FAILED
3914
3915 :*****
3916 :TEST ASHC RIGHT SHIFT 100000,000000 BY 32 SETS C
3917 :*****
3918
3919 014156 012700 100000 ASHC1: MOV #100000,RO ;HIGH ORDER=100000
3920 014162 005001 CLR R1 ;LOW ORDER=0 (C BIT=0)
3921 014164 073027 000040 ASHC #32.,RO ;RIGHT SHIFT 100000,0 BY 32
3922 014170 103001 BCC 1$ ;BRANCH IF C BIT ERROR
3923 014172 100401 BMI .+4 ;BRANCH IF N BIT OK
3924 014174 104000 1$: HLT ;*ERROR* ASHC C OR N BIT FAILED
3925 014176 022701 177777 CMP #-1,R1 ;LOW ORDER RESULT OK?
3926 014202 001003 BNE 2$ ;BRANCH IF NO
3927 014204 022700 177777 CMP #-1,RO ;HIGH ORDER RESULT OK?
3928 014210 001401 BEQ .+4 ;BRANCH IF YES

```

```

3929 014212 104000      2$:      HLT                ;*ERROR* ASHC RIGHT SHIFT FAILED
3930 014214 104400      SCOPE                ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3931
3932 ;*****
3933 ;TEST MUL INSTRUCTION ALT 1'S
3934 ;*****
3935
3936 ;      125252*40000=165252,100000
3937
3938 014216 012700 125252  MULO:  MOV      #125252,R0      ;INIT MULTIPLICAND
3939 014222 070027 040000  MUL      #40000,R0          ;R1:R0=40000*125252
3940 014226 100003      BPL      1$                ;BRANCH IF N BIT ERROR
3941 014230 102402      BVS      1$                ;BRANCH IF V BIT ERROR
3942 014232 001401      BEQ      1$                ;BRANCH IF Z BIT ERROR
3943 014234 103401      BCS      .+4              ;BRANCH IF C BIT OK
3944 014236 104000      1$:      HLT                ;*ERROR* MUL FLAGS FAILED
3945 014240 022700 165252  CMP      #165252,R0        ;HIGH ORDER RESULT OK?
3946 014244 001003      BNE      2$                ;BRANCH IF NO
3947 014246 022701 100000  CMP      #100000,R1        ;LOW ORDER RESULT OK?
3948 014252 001401      BEQ      .+4              ;BRANCH IF YES
3949 014254 104000      2$:      HLT                ;*ERROR* MUL FAILED
3950 014256 104400      SCOPE                ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3951
3952 ;*****
3953 ;TEST DIV INSTRUCTION ALT 1'S
3954 ;*****
3955
3956 014260 012701 125252  DIVO:  MOV      #125252,R1    ;LOW ORDER DIVIDEND
3957 014264 012700 177777  MOV      #-1,R0            ;HIGH ORDER DIVIDEND
3958 014270 000261      SEC                        ;C BIT=1
3959 014272 071027 000002  DIV      #2,R0             ;R1:R0=177777,125252/2
3960 014276 103403      BCS      1$                ;BRANCH IF C BIT ERROR
3961 014300 102402      BVS      1$                ;BRANCH IF V BIT ERROR
3962 014302 001401      BEQ      1$                ;BRANCH IF Z BIT ERROR
3963 014304 100401      BMI      .+4              ;BRANCH IF N BIT OK
3964 014306 104000      1$:      HLT                ;*ERROR* DIV FLAGS FAILED
3965 014310 005701      TST      R1                ;LOW ORDER RESULT OK?
3966 014312 001003      BNE      2$                ;BRANCH IF NO
3967 014314 020027 152525  CMP      R0,#152525        ;LOW ORDER RESULT OK?
3968 014320 001401      BEQ      .+4              ;BRANCH IF YES
3969 014322 104000      2$:      HLT                ;*ERROR* DIV FAILED
3970 014324 104400      SCOPE                ;LOOP ON SUBTEST OR SETUP LOC. RETURN
3971

```

3973  
3974  
3975  
3976  
3977  
3978  
3979  
3980  
3981  
3982  
3983  
3984  
3985  
3986  
3987  
3988  
3989  
3990  
3991  
3992  
3993  
3994  
3995  
3996  
3997  
3998  
3999  
4000  
4001  
4002  
4003  
4004  
4005  
4006  
4007  
4008  
4009  
4010  
4011  
4012  
4013  
4014  
4015  
4016  
4017  
4018  
4019  
4020  
4021  
4022  
4023  
4024  
4025  
4026  
4027  
4028

014326 012701 014612  
014332 005041  
014334 012741 071600  
014340 012741 177777  
014344 012741 077577  
014350 000262  
014352 000261  
014354 075001  
014356 100403  
014360 001402  
014362 102401  
014364 103001  
014366 104000  
014370 022737 077600 014606  
014376 001003  
014400 005737 014610  
014404 001401  
014406 104000  
014410 104400  
  
014412 012701 014612  
014416 012700 125253  
014422 010041  
014424 005300  
014426 010041

```
*****
;FIS BASIC INSTRUCTION TESTS
;FADD, FSUB, FMUL, FDIV

;TEST FADD INSTRUCTION

;THE TEST ADDS TWO NUMBERS THAT HAVE EXPONENTS 27 APART,
;WHICH IS THE LARGEST DIFFERENCE ALLOWED.

;      71600,000000 + 77577,177777= 77600,000000
;OR IN ENGLISH (INCLUDES HIDDEN NORMALIZE BIT)
;      .1 E350 + .577777777 E377=.1 E351

;CC=0000
;NOTE: THE FIS FLOATING STACK IS ALWAYS IN BANK 0
*****
```

```
FADD0:  MOV    #FSTACK+10,R1    ;INIT FLOATING STACK
        CLR    -(R1)           ;INIT LOW ARGUMENT A
        MOV    #71600,-(R1)    ;INIT HIGH ARGUMENT A
        MOV    #-1,-(R1)      ;INIT LOW ARGUMENT B
        MOV    #77577,-(R1)   ;INIT HIGH ARGUMENT B
        SEV
        SEC
        FADD   R1              ;ADD NO.S IN HEADING
        BMI   1$              ;N BIT=0
        BEQ   1$              ;Z BIT=0
        BVS   1$              ;V BIT=0
        BCC   .+4             ;C BIT=0
1$:      HLT
        CMP    #77600,@#HIGHA ;*ERROR* FADD STATUS FAILED
        BNE   2$              ;HIGH ANSWER OK?
        TST   @#LOWA          ;BRANCH IF NO
        BEQ   .+4             ;LOW ORDER ANSWER OK?
2$:      HLT
        SCOPE                  ;BRANCH IF YES
                                   ;*ERROR* FADD FAILED
                                   ;LOOP ON SUBTEST OR SETUP LOC. RETURN
```

```
*****
;TEST FSUB INSTRUCTION

;      FSUB MICROCODE IS SAME AS FADD EXCEPT FOR 1 LOCATION.
;THIS TEST WILL TEST MORE FADD MICROCODE BY MAKING ARGUMENT A 1
;GREATER THAN ARGUMENT B.

;      125252,125253-125252,125252=117400,000000
;CC=1000 (NOT TESTED)
;NOTE: THE FIS FLOATING STACK IS ALWAYS IN BANK 0
*****
```

```
FSUB0:  MOV    #FSTACK+10,R1    ;INIT FLOATING STACK
        MOV    #125253,R0      ;INIT HIGH ARGUMENT A
        MOV    R0,-(R1)        ;LOW ARGUMENT A=125253
        DEC   R0
        MOV    R0,-(R1)        ;HIGH ARGUMENT A=125252
```

4029	014430	010041			MOV	RO,-(R1)	;LOW ARGUMENT B=125252
4030	014432	010041			MOV	RO,-(R1)	;HIGH ARGUMENT B=125252
4031	014434	075011			FSUB	R1	;SUBTRACT NO.S IN HEADING
4032	014436	022737	117400	014606	CMP	#117400,2#HIGHA	;HIGH ANSWER OK?
4033	014444	001003			BNE	1\$	;BRANCH IF NO
4034	014446	005737	014610		TST	2#LOWA	;LOW ANSWER OK
4035	014452	001401			SEQ	+.4	;BRANCH IF YES
4036	014454	104000			HLT		;*ERROR* FSUB FAILED
4037	014456	104400			SCOPE		;LOOP ON SUBTEST OR SETUP LOC. RETURN

1\$:  
 ;\*\*\*\*\*  
 ;TEST FMUL INSTRUCTION

;TESTS SLOW MULTIPLY MICROCODE

; 161616,161616\*000052,125252=000000,000000  
 ;CC=0100 (NOT TESTED)  
 ;NOTE; THE FIS FLOATING STACK IS ALWAYS IN BANK 0  
 ;\*\*\*\*\*

4052	014460	012701	014612		FMULG: MOV	#FSTACK+10,R1	;INIT FLOATING STACK
4053	014464	012741	161616		MOV	#161616,-(R1)	;LOW ARGUMENT A=161616
4054	014470	012741	161616		MOV	#161616,-(R1)	;HIGH ARGUMENT A=161616
4055	014474	012741	125252		MOV	#125252,-(R1)	;LOW ARGUMENT B=125252
4056	014500	012741	000052		MOV	#000052,-(R1)	;HIGH ARGUMENT B=000052
4057	014504	075021			FMUL	R1	;FMUL NO.S IN HEADING
4058	014506	005737	014606		TST	2#HIGHA	;HIGH ANSWER OK?
4059	014512	001003			BNE	1\$	;BRANCH IF NO
4060	014514	005737	014610		TST	2#LOWA	;LOW ANSWER OK?
4061	014520	001401			BEQ	+.4	;BRANCH IF YES
4062	014522	104000			HLT		;*ERROR* FMUL FAILED
4063	014524	104400			SCOPE		;LOOP ON SUBTEST OR SETUP LOC. RETURN

1\$:  
 ;\*\*\*\*\*  
 ;TEST FDIV INSTRUCTION

; 167452,125252/027652,125253=177777,177777  
 ;CC=1000 (NOT TESTED)  
 ;NOTE; THE FIS FLOATING STACK IS ALWAYS IN BANK 0  
 ;\*\*\*\*\*

4077	014526	012701	014612		FDIV0: MOV	#FSTACK+10,R1	;INIT FLOATING STACK
4078	014532	012741	125252		MOV	#125252,-(R1)	;LOW ARGUMENT A=125252
4079	014536	012741	167452		MOV	#167452,-(R1)	;HIGH ARGUMENT A=167452
4080	014542	012741	125253		MOV	#125253,-(R1)	;LOW ARGUMENT B=125253
4081	014546	012741	027652		MOV	#027652,-(R1)	;HIGH ARGUMENT B=027652
4082	014552	075031			FDIV	R1	;DIVIDES NO.S IN HEADING
4083	014554	022737	177777	014606	CMP	#-1,2#HIGHA	;HIGH ANSWER OK?
4084	014562	001004			BNE	1\$	;BRANCH IF NO
4085	014564	022737	177777	014610	CMP	#-1,2#LOWA	;LOW ANSWER OK?
4086	014572	001401			BEQ	+.4	;BRANCH IF YES
4087	014574	104000			HLT		;*ERROR* FDIV FAILED
4088	014576	104400			SCOPE		;LOOP ON SUBTEST OR SETUP LOC. RETURN
4089	014600	000404			BR	MATH	;SKIP OVER FLOATING STACK

4091  
4092  
4093  
4094  
4095 014602 000000  
4096 014604 000000  
4097 014606 000000  
4098 014610 000000  
4099  
4100  
4101  
4102  
4103  
4104  
4105  
4106  
4107  
4108  
4109  
4110  
4111  
4112  
4113  
4114  
4115  
4116  
4117  
4118  
4119  
4120  
4121  
4122  
4123 014612 012737 000001 016212  
4124 014620 012700 000177  
4125 014624 012704 000001  
4126 014630 012705 010000  
4127  
4128 014634 162700 000177  
4129  
4130 014640 010001  
4131 014642 005201  
4132 014644 005201  
4133 014646 005201  
4134 014650 005201  
4135 014652 005201  
4136 014654 005201  
4137 014656 005201  
4138 014660 005201  
4139 014662 005301  
4140 014664 005301  
4141 014666 005301  
4142 014670 005301  
4143 014672 005301  
4144 014674 005301  
4145 014676 005301  
4146 014700 005301

```

;*FLOATING ARGUMENT STACK
;*THIS STACK IS ALWAYS IN MEMORY BANK 0
FSTACK: .WORD 0 ;HIGH ARGUMENT B
         .WORD 0 ;LOW ARGUMENT B
HIGHA:  .WORD 0 ;HIGH ARGUMENT A + RESULT
LOWA:   .WORD 0 ;LOW ARGUMENT A + RESULT

```

```

*****
:MATH
      A TEST OF THE COMPLEMENTING ARITHMETIC INSTRUCTIONS.
      E.G. INC-DEC, NEG-COM-INC, ADC-SBC, ADD-SUB, ASR-ASL
      THE TEST WILL LOOP 10000 OCTAL TIMES REGARDLESS IF
      ITERATION IS ENABLED OR DISABLED.

```

```

:REGISTER USAGE
      R0= CONTAINS THE BASE NO. USED IN THE TESTING.
      R1= WORKING REGISTER FOR MOST ARITHMETIC INSTRUCTIONS TESTED.
      R2= NOT USED (RESERVED FOR FLOPPY TEST)
      R3= USED IN ASL/ASR TEST
      R4= 1
      R5= 10000 ;PASS COUNT
*****

```

```

MATH:  MOV #1,2#ICOUNT ;DISABLE SR ITERATIONS
        MOV #177,R0 ;INIT BASE DATA
        MOV #1,R4 ;SET R4=00001
        MOV #10000,R5 ;SETUP NO. OF ITERATIONS.

MATHLP: SUB #177,R0 ;R0=R0-177 (FIRST TIME=0)

1$:    MOV R0,R1
        INC R1 ;R1=R1+1
        INC R1
        INC R1
        INC R1
        INC R1
        INC R1
        INC R1
        INC R1 ;R1=R1+10
        DEC R1 ;R1=R1-1
        DEC R1
        DEC R1
        DEC R1
        DEC R1
        DEC R1
        DEC R1 ;R1=R1-10

```

```

4147 014702 020100      CMP      R1,R0      ;R1 RESTORED OK?
4148 014704 001401      BEQ      .+4        ;BRANCH IF YES
4149 014706 104000      HLT                      ;*ERROR* INC OR DEC FAILED
4150
4151 014710 005401      NEG      R1
4152 014712 005101      COM      R1          ;SIMULATE NEG R1
4153 014714 005201      INC      R1          ;SIMULATE NEG R1
4154 014716 020100      CMP      R1,R0      ;R1 RESTORED FROM NEGATE?
4155 014720 001401      BEQ      .+4        ;BRANCH IF YES
4156 014722 104000      HLT                      ;*ERROR* NEG OR COM FAILED
4157 014724 000261      SEC
4158 014726 005501      ADC      R1          ;SET C BIT
4159 014730 000261      SEC          ;ADD C BIT TO R1
4160 014732 005601      SBC      R1
4161 014734 020100      CMP      R1,R0      ;SUBTRACT C BIT FROM R1
4162 014736 001401      BEQ      .+4        ;R1 RESTORED CORRECTLY?
4163 014740 104000      HLT                      ;BRANCH IF YES
4164
4165 014742 060001      ADD      R0,R1      ;*ERROR* ADC OR SBC FAILED
4166 014744 160001      SUB      R0,R1      ;R1=R1+R0
4167 014746 020100      CMP      R1,R0      ;R1=R1-R0
4168 014750 001401      BEQ      .+4        ;R1 RESTORED CORRECTLY?
4169 014752 104000      HLT                      ;BRANCH IF YES
4170
4171 014754 010103      MOV      R1,R3
4172 014756 006203      ASR      R3          ;TEST ASR/ASL
4173 014760 006303      ASL      R3          ;SHIFT R3 RIGHT 1
4174 014762 040401      BIC      R4,R1      ;SHIFT R3 LEFT 1
4175 014764 020103      CMP      R1,R3      ;CLEAR BIT 00
4176 014766 001401      BEQ      .+4        ;R3 RESTORED CORRECTLY?
4177 014770 104000      HLT                      ;BRANCH IF YES
4178 014772 077560      SOB      R5,MATHLP   ;*ERROR* ASR OR ASL FAILED
4179
4180 014774 104400      MATHND: SCOPE          ;REPEAT TEST
4181
4182
4183
4184
4185
4186
4187
4188
4189
4190
4191
4192
4193
4194
4195
4196
4197
4198
4199
4200
4201
4202
4203
4204
4205
4206
4207
4208
4209
4210
4211
4212
4213
4214
4215
4216
4217
4218
4219
4220
4221
4222
4223
4224
4225
4226
4227
4228
4229
4230
4231 014776 005737 016330      TST      @#PWRFLG    ;SET ON POWER FAIL
4232 015002 001404          BEQ      WAITS        ;SKIP OVER IF CLEAR
4233 015004 005037 016330      CLR      @#PWRFLG
4234 015010 000137 000666      JMP      @#ESTART    ;POWER FAIL OCCURRED SO RESTART
4235
4236          .SBTTL IF T BIT PASS SKIP INTERRUPT OUT OF WAIT TEST
4237
4238 015014 005737 015532      WAITS:   TST      @#TRPB    ;IS THIS A T BIT PASS?
4239 015020 100422          BMI      WAITX        ;BRANCH IF YES
4240
4241
4242 015022 012737 000010 016212      MOV      #10,@#ICOUNT
4243
4244
4245
4246
4247
4248
4249
4250
4251
4252
4253
4254
4255
4256
4257
4258
4259
4260
4261
4262
4263
4264
4265
4266
4267
4268
4269
4270
4271
4272
4273
4274
4275
4276
4277
4278
4279
4280
4281
4282
4283
4284
4285
4286
4287
4288
4289
4290
4291
4292
4293
4294
4295

```

```

4296                                     ;*****
4297                                     ;*****
4298 015030 017701 000100 WAITST: MOV    @SWR,R1      ;GET SWITCH SETTINGS.
4299 015034 042701 000230      BIC    #CWAIT,R1    ;CLEAR UNUSED BITS AND PLU/EIS BITS
4300 015040 122701 177547      CMPB   #ICWAIT,R1   ;SELECTED DEVICES STORED IN SWREG
4301 015044 001404      BEQ    WAIT4      ;BRANCH IF NO DEVICES SELECTED
4302 015046 000001      WAIT      ;INTERRUPTS WILL OCCUR
4303 015050 000001      WAIT      ;IF DEVICES ARE SELECTED
4304 015052 000001      WAIT
4305 015054 000001      WAIT
4306 015056 104400 WAIT4:  SCOPE      ;LOOP ON SUBTEST OR SETUP LOC. RETURN
4307 015060 012737 001000 016212 MOV    #1000,@#ICOUNT ;RESET ITERATION COUNTER
4308 015066 000442 WAITX:  BR     EAESRT  ;SKIP OVER STORAGE AREA
4309
4310
4311                                     ;*****
4312 .SBTTL BACKGROUND INSTRUCTION TEST TEMP STORAGE AND CONSTANTS
4313                                     ;*****
4314
4315
4375
4376 015070 125252 B:      125252
4377 015072 015070      B          ;ADDRESS OF B
4378 015074 052525      052525
4379
4380      .=B+10
4381 015100 177777 A:      -1
4382 015102 015104      A+4
4383
4384      .=A+4
4385 015104 125252      125252
4386 015106 015110      A+10      ;ADDRESS OF A+10
4387 015110 052525      052525
4388      ;FOR STORAGE
4389 015112 000000 C:      0
4390 015114 015112      C          ;ADDRESS OF C
4391
4392      .=C+10
4393 015122 000000 TEMP:  0
4394 015124 015122      TEMP      ;ADDRESS OF TEMP
4395
4396      .=TEMP+6
4397 015130 015132      TEMP+10    ;ADDRESS OF TEMP+10 OR "D"
4398 015132
4399 015132 000000 MARKSP:
4400 D:      0
4401      ;SWR MUST BE HERE SO IT CAN BE RELOCATED
4402
4403 015134 177570 SWR:    177570      ;CHANGES TO 176 IF NO HARDWARE SR PRESENT
4404
4405
4406
4407      ;GROUP OF NESTED SUBROUTINES FOR JSR TESTING
4408
4409 015136 000207 SUBR1:  RTS    PC      ; ONE INSTRUCTION
4410 015140 000277 SUBR2:  SCC

```

```

4411 015142 000205          RTS      R5          ;ONE SUBROUTINE LEVELS
4412 015144 004537 015140  SUBR3: JSR      R5, @#SUBR2 ;TWO SUBROUTINE LEVELS
4413 015150 000204          RTS      R4
4414 015152 004467 177766  SUBR4: JSR      R4, SUBR3  ;THREE SUBROUTINE LEVELS
4415 015156 000203          RTS      R3
4416 015160 004367 177766  SUBR5: JSR      R3, SUBR4  ;FOUR SUBROUTINE LEVELS
4417 015164 000200          RTS      R0
4418 015166 004067 177766  SUBR6: JSR      R0, SUBR5  ;FIVE SUBROUTINE LEVELS
4419 015172 000207          RTS      PC          ;AND EXIT

4420
4421
4422 015174 012737 016232 000024 EAESRT: MOV      #PFAIL, @#24 ;SETUP PWR FAIL VECTOR
4423 015202 012737 000340 000026  MOV      #340, @#26
4424
4425 ;IF RELOCATION ENABLED THEN TRPA IS MODIFIED IN THE UPPER BANKS.
4426 ;FOR EXAMPLE IF 12K UNDER TEST THEN TRPA+20000=JMP @#BEGIN+40000
4427 ;AND TRPA+4000=JMP @#BANK0
4428 015210 000137 015214  TRPA:  JMP      @#BANK0 ;SEE NOTE ABOVE
4429 015214  ENDREL: ;LAST RELOCATED LOCATION
4430
4431
4432 ;*****
4433 ;SBTTL ***END RELOCATED INSTRUCTION TESTS ***
4434 ;ENABL AMA
4435 ;SBTTL
4436 ;*****
4437
4438
4439
4440
4441
4442 ;*****
4443 ;SBTTL INCREMENT PASS COUNT AND PRINT END OF PASS DATA
4444 ;*****
4445
4446 015214 005237 000574          BANK0: INC      PASSN1 ;INCR INST PASS COUNTER
4447 015220 023737 000576 000574  CMP      PASSNO, PASSN1 ;TIME TO INCR PRINTED PASS COUNT?
4448 015226 103063          BHS      YESTR      ;BRANCH IF NO
4449
4450 ;CHECK THAT RX AND PLU MADE A PASS
4451
4452 015230 005037 000532          CLR      RETURN ;IN CASE OF ERROR HALT
4453 015234 017700 177674          MOV      @SWR, R0 ;GET DEVICES INHIBITED
4454 015240 005100          COM      R0 ;MAKE ENABLES FOR CHECK
4455 015242 042700 177754          BIC      @ICCHECKM, R0 ;CLEAR UNWANTED BITS
4456 015246 043700 000530          BIC      CHECK, R0 ;CLEAR BITS OF DEVICES THAT PASSED
4457 015252 001401          BEQ      .+4 ;BRANCH IF DEVICES SELECTED PASSED.
4458 015254 104000          HLT ;*ERROR* PLU SELECTED BUT DID NOT MAKE A PASS
4459 ;POSSIBLE CAUSES:
4460 ;FLOPPY FAILED TO INTERRUPT
4461 ;PLU TEST CABLE NOT INSTALLED.
4462 015256 005237 000524          INC      PASS ;INCREMENT TOTAL PASS COUNTER.
4463 015262 005037 000574          CLR      PASSN1 ;INIT RUNNING PASS COUNT
4464
4465 ;*****
4466 ;PRINT PASS=XXXX ERROR=XXXX RXERROR=XXXX TIME=XXXX
4467 ;*****

```



```

4467
4468 015266 105777 177642      ENDPAS: TSTB   JSWR      ;END OF PASS PRINTOUT WANTED?
4469 015272 100441              BMI     YESTR      ;BRANCH IF NO
4471 015274 106700              MFPS   RO         ;SAVE CURRENT STATUS
4472 015276 106427 000340      MTPS   #340       ;LOCK OUT INT.
4474
4479 015302 104001 017162      TYPE   PAS        ;TYPE "PASS="
4480 015306 013703 000524      MOV    PASS,R3    ;GET PASS COUNT
4481 015312 004737 016012      JSR    PC,TYPOCT  ;PRINT PASS COUNT IN OCTAL
4482 015316 104001 017171      TYPE   ERR        ;TYPE "ERROR="
4483 015322 013703 000526      MOV    ERROR,R3   ;GET ERROR COUNT
4484 015326 004737 016012      JSR    PC,TYPOCT  ;TYPE ERROR COUNT
4485 015332 104001 017150      TYPE   RXS        ;TYPE "RXERROR="
4486 015336 013703 000516      MOV    RXSOFT,R3  ;GET RX SOFT ERROR COUNT
4487 015342 004737 016012      JSR    PC,TYPOCT  ;TYPE RXSOFT ERROR COUNT
4488 015346 104001 017201      TYPE   FTIM       ;TYPE "TIME="
4489 015352 013703 003576      MOV    TIME,R3    ;GET CLOCK TIME
4490 015356 004737 016012      JSR    PC,TYPOCT  ;TYPE TIME IN OCTAL
4491 015362 104001 017146      TYPE   ,CR        ;TYPE CRLF
4492
4494 015366 106400              MTPS   RO         ;RESTORE PROC. STATUS
4496
4500 015370 005037 002130      CLR    TPBDAT     ;INIT CONSOLE DATA FOR CLEAN RESTART
4501 015374 000414              BR     CLRTBT     ;CLR TBIT IF SET AND RESTART
4502
4503 ;*****
4504 ;SBTTL TEST FOR T BIT TRAP SETUP
4505 ;*****
4506
4507 015376 005737 015532      YESTR: TST     TRPB   ;PREVIOUS PASS WITH T BIT?
4508              BEQ     CLRTBT ;TRPB IS ALSO END OF RELOCATION TEST PASS FLAG.
4509 015402 001411              BEQ     CLRTBT ;BRANCH IF NO
4510
4511 015404 032777 001000 177522 1$:  BIT     #BIT09,JSWR ;RELOCATION ENABLED?
4512 015412 001005              BNE    CLRTBT    ;BRANCH IF NO
4513 015414 005737 000540      TST    #CHAIN    ;RXDP CHAIN MODE?
4514 015420 001002              BNE    CLRTBT    ;BRANCH IF YES (NO RELOCATION TEST)
4515 015422 000137 023600      JMP    #BEGIN+20000 ;START INSTRUCTION TEST IN BANK1
4516
4517 015426 005016              CLRTBT: CLR    (SP) ;SETUP STACK FOR POSSIBLE TBIT PASS
4518 015430 005137 015532      COM    TRPB      ;SET T BIT SWITCH EVERY OTHER PASS
4519 015434 032777 010000 177472      BIT    #BIT12,JSWR ;T BIT TRAP TEST WANTED
4520 015442 001015              BNE    LINKER    ;BRANCH IF NO
4521 015444 012737 015534 000014      MOV    #YESRT,#14 ;SETUP T BIT TRAP VECTOR
4522 015452 005037 000016      CLR    #16       ;CLR TBIT BUT ALLOW INTERRUPTS
4523 015456 005737 015532      TST    TRPB      ;T BIT TEST NEXT PASS?
4524 015462 100005              BPL    LINKER    ;BRANCH IF NO
4525 015464 012716 000020      MOV    #20,(SP)  ;SET T BIT ON STACK
4526 015470 012746 003600      YESTR1: MOV   #BEGIN,-(6) ;RESTART TEST
4527 015474 000002              RTI           ;GOTO BEGIN VIA RTI
4528
4529 ;*****
4530 ;SBTTL ACT11 END OF PASS ROUTINE
4531 ;*****
4532
4533 015476 105737 000042      LINKER: TSTB   #42   ;SHOULD PROGRAM GO TO MONITOR

```

```

4534 015502 001772          BEQ      YESTR1      ;BRANCH IF NO ACT11 (REPEAT PROCESSOR TEST)
4535 015504 012737 000016 000014  MOV      #16, #14    ;LOAD T BIT TRAP VECTOR
4536 015512 013700 000042          ACT:  MOV      #42, R0    ;GO TO MONITOR OR ACT11 SYSTEM
4537 015516 004710          SENDAD: JSR      PC, (R0) ;RETURN TO ACT11
4538 015520 000240          NOP                      ;IF QUICK VERIFY=RESET ELSE NOP
4539 015522 000240          NOP                      ;IF QUICK VERIFY=CLR #-1 ELSE INC #0
4540 015524 000240          NOP                      ;IF QUICK VERIFY=BR .-4 ELSE NOP
4541 015526 000137 000666          JMP      #ESTART    ;REPEAT TEST UNDER ACT11
4542 015532 000000          TRPB:  0
4543 015534 000006          YESRT: RTT
4544 015536 000000          HALT

```

```

:*****
:SBTTL ***MESSAGE/ERROR SERVICE SUBROUTINES***

```

```

:HLTMES- ENTERED IF HLT OR TYPE TRAP
:      DECODES HLT OR TYPE AND GOES TO APPRO. ROUTINE
:*****

```

```

4554 015540 010137 000552  HLTMES: MOV      R1, SAVR1    ;SAVE R1
4555 015544 010037 000550      MOV      R0, SAVR0    ;SAVE R0
4556 015550 011601          MOV      (SP), R1     ;POINT R1 TO TRAP CALL
4557 015552 005741          TST      -(R1)        ;POINT R1 TO TRAP PC
4558 015554 011100          MOV      (R1), R0     ;GET TRAP CALL
4559 015556 006000          ROR      R0           ;IF BIT 0 THEN TYPE CALL.
4560 015560 103467          BCS      MES          ;BRANCH IF TYPE TRAP CALL
4561 015562 013700 000550      MOV      SAVR0, R0    ;RESTORE R0
4562 015566 013701 000552      MOV      SAVR1, R1    ;RESTORE R1

```

```

:*****
:PRINT PC=XXXX PSW=XXXX LOOP=XXXX
:*****

```

```

4568 015572 005237 000526  PERROR: INC      ERROR      ;ERROR COUNT LOCATION
4569 015576 037727 177332 020000  BIT      #SWR, #20000 ;INHIBIT ERROR PRINTOUT?
4570 015604 001036          BNE      1$          ;BRANCH IF NO
4571 015606 010637 000564          MOV      SP, SAVSP   ;SAVE SP FOR POSTERITY
4572 015612 062737 000004 000564  ADD      #4, #SAVSP   ;MAKE SP WHAT IT WAS AT TIME OF ERROR
4573 015620 012637 000566          MOV      (6)+, SAVPC ;PC OF FAILING ROUTINE
4574 015624 012637 000570          MOV      (6)+, SAVPS ;CC OF ERROR CONDITION
4575 015630 024646          CMP      -(6), -(6)  ;REPOSITION THE STACK
4576 015632 104001 017111          TYPE    PCE         ;TYPE "PC="
4577 015636 013703 000566          MOV      SAVPC, R3
4578 015642 004737 016012          JSR      PC, TYPOCT  ;PRINT OCTAL NUMBER
4579 015646 104001 017116          TYPE    CCE         ;TYPE "CC="
4580 015652 013703 000570          MOV      SAVPS, R3
4581 015656 004737 016012          JSR      PC, TYPOCT  ;PRINT OCTAL NUMBER
4582 015662 104001 017135          TYPE    SCPE        ;TYPE "LOOP="
4583 015666 013703 000532          MOV      RETURN, R3  ;SCOPE LOOP BEGIN ADDRESS
4584 015672 004737 016012          JSR      PC, TYPOCT
4585 015676 104001 017146          TYPE    CR          ;CALF
4586 015702 005777 177226          1$:  TST      #SWR      ;USER WANT HALT ON ERROR?
4587 015706 100404          BMI     2$          ;BRANCH IF YES
4588 015710 023727 000042 015516  CMP      #42, #SENDAD ;ACT 11 AUTO MODE?
4589 015716 001001          BNE     .+4         ;BRANCH IF NO (DON'T HALT ON ERROR)

```

```

4590 015720 000000      2$:   HALT                ;*NORMAL HALT* HALT ON ERROR SWITCH SET
4591
4592 015722 032777 000400 177204      BIT      #400,DSWR      ;USER WANT RESTART ON ERROR?
4593 015730 001402      BEQ      3$             ;BRANCH IF NO
4594 015732 000137 000666      JMP      ESTART        ;RESTART ON ERROR
4595 015736 000002      3$:   RTI                ;RETURN TO MAIN LINE PROCESSOR TEST
4596
4597
4598
4599

```

```

4600      ;*****
4601      ;TYPE- TRAP CALL SERVICE ROUTINE
4602      ;      COME HERE FROM HLTMES ROUTINE.
4603      ;REGISTERS USED:
4604      ;      R0- HOLDS CHAR
4605      ;      R1- POINTS TO BUFFER
4606      ;NOTE; R0 AND R1 ARE RESTORED HERE AND WERE SAVED IN HLTMES
4607      ;*****

```

```

4608 015740 005721      MES:   TST      (R1)+      ;POINT TO MESSAGE BUFFER ADDRESS
4609 015742 011101      MOV      (R1),R1        ;POINT R1 TO MESSAGE BUFFER
4610 015744 112100      1$:   MOVB     (R1)+,R0    ;GET A CHAR FROM BUFFER.
4611 015746 001412      BEQ      3$             ;BRANCH IF END OF BUFFER
4612 015750 120027 000045      CMPB     R0,#'%'       ;IS IT A %?
4613 015754 001005      BNE      2$            ;NO
4614 015756 012700 000015      MOV      #15,R0        ;PRINT CR
4615 015762 000004      PNTCHR
4616 015764 012700 000012      MOV      #12,R0        ;PRINT LF
4617 015770 000004      2$:   PNTCHR
4618 015772 000764      BR       1$            ;GET ANOTHER CHAR.
4619
4620 015774 013700 000550      3$:   MOV      SAVR0,R0    ;RESTORE R0 SAVED IN HLTMES
4621 016000 013701 000552      MOV      SAVR1,R1      ;RESTORE R1 SAVED IN HLTMES
4622 016004 062716 000002      ADD      #2,(SP)       ;BUMP SP PAST MESSAGE ADDRESS
4623 016010 000002      RTI
4624
4625
4626
4627
4628
4629

```

```

4630      ;*****
4631      ;SBTTL OCTAL TYPEOUT ROUTINE
4632      ;REGISTER USAGE:
4633      ;R0-R5 SAVED IN CORE
4634      ;R0= CHAR PRINTED
4635      ;R1= CHAR COUNT (ALWAYS 6)
4636      ;R3= OCTAL NO. TO BE PRINTED ON ENTRY
4637      ;*****

```

```

4636 016012 010037 000550      TYOCT: MOV      R0,SAVR0    ;SAVE R0
4637 016016 010137 000552      MOV      R1,SAVR1      ;SAVE R1
4638 016022 010237 000554      MOV      R2,SAVR2      ;SAVE R2
4639 016026 010337 000556      MOV      R3,SAVR3      ;SAVE R3
4640 016032 010437 000560      MOV      R4,SAVR4      ;SAVE R4
4641 016036 112701 000006      MOVB     #6,R1         ;CHAR. COUNT
4642 016042 005000      CLR      R0            ;HOLDS CHAR
4643 016044 000241      4$:   CLC
4644 016046 006103      ROL      R3            ;GET BIT 15 INTO C BIT
4645 016050 006100      ROL      R0            ;PUT IT INTO R0

```

```

4646 016052 052700 000060      BIS      #60,RO      ;MAKE IT ASCII
4647 016056 000004      PNTCHR      ;AND PRINT IT
4648 016060 005000      CLR      RO      ;INIT CHAR HOLDER
4649 016062 006103      ROL      R3      ;PUT EACH BIT OF THE NEXT OCTAL CHAR INTO RO.
4650 016064 006100      ROL      RO
4651 016066 006103      ROL      R3
4652 016070 006100      ROL      RO
4653 016072 105301      DECB     R1      ;DONE ALL CHARS?
4654 016074 001363      BNE     4$      ;BRANCH IF NO
4655
4656

```

```

4657 016076 013700 000550      MOV     SAVRO,RO
4658 016102 013701 000552      MOV     SAVR1,R1
4659 016106 013703 000556      MOV     SAVR3,R3
4660 016112 000207      RTS     PC      ;RETURN TO CALLER
4661

```

```

;*****
;SBTTL SCOPE LOOP ROUTINE
;SCOPE LOOP ROUTINE ENTERED BY USER TRAP ".SCOPE"
;IF PLU SELECTED SET PLU INTERRUPT ENABLE
;*****

```

```

4668
4669 016114 032777 040000 177012 SCOPEC: BIT     #BIT14,JSWR ;TEST SR FOR SCOPE
4670 016122 001012      BNE     2$      ;BRANCH IF SCOPE LOOP WANTED.
4671 016124 032777 004000 177002      BIT     #BIT11,JSWR ;ITERATION WANTED?
4672 016132 001011      BNE     3$      ;BRANCH IF NO
4673 016134 023737 016214 016212 1$:  CMP     SCOPEF,ICOUNT ;DONE ITERATIONS?
4674 016142 001405      BEQ     3$      ;BRANCH IF YES
4675 016144 005237 016214      INC     SCOPEF   ;UPDATE ITERATION COUNT.
4676 016150 013716 000532 2$:  MOV     RETURN,JSW ;REPOSITION THE STACK
4677 016154 000404      BR     4$      ;SCOPE RETURN
4678
4679
4680 016156 005037 016214 3$:  CLR     SCOPEF   ;CLR ITERATION COUNTER
4681 016162 011637 000532      MOV     JSW,RETURN ;SAVE BEGIN OF NEXT TEST ADDRESS
4682
4683 ;IF PLU TESTED SET INTERRUPT ENABLE
4684 016166 032777 000020 176740 4$:  BIT     #BIT04,JSWR ;PLU TESTED?
4685 016174 001005      BNE     5$      ;BRANCH IF NO
4686 016176 005077 162216      CLR     JSWCSR   ;MUST PULSE DRCR TO GET INTERRUPT.
4687 016202 052777 000101 162210      BIS     #BIT06+BIT00,JSWCSR ;SET PLU INTERRUPT AND REQUEST A
4688
4689
4690 016210 000002 5$:  RTI      ;RETURN INLINE-NEXT TEST
4691 016212 001000      ICOUNT: 1000
4692 016214 000000      SCOPEF: 0      ;COUNT LOCATION FOR ITERATION LOOP
4693
4694

```

```

;*****
;SBTTL OUTPUT CHARACTER TRAP ROUTINE
;*****

```

```

4698
4699 016216 105777 162212      OUTCHR: TSTB   JSWCSR ;WAIT FOR RDY
4700 016222 100375      BPL     OUTCHR
4701 016224 110077 162206      MOVB   RO,JSWPB ;PRINT CHAR

```

```

4702 016230 000002 RTI ;RETURN
4703
4704 ;*****
4705 ;.SBTTL POWER FAIL ROUTINE
4706 ;*****
4707
4708 016232 010046 PFAIL: MOV R0,-(6) ;SAVE REGISTER ON STACK
4709 016234 010146 MOV R1,-(6) ;WHEN POWERING DOWN
4710 016236 010246 MOV R2,-(6)
4711 016240 010346 MOV R3,-(6)
4712 016242 010446 MOV R4,-(6)
4713 016244 010546 MOV R5,-(6)
4714 016246 013746 000024 MOV 24,-(6)
4715 016252 010637 016330 MOV SP,PWRFLG ;STORE STACK POSITION, POWER FAIL FLAG
4716 016256 012737 016266 000024 MOV #PWRUP,24
4717 016264 000000 HALT ;HALT ON POWER DOWN NORMAL
4718 016266 013706 016330 PWRUP: MOV PWRFLG,SP ;RESTORE STACK POINTER
4719 016272 005000 CLR R0 ;DELAY ON POWER UP FOR TTY SAKE
4720 016274 005300 1$: DEC R0
4721 016276 100776 BMI 1$ ;DELAY AWHILE
4722 016300 104001 017104 TYPE ,PWR ;TELL POWER FAILED
4723 016304 012637 000024 MOV (6)+,24 ;RESTORE POWER FAIL VECTOR
4724 016310 012605 MOV (6)+,R5 ;RESTORE R5,
4725 016312 012604 MOV (6)+,R4 ;THRU R0
4726 016314 012603 MOV (6)+,R3
4727 016316 012602 MOV (6)+,R2
4728 016320 012601 MOV (6)+,R1
4729 016322 012600 MOV (6)+,R0
4730 016324 000002 RTI ;RETURN TO MAIN LINE
4731 016326 000000 FIN: 0
4732 016330 000000 PWRFLG: 0 ;SAVE SP DURING POWER FAIL
4733
4734
4735
4736 ;*****
4737 ;.SBTTL MEMORY SIZER AND RELOCATION
4738 ;.SBTTL SIZER TESTS FOR MEMORY STARTING AT BOTTOM
4739 ;IF RXDP CHAIN MODE DON'T SIZE MEMORY AND DEFAULT TO 4K TEST.
4740 ;*****
4741
4742 016332 012737 017776 000572 RELOC: MOV #17776,MEMORY ;INIT SIZE OF MEMORY TO 4K
4743
4744 016340 005737 000540 TST @#CHAIN ;RXDP CHAIN MODE?
4745 016344 001004 BNE 1$ ;BRANCH IF YES
4746 016346 032777 001000 176560 BIT #1000,@SWR ;USER WANT CORE EXPANSION?
4747 016354 001401 BEQ DET4 ;BRANCH IF YES
4748 016356 000207 1$: RTS PC ; RETURN AND TEST 4K ONLY
4749
4750 016360 012737 016432 000004 DET4: MOV #DET2,4 ;TRAP VECTOR SETUP
4751 016366 012737 000340 000006 MOV #340,6 ;TRAP STATUS SETUP
4752 016374 005537 037770 EIGHT: ADC @#37770 ;CHECK FOR 8K
4753 016400 005537 057770 TWELVE: ADC @#57770 ;CHECK FOR 12K
4754 016404 005537 077770 SIXTEEN: ADC @#077770 ;CHECK FOR 16K
4755 016410 005537 117770 TWENTY: ADC @#117770 ;CHECK FOR 20K
4756 016414 005537 137770 TWOFOR: ADC @#137770 ;CHECK FOR 24K
4757 016420 005537 157770 TWOEIG: ADC @#157770 ;CHECK FOR 28K

```

```

4758 016424 012702 157770      MOV      #157770,R2      ;SET R2= 28K-6 ADDRESS
4759 016430 000407              BR      TSTMEM          ;GO TEST 28K ADDRESS
4760 016432 012601      DET2:  MOV      (SP)+,R1      ;GET TRAP PC
4761 016434 024141              CMP      -(R1),-(R1)     ;POINT TO TOP OF MEMORY ADDRESS+2
4762 016436 014102              MOV      -(R1),R2       ;SET R2=LAST ADDRESS-6
4763 016440 005726              TST      (SP)+          ;DISCARD TRAP STATUS WORD
4764 016442 023702 016372      CMP      EIGHT-2,R2     ;IF 4K R2 POINTS TO EIGHT-2
4765
4766 016446 001544              BEQ      DET3           ;4K
4767
4768 ;*****
4769 ;SBTTL MEMORY ADDRESS TEST OF ALL MEMORY BANKS IF RELOCATION SELECTED
4770 ;REGISTER USAGE:
4771 ;R0=CURRENT ADDRESS
4772 ;R1=FIRST ADDRESS
4773 ;R2=LAST ADDRESS-6
4774 ;R4=CURRENT ADDRESS+2
4775 ;R3=LAST ADDRESS
4776 ;*****
4776 016450 010203      TSTMEM: MOV      R2,R3      ;GET LAST ADDRESS-6
4777 016452 062703 000006      ADD      #6,R3          ;MAKE IT LAST ADDRESS
4778 016456 010337 000572      MOV      R3,MEMORY      ;SAVE MAXIMUM MEMORY ON SYSTEM
4779 016462 012700 020000      MOV      #20000,R0      ;R0= FIRST ADDRESS
4780 016466 010001              MOV      R0,R1          ;SAVE FIRST ADDRESS FOR END OF TEST CHECK
4781
4782 ;FILL MEMORY FROM 20000 TO TOP WITH EACH LOCATIONS ADDRESS
4783 016470 010004      MOV      R0,R4          ;SET R4=FIRST ADDRESS
4784
4785 1$:  MOV      R0,(R4)+      ;STORE AN ADDRESS
4786 016474 010400      MOV      R4,R0          ;SET R0=NEW CURRENT ADDRESS
4787 016476 020003      CMP      R0,R3          ;DONE ALL OF AVAIL. MEMORY?
4788 016500 101774      BLOS    1$             ;BRANCH IF NO
4789
4790 ;TEST EACH MEMORY LOCATION IN DESCENDING ORDER
4791
4792 2$:  CMP      R3,-(R0)      ;IS THE DATA OK?
4793 016502 020340      BEQ      .+4           ;BRANCH IF YES
4794 016504 001401              HLT                      ;*ERROR* MEMORY ADDRESS TEST FAILED;
4795 ;SAVR0=LOCATION FAILED
4796 ;SAVR3=EXPECTED DATA (= SAVR0)
4797 016510 162703 000002      SUB      #2,R3          ;DECREMENT DATA/ADDRESS
4798 016514 020103      CMP      R1,R3          ;DONE TO 20000?
4799 016516 101771      BLOS    2$             ;BRANCH IF NO
4800
4801 ;STORE PROCESSOR INSTRUCTION TEST IN EACH 4K MEMORY BANK
4802
4803
4804 016520 023702 016376      CMP      EIGHT+2,R2
4805 016524 001442      BEQ      STR8           ;8K
4806 016526 023702 016402      CMP      TWELVE+2,R2
4807 016532 001434      BEQ      STR12          ;12K
4808 016534 023702 016406      CMP      SXTEEN+2,R2
4809 016540 001426      BEQ      STR16          ;16K
4810 016542 023702 016412      CMP      TWENTY+2,R2
4811 016546 001420      BEQ      STR20          ;20K
4812 016550 023702 016416      CMP      TWOFOR+2,R2
4813 016554 001412      BEQ      STR24          ;24K
    
```

```

4814 016556 000406          BR      STRT28          ;28K
4815 016560 005000          MOVE:  CLR      RD          ;SET UP MAIN CORE CURRENT
4816 016562 012021          1$:   MOV      (0)+(1)+    ;MOVE WORD
4817 016564 020027 015214      CMP      RD,#ENDREL      ;MOVE COMPLETE?
4818 016570 001374          BNE     1$              ;MOVE ANOTHER WORD
4819 016572 000207          RTS     PC              ;MOVE COMPLETE
4820 016574 004737 016640      STRT28: JSR     PC,XFER28 ;START 28K TRANSFER
4821 016600 000450          BR      MOD24          ;START 24K MODIFY
4822 016602 004737 016650      STRT24: JSR     PC,XFER24 ;START 24K TRANSFER
4823 016606 000450          BR      MOD20          ;START 20K MODIFY
4824 016610 004737 016660      STRT20: JSR     PC,XFER20 ;START 20K TRANSFER
4825 016614 000450          BR      MOD16          ;START 16K MODIFY
4826 016616 004737 016670      STRT16: JSR     PC,XFER16 ;START 16K TRANSFER
4827 016622 000450          BR      MOD12          ;START 12K MODIFY
4828 016624 004737 016700      STRT12: JSR     PC,XFER12 ;START 12K TRANSFER
4829 016630 000450          BR      MOD8           ;START 8K MODIFY
4830 016632 004737 016710      STRT8:  JSR     PC,XFER8  ;START 8K TRANSFER
4831 016636 000450          BR      MOD4           ;START 4K MODIFY
4832 016640 012701 140000      XFER28: MOV     #140000,R1 ;SET UP MOVE START LOCATION
4833 016644 004737 016560          JSR     PC,MOVE        ;GO TO MOVE SUBROUTINE
4834 016650 012701 120000      XFER24: MOV     #120000,R1
4835 016654 004737 016560          JSR     PC,MOVE
4836 016660 012701 100000      XFER20: MOV     #100000,R1
4837 016664 004737 016560          JSR     PC,MOVE
4838 016670 012701 060000      XFER16: MOV     #60000,R1
4839 016674 004737 016560          JSR     PC,MOVE
4840 016700 012701 040000      XFER12: MOV     #40000,R1
4841 016704 004737 016560          JSR     PC,MOVE
4842 016710 012701 020000      XFER8:  MOV     #20000,R1
4843 016714 004737 016560          JSR     PC,MOVE
4844 016720 000207          RTS     PC              ;RETURN FROM TRANSFERS
4845 016722 012737 143600 135212 MOD24:  MOV     #BEGIN+140000,TRPA+120002
4846 016730 012737 123600 115212 MOD20:  MOV     #BEGIN+120000,TRPA+100002
4847 016736 012737 103600 075212 MOD16:  MOV     #BEGIN+100000,TRPA+60002
4848 016744 012737 063600 055212 MOD12:  MOV     #BEGIN+60000,TRPA+40002
4849 016752 012737 043600 035212 MOD8:   MOV     #BEGIN+40000,TRPA+20002 ;STORE JMP TO 12K TEST
4850 016760 000207          MOD4:   MOV
4851 016760 000207          DET3:  RTS     PC              ;RETURN FROM MODIFY

```

```

;*****
;SBTTL UTILITY #1-PRINT REGISTERS AT TIME OF ERROR
;*****

```

```

4861 016762 012706 017474 017026 PNTABL: MOV     #STACK,SP ;SETUP STACK POOINTER
4862 016766 012737 000011          MOV     #ELAST-EFIRST/2,PNTMP ;SIZE OF TABLE
4863 016774 012705 000550          MOV     #EFIRST,R5 ;BEGIN OF TABLE
4864 017000 012503          1$:   MOV     (R5)+,R3 ;GET AN ENTRY
4865 017002 004737 016012          JSR     PC,TYPOCT ;PRINT OCTAL
4866 017006 104001 017146          TYPE   CR ;PRINT CR
4867 017012 005337 017026          DEC   PNTMP ;DONE WHOLE TABLE?
4868 017016 001370          BNE   1$ ;BRANCH IF NO
4869 017020 000000          HALT ;PNTABL ROUTINE NORMAL HALT

```

4870 017022 000137 000602  
4871 017026 000000

PNTMP: JMP #START ; IN CASE OF CONTINUE  
0 ; TEMP STORAGE FOR PNTABL

4872  
4873 ;\*\*\*\*\*  
4874 .SBTTL ASR 33 PAPER TAPE PUNCH ROUTINE  
4875 ;\*\*\*\*\*

4876  
4877 ; PUNCHES A TEST TAPE IN A BINARY COUNT PATTERN FROM 0-377  
4878 ; AND 50 FRAMES OF BLANK TAPE. THE PROGRAM IS CONTINUOUS RUNNING.  
4879 ; THE RESULTANT TAPE CAN BE USED AS AN INPUT TAPE FOR THE ASR 33  
4880 ; LOW SPEED READER TEST.

4881  
4882 017030 012706 017474  
4883 017034 005001  
4884 017036 012700 000017  
4885 017042 105777 161366  
4886 017046 100375  
4887 017050 005077 161362  
4888 017054 005300  
4889 017056 003371  
4890 017060 105777 161350  
4891 017064 100375  
4892 017066 110177 161344  
4893 017072 105201  
4894 017074 120127 000377  
4895 017100 101767  
4896 017102 000752

ASRUTL: MOV #STACK, SP ; SETUP STACK  
CLR R1 ; INIT DATA PATTERN  
MOV #15, R0 ; INIT 50 BLANK FRAME COUNT.  
1\$: TSTB @TPS ; IS PRINTER READY?  
BPL 1\$ ; BRANCH IF NO  
CLR @TPB ; PRINT NULL/BLANK FRAME  
DEC R0 ; DONE 50 FRAMES?  
BGT 1\$ ; BRANCH IF NO  
2\$: TSTB @TPS ; IS PRINTER READY?  
BPL 2\$ ; BRANCH IF NO  
MOVB R1, @TPB ; PRINT 0-377 DATA PATTERN  
INCB R1 ; UPDATE DATA PATTERN  
CMPB R1, #377 ; DONE DATA PATTERN?  
BLOS 2\$ ; BR IF NO  
BR ASRUTL ; KEEP DOING THIS UNTIL HALT LINE SET

4897  
4898  
4899 ;\*\*\*\*\*  
4900 .SBTTL MESSAGE STORAGE  
4901 ;\*\*\*\*\*

4902  
4903 017104 053520 022522 000 PWR: .ASCIZ 'PWR%'  
4904 017111 045 041520 000075 PCE: .ASCIZ '%PC='  
4905 017116 050040 053523 000075 CCE: .ASCIZ 'PSW='  
4906 017124 042515 047515 054522 MAXM: .ASCIZ 'MEMORY='  
017132 020075 000  
4907 017135 040 042522 052524 SCPE: .ASCIZ 'RETURN='  
017142 047122 000075  
4908 017146 000045 CR: .ASCIZ '%'  
4909 017150 051040 042530 051122 RXS: .ASCIZ 'RXERROR='  
017156 051117 000075  
4910 017162 050045 051501 036523 PAS: .ASCIZ '%PASS='  
017170 000  
4911 017171 040 051105 047522 ERR: .ASCIZ 'ERROR='  
017176 036522 000  
4912 017201 040 044524 042515 PTIM: .ASCIZ 'TIME='  
017206 000075  
4913 017210 042045 045526 044101 MREV: .ASCIZ '%DVKAH-A%'  
017216 040455 000045

4914  
4915 .EVEN  
4916  
4923  
4924



K07

MAINDEC-11-DVKAH-A  
DVKAHA.P11

LSI-11 4K SYSTEM TEST  
MESSAGE STORAGE

MACY11 27(732) 24-AUG-76 16:08 PAGE 23-12

SEQ 0089

4925  
4926 017474  
4927  
4928 017474 000000  
4929  
4930 000001

.=17474

STACK: 0 :BEGIN OF STACK  
.SBTTL STACK BUFFER AREA  
.END





















ADC	1693	2162	2173	2581	4158	4752	4753	4754	4755	4756	4757				
ADCB	2967	2978	3263												
ADD	1567	1638	1692	1696	2208	2505	2514	2522	3851	3858	4165	4572	4622	4777	
ASH	3886	3897													
ASHC	3910	3921													
ASL	3488	3507	4173												
ASLB	3577														
ASR	4172														
ASRB	3563														
BCC	1761	1791	3489	3637	3663	3675	3698	3887	3898	3911	3922	4003			
BCS	1767	1779	3416	3431	3444	3458	3472	3508	3527	3546	3564	3578	3735	3943	3960
	4560														
BEQ	1004	1006	1046	1063	1111	1130	1150	1243	1282	1291	1293	1335	1337	1366	1385
	1409	1433	1524	1626	1643	1650	1771	1793	1808	1816	1833	1841	1849	1857	1866
	1873	1882	1890	1905	1918	1927	1936	1945	1959	1969	1979	1989	2000	2023	2032
	2041	2050	2064	2074	2084	2094	2103	2113	2123	2133	2143	2153	2164	2175	2186
	2197	2223	2233	2240	2247	2259	2267	2275	2287	2296	2305	2318	2326	2335	2347
	2356	2365	2374	2383	2395	2402	2409	2421	2429	2437	2450	2459	2468	2477	2485
	2494	2507	2516	2524	2537	2546	2555	2564	2573	2583	2593	2605	2613	2622	2636
	2646	2656	2674	2682	2690	2698	2706	2714	2723	2730	2741	2750	2763	2772	2781
	2790	2802	2812	2822	2832	2846	2856	2866	2876	2886	2896	2905	2908	2918	2928
	2938	2948	2958	2969	2980	2991	3002	3015	3022	3030	3037	3049	3057	3065	3077
	3086	3095	3104	3113	3123	3135	3142	3149	3160	3168	3176	3189	3198	3207	3219
	3228	3237	3246	3255	3265	3268	3278	3290	3298	3307	3320	3330	3338	3346	3354
	3364	3374	3387	3397	3412	3436	3449	3463	3477	3491	3496	3510	3515	3529	3534
	3553	3569	3583	3639	3665	3677	3706	3737	3744	3761	3773	3785	3797	3838	3866
	3977	3888	3900	3912	3928	3942	3948	3962	3968	4001	4008	4035	4061	4086	4148
	4155	4162	4168	4176	4282	4301	4457	4509	4534	4593	4611	4674	4747	4766	4793
	4805	4807	4809	4811	4813										
BGE	1430	1787													
BGT	1439	1570	1641	1786	1798	4889									
BHI	1774														
BHIS	4448														
BIC	1064	1110	1359	1405	1957	1967	1977	1987	2285	2294	2303	2448	2457	2466	2634
	2644	2654	3704	3742	4174	4299	4455	4456							
BICB	2800	2910	2820	2830	3187	3196	3205	3318	3328	3372					
BIS	1043	1053	1081	1085	1094	1102	1224	1364	1412	1503	1507	1553	1592	1651	1654
	1655	4646	4687												
BIT	1045	1054	1062	1082	1117	1120	1178	1197	1214	1242	1244	1262	1482	1690	1999
	3876	4511	4519	4569	4592	4669	4671	4684	4746						
BITB	2010														
BLE	1788														
BLO	1780														
BLOS	1775	4788	4799	4895											
BLT	1446	1493	1569	1640	1794	2663									
BMI	1146	1156	1221	1276	1310	1331	1357	1379	1402	1425	1481	1673	1764	3410	3701
	3923	3963	4000	4289	4469	4587	4721								
BNE	1055	1083	1089	1096	1118	1121	1132	1179	1198	1215	1245	1263	1280	1284	1297
	1314	1340	1362	1483	1526	1529	1572	1675	1691	1694	1763	2011	3548	3625	3654
	3700	3864	3926	3946	3966	4006	4033	4059	4084	4512	4514	4520	4570	4589	4613
	4654	4670	4672	4685	4745	4818	4868								
BPL	1091	1098	1316	1773	1792	3492	3511	3530	3549	3637	3663	3675	3738	3940	4524
	4700	4886	4891												
BR	832	861	1033	1138	1208	1260	1367	1435	1437	1442	1448	1451	1573	1576	1653
	1656	1676	1695	3385	3626	3637	3655	3663	3675	4089	4308	4501	4618	4677	4759
	4814	4821	4823	4825	4827	4829	4831	4896							

BVC	1762	3446	3490	3566	3580	3637	3663	3675	3699						
BVS	1769	1785	3414	3433	3460	3474	3509	3528	3547	3637	3663	3675	3736	3941	3961
	4002														
CCC	3394	3408	3428	3455	3506	3561									
CLC	1778	3885	3896	4643											
CLN	1797	3794													
CLR	997	998	999	1000	1002	1010	1012	1013	1014	1015	1060	1078	1079	1080	1103
	1113	1114	1115	1116	1133	1159	1160	1187	1189	1206	1241	1250	1353	1363	1443
	1508	1527	1578	1634	1648	1652	1671	1688	2062	2072	2345	2362	2371	2504	2513
	2535	2552	2561	3101	3110	3119	3234	3243	3613	3781	3782	3834	3908	3920	3993
	4283	4452	4463	4500	4517	4522	4642	4648	4680	4686	4719	4815	4883	4887	
CLRB	2944	2854	2864	2874	3075	3217	3362								
CLV	1784														
CLZ	1791														
CMP	1005	1361	1383	1407	1429	1432	1438	1445	1568	1571	1639	1642	1807	1815	1832
	1840	1848	1856	1865	1872	1891	1889	1917	1926	1935	1944	1958	1968	1979	1988
	2142	2152	2222	2232	2239	2246	2258	2266	2274	2286	2295	2304	2317	2355	2364
	2373	2382	2394	2401	2408	2420	2428	2436	2449	2458	2467	2476	2506	2515	2523
	2545	2554	2563	2572	2604	2612	2621	2635	2645	2655	2855	2865	2907	2947	2957
	2968	2979	2990	3076	3085	3094	3103	3112	3122	3264	3337	3345	3363	3373	3435
	3448	3462	3476	3495	3514	3533	3552	3568	3582	3624	3638	3653	3664	3676	3705
	3760	3772	3837	3863	3865	3899	3925	3927	3945	3947	3967	4005	4032	4083	4085
	4147	4154	4161	4167	4175	4447	4575	4588	4673	4761	4764	4787	4792	4798	4804
	4806	4808	4810	4812	4817										
CMPB	1131	1281	1283	1292	1336	1492	1625	1904	2662	2673	2681	2689	2697	2705	2713
	2722	2729	2738	2749	2762	2771	2780	2789	2801	2811	2821	2831	3014	3021	3029
	3036	3048	3056	3064	3134	3141	3148	3159	3167	3175	3188	3197	3206	3227	3236
	3245	3254	3289	3297	3306	3319	3329	3353	3386	3396	4300	4612	4894		
COM	1109	1389	2082	2092	2354	2544	4152	4454	4518						
COMB	2884	2894	3084	3093	3226										
DEC	2121	2131	2372	2562	4027	4139	4140	4141	4142	4143	4144	4145	4146	4720	4867
	4888														
DECB	1315	2926	2936	3111	3244	3276	4653								
DIV	3959														
EMT	736	737													
FADD	3999														
FDIV	4082														
FMUL	4057														
FSUB	4031														
HALT	755	760	764	806	972	4544	4590	4717	4869						
INC	1007	1084	1119	1122	1299	1342	1360	1411	1431	1434	1440	1452	1500	1674	1727
	2101	2111	2363	2553	3622	3650	3758	4131	4132	4133	4134	4135	4136	4137	4138
	4153	4446	4462	4568	4675										
INCB	1296	1318	1339	1365	1501	1540	1629	2903	2916	3102	3235	4893			
IOT	739														
JMP	835	866	870	871	1264	1289	1487	2209	3878	4284	4428	4515	4541	4594	4870
JSR	1142	1152	1230	1236	1287	1504	1536	1555	1559	1594	1598	1621	3384	3395	3409
	3623	3651	3652	4412	4414	4416	4418	4481	4484	4487	4490	4537	4578	4581	4584
	4820	4822	4824	4826	4828	4830	4833	4835	4837	4839	4841	4843	4865		
MFPS	3703	3741	4471												
MOV	995	996	1011	1031	1034	1035	1036	1037	1038	1039	1040	1051	1061	1077	1101
	1108	1123	1124	1125	1126	1127	1128	1141	1151	1177	1185	1186	1188	1190	1191
	1192	1193	1201	1202	1203	1207	1217	1218	1219	1223	1235	1246	1249	1285	1298
	1317	1319	1341	1354	1390	1391	1413	1436	1441	1444	1447	1450	1453	1477	1478
	1479	1502	1509	1510	1530	1534	1535	1542	1552	1554	1558	1562	1566	1575	1577
	1579	1580	1591	1593	1597	1601	1602	1616	1617	1618	1632	1637	1645	1646	1647

	1657	1658	1689	1748	1750	1751	1754	1806	1814	1831	1839	1847	1855	1863	1864
	1879	1880	1887	1888	1915	1916	1924	1925	1933	1934	1942	1943	1955	1956	1965
	1966	1975	1976	1985	1986	1998	2020	2021	2029	2030	2038	2039	2047	2048	2060
	2061	2070	2071	2080	2081	2090	2091	2099	2100	2109	2110	2119	2120	2129	2130
	2139	2140	2149	2150	2159	2160	2170	2171	2181	2182	2192	2193	2207	2216	2217
	2218	2220	2221	2257	2265	2273	2284	2293	2302	2315	2324	2332	2344	2353	2380
	2419	2427	2435	2447	2456	2465	2474	2483	2491	2521	2534	2543	2570	2579	2589
	2603	2611	2619	2620	2632	2633	2642	2643	2651	2652	2653	2672	2680	2688	2696
	2704	2712	2720	2721	2736	2737	2747	2748	2760	2769	2778	2787	2798	2799	2808
	2809	2818	2819	2828	2829	2842	2843	2852	2853	2862	2863	2872	2873	2882	2883
	2892	2893	2901	2902	2914	2915	2924	2925	2934	2935	2944	2945	2954	2955	2964
	2965	2975	2976	2986	2987	2997	2998	3074	3083	3092	3186	3195	3204	3216	3225
	3252	3261	3274	3288	3296	3304	3305	3316	3317	3326	3327	3336	3344	3352	3360
	3361	3369	3370	3371	3429	3442	3456	3470	3486	3505	3524	3543	3562	3576	3621
	3628	3649	3656	3696	3740	3756	3757	3769	3770	3793	3849	3850	3852	3853	3854
	3855	3856	3857	3867	3868	3884	3895	3909	3919	3938	3956	3957	3992	3994	3995
	3996	4024	4025	4026	4028	4029	4030	4052	4053	4054	4055	4056	4077	4078	4079
	4080	4081	4123	4124	4125	4126	4130	4171	4292	4298	4307	4422	4423	4453	4480
	4483	4486	4489	4521	4525	4526	4535	4536	4554	4555	4556	4558	4561	4562	4571
	4573	4574	4577	4580	4583	4609	4614	4616	4620	4621	4636	4637	4638	4639	4640
	4657	4658	4659	4676	4681	4708	4709	4710	4711	4712	4713	4714	4715	4716	4718
	4723	4724	4725	4726	4727	4728	4729	4742	4750	4751	4758	4760	4762	4776	4778
	4779	4780	4783	4785	4786	4816	4832	4834	4836	4838	4840	4842	4845	4846	4847
	4848	4849	4861	4862	4863	4864	4882	4884							
MOV8	1539	1624	1903	2009	2761	2770	2779	2788	3047	3055	3063	3120	3158	3166	3174
	4610	4641	4701	4892											
MTPS	1020	1253	3697	3734	4472	4494									
MUL	1204	3939													
NEG	2141	2151	2381	2571	4151										
NEGB	2946	2956	3121	3253											
NOP	834	2211	4538	4539	4540										
RESET	1044	1052													
ROL	3629	3634	3635	3636	4644	4645	4649	4650	4651	4652					
ROLB	3457	3471	3660	3661	3662	3672	3673	3674							
ROR	3630	3631	3632	3633	4559										
RORB	3430	3443	3657	3658	3659	3669	3670	3671							
RTI	807	1300	1320	1343	1355	1394	1414	1454	1511	1543	1591	1603	1659	1728	4527
	4595	4623	4690	4702	4730										
RTS	1697	3389	3641	3667	3679	3859	4409	4411	4413	4415	4417	4419	4660	4748	4819
	4844	4851													
RTT	4543														
SBC	2184	2195	2591	4160											
SBCB	2989	3000													
SCC	1760	3441	3469	3487	3525	3544	3575	4410							
SEC	2161	2172	2183	2194	2580	2590	2966	2977	2988	2999	3262	3275	3958	3998	4157
	4153														
SEN	3835														
SEV	3997														
SOB	1541	1630	3759	4178											
SUB	1749	2022	2031	2040	2049	2316	2325	2333	2475	2484	2492	4128	4166	4797	
SWAB	3526	3545													
SXT	3795	3836													
TRAP	738														
TST	1032	1088	1090	1095	1097	1279	1378	1480	1523	1525	1528	1649	2063	2073	2083
	2093	2102	2112	2122	2132	2163	2174	2185	2196	2334	2346	2493	2536	2592	2592
	3001	3277	3399	3743	3784	3796	3965	4007	4034	4058	4060	4291	4299	4507	4513

TSTB	4523	4557	4586	4608	4744	4763										
	1003	1129	1145	1149	1155	1220	1275	1290	1309	1313	1330	1333	1356	1401	1424	
	1672	2845	2875	2885	2895	2904	2917	2927	2937	3218	3267	4468	4533	4699	4885	
	4890															
WAIT	1261	4302	4303	4304	4305											
XOR	3771	3783														
.ASCIZ	4903	4904	4905	4906	4907	4908	4909	4910	4911	4912	4913					
.DSABL	1744															
.ENABL	687	733	4434													
.END	4930															
.ENDC	842	928	1021	1026	1172	1254	1258	1459	1720	1830	3728	3749	3813	3828	4274	
	4374	4473	4478	4495	4499	4921										
.EVEN	4915															
.IF	838	921	1019	1023	1165	1252	1256	1416	1699	1820	3690	3711	3800	3815	4182	
	4316	4470	4475	4493	4497	4919										
.LIST	7	684	686	729	746	761	837	3612	4044	4070	4922					
.MACR	3593															
.MACRO	691															
.NLIST	5	6	683	685	718	742	836	3587	4042	4068	4917					
.PAGE	680															
.REPT	9	757														
.SBTTL	803	814	829	857	864	874	899	943	951	970	985	1029	1182	1227	1267	
	1268	1269	1270	1305	1326	1348	1374	1420	1465	1724	1732	1733	1741	1742	2227	
	3874	4296	4312	4433	4435	4442	4504	4530	4548	4629	4663	4696	4705	4737	4738	
	4768	4856	4874	4900	4929											
.TITLE	689															
.WORD	783	4095	4096	4097	4098											

ERRORS DETECTED: 0  
 DEFAULT GLOBALS GENERATED: 0

\*.DVKAHA/CRF=DVKAHA.P11  
 RUN-TIME: 14 28 5 SECONDS  
 RUN-TIME RATIO: 220/47=4.6  
 CORE USED: 12K (23 PAGES)

