

DC11

ON-LINE
MD-11-DZDCB-B

EP-DZDCB-B-DL-A
COPYRIGHT © 1976
FICHE 1 OF 1

NOV 1976
digital
MADE IN U.S.A.

This microfiche card contains a grid of frames. The frames are arranged in approximately 10 rows and 6 columns. Each frame contains a small, high-contrast image of a document page, likely a technical drawing or data table. The images are very small and difficult to read, but they appear to be organized in a structured manner. The right half of the card is mostly blank, with some faint, illegible markings.

50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94

1. ABSTRACT

TWO SEPARATE DIAGNOSTIC PROGRAMS ARE PROVIDED FOR THE DC-11 (ASYNCHRONOUS MODEM INTERFACE), MAINDEC-11-D9AA (DC-11 OFF LINE TESTS) AND MAINDEC-11-DZDCBA (DC-11 ON LINE TESTS). THE OFF LINE TESTS TEST ALL DC11 LOGIC AND MAY BE USED TO INDIVIDUALLY TEST UP TO 32 DC-11'S. THE OFF LINE TESTS DO NOT REQUIRE THE USE OF A MODEM, HOWEVER A SPECIAL JUMPER CONNECTOR IS REQUIRED. THE ON LINE TESTS ARE ESSENTIALLY DATA RELIABILITY TESTS REQUIRING THE USE OF MODEMS AND A SUITABLE TERMINAL DEVICE.

THIS DOCUMENT DESCRIBES THE ON LINE TESTS.

THE AVAILABLE TESTS ARE:

PRG0	SINGLE CHARACTER LINE MODE DATA TEST
PRG1	BINARY COUNT LINE MODE DATA TEST
PRG2	MESSAGE TRANSMIT ONLY W/W/O PARITY
PRG3	RECEIVE DATA TEST

2. REQUIREMENTS

2.1 EQUIPMENT

- A. PDP 11/20 SYSTEM
- B. DC11(S)
- C. SUITABLE TERMINAL DEVICE (ASA 33, 37, DATA POINT, ETC)
- D. MODEM TYPE 103 OR 202 OR EQUIVILENT

2.2 STORAGE

THIS PROGRAM USES ALL OF CORE (4K) EXCEPT THAT AREA RESERVED FOR THE BOOTSTRAP AND ABSOLUTE LOADERS.

3. OPERATING PROCEDURE:

3.1 LOADING PROCEDURE

THE ABSOLUTE LOADER IS USED TO LOAD THE PROGRAM.

95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129

3.2 DC-11 PARAMETER SELECTION

THE SELECTABLE DC-11 PARAMETERS ARE:

SW4	UP/DWN	TRANSMIT 1/2 STOP BITS		
SW3-2		SPEED SELECT		
SW3	SW2	DC11AA	DC11AB	DC11AC
0	0	110	110	110
0	1	134.5	300	150
1	0	150	1200	600
1	1	300	1500	1800
SW1-0		CHARACTER LENGTH		
SW1	SW0	CHARACTER LENGTH		
0	0	7		
0	1	6		
1	0	6		
1	1	5		

WHEN A TERMINAL IS INVOLVED DC-11 PARAMETERS SHOULD BE SET ACCORDING TO TERMINAL SPECIFICATIONS.

3.3 PDP-11 STANDARD OPERATING PARAMETERS

SW15	1 OR UP	HALT ON ERROR
SW14	1 OR UP	SCOPE LOOP (NOT USED)
SW13	1 OR UP	INHIBIT ERROR PRINTOUT
SW12	1 OR UP	INHIBIT TRACE TRAP (NOT USED)
SW11	1 OR UP	INHIBIT ITERATION (NOT USED)

131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179

3.4 GENERAL

THERE ARE THREE CONFIGURATIONS USING DC11/MODEM PAIRS WHICH MAY BE SELECTED BY PRG0 AND PRG1. THESE CONFIGURATIONS ARE SELECTED BY THE USER WHEN REQUESTED BY THE PROGRAM DURING THE LINE CONNECTION ROUTINE. THE FOLLOWING PROCEDURES SHOULD BE FOLLOWED TO SELECT ANY OF THE THREE SELECTABLE CONFIGURATIONS:

CONFIGURATION 0: THIS CONFIGURATION TRANSMITS DATA FROM THE DC11 CONNECTED TO THE LINE THAT WAS CALLED TO THE MODEM THAT CALLED (THE CALLER). THIS CONFIGURATION MAY BE USED TO TRANSMIT DATA TO A TERMINAL DEVICE. NOTE NO DATA CHECKING IS PERFORMED BY THE PROGRAM HOWEVER DATA MAY BE VISUALLY CHECKED AT THE TERMINAL DEVICE. TO INITIATE PROGRAM ACTION CALL THE MODEM CONNECTED TO A DC11 FROM A MODEM CONNECTED TO THE TERMINAL DEVICE. WHEN THE PHONE RINGS AT THE PDP11 THE PROGRAM WILL REQUEST THE CONFIGURATION. SET SR0=00 AND PRESS CONTINUE. WHEN THE 'HANDSHAKING' IS COMPLETED THE PROGRAM WILL REQUEST DC11 PARAMETERS LOAD THE PARAMETERS AS REQUESTED AND PRESS CONTINUE. THE PROGRAM WILL TYPE 'LINE CONNECTION MADE' AND BEGIN DATA TRANSMISSION SEE FIGURE 5-3 IN THE DC11 MAINTENANCE MANUAL FOR CONFIGURATION DIAGRAM.

CONFIGURATION 1: THIS CONFIGURATION TRANSMITS DATA FROM THE DC11 CONNECTED TO THE LINE THAT WAS CALLED TO THE DC11 CONNECTED TO THE LINE THAT CALLED (THE CALLER). TO INITIATE PROGRAM ACTION CALL THE DC11 YOU WISH TO TRANSMIT ON FROM THE LINE CONNECTED TO THE DC11 RECEIVER YOU WISH TO RECEIVE THE DATA ON. WHEN THE PHONE RINGS AT THE PDP11 THE PROGRAM WILL REQUEST THE CONFIGURATION AND MODEM TYPE. SET SR0=01 & SR2=0 IF A 103 (OR EQUIV.) AND SR2=1 IF A 202 (OR EQUIV.) PRESS CONTINUE. THE PROGRAM WILL REQUEST THE LINE NUMBER THAT YOU CALLED FROM. ENTER THIS INTO THE SR AND PRESS CONTINUE. WHEN THE CARRIER IS HEARD IN THE HEADSET PRESS THE DATA BUTTON ON THE DATA SET. YOU HAVE APPROXIMATELY 10 SECONDS IN WHICH TO DO THIS. WHEN THE 'HANDSHAKING' IS COMPLETED THE PROGRAM WILL REQUEST DC11 PARAMETERS. LOAD THE PARAMETERS AS REQUESTED AND PRESS CONTINUE. THE PROGRAM WILL TYPE 'LINE CONNECTION MADE' AND BEGIN DATA TRANSMISSION. WHEN 100. CHARACTERS HAVE BEEN PROCESSED (TRANSMITTED/RECEIVED AND CHECKED) THE BELL WILL RING AT THE TTY, AND ANOTHER 100. CHARACTER BLOCK WILL BE PROCESSED. SEE FIGURE 5-4 IN THE DC11 MAINTENANCE MANUAL FOR CONFIGURATION DIAGRAM. NOTE, DC11#X REFERS TO THE 'CALLED' DC11, AND DC11#Y REFERS TO THE CALLING DC11.

180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222

CONFIGURATION 2: THIS CONFIGURATION TRANSMITS DATA FROM BOTH THE CALLED TRANSMITTER AND THE TRANSMITTER CONNECTED TO THE LINE THAT WAS CALLING, I.E. IN ADDITION TO THE DATA TRANSMITTED AS IN CONFIGURATION 1 DATA IS ALSO TRANSMITTED IN THE REVERSE DIRECTION. TO INITIATE PROGRAM ACTION CALL THE DC11 YOU WISH TO TRANSMIT ON FROM THE DC11 YOU WISH TO RECEIVE/TRANSMIT ON. WHEN THE PHONE RINGS AT THE POP11 THE PROGRAM WILL REQUEST THE CONFIGURATION AND MODEM TYPE. SET SR0-1 =10 AND SR2=0. NOTE: *****DO NOT USE MODEM TYPE 202 (OR EQUIV) USING CONFIG #2***** THE PROGRAM WILL REQUEST THE LINE YOU CALLED FROM. ENTER THE LINE NUMBER INTO THE SR AND PRESS CONTINUE. WHEN THE CARRIER IS HEARD IN THE HEADSET PRESS THE DATA BUTTON ON THE DATA SET. NOTE YOU HAVE APPROXIMATELY 10 SECONDS IN WHICH TO DO THIS. WHEN THE 'HANDSHAKING IS COMPLETED THE PROGRAM WILL REQUEST TWO SETS OF DC11 PARAMETERS. THE CHARACTER LENGTH OF BOTH SETS MUST BE THE SAME AND THE SPEED OF THE SECOND SET MUST BE GREATER THAN THE SPEED OF THE FIRST. WHEN THE PARAMETERS HAVE BEEN LOADED THE PROGRAM WILL TYPE 'LINE CONNECTION MADE' AND BEGIN TWO WAY DATA TRANSMISSION. WHEN 100. CHARACTERS HAVE BEEN RECEIVED AND CHECKED THE BELL WILL RING AT THE TTY, AND ANOTHER BLOCK OF 100. CHARACTERS WILL BE PROCESSED. SEE FIGURE 5-5 IN THE DC11 MAINTENANCE MANUAL FOR CONFIGURATION DIAGRAM. NOTE, DC11#X REFERS TO THE 'CALLED' DC11, AND DC11#Y REFERS TO THE 'CALLING' DC11.

3.5 LINE NUMBERS

LINE NUMBER REFERS TO THE ADDRESSES TO WHICH THE DC11 RESPONDS.

LINE 0	77400X	LINE 10	77410X
LINE 1	77401X	LINE 11	77411X
LINE 2	77402X	LINE 12	77412X
LINE 3	77403X	LINE 13	77413X
LINE 4	77404X	LINE 14	77414X
LINE 5	77405X	LINE 15	77415X
LINE 6	77406X	LINE 16	77416X
LINE 7	77407X	LINE 17	77417X

223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278

- 4. USE PROCEDURE
- 4.1 PRG0 SINGLE CHARACTER LINE MODE DATA TEST
 - A. LOAD ADDRESS = 000200 (RESTART LOAD ADDR. = 000200)
 - B. SWITCH REGISTER
 - 1. SR 0-2 = 0
 - C. THE PROGRAM WILL NOW REQUEST THE DATA. LOAD DATA INTO SR 0-7 AND PRESS CONTINUE.
 - D. MAKE LINE CONNECTION. SEE SECT 3.4
- 4.2 PRG1 - BINARY COUNT LINE MODE DATA TEST
 - A. LOAD ADDRESS = 000200
 - B. SWITCH REGISTER
 - 1. SR 0-2 = 1
 - C. MAKE LINE CONNECTION SEE SECT 3.4
- 4.3 PRG2 - SPECIAL MESSAGE XMIT ONLY
 - A. LOAD ADDRESS = 000200
 - B. SWITCH REGISTER
 - 1. SR 0-2 = 2
 - 2. SR 3-6 = LINE NUMBER (SEE SECT 3.5)
 - C. DEPRESS START - THE PROGRAM WILL IDENTIFY ITSELF AND TYPE INSTRUCTIONS TO SELECT DESIRED DC-11 PARAMETERS (SEE SECT 3.2)
 - D. SET IN PARAMETERS IF IT IS DESIRED TO TRANSMIT DATA WITH PARITY RAISE SR6. ALSO RAISE SRS TO TRANSMIT ODD PARITY AND LOWER TO TRANSMIT EVEN PARITY.

SR6	UP/DWN	ENABLE/DISABLE	PARITY
SR5	UP/DWN	TRANSMIT ODD/EVEN	PARITY

 PRESS CONTINUE
 - E. WHEN 'MAKE LINE CONNECTION' IS TYPED CALL THE DC11 YOU WISH TO TRANSMIT ON FROM THE TERMINAL MODEM. WHEN THE 'HANDSHAKING' IS COMPLETED THE MESSAGE 'THE QUICK BROWN FOX JUMPED OVER THE LAZY DOGS BACK 0123456789' WILL BE TRANSMITTED. TO TERMINATE HANG UP.

279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307

4.4 PRG3 - RECEIVE TRANSMIT MESSAGE TEST

A. LOAD ADDRESS = 000200

B. SWITCH REGISTER

1. SR 0-2 = 3

2. SR 3-6 = LINE NUMBER (SEE SECT 3.5)

C. DEPRESS START - THE PROGRAM WILL IDENTIFY ITSELF AND
TYPE INSTRUCTIONS TO SELECT DESIRED OPTIONS.

D. SET IN OPTIONS AND PRESS CONTINUE.

E. WHEN 'MAKE LINE CONNECTION' IS TYPED CALL THE DC11
YOU WISH TO TRANSMIT ON. WHEN THE 'HANDSHAKING' IS COMPLETED
THE DC11 WILL TRANSMIT A CRLF TO THE TERMINAL DEVICE. AT THIS
TIME YOU MAY BEGIN TO SEND DATA FROM THE DEVICE TO THE DC11
WHERE IT WILL BE ECHOED BACK TO THE TERMINAL. TYPE CONTROL
C (↑C) TO SIGNAL START OF MESSAGE. THEN TYPE MESSAGE AND
↑C TO SIGNAL END OF MESSAGE.

F. IF NO ECHO IS DESIRED (ON A CHARACTER BASIS FOR EXAMPLE
WHEN USING A TERMINAL THAT PRODUCES ITS OWN LOCAL COPY)
RAISE SR7.

308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363

5. PROGRAM DESCRIPTIONS

5.1 PRG0 - SINGLE CHARACTER LINE MODE DATA TEST

PRG0 TRANSMITS USER SPECIFIED DATA AND A CARRIAGE RETURN/LINE FEED EVERY 72ND CHARACTER.

5.2 PRG1 - BINARY COUNT PATTERN LINE MODE DATA TEST

PRG1 TRANSMITS A BINARY COUNT PATTERN. THIS PROGRAM IS THE SAME AS PRG0 EXCEPT FOR THE DATA TRANSMITTED.

5.3 PRG2 - SPECIAL MESSAGE TRANSMIT ONLY

PRG2 TRANSMITS THE MESSAGE
THE QUICK BROWN FOX JUMPED OVER THE LAZY DOGS BACK 0123456789.
NO DATA ERROR CHECKING IS PERFORMED BY THE PROGRAM.

5.4 PRG3 - RECEIVE/TRANSMIT MESSAGE TEST

PRG3 - RECEIVES DATA FROM A TERMINAL AND READS THE RECEIVED MESSAGE BACK, AND TYPES THE MESSAGE ON THE PDP-11 TTY WHEN THE MESSAGE IS TERMINATED. CHARACTERS MAY BE ECHOED BACK (IF REQUIRED) ON A CHARACTER BASIS THEREBY CREATING LOCAL COPY AS THE MESSAGE IS TYPED. CONTROL C (↑) IS USED BY THE PROGRAM TO SIGNAL THE START AND END OF THE MESSAGE.
TRANSMISSION MAY BEGIN AT THE TERMINAL WHEN A CR/LF IS RECEIVED AT THE TERMINAL. THIS PROGRAM IS RESTRICTED TO USE BY ONLY FULL DUPLEX MODEMS.

6.0 ERRORS

THERE ARE TWO TYPES OF ERRORS WHICH ARE DETECTED BY THESE TESTS LINE FAILURE AND DATA ERRORS.
LINE FAILURES ARE DETECTED AND REPORTED BY ALL TESTS, AND DATA ERRORS ARE DETECTED ONLY IN PRG 0 & 1 WHEN USING CONFIGURATIONS 1 OR 2. DATA ERRORS IN THE OTHER TESTS MAY BE DETECTED BY VISUAL INSPECTION OF THE DATA AT THE TERMINAL.
LINE FAILURES ARE REPORTED BY TYPING THE PC, THE RECEIVER CONTROL STATUS REGISTER ADDRESS, AND ITS CONTENTS. SEE THE PROGRAM LISTING FOR A DETAILED DESCRIPTION OF THE ERROR.
THE MOST FREQUENTLY ENCOUNTERED ERROR WILL PROBABLY BE THE LOSS OF CARRIER. THIS ERROR WILL BE REPORTED IF AFTER A LINE CONNECTION IS MADE THE CARRIER IS LOST, EITHER BY 'HANGING UP' OR A 'GLITCH' ON THE LINE CAUSING THE CARRIER TO MOMENTARILY DROP. IN EITHER INSTANCE THE PROGRAM DISCONNECTS THE DC11 FROM THE MODEM (BY CLEARING DATA TERMINAL READY) AND THE LINE WILL HAVE TO BE RECONNECTED TO RESUME TESTING.
IF IT IS PHYSICALLY IMPOSSIBLE TO GET TO THE DATA BUTTON WITHIN THE TIME ALLOTTED (APPROX. 10 SECONDS) TO MAKE THE LINE CONNECTION, THIS TIME MAY BE INCREASED BY PUTTING A LARGER NUMBER INTO THE DELAY. PATCH THE LARGER NUMBER INTO THE ADDRESS FOLLOWING THE DELAY EMT (BETWEEN RINTBG AND RINTBH). FOR EXAMPLE PATCHING IN 72460 WILL ALLOW APPROXIMATELY 30 SECONDS IN WHICH TO RESPOND.

364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390

DATA ERRORS ARE REPORTED BY TYPING THE PC, THE RECEIVER CONTROL REGISTER ADDRESS OF THE LINE THAT FAILED, WHAT THE DATA SHOULD HAVE BEEN, WHAT THE DATA WAS, AND THE CHARACTER NUMBER.

PC=XXXXXX 174010 DATA ERR. S/B 301 WAS 321 CHAR NO 23

THIS TYPEOUT INDICATES A DATA ERROR ON LINE 1
IF CONFIGURATION 2 IS SELECTED TWO ERROR TYPEOUTS MAY OCCUR FOR A SINGLE ERROR DEPENDING ON WHERE THE ERROR OCCURED. CONFIGURATION 2 COMPARES THE DATA RECEIVED AT THE CALLED DC11 WITH THE DATA TRANSMITTED BY THE CALLED DC11, AND ALSO THE DATA RECEIVED AT THE CALLING DC11 (CALLER) WITH THE DATA TRANSMITTED BY THE CALLED DC11.
IF FOR EXAMPLE A DATA ERROR OCCURED AT THE RECEIVER OF THE CALLING DC11 CAUSING IT TO TRANSMIT INCORRECT DATA TO THE CALLED DC11 TWO TYPEOUTS WILL OCCUR AS SHOWN BELOW:

PC=XXXXXX 174010 DATA ERR. S/B 301 WAS 321 CHAR NO 23

PC=XXXXXX 174000 DATA ERR. S/B 301 WAS 321 CHAR NO 23

THESE TYPEOUTS SHOW THAT THE RECEIVER ON LINE 0 WAS THE CAUSE OF THE ERROR AND THE RECEIVER ON LINE 1 RECEIVED THE CORRECT INCORRECT DATA.

391

.TITLE MAINDEC-11-DZDCB-B DC11 ON LINE TEST
.NLIST MC,MD,SEQ
.LIST ME
.ABS

;THIS TEST CHECKS THE DC11 USING MODEMS AND REVISES D98B
;REFER ALSO TO TEST D98B (DC11 OFF LINE TESTS)

;STARTING PROCEEDURE
;LOAD ADDRESS 200
;LOAD PROGRAM # INTO SR0-2
;STACK POINTER IS AT 1000
;PRESS START

;AVAILABLE PROGRAMS
;PRG0- SINGLE CHARACTER LINE MODE DATA TEST.
;PRG1- SPECIAL BINARY COUNT LINE MODE DATA TEST.
;PRG2- SPECIAL MESSAGE XMIT ONLY W/W/O PARITY
;PRG3- RECEIVE DATA TEST
;PRG4- DATA ECHO TEST (USES FACILITY AT MAYNARD)

;STANDARD SR SWITCH OPTIONS (SWITCH SET TO A 1)

;SR15- HALT ON ERROR.
;SR14- SCOPE.
;SR13- INHIBIT PRINTOUT
;SR12- INHIBIT TRACE
;SR11- INHIBIT ITERATION.
;SR10- LOOP PROGRAM.
;SR9- SELECT ROUTINE.
;SR8- DISABLE STALL MODE AND RUN FULL SPEED.
;SR6 THROUGH SR0 - NUMBER OF ROUTINE TO BE SELECTED.

000000 000000
000000 000002
000002 000000
000004 000006
000006 000000
000010 000012
000012 000000
000014 000016
000016 000000
000020 000022
000022 000000
000024 000026
000026 000000
000030 002116
000032 000340
000034 000036
000036 000000
000040 000042
000042 000000
000044 000046
000046 000000
000050 000052
000052 000000
000054 000056
000056 000000
000060 000062

MACHER: .=0
.+2 ;UNASSIGNED TRAP
HALT
.+2 ;SP OVERFLOW, BUS ERROR TRAP
HALT
.+2 ;RESERVED INSTRUCTION TRAP
HALT
.+2 ;TRACE TRAP
HALT
.+2 ;TRAP TO CALL IOX
HALT
.+2 ;POWER FAIL TRAP
HALT
EMTINT ;EMT TRAP
PRTY?
.+2
HALT
.+2
HALT ;TRAPPED TO PREVIOUS ADDRESS.
.+2
HALT ;TRAPPED TO PREVIOUS ADDRESS.
.+2
HALT ;TRAPPED TO PREVIOUS ADDRESS.
.+2
HALT ;TRAPPED TO PREVIOUS ADDRESS.
.+2

000062	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000064	000066	.+2	
000066	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000070	000072	.+2	
000072	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000074	000076	.+2	
000076	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000100	000102	.+2	
000102	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000104	000106	.+2	
000106	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000110	000112	.+2	
000112	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000114	000116	.+2	
000116	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000120	000122	.+2	
000122	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000124	000126	.+2	
000126	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000130	000132	.+2	
000132	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000134	000136	.+2	
000136	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000140	000142	.+2	
000142	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000144	000146	.+2	
000146	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000150	000152	.+2	
000152	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000154	000156	.+2	
000156	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000160	000162	.+2	
000162	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000164	000166	.+2	
000166	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000170	000172	.+2	
000172	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000174	000176	.+2	
000176	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000200	000202	.+2	
000202	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000204	000206	.+2	
000206	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000210	000212	.+2	
000212	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000214	000216	.+2	
000216	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000220	000222	.+2	
000222	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000224	000226	.+2	
000226	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000230	000232	.+2	
000232	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000234	000236	.+2	
000236	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000240	000242	.+2	

000242	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000244	000246	.+2	
000246	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000250	000252	.+2	
000252	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000254	000256	.+2	
000256	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000260	000262	.+2	
000262	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000264	000266	.+2	
000266	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000270	000272	.+2	
000272	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000274	000276	.+2	
000276	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000300	000302	.+2	
000302	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000304	000306	.+2	
000306	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000310	000312	.+2	
000312	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000314	000316	.+2	
000316	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000320	000322	.+2	
000322	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000324	000326	.+2	
000326	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000330	000332	.+2	
000332	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000334	000336	.+2	
000336	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000340	000342	.+2	
000342	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000344	000346	.+2	
000346	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000350	000352	.+2	
000352	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000354	000356	.+2	
000356	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000360	000362	.+2	
000362	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000364	000366	.+2	
000366	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000370	000372	.+2	
000372	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.
000374	000376	.+2	
000376	000000	HALT	; TRAPPED TO PREVIOUS ADDRESS.

```

;EQUATE STATEMENTS
177570 SR=177570
177776 CC=177776
177776 PSW=177776
001000 STKPTR=1000
000000 OPEN=0
100000 MANUAL=BIT15
100000 BIT15=100000
040000 BIT14=40000
020000 BIT13=20000
010000 BIT12=10000
004000 BIT11=4000
002000 BIT10=2000
001000 BIT9=1000
000400 BIT8=400
000200 BIT7=200
000100 BIT6=100
000040 BIT5=40
000020 BIT4=20
000010 BIT3=10
000004 BIT2=4
000002 BIT1=2
000001 BIT0=1
005726 POPSP=5726
022626 POPSP2=022626
000340 PRTY7=340
000300 PRTY6=300
000240 PRTY5=240
000200 PRTY4=200
000140 PRTY3=140
000100 PRTY2=100
000040 PRTY1=40
000000 PRTY0=0
104000 TYPE=EMT+0
104001 TYPES=EMT+1
104002 STALL=EMT+2
104003 ERROR=EMT+3
104004 DATCHK=EMT+4
104005 CHALT=EMT+5
104006 STRXV=EMT+6
104007 STTXV=EMT+7
104010 EHALT=EMT+10
104011 SAVREG=EMT+11
104012 RSTREG=EMT+12
104013 ERROR1=EMT+13
104014 ERRTX=EMT+14
104015 ERRRX=EMT+15
104016 DELAY=EMT+16
000007 BELL=007
000000 N=0
000000 A=0
000000 B=0

```

```

;POP THE STACK. SAME AS TST (6)+
;POP STACK TWICE. SAME AS CMP (6)+,(6)+
;PRIORITY LEVEL DEFINITIONS

```

B02

MAINDEC-11-DZDCB-B DC11 ON LINE TEST
DZDCBB.PFC

MACY11 27(732) 02-MAR-76 11:23 PAGE 14

000200	000200		=200		
	000167	001636	JMP	START	;GO TO START OF PROGRAM.
	001000		=1000		
001000	174000		RXCSR:	174000	;RECEIVER CSR
001002	174002		RXBUF:	174002	;RECEIVER BUFFER
001004	174004		TXCSR:	174004	;TRANSMITTER CSR
001006	174006		TXBUF:	174006	;TRANSMITTER BUFFER
001010	000000		RXVTR:	OPEN	;RECEIVER VECTOR
001012	000240		RXLVL:	PRTYS	;RECEIVER PRIORITY LEVEL
001014	000000		TXVTR:	OPEN	;TRANSMITTER VECTOR
001016	000240		TXLVL:	PRTYS	;TRANSMITTER PRIORITY LEVEL
001020	177560		TKS:	177560	;LSR CSR
001022	177562		TKB:	177562	;LSR BUFFER
001024	177564		TPS:	177564	;LSP CSR
001026	177566		TPB:	177566	;LSP BUFFER
001030	000060		TKVTR:	60	;LSP INTERRUPT VECTOR
001032	000200		TKLVL:	PRTY4	;LSR PRIORITY LEVEL
001034	000064		TPVTR:	64	;LSP INTERRUPT VECTOR
001036	000200		TPLVL:	PRTY4	;LSP PRIORITY LEVEL
001040	000000		PRGNUM:	OPEN	;CONTAINS CURRENT PROGRAMS
001042	000000		PRGID:	OPEN	;CONTAINS PROGRAM INDICATORS
001044	005712		PRGTAB:	PRG0	;PRG0 START ADDRESS
001046	006026			PRG1	;PRG1 START ADDRESS
001050	006130			PRG2	;PRG2 START ADDRESS
001052	006226			PRG3	;PRG3 START ADDRESS
001054	006706			PRG4	;PRG4 STARTING ADDRESS
001056	000004		PRGLIM:	4	
001060	002330		EMTTAB:	TYP	;POINTER TO TYPEOUT ROUTINE
001062	002452			TYP5	;POINTER TO CHAINED MESSAGES ROUTINE
001064	000000			OPEN	;POINTER TO RANDOM STALL ROUTINE
001066	001554			ERR	;POINTER TO ERROR ROUTINE
001070	001454			DTCHK	;POINTER TO DATA CHECK ROUTINE
001072	001430			CHLT	;COMMON HALT
001074	002250			STRVRV	;POINTER TO ROUTINE TO SET RCVR VECTOR AND PRIORITY
001076	002300			STXMTV	;POINTER TO ROUTINE TO SET XMIT VECTOR AND PRIORITY
001100	001442			EHLT	;POINTER TO ERROR HALT ROUTINE
001102	002150			SAVRG	;POINTER TO SAVE REGISTERS ROUTINE
001104	002210			RSTRG	;POINTER TO RESTORE REGISTERS ROUTINE
001106	001576			ERR1	;POINTER TO ERROR ROUTINE
001110	001710			TXERR	;POINTER TO XMIT ERROR ROUTINE
001112	001732			RXERR	;POINTER TO RCVR ERROR ROUTINE
001114	002522			DLY	;POINTER TO DELAY ROUTINE
001116	000000		PARBIT:	OPEN	
001120	000000		COUNT:	OPEN	
001122	000000		SAVE:	OPEN	
001124	000000		LINE:	OPEN	
001126	000000		ENDR4:	OPEN	
001130	000000		SRT1:	OPEN	
001132	0000C3		CONFIG:	OPEN	
001134	000000		NUMBER:	OPEN	

001136 000000
 001140 000000
 001142 000000
 001144 000000
 001146 000000
 001150 000000
 001152 000000
 001154 000000
 001156 000000
 001160 000000
 001162 177777
 001164 000000
 001166 000000

 001170 000000
 001172 000000

RECDAT: OPEN
 XMTDAT: OPEN
 CARMSK: OPEN
 CTRD: OPEN
 TXCSRT: OPEN
 RXCSRT: OPEN
 TEMP: OPEN
 SRT: OPEN
 INBUF: OPEN
 BUFP: OPEN
 CALLER: -1
 CALLED: OPEN
 OTBUF: OPEN

 TBUF: OPEN
 MODEM: OPEN

:CONTAINS ADDRESS FROM WHERE NEXT TRAN-
 :SMITTED CHAR. (IN OUTBUF) IS TO COME

:CONTAINS MODEM TYPE 0=103,4=202

E02

MAINDEC-11-DZDCB-B DC11 ON LINE TEST
DZDCBB.PFC

MAY11 27(732) 02-MAR-76 11:23 PAGE 17

001174	000000				OPEN	;CONTAINS ADDRESS FROM WHERE NEXT TRANS- ;MITTED CHAR. (CALLER'S LINE) IS TO COME
001400	001400				INCPRG: . =1400	;TYPE INCORRECT PROGRAM SELECTED.
001402	104000				TYPE	
001404	011763				AINPRG	
001406	104005				CHALT	;COMMON HALT.
001410	000207				RTS %7	;EXIT.
001412	104000				SETSR: TYPE	;TYPE SELECT OPTION MESSAGE.
001414	011766				ASETSR	
001416	104005				CHALT	;COMMON HALT.
001420	000207				RTS %7	;EXIT.
001422	104000				PRGEND: TYPE	;TYPE PROGRAM END.
001424	012150				APGEND	
001426	104005				CHALT	;COMMON HALT.
	000207				RTS %7	;EXIT.
001430	011600				:COMMON HALT ROUTINE	
001432	162700	000002			CHLT: MOV %6,%0	;DEVELOP ADDRESS OF CALLER.
001436	000000				SUB #2,%0	
001440	000002				HALT	;HALT. ADDRESS OF CALL INSTRUCTION
					RTI	;IN DATA LIGHTS.
					:CONDITIONAL ERROR HALT ROUTINE.	
001442	005767	176122			EHLT: TST SR	;CHECK FOR HALT ON ERROR.
001446	100001				BPL EHLTA	;BRANCH IF NO HALT DESIRED.
001450	000000				HALT	;HALT.
001452	000002				RTI	;IN DATA LIGHTS.
					:DATA CHECK ROUTINE.	
001454	046767	177462	177456		DTCHK: BIC CARMASK,XMTDAT	;CLEAR UN TRANSMITTED BITS
001462	126767	177450	177450		CMPB RECDAT,XMTDAT	;COMPARE TRANSMITTED AND RECEIVED
001470	001430				BEG DTCHKA	;CHARS. BRANCH IF SAME.
001472	004567	001164			JSR %5,OACNV	;GO TO OCTAL TO ASCII CONVERT.
001476	001136				RECDAT	;SOURCE ADDR.
001500	011714				CWAS	;DESTINATION ADDR.
001502	000003				3	;#OF DIGITS TO CONVERT.
001504	004567	001152			JSR %5,OACNV	;GO TO OCTAL TO ASCII CONVERT.
001510	001140				XMTDAT	;SOURCE ADDR.
001512	011702				CSB	;DESTINATION ADDR.
001514	000003				3	;#OF DIGITS TO CONVERT.
001516	004567	001140			JSR %5,OACNV	;GO TO OCTAL TO ASCII CONVERT.
001522	001000				RXCSP	;SOURCE ADDR.
001524	010776				CSRADD	;DESTINATION ADDR.
001526	000006				6	;#OF DIGITS TO CONVERT.
001530	104013				ERROR1	
001532	010776				CSRADD	
001534	004567	001644			JSR 5,BDCNV	;CONVERT
001540	001144				CTRD	;CHAR #
001542	011732				CRNUM	;TO DECIMAL
001544	000004				4	;4 BITS
001546	104013				ERROR1	
001550	011661				CERDAT	
001552	000002				DTCHKA: RTI	;EXIT.
001554	012767	177777	000104		ERR: MOV #-1,ERRB	;SET UP ONE MESSAGE CALL.
001562	012767	000240	000100		MOV #24,ERRB+2	
001570	005067	000112			CLR ERRE	
001574	000413				BR ERRA	
001576	011667	000064			ERR1: MOV %6,ERRB	;DEVELOP ADDT'L MESSAGE ADDR.
001602	017767	000060	000056		MOV %ERRB,ERRB	;STORE AT ERRB.

001610	012767	177777	000052		MOV	#-1,ERRB+2	
001616	012767	000002	000062		MOV	#2,ERRE	
001624	032767	020000	175736	ERRA:	BIT	#BIT13,SR	;INHIBIT ERROR PRINT?
001632	001020				BNE	ERRC	;BRANCH TO INHIBIT PRINT.
001634	011667	000044			MOV	%6,ERRD	;DEVELOP CALLING ADDR.
001640	162767	000002	000036		SUB	#2,ERRD	
001646	004567	001010			JSR	%5,OACNV	;GO TO OCTAL TO ASCII CONVERT.
001652	001704				ERRD		;SOURCE ADDR.
001654	011054				APC		;DESTINATION ADDR.
001655	000006				6		;#OF DIGITS TO CONVERT.
001660	104011				SAVREG		
001662	104001				TYPES		;TYPE:
001664	011047				EMD		;ERROR HEADER,
001666	000000			ERRB:	OPEN		;ADDT'L ERROR MESSAGE IF ANY.
001670	177777				-1		
001672	104012				RSTREG		
001674	104010			ERRC:	EHALT		;GO ERR HALT IF DESIRED.
001676	066716	000004			ADD	ERRE,%6	
001702	000002				RTI		;EXIT.
001704	000000			ERRD:	OPEN		
001706	000000			ERRE:	OPEN		
001710				TXERR:			
001710	004567	000746			JSR	%5,OACNV	;GO TO OCTAL TO ASCII CONVERT.
001714	001146				TXCSRT		;SOURCE ADDR.
001716	011077				ATXWAS		;DESTINATION ADDR.
001720	000006				6		;#OF DIGITS TO CONVERT.
001722	012767	011065	000076		MOV	#ATXCSR,CRXTXB	
001730	000410				BR	CRXTX	
001732				RXERR:			
001732	004567	000724			JSR	%5,OACNV	;GO TO OCTAL TO ASCII CONVERT.
001736	001150				RXCSRT		;SOURCE ADDR.
001740	011120				ARXWAS		;DESTINATION ADDR.
001742	000006				6		;#OF DIGITS TO CONVERT.
001744	012767	011106	000054		MOV	#ARXCSR,CRXTXB	
001752	011667	000046		CRXTX:	MOV	%6,CRXTXA	;DEVELOP ADDR OF ADTT'L ERROR MESSAGE.
001756	017767	000042	000040		MOV	%CRXTXA,CRXTXA	
001764	032767	020000	175576		BIT	#BIT13,SR	;INHIBIT PRINT?
001772	001017				BNE	CRXTXC	;BRANCH TO INHIBIT PRINT.
001774	011667	177704			MOV	%6,ERRD	;DEVELOP CALLING ADDR.
002000	162767	000002	177676		SUB	#2,ERRD	
002006	004567	000650			JSR	%5,OACNV	;GO TO OCTAL TO ASCII CONVERT.
002012	001704				ERRD		;SOURCE ADDR.
002014	011054				APC		;DESTINATION ADDR.
002016	000006				6		;#OF DIGITS TO CONVERT.
002020	104001				TYPES		;TYPE ERROR MESSAGE.
002022	011047				EMD		;ERR HEADER
002024	000000			CRXTXA:	OPEN		;ADDT'L ERR MESSAGE
002026	000000			CRXTXB:	OPEN		;TXCSR OR RXCSR CONTENTS.
002030	177777				-1		
002032	104010			CRXTXC:	EHALT		;GO HALT IF DESIRED.
002034	062716	000002			ADD	#2,%6	
002040	000002				RTI		;EXIT.
002042	012706	001000		START:	MOV	#STKPTR,%6	;SET BOTTOM OF SP STACK.
002046	005067	175724			CLR	PSW	

```

002052 012767 000006 175724      MOV      #6,MACHER
002060 016700 175504      MOV      SR,%0          ;(SR) TO R0
002064 042700 177770      BIC      #177770,%0     ;LIMIT (SR) TO BITS 2-0
002070 010067 176744      MOV      %0,PRGNUM     ;SAVE PROGRAM #
002074 020067 176756      CMP      %0,PRGLIM     ;COMPARE (SR) TO PROGRAM LIMIT
002100 101403      BLOS     CRTA          ;VALID PROGRAM NUMBER?
002102 004767 177272      JSR      %7,INCPRG     ;NO. INCORRECT PROGRAM SELECTED.
002106 000755      BR       START         ;START OVER.
002110 006300      ASL      %0            ;ROX2
002112 000170 001044      JMP      @PRGTAB(0)    ;GO TO SELECTED PROGRAM.

;EMT TRAP INTERPRETER
002116 011646      EMTINT: MOV  @%6,-(6)    ;GET SAVED PC.
002120 162716 000002      SUB      #2,@%6        ;DECREMENT PC BY 2.
002124 017616 000000      MOV      @%6,@%6
002130 006116      EMTA:  PCL  @%6          ;EMT ARG X 2.
002132 042716 177001      BIC      #177001,@%6   ;REMOVE 7 MSB.
002136 062716 001060      ADD      #EMTTAB,@%6   ;FORM EMT RTN ADDR.
002142 017616 000000      MOV      @%6,@%6
002146 000136      JMP      @%6+          ;GO TO EMT ROUTINE.

;SAVE REGS 0 TO 4 SUBROUTINE.
002150 012667 000030      SAVRG: MOV  (6)+,SVRPC   ;SAVE PC AND PSW.
002154 012667 000026      MCV      (6)+,SVRPSW
002160 010446      MOV      %4,-(6)      ;SAVE REGS 0 - 4
002162 010346      MOV      %3,-(6)      ;IN STACK.
002164 010246      MOV      %2,-(6)
002166 010146      MOV      %1,-(6)
002170 010046      MOV      %0,-(6)
002172 016746 000010      MOV      SVRPSW,-(6)  ;RESTORE PC AND PSW.
002176 016746 000002      MOV      SVRPC,-(6)
002202 000002      RTI
002204 000000      SVRPC: OPEN
002206 000000      SVRPSW: OPEN

;RESTORE REGS 0 TO 4 SUBROUTINE.
002210 012667 000030      RSTRG: MOV  (6)+,RSTPC   ;SAVE PC AND PSW.
002214 012667 000026      MOV      (6)+,RSTPSW
002220 012600      MOV      (6)+,%0      ;RESTORE REGS 0 - 4
002222 012601      MOV      (6)+,%1      ;FROM STACK.
002224 012602      MOV      (6)+,%2
002226 012603      MOV      (6)+,%3
002230 012604      MOV      (6)+,%4
002232 016746 000010      MOV      RSTPSW,-(6)  ;RESTORE PC AND PSW.
002236 016746 000002      MOV      RSTPC,-(6)
002242 000002      RTI
002244 000000      RSTPC: OPEN
002246 000000      RSTPSW: OPEN

;ROUTINE TO SET RECEIVER INTERRUPT VECTOR AND PRIORITY
002250 017667 000000 000012      STRVRV: MOV  @%6,STPRA+2 ;MOVE VECTOR ADDR TO STPR 2
002256 062716 000002      ADD      #2,@%6        ;SET UP EXIT
002262 016701 176522      MOV      RXVTR,%1
002266 012721 000000      STPRA:  MOV  #OPEN,(1)+ ;SET VECTOR ADDRESS
002272 016721 176514      MOV      RXLVL,(1)+   ;SET PRIORITY
002276 000002      RTI
;ROUTINE TO SET TRANSMITTER INTERRUPT VECTOR AND PRIORITY.
002300 017667 000000 000012      STXMTV: MOV  @%6,STPPA+2 ;MOVE VECTOR ADDR TO STPPA+2

```

```

002306 062716 000002          ADD      #2,2%6          ;SET UP EXIT
002312 016701 176476          MOV      TXVTR,%1
002316 012721 000000          STPPA:  MOV      #OPEN,(1)+ ;SET VECTOR ADDRESS.
002322 016721 176470          MOV      TXLVL,(1)+ ;SET PRIORITY
002326 000002          RTI          ;EXIT.

;SUBROUTINE TO OUTPUT ASCII MESSAGE ON TELETYPE PRINTER.
002330 010067 000164          TYP:    MOV      %0,SAVR0 ;SAVE R0
002334 011600          TYPAA:  MOV      2%6,%0 ;GET ADDRESS THAT CONTAINS MESSAGE ADDRESS.
002336 062716 000002          ADD      #2,2%6          ;SET UP EXIT.
002342 011000          MOV      2%0,%0 ;ADDRESS OF MESSAGE TO R0.
002344 112067 000100          TYPAA:  MOVB     (0),TYPDAT ;GET CHARACTER
002350 122767 000100 000072          CMPB    #100,TYPDAT ;CHECK FOR "2" CHARACTER
002356 001003          BNE     TYPC ;BRANCH IF NOT "2"
002360 016700 000134          MOV      SAVR0,%0 ;RESTORE R0
002364 000002          RTI          ;TERMINATOR CHAR. DONE. EXIT.
002366 122767 000045 000054          TYPC:   CMPB    #45,TYPDAT ;CHECK FOR "%".
002374 001412          BEQ     TYPF ;BRANCH IF "%".
002376 004767 000002          JSR     %7,TYPD ;TYPE CHAR IN TYPDAT
002402 000760          BR      TYPD
002404 116777 000040 176414          TYPD:   MOVB     TYPDAT,2TPB ;OUTPUT CHARACTER TO PRINTER
002412 105777 176406          TSTB    2TPS ;WAIT FOR DONE FLAG.
002416 100375          BPL     -4
002420 000207          RTS     %7 ;EXIT
002422 112767 000015 000020          TYPF:   MOVB     #15,TYPDAT ;MOVE CARRIAGE RETURN CODE TO TYPDAT
002430 004767 177750          JSR     %7,TYPD ;GO TYPE CHAR.
002434 112767 000012 000006          TYPG:   MOVB     #12,TYPDAT ;MOVE LF CODE TO TYPDAT.
002442 004767 177736          JSR     %7,TYPD ;GO TYPE CHAR.
002446 000736          BR      TYPD
002450 000000          TYPDAT: OPEN
;SUBROUTINE TO OUTPUT A SERIES OF ASCII MESSAGES ON TELETYPE PRINTER
002452 010067 000042          TYP:    MOV      %0,SAVR0
002456 011600          TYPSSA: MOV      2%6,%0 ;GET ADDRESS THAT CONTAINS MESSAGE ADDRESS
002460 062716 000002          ADD      #2,2%6          ;UPDATE TO NEXT MESSAGE ADDRESS
002464 011067 000024          MOV      2%0,TYPSB ;ADDRESS OF MESSAGE TO TYPSB
002470 022767 177777 000016          CMP     #-1,TYPSB ;CHECK FOR TERMINATOR
002476 001003          BNE     TYPSSA ;BRANCH IF NOT TERMINATOR.
002500 016700 000014          MOV      SAVR0,%0 ;RESTORE R0
002504 000002          RTI          ;TERMINATOR, EXIT
002506 016700 000006          TYPSSA: MOV      SAVR0,%0
002512 104000          TYPE
002514 000000          TYPSB:  OPEN
002516 000757          BR      TYPSAA
002520 000000          SAVRO:  OPEN

```

```

002522 011667 000034
002526 062716 000002
002532 017746 000024
002536 001407
002540 012746 000226
002544 005316
002546 001376
002550 005726
002552 005316
002554 001371
002556 005726
002560 000002
002562 000000

```

```

:SUBROUTINE TO DELAY A SPECIFIED NUMBER OF MILLISECONDS
DLY:  MOV    2%6,DLCNT      ;GET DELAY COUNT ADDRESS.
      ADD    #2,2%6        ;SET UP EXIT ADDRESS
      MOV    2DLCNT,-(6)   ;DELAY COUNT TO STACK
      BEQ    DLYC
DLYA: MOV    #226,-(6)     ;1 MSEC COUNT TO STACK
DLYB: DEC    2%6           ;DECREMENT 1 MSEC COUNT
      BNE    DLYB         ;BRANCH IF NOT 0.
      POPSP                ;ZERO UNCOVER MSECS. COUNT.
      DEC    2%6           ;DECREMENT IT
DLYC: BNE    DLYA         ;BR IF NOT DONE DELAYING
      POPSP                ;DONE
DLCNT: RTI                ;EXIT.
      OPEN                ;CONTAINS MILLISECONDS COUNT ADDRESS.

```

```

002564 012700 177777
002570 010067 000012
002574 010067 000010
002600 010067 000006
002604 000207
002606 000000
002610 000000
002612 000000

```

```

:SUBROUTINE TO INITIALIZE BINARY COUNT PATTERNS
INBIN: MOV    #-1,%0      ;SET ALL VARIABLES
      MOV    %0,RIND      ;TO MINUS 1
      MOV    %0,PT0
      MOV    %0,PT1
      RTS    7            ;EXIT
RIND:  OPEN
PT0:   OPEN
PT1:   OPEN

```

```

002614 016767 177770 177770
002622 005167 177764
002626 005167 177754
002632 001002
002634 005267 177752
002640 042767 177400 177744
002646 016767 177740 177734
002654 016701 177732
002660 000207

```

```

:SPECIAL BINARY COUNT PATTERN SUBROUTINE. EXITS WITH BIN CHAR IN R0
GTBIN: MOV    PT0,PT1    ;PREVIOUS BIN CHAR TO PT1
      COM    PT1
      COM    RIND
      BNE    .+6
      INC    PT1
      BIC    #177400,PT1 ;MASK TO 8 BITS
      MOV    PT1,PT0     ;SAVE BIN CHAR IN PT0
      MOV    PT1,%1      ;BIN CHAR TO R1.
      RTS    %7         ;EXIT.

```

```

002662 104011
002664 013500
002666 012501
002670 012502
002672 060201
002674 010003
002676 042703 177770
002702 062703 000060
002706 110341
002710 042700 000037
002714 006000
002716 006000
002720 006000
002722 005302
002724 001363
002726 104012

```

```

:OCTAL TO ASCII CONVERT ROUTINE
OACNV: SAVREG                ;SAVE REGS.
      MOV    2(5)+,%0      ;GET OCTAL VALUE.
      MOV    (5)+,%1      ;GET DESTINATION ADDR.
      MOV    (5)+,%2      ;GET CONVERT COUNT.
      ADD    %2,%1        ;DEVELOP ADDR TO STORE 1ST CHAR.
OACNVA: MOV    %0,%3
      BIC    #177770,%3   ;ISOLATE LEAST SIGNIFICANT DIGIT.
      ADD    #60,%3       ;CONVERT DIGIT TO ASCII.
      MOVB   %3,-(1)      ;STORE ASCII CHARACTER.
      BIC    #7,%0
      ROR    %0
      ROR    %0
      ROR    %0
      DEC    %2
      BNE    OACNVA
      RSTREG                ;DONE ALL DIGITS?
                          ;BRANCH IF NOT DONE.
                          ;RESTORE REGS.

```

J02

MAINDEC-11-DZDCB-B DC11 ON LINE TEST
DZDCBB.PFC

MACY11 27(732) 02-MAR-76 11:23 PAGE 22

002730 000205

RTS %5

;DONE. EXIT.

```

;SUBROUTINE TO GENERATE PARITY ON DATA FOR 5,6,7,8 LEVEL CODE.
;PARITY BIT IS THE MSB OF THE CHARACTER PARITY CAN BE EITHER
;EVEN OR ODD
;GENERATES ODD/EVEN PARITY.

```

002732	032777	001000	176040	GENPAR:	BIT	#BIT9,ARXCSR	;TEST LSB CHAR LENGTH
002740	001034				BNE	ISSOR7	;CHAR IS 5 OR 7 IF SET
002742	032777	002000	176030		BIT	#BIT10,ARXCSR	;TEST MSB CHAR LENGTH
002750	001014				BNE	SIX	;CHAR LENGTH IS C IF SET
002752	012767	000200	176136	EIGHT:	MOV	#BIT7,PARBIT	;PLACE PARITY BIT IN PROPER POSITION
002760	012767	000007	176132		MOV	#7,COUNT	;SET UP ROTATE COUNTER=7
002766	042701	177600			BIC	#177600,%1	;MASK OFF UNUSED BITS
002772	012767	177400	176142		MOV	#177400,CARMSK	
003000	000450				BR	DOIT	;GO AND GENERATE PARITY FOR 8
							;LEVEL CODE
003002	012767	000040	176106	SIX:	MOV	#BIT5,PARBIT	;PLACE PARITY BIT IN PROPER POSITION
003010	012767	000005	176102		MOV	#5,COUNT	;SET UP ROTATE COUNTER=5
003016	042701	177740			BIC	#177740,%1	;MASK OFF UNUSED BITS
003022	012767	177000	176112		MOV	#177000,CARMSK	
003030	000434				BR	DOIT	;GO AND GENERATE PARITY FOR
							;C LEVEL CODE
003032	032777	002000	175740	ISSOR7:	BIT	#BIT10,ARXCSR	;TEST MSB OF CHAR LENGTH
003040	001014				BNE	FIVE	;CHAR LENGTH=5 IF SET
003042	012767	000100	176046	SEVEN:	MOV	#BIT6,PARBIT	;PLACE PARITY BIT IN PROPER POSITION
003050	012767	000006	176042		MOV	#6,COUNT	;SET UP ROTATE COUNTER=6
003056	042701	177700			BIC	#177700,%1	;MASK OFF UNUSED BITS
003062	012767	177600	176052		MOV	#177600,CARMSK	
003070	000414				BR	DOIT	;GO AND GENERATE PARITY FOR 7
							;LEVEL CODE
003072	012767	000020	176016	FIVE:	MOV	#BIT4,PARBIT	;PLACE PARITY BIT IN PROPER POSITION
003100	012767	000004	176012		MOV	#4,COUNT	;SET UP ROTATE COUNTER=4
003106	042701	177760			BIC	#177760,%1	;MASK OFF UNUSED BITS
003112	012767	177740	176022		MOV	#177740,CARMSK	
003120	000400				BR	DOIT	;GO AND GENERATE PARITY FOR
							;5 LEVEL CODE
003122	010167	175774		DOIT:	MOV	%1,SAVE	;SAVE DATA
003126	006001			AGAIN:	ROR	%1	;ROTATE DATA
003130	103415				BCS	ADD1	;IF CARRY SET ADD IN PARBIT
003132	005367	175762		RTN:	DEC	COUNT	;DECREMENT COUNTER
003136	001373				BNE	AGAIN	;NOT DONE DO IT AGAIN
003140	032767	000040	176006		BIT	#BIT5,SRT	;DONE EVEN OR ODD PARITY?
003146	001403				BEQ	DONE	;IF EVEN FINISHED
003150	066767	175742	175744		ADD	PARBIT,SAVE	;IF ODD ADD IN ANOTHER 1
003156	016701	175740		DONE:	MOV	SAVE,%1	;PLACE DATA + PARITY BACK IN R1
003162	000207				RTS	7	;AND EXIT
003164	066767	175726	175730	ADD1:	ADD	PARBIT,SAVE	;ADD PARBIT TO DATA
003172	000757				BR	RTN	;RETURN TO COUNTER


```

;SUBROUTINE TO SELECT LINE AND LOAD VECTOR ASSIGNMENT
LINESEL: TYPE
          LDLINE
          HALT
003174 104000
003176 013216
003200 000000
003202 016701 174362
003206 042701 177407
003212 010167 175734
003216 012702 000770
003222 012703 001000
003226 012704 000004
003232 040213
003234 050123
003236 005304
003240 001374
003242 006201
003244 006201
003246 016101 007276
003252 010123
003254 022121
003256 005723
003260 010113
003262 022767 000004 175550
003270 001001
003272 000205
003274 006267 175652
003300 006267 175646
003304 006267 175642
003310 004567 177346
003314 001152
003316 012754
003320 000002
003322 104000
003324 012744
003326 000205
          MOV SR,%1 ;LOAD R1
          BIC #177407,%1 ;MASK OFF ALL BUT LINE BITS
          MOV %1,TEMP ;SAVE LINE #
          MOV #770,%2 ;LOAD IN MASK
          MOV #RXCSR,%3 ;LOAD ADDRESS OF REGISTERS
          MOV #4,%4 ;SET UP COUNTER
          BIC %2,(3) ;MASK OFF LINE BITS
          BIS %1,(3)+ ;LOAD IN LINE BITS.
          DEC %4
          BNE .-6
          ASR %1 ;POSITION SELECTED LINE
          ASR %1
          MOV VECTAR(1),%1 ;GET LINE VECTOR ADDRESS
          MOV %1,(3)+ ;LOAD INTO PROG. RXVTR
          CMP (1)+,(1)+ ;ADD +4 TO RXVTR TO = TXVTR
          TST (3)+ ;POINT TO PROG TXVTR
          MOV %1,(3) ;LOAD INTO PROG TXVTR
          CMP #4,PRGNUM ;RUNNING PROGRAM # 4
          BNE +4
          RTS 5 ;RETURN TO PROG 4
          ASR TEMP ;POSITION
          ASR TEMP ;LINE
          ASR TEMP ;NUMBER
          JSR %5,OACNV ;GO TO OCTAL TO ASCII CONVERT.
          TEMP ;SOURCE ADDR.
          TLINE ;DESTINATION ADDR.
          2 ;#OF DIGITS TO CONVERT.
          TYPE ;TYPE LINE # THAT
          ALINE ;WAS CALLED
          RTS 5

```

```

;SUBROUTINE TO LOAD BINARY COUNT PATTERN INTO OUTPUT
;BUFFER
003330 105067 175600
003334 012500
003336 012567 175602
003342 116720 175566
003346 105267 175562
003352 005367 175566
003356 001371
003360 000205
INFIL: CLRB NUMBER ;INITIALIZE BINARY COUNT
FILL: MOV (5)+,%0 ;GET ADDRESS
      MOV (5)+,CTRD ;GET COUNT
FILLA: MOVB NUMBER,(0)+ ;LOAD ADDRESS WITH BINARY COUNT
       INCB NUMBER ;INC. BINARY COUNT
       DEC CTRD ;DEC. COUNT
       BNE FILLA
       RTS 5 ;EXIT

```

```

:SUBROUTINE TO MOVE A VARIABLE NUMBER OF BYTES.
003362 104011 BMOVE: SAVREG ;SAVE REGS.
003364 012501 MOV (5)+,%1 ;GET FROM ADDRESS
003366 012502 MOV (5)+,%2 ;GET TO ADDRESS
003370 012503 MOV (5)+,%3 ;GET COUNT
003372 112122 BMOVA: MOV (1)+,(2)+ ;MOVE BYTE
003374 005303 DEC %3 ;DECREMENT COUNT
003376 001375 BNE BMOVA ;BRANCH IF NOT DONE.
003400 104012 RSTREG ;RESTORE REGS.
003402 000205 RTS %5 ;DONE EXIT

: BINARY TO DECIMAL ASCII CONVERT SUBROUTINE.
003404 104011 BDCNV: SAVREG ;SAVE REGS.
003406 012700 003562 MOV #DECVAL,%0 ;SET UP ADDR TO STORE DECIMAL ASCII IN R0
003412 013501 MOV (5)+,%1 ;BINARY VALUE TO R1.
003414 012567 000052 MOV (5)+,BDCNVC ;DESTINATION ADDR TO BDCNVC.
003420 012567 000050 MOV (5)+,BDCNVD ;COUNT TO BDCNVD.
003424 012702 003550 MOV #ADTEMP,%2 ;ADDR OF TEN POWER STRING TO R2.
003430 012767 000005 000104 BDCNVA: MOV #5,CNVCTR ;SET UP FOR 5 POWER CONVERSIONS.
003436 012267 000104 MOV (2)+,TENPWR ;MOVE POWER OF TEN VALUE TO TENPWR.
003442 004767 000034 JSR %7,SUBTEN ;PERFORM CONVERSION
003446 005367 000070 DEC CNVCTR ;DONE 5 CONVERSIONS?
003452 001371 BNE BDCNVA ;BRANCH IF NOT YET 5.
003454 166700 000014 SUB BDCNVD,%0 ;SET UP ADDR TO MOVE DECIMAL
003460 010067 000004 MOV %0,BDCNVB ;DATA FROM.
003464 004567 177672 JSR %5,BMOVE ;MOVE DECIMAL DATA TO DESTINATION.
003470 000000 BDCNVB: OPEN ;SRC ADDR.
003472 000000 BDCNVC: OPEN ;DEST ADDR.
003474 000000 BDCNVD: OPEN ;COUNT.
003476 104012 RSTREG ;RESTORE REGS.
003500 000205 RTS %5 ;YES, EXIT.
003502 005067 000036 SUBTEN: CLR DIGIT ;CLEAR DIGIT
003506 166701 000034 SUBTEN: SUB TENPWR,%1 ;SUBTRACT TEN POWER FROM BINARY VALUE.
003512 103403 BCS SUBTNB ;BRANCH IF UNSUCCESSFUL SUBTRACTION.
003514 005267 000024 INC DIGIT
003520 000772 BR SUBTNA
003522 066701 000020 000010 SUBTNB: ADD TENPWR,%1 ;RESTORE SUBTRACTED VALUE.
003526 062767 000060 ADD #60,DIGIT ;CONVERT (DIGIT) TO ASCII
003534 116720 000004 MOV B DIGIT,(0)+ ;MOVE ASCII CHAR TO DECVAL FIELD.
003540 000207 RTS %7 ;EXIT.
003542 000000 CNVCTR: OPEN
003544 000000 DIGIT: OPEN
003546 000000 TENPWR: OPEN
003550 023420 ADTEMP: 10000.
003552 001750 1000.
003554 000144 100.
003556 000012 10.
003560 000001 1.
003562 040 040 040 040 040 040 040 DECVAL: .BYTE 040,040,040,040,040,040
003565 040 040 040

:SUBROUTINE TO SET STOP CODE,SPEED, AND CHARACTER LENGTH PARAMETERS SET
:IN SR INTO TXCSR AND RXCSR.
003570 104000 SETPAR: TYPE ;TYPE: SELECT PARAMETERS.
003572 011406 SELPAR
003574 000000 HALT ;WAIT FOR USER.
003576 C16767 173766 175350 MOV SR,SRT

```

003604						STPARB: JSR	%5,0ACNV		:GO TO OCTAL TO ASCII CONVERT.
003604	004567	177052				SRT			:SOURCE ADDR.
003610	001154					APARM			:DESTINATION ADDR.
003612	012204					3			:#OF DIGITS TO CONVERT.
003614	000003					TYPE			
003616	104000					PARMTS			
003620	012166					STPARC: MOV	RXCSR,%3		:GET RXCSR ADDRESS
003622	016703	175152				MOV	TXCSR,%4		:GET TXCSR ADDRESS
003626	016704	175152				BIC	#3030,(3)		:CLEAR RXCSR PARAMETERS
003632	042713	003030				BIC	#430,(4)		:CLEAR TXCSR PARAMETERS
003636	042714	000430				BIT	#BIT4,SRT		:SEE IF SR BIT 4 IS SET.
003642	032767	000020	175304			BEQ	TBIT3		:BRANCH IF NOT SET.
003650	001402					BIS	#BIT8,(4)		:SET. SET STOP CODE TO A 1.
003652	052714	000400				BIT	#BIT3,SRT		:SEE IF SR BIT 3 IS SET.
003656	032767	000010	175270	TBIT3:		BEQ	TBIT2		:BRANCH IF NOT SET.
003664	001404					BIS	#BIT4,(4)		:SET BIT4 IN TXCSR AND RXCSR
003666	052714	000020				BIS	#BIT4,(3)		:(MSB OF SPEED SELECT BITS.)
003672	052713	000020				BIT	#BIT2,SRT		:SEE IF SR BIT 2 IS SET.
003676	032767	000004	175250	TBIT2:		BEQ	TBIT1		:BRANCH IF NOT SET.
003704	001404					BIS	#BIT3,(4)		:SET BIT3 IN TXCSR AND RXCSR
003706	052714	000010				BIS	#BIT3,(3)		:(LSB OF SPEED SELECT BITS).
003712	052713	000010				MOV	#177400,CARMSK		:SET CHARACTER MASK TO 8 BITS.
003716	012767	177400	175216	TBIT1:		BIT	#BIT1,SRT		:SEE IF SR BIT 1 IS SET.
003724	032767	000002	175222			BEQ	STPARA		:BRANCH IF NOT SET.
003732	001425					MOV	#177700,CARMSK		:CHANGE CHAR MASK TO 6 BITS.
003734	012767	177700	175200			BIS	#BIT10,(3)		:SET RXCSR BIT 10(MSB OF CHAR LENGTH BITS).
003742	052713	002000				BIS	#BIT10,-4(4)		
003746	052764	002000	177774			BIT	#BIT0,SRT		:SEE IF SR BIT0 IS SET.
003754	032767	000001	175172			BEQ	PAREX		:BRANCH IF NOT SET.
003762	001410					MOV	#177740,CARMSK		:CHANGE CHAR MASK TO 5 BITS.
003764	012767	177740	175150	TBIT0:		BIS	#BIT9,(3)		:SET RXCSR BIT9 (LSB OF CHAR LENGTH BITS).
003772	052713	001000				BIS	#BIT9,-4(4)		
003776	052764	001000	177774			PAREX: RTS	%7		:EXIT.
004004	000207					STPARA: BIT	#BIT0,SRT		:SEE IF SR BIT0 IS SET.
004006	032767	000001	175140			BEQ	STPARA-2		:BRANCH IF NOT SET.
004014	001773					MOV	#177600,CARMSK		:CHANGE CHAR MASK TO 7 BITS.
004016	012767	177600	175116			BR	TBIT0		
004024	000762					STTSPD: TYPE			:TYPE MESSAGE TO SET
004026	104000					SETSPD			:TRANSMITTER SPEED
004030	012713					CHALT			:WAIT FOR USER
004032	104005					MOV	SR,SRT		:GET SPEED
004034	016767	173530	175112			BIC	#177747,SRT		:MASK OFF UNUSED BITS
004042	042767	177747	175104			JSR	%5,0ACNV		:GO TO OCTAL TO ASCII CONVERT.
004050	004567	176606				SRT			:SOURCE ADDR.
004054	001154					APARM			:DESTINATION ADDR.
004056	012204					3			:#OF DIGITS TO CONVERT.
004060	000003					TYPE			
004062	104000					PARMTS			
004064	012166					BIS	SRT,@TXCSR		:LOAD SPEED BITS
004066	056777	175062	174710			RTS	7		:EXIT
004074	000207								

```

;SUBROUTINE TO MAKE LINE CONNECTION.
004076 017767 174676 175044 LINCON: MOV  @RXCSR,RXCSR
004104 017767 174674 175034      MOV  @TXCSR, TXCSR
004112 032767 000002 175026      BIT  @BIT1, TXCSR      ;IS CLEAR TO SEND UP?
004120 001057                BNE  LINEUP            ;YES CONNECTION IS MADE.

004122 042777 000101 174650 LINCA: BIC  @101, @RXCSR  ;CLEAR IE BIT AND DTR
004130 042777 000001 174646      BIC  @1, @TXCSR       ;CLEAR REQUEST TO SEND
004136 005777 174640                TST  @RXBUF           ;CLEAR DONE FLAG
004142 104000                TYPE                ;TYPE
004144 011603                MAKCON           ;'MAKE LINE CONNECTION'

004146 017767 174626 174774 LINC8: MOV  @RXCSR,RXCSR
004154 032767 020000 174766      BIT  @BIT13, RXCSR   ;DID YOU RING
004162 001771                BEQ  LINC8              ;GO WAIT FOR RING

004164 052777 000001 174606 LINC0: BIS  @BIT0, @RXCSR ;SET DATA TERMINAL READY
004172 052777 000001 174604      BIS  @BIT0, @TXCSR   ;SET REQUEST TO SEND
004200 104016                DELAY                ;WAIT 10 SECONDS FOR
004202 023420                10000.              ;CLEAR TO SEND

004204 017767 174570 174736 LINC2: MOV  @RXCSR,RXCSR
004212 005777 174564                TST  @RXBUF           ;CLEAR DONE
004216 017767 174562 174722      MOV  @TXCSR, TXCSR   ;GET TXCSR CONTENTS
004224 032767 000002 174714      BIT  @BIT1, TXCSR   ;IS CLEAR TO SEND UP?
004232 001003                BNE  LINC2            ;YES. GO TO LINC2
004234 104014                ERRTX                ;NO. PRINT ERROR MESSAGE
004236 012323                LINCHM              ;'CLEAR TO SEND NOT SET'
004240 000730                BR   LINCA            ;START OVER AGAIN

004242 017767 174532 174700 LINC4: MOV  @RXCSR,RXCSR ;CLEAR ALL FLAGS
004250 005777 174526                TST  @RXBUF           ;AND DONE

004254 104000                LINCH: TYPE                ;TYPE MESSAGE
004256 012373                LINMAD              ;CONNECTION IS MADE'
004260 000205                LINEUP: RTS  5        ;EXIT LINE CONNECTION ROUTINE WITH
;LINE CONNECTED AND THE INTERRUPTS TURNED OFF

;SUBROUTINE TO OVERLAY (CR LF) IN DATA PATTERN (EVERY 72.ND CHAR)
004262 012701 013254 OVRLAY: MOV  @OUTBUF,%1 ;GET OUTBUF ADDRESS
004266 012702 000016      MOV  @14,%2          ;GET COUNTER
004272 012711 105215 OVRLYA: MOV  @105215,(1) ;INSERT CR&LF
004276 062701 000110      ADD  @72,%1          ;ADD OFFSET
004302 005302                DEC  %2              ;DONE?
004304 001372                BNE  OVRLYA
004306 000207                RTS  7              ;EXIT

;SUBROUTINE TO FORM ASCII VALUE OF DC11 ADDRESS
004310 013567 174610 ADRS: MOV  @5, LINE    ;GET LINE ADDRESS
004314 004567 176342      JSR  %5, OACNV       ;GO TO OCTAL TO ASCII CONVERT.
004320 001124                LINE                ;SOURCE ADDR.
004322 010776                CSRADD              ;DESTINATION ADDR.
004324 000006                6                  ;#OF DIGITS TO CONVERT.

```

```

004326 000205          RTS      5          ;EXIT

004330 000240          RISR:   NOP
004332 010067 174566    MOV      %0,LINE
004336 006300          ASL      %0
004340 016067 007376 174432  MOV      RCSR(0),RXCSR ;GET ADDRESS OF INTERRUPTING DC11'S RCSR
004346 017767 174426 174574  MOV      @RXCSR,RXCSR ;GET CSR CONTENTS
004354 100570          BMI      DCERR ;GO TO DC11 ERROR ROUTINE
004356 105767 174566    TSTB    RXCSR ;TEST DONE
004362 001002          BNE
004364 104003          ERROR
004366 000002          RTI
004370 020067 174570    RISRA:  CMP      %0,CALLED ;DID CALLED LINE INTERRUPT?
004374 001020          BNE     RISRB ;BRANCH IF CALLER INTERRUPTED
004376 005767 174570    TST     MODEM ;CHECK MODEM TYPE
004402 001403          BEQ     RISRAA ;BRANCH IF 103
004404 005770 007476    TST     @RBUF(0) ;READ CALLED LINES DATA
004410 000002          RTI
004412 117077 007476 174536  RISRAA: MOVB    @RBUF(0),@INBUF ;STORE CHARACTER IN INPUT BUFFER
004420 005267 174532    INC     INBUF ;INCREMENT POINTER
004424 022767 015370 174524  CMP     @INBUF+100.,INBUF ;HAVE 100. CHARACTERS BEEN RECEIVED?
004432 001430          BEQ     RISRC ;GO CHECK DATA IF YES
004434 000002          RTI ;EXIT IF NO
004436 117077 007476 174514  RISRB:  MOVB    @RBUF(0),@RBUF ;STORE CHARACTER IN INTERMEDIATE DATA BUFFER
004444 005267 174510    INC     RBUF ;INCREMENT POINTER
004450 022767 013432 174502  CMP     @RBUF+10.,RBUF ;HAVE 10 CHARACTERS BEEN RECEIVED
004456 002401          BLT     .+4
004460 000002          RTI ;EXIT
004462 022767 000002 174442  CMP     #2,CONFIG ;RUNNING CONFIGURATION 2?
004470 001405          BEQ     RISRBB
004472 022767 013564 174460  CMP     @RBUF+100.,RBUF ;HAVE 100. CHARACTERS BEEN RECEIVED?
004500 001405          BEQ     RISRC ;GO CHECK DATA IF YES, OTHERWISE
004502 000002          RTI ;EXIT
004504 052770 000100 007576  RISRBB: BIS     @BIT6,@TCSR(0) ;START CALLERS TRANSMITTER
004512 000002          RTI ;EXIT

;CHECK DATA CONFIGURATION #1
004514 000240          RISRC:  NOP
004516 012767 000001 174420  MOV     #1,CTRD ;INITIALIZE CHARACTER COUNT
004524 012702 013420    MOV     @RBUF,%2 ;POINT R2 TO CALLERS RECEIVED DATA BUFFER
004530 012703 013254    MOV     @OUTBUF,%3 ;R3 = FIRST ADDRESS OF OUTPUT DATA BUFFER
004534 010267 174420    MOV     %2,RBUF ;RESTORE CALLERS RCVD DATA BUFFER PTR
004540 022767 000001 174364  CMP     #1,CONFIG ;CHECK CONFIGURATION
004546 001015          BNE     RISRCA
004550 112367 174364  RISRCA: MOVB    (3)+,XMTDAT ;GET TRANSMITTED CHARACTER
004554 112267 174356    MOVB    (2)+,RECDAT ;GET RECEIVED CHARACTER
004560 104004          DATCHK ;CHECK DATA
004562 005267 174356    INC     CTRD ;INCREMENT CHARACTER COUNT
004566 022767 000101 174350  CMP     #101,CTRD ;HAS ALL DATA BEEN CHECKED
004574 001365          BNE     RISRCA
004576 000167 000100    JMP     FINISH

;CHECK DATA CONFIGURATION #2
004602 000240          RISRD:  NOP

```

```

004604 012704 015224          MOV      #INBUF,%4           ;POINT R4 TO CALLED LINES RECEIVER
004610 010467 174342          MOV      %4,INBUF           ;DATA BUFFER & INIT. POINTER
004614 012767 013420 174346  RISRDA: MOV      #BUFF,TBUFFP
004622 016701 174336          MOV      CALLED,%1
004626 016167 007376 174144  MOV      RCSR(1),RXCSR
004634 112367 174300          MOV      (3)+,XMTDAT
004640 112267 174272          MOV      (2)+,RECDAT       ;COMPARE TRANSMITTED DATA WITH DATA
004644 104004          DATCHK                      ;RECEIVED BY CALLED LINE
004646 016701 174310          MOV      CALLER,%1
004652 016167 007376 174120  MOV      RCSR(1),RXCSR
004660 112467 174252          MOV      (4)+,RECDAT       ;COMPARE TRANSMITTED DATA WITH DATA
004664 104004          DATCHK                      ;RECEIVED BY CALLER
004666 005267 174252          INC      CTRO
004672 022767 000101 174244  CMP      #101,CTRO
004700 001350          BNE      RISRDA

004702 000240          FINISH: NOP
004704 016701 174254          MOV      CALLED,%1
004710 004567 176420          JSR      5,FILL
004714 013254          OUTBUF
004716 000144          100.
004720 104000          TYPE
004722 011761          ENDPAS
004724 052771 000100 007576  BIS      #BIT6,%TCSR(1)
004732 000240          NOP
004734 000002          RTI

004736 032767 040000 174204  :ERROR SERVICE ROUTINE
004744 001404 0CERR: BIT      #BIT14,RXCST     ;TEST OVERRUN
004746 104015          BEQ      RISRE
004750 010776          ERRRX
004752 005770 007476          CSRADD
TST      %RBUF(0)           ;READ BUFFER

004756 032767 010000 174164  RISRE: BIT      #BIT12,RXCST     ;TEST CARRIER TRANSITION
004764 001413          BEQ      RISRF
004766 032767 000004 174154  BIT      #BIT2,RXCST     ;TEST CARRIER
004774 001007          BNE      RISRF
004776 004767 000512          JSR      7,DISCON        ;DISCONNECT LINE
005002 104015          ERRRX                      ;ERROR! LOST CARRIER
005004 010776          CSRADD
005006 005770 007476          TST      %RBUF(0)       ;READ BUFFER (CLEARS DONE)
005012 000002          RTI

005014 012767 013254 174144  RISRF: MOV      %OUTBUF,%OTBUF     ;SET OUTPUT BUFFER POINTER
005022 012767 015224 174126  MOV      #INBUF,INBUF     ;SET INPUT BUFFER POINTER
005030 012767 013420 174122  MOV      #BUFF,%BUFF      ;SET INTERMEDIATE BUFFER POINTER
005036 012767 013420 174124  MOV      #BUFF,TBUFFP     ;SET POINTER FOR CONFIG #2 TRANSMITTER
005044 032767 020000 174076  BIT      #BIT13,RXCST     ;CHECK RING INDICATOR
005052 001001          BNE      .+4              ;BRANCH IF RING
005054 000002          RTI
005056 004567 175600          JSR      %5,%OACNV        ;GO TO OCTAL TO ASCII CONVERT.
005062 001124          LINE                      ;SOURCE ADDR.
005064 012754          TLINE                     ;DESTINATION ADDR.
005066 000002          2                          ;#OF DIGITS TO CONVERT.
005070 104000          TYPE
005072 012744          ALINE

```

```

005074 010067 174064      MOV      %0,CALLED
005100 000000      HALT
005102 116767 172462 174062      MOVB    SR,MODEM      ;GET MODEM TYPE
005110 042767 177773 174054      BIC     #177773,MODEM ;0=103,4=202
005116 116767 172446 174006      MOVB    SR,CONFIG
005124 042767 177774 174000      BIC     #177774,CONFIG
005132 001044      BNE     RISRFC      ;GO TO SERVICE FOR CONFIG 1 OR 2
005134 004767 000376      JSR     7,CONN      ;CONNECT LINE IF CONFIGURATION 0
005140 104000      TYPE   ;TYPE MESSAGE TO PRESS DATA
005142 013155      BUTTON ;BUTTON ON DATA PHONE
005144 104016      DELAY  ;WAIT FOR CARRIER
005146 023420 10000. ;10 SECONDS
005150 005770 007476      TST     @RBUF(0)    ;READ BUFFER TO CLEAR DONE
005154 005770 007376      TST     @RCSR(0)    ;CLEAR ERROR FLAGS
005160 032770 000002 007576      BIT     @BIT1,@TCSR(0) ;TEST FOR CLEAR TO SEND
005166 001004      BNE     RISRFB
005170 104003      ERROR  ;ERROR! DID NOT RECEIVE CLEAR TO SEND
                                ;WITHIN TIME ALLOTTED (10 SEC.)
005172 004767 000316      JSR     7,DISCON   ;DISCONNECT LINE
005176 000002      RTI     ;AND EXIT

005200 016067 007576 173576 RISRFB: MOV     TCSR(0),TXCSR ;GET CALLED LINES TXCSR ADDRESS
005206 004767 176356      JSR     7,SETPAR   ;LOAD USER PARAMETERS
005212 104000      TYPE   ;TYPE 'LINE CONNECTION
005214 012373      LINPAD ;MADE'
005216 004567 175440      JSR     %5,OACNV   ;GO TO OCTAL TO ASCII CONVERT.
005222 001132      CONFIG ;SOURCE ADDR.
005224 012443      TCONFIG ;DESTINATION ADDR.
005226 000002      2      ;#OF DIGITS TO CONVERT.
005230 104000      TYPE
005232 012422      ACONFIG
005234 052770 000100 007576      BIS     @BIT6,@TCSR(0)
005242 000002      RTI     ;AND EXIT

                                ;HERE IF CONFIGURATION 1 OR 2
005244 104000      RISRFC: TYPE
005246 013053      MRU
005250 000000      HALT
005252 016701 172312      MOV     SR,%1
005256 042701 177740      BIC     @177740,%1   ;GET LINE #
005262 010167 173636      MOV     %1,LINE     ;MASK UNUSED BITS
005266 004567 175370      JSR     %5,OACNV   ;GO TO OCTAL TO ASCII CONVERT.
005272 001124      LINE  ;SOURCE ADDR.
005274 013152      URA   ;DESTINATION ADDR.
005276 000002      2      ;#OF DIGITS TO CONVERT.
005300 104000      TYPE   ;REPORT LINE # ON TTY
005302 013122      UR
005304 006301      ASL    %1
005306 010167 173650      MOV     %1,CALLER  ;SAVE CALLERS LINE #
005312 004767 000220      JSR     7,CONN     ;CONNECT CALLED LINE
005316 052771 000001 007376      BIS     @BIT0,@RCSR(1) ;SET DTR ON CALLERS LINE
005324 104000      TYPE   ;TYPE MESSAGE TO PRESS DATA
005326 013155      BUTTON ;ON DATA PHONE
005330 104016      DELAY ;WAIT 10 SECONDS FOR CLEAR TO SEND
005332 023420 10000. ;SET AT CALLED LINE
005334 027071 007476 007476      CMP     @RBUF(0),@RBUF(1) ;READ BUFFERS

```

```

005342 027071 007376 007376      CMP      @RCSR(0),@RCSR(1);READ CSRS TO CLEAR ERROR FLAGS
005350 032770 000002 007576      BIT      @BIT1,@TCSR(0) ;TEST FOR CLEAR TO SEND AT CALLED LINE
005356 001012      BNE     RISRFF
005360 104003      ERROR   ;ERROR! CLEAR TO SEND NOT SET AT CALLED LINE
005362 004767 000126      RISRFD: JSR      7,DISCON ;DISCONNECT
005366 042771 000001 007376      BIC     @BIT0,@RCSR(1) ;LINE
005374 042771 000001 007576      BIC     @BIT0,@TCSR(1)
005402 000002      RTI     ;AND EXIT

005404 022767 000002 173520  RISRFF: CMP      @2,CONFIG
005412 001414      BEQ     RISRFG
005414 022771 000004 007376      CMP     @BIT2,@RCSR(1) ;CHECK CARRIER AT CALLERS LINE
005422 001003      BNE     RISRFE
005424 104003      ERROR   ;ERROR! NO CARRIER AT CALLERS LINE
005426 000167 177730      JMP     RISRFD ;GO DISCONNECT LINES

005432 016167 007376 173340  RISRFE: MOV     RCSR(1),RXCSR
005440 000167 177534      JMP     RISRFB ;GO GET PAREMETERS AND ENABLE
;CALLED TRANSMITTER AND EXIT

;HERE IF CONFIGURATION 2
005444 032771 000002 007576  RISRFG: BIT      @BIT1,@TCSR(1) ;TEST CALLERS CLEAR TO SEND
005452 001003      BNE     RISRFH
005454 104003      ERROR   ;ERROR! NO CTS AT CALLERS LINE
005456 000167 177700      JMP     RISRFD ;GO DISCONNECT LINE AND EXIT
005462 016067 007376 173310  RISRFH: MOV     RCSR(0),RXCSR
005470 016167 007576 173306      MOV     TCSR(1),TXCSR
005476 004767 176066      JSR     7,SETPAR ;GO GET PARAMETERS FOR CALLERS
;TRANSMITTER AND CALLED RECEIVER

005502 016167 007376 173270      MOV     RCSR(1),RXCSR
005510 000167 177464      JMP     RISRFB

;SUBROUTINE TO DISCONNECT LINE RO HAS LINE #
005514 042770 000001 007376  DISCON: BIC     @BIT0,@RCSR(0)
005522 042770 000001 007576      BIC     @BIT0,@TCSR(0)
005530 005770 007376      TST     @RCSR(0)
005534 000207      RTS     7

;SUBROUTINE TO CONNECT LINE RO HAS LINE #
005536 052770 000001 007376  CONN:  BIS     @BIT0,@RCSR(0) ;SET DATA TERMINAL READY
005544 052770 000001 007576      BIS     @BIT0,@TCSR(0) ;SET REQUEST TO SEND
005552 000207      RTS     7

```



```

;*****
005554 000240 TISR: NOP
005556 006300 ASL %0 ;RC HAS LINE #
005560 105770 007576 TSTB @TCSR(0) ;CHECK FOR DONE
005564 100402 BMI TISRA ;BRANCH IF DONE
005566 104003 ERROR ;ERROR! FALSE INTERRUPT
005570 000002 TISRAA: RTI ;EXIT
005572 020067 173364 TISRA: CMP %0,CALLER ;DID CALLER INTERRUPT
005576 001015 BNE TISRC
005600 117770 173364 007676 MOVB @TBUFFF,@TBUF(0) ;TRANSMIT
005606 005267 173356 INC TBUFFP ;STEP POINTER
005612 022767 013564 173350 CMP @BUFF+100.,TBUFFP
005620 001003 BNE .+10
005622 042770 000100 007576 BIC @BIT6,@TCSR(0)
005630 000002 RTI
005632 117770 173330 007676 TISRC: MOVB @OTBUFF,@TBUF(0) ;TRANSMIT THE NEXT CHARACTER
005640 005267 173322 INC OTBUFF ;STEP POINTER TO NEXT CHAR.
005644 005767 173262 TST CONFIG ;WAS CONFIGURATION 0 SELECTED
005650 001010 BNE TISR8 ;BRANCH IF CONFIG #1 OR #2
005652 022767 015224 173306 CMP @OUTBUF+100.,OTBUFF;HAVE 1000. CHARS. BEEN SENT
005660 001343 BNE TISRAA ;EXIT IF NOT
005662 012767 013254 173276 TISR8B: MOV @OUTBUF,OTBUFF ;RESET POINTER
005670 000002 RTI ;AND EXIT

005672 022767 013420 173266 TISR8: CMP @OUTBUF+100.,OTBUFF;HAVE 100. CHARS. BEEN SENT?
005700 001333 BNE TISRAA ;EXIT IF NOT
005702 042770 000100 007576 BIC @BIT6,@TCSR(0) ;DISABLE TRANSMITTER INTERRUPT
005710 000764 BR TISR8B ;RESET POINTER AND EXIT

```

:PRGO - SINGLE CHARACTER LINE MODE TEST.

```

005712 000240
005714 104000
005716 011127
005720 104000
005722 011543
005724 000000
005726 116701 171636
005732 010167 005316
005736 004567 175420
005742 013254
005744 013255
005746 001747
005750 004767 176306
005754 004767 001266
005760 004767 001242
005764 004767 001202
005770 012767 000340 172000
005776 012702 000100
006002 012701 174000
006006 004567 001116
006012 104000
006014 011603
006016 005067 171754
006022 000001
006024 000776

```

```

*****
PRGO:  NOP                               ;BEGIN PRGO
      TYPE                               ;TYPE
      POTIT                              ;PROGRAM TITLE
      TYPE
      SELCAR
      HALT
      MOVB SR,%1                          ;GET USER SPECIFIED DATA
      MOV %1,OUTBUF                       ;AND
      JSR 5,BMOVE                         ;LOAD
      OUTBUF                              ;INTO
      OUTBUF+1                            ;OUTPUT
      999.                                ;BUFFER
      JSR 7,OVRLAY                        ;OVER LAY CR,LF'S IN DATA
      JSR 7,LDPRI                         ;LOAD PRIORITY LEVEL IN VECTOR+2
      JSR 7,LDTVEC                        ;LOAD TRANSMITTER VECTORS
      JSR 7,LDVECS                        ;LOAD RECEIVER VECTORS
      MOV #PARTY7,PSW                     ;SET PROCESSOR PRIORITY=7
      MOV #BIT6,%2                        ;SET IE
      MOV #174000,%1                      ;BIT IN
      JSR 5,MOVIT                          ;ALL RECEIVERS
      TYPE
      MAKCON                              ;'MAKE LINE CONNECTION'
      CLR PSW                             ;SET PROCESSOR PRIORITY=0
PRGOA: WAIT
      BR PRGOA                            ;WAIT
      HERE

```

:PRG1 - SPECIAL BINARY COUNT PATTERN LINE MODE TEST.

```

006026 104000
006030 011173
006032 012767 105215 005214
006040 004567 175264
006044 013256
006046 001750
006050 012767 000100 173056
006056 004767 001164
006062 004767 001140
006066 004767 001100
006072 012767 000340 171676
006100 012702 000100
006104 012701 174000
006110 004567 001014
006114 104000
006116 011603
006120 005067 171652
006124 000001
006126 000776

```

```

*****
PRG1:  TYPE                               ;TYPE PROGRAM TITLE.
      PITIT
      MOV #105215,OUTBUF                 ;LOAD CR LF
      JSR 5,INFIL                       ;LOAD OUTPUT
      OUTBUF+2                           ;WITH BINARY
      1000.                              ;COUNT PATTERN
      MOV #100,NUMBER                    ;LOAD PRIORITY LEVEL IN VECTOR +2
      JSR 7,LDPRI                         ;LOAD TRANSMITTER VECTORS
      JSR 7,LDTVEC                        ;LOAD RECEIVER VECTORS
      JSR 7,LDVECS                        ;LOAD RECEIVER VECTORS
      MOV #PARTY7,PSW                     ;SET PROCESSOR PRIORITY=7
      MOV #BIT6,%2                        ;GET IE BIT
      MOV #174000,%1                      ;GET FIRST CSR ADDRESS
      JSR 5,MOVIT                          ;AND MOVE IT
      TYPE
      MAKCON                              ;'MAKE LINE CONNECTION'
      CLR PSW                             ;SET PROCESSOR PRIORITY=0
PRG1C: WAIT
      BR PRG1C                            ;WAIT
      HERE

```

:PRG2-SPECIAL MESSAGE TRANSMIT ONLY THIS PROGRAM TRANSMITS
:THE MESSAGE 'A QUICK BROWN FOX JUMPED OVER THE LAZY DOGS'
:BACK 1234567890.'

```

006130 104000
006132 011242

```

```

PRG2:  TYPE                               ;TYPE PROGRAM
      P2TIT                              ;TITLE

```

006134	004567	175034		JSR	5,LINSEL	
006140	004767	175424		PRG2AA: JSR	7,SETPAR	:GO SET PARAMETERS
006144	052777	000001	172632	BIS	#BIT0,2TXCSR	:SET REQUEST TO SEND
006152	004567	175720		PRG2A: JSR	5,LINCON	:GO MAKE LINE CONNECTION
006156	012702	012574		PRG2B: MOV	#PRG2M,%2	:GET ADDRESS OF MESSAGE
006162	112201			PRG2C: MOVB	(2)+,%1	:GET FIRST CHARACTER
006164	020127	000045		CMP	%1,%1	:TERMINATOR CHARACTER
006170	001772			BEQ	PRG2B	:RESEND MESSAGE
006172	032767	000100	172754	BIT	#BIT6,SRT	:PARITY ENABLED
006200	001402			BEQ	+6	
006202	004767	174524		JSR	7,GENPAR	:GENERATE PARITY
006206	004567	175664		JSR	5,LINCON	:CHECK LINE CONNECTION
006212	010177	172570		MOV	%1,2TXBUF	:LOAD BUFFER
006216	105777	172562		PRG2D: TSTB	2TXCSR	:AND WAIT FOR CHARACTER
006222	100375			BPL	-4	:TO BE TRANSMITTED
006224	000756			BR	PRG2C	:GET NEXT CHARACTER.

;PRG3-PROGRAM TO RECEIVE A MESSAGE.

006226	104000			PRG3: TYPE		:TYPE PROGRAM
006230	011310			P3TIT		:TITLE
006232	004567	174736		JSR	5,LINSEL	
006236	004767	175326		JSR	7,SETPAR	:GET PARAMETERS
006242	004767	175560		JSR	7,STTSPD	:GET TRANSMITTER SPEED
006246	012706	000776		PRG3A: MOV	#STKPTR-2,%6	:REPOSITION STACK POINTER
006252	052777	000001	172524	BIS	#BIT0,2TXCSR	:SET REQUEST TO SEND
006260	004567	175612		JSR	5,LINCON	:MAKE LINE CONNECTION
006264	104006			STRXV		:SET RECEIVER INTERRUPT
006266	006320			RINT3		:TO THIS ADDRESS
006270	104007			STTXV		:SET TRANSMITTER INTERRUPT
006272	006456			TINT3		:TO THIS ADDRESS
006274	012767	006566	171562	MOV	#TPINT,64	:LOAD TELEPRINTER VECTOR
006302	012767	000200	171556	MOV	#PRTY4,66	:AND PRIORITY
006310	004567	000310		PRG3B: JSR	5,INIT3	:INITIALIZE PROGRAM
006314	000001			WAIT		:DO
006316	000776			BR	-2	:NOTHING
006320	017767	172454	172622	RINT3: MOV	2RXCSR,RXCSR	:GET RXCSR DATA
006326	100436			BMI	RINT3C	:BRANCH IF ERROR
006330	105767	172614		TSTB	RXCSR	:TEST
006334	100042			BPL	RINT3D	
006336	005703			TST	%3	:IS THIS THE FIRST
006340	100443			BMI	RINT3E	:CHARACTER BRANCH IF YES.
006342	117711	172434		MOVB	2RXBUF,(1)	:GET DATA
006346	105767	171216		TSTB	SR	:ECHO OPTION SELECTED
006352	100405			BMI	RINT3A	
006354	105777	172424		TSTB	2TXCSR	
006360	100375			BPL	-4	
006362	111177	172420		MOVB	(1),2TXBUF	:ECHO CHARACTER
006366	122103			RINT3A: CMPB	(1)+,%3	:LAST CHARACTER RECEIVED
006370	001401			BEQ	+4	
006372	000002			RTI		:EXIT
006374	042777	000100	172376	BIC	#BIT6,2RXCSR	:DISABLE RECEIVER
006402	012701	013254		MOV	#OUTBUF,%1	:INITIALIZE BUFFER POINTER
006406	052777	000100	172370	BIS	#BIT6,2TXCSR	:ENABLE TRANSMITTER
006414	052777	000100	172402	BIS	#BIT6,2TPS	:ENABLE TELEPRINTER

006422	000002			RINT3B:	RTI		:EXIT
006424	104015			RINT3C:	ERRRX		:TYPE ERROR MESSAGE
006426	012675				LFAIL		
006430	042777	000100	172342		BIC	#BIT6,@RXCSR	:DISABLE RECEIVER
006436	000167	000154			JMP	TPINTA	:RESTART PROGRAM
006442	104015			RINT3D:	ERRRX		:TYPE
006444	011006				RINTM:		:ERROR MESSAGE
006446	000002				RTI		:EXIT
006450	017703	172326		RINT3E:	MOV	@RXBUF,%3	
006454	000002			RINT3F:	RTI		
006456	017767	172322	172462	TINT3:	MOV	@TXCSR,TXCSR	:GET TXCSR DATA
006464	105767	172456			TSTB	TXCSR	:TEST
006470	100005				BPL	TINT3B	
006472	111177	172310			MOVB	(1),@TXBUF	:TRANSMIT CHARACTER
006476	122103				CMPB	(1)+,%3	:ALL CHARACTERS TRANSMITTED
006500	001422				BEQ	TINT3C	
006502	000002				RTI		:RETURN TO MAIN PROGRAM
006504	017767	172314	172440	TINT3B:	MOV	@TPS,TEMP	:SAVE TELEPRINTER STATUS
006512	005077	172306			CLR	@TPS	:DISABLE INTERRUPT
006516	105777	172302			TSTB	@TPS	:WAIT FOR
006522	100375				BPL	-.4	:TELEPRINTER TO FINISH
006524	104014				ERRTX		:TYPE
006526	011027				TINTM		:ERROR MESSAGE
006530	105777	172270			TSTB	@TPS	:WAIT FOR TELEPRINTER
006534	100375				BPL	-.4	:TO FINISH
006536	016777	172410	172260		MOV	TEMP,@TPS	:RESTORE TELEPRINTER STATUS
006544	000002				RTI		:EXIT
006546	042777	000100	172230	TINT3C:	BIC	#BIT6,@TXCSR	:DISABLE INTERRUPT
006554	032777	000100	172242		BIT	#BIT6,@TPS	:IS TTY ACTIVE
006562	001415				BEQ	TPINTA	
006564	000002				RTI		
006566	111277	172234		TPINT:	MOVB	(2),@TPB	:TYPE CHARACTER
006572	122203				CMPB	(2)+,%3	:WAS THIS THE LAST CHAR.
006574	001401				BEQ	+.4	
006576	000002				RTI		
006600	042777	000100	172216		BIC	#BIT6,@TPS	:DISABLE INTERRUPT
006606	032777	000100	172170		BIT	#BIT6,@TXCSR	:IS TRANSMITTER ACTIVE
006614	001002				BNE	+.6	
006616	012716	006246		TPINTA:	MOV	@PRG3A,(6)	
006622	000002				RTI		:EXIT
006624	012701	013254		INIT3:	MOV	@OUTBUF,%1	:GET BUFFER ADDRESS WHERE
006630	010102				MOV	%1,%2	:RECEIVED DATA IS TO BE STORED
006632	052703	100000			BIS	#BIT15,%3	:SET BIT 15
006636	012767	105215	004410		MOV	#105215,@OUTBUF	:LOAD CRLF IN FIRST 2 ADDRESSES
006644	105777	172134			TSTB	@TXCSR	:WAIT FOR
006650	100375				BPL	-.4	:TRANSMITTER
006652	112177	172130			MOVB	(1)+,@TXBUF	
006656	105777	172122			TSTB	@TXCSR	:SEND
006662	100375				BPL	-.4	:CRLF
006664	112177	172116			MOVB	(1)+,@TXBUF	
006670	105777	172110			TSTB	@TXCSR	
006674	100375				BPL	-.4	
006676	052777	000100	172074		BIS	#BIT6,@RXCSR	:ENABLE RECEIVER INTERRUPT
006704	000205				RTS	5	:EXIT INITIALIZATION ROUTINE

006706	104000			PRG4:	TYPE				
006710	011337				P4TIT				
006712	004567	174256			JSR	5,LINSEL			
006716	000005				RESET				
006720	004767	174644			JSR	7,SETPAR			
006724	052777	000001	172046		BIS	#BIT0,@RXCSR	;	SET DATA TERMINAL READY AND REQUEST	
006732	052777	000001	172044		BIS	#BIT0,@TXCSR	;	ON USER SELECTED LINE	
006740	104000			PRG4A:	TYPE			;	TYPE MESSAGE TO MAKE
006742	011603				MAKCON			;	LINE CONNECTION
006744	000000				HALT			;	WAIT FOR USER TO MAKE LINE CONNECTION
006746	005777	172026			TST	@RXCSR	;	READ RXCSR TO CLEAR ERROR FLAGS	
006752	005777	172024			TST	@RXBUF	;	READ BUFFER	
006756	032777	000002	172020		BIT	#BIT1,@TXCSR	;	TEST FOR CLEAR TO SEND	
006764	001003				BNE	PRG4B			
006766	104000			PRG4AA:	TYPE			;	TYPE ERROR MESSAGE
006770	012323				LINCHM				
006772	000762				BR	PRG4A		;	AND TRY AGAIN
006774	104000			PRG4B:	TYPE				
006776	012373				LINMAD				
007000	005067	000122			CLR	ERRCNT			
007004	012702	012574		PRG4BB:	MOV	#PRG2M,%2	;	GET BASE ADDRESS OF DATA TO BE TRANSMITTED	
007010	112201			PRG4C:	MOVB	(2)+,%1	;	GET A CHARACTER	
007012	020127	000045			CMP	%1,%1	;	WAS IT THE TERMINATOR?	
007016	001440				BEQ	PRG4E			
007020	032767	000100	172126		BIT	#BIT6,SRT	;	WAS PARITY OPTION SELECTED?	
007026	001402				BEQ	+6	;	BRANCH IF NO PARITY DESIRED	
007030	004767	173676			JSR	7,GENPAR	;	GENERATE PARITY ON CHAR. IN R1	
007034	032777	000002	171742		BIT	#BIT1,@TXCSR	;	CHECK CLEAR TO SEND	
007042	001751				BEQ	PRG4AA	;	TYPE ERROR MSG. IF NOT SET	
007044	010177	171736			MOV	%1,@TXBUF	;	TRANSMIT THE CHARACTER	
007050	005777	171724			TST	@RXCSR	;	ANY ERROR FLAGS?	
007054	100001				BPL	+4	;	BRANCH IF NO ERROR FLAGS	
007056	104003				ERROR		;	ERROR! SOME ERROR FLAG IS SET	
007060	105777	171714			TSTB	@RXCSR	;	WAIT FOR THE RECEIVER TO RECEIVE	
007064	100375				BPL	-4	;	THE TRANSMITTED CHARACTER	
007066	117703	171710			MOVB	@RXBUF,%3	;	SAVE IT IN R3	
007072	046701	172044			BIC	CARMSK,%1	;	CLEAR NON- TRANSMITTED BITS	
007076	120103				CMPSB	%1,%3	;	WAS RECEIVED & TRANSMITTED DATA THE SAME	
007100	001403				BEQ	PRG4D			
007102	104003				ERROR		;	ERROR! DATA ERROR	
007104	005267	000016			TNC	ERRCNT			
007110	105777	171670		PRG4D:	TSTB	@TXCSR	;	WAIT FOR TRANSMITTER TO FINISH	
007114	100375				BPL	-4			
007116	000734				BR	PRG4C			
007120	104000			PRG4E:	TYPE				
007122	011761				ENDPAS				
007124	000727				BR	PRG4BB			
007126	000000			ERRCNT:	OPEN				
							;	THIS ROUTINE MOVES THE CONTENTS OF R2 TO THE ADDRESS SPECIFIED	
					BY R1				
007130	012703	000010		MOVIT:	MOV	#10,%3	;	GET OFFSET	
007134	012767	000006	170642		MOV	#6,4	;	SET UP ERROR TRAP ADDRESS	
007142	012767	000002	170636		MOV	#2,6	;	TO RETURN	

007150 012700 000041
007154 010211
007156 060301
007160 005300
007162 001374
007164 005067 170616
007170 000205

```
MOVITA: MOV #33,%0 ;GET COUNTER
MOV %2,(1) ;MOVE THE DATA
ADD %3,%1 ;ADD OFFSET
DEC %0 ;ALL DATA MOVED?
BNE MOVITA ;NO. RETURN
CLR 6 ;RESTORE ERROR TRAP ADDRESS
RTS 5 ;RETURN
```

007172 012701 007776
007176 016702 000074
007202 012703 000010
007206 012704 000040
007212 010112
007214 060301
007216 060302
007220 005304
007222 001373
007224 000207

```
;SUBROUTINE TO LOAD ALL VECTORS
LDVECS: MOV #RISRO,%1
MOV VECTAB,%2
LDVECA: MOV #10,%3
MOV #32,%4
LDVECB: MOV %1,(2) ;LOAD VECTOR
ADD %3,%1
AND %3,%2
DEC %4
BNE LDVECB
RTS 7
```

007226 012701 010376
007232 016702 000040
007236 062702 000004
007242 000167 177734

```
LDTVEC: MOV #TISRO,%1
MOV VECTAB,%2
ADD #4,%2
JMP LDVECA
```

007246 016701 000024
007252 005721
007254 012702 000340
007260 012703 000100
007264 010211
007266 022121
007270 005303
007272 001374
007274 000207

```
;ROUTINE TO LOAD PRIORITY LEVEL 7 IN VECTOR +2
LDPRI: MOV VECTAB,%1 ;GET BASE VECTOR
TST (1)+ ;ADD 2
MOV #340,%2 ;GET LEVEL 7
MOV #64,%3 ;LOAD COUNTER
LDPRIA: MOV %2,(1) ;LOAD VECTOR +2
CMP (1)+,(1)+ ;POINT TO NEXT VECTOR
DEC %3 ;DECREMENT COUNTER
BNE LDPRIA
RTS 7
```

007276 000300
007300 000310
007302 000320
007304 000330
007306 000340
007310 000350
007312 000360
007314 000370
007316 000400
007320 000410
007322 000420
007324 000430
007326 000440
007330 000450
007332 000460
007334 000470
007336 000500
007340 000510

;VECTOR ASSIGNMENT TABLE

```
VECTAB: 300 ;LINE 0 VECTOR
310 ;LINE 1 VECTOR
320 ;LINE 2 VECTOR
330 ;LINE 3 VECTOR
340 ;LINE 4 VECTOR
350 ;LINE 5 VECTOR
360 ;LINE 6 VECTOR
370 ;LINE 7 VECTOR
400 ;LINE 10 VECTOR
410 ;LINE 11 VECTOR
420 ;LINE 12 VECTOR
430 ;LINE 13 VECTOR
440 ;LINE 14 VECTOR
450 ;LINE 15 VECTOR
460 ;LINE 16 VECTOR
470 ;LINE 17 VECTOR
500 ;LINE 20 VECTOR
510 ;LINE 21 VECTOR
```

007342 000520
007344 000530
007346 000540
007350 000550
007352 000560
007354 000570
007356 000600
007360 000610
007362 000620
007364 000630
007366 000640
007370 000650
007372 000660
007374 000670

520
530
540
550
560
570
600
610
620
630
640
650
660
670

;LINE 22 VECTOR
;LINE 23 VECTOR
;LINE 24 VECTOR
;LINE 25 VECTOR
;LINE 26 VECTOR
;LINE 27 VECTOR
;LINE 30 VECTOR
;LINE 31 VECTOR
;LINE 32 VECTOR
;LINE 33 VECTOR
;LINE 34 VECTOR
;LINE 35 VECTOR
;LINE 36 VECTOR
;LINE 37 VECTOR

;DC11 REGISTER ADDRESSES

	000000	N=0	
	000000	A=0	
007376			
007376	174000	174000+0	;ADDRESS OF RECEIVER LINE # 0
	000010	N=N+10	
	000001	A=A+1	
007400	174010	174000+10	;ADDRESS OF RECEIVER LINE # 1
	000020	N=N+10	
	000002	A=A+1	
007402	174020	174000+20	;ADDRESS OF RECEIVER LINE # 2
	000030	N=N+10	
	000003	A=A+1	
007404	174030	174000+30	;ADDRESS OF RECEIVER LINE # 3
	000040	N=N+10	
	000004	A=A+1	
007406	174040	174000+40	;ADDRESS OF RECEIVER LINE # 4
	000050	N=N+10	
	000005	A=A+1	
007410	174050	174000+50	;ADDRESS OF RECEIVER LINE # 5
	000060	N=N+10	
	000006	A=A+1	
007412	174060	174000+60	;ADDRESS OF RECEIVER LINE # 6
	000070	N=N+10	
	000007	A=A+1	
007414	174070	174000+70	;ADDRESS OF RECEIVER LINE # 7
	000100	N=N+10	
	000010	A=A+1	
007416	174100	174000+100	;ADDRESS OF RECEIVER LINE # 10
	000110	N=N+10	
	000011	A=A+1	
007420	174110	174000+110	;ADDRESS OF RECEIVER LINE # 11
	000120	N=N+10	
	000012	A=A+1	
007422	174120	174000+120	;ADDRESS OF RECEIVER LINE # 12
	000130	N=N+10	
	000013	A=A+1	
007424	174130	174000+130	;ADDRESS OF RECEIVER LINE # 13
	000140	N=N+10	
	000014	A=A+1	
007426	174140	174000+140	;ADDRESS OF RECEIVER LINE # 14
	000150	N=N+10	
	000015	A=A+1	
007430	174150	174000+150	;ADDRESS OF RECEIVER LINE # 15
	000160	N=N+10	
	000016	A=A+1	
007432	174160	174000+160	;ADDRESS OF RECEIVER LINE # 16
	000170	N=N+10	
	000017	A=A+1	
007434	174170	174000+170	;ADDRESS OF RECEIVER LINE # 17
	000200	N=N+10	
	000020	A=A+1	
007436	174200	174000+200	;ADDRESS OF RECEIVER LINE # 20
	000210	N=N+10	
	000021	A=A+1	

007440	174210	174000+210	; ADDRESS OF RECEIVER LINE # 21
	000220	N=N+10	
	000022	A=A+1	
007442	174220	174000+220	; ADDRESS OF RECEIVER LINE # 22
	000230	N=N+10	
	000023	A=A+1	
007444	174230	174000+230	; ADDRESS OF RECEIVER LINE # 23
	000240	N=N+10	
	000024	A=A+1	
007446	174240	174000+240	; ADDRESS OF RECEIVER LINE # 24
	000250	N=N+10	
	000025	A=A+1	
007450	174250	174000+250	; ADDRESS OF RECEIVER LINE # 25
	000260	N=N+10	
	000026	A=A+1	
007452	174260	174000+260	; ADDRESS OF RECEIVER LINE # 26
	000270	N=N+10	
	000027	A=A+1	
007454	174270	174000+270	; ADDRESS OF RECEIVER LINE # 27
	000300	N=N+10	
	000030	A=A+1	
007456	174300	174000+300	; ADDRESS OF RECEIVER LINE # 30
	000310	N=N+10	
	000031	A=A+1	
007460	174310	174000+310	; ADDRESS OF RECEIVER LINE # 31
	000320	N=N+10	
	000032	A=A+1	
007462	174320	174000+320	; ADDRESS OF RECEIVER LINE # 32
	000330	N=N+10	
	000033	A=A+1	
007464	174330	174000+330	; ADDRESS OF RECEIVER LINE # 33
	000340	N=N+10	
	000034	A=A+1	
007466	174340	174000+340	; ADDRESS OF RECEIVER LINE # 34
	000350	N=N+10	
	000035	A=A+1	
007470	174350	174000+350	; ADDRESS OF RECEIVER LINE # 35
	000360	N=N+10	
	000036	A=A+1	
007472	174360	174000+360	; ADDRESS OF RECEIVER LINE # 36
	000370	N=N+10	
	000037	A=A+1	
007474	174370	174000+370	; ADDRESS OF RECEIVER LINE # 37
	000400	N=N+10	
	000040	A=A+1	
	000000	N=0	
	000000	A=0	
007476			
007475	174002	174002+0	; ADDRESS OF RECEIVER BUFFER LINE # 0
	000010	N=N+10	
	000001	A=A+1	
007500	174012	174002+10	; ADDRESS OF RECEIVER BUFFER LINE # 1
	000020	N=N+10	
	000002	A=A+1	
007502	174022	174002+20	; ADDRESS OF RECEIVER BUFFER LINE # 2

RBUF:

	000030	N=N+10	
	000003	A=A+1	
007504	174032	174002+30	; ADDRESS OF RECEIVER BUFFER LINE # 3
	000040	N=N+10	
	000004	A=A+1	
007506	174042	174002+40	; ADDRESS OF RECEIVER BUFFER LINE # 4
	000050	N=N+10	
	000005	A=A+1	
007510	174052	174002+50	; ADDRESS OF RECEIVER BUFFER LINE # 5
	000060	N=N+10	
	000006	A=A+1	
007512	174062	174002+60	; ADDRESS OF RECEIVER BUFFER LINE # 6
	000070	N=N+10	
	000007	A=A+1	
007514	174072	174002+70	; ADDRESS OF RECEIVER BUFFER LINE # 7
	000100	N=N+10	
	000010	A=A+1	
007516	174102	174002+100	; ADDRESS OF RECEIVER BUFFER LINE # 10
	000110	N=N+10	
	000011	A=A+1	
007520	174112	174002+110	; ADDRESS OF RECEIVER BUFFER LINE # 11
	000120	N=N+10	
	000012	A=A+1	
007522	174122	174002+120	; ADDRESS OF RECEIVER BUFFER LINE # 12
	000130	N=N+10	
	000013	A=A+1	
007524	174132	174002+130	; ADDRESS OF RECEIVER BUFFER LINE # 13
	000140	N=N+10	
	000014	A=A+1	
007526	174142	174002+140	; ADDRESS OF RECEIVER BUFFER LINE # 14
	000150	N=N+10	
	000015	A=A+1	
007530	174152	174002+150	; ADDRESS OF RECEIVER BUFFER LINE # 15
	000160	N=N+10	
	000016	A=A+1	
007532	174162	174002+160	; ADDRESS OF RECEIVER BUFFER LINE # 16
	000170	N=N+10	
	000017	A=A+1	
007534	174172	174002+170	; ADDRESS OF RECEIVER BUFFER LINE # 17
	000200	N=N+10	
	000020	A=A+1	
007536	174202	174002+200	; ADDRESS OF RECEIVER BUFFER LINE # 20
	000210	N=N+10	
	000021	A=A+1	
007540	174212	174002+210	; ADDRESS OF RECEIVER BUFFER LINE # 21
	000220	N=N+10	
	000022	A=A+1	
007542	174222	174002+220	; ADDRESS OF RECEIVER BUFFER LINE # 22
	000230	N=N+10	
	000023	A=A+1	
007544	174232	174002+230	; ADDRESS OF RECEIVER BUFFER LINE # 23
	000240	N=N+10	
	000024	A=A+1	
007546	174242	174002+240	; ADDRESS OF RECEIVER BUFFER LINE # 24
	000250	N=N+10	
	000025	A=A+1	

007550	174252	174002+250	; ADDRESS OF RECEIVER BUFFER LINE # 25
	000260	N=N+10	
	00026	A=A+1	
007552	174262	174002+260	; ADDRESS OF RECEIVER BUFFER LINE # 26
	000270	N=N+10	
	00027	A=A+1	
007554	174272	174002+270	; ADDRESS OF RECEIVER BUFFER LINE # 27
	000300	N=N+10	
	00030	A=A+1	
007556	174302	174002+300	; ADDRESS OF RECEIVER BUFFER LINE # 30
	000310	N=N+10	
	00031	A=A+1	
007560	174312	174002+310	; ADDRESS OF RECEIVER BUFFER LINE # 31
	000320	N=N+10	
	00032	A=A+1	
007562	174322	174002+320	; ADDRESS OF RECEIVER BUFFER LINE # 32
	000330	N=N+10	
	00033	A=A+1	
007564	174332	174002+330	; ADDRESS OF RECEIVER BUFFER LINE # 33
	000340	N=N+10	
	00034	A=A+1	
007566	174342	174002+340	; ADDRESS OF RECEIVER BUFFER LINE # 34
	000350	N=N+10	
	00035	A=A+1	
007570	174352	174002+350	; ADDRESS OF RECEIVER BUFFER LINE # 35
	000360	N=N+10	
	00036	A=A+1	
007572	174362	174002+360	; ADDRESS OF RECEIVER BUFFER LINE # 36
	000370	N=N+10	
	00037	A=A+1	
007574	174372	174002+370	; ADDRESS OF RECEIVER BUFFER LINE # 37
	000400	N=N+10	
	00040	A=A+1	
	000000	N=0	
	000000	A=0	
007576			
007576	174004	174004+0	; ADDRESS OF TRANSMITTER CSR LINE # 0
	000010	N=N+10	
	000001	A=A+1	
007600	174014	174004+10	; ADDRESS OF TRANSMITTER CSR LINE # 1
	000020	N=N+10	
	000002	A=A+1	
007602	174024	174004+20	; ADDRESS OF TRANSMITTER CSR LINE # 2
	000030	N=N+10	
	000003	A=A+1	
007604	174034	174004+30	; ADDRESS OF TRANSMITTER CSR LINE # 3
	000040	N=N+10	
	000004	A=A+1	
007606	174044	174004+40	; ADDRESS OF TRANSMITTER CSR LINE # 4
	000050	N=N+10	
	000005	A=A+1	
007610	174054	174004+50	; ADDRESS OF TRANSMITTER CSR LINE # 5
	000060	N=N+10	
	000006	A=A+1	
007612	174064	174004+60	; ADDRESS OF TRANSMITTER CSR LINE # 6

TCSR:

	000070	N=N+10	
	000007	A=A+1	
007614	174074	174004+70	; ADDRESS OF TRANSMITTER CSR LINE # 7
	000100	N=N+10	
	000010	A=A+1	
007616	174104	174004+100	; ADDRESS OF TRANSMITTER CSR LINE # 10
	000110	N=N+10	
	000011	A=A+1	
007620	174114	174004+110	; ADDRESS OF TRANSMITTER CSR LINE # 11
	000120	N=N+10	
	000012	A=A+1	
007622	174124	174004+120	; ADDRESS OF TRANSMITTER CSR LINE # 12
	000130	N=N+10	
	000013	A=A+1	
007624	174134	174004+130	; ADDRESS OF TRANSMITTER CSR LINE # 13
	000140	N=N+10	
	000014	A=A+1	
007626	174144	174004+140	; ADDRESS OF TRANSMITTER CSR LINE # 14
	000150	N=N+10	
	000015	A=A+1	
007630	174154	174004+150	; ADDRESS OF TRANSMITTER CSR LINE # 15
	000160	N=N+10	
	000016	A=A+1	
007632	174164	174004+160	; ADDRESS OF TRANSMITTER CSR LINE # 16
	000170	N=N+10	
	000017	A=A+1	
007634	174174	174004+170	; ADDRESS OF TRANSMITTER CSR LINE # 17
	000200	N=N+10	
	000020	A=A+1	
007636	174204	174004+200	; ADDRESS OF TRANSMITTER CSR LINE # 20
	000210	N=N+10	
	000021	A=A+1	
007640	174214	174004+210	; ADDRESS OF TRANSMITTER CSR LINE # 21
	000220	N=N+10	
	000022	A=A+1	
007642	174224	174004+220	; ADDRESS OF TRANSMITTER CSR LINE # 22
	000230	N=N+10	
	000023	A=A+1	
007644	174234	174004+230	; ADDRESS OF TRANSMITTER CSR LINE # 23
	000240	N=N+10	
	000024	A=A+1	
007646	174244	174004+240	; ADDRESS OF TRANSMITTER CSR LINE # 24
	000250	N=N+10	
	000025	A=A+1	
007650	174254	174004+250	; ADDRESS OF TRANSMITTER CSR LINE # 25
	000260	N=N+10	
	000026	A=A+1	
007652	174264	174004+260	; ADDRESS OF TRANSMITTER CSR LINE # 26
	000270	N=N+10	
	000027	A=A+1	
007654	174274	174004+270	; ADDRESS OF TRANSMITTER CSR LINE # 27
	000300	N=N+10	
	000030	A=A+1	
007656	174304	174004+300	; ADDRESS OF TRANSMITTER CSR LINE # 30
	000310	N=N+10	
	000031	A=A+1	

007660	174314		174004+310	; ADDRESS OF TRANSMITTER CSR LINE # 31
	000320		N=N+10	
	000032		A=A+1	
007662	174324		174004+320	; ADDRESS OF TRANSMITTER CSR LINE # 32
	000330		N=N+10	
	000033		A=A+1	
007664	174334		174004+330	; ADDRESS OF TRANSMITTER CSR LINE # 33
	000340		N=N+10	
	000034		A=A+1	
007666	174344		174004+340	; ADDRESS OF TRANSMITTER CSR LINE # 34
	000350		N=N+10	
	000035		A=A+1	
007670	174354		174004+350	; ADDRESS OF TRANSMITTER CSR LINE # 35
	000360		N=N+10	
	000036		A=A+1	
007672	174364		174004+360	; ADDRESS OF TRANSMITTER CSR LINE # 36
	000370		N=N+10	
	000037		A=A+1	
007674	174374		174004+370	; ADDRESS OF TRANSMITTER CSR LINE # 37
	000400		N=N+10	
	000040		A=A+1	
	000000		N=0	
	000000		A=0	
007676		TBUF:		
007676	174006		174006+0	; ADDRESS OF TRANSMIT BUFFER LINE # 0
	000010		N=N+10	
	000001		A=A+1	
007700	174016		174006+10	; ADDRESS OF TRANSMIT BUFFER LINE # 1
	000020		N=N+10	
	000002		A=A+1	
007702	174026		174006+20	; ADDRESS OF TRANSMIT BUFFER LINE # 2
	000030		N=N+10	
	000003		A=A+1	
007704	174036		174006+30	; ADDRESS OF TRANSMIT BUFFER LINE # 3
	000040		N=N+10	
	000004		A=A+1	
007706	174046		174006+40	; ADDRESS OF TRANSMIT BUFFER LINE # 4
	000050		N=N+10	
	000005		A=A+1	
007710	174056		174006+50	; ADDRESS OF TRANSMIT BUFFER LINE # 5
	000060		N=N+10	
	000006		A=A+1	
007712	174066		174006+60	; ADDRESS OF TRANSMIT BUFFER LINE # 6
	000070		N=N+10	
	000007		A=A+1	
007714	174076		174006+70	; ADDRESS OF TRANSMIT BUFFER LINE # 7
	000100		N=N+10	
	000010		A=A+1	
007716	174106		174006+100	; ADDRESS OF TRANSMIT BUFFER LINE # 10
	000110		N=N+10	
	000011		A=A+1	
007720	174116		174006+110	; ADDRESS OF TRANSMIT BUFFER LINE # 11
	000120		N=N+10	
	000012		A=A+1	
007722	174126		174006+120	; ADDRESS OF TRANSMIT BUFFER LINE # 12

007724	000130 000013 174136 000140 000014	N=N+10 A=A+1 174006+130 N=N+10 A=A+1	; ADDRESS OF TRANSMIT BUFFER LINE # 13
007726	174146 000150 000015	174006+140 N=N+10 A=A+1	; ADDRESS OF TRANSMIT BUFFER LINE # 14
007730	174156 000160 000016	174006+150 N=N+10 A=A+1	; ADDRESS OF TRANSMIT BUFFER LINE # 15
007732	174166 000170 000017	174006+160 N=N+10 A=A+1	; ADDRESS OF TRANSMIT BUFFER LINE # 16
007734	174176 000200 000020	174006+170 N=N+10 A=A+1	; ADDRESS OF TRANSMIT BUFFER LINE # 17
007736	174206 000210 000021	174006+200 N=N+10 A=A+1	; ADDRESS OF TRANSMIT BUFFER LINE # 20
007740	174216 000220 000022	174006+210 N=N+10 A=A+1	; ADDRESS OF TRANSMIT BUFFER LINE # 21
007742	174226 000230 000023	174006+220 N=N+10 A=A+1	; ADDRESS OF TRANSMIT BUFFER LINE # 22
007744	174236 000240 000024	174006+230 N=N+10 A=A+1	; ADDRESS OF TRANSMIT BUFFER LINE # 23
007746	174246 000250 000025	174006+240 N=N+10 A=A+1	; ADDRESS OF TRANSMIT BUFFER LINE # 24
007750	174256 000260 000026	174006+250 N=N+10 A=A+1	; ADDRESS OF TRANSMIT BUFFER LINE # 25
007752	174266 000270 000027	174006+260 N=N+10 A=A+1	; ADDRESS OF TRANSMIT BUFFER LINE # 26
007754	174276 000300 000030	174006+270 N=N+10 A=A+1	; ADDRESS OF TRANSMIT BUFFER LINE # 27
007756	174306 000310 000031	174006+300 N=N+10 A=A+1	; ADDRESS OF TRANSMIT BUFFER LINE # 30
007760	174316 000320 000032	174006+310 N=N+10 A=A+1	; ADDRESS OF TRANSMIT BUFFER LINE # 31
007762	174326 000330 000033	174006+320 N=N+10 A=A+1	; ADDRESS OF TRANSMIT BUFFER LINE # 32
007764	174336 000340 000034	174006+330 N=N+10 A=A+1	; ADDRESS OF TRANSMIT BUFFER LINE # 33
007766	174346 000350 000035	174006+340 N=N+10 A=A+1	; ADDRESS OF TRANSMIT BUFFER LINE # 34

H04

MAINDEC-11-DZDCB-B DC11 ON LINE TEST
DZDCBB.PFC

MACY11 27(732) 02-MAR-76 11:23 PAGE 46

007770	174356 000360 000036	174006+350 N=N+10 A=A+1	; ADDRESS OF TRANSMIT BUFFER LINE # 35
007772	174366 000370 000037	174006+360 N=N+10 A=A+1	; ADDRESS OF TRANSMIT BUFFER LINE # 36
007774	174376 000400 000040	174006+370 N=N+10 A=A+1	; ADDRESS OF TRANSMIT BUFFER LINE # 37

007776	000000	000000	RISR0:	N=0		
010002	012700	174322		MOV	#0,%0	
	000167			JMP	RISR	:GO TO COMMON INTERRUPT SERVICE ROUTINE
010006	000001	000001	RISR1:	N=N+1		
010012	012700	174312		MOV	#1,%0	
	000167			JMP	RISR	:GO TO COMMON INTERRUPT SERVICE ROUTINE
010016	000002	000002	RISR2:	N=N+1		
010022	012700	174302		MOV	#2,%0	
	000167			JMP	RISR	:GO TO COMMON INTERRUPT SERVICE ROUTINE
010026	000003	000003	RISR3:	N=N+1		
010032	012700	174272		MOV	#3,%0	
	000167			JMP	RISR	:GO TO COMMON INTERRUPT SERVICE ROUTINE
010036	000004	000004	RISR4:	N=N+1		
010042	012700	174262		MOV	#4,%0	
	000167			JMP	RISR	:GO TO COMMON INTERRUPT SERVICE ROUTINE
010046	000005	000005	RISR5:	N=N+1		
010052	012700	174252		MOV	#5,%0	
	000167			JMP	RISR	:GO TO COMMON INTERRUPT SERVICE ROUTINE
010056	000006	000006	RISR6:	N=N+1		
010062	012700	174242		MOV	#6,%0	
	000167			JMP	RISR	:GO TO COMMON INTERRUPT SERVICE ROUTINE
010066	000007	000007	RISR7:	N=N+1		
010072	012700	174232		MOV	#7,%0	
	000167			JMP	RISR	:GO TO COMMON INTERRUPT SERVICE ROUTINE
010076	000010	000010	RISR10:	N=N+1		
010102	012700	174222		MOV	#10,%0	
	000167			JMP	RISR	:GO TO COMMON INTERRUPT SERVICE ROUTINE
010106	000011	000011	RISR11:	N=N+1		
010112	012700	174212		MOV	#11,%0	
	000167			JMP	RISR	:GO TO COMMON INTERRUPT SERVICE ROUTINE
010116	000012	000012	RISR12:	N=N+1		
010122	012700	174202		MOV	#12,%0	
	000167			JMP	RISR	:GO TO COMMON INTERRUPT SERVICE ROUTINE
010126	000013	000013	RISR13:	N=N+1		
010132	012700	174172		MOV	#13,%0	
	000167			JMP	RISR	:GO TO COMMON INTERRUPT SERVICE ROUTINE
010136	000014	000014	RISR14:	N=N+1		
010142	012700	174162		MOV	#14,%0	
	000167			JMP	RISR	:GO TO COMMON INTERRUPT SERVICE ROUTINE
	000015			N=N+1		

010146	012700	000015	RISR15: MOV	#15,%0	
010152	000167	174152	JMP	RISR	;GO TO COMMON INTERRUPT SERVICE ROUTINE
	000016			N=N+1	
010156	012700	000016	RISR16: MOV	#16,%0	
010162	000167	174142	JMP	RISR	;GO TO COMMON INTERRUPT SERVICE ROUTINE
	000017			N=N+1	
010166	012700	000017	RISR17: MOV	#17,%0	
010172	000167	174132	JMP	RISR	;GO TO COMMON INTERRUPT SERVICE ROUTINE
	000020			N=N+1	
010176	012700	000020	RISR20: MOV	#20,%0	
010202	000167	174122	JMP	RISR	;GO TO COMMON INTERRUPT SERVICE ROUTINE
	000021			N=N+1	
010206	012700	000021	RISR21: MOV	#21,%0	
010212	000167	174112	JMP	RISR	;GO TO COMMON INTERRUPT SERVICE ROUTINE
	000022			N=N+1	
010216	012700	000022	RISR22: MOV	#22,%0	
010222	000167	174102	JMP	RISR	;GO TO COMMON INTERRUPT SERVICE ROUTINE
	000023			N=N+1	
010226	012700	000023	RISR23: MOV	#23,%0	
010232	000167	174072	JMP	RISR	;GO TO COMMON INTERRUPT SERVICE ROUTINE
	000024			N=N+1	
010236	012700	000024	RISR24: MOV	#24,%0	
010242	000167	174062	JMP	RISR	;GO TO COMMON INTERRUPT SERVICE ROUTINE
	000025			N=N+1	
010246	012700	000025	RISR25: MOV	#25,%0	
010252	000167	174052	JMP	RISR	;GO TO COMMON INTERRUPT SERVICE ROUTINE
	000026			N=N+1	
010256	012700	000026	RISR26: MOV	#26,%0	
010262	000167	174042	JMP	RISR	;GO TO COMMON INTERRUPT SERVICE ROUTINE
	000027			N=N+1	
010266	012700	000027	RISR27: MOV	#27,%0	
010272	000167	174032	JMP	RISR	;GO TO COMMON INTERRUPT SERVICE ROUTINE
	000030			N=N+1	
010276	012700	000030	RISR30: MOV	#30,%0	
010302	000167	174022	JMP	RISR	;GO TO COMMON INTERRUPT SERVICE ROUTINE
	000031			N=N+1	
010306	012700	000031	RISR31: MOV	#31,%0	
010312	000167	174012	JMP	RISR	;GO TO COMMON INTERRUPT SERVICE ROUTINE
	000032			N=N+1	
010316	012700	000032	RISR32: MOV	#32,%0	
010322	000167	174002	JMP	RISR	;GO TO COMMON INTERRUPT SERVICE ROUTINE
	000033			N=N+1	

010326	012700	000033	RISR33:	MOV	#33,%0	
010332	000167	173772		JMP	RISR	;GO TO COMMON INTERRUPT SERVICE ROUTINE
	000034			N=N+1		
010336	012700	000034	RISR34:	MOV	#34,%0	
010342	000167	173762		JMP	RISR	;GO TO COMMON INTERRUPT SERVICE ROUTINE
	000035			N=N+1		
010346	012700	000035	RISR35:	MOV	#35,%0	
010352	000167	173752		JMP	RISR	;GO TO COMMON INTERRUPT SERVICE ROUTINE
	000036			N=N+1		
010356	012700	000036	RISR36:	MOV	#36,%0	
010362	000167	173742		JMP	RISR	;GO TO COMMON INTERRUPT SERVICE ROUTINE
	000037			N=N+1		
010366	012700	000037	RISR37:	MOV	#37,%0	
010372	000167	173732		JMP	RISR	;GO TO COMMON INTERRUPT SERVICE ROUTINE
	000040			N=N+1		
	000000			N=0		
010376	012700	000000	TISR0:	MOV	#0,%0	;PUT LINE # IN RO
010402	000167	175146		JMP	TISR	;GO TO COMMON INTERRUPT SERVICE
	000001			N=N+1		
010406	012700	000001	TISR1:	MOV	#1,%0	;PUT LINE # IN RO
010412	000167	175136		JMP	TISR	;GO TO COMMON INTERRUPT SERVICE
	000002			N=N+1		
010416	012700	000002	TISR2:	MOV	#2,%0	;PUT LINE # IN RO
010422	000167	175126		JMP	TISR	;GO TO COMMON INTERRUPT SERVICE
	000003			N=N+1		
010426	012700	000003	TISR3:	MOV	#3,%0	;PUT LINE # IN RO
010432	000167	175116		JMP	TISR	;GO TO COMMON INTERRUPT SERVICE
	000004			N=N+1		
010436	012700	000004	TISR4:	MOV	#4,%0	;PUT LINE # IN RO
010442	000167	175106		JMP	TISR	;GO TO COMMON INTERRUPT SERVICE
	000005			N=N+1		
010446	012700	000005	TISR5:	MOV	#5,%0	;PUT LINE # IN RO
010452	000167	175076		JMP	TISR	;GO TO COMMON INTERRUPT SERVICE
	000006			N=N+1		
010456	012700	000006	TISR6:	MOV	#6,%0	;PUT LINE # IN RO
010462	000167	175066		JMP	TISR	;GO TO COMMON INTERRUPT SERVICE
	000007			N=N+1		
010466	012700	000007	TISR7:	MOV	#7,%0	;PUT LINE # IN RO
010472	000167	175056		JMP	TISR	;GO TO COMMON INTERRUPT SERVICE
	000010			N=N+1		
010476	012700	000010	TISR10:	MOV	#10,%0	;PUT LINE # IN RO
010502	000167	175046		JMP	TISR	;GO TO COMMON INTERRUPT SERVICE

010506	000011	000011	TISR11:	N=N+1 MOV #11,%0	;PUT LINE # IN RO
010512	012700	175036		JMP TISR	;GO TO COMMON INTERRUPT SERVICE
010516	000012	000012	TISR12:	N=N+1 MOV #12,%0	;PUT LINE # IN RO
010522	012700	175026		JMP TISR	;GO TO COMMON INTERRUPT SERVICE
010526	000013	000013	TISR13:	N=N+1 MOV #13,%0	;PUT LINE # IN RO
010532	012700	175016		JMP TISR	;GO TO COMMON INTERRUPT SERVICE
010536	000014	000014	TISR14:	N=N+1 MOV #14,%0	;PUT LINE # IN RO
010542	012700	175006		JMP TISR	;GO TO COMMON INTERRUPT SERVICE
010546	000015	000015	TISR15:	N=N+1 MOV #15,%0	;PUT LINE # IN RO
010552	012700	174776		JMP TISR	;GO TO COMMON INTERRUPT SERVICE
010556	000016	000016	TISR16:	N=N+1 MOV #16,%0	;PUT LINE # IN RO
010562	012700	174766		JMP TISR	;GO TO COMMON INTERRUPT SERVICE
010566	000017	000017	TISR17:	N=N+1 MOV #17,%0	;PUT LINE # IN RO
010572	012700	174756		JMP TISR	;GO TO COMMON INTERRUPT SERVICE
010576	000020	000020	TISR20:	N=N+1 MOV #20,%0	;PUT LINE # IN RO
010602	012700	174746		JMP TISR	;GO TO COMMON INTERRUPT SERVICE
010606	000021	000021	TISR21:	N=N+1 MOV #21,%0	;PUT LINE # IN RO
010612	012700	174736		JMP TISR	;GO TO COMMON INTERRUPT SERVICE
010616	000022	000022	TISR22:	N=N+1 MOV #22,%0	;PUT LINE # IN RO
010622	012700	174726		JMP TISR	;GO TO COMMON INTERRUPT SERVICE
010626	000023	000023	TISR23:	N=N+1 MOV #23,%0	;PUT LINE # IN RO
010632	012700	174716		JMP TISR	;GO TO COMMON INTERRUPT SERVICE
010636	000024	000024	TISR24:	N=N+1 MOV #24,%0	;PUT LINE # IN RO
010642	012700	174706		JMP TISR	;GO TO COMMON INTERRUPT SERVICE
010646	000025	000025	TISR25:	N=N+1 MOV #25,%0	;PUT LINE # IN RO
010652	012700	174676		JMP TISR	;GO TO COMMON INTERRUPT SERVICE
010656	000026	000026	TISR26:	N=N+1 MOV #26,%0	;PUT LINE # IN RO
010662	012700	174666		JMP TISR	;GO TO COMMON INTERRUPT SERVICE

010666	000027	000027							
010672	012700	174656	TISR27:	N=N+1 MOV #27,%0 JMP TISR					:PUT LINE # IN RO :GO TO COMMON INTERRUPT SERVICE
010676	000030	000030							
010702	012700	174646	TISR30:	N=N+1 MOV #30,%0 JMP TISR					:PUT LINE # IN RO :GO TO COMMON INTERRUPT SERVICE
010706	000031	000031							
010712	012700	174636	TISR31:	N=N+1 MOV #31,%0 JMP TISR					:PUT LINE # IN RO :GO TO COMMON INTERRUPT SERVICE
010716	000032	000032							
010722	012700	174626	TISR32:	N=N+1 MOV #32,%0 JMP TISR					:PUT LINE # IN RO :GO TO COMMON INTERRUPT SERVICE
010726	000033	000033							
010732	012700	174616	TISR33:	N=N+1 MOV #33,%0 JMP TISR					:PUT LINE # IN RO :GO TO COMMON INTERRUPT SERVICE
010736	000034	000034							
010742	012700	174606	TISR34:	N=N+1 MOV #34,%0 JMP TISR					:PUT LINE # IN RO :GO TO COMMON INTERRUPT SERVICE
010746	000035	000035							
010752	012700	174576	TISR35:	N=N+1 MOV #35,%0 JMP TISR					:PUT LINE # IN RO :GO TO COMMON INTERRUPT SERVICE
010756	000036	000036							
010762	012700	174566	TISR36:	N=N+1 MOV #36,%0 JMP TISR					:PUT LINE # IN RO :GO TO COMMON INTERRUPT SERVICE
010766	000037	000037							
010772	012700	174556	TISR37:	N=N+1 MOV #37,%0 JMP TISR					:PUT LINE # IN RO :GO TO COMMON INTERRUPT SERVICE
	000040			N=N+1					

				:MESSAGES	
010776	020045	020040	020040	CSRADD:	.ASCII '% @'
011004	040040				
011006	043045	046101	042523	RINTM:	.ASCII '%FALSE INT. RCVR@'
011014	044440	052116	020056		
011022	041522	051126	100		
011027	045	040506	051514	TINTM:	.ASCII '%FALSE INT XMIT@'
011034	020105	047111	020124		
011042	046530	052111	100		

011047	045	041520	020075	.ASCII MESSAGES
011054	020040	020040	020040	EMO: .ASCII '%PC= '
011062	020040	100		APC: .ASCII ' @'
011065	040	052040	041530	ATXCSR: .ASCII ' TXCSR = '
011072	051123	036440	040	
011077	040	020040	020040	ATXWAS: .ASCII ' @'
011104	040040			
011106	020040	054122	051503	ARXCSR: .ASCII ' RXCSR = '
011114	020122	020075		
011120	020040	020040	020040	ARXWAS: .ASCII ' @'
011126	100			
011127	045	050045	043522	POTIT: .ASCII '%%PRD - SINGLE CHAR LINE MODE TEST@'
011134	020060	020055	044523	
011142	043516	042514	041440	
011150	040510	020122	044514	
011156	042516	046440	042117	
011164	020105	042524	052123	
011172	100			
011173	045	050045	043522	PITIT: .ASCII '%%PRG1 - SPEC BIN COUNT LINE MODE TEST@'
011200	020061	020055	050123	
011206	041505	041040	047111	
011214	041440	052517	052116	
011222	046040	047111	020105	
011230	047515	042504	052040	
011236	051505	040124		
011242	022445	051120	031107	P2TIT: .ASCII '%%PRG2-SPECIAL MESSAGE LINE MODE TEST@'
011250	051455	042520	044503	
011256	046101	046440	051505	
011264	040523	042507	046040	
011272	047111	020105	047515	
011300	042504	052040	051505	
011306	040124			
011310	022445	042522	042503	P3TIT: .ASCII '%%RECEIVE MESSAGE TEST@'
011316	053111	020105	042515	
011324	051523	043501	020105	
011332	042524	052123	100	
011337	045	040504	040524	P4TIT: .ASCII '%DATA ECHO TEST USING MAYNARD FACILITY@'
011344	042440	044103	020117	
011352	042524	052123	052440	
011360	044523	043516	046440	
011366	054501	040516	042122	
011374	043040	041501	046111	
011402	052111	040131		
011406	051445	052105	050040	SELPAR: .ASCII '%SET PARAMETERS IN SR AS FOLLOWS:'
011414	051101	046501	052105	
011422	051105	020123	047111	
011430	051440	020122	051501	
011436	043040	046117	047514	
011444	051527	072		
011447	045	051123	020064	.ASCII '%SR4 = STOP CODE%SR3 AND 2 = SPEED'
011454	020075	052123	050117	
011462	041440	042117	022505	
011470	051123	020063	047101	
011476	020104	020062	020075	

011504	050123	042505	104		
011511	045	051123	020061	.ASCII	'%SR1 AND 0 = CHAR LENGTH%a'
011516	047101	020104	020060		
011524	020075	044103	051101		
011532	046040	047105	052107		
011540	022510	100			
011543	045	042523	020124	SELCAR: .ASCII	'%SET TEST CHAR CODE IN SR7-SR0.a'
011550	042524	052123	041440		
011556	040510	020122	047503		
011564	042504	044440	020116		
011572	051123	026467	051123		
011600	027060	100			
011603	045	040515	042513	MAKCON: .ASCII	'%MAKE LINE CONNECTION.a'
011610	046040	047111	020105		
011616	047503	047116	041505		
011624	044524	047117	040056		
011632	051040	020130	047111	RXIDNS: .ASCII	' RX INT. DONE NOT SET.a'
011640	027124	042040	047117		
011646	020105	047516	020124		
011654	042523	027124	100		
011661	040	040504	040524	CERDAT: .ASCII	' DATA ERR. S/B: '
011666	042440	051122	020056		
011674	051440	041057	020072		
011702	020040	020040	053440	CSB: .ASCII	' WAS: '
011710	051501	020072			
011714	020040	020040	041440	CWAS: .ASCII	' CHAR NO. '
011722	040510	020122	047516		
011730	020056				
011732	020040	020040	100	CRNUM: .ASCII	' a'
011737	040	020040	020040	CALDAT: .ASCII	' =CALLED DATAa'
011744	041475	046101	042514		
011752	020104	040504	040524		
011760	100				
011761	007			ENDPAS: .BYTE	007
011762	100			.ASCII	'a'
011763	045	040077		AINPRG: .ASCII	'%?a'
011766	051445	052105	042040	ASETSR: .ASCII	'%SET DESIRED SR OPTIONS. NORMAL OPERATION '
011774	051505	051111	042105		
012002	051440	020122	050117		
012010	044524	047117	027123		
012016	047040	051117	040515		
012024	020114	050117	051105		
012032	052101	047511	020116		
012040	051511	053440	052111	.ASCII	'IS WITH SR = 000000a'
012046	020110	051123	036440		
012054	030040	030060	030060		
012062	040060				
012064	047040	020117	054124	NTXINT: .ASCII	' NO TX INT. TXCNT: '
012072	044440	052116	020056		
012100	054124	047103	035124		
012106	040				
012107	040	020040	020040	ATXCNT: .ASCII	' a'
012114	040040				
012116	047040	020117	054122	NRXINT: .ASCII	' NO RX INT. RXCNT: '
012124	044440	052116	020056		
012132	054122	047103	035124		

012140	040				
012141	040	020040	020040	ARXCNT: .ASCII	' 2'
012146	040040				
012150	050045	047522	051107	APGEND: .ASCII	'%PROGRAM END.2'
012156	046501	042440	042116		
012164	040056				
012166	050045	051101	046501	PARMTS: .ASCII	'%PARAMETERS = '
012174	052105	051105	020123		
012202	020075				
012204	020040	040040		APARM: .ASCII	' 2'
012210	051040	044530	052116	LINCBM: .ASCII	' RXINT NOT RING.2'
012216	047040	052117	051040		
012224	047111	027107	100		
012231	122	047111	020107	LINCCM: .ASCII	'RING STILL SET AFTER RXCSR READ.2'
012236	052123	046111	020114		
012244	042523	020124	043101		
012252	042524	020122	054122		
012260	051503	020122	042522		
012266	042101	040056			
012272	041440	051101	044522	LINCGM: .ASCII	' CARRIER DETECT NOT SET.2'
012300	051105	042040	052105		
012306	041505	020124	047516		
012314	020124	042523	027124		
012322	100				
012323	040	046103	040505	LINCHM: .ASCII	' CLEAR TO SEND NOT SET.2'
012330	020122	047524	051440		
012336	047105	020104	047516		
012344	020124	042523	027124		
012352	100				
012353	045	047514	020114	LOL: .ASCII	'%LOL TIMED OUT.2'
012360	044524	042515	020104		
012366	052517	027124	100		
012373	045	044514	042516	LINMAD: .ASCII	'%LINE CONNECTION MADE.2'
012400	041440	047117	042516		
012406	052103	047511	020116		
012414	040515	042504	040056		
012422	041445	047117	044506	ACONFIG: .ASCII	'%CONFIGURATION 2'
012430	052507	040522	044524		
012436	047117	021440	040		
012443	040	020040	100	TCONFIG: .ASCII	' 2'
012447	040	054122	047111	LINCFM: .ASCII	' RXINT NOT CARRIER TRAN.2'
012454	020124	047516	020124		
012462	040503	051122	042511		
012470	020122	051124	047101		
012476	040056				
012500	051045	044530	052116	RINGIN: .ASCII	'%RXINT RING DATA TERMINAL READY.2'
012506	051040	047111	020107		
012514	040504	040524	052040		
012522	051105	044515	040516		
012530	020114	042522	042101		
012536	027131	100			
012541	120	051101	052111	PARERR: .ASCII	'PARITY ERROR RXCNT= '
012546	020131	051105	047522		
012554	020122	054122	047103		
012562	036524	040			
012565	040	020040	020040	BRXCNT: .ASCII	' 2'

012572 040040

012574	015	012	
012576	044124	020105	052521
012604	041511	020113	051102
012612	053517	020116	047506
012620	020130	052512	050115
012626	042105	047440	042526
012634	020122	044124	020105
012642	040514	054532	042040
012650	043517	020123	040502
012656	045503	030040	031061
012664	032063	033065	034067
012672	027071	045	
012675	045	044514	042516
012702	043040	044501	042514
012710	022504	100	
012713	045	051123	027463
012720	036464	051124	047101
012726	046523	052111	042524
012734	020122	050123	042505
012742	040104		
012744	046045	047111	020105
012752	020043		
012754	020040	053440	051501
012762	041440	046101	042514
012770	104		
012771	045	047514	042101
012776	041440	047117	044506
013004	052507	040522	044524
013012	047117	044440	020116
013020	051123	030040	030455
013026	023040	046440	042117
013034	046505	052040	050131
013042	020105	047111	051440
013050	031122	100	
013053	045	047514	042101
013060	051440	030122	032055
013066	052075	020117	044514
013074	042516	054440	052517
013102	040440	042522	042040
013110	040511	044514	043516
013116	047440	040116	
013122	054445	052517	041440
013130	046101	042514	020104
013136	051106	046517	046040
013144	047111	020105	020043
013152	020040	100	
013155	045	051120	051505
013162	020123	040504	046524
013170	041040	052125	047524
013176	020116	047117	042040
013204	052101	020101	044120
013212	047117	040105	
013216	046045	040517	020104
013224	044514	042516	047040

PRG2M: .EVEN 015,012
 .BYTE
 .ASCII 'THE QUICK BROWN FOX JUMPED OVER THE LAZY DOGS BACK 0123456789.%'

LFAIL: .ASCII '%LINE FAILED%'

SETSPD: .ASCII '%SR3/4=TRANSMITTER SPEED%'

ALINE: .ASCII '%LINE #'

TLINE: .ASCII ' WAS CALLED'

CNFIGM: .ASCII '%LOAD CONFIGURATION IN SR 0-1 & MODEM TYPE IN SR2%'

WRU: .ASCII '%LOAD SR0-4=TO LINE YOU ARE DIALING ON%'

UR: .ASCII '%YOU CALLED FROM LINE #'

URA: .ASCII ' %'
 BUTTON: .ASCII '%PRESS DATA BUTTON ON DATA PHONE%'

LDLINE: .ASCII '%LOAD LINE NO. (B) IN SR 3-7%'

EOS

MAINDEC-11-DZDCB-B DC11 ON LINE TEST
DZDCBB.PFC

MACY11 27(732) 02-MAR-76 11:23 PAGE 56

013232	027117	024040	024470
013240	044440	020116	051123
013246	031440	033455	100
	013254		
013254	000000		
	015224		
015224	000000		
	017174		
	013420		
017174	000001		

OUTBUF: .EVEN
 OPEN
 .=OUTBUF+1000.
INBUF: OPEN
 .=INBUF+1000.
 BUFF=OUTBUF+100.
DEND: .END

ADD	752	786	808	840	847	856	880	893	935	938	993	996	1080	1081	1194
	1675	1687	1688	1695											
ASL	799	1213	1366	1423											
ASR	1013	1014	1023	1024	1025										
BCS	998	1077													
BEG	707	864	895	992	1112	1115	1119	1124	1129	1135	1165	1224	1230	1238	1240
	1291	1297	1385	1513	1515	1556	1577	1592	1596	1642	1644	1647	1657		
BIC	705	793	807	924	937	940	962	968	976	982	1004	1009	1109	1110	1142
	1157	1158	1322	1324	1358	1380	1381	1409	1410	1434	1447	1558	1565	1590	1598
	1655														
BIS	1010	1113	1116	1117	1120	1121	1126	1127	1131	1132	1149	1167	1168	1242	1286
	1350	1369	1415	1416	1508	1532	1560	1561	1605	1615	1624	1625			
BIT	737	772	956	958	972	991	1111	1114	1118	1123	1128	1134	1154	1164	1175
	1290	1296	1298	1310	1333	1376	1396	1514	1591	1599	1631	1643	1646		
BLOS	796														
BLT	1235														
BMI	1216	1425	1544	1548	1551										
BNE	738	773	860	883	898	901	922	945	957	959	973	990	1012	1021	1042
	1052	1066	1155	1176	1196	1218	1222	1252	1258	1277	1299	1311	1325	1334	1377
	1387	1397	1429	1433	1439	1441	446	1600	1632	1677	1690	1706			
BPL	701	869	1520	1546	1553	1574	3	1587	1608	1611	1614	1650	1653	1661	
BR	732	763	798	866	875	889	4	970	978	984	997	1079	1137	1179	1448
	1477	1499	1521	1542	1635	1662	1665								
CLR	731	790	1075	1475	1497	1581	1638	1678							
CLRB	1036														
CMP	795	882	1017	1020	1221	1229	1234	1237	1239	1251	1257	1276	1374	1375	1384
	1386	1428	1432	1440	1445	1512	1641	1704							
CMPB	706	859	863	1555	1576	1595	1656								
COM	920	921													
DEC	897	900	944	989	1011	1041	1051	1065	1195	1676	1689	1705			
EMT	584	585	586	587	588	589	590	591	592	593	594	595	596	597	598
HALT	423	425	427	429	431	433	437	439	441	443	445	447	449	451	453
	455	457	459	461	463	465	467	469	471	473	475	477	479	481	483
	485	487	489	491	493	495	497	499	501	503	505	507	509	511	513
	515	517	519	521	523	525	527	529	531	533	535	537	539	541	543
	545	547	549	697	702	1002	1098	1320	1356	1458	1628				
INC	923	1078	1228	1233	1256	1275	1431	1437	1659						
INCB	1040														
JMP	613	800	810	1259	1389	1392	1399	1405	1566	1696	2152	2156	2160	2164	2168
	2172	2176	2180	2184	2188	2192	2196	2200	2204	2208	2212	2216	2220	2224	2228
	2232	2236	2240	2244	2248	2252	2256	2260	2264	2268	2272	2276	2281	2285	2289
	2293	2297	2301	2305	2309	2313	2317	2321	2325	2329	2333	2337	2341	2345	2349
	2353	2357	2361	2365	2369	2373	2377	2381	2385	2389	2393	2397	2401	2405	
JSR	708	712	716	722	741	758	765	776	797	865	872	874	1026	1064	1069
	1101	1143	1203	1281	1300	1313	1326	1337	1341	1344	1360	1368	1379	1402	1461
	1465	1466	1467	1468	1472	1484	1488	1489	1490	1494	1506	1507	1509	1516	1517
	1528	1529	1530	1533	1540	1621	1623	1645							
MOV	695	729	730	733	734	735	736	739	762	769	770	771	774	789	791
	792	794	803	805	809	813	814	815	816	817	818	819	820	821	826
	827	828	829	830	831	832	833	834	839	841	842	843	846	848	849
	850	854	855	857	861	878	879	881	884	886	892	894	896	908	909
	910	911	919	925	926	932	933	934	936	960	961	963	966	967	969
	974	975	977	980	981	983	986	994	1003	1005	1006	1007	1008	1015	1016
	1019	1037	1038	1047	1048	1049	1057	1058	1059	1060	1061	1062	1063	1068	1099
	1107	1108	1122	1125	1130	1136	1141	1152	1153	1163	1172	1174	1181	1191	1192
	1193	1202	1212	1214	1215	1247	1248	1249	1250	1263	1264	1265	1266	1267	1271

	1272	1280	1306	1307	1308	1309	1319	1340	1357	1359	1367	1391	1400	1401	1404
	1442	1460	1469	1470	1471	1483	1487	1491	1492	1493	1510	1518	1531	1538	1539
	1543	1559	1570	1572	1580	1588	1601	1603	1604	1606	1639	1648	1670	1671	1672
	1673	1674	1682	1683	1684	1685	1686	1693	1694	1699	1701	1702	1703	2151	2155
	2159	2163	2167	2171	2175	2179	2183	2187	2191	2195	2199	2203	2207	2211	2215
	2219	2223	2227	2231	2235	2239	2243	2247	2251	2255	2259	2263	2267	2271	2275
	2280	2284	2288	2292	2296	2300	2304	2308	2312	2316	2320	2324	2328	2332	2336
	2340	2344	2348	2352	2356	2360	2364	2368	2372	2376	2380	2384	2388	2392	2396
	2400	2404													
MOV8	858	867	871	873	939	1039	1050	1082	1227	1232	1253	1254	1268	1269	1273
	1321	1323	1430	1436	1459	1511	1549	1554	1575	1594	1609	1612	1640	1654	
NOP	1211	1246	1262	1279	1287	1422	1453								
RESET	1622														
ROL	806														
ROR	941	942	943	987											
RTI	698	703	728	753	787	822	835	844	851	862	885	903	1220	1226	1231
	1236	1241	1243	1288	1304	1312	1338	1351	1382	1427	1435	1443	1557	1562	1569
	1571	1578	1589	1593	1597	1602									
RTS	685	689	693	870	912	927	947	995	1022	1032	1043	1054	1074	1083	1133
	1150	1186	1197	1207	1412	1417	1616	1679	1691	1707					
SUB	696	740	775	804	1067	1076									
TST	700	1018	1159	1173	1182	1223	1225	1294	1303	1331	1332	1411	1438	1547	1629
	1630	1649	1700												
TSTB	868	1217	1424	1519	1545	1550	1552	1573	1582	1586	1607	1610	1613	1652	1660
WAIT	1476	1498	1541												
.ABS	394														
.ASCII	2411	2413	2416	2421	2422	2424	2426	2428	2430	2432	2439	2446	2453	2457	2464
	2470	2476	2481	2487	2491	2495	2498	2500	2503	2504	2509	2510	2511	2518	2522
	2526	2524	2532	2534	2537	2540	2541	2544	2550	2555	2560	2563	2567	2570	2571
	2576	2582	2586	2590	2601	2604	2609	2611	2614	2623	2630	2634	2635	2641	
.BYTE	1092	2508	2589												
.END	2652														
.EVEN	2588	2646													
.LIST	393														
.MACR	604	605	606	607	608	609	610								
.NLIST	392														
.REM	1														
.REPT	438	1749	1849	1949	2049	2151	2280								
.TITLE	391														

ERRORS DETECTED: 0
 DEFAULT GLOBALS GENERATED: 0

#DZDCBB DZDCBB.SEG/CRF/SOL=DZDCBB.PFC
 RUN-TIME: 7 14 3 SECONDS
 RUN-TIME RATIO: 118/26=4.4
 CORE USED: 10K (19 PAGES)

E06

Speaker, printer, 2 floppy, 40 MB, 270 disk, 2 disk writer, 40 pages

||||| 222222222233312
67890123456789012 #8
||||| 222222222233312