

DM11

LOGIC TESTS
MD-11-DZDMA-C

EP-DZDMA-C-DL
COPYRIGHT ©72-77
FICHE 1 OF 1

JAN 1978
digital
MADE IN USA

REM %

IDENTIFICATION

PRODUCT CODE MAINDEC-11-DZDMA-C-D
PRODUCT NAME DM11 LOGIC TESTS
DATE RELEASED NOVEMBER, 1977
MAINTAINER DIAGNOSTIC GROUF

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1972, 1977 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL
DEC

PGP
DECUS

UNIBUS
DECTAPE

MASSBUS

1 ABSTRACT

TWO SEPARATE DIAGNOSTIC PROGRAMS ARE PROVIDED FOR TESTING THE DM11 (ASYNCHRONOUS DATA MULTIPLEXER), MAINDEC-11-DZDMA (DM11 LOGIC TESTS), AND MAINDEC-11-DZDMB (DM11 MULTIPLE LINE DATA TESTS). THE LOGIC TESTS INDIVIDUALLY TEST EACH OF THE 16 DM11 LINES AND ALL COMMON LOGIC. THE MULTIPLE LINE DATA TESTS RUN SEVERAL LINES CONCURRENTLY AND ARE USED TO TEST LINE INTERACTION AND DATA TRANSMISSION/RECEPTION RELIABILITY. THIS DOCUMENT DESCRIBES THE LOGIC TESTS. THE AVAILABLE TESTS ARE:
PRGO - LOGIC TEST
PRG1 - TRANSMITTER SCOPE LOOP
PRG2 - TRANSMIT/RECEIVE SCOPE LOOP

2 EQUIPMENTS

2.1 EQUIPMENT

- A PDP 11 FAMILY PROCESSOR
- B DM11
- C JUMPERS CONNECTING 16 TRANSMITTERS TO THEIR RESPECTIVE RECEIVERS

2.2 STORAGE

THIS PROGRAM USES ALL OF CORE (8K) EXCEPT THAT AREA RESERVED FOR THE LOADERS

3 LOADING PROCEDURE

THE ABSOLUTE LOADER IS USED TO LOAD THE PROGRAM

4 USE PROCEDURE

4 1 STARTING PROCEDURE

BEFORE STARTING MAKE SURE THAT THE TTY IS IN REMOTE MODE, AND THE JUMPERS ARE INSTALLED THREE STARTING ADDRESSES ARE PROVIDED

0200 - THIS STARTING ADDRESS REQUESTS DM11 PARAMETERS, AND MUST BE USED TO INITIALLY START THE PROGRAM, AND WHENEVER ANY OF THE PARAMETERS LISTED BELOW IS CHANGED

A VECTOR ADDRESS ?
RESPONSE TYPE N THE VECTOR ADDRESS OF THE DM11 RECEIVER UNDER TEST CARRIAGE RETURN SELECTS 0300

B UNIT #(8)?
RESPONSE THE DM11 UNIT NUMBER CORRESPONDS TO THE ADDRESS TO WHICH THE CLOCK STATUS REGISTER (CSR) RESPONDS

CSR ADDRESS	DM11 UNIT #	CSR ADDRESS	DM11 UNIT #
175000	0	175100	10
175010	1	175110	11
175020	2	175120	12
175030	3	175130	13
175040	4	175140	14
175050	5	175150	15
175060	6	175160	16
175070	7	175170	17

CARRIAGE RETURN SELECTS UNIT # 0

WHAT IS THE CHARACTER LENGTH?
RESPONSE CHARACTER LENGTH REFERS TO THE NUMBER OF DATA BITS PER CHARACTER (5-8) CARRIAGE RETURN SELECTS 8 DATA BITS PER CHARACTER

C PPG #
RESPONSE TYPE PROGRAM NUMBER OF PROGRAM YOU WISH TO RUN CARRIAGE RETURN SELECTS PROGRAM # 0

NOTES

CARRIAGE RETURN TERMINATES ALL RESPONSES
ANY UNACCEPTABLE RESPONSE WILL RESULT IN A ? TYPEOUT AND THE PARAMETER WILL AGAIN BE REQUESTED

0204 - THIS STARTING ADDRESS USES PREVIOUSLY DEFINED DM11 PARAMETERS AND REQUESTS THE PROGRAM NUMBER OF THE PROGRAM YOU WISH TO RUN

0210 - THIS STARTING ADDRESS STARTS THE PREVIOUSLY SELECTED PROGRAM USING PREVIOUSLY SELECTED PARAMETERS

4 2 SWITCH SETTINGS

THE FOLLOWING SWITCH SETTINGS APPLY TO PROGRAM #0

SR 0-6	ROUTINE TO BE RUN (IF ENABLED BY SR-9)
SR 8	RING BELL ON ERROR
SR 9	LOOP SELECTED ROUTINE
SR 11	INHIBIT ITERATION (DO EACH POUT NE ONCE)
SR 13	INHIBIT PRINTOUT
SP 14	SCOPE (LOOP ROUTINE)
SP 15	HALT ON ERROR

THIS PROGRAM HAS BEEN MODIFIED TO RUN ON A PROCESSOR WITH OR WITHOUT A HARDWARE SWITCH REGISTER. WHEN FIRST EXECUTED THE PROGRAM TESTS THE EXISTENCE OF A HARDWARE SWITCH REGISTER. IF NOT FOUND A SOFTWARE SWITCH REGISTER LOCATION (SWREG=LOC 176) IS DEFAULTED TO. IF THIS IS THE CASE, UPON EXECUTION THE CONTENTS OF THE SWREG ARE DUMPED IN OCTAL ON THE CONSOLE TTY AND ANY CHANGES ARE REQUESTED.

(IE) SWR=XXXXXX NEW=

POSSIBLE RESPONSES ARE:

1	<CR>	IF NO CHANGES ARE TO BE MADE
2	6 DIGITS 0-7	TO REPRESENT IN OCTAL THE NEW SWITCH REGISTER VALUE, LAST DIGIT FOLLOWED BY <CR>
3	U	TO ALLOW REENTERING VALUE IF ERROR IS COMMITTED KEYING IN SWREG VALUE

BUILT INTO THE PROGRAM IS THE ABILITY TO DYNAMICALLY CHANGE THE CONTENTS OF SWREG DURING PROGRAM EXECUTION. BY STRIKING G (CNTRL G) ON CONSOLE TTY THE OPERATOR SETS A REQUEST FLAG TO CHANGE THE CONTENTS OF SWREG, WHICH IS PROCESSED IN KEY AREAS OF THE PROGRAM CODE (IE) ERROR ROUTINES, AFTER HALTS END OF PASS, AND OTHER APPLICABLE AREAS.

5 0 PROGRAM DESCRIPTION

5 1 PRGO - LOGIC TESTS

PRGO CONSISTS OF 152(8) INDEPENDENT ROUTINES WHICH TEST
VARIOUS FUNCTIONS OF THE DM11 HARDWARE ANY OF THESE ROUTINES
MAY BE INDIVIDUALLY SELECTED AND RUN (SEE SEC 4 2 FOR SWITCH
SETTING)

5 1 1 ROUTINE DESCRIPTION

ROUTINE TESTS

RT0 TESTS THE ABILITY TO REFERENCE THE FOUR DM11 REGISTERS
CONTROL STATUS REGISTER (CSR), BUFFER ACTIVE REGISTER (BAR),
BREAK STATUS REGISTER (BKCSR), AND THE BASE REGISTER (BASREG)
IF AN ILLEGAL REFERENCE OCCURS WHEN THE CSR IS REFERENCED THE
PROGRAM WILL INDICATE AN ERROR, AND AUTOMATICALLY LOOP THE ERROR
AS LONG AS THE ERROR CONDITION EXISTS
RT0 PC=XXXXXX

RT1-RT10 BIT 'BANGS' THE CSR (BITS 0,1,2,4,5,6,12,13). TESTING THAT
EACH BIT IN THE CSR CAN BE INDIVIDUALLY SET AND CLEARED TWO ERROR
TYPES ARE DETECTED IN THESE TESTS, A BIT FAILED TO SET, AND/OR A
BIT FAILED TO CLEAR THE ERROR PRINTOUT SHOWS THE ROUTINE THAT
FAILED AND THE PC WHERE THE ERROR WAS DETECTED

RT11- TESTS THAT RESET AND CLEAR CLEAR ALL R/W BITS IN THE CSR TWO
ERROR TYPES ARE DETECTED IN THIS ROUTINE SHOWING THE CONTENTS OF THE
CSR AFTER THE RESET & CLEAR INSTRUCTION THE PROGRAM AUTOMATICALLY
LOOPS IF AN ERROR OCCURS SHOWN BELOW IS THE ERROR TYPEOUT
RT11 PC=XXXXXX ERR S B 00000 WAS XXXXXX

RT12 LOADS A BINARY COUNT PATTERN INTO THE BKCSR AND READS BACK THE RESULTS IF THE DATA READ BACK IS INCORRECT AN ERROR IS INDICATED THE SCOPE SWITCH WILL CAUSE THE PROGRAM TO RELOAD THE BINARY NUMBER AND REPEAT THE TEST THE ERROR TYPEOUT SHOWS CORRECT AND ACTUAL RESULTS
THE SECOND PORTION OF THE TEST CLEARS THE PREVIOUSLY LOADED NUMBER IF THE SCOPE SWITCH IS SET THE PROGRAM LOOPS BACK AND REPEATS THE CLEAR INSTRUCTION

RT13 THIS ROUTINE LOADS RANDOM NUMBERS INTO THE BKCSR IF A RANDOM NUMBER IS LOADED INCORRECTLY AN ERROR IS INDICATED SHOWING THE CORRECT AND ACTUAL RESULTS

RT14 THIS ROUTINE TESTS THAT RESET WILL CLEAR ALL BREAK STATUS REGISTER (BKCSR) BITS IF ALL BITS DO NOT CLEAR WHEN THE RESET IS GIVEN AN ERROR IS INDICATED THE ERROR TYPEOUT SHOWS THE CORRECT RESULT (ALL 0'S) AND THE ACTUAL RESULT

RT15-RT16 THESE ROUTINES ARE THE SAME AS RT12 & RT13 EXCEPT THAT THE BASE REGISTER IS TESTED

RT17 THIS ROUTINE TESTS THAT ALL BAR BITS CAN BE INDIVIDUALLY SET AND CLEARED THE ROUTINE SHIFTS A '1' THROUGH THE BAR THEREBY SETTING EACH BAR BIT AND THEN THE BAR BIT IS CLEARED THE ERROR TYPEOUTS SHOW CORRECT AND ACTUAL RESULTS

RT20 THIS ROUTINE TESTS THAT RESET AND CLEAR CLEAR ALL BAR BITS THE ERROR TYPEOUT SHOWS CORRECT AND ACTUAL RESULTS

RT21-RT23 THESE ROUTINES TEST THAT THE CSR, BAR, AND BKCSR RESPOND PROPERLY TO BYTE COMMANDS BOTH BYTES ARE REFERENCED IN THESE ROUTINES USING CLRB INSTRUCTIONS THE ERROR TYPEOUT SHOWS CORRECT AND ACTUAL RESULTS

RT24 THIS ROUTINE TESTS THAT THE DM11 CAN INTERRUPT THE PROCESSOR VIA THE OVER RUN BIT (CSR BIT 13) THE ERROR TYPEOUT SHOWS THE ROUTINE NUMBER AND THE PC WHERE THE ERROR WAS DETECTED

RT25 THIS ROUTINE TESTS THAT THE DM11 INTERRUPTS THE PROCESSOR AT THE PROPER LEVEL

RT26-RT45 THESE ROUTINES TEST THE BASIC TRANSMITTER FUNCTIONS ON EACH LINE

RT46-RT65 THESE ROUTINES TEST THE BASIC RECEIVER FUNCTIONS ON EACH LINE

RT66 THIS ROUTINE TESTS THAT THE DM11 WILL SET THE NEX BIT (CSR BIT 14) WHEN THE DM11 TRIES TO TRANSMIT FROM NON-EXISTANT MEMORY ALL LINES ARE INDIVIDUALLY TRANSMITTED ON THE ERROR TYPEOUT SHOWS THE FAILING LINE ALSO TESTED IS THAT THE NEX BIT WHEN SET CAUSES AN INTERRUPT

RT67 THIS ROUTINE TESTS THAT THE NEX BIT (CSR B T 14) SETS WHEN THE DM11 TRIES TO REFERENCE THE TUMBLE TABLE THAT S IN NON-EXISTANT MEMORY

RT70 THIS ROUTINE TESTS THAT WHEN THE GO B T (CSR BIT 0) S CLEAR THAT NO DATA IS RECEIVED ON ANY LINE ALL LINES ARE TRANSMITTED ON AND AFTER THE TRANSMISSION IS COMPLETE THE RECEIVER DONE FLAG IS TESTED THE ERROR TYPEOUT SHOWS THE LINE ON WHICH DATA WAS RECEIVED
THE TYPEOUT SHOWN BELOW SHOWS THAT DATA WAS RECEIVED ON LINE 0
RT70 PC=XXXXXX ERRS/B 000001 WAS 000001

RT71 THIS ROUTINE TESTS THAT THE CURRENT ADDRESS IS INCREMENTED PROPERLY BY THE DM11 THE TABLE BELOW SHOWS THE ADDRESS LOADED INTO IN THE CURRENT ADDRESS TABLE BEFORE 2 CHARACTERS ARE TRANSMITTED AND THE RESULTANT ADDRESS AFTER THE CHARACTER IS TRANSMITTED

BEFORE	AFTER	BEFORE	AFTER
000000	000001	000777	001000
000001	000002	001777	002000
000003	000004	003777	004000
000007	000010	007777	010000
000017	000020	017777	020000
000037	000040	037777	040000
000077	000100	077777	100000
000177	000200	177777	000000

000377 000400

THE ERROR TYPEOUT SHOWS CORRECT AND ACTUAL CURRENT ADDRESS
RT72 THIS ROUTINE TESTS THAT DATA CAN BE TRANSMITTED FROM ALL AVAILABLE CORE AND RECEIVED CORRECTLY THIS IS DONE BY TRANSMITTING 1 CHARACTER FROM SEVERAL ADDRESSES IN EACH 4K BLOCK OF CORE ON LINE 0 THE ERROR TYPEOUT WILL SHOW TRANSMITTED AND ACTUAL RECEIVED DATA IF A DATA ERROR RESULTED WHEN TRANSMITTING FROM THE FIRST 4K OF CORE EXAMINE THE CURRENT ADDRESS OF LINE 0 TO DETERMINE WHERE IN THE FIRST 4K OF CORE THE DM11 WAS TRANSMITTING FROM WHEN ERROR OCCURRED, FOR ERRORS IN OTHER 4K BLOCKS THE CORRECT RESULT CORRELATES TO THE ADDRESS WHERE THE ERROR OCCURRED FOR EXAMPLE

RT72 PC=XXXXXX ERR S/B 000001 WAS XXXXXX
INDICATES THAT THE DM11 FAILED TO TRANSMIT AND RECEIVE CORRECT DATA WHEN TRANSMITTING FROM LOCAT ON 20000
THE TEST IS ABORTED BEFORE TRANSMITTING IF THE CORE LOCAT ON IS NON-EXISTANT

RT73 THIS ROUTINE TESTS THAT THE TRANSMITTER CAN TRANSMIT 100 CHARACTERS ON EACH LINE THE ROUTINE TESTS THAT EXACTLY 100 CHARACTERS HAVE BEEN TRANSMITTED BEFORE READY (CSR BIT15) SETS AND THE BAR BIT CLEARS THE ERROR TYPEOUT GIVES THE NUMBER OF CHARACTERS RECEIVED AT THE TIME OF AN ERROR, AND THE FAILING LINE NUMBER (X2)

RT74 THIS ROUTINE TESTS THAT THE DM11 WILL STORE DATA SEQUENTIALLY IN THE TUMBLE TABLE AND ALSO THAT THE POINTER RETURNS TO THE TOP OF THE TABLE WHEN 64 CHARACTERS HAVE BEEN RECEIVED

RT75-114 THESE ROUTINES CHECK THAT A BREAK CAN BE TRANSMITTED AND RECEIVED ON ALL LINES

R115-R134 THESE ROUTINES INDIVIDUALLY TRANSMIT, RECEIVE AND CHECK DATA PLUS PARITY ON EACH OF THE 16 DM11 LINES ONLY DATA AND PARITY ERRORS ARE REPORTED

RT131 THIS ROUTINE SIMULTANEOUSLY TRANSMITS AND RECEIVES A CHARACTER (ALL 1'S) ON THE 16 DM11 LINES THE FOLLOWING TESTS ARE PERFORMED

- A THERE ARE 16 DATA ENTRIES (1 PER LINE)
- B THERE ISN'T A 17TH ENTRY
- C DATA IS CORRECT
- D ONE ENTRY FOR EACH LINE

RT136 THIS ROUTINE TRANSMITS A BREAK ON EACH LINE TESTS PERFORMED ARE THE SAME AS IN RT135

RT137-RT144 THESE ROUTINES TRANSMIT 64 CHARACTERS ON EACH LINE WITH A DELAY BEFORE BEGINNING TRANSMISSION ON THE NEXT SUCCESSIVE LINE THE DELAY BEFORE TRANSMITTING ON THE NEXT LINE IS HALVED BY SUCCESSIVE TESTS NO DATA CHECKING IS PERFORMED BY THESE TESTS TESTED ARE THAT OVER RUN (CSR BIT13) AND NEX (CSR BIT14) ARE NOT SET DURING TRANSMISSION/RECEPTION

RT145 THIS ROUTINE TESTS PROPER OPERATION OF THE HALF DUPLEX BIT (CSR BIT1)

RT146 THIS ROUTINE TESTS THAT THE DM11 COMES TO AN 'ORDERLY HALT' WHEN THE RESET INSTRUCTION IS GIVEN 'ORDERLY HALT' IS DEFINED AS CSR, BAR, AND BKCS CLEAR IMMEDIATELY AFTER THE RESET INSTRUCTION AND STAY CLEARED

5 2 PPG1- TRANSMITTER SCOPE LOOP
PROGRAM 1 ALLOWS THE USER TO SCOPE THE DM11 TRANSMITTER FUNCTIONS WITH THE DM11 CONTINUOUSLY RUNNING UNDER USER SUPPLIED PARAMETERS

5 3 PRG2- TRANSMITTER/RECEIVER SCOPE LOOP
PROGRAM 2 ALLOWS THE USER TO SCOPE THE DM11 RECEIVER FUNCTIONS WITH THE DM11 CONTINUOUSLY RUNNING UNDER USER SUPPLIED PARAMETERS

6 0 PROGRAM 1 AND PROGRAM 2 PARAMETERS
WHEN PROGRAM 1 OR PROGRAM 2 ARE SELECTED ADDITIONAL PARAMETERS WILL
BE REQUESTED BY EACH PROGRAM AS SHOWN BELOW

A TYPE LINES TO BE TESTED
EXAMPLES
TYPE TO SELECT LINE(S)
1 0
3 1,0
10 3
17 3,2,1,0
50 5,3
3101 10,7,6,0
17770 14,13,12,11,10,7,6,5,4,3
177777 ALL
NOTE, LINE NUMBERS ARE GIVEN IN OCTAL

B HOW MANY CHARACTERS
TYPE THE NUMBER OF CHARACTERS YOU WISH TO TRANSMIT NOTE,
THE NUMBER OF CHARACTERS MUST BE LESS THAN 200, AND IS TAKEN
IN OCTAL

C PUT CHARACTER IN SR (0-7), DELAY IN SR (8-15)
SELF-EXPLANATORY NOTE, THE DELAY REFERS TO A DELAY AFTER
ALL THE CHARACTERS HAVE BEEN TRANSMITTED AND BEFORE A NEW
TRANSMISSION PERIOD BEGINS

7 0 PROGRAM LIMITATIONS
BECAUSE THE DM11 DIAGNOSTICS ARE INSENSITIVE TO 'REAL' ELAPSED TIME
THE DIAGNOSTIC DOES NOT 'KNOW' IF THE DM11 IS OPERATING AT THE COR-
RECT FREQUENCY OR THAT THE STOP CODE SELECTION LOGIC IS CORRECT,
THESE SHOULD BE CHECKED WITH A SCOPE

8 0 PROGRAM NOTES
IF THE POWER FAILS THE PROGRAM TYPES AN ERPOP MESSAGE INDICATING THE
ROUTINE THAT WAS RUNNING (PROG #0 ONLY) AND RESTARTS THE PROGRAM

***** IMPORTANT NOTE *****

POWER FAIL TEST

A TEST OF THE POWER FAIL LOGIC SHOULD BE PERFORMED ON EACH UNIT
SELECT & RUN ROUTINE 144 (L A = 210 SR = 5144 PRESS START) TURN
THE POWER OFF THEN ON THE PROGRAM WILL TYPE OUT THE POWER FAIL
ERROR

P144 PC=0J3622

AND CONTINUE RUNNING ROUTINE 144 LOWER SR 9 AND WAIT FOR END OF
TEST MESSAGE 'TEST DZDMA COMPLETE'

NOTE IF THE POWER IS TURNED OFF DURING A RESET INSTRUCTION THE
PROGRAM WILL HALT PRESS CONTINUE AND REPEAT THE TEST

IF THE PROGRAM HANGS THE BUS EXAMINE THE CONTENTS OF PTNNO THE
CONTENTS OF RTNNO IS THE ROUTINE NUMBER THAT WAS RUNNING AT THE TIME
OF THE FAILURE

%

TITLE MAINDEC-11-DZDMA-C DM11 LOGIC TESTS
NLIST MC,MD,CND
LIST ME
ENABLE ABS,AMA

.DM11 LOGIC TESTS DIAGNOSTIC (MAINDEC-11-DZDMA)
.COPYRIGHT 1972,1977 DIGITAL EQUIPMENT CORP , MAYNARD, MASS 01754
.PRGO- INPUT-OUTPUT LOGIC TESTS
.PRG1- TRANSMITTER SCOPE LOOP
.PRG2- TRANSMIT/RECEIVE SCOPE LOOP
.STANDARD SR SWITCH OPTIONS (SWITCH SET TO A 1)
.SR15- HALT ON ERROR
.SR14- SCOPE
.SR13- INHIBIT PRINTOUT
.SR12- INHIBIT TRACE (NOT USED)
.SR11- INHIBIT ITERATION
.SR10- LOOP PROGRAM (NOT USED)
.SR9- LOOP ROUTINE
.SR8- RING BELL ON AN ERROR
.SR6 THROUGH SR0 - NUMBER OF ROUTINE TO BE LOOPED

EQUATE STATEMENTS

177776
177776
000004
000240
000000
100000
100000
040000
020000
010000
004000
002000
001000
000400
000200
000100
000040
000020
000010
000004
000002
000001
100000
040000
020000
010000
004000
002000
001000
000400
000200
000100

CC=177776
PSW=177776
ERRVEC=4
NOP=240
OPEN=0
MANUAL=BIT15
LBIT17=100000
LBIT16=40000
LBIT15=20000
LBIT14=10000
LBIT13=4000
LBIT12=2000
LBIT11=1000
LBIT10=400
LBIT7=200
LBIT6=100
LBIT5=40
LBIT4=20
LBIT3=10
LBIT2=4
LBIT1=2
LBIT0=1
BIT15=100000
BIT14=40000
BIT13=20000
BIT12=10000
BIT11=4000
BIT10=2000
BIT9=1000
BIT8=400
BIT7=200
BIT6=100

ADDRESS OF ERROR TRAP VECTOR

000040
000020
000010
000004
000002
000001
005726
022626
000340
000300
000240
000200
000140
000100
000040
000000

BIT5=40
BIT4=20
BIT3=10
BIT2=4
BIT1=2
BIT0=1
POPSP=5726
POPSP2=022626
PRTY7=340
PRTY6=300
PRTY5=240
PRTY4=200
PRTY3=140
PRTY2=100
PRTY1=40
PRTY0=0

,POP THE STACK SAME AS TST (6)+
,POP STACK TWICE SAME AS CMP (6)+, (6)+
,PRIORITY LEVEL DEFINITIONS

LINE NUMBERS

000000
000002
000004
000006
000010
000012
000014
000016
000020
000022
000024
000026
000030
000032
000034
000036
000000
000001
000002
000003
000004
000005
000006
000007

LINE0=3
LINE1=2
LINE2=4
LINE3=6
LINE4=10
LINE5=12
LINE6=14
LINE7=16
LINE10=20
LINE11=22
LINE12=24
LINE13=26
LINE14=30
LINE15=32
LINE16=34
LINE17=36
R0=%0
R1=%1
R2=%2
R3=%3
R4=%4
R5=%5
SP=%6
PC=%7

EMT CALLS

104000
104001
104002
104003
104004
104005
104006
104007
104010
104011
104012
104013
104014
104015

TYPE=EMT+0
ERROR=EMT+1
DATCHK=EMT+2
CHALT=EMT+3
EHALT=EMT+4
SRESET=EMT+5
SCOPE=EMT+6
SAVREG=EMT+7
RSTREG=EMT+10
ERROR1=EMT+11
INITIALIZE=EMT+12
SUSWR=EMT+13
KBDIN=EMT+14
CNTLIJ=EMT+15

Address	Hex	Label	Code	Description
104400	000007		DELAY=TRAP+0	
177777			BELL=007	
			RTLAST=-1	
000000	000000		Y=0	
000002	177777		X=-1	
000004	000000		A=0	
000006	000000		=0	
000010	000002		+2	. UNASSIGNED TRAP
000012	000000		HALT	
000014	000006	TRACHER	+2	. SP OVERFLOW, BUS ERROR TRAP
000016	000000		HALT	
000020	000012		+2	. RESERVED INSTRUCTION TRAP
000022	000000		HALT	
000024	000016		+2	. TRACE TRAP
000026	000000		HALT	
000030	000022		+2	. TRAP TO CALL IOX
000032	000000		HALT	
000034	000026		+2	. POWER FAIL TRAP
000036	000000		HALT	
000040	002606		EMT INT	. EMT TRAP
000042	000340		PRTY7	
000044	005506		DLY	. TRAP TRAP SIMILAR TO EMT
000046	000340		PRTY7	
000050	000042		+2	
000052	000000		HALT	. TRAPPED TO PREVIOUS ADDRESS
000054	000046		+2	
000056	000000		HALT	. TRAPPED TO PREVIOUS ADDRESS
000060	000052		+2	
000062	000000		HALT	. TRAPPED TO PREVIOUS ADDRESS
000064	000056		+2	
000066	000000		HALT	. TRAPPED TO PREVIOUS ADDRESS
000070	000062		+2	
000072	000000		HALT	. TRAPPED TO PREVIOUS ADDRESS
000074	000066		+2	
000076	000000		HALT	. TRAPPED TO PREVIOUS ADDRESS
000100	000072		+2	
000102	000000		HALT	. TRAPPED TO PREVIOUS ADDRESS
000104	000076		+2	
000106	000000		HALT	. TRAPPED TO PREVIOUS ADDRESS
000110	000102		+2	
000112	000000		HALT	. TRAPPED TO PREVIOUS ADDRESS
000114	000106		+2	
000116	000000		HALT	. TRAPPED TO PREVIOUS ADDRESS
000120	000112		+2	
000122	000000		HALT	. TRAPPED TO PREVIOUS ADDRESS
000124	000116		+2	
000126	000000		HALT	. TRAPPED TO PREVIOUS ADDRESS
000130	000122		+2	
000132	000000		HALT	. TRAPPED TO PREVIOUS ADDRESS
000134	000126		+2	
000136	000000		HALT	. TRAPPED TO PREVIOUS ADDRESS

000140	000142	+2	
000142	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000144	000146	+2	
000146	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000150	000152	+2	
000152	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000154	000156	+2	
000156	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000160	000162	+2	
000162	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000164	000166	+2	
000166	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000170	000172	+2	
000172	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000174	000176	+2	
000176	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000200	000202	+2	
000202	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000204	000206	+2	
000206	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000210	000212	+2	
000212	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000214	000216	+2	
000216	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000220	000222	+2	
000222	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000224	000226	+2	
000226	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000230	000232	+2	
000232	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000234	000236	+2	
000236	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000240	000242	+2	
000242	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000244	000246	+2	
000246	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000250	000252	+2	
000252	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000254	000256	+2	
000256	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000260	000262	+2	
000262	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000264	000266	+2	
000266	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000270	000272	+2	
000272	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000274	000276	+2	
000276	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000300	000302	+2	
000302	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000304	000306	+2	
000306	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000310	000312	+2	
000312	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000314	000316	+2	
000316	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS

000320	000322	+2	
000322	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000324	000326	+2	
000326	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000330	000332	+2	
000332	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000334	000336	+2	
000336	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000340	000342	+2	
000342	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000344	000346	+2	
000346	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000350	000352	+2	
000352	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000354	000356	+2	
000356	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000360	000362	+2	
000362	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000364	000366	+2	
000366	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000370	000372	+2	
000372	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS
000374	000376	+2	
000376	000000	HALT	, TRAPPED TO PREVIOUS ADDRESS

000046	000046		=46		
	002544		SENDAD		
	000052		=52		
000052	060000		60000		
	000174		=174		
000174	000000	DISPREG	0		
000176	000000	SWREG	0		
	000200		=200		
000200	000137	002066	JMP	@#START	, GO TO START OF DIAGNOSTIC
000204	000137	002134	JMP	@#RSTAT1	, GO GET PROGRAM # & RESTART PPROGRAM
					, USING PREVIOUS DM11 PARAMETERS
000210	000137	002222	JMP	@#PSTAT2	, RESTART PREVIOUS PROGRAM USING
					, PREVIOUS DM11 PARAMETERS
	001100		=1100		
001100	000000	SPBOT	0		
001102	177570	SWP	177570		
001104	177570	DISPLAY	177570		
001106	000000	CAT	OPEN		, STARTING ADDRESS OF
	001146		=CAT+32		, CURRENT ADDRESS TABLE
001146	000000	WCT	OPEN		, STARTING ADDRESS OF
	001206		=WCT+32		, WORD COUNT TABLE
001206	000000	BAT	OPEN		, STARTING ADDRESS OF
	001246		=BAT+32		, BIT ASSEMBLY TABLE
001246	000000	VAC	OPEN		, 32 SPARE WORDS
001250	175000	CSR	175000		, ADDRESS OF CLOCK STATUS REGISTER
001252	175002	BAP	175002		, ADDRESS OF BUFFER ACTIVE REGISTER
001254	175004	BKCSR	175004		, ADDRESS OF BREAK STATUS REGISTER
001256	175006	BASREG	175006		, ADDRESS OF BASE REGISTER
001260	000000	CLKINT	OPEN		, DM11 VECTOR ADDRESS (RECEIVER)
001262	000240	CLKLVL	PRTY5		, PRIORITY LEVEL
001264	000000	XMTINT	OPEN		, DM11 VECTOR ADDRESS (TRANSMITTER)
001266	000240	XMTLVL	PRTY5		, TRANSMITTER PRIORITY LEVEL
001270	000000	TTDAT	OPEN		, TUMBLE TABLE DATA
001272	000000	LINBIT	OPEN		, LINE BIT (FOR BAP)
001274	000000	RCVDAT	OPEN		
001276	000000	XMTDAT	OPEN		
001300	000000	CARMSK	OPEN		
	001306		=VAC+32		
001306	000000	TUMTAB	OPEN		, STARTING ADDRESS OF
	001506		=TUMTAB+128		, TUMBLE TABLE
001506	000000	KSTART	OPEN		, CURRENT PROGRAM START ADDRESS
001510	000000	CURTST	OPEN		, CONTAINS ADDR OF CURRENT TEST
001512	000000	RTNNO	OPEN		, CONTAINS CURRENT TEST #
001514	000000	NXTST	OPEN		, CONTAINS ADDR OF NEXT TEST
001516	000000	ICTR	OPEN		, CONTAINS CURRENT ITERATION COUNT
001520	000000	SCOPTR	OPEN		, CONTAINS CURRENT SCOPE POINTER
001522	000000	PPGLIM	OPEN		
001524	006604	PPGTAB	PRG0		, PRG0 START ADDRESS
001526	016222		PRG1		, PRG1 START ADDRESS
001530	016270		PRG2		, PRG2 START ADDRESS

001532	006626	RSTART	PRGOR	, PRGO RESTART ADDRESS
001534	016232		PRG1R	, PRG1 " "
001536	016300		PRG2R	, PRG2 " "
001540	003030	EMTTAB	TYP	, POINTER TO TYPEOUT ROUTINE
001542	001654		ERR	, POINTER TO ERROR ROUTINE
001544	001634		DTCHK	, POINTER TO DATA COMPARISON ROUTINE
001546	000000		0	
001550	000000		0	
001552	002740		SRSETT	, POINTER TO RESET ROUTINE
001554	002406		ESCOPE	, POINTER TO SCOPE ROUTINE
001556	002640		SAVPG	, POINTER TO SAVE REGISTERS ROUTINE
001560	002700		RSTRG	, POINTER TO RESTORE REGISTERS ROUTINE
001562	001672		ERR1	, POINTER TO ERROR1 ROUTINE
001564	003142		INIT	, POINTER TO INIT ALIZE ROUTINE
001566	017074		SUSWRP	
001570	017154		KBDINTT	
001572	017230		CNTLUU	
001574	177560	TKCSR	177560	
001576	177562	TKDBR	177562	
001600	177564	TPCSR	177564	
001602	177566	TPDBR	177566	
001604	000000	COUNT	OPEN	
001606	000000	PCADD	OPEN	
001610	000000	APCADD	OPEN	
001612	000000	PRVCNT	OPEN	
001614	175001	CSR	175001	
001616	175003	BAR	175003	
001620	175005	BKCSF	175005	
001622	175007	BASREG	175007	
001624	000000	PASS	OPEN	

```

, ROUTINE TO TYPE OUT INCORRECT ROUTINE SELECTED
001626 104000 INCRTN TYPE
001630 017444 M1 , TYPE INCORRECT ROUTINE SELECTED
001632 000207 RTS %7 , EXIT

, DATA COMPARISON ROUTINE
001634 123737 001274 001276 DTCHK CMPB RCVDAT, XMTDAT , COMPARE RECEIVED & TRANSMITTED DATA
001642 001403 BEQ 1$ , CHARS BRANCH IF SAME
001644 004737 002040 JSR 7, CNVDAT , CONVERT RCVDAT & XMTDAT TO ASCII
001650 104011 ERROR1
001652 000002 1$ RTI , EXIT

, ERROR ROUTINE WHENEVER THE PROGRAM DETECTS AN ERROR THE EPPOR
, AND ERROR1 EMT INSTRUCTIONS ENTER HERE ERROR AT ERR , AND
, ERROR1 AT ERR1
001654 012737 000402 001754 ERR MOV #402, ERRB , MOV BR +6 TO ERRB
001662 013737 001606 00161U MOV PCADD, APCADD , GET PC WHERE ERROR OCCUPED
001670 000410 BR EPRA
001672 012737 000240 001754 ERR1 MOV #240, ERRB , MOVE NOP TO ERRB
001700 013737 001606 00161U MOV PCADD, APCADD , GET PC WHERE ERROR OCCUPED
001706 004737 002040 JSR 7, CNVDAT , CONVERT RCVDAT & XMIT DAT TO ASCII
001712 104014 EPRA KBDIN , GO CHECK FOR G
001714 032777 020000 17716J BIT #B, T13, @SWP , ERROR PRINTOUT DESIPED
001722 001017 BNE ERRC , BRANCH IF NO PRINTOUT
001724 004537 005662 JSR 5, OACNV , CONVERT
001730 001610 APCADD , DATA
001732 017650 APC , TO
001734 000006 6 , ASCII
001736 004537 005662 JSR 5, OACNV , FOR
001742 001512 RTNNO , PRINTOUT
001744 017642 ATNUMB
001746 000003 3
001750 104000 TYPE , TYPE ERROR
001752 017637 EMO , MESSAGE
001754 000000 ERPB OPEN , NOP IF ERROR1, BR +6 IF EPPOR
001756 104000 TYPE , TYPE ANOTHER MESSAGE
001760 017401 ERDAT , IF ERROR 1
001762 032777 000400 177112 EPRC BIT #B, T8, @SWP , RING BELL ON EPPOR?
001770 001411 BEQ ERRC , BRANCH IF NO BELL ON EPPOR
001772 105777 177602 TSTB @TPCSR , TELEPRINTER
001776 100375 BPL -4 , READY?
002000 012777 000007 177574 MOV #BELL, @TPDBR , RING THE BELL
002006 105777 177566 TSTB @TPCSR , WAIT FOR THE BELL TO PING
002012 100375 BPL -4
002014 023737 000042 00004E EPRC CMP @#42, @#46 , ACT11?
002022 001403 BEQ EPRHLT
002024 005777 177052 TST @SWP , HALT ON EPPOR
002030 100001 BPL ERPEX , GO TO EXIT IF NO HALT ON EPPOR
002032 000000 EPRHLT HALT
002034 104014 ERPEX KBDIN , CHECK FOR G
002036 000002 RTI , RETURN

```

SUBROUTINE TO CONVERT RCVDAT AND XMTDAT TO ASCII AND PLACE

002040	004537	005662	. IN MESSAGE		
002044	001276		CNV DAT JSR	5. OACNV	
002046	017413		XMT DAT		
002050	000006		AASB		
002052	004537	005662	6		
002056	001274		JSR	5. OACNV	
002060	017427		RCV DAT		
002062	000006		AWAS		
002064	000207		6		
			PTS	7	.EXIT

. THE FIRST PART OF THE START ROUTINE CONTAINS A SHORT
 . ROUTINE TO CHECK FOR MEMORY MANAGEMENT. ALTHOUGH THIS
 . DIAGNOSTIC DOES NOT USE MEMORY MANAGEMENT, ITS PRESENCE
 . INDICATES THAT OVER 28K OF MEMORY MAY BE PRESENT IN WHICH
 . CASE TESTS RT66 AND RT67 MAY FAIL IF MEM MAN IS
 . PRESENT THESE TESTS ARE SKIPPED BY THE PROGRAM

```

002066 012706 001100 START MOV #SPBOT,%6
002072 104013 SUSWR .SEE IF SWITCH-LESS PROCESSOR
002074 012737 002116 000004 MOV #15,@#ERRVEC .SET UP FOR ERROR TRAP
002102 005737 172300 TST @#172300 .TEST FOR KT11
002106 012737 012424 012036 MOV #RT70,@#RT65+2 .KT11 PRESENT, SET UP TO
. SKIP RT66 AND RT67

002114 000402 BR +6
002116 012706 001100 1$ MOV #SPBOT,%6 .TRAP OCCURRED, NO KT11 PRESENT.
. RESET STACK
002122 012737 000006 000004 MOV #ERRVEC+2,@#ERRVEC .RESET ERROR TRAP

. OUT INTERRUPTS (SET PRIORITY LEVEL 7)
. GET DM11 PARAMETERS
002130 004737 003172 RSTAT1 JSR 7 @#DMPAP
002134 012706 001100 MOV #SPBOT,%6
002140 104012 INITIALIZE
002142 023737 000042 000046 CMP @#42,@#46 .ACT11?
002150 001405 BEQ PRGNUM+2
002152 104000 TYPE
002154 017436 M3
002156 004537 004124 JSR 5,RECD .GET PRGNUM AND PUT IT
002162 000000 PRGNUM 0 .HERE
002164 043737 001522 002162 BIC PRGLIM,PRGNUM .MASK OFF UNUSED BITS
002172 006337 002162 ASL PRGNUM .SHIFT PROGRAM #
002176 012737 004304 000024 MOV #PFAIL,24
002204 012737 000340 000026 MOV #PTY7,26
002212 013700 002162 MOV PRGNUM,%0 .GET PROGRAM #
002216 000170 001524 JMP @PRGTAB(0) .GO START PROGRAM
002222 012737 004304 000024 RSTAT2 MOV #PFAIL,24
002230 012737 000340 000026 MOV #PTY7,26
002236 012706 001100 MOV #SPBOT,%6
002242 104012 INITIALIZE
002244 013700 002162 MOV PRGNUM,%0 .GET PROGRAM #
002250 000170 001532 JMP @RSTART(0) .GO RESTART PROGRAM
002254 022737 000176 001102 SPSET CMP #SWREG,SWR
002262 001410 BEQ 1$
002264 023737 000042 000046 CMP @#42,@#46 .ACT11?
002272 001405 BEQ GETRDY
002274 104000 TYPE .TYPE MESSAGE TO REQUEST SWITCH
002276 017454 M3 REGISTER SETTINGS
002300 000000 HALT .WAIT FOR OPERATOR TO SET SWITCHES
002302 000401 BR GETRDY
002304 104015 1$ CNTLU .GO GET SWREG SETTINGS
002306 013737 001506 001514 GETRDY MOV KSTART,NXTST .ADDR OF 1ST ROUTINE TO NXTST
002314 012737 000006 000004 GTRDYX MOV #6,@#ERRVEC .RESET ERROR TRAP VECTOR
002322 104012 INITIALIZE
002324 004737 002554 GTRDYA JSR %7,FORWD .ROLL FORWARD TO "NEXT" ROUTINE
002330 032777 001000 176544 BIT #BIT9,@SWR .CHECK SELECT ROUTINE SWITCH
002336 001003 BNE GTRDYC .BRANCH IF SELECT ROUTINE SWITCH IS SET
  
```

002340	000177	177144			JMP	@CURTST		. GO RUN CURRENT ROUTINE
002344	000457				BR	SCOPED		. NO GO MANUAL RTN BYPASSED
002346	017700	176530		GTRDYC	MOV	@SWR,%0		. (SR) TO R0
002352	042700	177600			BIC	#177600,%0		. MASK UNDESIRED BITS
002356	123700	001512			CMPB	RTNNO,%0		. COMPARE RTNNO TO (R0)
002362	001002				BNE	GTRDYD		. BRANCH IF ROUTINE NOT FOUND YET
002364	000177	177120			JMP	@CURTST		. GO RUN ROUTINE
002370	022737	177777	001514	GTRDYD	CMP	#-1,NXTST		. NO CHECK FOR LAST ROUTINE
002376	001352				BNE	GTRDYA		. BRANCH IF NOT LAST ROUTINE
002400	004737	001626			JSR	%7, INCRTN		. YES INCORRECT ROUTINE SELECTED
002404	000740				BR	GETRDY		. START OVER
. SCOPE SERVICE ROUTINE								
002406	000240			ESCOPE	NOP			
002410	104014				KBDIN			. CHECK FOR G
002412	005077	176634			CLR	@BAR		. CLEAR ALL DM11 REGISTERS
002416	005077	176626			CLR	@CSR		. AND SET BASE REGISTER
002422	005077	176626			CLR	@BKCSR		. AT THE STARTING ADDRESS
002426	104012				INITIALIZE			
002430	013716	001520			MOV	SCOPTR,(SP)		
002434	032777	040000	176440		BIT	#BIT14,@SWR		. CHECK FOR SCOPE OPTION
002442	001402				BEQ	SCOPEB		. BRANCH IF SCOPE SW NOT SET
002444	000176	000000		SCOPEA	JMP	@(SP)		. RETURN TO ROUTINE
002450	032777	004000	176424	SCOPEB	BIT	#BIT11,@SWR		. TEST INHIBIT ITERATION SWITCH
002456	001012				BNE	SCOPED		. BRANCH IF INHIBIT ITERATION SW SET
002460	023737	000042	000046		CMP	@#42,@#46		. ACT11?
002466	001003				BNE	15		. BR IF NO
002470	005737	001624			TST	@#PASS		. 1ST PASS?
002474	001403				BEQ	SCOPED		. BR IF YES
002476	005337	001516	15		DEC	ICTR		. DECREMENT ITERATION COUNT
002502	001360				BNE	SCOPEA		. BRANCH IF COUNT NOT 0
002504	032777	001000	176370	SCOPED	BIT	#BIT9,@SWR		. CHECK SELECT ROUTINE SWITCH
002512	001275				BNE	GETRDY		. BRANCH IF SELECT RTN SW SET
002514	022737	177777	001514		CMP	#-1,NXTST		. LAST TEST?
002522	001274				BNE	GTRDYX		. BRANCH IF NOT LAST TEST
002524	005237	001624			INC	@#PASS		
002530	104000				TYPE			. TYPE
002532	017447				M2			. 'PRGEND'
002534	013700	000042			MOV	@#42,%0		. CHECK XADP/ACT11 MONITOR HOOK
002540	001662				BEQ	GETRDY		
002542	000005				RESET			
002544	004710			SENDAD	JSR	7,101		. RETURN TO XYDP/ACT11 MONITOR
002546	000240				NOP			
002550	000240				NOP			
002552	000240				NOP			
002554	013705	001514		FORWD	MOV	NXTST,%5		. ADDR OF NEXT ROUTINE TO R5
002560	012537	001512			MOV	(5)+,RTNNO		. GET NEXT ROUTINE NUMBER
002564	012537	001514			MOV	(5)+,NXTST		. GET ADDR OF NEXT "NEXT" ROUTINE
002570	012537	001516			MOV	(5)+,ICTR		. GET ITERATION COUNT
002574	012537	001520			MOV	(5)+,SCOPTR		. GET SCOPE LOOP ENTRY POINTER
002600	010537	001510		FORWDA	MOV	%5,CURTST		. ADDR OF NOW CURRENT TEST TO CURTST
002604	000207				RTS	%7		. EXIT FORWD SUBROUTINE
. EMT TRAP INTERPRETER								
002606	011646			EMTINT	MOV	(6) - b1		. GET PC OF NEXT INSTRUCTION

002610	162716	000002	SUB	#2, (6)	.FORM PC OF EMT INSTRUCTION
002614	011637	001606	MOV	(6), PCADD	.GET PC OF EMT INSTRUCTION
002620	017616	000000	MOV	2(6), (6)	.GET EMT INSTRUCTION
002624	105066	000001	CLRB	1(6)	.CLEAR MSH OF EMT INSTRUCTION
002630	006316		ASL	(6)	.SHIFT EMT IDENTIFIER
002632	062716	001540	ADD	#EMTTAB, (6)	
002636	013607		MOV	2(6)+, %7	.GO TO PROPER EMT

			.SAVE REGS 0 TO 4 SUBROUTINE			
002640	012637	002674	SAVRG	MOV	(6)+, SVRPC	.SAVE PC AND PSW
002644	012637	002676		MOV	(6)+, SVRPSW	
002650	010446			MOV	%4, -(6)	.SAVE REGS 0 - 4
002652	010346			MOV	%3, -(6)	.IN STACK
002654	010246			MOV	%2, -(6)	
002656	010146			MOV	%1, -(6)	
002660	010046			MOV	%0, -(6)	
002662	013746	002676		MOV	SVRPSW, -(6)	.RESTORE PC AND PSW
002666	013746	002674		MOV	SVRPC, -(6)	
002672	000002			RTI		.EXIT
002674	000000		SVRPC	OPEN		
002676	000000		SVRPSW	OPEN		

			.RESTORE REGS 0 TO 4 SUBROUTINE			
002700	012637	002774	RSTRG	MOV	(6)+, RSTPC	.SAVE PC AND PSW
002704	012637	002776		MOV	(6)+, RSTPSW	
002710	012600			MOV	(6)+, %0	.RESTORE REGS 0 - 4
002712	012601			MOV	(6)+, %1	.FROM STACK
002714	012602			MOV	(6)+, %2	
002716	012603			MOV	(6)+, %3	
002720	012604			MOV	(6)+, %4	
002722	013746	002736		MOV	RSTPSW, -(6)	.RESTORE PC AND PSW
002726	013746	002734		MOV	RSTPC, -(6)	
002732	000002			RTI		.EXIT
002734	000000		RSTPC	OPEN		
002736	000000		RSTPSW	OPEN		

			.ROUTINE TO ISSUE RESET			
002740	012700	052525	SPSETT	MOV	#52525, %0	.DATA TO PO
002744	005100			COM	%0	.COMPLEMENT (PO)
002746	010037	002742		MOV	%0, SRSETT+2	. (RO) TO SRSETT+2
002752	000005			RESET		.ISSUE RESET (PO) IS
002754	000002			PTI		.DISPLAYED EXIT

			.RANDOM NUMBER GENERATOR ROUTINE EXITS WITH NUMBER IN REGISTER 0			
002756	013700	003024	RNGEN	MOV	RP1, %0	
002762	006100			ROL	%0	
002764	006100			ROL	%0	
002766	063700	003026		ADD	RP2, %0	
002772	010037	003024		MOV	%0, RP1	
002776	006100			ROL	%0	
003000	006100			ROL	%0	
003002	063700	003026		ADD	RP2, %0	
003006	006100			ROL	%0	
003010	006100			ROL	%0	
003012	010077	003026		MOV	%0, RP2	

```

003016 G13700 003024      MOV      RP1,%0
003022 000207            RTS      %7          .EXIT NUMBER IN RO
003024 001233            RP1     1233
003026 007622            RP2     7622
      .SUBROUTINE TO OUTPUT ASCII MESSAGE ON TELETYPE PRINTER
003030 011600            TYP     MOV      @%6,%0      .GET ADDRESS THAT CONTAINS MESSAGE ADDRESS
003032 062716 000002      ADD      #2,@%6          .SET UP EXIT
003036 011000            MOV      @%0,%0          .ADDRESS OF MESSAGE TO RO
003040 112037 003140      TYFA   MOVVB   (0)+,TYPDAT .GET CHARACTER
003044 122737 000100 003140  CMPB    #100,TYPDAT .CHECK FOR"@"CHARACTER
003052 001001            BNE     TYP          .BRANCH IF NOT"@"
003054 000002            PTI     .TERMINATOR CHAR DONE EXIT
003056 122737 000045 003140  TYPC   CMPB    #45,TYPDAT .CHECK FOR"%"
003064 001412            BEQ     TYP          .BRANCH IF"%"
003066 004737 003074      JSP     %7,TYPD      .TYPE CHAR IN TYPDAT
003072 000762            BR      TYFA
003074 113777 003140 176500  TYPD   MOVVB   TYPDAT,@TPDBR .OUTPUT CHARACTER TO PRINTER
003102 105777 176472      TSTB   @TPCSP          .WAIT FOR DONE FLAG
003106 100375            BPL     -4
003110 000207            RTS      %7          .EXIT
003112 112737 000015 003140  TYPF   MOVVB   #15,TYPDAT .MOVE CARRIAGE RETURN CODE TO TYPDAT
003120 004737 003074      JSP     %7,TYPD      .GO TYPE CHAR
003124 112737 000010 003140  TYPG   MOVVB   #12,TYPDAT .MOVE LF CODE TO TYPDAT
003132 004737 003074      JSP     %7,TYPD      .GO TYPE CHAR
003136 000740            BR      TYFA
003140 000000            TYPDAT OPEN
  
```

.SUBROUTINE TO INITIALIZE STACK POINTER AND SET PROCESSOR PRIORITY

```

      .LEVEL 7
003142 012777 001106 176106  INIT   MOV      #CAT,@BASPEG .INITIALIZE THE BASE REGISTER
003150 012737 000340 177776      MOV      #PTY7,PSW      .SET PRIORITY LEVEL 7
003156 011637 001100      MOV      (SP),SPBOT     .GET RETURN ADDRESS
003162 012706 001100      MOV      #SPBOT,SP      .SET BOTTOM OF THE STACK
003166 000176 000000      JMP     @SP              .RETURN
  
```

.SUBROUTINE TO GET DM11 PARAMETERS

```

      .VECTOR ADDRESS
003172 023737 000042 000046  DMPAR  CMP      @#42,@#46      .ACT1!?
003200 001060            BNE     65              .BR IF NO
      .SIZE FOR INTERRUPT VECTOR IN AUTO MODE
003202 012700 000302      MOV      #302,PO        .SET UP FLOATING VECT AREA
003206 010060 177776      +5     MOV      RO,-2(RO)
003212 012720 000003      MOV      #3,(RO)+
003216 005720            TST     (RO)+
003220 022700 000776      CMP      #776,RO
003224 100370            BPL     45
003226 012737 003316 000014      MOV      #55,@#14      .SET BPT VECT
003234 012737 000340 000016      MOV      #340,@#16     .& PSW
003242 012737 177777 001146  35     MOV      #-1,WCT        .SET TO XMIT 1 CHAR
003250 012737 016564 001106      MOV      #OUTBUF,CAT
003256 012777 000105 175764      MOV      #BIT6+BIT2+BIT0,@CSR .SET IE
003264 005037 177776      CLR     @PSW           .LVL 0
003270 012777 000001 175754      MOV      #LBIT0,@BAP    .XMIT
003276 012737 177777 001604      MOV      #-1,CCUNT     .WAIT
  
```

003304	005337	001604		25	DEC	COUNT	
003310	001375				BNE	25	
003312	104001				ERROR		. NO INT OCCURRED
003314	000752				BR	35	. REPEAT IT
003316	162716	000004		55	SUB	#1, (SP)	. CALC INT VECT
003322	011637	003356			MOV	(SP), @#VECTOR	. STORE IT
003326	012737	000016	000014		MOV	#16, @#14	. RESTORE BPT VECT
003334	004737	004100			JSR	7, OVRLAY	. +2, HALT IN VECT AREA
003340	000415				BR	VECOK	
003342	004737	004100		65	JSR	7, OVRLAY	. PUT HALT, +2 IN VECTOR AREA
003346	104000				TYPE		. ASK USER FOR RECEIVER INT VECTOR
003350	017310				WHERE		. OF UNIT UNDER TEST
003352	004537	004124			JSR	5, RECD	. GET VECTOR AND PUT IT
003356	000000			VECTOR	0		. HERE
003360	005737	003356			TST	VECTOR	
003364	001003				BNE	VECOK	
003366	012737	000300	003356		MOV	#300, VECTOR	. SET VECTOR = TO 0300
003374	023727	003356	000300	VECOK	CMP	VECTOR, #300	. IS VECTOR HIGHER OR
003402	103003				BHIS	VECOKB	. EQUAL TO 0300
003404	104000			VECOKA	TYPE		. TYPE '?'
003406	017444				M1		
003410	000670				BR	DMPAR	. ASK FOR ANOTHER VECTOR
003412	023727	003356	000770	VECOKB	CMP	VECTOR, #770	. IS VECTOR = TO OR
003420	101371				BHI	VECOKA	. LESS THAN 770
003422	032737	000007	003356		BIT	#7, VECTOR	. LSB OF VECTOR MUST BE ALL 0'S
003430	001365				BNE	VECOKA	
003432	013737	003356	001260		MOV	VECTOR, CLK.INT	
003440	062737	000004	003356		ADD	#4, VECTOR	
003446	013737	003356	001264		MOV	VECTOR, XMT.INT	
							. UNIT NUMBER
003454	023737	000042	000046	DMPARB	CMP	@#42, @#46	. ACT11?
003462	001405				BEQ	UNIT+2	. BP IF YES
003464	104000				TYPE		
003466	017352				WHICH		
003470	004537	004124			JSR	5, RECD	. GET UNIT AND PUT IT
003474	000000			UNIT	0		. HERE
003476	023727	003474	000017		CMP	UNIT, #17	. UNIT SELECTED MUST BE
003504	101403				BLOS	UNTOKA	. BETWEEN 0 & 17
003506	104000				TYPE		
003510	017444				M1		
003512	000760				BR	DMPARB	
003514	006337	003474		UNTOKA	ASL	UNIT	
003520	006337	003474			ASL	UNIT	
003524	006337	003474			ASL	UNIT	
003530	012702	000004			MOV	#4, %2	
003534	012701	001250			MOV	#CSR, %1	
003540	042711	000370		UNTOKB	BIC	#370, (1)	. FORM ADDRESSES OF
003544	063721	003474			ADD	UNIT, (1)+	. REGISTERS OF UNIT SELECTED
003550	005302				DEC	%2	
003552	001372				BNE	UNTOKB	
003554	012702	000004			MOV	#4, %2	
003560	012703	001250			MOV	#CSR, %3	
003564	012701	001614			MOV	#CSR, %1	
003570	012311			UNTOKC	MOV	(3)+, (1)	. FORM 000 BYTE ADDRESSES


```

003572 005221          INC      (1)+
003574 005302          DEC      %2
003576 001374          BNE     UNTOKC
          , CHARACTER LENGTH
003600 023737 000042 000046 DMPARC  CMP     @#42,@#46      ,ACT11?
003606 001405          BEQ     LENGTH+2      ,BR IF YES
003610 104000          TYPE
003612 017365          LEVEL
003614 004537 004124          JSR     5,RECD      ,GET LENGTH AND PUT IT
003620 000000          LENGTH 0          ,HERE
003622 005737 003620          TST     LENGTH
003626 001003          BNE     LENOKA
003630 012737 000010 003620          MOV     #8,LENGTH
003636 023727 003620 000005 LENOKA  CMP     LENGTH,#5      , CHARACTER LENGTH SELECTED MUST
003644 103003          BHS     LENOKC      ,BE BETWEEN 5-8
003646 104000          LENOKB TYPE      ,CARRIAGE RETURN SELECTS 8
003650 017444          M1
003652 000752          BR      DMPARC
003654 023727 003620 000010 LENOKC  CMP     LENGTH,#8
003662 101371          BHI     LENOKB
003664 162737 000005 003620          SUB     #5,LENGTH
003672 006337 003620          ASL     LENGTH
003676 013701 003620          MOV     LENGTH,%1
003702 016137 003714 001300          MOV     LENOKD,11 @#CAPMSK      ,SET CHARACTER LENGTH MASK
003710 000240          NCP
003712 000207          RTS     7          ,EXIT PARAMETERS ROUTINE
    
```

THE BELOW TABLE REPRESENTS THE CHARACTER LENGTH MASK FOR 5, 6, 7, AND 8
 BITS PER CHARACTER RESPECTIVELY

```

003714 177740  LENOKD 177740
003716 177700          177700
003720 177600          177600
003722 177400          177400
    
```

CALCULATE MACHINE TIME TO TRANSMIT ONE CHARACTER

```

003724 005037 004074          TIMER: CLR     TIME1
003730 012737 177777 001146          MOV     #-1,WCT      ,SET UP TO TRANSMIT
003736 012737 016564 001106          MOV     #OUTBUF,CAT  ,1 CHARACTER ON LINE 1
003744 012777 004044 175306          MOV     #TIMEC,@CLKINT ,LOAD RECEIVER INTERRUPT
003752 012777 000340 175302          MOV     #PTY7,@CLKLVL ,AND PRIORITY
003760 012777 000001 175264          MOV     #LBIT0,@BAR  ,START TRANSMITTING
003766 012777 000105 175254          MOV     #BIT6+BIT2+BIT0 @CSR ,SET IE BIT
003774 005037 177776          CLR     @PSW      ,SET PROCESSER PRIORITY LEVEL = 0
004000 012737 000044 001604 TIMEA  MOV     #4,COUNT
004006 062737 000001 004074          ADD     #1,TIME1      ,INCREMENT MACH TIME TO TRANSMIT
004014 001007          BNE     TIMEB
004016 005077 175226          CLR     @CSR
004022 012737 000340 177776          MOV     #PTY7,PSW      ,SET PROCESSER PRIORITY LEVEL = 7
004030 104001          ERROR      ,TRANSMITTER FAILED TO INTERRUPT
004032 000734          BR      TIMER
004034 005337 001604          TIMEB  DEC     COUNT
004040 001375          BNE     -4
004042 000756          BR      TIMEA
004044 005077 175200          TIMEC  CLR     @CSR
004050 013737 004074 004076          MOV     TIME1,TIME14
004056 006037 004076          ROR     TIME14
    
```

```

004062 000241          CLC
004064 006037 004076  ROR    TIME14
004070 022626          POPSP2      ,RESTORE STACK POINTER
004072 000207          RTS     7      ,EXIT TIME CALCULATION ROUTINE

004074 000000          TIME1 OPEN    ,CONTAINS MACHINE TIME TO XMIT 1 CHAR
004076 000000          TIME14 OPEN   ,CONTAIN TIME TO XMIT 1/4 CHAR

, SUBROUTINE TO PUT HALT, +2 IN VECTOR AREA (0300-1000)
004100 012702 000302  OVRLAY MOV    #302,R2
004104 010262 177776  15     MOV    R2,-2(R2)
004110 005022          CLR    (R2)+
004112 005722          TST   (R2)+
004114 022702 000776  CMP    #776,R2
004120 100371          BPL   15
004122 000207          RTS   7
  
```

, SUBROUTINE TO RECEIVE DATA
 , THIS SUBROUTINE RECEIVES DATA FROM THE KEYBOARD (UP TO SIX OCTAL
 , DIGITS AND PLACES THEM INTO THE ADDRESS FOLLOWING THE SUBROUTINE
 , CALL (JSR 5,RECD) NO REGISTER CONTENTS ARE DISTURBED

, SUBROUTINE TO INPUT DATA FROM TTY

```

004124 010046          RECD  MOV    R0,-(SP)
004126 005015          15     CLR    (5)      ,CLEAR OLD DATA
004130 012737 000007 004202  MOV    #7,CNT    ,SET CHAR COUNT
004136 105777 175432  25     TSTB  @TKCSR    ,WAIT FOR CHAR
004142 100375          BPL   25
004144 117700 175426  MOVB  @TKDBR,R0
004150 142700 000200  BICB  #200,R0    ,STRIP OFF PARITY
004154 110077 175422  MOVB  R0,@TPDBR  ,ECHO CHARACTER
004160 122700 000025  CMPB  #25,R0    ,IS IT A U
004164 001443          BEQ   55        ,BRANCH IF YES
004166 122700 000015  CMPB  #15,R0    ,IS IT A <CR>
004172 001415          BEQ   65        ,BRANCH IF YESS
004174 142700 000060  BICB  #60,R0
004200 132700 000110  BITB  #110,R0   ,CHECK FOR 0-7 (8)
004204 001031          BNE   75        ,BRANCH IF NOT
004206 006315          ASL   (5)
004210 006315          ASL   (5)
004212 006315          ASL   (5)      ,SHIFT DATA
004214 150015          BISB  R0,(5)    ,INSET NEW CHAR
004216 005337 004302  DEC   CNT
004222 001422          BEQ   73        ,ONLY 6 CHAR'S PLEASE
004224 000744          BR   25        ,NEXT CHARACTER
004226 105777 175346  65     TSTB  @TPCSR
004232 100375          BPL   65        ,WAIT FOR READY
004234 012777 000012 17534C  MOV    #12,@TPDBR ,TYPE <LF>
004242 105777 175332  55     TSTB  @TPCSR
004246 100327          BPL   15
004250 005077 175326  CLR   @TPDBR    ,WAIT FOR READY
004254 105777 175320  95     TSTB  @TPCSR    LOAD CHAR
004260 100375          BPL   95
  
```

```

004262 005725          TST      (R5)+          ,ADJUST R5
004264 012600          MOV      (SP)+,R0        ,RESTORE R0
004266 000205          RTS      R5
004270 104000          7S     TYPE
004272 017444          M1
004274 104000          5S     TYPE
004276 017350          SCTLU
004300 000712          BR      1S              ,START OVER
004302 000000          CNT      0
  
```

```

004304 012737 004314 000024 ,POWER FAIL ROUTINE
004312 000000 PFAIL  MOV      #PWRUP,24
                   HALT
  
```

```

004314 000005          PWRUP  RESET          ,GIVE TELEPRINTER TIME TO START
004316 012706 001100          MOV      #SPBOT,%6
004322 104001          ERROR
004324 000137 002222          JMP      @#RSTAT2      ,TYPE POWER FAIL ERROR
                   ,GO RESTART PROGRAM
  
```

.LINE TEST SUBROUTINE THIS LINE TEST PROVIDES SEVERAL TESTS ON A DM11 L
 .THE SUBROUTINE IS CALLED BY JSR 5, LNTST THIS INSTRUCTION PROVIDES THE
 .LINE BIT AND LINE NUMBER. THE FOLLOWING LINE TESTS ARE PERFORMED
 .UNTIL CHARACTER SHOULD HAVE BEEN TRANSMITTED, THEN TESTS

```

                   ,THAT BAR BIT CLEARED          ,DO NEXT TEST IF ERROR
                   ,READY SET                      ,DO NEXT TEST IF ERROR
                   ,WORD COUNT WENT TO 0          ,DO NEXT TEST IF ERROR
                   ,CURRENT ADDRESS DID NOT INCREMENT ,DO NEXT TEST IF ERROR
                   , INTERRUPTS TO CORRECT VECTOR ,DO NEXT TEST IF ERPOR (NO INTERRUPT)
                   ,READY BIT CAN BE CLEARED      ,END OF TEST
004330 012537 016412 XMTTST MOV      (5)+,@#LINE ,GET LINE NUMBER
004334 004737 006552 JSR      7,GTLINB ,GO FORM LINE BIT (FOR BAR)
004340 005037 001276 CLR      XMTDAT
004344 004537 005754 1S     JSR      5,@#XMITC ,GO TO TRANSMIT SUBROUTINE
004350 177777          -1          ,TRANSMIT ONE CHAPACTER
004352 012703 000010 MOV      #10,%3 ,WAIT IN
004356 005002          CLR      %2 ,THIS
004360 005302          2S     DEC      %2 ,LOOP
004362 001376          BNE     -2 ,UNTIL THE
004364 005303          DEC      %3 ,TRANSMITTER
004366 001374          BNE     2S ,IS FINISHED
004370 017737 174656 001274 MOV      @BAR,PCVDAT ,BAR SHOULD NOW BE CLEAR
004376 001401          BEQ     3S ,BRANCH IF IT IS
004400 104011          ERROR1 ,ERROR! BAR BIT FAILED TO CLEAR
004402 005777 174642 3S     TST      @CSP ,TEST READY BIT SHOULD BE SET
004406 100401          BMI     4S ,BRANCH IF SET
004410 104001          ERROR ,ERROR! READY NOT SET
004412 013701 016412 4S     MOV      @#LINE,%1 ,GET LINE NUMBER
004416 016137 001146 001274 MOV      WCT(1),PCVDAT ,WORD COUNT SHOULD BE 0
004424 001401          BEQ     5S
004426 104011          ERROR1 ,ERROR! WORD COUNT NOT EQUAL TO 0
004430 012737 016564 001276 5S     MOV      #OUTBUF,XMTDAT ,
004436 016137 001106 001274 MOV      CAT(1),PCVDAT ,CURRENT ADDRESS SHOULD NOT HAVE INCREMENTED
004444 023737 001274 001276 CMP      PCVDAT,XMTDAT
004452 001401          BEQ     6S
  
```

004454	104011				ERROR1		, ERROR! CURRENT ADDR DID NOT INCREMENT
004456	012777	004510	174600	65	MOV	#75, @XMTINT	, LOAD TRANSMITTER INTERRUPT VECTOR
004464	052777	010000	174556		BIS	#BIT12, @CSR	, ENABLE TRANSMITTER INTERRUPT
004472	005037	177776			CLR	@#PSW	, SET PROCESSOR PRIORITY =0
004476	000240				NOP		
004500	012737	000340	177776		MOV	#PRTY7, @#PSW	, LOCK OUT INTERRUPTS
004506	104001				ERROR		, TRANSMITTER FAILED TO INTERRUPT OR
					, INTERRUPTED TO	WRONG LOCATION AND HALTED WITH ADDRESS +2 DISPLAYED	
004510	022626			75	CMP	(6)+, (6)+	, RESET STACK PTR
004512	012737	000340	177776		MOV	#PRTY7, @#PSW	, LOCK OUT INTERRUPTS
004520	042777	110000	174522		B C	#BIT12+BIT15, @CSR	, CLEAR XMIT IE & READY B TS
004526	005777	174516			TST	@CSR	, TEST THAT READY CLEARED
004532	100001				BPL	85	, GO TO EXIT
004534	104001				ERROR		, ERROR! READY FAILED TO CLEAR
004536	005726			85	TST	16+	, RESET STACK PTR
004540	104006				SCOPE		, SCOPE

.RECEIVER LINE TESTS
 .THE RECEIVER LINE TEST SUBROUTINE IS ENTERED WITH
 .A JSP 5, RCVTST INSTRUCTION FOLLOWED BY THE
 .LINE BIT AND LINE NUMBER OF THE LINE TO BE
 .TESTED THE SUBROUTINE PERFORMS THE FOLLOWING
 .TEST AS SHOWN BELOW IN THE EVENT OF AN ERROR
 .THE REMAINING TESTS ARE ABORTED
 .TEST SEQUENCE AND ADDRESS TAG

CHARACTER DONE SETS	RTSTA
CHARACTER DONE CAUSES INTERRUPT	RTSTB
CHARACTER DONE CAN BE CLEARED	RTSTC
TUMBLE TABLE ENTRY IS CORRECT	RTSTD
NO ENTRY IN NEXT TABLE ADDRESS	RTSTE
HARDWARE TABLE POINTER INCREMENTED	RTSTF
NEXT ENTRY WAS CORRECT	RTSTG

.NOTES IF THE HARDWARE PROVIDES AN INCORRECT VECTOR
 ADDRESS THE PROGRAM WILL HALT AND DISPLAY
 THE INCORRECT VECTOR+2 IN THE ADDRESS LIGHTS

004542	012737	177777	016564	RCVTST	MOV	#-1, OUTBUF	.LOAD ALL 1'S INTO OUTPUT BUFFER
004550	005037	001306			CLR	TUMTAB	.CLEAR THE FIRST
004554	005037	001310			CLP	TUMTAB+2	.TWO TUMBLE TABLE ADDRESSES
004560	012737	000340	177776		MOV	#PTY7, @PSW	.LOCK OUT INTERRUPTS
004566	012537	016412			MOV	(5)+, LINE	.GET LINE NUMBER
004572	004537	005754			JSP	5, @XMITD	.TRANSMIT 1 CHARACTER (0'S)
004576	177777				-1		.ON LINE SPECIFIED BY JSR
004600	052777	000001	174442		BIS	#BIT0, @CSP	.SET GO BIT
004606	005777	174436			TST	@CSR	.WAIT FOR TRANSMITTER
004612	100375				BPL	-4	.TO TRANSMIT 1 CHAR
004614	042777	100000	174426		BIC	#BIT15, @CSF	.CLEAR TRANSMITTER READY FLAG
004622	005046				CLP	-(SP)	.SET WATCH DOG TIMER
004624	105777	174420		15	TSTB	@CSR	.TEST CHAR DONE FLAG
004630	100404				BMI	25	.BRANCH IF SET
004632	005216				INC	(SF)	.WAIT FOR THE FLAG
004634	001373				BNE	15	
004636	104001				ERROR		.ERROR! CHAR DONE FLAG FAILED TO SET
004640	000550				BR	85	.GO TO EXIT
004642	005726			25	TST	(SP)+	.RESTORE STACK PTR
004644	012777	004700	174406		MOV	#35, @CLKINT	.LOAD RECEIVER INTERRUPT VEC ADPS
004652	052777	000100	174370		BIS	#BIT6, @CSR	.SET RECEIVER IE BIT
004660	005037	177776			CLR	@PSW	.ENABLE INTERRUPTS
004664	000240				NOP		
004666	012737	000340	177776		MOV	#PTY7, PSW	.LOCK OUT INTERRUPTS
004674	104001				ERROR		.RECEIVER FAILED TO INTERRUPT
004676	000531				BR	85	.GO TO EXIT
004700	012737	000340	177776	35	MOV	#PTY7, @PSW	.LOCK OUT INTERRUPTS
004706	022626				CMP	(6)+, (6)+	
004710	042777	000300	174322		BIC	#BIT7+BIT6, @CSR	.CLEAR CHAR DONE FLAG
004716	105777	174326			TSTB	@CSR	.TEST THAT CHAR DONE FLAG CLEARED
004722	100002				BPL	45	.BRANCH IF CHAR DONE FLAG CLEARED
004724	104001				ERROR		.ERROR! CHAR DONE FAILED TO CLEAR
004726	000515				BR	85	.GO TO EXIT

```

004730 013737 001306 001274 45 MOV TUMTAB,RCV DAT ,GET TUMBLE TABLE ENTRY
004736 042737 020000 001274 BIC #BIT13,RCV DAT ,CLEAR PARITY INDICATOR
004744 012737 000377 001276 MOV #377,XMT DAT ,LOAD XMT DAT WITH TRANSMITTED DATA
004752 043737 001300 001276 BIC CARMSK,XMT DAT ,CLEAR NON TRANSMITTED BITS
004760 153737 016412 001277 BISB LINE,XMT DAT+1 ,LOAD XMT DAT WITH PROPER LINE #
004766 052737 100000 001276 BIS #BIT15,XMT DAT ,SET VALID DATA ENTRY BIT IN XMT DAT
004774 023737 001274 001276 CMP RCV DAT,XMT DAT ,COMPARE TUMBLE TABLE ENTRY (RCV DAT) &
, CORRECT RESULT (XMT DAT)

005002 001402 BEQ 55
005004 104011 ERROR1 ,ERROR INCORRECT TUMBLE TABLE
005006 000465 BR 85 ,ENTRY, GO TO EXIT
005010 005037 001306 55 CLR TUMTAB
005014 013737 001310 001274 MOV TUMTAB+2,RCV DAT ,GET NEXT ENTRY
005022 001404 BEQ 65 ,BRANCH IF ALL 0'S
005024 005037 001276 CLR XMT DAT
005030 104011 ERROR1 ,ERROR! FALSE ENTRY IN NEXT
005032 000453 BR 85 ,TUMBLE TABLE ADDRESS
005034 004537 005754 65 JSR 5,@#XMTD ,TRANSMIT 1 CHARACTER (ALL 1 S)
005040 177777 -1 ,ON LINE SPECIFIED BY JSR
005042 005777 174202 TST @LSP ,WAIT FOR TRANSMITTER
005046 100375 BPL -4 ,READY FLAG
005050 105777 174174 TSTB @CSR ,TEST FOR THE DONE FLAG
005054 100375 BPL -4
005056 042777 000200 174164 BIC #BIT7,@CSR ,CLEAR CHAR DONE FLAG
005064 013737 001306 001274 MOV TUMTAB,RCV DAT ,TEST THAT HARDWARE TUMBLE
005072 001404 BEQ 75 ,TABLE POINTER INCREMENTED (+2)
005074 005037 001276 CLR XMT DAT
005100 104011 ERROR1 ,ERROR! TUMBLE TABLE POINTER DID
005102 000427 BR 85 ,NOT INCREMENT, GO TO EXIT
005104 013737 001310 001274 75 MOV TUMTAB+2,RCV DAT ,GET TUMBLE TABLE ENTRY
005112 042737 020000 001274 BIC #BIT13,RCV DAT ,CLEAR PARITY INDICATOR
005120 012737 000377 001276 MOV #377,XMT DAT ,LOAD XMT DAT WITH TRANSMITTED DATA
005126 043737 001300 001276 BIC CARMSK,XMT DAT ,CLEAR NON-TRANSMITTED BITS
005134 153737 016412 001277 BISB LINE,XMT DAT+1 ,LOAD LINE # INTO XMT DAT
005142 052737 100000 001276 BIS #BIT15,XMT DAT ,SET VALID DATA ENTRY BIT INTO XMT DAT
005150 023737 001274 001276 CMP RCV DAT,XMT DAT ,COMPARE TUMBLE TABLE ENTRY (RCV DAT) &
, CORRECT RESULT (XMT DAT)

005156 001401 BEQ 85
005160 104011 ERROR1 ,ERROR! 2ND TUMBLE TABLE ENTRY
005162 104006 55 SCOPE WAS INCORRECT, SCOPE
    
```

SUBROUTINE TO TEST BREAK OPERATION
 THE TRANSMITTER WILL TRANSMIT THE BREAK FOR TWO CHARACTER
 TIMES AND THEN THE FOLLOWING TESTS WILL BE PERFORMED

```

A VALID DATA ENTRY WAS MADE BKTSTB
BREAK BIT SET BKTSTC
DATA WAS ALL 0'S BKTSTD
005164 012777 000001 174056 BKTST MOV #1,@CSR ,SET THE GO BIT
005172 011577 174056 MOV (5),@BKC SR ,SET THE BREAK BIT
005176 105777 174046 TSTB @CSR ,WAIT FOR THE RECEIVER TO
005202 100375 BPL -4 ,RECEIVE BREAK
005204 042777 000200 174056 BIC #BIT7,@CSR ,CLEAR FLAG
005212 105777 174056 TSTB @CSR ,WAIT FOR THE RECEIVER TO
005216 100375 BPL -4 ,TO RECEIVE BREAK
    
```

005220	042777	000200	174022		B C	#BIT7, @CSR	, CLEAR FLAG
005226	005077	174022			CLR	@BKCSR	, CLEAR BREAK BIT
005232	005737	001306		15	TST	TUMTAB	, TEST FOR VALID DATA ENTRY
005236	100402				BM	25	
005240	104001				ERROR		, ERROR! NO VALID DATA ENTRY
005242	000421				BR	45	, GO TO EXIT
005244	032737	040000	001306	25	BIT	#BIT14, TUMTAB	, TEST THAT BREAK BIT IS SET
005252	0C1002				BNE	35	, IN TUMBLE TABLE
005254	104001				ERROR		, ERROR! BREAK BIT FAILED TO SET
005256	000413				BR	45	, GO TO EXIT
005260	105737	001306		35	TSTB	TUMTAB	, TEST THAT DATA IS ALL 0'S
005264	001410				BEQ	45	
005266	005037	001274			CLR	RCV DAT	
005272	113737	001306	001274		MOVB	TUMTAB, RCV DAT	, GET RECEIVED DATA
005300	005037	001276			CLR	XMT DAT	
005304	104011				ERROR1		, ERROR! DATA WAS NOT ALL 0'S
005306	104006			45	SCOPE		, SCOPE
, SUBROUTINE TO TRANSMIT & RECEIVE ON ALL LINES THE DELAY BETWEEN , TRANSMITTING ON A LINE IS SUPPLIED BY THE CALLING JSR INSTRUCTION , NOTE NO DATA CHECKING IS PERFORMED BY THIS TEST							
005310	012537	001604			DLXMT	MOV (5)+, @#COUNT	, GET CHARACTER DELAY COUNT
005314	005037	001276			CLR	XMT DAT	
005320	004537	005722			JSR	5, @MOVE	, LOAD OUTPUT BUFFER WITH DATA
005324	017657				MSG1		, TO BE TRANSMITTED
005326	016564				OUTBUF		
005330	000100				64		
005332	012737	000001	001272		MOV	#LBIT0, @#LINBIT	
005340	005037	016412			CLR	@#LINE	
005344	012777	000001	173676	15	MOV	#BIT0, @CSR	, SET THE GO BIT
005352	004537	005754		25	JSP	5, @#XMITD	, TRANSMIT 64 CHAR
005356	177700				-64		, ON A LINE
005360	013737	004074	005374		MOV	@#TIME1, 45	
005366	013704	001604			MOV	@#COUNT, %4	, GET CHARACTER DELAY COUNT
005372	104400			35	DELAY		
005374	000000			45	0		
005376	005304				DEC	%4	
005400	001374				BNE	35	
005402	062737	000002	016412		ADD	#2, LINE	, FORM NEXT LINE NUMBER
005410	006337	001272			ASL	LINBIT	, SHIFT LINE BIT
005414	103356				BCC	25	, BRANCH IF ALL LINES NOT DONE
005416	012704	000100			MOV	#64, %4	
005422	013737	004074	005432		MOV	TIME1, 65	
005430	104400			55	DELAY		
005432	000000			65	0		
005434	005304				DEC	%4	
005436	001374				BNE	55	
005440	017737	173606	001274		MOV	@BAR, RCV DAT	, GET & TEST BAR DATA
005446	001402				BEQ	75	, EXIT IF DONE
005450	104011				ERROR1		, ERROR! BAR SHOULD'VE BEEN CLEAR
005452	000413				BR	85	
005454	022777	100201	173566	75	CMP	#100201, @CSR	, TEST THAT ONLY DONE, GO & READY BITS ARE SET
005462	001407				BEQ	85	
005464	012737	100201	001276		MOV	#100201, XMT DAT	
005472	017737	173552	001274		MOV	@CSR, RCV DAT	, GET CSR CONTENTS

005500	104011				ERROR1		, INCORRECT CSR CONTENTS
005502	005726			85	POPSP		, RESET THE STACK
005504	104006				SCOPE		, SCOPE
, SUBROUTINE TO DELAY A SPECIFIED NUMBER OF MILLISECONDS							
005506	011637	005556			DLY	MOV (6), 35	, GET DELAY COUNT ADDRESS
005512	062716	000002				ADD #2, (6)	, SET UP EXIT ADDRESS
005516	017737	000034	005556			MOV @35, 35	, GET DELAY COUNT
005524	001413					BEQ 25	, EXIT IF NO DELAY
005526	012737	000050	005560	15		MOV #50, 45	
005534	162737	000001	005556			SUB #1, 35	
005542	001404					BEQ 25	
005544	005337	005560				DEC 45	
005550	001375					BNE -4	
005552	000765					BR 15	
005554	000002			25		PT	, EXIT
005556	000000			35		OPEN	, CONTAINS DELAY COUNT
005560	000000			45		OPEN	, CONTAINS DELAY ROUTINE CONSTANT
, SUBROUTINE TO INITIALIZE BINARY COUNT PATTERNS							
005562	012737	177777	005560		INB N	MOV #-1, RIND	, SET ALL VARIABLES
005570	004537	005702				JSP %5, BMOVE	, TO MINUS 1
005574	005604					RIND	
005576	005605					RIND+1	
005600	000005					5	
005602	000207					RTS %7	EXIT
005604	000000				P ND	OPEN	
005606	000000				PT0	OPEN	
005610	000000				PT1	OPEN	
, SPECIAL BINARY COUNT PATTERN SUBROUTINE EXITS WITH BIN CHAR IN R1							
005612	013737	005606	005610		GTBIN	MOV PT0, PT1	, PREVIOUS BIN CHAR TO PT1
005620	005137	005610				COM PT1	
005624	005137	005604				COM RIND	
005630	001002					BNE +6	
005632	005237	005610				INC PT1	
005636	042737	177400	005610			BIC #177400, PT1	, MASK TO 8 BITS
005644	013737	005610	005606			MOV PT1, PT0	, SAVE BIN CHAR IN PT0
005652	013701	005610				MOV PT1, %1	, BIN CHAR TO R1
005656	000240					NOP	
005660	000207					RTS %7	EXIT
, OCTAL TO ASCII CONVERT ROUTINE							
005662	104007				OALNV	SAVREG	, SAVE REGISTERS ON THE STACK
005664	013504					MOV @15, %4	, GET OCTAL VALUE
005666	012501					MOV (5), %1	, GET DESTINATION ADDR
005670	012502					MOV (5), %2	, GET CONVERT COUNT
005672	060201					ADD %2, %1	, DEVELOP ADDR TO STORE 1ST CHAR
005674	010403				OACNVA	MOV %4, %3	
005676	042703	177770				BIC #177770, %3	, ISOLATE LEAST SIGNIFICANT DIGIT
005702	062703	000060				ADD #60, %3	, CONVERT DIGIT TO ASCII
005706	110341					MOVB %3, -(1)	, STORE ASCII CHARACTER
005710	042704	000007				BIC #7, %4	
005714	006004					ROR %4	
005716	006004					ROR %4	
005720	006004					ROR %4	


```

005722 005302      DEC      %2      ,DONE ALL DIGITS?
005724 001363      BNE      0ACNVA  ,BRANCH IF NOT DONE
005726 104010      PSTREG     ,RESTORE THE REGISTERS
005730 000205      RTS      %5      ,DONE EXIT
    
```

```

, SUBROUTINE TO MOVE A VARIABLE NUMBER OF BYTES
BMOVE SAVREG     ,SAVE REGS
      MOV      (5)+,%1  ,GET"FROM"ADDRESS
      MOV      (5)+,%2  ,GET"TO"ADDRESS
      MOV      (5)+,%3  ,GET COUNT
      IS      MOV     (1)+,(2)+ ,MOVE BYTE
      DEC      %3      ,DECREMENT COUNT
      BNE      1$      ,BRANCH IF NOT DONE
      RSTREG     ,RESTORE REGS
      RTS      %5      ,DONE EXIT
    
```

```

, SUBROUTINE TO TRANSMIT DATA SUBROUTINE CALLED BY
JSR 5,XMITD
XMITD MOV      %0,-(SP)  ,SAVE PD ON THE STACK
      MOV      @#LINE,%0 ,GET LINE
      JSR      7,@#GTLINE ,FORM LINE BIT (FOR BAR)
      MOV      #CAT,@BASREG ,INITIALIZE BASE REGISTER
      MOV      #OUTBUF,CAT(0) ,LOAD FIRST CHAR ADDRESS IN CAT
      MOV      (5)+,%CT(0) ,GET WORD COUNT
      BIS      @#LINBIT,@BAR ,LOAD LINE POSITION INTO BAR
      MOV      (SP)+,%0    ,RESTORE PD
      RTS      5          ,EXIT
    
```

```

ROUTINE TO TEST A LINE
THE LINE TO BE TESTED IS PROVIDED BY THE JSR CALL TO THE ROUTINE
,100 CHARACTERS ARE TRANSMITTED, RECEIVED AND CHECKED BY THIS ROUTINE
DAT1$T MOV      (5)+,@#LINE  ,GET LINE NUMBER
DAT1$A MOV      #100,%COUNT ,GET CHARACTER COUNT
      MOV      #OUTBUF,%2    ,GET ADDRESS OF OUTPUT BUFFER
      IS      JSR      7,@#GTBIN ,GET DATA
      MOV     %1,(2)+      ,LOAD OUTPUT BUFFER WITH DATA
      DEC     COUNT      ,GOT ALL DATA?
      BNE     1$
      MOV     #TUMTAB+1  ,LOAD TUMBLE TABLE POINTER
      CLR     TUMTAB
      JSR     5,BMOVE    ,CLEAR
      TUMTAB ,TUMBLE
      TUMTAB+1 ,TABLE
      177 ,64 WORDS
      MOV     #INBUF,%2  ,SETUP INPUT BUFFER POINTER
      BIS     #BIT0,@CSR ,SET THE GO B T
      JSR     5,@XMITD  ,TRANSMIT
      -100 ,100 CHARACTERS
      BIT     #BIT15+BIT14+BIT13,@CSR ,TEST IF READY OR ANY ERROR
      BNE     3$      ,FLAGS ARE SET
      TSTB   @CSR     ,WAIT FOR THE RECEIVER
      BPL     2$      ,TO RECEIVE A CHARACTER
      BR     5$
      BIT     #BIT14+BIT13,@CSR ,TEST FOR ERROR FLAGS
      BEQ     4$      ,BRANCH NO ERROR
      ERROP
    
```

```

006146 000137 006466 JMP 155 .GO EXIT
006152 042777 100000 173070 45 BIC #BIT15,@CSR .CLEAR TRANSMITTER READY FLAG
006160 105777 173064 TSTB @CSR .TEST FOR CHARACTER READY
006164 100375 BPL -4
006166 042777 000200 173054 55 BIC #BIT7,@CSR .CLEAR CHAR DONE BIT
006174 005711 TST (1)
006176 100401 BMI +4 .TEST FOR VALID ENTRY
006200 104001 ERROR .REPORT INVALID ENTRY
006202 111122 MOVB (1),(2)+ .MOVE CHAR FROM TUM TAB TO INPUT BUFFER
    
```

.ROUTINE TO STORE RECEIVED PARITY BIT IN PARITY BIT BUFFER

```

006204 012705 000001 MOV #1,%5 .GET ROTATE COUNT
006210 000261 SEC .SET THE CARRY BIT
006212 032711 020000 BIT #BIT13,(1) .TEST RECEIVED PARITY BIT
006216 001001 BNE 65 .BRANCH IF RECEIVED PARITY WAS ODD
006220 000241 CLC .CLEAR CARRY BIT
006222 004537 006472 65 JSP 5,RORPARBUF .ROTATE RECEIVED PARITY INTO PARITY BUFFER
    
```

.ROUTINE TO TEST THAT ENTRY IS FOR THE CORRECT LINE

```

006226 011137 001270 MOV (1),@TTDAT .GET TABLE ENTRY
006232 042737 160777 001270 BIC #160777,TTDAT .CLEAR ALL BUT LINE NUMBER
006240 123737 016412 001271 CMPB LINE,TTDAT+1 .COMPARE LINE NUMBERS
006246 001410 BEQ 75
006250 013737 016412 001276 MOV LINE,XMTDAT .GET CORRECT LINE # (X2)
006256 013737 001270 001274 MOV TTDAT,RCVDAT .GET LINE # (X2) THAT FALSE DATA CAME IN ON
006264 104011 ERPOP1 .ERROR! DATA CAME IN ON A LINE THAT
    
```

PROGRAM WAS NOT TRANSMITTING IT

```

006266 000477 BR 155 .EXIT TEST
006270 020127 001504 75 JMP *1,#TUMTAB+176 .IS POINTER AT THE END
006274 001002 BNE 85 .OF THE TABLE
006276 012701 001204 MOV #TUMTAB-2,%1
006302 005721 85 TST (1)+ .INCREMENT POINTER
006304 010046 MOV %0,-(6) .SAVE REGISTER ZERO
006306 013700 016412 MOV LINE,%0 .FETCH LINE NUMBER
006312 005760 001146 TST WCT(0) .HAS THE LAST CHARACTER BEEN TRANSMITTED
006316 001402 BEQ +6 .LAST CHARACTER HAS BEEN TRANSMITTED
006320 012600 MOV (6)+,%0 .RESTORE REGISTER ZERO
006322 000674 BR 25 .GO WAIT FOR NEXT CHARACTER
006324 012600 MOV (6)+,%0 .RESTORE REGISTER ZERO
006326 012701 016564 95 MOV #OUTBUF,%1
006332 012702 016730 MOV #INBUF,%2
006336 012705 000014 MOV #12,%5 .ROTATE PARITY BUFFER
006342 004537 006472 105 JSP 5,RORPARBUF .12 PLACES RIGHT
006346 005037 001274 CLP RCVDAT
006352 005037 001276 CLP XMTDAT
006356 020127 016727 CMP %1,#OUTBUF+99 .HAVE ALL CHARS BEEN COMPARED
006362 001441 BEQ 155
006364 112137 001276 MOVB (1)+,XMTDAT .GET TRANSMITTED CHARACTER
006370 043737 001300 001276 BIC CARMASK,XMTDAT .CLEAR NON-TRANSMITTED BITS
006376 111237 001274 MOVB (2),RCVDAT .GET RECEIVED CHARACTER
006402 104002 DATCHK .COMPARE TRANS & RCVD CHARS
    
```

.ROUTINE TO COMPUTE AND CHECK PARITY ON RECEIVED DATA

```

006404 012703 000010 115 MOV #8,%3 .GET BIT COUNTER
006410 005000 CLP %0 .CLEAR COMPUTED PARITY INDICATOR
006412 106037 001274 125 PCPB RCVDAT .LOOK AT RECEIVED BIT
    
```

```

006416 103001          BCC 135      , BRANCH IF A 0
006420 005100          COM %0      , COMPLEMENT RO IF A 1
006422 005303      135 DEC %3      , DECREMENT BIT COUNTER
006424 001372          BNE 125     , LOOK AT NEXT BIT IF NOT DONE
006426 000240          NOP          , IF COMPUTED PARITY WAS ODD RO WILL
          , CONTAIN ALL 1'S, IF EVEN RO = 0
006430 112237 001274  MOVB (2)+,RCV DAT , GET RECEIVED CHARACTER
006434 012705 000001  MOV #1,%5      , ROTATE PARITY BUFFER 1 PLACE
006440 004537 006472  JSR 5,RORPARBUF , RIGHT LEAVING RECEIVED PARITY BIT IN CARRY
006444 103004          BCC 145     , BRANCH IF RECEIVED PARITY WAS EVEN
006446 005700          TST %0     , TEST FOR COMPUTED ODD PARITY
006450 001336          BNE 105     , BRANCH IF COMPUTED & RECEIVED WAS ODD
006452 104001          ERROR      , ERROR! COMPUTED =EVEN, RECEIVED = ODD
006454 000734          BR 105      , CONTINUE TEST
006456 005700      145 TST %0     , TEST FOR EVEN COMPUTED PARITY
006460 001732          BEQ 105     , BRANCH IF COMPUTED PARITY WAS EVEN
006462 104001          ERROR      , ERROR! COMPUTED =ODD, RECEIVED = EVEN
006464 000730          BR 105      , CONTINUE TEST
006466 005726      155 POPSP      , REPOSITION STACK POINTER
006470 104006          SCOPE
    
```

ROUTINE TO ROTATE PARITY BUFFER

```

006472 006037 006534  POPPARBUF ROR PARC
006476 006037 006536      ROR PAR1
006502 006037 006540      ROR PAR2
006506 006037 006542      ROR PAR3
006512 006037 006544      ROR PAR4
006516 006037 006546      ROR PAR5
006522 006037 006550      ROR PAR6
006526 005316          DEC %SP      , DECREMENT ROTATE COUNT
006530 001360          BNE RORPARBUF
006532 000205          RTS 5
    
```

PARITY BUFFER

```

006534 000000  PAP0 OPEN
006536 000000  PAP1 OPEN
006540 000000  PAR2 OPEN
006542 000000  PAR3 OPEN
006544 000000  PAP4 OPEN
006546 000000  PAR5 OPEN
006550 000000  PAP6 OPEN
    
```

SUBROUTINE TO FORM LINE BIT POSITION WITH THE LINE # IN LINE

```

006552 010046          GTLINB MOV %0,%1      , SAVE RO ON THE STACK
006554 005037 001272  CLP @%LINBIT , CLEAR LINE BIT
006560 013700 016412  MOV @%LINE,%0 , GET LINE
006564 000261          SEC          , SET CARRY
006566 006137 001272  15 POL LINBIT , SHIFT LINE BIT
006572 162700 000002  SUB #2,%0     , SUBTRACT 2 FROM LINE NUMBER
006576 100373          BPL 15      , BRANCH IF GREATER THAN C
006600 012600          MOV %SP,%0 , RESTORE RO
006602 000207          RTS
    
```

```

006604 104000          PRGO      TYPE
006606 017527          PRGOM
006610 012737 006644 001506      MOV      #RTD,KSTART      ,GET ADDRESS OF FIRST TEST
006616 005037 001512          CLR      RTNNO           ,CLEAR ROUTINE #
006622 000137 002254          JMP      SRSET
006626 012737 006644 001506      PRGOR   MOV      #RTD,KSTART      ,GET ADDRESS OF FIRST TEST
006634 005037 001512          CLR      RTNNO           ,CLEAR ROUTINE NUMBER
006640 000137 002306          JMP      GETRDY         ,GO AND START PROGRAM
*****
006644 000000          PTO      0              ,ROUTINE # 0 *
006646 006706          PT1     PT1           ,ADDR OF NEXT ROUTINE *
006650 000144          100     100          ,ITERATION COUNT *
006652 006654          RTOA    RTOA         ,SCOPE ENTRY POINT *
000000          X=X+1
*****
,TEST ABILITY TO REFERENCE CSP W THOUT TRAPPING
006654 012737 006676 000004      RTOA    MOV      #15,@#ERRVEC  ,SET UP ERROR TRAP
006662 005777 172362          TST     @CSR           ,REFERENCE CSR
006666 012737 000006 000004      MOV     #ERRVEC+2,@#ERRVEC  ,RESET TIME OUT TPAP
006674 104006          SCOPE
006676 162716 000004      15     SUB      #4 (6)     ,RESTORE PC TO WHERE THE ILLEGAL
,REFERENCE OCCURED
,ERROR ILLEGAL REFERENCE OCCURED
006702 104001          EPROR   PT1           ,LOOP ILLEGAL REFERENCE INSTRJCT CN
006704 000002          PT1
*****
006706 000001          PT1     1              ,ROUTINE # 1 *
006710 006760          RT2     RT2           ,ADDR OF NEXT ROUTINE *
006712 000144          100     100          ,ITERATION COUNT *
006714 006716          RT1A    RT1A         ,SCOPE ENTRY POINT *
000001          X=X+1
*****
,TEST THAT CSR BIT0 CAN BE SET AND CLEARED
006716 012777 000001 172324      RT1A    MOV      #BIT0,@CSR    ,SET BIT0
006724 022777 000001 172316      CMP     #BIT0,@CSR    ,TEST THAT BIT0 IS SET
006732 001402          BEQ     15           ,BRANCH IF SET
006734 104001          ERROR   ERROR         ,CSR BIT0 FAILED TO SET
006736 000407          BR      25          ,OR AN ADDITIONAL BIT ALSO SET
006740 042777 000001 172302      15     BIC     #BIT0,@CSR    ,CLEAR BIT0
006746 005777 172276          TST     @CSR         ,TEST THAT BIT0 IS CLEAR
006752 001401          BEQ     25          ,CSR BIT0 FAILED TO CLEAR
006754 104001          EPROR   ERROR
006756 104006          25     SCOPE
*****
006760 000002          PT2     2              ,ROUTINE # 2 *
006762 007032          RT3     RT3           ,ADDR OF NEXT ROUTINE *
006764 000144          100     100          ,ITERATION COUNT *
006766 006770          RT2A    RT2A         ,SCOPE ENTRY POINT *
000002          X=X+1
*****
,TEST THAT CSR BIT1 CAN BE SET AND CLEARED
006770 012777 000002 172252      RT2A    MOV      #BIT1,@CSR    ,SET BIT1
006776 022777 000002 172244      CMP     #BIT1,@CSR    ,TEST THAT BIT1 IS SET

```

```

007004 001402      BEQ      15      , BRANCH IF SET
007006 104001      ERROR
007010 000407      BR       25      , CSR BIT1 FAILED TO SET
007012 042777 000002 172230 15      BIC      #BIT1, @CSR , OR AN ADDITIONAL BIT ALSO SET
007020 005777 172224      TST      @CSR      , CLEAR BIT1
007024 001401      BEQ      25      , TEST THAT BIT1 IS CLEAR
007026 104001      ERROR
007030 104006      25      ERROR      , CSR BIT1 FAILED TO CLEAR
          SCOPE
    
```

```

*****
007032 000003      RT3      3      , ROUTINE # 3 *
007034 007104      RT4      , ADDR OF NEXT ROUTINE *
007036 000144      100     , ITERATION COUNT *
007040 007042      RT3A     , SCOPE ENTRY POINT *
          X=X+1
    
```

```

*****
, TEST THAT CSR BIT2 CAN BE SET AND CLEARED
007042 012777 000004 172230 RT3A     MOV      #BIT2, @CSR , SET BIT2
007050 022777 000004 172172      CMP      #BIT2, @CSP , TEST THAT BIT2 IS SET
007056 001402      BEQ      15      , BRANCH IF SET
007060 104001      ERROR
007062 000407      BR       25      , CSR BIT2 FAILED TO SET
007064 042777 000004 172156 15      BIC      #BIT2, @CSP , OR AN ADDITIONAL BIT ALSO SET
007072 005777 172152      TST      @CSR      , CLEAR BIT2
007076 001401      BEQ      25      , TEST THAT BIT2 IS CLEAR
007100 104001      ERROR
007102 104006      25      ERROR      , CSR BIT2 FAILED TO CLEAR
          SCOPE
    
```

```

*****
007104 000004      RT4      4      , ROUTINE # 4 *
007106 007156      RT5      , ADDR OF NEXT ROUTINE *
007110 000144      100     , ITERATION COUNT *
007112 007114      RT4A     , SCOPE ENTRY POINT *
          X=X+1
    
```

```

*****
, TEST THAT CSR BIT4 CAN BE SET AND CLEARED
007114 012777 000020 172126 RT4A     MOV      #BIT4, @CSR , SET BIT4
007122 022777 000020 172120      CMP      #BIT4, @CSR , TEST THAT BIT4 IS SET
007130 001402      BEQ      15      , BRANCH IF SET
007132 104001      ERROR
007134 000407      BR       25      , CSR BIT4 FAILED TO SET
007136 042777 000020 172134 15      BIC      #BIT4, @CSP , OR AN ADDITIONAL BIT ALSO SET
007144 005777 172100      TST      @CSP      , CLEAR BIT4
007150 001401      BEQ      25      , TEST THAT BIT4 IS CLEAR
007152 104001      ERROR
007154 104006      25      ERROR      , CSR BIT4 FAILED TO CLEAR
          SCOPE
    
```

```

*****
007156 000005      PT5      5      , ROUTINE # 5 *
007160 007230      RT6      , ADDR OF NEXT ROUTINE *
007162 000144      100     , ITERATION COUNT *
007164 007166      RT5A     , SCOPE ENTRY POINT *
          X=X+1
    
```

```

*****
, TEST THAT CSR BIT5 CAN BE SET AND CLEARED
007166 012777 000140 172054 PT5A     MOV      #BIT5, @CSP , SET BIT5
    
```

```

007174 022777 000040 172046      CMP      #BITS,@CSR      ,TEST THAT BITS IS SET
007202 001402                      BEQ      15              ,BRANCH IF SET
007204 104001                      ERROR                      ,CSR BITS FAILED TO SET
007206 000407                      BR       25              ,OR AN ADDITIONAL BIT ALSO SET
007210 042777 000040 172032 15    BIC      #BITS,@CSR      ,CLEAR BITS
007216 005777 172026                      TST      @CSR           ,TEST THAT BITS IS CLEAR
007222 001401                      BEQ      25              ,CSR BITS FAILED TO CLEAR
007224 104001                      ERROR                      ,CSR BITS FAILED TO CLEAR
007226 104006      25      SCOPE
,*****
007230 000006      RT6      6              ,ROUTINE # 6 *
007232 007302                      RT7                      ,ADDR OF NEXT ROUT NE *
007234 000144                      100                      ,ITERATION COUNT *
007236 007240      RT6A                      ,SCOPE ENTRY POINT *
000006      X=X+1
,*****

,TEST THAT CSR BIT6 CAN BE SET AND CLEARED
007240 012777 000100 172002  RT6A    MOV      #BIT6,@CSR      ,SET BIT6
007246 022777 000100 171754      CMP      #BIT6,@CSR      ,TEST THAT BIT6 IS SET
007254 001402                      BEQ      15              ,BRANCH IF SET
007256 104001                      ERROR                      ,CSR BIT6 FAILED TO SET
007260 000407                      BR       25              ,OR AN ADDITIONAL BIT ALSO SET
007262 042777 000100 171760 15    BIC      #BIT6,@CSR      ,CLEAR BIT6
007270 005777 171754                      TST      @CSR           ,TEST THAT BIT6 IS CLEAR
007274 001401                      BEQ      25              ,CSR BIT6 FAILED TO CLEAR
007276 104001                      ERROR                      ,CSR BIT6 FAILED TO CLEAR
007300 104006      25      SCOPE
,*****
007302 000007      RT7      7              ,ROUTINE # 7 *
007304 007354                      RT10                     ,ADDR OF NEXT ROUTINE *
007306 000144                      100                      ,ITERATION COUNT *
007310 007312      RT7A                      ,SCOPE ENTRY POINT *
000007      X=X+1
,*****

,TEST THAT CSR BIT12 CAN BE SET AND CLEARED
007312 012777 010000 171730  RT7A    MOV      #BIT12,@CSR     ,SET BIT12
007320 022777 010000 171722      CMP      #BIT12,@CSR     ,TEST THAT BIT12 IS SET
007326 001402                      BEQ      15              ,BRANCH IF SET
007330 104001                      ERROR                      ,CSR BIT12 FAILED TO SET
007332 000407                      BR       25              ,OR AN ADDITIONAL BIT ALSO SET
007334 042777 010000 171706 15    BIC      #BIT12,@CSR     ,CLEAR BIT12
007342 005777 171702                      TST      @CSR           ,TEST THAT BIT12 IS CLEAR
007346 001401                      BEQ      25              ,CSR BIT12 FAILED TO CLEAR
007350 104001                      ERROR                      ,CSR BIT12 FAILED TO CLEAR
007352 104006      25      SCOPE
,*****
007354 000010      RT10     10             ,ROUTINE # 10 *
007356 007426                      RT11                     ,ADDR OF NEXT ROUTINE *
007360 000144                      100                      ,ITERATION COUNT *
007362 007364      RT10A                      ,SCOPE ENTRY POINT *
000010      X=X+1
,*****

TEST THAT CSR BIT13 CAN BE SET AND CLEARED
    
```

```

007364 012777 020000 171656 RT10A MOV #BIT13, @CSR .SET BIT13
007372 022777 020000 171650 CMP #BIT13, @CSR .TEST THAT BIT13 IS SET
007400 001402 BEQ 15 .BRANCH IF SET
007402 104001 ERROR .CSR BIT13 FAILED TO SET
007404 000407 BR 25 .OR AN ADDITIONAL BIT ALSO SET
007406 042777 020000 171634 15 BIC #BIT13, @CSR .CLEAR BIT13
007414 005777 171630 TST @CSR .TEST THAT BIT13 IS CLEAR
007420 001401 BEQ 25
007422 104001 ERROR .CSR BIT13 FAILED TO CLEAR
007424 104006 25 SCOPE
.*****
007426 000011 RT11 11 .ROUTINE # 11 *
007430 007516 RT12 .ADDR OF NEXT ROUTINE *
007432 000144 100 .ITERATION COUNT *
007434 007436 RT11A .SCOPE ENTRY POINT *
.*****
X=X+1
.*****
.TEST THAT RESET & CLEAR INSTRUCTION CLEAR ALL R/W BITS IN THE CONTROL
.STATUS REG (CSR)
007436 012777 030167 171604 RT11A MOV #30167, @CSP .SET ALL R/W BITS IN THE CSR
007444 005037 001276 CLR XMTDAT
007450 104005 SRESET .ISSUE RESET
007452 017737 171572 001274 MOV @CSR, RCVDAT .GET CSR CONTENTS
007460 001402 BEQ 15 .BRANCH IF RESET CLEARED ALL BITS
007462 104011 ERROR1 .ERROR! RESET DID NOT CLEAR ALL BITS
007464 000764 BR RT11A .LOOP ON ERROR
007466 012777 030167 171554 15 MOV #30167 @CSR .SET ALL R/W BITS IN CSR
007474 005077 171550 CLR @CSR .CLEAR THE CSR
007500 017737 171544 001274 MOV @CSP, RCVDAT .GET & TEST CSP
007506 001402 BEQ 25 .GO TO EXIT IF RESULT = 0
007510 104011 ERROR1 .ERROR! CLEAR INST DID NOT CLEAR ALL BITS
007512 000765 BR 15 .LOOP ERROR
007514 104006 25 SCOPE .SCOPE
.*****
007516 000012 RT12 12 .ROUTINE # 12 *
007520 007652 RT13 .ADDR OF NEXT ROUTINE *
007522 000012 10 .ITERATION COUNT *
007524 007526 RT12A .SCOPE ENTRY POINT *
.*****
X=X+1
.*****
.TEST THAT A BINARY COUNT CAN BE LOADED INTO A CLEAR BKCSR AND THAT
A BINARY COUNT CAN BE CLEARED
007526 005037 001276 PT12A CLR XMTDAT
007532 013777 001276 171514 15 MOV XMTDAT, @BKCSR .LOAD BINARY COUNT INTO BKCSR
007540 017737 171510 001274 MOV @BKCSR, RCVDAT .GET BKCSR DATA
007546 023737 001276 001274 CMP XMTDAT, RCVDAT .COMPARE DATA LOADED & DATA READ BACK
007554 001405 BEQ 25 .BRANCH IF DATA COMPARES
007556 104011 ERROR1 .ERROR! DATA DID NOT COMPARE
007560 032777 040000 171314 BIT #BIT14, @SWR .SCOPE LOOP?
007566 001361 BNE 15 .BRANCH IF SCOPE LOOP
007570 013701 001276 25 MOV XMTDAT, %1 .SAVE BINARY COUNT
007574 005037 001276 CLR XMTDAT
007600 005077 171450 35 CLR @BKCSR .CLEAR BKCSR AND TEST
007604 017737 171444 001274 MOV @BKCSR, RCVDAT .BKCSR CAN BE CLEARED
    
```

```
007612 001405 BEQ 4S , BRANCH IF BKCSR CLEARED
007614 104011 ERROR1 , ERROR! BKCSR DID NOT CLEAR
007616 032777 040000 171256 BIT #BIT14, @SWR , SCOPE LOOP?
007624 001365 BNE 3S , BRANCH IF SCOPE LOOP
007626 010137 001276 4S MOV %1, XMTDAT , GET BINARY COUNT
007632 023727 001276 177777 CMP XMTDAT, #-1 , ALL NUMBERS BEEN LOADED
007640 001403 BEQ 5S , GO TO EXIT
007642 005237 001276 INC XMTDAT , INCREMENT BINARY COUNT
007646 000731 BR 1S , REPEAT TEST
007650 104006 5S SCOPE , SCOPE
, *****
007652 000013 RT13 13 , ROUTINE # 13 *
007654 007764 RT14 , ADDR OF NEXT ROUTINE *
007656 000144 100 , ITERATION COUNT *
007660 007662 RT13A , SCOPE ENTRY POINT *
000013 X=X+1
, *****
, TEST THAT RANDOM NUMBERS CAN BE LOADED INTO THE BKCSR
007662 012702 010C00 RT13A MOV #10000, %2 , GET RANDOM #COUNTER
007666 017737 171362 001612 1S MOV @BKCSR, PRVCNT , GET PREVIOUS CONTENTS
007674 004737 002756 JSR 7, @NRNGEN , GO GET A RANDOM NUMBER
007700 010037 001276 MOV %0, XMTDAT , GET RANDOM NUMBER
007704 013777 001276 171342 2S MOV XMTDAT, @BKCSR , LOAD RANDOM NUMBER INTO BKCSR
007712 017737 171336 001274 MOV @BKCSR, RCVDAT , GET BKCSR DATA
007720 023737 001276 001274 CMP XMTDAT, RCVDAT , COMPARE DATA
007726 001401 BEQ 3S , BRANCH IF SAME
007730 104011 ERROR1 , ERROR! DATA NOT THE SAME
007732 032777 040000 171142 3S BIT #BIT14, @SWR , SCOPE LOOP?
007740 001406 BEQ 4S , BRANCH IF NO LOOP ON ERROR
007742 005077 171306 CLR @BKCSR ,
007746 013777 001612 171300 MOV PRVCNT, @BKCSR , LOAD PREVIOUS CONTENTS
007754 000753 BP 2S , REPEAT TEST
007756 005302 4S DEC %2 ,
007760 001342 BNE 1S , BRANCH IF NOT
007762 104006 5S SCOPE , SCOPE
, *****
007764 000014 RT14 14 , ROUTINE # 14 *
007766 010024 RT15 , ADDR OF NEXT ROUTINE *
007770 000012 10 , ITERATION COUNT *
007772 007774 RT14A , SCOPE ENTRY POINT *
000014 X=X+1
, *****
, TEST THAT RESET CLEARS ALL BREAK STATUS REGISTER BITS
007774 012777 177777 171252 RT14A MOV #-1, @BKCSR
010002 005037 001276 CLR XMTDAT
010006 104005 SRESET
010010 017737 171240 001274 MOV @BKCSR, RCVDAT
010016 001401 BEQ 1S
010020 104011 ERROR1
010022 104006 1S SCOPE
, *****
010024 000015 RT15 15 , ROUTINE # 15 *
010026 010160 RT16 , ADDR OF NEXT ROUTINE *
```



```
010030 000012          10          , ITERATION COUNT          *
010032 010034          RT15A        , SCOPE ENTRY POINT          *
          000015          X=X+1
, *****
, TEST THAT A BINARY COUNT CAN BE LOADED INTO A CLEAR BASREG AND THAT
, A BINARY COUNT CAN BE CLEARED
010034 005037 001276          RT15A  CLR  XMTDAT
010040 013777 001276 171210 1$  MOV  XMTDAT, @BASREG ; LOAD BINARY COUNT INTO BASREG
010046 017737 171204 001274 1$  MOV  @BASREG, RCVDAT ; GET BASREG DATA
010054 023737 001276 001274 1$  CMP  XMTDAT, RCVDAT ; COMPARE DATA
010062 001405          BEQ  2$ ; BRANCH IF DATA COMPARES
010064 104011          ERROR1 ; ERROR! DATA DID NOT COMPARE
010066 032777 040000 171006 1$  BIT  #BIT14, @SWR ; SCOPE LOOP?
010074 001361          BNE  1$ ; BRANCH IF SCOPE LOOP
010076 013701 001276          2$  MOV  XMTDAT, %1 ; SAVE BINARY COUNT
010102 005037 001276          CLR  XMTDAT
010106 005077 171144          3$  CLR  @BASREG
010112 017737 171140 001274 3$  MOV  @BASREG, RCVDAT
010120 001405          BEQ  4$ ; BRANCH IF BKCSR CLEARED
010122 104011          ERROR1 ; ERROR! BKCSR DID NOT CLEAR
010124 032777 040000 170750 1$  BIT  #BIT14, @SWR ; SCOPE LOOP?
010132 001365          BNE  3$ ; BRANCH IF SCOPE LOOP
010134 010137 001276          4$  MOV  %1 XMTDAT ; GET BINARY COUNT
010140 023727 001276 177000 4$  CMP  XMTDAT, #177000 ; ALL NUMBERS BEEN LOADED
010146 001403          BEQ  5$ ; GO TO EXIT
010150 105237 001277          INCB XMTDAT+1 ; INCREMENT BINARY COUNT
010154 000731          BR  1$ ; REPEAT TEST
010156 104006          5$  SCOPE ; SCOPE
, *****
010160 000016          RT16  16 ; ROUTINE # 16          *
010162 010276          RT17 ; ADDR OF NEXT ROUTINE          *
010164 000144          100 ; ITERATION COUNT          *
010166 010170          RT16A ; SCOPE ENTRY POINT          *
          000016          X=X+1
, *****
, TEST THAT RANDOM NUMBERS CAN BE LOADED INTO THE BASE REG STER
010170 012702 010000          RT16A  MOV  #10000, %2 ; GET RANDOM #COUNTER
010174 017737 171056 001612 1$  MOV  @BASREG, PRVCNT ; GET PREVIOUS CONTENTS
010202 004737 002756          JSR  7, @#RNGEN ; GO GET A RANDOM NUMBER
010206 042700 000377          BIC  #000377, %0 ; CLEAR UNUSED BITS
010212 010037 001276          MOV  %0, XMTDAT ; GET RANDOM NUMBER
010216 013777 001276 171032 2$  MOV  XMTDAT, @BASREG ; LOAD RANDOM NUMBER INTO BASREG
010224 017737 171026 001274 2$  MOV  @BASREG, RCVDAT ; GET BASREG DATA
010232 023737 001276 001274 2$  CMP  XMTDAT, RCVDAT ; COMPARE DATA
010240 001401          BEQ  3$ ; BRANCH IF SAME
010242 104011          ERROR1 ; ERROR! DATA NOT THE SAME
010244 032777 040000 170630 3$  BIT  #BIT14, @SWP ; SCOPE LOOP?
010252 001406          BEQ  4$ ; BRANCH IF NO LOOP ON ERPGP
010254 005077 170776          CLR  @BASREG
010260 013777 001612 170770 3$  MOV  PRVCNT @BASREG ; LOAD PREVIOUS CONTENTS
010266 000753          BR  2$ ; REPEAT TEST
010270 005302          4$  DEC  %2 ; 10000 NUMBERS BEEN TESTED
010272 001340          BNE  1$ ; BRANCH IF NOT
010274 104006          5$  SCOPE ; SCOPE
```

```
010276 000017  
010300 010370  
010302 000144  
010304 010306  
000017  
RT17 17 ,ROUTINE # 17 *  
RT20 ,ADDR OF NEXT ROUTINE *  
100 ,ITERATION COUNT *  
RT17A ,SCOPE ENTRY POINT *  
X=X+1
```

```
010306 013701 001252  
010312 012777 001106 170736  
010320 012700 000001  
010324 050011  
010326 020011  
010330 001006  
010332 040011  
010334 005711  
010336 001011  
010340 006300  
010342 103370  
010344 104006  
010346 010037 001276  
010352 011137 001274  
010356 104011  
010360 000771  
010362 005037 001276  
010366 000771  
RT17A MOV BAR,%1 ,GET BAR ADDRESS *  
MOV #CAT,%BASREG ,INITIALIZE BASE REGISTER *  
MOV #1,%0 ,GET BIT TESTER *  
15 B S %0,(1) ,SET BAR BIT *  
CMP %0,(1) ,TEST THAT ONLY THE PROPER BAR BIT SET *  
BNE 35 ,BRANCH IF ERROR *  
B C %0,(1) ,CLEAR BAR BIT *  
TST (1) ,TEST THAT BAR BIT CLEARED *  
BNE 55 ,BRANCH IF BAR BIT FAILED TO CLEAR *  
ASL %0 ,SHIFT BIT TESTER *  
BCC 15  
25 SCOPE ,SCOPE *  
35 MOV %0,XMTDAT ,GET WHAT DATA WAS SUPPOSED TO BE *  
45 MOV (1),RCVDAT ,GET WHAT DATA WAS *  
ERROR1 ,ERROR! IMPROPER BIT OPERATION *  
BR 25 ,GO TO SCOPE *  
55 CLR XMTDAT ,GET WHAT DATA WAS SUPPOSED TO BE *  
BR 45
```

```
010370 000020  
010372 010456  
010374 000012  
010376 010400  
000020  
RT20 20 ,ROUTINE # 20 *  
RT21 ,ADDR OF NEXT ROUTINE *  
10 ,ITERATION COUNT *  
RT20A ,SCOPE ENTRY POINT *  
X=X+1
```

```
010400 005037 001276  
010404 052777 177777 170640  
010412 104005  
010414 017737 170632 001274  
010422 001402  
010424 104011  
010426 000412  
010430 052777 177777 170614 15  
010436 005077 170610  
010442 017737 170604 001274  
010450 001401  
010452 104011  
010454 104006  
RT20A CLR XMTDAT ,TEST THAT RESET CLEARS ALL BAR BITS *  
BIS #-1,%BAR ,SET ALL BAR BITS *  
SRESET ,RESET *  
MOV %BAR,RCVDAT ,GET BAR DATA *  
BEQ 15 ,BRANCH IF ALL 0'S *  
ERROR1 ,ERROR! RESET DID NOT CLEAR ALL BAR BITS *  
BR 25 ,GO TO EXIT *  
15 BIS #-1,%BAR ,SET ALL BIT IN THE BAR *  
CLR %BAR ,CLEAR ALL BITS IN THE BAR *  
MOV %BAR,RCVDAT ,GET & TEST RESULT OF CLEAR OPERATION *  
BEQ 25 ,EXIT IF ALL BITS CLEARED *  
ERROR1 ,ERROR! ALL BITS DID NOT CLEAR *  
25 SCOPE ,SCOPE *
```

```
010456 000021  
010460 010564  
010462 000144  
010464 010466  
000021  
RT21 21 ,ROUTINE # 21 *  
RT22 ,ADDR OF NEXT ROUTINE *  
100 ,ITERATION COUNT *  
RT21A ,SCOPE ENTRY POINT *  
X=X+1
```

```
. TEST THAT CSR RESPONDS PROPERLY TO BYTE COMMANDS
010466 012777 010100 170554 RT21A MOV #10100, @CSR ; LOAD TEST NUMBER IN CSR
010474 105077 170550 CLR B @CSR ; CLEAR EVEN BYTE
010500 022777 010000 170542 CMP #10000, @CSR ; TEST THAT ONLY EVEN BYTE CLEARED
010506 001410 BEQ 15
010510 012737 010100 001276 MOV #10100, XMTDAT ; LOAD CORRECT RESULT
010516 017737 170526 001274 MOV @CSR, RCV DAT ; GET ACTUAL RESULT
010524 104011 EROR1 ; ERROR! EVEN BYTE INSTRUCT ON FAILED
010526 000415 BR 25 ; GO TO SCOPE
010530 012777 010100 170512 15 MOV #10100, @CSR ; LOAD TEST NUMBER IN CSR
010536 105077 171052 CLR B @ CSR ; TEST THAT ONLY ODD BYTE CLEARED
010542 001407 BEQ 25
010544 012737 000100 001276 MOV #00100, XMTDAT ; LOAD CORRECT RESULT
010552 017737 170472 001274 MOV @CSR, RCV DAT ; LOAD ACTUAL RESULT
010560 104011 EROR1 ; ERRCR! ODD BYTE INSTRUCTION FAILED
010562 104006 25 SCOPE ; SCOPE
*****
010564 000022 RT22 22 ; ROUTINE # 22 *
010566 010672 RT23 ; ADDR OF NEXT ROUTINE *
010570 000144 100 ; ITERATION COUNT *
010572 010574 RT22A ; SCOPE ENTRY POINT *
000022 X=X+1
*****

. TEST THAT BAR RESPONDS PROPERLY TO BYTE COMMANDS
010574 012777 010100 170450 RT22A MOV #10100, @BAR ; LOAD TEST NUMBER IN BAR
010602 105077 170444 CLR B @BAR ; CLEAR EVEN BYTE
010606 022777 010000 170436 CMP #10000, @BAR ; TEST THAT ONLY EVEN BYTE CLEARED
010614 001410 BEQ 15
010616 012737 010100 001276 MOV #10100, XMTDAT ; LOAD CORRECT RESULT
010624 017737 170422 001274 MOV @BAR, RCV DAT ; GET ACTUAL RESULT
010632 104011 EROR1 ; ERROR! EVEN BYTE INSTRUCTION FAILED
010634 000415 BR 25 ; GO TO SCOPE
010636 012777 010100 170406 15 MOV #10100, @BAR ; LOAD TEST NUMBER IN BAR
010644 105077 170746 CLR B @ BAR ; TEST THAT ONLY ODD BYTE CLEARED
010650 001407 BEQ 25
010652 012737 000100 001276 MOV #00100, XMTDAT ; LOAD CORRECT RESULT
010660 017737 170364 001274 MOV @CSR, RCV DAT ; LOAD ACTUAL RESULT
010666 104011 EROR1 ; ERRCR! ODD BYTE INSTRUCTION FAILED
010670 104006 25 SCOPE ; SCOPE
*****
010672 000023 RT23 23 ; ROUTINE # 23 *
010674 011000 RT24 ; ADDR OF NEXT ROUTINE *
010676 000144 100 ; ITERATION COUNT *
010700 010702 RT23A ; SCOPE ENTRY POINT *
000023 X=Y+1
*****

. TEST THAT BKCSR RESPONDS PROPERLY TO BYTE COMMANDS
010702 012777 010100 170344 RT23A MOV #10100, @BKCSR ; LOAD TEST NUMBER IN BKCSR
010710 105077 170340 CLR B @BKCSR ; CLEAR EVEN BYTE
010714 022777 010000 170332 CMP #10000, @BKCSR ; TEST THAT ONLY EVEN BYTE CLEARED
010722 001410 BEQ 15
010724 012737 010100 001276 MOV #10100, XMTDAT ; LOAD CORRECT RESULT
010732 017737 170316 001274 MOV @BKCSR, RCV DAT ; GET ACTUAL RESULT
```

```
010740 104011          ERROR1          ,ERROR! EVEN BYTE INSTRUCT ON FAILED
010742 000415          BR            2$          ,GO TO SCOPE
010744 012777 010100 170302 1$  MOV          #10100,@BKCSR ,LOAD TEST NUMBER IN BKCSR
010752 105077 170642          CLRB         @BKCSR     ,TEST THAT ONLY ODD BYTE CLEARED
010756 001407          BEQ         2$
010760 012737 000100 001276  MOV          #00100,XMTDAT ,LOAD CORRECT RESULT
010766 017737 170256 001274  MOV          @CSR,RCVDAT ,LOAD ACTUAL RESULT
010774 104011          ERROR1          ,ERROR! ODD BYTE INSTRUCTION FAILED
010776 104006          2$          SCOPE          ,SCOPE
,*****
RT24 24          ,ROUTINE # 24          *
      RT25          ,ADDR OF NEXT ROUTINE  *
      100          ,ITERATION COUNT      *
      RT24A         ,SCOPE ENTRY POINT   *
      X=X+1
,*****
,TEST THAT OVER RUN BIT (CSR BIT13) CAUSES AN INTERRUPT WHEN SET
011010 012777 011042 170246 RT24A MOV          #1$,@XMTINT ,LOAD TRANSMITTER INTERRUPT VECTOR
011016 012777 010000 170224  MOV          #BIT12,@CSR ,SET TRANSMITTER IE BIT
011024 052777 020000 170216  BIS          #BIT13,@CSR ,SET OVER RUN BIT
011032 005037 177776          CLR          @PSW      ,ENABLE INTERRUPTS
011036 000240          NOP
011040 104001          ERROR          ,ERROR!OVERRUN FAILED TO CAUSE AN
,INTERRUPT,OR INTERRUPTED TO INCOR-
,RECT ADDRESS
011042 104006          1$          SCOPE          ,SCOPE
,*****
RT25 25          ,ROUTINE # 25          *
      RT26          ,ADDR OF NEXT ROUTINE  *
      100          ,ITERATION COUNT      *
      RT25A         ,SCOPE ENTRY POINT   *
      X=X+1
,*****
,TEST THAT THE DM11 INTERRUPTS AT THE CORRECT LEVEL
011054 012737 000340 177776 RT25A MOV          #PTY7,@PSW
011062 012777 011112 170174  MOV          #1$,@XMTINT ,LOAD TRANSMITTER INTEPRUPT VECTOR
011070 012777 030000 170152  MOV          #30000,@CSR ,SET OVER RUN & IE BITS
011076 012737 000200 177776  MOV          #PTY4,@PSW ,ALLOW INTERRUPTS ON LEVEL 5 & ABOVE
011104 000240          NOP
011106 104001          ERROR          ,ERROR!DM11 FAILED TO INTERRUPT
011110 000417          BR            3$          ,GO TO EXIT
011112 022626          1$          CMP          (6)+,(6)+ ,RESET STACK POINTER
011114 013737 001266 177776  MOV          XMTLVL,@PSW ,LOAD DM11 INTERRUPT LEVEL
011122 012777 011146 170124  MOV          #2$,@XMTINT ,LOAD TRANSMITTER INTERRUPT VECTOR
011130 005077 170114          CLR          @CSR
011134 012777 030000 170106  MOV          #30000,@CSR
011142 000240          NOP
011144 000401          BR            3$          ,GO TO EXIT
011146 104001          2$          ERROR          ,ERROR! DM11 INTEPRUPTED ON HIGHER
,PRIORITY LEVEL THAN SET FOR
011150 104006          3$          SCOPE
,*****
RT26 26          ,ROUTINE # 26          *
      RT27          ,ADDRESS OF NEXT TEST  *
011152 000026
011154 011170
```

```
U11156 000144          100          , ITERATION COUNT          *
011160 011162          LTST0          , SCOPE ENTRY POINT        *
          000026          X=X+1
, *****
, TRANSMITTER LINE TEST LINE 0
011162 004537 004330  LTST0 JSR      5, XMTTST      , GO TEST TRANSMITTER L NE 0
011166 000000          LINE0
          000001          Y=Y+1
, *****
011170 000027          RT27          27          , ROUTINE # 27              *
011172 011206          RT30          , ADDRESS OF NEXT TEST     *
011174 000144          100          , ITERATION COUNT          *
011176 011200          LTST1          , SCOPE ENTRY POINT        *
          000027          X=X+1
, *****
, TRANSMITTER LINE TEST LINE 1
011200 004537 004330  LTST1 JSR      5, XMTTST      , GO TEST TRANSMITTER L NE 1
011204 000002          LINE1
          000002          Y=Y+1
, *****
011206 000030          RT30          30          , ROUTINE # 30              *
011210 011224          RT31          , ADDRESS OF NEXT TEST     *
011212 000144          100          , ITERATION COUNT          *
011214 011216          LTST2          , SCOPE ENTRY POINT        *
          000030          X=X+1
, *****
, TRANSMITTER LINE TEST LINE 2
011216 004537 004330  LTST2 JSR      5, XMTTST      , GO TEST TRANSMITTER LINE 2
011222 000004          LINE2
          000003          Y=Y+1
, *****
011224 000031          RT31          31          , ROUTINE # 31              *
011226 011242          RT32          , ADDRESS OF NEXT TEST     *
011230 000144          100          , ITERATION COUNT          *
011232 011234          LTST3          , SCOPE ENTRY POINT        *
          000031          X=X+1
, *****
, TRANSMITTER LINE TEST LINE 3
011234 004537 004330  LTST3 JSR      5, XMTTST      , GO TEST TRANSMITTER LINE 3
011240 000006          LINE3
          000004          Y=Y+1
, *****
011242 000032          RT32          32          , ROUTINE # 32              *
011244 011260          RT33          , ADDRESS OF NEXT TEST     *
011246 000144          100          , ITERATION COUNT          *
011250 011252          LTST4          , SCOPE ENTRY POINT        *
          000032          X=X+1
, *****
, TRANSMITTER LINE TEST LINE 4
011252 004537 004330  LTST4 JSR      5, XMTTST      , GO TEST TRANSMITTER LINE 4
011256 000010          LINE4
          000005          Y=Y+1
, *****
011260 000033          RT33          33          , ROUTINE # 33              *
011262 011276          RT34          , ADDRESS OF NEXT TEST     *
011264 000144          100          , ITERATION COUNT          *
```

```
011266 011270          LTST5          ,SCOPE ENTRY POINT          *
          000033          X=X+1
          ,*****
          ,TRANSMITTER LINE TEST LINE 5
011270 004537 004330  LTST5 JSR          5,XMTTST          ,GO TEST TRANSMITTER LINE 5
011274 000012          LINE5
          000006          Y=Y+1
          ,*****
011276 000034          RT34          34          ,ROUTINE # 34          *
011300 011314          RT35          ,ADDRESS OF NEXT TEST          *
011302 000144          100          ,ITERATION COUNT          *
011304 011306          LTST6          ,SCOPE ENTRY POINT          *
          000034          X=X+1
          ,*****
          ,TRANSMITTER LINE TEST LINE 6
011306 004537 004330  LTST6 JSR          5,XMTTST          ,GO TEST TRANSMITTER LINE 6
011312 000014          LINE6
          000007          Y=Y+1
          ,*****
011314 000035          PT35          35          ,ROUTINE # 35          *
011316 011332          RT36          ,ADDRESS OF NEXT TEST          *
011320 000144          100          ,ITERATION COUNT          *
011322 011324          LTST7          ,SCOPE ENTRY POINT          *
          000035          X=X+1
          ,*****
          ,TRANSMITTER LINE TEST LINE 7
011324 004537 004330  LTST7 JSR          5,XMTTST          ,GO TEST TRANSMITTER LINE 7
011330 000016          LINE7
          000010          Y=Y+1
          ,*****
011332 000036          PT36          36          ,ROUTINE # 36          *
011334 011350          RT37          ,ADDRESS OF NEXT TEST          *
011336 000144          100          ,ITERATION COUNT          *
011340 011342          LTST10         ,SCOPE ENTRY POINT          *
          000036          X=X+1
          ,*****
          ,TRANSMITTER LINE TEST LINE 10
011342 004537 004330  LTST10 JSR         5,XMTTST          ,GO TEST TRANSMITTER LINE 10
011346 000020          LINE10
          000011          Y=Y+1
          ,*****
011350 000037          RT37          37          ,ROUTINE # 37          *
011352 011366          RT40          ,ADDRESS OF NEXT TEST          *
011354 000144          100          ,ITERATION COUNT          *
011356 011360          LTST11         ,SCOPE ENTRY POINT          *
          000037          X=X+1
          ,*****
          ,TRANSMITTER LINE TEST LINE 11
011360 004537 004330  LTST11 JSR         5,XMTTST          ,GO TEST TRANSMITTER LINE 11
011364 000022          LINE11
          000012          Y=Y+1
          ,*****
011366 000040          PT40          40          ,ROUTINE # 40          *
011370 011404          RT41          ,ADDRESS OF NEXT TEST          *
011372 000144          100          ,ITERATION COUNT          *
011374 011376          LTST12         ,SCOPE ENTRY POINT          *
```

```
000040 X=X+1
,*****
,TRANSMITTER LINE TEST LINE 12
011376 004537 004330 LTST12 JSR 5,XMTTST ,GO TEST TRANSMITTER LINE 12
011402 000024
000013 LINE12
Y=Y+1
,*****
011404 000041 RT41 41 ,ROUTINE # 41 *
011406 011422 RT42 ,ADDRESS OF NEXT TEST *
011410 000144 100 ,ITERATION COUNT *
011412 011414 LTST13 ,SCOPE ENTRY POINT *
000041 X=X+1
,*****
,TRANSMITTER LINE TEST LINE 13
011414 004537 004330 LTST13 JSR 5,XMTTST ,GO TEST TRANSMITTER LINE 13
011420 000026
000014 LINE13
Y=Y+1
,*****
011422 000042 RT42 42 ,ROUTINE # 42 *
011424 011440 RT43 ,ADDRESS OF NEXT TEST *
011426 000144 100 ,ITERATION COUNT *
011430 011432 LTST14 ,SCOPE ENTRY POINT *
000042 X=X+1
,*****
,TRANSMITTER LINE TEST LINE 14
011432 004537 004330 LTST14 JSR 5,XMTTST ,GO TEST TRANSMITTER LINE 14
011436 000030
000015 LINE14
Y=Y+1
,*****
011440 000043 RT43 43 ,ROUTINE # 43 *
011442 011456 RT44 ,ADDRESS OF NEXT TEST *
011444 000144 100 ,ITERATION COUNT *
011446 011450 LTST15 ,SCOPE ENTRY POINT *
000043 X=X+1
,*****
,TRANSMITTER LINE TEST LINE 15
011450 004537 004330 LTST15 JSR 5,XMTTST ,GO TEST TRANSMITTER LINE 15
011454 000032
000016 LINE15
Y=Y+1
,*****
011456 000044 RT44 44 ,ROUTINE # 44 *
011460 011474 RT45 ,ADDRESS OF NEXT TEST *
011462 000144 100 ,ITERATION COUNT *
011464 011466 LTST16 ,SCOPE ENTRY POINT *
000044 X=X+1
,*****
,TRANSMITTER LINE TEST LINE 16
011466 004537 004330 LTST16 JSR 5,XMTTST ,GO TEST TRANSMITTER LINE 16
011472 000034
000017 LINE16
Y=Y+1
,*****
011474 000045 RT45 45 ,ROUTINE # 45 *
011476 011512 RT46 ,ADDRESS OF NEXT TEST *
011500 000144 100 ,ITERATION COUNT *
011502 011504 LTST17 ,SCOPE ENTRY POINT *
000045 Y=Y+1
```

```
*****  
; TRANSMITTER LINE TEST LINE 17  
011504 004537 004330 LTST17 JSR 5,XMTTST ; GO TEST TRANSMITTER LINE 17  
011510 000036 LINE17  
000020 Y=Y+1  
000000 Y=0  
000000 A=0  
*****  
; ROUTINE # 46  
011512 000046 RT46 46 ; ROUTINE # 46 *  
011514 011530 RT47 ; ADDRESS OF NEXT TEST *  
011516 000144 100 ; ITERATION COUNT *  
011520 011522 RCV0 ; SCOPE ENTRY POINT *  
000046 X=X+1  
*****  
; RECEIVER LINE TEST LINE 0  
011522 004537 004542 RCV0 JSR 5,RCVTST ; GO TEST RECEIVER LINE 0  
011526 000000 LINE0  
000001 Y=Y+1  
*****  
; ROUTINE # 47  
011530 000047 RT47 47 ; ROUTINE # 47 *  
011532 011546 RT50 ; ADDRESS OF NEXT TEST *  
011534 000144 100 ; ITERATION COUNT *  
011536 011542 RCV1 ; SCOPE ENTRY POINT *  
000047 Y=Y+1  
*****  
; RECEIVER LINE TEST LINE 1  
011540 004537 004542 RCV1 JSP 5,RCVTST ; GO TEST RECEIVER LINE 1  
011544 000002 LINE1  
000002 Y=Y+1  
*****  
; ROUTINE # 50  
011546 000050 RT50 50 ; ROUTINE # 50 *  
011550 011564 RT51 ; ADDRESS OF NEXT TEST *  
011552 000144 100 ; ITERATION COUNT *  
011554 011556 RCV2 ; SCOPE ENTRY POINT *  
000050 X=X+1  
*****  
; RECEIVER LINE TEST LINE 2  
011556 004537 004542 RCV2 JSR 5,RCVTST ; GO TEST RECEIVER LINE 2  
011562 000004 LINE2  
000003 Y=Y+1  
*****  
; ROUTINE # 51  
011564 000051 RT51 51 ; ROUTINE # 51 *  
011566 011602 RT52 ; ADDRESS OF NEXT TEST *  
011570 000144 100 ; ITERATION COUNT *  
011572 011574 RCV3 ; SCOPE ENTRY POINT *  
000051 X=X+1  
*****  
; RECEIVER LINE TEST LINE 3  
011574 004537 004542 RCV3 JSR 5,RCVTST ; GO TEST RECEIVER LINE 3  
011600 000006 LINE3  
000004 Y=Y+1  
*****  
; ROUTINE # 52  
011602 000052 RT52 52 ; ROUTINE # 52 *  
011604 011620 RT53 ; ADDRESS OF NEXT TEST *  
011606 000144 100 ; ITERATION COUNT *  
011610 011612 RCV4 ; SCOPE ENTRY POINT *
```



```
000052
X=X+1
, *****
, RECEIVER LINE TEST LINE 4
011612 004537 004542 RCV4 JSR 5,RCVTST ,GO TEST RECEIVER LINE 4
011616 000010 LINE4
000005 Y=Y+1
, *****
011620 000053 RT53 53 ,ROUTINE # 53 *
011622 011636 RT54 ,ADDRESS OF NEXT TEST *
011624 000144 100 ,ITERATION COUNT *
011626 011630 RCV5 ,SCOPE ENTRY POINT *
000053 X=X+1
, *****
, RECEIVER LINE TEST LINE 5
011630 004537 004542 RCV5 JSR 5,RCVTST ,GO TEST RECEIVER LINE 5
011634 000012 LINE5
000006 Y=Y+1
, *****
011636 000054 RT54 54 ,ROUTINE # 54 *
011640 011654 RT55 ,ADDRESS OF NEXT TEST *
011642 000144 100 ,ITERATION COUNT *
011644 011646 RCV6 ,SCOPE ENTRY POINT *
000054 X=X+1
, *****
, RECEIVER LINE TEST LINE 6
011646 004537 004542 RCV6 JSR 5,RCVTST ,GO TEST RECEIVER LINE 6
011652 000014 LINE6
000007 Y=Y+1
, *****
011654 000055 RT55 55 ,ROUTINE # 55 *
011656 011672 RT56 ,ADDRESS OF NEXT TEST *
011660 000144 100 ,ITERATION COUNT *
011662 011664 RCV7 ,SCOPE ENTRY POINT *
000055 X=X+1
, *****
, RECEIVER LINE TEST LINE 7
011664 004537 004542 RCV7 JSR 5,RCVTST ,GO TEST RECEIVER LINE 7
011670 000016 LINE7
000010 Y=Y+1
, *****
011672 000056 RT56 56 ,ROUTINE # 56 *
011674 011710 RT57 ,ADDRESS OF NEXT TEST *
011676 000144 100 ,ITERATION COUNT *
011700 011702 RCV10 ,SCOPE ENTRY POINT *
000056 X=X+1
, *****
, RECEIVER LINE TEST LINE 10
011702 004537 004542 RCV10 JSR 5,RCVTST ,GO TEST RECEIVER LINE 10
011706 000020 LINE10
000011 Y=Y+1
, *****
011710 000057 RT57 57 ,ROUTINE # 57 *
011712 011726 RT60 ,ADDRESS OF NEXT TEST *
011714 000144 100 ,ITERATION COUNT *
011716 011720 RCV11 ,SCOPE ENTRY POINT *
000057 X=X+1
```

```
*****  
RECEIVER LINE TEST LINE 11  
011720 004537 004542 RCV11 JSR 5,RCVTST ,GO TEST RECEIVER LINE 11  
011724 000022 LINE11  
000012 Y=Y+1  
*****  
RT60 60 ;ROUTINE # 60 *  
011726 000060 RT61 ;ADDRESS OF NEXT TEST *  
011730 011744 100 ;ITERATION COUNT *  
011732 000144 RCV12 ;SCOPE ENTRY POINT *  
011734 011736 X=X+1  
000060  
*****  
RECEIVER LINE TEST LINE 12  
011736 004537 004542 RCV12 JSR 5,RCVTST ,GO TEST RECEIVER LINE 12  
011742 000024 LINE12  
000013 Y=Y+1  
*****  
RT61 61 ;ROUTINE # 61 *  
011744 000061 RT62 ;ADDRESS OF NEXT TEST *  
011746 011762 100 ;ITERATION COUNT *  
011750 000144 RCV13 ;SCOPE ENTRY POINT *  
011752 011754 X=X+1  
000061  
*****  
RECEIVER LINE TEST LINE 13  
011754 004537 004542 PCV13 JSR 5,RCVTST ,GO TEST RECEIVER LINE 13  
011760 000026 LINE13  
000014 Y=Y+1  
*****  
RT62 62 ;ROUTINE # 62 *  
011762 000062 RT63 ;ADDRESS OF NEXT TEST *  
011764 012000 100 ;ITERATION COUNT *  
011766 000144 RCV14 ;SCOPE ENTRY POINT *  
011770 011772 X=X+1  
000062  
*****  
RECEIVER LINE TEST LINE 14  
011772 004537 004542 RCV14 JSR 5,RCVTST ,GO TEST RECEIVER LINE 14  
011776 000030 LINE14  
000015 Y=Y+1  
*****  
PT63 63 ;ROUTINE # 63 *  
012000 000063 PT64 ;ADDRESS OF NEXT TEST *  
012002 012016 100 ;ITERATION COUNT *  
012004 000144 RCV15 ;SCOPE ENTRY POINT *  
012006 012010 X=X+1  
000063  
*****  
RECEIVER LINE TEST LINE 15  
012010 004537 004542 PCV15 JSR 5,RCVTST ,GO TEST RECEIVER LINE 15  
012014 000032 LINE15  
000016 Y=Y+1  
*****  
RT64 64 ;ROUTINE # 64 *  
012016 000064 RT65 ;ADDRESS OF NEXT TEST *  
012020 012034 100 ;ITERATION COUNT *  
012022 000144 RCV16 ;SCOPE ENTRY POINT *  
012024 012026 X=X+1  
000064  
*****
```

```

, RECEIVER LINE TEST LINE 16
012026 004537 004542 RCV16 JSR 5,RCVTST ,GO TEST RECEIVER LINE 16
012032 000034 LINE16
000017 Y=Y+1
, *****
012034 000065 RT65 65 ,ROUTINE # 65 *
012036 012054 RT66 ,ADDRESS OF NEXT TEST *
012040 000144 100 ,ITERATION COUNT *
012042 012044 RCV17 ,SCOPE ENTRY POINT *
000065 X=X+1
, *****
, RECEIVER LINE TEST LINE 17
012044 004537 004542 RCV17 JSR 5,PCVTST ,GO TEST RECEIVER LINE 17
012050 000036 LINE17
000020 Y=Y+1
012052 000240 NOP
, *****
012054 000066 RT66 66 ,ROUTINE # 66 *
012056 012314 RT67 ,ADDR OF NEXT ROUTINE *
012060 000012 10 ,ITERATION COUNT *
012062 012070 RT66A ,SCOPE ENTRY POINT *
000066 X=X+1
, *****

012064 000240 NOP
012066 000240 NOP

TEST THAT NEX BIT (CSR BIT 14) SETS WHEN THE TRANSMITTER REFERENCES
NON-EXISTANT MEMORY, THE CORRESPONDING BAR BIT CLEARS
AND THAT AN INTERPUPT OCCURS ALL LINES ARE USED FOR THE TEST
012070 004737 003724 RT66A JSR 7,TIMER ,GO CALCULATE MACHINE TIME TO TRANSMIT
,ONE CHARACTER
012074 012701 001106 MOV #CAT,%1 ,GET CAT ADDRESS
012100 012702 160000 MOV #160000,%2 ,GET A NON-EXISTANT ADDRESS
012104 012703 000020 MOV #16,%3 ,GET COUNTER
012110 010221 15 MOV %2,(1)+ ,LOAD THE CURRENT ADDRESS
012112 005303 DEC %3 ,TABLE WITH NON-EXISTANT
012114 001375 BNE 15 ,ADDRESSES
012116 012701 000001 MOV #LBITD,%1 ,GET LINE BIT
012122 012777 012260 167134 MOV #65,%XMTINT ,LOAD TRANSMITTER INT VECTOR
012130 052777 000060 167112 25 BIS #60,%CSR ,SET EXTENDED ADDRESS BITS
012136 050177 167110 BIS %1,%BAR ,START TRANSMITTER
012142 013737 004076 012152 MOV TIME14,%5 ,LOAD DELAY TIME TO
012150 104400 DELAY ,DELAY FOR 1/4TH OF A CHARACTER
012152 000000 OPEN ,TO RESPOND TO NEX
012154 017737 167072 001274 35 MOV %BAR,%RCV DAT ,GET BAR DATA & TEST
012162 001406 BEQ 45 ,THAT IT IS CLEAR
012164 005037 001276 CLR XMTDAT
012170 104011 ERROR1 ,ERROR! BAR BIT DID NOT CLEAR
012172 005077 167054 CLR %BAR
012176 000440 BR 75 ,GO TO SCOPE
012200 032777 040000 167042 45 BIT #BIT14,%CSR ,TEST THAT NEX BIT IS SET
012206 001002 BNE 55 ,BRANCH IF SET
012210 104001 ERROR ,ERROR! NEX BIT FAILED TO SET
012212 000432 BR 75 ,GO TO SCOPE
012214 042777 100000 167026 55 BIC #BIT15,%CSR ,CLEAR TRANSMITTER READY FLAG
012222 052777 010000 167020 BIS #BIT12,%CSR ,SET TRANSMITTER IE BIT
    
```

```
012230 005037 177776 CLR @#PSW ,ALLOW INTERRUPTS
012234 000240 NOP
012236 012737 000340 177776 MOV #PTY7,@#PSW ,LOCK OUT INTERRUPTS
012244 010137 001276 MOV %1,XMTDAT ,LOAD LINE THAT FAILED
012250 005037 001274 CLR RCVDAT
012254 104011 ERROR1 ,ERROR! NEX FAILED TO CAUSE INTERRUPT
,TYPEOUT SHOWS LINE # THAT FAILED
,GO TO SCOPE
012256 000410 BR 7$
012260 005077 166764 6$ CLR @CSR
012264 012737 000340 177776 MOV #PTY7,@#PSW ,LOCK OUT INTERRUPTS
012272 022626 CMP (6)+,(6)+ ,ADJUST STACK PTR
012274 006301 ASL %1 ,SHIFT LINE BIT
012276 103314 BCC 2$ ,DO NEXT LINE
012300 013737 004074 012310 7$ MOV TIME1,8$ ,WAIT FOR TRANSMITTER TO RUN
012306 104400 DELAY ,TO COMPLETION BEFORE
012310 000000 8$ OPEN ,EXITING TEST
012312 104006 SCOPE ,SCOPE
,*****
012314 000067 RT67 67 ,ROUTINE # 67 *
012316 012424 RT70 ,ADDR OF NEXT ROUTINE *
012320 000012 10 ,ITERATION COUNT *
012322 012324 RT67A ,SCOPE ENTRY POINT *
000067 X=X+1
,*****
TEST THAT NEX BIT SETS IF THE DM11 TABLES ARE IN NON-EXISTANT CORE
012324 012777 160000 166704 PT67A MOV #160000,@BASREG ,SET BASE REGISTER TO NON-EXISTANT ADRS
012332 012737 012414 000004 MOV #4$,@#ERRVEC ,SET TIME OUT TRAP VECTOR
012340 005737 160000 TST @#160000 ,CHECK THAT ADDRESS TIMES OUT
012344 013737 004076 012362 MOV TIME14,1$ ,GET TIME TO TRANSMIT 1/4 CHAR
012352 052777 000001 166672 BIS #LBIT0,@BAR ,START TO TRANSMIT ON LINE 0
012360 104400 DELAY ,DELAY 1/4TH OF A CHARACTER
012362 000000 1$ OPEN ,TIME
012364 005077 166662 CLR @BAR ,STOP TRANSMITTER
012370 022777 040060 166652 CMP #BIT14+60,@CSR ,TEST THAT ONLY NEX IS SET
012376 001401 BEQ 2$
012400 104001 ERRORP ,ERROR! EITHER NEX FALED TO SET
,OR OTHER BITS SET
012402 013737 004074 012412 2$ MOV TIME1,3$ ,DELAY 1 CHARACTER TIME TO ALLOW
012410 104400 DELAY ,TRANSMITTER TO RUN TO
012412 000000 3$ OPEN ,COMPLETION
012414 012737 000006 000004 4$ MOV #ERRVEC+2,@#EPRVEC ,RESTORE TIME OUT TRAP
012422 104006 SCOPE
,*****
012424 000070 RT70 70 ,ROUTINE # 70 *
012426 012540 RT71 ,ADDR OF NEXT ROUTINE *
012430 000144 100 ,ITERATION COUNT *
012432 012434 RT70A ,SCOPE ENTRY POINT *
000070 X=X+1
,*****
TEST THAT WHEN THE GO BIT IS CLEAR THAT THE RECEIPEPS DO NOT RECEIVE
DATA EACH LINE IN TURN IS TRANSMITTED ON,AND WHEN TEN CHARACTEPS
HAVE BEEN TRANSMITTED THE RECEIVER DONE FLAG IS TESTED IF IT IS SET
AN ERROR IS INDICATED ON THE LINE DATA WAS RECEIVED ON
012434 005037 016412 RT70A CLR LINE ,SET UP TO TRANSMIT
```

012440	004537	005754		15	JSR	5, @XMITD	, 10 CHARACTERS
012444	177766				-10		, ON EACH LINE
012446	005777	166576			TST	@CSR	, WAIT FOR 10 CHARACTERS
012452	100375				BPL	-4	, TO BE TRANSMITTED
012454	042777	100000	166566		BIC	#100000, @CSR	
012462	105777	166562			TSTB	@CSR	, TEST RECEIVER DONE FLAG
012466	100010				BPL	25	
012470	013737	001272	001274		MOV	LINBIT, RCVDAT	, GET LINE BIT OF ACTIVE LINE
012476	013737	001272	001276		MOV	LINBIT, XMTDAT	, THAT ERROR OCCURED ON
012504	104011				ERROR1		, ERROR DATA WAS RECEIVED ON LINE INDICATED
012506	000413				BR	45	, GO TO SCOPE
012510	062737	000002	016412	25	ADD	#2, LINE	, SET UP NEXT LINE NUMBER
012516	006337	001272			ASL	LINBIT	, GET READY TO TRANSMIT ON NEXT LINE
012522	103346				BCC	15	, GO TRANSMIT ON NEXT LINE
012524	013737	004074	012534		MOV	TIME1, 35	
012532	104400				DELAY		, DELAY 1 CHARACTER
012534	000000			35	0		, TIME BEFORE ENTERING NEXT TEST
012536	104006			45	SCOPE		, SCOPE

RT71 71 , ROUTINE # 71 *
RT72 , ADDR OF NEXT ROUTINE *
20 , ITERATION COUNT *
RT71A , SCOPE ENTRY POINT *
X=X+1

TEST THAT CURRENT ADDRESS INCREMENTS PROPERLY WHEN A CHARACTER IS TRANSMITTED LINE 0 IS USED FOR THE TEST

012550	005000			RT71A	CLR	%0	, R0=CURRENT ADRS AFTER TRANSMISSION
012552	010001			15	MOV	%0, %1	, R0=CURRENT ADDRESS BEFORE TRANSMISSION
012554	005201				INC	%1	, AND R1=CURRENT ADDRESS AFTER TRANSMISSION
012556	012737	012720	000004		MOV	#35, @ERRVEC	, SET UP PROCESSOR
012564	012737	000340	000006		MOV	#PRTY7, @ERRVEC+2	, TIME OUT TRAP
012572	012777	001106	166456		MOV	#CAT, @BASREG	, SET UP BASE REGISTER
012600	010037	001106			MOV	%0, CAT	, LOAD CURRENT ADDRESS TABLE (LINE 0)
012604	105710				TSTB	(0)	, DOES MEMORY EXIST?
012606	012737	177776	001146		MOV	#-2, WCT	, SET CHAR COUNT TO TRANSMIT 1 CHAR
012614	012777	000005	166426		MOV	#5, @CSR	, SET MAINT & GO BITS
012622	012777	000001	166422		MOV	#LBITD, @BAR	, TRANSMIT ON LINE 0
012630	105777	166414			TSTB	@CSR	, WAIT FOR THE RECEIVER
012634	100375				BPL	-4	, TO RECEIVE FIRST CHARACTER
012636	042777	000200	166404		BIC	#200, @CSR	, CLEAR RECEIVER DONE FLAG
012644	105777	166400			TSTB	@CSR	, WAIT FOR RECEIVER TO RECEIVE
012650	100375				BPL	-4	, THE SECOND CHARACTER
012652	023701	001106			CMR	CAT, %1	, TEST THAT CURRENT ADRS INCREMENTED PROPERLY
012656	001413				BEQ	25	
012660	010137	001276			MOV	%1, XMTDAT	, GET COMPUTED RESULT
012664	013737	001106	001274		MOV	CAT, RCVDAT	, GET ACTUAL RESULT
012672	104011				ERROR1		, ERROR! CURRENT ADDRESS DID NOT
012674	032777	040000	166200		BIT	#BIT14, @SWP	, INCREMENT PROPERLY
012702	001323				BNE	15	, BRANCH IF SCOPE SWITCH IS SET
012704	000405				BR	35	, GO TO EXIT
012706	005701			25	TST	%1	
012710	001403				BEQ	35	
012712	000261				SEC		

012714	006100				ROL	%0	
012716	100715				BMI	1\$	
012720	012737	000006	000004	3\$	MOV	#ERRVEC+2, @#ERRVEC	, RESTORE TIME OUT TRAP
012726	005037	000006			CLR	@#ERRVEC+2	
012732	104006				SCOPE		, SCOPE
, *****							
012734	000072				RT72	72	, ROUTINE # 72 *
012736	013300					RT73	, ADDR OF NEXT ROUTINE *
012740	000024					20	, ITERATION COUNT *
012742	012744					RT72A	, SCOPE ENTRY POINT *
	000072					X=X+1	
, *****							
, TEST THAT DATA CAN BE TRANSMITTED FROM ALL AVAILABLE CORE							
, LINE 0 IS USED FOR THE TEST AND ONLY ONE WORD IS TRANSMITTED							
, AT A TIME							
012744	005000				RT72A	CLR	%0 , CLEAR INDEX REGISTER
012746	000005					RESET	
012750	016037	013234	001106	1\$	MOV	AREA(0), CAT	, LOAD CURRENT ADDRESS
012756	012777	000005	166264		MOV	#5, @CSR	, SET MAINT & GO BITS
012764	012737	177777	001146		MOV	#-1, WCT	, SET UP CHAR COUNT TO TRANSMIT 1 CHAR
012772	012777	000001	166252		MOV	#LBITO, @BAR	, TRANSMIT CHAR ON LINE 0
013000	005777	166244			TST	@CSR	, WAIT FOR THE TRANSMITTER
013004	100375				BPL	-4	, TO TRANSMIT THE CHARACTER
013006	105777	166236			TSTB	@CSP	, TEST FOR DONE
013012	100375				BPL	-4	
013014	005077	166230			CLR	@CSR	, CLEAR ALL FLAGS
013020	005037	001274			CLR	RCV DAT	
013024	113737	001306	001274		MOVB	TUMTAB, RCV DAT	, GET RECEIVED CHARACTER
013032	117037	013234	001276		MOVB	@AREA(0), XMT DAT	, GET TRANSMITTED CHARACTER
013040	043737	001300	001276		BIC	CARMSK, XMT DAT	, CLEAR NON-TRANSMITTED BITS
013046	123737	001274	001276		CMPB	RCV DAT, XMT DAT	, COMPARE CHARACTERS
013054	001402				BEQ	2\$, BRANCH IF VALID COMPARISON
013056	104011				ERROR1		, ERROR DATA COMPARISON ERROR
, ((CAT)-1 IS THE MEMORY LOCATION WHERE THE DATA WAS TRANSMITTED FROM							
013060	000464				BR	6\$, GO TO EXIT
013062	020027	000006		2\$	CMP	%0, #6	, HAS FIRST 4K BEEN TESTED
013066	001402				BEQ	3\$, BRANCH IF IT HAS
013070	005720				TST	10 +	, INCREMENT INDEX
013072	000726				BR	1\$, GO REPEAT TEST
013074				3\$, BEGIN TESTING ABOVE 4K
013074	012737	017222	000004		MOV	#5\$ @#ERRVEC	, SET TIME OUT TRAP TO EXIT
013102	005001				CLR	%1	, TEST IF MEMORY TIMES OUT
013104	005201			4\$	INC	%1	, SET UP DATA IDENTIFIER
013106	005720				TST	(0)+	, INCREMENT DATA IDENTIFIER
013110	110170	013234			MOVB	%1, @AREA(0)	, INCREMENT INDEX
013114	016037	013234	001106		MOV	AREA(0), CAT	, LOAD IDENTIFIER INTO MEMOP
013122	012777	000005	166120		MOV	#5, @CSR	, LOAD CURRENT ADDRESS
013130	012737	177777	001146		MOV	#-1, WCT	, SET MAINT & GO BITS
013136	012777	000001	166106		MOV	#LBITO, @BAR	, SET UP CHAR COUNT TO TRANSMIT 1 CHAR
013144	005777	166100			TST	@CSR	, TRANSMIT ON LINE 0
013150	100375				BPL	-4	, WAIT FOR THE TRANSMITTER TO
013152	105777	166072			TSTB	@CSP	, TRANSMIT THE CHARACTER
, TEST FOR CHARACTER DONE							

```

013156 100375          BPL      -4
013160 005077 166064  CLR      @CSR
013164 113737 001306 001274  MOVB    TUMTAB,RCV DAT , GET THE RECEIVED CHARACTER
013172 117037 013234 001276  MOVB    @AREA(0),XMTDAT , GET THE TRANSMITTED CHARACTER
013200 043737 001300 001276  BIC     CARMSK,XMTDAT , CLEAR NON-TRANSMITTED BITS
013206 123737 001274 001276  CMPB    RCV DAT,XMTDAT , COMPARE CHARACTERS
013214 001733          BEQ     4$ , BRANCH IF VALID COMPARISON
013216 104011          ERROR1 , ERROR DATA COMPARISON ERROR NUMBER
013220 000404          BR      6$ , IN S/B GIVES MEMORY LOCATION (SEE TABLE)
013222 022626          POPSP2 , RESET THE STACK
013224 012737 000006 000004  MOV     #6,@#ERRVEC , RESTORE TIME OUT TRAP
013232 104006          6$     SCOPE , EXIT TEST
          ,MEMORY LOCATIONS TRANSMITTED FROM TABLE
013234 000000          AREA    0 , FOR DATA IN FIRST
013236 005252          5252 , 4K SEE THE LISTING
013240 012525          12525 , CONTENTS OF THESE LOCATIONS (BYTE
013242 017777          17777 , IS THE DATA TRANSMITTED
013244 020000          A8K    20000 , CONTENTS =1 (IF AVAILABLE)
013246 026314          "      2      "
013250 031463          "      3      "
          "      4      "
013252 037477          "      5      "
013254 040000          A12K   40000 , "      6      "
013256 057477          "      7      "
013260 060000          A16K   60000 , "      10     "
013262 077477          "      11     "
013264 100000          A20K  100000 , "      12     "
013266 117477          "      13     "
013270 120000          A24K  120000 , "      14     "
013272 137477          "      15     "
013274 140000          A28K  140000 , "      16     "
013276 173000          173000 ,
*****
013300 000073          PT73   73 , ROUTINE # 73 *
013302 013514          RT74   , ADDR OF NEXT ROUTINE *
013304 000012          10 , ITERATION COUNT *
013306 013310          RT73A , SCOPE ENTRY POINT *
          X=X+1
*****
, TEST THAT THE TRANSMITTER CAN TRANSMIT 100 CHARACTERS BEFORE SETTING
, THE READY BIT (CSR 15), AND CLEARING THE BAR BIT
013310 005037 016412          PT73A  CLR     LINE
013314 012777 000001 165726  1$     MOV     #1,@CSR , SET THE GO BIT
013322 005037 001274          CLP     RCV DAT
013326 013737 016412 001276  MOV     @#LINE,XMTDAT , GET LINE NUMBER (X2)
013334 004537 005754          JSR     5,@#XMITD , TRANSMIT 100 CHARACTERS
013340 177634          -100 , ON LINE AS SPECIFIED BY LINE
013342 105777 165702          2$     TSTB   @CSR , WAIT FOR THE RECEIVER
013346 100375          BPL     2$ , TO RECEIVE ONE CHARACTER
013350 042777 000200 165672  BIC     #BIT7,@CSR , CLEAR CHAR DONE FLAG
013356 005237 001274          INC     RCV DAT , INCREMENT CHAR RCVD COUNT
013362 023727 001274 000144  CMP     RCV DAT,#100 , HAVE 100 CHARS BEEN RCVD
013370 001416          BEQ     4$
013372 005777 165652          TST     @CSR , TEST READY FLAG
013376 100002          BPL     3$ , GO TEST BAR
  
```

```

013400 104011          ERROR1          ,ERROR! READY BIT SET TOO SOON
013402 000443          ,TYPEOUT SHOWS HOW MANY CHARS WERE RECEIVED WHEN READY SET AND THE LINE # (X2)
                                BR          8$          ,GO TO EXIT
013404 023777 001272 165640 3$      CMP          @#LINBIT,@BAR      ,TEST THAT BAR BIT IS SET
013412 001753          BEQ          2$          ,BRANCH IF SET
013414 017737 165632 001276          MOV          @BAR,XMTDAT      ,GET BAR CONTENTS
013422 104011          ERROR1          ,ERROR! BAR BIT CLEARED TOO SOON
                                ,TYPEOUT SHOWS THE BAR CONTENTS AND HOW MANY CHARS WERE RECEIVED WHEN BAR FAILED
                                ,LOCATION LINBIT HAS THE CORRECT BAR CONTENTS
013424 000432          BR          8$          ,EXIT TEST
013426 013737 004076 013436 4$      MOV          TIME14,5$      ,DELAY 1/4 CHARACTER TIME
013434 104400          DELAY          ,TO ALLOW TRANSMITTER TO FINISH
013436 000000          SS          OPEN
013440 005777 165604          TST          @CSR          ,TEST READY FLAG (SHOULD BE SET)
013444 100402          BMI          6$          ,GO TEST BAR
013446 104001          ERROR          ,ERROR! READY FLAG FAILED TO SET
013450 000420          BR          8$          ,GO TO EXIT
013452 005777 165574          6$      TST          @BAR          ,TEST THAT BAR BIT IS CLEAR
013456 001407          BEQ          7$          ,GO TO 7$ IF CLEAR
013460 017737 165566 001274          MOV          @BAR,RCV DAT
013466 005037 001276          CLR          XMTDAT
013472 104011          ERROR1          ,ERROR! BAR BIT FAILED TO CLEAR
013474 000406          BR          8$
013476 062737 000002 016412 7$      ADD          #2,@#LINE
013504 006337 001272          ASL          @#LINBIT
013510 103301          BCC          1$
013512 104006          SS          SCOPE
                                *****
013514 000074          RT74          74          ,ROUTINE # 74 *
013516 013702          RT75          RT75          ,ADDR OF NEXT ROUTINE *
013520 000012          10          ,ITERATION COUNT *
013522 013524          RT74A         RT74A         ,SCOPE ENTRY POINT *
                                X=X+1
                                *****
                                ,TEST THAT THE TUMBLE TABLE POINTER INCREMENTS PROPERLY AND
                                ,RETURNS TO THE BEGINNING AFTER 64 CHARACTERS HAVE BEEN RECEIVED
                                ,LINE 0 IS USED FOR THE TEST
013524 012701 001306          RT74A         MOV          #TUMTAB,%1      ,CLEAR THE
013530 012702 000100          MOV          #64,%2          TUMBLE TABLE
013534 005021          1$      CLR          (1)+
013536 005302          DEC          %2
013540 001375          BNE          1$
013542 012701 001306          MOV          #TUMTAB,%1
013546 012777 000004 165474          MOV          #BIT2,@CSR      ,SET MAINT BIT & CLEAR GO BIT
013554 005037 001276          CLR          XMTDAT
013560 005037 001274          CLR          RCV DAT
013564 012737 177677 001146          MOV          #-65,%CT      ,SET UP TO TRANSMIT 65 CHARACTERS
013572 052777 000001 165450          BIS          #BIT0,@CSR      ,SET THE GO BIT
013600 012777 000001 165444          MOV          #LBIT0,@BAR      ,TRANSMIT ON LINE 0
013606 105777 165436          2$      TSTB         @CSR          ,WAIT FOR CHAR DONE FLAG
013612 100375          BPL          2$
013614 042777 000200 165426          BIC          #BIT7,@CSR      ,CLEAR CHAR DONE FLAG
013622 005237 001274          INC          RCV DAT      ,INCREMENT CHARACTERS
013626 005237 001276          INC          XMTDAT      RECEIVED COUNT
    
```



```
013632 005711          TST      (1)          ,TEST TT ENTRY FOR VALID
013634 100402          BMI      35           ,DATA ENTRY
013636 104011          ERROR1                    ,ERROR! NO VALID DATA ENTRY
                                ,TYPEOUT SHOWS # OF CHARS RCVD WHEN ERROR OCCURED
013640 000417          BR       45           ,GO TO SCOPE
013642 005021          CLR      (1)+         ,CLEAR TT ENTRY
013644 023727 001276 000100 35      CMP      XMTDAT,#64    ,HAVE 64 CHARACTERS BEEN RECEIVED
013652 001355          BNE      25           ,
013654 005777 165370    TST      @CSR         ,WAIT FOR THE LAST CHARACTER
013660 100375          BPL      -4           ,TO BE TRANSMITTED
013662 105777 165362    TST@    @CSR         ,TEST FOR DONE
013666 100375          BPL      -4           ,
013670 005737 001306    TST      TUMTAB       ,TEST FIRST TT ENTRY
013674 100401          BMI      45           ,FOR VALID DATA
013676 104001          ERROR                    ,ERROR! POINTER DID NOT RETURN
013700 104006          45      SCOPE                    ,SCOPE
      000000
      000000
      ,*****
013702 000075          RT75     75           ,ROUTINE # 75 *
013704 013720          RT76                    ,ADDRESS OF NEXT TEST *
013706 000144          100                      ,ITERATION COUNT *
013710 013712          BRK0                    ,SCOPE ENTRY POINT *
      000075
      ,*****
013712 004537 005164    BRK0     JSR      5, BRKTST ,GO DO BPEAK TEST
013716 000001          LB10                    ,ON LINE 0
      000001
      ,*****
013720 000076          RT76     76           ,ROUTINE # 76 *
013722 013736          RT77                    ,ADDRESS OF NEXT TEST *
013724 000144          100                      ,ITERATION COUNT *
013726 013730          BRK1                    ,SCOPE ENTRY POINT *
      000076
      ,*****
013730 004537 005164    BRK1     JSR      5, BRKTST ,GO DO BREAK TEST
013734 000002          LB11                    ,ON LINE 1
      000002
      ,*****
013736 000077          RT77     77           ,ROUTINE # 77 *
013740 013754          RT100                   ,ADDRESS OF NEXT TEST *
013742 000144          100                      ,ITERATION COUNT *
013744 013746          BRK2                    ,SCOPE ENTRY POINT *
      000077
      ,*****
013746 004537 005164    BRK2     JSR      5, BRKTST ,GO DO BREAK TEST
013752 000004          LB12                    ,ON LINE 2
      000003
      ,*****
013754 000100          RT100    100          ,ROUTINE # 100 *
013756 013772          RT101                   ,ADDRESS OF NEXT TEST *
013760 000144          100                      ,ITERATION COUNT *
013762 013764          BRK3                    ,SCOPE ENTPY POINT *
```

```
000100          X=X+1
, *****
, BREAK TEST ON LINE 3
013764 004537 005164 BRK3 JSR 5, BRKTST , GO DO BREAK TEST
013770 000010          LBIT3 , ON LINE 3
          000004          Y=Y+1
, *****
013772 000101 RT101 101 , ROUTINE # 101 *
013774 014010          RT102 , ADDRESS OF NEXT TEST *
013776 000144          100 , ITERATION COUNT *
014000 014002 BRK4 , SCOPE ENTRY POINT *
          000101          X=X+1
, *****
, BREAK TEST ON LINE 4
014002 004537 005164 BRK4 JSR 5, BRKTST , GO DO BREAK TEST
014006 000020          LBIT4 , ON LINE 4
          000005          Y=Y+1
, *****
014010 000102 RT102 102 , ROUTINE # 102 *
014012 014026          RT103 , ADDRESS OF NEXT TEST *
014014 000144          100 , ITERATION COUNT *
014016 014020 BRK5 , SCOPE ENTRY POINT *
          000102          X=X+1
, *****
, BREAK TEST ON LINE 5
014020 004537 005164 BRK5 JSR 5, BRKTST , GO DO BREAK TEST
014024 000040          LBIT5 , ON LINE 5
          000006          Y=Y+1
, *****
014026 000103 RT103 103 , ROUTINE # 103 *
014030 014044          RT104 , ADDRESS OF NEXT TEST *
014032 000144          100 , ITERATION COUNT *
014034 014036 BRK6 , SCOPE ENTRY POINT *
          000103          X=X+1
, *****
, BREAK TEST ON LINE 6
014036 004537 005164 BRK6 JSR 5, BRKTST , GO DO BREAK TEST
014042 000100          LBIT6 , ON LINE 6
          000007          Y=Y+1
, *****
014044 000104 RT104 104 , ROUTINE # 104 *
014046 014062          RT105 , ADDRESS OF NEXT TEST *
014050 000144          100 , ITERATION COUNT *
014052 014054 BRK7 , SCOPE ENTRY POINT *
          000104          X=X+1
, *****
, BREAK TEST ON LINE 7
014054 004537 005164 BRK7 JSR 5, BRKTST , GO DO BREAK TEST
014060 000200          LBIT7 , ON LINE 7
          000010          Y=Y+1
, *****
014062 000105 RT105 105 , ROUTINE # 105 *
014064 014100          RT106 , ADDRESS OF NEXT TEST *
014066 000144          100 , ITERATION COUNT *
014070 014072 BRK10 , SCOPE ENTRY POINT *
          000105          X=X+1
```

```
*****  
BREAK TEST ON LINE 10  
014072 004537 005164 BRK10 JSR 5, BRKTST , GO DO BREAK TEST  
014076 000400 , ON LINE 10  
000011 Y=Y+1  
*****  
RT106 106 , ROUTINE # 106 *  
014100 000106 , ADDRESS OF NEXT TEST *  
014102 014116 RT107 *  
014104 000144 100 , ITERATION COUNT *  
014106 014110 BRK11 , SCOPE ENTRY POINT *  
000106 X=X+1  
*****  
BREAK TEST ON LINE 11  
014110 004537 005164 BRK11 JSR 5, BRKTST , GO DO BREAK TEST  
014114 001000 , ON LINE 11  
000012 Y=Y+1  
*****  
RT107 107 , ROUTINE # 107 *  
014116 000107 , ADDRESS OF NEXT TEST *  
014120 014134 RT110 *  
014122 000144 100 , ITERATION COUNT *  
014124 014126 BRK12 , SCOPE ENTRY POINT *  
000107 X=X+1  
*****  
BREAK TEST ON LINE 12  
014126 004537 005164 BRK12 JSR 5, BRKTST , GO DO BREAK TEST  
014132 002000 , ON LINE 12  
000013 Y=Y+1  
*****  
RT110 110 , ROUTINE # 110 *  
014134 000110 , ADDRESS OF NEXT TEST *  
014136 014152 RT111 *  
014140 000144 100 , ITERATION COUNT *  
014142 014144 BRK13 , SCOPE ENTRY POINT *  
000110 X=X+1  
*****  
BREAK TEST ON LINE 13  
014144 004537 005164 BRK13 JSR 5, BRKTST , GO DO BREAK TEST  
014150 004000 , ON LINE 13  
000014 Y=Y+1  
*****  
RT111 111 , ROUTINE # 111 *  
014152 000111 , ADDRESS OF NEXT TEST *  
014154 014170 RT112 *  
014156 000144 100 , ITERATION COUNT *  
014160 014162 BRK14 , SCOPE ENTRY POINT *  
000111 X=X+1  
*****  
BREAK TEST ON LINE 14  
014162 004537 005164 BRK14 JSR 5, BRKTST , GO DO BREAK TEST  
014166 010000 , ON LINE 14  
000015 Y=Y+1  
*****  
RT112 112 , ROUTINE # 112 *  
014170 000112 , ADDRESS OF NEXT TEST *  
014172 014206 RT113 *  
014174 000144 100 , ITERATION COUNT *  
014176 014200 BRK15 , SCOPE ENTRY POINT *  
000112 X=X+1  
*****
```

```
.BREAK TEST ON LINE 15
014200 004537 005164 BRK15 JSR 5, BRKTST .GO DO BREAK TEST
014204 020000 LBIT15 .ON LINE 15
000016 Y=Y+1
*****
014206 000113 RT113 113 .ROUTINE # 113 *
014210 014224 RT114 .ADDRESS OF NEXT TEST *
014212 000144 100 .ITERATION COUNT *
014214 014216 BRK16 .SCOPE ENTRY POINT *
000113 X=X+1
*****
.BREAK TEST ON LINE 16
014216 004537 005164 BRK16 JSR 5, BRKTST .GO DO BREAK TEST
014222 040000 LBIT16 .ON LINE 16
000017 Y=Y+1
*****
014224 000114 PT114 114 .ROUTINE # 114 *
014226 014242 PT115 .ADDRESS OF NEXT TEST *
014230 000144 100 .ITERATION COUNT *
014232 014234 BRK17 .SCOPE ENTRY POINT *
000114 X=Y+1
*****
.BREAK TEST ON LINE 17
014234 004537 005164 BRK17 JSR 5, BRKTST .GO DO BREAK TEST
014240 100000 LBIT17 .ON LINE 17
000020 Y=Y+1
000000 A=0
000000 Y=0
*****
014242 000115 PT115 115 .ROUTINE #115 *
014244 014260 PT116 .ADDRESS OF NEXT TEST *
014246 000144 100 .ITERATION COUNT *
014250 014252 DAT0 .SCOPE ENTRY POINT *
000115 X=X+1
*****
.DATA TEST 100 CHARACTERS LINE0
014252 004537 006020 DAT0 JSP 5, DATST .GO RUN DATA TEST
014256 030000 LINE0 .ON LINE0
000001 Y=Y+1
*****
014260 000116 PT116 116 .ROUTINE #116 *
014262 014276 RT117 .ADDRESS OF NEXT TEST *
014264 000144 100 .ITERATION COUNT *
014266 014270 DAT1 .SCOPE ENTRY POINT *
000116 X=X+1
*****
.DATA TEST 100 CHARACTERS LINE1
014270 004537 006020 DAT1 JSR 5, DATST .GO RUN DATA TEST
014274 000002 LINE1 .ON LINE1
000002 Y=Y+1
*****
014276 000117 PT117 117 .ROUTINE #117 *
014300 014314 RT120 .ADDRESS OF NEXT TEST *
014302 000144 100 .ITERATION COUNT *
014304 014306 DAT2 .SCOPE ENTRY POINT *
000117 X=Y+1
```

```
*****  
DATA TEST 100 CHARACTERS LINE2  
014306 004537 006020 DAT2 JSR 5,DATTST ,GO RUN DATA TEST  
014312 000004 LINE2 ,ON LINE2  
000003 Y=Y+1  
*****  
RT120 120 ,ROUTINE #120 *  
014314 000120 RT121 ,ADDRESS OF NEXT TEST *  
014316 014332 100 ,ITERATION COUNT *  
014320 000144 DAT3 ,SCOPE ENTRY POINT *  
014322 014324 X=X+1  
000120  
*****  
DATA TEST 100 CHARACTERS LINE3  
014324 004537 006020 DAT3 JSR 5,DATTST ,GO RUN DATA TEST  
014330 000006 LINE3 ,ON LINE3  
000004 Y=Y+1  
*****  
RT121 121 ,ROUTINE #121 *  
014332 000121 RT122 ,ADDRESS OF NEXT TEST *  
014334 014350 100 ,ITERATION COUNT *  
014336 000144 DAT ,SCOPE ENTRY POINT *  
014340 014342 X=>+1  
000121  
*****  
DATA TEST 100 CHARACTERS LINE4  
014342 004537 006020 DAT4 JSR 5,DATTST ,GO RUN DATA TEST  
014346 000010 LINE4 ,ON LINE4  
000005 Y=Y+1  
*****  
RT122 122 ,ROUTINE #122 *  
014350 000122 RT123 ,ADDRESS OF NEXT TEST *  
014352 014366 100 ,ITERATION COUNT *  
014354 000144 DAT5 ,SCOPE ENTRY POINT *  
014356 014360 X=X+1  
000122  
*****  
DATA TEST 100 CHARACTERS LINE5  
014360 004537 006020 DAT5 JSR 5,DATTST ,GO RUN DATA TEST  
014364 000012 LINES ,ON LINES  
000006 Y=Y+1  
*****  
RT123 123 ,ROUTINE #123 *  
014366 000123 RT124 ,ADDRESS OF NEXT TEST *  
014370 014404 100 ,ITERATION COUNT *  
014372 000144 DAT6 ,SCOPE ENTRY POINT *  
014374 014376 X=X+1  
000123  
*****  
DATA TEST 100 CHARACTERS LINE6  
014376 004537 006020 DAT6 JSR 5,DATTST ,GO RUN DATA TEST  
014402 000014 LINE6 ,ON LINE6  
000007 Y=Y+1  
*****  
RT124 124 ,ROUTINE #124 *  
014404 000124 RT125 ,ADDRESS OF NEXT TEST *  
014406 014422 100 ,ITERATION COUNT *  
014410 000144 DAT7 ,SCOPE ENTRY POINT *  
014412 014414 X=X+1  
000124  
*****
```

014414 004537 006020
014420 000016
000010

, DATA TEST 100 CHARACTERS LINE7
DAT7 JSR 5, DATTST , GO RUN DATA TEST
LINE7 , ON LINE7
Y=Y+1

014422 000125
014424 014440
014426 000144
014430 014432
000125

RT125 125 , ROUTINE #125 *
RT126 , ADDRESS OF NEXT TEST *
100 , ITERATION COUNT *
DAT10 , SCOPE ENTRY POINT *
X=X+1

014432 004537 006020
014436 000020
000011

, DATA TEST 100 CHARACTERS LINE10
DAT10 JSR 5, DATTST , GO RUN DATA TEST
LINE10 , ON LINE10
Y=Y+1

014440 000126
014442 014456
014444 000144
014446 014450
000126

RT126 126 , ROUTINE #126 *
RT127 , ADDRESS OF NEXT TEST *
100 , ITERATION COUNT *
DAT11 , SCOPE ENTRY POINT *
X=X+1

014450 004537 006020
014454 000022
000012

, DATA TEST 100 CHARACTERS LINE11
DAT11 JSR 5, DATTST , GO RUN DATA TEST
LINE11 , ON LINE11
Y=Y+1

014456 000127
014460 014474
014462 000144
014464 014466
000127

PT127 127 , ROUTINE #127 *
RT130 , ADDRESS OF NEXT TEST *
100 , ITERATION COUNT *
DAT12 , SCOPE ENTRY POINT *
X=X+1

014466 004537 006020
014472 000024
000013

, DATA TEST 100 CHARACTERS LINE12
DAT12 JSR 5, DATTST , GO RUN DATA TEST
LINE12 , ON LINE12
Y=Y+1

014474 000130
014476 014512
014500 000144
014502 014504
000130

RT130 130 , ROUTINE #130 *
RT131 , ADDRESS OF NEXT TEST *
100 , ITERATION COUNT *
DAT13 , SCOPE ENTRY POINT *
X=X+1

014504 004537 006020
014510 000026
000014

, DATA TEST 100 CHARACTERS LINE13
DAT13 JSR 5, DATTST , GO RUN DATA TEST
LINE13 , ON LINE13
Y=Y+1

014512 000131
014514 014530
014516 000144
014520 014522
000131

RT131 131 , ROUTINE #131 *
RT132 , ADDRESS OF NEXT TEST *
100 , ITERATION COUNT *
DAT14 , SCOPE ENTRY POINT *
X=X+1

DATA TEST 100 CHARACTERS LINE14

014522 004537 006020
014526 000030
000015

DAT14 JSR 5, DATTST ; GO RUN DATA TEST
LINE14 ; ON LINE14
Y=Y+1

014530 000132
014532 014546
014534 000144
014536 014540
000132

RT132 132 ; ROUTINE #132 *
RT133 ; ADDRESS OF NEXT TEST *
100 ; ITERATION COUNT *
DAT15 ; SCOPE ENTRY POINT *
X=X+1

014540 004537 006020
014544 000032
000016

; DATA TEST 100 CHARACTERS LINE15
DAT15 JSR 5, DATTST ; GO RUN DATA TEST
LINE15 ; ON LINE15
Y=Y+1

014546 000133
014550 014564
014552 000144
014554 014556
000133

RT133 133 ; ROUTINE #133 *
RT134 ; ADDRESS OF NEXT TEST *
100 ; ITERATION COUNT *
DAT16 ; SCOPE ENTRY POINT *
X=X+1

014556 004537 006020
014560 000034
000017

; DATA TEST 100 CHARACTERS LINE16
DAT16 JSR 5, DATTST ; GO RUN DATA TEST
LINE16 ; ON LINE16
Y=Y+1

014564 000134
014566 014602
014570 000144
014572 014574
000134

RT134 134 ; ROUTINE #134 *
RT135 ; ADDRESS OF NEXT TEST *
100 ; ITERATION COUNT *
DAT17 ; SCOPE ENTRY POINT *
X=X+1

014574 004537 006020
014600 000036
000020

; DATA TEST 100 CHARACTERS LINE17
DAT17 JSR 5, DATTST ; GO RUN DATA TEST
LINE17 ; ON LINE17
Y=Y+1

014602 000135
014604 015202
014606 000144
014610 014612
000135

RT135 135 ; ROUTINE # 135 *
RT136 ; ADDR OF NEXT ROUTINE *
100 ; ITERATION COUNT *
RT135A ; SCOPE ENTRY POINT *
X=X+1

; TEST THAT DATA (ALL 1'S) CAN BE TRANSMITTED ON LINES SIMULTANEOUSLY
; THE FOLLOWING TESTS ARE PERFORMED
; THERE ARE 16 DATA ENTRIES
; THERE ISN'T A 17TH ENTRY
; DATA RECEIVED IS CORRECT
; ONE DATA ENTRY PER LINE

014612 005037 001306
014616 004537 005732
014622 001306
014624 001307
014626 000177

RT135A CLR TUMTAB ; CLEAR THE
JSR 5, BMOVE ; TUMBLE
TUMTAB ; TABLE
TUMTAB+1 ; (200
177 ; ENTRIES)

```

014630 012737 177777 016564      MOV    #-1,OUTBUF      ,LOAD CHAR INTO OUTPUT BUFFER
014636 005000                    CLR    %0              ,SET RO = LINE 0
014640 012737 000001 001272      MOV    #LBIT0,LINBIT-  ,GET LINE BIT
014646 012777 000001 164374      MOV    #BIT0,@CSR      ,SET THE GO BIT
014654 010037 016412          15    MOV    %0,LINE         ,GET LINE NUMBER
014660 004537 005754          JSR    5,XMITD         ,TRANSMIT 1 CHAR
014664 177777                    -1                    ,ON EACH LINE
014666 005720                    TST    (0)+           ,INCREMENT LINE NUMBER (+2)
014670 006337 001272          ASL    LINBIT         ,SHIFT LINE BIT TO NEXT LINE
014674 103367                    BCC    1$            ,BRANCH IF ALL L NES NOT DONE
014676 013737 004074 014706      MOV    TIME1,2$      ,PUT TIME TO TRANSM T 1 CHAR
014704 104400                    DELAY                ,DELAY 1
014706 000000          25    OPEN                ,CHARACTER TIME
014710 017737 164336 001274      MOV    @BAR,RCVDAT   ,GET & TEST BAR CONTENTS
014716 001410                    BEQ    3$            ,BRANCH IF 0
014720 005037 001276          CLR    XMTDAT
014724 104011                    ERROR1                ,ERROR! BAR NOT CLEAR AFTER ALL
014726 005077 164320          CLR    @BAR          ,LINES FINISHED
014732 005077 164312          CLR    @CSR
014736 000520                    BR     16$           ,GO TO EXIT
014740 032777 020000 164302  35    BIT    #BIT13,@CSR   ,TEST THAT OVER RUN DID NOT SET
014746 001404                    BEQ    4$            ,BRANCH IF 0
014750 104001                    ERROR                ,ERROR! OVER RUN BIT SET
014752 005077 164272          CLR    @CSR
014756 000510                    BR     16$           ,GO TO EXIT

,TEST THAT THERE ARE 16 VALID DATA ENTRIES
014760 005077 164264          4$    CLR    @CSR        ,CLEAR THE CSR
014764 012702 000020          MOV    #16,%2        ,GET TT SCAN COUNT
014770 012701 001306          MOV    #TUMTAB,%1    ,GET FIRST TT ADDRESS
014774 005302          5$    DEC    %2          ,DECREMENT SCAN COUNTER
014776 100404                    BMI    6$            ,BRANCH IF 16 ENTRIES SCANNED
015000 005721                    TST    (1)+         ,TEST FOR VALID DATA ENTRY
015002 100774                    BMI    5$            ,BRANCH IF FOUND
015004 104001                    ERROR                ,ERROR! MISING DATA ENTRY
015006 000474                    BR     16$           ,GO TO EXIT
015010 005721          6$    TST    (1)+         ,TEST 17TH ENTRY (SHOULD BE - TO 0)
015012 001402                    BEQ    7$            ,BRANCH IF 0
015014 104001                    ERROR                ,ERROR! EXTRA DATA ENTRY
015016 000470                    BR     16$           ,GO TO EXIT

,TEST THAT THE DATA IS CORRECT IN ALL 16 ENTRIES
015020 012701 001306          7$    MOV    #TUMTAB,%1    ,GET FIST TT ADDRESS
015024 012702 000020          MOV    #16,%2        ,GET SCAN COUNT
015030 005302          8$    DEC    %2          ,DECREMENT SCAN COUNT
015032 100421                    BMI    10$           ,BRANCH IF 16 ENTRIES SCANNED
015034 013737 016564 001276      MOV    OUTBUF,XMTDAT ,GET TRANSMITTED DATA
015042 043737 001300 001276      BIC    CARMSK,XMTDAT ,CLEAR NON-TRANSMITTED BITS
015050 113737 001306 001274      MOVB   TUMTAB,RCVDAT ,GET RECEIVED DATA
015056 123737 001276 001274      CMPB   XMTDAT,RCVDAT ,COMPARE DATA
015064 001402                    BEQ    9$            ,BRANCH IF 0
015066 104011                    ERROR1                ,ERROR INCORRECT DATA
015070 000443                    BR     16$           ,GO TO EXIT
015072 005721          9$    TST    (1)+         ,INCREMENT TT ADDRESS
015074 000755                    BR     8$            ,TEST NEXT ENTRY

```



```
. CLEAR ALL BUT LINE NUMBER IN TUMBLE TABLE ENTRY
015076 012701 001306 105 MOV #TUMTAB,%1 ; GET FIRST TT ADDRESS
015102 012702 000020 MOV #16,%2 ; GET SCAN COUNT
015106 005302 115 DEC %2 ; DECREMENT SCAN COUNT
015110 100403 BMI 125 ; BRANCH IF ALL LINES TESTED
015112 042721 160777 RIC #160777.(1)+ ; CLEAR ALL BUT LINE NUMBER IN TT
015116 000773 BR 115 ; DO NEXT TT ADDRESS

. TEST THAT THERE IS AN ENTRY FOR EACH OF THE 16 LINES
015120 005037 001276 125 CLR XMTDAT
015124 012701 000020 MOV #16,%1
015130 012702 000020 135 MOV #16,%2
015134 012700 001306 MOV #TUMTAB,%0
015140 023720 001276 145 CMP XMTDAT,(0)+ ; TEST FOR LINE ENTRY
015144 001406 BEQ 155 ; BRANCH IF FOUND
015146 005302 DEC %2 ; DECREMENT SCAN COUNT
015150 001373 BNE 145 ; LOOK AT NEXT ENTRY
015152 005037 001274 CLR RCVDAT
015156 104011 ERROR1 ; ERROR! NO ENTRY FOUND FOR THIS LINE
015160 000407 BR 165 ; GO TO EXIT
015162 005301 155 DEC %1 ; DECREMENT LINES FOUND COUNT
015164 005701 TST %1
015166 001404 BEQ 165 ; BRANCH IF ALL LINES TESTED
015170 062737 001000 001276 ADD #1000,XMTDAT ; INCREMENT LINE NUMBER
015176 000754 BR 135 ; GO DO NEXT LINE
015200 104006 165 SCOPE ; SCOPE
*****
PT136 136 ; ROUTINE # 136 *
RT137 ; ADDR OF NEXT ROUTINE *
100 ; ITERATION COUNT *
RT136A ; SCOPE ENTRY POINT *
X=X+1
*****

. TEST THAT THE DM11 CAN TRANSMIT A BREAK ON ALL LINES SIMULTANEOUSLY
015212 013737 004074 015266 RT136A MOV @TIME1,15 ; GET TIME TO TRANSMIT ONE CHARACTER
015220 005037 001306 CLR TUMTAB ; CLEAR
015224 004537 005732 JSR 5,BMOVE ; THE
015230 001306 TUMTAB ; TUMBLE
015232 001307 TUMTAB+1 ; TABLE
015234 000177 177
015236 012777 000001 164024 MOV #BIT0,@CSR ; SET GO
015244 012777 177777 164002 MOV #-1,@BKCSR ; SET BREAK BIT FOR ALL LINES
015252 105777 163772 TSTB @CSR ; WAIT FOR THE RECEIVER
015256 100375 BPL -4 ; TO RECEIVE A BREAK
015260 005077 163770 CLR @BKCSR ; CLEAR ALL BREAK BITS
015264 104400 DELAY ; WAIT ONE CHARACTER
015266 000000 15 OPEN ; TIME
015270 022777 000201 163752 CMP #201,@CSR ; TEST THAT ONLY GO AND DONE ARE SET
015276 001410 BEQ 25
015300 017737 163744 001274 MOV @CSP,RCVDAT ; GET CSR ENTRY
015306 012737 000201 001276 MOV #201,XMTDAT ; GET CORRECT RESULT
015314 104011 ERROR1 ; ERROR! INCORRECT CSP DATA
015316 000476 BR 135 ; EXIT
```

TEST THAT THERE IS 16 VALID DATA ENTRIES

```
015320 012701 001306 25 MOV #TUMTAB,%1 .GET TUMBLE TABLE BASE ADDRESS
015324 012702 000020 MOV #16,%2 .GET SCAN COUNT
015330 005721 35 TST (1)+ .TEST FOR VALID DATA ENTRY
015332 100402 BM 45 .BRANCH IF VALID DATA ENTRY FOUND
015334 104001 ERROR .ERROR! MISSING VALID DATA ENTRY
015336 000466 BR 135 .EXIT
015340 005302 45 DEC %2 .DECREMENT SCAN COUNT
015342 001372 BNE 35 .BRANCH IF 16 ENTRIES NOT SCANNED
```

TEST THAT THE BREAK BIT IS SET IN 16 TUMBLE TABLE ENTRIES

```
015344 012701 001306 MOV #TUMTAB,%1
015350 012702 000020 MOV #16,%2
015354 032721 040000 55 B T #BIT14,(1)+ .BREAK BIT SET?
015360 001002 BNE 65 .BRANCH IF SET
015362 104001 ERROR .ERROR! MISSING BREAK BIT
015364 000453 BR 135 .EXIT
015366 005302 65 DEC %2 .DECREMENT SCAN COUNT
015370 001371 BNE 55
```

TEST THAT THE TUMBLE TABLE DATA BYTE IS ALL 0'S

```
015372 012701 001306 MOV #TUMTAB,%1
015376 012702 000020 MOV #16,%2
015402 105721 75 TSTB (1)+ .TEST DATA BYTE
015404 001402 BEQ 85 .BRANCH IF 0'S
015406 104001 ERROR .ERROR! INCORRECT DATA
015410 000441 BR 135 .EXIT
015412 105721 55 TSTB (1)+ .STEP TABLE POINTER TO NEXT DATA BYTE
015414 005302 DEC %2
015416 001371 BNE 75
```

CLEAR ALL BUT LINE NUMBER IN TUMBLE TABLE ENTRY

```
015420 012701 001306 MOV #TUMTAB,%1
015424 012702 000020 MOV #16,%2
015430 042721 160777 95 BIC #160777,(1)+ .CLEAR ALL BUT LINE NUMBER
015434 005302 DEC %2
015436 001374 BNE 95
```

TEST THAT THERE IS A TUMBLE TABLE ENTRY FOR EACH LINE

```
015440 005004 CLR %4 .CLEAR LINE NUMBER
015442 012703 000020 MOV #16,%3
015446 012702 000020 105 MOV #16,%2
015452 012701 001306 MOV #TUMTAB,%1
015456 020421 115 CMP %4,(1)+ .TEST FOR LINE ENTRY FOR THIS LINE
015460 001410 BEQ 125 .BRANCH IF FOUND
015462 005302 DEC %2
015464 001374 BNE 115
015466 010437 001276 MOV %4,XMTDAT
015472 010437 001274 MOV %4,RCVDAT
015476 104011 ERROR1 .ERROR! NO LINE ENTP. FOUND FOR THIS LINE
015500 000405 BR 135 .EXIT
015502 005303 125 DEC %3 .ALL LINES BEEN FOUND
015504 001403 BEQ 135 .EXIT IF YES
015506 062704 001000 ADD #1000,%4 .SEARCH FOR
015512 000755 BR 105 .NEXT LINE
015514 104006 135 SCOPE .SCOPE
```

015516 000137 RT137 137 ,ROUTINE # 137 *
015520 015534 RT140 ,ADDR OF NEXT ROUT NE *
015522 000002 2 ,ITERATION COUNT *
015524 015526 RT137A ,SCOPE ENTRY POINT *
000137 X=X+1

,TEST TO TRANSMIT ON EACH LINE WITH A DELAY BEFORE STAT NG THE
,NEXT LINE

015526 004537 005310 RT137A JSR 5, @#DLYXMT ,GO DO TEST DELAY *
015532 000040 32 ,THIS MUCH BETWEEN L NES *

015534 000140 RT140 140 ,ROUTINE # 140 *
015536 015552 RT141 ,ADDR OF NEXT ROUTINE *
015540 000002 2 ,ITERATION COUNT *
015542 015544 RT140A ,SCOPE ENTRY POINT *
000140 X=X+1

,TEST TO TPANSMIT ON EACH LINE WITH A DELAY BEFORE STAT NG THE
,NEXT LINE

015544 004537 005310 RT140A JSP 5, @#DLYXMT ,GO DO TEST DELAY *
015550 000020 16 ,THIS MUCH BETWEEN LINES *

015552 000141 RT141 141 ,ROUTINE # 141 *
015554 015570 RT142 ,ADDR OF NEXT ROUTINE *
015556 000002 2 ,ITERATION COUNT *
015560 015562 RT141A ,SCOPE ENTRY POINT *
000141 X=X+1

,TEST TO TRANSMIT ON EACH LINE WITH A DELAY BEFORE STATING THE
,NEXT LINE

015562 004537 005310 RT141A JSR 5, @#DLYXMT ,GO DO TEST DELAY *
015566 000010 8 ,THIS MUCH BETWEEN LINES *

015570 000142 RT142 142 ,ROUTINE # 142 *
015572 015606 RT143 ,ADDR OF NEXT ROUTINE *
J15574 000002 2 ,ITERATION COUNT *
015576 015600 RT142A ,SCOPE ENTRY POINT *
000142 X=X+1

,TEST TO TRANSMIT ON EACH LINE WITH A DELAY BEFOPE STATING THE
,NEXT LINE

015600 004537 005310 RT142A JSR 5, @#DLYXMT ,GO DO TEST DELAY *
015604 000004 4 ,THIS MUCH BETWEEN LINES *

015606 000143 RT143 143 ,ROUTINE # 143 *
015610 015624 RT144 ,ADDR OF NEXT ROUTINE *
015612 000002 2 ,ITERATION COUNT *
015614 015616 RT143A ,SCOPE ENTRY POINT *
000143 X=X+1

,TEST TO TRANSMIT ON EACH LINE WITH A DELAY BEFOPE STATING THE

```
.NEXT LINE
015616 004537 005310 RT143A JSR 5,@DLYXMT ,GO DO TEST DELAY
015622 000002 2 ,THIS MUCH BETWEEN L NES
.*****
015624 000144 RT144 144 ,ROUTINE # 144 *
015626 015642 RT145 ,ADDR OF NEXT ROUTINE *
015630 000002 2 ,ITERATION COUNT *
015632 015634 RT144A ,SCOPE ENTRY POINT *
000144 X=X+1
.*****

.TEST TO TRANSMIT ON EACH LINE WITH A DELAY BEFORE STATING THE
.NEXT LINE
015634 004537 005310 RT144A JSR 5,@DLYXMT ,GO DO TEST DELAY
015640 000001 1 ,THIS MUCH BETWEEN LINES
.*****
015642 000145 RT145 145 ,ROUTINE # 145 *
015644 016010 RT146 ,ADDR OF NEXT ROUTINE *
015646 000144 100 ,ITERATION COUNT *
015650 015652 RT145A ,SCOPE ENTRY POINT *
000145 X=X+1
.*****

.TEST THAT THE DM11 WORKS PROPERLY WHEN THE HALF-DUPLEX B T (CSR B T 1)
.IS SET THE TEST TRANSMITS DATA ON LINE 0, AND 'BREAKS' ON LINE 1 ONLY
.THE BREAK SHOULD BE RECEIVED ON LINE 0 IN THE TUMBLE TABLE
015652 005037 001306 PT145A CLR TUMTAB ,CLEAR THE FIRST TWO
015656 005037 001310 CLR TUMTAB+2 ,TUMBLE TABLE ENTRIES
015662 012737 016564 001106 MOV #OUTBUF,CAT ,SET UP TO
015670 012737 177777 001146 MOV #-1,WCT ,TRANSMIT 1 CHARACTER
015676 012777 000007 163344 MOV #7,@CSR ,SET GO, HALF DUPLEX & MAINT BITS
015704 012777 000001 163340 MOV #LBIT0,@BAR ,TRANSMIT 1 CHAP ON LINE 0
015712 012777 000002 163334 MOV #LBIT1,@BKCSR ,SET BREAK ON LINE 1
015720 105777 163324 TSTB @CSR ,WAIT FOR THE CHARACTER
015724 100375 BPL -4 ,TO BE RECEIVED
015726 005077 163322 CLR @BKCSR ,CLEAR THE BREAK BIT ON LINE 1

.TEST THAT ONLY THE BREAK WAS RECEIVED
015732 022737 141000 001306 CMP #141000,TUMTAB ,TDST FOR BREAK ENTRY (LINE 1)
015740 001410 BEQ 15
015742 013737 001306 001274 MOV TUMTAB,RCV DAT ,GET ACTUAL ENTRY
015750 012737 141000 001276 MOV #141000,XMTDAT ,GET CORRECT ENTRY
015756 104011 ERROR1 ,ERROR! INCORRECT BREAK ENTRY
015760 000407 BP 25 ,GO TO EXIT
015762 013737 001310 001274 15 MOV TUMTAB+2,RCV DAT ,TEST THAT NEXT ENTRY IS CLEAR
015770 001403 BEQ 25 ,EXIT IF CORRECT
015772 005037 001276 CLP XMTDAT
015776 104011 ERROR1 ,ERROR! SECOND ENTRY WAS NOT CLEAR
016000 005777 163244 25 TST @CSR ,WAIT FOR THE TRANSMITTER
016004 100375 BPL -4 ,TO FINISH
016006 104006 SCOPE ,SCOPE
.*****
016010 000146 PT146 146 ,ROUTINE # 146 *
016012 177777 PTLAST ,ADDR OF NEXT ROUTINE *
016014 000144 100 ,ITERATION COUNT *
016016 016020 PT146A ,SCOPE ENTRY POINT *
```

000146

X=X+1

, TEST THAT THE DM11 RESPONDS CORRECTLY TO A RESET

016020	012737	016564	001106	RT146A	MOV	#OUTBUF,CAT	, SET UP TO TRANSMIT 10
016026	012737	177770	001146		MOV	#-10,WCT	, CHARACTERS ON LINE 0
016034	013737	004074	016104		MOV	TIME1,2%	, GET TIME TO TRANSMIT 2 CHARACTERS
016042	013737	004074	016150		MOV	TIME1,6%	
016050	005037	001276			CLR	XMTDAT	
016054	012777	000007	163166		MOV	#7,@CSR	, SET MAINT , HALF DUPLEX & GO BITS
016062	012777	000001	163162		MOV	#LBIT0,@BAR	, START TO TRANSMIT ON LINE 0
016070	012777	000002	163156		MOV	#LBIT1,@BKCSR	, BREAK ON LINE 1
016076	012704	000002			MOV	#2,%4	
016102	104400			1%	DELAY		, WAIT 2 CHARACTER
016104	000000			2%	OPEN		, T MES
016106	005304				DEC	%4	
016110	001374				BNE	1%	
016112	104005				SRESET		, RESET
016114	017737	163130	001274		MOV	@CSR,RCV DAT	, GET CSR CONTENTS
016122	001401				BEQ	3%	, BRANCH IF 0
016124	104011				ERROR1		, ERROR! CSR DID NOT CLEAR
016126	017737	163120	001274	3%	MOV	@BAR,RCV DAT	, GET BAR CONTENTS
016134	001402				BEQ	4%	, BRANCH IF 0
016136	104011				ERROR1		, ERROR! BAR IS NOT CLEAR
016140	000427				BR	9%	, EXIT
016142	012704	000010		4%	MOV	#8,%4	
016146	104400			5%	DELAY		WAIT 8 MORE CHARACTER TIMES
016150	000000			6%	OPEN		
016152	005304				DEC	%4	
016154	001374				BNE	5%	
016156	017737	163066	001274		MOV	@CSR,RCV DAT	, TEST THAT CSR IS CLEAR
016164	001402				BEQ	7%	
016166	104011				ERROR1		, ERROR! CSR WAS NOT CLEAR
016170	000413				BR	9%	, GO TO EXIT
016172	017737	163054	001274	7%	MOV	@BAR,RCV DAT	, TEST THAT BAR IS CLEAR
016200	001402				BEQ	8%	
016202	104011				ERROR1		, ERROR! BAR DID NOT CLEAR
016204	000405				BR	9%	
016206	017737	163042	001274	8%	MOV	@BKCSR,RCV DAT	, TEST THAT BKCSR IS CLEAR
016214	001401				BEQ	9%	
016216	104011				ERROR1		, ERROR! BKCSR DID NOT CLEAR
016220	104006			9%	SCOPE		SCOPE

```
016222 104000  
016222 017543  
016224 004737 016402  
016226 004737 016454  
016232 005777 163010  
016236 001375  
016242 005077 163000  
016244 005037 016264  
016250 117737 162623 016264  
016254 104400  
016262 000000  
016264 000761
```

,PRG1- TRANSMITTER SCOPE LOOP
PRG1
TYPE
PRG1M
JSR 7,PARAM
JSR 7,LOOP
TST @BAR
BNE PRG1B
CLR @CSR
CLR PRG1D
MOVB @SWR+1,PRG1D
DELAY
OPEN
BP PRG1P

,BEGIN
,TYPE PROGRAM T TLE
,GO GET USER PARAMETERS
,GO LOOP TRANSMITTER
,WAIT FOR ALL LINES TO FIN SH
,BRANCH IF NOT DONE
,CLEAR THE CSR
,CLEAR DELAY TIME
,GET DELAY
,DELAY AS SPEC FIED
,BY USER
,LOOP BACK

```

,PRG2- RECEIVER SCOPE LOOP
PRG2
016270                                ,BEGIN
016270 104000                          ,TYPE PROGRAM
016272 017561                          ,TITLE
016274 004737 016402                    ,GO GET USER PARAMETERS
016300 004737 016454                    ,GO START TRANSMITTER
016304 012777 000001 162736 PRG2R JSR 7,PARAM ,SET GO,CLEAR THE OTHERS
016312 005777 162734 PRG2A MOV #BIT0,@CSR ,HAVE ALL LINES SELECTED F N SHED
016316 001415 PRG2AA TST @BAR ,BRANCH IF FINISHED TRANSMITTING
016320 105777 162724 BEQ PRG2B ,WAIT FOR THE RECE VER TO
016324 100372 TST@ @CSR ,RECEIVE A CHARACTER
016326 042777 000200 162714 BPL PRG2AA ,CLEAR RECEIVER FLAG
016334 020127 001504 BIC #BIT7,@CSR ,IS THE POINTER AT THE END OF THE TT
016340 001002 CMP %1,#TUMTAB+176 ,BRANCH IF NOT
016342 012701 001304 BNE +6 ,RESET POINTER
016346 005721 MOV #TUMTAB-2,%1 ,INCREMENT POINTER
016350 000755 BR PRG2A ,GO BACK & TEST TRANSMITTER FLAG
016352 005077 162672 PRG2B CLR @CSR ,CLEAR THE CSR
016356 005077 162670 CLR @BAR ,CLEAR THE BAR
016362 005037 016376 CLR PFG2C ,CLEAR USER DELAY
016366 117737 162511 016376 MOV@ @SWR+1,PRG2C ,LOAD USER DELAY
016374 104400 DELAY ,DELAY AS SPECIFIED
016376 000000 PRG2C OPEN ,BY USER
016400 000737 BR PRG2R REPEAT LOOP
    
```

```

, SUBROUTINE TO GET USER PARAMETERS (FOR PRG1 & 2)
PARPAM TYPE
016402 104000 ,ASK USER WHICH LINE
016404 017600 LINPAR ,TO TEST
016406 004537 004124 JSR 5,PECC ,GET LINE AND PUT IT
016412 000000 LINE 0 HERE
016414 104000 PARPAMA TYPE ,ASK USER HOW MANY
016416 017623 HOWMAN ,CHARACTERS TO TRANSMIT
016420 004537 004124 JSR 5,PECC ,GET CHARS AND PUT IT
016424 000000 CHAPS 0 HERE
016426 023727 016424 000010 CMP CHAPS,#200 ,LIMIT RESPONSE TO 200
016434 101403 BLOS PARPAMB (CORE LIMITATION)
016436 104000 TYPE
016440 017444 M1
016442 000764 BR PARPAMA RE-REQUEST PARAMETER
016444 104000 PARPAMB TYPE TYPE INSTRUCTIONS
016446 017467 M4
016450 104015 CNTLU ,GO GET VALUE
016452 000207 RTS ,EXIT
    
```

```

SUBROUTINE TO TRANSMIT DATA FROM THE SP
LOCP MOV@ @SWR OUTBUF ,FILL OUTPUT
016454 117737 162422 016564 JSR 5,BMOVE ,BUFFER
016462 004537 005732 OUTBUF ,WITH
016466 016564 OUTBUF+1 ,DATA TO BE
016470 016565 199 ,TRANSMITTED
016472 000307 MOV #CAT,@BASPEG ,INITIALIZE BASE REGISTER
016474 012777 001106 162554 MOV #OUTBUF,CAT ,LOAD CURRENT
016502 012737 016564 001106 JSR 5,BMOVE ,ADDRESS TABLE
016510 004537 005732
    
```

```

016514 001106          CAT          , WITH ADDRESS
016516 001110          CAT+2        , OF OUTPUT BUFFER
016520 000040          32
016522 013737 016424 001146  MOV      CHARS, WCT    , LOAD WORD COUNT
016530 005437 001146          NEG      WCT          , FORM TWO'S COMPLEMENT
016534 004537 005732          JSR      5, BMOVE     , TABLE WITH
016540 001146          WCT          , NUMBER OF
016542 001150          WCT+2        , CHARACTERS TO BE
016544 000040          32          , TRANSMITTED
016546 013737 016412 001272  MOV      LINE, LINBIT , SAVE LINES TO BE TRANSMITTED ON
016554 013777 016412 162470  MOV      LINE, DBAR   , START TRANSMITTING ON SELECTED LINES
016562 000207          PTS          , EXIT
    
```

```

016564 000000          OUTBUF 0          , FIRST ADDRESS OF 100
          016730          =OUTBUF+100    , CHARACTER OUTPUT BUFFER
016770 000000          INBUF  0          , FIRST ADDRESS OF 100
          017074          =INBUF+100    , CHARACTER INPUT BUFFER (WHERE RECEIVED
          , DATA IS STORED)
    
```

```

017074 013746 000006          SUSWPP MOV      @*6, -(SP)    , SAVE VECTORS
017100 013746 000004          MOV      @*4, -(SP)
017104 012737 017124 000004  MOV      #15, @*4    , SET UP FOR TIMEOUT
017112 022777 177777 161762  CMP      #-1, @SWR   , REFERENCE HARDWARE SWITCH REGISTER
017120 001402          BEQ      25
017122 000407          BF      35
017124 022626          15      CMP      (SP)+, (SP)+ , ADJUST STACK
017126 012737 000176 001102  25      MOV      #SWREG, SWR , POINT TO SOFTWARE SWITCH REGISTER
017134 012737 000174 001104  MOV      #DISPREG, DISPLAY , POINT TO SOFTWARE DISPLAY REGISTER
017142 012637 000004          35      MOV      (SP)+, @*4    , RESTORE VECTORS
017146 012637 000006          MOV      (SP)+, @*6
017152 000002          RTI
    
```

.ROUTINE TO CHECK FOR G BEING TYPED

```

017154 022737 000176 001102  ABDINTT CMP      #SWREG, SWR
017162 001021          BNE      15
017164 023737 000042 000046  CMP      @*42, @*46  ACT11?
017172 001415          BEQ      15          BR IF YES
017174 005037 017266          CLR      TMP1        , CLEAR TEMP AREA
017200 117737 162372 017266  MOV      @*4DBR, TMP1 , FETCH THE BUFFER
017206 142737 000200 017266  BICB    #200, TMP1   , STRIP OFF PARITY
017214 122737 000007 017266  CMPB    #7, TMP1    , WAS IT G
017222 001001          BNE      15          NOP
017224 104015          CNTLU
017226 000002          15      RTI          , GO CHANGE T
          , EXIT
    
```

.ROUTINE TO CHANGE CONTENTS OF SWREG LOC 1761

```

017230 022737 000176 001102  CNTLUU  CMP      #SWREG, SWR
017236 001023          BNE      FX
017240 104000          TYPE
017242 017323          $SWREG
017244 004537 005662          JSP      P5, QACNV , CONVERT TO ASCII
    
```


017250	000176				SWREG				
017252	017331				SVALUE				
017254	000006				6				
017256	104000				TYPE				
017260	017331				SVALUE				
017262	004537	004124			JSR	S, RECD			.GET TMP1 AND PUT IT
017266	000000		TMP1		D				.HERE
017270	022737	000007	004302		CMP	#7, CNT			
017276	001403				BEQ	FJX			
017300	013777	017266	161574		MOV	TMP1, @SWP			.CHANGE CONTENTS OF SWPEG
017306	000002		FJX		PT				

				, MESSAGES	
017310	053045	041505	020124	WHERE	ASCII '%VECT ADR?'
017316	042101	037522	100		
017323	045	053523	036522	SSWREG	ASCII '%SWR=?'
017330	100				
017331	040	020040	020040	SVALUE	ASCII ' NEW=?'
017336	020040	020040	047040		
017344	053505	040075			
017350	036445			SCTLU	ASCII '%='
017352	052445	044516	021524	WHICH	ASCII '%UNIT#(8)?'
017360	034050	037451	100		
017365	045	044103	051101	LEVEL	ASCII '%CHAR LENGTH'
017372	046040	043516	044124		
017400	100				
017401	045	051105	020122	ERDAT	ASCII '%EPP S'B'
017406	027523	035102	040		
017413	040	020040	020040	AASB	ASCII ' WAS'
017420	020040	040527	035123		
017426	040				
017427	040	020040	020040	AWAS	ASCII ' ?'
017434	040040				
017436	050045	043522	040043	M0	ASCII '%PRG#?'
017444	037445	100		M1	ASCII '%?'
017447	045	047105	040104	M2	ASCII '%END?'
017454	051445	036522	037460	M3	ASCII '%SP=0? GO ?'
017462	043440	027117	100		
017467	045	042114	041440	M4	ASCII '%LD CHAR IN SPO-7, DLY IN SPS-15?'
017474	040510	020122	047111		
017502	051440	030122	033455		
017510	042073	054514	044440		
017516	020116	051123	026470		
017524	032461	100			
017527	045	047514	044507	PRGOM	ASCII '%LOGIC TSTS?'
017534	020103	051524	051524		
017542	100				
017543	045	046530	052111	PRGIM	ASCII '%XMITTER LOOP?'
017550	042524	020122	047514		
017556	050117	100			
017561	045	046530	052111	PRG2M	ASCII '%XMITTER LOOP?'
017566	051057	041505	046040		
017574	047517	040120			
017600	052045	050131	046040	LINPAR	ASCII '%TYP LINES TO TEST?'
017606	047111	051505	052040		
017614	020117	051524	020124		
017622	100				
017623	045	047443	020106	HOWMAN	ASCII '%#OF CHARS?'
017630	044103	051101	037523		
017636	100				
017637	045	020122		EMO	ASCII '%P'
017642	020040	050040	036503	ATNUMB	ASCII '% PC='
017650	020040	020040	020040	APC	ASCII ' ?'
017656	100				
017657	015	012		MSG1	BYTE 15, 12
017661	124	042510	050440		
017666	044525	045503	041040		
017674	047522	047127	043040		

'THE QUICK BROWN FOX JUMPED OVER THE LAZY DOGS BACK 1234567890'

017702	054117	045040	046525
017710	042520	020104	053117
017716	051105	052040	042510
017724	046040	055101	020131
017732	047504	051507	041040
017740	041501	020113	031061
017746	032063	033065	034067
017754	030071		
	000001		

END

A = 000000	CAT = 001106	ERROR = 104001	L NE12= 000024	PAR5 = 006546
AASB 017413	CC = 177776	ERROR1= 104011	L NE13= 000026	PAR6 = 006550
APC 017650	CHALT = 104003	ERRVEC= 000004	L NE14= 000030	PASS = 001624
APCADD 001610	CHARS 016424	ERR1 = 001672	LINE15= 000032	PCADD = 001606
APER 013234	CLKINT 001260	ESCOPE 002406	L NE16= 000034	PFAIL = 004304
ATNUMB 017642	CLKLVL 001262	FJX 017306	LINE17= 000036	POPSP = 005726
AHAS 017427	CNT 004302	FORWD 002554	L NE2 = 000004	POPSP2= 022626
A12K 013254	CNTLU = 104015	FORWDA 002600	L NE3 = 000006	PRGLIM = 001522
A16K 013260	CNTLUU 017230	GETRDY 002306	LINE4 = 000010	PRGNUM = 002162
A20K 013264	CNV DAT 002040	GTBIN 005612	LINE5 = 000012	PRGTAB = 001524
A24K 013270	COUNT 001604	GTLINB 006552	LINE6 = 000014	PRGO = 006604
A2SK 013274	CSR 001250	GTRDYA 002324	LINE7 = 000016	PRGOM = 017527
ABF 013244	CURTST 001510	GTRDYC 002346	LINPAR 017600	PRGOR = 006626
BAR 001252	DATCHK= 104002	GTRDYD 002370	LOGP 016454	PRG1 = 016222
BASREG 001256	DATTST 006020	GTRDYX 002314	LTST0 011162	PRG1B = 016236
BAT 001206	DATO 014252	HOWMAN 017623	LTST1 011200	PRG1C = 016244
BELL = 000007	DAT1 014270	ICTR 001516	LTST10 011342	PRG1D = 016264
BIT0 = 000001	DAT1AA 006024	INBIN 005562	LTST11 011360	PRG1M = 017543
BIT1 = 000002	DAT10 014432	INBUF 016730	LTST12 011376	PRG1R = 016232
BIT10 = 002000	DAT11 014450	INCR TN 001626	LTST13 011414	PRG2 = 016270
BIT11 = 004000	DAT12 014466	INIT 003142	LTST14 011432	PRG2A = 016304
BIT12 = 010000	DAT13 014504	INITIA= 104012	LTST15 011450	PRG2AA = 016312
BIT13 = 020000	DAT14 014522	KBDIN = 104014	LTST16 011466	PRG2B = 016352
BIT14 = 040000	DAT15 014540	KBDINT 017154	LTST17 011504	PRG2C = 016376
BIT15 = 100000	DAT16 014556	KSTART 001506	LTST2 011216	PRG2M = 017561
BIT2 = 000004	DAT17 014574	LBIT0 = 000001	LTST3 011234	PRG2R = 016300
BIT3 = 000010	CAT2 014306	LBIT1 = 000002	LTST4 011252	PRTY0 = 000000
BIT4 = 000020	DAT3 014324	LCIT10= 000400	LTST5 011270	PRTY1 = 000040
BIT5 = 000040	DAT4 014342	LBIT11= 001000	LTST6 011306	PRTY2 = 000100
BIT6 = 000100	DAT5 014360	LBIT12= 002000	LTST7 011324	PRTY3 = 000140
BIT7 = 000200	DAT6 014376	LBIT13= 004000	MACHER 000004	PRTY4 = 000200
BIT8 = 000400	DAT7 014414	LBIT14= 010000	MANUAL= 100000	PRTY5 = 000240
BIT9 = 001000	DELAY = 104400	LBIT15= 020000	MSG1 017657	PRTY6 = 000300
BKCSR 001254	DISPLA 001104	LBIT16= 040000	M0 017436	PRTY7 = 000340
BMOVE 005732	DISPRE 000174	LBIT17= 100000	M1 017444	PRVCNT 001612
BRKTST 005164	DLY 005506	LBIT2 = 000004	M2 017447	PSW = 177776
BRFO 013712	DLYXMT 005310	LBIT3 = 000010	M3 017454	PTO 005606
BRF1 013730	DMPAR 003172	LBIT4 = 000020	M4 017467	PT1 005610
BRF10 014072	DMPARB 003454	LBIT5 = 000040	NOF = 000240	PWRUP 004314
BRF11 014110	DMPARC 003600	LBIT6 = 000100	NXTS1 001514	RCVDAT 001274
BRF12 014126	DTCHK 001634	LBIT7 = 000200	OACNV 005662	RCVTST 004542
BRK13 014144	EMALT = 104004	LENGTH 003620	OACNVA 005674	RCVO 011522
BRK14 014162	EMO 017637	LENOKA 003636	OPEN = 000000	RCV1 011540
BRK15 014200	EMTINT 002606	LENOKB 003646	OUTBUF 016564	RCV10 011702
BRK16 014216	EMTTAB 001540	LENOKC 003654	ORLAY 004100	RCV11 011720
BRK17 014234	FRDAT 017401	LENOKD 003714	PARAM 016402	RCV12 011736
BRK2 013746	ERR 001654	LEVEL 017365	PARAMA 016414	RCV13 011754
BRK3 013764	ERRA 001712	LINBIT 001272	PARAMB 016444	RCV14 011772
BRK4 014002	ERRB 001754	LINE 016412	PAP0 006534	RCV15 012010
BRK5 014020	ERRC 001762	LINE0 = 000000	PAP1 006536	RCV16 012026
BRK6 014036	ERRO 002014	LINE1 = 000002	PAP2 006540	RCV17 012044
BRK7 014054	ERREX 002034	LINE10= 000020	PAP3 006542	RCV2 011556
CAPMST 001300	EPHILT 002032	LINE11= 000022	PAP4 006544	RCV3 011574

PCV4	011612	RT121	014332	RT21	010456	RT62	011762	TIME14	004076
PCV5	011630	RT122	014350	RT21A	010466	RT63	012000	TKCSR	001574
PCV6	011646	RT123	014366	RT22	010564	RT64	012016	TKDBR	001576
PCV7	011664	RT124	014404	RT22A	010574	RT65	012034	TMP1	017266
RECD	004124	RT125	014422	RT23	010672	RT66	012054	TPCSR	001600
RIND	005604	RT126	014440	RT23A	010702	RT66A	012070	TPDBR	001602
RNGEN	002756	RT127	014456	RT24	011000	RT67	012314	TTDAT	001270
RORPAR	006472	RT13	007652	RT24A	011010	RT67A	012324	TUMTAB	001306
PP1	003024	RT13A	007662	RT25	011044	RT7	007302	TYP	003030
PP2	003026	RT130	014474	RT25A	011054	RT7A	007312	TYPA	003040
RSTART	001532	RT131	014512	RT26	011152	RT70	012424	TYPC	003056
RSTAT1	002134	RT132	014530	RT27	011170	RT70A	012434	TYPD	003074
RSTAT2	002222	RT133	014546	RT3	007032	RT71	012540	TYPDAT	003140
RSTPC	002734	RT134	014564	RT3A	007042	RT71A	012550	TYPE =	104000
RSTPSW	002736	RT135	014602	RT30	011206	RT72	012734	TYPF	003112
RSTREG=	104010	RT135A	014612	RT31	011224	RT72A	012744	TYPG	003124
RSTRG	002700	RT136	015202	RT32	011242	RT73	013300	UNIT	003474
RTLAST=	177777	RT136A	015212	RT33	011260	RT73A	013310	UNTOKA	003514
RTNNO	001512	RT137	015516	RT34	011276	RT74	013514	UNTOKB	003540
RT0	006644	RT137A	015526	RT35	011314	RT74A	013524	UNTOKC	003570
RT0A	006654	RT14	007764	RT36	011332	RT75	013702	VAC	001246
RT1	006706	RT14A	007774	RT37	011350	RT76	013720	VECOK	003374
RT1A	006716	RT140	015534	RT4	007104	RT77	013736	VECOKA	003404
RT10	007354	RT140A	015544	RT4A	007114	SAVREG=	104007	VECOKB	003412
RT10A	007364	RT141	015552	RT40	011366	SAVPG	002640	VECTOR	003356
RT100	013754	RT141A	015562	RT41	011404	SCOPE =	104006	WCT	001146
RT101	013772	RT142	015570	RT42	011422	SCOPEA	002444	WHERE	017310
RT102	014010	RT142A	015600	RT43	011440	SCOPEB	002450	WH CH	017352
RT103	014026	RT143	015606	RT44	011456	SCOPEE	002504	X =	000146
RT104	014044	RT143A	015616	RT45	011474	SCOPTR	001520	XMITD	005754
RT105	014062	RT144	015624	RT46	011512	SPBOT	001100	XMTDAT	001276
RT106	014100	RT144A	015634	RT47	011530	SRESET=	104005	XMTINT	001264
RT107	014116	RT145	015642	RT5	007156	SPSET	002254	XMTLVL	001266
RT11	007426	RT145A	015652	RT5A	007166	SRSETT	002740	XMTTST	004330
RT11A	007436	RT146	016010	RT50	011546	START	002066	Y =	000020
RT110	014134	RT146A	016020	RT51	011564	SUSWR =	104013	SCTLU	017350
RT111	014152	RT15	010024	RT52	011602	SUSWRR	017074	SENDAD	002544
PT112	014170	RT15A	010034	PT53	011620	SVRPC	002674	SSWREG	017323
RT113	014206	RT16	010160	PT54	011636	SVRPSW	002676	SVALUE	017331
PT114	014224	RT16A	010170	PT55	011654	SWR	001102	=	017756
PT115	014242	RT17	010276	PT56	011672	SWPEG	000176	BAR	001616
PT116	014260	RT17A	010306	PT57	011710	TIMEA	004000	BASPE	001622
PT117	014276	RT2	006760	PT6	007230	TIMEB	004034	BKCSR	001620
RT12	007516	PT2A	006770	PT6A	007240	TIMEC	004044	CSR	001614
RT12A	007526	RT20	010370	FT60	011726	TIMEP	003724		
RT120	014314	PT20A	010400	PT61	011744	TIME1	004074		

ABS 017756 000

ERRORS DETECTED 0

.DZDMAC SEQ/NL SEQ=DZDMAC P11
RUN-TIME 5 9 5 SECONDS
RUN-TIME RATIO 426/15=27 5
CORE USED 134 (25 PAGES)

