

DV11

STATIC LINE CARD TEST
MD-11-DZDVB-B

EP-DZDVB-B-DL-A

NOV 1976

COPYRIGHT 1976

digital

FICHE 1 OF 1

MADE IN USA

The image shows a grid of 14 columns and 14 rows of small data cards or test results. Each card contains various alphanumeric characters and symbols, likely representing test data or system status. The cards are arranged in a regular grid pattern, with some cards appearing slightly faded or less distinct than others. The overall appearance is that of a dense array of small, individual data points or test results.

IDENTIFICATION

PRODUCT CODE: MAINDEC-11-DZDVB-B-C
PRODUCT NAME: STATIC LINE CARD TESTS
DATE RELEASED: 21-APRIL-1976
MAINTAINER: DIAGNOSTICS
AUTHOR: JOHN EGOLF

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OF RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT © 1975, 1976 DIGITAL EQUIPMENT CORPORATION

1. ABSTRACT

THE FUNCTION OF THE DV11 DIAGNOSTICS ARE TO VERIFY THAT THE OPTION OPERATES ACCORDING TO SPECIFICATIONS. THE DIAGNOSTICS VERIFY THAT THERE ARE NO MALFUNCTIONS AND THE ALL OPERATIONS OF THE DV11 ARE CORRECT IN ITS ENVIRONMENT.

PARAMETERS MAY BE SET TO ALERT DIAGNOSTICS AS TO THE DV11 CONFIGURATION BY USING THE "TRIAL" PROGRAM (DZDVE SA:210). ALL QUESTIONS SHOULD BE ANSWERED AND THEN EACH DIAGNOSTIC WILL "OVERLAY" THESE PARAMETERS WHICH ARE STORED IN THE "STATUS TABLE" (SEE SECTION 8.4A). THE ALTERNATIVE TO "TRIAL" PROGRAM IS "AUTO SIZING" (SEE SECTION 8.5).

DZDVB EXERCISES ALL EXISTING LINE CARDS IN A STATIC STATE (MICRO PROCESSOR IS NEVER TURNED ON). TRANSMITTER AND RECEIVER FLAG, TRANSMITTER AND RECEIVER DATA, RECEIVER SYNCING AND CHAR SILO ARE TESTED. MOST TESTS EXERCISE A "GROUP" OF 4 LINES AT A TIME (00-03, 04-07, 08-11, 12-15). FOR EASE OF TROUBLESHOOTING, ONLY ONE LINE CARD MAY BE INSTALLED AND BY ALERTING THE DIAGNOSTIC AS TO WHICH LINE CARDS ARE PHYSICALLY REMOVED (SEE SECTION 9.4A) PROGRAM WILL RUN ANY COMBINATION OF LINE CARDS.

CURRENTLY THERE ARE SIX OFF LINE DIAGNOSTICS THAT ARE TO BE RUN IN SEQUENCE TO INSURE THAT IF AN ERROR SHOULD OCCUR IT WILL BE DETECTED AT AN EARLY STAGE AND INSURING THAT DIAGNOSIS OF ERROR WILL BE IMMEDIATE TO PROBLEM

NOTE: ADDITIONAL DIAGNOSTICS MAY BE ADDED IN THE FUTURE.

THE SIX DIAGNOSTICS ARE:

1. DZDVA [REV] BASIS R/W TEST AND ROM INSTRUCTION EXERCISER.
2. DZDVB [REV] STATIC LINE CARD TESTS.
3. DZDVC [REV] 'FREE RUNNING' ROM TESTS PART 1.
4. DZDVD [REV] 'FREE RUNNING' ROM TESTS PART 2.
5. DZDVE [REV] MODEM CONTROL AND CABLE TESTS PLUS MANUAL PARAMETER INPUT. (TRIAL PROGRAM)
6. DZDVF [REV] ASYNCHRONOUS LINE CARD TESTS.

2. REQUIREMENTS

2.1 EQUIPMENT

ANY PDP11 FAMILY CPU (WITH MINIMUM 8K MEMORY)
 ASR 33 (OR EQUIVALENT)
 DV11-AA MUX CNTRL UNIT
 AT LEAST ONE OF THE FOLLOWING
 DV11-BA 8 LINE SYNC MODULES
 DV11-BB 8 LINE ASYNC MODULES
 DV11-BC 4 SYNC LINES, 4 ASYNC LINES

4. STARTING PROCEEDURE

- A. SET SWITCH REGISTER TO 000200
- B. DEPRESS 'LOAD ADDRESS' KEY AND RELEASE
- C. SET SWR TO ZERO FOR 'AUTO SIZING' OR LEAVE
LEAVE SWR BIT 7=1 TO USE EXISTING PARAMETERS SET UP BY DV11 TRIAL PROGRAM OR A PREVIOUSLY RUN DV11 DIAGNOSTIC THAT USED THE 'AUTO SIZING'. (SECTION 7.2 AND 8.4.8.5 MAY BE HELPFUL)
- D. DEPRESS 'START KEY' AND RELEASE THE PROGRAM WILL TYPE MAINDEC NAME AND PROGRAM NAME (IF THIS WAS THE FIRST START UP OF THE PROGRAM) AND ALSO THE FOLLOWING:

'MAP OF DV11 STATUS'

!500	000300
!502	000226
!504	000226
!506	000226
!510	000226
!512	000062
!514	000226
!516	000062
!520	000226
!522	000062

THE ABOVE IS ONLY AN EXAMPLE! THIS WOULD INDICATE THE STATUS TABLE STARTING AT ADD. !500 IN THE PROGRAM. THE STATUS TABLE MUST BE VERIFIED BY THE USER IF AUTO SIZING IS DONE. FOR INFORMATION OF STATUS TABLE SEE SECTION 8.4 FOR HELP.

THE PROGRAM WILL TYPE 'R' AND PROCEED TO RUN THE DIAGNOSTIC

4.1 CONTROL SWITCH SETTINGS

NOTE: IF THERE IS NO READ SWR (!77570); SWR MAY BE MODIFIED AT LOC:176 OR BY HITTING CONTROL "G" (↑G) ON CONSOLE TERMINAL.

- SW 15 SET: HALT ON ERROR
- SW 14 SET: LOOP ON CURRENT TEST
- SW 13 SET: INHIBIT ERROR PRINT OUT
- SW 12 SET: INHIBIT **ALL** TYPE OUT BELL ON ERROR.
- SW 11 SET: INHIBIT ITERATIONS. (QUICK PASS)
- SW 10 SET: ESCAPE TO NEXT TEST
- SW 09 SET: LOOP WITH CURRENT DATA
- SW 08 SET: CATCH ERROR AND LOOP ON IT
- SW 07 SET: USE PREVIOUS STATUS TABLE. CLR-DO AUTO SIZE.
- SW 06 SET: RESERVED
- SW 05 SET: RESERVED
- SW 04 SET: RESERVED
- SW 03 SET: RESERVED
- SW 02 SET: LOCK ON SELECTED TEST
- SW 01 SET: RESTART PROGRAM AT SELECTED TEST
- SW 00 SET: RESELECT DV11'S DESIRED ACTIVE.

4.1.3 SWITCH REGISTER PRIORITYS

ERROR SWITCHES

- 1. SW 12 DELETE PRINT OUT/BELL ON ERROR.
- 2. SW 13 DELETE ERROR PRINTOUT.
- 3. SW 15 HALT ON THE ERROR.
- 4. SW 08 GOTC BEGINNING OF THE TEST(ON ERROR).
- 5. SW 10 GOTC NEXT TEST(ON ERROR).

SCOPE SWITCHES

- 1. SW 09 (IF ENABLED BY 'SCOPI') ON AN ERROR; IF AN '*' IS PRINTED IN FRONT OF THE TEST NO. (EX. *TEST NO. 10) SW09 IS INCORPORATED IN THAT TEST AND THEREFORE SW09 IS *USUALLY* THE BEST SWITCH FOR THE SCOPE LOOP (SW14=0, SW10=0, SW09=1, SW08=0). IF SW09 IS NOT ENABELED; AND THERE IS A *HARD* ERROR (CONSTANT); SW08 IS BEST.
 (SW14=1,0, SW10=0, SW09=0, SW08=1). FOR INTERMITTEMT ERRORS: SW14=1 WILL LOOP ON TEST REGARDLESS OF ERROR OR NOT ERROR.
 (SW14=1, SW10=0, SW09=0, SW08=1,0)
- 2. SW 14
- 3. SW 11

4.2 STARTING ADDRESS

STARTING ADDRESS IS AT 000200 THERE ARE NO OTHER STARTING ADDRESSES FOR THE DV11 DIAGNOSTICS PREVIOUSLY MENTIONED EXCEPT FOR DZDVE WHICH IS: 000200 FOR THE MODEM CONTROL AND CABLE TESTS AND 000210 FOR THE MANUAL PARAMETER INPUT PROGRAM.

NOTE: IF ADDRESS 000042 IS NON-ZERO THE PROGRAM ASSUMES IT IS UNDER ACT11 OR XXDP CONTROL AND WILL ACT ACCORDINGLY AFTER *ALL* AVAILABLE DV11'S ARE TESTED THE PROGRAM WILL RETURN TO 'XXDP' OR 'ACT-11'.

5. OPERATING PROCEDURE

WHEN PROGRAM IS INITIALLY STARTED MESSAGES AS DESCRIBED IN SECTION FOUR WILL BE PRINTED.

AND PROGRAM WILL BEGIN RUNNING THE DIAGNOSTIC

DDVVB MAQY11 27.732' 17-SEP-76 11:14 PAGE 7
 DDVVB.P11

18
17
16
15
14
13
12
11
10
9
8
7
6
5
4
3
2
1

5.2 PROGRAM AND/OR OPERATOR ACTION

THE TYPICAL APPROACH SHOULD BE

1. HALT ON ERROR (VIA SW 15=1) WHEN EVER AN ERROR OCCURS.
2. CLEAR SW 15.
3. SET SW 14: (LOOP ON THIS TEST)
4. SET SW 13: (INHIBIT ERROR PRINT OUT)

THE TEST NUMBER AND PC WILL BE TYPED OUT AND POSSIBLY AN ERROR MESSAGE (THIS DEPENDS ON THE TEST) TO GIVE THE OPERATOR AN IDEA AS TO THE SOURCE OF THE PROBLEM. IF IT IS NECESSARY TO KNOW MORE INFORMATION CONCERNING THE ERROR REPORT; LOOK IN THE LISTING FOR THAT TEST NUMBER WHICH WAS TYPED OUT AND THEN NOTE THE PC OF THE ERROR REPORT THIS WAY THE EXACT FUNCTIONING OF THE TEST CAN BE INTERPEDITED.

6. ERRORS

AS DESCRIBED PREVIOUSLY THERE WILL ALWAYS BE A TEST NUMBER AND PC TYPED OUT AT THE TIME OF AN ERROR (PROVIDING SW 13=0 AND SW 12=0). IN MOST CASES ADDITIONAL INFORMATION WILL BE SUPPLIED TO THE THE ERROR MESSAGE WHICH IS TO GIVE THE OPERATOR AN INDICATION OF THE ERROR.

6.2 ERROR RECOVERY

IF FOR SOME REASON THE DV11 SHOULD 'HANG THE BUS' (GAIN CONTROL OF BUS SO THAT CONSOLE MANUAL FUNCTIONS ARE INHIBITED) AN INIT OR POWER DOWN/UP IS NECESSARY FOR OPERATOR TO REGAIN CONTROL OF CPU. IF THIS SHOULD HAPPEN; LOOK IN LOCATION 'TSTNO' (ADDRESS 1224) FOR THE NUMBER OF THE TEST THAT WAS RUNNING AT THE TIME OF THE CATASTROPHIC ERROR. IN THIS WAY THE OPERATOR WILL HAVE AN IDEA AS TO WHAT THE DV11 WAS DOING AT THE TIME OF THE ERROR.

7. RESTRICTIONS

7.1 STARTING RESTRICTIONS

SEE SECTION 4. (PLEASE)
STATUS TABLE SHOULD BE VERIFIED REGARDLESS OF HOW PROGRAM WAS STARTED. ALSO IT IS IMPORTANT TO USE THIS LISTING ALONG WITH THE INFORMATION PRINTED ON THE TTY TO COMPLETELY ISOLATE PROBLEMS.

0
1
2
3
4
5
6
7
8
9
A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
[
\
]
^
_
`
a
b
c
d
e
f
g
h
i
j
k
l
m
n
o
p
q
r
s
t
u
v
w
x
y
z
{
|
}
~

7.2 OPERATING RESTRICTIONS

DV11 TRIAL PROGRAM MUST BE RUN PRIOR TO THE FIRST AND ONLY THE FIRST RUNNING OF ANY DV11 DIAGNOSTIC IF "AUTO SIZING" IS NOT USED.

NOTE: IF NO PROGRAM OTHER THAN A DV11 DIAGNOSTIC WAS LOADED AFTER DV11 TRIAL OR IF CORE MEMORY HAS NOT BEEN CHANGED OR IF THERE IS NO DV11 CONFIGURATION CHANGES: THE DV11 TRIAL PROGRAM NEED NEVER BE RUN AGAIN. HOWEVER IF ANY OF THE ABOVE HAVE BEEN VIOLATED THE DV11 TRIAL PROGRAM MUST BE RUN AGAIN BEFORE RUNNING THE DIAGNOSTICS NOTE: AN ALTERNATIVE TO THE ABOVE IS ATTEMPTING THE 'AUTO SIZING' WHEN PROGRAM IS INITIALLY STARTED WITH SW07=0.

7.3 HARDWARE CONFIGURATION RESTRICTIONS (SYNC LINE CARDS ONLY)

- 1. HARDWARE MUST BE SET TO FULL DUPLEX
- 2. PARITY OFF.
- 3. ALL LINES OF A PARTICULAR LINE CARD MUST BE CONFIGURED THE SAME.

8. MISCELLANEOUS

8.1 EXECUTION TIME

ALL DV11 DEVICE DIAGNOSTICS WILL GIVE AN 'END PASS' MESSAGE (PROVIDING NO ERRORS AND SW12=0) WITHIN 4 MINS. THIS IS ASSUMING SW11=1 (DELETE ITERATIONS) IS SET TO GIVE THE FASTEST POSSIBLE EXECUTION. THE ACTUAL EXECUTION TIME DEPENDS GREATLY ON THE PDP11 CPU CONFIGURATION.

8.2 PASS COMPLETE

NOTE: *EVERY* TIME THE PROGRAM IS STARTED: THE TESTS WILL RUN AS IF SW11 (DELETE ITERATIONS) WAS UP (=1). THIS IS TO 'VERIFY NO *HARD* ERRORS' AS SOON AS POSSIBLE. THEREFORE THE FIRST PASS -EACH TIME PROGRAM IS STARTED- WILL BE A 'QUICK PASS' UNTILL ALL DV11'S IN SYSTEM ARE TESTED. WHEN THE DIAGNOSTIC HAS COMPLETED A PASS THE FOLLOWING IS AN EXAMPLE OF THE PRINT OUT TO BE EXPECTED.

END PASS DZDV8-B CSR: 175000 VEC: 300 PASSES: 000001 ERRORS: 000000

NOTE: THE NUMBERS FOR CSR AND VEC ARE NOT NECESSARILY THE VALUES FOR THE DEVICE. THEY ARE ONLY FOR THIS EXAMPLE.

NOTE: DZDVE (MODEM AND CABLE TEST) END PASS MESSAGE IS A LARGE "END" TYPED OUT ON TTY. PLEASE NOTE THAT EACH CHARACTER PRINTED IS ACTUALLY AND "END PASS" INDICATION. THIS WAS USED IN PLACE OF "BELL" BECAUSE IF SW12=1 AND AN ERROR OCCURED THE BELL MAY BE MISTAKEN FOR END PASS. THE PASS EXECUTION IS SO FAST THAT THE STANDARD END PASS WAS TOO LENGTHLY. THEREFORE EACH CHAR IS AN "END PASS AND THE ENTIRE "END" IS NOT REQUIRED FOR ACCEPTANCE.

418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473

8.4A MORE ON THAT 'STATUS TABLE' (1500-1736)

'MAP OF DV11 STATUS'

1500	175000
1502	000300
1504	000226
1506	000062
1510	000226
1512	000062
1514	004000
1516	000000
1520	004000
1522	000000

THE ABOVE INFORMATION WILL BE REPEATED FOR EACH OF UP TO 8 DV11'S IN THE SYSTEM (THESE WILL FOLLOW UNDER THIS TABLE). EXPLANATION:

1500 175000 THIS IS THE SYSTEM CONTROL REGISTER FOR THE 1ST DV11 IN THE SYSTEM.
 1502 000300 THIS IS VECTOR 'A' FOR THE FIRST DV11 IN THE SYSTEM.
 1504 000226 THIS REPRESENTS 'SYNC A' AND THE SOFTWARE STATUS FOR THE 1ST LINE CARD IN THE 1ST DV11. THE BITS ARE AS FOLLOWS:

BIT 15 SET: LINE CARD *NOT INSTALLED (AND WONT BE TESTED)
 BIT 14 SET: RESERVED
 BIT 13 SET: RESERVED
 BIT 12 SET: ONE SYNC, =0: TWO SYNCs.
 BIT 11 SET: ASYNC LINE CARD, =0 SYNC LINE CARD.
 BIT 10 SET: RESERVED
 BIT 09 SET: BITS PER CHAR. (USED WITH BIT8)
 BIT 08 SET: BITS PER CHAR. (USED WITH BIT9)

BIT09	BIT08	BITS PER CHAR.
0	0	8
0	1	7
1	0	6
1	1	5

BIT 07-00 SYNC 'A' FOR SPECIFIED LINE CARD.
 1506 000062 THIS REPRESENTS 'SYNC B' FOR THE 1ST LINE CARD.
 1510 000226 THIS IS 'SYNC A' AND LINE STATUS FOR THE 2ND LINE CARD. (FOR BITS DEFINATION SEE EXPLANATION FOR LINE CARD 1).
 1512 000062 THIS IS 'SYNC B' FOR THE SECOND LINE CARD.
 1514 000226 THIS IS 'SYNC A' AND LINE STATUS FOR THE 3RD LINE CARD. (FOR BITS DEFINATION SEE EXPLANATION FOR LINE CARD 1).
 1516 000062 THIS IS 'SYNC B' FOR LINE CARD NO. 3.
 1520 000226 THIS IS 'SYNC A' AND LINE STATUS FOR THE 4TH LINE CARD. (FOR BITS DEFINATION SEE EXPLANATION FOR LINE CARD 1).
 1522 000062 THIS IS SYNC B FOR THE 4TH LINE CARD.

THE ABOVE IS REPEATED FOR EACH DV11 IN THE SYSTEM. THE TABLE IS FILLED BY AUTO SIZING OR BY THE MANUAL PARAMETER INPUT PROGRAM AS DESCRIBED PREVIOUSLY. ALSO IF DESIRED BY USER; THE LOCATIONS MAY BE ALTERED BY HAND (TOGGLED IN) TO SUIT THE SPECIFIC CONFIGURATION.

475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530

8.5 *** METHOD OF AUTO SIZING ***

8.5.1 FINDING THE CONTROL STATUS REGISTER.

THE PROGRAM WILL START AT ADDRESS 175000 AND START 'REFERENCEING' ADDRESS. IF A NON-EX MEMORY TRAP OCCURES; THE POINTER (HOLDING 175000) IS UPDATED BY 10 AND THE ABOVE IS REPEATED UNTILL ADDRESS 175400 IS REACHED. IF A 'SLAVE SYNC RESPONSE' WAS ISSUED BY THE DV11 (OR ANY OTHER DEVICE) (NO NXM TRAP)(AND IT (SEL0) WAS=0) ; POINTER PLUS 12 (SEL12) IS TESTED TO CONTAIN 177777 (MUST BE EXACTLY 177777); IF A TRAP IS ENCOUNTERED OR IF SEL12 DOES NOT CONTAIN 177777 THE ABOVE UPDATING IS PERFORMED. IF SEL12 WAS EQUAL TO 177777 THE POINTER IS STORED AWAY AND THE ROUTINE CONTINUES AS ABOVE:
NOTE: IF THE PROGRAM DOES NOT FIND YOUR DV11; SOMETHING IS WRONG AND AUTO SIZING SHOULD NOT BE DONE.

8.5.2 FINDING THE VECTOR

THE VECTOR AREA (ADDRESS 300-776) IS FILLED WITH THE INSTRUCTION IOT AND '+2' (NEXT ADDRESS). BIT7 AND BIT6 (RX INTERUPT AND RX INTERUPT IE) ARE SET INTO DVSCR REGISTER; A DELAY IS MADE AND IF NO INTERUPT OCCURES (BECAUSE OF A BAD DV11) THE PROGRAM ASSUMES VECTOR ADDRESS 300 AND THE PROBLEM SHOULD BE FIXED IN THE DIAGNOSTIC. ONCE THE PROBLEM IS FIXED; THE PROGRAM SHOULD BE RE-SETUP AGAIN TO GET CORRECT VECTOR. IF AN INTERUPT OCCURED; THE ADDRESS TO WHICH THE DV11 INTERUPTED TO IS PICKED UP AND REPORTED AS THE VECTOR. NOTE: IF THE VECTOR REPORTED IS NOT THE VECTOR SET UP BY YOU; THERE IS A PROBLEM AND AUTO SIZING SHOULD NOT BE DONE.

8.5.3 PARAMETER ASSUMPTIONS.

SINCE TOO MUCH HARDWARE WOULD NEED TO BE TURNED ON TO SIZE THE REST OF THE PARAMETERS; THE PROGRAM MUST ASSUME THE REMAINING VARIATIONS. THE RESULT IF NOT TO YOUR SPECIFIC CONFIGURATION MAY BE ALTERED BY HANG (TOGGLE IN) IS DESIRED. IN THIS WAY 95% OF THE PARAMETER SETUP WAS DONE BY THE PROGRAM AND 5% BY YOU.
THEREFORE:

- 1) ALL LINE CARDS(4) ARE ASSUMED TO BE INSTALLED.
SET BIT15 OF STATUS MAP OF ANY (APPROIATE) LINE CARDS MISSING
- 2) TWO SYNC.
SET BIT12 IF YOU HAVE A 4 LINE GROUP SET FOR 1 SYNC.
- 3) EIGHT BITS PER CHAR.
ADJUST BITS 9 AND BIT 8 IN STATUS MAP FOR YOUR CORRECT CONFIG.
- 4) SYNCHRONOUS LINE CARDS INSTALLED
SET BIT11 OF STATUS MAP FOR ASYNC LINE CARD AND ZERO SYNC CARDS.
- 5) SYNC "A"=226 AND SYNC "B"=062

IN ALL ADJUSTMENTS PLEASE REFER TO SECTION 8.4A FOR GREATER DETAIL.
§

;*MAINDEC-11-DZDVB-B/<377>/STATIC LINE CARD TESTS
;*COPYRIGHT 1972, DIGITAL EQUIPMENT CORP., MAYNARD, MASS. 01754
;*

MO1

531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561

; STARTING PROCEDURE
; LOAD PROGRAM
; LOAD ADDRESS 000200
; PRESS START
; PROGRAM WILL TYPE "MAINDEC-11-DZDVB-B/<377>/STATIC LINE CARD TESTS "
; PROGRAM WILL TYPE "R" TO INDICATE THAT TESTING HAS STARTED
; AT THE END OF A PASS, PROGRAM WILL TYPE PASS COMPLETE MESSAGE
; AND THEN RESUME TESTING

; SWITCH REGISTER OPTIONS

100000
040000
020000
010000
004000
002000
001000
000400
000200
000100
000040
000020
000010
000004
000002
000001

SW15=100000
SW14=40000
SW13=20000
SW12=10000
SW11=4000
SW10=2000
SW09=1000
SW08=400
SW07=200
SW06=100
SW05=40
SW04=20
SW03=10
SW02=4
SW01=2
SW00=1

=1, HALT ON ERROR
=1, LOOP ON CURRENT TEST
=1, INHIBIT ERROR TYPEOUT
=1, DELETE TYPEOUT/BELL ON ERROR.
=1, INHIBIT ITERATIONS
=1, ESCAPE TO NEXT TEST ON ERROR
=1, LOOP WITH CURRENT DATA
=1, LOOP ON ERROR
=1, DO "AUTO SIZING" ON INITIAL START UP.

; LOCK ON TEST SELECT
; RESTART PROGRAM AT SELECTED TEST
; RESELECT DV11 DESIRED ACTIVE
; NOTE: THIS MUST NOT EXCEED ORIGINAL COUNT

562
 563
 564
 565
 566
 567
 568
 569
 570
 571
 572
 573
 574
 575
 576
 577
 578
 579
 580
 581
 582
 583
 584
 585
 586
 587
 588
 589
 590
 591
 592
 593
 594
 595
 596
 597
 598
 599
 600
 601
 602
 603
 604
 605
 606
 607
 608

:REGISTER DEFINITIONS

 ;

000000	R0=%0	:GENERAL REGISTER
000001	R1=%1	:GENERAL REGISTER
000002	R2=%2	:GENERAL REGISTER
000003	R3=%3	:GENERAL REGISTER
000004	R4=%4	:GENERAL REGISTER
000005	R5=%5	:GENERAL REGISTER
000006	SP=%6	:PROCESSOR STACK POINTER
000007	PC=%7	:PROGRAM COUNTER

:LOCATION EQUIVALENCIES

 ;

177776	PS=177776	:PROCESSOR STATUS WORD
001200	STACK=1200	:START OF PROCESSOR STACK
100000	BIT15=100000	
040000	BIT14=40000	
020000	BIT13=20000	
010000	BIT12=10000	
004000	BIT11=4000	
002000	BIT10=2000	
001000	BIT9=1000	
000400	BIT8=400	
000200	BIT7=200	
000100	BIT6=100	
000040	BIT5=40	
000020	BIT4=20	
000010	BIT3=10	
000004	BIT2=4	
000002	BIT1=2	
000001	BIT0=1	
010000	ALU=BIT12	
020000	RAM=BIT13	
030000	XFR=BIT13+BIT12	
040000	NPR=BIT14	
050000	S.C=BIT14+BIT12	
060000	BCC=BIT14+BIT13	
070000	BRB=BIT14+BIT13+BIT12	

 ;

```

.....
-----
:TRAPCATCHER FOR ILLEGAL INTERRUPTS
:THE STANDARD "TRAP CATCHER" IS PLACED
:BEWEEN ADDRESS 0 TO ADDRESS 776.
:IT LOOKS LIKE "PC+2 HALT".
-----
.....

```

```

.....
:STANDARD INTERRUPT VECTORS
-----
:
:24
:PFail           :POWER FAIL HANDLER
:340             :SERVICE AT LEVEL 7
:ERR             :ERROR HANDLER
:340             :SERVICE AT LEVEL 7
:TRAPSRV        :GENERAL HANDLER DISPATCH SERVICE
:340             :SERVICE AT LEVEL 7
:
:40
:BLKW 1         :SAVE FOR ACT-11 OR DDP2
:BLKW 1         :RETURN ADDRESS IF UNDER ACT-11 OR DDP2
:BLKW 1         :SAVE FOR ACT-11 OR DDP2
:LOGICAL        :FOR USE WITH ACT-11 OR DDP2
:
:=174
LIGHT: 0
:=176
SSWR: 0
:
:=200
JMP .START      :GO TO START OF PROGRAM
:
:=1000
MTITLE: .ASCIZ  (377) 12) MAINTENC-11-CIDV8-B (377) STATIC LINE CARD TESTS .377)
:
:=1200
LIGHTS:
SWR: 177570
:INDIRECT POINTERS TO TELETYPE VECTORS AND REGISTERS
-----
TKCSR: 177560   :TELETYPE KEYBOARD CONTROL REGISTER
TKDBR: 177562   :TELETYPE KEYBOARD DATA BUFFER
TPCSR: 177564   :TELEPRINTER CONTROL REGISTER
*PCBR: 177566   :TELEPRINTER DATA BUFFER
:
:PROGRAM CONTROL PARAMETERS
-----
RETURN: 0       :SCOPE ADDRESS FOR LOOP ON TEST
NEXT: 0         :ADDRESS OF NEXT TEST TO BE EXECUTED
LOCK: 0         :ADDRESS FOR LOCK ON CURRENT DATA

```

.....

730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750

:PROGRAM CONTROL FLAGS
:-----

001310	000	INIFLG: .BYTE	0	:PROGRAM INITIALIZATION FLAG
001311	000	ERRFLG: .BYTE	0	:ERROR OCCURED FLAG
001312	000	LOKFLG: .BYTE	0	:LOCK ON CURRENT TEST FLAG
001313	000	QV.FLG: .BYTE	0	:QUICK VERIFY FLAG.
				:ON FIRST PASS OF EACH DV11 ITERATIONS WILL BE SUPPRESSE
	000000	.EVEN		
		\$Y=0		

:DEFINITIONS FOR TRAP SUBROUTINE CALLS
:POINTERS TO SUBROUTINES CAN BE FOUND
:IN THE TABLE IMMEDIATLY FOLLOWING THE DEFINITIONS

:*****

001314	104400	.TRFTAB:		
		SCOPE=TRAP+0		:CALL TO SCOPE LOOP AND ITERATION HANDLER
001314	002634	.SCOPE		
	104401	SCOPE1=TRAP+1		:CALL TO LOOP ON CURRENT DATA HANDLER
001316	003020	.SCOPE1		
	104402	TYPE=TRAP+2		:CALL TO TELETYPE OUTPUT ROUTINE
001320	003044	.TYPE		
	104403	INSTR=TRAP+3		:CALL TO ASCII STRING INPUT ROUTINE
001322	003120	.INSTR		
	104404	INSTER=TRAP+4		:CALL TO INPUT ERROR HANDLER
001324	003224	.INSTER		
	104405	PARAM=TRAP+5		:CALL TO NUMERICAL DATA INPUT ROUTINE
001326	003244	.PARAM		
	104406	SAVOS=TRAP+6		:CALL TO REGISTER SAVE ROUTINE
001330	003444	.SAVOS		
	104407	RESOS=TRAP+7		:CALL TO REGISTER RESTORE ROUTINE
001332	003504	.RESOS		
	104410	CONVRT=TRAP+10		:CALL TO DATA OUTPUT ROUTINE
001334	003536	.CONVRT		
	104411	CNVRT=TRAP+11		:CALL TO DATA OUTPUT ROUTINE WITHOUT CR-LF.
001336	003542	.CNVRT		
	104412	MSTCLR=TRAP+12		:CALL TO ISUE A MASTER CLEAR
001340	004556	.MSTCLR		
	104413	RAMCLR=TRAP+13		:CALL TO CLEAR THE RAMS
001342	004516	.RAMCLR		
	104414	DELAY=TRAP+14		:CALL TO VARIABLE DELAY COUNTER
001344	004476	.DELAY		
	104415	ROMCLK=TRAP+15		:CALL TO CLOCK ROM ONCE
001346	004566	.ROMCLK		
	104416	DATACLK=TRAP+16		:CALL TO CLK DATA
001350	004576	.DATACLK		

:*****

750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802

```

001352 000000
001354 000000
001356 000000
001360 000000
001362 000000
001364 000000
001366 000000
001370 000000
001372 000000
001374 000000
001376 000000
001400 000000
001402 000000
001404 000000

001406 000
001407 000
001410 000
001411 000

001412 010
001413 010
001414 010
001415 010

001416 000000
001420 000000
001422 000000
001424 000000

001426 000000
001430 000000
001432 000000
001434 000000
    
```

```

:DV11 VECTOR AND REGISTER INDIRECT POINTERS

DVRVEC: 0      : POINTER TO DV11 RECEIVER INTERRUPT VECTOR
DVRVLVL: 0     : POINTER TO DV11 RECEIVER INTERRUPT SERVICE PS
DVTVEC: 0      : POINTER TO DV11 TRANSMITTER INTERRUPT VECTOR
DVTLVL: 0      : POINTER TO DV11 TRANSMITTER INTERRUPT SERVICE PS
DVSCR: 0000    : POINTER TO DV11 SYSTEM CONTROL REGISTER
DVSCRH: 0000   : POINTER TO DV11 SYSTEM CONTROL REGISTER HIGH BYTE.
DVRIC: 0000    : POINTER TO DV11 NEXT RECEIVED CHARACTER REGISTER
DVLCR: 00      : POINTER TO DV11 LINE PARAMETER REGISTER
DVSRS: 00      : POINTER TO DV11 SECONDARY REGISTER SELECT REGISTER
DVSRSR: 00     : POINTER TO DV11 SECONDARY REGISTER SELECT HIGH BYTE.
DVSRA: 00      : POINTER TO DV11 SECONDARY REGISTER ACCESS REGISTER
DVSFR: 00      : POINTER TO DV11 SPECIAL FUNCTIONS REGISTER
DVNSR: 00      : POINTER TO DV11 NPR STATUS REGISTER
RESV16: 0      : POINTER TO RESERVED REGISTER.
    
```

:DVI. CONTROL INDICATORS FOR CURRENT DV11 UNDER TEST

```

-----
MASK.A: .BYTE 000      :LAST CHAR TO TEST AND PARITY MASK FOR LINES 00-03
MASK.B: .BYTE 000      :LAST CHAR TO TEST AND PARITY MASK FOR LINES 04-07
MASK.C: .BYTE 000      :LAST CHAR TO TEST AND PARITY MASK FOR LINES 08-11
MASK.D: .BYTE 000      :LAST CHAR TO TEST AND PARITY MASK FOR LINES 12-15

CLK.A: .BYTE 9.        :NUMBER OF CLOCKS NEEDED FOR ONE CHAR FOR LINES 00-03
CLK.B: .BYTE 8.        :NUMBER OF CLOCKS NEEDED FOR ONE CHAR FOR LINES 04-07
CLK.C: .BYTE 9.        :NUMBER OF CLOCKS NEEDED FOR ONE CHAR FOR LINES 08-11
CLK.D: .BYTE 9.        :NUMBER OF CLOCKS NEEDED FOR ONE CHAR FOR LINES 12-15

L00.03: 000000         :PARAMETERS FOR LINES 00-03
L04.07: 000000         :PARAMETERS FOR LINES 04-07
L08.11: 000000         :PARAMETERS FOR LINES 08-11
L12.15: 000000         :PARAMETERS FOR LINES 12-15

SYNC2A: 000000         :SYNC 2
SYNC2B: 000000         :
SYNC2C: 000000         :
SYNC2D: 000000         :
    
```

:SUMMARY

```

-----
: MASK.X      040      5 BITS PER CHAR.
:             100      6 BITS PER CHAR.
:             200      7 BITS PER CHAR.
:             000      8 BITS PER CHAR.

: CLK.X       005      5 BITS PER CHAR.
:             006      6 BITS PER CHAR.
:             007      7 BITS PER CHAR.
:             010      8 BITS PER CHAR.
    
```

:DV11 STATUS TABLE AND ADDRESS ASSIGNMENTS

Address	Value	Label	Description
001500	000001	DV.MAP:	
001500	000001	DVCRO0:	:CONTROL STATUS REGISTER FOR DV11 NUMBER 00
001502	000001	DVTR00:	:VECTOR "A" FOR DV11 NUMBER 00
001504	000001	DV00.A:	:PARAMETER FOR LINES 00-03 FOR DV11 NUMBER 00
001506	000001	SYNA00:	:SYNC TWO
001510	000001	DV00.B:	:PARAMETER FOR LINES 04-07 FOR DV11 NUMBER 00
001512	000001	SYNB00:	:SYNC TWO
001514	000001	DV00.C:	:PARAMETER FOR LINES 08-11 FOR DV11 NUMBER 00
001516	000001	SYNC00:	:SYNC TWO
001520	000001	DV00.D:	:PARAMETER FOR LINES 12-15 FOR DV11 NUMBER 00
001522	000001	SYND00:	:SYNC TWO
001524	000001	DVCRO1:	:CONTROL STATUS REGISTER FOR DV11 NUMBER 01
001526	000001	DVTR01:	:VECTOR "A" FOR DV11 NUMBER 01
001530	000001	DV01.A:	:PARAMETER FOR LINES 00-03 FOR DV11 NUMBER 01
001532	000001	SYNA01:	:SYNC TWO
001534	000001	DV01.B:	:PARAMETER FOR LINES 04-07 FOR DV11 NUMBER 01
001536	000001	SYNB01:	:SYNC TWO
001540	000001	DV01.C:	:PARAMETER FOR LINES 08-11 FOR DV11 NUMBER 01
001542	000001	SYNC01:	:SYNC TWO
001544	000001	DV01.D:	:PARAMETER FOR LINES 12-15 FOR DV11 NUMBER 01
001546	000001	SYND01:	:SYNC TWO
001550	000001	DVCRO2:	:CONTROL STATUS REGISTER FOR DV11 NUMBER 02
001552	000001	DVTR02:	:VECTOR "A" FOR DV11 NUMBER 02
001554	000001	DV02.A:	:PARAMETER FOR LINES 00-03 FOR DV11 NUMBER 02
001556	000001	SYNA02:	:SYNC TWO
001560	000001	DV02.B:	:PARAMETER FOR LINES 04-07 FOR DV11 NUMBER 02
001562	000001	SYNB02:	:SYNC TWO
001564	000001	DV02.C:	:PARAMETER FOR LINES 08-11 FOR DV11 NUMBER 02
001566	000001	SYNC02:	:SYNC TWO
001570	000001	DV02.D:	:PARAMETER FOR LINES 12-15 FOR DV11 NUMBER 02
001572	000001	SYND02:	:SYNC TWO
001574	000001	DVCRO3:	:CONTROL STATUS REGISTER FOR DV11 NUMBER 03
001576	000001	DVTR03:	:VECTOR "A" FOR DV11 NUMBER 03
001600	000001	DV03.A:	:PARAMETER FOR LINES 00-03 FOR DV11 NUMBER 03
001602	000001	SYNA03:	:SYNC TWO
001604	000001	DV03.B:	:PARAMETER FOR LINES 04-07 FOR DV11 NUMBER 03
001606	000001	SYNB03:	:SYNC TWO
001610	000001	DV03.C:	:PARAMETER FOR LINES 08-11 FOR DV11 NUMBER 03
001612	000001	SYNC03:	:SYNC TWO
001614	000001	DV03.D:	:PARAMETER FOR LINES 12-15 FOR DV11 NUMBER 03
001616	000001	SYND03:	:SYNC TWO
001620	000001	DVCRO4:	:CONTROL STATUS REGISTER FOR DV11 NUMBER 04
001622	000001	DVTR04:	:VECTOR "A" FOR DV11 NUMBER 04
001624	000001	DV04.A:	:PARAMETER FOR LINES 00-03 FOR DV11 NUMBER 04
001626	000001	SYNA04:	:SYNC TWO
001630	000001	DV04.B:	:PARAMETER FOR LINES 04-07 FOR DV11 NUMBER 04
001632	000001	SYNB04:	:SYNC TWO
001634	000001	DV04.C:	:PARAMETER FOR LINES 08-11 FOR DV11 NUMBER 04

000006 M0011 27.7321 17-SEP-76 11:14 PAGE 21
 000008.F11 PROGRAM PARAMETERS, VARIABLES, AND TRAP CALLS.

000008	001636	000001	SYND04: .BLKW 1	:SYNC TWO
000009	001640	000001	DV04.D: .BLKW 1	:PARAMETER FOR LINES 12-15 FOR DV11 NUMBER 04
000010	001642	000001	SYND04: .BLKW 1	:SYNC TWO
000011	001644	000001	DVCR05: .BLKW 1	:CONTROL STATUS REGISTER FOR DV11 NUMBER 05
000012	001646	000001	DVTR05: .BLKW 1	:VECTOR "A" FOR DV11 NUMBER 05
000013	001650	000001	DV05.A: .BLKW 1	:PARAMETER FOR LINES 00-03 FOR DV11 NUMBER 05
000014	001652	000001	SYNA05: .BLKW 1	:SYNC TWO
000015	001654	000001	DV05.B: .BLKW 1	:PARAMETER FOR LINES 04-07 FOR DV11 NUMBER 05
000016	001656	000001	SYNB05: .BLKW 1	:SYNC TWO
000017	001658	000001	DV05.C: .BLKW 1	:PARAMETER FOR LINES 08-11 FOR DV11 NUMBER 05
000018	001662	000001	SYND05: .BLKW 1	:SYNC TWO
000019	001664	000001	DV05.D: .BLKW 1	:PARAMETER FOR LINES 12-15 FOR DV11 NUMBER 05
000020	001666	000001	SYND05: .BLKW 1	:SYNC TWO
000021	001670	000001	DVCR06: .BLKW 1	:CONTROL STATUS REGISTER FOR DV11 NUMBER 06
000022	001672	000001	DVTR06: .BLKW 1	:VECTOR "A" FOR DV11 NUMBER 06
000023	001674	000001	DV06.A: .BLKW 1	:PARAMETER FOR LINES 00-03 FOR DV11 NUMBER 06
000024	001676	000001	SYNA06: .BLKW 1	:SYNC TWO
000025	001700	000001	DV06.B: .BLKW 1	:PARAMETER FOR LINES 04-07 FOR DV11 NUMBER 06
000026	001702	000001	SYNB06: .BLKW 1	:SYNC TWO
000027	001704	000001	DV06.C: .BLKW 1	:PARAMETER FOR LINES 08-11 FOR DV11 NUMBER 06
000028	001706	000001	SYND06: .BLKW 1	:SYNC TWO
000029	001710	000001	DV06.D: .BLKW 1	:PARAMETER FOR LINES 12-15 FOR DV11 NUMBER 06
000030	001712	000001	SYND06: .BLKW 1	:SYNC TWO
000031	001714	000001	DVCR07: .BLKW 1	:CONTROL STATUS REGISTER FOR DV11 NUMBER 07
000032	001716	000001	DVTR07: .BLKW 1	:VECTOR "A" FOR DV11 NUMBER 07
000033	001720	000001	DV07.A: .BLKW 1	:PARAMETER FOR LINES 00-03 FOR DV11 NUMBER 07
000034	001722	000001	SYNA07: .BLKW 1	:SYNC TWO
000035	001724	000001	DV07.B: .BLKW 1	:PARAMETER FOR LINES 04-07 FOR DV11 NUMBER 07
000036	001726	000001	SYNB07: .BLKW 1	:SYNC TWO
000037	001730	000001	DV07.C: .BLKW 1	:PARAMETER FOR LINES 08-11 FOR DV11 NUMBER 07
000038	001732	000001	SYND07: .BLKW 1	:SYNC TWO
000039	001734	000001	DV07.D: .BLKW 1	:PARAMETER FOR LINES 12-15 FOR DV11 NUMBER 07
000040	001736	000001	SYND07: .BLKW 1	:SYNC TWO
000041	001740	000000	DV.END: 000000	

```

896
897
898
899
900
901
902
903
904 001742 012737 000340 177776 .START: MOV #340,PS ;LOCK OUT INTERRUPTS
905 001750 012706 001200 MOV #STACK,SP ;SET UP STACK
906 001754 012737 004402 000024 MOV #.PFAIL,@#24 ;SET UP POWER FAIL VECTOR
907 001752 113737 001301 001303 MOV# DVNUM,S#VNUM ;SAVE NUMBER OF DEVICES IN SYSTEM.
908 001770 005037 001230 CLR PASCNT ;CLEAR PASS COUNT
909 001774 105037 001311 CLRB ERRFLG ;CLEAR ERROR FLAG
910 002000 105037 001313 CLRB QV.FLG ;ZERO QUICK VERIFY FLAG
911 002004 012737 001500 001306 MOV #DV.MAP,CREAM ;GET MAP POINTER.
912 002012 112737 000001 001304 MOV# #1,RUN ;POINT POINTER TO FIRST DEVICE.
913 002020 005037 001232 CLR ERRCNT ;CLEAR ERROR COUNT
914 002024 005037 001234 CLR LSTERR ;CLEAR LAST ERROR POINTER
915 002030 012737 000001 001226 MOV #1,TSTNO ;SET UP FOR TEST 1
916 002036 012737 001742 001214 MOV #.START,RETURN ;SET UP FOR POWER FAIL BEFORE
917
918 002044 105737 001310 TSTB INIFLG ;TESTING STARTS
919 002050 001063 BNE 1$ ;HAS INITIALIZATION BEEN PERFORMED
920 002052 013746 000004 MOV 4,-(SP) ;BR IF YES
921 002056 013746 000006 MOV 6,-(SP)
922 002062 005037 000006 CLR 6
923 002066 012737 002104 000004 MOV #80$,4
924 002074 005777 177102 TST @SWR
925 002100 000240 NOP
926 002102 000407 BR 81$
927 002104 022626 80$: CMP (SP)+,(SP)+
928 002106 012737 000174 001200 MOV #LIGHT,LIGHTS
929 002114 012737 000176 001202 MOV #SSWR,$WR
930 002122 012637 000006 81$: MOV (SP)+,6
931 002126 012637 000004 MOV (SP)+,4
932 002132 104402 001000 TYPE #MTITLE ;TYPE TITLE MESSAGE
933 002136 105137 001310 COMB INIFLG ;IF NOT SET FLAG AND DO
934 002142 105777 177034 TSTB @SWR ;BIT7=1??
935 002146 100402 BMI 16$ ;BR IF NO AUTO SIZE
936 002150 004737 006624 JSR PC,CSMAP ;GO DO THE AUTO SIZE
937 002154 104402 005461 16$: TYPE #XHEAD ;:TYPE HEADER
938 002160 012737 001500 001246 MOV #DV.MAP,TEMP1 ;SET POINTER
939 002166 017737 177054 001250 5$: MOV @TEMP1,TEMP2 ;SET DATA
940 002174 022737 177777 001250 CMP #177777,TEMP2 ;ALL DONE?
941 002202 001406 BEQ 1$ ;BR IF YES
942 002204 104410 CONVRT
943 002206 005506 XSTATQ
944 002210 062737 000002 001246 ADD #2,TEMP1 ;UPDATE POINTER
945 002216 000763 BR 5$
946 002220 005737 000042 1$: TST @#42 ;IS PROGRAM RUNNING UNDER MONITOR
947 002224 001030 BNE 3$ ;BR IF YES
948 002226 032777 000001 176746 BIT #SW00,@SWR ;SELECT SPECIFIC DEVICES??
949 002234 001424 BEQ 3$ ;BR IF NO.
950 002236 104402 005402 TYPE #MNEW ;TYPE THE MESSAGE.
951 002242 005000 CLR R0 ;ZERO DATA LIGHTS

```

DZDV6 MACY11 271732 17-SEP-75 11:14 PAGE 23
 DZDVBB.P11 PROGRAM INITIALIZATION AND START JP.

952	002244	000000				HALT				:WAIT FOR USER TO TELL WHAT DEVICES TO RUN
953	002246	127737	176730	001302		CMPS	QSWR,SAVACT			:IS THE NUMBER VALID?
954	002254	101404				BLOS	2\$:BR IF NUMBER IS OK.
955	002256	104402	005243			TYPE	,MERR3			:TELL USER OF INVALID NUMBER.
956	002262	000000				HALT				:STOP EVERY THING.
957	002264	000776				BR	.-2			:RESTART THE PROGRAM AGAIN.
958	002266	117737	176710	001300	2\$:	MOVB	QSWR,DVACTV			:GET NEW DEVICE PATTERN
959	002274	113700	001300			MOVB	DVACTV,RO			:SHOW THE USER WHAT HE SELECTED.
960	002300	042700	177400			BIC	#1C<377>,RO			:USE ONLY LOW BYTE.
961	002304	000000				HALT				:CONTINUE DYNAMIC SWITCHES.
962	002306	012700	000300		3\$:	MOV	#300,RO			:PREPARE TO CLEAR THE FLOATING
963	002312	012701	000302			MOV	#302,R1			:VECTOR AREA. 300-776
964	002316	010120			4\$:	MOV	R1,(R0)+			:START PUTTING "PC+2 - HALT"
965	002320	005021				CLR	(R1)+			:IN VECTOR AREA.
966	002322	022021				CMR	(R0)+,(R1)+			:POP POINTERS
967	002324	022700	001000			CMR	#1000,RO			:ALL DONE??
968	00233C	001372				BNE	4\$:BR IF NO.
969										
970										
971										
972										
973	002332	012737	000340	177776	.BEGIN:	MOV	#340,PS			:LOCK OUT INTERRUPTS
974	002340	012706	001200			MOV	#STACK,SP			:SET UP STACK
975	002344	005737	000042			TST	Q#42			:IS PROGRAM UNDER MONITOR CONTROL
976	002350	001023				BNE	3\$:BR IF YES
977	002352	032777	000004	176622		BYT	#BIT2,QSWR			:CHECK FOR LOCK ON TEST
978	002360	001411				BEG	1\$:BR IF NO LOCK DESIRED.
979	002362	104402	005301			TYPE	.MLOCK			:TYPE LOCK SELECTED.
980	002366	012737	000240	002702		MOV	#NOP,TTST			:ADJUST SCOPE ROUTINE.
981	002374	012737	000240	002704		MOV	#NOP,TTST+2			:SET UP TO LOCK
982	002402	000406				BR	2\$:CONTINUE ALONG.
983	002404	013737	003014	002702	1\$:	MOV	BRW,TTST			:PREPARE NORMAL SCOPE ROUTINE
984	002412	013737	003016	002704		MOV	BRX,TTST+2			:LOCK NOT SELECTED. SET UP FOR NORMAL SCOPE LOOP
985	002420				2\$:					
986	002420	012737	005666	001214	3\$:	MOV	#CYCLE,RETURN			:START AT "CYCLE" FIND WHICH DEVICE TO TEST
987	002426	104402	005171		4\$:	TYPE	MR			:TYPE R
988	002432	000177	176556			JMP	QRETURN			:START TESTING

:TEST START AND RESTART

```

999          :END OF PASS
990          :TYPE NAME OF TEST
991          :UPDATE PASS COUNT
992          :CHECK FOR EXIT TO ACT-11
993          :RESTART TEST
994
995 002436 000005          .EOP:  RESET          :MAKE THE WORLD CLEAN AGAIN.
996 002440 005037 001234 CLR          LSTERR          :CLEAR LAST ERROR PC
997 002444 105037 001311 CLRB         ERRFLG          :CLEAR ERROR FLAG
998 002450 005237 001230 INC          PASCNT          :UPDATE PASS COUNT
999 002454 013777 001230 176515 MOV         PASCNT, @LIGHTS :DISPLAY PASS COUNT
1000 002452 104402 005145 TYPE         ,MEPASS        :TYPE END PASS
1001 002456 104402 005330 TYPE         ,MCSR          :TYPE CSR
1002 002472 104411 002604 CNVRT        ,XCSR          :SHOW IT
1003 002476 104402 005336 TYPE         ,MVECX         :TYPE VECTOR
1004 002502 104411 002612 CNVRT        ,XVEC          :SHOW IT
1005 002506 104402 005344 TYPE         ,MPASSX        :TYPE PASSES
1006 002512 104411 002620 CNVRT        ,XPASS         :SHOW IT
1007 002516 104402 005355 TYPE         ,MERRX        :TYPE ERRORS
1008 002522 104411 002626 CNVRT        ,XERR          :SHOW IT
1009 002526 105337 001303 DECB        SAVNUM         :ARE ALL DEVICES TESTED?
1010 002532 001017          BNE          RESTR         :BR IF NO.
1011 002534 112737 000377 001313 MOVB        #377, @V.FLG     :SET THE QUICK VERIFY FLAG.
1012 002542 113737 001301 001303 MOVB        DVNUM, SAVNUM   :RESTORE THE COUNT
1013 002550 013701 000042 MOV         @#42, R1        :CHECK FOR ACT-11 OR DDP
1014 002554 001406          BEQ          RESTR         :IF NOT, CONTINUE TESTING
1015 002556 000005          RESET          :STOP THE SHOW--CLEAR THE WORLD
1016
1017          LOGICAL:      JSR          PC, (R1)
1018 002562 000240          NOP
1019 002564 000240          NOP
1020 002566 000240          NOP
1021 002570 000240          NOP
1022 002572 012737 005666 001214 RESTR:  MOV         #CYCLE, RETURN
1023 002600 000137 005666          JMP          CYCLE
1024 002604 000001          XCSR:      1
1025 002606          006          002          .BYTE      6.2
1026 002610 001362          DVSCR
1027 002612 000001          XVEC:      1
1028 002614          003          002          .BYTE      3.2
1029 002616 001352          DVRVEC
1030 002620 000001          XPASS:     1
1031 002622          006          002          .BYTE      6.2
1032 002624 001230          XERR:      !
1033 002626 000001          .BYTE      6.2
1034 002630          006          002          .BYTE      6.2
1035 002632 001232          ERRCNT
1036
1037          :SCOPE LOOP AND INTERATION HANDLER
1038          -----
1039
1040          .SCOPE:
1041 002634 022737 177570 001202 CMP         #177570, SWR     :IS THERE A REAL SWR?
1042 002642 001411          BEQ         645           :BR IF YES
1043 002644 017746 176336 MOV         @TKOBR, -(SP)   :SAVE KEYBOARD CHAR
1044 002650 042716 000200 BIC         #BIT7, (SP)    :CLEAR PARITY BIT
  
```

K02

DZDVS MACY11 27,732) 17-SEP-76 11:14 PAGE 25
 DZDV8B.P11 GENERAL UTILITIES (TYPE OUT,ERROR,SCOPE,ETC.)

```

1045 002654 122726 000007      CMPB    #7,(SP)+      ;WAS IT CNTRL 'G' ?
1046 002660 001002      BNE     .+6          ;BR IF NO.
1047 002662 004737 004640      JSR    PC,SERV.G    ;SERVICE "CNTRL 'G'".
1048 002666 005037 001234      CLR    LSTERR       ;CLEAR LAST ERROR PC.
1049 002672 010016      MOV    R0,(SP)      ;SAVE R0 ON THE STACK
1050 002674 032777 040000 176300  BIT    #BIT14,ASWR  ;"LOOP ON THIS TEST"?
1051 002702 001407      BEQ    1$           ;BR IF NO. (IF LOCK SW01=1; THIS LOC =240)
1052 002704 000437      BR     3$           ;GOTO 3$ (IF LOCK SW01=1; THIS LOC =240)
1053 002706 105777 176272      TSTB   @TKCSR       ;KEYBOARD DONE?
1054 002712 100034      BPL    3$           ;BR IF NO. (LOCK: HIT KEY TO GOTO NEXT TEST)
1055 002714 017700 176266      MOV    @TKDBR,R0    ;CLEAR DONE BIT
1056 002720 000415      BR     2$           ;CONTINUE
1057 002722 032777 004000 176252  1$:   BIT    #SW11,ASWR  ;DELETE ITERATION? (QUICK PASS)
1058 002730 001011      BNE    2$           ;BR IF YES
1059 002732 105737 001313      TSTB   QV.FLG       ;HAVE PASSES BEECOMPLETED?
1060 002736 001406      BEQ    2$           ;BR IF QUICK PASS.
1061 002740 005237 001224      INC    LPCNT         ;UPDATE ITERATION COUNTER
1062 002744 023737 001224 001222  CMP    LPCNT,ICOUNT ;ARE ALL ITERATIONS DONE??
1063 002752 001014      BNE    3$           ;BR IF NOT YET
1064 002754 105037 001311      CLRB   ERRFLG       ;PREPARE FOR NEW TEST
1065 002760 005037 001224      CLR    LPCNT        ;START ICOUNTER AT 0
1066 002764 005037 001220      CLR    LOCK         ;
1067 002770 012737 000020 001222  MOV    #20,ICOUNT   ;RESET ITERATIONS
1068 002776 013737 001216 001214  MOV    NEXT,RETURN  ;GET NEXT TEST
1069 003004 011600      MOV    (SP),R0      ;POP R0 OFF OF THE STACK
1070 003006 022626      POP2SP              ;FAKE AN "RTI"
1071 003010 000177 176200      JMP    @RETURN      ;GO DO THE TEST
1072 003014 001407      BRW:  1407          ;
1073 003016 000437      BRX:  437           ;
1074
1075
1076
1077
1078 003020 032777 001000 176154  .SCOPE: BIT    #SW09,ASWR  ;IS SW09=1 (SET)?
1079 003026 001405      BEQ    1$           ;BR IF NOT SET.
1080 003030 005737 001220      TST    LOCK         ;
1081 003034 001402      BEQ    1$           ;
1082 003036 013716 001220      MOV    LOCK,(SP)    ;GOTO THE ADDRESS IN LOCK.
1083 003042 000002      1$:   RTI           ;GO BACK.
1084
1085
1086
1087
1088 003044 010546      .TYPE: MOV    R5,-(SP)  ;SAVE R5 ON THE STACK.
1089 003046 017605 000002      MOV    @2(SP),R5    ;GET ADDRESS OF MESSAGE.
1090 003052 062766 000002 000002  ADD    #2,2(SP)      ;POP OVER ADDRESS.
1091 003060 032777 010000 176114  1$:   BIT    #SW12,ASWR  ;INHIBIT ALL PRINT OUT??
1092 003066 001012      BNE    3$           ;BR IF NO PRINT OUT WANTED (SW12=1)
1093 003070 105715      TSTB   (R5)         ;IS NUMBER MINUS? (MSB=1(BIT7))
1094 003072 100002      BPL    2$           ;BR IF NUMBER IS PLUS
1095 003074 104402 005104      TYPE   MCRLF        ;TYPE A CR/LF!
1096 003100 105777 176104      2$:   TSTB   @TPCSR    ;TTY READY?
1097 003104 100375      BPL    2$           ;BR IF NO.
1098 003106 112577 176100      MOVB   (R5)+,@TPDBR ;PRINT CURRENT CHAR.
1099 003112 001362      BNE    1$           ;IF NOT ZERO KEEP PRINTING!
1100 003114 012605      3$:   MOV    (SP)+,R5  ;END OF OUTPUT. RESTORE R5

```



```

1101 003116 000002          RTI          :GO HOME
1102          :-----:
1103
1104 003120 010346          .INSTR: MOV      R3,-(SP)          :SAVE R3 ON STACK
1105 003122 010446          MOV      R4,-(SP)          :SAVE R4 ON STACK
1106 003124 017637 000004 003142  MOV      @4(SP),.MSG
1107 003132 062766 000002 000004  ADD      #2,4(SP)
1108 003140 104402          .INST1: TYPE
1109 003142 000000          .MSG:  C
1110 003144 012704 005520  MOV      #INBUF,R4
1111 003150 012703 000007  MOV      #7,R3
1112 003154 105777 176024  1$:  TSTB  @TKCSR
1113 003160 100375          SPL      1$
1114 003162 117714 176020  MOVB    @TKDBR,(R4)
1115 003166 142714 000200  BICB    #20,(R4)
1116 003172 122427 000015  CMPB    (R4)+,#15
1117 003176 001417          BEQ     INSTR2
1118 003200 105777 176004  2$:  TSTB  @TPCSR
1119 003204 100375          BPL     2$
1120 003206 017777 175774 175776  MOV      @TKDBR,@TPDBR
1121 003214 005303          DEC     R3
1122 003216 001356          BNE     1$
1123 003220 012604          MOV     (SP)+,R4
1124 003222 012603          MOV     (SP)+,R3
1125 003224 104402 005100  .INSTE: TYPE  MQM
1126 003230 010346          MOV     R3,-(SP)
1127 003232 010446          MOV     R4,-(SP)
1128 003234 000741          BR     .INST1
1129 003236 012604  INSTR2: MOV    (SP)+,R4          :RESTORE R4
1130 003240 012603          MOV    (SP)+,R3          :RESTORE R3
1131 003242 000002          RTI
1132
1133          ;CONVERT ASCII STRING TO OCTAL
1134          :-----:
1135
1136 003244 010546          .PARAM: MOV     R5,-(SP)
1137 003246 010446          MOV     R4,-(SP)
1138 003250 016605 000004  MOV     4(SP),R5
1139 003254 012537 003434  MOV     (R5)+,LOLIM
1140 003260 012537 003436  MOV     (R5)+,HILIM
1141 003264 012537 003440  MOV     (R5)+,DEVADR
1142 003270 112537 003442  MOVB   (R5)+,LOBITS
1143 003274 112537 003443  MOVB   (R5)+,ADRCNT
1144 003300 010566 000004  MOV     R5,4(SP)
1145 003304 005005  PARAM1: CLR     R5
1146 003306 012704 005520  MOV     #INBUF,R4
1147 003312 122714 000015  CMPB   #15,(R4)
1148 003316 001420          BEQ    PARERR
1149 003320 121427 000060  1$:  CMPB   (R4),#60
1150 003324 002415          BLT    PARERR
1151 003326 121427 000067  CMPB   (R4),#67
1152 003332 003012          BGT    PARERR
1153 003334 142714 000060  BICB   #60,(R4)
1154 003340 152405          BISB   (R4)+,R5
1155 003342 122714 000015  CMPB   #15,(R4)
1156 003346 001406          BEQ    LIMITS

```

M02

DZDV8 MACY11 27(732) 17-SEP-75 11:14 PAGE 27
 DZDV88.P11 GENERAL UTILITIES (TYPE OUT,ERROR,SCOPE,ETC.)

```

1157 003350 006305          ASL      R5
1158 003352 006305          ASL      R5
1159 003354 006305          ASL      R5
1160 003356 000760          BR       1$
1161 003360 104404          PARERR: INSTER
1162 003362 000750          BR       PARAM1
1163
1164          :TEST TO SEE IF NUMBER IS WITHIN LIMITS
1165          :-----
1166
1167 003364 020537 003436      LIMITS: CMP      R5,HILIM
1168 003370 101373          BHI      PARERR
1169 003372 020537 003434      CMP      R5,LOLIM
1170 003376 103770          BLO      PARERR
1171 003400 133705 003442      BITB     LOBITS,R5
1172 003404 001365          BNE      PARERR
1173
1174          :STORE NUMBER AT SPECIFIED ADDRESS
1175
1176 003406 013704 003440          1$:  MOV      DEVADR,R4
1177 003412 010524          MOV      R5,(R4)+
1178 003414 062705 000002      ADD      #2,R5
1179 003420 105337 003443      DECB     ADRCNT
1180 003424 001372          BNE      1$
1181 003426 012604          MOV      (SP)+,R4
1182 003430 012605          MOV      (SP)+,R5
1183 003432 000002          RTI
1184 003434 000000      LOLIM:  0
1185 003436 000000      HILIM:  0
1186 003440 000000      DEVADR: 0
1187 003442 000000      LOBITS: 0
1188          ADRCNT=LOBITS+1
1189
1190          ;SAVE PC OF TEST THAT FAILED AND R0-R5
1191          :-----
1192
1193 003444 016637 000004 001276 .SAV05: MOV      4(SP),SAVPC      ;SAVE R7 (PC)
1194
1195          ;SAVE R0-R5
1196
1197 003452 010537 001272      SV05:  MOV      R5,SAVR5      ;SAVE R5
1198 003456 010437 001270      MOV      R4,SAVR4      ;SAVE R4
1199 003462 010337 001266      MOV      R3,SAVR3      ;SAVE R3
1200 003466 010237 001264      MOV      R2,SAVR2      ;SAVE R2
1201 003472 010137 001262      MOV      R1,SAVR1      ;SAVE R1
1202 003476 010037 001260      MOV      R0,SAVR0      ;SAVE R0
1203 003502 000002          RTI          ;LEAVE.
1204
1205          ;RESTORE R0-R5
1206
1207 003504 013700 001260      .RES05: MOV      SAVR0,R0      ;RESTORE R0
1208 003510 013701 001262      MOV      SAVR1,R1      ;RESTORE R1
1209 003514 013702 001264      MOV      SAVR2,R2      ;RESTORE R2
1210 003520 013703 001266      MOV      SAVR3,R3      ;RESTORE R3
1211 003524 013704 001270      MOV      SAVR4,R4      ;RESTORE R4
1212 003530 013705 001272      MOV      SAVR5,R5      ;RESTORE R5

```

```

1213 003534 000002          RTI          ;LEAVE
1214
1215          ;CONVERT OCTAL NUMBER TO ASCII AND OUTPUT TO TELEPRINTER
1216          ;-----
1217
1219 003536 104402 005104 .CONVR: TYPE      ,MCRLF
1219 003542 010046 .CNVRT: MOV       R0,-(SP)
1220 003544 010146      MOV       R1,-(SP)
1221 003546 010346      MOV       R3,-(SP)
1222 003550 010446      MOV       R4,-(SP)
1223 003552 010546      MOV       R5,-(SP)
1224 003554 017601 000012      MOV       @12(SP),R1
1225 003560 062766 000002 000012      ADD       #2,12(SP)
1226 003566 012137 003742      MOV       (R1)+,WRDCNT
1227 003572 112137 003744 1$:      MOVB     (R1)+,CHRCNT
1228 003576 112137 003745      MOVB     (R1)+,SPACNT
1229 003602 013137 003746      MOV       @2(R1)+,BINWRD
1230 003606 013704 003746 2$:      MOV       BINWRD,R4
1231 003612 113705 003744      MOVB     CHRCNT,R5
1232 003616 012700 005562      MOV       #TEMP,R0
1233 003622 010403 3$:      MOV       R4,R3
1234 003624 042703 177770      BIC      #177770,R3
1235 003630 062703 000060      ADD      #060,R3
1236 003634 110320      MOVB     R3,(R0)+
1237 003636 000241      CLC
1238 003640 006004      ROR     R4
1239 003642 000241      CLC
1240 003644 006004      ROR     R4
1241 003646 000241      CLC
1242 003650 006004      ROR     R4
1243 003652 005305      DEC     R5
1244 003654 001362      BNE     3$
1245 003656 012703 005624      MOV     #MDATA,R3
1246 003662 114023 4$:      MOVB     -(R0),(R3)+
1247 003664 105337 003744      DECB    CHRCNT
1248 003670 001374      BNE     4$
1249 003672 105737 003745      TSTB    SPACNT
1250 003676 001405      BEQ     6$
1251 003700 112723 000040 5$:      MOVB     #040,(R3)+
1252 003704 105337 003745      DECB    SPACNT
1253 003710 001373      BNE     5$
1254 003712 105013 6$:      CLRB    (R3)
1255 003714 104402 005624      TYPE    ,MDATA
1256 003720 005337 003742      DEC     WRDCNT
1257 003724 001322      BNE     1$
1258 003726 012605      MOV     (SP)+,R5
1259 003730 012604      MOV     (SP)+,R4
1260 003732 012603      MOV     (SP)+,R3
1261 003734 012601      MOV     (SP)+,R1
1262 003736 012600      MOV     (SP)+,R0
1263 003740 000002      RTI
1264 003742 000000      WRDCNT: 0
1265 003744 000000      CHRCNT: 0
1266          003745      SPACNT=CHRCNT+1
1267 003746 000000      BINWRD: 0
1268

```

:TRAP DISPATCH SERVICE
:ARGUMENT OF TRAP IS EXTRACTED
:AND USED AS OFFSET TO OBTAIN POINTER
:TO SELECTED SUBROUTINE

000000	011146	000000	.TRPSR:	MOV	(SP) -(SP)	:GET PC OF RETURN
000000	162716	000000		SUB	#2,(SP)	:PC OF TRAP
000000	011716	000000		MOV	2(SP),(SP)	:GET TRP
000000	006316		TRPCK:	ASL	(SP)	:MULTIPLY TRAP ARG BY 2
000000	042716	177001		BIC	#177001,(SP)	:CLEAR UNWANTED BITS
000000	062716	001314		ADD	#.TRPTAB,(SP)	:POINTER TO SUBROUTINE ADDRESS
000000	011716	000000		MOV	2(SP),(SP)	:SUBROUTINE ADDRESS
004000	000136			JMP	2(SP)+	:GO TO SUBROUTINE

:-----
:ERROR HANDLER
:-----

004000	022737	177570	001202	.HLT:	CMP	#177570,SWR	:IS THERE A REAL SWR?
004000	001411				BEQ	64\$:BR IF YES
004010	017746	175170			MOV	2TKDBR,-(SP)	:SAVE KEYBOARD CHAR
004016	042716	000200			BIC	#BIT7,(SP)	:CLEAR PARITY BIT
004022	122726	000007			CMPB	#7,(SP)+	:WAS IT CNTRL 'G'?
004026	001002				BNE	+6	:BR IF NO.
004030	004737	00464C			JSR	PC,SERV.G	:SERVICE "CNTRL 'G'".
004034	032777	C10000	175140	64\$:	BIT	#SW12,2SWR	:BELL ON ERROR?
004042	001406				BEQ	XBX	:BR IF NO BELL
004044	105777	175140			TSTB	2TPCSR	:TTY READY.
004050	100003				BPL	XBX	:DON'T WAIT IF TTY NOT READY.
004052	112777	000207	175132		MOVB	#207,2TPDBR	:PUSH A BELL AT THE TTY.
004060	032777	020000	175114	XBX:	BIT	#SW13,2SWR	:DELETE ERROR PRINT OUT?
004066	001105				BNE	HALTS	:BR IF NO PRINT OUT WANTED.
004070	021637	001234			CMP	(SP),LSTERR	:WAS THIS ERROR FOUND LAST TIME?
004074	001404				BEQ	1\$:BR IF YES
004076	011637	001234			MOV	(SP),LSTERR	:RECORD BEING HERE
004102	105037	001311			CLRB	ERRFLG	:PREPARE HEADER
004106	104406			1\$:	SAV05		:SAVE ALL PROC REGISTERS
004110	011605				MOV	(SP),R5	:GET THE PC OF ERROR
004112	162705	000002			SUB	#2,R5	:GET ADDRESS OF TRAP CALL
004116	011504				MOV	(R5),R4	:GET HLT INSTRUCTION
004120	006304				ASL	R4	:MULT BY TWO
004122	061504				ADD	(R5),R4	:DOUBLE IT
004124	006304				ASL	R4	:MULT AGAIN
004126	042704	177001			BIC	#177001,R4	:CLEAR JUNK
004132	062704	023056			ADD	#.ERRTAB,R4	:GET POINTER
004136	012437	004252			MOV	(R4)+,ERRMSG	:GET ERROR MESSAGE
004142	012437	004264			MOV	(R4)+,DATAHD	:GET DATA HEADER
004146	011437	004276			MOV	(R4),DATABP	:GET DATA TABLE
004152	105737	001311			TSTB	ERRFLG	:TYPE HEADREER
004156	001403				BEQ	TYPMSG	:BR IF YES
004160	005737	004276			TST	DATABP	:DOES DATA TABLE EXIST?
004164	001040				BNE	TYPDAT	:BR IF YES.
004166	104402	005104		TYPMSG:	TYPE	,MCALF	
004172	104402	005104			TYPE	,MCALF	
004176	005737	001220			TST	LOCK	

```

1325 004202 001402 BEQ 15
1326 004204 104402 005400 TYPE .MASTEK
1327 004210 104402 005366 15: TYPE .MTSTN
1328 004214 104411 004374 CNVRT .XTSTN :SHOW IT
1329 004220 104402 005454 TYPE .MERRPC :TYPE PC.
1330 004224 104411 004366 CNVRT .ERTABO :SHOW IT
1331 004230 104402 005104 TYPE .MCRLF :GIVE A CR/LF
1332 004234 112737 174630 CO1311 MOVB #-1,ERRFLG :NO MORE HEADER UNLESS NO DATA TABLE.
1333 004242 005737 004252 TST ERRMSG :IS THERE AN ERROR MESSAGE?
1334 004246 001402 BEQ WRKO.FM :BR IF NO.
1335 004250 104402 TYPE :TYPE
1336 004252 000000 ERRMSG: 0 :ERROR MESSAGE
1337 004254 005737 004264 WRKO.FM: TST DATAHD :DATA HEADER?
1338 004260 001402 BEQ TYPDAT :BR IF NO
1339 004262 104402 TYPE :TYPE
1340 004264 000000 DATAHD: 0 :DATA HEADER
1341 004266 005737 004276 TYPDAT: TST DATABP :DATA TABLE?
1342 004272 001402 BEQ RESREG :BR IF NO.
1343 004274 104410 CNVRT :SHOW
1344 004276 000000 DATABP: 0 :DATA TABLE
1345 004300 104407 RESREG: RESOS :RESTORE PROC REGISTERS
1346 004302 005737 174674 HALTS: TST #SWR :HALT ON ERROR?
1347 004306 100005 BPL EXITER :BR IF NO HALT ON ERROR
1348 004310 010046 PUSHRO :SAVE RO
1349 004312 016600 000002 MOV 2(SP),RO :SHOW ERROR PC IN DATA LIGHTS
1350 004316 000000 HALT :HALT
1351 004320 012600 POPRO :GET RO
1352 004322 005237 001232 EXITER: INC ERRCNT :UPDATE ERROR COUNT
1353 004326 032777 000400 174646 BIT #SWOB,#SWR :GOTO TOP OF TEST?
1354 004334 001007 BNE 15 :BR IF YES
1355 004336 032777 002000 174636 BIT #SWIO,#SWR :GOTO NEXT TEST?
1356 004344 001407 BEQ 25 :BR IF NO
1357 004346 013737 001216 001214 MOV NEXT,RETURN :SET FOR NEXT TEST
1358 004354 012706 001200 15: MOV #STACK,SP :RESET SP
1359 004360 000177 174630 JMP #RETURN :GOTO SPECIFIED TEST
1360 004364 000002 25: RTI :RETURN
1361 004366 000001 ERTABO: 1
1362 004370 006 002 .BYTE 6,2
1363 004372 001276 SAVPC
1364 004374 000001 XTSTN: 1
1365 004376 003 002 .BYTE 3,2
1366 004400 001226 TSTNO
1367 :ENTER HERE ON POWER FAILURE
1368 :-----
1369
1370
1371
1372 004402 .PFAIL:
1373 004402 012737 004414 000024 MOV #RESTART,24 :SET UP FOR POWER UP TRAP
1374 004410 000000 HALT :HALT ON POWER DOWN NORMAL
1375 004412 000777 BR .
1376 ;PROCESSOR WILL TRAP HERE WHEN POWER IS RESTORED
1377
1378
1379 004414 RESTAR:
1380 004414 012737 004402 000024 MOV #.PFAIL,24 :SET UP FOR POWER FAILRE

```

```

00442 012706 001200 MOV #STACK, SP ; RESET THE STACK POINTER
00442 005037 005562 CLR TEMP ; READY FOR TIMER
00442 005237 005562 INC TEMP ; PLUS ONE TO THE TIMER!
00442 001375 BNE .-4 ; BR IF MORE TO GO
00442 104402 005107 TYPE .MPFAIL ; TYPE THE MESSAGE
00444 104411 004470 CNVRT PFTAB ; TELL WHAT TEST TO RETURN TO.
00445 105037 001311 CLR ERRFLG ; START CLEAN
00445 005037 001234 CLR LSTERR ; .....
00446 104412 MSTCLR ; START CLEAN UP OF DEVICE
00446 104413 RAMCLR ; CLEAR IT ALL!
00446 000177 174524 JMP JRETURN ; START DOING THAT TEST AGAIN.
00447 000001 PFTAB: 1
00447 003 002 .BYTE 2
00447 001226 TSTNO
00447 010046 .DELAY: MOV RO, -(SP)
00450 013700 004514 MOV R0, R0
00450 005330 DEC R0
00450 001376 BNE .-2
00450 012600 MOV (SP)+, R0
00451 000002 RTS
00451 000036 IS: 30.

.RAMCLR:
00451 012777 004000 174536 MOV #MRESET, DVSCR ; ISSUE A MASTER CLEAR
00452 010146 MOV R1, -(SP) ; SAVE R1 ON THE STACK
00452 010446 MOV R4, -(SP) ; SAVE R4 ON THE STACK
00453 013701 001372 MOV DVSR5, R1 ; GET SECONDARY SEL. REG.
00453 013704 001376 MOV DVSR4, R4 ; GET SECONDARY REGISTER ACCESS REG.
00454 005014 IS: CLR (R4) ; ZERO THE SECONDARY REGISTER.
00454 062711 170361 ADD #1<BIT11+BIT10+BIT9+BIT8+BIT3+BIT2+BIT1+BIT0>, R1
00454 001374 BNE IS
00455 012604 MOV (SP)+, R4 ; RESTORE R4
00455 012601 MOV (SP)+, R1 ; RESTORE R1
00455 000002 RTS

.MSTCLR:
00455 012777 004000 174576 MOV #MRESET, DVSCR ; ISSUE MASTER CLEAR.
00456 000002 RTS

.RAMCLK:
00456 052777 000002 174566 BIS #BIT1, DVSCR
00457 000002 RTS

.DATACLK:
00457 010046 MOV RO, -(SP)
00460 005000 CLR RO
00460 052777 000400 174560 BIS #BIT8, DVLCR
00461 017737 174554 004636 IS: MOV DVLCR, R0
00461 106037 RORB R0, R0
00462 103003 BCC R0, R0
00462 005200 INC R0
00462 001370 BNE IS
00463 104000 HLT
00463 012600 2$: MOV (SP)+, R0
00463 000002 RTS
00463 000001 3$: .9LKW ;

```

E03

```

1437
1438 004640 032777 004000 174336 SERV.G: BIT #4000,@TKCSR :RX BUSY?
1439 004646 001374 BNE SERV.G :BR IF YES
1440 004650 017737 174326 005072 174316 1S: MOV @SWR,90$ :SAVE (SWR).
1441 004656 013777 005072 174316 1S: MOV 90$,@SWR
1442 004664 104402 005052 TYPE .89$
1443 004670 104411 005064 CNVRT .88$
1444 004674 104402 005074 TYPE .91$
1445 004700 105777 174300 TSTB @TKCSR :WAIT FOR DONE.
1446 004704 100375 BPL -4
1447 004706 017746 174274 MOV @TKDBR,-(SP)
1448 004712 042716 000200 BIC #BIT7,(SP)
1449 004716 122726 000015 CMPB #15,(SP)+
1450 004722 001450 BEQ 5$
1451 004724 005077 174252 CLP @SWR
1452 004730 105777 174254 2S: TSTB @TPCSR
1453 004734 100375 BPL -4
1454 004736 016677 177776 174246 MOV -2(SP),@TFDBR
1455 004744 000241 CLC
1456 004746 006177 174230 ROL @SWR
1457 004752 006177 174224 ROL @SWR
1458 004756 006177 174220 ROL @SWR
1459 004762 103735 BCS 1$
1460 004764 026627 177776 000060 CMP -2(SP),#60 :ERROR
1461 004772 002731 BLT 1$
1462 004774 026627 177776 000067 CMP -2(SP),#67
1463 005002 003325 BGT 1$
1464 005004 042766 177770 177776 BIC #10(7),-2(SP)
1465 005012 056677 177776 174162 BIS -2(SP),@SWR
1466 005020 105777 174160 TSTB @TKCSR
1467 005024 100375 BPL -4
1468 005026 017746 174154 MOV @TKDBR,-(SP)
1469 005032 042716 000200 BIC #BIT7,(SP)
1470 005036 122726 000015 CMPB #15,(SP)+
1471 005042 001332 BNE 2$
1472 005044 104402 005104 5S: TYPE @MCRLF
1473 005050 000207 RTS PC
1474
1475 005052 020377 051450 051127 89$: .ASCIZ <377>? (SWR)=/?
1476 005060 036451 000057
1477 .EVEN
1478 005064 000001 89$: !
1479 005066 006 000 .BYTE 6,0
1480 005070 005072 90$:
1481 005072 000000 90$: .WORD 0
1482 005074 036457 000057 91$: .ASCIZ ?/?
1483 .EVEN
1484 005100 020040 000077 MQM: .ASCIZ / ?/
(2) 005104 005015 000 MCRLF: .ASCIZ <15><12>
(2) 005107 377 053520 020122 MPFAIL: .ASCIZ <377>/PWR FAILED. RESTART AT TEST /
(2) 005145 377 047105 020104 MEPASS: .ASCIZ <377>/END PASS DZDVB-B /
(2) 005171 377 000122 MR: .ASCIZ <377>/R/
(2) 005174 050377 047522 051107 MERR2: .ASCIZ <377>/PROGRAM INDICATES NO DEVICES PRESENT./
(2) 005242 377 047111 052523 MERR3: .ASCIZ <377>/INSUFFICIENT DATA!/
(2) 005267 377 042624 052123 MTSTPC: .ASCIZ <377>/TEST PC-/
(2) 005301 377 047514 045503 MLOCK: .ASCIZ <377>/LOCK ON SELECTED TEST

```

```

005330 051503 035122 000040 MCSRX: .ASCIZ /CSR: /
005336 042526 035103 000040 MVECX: .ASCIZ /VEC: /
005344 040520 051523 051505 MPASSX: .ASCIZ /PASSES: /
005355 105 051122 05111 MERRX: .ASCIZ /ERRORS: /
005366 042524 052123 047040 MTSTN: .ASCIZ /TEST NO: /
005400 000052 MASTEK: .ASCIZ /*
005402 051777 052105 051440 MNEW: .ASCIZ <377> /SET SWITCH REG TO DV11'S DESIRED ACTIVE. /
005454 041520 020072 000 MERRPC: .ASCIZ /PC: /
005461 377 040515 020120 XHEAD: .ASCIZ <377> /MAP OF DV11 STATUS/<377>
      .EVEN
      XSTAT0: 2
      .BYTE 6.3
      TEMP1
      .BYTE 6.2
      TEMP2
      .EVEN
      :BUFFERS FOR INPUT-OUTPUT

005520 000000 INSLF: 0
      005552 . = +40
005562 000000 TEMP: 0
      005594 . = +40
005624 000000 MDATA: 0
      005656 . = +40

```


1500
1501
1502
1503
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522
1523
1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547
1548
1549
1550
1551
1552
1553
1554

```

005666 105737 001300
005672 001004
005674 104402 005174
005700 000000
005702 000776
005704 133737 001304 001300 1$:
005712 001020
005714 000241
005716 106137 001304
005722 105537 001304
005726 062737 000024 001306
005734 022737 001740 001306
005742 001360
005744 012737 001500 001306
005752 000754
005754 000241 2$:
005756 106137 001304
005762 105537 001304
005766 013700 001306
005772 062737 000024 001306
006000 022737 001740 001306

006006 001003
006010 012737 001500 001306 3$:
006016 012037 001362
006022 012037 001352
006026 012037 001416
006032 012037 001426
006036 012037 001420
006042 012037 001430
006046 012037 001422
006052 012037 001432
006056 012037 001424
006062 012037 001434
006066 012700 000002
006072 013737 001362 001364
006100 005237 001364
006104 013737 001364 001366
006112 005237 001366
006116 013737 001366 001370
006124 060037 001370
006130 013737 001370 001372
006136 060037 001372
006142 013737 001372 001374
006150 005237 001374
006154 013737 001374 001376
006162 005237 001376

```

```

CYCLE: TSTB DVACTV
BNE 1$
TYPE ,MERR2
HALT
BR .-2
BITB RUN,DVACTV
BNE 2$
CLC
ROLB RUN
ADCB RUN
ADD #24,CREAM
CMP #DV.END,CREAM
BNE 1$
MOV #DV.MAP,CREAM
BR 1$
2$: CLC
ROLB RUN
ADCB RUN
MOV CREAM,RC
ADD #24,CREAM
CMP #DV.END,CREAM

3$: BNE 3$
MOV #DV.MAP,CREAM
MOV (R0)+,DVSCR
MOV (R0)+,DVRVEC
MOV (R0)+,LO0.03
MOV (R0)+,SYNC2A
MOV (R0)+,LO4.07
MOV (R0)+,SYNC2B
MOV (R0)+,LO9.11
MOV (R0)+,SYNC2C
MOV (R0)+,L12.15
MOV (R0)+,SYNC2D
MOV #2,R0
MOV DVSCR,DVSCRH
INC DVSCRH
MOV DVSCRH,DVRIC
INC DVRIC
MOV DVRIC,DVLCR
ADD R0,DVLCR
MOV DVLCR,DVSRS
ADD R0,DVSRS
MOV DVSRS,DVSRSH
INC DVSRSH
MOV DVSRSH,DVSRA
INC DVSRA

```

```

:ROUTINE USED TO "CYCLE" THROUGH UP TO EIGHT DV11'S
:THIS ROUTINE SETS UP THE CONTROL ADDRESS FOR THE DIAGNOSTIC
:AND RUNS THE SPECIFIED DV11'S. THIS ROUTINE *MUST*
:BE RUN FIRST BEFORE ENTERING THE DIAGNOSTIC FOR THE
:SETUP NECESSARY.

:ARE ANY DV11'S TO BE TESTED?
:BR IF JK.
:NO DV11'S SELECTED!!
:STOP THE SHOW.
:DISQUALIFY CONT. SW.
:IS THIS ONE "ACTIVE"
:BR IF GOOD ONE FOUND.
:CLEAR PRCC. CARRY BIT.
:UPDATE POINTER
:CATCH CARRY FROM RUN
:UPDATE ADDRESS POINTER.

:KEEP GOING; NOT ALL TESTED FOR.
:RESET ADDRESS POINTER.
:KEEP LOOKING FOR ACTIVE DV11
:CLEAR PROC. CARRY.
:UPDATE POINTER.
:CATCH CARRY.
:GET ADDRESS POINTER.
:UPDATE.

:ALL DONE?
:BR IF NO.
:RESTORE POINTER.
:LOAD SYSTEM CTRL. REG
:LOAD VECTOR
:GET LINE PARAMETERS. 00-03
: 04-07
: 08-11
: 12-15

:SAVE CORE THIS WAY!
:GET SYS CTRL. REG HIGH BYTE.
:GOT IT.
:GET NXT REC. CHAR REG.
:GOT IT
:GET LN. PAR.REG.
:GOT IT
:GET SEC. REG. SEL. REG.
:GOT IT
:GET HIGH BYTE.
:GOT IT
:SEC. REG. ACCESS.
:GOT IT

```

H03

02216 MACY11 27(732) 17-SEP-76 11:14 PAGE 35
 022128.F11 GENERAL UTILITIES (TYPE OUT, ERROR, SCOPE, ETC.)

1555	006166	013737	001376	001400	MOV	DVSRA, DVSFR	: SPEC. FUN. REG.
1556	006174	060037	001400		ADD	RO, DVSFR	
1557	006200	013737	001400	001402	MOV	DVSFR, DVNSR	: NPR STAT. REG.
1558	006206	060037	001402		ADD	RO, DVNSR	
1559	006212	013737	001402	001404	MOV	DVNSR, RESV16	: RESERVED REG
1560	006220	060037	001404		ADD	RO, RESV16	
1561							
1562	006224	013737	001352	001354	MOV	DVRVEC, DVRLVL	: PTY LVL
1563	006232	060037	001354		ADD	RO, DVRLVL	
1564	006236	013737	001354	001356	MOV	DVRLVL, DVTVEC	: TX VEC
1565	006244	060037	001356		ADD	RO, DVTVEC	
1566	006250	013737	001356	001360	MOV	DVTVEC, DVTLVL	: TX LVL
1567	006256	060037	001360		ADD	RO, DVTLVL	
1568							
1569	006262	012700	001416		MOV	#L00.03, RO	: LOAD STAU0 00-03
1570	006266	012701	001406		MOV	#MASK.A, R1	: PREPARE MASK.
1571	006272	012702	001412		MOV	#CLK.A, R2	: PREPARE CLOCKS
1572	006276	004737	006516		JSR	PC, FIX.00	: GO AND CALCULATE CONFIGURATION.
1573							
1574	006302	012700	001420		MOV	#L04.07, RO	: LOAD STAU0 00-03
1575	006306	012701	001407		MOV	#MASK.B, R1	: PREPARE MASK.
1576	006312	012702	001413		MOV	#CLK.B, R2	: PREPARE CLOCKS
1577	006316	004737	006516		JSR	PC, FIX.00	: GO AND CALCULATE CONFIGURATION.
1578							
1579	006322	012700	001422		MOV	#L08.11, RO	: LOAD STAU0 00-03
1580	006326	012701	001410		MOV	#MASK.C, R1	: PREPARE MASK.
1581	006332	012702	001414		MOV	#CLK.C, R2	: PREPARE CLOCKS
1582	006336	004737	006516		JSR	PC, FIX.00	: GO AND CALCULATE CONFIGURATION.
1583							
1584	006342	012700	001424		MOV	#L12.15, RO	: LOAD STAU0 00-03
1585	006346	012701	001411		MOV	#MASK.D, R1	: PREPARE MASK.
1586	006352	012702	001415		MOV	#CLK.D, R2	: PREPARE CLOCKS
1587	006356	004737	006516		JSR	PC, FIX.00	: GO AND CALCULATE CONFIGURATION.
1588	006362	032777	000002	172612	BIT	#SW01, 2SWR	
1589	006370	001445			BEQ	7\$	
1590	006372						
1591	006372	005737	000042		TST	2*42	
1592	006376	001042			BNE	7\$	
1593	006400	104402	005104		TYPE	.MCRLF	
1594	006404	104403			INSTR		
1595	006406	005366			MTSTN		
1596	006410	104405			PARAM		
1597	006412	000001			1		
1598	006414	001000			1000		
1599	006416	001226			TSTNO		
1600	006420	000			0		
1601	006421	001			.BYTE		
1602	006422	012700	007256		MOV	#TST1, RO	
1603	006426	022710			CMP	(PC)+, (RO)	
1604	006430	012737			MOV	(PC)+, 2(PC)+	
1605	006432	001015			BNE	6\$	
1606	006434	023760	001226	000002	CMP	TSTNO, 2(RO)	
1607	006442	001011			BNE	6\$	
1608	006444	022760	001226	000004	CMP	#TSTNO, 4(RO)	
1609	006452	001005			BNE	6\$	
1610	006454	010037	001214		MOV	RO, RETURN	

```

1611 006460 104402 005104          TYPE      MCRLF
1612 006464 000412          BR        9$
1613 006466 005720          6$:      TST      (R0)+
1614 006470 020027 021754          CMP      R0, #TLAST+10
1615 006474 001354          BNE      5$
1616 006476 104402 005100          TYPE      MQM
1617 006502 000733          SR        4$
1618 006504 012737 007256 001214 7$:      MOV      #TST1, RETURN ;PREPARE RETURN ADDRESS
1619 006512 000177 172476          9$:      JMP      @RETURN ;GO START TESTING.
1620
1621 006516 011003          FIX.00: MOV      (R0), R3 ;GET PARAMETERS.
1622 006520 042703 176377          BIC      1400, R3 ;CLEAR JUNK.
1623 006524 005703          TST      R3 ;TEST FOR EIGHT BITS.
1624 006526 001004          BNE      1$ ;BR IF NOT 8 BITS.
1625 006530 105011          CLRB     (R1) ;SET
1626 006532 112712 000010          MOVB     #8., (R2) ;
1627 006536 000424          BR        4$ ;
1628 006540 022703 000400          1$:      CMP      #400, R3 ;CHECK FOR SEVEN BITS.
1629 006544 001005          BNE      2$ ;BR IF NOT 7 BITS.
1630 006546 112711 000200          MOVB     #200, (R1) ;
1631 006552 112712 000007          MOVB     #7., (R2) ;
1632 006556 000414          BR        4$ ;
1633 006560 022703 001000          2$:      CMP      #1000, R3 ;CHECK FOR SIX BITS.
1634 006564 001005          BNE      3$ ;BR IF NOT SIX BITS.
1635 006566 112711 000300          MOVB     #300, (R1) ;
1636 006572 112712 000006          MOVB     #6., (R2) ;
1637 006576 000404          BR        4$ ;
1638 006600 112711 000340          3$:      MOVB     #340, (R1) ;IF NONE OF THE ABOVE; MUST BE 5 BITS.
1639 006604 112712 000005          MOVB     #5., (R2) ;
1640 006610 032710 040000          4$:      BIT      #PARBIT, (R0) ;PARITY ENABLED?
1641 006614 001401          BEQ      5$ ;IF =0; THEN NO PARITY.
1642 006616 005212          INCB     (R2) ;PLUS ONE TO THE CLOCK!
1643 006620 000207          5$:      RTS      PC ;
1644
1645          ;*ROUTINE USED TO "AUTO SIZE" THE DV11
1646          ;*CSR AND VECTOR.
1647          ;*NOTE: THE CSR MAY BE ANY WHERE IN THE FLOATING
1648          ;* ADDRESS RANGE (175000:175400)
1649          ;* AND THE VECTOR MAY BE ANY WHERE IN THE
1650          ;* FLOATING VECTOR RANGE (300:770)
1651          ;*
1652
1653          AUTO.SIZE:
1654          006622 000005          RESET
1655          006624 012702 001500          CSRMAP: MOV      #DV.MAP, R2 ;INSURE A BUS INIT.
1656          006630 005022          1$:      CLR      (R2)+ ;LOAD MAP POINTER.
1657          006632 022702 001740          CMP      #DV.END, R2 ;ZERO ENTIRE MAP
1658          006636 001374          BNE      1$ ;ALL DONE?
1659          006640 105037 001301          CLRB     DVNUM ;BR IF NO
1660          006644 012702 001500          MOV      #DV.MAP, R2 ;SET OCTAL NUMBER OF DV11'S TO 0
1661          006650 012701 175000          MOV      #175000, R1 ;SET FOR FIRST ADDRESS TO BE TESTED
1662          006654 012737 007074 000004          MOV      #6$, @#4 ;SET FOR NON-EXISTANT DEVICE TIME OUT
1663          006662 005711          2$:      TST      (R1) ;IF DV11 DVSCR S'B 0
1664          006664 001037          BNE      3$ ;IF NO DEV ; TRAP TO 4. IF NO BIT 8 THEN NO DV11
1665          006666 022761 177777 000012          CMP      #177777, 12 R1) ;IF DV11 THEN DVSCR S'B ALL 1'S ON INIT!
1666          006674 001032          BNE      3$ ;BR IF NOT DV11

```

J03

DZDV8 MACY11 27.732) 17-SEP-76 11:14 PAGE 37
 DZDV8B.P11 GENERAL UTILITIES (TYPE OUT, ERROR, SCOPE, ETC.)

```

1667 006676 005761 000016          TST      16(R1)          ;IF DV11 THEN RESV16 S/B ALL 0'S
1668 006702 001030          BNE      3$            ;BR IF NOT DV11
1669          ;AT THIS POINT IT IS ASSUMED THAT R1 HOLDS A DV11 CSR ADDRESS.
1670 006704 010122          MOV      R1, (R2)+     ;STORE CSR IN CORE TABLE.
1671 006706 005722          TST      (R2)+        ;POP OVER VECTOR STORE AREA
1672 006710 052722 000226      BIS      #226, (R2)+   ;SET LINE CARD 1 STAT AND SYNC
1673 006714 052722 000062      SIS      #62, (R2)+   ;
1674 006720 052722 000226      BIS      #226, (R2)+   ;SET LINE CARD 2 STAT AND SYNC
1675 006724 052722 000062      BIS      #62, (R2)+   ;
1676 006730 052722 000226      BIS      #226, (R2)+   ;SET LINE CARD 3 STAT AND SYNC
1677 006734 052722 000062      BIS      #62, (R2)+   ;
1678 006740 052722 000226      BIS      #226, (R2)+   ;SET LINE CARD 4 STAT AND SYNC
1679 006744 052722 000062      SIS      #62, (R2)+   ;
1680 006750 05237 001301      INCB    DVNUM          ;UPDATE DEVICE COUNTER
1681 006754 122737 000010 001301  CMPB    #10, DVNUM     ;ARE MAX. NO. OF DEV FOUND?
1682 006762 001405          BEQ     100$          ;YES DON'T LOOK FOR ANY MORE.
1683 006764 062701 000010 3$:   ADD     #10, R1        ;UPDATE CSR POINTER ADDRESS
1684 006770 022701 175400      CMP     #175400, R1
1685 006774 001332          BNE     2$            ;BR IF MORE ADDRESS TO CHECK.
1686 006776 012722 177777 100$: MOV     #177777, (R2)+ ;TERMINATER.
1687 007002 105037 001300      CLRB   DVACTV        ;WERE ANY DV11'S FOUND AT ALL?
1688 007006 105737 001301      TSTB   DVNUM          ;ERROR AUTO SIZER FOUND NO DV11'S IN THIS SYS.
1689 007012 001423          BEQ     5$            ;
1690 007014 113701 001301      MOVSB  DVNUM, R1
1691 007020 110137 001303      MOVSB  R1, SAVNUM     ;SAVE NUMBER OF DEVICES
1692 007024 000241 4$:   CLC
1693 007026 106137 001300      ROLB   DVACTV        ;GENERATE ACTIVE REGISTER OF DEVICES.
1694 007032 105237 001300      INCB   DVACTV        ;SET THE BIT
1695 007036 005301          DEC     R1
1696 007040 001371          BNE     4$            ;BR IF MORE TO GENERATE
1697 007042 012737 000006 000004 MOV     #6, D#4        ;RESTORE TRAP VECTOR
1698 007050 113737 001300 001302 MOVSB   DVACTV, SAVACT ;SAVE ACTIVE REGISTER
1699 007056 000137 007102      JMP     VECMAP        ;GO FIND THE VECTOR NOW.
1700 007062 104402 005174 5$:   TYPE   MERR2        ;NOTIFY OPR THAT NO DV11'S FOUND.
1701 007066 005000          CLR     RO            ;MAKE DATA LIGHTS ZERO
1702 007070 000000          HALT
1703 007072 000776          BR     -2            ;STOP THE SHOW
1704 007074 012716 006764 6$:   MOV     #3$, (SP)     ;DISABLE CONT. SW.
1705 007100 000002          RTI                    ;ENTERED BY NON-EXISTANT TIME-OUT.
1706          ;RETURN TO MAINSTREAM
1707 007102 012737 000340 000022 VECMAP: MOV     #340, D#22 ;SET IOT TRAP PRIO TO 7
1708 007110 012737 007232 000020 MOV     #4$, D#20     ;SET IOT TRAP VECTOR
1709 007116 012702 001500          MOV     #DV. MAP, R2 ;SET SOFTWARE POINTER
1710 007122 012700 000300          MOV     #300, RO     ;FLOATING VECTORS START HERE.
1711 007126 012701 000302          MOV     #302, R1     ;PC OF IOT INSTR.
1712 007132 010120 1$:   MOV     R1, (RO)+     ;START FILLING VECTOR AREA
1713 007134 012721 000004          MOV     #4, (R1)+    ;WITH +2; IOT
1714 007140 022021          CMP     (RO)+, (R1)+ ;ADD 2 TO RO +R1
1715 007142 020127 001000          CMP     R1, #1000
1716 007146 101771          BLOS   1$            ;BR IF MORE TO FILL
1717 007150 113737 001300 001246 MOVSB   DVACTV, TEMP1 ;STORE TEMPORALLY
1718 007156 006037 001246 2$:   ROR    TEMP1        ;BRING OUT A BIT
1719 007162 103034          BCC    5$            ;BR IF ALL DONE
1720 007164 005037 177776          CLR     PS            ;ZERO CPU PRIO
1721 007170 012772 001300 000000 MOV     #BIT9+BIT7+BIT6, D(R2)
1722 007176 005000          CLR     RO            ;ATTEMPT TO FORCE AN INTERRUPT

```


1737
1738
1739
1740
1741
1742
1743
1744
1745
1746
1747
1748
1749
1750
1751
1752
1753
1754
1755
1756
1757
1758
1759
1760
1761
1762
1763
1764
1765
1766
1767
1768
1769
1770
1771
1772
1773
1774
1775
1776
1777
1778
1779
1780
1781
1782
1783
1784
1785
1786
1787
1788
1789
1790
1791
1792

***** TEST 1 *****
*TEST THAT "TRANSMITTER FLAG WAITING"
*IS TRUE AND THAT "RCV FLAG WAITING" IS
*FALSE AFTER AN INIT.
*THIS TEST WILL BE DONE FOR BOTH ASYNC AND SYNC LINE CARDS.

: TEST 1

TST1: MOV #1,TSTNO
MOV #TST2,NEXT
MOV #0,R0 ;PLACE LINE NUMBER INTO R0
MOV L00.03,STAT ;LOAD LINE CARD STATUS INTO STAT
BMI 100\$;BR IF LINE CARD NOT TO BE TESTED
JSR PC,105\$;GO DO THE TEST FOR LINE CARD 1
100\$: MOV #4,R0 ;PLACE LINE NUMBER INTO R0
MOV L04.07,STAT ;LOAD LINE CARD STATUS INTO STAT
BMI 101\$;BR IF LINE CARD NOT TO BE TESTED
JSR PC,105\$;GO DO THE TEST FOR LINE CARD 2
101\$: MOV #8,R0 ;LOAD LINE NUMBER
MOV L08.11,STAT ;LOAD LINE CARD STATUS INTO STAT
BMI 102\$;BR IF LINE CARD NOT TO BE TESTED
JSR PC,105\$;DO THE TEST FOR LINE CARD 3
102\$: MOV #12,R0 ;LOAD LINE NO.
MOV L12.15,STAT ;LOAD LINE CARD STATUS
BMI 103\$;BR IF LINE CARD NOT TO BE TESTED
JSR PC,105\$;DO THE TESTS FOR LINE CARD 4
103\$: SCOPE ;SCOPE THIS TEST.
105\$: ;TEST ENTRANCE.
RAMCLR ;CLEAR ALL DV11 SEC. REGS.
MOV R0,65\$;STORE LINE NO. POINTER.
CLR R1 ;ZERO MSCANNER POINTER
PERFORM ,SETSCAN ;POSITION SCANNER TO LINE NUMBER.
1\$: ;INITIAL LINE NUMBER HERE.
55\$: .BLKW 1 ;SET TO DO 4 LINES AT A TIME
2\$: MOV #4,R3 ;SET EXPECTED RESULTS IN R5
3\$: MOV #BIT1+BIT0,R5 ;BR-A "RX FLAG WAITING"?
MOV #BIT10,R2 ;LOAD DV11 INSTRUCTION
MOV R2,DV5FR ;READ BR TEST POINTS
MOV DVLCR,R4 ;TEST POINTS OK?
CMP R5,R4 ;BR IF YES
BEQ 4\$;EXPECT DVLCR BIT1+BIT0=1
1780: MOV #S.C+BIT6+BIT1,DV5FR ;S/C "ADVANCE SCANNER"
ROMCLK ;UPDATE MSCAN POINTER
INC R1 ;PREPARE TO SET LINE POINTER
MOV R1,R0 ;TO CORRECT POSITION
CLC ;
ROR R0 ;BR-A "TX FLAG WAITING"?
MOV #BIT9,R2 ;LOAD DV11 INSTRUCTION
MOV R2,DV5FR ;READ BR TEST POINT
MOV DVLCR,R4 ;SET EXPECTED RESULTS
MOV #BIT1,R5 ;TX FLAG WAITING TRUE?
CMP R5,R4 ;BR IF LCR BIT1=1 AND BIT0=0
BEQ 5\$;ERROR.
HLT 1

M03

```

1793 007512 012777 050102 171660 5$: MOV #S.C+BIT6+BIT1,ADVSR
1794 007520 104415 ROMCLK ;S/C "ADVANCE SCANNER"
1795 007522 005201 INC R1 ;UPDATE MSCAN POINTER
1796 007524 010100 MOV R1,R0 ;UPDATE LINE POINTER
1797 007526 000241 CLC ;
1799 007530 006000 ROR R0 ;
1799 007532 005303 DEC R3 ;ARE ALL 4 LINES TESTED?
1800 007534 001330 BNE 3$ ;BR IF NO!
1801 007536 000207 RTS PC ;CHECK NEXT SET OF LINES.
  
```

```

;*****TEST 2*****
;TEST THAT "MATCH DETECT" IS
;FALSE AFTER AN INIT.
;THIS TEST WILL BE DONE FOR BOTH ASYNC AND SYNC LINE CARDS.
;*****
  
```

: TEST 2

```

1812 007540 012737 000002 001226 tst2: MOV #2,TSTNO
1813 007546 012737 007742 001216 MOV #TST3,NEXT
1814 007554 012700 000000 MOV #0.,R0 ;PLACE LINE NUMBER INTO R0
1815 007560 013737 001416 001236 MOV L00.03,STAT ;LOAD LINE CARD STATUS INTO STAT
1816 007566 100402 BMI 100$ ;BR IF LINE CARD NOT TO BE TESTED
1817 007570 004737 007656 JSR PC,105$ ;GO DO THE TEST FOR LINE CARD 1
1818 007574 012700 000004 100$: MOV #4.,R0 ;PLACE LINE NUMBER INTO R0
1819 007600 013737 001420 001236 MOV L04.07,STAT ;LOAD LINE CARD STATUS INTO STAT
1820 007606 100402 BMI 101$ ;BR IF LINE CARD NOT TO BE TESTED
1821 007610 004737 007656 JSR PC,105$ ;GO DO THE TEST FOR LINE CARD 2
1822 007614 012700 000010 101$: MOV #8.,R0 ;LOAD LINE NUMBER
1823 007620 013737 001422 001236 MOV L08.11,STAT ;LOAD LINE CARD STATUS INTO STAT
1824 007626 100402 BMI 102$ ;BR IF LINE CARD NOT TO BE TESTED
1825 007630 004737 007656 JSR PC,105$ ;DO THE TEST FOR LINE CARD 3
1826 007634 012700 000014 102$: MOV #12.,R0 ;LOAD LINE NO.
1827 007640 013737 001424 001236 MOV L12.15,STAT ;LOAD LINE CARD STATUS
1828 007646 100402 BMI 103$ ;BR IF LINE CARD NOT TO BE TESTED
1829 007650 004737 007656 JSR PC,105$ ;DO THE TESTS FOR LINE CARD 4
1830 007654 104400 103$: SCOPE ;SCOPE THIS TEST.
1831 007656 105$: ;TEST ENTRANCE.
1832 007656 010037 007672 MOV R0,65$ ;SET LINE POINTER
1833 007662 104412 MSTCLR ;RESET THE DV11
1834 007664 005001 CLR R1 ;ZERO MSCANNER POINTER
1835 007666 004537 022470 1$: PERFORM ,SETSCAN ;SET MSCAN TO CORRECT LINE
1836 007672 000001 65$: .BLKW 1 ;INITIAL LINE POINTER PLACED HERE.
1837 007674 012703 000004 2$: MOV #4,R3 ;SET FOR A FOUR LINE GROUP.
1838 007700 012705 000003 3$: MOV #BIT1+BIT0,R5 ;SET EXPECTED RESULTS.
1839 007704 012702 076400 4$: MOV #BRB+BIT11+BIT10+BIT8,R2
1840 007710 010277 171464 MOV R2,ADVSR ;BR-B "MATCH DET"?
1841 007714 017704 171450 MOV ADVLCR,R4 ;READ DVLCR INTO R4
1842 007720 020504 CMP R5,R4 ;MATCH DET FALSE??
1843 007722 001401 BEQ 5$ ;BR IF YES
1844 007724 104001 HLT 1 ;LCR BIT1=1+BIT0=1 EXPECTED.
1845 007726 004537 022470 5$: PERFORM ,SETSCAN ;UPDATE MSCAN POINTER TO NEXT LINE.
1846 007732 000001 1 ;1 LINE
1847 007734 005303 DEC R3 ;ALL FOUR LINES DONE YET?
1848 007736 001362 BNE 4$ ;BR IF NO
  
```

N03

1849 007740 000207 R1S PC ;CHECK NEXT SET OF LINES

***** TEST 3 *****
;TEST THAT MAINT BIT WINDOW IS CLEARED
; * AFTER AN INIT.
;THIS TEST WILL BE DONE FOR SYNC LINE CARDS ONLY.

; TEST 3

1861	007742	012737	000003	001225	TST3:	MOV	#3, TSTNO	
1862	007750	012737	010150	001216		MOV	#TST4, NEXT	
1863	007756	012700	000000			MOV	#0, R0	; PLACE LINE NUMBER INTO R0
1864	007762	013737	001416	001236		MOV	L00.03, STAT	; LOAD LINE CARD STATUS INTO STAT
1865	007770	100402				BMI	100\$; BR IF LINE CARD NOT TO BE TESTED
1866	007772	004737	010060			JSR	PC, 105\$; GO DO THE TEST FOR LINE CARD 1
1867	007776	012700	000004		100\$:	MOV	#4, R0	; PLACE LINE NUMBER INTO R0
1868	010002	013737	001420	001236		MOV	L04.07, STAT	; LOAD LINE CARD STATUS INTO STAT
1869	010010	100402				BMI	101\$; BR IF LINE CARD NOT TO BE TESTED
1870	010012	004737	010060			JSR	PC, 105\$; GO DO THE TEST FOR LINE CARD 2
1871	010016	012700	000010		101\$:	MOV	#8, R0	; LOAD LINE NUMBER
1872	010022	013737	001422	001236		MOV	L08.11, STAT	; LOAD LINE CARD STATUS INTO STAT
1873	010030	100402				BMI	102\$; BR IF LINE CARD NOT TO BE TESTED
1874	010032	004737	010060			JSR	PC, 105\$; DO THE TEST FOR LINE CARD 3
1875	010036	012700	000014		102\$:	MOV	#12, R0	; LOAD LINE NO.
1876	010042	013737	001424	001236		MOV	L12.15, STAT	; LOAD LINE CARD STATUS
1877	010050	100402				BMI	103\$; BR IF LINE CARD NOT TO BE TESTED
1878	010052	004737	010060			JSR	PC, 105\$; DO THE TESTS FOR LINE CARD 4
1879	010056	104400			103\$:	SCOPE		; SCOPE THIS TEST.
1880	010060				105\$:			; TEST ENTRANCE.
1881	010060	032737	004000	001236		BIT	#ASYNC, STAT	; IS THIS A SYNC LINE CARD?
1882	010066	001401				BEQ	.+4	; BR IF SYNC LINE CARD.
1883	010070	000207				RTS	PC	; EXIT TEST
1884	010072	104412				MSTCLR		; RESET DV11
1885	010074	005002				CLR	R2	; ZERO SFR IMAGE
1886	010076	017705	171256			MOV	@DVLCR, R5	; READ THE DVLCR INTO R5
1887	010102	042705	000200			BIC	#BIT7, R5	; CLEAR MAINT BIT WINDOW EXPECTED
1888	010106	012703	000004			MOV	#4, R3	; SET TO DO 4 LINES.
1889	010112	010077	171254		1\$:	MOV	R0, @DVSR5	; LOAD LINE NUMBER
1890	010116	017704	171246			MOV	@DVLCR, R4	; READ DVLCR RESULTS INTO R4
1891	010122	042705	000060			BIC	#BIT5+BIT4, R5	; CLEAR EXTENDED ADDRESS BITS
1892	010126	042704	000060			BIC	#BIT5+BIT4, R4	; ""
1893	010132	020504				CMP	R5, R4	; OK?
1894	010134	001401				BEQ	2\$	
1895	010136	104001				HLT	1	; BIT7 INCORRECT
1896	010140	005200			2\$:	INC	R0	; UPDATE LINE POINTER
1897	010142	005303				DEC	R3	; ALL LINES DONE?
1898	010144	001362				BNE	1\$; BR IF NO
1899	010146	000207				RTS	PC	; RETURN FOR NEXT SET OF LINES.

***** TEST 4 *****
;TEST THAT THE BIT WINDOW WILL
;STAY CLEARED WHEN MAINT INTERNAL

1900
1901
1902
1903
1904

: *MODE IS SELECTED BUT COND. STROBE IS
: *NOT ASSERTED.
: *THIS TEST WILL BE DONE FOR SYNC LINE CARDS ONLY.
: *****

: TEST 4

000004 001226
010364 001216
000000
001416 001236
010266
000004 1005:
001420 001236
010266 1015:
000010
001422 001236
010266 1025:
000014
001424 001236
010266 1035:
004000 001236
001401
000207
104412
005002
004000 171056
017705
000200
000004
171040 15:
171032
000060
000060
020504
001401
104001
005200 25:
005303
001362
000207

TEST4: MOV #4, TSTNO
MOV #TSTS, NEXT
MOV #0, R0
MOV LOC.03, STAT
BMI 100\$
JSR PC, 105\$
100\$: MOV #4, R0
MOV LOC.07, STAT
BMI 101\$
JSR PC, 105\$
101\$: MOV #8, R0
MOV LOC.11, STAT
BMI 102\$
JSR PC, 105\$
102\$: MOV #12, R0
MOV LOC.15, STAT
BMI 103\$
JSR PC, 105\$
103\$: SCOPE
105\$: BIT #ASYNCR, STAT
BEQ .+4
RTS PC
MSTCLR
CLR R2
MOV #BIT11, DVLCR
MOV DVLCR, R5
BIC #BIT7, R5
MOV #4, R3
15: MOV R0, DVSR5
MOV DVLCR, R4
BIC #BITS+BIT4, R5
BIC #BITS+BIT4, R4
CMP R5, R4
BEQ 25
HLT
25: INC R0
DEC R3
BNE 15
RTS PC

: PLACE LINE NUMBER INTO R0
: LOAD LINE CARD STATUS INTO STAT
: BR IF LINE CARD NOT TO BE TESTED
: GO DO THE TEST FOR LINE CARD 1
: PLACE LINE NUMBER INTO R0
: LOAD LINE CARD STATUS INTO STAT
: BR IF LINE CARD NOT TO BE TESTED
: GO DO THE TEST FOR LINE CARD 2
: LOAD LINE NUMBER
: LOAD LINE CARD STATUS INTO STAT
: BR IF LINE CARD NOT TO BE TESTED
: DO THE TEST FOR LINE CARD 3
: LOAD LINE NO.
: LOAD LINE CARD STATUS
: BR IF LINE CARD NOT TO BE TESTED
: DO THE TESTS FOR LINE CARD 4
: SCOPE THIS TEST.
: TEST ENTRANCE.
: IS THIS A SYNC LINE CARD?
: BR IF SYNC LINE CARD.
: EXIT TEST
: RESET DV11
: ZERO SFR IMAGE
: SET INTERNAL MAINT MODE
: READ THE DVLCR INTO R5
: CLEAR MAINT BIT WINDOW EXPECTED
: SET TO DO 4 LINES.
: LOAD LINE NUMBER
: READ DVLCR RESULTS INTO R4
: CLEAR EXTENDED ADDRESS BITS
: ""
: OK?
: BIT? INCORRECT
: UPDATE LINE POINTER
: ALL LINES DONE?
: BR IF NO
: RETURN FOR NEXT SET OF LINES.

: ***** TEST 5 *****
: *TEST THAT THE BIT WINDOW WILL
: *SET WHEN MAINT INTERNAL MODE IS SELECTED
: *AND COND. STROBE IS ASSERTED.
: *THIS TEST WILL BE DONE FOR SYNC LINE CARDS ONLY.
: *****

: TEST 5

01100 012737 000005 001226
01103 012737 010612 001216
01104 012700 000000
01104 013737 001416 001236
01104 100402
01104 004737 010502
01104 012700 000004 1003:
01104 013737 001420 001236
01104 100402
01104 004737 010502
01104 012700 000010 1015:
01104 013737 001422 001236
01104 100402
01104 004737 010502
01104 012700 000014 1035:
01104 013737 001424 001236
01104 100402
01104 004737 010502
01104 104400 1035:
01105 032737 004000 001236
01105 001401
01105 000207
01105 104412
01105 005002
01105 012777 004000 170642
01105 017705 170636
01105 052705 000200
01105 012703 000004
01105 010077 170624 15:
01105 052777 100000 170614
01105 004737 022406
01105 017704 170604
01105 042705 000050
01105 042704 000060
01105 020504
01105 001401
01106 104001
01106 005200 25:
01106 005303
01106 001355
01106 000207

TESTS: MOV #5 TSTNO
MOV #TST6 NEXT
MOV #0, R0
MOV L00, 03, STAT
BMI IC0\$
JSR PC, 105\$
1003: MOV #4, R0
MOV L04, 07, STAT
BMI I01\$
JSR PC, 105\$
1015: MOV #8, R0
MOV L08, 11, STAT
BMI I02\$
JSR PC, 105\$
1035: MOV #12, R0
MOV L12, 15, STAT
BMI I03\$
JSR PC, 105\$
1035: SCOPE
1055: BIT #ASYNC, STAT
BEQ +4
RTS PC
MSTCLR
CLR R2
MOV #BIT11, 2DVLOR
MOV 2D, LOR, R5
BIS #BIT7, R5
MOV #4, R3
15: MOV R0, 2DVSRS
BIS #BIT15, 2DVLOR
JSR PC, CKBIT15
MOV 2DVLOR, R4
BIC #BITS+BIT4, R5
BIC #BITS+BIT4, R4
CMP R5, R4
BEQ 25\$
HLT I
25: INC R0
DEC R3
BNE 15\$
RTS PC

: PLACE LINE NUMBER INTO R0
: LOAD LINE CARD STATUS INTO STAT
: BR IF LINE CARD NOT TO BE TESTED
: GO DO THE TEST FOR LINE CARD 1
: PLACE LINE NUMBER INTO R0
: LOAD LINE CARD STATUS INTO STAT
: BR IF LINE CARD NOT TO BE TESTED
: GO DO THE TEST FOR LINE CARD 2
: LOAD LINE NUMBER
: LOAD LINE CARD STATUS INTO STAT
: BR IF LINE CARD NOT TO BE TESTED
: DO THE TEST FOR LINE CARD 3
: LOAD LINE NO.
: LOAD LINE CARD STATUS
: BR IF LINE CARD NOT TO BE TESTED
: DO THE TESTS FOR LINE CARD 4
: SCOPE THIS TEST.
: TEST ENTRANCE.
: IS THIS A SYNC LINE CARD?
: BR IF SYNC LINE CARD.
: EXIT TEST
: RESET DV:1
: ZERO SFR IMAGE
: SET INTERNAL MAINT MODE
: READ THE DVLOR INTO R5
: SET MAINT BIT WINDOW EXP RESULTS
: SET TO DO 4 LINES.
: LOAD LINE NUMBER
: SET STROBE
: GO WAIT FOR BIT15 TO =0
: READ DVLOR RESULTS INTO R4
: CLEAR EXTENDED ADDRESS BITS
: ""
: OK?
: BIT? INCORRECT
: UPDATE LINE POINTER
: ALL LINES DONE?
: BR IF NO
: RETURN FOR NEXT SET OF LINES.

:***** TEST 6 *****
: *TEST THAT THE BIT WINDOW WILL BE CLEARED
: *WHEN MAINT INTERNAL MODE IS SELECTED AND TX DSABLE
: *IS ASSERTED.
: *THIS TEST WILL BE DONE FOR SYNC LINE CARDS ONLY.
:*****

000006
000008
000010
000012
000014
000016
000020
000024
000028
000032
000036
000040
000044
000048
000052
000056
000060
000064
000068
000072
000076
000080
000084
000088
000092
000096
000100
000104
000108
000112
000116
000120
000124
000128
000132
000136
000140
000144
000148
000152
000156
000160
000164
000168
000172
000176
000180
000184
000188
000192
000196
000200
000204
000208
000212
000216
000220
000224
000228
000232
000236
000240
000244
000248
000252
000256
000260
000264
000268
000272
000276
000280
000284
000288
000292
000296
000300
000304
000308
000312
000316
000320
000324
000328
000332
000336
000340
000344
000348
000352
000356
000360
000364
000368
000372
000376
000380
000384
000388
000392
000396
000400
000404
000408
000412
000416
000420
000424
000428
000432
000436
000440
000444
000448
000452
000456
000460
000464
000468
000472
000476
000480
000484
000488
000492
000496
000500
000504
000508
000512
000516
000520
000524
000528
000532
000536
000540
000544
000548
000552
000556
000560
000564
000568
000572
000576
000580
000584
000588
000592
000596
000600
000604
000608
000612
000616
000620
000624
000628
000632
000636
000640
000644
000648
000652
000656
000660
000664
000668
000672
000676
000680
000684
000688
000692
000696
000700
000704
000708
000712
000716
000720
000724
000728
000732
000736
000740
000744
000748
000752
000756
000760
000764
000768
000772
000776
000780
000784
000788
000792
000796
000800
000804
000808
000812
000816
000820
000824
000828
000832
000836
000840
000844
000848
000852
000856
000860
000864
000868
000872
000876
000880
000884
000888
000892
000896
000900
000904
000908
000912
000916
000920
000924
000928
000932
000936
000940
000944
000948
000952
000956
000960
000964
000968
000972
000976
000980
000984
000988
000992
000996
001000

00000001
00000002
00000003
00000004
00000005
00000006
00000007
00000008
00000009
00000010
00000011
00000012
00000013
00000014
00000015
00000016
00000017
00000018
00000019
00000020
00000021
00000022
00000023
00000024
00000025
00000026
00000027
00000028
00000029
00000030
00000031
00000032
00000033
00000034
00000035
00000036
00000037
00000038
00000039
00000040
00000041
00000042
00000043
00000044
00000045
00000046
00000047
00000048
00000049
00000050
00000051
00000052
00000053
00000054
00000055
00000056
00000057
00000058
00000059
00000060
00000061
00000062
00000063
00000064
00000065
00000066
00000067
00000068
00000069
00000070
00000071
00000072

010612 012737 000006 001226
010620 012737 011040 001215
010626 012700 000000
010632 013737 001416 001236
010640 100402
010642 004737 010730
010646 012700 000004
010652 013737 001420 001236
010660 100402
010662 004737 010730
010666 012700 000010
010672 013737 001422 001236
010700 100402
010702 004737 010730
010706 012700 000014
010712 013737 001424 001236
010720 100402
010722 004737 010730
010726 104400
010730
010730 032737 004000 001236
010736 001401
010740 000207
010742 104412
010744 005002
010746 012777 005000 170414
010754 017705 170410
010760 042705 000200
010764 012703 000004
010770 019077 170376
010774 052777 100000 170366
011002 004737 022406
011006 017704 170356
011012 042705 000060
011016 042704 000060
011022 020504
011024 001401
011026 104001
011030 005200
011032 005303
011034 001355
011036 000207

```
: TEST 6
-----
TST6: MOV #6,TSTNO
MOV #TST7,NEXT
MOV #0,R0
MOV #00.03,STAT
SMI 100$
JSR PC,105$
100$: MOV #4,R0
MOV #04.07,STAT
BMI 101$
JSR PC,105$
101$: MOV #8,R0
MOV #08.11,STAT
BMI 102$
JSR PC,105$
102$: MOV #12,R0
MOV #12.15,STAT
BMI 103$
JSR PC,105$
103$: SCOPE
103$: BIT #ASYNC,STAT
BEQ +4
RTS PC
MSTCLR
CLR R2
MOV #BIT11+BIT9,DVLCR
MOV #DVLCR,R5
BIC #BIT7,R5
MOV #4,R3
1$: MOV R0,#DVSRS
BIS #BIT15,DVLCR
JSR PC,CKBIT15
MOV #DVLCR,R4
BIC #BITS+BIT4,R5
BIC #BITS+BIT4,R4
CMP R5,R4
BEQ 2$
HLT 1
2$: INC R0
DEC R3
BNE 1$
RTS PC
:PLACE LINE NUMBER INTO R0
:LOAD LINE CARD STATUS INTO STAT
:BR IF LINE CARD NOT TO BE TESTED
:GO DO THE TEST FOR LINE CARD 1
:PLACE LINE NUMBER INTO R0
:LOAD LINE CARD STATUS INTO STAT
:BR IF LINE CARD NOT TO BE TESTED
:GO DO THE TEST FOR LINE CARD 2
:LOAD LINE NUMBER
:LOAD LINE CARD STATUS INTO STAT
:BR IF LINE CARD NOT TO BE TESTED
:DO THE TEST FOR LINE CARD 3
:LOAD LINE NO.
:LOAD LINE CARD STATUS
:BR IF LINE CARD NOT TO BE TESTED
:DO THE TESTS FOR LINE CARD 4
:SCOPE THIS TEST.
:TEST ENTRANCE.
:IS THIS A SYNC LINE CARD?
:BR IF SYNC LINE CARD.
:EXIT TEST
:RESET DV11
:ZERO SFR IMAGE
:SET INTER MAINT MODE FOR SYSTEM TESTING
:READ THE DVLCR INTO R5
:CLEAR MAINT BIT WINDOW EXPECTED
:SET TO DO 4 LINES.
:LOAD LINE NUMBER
:SET STROBE
:GO WAIT FOR BIT15 TO =0
:READ DVLCR RESULTS INTO R4
:CLEAR EXTENDED ADDRESS BITS
:OK?
:BIT7 INCORRECT
:UPDATE LINE POINTER
:ALL LINES DONE?
:BR IF NO
:RETURN FOR NEXT SET OF LINES.
```

***** TEST 7 *****
*TEST THAT "MAINT DATA" WILL SHOW
*UP IN "MAINT BIT WINDOW".
*THIS TEST WILL BE DONE FOR SYNC LINE CARDS ONLY.

```
: TEST 7
-----
TST7: MOV #7,TSTNO
MOV #TST10,NEXT
```

E04

DZDV8 MACY11 27.732 17-SEP-75 11:14 PAGE 45
DZDV8B.P11 DV11 DEVICE DIAGNOSTICS. COPYRIGHT 1975 DIGITAL EQUIP. CORP.

011054	012700	000000		MOV	#0.,R0	:PLACE LINE NUMBER INTO R0
011060	013737	001416	001236	MOV	L00.03,STAT	:LOAD LINE CARD STATUS INTO STAT
011066	100402			BMI	100\$:BR IF LINE CARD NOT TO BE TESTED
011070	004737	011156		JSR	PC,105\$:GO DO THE TEST FOR LINE CARD 1
011074	012700	000004	100\$:	MOV	#4.,R0	:PLACE LINE NUMBER INTO R0
011100	013737	001420	001236	MOV	L04.07,STAT	:LOAD LINE CARD STATUS INTO STAT
011106	100402			BMI	101\$:BR IF LINE CARD NOT TO BE TESTED
011110	004737	011156		JSR	PC,105\$:GO DO THE TEST FOR LINE CARD 2
011114	012700	000010	101\$:	MOV	#8.,R0	:LOAD LINE NUMBER
011120	013737	001422	001236	MOV	L08.11,STAT	:LOAD LINE CARD STATUS INTO STAT
011126	100402			BMI	102\$:BR IF LINE CARD NOT TO BE TESTED
011130	004737	011156		JSR	PC,105\$:GO DO THE TEST FOR LINE CARD 3
011134	012700	000014	102\$:	MOV	#12.,R0	:LOAD LINE NO.
011140	013737	001424	001236	MOV	L12.15,STAT	:LOAD LINE CARD STATUS
011146	100402			BMI	103\$:BR IF LINE CARD NOT TO BE TESTED
011150	004737	011156		JSR	PC,105\$:GO DO THE TESTS FOR LINE CARD 4
011154	104400		103\$:	SCOPE		:SCOPE THIS TEST.
011156			105\$:			:TEST ENTRANCE.
011156	032737	004000	001236	BIT	#ASYNC,STAT	:IS THIS A SYNC LINE CARD?
011164	001401			BEQ	.+4	:BR IF SYNC LINE CARD.
011166	000207			RTS	PC	:EXIT TEST
011170	104412			MSTCLR		:RESET DV11
011172	005002			CLR	R2	:CLEAR DVSFR IMAGE
011174	012703	000004		MOV	#4,R3	:SET TO DO 4 LINES
011200	010077	170156	1\$:	MOV	R0,DVSR5	:LOAD LINE NUMBER
011204	004537	022266		PERFORM	LOAD.MODE	:LOAD THE MODE
011210	005000			BIT11+BIT9		:INT MAINT MODE AND TX CSABLE
011212	017705	170152		MOV	DVLCR,R5	:READ LSR
011216	010504			MOV	R5,R4	
011220	042705	000200		BIC	#BIT7,R5	:CLEAR MAINT BIT WINDOW RESULT
011224	020504			CMP	R5,R4	:WAS BIT WINDOW =TO 0
011226	001401			BEQ	.+4	:BR IF YES
011230	104001			HLT	1	:BIT7 OF LCR S/B=0
011232	012737	000012	001250	MOV	#10,TEMP2	:SET FOR 10 BITS
011240	052705	040200	2\$:	BIS	#BIT14+BIT7,R5	:SET MAINT DATA AND MAINT BIT WINDOW
011244	052777	140000	170116	BIS	#BIT15+BIT14,DVLCR	
011252	004737	022406		JSR	PC,CKBIT15	:STROBE MAINT DATA. WAIT BIT15=C
011256	017704	170106		MOV	DVLCR,R4	:READ THE LCR
011262	020504			CMP	R5,R4	:BIT14+BIT7=1?
011264	001401			BEQ	3\$:YES
011266	104001			HLT	1	:MAINT DATA DID NOT SHOW UP IN WINDOW
011270	042705	040200	3\$:	BIC	#BIT14+BIT7,R5	:CLEAR DATA AND WINDOW
011274	042777	040000	170066	BIC	#BIT14,DVLCR	:CLEAR MAINT DATA
011302	052777	100000	170060	BIS	#BIT15,DVLCR	:SET STROBE ON DV11
011310	004737	022406		JSR	PC,CKBIT15	:WAIT 15=0
011314	017704	170050		MOV	DVLCR,R4	:READ DVLCR
011320	020504			CMP	R5,R4	:WINDOW =0?
011322	001401			BEQ	4\$:BR IF YES
011324	104001			HLT	1	:BIT7 S/B=0
011326	005337	001250	4\$:	DEC	TEMP2	:10 BITS DONE?
011332	001342			BNE	2\$:BR IF NO
011334	005200			INC	R0	:UPDATE LINE POINTER
011336	005303			DEC	R3	:4 LINE GROUP DONE?
011340	001317			BNE	1\$:BR IF NO
011342	000207			RTS	PC	:RETURN FOR NEXT GROUP

F04

1129
1130
1131
1132
1133
1134
1135
1136
1137
1138
1139
1140
1141
1142
1143
1144
1145
1146
1147
1148
1149
1150
1151
1152
1153
1154
1155
1156
1157
1158
1159
1160
1161
1162
1163
1164
1165
1166
1167
1168
1169
1170
1171
1172
1173
1174
1175
1176
1177
1178
1179
1180
1181
1182
1183
1184

***** TEST 10 *****
: *TEST TO XMIT A BINARY COUNT PATTERN
: *THUR THE USE OF THE BIT WINDOW.
: *ONLY ONE LINE AT A TIME WILL BE EXERCISED.
: *THIS TEST WILL BE DONE FOR SYNC LINE CARDS ONLY.
: *****

: TEST 10

011344 012737 000010 001226
011352 012737 012224 001216
011350 012700 000000
011364 113737 001412 001242
011372 113737 001406 001244
011400 013737 001416 001236
011406 100402
011410 004737 011542
011414 012700 000004
011420 113737 001413 001242
011426 113737 001407 001244
011434 013737 001420 001236
011442 100402
011444 004737 011542
011450 012700 000010
011454 113737 001414 001242
011462 113737 001410 001244
011470 013737 001422 001236
011476 100402
011500 004737 011542
011504 012700 000014
011510 113737 001415 001242
011516 113737 001411 001244
011524 013737 001424 001236
011532 100402
011534 004737 011542
011540 104400
011542 032737 004000 001236
011550 001401
011552 000207
011554 010037 011570
011560 104412
011562 005001
011564 004537 022470
011570 000001
011572 012703 000004
011576 005005
011600 012777 050102 167572
011606 104415
011610 005201
011612 010077 167554
011616 004537 022266
011622 004000
011624 004537 022560
011630 012777 001000 167542

TST10: MOV #10,TSTNO
MOV #TST11,NEXT
MOV #0,R0 :PLACE LINE NUMBER INTO R0
MOVSB CLK.A,CLKX :PLACE "SHIFTS/PER/CHAR" IN CLKX
MOVSB MASK.A,MASKX :PLACE "MASK" FOR CHARS INTO MASKX
MOV L00.03,STAT :LOAD LINE CARD STATUS INTO STAT
BMI 100\$:BR IF LINE CARD NOT TO BE TESTED
JSR PC,105\$:GO DO THE TEST FOR LINE CARD 1
100\$: MOV #4,R0 :PLACE LINE NUMBER INTO R0
MOVSB CLK.B,CLKX :PLACE "SHIFTS/PER/CHAR" IN CLKX
MOVSB MASK.B,MASKX :GET MASK
MOV L04.07,STAT :LOAD LINE CARD STATUS INTO STAT
BMI 101\$:BR IF LINE CARD NOT TO BE TESTED
JSR PC,105\$:GO DO THE TEST FOR LINE CARD 2
101\$: MOV #8,R0 :LOAD LINE NUMBER
MOVSB CLK.C,CLKX :GET SHIFTS PER CHAR
MOVSB MASK.C,MASKX :GET MASK
MOV L08.11,STAT :LOAD LINE CARD STATUS INTO STAT
BMI 102\$:BR IF LINE CARD NOT TO BE TESTED
JSR PC,105\$:DO THE TEST FOR LINE CARD 3
102\$: MOV #12,R0 :LOAD LINE NO.
MOVSB CLK.D,CLKX :GET SHIFTS
MOVSB MASK.D,MASKX :GET MASKK
MOV L12.15,STAT :LOAD LINE CARD STATUS
BMI 103\$:BR IF LINE CARD NOT TO BE TESTED
JSR PC,105\$:DO THE TESTS FOR LINE CARD 4
103\$: SCOPE :SCOPE THIS TEST.
105\$: BIT #ASYNC,STAT :TEST ENTRANCE.
BEQ .+4 :IS THIS A SYNC LINE CARD?
RTS PC :BR IF SYNC LINE CARD.
MOV RO,65\$:EXIT TEST
MSTCLR :SET LINE NO. POINTER
CLR R1 :CLEAR DV11
PERFORM .SETSCAN :ZERO MSCANNER POINTER
BLKW 1 :ADJUST SCANNER FOR PROPER LINE
MOV #4,R3 :LINE NUMBER POINTER.
CLR R5 :SET FOR 4 LINES EXERCISED
MOV #5.C+BIT6+BIT1,ADVSR :SET DATA POINTER TO 0
ROMCLK :CLOCK SCANNER BY ONE
INC R1 :ADD +1 TO SCANNER POINTER
MOV RO,ADVSR5 :LOAD LINE NUMBER
PERFORM ,LOAD.MODE :LOAD MODE
BIT11 :CLEAR TMARK BIT.
7\$: PERFORM .CLR.TMARK :DO A BR "A" TEST FOR TX FLAG
MOV #BIT9,ADVSR

G04

2195	011636	005005			CLR R5	:SET EXPECTED DATA TO 0
2196	011640	032777	000001	167522	BIT #BIT0,ADVLCR	:IF FLAG TRUE?
2197	011646	001401			BEG .+4	:BR IF YES
2198	011650	104000			HLT	:TX FLAG NO TRUE(LOW(LPRO=0))
2199	011652	005077	167514		CLR ADVSR5	:ZERO LINE TO LINE 0
2200	011655	010577	167514		MOV R5,ADVSR4	:LOAD DATA INTO DVSRA
2201	011662	012777	020000	167510	MOV #BIT13,ADVSR	:EXECUTE A "ROM READ" INTSTR
2202	011670	104415			ROMCLK	:CLOCK.
2203	011672	012777	030260	167500	MOV #XFR+BIT7+BITS+BIT4,ADVSR	
2204	011700	104415			ROMCLK	:DO A DATA XFER FROM RAM OUTPUT TO TX BUFFER
2205	011702	104416			DATACLK	:ISSUE A MAINT CLK.
2206	011704	012777	001000	167456	MOV #BIT9,ADVSR	:DO A "BR A" TEST FOR TX FLAG
2207	011712	032777	000001	167450	BIT #BIT0,ADVLCR	:IS FLAG FALSE?
2208	011720	001001			BNE .+4	:BR IF YES
2209	011722	104000			HLT	:TX FLAG NOT FALSE(HIGH(LPRO=1))
2210	011724	012737	011732	001220	MOV #4\$,LOCK	:SET IF SW09=1 GOTO 4\$
2211	011732	113702	001242		MOV8 CLKX,R2	:SET REQUIRED SHIFTS
2212	011736	005037	022622		CLR DATA	:CLEAR STUFFER LOCATION
2213	011742	010077	167424		MOV R0,ADVSR5	:LOAD LINE NUMBER
2214	011746	104416			DATACLK	:ISSUE MAINT CLK
2215	011750	004537	022246		PERFORM TXSHIFT	:WORK THE TRANSMITTER
2216	011754	005302			DEC R2	:ALL SHIFTS DONE?
2217	011756	022702	000001		CMP #1,R2	:IS THE BUFFER ALMOST EMPTY?
2218	011762	001030			BNE 8\$:BR IF NO
2219	011764	005077	167402		CLR ADVSR5	:ZERO LINE NUMBER
2220	011770	032777	001000	167204	BIT #BIT9,ADSWR	:LOCK ON DATA?
2221	011776	001001			BNE .+4	:BR IF YES!!
2222	012000	005205			INC R5	:UPDATE DATA.
2223	012002	010577	167370		MOV R5,ADVSR4	:LOAD DATA INTO DVSRA
2224	012006	012777	020000	167364	MOV #BIT13,ADVSR	:DO A ROM READ
2225	012014	104415			ROMCLK	:CLK
2226	012016	012777	030260	167354	MOV #XFR+BIT7+BITS+BIT4,ADVSR	
2227	012024	104415			ROMCLK	:DO A DATA XFER TO TX BUFF
2228	012026	010077	167340		MOV R0,ADVSR5	:RESELECT LINE NUMBER
2229	012032	032777	001000	167142	BIT #BIT9,ADSWR	:LOCK ON DATA?
2230	012040	001001			BNE .+4	:BR IF YES!!
2231	012042	005305			DEC R5	:READJUST DATA CHAR.
2232	012044	005702			TST R2	:ALL SHIFTS DONE?
2233	012046	001337			BNE 5\$:BR IF NO
2234	012050	022737	000010	001242	CMP #8,.CLKX	:IS LINE CARD SET TO 8 BITS?
2235	012056	001414			BEG 15\$:BR IF YES
2236	012060	013737	001242	001246	MOV CLKX,TEMP1	:SAVE NUMBER OF SHIFTS DONE.
2237	012066	000241			CLC	:CLEAR CARRY
2238	012070	006037	022622		ROR DATA	:RIGHT JUSTIFY TX RESULTS.
2239	012074	005237	001246		INC TEMP1	:ALL DONE?
2240	012100	022737	000010	001246	CMP #8,.TEMP1	
2241	012106	001367			BNE 16\$:BR IF NO
2242	012110				15\$:	
2243	012110	013704	022622		MOV DATA,R4	:READ IMAGE CHAR FROM TX
2244	012114	143704	001244		BIC8 MASKX,R4	:STRIP PARITY IF IT EXISTS.
2245	012120	020504			CMP R5,R4	:ARE DATA CHARS THE SAME?
2246	012122	001401			BEG .+4	:BR IF GOOD DATA FROM TX
2247	012124	104003			HLT 3	:TX DATA COMPARE ERROR
2248	012126	104401			SCOP1	:LOCK ON DATA?
2249	012130	105205			INCB R5	:UPDATE DATA CHAR.
2250	012132	001403			BEG 6\$:BR IF 8BIT CODE DONE.

```

012141 012134 133705 001244 BITB MASKX,R5 ;IF <BBIT SEE IF ALL DONE.
012142 001674 BEQ 4$ ;BR IF NOT ALL DONE
012143 004537 022546 6$: PERFORM .SET.TMARK ;SET TMARK BIT
; *VERIFY THAT SETTING TMARK BIT PUTS LINE AT MARK.
; *
012146 113702 001242 MOVB CLKX,R2 ;SET COUNTER
012152 010077 167214 MOV RO,ADVSR5 ;SET LINE
012156 104416 9$: DATACLK ;CLOCK
012160 005302 DEC R2 ;FLUSH LAST CHARACTER.
012162 001375 BNE 9$ ;CHAR FLUSHED?
012164 012702 000024 MOV #20.,R2 ;LOOK AT 20. BITS.
012170 104416 10$: DATACLK ;MAINT CLK
012172 032777 000200 167172 BIT #BIT7,ADVLCR ;BIT WINDOW
012200 001001 BNE 11$ ;SET (MARK)
012202 104000 HLT 0 ;TX BIT WINDOW NOT SET (MARK)
012204 005302 11$: DEC R2 ;ALL BITS LOOKED AT"
012206 001370 BNE 10$ ;BR IF NO
012210 004537 022470 PERFORM .SETSCAN ;ADVANCE SCANNER TO NEXT LINE
012214 000001 I ;ONE LINE ADVANCE
012216 005303 DEC R3 ;ALL LINES(4) DONE"
012220 001201 BNE 7$ ;BR IF NO
012222 000207 RTS PC ;GET NEXT GROUP OF 4 LINES.

```

```

:***** TEST 11 *****
:*TEST TO CHECK THE IDLE CHARACTER
:*FOR EACH LINE OF THE TRANSMITTER.
:*THIS TEST USES "SYNCA".
:*THIS TEST WILL BE DONE FOR SYNC LINE CARDS ONLY.
:*****

```

: TEST 11

```

012224 012737 000011 001226 TST11: MOV #11,TSTNO
012232 012737 012740 001216 MOV #TST12,NEXT
012240 012700 000000 MOV #0.,RO ;PLACE LINE NUMBER INTO RO
012244 113737 001412 001242 MOVB CLK.A,CLKX ;PLACE "SHIFTS/PER/CHAR" IN CLKX
012252 113737 001406 001244 MOVB MASK.A,MASKX ;PLACE "MASK"FOR CHARS INTO MASKX
012260 013737 001416 001236 MOV LO0.03,STAT ;LOAD LINE CARD STATUS INTO STAT
012266 100402 BMI 100$ ;BR IF LINE CARD NOT TO BE TESTED
012270 004737 012422 JSR PC,105$ ;GO DO THE TEST FOR LINE CARD 1
012274 012700 000004 100$: MOV #4.,RO ;PLACE LINE NUMBER INTO RO
012300 113737 001413 001242 MOVB CLK.B,CLKX ;PLACE "SHIFTS/PER/CHAR" IN CLKX
012306 113737 001407 001244 MOVB MASK.B,MASKX ;GET MASK
012314 013737 001420 001236 MOV LO4.07,STAT ;LOAD LINE CARD STATUS INTO STAT
012322 100402 BMI 101$ ;BR IF LINE CARD NOT TO BE TESTED
012324 004737 012422 JSR PC,105$ ;GO DO THE TEST FOR LINE CARD 2
012330 012700 000010 101$: MOV #8.,RO ;LOAD LINE NUMBER
012334 113737 001414 001242 MOVB CLK.C,CLKX ;GET SHIFTS PER CHAR
012342 113737 001410 001244 MOVB MASK.C,MASKX ;GET MASK
012350 013737 001422 001236 MOV LO8.11,STAT ;LOAD LINE CARD STATUS INTO STAT
012356 100402 BMI 102$ ;BR IF LINE CARD NOT TO BE TESTED
012360 004737 012422 JSR PC,105$ ;DO THE TEST FOR LINE CARD 3
012364 012700 000014 102$: MOV #12.,RO ;LOAD LINE NO.
012370 113737 001415 001242 MOVB CLK.D,CLKX ;GET SHIFTS
012376 113737 001411 001244 MOVB MASK.D,MASKX ;GET MASK

```

2297	012404	013737	001424	001235	MOV	L12.15,STAT	:LOAD LINE CARD STATUS
2298	012412	100402			BMI	103\$:BR IF LINE CARD NOT TO BE TESTED
2299	012414	004737	012422		JSR	PC.105\$:DO THE TESTS FOR LINE CARD 4
2300	012420	104400			103\$:	SCOPE	:SCOPE THIS TEST.
2301	012422				105\$:		:TEST ENTRANCE.
2302	012422	032737	004000	001236	BIT	#ASYNC,STAT	:IS THIS A SYNC LINE CARD?
2303	012430	001401			SEQ	.+4	:BR IF SYNC LINE CARD.
2304	012432	000207			RTS	PC	:EXIT TEST
2305	012434	010037	012450		MOV	RO.65\$:LOAD LINE NO. POINTER
2306	012440	104412			MSTCLR		:RESET THE DV11
2307	012442	005001			CLR	R1	:ZERO MSCANNER POINTER
2308	012444	004537	022470		PERFORM	.SETSCAN	:SET MSCANNER TO LINES TESTED
2309	012450	000001			1\$:	.BLKW 1	:INITIAL LINE VALUE
2310	012452	012703	000004		2\$:	MOV	:SET TO DO 4 LINE GROUP
2311	012456	005005			3\$:	CLR	:ZERO
2312	012460	012777	050102	166712	MOV	#S.C+BIT6+BIT1,ADVSR	:ADVSR
2313	012466	104415			ROMCLK		:SET/CLEAR "ADVANCE MSCANNER"
2314	012470	005201			INC	P1	:UPDATE MSCANNER POINTER
2315	012472	010077	166674		6\$:	MOV	:LOAD LINE NUMBER INTO DV11
2316	012476	004537	022560		PERFORM	.CLR.TMARK	:CLR TMARK BIT.
2317	012502	004537	022266		PERFORM	.LOAD.MODE	:LOAD THE MODE
2318	012506	004000			BIT11		:INT MAINT MODE
2319	012510	005077	166662		CLR	ADVSR	:ZERO DATA FOR XFR
2320	012514	012777	020000	166656	MOV	#BIT13,ADVSR	:DO A RAM READ INSTR.
2321	012522	104415			ROMCLK		
2322	012524	012777	030260	166646	MOV	#XFR+BIT7+BITS+BIT4,ADVSR	
2323	012532	104415			ROMCLK		:DATA XFR TXBUFFER+RAM OUTPUT
2324	012534	104416			DATACLK		:ISSUE MAINT CLOCK PULSE
2325	012536	012737	012570	001220	MOV	#4\$.LOCK	:SET FOR SCOPI
2326	012544	113702	001242		MOVE	CLKX,R2	:NUMBER OF CLOCK PULSES NEEDED
2327	012550	104416			DATACLK		:MAINT CLOCK PULSE
2328	012552	005302			DEC	R2	:ALL CLOCKS DONE?
2329	012554	001375			BNE	.-4	:NO, DO MORE
2330	012556	113705	001236		MOVB	STAT,R5	:GET SYNC (IDLE) CHAR.
2331	012562	012737	000005	001250	MOV	#5.TEMP2	:SET FOR 5 CHARS
2332	012570	113702	001242		4\$:	MOVB	:GET CLOCKS NEEDED
2333	012574	005037	022622		CLR	DATA	:ZERO STORAGE AREA
2334	012500	010077	166566		MOV	RO,ADVSR	:LOAD LINE NUMBER
2335	012604	104416			5\$:	DATACLK	:ISSUE MAINT CLK PULSE
2336	012606	004537	022246		PERFORM	.TXSHIFT	:CLOCK THE TRANSMITTER
2337	012612	005302			DEC	R2	:MORE SHIFTS REQUIRED?
2338	012614	001373			BNE	5\$:BR IF YES
2339	012616	022737	000010	001242	CMP	#8.,CLKX	:IS LINE CARD SET TO 8 BITS?
2340	012624	001414			BEG	15\$:BR IF YES
2341	012626	013737	001242	001246	MOV	CLKX,TEMP1	:SAVE NUMBER OF SHIFTS DONE.
2342	012634	000241			16\$:	CLC	:CLEAR CARRY
2343	012636	006037	022622		ROR	DATA	:RIGHT JUSTIFY TX RESULTS.
2344	012642	005237	001246		INC	TEMP1	:ALL DONE?
2345	012646	022737	000010	001246	CMP	#8.,TEMP1	:?
2346	012654	001367			BNE	16\$:BR IF NO
2347	012656				15\$:		
2348	012656	013704	022622		MOV	DATA,R4	:SAVE DATA SHIFTED OUT OF TX.
2349	012662	143704	001244		BICB	MASKX,R4	:CLEAR UNWANTED BITS.
2350	012666	042705	177400		BIC	#1C<37>,R5	:CLEAR SIGN EXTEND.
2351	012672	143705	001244		BICB	MASKX,R5	:CLEAR UNUSED BITS
2352	012676	042704	177400		BIC	#1C<37>,R4	:CLEAR SIGN EXTEND.

J04

2353	012702	020504		CMP	R5,R4	: EXPECTED = FOUND ??
2354	012704	001401		BEQ	.+4	: BR IF OK
2355	012706	104003		HLT	3	: IDLE CHAR NOT WHAT EXPECTED.
2356	012710	005337	001250	DEC	TEMP2	: ALL IDLE CHARS DONE?
2357	012714	001325		BNE	4\$: BR IF NO
2358	012716	104401		SCOPI		: LOCK (SW09=1)?
2359	012720	004537	022546	PERFORM	.SET.TMARK	: SET TMARK BIT
2360	012724	004537	022470	PERFORM	.SETSCAN	: UPDATE SCANNER TO NEXT LINE
2361	012730	000901		1		:
2362	012732	005303		DEC	R3	: ALL LINES DONE
2363	012734	001256		BNE	6\$: BR IF NO
2364	012736	000207		RTS	PC	: EXIT FOR NEXT GROUP OF LINES.

:***** TEST 12 *****
 :*TEST TO CHECK THE IDLE CHARACTER
 :*FOR EACH LINE OF THE TRANSMITTER.
 :*THIS TEST USES "SYNCS".
 :*THIS TEST WILL BE DONE FOR SYNC LINE CARDS ONLY.
 :*****

: TEST 12

2376	012740	012737	000012	001226	TST12:	MOV	#12.TSTNO	
2377	012746	012737	013504	001216		MOV	#TST13.NEXT	
2378	012754	012700	000000			MOV	#0.R0	: PLACE LINE NUMBER INTO R0
2379	012760	113737	001412	001242		MOVB	CLK.A,CLKX	: PLACE "SHIFTS/PER/CHAR" IN CLKX
2380	012766	113737	001406	001244		MOVB	MASK.A,MASKX	: PLACE "MASK" FOR CHARS INTO MASKX
2381	012774	013737	001426	001240		MOV	SYNCA,SYNCA	:
2382	013002	013737	001416	001236		MOV	LO0.C3,STAT	: LOAD LINE CARD STATUS INTO STAT
2383	013010	100402				BMI	100\$: BR IF LINE CARD NOT TO BE TESTED
2384	013012	004737	013166			JSR	PC,105\$: GO DO THE TEST FOR LINE CARD 1
2385	013016	012700	000004		100\$:	MOV	#4.R0	: PLACE LINE NUMBER INTO R0
2386	013022	113737	001413	001242		MOVB	CLK.B,CLKX	: PLACE "SHIFTS/PER/CHAR" IN CLKX
2387	013030	113737	001407	001244		MOVB	MASK.B,MASKX	: GET MASK
2388	013036	013737	001430	001240		MOV	SYNCA,SYNCA	:
2389	013044	013737	001420	001236		MOV	LO4.07,STAT	: LOAD LINE CARD STATUS INTO STAT
2390	013052	100402				BMI	101\$: BR IF LINE CARD NOT TO BE TESTED
2391	013054	004737	013166			JSR	PC,105\$: GO DO THE TEST FOR LINE CARD 2
2392	013060	012700	000010		101\$:	MOV	#8.R0	: LOAD LINE NUMBER
2393	013064	113737	001414	001242		MOVB	CLK.C,CLKX	: GET SHIFTS PER CHAR
2394	013072	113737	001410	001244		MOVB	MASK.C,MASKX	: GET MASK
2395	013100	013737	001432	001240		MOV	SYNCA,SYNCA	:
2396	013106	013737	001422	001236		MOV	LO8.11,STAT	: LOAD LINE CARD STATUS INTO STAT
2397	013114	100402				BMI	102\$: BR IF LINE CARD NOT TO BE TESTED
2398	013116	004737	013166			JSR	PC,105\$: DO THE TEST FOR LINE CARD 3
2399	013122	012700	000014		102\$:	MOV	#12.R0	: LOAD LINE NO.
2400	013126	113737	001415	001242		MOVB	CLK.D,CLKX	: GET SHIFTS
2401	013134	113737	001411	001244		MOVB	MASK.D,MASKX	: GET MASK
2402	013142	013737	001434	001240		MOV	SYNCA,SYNCA	:
2403	013150	013737	001424	001236		MOV	L12.15,STAT	: LOAD LINE CARD STATUS
2404	013156	100402				BMI	103\$: BR IF LINE CARD NOT TO BE TESTED
2405	013160	004737	013166			JSR	PC,105\$: DO THE TESTS FOR LINE CARD 4
2406	013164	104400			103\$:	SCOPE		: SCOPE THIS TEST.
2407	013166				105\$:			: TEST ENTRANCE.
2408	013166	032737	004000	001236		BIT	#ASYNC,STAT	: IS THIS A SYNC LINE CARD?

K04

2409	013174	001401				BEQ	.+4	;BR IF SYNC LINE CARD.
2410	013176	000207				RTS	PC	;EXIT TEST
2411	013200	010037	013214			MOV	RO,65\$;LOAD LINE NO. POINTER
2412	013204	104412				MSTCLR		;RESET THE DV11
2413	013206	005001				CLR	R1	;ZERO MSCANNER POINTER
2414	013210	004537	022470		1\$:	PERFORM	.SETSCAN	;SET MSCANNER TO LINES TESTED
2415	013214	000001			65\$:	.BLKW	1	;INITIAL LINE VALUE
2416	013216	012703	000004		2\$:	MOV	#4,R3	;SET TO DO 4 LINE GROUP
2417	013222	005005			3\$:	CLR	R5	;ZERO
2418	013224	012777	050102	166146		MOV	#5.C+BIT6+BIT1,2	ADVSR
2419	013232	104415				ROMCLK		;SET/CLEAR "ADVANCE MSCANNER"
2420	013234	005201				INC	R1	;UPDATE MSCANNER POINTER
2421	013236	010077	166130		6\$:	MOV	RO,2DVSR	;LOAD LINE NUMBER INTO DV11
2422	013242	004537	022560			PERFORM	.CLR.TMARK	;CLR TMARK BIT.
2423	013246	004537	022266			PERFORM	.LOAD.MODE	;LOAD THE MODE
2424	013252	006000				BIT11+BIT10		;INT MAINT MODE AND SECOND SYNC
2425	013254	005077	166116			CLR	2DVSR	;ZERO DATA FOR XFR
2426	013260	012777	020000	166112		MOV	#BIT13,2DVSR	;DO A RAM READ INSTR.
2427	013266	104415				ROMCLK		
2428	013270	012777	030260	166102		MOV	#XFR+BIT7+BIT5+BIT4,2DVSR	
2429	013276	104415				ROMCLK		;DATA XFR TXBUFFER+RAM OUTPUT
2430	013300	104416				DATACLK		;ISSUE MAINT CLOCK PULSE
2431	013302	012737	013334	001220		MOV	#4\$,LOCK	;SET FOR SC 1
2432	013310	113702	001242			MOV	CLKX,R2	;NUMBER OF CLOCK PULSES NEEDED
2433	013314	104416				DATACLK		;MAINT CLOCK PULSE
2434	013316	005302				DEC	R2	;ALL CLOCKS DONE?
2435	013320	001375				BNE	.-4	;NO, DO MORE
2436	013322	113705	001240			MOV	SYNCR,R5	;GET SYNC (IDLE CHAR).
2437	013326	012737	000005	001250		MOV	#5,TEMP2	;SET FOR 5 CHARS
2438	013334	113702	001242		4\$:	MOV	CLKX,R2	;GET CLOCKS NEEDED
2439	013340	005037	022622			CLR	DATA	;ZERO STORAGE AREA
2440	013344	010077	166022			MOV	RO,2DVSR	;LOAD LINE NUMBER
2441	013350	104416			5\$:	DATACLK		;ISSUE MAINT CLK PULSE
2442	013352	004537	022246			PERFORM	.TXSHIFT	;CLOCK THE TRANSMITTER
2443	013356	005302				DEC	R2	;MORE SHIFTS REQUIRED?
2444	013360	001373				BNE	5\$;BR IF YES
2445	013362	022737	000010	001242		CMP	#8.,CLKX	;IS LINE CARD SET TO 8 BITS?
2446	013370	001414				BEQ	15\$;BR IF YES
2447	013372	013737	001242	001246		MOV	CLKX,TEMP1	;SAVE NUMBER OF SHIFTS DONE.
2448	013400	000241			16\$:	CLC		;CLEAR CARRY
2449	013402	006037	022622			ROR	DATA	;RIGHT JUSTIFY TX RESULTS.
2450	013406	005237	001246			INC	TEMP1	;ALL DONE?
2451	013412	022737	000010	001246		CMP	#8.,TEMP1	;?
2452	013420	001367				BNE	16\$;BR IF NO
2453	013422				15\$:			
2454	013422	013704	022622			MOV	DATA,R4	;SAVE DATA SHIFTED OUT OF TX
2455	013426	143704	001244			BICB	MASKX,R4	;CLEAR UNWANTED BITS.
2456	013432	042705	177400			BIC	#1C<37>,R5	;CLEAR SIGN EXTEND.
2457	013436	143705	001244			BICB	MASKX,R5	;CLEAR UNUSED BITS
2458	013442	042704	177400			BIC	#1C<37>,R4	;CLEAR SIGN EXTEND.
2459	013446	020504				CMP	R5,R4	;EXPECTED = FOUND ??
2460	013450	001401				BEQ	.-4	;BR IF OK
2461	013452	104003				HLT	3	;IDLE CHAR NOT WHAT EXPECTED.
2462	013454	005337	001250			DEC	TEMP2	;ALL IDLE CHARS DONE?
2463	013460	001325				BNE	4\$;BR IF NO
2464	013462	104401				SCOP1		;LOCK (SW09=1)?

2465	013464	004537	022546	PERFORM .SET.TMARK	;SET TMARK BIT
2466	013470	004537	022470	PERFORM .SETSCAN	;UPDATE SCANNER TO NEXT LINE
2467	013474	000001		1	
2468	013476	005303		DEC R3	;ALL LINES DONE
2469	013500	001256		BNE 6\$;BR IF NO
2470	013502	000207		RTS PC	;EXIT FOR NEXT GROUP OF LINES.

```

***** TEST 13 *****
;THIS TEST CHECKS "RECEIVE CHAR SILO" TO BE
;ALL ZERO'S WHEN "DATA ENABLE" IS NOT SET.
;EXPECTED DATA SHOULD BE LINE NUMBER ONLY
;DATA 0'S AND ERROR FLAGS 0.
;THIS TEST WILL BE DONE FOR BOTH ASYNC AND SYNC LINE CARDS.
*****

```

: TEST 13

2481				ST13:	MOV #13,TSTNO	
2482					MOV #TST14,NEXT	
2483	013504	012737	000013	001226	MOV #0,R0	;PLACE LINE NUMBER INTO R0
2484	013512	012737	014012	001216	MOV L00.03,STAT	;LOAD LINE CARD STATUS INTO STAT
2485	013520	012700	000000		BMI 100\$;BR IF LINE CARD NOT TO BE TESTED
2486	013524	013737	001416	001236	JSR PC,105\$;GO DO THE TEST FOR LINE CARD 1
2487	013532	100402			MOV #4,R0	;PLACE LINE NUMBER INTO R0
2488	013534	004737	013622		MOV L04.07,STAT	;LOAD LINE CARD STATUS INTO STAT
2489	013540	012700	000004		BMI 101\$;BR IF LINE CARD NOT TO BE TESTED
2490	013544	013737	001420	001236	JSR PC,105\$;GO DO THE TEST FOR LINE CARD 2
2491	013552	100402			MOV #8,R0	;LOAD LINE NUMBER
2492	013554	004737	013622		MC L08.11,STAT	;LOAD LINE CARD STATUS INTO STAT
2493	013560	012700	000010		BMI 102\$;BR IF LINE CARD NOT TO BE TESTED
2494	013564	013737	001422	001236	JSR PC,105\$;DO THE TEST FOR LINE CARD 3
2495	013572	100402			MOV #12,R0	;LOAD LINE NO.
2496	013574	004737	013622		MOV L12.15,-AT	;LOAD LINE CARD STATUS
2497	013600	012700	000014		BMI 103\$;BR IF LINE CARD NOT TO BE TESTED
2498	013604	013737	001424	001236	JSR PC,105\$;DO THE TESTS FOR LINE CARD 4
2499	013612	100402			SCOPE	;SCOPE THIS TEST.
2500	013614	004737	013622		MOV R0,65\$;TEST ENTRANCE.
2501	013620	104400			MOV #4,R3	;STORE LINE NO. POINTER
2502	013622				MSTCLR	;SET FOR 4 LINE GROUP
2503	013622	010037	013642		CLR R1	;RESET DV11
2504	013626	012703	000004		PERFORM ,SETSCAN	;ZERO MSCANNER POINTER
2505	013632	104412			.BLKW 1	;ADJUST SCANNER
2506	013634	005001			MOV R0,R5	;TO CORRECT LINE NO.
2507	013636	004537	022470		SWAB R5	;PLACE LINE NUMBER INTO R5
2508	013642	000001			CLRB R5	;PLACE LINE NO. IN HIGH BYTE
2509	013644	010005				;CLEAR LOW BYTE OF EXPECTED
2510	013646	000305				
2511	013650	105005				
2512	013652					
2513	013652	012777	050021	165520	MOV #S.C+BIT4+BIT0,ADVSR	
2514	013660	104415			ROMCLK	;SET/CLEAR SILO IN
2515	013662	005002			CLR R2	
2516	013664	012777	001400	165506	MOV #BIT9+BIT8,ADVSR	
2517	013672	032777	000001	165470	BIT #BIT0,ADVLCR	; "RCV CHAR WAITING TRUE"
2518	013700	001403			BEQ 5\$;BR IF YES
2519	013702	005202			INC R2	;DELAY IF NOT READY
2520	013704	001372			BNE 4\$;END OF DELAY?

M04

```

2521 013706 104000          HLT      0          ;"RCV CHAR WAITING" NOT TRUE
2522 013710 012777 030306 165462 5$:  MOV     #XFR+BIT7+BIT6+BIT2+BIT1,@DVSFR
2523 013716 017702 165456          MOV     @DVSFR,R2      ;XFR RICR+SILO OUT
2524 013722 104415          ROMCLK          ;DATA/XFER RICR+SILO OUT
2525 013724 017704 165436          MOV     @DVRIC,R4      ;READ RIC
2526 013730 020504          CMP     R5,R4          ;EXPECTED OK?
2527 013732 001401          BEQ     .+4
2528 013734 104001          HLT     1
2529 013736 062705 000400          ADD     #400,R5        ;UPDATE LINE NO. (POINTER)
2530 013742 005002          CLR     R2             ;SFR IMAGE
2531 013744 012777 050020 165426          MOV     #S.C+BIT4,@DVSFR
2532 013752 104415          ROMCLK          ;S/C "SET SILO OUT"
2533 013754 012777 001400 165416          MOV     #BIT9+BIT8,@DVSFR
2534 013762 032777 000001 165400 6$:  BIT     #BIT0,@DVLCR   ;"RCV CHAR WAITING"
2535 013770 001003          BNE     7$            ;FALSE?
2536 013772 005202          INC     R2             ;DELAY WAITING....
2537 013774 001372          BNE     6$            ;DELAY DONE?
2538 013776 104000          HLT     0
2539 014000 005237 013642 7$:  INC     65$           ;UPDATE MSCANNER POINTER(LINE)
2540 014004 005303          DEC     R3             ;GROUP OF 4 LINES DONE.
2541 014006 001311          BNE     1$            ;BR IF YES
2542 014010 000207          RTS     PC             ;EXIT FOR NEXT GROUP OF LINES
  
```

```

;***** TEST 14 *****
;*THIS TEST CHECKS "RECEIVER CHAR SILO"
;*WHEN "DATA ENABLE IS SET" EXPECTED DATA S/B
;*ALL 1'S FOR RX DATA. LINE NUMBER CORRECT,
;*AND ERROR FLAGS =0.
;*THIS TEST WILL BE DONE FOR SYNC LINE CARDS ONLY.
;*****
  
```

; TEST 14

```

2555 014012 012737 000014 001226 1ST14: MOV     #14,TSTNO
2556 014020 012737 014344 001216      MOV     #TST15,NEXT
2557 014026 012700 000000          MOV     #0.,RO        ;PLACE LINE NUMBER INTO RO
2558 014032 013737 001416 001236      MOV     LO0.03,STAT   ;LOAD LINE CARD STATUS INTO STAT
2559 014040 100402          BMI     100$         ;BR IF LINE CARD NOT TO BE TESTED
2560 014042 004737 014130          JSR     PC,105$       ;GO DO THE TEST FOR LINE CARD 1
2561 014046 012700 000004 100$:  MOV     #4.,RO        ;PLACE LINE NUMBER INTO RO
2562 014052 013737 001420 001236      MOV     LO4.07,STAT   ;LOAD LINE CARD STATUS INTO STAT
2563 014060 100402          BMI     101$         ;BR IF LINE CARD NOT TO BE TESTED
2564 014062 004737 014130          JSR     PC,105$       ;GO DO THE TEST FOR LINE CARD 2
2565 014066 012700 000010 101$:  MOV     #8.,RO        ;LOAD LINE NUMBER
2566 014072 013737 001422 001236      MOV     LO8.11,STAT   ;LOAD LINE CARD STATUS INTO STAT
2567 014100 100402          BMI     102$         ;BR IF LINE CARD NOT TO BE TESTED
2568 014102 004737 014130          JSR     PC,105$       ;DO THE TEST FOR LINE CARD 3
2569 014106 012700 000014 102$:  MOV     #12.,RO       ;LOAD LINE NO.
2570 014112 013737 001424 001236      MOV     L12.15,STAT   ;LOAD LINE CARD STATUS
2571 014120 100402          BMI     103$         ;BR IF LINE CARD NOT TO BE TESTED
2572 014122 004737 014130          JSR     PC,105$       ;DO THE TESTS FOR LINE CARD 4
2573 014126 104400          103$:  SCOPE             ;SCOPE THIS TEST.
2574 014130          105$:  TEST ENTRANCE.
2575 014130 032737 004000 001236      BIT     #ASYNC,STAT   ;IS THIS A SYNC LINE CARD?
2576 014136 001401          BEQ     .+4           ;BR IF SYNC LINE CARD.
  
```

```

2577 014140 000207          RTS      PC          ;EXIT TEST
2578 014142 010037 014162  MOV     RO,65$      ;STORE LINE NO. POINTER
2579 014146 012703 000004  MOV     #4,R3       ;SET FOR 4 LINE GROUP
2580 014152 104412          1$:    MSTCLR      ;RESET DV11
2581 014154 005001          CLR     R1          ;ZERO MSCANNER POINTER
2582 014156 004537 022470  PERFORM ,SETSCAN   ;ADJUST SCANNER
2583 014162 000001          65$:    .BLKW 1      ;TO CORRECT LINE NO.
2584 014164 010005          MOV     RO,R5       ;PLACE LINE NUMBER INTO R5
2585 014166 000305          SWAB   R5          ;PLACE LINE NO. IN HIGH BYTE
2586 014170 052705 000377  BIS     #377,R5     ;SET LOW BYTE TO ALL 1'S
2587 014174          3$:
2588 014174 012777 050023 165176  MOV     #S.C+BIT4+BIT1+BIT0,ADVSR ;S/C "SET REC'D DATA ENABLE"
2589 014202 104415          ROMCLK ;S/C "SET REC'D DATA ENABLE"
2590 014204 012777 050021 165166  MOV     #S.C+BIT4+BIT0,ADVSR ;SET/CLEAR SILO IN
2591 014212 104415          ROMCLK ;SET/CLEAR SILO IN
2592 014214 005002          CLR     R2          ;
2593 014216 012777 001400 165154  MOV     #BIT9+BIT8,ADVSR ;
2594 014224 032777 000001 165136  4$:    BIT     #BIT0,ADVLCR ;"RECV CHAR WAITING TRUE"
2595 014232 001403          BEQ    5$          ;BR IF YES
2596 014234 005202          INC    R2          ;DELAY IF NOT READY
2597 014236 001372          BNE   4$          ;END OF DELAY?
2598 014240 104000          HLT    0           ;"RECV CHAR WAITING" NOT TRUE
2599 014242 012777 030306 165130  5$:    MOV     #XFR+BIT7+BIT6+BIT2+BIT1,ADVSR ;XFR RICR+SILO OUT
2600 014250 017702 165124          MOV     ADVSR,R2   ;DATA/XFER RICR+SILO OUT
2601 014254 104415          ROMCLK ;READ RIC
2602 014256 017704 165104          MOV     ADVRIC,R4  ;EXPECTED OK?
2603 014262 020504          CMP    R5,R4
2604 014264 001401          BEQ    +4
2605 014266 104001          HLT    1
2606 014270 062705 000400          ADD    #400,R5    ;UPDATE LINE NO. (POINTER)
2607 014274 005002          CLR    R2         ;SFR IMAGE
2608 014276 012777 050020 165074  MOV     #S.C+BIT4,ADVSR ;S/C "SET SILO OUT"
2609 014304 104415          ROMCLK ;S/C "SET SILO OUT"
2610 014306 012777 001400 165064  MOV     #BIT9+BIT8,ADVSR ;
2611 014314 032777 000001 165046  6$:    BIT     #BIT0,ADVLCR ;"RECV CHAR WAITING"
2612 014322 001003          BNE   7$          ;FALSE?
2613 014324 005202          INC    R2         ;DELAY WAITING....
2614 014326 001372          BNE   6$          ;DELAY DONE?
2615 014330 104000          HLT    0
2616 014332 005237 014162          7$:    INC     65$       ;UPDATE MSCANNER POINTER(LINE)
2617 014336 005303          DEC    R3         ;GROUP OF 4 LINES DONE.
2618 014340 001304          BNE   1$          ;BR IF YES
2619 014342 000207          RTS     PC        ;EXIT FOR NEXT GROUP OF LINES

```

```

2620
2621
2622 ;***** TEST 15 *****
2623 ;*TEST THAT EACH RECEIVER WILL SET
2624 ;*"MATCH DETECT" WHEN THE FIRST SYNC
2625 ;*CHARACTER IS PUMPED INTO IT.
2626 ;*THIS TEST WILL BE DONE FOR SYNC LINE CARDS ONLY.
2627 ;*****
2628

```

```

2629 ; TEST 15
2630 -----
2631 014344 012737 000015 001226 TST15: MOV     #15,TSTNO
2632 014352 012737 014642 001216      MOV     #TST16,NEXT

```

000000	014360	012700	000000		MOV	#0, R0	: PLACE LINE NUMBER INTO R0
000001	014364	113737	001412	001242	MOV8	CLK.A, CLKX	: PLACE "SHIFTS/PER/CHAR" IN CLKX
000002	014368	013737	001416	001236	MOV	L00.03, STAT	: LOAD LINE CARD STATUS INTO STAT
000003	014372	100402			BMI	100\$: BR IF LINE CARD NOT TO BE TESTED
000004	014376	004737	014512		JSR	PC, 105\$: GO DO THE TEST FOR LINE CARD 1
000005	014380	012700	000004	100\$:	MOV	#4, R0	: PLACE LINE NUMBER INTO R0
000006	014384	113737	001412	001242	MOV8	CLK.B, CLKX	: PLACE "SHIFTS/PER/CHAR" IN CLKX
000007	014388	013737	001420	001236	MOV	L04.07, STAT	: LOAD LINE CARD STATUS INTO STAT
000008	014392	100402			BMI	101\$: BR IF LINE CARD NOT TO BE TESTED
000009	014396	004737	014512		JSR	PC, 105\$: GO DO THE TEST FOR LINE CARD 2
000010	014400	012700	000010	101\$:	MOV	#8, R0	: LOAD LINE NUMBER
000011	014404	113737	001414	001242	MOV8	CLK.C, CLKX	: GET SHIFTS PER CHAR
000012	014408	013737	001422	001236	MOV	L08.11, STAT	: LOAD LINE CARD STATUS INTO STAT
000013	014412	100402			BMI	102\$: BR IF LINE CARD NOT TO BE TESTED
000014	014416	004737	014512		JSR	PC, 105\$: DO THE TEST FOR LINE CARD 3
000015	014420	012700	000014	102\$:	MOV	#12, R0	: LOAD LINE NO.
000016	014424	113737	001415	001242	MOV8	CLK.D, CLKX	: GET SHIFTS
000017	014428	013737	001424	001236	MOV	L12.15, STAT	: LOAD LINE CARD STATUS
000018	014432	100402			BMI	103\$: BR IF LINE CARD NOT TO BE TESTED
000019	014436	004737	014512		JSR	PC, 105\$: DO THE TESTS FOR LINE CARD 4
000020	014440	104400		103\$:	SCOPE		: SCOPE THIS TEST.
000021	014444			105\$:			: TEST ENTRANCE.
000022	014448	032737	004000	001236	BIT	#ASYNC, STAT	: IS THIS A SYNC LINE CARD?
000023	014452	001401			BEQ	.+4	: BR IF SYNC LINE CARD.
000024	014456	000207			RTS	PC	: EXIT TEST
000025	014460	012703	000004		MOV	#4, R3	
000026	014464	010037	014544		MOV	R0, 65\$: SET LINE NO. POINTER
000027	014468	104412		1\$:	MSTCLR		: RESET DVI!
000028	014472	005001			CLR	R1	: ZERO MSCANNER POINTER
000029	014476	004537	022470		PERFORM	.SETSCAN	
000030	014480	000001		65\$:	.BLKW 1		: SET MSCANNER TO CORRECT LINE.
000031	014484	010077	164620	3\$:	MOV	R0, JDVSR5	: LOAD LINE NO.
000032	014488	004537	022266		PERFORM	LOAD.MODE	: LOAD THE MODE
000033	014492	025000			BIT13+BIT11+BIT9		: REC' ENABLE INT MAINT. TX DSABLE
000034	014496	113737	001236	022622	MOV8	STAT, DATA	: GET "SYNC" CHAR.
000035	014500	104416			DATACLK		: PRIME DVI!
000036	014504	004537	022326		PERFORM	.RXSHIFT	: SHIFT DATA INTO RECEIVER
000037	014508	001242			CLKX		: NO. OF SHIFTS GIVEN
000038	014512	012777	076400	164574	MOV	#BRB+BIT11+BIT10, BIT8, JDVSR	: BRB "MATCH DET"
000039	014516	017704	164560		MOV	JDVLCR, R4	
000040	014520	010405			MOV	R4, R5	
000041	014524	052705	000001		BIS	#BIT0, R5	
000042	014528	042705	000002		BIC	#BIT1, R5	
000043	014532	020504			CMP	R5, R4	: MATCH DET TRUE??
000044	014536	001401			BEQ	4\$: BR IF YES
000045	014540	104001			HLT	!	
000046	014544	005237	014544	4\$:	INC	65\$: UPDATE TO NEXT LINE.
000047	014548	005303			DEC	R3	: 4 LINE GROUP DONE?
000048	014552	001336			BNE	1\$: BR IF NO
000049	014556	000207			RTS	PC	: OBTAIN NEXT 4 LINE GROUP

***** TEST 16 *****
 : *TEST TO VERIFY THAT IF THE DVI1 RECEIVER
 : *IS SET FOR ONE SYN CHAR:
 : *"MATCH DET" *AND* "CHAR FLAG" ARE

C05

: *SET AFTER ONE SYNC IS PUSHED INTO THE RECEIVER
: * HOWEVER.
: * IF THE DVII RECEIVER IS SET FOR
: * TWO SYNC CHARS.
: * VERIFY THAT "MATCH DET" SETS ON THE FIRST SYNC
: * AND VERIFY THAT "MATCH DET" *AND* "CHAR FLAG"
: * ARE SET ON THE SECOND SYNC.
: * THIS TEST USES "SYNC A"
: * THIS TEST WILL BE DONE FOR SYNC LINE CARDS ONLY.
: *****

: TEST 16

014643 012737 000016 001226
014650 012737 015276 001216
014656 012700 000000
014662 113737 001412 001242
014670 013737 001416 001236
014676 100402
014680 004737 015010
014704 012700 000004
014710 113737 001413 001242
014716 013737 001420 001236
014724 100402
014728 004737 015010
014732 012700 000010
014736 113737 001414 001242
014744 013737 001422 001236
014752 100402
014754 004737 015010
014760 012700 000014
014764 113737 001415 001242
014772 013737 001424 001236
015000 100402
015002 004737 015010
015006 104400
015010
015010 032737 004000 001236
015016 001401
015020 000207
015022 012703 000004
015026 010037 015042
015032 104412
015034 005001
015036 004537 022470
015042 000001
015044 010077 164322
015050 004537 022266
015054 025000
015056 113737 001236 022622
015064 104416
015066 004537 022326
015072 001242
015074 012777 076400 164276
015102 017704 164262

TST16: MOV #16,TSTNO
MOV #TST17,NEXT
MOV #0,R0
MOV CLK.A,CLKX
MOV L00.03,STAT
BMI 1005
JSR PC,1055
1005: MOV #4,R0
MOV CLK.B,CLKX
MOV L04.07,STAT
BMI 1015
JSR PC,1055
1015: MOV #8,R0
MOV CLK.C,CLKX
MOV L09.11,STAT
BMI 1025
JSR PC,1055
1025: MOV #12,R0
MOV CLK.D,CLKX
MOV L12.15,STAT
BMI 1035
JSR PC,1055
1035: SCOPE
1055: BIT #ASYNC,STAT
BEQ +4
RTS PC
MOV #4,R3
MOV R0,655
15: MSTCLR
CLR R1
PERFORM ,SETSCAN
655: .BLKW 1
35: MOV R0,0DVSRS
PERFORM ,LOAD.MCDE
BIT13+BIT11+BIT9
MOV STAT,DATA
DATA CLK
PERFORM ,RXSHIFT
CLKX
MOV #BRB+BIT11+BIT10+BIT8,0DVSFR
MOV 0DVLCP,R4

: PLACE LINE NUMBER INTO R0
: PLACE "SHIFTS/PER/CHAR" IN CLKX
: LOAD LINE CARD STATUS INTO STAT
: BR IF LINE CARD NOT TO BE TESTED
: GO DO THE TEST FOR LINE CARD 1
: PLACE LINE NUMBER INTO R0
: PLACE "SHIFTS/PER/CHAR" IN CLKX
: LOAD LINE CARD STATUS INTO STAT
: BR IF LINE CARD NOT TO BE TESTED
: GO DO THE TEST FOR LINE CARD 2
: LOAD LINE NUMBER
: GET SHIFTS PER CHAR
: LOAD LINE CARD STATUS INTO STAT
: BR IF LINE CARD NOT TO BE TESTED
: DO THE TEST FOR LINE CARD 3
: LOAD LINE NO.
: GET SHIFTS
: LOAD LINE CARD STATUS
: BR IF LINE CARD NOT TO BE TESTED
: DO THE TESTS FOR LINE CARD 4
: SCOPE THIS TEST.
: TEST ENTRANCE.
: IS THIS A SYNC LINE CARD?
: BR IF SYNC LINE CARD.
: EXIT TEST
: SET FOR 4 LINES
: PLACE LINE NO. POINTER
: INIT DVII
: ZERO MSCANNER POINTER
: SET SCANNER TO LINE DESIRED
: INITIAL LINE NUMBER.
: LOAD LINE NUMBER
: LOAD
: MODE AND RX ENABLE AND TX DISABLE
: PLACE SYNC CHAR IN DATA
: INIT DATA CLOCK.
: SHIFT DATA INTO RX
: NUMBER OF SHIFTS NEEDED
: SET BR "B" AND MATCH DET.
: SAVE LPR IN R4

```

00000001 01101000 00000001
00000002 01101001 00000002
00000003 01101002 00000003
00000004 01101003 00000004
00000005 01101004 00000005
00000006 01101005 00000006
00000007 01101006 00000007
00000008 01101007 00000008
00000009 01101008 00000009
00000010 01101009 00000010
00000011 01101010 00000011
00000012 01101011 00000012
00000013 01101012 00000013
00000014 01101013 00000014
00000015 01101014 00000015
00000016 01101015 00000016
00000017 01101016 00000017
00000018 01101017 00000018
00000019 01101018 00000019
00000020 01101019 00000020
00000021 01101020 00000021
00000022 01101021 00000022
00000023 01101022 00000023
00000024 01101023 00000024
00000025 01101024 00000025
00000026 01101025 00000026
00000027 01101026 00000027
00000028 01101027 00000028
00000029 01101028 00000029
00000030 01101029 00000030
00000031 01101030 00000031
00000032 01101031 00000032
00000033 01101032 00000033
00000034 01101033 00000034
00000035 01101034 00000035
00000036 01101035 00000036
00000037 01101036 00000037
00000038 01101037 00000038
00000039 01101038 00000039
00000040 01101039 00000040
00000041 01101040 00000041
00000042 01101041 00000042
00000043 01101042 00000043
00000044 01101043 00000044
00000045 01101044 00000045
00000046 01101045 00000046
00000047 01101046 00000047
00000048 01101047 00000048
00000049 01101048 00000049
00000050 01101049 00000050
00000051 01101050 00000051
00000052 01101051 00000052
00000053 01101052 00000053
00000054 01101053 00000054
00000055 01101054 00000055
00000056 01101055 00000056
00000057 01101056 00000057
00000058 01101057 00000058
00000059 01101058 00000059
00000060 01101059 00000060
00000061 01101060 00000061
00000062 01101061 00000062
00000063 01101062 00000063
00000064 01101063 00000064
00000065 01101064 00000065
00000066 01101065 00000066
00000067 01101066 00000067
00000068 01101067 00000068
00000069 01101068 00000069
00000070 01101069 00000070
00000071 01101070 00000071
00000072 01101071 00000072
00000073 01101072 00000073
00000074 01101073 00000074
00000075 01101074 00000075
00000076 01101075 00000076
00000077 01101076 00000077
00000078 01101077 00000078
00000079 01101078 00000079
00000080 01101079 00000080
00000081 01101080 00000081
00000082 01101081 00000082
00000083 01101082 00000083
00000084 01101083 00000084
00000085 01101084 00000085
00000086 01101085 00000086
00000087 01101086 00000087
00000088 01101087 00000088
00000089 01101088 00000089
00000090 01101089 00000090
00000091 01101090 00000091
00000092 01101091 00000092
00000093 01101092 00000093
00000094 01101093 00000094
00000095 01101094 00000095
00000096 01101095 00000096
00000097 01101096 00000097
00000098 01101097 00000098
00000099 01101098 00000099
00000100 01101099 00000100
    
```

```

MOV R4,R5 ;SET FOR COMPARE
BIS #BIT0,R5 ;BR "A" FALSE
BIS #BIT1,R5 ;BR "B" TRUE
CMP R5,R4
BEQ .+4 ;BR IF LPR OK.
HLT . ;EXPECT B TRUE; A FALSE
MOV #BIT0,2DVSFR ;SET BR "A" AND RX CHAR FLAG.
MOV 2DVLCP,R4 ;SAVE LPR IN R4
MOV R4,R5 ;SET FOR COMPARE
BIT #TWO SYN,STAT ;SET FOR ONE SYNC OR TWO
BNE 4$ ;BR IF SET FOR ONE SYNC
BIS #BIT1+BIT0,R5
CMP R5,R4
BEQ .+4
HLT .
MOV9 STAT,DATA
PERFORM .RXSHIFT
CHKX
MOV #BRB+BIT11+BIT10+BIT8,2DVSFR ;SET BR "B" AND MATCH DET.
MOV 2DVLCP,R4 ;SAVE LPR IN R4
MOV R4,R5 ;SET FOR COMPARE
BIS #BIT0,R5 ;BR "A" FALSE
BIS #BIT1,R5 ;BR "B" TRUE
CMP R5,R4
BEQ .+4 ;BR IF LPR OK.
HLT . ;EXPECT B TRUE; A FALSE
MOV #BIT10,2DVSFR ;SET BR "A" AND RX CHAR FLAG.
MOV 2DVLCP,R4 ;SAVE LPR IN R4
MOV R4,R5 ;SET FOR COMPARE
BIS #BIT1,R5
BIS #BIT0,R5
CMP R5,R4
BEQ .+4
HLT .
INC R5 ;UPDATE LINE NUMBER
DEC R5
INC PC
    
```

```

***** TEST 17 *****
*TEST TO VERIFY THAT IF THE DVII RECEIVER
*IS SET FOR ONE SYNC CHAR:
* "MATCH DET" *AND* "CHAR FLAG" ARE
*SET AFTER ONE SYNC IS PUSHED INTO THE RECEIVER
* HOWEVER...
*IF THE DVII RECEIVER IS SET FOR
*TWO SYNC CHARS...
*VERIFY THAT "MATCH DET" SETS ON THE FIRST SYNC
*AND VERIFY THAT "MATCH DET" *AND* "CHAR FLAG"
*ARE SET ON THE SECOND SYNC.
*THIS TEST USES "SYNC B".
*THIS TEST WILL BE DONE FOR SYNC LINE CARDS ONLY.
*****
    
```


E05

28000
28001
28002
28003
28004
28005
28006
28007
28008
28009
28010
28011
28012
28013
28014
28015
28016
28017
28018
28019
28020
28021
28022
28023
28024
28025
28026
28027
28028
28029
28030
28031
28032
28033
28034
28035
28036
28037
28038
28039
28040
28041
28042
28043
28044
28045
28046
28047
28048
28049
28050
28051
28052
28053
28054
28055
28056

```

015376 012737 000017 001226
015304 012737 015762 001215
015312 012700 000000
015316 113737 001412 001242
015324 013737 001426 001240
015332 013737 001416 001236
015340 100402
015342 004737 015474
015346 012700 000004 1003:
015352 113737 001413 001242
015350 013737 001430 001240
015366 013737 001420 001236
015374 100402
015376 004737 015474
015402 012700 000010 1015:
015406 113737 001414 001242
015414 013737 001432 001240
015422 013737 001422 001236
015430 100402
015432 004737 015474
015436 012700 000014 1025:
015442 113737 001415 001242
015450 013737 001434 001240
015456 013737 001424 001236
015464 100402
015466 004737 015474
015472 104400 1035:
015474 104400 1055:
015474 032737 004000 001236
015502 001401
015504 000207
015506 012703 000004
015512 010037 015526 15:
015516 104412
015520 005001
015522 004537 022470
015526 000001 655:
015530 010077 163636 35:
015534 004537 022266
015540 027000
015542 013737 001240 022622
015550 104416
015552 004537 022326
015556 001242
015560 012777 076400 163612
015566 017704 163576
015572 010405
015574 052705 000001
015600 042705 000002
015604 020504
015606 001401
015610 104001
015612 012777 002000 163560
  
```

```

: TEST 17
-----
1ST17: MOV #17,TSTNO
MOV #TST20,NEXT
MOV #0,R0
MOV#B CLK.A,CLKX
MOV SYNC2A,SYNXX
MOV L00.03,STAT
BMI 100$
JSR PC,105$
100$: MOV #4,R0
MOV#B CLK.B,CLKX
MOV SYNC2B,SYNXX
MOV L04.07,STAT
BMI 101$
JSR PC,105$
101$: MOV #8,R0
MOV#B CLK.C,CLKX
MOV SYNC2C,SYNXX
MOV L08.11,STAT
BMI 102$
JSR PC,105$
102$: MOV #12,R0
MOV#B CLK.D,CLKX
MOV SYNC2D,SYNXX
MOV L12.15,STAT
BMI 103$
JSR PC,105$
103$: SCOPE
105$: BIT #ASYNC,STAT
BEQ .+4
RTS PC
MOV #4,R3
MOV RO,65$
15: MSTCLR
CLR R1
PERFORM ,SETSCAN
65$: .BLKW 1
35: MOV RO,DDVSR5
PERFORM ,LOAD MODE
BIT13+BIT11+BIT10+BIT9
MOV SYNXX,DATA
DATACLK
PERFORM ,RXSHIFT
CLKX
MOV #BRB+BIT11+BIT10
MOV DDVLCR,R4
MOV R4,R5
BIS #BIT0,R5
BIC #BIT1,R5
CMP R5,R4
BEQ .+4
HLT 1
MOV #BIT10,DDVSRF
  
```

```

:PLACE LINE NUMBER INTO RO
:PLACE "SHIFTS/PER/CHAR" IN CLKX
:LOAD LINE CARD STATUS INTO STAT
:BR IF LINE CARD NOT TO BE TESTED
:GO DO THE TEST FOR LINE CARD 1
:PLACE LINE NUMBER INTO RO
:PLACE "SHIFTS/PER/CHAR" IN CLKX
:LOAD LINE CARD STATUS INTO STAT
:BR IF LINE CARD NOT TO BE TESTED
:GO DO THE TEST FOR LINE CARD 2
:LOAD LINE NUMBER
:GET SHIFTS PER CHAR
:LOAD LINE CARD STATUS INTO STAT
:BR IF LINE CARD NOT TO BE TESTED
:DO THE TEST FOR LINE CARD 3
:LOAD LINE NO.
:GET SHIFTS
:LOAD LINE CARD STATUS
:BR IF LINE CARD NOT TO BE TESTED
:DO THE TESTS FOR LINE CARD 4
:SCOPE THIS TEST.
:TEST ENTRANCE.
:IS THIS A SYNC LINE CARD?
:BR IF SYNC LINE CARD.
:EXIT TEST
:SET FOR 4 LINES
:PLACE LINE NO. POINTER
:INIT DV11
:ZERO MSCANNER POINTER
:SET SCANNER TO LINE DESIRED
:INITIAL LINE NUMBER.
:LOAD LINE NUMBER
:LOAD
:MODE, RX ENABL, TX DSABL, SYNC2
:PLACE SYNC 2 IN DATA
:INIT DATA CLOCK.
:SHIFT DATA INTO RX
:NUMBER OF SHIFTS NEEDED
:BIT8,DDVSRF
:SET BR "B" AND MATCH DET.
:SAVE LPR IN R4
:SET FOR COMPARE
:BR "A" FALSE
:BR "B" TRUE
:BR IF LPR OK.
:EXPECT B TRUE; A FALSE
:SET BR "A" AND RX CHAR FLAG.
  
```


G05

2913	016044	113737	001407	001244	MOV8	MASK.B,MASKX	:GET MASK
2914	016052	013737	001420	001236	MOV	L04.07,STAT	:LOAD LINE CARD STATUS INTO STAT
2915	016060	100402			BMI	101\$:BR IF LINE CARD NOT TO BE TESTED
2916	016062	004737	016160		JSR	PC,105\$:GO DO THE TEST FOR LINE CARD 2
2917	016066	012700	000010		MOV	#9,R0	:LOAD LINE NUMBER
2919	016072	113737	001414	001242	MOV8	CLK.C,CLKX	:GET SHIFTS PER CHAR
2919	016100	113737	001410	001244	MOV8	MASK.C,MASKX	:GET MASK
2920	016106	013737	001422	001236	MOV	L08.11,STAT	:LOAD LINE CARD STATUS INTO STAT
2921	016114	100402			BMI	102\$:BR IF LINE CARD NOT TO BE TESTED
2922	016116	004737	016160		JSR	PC,105\$:DO THE TEST FOR LINE CARD 3
2923	016122	012700	000014		MOV	#12,R0	:LOAD LINE NO.
2924	016126	113737	001415	001242	MOV8	CLK.D,CLKX	:GET SHIFTS
2925	016134	113737	001411	001244	MOV8	MASK.D,MASKX	:GET MASK
2926	016142	013737	001424	001236	MOV	L12.15,STAT	:LOAD LINE CARD STATUS
2927	016150	100402			BMI	103\$:BR IF LINE CARD NOT TO BE TESTED
2928	016152	004737	016160		JSR	PC,105\$:DO THE TESTS FOR LINE CARD 4
2929	016156	104400			SCOPE		:SCOPE THIS TEST.
2930	016160						:TEST ENTRANCE.
2931	016160	032737	004000	001236	BIT	#ASYNC,STAT	:IS THIS A SYNC LINE CARD?
2932	016166	001401			BEQ	.+4	:BR IF SYNC LINE CARD.
2933	016170	000207			RTS	PC	:EXIT TEST
2934	016172	012703	000004		MOV	#4,R3	:SET FOR 4 LINE GROUP
2935	016176	010037	016212		MOV	R0,65\$:SET LINE POINTER
2936	016202	104412			MSTCLR		:RESET DV11
2937	016204	005001			CLR	R1	:ZERO MSCANNER POINTER
2938	016206	004537	022470		PERFORM	.SETSCAN	:ADJUST MSCANNER
2939	016212	000001			.BLKW 1		:LINE POINTER
2940	016214	010077	163152		MOV	R0,ADVSR5	:LOAD LINE NUMBER
2941	016220	012777	125000	163142	MOV	#BIT15+BIT13+BIT11+BIT9,ADVLCR	
2942	016226	004737	022406		JSR	PC,CKBIT15	
2943	016232	113737	001236	022622	MOV8	STAT,DATA	:GET SYNC CHAR
2944	016240	104416			DATACLK		:INIT DV11 BY ONE CLOCK
2945	016242	113737	001242	016576	MOV8	CLKX,10\$:GET NUMBER OF SHIFTS PER CHAR.
2946	016250	004537	022326		PERFORM	,RXSHIFT	:CLOCK RX
2947	016254	016576			10\$:NUMBER OF SHIFTS
2948	016256	113737	001236	022622	MOV8	STAT,DATA	:GET ANOTHER SYNC
2949	016264	004537	022326		PERFORM	,RXSHIFT	:SHIFT RX
2950	016270	016576			10\$:NUMBER OF SHIFTS
2951	016272	113737	001236	022622	MOV8	STAT,DATA	:SYNC CHAR
2952	016300	162737	000001	016576	SUB	#1,10\$:SET NUMBER OF SHIFTS -1
2953	016306	004537	022326		PERFORM	,RXSHIFT	:SHIFT RX
2954	016312	016576			10\$:SHIFTS
2955	016314	012777	050023	163056	MOV	#S.C+BIT4+BIT1+BIT0,ADVSR5	
2956	016322	104415			ROMCLK		:S/C "SET RECV DATA ENABLE"
2957	016324	012777	050021	163046	MOV	#S.C+BIT4+BIT0,ADVSR5	
2958	016332	104415			ROMCLK		:SET/CLEAR SILO IN
2959	016334	012777	001400	163036	MOV	#BIT9+BIT8,ADVSR5	
2960	016342	032777	000001	163020	BIT	#BIT0,ADVLCR	:RCV CHAR WAITING?"
2961	016350	001374			BNE	4\$:BR IF YES
2962	016352	012702	030306		MOV	#XFR+BIT7+BIT6+BIT2+BIT1,R2	
2963	016356	010277	163016		MOV	R2,ADVSR5	:XFR RIC+SILO OUT
2964	016362	104415			ROMCLK		:DATA/XFER RIC+SILO OUT
2965	016364	017704	162776		MOV	ADVRC,R4	:READ DVRIC REG
2966	016370	010405			MOV	R4,R5	
2967	016372	042705	020000		BIC	#BIT13,R5	
2968	016376	020504			CMF	R5,R4	:OVERRUN?"

H05

2999	016400	001401		BEQ	.+4		:BR IF NO
2999	016402	104001		HLT	1		:OVERRUN OCCURED TO SOON.
2999	016404	004537	022456	PERFORM	.SILO.OUT		:SILO OUT
2999	016410	113737	001236 022622	MOVB	STAT,DATA		
2999	016416	113704	001242	MOVB	CLKX,R4		
2999	016422	005304		DEC	R4		
2999	016424	000241	66\$:	CLC			
2999	016426	106037	022622	RORB	DATA		
2999	016432	105304		DECB	R4		
2999	016434	001373		BNE	66\$		
2999	016436	012737	000001 016576	MOV	#1,10\$		
2999	016444	004537	022326	PERFORM	.RXSHIFT		
2999	016450	016576		10\$			
2999	016452	012777	050021 162720	MOV	#S.C+BIT4+BIT0,ADVSR		
2999	016460	104415		ROMCLK			:SET/CLEAR SILO IN
2999	016462	012777	001400 162710	MOV	#BIT9+BIT8,ADVSR		
2999	016470	032777	000001 162672 5\$:	BIT	#BIT0,ADVLCR		:RECV CHAR WAITING
2999	016476	001374		BNE	5\$		
2999	016500	010005		MOV	R0,R5		:GET LINE NUMBER
2999	016502	000305		SWAB	R5		:PUT LINE NUMBER INTO HIGH BYTE
2999	016504	153705	001236	BISB	STAT,R5		:PLACE SYNC INTO EXPECTED
2999	016510	143705	001244	BICB	MASKX,R5		:CLEAR UNUSED BITS.
2999	016514	052705	020000	BIS	#BIT13,R5		:SET OVERRUN
2999	016520	012702	030306	MOV	#XFR+BIT7+BIT6+BIT2+BIT1,R2		
2999	016524	010277	162650	MOV	R2,ADVSR		
2999	016530	104415		ROMCLK			:DATA/XFER RICR+SILO OUT
2999	016532	017704	162630	MOV	ADVRC,R4		:READ DVRC
2999	016536	032737	040000 001236	BIT	#PARBIT,STAT		:PARITY?
2999	016544	001402		BEQ	6\$:BR IF NO
2999	016546	042704	010000	BIC	#BIT12,R4		:CLEAR PARITY ERROR IF IT EXISTS
2999	016552	020504	5\$:	CMP	R5,R4		:OVERRUN SET?
3000	016554	001401		BEQ	.+4		:BR IF YES
3001	016556	104001		HLT	1		:LINE,CHAR,AND OVERRUN EXPECTED.
3002	016560	004537	022456	PERFORM	.SILO.OUT		:SILO OUT
3003	016564	005237	016212	INC	65\$:UPDATE LINE POINTER
3004	016570	005303		DEC	R3		:4 LINE GROUP DONE?
3005	016572	001203		BNE	1\$:BR IF NO
3006	016574	000207		RTS	PC		:RETURN FOR NEXT 4 LINE GROUP
3007	016576	000001	10\$:	.BLKW	1		

***** TEST 21 *****
: *TEST OF RECEIVER DATA.
: *THIS TEST RUNS A BINARY COUNT PATTERN THROUGH
: *THE RECEIVER OF EACH LINE
: *THROUGH THE USE OF MAINT. DATA BIT.
: *THE TX IS NEVER ENABLED.
: *THIS TEST WILL BE DONE FOR SYNC LINE CARDS ONLY.
: *****

: TEST 21

3021	016600	012737	000021 001226	TST21: MOV	#21,TSTNO		
3022	016606	012737	017346 001216	MOV	#TST22,NEXT		
3023	016614	012700	000000	MOV	#0,R0		:PLACE LINE NUMBER INTO R0
3024	016620	113737	001412 001242	MOVB	CLK.A,CLKX		:PLACE "SHIFTS PER CHAR" IN CLKX

3025	016626	113737	001406	001244	MOV	MASK.A, MASKX	: PLACE "MASK" FOR CHARS INTO MASKX
3026	016634	013737	001416	001236	MOV	LOO.O3, STAT	: LOAD LINE CARD STATUS INTO STAT
3027	016642	100402			BMI	100\$: BR IF LINE CARD NOT TO BE TESTED
3028	016644	004737	016776		JSR	PC, 105\$: GO DO THE TEST FOR LINE CARD 1
3029	016650	012700	000004		MOV	#4., RO	: PLACE LINE NUMBER INTO RO
3030	016654	113737	001413	001242	MOV	CLK.B, CLKX	: PLACE "SHIFTS/PER/CHAR" IN CLKX
3031	016662	113737	001407	001244	MOV	MASK.B, MASKX	: GET MASK
3032	016670	013737	001420	001236	MOV	LO4.O7, STAT	: LOAD LINE CARD STATUS INTO STAT
3033	016676	100402			BMI	101\$: BR IF LINE CARD NOT TO BE TESTED
3034	016700	004737	016776		JSR	PC, 105\$: GO DO THE TEST FOR LINE CARD 2
3035	016704	012700	000010		MOV	#8., RO	: LOAD LINE NUMBER
3036	016710	113737	001414	001242	MOV	CLK.C, CLKX	: GET SHIFTS PER CHAR
3037	016716	113737	001410	001244	MOV	MASK.C, MASKX	: GET MASK
3038	016724	013737	001422	001236	MOV	LO6.11, STAT	: LOAD LINE CARD STATUS INTO STAT
3039	016732	100402			BMI	102\$: BR IF LINE CARD NOT TO BE TESTED
3040	016734	004737	016776		JSR	PC, 105\$: DO THE TEST FOR LINE CARD 3
3041	016740	012700	000014		MOV	#12., RO	: LOAD LINE NO.
3042	016744	113737	001415	001242	MOV	CLK.D, CLKX	: GET SHIFTS
3043	016752	113737	001411	001244	MOV	MASK.D, MASKX	: GET MASK
3044	016760	013737	001424	001236	MOV	L12.15, STAT	: LOAD LINE CARD STATUS
3045	016766	100402			BMI	103\$: BR IF LINE CARD NOT TO BE TESTED
3046	016770	004737	016776		JSR	PC, 105\$: DO THE TESTS FOR LINE CARD 4
3047	016774	104400			SCOPE		: SCOPE THIS TEST.
3048	016776						: TEST ENTRANCE.
3049	016776	032737	004000	001236	BIT	#ASYNC, STAT	: IS THIS A SYNC LINE CARD?
3050	017004	001401			BEG	.+4	: BR IF SYNC LINE CARD.
3051	017006	000207			RTS	PC	: EXIT TEST
3052	017010	012703	000004		MOV	#4.R3	: SET FOR 4 LINE GROUP.
3053	017014	010037	017030		MOV	RO, 65\$: PLACE LINE POINTER
3054	017020	104412			MSTCLR		: CLEAR THE DV11
3055	017022	005001			CLR	R1	: ZERO MSCANNER POINTER
3056	017024	004537	022470		PERFORM	.SETSCAN	: SET SCANNER
3057	017030	000001			.BLKW 1		: POSITION MSCAN TO LINE NO.
3058	017032	010077	162334		MOV	RO, ADVSR5	: LOAD LINE NUMBER
3059	017036	012777	125000	162324	MOV	#BIT15+BIT13+BIT11+BIT9, ADVLCR	: GO WAIT FOR BIT15 TO=0
3060	017044	004737	022406		JSR	PC, CKBIT15	: LOAD SYNC CHAR
3061	017050	113737	001236	022622	MOV	STAT, DATA	: GIVE AN INITIAL CLOCK
3062	017056	104416			DATACLK		: STROBE CHAR INTO RX.
3063	017060	004537	022326		PERFORM	.RXSHIFT	: PICK UP NO. OF CLOCKS.
3064	017064	001242			CLKX		: TWO SYNCs REQUIRED??
3065	017066	032737	010000	001236	BIT	#TWO SYN, STAT	: BR IF ONLY ONE SYNC..
3066	017074	001006			BNE	4\$: GIVE ANOTHER SYNC TO THE RX
3067	017076	113737	001236	022622	MOV	STAT, DATA	: STROBE IT IN
3068	017104	004537	022326		PERFORM	.RXSHIFT	: SHIFTS REQUIRED
3069	017110	001242			CLKX		: LOAD LINE NUMBER INTO "EXPECTED"
3070	017112	010005			MOV	RO, R5	: PLACE IT INTO HIGH BYTE
3071	017114	000305			SWAB	R5	: ZERO LOW BYTE
3072	017116	105005			CLRB	R5	: SET IF SW09=1: GOTO 5\$
3073	017120	012737	017174	001220	MOV	#5\$, LOCK	: CLOCK "DATA ENABLE"
3074	017126	012777	050023	162244	MOV	#5.C+BIT4+BIT1+BIT0, ADVSFR	: READ RX BUFFER INTO SILO
3075	017134	104415			ROMCLK		: SET FOR DELAY
3076	017136	004537	022434		PERFORM	.SILO.IN	
3077	017142	005002			CLR	R2	
3078	017144	012777	001400	162226	MOV	#BIT9+BIT8, ADVSFR	
3079	017152	032777	000001	162210	BIT	#BIT0, ADVLCR	: IS "RX CHAR WAITING" TRUE?
3080	017150	001403			BEG	9\$: BR IF TRUE..

J05

```

3091 017162 005202          INC      R2          :DELAY.....
3092 017164 001372          BNE     10$         :BR IF DELAY NOTDONE
3093 017166 104000          HLT     0           :RX CHAR WAITING NOT TRUE!
3094 017170 004537 022456      9$: PERFORM ,SILO.OUT :REMOVE CHAR FROM SILO
3095 017174 010537 022622      5$: MOV     R5,DATA   :PLACE CHAR INTO SOFTWARE LOC.
3095 017200 105037 022623          CLRB   DATA+1    :ZERO LINE NUMBER.
3097 017204 004537 022326          PERFORM ,RXSHIFT  :PLACE CHAR INTO RX BUFFER.
3098 017210 001242          CLKX                   :CLOCKS.
3099 017212 012777 050023 162160      MOV     #5,C+BIT4+BIT1+BIT0 :TO ADVSFR
3099 017220 104415          ROMCLK                :SET RX DATA ENABLE
3091 017222 004537 022434          PERFORM ,SILO.IN  :READ FROM RX BUFFER INTO SILO
3092 017226 005002          CLR     R2          :SET DELAY
3093 017230 012777 001400 162142      MOV     #BIT9+BIT8,ADVSFR
3094 017236 032777 000001 152124      6$: BIT     #BIT0,ADVLCR  :WAIT FOR RX CHAR WAITING
3095 017244 001403          BEQ    7$          :BR IF TRUE
3096 017246 005202          INC     R2          :UPDATE DELAY
3097 017250 001372          BNE     6$         :GOBACK
3098 017252 104000          HLT     0           :RX CHAR WAITING NOT TRUE
3099 017254 012702 030306      7$: MOV     #XFR+BIT7+BIT6+BIT5+BIT4+BIT3+BIT2+BIT1,R2
3100 017260 010277 162114          MOV     R2,ADVSFR  :DO DATA XFER FROM SILO TO DVRIC
3101 017264 104415          ROMCLK                :CLOCK
3102 017266 017704 162074          MOV     ADVRIC,R4   :LOAD DVRIC TO "FOUND" LOC.
3103 017272 032737 040000 001236      BIT     #PARBIT,STAT :PARITY ON??
3104 017300 001402          BEQ    16$         :BR IF PARITY NOT ON.
3105 017302 042704 010000          BIC     #BIT12,R4   :CLEAR PARITY ERROR (DON'T WORRY ABOUT PARITY NOW!)
3106 017306          16$:
3107 017306 020504          CMP     R5,R4      :RX DATA AND LINE NUMBER OK??
3108 017310 001401          BEQ    .+4         :BR IF EXPECTED =FOUND.
3109 017312 104002          HLT     2           :RX DATA ERROR
3110 017314 004537 022456          PERFORM ,SILO.OUT :REMOVE RX DATA FROM SILO
3111 017320 104401          SCOPI                :SW09=1?
3112 017322 105205          INCB   R5          :UPDATE DATA
3113 017324 001403          BEQ    9$          :BR IF ALL DATA DONE
3114 017326 133705 001244          BITB   MASKX,R5    :IF <8BITS CHECK END OF DATA.
3115 017332 001720          BEQ    5$          :BR IF MORE TO GO
3116 017334 005237 017030      8$: INC     65$        :UPDATE TO NEXT LINE.
3117 017340 005303          DEC     R2         :ALL 4 LINES DONE?
3118 017342 001226          BNE     1$         :BR IF NOT ALL DONE
3119 017344 000207          RTS     PC         :SCOPE THIS TEST
  
```

```

***** TEST 22 *****
: *TEST OF RECEIVER DATA.
: *THIS TEST RUNS A SET PATTERN THROUGH
: *THE RECEIVER OF EACH LINE
: *THROUGH THE USE OF THE TRANSMITTER.
: *THIS TEST EXERCISES ALL LINES IN GROUPS OF 4.
: *NOTE: SHOULD A DATA COMPARE ERROR OCCUR, THE PROGRAM
: *      REPORTS THE ERROR AS A RECEIVER DATA ERROR BASED
: *      ON THE TRANSMITTER HAS PREVIOUSLY BEEN CHECKED AND ASSUMED GOOD.
: *THIS TEST WILL BE DONE FOR SYNC LINE CARDS ONLY.
: *****
  
```

```

: TEST 22
:-----
TST22: MOV     #22,TSTNO
  
```

```

3136 017346 012737 000022 001226
  
```

K05

DZDV8 MACY11 27(732) 17-SEP-76 11:14 PAGE 64
 DZDV8B.F11 DV11 DEVICE DIAGNOSTICS. COPYRIGHT 1975 DIGITAL EQUIP. CORP.

3137	017354	012737	020336	001216	MOV	#TST23,NEXT	
3138	017362	012700	000000		MOV	#0.,RO	; PLACE LINE NUMBER INTO RO
3139	017366	113737	001412	001242	MOV	CLK.A,CLKX	; PLACE "SHIFTS/PER/CHAR" IN CLKX
3140	017374	113737	001406	001244	MOV	MASK.A,MASKX	; PLACE "MASK" FOR CHARS INTO MASKX
3141	017402	013737	001416	001236	MOV	LO0.03,STAT	; LOAD LINE CARD STATUS INTO STAT
3142	017410	100402			BMI	100\$; BR IF LINE CARD NOT TO BE TESTED
3143	017412	004737	017544		JSR	PC,105\$; GO DO THE TEST FOR LINE CARD 1
3144	017416	012700	000004		MOV	#4.,RO	; PLACE LINE NUMBER INTO RO
3145	017422	113737	001413	001242	MOV	CLK.B,CLKX	; PLACE "SHIFTS/PER/CHAR" IN CLKX
3146	017430	113737	001407	001244	MOV	MASK.B,MASKX	; GET MASK
3147	017436	013737	001420	001236	MOV	LO4.07,STAT	; LOAD LINE CARD STATUS INTO STAT
3148	017444	100402			BMI	101\$; BR IF LINE CARD NOT TO BE TESTED
3149	017446	004737	017544		JSR	PC,105\$; GO DO THE TEST FOR LINE CARD 2
3150	017452	012700	000010		MOV	#8.,RO	; LOAD LINE NUMBER
3151	017456	113737	001414	001242	MOV	CLK.C,CLKX	; GET SHIFTS PER CHAR
3152	017464	113737	001410	001244	MOV	MASK.C,MASKX	; GET MASK
3153	017472	013737	001422	001236	MOV	LO8.11,STAT	; LOAD LINE CARD STATUS INTO STAT
3154	017500	100402			BMI	102\$; BR IF LINE CARD NOT TO BE TESTED
3155	017502	004737	017544		JSR	PC,105\$; DO THE TEST FOR LINE CARD 3
3156	017506	012700	000014		MOV	#12.,RO	; LOAD LINE NO.
3157	017512	113737	001415	001242	MOV	CLK.D,CLKX	; GET SHIFTS
3158	017520	113737	001411	001244	MOV	MASK.D,MASKX	; GET MASK
3159	017526	013737	001424	001236	MOV	LO2.15,STAT	; LOAD LINE CARD STATUS
3160	017534	100402			BMI	103\$; BR IF LINE CARD NOT TO BE TESTED
3161	017536	004737	017544		JSR	PC,105\$; DO THE TESTS FOR LINE CARD 4
3162	017542	104400			SCOPE		; SCOPE THIS TEST.
3163	017544						; TEST ENTRANCE.
3164	017544	032737	004000	001236	BIT	#ASYNC,STAT	; IS THIS A SYNC LINE CARD?
3165	017552	001401			BEQ	.+4	; BR IF SYNC LINE CARD.
3166	017554	000207			RTS	PC	; EXIT TEST
3167	017556	010037	017654		MOV	RO,65\$; PLACE LINE NO.
3168	017562	005037	001250		CLR	TEMP2	
3169	017566	113704	001244		MOV	MASKX,R4	
3170	017572	005037	001252		CLR	TEMP3	
3171	017576	110437	001252		MOV	R4,TEMP3	
3172	017602	000241			CLC		
3173	017604	006104			ROL	R4	
3174	017606	050437	001252		BIS	R4,TEMP3	
3175	017612	000241			CLC		
3176	017614	006104			ROL	R4	
3177	017616	050437	001252		BIS	R4,TEMP3	
3178	017622	013737	001236	022572	MOV	STAT,SYNC	
3179	017630	113737	001236	022573	MOV	STAT,SYNC+1	
3180	017636	012737	000004	001246	MOV	#4,TEMP1	; SET FOR 4 LINES
3181	017644	104412			MSTCLR		; RESET DV11
3182	017646	005001			CLR	R1	; ZERO MSCANNER POINTER
3183	017650	004537	022470		PERFORM	,SETSCAN	; ADJUST SCANNER FOR PROPER LINE
3184	017654	000001			.BLKW 1		
3185	017656						
3186							; SET SOURCE SELECT
3187	017656	010077	161510		MOV	RO,ADVSR5	; LOAD LINE NUMBER
3188	017662	004537	022560		PERFORM	,CLR.TMARK	; CLEAR TMARK BIT.
3189	017666	004537	022266		PERFORM	,LOAD.MODE	; LOAD
3190	017672	024000			BIT13+BIT11		; MODE AND RX ENABLE
3191	017674	032737	010000	001236	BIT	#TWO5YN,STAT	
3192	017702	001003			BNE	9\$	

L05

DZDV8 MACY11 27(732) 17-SEP-75 11:14 PAGE 65
 DZDV8B.P11 DV11 DEVICE DIAGNOSTICS. COPYRIGHT 1975 DIGITAL EQUIP. CORP.

3193	017704	012703	022572		MOV	#SYNC,R3	
3194	017710	000402			BR	10\$	
3195	017712	012703	022573	9\$:	MOV	#SYNC+1,R3	
3196	017716	111337	001250	10\$:	MOVB	(R3),TEMP2	
3197	017722	043737	001252	001250	BIC	TEMP3,TEMP2	
3199	017730	005077	161435		CLR	ADVSR5	;ZERO LINE TO LINE 0
3199	017734	013777	001250	161434	MOV	TEMP2,ADVSR4	;LOAD DATA INTO DVSR4
3200	017742	012777	020000	161430	MOV	#BIT13,ADVSR	;EXECUTE A "ROM READ" INSTP
3201	017750	104415			ROMCLK		;CLOCK.
3202	017752	012777	030260	161420	MOV	#XFR+BIT7+BITS+BIT4,ADVSR	
3203	017760	104415			ROMCLK		;DO A DATA XFER FROM RAM OUTPUT TO TX BUFFER
3204	017762	104416			DATACLK		;ISSUE A MAINT CLK.
3205	017764	012737	017776	001220	MOV	#4\$,LOCK	;SET IF SW09=1 GOTO 4\$
3206	017772	010005			MOV	R0,R5	
3207	017774	000305			SWAB	R5	
3208	017776	113702	001242	4\$:	MOVB	CLKX,R2	;SET REQUIRED SHIFTS
3209	020002	010077	161364		MOV	R0,ADVSR5	;LOAD LINE NUMBER
3210	020006	111337	001250		MOVB	(R3),TEMP2	
3211	020012	043737	001252	001250	BIC	TEMP3,TEMP2	
3212	020020	105005			CLRB	R5	
3213	020022	053705	001250		BIS	TEMP2,R5	
3214	020026	104416		5\$:	DATACLK		;ISSUE MAINT CLK
3215	020030	005302			DEC	R2	;ALL SHIFTS DONE?
3216	020032	022702	000001		CMP	#1,R2	;IS THE BUFFER ALMOST EMPTY?
3217	020036	001033			BNE	8\$;BR IF NO
3218	020040	005077	161326		CLR	ADVSR5	;ZERO LINE NUMBER
3219	020044	032777	001000	161130	BIT	#BIT9,JSWR	;LOCK ON DATA?
3220	020052	001001			BNE	.+4	;BR IF YES!!
3221	020054	005203			INC	R3	;UPDATE DATA POINTER.
3222	020056	111337	001250		MOVB	(R3),TEMP2	;STORE DATA
3223	020062	013777	001250	161306	MOV	TEMP2,ADVSR4	;LOAD DATA INTO DVSR4
3224	020070	012777	020000	161302	MOV	#BIT13,ADVSR	;DO A ROM READ
3225	020076	104415			ROMCLK		;CLK
3226	020100	012777	030260	161272	MOV	#XFR+BIT7+BITS+BIT4,ADVSR	
3227	020106	104415			ROMCLK		;DO A DATA XFER TO TX BUFF
3228	020110	010077	161256		MOV	R0,ADVSR5	;RESELECT LINE NUMBER
3229	020114	032777	001000	161060	BIT	#BIT9,JSWR	;LOCK ON DATA?
3230	020122	001001			BNE	.+4	;BR IF YES!!
3231	020124	005303			DEC	R3	;READJUST DATA CHAR POINTER.
3232	020126	005702		8\$:	TST	R2	;ALL SHIFTS DONE?
3233	020130	001336			BNE	5\$;BR IF NO
3234	020132	022703	022572		CMP	#SYNC,R3	
3235	020136	001465			BEQ	50\$	
3236	020140	022703	022573		CMP	#SYNC+1,R3	
3237	020144	001462			BEQ	50\$	
3238	020146	012777	050023	161224	MOV	#S.C+BIT4+BIT1+BIT0,ADVSR	
3239	020154	104415			ROMCLK		;SET RX DATA ENABLE
3240	020156	004537	022434		PERFORM	,SILO.IN	;READ FROM RX BUFFER INTO SILO
3241	020162	005002			CLR	R2	;SET DELAY
3242	020164	012777	001400	161206	MOV	#BIT9+BIT8,ADVSR	
3243	020172	032777	000001	161170	BIT	#BIT0,ADVLCR	;WAIT FOR RX CHAR WAITING
3244	020200	001403			BEQ	27\$;BR IF TRUE
3245	020202	005202			INC	R2	;UPDATE DELAY
3246	020204	001372			BNE	26\$;GOBACK
3247	020206	104000			HLT	0	;RX CHAR WAITING NOT TRUE
3248	020210	012702	030306	27\$:	MOV	#XFR+BIT7+BIT6+BIT2+BIT1,R2	

M05

```

3249 020214 010277 161160      MOV      R2,ADVSRF      ;DO DATA XFER FROM SILO TO DVRIC
3250 020220 104415      ROMCLK      ;CLOCK
3251 020222 017704 161140      MOV      ADVRIC,R4      ;LOAD DVRIC TO "FOUND" LOC.
3252 020226 032737 040000 001236  BIT      #PARBIT,STAT  ;PARITY ON??
3253 020234 001402      BEQ      36$           ;BR IF PARITY NOT ON.
3254 020236 042704 010000      BIC      #BIT12,R4      ;CLEAR PARITY ERROR (DON'T WORRY ABOUT PARITY NOW!)
3255 020242 020504      36$:  CMP      R5,R4          ;RX DATA AND LINE NUMBER OK??
3256 020244 001401      BEQ      .+4           ;BR IF EXPECTED =FOUND.
3257 020246 104002      HLT      2             ;RX DATA ERROR
3259 020250 004537 022456  PERFORM  ,SILO.OUT      ;REMOVE RX DATA FROM SILO
3259 020254 104401      SCOP1      ;LOCK ON DATA?
3260 020256 005203      11$:  INC      R3
3261 020260 020327 022620  CMP      R3,#ENDPAT
3262 020264 001244      BNE      4$
3263 020266 004537 022546  6$:  PERFORM  ,SET.TMARK  ;SET TMARK BIT.
3264 020272 005237 017654  INC      65$           ;UPDATE LINE NO.
3265 020276 005337 001246  DEC      TEMP1         ;ALL LINES(4) DONE?
3266 020302 001402      BEQ      46$
3267 020304 000137 017644  JMP      1$
3268 020310 000207      46$:  RTS      PC           ;SCOPE THESE 4 LINES!
3269 020312 012777 050023 161060  50$:  MOV      #S.C+BIT4+BIT1+BIT0,ADVSRF
3270 020320 104415      ROMCLK
3271 020322 012777 050022 161050  MOV      #S.C+BIT4+BIT1,ADVSRF
3272 020330 104415      ROMCLK
3273 020332 000137 020256  JMP      11$
  
```

```

;***** TEST 23 *****
; *TEST OF RECEIVER "RE-SYNC"
; *THIS TEST WILL SEND (BY BIT WINDOW) TWO SYNC CHARS AND
; *THEN VERIFY THAT RX CHAR FLAG IS TRUE.
; *THEN A "RE-SYNC" WILL BE ISSUED AND
; *TWO NON-SYNC CHARS WILL BE SENT INTO THE RX
; *VERIFYING THAT THERE IS NO RX CHAR FLAG.
; *NEXT TWO SYNC CHARS ARE AGAIN MOVED INTO THE RX
; *VERIFYING CHAR FLAG AND THE THE RX SOULD INDEED
; * RE SYNC!
; *THIS TEST WILL BE DONE FOR SYNC LINE CARDS ONLY.
;*****
  
```

; TEST 23

```

3291 020336 012737 000023 001226  TST23: MOV      #23,TSTNO
3292 020344 012737 021042 001216  MOV      #TST24,NEXT
3293 020352 012700 000000      MOV      #0.,RO        ;PLACE LINE NUMBER INTO RO
3294 020356 113737 001412 001242  MOVVB   CLK.A,CLKX     ;PLACE "SHIFTS/PER/CHAR" IN CLKX
3295 020364 013737 001416 001236  MOV      LOO.O,STAT     ;LOAD LINE CARD STATUS INTO STAT
3296 020372 100402      BMI     100$          ;BR IF LINE CARD NOT TO BE TESTED
3297 020374 004737 020504      JSR    PC,105$        ;GO DO THE TEST FOR LINE CARD 1
3298 020400 012700 000004      100$: MOV      #4.,RO        ;PLACE LINE NUMBER INTO RO
3299 020404 113737 001413 001242  MOVVB   CLK.B,CLKX     ;PLACE "SHIFTS/PER/CHAR" IN CLKX
3300 020412 013737 001420 001236  MOV      LO4.O7,STAT    ;LOAD LINE CARD STATUS INTO STAT
3301 020420 100402      BMI     101$          ;BR IF LINE CARD NOT TO BE TESTED
3302 020422 004737 020504      JSR    PC,105$        ;GO DO THE TEST FOR LINE CARD 2
3303 020426 012700 000010      101$: MOV      #8.,RO        ;LOAD LINE NUMBER
3304 020432 113737 001414 001242  MOVVB   CLK.C,CLKX     ;GET SHIFTS PER CHAR
  
```

N05

DZDVB MACY11 27(732) 17-SEP-75 11:14 PAGE 67
 DZDVBB.P11 DV11 DEVICE DIAGNOSTICS. COPYRIGHT 1975 DIGITAL EQUIP. CORP.

3305	020440	013737	001422	001236		MOV	L08.11, STAT	; LOAD LINE CARD STATUS INTO STAT
3306	020446	100402				BMI	102\$; BR IF LINE CARD NOT TO BE TESTED
3307	020450	004737	020504			JSR	PC, 105\$; DO THE TEST FOR LINE CARD 3
3308	020454	012700	000014		102\$:	MOV	#12., R0	; LOAD LINE NO.
3309	020460	113737	001415	001242		MOV	CLK.D, CLKX	; GET SHIFTS
3310	020466	013737	001424	001236		MOV	L12.15, STAT	; LOAD LINE CARD STATUS
3311	020474	100402				BMI	103\$; BR IF LINE CARD NOT TO BE TESTED
3312	020476	004737	020504			JSR	PC, 105\$; DO THE TESTS FOR LINE CARD 4
3313	020502	104400			103\$:	SCOPE		; SCOPE THIS TEST.
3314	020504				105\$:			; TEST ENTRANCE.
3315	020504	032737	004000	001236		BIT	#ASYNC, STAT	; IS THIS A SYNC LINE CARD?
3316	020512	001401				BEQ	+4	; BR IF SYNC LINE CARD.
3317	020514	000207				RTS	PC	; EXIT TEST
3318	020516	012703	000004			MOV	#4, R3	; SET FOR 4 LINE GROUP
3319	020522	010037	020536			MOV	R0, 68\$; SAVE LINE NO
3320	020526	104412			1\$:	MSTCLR		; RESET
3321	020530	005001				CLR	R1	; ZERO MSCANNER POINTER
3322	020532	004537	022470			PERFORM	, SETSCAN	; SET SCANNER
3323	020536	000001			68\$:	.BLKW 1		; TO RIGHT LINE
3324	020540	012737	020546	001220		MOV	#3\$, LOCK	; SET IF SW09=1
3325	020546	010077	160620		3\$:	MOV	R0, ADVSR5	; LOAD LINE
3326	020552	004537	022266			PERFORM	, LOAD.MODE	; LOAD
3327	020556	025000				BIT13+BIT11+BIT9		; MODE
3328	020560	012702	000002			MOV	#2, R2	; SET COUNT
3329	020564	104416				DATACLK		; INIT DV11 SAT/SAR
3330	020566	013737	001236	022622	4\$:	MOV	STAT, DATA	; GET SYNC
3331	020574	004537	022326			PERFORM	, RXSHIFT	; SHIFT INTO RX
3332	020600	001242				CLKX		; CLOCKS
3333	020602	005302				DEC	R2	; TWO CHARS YET
3334	020604	001370				BNE	4\$	
3335	020606	012702	002000			MOV	#BIT10, R2	; BRA TEST
3336	020612	010277	160562			MOV	R2, ADVSFR	
3337	020616	017704	160546			MOV	ADVLCR, R4	
3338	020622	010405				MOV	R4, R5	
3339	020624	042705	000001			BIC	#BIT0, R5	
3340	020630	020504				CMP	R5, R4	; BRANCH TEST POINT BAD
3341	020632	001401				BEQ	64\$	
3342	020634	104001				HLT	1	
3343	020636	012777	050106	160534	64\$:	MOV	#5.C+BIT6+BIT2+BIT1, ADVSFR	
3344	020644	104415				ROMCLK		; S/C "RESYNC PULSE"
3345	020646	010277	160526			MOV	R2, ADVSFR	
3346	020652	017704	160512			MOV	ADVLCR, R4	
3347	020656	010405				MOV	R4, R5	
3348	020660	052705	000001			BIS	#BIT0, R5	
3349	020664	020504				CMP	R5, R4	
3350	020666	001401				BEQ	65\$	
3351	020670	104001				HLT	1	; RESYNC FAILED.
3352	020672	012702	000002		65\$:	MOV	#2, R2	
3353	020676	013737	001236	022622	5\$:	MOV	STAT, DATA	; GET SYNC
3354	020704	005437	022622			NEG	DATA	; MAKE IT A NON-SYNC
3355	020710	004537	022326			PERFORM	, RXSHIFT	; SHIFT
3356	020714	001242				CLKX		; INTO RX
3357	020716	005302				DEC	R2	; TWO DONE?
3358	020720	001366				BNE	5\$	
3359	020722	012702	002000			MOV	#BIT10, R2	
3360	020726	010277	160446			MOV	R2, ADVSFR	

```

021000 021000 000000 160432 MOV 20VLCR,R4
021001 021001 000001 000001 MOV R4,R5
021002 021002 000002 000002 BIS #BITC,R5
021003 021003 000003 000003 CMP R5,R4
021004 021004 000004 000004 BEQ 66$
021005 021005 000005 000005 HLT 1
021006 021006 000006 000006 MOV #2,R2
021007 021007 000007 001236 MOV STAT,DATA
021008 021008 000008 022326 PERFORM ,RXSHIFT
021009 021009 000009 000009 CLKX
021010 021010 000010 000010 DEC R2
021011 021011 000011 000011 BNE 65$
021012 021012 000012 002000 MOV #BITIC,R2
021013 021013 000013 160372 MOV R2,20V5FR
021014 021014 000014 160356 MOV 20VLCR,R4
021015 021015 000015 000001 MOV R4,R5
021016 021016 000016 000001 BIC #BITD,R5
021017 021017 000017 000001 CMP R5,R4
021018 021018 000018 000001 BEQ 67$
021019 021019 000019 000001 HLT 1
021020 021020 000020 020536 SCOP1
021021 021021 000021 000001 INC 68$
021022 021022 000022 000001 DEC R2
021023 021023 000023 000001 BNE 1$
021024 021024 000024 000001 RTS PC
EXIT

```

```

***** TEST 24 *****
*TEST TO VERIFY THAT SETTING RECEIVER ENABLE
*WILL SET RX FLAG AND MATCH DETECT.
*TEST WILL ALSO VERIFY THAT CLEARING RECEIVER
*ENABLE WILL CLEAR RX FLAG AND MATCH DETECT.
*THIS TEST WILL BE DONE FOR ASYNC LINE CARDS ONLY.

```

```
*****
```

```
: TEST 24
```

```

021024 012737 000024 001226 TST24: MOV #24,TSTNO
021025 012737 000025 001216 MOV #TST25,NEXT
021026 012700 000030 000000 MOV #0.,R0 ;PLACE LINE NUMBER INTO R0
021027 013737 001416 001236 MOV L00.03,STAT ;LOAD LINE CARD STATUS INTO STAT
021028 100402 ;BR IF LINE CARD NOT TO BE TESTED
021029 004737 021160 JSR PC,100$ ;GO DO THE TEST FOR LINE CARD 1
021030 012700 000004 100$: MOV #4.,R0 ;PLACE LINE NUMBER INTO R0
021031 013737 001420 001236 MOV L04.07,STAT ;LOAD LINE CARD STATUS INTO STAT
021032 100402 ;BR IF LINE CARD NOT TO BE TESTED
021033 004737 021160 JSR PC,101$ ;GO DO THE TEST FOR LINE CARD 2
021034 012700 000010 101$: MOV #8.,R0 ;LOAD LINE NUMBER
021035 013737 001422 001236 MOV L08.11,STAT ;LOAD LINE CARD STATUS INTO STAT
021036 100402 ;BR IF LINE CARD NOT TO BE TESTED
021037 004737 021160 JSR PC,102$ ;DO THE TEST FOR LINE CARD 3
021038 012700 000014 102$: MOV #12.,R0 ;LOAD LINE NO.
021039 013737 001424 001236 MOV L12.15,STAT ;LOAD LINE CARD STATUS
021040 100402 ;BR IF LINE CARD NOT TO BE TESTED
021041 004737 021160 JSR PC,103$ ;DO THE TESTS FOR LINE CARD 4

```

021156	104400		103\$:	SCOPE	:SCOPE THIS TEST.
021160			105\$:		:TEST ENTRANCE.
021160	032737	004000		BIT #ASYNC,STAT	:IS THIS AN ASYNC LINE CAR?
021166	001001	001236		BNE +4	:BR IF ASYNC.
021170	009307			RTS PC	:EXIT TEST
021172	012703	000004		MOV #4,R3	:SET TO TEST 4 LINES.
021176	104412		1\$:	MSTCLR	:INIT DV11
021200	005001			CLR R1	:INIT SCANNER POINTER.
021202	012777	000010	160152	MOV #BIT3,JDVSCR	:SET SOURCE ENABLE
021210	010037	021220		MOV R0,65\$:PREPARE MASTER SCANNER.
021214	004537	022470		PERFORM SETSCAN	:SET SCANNER
021220	000001		65\$:	.BLKW 1	:POSITION OF SCANNER.
021222	010077	160144		MOV R0,JDVSR5	:LOAD LINE NO.
021226	004537	022266		PERFORM .LOAD.MODE	:SET RX ENABLE.
021232	020000			BIT!3	
021234	012702	076400		MOV #BRB+BIT11+BIT10	:BIT8,R2
021240	010277	160134		MOV R2,JDVSFR	:BRB MATCH DETECT.
021244	017704	160120		MOV JDVLCR,R4	:READ BR POINTS.
021250	010405			MOV R4,R5	
021252	052705	000001		BIS #BITC,R5	:BR A FALSE.
021256	042705	000002		BIC #BIT1,R5	:BR B TRUE.
021262	020504			CMP R5,R4	:MATCH DETECT TRUE?
021264	001401			BEQ 2\$:BR IF YES
021266	104001			HLT 1	:RX FLAG NOT TRUE.
021270	012702	002000	2\$:	MOV #BIT10,R2	:BRA RX FLAG.
021274	010277	160100		MOV R2,JDVSFR	:LOAD INSTRUCTION.
021300	017704	160064		MOV JDVLCR,R4	:READ BR POINTS.
021304	010405			MOV R4,R5	
021306	052705	000002		BIS #BIT1,R5	:BR B FALSE
021312	042705	000001		BIC #BIT0,R5	:BR A TRUE.
021316	020504			CMP R5,R4	:RX FLAG TRUE?
021320	001401			BEQ 3\$:BR IF YES
021322	104001			HLT 1	:RX FLAG NOT TRUE.
021324	004537	022266	3\$:	PERFORM .LOAD.MODE	:CLEAR RX ENABLE.
021330	000000			0	
021332	012702	076400		MOV #BRB+BIT11+BIT10	:BIT9,R2
021336	010277	160036		MOV R2,JDVSFR	:BRB MATCH DETECT.
021342	017704	160022		MOV JDVLCR,R4	:READ BR POINTS.
021346	010405			MOV R4,R5	
021350	052705	000001		BIS #BIT0,R5	:BR A FALSE.
021354	052705	000002		BIS #BIT1,R5	:BR B FALSE.
021360	020504			CMP R5,R4	:MATCH DETECT FALSE?
021362	001401			BEQ 4\$:BR IF YES
021364	104001			HLT 1	:RX FLAG NOT FALSE.
021366	012702	002000	4\$:	MOV #BIT10,R2	:BRA RX FLAG.
021372	010277	160002		MOV R2,JDVSFR	:LOAD INSTRUCTION.
021376	017704	157766		MOV JDVLCR,R4	:READ BR POINTS.
021402	010405			MOV R4,R5	
021404	052705	000002		BIS #BIT1,R5	:BR B FALSE
021410	052705	000001		BIS #BIT0,R5	:BR A FALSE.
021414	020504			CMP R5,R4	:RX FLAG FALSE?
021416	001401			BEQ 5\$:BR IF YES
021420	104001			HLT 1	:RX FLAG NOT FALSE.
021422	005200		5\$:	INC R0	:UPDATE LINE NO.
021424	005303			DEC R3	:4 LINES DONE?
021426	001262			BNE 1\$:BR IF NO.

021430 000207 RIS PC :EXIT TEST.

***** TEST 25 *****
*TEST TO SET RECEIVER ENABLE.
*SET "RX DATA ENABLE".
*CLR "RX DATA ENABLE".
*AND EXPECT BOTH RX FLAG AND MATCH DETECT TO BE FALSE.
*THIS TEST WILL BE DONE FOR ASYNC LINE CARDS ONLY.

: TEST 25

021433	012737	000025	001226	TST25:	MOV	#25,TSTNO	
021440	012737	021744	001216		MOV	#TST26,NEXT	
021446	012700	000000			MOV	#0,R0	:PLACE LINE NUMBER INTO R0
021450	013737	001416	001236		MOV	L00.03,STAT	:LOAD LINE CARD STATUS INTO STAT
021456	100402				BMI	100\$:BR IF LINE CARD NOT TO BE TESTED
021462	004737	021550			JSR	PC,105\$:GO DO THE TEST FOR LINE CARD 1
021466	012700	000004		100\$:	MOV	#4,R0	:PLACE LINE NUMBER INTO R0
021472	013737	001420	001236		MOV	L04.07,STAT	:LOAD LINE CARD STATUS INTO STAT
021500	100402				BMI	101\$:BR IF LINE CARD NOT TO BE TESTED
021506	004737	021550			JSR	PC,105\$:GO DO THE TEST FOR LINE CARD 2
021506	012700	000010		101\$:	MOV	#8,R0	:LOAD LINE NUMBER
021512	013737	001422	001236		MOV	L08.11,STAT	:LOAD LINE CARD STATUS INTO STAT
021520	100402				BMI	102\$:BR IF LINE CARD NOT TO BE TESTED
021522	004737	021550			JSR	PC,105\$:DO THE TEST FOR LINE CARD 3
021526	012700	000014		102\$:	MOV	#12,R0	:LOAD LINE NO.
021532	013737	001424	001236		MOV	L12.15,STAT	:LOAD LINE CARD STATUS
021540	100402				BMI	103\$:BR IF LINE CARD NOT TO BE TESTED
021542	004737	021550			JSR	PC,105\$:DO THE TESTS FOR LINE CARD 4
021546	104400			103\$:	SCOPE		:SCOPE THIS TEST.
021550				105\$:			:TEST ENTRANCE.
021550	032737	004000	001236		BIT	#ASYNC,STAT	:IS THIS AN ASYNC LINE CARD
021556	001001				BNE	.+4	:BR IF ASYNC.
021560	000207				RTS	PC	:EXIT TEST
021562	012700	000004			MOV	#4,R3	:SET TO TEST 4 LINES.
021566	104412			1\$:	MSTCLR		:INIT DV11
021570	005001				CLR	R1	:INIT SCANNER POINTER.
021572	012777	000010	157562		MOV	#BIT3,JDVSCR	:SET SOURCE ENABLE
021576	010037	021610			MOV	R0,65\$:PREPARE MASTER SCANNER.
021604	004537	022470			PERFORM	SETSCAN	:SET SCANNER
021610	000001			65\$:	.BLKW	1	:POSITION OF SCANNER.
021612	010077	157554			MOV	R0,JDVSR5	:LOAD LINE NO.
021616	004537	022266			PERFORM	.LOAD.MODE	:SET RX ENABLE.
021622	020000				BIT13		
021624	012777	050023	157546		MOV	#S.C+BIT4+BIT1+BIT0,JDVSR	
021632	104415				ROMCLK		:SET RX DATA ENABLE.
021634	012777	050022	157536		MOV	#S.C+BIT4+BIT1,JDVSR	
021642	104415				ROMCLK		:CLEAR RX DATA ENABLE.
021644	012702	076400			MOV	#BRB+BIT11+BIT10+BIT8,R2	
021650	010277	157524			MOV	R2,JDVSR	:BRB MATCH DETECT.
021654	017704	157510			MOV	JDVLCR,R4	:READ BR POINTS.
021660	010405				MOV	R4,R5	
021662	052705	000001			BIS	#BIT0,R5	:BR A FALSE.
021666	052705	000002			BIS	#BIT1,R5	:BR B FALSE.

E06

```

021673 020504      CMP      R5,R4      ;MATCH DETECT FALSE?
021674 001401      BEQ      4$         ;BR IF YES
021676 104001      HLT      1         ;RX FLAG NOT FALSE.
021700 012702 002000 4$:      MOV      #BIT10,R2 ;BRA RX FLAG.
021704 010277 157470  MOV      R2,DVVSFR ;LOAD INSTRUCTION.
021710 017704 157454  MOV      DVVLCR,R4 ;READ BR POINTS.
021714 010405      MOV      R4,R5
021716 052705 000002  BIS      #BIT1,R5    ;BR B FALSE
021722 052705 000001  BIS      #BIT0,R5    ;BR A FALSE.
021726 020504      CMP      R5,R4      ;RX FLAG FALSE?
021730 001401      BEQ      5$         ;BR IF YES
021732 104001      HLT      1         ;RX FLAG NOT FALSE.
021734 005200 5$:      INC      R0         ;UPDATE LINE NO.
021736 005303      DEC      R3         ;4 LINES DONE?
021740 001312      BNE     1$         ;BR IF NO.
021742 000207      RTS      PC        ;EXIT TEST.
    
```

***** TEST 26 *****
 : *TEST TO SET RECEIVER ENABLE.
 : *ISSUE A RESYNC SIGNAL.
 : *AND EXPECT BOTH RX FLAG AND MATCH DETECT TO BE FALSE.
 : *THIS TEST WILL BE DONE FOR ASYNC LINE CARDS ONLY.
 : *****

: TEST 26

```

021744 012737 000026 001226 1$ST26:  MOV      #26,TSTNO
021752 012737 002436 001216  MOV      #.EOP,NEXT
021753 012700 000000  MOV      #0.,R0      ;PLACE LINE NUMBER INTO R0
021764 013737 001416 001236  MOV      LOC.03,STAT ;LOAD LINE CARD STATUS INTO STAT
021772 100402      BMI     100$       ;BR IF LINE CARD NOT TO BE TESTED
021774 004737 022062  JSR      PC,105$    ;GO DO THE TEST FOR LINE CARD 1
022000 012700 000004 100$:  MOV      #4.,R0      ;PLACE LINE NUMBER INTO R0
022004 013737 001420 001236  MOV      LOC.07,STAT ;LOAD LINE CARD STATUS INTO STAT
022012 100402      BMI     101$       ;BR IF LINE CARD NOT TO BE TESTED
022014 004737 022062  JSR      PC,105$    ;GO DO THE TEST FOR LINE CARD 2
022020 012700 000010 101$:  MOV      #8.,R0      ;LOAD LINE NUMBER
022024 013737 001422 001236  MOV      LOC.11,STAT ;LOAD LINE CARD STATUS INTO STAT
022032 100402      BMI     102$       ;BR IF LINE CARD NOT TO BE TESTED
022034 004737 022062  JSR      PC,105$    ;DO THE TEST FOR LINE CARD 3
022040 012700 000014 102$:  MOV      #12.,R0     ;LOAD LINE NO.
022044 013737 001424 001236  MOV      L12.15,STAT ;LOAD LINE CARD STATUS
022052 100402      BMI     103$       ;BR IF LINE CARD NOT TO BE TESTED
022054 004737 022062  JSR      PC,105$    ;DO THE TESTS FOR LINE CARD 4
022060 104400 103$:  SCOPE
022062 105$:  TEST ENTRANCE.
022062 032737 004000 001236  BIT      #ASYNC,STAT ;IS THIS AN ASYNC LINE CARD?
022070 001001      BNE     .+4         ;BR IF ASYNC.
022072 000207      RTS      PC        ;EXIT TEST
022074 012703 000004  MOV      #4.,R3     ;SET TO TEST 4 LINES.
022100 104412 1$:  MSTCLR
022102 005001      CLR      R1         ;INIT DV11
022104 012777 000010 157250  MOV      #BIT3,DVVSFR ;INIT SCANNER POINTER.
022112 010037 022122  MOV      R0,65$     ;SET SOURCE ENABLE
022116 004537 022470  PERFORM ,SETSCAN   ;PREPARE MASTER SCANNER.
                                ;SET SCANNER
    
```

F06

```

3595 022122 000001          55: .BLKW 1 ;POSITION OF SCANNER.
3596 022124 010077 157242 MOV R0,ADVSR5 ;LOAD LINE NO.
3597 022130 004537 022266 PERFORM .LOAD.MODE ;SET RX ENABLE.
3598 022134 020000 BIT13
3599 022136 012777 050106 157234 MOV #S.C+BIT6+BIT2+BIT1,ADVSR ;
3600 022144 104415 ROMCLK ;ISSUE RESYNC.
3601 022146 012702 076400 MOV #BRB+BIT11+BIT10+BIT8,R2
3602 022152 010277 157222 MOV R2,ADVSR ;BRB MATCH DETECT.
3603 022156 017704 157206 MOV ADVLCR,R4 ;READ BR POINTS.
3604 022162 010405 MOV R4,R5
3605 022164 052705 000001 BIS #BIT0,R5 ;BR A FALSE.
3606 022170 052705 000002 BIS #BIT1,R5 ;BR B FALSE.
3607 022174 020504 CMP R5,R4 ;MATCH DETECT FALSE?
3608 022176 001401 BEQ 4$ ;BR IF YES
3609 022200 104001 HLT 1 ;RX FLAG NOT FALSE.
3610 022202 012702 002000 4$: MOV #BIT10,R2 ;BRA RX FLAG.
3611 022206 010277 157166 MOV R2,ADVSR ;LOAD INSTRUCTION.
3612 022212 017704 157152 MOV ADVLCR,R4 ;READ BR POINTS.
3613 022216 010405 MOV R4,R5
3614 022220 052705 000002 BIS #BIT1,R5 ;BR B FALSE
3615 022224 052705 000001 BIS #BIT0,R5 ;BR A FALSE.
3616 022230 020504 CMP R5,R4 ;RX FLAG FALSE?
3617 022232 001401 BEQ 5$ ;BR IF YES
3618 022234 104001 HLT 1 ;RX FLAG NOT FALSE.
3619 022236 005200 5$: INC R0 ;UPDATE LINE NO.
3620 022240 005303 DEC R3 ;4 LINES DONE?
3621 022242 001316 BNE 1$ ;BR IF NO.
3622 022244 000207 RTS PC ;EXIT TEST.

TXSHIFT:
3623 022246 010046 MOV R0,-(SP)
3624 022246 010046 MOV ADVLCR,R0
3625 022250 017700 157114 MOV R0
3626 022254 106100 ROLB R0
3627 022256 106037 022622 RORB DATA
3628 022262 012600 MOV (SP)+,R0
3629 022264 000205 EXIT

LOAD.MODE:
3630 022266 012577 157076 MOV (R5)+,ADVLCR
3631 022272 052777 100000 157070 BIS #BIT15,ADVLCR
3632 022300 010046 MOV R0,-(SP)
3633 022302 005000 CLR R0
3634 022304 005777 157050 1$: TST ADVLCR
3635 022310 100004 BPL 2$
3636 022312 104414 DELAY
3637 022314 005200 INC R0
3638 022316 001372 BNE 1$
3639 022320 104000 HLT 0 ;BIT 15 FAILED TO CLEAR
3640 022322 012600 2$: MOV (SP)+,R0
3641 022324 000205 EXIT

RXSHIFT:
3642 022326 010046 MOV R0,-(SP)
3643 022330 010246 MOV R2,-(SP)
3644 022332 113502 MOVB 2(R5)+,R2
3645 022334 042777 040000 157026 1$: BIC #BIT14,ADVLCR
3646 022342 005000 CLR R0
3647 022344 000241 CLC
  
```

3641	022346	006037	022522		ROR	DATA
3642	022352	006000			ROR	RO
3643	022354	006000			ROR	RO
3644	022356	052700	100000		BIS	#BIT15,RO
3645	022362	050077	157002		BIS	RO,ADVLCR
3646	022366	004737	022405		JSR	PC,CKBIT15
3647	022372	104416			DATACLK	
3648	022374	105302			DECB	R2
3649	022376	001356			BNE	1\$
3650	022400	012502			MOV	(SP)+,R2
3651	022402	012500			MOV	(SP)+,RO
3652	022404	000205			EXIT	
3653						
3654	022406				CKBIT15:	
3655	022406	010046			MOV	RO,-(SP)
3656	022410	005000			CLR	RO
3657	022412	005777	156752		64\$: TST	ADVLCR
3658	022416	100004			BPL	65\$
3659	022420	104414			DELAY	
3660	022422	005200			INC	RO
3661	022424	001372			BNE	64\$
3662	022426	104000			HLT	0
3663	022430	012500			65\$: MOV	(SP)+,RO
3664	022432	000207			RTS	PC
3665	022434				SILO.IN:	
3666	022434	012777	050021	156736	MOV	#BIT14+BIT12+BIT4+BIT0,ADVSR
3667	022442	104415			ROMCLK	
3668	022444	012777	050022	156726	MOV	#BIT14+BIT12+BIT4+BIT1,ADVSR
3669	022452	104415			ROMCLK	
3670	022454	000205			EXIT	
3671						
3672	022456				SILO.OUT:	
3673	022456	012777	050020	156714	MOV	#BIT14+BIT12+BIT4,ADVSR
3674	022464	104415			ROMCLK	
3675	022466	000205			EXIT	
3676						
3677						
3678	022470				SETSCAN:	
3679	022470	010346			MOV	R3,-(SP)
3680	022472	052777	000010	156662	BIS	#BIT3,ADVSCR
3681	022500	012503			MOV	(R5)+,R3
3682	022502	001414			BEG	2\$
3683	022504	012777	050102	156666	1\$: MOV	#BIT14+BIT12+BIT6+BIT1,ADVSR
3684	022512	104415			ROMCLK	
3685	022514	005201			INC	R1
3686	022516	012777	050102	156654	MOV	#BIT14+BIT12+BIT6+BIT1,ADVSR
3687	022524	104415			ROMCLK	
3688	022526	005201			INC	R1
3689	022530	005303			DEC	R3
3690	022532	001364			BNE	1\$
3691	022534	012503			2\$: MOV	(SP)+,R3
3692	022536	010100			MOV	R1,RO
3693	022540	000241			CLC	
3694	022542	006000			ROR	RO
3695	022544	000205			EXIT	
3696	022546				SET.TMARK:	

H06

```
3697 022546 012777 050105 156624      MOV      #BIT14+BIT12+BIT6+BIT2+BIT0,DVSFR
3698 022554 104415      ROMCLK  ;SET/CLEAR "SET TMARK"
3699 022556 000205      EXIT
3700 022560      CLR.TMARK:
3701 022560 012777 050101 156612      MOV      #BIT14+BIT12+BIT6+BIT0,DVSFR
3702 022566 104415      ROMCLK  ;SET/CLEAR "CLEAR TMARK"
3703 022570 000205      EXIT
3704
3705 022572 000001      SYNC:   .BLKW 1
3706 022574      000      DATPAT: .BYTE  ↑B<00000000>      :ALL ZERO'S
3707 022575      377      .BYTE  ↑B<11111111>      :ALL ONE'S
3708 022576      125      .BYTE  ↑B<01010101>      :ALTERNATE ONE'S
3709 022577      252      .BYTE  ↑B<10101010>      :ALTERNATE ZERO'S
3710 022600      001      .BYTE  ↑B<00000001>      :F
3711 022601      002      .BYTE  ↑B<00000010>      :L
3712 022602      004      .BYTE  ↑B<00000100>      :O
3713 022603      010      .BYTE  ↑B<00001000>      :A
3714 022604      020      .BYTE  ↑B<00010000>      :T
3715 022605      040      .BYTE  ↑B<00100000>      :I
3716 022606      100      .BYTE  ↑B<01000000>      :N
3717 022607      200      .BYTE  ↑B<10000000>      :G
3718 022610      177      .BYTE  ↑B<01111111>      :O
3719 022611      277      .BYTE  ↑B<10111111>      :N
3720 022612      327      .BYTE  ↑B<11011111>      :I
3721 022613      357      .BYTE  ↑B<11101111>      :N
3722 022614      367      .BYTE  ↑B<11110111>      :G
3723 022615      373      .BYTE  ↑B<11111011>      :O
3724 022616      375      .BYTE  ↑B<11111101>      :N
3725 022617      376      .BYTE  ↑B<11111110>      :G
3726 022620      .EVEN
3727 022620 000000      SKIP=000000
3728 022622 000000      DT6:   5
3729 022624 046377 047111 020105      EM1:   .ASCIZ <377>/LINE CARD STATIC TEST/
          377 042522 042503      EM2:   .ASCIZ <377>/RECEIVER DATA COMAPRISON ERROR/
          377 051124 047101      EM3:   .ASCIZ <377>/TRANSMITTER DATA COMPARISON ERROR/
          046777 052123 041523      DH1:   .ASCIZ <377>/MSTSCAN DVSFR EXPECTED FOUND LINE(8)
          .EVEN
3730 023030 000000
3731 023032 000005      SAVR1  6,3
3732 023034 001262      SAVR1  6,1
3733 023036 000005      SAVR2  6,1
3734 023040 001264      SAVR2  6,4
3735 023042 000005      SAVR5  6,1
3736 023044 001272      SAVR5  2,1
3737 023046 000005      SAVR4  6,1
3738 023050 001270      SAVR4  6,1
3739 023052 000002      SAVR0  2,1
3740 023054 001260      SAVR0
3741
3742 023056      .ERRTAB:
3743 023056 000000      0
3744 023060 000000      0
3745 023062 000000      0
3746 023064 022624      EM1
3747 023066 022756      DH1   :HALT 1
```

023070	023030
023072	022753
023074	022756
023076	023030
023100	022713
023102	022756
023104	023030
023106	

DI6	
EM2	
DH1	:HALT 2
DT6	
EM3	
DH1	:HALT 3
DT6	

CORMAX:
.END

00001

J06

DZDVB MACY11 27(732) 17-SEP-76 11:14 PAGE 77
 DZDVB.P11 CROSS REFERENCE TABLE -- USER SYMBOLS

ADRCNT= 003443	1143*	1179*	1188*											
ALU = 010000	599#													
ASync = 004000	607#	1891	1933	1985	2039	2091	2167	2302	2408	2575	2655	2726	2831	
	2931	3049	3164	3315	3419	3506	3576							
AUTO.S 006E22	1653#													
BCC = 060000	604#													
BINWRD 003746	1229*	1230	1267*											
BIT0 = 000001	597#	1410	1773	1838	2186	2197	2513	2517	2534	2588	2590	2594	2611	
	2674	2746	2756	2767	2776	2851	2861	2872	2881	2955	2957	2960	2982	
	2985	3074	3079	3089	3094	3238	3243	3269	3339	3348	3363	3377	3436	
	3446	3456	3466	3519	3527	3537	3595	3605	3666	3697	3701			
BIT1 = 000002	596#	1410	1421	1773	1780	1789	1793	1838	2177	2312	2418	2522	2588	
	2599	2675	2747	2756	2768	2775	2852	2861	2873	2880	2955	2962	2992	
	3074	3089	3099	3238	3248	3269	3271	3343	3437	3445	3457	3455	3519	
	3521	3528	3536	3589	3596	3604	3668	3683	3686					
BIT10 = 002000	587#	1410	1774	1839	2424	2671	2742	2751	2763	2772	2842	2847	2856	
	2868	2877	3335	3359	3373	3432	3441	3452	3461	3523	3532	3591	3600	
BIT11 = 004000	586#	1410	1839	1938	1990	2044	2099	2182	2318	2424	2666	2571	2737	
	2742	2763	2842	2847	2868	2941	3059	3190	3327	3432	3452	3523	3531	
BIT12 = 010000	585#	599	601	603	605	2998	3105	3254	3666	3668	3673	3693	3695	
	3697	3701												
BIT13 = 020000	584#	600	601	604	605	2191	2214	2320	2426	2666	2737	2842	2941	
	2967	2991	3059	3190	3200	3224	3327	3431	3518	3588				
BIT14 = 040000	583#	602	603	604	605	1050	2107	2108	2114	2115	3638	3666	3669	
	3673	3683	3686	3697	3701									
BIT15 = 100000	582#	1995	2049	2108	2116	2941	3059	3623	3644					
BIT2 = 000004	595#	977	1410	2522	2599	2962	2992	3099	3248	3343	3599	3697		
BIT3 = 000010	594#	1410	3425	3512	3582	3680								
BIT4 = 000020	593#	1991	1892	1944	1945	1998	1999	2052	2053	2193	2216	2322	2428	
	2513	2531	2588	2590	2608	2955	2957	2982	3074	3089	3202	3226	3238	
	3269	3271	3519	3521	3666	3668	3673							
BIT5 = 000040	592#	1891	1892	1944	1945	1998	1999	2052	2053	2193	2216	2322	2428	
	3202	3226												
BIT6 = 000100	591#	1721	1780	1793	2177	2312	2418	2522	2599	2962	2992	3099	3248	
	3343	3589	3683	3686	3697	3701								
BIT7 = 000200	590#	1044	1291	1448	1469	1721	1887	1940	1992	2046	2102	2107	2114	
	2193	2216	2253	2322	2428	2522	2599	2962	2992	3099	3202	3226	3248	
BIT8 = 000400	589#	1410	1427	1839	2516	2533	2593	2610	2671	2742	2763	2847	2968	
	2959	2984	3078	3093	3242	3432	3452	3523	3591					
BIT9 = 001000	588#	1410	1721	1726	1786	2044	2099	2184	2196	2210	2219	2516	2533	
	2593	2610	2666	2737	2842	2941	2959	2984	3059	3078	3093	3219	3229	
	3242	3327												
BRB = 070000	605#	1839	2671	2742	2763	2847	2868	3432	3452	3523	3591			
BRW 003014	983	1072#												
BRX 003016	984	1073#												
CHRCNT 003744	1227*	1231	1247*	1265#	1266									
CKBIT1 022406	1996	2050	2109	2117	2942	3060	3646	3654#						
CLKX 001242	676#	2142*	2148*	2154*	2160*	2201	2224	2226	2246	2277*	2283*	2289*	2295*	
	2326	2332	2339	2341	2379*	2386*	2393*	2400*	2432	2438	2445	2447	2524*	
	2639*	2644*	2649*	2670	2705*	2710*	2715*	2720*	2741	2762	2806*	2812*	2819*	
	2824*	2846	2867	2906*	2912*	2918*	2924*	2945	2973	3024*	3030*	3036*	3042*	
	3064	3069	3088	3139*	3145*	3151*	3157*	3208	3294*	3299*	3304*	3309*	3332	
	3356	3370												
CLK.A 001412	776#	1571	2142	2277	2379	2634	2705	2906	2906	3024	3139	3294		
CLK.B 001413	777#	1576	2148	2283	2386	2639	2710	2812	2912	3030	3145	3299		
CLK.C 001414	778#	1581	2154	2289	2393	2644	2715	2918	2918	3036	3151	3304		

DVTR01	001526	819#								
DVTR02	001552	830#								
DVTR03	001576	841#								
DVTR04	001622	852#								
DVTR05	001646	863#								
DVTR06	001672	874#								
DVTR07	001716	895#								
DVTEC	001356	754#	1564*	1565*	1566					
DV.END	001740	895#	1519	1528	1657					
DV.MAP	001500	697	806#	911	938	1521	1531	1655	1660	1709
DV00.A	001504	809#								
DV00.B	001510	811#								
DV00.C	001514	813#								
DV00.D	001520	815#								
DV01.A	001530	820#								
DV01.B	001534	822#								
DV01.C	001540	824#								
DV01.D	001544	826#								
DV02.A	001554	831#								
DV02.B	001560	833#								
DV02.C	001564	835#								
DV02.D	001570	837#								
DV03.A	001600	842#								
DV03.B	001604	844#								
DV03.C	001610	846#								
DV03.D	001614	848#								
DV04.A	001624	853#								
DV04.B	001630	855#								
DV04.C	001634	857#								
DV04.D	001640	859#								
DV05.A	001650	864#								
DV05.B	001654	866#								
DV05.C	001660	868#								
DV05.D	001664	870#								
DV06.A	001674	875#								
DV06.B	001700	877#								
DV06.C	001704	879#								
DV06.D	001710	881#								
DV07.A	001720	886#								
DV07.B	001724	888#								
DV07.C	001730	890#								
DV07.D	001734	892#								
EM1	022624	3729#	3746							
EM2	022653	3729#	3749							
EM3	022713	3729#	3752							
ENDPAT	022620	3261	3726#							
ERRCNT	001232	668#	913*	1035	1353*					
ERRFLG	001311	703#	909*	997*	1064*	1305*	1318	1332*	1387*	
ERRMSG	004252	1315*	1333	1336#						
ERTAB0	004366	1330	1362#							
EXIT =	000205	607#	3620	3633	3652	3670	3675	3695	3699	3703
EXITER	004322	1348	1353#							
FIX.00	006516	1572	1577	1582	1587	1621#				
HALTS	004302	1301	1347#							
HILIM	003436	1140*	1167	1185#						
ICOUNT	001222	664#	1062	1067*						

MO6

DZDVB MACY11 27(732) 17-SEP-76 11:14 PAGE 80
 DZDV8B.P11 CROSS REFERENCE TABLE -- USER SYMBOLS

INBUF	005520	1110	1146	1493#										
INIFLG	001310	702#	918	933*										
INSTER=	104404	725#	1161											
INSTR =	104403	723#	1594											
INSTR2	003236	1117	1129#											
LIGHT	000174	636#	928											
LIGHTS	001200	647#	928*	999*										
LIMITS	003364	1156	1167#											
LOAD.M	022266	2098	2181	2317	2423	2665	2736	2841	3189	3326	3430	3450	3517	3587
		3621#												
LOBITS	003442	1142*	1171	1187#	1188									
LOCK	001220	663#	1066*	1080	1082	1324	2200*	2325*	2431*	3073*	3205*	3324*		
LOGICA	002550	633	1016#											
LOKFLG	001312	704#												
LOLIM	003434	1139*	1169	1184#										
LPCNT	001224	665#	1061*	1062	1065*									
LSTERR	001234	669#	914*	996*	1048*	1302	1304*	1388*						
LOO.03	001416	781#	1534*	1569	1750	1815	1864	1916	1968	2022	2074	2144	2279	2382
		2486	2558	2635	2706	2808	2908	3026	3141	3295	3402	3489	3559	
LC4.07	001420	782#	1536*	1574	1754	1819	1868	1920	1972	2026	2078	2150	2295	2389
		2490	2562	2640	2711	2814	2914	3032	3147	3300	3406	3493	3563	
LO8.11	001422	783#	1538*	1579	1758	1823	1872	1924	1976	2030	2082	2156	2291	2396
		2494	2566	2645	2716	2820	2920	3038	3153	3305	3410	3497	3567	
L12.15	001424	784#	1540*	1584	1762	1827	1876	1928	1980	2034	2086	2162	2297	2403
		2498	2570	2650	2721	2826	2926	3044	3159	3310	3414	3501	3571	
MASKX	001244	677#	2143*	2149*	2155*	2161*	2234	1	2278*	2284*	2290*	2296*	2349	2351
		2380*	2387*	2394*	2401*	2455	2457	*	2913*	2919*	2925*	2990	3025*	3031*
		3037*	3043*	3114	3140*	3146*	3152*	*	3169					
MASK.A	001406	771#	1570	2143	2278	2380	2907		3140					
MASK.B	001407	772#	1575	2149	2284	2387	2913	3001	3146					
MASK.C	001410	773#	1580	2155	2290	2394	2919	3037	3152					
MASK.D	001411	774#	1585	2161	2296	2401	2925	3043	3158					
MASTEK	005400	1326	1484#											
MCRLF	005104	1095	1218	1322	1323	1331	1472	1484#	1593	1611				
MCSRX	005330	1001	1484#											
MDATA	005624	1245	1255	1497#										
MEPASS	005145	1000	1484#											
MERRPC	005454	1329	1484#											
MERRX	005355	1007	1484#											
MERR2	005174	1484#	1510	1700										
MERR3	005243	955	1484#											
MLOCK	005301	979	1484#											
MNEW	005402	950	1484#											
MPASSX	005344	1005	1484#											
MPFAIL	005107	1385	1484#											
MQM	005100	1125	1484#	1616										
MR	005171	987	1484#											
MRESET=	004000	607#	1404	1417										
MSTCLR=	104412	737#	1389	1833	1884	1936	1988	2042	2094	2171	2306	2412	2505	2580
		2660	2731	2836	2936	3054	3181	3320	3423	3510	3580			
MTITLE	001000	645#	932											
MTSTN	005366	1327	1484#	1595										
MTSTPC	005267	1484#												
MVECX	005336	1003	1484#											
NEXT	001216	662#	1068	1358	1748*	1813*	1862*	1914*	1966*	2020*	2072*	2140*	2275*	2377*
		2484*	2556*	2632*	2703*	2804*	2904*	3022*	3137*	3292*	3400*	3487*	3557*	

NOLIST= ***** U
NPR = 040000
NPRLOC 022620
PARAM = 104405
PARAM1 003204
PARBIT= 040000
PARERR 003360
PASCNT 001230
PC =%000007

PERFOR= 004537

PFTAB 004470
POPRO = 012600
POP1SP= 005726
POP2SP= 022626
PS = 177776
PUSHRO= 010046
PUSH1S= 005746
PUSH2S= 024646
QV.FLG 001313
RAM = 020000
RAMCLR= 104413
RESREG 004300
RESTAR 004414
RESTRT 002572
RESV16 001404
RESOS = 104407
RETURN 001214
ROMCLK= 104415

RUN 001304
RXSHIF 022326

RC =%000000

527														
602#														
3727#														
727#	1596													
1145#	1162													
607#	1640	2996	3103	3252										
1148	1150	1152	1161#	1168	1170	1172								
667#	908*	998*	999	1032										
574#	936*	1017*	1047*	1294*	1473*	1572*	1577*	1582*	1587*	1603	1604*	1643*		
1735*	1752*	1756*	1760*	1764*	1801*	1817*	1821*	1825*	1829*	1849*	1866*	1870*		
1874*	1878*	1883*	1899*	1918*	1922*	1926*	1930*	1935*	1952*	1970*	1974*	1978*		
1982*	1987*	1996*	2006*	2024*	2028*	2032*	2036*	2041*	2050*	2060*	2076*	2080*		
2084*	2088*	2093*	2109*	2117*	2127*	2146*	2152*	2158*	2164*	2169*	2262*	2281*		
2287*	2293*	2299*	2304*	2364*	2384*	2391*	2398*	2405*	2410*	2470*	2488*	2492*		
2496*	2500*	2542*	2560*	2564*	2568*	2572*	2577*	2619*	2637*	2642*	2647*	2652*		
2657*	2682*	2708*	2713*	2718*	2723*	2728*	2783*	2810*	2816*	2822*	2828*	2833*		
2888*	2910*	2916*	2922*	2928*	2933*	2942*	3006*	3028*	3034*	3040*	3046*	3051*		
3060*	3119*	3143*	3149*	3155*	3161*	3166*	3268*	3297*	3302*	3307*	3312*	3317*		
3385*	3404*	3408*	3412*	3416*	3421*	3473*	3491*	3495*	3499*	3503*	3508*	3544*		
3561*	3565*	3569*	3573*	3578*	3612*	3646*	3664*							
607#	1770	1835	1845	2098	2173	2181	2183	2205	2243	2258	2308	2316		
2317	2336	2359	2360	2414	2422	2423	2442	2465	2466	2507	2582	2662		
2665	2669	2733	2736	2740	2761	2838	2841	2845	2866	2938	2946	2949		
2953	2971	2980	3002	3056	3063	3068	3076	3084	3087	3091	3110	3183		
3189	3189	3240	3258	3263	3322	3326	3331	3355	3369	3427	3430	3450		
3514	3517	3584	3587											
1386	1392#													
581#	1352													
581#														
581#	1070													
579#	904*	973*	1720*											
581#	1349													
581#														
705#	910*	1011*	1059											
600#														
739#	1390	1767												
1343	1346#													
1373	1379#													
1010	1014	1022#												
765#	1559*	1560*												
731#	1346													
661#	916*	986*	988	1022*	1068*	1071	1358*	1360	1391	1610*	1618*	1619		
743#	1781	1794	2178	2192	2194	2215	2217	2313	2321	2323	2419	2427		
2429	2514	2524	2532	2589	2591	2601	2609	2956	2958	2964	2983	2994		
3075	3090	3101	3201	3203	3225	3227	3239	3250	3270	3272	3344	3520		
3522	3590	3667	3669	3674	3684	3697	3698	3702						
695#	912*	1513	1516*	1517*	1524*	1525*								
2669	2740	2761	2845	2866	2946	2949	2953	2980	3063	3068	3087	3331		
3355	3369	3634#												
567#	951*	959*	960*	962*	964*	966	967	1049	1055*	1069*	1202	1207*		
1219	1232*	1236*	1246	1262*	1350*	1395	1396*	1397*	1399*	1425	1426*	1431*		
1434*	1526*	1532	1533	1534	1535	1536	1537	1538	1539	1540	1541	1542*		
1548	1550	1556	1558	1560	1563	1565	1567	1569*	1574*	1579*	1584*	1602*		
1603	1606	1608	1610	1613	1614	1621	1640	1701*	1710*	1712*	1714	1722*		
1723*	1749*	1753*	1757*	1761*	1768	1783*	1785*	1796*	1798*	1814*	1818*	1822*		

G07

DDV8 MACY11 27.732\ 17-SEP-75 11:14 PAGE 87
DDV8B.P11 CROSS REFERENCE TABLE -- USER SYMBOLS

.TRFTA	001314	716*	1280
.TYPE	003044	722	1088*

OVEND	1#	988													
OVFRNT	1#	527													
HLT	1#	1433	1779	1792	1844	1895	1948	2002	2056	2105	2113	2121	2188	2199	2227
	2001	2355	2461	2521	2528	2538	2598	2605	2615	2678	2750	2759	2771	2779	2855
	2004	2978	2884	2970	3001	3093	3098	3109	3247	3257	3342	3351	3366	3380	3440
	2449	3460	3469	3531	3540	3599	3608	3631	3662						
SBUFFE	1#	1490													
SOCK15	1#	3646													
SOCK15D	1#	3654													
SOCLR.T	1#	3700													
SOCYCLE	1#	1499													
SOPOP	1#	999													
SOPTINT	1#	3729													
SOPTFL	1#														
SOPTPAR	1#	1594													
SOHPRDE	1#	527													
SLOC01	527#	1737													
SLOC02	527#	1851	1901	1954	2008										
SLOC02A	527#	2062													
SLOC03	527#	2129													
SLOC03A	527#														
SLOC04	527#	2264	2366												
SLOC05	527#	2472	2544												
SLOC06	527#	2621													
SLOC06A	527#	2684	2785												
SLOC06B	527#	2890													
SLOC07	527#	3009													
SLOC07A	527#	3121													
SLOC10	527#	3275													
SLOC11	527#	3397													
SLOC12	527#	3475													
SLOC13	527#	3546													
SMSG	1#	1484													
SPPAIL	1#	1368													
SPPMCL	1#	1395													
SRYSHI	1#	3534													
SSCOPE	1#	1036													
SSETLI	1#	1745	1810	1859	1911	1963	2017	2069	2137	2272	2374	2491	2553	2629	2700
	2801	2901	3019	3134	3289	3397	3484	3554							
SSETSC	1#	3677													
SSETSY	1#														
SSET.T	1#	3696													
SSILOI	1#	3665													
SSIMBC	1#														
STRPDE	1#	717	719	721	723	725	727	729	731	733	735	737	739	741	743
	745														
STSTN	1#	1745	1810	1859	1911	1963	2017	2069	2137	2272	2374	2491	2553	2629	2700
	2801	2901	3019	3134	3289	3397	3484	3554							
STXSHI	1#	3614													
SVARIA	1#	643													
SXZ	1#	1738	1743	1804	1808	1852	1856	1902	1908	1955	1960	2009	2014	2063	2067
	2130	2135	2265	2270	2367	2372	2473	2479	2545	2551	2522	2627	2685	2698	2786
	2799	2891	2899	3010	3017	3122	3132	3276	3287	3389	3395	3476	3492	3547	3532

DZDVB MACY11 27(732) 17-SEP-76 11:14 PAGE 91
 DZDVB.P11 CROSS REFERENCE TABLE -- PERMANENT SYMBOLS

ADCB	1517	1525															
ADD	944	1090	1107	1178	1225	1235	1280	1311	1314	1410	1518	1527	1548	1550	1556		
ASL	1558	1560	1563	1565	1567	1583	1728	2529	2606								
BSC	1157	1158	1159	1278	1310	1312											
BSCS	1430	1719															
BSCS	1459																
BSCS	941	949	978	1014	1042	1051	1060	1079	1081	1117	1148	1156	1250	1289	1296		
BSCS	1303	1319	1325	1334	1339	1343	1357	1450	1589	1641	1682	1689	1778	1791	1843		
BSCS	1862	1894	1934	1947	1986	2001	2040	2055	2092	2104	2112	2120	2168	2187	2225		
BSCS	2236	2240	2242	2303	2340	2354	2409	2446	2460	2518	2527	2576	2595	2604	2656		
BSCS	2737	2737	2749	2758	2770	2778	2832	2854	2863	2875	2883	2932	2969	2997	3000		
BSCS	3050	3090	3095	3104	3108	3113	3115	3165	3235	3237	3244	3253	3256	3266	3316		
BSCS	3341	3350	3365	3379	3439	3448	3459	3468	3530	3539	3598	3607	3682				
BSCS	1152	1463															
BSCS	1168																
BSCS	950	1044	1234	1279	1291	1313	1448	1464	1469	1622	1726	1731	1887	1891	1992		
BSCS	1940	1944	1945	1998	1999	2046	2052	2053	2102	2114	2115	2350	2352	2456	2458		
BSCS	2675	2747	2768	2776	2852	2873	2881	2967	2998	3105	3197	3211	3254	3339	3377		
BSCS	3437	3446	3638														
BSCS	1115	1153	2234	2349	2351	2455	2457	2990									
BSCS	1427	1427	1465	1672	1673	1674	1675	1676	1677	1678	1679	1725	1730	1992	1995		
BSCS	2049	2107	2108	2116	2526	2674	2746	2756	2767	2775	2851	2861	2872	2880	2991		
BSCS	3174	3177	3213	3348	3363	3436	3445	3456	3457	3465	3466	3527	3528	3536	3537		
BSCS	3595	3596	3604	3605	3623	3644	3645	3680									
BSCS	1154	2989															
BSCS	946	977	1050	1057	1078	1091	1295	1300	1354	1356	1438	1588	1640	1881	1933		
BSCS	1985	2039	2091	2167	2186	2197	2210	2219	2253	2302	2408	2517	2534	2575	2594		
BSCS	2611	2655	2726	2754	2831	2859	2931	2960	2985	2996	3049	3065	3079	3294	3103		
BSCS	3164	3191	3219	3229	3243	3252	3315	3419	3506	3576							
BSCS	1171	1513	2241	3114													
BSCS	1170																
BSCS	954	1716															
BSCS	1150	1461															
BSCS	951	1751	1755	1759	1763	1816	1820	1824	1828	1865	1869	1873	1877	1917	1931		
BSCS	1925	1929	1969	1973	1977	1981	2023	2027	2031	2035	2075	2079	2083	2097	2145		
BSCS	2151	2157	2163	2280	2286	2292	2298	2383	2390	2397	2404	2487	2491	2495	2499		
BSCS	2559	2563	2567	2571	2636	2541	2646	2651	2707	2712	2717	2722	2809	2815	2821		
BSCS	2827	2909	2915	2921	2927	3027	3033	3039	3045	3142	3149	3154	3160	3296	3301		
BSCS	3306	3311	3403	3407	3411	3415	3490	3494	3498	3502	3560	3564	3568	3572			
BSCS	919	947	968	976	1010	1046	1058	1063	1092	1099	1122	1172	1180	1244	1248		
BSCS	1253	1257	1293	1301	1321	1355	1384	1398	1411	1432	1439	1471	1509	1514	1520		
BSCS	1530	1592	1605	1607	1609	1615	1624	1629	1634	1658	1664	1666	1668	1685	1696		
BSCS	1724	1800	1848	1898	1951	2005	2059	2123	2126	2198	2208	2211	2220	2220	2231		
BSCS	2250	2254	2257	2261	2329	2338	2346	2357	2363	2435	2444	2452	2463	2469	2520		
BSCS	2535	2537	2541	2597	2612	2614	2618	2681	2755	2782	2960	2987	2961	2978	2986		
BSCS	3005	3066	3082	3097	3118	3192	3217	3220	3230	3233	3246	3262	3334	3358	3372		
BSCS	3384	3420	3472	3507	3543	3577	3611	3630	3649	3661	3690						
BFL	1054	1094	1097	1113	1119	1298	1348	1446	1453	1467	3627	3658					
BR	926	945	957	982	1052	1056	1128	1160	1162	1375	1512	1522	1612	1617	1627		
CLC	1632	1637	1703	1729	3194												
CLR	237	1239	1241	1455	1515	1523	1692	1784	1797	2227	2342	2448	2975	3172	3175		
CLR	3640	3693															
CLR	908	913	914	922	951	965	996	1048	1065	1066	1145	1382	1398	1409	1426		
CLR	1451	1656	1701	1720	1722	1727	1769	1834	1885	1937	1999	2043	2095	2172	2176		
CLR	2185	2189	2202	2209	2307	2311	2319	2333	2413	2417	2425	2439	2506	2515	2520		
CLR	2581	2592	2607	2661	2732	2837	2937	3055	3077	3092	3168	3170	3182	3198	3218		

	3241	3321	3424	3511	3581	3625	3639	3656							
CLRB	909	910	997	1064	1254	1305	1387	1625	1659	1687	2511	3072	3086	3212	
CMP	927	940	966	967	1041	1062	1167	1169	1288	1302	1460	1462	1519	1528	1603
	1606	1609	1614	1628	1633	1657	1665	1684	1714	1715	1732	1777	1790	1842	1893
	1946	2000	2054	2103	2111	2119	2207	2224	2230	2235	2339	2345	2353	2445	2451
	2459	2526	2503	2676	2748	2757	2769	2777	2853	2862	2874	2892	2968	2999	3107
	3216	3234	3236	3255	3261	3340	3349	3364	3378	3438	3447	3458	3467	3529	3538
	3597	3606													
COMP	953	1045	1116	1147	1149	1151	1155	1292	1449	1470	1681				
COMB	933														
DEC	1121	1243	1256	1397	1695	1799	1847	1897	1950	2004	2058	2122	2125	2206	2221
	2249	2256	2260	2328	2337	2356	2362	2434	2443	2462	2468	2540	2617	2680	2781
	2986	2974	3004	3117	3215	3231	3265	3333	3357	3371	3383	3471	3542	3610	3689
DECB	1009	1179	1247	1252	2977	3648									
EMT	581														
HAL	619	952	956	961	1351	1374	1511	1702							
INC	998	1061	1353	1393	1431	1544	1546	1552	1554	1723	1782	1795	1896	1949	2003
	2057	2124	2179	2212	2229	2314	2344	2420	2450	2519	2536	2539	2596	2613	2615
	2679	2780	2885	3003	3081	3096	3116	3221	3245	3260	3264	3392	3470	3541	3609
	3629	3660	3685	3688											
INCB	1642	1680	1694	2239	3112										
JMP	641	988	1023	1071	1282	1360	1391	1619	1699	3267	3273				
JSR	936	1017	1047	1294	1572	1577	1582	1597	1752	1756	1760	1764	1817	1821	1825
	1829	1866	1870	1874	1878	1918	1922	1926	1930	1970	1974	1978	1982	1996	2024
	2028	2032	2036	2050	2076	2080	2084	2088	2109	2117	2146	2152	2158	2164	2281
	2287	2293	2299	2384	2391	2398	2405	2488	2492	2496	2500	2560	2564	2568	2572
	2537	2642	2647	2652	2708	2713	2718	2723	2810	2816	2822	2828	2910	2916	2922
	2928	2942	3028	3034	3040	3046	3060	3143	3149	3155	3161	3297	3302	3307	3312
	3404	3408	3412	3416	3491	3495	3499	3503	3561	3565	3569	3573	3646		
MOV	904	905	906	911	915	916	920	921	923	928	929	930	931	938	939
	962	963	964	973	974	980	981	983	984	986	999	1013	1022	1043	1049
	1055	1067	1068	1069	1082	1088	1089	1100	1104	1105	1106	1110	1111	1120	1123
	1124	1126	1127	1129	1130	1136	1137	1138	1139	1140	1141	1144	1146	1176	1177
	1181	1182	1193	1197	1198	1199	1200	1201	1202	1207	1208	1209	1210	1211	1212
	1219	1220	1221	1222	1223	1224	1226	1229	1230	1232	1233	1245	1258	1259	1260
	1261	1262	1275	1277	1281	1290	1304	1307	1309	1315	1316	1317	1350	1358	1359
	1373	1380	1381	1395	1396	1399	1404	1405	1406	1407	1408	1412	1413	1417	1425
	1428	1434	1440	1441	1447	1454	1468	1521	1526	1531	1532	1533	1534	1535	1536
	1527	1538	1539	1540	1541	1542	1543	1545	1547	1549	1551	1553	1555	1557	1559
	1562	1564	1566	1569	1570	1571	1574	1575	1576	1579	1580	1581	1584	1595	1596
	1602	1604	1610	1618	1621	1655	1660	1661	1662	1670	1686	1697	1704	1707	1708
	1709	1710	1711	1712	1713	1721	1733	1747	1748	1749	1750	1753	1754	1757	1758
	1761	1762	1768	1772	1773	1774	1775	1776	1780	1783	1786	1787	1788	1789	1793
	1796	1812	1813	1814	1815	1818	1819	1822	1823	1826	1827	1832	1837	1838	1839
	1840	1841	1861	1862	1863	1864	1867	1868	1871	1872	1875	1876	1886	1888	1889
	1890	1913	1914	1915	1916	1919	1920	1923	1924	1927	1928	1938	1939	1941	1942
	1943	1965	1966	1967	1968	1971	1972	1975	1976	1979	1980	1990	1991	1993	1994
	1997	2019	2020	2021	2022	2025	2026	2029	2030	2033	2034	2044	2045	2047	2048
	2051	2071	2072	2073	2074	2077	2078	2081	2082	2085	2096	2096	2097	2100	2101
	2106	2110	2118	2139	2140	2141	2144	2147	2150	2153	2156	2159	2162	2170	2175
	2177	2180	2184	2190	2191	2193	2196	2200	2203	2213	2214	2216	2218	2226	2230
	2247	2251	2274	2275	2276	2279	2282	2285	2288	2291	2294	2297	2305	2310	2312
	2315	2320	2322	2325	2331	2334	2341	2348	2376	2377	2378	2381	2392	2385	2389
	2389	2392	2395	2396	2399	2402	2403	2411	2416	2418	2421	2426	2428	2431	2437
	2440	2447	2454	2483	2484	2485	2486	2489	2490	2493	2494	2497	2498	2503	2504
	2509	2513	2516	2522	2523	2525	2531	2533	2555	2556	2557	2558	2561	2562	2565

	2566	2569	2570	2578	2579	2584	2588	2590	2593	2599	2600	2602	2608	2610	2631
	2632	2633	2635	2638	2640	2643	2645	2648	2650	2658	2659	2664	2671	2672	2673
	2702	2703	2704	2706	2709	2711	2714	2716	2719	2721	2729	2730	2735	2742	2744
	2745	2751	2752	2753	2763	2765	2766	2772	2773	2774	2803	2804	2805	2807	2808
	2811	2813	2814	2817	2819	2820	2823	2825	2826	2834	2835	2840	2843	2847	2849
	2850	2856	2857	2858	2865	2868	2870	2871	2877	2878	2879	2903	2904	2905	2908
	2911	2914	2917	2920	2923	2926	2934	2935	2940	2941	2955	2957	2959	2962	2963
	2965	2966	2979	2982	2984	2987	2992	2993	2995	3021	3022	3023	3026	3029	3032
	3035	3038	3041	3044	3052	3053	3058	3059	3070	3073	3074	3078	3085	3089	3093
	3099	3100	3102	3136	3137	3138	3141	3144	3147	3150	3153	3156	3159	3167	3178
	3180	3187	3193	3195	3199	3200	3202	3205	3206	3209	3223	3224	3226	3228	3238
	3242	3248	3249	3251	3269	3271	3291	3292	3293	3295	3298	3300	3303	3305	3308
	3310	3318	3319	3324	3325	3328	3330	3335	3336	3337	3338	3343	3345	3346	3347
	3352	3353	3359	3350	3361	3362	3367	3368	3373	3374	3375	3376	3399	3400	3401
	3402	3405	3406	3409	3410	3413	3414	3422	3425	3426	3429	3432	3433	3434	3435
	3441	3442	3443	3444	3452	3453	3454	3455	3461	3462	3463	3464	3486	3487	3488
	3489	3492	3493	3496	3497	3500	3501	3509	3512	3513	3516	3519	3521	3523	3524
	3525	3526	3532	3533	3534	3535	3556	3557	3558	3559	3562	3563	3566	3567	3570
	3571	3579	3582	3583	3586	3589	3591	3592	3593	3594	3600	3601	3602	3603	3615
	3616	3619	3622	3624	3632	3635	3636	3650	3651	3655	3663	3666	3668	3673	3679
	3681	3683	3686	3691	3692	3697	3701								
MOV8	907	912	958	959	1011	1012	1098	1114	1142	1143	1227	1228	1231	1236	1246
	1251	1299	1332	1626	1630	1631	1635	1636	1638	1639	1690	1691	1698	1717	2142
	2143	2148	2149	2154	2155	2160	2161	2201	2246	2277	2278	2283	2284	2289	2290
	2295	2296	2326	2330	2332	2379	2380	2386	2387	2393	2394	2400	2401	2432	2436
	2438	2634	2639	2644	2649	2667	2705	2710	2715	2720	2738	2760	2806	2812	2818
	2824	2906	2907	2912	2913	2918	2919	2924	2925	2943	2945	2948	2951	2972	2973
	3024	3025	3030	3031	3036	3037	3042	3043	3061	3067	3139	3140	3145	3146	3151
	3152	3157	3158	3169	3171	3179	3196	3208	3210	3222	3294	3299	3304	3309	3637
NEG	3354														
TOP	925	980	981	1018	1019	1020	1021								
RESET	995	1015	1654												
ROL	1456	1457	1458	3173	3176										
ROLB	1516	1524	1693	3617											
ROR	1238	1240	1242	1718	1785	1798	2228	2343	2449	3541	3642	3643	3694		
RORB	1429	2976	3618												
RTI	1083	1101	1131	1183	1203	1213	1263	1361	1400	1414	1418	1422	1435	1705	1734
RTS	1473	1643	1735	1801	1849	1883	1899	1935	1952	1987	2006	2041	2060	2093	2127
	2169	2262	2304	2364	2410	2470	2542	2577	2619	2657	2682	2729	2783	2833	2888
	2933	3006	3051	3119	3166	3268	3317	3385	3421	3473	3508	3544	3578	3612	3664
SUB	1276	1308	2952												
SWAB	2510	2585	2988	3071	3207										
TRAP	717	719	721	723	725	727	729	731	733	735	737	739	741	743	745
TST	924	946	975	1080	1320	1324	1333	1338	1342	1347	1591	1613	1623	1663	1667
TSTB	1671	2222	3232	3626	3657										
	918	934	1053	1059	1093	1096	1112	1118	1249	1297	1318	1445	1452	1466	1508
	1688														
.ASCIZ	645	1475	1482	1484	3729										
.BLKB	691	692	693	694	695										
.BLKW	630	631	632	807	808	809	810	811	812	813	814	815	816	818	819
	820	821	822	823	824	825	826	827	829	830	831	832	833	834	835
	836	837	838	840	841	842	843	844	845	846	847	848	849	851	852
	853	854	855	856	857	858	859	860	862	863	864	865	866	867	868
	869	870	871	873	874	875	876	877	878	879	880	881	882	884	885
	886	887	888	889	890	891	892	893	1436	1771	1836	2174	2309	2415	2508
	2583	2663	2734	2839	2939	3007	3057	3184	3323	3428	3515	3595	3705		

.BYTE	702 1034 3712 3733	703 1363 3713 3735	704 1366 3714 3737	705 1393 3715 3739	771 1479 3716	772 1485 3717	773 1487 3718	774 1600 3719	776 1601 3720	777 3706 3721	778 3707 3722	779 3708 3723	1025 3709 3724	1028 3710 3725	1031 3711 3731
.ENABL	541														
.END	3756														
.ENDC	1737 1956 2271 2579 3019 3553	1739 1959 2276 2590 3023 3558	1744 1961 2368 2623 3123 3756	1749 1967 2373 2628 3133	1805 2010 2378 2633 3138	1809 2013 2474 2686 3277	1814 2015 2479 2699 3288	1853 2021 2480 2704 3293	1855 2064 2485 2787 3389	1857 2068 2503 2800 3396	1863 2073 2513 2805 3401	1903 2131 2546 2892 3477	1907 2136 2551 2900 3483	1909 2141 2552 2905 3488	1915 2266 2557 3011 3548
.EQUIV	591														
.EVEN	696	707	1477	1483	1484	1489	3729								
.IF	527 1908 2135 2546 2899 3482	1738 1914 2140 2551 2904 3487	1743 1955 2265 2556 3010 3547	1748 1956 2270 2575 3017 3552	1804 1959 2275 2588 3022 3557	1809 1960 2367 2622 3122 3756	1813 1966 2372 2627 3132	1852 2009 2377 2632 3137	1853 2010 2473 2685 3276	1855 2014 2474 2698 3287	1856 2020 2479 2703 3292	1862 2063 2484 2786 3388	1902 2067 2503 2799 3395	1903 2072 2513 2804 3400	1907 2130 2545 2891 3476
.IFF	1739 1915 2140 2551 2992 3293	1743 1956 2141 2556 2899 3389	1748 1960 2266 2557 2904 3395	1749 1966 2270 2623 2905 3400	1805 1967 2275 2627 3011 3401	1808 2010 2276 2632 3017 3477	1813 2014 2368 2633 3022 3482	1814 2020 2372 2686 3023 3487	1853 2021 2377 2698 3123 3488	1856 2064 2378 2703 3132 3548	1862 2067 2474 2787 3137 3552	1863 2072 2484 2799 3138 3557	1903 2073 2484 2799 3277	1908 2131 2485 2904 3287	1914 2135 2546 2805 3292
.IFT	527 2067 2685 3482	1737 2130 2698 3547	1738 2135 2786 3552	1743 2265 2799	1804 2270 2891	1808 2367 2899	1852 2372 3010	1856 2473 3017	1902 2474 3122	1908 2479 3132	1955 2545 3276	1960 2546 3287	2009 2551 3388	2014 2622 3395	2063 2627 3476
.IFTF	527														
.IIF	1748 1868 1940 2020 2082 2162 2295 2387 2494 2639 2716 2812 2912 3031 3147 3309 3558	1749 1872 1941 2021 2086 2162 2296 2388 2498 2640 2720 2813 2913 3032 3151 3310 3559	1750 1876 1943 2022 2140 2269 2297 2393 2511 2644 2721 2818 2914 3036 3152 3400 3563	1754 1886 1966 2026 2141 2272 2318 2394 2512 2645 2737 2819 2918 3037 3153 3401 3567	1758 1887 1967 2030 2142 2275 2319 2395 2556 2649 2738 2824 2919 3038 3157 3402 3571	1762 1888 1968 2034 2143 2276 2330 2400 2557 2650 2739 2825 2920 3042 3158 3406	1813 1890 1972 2044 2144 2277 2331 2401 2558 2696 2760 2831 2924 3043 3159 3410	1814 1914 1976 2046 2148 2278 2370 2402 2562 2700 2761 2842 2925 3044 3137 3292 3414	1815 1915 1980 2047 2149 2279 2374 2408 2566 2703 2761 2843 2926 3137 3293 3487	1819 1916 1990 2049 2150 2283 2377 2424 2570 2704 2798 2865 3022 3138 3294 3488	1823 1920 1991 2050 2154 2284 2378 2436 2586 2705 2801 2904 3023 3139 3295 3489	1827 1924 1992 2072 2155 2285 2379 2484 2632 2706 2804 2905 3024 3140 3299 3493	1862 1928 1995 2073 2156 2289 2380 2485 2633 2710 2805 2906 3025 3141 3300 3497	1863 1938 1996 2074 2160 2290 2381 2486 2634 2711 2806 2907 3026 3145 3304 3501	1864 1939 1997 2078 2161 2291 2386 2490 2635 2715 2807 2909 3030 3146 3305 3557
.IRP	717 807 1966 2377 2804 3400	719 1738 2009 2473 2891 3476	721 1745 2017 2481 2901 3484	723 1748 2020 2484 2904 3487	725 1804 2063 2545 3010 3547	727 1810 2069 2553 3019 3554	729 1813 2072 2556 3022 3557	731 1852 2130 2622 3122 3729	733 1859 2137 2629 3134	735 1862 2140 2632 3137	737 1902 2265 2685 3276	739 1911 2272 2700 3289	741 1914 2275 2703 3292	743 1955 2367 2786 3388	745 1963 2374 2801 3397
.LIST	1 729	527 731	541 733	562 735	581 737	607 739	609 741	619 743	643 745	645 747	719 902	721 896	723 989	725 1037	727 1484

M07

DZDV8 MACY11 27(732) 17-SEP-76 11:14 PAGE 95
DZDV8B.P11 CROSS REFERENCE TABLE -- PERMANENT SYMBOLS

	1737	1738	1743	1749	1804	1808	1814	1852	1856	1863	1902	1908	1915	1955	1960
	1967	2009	2014	2021	2063	2067	2073	2130	2135	2141	2265	2270	2276	2367	2372
	2378	2473	2479	2485	2545	2551	2557	2622	2627	2633	2685	2698	2704	2786	2799
	2805	2891	2899	2905	3010	3017	3023	3122	3132	3138	3276	3287	3293	3388	3395
	3401	3476	3482	3488	3547	3552	3558	3729							
.MACRO	1	527													
.NLIST	1	527	541	562	581	607	609	619	643	645	719	721	723	725	727
	729	731	733	735	737	739	741	743	745	747	802	896	989	1037	1484
	1737	1738	1743	1749	1804	1808	1814	1852	1856	1863	1902	1908	1915	1955	1960
	1967	2009	2014	2021	2063	2067	2073	2130	2135	2141	2265	2270	2276	2367	2372
	2378	2473	2479	2485	2545	2551	2557	2622	2627	2633	2685	2698	2704	2786	2799
	2805	2891	2899	2905	3010	3017	3023	3122	3132	3138	3276	3287	3293	3388	3395
	3401	3476	3482	3488	3547	3552	3558	3729							
.PAGE	562	609	698	750	802	896	989	1499	1737						
.REM	1	896													
.REPT	619														
.SBTTL	527	562	609	643	896	989	1037	1737							
.TITLE	541														
.WORD	1481														

ERRORS DETECTED: 0
DEFAULT GLOBALS GENERATED: 0

*.DZDV8B/SOL/CRF=DZDV8B.MAC,DZDV8B.P11
RUN-TIME: 31 45 7 SECONDS
RUN-TIME RATIO: 820/84=9.7
CORE USED: 27K (53 PAGES)

