

RK11/05F/J

PERFORMANCE EXERCISER
MD-11-DZRKH-G

EP-DZRKH-G-DL-A
COPYRIGHT © 74-77
FICHE 1 OF 1

AUG 1977
digital
MADE IN USA

B01

EJF:02M9A0SEQ

00010000

770712

PDP10 411

37HDR10ZRKMGSEQ

00010000

770712

.REM %

IDENTIFICATION

PRODUCT CODE: MAINDEC-11-DZRKH-G-0
PRODUCT NAME: RK11/RK05 PERFORMANCE EXERCISER
DATE: APRIL, 1977
MAINTAINER: DIAGNOSTIC GROUP
AUTHOR: JIM KAPADIA
REVISIONS: TOM SAWYER, GEORGE GALLANT, CHUCK HESS

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1974, 1977 BY DIGITAL EQUIPMENT CORPORATION

TABLE OF CONTENTS

1.0	ABSTRACT
2.0	REQUIREMENTS
2.1	EQUIPMENT
2.2	PRELIMINARY PROGRAMS
2.3	EXECUTION TIME
3.0	STARTING ADDRESSES
4.0	PROGRAM CONTROL MODES
4.1	PAPER TAPE LOADING
4.2	RKDP DUMP MODE
4.3	RKDP CHAIN MODE
4.4	ACT11
5.0	DRIVE SELECTION
6.0	SWITCH OPTIONS
7.0	PROGRAM STRUCTURE AND DESCRIPTION
7.1	NON-EXERCISER TESTS
7.2	EXERCISER PROGRAM
8.0	LOOPING CAPABILITIES
9.0	TRANSFER DATA LOGGING
10.0	ERROR LOGGING
11.0	ERROR REPORTING AND RECOVERY
12.0	SUBROUTINES AND HANDLERS

1.0 ABSTRACT

THE RK11/RK05 PERFORMANCE EXERCISER IS A HIGH LEVEL EXERCISER PROGRAM AIMED AT SIMULATING A RK11/RK05 SYSTEM ENVIRONMENT AND CHECKING FOR ERRORS THAT ARISE IN SUCH AN ENVIRONMENT (INTERACTION, POLLING, ETC). IT ALSO PROVIDES A MEANS OF EVALUATING A SYSTEM THROUGH ITS ERROR LOGGING AND DATA-TRANSFER LOGGING FACILITIES.

AT THE BEGINNING OF THE PROGRAM THERE IS A SERIES OF TESTS SPECIFICALLY AIMED AT DETECTING AND ANALYZING FAILURES ASSOCIATED WITH BOUNDARY CONDITION TRANSFERS.

THE LATTER PART (AND THE MORE SIGNIFICANT ONE) CONSISTS OF THE EXERCISER.

2.0 REQUIREMENTS

2.1 EQUIPMENT

- A. PDP11 WITH CONSOLE TELTYPE
- B. 8K OF MEMORY - 12K FOR CHAIN MODE
- C. RK11 OR RKV11 CONTROLLER
- D. 1-8 RK05 OR RK05F DRIVES (DRIVE TYPES MAY BE MIXED)

2.2 PRELIMINARY PROGRAMS

SINCE THIS IS A HIGH-LEVEL EXERCISER PROGRAM THE CONTROLLER AND THE DRIVE SHOULD BE FREE OF BASIC FAULTS. IT IS POSSIBLE TO HANG THE PROGRAM IF THE HEAD POSITIONING LOGIC IS FAULTY ON DUAL DENSITY DRIVES. THUS THE FOLLOWING PROGRAMS SHOULD BE RUN BEFORE ATTEMPTING TO USE THIS PROGRAM.

- A. RK11 BASIC LOGIC TESTS (I AND II)
- B. RK11/RK05 DYNAMIC TESTS
- C. RK05 UTILITY PACKAGE (IF NEEDED)

2.3 EXECUTION TIME

THIS VARIES FROM 30 TO 90 MINUTES FOR A PASS. IT SHOULD BE NOTED THAT THIS IS AN EXERCISER LEVEL PROGRAM AND SHOULD BE PREFERABLY RUN FOR A LONG PERIOD OF TIME.

NOTE: THE FIRST PASS IS A SHORT (5-20 MINUTE) PASS TO SERVE AS A QUICK VERIFY OF THE RK SUBSYSTEM.

3.0 STARTING ADDRESS

200 - ALL SWITCHES DOWN. SEE SEC. 6.0 FOR SWITCHES.

210 - RESTART ADDRESS. THE RESTART ADDRESS PROVIDES THE USER WITH AN ABILITY TO GO STRAIGHT TO EXERCISER PART OF THE PROGRAM (SKIPPING TESTS 1-7). THERE IS A SWITCH OPTION (SW 4) WHICH ALLOWS THE USER TO INHIBIT THE REWRITE OF RANDOM PATTERNS ON ALL DRIVES, ON RESTART. SEE SEC- 6.9.

4.0 PROGRAM CONTROL MODES AND OPERATOR ACTION

PAPER TAPE LOADING
RKDP DUMP MODE
RKDP CHAIN MODE
ACT11

4.1 PAPER TAPE LOADING

4.1.1 LOAD PROGRAM INTO MEMORY USING STANDARD PROCEDURE FOR ABSOLUTE TAPES.

4.1.2 MAKE SURE THAT THE DRIVES TO BE CHECKED ARE LOADED WITH DISKS AND ARE IN 'RUN'. 'WRT ENABLE' THEM. CHECK THAT 'WRT PROT' LIGHT ON THESE DRIVES IS OFF. PUT DRIVES THAT ARE NOT TO BE TESTED ON 'LOAD'.

4.1.3 LOAD ADDRESS 200

4.1.4 SET SWITCHES IF DESIRED (SEE SEC 6.0) AND PRESS START

4.1.5 THE PROGRAM IDENTIFIES ITSELF

MAINDEC-11-DZRKH-G

RK11/RK05 PERFORMANCE EXERCISER

THEN IT PROCEEDS TO TEST THE DRIVES.

4.2 RKDP DUMP MODE

4.2.1 THE PROGRAM IS LOADED BY THE RKDP MONITOR.

4.2.2 SET SA=200. SELECT ANY SWITCHES YOU WANT AND PRESS START.

4.2.3 THE PROGRAM IDENTIFIES ITSELF AND PRINTS OUT:

'TO TEST DRIVE 'N' HALT PROGRAM, REMOVE RKDP PACK AND REPLACE IT WITH A WORK PACK, CLEAR LOCATION 40, AND RESTART PROGRAM'

IN RESPONSE TO THIS MESSAGE, PERFORM THE ACTIONS REQUESTED IF THE DRIVE ON WHICH THE RKDP PACK IS MOUNTED IS TO BE TESTED.

4.3 RKDP CHAIN MODE

THE PROGRAM IS CHAIN LOADED FROM RKDP PACK ON DRIVE 'N'. AFTER IDENTIFYING ITSELF, THE FOLLOWING MESSAGE APPEARS:

'DRIVE 'N' NOT TESTED'

DRIVE 'N' WILL NOT BE TESTED SINCE THE RKDP PACK IS ON THAT DRIVE.

4.4 ACT11 MODE

THE PROGRAM IS LOADED BY THE ACT11 MONITOR. AFTER IDENTIFYING ITSELF, ASCERTAINS THE NUMBER OF DRIVES PRESENT AND PROCEEDS TO TEST EACH OF THEM AS BEFORE.

5.0 DRIVE SELECTION

PUT ALL THE DRIVES THAT ARE TO BE EXERCISED AND TESTED ON 'RUN' WRITE ENABLE THEM. MAKE SURE THAT THE 'WRT PROT' IS OFF. THE PROGRAM RECOGNIZES THAT THESE DRIVES ARE ON LINE AND PROCEEDS TO TEST THEM. RK05F DRIVES WILL HAVE THE LETTER F TYPED AFTER THE DRIVE NUMBER.

IF A FATAL ERROR OCCURS ON A DRIVE WHILE THE PROGRAM IS RUNNING THE DRIVE IS AUTOMATICALLY DESELECTED ('DSELCT') AND DROPPED FROM THE DRIVE SELECTION LIST.

6.0 SWITCH OPTIONS

IF THE PROGRAM IS BEING RUN ON A SWITCHLESS PROCESSOR (I.E. AN 11/34) THE PROGRAM WILL DETERMINE THAT THE HARDWARE SWITCH REGISTER IS NOT PRESENT AND WILL USE A 'SOFTWARE' SWITCH REGISTER. THE 'SOFTWARE' SWITCH REGISTER IS LOCATED AT LOCATION 176 (8). THE SETTINGS OF THE 'SOFTWARE' SWITCHES ARE CONTROLLED THROUGH A KEYBOARD ROUTINE WHICH IS CALLED BY TYPING A 'CONTROL G'. THE PROGRAM WILL RECOGNIZE THE 'CONTROL G' WHENEVER THE PROGRAM ENTERS THE SCOPE ROUTINE OR BEGINS A NEW TEST. THE 'SOFTWARE' SWITCH VALUES ARE ENTERED AS AN OCTAL NUMBER IN RESPONSE TO THE PROMPT FROM THE SWITCH ENTRY ROUTINE:

'SWR = NNNNNN NEW ='

EACH TIME SWITCH SETTING ARE ENTERED, THE ENTIRE SWITCH REGISTER IMAGE MUST BE ENTERED. LEADING ZEROS ARE NOT REQUIRED. 'RUBOUT' AND 'CONTROL U' FUNCTIONS MAY BE USED TO CORRECT TYPING ERRORS DURING SWITCH ENTRY. ON PROCESSORS WITH HARDWARE SWITCH REGISTERS, THE 'SOFTWARE' SWITCH REGISTER MAY BE USED. IF THE PROGRAM FINDS ALL 16 SWITCHES IN THE 'UP' POSITION, ALL SWITCH REGISTER REFERENCES WILL BE TO THE 'SOFTWARE' REGISTER AND THE PROCEDURES DESCRIBED ABOVE MUST BE FOLLOWED.

SW<15>=1	HALT ON ERROR
SW<13>=1	INHIBIT ERROR PRINTOUTS
SW<12>=1	TYPE OUT THE ERROR HISTORY
SW<11>=1	DUMP OUT ALL RK11 REGISTERS
SW<10>=1	RING BELL ON ERROR
SW<09>=1	LOOP ON SPECIFIC ERROR
SW<08>=1	DUMP OUT TRANSFER DATA AND ERROR STATISTICS
SW<06>=1	SELECT BUS ADDRESS LIMITS FOR DATA TRANSFERS
SW<05>=1	HALT BEFORE DOING THE NEXT SET OF COMMANDS
SW<04>=1	DO NOT REWRITE THE DISKS ON 210 RETSART
SW<03>=1	TYPE OUT ELAPSED TIME AT ERROR
SW<02>=1	DROP DRIVE AFTER MAXIMUM ERRORS

SW<01>=1 TYPE SERIAL NUMBER OF ERRORING DRIVE
SW<00>=1 TYPE ONLY ELAPSED TIME IF SW<08> AND SW<03> = 1

6.1 SW<15>

THE PROGRAM HALTS ON ENCOUNTERING AN ERROR, AFTER TYPING OUT THE ERROR MESSAGE AND PERTINENT INFORMATION. PRESSING "CONTINUE" RESTORES NORMAL OPERATION OF THE PROGRAM.

6.2 SW<13>

THIS SWITCH INHIBITS ALL ERROR MESSAGES. NORMALLY USED WHEN LOOPING ON ERROR (SW 9).

6.3 SW<12>

IF THIS SWITCH IS SET WHEN AN ERROR OCCURS, INFORMATION ABOUT THE HISTORY OF THAT ERROR IS TYPED OUT.

THE FUNCTION THAT WAS BEING PERFORMED ON THE RK11 IS TYPED OUT. THE FUNCTION COULD BE EITHER A READ, WRITE, WRITE CHECK, READ CHECK. BESIDES THESE NORMAL FUNCTIONS, IT COULD BE A CONTROL RESET, DRIVE RESET OR POSITIONING OF THE HEADS (SEEKING). FOR THE FOUR FUNCTIONS THE INITIAL DISK ADDRESS, BUS ADDRESS AND WORD COUNT (2'S COMPLEMENT) ARE ALSO GIVEN. FOR DRIVE RESET AND POSITIONING THE DRIVE NUMBER OR WHICH THE OPERATION WAS BEING PERFORMED IS GIVEN.

SIMILAR INFORMATION IS TYPED OUT ABOUT THE FUNCTION THAT WAS DONE JUST BEFORE THE ONE GIVING THE ERROR.

6.4 SW<11>

IF THIS SWITCH IS SET WHEN AN ERROR OCCURS, THE CONTENTS OF ALL RK11 REGISTERS ARE TYPED OUT.

6.5 SW<09>

THIS SWITCH PROVIDES THE TIGHTEST POSSIBLE SCOPE LOOP. LOOPING IS DONE WHEN AN ERROR OCCURS. NOTE THAT THERE ARE TWO CLASSES OF ERRORS AND HENCE TWO CLASSES OF ERROR LOOPS, REFER TO SEC 8.0 FOR THE DIFFERENCE IN THE ERROR LOOPS PROVIDED BY SW 9.

6.6 SW<08>

WHEN THIS SWITCH IS SET, THE ERROR AND TRANSFER DATA STATISTICS WHICH HAVE BEEN COLLECTED UNTIL THAT TIME, ARE TYPED OUT.

THE TRANSFER DATA STATISTICS GIVE THE NUMBER OF WORDS WRITTEN AND READ ON EACH DRIVE THAT IS PRESENT. IT SHOULD BE NOTED THAT READ CHECK AND WRITE CHECK ARE CONSIDERED TO BE ESSENTIALLY READ OPERATIONS.

THE ERROR STATISTICS GIVE THE NUMBER OF ERRORS THAT HAVE OCCURRED

(IF ANY) IN THE FOLLOWING CATEGORIES, ON THE DRIVES THAT ARE PRESENT:

- CHECK SUM ERROR
- WRITE CHECK ERROR
- DATA COMPARISON ERROR
- HARD ERROR
- SEEK ERROR
- SEEK INCOMPLETE

ABORTS - WHEN AN ERROR OCCURS THE FUNCTION IS RETRIED TWICE. IF STILL THE ERROR PERSISTS THE FUNCTION IS ABORTED AND THE ABORT COUNT IS INCREMENTED FOR THAT DRIVE.

6.7 SW<06>

THIS SWITCH ENABLES THE USER TO SELECT THE LIMITS OF THE MEMORY BUS ADDRESSES BETWEEN WHICH THE DATA TRANSFERS WILL BE DONE. NORMALLY THE TRANSFERS ARE DONE BETWEEN THE LOWER LIMIT (BASEBA) AND THE HIGHER LIMIT (MAXBA). THESE TWO LIMITS ARE NORMALLY SELECTED BY THE PROGRAM AND USE THE MAXIMUM AVAILABLE MEMORY. IF THE USER WANTS TO DO DATA TRANSFERS BETWEEN SELECTED MEMORY ADDRESSES (EX: BETWEEN 12K AND 16K) THEN THIS SWITCH SHOULD BE SET AT THE STARTING OF THE PROGRAM. THE FOLLOWING MESSAGE APPEARS:

TYPE OCTAL BUS ADDRESS FOR DATA XFER, BETWEEN XXXXXX AND YYYYYY

- LO LIMIT?
- HI LIMIT?

IN RESPONSE THE USER SHOULD TYPE IN ANY TWO BUS ADDRESSES (OCTAL) BETWEEN XXXXXX AND YYYYYY. IF THE USER TYPES IN ANYTHING OUT OF THE X AND Y RANGE THE QUESTION IS ASKED AGAIN.

THIS SWITCH COULD BE QUITE USEFUL IN DETERMINING WHETHER THE PROBLEM IS WITHIN THE RK11 OR OUTSIDE (IN MEMORY). NORMALLY, IF THE PROBLEM IS WITHIN THE RK11, ERRORS WILL KEEP ON OCCURRING REGARDLESS OF WHERE IN THE MEMORY DATA TRANSFERS ARE TAKING PLACE. ON THE OTHER HAND IF THE PROBLEM IS MEMORY RELATED, THE ERRORS WILL TEND TO DISAPPEAR FOR DATA TRANSFERS TO CERTAIN MEMORY BLOCKS AND WOULD REAPPEAR FOR OTHER ONES.

6.8 SW<05>

THIS SWITCH PROVIDES THE USER A CAPABILITY TO HALT THE PROGRAM AT A KNOWN POINT. THE HALT IS DONE AFTER THE CURRENT SET OF EIGHT COMMANDS IN THE QUEUE HAVE BEEN EXECUTED. THE "HALT" IS LOCATED AT THE BEGINNING OF THE 'GENBRQ' ROUTINE, JUST BEFORE A SET OF 8 NEW COMMANDS IS GENERATED. AFTER THE PROGRAM HALTS, THE EXECUTION CAN BE RESUMED BY PRESSING CONTINUE, OR THE PROGRAM CAN BE STARTED BACK AT 200 OR RESTARTED AT 210.

6.9 SW<04>

THIS SWITCH PROVIDES THE USER WITH AN ABILITY TO SKIP THE TIME CONSUMING REWRITE OF ALL THE DISKS WHEN THE PROGRAM IS RESTARTED AT 210. THIS SWITCH CAN BE USED ONLY WHEN RESTARTING THE PROGRAM AT 210 WITH SW 4 SET. ON RESTARTING THE PROGRAM AT 210, THE INITIAL BOUNDARY CONDITION TESTS (YST1-YST7) ARE SKIPPED. IF SWITCH 4 IS SET, THE REWRITE OF ALL THE DISKS (WHICH WOULD HAVE BEEN NORMALLY DONE) IS ALSO SKIPPED. THE USER IS CAUTIONED TO USE THIS SWITCH CAREFULLY. THE DISKS SHOULD HAVE BEEN WRITTEN WITH RANDOM PATTERNS AT LEAST ONCE BEFORE RESTARTING THE PROGRAM AT 210. IT SHOULD BE NOTED THAT TESTS 1-7 WRITE ON CYLINDERS 0,1. ON RESTART, THE STATISTICS COLLECTED SO FAR ARE SAVED.

6.10 SW<03>

THIS SWITCH ALLOWS THE TYPEOUT OF THE ELAPSED TIME AT WHICH ERROR OCCURRED. THE TIMING STARTS AT THE BEGINNING OF THE EXERCISER PROGRAM. THIS SWITCH SHOULD NOT BE SET IF KWILL LINE CLOCK IS NOT AVAILABLE ON THE SYSTEM.

6.11 SW<02>

THIS SWITCH CAUSES DRIVES WHICH EXCEED A MAXIMUM NUMBER OF ERRORS TO BE DEASSIGNED BY THE PROGRAM. THE PROGRAM CONTINUES TESTING OTHER DRIVES WHICH HAVE NOT ACCUMULATED THE REQUIRED NUMBER OF ERRORS.

6.12 SW<01>

IF THIS SWITCH IS SET, THE PROGRAM ALLOWS A SERIAL NUMBER TO BE SPECIFIED FOR EACH DRIVE TESTED. THE SERIAL NUMBER IS TYPED WITH EACH ERROR MESSAGE FOR THAT PARTICULAR DRIVE.

6.13 SW<00>

IF SW<08> AND SW<03> ARE SET, SETTING THIS SWITCH TYPES OUT THE ELAPSED TIME FROM THE START OF THE PROGRAM.

7.0 EXERCISER PROGRAM

THE EXERCISER PROGRAM ATTEMPTS TO SIMULATE A DISK OPERATING SYSTEM ENVIRONMENT BY DOING RANDOM EVENTS (FUNCTIONS) USING RANDOMLY SELECTED PARAMETERS (DISK ADDRESS, BUS ADDRESS, WORD COUNT ETC). AN ATTEMPT IS MADE TO DETECT INTER-ACTION PROBLEMS, OVERLAPPING SEEK PROBLEMS, ETC. FOR EXAMPLE, OVER 500 MILLION BITS ARE TRANSFERRED PER HOUR ON A TYPICAL RK11/RK05 SYSTEM (BASED ON 2 DRIVES, PDP11/50, 28K SYSTEM).

EIGHT JOBS OR COMMANDS ARE GENERATED AT A TIME (GENBRQ) AND PUT IN A QUEUE TO BE PROCESSED. THE ALGORITHM WORKS AS FOLLOWS. COMMANDS IN THE QUEUE ARE PREPOSITIONED (HEADS) BY PERFORMING OVERLAPPING SEEKS. WHILE SOME OF THE DRIVES ARE BEING POSITIONED, THE LAST AVAILABLE (AND EXECUTABLE) COMMAND IS PERFORMED. THUS WHILE SOME DRIVES ARE BUSY POSITIONING THEIR HEADS, SOME DRIVE IS PERFORMING A FUNCTION (DATA TRANSFER, ETC). AS SOON AS THE CONTROLLER IS FREE, A CHECK IS MADE TO SEE IF THERE IS ANY DRIVE WHICH HAS ALREADY POSITIONED ITS HEAD. IF ONE IS FOUND THE COMMAND IS EXECUTED ON THAT DRIVE AND THE CONTROLLER AGAIN BECOMES BUSY. IF NO POSITIONED COMMAND IS FOUND, A CHECK IS MADE TO SEE IF THERE IS A COMMAND THAT IS TO BE POSITIONED. IF YES, IT IS POSITIONED AND THE LAST AVAILABLE COMMAND IS EXECUTED. IF IT IS FOUND THAT NO DRIVE NEEDS TO BE POSITIONED (THIS COULD HAPPEN IF THERE IS ONLY ONE COMMAND LEFT IN THE QUEUE OR THE REMAINING COMMANDS IN THE QUEUE ARE TO BE PERFORMED ON THE SAME DRIVE), THEN THE COMMANDS IS/ ARE EXECUTED.

THE ABOVE ALGORITHM HELPS SIMULATE A REAL ENVIRONMENT, AT THE SAME TIME MAXIMISING THE RATE OF DATA TRANSFERS. THE EXERCISER PROGRAM GIVES AN ELABORATE ERROR DETECTION CAPABILITY. THE STATE OF THE PROGRAM IS CONTINUOUSLY TRACKED BY SOFTWARE KEYS, FLAGS, ETC. THESE FLAGS AND KEYS HAVE BEEN EXPLAINED IN DETAIL AT THE BEGINNING OF THE LISTINGS, WHERE THEY ARE DEFINED. ON DUAL DENSITY DRIVES, ONLY ONE LOGICAL DRIVE IS SELECTED DURING EACH QUEUE BUILD. THIS INSURES THAT OVERLAPPED SEEKS WILL NOT INTERFERE WITH THE HEAD POSITIONING LOGIC.

THE PARAMETERS USED FOR DOING THE COMMANDS ARE SELECTED RANDOMLY USING A RANDOM GENERATOR. THE FUNCTION TO BE PERFORMED IS SELECTED RANDOMLY FROM ONE OF THE FOUR: WRITE, READ, WRITE CHECK, OR READ CHECK. THE DRIVE NUMBER IS SELECTED FROM THE AVAILABLE DRIVES. THE DISK ADDRESS IS SELECTED OVER THE ENTIRE RANGE AND THE WORD COUNT AND BUS ADDRESS ARE SELECTED RANDOMLY IN SUCH A WAY THAT A NON-EXISTENT MEMORY ERROR OR OVERRUN CONDITION DOES NOT OCCUR.

RANDOM DATA BLOCKS ARE WRITTEN ON THE DISK. THE FIRST WORD OF EACH SECTOR BLOCK IS A NUMBER (2'S COMPLEMENT) INDICATING THE TOTAL NUMBER OF WORDS WRITTEN IN THAT SECTOR. THE REST OF THE WORDS IN THE BLOCK ARE GENERATED USING THE DISK ADDRESS (OF THAT SECTOR) AS THE RANDOM SEED NUMBER.

8.0 LOOPING CAPABILITIES:

SWITCH 9 GIVES LOOPING CAPABILITIES, ON ERROR. THERE ARE TWO CLASSES OF ERRORS:

- A. ERRORS OCCURING IN THE NON-EXERCISER PART OF THE PROGRAM (ERROR NUMBERS UNDER 100 IN THE ERROR ITEMS TABLE)
- B. ERRORS OCCURING IN THE EXERCISER PART OF THE PROGRAM (ERROR NUMBERS STARTING FROM 100 AND UP IN THE ERROR ITEMS TABLE)
- C. NON-EXERCISER SCOPE LOOPS: IN THIS CASE, THE PROGRAM LOOPS ON A SPECIFIC ERROR GIVING A NARROW SCOPE LOOP. THIS SCOPE LOOP IS SIMILIAR TO THE ONE PROVIDED IN THE RK11 BASIC LOGIC TEST AND DYNAMIC TEST, WHICH THE USER MIGHT BE FAMILIAR WITH.
- D. EXERCISER SCOPE LOOPS: WHEN AN ERROR OCCURS (AFTER TYPING OUT THE ERROR MESSAGE) CONTROL IS TRANSFERRED TO THE BEGINNING OF THE COMMAND-QUEUE. THE COMMANDS FROM THE FIRST COMMAND ONWARDS, ARE EXECUTED AGAIN TILL THE POINT OF ERROR. THIS LOOPING PROVIDES THE USER WITH A CAPABILITY TO RECREATE A SET OF EVENTS THAT LED TO THE ERROR.

9.0 TRANSFER DATA LOGGING

IN THIS PROGRAM, WHENEVER A DATA TRANSFER TAKES PLACE IT IS LOGGED WHETHER IT IS READ, READ CHECK, WRITE OR WRITE CHECK. SEPERATE COUNTS ARE KEPT FOR DATA TRANSFERS TAKING PLACE ON EACH DRIVE IN THE SYSTEM. AT ANY GIVEN TIME THE USER CAN GET THESE TRANSFER STATISTICS BY SETTING SWITCH 8 TO 1 (SEE SEC.6.6). THIS IS HELPFUL FOR EVALUATING A SYSTEM.

10.0 ERROR LOGGING

THROUGHOUT THE EXERCISER PROGRAM, WHEN AN ERROR OCCURS IT IS LOGGED. THE FOLLOWING CLASSES OF ERRORS ARE LOGGED FOR EACH DRIVE IN THE SYSTEM:

- CHECK SUM ERROR
- WRITE CHECK ERROR
- DATA COMPARISON ERROR
- HARD ERRORS
- SEEK ERROR
- SEEK INCOMPLETE ERROR
- ABORTS

THE ERROR STATISTICS CAN BE OBTAINED BY PUTTING SWITCH 8 TO 1. THE ERROR STATISTICS CAN BE USED IN CONJUNCTION WITH DATA TRANSFER STATISTICS TO GIVE AN IDEA OF THE SYSTEM PERFORMANCE (NUMBER OF WORDS TRANSFERRED PER ERROR, CSE FREQUENCY, RECOVERABLE VERSUS NON-RECOVERABLE ERRORS ETC.).

11.0 ERROR REPORTING AND RECOVERY

WHENEVER AN ERROR OCCURS IT IS REPORTED ALONG WITH RELEVANT INFORMATION. THE RK11 REGISTERS REPORTED IN THE ERROR MESSAGES REPRESENT THE CONTENTS AT THE TIME OF ERROR. EACH ERROR MESSAGE CONTAINS A 'PC' NUMBER, THIS IS THE PC LOCATION IN THE PROGRAM WHERE THE ERROR CALL IS LOCATED. THE USER IS ADVISED TO REFERENCE THIS LOCATION IN THE LISTINGS, IN CASE MORE INFORMATION ABOUT THE ERROR IS DESIRED.

SOME (SYSTEM) ERRORS REFER TO SOFTWARE FLAGS AND KEYS WHICH ARE USED TO MONITOR THE ONGOING ACTIVITIES ON THE SYSTEM. THESE FLAGS ARE EXPLAINED AT THE BEGINING OF THE LISTINGS AND SOULD BE REFERRED TO, IF THE NEED ARISES.

IF A FATAL ERROR CONDITION IS DETECTED (LIKE DRIVE UNSAFE, WRITE PROTECT SET, DRIVE READY CLEAR, ETC.) THE DRIVE IS REMOVED FROM THE DRIVE SELECTION TABLE AND DROPPED FROM FURTHER TESTING. A MESSAGE IS GIVEN INDICATING DROPPING OF THAT DRIVE. FOR FURTHER INFORMATION, REFER TO THE 'CHKDRV' AND 'DSELCT' ROUTINES IN THE LISTINGS.

RECOVERABLE ERRORS ARE RETRIED THREE TIMES. IF THE ERROR CONDITION FAILS TO CORRECT OR A IF A DIFFERENT ERROR OCCURS THE FUNCTION IS ABORTED. MESSAGES ARE PRINTED ONLY ONCE FOR EACH ERROR. AFTER EIGHT ABORTS ARE RECORDED ON A DRIVE THE DRIVE IS DROPPED. DUAL DENSITY DRIVES ARE ALWAYS DROPPED IN PAIRS.

12.0 SUBROUTINES AND HANDLERS

THERE ARE TWO WAYS IN WHICH MOST OF THE SUBROUTINES USED IN THIS PROGRAM ARE CALLED:

1. THROUGH THE NORMAL JSR CALL

JSR REG, SUBROUTINE

2. THROUGH THE 'TRAP' INSTRUCTION. THE TRAP INSTRUCTION WITH ITS LOWER BYTE ENCODED SERVES AS A CALL FOR SOME ROUTINES. WHEN THE 'TRAP' IS EXECUTED A TRAP OCCURS TO THE TRAP VECTOR AND THE TRAP DECODER IS ENTERED. THE TRAP DECODER (\$TRAP) WILL PICK UP THE LOWER BYTE OF THE 'TRAP' INSTRUCTION AND USE IT TO INDEX THROUGH THE TRAP TABLE (\$TRAPAD) FOR THE STARTING ADDRESS OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL GO TO THE DESIRED ROUTINE.

3. \$SCOPE - THE SCOPE HANDLER

THE SCOPE HANDLER IS ENTERED THROUGH THE EXECUTION OF THE 'IOT' INSTRUCTION. IT KEEPS TRACK OF VARIOUS POINTERS, FLAGS AND DECIDES IF LOOPING IS TO BE DONE ON ERROR (SW 9). IT SHOULD BE NOTED THAT THIS HANDLER IS USED MOSTLY IN THE NON-EXERCISER PART OF THE PROGRAM.

4. \$ERROR - ERROR HANDLER ROUTINE

THE ERROR HANDLER IS ENTERED THROUGH THE EXECUTION OF THE 'EMT' INSTRUCTION. THE LOWER BYTE OF THE EMT INSTRUCTION IS ENCODED TO GIVE AN IDENTIFIER TO THE ERROR CALL. THUS 'ERROR 1' IS 104001, ETC. THE ERROR ROUTINE DECIDES IF ANY ACTION IS TO BE TAKEN DEPENDING ON THE SWITCH SETTING (LIKE, HALT ON ERROR, INHIBIT ERROR TYPEOUT, ETC.).

MOST OF THE SUBROUTINES RESIDE IN THE LATTER PART OF THE PROGRAM. THE USER CAN REFER TO THEM THROUGH THE CROSS REFERENCE TABLE AT THE END OF THE LISTINGS OR TABLE OF CONTENTS AT THE BEGINING.

587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620

```
.TITLE MD-11-DZRKHG, RK11-RK05 PERFORMANCE EXERCISEP
.*COPYRIGHT (C) 1973,1977
.*DIGITAL EQUIPMENT CORP.
.*MAYNARD, MASS. 01754
.*
.*PROGRAM BY JIM KAPADIA
.*
.*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
.*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
.*
.*REVISED BY GEORGE GALLANT, TOM SAWYER - MARCH 1976
.*REVISED BY CHUCK HESS - AUGUST 1976
.SBTTL OPERATIONAL SWITCH SETTINGS
.*
.*          SWITCH          USE
.*          -----          -----
.*          15          HALT ON ERROR
.*          14          LOOP ON TEST
.*          12          TYPE OUT ERROR HISTORY
.*          10          BELL ON ERROR
.*          9           LOOP ON ERROR
.*          8           TYPE OUT ERROR AND TRANSFER DATA STATISTICS
.*          6           SELECT BUS ADDRESS LIMITS FOR DISK DATA TRANSFERS
.*          5           HALT BEFORE DOING NEXT SET OF COMMANDS(GENBRQ)
.*          4           DO NOT REWRITE THE DISKS ON RESTART AT ZIC
.*          3           TYPE OUT ELAPSED TIME AT ERROR
.*          2           DROP DRIVE AFTER MAXM ERORS ON THIS DRIVE
.*          1           TYPE SERIAL NUMBER OF ERRORING DRIVE
.*          0           IF SW8=1, ONLY TYPE ELAPSED TIME
.*          11          DUMP OUT ALL RK11 REGISTERS ON ERROR
.*
.*          YOU ARE ADVISED TO READ THE DOCUMENT FOR THIS PROGRAM.
```

621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676

001100

000011
000012
000015
000200
177776

177774
177772
177570
177570

000000
000001
000002
000003
000004
000005
000006
000007
000006
000007

000000
000040
000100
000140
000200
000240
000300
000340

100000
040000
020000
010000
004000
002000
001000
000400
000200
000100
000040
000020

.SBTTL BASIC DEFINITIONS

;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***

STACK= 1100
 .EQUIV EMT,ERROR ;; BASIC DEFINITION OF ERROR CALL
 .EQUIV IOT,SCOPE ;; BASIC DEFINITION OF SCOPE CALL

;*MISCELLANEOUS DEFINITIONS

HT= 11 ;; CODE FOR HORIZONTAL TAB
 LF= 12 ;; CODE FOR LINE FEED
 CR= 15 ;; CODE FOR CARRIAGE RETURN
 CRLF= 200 ;; CODE FOR CARRIAGE RETURN-LINE FEED
 PS= 177776 ;; PROCESSOR STATUS WORD
 .EQUIV PS,PSW
 STKLMT= 177774 ;; STACK LIMIT REGISTER
 PIRQ= 177772 ;; PROGRAM INTERRUPT REQUEST REGISTER
 DSWR= 177570 ;; HARDWARE SWITCH REGISTER
 DDISP= 177570 ;; HARDWARE DISPLAY REGISTER

;*GENERAL PURPOSE REGISTER DEFINITIONS

R0= %0 ;; GENERAL REGISTER
 R1= %1 ;; GENERAL REGISTER
 R2= %2 ;; GENERAL REGISTER
 R3= %3 ;; GENERAL REGISTER
 R4= %4 ;; GENERAL REGISTER
 R5= %5 ;; GENERAL REGISTER
 R6= %6 ;; GENERAL REGISTER
 R7= %7 ;; GENERAL REGISTER
 SP= %6 ;; STACK POINTER
 PC= %7 ;; PROGRAM COUNTER

;*PRIORITY LEVEL DEFINITIONS

PR0= 0 ;; PRIORITY LEVEL 0
 PR1= 40 ;; PRIORITY LEVEL 1
 PR2= 100 ;; PRIORITY LEVEL 2
 PR3= 140 ;; PRIORITY LEVEL 3
 PR4= 200 ;; PRIORITY LEVEL 4
 PR5= 240 ;; PRIORITY LEVEL 5
 PR6= 300 ;; PRIORITY LEVEL 6
 PR7= 340 ;; PRIORITY LEVEL 7

;*SWITCH REGISTER SWITCH DEFINITIONS

SW15= 100000
 SW14= 40000
 SW13= 20000
 SW12= 10000
 SW11= 4000
 SW10= 2000
 SW09= 1000
 SW08= 400
 SW07= 200
 SW06= 100
 SW05= 40
 SW04= 20

677 000010
 678 000004
 679 000002
 680 000001
 681
 682
 683
 684
 685
 686
 687
 688
 689
 690
 691
 692
 693 100000
 694 040000
 695 020000
 696 010000
 697 004000
 698 002000
 699 001000
 700 000400
 701 000200
 702 000100
 703 000040
 704 000020
 705 000010
 706 000004
 707 000002
 708 000001
 709
 710
 711
 712
 713
 714
 715
 716
 717
 718
 719
 720
 721 000004
 722 000010
 723 000014
 724 000014
 725 000014
 726 000020
 727 000024
 728 000030
 729 000034
 730 000060
 731 000064
 732 000240

SW03= 10
 SW02= 4
 SW01= 2
 SW00= 1
 .EQUIV SW09,SW9
 .EQUIV SW08,SW8
 .EQUIV SW07,SW7
 .EQUIV SW06,SW6
 .EQUIV SW05,SW5
 .EQUIV SW04,SW4
 .EQUIV SW03,SW3
 .EQUIV SW02,SW2
 .EQUIV SW01,SW1
 .EQUIV SW00,SW0

.*DATA BIT DEFINITIONS (BIT00 TO BIT15)

BIT15= 100000
 BIT14= 40000
 BIT13= 20000
 BIT12= 10000
 BIT11= 4000
 BIT10= 2000
 BIT09= 1000
 BIT08= 400
 BIT07= 200
 BIT06= 100
 BIT05= 40
 BIT04= 20
 BIT03= 10
 BIT02= 4
 BIT01= 2
 BIT00= 1
 .EQUIV BIT09,BIT9
 .EQUIV BIT08,BIT8
 .EQUIV BIT07,BIT7
 .EQUIV BIT06,BIT6
 .EQUIV BIT05,BIT5
 .EQUIV BIT04,BIT4
 .EQUIV BIT03,BIT3
 .EQUIV BIT02,BIT2
 .EQUIV BIT01,BIT1
 .EQUIV BIT00,BIT0

.*BASIC "CPU" TRAP VECTOR ADDRESSES

ERRVEC= 4 ;: TIME OUT AND OTHER ERRORS
 RESVEC= 10 ;: RESERVED AND ILLEGAL INSTRUCTIONS
 TBITVEC= 14 ;: "T" BIT
 TRTVEC= 14 ;: TRACE TRAP
 BPTVEC= 14 ;: BREAKPOINT TRAP (BPT)
 IOTVEC= 20 ;: INPUT/OUTPUT TRAP (IOT) **SCOPE**
 PWRVEC= 24 ;: POWER FAIL
 EMTVEC= 30 ;: EMULATOR TRAP (EMT) **ERROR**
 TRAPVEC= 34 ;: "TRAP" TRAP
 TKVEC= 60 ;: TTY KEYBOARD VECTOR
 TPVEC= 64 ;: TTY PRINTER VECTOR
 PIRQVEC= 240 ;: PROGRAM INTERRUPT REQUEST VECTOR

```

733          000100          KWLVEC=100          ;KWILL CLOCK VECTOR
734
735          .EQUIV BIT15,ERR
736          .EQUIV BIT14,HE
737          .EQUIV BIT13,SCP
738
739
740          .EQUIV BIT12,DPL
741          .EQUIV BIT10,DRU
742          .EQUIV BIT09,SIN
743          .EQUIV BIT07,DRY
744          .EQUIV BIT06,RWS
745          .EQUIV BIT05,WPS
746
747
748
749          .EQUIV BIT12,SKE
750          .EQUIV BIT01,CSE
751          .EQUIV BIT00,WCE
752
753          .SBTTL TRAP CATCHER
754
755          000000          .=0
756          ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
757          ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
758          ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
759          000174          000174          .=174
760          000174          000000          DISPREG: .WORD 0          ;; SOFTWARE DISPLAY REGISTER
761          000176          000000          SWREG: .WORD 0          ;; SOFTWARE SWITCH REGISTER
762          .SBTTL STARTING ADDRESS(ES)
763          000200          000137          003376          JMP @#START ;; JUMP TO STARTING ADDRESS OF PROGRAM
764
765          000210          000210          .=210          ;RESTART ADDRESS, IF RESTART IS
766          000210          105237          001253          INCB FRSTRT          ;DONE AT 210, THE BOUNDARY CONDITION
767          000214          000137          003376          JMP @#START          ;TESTS (TST1-7) ARE SKIPPED. IF SW 4
768          ;IS SET THEN THE DISKS ARE NOT REWRITTEN
769          ;(WRDSK) WITH RANDOM PATTERNS. NORMALLY
770          ;ALL THE DISKS PRESENT ARE COMPLETELY
771          ;WRITTEN WITH RANDOM PATTERNS, AT THE
772          ;BEGINING OF THE
773          ;EXERCISER PART OF THE PROGRAM.
774
775          .SBTTL ACT11 HOOKS
776
777          ;*****
778          ;HOOKS REQUIRED BY ACT11
779          000220          000220          $SVPC=.          ;SAVE PC
780          000046          000046          .=46
781          000046          022750          SENDAD          ;;1)SET LOC.46 TO ADDRESS OF SENDAD IN .SECP
782          000052          000052          .=52
783          000052          000000          .WORD 0          ;;2)SET LOC.52 TO ZERO
784          000220          000220          .=$SVPC          ;; RESTORE PC
785
786          ;KT11 REGISTER DEFINITIONS
787          .SBTTL MEMORY MANAGEMENT DEFINITIONS
788

```

```

789          ;*KT11 VECTOR ADDRESS
790
791          000250          MMVEC= 250
792
793          ;*KT11 STATUS REGISTER ADDRESSES
794
795          177572          SR0= 177572
796          177574          SR1= 177574
797          177576          SR2= 177576
798          172516          SR3= 172516
799
800          ;*KERNEL "I" PAGE DESCRIPTOR REGISTERS
801
802          172300          KIPDR0= 172300
803          172302          KIPDR1= 172302
804          172304          KIPDR2= 172304
805          172306          KIPDR3= 172306
806          172310          KIPDR4= 172310
807          172312          KIPDR5= 172312
808          172314          KIPDR6= 172314
809          172316          KIPDR7= 172316
810
811          ;*KERNEL "D" PAGE DESCRIPTOR REGISTERS
812
813          172320          KDPDR0= 172320
814          172322          KDPDR1= 172322
815          172324          KDPDR2= 172324
816          172326          KDPDR3= 172326
817          172330          KDPDR4= 172330
818          172332          KDPDR5= 172332
819          172334          KDPDR6= 172334
820          172336          KDPDR7= 172336
821
822          ;*KERNEL "I" PAGE ADDRESS REGISTERS
823
824          172340          KIPAR0= 172340
825          172342          KIPAR1= 172342
826          172344          KIPAR2= 172344
827          172346          KIPAR3= 172346
828          172350          KIPAR4= 172350
829          172352          KIPAR5= 172352
830          172354          KIPAR6= 172354
831          172356          KIPAR7= 172356
832
833          ;*KERNEL "D" PAGE ADDRESS REGISTERS
834
835          172360          KDPAR0= 172360
836          172362          KDPAR1= 172362
837          172364          KDPAR2= 172364
838          172366          KDPAR3= 172366
839          172370          KDPAR4= 172370
840          172372          KDPAR5= 172372
841          172374          KDPAR6= 172374
842          172376          KDPAR7= 172376
843
844

```

Address	Tag Name	Value	Format	Description
845	.SBTTL COMMON TAGS			
847	*****			
848	*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS			
849	*USED IN THE PROGRAM.			
850				
851	001100	.=1100		START OF COMMON TAGS
852	001100	000000	SCMTAG: .WORD	CONTAINS PASS COUNT
853	001100	000000	SPASS: .WORD	CONTAINS THE TEST NUMBER
854	001102	000	STSTNM: .BYTE	CONTAINS ERROR FLAG
855	001103	000	SERFLG: .BYTE	CONTAINS SUBTEST ITERATION COUNT
856	001104	000000	SICNT: .WORD	CONTAINS SCOPE LOOP ADDRESS
857	001106	000000	SLPADR: .WORD	CONTAINS SCOPE RETURN FOR ERRORS
858	001110	000000	SLPERR: .WORD	CONTAINS TOTAL ERRORS DETECTED
859	001112	000000	SERTTL: .WORD	CONTAINS ITEM CONTROL BYTE
860	001114	000	SITEMB: .BYTE	CONTAINS MAX. ERRORS PER TEST
861	001115	001	SERMAX: .BYTE	CONTAINS PC OF LAST ERROR INSTRUCTION
862	001116	000000	SERRPC: .WORD	CONTAINS ADDRESS OF 'GOOD' DATA
863	001120	000000	SGDADR: .WORD	CONTAINS ADDRESS OF 'BAD' DATA
864	001122	000000	SBADADR: .WORD	CONTAINS 'GOOD' DATA
865	001124	000000	SGDDAT: .WORD	CONTAINS 'BAD' DATA
866	001126	000000	SBDDAT: .WORD	RESERVED--NOT TO BE USED
867	001130	000000	.WORD	
868	001132	000000	.WORD	
869	001134	000	SAUTOB: .BYTE	AUTOMATIC MODE INDICATOR
870	001135	000	SINTAG: .BYTE	INTERRUPT MODE INDICATOR
871	001136	000000	.WORD	
872	001140	177570	SWR: .WORD	ADDRESS OF SWITCH REGISTER
873	001142	177570	DISPLAY: .WORD	ADDRESS OF DISPLAY REGISTER
874	001144	177560	STKS: .WORD	TTY KBD STATUS
875	001146	177562	STKB: .WORD	TTY KBD BUFFER
876	001150	177564	STPS: .WORD	TTY PRINTER STATUS REG. ADDRESS
877	001152	177566	STPB: .WORD	TTY PRINTER BUFFER REG. ADDRESS
878	001154	000	SNULL: .BYTE	CONTAINS NULL CHARACTER FOR FILLS
879	001155	002	SFILLS: .BYTE	CONTAINS # OF FILLER CHARACTERS REQUIRED
880	001156	012	SFILLC: .BYTE	INSERT FILL CHARS. AFTER A "LINE FEED"
881	001157	000	STPFLG: .BYTE	"TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
882	001160	000000	SREGAD: .WORD	CONTAINS THE ADDRESS FROM WHICH (\$REG0) WAS OBTAINED
883				
884	001162	000000	SREG0: .WORD	CONTAINS ((\$REGAD)+0)
885	001164	000000	SREG1: .WORD	CONTAINS ((\$REGAD)+2)
886	001166	000000	SREG2: .WORD	CONTAINS ((\$REGAD)+4)
887	001170	000000	SREG3: .WORD	CONTAINS ((\$REGAD)+6)
888	001172	000000	SREG4: .WORD	CONTAINS ((\$REGAD)+10)
889	001174	000000	SREG5: .WORD	CONTAINS ((\$REGAD)+12)
890	001176	000000	SREG6: .WORD	CONTAINS ((\$REGAD)+14)
891	001200	000000	SREG7: .WORD	CONTAINS ((\$REGAD)+16)
892	001202	000000	SREG10: .WORD	CONTAINS ((\$REGAD)+20)
893	001204	000000	SESCAPE: 0	ESCAPE ON ERROR ADDRESS
894	001206	177607	SBELL: .ASCIZ	CODE FOR BELL
895	001212	077	SQUES: .ASCII	QUESTION MARK
896	001213	015	SCRFLF: .ASCII	CARRIAGE RETURN
897	001214	000012	SLF: .ASCIZ	LINE FEED
898				*****
899	001216	177400	RKDS: .WORD	
900	001220	177402	RKER: .WORD	

901	001222	177404	RKCS:	.WORD	177404	
902	001224	177406	RKWC:	.WORD	177406	
903	001226	177410	RKBA:	.WORD	177410	
904	001230	177412	RKDA:	.WORD	177412	
905	001232	177416	RKDB:	.WORD	177416	
906	001234	177546	KWLS:	.WORD	177546	;STATUS REGISTER FOR KW11L
907						
908	001236	000372	PCNTR:	.WORD	250.	
909						
910	001240	000220	RKVEC:	.WORD	220	;NORMAL RK11 INTERRUPT VECTOR ADDRESS
911	001242	000222	RKSTAT:	.WORD	222	;PSW TO BE USED ON INTERRUPT
912						
913	001244	000240	PPRLVL:	.WORD	240	;PROGRAM PRIORITY LEVEL=5. PRIORITY LEVEL
914						;AT WHICH THE PROGRAM OPERATES CAN BE CHANGED
915						;BY ALTERING THIS LOCATION.
916	001246	000340	KWPLVL:	.WORD	340	;PRIORITY LEVEL OF THE KW11L CLOCK SERVICE
917						;ROUTINE.
918						
919	001250	177777	SRDRV:	.WORD	177777	; 'SRDRV' CONTAINS THE DRIVE NO WHOOSE SERIAL
920						;NO IS TO BE TYPED OUT WHEN AN ERROR OCCURS,
921						;IF SW 1 IS SET. WHEN (SRDRV)=-1 SERIAL NO
922						;IS NOT TYPED OUT, BECAUSE THE ERROR WAS NOT
923						;POSITIVELY ATTRIBUTABLE TO A SPECIFIC DRIVE.
924						
925						
926	001252	000	FTITLE:	.BYTE	0	
927	001253	000	FRSTR:	.BYTE	0	;FLAG FOR RESTART AT 210

928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983

001254 000010

001264 000000

001266 000010

001306 000010

: THIS TABLE CONTAINS (IN ASCENDING ORDER) THE DRIVE NUMBERS THAT ARE
: PRESENT. THUS IF 3 DRIVES 0,1,2 ARE PRESENT: PDR WILL CONTAIN PDR1 WILL
: CONTAIN 1 AND PDR2 WILL CONTAIN 2. THE UPPER BIT OF EACH 'PDR' BYTE IS SET IF THE
: CORRESPONDING DRIVE IS AN 'F' DRIVE.

PDR. .BLKB 10

DRVPRS: .WORD 0 ;CONTAINS TOTAL NUMBER OF DRIVES PRESENT

: THE FOLLOWING LOCATIONS CONTAIN SERIAL NUMBERS CORRESPONDING TO EACH
: DRIVE. THE SERIAL NUMBERS ARE KEYED IN BY THE USER, WHEN THE PROGRAM
: IS STARTED WITH SWITCH 1 SET TO 1. THIS FEATURE IS NORMALLY USED IN
: PRODUCTION ENVIRONMENT.

SRNO: .BLKW 10 ;SERIAL NO'S FOR DRIVES 0-7

: THE FOLLOWING 8 KEYS ARE FOR THE 8 COMMANDS IN THE QUEUE, TO BE
: EXECUTED ON DIFFERENT DRIVES. EACH KEY IS ASSOCIATED WITH AN EXECUTABLE
: COMMAND ON THE RK11. VARIOUS BITS OF THE KEY DESCRIBE A COMMAND
: AS INDICATED BELOW

- : <0-2> DRIVE NUMBER ON WHICH THE COMMAND IS TO BE EXECUTED
- : <4> INDICATES THAT THE HEADS ARE BEING/OR HAVE BEEN POSITIONED ON THE DRIVE
- : <5> INDICATES A 'WPT CHK' SHOULD BE DONE FOLLOWING THE 'WRITE'
- : <6> INDICATES A WRITE CHECK FUNCTION HAS BEEN INITIATED
- : <7> INDICATES THAT A FUNCTION IS IN PROGRESS (IT IS NOT SET WHEN POSITIONING IS BEING DONE ON A DRIVE)
- : <8-10> INDICATES THE POSITION OF THIS KEY IN THE 8-KEY TABLE (POSITIONS BEING 0,1,2,3,4,5,6,7)
- : <11> INDICATES THAT FUNCTION CORRESPONDING TO THIS KEY HAS BEEN ABORTED
- : <12> INDICATES HIGH PRIORITY FOR THE COMMAND (NORMALLY SET AFTER AN ERROR OCCURED ON THE COMMAND)
- : <14> INDICATES THAT THE COMMAND CORRESPONDING TO THIS KEY HAS BEEN ABORTED BECAUSE THE DRIVE WAS DESELECTED (DSELECT)
- : <15> INDICATES THAT THE COMMAND HAS BEEN COMPLETED (ALSO SET WHEN COMMAND IS ABORTED AFTER RETRIES)

KEY: .BLKW 10 ;KEY FOR THE COMMANDS IN QUEUE

: THE PARAMETERS TO BE USED FOR EACH COMMAND IN THE QUEUE
: ARE STORED IN A TABLE STARTING AT 'CMND'. BITS <8-10>
: OF THE COMMAND KEYS (KEY, KEY2, ---KEY8) ARE USED TO POINT
: TO THE RIGHT SET OF PARAMETERS.

- : WORD 1 CONTAINS RKDA TO BE USED
- : WORD 2 CONTAINS RKCS (FUNCTION BITS ONLY)
- : WORD 3 CONTAINS RKWC (WORD COUNT 2'S COMP)
- : WORD 4 CONTAINS RKBA

```

984 001326 000040      CMND:  .BLKW  40      ;STORAGE TABLE
985
986                   ;THESE ARE BUSY FLAGS FOR THE DRIVES, IF A DRIVE IS BUSY PERFORMING
987                   ;ANY FUNCTION (INCLUDING POSITIONING) THEN BIT 7 OF THE FLAG FOR THAT
988                   ;DRIVE IS SET. BITS 0-3 CONTAIN THE OFFSET TO KEY # WHICH MADE THE DRIVE
989                   ;BUSY. EX: DRIVE #3 WAS MADE TO DO A WRITE BY COMMAND
990                   ;KEYS, HENCE 'BUSY3' WILL CONTAIN 210. NOTE THAT 10 IS THE
991                   ;OFFSET FOR KEYS (TAKING KEY AS BASE).  KEY #= OFFSET<0-3>/2 + 1
992
993 001426 000010      BUSY:  .BLKB  10      ;BUSY FLAGS FOR DRIVES 0-7
994
995
996                   ;THESE FLAGS WHEN SET INDICATE THAT A DRIVE IS BEING
997                   ;POSITIONED OR HAS ALREADY BEEN POSITIONED.
998
999 001436 000010      POS:   .BLKB  10      ;DRIVE 0 POSITIONED
1000
1001
1002
1003                   ;RETRY COUNTS FOR A PARTICULAR FUNCTION ON A DRIVE THE FUNCTION IS ABORTED
1004                   ;ON A DRIVE WHEN THE RETRY COUNT REACHES 3.
1005
1006 001446 000010      RETRY: .BLKB  10      ;DRIVES 0-7 RERTY COUNTS
1007
1008 001456 000000      WCFLG: .WORD  0      ;IF BIT 15 IS SET WRITE CHK IS TO BE DONE
1009                   ;FOLLOWING THE WRITE. BITS 0-3 CONTAIN THE
1010                   ;OFFSET TO KEY# (FROM BASE=KEY)
1011
1012 001460 000000      QSCNT: .WORD  0      ;THIS IS A COUNT FOR KEEPING TRACK OF THE TIME
1013                   ;TAKEN BY ALL THE 8 COMMANDS IN THE QUEUE.
1014                   ;IF THIS COUNTS DOWN TO 0 AN ERROR IS REPORTED
1015
1016
1017 001462 000000      PRSFNC: .WORD  0      ;COTAINS INFO ABOUT THE PRESENT COMMAND
1018                   ;BEING PERFORMED ON THE RK11
1019 001464 000000      PSTFNC: .WORD  0      ;CONTAINS INFO ABOUT THE COMMAND PERFORMED
1020                   ;BEFORE THE 'PRSCMND'
1021
1022
1023 001466 000000      CICNT:  .WORD  0      ;THIS IS A COUNT-TIMER USED FOR KEEPING TRACK
1024 001470 000000      CICNT1: .WORD  0      ;OF THE TIME TAKEN BY ANY FUNCTION TO BE
1025                   ;COMPLETED. IF THE COUNT GOES TO 0 AN ERROR IS REPORTED.
1026
1027 001472 000000      TIMER:  .WORD  0
1028 001474 000000      ERCODE: .WORD  0
1029 001476 000000      DRVPTR: .WORD  0
1030 001500 000000      DRVCNT: .WORD  0
1031
1032
1033 001502 000000      QDRV:   .WORD  0      ;TEMPORARY REGISTERS USED BY 'GENBRQ'
1034 001504 000000      QCYL:   .WORD  0      ;ROUTINE TO STORE VARIOUS PARAMETERS
1035 001506 000000      QSUR:   .WORD  0      ;OF A COMMAND AS THEY ARE GENERATED.
1036 001510 000000      QSEC:   .WORD  0
1037 001512 000000      QFNC:   .WORD  0
1038 001514 000000      QBUSAD: .WORD  0
1039 001516 000000      QWRCNT: .WORD  0
  
```

```

1040
1041
1042 ;THIS TABLE CONTAINS VARIOUS MAPPING FACTORS TO BE USED
1043 ;FOR GENERATING RANDOM PARAMETERS FROM RANDOM NUMBERS
1044
1045 001520 000000 DRMAP: .WORD 0 ;MAPPING FACTOR FOR GENERATING RANDOM DRIVE NUMBER
1046 001522 000000 CYLMAP: .WORD 0 ;MAPPING FACTOR FOR CYLINDER
1047 001524 000000 SECMAP: .WORD 0 ;MAPPING FACTOR FOR SECTOR
1048 001526 000000 FNMAP: .WORD 0 ;MAPPING FACTOR FOR FUNCTION
1049 001530 000000 BAMAP: .WORD 0 ;MAPPING FACTOR FOR BUS ADDRESS
1050 001532 000000 WCMAP: .WORD 0 ;MAPPING FACTOR FOR WORD COUNT
1051
1052
1053 ;THESE TWO FLAGS CORRESPOND TO THE 2 INTERRUPT HANDLERS (RK11) USED
1054 ;IN THIS PROGRAM. WHEN THE INTERRUPT HANDLER IS ENTERED THE FLAG IS
1055 ;CLEARED OR SET.
1056
1057 001534 000 INTFLG: .BYTE 0 ;FOR 'INTHND', CLEARED ON ENTERING HANDLER
1058 001535 000 INT1FL: .BYTE 0 ;FOR 'INTISK', SET ON ENTERING HANDLER
1059
1060 001536 000000 SAVKEY: .WORD 0
1061 001540 000000 ECOUNT: .WORD 0
1062
1063 ;THIS TABLE CONTAINS COUNTS FOR THE NUMBER OF OF ERRORS OCCURING ON A
1064 ;DRIVE (NOTE: ONLY THOSE ERRORS WHICH ARE POSITIVELY ATTRIBUTABLE TO A
1065 ;SPECIFIC DRIVE). THE COUNT KEPT ONLY IF SWITCH 2 IS SET. WHEN THE COUNT
1066 ;REACHES THE MAXIMUM ALLOWABLE (USUALLY 3) THE DRIVE IS DROPPED FROM
1067 ;TESTING AND IS TAKEN OUT OF THE DRIVE SELECTION TABLE.
1068
1069 001542 000010 ERDRV: .BLKB 10 ;COUNT FOR DRIVES 0-7
1070
1071 001552 000000 KWHR: .WORD 0 ;COUNTS HOURS (2'S COMPLEMENT)
1072 001554 000000 KWMIN: .WORD 0 ;COUNTS MINUTES (2'S COMPLEMENT)
1073 001556 000000 KWSEC: .WORD 0 ;COUNTS SECONDS (2'S COMPLEMENT)
1074 001560 000000 KWCOUNT: .WORD 0 ;COUNTS CPS FROM KWILL (2'S COMPLMNT)
1075
1076 ;THIS TABLE CONTAINS COUNTS FOR HARD ERRORS ON A PARTICULAR DRIVE.
1077 ;EX HECN2 WILL CONTAIN THE TOTAL NUMBER OF HARD ERRORS THAT OCCURED ON
1078 ;DRIVE 2
1079
1080 001562 000010 HECN: .BLKW 10 ;DRIVE 0-7 HARD ERROR COUNTS
1081
1082 ;THIS TABLE CONTAINS COUNTS FOR SEEK ERRORS
1083 ;ON A PARTICULAR DRIVE.
1084
1085 001602 000010 SKECN: .BLKW 10 ;DRIVE 0-7 SEEK ERROR COUNTS
1086
1087
1088 ;THIS TABLE CONTAINS COUNTS FOR SIN ERRORS ON A
1089 ;PARTICULAR DRIVE
1090
1091 001622 000010 SINCN: .BLKB 10 ;DRIVE 0-7 SIN COUNTS
1092
1093 ;THIS TABLE CONTAINS COUNTS FOR WRITE CHECK ERRORS
1094 ;THAT OCCURED ON A PARTICULAR DRIVE
1095

```

1096 001632 000010
1097
1098
1099
1100
1101
1102 001652 000010
1103
1104
1105
1106
1107
1108
1109 001672 000010
1110
1111
1112
1113 001712 000010

WCECN: .BLKW 10 ;WCE COUNT FOR DRIVES 0-7

;THIS TABLE CONTAINS COUNTS FOR CHECK SUM ERROR THAT
;OCCURED ON A PARTICULAR DRIVE

CSECN: .BLKW 10 ;CSE COUNT FOR DRIVES 0-7

;THIS TABLE CONTAINS COUNT OF NUMBER OF FUNCTIONS
;THAT WERE ABORTED ON A PARTICULAR DRIVE. A
;FUNCTION IS ABORTED ONLY AFTER DOING RETRIES

ABORT: .BLKW 10 ;ABORT COUNT FOR DRIVES 0-7

;COUNTS FOR NUMBER OF DATA ERRORS THAT OCCURED ON INDIVIDUAL DRIVES.

DATER: .BLKW 10 ;DRIVES 0-7

MO2

1114	001732	000000				NWRTL: .WORD	0	;LO WORD: OF THE 2 WORD COUNT-GIVING TOTAL
1115	001734	000000				NWRTH: .WORD	0	;HI WORD: # OF WORDS WRITTEN ON DRIVE C
1116	001736	000016				.BLKW	14.	;FOR REST OF DRIVES 1-7
1117								
1118								
1119	001772	000000				NRDL: .WORD	0	;LO WORD: 2 WORD COUNT GIVING TOTAL
1120	001774	000000				NRDH: .WORD	0	;HI WORD: # OF WORDS READ ON DRIVE C
1121	001776	000016				.BLKW	14.	;FOR DRIVES 1-7
1122								
1123	002032	001326				PCMND: .WORD	CMND	;POINTERS TO PARAMETERS FOR COMMANDS IN QUEUE
1124	002034	001336				.WORD	CMND+10	;POINTER TO SECOND COMMAND
1125	002036	001346				.WORD	CMND+20	;POINTER TO THIRD COMMAND
1126	002040	001356				.WORD	CMND+30	;POINTER TO FOURTH COMMAND
1127	002042	001366				.WORD	CMND+40	;POINTER TO FIFTH COMMAND
1128	002044	001376				.WORD	CMND+50	;POINTER TO SIXTH COMMAND
1129	002046	001406				.WORD	CMND+60	;POINTER TO SEVENTH COMMAND
1130	002050	001416				.WORD	CMND+70	;POINTER TO EIGHTH COMMAND
1131								
1132								
1133	002052	000000				BASEBA: .WORD	0	;CONTAINS THE LOWEST BUS ADDRESS STARTING WHICH DATA TRANSFERS
1134								;CAN BE DONE
1135	002054	000000				MAXBA: .WORD	0	;CONTAINS THE HIGHEST BUS ADDRESS TO WHICH DATA TRANSFERS
1136								;CAN BE DONE.
1137	002056	000000				REPCNT: .WORD	0	;CONTAINS THE REPETITION COUNT- THE NUMBER
1138								;OF TIMES Q REQUESTS WILL BE GENERATED. WHEN THIS
1139								;COUNT GOES TO 0, IT MEANS AN END OF PASS. HOWEVER
1140								;NOTE THAT THERE IS NO TRUE END OF PASS, IN THIS KIND
1141								;OF EXERCISER PROGRAM. THE EXERCISER RESUMES FROM
1142								;THE POINT IT LEFT OFF, AFTER TYPING OUT THE END IF
1143								;PASS MESSAGE.
1144	002060	000000				XXDPMD: .WORD	0	;LOW BYTE CONTAINS ADDRESS OF RK05 DRIVE
1145								;WHICH PROGRAM WAS LOADED FROM; HIGH BYTE
1146								;CONTAINS THE RK05 'XXDP' CODE.
1147								
1148								;ASCII MESSAGES
1149								
1150	002062	005015	045523	000105		MSG1: .ASCIZ	<15><12>/SKE/	
1151	002070	005015	041527	000105		MSG2: .ASCIZ	<15><12>/WCE/	
1152	002076	005015	051503	000105		MSG3: .ASCIZ	<15><12>/CSE/	
1153	002104	005015	040510	042122		MSG4: .ASCIZ	<15><12>/HARD EROR/	
1154	002112	042440	047522	000122				
1155	002120	047440	020116	047504		MSG5: .ASCIZ/	ON DOING /	
1156	002126	047111	020107	000				
1157	002133	127	044522	042524		MSG6: .ASCIZ	/WRITE/	
1158	002140	000						
1159	002141	122	040505	000104		MSG7: .ASCIZ	/READ/	
1160	002146	051127	020124	044103		MSG8: .ASCIZ	/WRT CHK/	
1161	002154	000113						
1162	002156	042122	041440	045510		MSG9: .ASCIZ	/RD CHK/	
1163	002164	000						
1164	002165	015	040412	047502		MSG10: .ASCIZ	<15><12>/ABORTED/<15><12>	
1165	002172	052122	042105	005015				
1166	002200	000						
1167	002201	123	042505	000113		MSG11: .ASCIZ	/SEEK/	
1168	002206	005015	041520	000075		MSG12: .ASCIZ	<15><12>/PC=/	
1169	002214	044120	051531	041040		MSG13: .ASCIZ	/PHYS BA=/	

1226 002662 040
1227 002663 040
1228 002664 000040
1229

BLNKS3: .ASCII //
BLNKS2: .ASCII //
BLNKS1: .ASCIZ //
.EVEN

1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285

002666

002666 027632
002670 031730
002672 032422
002674 000000

002676 027650
002700 031776
002702 032436
002704 000000

002706 027723
002710 031730
002712 032422
002714 000000

002716 027746
002720 031730
002722 032422
002724 000000

002726 027771
002730 031730
002732 032422

.SBTTL ERROR POINTER TABLE

;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
 ;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
 ;*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
 ;*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
 ;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;* EM ;:POINTS TO THE ERROR MESSAGE
 ;* DH ;:POINTS TO THE DATA HEADER
 ;* DT ;:POINTS TO THE DATA
 ;* DF ;:POINTS TO THE DATA FORMAT

\$ERRTB:

;*THERE ARE TWO CLASSES OF ERRORS:
 ;*1. ERRORS IN EXERCISER PART OF THE PROGRAM - ERROR NUMBERS BELOW 100
 ;*2. ERRORS IN THE NON-EXERCISER PART OF THE PROGRAM - ERROR NUMBERS EQUAL
 ;*TO AND GREATER THAN 100.
 ;*THE DOCUMENT CONTAINS MORE INFORMATION ON THESE.
 ;*THE FOLLOWING ERRORS OCCUR IN THE EXERCISER PART OF THE PROGRAM.

;ITEM 1

EM1 ;:ERROR ON WRITE
 DH1 ;:PC RKCS RKER RKDS RKDA
 DT1 ;:SERRPC \$REG0 \$REG1 \$REG2 \$REG3
 0

;ITEM 2

EM2 ;:ATTEMPT TO INITIATE FUNCTION ON 'BUSY' DRIVE
 DH2 ;:PC DRIVE
 DT2 ;:SERRPC \$REG0
 0

;ITEM 3

EM3 ;:CONTROL READY NOT SET
 DH1 ;:PC RKCS RKER RKDS RKDA
 DT1 ;:SERRPC \$REG0 \$REG1 \$REG2 \$REG3
 0

;ITEM 4

EM4 ;:R/W/S READY NOT SET
 DH1 ;:PC RKCS RKER RKDS RKDA
 DT1 ;:SERRPC \$REG0 \$REG1 \$REG2 \$REG3
 0

;ITEM 5

EM5 ;:CONTROL READY NOT SET AFTER FIRST INTERRUPT ON ISSUING SEEK
 DH1 ;:PC RKCS RKER RKDS RKDA
 DT1 ;:SERRPC \$REG0 \$REG1 \$REG2 \$REG3

1286	002734	000000	0	
1287				
1288				
1289			: ITEM	6
1290				
1291	002736	030056	EM6	; WRONG BITS IN RKCS, EXPECT SEEK
1292	002740	031730	DH1	; PC RKCS RKER RKDS RKDA
1293	002742	032422	DT1	; SERRPC \$REG0 \$REG1 \$REG2 \$REG3
1294	002744	000000	0	
1295				
1296			: ITEM	7
1297				
1298	002746	030115	EM7	; 'BUSY' FLAG CLEAR ON INTERRUPTING DRIVE
1299	002750	031776	DH2	; PC DRIVE
1300	002752	032436	DT2	; SERRPC \$REG0
1301	002754	000000	0	
1302				
1303			: ITEM	10
1304				
1305	002756	030162	EM10	; 'POSITIONING' FLAG FOR INTERRUPTING DRIVE CLEAR
1306	002760	031776	DH2	; PC DRIVE
1307	002762	032436	DT2	; SERRPC \$REG0
1308	002764	000000	0	
1309				
1310			: ITEM	11
1311				
1312	002766	030237	EM11	; 'ERR'OR SET AFTER FIRST INTERRUPT ON ISSUING SEEK
1313	002770	031730	DH1	; PC RKCS RKER RKDS RKDA
1314	002772	032422	DT1	; SERRPC \$REG0 \$REG1 \$REG2 \$REG3
1315	002774	000000	0	
1316				
1317			: ITEM	12
1318				
1319	002776	030317	EM12	; SCP SET AFTER FIRST INTERRUPT ON ISSUING SEEK
1320	003000	031730	DH1	; PC RKCS RKER RKDS RKDA
1321	003002	032422	DT1	; SERRPC \$REG0 \$REG1 \$REG2 \$REG3
1322	003004	000000	0	
1323				
1324			: ITEM	13
1325				
1326	003006	030371	EM13	; CONTROL READY NOT SET AFTER SEEK DONE INTERRUPT
1327	003010	031730	DH1	; PC RKCS RKER RKDS RKDA
1328	003012	032422	DT1	; SERRPC \$REG0 \$REG1 \$REG2 \$REG3
1329	003014	000000	0	
1330				
1331			: ITEM	14
1332				
1333	003016	030444	EM14	; INTERRUPTING DRIVE (SEEK DONE) WAS NOT 'BUSY'
1334	003020	031730	DH1	; PC RKCS RKER RKDS RKDA
1335	003022	032422	DT1	; SERRPC \$REG0 \$REG1 \$REG2 \$REG3
1336	003024	000000	0	
1337				
1338			: ITEM	15
1339				
1340	003026	030517	EM15	; R/W/S READY NOT SET FOR INTERRUPTING DRIVE (SEEK DONE)
1341	003030	031730	DH1	; PC RKCS RKER RKDS RKDA

1454			:ITEM	35					
1455					EM35	:DRIVE POWER LOW			
1456	003226	031451			DH1	:PC RKCS RKER RKDS RKDA			
1457	003230	031730			DT1	:\$ERRPC \$REG0 \$REG1 \$REG2 \$REG3			
1458	003232	032422			0				
1459	003234	000000							
1460			:ITEM	36					
1461					EM36	:DRIVE UNSAFE			
1462					DH1	:PC RKCS RKER RKDS RKDA			
1463	003236	031467			DT1	:\$ERRPC \$REG0 \$REG1 \$REG2 \$REG3			
1464	003240	031730			0				
1465	003242	032422							
1466	003244	000000							
1467									
1468			:ITEM	37					
1469					EM37	:WPS SET			
1470	003246	031503			DH1	:PC RKCS RKER RKDS RKDA			
1471	003250	031730			DT1	:\$ERRPC \$REG0 \$REG1 \$REG2 \$REG3			
1472	003252	032422			0				
1473	003254	000000							
1474									
1475			:*						
1476			:*						
1477			:*						
1478									
1479			:ITEM	100					
1480					EM23	:DATA (COMPARISON) ERROR			
1481	003256	030720			DH23	:PC RKBA EXPCT RECVD RKDA			
1482	003260	032110			DT1	:\$ERRPC \$REG0 \$REG1 \$REG2 \$REG3			
1483	003262	032422			0				
1484	003264	000000							
1485									
1486			:ITEM	101					
1487					EM101	:INTERRUPT DID NOT OCCUR AFTER WRITE			
1488	003266	031513			DH1	:PC RKCS RKER RKDS RKDA			
1489	003270	031730			DT1	:\$ERRPC \$REG0 \$REG1 \$REG2 \$REG3			
1490	003272	032422			0				
1491	003274	000000							
1492									
1493			:ITEM	102					
1494					EM102	:ERR'OR SET			
1495	003276	031553			DH1	:PC RKCS RKER RKDS RKDA			
1496	003300	031730			DT1	:\$ERRPC \$REG0 \$REG1 \$REG2 \$REG3			
1497	003302	032422			0				
1498	003304	000000							
1499									
1500			:ITEM	103					
1501					EM103	:RKDA INCREMENTED WRONGLY			
1502	003306	031567			DH103	:PC EXPCT RECVD			
1503	003310	032265			DT103	:\$ERRPC \$REG0 \$REG1			
1504	003312	032504			0				
1505	003314	000000							
1506									
1507			:ITEM	104					
1508					EM104	:RKBA INCREMENTED WRONGLY			
1509	003316	031615							

1510	003320	032265	DH103	;PC	EXPCT	RECVD			
1511	003322	032504	DT103	;\$ERRPC	\$REG0	\$REG1			
1512	003324	000000	0						
1513									
1514			: ITEM	105					
1515									
1516	003326	031643	EM105	;RKWC	DID NOT	OVERFLOW	TO	0	
1517	003330	032327	DH105	;PC	RKDA	RKWC			
1518	003332	032504	DT103	;\$ERRPC	\$REG0	\$REG1			
1519	003334	000000	0						
1520									
1521			: ITEM	106					
1522									
1523	003336	031673	EM106	;MEX	BITS	INCORRECT			
1524	003340	031730	DH1	;PC	RKCS	RKER	RKDS	RKDA	
1525	003342	032422	DT1	;\$ERRPC	\$REG0	\$REG1	\$REG2	\$REG3	
1526	003344	000000	0						
1527									
1528			: ITEM	107					
1529									
1530	003346	030720	EM23	;DATA	(COMPARISON)	ERROR	ON	READ	
1531	003350	032265	DH103	;PC	EXPCT	RECVD			
1532	003352	032504	DT103	;\$ERRPC	\$REG0	\$REG1			
1533	003354	000000	0						
1534									
1535			: ITEM	110					
1536									
1537	003356	031712	EM110	;WRITE	CHECK	ERROR			
1538	003360	032354	DH110	;PC	RKCS	RKER	RKBA	RKDA	
1539	003362	032422	DT1	;\$ERRPC	\$REG0	\$REG1	\$REG2	\$REG3	
1540	003364	000000	0						

```

1541                                     :IF POWER FAILED, ON RETURN OF POWER ENTER HERE.
1542
1543 003366 004237 022630                PFSTRT: JSR      PC WATIME      ;WAIT SOME TIME
1544 003372 005237 001253                INCB     FRSTRT      ;INDICATE THAT THE STATISTICS HAVE
1545                                     ;TO BE SAVED, ON RETRN FROM PWR FAIL.
1546
1547
1548
1549
1550 003376 000005                START:  RESET      ;CLEAR THE BUS
1551                                     ;;GIVE DRIVES TIME TO LOAD IF PROGRAM WAS STARTED BY APT
1552 003400 023737 000042 000046                CMP      #242, #246
1553 003406 001016                BNE     STARTA
1554 003410 005077 175614                CLR     #ARKDA      ;SELECT UNIT 0
1555 003414 012700 000250                MOV     #250, R0     ;WAIT FOR..
1556 003420 032777 000200 175570 20$:  BIT     #200, #ARKDS ;DRIVE READY..
1557 003426 001006                BNE     STARTA      ;IN CASE..
1558 003430 005001                CLR     R1          ;OF APT..
1559 003432 005301                DEC     R1          ;START, BUT..
1560 003434 001376                BNE     #-2         ;DON'T WAIT..
1561 003436 005300                DEC     R0          ;FOREVER.
1562 003440 001367                BNE     20$
1563 003442 000000                HALT
1564 003444
1565
1566
1567 003444 012706 001100                STARTA: SBTTL  INITIALIZE THE COMMON TAGS
1568 003450 005026                ;;CLEAR THE COMMON TAGS ($CMTAG) AREA
1569 003452 022706 001140                MOV     #CMTAG, R6  ;;FIRST LOCATION TO BE CLEARED
1570 003456 001374                CLR     (R6)+       ;;CLEAR MEMORY LOCATION
1571 003460 012706 001100                CMP     #SWR, R6    ;;DONE?
1572                                     BNE     #-6         ;;LOOP BACK IF NO
1573                                     MOV     #STACK, SP  ;;SETUP THE STACK POINTER
1574                                     ;;INITIALIZE A FEW VECTORS
1575 003464 012737 027204 000020                MOV     #SCOPE, #IOTVEC ;; IOT VECTOR FOR SCOPE ROUTINE
1576 003472 012737 000340 000022                MOV     #340, #IOTVEC+2 ;; LEVEL 7
1577 003500 012737 027350 000034                MOV     #STRAP, #TRAPVEC ;; TRAP VECTOR FOR TRAP CALLS
1578 003506 012737 000340 000036                MOV     #340, #TRAPVEC+2 ;; LEVEL 7
1579 003514 012737 027450 000024                MOV     #SPWRON, #PWRVEC ;; POWER FAILURE VECTOR
1580 003522 012737 000340 000026                MOV     #340, #PWRVEC+2 ;; LEVEL 7
1581 003530 012737 003530 001106                MOV     #, $LPADR   ;; INITIALIZE THE LOOP ADDRESS FOR SCOPE
1582 003536 012737 003536 001110                MOV     #, $LPERR   ;; SETUP THE ERROR LOOP ADDRESS
1583                                     ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
1584                                     ;;EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
1585 003544 013746 000004                MOV     #ERRVEC, -(SP) ;; SAVE ERROR VECTOR
1586 003550 012737 003604 000004                MOV     #64$, #ERRVEC ;; SET UP ERROR VECTOR
1587 003556 012737 177570 001140                MOV     #DSWR, SWR   ;; SETUP FOR A HARDWARE SWICH REGISTER
1588 003564 012737 177570 001142                MOV     #DISP, DISPLAY ;; AND A HARDWARE DISPLAY REGISTER
1589 003572 022777 177777 175340                CMP     #-1, #SWR   ;; TRY TO REFERENCE HARDWARE SWR
1590 003600 001012                BNE     66$         ;; BRANCH IF NO TIMEOUT TRAP OCCURRED
1591                                     ;; AND THE HARDWARE SWR IS NOT = -1
1592 003602 000403                BR      65$        ;; BRANCH IF ) TIMEOUT
1593 003604 012716 003612 64$:  MOV     #65$, (SP)  ;; SET UP FOR TRAP RETURN
1594 003610 000002                RTI
1595 003612 012737 000176 001140 65$:  MOV     #SWREG, SWR  ;; POINT TO SOFTWARE SWR
1596 003620 012737 000174 001142                MOV     #DISPREG, DISPLAY
1597 003626 012637 000004 66$:  MOV     (SP)+, #ERRVEC ;; RESTORE ERROR VECTOR
    
```

```

1597 003632 023737 000042 000046      CMP      2042,2046      ;ARE WE IN ACT11 AUTOMATIC MODE?
1598 003640 001416                      BEQ      69$           ;YES, SKIP TITLE PRINTOUT
1599                                     ;:SBTTL TYPE PROGRAM NAME
1600                                     ;:TYPE THE NAME OF THE PROGRAM IF FIRST PASS
1601 003642 005227 177777      INC      #-1           ;:FIRST TIME?
1602 003646 001052                      BNE      67$           ;:BRANCH IF NO
1603 003650 104401 003706      TYPE     68$           ;:TYPE ASCIZ STRING
1604                                     .SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
1605 003654 005737 000042      TST     2042          ;:ARE WE RUNNING UNDER XXDP/ACT?
1606 003660 001006                      BNE      69$           ;:BRANCH IF YES
1607 003662 023727 001140 000176      CMP     SWR,#SWREG    ;:SOFTWARE SWITCH REG SELECTED?
1608 003670 001005                      BNE      70$           ;:BRANCH IF NO
1609 003672 104406      GTSWR                                ;:GET SOFT-SWR SETTINGS
1610 003674 000403                      BR       70$
1611 003676 112737 000001 001134 69$: MOV     #1,$AUTOB    ;:SET AUTO-MODE INDICATOR
1612 003704                      70$:
1613 003704 000433                      BR       67$         ;:GET OVER THE ASCIZ
1614                                     ;:68$: .ASCIZ <CRLF>*RK11/RK05 PERFORMANCE EXERCISER*1512*MAINDEC-11-DZRKH-G*1CRLF
1615                                     67$:
1616 003774 012737 026206 000030      MOV     $ERROR,$EMTVEC ;EMT VECTOR FOR ERROR ROUTINE
1617 004002 013737 001244 000032      MOV     PPRVL,$EMTVEC+2 ;LEVEL 5
1618 004010 012737 022552 000100      MOV     $KWSRV,$KWLVEC ;KWL11 CLOCK SERVICE
1619 004016 013737 001246 000102      MOV     KWPLVL,$KWLVEC+2 ;LEVEL 7
1620
1621                                     ;THE FOLLOWING CODE FINDS OUT THE PROGRAM CONTROL MODE:
1622                                     ;PAPER TAPE (MANUAL), ACT11, RKDP CHAIN OR DUMP
1623
1624
1625 004024 005037 002060                      CLR     XXDPMO        ;CLEAR 'XXDP' LOAD DEVICE STORAGE
1626 004030 122737 000002 000041      CMPB   #2,41         ;LOADED FROM AN RK05 ?
1627 004036 001160                      BNE     ST2           ;BR IF NOT
1628 004040 013737 000040 002060      MOV     40,XXDPMO    ;GET DEVICE INDICATOR AND DRIVE ADDRESS OF
1629                                     ;LOADING RK05
1630 004046 122737 000010 002060      CMPB   #10,XXDPMO   ;VALID DRIVE ADDRESS ?
1631 004054 101002                      BHI     2$           ;BR IF YES
1632 004056 105037 002060                      CLRB   XXDPMO        ;CHANGE TO DRIVE ZERO
1633 004062 005737 000042      2$: TST     42         ;CHAIN MODE OR ACT11 AUTO ACCEPT ?
1634 004066 001424                      BEQ     3$           ;BR IF NEITHER
1635 004070 104401 004076      TYPE   72$          ;:TYPE ASCIZ STRING
1636 004074 000413                      BR     71$           ;:GET OVER THE ASCIZ
1637                                     ;:72$: .ASCIZ <15><12>/NOT TESTING DRIVE /
1638                                     71$:
1639 004124 005046                      CLR     -(SP)         ;CLEAR WORD ON STACK
1640 004126 113716 002060      MOVB   XXDPMO,(SP)  ;GET DRIVE ADDRESS
1641 004132 104403                      TYPOS                                ;TYPE THE ADDRESS
1642 004134 001                                .BYTE  1             ;ONLY 1 CHARACTER
1643 004135 000                                .BYTE  0             ;SUPPRESS LEADING ZEROS
1644 004136 000520                      BR     ST2           ;GET NUMBER OF DRIVES
1645 004140 005227 177777      3$: INC     #-1       ;FIRST TIME THROUGH HERE ?
1646 004144 001115                      BNE     ST2         ;BR IF NOT
1647 004146 104401 004154      TYPE   74$          ;:TYPE ASCIZ STRING
1648 004152 000411                      BR     73$           ;:GET OVER THE ASCIZ
1649                                     ;:74$: .ASCIZ <15><12>/TO TEST DRIVE /
1650                                     73$:
1651 004176 005046                      CLR     -(SP)         ;CLEAR WORD ON THE STACK
1652 004200 113716 002060      MOVB   XXDPMO,(SP)  ;GET DRIVE ADDRESS

```

1653	004204	104403		TYPOS		:TYPE THE DRIVE ADDRESS
1654	004206	001		:BYTE	1	:ONLY 1 CHARACTER
1655	004207	000		:BYTE	0	:SUPPRESS LEADING ZEROS
1656	004210	104401	004216	TYPE	76\$:TYPE ASCIZ STRING
1657	004214	000431		BR	75\$:GET OVER THE ASCIZ
1658				76\$:	.ASCIZ	/ HALT PROGRAM, REMOVE RKDP PACK AND REPLACE IT/<15><12>
1659	004300			75\$:		
1660	004300	104401	004306	TYPE	78\$:TYPE ASCIZ STRING
1661	004304	000435		BR	77\$:GET OVER THE ASCIZ
1662				78\$:	.ASCIZ	/WITH A WORK PACK, CLEAR LOCATION 40, AND RESTART PROGRAM/
1663	004400			77\$:		
1664						
1665						
1666						
1667	004400	104416		ST2:	CON.RESET	
1668	004402	005037	001264	CLR	DRVPRS	;FIND WHICH DRIVE #'S ARE PRESENT
1669	004406	005000		CLR	R0	
1670	004410	005002		CLR	R2	
1671	004412	005037	001254	CLR	PDR	;CLEAR DRIVES PRESENT TABLE
1672	004416	005037	001256	CLR	PDR+2	
1673	004422	005037	001260	CLR	PDR+4	
1674	004426	005037	001262	CLR	PDR+6	
1675	004432	012701	001254	MOV	#PDR,R1	
1676	004436	012703	001306	MOV	#KEY,R3	
1677	004442	010277	174562	MOV	R2,ARKDA	;SELECT A DRIVE
1678	004446	032777	000200	BIT	#200,ARKDS	;IS IT IN SYSTEM?
1679	004454	001415		BEQ	3\$;NO
1680	004456	010237	001502	MOV	R2,QDRV	;LOAD DRIVE ADDRESS INTO QDRV
1681	004462	104420		DRV.RESET		;RESET THE DRIVE
1682	004464	005737	002060	TST	XXDPMD	;PROGRAM LOADED FROM AN RK05 ?
1683	004470	001403		BEQ	2\$;BR IF NOT
1684	004472	120037	002060	CMPB	R0,XXDPMD	;LOADED FROM THIS RK05 ?
1685	004476	001404		BEQ	3\$;BR IF YES
1686	004500	110021		2\$:	MOV#B	R0,(R1)+
1687	004502	010223		MOV	R2,(R3)+	;STORE ADDRESS IN KEY TABLE
1688	004504	005237	001264	INC	DRVPRS	;BUMP THE NUMBER OF DRIVES COUNTER
1689	004510	062702	020000	3\$:	ADD	#20000,R2
1690	004514	005200		INC	R0	;NEXT DRIVE ADDRESS
1691	004516	022700	000010	CMP	#8.,R0	;NEXT DRIVE NUMBER
1692	004522	001347		BNE	1\$;DONE ALL DRIVES???
1693	004524	013703	001264	MOV	DRVPRS,R3	;LOOP TILL DONE
1694	004530	001510		BEQ	ST4	;FIND WHICH DRIVES ARE TYPE F
1695	004532	012701	001254	MOV	#PDR,R1	;BR IF NOT DRIVES PRESENT
1696	004536	005000		CLR	R0	
1697	004540	005002		CLR	R2	
1698	004542	104401	002362	TYPE	MSG20	
1699	004546	111102		4\$:	MOV#B	(R1),R2
1700	004550	010200		MOV	R2,R0	;GET DRIVE NUMBER
1701	004552	002472		BLT	9\$	
1702						
1703	004554	104401	002372	TYPE	MSG24	
1704						
1705	004560	010246		MOV	R2,-(SP)	;TYPE THE DRIVE NUMBER
1706	004562	004403		TYPOS		
1707	004564	001		:BYTE	1	
1708	004565	000		:BYTE	0	

1709	004566	000241			CLC			; MOVE DRIVE NUMBER TO BITS 15,14,13
1710	004570	006002			ROR	R2		; BIT0 TO CARRY
1711	004572	006002			ROR	R2		; BIT0 TO BIT15
1712	004574	006002			ROR	R2		; BIT0 TO BIT14
1713	004576	006002			ROR	R2		; BIT0 TO BIT13
1714	004600	042702	017777		BIC	#17777,R2		; CLEAR ANY EXTRANEIOUS BITS
1715								
1716	004604	010237	001502		MOV	R2,QDRV		
1717	004610	104420			DRV.RESET			; RESET THE DRIVE VIA QDRV
1718								
1719	004612	032702	020000		BIT	#20000,R2		; EVEN DRIVE NUMBER???
1720	004616	001003			BNE	5\$; NO - CLEAR BIT
1721								
1722	004620	052702	020000		BIS	#20000,R2		; MAKE IT AN ODD DRIVE
1723	004624	000402			BR	6\$		
1724								
1725	004626	042702	020000	5\$:	BIC	#20000,R2		; MAKE IT AN EVEN DRIVE
1726								
1727	004632	010277	174372	6\$:	MOV	R2,DRKDA		; SELECT THE NEW DRIVE
1728	004636	032777	000200	174352	BIT	#200,DRKDS		; MAKE SURE DRIVE IS IN SYSTEM
1729	004644	001420			BEQ	8\$; IF NOT, SKIP THIS TEST
1730								
1731	004646	012777	000011	174346	MOV	#11,DRKCS		; START A SEEK TO CYL 0
1732	004654	104417			CON.RDY			; WAIT FOR CONTROLLER
1733	004656	032777	000100	174332	BIT	#100,DRKDS		; IS IT IN MOTION???
1734	004664	001010			BNE	8\$; NO - J TYPE DRIVE
1735								
1736	004666	152711	000200		BISB	#200,(R1)		; YES - SET THE F TYPE BIT
1737	004672	104401	002375		TYPE	,MSG25		
1738								
1739	004676	032777	000100	174312	7\$:	BIT	#100,DRKDS	; WAIT FOR HEADS TO STOP
1740	004704	001774			BEQ	7\$		
1741								
1742	004706	105737	001253	8\$:	TSTB	FRSTR		
1743	004712	001012			BNE	9\$		
1744								
1745	004714	032777	000002	174216	BIT	#SW1,DSWR		; SERIAL NO. SW SET?
1746	004722	001406			BEQ	9\$; NO
1747								
1748	004724	104401	002326		TYPE	,MSG17		; TYPE "SR NO"
1749	004730	104413			RDDEC			; READ FROM TTY INPUT
1750	004732	006300			ASL	R0		; SAVE SERIAL NO FOR THE DRIVE
1751	004734	012660	001266		MOV	(SP)+,SRNO(R0)		
1752								
1753	004740	005201		9\$:	INC	R1		
1754	004742	003303			DEC	R3		
1755	004744	003300			BGT	4\$		
1756	004746	104401	001213		TYPE	,SCLF		

1757
 1758
 1759
 1760
 1761
 1762
 1763
 1764
 1765
 1766
 1767
 1768
 1769
 1770
 1771
 1772
 1773
 1774 004752 004737 017466
 1775 004756 012702 002052
 1776 004762 012703 002054
 1777 004766 005737 017524
 1778 004772 100022
 1779 004774 013700 017772
 1780 005000 020027 001540
 1781 005004 002012
 1782
 1783 005006 162700 000040
 1784 005012 012701 177772
 1785
 1786 005016 006300
 1787 005020 005201
 1788 005022 001375
 1789 005024 162700 000002
 1790 005030 000415
 1791
 1792 005032 012713 147776
 1793 005036 000413
 1794
 1795 005040 013700 017770
 1796
 1797
 1798 005044 005737 000040
 1799 005050 001003
 1800 005052 162700 000500
 1801 005056 000402
 1802 005060 162700 006000
 1803
 1804 005064 010013
 1805
 1806 005066 012712 032514
 1807 005072 032777 000100 174040
 1808 005100 001510
 1809 005102 104401 005110
 1810 005106 000432
 1811
 1812 005174

```

; 'MAXBA' IS THE HIGHEST BUS ADDRESS (MEMORY) TO WHICH DATA TRANSFERS CAN
; BE DONE BY THE PROGRAM.
; 'MAXBA' IS FIGURED USING THE FOLLOWING ALGORITHM:

; 1. IF KT11 IS NOT PRESENT,
; A. AND THE PROGRAM IS RUN UNDER XXDP, THEN THE TOP 1.5 K IS RESERVED
; AND THE 'MAXBA' IS COMPUTED ($LSTAD-6000).
; B. AND THE PROGRAM IS NOT RUNNING UNDER XXDP, THEN THE TOP 320 WORDS
; ARE RESERVED FOR 'MOM', LOADER, ETC. AND THE 'MAXBA' IS COMPUTED ($LSTAD-500).

; 2. IF KT11 IS PRESENT,
; A. AND MORE THAN 28K MEMORY IS PRESENT, THEN THE MAXIMUM BUS ADDRESS
; IS 147776 (OCTAL).
; B. AND LESS THAN 28K IS PRESENT, THEN THE TOP 2K IS RESERVED FOR RKDP
; MONITOR AND 'MAXBA' IS COMPUTED.
; FIGURE OUT THE AVAILABLE MEMORY AND 'MAXBA'

ST4: JSR PC, $SIZE ; GO SIZE THE MEMORY
      MOV #BASEBA, R2 ; INITIALIZE POINTERS
      MOV #MAXBA, R3
      TST SKT!1 ; 'KT11 AVAILABLE?'
      BPL 4$ ; NO
      MOV $LSTBK, R0 ; GET THE LAST BANK OF MEMORY
      CMP R0, #1540 ; 28K OR MORE?
      BGE 3$ ; YES

      SUB #40, R0 ; BACK UP 2 K'S (RKDP MONITOR, ETC.)
      MOV #-6, R1 ; AND FORM THE MAXIMUM BUS ADDRESS
                        ; FOR DATA TRANSFER

1$: ASL R0
   INC R1
   BNE 1$
   SUB #2, R0
2$: BR 6$

3$: MOV #147776, (R3) ; FOR 28K OR MORE, THIS IS THE 'MAXBA'
   BR 7$

4$: MOV $LSTAD, R0 ; KT11 NOT PRESENT, GET THE LAST
                        ; AVAILABLE ADDRESS

5$: TST #40 ; 'XXDP' LOADED PROGRAM ?
   BNE 8$ ; YES
   SUB #500, R0 ; NO, SAVE THE LAST 320 WORDS
   BR 6$

6$: SUB #6000, R0 ; SAVE THE LAST 1.5K OF MEMORY (RKDP
                        ; MONITOR, ETC.)
7$: MOV R0, (R3) ; SAVE THE MAXIMUM BUS ADDRESS (MAXBA) TO
                        ; WHICH DATA TRANSFER CAN BE DONE SAFELY
                        ; 'BASEBA'

8$: MOV #PGEND, (R2)
   BIT #SW06, $SWR
   BEQ ST3
   TYPE 65$ ; TYPE ASCIZ STRING
   BR 64$ ; GET OVER THE ASCIZ

65$: .ASCIZ <15><12>/TYPE OCTAL BUS ADDRESSES FOR DATA XFER. BETWEEN
64$:
  
```

```

1813 005174 011246          MOV      (R2),-(SP)      ;'BASEBA'
1814 005176 104402          TYP0C
1815 005200 104401 005206        TYPE      ,67$          ;;TYPE ASCIZ STRING
1816 005204 000402          BR       66$           ;;GET OVER THE ASCIZ
1817          ;;67$: .ASCIZ / 8 /
1818 005212          66$:
1819 005212 011346          MOV      (R3),-(SP)      ;'MAXBA'
1820 005214 104402          TYP0C
1821 005216          9$:
1822 005216 104401 005224        TYPE      ,69$          ;;TYPE ASCIZ STRING
1823 005222 000407          BR       68$           ;;GET OVER THE ASCIZ
1824          ;;69$: .ASCIZ <15><12>/LO LIMIT /
1825 005242          68$:
1826 005242 104412          RDOCT
1827 005244 012600          MOV      (SP)+,R0
1828 005246 020012          CMP      R0,(R2)        ;CORRECT LO LIMIT?
1829 005250 103762          BLO     9$
1830 005252 020013          CMP      R0,(R3)        ;CORRECT LO LIMIT?
1831 005254 103360          BHIS    9$
1832 005256 010012          MOV      R0,(R2)        ;'BASEBA'
1833 005260          10$:
1834 005260 104401 005266        TYPE      ,71$          ;;TYPE ASCIZ STRING
1835 005264 000407          BR       70$           ;;GET OVER THE ASCIZ
1836          ;;71$: .ASCIZ <15><12>/HI LIMIT /
1837 005304          70$:
1838 005304 104412          RDOCT
1839 005306 012600          MOV      (SP)+,R0
1840 005310 020013          CMP      R0,(R3)        ;CORRECT HI LIMIT?
1841 005312 101362          BHI     10$
1842 005314 020012          CMP      R0,(R2)        ;CORRECT LO LIMIT?
1843 005316 101760          BLOS    10$
1844 005320 010013          MOV      R0,(R3)        ;'MAXBA'
1845
1846 005322 023727 002054 037476 ST3:  CMP      MAXBA,#37476    ;8K MEMORY - CLOBBER XXDPT
1847 005330 002003          BGE     1$
1848 005332 012737 037476 002054  MOV      #37476,MAXBA    ;BUT SAVE LOADER
1849 005340 105737 001253 1$:  TSTB    FRSTR1          ;PROGRAM RESTARTED AT 210?
1850 005344 001402          BEQ     BCTST          ;NO
1851 005346 000137 007772          JMP     EXRC5R          ;YES, SKIP TEST 1 TO 7

```


1852
1853
1854
1855
1856
1857
1858
1859
1860
1861
1862

005352 012737 001306 001476
005360 013737 001264 001500
005366 017737 174104 001502
005374 062737 000002 001476
005402 005337 001500
100002
005410 000137 007772

;THIS IS THE BEGINING OF THE CONSTRAINED TESTS AIMED AT CHECKING THE
;DIFFERENT BOUNDARY CONDITIONS OF RK11/RK05
;FIND OUT THE DRIVE NUMBER TO BE TESTED.
ECTST: MOV #KEY, DRVPTR ; INITIALIZE PTR TO DRV#
MOV DRVPRS, DRVCNT ; NUMBER OF DRIVES PRESENT
NXTDRV: MOV @DRVPTR, QDRV ; SAVE DRIVE # (BITS 15-13)
ADD #2, DRVPTR ; INCRMENT PTR TO NXT DRV#
DEC DRVCNT ; DONE ALL DRIVES?
BPL TST1 ; NO, GO TEST THIS DRIVE
JMP EXRCR ; ALL DONE, GO TO EXERCISER PART

1863
 1864
 1865
 1866
 1867
 1868
 1869
 1870
 1871
 1872 005414 000004
 1873
 1874 005416 013701 001502
 1875 005422 010102
 1876 005424 062702 000002
 1877
 1878 005430 012737 005436 001110
 1879
 1880 005436 104416
 1881 005440 104420
 1882 005442 104416
 1883 005444 012737 111111 032514
 1884 005452 012703 000401
 1885 005456 004737 006304
 1886
 1887 005462 104101
 1888 005464 004737 020112
 1889 005470 104102
 1890 005472 004737 020126
 1891 005476 104103
 1892
 1893 005500 004737 020230
 1894 005504 104105
 1895
 1896 005506 032701 000010
 1897 005512 001005
 1898 005514 062701 000012
 1899 005520 062702 000016
 1900 005524 000747

```

:*****
:TEST 1 PERFORM WRITE OF 401 WORDS (1 SECTOR + 1 WORDS)
:THIS TEST PERFORMS A WRITE OF 401 WORDS (1 SECTOR + 1WORD) AND
:CHECKS IF RKDA,RKBA,RKWC INCREMENTED CORRECTLY.WRITING IS DONE
:ON CYLINDER 0, SURFACE 0, SECTORS 0,1 AND 10,11. IT SHOULD BE
:NOTED THAT THIS IS A BOUNDARY CONDITION TRANSFER. THE VALIDITY
:OF THE TRANSFER IS CHECKED IN THE NEXT TEST.
:DATA PATTERN WRITTEN IS 111111.
:*****
↑ST1: SCOPE
MOV QDRV,R1 ;GET RKDA
MOV R1,R2 ;SAVE RKDA
ADD #2,R2 ;EXPCD RKDA AFTER WRITE IS DONE
MOV #1$, $LPERR ;RETURN ADDRESS FOR LUPING
1$: CON.RESET
DRV.RESET
CON.RESET
MOV #111111, DBUF ;CLEAR MASK BITS IN POLLING LOGIC
MOV #401, R3 ;PATTERN TO BE WRITTEN
JSR PC, DOWRITE ;WORD COUNT FOR WRITE
;GO DO WRITE
ERROR 101 ;INTERRUPT DID NOT OCCUR AFTER WRITE
JSR PC, CHKCS ;CHECK ERROR BIT IN RKCS
ERROR 102 ;ERROR BIT IN RKCS SET ON DOING WRITE
JSR PC, CHKDA ;CHECK IF RKDA INCREMENTED RIGHT
ERROR 103 ;RKDA DID NOT INCREMENT RIGHT AFTER
;A WRITE OF 401 WORDS.
JSR PC, CHKWC ;CHECK IF RKWC OVERFLOWED TO 0
ERROR 105 ;RKWC DID NOT OVERFLOW TO 0 AFTER
;A WRITE OF 401 WORDS.
BIT #10, R1 ;SECTORS 10,11 WRITTEN?
BNE TST2 ;YES
ADD #12, R1 ;RKDA TO BE USED NEXT (SEC 10)
ADD #16, R2 ;EXPCD RKDA AFTER WRITE IS DONE
BR 2$ ;GO WRITE SECS 10,11
  
```

```

1901
1902
1903
1904
1905
1906
1907
1908 005526 000004
1909
1910 005530 013701 001502
1911 005534 012737 005542 001110
1912 005542 104416
1913 005544 104420
1914 005546 104416
1915
1916
1917 005550 004737 006434
1918
1919 005554 012703 001000
1920
1921 005560 004737 006424
1922
1923 005564 104101
1924
1925 005566 004737 020112
1926 005572 104102
1927
1928 005574 012704 032514
1929 005600 010402
1930 005602 004737 020150
1931 005606 104104
1932
1933 005610 012705 177764
1934 005614 022712 111111
1935 005620 001410
1936 005622 012737 111111 001164
1937 005630 004737 005720
1938 005634 104100
1939
1940
1941
1942
1943
1944 005636 005205
1945 005640 001421
1946 005642 005722
1947 005644 020227 033516
1948 005650 001361
1949
1950 005652 005712
1951 005654 001407
1952 005656 005037 001164
1953 005662 004737 005720
1954 005666 104100
1955
1956

```

```

*****
;#TEST 2 READ & CHECK THAT 401 WORD WRITE WAS DONE CORRECTLY
;THIS TEST PERFORMS A READ OF THE 401 WORDS WRITTEN IN THE
;PREVIOUS TEST AND CHECKS THAT THEY WERE CORRECTLY READ. MOREOVER
;IT CHECKS THAT ONLY ONE NON-ZERO WORD (401TH) WAS WRITTEN IN THE
;SECOND SECTOR AND THE REST OF THE WORDS ARE ALL ZEROS.
*****
TST2: SCOPE
15: MOV QDRV,R1 ;GET DRIVE #
MOV #15,$LPERR ;ADDRESS FOR LUPING ON EROR
CON.RESET
DRV.RESET
CON.RESET
JSR PC,CLEANBUF ;CLEAN UP THE DATA BUFFER
;INTO WHICH READ WILL
;BE DONE
MOV #1000,R3 ;WORD COUNT
JSR PC,DOREAD ;GO DO A READ OF 2 SECTORS
;FROM DISK ADDRESS GIVEN IN R1
;INTERRUPT DID NOT OCCUR AFTER
;READ OF 401 WORDS WAS DONE.
ERROR 101 ;CHECK IF EROR BIT IN RKCS SET?
;EROR BIT IN RKCS SET ON DOING A
;READ OF 401 WORDS.
JSR PC,CHKCS ;STARTING BUS ADDRESS, INTO WHICH READ
;WAS DONE
ERROR 102 ;CHECK IF RKBA INCREMENTED RIGHT
;RKBA DID NOT INCREMENT RIGHT AFTER READ
;OF 401 WORDS.
MOV #DBUF,R4 ;ALLOW 12 ERRORS, AT THE MOST
MOV R4,R2 ;CORRECT DATA READ?
JSR PC,CHKBA ;YES
ERROR 104 ;GET EXPCTD DATA WORD
;GET ERROR INFORMATION
;DATA ERROR OCCURRED WHEN A
;READ OF 401 WORDS WAS DONE
;THE DISK ADDRESS FROM WHERE
;THE DATA WAS READ INCORRECTLY
;IS GIVEN IN THE ERROR MESSAGE
25: MOV #-14,R5 ;REPORT 12 ERORS AT MOST
CMP #111111,(R2) ;INCREMENT POINTER
BEQ 35 ;CHECKED ALL 401 WORDS?
MOV #111111,$REG1
JSR PC,ERINF1
ERROR 100
35: INC R5
BEQ 65
TST (R2)+ ;CHECK THAT REST OF 377 WORDS
;ARE ALL 0'S
CMP R2,#DBUF+1002 ;GET EXPCTD DATA WORD (0)
BNE 25 ;GET ERROR INFO
;DATA ERROR. IN A PREVIOUS
;TEST A WRITE OF 401 WORDS
; (1 SECTOR + 1 WORD) WAS DONE
45: TST (R2)
BEQ 55
CLR $REG1
JSR PC,ERINF1
ERROR 100

```

E04

```

1957
1958
1959
1960
1961
1962
1963
1964
1965
1966 005670 005205          INC      R5          ;REPORT 12 ERRORS AT MOST
1967 005672 001404          BEQ      6$          ;
1968 005674 005722          TST      (R2)+       ;ALL WORDS CHECKED?
1969 005676 020227 034514   CMP      R2,#DBUF+2000
1970 005702 001363          BNE      4$          ;IF NOT GO BAK
1971
1972 005704 032701 000010   6$:     BIT      #10,R1      ;WERE SECTORS 10,11 READ
1973 005710 001030          BNE      TST3        ;YES
1974 005712 062701 000012   ADD      #12,R1      ;FROM NEW RKDA, SEC 10
1975 005716 000711          BR       1$          ;GO BACK AND READ FROM SECS 10,11
1976
1977
1978
1979
1980
1981
1982
1983 005720 010237 001162   ;ERINF1
1984 005724 011237 001166   ;AT THE TIME OF ENTRY:
1985 005730 010146          ;R2 CONTAINS ERRORING BUS ADDRESS (WHERE DATA ERROR OCCURRED).
1986 005732 020227 033512   ;(R2) CONTAINS BAD DATA THAT WAS READ BACK FROM DISK.
1987 005736 003001          ;R1 CONTAINS DISK ADDRESS WHERE READ BEGAN.
1988 005740 005316          ERINF1: MOV      R2,$REG0      ;GET BUS ADDRESS OF DATA ERROR
1989 005742 005216          MOV      (R2,$REG2      ;GET BAD DATA WORD (READ)
1990 005744 032716 000010   MOV      R1,-(SP)
1991 005750 001405          CMP      R2,#DBUF+776  ;FIGURE OUT THE DISK ADDRESS
1992 005752 032716 000004   BGT      1$          ;WHERE DATA ERROR OCCURRED
1993 005756 001402          DEC      (SP)
1994 005760 062716 000004   1$:     INC      (SP)
1995 005764 012637 001170   BIT      #10,(SP)
1996 005770 000207          BEQ      2$          ;
          BEQ      2$          ;
          BIT      #4,(SP)
          BEQ      2$          ;
          ADD      #4,(SP)
          2$:     MOV      (SP)+,$REG3
          RTS      PC

```

FU4

1997
1998
1999
2000
2001
2002
2003
2004
2005
2006
2007
2008 005772 000004
2009 005774 013701 001502
2010 006000 012737 006020 001110
2011 006006 010102
2012 006010 062702 000021
2013 006014 012703 006001
2014 006020 104416
2015 006022 104420
2016 006024 104416
2017
2018
2019 006026 012737 044444 032514
2020
2021 006034 004737 006304
2022
2023 006040 104101
2024
2025 006042 004737 020112
2026 006046 104102
2027 006050 004737 020126
2028 006054 104103
2029
2030
2031 006056 004737 020230
2032 006062 104105
2033 006064 032701 000020
2034 006070 001006
2035 006072 010201
2036 006074 062702 000020
2037 006100 012703 005401
2038 006104 000745

```
*****  
:TEST 3 PERFORM WRITE OF 12 SECTORS + 1 WORD  
:THIS TEST CHECKS FOR ANOTHER BOUNDARY CONDITION. IT  
:PERFORMS A WRITE OF 12 SECTORS + 1 WORD. RKDA,RKBA,  
:RKWC ARE CHECKED TO SEE IF THEY ARE INCREMENTED CORRECTLY.  
:VALIDITY OF THE DATA WRITTEN IS CHECKED IN THE NEXT  
:TEST. DATA IS WRITTEN ON SECTORS 0-11, SURFACE 0  
:CYLINDER 0 (6001TH WORD ON SECTOR 0, SURFACE 1, CYL 0).  
:ALSO ON SECTORS 0-11, SURFACE 1 (6001TH WORD ON SECTOR  
:0, CYL 1)  
*****  
TST3: SCOPE  
MOV QDRV,R1 ;GET DRIVE #  
MOV #15,$LPERR ;LUP ON ERROR TO '15'  
MOV R1,R2  
ADD #21,R2  
MOV #6001,R3  
15: CON.RESET  
DRV.RESET  
CON.RESET  
  
MOV #44444,DBUF ;PATTERN TO BE WRITTEN  
JSR PC,DOWRITE ;GO DO WRITE  
ERROR 101 ;INTERUPT DID NOT OCCUR ON  
;COMPLETION OF WRITE  
JSR PC,CHKCS ;CHECK IF EROR BIT IN RKCS SET  
ERROR 102 ;EROR BIT IN RKCS SET ON DOING WRITE  
JSR PC,CHKDA ;CHECK IF RKDA INCREMENTED RIGHT  
ERROR 103 ;RKDA DID NOT INCREMENT CORRECTLY  
;AFTER A WRITE OF 6001 (OCTAL) WORDS.  
;(12 SECTORS + 1)  
JSR PC,CHKWC ;CHECK IF RKWC OVERFLOWED TO 0  
ERROR 105 ;RKWC DID NOT OVERFLOW TO 0  
BIT #20,R1 ;WRITTEN ON SURFACE 1?  
BNE TST4 ;YES  
MOV R2,R1  
ADD #20,R2 ;SURFACE 1  
MOV #5401,R3 ;WORD COUNT  
BR 15 ;GO WRITE SURFACE 1
```

334

```
2039
2040
2041
2042
2043
2044
2045
2046
2047 006106 000004
2048 006110 013701 001502
2049 006114 062701 000013
2050 006120 012737 006126 001110
2051 006126 104416
2052 006130 104420
2053 006132 104416
2054
2055 006134 004737 006434
2056
2057
2058
2059 006140 012703 001000
2060
2061 006144 004737 006424
2062 006150 104101
2063
2064 006152 004737 020112
2065 006156 104102
2066 006160 012704 032514
2067 006164 010402
2068 006166 004737 020150
2069 006172 104104
2070 006174 012705 177764
2071 006200 022712 044444
2072 006204 001410
2073 006206 012737 044444 001164
2074 006214 004737 005720
2075 006220 104100
2076
2077
2078
2079
2080
2081
2082 006222 005205
2083 006224 001421
2084 006226 005722
2085 006230 020227 033516
2086 006234 001361
2087 006236 005712
2088 006240 001407
2089 006242 005037 001164
2090 006246 004737 005720
2091 006252 104100
2092
2093
2094
```

```
*****
: *TEST 4 READ & CHECK THAT 6001 WORD WRITE WAS DONE CORRECTLY
: THIS TEST CHECKS THAT THE 6001-WORD WRITE THAT WAS DONE IN THE
: PREVIOUS TEST WAS CORRECT, ESPECIALLY THE LAST 401 WORDS. THE
: FIRST WORD OF THE SECTOR (IN WHICH THE 6001TH WORD) IS WRITTEN
: IS THE ONLY NON-ZERO WORD IN THAT SECTOR, THE REST 377 WORDS ARE
: ALL ZEROS, IF THE WRITING WAS DONE CORRECTLY.
*****
1ST4: SCOPE
MOV QDRV,R1 ;GET DRIVE #
ADD #13,R1 ;DISK ADDRESS FROM WHERE READ IS DONE
MOV #15,$LPERR
1$: CON.RESET
DRV.RESET
CON.RESET
JSR PC,CLEANBUF ;CLEAN UP THE BUFFER INTO WHICH
;READ WILL BE DONE
;SET UP RKDA
;SECTOR 11, SURFACE 0
;WORD COUNT
MOV #1000,R3
JSR PC,DORREAD ;GO READ 1000 WORDS (2 SECS)
ERROR 101 ;INTERRUPT DID NOT OCCUR AFTER
;COMPLETION OF READ
JSR PC,CHKCS ;CHECK IF ERROR BIT IN RKCS SET
ERROR 102 ;ERROR (RKCS) SET ON DOING READ
MOV #DBUF,R4 ;STARTING BA OF DATA BUFFER
MOV R4,R2
JSR PC,CHKBA ;RKBA INCREMENTED CORRECTLY?
ERROR 104 ;RKBA DID NOT INCREMENT CORRECTLY
MOV #-14,R5
2$: CMP #44444,(R2) ;DATA WORD OK?
BEQ 3$
MOV #44444,$REG1 ;NO, GET EXPTD DATA WORD
JSR PC,ERINF1 ;GET OTHER ERROR INFO
ERROR 100 ;DATA ERROR. A WRITE OF 6001
;WORDS (12 SECS + 1 WORD) WAS DONE
;IN A PREVIOUS TEST. THE LAST TWO
;SECTORS (LAST 401 WORDS) WERE READ
;BACK. THIS ERROR INDICATES THAT
;SEC #11 (LAST BUT ONE SECTOR) GAVE
;BAD DATA WORDS
;REPORT 12 ERRORS AT MOST
INC R5
3$: BEQ 6$
TST (R2)+ ;INCREMENT POINTER TO BA
CMP R2,#DBUF+1002 ;CHECKED 401 WORDS?
BNE 2$
4$: TST (R2) ;CHECK THAT THE REMAINING 377
;WORDS OF THE LAST SECTOR (SEC #0)
;WERE READ BACK AS 0'S
CLR $REG1
JSR PC,ERINF1
ERROR 100 ;DATA ERROR. IF WRITE WAS DONE CORRECTLY
;IN THE PREVIOUS TEST, THE LAST SECTOR
;OF THE DATA BLOCK (12 SECS + 1 WORD)
;SHOULD CONTAIN ONLY 1 (FIRST) WORD
```

2095
2096
2097
2098
2099
2100
2101
2102
2103
2104
2105
2106
2107
2108

006254 005205
006256 001404
006260 005722
006262 020227 034514
006266 001363

006270 032701 000020
006274 001070
006276 062701 000020
006302 000711

SS:

SS:

INC R5
BEQ 6\$
TST (R2)+
CMP R2, #DBUF+2000
BNE 4\$

BIT #20,R1
BNE TST\$
ADD #20,R1
BR 1\$

:AS NON-ZERO, THE REST 377 SHOULD BE
:ALL 0'S. THIS ERROR INDICATES
:THE SOME OF 377 WORDS
:WERE NOT CORRECT
:REPORT 12 ERRORS AT MOST

:INCREMENT POINTER
:CHECKED ALL WORDS?
:NO

:DONE CHECKING FOR SURFACE 1?
:YES
:SO SET UP FOR SURFACE 1
:GO BACK & READ SURFACE 1

```

2109 :DOWRITE
2110 :THIS ROUTINE PERFORMS A WRITE ON A DISK AT THE TIME OF ENTRY. R1 CONTAINS
2111 :DISK ADDRESS (RKDA) WHERE WRITE IS TO BE DONE. R3 CONTAINS THE WORD COUNT
2112 : (RKWC), 'DBUF' CONTAINS THE DATA TO BE WRITTEN. NOTE IBA BIT IS SET.
2113
2114 ,WRITE IS DONE IN INTERRUPT MODE. IF THE INTERRUPT DOES NOT OCCUR WITHIN
2115 :A CERTAIN TIME, RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE 'JSR'
2116 :CALL. IF THE INTERRUPT OCCURS, RETURN ADDRESS IS ADJUSTED TO SKIP OVER
2117 :THE ERROR MESSAGE.
2118
2119 006304 012777 004002 172710 DOWRITE: MOV #4002,2RKCS ;WRITE, IBA
2120 006312 010177 172712 DOXFER: MOV R1,2RKDA ;ADDRESS THE DRIVE
2121 006316 010377 172702 MOV R3,2RKWC ;XFER THIS # OF WORDS
2122 006322 005477 172676 NEG 2RKWC
2123 006326 012777 032514 172672 MOV #DBUF,2RKBA ;USE THIS BUS ADDRESS
2124 006334 012777 006414 172676 MOV #35,2RKVEC ;SET UP INTERRUPT VECTOR
2125 006342 005046 CLR -(SP) ;NEW PSW
2126 006344 012746 006352 MOV #15,-(SP) ;SET NEW PC TO STACK *****
2127 006350 000002 RTI
2128 006352 052777 000101 172642 15: BIS #101,2RKCS ;SET IDE, GO (WRITE,IBA/ READ
2129 006360 005037 001466 CLR C1CNT
2130 006364 012737 177760 001470 MOV #-20,C1CNT1
2131 006372 005237 001466 25: INC C1CNT ;WAIT FOR INTERRUPT
2132 006376 001375 BNE .-4
2133
2134 006400 005237 001470 INC C1CNT1
2135 006404 001372 BNE 25
2136
2137 006406 004737 022032 JSR PC,GT4RG ;TIMED OUT, INTERRUPT DID NOT OCCUR
2138 006412 000207 RTS PC ;RETURN TO THE EROR MEASGE
2139
2140 006414 022626 35: CMP (SP)+,(SP)+ ;RESTORE STACK POINTER
2141 006416 062716 000002 ADD #2,(SP) ;ADJUST RETURN ADDRESS TO SKIP OVER
2142 006422 000207 RTS PC ;EROR MESAGE ON RETURN
  
```


2143
2144
2145
2146
2147
2148
2149
2150
2151
2152
2153
2154
2155
2156
2157
2158
2159
2160
2161
2162
2163
2164
2165
2166
2167
2168

006424 012777 000004 172570
006432 000727

006434 012702 177000
006440 012705 032514
006444 012725 022222
006450 005202

006452 001374
006454 000207

; THIS ROUTINE PERFORMS A READ ON THE DISK AT THE TIME OF ENTRY R1 CONTAINS
; THE DISK ADDRESS FROM WHERE THE READ IS TO BE DONE. R3 CONTAINS THE WORD
; COUNT (RKWC). READ WILL BE DONE INTO DATA BUFFER AT 'DBUF'.

; READ IS DONE IN INTERRUPT MODE. IF THE INTERRUPT DOES NOT OCCUR WITHIN
; A CERTAIN TIME, RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE 'JSR'
; CALL. IF THE INTERRUPT OCCURS AS EXPECTED, RETURN ADDRESS IS ADJUSTED
; TO SKIP OVER THE ERROR MESSAGE.

DORAD: MOV #4, R2 ; READ
BR DOXFER

; CLEANBUF
; CLEANS OUT THE DATA BUFFER (ALL WORDS WRITTEN TO 177777) INTO WHICH THE
; READ FROM THE DISK WILL BE DONE. DATA BUFFER STARTS AT 'DBUF' AND IS
; 1000 (OCTAL) WORDS LONG.

CLEANBUF: MOV #-1000, R2 ; SET COUNT
MOV #DBUF, R5 ; INITIALIZE BA
15: MOV #22222, (R5)+
INC R2 ; DONE ALL WORDS?
; BUFFER STARTING AT (PHYSICAL) BUS
; ADDRESS 177000 (177000-200776).

BNE 15
RTS PC ; YES RETURN

2169
2170
2171
2172
2173
2174
2175
2176
2177
2178
2179
2180
2181 006456 000004
2182 006460 023727 017772 002000
2183 006466 103002
2184 006470 000137 007040
2185 006474 012737 001600 172352
2186 006502 012737 002000 172354
2187 006510 012737 000001 177572
2188
2189
2190
2191
2192
2193
2194
2195
2196 006516 012737 006524 001110
2197 006524 104416
2198 006526 104420
2199
2200 006530 012700 000001
2201
2202 006534 012701 137000
2203 006540 010021
2204 006542 005200
2205 006544 020027 001001
2206 006550 001373
2207 006552 013777 001502 172450
2208 006560 012777 177000 172436
2209 006566 012777 177000 172432
2210 006574 012777 000003 172420
2211 006602 104417
2212
2213 006604 004737 020112
2214 006610 104102
2215
2216
2217
2218 006612 004737 020204
2219
2220
2221
2222
2223 006616 104106
2224

```
*****  
: TEST 5 CHECK DATA TRANSFER AROUND 32K BOUNDARY  
: *THIS TEST PERFORMES A WRITE OF 2 SECTORS ON THE DISK FROM MEMORY  
: *LOCATIONS AROUND THE 32K BOUNDARY. SECTORS 0,1 CYL 0, SURFACE  
: *0 ARE WRITTEN. PHYSICAL BUS ADDRESSES FOR THE DATA BUFFER:  
: * 177000 TO 200776 I.E. (32K-256) TO (32K+255)  
  
: *CHECKING IS DONE TO SEE IF MEX BITS, RKBA, RKDA, RKWC INCREMENTED  
: *CORRECTLY. THEN DATA BUFFER IS CLEARED OUT AND A READ IS DONE  
: *INTO IT. A CHECK IS MADE TO SEE IF THE CORRECT DATA WAS RECIEVED.  
: *ONLY 12 DATA ERRORS ARE REPORTED.  
*****  
: TESTS: SCOPE  
: CMP $LSTBK, #2000 ;33K OR MORE OF MEMORY?  
: BHIS 1$ ;YES  
: JMP TST6 ;IF NOT, DONT DO THIS TEST  
1$: MOV #1600, #KIPAR5 ;MAP 28-32K THRU PAR 5  
: MOV #2000, #KIPAR6 ;MAP 32-36K THRU PAR 6  
: MOV #1, #SRO ;TURN ON MEMORY MANAGEMENT  
  
: SET UP DATA BUFFER (1000 OCTAL WORDS LONG) FOR WRITING TWO SECTORS  
: ON THE DISK. THE TRANSFER IS DONE AROUND THE 32K BOUNDARY FROM  
: BUS ADDRESS (PHYSICAL) 177000 TO 200776, (32K-256) TO (32+256)  
  
: DATA IN THE BUFFER IS A COUNT PATTERN STARTING FROM 1 FOR THE FIRST  
: WORD TO 000 FOR THE LAST WORD.  
: PHYSICAL BUFFER ADDRESS: 177000 TO 200776 (32K-256 TO 32K+256)  
2$: MOV #2$, $LPERR ;LUP TO 2$ ON EROR (SW 9)  
: CON.RESET  
: DRV.RESET  
  
: MOV #1, RO ;INITIALIZE DATA PATTERN TO BE  
: WRITTEN  
3$: MOV #137000, R1 ;BA TO START PHYSICAL ADDRESS=177000  
: MOV RO, (R1)+ ;WRITE COUNT PATTERN (1-1000)  
: INC RO ;INTO DATA BUFFER (PHYS ADDRES  
: CMP RO, #1001 ;177000 TO 200776)  
: BNE 3$  
: MOV QDRV, #RKDA ;SUR 0, SEC 0, CYL 0  
: MOV #-1000, #RKWC ;WORD COUNT =2 SECS  
: MOV #177000, #RKBA ;BUS ADDRESS.  
: MOV #3, #RKCS ;WRITE, GO  
: CON.RDY ;WAIT FOR CNTROL RDY  
  
: JSR PC, #CHKCS ;ANY EROR IN RKCS?  
: ERROR 102 ;'ERR' SET IN RKCS, ON DOING A  
: WRITE OF SECTORS (0,1) FROM  
: (PHYSICAL) BUS ADDRESS 177000  
: (177000 TO 200776)  
  
: JSR PC, #CHKMEX ;CHECK THAT RKBA OVERFLOWED INTO  
: EXTENDED MEM. BIT (0) OF RKCS (BIT 4)  
: EX MEM BIT 0 SET?  
: GET RKCS, ER, OS, DA  
: MEX BITS INCORRECT, BIT 4 OF RKCS  
: (MEX BIT 0) SHOULD HAVE SET
```

2225											;	AFTER RKBA OVERFLOWED ON DOING
2226											;	A TRANSFER OF 2 SECTORS FROM BUS
2227											;	ADDRESS (PHYSICAL) STARTING AT 177000
2228	006620	012703	001600								;	WORD COUNT
2229	006624	012704	177000								;	STARTING BUS ADDRESS
2230	006630	004737	020150								;	CHECK IF RKBA INCREMENTED CORRECTLY
2231	006634	104104									;	RKBA DID NOT INCREMENT CORRECTLY
2232											;	AFTER WRITE OF 2 SECTORS FROM A DATA
2233											;	BUFFER STARTING AT (PHYSICAL) BUS
2234											;	ADDRESS (177000-200776)
2235	006636	013702	001502								;	GET EXPECTED
2236	006642	062702	000002								;	DISK ADDRESS
2237	006646	004737	020126								;	CHECK IF RKDA INCREMENTED CORRECTLY
2238	006652	104103									;	RKDA INCREMENTED WRONGLY AFTER
2239											;	A WRITE OF 2 SECTOR (0,1) FROM
2240											;	DATA BUFFER STARTING AT BUS
2241											;	ADDRESS (PHYSICAL) 177000.
2242												
2243	006654	004737	020230								;	CHECK IF RKWC OVERFLOWED CORRECTLY
2244	006660	104105									;	RKWC DID NOT OVERFLOW TO 0 ON
2245											;	DOING A WRITE OF 2 SECTORS FROM
2246											;	BA = 177000
2247												
2248											;	NOW, READ IS DONE OF THE DATA
2249											;	THAT WAS WRITTEN TO SEE IF IT
2250											;	CAN BE READ CORRECTLY
2251												
2252	006662	012737	006670	001110							;	LUP TO 4\$ ON EROR (SW 9)
2253	006670	104416			4\$:							
2254	006672	104420										
2255												
2256	006674	012701	137000								;	CLEAR THE 1000-WORD DATA
2257	006700	005021			5\$:						;	BUFFER (PA 177000 TO 200776)
2258	006702	020127	141000								;	ALL DONE?
2259	006706	001374										
2260												
2261											;	NOW, READ BACK INTO THE
2262											;	SAME BUFFER 2 SECTORS
2263											;	WRITTEN PREVIOUSLY
2264												
2265	006710	013777	001502	172312							;	ADDRESS THE DRIVE CYL 0, SEC 0, 0
2266	006716	012777	177000	172300							;	READ 2 SECTORS
2267	006724	012777	177000	172274							;	INTO THIS BUS ADDRESS
2268	006732	012777	000005	172262							;	READ, GO
2269												
2270	006740	104417									;	WAIT FOR CTRL RDY
2271												
2272	006742	004737	020112								;	ANY ERROR IN RKCS?
2273	006746	104102									;	ERROR BIT SET IN RKCS ON DOING
2274											;	A READ OF 2 SECTORS (0,1), CYL 0,
2275											;	SUR 0, INTO DATA BUFFER STARTING
2276											;	AT BUS ADDRESS 177000, NOTE AFTER
2277											;	177776, RKBA WILL OVERFLOW (0)
2278											;	INTO MEX BITS (BIT 4) OF RKCS.
2279											;	IF THE ENTIRE TRANSFER (1000 WORD)
2280											;	WAS DONE RKBA WILL CONTAIN 1000

```

2281 ;AND BIT 4 OF RKCS (MEX) WILL BE SET.
2282
2283 006750 012705 177764 6$: MOV #14,R5 ;REPORT ONLY 12 ERRORS.
2284 006754 012702 137000 MOV #137000,R2 ;STARTING ADDRESS OF BUFFER
2285 ;(PA=177000)
2286 006760 012701 000001 MOV #1,R1 ;INITIALIZE DATA PATTERN
2287
2288 006764 020112 7$: CMP R1,(R2) ;CORRECT DATA WORD RECVD?
2289 006766 001414 BEQ #5 ;REPORT THIS ERROR?
2290 006770 005705 TST R5
2291 006772 001420 BEQ #9 ;COUNT ERORS
2292 006774 005205 INC R5
2293
2294 006776 010137 001162 MOV R1,$REG0 ;GET EXPCTED DATA WORD
2295
2296 007002 011237 001164 MOV (R2),$REG1 ;GET DATA WORD RECVD
2297 007006 104107 ERROR 107 ;DATA COMPARISON ERROR ON DOING A
2298 ;READ OF 2 SECTORS (0,1, CYL 0, SURFACE 0
2299 ;INTO DATA BUFFER (PHYSICAL ADDRESS
2300 ;177000 TO 200776)
2301
2302 007010 104421 002214 TYPMSG MSG13 ;TYPE 'PHYSICAL BUS ADDRESS'
2303 007014 004737 017774 JSR PC,TYPDB0 ;TYPE THE 6 DIGIT PHYSICAL BUS ADDRESS
2304 ;WHERE THE DATA ERROR OCCURRED.
2305
2306 007020 062702 000002 8$: ADD #2,R2 ;INCREMENT POINTER TO BA
2307 007024 005201 INC R1
2308 007026 022701 001001 CMP #1001,R1 ;CHECKED THE ENTIRE BUFFER?
2309 007032 001354 BNE #7
2310
2311 ;**OFF
2312 007034 005037 177572 9$: CLR @#SR0 ;TURN OFF MEMORY MANAGEMENT

```

```

2313 ::*****
2314 :*TEST 6 CHECK DATA TRANSFER FROM 28K TO 32K
2315 ;*THIS TEST DOES A WRITE OF 4K WORDS FROM A BUFFER LOCATED AT 28K
2316 ;*THEN THE DATA IS READ BACK INTO THE SAME BUFFER(28K-32K) AND IS
2317 ;*CHECKED TO SEE IF IT IS CORRECT. NOTE THAT THE BUFFER IS FILLED
2318 ;*WITH ALL 1'S BEFORE DOING THE READ.
2319
2320 ;*THE WRITE IS DONE STARTING AT CYLINDER 0, SECTOR 0, SURFACE 0.
2321 ::*****
2322 007040 000004 †ST6: SCOPE
2323
2324 007042 023727 017772 001740 CMP $LSTBK,#1740 ;32K OR MORE OF MEMORY?
2325 007050 103002 BHIS 1$ ;YES
2326 007052 000137 007374 JMP TST7 ;IF NOT, DONT DO THIS TEST
2327 007056 012737 001600 172352 1$: MOV #1600,#KIPARS ;MAP 28-32K THRU PAR 5
2328 007064 012737 000001 177572 MOV #1,#SRO ;TURN ON MEM MANAGEMENT
2329
2330 ;WRITE A COUNT PATTERN (1-10000) INTO DATA BUFFER (PHYSICAL ADDRESS
2331 ;160000-177776). THIS DATA BUFFER WILL BE USED FOR WRITING ON THE DISK.
2332
2333 007072 012737 007100 001110 2$: MOV #2$,$LPERR ;LUP TO 2$ ON EROR
2334 007100 104416 CON.RESET
2335 007102 104420 DRV.RESET
2336 007104 012700 000001 MOV #1,R0 ;INITIALIZE DATA PATTERN TO BE WRITTEN
2337 007110 012701 120000 MOV #120000,R1 ;INITIALIZE BA (PA=160000) 28K
2338 007114 010021 3$: MOV R0,(R1)† ;WRITE COUNT PATTERNS (1-10000)
2339 007116 005200 INC R0 ;INTO DATA BUFFER (PA 160000 TO
2340 007120 020027 010001 CMP R0,#10001 ;177776, 28K-32K)
2341 007124 001373 BNE 3$
2342
2343 007126 013777 001502 172074 MOV QDRV,$RKDA ;WRITE ON SEC 0, CYL 0, SUR1
2344 007134 012777 170000 172062 MOV #-10000,$RKWC ;4K WORDS
2345 007142 012777 160000 172056 MOV #160000,$RKBA ;FROM THIS BUS ADDRESS
2346 007150 012777 000003 172044 MOV #3,$RKCS ;WRITE, GO
2347
2348 007156 104417 CON.RDY ;WAIT FOR CONTROL READY
2349
2350 007160 004737 020112 JSR PC,CHKCS ;ANY ERROR IN RKCS?
2351 007164 104102 ERROR 102 ;'ERR' BIT SET IN RKCS ON DOING
2352 ;A WRITE OF 4K WORDS FROM 160000
2353 ;(28K-32K). DISK WRITE BEGAN ON
2354 ;SEC 0, CYL 0, SUR 0. IF ALL 4K
2355 ;WORDS WERE WRITTEN RKBA SHOULD OVERFLOW
2356 ;AND CONTAIN 0. BIT 4 OF RKCS
2357 ;(MEX BIT) SHOULD BE 1
2358
2359 007166 004737 020204 JSR PC,CHKMEX ;CHECK IF RKBA OVERFLOWED AND MEX
2360 ;BITS (4) IN RKCS WAS SET.
2361 007172 104106 ERROR 106 ;MEX BIT 4 NOT SET AFTER OVERFLOW OF
2362 ;RKBA. WRITE OF 4K WORDS (28K-32K) WAS DONE.
2363
2364 ;RETURN HERE IF NO ERROR
2365 007174 012703 010000 MOV #10000,R3 ;WORD COUNT
2366 007200 012704 160000 MOV #160000,R4 ;STARTING BUS ADDRESS
2367 007204 004737 020150 JSR PC,CHKBA ;CHECK IF RKBA INCREMENTED CORRECTLY
2368 007210 104104 ERROR 104 ;RKBA DID NOT OVERFLOW TO AFTER A WRITE IF 4K

```

605

```

2369 ;WORDS (160000 TO 177776)
2370
2371 007212 004737 020230 JSR PC,CHKWC ;CHECK RKWC OVERFLOWED CORRECTLY
2372 007216 104105 ERROR 105 ;RKWC DID NOT OVEFLOW TO 0
2373 ;AFTER A WRITE OF 4K WORD (160000
2374 ;TO 177776)
2375
2376
2377 007220 012737 007226 001110 45: MOV #45,$LPERR ;RETURN ADDRESS FOR LUPING
2378 007226 104416 CON.RESET
2379 007230 104420 DRV.RESET
2380
2381 007232 012701 120000 55: MOV #120000,R1 ;CLEAR THE DATA BUFFER BEFORE
2382 007236 005021 CLR (R1)+ ;DOING A READ INTO IT
2383 007240 022701 140000 CMP #140000,R1
2384 007244 001374 BNE 55
2385
2386 007246 013777 001502 171754 MOV QDRV,$RKDA ;READ FROM SEC 0, SUR 0, CYL 0
2387 007254 012777 170000 171742 MOV #-10000,$RKWC ;4K WORDS
2388 007262 012777 160000 171736 MOV #160000,$RKBA ;INTO THIS BUS ADDRESS
2389
2390 007270 012777 000005 171724 MOV #5,$RKCS ;READ, GO
2391 007276 104417 CON.RDY ;WAIT FOR CNTROL RDY
2392
2393 007300 004737 020112 JSR PC,CHKCS ;ANY ERROR IN RKCS?
2394 007304 104102 ERROR 102 ;ERROR BIT SET IN RKCS ON DOING
2395 ;A READ OF 4K WORDS INTO MEMORY
2396 ;(160000-177776)
2397 007306 012705 177764 MOV #-14,R5 ;REPORT 12 ERRORS AT MOST
2398 007312 012702 120000 MOV #120000,R2 ;STARTING ADDRESS OF BUFFER
2399 ;(PA=160000)
2400 007316 012701 000001 MOV #1,R1 ;INITIALIZE DATA PATTERN
2401
2402 007322 020112 65: CMP R1,(R2) ;CORRECT DATA WORD?
2403 007324 001413 BEQ 75
2404 007326 010137 001162 MOV R1,$REG0 ;GET EXPCTD DATA WORD
2405 007332 011237 001164 MOV (R2),$REG1 ;GET DATA WORD RECVD
2406 007336 104107 ERROR 107 ;DATA ERROR ON DOING A READ OF
2407 ;4K WORDS STARTING FROM SEC 0,
2408 ;CYL 0, SUR 0 INTO MEMORY (160000-
2409 ;177776)
2410 007340 104421 002214 TYPMSG MSG13 ;TYPE 'PHYSICAL BUS ADDRESS'
2411 007344 004737 017774 JSR PC,TYPDBO ;TYPE OUT THE PHYSICAL BUS ADDRESS
2412 ;WHERE DATA
2413 007350 005205 INC R5 ;ERROR OCCURRED. R2 CONTAINS
2414 007352 001406 BEQ 85 ;THE VIRTUAL ADDRESS
2415
2416 007354 062702 000002 75: ADD #2,R2 ;POINTER TO NEXT BA
2417 007360 005201 INC R1 ;NEXT PATTERN
2418 007362 022701 001000 CMP #1000,R1 ;ALL DONE?
2419 007366 001355 BNE 65 ;NO
2420
2421 007370 005037 177572 85: CLR $SR0 ;TURN OFF MEM MANAGEMENT

```


005

2478											
2479	007514	053702	001502		XFR:	BIS	QDRV,R2			:ADD THE DRIVE # TO	
2480										:EXPCD RKDA AFTER XFER	
2481	007520	012737	007526	001110		MOV	#15,\$LPERR			:LUP BAK TO '15' ON ERROR	
2482										: (SW 9)	
2483	007526	104416			1\$:	CON.RESET					
2484	007530	104420				DRV.RESET					
2485	007532	013777	001502	171470		MOV	QDRV,ARKDA			:ADDRESS THE DRIVE, CYL 0,SUR 0,	
2486										:SEC 0	
2487	007540	010377	171460			MOV	R3,ARKWC				
2488	007544	005477	171454			NEG	ARKWC			:WORD COUNT (IF MORE THAN	
2489										:20K IS AVAILABLE A TRANSFER	
2490										:OF 20K WILL BE DONE, IF	
2491										:LESS THAN 20K, THE	
2492										:LARGEST TRANSFER WITHIN THE	
2493										:AVAILABLE MEMORY WILL	
2494										:BE DONE. IN BOTH	
2495										:CASES, DATA TRANSFER	
2496										:WILL BE DONE STARTING	
2497										:AT 'PGEND'	
2498	007550	012777	032514	171450		MOV	#PGEND,ARKBA			:START WRITE FROM HERE	
2499	007556	012777	000003	171436		MOV	#3,ARKCS			:WRITE, GO	
2500											
2501	007564	104417				CON.RDY				:WAIT FOR CONTROL READY	
2502											
2503	007566	004737	020112			JSR	PC,CHKCS			:CHK RKCS FOR ERROR?	
2504	007572	104102				ERROR	102			:ERROR BIT SET IN RKCS ON	
2505										:DOING A LARGE 'WRITE'	
2506											
2507	007574	004737	020126			JSR	PC,CHKDA			:CHECK IF RKDA INCREMENTED CORRECTLY?	
2508	007600	104103				ERROR	103			:RKDA DID NOT INCREMENT	
2509										:CORRECTLY	
2510											
2511	007602	012704	032514			MOV	#PGEND,R4				
2512	007606	004737	020150			JSR	PC,CHKBA			:CHECK THAT RKBA INCREMENTED	
2513										:CORRECTLY?	
2514	007612	104104				ERROR	104			:RKBA DID NOT INCREMENT	
2515										:CORRECTLY	
2516											
2517	007614	004737	020230			JSR	PC,CHKWC			:CHECK THAT RKWC OVERFLOWED	
2518	007620	104105				ERROR	105			:RKWC DID NOT OVERFLOW TO	
2519										:ZERO AFTER A WRITE	
2520											
2521	007622	012737	007630	001110		MOV	#25,\$LPERR			:LUP BAK TO '25' ON EROR (SW 9)	
2522	007630	104416			2\$:	CON.RESET					
2523	007632	104420				DRV.RESET					
2524	007634	013777	001502	171366	3\$:	MOV	QDRV,ARKDA			:ADDRESS THE DRIVE, CYL 0,SEC 0,SJR 0	
2525	007642	010377	171356			MOV	R3,ARKWC				
2526	007646	005477	171352			NEG	ARKWC				
2527	007652	012777	032514	171346		MOV	#PGEND,ARKBA			:STARTING BA	
2528											
2529	007660	012777	000407	171334	4\$:	MOV	#407,ARKCS			:WRITE CHECK, SSE, GO	
2530											
2531	007666	104417				CON.RDY				:WAIT FOR CONTROL RDY	
2532											
2533	007670	004737	020112			JSR	PC,CHKCS			:ANY ERROR IN RKCS	


```

2534 007674 104102          ERROR 102
2535
2536 007676 032777 040000 171316          BIT  #BIT14,ARKCS ;SKIP CHECKING FOR WCE IF HE SET
2537 007704 001030          BNE  7$
2538 007706 032777 000001 171304 5$:          BIT  #WCE,ARKER ;WRITE CHECK ERROR?
2539 007714 001406          BEQ  6$ ;NO
2540
2541 007716 004737 022032          JSR  PC,GT4RG ;GET RKCS,ER,DS,DA
2542 007722 017737 171300 001166          MOV  ARKBA,SREG2
2543 007730 104110          ERROR 110 ;WRITE CHECK ERROR. RKDA GIVES THE DISK ADDRESS
2544 ;WHERE WCE OCCURRED. (NOTE THE SECTOR IN
2545 ;ERROR IS OBTAINED BY BACKING OFF 1 SECTOR).
2546 ;NOTE THAT THE DATA BUFFER WHICH WAS WRITE
2547 ;CHECKED IS NOT ON A SECTOR BOUNDARY
2548 ;(LIKE 256, 512 WORD ETC.), BUT IS SOME
2549 ;SECTORS & A FRACTION (LIKE 300 WORDS ETC.)
2550
2551 007732 005777 171266          6$: TST  ARKWC ;WAS THE ENTIRE DATA BUFFER
2552 007736 001413          BEQ  7$ ;WRITE CHECKED?
2553
2554 007740 017705 171260          MOV  ARKWC,R5
2555 007744 042705 177760          BIC  #177760,R5 ;FORM THE RKBA AND RKWC
2556 007750 006305          ASL  R5
2557 007752 160577 171250          SUB  R5,ARKBA ;TO BE USED FOR DOING
2558 ;WRITE-CHECK IF THE REST
2559 007756 042777 000017 171240          BIC  #17,ARKWC ;OF THE DATA BUFFER
2560
2561 007764 000735          BR   4$ ;GO DO WRT-CHK FOR
2562 ;REST OF THE BUFFER
2563
2564 ;GO CHECK THE REST OF THE DRIVES.
2565
2566 00776E 000137 00536E          7$: JMP  NXTDRV
  
```

```

2567 .SBTTL EXERCISER PROGRAM
2568
2569 ;BEGINING OF THE EXERCISER PART OF THE PROGRAM.
2570 ;IF THE PROGRAM WAS RESTARTED AT 210, THEN THE STATISTICS COLLECTED
2571 ;SO FAR WILL NOT BE CLEARED.
2572
2573
2574 007772 104416 EXRC5R: CON.RESET
2575 007774 012700 001306 1$: MOV #KEY,RO ;CLEAR UP THE LOCATIONS FROM
2576 010000 005020 CLR (RO)+ ;'KEY' TO 'KWHR' (EXCLUDED)
2577 010002 020027 001552 CMP RO,#KWHR
2578 010006 001374 BNE 1$
2579 010010 105737 001253 TSTB FRSTRT ;RESTARTED AT 210?
2580 010014 001045 BNE 3$ ;YES, SAVE THE STATISTICS COLLECTED
2581 ;UPTILL NOW, DONT CLEAR THEM
2582
2583 010016 005020 2$: CLR (RO)+ ;CLEAR LOCATIONS FROM 'HECN'
2584 010020 020027 002032 CMP RO,#PCMD ;TO 'PCMD' (EXCLUDED)
2585 010024 001374 BNE 2$
2586
2587 010026 012700 001554 MOV #KWMIN,RO ;INITIALIZE COUNTS FOR MINS,
2588 010032 012701 177704 MOV #-60.,R1 ;SECS, KW11
2589 010036 010120 MOV R1,(RO)+
2590 010040 010120 MOV R1,(RO)+
2591 010042 010120 MOV R1,(RO)+
2592
2593 010044 012700 025730 MOV #RSDRVL,RO ;INITIALIZE PTR TO RANDOM NO. SEEDS
2594 010050 012720 123456 MOV #123456,(RO)+ ;USED BY THE RANDOM NUMBER GENERATOR
2595 010054 012720 176543 MOV #176543,(RO)+ ;SET UP RANDOM NUMBER SEEDS TO BE
2596 010060 012720 001201 MOV #1201,(RO)+
2597 010064 012720 062465 MOV #62465,(RO)+
2598 010070 012720 176105 MOV #176105,(RO)+
2599 010074 012720 174532 MOV #174532,(RO)+
2600 010100 012720 157650 MOV #157650,(RO)+
2601 010104 012720 030753 MOV #30753,(RO)+
2602 010110 012720 131547 MOV #131547,(RO)+
2603 010114 012720 032070 MOV #32070,(RO)+
2604 010120 012720 123456 MOV #123456,(RO)+
2605 010124 012720 176543 MOV #176543,(RO)+
2606
2607
2608 010130 005227 177777 3$: INC #-1 ;FIRST PASS?
2609 010134 001004 BNE 4$ ;BRANCH IF NOT
2610 010136 012737 000062 002056 MOV #50.,REPCNT ;SET UP SHORT REPITITION COUNT
2611 ;FOR FIRST PASS.
2612 010144 000403 BR 5$
2613 010146 013737 001236 002056 4$: MOV PCNTR,REPCNT ;REPETITION COUNT. WHEN THIS COUNT GOES
2614 ;TO 0, IT'S CONSIDERED TO BE AN END OF PASS.
2615 ;THE NEXT PASS WILL START WILL START RIGHT
2616 ;FROM WHERE THE EXERCISER LEFT OFF.
2617
2618 010154 004737 022656 5$: JSR PC,CHDPRS ;CHECK IF ANY DRIVES ARE PRESENT
2619 ;IF NONE, GO TO $EOP. END OF PASS
2620
2621
2622

```

GUS

2623									
2624	010160	012746	177777		MOV	#177777,-(SP)		:	PUT LOW DIVIDEND ON STACK
2625	010164	005046			CLR	-(SP)		:	CLEAR HIGH DIVIDEND AND PUSH
2626								:	IT ON STACK
2627	010166	013746	001264		MOV	DRVPR5,-(SP)		:	PUSH DIVISOR ON STACK
2628	010172	004737	025212		JSR	PC,2#SDIV		:	GO TO THE 'DIVIDE' SUBROUTINE
2629	010176	005726			TST	(SP)+		:	DISCARD THE REMAINDER. QUOTIENT IS
2630								:	NOW ON TOP OF THE STACK
2631	010200	012637	001520		MOV	(SP)+,DRMAP		:	GET MAPPING FACTOR FOR DRIVES
2632	010204	012737	000504	001522	MOV	#504,CYLMAP		:	GET MAPPING FACTOR FOR CYLINDERS
2633	010212	012737	012527	001524	MOV	#5463.,SECMAP		:	GET MAPPING FACTOR FOR SECTORS
2634	010220	012737	031463	001526	MOV	#13107.,FNMAP		:	GET MAPPING FACTOR FOR FUNCTION
2635									
2636	010226	013700	002054		MOV	MAXBA,RO		:	COMPUTE THE MAXIMUM ALLOWABLE
2637	010232	163700	002052		SUB	BASEBA,RO		:	WORD COUNT FOR DATA TRANSFERS
2638	010236	000241			CLC				
2639	010240	006000			ROR	RO		:	CONVERT TO WORDS
2640									
2641	010242	012746	177777		MOV	#177777,-(SP)		:	PUT LOW DIVIDEND ON STACK
2642	010246	005046			CLR	-(SP)		:	CLEAR HIGH DIVIDEND AND PUSH
2643								:	IT ON STACK
2644	010250	010046			MOV	RO,-(SP)		:	PUSH DIVISOR ON STACK
2645	010252	004737	025212		JSR	PC,2#SDIV		:	GO TO THE 'DIVIDE' SUBROUTINE
2646	010256	005726			TST	(SP)+		:	DISCARD THE REMAINDER. QUOTIENT IS
2647								:	NOW ON TOP OF THE STACK
2648	010260	005216			INC	(SP)			
2649	010262	012637	001530		MOV	(SP)+,BAMAP		:	SAVE THE MAPPING FACTOR FOR BUS ADDRESS

AUS

2650
2651
2652
2653
2654
2655
2656
2657
2658
2659
2660
2661
2662
2663
2664
2665
2666
2667
2668
2669
2670
2671
2672
2673
2674
2675
2676
2677
2678
2679
2680
2681
2682
2683
2684
2685
2686
2687
2688
2689
2690
2691
2692
2693
2694
2695
2696
2697
2698
2699
2700
2701
2702
2703
2704
2705

010266 105737 001253
 010272 001407
 010274 105037 001253
 010300 032777 000020 170632
 010306 001401
 010310 000540
 010312 012737 010330 001110
 010320 012702 001254
 010324 013703 001264
 010330 012700 011410
 010334 112201
 010336 042701 177770
 010342 010137 001502
 010346 000241
 010350 006001
 010352 006001
 010354 006001
 010356 006001
 010360 010177 170644
 010364 013704 002054
 010370 163704 002052
 010374 006204
 010376 042704 000377
 010402 000304
 010404 020427 000014
 010410 003402
 010412 012704 000014
 010416 010401
 010420 020400
 010422 003401
 010424 010001
 010426 000301
 010430 005401
 010432 010137 010446
 010436 010177 170562
 010442 004537 016704
 010446 000000
 010450 032514
 010452 012777 032514 170546
 010460 012777 000003 170534
 010466 104417
 010470 004737 020112
 010474 104001

: THE ENTIRE DISK (ALL DRIVES) IS WRITTEN WITH RANDOM PATTERNS. THE FIRST
 : WORD OF EACH SECTOR GIVES THE NUMBER OF WORDS (2'S COMPLEMENT) WRITTEN IN
 : THAT SECTORS. REST OF THE DATA WORDS FOR THE SECTOR ARE GENERATED USING
 : THE ABSOLUTE DISK ADDRESS AS THE RANDOM SEED.
 : IF THE PROGRAM WAS RESTARTED AT 210 THEN CHECK IF SW 4 IS SET. IF IT IS
 : THEN DO NOT REWRITE THE DISK WITH RANDOM PATTERNS. IF SW 4 IS NOT SET THEN
 : ALL THE DISKS (PRESENT) ARE WRITTEN WITH RANDOM PATTERNS.

WRDSK: TSTB FRSTRT ; RESTARTED AT 210?
 BEQ 1\$; NO
 CLRB FRSTRT ; YES, CLEAR THE RESTART FLAG
 BIT #SW4, 2SWR ; SW 4 SET?
 BEQ 1\$; NO
 BR BEGEX1 ; YES, DONT REWRITE ALL DISKS WITH
 ; RANDOM PATTERNS
 1\$: MOV #2\$, 5LPERR ; LUP TO '2\$' ON EROR, SW 9 SET!
 MOV #PDR, R2 ; POINTER TO DRIVE #'S TABLE
 MOV DRVPRS, R3 ; # OF DRIVES PRESENT
 2\$: MOV #4872., R0 ; NUMBER OF SECTORS PER DISK
 MOVB (R2)+, R1 ; GET THE FIRST AVAILABLE DRIVE
 BIC #177770, R1 ; POSITION THE BITS (15,14,13)
 MOV R1, QDRV
 CLC
 ROR R1
 ROR R1
 ROR R1
 ROR R1
 MOV R1, 2RDKDA ; BASE DISK ADDRESS
 MOV MAXBA, R4 ; CALCULATE MAXIMUM BUFFER
 SUB BASEBA, R4
 ASR R4 ; CONVERT TO WORDS
 BIC #377, R4 ; KEEP ONLY WHOLE BLOCKS
 SWAB R4
 CMP R4, #12. ; MAX OF 12 SECTORS
 BLE 3\$
 MOV #12., R4
 3\$: MOV R4, R1
 CMP R4, R0
 BLE 4\$
 MOV R0, R1
 4\$: SWAB R1
 NEG R1
 MOV R1, 5\$
 MOV R1, 2RDKWC
 JSR R5, GENBUF ; GENERATE RANDOM DATA BUFER
 5\$: .WORD 0 ; STARTING ADDRESS OF DATA BUFER
 .WORD DBUF
 MOV #DBUF, 2RDKBA ; FROM THIS BUS ADDRESS
 MOV #3, 2RDKCS ; WRITE, GO
 CON.RDY ; WAIT FOR CONTROL RDY
 JSR PC, CHKCS ; ANY ERROR?
 ERROR 1 ; AN ERROR OCCURED WHILE DOING WRITE


```

2738 ;THE PROGRAM IS GOING TO LOOP BACK TO THIS POINT AT THE END OF A PASS.
2739
2740 010630 104416 001100 BEGNEX: CON.RESET ;CLEAR EVERYTHING IN DRIVES
2741 010632 012706 001264 MOV #STACK,SP ;RESET STACK
2742 010636 005737 001264 TST DRVPRS ;ANY DRIVES LEFT IN SYSTEM?
2743 010642 001402 BEQ QMNGER
2744 010644 004737 014500 JSR PC,GENBRQ ;GO GENERATE 8 COMMANDS FOR THE Q
2745
2746
2747
2748 ;CHECK IF THERE IS ANY UNFINISHED COMMAND IN THE Q, WAITING TO BE EXECUTED.
2749 ;IF THERE IS NONE, GO TO THE 'GENBRQ' AND GENERATE 8 REQUESTS (COMMANDS),
2750 ;AND PUT THEM IN THE Q. IF THERE IS AN UNFINISHED COMMAND, FIND OUT IF
2751 ;THERE IS A PRIORITY COMMAND TO BE EXECUTED IMMEDIATELY.
2752
2753 010650 013746 001244 QMNGER: MOV PPRVL, -(SP) ;NEW PSW RAISE PRIORITY
2754 010654 012746 010662 MOV #1$, -(SP) ;RETURN PC *****
2755 010660 000002 RTI
2756
2757 010662 005737 001264 1$: TST DRVPRS ;ANY DRIVES IN SYSTEM?
2758 010666 001040 BNE 2$
2759 010670 104401 010676 TYPE 65$ ;TYPE ASCIZ STRING
2760 010674 000432 BR 64$ ;GET OVER THE ASCIZ
2761 ;65$: .ASCIZ <15><12>/HALTING - PRESS CONTINUE TO RESTART AT '200'<15><12><12><12>
2762 64$:
2763 010762 000000 HALT
2764 010764 000137 003376 JMP START
2765
2766 010770 012700 001306 2$: MOV #KEY,RO
2767 010774 005720 3$: TST (RO)+ ;ANY UNFINISHED COMMAND
2768 010776 100006 BPL 4$ ;IN Q
2769 011000 020027 001326 CMP RO, #KEY+20
2770 011004 001373 BNE 3$
2771 011006 004737 014500 JSR PC,GENBRQ ;IF NOT, GO GENERATE 8 MORE COMMANDS
2772 011012 000460 BR CHFAPN
2773
2774
2775 011014 012700 001306 4$: MOV #KEY,RO
2776 011020 032710 010000 5$: BIT #BIT12,(RO) ;ANY HIGH PRIORITY COMMAND IN Q
2777 011024 001404 BEQ 6$
2778 011026 005710 TST (RO) ;FINISHED?
2779 011030 100402 BMI 6$ ;YES
2780 011032 105710 TSTB (RO) ;IN EXECUTION?
2781 011034 100165 BPL PRICMND ;NO, GO PROCESS HIGH PRIORITY
2782
2783 011036 005720 001326 6$: TST (RO)+ ;CHECK THE ENTIRE Q
2784 011040 020027 001326 CMP RO, #KEY+20
2785 011044 001365 BNE 5$
2786
2787
2788 ;FIND OUT IF THERE IS A WRITE CHECK FUNCTION TO BE DONE IMMEDIATELY AFTER
2789 ;A WRITE, THAT WAS DONE PREVIOUSLY.
2790
2791 011046 005737 001456 TST WCFLG ;IS WRITE CHECK TO FOLLOW
2792 011052 100040 BPL CHFAPN ;WRITE? IF NOT, BRANCH
2793 ;YES
    
```



```

2826 ;NO HIGH PRIORITY COMMAND WAS FOUND IN THE Q. FIND OUT THE FIRST AVAILABLE
2827 ;COMMAND IN THE Q, FOR EXECUTION.
2828 011154 005000 CHFARN: CLR R0 ;WAIT FOR ANY IMMEDIATE INTERUPT
2829 011156 005046 CLR -(SP) ;NEW PSW
2830 011160 012746 011166 MOV #1$,-(SP) ;RETURN FOR RTI
2831 011164 000002 RTI
2832
2833
2834 011166 105200 1$: INCB R0
2835 011170 001376 BNE -2
2836 011172 013746 001244 MOV PPRVL, -(SP) ;NEW PSW, LOCK OUT CPU
2837 011176 012746 011204 MOV #2$, -(SP) ;RETURN FOR RTI *****
2838 011202 000002 RTI
2839
2840
2841 011204 012700 001306 2$: MOV #KEY, R0
2842 011210 005710 CHI: TST (R0) ;UNFINISHED COMMAND?
2843 011212 100436 BMI CH2
2844 011214 105710 TSTB (R0) ;IN PROGRESS?
2845 011216 100434 BMI CH2
2846 011220 011001 MOV (R0), R1
2847 011222 042701 177770 BIC #177770, R1
2848 011226 105761 001426 TSTB BUSY(R1) ;IS THIS DRIVE BUSY?
2849 011232 100426 BMI CH2
2850 011234 105761 001436 TSTB POS(R1) ;HAS THIS DRIVE BEEN POSITIONED
2851 ;FOR ANY OTHER COMMAND. IF YES,
2852 ;SKIP. IF NOT, PROCEED
2853 011240 001023 BNE CH2
2854
2855 ;CHECK IF THERE IS AY OTHER COMMAND
2856 011242 010002 MOV R0, R2 ;ON A DRIVE THAT IS NOT THE SAME
2857 ;AS THE PREVIOUS DRIVE. THIS COMMAND
2858 011244 000414 BR 2$ ;SHOULD NOT BE IN PROGRESS
2859 ;AND SHOULD NOT HAVE BEEN COMPLETED
2860 011246 005712 1$: TST (R2) ;UNFINISHED COMMAND?
2861 011250 100412 BMI 2$
2862 011252 105712 TSTB (R2) ;IN PROGRESS?
2863 011254 100410 BMI 2$
2864 011256 011203 MOV (R2), R3
2865 011260 042703 177770 BIC #177770, R3
2866 011264 105763 001426 TSTB BUSY(R3) ;IS THE DRIVE BUSY?
2867 011270 100402 BMI 2$
2868 011272 020301 CMP R3, R1 ;IS THIS COMMAND ON THE SAME DRIVE?
2869 011274 001447 BEQ POSTION ;IF YES, GO AND POSITION THE COMMAND
2870 ;POINTED TO BY R0, (BECAUSE THERE IS
2871 ;ONE MORE COMMAND THAT CAN BE PERFORMED
2872 ;ON THE SAME DRIVE)
2873 011276 005722 2$: TST (R2)+ ;CHECK REST OF THE Q
2874 011300 020227 001326 CMP R2, #KEY+20
2875 011304 001360 BNE 1$
2876 ;IF THERE WAS NO EXECUTABLE COMMAND
2877 011306 000470 BR EXNSK ;ON ANY OTHER DRIVE, THEN EXECUTE
2878 ;COMMAND POINTED TO BY R0
2879
2880 CH2: TST (R0)+ ;CHECK ENTIRE Q
2881 011312 020027 001326 CMP R0, #KEY+20

```



```

2882 011316 001334          BNE    CHI
2883
2884
2885          ;NO (UNPOSITIONED) EXECUTABLE COMMAND WAS FOUND IN THE Q. CHECK IF THERE
2886          ;IS ANY POSITIONED COMMAND IN THE Q, WAITING TO BE EXECUTED.
2887
2888 011320 105777 167676      TSTB   DRKCS          ;IF THE CONTROLLER IS BUSY GO TO
2889 011324 100402              BMI    IS            ;STATUS AND WAIT FOR INTERRUPTS
2890 011326 000137 021436      JMP     STATUS        ;IF THE CONTROLLER IS NOT BUSY FIND
2891
2892 011332 012700 001306      1S:   MOV    #KEY,RO  ;ANY POSITIONED COMMAND AND EXECUTE
2893 011336 032710 000020      2S:   BIT    #BIT4,(RO)
2894 011342 001414              BEQ    3S            ;IT
2895 011344 005710              TST   (RO)          ;MAKE SURE COMMAND IS POSITIONED
2896 011346 100412              BMI    3S            ;COMMAND IS UNFINISHED,
2897 011350 105710              TSTB  (RO)          ;IT IS NOT IN PROGRESS,
2898 011352 100410              BMI    3S            ;THE DRIVE IS NOT IN BUSY
2899 011354 011001              MOV    (RO),R1
2900 011356 042701 177770      BIC    #177770,R1
2901 011362 105761 001426      TSTB  BUSY(R1)
2902 011366 100402              BMI    3S
2903 011370 000137 011612      JMP     EXCUT         ;GO EXECUTE THE COMMAND IF THE
2904
2905 011374 005720              3S:   TST   (RO)+     ;ABOVE CONDITIONS ARE SATISFIED
2906 011376 020027 001326      CMP    RO,#KEY+20    ;CHECK ALL COMMANDS IN Q
2907 011402 001355              BNE   2S
2908 011404 000137 021436      JMP     STATUS
2909
2910
2911          ;ENTER HERE IF THERE IS A PRIORITY COMMAND TO BE EXECUTED.
2912
2913
2914
2915 011410 000137 011612      PRICMN: JMP    EXCUT          ;GO EXECUTE NON-SEEK COMMAND.
2916
2917          ;ENTER THIS IF A COMMAND IS TO BE PREPOSITIONED (BEFORE EXECUTING A
2918          ;FUNCTION)
2919
2920 011414 032710 000020      POSTION: BIT    #BIT4,(RO)    ;ALREADY POSITIONED?
2921 011420 001333              BNE   CH2            ;YES, GO BACK AND CHECK IF REST OF THE
2922          ;COMMANDS IN THE Q ARE TO BE POSITIONED
2923
2924 011422 004737 012164          JSR    PC,POSK        ;GO CHECK, & SET UP FLAGS
2925 011426 004737 020350          JSR    PC,POSCMND     ;SAVE INFO ABOUT PRESENT & PAST COMAND
2926 011432 012777 000111 167562      MOV    #111,DRKCS    ;POSITION THE COMMAND
2927 011440 005046              CLR   -(SP)          ;NEW PSW, DROP PRIORITY
2928 011442 012746 011450          MOV    #1S,-(SP)     ;RETURN FOR RTI
2929 011446 000002              RTI
2930
2931 011450 105737 001535      1S:   TSTB  INT1FL
2932 011454 001775              BEQ   .-4            ;WAIT FOR INTERRUPT
2933 011456 012777 013256 167554      MOV    #INTHND,DRKVEC ;RE-ESTABLISH RK INTERRUPT VECTOR
2934 011464 000137 011154      JMP    CHFAFN        ;GO BACK AND CHECK IF ANY COMMANDS TO BE
2935          ;POSITIONED OR EXECUTED
2936
2937
    
```

```

2938
2939
2940
2941
2942
2943
2944 011470 012701 001306      EXNSK: MOV      #KEY,R1
2945 011474 032711 000020      1$:  BIT      #BIT4,(R1) ;HEADS POSITIONED?
2946 011500 001412
2947 011502 005711
2948 011504 100410
2949 011506 105711
2950 011510 100406
2951 011512 011102
2952 011514 042702 177770
2953 011520 105762 001426
2954 011524 100005
2955
2956 011526 005721      2$:  TST      (R1)+ ;CHECK ALL COMMANDS IN Q
2957 011530 020127 001326      CMP      R1,#KEY+20
2958 011534 001357      BNE      1$
2959
2960 011536 000425      BR       EXCUT ;NO POSITIONED COMMAND WAS
2961
2962
2963
2964
2965
2966
2967 011540 010137 001536      3$:  MOV      R1,SAVKEY ;AN ALREADY POSITIONED COMMAND HAS
2968
2969 011544 004737 012164      JSR     PC,POSK ;BEEN FOUND.
2970
2971 011550 004737 020350      JSR     PC,POSCMND ;SAVE POINTER TO THE COMMAND(KEY)
2972 011554 012777 000111 167440      MOV     #111,QRKCS ;WHICH IS ALREADY POSITIONED
2973 011562 005046      CLR     -(SP) ;GO AND POSITION THE COMMAND(KEY)
2974 011564 012746 011572      MOV     #4$,-(SP) ;POINTED TO BY R0
2975 011570 000002      RTI    ;SAVE INFO ABOUT PAST & PRESENT COMAND
2976
2977
2978 011572 105737 001535      4$:  TSTB    INT1FL ;DID INTERRUPT OCCUR?
2979 011576 001775      BEQ     4$ ;BR IF NOT
2980 011600 012777 013256 167432      MOV     #INTHND,QRKVEC ;REESTABLISH INTERRUPT ADDRESS
2981 011606 013700 001536      MOV     SAVKEY,R0 ;RESTORE THE SAVED POINTER TO KEY
  
```

2982											; EXECUTE THE COMMAND POINTED TO BY R0
2983											; R0 CONTAINS THE POINTER TO THE
2984											; COMMAND KEY
2985	011612	011001		EXCUT:	MOV	(R0), R1					; GET DRIVE NO
2986	011614	042701	177770		BIC	#177770, R1					
2987	011620	005710			TST	(R0)					; THIS COMMAND UNFINISHED?
2988	011622	100004			BPL	1\$					
2989	011624	011037	001162		MOV	(R0), \$REGO					; GET KEY
2990	011630	104030			ERROR	30					; IF NOT, ERROR
2991											; AN ATTEMPT WAS MADE TO REEXECUTE A COMMAND
2992											; THAT HAS ALREADY BEEN EXECUTED BEFORE.
2993											; (ON DRIVE NO. GIVEN IN ERROR MESSAGE)
2994	011632	000512			BR	ABRT1					
2995	011634	105710		1\$:	TSTB	(R0)					; IS IT IN PROGRESS?
2996	011636	100004			BPL	3\$					
2997	011640	011037	001162		MOV	(R0), \$REGO					; GET KEY
2998	011644	104030			ERROR	30					; IF YES, ERROR
2999											
3000	011646	000504			BR	ABRT1					; AN ATTEMPT WAS MADE TO REEXECUTE A COMMAND
3001											; THAT IS IN PROGRESS (ON DRIVE NO. GIVEN
3002											; IN ERROR MESSAGE)
3003											
3004	011650	105761	001426	3\$:	TSTB	BUSY(R1)					; IS THE DRIVE BUSY?
3005	011654	100004			BPL	4\$					
3006	011656	010137	001162		MOV	R1, \$REGO					; GET DRIVE #
3007	011662	104002			ERROR	2					; 'BUSY' FLAG FOR THE DRIVE (CONTAINED
3008	011664	000470			BR	ABRT					; IN R1) IS SET, INDICATING THAT THE DRIVE
3009											; IS 'BUSY' AND ENGAGED IN AN ACTIVITY.
3010											; STILL AN ATTEMPT WAS MADE TO INITIATE
3011											; A FUNCTION ON THIS DRIVE. THIS IS AN
3012											; UNEXPECTED ERROR CONDITION.
3013											
3014	011666	105777	167330	4\$:	TSTB	\$RKCS					; CONTROL READY SET?
3015	011672	100404			BMI	5\$; YES
3016	011674	004737	022032		JSR	PC, GT4RG					; GET RKCS, ER, DS, DA
3017	011700	104003			ERROR	3					; CONTROL READY IS NOT SET. THIS IS AN
3018	011702	000461			BR	ABRT					; UNEXPECTED ERROR CONDITION AT THIS
3019											; POINT OF EXECUTION, CONTROL SHOULD
3020											; BE NORMALLY READY.
3021	011704	011002		5\$:	MOV	(R0), R2					
3022	011706	000302			SWAB	R2					
3023	011710	042702	177770		BIC	#177770, R2					; FORM THE ADDRESS OF THE
3024	011714	006302			ASL	R2					; PARAMETER LIST FOR THIS
3025	011716	010204			MOV	R2, R4					; COMMAND
3026	011720	016205	002032		MOV	PCAND(R2), R5					
3027											
3028	011724	011577	167300		MOV	(R5), \$RKDA					; GET THE FIRST ITEM FROM LIST
3029											; DISK ADDRESS
3030	011730	032777	000100	167260	BIT	#RWS, \$RKDS					; R/W/S RDY SET?
3031	011736	001006			CNE	6\$; YES
3032	011740	010137	001250		MOV	R1, SRDRV					; GET DRIVE #, FOR TYPING SERIAL #
3033	011744	004737	022032		JSR	PC, GT4RG					; GET RKCS, ER, DS, DA
3034	011750	104004			ERROR	4					; R/W/S RDY IS NOT SET FOR THE DRIVE.
3035	011752	000435			BR	ABRT					; A (NON-SEEK) FUNCTION WAS SUPPOSED
3036											; TO BE EXECUTED ON THIS DRIVE. THIS IS
3037											; AN UNEXPECTED ERROR CONDITIONS AT THIS

```

3038                                     ;POINT OF EXECUTION R/W/S ROY SHOULD
3039                                     ;BE NORMALLY SET.
3040 011754 016503 000002          6S:  MOV  2(R5),R3          ;GET FUNCTION TO BE DONE
3041                                     ;
3042 011760 122703 000002          CMPB  #2,R3          ;IS IT A WRITE FUNCTION?
3043 011764 001437                BEQ   WRFNC          ;YES, IT IS WRITE
3044                                     ;IT'S NOT A WRITE FUNCTION
3045                                     ;
3046 011766 016503 000002          NWRFNC: MOV 2(R5),R3  ;GET FUNCTION TO BE DONE
3047 011772 052703 000501          BIS  #501,R3        ;SET SSE,IDE,GO BITS
3048 011776 016577 000004          MOV  4(R5),@RKWC    ;GET WORD COUNT
3049 012004 016577 000006          MOV  6(R5),@RKBA    ;GET BUS ADDRESS
3050                                     ;
3051 012012 004737 020372          JSR  PC,FNCMND      ;SAVE INFO ABOUT PAST & PRESENT COMAND
3052                                     ;
3053 012016 010377 167200          MOV  R3,@RKCS       ;SET SSE,IDE, FUNCTION, GO
3054                                     ;
3055 012022 052710 000200          BIS  #BIT7,(R0)     ;SET FLAG INDICATING FUNCTION
3056 012026 052704 000200          BIS  #BIT7,R4       ;IN PROGRESS
3057                                     ;R4 CONTAINS OFFSET TO THE COMMAND KEY
3058                                     ;(FROM 'KEY') BITS 0-3, BIT 7 IS SET
3059 012032 110461 001426          MOVB R4,BUSY(R1)    ;SET FLAG INDICATING DRIVE BUSY
3060 012036 110437 001534          MOVB R4,INTFLG      ;SET FLAG FOR INTERRUPT USE
3061 012042 000137 021436          JMP  STATUS
3062                                     ;
3063 012046 004737 014426          ABRT: JSR PC,DRVABT ;ABORT THE FUNCTION
3064 012052 004737 016540          JSR  PC,CHKDRV     ;GO CHECK, DRIVE ERRORS
3065 012056 000240                NOP
3066 012060 000137 010650          ABRT1: JMP QMNGER

```

Address	OpCode	Operand 1	Operand 2	Operand 3	Label	Instruction	Comment
3067							;THE FUNCTION TO BE EXECUTED IS A
3068							;WRITE FUNCTION
3069	012064	016537	000004	012104	WRFNC:	MOV 4(R5),1\$;GET # OF WORDS TO BE WRITTEN
3070	012072	016537	000006	012106		MOV 6(R5),2\$;GET STARTING BA OF BUFFER
3071	012100	004537	016704			JSR R5,GENBUF	;GO GENERATE BUFFER
3072	012104	000000			1\$:	.WORD 0	;SAVE # OF WORDS
3073	012106	000000			2\$:	.WORD 0	;SAVE STARTING BUS ADDRESS OF BUFFER
3074	012110	052703	000101			BIS #101,R3	;SET IDE AND GO BIT
3075	012114	013777	012104	167102		MOV 1\$,JRKWC	;SET WORD COUNT
3076	012122	013777	012106	167076		MOV 2\$,JRKBA	;SET BUS ADDRESS
3077	012130	004737	020372			JSR PC,FNCMND	;SAVE INFO ABOUT PAST & PRESENT COMAND
3078							
3079	012134	010377	167062			MOV R3,JRKCS	;ISSUE WRITE,IDE,GO
3080	012140	052710	000200			BIS #BIT7,(R0)	;SET FLAG INDICATING FUNCTION IN
3081	012144	052704	000200			BIS #BIT7,R4	;PROGRESS
3082							
3083	012150	110461	001426			MOV B R4,BUSY(R1)	;SET FLAG INDICATING DRIVE BUSY
3084	012154	110437	001534			MOV B R4,INTFLG	;SET FLAG FOR INTERRUPT USE
3085							;R4 CONTAINS OFFSET TO THE COMMAND KEY
3086							; (FROM 'KEY') BITS 0-3, BIT 7 IS SET
3087	012160	000137	021436			JMP STATUS	

E06

3088	012164	011001			POSK:	MOV	(R0),R1	: INITIAL CHECKING PRIOR TO DOING
3089	012166	042701	177770			BIC	#177770,R1	: POSITIONING COMMAND POINTED TO BY R0
3090	012172	105761	001426			TSTB	BUSY(R1)	: DRIVE BUSY?
3091	012176	100004				BPL	1\$	
3092	012200	010137	001162			MOV	R1,\$REGO	: GET DRIVE # FOR WHICH 'BUSY' IS SET
3093	012204	104002				ERROR	2	: 'BUSY' FLAG FOR THE DRIVE (CONTAINED
3094	012206	000470				BR	7\$: IN R1) IS SET, INDICATING THAT THE DRIVE
3095								: IS 'BUSY' AND ENGAGED IN AN ACTIVITY
3096								: STILL AN ATTEMPT WAS MADE TO INITIATE
3097								: POSITIONING ON THIS DRIVE. THIS IS AN
3098								: UNEXCEPTED ERROR CONDITION.
3099	012210	105777	167006		1\$:	TSTB	ARKCS	: CONTROL READY SET?
3100	012214	100404				BMI	2\$: YES
3101	012216	004737	022032			JSR	PC,GT4RG	: GET RKCS, ER, DS, DA
3102	012222	104003				ERROR	3	: CONTROL READY IS NOT SET. THIS IS AN
3103	012224	000454				BR	6\$: UNEXPECTED ERROR CONDITION AT THIS
3104								: POINT OF EXECUTION, CONTROL SHOULD
3105								: BE NORMALLY READY.
3106	012226	011002			2\$:	MOV	(R0),R2	
3107	012230	000302				SWAB	R2	
3108	012232	042702	177770			BIC	#177770,R2	
3109	012236	006302				ASL	R2	
3110	012240	016203	002032			MOV	PCMND(R2),R3	: STARTING WORD OF COMMAND TABLE
3111	012244	011377	166760			MOV	(R3),ARKDA	
3112	012250	032777	000100	166740		BIT	#RWS,ARKDS	: R/W/S RDY SET?
3113	012256	001006				BNE	3\$: YES
3114	012260	010137	001250			MOV	R1,SRDRV	: GET DRIVE #, FOR TYPING SERIAL #
3115	012264	004737	022032			JSR	PC,GT4RG	: GET RKCS, ER, DS, DA
3116	012270	104004				ERROR	4	: R/W/S RDY IS NOT SET FOR THE DRIVE. A
3117	012272	000431				BR	6\$: (POSITIONING) SEEK WAS SUPPOSED TO BE
3118								: BE EXECUTED ON THIS DRIVE. THIS IS
3119								: AN UNEXPECTED ERROR CONDITION. AT THIS
3120								: POINT OF EXECUTION R/W/S RDY SHOULD
3121								: BE NORMALLY SET.
3122	012274	110261	001426		3\$:	MOV	R2,BUSY(R1)	: SET FLAG INDICATING DRIVE BUSY
3123	012300	152761	000200	001426		BISB	#BIT7,BUSY(R1)	
3124	012306	032710	000010			BIT	#BIT3,(R0)	: IS THIS A SEEK COMMAND
3125	012312	001006				BNE	4\$	
3126	012314	112761	000377	001436		MOV	#377,POS(R1)	: SET FLAG INDICATING, THIS DRIVE POSITIONS
3127	012322	052710	000020			BIS	#BIT4,(R0)	: SET FLAG INDICATING THIS COMMAND
3128	012326	000402				BR	5\$	
3129	012330	052710	000200		4\$:	BIS	#BIT7,(R0)	: POSITIONED. SET FLAG INDICATING
3130								: FUNCTION IN PROGRESS
3131	012334	012777	012376	166676	5\$:	MOV	#INTISK,ARKVEC	: SET UP RK11 VECTOR
3132	012342	013777	001244	166672		MOV	PPRLVL,ARKSTAT	: PSW ON INTERRUPT
3133	012350	105037	001535			CLRB	INTIFL	: CLEAR FLAG INDICATING - INTERRUPT
3134	012354	000207				RTS	PC	: OCCURRED
3135								
3136	012356	004737	014426		6\$:	JSR	PC,DRVABT	: ABORT THE FUNCTION
3137	012362	004737	016540			JSR	PC,CHKDRV	: GO CHECK. DRIVE ERRORS
3138	012366	000240				NOP		
3139	012370	005726			7\$:	TST	(SP)+	: POP THE RETURN ADDRESS
3140	012372	000137	010650			JMP	QMNGER	

```

3141 ;AFTER ISSUING A SEEK FOR POSITIONING, AN INTERRUPT IS ALLOWED TO TAKE
3142 ;*PLACE. THIS HANDLER SERVICES THE FIRST INTERRUPT, WHICH OCCURS AS A RESULT
3143 ;OF THE SEEK BEING ACCEPTED.
3144
3145 012376 105237 001535 INT15K: INCB INTIFL ;INDICATE THAT INTERRUPT TOOK PLACE
3146 012402 053766 001244 000002 BIS PPRVLV,2(SP) ;CPU PRIORITY TO 5 ON RETURN FROM
3147 ;INTERRUPT
3148
3149 012410 004737 020272 JSR PC,CHKCRDY ;CONTROL READY SET?
3150 012414 104005 ERROR 5 ;CONTROL READY NOT SET AFTER THE FIRST
3151 ;INTERRUPT ON INITIATING SEEK
3152
3153 012416 032777 020000 166576 BIT #SCP,ARKCS ;SCP BIT SET?
3154 012424 001403 BEQ 15
3155 012426 004737 022222 JSR PC,RG4SDR ;GET RKCS, ER, DS, DA AND DRIVE # FOR
3156 ;TYPING SERIAL DRIVE #
3157 012432 104012 ERROR 12 ;SCP SET AFTER FIRST INTERRUPT ON
3158 ;ACCEPTING SEEK. A SEEK WAS INITIATED,
3159 ;AS A RESULT OF WHICH (THIS) FIRST
3160 ;INTERRUPT OCCURRED, BUT SCP SHOULD
3161 ;NOT BE SET AFTER THE FIRST INTERRUPT.
3162 ;(IT GETS SET ONLY AFTER THE SEEK
3163 ;IS DONE).
3164 ;THIS IS THE FIRST INTERRUPT
3165 ;AFTER ISSUING SEEK
3166 012434 017700 166562 15: MOV ARKCS,RO
3167 012440 042700 177760 BIC #177760,RO ;CHECK THERE IS A SEEK FUNCTION
3168 012444 022700 000010 CMP #10,RO ;IN RKCS
3169 012450 001403 BEQ 25
3170 012452 004737 022032 JSR PC,GT4RG ;GET RKCS, ER, DS, DA
3171 012456 104006 ERROR 6 ;RKCS DOES NOT CONTAIN 'SEEK' FUNCTION.
3172 ;A SEEK WAS INITIATED AS A RESULT OF WHICH
3173 ;(THIS) FIRST INTERRUPT OCCURRED. RKCS
3174 ;SHOULD CONTAIN THE SEEK FUNCTION BITS.
3175 ;BUT IT DID NOT
3176
3177 012460 017700 166544 25: MOV ARKDA,RO ;GET THE DRIVE # FROM RKDA
3178 012464 042700 017777 BIC #17777,RO
3179 012470 000241 CLC
3180 012472 006100 ROL RO
3181 012474 006100 ROL RO
3182 012476 006100 ROL RO
3183 012500 006100 ROL RO
3184 012502 010001 MOV RO,R1
3185 012504 105761 001426 TSTB BUSY(R1) ;CHECK THIS DRIVE NO. WAS BUSY
3186 012510 100403 BMI 35 ;OK, IF IT WAS
3187 012512 010137 001162 MOV R1,$REGO ;GET DRIVE #(FROM RKDA)
3188 012516 104007 ERROR 7 ;'BUSY' FLAG FOR THE DRIVE WAS NOT SET.
3189 ;THE DRIVE # (IN RKDA) WHICH CAUSED (?)
3190 ;THIS (FIRST) INTERRUPT SHOULD HAVE BEEN
3191 ;'BUSY' (SOFTWARE FLAG). NOTE WHENEVER
3192 ;ANY OPERATION IS INITIATED ON ANY DRIVE
3193 ;'BUSY' FLAG FOR THAT DRIVE IS SET.
3194 012520 116100 001426 35: MOVB BUSY(R1),RO ;FORM THE ADDRESS OF
3195 012524 042700 177600 BIC #177600,RO ;THIS KEY
3196 012530 062700 001306 ADD #KEY,RO
    
```

```

3197
3198 012534 032710 000020          BIT      #BIT4,(R0)      ;IS THE KEY ACTIVE FOR 'POSITIONING'?
3199 012540 001003          BNE      4$
3200 012542 010137 001162          MOV      R1,$REGO      ;GET DRIVE NUMBER
3201 012546 104010          ERROR    10            ;POSITIONING FLAG (IN THE KEY) IS NOT
3202                                     ;SET FOR THE INTERRUPTING DRIVE (GIVEN
3203                                     ;IN EROR MESSAGE)
3204
3205 012550 105761 001436          4$:      TSTB     POS(R1)      ;IS THE 'POSITIONING' FLAG SET?
3206 012554 001003          BNE      5$
3207 012556 010137 001162          MOV      R1,$REGO      ;GET DRIVE # FROM RKDA
3208 012562 104010          ERROR    10            ;THIS INTERRUPT IS SUPPOSED TO BE AS
3209                                     ;A RESULT OF INITIATING A (POSITIONING)
3210                                     ;SEEK. WHENEVER A SEEK IS INITIATED
3211                                     ;TO POSITION THE HEADS THE POSITIONING
3212                                     ;FLAG (POS#) IS SET. OCCURANCE OF THIS
3213                                     ;ERROR INDICATED THAT THE DRIVE #
3214                                     ;(FROM RKDA)GIVING THIS INTERRUPT DID
3215                                     ;NOT HAVE ITS POSITIONING FLAG SET.
3216
3217 012564 005777 166432          5$:      TST      DRKCS      ;ANY ERROR?
3218 012570 100044          BPL      8$            ;NO - RETURN
3219
3220 012572 032737 000040 001474      BIT      #BITS,ERCODE
3221 012600 001012          BNE      6$            ;SAME ERROR
3222 012602 042737 000040 001474      BIC      #BITS,ERCODE
3223 012610 001026          BNE      7$
3224 012612 052737 000040 001474      BIS      #BITS,ERCODE
3225
3226 012620 004737 022222          JSR      PC,RG45DR      ;GET RKCS, ER, DS, DA AND DRIVE # FOR
3227                                     ;TYPING SERIAL DRIVE #
3228 012624 104011          ERROR    11            ;BIT 15, 'ERR' SET IN RKKCS AFTER FIRST
3229                                     ;INTERRUPT - WHICH OCCURRED AFTER A
3230                                     ;POSITIONING SEEK WAS INITIATED. RKER
3231                                     ;WILL CONTAIN ERROR BIT/S
3232 012626 042710 000020          6$:      BIC      #BIT4,(R0)      ;CLEAR 'POSITIONING' BIT
3233 012632 105061 001426          CLR      BUSY(R1)      ;CLEAR 'BUSY' FLAG
3234 012636 105061 001436          CLR      POS(R1)       ;CLEAR 'POSITIONING' FLAG
3235
3236 012642 004737 016006          JSR      PC,CLRERR      ;CLEAR THE ERROR
3237 012646 052710 010000          BIS      #BIT12,(R0)   ;INDICATE HIGH PRIORITY ON
3238 012652 105261 001446          INCB     RETRY(R1)      ;INCREMENT RETRY COUNT
3239 012656 126127 001446 000003      CMPB     RETRY(R1),#3   ;DONE RETRIES?
3240 012664 003406          BLE      8$            ;NO
3241
3242 012666 004737 014426          7$:      JSR      PC,DRVABT      ;ABORT THE FUNCTION
3243 012672 005061 001446          CLR      RETRY(R1)
3244 012676 005037 001474          CLR      ERCODE
3245
324E 012702 000002          8$:      RTI
    
```


3247
3248
3249
3250
3251
3252
3253
3254
3255
3256
3257
3258
3259
3260
3261
3262
3263
3264
3265
3266
3267
3268
3269
3270
3271
3272
3273
3274
3275
3276
3277
3278
3279
3280
3281
3282
3283
3284
3285
3286
3287
3288
3289
3290
3291
3292
3293
3294
3295
3296
3297
3298
3299
3300
3301
3302

012704 004737 020272
012710 104013

012712 017746 166300
012716 004737 022170

012722 012601
012724 105761 001426
012730 100403
012732 004737 022032
012736 104014

012740 116100 001426
012744 042700 177600
012750 062700 001306
012754 032710 000020
012760 001003
012762 010137 001162
012766 104010

012770 105761 001436
012774 001003
012776 010137 001162
013002 104010

013004 004737 016540
013010 000501

013012 017777 166200 166210
013020 032777 000100 166170
013026 001005
013030 004737 022032
013034 010137 001250
013040 104015
013042 032777 001000 166146
013050 001007

SKOMP: JSR PC,CHKCRDY
ERROR 13

15: MOV @RKDS, -(SP)
JSR PC,CROTFL

MOV (SP)+, R1
TSTB BUSY(R1)
BMI 25
JSR PC,GT4RG
ERROR 14

25: MOVB BUSY(R1), R0
BIC #177600, R0
ADD #KEY, R0
BIT #BIT4, (R0)
BNE 35
MOV R1, \$REGO
ERROR 10

35: TSTB POS(R1)
BNE 45
MOV R1, \$REGO
ERROR 10

45: JSR PC,CHKDRV
BR PFTERR

MOV @RKDS, @RKDA

BIT #RWS, @RKDS
BNE 55
JSR PC,GT4RG
MOV R1, SRDRV
ERROR 15

55: BIT #SIN, @RKDS
BNE PSINER

: THIS ROUTINE IS ENTERED UPON COMPLETION
: OF A SEEK OPERATION UNDER INTERRUPT MODE

: CONTROL READY SET?
: CONTROL RDY NOT SET, AFTER A SEEK
: DONE INTERRUPT!

: GET DRIVE # THAT INTERRUPTED
: ROTATE BITS 15,14,13 TO POSITION
: 0,1,2
: GET THE ROTATED BITS (DRIVE ID BITS)
: CHECK THAT DRIVE WAS BUSY

: 'BUSY' FLAG FOR THE INTERRUPTING DRIVE
: (RKDS) WAS NOT SET. DRIVE # (15,14,13 - RKDS
: INTERRUPTED AFTER SEEK WAS COMPLETE, BUT
: 'BUSY' FLAG CORRESPONDING TO THAT DRIVE
: WAS CLEAR. IF THE CORRECT DRIVE WAS
: INTERRUPTING 'BUSY' FLAG SHOULD HAVE
: BEEN SET.
: FORM THE ADDRESS OF THE
: KEY

: CHECK THAT POSITION BIT WAS SET

: GET DRIVE NUMBER
: POSITIONING FLAG (IN KEY) IS NOT SET
: SET FOR INTERRUPTING DRIVE (GIVEN IN ERCA
: MESSAGE)
: CHECK POSITIONING FLAG WAS SET

: 'POSITIONING' FLAG WAS CLEAR. WHEN
: DOING A (POSITIONING) SEEK, THE FLAG
: 'POS#' IS SET TO INDICATE THAT DRIVE
: IS POSITIONING HEADS (SEEKING). THIS
: ERROR INDICATES THAT FOR THE INTERRUPTING
: DRIVE (RKDS) POSITIONING FLAG WAS
: NOT SET.
: GO, CHECK FOR DRV ERRORS (DPL, DRU, DRY, WPS,
: IF THERE IS A DRV EROR, RETURN HERE
: THE DRIVE HAS BEEN DESELECTED, ALL
: FURTHER COMANDS ON THAT DRIVE ABORTED
: RETURN HERE IF NO DRIVE ERRORS
: GET THE DRIVE # FROM DRIVE ID BITS
: IN RKDS AND ADDRESS THE DRIVE
: R/W/S RDY SET?
: YES
: GET RKCS, ER, DS, DA
: GET DRIVE #, FOR TYPING SERIAL #
: R/W/S RDY NOT SET FOR INTERRUPTING
: DRIVE (RKDS), AFTER SEEK WAS COMPLETED.
: 'SIN' ERROR?
: YES, BRANCH

3303 013052 032777 040000 166142
3304 013060 001060
3305
3306 013062 105061 001426
3307 013066 000207

BIT #ME,DRKCS
BNE PORKER

CLRB BUSY(R1)
RTS PC

;ANY HARD ERROR?
;YES
;NO ERRORS DETECTED ON POSITIONING
;CLEAR BUSY FLAG FOR THIS DRIVE

3353										:	ENTER THIS ROUTINE WHEN AN INTEPRUPT OCCURS. NOTE THERE IS ONE OTHER INTERRUPT ROUTINE - INTISK
3354										:	CLEAR FLAG TO INDICATE THAT AN INTERRUPT OCCURED.
3355										:	CPU PRIORITY TO 5 ON RTI
3356	013256	105037	001534					INTHND: CLR8	INTFLG	:	CONTROL READY SET?
3357										:	CONTROL ROY CLEAR AFTER INTRUPT ON COMPLETION OF FUNCTION. IT SHOULD BE SET
3358	013262	013766	001244	000002				MOV	PPRLVL,2(SP)	:	SCP SET? SEARCH COMPLETE?
3359	013270	004737	020272					JSR	PC,CHKCRDY	:	
3360	013274	104024						ERROR	24	:	
3361										:	
3362	013276	032777	020000	165716	1\$:			BIT	#SCP,ARKCS	:	
3363	013304	001403						BEG	2\$:	
3364	013306	004737	012704					JSR	PC,SKCMP	:	GO TO SEEK COMPLETE ROUTINE
3365	013312	000002						RTI		:	
3366	013314	017746	165710		2\$:			MOV	ARKDA,-(SP)	:	GET THE DRIVE # TO WHICH THE COMMAND WAS ISSUED UNDER INTERRUPT MODE
3367										:	ROTATE BITS 15,14,13 TO POSITION
3368										:	0,1,2
3369	013320	004737	022170					JSR	PC,CROTLF	:	POP OFF THE DRIVE # FROM THE STACK
3370										:	CHECK THAT DRIVE WAS BUSY
3371	013324	012605						MOV	(SP)+,R5	:	
3372	013326	105765	001426					TSTB	BUSY(R5)	:	
3373	013332	100403						BMI	3\$:	
3374	013334	010537	001162					MOV	R5,\$REGO	:	
3375	013340	104007						ERROR	7	:	'BUSY' FLAG FOR THE INTERRUPTING DRIVE WAS NOT SET. WHENEVER ANY ACTIVITY IS INITIATED ON A DRIVE, THE (SOFTWARE) 'BUSY' FLAG IS SET TO INDICATE THAT DRIVE IS BUSY DOING SOMETHING.
3376										:	OCCURANCE OF THIS ERROR INDICATES THAT THE 'BUSY' FLAG FOR THE INTERRUPTING DRIVE (RKDA) IS CLEAR!
3377										:	CLEAR THE POSITION FLAG
3378										:	GET THE ADDRESS OF THE COMMAND KEY
3379										:	
3380										:	
3381										:	
3382										:	
3383	013342	105065	001436		3\$:			CLR8	POS(R5)	:	CHECK IT'S NOT A SEEK FUNCTION
3384	013346	116500	001426					MOV8	BUSY(R5),R0	:	
3385	013352	042700	177760					BIC	#177760,R0	:	
3386	013356	062700	001306					ADD	#KEY,R0	:	
3387	013362	032710	000010					BIT	#BIT3,(R0)	:	
3388	013366	001401						BEG	4\$:	
3389	013370	104020						ERROR	20	:	(SOFTWARE) FLAG FOR THE INTERRUPTING DRIVE (RKDA) INDICATES THAT A SEEK FUNCTION WAS BEING EXECUTED ON THE DRIVE. IF THAT'S THE CASE, SCP BIT SHOULD HAVE SET ON SEEK DONE INTRUPT, BUT IT WAS NOT. NOTE, HERE THERE IS A CHANGE OF MULTIPLE ERRORS OR ERROR MISINTERPRETATION
3390										:	CHECK THAT FUNCTION IN PROGRESS BIT WAS SET
3391										:	GET DRIVE NUMBER
3392										:	IF NOT, ERROR
3393										:	'FUNCTION IN PROGRESS' FLAG (IN THE KEY) WAS NOT SET FOR THE INTERRUPTING DRIVE. IF THIS DRIVE WAS BUSY DOING THE FUNCTION, THE ABOVE FLAG SHOULD BE SET.
3394										:	CHECK THAT THE INTERRUPTING DRIVE (IN RKDA) IS THE SAME AS THE DRIVE IN THE KEY
3395										:	
3396										:	
3397	013372	105710			4\$:			TSTB	(R0)	:	
3398	013374	100403						BMI	5\$:	
3399	013376	010537	001162					MOV	R5,\$REGO	:	
3400	013402	104031						ERROR	31	:	
3401										:	
3402										:	
3403										:	
3404										:	
3405	013404	011002			5\$:			MOV	(R0),R2	:	
3406	013406	042702	177770					BIC	#177770,R2	:	
3407	013412	020502						CMP	R5,R2	:	
3408	013414	001405						BEG	6\$:	

LOG

3409	013416	010537	001162		MOV	R5,\$REGO	:GET EXPCD DRIVE NO.
3410	013422	010237	001164		MOV	R2,\$REGI	:GET DRIVE NO. RECVD
3411	013426	104032			ERROR	32	:UNEXPECTED DRIVE NO. INTERRUPTED
3412	013430	006302		6\$:	ASL	R2	
3413	013432	011003			MOV	(R0),R3	
3414	013434	010037	001536		MOV	R0,\$AVKEY	
3415	013440	000303			SWAB	R3	
3416	013442	042703	177770		BIC	#177770,R3	:GET POSITION OF THE PARAMETER
3417	013446	006303			ASL	R3	:LIST FROM THE KEY
3418	013450	017704	165546		MOV	\$RKCS,R4	
3419	013454	042704	177761		BIC	#177761,R4	:CLEAR ALL BUT FUNCTION CODE
3420	013460	016305	002032		MOV	PCMD(R3),R5	:CHECK THAT THE FUNCTION IN
3421							:RKCS AND THE KEY ARE SAME.
3422	013464	126504	000002		CMPB	2(R5),R4	
3423							
3424	013470	001406			BEG	7\$:IF NOT, ERROR
3425	013472	016537	000002	001162	MOV	2(R5),\$REGO	:GET EXPCD FUNCTION CODE IN RKCS
3426	013500	010437	001164		MOV	R4,\$REGI	:GET CODE RECVD
3427	013504	104033			ERROR	33	:FUNCTION CODE THAT IS IN RKCS AFTER THIS
3428							:INTERRUPT OCCURED IS NOT THE EXPECTED ONE
3429	013506	042710	000200		BIC	#BIT7,(R0)	:CLEAR 'FUNCTION IN PROGRESS' BIT
3430	013512	142761	000200	001426	BICB	#BIT7,BUSY(R1)	:CLEAR BUSY FLAG FOR THIS DRIVE
3431	013520	004737	016540		JSR	PC,CHKDRV	:CHECK FOR DRIVE ERRORS
3432	013524	000002			RTI		:IF THERE WAS ANY DRIVE EROR
3433							:DESELECT THE DRIVE AND EXIT
3434							:IF NO ERROR, RETURN HERE
3435	013526	032777	001000	165462	BIT	#SIN,\$RKDS	:SIN ERROR?
3436	013534	001426			BEG	10\$	
3437	013536	004737	022222		JSR	PC,\$G4SDR	:GET RKCS, ER, DS, DA AND DRIVE # FOR
3438							:TYPING SERIAL DRIVE #
3439	013542	104016			ERROR	16	:SIN ERROR
3440	013544	004737	016152		JSR	PC,CLRSIN	
3441	013550	004737	016264		JSR	PC,SINCNT	:HELP COUNT OF SIN'S. IF MORE
3442							:THAN MAXM ALLOWABLE, DESELECT THE DRIVE
3443	013554	000002			RTI		:RETURN HERE IF COUNT=MAX
3444							:RETURN HERE IF LESS THAN MAX
3445	013556	105261	001446		INCB	RETRY(R1)	
3446	013562	122761	000003	001446	CMPB	#3,RETRY(R1)	
3447	013570	001405			BEG	8\$	
3448	013572	052710	010000		BIS	#BIT12,(R0)	
3449	013576	042710	000020		BIC	#BIT4,(R0)	
3450	013602	000002			RTI		
3451							
3452	013604	004737	014426		JSR	PC,DRVABT	:ABORT THIS FUNCTION
3453	013610	000002		8\$:	RTI		
3454				9\$:			
3455	013612	032777	040000	165402	BIT	#HE,\$RKCS	:HARD ERROR?
3456	013620	001076			BNE	HRDERR	
3457	013622	032777	100000	165372	BIT	#ERR,\$RKCS	:SOFT ERROR?
3458	013630	001002			BNE	SFTERR	:YES
3459	013632	000137	014300		JMP	NOERRR	:NO

NO6

```

3500 ; IF THERE WAS A HARD
3501 ; ERROR DURING THE DATA
3502 ; TRANSFER ENTER HERE
3503
3504 014016 032777 010000 165174 HRDERR: BIT #SKE,DRKER ;SKE?
3505 014024 001421 BEQ 1$
3506
3507 014026 032737 000004 001474 BIT #BIT2,ERCODE ;ALREADY WORKING ON A SK ERROR?
3508 014034 001051 BNE CMNERR ;YES - IGNORE THIS ONE
3509 014036 042737 000004 001474 BIC #BIT2,ERCODE ;ANY OTHER ERROR?
3510 014044 001064 BNE CMNABT ;YES - ABORT THIS FUNCTION
3511 014046 052737 000004 001474 BIS #BIT2,ERCODE ;SET THE SK ERROR BIT
3512
3513 014054 005262 001602 INC SKECN(R2) ;INCREMENT COUNT FOR SKE
3514 014060 005262 001562 INC HECN(R2) ;ON THIS DRIVE,
3515
3516 014064 104421 002062 TYPMSG ,MSG1
3517
3518 014070 032777 167740 165122 1$: BIT #167740,DRKER ;ANY HE BESIDES SKE?
3519 014076 001417 BEQ 2$
3520
3521 014100 032737 000010 001474 BIT #BIT3,ERCODE ;ALREADY WORKING ON A HE ERROR?
3522 014106 001024 BNE CMNERR ;YES - IGNORE THIS ONE
3523 014110 042737 000010 001474 BIC #BIT3,ERCODE ;ANY OTHER ERROR?
3524 014116 001037 BNE CMNABT ;YES - ABORT THIS FUNCTION
3525 014120 052737 000010 001474 BIS #BIT3,ERCODE ;SET THE HE ERROR BIT
3526
3527 014126 005262 001562 INC HECN(R2) ;INCREMENT HE COUNT FOR
3528 014132 104421 002104 TYPMSG ,MSG4 ;THIS DRIVE
3529
3530 014136 104421 002120 2$: TYPMSG ,MSG5 ;PRINT 'ON DOING'
3531 014142 004737 021736 JSR PC,TYPFN ;GO PRINT OUT THE FUNCTION
3532 ;WHICH GAVE THIS ERROR
3533
3534 014146 004737 022064 JSR PC,GETINF
3535 014152 004737 022226 JSR PC,GTSDRV ;SAVE DRIVE #, FOR TYPING SERIAL #
3536 014156 104022 ERROR 22 ;HARD ERROR ON DOING DATA XFER
3537
3538 014160 105261 001446 CMNERR: INCB RETRY(R1) ;INCREMENT RETRY COUNT
3539 014164 122761 000003 001446 CMPB #3,RETRY(R1) ;3 TRIES IN ALL?
3540 014172 001411 BEQ CMNABT ;YES, ABORT THIS FUNCTION
3541
3542 014174 052777 010000 165334 BIS #BIT12,DSAVKEY ;INDICATE HIGH PRIORITY ON RETRY
3543 014202 042777 000020 165326 BIC #BIT4,DSAVKEY ;CLEAR 'POSITIONING HEADS', IF SET
3544 014210 004737 016006 JSR PC,CLRERR ;CLEAR THIS ERROR
3545 014214 000002 RTI
3546
3547 014216 005037 001474 CMNABT: CLR ERCODE ;CLEAR ERROR CODE
3548 014222 104421 002532 TYPMSG ,MSG27
3549 014226 004737 014426 JSR PC,DRVABT ;ABORT THE FUNCTION
3550 014232 032777 010000 164760 BIT #SKE,DRKER ;SEEK ERROR?
3551 014240 001416 BEQ 3$ ;NO
3552 014242 104416 CON.RESET ;RESET THE CONTROLLER
3553 014244 010137 001502 MOV R1,QDRV ;SET DRIVE NUMBER
3554 014250 000241 CLC ;CLEAR THE 'C' BIT
3555 014252 006037 001502 ROR QDKV ;LEFT JUSTIFY DRIVE NUMBER

```

3556	014256	006037	001502	ROR	QDRV	:LEFT JUSTIFY DRIVE NUMBER
3557	014262	006037	001502	ROR	QDRV	:LEFT JUSTIFY DRIVE NUMBER
3558	014266	006037	001502	ROR	QDRV	:LEFT JUSTIFY DRIVE NUMBER
3559	014272	104420		DRV.RESET		:RESET THE DRIVE
3560	014274	104416		CON.RESET		:RESET THE CONTROLLER
3561	014276	000002		RTI		:THIS DATA TRANSFER

35:


```

3562                                     ; IF THERE WAS NO HARD OR
3563                                     ; SOFT ERROR ON DATA TRANSFER
3564                                     ; ENTER HERE
3565 014300 105761 001446 NOERROR: TSTB   RETRY(R1)
3566 014304 001406          BEQ     15
3567 014306 104421 002604          TYPMSG MSG28
3568 014312 116146 001446          MOVB   RETRY(R1),-(SP)
3569 014316 104403          TYPOS
3570 014320          002          .BYTE  2
3571 014321          000          .BYTE  0
3572
3573 014322 005037 001474          15:   CLR    ERCODE
3574 014326 105061 001446          CLRB  RETRY(R1)
3575 014332 042777 010000 165176          BIC   #BIT12,2SAVKEY ; CLEAR PRIORITY BIT IF SET
3576 014340 004737 021006          JSR   PC,STATSTC    ; GO, COLLECT STATISTICS ON THIS
3577                                     ; DATA TRANSFER
3578
3579 014344 022704 000004          CMP   #4,R4          ; WAS IT A 'READ' FUNCTION?
3580 014350 001002          BNE  25
3581 014352 004737 017110          JSR   PC,DATCHK     ; IF IT WAS 'READ', CHECK THE DATA
3582
3583
3584
3585 014356 022704 000002          25:   CMP   #2,R4          ; WAS IT A 'WRITE' FUNCTION?
3586 014362 001011          BNE  35
3587 014364 032777 000040 165144          BIT   #BITS,2SAVKEY ; IS 'WRT CHK' TO FOLLOW THIS
3588 014372 001412          BEQ  45              ; 'WRT' FUNCTION?
3589 014374 052703 100000          BIS   #BIT15,R3     ; SET FLAG BIT TO INDICATE
3590                                     ; THAT WRITE CHECK SHOULD
3591                                     ; FOLLOW THIS WRITE
3592 014400 010337 001456          MOV   R3,WCFLG      ; SET UP WC FLAG TO INDICATE
3593                                     ; THE ABOVE. THE LOWER BYTE
3594                                     ; CONTAINS THE POINTER TO THE
3595                                     ; COMMAND LIST, WHICH WILL
3596                                     ; BE USED, FOR DOING WRITE CHECK
3597 014404 000407          BR   55              ; IF WRITE CHECK IS TO BE DONE, DON'T
3598                                     ; SET BIT 15 OF THE KEY TILL WRT CHK
3599                                     ; IS DONE
3600
3601 014406 022704 000006          35:   CMP   #6,R4          ; WRT CHK FUNCTION?
3602 014412 001002          BNE  45
3603 014414 005037 001456          CLR   WCFLG         ; CLEAR WR CHK FLAG
3604
3605 014420 052710 100000          45:   BIS   #BIT15,(R0)  ; SET FLAG TO INDICATE THIS
3606 014424 000002          55:   RTI                    ; FUNCTION IS COMPLETED
  
```

```
3607 ;ABORT THE FUNCTION ON DRIVE POINTED TO BY R1
3608 ;CLEAR ASSOCIATED FLAGS
3609 ;DROP THE DRIVE IF MORE THAN 8. ABORTS
3610
3611 014426 010246          DRVABT: MOV      R2, -(SP)      ;SAVE R2
3612 014430 105061 001446  CLRB     RETRY(R1)
3613 014434 052710 104000  BIS     #104000, (R0) ;INDICATE THAT FUNCTION IS ABORTED
3614 014440 042710 010000  BIC     #BIT12, (R0) ;CLEAR HIGH PRIORITY BIT IF SET
3615 014444 010102          MOV     R1, R2
3616 014446 006302          ASL     R2
3617 014450 005262 001672  INC     ABORT(R2)
3618 014454 026227 001672 0J0010  CMP     ABORT(R2), #10
3619 014462 003402          BLE
3620 014464 000137 016312  JMP     DSELECT      ;DROP THE DRIVE
3621 014470 012602          1$: MOV     (SP)+, R2    ;RESTORE R2
3622 014472 104401 002165  TYPE   ,MSG10        ;TYPE "ABORTED"
3623 014476 000207          RTS     PC          ;RETURN
```

```

3624
3625
3626
3627
3628
3629
3630
3631
3632
3633
3634 014500 104407
3635 014502 005337 002056
3636 014506 001025
3637 014510 013737 001236 002056
3638 014516 104401 014524
3639 014522 000407
3640
3641 014542
3642 014542 013746 001100
3643 014546 005216
3644 014550 104405
3645 014552 004737 021116
3646 014556 000137 022704
3647
3648 014562 032777 000400 164350 1$:
3649 014570 001422
3650 014572 032777 000001 164340
3651 014600 001410
3652 014602 005727
3653 014604 000000 7$:
3654 014606 001013
3655 014610 005237 014604
3656 014614 004737 026660
3657 014620 000406
3658 014622 005037 014604 8$:
3659 014626 104401 001213
3660 014632 004737 021116
3661 014636 032777 000040 164274 2$:
3662 014644 001401
3663 014646 000000
3664
3665 014650 004737 022656 3$:
3666 014654 012700 001306 4$:
3667 014660 010004
3668 014662 005001
3669 014664 010120 5$:
3670 014666 062701 000400
3671 014672 022701 004000
3672 014676 001372
3673 014700 012700 001326
3674 014704 010005
3675 014706 012701 177740
3676 014712 005020 6$:
3677 014714 005201
3678 014716 001375
3679
  
```

```

; THIS ROUTINE GENERATES THE 8 COMMAND REQUESTS AND PUT THEM IN THE QUEUE. THE
; FOLLOWING PARAMETERS ARE GENERATED RANDOMLY:
; 1. DRIVE NUMBER ON WHICH THE COMMAND WILL BE PERFORMED.
; 2. FUNCTION TO BE PERFORMED.
; 3. DISK ADDRESS - CYLINDER, SURFACE, SECTOR.
; 4. STARTING BUS ADDRESS.
; 5. WORD COUNT FOR DATA TRANSFER.
  
```

```

; THE QUEUE IS LOCATED AT 'CMND' (TO 'CMNDB').
  
```

```

GENBRQ: CKSWR
DEC REPCNT ; DECREMENT REPETITION COUNT
BNE 1$ ; CONTINUE IF NOT 0
MOV PCNTR, REPCNT ; REESTABLISH REPETITION COUNT FOR EXERCISER
TYPE 5$ ; TYPE ASCIZ STRING
BR 64$ ; GET OVER THE ASCIZ
; 65$: .ASCIZ <15><12>/END OF PASS/
64$:
MOV $PASS, -(SP)
INC (SP)
TYPDS
JSR PC, REPSTAT
JMP $EOP

1$: BIT #SW8, @SWR
BEQ 2$
BIT #SW00, @SWR ; SWITCH 0 SET ?
BEQ 8$ ; BR IF NOT
TST (PC)+ ; CHECK INDICATOR
; TYPE TIME INDICATOR
BNE 2$ ; BR IF TIME ALREADY TYPED
INC 7$ ; INCREMENT THE INDICATOR
JSR PC, TIMTYP ; TYPE THE TIME (IF SWR 03 SET)
BR 2$ ; CONTINUE
8$: CLR 7$ ; CLEAR THE INDICATOR
TYPE $CRLF
JSR PC, REPSTAT
BIT #SW5, @SWR ; HALT?
BEQ 3$ ; NO
; YES, PRESSING CONTINUE RESUMES PROG EXECUTION
3$: JSR PC, CHDPRS ; CHECK IF ANY DRIVES PRESENT
4$: MOV #KEY, R0
MOV R0, R4
CLR R1
5$: MOV R1, (R0)+ ; CLEAR THE 8 COMMAND KEYS
ADD #400, R1 ; BITS 8,9,10 INDICATE THEIR
CMP #4000, R1 ; POSITION 0,1,2,3,4,5,6,7
BNE 5$
MOV #CMND, R0 ; CLEAR THE PARAMETER TABLE
MOV R0, R5
MOV #-40, R1 ; FOR THE 8 COMMANDS IN Q
6$: CLR (R0)+ ; (8X4) WORDS IN ALL
INC R1
BNE 6$
  
```

```

3680 014720 004737 015770 JSR PC,CLRFLGS ;CLEAR THE FLAGS PERTAINING TO THE B
3681 ;COMMANDS IN THE Q
3682 ;R4 CONTAINS 'KEY'
3683 ;R5 CONTAINS 'CMND'
3684 014724 022737 000001 001264 GEN1: CMP #1,DRVPRS ;ONLY 1 DRV PRESENT?
3685 014732 001002 BNE 22$ ;NO
3686 014734 005000 CLR R0 ;YES
3687 014736 000420 BR 3$
3688 014740 004737 025576 22$: JSR PC,$RAND ;GENERATE A RANDOM NUMBER
3689 ;GET A RANDOM DRIVE NUMBER
3690 ;FROM THE AVAILABLE DRIVES
3691 014744 025730 RSDRVL
3692
3693 014746 013746 025732 MOV RSDRVH,-(SP) ;PUT LOW DIVIDEND ON STACK
3694 014752 005046 CLR -(SP) ;CLEAR HIGH DIVIDEND AND PUSH
3695 ;IT ON STACK
3696 014754 013746 001520 MOV DRMAP,-(SP) ;PUSH DIVISOR ON STACK
3697 014760 004737 025212 JSR PC,#$DIV ;GO TO THE 'DIVIDE' SUBROUTINE
3698 014764 005726 TST (SP)+ ;DISCARD THE REMAINDER. QUOTIENT IS
3699 ;NOW ON TOP OF THE STACK
3700 014766 012600 MOV (SP)+,R0
3701 014770 020037 001264 CMP R0,DRVPRS ;MAKE SURE CORRECT MAPPING IS DONE
3702 014774 001001 BNE 3$
3703 014776 005300 DEC R0 ;'QDRVE' CONTAINS RANDOM DRIVE NO.
3704 015000 005037 001502 CLR QDRV
3705 015004 116037 001254 001502 3$: MOV B PDR(R0),QDRV
3706 015012 105737 001502 TSTB QDRV ;TEST IF TYPE F DRIVE
3707 015016 100016 BPL 32$ ;NOT IF POSITIVE
3708
3709 015020 142737 000200 001502 BICB #200,QDRV ;CLEAR THE FLAG BIT
3710 015026 132737 000001 001502 BITB #1,QDRV ;ODD OR EVEN DRIVE ADDRESS
3711 015034 001404 BEQ 31$
3712
3713 015036 005737 015724 TST ODDEVN ;MUST HAVE BEEN AN ODD ONE
3714 015042 001730 BEQ GEN1 ;INSURE THAT ODDS WHAT WE WANT
3715 015044 000403 BR 32$
3716
3717 015046 005737 015724 31$: TST ODDEVN ;MUST HAVE BEEN AN EVEN ONE
3718 015052 001332 BNE 22$ ;NO GOOD - TRY AGAIN
3719
3720 015054 004737 025576 32$: JSR PC,$RAND ;GENERATE A RANDOM NUMBER
3721 015060 025734 RSFUNL
3722
3723 015062 013746 025736 MOV RSFUNH,-(SP) ;PUT LOW DIVIDEND ON STACK
3724 015066 005046 CLR -(SP) ;CLEAR HIGH DIVIDEND AND PUSH
3725 ;IT ON STACK
3726 015070 013746 001526 MOV FNMAP,-(SP) ;PUSH DIVISOR ON STACK
3727 015074 004737 025212 JSR PC,#$DIV ;GO TO THE 'DIVIDE' SUBROUTINE
3728 015100 005726 TST (SP)+ ;DISCARD THE REMAINDER. QUOTIENT IS
3729 ;NOW ON TOP OF THE STACK
3730 015102 021627 000003 CMP (SP),#3 ;MAKE SURE CORRECT FUNCTION IS SELCTD
3731 015106 001001 BNE 20$
3732 015110 005316 DEC (SP)
3733 015112 012637 001512 20$: MOV (SP)+,QFNC ;THE FUNCTION THAT CAN BE PERFORMED
3734
3735 015116 004737 025576 JSR PC,$RAND ;GENERATE A RANDOM NUMBER

```

G07

```

3736 015122 025740 RSCYLL
3737
3738 015124 013746 025742 MOV RSCYLH,-(SP) ;PUT LOW DIVIDEND ON STACK
3739 015130 005046 CLR -(SP) ;CLEAR HIGH DIVIDEND AND PUSH
3740 ;IT ON STACK
3741 015132 013746 001522 MOV CYLMAP,-(SP) ;PUSH DIVISOR ON STACK
3742 015136 004737 025212 JSR PC,2*SDIV ;GO TO THE 'DIVIDE' SUBROUTINE
3743 015142 005726 TST (SP)+ ;DISCARD THE REMAINDER. QUOTIENT IS
3744 ;NOW ON TOP OF THE STACK
3745 015144 012637 001504 MOV (SP)+,QCYL ;(FROM 0-312)
3746 015150 022737 000313 001504 CMP #313,QCYL
3747 015156 001002 BNE 4$
3748 015160 005337 001504 DEC QCYL ;'QCYL' CONTAINS RANDOM CYLINDER NO.
3749
3750 015164 4$:
3751
3752 015164 013746 025742 MOV RSCYLH,-(SP) ;PUT LOW DIVIDEND ON STACK
3753 015170 005046 CLR -(SP) ;CLEAR HIGH DIVIDEND AND PUSH
3754 ;IT ON STACK
3755 015172 013746 001524 MOV SECMAP,-(SP) ;PUSH DIVISOR ON STACK
3756 015176 004737 025212 JSR PC,2*SDIV ;GO TO THE 'DIVIDE' SUBROUTINE
3757 015202 005726 TST (SP)+ ;DISCARD THE REMAINDER. QUOTIENT IS
3758 ;NOW ON TOP OF THE STACK
3759 015204 012637 001510 MOV (SP)+,QSEC ;(BETWEEN 0-13/8)
3760 015210 022737 000014 001510 CMP #14,QSEC
3761 015216 001002 BNE 5$
3762 015220 005337 001510 DEC QSEC ;'QSEC' CONTAINS RANDOM SEC #
3763
3764 015224 022737 077777 025742 5$: CMP #77777,RSCYLH ;SELECT SURFACE # RANDOMLY
3765 015232 101005 BHI 6$
3766 015234 012737 000020 001506 MOV #BIT4,QSUR ;SURFACE 1
3767 ;R1 CONTAINS THE MAXM WORD COUNT BASED ON
3768 ;AVAILABLE DISK SPACE.
3769 ;R2 CONTAINS THE MAXM WORD COUNT BASED ON
3770 ;AVAILABLE MEMORY SPACE.
3771 015242 005001 CLR R1
3772 015244 000404 BR 7$
3773
3774 015246 005037 001506 6$: CLR QSUR ;SURFACE 0
3775 015252 012701 000014 MOV #14,R1 ;14 SECTORS ON SUR 0
3776
3777 ;ASSUMING THAT ENOUGH MEMORY IS AVAILABLE THE MAXIMUM TRANSFER THAT CAN
3778 ;TAKE PLACE IS 20K WORDS. IF THE RANDOM CYLINDER # > OR = TO 307 AND THE
3779 ;SURFACE IS 1, CHANCES ARE THAT THE NUMBER OF WORDS TO BE TRANSFERRED MAY
3780 ;BE GREATER THAN THE SPACE AVAILABLE ON THE DISK. IN THAT CASE, THE WORDS
3781 ;COUNT IS TO BE SELECTED IN SUCH WAY THAT THIS OVERFLOW DOES NOT OCCUR.
3782
3783 015256 023727 001504 000306 7$: CMP QCYL,#306 ;IS THE RANDOM CYL # GREATER THAN 306?
3784 015264 002003 BGE 9$
3785 015266 012701 177777 8$: MOV #177777,R1 ;IF YES, MAKE SURE THAT THE
3786 015272 000431 BR 21$ ;WORD COUNT IS SELECTED PROPERLY
3787 ;COMPUTE MAXM WORD COUNT BASED ON
3788 ;AVAILABLE DISK SPACE
3789 015274 012700 000014 9$: MOV #14,R0 ;COMPUTE # OF SECTORS AVAILABLE ON
3790 015300 163700 001510 SUB QSEC,R0 ;CYLINDERS SELECTED
3791 015304 060001 ADD R0,R1
    
```

407

3792	015306	012703	000312		MOV	#312,R3	: COMPUTE # OF SECTORS AVAILABLE
3793	015312	163703	001504		SUB	QCYL,R3	: BEYOND THE CYLINDER SELECTED
3794	015316	012746	000030		MOV	#30,-(SP)	:: PUT THE MULTIPLIER ON THE STACK
3795	015322	010346			MOV	R3,-(SP)	:: PUT THE MULTIPLICAND ON THE STACK
3796	015324	004737	025100		JSR	PC,@#SMULT	:: CALL THE MULTIPLY ROUTINE
3797	015330	012616			MOV	(SP)+,(SP)	:: DISREGARD THE MSB'S
3798	015332	012603			MOV	(SP)+,R3	:: GET THE LSB'S OF THE PRODUCT
3799	015334	060103			ADD	R1,R3	: COMPUTE TOTAL # OF SECTORS AVAILABLE
3800	015336	012746	000400		MOV	#400,-(SP)	:: PUT THE MULTIPLIER ON THE STACK
3801	015342	010346			MOV	R3,-(SP)	:: PUT THE MULTIPLICAND ON THE STACK
3802	015344	004737	025100		JSR	PC,@#SMULT	:: CALL THE MULTIPLY ROUTINE
3803	015350	012616			MOV	(SP)+,(SP)	:: DISREGARD THE MSB'S
3804	015352	012603			MOV	(SP)+,R3	:: GET THE LSB'S OF THE PRODUCT
3805	015354	010301			MOV	R3,R1	: COMPUTE TOTAL # OF WORDS-SPACE
3806							: AVAILABLE ON DISK FROM THE SELECTED
3807							: CYL #
3808							: COMPUTE MAXM WORD COUNT BASED ON
3809							: AVAILABLE MEMORY SPACE.
3810	015356	004737	025576	215:	JSR	PC,\$RAND	: GENERATE RANDOM NUMBER
3811	015362	025744			RSBAL		
3812							
3813	015364	013746	025746		MOV	RSBAH,-(SP)	: PUT LOW DIVIDEND ON STACK
3814	015370	005046			CLR	-(SP)	: CLEAR HIGH DIVIDEND AND PUSH
3815							: IT ON STACK
3816	015372	013746	001530		MOV	BAMAP,-(SP)	: PUSH DIVISOR ON STACK
3817	015376	004737	025212		JSR	PC,@#SDIV	: GO TO THE 'DIVIDE' SUBROUTINE
3818	015402	005726			TST	(SP)+	: DISCARD THE REMAINDER. QUOTIENT IS
3819							: NOW ON TOP OF THE STACK
3820	015404	012637	001514		MOV	(SP)+,QBUSAD	: BE USED
3821	015410	006337	001514		ASL	QBUSAD	
3822	015414	063737	002052	001514	ADD	BASEBA,QBUSAD	: FORM THE RANDOM BUS-ADDRESS
3823							: BY ADDING RANDOM OFFSET TO
3824							: THE BASE BUS-ADDRESS
3825	015422	013703	002054		MOV	MAXBA,R3	: COMPUTE # OF WORDS THAT
3826	015426	163703	001514		SUB	QBUSAD,R3	: CAN BE TRANSFERRED, USING THE
3827	015432	000241			CLC		
3828	015434	006003			ROR	R3	: ABOVE GENERATED BUS-ADDRESS WITHOUT
3829	015436	010302			MOV	R3,R2	: CAUSING A NXM
3830							
3831	015440	020201		105:	CMP	R2,R1	: SELECT SMALLER OF THE TWO
3832	015442	103401			BLC	115	: WORD-COUNTS THAT WILL BE
3833							: USED FOR GENERATING A RANDOM
3834	015444	010103			MOV	R1,R3	: WORD COUNT)
3835							
3836							: R3 CONTAINS THE MAXM WORD COUNT
3837							: POSSIBLE. COMPUTE THE WORD COUNT
3838							: MAPPING FACTOR FROM THIS.
3839	015446			115:			
3840							
3841	015446	012746	177777		MOV	#177777,-(SP)	: PUT LOW DIVIDEND ON STACK
3842	015452	005046			CLR	-(SP)	: CLEAR HIGH DIVIDEND AND PUSH
3843							: IT ON STACK
3844	015454	010346			MOV	R3,-(SP)	: PUSH DIVISOR ON STACK
3845	015456	004737	025212		JSR	PC,@#SDIV	: GO TO THE 'DIVIDE' SUBROUTINE
3846	015462	005726			TST	(SP)+	: DISCARD THE REMAINDER. QUOTIENT IS
3847							: NOW ON TOP OF THE STACK

```

3848 015464 005216          INC      (SP)
3849 015466 012637 001532  MOV      (SP)+,WCMAP      ;WORD COUNT MAPPING FACTOR
3850
3851 015472 004737 025576  JSR      PC,$RAND        ;GENERATE A RANDOM NUMBER
3852 015476 025750          RSWCL
3853
3854 015500 013746 025752  MOV      RSWCH,-(SP)      ;PUT LOW DIVIDEND ON STACK
3855 015504 005046          CLR      -(SP)            ;CLEAR HIGH DIVIDEND AND PUSH
3856                                     ;IT ON STACK
3857 015506 013746 001532  MOV      WCMAP,-(SP)      ;PUSH DIVISOR ON STACK
3858 015512 004737 025212  JSR      PC,$DIV          ;GO TO THE 'DIVIDE' SUBROUTINE
3859 015516 005726          TST      (SP)+           ;DISCARD THE REMAINDER. QUOTIENT IS
3860                                     ;NOW ON TOP OF THE STACK
3861 015520 012637 001516  MOV      (SP)+,QWRCNT     ;'QWRCNT' CONTAINS THE RANDOM
3862                                     ;WORD COUNT THAT WILL BE USED
3863 015524 005737 001516  TST      QWRCNT          ;MAKE SURE THE WORD COUNT IS
3864 015530 003004          BGT      12$             ;NOT 0
3865 015532 005437 001516  NEG      QWRCNT          ;TAKE CARE OF ZERO AND NEG NUMBRS
3866 015536 005237 001516  INC      QWRCNT
3867 015542 113700 001502  12$: MOVB   QDRV,RO
3868 015546 000241          CLC
3869 015550 006000          ROR      RO
3870 015552 006000          ROR      RO              ;POSITION THE DRIVE NUMBER IN
3871 015554 006000          ROR      RO              ;BITS 15,14,13
3872 015556 006000          ROR      RO
3873 015560 013701 001504  MOV      QCYL,R1
3874 015564 000301          SWAB   R1
3875 015566 000241          CLC
3876 015570 006001          ROR      R1              ;POSITION THE CYLINDER NUMBER
3877 015572 006001          ROR      R1              ;IN BITS 12-5
3878 015574 006001          ROR      R1
3879 015576 050100          BIS      R1,RO
3880 015600 053700 001510  BIS      QSEC,RO          ;RO CONTAINS THE COMPLETE DISK
3881 015604 053700 001506  BIS      QSUR,RO          ;ADDRESS
3882 015610 010025          MOV      RO,(R5)+        ;INSERT RKDA IN THE PARAMETER TABLE
3883                                     ; (FOR THE 8 COMMANDS)
3884                                     ; WHICH FUNCTION?
3885                                     ; 0-READ CHECK, 1-READ, 2-WRITE
3886 015612 022737 000001 001512  CMP      #1,QFNC
3887 015620 001412          BEQ     2$
3888 015622 003014          BGT     14$
3889 015624 012725 000002 15$: MOV     #2,(R5)+
3890 015630 023727 025752 077777  CMP     RSWCH,#77777
3891 015636 101010          BHI     15$
3892 015640 052714 000040  BIS     #BIT5,(R4)
3893                                     ;SET FLAG IN KEY TO INDICATE
3894                                     ;THAT WRITE CHECK SHOULD BE
3895                                     ;DONE FOLLOWING THE WRITE
3896
3897 015646 012725 000004 2$: MOV     #4,(R5)+        ;READ FUNCTION CODE
3898 015652 000402          BR
3899
3900 015654 012725 000012 14$: MOV     #12,(R5)+      ;READ CHECK FUNCTION CODE
3901
3902 015660 013715 001516 15$: MOV     QWRCNT,(R5)    ;INSERT THE WORD COUNT (RWOC)
3903 015664 005425          NEG     (R5)+           ;(2'S COMPLEMENT)

```

3904	015666	013725	001514			MOV	QBUSAD,(R5)+	: INSERT THE BUS ADDRESS (RKBA) FOR : THIS COMMAND IN THE PARAMETER : TABLE
3905								
3906								
3907	015672	053724	001502	16\$:		BIS	QDRV,(R4)+	: SET THE DRIVE NUMBER INSIDE : THE KEY FOR THIS COMMAND
3908								
3909	015676	020427	001326			CMP	R4,#KEY+20	: GENERATED 8 COMMANDS IN : THE QUEUE?
3910								
3911	015702	001402				BEG	17\$	
3912	015704	000137	014724			JMP	GEN1	: IF NOT, GO BACK AND GENERATE : THE NEXT COMMAND AND THE : PARAMETERS (RKWC, BA, DA)
3913								
3914								
3915	015710	005237	015724	17\$:		INC	ODDEVN	: CHANGE FROM ODD/ENEN TO EVEN/ODD
3916	015714	042737	177776	015724		BIC	#177776,ODDEVN	: KEEP ONLY ONE BIT
3917	015722	000207				RTS	PC	: ALL 8 COMMANDS HAVE BEEN : GENERATED IN THE TASK-QUEUE
3918								
3919	015724	000000					ODDEVN: 0	

k07

```

3920 ;ENTER THIS CODE IF SW 9 HAS BEEN SET AND LOOPING HAS TO BE DONE ON ERROR
3921 ;CONTROL IS TRANSFERRED TO THIS, ON RETURN FROM THE ERROR HANDLER 'SEPRCR'.
3922
3923
3924 015726 004737 016006 EXCRUP: JSR PC,CLRERR ;WAIT FOR OTHER DRIVES TO GET DONE
3925 ;THEN ISSUE A CONTROL RESET
3926 015732 010146 MOV R1,-(SP)
3927 015734 012701 001306 MOV #KEY,R1 ;CLEAR OUT THE COMMAND-KEYS
3928 015740 042721 114220 BIC #114220,(R1)+
3929 015744 020127 001326 1$: CMP R1,#KEY+20
3930 015750 001373 BNE 1$
3931 015752 012601 MOV (SP)+,R1
3932 015754 004737 015770 JSR PC,CLRFLGS ;CLEAR OUT THE VARIOUS FLAGS PERTAINING
3933 ;TO THE 8 COMMANDS IN THE Q
3934 015760 012706 001100 MOV #STACK,SP ;REESTABLISH STACK POINTER
3935 015764 000137 010650 JMP QMNGER ;START OVER AGAIN, PROCESS THE COMMANDS
3936 ;IN THE Q AGAIN. NOTE THAT ON LOOPING
3937 ;(ON EROR, WITH SW 9) AN ATTEMPT IS MADE
3938 ;TO RECREATE THE SET OF EVENTS WHICH LED TO
3939 ;ERROR.
3940
3941
3942
3943
3944 ;CLRFLGS
3945 ;THIS ROUTINE CLEARS OUT THE VARIOUS FLAGS USED FOR THE 8 COMMANDS IN THE QUEUE.
3946
3947 015770 012700 001426 CLRFLGS: MOV #BUSY,R0 ;CLEAR THE 8 BUSY FLAGS
3948 015774 005020 1$: CLR (R0)+
3949 015776 020027 001462 CMP R0,#QSCNT+2 ;ALL DONE?
3950 016002 001374 BNE 1$ ;NO
3951 016004 000207 RTS PC
  
```

L07

```

3952          :CLRERR
3953          :THIS ROUTINE IS ENTERED WHEN A HARD ERROR HAS OCCURRED AND IT HAS TO BE
3954          :CLEARED. THE DRIVES THAT HAVE BEEN BUSY ARE CHECKED TO SEE IF THEIR R/W/S
3955          :RDY BIT HAS SET. WHEN R/W/S IS SET, CHECKING IS DONE FOR ANY ERROR. IF A
3956          :ERROR OCCURED IT IS REPORTED. IF NOT, APPROPRIATE FLAGS ARE SET AND
3957          :CLEARED FOR THAT DRIVE. AFTER ABOVE IS DONE FOR ALL DRIVES THAT HAVE BEEN
3958          :SEEKING, A CONTROL RESET IS ISSUED TO CLEAR THE HARD ERROR.
3959
3960 016006 010446          CLRERR: MOV      R4,-(SP)          ;SAVE R4, R4 ON THE STACK
3961 016010 010546          MOV      R5,-(SP)
3962 016012 005005          CLR      R5
3963 016014 005077 163210  CLR      @RKDA
3964
3965 016020 105765 001426 1$:  TSTB    BUSY(R5)          ;WAS THIS DRIVE BUSY SEEKING?
3966 016024 100035          BPL     4$                      ;NO
3967 016026 005037 001472  CLR     TIMER
3968 016032 032777 000100 163156 2$:  BIT     @RWS,@RKDS          ;R/W/S SET?
3969 016040 001015          BNE     3$                      ;YES
3970 016042 005237 001472  INC     TIMER          ;KEEP TIME
3971 016046 001371          BNE     2$                      ;WAIT FOR R/W/S RDY
3972 016050 004737 022222  JSR    PC,RG4SDR          ;GET RKCS, ER, DS, DA AND DRIVE # FOR
3973                                ;TYPING SERIAL DRIVE #
3974 016054 104004          ERROR  4                      ;R/W/S READY DID NOT SET
3975                                ;FOR THIS DRIVE, WAITED LONG ENOUGH.
3976 016056 032777 001000 163132  BIT     @SIN,@RKDS          ;SIN ERROR ON THIS DRIVE?
3977 016064 001403          BEQ     3$
3978 016066 004737 022222  JSR    PC,RG4SDR          ;GET RKCS, ER, DS, DA AND DRIVE # FOR
3979                                ;TYPING SERIAL DRIVE #
3980 016072 104016          ERROR  16                     ;SIN OCCURED ON THIS DRIVE
3981
3982 016074 116504 001426 3$:  MOVB   BUSY(R5),R4          ;FORM THE ADDRESS OF THE
3983 016100 042704 177760  BIC    @177760,R4          ;KEY WHICH MADE THIS DRIVE
3984 016104 062704 001306  ADD    @KEY,R4 ;BUSY
3985
3986 016110 042714 010000  BIC    @10000,(R4)        ;CLEAR HIGH PRIORITY BIT, IF SET
3987 016114 105065 001426  CLRB   BUSY(R5)          ;MAKE THIS DRIVE FREE, AVAILABLE
3988
3989
3990 016120 062777 020000 163102 4$:  ADD    @20000,@RKDA        ;ADDRESS THE NEXT POSSIBLE DRIVE
3991 016126 005205          INC    R5                    ;INCREMENT COUNT
3992 016130 022705 000010  CMP    @10,R5              ;ALL DONE
3993 016134 001331          BNE    1$                    ;NO
3994
3995 016136 004737 020340  JSR    PC,CRCMND          ;SAVE INFO ABOUT THE PAST & PRESENT COMAND
3996 016142 104416          CON.RESET
3997 016144 012605          MOV    (SP)+,R5            ;RESTORE R4,R5
3998 016146 012604          MOV    (SP)+,R4
3999 016150 000207          RTS     PC                  ;RETURN
    
```

```

4000 ;CLRSIN
4001 ;THIS ROUTINE IS ENTERED WHEN THERE IS A 'SIN' ERROR. AT TIME OF ENTRY
4002 ;RKDA CONTAINS THE DRIVE # THAT GAVE 'SIN'. A DRIVE RESET IS DONE ON THAT
4003 ;DRIVE. AFTER IT IS DONE, ROUTINE 'CLRHE' IS ENTERED, TO WAIT FOR THE
4004 ;OTHER DRIVES THAT HAVE BEEN DOING SEEKS. WHEN ALL THE DRIVES GIVE
4005 ;'R/W/S RDY' A CONTROL RESET IS DONE, RETURN IS MADE BACK TO THIS
4006 ;ROUTINE-'CLRSIN'- AND FINALLY CONTROL IS TRANSFERRED BACK TO THE MAIN
4007 ;PROGRAM.
4008
4009 016152 017737 163052 001516 CLRSIN: MOV @RKDA,@WRCNT ;SAVE DISK ADDRESS
4010 016160 004737 016006 JSR PC,CLRERR ;GO, WAIT FOR OTHER DRIVES TO COMPLETE
4011 ;THEIR SEEKS(IF THEY ARE DOING ANY)
4012 ;THEN DO CON.RESET TO CLR THE EROR.
4013 016164 013777 001516 163036 MOV @WRCNT,@RKDA ;ADDRESS THE DRIVE AGAIN
4014 016172 004737 020314 JSR PC,DRCMND ;SAVE INFO ABOUT THE PAST & PRESENT COMAND
4015 016176 012777 000015 163016 MOV #15,@RKCS ;DO DRIVE RESET ON THE
4016 ;DRIVE
4017 ;INDICATED IN RKDA
4018
4018 016204 104417 CON.RDY
4019 016206 005037 001472 CLR TIMER
4020 016212 032777 000100 162776 15: BIT #RWS,@RKDS ;WAIT FOR R/W/S RDY TO SET
4021 016220 001015 BNE 25
4022 016222 005237 001472 INC TIMER
4023 016226 001371 BNE 15
4024 016230 004737 022222 JSR PC,RG4SDR ;GET RKCS, ER, DS, DA AND DRIVE # FOR
4025 ;TYPING SERIAL DRIVE #
4026 016234 104004 ERROR 4 ;R/W/S RDY DID NOT SET AFTER
4027 ;DOING DRIVE RESET, TIMED OUT
4028 016236 032777 001000 162752 BIT #SIN,@RKDS
4029 016244 001403 BEQ 25
4030 016246 004737 022222 JSR PC,RG4SDR ;GET RKCS, ER, DS, DA AND DRIVE # FOR
4031 ;TYPING SERIAL DRIVE #
4032 016252 104016 ERROR 16 ;A DRIVE RESET WAS DONE ON THIS DRIVE
4033 ;TO CLEAR 'SIN', BUT 'SIN' DID NOT GET
4034 ;CLEARED
4035
4036 016254 004737 020340 25: JSR PC,CRCMND ;SAVE INFO ABOUT THIS COMMAND
4037 016260 104416 CON.RESET ;DO IT TO CLEAR OUT MASK F/FS
4038 016262 000207 RTS PC ;EXIT FROM THIS ROUTINE

```

4039
4040
4041
4042
4043
4044
4045
4046
4047
4048
4049
4050
4051
4052
4053
4054
4055
4056
4057

016264 105261 001622
016270 122761 000005 001622
016276 101403
016300 062716 000002
016304 000207
016306 000137 016312

```
:SINCNT  
:THIS ROUTINE IS ENTERED WHEN A 'SIN' ERROR OCCURS. THE 'SIN' COUNT FOR  
:THE DRIVE GIVING 'SIN' IS INCREMENTED. IF MORE THAN 5 'SIN' ERRORS  
:OCCURRED THE DRIVE IS DESELECTED. AT THE TIME OF ENTRY R1 CONTAINS THE  
:DRIVE NUMBER THAT GAVE 'SIN' ERROR.  
:CALL: JSR PC,SINCNT  
:----- RETURN HERE IF SIN COUNT (MAXIMUM ALLOWABLE)  
:----- WAS EXCEEDED.  
:----- RETURN HERE IF TOTAL SIN COUNT LESS THAN MAXIMUM  
:----- ALLOWABLE.  
  
SINCNT: INCB SINCN(R1) ;INCREMENT 'SIN' COUNT FOR THIS DRIVE  
CMPB #5,SINCN(R1) ;5 ERRORS OCCURRED?  
BLOS 1$ ;YES  
ADD #2,(SP) ;ADJUST PC FOR RETURN TO THE RIGHT POINT  
RTS PC ;RETURN  
  
1$: JMP DSELCT ;5 ERRORS OCCURRED, GO DESELECT
```

```

4058      ;DSELECT
4059      ;THIS ROUTINE IS ENTERED WHEN A DRIVE IS TO BE DESELECTED (TAKEN
4060      ;OUT OF SELECTION LIST), BECAUSE THE FATAL ERRORS ON THAT DRIVE
4061      ;HAS REACHED A MAXIMUM COUNT. R1 CONTAINS THE DRIVE NUMBER THAT
4062      ;THAT IS TO BE DESELECTED. THE DRIVE IS DESELECTED IF 1. TOTAL SIN COUNT
4063      ;FOR THAT DRIVE REACHES THE MAXIMUM ALLOWABLE 2. IF A FATAL ERROR
4064      ;LIKF DRIVE UNSAFE, DRIVE POWER LOW OCCURS. 3. IF WPS GETS SET, OR DRY
4065      ;IS CLEAR.
4066
4067
4068
4069      016312 012705 001253      DSELECT: MOV      #PDR-1,R5
4070      016316 013702 001264      MOV      DRVPRS,R2
4071      016322 062702 001253      ADD      #PDR-1,R2
4072      016326 005205      1$:      INC      R5
4073      016330 111503      MOV      (R5),R3
4074      016332 042703 177600      BIC      #177600,R3
4075      016336 020301      CMP      R3,R1
4076      016340 001403      BEQ      2$
4077      016342 020502      CMP      R5,R2
4078      016344 103770      BLO     1$
4079      016346 000472      BR      11$
4080      016350 111502      2$:      MOV      (R5),R2
4081      016352 020527 001264      5$:      CMP      R5,#PDR+10
4082      016356 001406      BEQ      4$
4083      016360 010504      MOV      R5,R4
4084      016362 005205      INC      R5
4085      016364 112524      3$:      MOV      (R5)+,(R4)+
4086      016366 022704 001263      CMP      #PDR+7,R4
4087      016372 001374      BNE     3$
4088      016374 105065 177777      4$:      CLRB    -1(R5)
4089
4090      ;THE DRIVE # TYPED OUT WAS DESELECTED
4091      ;BECAUSE ERROR COUNT EXCEEDED THE
4092      ;MAXIMUM ALLOWABLE
4093      016400 104401 002336      TYPE    MSG19
4094      016404 010146      MOV      R1,-(SP)
4095      016406 104403      TYPOS
4096      016410 001      .BYTE  1
4097      016411 000      .BYTE  0
4098      016412 004737 026766      JSR     PC,SNOTYP
4099
4100      016416 005337 001264      DEC     DRVPRS
4101
4102      016422 004737 022656      JSR     PC,CHDPRS
4103
4104
4105      016426 012746 177777      MOV     #177777,-(SP)
4106      016432 005046      CLR     -(SP)
4107
4108      016434 013746 001264      MOV     DRVPRS,-(SP)
4109      016440 004737 025212      JSP    PC,#SDIV
4110      016444 005726      TST    (SP)+
4111
4112      016446 012637 001520      MOV     (SP)+,DRAMAP
4113

```

```

;NUMBER OF DRIVES BEING TESTED
;FOR END ADDRESS OF TABLE
;LOCATE THE DRIVE (TO BE
;DESELECTED) IN THE TABLE
;DROP THE F FLAG
;IS THIS THE ONE
;CONTAINING AVAILABLE DRIVES
;FINISHED ?
;BR IF NOT
;DRIVE WAS NOT FOUND IN TABLE, EXIT
;GET THE DRIVE NUMBER
;IS THIS DRIVE # THE LAST ENTRY IN "TABLE"
;YES
;IF NOT, TAKE OUT THIS DRIVE # FROM
;THE MIDDLE AND PUSH UP THE
;REST OF THE ENTRIES
;CLEAR LAST ENTRY IN TABLE
;TYPE "DRAVE DROPPED"
;PUSH DRIVE NUMBER ON STACK
;TYPE IT ON THE TERMINAL
;GO TYPE OUT SERIAL NO OF THE DRIVE,
;IF SW 1 IS SET.
;DECREMENT THE TOTAL NUMBER OF
;DRIVES PRESENT
;CHECK IF ANY DRIVES PRESENT
;IF NONE GOT TO END OF PASS. $EOP
;PUT LOW DIVIDEND ON STACK
;CLEAR HIGH DIVIDEND AND PUSH
;IT ON STACK
;PUSH DIVISOR ON STACK
;GO TO THE 'DIVIDE' SUBROUTINE
;DISCARD THE REMAINDER. QUOTIENT IS
;NOW ON TOP OF THE STACK
;TO BE USED FOR GENERATING RANDOM
;DRIVE NUMBERS.

```

```

4114 016452 012704 001306      MOV      #KEY,R4      ;DESELECT THE COMMANDS
4115 016456 011405      6$: MOV      (R4),R5    ;IN THE 'COMMAND Q' CORRESPONDING
4116 016460 042705 177770      BIC      #177770,R5   ;TO THE DESELECTED DRIVE
4117 016464 020105      CMP      R1,R5
4118 016466 001002      BNE      7$
4119 016470 052714 104000      BIS      #104000,(R4) ;INDICATE COMMAND DESELECTED
4120 016474 005724      7$: TST      (R4)+     ;(AND COMPLETED)
4121 016476 022704 001326      CMP      #KEY+20,R4
4122 016502 001365      BNE      6$
4123
4124 016504 105702      8$: TSTB     R2        ;'F' TYPE DRIVE ?
4125 016506 100012      BPL      11$         ;NO - JUST EXIT
4126 016510 032701 000001      BIT      #1,R1       ;ODD OR EVEN DRIVE NUMBER
4127 016514 001403      BEQ      9$
4128 016516 042701 000001      BIC      #1,R1
4129 016522 000402      BR       10$
4130 016524 052701 000C      9$: BIS      #1,R1
4131 016530 000137 016312      10$: JMP      DSELCT  ;DROP CORRESPONDING DRIVE
4132
4133
4134 016534 000137 010630      11$: JMP      BEGNEY  ;GO RESTART EXERSISOR PART OF TEST
  
```

```

4135      ;CHKDRV
4136      ;THIS ROUTINE CHECKS FOR FATAL ERRORS OF THE DRIVE LIKE DPL, DRV
4137      ;WPS. IF ANY ONE OF THESE ERRORS OCCUR THE DRIVE IS DESELECTED
4138      ;AND NO MORE FUNCTIONS WILL BE PERFORMED ON THAT DRIVE. R1
4139      ;CONTAINS THE DRIVE NUMBER TO BE CHECKED.
4140
4141      ;*NOTE 1: IN THE ERROR MESSAGE WHERE RKDA IS PRINTED OUT, IT GIVES
4142      ;*ONLY THE DRIVE NUMBER (NOT CYLINDER, SUFACE AND SECTOR).
4143
4144      ;CALL: JSR      PC,CHKDRV
4145      ;      ----- RETURN HERE IF ANY FATAL ERROR OCCURED
4146      ;      ----- RETURN HERE IF THERE WAS NO FATAL ERROR
4147
4148      016540 017746 162464      CHKDRV: MOV      DRKDA, -(SP)      ;SAVE RKDA
4149      016544 010146              MOV      R1, -(SP)      ;GET DRIVE #
4150      016546 000241              CLC
4151      016550 006016              ROR      (SP)
4152      016552 006016              ROR      (SP)
4153      016554 006016              ROR      (SP)
4154      016556 006016              ROR      (SP)
4155      016560 012677 162444      MOV      (SP)+, DRKDA      ;ADDRESS THE DRIVE TO BE CHECKED
4156      016564 032777 010000 162424      BIT      #DPL, DRKDS      ;DRIVE POWER LOW?
4157      016572 001403              BEQ      1$
4158      016574 004737 022222      JSR      PC, RG4SDR      ;GET RKCS, ER, DS, DA AND DRIVE #
4159                                ;FOR TYPING SERIAL NUMBER
4160      016600 104035              ERROR    35              ;DRIVE POWER LO, *NOTE 1 ABOVE
4161      016602 032777 002000 162406 1$:      BIT      #DRU, DRKDS      ;DRIVE
4162      016610 001403              BEQ      2$
4163      016612 004737 022222      JSR      PC, RG4SDR      ;GET RKCS, ER, DS, DA AND DRIVE #
4164                                ;FOR TYPING SERIAL NUMBER
4165      016616 104036              ERROR    36              ;DRIVE UNSAFE BIT IS SET
4166                                ;*NOTE 1 ABOVE
4167      016620 032777 000040 162370 2$:      BIT      #WPS, DRKDS      ;WRITE PROTECT SET?
4168      016626 001403              BEQ      3$
4169      016630 004737 022222      JSR      PC, RG4SDR      ;GET RKCS, ER, DS, DA AND DRIVE #
4170                                ;FOR TYPING SERIAL NUMBER
4171      016634 104037              ERROR    37              ;WPS SET, CHECK WRITE PROTECT SWITCH ON DRIVE
4172                                ;*NOTE 1 ABOVE
4173      016636 032777 000200 162352 3$:      BIT      #DRY, DRKDS      ;DRIVE READY CLEAR?
4174      016644 001004              BNE      4$
4175      016646 004737 022222      JSR      PC, RG4SDR      ;GET RKCS, ER, DS, DA AND DRIVE #
4176                                ;FOR TYPING SERIAL NUMBER
4177      016652 104034              ERROR    34              ;DRIVE READY CLEAR, SHOULD BE SET
4178                                ;*NOTE 1 ABOVE
4179      016654 000411              BR       5$
4180
4181      016656 032777 012040 162332 4$:      BIT      #12040, DRKDS      ;ANY ERROR?
4182      016664 001005              BNE      5$              ;YES
4183      016666 012677 162336      MOV      (SP)+, DRKDA      ;RESTORE RKDA
4184      016672 062716 000002      ADD      #2, (SP)      ;ADJUST RETURN ADDRESS
4185      016676 000207              RTS      PC
4186
4187      016700 000137 016312      5$:      JMP      DSELECT
    
```

EUS

```

4188 ;GENBUF
4189 ;THIS ROUTINE GENERATES A BUFFER FULL OF RANDOM DATA WORDS. THIS BUFFER
4190 ;IS THEN USED TO WRITE DATA ON THE DISK. AT THE TIME OF ENTRY, RKDA
4191 ;CONTAINS THE DISK ADDRESS WHERE WRITE WILL BE DONE. SEED WORDS USED FOR
4192 ;THE RANDOM NUMBERS ARE:
4193 ; 1) ABSOLUTE DISK ADDRESS (DRIVE #, CYL #, SEC #, SUR #) - $HINUM
4194 ; 2) COMPLEMENT OF THE ABOVE WORD
4195 ;CALL: JSR R5,GENBUF
4196 ; X IS THE WORD COUNT (2'S COMPLEMENT)
4197 ; Y IS THE STARTING ADDRESS OF THE
4198 ; MEMORY BUFFER.
4199
4200 016704 104414 GENBUF: SAVREG ;SAVE REGISTERS
4201 016706 016504 000002 MOV 2(R5),R4 ;GET STARTING ADDRESS OF BUFFER
4202 016712 011503 MOV (R5),R3 ;GET WORD COUNT (# OF WORDS TO
;BE GENERATED)
4203
4204
4205 016714 017702 162310 1$: MOV @RKDA,R2 ;GET THIS RANDOM SEED
4206 016720 010237 025756 MOV R2,RS0TH
4207 016724 010237 025754 MOV R2,RS0TL
4208 016730 005137 025754 COM RS0TL ;GET LO RANDOM SEED
4209
4210 016734 022703 177400 CMP #-400,R3 ;IF THE BUFFER IS MORE THAN
4211 016740 003003 BGT 2$ ;ONE SECTOR (400 WORDS) LONG.
4212 016742 010305 MOV R3,R5 ;GENERATE THE BUFFER IN SUCH
4213 016744 005003 CLR R3 ;A WAY THAT EACH SECTOR
4214 016746 000404 BR 3$ ;BEGINS WITH RANDOM DATA
4215
4216 016750 062703 000400 2$: ADD #400,R3 ;WORDS GENERATED USING THAT
4217 016754 012705 177400 MOV #-400,R5 ;SECTOR ADDRESS AS THE RANDOM
;SEED
4218
4219 016760 010524 3$: MOV R5,(R4)+ ;FIRST WORD OF EVERY SECTOR IS
;A WORD COUNT (2'S COMP) INDICATING #
;OF WORDS ACTUALLY WRITTEN IN THAT SECTOR
;ALL DONE?
4220
4221
4222 016762 005205 INC R5
4223 016764 001427 BEQ 8$
4224
4225 016766 004737 025576 4$: JSR PC,$RAND ;GENERATE DATA WORDS
4226 016772 025754 RS0TL
4227 016774 012737 000002 017104 MOV #2,RCNT
4228 017002 013737 025756 017106 MOV RS0TH,RNUM
4229 017010 000406 BR 6$
4230 017012 005337 017104 5$: DEC RCNT
4231 017016 001763 BEQ 4$
4232 017020 013737 025754 017106 MOV RS0TL,RNUM
4233 017026 005737 017106 6$: TST RNUM
4234 017032 001767 BEQ 5$
4235 017034 013724 017106 MOV RNUM,(R4)+ ;FILL THE BUFFER. DON'T USE
4236 017040 005205 INC R5 ;ALL DONE?
4237 017042 001351 BNE 4$ ;NO
4238
4239 017044 005703 8$: TST R3 ;ANY MORE DATA WORDS (FOR
4240 017046 001412 BEQ 10$ ;REST OF THE SECTORS)?
4241 ;YES
4242 017050 010246 MOV R2,-(SP)
4243 017052 042716 177760 BIC #177760,(SP) ;(ABSOLUTE DISK ADDRESS & ITS

```


4244	017056	022726	000013		CMP	#13,(SP)+	:COMPLEMENT) TO USE FOR
4245	017062	001002			BNE	9\$:GENERATING DATA WORDS
4246	017064	062702	000004		ADD	#4,R2	:OF THE NEXT BLOCK
4247							
4248	017070	005202		9\$:	INC	R2	:HI RANDOM SEED
4249	017072	000712			BR	1\$	
4250							
4251	017074	104415		10\$:	RESREG		:RESTORE REGISTERS
4252	017076	062705	000004		ADD	#4,R5	:ADJUST RETURN ADDRESS
4253	017102	000205			RTS	R5	:RETURN
4254							
4255	017104	000000		RCNT:	0		
4256	017106	000000		RNUM:	0		

```

4257 ;DATCHK
4258 ;THIS ROUTINE IS ENTERED WHEN THE DATA THAT WAS READ FROM THE DISK IS TO
4259 ;BE CHECKED. AT THE TIME OF ENTRY R3 CONTAINS THE OFFSET OF POINTER TO
4260 ;THE ADDRESS OF THE PARAMETER LIST (RKCS,DA,WC,BA). DATA IS CHECKED IN
4261 ;BLOCKS OF 1 SECTOR (400 WORDS). EACH BLOCK IS GENERATED USING THE SECTOR
4262 ;ADDRESS (AND ITS COMPLEMENT) AS RANDOM SEEDS. WHEN A DATA MISCOMPARISON
4263 ;OCCURS THE BUS ADDRESS, EXPECTED AND RECEIVED DATA ARE REPORTED.
4264
4265 017110 104414 DATCHK: SAVREG ;SAVE R0-R5
4266 017112 016303 002032 MOV PCMD(R3),R3 ;GET ADDRESS OF THE PARAMETER
4267 ;TABLE
4268 017116 016304 000004 MOV 4(R3),R4 ;GET WORD COUNT (2'S COMP)
4269 017122 016305 000006 MOV 6(R3),R5 ;GET BUS ADDRESS
4270 017126 011301 MOV (R3),R1 ;GET DISK ADDRESS
4271
4272 017130 010146 MOV R1,-(SP)
4273 017132 004737 022170 JSR PC,CROTFL ;ROTATE BITS 15,14,13 TO
4274 ;0,1,2
4275 017136 012602 MOV (SP)+,R2 ;POP OFF DRIVE # FROM THE STACK
4276 017140 006302 ASL R2
4277 017142 062702 001712 ADD #DATER,R2 ;FORM THE ADDRESS OF DATA ERROR COUNT
4278 ;FOR THIS DRIVE
4279 017146 012737 177764 001540 MOV #-14,ECOUNT
4280 017154 011337 025756 MOV (R3),RSDTH ;CREATE RANDOM SEEDS TO
4281 017160 013737 025756 025754 MOV RSDTH,RSDTL ;BE USED FOR CHECKING DATA
4282 017166 005137 025754 COM RSDTL
4283
4284 017172 022704 177400 1$: CMP #-400,R4 ;DATA IS CHECKED IN 1 SECTOR
4285 017176 003003 BGT 2$ ;BLOCKS. EACH SECTOR IS GENERATED
4286 017200 010403 MOV R4,R3 ;USING THAT SECTOR ADDRESS
4287 017202 005004 CLR R4 ;AS THE RANDOM SEED
4288 017204 000404 BR 3$
4289
4290 017206 062704 000400 2$: ADD #400,R4
4291 017212 012703 177400 MOV #-400,R3
4292 017216 012500 3$: MOV (R5)+,R0 ;SAVE THE FIRST WORD OF THE SECTOR.
4293 ;FIRST WORD OF EVERY SECTOR IS A COUNT
4294 ;(2'S COMP) INDICATING # OF WORDS ACTLALY
4295 ;WRITTEN IN THAT SECTOR
4296 017220 005200 INC R0 ;INCREMENT COUNT OF # OF WORDS (WRITEN)
4297 ;IN THE SECTOR
4298 017222 005203 INC R3 ;INCRMENT COUNT OF DATA WORDS TO BE CHECKED
4299 017224 001465 BEQ 14$ ;BRANCH, IF DONE
4300
4301 017226 004737 025576 4$: JSR PC,$RAND ;GENERATE RANDOM DATA WORD
4302 017232 025754 RSDTL
4303 017234 012737 000002 017104 MOV #2,RCNT
4304 017242 013737 025756 017106 MOV RSDTH,RNUM
4305 017250 000406 BR 10$
4306 017252 005337 017104 9$: DEC RCNT
4307 017256 001763 BEQ 4$
4308 017260 013737 025754 017106 MOV RSDTL,RNUM
4309 017266 005737 017106 10$: TST RNUM
4310 017272 001767 BEQ 9$
4311
4312 017274 005700 TST R0
    
```

4313	017276	001401				BEQ	5\$	
4314	017300	005200				INC	R0	
4315								
4316	017302	023715	017106		5\$:	CMP	RNUM,(R5)	:EXPCTD WORD = RECVD WORD?
4317	017306	001431				BEQ	8\$:YES
4318								
4319	017310	005700				TST	R0	
4320	017312	001005				BNE	6\$	
4321	017314	005715				TST	(R5)	
4322	017316	001425				BEQ	8\$	
4323	017320	005037	001164			CLR	\$REG1	
4324	017324	000403				BR	7\$	
4325								
4326	017326	013737	017106	001164	6\$:	MOV	RNUM,\$REG1	:SAVE EXPCTD DATA WORD
4327	017334	005212			7\$:	INC	(R2)	:INCRMNT DATA EROR COUNT FOR THIS DRIVE
4328	017336	005737	001540			TST	ECOUNT	:STORE ONLY 12 (DEC) DATA ERRORS
4329	017342	001413				BEQ	8\$:IF MORE EXIT
4330	017344	010537	001162			MOV	R5,\$REG0	:SAVE ERROR BUS ADDRESS
4331	017350	011537	001166			MOV	(R5),\$REG2	:SAVE ERROR DATA WORD
4332	017354	010137	001170			MOV	R1,\$REG3	
4333	017360	004737	022226			JSR	PC,GTSDRV	:SAVE DRIVE #, FOR TYPING SERIAL #
4334	017364	104023				ERROR	23	:DATA (COMPARISON) ERROR ON DOING
4335								:READ FROM DISK NORMALLY ONLY 12 DATA
4336								:ERRORS WILL BE REPORTED. THROUGH
4337								:CHECKING WILL BE DONE, ERRORS
4338								:EXCEEDING 12 WON'T BE REPORTED. IF
4339								:YOU WANT MORE, CHANGE 'ECOUNT' TO
4340								:WHATEVER # OF ERRORS YOU WANT REPORTED
4341	017366	005237	001540			INC	ECOUNT	
4342								
4343	017372	005725			8\$:	TST	(R5)+	
4344	017374	005203				INC	R3	:DONE CHECKING?
4345	017376	001313				BNE	4\$	
4346								
4347	017400	005704			14\$:	TST	R4	:ANY MORE SECTOR BLOCKS
4348	017402	001427				BEQ	17\$:TO CHECK? IF NOT, EXIT
4349								
4350	017404	010146				MOV	R1,-(SP)	
4351								:GET THE NEW RANDOM SEEDS
4352	017406	042716	177760			BIC	#177760,(SP)	: (ABSOLUTE DISK ADDRESS & ITS COMPLEMENT
4353	017412	022726	000013			CMP	#13,(SP)+	:TO USE FOR GENERATING DATA WORDS
4354	017416	001002				BNE	15\$:OF THE NEXT BLOCK
4355	017420	062701	000004			ADD	#4,R1	
4356								
4357	017424	005201			15\$:	INC	R1	
4358	017426	032777	000002	161564		BIT	#CSE,ARKER	:IF THERE WAS A CSE THEN CHECK
4359	017434	001403				BEQ	16\$:ONLY THOSE SECTORS THAT WERE REAC
4360	017436	020177	161566			CMP	R1,ARKDA	
4361	017442	001407				BEQ	17\$	
4362	017444	010137	025756		16\$:	MOV	R1,RSDTH	
4363	017450	010137	025754			MOV	R1,RSDTL	
4364	017454	005137	025754			COM	RSDTL	
4365	017460	000644				BR	1\$	
4366	017462	104415			17\$:	RESREG		:RESTORE R0-R5
4367	017464	000207				RTS	PC	

```

4368
4369
4370
4371
4372
4373
4374
4375
4376
4377
4378
4379
4380
4381
4382
4383
4384 017466 010046
4385 017470 010146
4386 017472 010246
4387 017474 010346
4388 017476 013746 000004
4389 017502 013746 000006
4390 017506 010600
4391
4392 017510 104400
4393 017512 012637 000006
4394 017516 012701 003776
4395 017522 105727
4396 017524 000200
4397 017526 100062
4398 017530 012737 017666 000004
4399 017536 005737 177572
4400 017542 052737 100000 017524
4401 017550 005046
4402 017552 012702 172340
4403 017556 012703 000010
4404 017562 012762 077406 177740 1$:
4405 017570 011622
4406 017572 062716 000200
4407 017576 077307
4408 017600 012742 177600
4409 017604 005042
4410 017606 012737 017624 000004
4411 017614 012737 000020 172516
4412 017622 000401
4413 017624 022626 2$:
4414 017626 005237 177572 3$:
4415 017632 012737 017656 000004
4416 017640 005737 143776 4$:
4417 017644 062712 000040
4418 017650 023712 172356
4419 017654 101371
4420 017656 011202 SKTOUT:
4421 017660 005037 177572
4422 017664 000421
4423 017666 042737 100000 017524 SKTNEX:

```

.SBTTL ROUTINE TO SIZE MEMORY

```

*****
*CALL:
*   JSR   PC,$SIZE
*   RETURN
*SLSTAD WILL CONTAIN:
*   WITH KT11 OPTION      -- LAST VIRTUAL ADDRESS OF THE LAST BANK
*   WITHOUT KT11 OPTION  -- LAST ABSOLUTE ADDRESS OF AVAILABLE MEMOR
*SLST3K WILL CONTAIN THE LAST BANK AS A SAF
*SKT11 IS THE MEMORY MANAGEMENT KEY
*BIT07 = 0 DON'T USE MEMORY MANAGEMENT
*      MUST BE SETUP BEFORE THE CALL
*BIT15 = 0 DON'T HAVE MEMORY MANAGEMENT OPTION
*      DETERMINED BY ROUTINE

$SIZE:  MOV   R0,-(SP)      ;;SAVE R0 ON THE STACK
        MOV   R1,-(SP)      ;;SAVE R1 ON THE STACK
        MOV   R2,-(SP)      ;;SAVE R2 ON THE STACK
        MOV   R3,-(SP)      ;;SAVE R3 ON THE STACK
        MOV   @#ERRVEC,-(SP) ;;SAVE PRESENT ERROR VECTOR PS & PC
        MOV   @#ERRVEC+2,-(SP)
        MOV   SP,R0        ;;SAVE THE STACK POINTER
;;SET THE ERRVEC PS TO THE PRESENT PS
        TRAP
        MOV   (SP)+,@#ERRVEC+2 ;;PUSH OLD PSW AND PC ON STACK
        MOV   @3776,R1      ;;SAVE THE PSW IN @#ERRVEC+2
        MOV   (PC)+        ;;SETUP ADDRESS
        TSTB .WORD        ;;USE MEMORY MANAGEMENT?
        BPL   $SCORE       ;;SET TO USE MEMORY MANAGEMENT
        MOV   @SKTNEX,@#ERRVEC ;;BR IF NO
        TST   @#SRO        ;;SET FOR TIMEOUT
        BIS   @100000,$KT11 ;;KT11 ARE YOU THERE?
        CLR   -(SP)        ;;YES--SET KT11 KEY
        MOV   @KIPAR0,R2   ;;INITIALIZE FOR "PAR" LOADING
        MOV   @108,R3      ;;ADDRESS OF FIRST "PAR"
        MOV   @77406,-40(R2) ;;LOAD EIGHT "PAR.'S" AND EIGHT "PDF.'S"
        ADD   @200,(SP)    ;;PDR = 4K, LP, READ/WRITE
        SOB   R3,1$       ;;LOAD "PAR"
        MOV   @177600,-(R2) ;;UPDATE FOR NEXT "PAR"
        CLR   -(R2)        ;;LOOP UNTIL ALL EIGHT ARE LOADED
        MOV   @25,@#ERRVEC ;;SETUP KIPAR7 FOR I/O
        MOV   @20,@#SR3    ;;SETUP KIPAR6 FOR TESTING
        BR    3$          ;;CATCH TIMEOUT IF NO SR3
        CMP   (SP)+,(SP)+  ;;ENABLE 22 BIT MODE
        INC   @#SRO        ;;THIS POP-11 HAS A SR3 REGISTER
        MOV   @SKTOUT,@#ERRVEC ;;CLEAN OFF THE STACK--NO SR3
        TST   @143776     ;;TURN ON MEMORY MANAGEMENT
        ADD   @40,(R2)    ;;SET FOR TIME OUT
        CMP   @#KIPAR7 (R2) ;;TRAP ON NON-EX-MEM
        BHI   4$          ;;MAKE A 1K STEP
        MOV   (R2),R2     ;;LAST ONE?
        CLR   @#SRO       ;;NO--TRY IT
        BR    $SIZEX     ;;GET LAST BANK+1
        BIC   @100000,$KT11 ;;TURN OFF MEMORY MANAGEMENT
        ;;KT11 NON-EXISTENT

```

```

4424 017674 012737 017724 000004 SCORE: MOV #SCROUT,2#ERRVEC ;; SET FOR TIMEOUT
4425 017702 005002 CLR R2 ;; SET UP BANK
4426 017709 062701 004000 15: ADD #4000,R1 ;; INCREMENT BY 1K
4427 017710 062702 000040 ADD #40,R2 ;; 1K STEP
4428 017714 005711 TST (R1) ;; TRAP ON TIME OUT
4429 017716 022701 177776 CMP #177776,R1 ;; LAST ONE
4430 017722 001370 BNE 15 ;; NO--TRY AGAIN
4431 017724 162701 004000 SCROUT: SUB #4000,R1
4432 017730 162702 000040 $SIZE: SUB #40,R2 ;; DROP BACK
4433 017734 010006 MOV RO,SP ;; RESTORE THE STACK
4434 017736 012637 000006 MOV (SP)+,2#ERRVEC+2 ;; RESTORE ERROR VECTOR
4435 017742 012637 000004 MOV (SP)+,2#ERRVEC
4436 017746 010137 017770 MOV R1,$LSTAD ;; LAST ADDRESS
4437 017752 010237 017772 MOV R2,$LSTBK ;; LAST BANK
4438 017756 012603 MOV (SP)+,R3 ;; RESTORE R3
4439 017760 012602 MOV (SP)+,R2 ;; RESTORE R2
4440 017762 012601 MOV (SP)+,R1 ;; RESTORE R1
4441 017764 012600 MOV (SP)+,R0 ;; RESTORE R0
4442 017766 000207 RTS PC
4443 017770 000000 $LSTAD: .WORD 0 ;; CONTAINS THE LAST ADDRESS
4444 017772 000000 $LSTBK: .WORD 0 ;; CONTAINS THE LAST BANK

```

```

4445 ;TYPDBO
4446 ;THIS ROUTINE CONVERTS A VIRTUAL ADDRESS TO PHYSICAL ADDRESS AND TYPES
4447 ;OUT THE 6 DIGIT PHYSICAL ADDRESS. R2 CONTAINS VIRTUAL ADDRESS AT THE TIME
4448 ;OF ENTRY.
4449 ;TYPE OUT IS INHIBITED IF SW 13 IS SET.
4450
4451 017774 032777 020000 161136 TYPDBO: BIT #SW13,2SWR ;INHIBIT TYPEOUT?
4452 020002 001042 BNE 25 ;YES
4453 020004 010346 MOV R3,-(SP)
4454 020006 010446 MOV R4,-(SP)
4455 020010 010546 MOV R5,-(SP)
4456
4457 020012 010246 MOV R2,-(SP) ;PUSH VA ON STACK
4458 020014 004737 022170 JSR PC,CROTFL ;ROTATE BITS 15,14,13 INTO 2,1,0
4459 020020 012603 MOV (SP)+,R3 ;FORM OFFSET TO BE USED
4460 020022 006303 ASL R3 ;FOR KIPAR
4461
4462 020024 016304 172340 MOV KIPAR(R3),R4 ;GET THE BASE PAGE ADDRESS FROM
4463 ;KIPAR
4464 020030 005003 CLR R3 ;ROTATE LEFT 6 TIMES (MULTIPLY
4465 020032 017705 177772 MOV #-6,R5 ;BY 100 OCTAL) TO GET THE
4466 020036 006774 1S: ROL R4 ;BASE BUS ADDRESS (PHYSICAL)
4467 020040 005205 INC R5 ;R3 CONTAINS MSB-2 BITS
4468 020042 001375 BNE 1S
4469
4470
4471 020044 010246 MOV R2,-(SP) ;STRIP OFF TOP 3 BITS FROM VA &
4472
4473 020046 042716 160000 BIC #160000,(SP) ;GET THE OFFSET INSIDE THE PAGE
4474 020052 062604 ADD (SP)+,R4 ;FORM THE ENTIRE PHYSICAL
4475 020054 005503 ADC R3 ;ADDRESS. R4 CONTAINS LOWER 16 BITS
4476 ;R3 CONTAINS TOP 2 BITS
4477 020056 010437 001162 MOV R4,$REG0 ;SAVE LOWER 16 BITS OF PA
4478 020062 010337 001164 MOV R3,$REG1 ;SAVE TOP 2 BITS OF PA
4479 020066 012746 001162 MOV #SREG0,-(SP) ;PUSH POINTER TO PA ON STACK
4480 020072 004737 024464 JSR PC,2#SDB20 ;CONVERT THE 18 BIT BINARY
4481 ;ADDRESS TO OCTAL ASCII NUMBERS ON RETURN
4482 ;POINTER TO THE FIRST ASCII CHARACTERS
4483 ;IS ON STACK
4484 020076 004737 025014 JSR PC,2#SUPRS ;TYPE OUT THE OCTAL 6 DIGIT
4485 ;PHYSICAL ADDRESS.
4486
4487 020102 012605 MOV (SP)+,R5
4488 020104 012604 MOV (SP)+,R4
4489 020106 012603 MOV (SP)+,R3
4490
4491 020110 000207 2S: RTS PC
    
```

```

4492      ;CHKCS
4493      ;THIS ROUTINE CHECKS IF BIT 15 OF RKCS WAS SET. IF IT WAS RETURN IS MADE TO
4494      ;THE ERROR MESSAGE FOLLOWING THE JSR CALL. IF NOT, THE ERROR MADE TO SKIP
4495      ;OVER THE ERROR MESSAGE.
4496
4497      020112 005777 161104      CHKCS:  TST      @RKCS      ;BIT 15 SET?
4498      020116 100073              BPL      COMRET      ;NO
4499      020120 004737 022032      JSR      PC,GT4RG    ;YES, GET RKCS, ER, DS, DA
4500      020124 000207              RTS      PC          ;RETURN TO THE ERROR MESSAGE
4501
4502      ;CHKDA
4503      ;THIS ROUTINE CHECKS IF RKDA INCREMENTED CORRECTLY. IF NOT, RETURN IS MADE
4504      ;TO THE ERROR MESSAGE FOLLOWING THE JSR CALL. IF YES, RETURN IS MADE TO
4505      ;SKIP OVER THE ERROR MESSAGE.
4506      ;AT THE TIME OF ENTRY, R2 CONTAINS THE EXPECTED RKDA.
4507
4508      020126 020277 161076      CHKDA:  CMP      R2,@RKDA  ;DID RKDA INCREMENT CORRECTLY?
4509      020132 001465              BEQ      COMRET      ;YES
4510      020134 010237 001162      MOV      R2,$REG0    ;GET EXPCTD RKDA
4511      020140 017737 161064 001164  MOV      @RKDA,$REG1 ;GET RKDA RECVD
4512      020146 000207              RTS      PC          ;RETURN TO THE ERROR MESSAGE
4513
4514      ;CHKBA
4515      ;THIS ROUTINE CHECKS IF RKBA INCREMENTED CORRECTLY. IF NOT, RETURN IS MADE
4516      ;TO THE ERROR MESSAGE FOLLOWING THE JSR CALL. IF YES, RETURN IS MADE TO
4517      ;SKIP OVER THE ERROR MESSAGE.
4518      ;AT THE TIME OF ENTRY, R3 CONTAINS THE WORD COUNT (# OF WORDS TRANSFERRED),
4519      ;R4 CONTAINS THE BUS ADDRESS WHERE THE TRANSFER STARTED.
4520
4521      020150 000241              CHKBA:  CLC
4522      020152 006103              ROL      R3          ;FORM THE EXPCTD BUS ADDRESS
4523      020154 060304              ADD      R3,R4
4524      020156 000241              CLC
4525      020160 006003              ROR      R3
4526      020162 020477 161040      CMP      R4,@RKBA    ;DID RKBA INCREMENT CORRECTLY?
4527      020166 001447              BEQ      COMRET      ;YES
4528      020170 010437 001162      MOV      R4,$REG0    ;GET EXPCTD RKBA
4529      020174 000207              RTS      PC          ;RETURN TO THE EROR MESSAGE
4530
4531      020176 017737 161024 001164  MOV      @RKBA,$REG1 ;GET RKBA RECVD
4532
4533      ;CHKMEX
4534      ;THIS ROUTINE CHECKS THAT RKBA OVERFLOWED AND MEX BIT WAS SET IN RKCS (BIT 4).
4535      ;IF RKBA OVERFLOWED CORRECTLY, THE RETURN ADDRESS IS ADJUSTED TO SKIP THE
4536      ;ERROR MESSAGE ON RETURN.
4537
4537      020204 017746 161012      CHKMEX: MOV      @RKCS,-(SP) ;GET RKCS
4538      020210 042716 177717      BIC      #177717,(SP) ;GET MEX BITS 4,5
4539      020214 022726 000020      CMP      #BIT4,(SP)+ ;CHECK BIT 4 SET?
4540      020220 001432              BEQ      COMRET      ;YES, OK
4541      020222 004737 022032      JSR      PC,GT4RG    ;SAVE RKCS, ER, DS, DA
4542      020226 000207              RTS      PC          ;RETURN

```

```

4543 ;CHKWC
4544 ;THIS ROUTINE CHECKS IF RKWC OVERFLOWED CORRECTLY AFTER A DATA TRANSFER
4545 ;IF IT DID NOT, RETURN IS MADE TO THE ERROR MESSAGE. IF IT DID, RETURN IS
4546 ;MADE TO SKIP OVER THE ERROR MESSAGE.
4547
4548 020230 005777 160770      CHKWC:  TST      @RKWC      ;RKWC OVERFLOWED?
4549 020234 001424              BEQ      COMRET      ;YES
4550 020236 017737 160766 001162  MOV      @RKDA,$REG0
4551 020244 017737 160754 001164  MOV      @RKWC,$REG1
4552 020252 000207              RTS      PC          ;RETURN TO THE EROR MESSAGE
4553
4554
4555
4556 ;CHKRWS
4557 ;THIS ROUTINE CHECKS IF R/W/S RDY BIT IN RKDS IS SET. IF IT IS NOT SET RETURN
4558 ;IS MADE TO THE ERROR MESSAGE FOLLOWING THE JSR CALL. IF IT IS, THE RETURN
4559 ;ADDRESS IS ADJUSTED TO SKIP OVER THE ERROR MESSAGE ON RRETURN.
4560
4561 020254 032777 000100 160734  CHKRWS: BIT      @RWS,@RKDS ;RWS RDY SET?
4562 020262 001011              BNE      COMRET      ;YES
4563 020264 004737 022032      JSR      PC,GT4RG    ;GET RKCS, ER, DS, DA
4564 020270 000207              RTS      PC          ;RETURN TO THE ERROR MESSAGE
4565
4566
4567 ;CHKCRDY
4568 ;THIS ROUTINE CHECKS IF CONTROL READY BIT IN RKCS IS SET. IF IT IS NOT,
4569 ;RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE JSR CALL. IF IT IS,
4570 ;RETURN ADDRESS IS ADJUSTED TO SKIP OVER THE ERROR MESSAGE.
4571
4572 020272 105777 160724      CHKCRDY: TSTB     @RKCS      ;CONTROL READY SET?
4573 020276 100403              BMI      COMRET      ;YES
4574 020300 004737 022032      JSR      PC,GT4RG    ;GET RKCS, ER, DS, DA
4575 020304 000207              RTS      PC          ;RETURN TO THE EROR MESSAGE
4576
4577 020306 062716 000002      COMRET: ADD      #2,(SP) ;ADJUST RETURN ADDRESS TO SKIP OVER MESSAGE
4578 020312 000207              RTS      PC

```


4579
4580
4581
4582
4583
4584
4585
4586
4587
4588
4589
4590
4591
4592
4593
4594
4595
4596
4597
4598
4599
4600
4601
4602
4603
4604
4605
4606
4607
4608
4609
4610
4611
4612
4613
4614
4615
4616
4617
4618
4619
4620
4621
4622
4623
4624
4625
4626
4627

; THIS ROUTINE KEEPS A HISTORY OF THE COMMANDS THAT ARE BEING EXECUTED
; ON THE RK11. 'PRSFNC' CONTAINS INFORMATION ABOUT THE PRESENT COMMAND
; WHICH IS ABOUT TO BE INITIATED. 'PSTFNC' CONTAINS INFORMATION ABOUT THE
; COMMAND THAT WAS EXECUTED BEFORE THIS NEW ONE. THERE ARE MULTIPLE POINTS
; OF ENTRY DEPENDING ON THE TYPE OF COMMAND BEING PRESENTLY INITIATED:

; DRCMND - ENTERED WHEN A DRIVE RESET IS BEING INITIATED. DRIVE # IS SAVED
; IN BITS 0-2 OF 'PRSCMND' AND BIT 8 IS SET.

; CRCMND - ENTERED WHEN A CONTROL RESET IS BEING INITIATED. BIT 14 OF
; 'PRSCMND' IS SET.

; POSCMND - ENTERED WHEN A POSITIONING SEEK IS BEING INITIATED. BITS 0-2
; CONTAIN THE DRIVE NUMBER ON WHICH THE POSITIONING SEEK WAS DONE. ALSO
; BIT 7 IS SET.

; IN ALL ABOVE CASES BIT 15 OF 'PRSCMND' IS SET.

; FNCMND - ENTERED WHEN A COMMAND OTHER THAN ANY ONE OF THE ABOVE IS BEING
; INITIATED (EX: READ, WRITE, ETC).
; THE OFFSET TO THE COMMAND KEY (BASE=KEY) IS SAVED IN BITS 0-3 OF 'PRSCMND'.

; IT SHOULD BE NOTED THAT CONTENTS OF 'PRSFNC' ARE PUSHED INTO 'PSTFNC'
; AND SAVED, BEFORE PUTTING INFO ABOUT THE PRESENT COMMAND IN 'PRSFNC'.

; RO CONTAINS ADDRESS OF THE COMMAND KEY, AT THE TIME OF ENTRY.

```
020314 012737 100400 001512 DRCMND: MOV #BIT15+BIT8,QFNC
020322 017746 160702 MOV DRKDA,-(SP) ;SAVE DRIVE #
020326 004737 022170 JSR PC,CROTFL
020332 052637 001512 BIS (SP)+,QFNC
020336 000424 BR P2

020340 012737 140000 001512 CRCMND: MOV #BIT15+BIT14,QFNC
020346 000420 BR P2

020350 011037 001512 POSCMND: MOV (RO),QFNC
020354 042737 177770 001512 BIC #177770,QFNC ;GET DRIVE NO.
020362 052737 100200 001512 BIS #BIT15+BIT7,QFNC
020370 000407 BR P2

020372 005037 001512 FNCMND: CLR QFNC
020376 010046 P1: MOV RO,-(SP)
020400 162716 001306 SUB #KEY,(SP)
020404 052637 001512 BIS (SP)+,QFNC

020410 013737 001462 001464 P2: MOV PRSFNC,PSTFNC
020416 013737 001512 001462 MOV QFNC,PRSFNC
020424 000207 RTS PC
```

```

4628      ;HISTRY
4629      ;THIS ROUTINE TYPES OUT INFORMATION ABOUT THE FUNCTION THAT WAS
4630      ;BEING PERFORMED ON THE RK AT THE TIME OF ERROR AND THE FUNCTION
4631      ;THAT WAS PERFORMED JUST BEFORE THAT FUNCTION (WHICH LED TO
4632      ;THE ERROR). THIS ROUTINE IS CALLED WHEN AN ERROR OCCURS AND SW 12
4633      ;IS SET.
4634
4635      020426 010046      HISTRY: MOV      RO,-(SP)
4636      020430 010146      MOV      R1,-(SP)
4637
4638      020432 012700 001462      MOV      #PRSFNC,R0
4639      020436 104401 020746      TYPE    ,MH1
4640      020442 104401 020772      TYPE    ,MH3
4641      020446 104401 020762      TYPE    ,MH2
4642      020452 005710      65:    TST     (R0)
4643      020454 100053      BPL     3$      ;READ, READ CHECK, WRITE, WRITE CHECK, SEEK
4644      020456 105710      TSTB   (R0)
4645      020460 100427      BMI     2$      ;POSITIONING (SEEK)
4646      020462 032710 040000      BIT     #BIT14,(R0)
4647      020466 001014      BNE     1$      ;CONTROL RESET
4648
4649      020470 104401 020476      TYPE    65$      ;;TYPE ASCIZ STRING
4650      020474 000410      BR      64$      ;;GET OVER THE ASCIZ
4651      ;;65$: .ASCIZ /DRESET ON DRV /
4652      020516      64$:    BR      7$
4653      020516 000425
4654
4655      020520      1$:    TYPE    67$      ;;TYPE ASCIZ STRING
4656      020520 104401 020526      BR      66$      ;;GET OVER THE ASCIZ
4657      020524 000404      ;;67$: .ASCIZ /CRESET/
4658
4659      020536      66$:    BR      4$
4660      020536 000463
4661
4662      020540      2$:    TYPE    69$      ;;TYPE ASCIZ STRING
4663      020540 104401 020546      BR      68$      ;;GET OVER THE ASCIZ
4664      020544 000412      ;;69$: .ASCIZ /POSITIONING DRIVE /
4665
4666      020572      68$:    MOV     (R0),-(SP)
4667      020572 011046      7$:    BIC     #177770,(SP) ;TYPE DRIVE NO.
4668      020574 042716 177770      TYPOC
4669      020600 104402      BR      4$
4670      020602 000441
4671
4672      020604 011001      3$:    MOV     (R0),R1
4673      020606 016101 002032      MOV     PCMD(R1),R1 ;GO TYPE OUT THE FUNCTION
4674      020612 016104 000002      MOV     2(R1),R4 ;BEING PERFORMED
4675      020616 004737 021736      JSR     PC,TYPEFN
4676      020622 104401 020630      TYPE    71$      ;;TYPE ASCIZ STRING
4677      020626 000403      BR      70$      ;;GET OVER THE ASCIZ
4678      ;;71$: .ASCIZ <15><12>/DA=/
4679      020636      70$:    MOV     (R1),-(SP) ;TYPE OUT DISK ADDRESS
4680      020636 011146
4681      020640 104402
4682      020642 104401 020650      TYPOC
4683      020646 000403      TYPE    73$      ;;TYPE ASCIZ STRING
      BR      72$      ;;GET OVER THE ASCIZ
    
```

4684						73S:	.ASCIZ	/ BA=	
4685	020656					72S:	MOV	6(R1),-(SP)	
4686	020656	016146	000006				TYPOC		
4687	020662	104402					TYPE	75S	::TYPE ASCIZ STRING
4688	020664	104401	020672				BR	74S	::GET OVER THE ASCIZ
4689	020670	000403							
4690						75S:	.ASCIZ	/ WC=	
4691	020700					74S:	MOV	4(R1),-(SP)	
4692	020700	016146	000004				TYPOC		
4693	020704	104402							
4694									
4695	020706	020027	001464			4S:	CMP	RO,#PSTFNC	
4696	020712	001410					BEQ	5S	
4697	020714	005720					TST	(RO)+	
4698	020716	104401	020746				TYPE	,MH1	
4699	020722	104401	020775				TYPE	,MH4	
4700	020726	104401	020752				TYPE	,MH2	
4701	020732	000647					BR	6S	
4702	020734	104401	001213			5S:	TYPE	\$CRLF	
4703	020740	012601					MOV	(SP)+,R1	
4704	020742	012600					MOV	(SP)+,RO	
4705	020744	000207					RTS	PC	
4706	020746	005015	052506	041516	MH1:		.ASCIZ	<15><12>/FUNCTION /	
4707	020754	044524	047117	000040					
4708	020762	042440	051122	051117	MH2:		.ASCIZ	/ ERROR /	
4709	020770	000040							
4710	020772	052101	000		MH3:		.ASCIZ	/AT/	
4711	020775	120	044522	051117	MH4:		.ASCIZ	/PRIOR TO/	
4712	021002	052040	000117						
4713							.EVEN		

009

```

4714 ;STATSTC
4715 ;AT THE TIME OF ENTRY R1 CONTAINS THE DRIVE NUMBER FOR WHICH THE STATISTIC
4716 ;IS TO BE OBTAINED. R5 CONTAINS THE POINTER TO THE PARAMETER TABLE, FOR
4717 ;THE COMMAND EXECUTED ON THE ABOVE DRIVE. R4 CONTAINS THE FUNCTION CODE
4718 ; (WRITE, READ, ETC) FOR WHICH STATISTICS ARE TO BE TAKEN.
4719
4720 021006 010046 STATSTC:MOV R0,-(SP) ;PUSH R0, R2, R3 ONTO THE
4721 021010 010246 MOV R2,-(SP) ;STACK
4722 021012 010346 MOV R3,-(SP)
4723
4724 021014 005002 CLR R2
4725 021016 005701 TST R1 ;DRIVE 0?
4726 021020 001404 BEQ 2$ ;FORM THE OFFSET FOR THE
4727 021022 062702 000004 1$: ADD #4,R2 ;'WORDS XFERRD COUNTS'-
4728 021026 005301 DEC R1 ;NWRTL, NRDL
4729 021030 001374 BNE 1$
4730 021032 016506 000004 2$: MOV 4(R5),R0 ;GET WORD COUNT (RKWC) FROM
4731 021036 005400 NEG R0 ;THE PARAMETER TABLE
4732
4733 021040 005777 160156 TST 2RKCS ;ANY ERROR DURING THE XFER?
4734 021044 100004 BPL 3$
4735
4736 021046 017703 160152 MOV 2RKWC,R3 ;YES,
4737 021052 005403 NEG R3 ;GET THE # OF WORDS THAT
4738 021054 160300 SUB R3,R0 ;WERE ACTUALLY X-FERRED
4739
4740 021056 022704 000002 3$: CMP #2,R4 ;WRITE FUNCTION?
4741 021062 001005 BNE 5$
4742
4743 021064 060062 001732 4$: ADD R0,NWRTL(R2) ;YES, ADD THE # OF WORDS
4744 021070 005562 001734 ADC NRWTH(R2) ;XFERRD (WRITE)
4745 021074 000404 BR 6$ ;NOTE IT'S 2-WORD COUNT LO. HI
4746
4747 021076 060062 001772 5$: ADD R0,NRDL(R2) ;ADD THE # OF WORDS READ
4748 ;NOTE THAT WRT CHK,
4749 ;READ CHK ARE ALSO CONS-
4750 ;IDERED TO BE 'READ'
4751 021102 005562 001774 ADC NRDH(R2) ;CARRY OVER TO THE HI WORD
4752
4753 021106 012603 6$: MOV (SP)+,R3 ;POP R3,R2,R0 FROM THE STACK
4754 021110 012602 MOV (SP)+,R2
4755 021112 012600 MOV (SP)+,R0
4756 021114 000207 RTS PC

```

E09

```

4757      :REPSTAT
4758      ;THIS ROUTINE REPORTS ERROR STATISTICS AND DATA-TRANSFER STATISTICS.
4759
4760 021116 104401 002377 REPSTA: TYPE MSG26
4761 021122 013700 001264      MOV DRVPRS,R0
4762 021126 012701 001254      MOV #PDR,R1
4763
4764 021132 104401 001213 1$: TYPE $CRLF
4765 021136 112102      MOVB (R1)+,R2
4766 021140 042702 177770      BIC #177770,R2
4767 021144 010246      MOV R2,-(SP)
4768 021146 104403      TYPDS
4769 021150      .BYTE 3
4770 021151      .BYTE 0
4771 021152 104401 002662      TYPE ,BLNKS3
4772
4773 021156 005004      CLR R4
4774 021160 010203      MOV R2,R3
4775 021162 001404      BEQ 3$
4776 021164 062704 000004 2$: ADD #4,R4
4777 021170 005303      DEC R3
4778 021172 001374      BNE 2$
4779
4780 021174 104401 002664 3$: TYPE BLNKS1
4781 021200 010446      MOV R4,-(SP)
4782 021202 062716 001732      ADD #NARTL,(SP)
4783 021206 004737 024604      JSR PC,$DB2D
4784 021212 004737 025014      JSR PC,SUPRS
4785 021216 104401 002664      TYPE BLNKS1
4786 021222 010446      MOV R4,-(SP)
4787 021224 062716 001772      ADD #NRDL,(SP)
4788 021230 004737 024604      JSR PC,$DB2D
4789 021234 004737 025014      JSR PC,SUPRS
4790
4791 021240 006302      ASL R2
4792
4793 021242 104401 002664      TYPE BLNKS1
4794 021246 016246 001652      MOV CSECN(R2),-(SP)
4795 021252 104405      TYPDS
4796
4797 021254 104401 002664      TYPE BLNKS1
4798 021260 016246 001632      MOV WCECN(R2),-(SP)
4799 021264 104405      TYPDS
4800
4801 021266 104401 002664      TYPE BLNKS1
4802 021272 016246 001712      MOV DATER(R2),-(SP)
4803 021276 042716 100000      BIC #100000,(SP) ;DONT TYPE A NEGATIVE NO.
4804 021302 104405      TYPDS
4805
4806 021304 104401 002664      TYPE BLNKS1
4807 021310 016246 001562      MOV HECN(R2),-(SP)
4808 021314 104405      TYPDS
4809
4810 021316 005300      DEC R0 ;FINISHED WITH THE DRIVES ?
4811 021320 001304      BNE 1$ ;BR IF NOT
4812 021322 104401 002474      TYPE ,MSG26A ;REST OF SUMMARY MESSAGE

```

F03

4813	021326	013700	001264		MOV	DRVPRS,R0	:NUMBER OF DRIVES
4814	021332	012701	001254		MOV	#PDR,R1	: 'DRIVES PRESENT' TABLE ADDRESS
4815	021336	104401	001213	45:	TYPE	,\$CRLF	:CR-LF
4816	021342	112102			MOVB	(R1)+,R2	:DRIVE ADDRESS
4817	021344	042702	177770		BIC	#177770,R2	:LEAVE ONLY DRIVE NUMBER
4818	021350	010246			MOV	R2,-(SP)	:PUT ON STACK FOR TYPEOUT
4819	021352	104403			TYPOS		:TYPE IT IN OCTAL
4820	021354	003			.BYTE	3	:TYPE 3 CHARACTERS
4821	021355	000			.BYTE	0	:SUPPRESS LEADING ZEROS
4822	021356	104401	002662		TYPE	BLNKS3	:3 BLANKS
4823	021362	006302			ASL	R2	:CONVERT TO A WORD TABLE INDEX
4824	021364	104401	002664		TYPE	BLNKS1	
4825	021370	016246	001602		MOV	\$KECN(R2),-(SP)	
4826	021374	104405			TYPDS		
4827							
4828							
4829	021376	104401	002664		TYPE	BLNKS1	
4830	021402	016246	001672		MOV	ABORT(R2),-(SP)	
4831	021406	104405			TYPDS		
4832							
4833	021410	006202			ASR	R2	
4834	021412	104401	002664		TYPE	BLNKS1	
4835	021416	116246	001622		MOVB	\$INCN(R2),-(SP)	
4836	021422	104405			TYPDS		
4837							
4838	021424	005300			DEC	R0	
4839	021426	001343			BNE	45	
4840	021430	004737	026660		JSR	PC,TIMTYP	:TYPE THE TIME
4841	021434	000207			RTS	PC	

```

4842 :STATUS
4843 :THIS ROUTINE IS NORMALLY ENTERED WHEN THE PROGRAM IS WAITING FOR THE
4844 :CONTROLLER TO FINISH WHAT IT IS DOING. THERE ARE TWO DOUBLE PRECISION
4845 :COUNTS KEPT IN THIS ROUTINE.
4846 :CICNT,CICNT1
4847 :THIS COUNT KEEPS TRACK OF HOW LONG THE CONTROLLER HAS BEEN BUSY AFTER
4848 :A COMMAND WAS INITIATED. THE CONTROLLER SHOULD FINISH WHATEVER IT IS DOING
4849 :BEFORE THIS COUNT EXPIRES. IF IT DOES NOT, THERE IS AN ERROR CONDITION AND
4850 :IT IS SO REPORTED.
4851
4852 :QSCNT
4853 :THIS COUNT IS INITIALIZED EVERY TIME 8 COMMANDS ARE GENERATED. THE COUNT
4854 :IS INCREMENTED EVERY TIME THIS ROUTINE IS ENTERED. ALL THE 8 COMMANDS
4855 :SHOULD BE DONE BEFORE THIS COUNT EXPIRES. IF THEY DO NOT AN ERROR CONDITION
4856 :IS REPORTED. THIS COUNT HAS BEEN KEPT PRIMARILY TO INSURE THAT THE PROGRAM
4857 :DOES NOT GET CAUGHT IN AN INDEFINITE LOOP, BECAUSE OF AN ERROR CONDITION.
4858
4859 021436 005046 STATUS: CLR -(SP) ;DROP PRIORITY AND WAIT FOR INT
4860 021440 012746 021446 MOV #15,-(SP) ;RETURN FOR RTI
4861 021444 000002 RTI
4862
4863 ;NOTE THAT THE INTERRUPTS ARE ALLOWED ONLY
4864 ;AT CERTAIN PLACES IN THE PROGRAM, BECAUSE
4865 ;IT MAKES TROUBLESHOOTING OF FAILURES EASY.
4866 ;OTHER PLACES WHERE INTERRUPTS ARE ALLOWED
4867 ;TO TAKE PLACE:
4868 ;'CHFAFN', FIRST INTERRUPT AFTER ISSUING
4869 ;A SEEK FUNCTION.
4870 021446 005237 001460 15: INC QSCNT
4871 021452 001456 BEQ QEROR
4872 021454 105777 157542 TSTB DRKCS
4873 021460 100514 BMI CNOBSY
4874
4875 021462 005037 001466 CLR CICNT
4876 021466 012737 177761 001470 MOV #17,CICNT1
4877
4878 021474 105737 001534 CBSY: TSTB INTFLG ;FOR A NON-SEEK COMAND:
4879 ;INTFLG- BIT 7 IS SET, BITS 0-3 CONTAIN
4880 ;OFFSET TO THE COMMAND KEY (FROM KEY),
4881 ;FOR WHICH THIS INTERRUPT IS EXPCD.
4882 ;WHEN THE INTERRUPT OCCURS & 'INTHND' IS
4883 ;ENTERED 'INTFLG' IS CLEARED.
4884 021500 001507 BEQ SEXIT
4885 021502 005237 001466 INC CICNT
4886 021506 001372 BNE CBSY
4887 021510 005237 001470 INC CICNT1
4888 021514 001367 BNE CBSY
4889
4890 ;TIMED OUT WHILE WAITING FOR THE INTRUPT.
4891 ;ONE OF THE COMMANDS DID NOT INTERRUPT
4892 021516 113700 001534 NIEROR: MOVB INTFLG,RO
4893 021522 042700 177760 BIC #177760,RO
4894 021526 010003 MOV RO,R3
4895 021530 062700 001306 ADD #KEY,RO
4896 021534 011037 0C1172 MOV (RO),SREG4
4897 021540 042737 177770 001172 BIC #177770,SREG4
    
```

H03

```

4898 021546 013737 001172 001250      MOV      $REG4,SRDRV      ;GET DRIVE #, FOR TYPING SERIAL #
4899
4900 021554 104421 002245      TYPMSG   ,MSG15          ;PRINT 'DRVE # DIDN'T INTRUPT AFTER'
4901 021560 016305 002032      MOV      PC,MND(R3),R5
4902 021564 016504 000002      MOV      2(R5),R4
4903 021570 004737 021736      JSR      PC,TYPFN
4904 021574 004737 022032      JSR      PC,GT4RG
4905 021600 104025      ERROR    25              ;COMMAND TYPED OUT IN EROR MESSAGE DID
4906                                     ;NOT INTERUPT ON COMPLETION.
4907 021602 052710 104000      BIS      #BIT15+BIT11,(R0) ;INDICATE THAT FUNCTION IS ABCR'ED
4908 021606 000444      BR
4909
4910
4911 021610 005037 001460      QEROR:  CLR      QSCNT      ;REESTABLISH COUNT
4912 021614 004737 022032      JSR      PC,GT4RG
4913 021620 104026      ERROR    26
4914                                     ;ALL 8 COMMANDS SHOULD BE DONE BY NOW, TIMED
4915                                     ;OUT. THE PROGRAM IS WAITING FOR ONE OF THE
4916                                     ;COMMANDS IN THE Q TO BE FINISHED AND THIS
4917                                     ;DID NOT HAPPEN OR FOR SOME OTHER REASON THE
4918                                     ;'FINISHED' FLAG (BIT 15) OF ONE OF THE 8
4919                                     ;COMMAND KEYS WAS NOT SET. VARIOUS FLAGS 'POS',-7
4920                                     ;'BUSY'(-7), 'KEY'(-8) CONTAIN INFORMATION
4921                                     ;ABOUT THE STATUS OF THE SYSTEM.
4922 021622 032777 020000 157310      BIT      #SW13,JSWR      ;INHIBIT TYPEOUT?
4923 021630 001024      BNE      25              ;YES
4924 021632 104401 002305      TYPE,   MSG16
4925 021636 012700 001306      MOV      #KEY,R0
4926 021642 012701 001426      MOV      #BUSY,R1
4927 021646 012702 177770      MOV      #-10,R2
4928 021652 104401 001213      1$:    TYPE   $CRLF
4929 021656 012046      MOV      (R0)+,-(SP)    ;TYPE OUT CONTENTS OF ALL KEYS
4930 021660 104402      TYPOC   ;KEY-KEY8
4931 021662 104401 002662      TYPE   ,BLNKS3
4932 021666 005046      CLR      -(SP)
4933 021670 112116      MOV      (R1)+,(SP)    ;TYPE OUT CONTENTS OF ALL BUSY FLAGS
4934 021672 104403      TYPOS   ;BUSY-BUSY?
4935 021674      .BYTE  3
4936 021675      .BYTE  0
4937 021676 005202      INC      R2              ;DONE?
4938 021700 001364      BNE      1$              ;NO
4939
4940 021702 004737 016006      2$:    JSR      PC,CLRERR   ;MAKE SURE THERE IS NO HEAD MOVEMENT ON
4941                                     ;ANY DRIVE & THEN DO CONTROL RESET
4942 021706 000137 010630      JMP      BEGNEX          ;GO, BAK AND CONTINUE
4943
4944 021712 005004      CNOBSY: CLR      R4
4945 021714 005204      INC      R4
4946 021716 001376      BNE      -2
4947 021720 013746 001244      SEXIT: MOV      PPRVL,-(SP)
4948 021724 012746 021732      MOV      #RTIPC7,-(SP) ;RETURN FOR RTI *****
4949 021730 000002      RTI
4950
4951 021732 000137 010650      RTIPC7: JMP      QMNGER
    
```



```

4952 ;TYPFN
4953 ;ROUTINE TO TYPE OUT THE FUNCTION (READ,WRITE,ETC) ;R4 CONTAINS THE
4954 ;FUNCTION CODE AT THE TIME OF ENTRY.
4955 ;SW 13, IF SET INHIBITS TYPEOUT.
4956
4957 021736 032777 020000 157174 TYPFN: BIT #SW13,DSWR ;INHIBIT TYPEOUT?
4958 021744 001031 BNE 5$ ;YES
4959 021746 020427 000002 CMP R4,#2 ;WRITE?
4960 021752 001002 BNE 1$
4961 021754 104401 002133 TYPE ,MSG6
4962 021760 022704 000004 1$: CMP #4,R4 ;READ?
4963 021764 001002 BNE 2$
4964 021766 104401 002141 TYPE ,MSG7
4965 021772 022704 000012 2$: CMP #12,R4 ;READ CHECK?
4966 021776 001002 BNE 3$
4967 022000 104401 002156 TYPE ,MSG9
4968 022004 022704 000006 3$: CMP #6,R4 ;WRITE CHECK?
4969 022010 001002 BNE 4$
4970 022012 104401 002146 TYPE ,MSG8
4971 022016 022704 000010 4$: CMP #10,R4 ;SEEK?
4972 022022 001002 BNE 5$
4973 022024 104401 002201 TYPE ,MSG11
4974 022030 000207 5$: RTS PC
  
```

J09

```

4975 ;GT4RG
4976 ;GET CONTENTS OF RKCS, RKER, RKDS, RKDAA
4977
4978 022032 017737 157172 001170 GT4RG: MOV @RKDA,$REG3
4979 022040 017737 157156 001162 GT3RG: MOV @RKCS,$REG0
4980 022046 017737 157146 001164 MOV @RKER,$REG1
4981 022054 017737 157136 001166 MOV @RKDS,$REG2
4982 022062 000207 RTS PC
4983
4984
4985
4986
4987
4988
4989

```

```

;GETINF
;THIS ROUTINE GETS CONTENTS OF RKCE, RKER, RKDS. THEN IT BREAKS DOWN THE
;CONTENTS OF RKDA INTO ITS COMPONENT: CYLINDER, SECTOR, SURFACE AND DRIVE
;NUMBER.

```

```

4990 022064 004737 022040 GETINF: JSR PC,GT3RG
4991 022070 010046 MOV RO,-(SP)
4992 022072 010146 MOV R1,-(SP)
4993 022074 010246 MOV R2,-(SP)
4994 022076 012700 001200 MOV #SREG6+2,R0
4995 022102 017701 157122 MOV @RKDA,R1
4996 022106 010102 MOV R1,R2
4997 022110 042702 177760 BIC #177760,R2
4998 022114 010240 MOV R2,-(R0)
4999 022116 006201 ASR R1
5000 022120 006201 ASR R1
5001 022122 006201 ASR R1
5002 022124 006201 ASR R1
5003 022126 010102 MOV R1,R2
5004 022130 042702 177776 BIC #177776,R2
5005 022134 010240 MOV R2,-(R0)
5006 022136 006201 ASR R1
5007 022140 010102 MOV R1,R2
5008 022142 042702 177400 BIC #177400,R2
5009 022146 010240 MOV R2,-(R0)
5010 022150 000301 SWAB R1
5011 022152 042701 177770 BIC #177770,R1
5012 022156 010140 MOV R1,-(R0)
5013 022160 012602 MOV (SP)+,R2
5014 022162 012601 MOV (SP)+,R1
5015 022164 012600 MOV (SP)+,R0
5016 022166 000207 RTS PC

```

```

5017 ;CROTLF
5018 ;CALL: MOV #NO, -(SP) ;PUSH NO. TO BE ROTATED ON STACK
5019 ; JSR PC, CROTLF
5020 ;THIS ROUTINE ROTATES BITS 15, 14, 13 OF A WORD INTO BITS 2, 1, 0. THE
5021 ;REST OF THE BITS OF THE ROTATED WORD ARE CLEARED.
5022
5023
5024 022170 042766 017777 000002 CROTLF: BIC #17777, 2(SP)
5025 022176 000241 CLC
5026 022200 006166 000002 ROL 2(SP)
5027 022204 006166 000002 ROL 2(SP)
5028 022210 006166 000002 ROL 2(SP)
5029 022214 006166 000002 ROL 2(SP)
5030 022220 000207 RTS PC
5031
5032
5033 ;RG4SDRV
5034 ;CALL: JSR PC, RG4SDRV
5035 ;THIS ROUTINE GETS THE CONTENTS OF RKDS, RKER, RKCS, RKDA. THEN
5036 ;IT SAVES THE DRIVE NUMBER FROM RKDA IN 'SRDRV'.
5037 022222 004737 022032 RG4SDR: JSR PC, GT4RG ;GET RKCS, ER, DS, DA
5038
5039
5040 ;GTSDRV
5041 ;CALL: JSR PC, GTSDRV
5042 ;THIS ROUTINE EXTRACTS THE DRIVE # FROM RKDA (BITS 15,14,13) AND SAVES
5043 ;IT IN "SRDRV" (BITS 0,1,2)
5044
5045 022226 017746 156776 GTSDRV: MOV #RKDA, -(SP) ;GET BITS 15,14,13 FROM RKDA
5046 022232 004737 02217C JSR PC, CROTLF
5047 022236 012637 001250 MOV (SP)+, SRDRV ;SAVE THE DRIVE #
5048 022242 000207 RTS PC
  
```

109

```

5049          SBTTL  DRV.RESET - DRIVE RESET ROUTINE
5050          ;DRV.RESET - DRIVE RESET ROUTINE
5051          ;IF R/W/S RDY DOES NOT SET WITHIN A CERTAIN TIME OF DOING DRIVE RESET
5052          ;AN ERROR IS REPORTED.
5053
5054 022244 005037 022354 DR.RST: CLR      TIMEOUT
5055 022250 013777 001502 156752 MOV     @DRV,@RKDA
5056 022256 012777 000015 156736 MOV     #15,@RKCS
5057 022264 104417          CON.RDY
5058 022266 032777 000100 156722 1$: BIT     #100,@RKDS      ;DID R/W/S RDY SET?
5059 022274 001026          BNE     2$              ;YES
5060 022276 012746 177760 MOV     #-20,-(SP)      ;NO, WAIT FOR R/W/S
5061 022302 005216          INC     (SP)
5062 022304 001376          BNE     -2
5063 022306 005726          TST     (SP)+
5064 022310 005237 022354 INC     TIMEOUT
5065 022314 001364          BNE     1$
5066 022316 032777 020000 156614 BIT     #SW13,@SWR      ;INHIBIT TYPEOUT?
5067 022324 001012          BNE     2$              ;YES
5068 022326 104401 001213 TYPE    ,SCRLF          ;TIMED OUT, R/W/S RDY DID NOT SET
5069 022332 104401 027746 TYPE    ,EM4            ;REPORT ERROR
5070 022336 104401 002206 TYPE    ,MSG12
5071 022342 011646          MOV     (SP),-(SP)
5072 022344 162716 000002 SUB     #2,(SP)
5073 022350 104402          TYPOC
5074 022352 000002 2$: RTI
5075 022354 000000 TIMEOUT: 0
  
```

```

5076          SBTTL CON.RESET - CONTROL RESET ROUTINE
5077          ;CON.RESET
5078          ;CONTROL RESET ROUTINE
5079          ;CON.RDY
5080          ;CONTROL READY ROUTINE
5081
5082 022356 012777 000001 156636 CN.RST: MOV      #1, @RKCS
5083 022364 005037 001472          CN.RDY: CLR      TIMER
5084 022370 105777 '56626          IS:   TSTB     @RKCS          ;DID CONTROL RDY SET?
5085 022374 100451          BMI      2$          ;YES
5086 022376 012746 177750          MOV      @-30, -(SP)      ;WAIT FOR CNTRL RDY
5087 022402 005216          INC      (SP)
5088 022404 001376          BNE     -2
5089 022406 005726          TST     (SP)+
5090 022410 005237 001472          INC     TIMER
5091 022414 001365          BNE     1$
5092 022416 032777 020000 156514 BIT      @SW13, @SWR      ;INHIBIT TYPEOUT?
5093 022424 001035          BNE     2$          ;YES
5094 022426 104401 002206          TYPE   MSG12          ;CNTRL RDY DID NOT SET, REPORT ERROR
5095 022432 011646          MOV     (SP), -(SP)
5096 022434 162716 000002          SUB     #2, (SP)
5097 022440 104402          TYPOC
5098 022442 104401 022450          TYPE   ,65$          ;;TYPE ASCIZ STRING
5099 022446 000421          BR     64$          ;;GET OVER THE ASCIZ
5100          ;;65$: .ASCIZ <15><12>/CONTROLLER NOT READY - RKCS=/
5101 022512          64$:
5102 022512 017746 156504          MOV     @RKCS, -(SP)
5103 022516 104402          TYPOC
5104 022520 000002          2$:   RTI
  
```

```

S105 .SBTTL TYPMSG - TYPE MESSAGE ROUTINE (SW13)
S106 ;TYPMSG
S107 ;THIS ROUTINE IS USED FOR MESSAGE TYPEOUTS. IF SW 13 IS SET THE TYPEOUT
S108 ;IS SKIPPED.
S109 ;CALL: TYPMSG
S110 ; POINTER ;POINTER TO THE ASCII MESSAGE STRING
S111
S112 022522 032777 020000 156410 TY.MSG: BIT #SW13,@SWR ;INHIBIT TYPEOUT?
S113 022530 001005 BNE 2$ ;YES
S114 022532 017637 000000 022542 MOV @2(SP),1$ ;GET POINTER TO ASCII STRING
S115 022540 104401 TYPE
S116 022542 000000 1$: .WORD 0
S117
S118 022544 062716 000002 2$: ADD #2,(SP) ;ADJUST RETURN ADDRESS TO SKIP OVER POINTER
S119 022550 000002 RTI

```

```

5120          SBTTL KWSRVE - KWILL CLOCK SERVICE ROUTINE
5121          ; THIS ROUTINE SERVICES THE INTERRUPT FROM THE KWILL LINE CLOCK
5122          ; AND KEEPS TRACK OF ELAPSED TIME.
5123          ; KWCOUNT- CONTAINS CYCLES (PER SECOND) (2'S COMPLEMENT)
5124          ; KWSEC- CONTAINS SECONDS (2'S COMPLEMENT)
5125          ; KWMIN- CONTAINS MINUTES (2'S COMPLEMENT)
5126          ; KWHR- CONTAINS HOURS (2'S COMPLEMENT)
5127
5128 022552 005237 001560 KWSRVE: INC KWCOUNT ;COUNT 60 CPS
5129 022556 001401 BEQ 1$ ;OVERFLOWED?
5130 022560 000002 RTI
5131 022562 012737 177704 001560 1$: MOV #-60.,KWCOUNT ;RESET 60 CPS COUNT
5132 022570 005237 001556 INC KWSEC ;COUNT SECONDS
5133 022574 001401 BEQ 2$ ;OVERFLOWED?
5134 022576 000002 RTI ;RETURN
5135 022600 012737 177704 001556 2$: MOV #-60.,KWSEC ;RESET "SECONDS" COUNT
5136 022606 005237 001554 INC KWMIN ;COUNT MINUTES
5137 022612 001005 BNE 3$ ;OVERFLOWED?
5138 022614 012737 177704 001554 MOV #-60.,KWMIN ;RESET "MINUTES" COUNT
5139 022622 005237 001552 INC KWHR ;COUNT HOURS
5140
5141 022626 000002 3$: RTI ;RETURN
5142
5143
5144          ;WATIME
5145          ;ROUTINE PROVIDES SOME WAITING TIME.
5146
5147 022630 013746 022652 WATIME: MOV 2$,-(SP) ;COUNTER VALUE
5148 022634 005237 022654 1$: INC 3$ ;COUNT
5149 022640 001375 BNE 1$ ;HANG IN THERE UNTIL COUNT WRAPS AROUND
5150 022642 005216 INC (SP) ;COUNT AGAIN
5151 022644 001373 BNE 1$ ;GO THROUGH MINOR LOOP AGAIN
5152 022646 005726 TST (SP)+ ;RESTORE THE STACK POINTER
5153 022650 000207 RTS PC ;RETURN
5154 022652 177730 2$: .WORD 177730 ;VALUE FOR APPROX 15 SEC DELAY
5155 022654 000000 3$: .WORD 0 ;"MINOR" LOOP COUNTER
    
```

5156
 5157
 5158
 5159
 5160
 5161
 5162
 5163
 5164
 5165
 5166
 5167
 5168
 5169
 5170
 5171

022656 005737 001264
 022662 001401
 022664 000207
 022666 104401 002225
 022672 004737 022630
 022676 012706 001100
 022702 000400

```

:CHDPRS
:THIS ROUTINE CHECKS IF THERE ANY DRIVES PRESENT (ON LINE), IF THERE
:ARE, A RETURN IS MADE. IF THERE ARE NONE PRESENT, A MESSAGE IS PRINTED OUT.
:THE STACK POINTER IS RE-INITIATED TO 1100 AND CONTROL IS TRANSFERRED
:TO THE END OF PASS ROUTINE, SEOP. BEFORE PASSING CONTROL TO SEOP, SOME
:TIME IS KILLED (WATIME), THIS IS DONE TO KEEP THE NUMBER OF MESSAGES
:(END OF PASS #X) TO A SMALL AMOUNT.
    
```

```

CHDPRS: TST      DRVPRS      ;ANY DRIVES PRESENT?
        BEQ      IS          ;NO
        RTS      PC         ;YES, EXIT
IS:     TYPE     MSG14       ;NO, GIVE A MESSAGE
        JSR      PC,WATIME  ;KILL SOME TIME
        MOV      #STACK,SP  ;REINITIALIZE STACK
        BR       SEOP       ;GO TO END OF PASS ROUTINE
    
```


.SBTTL END OF PASS ROUTINE

5172
5173
5174
5175
5176
5177
5178
5179
5180
5181
5182
5183
5184
5185
5186
5187
5188
5189
5190
5191
5192
5193
5194
5195
5196
5197
5198
5199
5200

022704
022704 000004
022706 005037 001102
022712 005237 001100
022716 042737 100000 001100
022724 005327
022726 000001
022730 003013
022732 012737
022734 000001
022736 022726
022740 013700 000042
022744 001405
022746 000005
022750 004710
022752 000240
022754 000240
022756 000240
022760
022760 000137
022762 010630

```

*****
*INCREMENT THE PASS NUMBER ($PASS)
*INDICATE END-OF-PROGRAM AFTER 1 PASSES THRU THE PROGRAM
*IF THERES A MONITOR GO TO IT
*IF THERE ISN'T JUMP TO BEGNEX
SEOP:
SCOPE
CLR $STNM          ;; ZERO THE TEST NUMBER
INC $PASS          ;; INCREMENT THE PASS NUMBER
BIC #100000,$PASS ;; DON'T ALLOW A NEG. NUMBER
DEC (PC)+         ;; LOOP?
SEOPCT: .WORD 1
BGT $DOAGN        ;; YES
MOV (PC)+,(PC)+  ;; RESTORE COUNTER
SENDCT: .WORD 1
$GET42: MOV #42,R0 ;; GET MONITOR ADDRESS
        BEQ $DOAGN ;; BRANCH IF NO MONITOR
        RESET    ;; CLEAR THE WORLD
SENDAD: JSR PC,(R0) ;; GO TO MONITOR
        NOP     ;; SAVE ROOM
        NOP     ;; FOR
        NOP     ;; ACT11
$DOAGN:
$RTNAD: JMP #42,R0 ;; RETURN
        .WORD BEGNEX
    
```

E10

```

5201 .SBTTL TTY INPUT ROUTINE
5202
5203 ;*****
5204 .ENABL LSB
5205
5206 ;*****
5207 ;*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
5208 ;*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
5209 ;*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
5210 ;*WHEN OPERATING IN TTY FLAG MODE.
5211 022764 022737 000176 001140 $CKSWR: CMP #SWREG,SWR ;; IS THE SOFT-SWR SELECTED?
5212 022772 001074 BNE 15$ ;; BRANCH IF NO
5213 022774 105777 156144 TSTB @STKS ;; CHAR THERE?
5214 023000 100071 BPL 15$ ;; IF NO, DON'T WAIT AROUND
5215 023002 117746 156140 MOVB @STKB,-(SP) ;; SAVE THE CHAR
5216 023006 042716 177600 BIC #177,(SP) ;; STRIP-OFF THE ASCII
5217 023012 022726 000007 CMP #7,(SP)+ ;; IS IT A CONTROL G?
5218 023016 001062 BNE 15$ ;; NO, RETURN TO USER
5219 023020 123727 001134 000001 CMPB $AUTOB,#1 ;; ARE WE RUNNING IN AUTO-MODE?
5220 023026 001456 BEQ 15$ ;; BRANCH IF YES
5221
5222 023030 104401 023511 SGTSWR: TYPE , $CNTLG ;; ECHO THE CONTROL-G (↑G)
5223 023034 104401 023516 TYPE $MSWR ;; TYPE CURRENT CONTENTS
5224 023040 013746 000176 MOV SWREG,-(SP) ;; SAVE SWREG FOR TYPEOUT
5225 023044 104402 TYPOC ;; GO TYPE--OCTAL ASCII(ALL DIGITS,
5226 023046 104401 023527 TYPE , $MNEW ;; PROMPT FOR NEW SWR
5227 023052 005046 19$: CLR -(SP) ;; CLEAR COUNTER
5228 023054 005046 CLR -(SP) ;; THE NEW SWR
5229 023056 105777 156062 7$: TSTB @STKS ;; CHAR THERE?
5230 023062 100375 BPL 7$ ;; IF NOT TRY AGAIN
5231
5232 023064 117746 156056 MOVB @STKB,-(SP) ;; PICK UP CHAR
5233 023070 042716 177600 BIC #177,(SP) ;; MAKE IT 7-BIT ASCII
5234
5235
5236
5237 023074 021627 000025 9$: CMP (SP),#25 ;; IS IT A CONTROL-U?
5238 023100 001005 BNE 10$ ;; BRANCH IF NOT
5239 023102 104401 023504 TYPE , $CNTLU ;; YES, ECHO CONTROL-U (↑U)
5240 023106 062706 000006 20$: ADD #6,SP ;; IGNORE PREVIOUS INPUT
5241 023112 000757 BR 19$ ;; LET'S TRY IT AGAIN
5242
5243
5244 023114 021627 000015 10$: CMP (SP),#15 ;; IS IT A <CR>?
5245 023120 001022 BNE 16$ ;; BRANCH IF NO
5246 023122 005766 000004 TST 4(SP) ;; YES, IS IT THE FIRST CHAR?
5247 023126 001403 BEQ 11$ ;; BRANCH IF YES
5248 023130 016677 000002 156002 MOV 2(SP),@SWR ;; SAVE NEW SWR
5249 023136 062706 000006 11$: ADD #6,SP ;; CLEAR UP STACK
5250 023142 104401 001213 14$: TYPE , $CRLF ;; ECHO <CR> AND <LF>
5251 023146 123727 001135 000001 CMPB $INTAG,#1 ;; RE-ENABLE TTY KBD INTERRUPTS?
5252 023154 001003 BNE 15$ ;; BRANCH IF NOT
5253 023156 012777 000100 155760 MOV #100,@STKS ;; RE-ENABLE TTY KBD INTERRUPTS
5254 023164 000002 15$: RTI ;; RETURN
5255 023166 004737 024414 16$: JSR PC,$TYPEC ;; ECHO CHAR
5256 023172 021627 000060 CMP (SP),#60 ;; CHAR < 0?
    
```

F I U

5257	023176	002420			BLT	18\$:: BRANCH IF YES
5258	023200	021627	000067		CMP	(SP), #67	:: CHAR > 7?
5259	023204	003015			BGT	18\$:: BRANCH IF YES
5260	023206	042726	000060		BIC	#60, (SP)+	:: STRIP-OFF ASCII
5261	023212	005766	000002		TST	2(SP)	:: IS THIS THE FIRST CHAR
5262	023216	001403			BEQ	17\$:: BRANCH IF YES
5263	023220	006316			ASL	(SP)	:: NO, SHIFT PRESENT
5264	023222	006316			ASL	(SP)	:: CHAR OVER TO MAKE
5265	023224	006316			ASL	(SP)	:: ROOM FOR NEW ONE.
5266	023226	005266	000002	17\$:	INC	2(SP)	:: KEEP COUNT OF CHAR
5267	023232	056616	177776		BIS	-2(SP), (SP)	:: SET IN NEW CHAR
5268	023236	000707			BR	7\$:: GET THE NEXT ONE
5269	023240	104401	001212	18\$:	TYPE	\$QUES	:: TYPE ?(CR)(LF)
5270	023244	000720			BR	20\$:: SIMULATE CONTROL-U
5271					.DSABL	LSB	
5272							
5273							
5274							
5275							
5276							
5277							
5278							
5279							
5280							
5281							
5282	023246	011646			\$RDCHR: MOV	(SP), -(SP)	:: PUSH DOWN THE PC
5283	023250	016666	000004	000002	MOV	4(SP), 2(SP)	:: SAVE THE PS
5284	023256	105777	155662		1\$:	TSTB	2\$TKS
5285	023262	100375			BPL	1\$:: WAIT FOR
5286	023264	117766	155656	000004	MOVB	2\$TKB, 4(SP)	:: A CHARACTER
5287	023272	042766	177600	000004	BIC	#1C<177>, 4(SP)	:: READ THE TTY
5288	023300	026627	000004	000023	CMP	4(SP), #23	:: GET RID OF JUNK IF ANY
5289	023306	001013			BNE	3\$:: IS IT A CONTROL-S?
5290	023310	105777	155630	2\$:	TSTB	2\$TKS	:: BRANCH IF NO
5291	023314	100375			BPL	2\$:: WAIT FOR A CHARACTER
5292	023316	117746	155624		MOVB	2\$TKB, -(SP)	:: LOOP UNTIL ITS THERE
5293	023322	042716	177600		BIC	#1C177, (SP)	:: GET CHARACTER
5294	023326	022627	000021		CMP	(SP)+, #21	:: MAKE IT 7-BIT ASCII
5295	023332	001366			BNE	2\$:: IS IT A CONTROL-Q?
5296	023334	000750			BR	1\$:: IF NOT DISCARD IT
5297	023336	026627	000004	000140	3\$:	CMP	4(SP), #140
5298	023344	002407			BLT	4\$:: YES, RESUME
5299	023346	026627	000004	000175	CMP	4(SP), #175	:: IS IT UPPER CASE?
5300	023354	003003			BGT	4\$:: BRANCH IF YES
5301	023356	042766	000040	000004	BIC	#40, 4(SP)	:: IS IT A SPECIAL CHAR?
5302	023364	000002			4\$:	RTI	:: BRANCH IF YES
5303							:: MAKE IT UPPER CASE
5304							:: GO BACK TO USER
5305							
5306							
5307							
5308							
5309							
5310	023366	010346			\$RDLIN: MOV	R3, -(SP)	:: SAVE R3
5311	023370	012703	023474		1\$:	MOV	#TTYIN, R3
5312	023374	022703	023504		2\$:	CMP	#TTYIN+8., R3

*THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY

*CALL:

* RDCHR :: INPUT A SINGLE CHARACTER FROM THE TTY
 * RETURN HERE :: CHARACTER IS ON THE STACK
 * :: WITH PARITY BIT STRIPPED OFF

*THIS ROUTINE WILL INPUT A STRING FROM THE TTY

*CALL:

* RDLIN :: INPUT A STRING FROM THE TTY
 * RETURN HERE :: ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
 * :: TERMINATOR WILL BE A BYTE OF ALL 0'S

GIU

5313	023400	101405				BLOS	4S	:: BR IF YES
5314	023402	104410				RDCHR		:: GO READ ONE CHARACTER FROM THE TTY
5315	023404	112613				MOVB	(SP)+,(R3)	:: GET CHARACTER
5316	023406	122713	000177		10S:	CMPB	#177,(R3)	:: IS IT A RUBOUT
5317	023412	001003				BNE	3S	:: SKIP IF NOT
5318	023414	104401	001212		4S:	TYPE	SQUES	:: TYPE A '?'
5319	023420	000763				BR	1S	:: CLEAR THE BUFFER AND LOOP
5320	023422	111337	023472		3S:	MOVB	(R3),9S	:: ECHO THE CHARACTER
5321	023426	104401	023472			TYPE	9S	
5322	023432	122723	000015			CMPB	#15,(R3)+	:: CHECK FOR RETURN
5323	023436	001356				BNE	2S	:: LOOP IF NOT RETURN
5324	023440	105063	177777			CLRB	-1(R3)	:: CLEAR RETURN (THE 15)
5325	023444	104401	001214			TYPE	SLF	:: TYPE A LINE FEED
5326	023450	012603				MOV	(SP)+,R3	:: RESTORE R3
5327	023452	011646				MOV	(SP)-,(SP)	:: ADJUST THE STACK AND PUT ADDRESS OF THE
5328	023454	016666	000004	000002		MOV	4(SP),2(SP)	:: FIRST ASCII CHARACTER ON IT
5329	023462	012766	023474	000004		MOV	#STTYIN,4(SP)	
5330	023470	000002				RTI		:: RETURN
5331	023472	000			9S:	.BYTE	0	:: STORAGE FOR ASCII CHAR. TO TYPE
5332	023473	000				.BYTE	0	:: TERMINATOR
5333	023474	000010			STTYIN:	.BLKB	8.	:: RESERVE 8 BYTES FOR TTY INPUT
5334	023504	052536	005015	000	SCNTLU:	.ASCIZ	/U/<15><12>	:: CONTROL "U"
5335	023511	136	006507	000012	SCNTLG:	.ASCIZ	/G/<15><12>	:: CONTROL "G"
5336	023516	005015	053523	020122	SMSWR:	.ASCIZ	<15><12>/SWR = /	
5337	023524	020075	000					
5338	023527	040	047040	053505	SMNEW:	.ASCIZ	/ NEW = /	
5339	023534	036440	000040					

H10

5340
5341
5342
5343
5344
5345
5346
5347
5348
5349
5350 023540 011646
5351 023542 016666 000004 000002
5352 023550 010046
5353 023552 010146
5354 023554 010246
5355 023556 104411
5356 023560 012600
5357 023562 005001
5358 023564 005002
5359 023566 112046
5360 023570 001412
5361 023572 006301
5362 023574 006102
5363 023576 006301
5364 023600 006102
5365 023602 006301
5366 023604 006102
5367 023606 042716 177770
5368 023612 062601
5369 023614 000764
5370 023616 005726
5371 023620 010166 000012
5372 023624 010237 023640
5373 023630 012602
5374 023632 012601
5375 023634 012600
5376 023636 000002
5377 023640 000000

```
.SBTTL READ AN OCTAL NUMBER FROM THE TTY

*****
; THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
; CHANGE IT TO BINARY.
; CALL:
; *   RDOCT           ;; READ AN OCTAL NUMBER
; *   RETURN HERE    ;; LOW ORDER BITS ARE ON TOP OF THE STACK
; *                   ;; HIGH ORDER BITS ARE IN $HIOCT

$RDOCT: MOV     (SP), -(SP)           ;; PROVIDE SPACE FOR THE
        MOV     4(SP), 2(SP)        ;; INPUT NUMBER
        MOV     R0, -(SP)           ;; PUSH R0 ON STACK
        MOV     R1, -(SP)           ;; PUSH R1 ON STACK
        MOV     R2, -(SP)           ;; PUSH R2 ON STACK
1$:     RDLIN                    ;; READ AN ASCII LINE
        MOV     (SP)+, R0           ;; GET ADDRESS OF 1ST CHARACTER
        CLR     R1                   ;; CLEAR DATA WORD
        CLR     R2
2$:     MOVB    (R0)+, -(SP)        ;; PICKUP THIS CHARACTER
        BEQ     3$                   ;; IF ZERO GET OUT
        ASL    R1                      ;; *2
        ROL    R2
        ASL    R1                      ;; *4
        ROL    R2
        ASL    R1                      ;; *8
        ROL    R2
        BIC    #1C7, (SP)           ;; STRIP THE ASCII JUNK
        ADD    (SP)+, R1           ;; ADD IN THIS DIGIT
        BR     2$                   ;; LOOP
3$:     TST     (SP)+               ;; CLEAN TERMINATOR FROM STACK
        MOV     R1, 12(SP)          ;; SAVE THE RESULT
        MOV     R2, $HIOCT
        MOV     (SP)+, R2           ;; POP STACK INTO R2
        MOV     (SP)+, R1           ;; POP STACK INTO R1
        MOV     (SP)+, R0           ;; POP STACK INTO R0
        RTI
$HIOCT: .WORD    0                ;; HIGH ORDER BITS GO HERE
```

.SBTTL READ A DECIMAL NUMBER FROM THE TTY

5378
5379
5380
5381
5382
5383
5384
5385
5386
5387
5388
5389
5390
5391
5392
5393
5394
5395
5396
5397
5398
5399
5400
5401
5402
5403
5404
5405
5406
5407
5408
5409
5410
5411
5412
5413
5414
5415
5416
5417
5418
5419
5420
5421
5422
5423
5424
5425
5426
5427
5428
5429
5430
5431
5432
5433

023642 011646
023644 016666 000004 000002
023652 010046
023654 010146
023656 010246
023660 104411
023662 012600
023664 010037 024010
023670 005046
023672 005002
023674 122710 000055
023700 001001
023702 112002
023704 112001
023706 001424
023710 122701 000060
023714 003032
023716 122701 000071
023722 002427
023724 032716 170000
023730 001024
023732 006316
023734 011646
023736 006316
023740 006316
023742 062616
023744 102416
023746 162701 000060
023752 060116
023754 102412
023756 000752
023760 005702
023762 001401
023764 005416
023766 012666 000012
023772 012602
023774 012601
023776 012600
024000 000002
024002 005726
024004 105010

```

*****
*THIS ROUTINE WILL READ A DECIMAL (ASCII) NUMBER FROM THE TTY AND
*CHANGE IT TO BINARY. IF TOO MANY CHARACTERS OR ANY ILLEGAL CHARACTERS
*ARE READ A "?" FOLLOWED BY A CARRIAGE RETURN-LINE FEED WILL BE TYPED.
*THE COMPLETE NUMBER MUST BE RETYPED. THE INPUT IS TERMINATED BY THE
*USER TYPING A CARRIAGE RETURN. THE RANGE OF THE INPUT NUMBER IS
*POSITIVE 32767 TO NEGATIVE 32768.
*CALL:
*      RODEC          ;; READ A DECIMAL NUMBER
*      RETURN HERE   ;; NUMBER IS ON TOP OF THE STACK
:
SRDEC: MOV      (SP), -(SP)      ;; PROVIDE SPACE FOR
      MOV      4(SP), 2(SP)    ;; THE INPUT NUMBER
      MOV      RO, -(SP)      ;; PUSH RO ON STACK
      MOV      R1, -(SP)      ;; PUSH R1 ON STACK
      MOV      R2, -(SP)      ;; PUSH R2 ON STACK
1$:   RDLIN     ;; READ AN ASCII LINE
      MOV      (SP)+, RO      ;; ADDRESS OF 1ST CHAR.
      MOV      RO, 6$        ;; SAVE INCASE OF BAD INPUT
      CLR      -(SP)         ;; CLEAR DATA WORD
      CLR      R2           ;; SIGN SET POSITIVE
      CMPB    #'-, (RO)     ;; SEE IF A MINUS SIGN WAS TYPED
      BNE     2$           ;; BR IF NO MINUS SIGN
      MOVB    (RO)+, R2     ;; SAVE FOR LATER USE
2$:   MOVB    (RO)+, R1     ;; PICKUP THIS CHARACTER
      BEQ     3$           ;; GET OUT IF ZERO
      CMPB    #'0, R1      ;; MAKE SURE THIS CHARACTER
      BGT     5$           ;; IS A DIGIT BETWEEN 0 & 9
      CMPB    #'9, R1
      BLT     5$
      BIT     #'C7777, (SP) ;; DON'T LET NUMBER GET TO BIG
      BNE     5$           ;; BR IF NUMBER WOULD OVERFLOW
      ASL     (SP)         ;; *2
      MOV     (SP), -(SP)  ;; SAVE FOR LATER
      ASL     (SP)         ;; *4
      ASL     (SP)         ;; *8
      ADD     (SP)+, (SP)  ;; *10.
      BVS     5$           ;; OVERFLOW ISN'T ALLOWED
      SUB     #'0, R1      ;; STRIP AWAY THE ASCII JUNK
      ADD     R1, (SP)     ;; ADD IN THIS DIGIT
      BVS     5$           ;; OVERFLOW ISN'T ALLOWED
      BR     2$           ;; LOOP
3$:   TST     R2           ;; CHECK IF NUMBER IS NEG
      BEQ     4$           ;; BR IF NO
      NEG     (SP)        ;; YES--NEGATE THE NUMBER
4$:   MOV     (SP)+, 12(SP) ;; SAVE THE RESULT
      MOV     (SP)+, R2    ;; POP STACK INTO R2
      MOV     (SP)+, R1    ;; POP STACK INTO R1
      MOV     (SP)+, RO    ;; POP STACK INTO RO
      RTI                    ;; RETURN
5$:   TST     (SP)+        ;; CLEAN PARTIAL NUMBER FROM STACK
      CLRB   (RO)         ;; SET A TERMINATOR
    
```

5434 024006 104401
5435 024010 000000
5436 024012 104401 001212
5437 024016 000720

6S: TYPE
WORD 0
TYPE .SQUES
BR 1S

:: TYPE THE INPUT UP TO BAD CHAR.
:: POINTER GOES HERE
:: CR & LF
:: TRY AGAIN

.SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

5438
5439
5440
5441
5442
5443
5444
5445
5446
5447
5448
5449
5450
5451
5452
5453
5454
5455
5456
5457
5458
5459
5460
5461
5462
5463
5464
5465
5466
5467
5468
5469
5470
5471
5472
5473
5474
5475
5476
5477
5478
5479
5480
5481
5482
5483
5484
5485
5486
5487
5488
5489
5490
5491
5492
5493

024020
024020 010046
024022 010146
024024 010246
024026 010346
024030 010546
024032 012746 020200
024036 016605 000020
024042 100004
024044 005405
024046 112766 000055 000001
024054 005000 1\$:
024056 012703 024234
024062 112723 000040
024066 005002 2\$:
024070 016001 024224
024074 160105 3\$:
024076 002402
024100 005202
024102 000774
024104 060105 4\$:
024106 005702
024110 001002
024112 105716
024114 100407
024116 106316 5\$:
024120 103003
024122 116663 000001 177777
024130 052702 000060 6\$:
024134 052702 000040 7\$:
024140 110223
024142 005720
024144 020027 000010
024150 002746
024152 003002
024154 010502
024156 000764
024160 105726 8\$:
024162 100003
024164 116663 177777 177776 9\$:
024172 105013
024174 012605
024176 012603
024200 012602

```

*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
*REPLACED WITH SPACES.
*CALL:
*      MOV      NUM,-(SP)      ;;PUT THE BINARY NUMBER ON THE STACK
*      TYPDS                    ;;GO TO THE ROUTINE

$TYPDS:
MOV      R0,-(SP)            ;;PUSH R0 ON STACK
MOV      R1,-(SP)            ;;PUSH R1 ON STACK
MOV      R2,-(SP)            ;;PUSH R2 ON STACK
MOV      R3,-(SP)            ;;PUSH R3 ON STACK
MOV      R5,-(SP)            ;;PUSH R5 ON STACK
MOV      #20200,-(SP)        ;;SET BLANK SWITCH AND SIGN
MOV      20(SP),R5           ;;GET THE INPUT NUMBER
BPL      1$                  ;;BR IF INPUT IS POS.
NEG      R5                  ;;MAKE THE BINARY NUMBER POS.
MOVB    #'-,1(SP)           ;;MAKE THE ASCII NUMBER NEG.
1$:     CLR      R0           ;;ZERO THE CONSTANTS INDEX
MOV      #5DBLK,R3          ;;SETUP THE OUTPUT POINTER
MOVB    #' ,(R3)+           ;;SET THE FIRST CHARACTER TO A BLANK
2$:     CLR      R2           ;;CLEAR THE BCD NUMBER
MOV      $DTBL(R0),R1       ;;GET THE CONSTANT
3$:     SUB      R1,R5        ;;FORM THIS BCD DIGIT
BLT     4$                  ;;BR IF DONE
INC     R2                  ;;INCREASE THE BCD DIGIT BY 1
4$:     ADD      R1,R5        ;;ADD BACK THE CONSTANT
TST     R2                  ;;CHECK IF BCD DIGIT=0
BNE     5$                  ;;FALL THROUGH IF 0
TSTB   (SP)                 ;;STILL DOING LEADING 0'S?
BMI     7$                  ;;BR IF YES
5$:     ASLB    (SP)         ;;MSD?
BCC     6$                  ;;BR IF NO
MOVB   1(SP),-1(R3)         ;;YES--SET THE SIGN
6$:     BIS     #'0,R2       ;;MAKE THE BCD DIGIT ASCII
7$:     BIS     #' ,R2       ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
MOVB   R2,(R3)+           ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
TST    (R0,+              ;;JUST INCREMENTING
CMP    R0,#10             ;;CHECK THE TABLE INDEX
BLT    2$                 ;;GO DO THE NEXT DIGIT
BGT    8$                 ;;GO TO EXIT
MOV    R5,R2              ;;GET THE LSD
BR     6$                 ;;GO CHANGE TO ASCII
8$:     TSTB   (SP)+        ;;WAS THE LSD THE FIRST NON-ZERO?
BPL    9$                 ;;BR IF NO
9$:     MOVB   -1(SP),-2(R3) ;;YES--SET THE SIGN FOR TYPING
CLRB   (R3)               ;;SET THE TERMINATOR
MOV    (SP)+,R5           ;;POP STACK INTO R5
MOV    (SP)+,R3           ;;POP STACK INTO R3
MOV    (SP)+,R2           ;;POP STACK INTO R2

```


5494	024202	012601			MOV	(SP)+,R1	::POP STACK INTO R1
5495	024204	012600			MOV	(SP)+,R0	::POP STACK INTO R0
5496	024206	104401	024234		TYPE	\$DBLK	::NOW TYPE THE NUMBER
5497	024212	016666	000002	000004	MOV	2(SP),4(SP)	::ADJUST THE STACK
5498	024220	012616			MOV	(SP)+,(SP)	
5499	024222	000002			RTI		::RETURN TO USER
5500	024224	023420			\$DTBL:	10000.	
5501	024226	001750				1000.	
5502	024230	000144				100.	
5503	024232	000012				10.	
5504	024234	000004			\$DBLK:	.BLKW 4	

```

5505 .SBTTL TYPE ROUTINE
5506
5507 ;*****
5508 ;ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
5509 ;THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
5510 ;*NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
5511 ;*NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
5512 ;*NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
5513 ;*
5514 ;*CALL:
5515 ;*1) USING A TRAP INSTRUCTION
5516 ;* TYPE ,MESADR ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
5517 ;*OR
5518 ;* TYPE
5519 ;* MESADR
5520 ;*
5521
5522 $TYPE: TSTB $STPFLG ;; IS THERE A TERMINAL?
5523 BPL 1$ ;; BR IF YES
5524 HALT ;; HALT HERE IF NO TERMINAL
5525 BR 3$ ;; LEAVE
5526 1$: MOV RO, -(SP) ;; SAVE RO
5527 MOV 2$(SP), RO ;; GET ADDRESS OF ASCIZ STRING
5528 2$: MOVB (RO)+, -(SP) ;; PUSH CHARACTER TO BE TYPED ONTO STACK
5529 BNE 4$ ;; BR IF IT ISN'T THE TERMINATOR
5530 TST (SP)+ ;; IF TERMINATOR POP IT OFF THE STACK
5531 60$: MOV (SP)+, RO ;; RESTORE RO
5532 3$: ADD #2, (SP) ;; ADJUST RETURN PC
5533 RTI ;; RETURN
5534 4$: CMPB #HT, (SP) ;; BRANCH IF <HT>
5535 BEQ 8$ ;; BRANCH IF NOT <CRLF>
5536 24310: CMPB #CRLF, (SP) ;; BRANCH IF NOT <CRLF>
5537 BNE 5$ ;;
5538 24316: TST (SP)+ ;; POP <CR><LF> EQUIV
5539 24320: TYPE ;; TYPE A CR AND LF
5540 24322: $CRLF
5541 24324: CLRB $CHARCNT ;; CLEAR CHARACTER COUNT
5542 24330: BR 2$ ;; GET NEXT CHARACTER
5543 24332: JSR PC, $TYPEPC ;; GO TYPE THIS CHARACTER
5544 24336: 6$: CMPB $FILLC, (SP)+ ;; IS IT TIME FOR FILLER CHARS.?
5545 24342: BNE 2$ ;; IF NO GO GET NEXT CHAR.
5546 24344: MOV $NULL, -(SP) ;; GET # OF FILLER CHARS. NEEDED
5547 ;; AND THE NULL CHAR.
5548 24350: 7$: DECB 1(SP) ;; DOES A NULL NEED TO BE TYPED?
5549 24354: BLT 6$ ;; BR IF NO--GO POP THE NULL OFF OF STACK
5550 24356: JSR PC, $TYPEPC ;; GO TYPE A NULL
5551 24362: DECB $CHARCNT ;; DO NOT COUNT AS A COUNT
5552 24366: BR 7$ ;; LOOP
5553
5554 ;HORIZONTAL TAB PROCESSOR
5555
5556 8$: MOVB #' (SP) ;; REPLACE TAB WITH SPACE
5557 9$: JSR PC, $TYPEPC ;; TYPE A SPACE
5558 24400: BITB #7, $CHARCNT ;; BRANCH IF NOT AT
5559 24406: BNE 9$ ;; TAB STOP
5560 24410: TST (SP)+ ;; POP SPACE OFF STACK

```

5561	024412	000724				BB	25	;; GET NEXT CHARACTER
5562	024414	105777	154530			\$TYPEC: TSTB	25	;; WAIT UNTIL PRINTER IS READY
5563	024420	100375				BPL	\$TYPEC	
5564	024422	116677	000002	154522		MOVB	2(SP), 2\$TPB	;; LOAD CHAR TO BE TYPED INTO DATA REG.
5565	024430	122766	000015	000002		CMPB	#CR, 2(SP)	;; IS CHARACTER A CARRIAGE RETURN?
5566	024436	001003				BNE	1\$;; BRANCH IF NO
5567	024440	105037	024460			CLRB	\$CHARCNT	;; YES--CLEAR CHARACTER COUNT
5568	024444	000406				BR	\$TYPEX	;; EXIT
5569	024446	122766	000012	000002	1\$:	CMPB	#LF, 2(SP)	;; IS CHARACTER A LINE FEED?
5570	024454	001402				BEQ	\$TYPEX	;; BRANCH IF YES
5571	024456	105227				INCB	(PC)+	;; COUNT THE CHARACTER
5572	024460	000000				\$CHARCNT: .WORD	0	;; CHARACTER COUNT STORAGE
5573	024462	000207				\$TYPEX: RTS	PC	
5574								

.SBTTL DOUBLE LENGTH BINARY TO OCTAL ASCII CONVERT ROUTINE

```

5575
5576
5577
5578
5579
5580
5581
5582
5583
5584
5585
5586 024464 104414
5587 024466 016601 000002
5588 024472 012705 024603
5589 024476 012704 000014
5590 024502 012703 177770
5591 024506 012100
5592 024510 012101
5593 024512 005002
5594 024514 110245
5595 024516 010002
5596 024520 005304
5597 024522 003007
5598 024524 001405
5599 024526 005205
5600 024530 010566 000002
5601 024534 104415
5602 024536 000207
5603 024540 006203
5604 024542 006001
5605 024544 006000
5606 024546 006001
5607 024550 006000
5608 024552 006001
5609 024554 006000
5610 024556 040302
5611 024560 062702 000060
5612 024564 000753
5613 024566 000016

*****
*THIS ROUTINE WILL CONVERT A 32-BIT UNSIGNED BINARY NUMBER TO AN
*UNSIGNED OCTAL ASCII NUMBER.
*CALL
*   MOV     #PNTR, -(SP)      ;; POINTER TO LOW WORD OF BINARY NUMBER
*   JSR     PC, @#SDB20      ;; CALL THE ROUTINE
*   RETURN                                ;; THE ADDRESS OF THE FIRST ASCII CHAR. IS ON THE STACK

SDB20: SAVREG                ;; SAVE ALL REGISTERS
MOV     2(SP), R1            ;; PICKUP THE POINTER TO LOW WORD
MOV     #SOCTVL+13., R5      ;; POINTER TO DATA TABLE
MOV     #12., R4             ;; DO ELEVEN CHARACTERS
MOV     #107, R3             ;; MASK
MOV     (R1)+, R0            ;; LOWER WORD
MOV     (R1)+, R1            ;; HIGH WORD
CLR     R2                   ;; TERMINATOR
15:     MOVB   R2, -(R5)       ;; PUT CHARACTER IN DATA TABLE
MOV     R0, R2               ;; GET THIS DIGIT
DEC     R4                   ;; COUNT THIS CHARACTER
BGT     3$                   ;; BR IF NOT THE LAST DIGIT
BEQ     2$                   ;; BR IF IT IS THE LAST DIGIT
INC     R5                   ;; ALL DIGITS DONE-ADJUST POINTER FOR FIRST
MOV     R5, 2(SP)           ;; ASCII CHAR. & PUT IT ON THE STACK
RESREG                                ;; RESTORE ALL REGISTERS
RTS     PC                   ;; RETURN TO USER
2$:     ASR     R3             ;; POSITION THE MASK FOR THE LAST DIGIT
3$:     ROR     R1             ;; POSITION THE BINARY NUMBER FOR
;; THE NEXT OCTAL DIGIT

BIC     R3, R2               ;; MASK OUT ALL JUNK
ADD     #'0, R2              ;; MAKE THIS CHAR. ASCII
BR      1$                   ;; GO PUT IT IN THE DATA TABLE
SOCTVL: .BLKB 14.           ;; RESERVE DATA TABLE
    
```

.SBTTL DOUBLE LENGTH BINARY TO DECIMAL ASCII CONVERT ROUTINE

5614
5615
5616
5617
5618
5619
5620
5621
5622
5623
5624
5625
5626
5627
5628
5629
5630
5631
5632
5633
5634
5635
5636
5637
5638
5639
5640
5641
5642
5643
5644
5645
5646
5647
5648
5649
5650
5651
5652
5653
5654
5655
5656
5657
5658
5659
5660
5661
5662
5663
5664
5665
5666
5667
5668
5669

024604 104414
024606 016602 000002
024612 012700 024764
024616 010066 000002
024622 012201
024624 012202
024626 012737 000012 024702
024634 012704 024714
024640 012705 024716
024644 005003
024646 161401
024650 005602
024652 161502
024654 002402
024656 005203
024660 000772
024662 062401
024664 005502
024666 062402
024670 022525
024672 052703 000060
024676 110320
024700 005327
024702 000000
024704 001357
024706 105020
024710 104415
024712 000207
024714 145000
024716 035632
024720 160400
024722 002765
024724 113200
024726 000230
024730 041100
024732 000017
024734 103240
024736 000001
024740 023420
024742 000000
024744 001750
024746 000000
024750 000144

```

*****
THIS ROUTINE WILL CONVERT A 32-BIT BINARY NUMBER TO AN UNSIGNED
DECIMAL (ASCII) NUMBER. THE SIGN OF THE BINARY NUMBER MUST BE
POSITIVE.
CALL
*   MOV     #PNTR, -(SP)    ;; POINTER TO LOW WORD OF BINARY NUMBER
*   JSR    PC, @SDB20      ;; THE FIRST ADDRESS OF ASCII
*   RETURN                               ;; IS ON THE STACK

SDB20:  SAVREG                ;; SAVE REGISTERS
        MOV     2(SP), R2    ;; PICKUP THE DATA POINTER
        MOV     #SDECVL, R0  ;; GET ADDRESS OF "SDECVL" STRING
        MOV     R0, 2(SP)    ;; PUT ADDRESS OF ASCII STRING ON STACK
        MOV     (R2)+, R1    ;; PICKUP THE BINARY NUMBER
        MOV     (R2)+, R2
        MOV     #10, 4S     ;; SET UP TO DO 10 CONVERSIONS
        MOV     #STNPWR, R4  ;; ADDRESS OF TEN POWER
        MOV     #STNPWR+2, R5
        CLR     R3          ;; CLEAR PARTIAL
        SUB     (R4), R1    ;; SUBTRACT TEN POWER
        SBC     R2
        SUB     (R5), R2
        BLT     3S         ;; BR IF TEN POWER TOO LARGE
        INC     R3         ;; ADD 1 TO PARTIAL
        BR     2S         ;; LOOP
        ADD     (R4)+, R1   ;; RESTORE SUBTRACTED VALUE
        ADC     R2
        ADD     (R4)+, R2
        CMP     (R5)+, (R5)+
        BIS     #0, R3     ;; MOVE TO NEXT TEN POWER
        MOVB   R3, (R0)+   ;; CHANGE PARTIAL TO ASCII
        DEC     (PC)+     ;; SAVE IT
        .WORD  0          ;; DONE?
        BNE   1S         ;; BR IF NO
        CLRB   (R0)+     ;; TERMINATOR
        RESREG                ;; RESTORE REGISTERS
        RTS    PC        ;; RETURN
STNPWR: 145000           ;; 1.0E09
        35632
        160400         ;; 1.0E08
        2765
        113200        ;; 1.0E07
        230
        041100        ;; 1.0E06
        17
        103240        ;; 1.0E05
        1
        23420         ;; 1.0E04
        0
        1750         ;; 1.0E03
        0
        144          ;; 1.0E02
    
```

5670 024752 000000
5671 024754 000012
5672 024756 000000
5673 024760 000001
5674 024762 000000
5675 024764 000014

0
12
0
1
0
\$DECVL: .BLKB 12.

:::1.0E01
:::1.0E00
:::RESERVE STORAGE FOR ASCII STRING

```

5676 .SBTTL SUPRS - TYPE NUMERICAL ASCIZ STRING, REPLACE LEADING 0'S BY BLANKS
5677 .SBTTL SUPRSL - TYPE NUMERICAL ASCIZ STRING, LEFT JUSTIFY
5678 ;NOT FROM SYSMAC
5679
5680 SUPRSL: MOV RO, -(SP) ;SAVE RO
5681 CLR SUP2
5682 MOV 4(SP), RO
5683 BR SUP1
5684
5685 SUPRS: MOV RO, -(SP) ;SAVE RO
5686 MOV 4(SP), RO ;PICKUP THE POINTER
5687 MOV RO, SUP2 ;SAVE FOR TYPING
5688
5689 SUP1:
5690 1$: TSTB (RO) ;TERMINATOR?
5691 BEQ 2$ ;BR IF YES
5692 CMPB #'0, (RO) ;IS THIS AN ASCII "0"?
5693 BNE 4$ ;NO
5694 MOVB #'40, (RO)+ ;REPLACE IT WITH "BLANK"
5695 BR 1$
5696 2$: DEC RO ;BACKUP BY 1
5697 MOVB #'0, (RO) ;ASCII "0"
5698 4$: TST SUP2 ;LEFT JUSTIFY?
5699 BNE 5$ ;NO
5700 MOV RO, SUP2 ;YES
5701 5$: TYPE ;GO TYPE
5702 SUP2: .WORD 0
5703 MOV (SP)+, RO ;RESTORE RO
5704 MOV (SP)+, (SP) ;RESTORE THE STACK
RTS PC ;RETURN
    
```

.SBTTL INTEGER MULTIPLY ROUTINE

```

5705
5706
5707
5708
5709
5710
5711
5712
5713
5714
5715
5716
5717
5718
5719 025103
5720 025100 010046
5721 025102 010146
5722 025104 010246
5723 025106 005046
5724 025110 016601 000012
5725 025114 100002
5726 025116 005216
5727 025120 005401
5728 025122 016602 000014
5729 025126 100002
5730 025130 005316
5731 025132 005402
5732 025134 012746 000021
5733 025140 005000
5734 025142 103001
5735 025144 060200
5736 025146 006000
5737 025150 006001
5738 025152 005316
5739 025154 001372
5740 025156 022616
5741 025160 001403
5742 025162 005400
5743 025164 005401
5744 025166 005600
5745 025170 005726
5746 025172 010066 000012
5747 025176 010166 000010
5748 025202 012602
5749 025204 012601
5750 025206 012600
5751 025210 000207

*****
*CALL
*   MOV     MULTIPLIER, -(SP)
*   MOV     MULTIPLICAND, -(SP)
*   JSR     PC, @#SMULT
*   RETURN  ;; PRODUCT IS ON THE STACK
*
*   STACK  PRODUCT
*   -----
*   TOP    LSB'S
*   +2     MSB'S
*
$MULT:
MOV     R0, -(SP)           ;; PUSH R0 ON STACK
MOV     R1, -(SP)           ;; PUSH R1 ON STACK
MOV     R2, -(SP)           ;; PUSH R2 ON STACK
CLR     -(SP)               ;; CLEAR THE SIGN KEY
MOV     12(SP), R1          ;; GET THE MULTIPLICAND
BPL     1$                  ;; BR IF PLUS
INC     (SP)                ;; SET THE SIGN KEY
NEG     R1                  ;; MAKE THE MULTIPLICAND POSTIVE
MOV     14(SP), R2          ;; GET THE MULTIPLIER
BPL     2$                  ;; BR IF PLUS
DEC     (SP)                ;; UPDATE THE SIGN KEY
NEG     R2                  ;; MAKE THE MULTIPLIER POSTIVE
MOV     #17., -(SP)         ;; SET THE LOOP COUNT
CLR     R0                  ;; SETUP FOR THE MULTIPLY LOOP
BCC     4$                  ;; DON'T ADD IF MULTIPLICAND = 0
ADD     R2, R0
ROR     R0                  ;; POSITION THE PARITIAL PRODUCT AND
ROR     R1                  ;; THE MULTIPLICAND
DEC     (SP)                ;; HAS ALL BITS OF THE MULTIPLICAND BEEN DONE?
BNE     3$                  ;; BR IF NO
CMP     (SP)+, (SP)         ;; SHOULD PRODUCT BE NEGATIVE?
BEQ     5$                  ;; GO TO EXIT IF NO
NEG     R0                  ;; YES--SO MAKE IT SO
NEG     R1
R0
SBC     R0
5$:  TST     (SP)+           ;; CLEAR SIGN INFO. OFF OF STACK
MOV     R0, 12(SP)          ;; PUT THE PRODUCT ON THE STACK (MSB'S)
MOV     R1, 10(SP)          ;; LSB'S
MOV     (SP)+, R2           ;; POP STACK INTO R2
MOV     (SP)+, R1           ;; POP STACK INTO R1
MOV     (SP)+, R0           ;; POP STACK INTO R0
RTS     PC

```



```

5752 .SBTTL INTEGER DIVIDE ROUTINE
5753
5754 :*CALL:
5755 :* MOV LOW DIVIDEND,-(SP) ;THE HIGH DIVIDEND MUST BE 1/2
5756 :* MOV HIGH DIVIDEND,-(SP) ; AS LARGE AS THE DIVISOR
5757 :* MOV DIVISOR,-(SP)
5758 :* JSR PC,$DIV
5759 :* RETURN ;QUOTIENT & REMAINDER ARE ON THE STACK
5760 :* "V"=0 IMPLIES NO ERROR
5761 :* "V"=1 IMPLIES ERROR OCCURRED
5762 :* "C"=0 DIVIDE OVERFLOW OCCURRED
5763 :* "C"=1 ATTEMPTED TO DIVIDE BY ZERO
5764
5765
5766 :* STACK NO ERROR OVERFLOW DIVIDE BY ZERO
5767 :* -----
5768 :* TOP REMAINDER ALL ZEROS ALL ONES
5769 :* +2 QUOTIENT ALL ZEROS ALL ONES
5770
5771 025212 013746 000034 $DIV: MOV 34,-(SP) ;SAVE CURRENT TRAP VECTOR
5772 025216 012737 025226 000034 MOV #1$,34 ;SET UP TRAP VECTOR
5773 025224 104400 TRAP
5774 025226 012716 025250 1$: MOV #2$, (SP) ;REPLACE NEW PC
5775 025232 016637 000004 000034 MOV 4(SP),34 ;RESTORE OLD TRAP VECT
5776 025240 016666 000002 000004 MOV 2(SP),4(SP) ;SAVE PSW
5777 025246 000002 RTI ;RESTORE PSW
5778
5779 025250 042716 000017 2$: BIC #17,(SP) ;STRIP AWAY CONDITION CODES
5780 025254 010046 MOV R0,-(SP) ;PUSH R0 ON STACK
5781 025256 010146 MOV R1,-(SP) ;PUSH R1 ON STACK
5782 025260 010246 MOV R2,-(SP) ;PUSH R2 ON STACK
5783 025262 010346 MOV R3,-(SP) ;PUSH R3 ON STACK
5784 025264 005046 CLR -(SP) ;SAVE A PLACE FOR SIGNS
5785 025266 012746 000021 MOV #17,-(SP) ;SETUP THE ITERATION COUNTER
5786 025272 016601 000024 MOV 24(SP),R1 ;PICKUP THE DIVIDEND
5787 025276 016600 000022 MOV 22(SP),R0
5788 025302 100005 BPL 3$ ;CHECK THE SIGN
5789 025304 105366 000003 DECB 3(SP) ;KEEP TRACK OF THE SIGN
5790 025310 005400 NEG R0 ;AND NEGATE THE ORIGINAL
5791 025312 005401 NEG R1 ;NUMBER
5792 025314 005600 SBC R0
5793 025316 016602 000020 3$: MOV 20(SP),R2 ;PICKUP THE DIVISOR
5794 025322 022702 000001 CMP #1,R2 ;IF THE DIVISOR IS 1 SKIP THE REST
5795 025326 001463 BEQ 13$ ;YES
5796 025330 005702 TST R2
5797 025332 002407 BLT 4$ ;CHECK THE SIGN
5798 025334 003011 BGT 5$ ;DIVISOR OF 0 IS A NO-NO
5799 025336 052766 000003 000014 BIS #3,14(SP) ;SET "V" & "C"
5800 025344 012700 177777 MOV #-1,R0 ;SET REMAINDER TO ALL ONES
5801 025350 000424 BR 9$ ;EXIT
5802 025352 005266 000002 4$: INC 2(SP) ;KEEP TRACK OF DIVISORS SIGN
5803 025356 000401 BR 6$
5804 025360 005402 5$: NEG R2 ;NEGATE THE ORIGINAL NUMBER
5805 025362 000241 6$: CLC ;CLEAR "C"
5806 025364 000405 BR 8$ ;START FORMING QUOTIENT
5807 025366 006100 7$: RCL R0 ;POSITION MSB'S
    
```

5808	025370	010003		MOV	R0,R3	: COPY
5809	025372	060203		ADD	R2,R3	: COMPARE DIVIDEND & DIVISOR
5810	025374	103001		BCC	8\$: BR IF DIVIDEND > DIVISOR
5811	025376	010300		MOV	R3,R0	: REMAINDER AFTER THIS LOOP
5812	025400	006101	8\$:	ROL	R1	: QUOTIENT BIT ENTERS HERE
5813	025402	005316		DEC	(SP)	: DONE?
5814	025404	001370		BNE	7\$: BR IF NO
5815	025406	005701		TST	R1	: OVERFLOW?
5816	025410	100005		BPL	10\$: BR IF NO
5817	025412	052766	000002 000014	BIS	#2,14(SP)	: SET "V" IN RETURN STATUS WORD
5818	025420	005000		CLR	R0	: SET REMAINDER TO ALL ZEROS
5819	025422	010001	9\$:	MOV	R0,R1	: COPY REMAINDER INTO QUOTIENT
5820	025424	005726	10\$:	TST	(SP)+	: CLEAR COUNTER FROM STACK
5821	025426	005716		TST	(SP)	: REMAINDER SIGN CORRECTION NEEDED?
5822	025430	002004		BGE	11\$: BR IF NO
5823	025432	005400		NEG	R0	: NEGATE REMAINDER
5824	025434	105066	000001	CLRB	1(SP)	: CLEAR SIGN
5825	025440	005316		DEC	(SP)	: BUT DON'T FORGET QUOTIENT
5826	025442	005726		TST	(SP)+	: QUOTIENT SIGN CORRECTION NEEDED?
5827	025444	001401		BEQ	12\$: BR IF NO
5828	025446	005401		NEG	R1	: NEGATE QUOTIENT
5829	025450	010166	000020	MOV	R1,20(SP)	: RETURN QUOTIENT AND
5830	025454	010066	000016	MOV	R0,16(SP)	: REMAINDER TO USER
5831	025460	012603		MOV	(SP)+,R3	: POP STACK INTO R3
5832	025462	012602		MOV	(SP)+,R2	: POP STACK INTO R2
5833	025464	012601		MOV	(SP)+,R1	: POP STACK INTO R1
5834	025466	012600		MOV	(SP)+,R0	: POP STACK INTO R0
5835	025470	012666	000002	MOV	(SP)+,2(SP)	: SETUP TO RETURN CONDITION CODES
5836	025474	000002		RTI		: RETURN
5837	025476	022626	13\$:	CMP	(SP)+,(SP)+	: POP THE STACK
5838	025500	000763		BR	12\$	

5839
5840
5841
5842
5843
5844
5845
5846
5847
5848
5849
5850
5851
5852
5853
5854
5855
5856
5857
5858
5859
5860
5861
5862
5863
5864
5865
5866
5867
5868
5869
5870
5871
5872
5873
5874
5875
5876
5877
5878
5879
5880
5881
5882
5883

.SBTTL SAVE AND RESTORE RO-R5 ROUTINES

```
*****  
*SAVE RO-R5  
*CALL:  
* SAVREG  
*UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:  
*  
*TOP---(+16)  
* +2---(+18)  
* +4---R5  
* +6---R4  
* +8---R3  
*+10---R2  
*+12---R1  
*+14---R0
```

\$SAVREG:

```
MOV R0,-(SP) ;: PUSH R0 ON STACK  
MOV R1,-(SP) ;: PUSH R1 ON STACK  
MOV R2,-(SP) ;: PUSH R2 ON STACK  
MOV R3,-(SP) ;: PUSH R3 ON STACK  
MOV R4,-(SP) ;: PUSH R4 ON STACK  
MOV R5,-(SP) ;: PUSH R5 ON STACK  
MOV 22(SP),-(SP) ;: SAVE PS OF MAIN FLOW  
MOV 22(SP),-(SP) ;: SAVE PC OF MAIN FLOW  
MOV 22(SP),-(SP) ;: SAVE PS OF CALL  
MOV 22(SP),-(SP) ;: SAVE PC OF CALL  
RTI
```

```
*RESTORE RO-R5  
*CALL:  
* RESREG
```

\$RESREG:

```
MOV (SP)+,22(SP) ;: RESTORE PC OF CALL  
MOV (SP)+,22(SP) ;: RESTORE PS OF CALL  
MOV (SP)+,22(SP) ;: RESTORE PC OF MAIN FLOW  
MOV (SP)+,22(SP) ;: RESTORE PS OF MAIN FLOW  
MOV (SP)+,R5 ;: POP STACK INTO R5  
MOV (SP)+,R4 ;: POP STACK INTO R4  
MOV (SP)+,R3 ;: POP STACK INTO R3  
MOV (SP)+,R2 ;: POP STACK INTO R2  
MOV (SP)+,R1 ;: POP STACK INTO R1  
MOV (SP)+,R0 ;: POP STACK INTO R0  
RTI
```

025502
025502 010046
025504 010146
025506 010246
025510 010346
025512 010446
025514 010546
025516 016646 000022
025522 016646 000022
025526 016646 000022
025532 016646 000022
025536 000002

025540
025540 012666 000022
025544 012666 000022
025550 012666 000022
025554 012666 000022
025560 012605
025562 012604
025564 012603
025566 012602
025570 012601
025572 012600
025574 000002

5884				.SBTTL	RANDOM NUMBER GENERATOR ROUTINE	
5885				*CALL:		
5886				*	JSR PC,\$RAND	;CALL THE ROUTINE
5887				*	RETURN	;RETURN HERE THE RANDOM
5888				*		;NUMBER WILL BE IN
5889				*		;\$HINUM,\$LONUM
5890	025576			\$RAND:		
5891	025576	010046			MOV RO,-(SP)	;PUSH RO ON STACK
5892	025600	010146			MOV R1,-(SP)	;PUSH R1 ON STACK
5893	025602	010246			MOV R2,-(SP)	;PUSH R2 ON STACK
5894	025604	010346			MOV R3,-(SP)	;PUSH R3 ON STACK
5895	025606	010446			MOV R4,-(SP)	;PUSH R4 ON STACK
5896	025610	017604	000012		MOV @12(SP),R4	;GET POINTER TO THE SAVED SEEDS
5897						;FOR GENERATING THIS RANDOM NUMBER
5898	025614	011400			MOV (R4),RO	;GET LO NUMBER SEED
5899	025616	016401	000002		MOV 2(R4),R1	;GET HIGH NUMBER SEED
5900	025622	012703	177771		MOV #-7,R3	;SET SHIFT COUNT
5901	025626	005002			CLR R2	;ZERO R2
5902	025630	006300		1\$:	ASL RO	;SHIFT RO LEFT AND
5903	025632	006101			ROL R1	;ROTATE CARRY INTO R1 AND
5904	025634	006102			ROL R2	;ROTATE CARRY INTO R2
5905	025636	005203			INC R3	;CHECK FOR DONE
5906	025640	001373			BNE 1\$;CONTINUE SHIFT LOOP
5907	025642	061400			ADD (R4),RO	;ADD NUMBER TO MAKE X 129
5908	025644	005501			ADC R1	;PROPOGATE CARRY
5909	025646	066401	000002		ADD 2(R4),R1	;ADD NUMBER TO MAKE X 129
5910	025652	005502			ADC R2	;PROPOGATE CARRY
5911	025654	062700	001057		ADD #1057,RO	;ADD LOW CONSTANT
5912	025660	005501			ADC R1	;PROPOGATE CARRY
5913	025662	005502			ADC R2	;PROPOGATE CARRY
5914	025664	062701	047401		ADD #47401,R1	;ADD HIGH CONSTANT
5915	025670	005502			ADC R2	;PROPOGATE CARRY
5916	025672	062702	000006		ADD #6,R2	;ADD HIGHEST CONSTART
5917	025676	060200			ADD R2,RO	;REPRIME RO WITH HIGHEST DIGIT
5918	025700	005501			ADC R1	;PROPOGATE CARRY
5919	025702	010014			MOV RO,(R4)	;SAVE RO-\$LONUM (FOR USE NXT TIME)
5920	025704	010164	000002		MOV R1,2(R4)	;SAVE R1-\$HINUM (FOR USE NXT TIME)
5921	025710	012604			MOV (SP)+,R4	
5922	025712	012603			MOV (SP)+,R3	;POP STACK INTO R3
5923	025714	012602			MOV (SP)+,R2	;POP STACK INTO R2
5924	025716	012601			MOV (SP)+,R1	;POP STACK INTO R1
5925	025720	012600			MOV (SP)+,RO	;POP STACK INTO RO
5926	025722	062716	000002		ADD #2,(SP)	;ADJUST SP FOR CORRECT RETURN
5927	025726	000207			RTS PC	;RETURN
5928	025730	123456		RSDRVL:	123456	;RANDOM SEED FOR DRIVE SELECTION (LO)
5929	025732	176543		RSDRVH:	176543	; " " (HI)
5930	025734	001201		RSFUNL:	1201	;RANDOM SEED FOR FUNCTION
5931	025736	062465		RSFUNH:	62465	; " " (HI)
5932	025740	176105		RSCYLL:	176105	;RANDOM SEED FOR CYLINDER (LO)
5933	025742	174532		RSCYLH:	174532	; " " (HI)
5934	025744	157650		RSBAL:	157650	;RANDOM SEED FOR BUS ADDRESS (LO)
5935	025746	030753		RSBAH:	30753	; " " (HI)
5936	025750	131547		RSWCL:	131547	;RANDOM SEED FOR WORD COUNT (LO)
5937	025752	032070		RSWCH:	32070	; " " (HI)
5938	025754	123456		RSDTL:	123456	;RANDOM SEED FOR DATA (LO)
5939	025756	176543		RSDTH:	176543	; " " (HI)

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

5940
5941
5942
5943
5944
5945
5946
5947
5948
5949
5950
5951
5952
5953
5954
5955
5956
5957
5958
5959
5960
5961
5962
5963
5964
5965
5966
5967
5968
5969
5970
5971
5972
5973
5974
5975
5976
5977
5978
5979
5980
5981
5982
5983
5984
5985
5986
5987
5988
5989
5990
5991
5992
5993
5994
5995

```

*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
*OCTAL (ASCII) NUMBER AND TYPE IT.
*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBEP OF DIGITS TO TYPE
*CALL:
*   MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOS   ;;CALL FOR TYPEOUT
*   .BYTE  N              ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*   .BYTE  M              ;;M=1 OR 0
*                               ;;1=TYPE LEADING ZEROS
*                               ;;0=SUPPRESS LEADING ZEROS
*$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*$TYPOS OR $TYPOC
*CALL:
*   MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPON   ;;CALL FOR TYPEOUT
*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
*CALL:
*   MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOC   ;;CALL FOR TYPEOUT
5965 025760 017646 000000 $TYPOS: MOV     2(SP),-(SP)      ;; PICKUP THE MODE
5966 025764 116637 000001 026203 MOV     1(SP),$OFILL    ;; LOAD ZERO FILL SWITCH
5967 025772 112637 026205 MOV     (SP)+,$OMODE+1  ;; NUMBER OF DIGITS TO TYPE
5968 025776 062716 000002 ADD     #2,(SP)        ;; ADJUST RETURN ADDRESS
5969 026002 000406 BR      $TYPON
5970 026004 112737 000001 026203 $TYPOC: MOV     #1,$OFILL    ;; SET THE ZERO FILL SWITCH
5971 026012 112737 000006 026205 MOV     #6,$OMODE+1    ;; SET FOR SIX(6) DIGITS
5972 026020 112737 000005 026202 $TYPON: MOV     #5,$OCNT  ;; SET THE ITERATION COUNT
5973 026026 010346 MOV     R3,-(SP)      ;; SAVE R3
5974 026030 010446 MOV     R4,-(SP)      ;; SAVE R4
5975 026032 010546 MOV     R5,-(SP)      ;; SAVE R5
5976 026034 113704 026205 MOV     $OMODE+1,R4   ;; GET THE NUMBER OF DIGITS TO TYPE
5977 026040 005404 NEG     R4
5978 026042 062704 000006 ADD     #6,R4          ;; SUBTRACT IT FOR MAX. ALLOWED
5979 026046 110437 026204 MOV     R4,$OMODE    ;; SAVE IT FOR USE
5980 026052 113704 026203 MOV     $OFILL,R4    ;; GET THE ZERO FILL SWITCH
5981 026056 016605 000012 MOV     12(SP),R5    ;; PICKUP THE INPUT NUMBER
5982 026062 005003 CLR     R3           ;; CLEAR THE OUTPUT WORD
5983 026064 006105 1$: ROL    R5           ;; ROTATE MSB INTO "C"
5984 026066 000404 BR      3$
5985 026070 006105 2$: ROL    R5           ;; GO DO MSB
5986 026072 006105 ROL    R5           ;; FORM THIS DIGIT
5987 026074 006105 ROL    R5
5988 026076 010503 MCV    R5,R3
5989 026100 006103 3$: ROL    R3           ;; GET LSB OF THIS DIGIT
5990 026102 105337 026204 DECB   $OMODE        ;; TYPE THIS DIGIT?
5991 026106 100016 BPL    7$           ;; BR IF NO
5992 026110 042703 177770 BIC    #177770,R3   ;; GET RID OF JUNK
5993 026114 001002 BNE    4$           ;; TEST FOR 0
5994 026116 005704 TST    R4           ;; SUPPRESS THIS 0?
5995 026120 001403 BEG    5$           ;; BR IF YES

```

5996	026122	005204		4\$:	INC	R4	:: DON'T SUPPRESS ANYMORE 0'S
5997	026124	052703	000060		BIS	#'0,R3	:: MAKE THIS DIGIT ASCII
5998	026130	052703	000040	5\$:	BIS	#',R3	:: MAKE ASCII IF NOT ALREADY
5999	026134	110337	026200		MOVB	R3,9\$:: SAVE FOR TYPING
6000	026140	104401	026200		TYPE	8\$:: GO TYPE THIS DIGIT
6001	026144	105337	026202	7\$:	DECB	\$OCNT	:: COUNT BY 1
6002	026150	003347			BGT	2\$:: BR IF MORE TO DO
6003	026152	002402			BLT	6\$:: BR IF DONE
6004	026154	005204			INC	R4	:: INSURE LAST DIGIT ISN'T A BLANK
6005	026156	000744			BR	2\$:: GO DO THE LAST DIGIT
6006	026160	012605		6\$:	MOV	(SP)+,R5	:: RESTORE R5
6007	026162	012604			MOV	(SP)+,R4	:: RESTORE R4
6008	026164	012603			MOV	(SP)+,R3	:: RESTORE R3
6009	026166	016666	000002 000004		MOV	2(SP),4(SP)	:: SET THE STACK FOR RETURNING
6010	026174	012616			MOV	(SP)+,(SP)	
6011	026176	000002			RTI		:: RETURN
6012	026200	000		8\$:	.BYTE	0	:: STORAGE FOR ASCII DIGIT
6013	026201	000			.BYTE	0	:: TERMINATOR FOR TYPE ROUTINE
6014	026202	000		\$OCNT:	.BYTE	0	:: OCTAL DIGIT COUNTER
6015	026203	000		\$OFILL:	.BYTE	0	:: ZERO FILL SWITCH
6016	026204	000000		\$OMODE:	.WORD	0	:: NUMBER OF DIGITS TO TYPE
6017							

111

```

6018 .SBTTL ERROR HANDLER ROUTINE
6019
6020 ;*SW15=1 HALT ON ERROR
6021 ;*SW13=1 INHIBIT ERROR TYPEOUTS
6022 ;*SW12=1 TYPE OUT THE ERROR HISTORY, THE FUNCTION THAT
6023 WAS BEING PERFORMED ON RK AT THE TIME OF ERROR AND
6024 THE FUNCTION PERFORMED PRIOR TO THAT.
6025 ;*NOTE THIS SWITCH OPTION (12) IS MEANINGFUL ONLY FOR ERRORS OCCURING IN THE
6026 ;*EXERCISER PART OF THE PROGRAM.
6027 ;*SW11=1 DUMP OUT ALL RK REGISTERS
6028 ;*SW10=1 BELL ON ERROR
6029 ;*SW09=1 LOOP ON ERROR
6030 ;*SW03=1 TYPE OUT TIME AT WHICH ERROR OCCURED
6031 ;*SW02=1 DROP THE DRIVE AFTER MAXM ERORS ON THIS DRIVE
6032 ;*SW01=1 TYPE OUT THE SERIAL NUMBER OF THE ERRORING DRIVE
6033 ;*GO TO $ERRTYP ON ERROR
6034
6035
6036 $ERROR: CKSWR ;LOOK FOR A 'CONTROL G'
6037 INCB $ERFLG ;SET THE ERROR FLAG
6038 BEQ $ERROR ;DON'T LET THE FLAG GO TO ZERO
6039 MOV $STNM, @DISPLAY ;DISPLAY TEST NUMBER AND ERROR FLAG
6040 BIT #SW10, @SWR ;BELL ON ERROR?
6041 BEQ 1$ ;NO - SKIP
6042 TYPE $BELL ;RING BELL
6043 INC $ERTTL ;COUNT THE NUMBER OF ERRORS
6044
6045 BIT #SW2, @SWR ;COUNT # OF ERORS & DROP DRVE?
6046 BEQ 3$ ;NO
6047 ;YES
6048 MOV R1, -(SP) ;SAVE R1
6049 MOV SRDRV, R1 ;GET ERRORING DRIVE #
6050 BMI 2$ ;IF (SRDRV)= -1, SKIP (BECAUSE THE
6051 ;EROR WAS NOT ATTRIBUTABLE TO ANY
6052 ;SPECIFIC DRIVE)
6053 INCB ERDRV(R1) ;COUNT # OF ERORS ON THIS DRIVE
6054 CMPB ERDRV(R1), #3 ;# OF ERORS GREATER THAN ALLOWABLE?
6055 BLOS 2$ ;NO
6056 JMP DSELCT ;DROP THE DRIVE
6057
6058 2$: MOV (SP)+, R1 ;RESTORE R1
6059
6060 3$: MOV (SP), $ERRPC ;GET ADDRESS OF ERROR INSTRUCTION
6061 SUB #2, $ERRPC
6062 CLR -(SP)
6063 MOVB @ERRPC, (SP) ;STRIP AND SAVE THE ERROR ITEM CODE
6064 CMPB (SP), #100 ;FORM THE COMSECT ITEM# IF THIS IS AN
6065 BLT 4$ ;EROR MESSAGE EQUAL OR ABOVE 100.
6066 SUB #40, (SP) ;NOTE THERE R 2 CLASSES OF ERRORS:
6067 ;1) $ITEMB'S BELOW 100
6068 ;2) $ITEMB'S ABOVE 100
6069 ;SUBTRACTION FACTOR HAS TOBE SUCH THAT
6070 ;THE COMSECT OFFSET IS SELECTED. THIS
6071 ;FACTOR WILL CHANGE IF THE TOTAL # OF
6072 ;ERROR MESSAGES IN CLASS 1 CHANGES.
6073 ;#=100 -LAST ITEM IN # CLASS 1 - 1

```

```

6074 026340 012637 001114 4$: MOV (SP)+,$ITEMB
6075 026344 032777 020000 152566 BIT #SW13,$SWR ;SKIP TYPEOUT IF SET
6076 026352 001012 BNE $$ ;SKIP TYPEOUTS
6077 026354 004737 026472 JSR PC,$SERRTYP ;GO TO USER ERROR ROUTINE
6078 026360 104401 001213 TYPE ,$CRLF
6079
6080 026364 032777 010000 152546 BIT #SW12,$SWR ;TYPE ERROR HISTORY?
6081 026372 001402 BEQ $$ ;NO
6082 026374 004737 020426 JSR PC,HISTRY ;YES
6083
6084 026400 023737 000042 000046 5$: CMP $#42,$#46 ;ACT11 AUTOMATIC MODE?
6085 026406 001403 BEQ .+10 ;YES, HALT ON ERROR
6086 026410 005777 152524 TST $SWR ;HALT ON ERROR
6087 026414 100002 BPL $$ ;SKIP IF CONTINUE
6088 026416 000000 HALT ;HALT ON ERROR!
6089 026420 104407 CKSWR ;LOOK FOR A 'CONTROL G'
6090 026422 032777 001000 152510 6$: BIT #SW09,$SWR ;LOOP ON ERROR SWITCH SET?
6091 026430 001411 BEQ 7$ ;BR IF NO
6092 026432 123727 001114 000040 CMPB $ITEMB,$#40 ;THERE R 37 ERROR MESSAGES IN CLASS 1
6093 026440 103011 BHIS 8$
6094 026442 013746 001244 MOV PPRLVL,-(SP) ;LOCK OUT ALL INTERUPTS ON RETURN
6095 ;FROM THIS EROR HANDLER, IF THE EROR
6096 ;IS IN EXERCISER & LOOPING IS TO
6097 ;BE DONE
6098 026446 005726 TST (SP)+
6099 026450 012716 015726 MOV #EXCRLUP,(SP) ;IF THIS ERROR CALL WAS FROM EXERCISER
6100 ;PART OF THE PROGRAM, GO TO 'EXCRLUP'
6101 ;OTHERWISE RETURN THRU '$LUPERR'
6102
6103 026454 012737 177777 001250 7$: MOV #-1,$RDRV ;RESET SERIAL NO FLAG
6104 ;IF ($RDRV)=-1, THEN THE SERIAL
6105 ;NO OF THE DRIVE WILL NOT BE
6106 ;TYPED OUT.
6107 ;OTHERWISE, SERIAL NO FOR THE DRIVE
6108 ;# IN '$RDRV' WILL BE TYPED.
6109 026462 000002 RTI
6110 026464 013716 001110 8$: MOV $LPERR,(SP) ;FUDGE RETURN FOR LOOPING
6111 026470 000771 BR 7$ ;RETURN

```


SBTTL ERROR MESSAGE TYPEOUT ROUTINE

;*THIS ROUTINE USES THE "ITEM CONTROL BYTE" (\$ITEMB) TO DETERMINE WHICH
 ;*ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" (\$ERRTB,
 ;*AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.

6112									
6113									
6114									
6115									
6116									
6117									
6118									
6119	026472	104401	001213						
6120	026476	010046							
6121	026500	005000							
6122	026502	153700	001114						
6123	026506	001004							
6124	026510	013746	001116						
6125	026514	104402							
6126	026516	000425							
6127	026520	005300		15:					
6128	026522	006300							
6129	026524	006300							
6130	026526	006300							
6131	026530	062700	002666						
6132	026534	012037	026544						
6133	026540	001404							
6134	026542	104401							
6135	026544	000000		25:					
6136	026546	104401	001213	35:					
6137	026552	032777	004000	45:	152360				
6138	026560	001404							
6139	026562	004737	027032						
6140	026566	104401	001213						
6141									
6142	026572	012037	026602	55:					
6143	026576	001404							
6144	026600	104401							
6145	026602	000000		65:					
6146	026604	104401	001213						
6147	026610	011000		75:					
6148	026612	001406							
6149									
6150									
6151	026614	013046		85:					
6152	026616	104402							
6153	026620	104401	002663						
6154	026624	005710							
6155	026626	001372							
6156									
6157	026630	012600		95:					
6158	026632	104401	001213						
6159	026636	123727	001114		000040				
6160									
6161	026644	103004							
6162	026646	004737	026660						
6163	026652	004737	026766						
6164									
6165	026656	000207		105:					

```

6166          :TIMTYP
6167          :THIS ROUTINE TYPES THE TIME IN HOURS:MIN:SECS IF SW 3 IS SET
6168          :SW 3 SHOULD NOT BE SET IF KWILL IS NOT PRESENT.
6169
6170 026660 032777 000010 152252 TIMTYP: BIT      #SW2, @SWR      ; IS SW 3 SET?
6171 026666 001434          BEQ      4$          ; IF NOT SKIP TYPING TIME
6172 026670 104401 002652          TYPE     ,MSG29        ; 'TIME'
6173 026674 104401 002662          TYPE     ,BLNKS3
6174 026700 104414          SAVREG
6175 026702 012700 001552          MOV      #KWHR, R0      ; SAVE R0-R4
6176 026706 012001          MOV      (R0)+, R1      ; INITIALIZE POINTER
6177 026710 000404          BR       2$
6178 026712 012001          1$: MOV     (R0)+, R1      ; TYPE OUT
6179 026714 001402          BEQ      2$
6180 026716 062701 000074          ADD      #60, R1
6181 026722 010137 026762          2$: MOV     R1, 5$
6182 026726 012746 026762          MOV     #5$, -(SP)      ; HOURS:MINS:SECS
6183 026732 004737 024604          JSR     PC, @#SDB20     ; CONVERT TO ASCIZ STRING
6184 026736 004737 025000          JSR     PC, @#SUPRSL    ; GO TYPE
6185 026742 020027 001560          CMP     R0, #KWSEC+2    ; ALL DONE?
6186 026746 001403          BEQ     3$
6187 026750 104401 002334          TYPE     ,MSG18
6188 026754 000756          BR       1$
6189 026756 104415          3$: RESREG
6190 026760 000207          4$: RTS     PC          ; RESTORE R0-R4
6191 026762 000000 000000          5$: .WORD  0,0         ; RETURN
    
```

```

6192          :SNOTYP
6193          :THIS ROUTINE TYPES OUT THE SERIAL NUMBER OF THE ERRORING DRIVE, IF SW 1
6194          :IS SET. NOTE THAT THE SERIAL NUMBER IS TYPED OUT ONLY WHEN THE DRIVE
6195          :CAN BE IDENTIFIED POSITIVELY, AS THE ONE WHICH GAVE THE ERROR. IF THE
6196          :ERROR CANNOT BE ATTRIBUTED TO ANY SPECIFIC DRIVE (SRDRV)=-1, THEN
6197          :THE SERIAL NUMBER IS NOT TYPED OUT.
6198
6199 026766 032777 000002 152144 SNOTYP: BIT      #SW1,2SWR      ;TYPE OUT SERIAL #?
6200 026774 001415          BEQ      2$          ;NO
6201 026776 010146          MOV      R1,-(SP)     ;SAVE R1
6202 027000 013701 001250  MOV      SRDRV,R1    ;GET ERRORING DRIVE #
6203 027004 006301          ASL      R1          ;IF (SRDRV)=-1, SKIP (BECAUSE
6204 027006 100407          BMI      1$          ;THE ERROR WAS NOT ATTRIBUTABLE
6205                                     ;TO A SPECIFIC DRIVE)
6206 027010 104401 001213          TYPE     ,SCRLF      ;
6207 027014 104401 002326          TYPE     ,MSG17     ;TYPE "SR. NO:"
6208 027020 016146 001266          MOV      SRNO(R1),-(SP) ;GET THE SERIAL #
6209 027024 104405          TYPDS                    ;TYPE IT OUT (DECIMAL)
6210
6211 027026 012601          1$: MOV      (SP)+,R1    ;RESTORE R1
6212 027030 000207          2$: RTS      PC      ;RETURN
6213
6214
6215
6216          :DMPREG
6217          :THIS ROUTINE DUMPS OUT ALL RK11 REGISTERS WHEN SW 11 IS SET AND AN ERROR OCCURS.
6218
6219          DMPREG:
6220 027032 104401 027040          TYPE     65$      ;;TYPE ASCIZ STRING
6221 027036 000441          BR      64$      ;;GET OVER THE ASCIZ
6222          ;;65$: .ASCIZ <15><12>/ PC      RKDS      RKER      RKCS      RKWC      RKBA      RKCA      RKDB
6223          64$:
6224 027142 013746 001116          MOV      $ERRPC,-(SP)
6225 027146 104402          TYPOC
6226 027150 104401 002663          TYPE     ,BLNKS2
6227 027154 010046          MOV      R0,-(SP)
6228 027156 012700 001216          MOV      #RKDS,R0
6229 027162 013046          1$: MOV      @R0+,-(SP)
6230 027164 104402          TYPOC
6231 027166 104401 002663          TYPE     ,BLNKS2
6232 027172 020027 001232          CMP      R0,#RKDB
6233 027176 003771          BLE     1$
6234 027200 012600          MOV      (SP)+,R0
6235 027202 000207          RTS      PC
    
```

6236
6237
6238
6239
6240
6241
6242
6243
6244
6245
6246
6247
6248
6249
6250
6251
6252
6253
6254
6255
6256
6257
6258
6259
6260
6261
6262
6263
6264
6265
6266
6267
6268
6269
6270
6271
6272
6273
6274
6275
6276
6277
6278

027204
027204 104407
027206 032777 040000 151724
027214 001047
027216 000416
027220 013746 000004
027224 012737 027244 000004
027232 005737 177060
027236 012637 000004
027242 000421
027244 022626
027246 012637 000004
027252 000407
027254
027254 105737 001102
027260 001412
027262 032777 001000 151650
027270 001404
027272 013737 001110 001106
027300 000415
027302 105037 001103
027306 105237 001102
027312 011637 001106
027316 011637 001110
027322 005037 001204
027326 112737 000001 001115
027334 013777 001102 151600
027342 013716 001106
02734E 000002

.SBTTL SCOPE HANDLER ROUTINE

```

*****
*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
*AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY'7:0).
*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY'15:08)
*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
*SW14=1 LOOP ON TEST
*SW09=1 LOOP ON ERROR
*CALL
* SCOPE ;;SCOPE=IOT

SSCOPE:
CKSWR
BIT #BIT14,@SWR ;:TEST FOR CHANGE IN SOFT-SWR
BNE $OVER ;:LOOP ON PRESENT TEST?
;:YES IF SW14=1
*****START OF CODE FOR THE XOR TESTER*****
$XTSTR: BR 6$
;:IF RUNNING ON THE "XOR" TESTER CHANGE
;:THIS INSTRUCTION TO A "NOP" (NOP=24C,
;:SAVE THE CONTENTS OF THE ERROR VECTOR
;:SET FOR TIMEOUT
;:TIME OUT ON XOR?
;:RESTORE THE ERROR VECTOR
;:GO TO THE NEXT TEST
5$: CMP (SP)+,(SP)+ ;:CLEAR THE STACK AFTER A TIME OUT
MOV (SP)+,@ERRVEC ;:RESTORE THE ERROR VECTOR
BR 7$ ;:LOOP ON THE PRESENT TEST
6$;*****END OF CODE FOR THE XOR TESTER*****
2$: TSTB $ERFLG ;:HAS AN ERROR OCCURRED?
BEQ $SVLAD ;:BR IF NO
BIT #BIT09,@SWR ;:LOOP ON ERROR?
BEQ 4$ ;:BR IF NO
7$: MOV $LPERR,$LPADR ;:SET LOOP ADDRESS TO LAST SCOPE
BR $OVER
4$: CLRB $ERFLG ;:ZERO THE ERROR FLAG
$SVLAD: INCB $TSTNM ;:COUNT TEST NUMBERS
MOV (SP),$LPADR ;:SAVE SCOPE LOOP ADDRESS
MOV (SP),$LPERR ;:SAVE ERROR LOOP ADDRESS
CLR $ESCAPE ;:CLEAR THE ESCAPE FROM ERROR ADDRESS
MOVB #1,$ERMAX ;:ONLY ALLOW ONE(1) ERROR ON NEXT TEST
$OVER: MOV $TSTNM,@DISPLAY ;:DISPLAY TEST NUMBER
MOV $LPADR,(SP) ;:FUDGE RETURN ADDRESS
RTI ;:FIXES PS
    
```

FILE

6279
6280
6281
6282
6283
6284
6285
6286
6287 027350 010046
6288 027352 016600 000002
6289 027356 005740
6290 027360 111000
6291 027362 006300
6292 027364 016000 027404
6293 027370 000200
6294
6295
6296
6297
6298 027372 011646
6299 027374 016666 000004 000002
6300 027402 000002
6301
6302
6303
6304
6305
6306
6307
6308
6309 027404 027372
6310 027406 024244
6311 027410 026004
6312 027412 025760
6313 027414 026020
6314 027416 024020
6315
6316 027420 023034
6317
6318 027422 022764
6319 027424 023246
6320 027426 023366
6321 027430 023540
6322 027432 023642
6323 027434 025502
6324 027436 025540
6325 027440 022356
6326 027442 022364
6327 027444 022244
6328 027446 022522
6329

.SBTTL TRAP DECODER

```

;*****
;*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
;*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
;*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
;*GO TO THAT ROUTINE.

```

```

$TRAP:  MOV    RO, -(SP)          ;; SAVE RO
        MOV    2(SP), RO        ;; GET TRAP ADDRESS
        TST   -(RO)            ;; BACKUP BY 2
        MOVB  (RO), RO         ;; GET RIGHT BYTE OF TRAP
        ASL   RO                ;; POSITION FOR INDEXING
        MOV   $TRPAD(RO), RO    ;; INDEX TO TABLE
        RTS   RO                ;; GO TO ROUTINE

```

;; THIS IS USE TO HANDLE THE "GETPRI" MACRO

```

$TRAP2: MOV   (SP), -(SP)      ;; MOVE THE PC DOWN
        MOV   4(SP), 2(SP)    ;; MOVE THE PSW DOWN
        RTI                          ;; RESTORE THE PSW

```

.SBTTL TRAP TABLE

```

;*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
;*BY THE "TRAP" INSTRUCTION.

```

	ROUTINE
\$TRPAD: .WORD	\$TRAP2
\$TYPE	;; CALL=TYPE TRAP+1(104401) TTY TYPEOUT ROUTINE
\$TYPOC	;; CALL=TYPOC TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
\$TYPOS	;; CALL=TYPOS TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
\$TYPON	;; CALL=TYPON TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
\$TYPDS	;; CALL=TYPDS TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)
\$GTSWR	;; CALL=GTSWR TRAP+6(104406) GET SOFT-SWR SETTING
\$CKSWR	;; CALL=CKSWR TRAP+7(104407) TEST FOR CHANGE IN SOFT-SWR
\$RDCHR	;; CALL=RDCHR TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
\$RDLIN	;; CALL=RDLIN TRAP+11(104411) TTY TYPEIN STRING ROUTINE
\$RDOCT	;; CALL=RDOCT TRAP+12(104412) READ AN OCTAL NUMBER FROM TTY
\$RDDEC	;; CALL=RDDEC TRAP+13(104413) READ A DECIMAL NUMBER FROM TTY
\$SAVREG	;; CALL=SAVREG TRAP+14(104414) SAVE RO-RS ROUTINE
\$RESREG	;; CALL=RESREG TRAP+15(104415) RESTORE RO-RS ROUTINE
CN.RST	;; CALL=CN.RESET TRAP+16(104416) CONTROL RESET ROUTINE
CN.RDY	;; CALL=CN.RDY TRAP+17(104417) WAIT FOR CONTROL READY
DR.RST	;; CALL=DRV.RESET TRAP+20(104420) DRIVE RESET ROUTINE
TY.MSG	;; CALL=TYPMSG TRAP+21(104421) TYPE MESSAGE ROUTINE. SW13

.SBTTL POWER DOWN AND UP ROUTINES

```

6330
6331
6332
6333
6334 027450 012737 027614 000024 $PWRDN: MOV $SILLUP,@PWRVEC ;;SET FOR FAST UP
6335 027456 012737 000340 000026 MOV @340,@PWRVEC+2 ;;PRIO:7
6336 027464 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
6337 027466 010146 MOV R1,-(JP) ;;PUSH R1 ON STACK
6338 027470 010246 MOV R2,-(SP) ;;PUSH R2 ON STACK
6339 027472 010346 MOV R3,-(SP) ;;PUSH R3 ON STACK
6340 027474 010446 MOV R4,-(SP) ;;PUSH R4 ON STACK
6341 027476 010546 MOV R5,-(SP) ;;PUSH R5 ON STACK
6342 027500 017746 151434 MOV @SWR,-(SP) ;;PUSH @SWR ON STACK
6343 027504 010637 027620 MOV SP,$SAVR6 ;;SAVE SP
6344 027510 012737 027522 000024 MOV $PWRUP,@PWRVEC ;;SET UP VECTOR
6345 027516 000000 HALT
6346 027520 000776 BR -2 ;;HANG UP
6347
6348
6349
6350 027522 012737 027614 000024 $PWRUP: MOV $SILLUP,@PWRVEC ;;SET FOR FAST DOWN
6351 027530 013706 027620 MOV $SAVR6,SP ;;GET SP
6352 027534 005037 027620 CLR $SAVR6 ;;WAIT LOOP FOR THE TTY
6353 027540 005237 027620 IS: INC $SAVR6 ;;WAIT FOR THE INC
6354 027544 001375 BNE IS ;;OF WORD
6355 027546 012677 151366 MOV (SP)+,@SWR ;;POP STACK INTO @SWR
6356 027552 012605 MOV (SP)+,R5 ;;POP STACK INTO R5
6357 027554 012604 MOV (SP)+,R4 ;;POP STACK INTO R4
6358 027556 012603 MOV (SP)+,R3 ;;POP STACK INTO R3
6359 027560 012602 MOV (SP)+,R2 ;;POP STACK INTO R2
6360 027562 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
6361 027564 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
6362 027566 012737 027450 000024 MOV $PWRDN,@PWRVEC ;;SET UP THE POWER DOWN VECTOR
6363 027574 012737 000340 000026 MOV @340,@PWRVEC+2 ;;PRIO:7
6364 027602 104401 TYPE ;;REPORT THE POWER FAILURE
6365 027604 027622 $PWRMG: .WORD $POWER ;;POWER FAIL MESSAGE POINTER
6366 027606 012716 MOV (PC)+,(SP) ;;RESTART AT PFSTR
6367 027610 003366 $PWRAD: .WORD PFSTR ;;RESTART ADDRESS
6368 027612 000002 RTI
6369 027614 000000 $ILLUP: HALT ;;THE POWER UP SEQUENCE WAS STARTED
6370 027616 000776 BR -2 ;;BEFORE THE POWER DOWN WAS COMPLETE
6371 027620 000000 $SAVR6: 0 ;;PUT THE SP HERE
6372 027622 005015 047520 042527 $POWER: .ASCIZ '<15><12>"POWER"'
6373 027630 000122 .EVEN
6374
    
```

FILE

:ERROR MESSAGES

6375						
6376						
6377	027632	051105	051117	047440	EM1:	.ASCIZ /EROR ON WRITE/
6378	027640	020116	051127	052111		
6379	027646	000105				
6380	027650	052101	046505	052120	EM2:	.ASCIZ /ATEMPT TO INITIATE FUNCTION ON 'BUSY' DRIVE/
6381	027656	052040	020117	047111		
6382	027664	052111	040511	042524		
6383	027672	043040	047125	052103		
6384	027700	047511	020116	047117		
6385	027706	023440	052502	054523		
6386	027714	020047	051104	042526		
6387	027722	000				
6388	027723	103	052116	047522	EM3:	.ASCIZ /CNTROL RDY NOT SET/
6389	027730	020114	042122	020131		
6390	027736	047516	020124	042523		
6391	027744	000124				
6392	027746	051057	053457	051457	EM4:	.ASCIZ "/R/W/S RDY NOT SET"
6393	027754	051040	054504	047040		
6394	027762	052117	051440	052105		
6395	027770	000				
6396	027771	103	052116	047522	EM5:	.ASCIZ /CNTROL RDY NOT SET AFTER 1ST INTRUPT ON ISSUING SEEK/
6397	027776	020114	042122	020131		
6398	030004	047516	020124	042523		
6399	030012	020124	043101	042524		
6400	030020	020122	051461	020124		
6401	030026	047111	051124	050125		
6402	030034	020124	047117	044440		
6403	030042	051523	044525	043516		
6404	030050	051440	042505	000113		
6405	030056	051127	047117	020107	EM6:	.ASCIZ /WRONG BITS IN RKCS. EXPCT SEEK/
6406	030064	044502	051524	044440		
6407	030072	020116	045522	051503		
6408	030100	020054	054105	041520		
6409	030106	020124	042523	045505		
6410	030114	000				
6411	030115	047	052502	054523	EM7:	.ASCIZ /'BUSY' FLAG CLEAR ON INTRUPTING DRIVE/
6412	030122	020047	046106	043501		
6413	030130	041440	042514	051101		
6414	030136	047440	020116	047111		
6415	030144	051124	050125	044524		
6416	030152	043516	042040	053122		
6417	030160	000105				
6418	030162	050047	051517	052111	EM10:	.ASCIZ /'POSITIONING' FLAG FOR INTRUPTING DRIVE CLEAR/
6419	030170	047511	044516	043516		
6420	030176	020047	046106	043501		
6421	030204	043040	051117	044440		
6422	030212	052116	052522	052120		
6423	030220	047111	020107	051104		
6424	030226	042526	041440	042514		
6425	030234	051101	000			
6426	030237	047	051105	023522	EM11:	.ASCIZ /'ERR'OR SET AFTER 1ST INTERRUPT ON ISSUING SEEK/
6427	030244	051117	051440	052105		
6428	030252	040440	052106	051105		
6429	030260	030440	052123	044440		
6430	030266	052116	051105	052522		

6431	030274	052120	047440	020116		
6432	030302	051511	052523	047111		
6433	030310	020107	042523	045505		
6434	030316	000				
6435	030317	123	050103	051440	EM12:	.ASCIZ /SCP SET AFTER 1ST INTRUPT ON ISSUING SEEK/
6436	030324	052105	040440	052106		
6437	030332	051105	030440	052123		
6438	030340	044440	052116	052522		
6439	030346	052120	047440	020116		
6440	030354	051511	052523	047111		
6441	030362	020107	042523	045505		
6442	030370	000				
6443	030371	103	052116	047522	EM13:	.ASCIZ /CNTROL RDY NOT SET AFTER SEEK DONE INTRUPT/
6444	030376	020114	042122	020131		
6445	030404	047516	020124	042523		
6446	030412	020124	043101	042524		
6447	030420	020122	042523	045505		
6448	030426	042040	047117	020105		
6449	030434	047111	051124	050125		
6450	030442	000124				
6451	030444	047111	051124	050125	EM14:	.ASCIZ /INTRUPTING DRVE (SEEK DONE) WAS NOT 'BUSY' /
6452	030452	044524	043516	042040		
6453	030460	053122	020105	051450		
6454	030466	042505	020113	047504		
6455	030474	042516	020051	040527		
6456	030502	020123	047516	020124		
6457	030510	041047	051525	023531		
6458	030516	000				
6459	030517	122	053457	051457	EM15:	.ASCIZ "R/W/S READY NOT SET FOR INTRUPTING DRVE (SEEK DONE)"
6460	030524	051040	040505	054504		
6461	030532	047040	052117	051440		
6462	030540	052105	043040	051117		
6463	030546	044440	052116	052522		
6464	030554	052120	047111	020107		
6465	030562	051104	042526	024040		
6466	030570	042523	045505	042040		
6467	030576	047117	024505	000		
6468	030603	123	047111	042440	EM16:	.ASCIZ /SIN EROR/
6469	030610	047522	000122			
6470	030614	042447	051122	047447	EM17:	.ASCIZ /'ERR'OR ON DOING SEEK/
6471	030622	020122	047117	042040		
6472	030630	044517	043516	051440		
6473	030636	042505	000113			
6474	030642	041523	020120	044504	EM20:	.ASCIZ /SCP DID NOT SET AFTER SEEK WAS DONE/
6475	030650	020104	047516	020124		
6476	030656	042523	020124	043101		
6477	030664	042524	020122	042523		
6478	030672	045505	053440	051501		
6479	030700	042040	047117	000105		
6480	030706	047523	052106	042440	EM21:	.ASCIZ /SOFT EROR/
6481	030714	047522	000122			
6482	030720	040504	040524	024040	EM23:	.ASCIZ /DATA (COMPARISON) EROR/
6483	030726	047503	050115	051101		
6484	030734	051511	047117	020051		
6485	030742	051105	051117	000		
6486	030747	103	052116	047522	EM24:	.ASCIZ /CNTROL RDY CLR ON INTRUPT AFTER RK FUNCTION

6487	030754	020114	042122	020131		
6488	030762	046103	020122	047117		
6489	030770	044440	052116	052522		
6490	030776	052120	040440	052106		
6491	031004	051105	051040	020113		
6492	031012	052506	041516	044524		
6493	031020	047117	000			
6494	031023	123	052524	045503	EM26:	.ASCIZ /STUCK IN LOOP,8 COMANDS SHLD BE DONE BY NOW/
6495	031030	044440	020116	047514		
6496	031036	050117	034054	041440		
6497	031044	046517	047101	051504		
6498	031052	051440	046110	041104		
6499	031060	020105	047504	042516		
6500	031066	041040	020131	047516		
6501	031074	000127				
6502	031076	052101	050115	020124	EM27:	.ASCIZ /ATMPT TO DO WRITE BEFORE WRT CHK/
6503	031104	047524	042040	020117		
6504	031112	051127	052111	020105		
6505	031120	042502	047506	042522		
6506	031126	053440	052122	041440		
6507	031134	045510	000			
6508	031137	101	046524	052120	EM30:	.ASCIZ /ATMPT TO REEXECUTE COMMAND-IN PROGRESS OR ALREADY FINISHED/
6509	031144	052040	020117	042522		
6510	031152	054105	041505	052125		
6511	031160	020105	047503	046515		
6512	031166	047101	026504	047111		
6513	031174	050040	047522	051107		
6514	031202	051505	020123	051117		
6515	031210	040440	051114	040505		
6516	031216	054504	043040	047111		
6517	031224	051511	042510	000104		
6518	031232	043047	047125	052103	EM31:	.ASCIZ /'FUNCTION IN PROGRES' FLG FOR INTRUPTING DRIVE ISN'T SET/
6519	031240	047511	020116	047111		
6520	031246	050040	047522	051107		
6521	031254	051505	020047	046106		
6522	031262	020107	047506	020122		
6523	031270	047111	051124	050125		
6524	031276	044524	043516	042040		
6525	031304	044522	042526	044440		
6526	031312	047123	052047	051440		
6527	031320	052105	000			
6528	031323	125	042516	050130	EM32:	.ASCIZ /UNEXPCTED DRIVE INTRUPTED/
6529	031330	052103	042105	042040		
6530	031336	044522	042526	044440		
6531	031344	052116	052522	052120		
6532	031352	042105	000			
6533	031355	125	042516	050130	EM33:	.ASCIZ /UNEXPCTD FUNCTION CODE IN RKCS AFTER INTRUPT/
6534	031362	052103	020104	052506		
6535	031370	041516	044524	047117		
6536	031376	041440	042117	020105		
6537	031404	047111	051040	041513		
6538	031412	020123	043101	042524		
6539	031420	020122	047111	051124		
6540	031426	050125	000124			
6541	031432	051104	042526	051040	EM34:	.ASCIZ /DRVE RDY CLEAR/
6542	031440	054504	041440	042514		

6543	031446	051101	000				
6544	031451	104	053122	020105	EM35:	.ASCIZ	/DRVE POWER LO/
6545	031456	047520	042527	020122			
6546	031464	047514	000				
6547	031467	104	053122	020105	EM36:	.ASCIZ	/DRVE UNSAFE/
6548	031474	047125	040523	042506			
6549	031502	000					
6550	031503	127	051520	051440	EM37:	.ASCIZ	/WPS SET/
6551	031510	052105	000				
6552	031513	111	052116	051105	EM101:	.ASCIZ	/INTERUPT DIDN'T OCUR AFTER WRTE/
6553	031520	050125	020124	044504			
6554	031526	047104	052047	047440			
6555	031534	052503	020122	043101			
6556	031542	042524	020122	051127			
6557	031550	042524	000				
6558	031553	047	051105	023522	EM102:	.ASCIZ	/'ERR'OR SET/
6559	031560	051117	051440	052105			
6560	031566	000					
6561	031567	122	042113	020101	EM103:	.ASCIZ	/RKDA INCRMENTED WRONG/
6562	031574	047111	051103	042515			
6563	031602	052116	042105	053440			
6564	031610	047522	043516	000			
6565	031615	122	041113	020101	EM104:	.ASCIZ	/RKBA INCRMENTED WRONG/
6566	031622	047111	051103	042515			
6567	031630	052116	042105	053440			
6568	031636	047522	043516	000			
6569	031643	122	053513	020103	EM105:	.ASCIZ	/RKWC DIDN'T OVRFLO TO 0/
6570	031650	044504	047104	052047			
6571	031656	047440	051126	046106			
6572	031664	020117	047524	030040			
6573	031672	000					
6574	031673	115	054105	041040	EM106:	.ASCIZ	/MEX BITS WRONG/
6575	031700	052111	020123	051127			
6576	031706	047117	000107				
6577	031712	051127	042524	041440	EM110:	.ASCIZ	/WRTE CHK EROR/
6578	031720	045510	042440	047522			
6579	031726	000122					


```

6636 032342 040504 020040 051040
6637 032350 053513 000103
6638 032354 020040 041520 020040 DH110: .ASCIZ / PC RKCS RKER RKBA RKDA/
6639 032362 020040 051040 041513
6640 032370 020123 020040 051040
6641 032376 042513 020122 020040
6642 032404 051040 041113 020101
6643 032412 020040 051040 042113
6644 032420 000101
6645
6646
6647 .EVEN
6648
6649 032422 001116 001162 001164 DT1: .WORD $ERRPC,$REG0,$REG1,$REG2,$REG3,0
6650 032430 001166 001170 000000
6651
6652 032436 001116 001162 000000 DT2: .WORD $ERRPC,$REG0,0
6653
6654 032444 001116 001162 001164 DT21: .WORD $ERRPC,$REG0,$REG1,$REG2,$REG3,$REG4,$REG5,$REG6,0
6655 032452 001166 001170 001172
6656 032460 001174 001176 000000
6657 032466 001116 001162 001164 DT25: .WORD $ERRPC,$REG0,$REG1,$REG2,$REG3,$REG4,0
6658 032474 001166 001170 001172
6659 032502 000000
6660 032504 001116 001162 001164 DT103: .WORD $ERRPC,$REG0,$REG1,0
6661 032512 000000
6662
6663 ;THIS IS THE DATA BUFFER USED TO WRITE THE RANDOM PATTERNS ON THE
6664 ;DISK AT THE BEGINING. 400 (OCTAL) WORDS ARE WRITTEN AT A TIME, THUS
6665 ;THIS BUFFER IS 400/8 WORDS LONG.
6666
6667 032514 DBUF:
6668 032514 000240 PGEND: NOP
6669 000001 .END

```

ABORT 001672
ABRT 012046
ABRT1 012060
BAMAP 001530
BASEBA 002052
BCTST 005352
BEGEX1 010612
BEGNEX 010630
BIT0 = 000001
BIT00 = 000001
BIT01 = 000002
BIT02 = 000004
BIT03 = 000010
BIT04 = 000020
BIT05 = 000040
BIT06 = 000100
BIT07 = 000200
BIT08 = 000400
BIT09 = 001000
BIT1 = 000002
BIT10 = 002000
BIT11 = 004000
BIT12 = 010000
BIT13 = 020000
BIT14 = 040000
BIT15 = 100000
BIT2 = 000004
BIT3 = 000010
BIT4 = 000020
BIT5 = 000040
BIT6 = 000100
BIT7 = 000200
BIT8 = 000400
BIT9 = 001000
BLNKS1 002664
BLNKS2 002663
BLNKS3 002662
BPTVEC= 000014
BUSY 001426
CBSY 021474
CHDPRS 022656
CHFAFN 011154
CHKBA 020150
CHKCRD 020272
CHKCS 020112
CHKDA 020126
CHKDRV 016540
CHKMEX 020204
CHKRWS 020254
CHKWC 020230
CH1 011210
CH2 011310
CICNT 001466

CICNT1 001470
CRSWR = 104407
CLEANB 006434
CLRERR 016006
CLRFLG 015770
CLRSIN 016152
CMNABT 014216
CMND 001326
CMNERR 014160
CNOBSY 021712
CN.RDY 022364
CN.RST 022356
COMRET 020306
CON.RD= 104417
CON.RE= 104416
CR = 000015
CRCMND 020340
CRLF = 000200
CROTLF 022170
CSE = 000002
CSECN 001652
CYLMAP 001522
DATCHK 017110
DATER 001712
DBUF 032514
DDISP = 177570
DH1 031730
DH103 032265
DH105 032327
DH110 032354
DH2 031776
DH21 032013
DH23 032110
DH25 032155
DH27 032232
DH30 032313
DISPLA 001142
DISPRE 000174
DMPREG 027032
DORAD 006424
DOWRIT 006304
DOXFER 006312
DPL = 010000
DRCMND 020314
DRMAP 001520
DRU = 002000
DRVABT 014426
DRVCNT 001500
DRVPRS 001264
DRVPTR 001476
DRV.RE= 104420
DRY = 000200
DR.RST 022244

DSELECT 016312
DSWR = 177570
DT1 032422
DT103 032504
DT2 032436
DT21 032444
DT25 032466
ECOUNT 001540
EMTVEC= 000030
EM1 027632
EM10 030162
EM101 031513
EM102 031553
EM103 031567
EM104 031615
EM105 031643
EM106 031673
EM11 030237
EM110 031712
EM12 030317
EM13 030371
EM14 030444
EM15 030517
EM16 030603
EM17 030614
EM2 027650
EM20 030642
EM21 030706
EM23 030720
EM24 030747
EM26 031023
EM27 031076
EM3 027723
EM30 031137
EM31 031232
EM32 031323
EM33 031355
EM34 031432
EM35 031451
EM36 031467
EM37 031503
EM4 027746
EM5 027771
EM6 030056
EM7 030115
ERCODE 001474
ERDRV 001542
ERINF1 005720
ERR = 100000
ERRVEC= 000004
EXCLU 015726
EXCUT 011612
EXNSK 011470

EXRCSB 007772
FNCRND 020372
FNMAP 001526
FRSTRT 001253
FTITLE 001252
GENBUF 016704
GEN1 014724
GENBRQ 014500
GETINF 022064
GTSORV 022226
GTSWR = 104406
GT3RG 022040
GT4RG 022032
HE = 040000
HECN 001562
HISTRY 020426
HRDERR 014016
HT = 000011
INTFLG 001534
INTHND 013256
INTIFL 001535
INTISK 012376
IOTVEC= 000020
KDPAR0= 172360
KDPAR1= 172362
KDPAR2= 172364
KDPAR3= 172366
KDPAR4= 172370
KDPAR5= 172372
KDPAR6= 172374
KDPAR7= 172376
KDPDR0= 172320
KDPDR1= 172322
KDPDR2= 172324
KDPDR3= 172326
KDPDR4= 172330
KDPDR5= 172332
KDPDR6= 172334
KDPDR7= 172336
KEY 001306
KIPAR0= 172340
KIPAR1= 172342
KIPAR2= 172344
KIPAR3= 172346
KIPAR4= 172350
KIPAR5= 172352
KIPAR6= 172354
KIPAR7= 172356
KIPDR0= 172300
KIPDR1= 172302
KIPDR2= 172304
KIPDR3= 172306
KIPDR4= 172310

KIPDR5= 172312
KIPDR6= 172314
KIPDR7= 172316
KWCOUN 001560
KWHR 001552
KWLS 001234
KWLVEC= 000100
KWMIN 001554
KWPLVL 001246
KWSEC 001556
KWSRVE 022552
LF = 000012
MAXBA 002054
MH1 020746
MH2 020762
MH3 020772
MH4 020775
MMVEC = 000250
MSG1 002062
MSG10 002165
MSG11 002201
MSG12 002206
MSG13 002214
MSG14 002225
MSG15 002245
MSG16 002305
MSG17 002326
MSG18 002334
MSG19 002336
MSG2 002070
MSG20 002362
MSG24 002372
MSG25 002375
MSG26 002377
MSG26A 002474
MSG27 002532
MSG28 002604
MSG29 002652
MSG3 002076
MSG4 002104
MSG5 002120
MSG6 002133
MSG7 002141
MSG8 002146
MSG9 002156
NIEROR 021516
NOEROR 014300
NRDH 001774
NRDL 001772
NWRFNC 011766
NWRTH 001734
NWRTL 001732
NXTDRV 005366

ODDEVN	015724	RG4SDR	022222	ST3	005322	TYPMSG=	104421	\$GDOAT	001124
PCMND	002032	RKBA	001226	ST4	004752	TYPOC =	104402	\$GET42	022740
PCNTR	001236	RKCS	001222	SUPRS	025014	TYPON =	104404	\$GTSWR	023034
PDR	001254	RKDA	001230	SUPRSL	025000	TYPOS =	104403	\$HO =	000000
PFSTR	003366	RKDB	001232	SUP1	025026	TY.MSG	022522	\$HIOCT	023640
PFTERR	013214	RKDS	001216	SUP2	025070	WATIME	022630	\$ICNT	001104
PGEND	032514	RKER	001220	SWR	001140	WCE =	000001	\$ILLUP	027614
PIRQ =	177772	RKSTAT	001242	SWREG	000176	WCECN	001632	\$INTAG	001135
PIRQVE=	000240	RKVEC	001240	SWO =	000001	WCFLG	001456	\$ITEMB	001114
PORKER	013222	RKWC	001224	SWO0 =	000001	WCMAP	001532	\$KTNEX	017666
POS	001436	RNUM	017106	SWO1 =	000002	WPS =	000040	\$KTOUT	017656
POSCMN	020350	RSBAH	025746	SWO2 =	000004	WRDSK	010266	\$KT11	017524
POSK	012164	RSBAL	025744	SWO3 =	000010	WRFNC	012064	\$LF	001214
POSTIO	011414	RSCYLH	025742	SWO4 =	000020	XFR	007514	\$LPAOR	001106
PPRLVL	001244	RSCYLL	025740	SWO5 =	000040	XFR16K	007504	\$LPERR	001110
PRICMN	011410	RSDRVH	025732	SWO6 =	000100	XXDPMO	002060	\$LSTAD	017770
PRSFNC	001462	RSDRVL	025730	SWO7 =	000200	\$AUTOB	001134	\$LSTBK	017772
PRO =	000000	RSDTH	025756	SWO8 =	000400	\$BDADR	001122	\$MNEW	023527
PR1 =	000040	RSDTL	025754	SWO9 =	001000	\$BDAT	001126	\$MSWR	023516
PR2 =	000100	RSFUNH	025736	SW1 =	000002	\$BELL	001206	\$MUL =	000003
PR3 =	000140	RSFUNL	025734	SW10 =	002000	\$CHARC	024460	\$MULT	025100
PR4 =	000200	RSWCH	025752	SW11 =	004000	\$CKSWR	022764	\$NULL	001154
PR5 =	000240	RSWCL	025750	SW12 =	010000	\$CMTAG	001100	\$NWTST=	000001
PR6 =	000300	RTIPC7	021732	SW13 =	020000	\$CM1 =	000011	\$OCNT	026202
PR7 =	000340	RWS =	000100	SW14 =	040000	\$CM2 =	000022	\$OCTLV	024566
PS =	177776	R6 =	%000006	SW15 =	100000	\$CM3 =	000011	\$OMODE	026204
PSINER	013070	R7 =	%000007	SW2 =	000004	\$CNTLG	023511	\$OVER	027334
PSRTRY	013130	SAVKEY	001536	SW3 =	000010	\$CNTLU	023504	\$PASS	001100
PSTFNC	001464	SAVREG=	104414	SW4 =	000020	\$SCORE	017674	\$POWER	027622
PSW =	177776	SCP =	020000	SW5 =	000040	\$CRLF	001213	\$PWAD	027610
PRVFC=	000024	SECMAP	001524	SW6 =	000100	\$CROUT	017724	\$PWADN	027450
P1	020376	SEXIT	021720	SW7 =	000200	\$DBLK	024234	\$PWARG	027604
P2	020410	SFTERR	013636	SW8 =	000400	\$DB2D	024604	\$PWRLP	027522
QBUSAD	001514	SIN =	001000	SW9 =	001000	\$DB20	024464	\$QUES	001212
QCYL	001504	SINCN	001622	TBITVE=	000014	\$DECVL	024764	\$RAND	025576
QDRV	001502	SINCNT	016264	TIMER	001472	\$DIV	025212	\$ROCHR	023246
QEROR	021610	SKCMP	012704	TIMOUT	022354	\$DOAGN	022760	\$RODEC	023642
QFNC	001512	SKE =	010000	TINTYP	026660	\$DTBL	024224	\$ROLIN	023366
QINGER	010650	SKECN	001602	TKVEC =	000060	\$ENDAD	022750	\$ROCT	023540
QSCNT	001460	SNOTYP	026766	TPVEC =	000064	\$ENDCT	022734	\$RDSZ =	000010
QSEC	001510	SRDRV	001250	TRAPVE=	000034	\$EOP	022704	\$REGAD	001160
QSLR	001506	SRNO	001266	TRTVEC=	000014	\$EOPCT	022726	\$REGO	001162
QARCNT	001516	SRO =	177572	TST1	005414	\$ERFLG	001103	\$REG1	001164
RCNT	017104	SR1 =	177574	TST2	005526	\$ERMAX	001115	\$REG10	001202
ROCHR =	104410	SR2 =	177576	TST3	005772	\$ERROR	026206	\$REG2	001166
RODEC =	104413	SR3 =	172516	TST4	006106	\$ERRPC	001116	\$REG3	001170
ROLIN =	104411	STACK =	001100	TST5	006456	\$ERRTB	002666	\$REG4	001172
ROCT =	104412	START	003376	TST6	007040	\$ERTY	026472	\$REG5	001174
REPCNT	002056	STARTA	003444	TST7	007374	\$ERTTL	001112	\$REG6	001176
REPSTA	021116	STATST	021006	TYPD80	017774	\$ESCAP	001204	\$REG7	001200
RESREG=	104415	STATUS	021436	TYPD5 =	104405	\$FILLC	001156	\$RESRE	025540
RESVEC=	000010	STKLMT=	177774	TYPE =	104401	\$FILLS	001155	\$RTNAD	022762
RETRY	001446	ST2	004400	TYPFN	021736	\$GDADR	001120	\$SAVRE	025502

\$SAVR6	027620	\$SVPC	= 000220	\$TPB	001152	\$TSTNM	001102	\$TYPON	026020
\$SCOPE	027204	\$SWR	= 143000	\$TPFLG	001157	\$TTYIN	023474	\$TYPOS	025760
\$SETUP=	000115	\$SWRMK=	000000	\$TPS	001150	\$TYPDS	024020	\$XTSTR	027216
\$SIZE	017466	\$TKB	001146	\$TRAP	027350	\$TYPE	024244	\$GET4=	000000
\$SIZEX	017730	\$TKS	001144	\$TRAP2	027372	\$TYPEC	024414	\$OFILL	026203
\$STUP =	177777	\$TN	= 000010	\$TRP	= 000022	\$TYPEX	024462	.	= 032516
\$SVLAD	027306	\$TNPWR	024714	\$TRPAD	027404	\$TYPOC	026004		

. ABS. 032516 000

ERRORS DETECTED: 0

DSKZ:DZRKHG/SOL=DSKZ:SYSMAC.SML,DSKM:DZRKHG.P11
RUN-TIME: 15 22 .6 SECONDS
RUN-TIME RATIO: 609/38=15.6
CORE USED: 36k (71 PAGES)