

RP11E

MULTI-DRIVE EXERCISER
MD-11-DZRP1-B

EP-DZRP1-B-DL-A
COPYRIGHT © 1976
FICHE 1 OF 1

NOV 1976
digital
MADE IN U.S.A.

This image displays a grid of 128 small plots, arranged in 8 rows and 16 columns. Each plot contains a different visualization, likely representing data from a multi-drive exerciser. The visualizations include:

- Waveforms and signal traces.
- Tables of data points.
- Bar charts and histograms.
- Scatter plots.
- Diagrams and flowcharts.

The plots are arranged in a regular grid on a dark background. The overall appearance is that of a technical manual or a data analysis report.

DO1

NO-11-DZRP1-B, RPIIE MULTI-DRIVE EXERCISER PROGRAM
DZRP1B.CMB

MACY11 27(732) 01-NOV-76 15:32 PAGE 4

101

E01

102
103
104
105
106
107
108

8. PROGRAM DESCRIPTION

- 8.1 PROGRAM OPERATION
- 8.2 SELECTION OF OPERATIONAL VARIABLES
- 8.3 DATA PATTERNS

9. PROGRAM LISTING

109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164

1. ABSTRACT

THE RP11E MULTI-DRIVE EXERCISER PROGRAM EXERCISES 1 TO 8 RPO2, RPRO2, OR RPO3 DISK DRIVES ATTACHED TO THE SAME RP11E. IF 2 OR MORE DISK DRIVES ARE BEING EXERCISED, OPERATIONS ON THE DRIVES ARE OVERLAPPED (OTHER DRIVES ARE PERFORMING SEEK OPERATIONS WHILE ONE DRIVE IS PERFORMING A DATA TRANSFER OR WRITE CHECK OPERATION). OPERATIONS AMONG THE DRIVES ARE OPTIMIZED SO THAT A HIGH SUBSYSTEM DATA TRANSFER RATE OR A HIGH DRIVE POSITIONING RATE CAN BE MAINTAINED.

THE PERFORMANCE OF EACH DISK DRIVE IS MONITORED BY THE PROGRAM. IF A DRIVE EXCEEDS A PRESET NUMBER OF ERRORS, THE DRIVE IS AUTOMATICALLY DEASSIGNED. (THE OPERATOR HAS THE OPTION OF OVERRIDING THE AUTOMATIC DEASSIGNMENT FEATURE.) THE PROGRAM REPORTS PERFORMANCE DATA FOR EACH DRIVE BEING EXERCISED ON REQUEST FROM THE OPERATOR OR AUTOMATICALLY AT AN INTERVAL DETERMINED BY THE OPERATOR AT PROGRAM STARTUP.

ALL DATA TRANSFER COMMANDS ARE USED (I.E., READ & WRITES WITH AND WITHOUT IMPLIED SEEKS) AS WELL AS WRITE CHECK COMMANDS.

THE DATA TRANSFER COMMANDS ARE SELECTED RANDOMLY EXCEPT FOR THE WRITE CHECK COMMAND. THE WRITE CHECK COMMAND IS USED TO VERIFY A PREVIOUS WRITE OPERATION.

PROGRAM/OPERATOR COMMUNICATIONS ARE THROUGH THE TELETYPE; PROGRAM OPTIONS ARE SELECTED BY SWITCH REGISTER SETTINGS.

ALL COMMANDS, DATA PATTERN, AND DATA BUFFER SIZES ARE SELECTED RANDOMLY BY THE PROGRAM. ADDITIONALLY THE ADDRESSES (EG, CYLINDER, TRACK, AND SECTOR) FOR EACH OPERATION ARE SELECTED RANDOMLY.

2. REQUIREMENTS

2.1 EQUIPMENT

REQUIRED

PDP-11 PROCESSOR (WITH OR WITHOUT HARDWARE SWITCH REGISTER)
8K MEMORY
TELETYPE
PROGRAM LOADING DEVICE
KW11-L OR KW11-P CLOCK
RP11E WITH 1 RPO2-RPRO2 OR 1 RPO3

OPTIONAL

4K TO 20K ADDITIONAL MEMORY
1 TO 7 ADDITIONAL RPO2'S-RPRO2'S OR RPO3'S ON THE SAME RP11E

165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218

2.2 MEDIA

THE RP11E MULTI-DRIVE EXERCISER PROGRAM REQUIRES FORMATTED DISK PACKS WHICH CONTAIN RANDOM OR PATTERNED DATA RECOGNIZED BY THE EXERCISER. DISK PACKS USED BY THE PROGRAM MAY BE GENERATED BY THE RP11E FORMATTER PROGRAM (MAINDEC-11-DZRP2) OR BY THE 'W' COMMAND OF THE RP11E MULTI-DRIVE EXERCISER (SEE SECTION 4.4).

2.3 PRELIMINARY PROGRAMS

MAINDEC-11-DZRPW - RP11E DISKLESS CONTROLLER TEST
MAINDEC-11-DZRPY - RP11E FUNCTIONAL LOGIC AND READ/WRITE TEST
MAINDEC-11-DZRPZ - RP11E DRIVE POSITIONING TEST
MAINDEC-11-DZRP2 - RP11E DRIVE FORMATTER PROGRAM

3. OPERATING THE PROGRAM

3.1 *** BEFORE STARTING REFER TO SECTION 4.2 ***
THE PROGRAM MAY BE LOADED WITH THE ABSOLUTE PAPER TAPE LOADER OR IT MAY BE LOADED FROM THE APPROPRIATE MEDIA USING THE ASSOCIATED 'XXDP' LOADER. IF THE PROGRAM IS BEING RUN ON A PROCESSOR WITH 8K OF MEMORY, THE PROGRAM WILL NOT PRESERVE THE 'XXDP' LOADER; THE 'ABS' LOADER (OR THE 'ABS' LOADER SECTION OF THE 'XXDP' LOADER) WILL BE PRESERVED, HOWEVER.

THE 'XXDP' LOADER IS NOT PRESERVED IN AN 8K PROCESSOR BECAUSE OF THE MEMORY REQUIREMENTS OF THE 'XXDP' LOADER; THE PROGRAM USES THE 'XXDP' LOADER SPACE FOR BUFFER SPACE ON THE 8K PROCESSOR.

THE PROGRAM MAY BE INCLUDED IN AN 'XXDP' CHAIN IF THE PROCESSOR TO RUN THE CHAIN IS 12K OR GREATER.

3.2 THE NORMAL STARTING LOCATION FOR THE PROGRAM IS 200(8). PARAMETERS MAY BE CHANGED BY STARTING THE PROGRAM AT LOCATION 204(8).

3.3 THE PROGRAM MAY BE RESTARTED FROM EITHER LOCATION 200(8) OR OR LOCATION 204 (8).

3.4 SET THE 'FORMAT' AND 'MAINTENANCE' SWITCHES ON THE RP11E TO 'NORMAL'; SET THE CONTROLLER WRITE LOCKOUT AND DRIVE WRITE ENABLE SWITCHES AS REQUIRED.

ONCE THE PROGRAM IS LOADED AND STARTED, OPERATIONS ARE INITIATED AND CONTROLLED BY KEYBOARD COMMANDS AND SWITCH REGISTER SWITCH SETTINGS.

IF THE PROGRAM IS BEING RUN AS PART OF AN 'XXDP' CHAIN, THE 'T' COMMAND IS NOT REQUIRED TO START THE TEST; THE PROGRAM WILL AUTOMATICALLY INITIATE A 'TA' COMMAND. IF THE 'XXDP' CHAIN IS BEING LOADED FROM AN RPO2, RPRO2, OR RPO3, DRIVE 0 WILL BE BYPASSED WHEN THE 'TA' COMMAND IS ISSUED. NOTE THAT OPERATOR INTERVENTION IS NOT REQUIRED.

219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274

3.5 PASS/TEST TERMINATION

3.5.1 PASS TERMINATION

END OF PASS MAY BE DETERMINED BY EITHER OF THE FOLLOWING CONDITIONS.
THE END OF PASS CONDITION USED IS DETERMINED BY PARAMETER 'SEKMOD'.

- A. IF PARAMETER 'SEKMOD' IS 0, END OF PASS OCCURS WHEN THE DRIVE HAS READ 6.25×10^{18} WORDS (1×10^{10} BITS).
- B. IF PARAMETER 'SEKMOD' IS 1, END OF PASS OCCURS WHEN THE DRIVE HAS PERFORMED 1×10^{16} SEEKS.

3.5.2 TEST TERMINATION

THE TEST FOR A DRIVE IS TERMINATED (SW<04> = 0) WHEN:

- A. THE DRIVE HAS COMPLETED THE NUMBER OF PASSES SPECIFIED IN PARAMETER 'PASCNT'.
- B. THE TOTAL ERRORS ACCUMULATED EXCEED 100.
- C. A FATAL ERROR OCCURS.

3.6 RUN TIME

THE EXERCISER PROGRAM MAY BE RUN IN TWO MODES. THE MODE IS DETERMINED BY THE VALUE IN PARAMETER 'BUFRSZ'. IF 'BUFRSZ' IS '1' SECTOR, THE PROGRAM RUNS IN A SEEK HEAVY MODE; IF 'BUFRSZ' APPROACHES ONE TRACK IN SIZE (5000 OCTAL) THE PROGRAM RUNS IN A DATA TRANSFER HEAVY MODE. THE PROGRAM RUN TIME VARIES GREATLY DEPENDING ON THE OPERATION MODE SELECTED, THE MEMORY AVAILABLE OVER BK, THE READ/WRITE RATIO PARAMETER - 'RATIO', AND BY SWITCHES 0 & 1.

3.6.1 RUN TIME IN 'DATA TRANSFER MODE'

14 HOURS FOR 1 DRIVE.

(ADD 4 HOURS FOR EACH ADDITIONAL DRIVE TESTED.)

NOTE: IF SW<01> = 1 (NO SOFTWARE DATA COMPARISONS), THE RUN TIMES ARE THE FOLLOWING VALUES, APPROXIMATELY:

12 HOURS FOR 1 DRIVE

(ADD 3 HOURS FOR EACH ADDITIONAL DRIVE TESTED.)

3.6.2 RUN TIME IN 'SEEK VERIFICATION MODE'

ASSUME THE FOLLOWING PARAMETERS VALUES:

PARAMETER 'BUFRSZ' = 1 SECTOR (400(8) WORDS)

PARAMETER 'LT' = 'FT'

PARAMETER 'LS' = 'FS'

SW<00> = 1 (READ ONLY MODE)

17 HOURS FOR 1 DRIVE

I01

MD-11-DZRP1-B, RPIIE MULTI-DRIVE EXERCISER PROGRAM
DZRP1B.CMB

MACY11 27(732) 01-NOV-76 15:32 PAGE 9

275
276

(ADD 8 HOURS FOR EACH ADDITIONAL DRIVE TESTED.)

277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332

3.7 UNIBUS & VECTOR ADDRESSES

THE PROGRAM ASSUMES THE FOLLOWING UNIBUS AND VECTOR ADDRESSES. (REFER TO SECTION 4.2.2 FOR THE LOCATIONS AT WHICH TO CHANGE THESE ADDRESSES.)

<u>UNIT</u>	<u>UNIBUS ADDRESS</u>	<u>VECTOR ADDRESS</u>
RP11E	175710	254
TTY PRINTER	177564	NOT USED
TTY KEYBOARD	177560	60
KW11-L	177546	100
KW11-P	172542	104

3.8 SUBSYSTEMS WITH BOTH RP02-RPR02 AND RP03 DRIVES

RP11E SUBSYSTEMS WITH RP02-RPR02 AND RP03 DISK DRIVES ARE NOT SUPPORTED BY THE MULTI-DRIVE EXERCISER. IF THE PROGRAM IS RUN ON A SYSTEM WITH BOTH DRIVE TYPES, EITHER THE RP02-RPR02 DRIVES OR THE RP03 DRIVES MUST BE POWERED OFF.

4. CONTROLLING THE PROGRAM

4.1 PARAMETERS

WHEN THE PROGRAM IS STARTED FROM LOCATION 200, PRELOADED PARAMETERS WILL BE ASSUMED. IF THE PROGRAM IS STARTED FROM LOCATION 204, THE FOLLOWING MESSAGE WILL BE TYPED.

ENTER PARAMETERS:

THE PROGRAM WILL THEN IDENTIFY THE PARAMETER BY THE NAME GIVEN BELOW, DISPLAY THE CURRENT VALUE OF THE PARAMETER (IN OCTAL) AND THE AND WAIT FOR THE ENTRY.

IF ONLY A CARRIAGE RETURN IS ENTERED, THE PROGRAM WILL USE THE PRESENT VALUE OF THE PARAMETER. THE RUBOUT KEY WILL ALLOW THE OPERATOR TO DELETE AN INCORRECT ENTRY; 'CONTROL U' WILL ALLOW AN ENTIRE ENTRY TO BE DELETED AND REENTERED. THE PROGRAM WILL TYPE A '?' IF AN ALPHABETIC OR INCORRECT NUMBER (FOR THE BASE OF THE PARAMETER) IS ENTERED. IF 'CONTROL C' IS ENTERED, THE PROGRAM WILL RETURN TO THE BEGINNING OF THE PARAMETER LIST. IF A PERIOD IS ENTERED (FOLLOWED BY A CARRIAGE RETURN) EITHER TO TERMINATE AN ENTRY OR IN PLACE OF A PARAMETER CHANGE ENTRY, THE PROGRAM WILL USE THE PRESENT VALUES OF THE REMAINING PARAMETERS AS DEFAULT VALUES.

(NOTE: A PARAMETER ENTRY MUST BE TERMINATED BY A 'CARRIAGE RETURN' OR A 'PERIOD' - 'CARRIAGE RETURN'.)

4.1.1 KEYBOARD ENTRY PARAMETERS

NAME	DEFAULT VALUE	VALUE RANGE	FUNCTION
BUFRSZ	(SEE NOTE)		CONTROLS THE MAXIMUM BUFFER SIZE USED FOR DATA TRANSFERS
PASCNT	1	1 - 1747	NUMBER OF PASSES TO END OF TEST.
INTRVL	5	0 - 377	DETERMINES THE INTERVAL (IN MINUTES) BETWEEN AUTOMATIC PERFORMANCE SUMMARY TYPEOUTS
CPLMT	4	0 - 'BUFRSZ'	THE NUMBER OF DATA COMPARISON ERRORS PRINTED OUT IF SW(02)=0
LC	(SEE NOTE)		THE MAXIMUM CYLINDER ADDRESS
FC	(SEE NOTE)		THE MINIMUM CYLINDER ADDRESS. VALUE MUST NOT BE GREATER THAN VALUE IN 'LC'
LT	23	0 - 23	THE MAXIMUM TRACK ADDRESS
FT	0	0 - 23	THE MINIMUM TRACK ADDRESS
LS	11	0 - 11	THE MAXIMUM SECTOR ADDRESS
FS	0	0 - 11	THE MINIMUM SECTOR ADDRESS
SEKMOD	1	0 OR 1	THE MINIMUM SECTOR ADDRESS MUST NOT BE GREATER THAN THE VALUE IN 'LS'
			IF EQ 0, END OF PASS DETERMINED BY THE 'WORDS READ' COUNT.
			IF EQ 1, END OF PASS IS DETERMINED BY THE NUMBER OF SEEKS.
RPADR	176710	N/A	THE RP11E UNIBUS ADDRESS
RPVEC	254	N/A	THE RP11E VECTOR ADDRESS
RATIO	3	0 - 7	CONTROLS THE APPROXIMATE RATIO OF READ TO WRITE ORDERS.
			VALUE R/W RATIO
			0 15/1
			1 7/1
			2 6/2
			3 5/3
			4 4/4
			5 3/5
			6 2/6
			7 1/7
AUTOCK	1	0 OR 1	IF EQ 1, THE PROGRAM PERFORM WRITE CHECKS AFTER EACH WRITE COMMAND.

334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389

MO1

MD-11-DZRP1-B, RP11E MULTI-DRIVE EXERCISER PROGRAM
DZRP1B.CMB

MACY11 27(732) 01-NOV-76 15:32 PAGE 13

IF EQ 0, THE PROGRAM
WILL PERFORM WRITE CHECKS
RANDOMLY.

390
391
392
393
394

NOTE: THE PROGRAM WILL SELECT A MAXIMUM BUFFER SIZE WHICH IS DETERMINED BY THE MEMORY AVAILABLE. THE MAXIMUM BUFFER SIZE ASSIGNED BY THE PROGRAM IS 5400 (8) WORDS. THE OPERATOR MAY SPECIFY ANY OTHER MAXIMUM SIZE AS LONG AS THE VALUE SPECIFIED IS AT LEAST 4 WORDS BUT NO LARGER THAN THE INITIAL VALUE OF 'BUFRSZ' DETERMINED BY THE PROGRAM.

THE MAXIMUM VALUES FOR 'FC' AND 'LC' ARE THE DETERMINED BY THE DRIVE TYPE BEING TESTED: 202 (10) FOR RPO2'S; 405 (10) FOR RPO3'S; AND 405 (10) FOR SYSTEMS WITH BOTH RPO2'S AND RPO3'S.

4.1.2 PERIPHERAL ADDRESSES AND OTHER LOCATIONS OF INTEREST

TO ALTER THESE LOCATIONS, THE OPERATOR MUST MAKE MANUAL ENTRIES BEFORE THE PROGRAM IS STARTED. THE KEYBOARD ENTRY ROUTINE DOES NOT PROVIDE ACCESS TO THESE LOCATIONS.

LOC	TAG	CONTENTS	FUNCTION
1216	SLKCSR	172540	ADDRESS OF KW11-P STATUS REGISTER
1220	SLKCSB	172542	ADDRESS OF KW11-P COUNTER BUFFER
1222	SLPVEC	104	KW11-P VECTOR ADDRESS
1224	SLKS	177546	ADDRESS OF KW11-L STATUS REGISTER
1226	SLLVEC	100	KW11-L VECTOR ADDRESS
1232	HZ	74	74 (60 DECIMAL) IF SYSTEM IS 60 HZ; 62 (50 DECIMAL) IF SYSTEM IS 50 HZ.

4.2 SWITCH REGISTER SETTINGS

IF THE DIAGNOSTIC IS RUN ON A CPU WITHOUT A SWITCH REGISTER THEN A SOFTWARE SWITCH REGISTER IS USED WHICH ALLOWS THE USER THE SAME SWITCH OPTIONS AS THE HARDWARE SWITCH REGISTER. IF THE HARDWARE SWITCH REGISTER DOES NOT EXIST OR IF ONE DOES AND IT CONTAINS ALL ONES (177777) THEN THE SOFTWARE SWITCH REGISTER (LOC. 176) IS USED.

CONTROL:

THIS PROGRAM ALSO SUPPORTS THE DYNAMIC LOADING OF THE SOFTWARE SWITCH REGISTER (LOC. 176) FROM THE TTY. THIS CAN BE ACCOMPLISHED BY DOING THE FOLLOWING:

- 1) TYPE CONTROL G (<↑G>); THIS WILL ALLOW THE TTY TO ENTER DATA INTO LOC. 176 AT SELECTED POINTS WITHIN THE PROGRAM.
- 2) THE MACHINE WILL THEN TYPE: SWR=XXXXXXNEW= (XXXXXX IS THE OCTAL CONTENTS OF THE SOFTWARE SWITCH REGISTER.)
- 3) AFTER THE "NEW=" HAS BEEN TYPED THEN THE OPERATOR CAN DO ONE OF THE FOLLOWING AT THE TTY:
 - A) TYPE A NUMBER TO BE LOADED INTO LOC. 176 FOLLOWED BY A <CR>. (ONLY NUMBERS BETWEEN 0-7 WILL BE ACCEPTED AND ONLY 5 NUMBERS

395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450

5
5
5
5
5

WILL BE ALLOWED)
IF A <CR> IS THE FIRST KEY DEPRESSED THE SOFTWARE SWITCH
REGISTER CONTENTS WILL NOT BE CHANGED.

B) IF A CONTROL U (<U>) IS DEPRESSED THEN THE PROGRAM WILL SEND YOU
BACK TO STEP 2.

SW <15> = 1	HALT ON ERROR
SW <13> = 1	INHIBIT ERROR TYPEOUT
SW <10> = 1	RING THE TELETYPE BELL IF ERROR
SW <6> = 1	DON'T SYSTEM STATUS WHEN PROGRAM STARTED
	INHIBIT PERFORMANCE SUMMARY TYPEOUTS
SW <5> = 1	LOOP ON PRESENT OPERATION(S)
SW <4> = 1	INHIBIT MAXIMUM ERROR COUNT CHECK; DO NOT DEASSIGN DRIVES WHEN NORMAL END OF TEST REACHED.
SW <3> = 1	DISPLAY SECTOR WHICH GAVE 'HARD' ERROR IF DATA COMPARE ERRORS & SW<2> SET, DISPLAY REST OF BUFFER
SW <2> = 1	DISPLAY ALL DATA COMPARISON ERRORS
SW <1> = 1	INHIBIT DATA COMPARISON AFTER READ ORDERS
SW <0> = 1	READ ONLY MODE

4.3 KEYBOARD COMMANDS

THE KEYBOARD COMMANDS CONTROL THE ASSIGNMENT/DEASSIGNMENT OF DRIVES,
ALLOW THE OPERATOR TO REQUEST DRIVE PERFORMANCE SUMMARIES, AND ALLOW
DATA PACKS TO BE WRITTEN

WHEN THE PROGRAM IS STARTED (OR RESTARTED), KEYBOARD COMMANDS ARE
NOT RECOGNIZED UNTIL THE PROGRAM HAS INITIALIZED ITSELF. THE OPERATOR
MUST WAIT UNTIL THE 'PROGRAM INITIALIZE COMPLETE' MESSAGE IS TYPED
BEFORE ATTEMPTING TO USE THE COMMANDS. AFTER INITIALIZATION HAS BEEN
COMPLETED, THESE COMMANDS MAY BE USED.

IF THE PROGRAM IS BEING RUN AS PART OF AN 'XXDP' PROGRAM CHAIN, OPERATIONS
ARE AUTOMATICALLY STARTED. THE PROGRAM ITSELF SIMULATES THE ISSUING
OF A 'TA' COMMAND.

4.3.1 'T' COMMAND

USED TO ASSIGN A DRIVE(S) FOR TEST

FORMAT: TN<CR>

N = DRIVE NUMBER. MAY BE 0 TO 7 OR 'A'. ENTRY MUST BE
TERMINIATED BY A CARRIAGE RETURN <CR>.

EXAMPLE: T0<CR> - ASSIGN DRIVE 0 FOR TEST
TA<CR> - ASSIGN ALL AVAILABLE DRIVES FOR TEST

NOTE: DRIVE OPERATION BEGINS IMMEDIATELY
AFTER COMMAND IS ENTERED.

4.3.2 'D' COMMAND

USED TO DEASSIGN A DRIVE(S) BEING EXERCISED.

FORMAT: DN<CR>

455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510

002

ND-11-DZRP1-8, RPIIE MULTI-DRIVE EXERCISER PROGRAM
DZRP1B.CMB

MACY11 27(732) 01-NOV-76 15:32 PAGE 17

511
512
513

N = DRIVE NUMBER. MAY BE 0 TO 7 OR 'A'. ENTRY MUST BE
TERMINATED BY A CARRIAGE RETURN <CR>.

EXAMPLE: DD<CR> - DEASSIGN DRIVE 0
DA<CR> - DEASSIGN ALL DRIVES BEING TESTED.

- NOTES:
1. IF THE 'D' COMMAND REFERENCES A DRIVE NOT ASSIGNED, THE PROGRAM WILL TYPEOUT 'DRIVE NOT ASSIGNED'.
 2. THE DRIVES WILL BE DEASSIGNED AS THEIR OPERATION COMPLETE.
 3. IF THE 'DA' COMMAND IS USED, ONLY DRIVES BEING TESTED WILL BE DEASSIGNED - THE ERROR MESSAGE IN (1) ABOVE WILL NOT BE DISPLAYED.

4.3.3 'S' COMMAND

USED TO REQUEST A PERFORMANCE SUMMARY TYPEOUT FOR THE REFERENCED DRIVE(S).

FORMAT: SN<CR>

N = DRIVE NUMBER. MAY BE 0 TO 7 OR 'A'. ENTRY MUST BE TERMINATED BY A CARRIAGE RETURN <CR>.

EXAMPLE: SD<CR> - TYPEOUT PERFORMANCE SUMMARY FOR DRIVE 0
SA<CR> - TYPEOUT PERFORMANCE SUMMARY FOR ALL DRIVES BEING TESTED.

- NOTES:
1. IF 'SA' IS USED ONLY DRIVES BEING TESTED WILL BE DISPLAYED.
 2. IF PARAMETER 'INTRVL' IS NOT ZERO, THE PROGRAM WILL AUTOMATICALLY DISPLAY A PERFORMANCE SUMMARY FOR EACH DRIVE BEING TESTED AT A RATE DETERMINED BY 'INTRVL'.
 3. IF THE 'SA' COMMAND IS USED, THE PROGRAM WILL TYPEOUT THE OPERATOR ENTERED DATE, OPERATOR I.D., AND THE DRIVE I.D. FOR EACH DRIVE BEING TESTED. THE DATE AND OPERATOR I.D. WILL NOT BE TYPED OUT IF NO DRIVES ARE BEING TESTED.

4.3.4 'W' COMMAND

USED TO WRITE A DATA PACK WITH DATA ACCEPTABLE TO THE RP02 MULTI-DRIVE EXERCISER PROGRAM.

FORMAT: WN<CR>

N = DRIVE NUMBER. MAY BE 0 TO 7 OR 'A'. ENTRY MUST BE TERMINATED BY A CARRIAGE RETURN <CR>.

EXAMPLE: WA<CR> - WRITE DATA PACKS ON ALL AVAILABLE DRIVES.
WD<CR> - GENERATE A DATA PACK ON DRIVE 0.

- NOTES:
1. THE 'W' COMMAND SHOULD NOT BE USED UNLESS 'BUFRSZ' PARAMETER IS APPROXIMATELY 1 TRACK IN SIZE - 5000 (10).

14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100

570
571
572
573

IF THE BUFFER SIZE IS MUCH LESS THAN 1 TRACK, THE
TIME REQUIRED TO WRITE A DATA PACK IS TOO GREAT TO
BE PRACTICAL.

574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629

2. THE 'W' COMMAND PERFORMS A SEQUENTIAL WRITE OF THE PACK USING A 'WRITE WITH IMPLIED SEEKS' COMMAND. THE DATA PATTERN USED FOR EACH WRITE IS SELECTED RANDOMLY. THE PACK IS WRITTEN SEQUENTIALLY, BEGINNING AT 'FC', 'FT' AND CONTINUING TO 'LC', 'LT'.
3. THE 'W' COMMAND DOES NOT WRITE HEADERS AND ASSUMES THAT THE FORMAT OF THE PACK IS GOOD.
4. THE 'W' COMMAND CANNOT BE STARTED IF SWITCH 0 (READ ONLY MODE) IS SET. IF SWITCH 0 SET DURING THE OPERATION OF THE 'W' COMMAND, THE DRIVE PERFORMING THE 'W' COMMAND WILL IGNORE THE SWITCH.
5. THE DATA WRITTEN IS VERIFIED BY A 'WRITE CHECK COMMAND' (IF THE PARAMETER 'AUTOCK' IS '1').

4.3.5 'R' COMMAND

USED TO PERFORM A SEQUENTIAL READ OF THE PACK.

FORMAT: RN<CR>

N = DRIVE NUMBER. MAY BE 0 TO 7 OR 'A'. ENTRY MUST BE TERMINATED BY A CARRIAGE RETURN <CR>.

EXAMPLE: RA<CR> - READ THE PACKS ON ALL OF THE ONLINE DRIVES.
RD<CR> - READ THE PACK ON DRIVE 0.

- NOTES:
1. THE PROGRAM WILL PERFORM A NORMAL CHECK OF ALL DATA READ. HOWEVER, ALL OPERATIONS WILL BE SEQUENTIAL.
 2. THE PROGRAM WILL READ THE PACK STARTING AT THE ADDRESS SPECIFIED BY 'FC', 'FT' TO THE ADDRESS SPECIFIED BY 'LC', 'LT'. THE READ WILL BE SEQUENTIAL.

4.3.6 GENERAL COMMAND INFORMATION

- A. WHEN A COMMAND IS ENTERED, THE PROGRAM WILL TYPE OUT THE TIME
- B. IF THE COMMAND ENTERED IS NOT VALID, THE PROGRAM WILL TYPE 'INVALID COMMAND'.
- C. DRIVES ASSIGNED (WITH THE 'T' COMMAND) OR DEASSIGNED (WITH THE 'D' COMMAND) MAY BE ENTERED IN ANY SEQUENCE.
- D. THE ERROR RESPONSES FROM THE PROGRAM ARE AS FOLLOWS

RESPONSE	COMMAND(S)
?DRIVE N OFFLINE	T, W, R
?DRIVE N NOT ASSIGNED	D, S
?DRIVE N ALREADY ASSIGNED	T, W, R

H02

NO-11-DZRP1-B, RPIIE MULTI-DRIVE EXERCISER PROGRAM
DZRP1B.CMB

MACY11 27(732) 01-NOV-76 15:32 PAGE 21

630

?DRIVE N UNSAFE

T, W, R

631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
6865. PERFORMANCE SUMMARY TYPEOUT

5.1 THE PROGRAM WILL DISPLAY A PERFORMANCE SUMMARY FOR THE DRIVES BEING EXERCISED. THIS SUMMARY WILL BE DISPLAYED AUTOMATICALLY IF THE PARAMETER 'INTRVL' IS NOT ZERO OR CAN BE DISPLAYED ON REQUEST BY THE OPERATOR THROUGH THE USE OF THE 'S' COMMAND. THE PERFORMANCE SUMMARY TYPEOUT CONTAINS THE FOLLOWING FIELDS:

'DRV'	THE DRIVE NUMBER
'PASS'	THE PRESENT PASS COUNT FOR THE DRIVE
'ORDERS'	THE NUMBER OF ORDERS PERFORMED BY THE DRIVE
'SEEKS'	THE NUMBER OF SEEK OPERATIONS THE DRIVE PERFORMED
'SOFT'	THE NUMBER OF SOFT DATA ERRORS
'HARD'	THE NUMBER OF HARD DATA ERRORS
'SUSI'	THE NUMBER OF 'SUSI' ERRORS
'MISP'	THE NUMBER OF POSITIONING ERRORS
'OTHER'	THE TOTAL ERRORS OF OTHER TYPES

5.2 SOFT/HARD ERROR DEFINITIONS

5.2.1 HARD ERRORS

'CSME', 'MPE', AND 'LPE' ERRORS WHICH ARE NOT RECOVERABLE AFTER 10 RETRY ATTEMPTS FOLLOWED BY A HOME SEEK AND A RE-SEEK TO THE ERROR CYLINDER AND 10 ADDITIONAL RETRY ATTEMPTS.

5.2.2 SOFT ERRORS

'CSME', 'MPE', OR 'LPE' ERRORS WHICH ARE RECOVERABLE DURING THE 10 RETRY, HOME SEEK, RE-SEEK, 10 RETRY SEQUENCE DESCRIBED ABOVE.

6. DATA CHECKING & ERROR RECOVERY

6.1 DATA COMPARISON

DATA COMPARISON OCCURS AFTER EACH READ ORDER UNDER THE THE FOLLOWING CONDITIONS:

- A. THE ORDER TERMINATED WITH NO ERROR.
- B. THE OPERATION TERMINATED WITH A DATA ERROR BUT READ CORRECTLY CORRECTLY AFTER RETRY ATTEMPTS.

6.2 VERIFICATION OF DATA WRITTEN

AFTER EACH WRITE OPERATION, THE DATA WRITTEN IS CHECKED WITH A WRITE CHECK COMMAND - IF PARAMETER 'AUTOCK' IS '1'.
(IF 'AUTOCK' IS '0', WRITE CHECKS WILL BE PERFORMED RANDOMLY.)

J02

ND-11-DZRP1-8, RPIIE MULTI-DRIVE EXERCISER PROGRAM
DZRP18.CMB

MACY11 27(732) 01-NOV-76 15:32 PAGE 23

687

688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743

7. ERROR MESSAGES

DRIVE ERRORS ARE REPORTED ON THE TELETYPE OR (IF AVAILABLE) A LINE PRINTER. ALL ERROR CONDITIONS ARE REPORTED IN ERROR MESSAGES; THE PROGRAM CONTAINS NO CODED ERROR HALTS. IF THE PROGRAM HALTS (ASSUMING, OF COURSE, THAT SW(15) IS NOT SET), AN UNRECOVERABLE PROGRAM CONDITION HAS OCCURED OR A CENTRAL PROCESSOR FAILURE HAS OCCURED.

ERROR MESSAGES ARE MADE UP OF SEVERAL LINES. EACH TYPE OF ERROR HAS SEVERAL OPTIONAL LINES WHICH MAY APPEAR WITH IT. ALL OF THE POSSIBLE ERROR MESSAGE LINES WHICH MAY APPEAR ARE GIVEN IN THE SECTION DESCRIBING THE PARTICULAR ERROR HEADER.

7.1 ERROR DESCRIPTION LINES

(THE MESSAGE TAGS ARE GIVEN FOR REFERENCE.)

MESSAGE
TAG

TEXT

- | | |
|------|---|
| EM1 | RP11 DIDN'T RESPOND TO ADDRESSING
WHEN THE PROGRAM ADDRESSED THE RP11, A BUS TIMEOUT OCCURED. |
| EM2 | 'INVALID RP11 COMMAND'
THE PROGRAM ATTEMPTED TO ISSUE AN INVALID RP11 COMMAND. THIS ERROR WILL INDICATE EITHER A PROGRAMMING ERROR OR A CENTRAL PROCESSOR FAILURE. |
| EM3 | 'UNDEFINED INTERRUPT FROM THE RP11'
AN INTERRUPT FROM THE RP11 OCCURED AND NO ATTENTION BITS WERE SET AND NO TRANSFER WAS UNDERWAY. |
| EM10 | 'CAN'T MATCH DATA READ WITH A PATTERN'
THE DATA COMPARSION ROUTINE CANNOT IDENTIFY THE DATA PATTERN READ. |
| EM12 | 'DATA COMPARSION ERROR'
THE COMPARSION ROUTINE WAS ABLE TO IDENTIFY THE DATA PATTERN; HOWEVER, A COMPARSION ERROR OCCURED. |
| EM15 | 'ERR' NOT SET BUT 'RPER' CONTENTS NOT ZERO'
THE ERROR BIT IN 'RPCS' WAS NOT SET BUT ONE OR MORE ERROR BITS WAS SET IN THE ERROR REGISTER. |
| EM16 | 'WORD COUNT NOT ZERO OR BUFFER ADDRESS WRONG |

L02

MD-11-DZRP1-B, RP11E MULTI-DRIVE EXERCISER PROGRAM
DZRP1B.CMB

MACY11 27(732) 01-NOV-76 15:32 PAGE 25

744
745
746

AFTER AN ERROR FREE DATA TRANSFER, THE WORD COUNT REGISTER
DID NOT GO TO ZERO OR THE BUFFER ADDRESS REGISTER CONTENTS
WERE INCORRECT.

747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802

- EM17 'SOFTWARE TIMEOUT DURING POSITIONING'
A SEEK OR HOME SEEK COMMAND DID NOT COMPLETE WITHIN 1 SECOND.
- EM20 'SOFTWARE TIMEOUT DURING I/O'
A DATA TRANSFER OR WRITE CHECK COMMAND DID NOT COMPLETE WITHIN 1 SECOND.
- EM21 'DRIVE OFFLINE'
THE INDICATED DRIVE HAS GONE OFFLINE.
- EM22 'DRIVE UNSAFE'
THE INDICATED DRIVE HAS BECOME UNSAFE.
- EM23 'SEEK INCOMPLETE'
A SEEK INCOMPLETE ERROR HAS OCCURED ON THE INDICATED DRIVE.
- EM24 'UNIBUS TRANSFER ERROR'
A UNIBUS TIMING ERROR OR NON-EXISTENT MEMORY ERROR HAS OCCURED.
- EM25 'CONTROLLER ERROR'
A 'MODE' ERROR OR A 'PROGRAM' ERROR HAS OCCURED.
- EM26 'NON-EXISTENT DISK ADDRESS'
A NON-EXISTENT SECTOR, TRACK, OR CYLINDER ERROR HAS OCCURED.
- EM27 'DATA ERROR'
ANY OR ALL OF THE FOLLOWING ERRORS OCCURED: 'CHECKSUM' ERROR, 'WORD PARITY ERROR', OR 'LONGITUDINAL PARITY' ERROR.
- EM32 'WRITE CHECK ERROR (NO DATA ERROR)'
A WRITE CHECK ERROR OCCURED. 'CHECKSUM', 'WORD PARITY ERROR', OR 'LONGITUDINAL PARITY' ERROR BITS WERE NOT SET.
- EM33 'WRITE CHECK ERROR (DATA ERROR BITS SET)'
A WRITE CHECK ERROR OCCURED. 'CHECKSUM', 'WORD PARITY', OR 'LONGITUDINAL PARITY' ERROR BITS WERE SET.
- EM34 'HEADER NOT FOUND'
A 'HEADER NOT FOUND' ERROR OCCURED. THE PROGRAM VERIFIED THAT THE DISK WAS ON THE CORRECT CYLINDER.

803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858

- EM35 'FORMAT ERROR WHILE SEARCHING FOR INITIAL SECTOR'
A 'FORMAT ERROR' WAS DETECTED WHILE THE CONTROLLER WAS SEARCHING FOR THE FIRST SECTOR OF THE DATA TO BE TRANSFERED.
- EM36 'HEADER NOT FOUND, CYLINDER IN HEADER DOES NOT COMPARE'
A HEADER NOT FOUND ERROR OCCURED. THE PROGRAM READ THE HEADER OF THE SECTOR BEING SEARCHED FOR (USING A HEADER READ) AND THE CYLINDER ADDRESS FIELD IN THE HEADER DID NOT COMPARE WITH THE CYLINDER THE DISK WAS EXPECTED TO BE AT. THE PROGRAM ISSUES A HOME SEEK TO THE DRIVE AFTER REPORTING THIS ERROR.
- EM37 'DIFFERENT ERROR DURING RETRY'
DURING ERROR RECOVERY OR RETRY A DIFFERENT ERROR TYPE OCCURED.
- EM43 ''ERR' SET BUT NO ERROR BITS SET'
'ERR' IN 'RPCS' WAS SET, BUT NO ERROR BITS IN 'RPER' WERE SET.
- EM44 'WRITE PROTECTION VIOLATION'
THE PROGRAM ATTEMPTED TO WRITE ON A WRITE PROTECTED DRIVE.
- EM45 'FORMAT ERROR DURING I/O'
A 'FORMAT ERROR' WAS DETECTED WHILE THE CONTROLLER WAS SEARCHING FOR THE SECOND OR SUBSEQUENT SECTOR TO BE TRANSFERED.

8. PROGRAM DESCRIPTION

8.1 PROGRAM OPERATION

WHEN THE PROGRAM IS STARTED FROM LOCATION 200(8), ALL TABLES AND PARAMETERS ARE CLEARED OR INITIALIZED. THE PARAMETERS WHICH ARE UNDER OPERATOR TTY ENTRY CONTROL ARE CHECKED FOR VALIDITY AND CONSISTENCY. TTY KEYBOARD INTERRUPT ENABLE IS SET, AND THE KW11-L OR KW11-P CLOCK IS STARTED. WHEN THESE ACTIONS HAVE BEEN COMPLETED, THE PROGRAM TYPES OUT 'PROGRAM INTIALIZE COMPLETE'. COMMAND ENTRIES WILL NOW BE ACCEPTED BY THE PROGRAM

THE PROGRAM SCANS ITS INTERNAL ASSIGNMENT TABLES, LOOKING FOR:

- 1) DRIVES TO ASSIGN/DEASSIGN
- 2) PERFORMANCE SUMMARY TYPEOUT REQUESTS
- 3) DRIVES REQUIRING COMMAND INITIATION, BUFFER ASSIGNMENT, OR PARAMETER SELECTION.
- 4) DRIVES COMPLETING CURRENT OPERATIONS.

859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911
912

THE PROGRAM CONTINUES SCANNING ITS TABLES UNTIL AN ENTRY IS FOUND. IN THE CASE OF THE PROGRAM AT INITIAL START, THE FIRST ENTRY WILL BE MADE BY THE OPERATOR WHEN A DRIVE IS ASSIGNED ('T' COMMAND).

WHEN A DRIVE IS ASSIGNED, THE KEYBOARD ENTRY ROUTINE VERIFIES THAT THE DRIVE IS PRESENT AND IS ONLINE. THE ASSIGNMENT ROUTINE THEN ISSUES A HOME SEEK INSTRUCTION.

PARAMETERS FOR THE OPERATION ARE SELECTED AND A BUFFER IS ASSIGNED. IF THE OPERATION IS A WRITE OR WRITE CHECK ORDER, THE ASSIGNED BUFFER WILL BE FILLED WITH THE SELECTED PATTERN. (WRITE CHECK ORDERS ARE ISSUED AFTER EACH WRITE ORDER. THE WRITE CHECK ORDER USES THE PARAMETERS SELECTED FOR THE PRECEDING WRITE ORDER.) CONTROL (COMMAND INITIATION DESCRIPTION)

WHEN THE DATA TRANSFER OPERATION IS COMPLETE, THE DRIVE REGISTERS ARE STORED AND A DATA TRANSFER IS INITIATED FOR A WAITING DRIVE.

IF THE OPERATION HAS BEEN COMPLETED NORMALLY, THE SAVED DRIVE REGISTERS ARE CHECKED TO VERIFY THAT NO ERROR BITS ARE SET; THE RPIIE BUS ADDRESS AND WORD COUNT ADDRESS REGISTERS ARE CHECKED TO VERIFY THAT THE CORRECT NUMBER OF WORDS HAVE BEEN TRANSFERED AND THAT THE TWO REGISTERS ARE CONSISTENT WITH EACH OTHER; AND IF THE ORDER WAS A READ ORDER, THE DATA BUFFER IS COMPARED. WHEN THIS SEQUENCE IS COMPLETED, THE DRIVE IS RETURNED TO THE ASSIGNED, INACTIVE LIST. THE PROGRAM THEN INITIATES A DATA TRANSFER ON A WAITING DRIVE AND RESELECTS AND REINITIATES ANOTHER OPERATION ON THE RELEASED DRIVE.

ERRORS WHICH OCCUR ARE PROCESSED IN THE FOLLOWING ORDER. MULTIPLE ERRORS WILL BE REPORTED AS THE FIRST ERROR TYPE CHECKED.

A. ERRORS REPORTED FOR OPERATIONS WHICH HAVE NOT COMPLETED NORMALLY.

SOFTWARE TIMEOUT DURING POSITIONING - EM17
SOFTWARE TIMEOUT DURING I/O - EM20
DRIVE OFFLINE - EM21
DRIVE UNSAFE - EM22

B. ERRORS REPORTED FOR OPERATIONS WHICH COMPLETE NORMALLY.

SEEK INCOMPLETE - EM23
UNIBUS TRANSFER ERROR - EM24
CONTROLLER ERROR - EM25
NON-EXISTENT DISK ADDRESS - EM26
DATA ERROR - EM27
WRITE CHECK ERROR (NO DATA ERROR) - EM32
WRITE CHECK ERROR (DATA ERROR BITS SET) - EM33
HEADER NOT FOUND - EM34
FORMAT ERROR WHILE SEARCHING FOR INITIAL SECTOR - EM35
POSITIONING ERROR - EM36
DIFFERENT ERROR DURING RETRY - EM37
WRITE PROTECTION VIOLATION - EM44
FORMAT ERROR DURING I/O - EM45

913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948

C. ERRORS NOT FLAGGED BY THE HARDWARE ERROR DETECTION LOGIC.

RP11 DIDN'T RESPOND TO ADDRESSING - EM1
INVALID RP11 COMMAND - EM2
UNDEFINED INTERRUPT FROM THE RP11 - EM3
CAN'T MATCH DATA READ WITH A PATTERN - EM10
DATA COMPARE ERRORS - EM12
'ERR' NOT SET BUT 'RPER' CONTENTS NOT ZERO - EM15
WORD COUNT NOT ZERO OR BUFFER ADDRESS WRONG - EM16
'ERR' SET BUT NOT ERROR BITS IN 'RPER' SET - EM43

B.2 SELECTION OF OPERATION VARIABLES

- A. SECTOR ADDRESS SELECTION IS RANDOM BETWEEN THE VALUES IN 'FS' AND 'LS'. TRACK ADDRESS SELECTION IS RANDOM BETWEEN THE VALUES IN 'FT' AND 'LT'. CYLINDER ADDRESS SELECTION IS RANDOM BETWEEN 'FC' AND 'LC'.
- B. THE BUFFER SIZE IS RANDOM SELECTED BETWEEN 4 (10) - AND THE VALUE IN 'BUFRSZ'. THE SIZE SELECTED IS WEIGHTED TO ENSURE THAT AT LEAST 4 WORDS ARE WRITTEN IN THE DATA AREA OF THE LAST SECTOR. THIS IS NECESSARY AS THE PROGRAM REQUIRES 4 LOCATIONS IN THE DATA PORTION OF THE SECTOR TO BE ABLE TO MATCH THE DATA TO A PATTERN FOR DATA COMPARISON PURPOSES.
- C. THE DATA WRITTEN IS RANDOMLY SELECTED AMONG THE 20 (8) STANDARD PATTERNS.
- D. THE ORDERS ARE SELECTED RANDOMLY. WRITE CHECK ORDERS ARE PERFORMED ONLY IF THE PREVIOUS ORDER WAS A WRITE COMMAND.
- E. THE FIRST ORDER PERFORMED AFTER A UNIT IS ASSIGNED WITH A 'T' COMMAND IS NOT RANDOMLY SELECTED. THE PARAMETERS FOR THE FIRST OPERATION ARE THE MINIMUM OR STARTING VALUES OF THE VARIABLES.

8.3 DATA PATTERNS

THE PROGRAM SELECTS ONE OF THE FOLLOWING DATA PATTERNS TO WRITE WHEN A WRITE ORDER IS SELECTED. THE ENTIRE BUFFER IS FILLED WITH THE SELECTED PATTERN. WHEN DATA IS READ FROM THE DISK, THE PROGRAM COMPARES DATA ON A SECTOR BASIS: FROM THE FIRST 4 DATA WORDS OF EACH SECTOR, THE PROGRAM MATCHES THE DATA TO ONE OF THE FOLLOWING PATTERNS.

PATTERN '8' IS DEFINED AS THE 'WORST CASE' PATTERN.

PAT 0	PAT 1	PAT 2	PAT 3	PAT 4	PAT 5	PAT 6	PAT 7
000000	000001	177776	000000	000000	052525	007417	026455
000000	000003	177774	000000	010421	052525	007417	026455
000000	000007	177770	000000	021042	052525	007417	026455
000000	000017	177760	177777	031463	125252	170360	151322
000000	000037	177740	177777	042104	125252	170360	151322
000000	000077	177700	177777	052525	125252	170360	151322
000000	000177	177600	000000	063146	052525	007417	026455
000000	000377	177400	000000	073567	052525	007417	026455
000000	000777	177000	177777	104210	125252	170360	151322
000000	001777	176000	177777	114631	125252	170360	151322
000000	003777	174000	000000	125252	052525	007417	026455
000000	007777	170000	177777	135673	125252	170360	151322
000000	017777	160000	000000	146314	052525	007417	026455
000000	037777	140000	177777	156735	125252	170360	151322
000000	077777	100000	000000	167356	052525	007417	026455
000000	177777	000000	177777	177777	125252	170360	151322
PAT 8	PAT 9	PAT 10	PAT 11	PAT 12	PAT 13	PAT 14	PAT 15
077577	000001	177776	172666	077777	153333	000000	177777
077577	000002	177775	155555	137777	066667	177777	000000
077577	000004	177773	172666	157777	153333	177777	000000
077577	000010	177767	155555	167777	066667	177777	000000
077577	000020	177757	172666	173777	153333	177777	000000
077577	000040	177737	155555	175777	066667	177777	000000
077577	000100	177677	172666	176777	153333	177777	000000
077577	000200	177577	155555	177377	066667	177777	000000
077577	000400	177377	172666	177577	153333	177777	000000
077577	001000	176777	155555	177677	066667	177777	000000
077577	002000	175777	172666	177737	153333	177777	000000
077577	004000	173777	155555	177757	066667	177777	000000
077577	010000	167777	172666	177767	153333	177777	000000
077577	020000	157777	155555	177773	066667	177777	000000
077577	040000	137777	172666	177775	153333	177777	000000
077577	100000	077777	155555	177776	066667	177777	000000

9. PROGRAM LISTING

x

949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999
1000
1001
1002

1003
1004
1005
1006
1007
1008
1009
1010
1011
1012
1013
1014
1015
1016
1017
1018
1019
1020
1021
1022
1023
1024
1025
1026
1027
1028
1029
1030
1031
1032
1033
1034
1035
1036
1037
1038
1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057
1058

```
.TITLE MD-11-DZRP1-B, RPI1E MULTI-DRIVE EXERCISER PROGRAM
#COPYRIGHT (C) 1975,1976
#DIGITAL EQUIPMENT CORP.
#MAYNARD, MASS. 01754
#
#PROGRAM BY C. HESS/F. ROEMER
#
#THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
#PACKAGE (MAINDEC-11-DZQAC-C1),MAR 24, 1976.
#
.SBTTL OPERATIONAL SWITCH SETTINGS
#
#           SWITCH          USE
#-----
#           15             HALT ON ERROR
#           13             INHIBIT ERROR TYPEOUTS
#           10             BELL ON ERROR
#           7              DON'T TYPE SYSTEM STATUS.
#           6              INHIBIT PERFORMANCE SUMMARY TYPEOUTS
#           5              DON'T CHANGE PARAMETERS (LOOP ON PRESENT VALUES)
#           4              DO NOT CHECK FOR MAXIMUM ERROR COUNT OR DEASSIGN
#           3              DRIVE WHEN NORMAL END OF TEST REACHED
#           3              DISPLAY SECTOR WHICH GAVE 'HARD' ERROR
#           3              IF DATA COMPARE ERROR & SM2 SET, DISPLAY
#           2              REMAINDER OF BUFFER
#           2              DISPLAY ALL DATA COMPARE ERRORS
#           1              INHIBIT DATA COMPARISON AFTER READ ORDERS
#           0              READ ONLY MODE
#

.SBTTL BASIC DEFINITIONS
#
#INITIAL ADDRESS OF THE STACK POINTER ### 1100 ###
STACK= 1100
.EQUIV ENT,ERROR           ;;BASIC DEFINITION OF ERROR CALL
.EQUIV IOT,SCOPE          ;;BASIC DEFINITION OF SCOPE CALL
#
#MISCELLANEOUS DEFINITIONS
HT= 11                      ;;CODE FOR HORIZONTAL TAB
LF= 12                      ;;CODE FOR LINE FEED
CR= 15                      ;;CODE FOR CARRIAGE RETURN
CALF= 200                   ;;CODE FOR CARRIAGE RETURN-LINE FEED
PS= 177776                  ;;PROCESSOR STATUS WORD
.EQUIV PS,PSW
STK_LMT= 177774              ;;STACK LIMIT REGISTER
PIRQ= 177772                 ;;PROGRAM INTERRUPT REQUEST REGISTER
DSMR= 177570                 ;;HARDWARE SWITCH REGISTER
DDISP= 177570                ;;HARDWARE DISPLAY REGISTER
#
#GENERAL PURPOSE REGISTER DEFINITIONS
R0= X0                      ;;GENERAL REGISTER
R1= X1                      ;;GENERAL REGISTER
R2= X2                      ;;GENERAL REGISTER
R3= X3                      ;;GENERAL REGISTER
R4= X4                      ;;GENERAL REGISTER
R5= X5                      ;;GENERAL REGISTER
```

001100

000011
000012
000015
000200
177776
177774
177772
177570
177570

000000
000001
000002
000003
000004
000005

```

1059      000006      R6=      %6      ::GENERAL REGISTER
1060      000007      R7=      %7      ::GENERAL REGISTER
1061      .EQUIV      R6,SP      ::STACK POINTER
1062      .EQUIV      R7,PC      ::PROGRAM COUNTER
1063
1064      ::#PRIORITY LEVEL DEFINITIONS
1065      000000      PR0=      0      ::PRIORITY LEVEL 0
1066      000040      PR1=      40     ::PRIORITY LEVEL 1
1067      000100      PR2=      100    ::PRIORITY LEVEL 2
1068      000140      PR3=      140    ::PRIORITY LEVEL 3
1069      000200      PR4=      200    ::PRIORITY LEVEL 4
1070      000240      PR5=      240    ::PRIORITY LEVEL 5
1071      000300      PR6=      300    ::PRIORITY LEVEL 6
1072      000340      PR7=      340    ::PRIORITY LEVEL 7
1073
1074      ::#"SWITCH REGISTER" SWITCH DEFINITIONS
1075      100000      SW15=     100000
1076      040000      SW14=     400000
1077      020000      SW13=     200000
1078      010000      SW12=     100000
1079      004000      SW11=     40000
1080      002000      SW10=     20000
1081      001000      SW09=     10000
1082      000400      SW08=     4000
1083      000200      SW07=     2000
1084      000100      SW06=     1000
1085      000040      SW05=     400
1086      000020      SW04=     200
1087      000010      SW03=     100
1088      000004      SW02=     40
1089      000002      SW01=     20
1090      000001      SW00=     10
1091      .EQUIV      SW15,SW15
1092      .EQUIV      SW14,SW14
1093      .EQUIV      SW13,SW13
1094      .EQUIV      SW12,SW12
1095      .EQUIV      SW11,SW11
1096      .EQUIV      SW10,SW10
1097      .EQUIV      SW09,SW09
1098      .EQUIV      SW08,SW08
1099      .EQUIV      SW07,SW07
1100      .EQUIV      SW06,SW06
1101      .EQUIV      SW05,SW05
1102      .EQUIV      SW04,SW04
1103      .EQUIV      SW03,SW03
1104      .EQUIV      SW02,SW02
1105      .EQUIV      SW01,SW01
1106      .EQUIV      SW00,SW00
1107
1108      ::#DATA BIT DEFINITIONS (BIT00 TO BIT15)
1109      100000      BIT15=    100000
1110      040000      BIT14=    400000
1111      020000      BIT13=    200000
1112      010000      BIT12=    100000
1113      004000      BIT11=    40000
1114      002000      BIT10=    20000
1115      001000      BIT09=    10000
1116      000400      BIT08=    4000
1117      000200      BIT07=    2000
1118      000100      BIT06=    1000
1119      000040      BIT05=    400
1120      000020      BIT04=    200
1121      000010      BIT03=    100
1122      000004      BIT02=    40
1123      000002      BIT01=    20
1124      000001      BIT00=    10

```



```

1115      000010      BIT03= 10
1116      000004      BIT02= 4
1117      000002      BIT01= 2
1118      000001      BIT00= 1
1119      .EQUIV      BIT09,BIT9
1120      .EQUIV      BIT08,BIT8
1121      .EQUIV      BIT07,BIT7
1122      .EQUIV      BIT06,BIT6
1123      .EQUIV      BIT05,BIT5
1124      .EQUIV      BIT04,BIT4
1125      .EQUIV      BIT03,BIT3
1126      .EQUIV      BIT02,BIT2
1127      .EQUIV      BIT01,BIT1
1128      .EQUIV      BIT00,BIT0
1129
1130      ;#BASIC "CPU" TRAP VECTOR ADDRESSES
1131      000004      ERRVEC= 4          ;: TIME OUT AND OTHER ERRORS
1132      000010      RESVEC= 10       ;: RESERVED AND ILLEGAL INSTRUCTIONS
1133      000014      TBITVEC=14       ;: "T" BIT
1134      000014      TRTVEC= 14       ;: TRACE TRAP
1135      000014      BPTVEC= 14       ;: BREAKPOINT TRAP (BPT)
1136      000020      IOTVEC= 20       ;: INPUT/OUTPUT TRAP (IOT) ##SCOPE##
1137      000024      PWRVEC= 24       ;: POWER FAIL
1138      000030      EMTVEC= 30       ;: EMULATOR TRAP (EMT) ##ERROR##
1139      000034      TRAPVEC=34       ;: "TRAP" TRAP
1140      000060      TKVEC= 60        ;: TTY KEYBOARD VECTOR
1141      000064      TPVEC= 64        ;: TTY PRINTER VECTOR
1142      000240      PIRQVEC=240      ;: PROGRAM INTERRUPT REQUEST VECTOR
1143
1144      ;RPI1 REGISTER INDEX VALUES
1145
1146      000000      RPDS=00           ;: DRIVE STATUS REGISTER
1147      000002      RPER=02          ;: ERROR REGISTER
1148      000004      RPCS=04          ;: CONTROL REGISTER
1149      000006      RPWC=06          ;: WORD COUNT REGISTER
1150      000010      RPBA=10          ;: BUFFER ADDRESS REGISTER
1151      000012      RPCA=12          ;: CYLINDER ADDRESS REGISTER
1152      000014      RPOA=14          ;: SECTOR/TRACK ADDRESS REGISTER
1153      000016      RPM1=16          ;: MAINTENANCE REGISTER #1
1154      000020      RPM2=20          ;: MAINTENANCE REGISTER #2
1155      000022      RPM3=22          ;: MAINTENANCE REGISTER #3
1156      000024      SUCA=24          ;: SELECTED UNIT CYLINDER ADDRESS REGISTER
1157      000026      SILO=26         ;: SILO REGISTER
1158
1159      ;RPI1 OP CODE DEFINITIONS
1160
1161      000001      CLEAR=1           ;: CLEAR THE CONTROLLER
1162      000003      WRTSEK=3          ;: WRITE WITH IMPLIED SEEK AND HEAD SELECTION
1163      000005      RDSEK=5           ;: READ WITH IMPLIED SEEK AND HEAD SELECT
1164      000007      WRTCHK=7         ;: WRITE CHECK WITH IMPLIED SEEK AND HEAD SELECT
1165      000011      SEEK=11          ;: SEEK
1166      000013      WRITE=13         ;: WRITE (NO IMPLIED SEEK OR HEAD SELECT)
1167      000015      HOMESEK=15       ;: HOME SEEK
1168      000017      READ=17         ;: READ (NO IMPLIED SEEK OR HEAD SELECT)
1169
1170      ;RPI1 REGISTER EQUATES

```

```

1171
1172           ;RPDS (DRIVE STATUS REGISTER)
1173
1174           ;ATTENTION BITS ARE REFERENCED BY BIT NUMBER (BIT00 - BIT07)
1175           000400      SUMP=400           ;SELECTED UNIT WRITE PROTECTED
1176           001000      SUFU=1000        ;SELECTED UNIT FILE UNSAFE
1177           002000      SUSU=2000        ;SELECTED UNIT SEEK UNDERWAY
1178           004000      SUSI=4000        ;SELECTED UNIT SEEK INCOMPLETE
1179           010000      HNF=10000        ;HEADER NOT FOUND
1180           020000      SURP03=20000     ;SELECTED UNIT IS AN RPO3
1181           040000      SUOL=40000       ;SELECTED UNIT IS ONLINE
1182           100000      SURDY=100000     ;SELECTED UNIT IS READY
1183
1184           ;RPER (ERROR REGISTER)
1185
1186           000001      DSKERR=1          ;DISK ERROR
1187           000002      EOP=2             ;END OF PACK
1188           000004      NXME=4            ;NON-EXISTENT MEMORY
1189           000010      WCE=10            ;WRITE CHECK ERROR
1190           000020      TIMEE=20          ;TIMING ERROR
1191           000040      CSME=40           ;CHECKSUM ERROR
1192           000100      WPE=100           ;WORD PARITY ERROR
1193           000200      LPE=200           ;LONGITUDINAL PARITY ERROR
1194           000400      MODERR=400        ;MODE ERROR
1195           001000      FMTE=1000         ;FORMAT ERROR
1196           002000      PROG=2000         ;PROGRAM ERROR
1197           004000      NXS=4000          ;NON-EXISTENT SECTOR
1198           010000      NXT=10000         ;NON-EXISTENT TRACK
1199           020000      NXC=20000         ;NON-EXISTENT CYLINDER
1200           040000      FUV=40000        ;FILE UNSAFE VIOLATION
1201           100000      MPV=100000       ;WRITE PROTECT VIOLATION
1202
1203           ;RPCS (CONTROL REGISTER)
1204
1205           ;'GO' BIT AND FUNCTION BITS ARE LOADED TOGETHER AND ARE DEFINED ELSEWHERE.
1206           ;EXTENDED MEMORY ADDRESS BITS ARE REFERED TO BY BIT NUMBER
1207           000100      IDE=100            ;INTERRUPT ON DONE
1208           000200      RDY=200           ;RPI1 READY
1209           ;DRIVE SELECT BITS ARE REFERED TO BY BIT NUMBER
1210           004000      HDR=4000          ;HEADER
1211           010000      MODE=10000        ;MODE
1212           020000      AIE=20000        ;ATTENTION INTERRUPT ENABLE
1213           040000      HE=40000         ;HARD ERROR
1214           100000      ERR=100000       ;ERROR
1215
1216           .SBTTL TRAP CATCHER
1217
1218           000000      .=0
1219           ;#ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
1220           ;#SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
1221           ;#LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
1222           000174      .=174
1223           000174      000000      DISPREG: .WORD 0           ;;SOFTWARE DISPLAY REGISTER
1224           000176      000000      SWREG: .WORD 0             ;;SOFTWARE SWITCH REGISTER
1225
1226           .SBTTL ACT11 HOOKS

```

```

1227
1228
1229      ;:*****
;HOOKS REQUIRED BY ACT11
1230      $SVPC=.          ;SAVE PC
1231      .=46
1232 000046 SENDAD      ;;1)SET LOC.46 TO ADDRESS OF SENDAD IN .SEOP
1233      .=52
1234 000052 .WORD 40000 ;;2)SET LOC.52 TO 40000
1235      .=$SVPC        ;; RESTORE PC
1236
1237      .SBTTL STARTING ADDRESSES
1238
1239      .=200
1240
1241 000200 000137 002016 JMP START ;START PROGRAM WITHOUT CHANGING PARAMETERS
1242 000204 000137 002024 JMP START1 ;START PROGRAM AND CHANGE PARAMETERS

```

1243
 1244
 1245
 1246
 1247
 1248
 1249
 1250 001100 001100
 1251 001100 000000
 1252 001102 000
 1253 001103 000
 1254 001104 000000
 1255 001106 000000
 1256 001110 000000
 1257 001112 000000
 1258 001114 000
 1259 001115 001
 1260 001116 000000
 1261 001120 000000
 1262 001122 000000
 1263 001124 000000
 1264 001126 000000
 1265 001130 000000
 1266 001132 000000
 1267 001134 000
 1268 001135 000
 1269 001136 000000
 1270 001140 177570
 1271 001142 177570
 1272 001144 177560
 1273 001146 177552
 1274 001150 177564
 1275 001152 177566
 1276 001154 000
 1277 001155 002
 1278 001156 012
 1279 001157 000
 1280 001160 000000
 1281
 1282 001162 000000
 1283 001164 000000
 1284 001166 000000
 1285 001170 000000
 1286 001172 000000
 1287 001174 000000
 1288 001176 000000
 1289 001200 000000
 1290 001202 000000
 1291 001204 000000
 1292 001206 177607 000377
 1293 001212 077
 1294 001213 015
 1295 001214 000012
 1296
 1297 001216 176710
 1298 001220 000254

.SBTTL COMMON TAGS

 *THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
 *USED IN THE PROGRAM.

 .=1100
 SCMTAG: .WORD 0
 SPASS: .WORD 00
 STSTNM: .BYTE 00
 SERFLG: .BYTE 00
 SICNT: .WORD 00
 SLPADR: .WORD 00
 SLPERR: .WORD 00
 SERTTL: .WORD 00
 SITEMB: .BYTE 00
 SERMAX: .BYTE 1
 SERRPC: .WORD 00
 SGDADR: .WORD 00
 SBDADR: .WORD 00
 SGDDAT: .WORD 00
 SBDAT: .WORD 00
 .WORD 00
 SAUTOB: .BYTE 00
 SINTAG: .BYTE 00
 .WORD 0
 SWR: .WORD DSWR
 DISPLAY: .WORD DDISP
 STKS: 177560
 STKB: 177562
 STPS: 177564
 STPB: 177566
 SNUL: .BYTE 0
 SFILLS: .BYTE 2
 SFILLC: .BYTE 12
 STPFLG: .BYTE 0
 SREGAD: .WORD 0
 SREG0: .WORD 0
 SREG1: .WORD 0
 SREG2: .WORD 0
 SREG3: .WORD 0
 SREG4: .WORD 0
 SREG5: .WORD 0
 SREG6: .WORD 0
 SREG7: .WORD 0
 SREG10: .WORD 0
 SREG11: .WORD 0
 SBELL: .ASCIZ <207><377><377>
 SQUES: .ASCII /?/
 SCRLF: .ASCII <15>
 SLF: .ASCIZ <12>

 RPADR: .WORD 176710
 RPVEC: .WORD 254

START OF COMMON TAGS
 CONTAINS PASS COUNT
 CONTAINS THE TEST NUMBER
 CONTAINS ERROR FLAG
 CONTAINS SUBTEST ITERATION COUNT
 CONTAINS SCOPE LOOP ADDRESS
 CONTAINS SCOPE RETURN FOR ERRORS
 CONTAINS TOTAL ERRORS DETECTED
 CONTAINS ITEM CONTROL BYTE
 CONTAINS MAX. ERRORS PER TEST
 CONTAINS PC OF LAST ERROR INSTRUCTION
 CONTAINS ADDRESS OF 'GOOD' DATA
 CONTAINS ADDRESS OF 'BAD' DATA
 CONTAINS 'GOOD' DATA
 CONTAINS 'BAD' DATA
 RESERVED--NOT TO BE USED
 AUTOMATIC MODE INDICATOR
 INTERRUPT MODE INDICATOR
 ADDRESS OF SWITCH REGISTER
 ADDRESS OF DISPLAY REGISTER
 TTY KBD STATUS
 TTY KBD BUFFER
 TTY PRINTER STATUS REG. ADDRESS
 TTY PRINTER BUFFER REG. ADDRESS
 CONTAINS NULL CHARACTER FOR FILLS
 CONTAINS # OF FILLER CHARACTERS REQUIRED
 INSERT FILL CHARS. AFTER A "LINE FEED"
 "TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
 CONTAINS THE ADDRESS FROM
 WHICH (SREG0) WAS OBTAINED
 CONTAINS ((SREGAD)+0)
 CONTAINS ((SREGAD)+2)
 CONTAINS ((SREGAD)+4)
 CONTAINS ((SREGAD)+6)
 CONTAINS ((SREGAD)+10)
 CONTAINS ((SREGAD)+12)
 CONTAINS ((SREGAD)+14)
 CONTAINS ((SREGAD)+16)
 CONTAINS ((SREGAD)+20)
 CONTAINS ((SREGAD)+22)
 CODE FOR BELL
 QUESTION MARK
 CARRIAGE RETURN
 LINE FEED

 FIRST ADDRESS OF RP11
 RP11 VECTOR ADDRESS

1299 001222 000240
1300 001224 172540
1301 001226 172542
1302 001230 000104
1303 001232 177546
1304 001234 000100
1305 001236 177777
1306 001240 000074
1307 001242 000000
1308 001244 000000
1309 001246 001100
1310 001250 000000
1311 001252 000000
1312 001254 000003
1313 001256 000000
1314
1315 001260 001750
1316 001262 000000
1317 001264 000000
1318 001266 000000
1319 001270 000000
1320 001272 000000
1321
1322
1323
1324
1325
1326
1327
1328 001274 137100
1329 001276 022500
1330 001300 041100
1331 001302 000017
1332 001304 000001
1333 001306 000000
1334
1335
1336 001310 000144
1337 001312 000005
1338
1339 001314 000004
1340 001316 000000
1341 001320 000003
1342
1343
1344
1345
1346
1347
1348
1349
1350 001322 000001
1351
1352
1353
1354

RPPRIO: .WORD 5*32.
SLKCSR: .WORD 172540
SLKCSB: .WORD 172542
SLPVEC: .WORD 104
SLKS: .WORD 177546
SLLVEC: .WORD 100
CLKFLG: .WORD -1
HZ: .WORD 74
CNTRLC: .WORD 0
LSTAD: .WORD 0
STACK1: .WORD STACK
STATIN: .WORD 0
PACK: .WORD 0
FAIRNS: .WORD 3
MAXCYL: .WORD 0

TIMOUT: .WORD 1000.
CHNGPM: .WORD 0
DRIVE: .WORD 0
CYL.ER: .WORD 0
TRK.ER: .WORD 0
SEC.ER: .WORD 0

:RP11 PRIORITY
:ADDR OF KW11-P STATUS REGISTER
:ADDR OF KW11-P COUNTER BUFFER
:ADDR OF KW11-P VECTOR
:ADDR OF KW11-L STATUS REGISTER
:ADDR OF KW11-L VECTOR
:'0' IF A CLOCK IS AVAILABLE
:74 (8) IF 60 HZ SYSTEM; 62 (8) IF 50 HZ SYSTEM
:VECTOR ADDRESS FOR CONTROL C
:CONTAINS LAST MEMORY ADDRESS
:CONSTANT USED TO CHECK STACK POINTER
:ERROR RATE DATA DISPLAY INDICATOR
:'W' OR 'R' COMMAND INDICATOR
:'FAIRNESS' COUNT FOR BUFFER WAIT
:MAXIMUM CYLINDER ADDRESS ALLOWED FOR
:ANY DRIVE TESTED. (FILLED IN DURING STARTUP.)
:TIME (IN MS) ALLOWED FOR OPERATION
:IS NON-ZERO IF PARAMETERS TO BE CHANGED
:STORE DRIVE NUMBER HERE
:STORE CYLINDER ADDRESS HERE
:STORE TRACK ADDRESS HERE
:STORE SECTOR ADDRESS HERE

;;*****

.SBTTL CONTROL PARAMETERS

;;*****

ENDCON: .WORD 137100
ENDSEK: .WORD 22500
PASCNT: .WORD 17
BUFRSZ: .WORD 041100

MAXER: .WORD 1
INTRVL: .WORD 100.

CMPLMT: .WORD 5
SEKMOD: .WORD 4
RATIO: .WORD 03

:6.25X10¹⁸ WORDS (10) (1X10¹⁰ BITS)
:MSW
:1 X 10¹⁶ SEEKS (LSW)
:MSW
:NUMBER OF PASSES TO END OF TEST
:MAXIMUM DATA TRANSFER SIZE IN WORDS
:(FILLED BY PROGRAM AT STARTUP OR BY OPERATOR
:DURING PARAMETER ENTRY DIALOG.)
:MAXIMUM ERRORS - 100(10)
:LOW BYTE IS PERFORMANCE TIMEOUT INTERVAL
:COUNTER. UPPER BYTE IS VALUE.
:NUMBER OF COMPARE ERRORS TYPED OUT
:IF EQ 1, END OF PASS DETERMINED BY SEEK COUNT
:READ/WRITE RATIO (RANGE 0 - 7)
:0 - 15/1 (READ/WRITE)
:1 - 7/1
:2 - 6/2
:3 - 5/3
:4 - 4/4
:5 - 3/5
:6 - 2/6
:7 - 1/7
:IF EQ 1, DO A WRITE CHECK AFTER EACH ORDER
:IF EQ 0, SELECT WRITE CHECK ORDERS RANDOMLY

;;*****


```

1383 .SBTTL ERROR POINTER TABLE
1384
1385 ;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
1386 ;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
1387 ;*LOCATION SITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
1388 ;*NOTE1: IF SITEMB IS 0 THE ONLY PERTINENT DATA IS (SERRPC).
1389 ;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
1390
1391 ;* EM ;:POINTS TO THE ERROR MESSAGE
1392 ;* DH ;:POINTS TO THE DATA HEADER
1393 ;* DT ;:POINTS TO THE DATA
1394 ;* DF ;:POINTS TO THE DATA FORMAT
1395
1396
1397 001346 SERRTB:
1398
1399 ;ERROR 1
1400
1401 001346 027030 EM1 ;RP11 DIDN'T RESPOND TO ADDRESSING
1402 001350 030352 DH1
1403 001352 032010 DT1
1404 001354 032264 DF1
1405
1406 ;ERROR 2
1407
1408 001356 027072 EM2 ;INVALID RP11 COMMAND
1409 001360 030360 DH2
1410 001362 032012 DT2
1411 001364 032270 DF2
1412
1413 ;ERROR 3
1414
1415 001366 027117 EM3 ;UNDEFINED INTERRUPT FROM RP11
1416 001370 030375 DH3
1417 001372 032016 DT3
1418 001374 032270 DF2
1419
1420 ;ERROR 4
1421
1422 001376 000000 0 ;UNUSED
1423 001400 000000 0
1424 001402 000000 0
1425 001404 000000 0
1426
1427 ;ERROR 5
1428
1429 001406 000000 0 ;UNUSED
1430 001410 000000 0
1431 001412 000000 0
1432 001414 000000 0
1433
1434 ;ERROR 6
1435
1436 001416 000000 0 ;UNUSED
1437 001420 000000 0
1438 001422 000000 0
    
```

1439	001424	000000	0	
1440				
1441				;ERROR 7
1442				
1443	001426	000000	0	;UNUSED
1444	001430	000000	0	
1445	001432	000000	0	
1446	001434	000000	0	
1447				
1448				;ERROR 10
1449				
1450	001436	027161	EM10	;CAN'T MATCH DATA READ WITH A PATTERN
1451	001440	030412	DH10	
1452	001442	032026	DT10	
1453	001444	032274	DF10	
1454				
1455				;ERROR 11
1456				
1457	001446	000000	0	;SECOND LINE OF 'CAN'T MATCH DATA' MESSAGE
1458	001450	000000	0	
1459	001452	032022	DT11	
1460	001454	032270	DF2	
1461				
1462				;ERROR 12
1463				
1464	001456	027226	EM12	;DATA COMPARE ERRORS
1465	001460	030412	DH10	
1466	001462	032026	DT10	
1467	001464	032304	DF12	
1468				
1469				;ERROR 13
1470				
1471	001466	000000	0	;DATA COMPARE DETAIL LINE
1472	001470	000000	0	
1473	001472	032040	DT13	
1474	001474	032314	DF13	
1475				
1476				;ERROR 14
1477				
1478	001476	000000	0	;DATA COMPARE ERROR SUMMARY LINE
1479	001500	030571	DH14	
1480	001502	032046	DT14	
1481	001504	032320	DF14	
1482				
1483				;ERROR 15
1484				
1485	001506	027252	EM15	; 'ERR' NOT SET BUT 'RPER' CONTENTS NOT ZERO
1486	001510	030617	DH15	
1487	001512	032050	DT15	
1488	001514	032324	DF15	
1489				
1490				;ERROR 16
1491				
1492	001516	027325	EM16	;WORD COUNT NOT ZERO OR BUFFER ADDRESS WRONG
1493	001520	030654	DH16	
1494	001522	032060	DT16	

1495	001524	032330	DF16	
1496				
1497				;ERROR 17
1498				
1499	001526	027401	EM17	;SOFTWARE TIMEOUT DURING POSITIONING
1500	001530	030775	DH17	
1501	001532	032076	DT17	
1502	001534	032334	DF17	
1503				
1504				;ERROR 20
1505				
1506	001536	027445	EM20	;SOFTWARE TIMEOUT DURING I/O
1507	001540	030775	DH17	
1508	001542	032076	DT17	
1509	001544	032334	DF17	
1510				
1511				;ERROR 21
1512				
1513	001546	027501	EM21	;DRIVE OFFLINE
1514	001550	030775	DH17	
1515	001552	032076	DT17	
1516	001554	032334	DF17	
1517				
1518				;ERROR 22
1519				
1520	001556	027517	EM22	;DRIVE UNSAFE
1521	001560	030775	DH17	
1522	001562	032076	DT17	
1523	001564	032334	DF17	
1524				
1525				;ERROR 23
1526				
1527	001566	027534	EM23	;SEEK INCOMPLETE
1528	001570	031117	DH23	
1529	001572	032124	DT23	
1530	001574	032344	DF23	
1531				
1532				;ERROR 24
1533				
1534	001576	027554	EM24	;UNIBUS TRANSFER ERROR
1535	001600	031237	DH24	
1536	001602	032144	DT24	
1537	001604	032354	DF24	
1538				
1539				;ERROR 25
1540				
1541	001606	027602	EM25	;CONTROLLER ERROR
1542	001610	031304	DH25	
1543	001612	032156	DT25	
1544	001614	032324	DF15	
1545				
1546				;ERROR 26
1547				
1548	001616	027623	EM26	;NON-EXISTENT DISK ADDRESS
1549	001620	031341	DH26	
1550	001622	032166	DT26	

1551	001624	032360	DF26	
1552				
1553				
1554				
1555				
1556	001626	027655	EM27	;DATA ERROR
1557	001630	031416	DH27	
1558	001632	032202	DT27	
1559	001634	032364	DF27	
1560				
1561				
1562				
1563	001636	000000	0	;SOFT ERROR REPORT LINE
1564	001640	031570	DH30	
1565	001642	000000	0	
1566	001644	000000	0	
1567				
1568				
1569				
1570	001646	000000	0	;HARD ERROR REPORT LINE
1571	001650	031603	DH31	
1572	001652	000000	0	
1573	001654	000000	0	
1574				
1575				
1576	001656	027670	EM32	;WRITE CHECK ERROR (NO DATA ERROR)
1577	001660	031416	DH27	
1578	001662	032202	DT27	
1579	001664	032364	DF27	
1580				
1581				
1582				
1583	001666	027732	EM33	;WRITE CHECK ERROR (DATA ERROR BITS SET)
1584	001670	031416	DH27	
1585	001672	032202	DT27	
1586	001674	032364	DF27	
1587				
1588				
1589				
1590	001676	030002	EM34	;HEADER NOT FOUND
1591	001700	031616	DH34	
1592	001702	032236	DT34	
1593	001704	032374	DF34	
1594				
1595				
1596				
1597	001706	030023	EM35	;FORMAT ERROR WHILE SEARCHING FOR INITIAL SECTOR
1598	001710	031416	DH27	
1599	001712	032202	DT27	
1600	001714	032364	DF27	
1601				
1602				
1603				
1604	001716	030103	EM36	; HEADER NOT FOUND, CYLINDER IN HEADER
1605				; DOES NOT COMPARE
1606	001720	031616	DH34	

1607	001722	032236	DT34	
1608	001724	032374	DF34	
1609				
1610				;ERROR 37
1611				
1612	001726	030171	EM37	;DIFFERENT ERROR DURING RETRY
1613	001730	030775	DH17	
1614	001732	032076	DT17	
1615	001734	032334	DF17	
1616				
1617				;ERROR 40
1618				
1619	001736	000000	0	;UNUSED
1620	001740	000000	0	
1621	001742	000000	0	
1622	001744	000000	0	
1623				
1624				;ERROR 41
1625				
1626	001746	000000	0	;RETRY SUCCESSFUL
1627	001750	031745	DH41	
1628	001752	000000	0	
1629	001754	000000	0	
1630				
1631				;ERROR 42
1632				
1633	001756	000000	0	;RETRY UNSUCCESSFUL
1634	001760	031765	DH42	
1635	001762	000000	0	
1636	001764	000000	0	
1637				
1638				;ERROR 43
1639				
1640	001766	030226	EM43	;ERROR SIGNALLED BUT NO ERROR BITS SET
1641	001770	030775	DH17	
1642	001772	032076	DT17	
1643	001774	032334	DF17	
1644				
1645				;ERROR 44
1646				
1647	001776	030267	EM44	;WRITE PROTECT VIOLATION
1648	002000	030617	DH15	
1649	002002	032050	DT15	
1650	002004	032324	DF15	
1651				
1652				;ERROR 45
1653				
1654	002006	030322	EM45	;FORMAT ERROR DURING I/O
1655	002010	031416	DH27	
1656	002012	032202	DT27	
1657	002014	032364	DF27	
1658				
1659				;;*****
1660				
1661				.SBTTL SETUP AND INITIALIZATION ROUTINE
1662				

```

1663      :      START ADDRESS = 200
1664      :      START ADDRESS WITH PARAMETER CHANGES = 204
1665
1666      ;;*****
1667
1668 002016 005037 001262      START: CLR      CHNGPM      ;CLEAR 'START FROM 204' INDICATOR
1669 002022 000403              BR      BEGIN      ;START THE PROGRAM
1670 002024 012737 177777 001262 START1: MOV      8-1,CHNGPM ;SET 'CHANGE PARAMETER' INDICATOR
1671 002032 000005      BEGIN: RESET      ;CLEAR EVERYTHING
1672      .SBTTL INITIALIZE THE COMMON TAGS
1673      ;;CLEAR THE COMMON TAGS (SCHTAG) AREA
1674 002034 012706 001100      MOV      8SCHTAG,R6 ;FIRST LOCATION TO BE CLEARED
1675 002040 005026              CLR      (R6)+      ;CLEAR MEMORY LOCATION
1676 002042 022706 001140      CMP      8SMR,R6 ;;DONE?
1677 002046 001374              BNE      -6         ;LOOP BACK IF NO
1678 002050 012706 001100      MOV      8STACK,SP ;SETUP THE STACK POINTER
1679      ;;INITIALIZE A FEW VECTORS
1680 002054 012737 015624 000030      MOV      8ERROR,8ENTVEC ;ENT VECTOR FOR ERROR ROUTINE
1681 002062 012737 000340 000032      MOV      8340,8ENTVEC+2 ;LEVEL 7
1682 002070 012737 021020 000034      MOV      8STRAP,8TRAPVEC ;TRAP VECTOR FOR TRAP CALLS
1683 002076 012737 000340 000036      MOV      8340,8TRAPVEC+2;LEVEL 7
1684 002104 012737 176543 020620      MOV      8176543,8MINUM ;PRIME THE RANDOM NUMBER GENERATOR
1685 002112 012737 123456 020622      MOV      8123456,8LONUM ;BOTH HIGH AND LOW WORDS
1686      ;;SIZE FOR A HARDWARE SWITCH REGISTER, IF NOT FOUND OR IT IS
1687      ;;EQUAL TO A "-1" SETUP FOR A SOFTWARE SWITCH REGISTER.
1688 002120 013746 000004              MOV      8ERRVEC,-(SP) ;SAVE ERROR VECTOR
1689 002124 012737 002160 000004      MOV      8648,8ERRVEC ;SET UP ERROR VECTOR
1690 002132 012737 177570 001140      MOV      8DSMR,SMR ;SETUP FOR A HARDWARE SWICH REGISTER
1691 002140 012737 177570 001142      MOV      8DISP,DISPLAY ;AND A HARDWARE DISPLAY REGISTER
1692 002146 022777 177777 176764      CMP      8-1,8SMR ;TRY TO REFERENCE HARDWARE SMR
1693 002154 001012              BNE      668        ;BRANCH IF NO TIMEOUT TRAP OCCURRED
1694
1695 002156 000403              BR      658        ;AND THE HARDWARE SMR IS NOT = -1
1696 002160 012716 002166      648: MOV      8658,(SP) ;BRANCH IF NO TIMEOUT
1697 002164 000002              RTI ;SET UP FOR TRAP RETURN
1698 002166 012737 000176 001140      658: MOV      8SMREG,SMR ;POINT TO SOFTWARE SMR
1699 002174 012737 000174 001142      MOV      8DISPREG,DISPLAY
1700 002202 012637 000004      668: MOV      (SP)+,8ERRVEC ;RESTORE ERROR VECTOR
1701
1702 002206 012737 000240 000032      MOV      8240,8ENTVEC+2 ;CHANGE ENT PRIORITY TO 5
1703 002214 012737 000240 000036      MOV      8240,8TRAPVEC+2 ;CHANGE TRAP PRIORITY TO 5
1704 002222 104401 033644      18: TYPE      TITLE ;TYPE THE PROGRAM NAME AND MAINDEC NUMBER
1705 002226 012737 001213 002224      MOV      8SCALF,18+2 ;CHANGE 'TITLE' TO CR-LF
1706 002234 005037 177776              CLR      P5 ;RESET PROCESSOR PRIORITY
1707 002240 004737 016756              JSR      PC,8TKINT ;INITIALIZE THE TTY KEYBOARD
1708      .SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
1709 002244 005737 000042              TST      8842 ;ARE WE RUNNING UNDER XDP/ACT?
1710 002250 001006              BNE      678        ;BRANCH IF YES
1711 002252 023727 001140 000176      CMP      SMR,8SMREG ;SOFTWARE SWITCH REG SELECTED?
1712 002260 001005              BNE      688        ;BRANCH IF NO
1713 002262 104406              GTSMR ;GET SOFT-SMR SETTINGS
1714 002264 000403              BR      688
1715 002266 112737 000001 001134      678: MOV8      81,8AUTOB ;SET AUTO-MODE INDICATOR
1716 002274              688:
1717 002274 005037 001250              CLR      STATIN ;CLEAR PERFORMANCE SUMMARY INDICATOR
1718 002300 105037 001157              CLR8     STPFLG ;SET TTY AVAILABILITY FLAG

```

```

1719 002304 012705 025460      MOV      #ASMLST,R5      ;START OF AREA TO CLEAR
1720 002310 005025      CLR      (R5)+          ;CLEAR
1721 002312 022705 025736      CMP      #BLKADR,R5    ;LOOK FOR END OF CLEAR AREA
1722 002316 001374      BNE      2S            ;BR IF NOT FINISHED
1723 002320 013737 001240 010144      MOV      #Z,SIXTEE     ;1/60 TH OR 1/50 TH SECOND COUNTER VALUE
1724 002326 005437 010144      NEG      SIXTEE        ;CONVERT TO 2'S COMP
1725 002332 012737 030060 010130      MOV      #30060,HOUR   ;ASCII '00' TO HOUR COUNTER
1726 002340 012737 030060 010134      MOV      #30060,MINUTE ;ASCII '00' TO MINUTES COUNTER
1727 002346 012737 030060 010140      MOV      #30060,SECOND ;ASCII '00' TO SECONDS COUNTER
1728 002354 105037 001313      CLRB    INTRVL+1      ;CLEAR INTERVAL COUNTER
1729 002360 005037 177776      CLR     PSM           ;CLEAR PROCESSOR STATUS
1730 002364 005037 001252      CLR     PACK         ;'R' OR 'M' COMMAND INDICATOR
1731
1732
1733      ;ROUTINE TO DETERMINE BUFFER AREA SIZE
1734 002370 005227 177777      SIZMEM: INC      0-1    ;FIRST START ?
1735 002374 001013      BNE     1S           ;BR IF NOT
1736 002376 004737 033742      JSR     PC,SSIZE    ;SEE HOW MUCH MEMORY ON SYSTEM
1737 002402 012737 000137 002370      MOV     #137,SIZMEM ;CLEAR ENTRY TO 'SSIZE'
1738 002410 012737 002424 002372      MOV     #1S,SIZMEM+2 ;SAME
1739 002416 013737 034036 001244      MOV     #LSTAD,LSTAD ;SAVE THE HIGH MEMORY ADDRESS
1740 002424 012737 000001 025614      1S:    MOV     #1,BUFTBL ;LOAD NUMBER OF BUFFERS
1741 002432 012737 033644 025616      MOV     #ENDPGH,BUFTBL+2 ;STARTING ADDRESS OF BUFFER
1742 002440 013737 001244 025620      MOV     #LSTAD,BUFTBL+4 ;LAST ADDR TO BUFFER ALLOCATION TABLE
1743 002446 162737 033644 025620      SUB     #ENDPGH,BUFTBL+4 ;SUBTRACT PROGRAM SPACE
1744 002454 000241      CLC     ;CLEAR THE 'C' BIT
1745 002456 006037 025620      ROR     BUFTBL+4     ;CONVERT TO WORD COUNT
1746 002462 022737 037776 001244      CMP     #37776,LSTAD ;ONLY BK ON THE SYSTEM ?
1747 002470 103003      BHS    2S           ;BR IF BK OR LESS
1748 002472 105737 000041      TSTB   41           ;SEE WHO LOADED THE PROGRAM
1749 002476 001004      BNE     3S           ;BR IF LOADED BY 'XXDP'
1750 002500 162737 000144 025620      2S:    SUB     #100.,BUFTBL+4 ;SUBTRACT 'ABS' LOADER SIZE
1751 002506 000403      BR     4S           ;CONTINUE WITH BUFFER SPACE SETUP
1752 002510 162737 002734 025620      3S:    SUB     #1500.,BUFTBL+4 ;SUBTRACT 'XXDP' LOADER SIZE
1753 002516 005737 001306      4S:    TST     BUFRSZ     ;VALUE IN 'BUFRSZ' ?
1754 002522 001012      BNE     5S           ;BR IF VALUE IS
1755 002524 012737 005400 001306      MOV     #2816.,BUFRSZ ;ASSUME FULL TRACK + 1 SEC MAXIMUM
1756 002532 023737 001306 025620      CMP     BUFRSZ,BUFTBL+4 ;IS THAT TOO LARGE ?
1757 002540 101403      BLOS   5S           ;BR IF NOT
1758 002542 013737 025620 001306      MOV     BUFTBL+4,BUFRSZ ;USE MAX AVAIL MEMORY AS MAX BUFFER SIZE
1759 002550 005737 001262      5S:    TST     CHNGPH     ;CHANGE PARAMETERS ?
1760 002554 001455      BEQ     CKADR       ;BR IF NOT
1761
1762      ;PARAMETER ENTRY ROUTINE
1763
1764 002556 012737 002662 001242      ENTPAR: MOV     #ENTPR1,CNTRLC ;CONTROL C RETURN ADDRESS
1765 002564 104401 033374      ENTPR:  TYPE    #ASKPAR ;'ENTER PARAMETERS'
1766 002570 012704 033276      MOV     #PARLST,R4    ;ENTRY PARAMETER LIST TO R4
1767 002574 012437 002612      1S:    MOV     (R4)+,4S     ;ADDRESS OF PARAMETER NAME
1768 002600 001435      BEQ     ENTPR2       ;BR IF AT END OF TABLE
1769 002602 000402      BR     3S           ;GET AROUND THE CR-LF
1770 002604 104401 001213      2S:    TYPE    #,SCRLF   ;CR-LF
1771 002610 104401      3S:    TYPE    ;TYPE THE PARAMETER NAME
1772 002612 000000      4S:    .WORD 0         ;ADDRESS OF PARAMETER NAME TEXT
1773 002614 011405      MOV     (R4),R5      ;ADDRESS OF PARAMETER LOCATION
1774 002616 011546      MOV     (R5),-(SP)   ;CONTENTS OF PARAMETER LOCATION

```

1775	002620	104402				TYP0C			:TYPE THE CURRENT VALUE
1776	002622	104401	032501			TYPE	,SPACE1		:1 SPACE
1777	002626	104411				R0LIN			:READ THE KEYBOARD
1778	002630	012601				MOV	(SP)+,R1		:BUFFER ADDRESS
1779	002632	004037	012020			JSR	R0,CK.NUM		:CHECK THE NUMBER
1780	002636	002604				2S			:ILLEGAL INPUT
1781	002640	002650				5S			:TERMINATED WITH A 5S
1782	002642	002656				7S			:TERMINATED WITH A 7S
1783	002644	002652				6S			:NO ENTRY - TERMINATED WITH A 6S
1784	002646	002674				ENTPR2			:NO ENTRY - TERMINATED WITH A 6S
1785	002650	010215			5S:	MOV	R2,(R5)		:MOVE NEW VALUE TO PARAMETER LOCATION
1786	002652	005724			6S:	TST	(R4)+		:INCREMENT THE PARAMETER POINTER
1787	002654	000747				BR	1S		:GET MORE PARAMETERS
1788	002656	010215			7S:	MOV	R2,(R5)		:NEW PARAMETER VALUE
1789	002660	000405				BR	ENTPR2		:CONTINUE
1790	002662	012706	001100		ENTPR1:	MOV	#STACK,SP		:RESET THE STACK POINTER
1791	002666	005037	177776			CLR	PSW		:CLEAR THE STATUS WORD
1792	002672	000734				BR	ENTPR		:START WITH PARAMETER ENTRY AGAIN
1793	002674	005077	176244		ENTPR2:	CLR	#STKS		:CLEAR THE KEYBOARD INTERRUPT
1794	002700	005037	177776			CLR	PSW		:CLEAR PROCESSOR STATUS
1795	002704	012706	001100			MOV	#STACK,SP		:RESTORE STACK POINTER FOR RESTART
1796									
1797									
1798									
1799	002710	012737	002732	000004	CKADR:	MOV	#1S,ERRVEC		:CHANGE TIMEOUT RETURN
1800	002716	005777	176274			TST	#RPAR		:SEE IF RP11 RESPONDS
1801	002722	012737	000006	000004		MOV	#ERRVEC+2,ERRVEC		:RESET THE TIMEOUT VECTOR
1802	002730	000411				BR	2S		:CONTINUE WITH CHECKING
1803	002732	012737	000006	000004	1S:	MOV	#ERRVEC+2,ERRVEC		:RESET TIMEOUT VECTOR
1804	002740	104001				ERROR	1		:REPORT RP11 DIDN'T RESPOND
1805	002742	013700	000042			MOV	#42,R0		: 'CHAIN MODE' OR 'ACT11' ?
1806	002746	001703				BEQ	ENTPAR		:IF NOT - GO TO ENTER PARAMETER ROUTINE
1807	002750	000137	003634			JMP	SENDAD		:RETURN TO MONITOR
1808	002754	004737	021314		2S:	JSR	PC,RPINIT		:INITIALIZE THE RP11 HANDLER
1809	002760	012737	177777	021132		MOV	#-1,SAVEFG		:SET THE 'SAVE REGISTER' FLAG
1810	002766	012737	000312	001256		MOV	#202,MAXCYL		:START CYLINDER LIMIT AT RPO2 LIMIT
1811	002774	005737	021122			TST	DRVTYP		:SEE WHICH DRIVES (RPO2 OR RPO3) ARE
1812									:ON SYSTEM
1813	003000	001403				BEQ	3S		:BR IF RPO2'S
1814	003002	012737	000625	001256		MOV	#405.,MAXCYL		:CYLINDER LIMIT FOR RPO3'S
1815	003010	005737	001324		3S:	TST	LC		:VALUE ENTERED IN 'LC' ?
1816	003014	001003				BNE	4S		:BR IF ONE WAS
1817	003016	013737	001256	001324		MOV	MAXCYL,LC		:USE MAXIMUM VALUE
1818	003024	005037	001262		4S:	CLR	CHNGPM		:CLEAR CHANGE PARAMETERS INDICATOR
1819	003030	023737	001306	025620		CMP	BUFRSZ,BUFTBL+4		:REQUESTED TRANSFER SIZE TOO LARGE ?
1820	003036	101004				BHI	5S		:BR IF REQUESTED MAXIMUM TOO LARGE
1821	003040	022737	000004	001306		CMP	#4,BUFRSZ		:SEE IF MAXIMUM TRANSFER SIZE TOO SMALL
1822	003046	101404				BLOS	6S		:BR IF NOT TOO SMALL
1823	003050	012746	033501		5S:	MOV	#PAR1,-(SP)		:ADDR OF PARAMETER NAME
1824	003054	000137	003256			JMP	BADPAR		:REPORT THE PARAMETER ERROR
1825	003060	023737	001306	001344	6S:	CMP	BUFRSZ,BEGSZ		:IS MAX RECORD LENGTH SMALLER THAN 1 SECTOR ?
1826	003066	103003				BHIS	CKPAR		:BR IF NOT
1827	003070	013737	001306	001344		MOV	BUFRSZ,BEGSZ		:USE MAX RECORD SIZE AS STARTING SIZE
1828	003076	023737	001256	001324	CKPAR:	CMP	MAXCYL,LC		:MAXIMUM CYLINDER ADDR TOO LARGE ?
1829	003104	103004				BHIS	1S		:BR IF NOT
1830	003106	012746	033531			MOV	#PAR4,-(SP)		:ADDR OF PARAMETER NAME

;CHECK THE PARAMETERS FOR VALIDITY

```

1831 003112 000137 003256      JMP      BADPAR      ;REPORT PARAMETER ERROR
1832 003116 023737 001324 001326 1S:    CMP      LC,FC      ;MAX CYLINDER LARGER THAN MIN CYLINDER
1833 003124 103004          BHS      2S        ;BR IF IT IS
1834 003126 012746 033535      MOV      #PAR5,-(SP) ;ADDR OF PARAMETER NAME
1835 003132 000137 003256      JMP      BADPAR      ;REPORT PARAMETER ERROR
1836 003136 022737 000023 001330 2S:    CMP      #19.,LT    ;MAXIMUM TRACK ADDRESS TOO LARGE ?
1837 003144 103004          BHS      3S        ;BR IF NOT
1838 003146 012746 033541      MOV      #PAR6,-(SP) ;ADDRESS OF PARAMETER NAME
1839 003152 000137 003256      JMP      BADPAR      ;REPORT PARAMETER ERROR
1840 003156 023737 001330 001332 3S:    CMP      LT,FT      ;SEE IF MAX TRACK EQ OR LARGER THAN MIN TRACK
1841 003164 103004          BHS      4S        ;BR IF IT IS
1842 003166 012746 033545      MOV      #PAR7,-(SP) ;ADDRESS OF PARAMETER NAME
1843 003172 000137 003256      JMP      BADPAR      ;REPORT PARAMETER ERROR
1844 003176 022737 000011 001334 4S:    CMP      #9.,LS     ;SEE IF MAX SECTOR TOO LARGE ?
1845 003204 103004          BHS      5S        ;BR IF MAX SECTOR OK
1846 003206 012746 033551      MOV      #PAR8,-(SP) ;ADDRESS OF PARAMETER NAME
1847 003212 000137 003256      JMP      BADPAR      ;REPORT PARAMETER ERROR
1848 003216 023737 001334 001336 5S:    CMP      LS,FS      ;MINIMUM SECTOR ADDRESS TOO LARGE
1849 003224 103004          BHS      6S        ;BR IF NOT
1850 003226 012746 033555      MOV      #PAR9,-(SP) ;ADDRESS OF PARAMETER NAME
1851 003232 000137 003256      JMP      BADPAR      ;REPORT PARAMETER ERROR
1852 003236 022737 000007 001320 6S:    CMP      #7,RATIO   ;SEE IF R/N RATIO TOO LARGE
1853 003244 103016          BHS      SETVEC     ;BR IF NOT
1854 003246 012746 033607      MOV      #PAR14,-(SP);ADDRESS OF PARAMETER NAME
1855 003252 000137 003256      JMP      BADPAR      ;REPORT PARAMETER ERROR
1856
1857      ;REPORT THE BAD PARAMETER
1858
1859 003256 012637 003270      BADPAR: MOV      (SP)+,1S ;MOVE PARAMETER NAME
1860 003262 104401 033421          TYPE      ,NGPAR    ;'BAD PARAMETER'
1861 003266 104401          TYPE
1862 003270 000000          1S:      .WORD      0 ;PARAMETER NAME
1863 003272 104401 033451          TYPE      REPAR    ;'REENTER PARAMETERS
1864 003276 000137 002556          JMP      ENTPAR     ;GO THROUGH PARAMETER ENTRY ROUTINE AGAIN
1865
1866      ;DISPLAY DRIVE STATUS AND SET UP THE OTHER UNITS THE
1867      ;PROGRAM WILL USE
1868
1869 003302 005227 177777      SETVEC: INC      #-1 ;FIRST START ?
1870 003306 001404          BEQ      9S        ;BR IF IT IS
1871 003310 032777 000200 175622      BIT      #SW07,JSWR ;SWITCH 6 SET ?
1872 003316 001064          BNE      9S        ;BR IF SET
1873 003320 005004          CLR      R4        ;DRIVE TABLE POINTER
1874 003322 012703 000010          MOV      #8.,R3    ;ITERATION COUNTER
1875 003326 104401 001213          TYPE      ,SCRLF   ;CR-LF
1876 003332 104401 032625          TYPE      ,SYSTAT  ;TYPE STATUS HEADING
1877 003336 010446          1S:      MOV      R4,-(SP)  ;DRIVE NUMBER FOR TYPEOUT
1878 003340 104403          TYPOS    ;TYPE THE DRIVE NUMBER
1879 003342 001 000          .BYTE    1,0
1880 003344 104401 032476          TYPE      ,SPACE4  ;SPACES
1881 003350 105764 021112      TSTB    DRVSTA(R4) ;SEE WHAT DRIVE'S STATUS IS
1882 003354 001405          BEQ      2S        ;BR IF OFFLINE OR NOT PRESENT
1883 003356 100413          BMI     3S        ;BR IF UNSAFE
1884 003360 012737 032535 003442      MOV      #UNTON,6S ;MESSAGE ADDRESS
1885 003366 000412          BR      4S        ;DETERMINE DRIVE TYPE MESSAGE
1886 003370 012737 032524 003442 2S:    MOV      #UNTOFF,6S ;OFFLINE MESSAGE ADDRESS

```

```

1887 003376 012737 032501 003452      MOV      #SPACE1,7$      ;DUMMY MESSAGE
1888 003404 000415                          BR        5$            ;PRINT IT
1889 003406 012737 032615 003442 3$:    MOV      #NOTSAF,6$     ;UNIT UNSAFE
1890 003414 012737 032503 003452 4$:    MOV      #RPO2,7$      ;ASSUME RPO2
1891 003422 136437 021304 021122      BITB     ATABIT(R4),DRVTYP ;SEE WHICH DRIVE TYPE
1892 003430 001403                          BEQ      5$            ;BR IF RPO2
1893 003432 012737 032510 003452      MOV      #RPO3,7$      ;'RPO3'
1894 003440 104401                          TYPE     ;TYPE THE IDENTIFYING MESSAGE
1895 003442 000000                          .WORD   0              ;MESSAGE ADDRESS HERE
1896 003444 104401 032476                          TYPE     ,SPACE4      ;SPACES
1897 003450 104401                          TYPE     ;TYPE THE DRIVE TYPE MESSAGE
1898 003452 000000 7$:    .WORD   0              ;DRIVE TYPE MESSAGE GOES HERE
1899 003454 104401 001213      TYPE     $CRLF        ;CR-LF
1900 003460 005303                          DEC      R3            ;DECREMENT THE ITERATION COUNTER
1901 003462 001402                          BEQ      8$            ;BR IF END
1902 003464 005204                          INC      R4            ;INCREMENT TABLE POINTER
1903 003466 000723                          BR       1$            ;CONTINUE
1904 003470 104401 033212 8$:    TYPE     INTDON       ;TYPE 'INITIALIZE COMPLETE'
1905 003474 004737 006762      JSR     PC,CKCLK      ;START CLOCK IF ONE ON SYSTEM
1906 003500 012737 000200 177776  MOV     #PR4,PSW      ;SET PRIORITY TO KEYBOARD LEVEL
1907 003506 004737 016756      JSR     PC,$TKINT     ;INITIALIZE THE KEYBOARD INTERRUPT HANDLER
1908 003512 012737 006640 001242  MOV     #DORTI,CNTRLC ;ADDRESS IF 'CONTROL C'
1909 003520 012737 010146 000060  MOV     #KSR,TKVEC    ;CHANGE KEYBOARD VECTOR ADDRESS
1910 003526 005037 177776      CLR     PSW           ;LOWER PRIORITY
1911
1912      ;SET UP IF 'XXDP' OR 'ACT11' OPERATION
1913
1914 003532 005737 000042  MONTR:  TST      42      ;'XXDP' CHAIN MODE OR 'ACT11' AUTO ACCEPT
1915 003536 001417                          BEQ     2$            ;BR IF NEITHER
1916 003540 012703 000010      MOV     #8.,R3       ;DRIVE COUNTER
1917 003544 005004                          CLR     R4            ;DRIVE POINTER
1918 003546 105737 000041      TSTB   41            ;SEE WHICH - 'XXDP' OR 'ACT11' ?
1919 003552 001407                          BEQ     1$            ;BR IF 'ACT11' CONTROL
1920 003554 122737 000007 000041  CMPB   #7,41        ;IS RPO2 OR RPO3 THE LOADING DEVICE ?
1921 003562 001003                          BNE     1$            ;BR IF NOT
1922 003564 005204                          INC     R4            ;SETUP TO BYPASS DRIVE 0
1923 003566 012703 000007      MOV     #7,R3        ;DRIVES TO TRY TO ASSIGN
1924 003572 004737 010502 1$:    JSR     PC,ASGN2     ;ASSIGN ALL AVAILABLE DRIVES (EXCEPT DRIVE
1925                                     ;0 IF LOADED FROM AN RPO2 OR RPO3)
1926 003576 000137 004046 2$:    JMP     MAIN1        ;START THE PROGRAM
1927
1928      ;'XXDP' OR 'ACT11' END OF TEST ROUTINE
1929
1930 003602 013700 000042  SGET42: MOV     42,R0      ;MONITOR ADDRESS
1931 003606 001002                          BNE     1$            ;BR IF MONITOR ADDRESS
1932 003610 000137 004046      JMP     MAIN1        ;NONE, CONTINUE
1933 003614 022700 003634 1$:    CMP     #SENDAD,R0   ;IS MONITOR 'ACT11'
1934 003620 001005                          BNE     SENDAD        ;NO, BRANCH
1935 003622 022760 177777 000002  CMP     #-1,2(R0)    ;YES, IF THIS LAST PASS
1936 003630 001005                          BNE     SDOAGN        ;NO, MAKE ANOTHER PASS
1937 003632 000005                          RESET
1938 003634 004710  SENDAD: JSR     PC,(R0)  ;CLEAR EVERYTHING
1939 003636 000240                          NOP
1940 003640 000240                          NOP
1941 003642 000240                          NOP
1942 003644 000137 002016  SDOAGN: JMP     START    ;GO TO THE MONITOR
                                     ;SAVE ROOM
                                     ;FOR
                                     ;ACT11
                                     ;START AGAIN

```



```

1943
1944
1945
1946
1947
1948
1949
1950 003650 005737 001250 MAIN: TST STATIN ;TYPE ERROR RATE STATISTICS ?
1951 003654 001410 BEQ MAIN0 ;BR IF NOT
1952 003656 032777 000100 175254 BIT #SW06,JSWR ;CHECK SWITCH 6
1953 003664 001004 BNE MAIN0 ;BR IF SET
1954 003666 005037 001250 CLR STATIN ;CLEAR THE INDICATOR
1955 003672 004737 007126 JSR PC,STATPR ;TYPE THE STATISTICS
1956
1957 ;LOOK FOR DRIVES TO BE DEASSIGNED
1958
1959 003676 012703 000010 MAIN0: MOV #8,R3 ;UNIT COUNTER
1960 003702 012705 025504 MOV #UNIT,R5 ;ADDRESS OF 'DROP UNIT' TABLE
1961 003706 005715 1S: TST (R5) ;SEE IF ENTRY AT PRESENT POSITION
1962 003710 001011 BNE 3S ;BR IF THERE IS ONE
1963 003712 062705 000002 2S: ADD #2,R5 ;INCREMENT TO NEXT TABLE POSITION
1964 003716 005303 DEC R3 ;DECREMENT UNIT COUNTER
1965 003720 001372 BNE 1S ;BR IF MORE TO CHECK
1966 003722 005737 025460 TST ASNLST ;ANY DRIVES STILL RUNNING ?
1967 003726 001047 BNE MAIN1 ;BR IF ANY ARE - CHECK ASSIGN QUEUE
1968 003730 000137 003602 JMP $GET42 ;CHECK FOR MONITOR RETURN
1969 003734 012701 025550 3S: MOV #AVAIL,R1 ;ADDRESS OF 'AVAILABLE' UNITS TABLE
1970 003740 005711 4S: TST (R1) ;SEE IF AT END OF TABLE
1971 003742 001405 BEQ 5S ;BR IF AT END: GO CHECK 'WAIT' TABLE
1972 003744 021115 CMP (R1),(R5) ;IS UNIT IN 'AVAIL' THE ONE TO BE DROPPED
1973 003746 001414 BEQ 7S ;BR IF YES
1974 003750 062701 000002 ADD #2,R1 ;INCREMENT 'AVAIL' TABLE ADDRESS
1975 003754 000771 BR 4S ;CONTINUE LOOKING
1976 003756 012701 025572 5S: MOV #WAIT,R1 ;MOVE THE ADDRESS OF THE BUFFER WAIT TABLE
1977 003762 005711 6S: TST (R1) ;AT THE END OF THE 'WAIT' TABLE ?
1978 003764 001752 BEQ 2S ;BR IF YES: SEE IF ANY MORE 'DROP' REQUESTS
1979 003766 021115 CMP (R1),(R5) ;UNIT IN THE 'WAIT' TABLE ?
1980 003770 001403 BEQ 7S ;BR IF IT IS
1981 003772 062701 000002 ADD #2,R1 ;INCREMENT 'WAIT' TABLE ADDRESS
1982 003776 000771 BR 6S ;CONTINUE LOOK THROUGH THE 'WAIT' TABLE
1983 004000 011100 7S: MOV (R1),R0 ;PUT THE UNIT'S BLOCK ADDRESS IN R0
1984 004002 104401 001213 TYPE SCRLF ;CR-LF
1985 004006 004737 007634 JSR PC,STIME ;TYPE THE TIME
1986 004012 104401 032515 TYPE UNTMSG ;'DRIVE'
1987 004016 111046 MOVB (R0),-(SP) ;DRIVE NUMBER
1988 004020 104403 TYP0S ;TYPE IT
1989 004022 001 000 BYTE 1,0
1990 004024 104401 033067 TYPE DEASSG ;'DEASSIGNED'
1991 004030 004737 007240 JSR PC,TYPST ;TYPE THE DRIVE'S PERFORMANCE SUMMARY
1992 004034 005015 CLR (R5) ;CLEAR THE 'DROP UNIT' TABLE ENTRY
1993 004036 005011 CLR (R1) ;REMOVE THE UNIT FROM THE 'AVAIL' OR 'WAIT' TABLE
1994 004040 004737 006650 JSR PC,CMPRES ;COMPRESS THE RESPECTIVE TABLE
1995 004044 000722 BR 2S ;SEE IF ANY MORE UNITS
1996
1997 ;LOOK FOR DRIVES TO BE ASSIGNED
1998

```

```

1999 004046 012703 000010 MAIN1: MOV #8.,R3 ;UNIT COUNT
2000 004052 005002 CLR R2 ;'AVAIL' INDEX
2001 004054 005004 CLR R4 ;ASSIGN LIST INDEX
2002 004056 005005 CLR R5 ;NEW UNIT INDEX
2003 004060 005765 025526 1S: TST NEWUNT(R5) ;NEW UNIT IN THIS POSITION
2004 004064 001006 BNE 3S ;BR IF THERE IS
2005 004066 062705 000002 2S: ADD #2,R5 ;INCREMENT R5
2006 004072 005204 INC R4 ;INCREMENT ASSIGN INDEX
2007 004074 005303 DEC R3 ;DECREMENT UNIT COUNT
2008 004076 001370 BNE 1S ;BR IF MORE UNITS
2009 004100 000472 BR MAIN2 ;START OPERATIONS FOR THE AVAILABLE UNITS
2010 004102 104401 001213 3S: TYPE ,SCRLF ;CR-LF
2011 004106 004737 007634 JSR PC,STIME ;TYPE THE TIME
2012 004112 104401 032515 TYPE ,UNMSG ;'DRIVE'
2013 004116 010446 MOV R4,-(SP) ;DRIVE NUMBER
2014 004120 104403 TYPOS ;TYPE IT
2015 004122 001 000 .BYTE 1,0
2016 004124 104401 033131 TYPE ,ASGND ;'ASSIGNED'
2017 004130 005762 025550 4S: TST AVAIL(R2) ;AT END OF AVAILABLE TABLE
2018 004134 001403 BEQ 5S ;BR IF YES
2019 004136 062702 000002 ADD #2,R2 ;INCREMENT AVAILABLE TABLE INDEX
2020 004142 000772 BR 4S ;CONTINUE LOOKING FOR END OF TABLE
2021 004144 016562 025526 025550 5S: MOV NEWUNT(R5),AVAIL(R2) ;MOVE ADDR OF UNIL INTO AVAIL LST
2022 004152 005065 025526 CLR NEWUNT(R5) ;TAKE UNIT OUT OF NEW UNIT TABLE
2023 004156 156437 021304 025460 BISB ATABIT(R4),ASNLST ;SET UNIT ASSIGNED INDICATOR
2024 004164 016200 025550 MOV AVAIL(R2),R0 ;PUT STARTING ADDRESS OF BLOCK IN R0
2025 004170 113760 001336 000012 MOVBS FS,$SEC(R0) ;INITIAL SECTOR VALUE
2026 004176 113760 001332 000013 MOVBS FT,$TRK(R0) ;INITIAL TRACK VALUE
2027 004204 013760 001326 000010 MOV FC,$CYL(R0) ;INITIAL CYLINDER VALUE
2028 004212 113760 001342 000002 MOVBS BECCOD,$COMND(R0) ;INITIAL COMMAND CODE
2029 004220 113760 001340 000026 MOVBS BEGPAT,$PATTTC(R0) ;PATTERN CODE
2030 004226 106360 000026 ASLB SPATTTC(R0) ;CONVERT CODE TO A TABLE INDEX
2031 004232 013760 001344 000020 MOV BEGSIZ,$SWORDL(R0) ;BEGINNING RECORD SIZE
2032 004240 013760 001344 000004 MOV BEGSIZ,$SWORDM(R0) ;VALUE FOR DATA TRANSFER
2033 004246 005460 000004 NEG SWORDM(R0) ;MAKE IT INTO 2'S COMPLEMENT
2034 004252 013760 001254 000064 MOV FAIRNS,$FAIR(R0) ;LOAD FAIRNESS COUNT
2035 004260 062702 000002 ADD #2,R2 ;INCREMENT 'AVAILABLE' TABLE POINTER
2036 004264 000700 BR 2S ;LOOK FOR MORE UNITS
2037
2038 ;GET PARAMETERS, BUFFER SPACE, AND START ORDERS FOR DRIVES IN
2039 ; THE 'AVAILABLE' QUEUE
2040
2041 004266 005737 025572 MAIN2: TST WAIT ;OUTSTANDING BUFFER REQUESTS
2042 004272 001065 BNE MAIN3 ;BR IF THERE ARE
2043 004274 005002 CLR R2 ;CLEAR 'AVAIL' TABLE POINTER
2044 004276 005762 025550 1S: TST AVAIL(R2) ;ANY UNITS WAITING FOR PARAMETERS
2045 004302 001513 BEQ IDLE ;BRANCH IF NONE
2046 004304 016200 025550 MOV AVAIL(R2),R0 ;CONTROL BLOCK ADDR IN R0
2047 004310 026037 000064 001254 CMP $FAIR(R0),FAIRNS ;HAS ENTRY BEEN IN THE QUEUE ?
2048 004316 001010 BNE 3S ;BR IF IT HAS
2049 004320 105760 000022 TSTB $PACK(R0) ;'R' OR 'W' COMMAND FOR THE DRIVE ?
2050 004324 001403 BEQ 2S ;BR IF NOT
2051 004326 004737 006332 JSR PC,WRTPK ;GET DATA PACK PARAMETERS
2052 004332 000402 BR 3S ;GET THE BUFFER
2053 004334 004737 005512 2S: JSR PC,GETPAR ;LOAD NEW PARAMETERS
2054 004340 005046 3S: CLR -(SP) ;MAKE ROOM ON THE STACK FOR THE BUFFER ADDR

```

```

2055 004342 004737 004720
2056 004346 012660 000006
2057 004352 001414
2058 004354 004737 005304
2059 004360 005060 000064
2060 004364 004737 005434
2061 004370 012705 025462
2062 004374 005725
2063 004376 001376
2064 004400 010045
2065 004402 000413
2066 004404 005360 000064
2067 004410 001402
2068 004412 005722
2069 004414 000730
2070 004416 012705 025572
2071 004422 005725
2072 004424 001376
2073 004426 016245 025550
2074 004432 012701 025550
2075 004436 060201
2076 004440 004737 006650
2077 004444 000714
2078
2079
2080
2081 004446 013700 025572
2082 004452 005046
2083 004454 004737 004720
2084 004460 012660 000006
2085 004464 001002
2086 004466 000137 004532
2087 004472 004737 005304
2088 004476 004737 005434
2089 004502 005060 000064
2090 004506 012705 025462
2091 004512 005725
2092 004514 001376
2093 004516 010045
2094 004520 012701 025572
2095 004524 004737 006650
2096 004530 000656
2097
2098
2099
2100 004532 012701 025462
2101 004536 012100
2102 004540 001430
2103 004542 005760 000016
2104 004546 001773
2105 004550 162701 000002
2106 004554 010146
2107 004556 004737 004626
2108 004562 004737 012374
2109 004566 004737 005056
2110 004572 004737 011306
    
```

```

JSR PC,GETBUF ;GET BUFFER
MOV (SP)+,SBUF(RO) ;MOVE BUFFER ADDR TO DPB
BEQ SS ;BR IF '0' ADDR (NO BUFFER)
JSR PC,FILBUF ;FILL THE BUFFER
CLR SFAIR(RO) ;CLEAR THE 'FAIRNESS' COUNT
JSR PC,GODRIV ;PUT CURRENT DPB IN DRIVER
MOV #ORDERQ,R5 ;ADDRESS OF ORDER QUEUE IN R5
TST (R5)+ ;END OF QUEUE ?
BNE -2 ;BR IF NOT
MOV RO,-(R5) ;PUT BLOCK ADDRESS INTO QUEUE
BR 8S ;COMPRESS THE 'AVAIL' LIST
5S: DEC SFAIR(RO) ;DECREMENT THE 'FAIRNESS' COUNT
BEQ 6S ;ENTRY WAITING FOR BUFFER PAST LIMIT
TST (R2)+ ;INCREMENT THE 'AVAILABLE TABLE' POINTER
BR 1S ;CONTINUE LOOKING
6S: MOV #WAIT,R5 ;TABLE ADDRESS
TST (R5)+ ;AT END OF TABLE ?
BNE -2 ;BR IF NOT
7S: MOV AVAIL(R2),-(R5) ;MOVE ENTRY FROM AVAILABLE TO WAIT
8S: MOV #AVAIL,R1 ;TABLE TO COMPRESS
ADD R2,R1 ;FORM TABLE POSITION
JSR PC,COMPRES ;COMPRESS THE INDICATED TABLE
BR 1S ;CONTINUE PROCESSING

;GET BUFFER ASSIGNMENTS FOR DRIVES IN THE 'BUFFER WAIT' QUEUE
MAIN3: MOV WAIT,RO ;MOVE THE 'WAIT' ENTRY TO RO
CLR -(SP) ;MAKE ROOM ON THE STACK FOR THE BUFFER ADDR
JSR PC,GETBUF ;TRY TO GET A BUFFER
MOV (SP)+,SBUF(RO) ;MOVE THE BUFFER ADDR TO THE DPB
BNE 1S ;BR IF A BUFFER WAS ASSIGNED
JMP IDLE ;NO BUFFER AVAILABLE YET
1S: JSR PC,FILBUF ;FILL THE BUFFER
JSR PC,GODRIV ;PUT THE ENTRY IN THE DRIVER
CLR SFAIR(RO) ;CLEAR THE 'FAIRNESS' COUNT
MOV #ORDERQ,R5 ;ADDRESS OF ORDER QUEUE IN R5
TST (R5)+ ;AT END OF THE QUEUE
BNE -2 ;BR IF NOT
MOV RO,-(R5) ;PUT BLOCK ADDRESS IN QUEUE
MOV #WAIT,R1 ;TABLE ADDRESS
JSR PC,COMPRES ;COMPRESS THE WAIT TABLE
BR MAIN2 ;LOOK FOR MORE ENTRIES

;WAIT FOR AN ORDER TO FINISH
IDLE: MOV #ORDERQ,R1 ;ADDRESS OF THE ORDER QUEUE IN R1
1S: MOV (R1)+,RO ;PUT BLOCK ADDRESS INTO RO
BEQ 3S ;BR IF END OF QUEUE
TST STATUS(RO) ;SEE IF UNIT FINISHED
BEQ 1S ;BR IF UNIT NOT FINISHED
SUB #2,R1 ;CORRECT THE QUEUE POINTER
MOV R1,-(SP) ;SAVE THE QUEUE ADDRESS
JSR PC,STATIS ;ACCUMULATE STATISTICS FOR UNIT IN RO
JSR PC,PROCES ;PROCESS END OF ORDER
JSR PC,RELBUF ;RESTORE THE BUFFER
JSR PC,ABNRML ;SEE IF ANY UNITS HAVE TOO MANY ERRORS
    
```

```

2111 004576 004737 011334 JSR PC,NRML ;SEE IF ANY UNIT HAS XFERED 3X10+9 BITS
2112 004602 012601 MOV (SP)+,R1 ;RESTORE THE ORDER TABLE INDEX
2113 004604 012705 025550 MOV #AVAIL,R5 ;FIND THE END OF THE 'AVAILABLE' TABLE
2114 004610 005725 2S: TST (R5)+ ;END OF THE TABLE ?
2115 004612 001376 BNE 2S ;BR IF NOT AT END OF LIST
2116 004614 011145 MOV (R1), -(R5) ;MOV THE BLOCK ADDRESS INTO THE TABLE
2117 004616 004737 006650 JSR PC,CMPRES ;COMPRESS THE ORDER QUEUE
2118 004622 000137 003650 3S: JMP MAIN ;CONTINUE THE LOOP
2119
2120 ;ROUTINE TO UPDATE THE GENERAL STATISTICS FOR THE DRIVE IN RD
2121
2122 004626 016037 000076 004716 STATIS: MOV $RPBA(RD),FACTOR ;STORE THE FINAL BUFFER ADDRESS
2123 004634 166037 000006 004716 SUB $BUF(RD),FACTOR ;SUBTRACT THE INITIAL ADDRESS
2124 004642 001413 BEQ 1S ;BR IF NO DATA TRANSFER
2125 004644 006237 004716 ASR FACTOR ;CONVERT TO A WORD COUNT
2126 004650 132760 000004 000002 BITB #BIT02,$COMND(RD) ;READ OR WRITE ORDER ?
2127 004656 001405 BEQ 1S ;BR IF WRITE
2128 004660 063760 004716 000044 ADD FACTOR,$READ(RD) ;UPDATE THE READ WORD COUNT
2129 004666 005560 000046 ADC $READ+2(RD)
2130 004672 026060 000010 000106 1S: CMP $CYL(RD),$SUCA(RD) ;DID MID-TRANSFER SEEK OCCUR
2131 004700 001405 BEQ 2S ;BR IF NOT
2132 004702 062760 000001 000040 ADD #1,$POSIT(RD) ;INCREMENT SEEK COUNT
2133 004710 005560 000042 ADC $POSIT+2(RD) ;ADD CARRY TO UPPER WORD
2134 004714 000207 2S: RTS PC
2135
2136 004716 000000 FACTOR: .WORD 0 ;USED FOR WORDS TRANSFERED
2137
2138 ;*****
2139
2140 .SBTTL BUFFER SUPPORT ROUTINES
2141
2142 ;*****
2143
2144 ;ROUTINE TO GET A BUFFER
2145
2146 004720 010146 GETBUF: MOV R1,-(SP) ;SAVE R1
2147 004722 010246 MOV R2,-(SP) ;SAVE R2
2148 004724 010346 MOV R3,-(SP) ;SAVE R3
2149 004726 013702 025614 MOV BUFTBL,R2 ;NUMBER OF SEPARATE BUFFERS
2150 004732 001413 BEQ 5S ;BR IF NONE AVAILABLE
2151 004734 012701 025616 MOV #BUFTBL+2,R1 ;FIRST ADDRESS OF ALLOCATION TABLE
2152 004740 026061 000020 000002 1S: CMP $WRDL(RD),2(R1) ;SEE IF THERE IS A BLOCK LARGE ENOUGH
2153 004746 101411 BLOS 3S ;BRANCH IF IT IS
2154 004750 005302 DEC R2 ;DECREMENT TABLE COUNT
2155 004752 001403 BEQ 5S ;BR IF THROUGH TABLE
2156 004754 062701 000004 ADD #4,R1 ;INCREMENT TABLE POINTER
2157 004760 000767 BR 1S ;CONTINUE LOOKING
2158 004762 012603 5S: MOV (SP)+,R3 ;RESTORE R3
2159 004764 012602 MOV (SP)+,R2 ;RESTORE R2
2160 004766 012601 MOV (SP)+,R1 ;RESTORE R1
2161 004770 000207 RTS PC ;RETURN
2162 004772 011166 000010 3S: MOV (R1),10(SP) ;BUFFER ADDRESS TO STACK
2163 004776 166061 000020 000002 SUB $WRDL(RD),2(R1) ;ADJUST BUFFER SIZE
2164 005004 001407 BEQ 4S ;BR IF DIFFERENCE IS ZERO
2165 005006 006360 000020 ASL $WRDL(RD) ;CONVERT # WORDS TO BYTES
2166 005012 066011 000020 ADD $WRDL(RD),(R1) ;MAKE NEW STARTING ADDRESS

```

```

2167 005016 006260 000020      ASR      $WRDL(R0)      ;RETURN # BYTES TO WORDS
2168 005022 000757              BR        $$           ;RETURN
2169 005024 005337 025614      4$:     DEC      BUFTBL      ;DECREMENT ENTRIES COUNT
2170 005030 001754              BEQ      $$           ;BR IF ALLOCATION TABLE EMPTY
2171 005032 005302              DEC      R2           ;DECREMENT TABLE COUNT
2172 005034 001752              BEQ      $$           ;BR IF ITEM WERE LAST ENTRY
2173 005036 010103              MOV      R1,R3       ;MOVE TABLE POINTER
2174 005040 062703 000004      ADD      #4,R3       ;POINT TO NEXT ENTRY
2175 005044 012321              6$:     MOV      (R3)+,(R1)+ ;MOVE ITEMS
2176 005046 012321              MOV      (R3)+,(R1)+
2177 005050 005302              DEC      R2           ;DECREMENT TABLE COUNT
2178 005052 001374              BNE     $$           ;CONTINUE IF NOT AT END OF TABLE
2179 005054 000742              BR        $$           ;RETURN
2180
2181
2182      ;ROUTINE TO PUT BUFFER BACK IN TABLE
2183
2184 005056 104412      RELBUF: SAVREG      ;SAVE R0-R5
2185 005060 012701 025616      MOV      #BUFTBL+2,R1 ;BEGINNING OF TABLE
2186 005064 013702 025614      MOV      BUFTBL,R2   ;ENTRY COUNT
2187 005070 001424              BEQ      2$          ;BR IF EMPTY TABLE
2188 005072 016003 000020      MOV      $WRDL(R0),R3 ;TRIAL ADDRESS
2189 005076 006303              ASL     R3           ;CHANGE TO BYTE COUNT
2190 005106 066003 000006      ADD      $BUF(R0),R3 ;ADDRESS OF HIGHER ADJACENT BLOCK
2191 005104 021103              1$:     CMP      (R1),R3   ;UPPER ADJACENT BLOCK
2192 005106 001432              BEQ     4$          ;BR IF YES
2193 005110 062701 000004      ADD     #4,R1       ;INCREMENT POINTER
2194 005114 005302              DEC     R2          ;DECREMENT ENTRY COUNT
2195 005116 001372              BNE     1$         ;CONTINUE SEARCHING
2196 005120 016011 000006      MOV     $BUF(R0),(R1) ;PUT THE BUFFER BLOCK INTO THE TABLE
2197 005124 016061 000020 000002      MOV     $WRDL(R0),2(R1) ;BLOCK SIZE
2198 005132 005237 025614      INC     BUFTBL      ;INCREMENT ENTRY COUNT
2199 005136 005202              INC     R2          ;INCREMENT R2 FOR USE LATER
2200 005140 000422              BR     5$          ;SEE IF A LOWER ADJACENT BLOCK IS IN THE TABLE
2201 005142 016021 000006      2$:     MOV     $BUF(R0),(R1)+ ;BLOCK ADDRESS TO TABLE
2202 005146 016021 000020      MOV     $WRDL(R0),(R1)+ ;SIZE TO TABLE
2203 005152 005237 025614      INC     BUFTBL      ;INCREMENT ENTRY COUNT
2204 005156 022737 000002 025614 3$:     CMP     #2, BUFTBL ;SEE HOW MANY BLOCKS ARE IN TABLE
2205 005164 103001              BHIS   .+4         ;BR IF NOT MORE THAN 2
2206 005166 000240              NOP

```

2207	005170	104413			RESREG		:RESTORE R0-R5	
2208	005172	000207			RTS	PC	:RETURN	
2209	005174	016011	000006		MOV	\$BUF(R0), (R1)	:RELEASED BUFFER IS LOWER ADJACENT	
2210	005200	066061	000020	000002	4S:	ADD	\$WORDL(R0), 2(R1)	:INCREMENTED SIZE
2211	005206	010246			5S:	MOV	R2, -(SP)	:SAVE R2
2212	005210	013702	025614		MOV	\$BUFTBL, R2	:ENTRY COUNT	
2213	005214	012705	025616		MOV	\$BUFTBL+2, R5	:BEGINNING OF TABLE	
2214	005220	016504	000002		6S:	MOV	2(R5), R4	:BLOCK SIZE (IN WORDS)
2215	005224	006304			ASL	R4	:CHANGE TO BYTE COUNT	
2216	005226	061504			ADD	(R5), R4	:ADD BLOCK BEGINNING ADDRESS	
2217	005230	020411			CMP	R4, (R1)	:R1 STILL POINTS TO INSERTED ENTRY	
2218	005232	001406			BEQ	\$S	:LOWER ADJACENT IN TABLE	
2219	005234	062705	000004		ADD	\$4, R5	:INCREMENT POINTER	
2220	005240	005302			DEC	R2	:DECREMENT ENTRY COUNT	
2221	005242	001366			BNE	\$S	:CONTINUE LOOKING	
2222	005244	005726			TST	(SP)+	:RESTORE STACK POINTER	
2223	005246	000743			BR	\$S	:END	
2224	005250	012602			8S:	MOV	(SP)+, R2	:RESTORE R2
2225	005252	066165	000002	000002	ADD	2(R1), 2(R5)	:INCREMENT LOWER BLOCK LENGTH	
2226	005260	005337	025614		DEC	\$BUFTBL	:DECREMENT ENTRY COUNT	
2227	005264	010105			MOV	R1, R5	:GET READY TO COMPRESS	
2228	005266	062705	000004		ADD	\$4, R5	:INCREMENT TO NEXT ENTRY	
2229	005272	012521			9S:	MOV	(R5)+, (R1)+	:COMPRESS TABLE
2230	005274	012521			MOV	(R5)+, (R1)+	:MOVE SIZE FIELD DOWN	
2231	005276	005302			DEC	R2	:DECREMENT ENTRY COUNT	
2232	005300	001374			BNE	\$S	:BR IF NOT FINISHED	
2233	005302	000725			BR	\$S	:FINISHED	
2234								
2235								
2236								
2237								
2238	005304	104412			FILBUF: SAVREG		:SAVE R0-R5	
2239	005306	132760	000004	000002	BITB	\$BIT02, \$COMND(R0)	:READ OR WRITE ORDER ?	
2240	005314	001404			BEQ	\$S	:BR IF WRITE	
2241	005316	122760	000007	000002	CMPB	\$WRTCHK, \$COMND(R0)	:WRITE CHECK ?	
2242	005324	001041			BNE	\$S	:BR IF NOT	
2243	005326	026027	000006	033644	1S:	CMP	\$BUF(R0), \$ENDPGM	:MAKE SURE BUFFER IS ABOVE PROGRAM
2244	005334	103002			BHIS	+.6	:BR IF IT IS	
2245	005336	000000			HALT		:BUFFER ADDRESS WITHIN PROGRAM, ILLEGAL	
2246	005340	000776			BR	-.2	:INTERLOCK THE HALT	
2247	005342	023760	001306	000020	CMP	\$BUFRSZ, \$WORDL(R0)	:SEE IF WORD LENGTH DOESN'T EXCEED MAXIMUM	
2248	005350	103002			BHIS	+.6	:BR IF IT DOESN'T	
2249	005352	000000			HALT		:WORD LENGTH FOR OPERATION GREATER THAN AVAIL MEM	
2250	005354	000776			BR	-.2	:INTERLOCK THE HALT	
2251	005356	016001	000006		MOV	\$BUF(R0), R1	:BUFFER ADDRESS	
2252	005362	016002	000020		MOV	\$WORDL(R0), R2	:POSITIVE WORD COUNT	
2253	005366	005004			CLR	R4	:CLEAR R4	
2254	005370	116004	000026		MOV	\$PATT(R0), R4	:RELATIVE PATTERN ADDRESS	
2255	005374	016405	025764		MOV	\$STNDAT(R4), R5	:PATTERN ADDRESS	
2256	005400	012703	000020		MOV	\$16., R3	:PATTERN COUNT	
2257	005404	012521			2S:	MOV	(R5)+, (R1)+	:MOVE THE PATTERN INTO THE BUFFER
2258	005406	005302			DEC	R2	:DECREMENT THE WORD COUNT	
2259	005410	001407			BEQ	\$S	:BR IF DONE (WORD COUNT = 0)	
2260	005412	005303			DEC	R3	:DECREMENT THE PATTERN COUNT	
2261	005414	001373			BNE	\$S	:BR IF MORE PATTERN	
2262	005416	012703	000020		MOV	\$16., R3	:RESTORE PATTERN COUNT	

```

2263 005422 016405 025764          MOV    STNDAT(R4),R5    ;RESTORE THE ADDRESS
2264 005426 000766                BR     2S              ;CONTINUE DISTRIBUTING THE PATTERN
2265 005430 104413          3S:   RESREG          ;RESTORE RD-RS
2266 005432 000207          RTS     PC              ;RETURN

;START THE ORDER FOR THE DPB IN RD

2270 005434 010046          GODRIV: MOV   RD,-(SP)     ;SAVE RD
2271 005436 010037 005446          MOV   RD,R5           ;CURRENT DPB ADDRESS
2272 005442 004037 021566          JSR   RD,RP11         ;DRIVER ENTRANCE
2273 005446 000000          1S:   0                ;DPB ADDR GOES HERE
2274 005450 000000          HALT                    ;DRIVER REJECTED REQUEST
2275 005452 012500          MOV   (SP)+,RD        ;RESTORE RD
2276 005454 062760 000001 000034          ADD   #1,SOPERC(RD)   ;INCREMENT THE OPERATION COUNT
2277 005462 005560 000036          ADC   SOPERC+2(RD)    ;ADD ANY CARRY
2278 005466 026060 000032 000010          CMP   $PREVA+2(RD),SCYL(RD) ;DID ORDER REQUIRE A CYLINDER CHANGE
2279 005474 001405          BEQ   2S              ;BR IF NOT
2280 005476 062760 000001 000040          ADD   #1,SPOSIT(RD)  ;INCREMENT SEEK COUNT
2281 005504 005560 000042          ADC   SPOSIT+2(RD)   ;ADD ANY CARRY
2282 005510 000207          2S:   RTS     PC

;*****
.SBTL  GENERATE VARIABLES FOR THE NEXT OPERATION
;*****
;GENERATE VARIABLES FOR THE OPERATION

2291 005512 010546          GETPAR: MOV   RS,-(SP)  ;SAVE RS
2292 005514 004737 006616          JSR   PC,PREVST      ;SAVE CURRENT SECTOR & TRACK ADDRS
2293 005520 016060 000106 000032          MOV   $SUCA(RD),SPREVA+2(RD) ;SAVE CURRENT CYLINDER
2294 005526 032777 000040 173404          BIT   #SMD5,$SMR    ;SWITCH 5 SET ?
2295 005534 001414          BEQ   GTPAR1         ;BR IF NOT SET
2296 005536 122760 000007 000002          CMPB $WRTCHK,$SCOMND(RD) ;PRESENT ORDER A WRITE CHECK ?
2297 005544 001006          BNE   1S            ;BR IF NOT
2298 005546 005737 001322          TST   AUTOCK        ;AUTO WRITE CHECKS ?
2299 005552 001403          BEQ   1S            ;BR IF NOT
2300 005554 116060 000024 000002          MOVB $PREVO(RD),$SCOMND(RD) ;RESTORE PREVIOUS OPERATION
2301 005562 000137 006216          1S:   JMP   PARXIT    ;EXIT
2302 005566 116060 000002 000024          GTPAR1: MOVB $SCOMND(RD),$SPREVO(RD) ;SAVE CURRENT OPERATION CODE
2303 005574 004737 020522          JSR   PC,$RAND      ;CYCLE THE RANDOM NUMBER GENERATOR
2304 005600 032777 000001 173332          BIT   #SMD,$SMR    ;SEE IF SMD SET
2305 005606 001017          BNE   2S            ;BR IF SET - READ ONLY
2306 005610 012705 000010          1S:   MOV   #10,R5    ;READ/WRITE SELECTION DIVISOR
2307 005614 004737 011600          JSR   PC,GETREM     ;GET SELECTION VALUE
2308 005620 020537 001320          CMP   R5,RATIO     ;DETERMINE IF READ OR WRITE
2309 005624 003010          BGT   2S            ;BR IF READ
2310 005626 004737 006230          JSR   PC,RANWRT    ;SELECT A WRITE ORDER
2311 005632 122760 000007 000002          CMPB $WRTCHK,$SCOMND(RD) ;WAS WRITE CHECK SELECTED ?
2312 005640 001013          BNE   GETSEC       ;NO, CONTINUE WITH THE SELECTION
2313 005642 000137 006216          JMP   PARXIT       ;BYPASS REST OF VARIABLE SELECTION
2314 005646 013705 020620          2S:   MOV   $MINUM,R5 ;SELECT READ OPERATION CODE
2315 005652 042705 177776          BIC   #1,R5        ;MASK OUT ALL BUT BIT 0
2316 005656 062705 000003          ADD   #3,R5        ;TABLE OFFSET FOR READ CODE
2317 005662 116560 025756 000002          3S:   MOVB  $CONTBL(R5),$SCOMND(RD) ;ORDER SELECTION CODE TO CONTROL BLOCK

```

DOS

MD-11-DZRP1-B,
DZRP1B.CMB

RP11E MULTI-DRIVE EXERCISER PROGRAM
GENERATE VARIABLES FOR THE NEXT OPERATION

MACY11 27(732) 01-NOV-76 15:32 PAGE 56

```

2319
2320 ;GENERATE A RANDOM SECTOR ADDRESS BETWEEN VALUES 'FS' & 'LS'
2321
2322 005670 013705 001334 GETSEC: MOV LS,R5 ;GET MAXIMUM SECTOR ADDRESS
2323 005674 163705 001336 SUB FS,R5 ;SUBTRACT MINIMUM SECTOR ADDRESS
2324 005700 001403 BEQ 1$ ;BR IF MIN & MAX THE SAME
2325 005702 005205 INC R5 ;INCREMENT DIFFERENCE TO USE AS DIVISOR
2326 005704 004737 011600 JSR PC,GETREM ;GET THE RANDOM AUGMENT
2327 005710 063705 001336 1$: ADD FS,R5 ;CONVERT TO ADDRESS
2328 005714 110560 000012 MOVB R5,SSEC(RO) ;STORE SECTOR ADDRESS IN DPB
2329
2330 ;GENERATE A RANDOM TRACK ADDRESS BETWEEN VALUES 'FT' & 'LT'
2331
2332 005720 013705 001330 GETTRK: MOV LT,R5 ;GET MAXIMUM TRACK ADDRESS
2333 005724 163705 001332 SUB FT,R5 ;SUBTRACT MINIMUM TRACK ADDRESS
2334 005730 001403 BEQ 1$ ;BR IF MIN & MAX THE SAME
2335 005732 005205 INC R5 ;INCREMENT DIFFERENCE TO USE AS DIVISOR
2336 005734 004737 011600 JSR PC,GETREM ;GET THE RANDOM TRACK AUGMENT
2337 005740 063705 001332 1$: ADD FT,R5 ;CONVERT AUGMENT TO AN ADDRESS
2338 005744 110560 000013 MOVB R5,STRK(RO) ;STORE TRACK ADDRESS IN DPB
2339
2340 ;GENERATE A RANDOM CYLINDER ADDRESS BETWEEN VALUES 'FC' & 'LC'
2341
2342 005750 013705 001324 GETCYL: MOV LC,R5 ;GET MAXIMUM CYLINDER ADDRESS
2343 005754 163705 001326 SUB FC,R5 ;SUBTRACT MINIMUM CYLINDER ADDRESS
2344 005760 001403 BEQ 1$ ;BR IF MIN & MAX THE SAME
2345 005762 005205 INC R5 ;INCREMENT DIFFERENCE TO USE AS DIVISOR
2346 005764 004737 011600 JSR PC,GETREM ;GET THE RANDOM AUGMENT
2347 005770 063705 001326 1$: ADD FC,R5 ;CONVERT AUGMENT TO AN ADDRESS
2348 005774 010560 000010 MOV R5,SCYL(RO) ;STORE CYLINDER ADDRESS IN DPB
2349
2350 ;GENERATE A RANDOM BUFFER LENGTH BETWEEN 4 & THE VALUE IN 'BUFRSZ'
2351
2352 006000 013705 001306 GETSIZ: MOV BUFRSZ,R5 ;GET BUFFER SIZE
2353 006004 005205 INC R5 ;INCREMENT THE MAXIMUM SIZE
2354 006006 004737 011600 JSR PC,GETREM ;DIVIDE BY MAX VALUE
2355 006012 005705 TST R5 ;IS THE REMAINDER 0 ?
2356 006014 001413 BEQ 1$ ;ZERO, TRY AGAIN
2357 006016 010546 MOV R5,-(SP) ;NEW WORD LENGTH ON STACK FOR CHECK
2358 006020 005046 CLR -(SP) ;MAKE UPPER DIVIDEND ZERO
2359 006022 012746 000400 MOV #256,-(SP) ;SECTOR SIZE IS THE DIVISOR
2360 006026 004737 020206 JSR PC,SDIV ;DIVIDE BUFFER SIZE BY SECTOR SIZE
2361 006032 021627 000004 CMP (SP),#4 ;SEE IF REMAINDER LESS THAN 4
2362 006036 103005 BHS 2$ ;BR IF NOT
2363 006040 062706 000004 ADD #4,SP ;CORRECT THE STACK POINTER
2364 006044 004737 020522 1$: JSR PC,BRAND ;CYCLE THE RANDOM NUMBER GENERATOR
2365 006050 000753 BR GETSIZ ;TRY AGAIN
2366 006052 122760 000004 2$: BITB #4,SCOMD(RO) ;READ OR WRITE ?
2367 006060 001002 BNE 3$ ;BR IF READ
2368 006062 042705 000001 BIC #1,R5 ;MAKE THE SIZE EVEN
2369 006066 010560 000020 3$: MOV R5,SWORDL(RO) ;WORD LENGTH TO CONTROL BLOCK
2370 006072 122760 000013 000002 CHPB #WRITE,SCOMD(RO) ;WRITE WITHOUT IMPLIED SEEK ?
2371 006100 001404 BEQ 4$ ;BR IF IT IS
2372 006102 122760 000017 000002 CHPB #READ,SCOMD(RO) ;READ WITHOUT IMPLIED SEEK ?
2373 006110 001027 BNE 4$ ;BR IF NOT
2374 006112 005016 4$: CLR (SP) ;CLEAR THE STACK

```



```

2375 006114 116016 000012          MOVB    SSEC(RO), (SP)      ;MOVE THE SECTOR ADDRESS
2376 006120 066616 000002          ADD     2(SP), (SP)       ;ADD THE NUMBER OF SECTORS IN THE BUFFER
2377 006124 022716 000010          CMP     #8., (SP)        ;DO THEY EXCEED THE TRACK
2378 006130 103017          BHS     6$               ;BR IF NOT
2379 006132 132760 000010 000002      BITB    #10, SCONND(RO)   ;SEE IF AN 'IMPLIED SEEK' COMMAND
2380 006140 001413          BEQ     6$               ;BR IF NOT
2381 006142 132760 000004 000002      BITB    #4, SCONND(RO)   ;READ WITHOUT IMPLIED SEEK ?
2382 006150 001004          BNE     5$               ;BR IF READ
2383 006152 112760 000003 000002      MOVB    #WRTSEK, SCONND(RO) ;LOAD COMMAND
2384 006160 000403          BR     6$               ;CONTINUE
2385 006162 112760 000005 000002 5$: MOVB    #RDSEK, SCONND(RO) ;LOAD COMMAND
2386 006170 062706 000004 6$: ADD     #4, SP           ;CORRECT THE STACK POINTER
2387 006174 016060 000020 000004      MOV     SWRD(RO), SWRD(RO) ;SETUP WORD COUNT
2388 006202 005460 000004          NEG     SWRD(RO)         ;MAKE IT NEGATIVE
2389
2390          ;GET THE PATTERN CODE & EXIT FROM PARAMETER SELECTION
2391
2392          PATCOD: JSR     PC, GETPAT      ;GET PATTERN CODE
2393 006206 004737 006304          MOVB    R5, SPATTC(RO)   ;MOVE PATTERN CODE TO CONTROL BLOCK
2394 006212 110560 000026          PARXIT: MOV     FAIRNS, SFAIR(RO) ;LOAD 'FAIRNESS' COUNT
2395 006216 013760 001254 000064      MOV     (SP)+, R5        ;RESTORE R5
2396 006224 012605          RTS     PC               ;RETURN
2397 006226 000207
2398
2399          ;ROUTINE TO SELECT A WRITE (OR WRITE CHECK) OPERATION
2400
2401          RANWRT: MOV     #3, R5        ;WRITE OPERATION SELECTION DIVISOR
2402 006230 012705 000003          JSR     PC, GETREM      ;GET SELECTION CODE
2403 006234 004737 011600          TST     AUTOCK         ;ARE WRITE CHECK ORDERS TO BE SELECTED
2404 006240 005737 001322          ;RANDOMLY ?
2405          BEQ     1$          ;BR IF THEY ARE
2406 006244 001403          BIC     #2, R5         ;SET CODE TO EXCLUDE WRITE CHECK ORDERS
2407 006246 042705 000002          BR     2$             ;FINISH
2408 006252 000410          1$: CMP     R5, #2     ;WRITE CHECK SELECTED ?
2409 006254 020527 000002          BNE     2$             ;BR IF NOT
2410 006260 001005          BITB    #BIT02, SPREVO(RO) ;WAS PREVIOUS ORDER A WRITE ?
2411 006262 132760 000004 000024      BEQ     2$             ;BR IF IT WAS
2412 006270 001401          CLR     R5             ;CHANGE WRITE CHECK CODE TO WRITE WITH
2413 006272 005005          ;IMPLIED SEEK
2414 006274 116560 025756 000002 2$: MOVB    CONTBL(R5), SCONND(RO) ;CODE TO DRIVE BLOCK
2415 006302 000207          RTS     PC             ;RETURN
2416
2417          ;ROUTINE TO SELECT A PATTERN
2418
2419          GETPAT: MOV     #16, R5       ;SELECT PATTERN
2420 006304 012705 000020          JSR     PC, GETREM      ;GET CODE
2421 006310 004737 011600          TST     R5             ;WAS PATTERN ZERO SELECTED ?
2422 006314 005705          BNE     1$             ;BR IF NOT ZERO
2423 006316 001003          JSR     PC, SRAND       ;CYCLE THE RANDOM NUMBER GENERATOR
2424 006320 004737 020522          BR     GETPAT          ;TRY AGAIN
2425 006324 000767          1$: ASL     R5           ;MAKE CODE INTO TABLE INDEX
2426 006326 006305          RTS     PC             ;RETURN
2427 006330 000207
2428
2429          ;ROUTINE TO SETUP PARAMETERS FOR A SEQUENTIAL READ OR WRITE OF THE DISK
2430
2431          WRTPK: JSR     PC, SRAND       ;CYCLE THE RANDOM NUMBER GENERATOR
2432 006332 004737 020522          TST     $OPERC+2(RO)   ;SEE IF FIRST OPERATION
2433 006336 005760 000036
    
```

```

006342 001007      BNE      WRTPK1      ;BR IF UPPER WORD OF COUNTER NOT ZERO
006344 005760 000034  TST      $OPERC(RD) ;LOWER WORD ZERO ?
006350 001004      BNE      WRTPK1      ;BR IF NOT 1ST OPERATION
006352 105760 000022  TSTB    $SPACK(RD)   ;SEE WHICH - 'R' OR 'M'
006356 100504      BMI      WRTPK3      ;BR IF 'M'
006360 000477      BR       WRTPK2      ;'R' OPERATION
006362 032777 000040 172550 WRTPK1: BIT    $SMD5,$SMR    ;LOOP ON LAST ADDRESS ?
006370 001106      BNE      WRTPK4      ;BR IF LOOP
006372 032760 000002 000070  BIT    $EOP,$RPER(RD) ;DID LAST ORDER OVERFLOW ?
006400 001032      BNE      1$          ;BR IF IT DID
006402 116060 000002 000024  MOVB   $COMND(RD),$SPREV0(RD) ;SAVE CURRENT PARAMETERS
006410 004737 006616  JSR     PC,PREVST   ;SAVE CURRENT SECTOR & TRACK
006414 016060 000106 000032  MOV    $SUCA(RD),$SPREVA+2(RD) ;CURRENT CYLINDER
006422 016060 000102 000012  MOV    $SPDA(RD),$SSEC(RD)     ;NEW SECTOR & TRACK ADDRESS
006430 042760 000360 000012  BIC    $360,$SSEC(RD)        ;CLEAR THE 'SOT' BITS
006436 016060 000100 000010  MOV    $SPCA(RD),$CYL(RD)     ;NEW CYLINDER ADDRESS
006444 026037 000010 001324  CMP    $CYL(RD),LC           ;SEE IF END CYLINDER
006452 103427      BLO     2$          ;BR IF NOT
006454 101004      BMI     1$          ;BR IF PAST END CYLINDER
006456 126037 000013 001330  CMPB   $TRK(RD),LT         ;END TRACK ?
006464 101422      BLOS   2$          ;BR IF NOT EXCEEDED
006466 113760 001332 000013 1$:   MOVB   FT,$TRK(RD)       ;RESET TRACK ADDRESS
006474 113760 001336 000012  MOVB   FS,$SSEC(RD)        ;RESET SECTOR ADDRESS
006502 013760 001326 000010  MOV    FC,$CYL(RD)         ;RESET CYLINDER ADDRESS
006510 004737 011410  JSR     PC,NRML2         ;DROP THE UNIT (NORMAL TERMINATION)
006514 032777 000020 172416  BIT    $SMD4,$SMR         ;IS SWITCH 4 SET ?
006522 001003      BNE     2$          ;BR IF SET
006524 005726      TST    (SP)+           ;INCREMENT THE STACK POINTER
006526 000137 003650  JMP     MAIN            ;RETURN DIRECTLY TO 'MAIN'
006532 013760 001306 000020 2$:   MOV    BUFRSZ,$SMDL(RD)    ;BUFFER SIZE IS MAXIMUM
006540 013760 001306 000004  MOV    BUFRSZ,$SMDM(RD)    ;WORD COUNT
006546 005460 000004  NEG    $SMDM(RD)          ;CHANGE WORD COUNT TO 2'S COMPLEMENT
006552 105760 000022  TSTB   $SPACK(RD)        ;READ OR WRITE ?
006556 100404      BMI     WRTPK3      ;BR IF WRITE
006560 112760 000005 000002 WRTPK2: MOVB   $ROSEK,$COMND(RD) ;OP CODE
006566 000407      BR       WRTPK4      ;EXIT
006570 112760 000003 000002 WRTPK3: MOVB   $WRTSEK,$COMND(RD) ;OP CODE
006576 004737 006304  JSR     PC,GETPAT       ;GET PATTERN CODE
006602 110560 000026  MOVB   RS,$PATT(RD)      ;PATTERN CODE
006606 013760 001254 000064 WRTPK4: MOV    FAIRMS,$FAIR(RD) ;LOAD 'FAIRNES' COUNT
006614 000207      RTS     PC           ;RETURN

;DECREMENT AND SAVE CURRENT SECTOR & TRACK ADDRESS
PREVST: SUB    $4,SP         ;MAKE ROOM ON THE STACK
        JSR    PC,READOR  ;DECREMENT SECTOR-TRACK ADDRESS
        MOVB  (SP)+,$SPREVA+1(RD) ;SAVE CURRENT TRACK
        MOVB  (SP)+,$SPREVA(RD)   ;SAVE CURRENT SECTOR
        RTS    PC          ;RETURN

;*****
.SBTTL  GENERAL SUPPORT SUBROUTINES
;*****

```

006342
006344
006350
006352
006356
006360
006362
006370
006372
006400
006402
006410
006414
006422
006430
006436
006444
006452
006454
006456
006464
006466
006474
006502
006510
006514
006522
006524
006526
006532
006540
006546
006552
006556
006560
006566
006570
006576
006602
006606
006614
006616
006622
006626
006632
006636

```

;DUMMY HANDLER IF 'CONTROL C' ENTERED DURING NORMAL OPERATION
006640 012746 000003 DORTI: MOV #3, -(SP) ;PUT THE 'CONTROL C' BACK ON THE STACK
006644 000137 017100 JMP STKSRV+52 ;RETURN TO THE ENTRY ROUTINE

;ROUTINE TO COMPRESS THE TABLE WHOSE ADDRESS IS IN R1
006650 016111 000002 CMPRES: MOV 2(R1), (R1) ;COMPRESS THE TABLE IN R1
006654 001403 BEQ 1$ ;BR WHEN ZERO FOUND
006656 062701 000002 ADD #2, R1 ;INCREMENT R1
006662 000772 BR CMPRES ;CONTINUE COMPRESSING TABLE
006664 000207 1$: RTS PC ;RETURN

;DECREMENT THE SECTOR-TRACK ADDRESS
006666 005066 000004 READR: CLR 4(SP) ;CLEAR STACK FOR SECTOR
006672 116066 000102 000004 MOVB $APDA(R0), 4(SP) ;INCREMENTED SECTOR ON STACK
006700 042766 177760 000004 BIC #17, 4(SP) ;CLEAR THE '501' BITS
006706 105366 000004 DECB 4(SP) ;DECREMENT THE SECTOR ADDRESS
006712 100017 BPL 1$ ;BR IF SECTOR GREATER THAN 0
006714 012766 000011 000004 MOV #9, 4(SP) ;JAM SECTOR ADDRESS TO 9
006722 005066 000002 CLR 2(SP) ;CLEAR STACK FOR TRACK
006726 116066 000103 000002 MOVB $APDA+1(R0), 2(SP) ;TRACK ADDRESS
006734 105366 000002 DECB 2(SP) ;DECREMENT TRACK ADDRESS
006740 100007 BPL 2$ ;BR IF IT DIDN'T GO NEG
006742 012766 000023 000002 MOV #19, 2(SP) ;RESET TRACK TO 19(10)
006750 000403 BR 2$
006752 116066 000103 000002 1$: MOVB $APDA+1(R0), 2(SP) ;TRACK ADDRESS
006760 000207 2$: RTS PC ;RETURN

;ROUTINE TO CHECK FOR KM11-L OR KM11-P CLOCKS
006762 012737 177777 001236 CKCLK: MOV #1, CLKFLG ;CLEAR CLOCK AVAILABILITY FLAG
006770 012737 007044 000004 MOV #CKCLK1, @ERRVEC ;SET UP VECTOR FOR CLOCK CHECK
006776 005037 000006 CLR @ERRVEC+2 ;NEW PSM
007002 005777 172216 TST @SLKCSR ;CHECK FOR KM11-P
007006 005037 001236 CLR CLKFLG ;SET CLOCK AVAILABILITY FLAG
007012 013701 001230 MOV $LPVEC, R1 ;KM11-P VECTOR ADDRESS
007016 012721 007660 MOV #CLOCK, (R1)+ ;SET UP KM11-P VECTOR
007022 012711 000300 MOV #300, (R1) ;PSM - PRI 6
007026 012777 177777 172172 MOV #1, @SLKCSB ;LOAD COUNTER BUFFER WITH 1'S
007034 012777 000135 172162 MOV #135, @SLKCSR ;SET CLOCK - CNT UP, 16MS, CONT INT
007042 000425 BR CKCLK3
007044 062706 000004 CKCLK1: ADD #4, SP ;RESTORE THE STACK POINTER
007050 012737 007112 000004 MOV #CKCLK2, @ERRVEC ;CHANGE ERROR VECTOR TO CHECK FOR KM11-L
007056 005777 172150 TST @SLKS ;LOOK FOR KM11-L
007062 005037 001236 CLR CLKFLG ;SET CLOCK FLAG
007066 013701 001234 MOV $LVEC, R1 ;KM11-L VECTOR ADDRESS
007072 012721 007660 MOV #CLOCK, (R1)+ ;SET UP KM11-L VECTOR
007076 012711 000300 MOV #300, (R1) ;PSM - PRI 6
007102 012777 000100 172122 MOV #100, @SLKS ;SET KM11-L INTERRUPT
007110 000402 BR CKCLK3
007112 062706 000004 CKCLK2: ADD #4, SP ;RESTORE THE STACK POINTER
007116 012737 000006 000004 CKCLK3: MOV #6, @ERRVEC ;RESTORE THE ERROR VECTOR
007124 000207 RTS PC

```

;ROUTINE TO DISPLAY STATISTICS FOR ALL DRIVES ASSIGNED

007126	104412			STATPR: SAVREG							
007130	005004			CLR	R4						:SAVE R0-R5
007132	012703	000010		MOV	#R3						:R4 CONTAINS THE UNIT POINTER
007136	012700	024274		MOV	#BLKD,R0						:R3 CONTAINS THE UNIT COUNTER
007142	136437	021304	025460	18:	BITB	ATABIT(R4),ASMLST					:ADDR OF FIRST COUNTER
007150	001006			BNE	25						:SEE IF DRIVE ASSIGNED
007152	005204			INC	R4						:BR IF IT IS
007154	062700	000112		ADD	#SSILO+2,R0						:INCREMENT THE UNIT POINTER
007160	005303			DEC	R3						:INCREMENT THE BLOCK ADDRESS
007162	001357			BNE	18						:FINISHED ?
007164	000423			BR	65						:BR IF NOT
007166	004737	007270		JSR	PC,SHDTYP						:YES, EXIT
007172	136437	021304	025460	38:	BITB	ATABIT(R4),ASMLST					:TYPE THE HEADING
007200	001003			BNE	45						:IS THE UNIT ASSIGNED
007202	062700	000112		ADD	#SSILO+2,R0						:BR IF ASSIGNED
007206	000407			BR	55						:ADD TABLE SIZE TO ADDRESS
007210	010002			45:	MOV	R0,R2					:PUT BLOCK ADDRESS IN R2
007212	062702	000034		ADD	#SOPERC,R2						:FIRST COUNTER TO DISPLAY
007216	004737	007306		JSR	PC,SDETAL						:TYPE THE STATISTICS
007222	062700	000112		ADD	#SSILO+2,R0						:INCREMENT BLOCK ADDRESS
007226	005204			55:	INC	R4					:INCREMENT UNIT NUMBER
007230	005303			DEC	R3						:DECREMENT UNIT COUNTER
007232	001357			BNE	38						:BR IF NOT FINISHED
007234	104413			65:	RESREG						:RESTORE R0-R5
007236	000207			RTS	PC						

;ROUTINE TO TYPE STATISTICS FOR THE DRIVE IN R0

007240	104412			TYPEST: SAVREG							
007242	004737	007270		JSR	PC,SHDTYP						:SAVE R0-R5
007246	005004			CLR	R4						:TYPE THE HEADING
007250	111004			MOVB	(R0),R4						:CLEAR R4 FOR DRIVE NUMBER
007252	010002			MOV	R0,R2						:DRIVE NUMBER
007254	062702	000034		ADD	#SOPERC,R2						:PUT BLOCK ADDRESS IN R2
007260	004737	007306		JSR	PC,SDETAL						:ADDRESS OF 'SOPERC' IN PRESENT CLOCK
007264	104413			RESREG							:TYPE THE STATISTICS
007266	000207			RTS	PC						:RESTORE R0-R5
											:RETURN

;TYPE THE HEADER FOR THE DRIVE PERFORMANCE SUMMARY TYPEOUT

007270	104401	001213		SHDTYP: TYPE	SCRLF						:CR-LF
007274	004737	007634		JSR	PC,STIME						:TYPE THE TIME OF DAY
007300	104401	032646		TYPE	STATHD						:HEADER
007304	0002C7			RTS	PC						:RETURN

;TYPE THE DRIVE PERFORMANCE DATA LINE

007306	010446			SDETAL: MOV	R4,-(SP)						:DRIVE NUMBER
007310	104403			TYPOS							:TYPE IT
007312	001	000		BYTE	1,0						
007314	104401	032477		TYPE	SPACE3						:SPACES
007320	016046	000062		MOV	\$PASSC(R0),-(SP)						:PUT THE PASS COUNT ON THE STACK
007324	004737	015574		JSR	PC,\$582D						:CONVERT IT
007330	004737	011642		JSR	PC,\$APZRS						:TYPE IT

```

2599 007334 104401 032500      TYPE      SPACE2      : SPACES
2600 007340 010246      MOV      R2,-(SP)      : PUT $OPERC ON THE STACK
2601 007342 004737 020624      JSR      PC,$DB20      : CONVERT IT
2602 007346 004737 011622      JSR      PC,$RPZR8      : TYPE $OPERC
2603 007352 104401 032500      TYPE      SPACE2      : SPACES
2604 007356 062702 000004      ADD      #4,R2          : INCREMENT R2
2605 007362 010246      MOV      R2,-(SP)      : PUT $POSIT ON THE STACK
2606 007364 004737 020624      JSR      PC,$DB20      : CONVERT IT
2607 007370 004737 011622      JSR      PC,$RPZR8      : TYPE $POSIT
2608 007374 104401 032500      TYPE      SPACE2      : SPACES
2609 007400 062702 000004      ADD      #4,R2          : INCREMENT R2
2610 007404 010246      MOV      R2,-(SP)      : PUT $READ ON THE STACK
2611 007406 004737 020624      JSR      PC,$DB20      : CONVERT $READ
2612 007412 004737 011652      JSR      PC,$RPZR0      : TYPE IT
2613 007416 104401 032501      TYPE      SPACE1      : 1 SPACE
2614 007422 062702 000004      ADD      #4,R2          : INCREMENT R2
2615 007426 010146      1S:     MOV      R1,-(SP)      : SAVE R1
2616 007430 012701 000004      MOV      #4,R1          : USE R1 AS A COUNTER
2617 007434 062702 000002      ADD      #2,R2          : INCREMENT R2 AGAIN
2618 007440 012246      2S:     MOV      (R2)+,-(SP)      : PUT '$SOFT', '$SHARD', '$SKI', OR '$MISPO'
2619                                     : ON THE STACK
2620 007442 004737 015574      JSR      PC,$SB20      : CONVERT IT
2621 007446 004737 011632      JSR      PC,$RPZR4      : TYPEOUT
2622 007452 104401 032501      TYPE      SPACE1      : 1 SPACE
2623 007456 005301      DEC      R1              : DONE ?
2624 007460 001367      BNE      2$              : BR IF NOT
2625 007462 012601      MOV      (SP)+,R1        : RESTORE R1
2626 007464 016046 000050      MOV      $TOTAL(R0),-(SP) : CALCULATE NUMBER OF OTHER ERRORS
2627 007470 166016 000052      SUB      $SOFT(R0),(SP)  : SUBTRACT $SOFT FROM $TOTAL
2628 007474 166016 000054      SUB      $SHARD(R0),(SP) : SUBTRACT $SHARD FROM $TOTAL
2629 007500 166016 000056      SUB      $SKI(R0),(SP)   : SUBTRACT $SKI FROM $TOTAL
2630 007504 166016 000060      SUB      $MISPO(R0),(SP) : SUBTRACT $MISPO FROM $TOTAL
2631 007510 004737 015574      JSR      PC,$SB20      : CONVERT 'OTHER' COUNT
2632 007514 004737 011632      JSR      PC,$RPZR4      : TYPE IT
2633 007520 104401 001213      TYPE      $CALF
2634 007524 000207      RTS      PC
2635
2636      ;ROUTINE TO INCREMENT $SOFT
2637
2638      ;NOTE: $SOFT WILL NOT BE INCREMENTED BEYOND 9999 (10)
2639
2640 007526 026027 000052 023417 INCSOF: CMP      $SOFT(R0),#9999. : IS $SOFT ALREADY AT MAXIMUM ?
2641 007534 103002      BHS      1$              : BR IF IT IS
2642 007536 005260 000052      INC      $SOFT(R0)      : INCREMENT $SOFT
2643 007542 000207      1S:     RTS      PC          : RETURN
2644
2645      ;ROUTINE TO INCREMENT $SHARD
2646
2647      ;NOTE: $SHARD WILL NOT BE INCREMENTED BEYOND 9999 (10)
2648
2649 007544 026027 000054 023417 INCHRD: CMP      $SHARD(R0),#9999. : IS $SHARD ALREADY AT MAXIMUM ?
2650 007552 103002      BHS      1$              : BR IF IT IS
2651 007554 005260 000054      INC      $SHARD(R0)     : INCREMENT $SHARD
2652 007560 000207      1S:     RTS      PC          : RETURN
2653
2654      ;ROUTINE TO INCREMENT $SKI

```

```

2655
2656
2657
2658 007562 026027 000056 023417 INCSKI: CMP     $SKI(RO),#9999.  ;IS $SKI ALREADY AT MAXIMUM ?
2659 007570 103002          BHIS     IS                ;BR IF IT IS
2660 007572 005260 000056          INC     $SKI(RO)          ;INCREMENT $SKI
2661 007576 000207          IS:      RTS      PC                ;RETURN
2662
2663
2664
2665
2666
2667 007600 026027 000060 023417 INCMIS: CMP     SMISPO(RO),#9999. ;IS SMISPO ALREADY AT MAXIMUM ?
2668 007606 103002          BHIS     IS                ;BR IF IT IS
2669 007610 005260 000060          INC     SMISPO(RO)       ;INCREMENT SMISPO
2670 007614 000207          IS:      RTS      PC                ;RETURN
2671
2672
2673
2674
2675
2676 007616 026027 000050 023417 INCTOT: CMP     $TOTAL(RO),#9999. ;IS $TOTAL ALREADY AT MAXIMUM ?
2677 007624 103002          BHIS     IS                ;BR IF IT IS
2678 007626 005260 000050          INC     $TOTAL(RO)      ;INCREMENT $TOTAL
2679 007632 000207          IS:      RTS      PC                ;RETURN
2680
2681
2682
2683
2684
2685
2686
2687
2688
2689
2690
2691
2692
2693
2694 007634 005737 001236 STIME:  TST     CLKFLG          ;CLOCK ON THE SYSTEM ?
2695 007640 001006          BNE     IS                ;BR IF NOT
2696 007642 104401 010130          TYPE   ,HOUR             ;TYPE THE HOURS
2697 007646 104401 010134          TYPE   ,MINUTE          ;TYPE THE MINUTES
2698 007652 104401 010140          TYPE   ,SECOND          ;TYPE THE SECONDS
2699 007656 000207          IS:      RTS      PC
2700
2701
2702
2703
2704
2705
2706
2707
2708
2709
2710
;ROUTINE TO INCREMENT $MISPO
;NOTE: $MISPO WILL NOT BE INCREMENTED BEYOND 9999 (10)
;ROUTINE TO INCREMENT $TOTAL
;NOTE: $TOTAL WILL NOT BE INCREMENTED BEYOND 9999 (10)
;ROUTINE TO TYPE THE TIME
;CLOCK HANDLER ROUTINE
CLOCK:  MOV     RO,-(SP)          ;SAVE RO
        INC     SIXTEE          ;INCREMENT THE 1/60 SECOND COUNTER
        BNE     IS                ;BR IF A SECOND NOT COUNTED
        MOV     #2,SIXTEE        ;RESTORE THE VALUE
        NEG     SIXTEE          ;MAKE IT INTO 2'S COMP
        INCB   SECOND+1        ;INCREMENT THE SECONDS
        CMPB   #72,SECOND+1    ;SEE IF COUNTER AT MAX
        BNE     IS                ;BR IF NOT
        MOVB  #60,SECOND+1     ;RESTORE VALUE
        INCB   SECOND          ;INCREMENT UPPER
        CMPB   #66,SECOND      ;UPPER AT MAX
        BNE     IS                ;BR IF NOT
        MOVB  #60,SECOND       ;RESET UPPER
        INCB   INTRVL+1        ;INCREMENT STATISTICS TYPEOUT INTERVAL
        INCB   MINUTE+1        ;INCREMENT MINUTE
        CMPB   #72,MINUTE+1    ;AT MAX ?
        BNE     IS                ;BR IF NOT
        MOVB  #60,MINUTE+1     ;RESET LOWER
    
```

```

2711 007774 105237 010134      INCB  MINUTE      ; INCREMENT UPPER HALF
2712 010000 122737 000066 010134  CMPB  #66,MINUTE ; AT MAX ?
2713 010006 001026      BNE   1$        ; BR IF NOT
2714 010010 112737 000060 010134  MOVB  #60,MINUTE ; RESET UPPER
2715 010016 105237 010131      INCB  HOUR+1     ; INCREMENT HOURS
2716 010022 022737 035071 010130  CMP   #35071,HOUR ; AT MAX (99) ?
2717 010030 001412      BEQ   2$        ; BR IF IT IS
2718 010032 122737 000072 010131  CMPB  #72,HOUR+1 ; AT MAX ?
2719 010040 001011      BNE   1$        ; BR IF NOT
2720 010042 112737 000060 010131  MOVB  #60,HOUR+1 ; RESET VALUE
2721 010050 105237 010130      INCB  HOUR       ; INCREMENT UPPER
2722 010054 000403      BR    1$
2723 010056 012737 030060 010130 2$:  MOV   #30060,HOUR ; RESET HOUR FIELD
2724 010064 012746 000021 1$:  MOV   #17,-(SP)  ; 17 MS ON THE STACK
2725 010070 004737 023360      JSR   PC,APTMR   ; DRIVER TIMER ROUTINE
2726 010074 115737 001312      TSTB  INTRVL     ; DISPLAY THE PERFORMANCE SUMMARY ?
2727 010100 001411      BEQ   3$        ; BR IF NOT
2728 010102 123737 001312 001313  CMPB  INTRVL,INTRVL+1 ; DISPLAY INTERVAL FINISHED ?
2729 010110 001005      BNE   3$        ; BR IF NOT
2730 010112 105037 001313      CLRB  INTRVL+1  ; RESTORE THE INTERVAL
2731 010116 012737 177777 001250  MOV   #-1,STATIN ; SET ERROR RATE DATA DISPLAY FLAG
2732 010124 012600 3$:  MOV   (SP)+,RO  ; RESTORE RO
2733 010126 000002      RTI
2734
2735 010130      060      060      HOUR:  .BYTE  60,60      ; HOURS
2736 010132      072      000      .BYTE  72,0          ; ' ' & TERMINATOR
2737 010134      060      060      MINUTE: .BYTE  60,60     ; MINUTES
2738 010136      072      000      .BYTE  72,0          ; ' ' & TERMINATOR
2739 010140      060      060      SECOND: .BYTE  60,60     ; SECONDS
2740 010142      040      000      .BYTE  40,0          ; SPACE, TERMINATOR
2741
2742
2743 010144 000000      SIXTEE: .WORD  0          ; 1/60TH OR 1/50TH OF A SECOND COUNTER
2744
2745      ;COMMAND DECODE ROUTINE
2746
2747 010146 104412      KSR:  SAVREG      ; SAVE R0-R5
2748 010150 012746 000200      MOV   #PR4,-(SP) ; RETURN AT PRIORITY 4
2749 010154 012746 010230      MOV   #KSR1,-(SP) ; DUMMY INTERRUPT RETURN
2750 010160 017746 170762      MOV   #STKB,-(SP) ; GET THE CHARACTER FROM THE KEYBOARD
2751 010164 042716 177600      BIC   #C177,(SP) ; CLEAR THE JUNK
2752 010170 021627 000007      CMP   (SP),#7    ; 'CONTROL G' ?
2753 010174 001010      BNE   1$        ; BR IF NOT
2754 010176 022737 000176 001140  CMP   #SWREG,SWR ; SOFTWARE SWITCH REGISTER ?
2755 010204 001004      BNE   1$        ; BR IF NOT ACTIVE
2756 010206 012766 010420 000002  MOV   #KSR2,2(SP) ; CHANGE THE RETURN ADDRESS
2757 010214 000403      BR    2$
2758 010216 012737 017026 000060 1$:  MOV   #STKSRV,TKVEC ; CHANGE KEYBOARD VECTOR ADDRESS
2759 010224 000137 017032 2$:  JMP   $TKSRV+4   ; PROCESS THE CHARACTER JUST ENTERED
2760 010230 104411      KSR1: RDLIN      ; READ THE KEYBOARD
2761 010232 012737 010146 000060  MOV   #KSR,TKVEC ; CHANGE THE KEYBOARD VECTOR
2762 010240 012605      MOV   (SP)+,RS  ; BUFFER ADDRESS
2763 010242 005205      INC   RS        ; POINT TO DRIVE NUMBER
2764 010244 104401 001213      TYPE  ,SCRLF    ; CR-LF
2765 010250 122715 000101      CMPB  #'A,(RS) ; EQ TO AN 'A'
2766 010254 001410      BEQ   1$        ; BR IF IT IS

```

2767	010256	121527	000067		CMPB	(R5),#67	:UNIT NUMBER GREATER THAN AN ASCII 7 ?	
2768	010262	101054			BHI	65	:BR IF IT IS	
2769	010264	121527	000060		CMPB	(R5),#60	:UNIT NUMBER LESS THAN AN ASCII 0 ?	
2770	010270	103451			BLO	65	:BR IF IT IS	
2771	010272	142715	177770		BICB	#1C7,(R5)	:LEAVE ONLY LOWER 3 BITS IF CHAR NOT 'A'	
2772	010276	122765	000124	177777	1S:	CMPB	#'T,-1(R5)	:EQ TO 'T'
2773	010304	001003			BNE	25	:BR IF NOT EQ	
2774	010306	004737	010424		JSR	PC,NEWASN	:ASSIGN UNIT FOR TEST	
2775	010312	000442			BR	KSR2	:EXIT	
2776	010314	122765	000104	177777	2S:	CMPB	#'D,-1(R5)	:EQ TO 'D' ?
2777	010322	001003			BNE	35	:BR IF NOT EQ	
2778	010324	004737	010664		JSR	PC,DEASGN	:DEASSIGN UNIT	
2779	010330	000433			BR	KSR2	:EXIT	
2780	010332	122765	000123	177777	3S:	CMPB	#'S,-1(R5)	:EQ TO 'S'
2781	010340	001003			BNE	45	:BR IF NOT EQ	
2782	010342	004737	010772		JSR	PC,SCMND	:TYPE STATISTICS	
2783	010346	000424			BR	KSR2	:EXIT	
2784	010350	122765	000127	177777	4S:	CMPB	#'W,-1(R5)	:EQ TO 'W'
2785	010356	001007			BNE	55	:BR IF NOT EQ	
2786	010360	032777	000001	170552		BIT	#SW0,JSWR	:IS SWITCH 0 SET ?
2787	010366	001012			BNE	65	:BR IF SET, CAN'T DO 'W' COMMAND	
2788	010370	004737	011074		JSR	PC,DATAPK	:WRITE A DATA PACK	
2789	010374	000411			BR	KSR2	:EXIT	
2790	010376	122765	000122	177777	5S:	CMPB	#'R,-1(R5)	:EQ TO 'R' ?
2791	010404	001003			BNE	65	:BR IF NOT EQ	
2792	010406	004737	011106		JSR	PC,REDAPK	:READ A DATA PACK	
2793	010412	000402			BR	KSR2	:EXIT	
2794	010414	104401	033146		6S:	TYPE	:TYPE 'INVALID COMMAND' MESSAGE	
2795	010420	104413			KSR2:	RESREG	:RESTORE R0-R5	
2796	010422	000002			RTI		:RETURN	

;ROUTINE TO ASSIGN A DRIVE ('T' COMMAND)

2800	010424	005037	001252		NEWASN:	CLR	PACK	:CLEAR 'W' COMMAND INDICATOR
2801	010430	005004			ASGNO:	CLR	R4	:R4 IS TABLE INDEX
2802	010432	012703	000010			MOV	#8,R3	:SET INITIAL COUNT TO 8
2803	010436	122715	000101			CMPB	#101,(R5)	:ASSIGN ALL UNITS?
2804	010442	001417				BEQ	ASGN2	:BR IF ALL UNITS
2805	010444	111504			ASGN1:	MOVB	(R5),R4	:PUT UNIT # IN R4
2806	010446	012737	032567	011140		MOV	#UNTASN,ASNMSG	: 'UNIT ASSIGNED' MESSAGE ADDR
2807	010454	012703	000001			MOV	#1,R3	:RELOAD R3 FOR 1 UNIT
2808	010460	136437	021304	025460		BITB	ATABIT(R4),ASNLST	:UNIT ALREADY ASSIGNED ?
2809	010466	001002				BNE	15	:BR IF IT IS
2810	010470	004737	010524			JSR	PC,ASGN3	:SEE IF UNIT ON THE SYSTEM
2811	010474	000137	011120		1S:	JMP	ASNERR	:RETURN HERE IF DRIVE NOT AVAIL
2812	010500	000207				RTS	PC	:EXIT
2813	010502	004737	010524		ASGN2:	JSR	PC,ASGN3	:ASSIGN ALL UNASSIGNED, AVAIL UNITS
2814	010506	000137	010514			JMP	15	:UNIT NOT ON SYSTEM
2815	010512	000207				RTS	PC	:EXIT
2816	010514	012746	010506		1S:	MOV	#ASGN2+4,-(SP)	:PUT RETURN ADDRESS ON THE STACK
2817	010520	000137	010626			JMP	ASGN4	:LOOK FOR MORE UNITS
2818	010524	136437	021304	025460	ASGN3:	BITB	ATABIT(R4),ASNLST	:UNIT ALREADY ASSIGNED ?
2819	010532	001035				BNE	ASGN4	:BR IF IT IS
2820	010534	005737	021124		1S:	TST	TRANSW	:DATA TRANSFER UNDER WAY ?
2821	010540	001375				BNE	15	:BR IF IT IS
2822	010542	110437	025414			MOVB	R4,GENDPB	:DRIVE NUMBER


```

2823 010546 004737 015354 JSR PC,RECALO ;RECALIBRATE DRIVE
2824 010552 105764 021112 TSTB DRVSTA(R4) ;DRIVE AVAILABLE?
2825 010556 001432 BEQ ASGN6 ;BR IF DRIVE OFFLINE
2826 010560 100435 BMI ASGN7 ;BR DRIVE NOT AVAILABLE
2827 010562 006304 ASL R4 ;MAKE R4 INTO WORD INDEX
2828 010564 016464 025736 025526 MOV BLKADR(R4),NEWUNT(R4) ;DPB ADDRESS
2829 010572 016400 025736 MOV BLKADR(R4),RO ;PUT BLOCK'S ADDR INTO RO
2830 010576 004737 011150 JSR PC,CLRDPB ;CLEAR BLOCK FOR UNIT JUST ASSIGNED
2831 010602 012760 000001 000062 MOV #1,$PASSC(RO) ;PRESET PASS COUNT TO 1
2832 010610 005737 001252 TST PACK ;WRITE DATA PACK ?
2833 010614 001403 BEQ 2$ ;BR IF NOT
2834 010616 113760 001252 000022 MOVB PACK,$PACK(RO) ;SET READ/WRITE DATA PACK INDICATOR
2835 010624 006204 2$: ASR R4 ;RESTORE UNIT ADDRESS
2836 010626 005303 ASGN4: DEC R3 ;DEC UNIT COUNT
2837 010630 001402 BEQ ASGN5 ;BR IF FINISHED
2838 010632 005204 INC R4 ;INCREMENT UNIT NUMBER
2839 010634 000733 BR ASGN3 ;CONTINUE
2840 010636 062716 000004 ASGN5: ADD #4,(SP) ;INCREMENT RETURN
2841 010642 000407 BR ASGN6 ;EXIT
2842 010644 012737 032524 011140 ASGN6: MOV #UNTOFF,ASNMSG ;'OFFLINE' MESSAGE ADDRESS
2843 010652 000403 BR ASGN8 ;EXIT
2844 010654 012737 032615 011140 ASGN7: MOV #NOTSAF,ASNMSG ;ADDR OF 'DRIVE UNSAFE' MESSAGE
2845 010662 000207 ASGN8: RTS PC ;RETURN
2846
2847 ;ROUTINE TO DEASSIGN A UNIT ('D' COMMAND)
2848
2849 010664 005004 DEASGN: CLR R4
2850 010666 122715 000101 CMPB #101,(R5) ;DEASSIGN ALL UNITS ?
2851 010672 001434 BEQ 5$ ;BR IF YES
2852 010674 012703 000001 MOV #1,R3 ;SET R3 FOR ONE UNIT
2853 010700 111504 MOVB (R5),R4 ;GET UNIT NUMBER
2854 010702 136437 021304 025460 1$: BITB ATABIT(R4),ASNLST ;UNIT ASSIGNED ?
2855 010710 001414 BEQ 3$ ;BR IF NOT
2856 010712 146437 021304 025460 BICB ATABIT(R4),ASNLST ;DELETE THE UNIT FROM THE ASSIGNED LIST
2857 010720 006304 ASL R4 ;MAKE ADDR INTO A WORD INDEX
2858 010722 016464 025736 025504 MOV BLKADR(R4),DUNIT(R4) ;PUT ADDRESS IN DEASSIGN LIST
2859 010730 006204 ASR R4
2860 010732 005303 2$: DEC R3 ;ANY MORE UNITS ?
2861 010734 001412 BEQ 4$ ;BR IF NOT
2862 010736 005204 INC R4
2863 010740 000760 BR 1$
2864 010742 122715 000101 3$: CMPB #101,(R5) ;DEASSIGN ALL UNITS ?
2865 010746 001771 BEQ 2$ ;BR IF YES
2866 010750 012737 032545 011140 MOV #UN,NOT,ASNMSG ;ADDR OF 'NOT ASSIGNED' MESSAGE
2867 010756 004737 011120 JSR PC,ASNERR ;REPORT IT
2868 010762 000207 4$: RTS PC
2869 010764 012703 000010 5$: MOV #8.,R3 ;SET UNIT COUNT TO 8
2870 010770 000744 BR 1$
2871
2872 ;ROUTINE TO TYPE UNIT PERFORMANCE SUMMARY ('S' COMMAND)
2873
2874 010772 005004 SCMD: CLR R4
2875 010774 122715 000101 CMPB #101,(R5) ;ALL STATISTICS ?
2876 011000 001421 BEQ 2$ ;BR IF YES
2877 011002 111504 MOVB (R5),R4 ;GET UNIT #
2878 011004 136437 021304 025460 BITB ATABIT(R4),ASNLST ;SEE IF UNIT ASSIGNED

```

```

2879 011012 001406      BEQ      1$      ;BR IF NOT
2880 011014 006304      ASL      R4      ;MAKE UNIT ADDR INTO WORD INDEX
2881 011016 016400 025736  MOV      BLKADR(R4),R0 ;ADDR OF BLOCK
2882 011022 004737 007240  JSR      PC,TYPEST ;TYPE DRIVE STATISTICS
2883 011026 000421      BR       5$      ;EXIT
2884 011030 012737 032545 011140 1$:  MOV      #UNTNOT,ASNMSG ;ADDR OF 'NOT ASSIGNED' MSG
2885 011036 004737 011120  JSR      PC,ASNERR ;TYPE ERROR MESSAGE
2886 011042 000413      BR       5$      ;EXIT
2887 011044 012703 000010 2$:  MOV      #8.,R3 ;UNIT COUNT
2888 011050 105737 025460 3$:  TSTB   ASNLIST ;SEE IF ANY UNIT ASSIGNED
2889 011054 001004      BNE     4$      ;BR IF ANY ARE
2890 011056 005204      INC     R4      ;INCREMENT UNIT ADDRESS
2891 011060 005303      DEC     R3      ;DECREMENT COUNTER
2892 011062 001372      BNE     3$      ;MORE TO CHECK ?
2893 011064 000402      BR       5$      ;NONE ASSIGNED, RETURN
2894 011066 004737 007126 4$:  JSR      PC,STATPR ;TYPE ALL STATISTICS
2895 011072 000207 5$:  RTS      PC
2896
2897 ;ROUTINE TO WRITE A DATA PACK ('W' COMMAND)
2898
2899 011074 012737 177777 001252 DATAPK: MOV      #-1,PACK ;SET THE 'W' COMMAND INDICATOR
2900 011102 000137 010430  JMP      ASGNO ;ASSIGN REQUESTED UNIT
2901
2902 ;ROUTINE TO READ A DATA PACK ('R' COMMAND)
2903
2904 011106 012737 000001 001252 REDAPK: MOV      #1,PACK ;SET THE 'READ' INDICATOR
2905 011114 000137 010430  JMP      ASGNO ;ASSIGN THE REQUESTED UNIT
2906
2907 ;TYPEOUT ASSIGN/DEASSIGN ERROR MESSAGE
2908
2909 ASNERR: TYPE      ,QUES ;QUESTION MARK
2910 011120 104401 033144  TYPE      ,UNTMMSG ;TYPE 'UNIT'
2911 011124 104401 032515  MOV      R4,-(SP) ;DRIVE NUMBER
2912 011130 010446  TYPEPOS ;TYPE IT
2913 011132 104403  .BYTE 1,0
2914 011134 001 000  TYPE      ,0 ;TYPE SPECIFIC MESSAGE
2915 011136 104401  ASNMSG: .WORD 0 ;MESSAGE ADDRESS
2916 011140 000000  TYPE      ,SCRLF
2917 011142 104401 001213  RTS      PC
2918 011146 000207
2919
2920 ;ROUTINE TO CLEAR THE DPB FOR THE ASSIGNED UNIT
2921
2922 CLRDPB:
2923 011150  MOV      R3,-(SP) ;: PUSH R3 ON STACK
2924 011150 010346  MOV      R4,-(SP) ;: PUSH R4 ON STACK
2925 011152 010446  MOV      R5,-(SP) ;: PUSH R5 ON STACK
2926 011154 010546  MOV      R0,R4 ;GET THE DPB ADDRESS
2927 011156 010004  ADD      #2,R4 ;ADDRESS OF FIRST LOCN TO BE CLEARED
2928 011160 062704 000002  MOV      #5,R3 ;NUMBER OF LOCNS TO BE CLEARED
2929 011164 012703 000005 1$:  CLR      (R4)+ ;CLEAR THE LOCATION
2930 011170 005024  DEC     R3 ;DECREMENT THE COUNTER
2931 011172 005303  BNE     1$ ;BR IF NOT FINISHED
2932 011174 001375  ADD      #2,R4 ;MOVE THE ADDRESS PAST THE 'REG' ADDR
2933 011176 062704 000002  MOV      #5,SILO-$REG,R3 ;NUMBER OF LOCNS TO BE CLEARED
2934 011202 012703 000074 2$:  CLR      (R4)+ ;CLEAR

```

```

2935 011210 162703 000002          SUB      #2,R3          ;DECREMENT THE LOCN COUNTER
2936 011214 001374          BNE     25          ;BR IF NOT FINISHED
2937 011216 012605          MOV     (SP)+,R5    ;POP STACK INTO R5
2938 011220 012604          MOV     (SP)+,R4    ;POP STACK INTO R4
2939 011222 012603          MOV     (SP)+,R3    ;POP STACK INTO R3
2940 011224 000207          RTS     PC
2941
2942          ;DEASSIGN A DRIVE IF A FATAL ERROR OCCURS
2943
2944 011226 011446          DROP:  MOV     (R4),-(SP) ;SAVE R4
2945 011230 005004          CLR     R4          ;CLEAR R4 FOR UNIT NUMBER
2946 011232 111004          MOV     (R0),R4     ;MOVE UNIT NUMBER TO R4
2947 011234 146437 021304 025460 BIC     ATABIT(R4),ASNLST ;REMOVE UNIT FROM ASSIGNED LIST
2948 011242 006304          ASL     R4          ;MAKE UNIT NUMBER INTO A TABLE INDEX
2949 011244 010064 025504          MOV     R0,DUNIT(R4) ;PUT UNIT IN DROP LIST
2950 011250 104401 001213          TYPE   ,SCLF        ;CR-LF
2951 011254 104401 001213          TYPE   ,SCLF        ;CR-LF
2952 011260 104401 033001          TYPE   ,DROPNNG     ;TYPE 'DROPPING UNIT'
2953 011264 104401 033103          TYPE   ,DRNUM       ;'DRIVE #'
2954 011270 111046          MOV     (R0),-(SP) ;DRIVE NUMBER
2955 011272 104403          TYPOS  ;TYPE IT
2956 011274 001 000          .BYTE  1,0
2957 011276 104401 001213          TYPE   ,SCLF        ;CR-LF
2958 011302 012604          MOV     (SP)+,R4    ;RESTORE R4
2959 011304 000207          RTS     PC          ;RETURN
2960
2961          ;ROUTINE TO DEASSIGN A UNIT IF ERRORS BECOMES EXCESSIVE
2962
2963 011306 032777 000020 167624 ABNRM:  BIT     #SW04,DSMR ;SEE IF SWITCH 4 SET
2964 011314 001006          BNE     15          ;BR IF IT'S SET
2965 011316 023760 001310 000050          CMP     MAXER,STOTAL(R0) ;CHECK TOTAL ERROR VALUE
2966 011324 101002          BHI     15          ;BR IF NOT AT MAXIMUM
2967 011326 000137 011226          JMP     DROP        ;DEASSIGN THE DRIVE
2968 011332 000207          15:   RTS     PC          ;RETURN
2969
2970          ;ROUTINE TO CHECK FOR END OF PASS AND END OF TEST
2971
2972 011334 005737 001316          NRML:  TST     SEKMOD ;END OF PASS DETERMINED BY SEEKS OR WORDS ?
2973 011340 001012          BNE     NRML1       ;BR IF SEEKS
2974 011342 026037 000046 001276          CMP     SREAD+2(R0),ENDCON+2 ;CHECK MSW OF WORDS READ COUNT
2975 011350 101017          BHI     NRML2       ;BR IF MSW GREATER THAN LIMIT
2976 011352 103405          BLO     NRML1       ;BR IF MSW LESS THAN LIMIT
2977 011354 026037 000044 001274          CMP     SREAD(R0),ENDCON ;CHECK LSM AGAINST LIMIT
2978 011362 103012          BHS     NRML2       ;BR IF EQUAL OR GREATER
2979 011364 000504          BR     NRMLX        ;EXIT
2980 011366 026037 000042 001302          NRML1: CMP     SPOSIT+2(R0),ENDSEK+2 ;CHECK MSW OF SEEK COUNT
2981 011374 101005          BHI     NRML2       ;BR IF MSW GREATER THAN LIMIT
2982 011376 103477          BLO     NRMLX        ;EXIT IF MSW LESS THAN LIMIT
2983 011400 026037 000040 001300          CMP     SPOSIT(R0),ENDSEK ;CHECK LSM OF SEEK COUNT
2984 011406 103473          BLO     NRMLX        ;EXIT IF LSM LESS THAN LIMIT
2985 011410 104401 001213          NRML2: TYPE   ,SCLF        ;CR-LF
2986 011414 104401 033035          TYPE   ,ENDPAS     ;END OF PASS FOR THE UNIT
2987 011420 016046 000062          MOV     SPASSC(R0),-(SP) ;PUT PASS COUNT ON THE STACK
2988 011424 104405          TYPOS  ;CONVERT PASS COUNT TO DECIMAL AND TYPE IT
2989 011426 032777 000020 167504          BIT     #SW04,DSMR ;SWITCH 4 SET ?
2990 011434 001016          BNE     15          ;BR IF SET

```

```

2991 011436 026037 000062 001304      CMP      SPASSC(RD),PASCNT      ;SEE IF AT END OF TEST
2992 011444 103412                      BLO      IS                    ;BR IF NOT
2993 011446 104401 033051      TYPE    ,ENDTST              ;TYPE 'END OF TEST'
2994 011452 104401 033103      TYPE    DRNUM                ;'DRIVE #'
2995 011456 111046      MOV     (RD),-(SP)           ;DRIVE NUMBER
2996 011460 104403      TYPOS   TYPE IT              ;TYPE IT
2997 011462 001 000                      .BYTE   1,0
2998 011464 104401 001213      TYPE    $CRLF                ;CR-LF
2999 011470 000430      BR      3S                   ;DEASSIGN THE DRIVE
3000 011472 104401 033103      TYPE    DRNUM                ;'DRIVE #'
3001 011476 111046      MOV     (RD),-(SP)           ;DRIVE NUMBER
3002 011500 104403      TYPOS   TYPE IT              ;TYPE IT
3003 011502 001 000                      .BYTE   1,0
3004 011504 104401 001213      TYPE    $CRLF                ;CR-LF
3005 011510 004737 007240      JSR     PC,TYPEST            ;TYPE THE UNIT'S STATISTICS
3006 011514 010346      MOV     R3,-(SP)             ;SAVE R3
3007 011516 010446      MOV     R4,-(SP)             ;SAVE R4
3008 011520 010004      MOV     R0,R4                ;UNIT'S BLOCK ADDRESS
3009 011522 062704 000034      ADD     #SOPERC,R4           ;ADD THE STARTING ADDR OF SECTIONS TO CLEAR
3010 011526 012703 000006      MOV     #6,R3                ;NUMBER OF LOCHS TO BE CLEARED
3011                                     ;(ERROR COUNTERS NOT CLEARED)
3012 011532 005024      2S:   CLR     (R4)+           ;CLEAR THE LOCH
3013 011534 005303      DEC     R3                   ;DECREMENT THE LOCATION COUNTER
3014 011536 001375      BNE     2S                    ;BR IF MORE TO GO
3015 011540 012604      MOV     (SP)+,R4             ;RESTORE R4
3016 011542 012603      MOV     (SP)+,R3             ;RESTORE R3
3017 011544 005260 000062      INC     SPASSC(RD)           ;INCREMENT THE PASS COUNT
3018 011550 000412      BR      NRM LX               ;EXIT
3019 011552 104401 001213      3S:   TYPE    $CRLF
3020 011556 005004      CLR     R4                    ;CLEAR R4 FOR DRIVE NUMBER
3021 011560 111004      MOV     (RD),R4              ;MOVE DRIVE NUMBER
3022 011562 146437 021304 025460      BICB   ATABIT(R4),ASNLST    ;DELETE DRIVE FROM ASSIGNED LIST
3023 011570 006304      ASL     R4                    ;MAKE DRIVE NUMBER INTO TABLE INDEX
3024 011572 010064 025504      MOV     R0,DUNIT(R4)        ;PUT BLOCK ADDRESS INTO DROP LIST
3025 011576 000207      NRM LX: RTS                  ;RETURN
3026                                     ;ROUTINE TO GET THE REMAINDER OF THE RANDOM NUMBER
3027
3028
3029 011600 013746 020620      GETREN: MOV     SHNUM,-(SP)    ;LOWER DIVIDEND
3030 011604 005046      CLR     -(SP)                ;UPPER DIVIDEND
3031 011606 010546      MOV     R5,-(SP)            ;PUT DIVISOR ON THE STACK
3032 011610 004737 020206      JSR     PC,$DIV              ;PUT THE REMAINDER INTO R5
3033 011614 012605      MOV     (SP)+,R5            ;ADJUST THE STACK POINTER
3034 011616 005726      TST     (SP)+
3035 011620 000207      RTS     PC
3036                                     ;ROUTINE TO REPLACE LEADING ZEROS IN A NUMERIC STRING WITH SPACES
3037
3038
3039 011622 012737 000004 011742      SRPZR8: MOV     #4,RPZRC      ;SETUP TO TYPE 8 SIGNIFICANT DIGITS
3040 011630 000412      BR      RPZERO               ;TYPE THE VALUE
3041 011632 012737 000006 011742      SRPZR4: MOV     #6,RPZRC      ;SETUP TO TYPE 4 SIGNIFICANT DIGITS
3042 011640 000406      BR      RPZERO               ;TYPE THE VALUE
3043 011642 012737 000007 011742      SRPZR5: MOV     #7,RPZRC      ;SETUP TO TYPE 3 SIGNIFICANT DIGITS
3044 011650 000402      BR      RPZERO               ;TYPE THE VALUE
3045 011652 005037 011742      SRPZR0: CLR     RPZRC        ;SETUP TO TYPE 10 SIGNIFICANT DIGITS
3046 011656 010046      RPZERO: MOV     R0,-(SP)     ;SAVE R0

```

```

3047 011660 016600 000004      .      MOV      4(SP),R0      ;ADDRESS OF NUMBER TO R0
3048 011664 122710 000060      1S:     CMPB     8'0,(R0)      ;BYTE EQUAL TO ASCII '0' ?
3049 011670 001004      BNE      2S           ;BR IF NOT
3050 011672 112710 000040      MOVB     8'40,(R0)     ;REPLACE THE ZERO WITH A SPACE
3051 011676 005200      INC      R0           ;INCREMENT THE BYTE ADDRESS
3052 011700 000771      BR       1S           ;GO BACK AND LOOK FOR MORE LEADING ZEROS
3053 011702 105710      2S:     TSTB     (R0)        ;SEE IF ZERO BYTE TERMINATOR
3054 011704 001003      BNE      3S           ;BR IF NOT
3055 011706 005300      DEC      R0           ;BACKUP STRING POINTER
3056 011710 112710 000060      MOVB     8'0,(R0)     ;PUT A ZERO BACK IN
3057 011714 016637 000004 011732 3S:     MOV      4(SP),4S     ;PUT ADDRESS IN LOCATION FOR TYPEOUT
3058 011722 063737 011742 011732      ADD      RPZRC,4S     ;BEGINNING OF SIGNIFICANT DIGITS
3059 011730 104401      TYPE     TYPE         ;TYPE THE NUMBER
3060 011732 000000      4S:     .WORD    0           ;ADDRESS OF NUMBER
3061 011734 012600      MOV      (SP)+,R0     ;RESTORE R0
3062 011736 012616      MOV      (SP)+,(SP)  ;MOVE RETURN ADDRESS
3063 011740 000207      RTS      PC           ;RETURN
3064
3065 011742 000000      RPZRC:  .WORD    0           ;OFFSET FOR CONVERTED DIGITS HERE
3066
3067      ;THIS ROUTINE IS USED TO CHECK IF AN ASCII CHARACTER IS A DIGIT
3068      ;BETWEEN 0 AND 7.
3069
3070      .
3071      .
3072      .
3073      .
3074      .
3075      .
3076      .
3077      .
3078      .
3079      .
3080      .
3081      .
3082      .
3083      .
3084      .
3085      .
3086      .
3087      .
3088      .
3089      .
3090      .
3091      .
3092      .
3093      .
3094      .
3095      .
3096      .
3097      .
3098      .
3099      .
3100      .
3101      .
3102      .

```

```

3103 012016 000200          RTS      R0          ;RETURN
3104
3105
3106          ;THIS ROUTINE CHECKS AN ASCIZ STRING FOR LEGAL CHARACTERS
3107          ;AND FORMS AN OCTAL NUMBER IN R2
3108
3109          :
3110          :
3111          :
3112          :
3113          :
3114          :
3115          :
3116          :
3117 012020 010346          CK.NUM:  MOV    R3, -(SP)          ;SAVE R3
3118 012022 005003          CLR     R3          ;START NUMBER AT ZERO
3119 012024 004037 011744   JSR    R0, CK.OCT   ;OCTAL DIGIT?
3120 012030 000405          BR     1$          ;YES--BRANCH
3121 012032 004037 011774   JSR    R0, CK.CHR   ;CHECK ONE CHARACTER
3122 012036 012122          6$          ;ILLEGAL CHARACTER
3123 012040 012112          8$          ;CARRIAGE RETURN
3124 012042 012110          7$          ;
3125 012044 005201          1$:    INC     R1          ;MOVE TO NEXT CHARACTER
3126 012046 006303          ASL   R3          ;FOR THE OCTAL NUMBER IN R3
3127 012050 103424          BCS   6$          ;DON'T LET IT GET TO BIG
3128 012052 006303          ASL   R3
3129 012054 103422          BCS   6$
3130 012056 006303          ASL   R3
3131 012060 103420          BCS   6$
3132 012062 060203          ADD   R2, R3
3133 012064 004037 011744   JSR    R0, CK.OCT   ;IS THIS AN OCTAL DIGIT?
3134 012070 000765          BR     1$          ;YES--MAKE IT PART OF THE NUMBER
3135 012072 010302          2$:    MOV    R3, R2          ;SAVE THE OCTAL NUMBER
3136 012074 005003          CLR     R3          ;START WITH ZERO INDEX
3137 012076
3138 012076 004037 011774   3$:    JSR    R0, CK.CHR   ;CHECK ONE CHARACTER
3139 012102 012122          6$          ;ILLEGAL CHARACTER
3140 012104 012116          5$          ;CARRIAGE RETURN
3141 012106 012114          4$          ;
3142 012110 005723          7$:    TST   (R3)+          ;'PERIOD' ONLY
3143 012112 005723          8$:    TST   (R3)+          ;'CR' ONLY
3144 012114 005723          4$:    TST   (R3)+          ;'PERIOD'
3145 012116 005723          5$:    TST   (R3)+          ;'CR'
3146 012120 060300          ADD   R3, R0          ;YES--SAVE THE OCTAL NUMBER
3147 012122 012603          6$:    MOV    (SP)+, R3     ;RESTORE R3
3148 012124 011000          MOV    (R0), R0       ;PICKUP EXIT ADDRESS
3149 012126 000200          RTS      R0          ;RETURN
3150
3151          ;THIS ROUTINE USES THE "ITEM CONTROL BYTE" (SITEMB) TO DETERMINE
3152          ;WHICH ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR
3153          ;TABLE" (SEARTEB), AND REPORTS THE APPROPRIATE INFORMATION
3154          ;CONCERNING THE ERROR.
3155
3156 012130 104412          TYPERR: SAVREG          ;SAVE R0-R5
3157 012132 032777 020000 167000 BIT    #SW13, JSR       ;INHIBIT ERROR TYPEOUTS ?
3158 012140 001113          BNE    20$          ;BR IF INHIBIT

```

3159	012142	005000		CLR	RO	:CLEAR RO FOR ERROR NUMBER
3160	012144	113700	001114	MOV	\$ITEMB,RO	:ERROR NUMBER
3161	012150	005300		DEC	RO	:FORM INDEX FOR ERROR TABLE
3162	012150	006300		ASL	RO	
3163	012150	006300		ASL	RO	
3164	012150	006300		ASL	RO	
3165	012160	062700	001346	15:	ADD	\$SEARTB,RO
3166	012164	012037	012204		MOV	(RO)+,2\$
3167	012170	001406			BEQ	3\$
3168	012172	104401	001213		TYPE	,SCRLF
3169	012176	004737	007634		JSR	PC,STIME
3170	012202	104401			TYPE	
3171	012204	000000		25:	.WORD	0
3172	012206	012037	012222	35:	MOV	(RO)+,4\$
3173	012212	001404			BEQ	5\$
3174	012214	104401	001213		TYPE	,SCRLF
3175	012220	104401			TYPE	
3176	012222	000000		45:	.WORD	0
3177	012224	012001		55:	MOV	(RO)+,R1
3178	012226	001460			BEQ	20\$
3179	012230	005005			CLR	R5
3180	012232	012000			MOV	(RO)+,RO
3181	012234	012002			MOV	(RO)+,R2
3182	012236	001451			BEQ	17\$
3183	012240	005105			COM	R5
3184	012242	104401	001213		TYPE	,SCRLF
3185	012246	112003		105:	MOV	(RO)+,R3
3186	012250	112004			MOV	(RO)+,R4
3187	012252	006004		115:	ROR	R4
3188	012254	103403			BCS	12\$
3189	012256	013146			MOV	2(R1)+,-(SP)
3190	012260	104402			TYPOC	
3191	012262	000402			BR	13\$
3192	012264			125:		
3193	012264	013146			MOV	2(R1)+,-(SP)
3194	012266	104405			TYPDS	
3195	012270	005303		135:	DEC	R3
3196	012272	001403			BEQ	14\$
3197	012274	104401	032500		TYPE	,SPACE2
3198	012300	000764			BR	11\$
3199	012302	005302		145:	DEC	R2
3200	012304	003431			BLE	20\$
3201	012306	104401	001213		TYPE	,SCRLF
3202	012312	005760	000002		TST	2(RO)
3203	012316	001404			BEQ	15\$
3204	012320	005105			COM	R5
3205	012322	001002			BNE	15\$
3206	012324	104401	032500		TYPE	,SPACE2
3207	012330	012037	012336	155:	MOV	(RO)+,16\$
3208	012334	104401			TYPE	
3209	012336	000000		165:	.WORD	0
3210	012340	005710			TST	(RO)
3211	012342	001003			BNE	21\$
3212	012344	062700	000004		ADD	84,RO
3213	012350	000754			BR	14\$
3214	012352	104401	001213	215:	TYPE	,SCRLF

```

3215 012356 005705          TST      RS          ; INDENT?
3216 012360 001332          BNE     10$          ; NO--BRANCH
3217 012362 104401 032500 17$:  TYPE    SPACE2      ; YES--TYPE SPACES
3218 012366 000727          BR      10$          ; LOOP
3219 012370 104413          RESREG  PC          ; RESTORE R0-R5
3220 012372 000207          RTS     PC          ; RETURN

;;*****
.SBTTL  END OF ORDER PROCESSING
;;*****

;PROCESS THE ORDER TERMINATION
PROCES: TST      STATUS(R0) ; SEE IF RP11 HANDLER SIGNALLED AN ERROR
        BPL     1$          ; BR IF NO ERROR DETECTED
        JMP     ERPROC      ; ERROR - PROCESS IT
1$:     JSR     PC,CKERR     ; NO ERROR, CHECK ERROR BITS ANYWAY
        JSR     PC,CKBUS    ; NO ERROR, CHECK BUS ADDR & WC
        BIT     #SM01,JSWR  ; COMPARE THE BUFFER ?
        BNE     2$          ; BR IF NOT
2$:     JSR     PC,CMPAR    ; NO ERROR, COMPARE DATA
        RTS     PC          ; RETURN

;CHECK ERROR BITS IN 'RPER' & 'RPDS'
CKERR:  BIT     #HF!SUSI!SUFU,SRPDS(R0) ; SEE IF ERROR BITS IN RPDS
        BNE     1$          ; BR IF ANY SET
        TST     SRPER(R0)   ; ANY BITS SET IN RPER
        BEQ     2$          ; BR IF NONE SET
1$:     ERROR   15          ; ERROR BITS SET, NO ERROR SIGNALLED
        JSR     PC,INCTOT   ; INCREMENT TOTAL ERROR COUNT
        ADD     #2,SP       ; RETURN TO MAIN ROUTINE
2$:     RTS     PC          ; RETURN

```



```

3250
3251 ;CHECK BUS ADDRESS REGISTER & WORD COUNT REGISTER
3252
3253 012466 016046 000020 CKBUS: MOV SWRDL(R0),-(SP) ;WORD LENGTH
3254 012472 006316 ASL (SP) ;CHANGE INTO BYTE COUNT
3255 012474 066016 000006 ADD SBUF(R0),(SP) ;ADD THE STARTING LOCATION
3256 012500 011637 001124 MOV (SP),SGDDAT ;STORE IN CASE OF ERROR
3257 012504 022660 000076 CMP (SP)+,SRPBA(R0) ;BUFFER ADDRESS PROPER ?
3258 012510 001003 BNE IS ;BR IF NOT CORRECT
3259 012512 005760 000074 TST SRPWC(R0) ;CHECK WORD COUNT
3260 012516 001405 BEQ 2S ;BR IF ZERO
3261 012520 104016 1S: ERROR 16 ;WORD COUNT OR BUFFER ADDRESS INCORRECT
3262 012522 004737 007616 JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
3263 012526 062706 000002 ADD #2,SP ;RETURN TO MAIN ROUTINE
3264 012532 000207 2S: RTS PC ;RETURN
3265
3266 ;COMPARE THE BUFFER
3267
3268 012534 122760 000007 000002 CMPAR: CMPB #WRTCHK,SCOMND(R0) ;WRITE CHECK ?
3269 012542 001404 BEQ IS ;BR IF WRITE CHECK
3270 012544 132760 000004 000002 BITB #BIT02,SCOMND(R0) ;READ ORDER ?
3271 012552 001001 BNE CMPAR ;BR IF READ
3272 012554 000207 1S: RTS PC ;RETURN
3273 012556 016001 000006 CMPAR: MOV SBUF(R0),R1 ;BUFFER ADDRESS
3274 012562 016037 000020 013154 MOV SWRDL(R0),CMCNT ;WORD COUNT TO WORKING LOCATION
3275 012570 066037 000074 013154 ADD SRPWC(R0),CMCNT ;CALCULATE ACTUAL WORDS TRANSFERED
3276 012576 016037 000010 013156 MOV SCYL(R0),CMCYL ;CYLINDER ADDRESS
3277 012604 116037 000013 013162 MOV SBTRK(R0),CMTRK ;TRACK ADDRESS
3278 012612 116037 000012 013160 MOV SBSEC(R0),CMSEC ;SECTOR ADDRESS
3279 012620 013737 001314 013152 CMSTR: MOV CMPLMT,LIMIT ;DISPLAY LIMIT
3280 012626 005237 013152 INC LIMIT ;CONVERT PARAMETER INTO LIMIT VALUE
3281 012632 010137 013164 MOV R1,CMBUF ;STARTING ADDRESS OF SECTOR BUFFER
3282 012636 112737 177777 013142 MOVB #-1,ZROIND ;CLEAR THE 'ZERO'S' INDICATOR
3283 012644 105037 013143 CLRB FRSTER ;CLEAR 'FIRST ERROR' INDICATOR
3284 012650 005037 013150 CLR ERCTR ;CLEAR ERROR COUNTER
3285 012654 005037 013144 CLR SAVER1 ;CLEAR THE R1 SAVE WORD
3286 012660 005037 013146 CLR SAVER5 ;CLEAR THE R5 SAVE WORD
3287 012664 023727 013154 000400 CMP CMCNT,#256. ;IS BUFFER SIZE GREATER THAN ONE SECTOR ?
3288 012672 101003 BHI IS ;BR IF IT IS
3289 012674 013702 013154 MOV CMCNT,R2 ;LESS THAN, USE REMAINING BUFFER
3290 012700 000402 BR 2S
3291 012702 012702 000400 1S: MOV #256.,R2 ;COMPARE SECTOR
3292 012706 160237 013154 2S: SUB R2,CMCNT ;DECREMENT WORD COUNT
3293 012712 004737 013404 CHDAT: JSR PC,MATCH ;FIND THE PATTERN
3294 012716 000403 BR 2S ;FOUND A PATTERN
3295 012720 004737 015040 JSR PC,NONTCH ;RETURN HERE IF NO MATCH WITH PATTERN MADE
3296 012724 000456 BR 9S ;BYPASS COMPARE ROUTINE
3297 012726 011405 2S: MOV (R4),R5 ;ADDRESS OF PATTERN ADDRESS IN R4
3298 012730 012703 000020 MOV #20,R3 ;R3 IS PATTERN POS COUNTER
3299 012734 022125 3S: CMP (R1)+,(R5)+ ;COMPARE BUFFER WITH PATTERN
3300 012736 001016 BNE 5S ;BR IF NOT EQUAL
3301 012740 005737 013150 TST ERCTR ;ERRORS DETECTED ?
3302 012744 001406 BEQ 4S ;BR IF NO ERRORS
3303 012746 032777 000010 166164 BIT #SM3,JSWR ;SWITCH 3 SET ?
3304 012754 001402 BEQ 4S ;BR IF NOT SET
3305 012756 004737 013166 JSR PC,CHPRT ;DISPLAY THE WORD

```

3306	012762	005302		45:	DEC	R2	: DECREMENT SIZE COUNT
3307	012764	001434			BEQ	R5	: BR WHEN AT END
3308	012766	005303			DEC	R3	: DECREMENT PATT POS COUNT
3309	012770	001361			BNE	35	: BR IF NOT AT END OF PATT
3310	012772	000755			BR	25	: RESTART THE PATTERN
3311	012774	005761	177776	55:	TST	-2(R1)	: IS MISCOMPARED CHARACTER=0
3312	013000	001406			BEQ	65	: BR IF YES
3313	013002	112737	177777 013142		MOVB	8-1,ZROIND	: SET NON-ZERO MISCOMPARED IND
3314	013010	004737	013166		JSR	PC,CHPRT	: REPORT ERROR
3315	013014	000762			BR	45	: CONTINUE COMPARE
3316	013016	105737	013143	65:	TSTB	FRSTER	: FIRST ERROR?
3317	013022	001007			BNE	75	: BR IF NOT
3318	013024	105037	013142		CLRB	ZROIND	: SET THE ZERO INDICATOR
3319	013030	010137	013144		MOV	R1,SAVER1	: SAVE CURRENT R1
3320	013034	010537	013146		MOV	R5,SAVERS	: SAVE CURRENT R5
3321	013040	000750			BR	45	: CONTINUE COMPARE
3322	013042	105737	013142	75:	TSTB	ZROIND	: ANY MISCOMPARISONS NOT ZEROS ?
3323	013046	001745			BEQ	45	: BR IF NONE; ALL ERRORS ARE ZERO
3324	013050	004737	013166		JSR	PC,CHPRT	: REPORT ERROR
3325	013054	000742			BR	45	: CONTINUE COMPARING
3326	013056	004737	013362	85:	JSR	PC,ENDCMP	: PRINT LAST LINE (IF ERRORS)
3327	013062	005737	013154	95:	TST	CMCNT	: AT END OF BUFFER
3328	013066	003424			BLE	CMPRX	: BR IF AT END
3329	013070	005237	013160		INC	CMSEC	: INCREMENT SECTOR
3330	013074	023727	013160 000012		CMF	CMSEC,#10.	: SECTOR GREATER THAN MAX ?
3331	013102	103646			BLO	CMSTR	: BR IF NOT GREATER THAN MAX
3332	013104	005037	013160		CLR	CMSEC	: CLEAR SECTOR ADDRESS
3333	013110	005237	013162		INC	CMTRK	: INCREMENT TRACK
3334	013114	023727	013162 000024		CMF	CMTRK,#20.	: TRACK GREATER THAN MAX ?
3335	013122	103636			BLO	CMSTR	: BR IF NOT GREATER
3336	013124	005037	013162		CLR	CMTRK	: RESET TRACK ADDRESS
3337	013130	005237	013156		INC	CMCYL	: INCREMENT CYLINDER ADDRESS
3338	013134	000137	012620		JMP	CMSTR	: CONTINUE WITH COMPARE
3339	013140	000207		CHPRX:	RTS	PC	
3340							
3341	013142	377		ZROIND:	.BYTE	-1	: ZERO INDICATOR
3342	013143	000		FRSTER:	.BYTE	0	: FIRST ERROR INDICATOR
3343							: IF NOT 0, MISCOMPARISON FOUND
3344	013144	000000		SAVER1:	.WORD	0	: SAVE R1 HERE
3345	013146	000000		SAVERS:	.WORD	0	: SAVE R5 HERE
3346	013150	000000		ERCTR:	.WORD	0	: NUMBER OF ERRORS
3347	013152	000000		LIMIT:	.WORD	0	: DISPLAY LIMIT
3348	013154	000000		CMCNT:	.WORD	0	: WORD COUNT
3349	013156	000000		CMCYL:	.WORD	0	: CYLINDER ADDRESS
3350	013160	000000		CMSEC:	.WORD	0	: SECTOR ADDRESS
3351	013162	000000		CMTRK:	.WORD	0	: TRACK ADDRESS
3352	013164	000000		CMBUF:	.WORD	0	: BEGINNING ADDRESS OF SECTOR
3353							
3354							
3355							
3356	013166	105737	013143	CHPRT:	TSTB	FRSTER	: FIRST ERROR?
3357	013172	001010			BNE	15	: BR IF NOT
3358	013174	112737	000012 001114		MOVB	#12,SITEMB	: ERROR TABLE INDEX
3359	013202	004737	012130		JSR	PC,TYPERR	: DATA COMPARISON ERROR
3360	013206	112737	177777 013143		MOVB	8-1,FRSTER	: SET 'FIRST ERROR' INDICATOR
3361	013214	005737	013144	15:	TST	SAVER1	: SAVED REGISTERS ?

;TYPE DATA COMPARE ERRORS

```

3362 013220 001420 BEQ 25 ;BR IF NONE
3363 013222 010146 MOV R1,-(SP) ;PUSH R1 ON STACK
3364 013224 010546 MOV R5,-(SP) ;PUSH R5 ON STACK
3365 013226 013701 013144 MOV SAVER1,R1 ;DISPLAY SAVED R1
3366 013232 013705 013146 MOV SAVER5,R5 ;DISPLAY SAVED R5
3367 013236 004737 013274 JSR PC,CMPRT1 ;PRINT SAVED VALUES
3368 013242 005237 013150 INC ERCTR ;INCREMENT THE ERROR COUNTER
3369 013246 005037 013144 CLR SAVER1 ;CLEAR SAVED REGISTER INDICATORS
3370 013252 005037 013146 CLR SAVER5 ;CLEAR THE OTHER ONE
3371 013256 012605 MOV (SP)+,R5 ;POP STACK INTO R5
3372 013260 012601 MOV (SP)+,R1 ;POP STACK INTO R1
3373 013262 004737 013274 25: JSR PC,CMPRT1 ;PRINT REMAINDER OF MESSAGE
3374 013266 005237 013150 INC ERCTR ;INCREMENT THE ERROR COUNTER
3375 013272 000207 RTS PC ;RETURN
3376 013274 005737 013152 CMPRT1: TST LIMIT ;TIMEOUT LIMIT REACHED ?
3377 013300 001403 BEQ 15 ;BR IF IT HAS
3378 013302 005337 013152 DEC LIMIT ;DECREMENT LIMIT COUNTER
3379 013306 001004 BNE 25 ;BR IF NOT AT LIMIT
3380 013310 032777 000004 165622 15: BIT #SND2,JSWR ;PRINT ALL DATA COMPARE ERRORS ?
3381 013316 001420 BEQ 35 ;BR IF NOT
3382 013320 010137 001122 25: MOV R1,$BADDR ;ADDRESS OF BAD WORD
3383 013324 162737 000002 001122 SUB #2,$BADDR ;ADJUST ADDRESS
3384 013332 016537 177776 001124 MOV -2(R5),$GDDAT ;GOOD DATA
3385 013340 016137 177776 001126 MOV -2(R1),$BDDAT ;BAD DATA
3386 013346 112737 000013 001114 MOVB #13,$ITEMB ;ERROR TABLE INDEX
3387 013354 004737 012130 JSR PC,TYPERR ;DISPLAY WORD THAT DIDN'T COMPARE
3388 013360 000207 35: RTS PC ;RETURN
3389
3390 ;LAST LINE OF COMPARE ERROR REPORTING
3391
3392 013362 005737 013150 ENDCMP: TST ERCTR ;SEE IF ANY ERRORS
3393 013366 001405 BEQ 15 ;BR IF NONE
3394 013370 104014 ERROR 14 ;NUMBER OF COMPARE ERRORS
3395 013372 004737 007616 JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
3396 013376 062706 000002 ADD #2,SP ;RETURN TO MAIN ROUTINE
3397 013402 000207 15: RTS PC ;RETURN
3398
3399 ;FIND THE CORRECT PATTERN - RETURN WITH ADDRESS OF PATTERN IN R4
3400 ; RETURN +2 IF PATTERN CAN'T BE FOUND
3401
3402 013404 010146 MATCH: MOV R1,-(SP) ;SAVE R1 ON THE STACK
3403 013406 012704 000044 MOV #44,R4 ;PATTERN TABLE INDEX
3404 013412 011601 15: MOV (SP),R1 ;RELOAD R1
3405 013414 162704 000002 SUB #2,R4 ;DECREMENT INDEX
3406 013420 016405 025764 MOV STNDAT(R4),R5 ;ADDRESS OF PATTERN ADDRESS
3407 013424 001411 BEQ 35 ;BR IF ALL PATTERNS CHECKED AND NO MATCH
3408 ; FOUND
3409 013426 012703 000004 25: MOV #4,R3 ;NUMBER OF LOCATIONS TO CHECK
3410 013432 022125 CMP (R1)+,(R5)+ ;COMPARE THE BUFFER AGAINST THE PATTERN
3411 013434 001366 BNE 15 ;BR IF NOT EQUAL, TRY NEXT PATTERN
3412 013436 005303 DEC R3 ;FINISHED CHECKING?
3413 013440 001374 BNE 25 ;BR IF NOT FINISHED
3414 013442 062704 025764 ADD #STNDAT,R4 ;MAKE PATTERN ADDRESS ABSOLUTE
3415 013446 000403 BR 45 ;EXIT
3416 013450 062766 000002 35: ADD #2,2(SP) ;INCREMENT RETURN ADDRESS
3417 013456 012601 45: MOV (SP)+,R1 ;RESTORE R1

```

```

3418 013460 000207          RTS      PC          ;RETURN
3419
3420          ;ORDER TERMINATED WITH AN ERROR - PROCESS THE ERROR
3421
3422 013462 032760 000200 000016 ERPROC: BIT      #BIT07,STATUS(RO) ;DONE BIT SET ?
3423 013470 001402          BEQ      ERPRC1      ;BR IF ORDER DIDN'T COMPLETE NORMALLY
3424 013472 000137 013662          JMP      DONE        ;PROCESS ERROR WITH 'DONE' BIT SET
3425
3426          ;PROCESS ORDER COMPLETION WITH 'ERROR' & 'DONE NOT' BITS
3427
3428 013476 032760 000400 000016 ERPRC1: BIT      #BIT08,STATUS(RO) ;WAS A 'RESET' ISSUED ?
3429 013504 001405          BEQ      15          ;BR IF NOT
3430 013506 012777 000100 165430          MOV      #BIT06,STKS ;RESTORE TTY KEYBOARD INTERRUPT
3431 013514 004737 006762          JSR      PC,CKCLK   ;START THE CLOCK
3432 013520 032760 040000 000016 15:  BIT      #BIT14,STATUS(RO) ;UNIT WENT OFFLINE ?
3433 013526 001022          BNE     OFLIN       ;BR IF IT DID
3434 013530 032760 020000 000016          BIT      #BIT13,STATUS(RO) ;BAD COMMAND CODE USED ?
3435 013536 001023          BNE     BADOP       ;BR IF SO
3436 013540 032760 010000 000016          BIT      #BIT12,STATUS(RO) ;SEE IF DRIVE WAS UNSAFE
3437 013546 001021          BNE     UNSAF       ;BR IF IT WENT UNSAFE
3438 013550 032760 001000 000016          BIT      #BIT09,STATUS(RO) ;TIMEOUT DURING POSITIONING ?
3439 013556 001022          BNE     TIMPOS      ;BR IF YES
3440 013560 032760 000400 000016          BIT      #BIT8,STATUS(RO) ;TIMEOUT DURING I/O
3441 013566 001023          BNE     TIMIO       ;BR IF YES
3442 013570 104043          ERROR   43         ;INVALID STATUS CODE
3443 013572 000207          RTS      PC          ;RETURN
3444
3445          ;DRIVE WENT OFFLINE
3446
3447 013574 104021          OFLIN:  ERROR   21         ;DRIVE WENT OFFLINE
3448 013576 004737 007616          JSR      PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
3449 013602 000137 011226          JMP      DROP       ;DEASSIGN THE DRIVE
3450
3451          ;PROGRAM TRIED TO GIVE THE DRIVE A BAD COMMAND
3452
3453 013606 104002          BADOP:  ERROR   2         ;INVALID COMMAND ATTEMPTED
3454 013610 000207          RTS      PC          ;RETURN
3455
3456          ;DRIVE IS UNSAFE
3457
3458 013612 104022          UNSAF:  ERROR   22         ;DRIVE UNSAFE
3459 013614 004737 007616          JSR      PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
3460 013620 000137 011226          JMP      DROP       ;DEASSIGN THE DRIVE
3461
3462          ;DRIVE TIMED OUT DURING POSITIONING
3463
3464 013624 104017          TIMPOS: ERROR   17         ;DRIVE TIMED OUT DURING POSITIONING
3465 013626 004737 007616          JSR      PC,INCTOT ;INCREMENT THE 'TOTAL' ERROR COUNT
3466 013632 000137 011226          JMP      DROP       ;DEASSIGN THE DRIVE
3467
3468          ;DRIVE TIMED OUT DURING A DATA TRANSFER
3469
3470 013636 104020          TIMIO:  ERROR   20         ;DRIVE TIMED OUT DURING I/O
3471 013640 004737 007616          JSR      PC,INCTOT ;INCREMENT THE 'TOTAL' ERROR COUNT
3472 013644 012777 000100 165272          MOV      #BIT06,STKS ;RESTORE THE TTY KEYBOARD INTERRUPT ENABLE
3473 013652 004737 006762          JSR      PC,CKCLK   ;RESTART THE CLOCK

```

```

3474 013656 000137 011226          JMP      DROP          ;DEASSIGN THE DRIVE
3475
3476          ;PROCESS ORDER COMPLETION WITH 'ERROR' & 'DONE' BITS SET
3477
3478 013662 022760 000002 000070  DONE:  CMP      #EOP,SRPER(RO) ;END OF PACK ?
3479 013670 001475          BEQ      IS           ;BR IF EOP, OPERATION OVERFLOWED
3480 013672 022760 000010 000070          CMP      #WCE,SRPER(RO) ;WRITE CHECK ERROR ONLY ?
3481 013700 001002          BNE      .+6         ;BR IF NOT
3482 013702 000137 014066          JMP      WCEER        ;REPORT THE WRITE CHECK ERROR
3483 013706 032760 100000 000070          BIT      #WPV,SRPER(RO) ;WRITE PROTECTION VIOLATION ?
3484 013714 001402          BEQ      .+6         ;BR IF NOT
3485 013716 000137 014076          JMP      WPVER        ;REPORT THE WRITE PROTECTION VIOLATION
3486 013722 032760 040000 000070          BIT      #FUV,SRPER(RO) ;FILE UNSAFE ?
3487 013730 001402          BEQ      .+6         ;BR IF NOT
3488 013732 000137 013612          JMP      UNSAF        ;REPORT THE UNSAFE
3489 013736 032760 004000 000066          BIT      #SUSI,SRPDS(RO) ;SEEK INCOMPLETE ?
3490 013744 001402          BEQ      .+6         ;BR IF NOT
3491 013746 000137 014424          JMP      SKIER        ;PROCESS IT
3492 013752 032760 034000 000070          BIT      #NXC!NXT!NXS,SRPER(RO) ;INVALID DISK ADDRESS ?
3493 013760 001402          BEQ      .+6         ;BR IF NOT
3494 013762 000137 014106          JMP      BDADR        ;REPORT INVALID DISK ADDRESS
3495 013766 032760 012000 000070          BIT      #PROG!MODE,SRPER(RO) ;CONTROLLER ERROR ?
3496 013774 001402          BEQ      .+6         ;BR IF NOT
3497 013776 000137 014116          JMP      CNTRLR       ;REPORT THE CONTROLLER ERROR
3498 014002 032760 000024 000070          BIT      #TIMEE!NXME,SRPER(RO) ;INTERFACE (UNIBUS) ERROR ?
3499 014010 001402          BEQ      .+6         ;BR IF NOT
3500 014012 000137 014126          JMP      INTRFA       ;REPORT THE ERROR
3501 014016 032760 001000 000070          BIT      #FMTE,SRPER(RO) ;FORMAT ERROR ?
3502 014024 001402          BEQ      .+6         ;BR IF NOT
3503 014026 000137 014136          JMP      FMTERR       ;PROCESS THE FORMAT ERROR
3504 014032 032760 010000 000066          BIT      #HNF,SRPDS(RO) ;HEADER NOT FOUND ?
3505 014040 001402          BEQ      .+6         ;BR IF NOT SET
3506 014042 000137 014460          JMP      CKHNF        ;PROCESS THE ERROR
3507 014046 032760 000340 000070          BIT      #LPE!WPE!CSME,SRPER(RO) ;DATA ERROR ?
3508 014054 001402          BEQ      .+6         ;BR IF NOT
3509 014056 000137 014622          JMP      DATER        ;REPORT THE DATA ERROR
3510 014062 104043          ERROR   43          ;ERROR REPORT BUT NO BITS SET
3511 014064 000207          IS:    RTS         PC          ;RETURN
3512
3513          ;REPORT A WRITE CHECK ERROR (DATA CHECK BITS NOT SET)
3514
3515 014066 104032          WCEER: ERROR   32          ;WRITE CHECK (DATA CHECK BITS NOT SET)
3516 014070 004737 007616          JSR      PC,INCTOT   ;INCREMENT 'TOTAL' ERROR COUNT
3517 014074 000207          RTS         PC          ;RETURN
3518
3519          ;REPORT WRITE PROTECTION VIOLATION
3520
3521 014076 104044          WPVER: ERROR   44          ;WRITE PROTECTION VIOLATION
3522 014100 004737 007616          JSR      PC,INCTOT   ;INCREMENT 'TOTAL' ERROR COUNT
3523 014104 000207          RTS         PC          ;RETURN
3524
3525          ;REPORT INVALID DISK ADDRESS ('NXC', 'NXT', 'NXS')
3526
3527 014106 104026          BDADR: ERROR   26          ;INVALID DISK ADDRESS
3528 014110 004737 007616          JSR      PC,INCTOT   ;INCREMENT 'TOTAL' ERROR COUNT
3529 014114 000207          RTS         PC          ;RETURN

```

```

3530
3531 ;REPORT CONTROLLER ERROR ('PROG' & 'MODE')
3532
3533 014116 104025 CNTRLR: ERROR 25 ;REPORT CONTROLLER ERROR
3534 014120 004737 007616 JSR PC, INCTOT ;INCREMENT 'TOTAL' ERROR COUNT
3535 014124 000207 RTS PC ;RETURN
3536
3537 ;REPORT UNIBUS INTERFACE ERROR ('TIMEE' & 'NXME')
3538
3539 014126 104024 INTRFA: ERROR 24 ;REPORT UNIBUS ERROR
3540 014130 004737 007616 JSR PC, INCTOT ;INCREMENT 'TOTAL' ERROR COUNT
3541 014134 000207 RTS PC ;RETURN
3542
3543 ;REPORT FORMAT ERROR
3544
3545 014136 122760 000007 000002 FMTERR: CMPB #WRTCHK, SCOMND(RO) ;WRITE CHECK OPERATION ?
3546 014144 001404 BEQ 1$ ;BR IF WRITE CHECK
3547 014146 132760 000004 000002 BITB #BIT02, SCOMND(RO) ;WRITE COMMAND ?
3548 014154 001010 BNE 2$ ;BR IF NOT
3549 014156 016046 000076 1$: MOV SRPBA(RO), -(SP) ;PUT PRESENT BUFFER ADDRESS ON THE STACK
3550 014162 166016 000006 SUB SBUF(RO), (SP) ;SUBTRACT STARTING ADDRESS
3551 014166 022726 000200 CMP #128., (SP)+ ;SILO FILLED OR HAS XFER TO DISK STARTED ?
3552 014172 103074 BHIS 6$ ;BR IF NOT
3553 014174 000404 BR 3$
3554 014176 026060 000006 000076 2$: CMP SBUF(RO), SRPBA(RO) ;READ TRANSFER STARTED ?
3555 014204 001467 BEQ 6$ ;BR IF NOT
3556 014206 104045 3$: ERROR 4$ ;FORMAT ERROR DURING I/O
3557 014210 162706 000004 SUB #4, SP ;MAKE ROOM ON THE STACK
3558 014214 004737 006666 JSR PC, READDR ;ADJUST SECTOR/TRACK ADDRESSES
3559 014220 112660 000013 MOVB (SP)+, STRK(RO) ;MOVE THE TRACK ADDRESS
3560 014224 112660 000012 MOVB (SP)+, SSEC(RO) ;MOVE THE SECTOR ADDRESS
3561 014230 016060 000106 000010 MOV SSUCA(RO), SCYL(RO) ;USE PRESENT CYLINDER ADDRESS
3562 014236 022760 000400 000020 CMP #256., SWRDL(RO) ;WAS INITIAL TRANSFER TO BE GREATER
3563 ; THAN 1 SECTOR ?
3564 014244 103015 BHIS 4$ ;BR IF NOT
3565 014246 004737 005056 JSR PC, RELBUF ;RELEASE PRESENT BUFFER
3566 014252 012760 000400 000020 MOV #256., SWRDL(RO) ;SETUP FOR THE FAILING SECTOR
3567 014260 012760 177400 000004 MOV #-256., SWRDM(RO) ;WORD COUNT (2'S COMPLEMENT)
3568 014266 005046 CLR -(SP) ;CLEAR THE STACK
3569 014270 004737 004720 JSR PC, GETBUF ;GET NEW BUFFER
3570 014274 012660 000006 MOV (SP)+, SBUF(RO) ;LOAD BUFFER ADDRESS
3571 014300 012737 001001 015572 4$: MOV #FMTE!DSKERR MASK ;ERROR MASK FOR RETRY
3572 014306 112737 000012 015571 MOVB #10., SRETRY+1 ;RETRY LIMIT
3573 014314 004737 007616 JSR PC, INCTOT ;INCREMENT 'TOTAL' ERROR COUNT
3574 014320 004737 015472 JSR PC, RETRY ;RETRY THE OPERATION
3575 014324 000411 BR 5$ ;RETRY GOOD
3576 014326 004737 015350 JSR PC, RECALT ;RESTORE (PART OF STANDARD RECOVERY)
3577 014332 004737 015472 JSR PC, RETRY ;RETRY AGAIN
3578 014336 000404 BR 5$ ;RETRY GOOD
3579 014340 104042 ERROR 42 ;UNSUCCESSFUL RETRY
3580 014342 004737 007544 JSR PC, INCHRD ;INCREMENT 'HARD' ERROR COUNT
3581 014346 000425 BR 8$ ;EXIT
3582 014350 104041 5$: ERROR 41 ;SUCCESSFUL RETRY
3583 014352 004737 007526 JSR PC, INCSOF ;INCREMENT 'SOFT' ERROR COUNT
3584 014356 004737 012534 JSR PC, CMPAR ;COMPARE THE BUFFER
3585 014362 000417 BR 8$ ;EXIT

```

```

3586 014364 104035      6S:  ERROR 35      :FORMAT ERROR SEARCHING FOR INITIAL SECTOR
3587 014366 004737 007616      JSR  PC,INCTOT      :INCREMENT 'TOTAL' ERROR COUNT
3588 014372 012737 001001 015572      MOV  #FMTE!DSKERR,MASK :ERROR MASK FOR RETRY
3589 014400 112737 000001 015571      MOV  #1,$RETRY+1     :RETRY COUNT
3590 014406 004737 015472      JSR  PC,RETRY       :RETRY THE ORDER
3591 014412 000402      BR   7S            :GOOD RETRY
3592 014414 104042      ERROR 42          :UNSUCCESSFUL RETRY
3593 014416 000401      BR   8S            :EXIT
3594 014420 104041      7S:  ERROR 41          :SUCCESSFUL RETRY
3595 014422 000207      8S:  RTS   PC        :RETURN
3596
3597      ;REPORT SEEK INCOMPLETE
3598
3599 014424 016037 000032 001124  SKIER: MOV  $PREVA+2(RO), $GDDAT :PREVIOUS CYLINDER ADDRESS
3600 014432 016037 000010 001126      MOV  $CYL(RO), $BDDAT :DESTINATION CYLINDER
3601 014440 104023      ERROR 23          :SEEK INCOMPLETE
3602 014442 004737 007616      JSR  PC,INCTOT      :INCREMENT 'TOTAL' ERROR COUNT
3603 014446 004737 007562      JSR  PC,INCSKI     :INCREMENT 'SUSI' ERROR COUNT
3604 014452 004737 015350      JSR  PC,RECALT     :RESTORE
3605 014456 000207      RTS   PC           :RETURN
3606
3607      ;REPORT HEADER NOT FOUND ERROR OR POSITIONING ERROR
3608
3609 014460 116046 000102  CKHNF: MOV  $RPDA(RO), -(SP) :SECTOR ADDRESS ON THE STACK
3610 014464 042716 000360      BIC  #360, (SP)     :CLEAR THE 'SOT' BITS
3611 014470 116046 000103      MOV  $RPDA+1(RO), -(SP) :TRACK ADDRESS
3612 014474 004737 015402      JSR  PC,READHD     :READ THE HEADER FROM THE INITIAL SECTOR
3613 014500 032737 100000 025436      BIT  #ERR, GENREG+RPER :ERROR DURING OPERATION ?
3614 014506 001041      BNE  1S            :BR IF ERROR
3615 014510 013737 033640 001126      MOV  CYLDER+2, $BDDAT :CYLINDER FROM HEADER
3616 014516 006237 001126      ASR  $BDDAT        :SHIFT CYLINDER ADDRESS
3617 014522 006237 001126      ASR  $BDDAT        :SHIFT CYLINDER ADDRESS
3618 014526 006237 001126      ASR  $BDDAT        :SHIFT CYLINDER ADDRESS
3619 014532 006237 001126      ASR  $BDDAT        :SHIFT CYLINDER ADDRESS
3620 014536 006237 001126      ASR  $BDDAT        :SHIFT CYLINDER ADDRESS
3621 014542 006237 001126      HSR  $BDDAT        :SHIFT CYLINDER ADDRESS
3622 014546 026037 000106 001126      CMP  $SUCA(RO), $BDDAT :AT CORRECT CYLINDER ?
3623 014554 001416      BEQ  1S            :BR IF AT CORRECT CYLINDER
3624 014556 016037 000032 001124      MOV  $PREVA+2(RO), $GDDAT :PREVIOUS CYLINDER ADDRESS
3625 014564 104036      ERROR 36          :POSITIONING ERROR
3626 014566 004737 007600      JSR  PC,INCMIS     :INCREMENT POSITIONING ERROR COUNT
3627 014572 004737 015350      JSR  PC,RECALT     :RESTORE THE DRIVE
3628 014576 016037 000106 000032      MOV  $SUCA(RO), $PREVA+2 :SAVE PREVIOUS CYLINDER
3629 014604 005060 000010      CLR  $CYL(RO)      :RESET CURRENT CYLINDER
3630 014610 000401      BR   2S            :CLEAN UP, THEN EXIT
3631 014612 104034      1S:  ERROR 34          :HEADER NOT FOUND ERROR
3632 014614 004737 007616      2S:  JSR  PC,INCTOT      :INCREMENT 'TOTAL' ERROR COUNT
3633 014620 000207      RTS   PC           :RETURN
3634
3635      ;REPORT DATA ERROR ('LPE', 'WPE', & 'CSME')
3636
3637 014622 032760 000010 000070  DATER: BIT  #WCE, $RPER(RO) :WRITE CHECK ERROR ALSO ?
3638 014630 001402      BEQ  1S            :BR IF NOT
3639 014632 104033      ERROR 33          :REPORT WRITE CHECK WITH DATA CHECK
3640 014634 000403      BR   2S            :CONTINUE
3641 014636 104027      1S:  ERROR 27          :DATA ERROR

```

3642	014640	004737	015144			JSR	PC, PRTBAD	:TYPE THE BAD SECTOR
3643	014644	004737	007616	2S:		JSR	PC, INCTOT	:INCREMENT 'TOTAL' ERROR COUNT
3644	014650	162706	000004			SUB	#4, SP	:MAKE ROOM ON THE STACK
3645	014654	004737	006666			JSR	PC, READDR	:ADJUST SECTOR/TRACK ADDRESSES
3646	014660	112660	000013			MOVB	(SP)+, STRK(RD)	:MOVE THE TRACK ADDRESS
3647	014664	112660	000012			MOVB	(SP)+, SSEC(RD)	:MOVE THE SECTOR ADDRESS
3648	014670	016060	000106	000010		MOV	SSUCA(RD), SCYL(RD)	:USE PRESENT CYLINDER ADDRESS
3649	014676	022760	000400	000020		CMP	#256., SWRDL(RD)	:INITIAL TRANSFER SIZE LARGER :THAN 1 SECTOR ?
3650								
3651	014704	103023				BHIS	3S	:BR IF NOT
3652	014706	004737	005056			JSR	PC, RELBUF	:RELEASE THE PRESENT BUFFER
3653	014712	012760	000400	000020		MOV	#256., SWRDL(RD)	:SETUP FOR 1 SECTOR
3654	014720	012760	177400	000004		MOV	#-256., SWRDM(RD)	:WORD COUNT
3655	014726	005046				CLR	-(SP)	:CLEAR THE STACK
3656	014730	004737	004720			JSR	PC, GETBUF	:GET NEW BUFFER
3657	014734	012660	000006			MOV	(SP)+, SBUF(RD)	:LOAD BUFFER ADDRESS
3658	014740	122760	000007	000002		CMPB	SWRCHK, SCOND(RD)	:IS THE COMMAND A WRITE CHECK ?
3659	014746	001002				BNE	3S	:BR IF NOT
3660	014750	004737	005304			JSR	PC, FILBUF	:REFILL THE BUFFER
3661	014754	012737	000350	015572	3S:	MOV	SWRCHK, SCOND(RD)	:RETRY MASK
3662	014762	112737	000012	015571		MOVB	#10., SRETRY+1	:RETRY LIMIT
3663	014770	004737	015472			JSR	PC, RETRY	:RETRY THE SECTOR
3664	014774	000413				BR	4S	:RETRY GOOD
3665	014776	004737	015350			JSR	PC, RECALT	:RESTORE THE DRIVE
3666	015002	004737	015472			JSR	PC, RETRY	:RETRY 10 MORE TIMES
3667	015006	000406				BR	4S	:RETRY GOOD
3668	015010	104031				ERROR	31	:HARD ERROR
3669	015012	004737	007544			JSR	PC, INCHRD	:INCREMENT 'HARD' ERROR COUNT
3670	015016	004737	015144			JSR	PC, PRTBAD	:PRINT BAD SECTOR ?
3671	015022	000405				BR	5S	:EXIT
3672	015024	104030			4S:	ERROR	30	:SOFT ERROR
3673	015026	004737	007526			JSR	PC, INCSOF	:INCREMENT 'SOFT' ERROR COUNT
3674	015032	004737	012534			JSR	PC, CMPAR	:COMPARE THE BUFFER
3675	015036	000207			5S:	RTS	PC	:RETURN
3676								
3677								
3678								
3679								
3680	015040	010346						
3681	015042	112737	000010	001114		NONMCH:	MOV R3, -(SP)	:SAVE R3
3682	015050	004737	012130			MOVB	#10, SITEMB	:ERROR TABLE INDEX
3683	015054	012703	000004			JSR	PC, TYPERR	:CAN'T MATCH PATTERN WITH DATA READ
3684	015060	010137	001122			MOV	#4, R3	:WORD COUNTER
3685	015064	012137	001126			MOV	R1, SBDADR	:ADDRESS OF WORD
3686	015070	112737	000011	001114		MOV	(R1)+, SBDADR	:WORD
3687	015076	004737	012130			MOVB	#11, SITEMB	:ERROR TABLE INDEX
3688	015102	005303				JSR	PC, TYPERR	:DISPLAY THE PATTERN 'SEED'
3689	015104	001365				DEC	R3	:DECREMENT WORD COUNTER
3690	015106	062701	000770			BNE	1S	:BR IF NOT DONE
3691	015112	060237	013150			ADD	#770, R1	:INCREMENT BUFFER POINTER
3692						ADD	R2, ERCTR	:ADD SECTOR (OR LESS) COUNT TO THE :COMPARISON ERROR COUNT
3693	015116	005002				CLR	R2	:CLEAR 'WORDS TO COMPARE' COUNT IN R2
3694	015120	112737	177777	013143		MOVB	#-1, FRSTER	:SET 'NOT FIRST ERROR' INDICATOR
3695	015126	012603				MOV	(SP)+, R3	:RESTORE R3
3696	015130	032777	100000	164002		BIT	#SW15, SWR	:HALT ON ERROR ?
3697	015136	001401				BEQ	2S	:BR IF NOT


```

3698 015140 000000          HALT          ;ERROR HALT
3699 015142 000207          RTS           ;RETURN
3700                                     ;ROUTINE TO DISPLAY THE SECTOR WHICH GAVE THE HARD ERROR
3701
3702
3703 015144 032777 000010 163766 PRTBAD: BIT      #SW3,2SWR      ;PRINT THE BAD SECTOR ?
3704 015152 001475          BEQ       75          ;BR IF NOT
3705 015154 032777 020000 163756 BIT      #SW13,2SWR     ;INHIBIT ERROR TYPEOUTS
3706 015162 001071          BNE       75          ;BR IF INHIBIT
3707 015164 122760 000007 000002 CMPB    #WRTCHK,SCOMND(RO) ;PRESENT COMMAND A WRITE CHECK ?
3708 015172 001465          BEQ       75          ;BR IF IT IS
3709 015174 032760 000004 000002 BIT      #BIT02,SCOMND(RO) ;PRESENT COMMAND A WRITE ?
3710 015202 001461          BEQ       75          ;BR IF IT IS
3711 015204 016001 000076          MOV      SRPBA(RO),R1    ;PUT THE END ADDRESS INTO R1
3712 015210 016046 000020          MOV      $WDL(RO),-(SP) ;FIND THE BEGINNING OF THE SECTOR
3713 015214 066016 000074          ADD      $RPMC(RO),(SP) ;SUBTRACT THE WORDS NOT TRANSFERED
3714 015220 005046          CLR      -(SP)        ;MAKE THE UPPER DIVIDEND 0
3715 015222 012746 000400          MOV      #256, -(SP)   ;DIVIDE THE WORDS TRANSFERED BY THE SECTOR SIZE
3716 015226 004737 020206          JSR     PC,$DIV        ;DIVIDE
3717 015232 005716          TST     (SP)          ;REMAINDER = 0 ?
3718 015234 001403          BEQ     15          ;BR IF IT IS - COMPLETE SECTOR TRANSFERED
3719 015236 006316          ASL     (SP)          ;CONVERT THE RESIDUAL SECTOR SIZE INTO BYTE COUNT
3720 015240 161601          SUB     (SP),R1       ;SUBTRACT IT FROM THE END ADDRESS
3721 015242 000402          BR      25          ;FINISH THE SIZING
3722 015244 162701 001000          SUB     #1000,R1      ;SUBTRACT FULL SECTOR SIZE FROM END ADDR
3723 015250 062706 000004          ADD     #4,SP         ;RESTORE THE STACK POINTER
3724 015254 104401 032404          TYPE   ,LH11H        ;PRINT THE HEADER
3725 015260 032777 000010 163652 35: BIT      #SW03,2SWR     ;PRINT ANY MORE OF THE SECTOR
3726 015266 001420          BEQ     55          ;BR IF NOT
3727 015270 012702 000007          MOV     R2,R2        ;R2 CONTAINS THE WORDS/LINE COUNT
3728 015274 010146          MOV     R1, -(SP)    ;PUT THE ADDRESS ON THE STACK
3729 015276 104402          TYPC   ;PRINT IT
3730 015300 020160 000076          CMP     R1,SRPBA(RO) ;PRINTED ALL THE SECTOR ?
3731 015304 001411          BEQ     55          ;BR IF ALL PRINTED
3732 015306 104401 032500          TYPE   ,SPACE2       ;SPACES
3733 015312 012146          MOV     (R1)+, -(SP) ;PUT THE DATA ON THE STACK
3734 015314 104402          TYPC   ;PRINT IT
3735 015316 005302          DEC     R2          ;DECREMENT THE HORIZONTAL COUNT
3736 015320 001367          BNE     45          ;BR IF NOT AT THE END OF THE LINE
3737 015322 104401 001213          TYPE   ,SCRLF        ;CR-LF
3738 015326 000754          BR      35          ;RESTORE THE WORDS/LINE COUNT
3739 015330 104401 001213          TYPE   ,SCRLF        ;PRINT WHAT REMAINS IN THE BUFFER
3740 015334 032777 100000 163576 65: BIT      #SW15,2SWR     ;HALT ON ERROR ?
3741 015342 001401          BEQ     75          ;BR IF NOT
3742 015344 000000          HALT
3743 015346 000207          RTS           ;RETURN
3744
3745                                     ;ROUTINE TO DO A HOME SEEK - DRIVE SELECTED IN RO
3746                                     ;ENTER AT 'RECALO' IF UNIT NUMBER ALREADY LOADED
3747                                     ;INTO 'GENDPB'
3748
3749 015350 111037 025414          RECAL: MOVB   (RO),GENDPB ;MOVE THE UNIT # TO THE GENERAL DPB
3750 015354 112737 000015 025416 RECALO: MOVB   #HOMSEK,GENDPB+SCOMND ;HOME SEEK COMMAND
3751 015362 004037 021566          JSR     RO,RP11      ;DRIVER ENTRANCE
3752 015366 025414          GENDPB ;DPB ADDRESS FOR ORDER
3753 015370 000000          HALT          ;DRIVER DIDN'T ACCEPT THE ORDER

```

```

3754 015372 005737 025432 15: TST GENDPB+STATUS ;SEE IF FINISHED
3755 015376 001775 BEQ 15 ;BR IF NOT FINISHED
3756 015400 000207 RTS PC ;RETURN
3757
3758 ;UTILITY READ HEADER ROUTINE
3759 ; ENTER WITH TRACK AND SECTOR ADDRS ON THE STACK
3760
3761 015402 116637 000002 025427 READHD: MOVB 2(SP),GENDPB+STRK ;TRACK ADDRESS
3762 015410 116637 000004 025426 MOVB 4(SP),GENDPB+SSEC ;SECTOR ADDRESS
3763 015416 111037 025414 MOVB (RO),GENDPB ;DRIVE NUMBER
3764 015422 016037 000106 025424 MOV SSUCA(RO),GENDPB+SCYL ;CYLINDER ADDRESS
3765 015430 012737 014000 025416 MOV #MODE!HDR,GENDPB+SCOMD ;MODE AND HEADER BITS
3766 015436 112737 000017 025416 MOVB #READ,GENDPB+SCOMD ;READ COMMAND
3767 015444 004037 021566 JSR RO,RP11 ;DRIVER ENTRANCE
3768 015450 025414 GENDPB ;DPB ADDRESS FOR ORDER
3769 015452 000000 HALT ;DRIVER DIDN'T ACCEPT COMMAND
3770 015454 005737 025432 15: TST GENDPB+STATUS ;FINISHED?
3771 015460 001775 BEQ 15 ;BR IF NOT
3772 015462 012666 000002 MOV (SP)+,2(SP) ;ADJUST STACK FOR RETURN
3773 015466 005726 TST (SP)+
3774 015470 000207 RTS PC ;RETURN
3775
3776 ;RETRY THE PRESENT OPERATION
3777 ; RETURN IF RETRY SUCCESSFUL
3778 ; RETURN+2 IF RETRY UNSUCCESSFUL
3779 ; RETURN TO MAIN PROGRAM IF DIFFERENT ERROR OCCURS
3780
3781 015472 105037 015570 RETRY: CLRB SRETRY ;CLEAR RETRY COUNTER
3782 015476 004737 005434 15: JSR PC,GOODRIV ;RE-START ORDER
3783 015502 005760 000016 25: TST STATUS(RO) ;ORDER FINISHED?
3784 015506 001775 BEQ 25 ;BR IF NOT
3785 015510 100403 BMI 35 ;BR IF ERROR
3786 015512 105237 015570 INCB SRETRY ;INCREMENT RETRY COUNT
3787 015516 000420 BR 65 ;GO TO EXIT, SUCCESSFUL RETRY
3788 015520 032760 000200 000016 35: BIT #BIT7,STATUS(RO) ;DID ORDER TERMINATE NORMALLY ?
3789 015526 001415 BEQ 75 ;BR IF NOT
3790 015530 033760 015572 000070 BIT MASK,SAPER(RO) ;SAME ERROR?
3791 015536 001411 BEQ 75 ;BR IF NOT
3792 015540 105237 015570 55: INCB SRETRY ;INCREMENT RETRY COUNT
3793 015544 123737 015570 015571 CHPB SRETRY,SRETRY+1 ;REACHED RETRY LIMIT ?
3794 015552 001351 BNE 15 ;BR IF NOT
3795 015554 062716 000002 ADD #2,(SP) ;INCREMENT RETURN, UNSUCCESSFUL RETRY
3796 015560 000207 65: RTS PC ;RETURN
3797 015562 104037 75: ERROR 37 ;DIFFERENT ERROR DURING RETRY
3798 015564 005726 TST (SP)+ ;ADJUST STACK POINTER FOR DIRECT RETURN
3799 015566 000207 RTS PC ;RETURN
3800
3801 015570 000 000 SRETRY: .BYTE 0,0 ;RETRY LIMIT & RETRY COUNTER
3802 015572 000000 MASK: .WORD 0 ;ERROR MASK
3803
3804 ;THIS ROUTINE WILL CONVERT A 16-BIT UNSIGNED BINARY NUMBER TO
3805 ;AN UNSIGNED DECIMAL ASCII NUMBER.
3806
3807 ;CALL
3808 ; MOV #NUMBER,-(SP) ;PUT THE BINARY NUMBER ON THE STACK
3809 ; JSR PC,$S820 ;CALL

```

```

3810          RETURN                                ; ADDRESS OF 1ST CHARACTER IS ON THE STACK
3811          ;
3812          ; NOTE: THIS FORM OF 'SSB20' MUST BE USED, THE PROGRAM CANNOT USE THE
3813          ; VERSION OF THIS ROUTINE WHICH IS ON THE SYSMAC LIBRARY, REV C OR LATER.
3814          ;
3815 015574 016637 000002 015620 SSB20: MOV 2(SP), 1$ ; SAVE THE BINARY NUMBER
3816 015602 012746 015620      MOV 1$, -(SP) ; SET POINTER
3817 015606 004737 020624      JSR PC, $DB20 ; CALL DOUBLE LENGTH CONVERT
3818 015612 012666 000002      MOV (SP)+, 2(SP) ; PICKUP THE POINTER
3819 015616 000207              RTS PC ; RETURN
3820 015620 000000 000000      1$: .WORD 0,0

; ; *****
; .SBTTL MACRO ROUTINES
; .SBTTL ERROR HANDLER ROUTINE
; ; *****
; * THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
; * SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
; * AND GO TO TYPERR ON ERROR
; * THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
; * SW15=1 HALT ON ERROR
; * SW13=1 INHIBIT ERROR TYPEOUTS
; * SW10=1 BELL ON ERROR
; * CALL
; * ERROR N ; ; ERROR=EMT AND N=ERROR ITEM NUMBER

3837          *
3838          *
3839          *
3840          *
3841          *
3842          *
3843          *
3844          *
3845          *
3846          *
3847          *
3848          *
3849          *
3850          *
3851          *
3852          *
3853          *
3854          *
3855          *
3856          *
3857          *
3858          *
3859          *
3860          *
3861          *
3862          *
3863          *
3864          *
3865          *
3866          *
3867          *
3868          *
3869          *
3870          *
3871          *
3872          *
3873          *
3874          *
3875          *
3876          *
3877          *
3878          *
3879          *
3880          *
3881          *
3882          *
3883          *
3884          *
3885          *
3886          *
3887          *
3888          *
3889          *
3890          *
3891          *
3892          *
3893          *
3894          *
3895          *
3896          *
3897          *
3898          *
3899          *
3900          *
3901          *
3902          *
3903          *
3904          *
3905          *
3906          *
3907          *
3908          *
3909          *
3910          *
3911          *
3912          *
3913          *
3914          *
3915          *
3916          *
3917          *
3918          *
3919          *
3920          *
3921          *
3922          *
3923          *
3924          *
3925          *
3926          *
3927          *
3928          *
3929          *
3930          *
3931          *
3932          *
3933          *
3934          *
3935          *
3936          *
3937          *
3938          *
3939          *
3940          *
3941          *
3942          *
3943          *
3944          *
3945          *
3946          *
3947          *
3948          *
3949          *
3950          *
3951          *
3952          *
3953          *
3954          *
3955          *
3956          *
3957          *
3958          *
3959          *
3960          *
3961          *
3962          *
3963          *
3964          *
3965          *
3966          *
3967          *
3968          *
3969          *
3970          *
3971          *
3972          *
3973          *
3974          *
3975          *
3976          *
3977          *
3978          *
3979          *
3980          *
3981          *
3982          *
3983          *
3984          *
3985          *
3986          *
3987          *
3988          *
3989          *
3990          *
3991          *
3992          *
3993          *
3994          *
3995          *
3996          *
3997          *
3998          *
3999          *
4000          *

```

```

3866 015766 001402          BEQ      1S          ;;NO - SKIP
3867 015770 104401 001206    TYPE     ,SBELL      ;;RING BELL
3868 015774 005237 001112    1S:    INC      $ERTTL  ;;COUNT THE NUMBER OF ERRORS
3869 016000 011637 001116    MOV     (SP), $ERRPC  ;;GET ADDRESS OF ERROR INSTRUCTION
3870 016004 162737 000002 001116  SUB     #2, $ERRPC
3871 016012 117737 163100 001114  MOVB   #2, $ERRPC, $ITEMB ;;STRIP AND SAVE THE ERROR ITEM CODE
3872 016020 032777 020000 163112  BIT    #BIT13, $SMR      ;;SKIP TYPEOUT IF SET
3873 016026 001004          BNE     20S         ;;SKIP TYPEOUTS
3874 016030 004737 012130    JSR    PC, $TYPERR      ;;GO TO USER ERROR ROUTINE
3875 016034 104401 001213    TYPE   , $CRLF
3876 016040          20S:
3877 016040 005777 163074    2S:    TST     $SMR          ;;HALT ON ERROR
3878 016044 100002          BPL     3S          ;;SKIP IF CONTINUE
3879 016046 000000          HALT
3880 016050 104407          CKSMR      ;;HALT ON ERROR!
3881 016052          3S:
3882 016052 000002          RTI          ;;RETURN
3883
3884          .SBTTL TYPE ROUTINE
3885
3886          ;;*****
3887          ;;ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
3888          ;;THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
3889          ;;NOTE1:          $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
3890          ;;NOTE2:          $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
3891          ;;NOTE3:          $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
3892          ;;
3893          ;;CALL:
3894          ;;1) USING A TRAP INSTRUCTION
3895          ;;      TYPE      ,MESADR          ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
3896          ;;OR
3897          ;;      TYPE
3898          ;;      MESADR
3899          ;;
3900
3901 016054 105737 001157    STYPE: TSTB   $TPFLG      ;;IS THERE A TERMINAL?
3902 016060 100002          BPL     1S          ;;BR IF YES
3903 016062 000000          HALT          ;;HALT HERE IF NO TERMINAL
3904 016064 000407          BR     3S          ;;LEAVE
3905 016066 010046    1S:    MOV     RD, -(SP)      ;;SAVE RD
3906 016070 017600 000002    MOV     #2(SP), RD      ;;GET ADDRESS OF ASCIZ STRING
3907 016074 112046    2S:    MOVB   (RD)+, -(SP)    ;;PUSH CHARACTER TO BE TYPED ONTO STACK
3908 016076 001005          BNE     4S          ;;BR IF IT ISN'T THE TERMINATOR
3909 016100 005726          TST    (SP)+          ;;IF TERMINATOR POP IT OFF THE STACK
3910 016102 012600    60S:  MOV     (SP)+, RD      ;;RESTORE RD
3911 016104 062716 000002    3S:    ADD     #2, (SP)      ;;ADJUST RETURN PC
3912 016110 000002          RTI          ;;RETURN
3913 016112 122716 000011    4S:    CMPEB $HT, (SP)      ;;BRANCH IF <HT>
3914 016116 001430          BEQ     8S
3915 016120 122716 000200    CMPEB  $CRLF, (SP)     ;;BRANCH IF NOT <CRLF>
3916 016124 001006          BNE     5S
3917 016126 005726          TST    (SP)+          ;;POP <R><LF> EQUIV
3918 016130 104401          TYPE   /CR AND LF    ;;TYPE /CR AND LF
3919 016132 001213          SCRLF
3920 016134 105037 016270    CLRB   $CHARCNT      ;;CLEAR CHARACTER COUNT
3921 016140 000755          BR     2S          ;;GET NEXT CHARACTER

```

```

3922 016142 004737 016224 5S: JSR PC,STYPEC ;;GO TYPE THIS CHARACTER
3923 016146 123726 001156 6S: CMPB SFILLC,(SP)+ ;;IS IT TIME FOR FILLER CHARS.?
3924 016152 001350 001154 BNE 2S ;;IF NO GO GET NEXT CHAR.
3925 016154 013746 001154 MOV SNULL,-(SP) ;;GET # OF FILLER CHARS. NEEDED
3926 016160 105366 000001 7S: DECB 1(SP) ;;AND THE NULL CHAR.
3927 016164 002770 BLT 6S ;;DOES A NULL NEED TO BE TYPED?
3928 016166 004737 016224 JSR PC,STYPEC ;;BR IF NO--GO POP THE NULL OFF OF STACK
3929 016172 105337 016270 DECB SCHARCNT ;;GO TYPE A NULL
3930 016176 000770 BR 7S ;;DO NOT COUNT AS A COUNT
3931 ;;LOOP

```

;HORIZONTAL TAB PROCESSOR

```

3932 016200 112716 000040 8S: MOVB #' (SP) ;;REPLACE TAB WITH SPACE
3933 016204 004737 016224 9S: JSR PC,STYPEC ;;TYPE A SPACE
3934 016210 132737 000007 016270 BITB #'SCHARCNT ;;BRANCH IF NOT AT
3935 016216 001372 BNE 9S ;;TAB STOP
3936 016220 005726 TST (SP)+ ;;POP SPACE OFF STACK
3937 016222 000724 BR 2S ;;GET NEXT CHARACTER
3938 016224 105777 162720 STYPEC: TSTB STPS ;;WAIT UNTIL PRINTER IS READY
3939 016230 100375 BPL STYPEC
3940 016232 116677 000002 162712 MOVB 2(SP),STPB ;;LOAD CHAR TO BE TYPED INTO DATA REG.
3941 016240 122766 000015 000002 CMPB #CR,2(SP) ;;IS CHARACTER A CARRIAGE RETURN?
3942 016246 001003 BNE 1S ;;BRANCH IF NO
3943 016250 105037 016270 CLAB SCHARCNT ;;YES--CLEAR CHARACTER COUNT
3944 016254 000406 BR STYPEX ;;EXIT
3945 016256 122766 000012 000002 1S: CMPB #LF,2(SP) ;;IS CHARACTER A LINE FEED?
3946 016264 001402 BEQ STYPEX ;;BRANCH IF YES
3947 016266 105227 INCB (PC)+ ;;COUNT THE CHARACTER
3948 016270 000000 SCHARCNT: WORD 0 ;;CHARACTER COUNT STORAGE
3949 016272 000207 STYPEX: RTS PC

```

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

```

*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
*OCTAL (ASCII) NUMBER AND TYPE IT.
*STYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*   MOV   NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOS      ;;CALL FOR TYPEOUT
*   .BYTE  N           ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*   .BYTE  M           ;;M=1 OR 0
*                               ;;1=TYPE LEADING ZEROS
*                               ;;0=SUPPRESS LEADING ZEROS
*
*STYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*STYPOS OR STYPOC
*CALL:
*   MOV   NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPON      ;;CALL FOR TYPEOUT
*
*STYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
*CALL:
*   MOV   NUM,-(SP)      ;;NUMBER TO BE TYPED

```

3950
3951
3952
3953
3954
3955
3956
3957
3958
3959
3970
3971
3972
3973
3974
3975
3976
3977

```

3978 ;*          TYPOC          ;;CALL FOR TYPEOUT
3979
3980 016274 017646 000000          STYPOS: MOV      2(SP),-(SP)          ;; PICKUP THE MODE
3981 016300 116637 000001 016517 MOVB     1(SP),SOFILL          ;; LOAD ZERO FILL SWITCH
3982 016306 112637 016521          MOVB     (SP)+,SOMODE+1          ;; NUMBER OF DIGITS TO TYPE
3983 016312 062716 000002          ADD      2, (SP)              ;; ADJUST RETURN ADDRESS
3984 016316 000406          BR       STYPOS
3985 016320 112737 000001 016517 STYPOC: MOVB     21,SOFILL          ;; SET THE ZERO FILL SWITCH
3986 016326 112737 000006 016521 MOVB     26,SOMODE+1          ;; SET FOR SIX(6) DIGITS
3987 016334 112737 000005 016516 STYPON: MOVB     25,SOCNT          ;; SET THE ITERATION COUNT
3988 016342 010346          MOV      R3,-(SP)            ;; SAVE R3
3989 016344 010446          MOV      R4,-(SP)            ;; SAVE R4
3990 016346 010546          MOV      R5,-(SP)            ;; SAVE R5
3991 016350 113704 016521          MOVB     SOMODE+1,R4          ;; GET THE NUMBER OF DIGITS TO TYPE
3992 016354 005404          NEG      R4
3993 016356 062704 000006          ADD      26,R4              ;; SUBTRACT IT FOR MAX. ALLOWED
3994 016362 110437 016520          MOVB     R4,SOMODE          ;; SAVE IT FOR USE
3995 016366 113704 016517          MOVB     SOFILL,R4          ;; GET THE ZERO FILL SWITCH
3996 016372 016605 000012          MOV      12(SP),R5          ;; PICKUP THE INPUT NUMBER
3997 016376 005003          CLR      R3                ;; CLEAR THE OUTPUT WORD
3998 016400 006105          1S:     ROL      R5          ;; ROTATE MSB INTO "C"
3999 016402 000404          BR       3S
4000 016404 006105          2S:     ROL      R5          ;; FORM THIS DIGIT
4001 016406 006105          ROL      R5
4002 016410 006105          ROL      R5
4003 016412 010503          MOV      R5,R3
4004 016414 006103          3S:     ROL      R3          ;; GET LSB OF THIS DIGIT
4005 016416 105337 016520          DECB    SOMODE          ;; TYPE THIS DIGIT?
4006 016422 100016          BPL     7S              ;; BR IF NO
4007 016424 042703 177770          BIC     2177770,R3          ;; GET RID OF JUNK
4008 016430 001002          BNE     4S              ;; TEST FOR 0
4009 016432 005704          TST     R4              ;; SUPPRESS THIS 0?
4010 016434 001403          BEQ     5S              ;; BR IF YES
4011 016436 005204          4S:     INC      R4          ;; DON'T SUPPRESS ANYMORE 0'S
4012 016440 052703 000060          BIS     8'0,R3          ;; MAKE THIS DIGIT ASCII
4013 016444 052703 000040          5S:     BIS     8'R3          ;; MAKE ASCII IF NOT ALREADY
4014 016450 110337 016514          MOVB    R3,2S          ;; SAVE FOR TYPING
4015 016454 104401 016514          TYPE    2S              ;; GO TYPE THIS DIGIT
4016 016460 105337 016516          7S:     DECB    SOCNT          ;; COUNT BY 1
4017 016464 003347          BGT     2S              ;; BR IF MORE TO DO
4018 016466 002402          BLT     6S              ;; BR IF DONE
4019 016470 005204          INC     R4              ;; INSURE LAST DIGIT ISN'T A BLANK
4020 016472 000744          BR      2S              ;; GO DO THE LAST DIGIT
4021 016474 012605          6S:     MOV     (SP)+,R5          ;; RESTORE R5
4022 016476 012604          MOV     (SP)+,R4          ;; RESTORE R4
4023 016500 012603          MOV     (SP)+,R3          ;; RESTORE R3
4024 016502 016666 000002 000004 MOV     2(SP),4(SP)          ;; SET THE STACK FOR RETURNING
4025 016510 012616          MOV     (SP)+,(SP)
4026 016512 000002          RTI
4027 016514 000          8S:     .BYTE   0          ;; RETURN
4028 016515 000          .BYTE   0          ;; STORAGE FOR ASCII DIGIT
4029 016516 000          SOCNT:  .BYTE   0          ;; TERMINATOR FOR TYPE ROUTINE
4030 016517 000          SOFILL: .BYTE   0          ;; OCTAL DIGIT COUNTER
4031 016520 000000          SOMODE: .WORD   0          ;; ZERO FILL SWITCH
4032
4033          .SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

```

```

4034
4035
4036
4037
4038
4039
4040
4041
4042
4043
4044
4045 016522
4046 016522 010046
4047 016524 010146
4048 016526 010246
4049 016530 010346
4050 016532 010546
4051 016534 012746 020200
4052 016540 016605 000020
4053 016544 100004
4054 016546 005405
4055 016550 112766 000055, 000001
4056 016556 005000
4057 016560 012703 016736
4058 016564 112723 000040
4059 016570 005002
4060 016572 016001 016726
4061 016576 160105
4062 016600 002402
4063 016602 005202
4064 016604 000774
4065 016606 060105
4066 016610 005702
4067 016612 001002
4068 016614 105716
4069 016616 100407
4070 016620 106316
4071 016622 103003
4072 016624 116663 000001 177777
4073 016632 052702 000060
4074 016636 052702 000040
4075 016642 110223
4076 016644 005720
4077 016646 020027 000010
4078 016652 002746
4079 016654 003002
4080 016656 010502
4081 016660 000764
4082 016662 105726
4083 016664 100003
4084 016666 116663 177777 177776
4085 016674 105013
4086 016676 012605
4087 016700 012603
4088 016702 012602
4089 016704 012601

*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
*REPLACED WITH SPACES.
*CALL:
*      MOV      NUM,-(SP)          ;;PUT THE BINARY NUMBER ON THE STACK
*      TYPDS                    ;;GO TO THE ROUTINE

STYPDS:
MOV      R0,-(SP)                ;;PUSH R0 ON STACK
MOV      R1,-(SP)                ;;PUSH R1 ON STACK
MOV      R2,-(SP)                ;;PUSH R2 ON STACK
MOV      R3,-(SP)                ;;PUSH R3 ON STACK
MOV      R5,-(SP)                ;;PUSH R5 ON STACK
MOV      #20200,-(SP)            ;;SET BLANK SWITCH AND SIGN
MOV      20(SP),R5                ;;GET THE INPUT NUMBER
BPL      IS                        ;;BR IF INPUT IS POS.
NEG      R5                        ;;MAKE THE BINARY NUMBER POS.
MOVB    #'-,1(SP)                ;;MAKE THE ASCII NUMBER NEG.
CLR      R0                        ;;ZERO THE CONSTANTS INDEX
MOV      #5DBLK,R3                ;;SETUP THE OUTPUT POINTER
MOVB    #' ,(R3)+                ;;SET THE FIRST CHARACTER TO A BLANK
2S:     CLR      R2                ;;CLEAR THE BCD NUMBER
MOV      SDTBL(R0),R1            ;;GET THE CONSTANT
3S:     SUB      R1,R5                ;;FORM THIS BCD DIGIT
BLT     4S                        ;;BR IF DONE
INC      R2                        ;;INCREASE THE BCD DIGIT BY 1
4S:     ADD      R1,R5                ;;ADD BACK THE CONSTANT
TST     R2                        ;;CHECK IF BCD DIGIT=0
BNE     5S                        ;;FALL THROUGH IF 0
TSTB   (SP)                        ;;STILL DOING LEADING 0'S?
BMI     7S                        ;;BR IF YES
5S:     ASLB    (SP)                ;;MSD?
BCC     6S                        ;;BR IF NO
6S:     MOVB   1(SP),-1(R3)        ;;YES--SET THE SIGN
BIS     #'0,R2                    ;;MAKE THE BCD DIGIT ASCII
7S:     BIS     #' ,R2                ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
MOVB   R2,(R3)+                ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
TST    (R0)+                    ;;JUST INCREMENTING
CMP    R0,#10                    ;;CHECK THE TABLE INDEX
BLT    2S                        ;;GO DO THE NEXT DIGIT
BGT    8S                        ;;GO TO EXIT
MOV    R5,R2                    ;;GET THE LSD
BR     6S                        ;;GO CHANGE TO ASCII
8S:     TSTB   (SP)+                ;;WAS THE LSD THE FIRST NON-ZERO?
BPL    9S                        ;;BR IF NO
9S:     MOVB   -1(SP),-2(R3)        ;;YES--SET THE SIGN FOR TYPING
CLRB   (R3)                    ;;SET THE TERMINATOR
MOV    (SP)+,R5                ;;POP STACK INTO R5
MOV    (SP)+,R3                ;;POP STACK INTO R3
MOV    (SP)+,R2                ;;POP STACK INTO R2
MOV    (SP)+,R1                ;;POP STACK INTO R1
    
```

```

4090 016706 012600          MOV      (SP)+,RO      ;;POP STACK INTO RO
4091 016710 104401 016736  TYPE      $DBLK      ;;NOW TYPE THE NUMBER
4092 016714 016666 000002 000004  MOV      2(SP),4(SP)  ;;ADJUST THE STACK
4093 016722 012616          MOV      (SP)+,(SP)
4094 016724 000002          RTI                      ;;RETURN TO USER
4095 016726 023420          SDBLK: 10000.
4096 016730 001750          1000.
4097 016732 000144          100.
4098 016734 000012          10.
4099 016736 000004          SDBLK: .BLKW 4
4100
4101          .SBTTL  TTY INPUT ROUTINE
4102
4103          ;;*****
4104          .ENABL  LSB
4105 016746 000000  STKCNT: .WORD 0      ;;NUMBER OF ITEMS IN QUEUE
4106 016750 000000  STKQIN: .WORD 0      ;;INPUT POINTER
4107 016752 000000  STKQOUT: .WORD 0    ;;OUTPUT POINTER
4108 016754 000001  STKQSRV: .BLKB 1    ;;TTY KEYBOARD QUEUE
4109          STKQEND=.
4110          .EVEN
4111
4112          ;;TK INITIALIZE ROUTINE
4113          ;;THIS ROUTINE WILL INITIALIZE THE TTY KEYBOARD INPUT QUEUE
4114          ;;SETUP THE INTERRUPT VECTOR AND TURN ON THE KEYBOARD INTERRUPT
4115
4116          ;;CALL:
4117          *      JSR      PC,STKINT
4118          *      RETURN
4119
4120 016756 005037 016746  STKINT: CLR      STKCNT      ;;CLEAR COUNT OF ITEMS IN QUEUE
4121 016762 012737 016754 016750  MOV      $STKQSRV,STKQIN  ;;MOVE THE STARTING ADDRESS OF THE
4122 016770 013737 016750 016752  MOV      STKQIN,STKQOUT  ;;QUEUE INTO THE INPUT & OUTPUT POINTERS.
4123 016776 012737 017026 000060  MOV      $STKSRV,$STKVEC  ;;INITIALIZE THE KEYBOARD VECTOR
4124 017004 012737 000200 000062  MOV      $200,$STKVEC+2  ;;"BR" LEVEL 4
4125 017012 005777 162130  TST      $STKB          ;;CLEAR DONE FLAG
4126 017016 012777 000100 162120  MOV      $100,$STKS      ;;ENABLE TTY KEYBOARD INTERRUPT
4127 017024 000207          RTS      PC          ;;RETURN TO CALLER
4128
4129          ;;TK SERVICE ROUTINE
4130          ;;THIS ROUTINE WILL SERVICE THE TTY KEYBOARD INTERRUPT
4131          ;;BY READING THE CHARACTER FROM THE INPUT BUFFER AND PUTTING
4132          ;;IT IN THE QUEUE.
4133          ;;IF THE CHARACTER IS A "CONTROL-C" (1C) STKINT IS CALLED AND
4134          ;;UPON RETURN EXIT IS MADE TO THE "CONTROL-C" RESTART ADDRESS ($CNTRLC)
4135
4136 017026 117746 162114  STKSRV: MOVB     $STKB,-(SP)  ;;PICKUP THE CHARACTER
4137 017032 042716 177600  BIC      $1C177,(SP)      ;;STRIP THE JUNK
4138 017036 021627 000003  CMP      (SP),#3          ;;IS IT A CONTROL C?
4139 017042 001007          BNE      1$              ;;BRANCH IF NO
4140 017044 104401 020144  TYPE     $CNTLC          ;;TYPE A CONTROL-C (1C)
4141 017050 004737 016756  JSR      PC,STKINT        ;;INIT THE KEYBOARD
4142 017054 005726          TST      (SP)+          ;;CLEAN UP STACK
4143 017056 000177 162160  JMP      $CNTRLC         ;;CONTROL C RESTART
4144 017062 021627 000007  1$:     CMP      (SP),#7    ;;IS IT A CONTROL G?
4145 017066 001004          BNE      2$              ;;BRANCH IF NO

```



```

4146 017070 022737 000176 001140      CMP    #SWREG,SWR      ;; IS SOFT-SWR SELECTED?
4147 017076 001500                      BEQ    65              ;; GO TO SWR CHANGE
4148
4149 017100                      25:    CMP    #1,STKCNT      ;; IS THE QUEUE FULL?
4150 017100 022737 000001 016746      BNE    35              ;; BRANCH IF NO
4151 017106 001004                      TYPE   #BELL          ;; RING THE TTY BELL
4152 017110 104401 001206                      TST   (SP)+           ;; CLEAN CHARACTER OFF OF STACK
4153 017114 005726                      BR     55              ;; EXIT
4154 017116 000451                      35:    CMP    (SP),#23      ;; IS IT A CONTROL-S?
4155 017120 021627 000023      BNE    325            ;; BRANCH IF NO
4156 017124 001021                      CLR   #STKS          ;; DISABLE TTY KEYBOARD INTERRUPTS
4157 017126 005077 162012      TST   (SP)+           ;; CLEAN CHAR OFF STACK
4158 017132 005726                      315:  TSTB  #STKS          ;; WAIT FOR A CHAR
4159 017134 105777 162004      BPL   315             ;; LOOP UNTIL ITS THERE
4160 017140 100375                      MOVB  #STKB,-(SP)     ;; GET THE CHARACTER
4161 017142 117746 162000      BIC   #1C177,(SP)    ;; MAKE IT 7-BIT ASCII
4162 017146 042716 177600      CMP   (SP)+,#21      ;; IS IT A CONTROL-Q?
4163 017152 022627 000021      BNE   315            ;; BRANCH IF NO
4164 017156 001366                      MOV   #100,#STKS     ;; REENABLE TTY KEYBOARD INTERRUPTS
4165 017160 012777 000100 161756      RTI                          ;; RETURN
4166 017166 000002                      325:  INC   STKCNT         ;; COUNT THIS CHARACTER
4167 017170 005237 016746      CMP   (SP),#140      ;; IS IT UPPER CASE?
4168 017174 021627 000140      BLT   45              ;; BRANCH IF YES
4169 017200 002405                      CMP   (SP),#175      ;; IS IT A SPECIAL CHAR?
4170 017202 021627 000175      BGT   45              ;; BRANCH IF YES
4171 017206 003002                      BIC   #40,(SP)       ;; MAKE IT UPPER CASE
4172 017210 042716 000040      MOVB  (SP)+,#STKQIN  ;; AND PUT IT IN QUEUE
4173 017214 112677 177530      INC   STKQIN         ;; UPDATE THE POINTER
4174 017220 005237 016750      CMP   STKQIN,#STKQEND ;; GO OFF THE END?
4175 017224 023727 016750 016755      BNE   55              ;; BRANCH IF NO
4176 017232 001003                      MOV   #STKQRT,STKQIN ;; RESET THE POINTER
4177 017234 012737 016754 016750      RTI                          ;; RETURN
4178 017242 000002
4179
4180
4181
4182
4183
4184
4185 017244 022737 000176 001140 $CKSWR: CMP    #SWREG,SWR      ;; IS THE SOFT-SWR SELECTED
4186 017252 001124                      BNE   155             ;; EXIT IF NOT
4187 017254 105777 161664      TSTB  #STKS          ;; IS A CHAR WAITING?
4188 017260 100121                      BPL   155             ;; IF NOT, EXIT
4189 017262 117746 161660      MOVB  #STKB,-(SP)     ;; YES
4190 017266 042716 177600      BIC   #1C177,(SP)    ;; MAKE IT 7-BIT ASCII
4191 017272 021627 000007      CMP   (SP),#7        ;; IS IT A CONTROL-G?
4192 017276 001300      BNE   25              ;; IF NOT, PUT IT IN THE TTY QUEUE
4193
4194
4195
4196
4197
4198
4199 017300 123727 001134 000001 65:    CMPB  $AUTOB,#1      ;; ARE WE RUNNING IN AUTO-MODE?
4200 017306 001674                      BEQ   25              ;; BRANCH IF YES
4201 017310 005726                      TST  (SP)+           ;; CLEAR CONTROL-G OFF STACK

```

```

*****
;SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
;ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
;SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP
;CALL WHEN OPERATING IN TTY INTERRUPT MODE.

```

```

*****
;CONTROL IS PASSED TO THIS POINT FROM EITHER THE TTY INTERRUPT SERVICE
;ROUTINE OR FROM THE SOFTWARE SWITCH REGISTER TRAP CALL, AS A RESULT OF A
;CONTROL-G BEING TYPED, AND THE SOFTWARE SWITCH REGISTER BEING SELECTED.

```

4202	017312	004737	016756		JSR	PC,STKINT	::: FLUSH THE TTY INPUT QUEUE
4203	017316	005077	161622		CLR	2STKS	::: DISABLE TTY KEYBOARD INTERRUPTS
4204	017322	112737	000001	001135	MOVB	#1,\$INTAG	::: SET INTERRUPT MODE INDICATOR
4205							
4206	017330	104401	020156		TYPE	,SCNTLG	::: ECHO THE CONTROL-G (↑G)
4207	017334	104401	020163		SGTSMR: TYPE	,SMSWR	::: TYPE CURRENT CONTENTS
4208	017340	013746	000176		MOV	SWREG,-(SP)	::: SAVE SWREG FOR TYPEOUT
4209	017344	104402			TYPOC		::: GO TYPE--OCTAL ASCII(ALL DIGITS)
4210	017346	104401	020174		TYPE	,SMNEW	::: PROMPT FOR NEW SMR
4211	017352	005046			19S: CLR	-(SP)	::: CLEAR COUNTER
4212	017354	005046			CLR	-(SP)	::: THE NEW SMR
4213	017356	105777	161562		7S: TSTB	2STKS	::: CHAR THERE?
4214	017362	100375			BPL	7S	::: IF NOT TRY AGAIN
4215							
4216	017364	117746	161556		MOVB	2STKB,-(SP)	::: PICK UP CHAR
4217	017370	042716	177600		BIC	#1C177,(SP)	::: MAKE IT 7-BIT ASCII
4218							
4219	017374	021627	000003		CMP	(SP),#3	::: IS IT A CONTROL-C?
4220	017400	001015			BNE	9S	::: BRANCH IF NOT
4221	017402	104401	020144		TYPE	,SCNTLC	::: YES, ECHO CONTROL-C (↑C)
4222	017406	062706	000006		ADD	#6,SP	::: CLEAN UP STACK
4223	017412	123727	001135	000001	CMPB	\$INTAG,#1	::: REENABLE TTY KEYBOARD INTERRUPTS?
4224	017420	001003			BNE	8S	::: BRANCH IF NO
4225	017422	012777	000100	161514	MOV	#100,2STKS	::: ALLOW TTY KEYBOARD INTERRUPTS
4226	017430	000177	161606		8S: JMP	2CNTRLC	::: CONTROL-C RESTART
4227							
4228							
4229	017434	021627	000025		9S: CMP	(SP),#25	::: IS IT A CONTROL-U?
4230	017440	001005			BNE	10S	::: BRANCH IF NOT
4231	017442	104401	020151		TYPE	,SCNTLU	::: YES, ECHO CONTROL-U (↑U)
4232	017446	062706	000006		20S: ADD	#6,SP	::: IGNORE PREVIOUS INPUT
4233	017452	000737			BR	19S	::: LET'S TRY IT AGAIN
4234							
4235							
4236	017454	021627	000015		10S: CMP	(SP),#15	::: IS IT A <CR>?
4237	017460	001022			BNE	16S	::: BRANCH IF NO
4238	017462	005766	000004		TST	4(SP)	::: YES, IS IT THE FIRST CHAR?
4239	017466	001403			BEQ	11S	::: BRANCH IF YES
4240	017470	016677	000002	161442	MOV	2(SP),2SMR	::: SAVE NEW SMR
4241	017476	062706	000006		11S: ADD	#6,SP	::: CLEAN UP STACK
4242	017502	104401	001213		14S: TYPE	,SCRLF	::: ECHO <CR> AND <LF>
4243	017506	123727	001135	000001	CMPB	\$INTAG,#1	::: RE-ENABLE TTY KBD INTERRUPTS?
4244	017514	001003			BNE	15S	::: BRANCH IF NOT
4245	017516	012777	000100	161420	MOV	#100,2STKS	::: RE-ENABLE TTY KBD INTERRUPTS
4246	017524	000002			15S: RTI		::: RETURN
4247	017526	004737	016224		16S: JSR	PC,STYPEC	::: ECHO CHAR
4248	017532	021627	000060			(SP),#60	::: CHAR < 0?
4249	017536	002420			BLT	18S	::: BRANCH IF YES
4250	017540	021627	000067		CMP	(SP),#67	::: CHAR > 7?
4251	017544	003015			BGT	18S	::: BRANCH IF YES
4252	017546	042726	000060		BIC	#60,(SP)+	::: STRIP-OFF ASCII
4253	017552	005766	000002		TST	2(SP)	::: IS THIS THE FIRST CHAR
4254	017556	001403			BEQ	17S	::: BRANCH IF YES
4255	017560	006316			ASL	(SP)	::: NO, SHIFT PRESENT
4256	017562	006316			ASL	(SP)	::: CHAR OVER TO MAKE
4257	017564	006316			ASL	(SP)	::: ROOM FOR NEW ONE.

```

4258 017566 005266 000002      17S:  INC      2(SP)      ;;KEEP COUNT OF CHAR
4259 017572 056616 177776      BIS      -2(SP), (SP)  ;;SET IN NEW CHAR
4260 017576 000667          BR       7S           ;;GET THE NEXT ONE
4261 017600 104401 001212      18S:  TYPE     $QUES     ;;TYPE ?<CR><LF>
4262 017604 000720          BR       20S         ;;SIMULATE CONTROL-U
4263
4264
4265
4266
4267
4268
4269
4270
4271
4272
4273
4274 017606 011646          SRDCHR: MOV      (SP), -(SP)  ;;PUSH DOWN THE PC AND
4275 017610 016666 000004 000002  MOV      4(SP), 2(SP)  ;;THE PS
4276 017616 005066 000004          CLR      4(SP)        ;;GET READY FOR A CHARACTER
4277 017622 005046          CLR      -(SP)        ;;PUT NEW PS ON STACK
4278 017624 012746 017632  MOV      #64S, -(SP)   ;;PUT NEW PC ON STACK
4279 017630 000002          RTI                    ;;POP NEW PC AND PS
4280 017632
4281 017632 005737 016746      64S:  TST      STKCNT      ;;WAIT ON A CHARACTER
4282 017636 001775          BEQ      1S           ;;
4283 017640 005337 016746      1S:   DEC      STKCNT      ;;DECREMENT THE COUNTER
4284 017644 117766 177102 000004  MOVB    2STKGOUT, 4(SP) ;;GET ONE CHARACTER
4285 017652 005237 016752          INC      STKGOUT      ;;UPDATE THE POINTER
4286 017656 023727 016752 016755  CMP     STKGOUT, #STKGEND ;;DID IT GO OFF OF THE END?
4287 017664 001003          BNE     2S           ;;BRANCH IF NO
4288 017666 012737 016754 016752  MOV     #STKQSRT, STKGOUT ;;RESET THE POINTER
4289 017674 000002          RTI                    ;;RETURN
4290
4291
4292
4293
4294
4295
4296
4297 017676 010346          SRDLIN: MOV     R3, -(SP)  ;;SAVE R3
4298 017700 005046          CLR     -(SP)        ;;CLEAR THE RUBOUT KEY
4299 017702 012703 020132      1S:   MOV     #STTYIN, R3  ;;GET ADDRESS
4300 017706 022703 020144      2S:   CMP     #STTYIN+10., R3 ;;BUFFER FULL?
4301 017712 101456          BLOS    4S           ;;BR IF YES
4302 017714 104410          RDCHR   ;;GO READ ONE CHARACTER FROM THE TTY
4303 017716 112613          MOVB   (SP)+, (R3)   ;;GET CHARACTER
4304 017720 122713 000177      10S:  CMPB   #177, (R3)   ;;IS IT A RUBOUT
4305 017724 001022          BNE    5S           ;;BR IF NO
4306 017726 005716          TST    (SP)         ;;IS THIS THE FIRST RUBOUT?
4307 017730 001007          BNE    6S           ;;BR IF NO
4308 017732 112737 000134 020130  MOVB   #' \, 9S     ;;TYPE A BACK SLASH
4309 017740 104401 020130          TYPE   9S
4310 017744 012716 177777          MOV    #-1, (SP)    ;;SET THE RUBOUT KEY
4311 017750 005303      6S:   DEC    R3           ;;BACKUP BY ONE
4312 017752 020327 020132      CMP    R3, #STTYIN  ;;STACK EMPTY?
4313 017756 103434          BLO    4S           ;;BR IF YES

```

```

4314 017760 111337 020130      MOVB      (R3),9S      ;;SETUP TO TYPEOUT THE DELETED CHAR.
4315 017764 104401 020130      TYPE      9S          ;;GO TYPE
4316 017770 000746                BR        2S          ;;GO READ ANOTHER CHAR.
4317 017772 005716                TST      (SP)        ;;RUBOUT KEY SET?
4318 017774 001406                BEQ      7S          ;;BR IF NO
4319 017776 112737 000134 020130      MOVB      #' \,9S    ;;TYPE A BACK SLASH
4320 020004 104401 020130      TYPE      9S          ;;
4321 020010 005016                CLR      (SP)        ;;CLEAR THE RUBOUT KEY
4322 020012 122713 000025      7S:      CMPB      #25,(R3)  ;;IS CHARACTER A CTRL U?
4323 020016 001003                BNE      8S          ;;BR IF NO
4324 020020 104401 020151      TYPE      ,SCNTLU    ;;TYPE A CONTROL "U"
4325 020024 000726                BR        1S          ;;GO START OVER
4326 020026 122713 000022      8S:      CMPB      #22,(R3)  ;;IS CHARACTER A "r"?
4327 020032 001011                BNE      3S          ;;BRANCH IF NO
4328 020034 105013                CLRB     (R3)        ;;CLEAR THE CHARACTER
4329 020036 104401 001213      TYPE      ,SCALF     ;;TYPE A "CR" & "LF"
4330 020042 104401 020132      TYPE      ,STTYIN   ;;TYPE THE INPUT STRING
4331 020046 000717                BR        2S          ;;GO PICKUP ANOTHER CHACTER
4332 020050 104401 001212      4S:      TYPE      ,SQUES    ;;TYPE A '?'
4333 020054 000712                BR        1S          ;;CLEAR THE BUFFER AND LOOP
4334 020056 111337 020130      3S:      MOVB      (R3),9S    ;;ECHO THE CHARACTER
4335 020062 104401 020130      TYPE      9S          ;;
4336 020066 122723 000015      CMPB     #15,(R3)+  ;;CHECK FOR RETURN
4337 020072 001305                BNE      2S          ;;LOOP IF NOT RETURN
4338 020074 105063 177777      CLRB     -1(R3)     ;;CLEAR RETURN (THE 15)
4339 020100 104401 001214      TYPE      ,SLF      ;;TYPE A LINE FEED
4340 020104 005726                TST     (SP)+       ;;CLEAN RUBOUT KEY FROM THE STACK
4341 020106 012603                MOV      (SP)+,R3   ;;RESTORE R3
4342 020110 011646                MOV      (SP),-(SP) ;;ADJUST THE STACK AND PUT ADDRESS OF THE
4343 020112 016666 000004 000002      MOV      4(SP),2(SP) ;;FIRST ASCII CHARACTER ON IT
4344 020120 012766 020132 000004      MOV      #STTYIN,4(SP)
4345 020126 000002                RTI
4346 020130 000                9S:      .BYTE    0          ;;RETURN
4347 020131 000                .BYTE    0          ;;STORAGE FOR ASCII CHAR. TO TYPE
4348 020132 000012                STTYIN: .BLKB   10.  ;;TERMINATOR
4349 020144 041536 005015 000      SCNTLC: .ASCIZ  /?C/<15><12>  ;;RESERVE 10. BYTES FOR TTY INPUT
4350 020151 0136 006525 000012      SCNTLU: .ASCIZ  /?U/<15><12>  ;;CONTROL "C"
4351 020156 043536 005015 000      SCNTLG: .ASCIZ  /?G/<15><12>  ;;CONTROL "U"
4352 020163 015 051412 051127      SMSWR:  .ASCIZ  <15><12>/SWR = /  ;;CONTROL "G"
4353 020170 036440 000040
4354 020174 020040 042516 020127      SMNEW:  .ASCIZ  / NEW = /
4355 020202 020075 000
4356 020206                .EVEN
4357
4358                .SBTTL  INTEGER DIVIDE ROUTINE
4359
4360                ;*****
4361                ;THIS ROUTINE WILL DIVIDE A 32-BIT TWO'S COMPLEMENT INTEGER
4362                ;DIVIDEND BY A 16-BIT TWO'S COMPLEMENT INTEGER DIVISOR GIVING
4363                ;A 16-BIT TWO'S COMPLEMENT INTEGER QUOTIENT AND A 16-BIT REMAINDER.
4364                ;DIVISION WILL BE PERFORMED SO THAT THE REMAINDER IS OF THE
4365                ;SAVE SIGN AS THE DIVIDEND.
4366                ;CALL:
4367                ;      MOV      LOW DIVIDEND,-(SP) ;;THE HIGH DIVIDEND MUST BE < 1/2
4368                ;      MOV      HIGH DIVIDEND,-(SP); AS LARGE AS THE DIVISOR
4369                ;      MOV      DIVISOR,-(SP)

```

```

4370      JSR      PC,SDIV
4371      RETURN   ;; QUOTIENT & REMAINDER ARE ON THE STACK
4372      "V"=0   IMPLIES NO ERROR
4373      "V"=1   IMPLIES ERROR OCCURRED
4374      "C"=0   DIVIDE OVERFLOW OCCURRED
4375      "C"=1   ATTEMPTED TO DIVIDE BY ZERO
4376
4377
4378      STACK   NO ERROR      OVERFLOW      DIVIDE BY ZERO
4379      -----
4380      TOP     REMAINDER     ALL ZEROS   ALL ONES
4381      +2     QUOTIENT      ALL ZEROS   ALL ONES
4382
4383      SDIV:
4384      020206 104400      TRAP
4385      020210 042716 000017 BIC      817,(SP)      ;; PUSH OLD PSH AND PC ON STACK
4386      020214 010046      MOV      R0,-(SP)     ;; STRIP AWAY CONDITION CODES
4387      020216 010146      MOV      R1,-(SP)     ;; PUSH R0 ON STACK
4388      020220 010246      MOV      R2,-(SP)     ;; PUSH R1 ON STACK
4389      020222 010346      MOV      R3,-(SP)     ;; PUSH R2 ON STACK
4390      020224 005046      CLR      -(SP)        ;; PUSH R3 ON STACK
4391      020226 012746 000021 MOV      817,-(SP)    ;; SAVE A PLACE FOR SIGNS
4392      020232 016601 000024 MOV      24(SP),R1    ;; SETUP THE ITERATION COUNTER
4393      020236 016600 000022 MOV      22(SP),R0    ;; PICKUP THE DIVIDEND
4394      020242 100005      BPL      1$
4395      020244 105366 000003 DECB     3(SP)        ;; CHECK THE SIGN
4396      020250 005400      NEG      R0           ;; KEEP TRACK OF THE SIGN
4397      020252 005401      NEG      R1           ;; AND NEGATE THE ORIGINAL
4398      020254 005600      SBC      R0           ;; NUMBER
4399      020256 016602 000020 1$: MOV     20(SP),R2    ;; PICKUP THE DIVISOR
4400      020262 002407      BLT      2$
4401      020264 003011      BGT      3$
4402      020266 052766 000003 000014 BIS      83,14(SP)   ;; CHECK THE SIGN
4403      020274 012700 177777 MOV      8-1,R0      ;; DIVISOR OF 0 IS A NO-NO
4404      020300 000424      BR       7$          ;; SET "V" & "C"
4405      020302 005266 000002 2$: INC     2(SP)     ;; SET REMAINDER TO ALL ONES
4406      020306 000401      BR       4$          ;; EXIT
4407      020310 005402 3$: NEG     R2         ;; KEEP TRACK OF DIVISORS SIGN
4408      020312 000241 4$: CLC
4409      020314 000405      BR       6$          ;; NEGATE THE ORIGINAL NUMBER
4410      020316 006100 5$: ROL     R0         ;; CLEAR "C"
4411      020320 010003      MOV      R0,R3       ;; START FORMING QUOTIENT
4412      020322 060203      ADD      R2,R3       ;; POSITION MSB'S
4413      020324 103001      BCC      6$         ;; COPY
4414      020326 010300      MOV      R3,R0       ;; COMPARE DIVIDEND & DIVISOR
4415      020330 006101 6$: ROL     R1         ;; BR IF DIVIDEND > DIVISOR
4416      020332 005316      DEC      (SP)        ;; REMAINDER AFTER THIS LOOP
4417      020334 001370      BNE      5$         ;; QUOTIENT BIT ENTERS HERE
4418      020336 005701      TST      R1         ;; DONE?
4419      020340 100005      BPL      8$         ;; BR IF NO
4420      020342 052766 000002 000014 BIS      82,14(SP)   ;; OVERFLOW?
4421      020350 005000      CLR      R0         ;; BR IF NO
4422      020352 010001 7$: MOV     R0,R1     ;; SET "V" IN RETURN STATUS WORD
4423      020354 005726 8$: TST     (SP)+     ;; SET REMAINDER TO ALL ZEROS
4424      020356 005716      TST     (SP)        ;; COPY REMAINDER INTO QUOTIENT
4425      020360 002004      BGE      9$         ;; CLEAR COUNTER FROM STACK

```

```

;; REMAINDER SIGN CORRECTION NEEDED?
;; BR IF NO

```

```

4426 020362 005400          NEG      RO          ;; NEGATE REMAINDER
4427 020364 105066 000001  CLRB     1(SP)      ;; CLEAR SIGN
4428 020370 005316          DEC      (SP)       ;; BUT DON'T FORGET QUOTIENT
4429 020372 005726          95:    TST      (SP)+  ;; QUOTIENT SIGN CORRECTION NEEDED?
4430 020374 001401          BEQ      105       ;; BR IF NO
4431 020376 005401          NEG      R1          ;; NEGATE QUOTIENT
4432 020400 010166 000020  105:    MOV      R1,20(SP) ;; RETURN QUOTIENT AND
4433 020404 010066 000016  MOV      RO,16(SP)   ;; REMAINDER TO USER
4434 020410 012603          MOV      (SP)+,R3   ;; POP STACK INTO R3
4435 020412 012602          MOV      (SP)+,R2   ;; POP STACK INTO R2
4436 020414 012601          MOV      (SP)+,R1   ;; POP STACK INTO R1
4437 020416 012600          MOV      (SP)+,RO   ;; POP STACK INTO RO
4438 020420 012666 000002  MOV      (SP)+,2(SP) ;; SETUP TO RETURN CONDITION CODES
4439 020424 000002          RTI                    ;; RETURN

```

.SBTTL SAVE AND RESTORE RO-R5 ROUTINES

```

*****
#SAVE RO-R5
#CALL:
# SAVREG
#UPON RETURN FROM SSAVEG THE STACK WILL LOOK LIKE:
#
#TOP---(+16)
# +2---(+18)
# +4---R5
# +6---R4
# +8---R3
#+10---R2
#+12---R1
#+14---RO

```

```

4458 020426          SSAVEG:
4459 020426 010046          MOV      RO,-(SP)   ;; PUSH RO ON STACK
4460 020430 010146          MOV      R1,-(SP)   ;; PUSH R1 ON STACK
4461 020432 010246          MOV      R2,-(SP)   ;; PUSH R2 ON STACK
4462 020434 010346          MOV      R3,-(SP)   ;; PUSH R3 ON STACK
4463 020436 010446          MOV      R4,-(SP)   ;; PUSH R4 ON STACK
4464 020440 010546          MOV      R5,-(SP)   ;; PUSH R5 ON STACK
4465 020442 016646 000022  MOV      (SP),-(SP) ;; SAVE PS OF MAIN FLOW
4466 020446 016646 000022  MOV      (SP),-(SP) ;; SAVE PC OF MAIN FLOW
4467 020452 016646 000022  MOV      (SP),-(SP) ;; SAVE PS OF CALL
4468 020456 016646 000022  MOV      (SP),-(SP) ;; SAVE PC OF CALL
4469 020462 000002          RTI

```

```

#RESTORE RO-R5
#CALL:
# RESREG
#RESREG:
MOV      (SP)+,22(SP) ;; RESTORE PC OF CALL
MOV      (SP)+,22(SP) ;; RESTORE PS OF CALL
MOV      (SP)+,22(SP) ;; RESTORE PC OF MAIN FLOW
MOV      (SP)+,22(SP) ;; RESTORE PS OF MAIN FLOW
MOV      (SP)+,R5    ;; POP STACK INTO R5
MOV      (SP)+,R4    ;; POP STACK INTO R4
MOV      (SP)+,R3    ;; POP STACK INTO R3

```

```

4474 020464          4475 020464 012666 000022
4476 020470 012666 000022
4477 020474 012666 000022
4478 020500 012666 000022
4479 020504 012605
4480 020506 012604
4481 020510 012603

```

```

4482 020512 012602      MOV      (SP)+,R2      ;;POP STACK INTO R2
4483 020514 012601      MOV      (SP)+,R1      ;;POP STACK INTO R1
4484 020516 012600      MOV      (SP)+,R0      ;;POP STACK INTO R0
4485 020520 000002      RTI

```

.SBTTL RANDOM NUMBER GENERATOR ROUTINE

```

*****
;THIS ROUTINE IS A DOUBLE PRECISION PSEUDO RANDOM NUMBER GENERATOR
;WITH A RANGE OF 0 TO 2(+33)-1.

```

```

;CALL:
;      JSR      PC,SRAND      ;;CALL THE ROUTINE
;      RETURN      ;;RETURN HERE THE RANDOM
;                  ;;NUMBER WILL BE IN
;                  ;;SHINUM,SLONUM

```

```

SRAND:
MOV      RO,-(SP)      ;;PUSH RO ON STACK
MOV      R1,-(SP)      ;;PUSH R1 ON STACK
MOV      R2,-(SP)      ;;PUSH R2 ON STACK
MOV      SLONUM,R0     ;;SET RO WITH LOW
MOV      SHINUM,R1     ;;SET R1 WITH HIGH
MOV      #-7,R2        ;;SET SHIFT COUNT
IS:      ASL      RO      ;;SHIFT RO LEFT AND
          ROL      R1      ;;ROTATE CARRY INTO R1 AND
          INC     R2        ;;CHECK FOR DONE
          BNE     IS        ;;CONTINUE SHIFT LOOP
          ADD     SLONUM,R0  ;;ADD NUMBER TO MAKE X 129
          ADC     R1        ;;PROPOGATE CARRY
          ADD     SHINUM,R1  ;;ADD NUMBER TO MAKE X 129
          ADD     #1057,R0   ;;ADD LOW CONSTANT
          ADC     R1        ;;PROPOGATE CARRY
          ADD     #47401,R1  ;;ADD HIGH CONSTANT
          MOV     RO,SLONUM  ;;SAVE RO
          MOV     R1,SHINUM  ;;SAVE R1
          MOV     (SP)+,R2   ;;POP STACK INTO R2
          MOV     (SP)+,R1   ;;POP STACK INTO R1
          MOV     (SP)+,R0   ;;POP STACK INTO R0
          RTS      PC        ;;RETURN
SHINUM: .WORD    176543
SLONUM: .WORD    123456

```

.SBTTL DOUBLE LENGTH BINARY TO DECIMAL ASCII CONVERT ROUTINE

```

*****
;THIS ROUTINE WILL CONVERT A 32-BIT BINARY NUMBER TO AN UNSIGNED
;DECIMAL (ASCII) NUMBER. THE SIGN OF THE BINARY NUMBER MUST BE
;POSITIVE.

```

```

;CALL
;      MOV      #PNTR,-(SP)  ;;POINTER TO LOW WORD OF BINARY NUMBER
;      JSR      PC,#$DB2D
;      RETURN      ;;THE FIRST ADDRESS OF ASCII
;                  ;;IS ON THE STACK

```

```

$DB2D: SAVREG      ;;SAVE REGISTERS

```

```

4490 020522 010046
4491 020523 010146
4492 020524 010246
4493 020525 013700 020622
4494 020526 013701 020620
4495 020527 012702 177771
4496 020528 006300
4497 020529 006101
4498 020530 005202
4499 020531 001374
4500 020532 063700 020622
4501 020533 005501
4502 020534 063701 020620
4503 020535 062700 001057
4504 020536 005501
4505 020537 062701 047401
4506 020538 010037 020622
4507 020539 010137 020620
4508 020540 012602
4509 020541 012601
4510 020542 012600
4511 020543 000207
4512 020544 176543
4513 020545 123456
4514 020624 104412

```

```

4538 020626 016602 000002      MOV      2(SP),R2      ;; PICKUP THE DATA POINTER
4539 020632 012700 021004      MOV      @SDECVL,R0   ;; GET ADDRESS OF "SDECVL" STRING
4540 020636 010066 000002      MOV      R0,2(SP)    ;; PUT ADDRESS OF ASCII STRING ON STACK
4541 020642 012201      MOV      (R2)+,R1    ;; PICKUP THE BINARY NUMBER
4542 020644 012202      MOV      (R2)+,R2
4543 020646 012737 000012 020722      MOV      #10,R4      ;; SET UP TO DO 10 CONVERSIONS
4544 020654 012704 020734      MOV      @STNPMR,R4   ;; ADDRESS OF TEN POWER
4545 020660 012705 020736      MOV      @STNPMR+2,R5
4546 020664 005003      15: CLR      R3      ;; CLEAR PARTIAL
4547 020666 161401      25: SUB      (R4),R1   ;; SUBTRACT TEN POWER
4548 020670 005602      SBC      R2
4549 020672 161502      SUB      (R5),R2
4550 020674 002402      SBC      R2
4551 020676 005203      BLT      35:        ;; BR IF TEN POWER TOO LARGE
4552 020700 000772      INC      R3          ;; ADD 1 TO PARTIAL
4553 020702 062401      BR       25:        ;; LOOP
4554 020704 005502      35: ADD      (R4)+,R1  ;; RESTORE SUBTRACTED VALUE
4555 020706 062402      ADC      R2
4556 020710 022525      ADD      (R4)+,R2
4557 020712 052703 000060      CMP      (R5)+,(R5)+ ;; MOVE TO NEXT TEN POWER
4558 020716 110320      BIS      #0,R3      ;; CHANGE PARTIAL TO ASCII
4559 020720 005327      MOV8     R3,(R0)+   ;; SAVE IT
4560 020722 000000      DEC      (PC)+     ;; DONE?
4561 020724 001357      45: .WORD   0
4562 020726 105020      BNE     15:        ;; BR IF NO
4563 020730 104413      CLRB    (R0)+     ;; TERMINATOR
4564 020732 000207      RESREG  PC       ;; RESTORE REGISTERS
4565 020734 145000      RTS     PC       ;; RETURN
4566 020736 035632      STNPMR: 145000    ;; 1.0E09
4567 020740 160400      25632    ;; 1.0E08
4568 020742 002765      160400    ;; 1.0E07
4569 020744 113200      2765     ;; 1.0E06
4570 020746 000230      113200    ;; 1.0E05
4571 020750 041100      230      ;; 1.0E04
4572 020752 000017      041100    ;; 1.0E03
4573 020754 103240      17       ;; 1.0E02
4574 020756 000001      103240    ;; 1.0E01
4575 020760 023420      1        ;; 1.0E00
4576 020762 000000      23420    ;; 1.0E00
4577 020764 001750      0        ;; 1.0E00
4578 020766 000000      1750     ;; 1.0E00
4579 020770 000144      0        ;; 1.0E00
4580 020772 000000      144      ;; 1.0E00
4581 020774 000012      0        ;; 1.0E00
4582 020776 000000      12       ;; 1.0E00
4583 021000 000001      0        ;; 1.0E00
4584 021002 000000      1        ;; 1.0E00
4585 021004 000014      0        ;; 1.0E00
4586
4587 SDECVL: .BLKB 12.      ;; RESERVE STORAGE FOR ASCII STRING
4588 .SBTTL TRAP DECODER
4589
4590 ;; *****
4591 ;; THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
4592 ;; AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
4593 ;; OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
4594 ;; GO TO THAT ROUTINE.

```


4594
4595
4596
4597
4598
4599
4600
4601
4602
4603
4604
4605
4606
4607
4608
4609
4610
4611
4612
4613
4614
4615
4616
4617
4618
4619
4620
4621
4622
4623
4624
4625
4626
4627
4628
4629
4630
4631
4632
4633
4634
4635
4636
4637
4638
4639
4640
4641
4642
4643
4644
4645
4646
4647
4648
4649

021020 010046
021022 016600 000002
021026 005740
021030 111000
021032 006300
021034 016000 021054
021040 000200

STRAP: MOV RO, -(SP) ;; SAVE RO
MOV 2(SP), RO ;; GET TRAP ADDRESS
TST -(RO) ;; BACKUP BY 2
MOVB (RO), RO ;; GET RIGHT BYTE OF TRAP
ASL RO ;; POSITION FOR INDEXING
MOV STRPAD(RO), RO ;; INDEX TO TABLE
RTS RO ;; GO TO ROUTINE

;; THIS IS USE TO HANDLE THE "GETPRI" MACRO

021042 011646
021044 016666 000004 000002
021052 000002

STRAP2: MOV (SP), -(SP) ;; MOVE THE PC DOWN
MOV 4(SP), 2(SP) ;; MOVE THE PSW DOWN
RTI ;; RESTORE THE PSW

.SBTTL TRAP TABLE

;; THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
;; BY THE "TRAP" INSTRUCTION.

ROUTINE

STRPAD: .WORD STRAP2
STYPE ;; CALL=TYPE TRAP+1(104401) TTY TYPEOUT ROUTINE
STYPC ;; CALL=TYPC TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
STYPOS ;; CALL=TYPOS TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
STYPON ;; CALL=TYPON TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
STYPOS ;; CALL=TYPOS TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)

SGTSMR ;; CALL=GTSMR TRAP+6(104406) GET SOFT-SMR SETTING

SCKSMR ;; CALL=CKSMR TRAP+7(104407) TEST FOR CHANGE IN SOFT-SMR
SFDCHR ;; CALL=RDCHR TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
SFDLIN ;; CALL=RDLIN TRAP+11(104411) TTY TYPEIN STRING ROUTINE
SSAVREG ;; CALL=SAVREG TRAP+12(104412) SAVE RD-RS ROUTINE
SRESREG ;; CALL=RESREG TRAP+13(104413) RESTORE RD-RS ROUTINE

;; *****

.SBTTL RP11 HANDLER

;; *****

;; STORAGE FOR RPDS & RPCS ON AN ILLEGAL INTERRUPT ERROR
; RPERRS = RPDS
; RPERRS+2 = RPCS

021104 000000
021106 000000

RPERRS: .WORD 0
.WORD 0

;; TABLE OF DRIVE ACTIVE INDICATORS (DRVACT=1 WORD)
;; THIS IS A ONE WORD QUEUE WHICH WILL CONTAIN A
;; BIT FOR EACH DRIVE WHICH IS ACTIVE WITH A COMMAND.

021110 000000

DRVACT: .WORD 0

```

4650
4651
4652
4653
4654
4655
4656 021112 000
4657 021113 000
4658 021114 000
4659 021115 000
4660 021116 000
4661 021117 000
4662 021120 000
4663 021121 000
4664
4665
4666
4667
4668
4669
4670 021122 000000
4671
4672
4673
4674
4675
4676 021124 000000
4677
4678
4679
4680
4681
4682
4683
4684 021126 000000
4685
4686
4687
4688
4689
4690 021130 000
4691
4692
4693
4694
4695
4696 021131 000
4697
4698
4699
4700
4701
4702
4703
4704 021132 000000
4705

```

```

;TABLE OF DRIVE STATUS INDICATORS (DRVSTA=8 BYTES)
;DRVSTA=0 DRIVE NONEXISTENT OR OFFLINE
;DRVSTA>0 DRIVE IS ONLINE
;DRVSTA<0 DRIVE IS UNSAFE OR AN RPO3

DRVSTA: .BYTE 0           ;DRIVE 0
        .BYTE 0           ;DRIVE 1
        .BYTE 0           ;DRIVE 2
        .BYTE 0           ;DRIVE 3
        .BYTE 0           ;DRIVE 4
        .BYTE 0           ;DRIVE 5
        .BYTE 0           ;DRIVE 6
        .BYTE 0           ;DRIVE 7

;DRIVE TYPE INDICATOR (DRVTYPE = 1 WORD)
;THIS IS A ONE WORD INDICATOR. EACH DRIVE IS ASSIGNED ONE BIT
;STARTING AT BIT00 FOR DRIVE 0. THE DRIVE'S BIT WILL BE SET IF IT
;IS AN RPO3 AND RESET IF IT IS AN RPO2.

DRVTYPE: .WORD 0

;TRANSFER WAIT FLAG (TRANSMT=1 WORD)
;THIS IS A ONE WORD QUEUE. IT WILL CONTAIN THE ADDRESS OF
;"DPB" OF THE I/O OPERATION.

TRANSMT: .WORD 0

;SEEK WAIT KEYS (SEEKWT=1 WORD)
;THIS IS A ONE WORD QUEUE THAT WILL CONTAIN A KEY FOR EACH OF
;THE DRIVES THAT ARE PERFORMING A SEARCH COMMAND FOR THE I/O
;REQUEST THAT IS AT THE TOP OF THEIR REQUEST QUEUE.
;EACH DRIVE IS ASSIGNED ONE BIT, STARTING AT BIT00 FOR DRIVE 0.

SEEKWT: .WORD 0

;RPII DRIVER ACTIVE FLAG (ACTDRV=1 BYTE)
;ACTDRV=0 DRIVER IS INACTIVE
;ACTDRV>0 DRIVER IS ACTIVE

ACTDRV: .BYTE 0

;SOFTWARE TIMER ROUTINE ACTIVE FLAG (ACTSTR=1 BYTE)
;ACTSTR=0 SOFTWARE TIMER ROUTINE IS INACTIVE
;ACTSTR>0 SOFTWARE TIMER ROUTINE IS ACTIVE

ACTSTR: .BYTE 0

;SAVE REGISTERS FLAG (SAVEFG =1 WORD)
;SAVEFG<0 SAVE THE RPIIE REGISTERS WHEN THE
;OPERATION IS COMPLETED AS PER (DPB+14).
;SAVEFG=0 SAVE THE RPIIE REGISTERS, AS PER
;(DPB+14), AFTER AN ERROR.

SAVEFG: .WORD 0

```

```

4706 ;ORDER REQUEST QUEUES/LISTS
4707
4708 021134 000000 000000 000000 QREGS: .WORD 0,0,0,0,0,0,0,0,0 ;STORE REGISTERS ORDER QUEUE
4709 021142 000000 000000 000000
4710 021150 000000 000000 000000
4711 021156 000000 000000 000000 QSEEK: .WORD 0,0,0,0,0,0,0,0,0 ;SEEK/HOME SEEK ORDER QUEUE
4712 021164 000000 000000 000000
4713 021172 000000 000000 000000
4714 021200 000000 000000 000000 QTRANS: .WORD 0,0,0,0,0,0,0,0,0 ;TRANSFER ORDER QUEUE
4715 021206 000000 000000 000000
4716 021214 000000 000000 000000
4717 021222 000000 000000 000000 QDONE: .WORD 0,0,0,0,0,0,0,0,0 ;ON CYLINDER TRANSFER QUEUE
4718 021230 000000 000000 000000
4719 021236 000000 000000 000000
4720 021244 000000 000000 000000 QWAIT: .WORD 0,0,0,0,0,0,0,0 ;TRANSFER SEEK DONE LIST
4721 021252 000000 000000 000000
4722 021260 000000 000000 000000

```

```

4723 ;TIMEOUT TABLE (TIMER=8 WORDS)
4724 ;THIS TABLE CONTAINS THE TIME ALLOWED FOR AN OPERATION
4725
4726
4727

```

```

4728 021264 177777 TIMER: .WORD -1 ;DRIVE 0
4729 021266 177777 .WORD -1 ;DRIVE 1
4730 021270 177777 .WORD -1 ;DRIVE 2
4731 021272 177777 .WORD -1 ;DRIVE 3
4732 021274 177777 .WORD -1 ;DRIVE 4
4733 021276 177777 .WORD -1 ;DRIVE 5
4734 021300 177777 .WORD -1 ;DRIVE 6
4735 021302 177777 .WORD -1 ;DRIVE 7
4736

```

```

4737 ;ATTENTION BITS TABLE (ATABIT=8 BYTES)
4738 ;THIS TABLE CONTAINS THE CORRESPONDING BIT TO EACH DRIVES
4739 ;ATTENTION BIT
4740

```

```

4741 021304 001 ATABIT: .BYTE 1 ;DRIVE 0
4742 021305 002 .BYTE 2 ;DRIVE 1
4743 021306 004 .BYTE 4 ;DRIVE 2
4744 021307 010 .BYTE 10 ;DRIVE 3
4745 021310 020 .BYTE 20 ;DRIVE 4
4746 021311 040 .BYTE 40 ;DRIVE 5
4747 021312 100 .BYTE 100 ;DRIVE 6
4748 021313 200 .BYTE 200 ;DRIVE 7
4749

```

```

4750 ;RP11E DRIVER INITIALIZATION CODE
4751 ;THIS ROUTINE WILL DETERMINE WHICH RPO2 OR RPO3 DRIVES ARE
4752 ;AVAILABLE FOR TESTING AND SET THE 'DRVSTA' INDICATOR
4753 ;TO THE PROPER STATE FOR EACH DRIVE.
4754 ;NOTE: THIS ROUTINE CALLS DRVINT
4755

```

```

4756 ;CALL
4757
4758 JSR PC,RPINIT
4759 RETURN
4760

```

```

4761 021314 104412 RPINIT: SAVREG ;SAVE R0-R5

```

```

4762 021316 013746 177776      MOV      2#PS, -(SP)      ;SAVE THE PRESENT PROCESSOR STATUS
4763 021322 013737 001222 177776  MOV      RPPR10, 2#PS    ;CHANGE THE PRIORITY
4764 021330 012701 021104      MOV      #RPERR5, R1     ;FIRST ADDRESS TO BE CLEARED
4765 021334 012702 021262      MOV      #TIMER-2, R2    ;LAST ADDRESS TO BE CLEARED
4766 021340 005021      1S:    CLR      (R1)+           ;CLEAR
4767 021342 020102      CMP      R1, R2          ;ARE WE DONE?
4768 021344 101775      BLOS     1S              ;BRANCH IF NO
4769 021346 012702 021302      MOV      #ATABIT-2, R2   ;LAST ADDRESS
4770 021352 012721 177777      2S:    MOV      #-1, (R1)+     ;INITIALIZE
4771 021356 020102      CMP      R1, R2          ;DONE?
4772 021360 101774      BLOS     2S              ;LOOP IF NO
4773 021362 013703 001220      MOV      RPVEC, R3       ;SETUP THE RP11 VECTOR
4774 021366 012723 022502      MOV      #ISR, (R3)+     ;
4775 021372 013713 001222      MOV      RPPR10, (R3)    ;
4776 021376 013704 001216      MOV      RPADR, R4       ;RP11 ADDRESS
4777 021402 005001      CLR      R1              ;START WITH DRIVE 0
4778 021404 004737 021444      3S:    JSR      PC, DRVINT     ;INIT THE DRIVE
4779 021410 005201      4S:    INC      R1           ;GO TO NEXT DRIVE
4780 021412 042701 177770      BIC      #1C7, R1        ;MASK OUT UNUSED BITS
4781 021416 001372      BNE      3S              ;BR IF MORE DRIVES TO GO
4782 021420 012701 000007      MOV      #7, R1          ;START WITH DRIVE 7
4783 021424 005037 177776      CLR      2#PS           ;CLEAR THE PROCESSOR STATUS
4784 021430 005301      5S:    DEC      R1           ;GO TO THE NEXT DRIVE
4785 021432 100376      BPL      5S              ;CHECK NEXT DRIVE
4786 021434 012637 177776      MOV      (SP)+, 2#PS     ;RESTORE THE PROCESSOR STATUS
4787 021440 104413      RESREG     ;RESTORE R0-R5
4788 021442 000207      RTS      PC              ;BYE-BYE
4789
4790
4791      ;DRIVE INITIALIZATION ROUTINE
4792      ;THIS ROUTINE DETERMINES OF A DRIVE IS PRESENT AND IF IT IS
4793      ;AN RPD2 OR RPD3. 'DRVSTA' IS SET TO REFLECT THE DRIVE'S
4794      ;STATUS AND THE DRIVE TYPE INDICATOR BIT IS SET IN 'DRVTYP'.
4795      ;CALL
4796      MOV      #DRVNUM, R1      ;DRIVE NUMBER TO R1
4797      MOV      RPADR, R4       ;UNIBUS ADDRESS OF RP11 (RPDS)
4798      JSR      PC, DRVINT     ;CALLED BY A JSR
4799      RETURN                    ;NORMAL RETURN
4800      DRVINT: SAVREG           ;SAVE R0-R5
4801      MOV      #-1, DRVSTA(R1) ;START DRIVE STATUS AS UNSAFE
4802      MOV      R1, RPCS+1(R4)  ;SELECT A DRIVE
4803      BIT      #SUFU, RPDS(R4) ;DRIVE UNSAFE ?
4804      BNE      3S              ;BR IF UNSAFE
4805      BIT      #SUOL, RPDS(R4) ;DRIVE ONLINE ?
4806      BEQ      1S              ;BR IF NOT
4807      BIT      #SUSI, RPDS(R4) ;SEEK INCOMPLETE SET ?
4808      BNE      2S              ;BR IF SET
4809      BIT      #SURDY, RPDS(R4) ;DRIVE READY ?
4810      BNE      2S              ;BR IF READY
4811      CLRB     DRVSTA(R1)     ;SET DRIVE OFFLINE OR NONEXISTENT
4812      BR      5S              ;EXIT
4813      MOV      #1, DRVSTA(R1)  ;SET DRIVE AVAILABLE
4814      BIT      #SURP03, RPDS(R4) ;DRIVE AN RPD3 ?
4815      BNE      4S              ;BR IF IT IS
4816      BICB     ATABIT(R1), DRVTYP ;SET RPD2 INDICATOR
4817      BR      5S              ;EXIT

```

JOB

MD-11-DZRP1-B, RPI1E MULTI-DRIVE EXERCISER PROGRAM
DZRP1B.CMB RPI1 HANDLER

MACY11 27(732) 01-NOV-76 15:32 PAGE 101

```

4818 021554 156137 021304 1122 4S:  BISB  ATABIT(R1),DRVTYP  ;SET RPO3 INDICATOR
4819 021562 104413          5S:  RESREG                ;RESTORE RO-R5
4820 021564 000207          RTS    PC                ;RETURN
4821
4822          ;REQUEST PRE-PROCESSOR-HANDLES SUBSYSTEM REQUEST
4823          ;CALL
4824          ;
4825          ;
4826          JSR    RO,2#RPI1          ;CALL THE RPI1E DRIVER
4827          PNTADR                ;ADDRESS OF POINTER OF DRIVE'S PARAMETER BLOCK
4828          RETURN1                ;RETURN HERE IF QUEUE IS FULL
4829          RETURN2                ;RETURN HERE IF REQUEST IS IN QUEUE OR THERE
4830          ;IS AN ERROR CONDITION
4831
4832 021566 013746 177776          RP11:  MOV    PSW, -(SP)          ;SAVE THE CALLING STATUS
4833 021572 013737 001222 177776  MOV    RPPRIO, PSW          ;DON'T ALLOW ANY RPI1E INTERRUPTS
4834 021600 112737 000001 021130  MOVB   #1, ACTDRV          ;SET "ACTIVE DRIVER" FLAG
4835 021606 010246          MOV    R2, -(SP)          ;SAVE R2
4836 021610 012002          MOV    (RO)+, R2          ;PICKUP THE DRIVE PARAMETER BLOCK POINTER
4837 021612 005062 000016          CLR   16(R2)            ;CLEAR THE STATUS/ERROR INDICATOR
4838 021616 004037 024060          JSR   RO, LODQUE          ;PUT THIS REQUEST IN QUEUE
4839 021622 000403          BR    1$                ;QUEUE IS FULL
4840 021624 004737 021646          JSR   PC, CI            ;INITIATE A COMMAND
4841 021630 005720          TST   (RO)+
4842 021632 012602          1$:  MOV    (SP)+, R2          ;RESTORE R2
4843 021634 105037 021130          CLRB  ACTDRV            ;CLEAR "ACTIVE DRIVER" FLAG
4844 021640 012637 177776          MOV   (SP)+, 2#PS        ;RETURN "PS" TO USER LEVEL
4845 021644 000200          RTS    RO                ;RETURN TO CALLER
4846
4847          ;COMMAND INITIATION ROUTINE
4848
4849 021646 104412          CI:  SAVREG                ;SAVE RO-R5
4850 021650 013704 001216          MOV   RPADR, R4          ;RPI1 ADDRESS
4851 021654 005737 021124          TST   TRNSMT            ;TRANSFER IN PROGRESS ?
4852 021660 001035          BNE   5$                ;BR IF ONE IS
4853 021662 005737 021134          TST   QREGS             ;PENDING STORE REGISTERS OP ?
4854 021666 001402          BEQ   1$                ;BR IF NOT
4855 021670 004737 021760          JSR   PC, CI1           ;STORE THE REGISTERS
4856 021674 005737 021156          1$:  TST   QSEEK           ;PENDING SEEKS OR HOME SEEKS ?
4857 021700 001402          BEQ   2$                ;BR IF NONE
4858 021702 004737 022024          JSR   PC, CI2           ;START PENDING SEEKS
4859 021706 005737 021200          2$:  TST   QTRANS          ;PENDING TRANSFER ORDERS ?
4860 021712 001402          BEQ   3$                ;BR IF NONE
4861 021714 004737 022142          JSR   PC, CI3           ;START THE TRANSFER ORDERS
4862 021720 005737 021222          3$:  TST   QDONE           ;ON CYLINDER TRANSFER REQUESTS ?
4863 021724 001405          BEQ   4$                ;BR IF DONE
4864 021726 004737 022264          JSR   PC, CI4           ;START ORDER AT HEAD OF QUEUE
4865 021732 005737 021124          TST   TRNSMT            ;TRANSFER ORDER STARTED ?
4866 021736 001006          BNE   5$                ;BR IF ONE WAS
4867 021740 105737 021110          4$:  TSTB  DRVACT          ;ANY ACTIVE DRIVES ?
4868 021744 001403          BEQ   5$                ;BR IF NONE
4869 021746 112764 000040 000005  MOVB   #40, RPCS+1(R4)    ;SET ATTENTION INTERRUPT ENABLE
4870 021754 104413          5$:  RESREG                ;RESTORE RO-R5
4871 021756 000207          RTS    PC                ;RETURN
4872
4873          ;STORE THE REGISTERS COMMAND

```

```

4874
4875 021760 117764 177150 000005 CI1:  MOVB  QGREGS,RPCS+1(R4)  ;SELECT THE DRIVE
4876 021766 013702 021134          MOV   QREGS,R2          ;DPB ADDRESS
4877 021772 004737 024000          JSR   PC,SVRP11        ;STORE THE REGISTERS
4878 021776 012762 000200 000016  MOV   #BIT07,16(R2)    ;SET 'DONE'
4879 022004 012702 021134          MOV   #QREGS,R2        ;QUEUE ADDRESS
4880 022010 004737 024256          JSR   PC,POPQUE        ;'POP' THE QUEUE
4881 022014 005737 021134          TST   QREGS            ;ANY MORE REQUESTS IN QUEUE ?
4882 022020 001357          BNE   CI1              ;BR IF ANY ARE
4883 022022 000207          RTS                    ;RETURN
4884
4885          ;START THE SEEK OR HOME SEEK COMMAND
4886
4887 022024 117764 177126 000005 CI2:  MOVB  QOSEEK,RPCS+1(R4)  ;SELECT THE DRIVE
4888 022032 013702 021156          MOV   QSEEK,R2         ;DPB ADDRESS
4889 022036 005001          CLR   R1               ;CLEAR R1
4890 022040 117701 177112          MOVB  QOSEEK,R1        ;DRIVE ADDRESS
4891 022044 004037 022436          JSR   RO,CIR           ;SEE IF DRIVE IS READY
4892 022050 000424          BR    IS               ;DRIVE NOT READY OR IS UNSAFE
4893 022052 016264 000010 000012  MOV   10(R2),RPCA(R4)  ;DESIRED CYLINDER ADDRESS
4894 022060 016264 000012 000014  MOV   12(R2),RPDA(R4)  ;SECTOR/TRACK ADDRESS
4895 022066 116264 000002 000004  MOVB  2(R2),RPCS(R4)   ;START THE COMMAND
4896 022074 156137 021304 021110  BISB  ATABIT(R1),DRVACT ;SET THE DRIVE'S ACTIVE BIT
4897 022102 006301          ASL   R1               ;ADDRESS WORDS
4898 022104 013761 001260 021264  MOV   TIMEOUT,TIMER(R1) ;START TIMER FOR DRIVE
4899 022112 013761 021156 021244  MOV   QSEEK,QWAIT(R1)  ;PUT DPB ADDRESS IN 'WAIT' QUEUE
4900 022120 006201          ASR   R1               ;RESTORE DRIVE ADDRESS
4901 022122 012701 021156          IS:   MOV   #QSEEK,R1   ;QUEUE ADDRESS
4902 022126 004737 024256          JSR   PC,POPQUE        ;'POP' THE SEEK QUEUE
4903 022132 005737 021156          TST   QSEEK            ;MORE REQUESTS ?
4904 022136 001332          BNE   CI2              ;BR IF MORE
4905 022140 000207          RTS                    ;RETURN
4906
4907          ;DO AN EXPLICIT SEEK IF DRIVE IS NOT ON CYLINDER
4908
4909 022142 117764 177032 000005 CI3:  MOVB  QOTRANS,RPCS+1(R4) ;SELECT THE DRIVE
4910 022150 005001          CLR   R1               ;CLEAR R1
4911 022152 117701 177022          MOVB  QOTRANS,R1       ;DRIVE ADDRESS
4912 022156 013702 021200          MOV   QTRANS,R2        ;DPB ADDRESS
4913 022162 004037 022436          JSR   RO,CIR           ;SEE IF DRIVE READY
4914 022166 000426          BR    IS               ;DRIVE NOT READY
4915 022170 016264 000010 000012  MOV   10(R2),RPCA(R4)  ;DESIRED CYLINDER
4916 022176 016264 000012 000014  MOV   12(R2),RPDA(R4)  ;SECTOR/TRACK ADDRESS
4917 022204 112764 000011 000004  MOVB  #SEEK,RPCS(R4)   ;SEEK COMMAND
4918 022212 156137 021304 021110  BISB  ATABIT(R1),DRVACT ;SET DRIVE ACTIVE
4919 022220 156137 021304 021126  BISB  ATABIT(R1),SEEKWT ;SET SEEK WAIT BIT
4920 022226 006301          ASL   R1               ;SETUP TO ADDRESS WORDS
4921 022230 013761 001260 021264  MOV   TIMEOUT,TIMER(R1) ;START TIMER FOR DRIVE
4922 022236 013761 021200 021244  MOV   QTRANS,QWAIT(R1) ;'WAIT' TABLE ENTRY
4923 022244 012701 021200          IS:   MOV   #QTRANS,R1  ;TRANSFER QUEUE ADDRESS
4924 022250 004737 024256          JSR   PC,POPQUE        ;'POP' THE TRANSFER QUEUE
4925 022254 005737 021200          TST   QTRANS           ;MORE DRIVES IN QUEUE ?
4926 022260 001330          BNE   CI3              ;BR IF MORE DRIVES
4927 022262 000207          RTS                    ;RETURN
4928
4929          ;START THE PENDING ON CYLINDER TRANSFER REQUEST

```

```

4930
4931 022264 117764 176732 000005 CI4:  MOVB  3000E,RPCS+1(R4)  ;SELECT THE DRIVE
4932 022272 117701 176724          MOVB  3000E,R1          ;DRIVE ADDRESS
4933 022276 013702 021222          MOV   3000E,R2          ;DPB ADDRESS
4934 022302 004037 022436          JSR   RD,CIR           ;SEE IF DRIVE IS READY
4935 022306 000440          BR    1$              ;DRIVE NOT READY
4936 022310 016264 000004 000006          MOV   4(R2),RPWC(R4)   ;WORD COUNT
4937 022316 016264 000006 000010          MOV   6(R2),RPBA(R4)   ;BUFFER ADDRESS
4938 022324 016264 000010 000012          MOV   10(R2),RPCA(R4)  ;CYLINDER ADDRESS
4939 022332 016264 000012 000014          MOV   12(R2),RPDA(R4)  ;SECTOR/TRACK ADDRESS
4940 022340 016246 000002          MOV   2(R2),-(SP)      ;COMMAND CODE, MODE & HDR BITS
4941 022344 151266 000001          BISB  (R2),1(SP)       ;DRIVE ADDRESS
4942 022350 156216 000001          BISB  1(R2),(SP)      ;'MEX' BITS
4943 022354 052716 000100          BIS   8IDE,(SP)       ;INTERRUPT ON DONE BIT
4944 022360 012664 000004          MOV   (SP)+,RPCS(R4)   ;START THE COMMAND
4945 022364 156137 021304 021110          BISB  ATABIT(R1),DRVACT ;DRIVE ACTIVE BIT
4946 022372 006301          ASL   R1              ;ADDRESS WORDS
4947 022374 013761 001260 021264          MOV   TIMEOUT,TIMER(R1) ;START TIMER FOR DRIVE
4948 022402 006201          ASR   R1              ;RESTORE R1
4949 022404 010237 021124          MOV   R2,TRANSWT      ;DPB ADDRESS
4950 022410 012701 021222          1$:  MOV   3000E,R1      ;QUEUE ADDRESS
4951 022414 004737 024256          JSR   PC,POPQUE       ;'POP' THE QUEUE
4952 022420 005737 021124          TST   TRANSWT         ;TRANSFER ORDER RUNNING ?
4953 022424 001003          BNE   2$              ;BR IF ONE IS
4954 022426 005737 021222          TST   3000E           ;MORE ORDERS WAITING ?
4955 022432 001314          BNE   CI4             ;BR IF MORE
4956 022434 000207          2$:  RTS    PC         ;RETURN
4957
4958          ;SEE IF DRIVE IS ONLINE
4959
4960 022436 004737 021444          CIR:  JSR   PC,DRVINT    ;CHECK DRIVE'S STATUS
4961 022442 105761 021112          TSTB  DRVSTA(R1)      ;SEE WHAT DRIVE'S STATUS IS
4962 022446 003013          BGT   3$              ;BR IF DRIVE ONLINE
4963 022450 002404          BLT   1$              ;BR IF DRIVE IS UNSAFE
4964 022452 012762 140000 000016          MOV   8BIT15:BIT14,16(R2) ;SET OFFLINE INDICATOR
4965 022460 000403          BR    2$              ;GO STORE REGISTERS
4966 022462 012762 110000 000016          1$:  MOV   8BIT15:BIT12,16(R2) ;SET UNSAFE INDICATOR
4967 022470 004737 024000          2$:  JSR   PC,SVRP11    ;STORE THE REGISTERS
4968 022474 000401          BR    4$              ;EXIT
4969 022476 005720          3$:  TST   (R0)+        ;STEP AROUND ERROR RETURN
4970 022500 000200          4$:  RTS    R0         ;RETURN
4971
4972          ;INTERRUPT SERVICE ROUTINE
4973
4974 022502 112737 000001 021130          ISR:  MOVB  81,ACTDRV   ;SET "ACTIVE DRIVER" FLAG
4975 022510 104412          SAVREG ;SAVE R0-R5
4976 022512 013704 001216          MOV   RPADR,R4        ;ADDRESS OF RP11
4977 022516 005737 021124          TST   TRANSWT         ;TRANSFER OPERATION IN PROGRESS ?
4978 022522 001403          BEQ   1$              ;BR IF NOT
4979 022524 004737 022552          JSR   PC,TD           ;CALL TRANSFER DONE
4980 022530 000402          BR    2$              ;EXIT
4981 022532 004737 023034          1$:  JSR   PC,SC        ;CALL SPECIAL CONDITIONS
4982 022536 004737 021646          2$:  JSR   PC,CI        ;GO TO THE COMMAND INITIATION ROUTINE
4983 022542 104413          RESREG ;RESTORE R0-R5
4984 022544 105037 021130          CLRB  ACTDRV         ;CLEAR "ACTIVE DRIVER" FLAG
4985 022550 000002          RTI                    ;RETURN

```

```

4986
4987
4988
4989 022552 005001 TD: CLR R1 ;CLEAR DRIVE NUMBER STORAGE
4990 022554 117701 176344 MOV B #TRANSW,R1 ;GET DRIVE NUMBER
4991 022560 146137 021304 021110 BICB ATABIT(R1),DRVACT ;CLEAR DRIVE ACTIVE BIT
4992 022566 006301 ASL R1
4993 022570 012761 177777 021264 MOV #8-1,TIMER(R1) ;STOP TIMER
4994 022576 006201 ASR R1
4995 022600 013702 021124 MOV TRANSW,R2 ;GET "DPB" ADDRESS FROM THE
4996 022604 005037 021124 CLR TRANSW ;TRANSFER WAIT QUEUE--CLEAR QUEUE
4997 022610 012762 000200 000016 MOV #BIT07,16(R2) ;SET DONE
4998 022616 110164 000005 MOV B R1,RPCS+1(R4) ;SELECT THE DRIVE
4999 022622 116164 021304 000000 MOV B ATABIT(R1),RPDS(R4) ;CLEAR DRIVE'S ATTENTION BIT
5000 022630 005764 000004 TST RPCS(R4) ;ERROR SET ?
5001 022634 100413 BMI 2$ ;BR IF YES
5002 022636 005737 021132 TST SAVEFG ;SAVE THE RP11E REGISTERS?
5003 022642 100002 BPL 1$ ;BRANCH IF NO
5004 022644 004737 024000 JSR PC,SVRP11 ;YES--SAVE THE REGISTERS
5005 022650 042764 000100 000004 1$: BIC #IDE,RPCS(R4) ;CLEAR 'INTERRUPT ON DONE' BIT
5006 022656 004737 022742 JSR PC,WC ;SEE IF WRITE CHECK TO BE PUT IN QUEUE
5007 022662 000505 BR SC0 ;SPECIAL CONDITIONS ENTRY
5008 022664 004737 024000 2$: JSR PC,SVRP11 ;SAVE THE REGISTERS
5009 022670 012764 000001 000004 MOV #CLEAR,RPCS(R4) ;CLEAR THE CONTROLLER
5010 022676 004737 021444 JSR PC,DRVINT ;CHECK THE DRIVE'S STATUS
5011 022702 105761 021112 TSTB DRVSTA(R1) ;DRIVE STILL ONLINE ?
5012 022706 003011 BGT 4$ ;BR IF ONLINE
5013 022710 100404 BMI 3$ ;BR IF UNSAFE
5014 022712 012762 140000 000016 MOV #BIT15:BIT!4,16(R2) ;SET DRIVE OFFLINE INDICATOR
5015 022720 000466 BR SC0 ;CHECK FOR OTHER DRIVES
5016 022722 012762 110000 000016 3$: MOV #BIT15:BIT12,16(R2) ;SET DRIVE UNSAFE INDICATOR
5017 022730 000462 BR SC0 ;CHECK FOR OTHER DRIVES
5018 022732 052762 100100 000016 4$: BIS #BIT15:BIT06,16(R2) ;SET DATA ERROR FLAG
5019 022740 000456 BR SC0 ;SPECIAL CONDITIONS ENTRY
5020
5021 ;FORCED WRITE CHECK ROUTINE
5022
5023 022742 005737 001322 WC: TST AUTOCK ;AUTOMATIC WRITE CHECKS ?
5024 022746 001430 BEQ 1$ ;BR IF NOT
5025 022750 132762 000004 000002 BITB #BIT02,$COMND(R2) ;WRITE COMMAND ?
5026 022756 001024 BNE 1$ ;BR IF NOT
5027 022760 010146 MOV R1,-(SP) ;SAVE R1
5028 022762 012701 021200 MOV #QTRANS,R1 ;TRANSFER QUEUE ADDRESS
5029 022766 004037 024226 JSR RD,DRVQUE ;PUT THE OPERATION IN THE QUEUE
5030 022772 000416 BR 1$ ;QUEUE IS FULL
5031 022774 005062 000016 CLR 16(R2) ;CLEAR 'DONE' BIT IN DPB
5032 023000 116262 000002 000024 MOV B $COMND(R2),$PREV0(R2) ;SAVE WRITE OPERATION CODE
5033 023006 016262 000010 000032 MOV $CYL(R2),$PREVA+2(R2) ;SAVE CYLINDER
5034 023014 016262 000012 000030 MOV $SEC(R2),$PREVA(R2) ;SAVE SECTOR AND TRACK ADDRESSES
5035 023022 112762 000007 000002 MOV B #WATCHK,$COMND(R2) ;CHANGE DRIVER CODE TO WRITE CHECK
5036 023030 012601 1$: MOV (SP)+,R1 ;RESTORE R1
5037 023032 000207 RTS PC ;EXIT
5038
5039 ;SPECIAL CONDITION ROUTINE
5040
5041 023034 105764 000000 SC: TSTB RPDS(R4) ;ATTENTION BITS SET ?

```


5042	023040	001016			BNE	SC0	:BR IF SOME SET
5043	023042	016437	000000	021104	MOV	RPDS(R4),RPERRS	:STORE DRIVE STATUS REGISTER
5044	023050	016437	000004	021106	MOV	RPCS(R4),RPERRS+2	:STORE THE CONTROL REGISTER
5045	023056	104003			ERROR	3	:ILLEGAL INTERRUPT
5046	023060	005737	021110		TST	DRVACT	:ANY DRIVES ACTIVE ?
5047	023064	001403			BEQ	IS	:BR IF NOT
5048	023066	112764	000040	000005	MOVB	#40,RPCS+1(R4)	:SET 'AIE'
5049	023074	000207			RTS	PC	:RETURN

IS:

```

5050 023076 005001          SCO:  CLR      R1          ;CLEAR DRIVE NUMBER STORAGE
5051 023100 012703 000001    MOV      #1,R3        ;START WITH DRIVE 0'S BIT
5052 023104 030337 021110    SC1:  BIT      R3,DRVACT ;IS THIS DRIVE ACTIVE ?
5053 023110 001004          BNE     SC3          ;BR IF IT IS
5054 023112 005201          SC2:  INC      R1          ;GO TO NEXT DRIVE
5055 023114 106303          ASLB   R3          ;SHIFT DRIVE'S BIT
5056 023116 001372          BNE     SC1          ;BR IF MORE DRIVES TO CHECK
5057 023120 000207          RTS     PC          ;RETURN
5058 023122 006301          SC3:  ASL      R1          ;SETUP TO ADDRESS WORDS
5059 023124 016102 021244    MOV     @WAIT(R1),R2 ;GET DRIVE'S DPB ADDRESS
5060 023130 006201          ASR      R1          ;RESTORE ADDRESS
5061 023132 110164 000005    MOV     R1,RPCS+1(R4) ;SELECT DRIVE
5062 023136 032764 002000 000000 BIT     #SUSU,RPDS(R4) ;DRIVE STILL SEEKING ?
5063 023144 001362          BNE     SC2          ;BR IF IT IS
5064 023146 006301          ASL      R1          ;ADDRESS WORDS
5065 023150 005061 021244    CLR     @WAIT(R1)    ;CLEAR THE WAIT QUEUE ENTRY
5066 023154 012761 177777 021264    MOV     #-1,TIMER(R1) ;STOP THE TIMER
5067 023162 006201          ASR      R1          ;RESTORE DRIVE ADDRESS
5068 023164 146137 021304 021110 BICB   ATABIT(R1),DRVACT ;CLEAR THE DRIVE'S ACTIVE BIT
5069 023172 116164 021304 000000 MOV     ATABIT(R1),RPDS(R4) ;CLEAR DRIVE'S ATTENTION BIT
5070 023200 032764 001000 000000 BIT     #SUFU,RPDS(R4) ;DRIVE UNSAFE ?
5071 023206 001027          BNE     1$          ;BR IF IT IS
5072 023210 032764 040000 000000 BIT     #SUOL,RPDS(R4) ;IS DRIVE STILL ONLINE ?
5073 023216 001432          BEQ     2$          ;BR IF NOT
5074 023220 032764 140000 000004 BIT     #ERR!HE,RPCS(R4) ;ANY ERRORS SET ?
5075 023226 001034          BNE     3$          ;BR IF SET
5076 023230 136137 021304 021126 BITB   ATABIT(R1),SEEKMT ;TRANSFER SEEK ?
5077 023236 001434          BEQ     4$          ;BR IF NOT
5078 023240 010146          MOV     R1,-(SP)    ;SAVE R1
5079 023242 012701 021222    MOV     @DONE,R1    ;DONE QUEUE ADDRESS
5080 023246 004037 024226    JSR     R0,DRVQUE   ;PUT DRIVE'S DPB ADDRESS IN DONE QUEUE
5081 023252 000240          NOP                    ;RETURN IF QUEUE FULL (SHOULDN'T HAPPEN)
5082 023254 012601          MOV     (SP)+,R1    ;RESTORE R1
5083 023256 146137 021304 021126 BICB   ATABIT(R1),SEEKMT ;CLEAR WAIT BIT
5084 023264 000712          BR      SC2          ;GET ANOTHER DRIVE
5085 023266 052762 110000 000016 1$:  BIS     #BIT15!BIT12,16(R2) ;SET DRIVE UNSAFE STATUS
5086 023274 112761 177777 021112 MOV     #-1,DRVSTA(R1) ;SET DRIVE UNSAFE
5087 023302 000420          BR      5$          ;STORE REGISTERS
5088 023304 052762 140000 000016 2$:  BIS     #BIT15!BIT14,16(R2) ;SET DRIVE OFFLINE STATUS
5089 023312 105061 021112    CLAB   DRVSTA(R1)   ;SET DRIVE OFFLINE
5090 023316 000412          BR      5$          ;STORE REGISTERS
5091 023320 052762 100240 000016 3$:  BIS     #BIT15!BIT7!BITS,16(R2) ;SET ERROR DURING SEEK STATUS
5092 023326 000406          BR      5$          ;STORE REGISTERS
5093 023330 052762 000200 000016 4$:  BIS     #BIT07,16(R2) ;NORMAL END OF ORDER STATUS
5094 023336 005737 021132    TST    SAVEFG       ;SAVE REGISTERS ?
5095 023342 001663          BEQ     SC2          ;BR IF NOT
5096 023344 146137 021304 021126 5$:  BICB   ATABIT(R1),SEEKMT ;CLEAR DRIVE'S WAIT BIT
5097 023352 004737 024000    JSR     PC,SVRP11   ;STORE THE RPI1E REGISTERS
5098 023356 000655          BR      SC2          ;GET ANOTHER DRIVE
5099
5100          ;TIMER ROUTINE
5101          ;CALL
5102          ;
5103          ;
5104          ;
5105 023360 005737 021130    RPTMR: TST    ACTDRV ;CHECK "ACTDRV & ACTSTR"

```

```

S106 023364 001040          BNE      55          ; IF NON-ZERO, EXIT
S107 023366 112737 000001 021131  MOVB    #1,ACTSTR  ; SET "ACTSTR"
S108 023374 104412          SAVREG          ; SAVE R0-R5
S109 023376 005001          CLR      R1      ; START WITH DRIVE 0
S110 023400 005003          CLR      R3
S111 023402 005763 021264      15:    TST     TIMER(R3)  ; IS THE TIMER RUNNING?
S112 023406 002407          BLT     25      ; BRANCH IF NO
S113 023410 166663 000002 021264  SUB     2(SP),TIMER(R3) ; COUNT THE INTERVAL
S114 023416 003003          BGT     25      ; BR IF NO SOFTWARE TIMEOUT
S115 023420 004737 023472      JSR     PC,STO    ; CALL SOFTWARE TIMEOUT ROUTINE
S116 023424 000406          BR      35      ; GO TO THE EXIT
S117 023426 005201          25:    INC     R1      ; MOVE TO NEXT DRIVE
S118 023430 005723          TST     (R3)+
S119 023432 022701 000010      CMP     #8.,R1    ; OUT OF DRIVES?
S120 023436 003361          BGT     15      ; BRANCH IF NO
S121 023440 000407          BR      45      ; BYPASS 'SC' AND 'CI' CHECKS
S122 023442 005737 021124      35:    TST     TRANSW  ; ACTIVE TRANSFER COMMAND ?
S123 023446 001004          BNE     45      ; BR IF YES
S124 023450 004737 023076      JSR     PC,SCO    ; LOOK FOR DRIVES FINISHED SEEKING
S125 023454 004737 021646      JSR     PC,CI     ; START ANY OUTSTANDING COMMANDS
S126 023460 104413          45:    RESREG          ; RESTORE R0-R5
S127 023462 105037 021131      CLRB   ACTSTR    ; ZERO ACTIVE SOFTWARE TIMEOUT ROUTINE FLAG
S128 023466 012616          55:    MOV     (SP)+,(SP) ; ADJUST THE STACK
S129 023470 000207          RTS     PC      ; RETURN

; SOFTWARE TIMEOUT ROUTINE
CALL:  STO
      MOV     #DRVNUM,R1 ; DRIVE NUMBER
      JSR     PC,STO     ; CALL--DRVACT MUST BE NONZERO
      RETURN

STO:  MOV     RPADR,R4   ; GET ADDRESS OF RP11
      MOVB   R1,RPCS+1(R4) ; SELECT THE DRIVE
      ASL    R1         ; WORD INDEX
      MOV    #8-1,TIMER(R1) ; STOP TIMER
      ASR    R1         ; RESTORE R1
      TST    TRANSW    ; DATA TRANSFER IN PROGRESS ?
      BEQ    STO1      ; BR IF NOT
      CMPB  R1,TRANSW  ; IN PROGRESS FOR THIS DRIVE ?
      BNE   STO5      ; BR IF NOT
      TSTB  RPCS(R4)   ; CONTROLLER READY ?
      BMI   STO5      ; BR IF READY
      BICB  ATABIT(R1),DRVACT ; CLEAR DRIVE ACTIVE BIT
      MOV   TRANSW,R2  ; PUT DPB ADDRESS IN R2
      JSR  PC,SVRP11   ; STORE THE REGISTERS
      JSR  PC,DRVINT   ; CHECK ON THE DRIVE'S STATUS
      MOV  #BIT15:BIT08,16(R2) ; SET TIMEOUT & 'RESET' INDICATOR
      TSTB  DRVSTA(R1) ; SEE IF DRIVE STILL ONLINE
      BGT  25         ; BR IF DRIVE STILL ONLINE
      BLT  15         ; BR IF DRIVE UNSAFE
      BIS  #BIT14,16(R2) ; SET OFFLINE INDICATOR
      BR   25         ; GO INIT THE DRIVE
      BIS  #BIT12,16(R2) ; SET UNSAFE INDICATOR
      15:  MOVB  #CLEAR,RPCS(R4) ; CLEAR THE CONTROLLER
      25:  MOVB  #CLEAR,RPCS(R4) ; CLEAR THE CONTROLLER AGAIN

```

```

5162 023630 005037 021124 CLR TRANSWT ;CLEAR THE TRANSFER QUEUE
5163 023634 000460 BR ST05 ;EXIT
5164 023636 006301 ST01: ASL R1 ;ADDRESS WORDS
5165 023640 016102 021244 MOV QWAIT(R1),R2 ;GET DPB ADDRESS
5166 023644 006201 ASR R1 ;RESTORE R1
5167 023646 032764 001000 000000 BIT #SUFU,RPDS(R4) ;DRIVE UNSAFE ?
5168 023654 001020 BNE ST02 ;BR IF UNSAFE
5169 023656 032764 004000 000000 BIT #SUSI,RPDS(R4) ;SEEK INCOMPLETE ?
5170 023664 001044 BNE ST05 ;BR IF SET
5171 023666 032764 040000 000000 BIT #SUOL,RPDS(R4) ;DRIVE ONLINE ?
5172 023674 001417 BEQ ST03 ;BR IF NOT
5173 023676 032764 100000 000000 BIT #SUDY,RPDS(R4) ;DRIVE READY ?
5174 023704 001034 BNE ST05 ;BR IF READY
5175 023706 012762 101000 000016 MOV #BIT15:BIT09,16(R2) ;SET INDICATOR FOR TIMEOUT DURING SEEK
5176 023714 000414 BR ST04 ;CONTINUE WITH PROCESSING
5177 023716 012762 110000 000016 ST02: MOV #BIT15:BIT12,16(R2) ;DRIVE UNSAFE INDICATOR
5178 023724 112761 177777 021112 MOVB #-1,DRVSTA(R1) ;SET DRIVE UNSAFE
5179 023732 000405 BR ST04 ;CONTINUE
5180 023734 012762 140000 000016 ST03: MOV #BIT15:BIT14,16(R2) ;DRIVE OFFLINE INDICATOR
5181 023742 105061 021112 CLRB DRVSTA(R1) ;SET DRIVE OFFLINE
5182 023746 006301 ST04: ASL R1 ;ADDRESS WORDS
5183 023750 005061 021244 CLR QWAIT(R1) ;CLEAR THE ENTRY
5184 023754 006201 ASR R1 ;RESTORE R1
5185 023756 146137 021304 021110 BICB ATABIT(R1),DRVACT ;CLEAR DRIVE'S ACTIVE BIT
5186 023764 146137 021304 021126 BICB ATABIT(R1),SEEKWT ;CLEAR SEEK WAIT BIT
5187 023772 004737 024000 JSR PC,SVRP11 ;SAVE THE REGISTERS
5188 023776 000207 ST05: RTS PC ;RETURN

```

;ROUTINE TO SAVE THE RP11E REGISTERS AS PER DPB+14

```

5190 ;CALL
5191 ;
5192 ;
5193 ;
5194 ;
5195 ;
5196 ;
5197 024000 104412 SVRP11: SAVREG ;SAVE R0-R5
5198 024002 013704 MOV RPADR,R4 ;RP11 ADDRESS
5199 024006 111264 MOVB (R2),RPCS+1(R4) ;SELECT DRIVE
5200 024012 016202 MOV 14(R2),R2 ;GET THE ERROR TABLE POINTER
5201 024016 001416 BEQ 45 ;EXIT IF 0
5202 024020 005003 CLR R3 ;COUNTER & POINTER
5203 024022 012705 000020 MOV #RPM2,R5 ;PROBLEM REGISTER
5204 024026 020305 15: CMP R3,R5 ;REACHED RPM2 ?
5205 024030 001002 BNE 25 ;BR IF NO
5206 024032 005723 TST (R3)+ ;INCREMENT THE INDEX
5207 024034 005723 TST (R3)+ ;INCREMENT THE INDEX
5208 024036 010446 25: MOV R4,-(SP) ;FORM RP11 ADDRESS THAT IS
5209 024040 060316 ADD R3,(SP) ;TO BE READ
5210 024042 013622 MOV 2(SP)+,(R2)+ ;AND READ IT
5211 024044 005723 35: TST (R3)+ ;MOVE TO NEXT REG INDEX
5212 024046 020327 000026 CMP R3,#SILO ;DONE?
5213 024052 003765 BLE 15 ;BRANCH IF NO
5214 024054 104413 45: RESREG ;RESTORE R0-R5
5215 024056 000207 RTS PC ;RETURN TO USER

```

;ROUTINE TO PUT THE REQUEST IN THE PROPER QUEUE

0000
0001
0002
0003
0004
0005
0006
0007
0008
0009
0010
0011
0012
0013
0014
0015
0016
0017
0018
0019
0020
0021
0022
0023
0024
0025
0026
0027
0028
0029
0030
0031
0032
0033
0034
0035
0036
0037
0038
0039
0040
0041
0042
0043
0044
0045
0046
0047
0048
0049
0050
0051
0052
0053
0054
0055
0056
0057
0058
0059
0060
0061
0062
0063
0064
0065
0066
0067
0068
0069
0070
0071
0072
0073
0074
0075
0076
0077
0078
0079
0080
0081
0082
0083
0084
0085
0086
0087
0088
0089
0090
0091
0092
0093
0094
0095
0096
0097
0098
0099

024060 010146
024062 032762 000001 000002
024070 001003
024072 012701 021134
024076 000445
024100 122762 000011 000002
024106 001404
024110 122762 000015 000002
024116 001003
024120 012701 021156
024124 000432
024126 122762 000005 000002
024134 001424
024135 122762 000003 000002
024144 001420
024146 122762 000007 000002
024154 001414
024156 122762 000017 000002
024164 001410
024166 122762 000013 000002
024174 001404
024176 012762 120000 000016
024204 000405
024206 012701 021200
024212 004037 024226
024216 000401
024220 005720
024222 012601
024224 000200

```
CALL
MOV #DPBNUM,R2      ; ADDRESS OF PARAMETER BLOCK
JSR  RD,LODQUE      ; PUT THE REQUEST IN THE PROPER QUEUE
RETURN1             ; RETURN HERE IF QUEUE IS FULL
RETURN2            ; RETURN HERE IF REQUEST IS IN QUEUE

LODQUE: MOV R1, -(SP)   ; SAVE R1
          BIT #BIT0,2(R2) ; IS THIS A GET REGISTER REQUEST ?
          BNE 15        ; BR IF NOT
          MOV #QREGS,R1 ; LOAD QUEUE ADDRESS
          BR 75         ; GO ENTER REQUEST
15:      CMPB #SEEK,2(R2) ; SEEK REQUEST ?
          BEQ 25        ; BR IF IT IS
          CMPB #HOMSEK,2(R2) ; HOME SEEK REQUEST ?
          BNE 35        ; BR IF NOT
25:      MOV #QSEEK,R1  ; QUEUE ADDRESS
          BR 75         ; ENTER REQUEST
35:      CMPB #RDSEK,2(R2) ; READ W/IMPLIED SEEK ?
          BEQ 55        ; BR IF IT IS
          CMPB #WRTSEK,2(R2) ; WRITE W/IMPLIED SEEK ?
          BEQ 55        ; BR IF IT IS
          CMPB #WRTCHK,2(R2) ; WRITE CHECK ?
          BEQ 55        ; BR IF WRITE CHECK
          CMPB #READ,2(R2) ; READ W/O IMPLIED SEEK ?
          BEQ 55        ; BR IF IT IS
          CMPB #WRITE,2(R2) ; WRITE W/O IMPLIED SEEK ?
          BEQ 55        ; BR IF IT IS
          MOV #BIT15!BIT13,16(R2) ; SET INVALID OPCODE INDICATOR
          BR 85         ; EXIT WITHOUT MAKING QUEUE ENTRY
55:      MOV #QTRANS,R1 ; QUEUE ADDRESS
          JSR RD,DRVQUE ; PUT THE REQUEST IN THE QUEUE
          BR 95         ; QUEUE WAS FULL
85:      TST (RD)+       ; INCREMENT RETURN
95:      MOV (SP)+,R1    ; RESTORE R1
          RTS RD         ; RETURN

ROUTINE TO PUT A REQUEST IN QUEUE
CALL
MOV #QNAME,R1       ; QUEUE ADDRESS
MOV #DPB,R2         ; ADDRESS OF PARAMETER BLOCK
JSR  RD,DRVQUE      ; GO PUT REQUEST IN QUEUE
RETURN1             ; RETURN HERE IF QUEUE IS FULL
RETURN2            ; RETURN HERE IF REQUEST IS IN QUEUE

DRVQUE: MOV #8, -(SP)  ; QUEUE SIZE COUNTER
15:      TST (R1)+      ; SEE IF AT END OF ENTRIES
          BEQ 25        ; BR IF YES
          DEC (SP)      ; DECREMENT THE COUNTER
          BGT 15        ; BR IF NOT AT END
          BR 35        ; AT END
25:      MOV R2, -2(R1) ; PUT REQUEST IN THE QUEUE
          TST (RD)+     ; INCREMENT RETURN
35:      TST (SP)+     ; CORRECT THE STACK POINTER
          RTS RD        ; RETURN
```

024274
024275
024276
024277
024278
024279
024280
024281
024282
024283
024284
024285
024286
024287
024288
024289
024290
024291
024292
024293
024294
024295
024296
024297
024298
024299
024300
024301
024302
024303
024304
024305
024306
024307
024308
024309
024310
024311
024312
024313
024314
024315
024316
024317
024318
024319
024320
024321
024322
024323
024324
024325
024326
024327
024328
024329

024256 016111 000002
024257 001403
024258 062701 000002
024270 000772
024272 000207

```

;ROUTINE TO "POP" THE REQUEST FROM QUEUE
;CALL
;   MOV    #QNAME,R1    ;QUEUE ADDRESS TO R1
;   JSR   PC,POPQUE    ;CALL TO REMOVE REQUEST
POPQUE: MOV    2(R1),(R1) ;SHIFT ENTRY DOWN
        BEQ   IS        ;BR IF AT END
        ADD   #2,R1     ;INCREMENT THE POINTER
        BR   POPQUE    ;CONTINUE
IS:     RTS   PC        ;RETURN
;*****
.SBTTL  DATA, CONTROL, & STATUS BLOCKS
;*****
;BLOCK LOCATION EQUATE STATEMENTS

```

000001	SMEX	=	1	;EXTENDED MEMORY BITS
000002	SCOMND	=	SMEX+1	;OPERATION CODE
000003	SMODE	=	SCOMND+1	;MODE & HDR BITS
000004	SMRDM	=	SMODE+1	;WORD COUNT (2'S COMP)
000006	SBUF	=	SMRDM+2	;BUFFER ADDR
000010	SCYL	=	SBUF+2	;CYLINDER ADDRESS
000012	SSEC	=	SCYL+2	;SECTOR ADDRESS
000013	STRK	=	SSEC+1	;TRACK ADDRESS OF LAST REG ADDR
000014	SREG	=	STRK+1	;REGISTER STORAGE ADDRESS
000016	STATUS	=	SREG+2	;STATUS WORD (SET BY DRIVER)
000020	SMRDL	=	STATUS+2	;WORD COUNT (NOT 2'S COMP)
000022	SPACK	=	SMRDL+2	;WRITE DATA PACK INDICATOR
000024	SPREVO	=	SPACK+2	;PREVIOUS COMMAND SELECTION CODE
000026	SPATTC	=	SPREVO+2	;PATTERN CODE
000030	SPREVA	=	SPATTC+2	;PREVIOUS ADDRESS - TRACK, SECTOR, CYLINDER
000034	SOPERC	=	SPREVA+4	;OPERATION COUNT
000040	SPOSIT	=	SOPERC+4	;SEEK COUNT
000044	SREAD	=	SPOSIT+4	;TOTAL BITS READ COUNT
000050	STOTAL	=	SREAD+4	;TOTAL ERRORS (ALL TYPES) COUNT
000052	SSOFT	=	STOTAL+2	; 'SOFT' ERROR COUNT
000054	SHARD	=	SSOFT+2	; 'HARD' ERROR COUNT
000056	SSKI	=	SHARD+2	; 'SUSI' ERROR COUNT
000060	SMISPO	=	SSKI+2	;POSITIONING ERROR COUNT
000062	SPASSC	=	SMISPO+2	;PASS COUNTER
000064	SFAIR	=	SPASSC+2	;BUFFER WAIT COUNT
000066	SRPDS	=	SFAIR+2	;RPI1E REGISTER STORAGE
000070	SRPER	=	SRPDS+2	;ERROR REGISTER
000072	SRPCS	=	SRPER+2	;CONTROL REGISTER
000074	SRPMC	=	SRPCS+2	;WORD COUNT REGISTER
000076	SRPBA	=	SRPMC+2	;BUFFER ADDRESS REGISTER
000100	SRPCA	=	SRPBA+2	;CYLINDER ADDRESS REGISTER
000102	SRPDA	=	SRPCA+2	;SECTOR/ADDRESS REGISTER
000104	SRPM1	=	SRPDA+2	;MAINTENANCE REGISTER #1
000106	SSUCA	=	SRPM1+2	;SELECTED UNIT CYLINDER ADDR REGISTER
000110	SSILO	=	SSUCA+2	;SILO REGISTER

G09

5330
5331
5332
5333
5334
5335
5336
5337
5338
5339
5340
5341
5342
5343
5344
5345
5346
5347
5348
5349
5350
5351
5352
5353
5354
5355
5356
5357
5358
5359
5360
5361
5362
5363
5364
5365
5366
5367
5368
5369
5370
5371
5372
5373
5374
5375
5376
5377
5378
5379
5380
5381
5382
5383
5384
5385

```

;BLOCK FOR DRIVE 0
000          000          000          000          000          000          000          000
BLK0:   .BYTE  024274,000          ;DRIVE NUMBER
         .WORD  024276,0000000
         .WORD  024300,0000000
         .WORD  024302,0000000
         .WORD  024304,0000000
         .WORD  024306,0000000
         .WORD  024310,024362          +52
         .WORD  024312,0000000
         .WORD  024314,0000000
         .WORD  024316,0000000
         .WORD  024320,0000000
         .WORD  024322,0000000
         .WORD  024324,0000000
         .WORD  024326,0000000
         .WORD  024328,0000000
         .WORD  024330,0000000
         .WORD  024332,0000000
         .WORD  024334,0000000
         .WORD  024336,0000000
         .WORD  024338,0000000
         .WORD  024340,0000000
         .WORD  024342,0000000
         .WORD  024344,0000000
         .WORD  024346,0000000
         .WORD  024348,0000000
         .WORD  024350,0000000
         .WORD  024352,0000000
         .WORD  024354,0000000
         .WORD  024356,0000000
         .WORD  024360,0000000
         .WORD  024362,0000000
         .WORD  024364,0000000
         .WORD  024366,0000000
         .WORD  024370,0000000
         .WORD  024372,0000000
         .WORD  024374,0000000
         .WORD  024376,0000000
         .WORD  024400,0000000
         .WORD  024402,0000000
         .WORD  024404,0000000

;BLOCK FOR DRIVE 1
000          001          000          000          000          000          000          000
BLK1:   .BYTE  024406,001          ;DRIVE NUMBER
         .WORD  024410,0000000
         .WORD  024412,0000000
         .WORD  024414,0000000
         .WORD  024416,0000000
         .WORD  024420,0000000
         .WORD  024422,024474          +52
         .WORD  024424,0000000
         .WORD  024426,0000000
         .WORD  024430,0000000
         .WORD  024432,0000000
         .WORD  024434,0000000
         .WORD  024436,0000000
         .WORD  024438,0000000
         .WORD  024440,0000000

```


5442	024610	000000		.WORD	0
5443	024612	000000		.WORD	0
5444	024614	000000		.WORD	0
5445	024616	000000		.WORD	0
5446	024620	000000		.WORD	0
5447	024622	000000		.WORD	0
5448	024624	000000		.WORD	0
5449	024626	000000		.WORD	0
5450	024630	000000		.WORD	0

;BLOCK FOR DRIVE 3

5451						
5452						
5453						
5454	024632	003	000	BLK3: .BYTE	3,0	;DRIVE NUMBER
5455	024634	000000		.WORD	0	
5456	024636	000000		.WORD	0	
5457	024640	000000		.WORD	0	
5458	024642	000000		.WORD	0	
5459	024644	000000		.WORD	0	
5460	024646	024720		.WORD	+52	
5461	024650	000000		.WORD	0	
5462	024652	000000		.WORD	0	
5463	024654	000000		.WORD	0	
5464	024656	000000		.WORD	0	
5465	024660	000000		.WORD	0	
5466	024662	000000		.WORD	0	
5467	024664	000000		.WORD	0	
5468	024666	000000		.WORD	0	
5469	024670	000000		.WORD	0	
5470	024672	000000		.WORD	0	
5471	024674	000000		.WORD	0	
5472	024676	000000		.WORD	0	
5473	024700	000000		.WORD	0	
5474	024702	000000		.WORD	0	
5475	024704	000000		.WORD	0	
5476	024706	000000		.WORD	0	
5477	024710	000000		.WORD	0	
5478	024712	000000		.WORD	0	
5479	024714	000000		.WORD	0	
5480	024716	000000		.WORD	0	
5481	024720	000000		.WORD	0	
5482	024722	000000		.WORD	0	
5483	024724	000000		.WORD	0	
5484	024726	000000		.WORD	0	
5485	024730	000000		.WORD	0	
5486	024732	000000		.WORD	0	
5487	024734	000000		.WORD	0	
5488	024736	000000		.WORD	0	
5489	024740	000000		.WORD	0	
5490	024742	000000		.WORD	0	

;BLOCK FOR DRIVE 4

5491						
5492						
5493						
5494	024744	004	000	BLK4: .BYTE	4,0	;DRIVE NUMBER
5495	024746	000000		.WORD	0	
5496	024750	000000		.WORD	0	
5497	024752	000000		.WORD	0	

5498	024754	000000	.WORD	0
5499	024756	000000	.WORD	0
5500	024760	025032	.WORD	+52
5501	024762	000000	.WORD	0
5502	024764	000000	.WORD	0
5503	024766	000000	.WORD	0
5504	024770	000000	.WORD	0
5505	024772	000000	.WORD	0
5506	024774	000000	.WORD	0
5507	024776	000000	.WORD	0
5508	025000	000000	.WORD	0
5509	025002	000000	.WORD	0
5510	025004	000000	.WORD	0
5511	025006	000000	.WORD	0
5512	025010	000000	.WORD	0
5513	025012	000000	.WORD	0
5514	025014	000000	.WORD	0
5515	025016	000000	.WORD	0
5516	025020	000000	.WORD	0
5517	025022	000000	.WORD	0
5518	025024	000000	.WORD	0
5519	025026	000000	.WORD	0
5520	025030	000000	.WORD	0
5521	025032	000000	.WORD	0
5522	025034	000000	.WORD	0
5523	025036	000000	.WORD	0
5524	025040	000000	.WORD	0
5525	025042	000000	.WORD	0
5526	025044	000000	.WORD	0
5527	025046	000000	.WORD	0
5528	025050	000000	.WORD	0
5529	025052	000000	.WORD	0
5530	025054	000000	.WORD	0

;BLOCK FOR DRIVE 5

5531					
5532					
5533					
5534	025056	005	BLKS:	.BYTE	5,0
5535	025060	000000		.WORD	0
5536	025062	000000		.WORD	0
5537	025064	000000		.WORD	0
5538	025066	000000		.WORD	0
5539	025070	000000		.WORD	0
5540	025072	025144		.WORD	+52
5541	025074	000000		.WORD	0
5542	025076	000000		.WORD	0
5543	025100	000000		.WORD	0
5544	025102	000000		.WORD	0
5545	025104	000000		.WORD	0
5546	025106	000000		.WORD	0
5547	025110	000000		.WORD	0
5548	025112	000000		.WORD	0
5549	025114	000000		.WORD	0
5550	025116	000000		.WORD	0
5551	025120	000000		.WORD	0
5552	025122	000000		.WORD	0
5553	025124	000000		.WORD	0

;DRIVE NUMBER

5554	025126	000000	.WORD	0
5555	025130	000000	.WORD	0
5556	025132	000000	.WORD	0
5557	025134	000000	.WORD	0
5558	025136	000000	.WORD	0
5559	025140	000000	.WORD	0
5560	025142	000000	.WORD	0
5561	025144	000000	.WORD	0
5562	025146	000000	.WORD	0
5563	025150	000000	.WORD	0
5564	025152	000000	.WORD	0
5565	025154	000000	.WORD	0
5566	025156	000000	.WORD	0
5567	025160	000000	.WORD	0
5568	025162	000000	.WORD	0
5569	025164	000000	.WORD	0
5570	025166	000000	.WORD	0

;BLOCK FOR DRIVE 6

5571					
5572					
5573					
5574	025170	006	000	BLK6: .BYTE	6,0 ;DRIVE NUMBER
5575	025172	000000		.WORD	0
5576	025174	000000		.WORD	0
5577	025176	000000		.WORD	0
5578	025200	000000		.WORD	0
5579	025202	000000		.WORD	0
5580	025204	025256		.WORD	+52
5581	025206	000000		.WORD	0
5582	025210	000000		.WORD	0
5583	025212	000000		.WORD	0
5584	025214	000000		.WORD	0
5585	025216	000000		.WORD	0
5586	025220	000000		.WORD	0
5587	025222	000000		.WORD	0
5588	025224	000000		.WORD	0
5589	025226	000000		.WORD	0
5590	025230	000000		.WORD	0
5591	025232	000000		.WORD	0
5592	025234	000000		.WORD	0
5593	025236	000000		.WORD	0
5594	025240	000000		.WORD	0
5595	025242	000000		.WORD	0
5596	025244	000000		.WORD	0
5597	025246	000000		.WORD	0
5598	025250	000000		.WORD	0
5599	025252	000000		.WORD	0
5600	025254	000000		.WORD	0
5601	025256	000000		.WORD	0
5602	025260	000000		.WORD	0
5603	025262	000000		.WORD	0
5604	025264	000000		.WORD	0
5605	025266	000000		.WORD	0
5606	025270	000000		.WORD	0
5607	025272	000000		.WORD	0
5608	025274	000000		.WORD	0
5609	025276	000000		.WORD	0

```

5610 025300 000000 .WORD 0
5611
5612 ;BLOCK FOR DRIVE 7
5613
5614 025302 007 000 BLK7: .BYTE 7,0 ;DRIVE NUMBER
5615 025304 000000 .WORD 0
5616 025306 000000 .WORD 0
5617 025310 000000 .WORD 0
5618 025312 000000 .WORD 0
5619 025314 000000 .WORD 0
5620 025316 025370 .WORD 0
5621 025320 000000 .WORD +52
5622 025322 000000 .WORD 0
5623 025324 000000 .WORD 0
5624 025326 000000 .WORD 0
5625 025330 000000 .WORD 0
5626 025332 000000 .WORD 0
5627 025334 000000 .WORD 0
5628 025336 000000 .WORD 0
5629 025340 000000 .WORD 0
5630 025342 000000 .WORD 0
5631 025344 000000 .WORD 0
5632 025346 000000 .WORD 0
5633 025350 000000 .WORD 0
5634 025352 000000 .WORD 0
5635 025354 000000 .WORD 0
5636 025356 000000 .WORD 0
5637 025360 000000 .WORD 0
5638 025362 000000 .WORD 0
5639 025364 000000 .WORD 0
5640 025366 000000 .WORD 0
5641 025370 000000 .WORD 0
5642 025372 000000 .WORD 0
5643 025374 000000 .WORD 0
5644 025376 000000 .WORD 0
5645 025400 000000 .WORD 0
5646 025402 000000 .WORD 0
5647 025404 000000 .WORD 0
5648 025406 000000 .WORD 0
5649 025410 000000 .WORD 0
5650 025412 000000 .WORD 0
5651
5652 ;GENERAL PURPOSE DPB - USED BY 'READHD' & 'RECALT'
5653
5654 025414 000000 000000 177775 GENDPB: .WORD 0,0,-3,CYLDER
5655 025422 033636 000000 025434 .WORD 0,0,GENREG,0
5656 025424 000000 000000 025434 .WORD 0,0,GENREG,0
5657 025432 000000
5658 025434 000012 GENREG: .BLKW 12 ;REGISTER STORAGE IF ERROR
5659
5660 ;*****
5661
5662 .SBTTL TABLES, CONSTANTS, AND VARIABLE LOCATIONS
5663
5664 ;*****
5665

```

5666	025460	000000			ASNLST: .WORD	0		;BIT SET FOR EACH ASSIGNED DRIVE
5667								
5668	025462	000000	000000	000000	ORDERQ: .WORD	0,0,0,0,0,0,0,0,0,0		;LIST OF DRIVES PERFORMING COMMANDS
5669	025470	000000	000000	000000				
5670	025476	000000	000000	000000				
5671								
5672	025504	000000	000000	000000	DUNIT: .WORD	0,0,0,0,0,0,0,0,0,0		;ADDRESSES OF DRIVES TO BE DEASSIGNED
5673	025512	000000	000000	000000				
5674	025520	000000	000000	000000				
5675								
5676	025526	000000	000000	000000	NEWUNT: .WORD	0,0,0,0,0,0,0,0,0,0		;ADDRESSES OF NEWLY ASSIGNED DRIVES
5677	025534	000000	000000	000000				
5678	025542	000000	000000	000000				
5679								
5680	025550	000000	000000	000000	AVAIL: .WORD	0,0,0,0,0,0,0,0,0,0		;LIST OF DRIVES WAITING FOR PARAMETERS
5681	025556	000000	000000	000000				
5682	025564	000000	000000	000000				
5683								
5684	025572	000000	000000	000000	WAIT: .WORD	0,0,0,0,0,0,0,0,0,0		;LIST OF DRIVES WAITING FOR BUFFERS
5685	025600	000000	000000	000000				
5686	025606	000000	000000	000000				
5687								
5688	025614	000000			BUFTBL: .WORD	0		;BUFFER ALLOCATION TABLE ENTRY COUNT
5689	025616	000000	000000		.WORD	0,0		
5690	025622	000000	000000		.WORD	0,0		
5691	025626	000000	000000		.WORD	0,0		
5692	025632	000000	000000		.WORD	0,0		
5693	025636	000000	000000		.WORD	0,0		
5694	025642	000000	000000		.WORD	0,0		
5695	025646	000000	000000		.WORD	0,0		
5696	025652	000000	000000		.WORD	0,0		
5697	025656	000000	000000		.WORD	0,0		
5698	025662	000000	000000		.WORD	0,0		
5699	025666	000000	000000		.WORD	0,0		
5700	025672	000000	000000		.WORD	0,0		
5701	025676	000000	000000		.WORD	0,0		
5702	025702	000000	000000		.WORD	0,0		
5703	025706	000000	000000		.WORD	0,0		
5704	025712	000000	000000		.WORD	0,0		
5705	025716	000000	000000		.WORD	0,0		
5706	025722	000000	000000		.WORD	0,0		
5707	025726	000000	000000		.WORD	0,0		
5708	025732	000000	000000		.WORD	0,0		
5709								
5710	025736				BLKADR: .WORD	BLK0		;ADDRESS OF EACH UNIT BLOCK START
5711	025736	024274			.WORD	BLK1		
5712	025740	024406			.WORD	BLK2		
5713	025742	024520			.WORD	BLK3		
5714	025744	024632			.WORD	BLK4		
5715	025746	024744			.WORD	BLK5		
5716	025750	025056			.WORD	BLK6		
5717	025752	025170			.WORD	BLK7		
5718	025754	025302			.WORD			
5719								
5720	025756	003			COMTBL: .BYTE	WRTSEK		;WRITE WITH IMPLIED SEEK (CODE = 0)
5721	025757	013			.BYTE	WRITE		;WRITE WITHOUT IMPLIED SEEK (CODE = 1)

5722 025760 007 .BYTE WRTCHK ;WRITE CHECK (CODE = 2)
5723 025761 005 .BYTE RDSEK ;READ WITH IMPLIED SEEK (CODE = 3)
5724 025762 017 .BYTE READ ;READ WITHOUT IMPLIED SEEK (CODE = 4)

5725
5726
5727 025764 .EVEN

;;*****

.SBTTL DATA PATTERNS

;;*****

5735 025764 000000 STNDAT: .WORD 0 ;STANDARD DATA PATTERN POINTER TABLE
5736 025766 026070 .WORD DATA1
5737 025770 026130 .WORD DATA1+40
5738 025772 026170 .WORD DATA1+100
5739 025774 026230 .WORD DATA1+140
5740 025776 026270 .WORD DATA1+200
5741 026000 026330 .WORD DATA1+240
5742 026002 026370 .WORD DATA1+300
5743 026004 026430 .WORD DATA1+340
5744 026006 026470 .WORD DATA1+400
5745 026010 026530 .WORD DATA1+440
5746 026012 026570 .WORD DATA1+500
5747 026014 026630 .WORD DATA1+540
5748 026016 026670 .WORD DATA1+600
5749 026020 026730 .WORD DATA1+640
5750 026022 026770 .WORD DATA1+700
5751 026024 026030 .WORD DATA0 ;ZER0ES
5752 026026 026732 .WORD DATA1+642 ;ONES

5753
5754 026030 000000 DATA0: .WORD 0 ;STANDARD PATTERN 0
5755 026032 000000 .WORD 0
5756 026034 000000 .WORD 0
5757 026036 000000 .WORD 0
5758 026040 000000 .WORD 0
5759 026042 000000 .WORD 0
5760 026044 000000 .WORD 0
5761 026046 000000 .WORD 0
5762 026050 000000 .WORD 0
5763 026052 000000 .WORD 0
5764 026054 000000 .WORD 0
5765 026056 000000 .WORD 0
5766 026060 000000 .WORD 0
5767 026062 000000 .WORD 0
5768 026064 000000 .WORD 0
5769 026066 000000 .WORD 0

5770
5771 026070 000001 DATA1: .WORD 000001 ;STANDARD PATTERN 1
5772 026072 000003 .WORD 000003
5773 026074 000007 .WORD 000007
5774 026076 000017 .WORD 000017
5775 026100 000037 .WORD 000037
5776 026102 000077 .WORD 000077
5777 026104 000177 .WORD 000177

5778	026106	000377	.WORD	000377
5779	026110	000777	.WORD	000777
5780	026112	001777	.WORD	001777
5781	026114	003777	.WORD	003777
5782	026116	007777	.WORD	007777
5783	026120	017777	.WORD	017777
5784	026122	037777	.WORD	037777
5785	026124	077777	.WORD	077777
5786	026126	177777	.WORD	177777
5787				
5788	026130	177776	.WORD	177776
5789	026132	177774	.WORD	177774
5790	026134	177770	.WORD	177770
5791	026136	177760	.WORD	177760
5792	026140	177740	.WORD	177740
5793	026142	177700	.WORD	177700
5794	026144	177600	.WORD	177600
5795	026146	177400	.WORD	177400
5796	026150	177000	.WORD	177000
5797	026152	176000	.WORD	176000
5798	026154	174000	.WORD	174000
5799	026156	170000	.WORD	170000
5800	026160	160000	.WORD	160000
5801	026162	140000	.WORD	140000
5802	026164	100000	.WORD	100000
5803	026166	000000	.WORD	000000
5804				
5805	026170	000000	.WORD	000000
5806	026172	000000	.WORD	000000
5807	026174	000000	.WORD	000000
5808	026176	177777	.WORD	177777
5809	026200	177777	.WORD	177777
5810	026202	177777	.WORD	177777
5811	026204	000000	.WORD	000000
5812	026206	000000	.WORD	000000
5813	026210	177777	.WORD	177777
5814	026212	177777	.WORD	177777
5815	026214	000000	.WORD	000000
5816	026216	177777	.WORD	177777
5817	026220	000000	.WORD	000000
5818	026222	177777	.WORD	177777
5819	026224	000000	.WORD	000000
5820	026226	177777	.WORD	177777
5821				
5822	026230	000000	.WORD	000000
5823	026232	010421	.WORD	010421
5824	026234	021042	.WORD	021042
5825	026236	031463	.WORD	031463
5826	026240	042104	.WORD	042104
5827	026242	052525	.WORD	052525
5828	026244	063146	.WORD	063146
5829	026246	073567	.WORD	073567
5830	026250	104210	.WORD	104210
5831	026252	114631	.WORD	114631
5832	026254	125252	.WORD	125252
5833	026256	135673	.WORD	135673

;STANDARD PATTERN 2

;STANDARD PATTERN 3

;STANDARD PATTERN 4

5872	026260	146314	.WORD	146314
5873	026262	156739	.WORD	156739
5874	026264	167356	.WORD	167356
5875	026266	177777	.WORD	177777
5876	026270	050525	.WORD	050525
5877	026272	060626	.WORD	060626
5878	026274	070727	.WORD	070727
5879	026276	080828	.WORD	080828
5880	026280	090929	.WORD	090929
5881	026282	101030	.WORD	101030
5882	026284	111131	.WORD	111131
5883	026286	121232	.WORD	121232
5884	026288	131333	.WORD	131333
5885	026290	141434	.WORD	141434
5886	026292	151535	.WORD	151535
5887	026294	161636	.WORD	161636
5888	026296	171737	.WORD	171737
5889	026298	181838	.WORD	181838
5890	026300	191939	.WORD	191939
5891	026302	202040	.WORD	202040
5892	026304	212141	.WORD	212141
5893	026306	222242	.WORD	222242
5894	026308	232343	.WORD	232343
5895	026310	242444	.WORD	242444
5896	026312	252545	.WORD	252545
5897	026314	262646	.WORD	262646
5898	026316	272747	.WORD	272747
5899	026318	282848	.WORD	282848
5900	026320	292949	.WORD	292949
5901	026322	303050	.WORD	303050
5902	026324	313151	.WORD	313151
5903	026326	323252	.WORD	323252
5904	026330	007417	.WORD	007417
5905	026332	007417	.WORD	007417
5906	026334	007417	.WORD	007417
5907	026336	170360	.WORD	170360
5908	026338	170360	.WORD	170360
5909	026340	170360	.WORD	170360
5910	026342	170360	.WORD	170360
5911	026344	007417	.WORD	007417
5912	026346	007417	.WORD	007417
5913	026348	170360	.WORD	170360
5914	026350	170360	.WORD	170360
5915	026352	170360	.WORD	170360
5916	026354	007417	.WORD	007417
5917	026356	170360	.WORD	170360
5918	026358	007417	.WORD	007417
5919	026360	170360	.WORD	170360
5920	026362	170360	.WORD	170360
5921	026364	007417	.WORD	007417
5922	026366	170360	.WORD	170360
5923	026370	026455	.WORD	026455
5924	026372	026455	.WORD	026455
5925	026374	026455	.WORD	026455
5926	026376	151322	.WORD	151322
5927	026400	151322	.WORD	151322
5928	026402	151322	.WORD	151322
5929	026404	026455	.WORD	026455
5930	026406	026455	.WORD	026455
5931	026410	151322	.WORD	151322
5932	026412	151322	.WORD	151322
5933	026414	026455	.WORD	026455
5934	026416	151322	.WORD	151322
5935	026420	026455	.WORD	026455
5936	026422	151322	.WORD	151322
5937	026424	026455	.WORD	026455
5938	026426	151322	.WORD	151322

;STANDARD PATTERN 5

;STANDARD PATTERN 6

;STANDARD PATTERN 7

5890	026430	077577	.WORD	077577	;STANDARD PATTERN 8 (WORST CASE PATTERN)
5891	026432	077577	.WORD	077577	
5892	026434	077577	.WORD	077577	
5893	026436	077577	.WORD	077577	
5894	026438	077577	.WORD	077577	
5895	026440	077577	.WORD	077577	
5896	026442	077577	.WORD	077577	
5897	026444	077577	.WORD	077577	
5898	026446	077577	.WORD	077577	
5899	026448	077577	.WORD	077577	
5900	026450	077577	.WORD	077577	
5901	026452	077577	.WORD	077577	
5902	026454	077577	.WORD	077577	
5903	026456	077577	.WORD	077577	
5904	026458	077577	.WORD	077577	
5905	026460	077577	.WORD	077577	
5906	026462	077577	.WORD	077577	
5907	026470	000001	.WORD	000001	;STANDARD PATTERN 9
5908	026472	000002	.WORD	000002	
5909	026474	000004	.WORD	000004	
5910	026476	000010	.WORD	000010	
5911	026500	000020	.WORD	000020	
5912	026502	000040	.WORD	000040	
5913	026504	000100	.WORD	000100	
5914	026506	000200	.WORD	000200	
5915	026510	000400	.WORD	000400	
5916	026512	001000	.WORD	001000	
5917	026514	002000	.WORD	002000	
5918	026516	004000	.WORD	004000	
5919	026520	010000	.WORD	010000	
5920	026522	020000	.WORD	020000	
5921	026524	040000	.WORD	040000	
5922	026526	100000	.WORD	100000	
5923	026530	177776	.WORD	177776	;STANDARD PATTERN 10
5924	026532	177775	.WORD	177775	
5925	026534	177773	.WORD	177773	
5926	026536	177767	.WORD	177767	
5927	026540	177757	.WORD	177757	
5928	026542	177737	.WORD	177737	
5929	026544	177677	.WORD	177677	
5930	026546	177577	.WORD	177577	
5931	026550	177377	.WORD	177377	
5932	026552	176777	.WORD	176777	
5933	026554	175777	.WORD	175777	
5934	026556	173777	.WORD	173777	
5935	026558	167777	.WORD	167777	
5936	026560	157777	.WORD	157777	
5937	026562	137777	.WORD	137777	
5938	026564	077777	.WORD	077777	
5939	026566	077777	.WORD	077777	
5940	026570	172666	.WORD	172666	;STANDARD PATTERN 11
5941	026572	155555	.WORD	155555	
5942	026574	172666	.WORD	172666	
5943	026576	155555	.WORD	155555	
5944	026600	172666	.WORD	172666	

5946 026602 155555
5947 026604 172666
5948 026606 155555
5949 026610 172666
5950 026612 155555
5951 026614 172666
5952 026616 155555
5953 026620 172666
5954 026622 155555
5955 026624 172666
5956 026626 155555
5958 026630 077777
5959 026632 137777
5960 026634 157777
5961 026636 167777
5962 026640 173777
5963 026642 175777
5964 026644 176777
5965 026646 177377
5966 026648 177577
5967 026650 177677
5968 026652 177737
5969 026654 177757
5970 026656 177767
5971 026660 177773
5972 026662 177775
5973 026664 177776
5974 026666 177776
5975 026670 153333
5976 026672 066667
5977 026674 153333
5978 026676 066667
5979 026700 153333
5980 026702 066667
5981 026704 153333
5982 026706 066667
5983 026710 153333
5984 026712 066667
5985 026714 153333
5986 026716 066667
5987 026720 153333
5988 026722 066667
5989 026724 153333
5990 026726 066667
5991 026730 000000
5992 026732 000000
5993 026734 177777
5994 026736 177777
5995 026740 177777
5996 026742 177777
5997 026744 177777
5998 026746 177777
6000 026750 177777
6001 026752 177777

.WORD 155555
.WORD 172666
.WORD 155555
.WORD 172666
.WORD 155555
.WORD 172666
.WORD 155555
.WORD 172666
.WORD 155555
.WORD 172666
.WORD 155555
.WORD 172666
.WORD 155555
.WORD 077777
.WORD 137777
.WORD 157777
.WORD 167777
.WORD 173777
.WORD 175777
.WORD 176777
.WORD 177377
.WORD 177577
.WORD 177677
.WORD 177737
.WORD 177757
.WORD 177767
.WORD 177773
.WORD 177775
.WORD 177776
.WORD 153333
.WORD 066667
.WORD 153333
.WORD 066667
.WORD 153333
.WORD 066667
.WORD 153333
.WORD 066667
.WORD 153333
.WORD 066667
.WORD 153333
.WORD 066667
.WORD 153333
.WORD 066667
.WORD 153333
.WORD 066667
.WORD 000000
.WORD 000000
.WORD 177777
.WORD 177777
.WORD 177777
.WORD 177777
.WORD 177777
.WORD 177777
.WORD 177777
.WORD 177777

;STANDARD PATTERN 12

;STANDARD PATTERN 13

;STANDARD PATTERN 14

6002	026754	177777	.WORD	177777
6003	026756	177777	.WORD	177777
6004	026760	177777	.WORD	177777
6005	026762	177777	.WORD	177777
6006	026764	177777	.WORD	177777
6007	026766	177777	.WORD	177777
6008				
6009	026770	177777	.WORD	177777
6010	026772	177777	.WORD	177777
6011	026774	000000	.WORD	000000
6012	026776	000000	.WORD	000000
6013	027000	000000	.WORD	000000
6014	027002	000000	.WORD	000000
6015	027004	000000	.WORD	000000
6016	027006	000000	.WORD	000000
6017	027010	000000	.WORD	000000
6018	027012	000000	.WORD	000000
6019	027014	000000	.WORD	000000
6020	027016	000000	.WORD	000000
6021	027020	000000	.WORD	000000
6022	027022	000000	.WORD	000000
6023	027024	000000	.WORD	000000
6024	027026	000000	.WORD	000000

;STANDARD PATTERN 15

;;*****

.SBTTL PRINTER/TELETYPE MESSAGES

;;*****

6032	027030	050122	030461	042040	EM1: .ASCIZ 3RP11 DIDN'T RESPOND TO ADDRESSING3
6033	027036	042111	023516	020124	
6034	027044	042522	050123	047117	
6035	027052	020104	047524	040440	
6036	027060	042104	042522	051523	
6037	027066	047111	000107		
6038					
6039	027072	047111	040526	044514	EM2: .ASCIZ 3INVALID RP11 COMMAND3
6040	027100	020104	050122	030461	
6041	027106	041440	046517	040515	
6042	027114	042116	000		
6043					
6044	027117	125	042116	043105	EM3: .ASCIZ 3UNDEFINED INTERRUPT FROM THE RP113
6045	027124	047111	042105	044440	
6046	027132	052116	051105	052522	
6047	027140	052120	043040	047522	
6048	027146	020115	044124	020105	
6049	027154	050122	030461	000	
6050					
6051	027161	103	047101	052047	EM10: .ASCIZ 3CAN'T MATCH DATA READ WITH A PATTERN3
6052	027166	046440	052101	044103	
6053	027174	042040	052101	020101	
6054	027202	042522	042101	053440	
6055	027210	052111	020110	020101	
6056	027216	040520	052124	051105	
6057	027224	000116			

6058						
6059	027226	040504	040524	041440	EM12:	.ASCIZ 2DATA COMPARE ERRORS2
6060	027234	046517	040520	042522		
6061	027242	042440	051122	051117		
6062	027250	000123				
6063						
6064	027252	042447	051122	020047	EM15:	.ASCIZ 2'ERR' NOT SET BUT 'RPER' CONTENTS NOT ZERO2
6065	027260	047516	020124	042523		
6066	027266	020124	052502	020124		
6067	027274	051047	042520	023522		
6068	027302	041440	047117	042524		
6069	027310	052116	020123	047516		
6070	027316	020124	042532	047522		
6071	027324	000				
6072						
6073	027325	127	051117	020104	EM16:	.ASCIZ 2WORD COUNT NOT ZERO OR BUFFER ADDRESS WRONG2
6074	027332	047503	047125	020124		
6075	027340	047516	020124	042532		
6076	027346	047522	047440	020122		
6077	027354	052502	043106	051105		
6078	027362	040440	042104	042522		
6079	027370	051523	053440	047522		
6080	027376	043516	000			
6081						
6082	027401	123	043117	053524	EM17:	.ASCIZ 2SOFTWARE TIMEOUT DURING POSITIONING2
6083	027406	051101	020105	044524		
6084	027414	042515	052517	020124		
6085	027422	052504	044522	043516		
6086	027430	050040	051517	052111		
6087	027436	047511	044516	043516		
6088	027444	000				
6089						
6090	027445	123	043117	053524	EM20:	.ASCIZ 2SOFTWARE TIMEOUT DURING I/O2
6091	027452	051101	020105	044524		
6092	027460	042515	052517	020124		
6093	027466	052504	044522	043516		
6094	027474	044440	047457	000		
6095						
6096	027501	104	044522	042526	EM21:	.ASCIZ 2DRIVE OFFLINE2
6097	027506	047440	043106	044514		
6098	027514	042516	000			
6099						
6100	027517	104	044522	042526	EM22:	.ASCIZ 2DRIVE UNSAFE2
6101	027524	052440	051516	043101		
6102	027532	000105				
6103						
6104	027534	042523	045505	044440	EM23:	.ASCIZ 2SEEK INCOMPLETE2
6105	027542	041516	046517	046120		
6106	027550	052105	000105			
6107						
6108	027554	047125	041111	051525	EM24:	.ASCIZ 2UNIBUS TRANSFER ERROR2
6109	027562	052040	040522	051516		
6110	027570	042506	020122	051105		
6111	027576	047522	000122			
6112						
6113	027602	047503	052116	047522	EM25:	.ASCIZ 2CONTROLLER ERROR2

6114	027610	046114	051105	042440	
6115	027616	051122	051117	000	
6116					
6117	027623	116	047117	042455	EM26: .ASCIZ 3NON-EXISTENT DISK ADDRESS3
6118	027630	044530	051123	047105	
6119	027636	020124	044504	045523	
6120	027644	040440	042104	042522	
6121	027652	051523	000		
6122					
6123	027655	104	052101	020101	EM27: .ASCIZ 3DATA ERROR3
6124	027662	051105	047522	000122	
6125					
6126	027670	051127	052111	020105	EM32: .ASCIZ 3WRITE CHECK ERROR (NO DATA ERROR)3
6127	027676	044103	041505	020113	
6128	027704	051105	047522	020122	
6129	027712	047050	020117	040504	
6130	027720	040524	042440	051122	
6131	027726	051117	000051		
6132					
6133	027732	051127	052111	020105	EM33: .ASCIZ 3WRITE CHECK ERROR (DATA ERROR BITS SET)3
6134	027740	044103	041505	020113	
6135	027746	051105	047522	020122	
6136	027754	042050	052101	020101	
6137	027762	051105	047522	020122	
6138	027770	044502	051524	051440	
6139	027776	052105	000051		
6140					
6141	030002	042510	042101	051105	EM34: .ASCIZ 3HEADER NOT FOUND3
6142	030010	047040	052117	043040	
6143	030016	052517	042116	000	
6144					
6145	030023	104	051117	040515	EM35: .ASCIZ 3FORMAT ERROR WHILE SEARCHING FOR INITIAL SECTOR3
6146	030030	020124	051105	047522	
6147	030036	020122	044127	046111	
6148	030044	020105	042523	051101	
6149	030052	044103	047111	020107	
6150	030060	047506	020122	047111	
6151	030066	052111	040511	020114	
6152	030074	042523	052103	051117	
6153	030102	000			
6154					
6155	030103	110	040505	042504	EM36: .ASCIZ 3HEADER NOT FOUND, CYLINDER IN HEADER DOES NOT COMPARE3
6156	030110	020122	047516	020124	
6157	030116	047506	047125	026104	
6158	030124	041440	046131	047111	
6159	030132	042504	020122	047111	
6160	030140	044040	040505	042504	
6161	030146	020122	047504	051505	
6162	030154	047040	052117	041440	
6163	030162	046517	040520	042522	
6164	030170	000			
6165					
6166	030171	104	043111	042506	EM37: .ASCIZ 3DIFFERENT ERROR DURING RETRY3
6167	030176	042522	052116	042440	
6168	030204	051122	051117	042040	
6169	030212	051125	047111	020107	

6170	030220	042522	051124	000131					
6171									
6172	030226	042447	051122	020047	EM43:	.ASCIZ	3'ERR'	SET BUT NOT ERROR BITS SET3	
6173	030234	042523	020124	052502					
6174	030242	020124	047516	020124					
6175	030250	051105	047522	020122					
6176	030256	044502	051524	051440					
6177	030264	052105	000						
6178									
6179	030267	127	044522	042524	EM44:	.ASCIZ	3WRITE PROTECTION VIOLATION3		
6180	030274	050040	047522	042524					
6181	030302	052103	047511	020116					
6182	030310	044526	046117	052101					
6183	030316	047511	000116						
6184									
6185	030322	047506	046522	052101	EM45:	.ASCIZ	3FORMAT ERROR DURING I/O3		
6186	030330	042440	051122	051117					
6187	030336	042040	051125	047111					
6188	030344	020107	027511	000117					
6189									
6190	030352	050122	042101	000122	DH1:	.ASCIZ	3RPAOR3		
6191	030360	051104	020126	020043	DH2:	.ASCIZ	3DRV #	RPCS3	
6192	030366	020040	050122	051503					
6193	030374	000							
6194	030375	122	042120	020123	DH3:	.ASCIZ	3RPOS	RPCS3	
6195	030402	020040	051040	041520					
6196	030410	000123							
6197	030412	020040	020040	020040	DH10:	.ASCII	3	BUFFER3<15><12>	
6198	030420	020040	052502	043106					
6199	030426	051105	005015						
6200	030432	051104	020126	020043		.ASCIZ	3DRV #	START CYL TRK SEC3	
6201	030440	020040	052123	051101					
6202	030446	020124	020040	054503					
6203	030454	020114	020040	020040					
6204	030462	051124	020113	020040					
6205	030470	020040	042523	000103					
6206	030476	042101	051104	020040	DH10A:	.ASCIZ	3ADDR	CONTENTS3	
6207	030504	020040	047503	052116					
6208	030512	047105	051524	000					
6209	030517	040	020040	020040	DH12:	.ASCII	3	GOOD BAD3<15><12>	
6210	0524	020040	043440	047517					
6211	030532	020104	020040	041040					
6212	030540	042101	005015						
6213	030544	042101	051104	020040		.ASCIZ	3ADDR	DATA DATA3	
6214	030552	020040	040504	040524					
6215	030560	020040	020040	040504					
6216	030566	040524	000						
6217	030571	124	052117	046101	DH14:	.ASCIZ	3TOTAL COMPARE ERRORS:3		
6218	030576	041440	046517	040520					
6219	030604	042522	042440	051122					
6220	030612	051117	035123	000					
6221	030617	104	053123	021440	DH15:	.ASCIZ	3DRV #	RPDS RPER RPCS3	
6222	030624	020040	051040	042120					
6223	030632	020123	020040	051040					
6224	030640	042520	020122	020040					
6225	030646	051040	041520	000123					

6282	031341	104	053122	021440	DH26:	.ASCIZ	DRV #	RPDS	RPER	RPCS	RPCA	RPDA	
6283	031346	020040	051040	042120									
6284	031354	020123	020040	051040									
6285	031362	042520	020122	020040									
6286	031370	051040	041520	020123									
6287	031376	020040	051040	041520									
6288	031404	020101	020040	051040									
6289	031412	042120	000101										
6290	031416	051104	020126	020043	DH27:	.ASCIZ	DRV #	CYL	TRK	SEC	RPDS	RPER	RPCS
6291	031424	020040	054503	020114									
6292	031432	020040	020040	051124									
6293	031440	020113	020040	020040									
6294	031446	042523	020103	020040									
6295	031454	020040	050122	051504									
6296	031462	020040	020040	050122									
6297	031470	051105	020040	020040									
6298	031476	050122	051503	000									
6299	031503	122	053520	020103	DH27A:	.ASCIZ	RPWC	RPBA	RPCA	RPDA	RPM1	SUCA	SIL0
6300	031510	020040	051040	041120									
6301	031516	020101	020040	051040									
6302	031524	041520	020101	020040									
6303	031532	051040	042120	020101									
6304	031540	020040	051040	046520									
6305	031546	020061	020040	051440									
6306	031554	041525	020101	020040									
6307	031562	051440	046111	000117									
6308	031570	047523	052106	042440	DH30:	.ASCIZ	SOFT ERROR						
6309	031576	051122	051117	000									
6310	031603	110	051101	020104	DH31:	.ASCIZ	HARD ERROR						
6311	031610	051105	047522	000122									
6312	031616	051104	020126	020043	DH34:	.ASCIZ	DRV #	PREV CYL	RPDS	RPER	RPCS	RPDA	
6313	031624	051120	053105	041440									
6314	031632	046131	020040	050122									
6315	031640	051504	020040	020040									
6316	031646	050122	051105	020040									
6317	031654	020040	050122	051503									
6318	031662	020040	020040	050122									
6319	031670	040504	000										
6320	031673	122	041520	020101	DH34A:	.ASCIZ	RPCA	SUCA	HEADER (AS READ INTO MEM)				
6321	031700	020040	051440	041525									
6322	031706	020101	020040	044040									
6323	031714	040505	042504	020122									
6324	031722	040450	020123	042522									
6325	031730	042101	044440	052116									
6326	031736	020117	042515	024515									
6327	031744	000											
6328	031745	122	052105	054522	DH41:	.ASCIZ	RETRY SUCCESSFUL						
6329	031752	051440	041525	051505									
6330	031760	043123	046125	000									
6331	031765	122	052105	054522	DH42:	.ASCIZ	RETRY UNSUCCESSFUL						
6332	031772	052440	051516	041525									
6333	032000	051505	043123	046125									
6334	032006	000											
6335													
6336		032010											
6337													

.EVEN

6338	032010	001216			DT1:	.WORD	RPADR
6339	032012	001264	001166		DT2:	.WORD	DRIVE, \$REGO+RPCS
6340	032016	021104	021106		DT3:	.WORD	RPERRS, RPERRS+2
6341	032022	001122	001126		DT11:	.WORD	\$BDADR, \$BDAT
6342	032026	001264	013164	013156	DT10:	.WORD	DRIVE, CMBUF, CMCYL, CMTRK, CMSEC
6343	032034	013162	013160				
6344	032040	001122	001124	001126	DT13:	.WORD	\$BDADR, \$GDDAT, \$BDAT
6345	032046	013150			DT14:	.WORD	ERCTR
6346	032050	001264	001162	001164	DT15:	.WORD	DRIVE, \$REGO+RPDS, \$REGO+RPER, \$REGO+RPCS
6347	032056	001166					
6348	032060	001264	001124	001172	DT16:	.WORD	DRIVE, \$GDDAT, \$REGO+RPBA, \$REGO+RPWC, \$REGO+RPDS, \$REGO+RPER
6349	032066	001170	001162	001164			
6350	032074	001166				.WORD	\$REGO+RPCS
6351	032076	001264	001162	001164	DT17:	.WORD	DRIVE, \$REGO+RPDS, \$REGO+RPER, \$REGO+RPCS, \$REGO+RPWC, \$REGO+RPBA
6352	032104	001166	001170	001172			
6353	032112	001174	001176	001200	DT17A:	.WORD	\$REGO+RPCA, \$REGO+RPDA, \$REGO+RPM1, \$REGO+20, \$REGO+22
6354	032120	001202	001204				
6355	032124	001264	001124	001126	DT23:	.WORD	DRIVE, \$GDDAT, \$BDAT, \$REGO+RPDS, \$REGO+RPER, \$REGO+RPCS
6356	032132	001162	001164	001166			
6357	032140	001174	001202		DT23A:	.WORD	\$REGO+RPCA, \$REGO+20
6358	032144	001264	001162	001164	DT24:	.WORD	DRIVE, \$REGO+RPDS, \$REGO+RPER, \$REGO+RPCS, \$REGO+RPBA
6359	032152	001166	001172				
6360	032156	001264	001162	001164	DT25:	.WORD	DRIVE, \$REGO+RPDS, \$REGO+RPER, \$REGO+RPCS
6361	032164	001166					
6362	032166	001264	001162	001164	DT26:	.WORD	DRIVE, \$REGO+RPDS, \$REGO+RPER, \$REGO+RPCS, \$REGO+RPCA, \$REGO+RPDA
6363	032174	001166	001174	001176			
6364	032202	001264	001266	001270	DT27:	.WORD	DRIVE, CYL.ER, TRK.ER, SEC.ER, \$REGO+RPDS, \$REGO+RPER, \$REGO+RPCS
6365	032210	001272	001162	001164			
6366	032216	001166					
6367	032220	001170	001172	001174	DT27A:	.WORD	\$REGO+RPWC, \$REGO+RPBA, \$REGO+RPCA, \$REGO+RPDA, \$REGO+RPM1, \$REGO+20, \$REGO+22
6368	032226	001176	001200	001202			
6369	032234	001274					
6370	032236	001264	001124	001162	DT34:	.WORD	DRIVE, \$GDDAT, \$REGO+RPDS, \$REGO+RPER, \$REGO+RPCS, \$REGO+RPDA
6371	032244	001164	001166	001176			
6372	032252	001174	001202	033636	DT34A:	.WORD	\$REGO+RPCA, \$REGO+20, CYLDER, CYLDER+2, CYLDER+4
6373	032260	033640	033642				
6374							
6375	032264	000001			DF1:	.WORD	1 ;1 'DH' LINE
6376	032266	001				.BYTE	1 ;# OF ENTRIES IN 'DH' LINE
6377	032267	000				.BYTE	0 ;ENTRIES ARE ALL OCTAL
6378							
6379							
6380	032270	000001			DF2:	.WORD	1 ;2 ENTRIES IN THE 'DH'
6381	032272	002				.BYTE	2
6382	032273	000				.BYTE	0
6383							
6384	032274	000002			DF10:	.WORD	2
6385	032276	005				.BYTE	5
6386	032277	000				.BYTE	0
6387	032300	030476				.WORD	DH10A
6388	032302	000				.BYTE	0
6389	032303	000				.BYTE	0
6390							
6391	032304	000002			DF12:	.WORD	2
6392	032306	005				.BYTE	5
6393	032307	000				.BYTE	0

6394	032310	030517		.WORD	DH12	
6395	032312	000		.BYTE	0	
6396	032313	000		.BYTE	0	
6397						
6398	032314	000001	DF13:	.WORD	1	
6399	032316	003		.BYTE	3	
6400	032317	000		.BYTE	0	
6401						
6402	032320	000001	DF14:	.WORD	1	
6403	032322	001		.BYTE	1	
6404	032323	001		.BYTE	1	;ITEM IS DECIMAL
6405						
6406	032324	000001	DF15:	.WORD	1	
6407	032326	004		.BYTE	4	
6408	032327	000		.BYTE	0	
6409						
6410	032330	000001	DF16:	.WORD	1	
6411	032332	007		.BYTE	7	
6412	032333	000		.BYTE	0	
6413						
6414	032334	000002	DF17:	.WORD	2	;2 'DH' LINES
6415	032336	006		.BYTE	6	
6416	032337	000		.BYTE	0	
6417	032340	031052		.WORD	DH17A	
6418	032342	005		.BYTE	5	
6419	032343	000		.BYTE	0	
6420						
6421	032344	000002	DF23:	.WORD	2	
6422	032346	006		.BYTE	6	
6423	032347	000		.BYTE	0	
6424	032350	031222		.WORD	DH23A	
6425	032352	002		.BYTE	2	
6426	032353	000		.BYTE	0	
6427						
6428	032354	000001	DF24:	.WORD	1	
6429	032356	005		.BYTE	5	
6430	032357	000		.BYTE	0	
6431						
6432	032360	000001	DF26:	.WORD	1	
6433	032362	006		.BYTE	6	
6434	032363	000		.BYTE	0	
6435						
6436	032364	000002	DF27:	.WORD	2	;2 'DH' LINES
6437	032366	007		.BYTE	7	
6438	032367	000		.BYTE	0	
6439	032370	031503		.WORD	DH27A	
6440	032372	007		.BYTE	7	
6441	032373	000		.BYTE	0	
6442						
6443	032374	000002	DF34:	.WORD	2	
6444	032376	006		.BYTE	6	
6445	032377	000		.BYTE	0	
6446	032400	031673		.WORD	DH34A	
6447	032402	005		.BYTE	5	
6448	032403	000		.BYTE	0	
6449						

6450											
6451	032404	047503	052116	047105	LIN11H:	.ASCII	CONTENTS OF ERROR SECTOR (REPORTED ABOVE)	<15>	<12>		
6452	032412	051524	047440	020106							
6453	032420	051105	047522	020122							
6454	032426	042523	052103	051117							
6455	032434	024040	042522	047520							
6456	032442	052122	042105	040440							
6457	032450	047502	042526	006451							
6458	032456	012									
6459	032457	101	042104	020122		.ASCIZ	ADDR	DATA	<15>	<12>	
6460	032464	020040	042040	052101							
6461	032472	006501	000012								
6462	032476	040				SPACE4:	.ASCII	/	/		
6463	032477	040				SPACE3:	.ASCII	/	/		
6464	032500	040				SPACE2:	.ASCII	/	/		
6465	032501	040	000			SPACE1:	.ASCIZ	/	/		
6466	032503	122	030120	000062		RPO2:	.ASCIZ	/RPO2/			
6467	032510	050122	031460	000		RPO3:	.ASCIZ	/RPO3/			
6468	032515	104	044522	042526		UNTMSG:	.ASCIZ	/DRIVE /			
6469	032522	000040									
6470	032524	047440	043106	044514		UNTOFF:	.ASCIZ	/ OFFLINE/			
6471	032532	042516	000								
6472	032535	040	047117	044514		UNTON:	.ASCIZ	/ ONLINE/			
6473	032542	042516	000								
6474	032545	040	047516	020124		UNTNOT:	.ASCIZ	/ NOT BEING TESTED/			
6475	032552	042502	047111	020107							
6476	032560	042524	052123	042105							
6477	032566	000									
6478	032567	040	046101	042522		UNTSN:	.ASCIZ	/ ALREADY BEING TESTED/			
6479	032574	042101	020131	042502							
6480	032602	047111	020107	042524							
6481	032610	052123	042105	000							
6482	032615	040	047125	040523		NOTSAF:	.ASCIZ	/ UNSAFE/			
6483	032622	042506	000								
6484	032625	104	044522	042526		SYSTAT:	.ASCIZ	/DRIVE STATUS: /	<15>	<12>	<12>
6485	032632	051440	040524	052524							
6486	032640	035123	005015	000012							
6487	032646	051104	053111	020105		STATHD:	.ASCII	/DRIVE PERFORMANCE SUMMARY /	<15>	<12>	
6488	032654	042520	043122	051117							
6489	032662	040515	041516	020105							
6490	032670	052523	046515	051101							
6491	032676	006531	012								
6492	032701	104	053122	050040			.ASCII	/DRV PASS ORDERS	SEEKS	WRDS READ/	
6493	032706	051501	020123	051117							
6494	032714	042504	051522	020040							
6495	032722	051440	042505	051513							
6496	032730	020040	053440	042122							
6497	032736	020123	042522	042101							
6498	032744	051440	043117	020124			.ASCIZ	/ SOFT HARD SUSI MISP OTHER /	<15>	<12>	
6499	032752	040510	042122	051440							
6500	032760	051525	020111	044515							
6501	032766	050123	047440	044124							
6502	032774	051105	005015	000							
6503	033001	007	043077	052101		DROPNG:	.ASCIZ	<07> / ?FATAL OR EXCESSIVE ERRORS /			
6504	033006	046101	047440	020122							
6505	033014	054105	042503	051523							

6506	033022	053111	020105	051105	
6507	033030	047522	051522	000	
6508	033035	105	042116	047440	ENDPAS: .ASCIZ /END OF PASS/
6509	033042	020106	040520	051523	
6510	033050	000			
6511	033051	015	042412	042116	ENDTST: .ASCIZ <15><12>/END OF TEST/
6512	033056	047440	020106	042524	
6513	033064	052123	000		
6514	033067	040	042504	051501	DEASSG: .ASCIZ / DEASSIGNED/
6515	033074	044523	047107	042105	
6516	033102	000			
6517	033103	015	025012	025052	DRNUM: .ASCIZ <15><12>/***** DRIVE 8 /
6518	033110	025052	025052	025052	
6519	033116	020052	051104	053111	
6520	033124	020105	020043	000	
6521	033131	040	052123	051101	ASGND: .ASCIZ / STARTED/<15><12>
6522	033136	042524	006504	000012	
6523	033144	000077			QUES: .ASCIZ /?/
6524	033146	047111	040926	044514	INVL: .ASCIZ /INVALID COMMAND/<15><12>
6525	033154	020104	047503	046515	
6526	033162	047101	006504	000012	
6527	033170	020077	047111	040526	BADENT: .ASCIZ /? INVALID ENTRY/<15><12>
6528	033176	044514	020104	047105	
6529	033204	051124	006531	000012	
6530	033212	005015	051120	043517	INTDON: .ASCIZ <15><12>/PROGRAM INITIALIZATION COMPLETE, ENTER COMMANDS/<15><12>
6531	033220	040522	020115	047111	
6532	033226	052111	040511	044514	
6533	033234	040532	044524	047117	
6534	033242	041440	046517	046120	
6535	033250	052105	026105	042440	
6536	033256	052116	051105	041440	
6537	033264	046517	040515	042116	
6538	033272	006523	000012		

.EVEN

6541	033276	033571	PARLST: .WORD	PAR11	;PARAMETER ENTRY LIST
6542	033300	001216	.WORD	RPADR	
6543	033302	033600	.WORD	PAR12	
6544	033304	001220	.WORD	RPVEC	
6545	033306	033501	.WORD	PAR1	
6546	033310	001306	.WORD	BUFRSZ	;LOCATION
6547	033312	033531	.WORD	PAR4	
6548	033314	001324	.WORD	LC	
6549	033316	033535	.WORD	PAR5	
6550	033320	001326	.WORD	FC	
6551	033322	033541	.WORD	PAR6	
6552	033324	001330	.WORD	LT	
6553	033326	033545	.WORD	PAR7	
6554	033330	001332	.WORD	FT	
6555	033332	033551	.WORD	PAR8	
6556	033334	001334	.WORD	LS	
6557	033336	033555	.WORD	PAR9	
6558	033340	001336	.WORD	FS	
6559	033342	033511	.WORD	PAR2	;PARAMETER NAME
6560	033344	001312	.WORD	INTRVL	
6561	033346	033626	.WORD	PAR19	

```

6562 033350 001304 .WORD PASCNT
6563 033352 033561 .WORD PAR10
6564 033354 001316 .WORD SEKMOD
6565 033356 033607 .WORD PAR14
6566 033360 001320 .WORD RATIO
6567 033362 033521 .WORD PAR3
6568 033364 001314 .WORD CMPLMT
6569 033366 033616 .WORD PAR15
6570 033370 001322 .WORD AUTOCK
6571 033372 000000 .WORD 0 ;TABLE TERMINATOR
6572
6573 033374 047105 042524 020122 ASKPAR: .ASCIZ /ENTER PARAMETERS:/(15)(12)(12)
6574 033402 040520 040522 042515
6575 033410 042524 051522 006472
6576 033416 005012 000
6577 033421 015 042412 051122 NGPAR: .ASCIZ (15)(12)/ERROR IN PARAMETER: /
6578 033426 051117 044440 020116
6579 033434 040520 040522 042515
6580 033442 042524 035122 020040
6581 033450 000
6582 033451 040 051040 026505 REPAR: .ASCIZ / RE-ENTER PARAMETERS/(15)(12)
6583 033456 047105 042524 020122
6584 033464 040520 040522 042515
6585 033472 042524 051522 005015
6586 033500 000
6587
6588 033501 102 043125 051522 PAR1: .ASCIZ /BUFRSZ /
6589 033506 020132 000
6590 033511 111 052116 053122 PAR2: .ASCIZ /INTRVL /
6591 033516 020114 000
6592 033521 103 050115 046514 PAR3: .ASCIZ /CMPLMT /
6593 033526 020124 000
6594 033531 114 020103 000 PAR4: .ASCIZ /LC /
6595 033535 106 020103 000 PAR5: .ASCIZ /FC /
6596 033541 114 020124 000 PAR6: .ASCIZ /LT /
6597 033545 106 020124 000 PAR7: .ASCIZ /FT /
6598 033551 114 020123 000 PAR8: .ASCIZ /LS /
6599 033555 106 020123 000 PAR9: .ASCIZ /FS /
6600 033561 123 045505 047515 PAR10: .ASCIZ /SEKMOD /
6601 033566 020104 000
6602 033571 122 040520 051104 PAR11: .ASCIZ /RPADR /
6603 033576 000040
6604 033600 050122 042526 020103 PAR12: .ASCIZ /RPVEC /
6605 033606 000
6606 033607 122 052101 047511 PAR14: .ASCIZ /RATIO /
6607 033614 000040
6608 033616 052501 047524 045503 PAR15: .ASCIZ /AUTOCK /
6609 033624 000040
6610 033626 040520 041523 052116 PAR19: .ASCIZ /PASCNT /
6611 033634 000040
6612
6613 .EVEN
6614
6615 033636 000000 000000 000000 CYLDER: .WORD 0,0,0 ;HEADER BUFFER FOR 'READHD' ROUTINE
6616
6617 033644 ENDPGM = . ;BUFFERS START HERE

```

```

6618
6619 033644 005015 046412 044501 TITLE: .ASCII <15><12><12>/MAINDEC-11-DZRP1-B/<15><12>
6620 033652 042116 041505 030455
6621 033660 026461 055104 050122
6622 033666 026461 006502 012
6623 033673 122 030520 042461 .ASCIZ /RPI1E MULTI-DRIVE EXERCISER PROGRAM/<15><12><12>
6624 033700 046440 046122 044524
6625 033706 042055 044522 042526
6626 033714 042440 042530 041522
6627 033722 051511 051105 050040
6628 033730 047522 051107 046501
6629 033736 005015 000012
6630
6631 .EVEN
6632 .SBTTL ROUTINE TO SIZE MEMORY
6633
6634 ::*****
6635 ::CALL:
6636 :: JSR PC,SSIZE
6637 :: RETURN
6638 ::SLSTAD WILL CONTAIN THE LAST AVAILABLE MEMORY LOCATION
6639
6640 033742 010046 SSIZE: MOV RO,-(SP) ;;SAVE RO ON THE STACK
6641 033744 010146 MOV R1,-(SP) ;;SAVE R1 ON THE STACK
6642 033746 013746 000004 MOV @#ERRVEC,-(SP) ;;SAVE PRESENT ERROR VECTOR PS & PC
6643 033752 013746 000006 MOV @#ERRVEC+2,-(SP)
6644 033756 010600 MOV SP,RO ;;SAVE THE STACK POINTER
6645 ;;SET THE ERRVEC PS TO THE PRESENT PS
6646 033760 104400 TRAP ;;PUSH OLD PSM AND PC ON STACK
6647 033762 012637 000006 MOV (SP)+,@#ERRVEC+2 ;;SAVE THE PSM IN @#ERRVEC+2
6648 033766 012737 034006 000004 MOV #2,@#ERRVEC ;;SET FOR TIMEOUT
6649 033774 012701 020000 MOV #20000,R1 ;;FIRST ADDRESS
6650 034000 005711 1S: TST (R1) ;;TEST THIS ADDRESS
6651 034002 005721 TST (R1)+ ;;STEP TO NEXT ADDRESS
6652 034004 000775 BR 1S ;;TRY ANOTHER
6653 034006 162701 000002 2S: SUB #2,R1 ;;DROP BACK
6654 034012 010006 MOV RO,SP ;;RESTORE THE STACK
6655 034014 012637 000006 MOV (SP)+,@#ERRVEC+2 ;;RESTORE ERROR VECTOR
6656 034020 012637 000004 MOV (SP)+,@#ERRVEC
6657 034024 010137 034036 MOV R1,SLSTAD ;;LAST ADDRESS
6658 034030 012601 MOV (SP)+,R1 ;;RESTORE R1
6659 034032 012600 MOV (SP)+,RO ;;RESTORE RO
6660 034034 000207 RTS PC
6661 034036 000000 SLSTAD: .WORD 0 ;;CONTAINS THE LAST ADDRESS
6662
6663 000001 .END

```


QSEK	021156	4711#	4856	4887	4888	4890	4899	4901	4903	5234									
QTRANS	021200	4714#	4859	4909	4911	4912	4922	4923	4925	5028	5248								
QUES	033144	2910	6523#																
QWAIT	021244	4720#	4899#	4922*	5059	5065*	5165	5183*											
RANWRT	006230	2311	2400#																
RATIO	001320	1341#	1852	2309	6566														
RDCHR =	104410	4302	4627#																
RDLIN =	104411	1777	2760	4628#															
RDSEK =	000005	1163#	2385	2465	5236	5723													
RDY =	000200	1208#																	
READ =	000017	1168#	2372	3766	5242	5724													
READOR	006666	2476	2502#	3558	3645	3845													
READHD	015402	3612	3761#																
RECALT	015350	3576	3604	3627	3665	3749#													
RECALD	015354	2823	3750#																
REDAPK	011106	2792	2905#																
RELBUF	005056	2109	2184#	3565	3652														
REPAR	033451	1863	6582#																
RESREG=	104413	2207	2265	2568	2580	2795	3219	4563	4630#	4787	4819	4870	4983	5126					
		5214																	
RESVEC=	000010	1132#																	
RETRY	015472	3574	3577	3590	3663	3666	3781#												
RPADR	001216	1297#	1800	4776	4850	4976	5138	5198	6338	6542									
RPBA =	000010	1150#	4937*	6348	6351	6358	6367												
RPCA =	000012	1151#	4893*	4915*	4938*	6353	6357	6362	6367	6372									
RPCS =	000004	1148#	4802*	4869*	4875*	4887*	4895*	4909*	4917*	4931*	4944*	4998*	5000	5005*					
		5009#	5044	5048#	5061*	5074	5139*	5147	5160*	5161*	5199*	6339	6346	6350					
		6351	6355	6358	6360	6362	6364	6370											
RPDA =	000014	1152#	4894*	4916*	4939*	6353	6362	6367	6370										
RPDS =	000000	1146#	4803	4805	4807	4809	4814	4999*	5041	5043	5062	5069*	5070	5072					
		5167	5169	5171	5173	6346	6348	6351	6355	6358	6360	6362	6364	6370					
		1147#	3613	6346	6348	6351	6355	6358	6360	6362	6364	6370							
RPER =	000002	4642#	4764	5043*	5044*	6340													
RPERRS	021104	1808	4761#																
RPINIT	021314	1153#	6353	6367															
RPN1 =	000016	1154#	5203																
RPN2 =	000020	1155#																	
RPN3 =	000022	1299#	4763	4775	4833														
RPPRIO	001222	2725	5105#																
RPTMR	023360	1298#	4773	6544															
RPVEC	001220	1149#	4936*	6348	6351	6367													
RPWC =	000006	3040	3042	3044	3046#														
RPZERO	011656	3039#	3041*	3043*	3045*	3058	3065#												
RPZRC	011742	1890	6466#																
RP02	032503	1893	6467#																
RP03	032510	2272	3751	3767	4832#														
RP11	021566	1053#	1779*	1805*	1930*	1933	1935	1938	1983*	1987	2024*	2025*	2026*	2027*					
RO =	=%000000	2028#	2029*	2030*	2031*	2032*	2033*	2034*	2046*	2047	2049	2056*	2059*	2064					
		2066#	2081*	2084*	2089*	2093	2101*	2103	2122	2123	2126	2128*	2129*	2130					
		2132*	2133*	2152	2163	2165*	2166	2167*	2188	2190	2196	2197	2201	2202					
		2209	2210	2239	2241	2243	2247	2251	2252	2254	2270	2271	2272*	2275*					
		2276*	2277*	2278	2280*	2281*	2294*	2297	2301*	2303*	2312	2318*	2328*	2338*					
		2348*	2366	2369*	2370	2372	2375	2379	2381	2383*	2385*	2387*	2388*	2393*					
		2394*	2409	2413*	2430	2432	2434	2439	2441*	2443*	2444*	2445*	2446*	2447					
		2450	2452*	2453*	2454*	2460*	2461*	2462*	2463	2465*	2467*	2469*	2470*	2477*					
		2478*	2503	2509	2514	2548*	2552*	2559*	2561	2564*	2576	2577	2596	2626					

M11

	2627	2628	2629	2630	2640	2642*	2649	2651*	2658	2660*	2667	2669*	2676
	2678*	2693	2732*	2829*	2831*	2834*	2881*	2926	2946	2949	2954	2965	2974
	2977	2980	2983	2987	2991	2995	3001	3008	3017*	3021	3024	3046	3047*
	3048	3050*	3051*	3053	3055*	3056*	3061*	3083	3084*	3099	3100	3102*	3103*
	3119*	3121*	3133*	3138*	3146*	3148*	3149*	3159*	3160*	3161*	3162*	3163*	3164*
	3165*	3166	3172	3177	3180*	3181	3185	3186	3202	3207	3210	3212*	3230
	3242	3244	3253	3255	3257	3259	3268	3270	3273	3274	3275	3276	3277
	3278	3422	3428	3432	3434	3436	3438	3440	3478	3480	3483	3486	3489
	3492	3495	3498	3501	3504	3507	3545	3547	3549	3550	3554	3559*	3560*
	3561*	3562	3566*	3567*	3570*	3599	3600	3609	3611	3622	3624	3628	3629*
	3637	3646*	3647*	3648*	3649	3653*	3654*	3657*	3658	3707	3709	3711	3712
	3713	3730	3749	3751*	3763	3764	3767*	3783	3788	3790	3843	3848	3850
	3851	3852	3853	3854	3855	3856	3857	3858	3859	3905	3906*	3907	3910*
	4046	4056*	4060	4076	4077	4090*	4386	4393*	4396*	4398*	4403*	4410*	4411
	4414*	4421*	4422	4426*	4433	4437*	4459	4484*	4499	4502*	4505*	4509*	4512*
	4515	4519*	4539*	4540	4558*	4562*	4595	4596*	4597	4598*	4599*	4600*	4601*
	4836	4838*	4841	4845*	4891*	4913*	4934*	4969	4970*	5029*	5080*	5249*	5251
R1	5253*	5271	5273*	6640	6644*	6654	6659*	1977	1979	1981*	1983	1993*	2074*
	1054*	1778*	1969*	1970	1972	1974*	1976*	2116	2146	2151*	2152	2156*	2160*
	2075*	2094*	2100*	2101	2105*	2106	2112*	2191	2193*	2196*	2197*	2201*	2202*
	2162	2163*	2166*	2173	2175*	2176*	2185*	2251*	2257*	2494*	2496*	2524*	2525*
	2209*	2210*	2217	2225	2227	2229*	2230*	2625*	3076	3078	3080	3095	3097
	2526*	2534*	2535*	2536*	2615	2616*	2623*	3299	3311	3319	3363	3365*	3372*
	3101*	3125*	3177*	3189	3193	3273*	3281	3684	3685	3690*	3711*	3720*	3722*
	3382	3385	3402	3404*	3410	3417*	3684	3685	3690*	3711*	3720*	3722*	3728
	3730	3733	3841	3849*	3850*	3851*	3852*	3853*	3854*	3855*	3856*	3857*	3858*
	3859*	3861*	4047	4060*	4061	4065	4089*	4387	4392*	4397*	4415*	4418	4422*
	4431*	4432	4436*	4460	4483*	4500	4503*	4506*	4510*	4511*	4513*	4514*	4516
	4518*	4541*	4547*	4553*	4764*	4766*	4767	4770*	4771	4777*	4779*	4780*	4782*
	4784*	4801*	4802	4811*	4813*	4816	4818	4889*	4890*	4896	4897*	4898*	4899*
	4900*	4901*	4910*	4911*	4918	4919	4920*	4921*	4922*	4923*	4932*	4945	4946*
	4947*	4948*	4950*	4961	4989*	4990*	4991	4992*	4993*	4994*	4998	4999	5011
	5027	5028*	5036*	5050*	5054*	5058*	5059	5060*	5061	5064*	5065*	5066*	5067*
	5068	5069	5076	5078	5079*	5082*	5083	5086*	5089*	5096	5109*	5117*	5119
	5139	5140*	5141*	5142*	5145	5149	5154	5164*	5165	5166*	5178*	5181*	5182*
	5183*	5184*	5185	5186	5225	5228*	5234*	5248*	5252*	5265	5270*	5281*	5283*
R2	6641	6649*	6650	6651	6653*	6657	6658*	2024	2035*	2043*	2044	2046	2068
	1055*	1785	1788	2000*	2017	2019*	2021*	2177*	2186*	2194*	2199*	2211	2212*
	2073	2075	2147	2149*	2154*	2159*	2171*	2577*	2578*	2600	2604*	2605	2609*
	2220*	2224*	2231*	2252*	2258*	2561*	2562*	3132	3135*	3181*	3199*	3289*	3292
	2610	2614*	2617*	2618	3080*	3081*	3132	4048	4059*	4063*	4066	4073*	4074*
	3306*	3691	3693*	3727*	3735*	3842	3860*	4408	4435*	4461	4482*	4501	4507*
	4075	4080*	4088*	4388	4399*	4407*	4412	4435*	4461	4482*	4501	4504*	4507*
	4517*	4538*	4541	4542*	4548*	4549*	4554*	4555*	4765*	4767	4769*	4771	4835
	4836*	4837*	4842*	4876*	4878*	4879*	4888*	4893	4894	4895	4912*	4915	4916
	4933*	4936	4937	4938	4939	4940	4941	4942	4949	4964*	4966*	4995*	4997*
	5014*	5016*	5018*	5025	5031*	5032*	5033*	5034*	5035*	5059*	5085*	5088*	5091*
	5093*	5150*	5153*	5157*	5159*	5165*	5175*	5177*	5180*	5199	5200*	5210*	5226
R3	5230	5232	5236	5238	5240	5242	5244	5246*	5270	2148	2158*	2173*	2174*
	1056*	1874*	1900*	1916*	1923*	1959*	1964*	1999*	2007*	2547*	2553*	2566*	2802*
	2175	2176	2188*	2199*	2190*	2191	2256*	2260*	2262*	2930*	2933*	2935*	2939*
	2807*	2836*	2852*	2860*	2869*	2887*	2891*	2923	2928*	2930*	2933*	2935*	2939*
	3006	3010*	3013*	3016*	3117	3118*	3126*	3128*	3130*	3132*	3135	3136*	3142
	3143	3144	3145	3146	3147*	3195*	3195*	3298*	3308*	3409*	3412*	3680	3683*
	3688*	3695*	3988	3997*	4003*	4004*	4007*	4012*	4013*	4014	4023*	4049	4057*
	4058*	4072*	4075*	4084*	4085*	4087*	4297	4299*	4300	4303*	4304	4311*	4312

		4314	4322	4326	4328*	4334	4336	4338*	4341*	4389	4411*	4412*	4414	4434*
		4462	4481*	4546*	4551*	4557*	4558	4773*	4774*	4775*	5051*	5052	5055*	5110*
R4	=%000004	5111	5113*	5118	5202*	5204	5206	5207	5209	5211	5212			
		1057*	1766*	1767	1773	1786	1873*	1877	1881	1891	1902*	1917*	1922*	2001*
		2006*	2013	2023	2214*	2215*	2216*	2217	2253*	2254*	2255	2263	2546*	2549
		2551*	2557	2565*	2575*	2576*	2592	2801*	2805*	2808	2818	2822	2824	2827*
		2828*	2829	2835*	2838*	2849*	2853*	2854	2856	2857*	2858*	2859*	2862*	2874*
		2877*	2878	2880*	2881	2890*	2912	2924	2926*	2927*	2929*	2932*	2934*	2938*
		2944	2945*	2946*	2947	2948*	2949*	2958*	3007	3008*	3009*	3012*	3015*	3020*
		3021*	3022	3023*	3024*	3186*	3187*	3297	3403*	3405*	3406	3414*	3989	3991*
		3992*	3993*	3994	3995*	4009	4011*	4019*	4022*	4463	4480*	4544*	4547	4553
		4555	4776*	4802*	4803	4805	4807	4809	4814	4850*	4869*	4875*	4887*	4893*
		4894*	4895*	4909*	4915*	4916*	4917*	4931*	4936*	4937*	4938*	4939*	4944*	4976*
		4998*	4999*	5000	5005*	5009*	5041	5043	5044	5048*	5061*	5062	5069*	5070
		5072	5074	5138*	5139*	5147	5160*	5161*	5167	5169	5171	5173	5198*	5199*
		5208												
R5	=%000005	1058*	1719*	1720*	1721	1773*	1774	1785*	1788*	1960*	1961	1963*	1972	1979
		1992*	2002*	2003	2005*	2021	2022*	2061*	2062	2064*	2070*	2071	2073*	2090*
		2091	2093*	2113*	2114	2116*	2213*	2214	2216	2219*	2225*	2227*	2228*	2229
		2230	2255*	2257	2263*	2292	2307*	2309	2315*	2316*	2317*	2318	2322*	2323*
		2325*	2327*	2328	2332*	2333*	2335*	2337*	2338	2342*	2343*	2345*	2347*	2348
		2352*	2353*	2355	2357	2368*	2369	2393	2395*	2400*	2405*	2407	2411*	2413
		2418*	2420	2424*	2469	2762*	2763*	2765	2767	2769	2771*	2772	2776	2780
		2784	2790	2803	2805	2850	2853	2864	2875	2877	2925	2937*	3031	3033*
		3179*	3183*	3204*	3215	3297*	3299	3320	3364	3366*	3371*	3384	3406*	3410
		3990	3996*	3998*	4000*	4001*	4002*	4003	4021*	4050	4052*	4054*	4061*	4065*
		4080	4086*	4464	4479*	4545*	4549	4556	5203*	5204				
R6	=%000006	1059*	1061	1674*	1675*	1676								
R7	=%000007	1060*	1062											
SAVEFG	021132	1809*	4704*	5002	5094									
SAVER1	013144	3285*	3319*	3344*	3361	3365	3369*							
SAVERS	013146	3286*	3320*	3345*	3366	3370*								
SAVREG=	104412	2184	2233	2545	2573	2747	3156	4537	4629*	4761	4800	4849	4975	5108
		5197												
SC	023034	4981	5041*											
SCMND	010772	2782	2874*											
SC0	023076	5007	5015	5017	5019	5042	5050*	5124						
SC1	023104	5052*	5056											
SC2	023112	5054*	5063	5084	5095	5098								
SC3	023122	5053	5058*											
SOETAL	007306	2563	2579	2592*										
SECOND	010140	1727*	2688	2698*	2699	2701*	2702*	2703	2705*	2739*				
SEC.ER	001272	1320*	3847*	6364										
SEEK =	000011	1165*	4917	5230										
SEEKNT	021126	4684*	4919*	5076	5083*	5096*	5186*							
SEKMOD	001316	1340*	2972	6564										
SETVEC	003302	1853	1869*											
SHDTYP	007270	2556	2574	2585*										
SILO =	000026	1157*	5212											
SIXTEE	010144	1723*	1724*	2694*	2696*	2697*	2743*							
SIZMEM	002370	1734*	1737*	1738*										
SKIER	014424	3491	3599*											
SP	=%000006	1061*	1678*	1688*	1696*	1700	1774*	1778	1790*	1795*	1823*	1830*	1834*	1838*
		1842*	1846*	1850*	1854*	1859	1877*	1967*	2013*	2054*	2056	2082*	2084	2106*
		2112	2146*	2147*	2148*	2158	2159	2160	2162*	2211*	2222	2224	2270*	2275
		2292*	2357*	2358*	2359*	2361	2363*	2374*	2375*	2376*	2377	2386*	2395	2458

2475*	2477	2478	2489*	2502*	2503*	2504*	2505*	2507*	2508*	2509*	2510*	2512*
2514*	2530*	2539*	2542*	2596*	2600*	2605*	2610*	2615*	2618*	2625	2626*	2627*
2628*	2629*	2630*	2693*	2724*	2732	2748*	2749*	2750*	2751*	2752	2756*	2762
2816*	2840*	2912*	2923*	2924*	2925*	2937	2938	2939	2944*	2954*	2958	2987*
2995*	3001*	3006*	3007*	3015	3016	3029*	3030*	3031*	3033	3034	3046*	3047
3057	3061	3062*	3117*	3147	3189*	3193*	3248*	3253*	3254*	3255*	3256	3257
3263*	3363*	3364*	3371	3372	3396*	3402*	3404	3416*	3417	3549*	3550*	3551
3557*	3559	3560	3568*	3570	3609*	3610*	3611*	3644*	3646	3647	3655*	3657
3680*	3695	3712*	3713*	3714*	3715*	3717	3719*	3720	3723*	3728*	3733*	3761
3762	3772*	3773	3795*	3798	3815	3816*	3818*	3841*	3842*	3844*	3846	3847
3860	3861	3869	3905*	3906	3907*	3909	3910	3911*	3913	3915	3917	3923
3925*	3927*	3935*	3939	3943	3944	3948	3980*	3981	3982	3983*	3988*	3989*
3990*	3996	4021	4022	4023	4024*	4025*	4046*	4047*	4048*	4049*	4050*	4051*
4052	4055*	4068	4070*	4072	4082	4084	4086	4087	4088	4089	4090	4092*
4093*	4136*	4137*	4138	4142	4144	4153	4155	4158	4161*	4162*	4163	4168
4170	4172*	4173	4189*	4190*	4191	4201	4208*	4211*	4212*	4216*	4217*	4219
4222*	4229	4232*	4236	4238	4240	4241*	4248	4250	4252*	4253	4255*	4256*
4257*	4258*	4259*	4274*	4275*	4276*	4277*	4278*	4284*	4297*	4298*	4303	4306
4310*	4317	4321*	4340	4341	4342*	4343*	4344*	4385*	4386*	4387*	4388*	4389*
4390*	4391*	4392	4393	4395*	4399	4402*	4405*	4416*	4420*	4423	4424	4427*
4428*	4429	4432*	4433*	4434	4435	4436	4437	4438*	4459*	4460*	4461*	4462*
4463*	4464*	4465*	4466*	4467*	4468*	4475*	4476*	4477*	4478*	4479	4480	4481
4482	4483	4484	4499*	4500*	4501*	4517	4518	4519	4538	4540*	4595*	4596
4606*	4607*	4762*	4786	4832*	4835*	4842	4844	4940*	4941*	4942*	4943*	4944
5027*	5036	5078*	5082	5113	5128*	5208*	5209*	5210	5225*	5252	5264*	5267*
5272	6640*	6641*	6642*	6643*	6644	6647	6654*	6655	6656	6658	6659	
1776	1887	2613	2622	6465#								
2599	2603	2608	3197	3206	3217	3732	6464#					
2595	6463#											
1880	1896	6462#										
1036#	1309	1678	1790	1795								
1309#												
1241	1668#	1942										
1242	1670#											
2587	6487#											
1310#	1717*	1950	1954*	2731*								
2107	2122#											
1955	2545#	2894										
1047#												
2255	2263	3406	3414	5735#								
5115	5138#											
5144	5164#											
5168	5177#											
5172	5180#											
5176	5179	5182#										
5146	5148	5163	5170	5174	5188#							
1156#												
1176#	3242	4803	5070	5167								
1181#	4805	5072	5171									
1182#	4809	5173										
1180#	4814											
1178#	3242	3489	4807	5169								
1177#	5062											
1175#												
4877	4967	5004	5008	5097	5151	5187	5197#					
1270#	1676	1690*	1692	1698*	1711	1871	1952	2295	2305	2437	2456	2754

SPACE1 032501
SPACE2 032500
SPACE3 032477
SPACE4 032476
STACK = 001100
STACK1 001246
START 002016
START1 002024
STATHD 032646
STATIN 001250
STATIS 004626
STATPR 007126
STKLMT= 177774
STNDAT 025764
STO 023472
STO1 023636
STO2 023716
STO3 023734
STO4 023746
STO5 023776
SUCA = 000024
SUFU = 001000
SUOL = 040000
SUDY = 100000
SURPO3= 020000
SUSI = 004000
SUSU = 002000
SUMP = 000400
SVRP11 024000
SMR 001140

.SCHTA	18	10038	1243
.SD82D	18	10038	4524
.SD820	18		
.SDIV	18	10038	4358
.SEOP	18		
.SERRO	18	10038	3826
.SERRT	18	10038	
.SHULT	18		
.SPOWE	18		
.SRAND	18	10038	4487
.SRDDE	18		
.SRDOC	18		
.SREAD	18	10038	4101
.SR2AZ	18		
.SSAVE	18	10038	4441
.SS82D	18		
.SS820	18		
.SSCOP	18		
.SSIZE	18	10038	6632
.SSUPR	18		
.STRAP	18	10038	4587
.STYP8	18		
.STYPD	18	10038	4033
.STYPE	18	10038	3884
.STYPO	18	10038	3955
.S4OCA	18		
.1170	18		

ADC	2129	2133	2277	2281	4510	4513	4554								
ADD	1963	1974	1981	2005	2019	2035	2075	2128	2132	2156	2166	2174	2190	2193	2210
	2216	2219	2225	2228	2276	2280	2317	2327	2337	2347	2363	2376	2386	2496	2530
	2539	2552	2559	2562	2564	2578	2604	2609	2614	2617	2840	2927	2932	3009	3058
	3132	3146	3165	3212	3248	3255	3263	3275	3396	3414	3416	3690	3691	3713	3723
	3795	3911	3983	3993	4065	4222	4232	4241	4412	4509	4511	4512	4514	4553	4555
	5209	5283													
ASL	2165	2189	2215	2424	2827	2857	2880	2948	3023	3126	3128	3130	3162	3163	3164
	3254	3719	4255	4256	4257	4505	4599	4897	4920	4946	4992	5058	5064	5140	5164
	5182														
ASLB	2030	4070	5055												
ASR	2125	2167	2835	2859	3616	3617	3618	3619	3620	3621	4900	4948	4994	5060	5067
	5142	5166	5184												
BCC	4071	4413													
BOS	3127	3129	3131	3188											
BEQ	1760	1768	1806	1813	1870	1882	1892	1901	1915	1919	1951	1971	1973	1978	1980
	2018	2045	2050	2057	2067	2102	2104	2124	2127	2131	2150	2155	2164	2170	2172
	2187	2192	2218	2240	2259	2279	2296	2300	2324	2334	2344	2356	2371	2380	2404
	2410	2495	2717	2727	2766	2804	2825	2833	2837	2851	2855	2861	2865	2876	2879
	3096	3167	3173	3178	3182	3196	3203	3245	3260	3269	3302	3304	3307	3312	3323
	3362	3377	3381	3393	3407	3423	3429	3479	3484	3487	3490	3493	3496	3499	3502
	3505	3508	3546	3555	3623	3638	3697	3704	3708	3710	3718	3726	3731	3741	3755
	3771	3784	3789	3791	3863	3866	3914	3949	4010	4147	4200	4239	4254	4282	4318
	4430	4806	4854	4857	4860	4863	4868	4978	5024	5047	5073	5077	5095	5144	5172
	5201	5231	5237	5239	5241	5243	5245	5266	5282						
BGE	4425														
BGT	2310	4017	4079	4171	4251	4401	4962	5012	5114	5120	5155	5268			
BHI	1820	2449	2768	2966	2975	2981	3079	3288							
BHIS	1747	1826	1829	1833	1837	1841	1845	1849	1853	2205	2244	2248	2362	2378	2641
	2650	2659	2668	2677	2978	3552	3564	3651							
BIC	2316	2368	2405	2445	2504	2751	3081	3610	4007	4137	4162	4172	4190	4217	4252
	4385	4780	5005												
BICB	2771	2856	2947	3022	4816	4991	5068	5083	5096	5149	5185	5186			
BIS	4012	4013	4073	4074	4259	4402	4420	4557	4943	5018	5085	5088	5091	5093	5157
	5159														
BISB	2023	4818	4896	4918	4919	4941	4942	4945							
BIT	1871	1952	2295	2305	2437	2439	2456	2786	2963	2989	3157	3235	3242	3303	3380
	3422	3428	3432	3434	3436	3438	3440	3483	3486	3489	3492	3495	3498	3501	3504
	3507	3613	3637	3696	3703	3705	3709	3725	3740	3788	3790	3865	3872	4803	4805
	4807	4809	4814	5052	5062	5070	5072	5074	5167	5169	5171	5173	5226		
BITB	1891	2126	2239	2366	2379	2381	2409	2549	2557	2808	2818	2854	2878	3270	3547
	3937	5025	5076												
BLE	3200	3328	5213												
BLO	2448	2770	2976	2982	2984	2992	3077	3331	3335	4313					
BLOS	1757	1822	2153	2451	4301	4768	4772								
BLT	3928	4018	4062	4078	4169	4249	4400	4550	4963	5112	5156				
BMI	1883	2435	2464	2826	3785	4069	5001	5013	5148						
BNE	1677	1693	1710	1712	1722	1735	1749	1754	1816	1872	1921	1931	1934	1936	1953
	1962	1965	1967	2004	2008	2042	2048	2063	2072	2085	2092	2115	2178	2195	2221
	2232	2242	2261	2298	2306	2313	2367	2373	2382	2408	2421	2431	2433	2438	2440
	2457	2550	2554	2558	2567	2624	2685	2695	2700	2704	2709	2713	2719	2729	2753
	2755	2773	2777	2781	2785	2787	2791	2809	2819	2821	2889	2892	2931	2936	2964
	2973	2990	3014	3049	3054	3098	3158	3205	3211	3216	3236	3243	3258	3271	3300
	3309	3317	3357	3379	3411	3413	3433	3435	3437	3439	3441	3481	3548	3614	3659
	3689	3706	3736	3794	3873	3908	3916	3924	3938	3945	4008	4067	4139	4145	4151
	4156	4164	4176	4186	4192	4220	4224	4230	4237	4244	4287	4305	4307	4323	4327

	4337	4417	4508	4561	4781	4804	4808	4810	4815	4852	4866	4882	4904	4926	4953
	4955	5026	5042	5053	5056	5063	5071	5075	5106	5123	5146	5168	5170	5174	5205
	5227	5233													
BPL	2506	2511	3231	3878	3902	3942	4006	4053	4083	4160	4188	4214	4394	4419	4785
	5003														
BR	1669	1695	1714	1751	1769	1787	1789	1792	1802	1885	1888	1903	1975	1982	1995
	2009	2020	2036	2052	2065	2069	2077	2096	2157	2168	2179	2200	2223	2233	2246
	2250	2264	2365	2384	2406	2423	2436	2466	2497	2513	2529	2538	2555	2560	2722
	2757	2775	2779	2783	2789	2793	2839	2841	2843	2863	2870	2883	2886	2893	2979
	2999	3018	3040	3042	3044	3052	3082	3120	3134	3191	3198	3213	3218	3290	3294
	3296	3310	3315	3321	3325	3415	3553	3575	3578	3581	3585	3591	3593	3630	3640
	3664	3667	3671	3721	3738	3787	3904	3921	3931	3940	3947	3984	3999	4020	4064
	4081	4154	4233	4260	4262	4316	4325	4331	4333	4404	4406	4409	4552	4812	4817
	4839	4892	4914	4935	4965	4968	4980	5007	5015	5017	5019	5030	5084	5087	5090
	5092	5098	5116	5121	5158	5163	5176	5179	5229	5235	5247	5250	5269	5284	6652
CLC	1744	4408													
CLR	1668	1675	1706	1717	1720	1729	1730	1791	1793	1794	1818	1873	1910	1917	1954
	1992	1993	2000	2001	2002	2022	2043	2054	2059	2082	2089	2253	2358	2374	2411
	2502	2508	2521	2523	2533	2546	2575	2800	2801	2849	2874	2929	2934	2945	3012
	3020	3030	3045	3118	3136	3159	3179	3284	3285	3286	3332	3336	3369	3370	3568
	3629	3655	3693	3714	3997	4056	4059	4120	4157	4203	4211	4212	4276	4277	4298
	4321	4390	4421	4546	4766	4777	4783	4837	4889	4910	4989	4996	5031	5050	5065
	5109	5110	5162	5183	5202										
CLRB	1718	1728	2730	3283	3318	3781	3920	3946	4085	4328	4338	4427	4562	4811	4843
	4984	5089	5127	5181											
CMP	1676	1692	1711	1721	1746	1756	1819	1821	1825	1828	1832	1836	1840	1844	1848
	1852	1933	1935	1972	1979	2047	2130	2152	2191	2204	2217	2243	2247	2278	2309
	2361	2377	2407	2447	2640	2649	2658	2667	2676	2716	2752	2754	2965	2974	2977
	2980	2983	2991	3257	3287	3299	3330	3334	3410	3478	3480	3551	3554	3562	3622
	3649	3730	4077	4138	4144	4146	4150	4155	4163	4168	4170	4175	4185	4191	4219
	4229	4236	4248	4250	4286	4300	4312	4556	4767	4771	5119	5204	5212		
CMPB	1920	2241	2297	2312	2370	2372	2450	2699	2703	2708	2712	2718	2728	2765	2767
	2769	2772	2776	2780	2784	2790	2803	2850	2864	2875	3048	3076	3078	3097	3268
	3545	3658	3707	3793	3913	3915	3923	3944	3948	4199	4223	4243	4304	4322	4326
	4336	5145	5230	5232	5236	5238	5240	5242	5244						
COM	3183	3204													
DEC	1900	1964	2007	2066	2154	2169	2171	2177	2194	2220	2226	2231	2258	2260	2553
	2566	2623	2836	2860	2891	2930	3013	3055	3161	3195	3199	3306	3308	3378	3412
	3688	3735	4283	4311	4416	4428	4559	4784	5267						
DECB	2505	2510	3927	3930	4005	4016	4395								
EMT	1037														
HALT	1222	2245	2249	2274	3698	3742	3753	3769	3879	3903					
INC	1734	1869	1902	1922	2006	2198	2199	2203	2325	2335	2345	2353	2551	2565	2642
	2651	2660	2669	2678	2694	2763	2838	2862	2890	3017	3051	3101	3125	3280	3329
	3333	3337	3368	3374	3868	4011	4019	4063	4167	4174	4258	4285	4405	4507	4551
	4779	5054	5117												
INCB	2698	2702	2706	2707	2711	2715	2721	3786	3792	3862	3950				
IOT	1038														
JMP	1241	1242	1807	1824	1831	1835	1839	1843	1847	1851	1855	1864	1926	1932	1942
	1968	2086	2118	2302	2314	2459	2490	2759	2811	2814	2817	2900	2906	2967	3232
	3338	3424	3449	3460	3466	3474	3482	3485	3488	3491	3494	3497	3500	3503	3506
	3509	4143	4226												
JSR	1707	1736	1779	1808	1905	1907	1924	1938	1955	1985	1991	1994	2011	2051	2053
	2055	2058	2060	2076	2083	2087	2088	2095	2107	2108	2109	2110	2111	2117	2272
	2293	2304	2308	2311	2326	2336	2346	2354	2360	2364	2392	2401	2419	2422	2429
	2442	2455	2468	2476	2556	2563	2574	2579	2586	2597	2598	2601	2602	2606	2607

NOV

2611	2612	2620	2621	2631	2632	2725	2774	2778	2782	2788	2792	2810	2813	2823
2830	2867	2882	2885	2894	3005	3032	3119	3121	3133	3138	3169	3233	3234	3237
3247	3262	3293	3295	3305	3314	3324	3326	3359	3367	3373	3387	3395	3431	3448
3459	3465	3471	3473	3516	3522	3528	3534	3540	3558	3565	3569	3573	3574	3576
3577	3580	3583	3584	3587	3590	3602	3603	3604	3612	3626	3627	3632	3642	3643
3645	3652	3656	3660	3663	3665	3666	3669	3670	3673	3674	3682	3687	3716	3751
3767	3782	3817	3845	3874	3922	3929	3936	4141	4202	4247	4778	4838	4840	4855
4858	4861	4864	4877	4880	4891	4902	4913	4924	4934	4951	4960	4967	4979	4981
4982	5004	5006	5008	5010	5029	5080	5097	5115	5124	5125	5151	5152	5187	5249
1670	1674	1678	1680	1681	1682	1683	1684	1685	1688	1689	1690	1691	1696	1698
1699	1700	1702	1703	1705	1719	1723	1725	1726	1727	1737	1738	1739	1740	1741
1742	1755	1758	1764	1766	1767	1773	1774	1778	1785	1788	1790	1795	1799	1801
1803	1805	1809	1810	1814	1817	1823	1827	1830	1834	1838	1842	1846	1850	1854
1859	1874	1877	1884	1886	1887	1889	1890	1893	1906	1908	1909	1916	1923	1930
1959	1960	1969	1976	1983	1999	2013	2021	2024	2027	2031	2032	2034	2046	2056
2061	2064	2070	2073	2074	2081	2084	2090	2093	2094	2100	2101	2106	2112	2113
2116	2122	2146	2147	2148	2149	2151	2158	2159	2160	2162	2173	2175	2176	2185
2186	2188	2196	2197	2201	2202	2209	2211	2212	2213	2224	2227	2227	2229	2230
2251	2252	2255	2257	2257	2262	2263	2270	2271	2275	2292	2294	2307	2315	2322
2332	2342	2348	2352	2357	2359	2369	2387	2394	2395	2400	2418	2443	2444	2446
2454	2460	2461	2470	2489	2494	2507	2512	2519	2520	2524	2525	2526	2527	2528
2531	2534	2535	2536	2537	2540	2547	2548	2561	2577	2592	2596	2600	2605	2610
2615	2616	2618	2625	2626	2693	2696	2723	2724	2731	2732	2748	2749	2750	2756
2758	2761	2762	2802	2806	2807	2816	2828	2829	2831	2842	2844	2852	2858	2866
2869	2881	2884	2887	2899	2905	2912	2923	2924	2925	2926	2928	2933	2937	2938
2939	2944	2949	2958	2987	3006	3007	3000	3010	3015	3016	3024	3029	3031	3033
3039	3041	3043	3046	3047	3057	3061	3062	3102	3117	3135	3147	3148	3166	3172
3177	3180	3181	3189	3193	3207	3253	3256	3273	3274	3276	3279	3281	3289	3291
3297	3298	3319	3320	3363	3364	3365	3366	3371	3372	3382	3384	3385	3402	3403
3404	3406	3409	3417	3430	3472	3549	3561	3566	3567	3570	3571	3588	3599	3600
3615	3624	3628	3648	3653	3654	3657	3661	3680	3683	3684	3685	3695	3711	3712
3715	3727	3728	3733	3764	3765	3772	3815	3816	3818	3841	3842	3848	3849	3850
3851	3852	3853	3854	3855	3856	3857	3858	3859	3860	3861	3864	3869	3905	3906
3910	3925	3980	3988	3989	3990	3996	4003	4021	4022	4023	4024	4025	4046	4047
4048	4049	4050	4051	4052	4057	4060	4080	4086	4087	4088	4089	4090	4092	4093
4121	4122	4123	4124	4126	4165	4177	4208	4225	4240	4245	4274	4275	4278	4288
4297	4299	4310	4341	4342	4343	4344	4386	4387	4388	4389	4391	4392	4393	4399
4403	4411	4414	4422	4432	4433	4434	4435	4436	4437	4438	4459	4460	4461	4462
4463	4464	4465	4466	4467	4468	4475	4476	4477	4478	4479	4480	4481	4482	4483
4484	4499	4500	4501	4502	4503	4504	4515	4516	4517	4518	4519	4538	4539	4540
4541	4542	4543	4544	4545	4595	4596	4600	4606	4607	4762	4763	4764	4765	4769
4770	4773	4774	4775	4776	4782	4786	4832	4833	4835	4836	4842	4844	4850	4876
4878	4879	4888	4893	4894	4898	4899	4901	4912	4915	4916	4921	4922	4923	4933
4936	4937	4938	4939	4940	4944	4947	4949	4950	4964	4966	4976	4993	4995	4997
5009	5014	5016	5027	5028	5033	5034	5036	5043	5044	5051	5059	5066	5078	5079
5082	5128	5138	5141	5150	5153	5165	5175	5177	5180	5198	5200	5203	5208	5210
5225	5228	5234	5246	5248	5252	5264	5270	5281	6640	6641	6642	6643	6644	6647
6648	6649	6654	6655	6656	6657	6658	6659							
1715	1987	2025	2026	2028	2029	2254	2301	2303	2318	2328	2338	2375	2383	2385
2393	2413	2441	2452	2453	2465	2467	2469	2477	2478	2503	2509	2514	2576	2701
2705	2710	2714	2720	2805	2822	2834	2853	2877	2946	2954	2995	3001	3021	3050
3056	3080	3160	3185	3186	3277	3278	3282	3313	3358	3360	3386	3559	3560	3572
3589	3609	3611	3646	3647	3662	3681	3686	3694	3749	3750	3761	3762	3763	3766
3843	3846	3847	3871	3907	3935	3943	3981	3982	3985	3986	3987	3991	3994	3995
4014	4055	4058	4072	4075	4084	4136	4161	4173	4189	4204	4216	4284	4303	4308
4314	4319	4334	4558	4598	4801	4802	4813	4834	4869	4875	4887	4890	4895	4909

NOVB

	4911	4917	4931	4932	4974	4990	4998	4999	5032	5035	5048	5061	5069	5086	5107
NEG	5139	5160	5161	5178	5199										
NOP	1724	2033	2388	2462	2697	3992	4054	4396	4397	4407	4426	4431			
RESET	1939	1940	1941	2206	5081										
ROL	1671	1937													
ROR	3998	4000	4001	4002	4004	4410	4415	4506							
RTI	1745	3187													
	1697	2733	2796	3882	3912	4026	4094	4166	4178	4246	4279	4289	4345	4439	4469
	4485	4608	4985												
RTS	2134	2161	2208	2266	2282	2396	2414	2425	2471	2479	2498	2515	2541	2569	2581
	2588	2634	2643	2652	2661	2670	2679	2689	2812	2815	2845	2868	2895	2918	2940
	2959	2968	3025	3035	3063	3084	3103	3149	3220	3238	3249	3264	3272	3339	3375
	3388	3397	3418	3443	3454	3511	3517	3523	3529	3535	3541	3595	3605	3633	3675
	3699	3743	3756	3774	3796	3799	3819	3952	4127	4520	4564	4601	4788	4820	4845
	4871	4883	4905	4927	4956	4970	5037	5049	5057	5129	5188	5215	5253	5273	5285
	6660														
SBC	4398	4548													
SUB	1743	1750	1752	2105	2123	2163	2323	2333	2343	2475	2627	2628	2629	2630	2935
	3292	3383	3405	3550	3557	3644	3720	3722	3844	3870	4061	4547	4549	5113	6653
TRAP	4384	4610	4619	4620	4621	4622	4624	4626	4627	4628	4629	4630	6646		
TST	1709	1753	1759	1786	1800	1811	1815	1914	1950	1961	1966	1970	1977	2003	2017
	2041	2044	2062	2068	2071	2091	2103	2114	2222	2299	2355	2402	2420	2430	2432
	2458	2522	2532	2684	2820	2832	2972	3034	3083	3099	3100	3142	3143	3144	3145
	3202	3210	3215	3230	3244	3259	3301	3311	3327	3361	3376	3392	3717	3754	3770
	3773	3783	3798	3877	3909	3917	3939	4009	4066	4076	4125	4142	4153	4158	4201
	4238	4253	4281	4306	4317	4340	4418	4423	4424	4429	4597	4841	4851	4853	4856
	4859	4862	4865	4881	4903	4925	4952	4954	4969	4977	5000	5002	5023	5046	5094
TSTB	5105	5111	5118	5122	5143	5206	5207	5211	5251	5265	5271	5272	6650	6651	
	1748	1881	1918	2049	2434	2463	2726	2824	2888	3053	3095	3316	3322	3356	3901
	3941	4068	4082	4159	4187	4213	4867	4961	5011	5041	5147	5154			
.ASCII	1293	1294	6197	6209	6226	6255	6451	6462	6463	6464	6487	6492	6619		
.ASCIZ	1292	1295	4349	4350	4351	4352	4354	6032	6039	6044	6051	6059	6064	6073	6082
	6090	6096	6100	6104	6108	6113	6117	6123	6126	6133	6141	6145	6155	6166	6172
	6179	6185	6190	6191	6194	6200	6206	6213	6217	6221	6230	6240	6248	6259	6267
	6270	6277	6292	6290	6299	6308	6310	6312	6320	6328	6331	6459	6465	6466	6467
	6468	6470	6472	6474	6478	6482	6484	6498	6503	6508	6511	6514	6517	6521	6523
	6524	6527	6530	6573	6577	6582	6588	6590	6592	6594	6595	6596	6597	6598	6599
	6600	6602	6604	6606	6608	6610	6623								
.BLKB	4108	4348	4585												
.BLKW	4099	5658													
.BYTE	1252	1253	1258	1259	1267	1268	1276	1277	1278	1279	1879	1989	2015	2594	2735
	2736	2737	2738	2739	2740	2914	2956	2997	3003	3341	3342	3801	4027	4028	4029
	4030	4346	4347	4656	4657	4658	4659	4660	4661	4662	4663	4690	4696	4741	4742
	4743	4744	4745	4746	4747	4748	5334	5374	5414	5454	5494	5534	5574	5614	5720
	5721	5722	5723	5724	6376	6377	6381	6382	6385	6386	6388	6389	6392	6393	6395
	6396	6399	6400	6403	6404	6407	6408	6411	6412	6415	6416	6418	6419	6422	6423
	6425	6426	6429	6430	6433	6434	6437	6438	6440	6441	6444	6445	6447	6448	
.DSABL	4263														
.ENABL	1	1003	4104												
.END	6663														
.ENDC	1009	1020	1021	1037	1129	1143	1225	1229	1233	1235	1246	1250	1252	1280	1292
	1293	1297	1323	1327	1354	1358	1370	1374	1383	1659	1660	1667	1678	1679	1680
	1682	1684	1686	1702	1711	1717	1945	1949	2139	2143	2285	2289	2482	2486	3223
	3227	3823	3829	3832	3862	3869	3874	3875	3876	3877	3882	3883	3887	3907	3958
	4036	4104	4135	4144	4148	4179	4181	4196	4227	4263	4267	4278	4290	4291	4299
	4301	4304	4332	4349	4350	4356	4361	4385	4444	4490	4527	4590	4596	4599	4618

CROSS REFERENCE TABLE -- PERMANENT SYMBOLS

.EQUIV	4619	4620	4621	4622	4623	4624	4625	4626	4627	4628	4629	4630	4631	4633	4637
.EVEN	5288	5292	5661	5665	5730	5734	6027	6031	6635	6648	6662	1097	1098	1099	1100
.IF	1037	1038	1046	1061	1062	1091	1092	1093	1094	1095	1096				
.IFF	1119	1120	1121	1122	1123	1124	1125	1126	1127	1128					
.IFT	2741	4110	4356	5727	6336	6539	6613	6630		1231	1233	1245	1249	1251	1280
.IFTF	1005	1020	1021	1035	1101	1129	1225	1228	1231	1233	1245	1249	1251	1280	1292
.IIF	1296	1297	1322	1326	1353	1357	1369	1373	1659	1666	1673	1678	1680	1682	1684
.IRP	1686	1702	1708	1711	1944	1948	2138	2142	2284	2288	2481	2485	3222	3226	3822
.LIST	3828	3831	3841	3865	3872	3874	3875	3877	3881	3882	3883	3886	3907	3957	4035
.MACRO	4103	4105	4133	4138	4144	4180	4181	4195	4219	4266	4267	4277	4290	4298	4300
.MCALL	4304	4305	4348	4349	4356	4360	4385	4443	4489	4526	4589	4595	4599	4610	4619
.MLIST	4620	4621	4622	4623	4624	4626	4627	4628	4629	4630	4631	4632	4636	5287	5291
.PAGE	5660	5664	5729	5733	6026	6030	6634	6638	6647	6648					
.REPT	1020	1021	1035	1229	1233	1246	1249	1251	1280	1297	1323	1327	1354	1358	1370
.SBTTL	1374	1660	1667	1678	1945	1949	2139	2143	2285	2289	2482	2486	3223	3227	3823
.TITLE	3829	3831	3865	3881	3882	3883	3887	3958	4036	4104	4181	4196	4206	4267	4270
.WORD	4278	4290	4291	4300	4332	4348	4361	4444	4490	4527	4590	4596	4633	4637	5288
	5292	5661	5665	5730	5734	6027	6031	6635	6638	6648					
	3875	4269	4274	6642	6648	6658	6662								
	3874	4206	4267	4270	6639	6642	6654	6658							
	1004	1009	1014	1018	1019	1020	1021	1022	1023	1024	1025	1026	1027	1029	1030
	1031	1222	1296	1679	1686	3190	3194	3832	3833	3834	3835	3836	3840	3880	3882
	3883	3954	4104	4110	4149	4150	4209	4340	4349	4356	4618	4619	4620	4621	4622
	4624	4626	4627	4628	4629	4630									
	1297	1659	2600	2610	2627	2923	2937	3363	3371	3841	3850	4046	4086	4386	4434
	4459	4479	4499	4517	5331	5711									
	1	1003	1143	1222	1280	1282	1283	1284	1285	1286	1287	1288	1289	1290	1291
	1292	1659	1686	2635	3882	4290	4610	4618	4619	4620	4621	4622	4623	4624	4625
	4626	4627	4628	4629	4630	4631	6632								
	1	1003	1021	1243	2635	4610									
	1003	1143	1686												
	1	1003	1143	1222	1280	1282	1283	1284	1285	1286	1287	1288	1289	1290	1291
	1292	1659	1686	2635	3882	4290	4610	4618	4619	4620	4621	4622	4623	4624	4625
	4626	4627	4628	4629	4630	4631	6632								
	1243	1383													
	1222	1282	3616	5335	5341	5375	5381	5415	5421	5455	5461	5495	5501	5535	5541
	5575	5581	5615	5621	5689	5755	5891								
	1014	1033	1216	1226	1237	1243	1324	1355	1371	1383	1661	1672	1708	1946	2140
	2286	2483	3224	3824	3826	3884	3955	4033	4101	4358	4441	4487	4524	4587	4610
	4634	5289	5662	5731	6028	6632									
	1004														
	1222	1223	1224	1234	1251	1254	1255	1256	1257	1260	1261	1262	1263	1264	1265
	1266	1269	1270	1271	1280	1282	1283	1284	1285	1286	1287	1288	1289	1290	1291
	1297	1298	1299	1300	1301	1302	1303	1304	1305	1306	1307	1308	1309	1310	1311
	1312	1313	1315	1316	1317	1318	1319	1320	1328	1329	1330	1331	1332	1333	1336
	1337	1339	1340	1341	1350	1359	1363	1364	1365	1366	1367	1375	1376	1378	1772
	1862	1895	1898	2136	2743	2916	3060	3065	3171	3176	3209	3344	3345	3346	3347
	3348	3349	3350	3351	3352	3802	3820	3951	4031	4105	4106	4107	4521	4522	4560
	4617	4642	4643	4649	4670	4676	4684	4704	4708	4711	4714	4717	4720	4728	4729
	4730	4731	4732	4733	4734	4735	5335	5336	5337	5338	5339	5340	5341	5342	5343
	5344	5345	5346	5347	5348	5349	5350	5351	5352	5353	5354	5355	5356	5357	5358
	5359	5360	5361	5362	5363	5364	5365	5366	5367	5368	5369	5370	5375	5376	5377
	5378	5379	5380	5381	5382	5383	5384	5385	5386	5387	5388	5389	5390	5391	5392
	5393	5394	5395	5396	5397	5398	5399	5400	5401	5402	5403	5404	5405	5406	5407
	5408	5409	5410	5415	5416	5417	5418	5419	5420	5421	5422	5423	5424	5425	5426

CROSS REFERENCE TABLE -- PERMANENT SYMBOLS

5427	5428	5429	5430	5431	5432	5433	5434	5435	5436	5437	5438	5439	5440	5441
5442	5443	5444	5445	5446	5447	5448	5449	5450	5455	5456	5457	5458	5459	5460
5461	5462	5463	5464	5465	5466	5467	5468	5469	5470	5471	5472	5473	5474	5475
5476	5477	5478	5479	5480	5481	5482	5483	5484	5485	5486	5487	5488	5489	5490
5495	5496	5497	5498	5499	5500	5501	5502	5503	5504	5505	5506	5507	5508	5509
5510	5511	5512	5513	5514	5515	5516	5517	5518	5519	5520	5521	5522	5523	5524
5525	5526	5527	5528	5529	5530	5535	5536	5537	5538	5539	5540	5541	5542	5543
5544	5545	5546	5547	5548	5549	5550	5551	5552	5553	5554	5555	5556	5557	5558
5559	5560	5561	5562	5563	5564	5565	5566	5567	5568	5569	5570	5575	5576	5577
5578	5579	5580	5581	5582	5583	5584	5585	5586	5587	5588	5589	5590	5591	5592
5593	5594	5595	5596	5597	5598	5599	5600	5601	5602	5603	5604	5605	5606	5607
5608	5609	5610	5615	5616	5617	5618	5619	5620	5621	5622	5623	5624	5625	5626
5627	5628	5629	5630	5631	5632	5633	5634	5635	5636	5637	5638	5639	5640	5641
5642	5643	5644	5645	5646	5647	5648	5649	5650	5654	5656	5666	5668	5672	5676
5680	5684	5688	5689	5690	5691	5692	5693	5694	5695	5696	5697	5698	5699	5700
5701	5702	5703	5704	5705	5706	5707	5708	5711	5712	5713	5714	5715	5716	5717
5718	5735	5736	5737	5738	5739	5740	5741	5742	5743	5744	5745	5746	5747	5748
5749	5750	5751	5752	5754	5755	5756	5757	5758	5759	5760	5761	5762	5763	5764
5765	5766	5767	5768	5769	5771	5772	5773	5774	5775	5776	5777	5778	5779	5780
5781	5782	5783	5784	5785	5786	5788	5789	5790	5791	5792	5793	5794	5795	5796
5797	5798	5799	5800	5801	5802	5803	5805	5806	5807	5808	5809	5810	5811	5812
5813	5814	5815	5816	5817	5818	5819	5820	5822	5823	5824	5825	5826	5827	5828
5829	5830	5831	5832	5833	5834	5835	5836	5837	5839	5840	5841	5842	5843	5844
5845	5846	5847	5848	5849	5850	5851	5852	5853	5854	5856	5857	5858	5859	5860
5861	5862	5863	5864	5865	5866	5867	5868	5869	5870	5871	5873	5874	5875	5876
5877	5878	5879	5880	5881	5882	5883	5884	5885	5886	5887	5888	5890	5891	5892
5893	5894	5895	5896	5897	5898	5899	5900	5901	5902	5903	5904	5905	5907	5908
5909	5910	5911	5912	5913	5914	5915	5916	5917	5918	5919	5920	5921	5922	5924
5925	5926	5927	5928	5929	5930	5931	5932	5933	5934	5935	5936	5937	5938	5939
5941	5942	5943	5944	5945	5946	5947	5948	5949	5950	5951	5952	5953	5954	5955
5956	5958	5959	5960	5961	5962	5963	5964	5965	5966	5967	5968	5969	5970	5971
5972	5973	5975	5976	5977	5978	5979	5980	5981	5982	5983	5984	5985	5986	5987
5988	5989	5990	5992	5993	5994	5995	5996	5997	5998	5999	6000	6001	6002	6003
6004	6005	6006	6007	6009	6010	6011	6012	6013	6014	6015	6016	6017	6018	6019
6020	6021	6022	6023	6024	6338	6339	6340	6341	6342	6344	6345	6346	6348	6350
6351	6353	6355	6357	6358	6360	6362	6364	6367	6370	6372	6375	6380	6384	6387
6391	6394	6398	6402	6406	6410	6414	6417	6421	6424	6428	6432	6436	6439	6443
6446	6541	6542	6543	6544	6545	6546	6547	6548	6549	6550	6551	6552	6553	6554
6555	6556	6557	6558	6559	6560	6561	6562	6563	6564	6565	6566	6567	6568	6569
6570	6571	6615	6661											

ERRORS DETECTED: 0
DEFAULT GLOBALS GENERATED: 0

#, NOW. SEQ/SOL/CRF/NL: TOC/PAGNUM=DZRP1B.SML, DZRP1B.CMB
RUN-TIME: 44 66 10 SECONDS
RUN-TIME RATIO: 284/121=2.3
CORE USED: 35K (69 PAGES)

