

CONTENTS

- 1. ABSTRACT
- 2. REQUIREMENTS
 - 2.1 EQUIPMENT
 - 2.2 STORAGE
 - 2.3 PRELIMINARY PROGRAMS
- 3. LOADING PROCEDURE
- 4. STARTING PROCEDURE
 - 4.1 STARTING ADDRESSES
 - 4.2 OPERATOR ACTION
 - 4.3 UNIBUS ADDRESSES
- 5. OPERATING PROCEDURE
 - 5.1 SOFTWARE SWITCH REGISTER
 - 5.2 OPERATIONAL SWITCH SETTINGS
 - 5.3 RP11E CONTROLLER SETUP
 - 5.4 TEST SELECTION
 - 5.4 CHANGING RP11E UNIBUS AND VECTOR ADDRESSES
- 6. ERRORS
- 7. MISCELLANEOUS
 - 7.1 EXECUTION TIME
 - 7.2 END OF TEST
 - 7.3 STACK POINTER
 - 7.4 SUBROUTINE CALLS
- 8. PROGRAM DESCRIPTION
- 9. PROGRAM LISTING

46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85

97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141

1. ABSTRACT

THE RP11E DISKLESS TEST EXERCISES THE RP11E IN THE MAINTENANCE MODE. THE PROGRAM VERIFIES THE LOGIC CONTAINED IN THE RP11E BY UTILIZING THE THREE MAINTENANCE REGISTERS WHICH SIMULATE THE SIGNALS PASSING BETWEEN THE RP11E AND AN RPO2, RPRO2, OR RPO3 DISK DRIVE.

2. REQUIREMENTS

2.1 EQUIPMENT

PDP-11 COMPUTER WITH 8K OF MEMORY (WITH OR WITHOUT HARDWARE SWITCH REGISTER); CONSOLE TELETYPE; RP11E DISK CONTROLLER.

2.2 STORAGE

THIS PROGRAM WILL LOAD AND RUN IN 8K.

2.3 PRELIMINARY PROGRAMS

NONE

3. LOADING PROCEDURE

THE PROGRAM MAY BE LOADED FROM EITHER PAPER TAPE OR AN 'XXDP' DEVICE. REFER TO EITHER THE STANDARD PROCEDURES FOR LOADING 'ABS' FORMAT PAPER TAPES OR TO THE 'XXDP' SYSTEM REFERENCE DOCUMENT.

4. STARTING PROCEDURE

4.1 *** BEFOR STARTING REFER TO SECTION 5. ***
STARTING ADDRESSES

200 NORMAL STARTING ADDRESS
204 SELECT RP11 ADDRESS

4.1.1 START FROM LOCATION 200

WHEN THE PROGRAM IS STARTED FROM LOCATION 200, THE PROGRAM WILL PERFORM ALL OF THE TESTS IN SEQUENCE.

4.1.2 START FROM LOCATION 204

WHEN THE PROGRAM IS STARTED FROM LOCATION 204, OPERATION IS THE SAME AS THE START FROM 200, EXCEPT THAT THE PROGRAM ASKS FOR A NEW RP11E ADDRESS, VECTOR ADDRESS, AND PRIORITY. THE OPERATOR

EO1

MAINDEC-11-DZRPW-B, RP11-E DISKLESS LOGIC TEST MACY11 27(732) 01-NOV-76 16:44 PAGE 5
DZRPMB.CMB

142
143
144

MAY ENTER NEW ADDRESS VALUES OR RETAIN THE OLD VALUES. REFER TO
SECTION 4.3.

145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199

4.2 OPERATOR ACTION

1. LOAD PROGRAM INTO MEMORY (SEE SECTION 3.)
2. POWER DOWN OR CYCLE DOWN DRIVE D (SEE SECTION 5.2).
3. LOAD ADDRESS 200 OR 204.
4. SET SWITCHES (SEE SECTION 5.1) (SOFTWARE SWITCH REGISTER IS LOC. 176)
5. PRESS START.

4.3 UNIBUS ADDRESSES

THE PROGRAM ASSUMES THE FOLLOWING UNIBUS ADDRESSES. THESE ADDRESSES MAY BE CHANGED AT THE INDICATED LOCATION BEFORE STARTING THE PROGRAM.

MEMORY LOCATION	CONTENTS	FUNCTION
1136	177560	TTY KEYBOARD STATUS REG
1140	177562	TTY KEYBOARD BUFFER REG
1142	177564	TTY PRINTER STATUS REGISTER
1144	177566	TTY PRINTER BUFFER REG

RP11E ADDRESSES (UNIBUS AND VECTOR) ARE CHANGED IN RESPONSE TO THE PROGRAM'S TYPED REQUESTS IF THE PROGRAM IS STARTED FROM LOCATION 204 OR IF THERE IS NO RESPONSE WHEN LOCATION 176710 IS ADDRESSED.

5. OPERATING PROCEDURES

IF THE DIAGNOSTIC IS RUN ON A CPU WITHOUT A SWITCH REGISTER THEN A SOFTWARE SWITCH REGISTER IS USED WHICH ALLOWS THE USER THE SAME SWITCH OPTIONS AS THE HARDWARE SWITCH REGISTER. IF THE HARDWARE SWITCH REGISTER DOES NOT EXIST OR IF ONE DOES AND IT CONTAINS ALL ONES (177777) THEN THE SOFTWARE SWITCH REGISTER (LOC. 176) IS USED.

CONTROL:

THIS PROGRAM ALSO SUPPORTS THE DYNAMIC LOADING OF THE SOFTWARE SWITCH REGISTER (LOC. 176) FROM THE TTY. THIS CAN BE ACCOMPLISHED BY DOING THE FOLLOWING:

- 1) TYPE CONTROL G (<G>); THIS WILL ALLOW THE TTY TO ENTER DATA INTO LOC. 176 AT SELECTED POINTS WITHIN THE PROGRAM.
- 2) THE MACHINE WILL THEN TYPE: SWR=XXXXXXNEW= (XXXXXX IS THE OCTAL CONTENTS OF THE SOFTWARE SWITCH REGISTER.)
- 3) AFTER THE "NEW=" HAS BEEN TYPED THEN THE OPERATOR CAN DO ONE OF THE FOLLOWING AT THE TTY:

200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300

- A) TYPE A NUMBER TO BE LOADED INTO LOC. 176 FOLLOWED BY A <CR>. (ONLY NUMBERS BETWEEN 0-7 WILL BE ACCEPTED AND ONLY 6 NUMBERS WILL BE ALLOWED) IF A <CR> IS THE FIRST KEY DEPRESSED THE SOFTWARE SWITCH REGISTER CONTENTS WILL NOT BE CHANGED.
- B) IF A CONTROL U <U> IS DEPRESSED THEN THE PROGRAM WILL SEND YOU BACK TO STEP 2.

5.1 OPERATIONAL SWITCH SETTINGS

WITH ALL SWITCHES SET TO ZERO, THE PROGRAM WILL TYPE ALL ERRORS AND CONTINUE TESTING.

THE SWITCH SETTINGS ARE:

- SW<15>=1...HALT ON ERROR
- SW<14>=1...LOOP ON TEST
- SW<13>=1...INHIBIT ERROR TYPEOUTS
- SW<11>=1...INHIBIT ITERATIONS
- SW<10>=1...RING BELL ON ERROR
- SW<09>=1...LOOP ON ERROR
- SW<08>=1...LOOP ON THE TEST NUMBER CONTAINED IN SWITCHES <0:6>
- SW<07>=1...IN FLOATING 1'S & 0'S TESTS AND SILO DATA TEST, GO TO THE NEXT TEST AFTER A DATA COMPARSION ERROR.

5.2 CONTROLLER SETUP

BEFORE THE PROGRAM IS STARTED, THE CONTROLLER MAINTENANCE SWITCH MUST BE SET TO 'ENABLE'. DRIVE 0 MUST BE EITHER CYCLED DOWN OR BE POWERED DOWN.

AS THE CONTROLLER USES THE 'SURP03' LINE COMING FROM THE DRIVE TO DETERMINE THE MAXIMUM CYLINDER ADDRESS FOR THE DRIVE, SPECIAL SETUP PROCEDURES ARE REQUIRED TO TEST THE CONTROLLER WHEN MIXED DRIVES (RP02 OR RP03 DRIVES) ARE CONNECTED. IF DRIVE 0 IS AN RP02 OR AN RP02 AND IT IS DESIRED TO TEST THE CONTROLLER USING THE RP03 MAXIMUM CYLINDER ADDRESS, POWER DOWN DRIVE 0 AND CONNECT A JUMPER BETWEEN H13P2 AND GROUND. GROUNDING THIS PIN FORCES THE RP03 SIGNAL ('SURP03') HIGH.

IF DRIVE IS AN RP03 AND THE CONTROLLER IS TO BE TESTED USING THE RP02 MAXIMUM CYLINDER ADDRESS, POWER DOWN DRIVE 0.

IF THE CONTROLLER IS TO BE TESTED USING THE CYLINDER ADDRESS LIMIT OF DRIVE 0, THE DRIVE MUST BE CYCLED DOWN.

5.3 TEST SELECTION

TO EXECUTE A SPECIFIC TEST, SET SW<08> TO 1 AND SET THE TEST NUMBER (REFER TO THE PROGRAM LISTING) IN SWITCHES <0:6>, START THE PROGRAM IN THE USUAL MANNER. THE PROGRAM WILL PERFORM ALL THE TESTS UP TO THE SPECIFIED TEST FOR ONE ITERATION AND WILL LOOP ON THE TEST SPECIFIED IN THE SWITCHES. (REFERE TO SECTION 5. FOR SOFTWARE SWITCH REGISTER)

266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311

5.4 CHANGING RP11E UNIBUS AND VECTOR ADDRESSES

THE OPERATOR MAY CHANGE THE DEFAULT VALUES OF THE RP11E UNIBUS AND VECTOR ADDRESSES BY STARTING THE PROGRAM FROM LOCATION 204. THE PROGRAM WILL TYPE THE FOLLOWING MESSAGE:

RPADR = 176710/

THE OPERATOR MAY EITHER ENTER A NEW RP11E UNIBUS ADDRESS VALUE OR HE MAY RETAIN THE PRELOADED VALUE BY ENTERING A CARRIAGE RETURN.

THE PROGRAM WILL THEN TYPE:

RPVEC = 254/

THE VECTOR ADDRESS MAY BE CHANGED BY ENTERING A NEW VALUE OR THE PRELOADED VALUE MAY BE RETAINED BY ENTERING A CARRIAGE RETURN.

THE PROGRAM WILL THEN REQUEST A NEW RP11E PRIORITY WITH THE FOLLOWING MESSAGE:

RPPRIO = 5/

A NEW PRIORITY MAY BE ENTERED OR THE PRESENT PRIORITY MAY BE RETAINED.

THE PROGRAM WILL THEN VERIFY THAT THE LOADED RP11E UNIBUS ADDRESS RESPONDS WHEN THE PROGRAM ADDRESSES THE LOCATION. IF THERE IS NO RESPONSE FROM THE ADDRESS, THE PROGRAM WILL TYPE:

'RP11E DIDN'T RESPOND TO ADDRESSING'

THE PROGRAM WILL LOOP BACK TO THE RP11E ADDRESS ENTRY MESSAGE.

THE PROGRAM ALWAYS CHECKS FOR RESPONSE FROM THE RP11E BEFORE STARTING THE TESTS WHETHER OR NOT A START FROM LOCATION 204 WAS INITIATED.

6. ERRORS

WHEN THE PROGRAM DETECTS AN ERROR, THE ERROR ROUTINE IS CALLED AND THE SW(13) IS NOT SET, THE ERROR MESSAGE PERTAINING TO THE ERROR WILL BE TYPED. EACH ERROR TYPEOUT WILL CONTAIN THE FOLLOWING*

- A. AN ERROR MESSAGE
- B. A DATA HEADER LINE
- C. A DATA LINE CONTAINING:
 - 1. THE TEST NUMBER
 - 2. THE PC (PROGRAM COUNTER CONTENTS) WHERE THE ERROR CALL WAS MADE.
 - 3. CONTENTS OF THE APPROPRIATE REGISTERS

312
313
314
315

D. THE ERROR ROUTINE WILL HONOR A 1G (REFERENCE OPERATING PROCEDURE SECTION 5.)

362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417

8. TEST DESCRIPTION

- 8.1 BEFORE TESTING IS STARTED, THE PROGRAM VERIFIES THAT THE ADDRESS SPECIFIED AS THE FIRST RP11E ADDRESS RESPONDS WHEN ADDRESSED. THE PROGRAM WILL NOT CONTINUE UNTIL IT RECEIVES A RESPONSE FROM THE RP11E.
- 8.2 TEST 0 - THIS TEST VERIFIES THAT ALL LOADABLE BITS IN REGISTERS RPER, RPCS, RPWC, RPBA, RPCA, AND RPDA CAN BE SET AND THAT A 'RESET' INSTRUCTION FROM THE PROCESSOR CLEARS THE REGISTERS.
- 8.3 TEST 1 - THIS TEST VERIFIES THAT THE SELECTED UNIT ON LINE ('SUOL') BIT IN RPDS CAN BE SET IN MAINTENANCE MODE.
- 8.4 TEST 2 - THIS TEST VERIFIES THAT THE RP11E INITIALIZE INSTRUCTION CLEARS THE REGISTERS. THE REGISTERS CHECKED ARE RPER, RPCS, RPWC, RPBA, RPCA, AND RPDA.
- 8.5 TEST 3 - THIS TEST TESTS THE LOADING OF ALL POSSIBLE BITS IN REGISTER RPER USING A FLOATING 1'S AND 0'S PATTERN.
- 8.6 TEST 4 - THIS TEST TESTS THE LOADING OF ALL POSSIBLE BITS IN REGISTER RPCS USING A FLOATING 1'S AND 0'S PATTERN.
- 8.7 TEST 5 - THIS TEST TESTS THE LOADING OF ALL POSSIBLE BITS IN REGISTER RPWC USING A FLOATING 1'S AND 0'S PATTERN.
- 8.8 TEST 6 - THIS TEST TESTS THE LOADING OF ALL POSSIBLE BITS IN REGISTER RPBA USING A FLOATING 1'S AND 0'S PATTERN.
- 8.9 TEST 7 - THIS TEST TESTS THE LOADING OF ALL POSSIBLE BITS IN REGISTER RPCA USING A FLOATING 1'S AND 0'S PATTERN.
- 8.10 TEST 10 - THIS TEST TESTS THE LOADING OF ALL POSSIBLE BITS IN REGISTER RPDA USING A FLOATING 1'S AND 0'S PATTERN.
- 8.11 TEST 11 - THIS TEST VERIFIES THE HIGH SPEED OPERATION OF THE WORD COUNT REGISTER IN A MANNER SIMILAR TO ITS OPERATION AS A COUNTER DURING A DATA TRANSFER OPERATION. THE CONTENTS OF EACH MEMORY LOCATION (UP TO 28K) ARE LOADED INTO AND READ FROM THE REGISTER AND CHECKED. THE LOAD AND READ OF THE REGISTER ARE PERFORMED AT THE MAXIMUM POSSIBLE PROGRAM RATE. FAILURES IN THIS TEST CAN INDICATE SETTLE DOWN PROBLEMS IN THE REGISTER
- 8.12 TEST 12 - THIS TEST VERIFIES THE HIGH SPEED OPERATION OF THE BUFFER ADDRESS REGISTER IN A MANNER SIMILAR TO ITS OPERATION AS A COUNTER DURING A DATA TRANSFER OPERATION. THE CONTENTS OF EACH MEMORY LOCATION (UP TO 28K) ARE LOADED INTO AND READ FROM THE REGISTER AND CHECKED. THE LOAD AND READ OF THE REGISTER ARE PERFORMED AT THE MAXIMUM POSSIBLE PROGRAM RATE. FAILURES IN THIS TEST CAN INDICATE SETTLE DOWN PROBLEMS IN THE REGISTER
- 8.13 TEST 13 - TEST THAT THE 'SLUDY' BIT CAN BE SET AND CLEARED. THE BIT IS TESTED BY LOADING THE DRIVE READY BIT IN THE MAINTENANCE REGISTER

L01

MAINDEC-11-DZRPW-B, RP11-E DISKLESS LOGIC TEST MACY11 27(732) 01-NOV-76 16:44 PAGE 12
DZRPWB.CMB

418
419
420
421
422

8.14

TEST 14 - TEST THAT 'SELECTED UNIT SEEK INCOMPLETE' CAN BE SET IN
MAINTENANCE MODE, THAT 'DRIVE ERROR' SETS IN RPER, AND THAT
'ERR' AND 'HE' SET IN RPCS.

MO1

- 423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
- 8.15 TEST 15 - TEST THAT 'SELECTED UNIT FILE UNSAFE' CAN BE SET AND CLEARED IN MAINTENANCE MODE.
- 8.16 TEST 16 - TEST THAT 'SELECTED UNIT WRITE PROTECT' CAN BE SET AND CLEARED IN MAINTENANCE MODE.
- 8.17 TEST 17 - TEST THAT 'SELECTED UNIT WRITE PROTECTED' CAN BE SET AND CLEARED IN MAINTENANCE MODE.
- 8.18 TEST 20 - TEST THAT EACH OF THE ATTENTION BITS CAN BE SET AND EACH IS CLEARED WHEN A '1' IS WRITTEN INTO THE BIT. VERIFY THAT A 'RESET' INSTRUCTION CLEARS THE ATTENTION BITS AND THAT WRITING 0'S INTO THE ATTENTION BITS DOES NOT CLEAR THE BITS.
- 8.19 TEST 21 - VERIFY THAT 'WPV' OCCURS WHEN A WRITE COMMAND IS ISSUED TO THE CONTROLLER AND 'SUMP' IS SET. VERIFY THAT 'ERR' AND 'HE' SET IN RPCS.
- 8.20 TEST 22 - VERIFY THAT 'FUV' OCCURS WHEN A COMMAND IS ISSUED TO THE CONTROLLER AND 'SUFU' IS SET. VERIFY THAT 'ERR' AND 'HE' BITS SET IN RPCS.
- 8.21 TEST 23 - VERIFY THAT 'NXC' DOES NOT SET WHEN A WRITE COMMAND IS ISSUED USING EACH VALID CYLINDER CODE.
- 8.22 TEST 24 - VERIFY THAT 'NXC' SETS WHEN A WRITE ORDER IS GIVEN FOR EACH INVALID CYLINDER ADDRESS. VERIFY THAT 'ERR' AND 'HE' BITS SET IN RPCS
- 8.23 TEST 25 - VERIFY THAT 'NXT' DOES NOT SET WHEN A WRITE COMMAND IS GIVEN USING EACH VALID TRACK ADDRESS.
- 8.24 TEST 26 - VERIFY THAT 'NXT' OCCURS WHEN A WRITE COMMAND IS GIVEN USING EACH INVALID TRACK ADDRESS CODE UP TO THE LIMIT OF THE REGISTER. VERIFY THAT 'ERR' AND 'HE' BITS SET IN RPCS.
- 8.25 TEST 27 - VERIFY THAT 'NXS' DOES NOT OCCUR WHEN A WRITE COMMAND IS GIVEN USING EACH VALID SECTOR ADDRESS.
- 8.26 TEST 30 - VERIFY THAT 'NXS' OCCURS WHEN A WRITE COMMAND IS GIVEN USING EACH INVALID SECTOR ADDRESS CODE UP TO THE LIMIT OF THE REGISTER. VERIFY THAT 'ERR' AND 'HE' BITS SET IN RPCS.
- 8.27 TEST 31 - VERIFY THAT A 'PROG' ERROR OCCURS IF A COMMAND IS ISSUED WHEN 'SUOL' IS NOT SET. VERIFY THAT 'ERR' AND 'HE' BITS ARE SET IN RPCS.
- 8.28 TEST 32 - VERIFY THAT A 'MODE' ERROR OCCURS IF AN ATTEMPT IS MADE TO WRITE A HEADER WHEN THE CONTROLLER IS IN 'PDP-11' MODE.
- 8.29 TEST 33 - VERIFY THAT AN INTERRUPT OCCURS WHEN AN ATTENTION BIT AND 'AIE' ARE SET. WHEN THE INTERRUPT OCCURS, VERIFY THAT 'AIE' HAS RESET.
- 8.30 TEST 34 - VERIFY THAT THE CONTROLLER DOES NOT GENERATE AN INTERRUPT WHEN 'AIE' IS SET AND NO ATTENTION BITS ARE SET.

NO1

MAINDEC-11-DZRPW-B, RP11-E DISKLESS LOGIC TEST MACY11 27(732) 01-NOV-76 16:44 PAGE 14
DZRPWB.CMB

479

- 480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
- 8.31 TEST 35 - VERIFY THAT EACH ATTENTION BIT SET WILL GENERATE A SEPARATE INTERRUPT. ATTENTION BITS 0 AND 1 ARE SET AND 'AIE' IS SET; VERIFY THAT AN INTERRUPT OCCURS. RESET ATTENTION BIT 0 AND SET 'AIE' AGAIN; VERIFY THAT A SECOND INTERRUPT OCCURS.
- 8.32 TEST 36 - VERIFY THAT AN INTERRUPT OCCURS WHEN THE CONTROLLER IS READY AND 'IDE' IS SET. VERIFY THAT 'IDE' DOES NOT RESET WHEN AN INTERRUPT OCCURS.
- 8.33 TEST 37 - VERIFY THAT AN INTERRUPT DOES NOT OCCUR WHEN THE CONTROLLER IS READY AND 'IDE' IS NOT SET.
- 8.34 TEST 40 - VERIFY THAT A CONTROLLER INTERRUPT OCCURS WITH THE PROCESSOR AT PRIORITY 4.
- 8.35 TEST 41 - VERIFY THAT A CONTROLLER INTERRUPT DOES NOT OCCUR WHEN THE PROCESSOR IS AT PRIORITY 5.
- 8.36 TEST 42 - VERIFY THAT A CONTROLLER INTERRUPT DOES NOT OCCUR WHEN THE PROCESSOR IS AT PRIORITY 6.
- 8.37 TEST 43 - VERIFY THAT A CONTROLLER INTERRUPT DOES NOT OCCUR WHEN THE PROCESSOR IS AT PRIORITY 7.
- 8.38 TEST 44 - VERIFY THAT CONTROLLER READY RESETS WHEN 'GO' IS SET AND THAT CONTROLLER INITIALIZE RETURNS THE CONTROLLER TO THE 'READY' STATE.
- 8.39 TEST 45 - TEST THE 'SUCA' BIT PATH IN THE CONTROLLER.
- 8.40 TEST 46 - VERIFY THAT THE 'SOT' COUNTER COUNTS SECTOR PULSES PROPERLY.
- 8.41 TEST 47 - VERIFY THAT 'INDEX' CLEARS THE 'SOT' COUNTER. CHECK THAT THE 'SOT' CONTAINS SOME COUNT; IF THE 'SOT' IS CLEAR, ISSUE A SECTOR PULSE TO SET A VALUE INTO THE COUNTER. GENERATE AN INDEX PULSE AND VERIFY THAT THE 'SOT' CLEARS.
- 8.42 TEST 50 - VERIFY THAT SILO MEMORY LOGIC. CLEAR THE CONTROLLER; VERIFY THAT THE SILO'S 'INPUT READY' BIT IS SET. LOAD THE SILO AND VERIFY THAT WORD 'BUBBLES' THROUGH THE SILO AND THAT 'OUTPUT READY' SETS. READ THE SILO REGISTER AND VERIFY THAT THE DATA IS CORRECT. AFTER THE SILO REGISTER IS READ, VERIFY THAT 'OUTPUT READY' CLEARS. PERFORM THE TEST USING FLOATING 1'S AND 0'S PATTERN.
- 8.43 TEST 51 - VERIFY THAT THE SILO MEMORY CAN HOLD 64 WORDS. LOAD THE SILO WITH NUMBERS FROM 1 (8) TO 100 (8). VERIFY THAT 'INPUT READY' CLEARS AFTER 64 (10) WORDS HAVE BEEN LOADED INTO THE SILO AND THAT 'OUTPUT READY' IS SET. READ EACH WORD FROM THE SILO AND COMPARE IT. VERIFY THAT 'INPUT READY' SET WHEN THE FIRST WORD IS READ FROM THE FULL SILO. VERIFY THAT 'INPUT READY' REMAINS SET AND THAT 'OUTPUT READY' STAYS SET UNTIL THE SILO IS EMPTY.
- 8.44 TEST 52 - ISSUE A SEEK IN MAINTENANCE MODE. VERIFY THAT 'SET CYLINDER', 'RESET HEAD', 'SET HEAD', AND 'SEEK START' CONTROL SIGNALS OCCUR AT THE PROPER TIME. VERIFY THAT THE HEAD ADDRESS AND CYLINDER ADDRESS ARE CORRECT AT THE PROPER TIME.

C02

MAINDEC-11-DZRPW-B, RP11-E DISKLESS LOGIC TEST MACY11 27(732) 01-NOV-76 16:44 PAGE 16
DZRPWB.CMB

536

537
538
539
540
541
542
543
544
545
546
547
548
549
550

- 8.45 TEST 53 - ISSUE A HOME SEEK IN MAINTENANCE MODE. VERIFY THAT 'CONTROL' AND 'RESTORE' ARE SET ON THE BUS.
- 8.46 TEST 54 - ISSUE A READ IN MAINTENANCE MODE. VERIFY THAT 'CONTROL', 'SELECT HEAD' AND 'READ' ARE ON THE DRIVE BUS OUT LINES.
- 8.47 TEST 55 - ISSUE A WRITE FORMAT IN MAINTENANCE MODE. VERIFY THAT 'CONTROL', 'SELECT HEAD', 'ERASE', AND 'WRITE' ARE SET ON THE BUS OUT LINES.

- 9. PROGRAM LISTING

E02

MAINDEC-11-DZRPW-B, RP11-E DISKLESS LOGIC TEST MACY11 27(732) 01-NOV-76 16:44 PAGE 18
DZRPWB.CMB

551
552

%

570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608

```

TITLE MAINDEC-11-DZRPW-B, RP11-E DISKLESS LOGIC TEST
*COPYRIGHT (C) 1975,1976
*DIGITAL EQUIPMENT CORP.
*MAYNARD, MASS. 01754
*
*PROGRAM BY C. HESS/F. ROEMER
*
*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
*PACKAGE (MAINDEC-11-DZQAC-C1),MAR 24, 1976.
*
.SBTTL OPERATIONAL SWITCH SETTINGS
*
*      SWITCH      USE
*      -----
*      15          HALT ON ERROR
*      14          LOOP ON TEST
*      13          INHIBIT ERROR TYPEOUTS
*      11          INHIBIT ITERATIONS
*      10          BELL ON ERROR
*      9           LOOP ON ERROR
*      8           LOOP ON TEST IN SWR<6:0>
*      7           EXIT FROM TEST AFTER ERROR DURING FLOATING 1'S AND 0'
*                TESTS AND THE SILO DATA TEST.

```

.SBTTL TRAP CATCHER

000000

```

.=0
;#ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A "+2,HALT"
;#SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
;#LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
.=174
DISPREG: .WORD 0      ;;SOFTWARE DISPLAY REGISTER
SWREG:   .WORD 0      ;;SOFTWARE SWITCH REGISTER

```

000174 000000
000176 000000

.SBTTL ACT11 HOOKS

```

;*****
;HOOKS REQUIRED BY ACT11
$SVPC=.          ;SAVE PC
.=46             ;;1)SET LOC.46 TO ADDRESS OF SENDAD IN .SEOP
SENDAD
.=52             ;;2)SET LOC.52 TO ZERO
.WORD 0          ;;
.=SVPC           ;; RESTORE PC

```

000200 000046
000046 016364
000052 000052
000052 000000
000200 000200

.SBTTL STARTING ADDRESSES

000200
000200 000137 002364
000204 000137 002372

```

.=200
;#200 = NORMAL START
      JMP START
;#204 = SELECT RP11E ADDRESS
      JMP START1

```

.SBTTL BASIC DEFINITIONS

```

609          :#INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
610          001100  STACK= 1100
611          .EQUIV EMT,ERROR      ;;BASIC DEFINITION OF ERROR CALL
612          .EQUIV IOT,SCOPE      ;;BASIC DEFINITION OF SCOPE CALL
613
614          ;#MISCELLANEOUS DEFINITIONS
615          000011  HT= 11          ;;CODE FOR HORIZONTAL TAB
616          000012  LF= 12          ;;CODE FOR LINE FEED
617          000015  CR= 15          ;;CODE FOR CARRIAGE RETURN
618          000200  CRLF= 200       ;;CODE FOR CARRIAGE RETURN-LINE FEED
619          177776  PS= 177776     ;;PROCESSOR STATUS WORD
620          .EQUIV PS,PSW
621          177774  STKLM= 177774   ;;STACK LIMIT REGISTER
622          177772  PIRQ= 177772   ;;PROGRAM INTERRUPT REQUEST REGISTER
623          177570  DSWR= 177570   ;;HARDWARE SWITCH REGISTER
624          177570  DDISP= 177570  ;;HARDWARE DISPLAY REGISTER
625
626          ;#GENERAL PURPOSE REGISTER DEFINITIONS
627          000000  R0= X0          ;;GENERAL REGISTER
628          000001  R1= X1          ;;GENERAL REGISTER
629          000002  R2= X2          ;;GENERAL REGISTER
630          000003  R3= X3          ;;GENERAL REGISTER
631          000004  R4= X4          ;;GENERAL REGISTER
632          000005  R5= X5          ;;GENERAL REGISTER
633          000006  R6= X6          ;;GENERAL REGISTER
634          000007  R7= X7          ;;GENERAL REGISTER
635          .EQUIV R6,SP          ;;STACK POINTER
636          .EQUIV R7,PC          ;;PROGRAM COUNTER
637
638          ;#PRIORITY LEVEL DEFINITIONS
639          000000  PR0= 0           ;;PRIORITY LEVEL 0
640          000040  PR1= 40         ;;PRIORITY LEVEL 1
641          000100  PR2= 100        ;;PRIORITY LEVEL 2
642          000140  PR3= 140        ;;PRIORITY LEVEL 3
643          000200  PR4= 200        ;;PRIORITY LEVEL 4
644          000240  PR5= 240        ;;PRIORITY LEVEL 5
645          000300  PR6= 300        ;;PRIORITY LEVEL 6
646          000340  PR7= 340        ;;PRIORITY LEVEL 7
647
648          ;#"SWITCH REGISTER" SWITCH DEFINITIONS
649          100000  SW15= 100000
650          040000  SW14= 40000
651          020000  SW13= 20000
652          010000  SW12= 10000
653          004000  SW11= 4000
654          002000  SW10= 2000
655          001000  SW09= 1000
656          000400  SW08= 400
657          000200  SW07= 200
658          000100  SW06= 100
659          000040  SW05= 40
660          000020  SW04= 20
661          000010  SW03= 10
662          000004  SW02= 4
663          000002  SW01= 2
664          000001  SW00= 1

```

```

665 .EQUIV SW09,SW9
666 .EQUIV SW08,SW8
667 .EQUIV SW07,SW7
668 .EQUIV SW06,SW6
669 .EQUIV SW05,SW5
670 .EQUIV SW04,SW4
671 .EQUIV SW03,SW3
672 .EQUIV SW02,SW2
673 .EQUIV SW01,SW1
674 .EQUIV SW00,SW0

```

```

675
676
677 100000
678 040000
679 020000
680 010000
681 004000
682 002000
683 001000
684 000400
685 000200
686 000100
687 000040
688 000020
689 000010
690 000004
691 000002
692 000001

```

```

        :#DATA BIT DEFINITIONS (BIT00 TO BIT15)
        BIT15= 100000
        BIT14= 40000
        BIT13= 20000
        BIT12= 10000
        BIT11= 4000
        BIT10= 2000
        BIT09= 1000
        BIT08= 400
        BIT07= 200
        BIT06= 100
        BIT05= 40
        BIT04= 20
        BIT03= 10
        BIT02= 4
        BIT01= 2
        BIT00= 1
        .EQUIV BIT09,BIT9
        .EQUIV BIT08,BIT8
        .EQUIV BIT07,BIT7
        .EQUIV BIT06,BIT6
        .EQUIV BIT05,BIT5
        .EQUIV BIT04,BIT4
        .EQUIV BIT03,BIT3
        .EQUIV BIT02,BIT2
        .EQUIV BIT01,BIT1
        .EQUIV BIT00,BIT0

```

```

703
704
705 000004
706 000010
707 000014
708 000014
709 000014
710 000020
711 000024
712 000030
713 000034
714 000060
715 000064
716 000240
717
718
719
720 000000

```

```

        :#BASIC "CPU" TRAP VECTOR ADDRESSES
        ERRVEC= 4           ;; TIME OUT AND OTHER ERRORS
        RESVEC= 10        ;; RESERVED AND ILLEGAL INSTRUCTIONS
        TBITVEC=14        ;; "T" BIT
        TRTVEC= 14        ;; TRACE TRAP
        BPTVEC= 14        ;; BREAKPOINT TRAP (BPT)
        IOTVEC= 20        ;; INPUT/OUTPUT TRAP (IOT) ##SCOPE##
        PWRVEC= 24        ;; POWER FAIL
        EMTVEC= 30        ;; EMULATOR TRAP (EMT) ##ERROR##
        TRAPVEC=34        ;; "TRAP" TRAP
        TKVEC= 60         ;; TTY KEYBOARD VECTOR
        TPVEC= 64         ;; TTY PRINTER VECTOR
        PIRGVEC=240      ;; PROGRAM INTERRUPT REQUEST VECTOR

```

```

        .SBTTL RP11E REGISTER INDEX EQUATES
        RPOS=00

```

721	000002	RPER=02
722	000004	RPCS=04
723	000006	RPWC=06
724	000010	RPBA=10
725	000012	RPCA=12
726	000014	RPOA=14
727	000016	RPM1=16
728	000020	RPM2=20
729	000022	RPM3=22
730	000024	SUCA=24
731	000026	SIL0=26
732		
733		

734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789

001100
001100 000000
001102 000
001103 000
001104 000000
001106 000000
001110 000000
001112 000000
001114 000
001115 001
001116 000000
001120 000000
001122 000000
001124 000000
001126 000000
001130 000000
001132 000000
001134 000
001135 000
001136 000000
001140 177570
001142 177570
001144 177560
001146 177562
001150 177564
001152 177566
001154 000
001155 002
001156 012
001157 000
001160 000000
001162 000000
001164 000000
001166 177607 000377
001172 077
001173 015
001174 000012
001176 000000
001200 000000
001202 000000
001204 000000
001206 000000
001210 176710
001212 000254 000256
001216 000240

.SBTTL COMMON TAGS

*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
*USED IN THE PROGRAM.

.=1100

SCMTAG: .WORD 0
SPASS: .WORD 0
STSTNM: .BYTE 0
SERFLG: .BYTE 0
SICNT: .WORD 0
SLPADR: .WORD 0
SLPERR: .WORD 0
SERTTL: .WORD 0
SITEMB: .BYTE 0
SERMAX: .BYTE 1
SERRPC: .WORD 0
SGDADR: .WORD 0
SBDADR: .WORD 0
SGDDAT: .WORD 0
SBDAT: .WORD 0
SAUTOB: .BYTE 0
SINTAG: .BYTE 0
SMR: .WORD DSWR
DISPLAY: .WORD DDISP
STKS: 177560
STKB: 177562
STPS: 177564
STPB: 177566
SNUL: .BYTE 0
SFILLS: .BYTE 2
SFILLC: .BYTE 12
STPFLG: .BYTE 0
STMPO: .WORD 0
STINES: 0
SESCAPE: 0
SBELL: .ASCIZ <207><377><377>
SQUES: .ASCII /?/
SCRLF: .ASCII <15>
SLF: .ASCIZ <12>

START OF COMMON TAGS
CONTAINS PASS COUNT
CONTAINS THE TEST NUMBER
CONTAINS ERROR FLAG
CONTAINS SUBTEST ITERATION COUNT
CONTAINS SCOPE LOOP ADDRESS
CONTAINS SCOPE RETURN FOR ERRORS
CONTAINS TOTAL ERRORS DETECTED
CONTAINS ITEM CONTROL BYTE
CONTAINS MAX. ERRORS PER TEST
CONTAINS PC OF LAST ERROR INSTRUCTION
CONTAINS ADDRESS OF 'GOOD' DATA
CONTAINS ADDRESS OF 'BAD' DATA
CONTAINS 'GOOD' DATA
CONTAINS 'BAD' DATA
RESERVED--NOT TO BE USED
AUTOMATIC MODE INDICATOR
INTERRUPT MODE INDICATOR
ADDRESS OF SWITCH REGISTER
ADDRESS OF DISPLAY REGISTER
TTY KBD STATUS
TTY KBD BUFFER
TTY PRINTER STATUS REG. ADDRESS
TTY PRINTER BUFFER REG. ADDRESS
CONTAINS NULL CHARACTER FOR FILLS
CONTAINS # OF FILLER CHARACTERS REQUIRED
INSERT FILL CHARS. AFTER A "LINE FEED"
"TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
USER DEFINED
MAX. NUMBER OF ITERATIONS
ESCAPE ON ERROR ADDRESS
CODE FOR BELL
QUESTION MARK
CARRIAGE RETURN
LINE FEED
MAXIMUM CYLINDER ADDRESS CHECKED
MAXIMUM CYLINDER ADDRESS BITS CHECKED
STORAGE FOR PATTERN IN FLOATING 1'S & 0'S TESTS
CHANGE RP11 ADDRESS FLAG
STORE BITS TO BE LOADED INTO RPM3 HERE

;RP11E ADDRESSES

RPADR: .WORD 176710
RPVEC: .WORD 254,256
RPPRIO: .WORD <5*32.>

;RP11E BUS ADDRESS
;RP11E VECTOR ADDRESSES
;RP11E PRIORITY

790
791
792
793
794
795
796
797
798
799
800
801
802001220 000000
001222 000000
001224 000000
001226 000000
001230 000000
001232 000000
001234 000000
001236 000000
001240 000000
001242 000000

;SAVE THE RP11E REGISTERS HERE

SRPDS: .WORD 0
SRPER: .WORD 0
SRPCS: .WORD 0
SRPWC: .WORD 0
SRPBA: .WORD 0
SRPCA: .WORD 0
SRPDA: .WORD 0
SRPM1: .WORD 0
SSUCA: .WORD 0
SSILO: .WORD 0:DRIVE STATUS REGISTER
:ERROR REGISTER
:COMMAND & STATUS REGISTER
:WORD COUNT REGISTER
:BUFFER ADDRESS REGISTER
:CURRENT CYLINDER ADDRESS REGISTER
:TRACK-SECTOR ADDRESS REGISTER
:MAINTENANCE REGISTER #1
:SELECTED UNIT CYLINDER ADDRESS REGISTER
:SILO REGISTER

803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858

.SBTTL ERROR POINTER TABLE
 ;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
 ;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
 ;*LOCATION SITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
 ;*NOTE1: IF SITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
 ;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;* EM ;:POINTS TO THE ERROR MESSAGE
 ;* DH ;:POINTS TO THE DATA HEADER
 ;* DT ;:POINTS TO THE DATA
 ;* DF ;:POINTS TO THE DATA FORMAT

SERRTB:
 ;ERROR 1
 EM1 ;RP11 DIDN'T RESPOND TO ADDRESSING
 DH1
 DT1
 DF1
 ;ERROR 2
 EM2 ;CAN'T LOAD REGISTER CORRECTLY
 DH2
 DT2
 DF2
 ;ERROR 3
 EM3 ;RESET DIDN'T CLEAR REGISTER
 DH2
 DT2
 DF2
 ;ERROR 4
 EM4 ;CONTROLLER CLEAR DIDN'T CLEAR REGISTER
 DH2
 DT2
 DF2
 ;ERROR 5
 EM5 ;FLOATING 1'S & 0'S TEST ERROR
 DH2
 DT2
 DF2
 ;ERROR 6
 EM6 ;REGISTER RAPID ACCESS TEST ERROR
 DH2
 DT2

001244
 001244 022510
 001246 027751
 001250 031352
 001252 031652
 001254 022552
 001256 027767
 001260 031356
 001262 031662
 001264 022610
 001266 027767
 001270 031356
 001272 031662
 001274 022644
 001276 027767
 001300 031356
 001302 031662
 001304 022713
 001306 027767
 001310 031356
 001312 031662
 001314 022751
 001316 027767
 001320 031356

859	001322	031662	DF2	
860				
861				;ERROR 7
862				
863	001324	023012	EM7	;CAN'T SET 'SURDY' BIT
864	001326	030035	DH7	
865	001330	031370	DT7	
866	001332	031656	DF1	
867				
868				;ERROR 10
869				
870	001334	023040	EM10	;CAN'T CLEAR THE 'SURDY' BIT
871	001336	030035	DH7	
872	001340	031370	DT7	
873	001342	031656	DF1	
874				
875				;ERROR 11
876				
877	001344	023074	EM11	;CAN'T SET 'SUSI'
878	001346	030062	DH11	
879	001350	031376	DT11	
880	001352	031662	DF2	
881				
882				;ERROR 12
883				
884	001354	023115	EM12	; 'DSK ERR' NOT SET WITH 'SUSI'
885	001356	030062	DH11	
886	001360	031376	DT11	
887	001362	031662	DF2	
888				
889				;ERROR 13
890				
891	001364	023153	EM13	; 'ERR' OR 'HE' NOT SET WITH 'SUSI'
892	001366	030062	DH11	
893	001370	031376	DT11	
894	001372	031662	DF2	
895				
896				;ERROR 14
897				
898	001374	023215	EM14	;CAN'T SET 'SUFU'
899	001376	030062	DH11	
900	001400	031376	DT11	
901	001402	031662	DF2	
902				
903				;ERROR 15
904				
905	001404	023236	EM15	;CAN'T CLEAR 'SUFU'
906	001406	030062	DH11	
907	001410	031376	DT11	
908	001412	031662	DF2	
909				
910				;ERROR 16
911				
912	001414	023261	EM16	;CAN'T SET 'SUMP'
913	001416	030062	DH11	
914	001420	031376	DT11	

915	001422	031662	DF2	
916				
917				;ERROR 17
918				
919	001424	023302	EM17	;CAN'T CLEAR 'SUMP'
920	001426	030062	DH11	
921	001430	031376	DT11	
922	001432	031662	DF2	
923				
924				;ERROR 20
925				
926	001434	023325	EM20	;CAN'T SET ATTENTION BIT
927	001436	030127	DH20	
928	001440	031410	DT20	
929	001442	031666	DF20	
930				
931				;ERROR 21
932				
933	001444	023355	EM21	;CAN'T CLEAR ATTENTION BIT
934	001446	030127	DH20	
935	001450	031410	DT20	
936	001452	031666	DF20	
937				
938				;ERROR 22
939				
940	001454	023407	EM22	;RESET DIDN'T CLEAR ATTENTION BITS
941	001456	030035	DH7	
942	001460	031370	DT7	
943	001462	031656	DF1	
944				
945				;ERROR 23
946				
947	001464	023451	EM23	;ATTENTION BITS CLEARED BY WRITING 0'S INTO RPDS
948	001466	030035	DH7	
949	001470	031370	DT7	
950	001472	031656	DF1	
951				
952				;ERROR 24
953				
954	001474	023531	EM24	;CAN'T SET 'WPV' ERROR
955	001476	030164	DH24	
956	001500	031420	DT24	
957	001502	031666	DF20	
958				
959				;ERROR 25
960				
961	001504	023557	EM25	; 'ERR' OR 'HE' NOT SET WITH 'WPV'
962	001506	030164	DH24	
963	001510	031420	DT24	
964	001512	031666	DF20	
965				
966				;ERROR 26
967				
968	001514	023620	EM26	;CAN'T SET 'FUV' ERROR
969	001516	030164	DH24	
970	001520	031420	DT24	

971	001522	031666	DF20	
972				
973				;ERROR 27
974				
975	001524	023646	EM27	; 'ERR' OR 'HE' NOT SET WITH 'FUV'
976	001526	030164	DH24	
977	001530	031420	DT24	
978	001532	031666	DF20	
979				
980				;ERROR 30
981				
982	001534	023707	EM30	; 'NXC' ERROR SET WITH VALID CYLINDER ADDRESS
983	001536	030221	DH30	
984	001540	031430	DT30	
985	001542	031672	DF30	
986				
987				;ERROR 31
988				
989	001544	023763	EM31	; 'NXC' DIDN(T SET WITH INVALID CYLINDER ADDRESS
990	001546	030221	DH30	
991	001550	031430	DT30	
992	001552	031672	DF30	
993				
994				;ERROR 32
995				
996	001554	024042	EM32	; 'ERR' OR 'HE' DIDN'T SET WITH 'NXC'
997	001556	030221	DH30	
998	001560	031430	DT30	
999	001562	031672	DF30	
1000				
1001				;ERROR 33
1002				
1003	001564	024106	EM33	; 'NXT' ERROR SET WITH VALID TRACK ADDRESS
1004	001566	030312	DH33	
1005	001570	031444	DT33	
1006	001572	031672	DF30	
1007				
1008				;ERROR 34
1009				
1010	001574	024157	EM34	; 'NXT' DIDN'T SET WITH INVALID TRACK ADDRESS
1011	001576	030312	DH33	
1012	001600	031444	DT33	
1013	001602	031672	DF30	
1014				
1015				;ERROR 35
1016				
1017	001604	024233	EM35	; 'ERR' OR 'HE' DIDN'T SET WITH 'NXT'
1018	001606	030312	DH33	
1019	001610	031444	DT33	
1020	001612	031672	DF30	
1021				
1022				;ERROR 36
1023				
1024	001614	024277	EM36	; 'NXS' ERROR SET WITH VALID SECTOR ADDRESS
1025	001616	030312	DH33	
1026	001620	031444	DT33	

1027	001622	031672	DF30	
1028				
1029				;ERROR 37
1030				
1031	001624	024351	EM37	; 'NXS' DIDN'T SET WITH INVALID SECTOR ADDRESS
1032	001626	030312	DH33	
1033	001630	031444	DT33	
1034	001632	031672	DF30	
1035				
1036				;ERROR 40
1037				
1038	001634	024426	EM40	; 'ERR' OR 'HE' DIDN'T SET WITH 'NXS'
1039	001636	030312	DH33	
1040	001640	031444	DT33	
1041	001642	031672	DF30	
1042				
1043				;ERROR 41
1044				
1045	001644	024472	EM41	; CAN'T SET 'PROG' ERROR
1046	001646	030164	DH24	
1047	001650	031420	DT24	
1048	001652	031666	DF20	
1049				
1050				;ERROR 42
1051				
1052	001654	024521	EM42	; 'ERR' OR 'HE' NOT SET WITH 'PROG'
1053	001656	030164	DH24	
1054	001660	031420	DT24	
1055	001662	031666	DF20	
1056				
1057				;ERROR 43
1058				
1059	001664	024563	EM43	; CAN'T SET 'MODE' ERROR
1060	001666	030164	DH24	
1061	001670	031420	DT24	
1062	001672	031666	DF20	
1063				
1064				;ERROR 44
1065				
1066	001674	024612	EM44	; 'ERR' OR 'HE' NOT SET WITH 'MODE'
1067	001676	030164	DH24	
1068	001700	031420	DT24	
1069	001702	031666	DF20	
1070				
1071				;ERROR 45
1072				
1073	001704	024654	EM45	; CAN'T CLEAR 'SUSI'
1074	001706	030062	DH11	
1075	001710	031376	DT11	
1076	001712	031662	DF2	
1077				
1078				;ERROR 46
1079				
1080	001714	024677	EM46	; NO ATTENTION INTERRUPT
1081	001716	030403	DH46	
1082	001720	031460	DT46	

1083	001722	031662	DF2	
1084				
1085				;ERROR 47
1086				
1087	001724	024726	EM47	; 'AIE' DIDN'T CLEAR WHEN INTERRUPT OCCURED
1088	001726	030403	DM46	
1089	001730	031460	DT46	
1090	001732	031662	DF2	
1091				
1092				;ERROR 50
1093				
1094	001734	025000	EM50	;NO INTERRUPT WITH ATTENTION BITS 0 & 1 SET
1095	001736	030463	DM50	
1096	001740	031472	DT50	
1097	001742	031666	DF20	
1098				
1099				;ERROR 51
1100				
1101	001744	025053	EM51	;SECOND INTERRUPT DIDN'T OCCUR WITH ATTENTION BIT 1 SET
1102	001746	030463	DM50	
1103	001750	031472	DT50	
1104	001752	031666	DF20	
1105				
1106				;ERROR 52
1107				
1108	001754	025142	EM52	;NO INTERRUPT FROM CONTROLLER 'READY'
1109	001756	030520	DM52	
1110	001760	031502	DT52	
1111	001762	031656	DF1	
1112				
1113				;ERROR 53
1114				
1115	001764	025207	EM53	; 'READY' INTERRUPT WITH 'IDE' SET
1116	001766	030520	DM52	
1117	001770	031502	DT52	
1118	001772	031656	DF1	
1119				
1120				;ERROR 54
1121				
1122	001774	025250	EM54	;NO INTERRUPT FROM RP11 WITH CPU AT PR4
1123	001776	030520	DM52	
1124	002000	031502	DT52	
1125	002002	031656	DF1	
1126				
1127				;ERROR 55
1128				
1129	002004	025317	EM55	; INTERRUPT FROM RP11 WITH CPU AT PR5
1130	002006	030520	DM52	
1131	002010	031502	DT52	
1132	002012	031656	DF1	
1133				
1134				;ERROR 56
1135				
1136	002014	025363	EM56	; INTERRUPT FROM RP11 WITH CPU AT PR6
1137	002016	030520	DM52	
1138	002020	031502	DT52	

E03

1139	002022	031656	DF1	
1140				
1141				;ERROR 57
1142				
1143	002024	025427	EM57	;INTERRUPT FROM RP11 WITH CPU AT PR7
1144	002026	030520	DH52	
1145	002030	031502	DT52	
1146	002032	031656	DF1	
1147				
1148				;ERROR 60
1149				
1150	002034	025473	EM60	; 'READY' DIDN'T CLEAR AT END OF OPERATION
1151	002036	030520	DH52	
1152	002040	031502	DT52	
1153	002042	031656	DF1	
1154				
1155				;ERROR 61
1156				
1157	002044	025544	EM61	; 'SUCA' INCORRECT
1158	002046	030545	DH61	
1159	002050	031510	DT61	
1160	002052	031666	DF20	
1161				
1162				;ERROR 62
1163				
1164	002054	025565	EM62	; INDEX DIDN'T CLEAR 'SOT'
1165	002056	030613	DH62	
1166	002060	031520	DT62	
1167	002062	031656	DF1	
1168				
1169				;ERROR 63
1170				
1171	002064	025616	EM63	; 'SOT' DIDN'T COUNT CORRECTLY
1172	002066	030640	DH63	
1173	002070	031526	DT63	
1174	002072	031666	DF20	
1175				
1176				;ERROR 64
1177				
1178	002074	025653	EM64	;CONTROLLER CLEAR DIDN'T SET SILO INPUT READY
1179	002076	030705	DH64	
1180	002100	031536	DT64	
1181	002102	031666	DF20	
1182				
1183				;ERROR 65
1184				
1185	002104	025730	EM65	;SILO OUTPUT READY NOT SET AFTER WORD LOADED INTO SILO
1186	002106	030751	DH65	
1187	002110	031546	DT65	
1188	002112	031656	DF1	
1189				
1190				;ERROR 66
1191				
1192	002114	026016	EM66	;DATA READ FROM SILO IS INCORRECT
1193	002116	030776	DH66	
1194	002120	031554	DT66	

1195	002122	031672	DF30	
1196				
1197				;ERROR 67
1198				
1199	002124	026057	EM67	;SILO INPUT READY DIDN'T CLEAR AFTER 64 WORDS WERE
1200				;LOADED INTO THE SILO
1201	002126	030751	DH65	
1202	002130	031546	DT65	
1203	002132	031656	DF1	
1204				
1205				;ERROR 70
1206				
1207	002134	026167	EM70	;SILO OUTPUT READY DIDN'T CLEAR AFTER SILO EMPTIED
1208	002136	030751	DH65	
1209	002140	031546	DT65	
1210	002142	031656	DF1	
1211				
1212				;ERROR 71
1213				
1214	002144	026251	EM71	;BUS OUT LINES TO THE DRIVE ARE NOT CLEARED BY CONTROLLER CLEAR
1215	002146	031054	DH71	
1216	002150	031570	DT71	
1217	002152	031676	DF71	
1218				
1219				;ERROR 72
1220				
1221	002154	026351	EM72	;DRIVE BUS ERROR: 'SET CYLINDER' AND CYLINDER ADDRESS
1222				;SHOULD BE ON THE BUS
1223	002156	031141	DH72	
1224	002160	031606	DT72	
1225	002162	031672	DF30	
1226				;ERROR 73
1227				
1228				
1229	002164	026464	EM73	;DRIVE BUS ERROR: ONLY 'RESET HEAD' SHOULD BE ON THE BUS
1230	002166	031216	DH73	
1231	002170	031622	DT73	
1232	002172	031672	DF30	
1233				
1234				;ERROR 74
1235				
1236	002174	026554	EM74	;DRIVE BUS ERROR: 'SET HEAD' & HEAD ADDRESS SHOULD BE ON THE BUS
1237	002176	031275	DH74	
1238	002200	031636	DT74	
1239	002202	031672	DF30	
1240				
1241				;ERROR 75
1242				
1243	002204	026654	EM75	;DRIVE BUS ERROR: ONLY 'SEEK START' SHOULD BE ON THE BUS
1244				
1245	002206	031216	DH73	
1246	002210	031622	DT73	
1247	002212	031672	DF30	
1248				
1249				;ERROR 76
1250				

1251	002214	026744	EM76	;DRIVE BUS ERROR: 'RESTORE' AND 'CONTROL' SHOULD BE ON THE BUS
1252	002216	031216	DH73	
1253	002220	031622	DT73	
1254	002222	031672	DF30	
1255				
1256				
1257				
1258	002224	027042	EM77	;DRIVE BUS ERROR: 'CONTROL', 'SELECT HEAD', & 'READ' ;SHOULD BE ON THE BUS
1259				
1260	002226	031216	DH73	
1261	002230	031622	DT73	
1262	002232	031672	DF30	
1263				
1264				
1265				
1266	002234	027156	EM100	;DRIVE BUS ERROR: 'CONTROL', 'SELECT HEAD', 'ERASE', ;AND 'WRITE' SHOULD BE ON THE BUS
1267				
1268	002236	031216	DH73	
1269	002240	031622	DT73	
1270	002242	031672	DF30	
1271				
1272				
1273				
1274	002244	027303	EM101	; 'READY' DIDN'T CLEAR WHEN 'GO' WAS SET
1275	002246	030520	DH52	
1276	002250	031502	DT52	
1277	002252	031656	DF1	
1278				
1279				
1280				
1281	002254	027352	EM102	;CAN'T SET 'SUOL'
1282	002256	030035	DH7	
1283	002260	031370	DT7	
1284	002262	031656	DF1	
1285				
1286				
1287				
1288	002264	027373	EM103	;CAN'T CLEAR 'SUOL'
1289	002266	030035	DH7	
1290	002270	031370	DT7	
1291	002272	031656	DF1	
1292				
1293				
1294				
1295	002274	027416	EM104	;CAN'T SET 'SUSU'
1296	002276	030035	DH7	
1297	002300	031370	DT7	
1298	002302	031656	DF1	
1299				
1300				
1301				
1302	002304	027437	EM105	;CAN'T CLEAR 'SUSU'
1303	002306	030035	DH7	
1304	002310	031370	DT7	
1305	002312	031656	DF1	
1306				

```

1307 ;ERROR 106
1308
1309 002314 027462 EM106 ;'IDE' NOT SET AFTER INTERRUPT
1310 002316 030520 DH52
1311 002320 031502 DT52
1312 002322 031656 DF1
1313
1314 ;ERROR 107
1315
1316 002324 027520 EM107 ;ATTN INTERRUPT OCCURED WITH NO ATTN BITS SET
1317 002326 030062 DH11
1318 002330 031376 DT11
1319 002332 031662 DF2
1320
1321 ;ERROR 110
1322
1323 002334 027575 EM110 ;SILO NOT FULL, 'INPUT READY' NOT SET
1324 002336 030751 DH65
1325 002340 031546 DT65
1326 002342 031656 DF1
1327
1328 ;ERROR 111
1329
1330 002344 027642 EM111 ;SILO NOT EMPTY, 'OUTPUT READY' NOT SET
1331 002346 030751 DH65
1332 002350 031546 DT65
1333 002352 031656 DF1
1334
1335 ;ERROR 112
1336
1337 002354 027711 EM112 ;'INIT' COMMAND SET 'PROG' ERROR
1338 002356 030164 DH24
1339 002360 031420 DT24
1340 002362 031666 DF20
1341
1342
1343 .SBTTL START OF PROGRAM
1344
1345 002364 005037 001204 START: CLR BUSADR ;CLEAR THE ADDRESS CHANGE FLAG
1346 002370 000403 BR START2 ;GO TO SETUP
1347 002372 012737 177777 001204 START1: MOV 8-1,BUSADR ;SET ADDRESS CHANGE FLAG
1348 002400 000005 START2: RESET ;CLEAR THE BUS
1349
1350 .SBTTL INITIALIZE THE COMMON TAGS
1351 ;;CLEAR THE COMMON TAGS (SCHTAG) AREA
1352 002402 012706 001100 MOV #SCHTAG,R6 ;;FIRST LOCATION TO BE CLEARED
1353 002406 005026 CLR (R6)+ ;;CLEAR MEMORY LOCATION
1354 002410 022706 001140 CMP #SNR,R6 ;;DONE?
1355 002414 001374 BNE .-6 ;;LOOP BACK IF NO
1356 002416 012706 001100 MOV #STACK,SP ;;SETUP THE STACK POINTER
1357 ;;INITIALIZE A FEW VECTORS
1358 002422 012737 020734 000020 MOV #SCOPE,@IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE
1359 002430 012737 000340 000022 MOV #340,@IOTVEC+2 ;;LEVEL 7
1360 002436 012737 016404 000030 MOV #ERROR,@EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
1361 002444 012737 000340 000032 MOV #340,@EMTVEC+2 ;;LEVEL 7
1362 002452 012737 021310 000034 MOV #TRAP,@TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
1363 002460 012737 000340 000036 MOV #340,@TRAPVEC+2;LEVEL 7

```

```

1363 002466 013737 016320 016312 MOV SENDCT,SEOPCT ;:SETUP END-OF-PROGRAM COUNTER
1364 002474 005037 001162 CLR STIMES ;:INITIALIZE NUMBER OF ITERATIONS
1365 002500 005037 001164 CLR SESCAPE ;:CLEAR THE ESCAPE ON ERROR ADDRESS
1366 002504 112737 000001 001115 MOVVB #1,SEMAX ;:ALLOW ONE ERROR PER TEST
1367 002512 012737 002512 001106 MOV #.,SLPADR ;:INITIALIZE THE LOOP ADDRESS FOR SCOPE
1368 002520 012737 002520 001110 MOV #.,SLPERR ;:SETUP THE ERROR LOOP ADDRESS
1369 ;:SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
1370 ;:EQUAL TO A "-1" SETUP FOR A SOFTWARE SWITCH REGISTER.
1371 002526 013746 000004 MOV #ERRVEC, -(SP) ;:SAVE ERROR VECTOR
1372 002532 012737 002566 000004 MOV #645, #ERRVEC ;:SET UP ERROR VECTOR
1373 002540 012737 177570 001140 MOV #DSWR, SWR ;:SETUP FOR A HARDWARE SWICH REGISTER
1374 002546 012737 177570 001142 MOV #DDISP, DISPLAY ;:AND A HARDWARE DISPLAY REGISTER
1375 002554 022777 177777 176356 CMP #1, #SWR ;:TRY TO REFERENCE HARDWARE SWR
1376 002562 001012 BNE 665 ;:BRANCH IF NO TIMEOUT TRAP OCCURRED
1377 ;:AND THE HARDWARE SWR IS NOT = -1
1378 002564 000403 BR 655 ;:BRANCH IF NO TIMEOUT
1379 002566 012716 002574 645: MOV #655, (SP) ;:SET UP FOR TRAP RETURN
1380 002572 000002 RTI
1381 002574 012737 000176 001140 655: MOV #SWREG, SWR ;:POINT TO SOFTWARE SWR
1382 002602 012737 000174 001142 MOV #DISPREG, DISPLAY
1383 002610 012637 000004 665: MOV (SP)+, #ERRVEC ;:RESTORE ERROR VECTOR
1384
1385 002614 005037 001100 CLR SPASS ;:CLEAR THE PASS COUNT
1386 002620 005227 177777 INC #1 ;:FIRST START ?
1387 002624 001042 BNE 15 ;:BR IF NOT
1388 002626 103441 BCS 15 ;:BR IF NOT
1389 002630 104401 002636 TYPE ,685 ;:TYPE ASCIZ STRING
1390 002634 000431 BR 675 ;:GET OVER THE ASCIZ
1391 ;:685: .ASCIZ <15><12><12>/MAINDEC-11-DZRPW-B, RP11-E DISKLESS LOGIC TEST/
1392 002720 675:
1393 002720 005737 000042 TST #42 ;:UNDER MONITOR CONTROL ?
1394 002724 001002 BNE 15 ;:BR IF YES
1395 002726 104401 022115 TYPE ,DRVOL ;:TYPE ONLINE MESSAGE
1396 002732 15:
1397 ;.SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
1398 002732 005737 000042 TST #42 ;:ARE WE RUNNING UNDER XXDP/ACT?
1399 002736 001006 BNE 695 ;:BRANCH IF YES
1400 002740 023727 001140 000176 CMP SWR, #SWREG ;:SOFTWARE SWITCH REG SELECTED?
1401 002746 001005 BNE 705 ;:BRANCH IF NO
1402 002750 104406 GTSWR ;:GET SOFT-SWR SETTINGS
1403 002752 000403 BR 705
1404 002754 112737 000001 001134 695: MOVVB #1, SAUTOB ;:SET AUTO-MODE INDICATOR
1405 002762 705:
1406 002762 004737 021376 JSR PC, GETADR ;:CHECK THE BUS ADDRESS
1407 002766 013777 001216 176220 MOV RPPRIO, #RPVEC+2 ;:SETUP RP11 PRIORITY
1408 002774 104401 001173 RSTART: TYPE ,SCRLF ;:CR-LF
1409 003000 005037 000000 CLR #0 ;:CLEAR LOCATION 0
1410 003004 005077 176202 CLR #RPVEC ;:SETUP VECTOR TO LOCATION 0
1411 003010 013704 001210 MOV RPADR, R4 ;:LOAD RP11 ADDRESS POINTER
1412 003014 012764 000000 000004 MOV #0, RPS(R4) ;:SELECT DRIVE 0
1413 003022 032754 020000 000000 BIT #BIT13, RPS(R4) ;:DRIVE 0 AN RPO3 ?
1414 003030 001007 BNE 15 ;:BR IF NOT
1415 003032 012737 000312 001176 MOV #202., MAXCYL ;:SET MAXIMUM CYLINDER ADDRESS TO 202
1416 003040 012737 000400 001200 MOV #256., MAXPAT ;:CYLINDER BITS TO BE TESTED
1417 003046 000406 BR 25 ;:CONTINUE
1418 003050 012737 000625 001176 15: MOV #405., MAXCYL ;:SET MAXIMUM CYLINDER ADDRESS TO 405
    
```

```

1419 003056 012737 001000 001200      MOV      #512, MAXPAT      ;CYLINDER BITS TO BE TESTED
1420 003064 012737 003064 001110 2S:    MOV      #, SLPERR        ;LOAD LOOP ON ERROR ADDRESS
1421 003072 012737 003072 001106      MOV      #, SLPADR        ;LOAD LOOP ON TEST ADDRESS
1422 003100 012737 000340 177776      MOV      #PR7, PSW        ;SET PROCESSOR PRIORITY TO MAXIMUM
1423 003106 005037 001102      CLR      STSTNM           ;CLEAR TEST NUMBER
1424 003112 005037 001104      CLR      SICNT            ;CLEAR ITERATION COUNT
1425 003116 000137 003122      JMP      TSTO             ;START TEST 0

```

.SBTTL ##### START OF TESTS #####

;#TEST 0 CONTROLLER RESET TEST

;#TEST THAT 'RESET' CLEARS THE CONTROLLER.

TSTO:

```

1437 003122      NOP
1438 003122 000240      MOV      #RESRP, SLPADR   ;LOAD LOOP ON TEST ADDRESS
1439 003124 012737 003152 001106      MOV      #RESRP, SLPERR   ;LOAD ERROR LOOP ADDRESS
1440 003132 012737 003152 001110      MOV      RPADR, R4        ;RP11E BUS ADDRESS
1441 003140 013704 001210      MOV      #2, STIMES       ;DO 2 ITERATIONS
1442 003144 012737 000002 001162 RESRP:  MOV      #STACK, SP      ;SETUP THE STACK POINTER
1443 003152 012706 001100      MOV      #176556, RPER(R4) ;LOAD RPER
1444 003156 012764 176656 000002      MOV      #37576, RPCS(R4) ;LOAD RPCS
1445 003164 012764 037576 000004      MOV      #-1, RPWC(R4)    ;LOAD RPWC
1446 003172 012764 177777 000006      MOV      #-1, RPBA(R4)    ;LOAD RPBA
1447 003200 012764 177777 000010      MOV      #777, RPCA(R4)   ;LOAD RPCA
1448 003206 012764 000777 000012      MOV      #17417, RPDA(R4) ;LOAD RPDA
1449 003214 012764 017417 000014      JSR      PC, SAVRP        ;SAVE THE RP11 REGISTERS
1450 003222 004737 022014
1451 003226      MOV      #RPER, SBDADR   ;REGISTER ADDRESS INDEX
1452 003226 012737 000002 001122      ADD      R4, SBDADR      ;FORM REGISTER ADDRESS
1453 003234 060437 001122      MOV      #176656, SGDDAT ;GOOD DATA
1454 003240 012737 176656 001124      MOV      #RPER, SDDAT    ;CONTENTS TO BE CHECKED
1455 003246 013737 001222 001126      BIS      SDDAT, SGDDAT   ;SET UNUSED BITS FOR TYPEOUT
1456 003254 053737 001126 001124      CMP      SGDDAT, SDDAT   ;DID RPER LOAD PROPERLY ?
1457 003262 023737 001124 001126      BEQ      2S              ;BR IF IT DID
1458 003270 001401      BEQ      2S              ;BR IF IT DID
1459 003272 104002      ERROR    2              ;COULD NOT LOAD RPER CORRECTLY
1460 003274
1461 003274 012737 000004 001122 2S:    MOV      #RPCS, SBDADR   ;REGISTER ADDRESS INDEX
1462 003302 060437 001122      ADD      R4, SBDADR      ;FORM REGISTER ADDRESS
1463 003306 012737 177776 001124      MOV      #177776, SGDDAT ;GOOD DATA
1464 003314 013737 001224 001126      MOV      #RPCS, SDDAT    ;CONTENTS TO BE CHECKED
1465 003322 053737 001126 001124      BIS      SDDAT, SGDDAT   ;SET UNUSED BITS FOR TYPEOUT
1466 003330 023737 001124 001126      CMP      SGDDAT, SDDAT   ;DID RPCS LOAD PROPERLY ?
1467 003336 001401      BEQ      3S              ;BR IF IT DID
1468 003340 104002      ERROR    2              ;COULD NOT LOAD RPCS CORRECTLY
1469 003342
1470 003342 012737 000006 001122 3S:    MOV      #RPWC, SBDADR   ;REGISTER ADDRESS INDEX
1471 003350 060437 001122      ADD      R4, SBDADR      ;FORM REGISTER ADDRESS
1472 003354 012737 177777 001124      MOV      #-1, SGDDAT     ;GOOD DATA
1473 003362 013737 001226 001126      MOV      #RPWC, SDDAT    ;CONTENTS TO BE CHECKED
1474 003370 053737 001126 001124      BIS      SDDAT, SGDDAT   ;SET UNUSED BITS FOR TYPEOUT

```



```

1531 003752 104003          ERROR 3          ;RESET DIDN'T CLEAR INDICATED REGISTER
1532 003754 012737 000016 001122  MOV      #RPM1,SBDADR ;REGISTER ADDRESS INDEX VALUE
1533 003762 060437 001122          ADD      R4,SBDADR   ;FORM REGISTER ADDRESS
1534 003766 013737 001236 001126  MOV      #RPM1,SDDAT ;REGISTER VALUE FOR TYPEOUT
1535 003774 042737 004000 001126  BIC      #4000,SDDAT  ;CLEAR THE INPUT READY BIT
1536 004002 023737 001124 001126  CMP      $GDDAT,SDDAT ;IS RPM1 CLEAR ?
1537 004010 001401          BEQ      +4          ;BR IF IT IS
1538 004012 104003          ERROR 3          ;RESET DIDN'T CLEAR INDICATED REGISTER
1539 004014 012737 000014 001122  MOV      #RPA, SBDADR ;REGISTER ADDRESS INDEX VALUE
1540 004022 060437 001122          ADD      R4,SBDADR   ;FORM REGISTER ADDRESS
1541 004026 013737 001234 001126  MOV      #RPA, SDDAT  ;REGISTER CONTENTS FOR TYPEOUT
1542 004034 042737 000360 001126  BIC      #360,SDDAT  ;CLEAR THE 'SOT' BITS
1543 004042 023737 001124 001126  CMP      $GDDAT,SDDAT ;IS REGISTER RPA CLEAR ?
1544 004050 001401          BEQ      +4          ;BR IF IT IS
1545 004052 104003          ERROR 3          ;RESET DIDN'T CLEAR INDICATED REGISTER
1546 004054 012737 000200 001124  MOV      #200,$GDDAT  ;EXPECTED VALUE
1547 004062 013737 001224 001126  MOV      #RPCS,SDDAT ;REGISTER CONTENTS FOR TYPEOUT
1548 004070 023737 001124 001126  CMP      $GDDAT,SDDAT ;CONTENTS CORRECT ?
1549 004076 001401          BEQ      BS         ;BR IF CORRECT
1550 004100 104003          ERROR 3          ;RESET DIDN'T CLEAR INDICATED REGISTER
1551 004102 000004          BS:          SCOPE ;LOOP ?

```

```

;*****
;#TEST 1          TEST SETTING 'SUOL' (SELECTED UNIT ONLINE)
;*****

```

```

1557 004104          TEST1:
1558 004104 000240          NOP
1559 004106 012737 004130 001106  MOV      #SETOL,SLPADR ;LOAD LOOP ON TEST ADDRESS
1560 004114 012737 004130 001110  MOV      #SETOL,SLPERR ;LOAD ERROR LOOP ADDRESS
1561 004122 013704 001210          MOV      RPADR,R4     ;RPIIE BUS ADDRESS
1562 004126 000005          RESET              ;CLEAR THE CONTROLLER
1563 004130 012706 001100          SETOL: MOV      #STACK,SP   ;SETUP THE STACK POINTER
1564 004134 004737 021706          JSR      PC,CLR      ;CLEAR THE CONTROLLER
1565 004140 052764 020000 000022  BIS      #BIT13,RPM3(R4);SET MAINT UNIT ONLINE
1566 004146 004737 022014          JSR      PC,SAVR     ;SAVE THE RPIIE REGISTERS
1567 004152 032737 040000 001220  BIT      #BIT14,SRPDS ;DID SELECTED UNIT ONLINE SET ?
1568 004160 001002          BNE      1$         ;BRANCH IF SET
1569 004162 104102          ERROR 102         ;SELECTED UNIT ONLINE NOT SET
1570 004164 000412          BR      2$         ;BYPASS REST OF CHECKS
1571 004166 042764 020000 000022  1$: BIC      #BIT13,RPM3(R4);CLEAR MAINT UNIT ONLINE
1572 004174 004737 022014          JSR      PC,SAVR     ;SAVE THE RPIIE REGISTERS
1573 004200 032737 040000 001220  BIT      #BIT14,SRPDS ;DID SELECTED UNIT ONLINE CLEAR?
1574 004206 001401          BEQ      2$         ;SELECTED UNIT ONLINE DID NOT CLEAR
1575 004210 104103          ERROR 103         ;LOOP ?
1576 004212 000004          2$: SCOPE
1577 004214 052764 020000 000022  BIS      #BIT13,RPM3(R4);SET MAINT DRIVE ONLINE

```

```

;*****
;#TEST 2          CONTROLLER CLEAR TEST
;*****

```

```

1583 ;#TEST THE ABILITY OF BIT 0 OF RPCS TO CLEAR THE CONTROLLER
1584 ;#WHEN THE COMMAND BITS ARE 0.
;*****

```


1643	004606	053737	001126	001124	BIS	\$BDDAT,\$GDDAT	:SET UNUSED BITS FOR TYPEOUT	
1644	004614	023737	001124	001126	CMP	\$GDDAT,\$SBDDAT	:DID RPCA LOAD PROPERLY ?	
1645	004622	001401			BEQ	65	:BR IF IT DID	
1646	004624	104002			ERROR	2	:COULD NOT LOAD RPCA CORRECTLY	
1647	004626							
1648	004626	012737	000014	001122	65:	MOV	;\$RPDA,\$BDADR	:REGISTER ADDRESS INDEX
1649	004634	060437	001122		ADD	R4,\$BDADR	:FORM REGISTER ADDRESS	
1650	004640	012737	017417	001124	MOV	;\$17417,\$GDDAT	:GOOD DATA	
1651	004646	013737	001234	001126	MOV	;\$RPDA,\$BDDAT	:CONTENTS TO BE CHECKED	
1652	004654	053737	001126	001124	BIS	\$BDDAT,\$GDDAT	:SET UNUSED BITS FOR TYPEOUT	
1653	004662	023737	001124	001126	CMP	\$GDDAT,\$SBDDAT	:DID RPDA LOAD PROPERLY ?	
1654	004670	001401			BEQ	75	:BR IF IT DID	
1655	004672	104002			ERROR	2	:COULD NOT LOAD RPDA CORRECTLY	
1656	004674	012737	060001	001206	75:	MOV	;\$BIT14!BIT13!BIT00,\$IPL	
1657	004702	112764	000001	000004	MOV	;\$1,\$RPCS(R4)	:SET THE 'GO' BIT	
1658	004710	004737	021756		JSR	PC,\$T3P	:GENERATE 3 CLOCK PULSES	
1659	004714	004737	022014		JSR	PC,\$SAVRP	:SAVE THE RPIIE REGISTERS	
1660	004720	032737	002000	001222	BIT	;\$BIT10,\$RPER	:DID 'PROG' SET WITH CLEAR ?	
1661	004726	001401			BEQ	95	:BR IF NOT	
1662	004730	104112			ERROR	112		
1663	004732	005037	001124		95:	CLR	\$GDDAT	:EXPECTED VALUE
1664	004736	012737	000002	001122	MOV	;\$RPER,\$BDADR	:REGISTER ADDRESS INDEX VALUE	
1665	004744	060437	001122		ADD	R4,\$BDADR	:FORM REGISTER ADDRESS	
1666	004750	013737	001222	001126	MOV	;\$RPER,\$BDDAT	:REGISTER VALUE FOR TYPEOUT	
1667	004756	023737	001124	001126	CMP	\$GDDAT,\$SBDDAT	:IS REGISTER RPER CLEAR ?	
1668	004764	001401			BEQ	.\$+4	:BR IF IT IS	
1669	004766	104004			ERROR	4	:CONTROLLER CLEAR DIDN'T CLEAR INDICATED REGISTER	
1670	004770	012737	000006	001122	MOV	;\$RPWC,\$BDADR	:REGISTER ADDRESS INDEX VALUE	
1671	004776	060437	001122		ADD	R4,\$BDADR	:FORM REGISTER ADDRESS	
1672	005002	013737	001226	001126	MOV	;\$RPWC,\$BDDAT	:REGISTER VALUE FOR TYPEOUT	
1673	005010	023737	001124	001126	CMP	\$GDDAT,\$SBDDAT	:IS REGISTER RPWC CLEAR ?	
1674	005016	001401			BEQ	.\$+4	:BR IF IT IS	
1675	005020	104004			ERROR	4	:CONTROLLER CLEAR DIDN'T CLEAR INDICATED REGISTER	
1676	005022	012737	000010	001122	MOV	;\$RPBA,\$BDADR	:REGISTER ADDRESS INDEX VALUE	
1677	005030	060437	001122		ADD	R4,\$BDADR	:FORM REGISTER ADDRESS	
1678	005034	013737	001230	001126	MOV	;\$RPBA,\$BDDAT	:REGISTER VALUE FOR TYPEOUT	
1679	005042	023737	001124	001126	CMP	\$GDDAT,\$SBDDAT	:IS REGISTER RPBA CLEAR ?	
1680	005050	001401			BEQ	.\$+4	:BR IF IT IS	
1681	005052	104004			ERROR	4	:CONTROLLER CLEAR DIDN'T CLEAR INDICATED REGISTER	
1682	005054	012737	000012	001122	MOV	;\$RPCA,\$BDADR	:REGISTER ADDRESS INDEX VALUE	
1683	005062	060437	001122		ADD	R4,\$BDADR	:FORM REGISTER ADDRESS	
1684	005066	013737	001232	001126	MOV	;\$RPCA,\$BDDAT	:REGISTER VALUE FOR TYPEOUT	
1685	005074	023737	001124	001126	CMP	\$GDDAT,\$SBDDAT	:IS REGISTER RPCA CLEAR ?	
1686	005102	001401			BEQ	.\$+4	:BR IF IT IS	
1687	005104	104004			ERROR	4	:CONTROLLER CLEAR DIDN'T CLEAR INDICATED REGISTER	
1688	005106	012737	000016	001122	MOV	;\$RPM1,\$BDADR	:REGISTER ADDRESS INDEX VALUE	
1689	005114	060437	001122		ADD	R4,\$BDADR	:FORM REGISTER ADDRESS	
1690	005120	013737	001236	001126	MOV	;\$RPM1,\$BDDAT	:REGISTER VALUE FOR TYPEOUT	
1691	005126	042737	004000	001126	BIC	;\$4000,\$BDDAT	:CLEAR THE INPUT READY BIT	
1692	005134	023737	001124	001126	CMP	\$GDDAT,\$SBDDAT	:IS RPM1 CLEAR ?	
1693	005142	001401			BEQ	.\$+4	:BR IF IT IS	
1694	005144	104004			ERROR	4	:CONTROLLER CLEAR DIDN'T CLEAR INDICATED REGISTER	
1695	005146	012737	000014	001122	MOV	;\$RPDA,\$BDADR	:REGISTER ADDRESS INDEX VALUE	
1696	005154	060437	001122		ADD	R4,\$BDADR	:FORM REGISTER ADDRESS	
1697	005160	013737	001234	001126	MOV	;\$RPDA,\$BDDAT	:REGISTER VALUE FOR TYPEOUT	
1698	005166	042737	000360	001126	BIC	;\$360,\$BDDAT	:CLEAR THE 'SOT' BITS	


```

1699 005174 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;IS REGISTER RPDA CLEAR ?
1700 005202 001401                      BEQ      .+4                ;BR IF IT IS
1701 005204 104004                      ERROR    4                  ;CONTROLLER CLEAR DIDN'T CLEAR INDICATED REGISTER
1702 005206 012737 000200 001124      MOV      #200,$GDDAT        ;EXPECTED VALUE
1703 005214 013737 001224 001126      MOV      $RPCS,$BDDAT       ;REGISTER CONTENTS FOR TYPEOUT
1704 005222 023737 001124 001126      CMP      $GDDAT,$BDDAT     ;CONTENTS CORRECT ?
1705 005230 001401                      BEQ      $S                ;BR IF CORRECT
1706 005232 104004                      ERROR    4                  ;CONTROLLER CLEAR DIDN'T CLEAR INDICATED REGISTER
1707 005234 052764 020000 000022  $S:    BIS      #BIT13,$RPM3($R4) ;SET MAINTENANCE DRIVE ONLINE
1708 005242 000004                      SCOPE

```

```

;#THE FOLLOWING 6 TESTS TEST LOADING AND READING OF ALL POSSIBLE
;#BITS IN REGISTERS RPER, RPCS, RPWC, RPBA, RPCA AND
;#RPDA USING FLOATING 1'S AND FLOATING 0'S PATTERNS.

```

```

;*****
;#TEST 3      TEST BITS IN 'RPER'

```

```

;*****
;#TEST 3:

```

```

1719 005244                      ;#TEST 3:
1720 005244 000240                      NOP
1721 005246 012737 005274 001106      MOV      #15,$LPADR        ;LOAD LOOP ON TEST ADDRESS
1722 005254 012737 005324 001110      MOV      #ERBT,$LPERR      ;LOAD ERROR LOOP ADDRESS
1723 005262 013704 001210                      MOV      $RPAR,$R4         ;RP11E BUS ADDRESS
1724 005266 012737 000012 001162      MOV      #10,$TIMES        ;DO 10. ITERATIONS
1725 005274                      ;#TEST 3:
1726 005274 012706 001100                      MOV      #STACK,$SP        ;SETUP THE STACK POINTER
1727 005300 004737 021706                      JSR      PC,$CLR           ;CLEAR THE CONTROLLER
1728 005304 010437 001122                      MOV      $R4,$BDDADR       ;RP11 ADDRESS
1729 005310 062737 000002 001122      ADD      #RPER,$BDDADR     ;FORM ADDRESS OF REGISTER BEING CHECKED
1730 005316 012700 000001                      MOV      #1,$RO           ;BEGINNING TEST PATTERN
1731 005322 005001                      CLR      $R1              ;FLOATING 1'S INDICATOR
1732 005324 010037 001124 001124      ERBT:  MOV      $RO,$GDDAT   ;REFERENCE PATTERN
1733 005330 042737 001121 001124      BIC      #176656,$GDDAT    ;CLEAR UNUSED BITS
1734 005336 013764 001124 000002      MOV      $GDDAT,$RPER($R4) ;PUT PATTERN IN RPER
1735 005344 004737 022014                      JSR      PC,$SAVRP        ;SAVE THE RP11 REGISTERS
1736 005350 013737 001222 001126      MOV      $RPER,$BDDAT     ;VALUE FOR TYPEOUT IN CASE OF ERROR
1737 005356 013737 001222 001160      MOV      $RPER,$STMPD     ;WORKING LOCATION FOR CHECKING
1738 005364 042737 001121 001160      BIC      #176656,$STMPD   ;CLEAR UNUSED BITS
1739 005372 023737 001124 001160      CMP      $GDDAT,$STMPD    ;REGISTER LOADED OK ?
1740 005400 001403                      BEQ      $S                ;BR IF OK
1741 005402 104005                      ERROR    5                  ;FAILURE IN FLOATING 1'S & 0'S TEST
1742 005404 005064 000002                      CLR      $RPER($R4)       ;CLEAR THE REGISTER
1743 005410 005100 2S:  COM      $RO              ;COMPLIMENT TEST PATTERN
1744 005412 005101                      COM      $R1              ;COMPLIMENT PASS INDICATOR
1745 005414 001343                      BNE     ERBT              ;BR IF JUST FINISHED FLOATING 1'S PASS
1746 005416 006300                      ASL     $RO              ;SHIFT THE TEST PATTERN
1747 005420 103341                      BCC     ERBT              ;BR IF MORE TO DO
1748 005422 005064 000002                      CLR      $RPER($R4)       ;CLEAR THE REGISTER
1749 005426 000004                      SCOPE

```

```

;*****
;#TEST 4      TEST BITS IN 'RPCS'

```

```

;*****

```

```

1750
1751
1752
1753
1754

```

```

1755 005430          TST4:  NOP
1756 005430 000240      MOV      #15,SLPADR      ;LOAD LOOP ON TEST ADDRESS
1757 005432 012737 005460 001106      MOV      #CSBT,SLPERR   ;LOAD ERROR LOOP ADDRESS
1758 005440 012737 005510 001110      MOV      RPADR,R4      ;RP11E BUS ADDRESS
1759 005446 013704 001210          MOV      #10.,$TIMES   ;;DO 10. ITERATIONS
1760 005452 012737 000012 001162      1S:
1761 005460          MOV      #STACK,SP     ;SETUP THE STACK POINTER
1762 005460 012706 001100      JSR      PC,CLRP      ;CLEAR THE CONTROLLER
1763 005464 004737 021706      MOV      R4,$BDADR    ;RP11 ADDRESS
1764 005470 010437 001122          ADD      #RPCS,$BDADR  ;FORM ADDRESS OF REGISTER BEING CHECKED
1765 005474 062737 000004 001122      MOV      #1,RD        ;BEGINNING TEST PATTERN
1766 005502 012700 000001          CLR      R1           ;FLOATING 1'S INDICATOR
1767 005506 005001          MOV      RD,$GDDAT    ;REFERENCE PATTERN
1768 005510 010037 001124      BIC      #1C37576,$GDDAT ;CLEAR UNUSED BITS
1769 005514 042737 140201 001124      MOV      $GDDAT,RPCS(R4) ;PUT PATTERN IN RPCS
1770 005522 013764 001124 000004      JSR      PC,SAVRP     ;SAVE THE RP11 REGISTERS
1771 005530 004737 022014          MOV      #SRPCS,$BDAT ;VALUE FOR TYPEOUT IN CASE OF ERROR
1772 005534 013737 001224 001126      MOV      #SRPCS,$TMPD ;WORKING LOCATION FOR CHECKING
1773 005542 013737 001224 001160      BIC      #1C37576,$TMPD ;CLEAR UNUSED BITS
1774 005550 042737 140201 001160      CMP      $GDDAT,$TMPD ;REGISTER LOADED OK ?
1775 005556 023737 001124 001160      BEQ      2S           ;BR IF OK
1776 005564 001403          ERROR      5          ;FAILURE IN FLOATING 1'S & 0'S TEST
1777 005566 104005          CLR      RPCS(R4)    ;CLEAR THE REGISTER
1778 005570 005064 000004      COM      RD           ;COMPLIMENT TEST PATTERN
1779 005574 005100 2S:          COM      R1           ;COMPLIMENT PASS INDICATOR
1780 005576 005101          BNE      CSBT        ;BR IF JUST FINISHED FLOATING 1'S PASS
1781 005600 001343          ASL      RD           ;SHIFT THE TEST PATTERN
1782 005602 006300          BCC      CSBT        ;BR IF MORE TO DO
1783 005604 103341          CLR      RPCS(R4)    ;CLEAR THE REGISTER
1784 005606 005064 000004      SCOPE
1785 005612 000004          ;LOOP ?

```

```

;:*****
;#TEST 5 TEST BITS IN 'RPMC'

```

```

;:*****
;#TESTS:

```

```

1791 005614          TSTS:  NOP
1792 005614 000240      MOV      #15,SLPADR      ;LOAD LOOP ON TEST ADDRESS
1793 005616 012737 005644 001106      MOV      #MCBT,SLPERR   ;LOAD ERROR LOOP ADDRESS
1794 005624 012737 005674 001110      MOV      RPADR,R4      ;RP11E BUS ADDRESS
1795 005632 013704 001210          MOV      #10.,$TIMES   ;;DO 10. ITERATIONS
1796 005636 012737 000012 001162      1S:
1797 005644          MOV      #STACK,SP     ;SETUP THE STACK POINTER
1798 005644 012706 001100      JSR      PC,CLRP      ;CLEAR THE CONTROLLER
1799 005650 004737 021706      MOV      R4,$BDADR    ;RP11 ADDRESS
1800 005654 010437 001122          ADD      #RPMC,$BDADR  ;FORM ADDRESS OF REGISTER BEING CHECKED
1801 005660 062737 000006 001122      MOV      #1,RD        ;BEGINNING TEST PATTERN
1802 005666 012700 000001          CLR      R1           ;FLOATING 1'S INDICATOR
1803 005672 005001          MOV      RD,$GDDAT    ;REFERENCE PATTERN
1804 005674 010037 001124      BIC      #1C177777,$GDDAT ;CLEAR UNUSED BITS
1805 005700 042737 000000 001124      MOV      $GDDAT,RPMC(R4) ;PUT PATTERN IN RPMC
1806 005706 013764 001124 000006      JSR      PC,SAVRP     ;SAVE THE RP11 REGISTERS
1807 005714 004737 022014          MOV      #SRPMC,$BDAT ;VALUE FOR TYPEOUT IN CASE OF ERROR
1808 005720 013737 001226 001126      MOV      #SRPMC,$TMPD ;WORKING LOCATION FOR CHECKING
1809 005726 013737 001226 001160      BIC      #1C177777,$TMPD ;CLEAR UNUSED BITS
1810 005734 042737 000000 001160

```

1811	005742	023737	001124	001160	CMP	SGDDAT,STMPD	:REGISTER LOADED OK ?
1812	005750	001403			BEQ	ZS	:BR IF OK
1813	005752	104005			ERROR	S	:FAILURE IN FLOATING 1'S & 0'S TEST
1814	005754	005064	000006		CLR	RPWC(R4)	:CLEAR THE REGISTER
1815	005760	005100			COM	R0	:COMPLIMENT TEST PATTERN
1816	005762	005101			COM	R1	:COMPLIMENT PASS INDICATOR
1817	005764	001343			BNE	MCBT	:BR IF JUST FINISHED FLOATING 1'S PASS
1818	005766	006300			ASL	R0	:SHIFT THE TEST PATTERN
1819	005770	103341			BCC	MCBT	:BR IF MORE TO DO
1820	005772	005064	000006		CLR	RPWC(R4)	:CLEAR THE REGISTER
1821	005776	000004			SCOPE		:LOOP ?

:TEST 6 TEST BITS IN 'RPBA'

1827	006000				TST6:	
1828	006000	000240			NOP	
1829	006002	012737	006030	001106	MOV	#15,SLPADR :LOAD LOOP ON TEST ADDRESS
1830	006010	012737	006060	001110	MOV	#BAST,SLPERR :LOAD ERROR LOOP ADDRESS
1831	006016	013704	001210		MOV	RPADR,R4 :RP11E BUS ADDRESS
1832	006022	012737	000012	001162	MOV	#10.,\$TIMES ;;DO 10. ITERATIONS
1833	006030				1S:	
1834	006030	012706	001100		MOV	#STACK,SP :SETUP THE STACK POINTER
1835	006034	004737	021706		JSR	PC,CLR# :CLEAR THE CONTROLLER
1836	006040	010437	001122		MOV	R4,\$BDADR :RP11 ADDRESS
1837	006044	062737	000010	001122	ADD	#RPBA,\$BDADR :FORM ADDRESS OF REGISTER BEING CHECKED
1838	006052	012700	000001		MOV	#1,R0 :BEGINNING TEST PATTERN
1839	006056	005001			CLR	R1 :FLOATING 1'S INDICATOR
1840	006060	010037	001124		MOV	R0,SGDDAT :REFERENCE PATTERN
1841	006064	042737	000000	001124	BIC	#1C177777,SGDDAT :CLEAR UNUSED BITS
1842	006072	013764	001124	000010	MOV	SGDDAT,RPBA(R4) :PUT PATTERN IN RPBA
1843	006100	004737	022014		JSR	PC,SAVRP :SAVE THE RP11 REGISTERS
1844	006104	013737	001230	001126	MOV	SA#BA,\$BDADR :VALUE FOR TYPEOUT IN CASE OF ERROR
1845	006112	013737	001230	001160	MOV	SA#BA,STMPD :WORKING LOCATION FOR CHECKING
1846	006120	042737	000000	001160	BIC	#1C177777,STMPD :CLEAR UNUSED BITS
1847	006126	023737	001124	001160	CMP	SGDDAT,STMPD :REGISTER LOADED OK ?
1848	006134	001403			BEQ	ZS :BR IF OK
1849	006136	104005			ERROR	S :FAILURE IN FLOATING 1'S & 0'S TEST
1850	006140	005064	000010		CLR	RPBA(R4) :CLEAR THE REGISTER
1851	006144	005100			COM	R0 :COMPLIMENT TEST PATTERN
1852	006146	005101			COM	R1 :COMPLIMENT PASS INDICATOR
1853	006150	001343			BNE	BAST :BR IF JUST FINISHED FLOATING 1'S PASS
1854	006152	006300			ASL	R0 :SHIFT THE TEST PATTERN
1855	006154	103341			BCC	BAST :BR IF MORE TO DO
1856	006156	005064	000010		CLR	RPBA(R4) :CLEAR THE REGISTER
1857	006162	000004			SCOPE	:LOOP ?

:TEST 7 TEST BITS IN 'RPCA'

1863	006164				TST7:	
1864	006164	000240			NOP	
1865	006166	012737	006214	001106	MOV	#15,SLPADR :LOAD LOOP ON TEST ADDRESS
1866	006174	012737	006244	001110	MOV	#CA#T,SLPERR :LOAD ERROR LOOP ADDRESS

E04

1867	006202	013704	001210		MOV	RPADR,R4	:RP11E BUS ADDRESS
1868	006206	012737	000012	001162	MOV	#10.,\$TIMES	::DO 10. ITERATIONS
1869	006214				15:		
1870	006214	012706	001100		MOV	#STACK,SP	:SETUP THE STACK POINTER
1871	006220	004737	021706		JSR	PC,CLRP	:CLEAR THE CONTROLLER
1872	006224	010437	001122		MOV	R4,SBDADR	:RP11 ADDRESS
1873	006230	062737	000012	001122	ADD	#RPCA,SBDADR	:FORM ADDRESS OF REGISTER BEING CHECKED
1874	006236	012700	000001		MOV	#1,R0	:BEGINNING TEST PATTERN
1875	006242	005001			CLR	R1	:FLOATING 1'S INDICATOR
1876	006244	010037	001124		MOV	R0,SGDDAT	:REFERENCE PATTERN
1877	006250	042737	177000	001124	BIC	#1C777,SGDDAT	:CLEAR UNUSED BITS
1878	006256	013764	001124	000012	MOV	SGDDAT,RPCA(R4)	:PUT PATTERN IN RPCA
1879	006264	004737	022014		JSR	PC,SAVRP	:SAVE THE RP11 REGISTERS
1880	006270	013737	001232	001126	MOV	SRPCA,SDDAT	:VALUE FOR TIMEOUT IN CASE OF ERROR
1881	006276	013737	001232	001160	MOV	SRPCA,STMPD	:WORKING LOCATION FOR CHECKING
1882	006304	042737	177000	001160	BIC	#1C777,STMPD	:CLEAR UNUSED BITS
1883	006312	023737	001124	001160	CMF	SGDDAT,STMPD	:REGISTER LOADED OK ?
1884	006320	001403			BEQ	ZS	:BR IF OK
1885	006322	104005			ERROR	S	:FAILURE IN FLOATING 1'S & 0'S TEST
1886	006324	005064	000012		CLR	RPCA(R4)	:CLEAR THE REGISTER
1887	006330	005100			COM	R0	:COMPLIMENT TEST PATTERN
1888	006332	005101			COM	R1	:COMPLIMENT PASS INDICATOR
1889	006334	001343			BNE	CABT	:BR IF JUST FINISHED FLOATING 1'S PASS
1890	006336	006300			ASL	R0	:SHIFT THE TEST PATTERN
1891	006340	103341			BCC	CABT	:BR IF MORE TO DO
1892	006342	005064	000012		CLR	RPCA(R4)	:CLEAR THE REGISTER
1893	006346	000004			SCOPE		:LOOP ?

::*****
 ;#TEST 10 TEST BITS IN 'RPDA'

::*****
 ;#ST10:

1899	006350				NOP		
1900	006350	000240			MOV	#1S,SLPADR	:LOAD LOOP ON TEST ADDRESS
1901	006352	012737	006400	001106	MOV	#DABT,SLPERR	:LOAD ERROR LOOP ADDRESS
1902	006360	012737	006430	001110	MOV	RPADR,R4	:RP11E BUS ADDRESS
1903	006366	013704	001210		MOV	#10.,\$TIMES	::DO 10. ITERATIONS
1904	006372	012737	000012	001162	15:		
1905	006400						
1906	006400	012706	001100		MOV	#STACK,SP	:SETUP THE STACK POINTER
1907	006404	004737	021706		JSR	PC,CLRP	:CLEAR THE CONTROLLER
1908	006410	010437	001122		MOV	R4,SBDADR	:RP11 ADDRESS
1909	006414	062737	000014	001122	ADD	#RPDA,SBDADR	:FORM ADDRESS OF REGISTER BEING CHECKED
1910	006422	012700	000001		MOV	#1,R0	:BEGINNING TEST PATTERN
1911	006426	005001			CLR	R1	:FLOATING 1'S INDICATOR
1912	006430	010037	001124		MOV	R0,SGDDAT	:REFERENCE PATTERN
1913	006434	042737	160360	001124	BIC	#1C17417,SGDDAT	:CLEAR UNUSED BITS
1914	006442	013764	001124	000014	MOV	SGDDAT,RPDA(R4)	:PUT PATTERN IN RPDA
1915	006450	004737	022014		JSR	PC,SAVRP	:SAVE THE RP11 REGISTERS
1916	006454	013737	001234	001126	MOV	SRPDA,SDDAT	:VALUE FOR TIMEOUT IN CASE OF ERROR
1917	006462	013737	001234	001160	MOV	SRPDA,STMPD	:WORKING LOCATION FOR CHECKING
1918	006470	042737	160360	001160	BIC	#1C17417,STMPD	:CLEAR UNUSED BITS
1919	006476	023737	001124	001160	CMF	SGDDAT,STMPD	:REGISTER LOADED OK ?
1920	006504	001403			BEQ	ZS	:BR IF OK
1921	006506	104005			ERROR	S	:FAILURE IN FLOATING 1'S & 0'S TEST
1922	006510	005064	000014		CLR	RPDA(R4)	:CLEAR THE REGISTER

```

1923 006514 005100      25:  COM      RO      ;COMPLIMENT TEST PATTERN
1924 006516 005101      COM      R1      ;COMPLIMENT PASS INDICATOR
1925 006520 001343      BNE      DABT    ;BR IF JUST FINISHED FLOATING 1'S PASS
1926 006522 006300      ASL      RO      ;SHIFT THE TEST PATTERN
1927 006524 103341      BCC      DABT    ;BR IF MORE TO DO
1928 006526 005064 000014  CLR      RPDAR(R4) ;CLEAR THE REGISTER
1929 006532 000004      SCOPE                    ;LOOP ?

```

```

;*****
;#TEST 11      'RPWC' RAPID ACCESS TEST
;*****

```

```

1935 006534      TST11:
1936 006534 000240      NOP
1937 006536 012737 006564 001106  MOV      #15,SLPADR ;LOAD LOOP ON TEST ADDRESS
1938 006544 012737 006622 001110  MOV      @RAPWC,SLPERR ;LOAD ERROR LOOP ADDRESS
1939 006552 013704 001210      MOV      RPDAR,R4 ;RP11E BUS ADDRESS
1940 006556 012737 000002 001162  MOV      #2,STIMES ;DO 2 ITERATIONS
1941 006564 012706 001100 18:  MOV      @STACK,SP ;SETUP THE STACK POINTER
1942 006570 012737 000006 001122  MOV      @RPWC,@SDADR ;INDEX OF REGISTER TESTED
1943 006576 060437 001122  ADD      R4,@SDADR ;ADD THE BUS ADDRESS
1944 006602 013701 001122  MOV      @SDADR,R1 ;COPY REGISTER ADDRESS
1945 006606 012737 006660 000004  MOV      @RAPWC1,@ERRVEC ;SETUP FOR END MEMORY TRAP
1946 006614 005000      CLR      RO ;SETUP START MEMORY LOCATION
1947 006616 004737 021706  JSR      PC,CLRP ;CLEAR THE RP11E
1948 006622 011011  RAPWC:  MOV      (RO),(R1) ;MOVE MEMORY TO REGISTER
1949 006624 011102      MOV      (R1),R2 ;READ THE REGISTER
1950 006626 020220      CMP      R2,(RO)+ ;TEST FOR PROPER VALUE IN REGISTER
1951 006630 001774      BEQ      RAPWC ;BR IF CORRECT
1952 006632 014037 001124  MOV      -(RO),SGDDAT ;MOVE GOOD DATA TO SGDDAT FOR TYP0UT
1953 006636 010237 001126  MOV      R2,@SDDAT ;MOVE REGISTER DATA TO @SDDAT FOR TYP0UT
1954 006642 104006  ERROR 6 ;REGISTER CONTENTS INCORRECT
1955 006644 032777 000200 172266 BIT      @SW07,@SWR ;PRINT ANY MORE ERRORS ?
1956 006652 001002      BNE      RAPWC1 ;BR IF NOT
1957 006654 005720      TST      (RO)+ ;CONTINUE TEST
1958 006656 000761      BR      RAPWC
1959 006660 012737 000006 000004  RAPWC1: MOV      @ERRVEC+2,@ERRVEC ;RESTORE TRAP CATCHER
1960 006666 012737 000340 177776  MOV      @PR7,@PSW ;RESTORE NO INTERRUPTS
1961 006674 005000      CLR      RO ;CLEAR THE REGISTER
1962 006676 000004      SCOPE                    ;LOOP ?

```

```

;*****
;#TEST 12      'RPBA' RAPID ACCESS TEST
;*****

```

```

1968 006700      TST12:
1969 006700 000240      NOP
1970 006702 012737 006730 001106  MOV      #15,SLPADR ;LOAD LOOP ON TEST ADDRESS
1971 006710 012737 006766 001110  MOV      @RAPBA,SLPERR ;LOAD ERROR LOOP ADDRESS
1972 006716 013704 001210      MOV      RPDAR,R4 ;RP11E BUS ADDRESS
1973 006722 012737 000002 001162  MOV      #2,STIMES ;DO 2 ITERATIONS
1974 006730 012706 001100 18:  MOV      @STACK,SP ;SETUP THE STACK POINTER
1975 006734 012737 000010 001122  MOV      @RPBA,@SDADR ;INDEX OF REGISTER TESTED
1976 006742 060437 001122  ADD      R4,@SDADR ;ADD THE BUS ADDRESS
1977 006746 013701 001122  MOV      @SDADR,R1 ;COPY REGISTER ADDRESS
1978 006752 012737 007024 000004  MOV      @RAPBA1,@ERRVEC ;SETUP FOR END MEMORY TRAP

```

```

1979 006760 005000          CLR      R0          ;SETUP START MEMORY LOCATION
1980 006762 004737 021706  JSR      PC,CLRP    ;CLEAR THE RP11E
1981 006766 011011          MOV      (R0),(R1)  ;MOVE MEMORY TO REGISTER
1982 006770 011102          MOV      (R1),R2   ;READ THE REGISTER
1983 006772 020220          CMP      R2,(R0)+  ;TEST FOR PROPER VALUE IN REGISTER
1984 006774 001774          BEQ     RAPBA      ;BR IF CORRECT
1985 006776 014037 001124  MOV      -(R0),SGDAT ;MOVE GOOD DATA TO SGDAT FOR TYP0UT
1986 007002 010237 001126  MOV      R2,$BDAT  ;MOVE REGISTER DATA TO $BDAT FOR TYP0UT
1987 007006 104006          ERROR   6         ;REGISTER CONTENTS INCORRECT
1988 007010 032777 000200 172122 BIT      $SM07,$SMR ;PRINT ANY MORE ERRORS ?
1989 007016 001002          BNE     RAPBA1    ;BR IF NOT
1990 007020 005720          TST     (R0)+     ;CONTINUE TEST
1991 007022 000761          BR      RAPBA
1992 007024 012737 000006 000004 RAPBA1: MOV  $ERRVEC+2,$ERRVEC ;RESTORE TRAP CATCHER
1993 007032 012737 000340 177776  MOV      $PR7,$PSM ;RESTORE NO INTERRUPTS
1994 007040 005000          CLR      R0       ;CLEAR THE REGISTER
1995 007042 000004          SCOPE   ;LOOP ?

```

;#TEST 13 TEST SETTING 'SUROY' (SELECTED UNIT READY)

```

2000 *****
2001 007044          ;#TEST 13:
2002 007044 000240          ;#TEST 13:
2003 007046 012737 007066 001106  NOP
2004 007054 012737 007066 001110  MOV      $DSF1,$LPAOR ;LOAD LOOP ON TEST ADDRESS
2005 007062 013704 001210          MOV      $DSF1,$LPERA ;LOAD ERROR LOOP ADDRESS
2006 007066 012706 001100          MOV      RPAOR,R4    ;RP11E BUS ADDRESS
2007 007072 004737 021706          DSF1: MOV      $STACK,SP  ;SETUP THE STACK POINTER
2008 007076 052764 040000 000022 JSR      PC,CLRP    ;CLEAR THE CONTROLLER
2009 007104 004737 022014          BIS      $BIT14,$RPM3(R4) ;SET MAINT UNIT READY
2010 007110 032737 100000 001220 JSR      PC,SAVRP   ;SAVE THE RP11E REGISTERS
2011 007116 001002          BIT      $BIT15,$RPM5 ;DID SELEL. UNIT READY SET?
2012 007120 104007          BNE     1$        ;BRANCH IF SET
2013 007122 000412          ERROR   7         ;SELECTED UNIT READY NOT SET
2014 007124 042764 040000 000022 1$: BIC     $BIT14,$RPM3(R4) ;CLEAR MAINT UNIT READY
2015 007132 004737 022014          JSR      PC,SAVRP   ;SAVE THE RP11E REGISTERS
2016 007136 032737 100000 001220 BIT      $BIT15,$RPM5 ;DID SELECTED UNIT READ? CLEAR?
2017 007144 001401          BEQ     2$        ;SELECTED UNIT READY DID NOT CLEAR
2018 007146 104010          ERROR   10        ;LOOP ?
2019 007150 000004          2$: SCOPE

```

;#TEST 14 TEST SETTING OF 'SUSI' (SELECTED UNIT SEEK INCOMPLETE)

```

2020 *****
2021 *****
2022 *****
2023 *****
2024 *****
2025 *****
2026 007152          ;#TEST 14:
2027 007152 000240          ;#TEST 14:
2028 007154 012737 007174 001106  NOP
2029 007162 012737 007174 001110  MOV      $DSF4,$LPAOR ;LOAD LOOP ON TEST ADDRESS
2030 007170 013704 001210          MOV      $DSF4,$LPERA ;LOAD ERROR LOOP ADDRESS
2031 007174 012706 001100          MOV      RPAOR,R4    ;RP11E BUS ADDRESS
2032 007200 004737 021706          DSF4: MOV      $STACK,SP  ;SETUP THE STACK POINTER
2033 007204 052764 002000 000022 JSR      PC,CLRP    ;CLEAR THE CONTROLLER
2034 007212 004737 022014          BIS      $BIT10,$RPM3(R4) ;SET MAINT. SEEK INCOMPLETE
                JSR      PC,SAVRP ;SAVE THE RP11E REGISTERS

```

```

2035 007216 032737 004000 001220 BIT #BIT11,SRPDS ;DID SEEK INCOMPLETE SET?
2036 007224 001002 BNE 15
2037 007226 104011 ERROR 11 ;SEEK INCOMPLETE DID NOT SET
2038 007230 000426 BR 45 ;BYPASS REST OF THE TEST
2039 007232 032737 000001 001222 15: BIT #BIT00,SRPER ;DID DISK ERROR SET?
2040 007240 001001 BNE 25 ;BR IF YES
2041 007242 104012 ERROR 12 ;DISK ERROR DID NOT SET AFTER SUSI
2042 007244
2043 007244 013746 001224 MOV SRPCS,-(SP) ;PUT CONTENTS OF RPCS ON THE STACK
2044 007250 005116 COM (SP) ;COMPLEMENT THE CONTENTS
2045 007252 032726 140000 BIT #BIT15:BIT14,(SP)+ ;CHECK 'ERR' AND 'HE' BITS
2046 007256 001401 BEQ 35 ;BR IF BOTH SET
2047 007260 104013 ERROR 13 ;'ERR' OR 'HE' DIDN'T SET WITH 'SUSI'
2048 007262 042764 002000 000022 35: BIC #BIT10,RPM3(R4) ;CLEAR 'SUSI'
2049 007270 004737 022014 JSR PC,SAVRP ;SAVE THE RP11E REGISTERS
2050 007274 032737 004000 001220 BIT #BIT11,SRPDS ;DID SEEK INCOMPLETE CLEAR?
2051 007302 001401 BEQ 45 ;BRANCH IF CLEAR
2052 007304 104045 ERROR 45 ;SEEK INCOMPLETE DID NOT CLEAR
2053 007306 000004 45: SCOPE ;LOOP ?

```

```

;*****
;#TEST 15 TEST SETTING OF 'SUSU' (SELECTED UNIT SEEK UNDERWAY

```

```

;*****
;#TEST 15:
2059 007310 NOP
2060 007310 000240 MOV #DSF6,SLPADR ;LOAD LOOP ON TEST ADDRESS
2061 007312 012737 007332 001106 MOV #DSF6,SLPERR ;LOAD ERROR LOOP ADDRESS
2062 007320 012737 007332 001110 MOV RPADR,R4 ;RP11E BUS ADDRESS
2063 007326 013704 001210 DSF6: MOV #STACK,SP ;SETUP THE STACK POINTER
2064 007332 012706 001100 JSR PC,CLRP ;CLEAR THE CONTROLLER
2065 007336 004737 021706 BIC #BIT14,RPM3(R4) ;RESET MAINT READY
2066 007342 042764 040000 000022 BIS #BIT13,RPM3(R4) ;SET MAINT DRIVE ONLINE
2067 007350 052764 020000 000022 JSR PC,SAVRP ;SAVE THE RP11E REGISTERS
2068 007356 004737 022014 BIT #BIT10,SRPDS ;DID 'SUSU' SET ?
2069 007362 032737 002000 001220 BNE 15
2070 007370 001002 ERROR 104 ;'SUSU' DIDN'T SET
2071 007372 104104 BR 25 ;BYPASS REST OF THE TEST
2072 007374 000412 BIS #BIT14,RPM3(R4) ;SET MAINT READY
2073 007376 052764 040000 000022 15: JSR PC,SAVRP ;SAVE THE RP11E REGISTERS
2074 007404 004737 022014 BIT #BIT10,SRPDS ;DID 'SUSU' RESET ?
2075 007410 032737 002000 001220 BEQ 25 ;BR IF IT DID
2076 007416 001401 ERROR 105 ;'SUSU' DIDN'T CLEAR
2077 007420 104105 25: SCOPE ;LOOP ?
2078 007422 000004

```

```

;*****
;#TEST 16 TEST SETTING OF 'SUFU' (SELECTED UNIT FILE UNSAFE

```

```

;*****
;#TEST 16:
2084 007424 NOP
2085 007424 000240 MOV #DSF7,SLPADR ;LOAD LOOP ON TEST ADDRESS
2086 007426 012737 007446 001106 MOV #DSF7,SLPERR ;LOAD ERROR LOOP ADDRESS
2087 007434 012737 007446 001110 MOV RPADR,R4 ;RP11E BUS ADDRESS
2088 007442 013704 001210 DSF7: MOV #STACK,SP ;SETUP THE STACK POINTER
2089 007446 012706 001100 JSR PC,CLRP ;CLEAR THE CONTROLLER
2090 007452 004737 021706

```

```

2091 007456 052764 004000 000022      BIS      #BIT11,RPM3(R4) ;SET MAINT. FILE UNSAFE
2092 007464 004737 022014      JSR      PC,SAVRP ;SAVE THE RP11E REGISTERS
2093 007470 032737 001000 001220      BIT      #BIT09,SRPDS ;DID FILE UNSAFE SET?
2094 007476 001002      BNE      15
2095 007500 104014      ERROR   14 ;FILE UNSAFE DID NOT SET
2096 007502 000412      BR       25 ;BYPASS REST OF THE TEST
2097 007504 042764 004000 000022 15:      BIC      #BIT11,RPM3(R4) ;CLEAR 'SUFU'
2098 007512 004737 022014      JSR      PC,SAVRP ;SAVE THE RP11E REGISTERS
2099 007516 032737 001000 001220      BIT      #BIT09,SRPDS ;IS FILE UNSAFE CLEAR?
2100 007524 001401      BEQ     25
2101 007526 104015      ERROR   15 ;FILE UNSAFE DID NOT CLEAR
2102 007530 000004      25:     SCOPE ;LOOP ?
2103
2104      ::*****
2105      ;*TEST 17 TEST 'SUMP' (SELECTED UNIT WRITE PROTECTED)
2106
2107      ::*****
2108      TST17:
2109      NOP
2110      MOV     #DSF11,SLPADR ;LOAD LOOP ON TEST ADDRESS
2111      MOV     #DSF11,SLPERR ;LOAD ERROR LOOP ADDRESS
2112      MOV     RPADR,R4 ;RP11E BUS ADDRESS
2113      MOV     #STACK,SP ;SETUP THE STACK POINTER
2114      JSR     PC,CLRP ;CLEAR THE CONTROLLER
2115      BIS     #BIT15,RPM3(R4) ;SET MAINT READ ONLY
2116      JSR     PC,SAVRP ;SAVE THE RP11E REGISTERS
2117      BIT     #BIT08,SRPDS ;DID WRITE PROTECT SET?
2118      BNE     15
2119      ERROR  16 ;WRITE PROTECT DID NOT SET
2120      BR      25 ;BYPASS REST OF THE TEST
2121      BIC     #BIT15,RPM3(R4) ;CLEAR MAINTENANCE READ ONLY
2122      JSR     PC,SAVRP ;SAVE THE RP11E REGISTERS
2123      BIT     #BIT08,SRPDS ;DID WRITE PROTECT CLEAR?
2124      BEQ     25
2125      ERROR  17 ;WRITE PROTECT DID NOT CLEAR
2126      25:     SCOPE ;LOOP ?

```



```

2127
2128
2129
2130
2131
2132 007640
2133 007640 000240
2134 007642 012737 007670 001106
2135 007650 012737 007702 001110
2136 007656 013704 001210
2137 007662 012737 000012 001162
2138 007670 012706 001100
2139 007674 012737 000001 001124
2140 007702 012737 007702 001110
2141 007710 004737 021706
2142 007714 012764 000377 000000
2143 007722 013764 001124 000020
2144 007730 004737 022014
2145 007734 123737 001124 001220
2146 007742 001404
2147 007744 113737 001220 001126
2148 007752 104020
2149 007754 012737 007754 001110
2150 007762 013764 001124 000000
2151 007770 004737 022014
2152 007774 105737 001220
2153 010000 001401
2154 010002 104021
2155 010004 006337 001124
2156 010010 032737 000400 001124
2157 010016 001731
2158 010020 012737 010020 001110
2159 010026 012764 000377 000020
2160 010034 000005
2161 010036 105737 001220
2162 010042 001401
2163 010044 104022
2164 010046 005064 000020
2165 010052 012764 000377 000020
2166 010060 005064 000000
2167 010064 004737 022014
2168 010070 122737 000377 001220
2169 010076 001410
2170 010100 005037 001124
2171 010104 005037 001126
2172 010110 113737 001220 001126
2173 010116 104023
2174 010120 000004
2175
2176
2177
2178
2179
2180 010122
2181 010122 000240
2182 010124 012737 010144 001106

```

```

*****
;TEST 20 TEST SET AND CLEAR OF THE ATTENTION BITS
*****
TST20:
NOP
MOV #15,SLPADR ;LOAD LOOP ON TEST ADDRESS
MOV #DSF13,SLPERR ;LOAD ERROR LOOP ADDRESS
MOV RPADR,R4 ;RPIIE BUS ADDRESS
MOV #10,$TIMES ;DO 10 ITERATIONS
15: MOV #STACK,SP ;SETUP THE STACK POINTER
MOV #1,$GDDAT ;INITIALIZE ATTENTION BIT PATTERN
DSF13: MOV #DSF13,SLPERR ;CHANGE LOOP ON ERROR ADDRESS
JSR PC,CLAP ;CLEAR THE CONTROLLER
MOV #377,RPDS(R4) ;CLEAR ATTENTION BITS
MOV $GDDAT,RPMS(R4) ;SET MAINT ATTENTION BIT
JSR PC,SAVRP ;SAVE THE RPIIE REGISTERS
CMPB $GDDAT,$RPDS ;DID THE ATTN BIT SET IN RPDS?
BEQ 25 ;BRANCH IF OK
MOVB $RPDS,$SDDAT
ERROR 20 ;ATTENTION BIT DID NOT SET
25: MOV #25,SLPERR ;CHANGE LOOP ON ERROR ADDRESS
MOV $GDDAT,RPDS(R4) ;CLEAR ATTENTION BIT
JSR PC,SAVRP ;SAVE THE RPIIE REGISTERS
TSTB $RPDS ;DID IT CLEAR?
BEQ 35 ;BRANCH IF CLEAR
ERROR 21 ;ATTENTION BIT DID NOT CLEAR
35: ASL $GDDAT ;ROTATE PATTERN
BIT #BIT08,$GDDAT ;END OF PATTERN?
BEQ DSF13 ;BRANCH IF NO
45: MOV #45,SLPERR ;CHANGE LOOP ON ERROR ADDRESS
MOV #377,RPMS(R4) ;SET ATTENTION BITS
RESET
TSTB $RPDS ;DID RESET CLEAR ATTN BITS?
BEQ 55
ERROR 22 ;RESET DID NOT CLEAR ATTENTION BITS
55: CLR RPMS(R4)
MOV #377,RPMS(R4) ;SET ALL ATTENTION BITS
CLR RPDS(R4) ;ISSUE CLEAR RPDS
JSR PC,SAVRP ;SAVE THE RPIIE REGISTERS
CMPB #377,$RPDS ;DID ATTENTION BITS REMAIN SET?
BEQ 65 ;BRANCH IF YES
CLR $GDDAT
CLR $SDDAT
MOVB $RPDS,$SDDAT ;GET BAD DATA
ERROR 23 ;ATTENTION BITS CLEARED WITH A ZERO
65: SCOPE ;LOOP ?

```

```

*****
;TEST 21 TEST THE 'MPV' BIT (WRITE PROTECT VIOLATION)
*****
TST21:
NOP
MOV #ERF1,SLPADR ;LOAD LOOP ON TEST ADDRESS

```

```

2183 010132 012737 010144 001110      MOV      #ERF1,SLPERR      ;LOAD ERROR LOOP ADDRESS
2184 010140 013704 001210      MOV      RPADR,R4        ;RPIIE BUS ADDRESS
2185 010144 012706 001100      ERF1:  MOV      #STACK,SP  ;SETUP THE STACK POINTER
2186 010150 004737 021706      JSR      PC,CLRP         ;CLEAR THE CONTROLLER
2187 010154 052764 100000 000022  BIS      #BIT15,RPM3(R4) ;SET MAINT READ ONLY
2188 010162 012764 177777 000006  MOV      #-1,RPWC(R4)    ;SET WORD COUNT
2189 010170 112764 000003 000004  MOVVB   #3,RPCS(R4)     ;ISSUE A WRITE
2190 010176 012737 160001 001206  MOV      #BIT15!BIT14!BIT13!BIT00,TPL
2191 010204 004737 021756      JSR      PC,T3P          ;GENERATE 3 CLOCK PULSES
2192 010210 004737 022014      JSR      PC,SAVRP        ;SAVE THE RPIIE REGISTERS
2193 010214 032737 100000 001222  BIT      #BIT15,$RPER    ;DID WRITE VIOLATION SET?
2194 010222 001001      BNE     $                ;
2195 010224 104024      ERROR   24              ;WRITE PROTECTION VIOLATION DID NOT SET
2196 010226      IS:
2197 010226 013746 001224      MOV      $RPCS,-(SP)    ;PUT CONTENTS OF RPCS ON THE STACK
2198 010232 005116      COM     (SP)            ;COMPLEMENT THE CONTENTS
2199 010234 032726 140000      BIT      #BIT15!BIT14,(SP)+ ;CHECK 'ERR' AND 'HE' BITS
2200 010240 001401      BEQ     25              ;BR IF BOTH SET
2201 010242 104025      ERROR   25              ;'ERR' OR 'HE' NOT SET WITH 'WPV'
2202 010244 000004      25:    SCOPE            ;LOOP ?

```

;TEST 22 TEST THE 'FUV' BIT (FILE UNSAFE VIOLATION)

```

2208 061246      TST2:
2209 010246 000240      NOP
2210 010250 012737 010270 001106  MOV      #ERF2,SLPADR    ;LOAD LOOP ON TEST ADDRESS
2211 010256 012737 010270 001110  MOV      #ERF2,SLPERR    ;LOAD ERROR LOOP ADDRESS
2212 010264 013704 001210      MOV      RPADR,R4        ;RPIIE BUS ADDRESS
2213 010270 012706 001100      ERF2:  MOV      #STACK,SP  ;SETUP THE STACK POINTER
2214 010274 004737 021706      JSR      PC,CLRP         ;CLEAR THE CONTROLLER
2215 010300 012764 177777 000006  MOV      #-1,RPWC(R4)    ;LOAD THE WORD COUNT
2216 010306 112764 000003 000004  MOVVB   #3,RPCS(R4)     ;ISSUE WRITE
2217 010314 012737 064001 001206  MOV      #BIT14!BIT13!BIT11!BIT00,TPL
2218 010322 004737 021756      JSR      PC,T3P          ;GENERATE 3 CLOCK PULSES
2219 010326 004737 022014      JSR      PC,SAVRP        ;SAVE THE RPIIE REGISTERS
2220 010332 032737 040000 001222  BIT      #BIT14,$RPER    ;DID FILE UNSAFE VIOLATION SET?
2221 010340 001001      BNE     $                ;
2222 010342 104026      ERROR   26              ;FILE UNSAFE VIOLATION DID NOT SET
2223 010344      IS:
2224 010344 013746 001224      MOV      $RPCS,-(SP)    ;PUT CONTENTS OF RPCS ON THE STACK
2225 010350 005116      COM     (SP)            ;COMPLEMENT THE CONTENTS
2226 010352 032726 140000      BIT      #BIT15!BIT14,(SP)+ ;CHECK 'ERR' AND 'HE' BITS
2227 010356 001401      BEQ     27              ;BR IF BOTH SET
2228 010360 104027      ERROR   27              ;'ERR' OR 'HE' DID NOT SET WITH 'FUV'
2229 010362 000004      27:    SCOPE            ;LOOP ?

```

;TEST 23 TEST 'NXC' BIT (NON-EXISTENT CYLINDER) WITH VALID ADDRESSES

```

2235 010364      TST23:
2236 010364 000240      NOP
2237 010366 012737 010406 001106  MOV      #15,SLPADR     ;LOAD LOOP ON TEST ADDRESS
2238 010374 012737 010416 001110  MOV      #ERF3,SLPERR    ;LOAD ERROR LOOP ADDRESS

```

```

2239 010402 013704 001210      MOV      RPADR,R4      ;RP11E BUS ADDRESS
2240 010406 012706 001100      1S:     MOV      #STACK,SP ;SETUP THE STACK POINTER
2241 010412 005037 001124      CLR      $GDDAT      ;START AT ADDRESS 0
2242 010416 004737 021706      ERF3:   JSR      PC,CLRP    ;CLEAR THE CONTROLLER
2243 010422 013764 001124 000012  MOV      $GDDAT,RP(A4) ;LOAD CYLINDER ADDR
2244 010430 012737 177777 001226  MOV      #-1,$RPMC    ;LOAD WORD COUNT
2245 010436 112764 000003 000004  MOV      #3,$RPCS(R4) ;ISSUE A WRITE
2246 010444 012737 060001 001206  MOV      #BIT14!BIT13!BIT00,TPL
2247 010452 004737 021756      JSR      PC,T3P      ;GENERATE 3 CLOCK PULSES
2248 010456 004737 022014      JSR      PC,SAVRP    ;SAVE THE RP11E REGISTERS
2249 010462 032737 020000 001222  BIT      #BIT13,$RPER ;DID NON-EXISTENT CYLINDER SET?
2250 010470 001401 25      BEQ      25          ;BR IF NOT
2251 010472 104030 30      ERROR   30          ;'NXC' SET ON VALID ADDRESS
2252 010474 005237 001124 2S:     INC      $GDDAT      ;UPDATE CYLINDER ADDRESS
2253 010500 023737 001176 001124  CMP      MAXCYL,$GDDAT ;IS ADDR STILL LEGAL?
2254 010506 103343      BHS     ERF3        ;BRANCH IF YES
2255 010510 000004      SCOPE   ;LOOP ?

```

```

;*****
;#TEST 24      TEST 'NXC' WITH INVALID ADDRESSES
;*****

```

```

2257
2258
2259
2260
2261 010512      ;*****
2262 010512 000240      ;#TEST 24:
2263 010514 012737 010534 001106      NOP
2264 010522 012737 010552 001110      MOV      #1S,$LPADR  ;LOAD LOOP ON TEST ADDRESS
2265 010530 013704 001210      MOV      #ERF4,$LPERR ;LOAD ERROR LOOP ADDRESS
2266 010534 012706 001100      MOV      RPADR,R4    ;RP11E BUS ADDRESS
2267 010540 013737 001176 001124  1S:     MOV      #STACK,SP  ;SETUP THE STACK POINTER
2268 010546 005237 001124      MOV      MAXCYL,$GDDAT ;MAXIMUM CYLINDER ADDRESS
2269 010552 004737 021706      INC      $GDDAT      ;INCREMENT BEYOND LIMIT
2270 010556 013764 001124 000012  ERF4:   JSR      PC,CLRP    ;CLEAR THE CONTROLLER
2271 010564 012764 177777 000006  MOV      $GDDAT,RP(A4) ;LOAD CYLINDER ADDR
2272 010572 112764 000003 000004  MOV      #-1,$RPMC(R4) ;LOAD WORD COUNT
2273 010600 012737 060001 001206  MOV      #3,$RPCS(R4) ;ISSUE WRITE
2274 010606 004737 021756      MOV      #BIT14!BIT13!BIT00,TPL
2275 010612 004737 022014      JSR      PC,T3P      ;GENERATE 3 CLOCK PULSES
2276 010616 032737 020000 001222  JSR      PC,SAVRP    ;SAVE THE RP11E REGISTERS
2277 010624 001002      BIT      #BIT13,$RPER ;DID NON-EXISTENT CYL SET?
2278 010626 104031 25      BNE     25          ;'NXC' DID NOT SET
2279 010630 000407      ERROR   31          ;BYPASS REST OF THE TEST
2280 010632      BR      3S
2281 010632 013746 001224 2S:     MOV      $RPCS,-(SP)  ;PUT CONTENTS OF RPCS ON THE STACK
2282 010636 005116      COM     (SP)         ;COMPLEMENT THE CONTENTS
2283 010640 032726 140000      BIT      #BIT15!BIT14,(SP) ;CHECK 'ERR' AND 'HE' BITS
2284 010644 001401 3S      BEQ     3S          ;BR IF BOTH SET
2285 010646 104032      ERROR   32          ;'ERR' OR 'HE' DIDN'T SET WITH 'NXC'
2286 010650 005237 001124 3S:     INC      $GDDAT      ;UPDATE CYLINDER ADDR
2287 010654 023737 001200 001124  CMP      MAXPAT,$GDDAT ;PATTERN EXCEEDED?
2288 010662 001333      BNE     ERF4        ;BR IF NOT
2289 010664 000004      SCOPE   ;LOOP ?

```

```

;*****
;#TEST 25      TEST 'NXT' BIT (NON-EXISTENT TRACK) WITH VALID ADDRESSES
;*****

```

```

2290
2291
2292
2293
2294

```

M04

```

2295 010666          TST25:
2296 010666 000240      NOP
2297 010670 012737 010710 001106  MOV    #15,SLPADR      ;LOAD LOOP ON TEST ADDRESS
2298 010676 012737 010720 001110  MOV    #ERF5,SLPERR   ;LOAD ERROR LOOP ADDRESS
2299 010704 013704 001210          MOV    RPADR,R4       ;RP11E BUS ADDRESS
2300 010710 012706 001100          IS:  MOV    #STACK,SP    ;SETUP THE STACK POINTER
2301 010714 005037 001124          CLR    $GDDAT        ;STARTING TRACK ADDR OF 0
2302 010720 004737 021706          ERF5: JSR    PC,CLRP       ;CLEAR THE CONTROLLER
2303 010724 113764 001124 000015  MOVB   $GDDAT,RPDA+1(R4) ;LOAD TRACK ADDRESS
2304 010732 012764 177777 000006  MOV    #-1,RPWC(R4)   ;LOAD WORD COUNT
2305 010740 112764 000003 000004  MOVB   #3,APCS(R4)    ;WRITE
2306 010746 012737 060001 001206  MOV    #BIT14!BIT13!BIT00,TPL
2307 010754 004737 021756          JSR    PC,T3P        ;GENERATE 3 CLOCK PULSES
2308 010760 004737 022014          JSR    PC,SAVRP      ;SAVE THE RP11E REGISTERS
2309 010764 032737 010000 001222  BIT    #BIT12,SRPER   ;IS NXT SET?
2310 010772 001401          BEQ    25
2311 010774 104033          ERROR  33            ;'NXT' SET ON VALID ADDRESS
2312 010776 005237 001124          25:  INC    $GDDAT        ;INCREMENT THE TRACK ADDRESS
2313 011002 022737 000023 001124  CMP    #19,$GDDAT    ;IS TRACK ADDRESS STILL VALID
2314 011010 103343          BHIS   ERF5          ;BRANCH IF YES
2315 011012 000004          SCOPE ;LOOP ?
2316
2317
2318
2319
2320
2321
2322
2323
2324
2325
2326
2327
2328
2329
2330
2331
2332
2333
2334
2335
2336
2337
2338
2339
2340
2341
2342
2343
2344
2345
2346
2347
2348
2349
2350
  
```

 ;*TEST 26 TEST 'NXT' BIT WITH INVALID ADDRESSES

 TST26:

```

2322 011014          TST26:
2323 011014 000240      NOP
2324 011016 012737 011036 001106  MOV    #15,SLPADR      ;LOAD LOOP ON TEST ADDRESS
2325 011024 012737 011050 001110  MOV    #ERF6,SLPERR   ;LOAD ERROR LOOP ADDRESS
2326 011032 013704 001210          MOV    RPADR,R4       ;RP11E BUS ADDRESS
2327 011036 012706 001100          IS:  MOV    #STACK,SP    ;SETUP THE STACK POINTER
2328 011042 012737 000024 001124  MOV    #20,$GDDAT     ;START WITH INVALID ADDRESS
2329 011050 004737 021706          ERF6: JSR    PC,CLRP       ;CLEAR THE CONTROLLER
2330 011054 113764 001124 000015  MOVB   $GDDAT,RPDA+1(R4) ;LOAD TRACK ADDR
2331 011062 012737 177777 001226  MOV    #-1,SRPWC      ;WRITE
2332 011070 012764 000003 000004  MOV    #3,APCS(R4)    ;WRITE
2333 011076 012737 060001 001206  MOV    #BIT14!BIT13!BIT00,TPL
2334 011104 004737 021756          JSR    PC,T3P        ;GENERATE 3 CLOCK PULSES
2335 011110 004737 022014          JSR    PC,SAVRP      ;SAVE THE RP11E REGISTERS
2336 011114 032737 010000 001222  BIT    #BIT12,SRPER   ;DID NXT SET?
2337 011122 001002          BNE    25
2338 011124 104034          ERROR  34            ;'NXT' DIDN'T SET WITH INVALID ADDRESS
2339 011126 000407          BR     35            ;BYPASS REST OF THE TEST
2340
2341
2342
2343
2344
2345
2346
2347
2348
2349
2350
  
```

```

2351
2352
2353
2354
2355 011164
2356 011164 000240
2357 011166 012737 011206 001106
2358 011174 012737 011216 001110
2359 011202 013704 001210
2360 011206 012706 001100
2361 011212 005037 001124
2362 011216 004737 021706
2363 011222 013764 001124 000014
2364 011230 012764 177777 000006
2365 011236 112764 000003 000004
2366 011244 012737 060001 001206
2367 011252 004737 021756
2368 011256 004737 022014
2369 011262 032737 004000 001222
2370 011270 001401
2371 011272 104036
2372 011274 005237 001124
2373 011300 022737 000011 001124
2374 011306 103343
2375 011310 000004
2376
2377
2378
2379
2380
2381 011312
2382 011312 000240
2383 011314 012737 011334 001106
2384 011322 012737 011346 001110
2385 011330 013704 001210
2386 011334 012706 001100
2387 011340 012737 000012 001124
2388 011346 004737 021706
2389 011352 013764 001124 000014
2390 011360 012764 177777 000006
2391 011366 112764 000003 000004
2392 011374 012737 060001 001206
2393 011402 004737 021756
2394 011406 004737 022014
2395 011412 032737 004000 001222
2396 011420 001002
2397 011422 104037
2398 011424 000407
2399 011426
2400 011426 013746 001224
2401 011432 005116
2402 011434 032726 140000
2403 011440 001401
2404 011442 104040
2405 011444 005237 001124
2406 011450 022737 000020 001124

```

;TEST 27 TEST 'NXS' BIT (NON-EXISTENT SECTOR) WITH VALID ADDRESSES

```

TST27:
NOP
MOV #15,SLPADR ;LOAD LOOP ON TEST ADDRESS
MOV #ERF7,SLPERR ;LOAD ERROR LOOP ADDRESS
MOV RPADR,R4 ;RPIIE BUS ADDRESS
1S: MOV #STACK,SP ;SETUP THE STACK POINTER
CLR $GDDAT ;STARTING SECTOR ADDRESS OF 0
ERF7: JSR PC,CLRP ;CLEAR THE CONTROLLER
MOV $GDDAT,RPDA(R4) ;LOAD SECTOR ADDR
MOV #-1,RPWC(R4) ;LOAD WORD COUNT
MOVB #3,RPCS(R4) ;WRITE
MOV #BIT14!BIT13!BIT00,TPL ;
JSR PC,T3P ;GENERATE 3 CLOCK PULSES
JSR PC,SAVRP ;SAVE THE RPIIE REGISTERS
BIT #BIT11,$RPER ;DID NXS SET?
2S: BEQ 25
ERROR 36 ;'NXS' SET ON VALID ADDRESS
INC $GDDAT ;UPDATE SECTOR ADDR
CMP #9,$GDDAT ;IS ADDR STILL LEGAL?
BHS ERF7 ;BRANCH IF YES
SCOPE ;LOOP ?

```

;TEST 30 TEST 'NXS' BIT WITH INVALID ADDRESSES

```

TST30:
NOP
MOV #15,SLPADR ;LOAD LOOP ON TEST ADDRESS
MOV #ERF10,SLPERR ;LOAD ERROR LOOP ADDRESS
MOV RPADR,R4 ;RPIIE BUS ADDRESS
1S: MOV #STACK,SP ;SETUP THE STACK POINTER
MOV #10,$GDDAT ;START WITH MAXIMUM SECTOR ADDR + 1
ERF10: JSR PC,CLRP ;CLEAR THE CONTROLLER
MOV $GDDAT,RPDA(R4) ;LOAD SECTOR ADDR
MOV #-1,RPWC(R4) ;LOAD WORD COUNT
MOVB #3,RPCS(R4) ;WRITE
MOV #BIT14!BIT13!BIT00,TPL ;
JSR PC,T3P ;GENERATE 3 CLOCK PULSES
JSR PC,SAVRP ;SAVE THE RPIIE REGISTERS
BIT #BIT11,$RPER ;DID NXS SET?
2S: BNE 25
ERROR 37 ;'NXS' DIDN'T SET WITH INVALID ADDRESS
BR 35 ;BYPASS REST OF THE TEST
3S: MOV $RPCS,-(SP) ;PUT CONTENTS OF RPCS ON THE STACK
COM (SP) ;COMPLEMENT THE CONTENTS
BIT #BIT15!BIT14,(SP)+ ;CHECK 'ERR' AND 'HE' BITS
BEQ 35 ;BR IF BOTH SET
ERROR 40 ;'ERR' OR 'HE' DIDN'T SET WITH 'NXS'
INC $GDDAT ;UPDATE ADDRESS
CMP #20,$GDDAT ;IS PATTERN EXHAUSTED?

```

```

407 011456 001333      BNE      ERF10      ;BRANCH IF NOT
408 011460 000004      SCOPE      ;LOOP ?
409
410
411
412
413
414
415 011462
416 011462 000240
417 011464 012737 011504 001106  MOV      #ERF11,SLPADR ;LOAD LOOP ON TEST ADDRESS
418 011472 012737 011504 001110  MOV      #ERF11,SLPERR ;LOAD ERROR LOOP ADDRESS
419 011500 013704 001210  MOV      RPADR,R4      ;RPI1E BUS ADDRESS
420 011504 012706 001100  ERF11:  MOV      #STACK,SP   ;SETUP THE STACK POINTER
421 011510 004737 021706  JSR      PC,CLRP      ;CLEAR RP11
422 011514 042764 020000 000022  BIC      #BIT13,RPM3(R4) ;RESET MAINTENANCE 'SUOL'
423 011522 012764 000003 000004  MOV      #3,RPCS(R4)   ;ISSUE WRITE
424 011530 012737 060001 001206  MOV      #BIT14!BIT13!BIT00,TPL
425 011536 004737 021756  JSR      PC,T3P      ;GENERATE 3 CLOCK PULSES
426 011542 004737 022014  JSR      PC,SAVRP    ;SAVE THE RPI1E REGISTERS
427 011546 032737 002000 001222  BIT      #BIT10,SRPER ;DID PROGRAM ERROR SET?
428 011554 001001
429 011556 104041
430 011560
431 011560 013746 001224  15:     MOV      SRPCS,-(SP)  ;PUT CONTENTS OF RPCS ON THE STACK
432 011564 005116  COM      (SP)        ;COMPLEMENT THE CONTENTS
433 011566 032726 140000  BIT      #BIT15!BIT14,(SP)+ ;CHECK 'ERR' AND 'HE' BITS
434 011572 001401  BEQ      25         ;BR IF BOTH SET
435 011574 104042  ERROR   42         ;'ERR' OR 'HE' DIDN'T SET WITH 'PROG'
436 011576 032764 020000 000022  25:     BIT      #BIT13,RPM3(R4) ;SET MAINTENANCE 'SUOL'
437 011604 000004  SCOPE

```

```

*****
;TEST 32      TEST SETTING OF 'MODE' BIT (MODE ERROR)
*****

```

```

438
439
440
441
442
443
444
445 011606
446 011606 000240
447 011610 012737 011630 001106  MOV      #ERF12,SLPADR ;LOAD LOOP ON TEST ADDRESS
448 011616 012737 011630 001110  MOV      #ERF12,SLPERR ;LOAD ERROR LOOP ADDRESS
449 011624 013704 001210  MOV      RPADR,R4      ;RPI1E BUS ADDRESS
450 011630 012706 001100  ERF12:  MOV      #STACK,SP   ;SETUP THE STACK POINTER
451 011634 004737 021706  JSR      PC,CLRP      ;CLEAR THE CONTROLLER
452 011640 012764 177777 000006  MOV      #1,RPMC(R4)   ;LOAD WORD COUNT
453 011646 012764 004003 000004  MOV      #4003,RPCS(R4) ;WRITE HEADER IN PDP11 MODE
454 011654 012737 060001 001206  MOV      #BIT14!BIT13!BIT00,TPL
455 011662 004737 021756  JSR      PC,T3P      ;GENERATE 3 CLOCK PULSES
456 011666 004737 022014  JSR      PC,SAVRP    ;SAVE THE RPI1E REGISTERS
457 011672 032737 000400 001222  BIT      #BIT08,SRPER ;DID MODE ERROR SET?
458 011700 001001
459 011702 104043
460 011704
461 011704 013746 001224  15:     MOV      SRPCS,-(SP)  ;PUT CONTENTS OF RPCS ON THE STACK
462 011710 005116  COM      (SP)        ;COMPLEMENT THE CONTENTS
463 011712 032726 140000  BIT      #BIT15!BIT14,(SP)+ ;CHECK 'ERR' AND 'HE' BITS
464 011716 001401  BEQ      25         ;BR IF BOTH SET

```

```

463 011720 104044          ERROR 44          ;'ERR' OR 'HE' DIDN'T SET WITH 'MODE'
464 011722 000004          2S:  SCOPE          ;LOOP ?
465
466
467
468
469
470
471 011724          ;*****
472 011726 000240          ;#TEST 33      TEST ATTENTION INTERRUPT
473 011726 012737 011746 001106          ;*****
474 011734 012737 011760 001110          ;TST33:
475 011742 013704 001210          ;   NOP
476 011746 012706 001100          ;   MOV #15,SLPADR ;LOAD LOOP ON TEST ADDRESS
477 011752 012737 000001 001124          ;   MOV #CSF1,SLPERR ;LOAD ERROR LOOP ADDRESS
478 011764 012777 000340 167222          ;   MOV RPAOR,R4 ;RP11E BUS ADDRESS
479 011772 012777 012050 167212          ;   MOV #STACK,SP ;SETUP THE STACK POINTER
480 012000 004737 021706          ;   MOV #1,SGDDAT ;STARTING TEST PATTERN
481 012004 005037 177776          ;   JSR PC,CLAP ;CLEAR THE CONTROLLER
482 012010 052764 020000 000004          ;   MOV #PR7,ARPVEC+2 ;INTERUPT RETURN ADDRESS
483 012016 013764 001124 000020          ;   MOV #25,ARPVEC ;INTERRUPT RETURN ADDRESS
484 012024 000240          ;   JSR PC,CLAP ;CLEAR RP11
485 012026 000240          ;   CLR #PSW ;CLEAR PRIORITY LEVEL
486 012030 000240          ;   BIS #BIT13,RPCS(R4) ;ENABLE ATTENTION INTERRUPT
487 012032 012737 000340 177776          ;   MOV SGDDAT,RPM2(R4) ;SET ATTENTION BIT AND
488 012040 004737 022014          ;   NOP ;WAIT FOR INTERRUPT
489 012044 104046          ;   MOV #PR7,#PSW ;LOCKOUT INTERRUPTS
490 012046 000407          ;   JSR PC,SAVRP ;SAVE THE RP11E REGISTERS
491 012050 012706 001100          ;   ERROR 46 ;NO ATTENTION INTERRUPT
492 012054 032764 020000 000004          ;   BR 35 ;BYPASS REST OF THE TEST
493 012062 001401          ;   MOV #STACK,SP ;RESTORE STACK
494 012064 104047          ;   BIT #BIT13,RPCS(R4) ;DID 'AIE' CLEAR?
495 012066 013764 001124 000000          ;   ERROR 47 ;'AIE' DIDN'T CLEAR WHEN INTERRUPT OCCURED
496 012074 006337 001124          ;   MOV SGDDAT,RPDS(R4) ;CLEAR ATTENTION BIT
497 012100 032737 000400 001124          ;   ASL SGDDAT ;SHIFT TEST PATTERN
498 012106 001724          ;   BIT #BIT08,SGDDAT ;PATTERN EXCEEDED?
499 012110 000004          ;   BEQ CSF1 ;BRANCH IF NO
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518

```

```

;*****
;#TEST 34      TEST NO ATTENTION INTERRUPT
;*****

```

```

012112          ;TST34:
012112 000240          ;   NOP
012114 012737 012134 001106          ;   MOV #15,SLPADR ;LOAD LOOP ON TEST ADDRESS
012122 012737 012146 001110          ;   MOV #TSTNAT,SLPERR ;LOAD ERROR LOOP ADDRESS
012130 013704 001210          ;   MOV RPAOR,R4 ;RP11E BUS ADDRESS
012134 012706 001100          ;   MOV #STACK,SP ;SETUP THE STACK POINTER
012140 012737 000001 001124          ;   MOV #1,SGDDAT ;STARTING TEST PATTERN
012146 004737 021706          ;   JSR PC,CLAP ;CLEAR THE CONTROLLER
012152 012777 000340 167034          ;   MOV #PR7,ARPVEC+2 ;INTERUPT RETURN ADDRESS
012160 012777 012222 167024          ;   MOV #15,ARPVEC ;INTERRUPT RETURN ADDRESS
012166 004737 021706          ;   JSR PC,CLAP ;CLEAR RP11
012172 052764 020000 000004          ;   BIS #BIT13,RPCS(R4) ;SET 'AIE'
012200 005037 177776          ;   CLR #PSW ;CLEAR PRIORITY LEVEL
012204 000240          ;   NOP ;WAIT FOR INTERRUPT

```

012206	000240				NOP		
012210	000240				NOP		
012212	012737	000340	177776		MOV	#PR7, #PSW	: LOCKOUT INTERRUPTS
012220	000405				BR	25	: OK, INTERRUPT DIDN'T OCCUR
012222	012706	001100		15:	MOV	#STACK, SP	: RESTORE STACK
012226	004737	022014			JSR	PC, SAVRP	: SAVE THE RPIIE REGISTERS
012232	104107				ERROR	107	: ATTENTION INTERRUPT OCCURED WITH NO ATTN BITS SET
012234	000004			25:	SCOPE		: LOOP ?

: #TEST 35 TEST ATTENTION INTERRUPT WITH 2 ATTN BITS SET

: #TST35:

012236	000240				NOP		
012240	012737	012260	001106		MOV	#TSTAT, SLPADR	: LOAD LOOP ON TEST ADDRESS
012246	012737	012260	001110		MOV	#TSTAT, SLPERR	: LOAD ERROR LOOP ADDRESS
012254	013704	001210			MOV	RPADR, R4	: RPIIE BUS ADDRESS
012260	012706	001100		TSTAT:	MOV	#STACK, SP	: SETUP THE STACK POINTER
012264	012737	012260	001110		MOV	#TSTAT, SLPERR	: CHANGE LOOP ON ERROR ADDRESS
012272	012777	000340	166714		MOV	#PR7, #PVEC+2	
012300	012777	012356	166704		MOV	#IS, #PVEC	
012306	004737	021706			JSR	PC, CLR	: CLEAR THE CONTROLLER
012312	005037	177776			CLR	#PSW	: LOWER PROCESSOR PRIORITY
012316	052764	020000	000004		BIS	#BIT13, RPCS(R4)	: ENABLE ATTENTION INTERRUPT
012324	012764	000003	000020		MOV	#3, RPI2(R4)	: SET ATTENTION BITS
012332	000240				NOP		
012334	000240				NOP		
012336	000240				NOP		
012340	012737	000340	177776		MOV	#PR7, #PSW	: RAISE PROCESSOR PRIORITY
012346	004737	022014			JSR	PC, SAVRP	: SAVE THE RPIIE REGISTERS
012352	104050				ERROR	50	: RPIIE DID NOT INTERRUPT WITH ATTENTION : BITS 0 AND 1 SET
012354	000431				BR	25	
012356	012737	012356	001110	15:	MOV	#IS, SLPERR	: CHANGE LOOP ON ERROR ADDRESS
012364	012706	001100			MOV	#STACK, SP	: RESTORE STACK
012370	012777	012440	166614		MOV	#25, #PVEC	
012376	005037	177776			CLR	#PSW	
012402	052764	020000	000004		BIS	#BIT13, RPCS(R4)	: ENABLE ATTENTION INTERRUPT
012410	012764	000001	000000		MOV	#BIT00, RPI5(R4)	: CLEAR ATTENTION BIT ZERO
012416	000240				NOP		
012420	000240				NOP		
012422	000240				NOP		
012424	012737	000340	177776		MOV	#PR7, #PSW	: RAISE PROCESSOR PRIORITY
012432	004737	022014			JSR	PC, SAVRP	: SAVE THE RPIIE REGISTERS
012436	104051				ERROR	51	: ATTENTION BIT 1 DID NOT INTERRUPT
012440	000004			25:	SCOPE		: LOOP ?

: #TEST 36 TEST 'IDE' BIT (INTERRUPT ON DONE ENABLE)

: #TST36:

012442					NOP		
012444	000240				MOV	#CSF2, SLPADR	: LOAD LOOP ON TEST ADDRESS
012444	012737	012464	001106				

E05

```

012575 012452 012737 012464 001110      MOV      #CSF2,SLPERR      ;LOAD ERROR LOOP ADDRESS
012576 012460 013704 001210      MOV      RPADR,R4        ;RP11E BUS ADDRESS
012577 012464 012706 001100      CSF2:   MOV      #STACK,SP ;SETUP THE STACK POINTER
012578 012470 004737 021706      JSR      PC,CLR          ;CLEAR THE CONTROLLER
012579 012474 012777 012546 166510  MOV      #1$,JRPVEC      ;RETURN VECTOR
012580 012502 012777 000340 166504  MOV      #PR7,JRPVEC+2
012581 012510 005037 177776      CLR      PSH            ;ALLOW INTERRUPTS
012582 012514 052764 000100 000004  BIS      #BIT06,RPCS(R4) ;ENABLE INTERRUPT ON READY
012583 012522 000240      NOP
012584 012524 000240      NOP
012585 012526 000240      NOP
012586 012530 012737 000340 177776  MOV      #PR7,JPSH      ;LOCKOUT INTERRUPTS
012587 012536 004737 022014      JSR      PC,SAVRP       ;SAVE THE RP11E REGISTERS
012588 012544 104052      ERROR   52             ;NO READY INTERRUPT
012589 012544 000407      BR      25             ;BYPASS 'IDE' CHECK
012590 012546 004737 022014      JSR      PC,SAVRP       ;SAVE THE REGISTERS
012591 012550 032737 000100 001224 1S:     BIT      #BIT06,RPCS    ;IS 'IDE' STILL SET ?
012592 012560 001001      BNE     25             ;BR IF IT IS
012593 012562 104106      ERROR   106           ;'IDE' NOT SET AFTER INTERRUPT
012594 012564 000004      2S:     SCOPE          ;LOOP ?

```

;TEST 37 TEST INTERRUPT WITHOUT INTERRUPT ENABLE SET

TST37:

```

012566 000240      NOP
012566 012737 012610 001106      MOV      #CSF3,SLPADR   ;LOAD LOOP ON TEST ADDRESS
012567 012737 012610 001110      MOV      #CSF3,SLPERR   ;LOAD ERROR LOOP ADDRESS
012568 013704 001210      MOV      RPADR,R4        ;RP11E BUS ADDRESS
012569 012706 001100      CSF3:   MOV      #STACK,SP    ;SETUP THE STACK POINTER
012570 004737 021706      JSR      PC,CLR          ;CLEAR THE CONTROLLER
012571 012614 004737 021706      JSR      PC,CLR          ;CLEAR THE CONTROLLER
012572 012620 012777 012656 166364  MOV      #1$,JRPVEC      ;INTERRUPT VECTOR
012573 012626 112764 000377 000020  MOVB    #377,RPM2(R4)   ;SET ATTENTION BITS
012574 012634 005037 177776      CLR      JPSH            ;ALLOW INTERRUPTS AND
012575 012640 000240      NOP                    ;WAIT AWHILE
012576 012642 000240      NOP
012577 012644 000240      NOP
012578 012646 012737 000340 177776  MOV      #PR7,JPSH      ;LOCKOUT INTERRUPTS
012579 012654 000403      BR      25
012580 012656 004737 022014      1S:     JSR      PC,SAVRP   ;SAVE THE RP11E REGISTERS
012581 012662 104053      ERROR   53             ;READY INTERRUPT OCCURED WITHOUT 'IDE' SET
012582 012664 000004      2S:     SCOPE          ;LOOP ?

```

;TEST 40 TEST INTERRUPT AT PRIORITY 4

TST40:

```

012666 000240      NOP
012666 012737 012710 001106      MOV      #CSF6,SLPADR   ;LOAD LOOP ON TEST ADDRESS
012667 012737 012710 001110      MOV      #CSF6,SLPERR   ;LOAD ERROR LOOP ADDRESS
012668 013704 001210      MOV      RPADR,R4        ;RP11E BUS ADDRESS
012669 012706 001100      CSF6:   MOV      #STACK,SP    ;SETUP THE STACK POINTER
012670 004737 021706      JSR      PC,CLR          ;CLEAR RP11E
012671 012714 004737 021706      JSR      PC,CLR          ;CLEAR RP11E
012672 012720 012777 012764 166264  MOV      #1$,JRPVEC      ;SETUP INTERRUPT VECTOR

```

DZRPWB.CMB

T40

TEST INTERRUPT AT PRIORITY 4

```

2631 012726 052764 000100 000004      BIS      #BIT06,RPCS(R4) ;ENABLE READY INTERRUPT
2632 012734 012737 000200 177776      MOV      #PR4,2#PSW ;LOWER PROCESSOR LEVEL
2633 012742 000240      NOP
2634 012744 000240      NOP
2635 012746 000240      NOP
2636 012750 012737 000340 177776      MOV      #PR7,2#PSW
2637 012756 004737 022014      JSR      PC,SAVRP ;SAVE THE RP11E REGISTERS
2638 012762 104054      ERROR   54 ;NO READY INTERRUPT AT LEVEL 4
2639 012764 000004      IS:     SCOPE ;LOOP ?
2640
2641
2642
2643
2644
2645
2646
2647 012766 000240      TST41:  NOP
2648 012770 012737 013010 001106      MOV      #CSF7,SLPADR ;LOAD LOOP ON TEST ADDRESS
2649 012776 012737 013010 001110      MOV      #CSF7,SLPERR ;LOAD ERROR LOOP ADDRESS
2650 013004 013704 001210      MOV      RPADR,R4 ;RP11E BUS ADDRESS
2651 013010 012706 001100      CSF7:  MOV      #STACK,SP ;SETUP THE STACK POINTER
2652 013014 004737 021706      JSR      PC,CLRP ;CLEAR RP11E
2653 013020 012777 013060 166164      MOV      #1$,JRPVEC ;SETUP INTERRUPT VECTOR
2654 013026 052764 000100 000004      BIS      #BIT06,RPCS(R4) ;ENABLE INTERRUPT ON READY
2655 013034 012737 000240 177776      MOV      #PRS,2#PSW ;SET PRIORITY LEVEL TO 5
2656 013042 000240      NOP
2657 013044 000240      NOP
2658 013046 000240      NOP
2659 013050 012737 000340 177776      MOV      #PR7,2#PSW
2660 013056 000403      BR      25
2661 013060 004737 022014      IS:     JSR      PC,SAVRP ;SAVE THE RP11E REGISTERS
2662 013064 104055      ERROR   55 ;INTERRUPT RECEIVED AT PRIORITY LEVEL 5
2663 013066 000004      2S:     SCOPE ;LOOP ?
2664
2665
2666
2667
2668 013070      TST42:  NOP
2669 013070 000240      MOV      #CSF10,SLPADR ;LOAD LOOP ON TEST ADDRESS
2670 013072 012737 013112 001106      MOV      #CSF10,SLPERR ;LOAD ERROR LOOP ADDRESS
2671 013100 012737 013112 001110      MOV      RPADR,R4 ;RP11E BUS ADDRESS
2672 013106 013704 001210      CSF10: MOV      #STACK,SP ;SETUP THE STACK POINTER
2673 013112 012706 001100      JSR      PC,CLRP ;CLEAR RP11E
2674 013116 004737 021706      MOV      #1$,JRPVEC ;TRAP VECTOR
2675 013122 012777 013162 166062      BIS      #BIT06,RPCS(R4) ;ENABLE READY INTERRUPT
2676 013130 052764 000100 000004      MOV      #PR6,2#PSW ;SET PRIORITY LEVEL TO 6
2677 013136 012737 000300 177776      NOP
2678 013144 000240      NOP
2679 013146 000240      NOP
2680 013150 000240      NOP
2681 013152 012737 000340 177776      MOV      #PR7,2#PSW
2682 013160 000403      BR      25
2683 013162 004737 022014      IS:     JSR      PC,SAVRP ;SAVE THE RP11E REGISTERS
2684 013166 104056      ERROR   56 ;INTERRUPT RECEIVED AT LEVEL 6
2685 013170 000004      2S:     SCOPE ;LOOP ?
2686

```

2687
2688
2689
2690
2691 013172
2692 013172 000240
2693 013174 012737 013214 001106
2694 013202 012737 013214 001110
2695 013210 013704 001210
2696 013214 012706 001100
2697 013220 004737 021706
2698 013224 012777 013250 165760
2699 013232 052764 000100 000004
2700 013240 000240
2701 013242 000240
2702 013244 000240
2703 013246 000403
2704 013250 004737 022014
2705 013254 104056
2706 013256 000004

:TEST 43 TEST NO INTERRUPT AT PRIORITY 7

TST43:

NOP
MOV #CSF11,SLPADR ;LOAD LOOP ON TEST ADDRESS
MOV #CSF11,SLPERR ;LOAD ERROR LOOP ADDRESS
MOV RPADR,R4 ;RP11E BUS ADDRESS
CSF11: MOV #STACK,SP ;SETUP THE STACK POINTER
JSR PC,CLRP ;CLEAR RP11E
MOV #IS,SRPVEC ;SETUP VECTOR INTERRUPT
BIS #BIT06,RPCS(R4) ;ENABLE READY INTERRUPT
NOP
NOP
NOP
BR 2S
1S: JSR PC,SAVRP ;SAVE THE RP11E REGISTERS
ERROR 56 ;INTERRUPT RECEIVED AT LEVEL 7
2S: SCOPE ;LOOP ?

2707
2708
2709
2710
2711
2712 013260
2713 013260 000240
2714 013262 012737 013302 001106
2715 013270 012737 013302 001110
2716 013276 013704 001210
2717 013302 012706 001100
2718 013306 004737 021706
2719 013312 112764 000003 000004
2720 013320 004737 022014
2721 013324 105737 001224
2722 013330 100001
2723 013332 104101
2724 013334 012737 060001 001206
2725 013342 004737 021756
2726 013346 004737 022014
2727 013352 105737 001224
2728 013356 100401
2729 013360 104060
2730 013362 000004
2731
2732

:TEST 44 TEST CLEAR AND SET OF 'RDY' (CONTROLLER READY)

TST44:

NOP
MOV #CSF12,SLPADR ;LOAD LOOP ON TEST ADDRESS
MOV #CSF12,SLPERR ;LOAD ERROR LOOP ADDRESS
MOV RPADR,R4 ;RP11E BUS ADDRESS
CSF12: MOV #STACK,SP ;SETUP THE STACK POINTER
JSR PC,CLRP ;CLEAR RP11E
MOV #3,RPCS(R4) ;ISSUE WRITE
JSR PC,SAVRP ;SAVE THE RP11E REGISTERS
TSTB SRPCS ;IS READY SET?
BPL 1S ;BRANCH IF NO
ERROR 101 ;'RDY' DID NOT CLEAR WITH 'GO'
1S: MOV #BIT14:BIT13:BIT00,TPL
JSR PC,T3P ;GENERATE 3 CLOCK PULSES
JSR PC,SAVRP ;SAVE THE RP11E REGISTERS
TSTB SRPCS ;DID READY SET?
BMI 2S
ERROR 2S
2S: SCOPE ;READY DID NOT SET AT END OF OPERATION
;LOOP ?

2733
2734
2735
2736 013364
2737 013364 000240
2738 013366 012737 013406 001106
2739 013374 012737 013416 001110
2740 013402 013704 001210
2741 013406 012706 001100
2742 013412 005037 001124

:TEST 45 TEST 'SUCA' BIT PATH IN THE CONTROLLER

TST45:

NOP
MOV #IS,SLPADR ;LOAD LOOP ON TEST ADDRESS
MOV #CAF1,SLPERR ;LOAD ERROR LOOP ADDRESS
MOV RPADR,R4 ;RP11E BUS ADDRESS
1S: MOV #STACK,SP ;SETUP THE STACK POINTER
CLR \$GDDAT ;START TEST PATTERN AT 0

H05

```
2743 013416 004737 021706 CAF1: JSR PC,CLRP ;CLEAR THE CONTROLLER
2744 013422 113764 001124 000021 MOVB SGDDAT,RPM2+1(R4) ;LOAD MAINT CYLINDER ADDR
2745 013430 004737 022014 JSR PC,SAVRP ;SAVE THE RP11E REGISTERS
2746 013434 013737 001240 001126 MOV $SUCR,$BDDAT ;GET DISK CYLINDER ADDR
2747 013442 023737 001124 001126 CMP SGDDAT,$BDDAT ;IS SUCR CORRECT?
2748 013450 001401 BEQ 25
2749 013452 104061 ERROR 61 ;SUCR INCORRECT
2750 013454 005237 001124 25: INC SGDDAT ;UPDATE CYLINDER ADDR.
2751 013460 032737 000400 001124 BIT #BIT08,$SGDDAT ;IS PATTERN EXCEEDED?
2752 013466 001753 BEQ CAF1 ;BRANCH IF NO
2753 013470 000004 SCOPE ;LOOP ?
2754
2755 ;*****
2756 ;*TEST 46 TEST THAT THE 'SOT' COUNTS CORRECTLY
2757 ;*****
2758 ;*****
2759 TST46:
2760 NOP
2761 013472 000240 MOV #15,$LPRDR ;LOAD LOOP ON TEST ADDRESS
2762 013474 012737 013530 001106 MOV #DAF1,$LPERR ;LOAD ERROR LOOP ADDRESS
2763 013502 012737 013560 001110 MOV RPAR,R4 ;RP11E BUS ADDRESS
2764 013510 013704 001210 MOV #BIT13:BIT08,RPM3(R4) ;GENERATE A SECTOR PULSE TO CLEAR
2765 013514 012764 020400 000022 MOV #BIT13,RPM3(R4) ;INDEX SYNC FF (IF SET)
2766 013522 012764 020000 000022 MOV #STACK,SP ;SETUP THE STACK POINTER
2767 013530 012706 001100 15: MOV RPAR(R4),SGDDAT ;GET THE REGISTER
2768 013534 016437 000014 001124 BIC #C360,$SGDDAT ;LEAVE THE 'SOT' BITS
2769 013542 042737 177417 001124 JSR PC,CLRP ;CLEAR THE CONTROLLER
2770 013550 004737 021706 MOV #20,R5 ;ITERATION COUNTER
2771 013554 012705 000024 DAF1: JSR PC,SAVRP ;SAVE THE RP11E REGISTERS
2772 013560 004737 022014 MOV SRPAR,$BDDAT ;GET SOT
2773 013564 013737 001234 001126 MOV SRPAR,$TMP0 ;MOVE CONTENTS TO A WORKING LOCATION
2774 013572 013737 001234 001160 BIC #C360,$TMP0 ;CLEAR UNWANTED BITS
2775 013600 042737 177417 001160 CMP SGDDAT,$TMP0 ;CONTENTS OF 'SOT' CORRECT ?
2776 013606 023737 001124 001160 BEQ 25
2777 013614 001401 ERROR 63 ;CONTENTS OF SOT INCORRECT
2778 013616 104063 25: DEC R5 ;DECREMENT THE ITERATION COUNTER
2779 013620 005305 BEQ 35 ;BR WHEN FINISHED
2780 013622 001420 MOV #BIT13:BIT08,RPM3(R4) ;GENERATE ONE SECTOR PULSE
2781 013624 012764 020400 000022 MOV #BIT13,RPM3(R4)
2782 013632 012764 020000 000022 ADD #20,$SGDDAT ;UPDATE TEST ADDR
2783 013640 062737 000020 001124 CMP #360,$SGDDAT ;MAXIMUM VALUE ?
2784 013646 022737 000360 001124 BHS DAF1 ;BRANCH IF NOT
2785 013654 103341 CLR $SGDDAT ;RESET TO ZERO
2786 013656 005037 001124 BR DAF1 ;CONTINUE
2787 013664 000004 35: SCOPE ;LOOP ?
2788
2789 ;*****
2790 ;*TEST 47 TEST THAT 'INDEX' CLEARS THE 'SOT' COUNTER
2791 ;*****
2792 ;*****
2793 TST47:
2794 013666 000240 NOP
2795 013666 012737 013710 001106 MOV #DAF2,$LPRDR ;LOAD LOOP ON TEST ADDRESS
2796 013670 012737 013710 001110 MOV #DAF2,$LPERR ;LOAD ERROR LOOP ADDRESS
2797 013704 013704 001210 MOV RPAR,R4 ;RP11E BUS ADDRESS
2798 013710 012706 001100 DAF2: MOV #STACK,SP ;SETUP THE STACK POINTER
```

```

2799 013714 004737 021706 JSR PC CLAP ;CLEAR RP11E
2800 013720 012764 020400 000022 MOV #BIT13!BIT08,RPM3(R4) ;GENERATE A SECTOR PULSE
2801 013726 012764 020000 000022 MOV #BIT13,RPM3(R4)
2802 013734 012764 020400 000022 MOV #BIT13!BIT08,RPM3(R4) ;GENERATE A SECTOR PULSE
2803 013742 012764 020000 000022 MOV #BIT13,RPM3(R4)
2804 013750 012764 020400 000022 MOV #BIT13!BIT08,RPM3(R4) ;GENERATE A SECTOR PULSE
2805 013756 012764 020000 000022 MOV #BIT13,RPM3(R4)
2806 013764 012764 020400 000022 MOV #BIT13!BIT08,RPM3(R4) ;GENERATE A SECTOR PULSE
2807 013772 012764 020000 000022 MOV #BIT13,RPM3(R4)
2808 014000 012764 020400 000022 MOV #BIT13!BIT08,RPM3(R4) ;GENERATE A SECTOR PULSE
2809 014006 012764 020000 000022 MOV #BIT13,RPM3(R4)
2810 014014 012764 020400 000022 MOV #BIT13!BIT08,RPM3(R4) ;GENERATE A SECTOR PULSE
2811 014022 012764 020000 000022 MOV #BIT13,RPM3(R4)
2812 014030 012764 020400 000022 MOV #BIT13!BIT08,RPM3(R4) ;GENERATE A SECTOR PULSE
2813 014036 012764 020000 000022 MOV #BIT13,RPM3(R4)
2814 014044 012764 020400 000022 MOV #BIT13!BIT08,RPM3(R4) ;GENERATE A SECTOR PULSE
2815 014052 012764 020000 000022 MOV #BIT13,RPM3(R4)
2816 014060 012764 020400 000022 MOV #BIT13!BIT08,RPM3(R4) ;GENERATE A SECTOR PULSE
2817 014066 012764 020000 000022 MOV #BIT13,RPM3(R4)
2818 014074 012764 020400 000022 MOV #BIT13!BIT08,RPM3(R4) ;GENERATE A SECTOR PULSE
2819 014102 012764 020000 000022 MOV #BIT13,RPM3(R4)
2820 014110 012764 020400 000022 MOV #BIT13!BIT08,RPM3(R4) ;GENERATE A SECTOR PULSE
2821 014116 012764 020000 000022 MOV #BIT13,RPM3(R4)
2822 014124 012764 020400 000022 MOV #BIT13!BIT08,RPM3(R4) ;GENERATE A SECTOR PULSE
2823 014132 012764 020000 000022 MOV #BIT13,RPM3(R4)
2824 014140 012764 020400 000022 MOV #BIT13!BIT08,RPM3(R4) ;GENERATE A SECTOR PULSE
2825 014146 012764 020000 000022 MOV #BIT13,RPM3(R4)
2826 014154 012764 020400 000022 MOV #BIT13!BIT08,RPM3(R4) ;GENERATE A SECTOR PULSE
2827 014162 012764 020000 000022 MOV #BIT13,RPM3(R4)
2828 014170 004037 021766 JSR RO,INDEXP ;GENERATE 1 INDEX PULSE
2829 014174 000001 .WORD 1 ;CONSTANT FOR 1 INDEX PULSE
2830 014176 012764 020400 000022 MOV #BIT13!BIT08,RPM3(R4) ;GENERATE A SECTOR PULSE
2831 014204 012764 020000 000022 MOV #BIT13,RPM3(R4) ;TO CLEAR THE 'SOT'
2832 014212 004737 022014 JSR PC,SAVAP ;STORE THE RP11E REGISTERS
2833 014216 013737 001234 001126 MOV SRPDA,SBDDAT ;STORE THE CONTENTS
2834 014224 013737 001234 001160 MOV SRPDA,STMPO ;MOVE CONTENTS TO A WORKING LOCATION
2835 014232 042737 177417 BIC #1C360,STMPO ;MASK OUT ALL BUT THE 'SOT' BITS
2836 014240 001401 BEQ 15
2837 014242 104062 ERROR 62 ;SOT DID NOT CLEAR WITH INDEX PULSE
2838 014244 000004 15: SCOPE ;LOOP ?

```

```

2839
2840
2841 ;*****
2842 ;#TEST 50 SILO TEST, PART 1
2843
2844 ;#THIS TEST CHECKS THE SILO MEMORY IN MAINTENANCE
2845 ;#MODE. IF INREADY IS SET, DATA IS OUTPUT TO REGISTER
2846 ;#'SILO' WHICH IS THE SILO MEMORY. AFTER THE DATA FILTERS
2847 ;#THRU THE MEMORY, OUTREADY GOES TRUE. THE DATA IS READ
2848 ;#BACK AND COMPARED.
2849
2850 ;*****
2851 ;#TEST50:
2852 NOP
2853 MOV #SILOT,SLPADR ;LOAD LOOP ON TEST ADDRESS
2854 MOV #SILOT,SLPERR ;LOAD ERROR LOOP ADDRESS

```

```

2855 014264 013704 001210      MOV      RPADR,R4      ;RPIIE BUS ADDRESS
2856 014270 012706 001100      MOV      #STACK,SP   ;SETUP THE STACK POINTER
2857 014274 012737 000001 001124      MOV      #1,SGDDAT    ;INITIALIZE FLOATING ONE PATTERN
2858 014302 005005      CLR      R5           ;PATTERN FLAG
2859 014304 012737 014304 001110 1S:      MOV      #1S,SLPERR   ;RESTORE THE LOOP ON ERROR ADDRESS
2860 014312 004737 021706      JSR      PC,CLRP      ;CLEAR THE CONTROLLER
2861 014316 004737 022014      JSR      PC,SAVRP     ;SAVE THE RPIIE REGISTERS
2862 014322 032737 004000 001236      BIT      #BIT11,SRPM1 ;IS INREADY SET?
2863 014330 001002      BNE     2S           ;BRANCH IF SET
2864 014332 104064      ERROR   64          ;SILO INREADY IS NOT SET AFTER CLEAR
2865 014334 000454      BR      9S          ;EXIT
2866 014336 012737 014336 001110 2S:      MOV      #2S,SLPERR   ;CHANGE LOOP ON ERROR ADDRESS
2867 014344 013764 001124 000026      MOV      SGDDAT,SILO(R4) ;LOAD DATA IN SILO
2868 014352 012701 000060      MOV      #60,R1      ;WAIT FOR OUT READY TO SET
2869 014356 005301      3S:      DEC      R1
2870 014360 001376      BNE     3S
2871 014362 004737 022014      JSR      PC,SAVRP     ;SAVE THE RPIIE REGISTERS
2872 014366 032737 010000 001236      BIT      #BIT12,SRPM1 ;IS OUTREADY SET?
2873 014374 001002      BNE     5S          ;BRANCH IF SET
2874 014376 104065      ERROR   65          ;SILO OUTREADY IS NOT SET
2875 014400 000432      BR      9S
2876 014402 016437 000026 001126 5S:      MOV      SILO(R4),SBDDAT ;GET DATA BACK FROM SILO
2877 014410 023737 001124 001126      CMP      SGDDAT,SBDDAT ;IS DATA CORRECT?
2878 014416 001401      BEQ     6S
2879 014420 104066      ERROR   66          ;DATA READ FROM SILO INCORRECT
2880 014422 005765      6S:      TST      R5
2881 014424 001012      BNE     8S          ;ARE WE FLOATING A ONE?
2882 014426 006337 001124      ASL      SGDDAT      ;BRANCH IF ZERO
2883 014432 103401      BCS     7S          ;SHIFT PATTERN
2884 014434 000723      BR      1S          ;BRANCH IF PATTERN EXCEEDED
2885 014436 012705 000001      7S:      MOV      #1,R5
2886 014442 012737 077777 001124      MOV      #77777,SGDDAT ;SET PATTERN FLAG
2887 014450 000715      BR      1S          ;FLOATING ZERO PATTERN
2888 014452 006237 001124      8S:      ASR      SGDDAT      ;SHIFT FLOATING ZERO
2889 014456 052737 100000 001124      BIS      #BIT15,SGDDAT
2890 014464 103707      BCS     1S
2891 014466 000004      9S:      SCOPE              ;LOOP ?

```

```

;*****
;#TEST 51      SILO TEST, PART 2

```

```

;#ENSURE THAT THE SILO MEMORY CAN HOLD 64 DISCREET NUMBERS
;#AT ONE TIME. AFTER LOADING THE 64 NUMBERS SIGNAL INREADY
;#SHOULD CLEAR INDICATING THE SILO IS FULL. THE SILO IS THEN
;#READ OUT EXPECTING SEQUENTIAL NUMBERS OF 1 THRU 100 OCTAL. AT
;#THIS TIME OUT READY SHOULD CLEAR.

```

```

;*****
TST51:

```

```

2904 014470      NOP
2905 014470 000240      MOV      #SILOT1,SLPADR ;LOAD LOOP ON TEST ADDRESS
2906 014472 012737 014520 001106      MOV      #SILOT1,SLPERR ;LOAD ERROR LOOP ADDRESS
2907 014500 012737 014520 001110      MOV      RPADR,R4      ;RPIIE BUS ADDRESS
2908 014506 013704 001210      MOV      #10,$TIMES    ;DO 10. ITERATIONS
2909 014512 012737 000012 001162      MOV      #STACK,SP    ;SETUP THE STACK POINTER
2910 014520 012706 001100

```

K05

2911	014524	012737	000001	001124		MOV	#1,SGDDAT	: INITIALIZE TEST PATTERN
2912	014532	012737	014532	001110	1S:	MOV	#1\$,SLPERR	: RESTORE THE LOOP ON ERROR ADDRESS
2913	014540	004737	021706			JSR	PC,CLRP	: CLEAR THE CONTROLLER
2914	014544	004737	022014			JSR	PC,SAVRP	: SAVE THE RP11E REGISTERS
2915	014550	032737	004000	001236		BIT	#BIT11,\$RPM1	: IS INREADY SET?
2916	014556	001001				BNE	2\$: BRANCH IF SET
2917	014560	104064				ERROR	64	: SILO INREADY SHOULD BE SET
2918	014562	012737	014562	001110	2S:	MOV	#2\$,SLPERR	: CHANGE THE LOOP ON ERROR ADDRESS
2919	014570	012706	001100			MOV	#STACK,SP	: SETUP THE STACK POINTER
2920	014574	013764	001124	000026		MOV	SGDDAT,SILO(R4)	: LOAD PATTERN IN SILO
2921	014602	005237	001124			INC	SGDDAT	: UPDATE PATTERN
2922	014606	022737	000101	001124		CMP	#65.,SGDDAT	: IS THE SILO FULL?
2923	014614	001362				BNE	2\$: BRANCH NOT FULL
2924	014616	016437	000016	001236		MOV	RPM1(R4),\$RPM1	: SAVE THE REGISTER
2925	014624	032737	004000	001236		BIT	#BIT11,\$RPM1	: DID INREADY CLEAR?
2926	014632	001401				BEQ	3\$: BRANCH IF YES
2927	014634	104067				ERROR	67	: SILO INREADY DID NOT CLEAR
2928	014636	012737	000001	001124	3S:	MOV	#1,SGDDAT	: RESET PATTERN
2929	014644	016437	000016	001236	4S:	MOV	RPM1(R4),\$RPM1	: SAVE THE REGISTER
2930	014652	032737	010000	001236		BIT	#BIT12,\$RPM1	: IS OUTREADY SET?
2931	014660	001001				BNE	5\$: BRANCH IF SET
2932	014662	104065				ERROR	65	: SILO OUTREADY SHOULD BE SET
2933	014664	012737	015014	001164	5S:	MOV	#9\$,SESCAPE	: SETUP THE ESCAPE ADDRESS
2934	014672	016437	000026	001126		MOV	SILO(R4),SDDAT	: READ SILO MEMORY
2935	014700	023737	001124	001126		CMP	SGDDAT,SDDAT	: IS DATA CORRECT?
2936	014706	001405				BEQ	6\$: BRANCH IF EQUAL
2937	014710	104066				ERROR	66	: INCORRECT DATA RECEIVED FROM SILO
2938	014712	032777	000200	164220		BIT	#SW07,\$SWR	: IS SWITCH 7 SET ?
2939	014720	001022				BNE	7\$: BR IF IT IS - BYPASS REST OF TEST
2940	014722	012705	000400		6S:	MOV	#256.,R5	: CONSTANT FOR STALL
2941	014726	005305			10S:	DEC	R5	: STALL AND WAIT FOR 'INPUT READY' TO
2942	014730	001376				BNE	10\$: SET (FOR THE FIRST TIME THROUGH THE LOOP)
2943	014732	016437	000016	001236		MOV	RPM1(R4),\$RPM1	: SAVE THE MAINTENANCE REGISTER
2944	014740	005237	001124			INC	SGDDAT	: UPDATE EXPECTED PATTERN
2945	014744	022737	000101	001124		CMP	#65.,SGDDAT	: HAVE 64 WORDS BEEN READ
2946	014752	001413				BEQ	8\$: BRANCH IF NO
2947	014754	032737	004000	001236		BIT	#BIT11,\$RPM1	: IS INPUT READY SET ?
2948	014762	001001				BNE	7\$: BR IF IT IS
2949	014764	104110				ERROR	110	: SILO NOT FULL, INPUT READY SHOULD BE SET
2950	014766	032737	010000	001236	7S:	BIT	#BIT12,\$RPM1	: SEE IF OUTPUT READY STILL SET
2951	014774	001333				BNE	5\$: BR IF OUTPUT READY SET
2952	014776	104111				ERROR	111	: WORDS STILL IN SILO, OUTPUT READY
2953								: SHOULD BE SET
2954	015000	000731				BR	5\$: CONTINUE
2955	015002	032737	010000	001236	8S:	BIT	#BIT12,\$RPM1	: HAS SILO OUTREADY CLEARED ?
2956	015010	001401				BEQ	9\$: BR IF CLEAR
2957	015012	104070				ERROR	70	: SILO SHOULD BE EMPTY BUT
2958								: OUTREADY IS STILL SET
2959	015014	005037	001164		9S:	CLR	SESCAPE	: CLEAR THE ESCAPE ADDRESS
2960	015020	000004				SCOPE		: LOOP ?

```

:*****
: *TEST 52      TEST 'SEEK' COMMAND BUS SIGNALS
:
: *TEST THE OPERATION OF A SEEK COMMAND IN MAINTENANCE MODE.

```

2961
2962
2963
2964
2965
2966

```

2967                                     ;*ISSUE A SEEK COMMAND AND CHECK THE SETTING OF SET CYLINDER
2968                                     ;*RESET HEAD, SET HEAD, SEEK START AND CAR BITS 0 THRU 7.
2969                                     ;*ALL THESE SIGNALS ARE FOUND ON BUS OUT CONTROL.
2970
2971                                     ;*****
2972                                     †T52:
2973 015022 000240                       NOP
2974 015024 012737 015044 001106       MOV      #15, $LPADR      ;LOAD LOOP ON TEST ADDRESS
2975 015032 012737 015052 001110       MOV      #SEEK, $LPERR   ;LOAD ERROR LOOP ADDRESS
2976 015040 013704 001210               MOV      RPADR, R4       ;RP11E BUS ADDRESS
2977 015044 012706 001100 15:         MOV      #STACK, SP     ;SETUP THE STACK POINTER
2978 015050 005005                       CLR      R5              ;CLEAR PASS FLAG
2979 015052 004737 021706 001100 15:   JSR      PC, CLRP       ;CLEAR THE CONTROLLER
2980 015056 004737 022014               JSR      PC, SAVRP      ;SAVE THE RP11 REGISTERS
2981 015062 013737 001236 001126       MOV      $RPM1, $BDDAT  ;GET CONTENTS OF RPM1
2982 015070 042737 174000 001126       BIC      #174000, $BDDAT ;CLEAR UNWANTED BITS
2983 015076 001403                       BEQ      25              ;BRANCH IF RESULT IS ZERO
2984 015100 005037 001124               CLR      $GDDAT
2985 015104 104071                       ERROR    71              ;SOME BUS OUT SIGNALS TO THE
2986                                     ;DRIVE ARE SET AFTER RESET
2987 015106 012764 000252 000012 25:   MOV      #170., RPCA(R4) ;LOAD CYCL 170 INTO RPCA
2988 015114 005705                       TST      R5
2989 015116 001403                       BEQ      35
2990 015120 012764 000125 000012       MOV      #85., RPCA(R4) ;LOAD CYLINDER 85 INTO REGISTER
2991 015126 112764 000017 000015 35:   MOV      #17, RPD+1(R4) ;LOAD TRACK ADDR
2992 015134 005705                       TST      R5              ;IS THIS FIRST PASS
2993 015136 001403                       BEQ      45              ;BRANCH IF YES
2994 015140 112737 000020 001235       MOV      #20, $RPDA+1   ;SET HIGH ORDER BIT OF TRACK ADDR
2995 015146 112764 000011 000004 45:   MOV      #11, RPCS(R4)  ;ISSUE SEEK COMMAND
2996 015154 012737 060001 001206       MOV      #BIT14:BIT13:BIT00, TPL
2997 015162 004037 021736               JSR      RO, TIMEP      ;GENERATE 5 TIMING PULSES
2998 015166 000005                       .WORD    5              ;CONSTANT FOR 5 TIMING PULSES
2999 015170 004737 022014               JSR      PC, SAVRP      ;GET THE REGISTERS
3000 015174 013737 001236 001126       MOV      $RPM1, $BDDAT  ;GET CONTROL LINES FROM RPM1
3001 015202 042737 174000 001126       BIC      #174000, $BDDAT ;CLEAR UNWANTED BITS
3002 015210 012737 000525 001124       MOV      #525, $GDDAT   ;LOAD EXPECTED VALUE OF RPM1
3003 015216 005705                       TST      R5              ;IS THIS FIRST PASS
3004 015220 001403                       BEQ      55              ;BRANCH IF YES
3005 015222 012737 000652 001124       MOV      #652, $GDDAT
3006 015230 023737 001124 001126 55:   CMP      $GDDAT, $BDDAT ;WERE CONTENTS OF RPM1 CORRECT?
3007 015236 001401                       BEQ      65
3008 015240 104072                       ERROR    72              ;BRANCH IF YES
3009                                     ;THE CONTROL SIGNAL SET CYLINDER
3010                                     ;AND THE CONTENTS OF CAR SHOULD
3011                                     ;BE ON THE BUS OUT LINES
3012 015242 004037 021736 65:         JSR      RO, TIMEP      ;GENERATE 4 CLOCK PULSES
3013 015246 000004                       .WORD    4              ;CONSTANT FOR 4 CLOCK PULSES
3014 015250 004737 022014               JSR      PC, SAVRP      ;GET THE REGISTERS
3015 015254 013737 001236 001126       MOV      $RPM1, $BDDAT  ;GET CONTENTS OF RPM1
3016 015262 042737 174000 001126       BIC      #174000, $BDDAT ;CLEAR UNWANTED BITS
3017 015270 012737 002010 001124       MOV      #BIT10:BIT03, $GDDAT ;LOAD EXPECTED VALUE OF RPM1
3018 015276 023737 001124 001126       CMP      $GDDAT, $BDDAT ;ARE CONTENTS OF RPM1 CORRECT?
3019 015304 001401                       BEQ      75              ;BRANCH IF YES
3020 015306 104073                       ERROR    73              ;THE CONTROL SIGNAL RESET HEAD
3021                                     ;SHOULD BE ON THE BUS OUT LINES
3022 015310 004037 021736 75:         JSR      RO, TIMEP      ;GENERATE 4 CLOCK PULSES
3023 015314 000004                       .WORD    4              ;CONSTANT FOR 4 CLOCK PULSES
    
```



```

3023 015316 004737 022014 JSR PC,SAVRP ;GET THE REGISTERS
3024 015322 013737 001236 001126 MOV SRPM1,$BDDAT ;GET CONTENTS OF RPM1
3025 015330 042737 174000 001126 BIC #174000,$BDDAT ;CLEAR UNWANTED
3026 015336 012737 001360 001124 MOV #1360,$GDDAT ;LOAD EXPECTED VALUE OF RPM1
3027 015344 005705 TST R5 ;IS THIS THE FIRST PASS ?
3028 015346 001403 BEQ B$ ;BRANCH IF YES
3029 015350 012737 001010 001124 MOV #1010,$GDDAT ;SECOND PASS VALUE
3030 015356 023737 001124 001126 9$: CMP $GDDAT,$BDDAT ;ARE CONTENTS OF RPM1 CORRECT?
3031 015364 001401 BEQ 9$
3032 015366 104074 ERROR 74 ;THE CONTROL SIGNAL SET HEAD AND
3033 ;THE HEAD ADDRESS SHOULD BE ON
3034 ;THE BUS OUT LINES
3035 015370 004037 021736 9$: JSR RO,TIMEP ;GENERATE 4 CLOCK PULSES
3036 015374 000004 .WORD 4 ;CONSTANT FOR 4 CLOCK PULSES
3037 015376 004737 022014 JSR PC,SAVRP ;GET THE REGISTERS
3038 015402 013737 001236 001126 MOV SRPM1,$BDDAT ;GET CONTENTS OF RPM1
3039 015410 042737 174000 001126 BIC #174000,$BDDAT ;CLEAR UNWANTED BITS
3040 015416 012737 002004 001124 MOV #BIT10:BIT02,$GDDAT ;LOAD EXPECTED BITS
3041 015424 023737 001124 001126 CMP $GDDAT,$BDDAT ;ARE CONTENTS OF RPM1 CORRECT?
3042 015432 001401 BEQ 10$ ;BRANCH IF YES
3043 015434 104075 ERROR 75 ;THE CONTROL SIGNAL SEEK START
3044 ;SHOULD BE ON THE BUS OUT LINES
3045 015436 005704 10$: TST R4 ;IS THIS FIRST PASS?
3046 015440 001002 BNE 11$ ;BRANCH IF NO
3047 015442 005205 INC R5 ;SET SECOND PASS INDICATOR
3048 015444 000602 BR SEEK ;MAKE SECOND PASS
3049 015446 000004 11$: SCOPE ;LOOP ?
3050
3051
3052 ;*****
3053 ;*TEST 53 TEST 'HOME SEEK' COMMAND BUS SIGNALS
3054
3055 ;*ISSUE A RESTORE COMMAND AND CHECK THE GENERATION OF
3056 ;*THE SIGNAL 'RESTORE' ON THE BUS OUT CONTROL LOGIC.
3057
3058 ;*****
3059 ;*TEST 53:
3060 015450 000240 NOP
3061 015452 012737 015472 001106 MOV #RESTOR,$LPADR ;LOAD LOOP ON TEST ADDRESS
3062 015460 012737 015472 001110 MOV #RESTOR,$LPERR ;LOAD ERROR LOOP ADDRESS
3063 015466 013704 001210 MOV RPADR,R4 ;RP11E BUS ADDRESS
3064 015472 012706 001100 RESTOR: MOV #STACK,SP ;SETUP THE STACK POINTER
3065 015476 004737 021706 JSR PC,CLRP ;CLEAR THE CONTROLLER
3066 015502 004737 022014 JSR PC,SAVRP ;SAVE THE REGISTERS
3067 015506 013737 001236 001126 MOV SRPM1,$BDDAT ;GET CONTENTS OF RPM1
3068 015514 042737 174000 001126 BIC #174000,$BDDAT ;CLEAR UNWANTED BITS
3069 015522 005737 001126 TST $BDDAT ;ANY SET ?
3070 015526 001403 BEQ 1$ ;BRANCH IF RESULT IS YES
3071 015530 005037 001124 CLR $GDDAT
3072 015534 104071 ERROR 71 ;SOME BUS OUT SIGNALS TO THE
3073 ;DRIVE ARE SET AFTER RESET
3074 015536 012764 000015 000004 1$: MOV #15,RPCS(R4) ;ISSUE HOME COMMAND
3075 015544 012737 060001 001206 MOV #BIT14:BIT13:BIT00,TPL
3076 015552 004037 021736 JSR RO,TIMEP ;GENERATE 4 CLOCK PULSES
3077 015556 000004 .WORD 4 ;CONSTANT FOR 4 CLOCK PULSES
3078 015560 004737 022014 JSR PC,SAVRP ;GET THE REGISTERS

```

```

3079 015564 013737 001236 001126      MOV      SRPM1,SBDDAT      ;GET CONTROL LINES FROM RPM1
3080 015572 042737 174000 001126      BIC      #174000,SBDDAT   ;CLEAR UNWANTED BITS
3081 015600 012737 002100 001124      MOV      #BIT10:BIT06,SGDDAT ;LOAD EXPECTED VALUE OF RPM1
3082 015606 023737 001124 001126      CMP      SGDDAT,SBDDAT   ;WERE CONTENTS OF RPM1 CORRECT?
3083 015614 001401                      BEQ      25              ;BRANCH IF YES
3084 015616 104076                      ERROR   76              ;ISSUED HOME COMMAND-EXPECTED
3085                                     ;RESTORE AND CONTROL TO BE SET
3086                                     ;ON BUS OUT LINES
3087 015620 000004      25:      SCOPE          ;LOOP ?

```

```

;*****
;*TEST 54      TEST 'READ' BUS SIGNALS

```

```

;ISSUE A READ COMMAND WITH NO SEEK IMPLIED AND CHECK THE GENERATION
;OF THE SIGNAL READ IN THE BUS OUT LOGIC.

```

```

;*****
T54:

```

```

3097 015622                      NOP
3098 015622 000240                      MOV      #READT,SLPADR   ;LOAD LOOP ON TEST ADDRESS
3099 015624 012737 015644 001106      MOV      #READT,SLPERR   ;LOAD ERROR LOOP ADDRESS
3100 015632 012737 015644 001110      MOV      RPADR,R4        ;RP11E BUS ADDRESS
3101 015640 013704 001210                      MOV      #STACK,SP      ;SETUP THE STACK POINTER
3102 015644 012706 001100      READT:  JSR      PC,CLRP      ;CLEAR THE CONTROLLER
3103 015650 004737 021706                      MOV      #-1,RPWC(R4)    ;LOAD WORD COUNT
3104 015654 012764 177777 000006      MOV      #17,RPCS(R4)    ;ISSUE READ COMMAND
3105 015662 012764 000017 000004      MOV      #BIT14:BIT13:BIT00,TPL ;
3106 015670 012737 060001 001206      JSR      RD,TIMEP        ;GENERATE 4 CLOCK PULSES
3107 015676 004037 021736                      .WORD   4                ;CONSTANT FOR 4 CLOCK PULSES
3108 015702 000004                      MOV      #BIT14:BIT13:BIT08:BIT00,TPL ;
3109 015704 012737 060401 001206      JSR      RD,TIMEP        ;GENERATE 3 CLOCK PULSES
3110 015712 004037 021736                      .WORD   3                ;CONSTANT FOR 3 CLOCK PULSES
3111 015716 000003                      JSR      PC,SAVRP        ;GET THE REGISTERS
3112 015720 004737 022014                      MOV      SRPM1,SBDDAT   ;GET CONTENTS OF RPM1
3113 015724 013737 001236 001126      BIC      #174000,SBDDAT   ;CLEAR UNWANTED BITS
3114 015732 042737 174000 001126      MOV      #BIT10:BIT05:BIT01,SGDDAT ;LOAD EXPECTED VALUE OF RPM1
3115 015740 012737 002042 001124      CMP      SGDDAT,SBDDAT   ;ARE CONTENTS OF RPM1 CORRECT
3116 015746 023737 001124 001126      BEQ      15              ;BRANCH IF YES
3117 015754 001401                      ERROR   77              ;ISSUED READ WITH NO SEEK COMMAND
3118 015756 104077                      ;EXPECTED CONTROL, SELECT HEAD, AND READ
3119                                     ;SIGNALS ON THE BUS OUT LINES
3120                                     ;LOOP ?
3121 015760 000004      15:      SCOPE

```

```

;*****
;*TEST 55      TEST 'WRITE' BUS SIGNALS

```

```

;ISSUE A WRITE FORMAT COMMAND AND CHECK THE GENERATION OF THE
;WRITE SIGNAL IN THE BUS OUT LOGIC.

```

```

;*****
T55:

```

```

3131 015762                      NOP
3132 015762 000240                      MOV      #WRITE,SLPADR   ;LOAD LOOP ON TEST ADDRESS
3133 015764 012737 016004 001106      MOV      #WRITE,SLPERR   ;LOAD ERROR LOOP ADDRESS
3134 015772 012737 016004 001110

```

```

3135 016000 013704 001210      MOV      RPADR,R4      ;RP11E BUS ADDRESS
3136 016004 012706 001100      WRITE:  MOV      #STACK,SP  ;SETUP THE STACK POINTER
3137 016010 004737 021706      JSR      PC,CLRP      ;CLEAR THE CONTROLLER
3138 016014 012764 177777 000006  MOV      #-1,RPMC(R4) ;SET UP WORD COUNT
3139 016022 012764 000001 000014  MOV      #1,RPDA(R4)  ;SELECT SECTOR 1, TRACK 0
3140 016030 012764 014003 000004  MOV      #14003,RPCS(R4);ISSUE WRITE FORMAT COMMAND
3141 016036 012737 060001 001206  MOV      #BIT14!BIT13!BIT00,TRP
3142 016044 004037 021736      JSR      RO,TIMEP     ;GENERATE 19 CLOCK PULSES
3143 016050 000023      .WORD    19          ;CONSTANT FOR 19 CLOCK PULSES
3144 016052 004037 021766      JSR      RO,INDEXP   ;GENERATE 1 INDEX PULSE
3145 016056 000001      .WORD    1          ;CONSTANT FOR 1 INDEX PULSE
3146 016060 012764 020400 000022  MOV      #BIT13!BIT08,RPM3(R4);GENERATE SECTOR PULSE
3147 016066 012764 020000 000022  MOV      #BIT13,RPM3(R4)
3148 016074 012764 020400 000022  MOV      #BIT13!BIT08,RPM3(R4);GENERATE SECTOR PULSE
3149 016102 004037 021736      JSR      RO,TIMEP     ;GENERATE 3 CLOCK PULSES
3150 016106 000003      .WORD    3          ;CONSTANT FOR 3 CLOCK PULSES
3151 016110 004737 022014      JSR      PC,SAVRP    ;GET THE REGISTERS
3152 016114 013737 001236 001126  MOV      SRPM1,$BDDAT ;GET CONTENTS OF RPM1
3153 016122 042737 174000 001126  BIC      #174000,$BDDAT;CLEAR UNWANTED BITS
3154 016130 012737 002061 001124  MOV      #BIT10!BIT05!BIT04!BIT00,$GDDAT;LOAD EXPECTED VALUE OF RPM1
3155 016136 023737 001124 001126  CMP      $GDDAT,$BDDAT;ARE CONTENTS OF RPM1 CORRECT
3156 016144 001401      BEQ      IS          ;BRANCH IF YES
3157 016146 104100      ERROR    100        ;ISSUED A WRITE FORMAT COMMAND
3158                                     ;AND EXPECTED CONTROL, SELECT HEADS, ERASE,
3159                                     ;AND WRITE SIGNALS ON THE BUS OUT LOGIC
3160 016150 000004      IS:      SCOPE
3161 016152 004737 021706      JSR      PC,CLRP     ;CLEAR THE CONTROLLER
3162 016156 000137 016162      JMP      SEOP        ;GO TO THE END OF PASS ROUTINE
3163
3164
3165 .SBTTL END OF PASS ROUTINE
3166
3167 ;*****
3168 ;INCREMENT THE PASS NUMBER ($PASS)
3169 ;INDICATE END-OF-PROGRAM AFTER 8. PASSES THRU THE PROGRAM
3170 ;IF THERES A MONITOR GO TO IT
3171 ;IF THERE ISN'T JUMP TO RSTART
3172
3173 016162      SEOP:
3174 016162 104401 016170      TYPE    65$        ;TYPE ASCIZ STRING
3175 016166 000410      BR      64$        ;GET OVER THE ASCIZ
3176 ;:65$: .ASCIZ <15><12><12>/END OF PASS/
3177 016210      64$:
3178 016210 013746 001100      MOV      $PASS,-(SP) ;SAVE $PASS FOR TYPEOUT
3179 016214 104403      TYPOS    ;GO TYPE--OCTAL ASCII
3180 016216 005      .BYTE    5        ;TYPE 5 DIGIT(S)
3181 016217 000      .BYTE    0        ;SUPPRESS LEADING ZEROS
3182 016220 104401 016226      TYPE    67$        ;TYPE ASCIZ STRING
3183 016224 000413      BR      66$        ;GET OVER THE ASCIZ
3184 ;:67$: .ASCIZ / ERRORS DETECTED = /
3185 ;66$:
3186 016254      MOV      $ERTTL,-(SP) ;SAVE $ERTTL FOR TYPEOUT
3187 016260 104402      TYPOC    ;GO TYPE--OCTAL ASCII(ALL DIGITS)
3188 016262 005037 001112      CLR      $ERTTL     ;CLEAR THE ERROR TOTAL
3189 016266 005037 001102      CLR      $STNM      ;ZERO THE TEST NUMBER
3190 016272 005037 001162      CLR      $STINES    ;ZERO THE NUMBER OF ITERATIONS

```

```

3191 016276 005237 001100      INC      SPASS      ;; INCREMENT THE PASS NUMBER
3192 016302 042737 100000 001100    BIC      #100000,SPASS ;; DON'T ALLOW A NEG. NUMBER
3193 016310 005327          DEC      (PC)+      ;; LOOP?
3194 016312 000010          SEOPCT: .WORD      B.
3195 016314 003027          BGT      SDOAGN      ;; YES
3196 016316 012737          MOV      (PC)+,2(PC)+ ;; RESTORE COUNTER
3197 016320 000010          SENDCT: .WORD      B.
3198 016322 016312          SEOPCT
3199 016324 104401 016332    TYPE      655      ;; TYPE ASCIZ STRING
3200 016330 000407          BR      645      ;; GET OVER THE ASCIZ
3201          ;; 655: .ASCIZ <15><12>/END OF TEST/
3202          645:
3203 016350 104401 016400    TYPE      SNULL      ;; TYPE NULL CHARACTER
3204 016354 013700 000042    SGET42: MOV      2#42,R0 ;; GET MONITOR ADDRESS
3205 016360 001405          BEQ      SDOAGN      ;; BRANCH IF NO MONITOR
3206 016362 000005          RESET      ;; CLEAR THE WORLD
3207 016364 004710          SENDAD: JSR      PC,(R0) ;; GO TO MONITOR
3208 016366 001240          NOP      ;; SAVE ROOM
3209 016370 000340          NOP      ;; FOR
3210 016372 000240          NOP      ;; ACT11
3211 016374          SDOAGN:
3212 016374 000137          JMP      2(PC)+      ;; RETURN
3213 016376 002774          SRTNAD: .WORD      RSTART
3214 016400          377      000  SNULL: .BYTE      -1,-1,0 ;; NULL CHARACTER STRING
3215          016404          .EVEN
3216
3217          .SBTTL *** SUBROUTINES ***
3218
3219          .SBTTL ERROR HANDLER ROUTINE
3220
3221          ;; *****
3222          ;; THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
3223          ;; SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
3224          ;; AND GO TO TYPERR ON ERROR
3225          ;; THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
3226          ;; #SW15=1      HALT ON ERROR
3227          ;; #SW13=1      INHIBIT ERROR TYPEOUTS
3228          ;; #SW10=1      BELL ON ERROR
3229          ;; #SW09=1      LOOP ON ERROR
3230          ;; #CALL
3231          ;; *      ERROR      N      ;; ERROR=EMT AND N=ERROR ITEM NUMBER
3232
3233          ERROR:
3234 016404 104407          CKSMR
3235 016406 105237 001103    7S:      INCB      SERFLG      ;; TEST FOR CHANGE IN SOFT-SWR
3236 016412 001775          BEQ      7S      ;; SET THE ERROR FLAG
3237 016414 013777 001102 162520    MOV      STSTN,2DISPLAY ;; DON'T LET THE FLAG GO TO ZERO
3238 016422 032777 002000 162510    BIT      #BIT10,2SWR ;; DISPLAY TEST NUMBER AND ERROR FLAG
3239 016430 001402          BEQ      1S      ;; BELL ON ERROR?
3240 016432 104401 001166          TYPE      SBELL      ;; NO - SKIP
3241 016436 005237 001112          INC      SERTTL      ;; RING BELL
3242 016442 011637 001116          MOV      (SP),SERRPC ;; COUNT THE NUMBER OF ERRORS
3243 016446 162737 000002 001116    SUB      #2,SERRPC ;; GET ADDRESS OF ERROR INSTRUCTION
3244 016454 117737 162436 001114    MOVB     2SERRPC,SITEMB ;; STRIP AND SAVE THE ERROR ITEM CODE
3245 016462 032777 020000 162450    BIT      #BIT13,2SWR ;; SKIP TYPEOUT IF SET
3246 016470 001004          BNE      20S      ;; SKIP TYPEOUTS

```

```

3247 016472 004737 016556 JSR PC, TYPERR ;;GO TO USER ERROR ROUTINE
3248 016476 104401 001173 TYPE , SCRLF
3249 016502 20S:
3250 016502 005777 162432 2S: TST @SWR ;;HALT ON ERROR
3251 016506 100002 BPL 3S ;;SKIP IF CONTINUE
3252 016510 000000 HALT ;;HALT ON ERROR!
3253 016512 104407 CKSWR ;;TEST FOR CHANGE IN SOFT-SWR
3254 016514 032777 001000 162416 3S: BIT @BIT09, @SWR ;;LOOP ON ERROR SWITCH SET?
3255 016522 001402 BEQ 4S ;;BR IF NO
3256 016524 013716 001110 MOV @LPERR, (SP) ;;FUDGE RETURN FOR LOOPING
3257 016530 005737 001164 4S: TST @ESCAPE ;;CHECK FOR AN ESCAPE ADDRESS
3258 016534 001402 BEQ 5S ;;BR IF NONE
3259 016536 013716 001164 MOV @ESCAPE, (SP) ;;FUDGE RETURN ADDRESS FOR ESCAPE
3260 016542 022737 016364 000042 5S: CMP @SENDAD, @#42 ;;ACT-11 AUTO-ACCEPT?
3261 016550 001001 BNE 6S ;;BRANCH IF NO
3262 016552 000000 HALT ;;YES
3263 016554 6S:
3264 016554 000002 RTI ;;RETURN
3265
3266
3267 016556 104413 TYPERR: SAVREG ;;SAVE R0-R5
3268 016560 005037 001160 CLR STMPD ;;CLEAR LOCATION FOR TEST NUMBER
3269 016564 113737 001102 001160 MOV @STNM, STMPD ;;LOAD TEST NUMBER FOR TYPEOUT
3270 016572 005000 CLR R0 ;;CLEAR R0 FOR ERROR NUMBER
3271 016574 113700 001114 MOV @ITEMB, R0 ;;ERROR NUMBER
3272 016600 005300 DEC R0 ;;FORM INDEX FOR ERROR TABLE
3273 016602 006300 ASL R0
3274 016604 006300 ASL R0
3275 016606 006300 ASL R0
3276 016610 062700 001244 1S: ADD @ERRTB, R0 ;;FORM ADDRESS
3277 016614 012037 016630 MOV (R0)+, 2S ;;GET ERROR MESSAGE (EM) POINTER
3278 016620 001404 BEQ 3S ;;BRANCH IF THERE ISN'T ONE
3279 016622 104401 001173 TYPE , SCRLF ;;CARRIAGE RETURN - LINE FEED
3280 016626 104401 TYPE
3281 016630 000000 2S: .WORD 0 ;;EM POINTER GOES HERE
3282 016632 012037 016646 3S: MOV (R0)+, 4S ;;PICK UP DATA HEADER (DH) POINTER
3283 016636 001404 BEQ 5S ;;BRANCH IF NONE
3284 016640 104401 001173 TYPE , SCRLF ;;CARRIAGE RETURN-LINE FEED
3285 016644 104401 TYPE
3286 016646 000000 4S: .WORD 0 ;;DH POINTER GOES HERE
3287 016650 012001 5S: MOV (R0)+, R1 ;;PICKUP DATA TABLE (DT) POINTER
3288 016652 001450 BEQ 20S ;;BRANCH IF NONE
3289 016654 005005 CLR R5 ;;SET INDENT SWITCH
3290 016656 012000 MOV (R0)+, R0 ;;DATA FORMAT (DF) POINTER
3291 016660 012002 MOV (R0)+, R2 ;;NUMBER OF DH'S TO TYPE
3292 016662 001441 BEQ 17S ;;BRANCH IF DH NUMBER IS 0
3293 016664 005105 COM R5 ;;NO INDENT
3294 016666 104401 001173 TYPE , SCRLF ;;CARRIAGE RETURN-LINE FEED
3295 016672 112003 10S: MOV @R3, (R0)+, R3 ;;NUMBER OF DATA WORDS TO TYPE
3296 016674 112004 MOV @R4, (R0)+, R4 ;;AND HOW TO TYPE THEM
3297 016676 006004 11S: ROR R4 ;;OCTAL OR DECIMAL?
3298 016700 103403 BCS 12S ;;DECIMAL--BRANCH
3299 016702 013146 MOV @R1+, -(SP) ;;SAVE @R1+ FOR TYPEOUT
3300 016704 104402 TYPOC ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
3301 016706 000402 BR 13S
3302 016710 12S:

```

```

3303 016710 013146      MOV      2(R1)+,-(SP)      ;;SAVE 2(R1)+ FOR TYPEOUT
3304 016712 104405      TYPDS                      ;;GO TYPE--DECIMAL ASCII WITH SIGN
3305 016714 005303      13S:   DEC      R3          ;;MORE NUMBERS TO TYPE?
3306 016716 001403      BEQ      14S              ;;NO--BRANCH
3307 016720 104401 022112      TYPE     BLNKS2          ;;YES--TYPE SEPARATORS
3308 016724 000764      BR       11S              ;;LOOP
3309 016726 005302      14S:   DEC      R2          ;;MORE DH'S?
3310 016730 003421      BLE     20S              ;;NO--BRANCH
3311 016732 104401 001173      TYPE     SCRLF           ;;YES--START A NEW LINE
3312 016736 005105      COM      R5              ;;INDENT?
3313 016740 001002      BNE     15S              ;;NO--BRANCH
3314 016742 104401 022112      TYPE     BLNKS2          ;;YES--TYPE SPACES
3315 016746 012037 016754      15S:   MOV      (R0)+,16S  ;;GET NEXT DH
3316 016752 104401      TYPE                      ;;AND TYPE IT
3317 016754 000000      16S:   .WORD     0          ;;DH POINTER GOES HERE
3318 016756 104401 001173      TYPE     SCRLF           ;;CARRIAGE RETURN-LINE FEED
3319 016762 005705      TST      R5              ;;INDENT?
3320 016764 001342      BNE     10S              ;;NO--BRANCH
3321 016766 104401 022112      17S:   TYPE     BLNKS2          ;;YES--TYPE SPACES
3322 016772 000737      BR       10S              ;;LOOP
3323 016774 104414      20S:   RESREG                    ;;RESTORE R0-R5
3324 016776 000207      RTS      PC              ;;RETURN

```

.SBTTL TYPE ROUTINE

```

3325 *****
3326 #ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
3327 #THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
3328 #NOTE1:          SFULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
3329 #NOTE2:          SFILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
3330 #NOTE3:          SFILLC CONTAINS THE CHARACTER TO FILL AFTER.
3331 #
3332 #CALL:
3333 #1) USING A TRAP INSTRUCTION
3334 #      TYPE      ,MESADR      ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
3335 #OR
3336 #      TYPE
3337 #      MESADR
3338 #
3339
3340
3341
3342
3343
3344 017000 105737 001157      STYPE:  TSTB     STPFLG      ;;IS THERE A TERMINAL?
3345 017004 100002      BPL     1S              ;;BR IF YES
3346 017006 000000      HALT                    ;;HALT HERE IF NO TERMINAL
3347 017010 000407      BR      3S              ;;LEAVE
3348 017012 010046      1S:   MOV      R0,-(SP)      ;;SAVE R0
3349 017014 017600 000002      MOV     22(SP),R0        ;;GET ADDRESS OF ASCIZ STRING
3350 017020 112046      2S:   MOVB     (R0)+,-(SP)  ;;PUSH CHARACTER TO BE TYPED ONTO STACK
3351 017022 001005      BNE     4S              ;;BR IF IT ISN'T THE TERMINATOR
3352 017024 005726      TST     (SP)+           ;;IF TERMINATOR POP IT OFF THE STACK
3353 017026 012600      60S:  MOV     (SP)+,R0        ;;RESTORE R0
3354 017030 062716 000002      3S:   ADD     2,(SP)         ;;ADJUST RETURN PC
3355 017034 000002      RTI                      ;;RETURN
3356 017036 122716 000011      4S:   CMPB     8HT,(SP)     ;;BRANCH IF <HT>
3357 017042 001430      BEQ     8S              ;;
3358 017044 122716 000200      CMPB     8CRLF,(SP)     ;;BRANCH IF NOT <CRLF>

```

```

3359 017050 001006 BNE 58
3360 017052 005726 TST (SP)+ ;:POP (CR)<LF> EQUIV
3361 017054 104401 TYPE ;:TYPE A CR AND LF
3362 017056 001173 SCRLF
3363 017060 105037 017214 CLRB SCHARCNT ;:CLEAR CHARACTER COUNT
3364 017064 000755 BR 25 ;:GET NEXT CHARACTER
3365 017066 004737 017150 58: JSR PC,STYPEC ;:GO TYPE THIS CHARACTER
3366 017072 123726 001156 68: CMPB SFILLC,(SP)+ ;:IS IT TIME FOR FILLER CHARS.?
3367 017076 001350 BNE 25 ;:IF NO GO GET NEXT CHAR.
3368 017100 013746 001154 MOV SNULL,-(SP) ;:GET # OF FILLER CHARS. NEEDED
3369 ;:AND THE NULL CHAR.
3370 017104 105366 000001 78: DECB 1(SP) ;:DOES A NULL NEED TO BE TYPED?
3371 017110 002770 BLT 68 ;:BR IF NO--GO POP THE NULL OFF OF STACK
3372 017112 004737 017150 JSR PC,STYPEC ;:GO TYPE A NULL
3373 017116 105337 017214 DECB SCHARCNT ;:DO NOT COUNT AS A COUNT
3374 017122 000770 BR 78 ;:LOOP

```

;HORIZONTAL TAB PROCESSOR

```

3375
3376
3377
3378 017124 112716 000040 88: MOVB 8'(SP) ;:REPLACE TAB WITH SPACE
3379 017130 004737 017150 98: JSR PC,STYPEC ;:TYPE A SPACE
3380 017134 132737 000007 017214 BITB 8',SCHARCNT ;:BRANCH IF NOT AT
3381 017142 001372 BNE 98 ;:TAB STOP
3382 017144 005726 TST (SP)+ ;:POP SPACE OFF STACK
3383 017146 000724 BR 25 ;:GET NEXT CHARACTER
3384 017150 105777 161774 STYPEC: TSTB 2STPS ;:WAIT UNTIL PRINTER IS READY
3385 017154 100375 BPL STYPEC
3386 017156 116677 000002 161766 MOVB 2(SP),2STPB ;:LOAD CHAR TO BE TYPED INTO DATA REG.
3387 017164 122766 000015 000002 CMPB 8CR,2(SP) ;:IS CHARACTER A CARRIAGE RETURN?
3388 017172 001003 BNE 18 ;:BRANCH IF NO
3389 017174 105037 017214 CLRB SCHARCNT ;:YES--CLEAR CHARACTER COUNT
3390 017200 000406 BR STYPEX ;:EXIT
3391 017202 122766 000012 000002 18: CMPB 8LF,2(SP) ;:IS CHARACTER A LINE FEED?
3392 017210 001402 BEQ STYPEX ;:BRANCH IF YES
3393 017212 105227 INCB (PC)+ ;:COUNT THE CHARACTER
3394 017214 000000 SCHARCNT: WORD 0 ;:CHARACTER COUNT STORAGE
3395 017216 000207 STYPEX: RTS PC
3396
3397
3398
3399

```

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

```

3400 ;:*****
3401 ;:THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
3402 ;:OCTAL (ASCII) NUMBER AND TYPE IT.
3403 ;:STYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
3404 ;:CALL:
3405 ;:MOV NUM,-(SP) ;:NUMBER TO BE TYPED
3406 ;:TYPOS ;:CALL FOR TYPEOUT
3407 ;: .BYTE N ;:N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
3408 ;: .BYTE M ;:M=1 OR 0
3409 ;: ;:1=TYPE LEADING ZEROS
3410 ;: ;:0=SUPPRESS LEADING ZEROS
3411 ;:
3412 ;:STYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
3413 ;:STYPOS OR STYPOC
3414 ;:CALL:

```

```

0415
0416
0417
0418
0419
0420
0421
0422
0423
0424 017220 017646 000000
0425 017224 116637 000001 017443
0426 017232 112637 017445
0427 017236 062716 000002
0428 017242 000406
0429 017244 112737 000001 017443
0430 017252 112737 000006 017445
0431 017260 112737 000005 017442
0432 017266 010346
0433 017270 010446
0434 017272 010546
0435 017274 113704 017445
0436 017300 005404
0437 017302 062704 000006
0438 017306 110437 017444
0439 017312 113704 017443
0440 017316 016605 000012
0441 017322 005003
0442 017324 006105 1S:
0443 017326 000404
0444 017330 006105 2S:
0445 017332 006105
0446 017334 006105
0447 017336 010503
0448 017340 006103 3S:
0449 017342 105337 017444
0450 017346 100016
0451 017350 042703 177770
0452 017354 001002
0453 017356 005704
0454 017360 001403
0455 017362 005204 4S:
0456 017364 052703 000060
0457 017370 052703 000040 5S:
0458 017374 110337 017440
0459 017400 104401 017440
0460 017410 003347 017442 7S:
0461 017412 002402
0462 017414 005204
0463 017416 000744
0464 017420 012605 6S:
0465 017422 012604
0466 017424 012603
0467 017426 016665 000002 000004
0468 017434 012616
0469 017436 000002
0470 017440 000
    
```

```

;*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
;*      TYPON                      ;;CALL FOR TYPEOUT
;*
;*STYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
;*CALL:
;*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
;*      TYPOC                      ;;CALL FOR TYPEOUT
;*
STYPOS: MOV      2(SP),-(SP)      ;;PICKUP THE MODE
        MOV      1(SP),SOFILL    ;;LOAD ZERO FILL SWITCH
        MOV      (SP)+,SOMODE+1  ;;NUMBER OF DIGITS TO TYPE
        ADD      #2,(SP)         ;;ADJUST RETURN ADDRESS
        BR      STYPON
STYPOC: MOV      #1,SOFILL      ;;SET THE ZERO FILL SWITCH
        MOV      #6,SOMODE+1    ;;SET FOR SIX(6) DIGITS
STYPON: MOV      #5,SOCNT      ;;SET THE ITERATION COUNT
        MOV      R3,-(SP)       ;;SAVE R3
        MOV      R4,-(SP)       ;;SAVE R4
        MOV      R5,-(SP)       ;;SAVE R5
        MOV      SOMODE+1,R4    ;;GET THE NUMBER OF DIGITS TO TYPE
        NEG      R4
        ADD      #6,R4          ;;SUBTRACT IT FOR MAX. ALLOWED
        MOV      R4,SOMODE      ;;SAVE IT FOR USE
        MOV      SOFILL,R4     ;;GET THE ZERO FILL SWITCH
        MOV      12(SP),R5     ;;PICKUP THE INPUT NUMBER
        CLR      R3            ;;CLEAR THE OUTPUT WORD
        ROL      R5            ;;ROTATE MSB INTO "C"
        BR      3S            ;;GO DO MSB
        ROL      R5            ;;FORM THIS DIGIT
        ROL      R5
        ROL      R5
        MOV      R5,R3
        ROL      R3            ;;GET LSB OF THIS DIGIT
        DECB    SOMODE        ;;TYPE THIS DIGIT?
        BPL      7S            ;;BR IF NO
        BIC      #177770,R3   ;;GET RID OF JUNK
        BNE      4S            ;;TEST FOR 0
        TST      R4            ;;SUPPRESS THIS 0?
        BEQ      5S            ;;BR IF YES
        INC      R4            ;;DON'T SUPPRESS ANYMORE 0'S
        BIS      #'0,R3      ;;MAKE THIS DIGIT ASCII
        BIS      #' ,R3      ;;MAKE ASCII IF NOT ALREADY
        MOV      R3,#S        ;;SAVE FOR TYPING
        TYPE    #S            ;;GO TYPE THIS DIGIT
        DECB    SOCNT        ;;COUNT BY 1
        BGT      2S            ;;BR IF MORE TO DO
        BLT      6S            ;;BR IF DONE
        INC      R4            ;;INSURE LAST DIGIT ISN'T A BLANK
        BR      2S            ;;GO DO THE LAST DIGIT
        MOV      (SP)+,R5     ;;RESTORE R5
        MOV      (SP)+,R4     ;;RESTORE R4
        MOV      (SP)+,R3     ;;RESTORE R3
        MOV      2(SP),4(SP)  ;;SET THE STACK FOR RETURNING
        MOV      (SP)+,(SP)
        RTI
8S:      .BYTE 0
    
```


3471 017441 000
3472 017442 000
3473 017443 000
3474 017444 000000
3475
3476
3477
3478
3479
3480
3481
3482
3483
3484
3485
3486
3487
3488 017446
3489 017446 010046
3490 017450 010146
3491 017452 010246
3492 017454 010346
3493 017456 010546
3494 017460 012746 020200
3495 017464 016605 000020
3496 017470 100004
3497 017472 005405
3498 017474 112766 000055 000001
3499 017502 005000
3500 017504 012703 017662
3501 017510 112723 000040
3502 017514 005002
3503 017516 016001 017652
3504 017522 160105
3505 017524 002402
3506 017526 005202
3507 017530 000774
3508 017532 060105
3509 017534 005702
3510 017536 001002
3511 017540 105716
3512 017542 100407
3513 017544 106316
3514 017546 103003
3515 017550 116663 000001 177777
3516 017556 052702 000060
3517 017562 052702 000040
3518 017566 110223
3519 017570 005720
3520 017572 020027 000010
3521 017576 002746
3522 017600 003002
3523 017602 010502
3524 017604 000764
3525 017606 105726
3526 017610 100003

.BYTE 0
S0CNT: .BYTE 0
S0FILL: .BYTE 0
S0MODE: .WORD 0
::: TERMINATOR FOR TYPE ROUTINE
::: OCTAL DIGIT COUNTER
::: ZERO FILL SWITCH
::: NUMBER OF DIGITS TO TYPE

.SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
*REPLACED WITH SPACES.

*CALL:
* MOV NUM,-(SP) :::PUT THE BINARY NUMBER ON THE STACK
* TYPDS :::GO TO THE ROUTINE

STYPDS:
MOV R0,-(SP) :::PUSH R0 ON STACK
MOV R1,-(SP) :::PUSH R1 ON STACK
MOV R2,-(SP) :::PUSH R2 ON STACK
MOV R3,-(SP) :::PUSH R3 ON STACK
MOV R5,-(SP) :::PUSH R5 ON STACK
MOV #20200,-(SP) :::SET BLANK SWITCH AND SIGN
MOV 20(SP),R5 :::GET THE INPUT NUMBER
BPL 1\$:::BR IF INPUT IS POS.
NEG R5 :::MAKE THE BINARY NUMBER POS.
MOVB #'-,1(SP) :::MAKE THE ASCII NUMBER NEG.
1\$: CLR R0 :::ZERO THE CONSTANTS INDEX
MOV #SDBLK,R3 :::SETUP THE OUTPUT POINTER
MOVB #' ,(R3)+ :::SET THE FIRST CHARACTER TO A BLANK
2\$: CLR R2 :::CLEAR THE BCD NUMBER
MOV \$DTBL(R0),R1 :::GET THE CONSTANT
3\$: SUB R1,R5 :::FORM THIS BCD DIGIT
BLT 4\$:::BR IF DONE
INC R2 :::INCREASE THE BCD DIGIT BY 1
BR 3\$
4\$: ADD R1,R5 :::ADD BACK THE CONSTANT
TST R2 :::CHECK IF BCD DIGIT=0
BNE 5\$:::FALL THROUGH IF 0
TSTB (SP) :::STILL DOING LEADING 0'S?
BMI 7\$:::BR IF YES
5\$: ASLB (SP) :::MSD?
BCC 6\$:::BR IF NO
MOVB 1(SP),-1(R3) :::YES--SET THE SIGN
6\$: BIS #'0,R2 :::MAKE THE BCD DIGIT ASCII
7\$: BIS #' ,R2 :::MAKE IT A SPACE IF NOT ALREADY A DIGIT
MOVB R2,(R3)+ :::PUT THIS CHARACTER IN THE OUTPUT BUFFER
TST (R0)+ :::JUST INCREMENTING
CMP R0,#10 :::CHECK THE TABLE INDEX
BLT 2\$:::GO DO THE NEXT DIGIT
BGT 8\$:::GO TO EXIT
MOV R5,R2 :::GET THE LSD
BR 6\$:::GO CHANGE TO ASCII
8\$: TSTB (SP)+ :::WAS THE LSD THE FIRST NON-ZERO?
BPL 9\$:::BR IF NO

```

3527 017612 116663 177777 177776          MOVB    -1(SP),-2(R3)    ;; YES--SET THE SIGN FOR TYPING
3528 017620 105013          9S:    CLRB    (R3)        ;; SET THE TERMINATOR
3529 017622 012605          MOV     (SP)+,R5        ;; POP STACK INTO R5
3530 017624 012603          MOV     (SP)+,R3        ;; POP STACK INTO R3
3531 017626 012602          MOV     (SP)+,R2        ;; POP STACK INTO R2
3532 017630 012601          MOV     (SP)+,R1        ;; POP STACK INTO R1
3533 017632 012600          MOV     (SP)+,R0        ;; POP STACK INTO R0
3534 017634 104401 017662          TYPE    $DBLK          ;; NOW TYPE THE NUMBER
3535 017640 016666 000002 000004          MOV     2(SP),4(SP)    ;; ADJUST THE STACK
3536 017646 012616          MOV     (SP)+,(SP)
3537 017650 000002          RTI
3538 017652 023420          SOTBL: 10000.          ;; RETURN TO USER
3539 017654 001750          1000.
3540 017656 000144          100.
3541 017660 000012          10.
3542 017662 000004          SDBLK: .BLKW 4
3543
3544          .SBTTL TTY INPUT ROUTINE
3545
3546          ;; *****
3547          .ENABL LSB
3548
3549          ;; *****
3550          #SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
3551          #ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
3552          #SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
3553          #WHEN OPERATING IN TTY FLAG MODE.
3554 017672 022737 000176 001140 SCKSMR: CMP     $SMREG,SMR    ;; IS THE SOFT-SMR SELECTED?
3555 017700 001074          BNE     15$            ;; BRANCH IF NO
3556 017702 105777 161236          TSTB   $STKS          ;; CHAR THERE?
3557 017706 100071          BPL     15$            ;; IF NO, DON'T WAIT AROUND
3558 017710 117746 161232          MOVB   $STKB,-(SP)    ;; SAVE THE CHAR
3559 017714 042716 177600          BIC    $1C177,(SP)    ;; STRIP-OFF THE ASCII
3560 017720 022726 000007          CMP    $7(SP)+        ;; IS IT A CONTROL G?
3561 017724 001062          BNE     15$            ;; NO, RETURN TO USER
3562 017726 123727 001134 000001          CMPSB $AUTOB,$1      ;; ARE WE RUNNING IN AUTO-MODE?
3563 017734 001456          BEQ    15$            ;; BRANCH IF YES
3564
3565 017736 104401 020544          TYPE   ,SCNTLG        ;; ECHO THE CONTROL-G (1G)
3566 017742 104401 020551          SGTSMR: TYPE   $SMR    ;; TYPE CURRENT CONTENTS
3567 017746 013746 000176          MOV    $SMREG,-(SP)  ;; SAVE SMREG FOR TYPEOUT
3568 017752 104402          TYPOC          ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
3569 017754 104401 020562          TYPE   ,SMNEW        ;; PROMPT FOR NEW SMR
3570 017760 005046          19S:  CLR    -(SP)     ;; CLEAR COUNTER
3571 017762 005046          CLR    -(SP)         ;; THE NEW SMR
3572 017764 105777 161154          7S:   TSTB   $STKS    ;; CHAR THERE?
3573 017770 100375          BPL    7S            ;; IF NOT TRY AGAIN
3574
3575 017772 117746 161150          MOVB   $STKB,-(SP)    ;; PICK UP CHAR
3576 017776 042716 177600          BIC    $1C177,(SP)    ;; MAKE IT 7-BIT ASCII
3577
3578
3579
3580 020002 021627 000025          9S:   CMP    (SP),#25   ;; IS IT A CONTROL-U?
3581 020006 001005          BNE     10$           ;; BRANCH IF NOT
3582 020010 104401 020537          TYPE   ,SCNTLU        ;; YES, ECHO CONTROL-U (1U)
    
```

```

3583 020014 062706 000006      20$: ADD      #6,SP      ;; IGNORE PREVIOUS INPUT
3584 020020 000757              BR        19$      ;; LET'S TRY IT AGAIN
3585
3586
3587 020022 021627 000015      10$: CMP      (SP),#15  ;; IS IT A <CR>?
3588 020026 001022              BNE      16$      ;; BRANCH IF NO
3589 020030 005766 000004              TST      4(SP)    ;; YES, IS IT THE FIRST CHAR?
3590 020034 001403              BEQ      11$      ;; BRANCH IF YES
3591 020036 016677 000002 161074      MOV      2(SP),@SMR ;; SAVE NEW SMR
3592 020044 062706 000006      11$: ADD      #6,SP      ;; CLEAR UP STACK
3593 020050 104401 001173      14$: TYPE    ,SCLF    ;; ECHO <CR> AND <LF>
3594 020054 123727 001135 000001      CMPB    $INTAG,#1  ;; RE-ENABLE TTY KBD INTERRUPTS?
3595 020062 001003              BNE      15$      ;; BRANCH IF NOT
3596 020064 012777 000100 161052      MOV      #100,@STKS ;; RE-ENABLE TTY KBD INTERRUPTS
3597 020072 000002      15$: RTI              ;; RETURN
3598 020074 004737 017150      16$: JSR      PC,STYPEC ;; ECHO CHAR
3599 020100 021627 000060      CMP      (SP),#60  ;; CHAR < 0?
3600 020104 002420              BLT      18$      ;; BRANCH IF YES
3601 020106 021627 000067      CMP      (SP),#67  ;; CHAR > ??
3602 020112 003015              BGT      18$      ;; BRANCH IF YES
3603 020114 042726 000060      BIC      #60,(SP)+ ;; STRIP-OFF ASCII
3604 020120 005766 000002      TST      2(SP)    ;; IS THIS THE FIRST CHAR
3605 020124 001403              BEQ      17$      ;; BRANCH IF YES
3606 020126 006316              ASL      (SP)     ;; NO, SHIFT PRESENT
3607 020130 006316              ASL      (SP)     ;; CHAR OVER TO MAKE
3608 020132 006316              ASL      (SP)     ;; ROOM FOR NEW ONE.
3609 020134 005266 000002      17$: INC      2(SP)    ;; KEEP COUNT OF CHAR
3610 020140 056616 177776      BIS      -2(SP),(SP) ;; SET IN NEW CHAR
3611 020144 000707              BR        7$      ;; GET THE NEXT ONE
3612 020146 104401 001172      18$: TYPE    ,SQUES  ;; TYPE ?<CR><LF>
3613 020152 000720              BR        20$    ;; SIMULATE CONTROL-U
3614
3615
3616
3617
3618
3619
3620
3621
3622
3623
3624
3625 020154 011646 000004 000002      $R0CHR: MOV      (SP),-(SP) ;; PUSH DOWN THE PC
3626 020156 016666 000004 000002      MOV      4(SP),2(SP) ;; SAVE THE PS
3627 020164 105777 160754      1$: TSTB    @STKS   ;; WAIT FOR
3628 020170 100375              BPL      1$      ;; A CHARACTER
3629 020172 117766 160750 000004      MOVB    @STKB,4(SP) ;; READ THE TTY
3630 020200 042766 177600 000004      BIC      #1C<177>,4(SP) ;; GET RID OF JUNK IF ANY
3631 020206 026627 000004 000023      CMP      4(SP),#23 ;; IS IT A CONTROL-S?
3632 020214 001013              BNE      3$      ;; BRANCH IF NO
3633 020216 105777 160722      2$: TSTB    @STKS   ;; WAIT FOR A CHARACTER
3634 020222 100375              BPL      2$      ;; LOOP UNTIL ITS THERE
3635 020224 117746 160716      MOVB    @STKB,-(SP) ;; GET CHARACTER
3636 020230 042716 177600      BIC      #1C177,(SP) ;; MAKE IT 7-BIT ASCII
3637 020234 022627 000021      CMP      (SP)+,#21 ;; IS IT A CONTROL-Q?
3638 020240 001366              BNE      2$      ;; IF NOT DISCARD IT

```

***** THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY *****

*CALL: * R0CHR * INPUT A SINGLE CHARACTER FROM THE TTY * RETURN HERE * CHARACTER IS ON THE STACK * WITH PARITY BIT STRIPPED OFF *

```

3625 020154 011646 000004 000002      $R0CHR: MOV      (SP),-(SP) ;; PUSH DOWN THE PC
3626 020156 016666 000004 000002      MOV      4(SP),2(SP) ;; SAVE THE PS
3627 020164 105777 160754      1$: TSTB    @STKS   ;; WAIT FOR
3628 020170 100375              BPL      1$      ;; A CHARACTER
3629 020172 117766 160750 000004      MOVB    @STKB,4(SP) ;; READ THE TTY
3630 020200 042766 177600 000004      BIC      #1C<177>,4(SP) ;; GET RID OF JUNK IF ANY
3631 020206 026627 000004 000023      CMP      4(SP),#23 ;; IS IT A CONTROL-S?
3632 020214 001013              BNE      3$      ;; BRANCH IF NO
3633 020216 105777 160722      2$: TSTB    @STKS   ;; WAIT FOR A CHARACTER
3634 020222 100375              BPL      2$      ;; LOOP UNTIL ITS THERE
3635 020224 117746 160716      MOVB    @STKB,-(SP) ;; GET CHARACTER
3636 020230 042716 177600      BIC      #1C177,(SP) ;; MAKE IT 7-BIT ASCII
3637 020234 022627 000021      CMP      (SP)+,#21 ;; IS IT A CONTROL-Q?
3638 020240 001366              BNE      2$      ;; IF NOT DISCARD IT

```



```

3695 020476 104401 001174 TYPE SLF :: TYPE A LINE FEED
3696 020502 005726 TST (SP)+ :: CLEAN RUBOUT KEY FROM THE STACK
3697 020504 012603 MOV (SP)+,R3 :: RESTORE R3
3698 020506 011646 MOV (SP)-,(SP) :: ADJUST THE STACK AND PUT ADDRESS OF THE
3699 020510 016666 000004 000002 MOV 4(SP),2(SP) :: FIRST ASCII CHARACTER ON IT
3700 020516 012766 020530 000004 MOV #STTYIN,4(SP)
3701 020524 000002 RTI :: RETURN
3702 020526 000002 95: .BYTE 0 :: STORAGE FOR ASCII CHAR. TO TYPE
3703 020527 000002 .BYTE 0 :: TERMINATOR
3704 020530 000007 STTYIN: .BLKB 7 :: RESERVE 7 BYTES FOR TTY INPUT
3705 020537 136 006525 000012 SCNTLU: .ASCIZ /IU<15><12> :: CONTROL "U"
3706 020544 043536 005015 000 SCNTLG: .ASCIZ /IG<15><12> :: CONTROL "G"
3707 020551 015 051412 051127 SMSWR: .ASCIZ <15><12>/SWR = /
3708 020556 036440 000040 SMNEW: .ASCIZ / NEW = /
3709 020562 020040 042516 020127 .EVEN
3710 020570 020075 000
3711 020574 .SBTTL READ AN OCTAL NUMBER FROM THE TTY
3712
3713
3714
3715 :: *****
3716 :: THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
3717 :: CHANGE IT TO BINARY.
3718 :: THE INPUT CHARACTERS WILL BE CHECKED TO INSURED THEY ARE LEGAL
3719 :: OCTAL DIGITS. IF AN ILLEGAL CHARACTER IS READ A "?" WILL BE TYPED
3720 :: FOLLOWED BY A CARRIAGE RETURN-LINE FEED. THE COMPLETE NUMBER MUST
3721 :: THEN BE RETYPED. THE INPUT IS TERMINATED BY TYPING A CARRIAGE RETURN.
3722 :: CALL:
3723 :: * RDOCT :: READ AN OCTAL NUMBER
3724 :: * RETURN HERE :: LOW ORDER BITS ARE ON TOP OF THE STACK
3725 :: * :: HIGH ORDER BITS ARE IN SHIOCT
3726
3727 020574 011646 SDOCT: MOV (SP)-,(SP) :: PROVIDE SPACE FOR THE
3728 020576 016666 000004 000002 MOV 4(SP),2(SP) :: INPUT NUMBER
3729 020604 010046 MOV R0,-(SP) :: PUSH R0 ON STACK
3730 020606 010146 MOV R1,-(SP) :: PUSH R1 ON STACK
3731 020610 010246 MOV R2,-(SP) :: PUSH R2 ON STACK
3732 020612 104411 15: RDLIN :: READ AN ASCII LINE
3733 020614 012600 MOV (SP)+,R0 :: GET ADDRESS OF 1ST CHARACTER
3734 020616 010037 020722 MOV R0,55 :: AND SAVE IT
3735 020622 005001 CLR R1 :: CLEAR DATA WORD
3736 020624 005002 CLR R2
3737 020626 112046 25: MOVB (R0)+,-(SP) :: PICKUP THIS CHARACTER
3738 020630 001420 BEQ 35 :: IF ZERO GET OUT
3739 020632 122716 000060 CMPB #'0,(SP) :: MAKE SURE THIS CHARACTER
3740 020636 003026 BGT 45 :: IS AN OCTAL DIGIT
3741 020640 122716 000067 CMPB #'7,(SP)
3742 020644 002423 BLT 45
3743 020646 006301 ASL R1 :: *2
3744 020650 006102 ROL R2
3745 020652 006301 ASL R1 :: *4
3746 020654 006102 ROL R2
3747 020656 006301 ASL R1 :: *8
3748 020660 006102 ROL R2
3749 020662 042716 177770 BIC #1C7,(SP) :: STRIP THE ASCII JUNK
3750 020666 062601 ADD (SP)+,R1 :: ADD IN THIS DIGIT
    
```

```

3751 020670 000756          BR      25          ;; LOOP
3752 020672 005726          35:   TST      (SP)+        ;; CLEAN TERMINATOR FROM STACK
3753 020674 010166 000012   MOV      R1,12(SP)    ;; SAVE THE RESULT
3754 020700 010237 020732   MOV      R2,SHIOCT
3755 020704 012602          MOV      (SP)+,R2     ;; POP STACK INTO R2
3756 020706 012601          MOV      (SP)+,R1     ;; POP STACK INTO R1
3757 020710 012600          MOV      (SP)+,R0     ;; POP STACK INTO R0
3758 020712 000002          RTI
3759 020714 005726          45:   TST      (SP)+        ;; CLEAN PARTIAL FROM STACK
3760 020716 105010          CLRB     (R0)         ;; SET A TERMINATOR
3761 020720 104401          TYPE
3762 020722 000000          55:   .WORD    0        ;; TYPE UP THRU THE BAD CHAR.
3763 020724 104401 001172   TYPE    $QUES        ;; "?" "CR" & "LF"
3764 020730 000730          BR      15          ;; TRY AGAIN
3765 020732 000000          SHIOCT: .WORD, 0     ;; HIGH ORDER BITS GO HERE
3766
3767          .SBTTL SCOPE HANDLER ROUTINE
3768
3769          ;; *****
3770          ;; THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
3771          ;; AND LOAD THE TEST NUMBER($STNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
3772          ;; AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
3773          ;; THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
3774          ;; $SW14=1 LOOP ON TEST
3775          ;; $SW11=1 INHIBIT ITERATIONS
3776          ;; $SW09=1 LOOP ON ERROR
3777          ;; $SW08=1 LOOP ON TEST IN SWR<6:0>
3778          ;; $CALL
3779          ;; SCOPE          ;; SCOPE=IOT
3780
3781 020734          $$SCOPE:
3782 020734 104407          CKSWR
3783 020736 032777 040000 160174 15:   BIT      #BIT14,$SWR    ;; TEST FOR CHANGE IN SOFT-SWR
3784 020744 001114          BNE     $OVER         ;; LOOP ON PRESENT TEST?
3785          ;; *****START OF CODE FOR THE XOR TESTER*****
3786 020746 000416          $XTSTR: BR      65
3787          ;; IF RUNNING ON THE "XOR" TESTER CHANGE
3788 020750 013746 000004          MOV     @ERRVEC,-(SP)  ;; THIS INSTRUCTION TO A "NOP" (NOP=240)
3789 020754 012737 020774 000004          MOV     $$,@ERRVEC   ;; SAVE THE CONTENTS OF THE ERROR VECTOR
3790 020762 005737 177060          TST     @177060       ;; SET FOR TIMEOUT
3791 020766 012637 000004          MOV     (SP)+,@ERRVEC ;; TIME OUT ON XOR?
3792 020772 000466          BR      $SVLAD        ;; RESTORE THE ERROR VECTOR
3793 020774 022626          55:   CMP     (SP)+,(SP)+  ;; GO TO THE NEXT TEST
3794 020776 012637 000004          MOV     (SP)+,@ERRVEC ;; CLEAR THE STACK AFTER A TIME OUT
3795 021002 000426          BR      75           ;; RESTORE THE ERROR VECTOR
3796 021004          65:; *****END OF CODE FOR THE XOR TESTER*****
3797 021004 032777 000400 160126          BIT     #BIT08,$SWR    ;; LOOP ON SPEC. TEST?
3798 021012 001407          BEQ     25           ;; BR IF NO
3799 021014 017746 160120          MOV     @SWR,-(SP)     ;; SET DESIRED TEST NUM. FROM SWR
3800 021020 042716 000200          BIC     $$SWRMK,(SP)   ;; STRIP AWAY UNDESIRED BITS
3801 021024 122637 001102          CMPB   (SP)+,$STNM    ;; ON THE RIGHT TEST?
3802 021030 001462          BEQ     $OVER         ;; BR IF YES
3803 021032 105737 001103          25:   TSTB   $ERFLG      ;; HAS AN ERROR OCCURRED?
3804 021036 001421          BEQ     35           ;; BR IF NO
3805 021040 123737 001115 001103          CMPB   $ERMAX,$ERFLG  ;; MAX. ERRORS FOR THIS TEST OCCURRED?
3806 021046 101015          BHI     35           ;; BR IF NO

```

```

3807 021050 032777 001000 160062 BIT #BIT09,2SWR :: LOOP ON ERROR?
3808 021056 001404 BEQ 45 :: BR IF NO
3809 021060 013737 001110 001106 7S: MOV SLPERR,SLPADR :: SET LOOP ADDRESS TO LAST SCOPE
3810 021066 000443 BR SOVER
3811 021070 105037 001103 4S: CLRB SERFLG :: ZERO THE ERROR FLAG
3812 021074 005037 001162 CLR $TIMES :: CLEAR THE NUMBER OF ITERATIONS TO MAKE
3813 021100 000415 BR 15 :: ESCAPE TO THE NEXT TEST
3814 021102 032777 004000 160030 3S: BIT #BIT11,2SWR :: INHIBIT ITERATIONS?
3815 021110 001011 BNE 15 :: BR IF YES
3816 021112 005737 001100 TST $PASS :: IF FIRST PASS OF PROGRAM
3817 021116 001406 BEQ 15 :: INHIBIT ITERATIONS
3818 021120 005237 001104 INC $ICNT :: INCREMENT ITERATION COUNT
3819 021124 023737 001162 001104 CMP $TIMES,$ICNT :: CHECK THE NUMBER OF ITERATIONS MADE
3820 021132 002021 BGE SOVER :: BR IF MORE ITERATION REQUIRED
3821 021134 012737 000001 001104 1S: MOV #1,$ICNT :: REINITIALIZE THE ITERATION COUNTER
3822 021142 013737 021212 001162 MOV $SMXCNT,$TIMES :: SET NUMBER OF ITERATIONS TO DO
3823 021150 105237 001102 $SVLAD: INCB $STSTNM :: COUNT TEST NUMBERS
3824 021154 011637 001106 MOV (SP),SLPADR :: SAVE SCOPE LOOP ADDRESS
3825 021160 011637 001110 MOV (SP),SLPERR :: SAVE ERROR LOOP ADDRESS
3826 021164 005037 001164 CLR $ESCAPE :: CLEAR THE ESCAPE FROM ERROR ADDRESS
3827 021170 112737 000001 001115 MOVB #1,$SERMAX :: ONLY ALLOW ONE(1) ERROR ON NEXT TEST
3828 021176 013777 001102 157736 SOVER: MOV $STSTNM,$DISPLAY :: DISPLAY TEST NUMBER
3829 021204 013716 001106 MOV SLPADR,(SP) :: FUDGE RETURN ADDRESS
3830 021210 000002 RTI :: FIXES PS
3831 021212 000764 $SMXCNT: 500. :: MAX. NUMBER OF ITERATIONS

```

.SBTTL SAVE AND RESTORE R0-R5 ROUTINES

::*****:*****

```

::#SAVE R0-R5
::#CALL:
::# SAVREG
::#UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
::#
::#TOP---(+16)
::# +2---(+18)
::# +4---R5
::# +6---R4
::# +8---R3
::#+10---R2
::#+12---R1
::#+14---R0

```

```

$SAVREG:
MOV R0,-(SP) :: PUSH R0 ON STACK
MOV R1,-(SP) :: PUSH R1 ON STACK
MOV R2,-(SP) :: PUSH R2 ON STACK
MOV R3,-(SP) :: PUSH R3 ON STACK
MOV R4,-(SP) :: PUSH R4 ON STACK
MOV R5,-(SP) :: PUSH R5 ON STACK
MOV 22(SP),-(SP) :: SAVE PS OF MAIN FLOW
MOV 22(SP),-(SP) :: SAVE PC OF MAIN FLOW
MOV 22(SP),-(SP) :: SAVE PS OF CALL
MOV 22(SP),-(SP) :: SAVE PC OF CALL
RTI

```

```

3850 021214
3851 021214 010046
3852 021216 010146
3853 021220 010246
3854 021222 010346
3855 021224 010446
3856 021226 010546
3857 021230 016646 000022
3858 021234 016646 000022
3859 021240 016646 000022
3860 021244 016646 000022
3861 021250 000002
3862

```

```

3853
3854
3855
3856 021250
3857 021250 012666 000022
3858 021256 012666 000022
3859 021262 012666 000022
3870 021266 012666 000022
3871 021272 012605
3872 021274 012604
3873 021276 012603
3874 021300 012602
3875 021302 012601
3876 021304 012600
3877 021306 000002

```

```

;#RESTORE RO-RS
;#CALL:
;# RESREG
$RESREG:
MOV (SP)+,22(SP) ;:RESTORE PC OF CALL
MOV (SP)+,22(SP) ;:RESTORE PS OF CALL
MOV (SP)+,22(SP) ;:RESTORE PC OF MAIN FLOW
MOV (SP)+,22(SP) ;:RESTORE PS OF MAIN FLOW
MOV (SP)+,R5 ;:POP STACK INTO R5
MOV (SP)+,R4 ;:POP STACK INTO R4
MOV (SP)+,R3 ;:POP STACK INTO R3
MOV (SP)+,R2 ;:POP STACK INTO R2
MOV (SP)+,R1 ;:POP STACK INTO R1
MOV (SP)+,R0 ;:POP STACK INTO R0
RTI

```

.SBTTL TRAP DECODER

```

3881
3882
3883
3884
3885
3886
3887 021310 010046
3888 021312 016600 000002
3889 021316 005740
3890 021320 111000
3891 021322 006300
3892 021324 016000 021344
3893 021330 000200

```

```

;:*****
;#THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
;#AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
;#OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
;#GO TO THAT ROUTINE.
STRAP: MOV RO,-(SP) ;:SAVE RO
MOV 2(SP),RO ;:GET TRAP ADDRESS
TST -(RO) ;:BACKUP BY 2
MOVB (RO),RO ;:GET RIGHT BYTE OF TRAP
ASL RO ;:POSITION FOR INDEXING
MOV $TRPAD(RO),RO ;:INDEX TO TABLE
RTS RO ;:GO TO ROUTINE

```

;;THIS IS USE TO HANDLE THE "GETPRI" MACRO

```

3898 021332 011646
3899 021334 016666 000004 000002
3900 021342 000002

```

```

STRAP2: MOV (SP),-(SF) ;:MOVE THE PC DOWN
MOV 4(SP),2(SP) ;:MOVE THE PSW DOWN
RTI ;:RESTORE THE PSW

```

.SBTTL TRAP TABLE

```

3902
3903
3904
3905
3906
3907
3908
3909 021344 021332
3910 021346 017000
3911 021350 017244
3912 021352 017220
3913 021354 017260
3914 021356 017446
3915
3916 021360 017742
3917
3918 021362 017672

```

```

;#THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
;#BY THE "TRAP" INSTRUCTION.
:
ROUTINE
-----
$TRPAD: .WORD STRAP2
$TYPE ;:CALL=TYPE TRAP+1(104401) TTY TYPEOUT ROUTINE
$TYPOC ;:CALL=TYPOC TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
$TYPOS ;:CALL=TYPOS TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
$TYPON ;:CALL=TYPON TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
$TYPDS ;:CALL=TYPDS TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)
$GTSWR ;:CALL=GTSWR TRAP+6(104406) GET SOFT-SWR SETTING
$CKSWR ;:CALL=CKSWR TRAP+7(104407) TEST FOR CHANGE IN SOFT-SWR

```


3919 021364 020154
 3920 021366 020274
 3921 021370 020574
 3922 021372 021214
 3923 021374 021252
 3924
 3925
 3926
 3927
 3928
 3929
 3930
 3931 021376 005737 001204
 3932 021402 001514
 3933 021404 005037 001204
 3934 021410
 3935 021410 104401 021416
 3936 021414 000405
 3937
 3938 021430
 3939 021430 013746 001210
 3940
 3941 021434 104403
 3942 021436 006
 3943 021437 001
 3944 021440 104401 021446
 3945 021444 000401
 3946
 3947 021450
 3948 021450 104412
 3949 021452 012600
 3950 021454 001402
 3951 021456 010037 001210
 3952 021462
 3953 021462 104401 021470
 3954 021466 000404
 3955
 3956 021500
 3957 021500 013746 001212
 3958
 3959 021504 104403
 3960 021506 006
 3961 021507 001
 3962 021510 104401 021516
 3963 021514 000401
 3964
 3965 021520
 3966 021520 104412
 3967 021522 012600
 3968 021524 001402
 3969 021526 010037 001212
 3970 021532
 3971 021532 104401 021540
 3972 021536 000404
 3973
 3974 021550

SROCHR ::CALL=ROCHR TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
 SROLIN ::CALL=ROLIN TRAP+11(104411) TTY TYPEIN STRING ROUTINE
 SRODOCT ::CALL=RODOCT TRAP+12(104412) READ AN OCTAL NUMBER FROM TTY
 SRAVREG ::CALL=SAVREG TRAP+13(104413) SAVE RO-R5 ROUTINE
 SRESREG ::CALL=RESREG TRAP+14(104414) RESTORE RO-R5 ROUTINE

: THIS ROUTINE IS USED TO ENSURE THAT THE BUS ADDRESS
 : OF THE RP11 IS SETUP TO READ THE PROPER VALUE.
 : IT WILL ALSO READ THE ADDRESS FROM THE TTY IF
 : REQUIRED.
 : NOTE: THIS ROUTINE DOES NOT PROTECT RO-R4

GETADR: TST BUSADR ; INPUT FROM TTY REQUESTED?
 BEQ 55 ; NO--BRANCH
 CLR BUSADR ; YES--CLEAR THE REQUEST FLAG
 15: TYPE 655 ; TYPE ASCIZ STRING
 BR 645 ; GET OVER THE ASCIZ
 ::655: .ASCIZ <15><12>/RPAOR=
 645: MOV RPAOR,-(SP) ; SAVE RPAOR FOR TYPEOUT
 ; RP11 ADDRESS
 ; GO TYPE--OCTAL ASCII
 TYPOS 6 ; TYPE 6 DIGIT(S)
 .BYTE 1 ; TYPE LEADING ZEROS
 .BYTE 1 ; TYPE ASCIZ STRING
 TYPE 675 ; GET OVER THE ASCIZ
 BR 665
 ::675: .ASCIZ 2/2
 665: RDOCT ; GET NEW RP11 ADDRESS
 MOV (SP)+,RO ; SAVE THE ADDRESS
 BEQ 25 ; BR IF ZERO ENTRY OR A 'CR'
 MOV RO,RPAOR ; STORE THE ADDRESS
 25: TYPE 695 ; TYPE ASCIZ STRING
 BR 685 ; GET OVER THE ASCIZ
 ::695: .ASCIZ /RPVEC=
 685: MOV RPVEC,-(SP) ; SAVE RPVEC FOR TYPEOUT
 ; RP11 VECTOR ADDRESS
 ; GO TYPE--OCTAL ASCII
 TYPOS 6 ; TYPE 6 DIGIT(S)
 .BYTE 1 ; TYPE LEADING ZEROS
 .BYTE 1 ; TYPE ASCIZ STRING
 TYPE 715 ; GET OVER THE ASCIZ
 BR 705
 ::715: .ASCIZ 2/2
 705: RDOCT ; READ NEW RP11 VECTOR
 MOV (SP)+,RO ; STORE THE VECTOR ADDRESS
 BEQ 35 ; BR IF ZERO ENTRY OR 'CR'
 MOV RO,RPVEC ; SAVE NEW RP11 VECTOR ADDRESS
 35: TYPE 735 ; TYPE ASCIZ STRING
 BR 725 ; GET OVER THE ASCIZ
 ::735: .ASCIZ /RPPRI0=
 725:

```

3975 021550 013700 001216      MOV      RPPRIO,RO      ;CONVERT PRIORITY FOR TYPEOUT
3976 021554 006300              ASL      RO
3977 021556 006300              ASL      RO
3978 021560 006300              ASL      RO
3979 021562 000300              SWAB     RO
3980 021564 010046              MOV      RO,-(SP)      ;ALIGN FOR TYPEOUT
3981                                ;SAVE RO FOR TYPEOUT
3982 021566 104403              TYPOS    ;RP11 PRIORITY
3983 021570 001                .BYTE   1              ;GO TYPE--OCTAL ASCII
3984 021571 001                .BYTE   1              ;TYPE 1 DIGIT(S)
3985 021572 104401 021600      TYPE     755           ;TYPE LEADING ZEROS
3986 021576 000401              BR       745           ;TYPE ASCIZ STRING
3987                                ;GET OVER THE ASCIZ
3988 021602              ;:755:
3989 021602 104412              ;:745:
3990 021604 012600              RDOCT
3991 021606 001407              MOV      (SP)+,RO      ;GET NEW PRIORITY LEVEL
3992 021610 006300              BEQ      45            ;SAVE NEW PRIORITY
3993 021612 006300              ASL      RO            ;BR IF ZERO ENTRY OR A 'CR'
3994 021614 006300              ASL      RO            ;CONVERT TO PRIORITY VALUE
3995 021616 006300              ASL      RO            ;CONVERT TO PRIORITY VALUE
3996 021620 006300              ASL      RO            ;CONVERT TO PRIORITY VALUE
3997 021622 010037 001216      MOV      RO,RPPRIO     ;CONVERT TO PRIORITY VALUE
3998 021626 013777 001216 157360 45:      MOV      RPPRIO,3PVEC+2 ;SAVE THE VALUE
3999 021634 013701 000004 55:      MOV      ERRVEC,R1     ;LOAD NEW PRIORITY VALUE
4000 021640 012737 021660 000004      MOV      865,ERRVEC    ;SAVE THE ERROR VECTOR
4001 021646 005777 157336      TST     3PADR          ;SETUP FOR TRAP
4002 021652 010137 000004      MOV      R1,ERRVEC     ;CHECK FOR RP11
4003 021656 000207              RTS      PC            ;RESTORE ERROR VECTOR
4004 021660 010137 000004 65:      MOV      R1,ERRVEC     ;RETURN
4005 021664 022626              CMP      (SP)+,(SP)+   ;RESTORE ERROR VECTOR
4006 021666 104001              ERROR    1             ;CLEAN OFF THE STACK
4007 021670 005737 000042      TST     3#42          ;REPORT THE ERROR
4008 021674 001645              BEQ      15            ;IS THERE A MONITOR?
4009 021676 005037 016312      CLR      SEOPCT        ;NO--GO ASK FOR ADDRESS AGAIN
4010 021702 000137 016162      JMP      SEOP           ;NO PASSES
4011                                ;GO TO END OF PROGRAM
4012                                ;ROUTINE TO CLEAR THE RP11E IN MAINTENANCE MODE
4013
4014 021706 012737 060001 001206  CLR#:  MOV      8BIT14!BIT13!BIT00,TPL
4015 021714 012764 000001 000004      MOV      81,RPCS(R4)   ;CLEAR THE CONTROLLER
4016 021722 004737 021756              JSR      PC,T3P        ;GENERATE 3 CLOCK PULSES
4017 021726 052764 020000 000022      BIS      8BIT13,RPM3(R4) ;SET 'SUOL'
4018 021734 000207              RTS      PC            ;RETURN
4019
4020                                ;GENERATE CLOCK PULSES
4021
4022 021736 012046              TIMEP:  MOV      (RO)+,-(SP) ;GET NUMBER OF CLOCK PULSES
4023 021740 013764 001206 000022 15:      MOV      TPL,RPM3(R4)  ;SET SPECIFIED MAINTENANCE BITS
4024 021746 005316              DEC      (SP)          ;DECREMENT THE COUNT
4025 021750 001373              BNE     15            ;BR IF MORE CLOCK PULSES
4026 021752 005726              TST     (SP)+         ;RESTORE THE STACK POINTER
4027 021754 000200              RTS      RO            ;RETURN
4028
4029                                ;ROUTINE TO GENERATE 3 CLOCK PULSES
4030

```


DZRPWB.CMB TRAP TABLE

4087	022276	043117	020106	047506	
4088	022304	020122	044124	105	
4089	022311	015	050012	047522	.ASCII <15><12>PROGRAM TO FUNCTION PROPERLY. IF DRIVE 0 IS CYCLED
4090	022316	051107	046501	052040	
4091	022324	020117	052506	041516	
4092	022332	044524	047117	050040	
4093	022340	047522	042520	046122	
4094	022346	027131	020040	043111	
4095	022354	042040	044522	042526	
4096	022362	030040	044440	020123	
4097	022370	054503	046103	042105	
4098	022376	005015	050125	020054	.ASCII <15><12>JUP, STOP THE PROGRAM, CYCLE DOWN THE DRIVE, AND
4099	022404	052123	050117	052040	
4100	022412	042510	050040	047522	
4101	022420	051107	046501	020054	
4102	022426	054503	046103	020105	
4103	022434	047504	047127	052040	
4104	022442	042510	042040	044522	
4105	022450	042526	020054	047101	
4106	022456	104			
4107	022457	015	051012	051505	.ASCIZ <15><12>RESTART THE PROGRAM<15><12><12>
4108	022464	040524	052122	052040	
4109	022472	042510	050040	047522	
4110	022500	051107	046501	005015	
4111	022506	000012			
4112					
4113					.EVEN
4114					
4115					.SBTTL ERROR MESSAGES
4116					
4117	022510	050122	030461	042040	EM1: .ASCIZ RP11 DIDN'T RESPOND TO ADDRESSING
4118	022516	042111	023516	020124	
4119	022524	042522	050123	047117	
4120	022532	020104	047524	040440	
4121	022540	042104	042522	051523	
4122	022546	047111	000107		
4123	022552	040503	023516	020124	EM2: .ASCIZ CAN'T LOAD REGISTER CORRECTLY
4124	022560	047514	042101	051040	
4125	022566	043505	051511	042524	
4126	022574	020122	047503	051122	
4127	022602	041505	046124	000131	
4128	022610	042522	042523	020124	EM3: .ASCIZ RESET DIDN'T CLEAR REGISTER
4129	022616	044504	047104	052047	
4130	022624	041440	042514	051101	
4131	022632	051040	043505	051511	
4132	022640	042524	000122		
4133	022644	047503	052116	047522	EM4: .ASCIZ CONTROLLER CLEAR DIDN'T CLEAR REGISTER
4134	022652	046114	051105	041440	
4135	022660	042514	051101	042040	
4136	022666	042111	023516	020124	
4137	022674	046103	040505	020122	
4138	022702	042522	044507	052123	
4139	022710	051105	000		
4140	022713	106	047514	052101	EM5: .ASCIZ FLOATING 1'S & 0'S TEST ERROR
4141	022720	047111	020107	023461	
4142	022726	020123	020046	023460	

DZRPWB.CMB ERROR MESSAGES

4143	022734	020123	042524	052123		
4144	022742	042440	051122	051117		
4145	022750	000				
4146	022751	122	043505	051511	EM6:	.ASCIZ @REGISTER RAPID ACCESS TEST ERROR@
4147	022756	042524	020122	040522		
4148	022764	044520	020104	041501		
4149	022772	042503	051523	052040		
4150	023000	051505	020124	051105		
4151	023006	047522	000122			
4152	023012	040503	023516	020124	EM7:	.ASCIZ @CAN'T SET 'SURDY' BIT@
4153	023020	042523	020124	051447		
4154	023026	051125	054504	020047		
4155	023034	044502	000124			
4156	023040	040503	023516	020124	EM10:	.ASCIZ @CAN'T CLEAR THE 'SURDY' BIT@
4157	023046	046103	040505	020122		
4158	023054	044124	020105	051447		
4159	023062	051125	054504	020047		
4160	023070	044502	000124			
4161	023074	040503	023516	020124	EM11:	.ASCIZ @CAN'T SET 'SUSI'@
4162	023102	042523	020124	051447		
4163	023110	051525	023511	000		
4164	023115	047	051504	020113	EM12:	.ASCIZ @'DSK ERR' NOT SET WITH 'SUSI'@
4165	023122	051105	023522	047040		
4166	023130	052117	051440	052105		
4167	023136	053440	052111	020110		
4168	023144	051447	051525	023511		
4169	023152	000				
4170	023153	047	051105	023522	EM13:	.ASCIZ @'ERR' OR 'HE' NOT SET WITH 'SUSI'@
4171	023160	047440	020122	044047		
4172	023166	023505	047040	052117		
4173	023174	051440	052105	053440		
4174	023202	052111	020110	051447		
4175	023210	051525	023511	000		
4176	023215	103	047101	052047	EM14:	.ASCIZ @CAN'T SET 'SUFU'@
4177	023222	051440	052105	023440		
4178	023230	052523	052506	000047		
4179	023236	040503	023516	020124	EM15:	.ASCIZ @CAN'T CLEAR 'SUFU'@
4180	023244	046103	040505	020122		
4181	023252	051447	043125	023525		
4182	023260	000				
4183	023261	103	047101	052047	EM16:	.ASCIZ @CAN'T SET 'SUMP'@
4184	023266	051440	052105	023440		
4185	023274	052523	050127	000047		
4186	023302	040503	023516	020124	EM17:	.ASCIZ @CAN'T CLEAR 'SUMP'@
4187	023310	046103	040505	020122		
4188	023316	051447	053525	023520		
4189	023324	000				
4190	023325	103	047101	052047	EM20:	.ASCIZ @CAN'T SET ATTENTION BIT@
4191	023332	051440	052105	040440		
4192	023340	052124	047105	044524		
4193	023346	047117	041040	052111		
4194	023354	000				
4195	023355	103	047101	052047	EM21:	.ASCIZ @CAN'T CLEAR ATTENTION BIT@
4196	023362	041440	042514	051101		
4197	023370	040440	052124	047105		
4198	023376	044524	047117	041040		

4199	023404	052111	000		
4200	023407	122	051505	052105	EM22: .ASCIZ @RESET DIDN'T CLEAR ATTENTION BITS@
4201	023414	042040	042111	023516	
4202	023422	020124	046103	040505	
4203	023430	020122	052101	042524	
4204	023436	052116	047511	020116	
4205	023444	044502	051524	000	
4206	023451	101	052124	047105	EM23: .ASCIZ @ATTENTION BITS CLEARED BY WRITING 0'S INTO RPO@
4207	023456	044524	047117	041040	
4208	023464	052111	020123	046103	
4209	023472	040505	042522	020104	
4210	023500	054502	053440	044522	
4211	023506	044524	043516	030040	
4212	023514	051447	044440	052116	
4213	023522	020117	050122	051504	
4214	023530	000			
4215	023531	103	047101	052047	EM24: .ASCIZ @CAN'T SET 'MPV' ERROR@
4216	023536	051440	052105	023440	
4217	023544	050127	023526	042440	
4218	023550	051122	051117	000	
4219	023557	047	051105	023522	EM25: .ASCIZ @'ERR' OR 'HE' NOT SET WITH 'MPV'@
4220	023564	047440	020122	044047	
4221	023572	023505	047040	052117	
4222	023600	051440	052105	053440	
4223	023606	052111	020110	053447	
4224	023614	053120	000047		
4225	023620	040503	023516	020124	EM26: .ASCIZ @CAN'T SET 'FUV' ERROR@
4226	023626	042523	020124	043047	
4227	023634	053125	020047	051105	
4228	023642	047522	000122		
4229	023646	042447	051122	020047	EM27: .ASCIZ @'ERR' OR 'HE' NOT SET WITH 'FUV'@
4230	023654	051117	023440	042510	
4231	023662	020047	047516	020124	
4232	023670	042523	020124	044527	
4233	023676	044124	023440	052506	
4234	023704	023526	000		
4235	023707	047	054116	023503	EM30: .ASCIZ @'NXC' ERROR SET WITH VALID CYLINDER ADDRESS@
4236	023714	042440	051122	051117	
4237	023722	051440	052105	053440	
4238	023730	052111	020110	040526	
4239	023736	044514	020104	054503	
4240	023744	044514	042116	051105	
4241	023752	040440	042104	042522	
4242	023760	051523	000		
4243	023763	047	054116	023503	EM31: .ASCIZ @'NXC' DIDN'T SET WITH INVALID CYLINDER ADDRESS@
4244	023770	042040	042111	023516	
4245	023776	020124	042523	020124	
4246	024004	044527	044124	044440	
4247	024012	053116	046101	042111	
4248	024020	041440	046131	047111	
4249	024026	042504	020122	042101	
4250	024034	051104	051505	000123	
4251	024042	042447	051122	020047	EM32: .ASCIZ @'ERR' OR 'HE' DIDN'T SET WITH 'NXC'@
4252	024050	051117	023440	042510	
4253	024056	020047	044504	047104	
4254	024064	052047	051440	052105	

4255 024072 053440 052111 020110
 4256 024100 047047 041530 000047
 4257 024106 047047 052130 020047
 4258 024114 051105 047522 020122
 4259 024122 042523 020124 044527
 4260 024130 044124 053040 046101
 4261 024138 042111 052040 040522
 4262 024146 045503 040440 042104
 4263 024154 042522 051523 000
 4264 024157 047 054116 023524
 4265 024164 042040 042111 023516
 4266 024172 020124 042523 020124
 4267 024200 044527 044124 044440
 4268 024206 053116 046101 042111
 4269 024214 052040 040522 045503
 4270 024222 040440 042104 042522
 4271 024230 051523 000
 4272 024233 047 051105 023522
 4273 024240 047440 020122 044047
 4274 024246 023505 042040 042111
 4275 024254 023516 020124 042523
 4276 024262 020124 044527 044124
 4277 024270 023440 054116 023524
 4278 024276 000
 4279 024277 047 054116 023523
 4280 024304 042440 051122 051117
 4281 024312 051440 052105 053440
 4282 024320 052111 020110 040526
 4283 024326 044514 020104 042523
 4284 024334 052103 051117 040440
 4285 024342 042104 042522 051523
 4286 024350 000
 4287 024351 047 054116 023523
 4288 024356 042040 042111 023516
 4289 024364 020124 042523 020124
 4290 024372 044527 044124 044440
 4291 024400 053116 046101 042111
 4292 024406 051440 041505 047524
 4293 024414 020122 042101 051104
 4294 024422 051505 000123
 4295 024426 042447 051122 020047
 4296 024434 051117 023440 042510
 4297 024442 020047 044504 047104
 4298 024450 052047 051440 052105
 4299 024456 053440 052111 020110
 4300 024464 047047 051530 000047
 4301 024472 040503 023516 020124
 4302 024480 042523 020124 050047
 4303 024490 047522 023507 042440
 4304 024496 051122 051117 000
 4305 024521 047 051105 023522
 4306 024526 047440 020122 044047
 4307 024534 023505 047040 052117
 4308 024542 051440 052105 053440
 4309 024550 052111 020110 050047
 4310 024556 047522 023507 000

EM33: .ASCIZ @'NXT' ERROR SET WITH VALID TRACK ADDRESS@

EM34: .ASCIZ @'NXT' DIDN'T SET WITH INVALID TRACK ADDRESS@

EM35: .ASCIZ @'ERR' OR 'HE' DIDN'T SET WITH 'NXT'@

EM36: .ASCIZ @'NXS' ERROR SET WITH VALID SECTOR ADDRESS@

EM37: .ASCIZ @'NXS' DIDN'T SET WITH INVALID SECTOR ADDRESS@

EM40: .ASCIZ @'ERR' OR 'HE' DIDN'T SET WITH 'NXS'@

EM41: .ASCIZ @CAN'T SET 'PROG' ERROR@

EM42: .ASCIZ @'ERR' OR 'HE' NOT SET WITH 'PROG'@

DZRPWB.CMB ERROR MESSAGES

4311	024563	103	047101	052047	EM43:	.ASCIZ @CAN'T SET 'MODE' ERROR@
4312	024570	051440	052105	023440		
4313	024576	047515	042504	020047		
4314	024604	051105	047522	000122		
4315	024612	042447	051122	020047	EM44:	.ASCIZ @'ERR' OR 'HE' NOT SET WITH 'MODE'@
4316	024620	051117	023440	042510		
4317	024626	020047	047516	020124		
4318	024634	042523	020124	044527		
4319	024642	044124	023440	047515		
4320	024650	042504	000047			
4321	024654	040503	023516	020124	EM45:	.ASCIZ @CAN'T CLEAR 'SUSI'@
4322	024662	046103	040505	020122		
4323	024670	051447	051525	023511		
4324	024676	000				
4325	024677	116	020117	052101	EM46:	.ASCIZ @NO ATTENTION INTERRUPT@
4326	024704	042524	052116	047511		
4327	024712	020116	047111	042524		
4328	024720	051122	050125	000124		
4329	024726	040447	042511	020047	EM47:	.ASCIZ @'AIE' DIDN'T CLEAR WHEN INTERRUPT OCCURED@
4330	024734	044504	047104	052047		
4331	024742	041440	042514	051101		
4332	024750	053440	042510	020116		
4333	024756	047111	042524	051122		
4334	024764	050125	020124	041517		
4335	024772	052503	042522	000104		
4336	025000	047516	044440	052116	EM50:	.ASCIZ @NO INTERRUPT WITH ATTENTION BITS 0 & 1 SET@
4337	025006	051105	052522	052120		
4338	025014	053440	052111	020110		
4339	025022	052101	042524	052116		
4340	025030	047511	020116	044502		
4341	025036	051524	030040	023040		
4342	025044	030440	051440	052105		
4343	025052	000				
4344	025053	123	041505	047117	EM51:	.ASCIZ @SECOND INTERRUPT DIDN'T OCCUR WITH ATTENTION BIT 1 SET@
4345	025060	020104	047111	042524		
4346	025066	051122	050125	020124		
4347	025074	044504	047104	052047		
4348	025102	047440	041503	051125		
4349	025110	053440	052111	020110		
4350	025116	052101	042524	052116		
4351	025124	047511	020116	044502		
4352	025132	020124	020061	042523		
4353	025140	007124				
4354	025142	047516	044440	052116	EM52:	.ASCIZ @NO INTERRUPT FROM CONTROLLER 'READY'@
4355	025150	051105	052522	052120		
4356	025156	043040	047522	020115		
4357	025164	047503	052116	047522		
4358	025172	046114	051105	023440		
4359	025200	042522	042101	023531		
4360	025206	000				
4361	025207	047	042522	042101	EM53:	.ASCIZ @'READY' INTERRUPT WITH 'IDE' SET@
4362	025214	023531	044440	052116		
4363	025222	051105	052522	052120		
4364	025230	053440	052111	020110		
4365	025236	044447	042504	020047		
4366	025244	042523	000124			

4367	025250	047516	044440	052116	EMS4: .ASCIZ @NO INTERRUPT FROM RP11 WITH CPU AT PR4@
4368	025256	051105	052522	052120	
4369	025264	043040	047522	020115	
4370	025272	050122	030461	053440	
4371	025300	052111	020110	050103	
4372	025306	020125	052101	050040	
4373	025314	032122	000		
4374	025317	111	052116	051105	EMS5: .ASCIZ @INTERRUPT FROM RP11 WITH CPU AT PR5@
4375	025324	052522	052120	043040	
4376	025332	047522	020115	050122	
4377	025340	030461	053440	052111	
4378	025346	020110	050103	020125	
4379	025354	052101	050040	032522	
4380	025362	000			
4381	025363	111	052116	051105	EMS6: .ASCIZ @INTERRUPT FROM RP11 WITH CPU AT PR6@
4382	025370	052522	052120	043040	
4383	025376	047522	020115	050122	
4384	025404	030461	053440	052111	
4385	025412	020110	050103	020125	
4386	025420	052101	050040	033122	
4387	025426	000			

DZRPWB.CMB ERROR MESSAGES

4388	025427	111	052116	051105	EM57:	.ASCIZ	QINTERRUPT FROM RP11 WITH CPU AT PR7Q
4389	025434	052522	052120	043040			
4390	025442	047522	020115	050122			
4391	025450	030461	053440	052111			
4392	025456	020110	050103	020125			
4393	025464	052101	050040	033522			
4394	025472	000					
4395	025473	047	042522	042101	EM60:	.ASCIZ	Q'READY' DIDN'T CLEAR AT END OF OPERATIONSQ
4396	025500	023531	042040	042111			
4397	025506	023516	020124	046103			
4398	025514	040505	020122	052101			
4399	025522	042440	042116	047440			
4400	025530	020106	050117	051105			
4401	025536	052101	047511	000116			
4402	025544	051447	041525	023501	EM61:	.ASCIZ	Q'SUCA' INCORRECTQ
4403	025552	044440	041516	051117			
4404	025560	042522	052103	000			
4405	025567	111	042116	054105	EM62:	.ASCIZ	QINDEX DIDN'T CLEAR 'SOT'Q
4406	025572	042040	042111	023516			
4407	025600	020124	046103	040505			
4408	025606	020122	051447	052117			
4409	025614	000047					
4410	025616	051447	052117	020047	EM63:	.ASCIZ	Q'SOT' DIDN'T COUNT CORRECTLYQ
4411	025624	044504	047104	052047			
4412	025632	041440	052517	052116			
4413	025640	041440	051117	042522			
4414	025646	052103	054514	000			
4415	025653	103	047117	051124	EM64:	.ASCIZ	QCONTROLLER CLEAR DIDN'T SET SILO INPUT READYQ
4416	025660	046117	042514	020122			
4417	025666	046103	040505	020122			
4418	025674	044504	047104	052047			
4419	025702	051440	052105	051440			
4420	025710	046111	020117	047111			
4421	025716	052520	020124	042522			
4422	025724	042101	000131				
4423	025730	044523	047514	047440	EM65:	.ASCIZ	QSILO OUTPUT READY NOT SET AFTER WORD LOADED INTO SILOQ
4424	025736	052125	052520	020124			
4425	025744	042522	042101	020131			
4426	025752	047516	020124	042523			
4427	025760	020124	043101	042524			
4428	025766	020122	047527	042122			
4429	025774	046040	040517	042504			
4430	026002	020104	047111	047524			
4431	026010	051440	046111	000117			
4432	026016	040504	040524	051040	EM66:	.ASCIZ	QDATA READ FROM SILO IS INCORRECTQ
4433	026024	040505	020104	051106			
4434	026032	046517	051440	046111			
4435	026040	020117	051511	044440			
4436	026046	041516	051117	042522			
4437	026054	052103	000				
4438	026057	123	046111	020117	EM67:	.ASCII	QSILO INPUT READY DIDN'T CLEAR AFTER 64 WORDS WEREQ
4439	026064	047111	052520	020124			
4440	026072	042522	042101	020131			
4441	026100	044504	047104	052047			
4442	026106	041440	042514	051101			
4443	026114	040440	052106	051105			

DZRPWB.CMB ERROR MESSAGES

4444	026122	033040	020064	047527	
4445	026130	042122	020123	042527	
4446	026136	042522			
4447	026140	005015	047514	042101	.ASCIZ <15><12>@LOADED INTO THE SILO@
4448	026146	042105	044440	052116	
4449	026154	020117	044124	020105	
4450	026162	044523	047514	000	
4451	026167	123	046111	020117	EM70: .ASCIZ @SILO OUTPUT READY DIDN'T CLEAR AFTER SILO EMPTIED@
4452	026174	052517	050124	052125	
4453	026202	051040	040505	054504	
4454	026210	042040	042111	023516	
4455	026216	020124	046103	040505	
4456	026224	020122	043101	042524	
4457	026232	020122	044523	047514	
4458	026240	042440	050115	044524	
4459	026246	042105	000		
4460	026251	102	051525	047440	EM71: .ASCIZ @BUS OUT LINES TO THE DRIVE WERE NOT CLEARED BY CONTROLLER CLEAR@
4461	026256	052125	046040	047111	
4462	026264	051505	052040	020117	
4463	026272	044124	020105	051104	
4464	026300	053111	020105	042527	
4465	026306	042522	047040	052117	
4466	026314	041440	042514	051101	
4467	026322	042105	041040	020131	
4468	026330	047503	052116	047522	
4469	026336	046114	051105	041440	
4470	026344	042514	051101	000	
4471	026351	104	044522	042526	EM72: .ASCII @DRIVE BUS ERROR; 'SET CYLINDER' AND CYLINDER ADDRESS@
4472	026356	041040	051525	042440	
4473	026364	051122	051117	020073	
4474	026372	051447	052105	041440	
4475	026400	046131	047111	042504	
4476	026406	023522	040440	042116	
4477	026414	041440	046131	047111	
4478	026422	042504	020122	042101	
4479	026430	051104	051505	123	
4480	026435	015	051412	047510	.ASCIZ <15><12>@SHOULD BE ON THE BUS@
4481	026442	046125	020104	042502	
4482	026450	047440	020116	044124	
4483	026456	020105	052502	000123	
4484	026464	051104	053111	020105	EM73: .ASCIZ @DRIVE BUS ERROR: ONLY 'RESET HEAD' SHOULD BE ON THE BUS@
4485	026472	052502	020123	051105	
4486	026500	047522	035122	047440	
4487	026506	046116	020131	051047	
4488	026514	051505	052105	044040	
4489	026522	040505	023504	051440	
4490	026530	047510	046125	020104	
4491	026536	042502	047440	020116	
4492	026544	044124	020105	052502	
4493	026552	000123			
4494	026554	051104	053111	020105	EM74: .ASCIZ @DRIVE BUS ERROR: 'SET HEAD' & HEAD ADDRESS SHOULD BE ON THE BUS@
4495	026562	052502	020123	051105	
4496	026570	047522	035122	023440	
4497	026576	042523	020124	042510	
4498	026604	042101	020047	020046	
4499	026612	042510	042101	040440	

4500	026620	042104	042522	051523	
4501	026626	051440	047510	046125	
4502	026634	020104	042502	047440	
4503	026642	020116	044124	020105	
4504	026650	052502	000123		
4505	026654	051104	053111	020105	EM75: .ASCIZ @DRIVE BUS ERROR: ONLY 'SEEK START' SHOULD BE ON THE BUS@
4506	026662	052502	020123	051105	
4507	026670	047522	035122	047440	
4508	026676	046116	020131	051447	
4509	026704	042505	020113	052123	
4510	026712	051101	023524	051440	
4511	026720	047510	046125	020104	
4512	026726	042502	047440	020116	
4513	026734	044124	020105	052502	
4514	026742	000123			
4515	026744	051104	053111	020105	EM76: .ASCIZ @DRIVE BUS ERROR: 'RESTORE' AND 'CONTROL' SHOULD BE ON THE BUS@
4516	026752	052502	020123	051105	
4517	026760	047522	035122	023440	
4518	026766	042522	052123	051117	
4519	026774	023505	040440	042116	
4520	027002	023440	047503	052116	
4521	027010	047522	023514	051440	
4522	027016	047510	046125	020104	
4523	027024	042502	047440	020116	
4524	027032	044124	020105	052502	
4525	027040	000123			
4526	027042	051104	053111	020105	EM77: .ASCII @DRIVE BUS ERROR: 'CONTROL', 'SELECT HEAD', AND 'READ'@
4527	027050	052502	020123	051105	
4528	027056	047522	035122	023440	
4529	027064	047503	052116	047522	
4530	027072	023514	020054	051447	
4531	027100	046105	041505	020124	
4532	027106	042510	042101	026047	
4533	027114	040440	042116	023440	
4534	027122	042522	042101	047	
4535	027127	015	051412	047510	.ASCIZ <15><12>@SHOULD BE ON THE BUS@
4536	027134	046125	020104	042502	
4537	027142	047440	020116	044124	
4538	027150	020105	052502	000123	
4539	027156	051104	053111	020105	EM100: .ASCII @DRIVE BUS ERROR: 'CONTROL', SELECT HEAD', 'ERASE',@
4540	027164	052502	020123	051105	
4541	027172	047522	035122	023440	
4542	027200	047503	052116	047522	
4543	027206	023514	020054	042523	
4544	027214	042514	052103	044040	
4545	027222	040505	023504	020054	
4546	027230	042447	040522	042523	
4547	027236	026047			
4548	027240	005015	047101	020104	.ASCIZ <15><12>@AND 'WRITE' SHOULD BE ON THE BUS@
4549	027246	053447	044522	042524	
4550	027254	020047	044123	052517	
4551	027262	042114	041040	020105	
4552	027270	047117	052040	042510	
4553	027276	041040	051525	000	
4554	027303	047	042522	042101	EM101: .ASCIZ @'READY' DIDN'T CLEAR WHEN 'GO' WAS SET@
4555	027310	023531	042040	042111	

4556	027316	023516	020124	046103	
4557	027324	040505	020122	044127	
4558	027332	047105	023440	047507	
4559	027340	020047	040527	020123	
4560	027346	042523	000124		
4561	027352	040503	023516	020124	EM102: .ASCIZ @CAN'T SET 'SUOL'@
4562	027360	042523	020124	051447	
4563	027366	047525	023514	000	
4564	027373	103	047101	052047	EM103: .ASCIZ @CAN'T CLEAR 'SUOL'@
4565	027400	041440	042514	051101	
4566	027406	023440	052523	046117	
4567	027414	000047			
4568	027416	040503	023516	020124	EM104: .ASCIZ @CAN'T SET 'SUSU'@
4569	027424	042523	020124	051447	
4570	027432	051525	023525	000	
4571	027437	103	047101	052047	EM105: .ASCIZ @CAN'T CLEAR 'SUSU'@
4572	027444	041440	042514	051101	
4573	027452	023440	052523	052523	
4574	027460	000047			
4575	027462	044447	042504	020047	EM106: .ASCIZ @'IDE' NOT SET AFTER INTERRUPT@
4576	027470	047516	020124	042523	
4577	027476	020124	043101	042524	
4578	027504	020122	047111	042524	
4579	027512	051122	050125	000124	
4580	027520	052101	047124	044440	EM107: .ASCIZ @ATTN INTERRUPT OCCURED WITH NO ATTN BITS SET@
4581	027526	052116	051105	052522	
4582	027534	052120	047440	041503	
4583	027542	051125	042105	053440	
4584	027550	052111	020110	047516	
4585	027556	040440	052124	020116	
4586	027564	044502	051524	051440	
4587	027572	052105	000		
4588	027575	123	046111	020117	EM110: .ASCIZ @SILO NOT FULL, 'INPUT READY' NOT SET@
4589	027602	047516	020124	052506	
4590	027610	046114	020054	044447	
4591	027616	050116	052125	051040	
4592	027624	040505	054504	020047	
4593	027632	047516	020124	042523	
4594	027640	000124			
4595	027642	044523	047514	047040	EM111: .ASCIZ @SILO NOT EMPTY, 'OUTPUT READY' NOT SET@
4596	027650	052117	042440	050115	
4597	027656	054524	020054	047447	
4598	027664	052125	052520	020124	
4599	027672	042522	042101	023531	
4600	027700	047040	052117	051440	
4601	027706	052105	000		
4602	027711	047	047111	052111	EM112: .ASCIZ @'INIT' COMMAND SET 'PROG' ERROR@
4603	027716	020047	047503	046515	
4604	027724	047101	020104	042523	
4605	027732	020124	050047	047522	
4606	027740	023507	042440	051122	
4607	027746	051117	000		
4608					
4609					;ERROR HEADER (DH) MESSAGES
4610					
4611	027751	105	051122	050040	DH1: .ASCIZ @ERR PC RPAR@

DZRPWB.CMB ERROR MESSAGES

4724	031126	040504	020040	020040									
4725	031134	050122	030515	000									
4726	031141	124	051505	020124	DH72:	.ASCIZ	ATEST	#	ERR PC	RPDS	RPCS	RPCA	RPM13
4727	031146	020043	042440	051122									
4728	031154	050040	020103	051040									
4729	031162	042120	020123	020040									
4730	031170	051040	041520	020123									
4731	031176	020040	051040	041520									
4732	031204	020101	020040	051040									
4733	031212	046520	000061										
4734	031216	042524	052123	021440	DH73:	.ASCIZ	ATEST	#	ERR PC	RPDS	RPCS	RPM1	EXPTD BUS3
4735	031224	020040	051105	020122									
4736	031232	041520	020040	050122									
4737	031240	051504	020040	020040									
4738	031246	050122	051503	020040									
4739	031254	020040	050122	030515									
4740	031262	042440	050130	042124									
4741	031270	041040	051525	000									
4742	031275	124	051505	020124	DH74:	.ASCIZ	ATEST	#	ERR PC	RPDS	RPCS	RPCA	RPM13
4743	031302	020043	042440	051122									
4744	031310	050040	020103	051040									
4745	031316	042120	020123	020040									
4746	031324	051040	041520	020123									
4747	031332	020040	051040	042120									
4748	031340	020101	020040	051040									
4749	031346	046520	000061										

.EVEN

;ERROR MESSAGE 'DT' ENTRIES

4755	031352	001116	001210		DT1:	.WORD	SERRPC, RPADR
4756	031356	001160	001116	001122	DT2:	.WORD	STMPO, SERRPC, SBDADR, SGDDAT, SBDAT
4757	031364	001124	001126				
4758	031370	001160	001116	001220	DT7:	.WORD	STMPO, SERRPC, SRPDS
4759	031376	001160	001116	001220	DT11:	.WORD	STMPO, SERRPC, SRPDS, SRPER, SRPCS
4760	031404	001222	001224				
4761	031410	001160	001116	001124	DT20:	.WORD	STMPO, SERRPC, SGDDAT, SRPDS
4762	031416	001220					
4763	031420	001160	001116	001222	DT24:	.WORD	STMPO, SERRPC, SRPER, SRPCS
4764	031426	001224					
4765	031430	001160	001116	001222	DT30:	.WORD	STMPO, SERRPC, SRPER, SRPCS, SRPCA, SGDDAT
4766	031436	001224	001232	001124			
4767	031444	001160	001116	001222	DT33:	.WORD	STMPO, SERRPC, SRPER, SRPCS, SRPDA, SGDDAT
4768	031452	001224	001234	001124			
4769	031460	001160	001116	001220	DT46:	.WORD	STMPO, SERRPC, SRPDS, SRPCS, SGDDAT
4770	031466	001224	001124				
4771	031472	001160	001116	001220	DT50:	.WORD	STMPO, SERRPC, SRPDS, SRPCS
4772	031500	001224					
4773	031502	001160	001116	001224	DT52:	.WORD	STMPO, SERRPC, SRPCS
4774	031510	001160	001116	001240	DT61:	.WORD	STMPO, SERRPC, SSUCA, SGDDAT
4775	031516	001124					
4776	031520	001160	001116	001126	DT62:	.WORD	STMPO, SERRPC, SBDAT
4777	031526	001160	001116	001126	DT63:	.WORD	STMPO, SERRPC, SBDAT, SGDDAT
4778	031534	001124					
4779	031536	001160	001116	001236	DT64:	.WORD	STMPO, SERRPC, SRPM1, SSILO

4780	031544	001242					
4781	031546	001160	001116	001236	DT65:	.WORD	STMPO, SERRPC, SRPM1
4782	031554	001160	001116	001236	DT66:	.WORD	STMPO, SERRPC, SRPM1, SSILO, SGDDAT, SBDDAT
4783	031562	001242	001124	001126			
4784	031570	001160	001116	001220	DT71:	.WORD	STMPO, SERRPC, SRPDS, SRPCS, SRPCA, SRPDA, SRPM1
4785	031576	001224	001232	001234			
4786	031604	001236					
4787	031606	001160	001116	001220	DT72:	.WORD	STMPO, SERRPC, SRPDS, SRPCS, SRPCA, SRPM1
4788	031614	001224	001232	001236			
4789	031622	001160	001116	001220	DT73:	.WORD	STMPO, SERRPC, SRPDS, SRPCS, SRPM1, SGDDAT
4790	031630	001224	001236	001124			
4791	031636	001160	001116	001220	DT74:	.WORD	STMPO, SERRPC, SRPDS, SRPCS, SRPDA, SRPM1
4792	031644	001224	001234	001236			

;ERROR MESSAGE 'DF' ENTRIES

4793							
4794							
4795							
4796	031652	000001			DF:	.WORD	1
4797	031654	002				.BYTE	2
4798	031655	000				.BYTE	0
4799							
4800	031656	000001			DF1:	.WORD	1
4801	031660	003				.BYTE	3
4802	031661	000				.BYTE	0
4803							
4804	031662	000001			DF2:	.WORD	1
4805	031664	005				.BYTE	5
4806	031665	000				.BYTE	0
4807							
4808	031666	000001			DF20:	.WORD	1
4809	031670	004				.BYTE	4
4810	031671	000				.BYTE	0
4811							
4812	031672	000001			DF30:	.WORD	1
4813	031674	006				.BYTE	6
4814	031675	000				.BYTE	0
4815							
4816	031676	000001			DF71:	.WORD	1
4817	031700	007				.BYTE	7
4818	031701	000				.BYTE	0
4819							
4820		000001				.END	

CSF2	012464	2574	2575	2577#										
CSF3	012610	2602	2603	2605#										
CSF6	012710	2625	2626	2628#										
CSF7	013010	2647	2648	2650#										
DABT	006430	1902	1912#	1925	1927									
DAF1	013560	2762	2771#	2784	2786									
DAF2	013710	2795	2796	2798#										
DOISP =	177570	624#	762	1374										
DF	031652	824	479#											
DF1	031656	866	873	943	950	1111	1118	1125	1132	1139	1146	1153	1167	1188
		1203	1210	1277	1284	1291	1298	1305	1312	1326	1333	4800#		
DF2	031662	831	838	845	852	859	880	887	894	901	908	915	922	1076
		1083	1090	1319	4804#									
DF20	031666	929	936	957	964	971	978	1048	1055	1062	1069	1097	1104	1160
		1174	1181	1340	4808#									
DF30	031672	985	992	999	1006	1013	1020	1027	1034	1041	1195	1225	1232	1239
		1247	1254	1262	1270	4812#								
DF71	031676	1217	4816#											
DH1	027751	822	4611#											
DH11	030062	878	885	892	899	906	913	920	1074	1317	4625#			
DH2	027767	829	836	843	850	857	4614#							
DH20	030127	927	934	4632#										
DH24	030164	955	962	969	976	1046	1053	1060	1067	1338	4637#			
DH30	030221	983	990	997	4642#									
DH33	030312	1004	1011	1018	1025	1032	1039	4652#						
DH46	030403	1081	1088	4662#										
DH50	030463	1095	1102	4671#										
DH52	030520	1109	1116	1123	1130	1137	1144	1151	1275	1310	4676#			
DH61	030545	1158	4680#											
DH62	030613	1165	4687#											
DH63	030640	1172	4691#											
DH64	030705	1179	4698#											
DH65	030751	1186	1201	1208	1324	1331	4705#							
DH66	030776	1193	4709#											
DH7	030035	864	871	941	948	1282	1289	1296	1303	4621#				
DH71	031054	1215	4717#											
DH72	031141	1223	4726#											
DH73	031216	1230	1245	1252	1260	1268	4734#							
DH74	031275	1237	4742#											
DISPLA	001142	762#	1374#	1382#	3237#	3828#								
DISPRE	000174	585#	1382											
DRVOL	022115	1395	4066#											
DSF1	007066	2003	2004	2006#										
DSF11	007554	2110	2111	2113#										
DSF13	007702	2135	2140#	2157										
DSF4	007174	2028	2029	2031#										
DSF6	007332	2061	2062	2064#										
DSF7	007446	2086	2087	2089#										
DSMR =	177570	623#	761	1373										
DT1	031352	823	4755#											
DT11	031376	879	886	893	900	907	914	921	1075	1318	4759#			
DT2	031356	830	837	844	851	858	4756#							
DT20	031410	928	935	4761#										
DT24	031420	956	963	970	977	1047	1054	1061	1068	1339	4763#			
DT30	031430	984	991	998	4765#									
DT33	031444	1005	1012	1019	1026	1033	1040	4767#						

MAXPAT 001200
PC =X000007

780#	1416#	1419#	2287										
636#	1406#	1450#	1506#	1564#	1566#	1572#	1601#	1658#	1659#	1727#	1735#	1763#	
1771#	1799#	1807#	1835#	1843#	1871#	1879#	1907#	1915#	1947#	1980#	2007#	2009#	
2015#	2032#	2034#	2049#	2065#	2068#	2074#	2090#	2092#	2098#	2114#	2116#	2122#	
2141#	2144#	2151#	2167#	2186#	2191#	2192#	2214#	2218#	2219#	2242#	2247#	2248#	
2269#	2274#	2275#	2302#	2307#	2308#	2329#	2334#	2335#	2362#	2367#	2368#	2388#	
2393#	2394#	2420#	2424#	2425#	2449#	2453#	2454#	2477#	2480#	2488#	2512#	2515#	
2524#	2542#	2550#	2564#	2578#	2587#	2590#	2606#	2615#	2629#	2637#	2651#	2660#	
2674#	2683#	2697#	2704#	2718#	2720#	2725#	2726#	2743#	2745#	2769#	2771#	2799#	
2832#	2860#	2861#	2871#	2913#	2914#	2979#	2980#	2999#	3013#	3023#	3037#	3065#	
3066#	3078#	3103#	3112#	3137#	3151#	3161#	3193#	3196#	3207#	3212	3247#	3324#	
3365#	3372#	3379#	3393#	3395#	3598#	4003#	4016#	4018#	4033#	4060#			

PIRQ = 177772
PIRQVE = 000240
PR0 = 000000
PR1 = 000040
PR2 = 000100
PR3 = 000140
PR4 = 000200
PR5 = 000240
PR6 = 000300
PR7 = 000340

622#													
716#													
639#													
640#													
641#													
642#													
643#	2632												
644#	2654												
645#	2677												
646#	1422	1960	1993	2478	2487	2513	2521	2540	2549	2563	2580	2586	
2613	2636	2658	2681										
619#	620												

PS = 177776
PSW = 177776

620#	1422#	1960#	1993#	2481#	2487#	2517#	2521#	2543#	2549#	2557#	2563#	2581#	
2586#	2609#	2613#	2632#	2636#	2654#	2658#	2677#	2681#					

PARVEC = 000024
RAPBA 006766
RAPBA1 007024
RAPMC 006622
RAPMC1 006660
RDCRA = 104410
RDLIN = 104411
RDOCT = 104412
READT 015644
RESREG = 104414
RESRP 003152
RESTOR 015472
RESVEC = 000010
RPAOR 001210

711#													
1971	1981#	1984	1991										
1978	1989	1992#											
1938	1948#	1951	1958										
1945	1956	1959#											
3658	3919#												
3732	3920#												
3921#	3948	3966	3989										
3099	3100	3102#											
3323	3923#												
1439	1440	1443#											
3061	3062	3064#											
706#													
787#	1411	1441	1561	1591	1723	1759	1795	1831	1867	1903	1939	1972	
2005	2030	2063	2088	2112	2136	2184	2212	2239	2265	2299	2326	2359	
2385	2418	2447	2474	2509	2537	2576	2604	2627	2649	2672	2695	2716	
2740	2763	2797	2855	2908	2976	3063	3101	3135	3939	3951#	4001	4755	
724#	1447#	1479	1520	1598#	1630	1676	1837	1842#	1850#	1856#	1975	4054	
725#	1448#	1488	1526	1599#	1639	1682	1873	1878#	1886#	1892#	2243#	2270#	
2987#	2990#	4055											

RPBA = 000010
RPCA = 000012

722#	1412#	1445#	1461	1596#	1612	1657#	1765	1770#	1778#	1784#	2189#	2216#	
2245#	2272#	2305#	2332#	2365#	2391#	2422#	2451#	2482#	2492	2516#	2544#	2558#	
2582#	2631#	2653#	2676#	2699#	2719#	2995#	3074#	3105#	3140#	4015#	4052		

RPCS = 000004

726#	1449#	1497	1539	1600#	1648	1695	1909	1914#	1922#	1928#	2303#	2330#	
2363#	2389#	2767	2991#	3139#	4056								

RPOA = 000014

720#	1413	2142#	2150#	2166#	2495#	2559#	4050						
------	------	-------	-------	-------	-------	-------	------	--	--	--	--	--	--

RPOS = 000000
RPER = 000002
RPM1 = 000016
RPM2 = 000020
RPM3 = 000022

721#	1444#	1452	1508	1595#	1603	1664	1729	1734#	1742#	1748#	4051		
727#	1537	1688	2924	2929	2943	4057							

728#	2143#	2159#	2164#	2165#	2483#	2545#	2608#	2744#					
729#	1565#	1571#	1577#	1707#	2008#	2014#	2033#	2048#	2066#	2067#	2073#	2091#	

DZRPWB.CMB CROSS REFERENCE TABLE -- USER SYMBOLS

		2621	2641	2643	2664	2666	2687	2689	2708	2710	2737	2734	2755	2757
		2789	2791	2841	2843	2894	2896	2963	2965	3052	3054	3090	3092	3124
		3126												
SOCNT	017442	3430	3459	3472										
SOMODE	017444	3425	3429	3434	3437	3448	3474							
SOVER	021176	3784	3802	3810	3820	3828								
SPASS	001100	742	1385	3178	3191	3192	3214	3816	3832					
SOUES	001172	775	3266	3397	3612	3688	3705	3763	3766					
SRDCHR	020154	3625	3919											
SRDDEC=	***** U	3922												
SRDLIN	020274	3653	3920											
SRDOCT	020574	3727	3921											
SRDSZ =	000007	3646												
SRDSRE	021252	3866	3923											
SRPBA	001230	747	1482	1522	1633	1678	1844	1845	4054					
SRPCA	001232	798	1491	1528	1642	1684	1880	1881	4755	4765	4784	4787		
SRPCS	001224	795	1464	1547	1615	1703	1772	1773	2043	2197	2224	2281	2341	2400
		2430	2459	2591	2721	2727	4052	4759	4763	4765	4767	4769	4771	4773
SRPDA	001234	4784	4787	4789	4791									
		799	1500	1541	1651	1697	1916	1917	2772	2773	2833	2834	2994	4056
SRPDS	001220	4767	4784	4791										
		793	1567	1573	2010	2016	2035	2050	2069	2075	2093	2099	2117	2123
		2145	2147	2152	2161	2168	2172	4050	4758	4759	4761	4769	4771	4784
SRPER	001222	4787	4789	4791										
		794	1455	1510	1606	1660	1666	1736	1737	2039	2193	2220	2249	2276
SRPHI	001236	2309	2336	2369	2395	2426	2455	4051	4759	4763	4765	4767		
		800	1534	1690	2862	2872	2915	2924	2925	2929	2930	2943	2947	2950
		2955	2981	3000	3014	3024	3038	3067	3079	3113	3152	4057	4779	4781
		4782	4784	4787	4789	4791								
SRPMC	001226	796	1473	1516	1624	1672	1808	1809	2244	2331	4053			
SRTNAD	016376	3213												
SRZA =	***** U	3924												
SSAVRE	021214	3850	3922											
SSCOPE	020734	1357	3781											
SSSETUP=	000127	1342	1356	1357	1359	1361	1363	1364	1365	1367	1397	3189	3234	3253
		3261	3549	3711	3782									
SSILO	001242	802	4059	4779	4782									
SSITUP =	177777	1342												
SSUCA	001240	801	2746	4058	4774									
SSVLAD	021150	3792	3823											
SSVPC =	000200	592	597											
SSMR =	167400	554	564	568	569	570	571	572	573	574	772	773	774	1364
		1365	1367	1368	1442	1562	1592	1724	1760	1796	1832	1868	1904	1940
		1973	2006	2031	2064	2089	2113	2137	2185	2213	2240	2266	2300	2327
		2360	2386	2419	2448	2475	2510	2538	2577	2605	2628	2650	2673	2696
		2717	2741	2764	2798	2856	2909	2977	3064	3102	3136	3170	3190	3206
		3212	3214	3225	3226	3227	3228	3229	3238	3245	3250	3254	3266	3773
		3774	3775	3776	3777	3783	3795	3797	3798	3803	3804	3805	3812	3813
		3814	3825	3828	3831									
SSMRK=	000200	554	574	575	3777	3778	3799	3800						
STINES	001162	772	1364	1442	1592	1724	1760	1796	1832	1868	1904	1940	1973	2137
		2909	3190	3812	3819	3822	3831							
STKB	001146	764	3547	3558	3575	3629	3635							
STKS	001144	763	3547	3556	3572	3596	3627	3633						
STMPO	001160	771	1737	1738	1739	1773	1774	1775	1809	1810	1811	1845	1846	1847
		1881	1882	1883	1917	1918	1919	2773	2774	2775	2834	2835	3268	3269

ADD	1453	1462	1471	1480	1489	1498	1509	1515	1521	1527	1533	1540	1604	1613	1622
	1631	1640	1649	1665	1671	1677	1683	1689	1696	1729	1765	1801	1837	1873	1909
ASL	1943	1976	2782	3276	3354	3426	3436	3508	3583	3592	3750				
	1746	1782	1818	1854	1890	1926	2155	2496	2882	3273	3274	3275	3606	3607	3608
	3743	3745	3747	3891	3976	3977	3978	3992	3993	3994	3995	3996			
ASLB	3513														
ASR	2888														
BCC	1747	1783	1819	1855	1891	1927	3514								
BDS	1388	2883	2890	3298											
BEQ	1458	1467	1476	1485	1494	1503	1512	1518	1524	1530	1537	1544	1549	1574	1609
	1618	1627	1636	1645	1654	1661	1668	1674	1680	1686	1693	1700	1705	1740	1776
	1812	1848	1884	1920	1951	1984	2017	2046	2051	2076	2100	2124	2146	2153	2157
	2162	2169	2200	2227	2250	2284	2310	2344	2370	2403	2433	2462	2493	2498	2748
	2752	2776	2779	2836	2878	2926	2936	2946	2956	2983	2989	2993	3004	3007	3018
	3028	3031	3042	3070	3083	3117	3156	3205	3236	3239	3255	3258	3278	3283	3288
	3292	3306	3357	3392	3453	3563	3590	3605	3674	3738	3798	3802	3804	3808	3817
	3932	3950	3968	3991	4008										
BGE	3820														
BGT	3195	3460	3522	3602	3643	3740									
BHI	3806														
BHIS	2254	2314	2374	2784											
BIC	1535	1542	1571	1691	1698	1733	1738	1769	1774	1805	1810	1841	1846	1877	1882
	1913	1918	2014	2048	2066	2097	2121	2421	2768	2774	2835	2982	3001	3015	3025
	3039	3068	3080	3114	3153	3192	3450	3559	3576	3603	3630	3636	3644	3749	3800
BIS	1456	1465	1474	1483	1492	1501	1565	1577	1607	1616	1625	1634	1643	1652	1707
	2008	2033	2067	2073	2091	2115	2187	2482	2516	2544	2558	2582	2631	2653	2676
	2699	2889	3455	3456	3516	3517	3610	4017							
BIT	1413	1567	1573	1660	1955	1988	2010	2016	2035	2039	2045	2050	2069	2075	2093
	2099	2117	2123	2156	2193	2199	2220	2226	2249	2276	2283	2309	2336	2343	2369
	2395	2402	2426	2432	2435	2455	2461	2492	2497	2591	2751	2862	2872	2915	2925
	2930	2938	2947	2950	2955	3238	3245	3254	3783	3797	3807	3814			
BITB	3380														
BLE	3310														
BLO	3669														
BLOS	3657														
BLT	3371	3461	3505	3521	3600	3641	3742								
BMI	2728	3512													
BNE	1354	1376	1387	1394	1399	1401	1414	1568	1745	1781	1817	1853	1889	1925	1956
	1989	2011	2036	2040	2070	2094	2118	2194	2221	2277	2288	2337	2348	2396	2407
	2427	2456	2592	2863	2870	2873	2881	2916	2923	2931	2939	2942	2948	2951	3046
	3246	3262	3313	3320	3351	3359	3367	3381	3388	3451	3510	3555	3561	3581	3588
	3595	3632	3638	3661	3663	3679	3683	3693	3784	3815	4025	4041			
BPL	2722	3251	3345	3385	3449	3496	3526	3557	3573	3628	3634				
BR	1346	1378	1390	1403	1417	1570	1958	1991	2013	2038	2072	2096	2120	2279	2339
	2398	2490	2522	2553	2589	2614	2659	2682	2703	2786	2865	2875	2884	2887	2954
	3048	3175	3183	3200	3301	3308	3322	3347	3364	3374	3383	3390	3427	3442	3463
	3507	3524	3584	3611	3613	3639	3672	3681	3687	3689	3751	3764	3786	3792	3795
	3810	3813	3936	3945	3954	3963	3972	3986							
CLR	1345	1352	1364	1365	1385	1409	1410	1423	1424	1507	1663	1731	1742	1748	1767
	1778	1784	1803	1814	1820	1839	1850	1856	1875	1886	1892	1911	1922	1928	1946
	1961	1979	1994	2164	2166	2170	2171	2241	2301	2361	2481	2517	2543	2557	2581
	2609	2742	2785	2858	2959	2978	2984	3071	3188	3189	3190	3268	3270	3289	3440
	3499	3502	3570	3571	3654	3677	3735	3736	3812	3826	3933	4009			
CLR8	3363	3389	3528	3684	3694	3760	3811								
CHP	1353	1375	1400	1457	1466	1475	1484	1493	1502	1511	1517	1523	1529	1536	1543
	1548	1608	1617	1626	1635	1644	1653	1667	1673	1679	1685	1692	1699	1704	1739

DZRPWB.CMB CROSS REFERENCE TABLE -- PERMANENT SYMBOLS

	1775	1811	1847	1883	1919	1950	1983	2253	2287	2313	2347	2373	2406	2747	2775
	2783	2877	2922	2935	2945	3006	3017	3030	3041	3082	3116	3155	3261	3520	3554
	3560	3580	3587	3599	3601	3631	3637	3640	3642	3656	3668	3793	3819	4005	
CMPB	2145	2168	3356	3358	3366	3387	3391	3562	3594	3660	3678	3682	3692	3739	3741
	3801	3805													
CON	1743	1744	1779	1780	1815	1816	1851	1852	1887	1888	1923	1924	2044	2198	2225
	2282	2342	2401	2431	2460	3293	3312								
DEC	2778	2869	2941	3193	3272	3305	3309	3667	4024	4040					
DEC8	3370	3373	3448	3459											
ENT	611														
HALT	584	3252	3263	3346											
INC	1386	2252	2268	2286	2312	2346	2372	2405	2750	2921	2944	3047	3191	3241	3454
	3462	3506	3609	3818											
INC8	3235	3393	3823												
TOT	612														
JMP	603	605	1425	3162	3212	4010									
JSR	1406	1450	1506	1564	1566	1572	1601	1658	1659	1727	1735	1763	1771	1799	1807
	1835	1843	1871	1879	1907	1915	1947	1980	2007	2009	2015	2032	2034	2049	2065
	2068	2074	2090	2092	2098	2114	2116	2122	2141	2144	2151	2167	2186	2191	2192
	2214	2218	2219	2242	2247	2248	2269	2274	2275	2302	2307	2308	2329	2334	2335
	2362	2367	2368	2388	2393	2394	2420	2424	2425	2449	2453	2454	2477	2480	2488
	2512	2515	2524	2542	2550	2564	2578	2587	2590	2606	2615	2629	2637	2651	2660
	2674	2683	2697	2704	2718	2720	2725	2726	2743	2745	2769	2771	2799	2828	2832
	2860	2861	2871	2913	2914	2979	2980	2997	2999	3011	3013	3021	3023	3035	3037
	3065	3066	3076	3078	3103	3107	3110	3112	3137	3142	3144	3149	3151	3161	3207
	3247	3365	3372	3379	3598	4016	4031								
MOV	1347	1351	1355	1357	1358	1359	1360	1361	1362	1363	1367	1368	1371	1372	1373
	1374	1379	1381	1382	1383	1407	1411	1412	1415	1416	1418	1419	1420	1421	1422
	1439	1440	1441	1442	1443	1444	1445	1446	1447	1448	1449	1452	1454	1455	1461
	1463	1464	1470	1472	1473	1479	1481	1482	1488	1490	1491	1497	1499	1500	1508
	1510	1514	1516	1520	1522	1526	1528	1532	1534	1539	1541	1546	1547	1559	1560
	1561	1563	1589	1590	1591	1592	1594	1595	1596	1597	1598	1599	1600	1603	1605
	1606	1612	1614	1615	1621	1623	1624	1630	1632	1633	1639	1641	1642	1648	1650
	1651	1656	1664	1666	1670	1672	1676	1678	1682	1684	1688	1690	1695	1697	1702
	1703	1721	1722	1723	1724	1726	1728	1730	1732	1734	1736	1737	1757	1758	1759
	1760	1762	1764	1766	1768	1770	1772	1773	1793	1794	1795	1796	1798	1800	1802
	1804	1806	1808	1809	1829	1830	1831	1832	1834	1836	1838	1840	1842	1844	1845
	1865	1866	1867	1868	1870	1872	1874	1876	1878	1880	1881	1901	1902	1903	1904
	1906	1908	1910	1912	1914	1916	1917	1937	1938	1939	1940	1941	1942	1944	1945
	1948	1949	1952	1953	1959	1960	1970	1971	1972	1973	1974	1975	1977	1978	1981
	1982	1985	1986	1992	1993	2003	2004	2005	2006	2028	2029	2030	2031	2043	2061
	2062	2063	2064	2086	2087	2088	2089	2110	2111	2112	2113	2134	2135	2136	2137
	2138	2139	2140	2142	2143	2149	2150	2158	2159	2165	2182	2183	2184	2185	2188
	2190	2197	2210	2211	2212	2213	2215	2217	2224	2237	2238	2239	2240	2243	2244
	2246	2263	2264	2265	2266	2267	2270	2271	2273	2281	2297	2298	2299	2300	2304
	2306	2324	2325	2326	2327	2328	2331	2332	2333	2341	2357	2358	2359	2360	2363
	2364	2366	2383	2384	2385	2386	2387	2389	2390	2392	2400	2416	2417	2418	2419
	2422	2423	2430	2445	2446	2447	2448	2450	2451	2452	2459	2472	2473	2474	2475
	2476	2478	2479	2483	2487	2491	2495	2507	2508	2509	2510	2511	2513	2514	2521
	2523	2535	2536	2537	2538	2539	2540	2541	2545	2549	2554	2555	2556	2559	2563
	2574	2575	2576	2577	2579	2580	2586	2602	2603	2604	2605	2607	2613	2625	2626
	2627	2628	2630	2632	2636	2647	2648	2649	2650	2652	2654	2658	2670	2671	2672
	2673	2675	2677	2681	2693	2694	2695	2696	2698	2714	2715	2716	2717	2724	2738
	2739	2740	2741	2746	2761	2762	2763	2764	2765	2766	2767	2770	2772	2773	2780
	2781	2795	2796	2797	2798	2800	2801	2802	2803	2804	2805	2806	2807	2808	2809
	2810	2811	2812	2813	2814	2815	2816	2817	2818	2819	2820	2821	2822	2823	2824

.ENDC	559	571	573	574	575	587	591	595	597	611	703	717	737	741	743
	771	772	773	774	775	779	803	1342	1355	1356	1359	1361	1363	1364	1365
	1367	1369	1385	1392	1400	1406	1432	1433	1436	1437	1440	1442	1443	1554	1555
	1556	1557	1558	1562	1581	1582	1586	1587	1590	1592	1593	1716	1717	1718	1719
	1722	1724	1725	1752	1753	1754	1755	1758	1760	1761	1788	1789	1790	1791	1794
	1796	1797	1824	1825	1826	1827	1830	1832	1833	1860	1861	1862	1863	1866	1868
	1869	1896	1897	1898	1899	1902	1904	1905	1932	1933	1934	1935	1938	1940	1941
	1965	1966	1967	1968	1971	1973	1974	1998	1999	2000	2001	2004	2006	2023	2024
	2025	2026	2029	2031	2056	2057	2058	2059	2062	2064	2081	2082	2083	2084	2087
	2089	2105	2106	2107	2108	2111	2113	2129	2130	2131	2132	2135	2137	2138	2177
	2178	2179	2180	2183	2185	2205	2206	2207	2208	2211	2213	2232	2233	2234	2235
	2238	2240	2258	2259	2260	2261	2264	2266	2292	2293	2294	2295	2298	2300	2319
	2320	2321	2322	2325	2327	2352	2353	2354	2355	2358	2360	2378	2379	2380	2381
	2384	2386	2411	2412	2413	2414	2417	2419	2440	2441	2442	2443	2446	2448	2467
	2468	2469	2470	2473	2475	2502	2503	2504	2505	2508	2510	2530	2531	2532	2533
	2536	2538	2569	2570	2571	2572	2575	2577	2597	2598	2599	2600	2603	2605	2620
	2621	2622	2623	2626	2628	2642	2643	2644	2645	2648	2650	2665	2666	2667	2668
	2671	2673	2688	2689	2690	2691	2694	2696	2709	2710	2711	2712	2715	2717	2733
	2734	2735	2736	2739	2741	2756	2757	2758	2759	2762	2764	2790	2791	2792	2793
	2796	2798	2842	2843	2850	2851	2854	2856	2895	2896	2903	2904	2907	2909	2910
	2964	2965	2971	2972	2975	2977	3053	3054	3058	3059	3062	3064	3091	3092	3096
	3097	3100	3102	3125	3126	3130	3131	3134	3136	3168	3170	3172	3177	3181	3182
	3185	3189	3195	3198	3199	3202	3204	3206	3212	3214	3215	3222	3225	3235	3242
	3247	3248	3249	3250	3261	3265	3266	3330	3350	3401	3479	3547	3548	3550	3578
	3614	3618	3646	3647	3655	3657	3660	3688	3705	3711	3716	3722	3766	3770	3773
	3778	3783	3785	3796	3799	3802	3803	3805	3807	3814	3818	3823	3824	3828	3831
	3832	3836	3882	3888	3891	3910	3911	3912	3913	3914	3915	3916	3917	3918	3919
	3920	3921	3922	3923	3924	3938	3943	3944	3947	3956	3961	3962	3965	3974	3984
	3985	3988													
.EQUIV	611	612	620	635	636	665	666	667	668	669	670	671	672	673	674
	693	694	695	696	697	698	699	700	701	702					
.EVEN	1392	3177	3185	3202	3215	3711	3938	3947	3956	3965	3974	3988	4113	4751	
.IF	555	571	572	573	574	575	587	590	593	595	609	675	703	736	740
	742	771	772	773	774	778	779	1342	1350	1355	1357	1359	1361	1363	1364
	1367	1367	1385	1391	1397	1400	1431	1433	1436	1439	1442	1443	1553	1555	1556
	1559	1562	1580	1582	1586	1589	1592	1593	1715	1717	1718	1721	1724	1725	1751
	1753	1754	1757	1760	1761	1787	1789	1790	1793	1796	1797	1823	1825	1826	1829
	1832	1833	1859	1861	1862	1865	1868	1869	1895	1897	1898	1901	1904	1905	1931
	1933	1934	1937	1940	1941	1964	1966	1967	1970	1973	1974	1997	1999	2000	2003
	2006	2022	2024	2025	2028	2031	2055	2057	2058	2061	2064	2080	2082	2083	2086
	2089	2104	2106	2107	2110	2113	2128	2130	2131	2134	2137	2138	2176	2178	2179
	2182	2185	2204	2206	2207	2210	2213	2231	2233	2234	2237	2240	2257	2259	2260
	2263	2266	2291	2293	2294	2297	2300	2318	2320	2321	2324	2327	2351	2353	2354
	2357	2360	2377	2379	2380	2383	2386	2410	2412	2413	2416	2419	2439	2441	2442
	2445	2448	2466	2468	2472	2475	2475	2501	2503	2504	2507	2510	2529	2531	2532
	2535	2538	2568	2570	2571	2574	2577	2596	2598	2599	2602	2605	2619	2621	2622
	2625	2628	2641	2643	2644	2647	2650	2664	2666	2667	2670	2673	2687	2689	2690
	2693	2696	2708	2710	2711	2714	2717	2732	2734	2735	2738	2741	2755	2757	2758
	2761	2764	2789	2791	2792	2795	2798	2841	2843	2850	2853	2856	2894	2896	2903
	2906	2909	2910	2963	2965	2971	2974	2977	3052	3054	3058	3061	3064	3090	3092
	3096	3099	3102	3124	3126	3130	3133	3136	3167	3168	3169	3170	3171	3172	3174
	3176	3180	3181	3184	3194	3197	3199	3201	3204	3206	3212	3214	3215	3221	3224
	3235	3238	3245	3247	3248	3250	3254	3261	3265	3266	3329	3350	3400	3478	3546
	3548	3549	3550	3578	3617	3618	3646	3654	3656	3660	3661	3704	3705	3711	3715
	3718	3734	3769	3772	3777	3783	3795	3797	3798	3799	3803	3804	3805	3814	3816
	3824	3825	3830	3831	3832	3835	3881	3887	3891	3902	3911	3912	3913	3914	3915

	3916	3918	3919	3920	3921	3922	3923	3924	3937	3942	3943	3946	3955	3960	3961
.IFF	3964	3973	3983	3984	3987										
	571	573	574	575	591	595	597	609	737	740	742	771	779	1355	1431
	1432	1433	1437	1439	1442	1553	1554	1555	1557	1559	1562	1580	1581	1582	1587
	1589	1592	1715	1716	1717	1719	1722	1724	1751	1752	1753	1755	1758	1760	1787
	1788	1789	1791	1794	1796	1823	1824	1825	1827	1830	1832	1859	1860	1861	1863
	1866	1868	1895	1896	1897	1899	1902	1904	1931	1932	1933	1935	1938	1940	1964
	1965	1966	1968	1971	1973	1997	1998	1999	2001	2003	2006	2022	2023	2024	2026
	2028	2031	2055	2056	2057	2059	2061	2064	2080	2081	2082	2084	2086	2089	2104
	2105	2106	2108	2110	2113	2128	2129	2130	2132	2135	2137	2176	2177	2178	2180
	2182	2185	2204	2205	2206	2208	2210	2213	2231	2232	2233	2235	2238	2240	2257
	2258	2259	2261	2264	2266	2291	2292	2293	2295	2298	2300	2318	2319	2320	2322
	2325	2327	2351	2352	2353	2355	2358	2360	2377	2378	2379	2381	2384	2386	2410
	2411	2412	2414	2416	2419	2439	2440	2441	2443	2445	2448	2466	2467	2468	2470
	2473	2475	2501	2502	2503	2505	2508	2510	2529	2530	2531	2533	2535	2538	2568
	2569	2570	2572	2574	2577	2596	2597	2598	2600	2602	2605	2619	2620	2621	2623
	2625	2628	2641	2642	2643	2645	2647	2650	2664	2665	2666	2668	2670	2673	2687
	2688	2689	2691	2693	2696	2708	2709	2710	2712	2714	2717	2732	2733	2734	2736
	2739	2741	2755	2756	2757	2759	2762	2764	2789	2790	2791	2793	2795	2798	2841
	2842	2843	2851	2853	2856	2894	2895	2896	2904	2906	2909	2963	2964	2965	2972
	2975	2977	3052	3053	3054	3059	3061	3064	3090	3091	3092	3097	3099	3102	3124
	3125	3126	3131	3133	3136	3168	3171	3174	3181	3194	3197	3214	3222	3224	3238
	3261	3266	3330	3401	3479	3547	3550	3618	3620	3625	3646	3647	3656	3688	3704
.IFT	3716	3770	3796	3799	3805	3831	3836	3882	3888	3943	3944	3961	3962	3984	3985
	1392	3177	3185	3202	3248	3620	3625	3739	3759	3766	3813	3938	3947	3956	3965
.IFTF	3974	3988													
	1392	3177	3185	3202	3247	3565	3618	3621	3735	3743	3765	3811	3938	3947	3956
.IIF	3965	3974	3988												
	554	559	564	568	569	570	571	574	575	576	584	778	1356	1359	1363
	1364	1365	1367	1368	3170	3179	3187	3189	3190	3214	3215	3225	3226	3227	3228
	3229	3234	3253	3261	3266	3300	3304	3397	3547	3568	3696	3705	3711	3766	3773
	3774	3775	3776	3777	3778	3782	3812	3813	3828	3831	3832	3910	3911	3912	3913
.IRP	3914	3916	3918	3919	3920	3921	3922	3923	3940	3958	3981				
	779	1342	1431	1508	1553	1580	1664	1715	1751	1787	1823	1859	1895	1931	1964
	1997	2022	2055	2080	2104	2128	2176	2204	2231	2257	2291	2318	2351	2377	2410
	2439	2466	2501	2529	2568	2596	2619	2641	2664	2687	2708	2732	2755	2789	2841
.LIST	2894	2963	3052	3090	3124	3174	3489	3529	3729	3755	3851	3871	4049		
	1	554	574	584	717	771	772	1342	1369	1392	1431	1442	1553	1562	1580
	1592	1715	1724	1751	1760	1787	1796	1823	1832	1859	1868	1895	1904	1931	1940
	1964	1973	1997	2006	2022	2031	2055	2064	2080	2089	2104	2113	2128	2137	2176
	2185	2204	2213	2231	2240	2257	2266	2291	2300	2318	2327	2351	2360	2377	2386
	2410	2419	2439	2448	2466	2475	2501	2510	2529	2538	2568	2577	2596	2605	2619
	2628	2641	2650	2664	2673	2687	2696	2708	2717	2732	2741	2755	2764	2789	2798
	2841	2856	2894	2909	2963	2977	3052	3064	3090	3102	3124	3136	3177	3185	3189
	3202	3206	3261	3646	3777	3902	3910	3911	3912	3913	3914	3915	3916	3917	3918
	3919	3920	3921	3922	3923	3924	3938	3947	3956	3965	3974	3988			
.MACRO	1	575	733												
.MCALL	554	717	1369												
.MLIST	1	554	574	584	717	771	772	1342	1369	1392	1431	1442	1553	1562	1580
	1592	1715	1724	1751	1760	1787	1796	1823	1832	1859	1868	1895	1904	1931	1940
	1964	1973	1997	2006	2022	2031	2055	2064	2080	2089	2104	2113	2128	2137	2176
	2185	2204	2213	2231	2240	2257	2266	2291	2300	2318	2327	2351	2360	2377	2386
	2410	2419	2439	2448	2466	2475	2501	2510	2529	2538	2568	2577	2596	2605	2619
	2628	2641	2650	2664	2673	2687	2696	2708	2717	2732	2741	2755	2764	2789	2798
	2841	2856	2894	2909	2963	2977	3052	3064	3090	3102	3124	3136	3177	3185	3189
	3202	3206	3261	3646	3777	3902	3910	3911	3912	3913	3914	3915	3916	3917	3918

	3919	3920	3921	3922	3923	3924	3938	3947	3956	3965	3974	3988			
.PAGE	734	803													
.REM	1														
.REPT	584	771	2800	3976	3992										
.SBTTL	564	578	588	599	607	718	734	803	1343	1349	1397	1428	1431	1553	1580
	1715	1751	1787	1823	1859	1895	1931	1964	1997	2022	2055	2080	2104	2128	2176
	2204	2231	2257	2291	2318	2351	2377	2410	2439	2466	2501	2529	2568	2596	2619
	2641	2664	2687	2708	2732	2755	2789	2841	2894	2963	3052	3090	3124	3165	3217
	3219	3327	3398	3476	3544	3713	3767	3833	3879	3902	4115				
.TITLE	554														
.WORD	584	585	586	596	742	745	746	747	748	751	752	753	754	755	756
	757	760	761	762	771	779	780	781	782	783	787	788	789	793	794
	795	796	797	798	799	800	801	802	2829	2998	3012	3022	3036	3077	3108
	3111	3143	3145	3150	3194	3197	3213	3281	3286	3317	3394	3474	3762	3765	3909
	4032	4755	4756	4758	4759	4761	4763	4765	4767	4769	4771	4773	4774	4776	4777
	4779	4781	4782	4784	4787	4789	4791	4796	4800	4804	4808	4812	4816		

ERRORS DETECTED: 0
 DEFAULT GLOBALS GENERATED: 0

* DZRPWB.SEQ/SOL/CRF/NL:TOC/PAGNUM=DZRPWB.SML,DZRPWB.CMB
 RUN-TIME: 47 64 8 SECONDS
 RUN-TIME RATIO: 256/120=2.1
 CORE USED: 34K (67 PAGES)

