

RP11E

DRIVE POSITIONING TEST MD-11-DZRPZ-C

EP-DZRPZ-C-DL-C

DEC 1977

COPYRIGHT © 75-77

digital

FICHE 1 OF 1

MADE IN USA

[Plot 1]	[Plot 2]	[Plot 3]	[Plot 4]	[Plot 5]	[Plot 6]	[Plot 7]	[Plot 8]	[Plot 9]	[Plot 10]
[Plot 11]	[Plot 12]	[Plot 13]	[Plot 14]	[Plot 15]	[Plot 16]	[Plot 17]	[Plot 18]	[Plot 19]	[Plot 20]
[Plot 21]	[Plot 22]	[Plot 23]	[Plot 24]	[Plot 25]	[Plot 26]	[Plot 27]	[Plot 28]	[Plot 29]	[Plot 30]
[Plot 31]	[Plot 32]	[Plot 33]	[Plot 34]	[Plot 35]	[Plot 36]	[Plot 37]	[Plot 38]	[Plot 39]	[Plot 40]
[Plot 41]	[Plot 42]	[Plot 43]	[Plot 44]	[Plot 45]	[Plot 46]	[Plot 47]	[Plot 48]	[Plot 49]	[Plot 50]
[Plot 51]	[Plot 52]	[Plot 53]	[Plot 54]	[Plot 55]	[Plot 56]	[Plot 57]	[Plot 58]	[Plot 59]	[Plot 60]
[Plot 61]	[Plot 62]	[Plot 63]	[Plot 64]	[Plot 65]	[Plot 66]	[Plot 67]	[Plot 68]	[Plot 69]	[Plot 70]
[Plot 71]	[Plot 72]	[Plot 73]	[Plot 74]	[Plot 75]	[Plot 76]	[Plot 77]	[Plot 78]	[Plot 79]	[Plot 80]
[Plot 81]	[Plot 82]	[Plot 83]	[Plot 84]	[Plot 85]	[Plot 86]	[Plot 87]	[Plot 88]	[Plot 89]	[Plot 90]
[Plot 91]	[Plot 92]	[Plot 93]	[Plot 94]	[Plot 95]	[Plot 96]	[Plot 97]	[Plot 98]	[Plot 99]	[Plot 100]

B01

EDF1DTRPZ000411
06-SEP-77 16:08

06-SEP-77 16:08

001000RPZ-C.7RPIIE DRIVE POSITIONING TEST MACY11 300000RPZ00E0EP-77 16:32 00000000

771114
SEC 000.

.REM 2

IDENTIFICATION

PRODUCT CODE: MAINDEC-11-DZRPZ-C-D
PRODUCT NAME: RPIIE DRIVE POSITIONING TEST
DATE CREATED: SEPTEMBER 1977
MAINTAINER: DIAGNOSTIC GROUP
AUTHOR: C. MESS

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT ©. 1975, 1977 BY DIGITAL EQUIPMENT CORPORATION.

CONTENTS

- 1. ABSTRACT
- 2. REQUIREMENTS
 - 2.1 EQUIPMENT
 - 2.2 STORAGE
 - 2.3 PRELIMINARY PROGRAMS
- 3. LOADING PROCEDURE
- 4. STARTING PROCEDURE
 - 4.1 STARTING ADDRESS
 - 4.2 OPERATOR ACTION
 - 4.3 PROGRAM ACTION
 - 4.4 'CONTROL C' OPERATION
- 5. OPERATING PROCEDURE
 - 5.1 SOFTWARE SWITCH REGISTER
 - 5.2 OPERATIONAL SWITCH SETTINGS
- 6. ERRORS
 - 6.1 ERROR TYPES
 - 6.2 ERROR RECOVERY
- 7. RESTRICTIONS
 - 7.1 SYSTEMS WITH MIXED DRIVE TYPES
 - 7.2 FORMATTED DISK PACKS
- 8. MISCELLANEOUS
 - 8.1 EXECUTION TIME
 - 8.2 STACK POINTER
 - 8.3 TIMING TEST (TEST10-TEST12) PRINTOUTS
 - 8.4 END OF TEST
 - 8.5 DEFAULT ADDRESSES, TEST SEQUENCE, AND PARAMETERS
 - 8.6 TIMING TEST RESTRICTIONS
 - 8.7 DISK POSITIONING CHECK
- 9. PROGRAM DESCRIPTION
 - 9.1 TEST DESCRIPTIONS
- 10. PROGRAM LISTING

1. ABSTRACT

THIS PROGRAM CONTAINS A SERIES OF TESTS THAT WILL ENSURE THAT THE DISK DRIVE IS CAPABLE OF PERFORMING SEEKS, THAT THE ACCESS TIMES ARE WITHIN TOLERANCE, AND THAT THE CYLINDER ADDRESSING CAPABILITY OF THE DRIVE IS FUNCTIONING PROPERLY.

2. REQUIREMENTS

2.1 EQUIPMENT

PDP-11 COMPUTER WITH 8K OF MEMORY (WITH OR WITHOUT HARDWARE SWITCH REGISTER); CONSOLE TELETYPE; RPIIE DISK CONTROLLER;
 1 TO 8 RPO2, RPRO2, OR RPO3 DISK DRIVES WITH FORMATTED PACKS.

2.2 STORAGE

THIS PROGRAM WILL LOAD AND RUN IN 8K.

2.3 PRELIMINARY PROGRAMS

MAINDEC-11-DZRPW - RPIIE DISKLESS LOGIC TEST

3. LOADING PROCEDURE

*** BEFORE STARTING, REFER TO SECTION 5.***
 THE PROGRAM MAY BE LOADED FROM EITHER PAPER TAPE OR AN 'XXDP' DEVICE. REFER TO EITHER THE STANDARD PROCEDURES FOR LOADING 'ABS' FORMAT PAPER TAPES OR TO THE 'XXDP' SYSTEM REFERENCE DOCUMENT.

THIS PROGRAM MAY BE INCLUDED IN AN 'XXDP' CHAIN. IF THE PROGRAM IS PART OF A CHAIN AND IS LOADED FROM AN RPO2, RPRO2, OR AN RPO3, THE PROGRAM WILL BYPASS TESTING DRIVE 0.

4. STARTING PROCEDURE

4.1 STARTING ADDRESSES

200 NORMAL STARTING ADDRESS
 204 SELECT OPERATING PARAMETERS
 210 SELECT RPII ADDRESS
 214 COMBINATION OF 204 AND 210

4.1.1 START FROM LOCATION 200

WHEN THE PROGRAM IS STARTED FROM LOCATION 200, THE PROGRAM WILL TEST ALL AVAILABLE DRIVES (SEE SECTION 3. FOR DRIVE 0 EXCEPTION), USING TESTS 0 - 10, 8, 12, WITH DEFAULT PARAMETERS. PREVIOUS PARAMETER CHANGES ARE OVERLAYED.

4.1.2 START FROM LOCATION 204

WHEN THE PROGRAM IS STARTED FROM LOCATION 204, THE PARAMETERS ARE RESET TO THEIR DEFAULT VALUES, AND THE PROGRAM ENTERS CONVERSATIONAL MODE. REFER TO SECTION 4.3.2.

4.1.3 START FROM LOCATION 210

WHEN THE PROGRAM IS STARTED FROM LOCATION 210, OPERATION IS THE SAME AS THE START FROM 200, EXCEPT THAT THE PROGRAM ASKS FOR A NEW RPIIE ADDRESS, VECTOR ADDRESS, AND PRIORITY. THE OPERATOR MAY ENTER NEW ADDRESS VALUES OR RETAIN THE OLD VALUES. THE TEST PARAMETERS ARE RESET TO THE DEFAULT VALUES. REFER TO SECTION 4.3.1.

4.1.4 START FROM LOCATION 214

PROGRAM START FROM LOCATION 214 IS THE SAME AS THE START FROM LOCATION 204 EXCEPT THAT THE OPERATOR MAY ENTER NEW RPIIE ADDRESS, VECTOR ADDRESS, OR PRIORITY. THE TEST PARAMETERS ARE RESET TO THE DEFAULT VALUES. REFER TO SECTIONS 4.3.1 & 4.3.2.

4.2 OPERATOR ACTION

1. LOAD PROGRAM INTO MEMORY (SEE SECTION 3.)
2. LOAD A FORMATTED PACK INTO DRIVE(S) TO BE TESTED
3. BRING DRIVE(S) TO ONLINE STATE.
4. SET 'FORMAT' AND 'MAINTENANCE' SWITCHES ON THE RPIIE CONTROL PANEL TO 'NORMAL'.
5. LOAD ADDRESS 200, 204, 210, OR 214.
6. SET SWITCHES (SEE SECTION 5).
7. PRESS START.

4.3 PROGRAM ACTION

IN AN EFFORT TO ALLOW CONVERSATION WITH A PROGRAM FOR THE PURPOSE OF CONTROLLING ITS OPERATION AND PARAMETERS THE FOLLOWING CONSTRUCTIONS HAVE BEEN ADOPTED.

NOTE1: IN ALL EXAMPLES BRACKETS ARE USED FOR CLARITY AND ARE NOT TYPED BY THE USER.

NOTE2: THE CARRIAGE RETURN TYPED BY THE USER IS INDICATED BY '<CR>' AND WILL BE ECHOED AS A "CARRIAGE RETURN-LINE FEED."

<CR> PERIOD

A STATEMENT TERMINATOR: WHEN TYPED AT THE END OF A LINE (LEGAL ON ALL LINES) IT TELLS THE PARAMETER STRING INTERPRETER 'PSI' THIS IS THE END OF CHANGES TO THE CURRENT PARAMETER STRING.

.. CR

PERIOD PERIOD

AN INPUT TERMINATOR: WHEN A PERIOD IS TYPED AFTER A "STATEMENT TERMINATOR PERIOD" IT TELLS THE PSI THIS IS THE END OF ALL CHANGES (LEGAL ON ALL LINES) BEGIN EXECUTION.

. CR

COMMA

A CONTINUATION INDICATOR AND FIELD SEPARATOR:

- 1 THIS IS THE CONSTRUCTION USED WHEN NOT USING A PERIOD: THAT IS TO SAY THE COMMA SAYS "TERMINATE THE LINE BUT NOT THE INPUT FOR PARAMETER CHANGES".
- 2) SEPARATE MULTIPLE ENTRIES ON THE SAME TEXT STRING. E.G., A,B,C,D.

SLASH

A MODIFICATION INDICATOR: AT ANY GIVEN PARAMETER STOP IF A SLASH IS TYPED IT SAYS "OPEN THIS PARAMETER FOR CHANGES".

. CR

CONTROL-U

DUMP THE PRESENT INPUT STRING AND START A NEW LINE. TYPED BY DEPRESSING THE "CONTROL KEY" (CTRL) AND THEN STRIKING THE "U".

RUBOUT

DELETE THE LAST CHARACTER FROM THE INPUT STRING. TYPED BY STRIKING THE "RUBOUT" KEY, WHICH WILL BE ECHOED BY A BACKSLASH (\) FOLLOWED BY THE CHARACTER DELETED.

4.3.1 ADDRESS SELECTION

STARTING THE PROGRAM FROM 200 (8) WILL RESULT IN AUTOMATIC SELECTION OF THE DEFAULT RPIIE VALUES OF BUS ADDRESS, VECTOR ADDRESS, AND PRIORITY LEVEL. IF THE DEFAULT VALUE OF THE BUS ADDRESS DOES NOT RESPOND (TIMES OUT) TO ADDRESSING, IT IS REPORTED AS AN ERROR. AFTER THE ERROR IS REPORTED, ONE OF TWO COURSES OF ACTION WILL BE TAKEN:

1. IF THERE IS A MONITOR -- RETURN TO THE MONITOR
2. IF THERE ISN'T A MONITOR -- ASK FOR NEW ADDRESSES

STARTING THE PROGRAM AT EITHER LOCATION 210 OR LOCATION 214 ALLOWS THE OPERATOR TO CHANGE THE RPIIE BUS ADDRESS, THE VECTOR ADDRESS, AND OR THE PRIORITY.

4.3.1.1 ADDRESS SELECTION EXAMPLES

EXAMPLE #1

RPDS=176710 176300..

EXAMPLE #2

RPDS=176710 176300.
RHVEC=254 260.
RHPRIO=5 6..

EXAMPLE #3

RPDS=177200
RHVEC=254 260..

EXAMPLE #4

RPII FAILED TO RESPOND TO ADDRESSING
RPDS ERR PC
176710 XXXXXX
RPDS=176710 176300..

EXAMPLE #5

RPDS=176710 177667 6300.
RHVEC=254.
RHPRIO=5
RPDS=176300

4.3.2 DRIVE, TEST, AND PARAMETER SELECTION

STARTING THE PROGRAM AT 200 WILL RESULT IN AUTOMATIC
SELECTION OF THE DRIVES TO TEST AND THE TESTS TO RUN.

STARTING THE PROGRAM AT 210 OR 214 ALLOWS THE OPERATOR
TO SELECT THE DRIVE(S) TO BE TESTED, THE TESTS TO BE EXECUTED,
AND THE PARAMETERS TO USE.

4.3.2.1 DRIVE, TEST, AND PARAMETER SELECTION DESCRIPTION

THE FOLLOWING IS A TABLE OF TERMS USED IN THE DESCRIPTION.

"R"	REPEATS (ITERATIONS)
"FC"	FIRST CYLINDER ADDRESS
"LC"	LAST CYLINDER ADDRESS
"IC"	INCREMENT CYLINDER
"TK"	TRACK ADDRESS

SPECIAL CASES OF CONTROL CHARACTERS

IF (...) IS TYPED WHILE A TEST IS OPEN FOR MODIFICATION
(...) AND OTHER TESTS IN THE "TEST COMMAND" STRING
ARE TO BE OPENED, THEY WILL RECIEVE THE PARAMETERS OF
THE TEST THAT IS OPEN WHEN (...) IS TYPED.

< > IS ILLEGAL AS A "TEST" LINE TERMINATOR
UNLESS A TEST IS TO BE OPENED.

ON STARTING THE PROGRAM ALL TESTS WILL RUN AGAINST ALL DRIVES
IN A WORST CASE MANNER. BUT IF THE USER DESIRES TO SELECT THE
DRIVES TO BE TESTED, THE TESTS TO BE EXECUTED, AND THE PARAMETERS
TO BE USED HE ENTERS CONVERSATION MODE BY TYPING CONTROL C (^C).

THE PROGRAM WILL RESPOND WITH:

DRIVE(S)=

WE WILL ASSUME FOR OUR EXAMPLE THAT THE OPERATOR WISHES TO TEST
DRIVE #3 USING TESTS 2 THRU 7 AND TEST 11 AND DOES NOT DESIRE TO CHANGE
THE PARAMETERS (INITIAL CYLINDER ADDRESS, FINAL CYLINDER ADDRESS, ETC.).
THE USER WOULD TYPE "3< >" WHICH SAYS "THIS IS THE END OF ANY
CHANGES TO THIS LINE BUT TAKE ME DEEPER FOR MORE CHANGES", AND <CR> "TAKE IT."

FOR CLARITY THE LINE WILL BE REPEATED AS IT LOOKS AFTER USER RESPONSE WITH
THE LINE BELOW IT ADDED, THE PROGRAMS RESPONSE:

DRIVE(S)=3.<CR>
TEST=

NOW THE USER INSERTS THE TEST NUMBERS HE DESIRES. IN THIS CASE
HE WANTS TESTS 2 THRU 7 AND TEST 11 SO HE TYPES 2-7< > (TO
SEPERATE FIELD), 11< > (END OF ANY CHANGES START EXECUTION),
<CR> (TAKE IT).

IT NOW LOOKS LIKE THIS

DRIVE(S)=3.<CR>
TEST=2-7.11.<CR>

IN OUR NEXT EXAMPLE WE WILL ASSUME THE USER WISHES TO TEST DRIVE
4 AND RUN TESTS 1 AND 3 THRU 11 WITH THE PARAMETER FOR TESTS 3
AND 10 MODIFIED.
THIS IS HOW HE WOULD RESPOND:

DRIVE(S)=4.(CR)
TEST=

THE USER NOW WILL INSERT A LINE TO GET TESTS 1 AND 3 THRU 11
BUT REMEMBER HE WISHES TO "OPEN" TESTS 3 AND 10 FOR PARAMETER
CHANGES. THE ENTIRE ENTRY IS SHOWN BELOW:

DRIVE(S)=4.(CR)
TEST=1.3 4-7.10 11.(CR)

NOTICE THIS SAYS SELECT TEST ONE, CONTINUE(.); SELECT TEST 3, OPEN(.);
SELECT TESTS 4-7, CONTINUE(.); SELECT TEST 10, OPEN(.); SELECT TEST
11, END OF INPUT (.).

THE PSI SCANS THE TEST STRING AND DETERMINES THAT TEST #1'S
PARAMETERS WILL REMAIN THE SAME BUT
TEST 3'S MUST BE CHANGED. THEREFORE, TEST
3 IS OPENED FOR CHANGE.

RESPONDS: <FOR CLARITY ENTIRE TRANSACTION REPEATED>

DRIVE(S)=4.(CR)
TEST=1.3 4-7.10 11.(CR)
TEST 3
R=X ;WHERE X IS ITERATION

AS IN THE NORMAL MANNER TYPING A (.) WILL OPEN THIS LINE FOR
MODIFICATION OF THE ITERATION COUNT, ENDING THE LINE WITH A
(.) (PERIOD) WOULD TERMINATE THE CHANGES FOR THIS TEST, AND AS
IN THE EXAMPLE SHOWN USING A (,) (COMMA) WILL GET US THE NEXT
PARAMETER.

DRIVE(S)=4.(CR)
TEST=1.3 4-7.10 11.(CR)
TEST 3
R=1, CR ;DO NOT ALTER-BUT CONTINUE
FC=4 ;WHERE N IS FIRST CYLINDER ADDRESS

THE USER DOES NOT WISH TO CHANGE "FC" SO THE FOLLOWING ACTION IS TAKEN:

```
DRIVE(S)=4.(CR)
TEST=1.3 4-7.10 11.(CR)
TEST 3
R=1.(CR)           ;DO NOT ALTER THIS LINE BUT CONTINUE
FC=0.(CR)         ;DO NOT ALTER THIS LINE BUT CONTINUE
LC=202
```

THE PROGRAM RESPONDS WITH THE PREVIOUSLY ASSIGNED PARAMETER FOR LAST CYLINDER ADDRESS IN THIS CASE USING "202" AS THE EXAMPLE. THIS IS WHAT THE USER INTENDED TO MODIFY AND IS WHY HE OPENED TEST #3. HE WANTS TO CHANGE IT TO CYLINDER 20. THEREFORE HE TYPES <> (OPEN LINE FOR CHANGE), "20" (THE NEW VALUE). (THIS IS THE END OF CHANGES FOR THIS DRIVE). (CR) TAKE IT

THE TOTAL TRANSACTION AND RESPONSE:

```
DRIVE(S)=4.(CR)
TEST=1.3 4-7.10 11. CR
TEST 3
R= 1.(CR)
FC=0.(CR)
LC= 202 20.(CR)
TEST 10
R=1
```

THE PROGRAM HAS LOADED TEST #3 WITH ITS NEW PARAMETERS. TESTS NUMBER 4 THRU 7 WITH THEIR PREVIOUSLY ASSIGNED PARAMETERS AND IS NOW WAITING FOR CHANGES TO TEST 10.

THE USER TYPES <> (OPEN THIS LINE FOR CHANGE), "10" (MAKE ITERATION COUNT 10). (THIS IS THE END OF CHANGES TO THIS TEST) (CR) (TAKE IT).

THE PROGRAM NOW LOADS TEST 10 WITH THE NEW PARAMETERS. TEST !! WITH PREVIOUSLY ASSIGNED PARAMETERS AND RESPONDS WITH:

DRIVE(S)=

SINCE THE USER DID NOT END THE CONVERSATION MODE WITH A (CR) THE PROGRAM HAS LOOPED BACK TO THE BEGINNING LOOKING FOR MORE CHANGES. THAT IS TO SAY, AFTER THE ENTRY FOR DRIVE SELECTION A (CR) WILL CAUSE THE TEST MESSAGE TO BE REPEATED AND FURTHER CHANGES CAN BE MADE. HOWEVER, AT SOME POINT IN ORDER TO EXECUTE THE CHANGES MADE WE MUST NOTIFY THE PROGRAM WE ARE FINISHED BY TYPING (CR).

4.3.3.2 DRIVE, TEST, AND PARAMETER SELECTION EXAMPLES

EXAMPLE #1

```
DRIVE=4. .CR          :SELECT DRIVE #4. TERMINATE AND  
                      :BEGIN EXECUTION USING PREVIOUSLY ASSIGNED  
                      :PARAMETERS
```

EXAMPLE #2

```
DRIVE=0. CR          :SELECT DRIVE #0 AND MAKE CHANGES ". "  
TEST=1-5. .CR       :RUN TEST 1 THRU 5 ONLY. USE DEFAULT  
                      :PARAMETERS AND TERMINATE AND EXECUTE ". "
```

EXAMPLE #3

```
DRIVE=2. CR          :SELECT DRIVE #2 AND MAKE CHANGES ". "  
TEST=1-5.6 7 10. .CR :RUN TEST 1-5 WITH DEFAULT PARAMETERS. OPEN  
TEST 6               :TEST 6, 7 AND 10 FOR CHANGES  
R=1. CR              :LEAVE R AS IS MOVE TO NEXT PARAMETER  
FC=0 10. CR         :SET "FC" CYLINDER ADDRESS TO 10 ". " ENC CHANGES  
                     :TO TEST #6
```

```
TEST 7               :50 ITERATIONS. MOVE TO NEXT PARAMETER  
R=1 50. CR           :DO NOT CHANGE "FC" CYLINDER ADDRESS BUT CONTINUE ". "  
FC=0. CR             :TEST 10 IS STILL PENDING  
LC=202 50. .CR      :AND WILL THEREFORE BE  
                     :SET TO THE SAME PARAMETERS  
                     :AS TEST 7 -- START EXECUTION
```

EXAMPLE #4

```
DRIVE=0.1.4.         :TEST DRIVES 0, 1, AND 4 IN SEQUENCE  
TEST=0-5.           :CHANGE TEST 0-5  
TEST 0  
R=10.  
FC=0.  
LC=202 1. .         :CHANGE LAST CYLINDER FROM 202  
                     :TO 1 FOR TEST #0-5; START TESTING
```

4.4 'CONTROL C' OPERATION

THE OPERATOR MAY TERMINATE THE PROGRAM AT ANY TIME BY TYPING A 'CONTROL C'. 'CONTROL C' RETURNS THE PROGRAM TO THE PARAMETER ENTRY ROUTINE. THE TEST PARAMETERS ARE NOT RESTORED TO THE DEFAULT VALUES BY THE 'CONTROL C' RETURN. CONTROL G OPERATION REFER TO SECTION 5.

5. OPERATING PROCEDURE

IF THE DIAGNOSTIC IS RUN ON A CPU WITHOUT A SWITCH REGISTER THEN A SOFTWARE SWITCH REGISTER IS USED WHICH ALLOWS THE USER THE SAME SWITCH OPTIONS AS THE HARDWARE SWITCH REGISTER. IF THE HARDWARE SWITCH REGISTER DOES NOT EXIST OR IF ONE DOES AND IT CONTAINS ALL ONES (177777) THEN THE SOFTWARE SWITCH REGISTER (LOC. 176) IS USED.

CONTROL:

THIS PROGRAM ALSO SUPPORTS THE DYNAMIC LOADING OF THE SOFTWARE SWITCH REGISTER (LOC. 176) FROM THE TTY. THIS CAN BE ACCOMPLISHED BY DOING THE FOLLOWING:

- 1) TYPE CONTROL G (<IG>); THIS WILL ALLOW THE TTY TO ENTER DATA INTO LOC. 176 AT SELECTED POINTS WITHIN THE PROGRAM.
- 2) THE MACHINE WILL THEN TYPE: SWR=XXXXXXNEW= (XXXXXX IS THE OCTAL CONTENTS OF THE SOFTWARE SWITCH REGISTER.)
- 3) AFTER THE 'NEW=' HAS BEEN TYPED THEN THE OPERATOR CAN DO ONE OF THE FOLLOWING AT THE TTY:
 - A) TYPE A NUMBER TO BE LOADED INTO LOC. 176 FOLLOWED BY A '<CR>'. (ONLY NUMBERS BETWEEN 0-7 WILL BE ACCEPTED AND ONLY 6 NUMBERS WILL BE ALLOWED)
IF A '<CR>' IS THE FIRST KEY DEPRESSED THE SOFTWARE SWITCH REGISTER CONTENTS WILL NOT BE CHANGED.
 - B) IF A CONTROL U (<IU>) IS DEPRESSED THEN THE PROGRAM WILL SEND YOU BACK TO STEP 2.

5.1 OPERATIONAL SWITCH SETTINGS

WITH SW<15:0>=0 THE PROGRAM WILL PRINT OUT ON ERRORS AND CONTINUE IN TEST.

THE SWITCH SETTINGS ARE:
SW<15>=1...HALT ON ERROR
SW<14>=1...LOOP ON TEST
SW<13>=1...INHIBIT ERROR TYPEOUTS
SW<11>=1...INHIBIT ITERATIONS
SW<10>=1...RING BELL ON ERROR
SW<09>=1...LOOP ON ERROR
SW<06>=1...TYPE ALL RP11 REGISTERS IF ERROR
SW<04>=1...TYPE THE LONG SEEK TIME GRAPH (TEST #12)
SW<03>=1...PERFORM STALL BETWEEN SEEK ORDERS
SW<02>=1...USE RANDOM STALL VALUE BETWEEN SEEK ORDERS
SW<01>=1...PERFORM INCREMENTING STALL IN TEST 4
SW<00>=1...DO NOT CHECK POSITION AFTER SEEK ORDERS

MO-11-DZRPZ-C. RPIIE DRIVE POSITIONING TEST
DZRPZC.P11 06-SEP-77 16:08

MACY11 30(1046)

MO1

06-SEP-77 16:32 PAGE 13

SEG 0012

6. ERRORS

THERE ARE A NUMBER OF ERRORS THAT CAN OCCUR IN THIS PROGRAM. WHEN AN ERROR IS ENCOUNTERED THE CALL TO THE ERROR ROUTINE IS MADE AND IF SW(13) IS NOT SET AN ERROR MESSAGE PERTAINING TO THE ERROR WILL BE TYPED. EACH ERROR TYPE OUT WILL CONTAIN THE FOLLOWING:

1. AN ERROR MESSAGE
2. A DATA HEADER
3. A DATA STRING

6.1. ERROR TYPES

THE ERRORS THAT OCCUR IN THIS PROGRAM FALL INTO TWO (2) CATEGORIES DEFINED AND EXPLAINED AS FOLLOWS:

6.1.1 NON-FATAL ERROR

THESE ERRORS WILL BE DUE TO "DISK" OR "DATA" FAILURES WHICH WILL BE REPORTED AS THEY OCCUR. AFTER REPORTING THE ERROR THE PROGRAM WILL CONTINUE TESTING.

6.1.2 FATAL ERROR

THIS TYPE OF ERROR WILL BE THE RESULT OF ANY KIND OF ERROR THAT INHIBITS THE PROGRAM FROM TESTING THE DISK.

THIS ERROR WILL BE REPORTED WHEN IT OCCURS, THEN THE PROGRAM WILL ABORT THE TEST AND GO TO THE END OF PROGRAM.

6.2 ERROR RECOVERY

6.2.1 NON-FATAL ERROR

WHEN THIS TYPE OF ERROR OCCURS IT WILL BE REPORTED AND THE PROGRAM WILL CONTINUE IN TEST.

6.2.2 FATAL ERROR

WHEN THIS TYPE OF ERROR OCCURS IT WILL BE REPORTED. THE PROGRAM WILL ABORT THE TEST AND GO TO THE END OF PROGRAM.

7. RESTRICTIONS

7.1 SUBSYSTEMS WITH MIXED DRIVE TYPES

THE PROGRAM ASSUMES THAT ONLY ONE KIND OF DRIVE IS ATTACHED TO A SYSTEM (E.G. RPO2'S & RPO2'S OR RPO3'S). IF BOTH RPO2'S

(AND RPO2'S) OR RPO3'S ARE ON THE SAME SYSTEM, THE PROGRAM WILL ASSUME THAT ALL OF THE DRIVES ARE RPO3'S. TO TEST DRIVES ON A MIXED SYSTEM, TEST ALL OF THE SAME KIND OF DRIVE AT ONE TIME. THE OTHER DRIVES ON THE CONTROLLER MUST BE POWERED DOWN.

7.2 FORMATTED PACKS

EACH OF THE DRIVES BEING TESTED MUST HAVE A FORMATTED PACK. (UNLESS THE PROGRAM IS RUN WITH SWITCH (00) SET.)

8. MISCELLANEOUS

8.1 EXECUTION TIME

TO MAKE ONE PASS OF THE PROGRAM (TESTS 0 - 7) TAKES APPROXIMATELY 1.8 HOURS FOR EACH RPO2 OR RPO2 TESTED AND APPROXIMATELY 6.5 HOURS FOR EACH RPO3 TESTED. NOTE THAT TEST 7 REQUIRES 1.3 HOURS FOR RPO2 DRIVES AND 5.4 HOURS FOR RPO3 DRIVES. IN SPITE OF THE LENGTHY RUN TIME OF TEST 7, IT IS RECOMMENDED THAT TEST 7 BE RUN OCCASIONALLY TO VERIFY THE SUBTRACTOR IN THE DISK DRIVE. TEST 7 HAS ALSO PROVEN TO BE A VALUABLE LONG TERM SEEK VERIFIER, ALSO.

8.2 STACK POINTER

STACK IS INITIALLY SET TO 1100 AND EXTENDS DOWNWARD IN MEMORY.

8.3 TIMING TEST PRINTOUTS

8.3.1 TIMING TEST (TESTS 10 & 11) PRINTOUT EXAMPLES

EXAMPLE #1

ONE CYLINDER SEEK TIMES
(SEEK TIME IS IN MICRO SECONDS)

FORWARD		REVERSE	
# OF SEEKS	SEEK TIME	# OF SEEKS	SEEK TIME
193	10000	60	10000
9	12500	142	12500


EXAMPLE #2

SEEK TIMES BETWEEN CYL 0 & 202
(SEEK TIME IS IN MICRO SECONDS)

FORWARD		REVERSE	
# OF SEEKS	SEEK TIME	# OF SEEKS	SEEK TIME
200	45000	156	45000
		44	60000

8.3.2 SEEK GRAPH TEST (TEST #12)
EXAMPLE: SMALL SEEK GRAPH (SWITCH (04) = 0)
SEEK TIME GRAPH

X AXIS - SEEK TIME - MILLI SECS
Y AXIS - CYLINDER SEEKED FROM 0



MD-11-DERP2-C. RPIIE DRIVE POSITIONING TEST
DERP2C.F11 06-SEP-77 16:08

MACY11 30(1046)

002

06-SEP-77 16:32 PAGE 17

SEG 0016

B.4 END OF TEST

WITH ALL SWITCHES ON A "0" AN "END OF PASS" MESSAGE WILL BE TYPED AT THE COMPLETION OF TESTING A DRIVE AND THE "END OF TEST" TYPEOUT WILL OCCUR WHEN ALL DRIVES HAVE BEEN TESTED.

B.5 DEFAULT ADDRESSES, TEST SEQUENCE, AND PARAMETERS

B.5.1 DEFAULT ADDRESS

THE PROGRAM IS LOADED FOR THE FOLLOWING ADDRESSES:
RPIIE BUS ADDRESS - 176710 RPIIE VECTOR ADDRESS - 254 RPIIE PRIORITY - 5

TO ALTER THESE ADDRESSES, START THE PROGRAM AT LOCATION 210 OR 214.

B.5.2 DEFAULT TEST SEQUENCE

THE DEFAULT TEST SEQUENCE IS TESTS 0 - 7. HIS SEQUENCE IS RESTORED ANY TIME A START FROM 200, 204, 210, OR 214 IS INITIATED. 'CONTROL C' RESTART DOES NOT ALTER THE TEST SEQUENCE.

B.5.3 DEFAULT TEST PARAMETERS

THE DEFAULT TEST PARAMETERS ARE GIVEN BELOW. REFER TO SECTION 4.3.1 FOR A GLOSSARY OF THE MNEMONICS USED TO IDENTIFY THE PARAMETERS. THE DEFAULT TEST PARAMETERS ARE RESTORED WHEN A START AT 200, 204, 210, OR 214 IS INITIATED. THE 'CONTROL C' RESTART DOES NOT ALTER THE CURRENT PARAMETER VALUES.

TEST #	'R'	'FC'	'LC'	'IC'	'TK'
TEST 0	100	-	-	-	0
TEST 1	1000	0	MAXCYL	-	0
TEST 2	10	0	MAXCYL	1	0
TEST 3	40	0	NOTE 3	1	0
TEST 4	10	0	MAXCYL	1	0
TEST 5	10	0	MAXCYL	1	0
TEST 6	10	0	MAXCYL	1	0
TEST 7	1	0	MAXCYL	1	0
TEST 10	(SEE BELOW - NOTE 1)				
TEST 11	1	0	MAXCYL	-	-
TEST 12	(SEE BELOW - NOTE 2)				

NOTE 1: TEST 10 ASSUMES THE FOLLOWING DEFAULT PARAMETERS. THESE PARAMETERS CANNOT BE ALTERED BY THE OPERATOR.

1 0 MAXCYL 1 -

NOTE 2: TEST 12 ASSUMES THE FOLLOWING DEFAULT PARAMETERS. THESE PARAMETERS CANNOT BE ALTERED BY THE OPERATOR.

1 0 MAXCYL 1 -

NOTE 3: 'MAXCYL' USED ABOVE IS USED TO DENOTE THE MAXIMUM CYLINDER ADDRESS USED BY THE PROGRAM. THE VALUE OF 'MAXCYL' IS DETERMINED BY THE TYPE OF DRIVES USED ON THE SYSTEM. 'MAXCYL' IS 405 (10) IF THE DRIVES ARE RPO3'S AND IS 202 (10) IF THE DRIVES ARE RPO2'S. IN TEST 3, 'LC' WILL BE 128 (10) IF THE DRIVES ARE RPO2'S AND 256 (10) IF THE DRIVES ARE RPO3'S.

E.6 TIMING TEST RESTRICTIONS

THE TIMING TESTS (TESTS 10, 11, & 12) ARE NOT INTENDED TO BE 'PASS-FAIL' TESTS. BECAUSE A HIGH RESOLUTION CLOCK IS NOT USED, THE TIMES ARE APPROXIMATE AND ARE INTENDED TO BE A GENERAL INDICATION OF THE CONDITION OF THE DRIVE'S SERVO SYSTEM. NO ATTEMPT SHOULD BE MADE TO ADJUST THE SERVO SYSTEM USING THE OUTPUT FROM THESE TESTS.

E.7 POSITIONING CHECK

IF SW(00) IS NOT SET, THE PROGRAM WILL CHECK THE DISK'S POSITION AFTER EACH SEEK (EXCEPT IN TESTS 10, 11, & 12).

THE PROGRAM CHECKS POSITION IN THE FOLLOWING MANNER:

USING THE 'SOT' COUNTER TO DETERMINE THE ADDRESS, THE PROGRAM READS THE HEADER FROM THE NEXT SECTOR AND COMPARES THE CYLINDER ADDRESS IN THE HEADER AGAINST THE CYLINDER THE PROGRAM EXPECTED; IF THE CYLINDER ADDRESS IN THE HEADER DOESN'T AGREE WITH THE EXPECTED CYLINDER ADDRESS, THE PROGRAM REPORTS A POSITIONING ERROR AND ISSUES A HOME SEEK TO THE DRIVE. (THE PROGRAM ALSO CHECKS POSITION AFTER A HOME SEEK OPERATION.)

9. PROGRAM DESCRIPTION

THE RPIIE DRIVE POSITIONING TEST CONTAINS 11 TESTS. TESTS 0 - 6 TEST THE OPERATION OF THE DRIVE'S SERVO SYSTEM. POSITIONING ACCURACY IS CHECKED BY READING A HEADER FROM THE DESTINATION CYLINDER USING A 'READ WITHOUT IMPLIED SEEK' INSTRUCTION AFTER THE SEEK TERMINATES.

TESTS 10) & 11, 12 MEASURE SEEK TIME. TEST 10 & 11 MEASURE THE TIME FOR SPECIFIC SEEK OPERATIONS; TEST 12 MEASURES THE TIME REQUIRED TO SEEK FROM CYLINDER 0 TO ALL OTHER CYLINDERS. TESTS 10 & 11 TYPE OUT THE MEASURED SEEK TIME IN MICROSECONDS WHILE TEST 12 PRODUCES A SEEK TIME GRAPH. IN THE SEEK TIMING TESTS, POSITIONING ACCURACY IS NOT CHECKED.

SEEK TIME IN TESTS 10, 11, & 12 IS DETERMINED BY COUNTING THE NUMBER OF SECTOR PULSES OCCURRING BETWEEN START OF SEEK AND SEEK DONE. THE 'SOT' COUNTER IS USED AS THE REFERENCE IN THESE TESTS. THE RESOLUTION OF THE TIMING TESTS IS 2.5 MS.

THE PROGRAM WILL START BY IDENTIFYING ITSELF AND DETERMINING ALL DRIVES THAT ARE AVAILABLE FOR TESTING. THEN BEGINNING WITH THE LOWEST NUMERICAL DRIVE AND PROCEEDING IN SEQUENTIAL ORDER ALL OF THE DRIVES WILL BE TESTED. ONE PASS THROUGH THE TEST SEQUENCE (TESTS 0 - 7) WILL BE PERFORMED ON EACH DRIVE BEFORE MOVING TO THE NEXT DRIVE IN SEQUENCE. THE DRIVE TO BE TESTED WILL BE TYPED AT THE BEGINNING OF EACH PASS. AN "END OF PASS" MESSAGE WILL BE TYPED AT THE COMPLETION OF EACH PASS. AND AN "END OF TEST" MESSAGE WILL BE TYPED AFTER TESTING ALL DRIVES.

REFER TO THE FOLLOWING SECTION FOR A DETAILED DESCRIPTION OF EACH TEST.

9.1 TEST DESCRIPTIONS

IN THE DESCRIPTIONS OF THE FOLLOWING TESTS, THE VARIABLES USED AND THEIR DEFAULT VALUES (UNLESS SPECIFIED OTHERWISE) ARE.

MNEMONIC -----	VARIABLE -----
FC	FIRST CYLINDER ADDRESS
LC	LAST CYLINDER ADDRESS
IC	INCREMENT VALUE
NC OR NC1	NEW OR MODIFIED CYLINDER (FC+IC) ADDRESS
NC2	NEW OR MODIFIED CYLINDER (LC-IC) ADDRESS
TA	TRACK ADDRESS

9.1.1 TEST 0 - HOME SEEK TEST

THIS TEST WILL CAUSE THE DRIVE TO EXECUTE A HOME SEEK COMMAND CYCLE. AT THE COMPLETION OF THE COMMAND, THE STATUS INDICATORS ARE CHECKED TO VERIFY THAT NO ERRORS HAVE OCCURED.

9.1.2 TEST 1 - SEEK/SEEK TEST

THIS TEST WILL CAUSE THE DRIVE TO EXECUTE A FORWARD SEEK CYCLE TO "LC" "LT" "LS" FOLLOWED BY A REVERSE SEEK CYCLE TO "FC" "FT" "FS". AT THE COMPLETION OF EACH SEEK, THE PROPER INDICATORS ARE EXAMINED TO INSURE PROPER OPERATION.

9.1.3 TEST 2 - INCREMENTAL SEEK TEST

THIS TEST WILL COMMAND FORWARD SEEK CYCLES TO ADVANCE THE CYLINDER ADDRESS FROM "FC" TO "LC" BY THE INCREMENT "IC" WHEN THE RESULTANT CYLINDER ADDRESS (NC) EXCEEDS "LC" REVERSE SEEK CYCLES ARE INITIATED, STARTING AT THE LAST LEGAL "NC" AND DECREMENTING BY "IC" UNTIL "NC" IS LESS THAN "FC". AT THE COMPLETION OF EACH SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO INSURE PROPER OPERATION.

9.1.4 TEST 3 - STEPPING SEEK TEST

THIS TEST WILL COMMAND SEEK CYCLES TO CYLINDER 0, 1, 2, 4, 8, 16, 32, 64, AND 128 (AND 256 IF AN RPO3). AT THE COMPLETION OF EACH SEEK COMMAND, THE PROPER INDICATORS ARE EXAMINED TO VERIFY PROPER OPERATION.

9.1.5 TEST 4 - OSCILLATING SEEK TEST

THIS TEST WILL COMMAND SEEK CYCLES FROM "FC" TO "NC" AND BACK TO "FC". "NC" STARTS AT "FC" AND INCREMENTS BY "IC" UP TO CYLINDER "LC", THEN IS DECREMENTED BY "IC" BACK TO CYLINDER "FC". AT THE COMPLETION OF EVERY SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO VERIFY PROPER OPERATION.

9.1.6 TEST 5 - CONVERGING/DIVERGING SEEK TEST

THIS TEST WILL CAUSE THE DRIVE TO EXECUTE FORWARD AND REVERSE SEEKS FROM "NC1" AND "NC2" RESPECTIVELY. "NC1" WILL BE INCREMENTED BY "IC" AND "NC2" WILL BE DECREMENTED BY "IC" UNTIL "NC1" IS GREATER THAN THE INITIAL VALUE OF "NC2" AND "NC2" IS LESS THAN THE INITIAL VALUE OF "NC1". AT THE COMPLETION OF EACH SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO VERIFY PROPER OPERATION. "NC1" AND "NC2" DEFAULT TO "FC" AND "LC" RESPECTIVELY.

9.1.7 TEST 6 - SERVO ADDRESSING LOGIC NOSE GENERATION

IN THIS TEST A SEEK IS DONE TO CYL "NC" THEN A SEEK TO NC+4 THEN NC+1 THEN NC+3 THEN NC+2 THEN NC+5. NOW "NC" IS UPDATED BY "IC" AND THE ABOVE SEQUENCE IS REPEATED UNTIL "LC" IS EXCEEDED BY ANY OF THE ABOVE VALUES. THE INITIAL VALUE OF "NC" IS "FC". AT THE COMPLETION OF EACH SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO INSURE PROPER OPERATION.

9.1.8 TEST 7 - CYLINDER ADDRESSING TEST

THIS TEST WILL CAUSE THE DRIVE TO SEEK FROM EACH CYLINDER TO EVERY OTHER CYLINDER BETWEEN CYLINDERS "FC" AND "LC". SEEK CYCLES ARE COMMANDED FROM CYLINDER "NC" TO CYLINDER "NC1" AND BACK TO CYLINDER "NC". "NC" AND "NC1" START AT "FC". "NC1" IS INCREMENTED BY "IC" UNTIL "NC1" IS EQUAL TO "LC". WHEN "NC1" IS EQUAL TO "LC" IT IS RESET TO "FC" AND "NC" IS INCREMENTED BY "IC". THE CYCLE IS COMPLETE WHEN "NC" AND "NC1" BOTH EQUAL "LC". AT THE COMPLETION OF EACH SEEK COMMAND, THE INDICATORS ARE EXAMINED TO VERIFY PROPER OPERATION.

9.1.9 TEST 10 - ONE CYLINDER SEEK TIMER TEST

THIS TEST PERFORMS ONE CYLINDER SEEKS FROM CYLINDER 0 TO THE MAXIMUM CYLINDER FOR THE DRIVE (E.G. 202 FOR RP02'S AND 405 FOR RP03'S). THE SEEK TIMES ARE MEASURED RELATIVE TO THE SECTOR PULSES FROM THE DRIVE. THE TEST DISPLAYS THE FORWARD AND REVERSE TIMES.

9.1.10 TEST 11 - SEEK-SEEK TIMER TEST

THIS TEST IS A GENERAL PURPOSE TIMING TEST WHICH PERFORMS 200 ITERATIONS BETWEEN THE CYLINDER IN 'FC' AND THE CYLINDER IN 'LC'. BOTH FORWARD AND REVERSE SEEKS ARE TIMED AND DISPLAYED. THE SEEK TIMES DISPLAYED ARE RELATIVE TO THE SECTOR COUNTER. 'FC' DEFAULTS TO 0; 'LC' DEFAULTS TO 'MAXCYL' (202 IF RP02'S OR 405 IF RP03'S).

9.1.11 TEST 12 - SEEK TIME GRAPH TEST

THIS TEST PRODUCES TWO SEEK TIME GRAPHS. THE FIRST GRAPH IS TYPED IS SWITCH <04> IS 0. THIS GRAPH IS A PLOT OF SEEK TIME AGAINST CYLINDERS SEEKED TO FROM CYLINDER 0. THE CYLINDERS PLOTTED ARE: 0,1,2,3,4,6,8,10,12,14,16,18,20,25,...,100,105,...,MAXCYL. THE OTHER GRAPH WHICH IS PRODUCED (SWITCH <04> SET) IS TIME TO SEEK TO ALL CYLINDERS FROM CYLINDER 0.

IN BOTH SEEK GRAPHS, ONLY THE FORWARD SEEK TIMES ARE MEASURED.

THIS TEST USES THE SECTOR COUNTER ('SOT') IN THE RP11 AS THE TIME BASE FOR THE MEASUREMENTS. USE OF THE 'SOT' PROVIDES A RESOLUTION OF 2.5 MS.

.C. PROGRAM LISTING

1039 000204 000137 002270
1040 000210 000137 002236
1041 000214 000137 002260
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1060
1061
1062
1063
1064
1065
1066
1067
1068
1069
1070
1071
1072
1073
1074
1075
1076
1077
1078
1079
1080
1081
1082
1083
1084
1085
1086
1087
1088
1089
1090
1091
1092
1093
1094

;;*START2
:*210 = SELECT RP11 ADDRESSES
;;*START3
:*214 = COMBINATION OF 204 AND 210
;;*START4

.SBTTL BASIC DEFINITIONS

;;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
STACK= 1100
.EQUIV EMT,ERROR ;;BASIC DEFINITION OF ERROR CALL
.EQUIV IOT,SCOPE ;;BASIC DEFINITION OF SCOPE CALL

;;*MISCELLANEOUS DEFINITIONS

HT= 11 ;;CODE FOR HORIZONTAL TAB
LF= 12 ;;CODE FOR LINE FEED
CR= 15 ;;CODE FOR CARRIAGE RETURN
CRLF= 200 ;;CODE FOR CARRIAGE RETURN-LINE FEED
PS= 177776 ;;PROCESSOR STATUS WORD
.EQUIV PS,PSW
STKLMT= 177774 ;;STACK LIMIT REGISTER
PIRQ= 177772 ;;PROGRAM INTERRUPT REQUEST REGISTER
OSWR= 177570 ;;HARDWARE SWITCH REGISTER
DDISP= 177570 ;;HARDWARE DISPLAY REGISTER

;;*GENERAL PURPOSE REGISTER DEFINITIONS

R0= %0 ;;GENERAL REGISTER
R1= %1 ;;GENERAL REGISTER
R2= %2 ;;GENERAL REGISTER
R3= %3 ;;GENERAL REGISTER
R4= %4 ;;GENERAL REGISTER
R5= %5 ;;GENERAL REGISTER
R6= %6 ;;GENERAL REGISTER
R7= %7 ;;GENERAL REGISTER
SP= %6 STACK POINTER
PC= %7 ;;PROGRAM COUNTER

;;*PRIORITY LEVEL DEFINITIONS

PRO= 0 ;;PRIORITY LEVEL 0
PR1= 40 ;;PRIORITY LEVEL 1
PR2= 100 ;;PRIORITY LEVEL 2
PR3= 140 ;;PRIORITY LEVEL 3
PR4= 200 ;;PRIORITY LEVEL 4
PR5= 240 ;;PRIORITY LEVEL 5
PR6= 300 ;;PRIORITY LEVEL 6
PR7= 340 ;;PRIORITY LEVEL 7

;;*"SWITCH REGISTER" SWITCH DEFINITIONS

SW15= 100000
SW14= 40000
SW13= 20000
SW12= 10000
SW11= 4000
SW10= 2000
SW09= 1000
SW08= 400

001100

000011
000012
000015
000200
177776

177774
177772
177570
177570

000000
000001
000002
000003
000004
000005
000006
000007
000006
000007

000000
000040
000100
000140
000200
000240
000300
000340

100000
040000
020000
010000
004000
002000
001000
000400

1095 000200
1096 000100
1097 000040
1098 000020
1099 000010
1100 000004
1101 000002
1102 000001

SW07 = 200
SW06 = 100
SW05 = 40
SW04 = 20
SW03 = 10
SW02 = 4
SW01 = 2
SW00 = 1

.EQUIV SW09,SW9
.EQUIV SW08,SW8
.EQUIV SW07,SW7
.EQUIV SW06,SW6
.EQUIV SW05,SW5
.EQUIV SW04,SW4
.EQUIV SW03,SW3
.EQUIV SW02,SW2
.EQUIV SW01,SW1
.EQUIV SW00,SW0

1115 100000
1116 040000
1117 020000
1118 010000
1119 004000
1120 002000
1121 001000
1122 000400
1123 000200
1124 000100
1125 000040
1126 000020
1127 000010
1128 000004
1129 000002
1130 000001

.*DATA BIT DEFINITIONS (BIT00 TO BIT15)

BIT15 = 100000
BIT14 = 40000
BIT13 = 20000
BIT12 = 10000
BIT11 = 4000
BIT10 = 2000
BIT09 = 1000
BIT08 = 400
BIT07 = 200
BIT06 = 100
BIT05 = 40
BIT04 = 20
BIT03 = 10
BIT02 = 4
BIT01 = 2
BIT00 = 1

.EQUIV BIT09,BIT9
.EQUIV BIT08,BIT8
.EQUIV BIT07,BIT7
.EQUIV BIT06,BIT6
.EQUIV BIT05,BIT5
.EQUIV BIT04,BIT4
.EQUIV BIT03,BIT3
.EQUIV BIT02,BIT2
.EQUIV BIT01,BIT1
.EQUIV BIT00,BIT0

1143 000004
1144 000010
1145 000014
1146 000014
1147 000014
1148 000020
1149 000024
1150 000030

.*BASIC "CPU" TRAP VECTOR ADDRESSES

FARVEC = 4 ; TIME OUT AND OTHER ERRORS
RESVEC = 10 ; RESERVED AND ILLEGAL INSTRUCTIONS
TBITVEC = 14 ; "T" BIT
TRTVEC = 14 ; TRACE TRAP
BPTVEC = 14 ; BREAKPOINT TRAP (BPT)
IOTVEC = 20 ; INPUT/OUTPUT TRAP (IOT) **SCOPE**
PWRVEC = 24 ; POWER FAIL
EMTVEC = 30 ; EMULATOR TRAP (EMT) **ERROR**

```

1151      000034      TRAPVEC=34      ;:"TRAP" TRAP
1152      000060      TKVEC= 60      ;:TTY KEYBOARD VECTOR
1153      000064      TPVEC= 64      ;:TTY PRINTER VECTOR
1154      000240      PIRQVEC=240    ;:PROGRAM INTERRUPT REQUEST VECTOR
1155
1156      ;OP CODE DEFINITIONS
1157
1158      000001      CLEAR=1      ;CONTROLLER CLEAR
1159      000003      WRTSEK=3      ;WRITE WITH IMPLIED SEEK AND HEAD SELECTION
1160      000005      ROSEK=5      ;READ WITH IMPLIED SEEK AND HEAD SELECT
1161      000007      WCKSEK=7      ;WRITE CHECK WITH IMPLIED SEEK AND HEAD SELECT
1162      000011      SEEK=11      ;SEEK
1163      000013      WRITE=13     ;WRITE (NO IMPLIED SEEK OR HEAD SELECT)
1164      000015      HOMSEK=15    ;HOME SEEK
1165      000017      READ=17      ;READ (NO IMPLIED SEEK OR HEAD SELECT)
1166
1167      ;RP11 REGISTER EQUATES
1168
1169      ;RPDS (DRIVE STATUS REGISTER)
1170
1171      ;ATTENTION BITS ARE REFERENCED BY BIT NUMBER (BIT00 - BIT07)
1172      000400      SWUP=400      ;SELECTED UNIT WRITE PROTECTED
1173      001000      SUFU=1000     ;SELECTED UNIT FILE UNSAFE
1174      002000      SUSU=2000     ;SELECTED UNIT SEEK UNDERWAY
1175      004000      SUSI=4000     ;SELECTED UNIT SEEK INCOMPLETE
1176      010000      HNF=10000    ;HEADER NOT FOUND
1177      020000      SURP03=20000  ;SELECTED UNIT IS AN RP03
1178      040000      SUOL=40000   ;SELECTED UNIT IS ONLINE
1179      100000      SURDY=100000  ;SELECTED UNIT IS READY
1180
1181      ;RPER (ERROR REGISTER)
1182
1183      000001      DSKERR=1      ;DISK ERROR
1184      000002      EOP=2        ;END OF PACK
1185      000004      NXME=4      ;NON-EXISTENT MEMORY
1186      000010      WCE=10      ;WRITE CHECK ERROR
1187      000020      TIMEE=20     ;TIMING ERROR
1188      000040      CSME=40      ;CHECKSUM ERROR
1189      000100      APE=100     ;WORD PARITY ERROR
1190      000200      LPE=200     ;LONGITUDINAL PARITY ERROR
1191      000400      MODERR=400   ;MODE ERROR
1192      001000      FMTE=1000    ;FORMAT ERROR
1193      002000      PROG=2000    ;PROGRAM ERROR
1194      004000      NXS=4000    ;NON-EXISTENT SECTOR
1195      010000      NXT=10000    ;NON-EXISTENT TRACK
1196      020000      NXC=20000    ;NON-EXISTENT CYLINDER
1197      040000      FUV=40000    ;FILE UNSAFE VIOLATION
1198      100000      WPV=100000   ;WRITE PROTECT VIOLATION
1199
1200      ;RPCS (CONTROL REGISTER)
1201
1202      ;'GO' BIT AND FUNCTION BITS ARE LOADED TOGETHER AND ARE DEFINED ELSEWHERE.
1203      ;EXTENDED MEMORY ADDRESS BITS ARE REFERED TO BY BIT NUMBER
1204      000100      IDE=100      ;INTERRUPT ON DONE
1205      000200      RDY=200      ;RP11 READY
1206      ;DRIVE SELECT BITS ARE REFERED TO BY BIT NUMBER
    
```

1207 004000
1208 010000
1209 020000
1210 040000
1211 100000
1212
1213

HDR=4000
MODE=10000
AIE=20000
HE=40000
ERR=100000

:HEADER
:MODE
:ATTENTION INTERRUPT ENABLE
:HARD ERROR
:ERROR


```

1270 001222 000000 CNTRLC: .WORD 0 : CONTROL "C" FLAG
1271 001223 000000 BUSADR: .WORD 0000 : GET ADDRESSES FROM THE TTY FLAG 0=NO -1=YES
1272 001224 000000 INADR: .WORD 0000 : CONTAINS INNER ADDRESS FOR TIMING TEST
1273 001225 000000 OUTADR: .WORD 0000 : CONTAINS OUTER ADDRESS FOR TIMING TEST
1274 001226 000000 DRVSEL: .WORD 0000 : DRIVES SELECTED FOR TESTING
1275 001227 000000 TSTMS: .WORD 777 : RUN TESTS 0-10
1276 001228 000000 MAXCYL: .WORD 0000 : MAXIMUM CYLINDER ADDRESS
1277 001229 000000 DRVTYP: .WORD 0 : CONTAINS A BIT FOR EACH RPO3 DRIVE
1278 001230 000000 : ON THE SYSTEM. BIT0=DRIVE 0, ETC
1279 001231 000000 SPSAV: .WORD 0 : SAVE THE STACK POINTER HERE
1280 001232 000000 BYPASS: .WORD 0000 : BYPASS CURRENT TEST ADDRESS
1281 001233 000000 CHKDRV: .WORD 0000 : DRIVE UNDER TEST
1282 001234 000000 DRVMSK: .WORD 0000 : DRIVE MASK BIT
1283 001235 000000 DRVBAD: .WORD 0000 : CONTAINS BITS FOR UNSAFE OR OFFLINE DRIVES
1284 001236 000000 CYL.CA: .WORD 0000 : CURRENT CYLINDER
1285 001237 000000 TRK.RD: .WORD 0000 : TRACK READ
1286 001238 000000 SEC.RD: .WORD 0000 : SECTOR READ
1287 001239 000000 CYL.DS: .WORD 0000 : CYLINDER DESIRED
1288 001240 000000 STR20X: .WORD 0 : START FROM 200, 204, 210, 214 FLAG

: CONSTANTS STORAGE
1291 001266 176710 RPAOR: .WORD 176710 : RPII ADDRESS
1292 001267 000254 RPVEC: .WORD 000254 : RPII VECTOR ADDRESS
1293 001268 000240 RPPRIO: .WORD 000240 : RPII PRIORITY
1294 001269 000000 STALLO: .WORD 0 : VARIABLE STALL (TEST 4)
1295 001270 000031 STALL1: .WORD 000031 : 25 MILLISECONDS STALL (TEST 0-6)
1296 001271 000000 STALLG: .WORD 000000 : GENERAL STALL VALUE (VARIABLE)
1297 001272 000062 MXSTAL: .WORD 000062 : MAX INCREMENTING STALL ALLOWED IN TEST -
1298 : EVEN

: *TABLE OF DRIVE STATUS INDICATORS
1300 : *DRVSTA=0 - DRIVE IS ONLINE
1301 : *DRVSTA=1 - DRIVE IS OFFLINE, UNSAFE, OR AN RPO3
1302 001304 000 DRVSTA: .BYTE 0 : DRIVE 0
1303 001305 000 : DRIVE 1
1304 001306 000 : DRIVE 2
1305 001307 000 : DRIVE 3
1306 001308 000 : DRIVE 4
1307 001309 000 : DRIVE 5
1308 001310 000 : DRIVE 6
1309 001311 000 : DRIVE 7
1310 001312 000 : DRIVE 8
1311 001313 000 : DRIVE 9

: ATTENTION BIT TABLE
1315 001314 001 ATABIT: .BYTE 1 : DRIVE 0
1316 001315 002 : DRIVE 1
1317 001316 004 : DRIVE 2
1318 001317 010 : DRIVE 3
1319 001318 020 : DRIVE 4
1320 001319 040 : DRIVE 5
1321 001320 080 : DRIVE 6
1322 001321 100 : DRIVE 7
1323 001322 200 : DRIVE 8
1324 001323 200 : DRIVE 9

: BIT TABLE
1324 001324 000000 BITS: .WORD BIT0C

```

```

13295 001332 000002 .WORD BIT01
13296 001333 000004 .WORD BIT02
13297 001334 000010 .WORD BIT03
13298 001335 000020 .WORD BIT04
13299 001336 000040 .WORD BIT05
13300 001337 000100 .WORD BIT06
13301 001338 000200 .WORD BIT07
13302 001339 000400 .WORD BIT08
13303 001340 001000 .WORD BIT09
13304 001341 002000 .WORD BIT10
13305 001342 004000 .WORD BIT11
13306 001354 010000 .WORD BIT12
13307 001355 020000 .WORD BIT13
13308 001356 040000 .WORD BIT14
13309 001362 100000 .WORD BIT15

```

:DRIVE OPERATION PARAMETER BLOCK

```

13310 001364 000 .DPB: .BYTE 0 :OP CODE
13311 001365 000 .BYTE 00 :DRIVE ADDRESS
13312 001366 000000 .WORD 000 :CYLINDER ADDRESS
13313 001370 000 .BYTE 000 :SECTOR ADDRESS
13314 001371 000 .BYTE 0 :TRACK ADDRESS

```

:COMMON STORAGE FOR TEST PARAMETER

```

13315 001372 000000 PRM: .WORD 0
13316 001374 000000 RPT: .WORD 0 :REPEAT COUNTS FOR ALL TESTS
13317 001376 000000 FC: .WORD 00 :FIRST CYLINDER
13318 001400 000000 LC: .WORD 00 :LAST CYLINDER
13319 001402 000000 IC: .WORD 00 :INCREMENT CYLINDER
13320 001404 000000 TK: .WORD 0 :TRACK ADDRESS

```

:TABLE OF PARAMETER POINTERS

```

13321 001406 001632 PRMPT: .WORD PRM0
13322 001410 001640 .WORD PRM1
13323 001412 001654 .WORD PRM2
13324 001414 001670 .WORD PRM3
13325 001416 001704 .WORD PRM4
13326 001420 001720 .WORD PRM5
13327 001422 001734 .WORD PRM6
13328 001424 001750 .WORD PRM7
13329 001426 001764 .WORD PRM10
13330 001430 001770 .WORD PRM11
13331 001432 002000 .WORD PRM12

```

:PARAMETER UPPER LIMIT

```

13332 001434 077777 PRMLMT: .WORD 32767. : "R"
13333 001436 000312 .WORD 202. : "FC"
13334 001440 000312 .WORD 202. : "LC"
13335 001442 000312 .WORD 202. : "IC"
13336 001444 000023 .WORD 19. : "TK"

```

:TABLE OF MESSAGE POINTERS

```

13337 001446 021420 PRMSG: .WORD MSG.R
13338 001450 021420 .WORD MSG.F

```

```

1382 001452 021425
1383 001454 021430
1384 001456 021433
1385
1386
1387 001460 000021 000144 000000
1388 001466 000037 001750 000000
1389 001474 000312 000000 000000
1390 001502 000037 000010 000000
1391 001510 000312 000001 000000
1392 001516 000037 000010 000000
1393 001524 000200 000001 000000
1394 001532 000037 000010 000000
1395 001540 000312 000001 000000
1396 001546 000037 000010 000000
1397 001554 000312 000001 000000
1398 001562 000037 000010 000000
1399 001570 000312 000001 000000
1400 001576 000037 000001 000000
1401 001604 000312 000001 000000
1402 001612 000001 000001 000000
1403 001616 000001 000001 000000
1404 001624 000312 000001 000000
1405 001626 000001 000001 000000
1406
1407
1408
1409
1410
1411 001632 000021
1412 001634 000144
1413 001636 000000
1414
1415
1416
1417
1418
1419 001640 000037
1420 001642 001750
1421 001644 000000
1422 001646 000312
1423 001650 000000
1424 001652 000000
1425
1426
1427
1428
1429 001654 000037
1430 001656 000012
1431 001660 000000
1432 001662 000312
1433 001664 000001
1434 001666 000000
1435
1436
1437
1438
1439 001670 000037
1440 001672 000012
1441 001674 000000
1442 001676 000200
1443 001700 000001
1444 001702 000000

```

```

.WORD MSG.LC
.WORD MSG.IC
.WORD MSG.TK

:DEFAULT VALUES OF TESTS PARAMETERS
DFLT: .WORD 21,100.0 ;HOME SEEK (T0)
.WORD 37,1000.0,202.0,0 ;SEEK/SEEK (T1)
.WORD 37,10,0,202.0,1.0 ;INCREMENT SEEK (T2)
.WORD 37,10,0,128.0,1.0 ;STEPPING SEEK (T3)
.WORD 37,10,0,202.0,1.0 ;OSCILLATING SEEK (T4)
.WORD 37,10,0,202.0,1.0 ;CONVERGING/DIVERGING SEEK (T5)
.WORD 37,10,0,202.0,1.0 ;SERVO ADDRESSING LOGIC NOISE (T6)
.WORD 37,1,0,202.0,1.0 ;CYLINDER ADDRESSING TEST (T7)
.WORD 1,1 ;ONE CYLINDER SEEK TIMER TEST (T8)
.WORD 1,1,0,202 ;SEEK-SEEK TIMER TEST (T11)
.WORD 1,1 ;SEEK TIME GRAPH TEST (T12)

```

```

:PARAMETER TABLES

:HOME SEEK (T0)
PRM0: .WORD 21
RPT0: .WORD 100.
TK0: .WORD 0

:SEEK-SEEK (T1)
PRM1: .WORD 37
RPT1: .WORD 1000.
FC1: .WORD 0
LC1: .WORD 202.
IC1: .WORD 0
TK1: .WORD 0

:INCREMENT SEEK (T2)
PRM2: .WORD 37
RPT2: .WORD 10.
FC2: .WORD 0
LC2: .WORD 202.
IC2: .WORD 1.
TK2: .WORD 0

:STEPPING SEEK (T3)
PRM3: .WORD 37
RPT3: .WORD 10.
FC3: .WORD 0
LC3: .WORD 128.
IC3: .WORD 1.
TK3: .WORD 0

```

001704 000037
 001706 000012
 001710 000000
 001712 000312
 001714 000001
 001716 000000
 001720 000037
 001722 000012
 001724 000000
 001726 000312
 001730 000001
 001732 000000
 001734 000037
 001736 000012
 001740 000000
 001742 000312
 001744 000001
 001746 000000
 001750 000037
 001752 000001
 001754 000000
 001756 000312
 001760 000001
 001762 000000
 001764 000001
 001766 000001
 001770 000007
 001772 000001
 001774 000000
 001776 000312
 002000 000001
 002002 000001
 002004 000000
 002006 000000
 002010 000000
 002012 000000
 002014 000000
 002016 000000
 002020 000000
 002022 000000

: OSCILLATING SEEK (T4)
 PRM4: .WORD 37
 RPT4: .WORD 10.
 FC4: .WORD 0
 LC4: .WORD 202.
 IC4: .WORD 1
 TK4: .WORD 0

: CONVERGING/DIVERGING SEEK (T5)
 PRM5: .WORD 37
 RPT5: .WORD 10.
 FC5: .WORD 0
 LC5: .WORD 202.
 IC5: .WORD 1
 TK5: .WORD 0

: SERVO ADDRESSING LOGIC NOISE GENERATOR (T6)
 PRM6: .WORD 37
 RPT6: .WORD 10.
 FC6: .WORD 0
 LC6: .WORD 202.
 IC6: .WORD 1
 TK6: .WORD 0

: CYLINDER ADDRESSING (T7)
 PRM7: .WORD 37
 RPT7: .WORD 1
 FC7: .WORD 0
 LC7: .WORD 202.
 IC7: .WORD 1
 TK7: .WORD 0

: ONE CYLINDER SEEK TIME TEST (T10)
 PRM10: .WORD 1
 RPT10: .WORD 1

: SEEK-SEEK TIMING TEST (T11)
 PRM11: .WORD 7
 RPT11: .WORD 1
 FC11: .WORD 0
 LC11: .WORD 202.

: SEEK TIME GRAPH TEST (T12)
 PRM12: .WORD 1
 RPT12: .WORD 1

: SAVE THE RPIIE REGISTERS HERE

\$RPDS: .WORD 0 : DRIVE STATUS REGISTER
 \$RPER: .WORD 0 : ERROR REGISTER
 \$RPCS: .WORD 0 : COMMAND & STATUS REGISTER
 \$RPWC: .WORD 0 : WORD COUNT REGISTER
 \$RPBA: .WORD 0 : BUFFER ADDRESS REGISTER
 \$RPCA: .WORD 0 : CURRENT CYLINDER ADDRESS REGISTER
 \$RPDA: .WORD 0 : TRACK-SECTOR ADDRESS REGISTER
 \$RPM1: .WORD 0 : MAINTENANCE REGISTER #1

1494 002024 000000 \$SUCA: .WORD 0 :SELECTED UNIT CYLINDER ADDRESS REGISTER
1495 002026 000000 \$SILO: .WORD 0 :SILO REGISTER

:REGISTER INDEX VALUES

1496 000000 RPD5=00 :DRIVE STATUS REGISTER
1497 000002 RPER=02 :ERROR REGISTER
1498 000004 RPCS=04 :CONTROL REGISTER
1499 000006 RPWC=06 :WORD COUNT REGISTER
1500 000010 RPBA=10 :BUFFER ADDRESS REGISTER
1501 000012 RPCA=12 :CYLINDER ADDRESS REGISTER
1502 000014 RPOA=14 :SECTOR/TRACK ADDRESS REGISTER
1503 000016 RPM1=16 :MAINTENANCE REGISTER #1
1504 000020 RPM2=20 :MAINTENANCE REGISTER #2
1505 000022 RPM3=22 :MAINTENANCE REGISTER #3
1506 000024 SUCA=24 :SELECTED UNIT CYLINDER ADDRESS REGISTER
1507 000026 SILO=26 :SILO REGISTER

1508 002030 0200 040 BLNK13: .ASCII
1509 002033 0000 040 BLNK10: .ASCII
1510 002035 0000 040 BLNK59: .ASCII
1511 002037 0000 040 BLNK58: .ASCII
1512 002039 0000 040 BLNK57: .ASCII
1513 002041 0000 040 BLNK56: .ASCII
1514 002043 0000 040 BLNK55: .ASCII
1515 002045 0000 040 BLNK54: .ASCII
1516 002047 0000 040 BLNK53: .ASCII
1517 002049 0000 040 BLNK52: .ASCII
1518 002051 0000 040 BLNK51: .ASCII
1519
1520
1521
1522
1523
1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547
1548
1549
1550
1551
1552
1553
1554
1555
1556
1557
1558
1559
1560
1561
1562
1563
1564
1565
1566
1567
1568
1569
1570
1571
1572
1573
1574
1575
1576
1577
1578
1579
1580
1581
1582
1583
1584
1585
1586
1587
1588
1589
1590
1591
1592
1593
1594
1595
1596
1597
1598
1599
1600
1601
1602
1603
1604
1605
1606
1607
1608
1609
1610
1611
1612
1613
1614
1615
1616
1617
1618
1619
1620
1621
1622
1623
1624
1625
1626
1627
1628
1629
1630
1631
1632
1633
1634
1635
1636
1637
1638
1639
1640
1641
1642
1643
1644
1645
1646
1647
1648
1649
1650
1651
1652
1653
1654
1655
1656
1657
1658
1659
1660
1661
1662
1663
1664
1665
1666
1667
1668
1669
1670
1671
1672
1673
1674
1675
1676
1677
1678
1679
1680
1681
1682
1683
1684
1685
1686
1687
1688
1689
1690
1691
1692
1693
1694
1695
1696
1697
1698
1699
1700
1701
1702
1703
1704
1705
1706
1707
1708
1709
1710
1711
1712
1713
1714
1715
1716
1717
1718
1719
1720
1721
1722
1723
1724
1725
1726
1727
1728
1729
1730
1731
1732
1733
1734
1735
1736
1737
1738
1739
1740
1741
1742
1743
1744
1745
1746
1747
1748
1749
1750
1751
1752
1753
1754
1755
1756
1757
1758
1759
1760
1761
1762
1763
1764
1765
1766
1767
1768
1769
1770
1771
1772
1773
1774
1775
1776
1777
1778
1779
1780
1781
1782
1783
1784
1785
1786
1787
1788
1789
1790
1791
1792
1793
1794
1795
1796
1797
1798
1799
1800

.EVEN

.SBTTL ERROR POINTER TABLE

: *THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
: *THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
: *LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
: *NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
: *NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

: * EM ::POINTS TO THE ERROR MESSAGE
: * DH ::POINTS TO THE DATA HEADER
: * DT ::POINTS TO THE DATA
: * DF ::POINTS TO THE DATA FORMAT

\$ERRTB:
: *EM AND DH ARE ASCII MESSAGES. DT IS A STRING OF WORDS THAT POINT TO THE
: *DATA TO BE TYPED AND DF IS A STRING OF DATA THAT TELL HOW THE DT WORDS
: *ARE TO BE TYPED. IF ANY OF THE POINTERS ARE NOT NEEDED FOR A PARTICULAR
: *ERROR IT IS REPLACED WITH A ZERO.
: *EACH OF THE ITEMS BELOW REFER TO THE ERROR NUMBER AND INDICATE
: *THE INFORMATION THAT WILL BE TYPED WHEN THE ERROR OCCURS.
: *UNLESS STATED OTHER ALL NUMBERS ARE OCTAL

:ERROR 1

002046 021642 EM1 :RPI1 FAILED TO RESPOND TO ADDRESSING
002050 022603 DH1
002052 023336 DT1
002054 023472 DF1

:ERROR 2

002056 021707 EM2 :DRIVE UNSAFE
002060 022620 DH2
002062 023342 DT2
002064 023476 DF2

:ERROR 3

002066 021724 EM3 :DRIVE OFFLINE
002070 022620 DH3
002072 023342 DT3
002074 023476 DF3

:ERROR 4

002076 021742 EM4 :DISK ERROR DURING TIMING TEST
002100 022620 DH4
002102 023342 DT4
002104 023476 DF4

:ERROR 5

002106 022001 EM5 :NO INTERRUPT FROM POSITIONING AFTER 1 SECOND

1502
1503
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522
1523
1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547
1548
1549
1550

1582	002110	022620	DH2	
1583	002112	023342	DT2	
1584	002114	023476	DF2	
1585				
1586				: ERROR 6
1587				
1588	002116	022056	EM6	: DISK ERROR AFTER POSITIONING
1589	002120	022620	DH2	
1590	002122	023342	DT2	
1591	002124	023476	DF2	
1592				: ERROR 7
1593				
1594	002126	022113	EM7	: ATTN BIT NOT SET AFTER POSITIONING
1595	002130	022620	DH2	
1596	002132	023342	DT2	
1597	002134	023476	DF2	
1598				: ERROR 10
1599				
1600				
1601	002136	022166	EM10	: DRIVE OFFLINE AFTER POSITIONING
1602	002140	022620	DH2	
1603	002142	023342	DT2	
1604	002144	023476	DF2	
1605				: ERROR 11
1606				
1607				
1608				
1609	002146	022226	EM11	: 'SUCA' NOT CORRECT AFTER POSITIONING
1610	002150	022675	DH11	
1611	002152	023356	DT11	
1612	002154	023502	DF11	
1613				: ERROR 12
1614				
1615				
1616	002156	022273	EM12	: DISK ERROR WHILE VERIFYING POSITION
1617	002160	022762	DH12	
1618	002162	023374	DT12	
1619	002164	023506	DF12	
1620				: ERROR 13
1621				
1622				
1623	002166	022337	EM13	: DISK POSITIONED TO WRONG CYLINDER
1624	002170	023057	DH13	
1625	002172	023414	DT13	
1626	002174	023512	DF13	
1627				: ERROR 14
1628				
1629				
1630	002176	022401	EM14	: NO INTERRUPT FROM I/O AFTER 1 SECOND
1631	002200	022620	DH2	
1632	002202	023342	DT2	
1633	002204	023476	DF2	
1634				: ERROR 15
1635				
1636	002206	022446	EM15	: SEEK INCOMPLETE

1638	002210	022620	DH2	
1639	002212	023342	DT2	
1640	002214	023476	DF2	
1641				
1642				: ERROR 16
1643				
1644	002216	022466	EM16	: DRIVE NOT READY AFTER POSITIONING
1645	002220	022620	DH2	
1646	002222	023342	DT2	
1647	002224	023476	DF2	
1648				
1649				: ERROR 17
1650				
1651	002226	022530	EM17	: DRIVE NOT READY/OFFLINE DURING TIMING TEST
1652	002230	022620	DH2	
1653	002232	023342	DT2	
1654	002234	023476	DF2	
1655				
1656				

```

1657
1658
1659
1660
1661 002236 012737 177777 001224 START3: MOV # -1, @BUSADR ; GET BUSADR FLAG
1662 002244 000402 BR STRT1A ;
1663 002246 005037 001224 START1: CLR @BUSADR ; CLR BUSADR FLAG
1664 002252 005037 001222 STRT1A: CLR @CNTRLC ; NO CONTROL "C"
1665 002256 000411 BR START ;
1666 002260 012737 177777 001224 START4: MOV # -1, @BUSADR ; SET BUSADR FLAG
1667 002266 000402 BR STRT2A ;
1668 002270 005037 001224 START2: CLR @BUSADR ; CLR BUSADR FLAG
1669 002274 012737 177777 001222 STRT2A: MOV # -1, @CNTRLC ; SET CONTROL "C" FLAG
1670 002302 012737 177777 001264 START: MOV # -1, STR20X ; SET START FLAG
1671 002310 000005 RESET ;
1672
1673 .SBTTL INITIALIZE THE COMMON TAGS
1674 :: CLEAR THE COMMON TAGS ($CMTAG) AREA
1675 002312 012706 001100 MOV # $CMTAG, R6 ; FIRST LOCATION TO BE CLEARED
1676 002316 005026 CLR (R6)+ ; CLEAR MEMORY LOCATION
1677 002320 022706 001140 CMP # SWR, R6 ; ; DONE?
1678 002324 001374 BNE -6 ; LOOP BACK IF NO
1679 002326 012706 001100 MOV # STACK, SP ; SETUP THE STACK POINTER
1680 :: INITIALIZE A FEW VECTORS
1681 002332 012737 012524 000020 MOV # $SCOPE, @IOTVEC ; IOT VECTOR FOR SCOPE ROUTINE
1682 002340 012737 000340 000022 MOV # 340, @IOTVEC+2 ; LEVEL 7
1683 002346 012737 007742 000030 MOV # $ERROR, @EMTVEC ; EMT VECTOR FOR ERROR ROUTINE
1684 002354 012737 000340 000032 MOV # 340, @EMTVEC+2 ; LEVEL 7
1685 002362 012737 013164 000034 MOV # $TRAP, @TRAPVEC ; TRAP VECTOR FOR TRAP CALLS
1686 002370 012737 000340 000036 MOV # 340, @TRAPVEC+2 ; LEVEL 7
1687 002376 005037 001206 CLR $TIMES ; INITIALIZE NUMBER OF ITERATIONS
1688 002402 005037 001210 CLR $ESCAPE ; CLEAR THE ESCAPE ON ERROR ADDRESS
1689 002406 112737 000001 001115 MOVB # 1, $SERMAX ; ALLOW ONE ERROR PER TEST
1690 002414 012737 002414 001106 MOV # ., $LPADR ; INITIALIZE THE LOOP ADDRESS FOR SCOPE
1691 002422 012737 002422 001110 MOV # ., $LPERR ; SETUP THE ERROR LOOP ADDRESS
1692 :: SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
1693 :: EQUAL TO A "-1" SETUP FOR A SOFTWARE SWITCH REGISTER.
1694 002430 013746 000004 MOV @ERRVEC, -(SP) ; SAVE ERROR VECTOR
1695 002434 012737 002470 000004 MOV # 64$, @ERRVEC ; SET UP ERROR VECTOR
1696 002442 012737 177570 001140 MOV # DSWR, SWR ; SETUP FOR A HARDWARE SWICH REGISTER
1697 002450 012737 177570 001142 MOV # DISP, DISPLAY ; AND A HARDWARE DISPLAY REGISTER
1698 002456 022777 176454 CMP # -1, @SWR ; TRY TO REFERENCE HARDWARE SWR
1699 002464 001012 BNE 66$ ; BRANCH IF NO TIMEOUT TRAP OCCURRED
1700 002466 000403 BR 65$ ; AND THE HARDWARE SWR IS NOT = -1
1701 002470 012716 002476 64$: BR # 65$, (SP) ; BRANCH IF NO TIMEOUT
1702 002474 000002 RTI ; SET UP FOR TRAP RETURN
1703 002476 012737 000176 001140 65$: MOV # SWREG, SWR ; POINT TO SOFTWARE SWR
1704 002504 012737 000174 001142 MOV # DISPREG, DISPLAY ;
1705 002512 012637 000004 66$: MOV (SP)+, @ERRVEC ; RESTORE ERROR VECTOR
1706
1707 002516 012700 001160 MOV # $REGAD, RO ; FIRST ADDRESS
1708 002522 005020 1$: CLR (RO)+ ; CLEAR VARIABLE STORAGE
1709 002524 022700 001212 CMP # $BELL, RO ; DONE?
1710 002530 001374 BNE 1$ ; NO--BRANCH
1711 002532 005227 177777 INC # -1 ; FIRST START
1712 002536 001036 BNE 2$ ; BR IF NOT

```

1713	002540	023737	000042	000046		CMP	0042,0046	:ACT11 AUTO MODE?
1714	002546	001432				BEQ	25	:YES SKIP TITLE PRINTOUT
1715	002550	104401	002556			TYPE	685	:TYPE ASCIZ STRING
1716	002554	000427				BR	675	:GET OVER THE ASCIZ
1717					685:	.ASCIZ	<15><12>/MD-11-DZRPZ-C, RPIIE DRIVE POSITIONING TEST/	
1718	002634				675:			
1719	002634	004737	011254		25:	JSR	PC,STKINT	:SETUP THE TTY KEYBOARD
1720					.SBTTL	GET VALUE FOR SOFTWARE SWITCH REGISTER		
1721	002640	005737	000042			TST	0042	:ARE WE RUNNING UNDER XXDP/ACT?
1722	002644	001006				BNE	695	:BRANCH IF YES
1723	002646	023727	001140	000176		CMP	SWR,#SWREG	:SOFTWARE SWITCH REG SELECTED?
1724	002654	001005				BNE	705	:BRANCH IF NO
1725	002656	104406				GTSWR		:GET SOFT-SWR SETTINGS
1726	002660	000403				BR	705	
1727	002662	112737	000001	001134	695:	MOV	#1,\$AUTOB	:SET AUTO-MODE INDICATOR
1728	002670				705:			
1729	002670	012737	000377	001234		MOV	#377,TSTNMS	:SELECT TESTS 0-7
1730	002676	012700	001460			MOV	#DFLT,RO	:DEFAULT PARAMETERS POINTER
1731	002702	012701	001632			MOV	#PRM0,R1	:TABLE POINTER
1732	002706	010102				MOV	R1,R2	:STOP ADDRESS
1733	002710	012021			35:	MOV	(R0)+,(R1)+	:MOVE DEFAULT PARAMETERS INTO
1734	002712	020002				CMP	RO,R2	:RUN TIME TABLES ** DONE?
1735	002714	103775				BLO	35	:NO--BRANCH
1736	002716	000406				BR	SRTINT	:FINISH SETUP
1737	002720	000005			STARTS:	RESET		:CONTROL C' RESET
1738	002722	004737	011254			JSR	PC,STKINT	
1739	002726	012737	177777	001222		MOV	#-1,CNTRLC	:SET 'CONTROL C' SWITCH
1740	002734	012737	000340	000062	SRTINT:	MOV	#PR7,TKVEC+2	:SET TTY PRIORITY TO 7
1741	002742	005037	177776			CLR	PS	:SET PRIORITY TO ZERO
1742	002746	005037	001252			CLR	DRVBAD	:CLEAR OFFLINE/UNSAFE DRIVE BITS
1743	002752	005037	001206			CLR	\$TIMES	:INITIALIZE NUMBER OF ITERATIONS
1744	002756	005037	001210			CLR	\$ESCAPE	:CLEAR THE ESCAPE ON ERROR ADDRESS
1745	002762	005037	001244			CLR	BYPASS	:CLEAR THE BYPASS ADDRESS
1746	002766	012737	000001	001104		MOV	#1,\$ICNT	:PRESET ITERATION COUNT TO 1
1747	002774	112737	000001	001115		MOV	#1,\$SERMAX	:ALLOW ONE ERROR PER TEST
1748	003002	012737	003002	001106		MOV	#,\$LPAOR	:INITIALIZE THE LOOP ADDRESS FOR SCOPE
1749	003010	012737	003010	001110		MOV	#,\$LPERR	:SETUP THE ERROR LOOP ADDRESS
1750	003016	004737	017256			JSR	PC,GETADR	:CHECK RPII ADDRESS
1751	003022	004737	013642			JSR	PC,RPINIT	:FIND OUT WHICH DRIVES ARE ON SYSTEM
1752	003026	012737	000312	001236		MOV	#202,MAXCYL	:ASSUME RPO2'S
1753	003034	005737	001240			TST	DRVTYP	:WHICH DRIVES ?
1754	003040	001403				BEQ	15	:BR IF THEY REALLY WERE RPO2'S
1755	003042	012737	000625	001236		MOV	#405,MAXCYL	:SET MAX CYLINDER FOR RPO3'S
1756	003050	013737	001236	001436	15:	MOV	MAXCYL,PRMLMT+2	:UPDATE 'FC' LIMIT
1757	003056	013737	001236	001440		MOV	MAXCYL,PRMLMT+4	:UPDATE 'LC' LIMIT
1758	003064	005737	001264			TST	STR20X	:COMING FROM A 'CONTROL C' RESTART ?
1759	003070	001002				BNE	95	:BR IF NOT
1760	003072	000137	003442			JMP	START6	:BYPASS 'LC' UPDATE AND DRIVE STATUS TYPEOUT
1761	003076				95:			
1762	003076	013737	001236	001646		MOV	MAXCYL,LC1	:SETUP MAX CYLINDER FOR TEST 1
1763	003104	013737	001236	001662		MOV	MAXCYL,LC2	:SETUP MAX CYLINDER FOR TEST 2
1764	003112	013737	001236	001712		MOV	MAXCYL,LC4	:SETUP MAX CYLINDER FOR TEST 4
1765	003120	013737	001236	001726		MOV	MAXCYL,LC5	:SETUP MAX CYLINDER FOR TEST 5
1766	003126	013737	001236	001742		MOV	MAXCYL,LC6	:SETUP MAX CYLINDER FOR TEST 6
1767	003134	013737	001236	001756		MOV	MAXCYL,LC7	:SETUP MAX CYLINDER FOR TEST 7
1768	003142	013737	001236	001776		MOV	MAXCYL,LC11	:SETUP MAX CYLINDER FOR TEST 11

```

1769 003150 012737 000200 001676      MOV      #128.,LC3      ;ASSUME RPO2
1770 003156 005737 001240                TST      DRVTP        ;RPO2 OR RPO3 ?
1771 003162 001403                BEQ      2$           ;BR IF RPO2'S
1772 003164 012737 000400 001676      MOV      #256.,LC3    ;CHANGE VALUE FOR RPO3
1773 003172 005227 177777      2$:      INC      #-1        ;FIRST START ?
1774 003176 001404                BEQ      10$          ;BR IF IT IS
1775 003200 032777 000200 175732      BIT      #SW07,DSWR   ;INHIBIT THE STATUS TYPEOUT
1776 003206 001115                BNE      START6      ;BR IF YES
1777 003210      10$:
1778 003210 104401 003216      TYPE     65$         ;:TYPE ASCIZ STRING
1779 003214 000412                BR       64$         ;:GET OVER THE ASCIZ
1780      65$: .ASCIZ <15><12><12><DRIVE STATUS:><15><12><12>
1781      64$:
1782 003242 005001                CLR      R1          ;CLEAR TABLE POINTER
1783 003244 012702 000010      MOV      #8.,R2      ;COUNTER
1784 003250      3$:
1785 003250 010146      MOV      R1, -(SP)   ;SAVE R1 FOR TYPEOUT
1786      ;:TYPE DRIVE NUMBER
1787 003252 104403      TYPDS   ;:GO TYPE--OCTAL ASCII
1788 003254 001          .BYTE 1 ;:TYPE 1 DIGIT(S)
1789 003255 000          .BYTE 0 ;:SUPPRESS LEADING ZEROS
1790 003256 105761 001304      TSTB   DRVSTA(R1)   ;CHECK DRIVE'S STATUS
1791 003262 001450      BEQ    7$           ;DRIVE IS OFFLINE OR NON-EXISTENT
1792 003264 100412      BMI    4$           ;DRIVE IS UNSAFE
1793 003266 104401 003274      TYPE   67$         ;:TYPE ASCIZ STRING
1794 003272 000406      BR     66$         ;:GET OVER THE ASCIZ
1795      67$: .ASCIZ / ONLINE /
1796      66$:
1797 003310 000411      BR     5$           ;
1798 003312      4$:
1799 003312 104401 003320      TYPE   69$         ;:TYPE ASCIZ STRING
1800 003316 000406      BR     68$         ;:GET OVER THE ASCIZ
1801      69$: .ASCIZ / UNSAFE /
1802      68$:
1803 003334 136137 001314 001240      BITB   ATABIT(R1),DRVTP ;SEE WHICH DRIVE TYPE
1804 003342 001010      BNE    6$           ;BR IF RPO3
1805 003344 104401 003352      TYPE   71$         ;:TYPE ASCIZ STRING
1806 003350 000404      BR     70$         ;:GET OVER THE ASCIZ
1807      71$: .ASCIZ / RPO2
1808      70$:
1809 003362 000422      BR     8$           ;
1810      6$:
1811 003364 104401 003372      TYPE   73$         ;:TYPE ASCIZ STRING
1812 003370 000404      BR     72$         ;:GET OVER THE ASCIZ
1813      73$: .ASCIZ / RPO3 /
1814      72$:
1815 003402 000412      BR     8$           ;
1816      7$:
1817 003404 104401 003412      TYPE   75$         ;:TYPE ASCIZ STRING
1818 003410 000407      BR     74$         ;:GET OVER THE ASCIZ
1819      75$: .ASCIZ / OFFLINE /
1820      74$:
1821 003430 104401 001217      8$:      TYPE   $CRLF       ;CR-LF
1822 003434 005201                INC      R1          ;INCREMENT TABLE POINTER
1823 003436 005302                DEC      R2          ;DECREMENT THE COUNTER
1824 003440 001303                BNE     3$          ;CONTINUE
    
```

```

1825 003442 005037 001264      START6: CLR      STR20X      ;CLEAR MANUAL START FLAG
1826 003446 005737 001222      TST      CNTRLC      ;CONTROL "C" START/RESTART?
1827 003452 001403      BEQ      1$          ;NO--BRANCH
1828 003454 004737 017610      JSR      PC, @#GT.PRM ;YES--GET PARAMETERS
1829 003460 000416      BR       5$          ;
1830 003462 005037 001232      1$: CLR      DRVSEL     ;NO DRIVES SELECTED
1831 003466 005000      CLR      R0          ;DETERMINE THE DRIVES THAT
1832 003470 012701 000001      MOV      #1, R1      ;ARE AVAILABLE FOR TESTING
1833 003474 105760 001304      2$: TSTB     DRVSTA(R0)
1834 003500 003403      BLE     3$          ;
1835 003502 156037 001314 001232  BLSB     ATABIT(R0), @#DRVSEL
1836 003510 005200      3$: INC      R0          ;
1837 003512 106301      ASLB     R1          ;
1838 003514 001367      BNE     2$          ;
1839 003516      5$:          ;
1840 003516 104401 003524      TYPE     65$        ;:TYPE ASCIZ STRING
1841 003522 000415      BR       64$        ;:GET OVER THE ASCIZ
1842      ;:65$: .ASCIZ <15><12>/DRIVE(S) TO BE TESTED /
1843 003556      64$:          ;
1844 003556 005037 007656      CLR      @#SENDCT    ;DETERMINE PASSES TO MAKE AND
1845 003562 005000      CLR      R0          ;THE DRIVES TO BE TESTED
1846 003564 013701 001232      MOV      @#DRVSEL, R1 ;ANY DRIVES SELECTED?
1847 003570 001010      BNE     9$          ;YES--BRANCH
1848 003572 104401 003600      TYPE     67$        ;:TYPE ASCIZ STRING
1849 003576 000403      BR       66$        ;:GET OVER THE ASCIZ
1850      ;:67$: .ASCIZ /NONE/
1851 003606      66$:          ;
1852 003606 000137 007474      JMP      @#SEOP      ;GO TO END OF PROGRAM
1853 003612 005737 001222      9$: TST      CNTRLC    ;CONTROL "C" START/RESTART ?
1854 003616 001010      BNE     6$          ;BR IF NOT
1855 003620 005737 000042      TST      42         ;UNDER MONITOR CONTROL ?
1856 003624 001405      BEQ     6$          ;BR IF NOT
1857 003626 122737 000007 000041  CMPB     #7, 41     ;LOADED BY RPO2/RPO3 ?
1858 003634 001001      BNE     6$          ;BR IF NOT
1859 003636 006201      ASR      R1          ;EXCLUDE DRIVE 0 FROM TESTING
1860 003640 006201      6$: ASR      R1          ;REPORT THE DRIVES TO BE TESTED
1861 003642 103013      BCC     7$          ;
1862 003644 005237 007656      INC      @#SENDCT    ;GIVE THIS DRIVE A PASS
1863 003650 010046      MOV      R0, -(SP)  ;SAVE R0 FOR TYPEOUT
1864 003652 104403      TYPOS   1          ;GO TYPE--OCTAL ASCII
1865 003654 001      .BYTE   1          ;TYPE 1 DIGIT(S)
1866 003655 000      .BYTE   0          ;SUPPRESS LEADING ZEROS
1867 003656 005701      TST      R1          ;MORE DRIVES?
1868 003660 001406      BEQ     8$          ;NO--BRANCH
1869 003662 104401 003670      TYPE     69$        ;:TYPE ASCIZ STRING
1870 003666 000401      BR       68$        ;:GET OVER THE ASCIZ
1871      ;:69$: .ASCIZ " "
1872 003672      68$:          ;
1873 003672 005200      7$: INC      R0          ;INCREMENT DRIVE NUMBER
1874 003674 000761      BR       6$          ;
1875 003676 013737 007656 007650  8$: MOV      @#SENDCT, @#SEOPCT
1876 003704 005037 001246      RSTRT1: CLR     CHKDRV ;INIT. THE CHECK DRIVE KEY
1877 003710 012737 000001 001250  MOV      #1, DRVMSK ;START TO CHECK DESIRED DRIVES
1878 003716 033737 001250 001232  BIT      DRVMSK, DRVSEL ;IS THIS DRIVE SELECTED?
1879 003724 001011      RSTRT3: BNE     DRVOK ;YES--GO CHECK IF DRIVE IS READY FOR TESTING
1880 003726 005237 001246      RESTART: INC     CHKDRV ;MOVE TO NEXT DRIVE NUMBER

```



```

1881 003732 106337 001250 ASLB DRVMSK : POSITION THE MASK
1882 003736 103767 BCC RSTAT2 : BR IF MORE DRIVES
1883 003740 043737 001252 001232 BIC DRVBA0,DRVSEL : CLEAR SELECTION BITS FOR ANY OFFLINE/UNSAFE
1884 : DRIVES
1885 003746 000756 BR RSTAT1 : CONTINUE WITH CYCLE
1886 003750 013702 001246 DRVOK: MOV J0CHKDRV,R2 : PICKUP THE DRIVE NUMBER
1887 003754 110237 001365 MOVB R2,DPB+1 : LOAD DRIVE NUMBER
1888 003760 104401 003766 TYPE 658 : TYPE ASCIZ STRING
1889 003764 000411 BR 648 : GET OVER THE ASCIZ
1890 : :658: .ASCIZ <15><12><12> TESTING DRIVE /
1891 : 648:
1892 004010 MOV R2,-(SP) : SAVE R2 FOR TYPEOUT
1893 004010 010246 TYPOS : GO TYPE--OCTAL ASCII
1894 004012 104403 .BYTE 1 : TYPE 1 DIGIT(S)
1895 004014 001 .BYTE 0 : SUPPRESS LEADING ZEROS
1896 004015 00C
1897 004016 104401 001217 TYPE $CALF
1898 004022 013700 001266 MOV RPAOR,R0 : RPII ADDRESS
1899 004026 016037 000C12 001254 MOV RPCA(R0),CYL,CR : INITIALIZE CURRENT STORAGE

```

1899
1900
1901

.SBTTL 0000 TESTS 0000

*IN THE DESCRIPTIONS OF THE BELOW TESTS THE VARIABLES USED
*AND THEIR DEFAULT VALUES (UNLESS SPECIFIED OTHERWISE) ARE:

*MNEMONIC	VALUE	VARIABLE
*R	1	ITERATIONS (REPEATS)
*FC	0	FIRST CYLINDER ADDRESS
*LC	410	LAST CYLINDER ADDRESS
*IC	1	INCREMENT VALUE
*NC OR NC1	FC+IC	NEW OR MODIFIED CYLINDER ADDRESS
*NC2	LC-IC	NEW OR MODIFIED CYLINDER ADDRESS
*TK	C	TRACK ADDRESS

1902
1903
1904
1905
1906
1907
1908
1909
1910
1911
1912
1913
1914
1915
1916
1917
1918
1919
1920
1921
1922
1923
1924
1925

*TEST 0 HOME SEEK TEST

* THIS TEST WILL CAUSE THE DRIVE TO EXECUTE A HOME SEEK
* COMMAND CYCLE. AT THE COMPLETION OF THE COMMAND THE
* STATUS INDICATORS ARE CHECKED TO VERIFY THAT NO ERRORS
* HAVE OCCURED.
* THIS TEST IS REPEATED 100 TIMES.

*STO:

004034	033737	001324	001234	BIT	2#BITS+(0*2),TSTNMS ;DO THIS TEST?
004034	001002			BNE	64\$:YES--BRANCH
004042	000137	004156		JMP	TST1 :NO--GO TO THE NEXT TEST
004050	013737	001634	001206	MOV	2#RPT0,\$TIMES ;GET THE ITERATION COUNT
004056	012737	004144	001106	MOV	#TEST0,2#SLPADR
004064	012737	004034	001110	MOV	#TST0,2#SLPERR ;SETUP THE ERROR LOOP ADDRESS
004072	012737	000000	001102	MOV	#0,2#TSTNM ;SET UP TEST NUMBER AND
004100	013777	001102	175034	MOV	\$TSTNM,DISP ;CLEAR THE ERROR FLAG (SERFL)
004106	012737	004154	001244	MOV	#EXIT0,BYPASS ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
004114	013700	001266		MOV	RADR,R0 ;SETUP BYPASS ADDRESS
004120	112737	000015	001364	MOV.B	#HOMSEK,DPB ;RPII ADDRESS
004126	005037	001366		CLR	DPB+2 ;LOAD HOME SEEK OPCODE
004132	005037	001370		CLR	CPE+4 ;CYL ADDR ZERO
					;CLEAR TRACK SECTOR STORAGE

1955	007136	113737	001636	001371
1956	007144	012706	001100	
1957	007150	004737	014036	
1958	007154	000004		

```

TESTO:  MOV      TK0,DPB+5      ;LOAD USER SPECIFIED TRACK
        MOV      #STACK,SP      ;SET UP STACK POINTER
EXITO:  JSR      PC,SEEKS        ;DO THE SPECIFIED SEEK
        SCOPE                    ;LOOP

```

```

*****
*TEST 1      SEEK/SEEK TEST

```

```

* THIS TEST WILL CAUSE THE DRIVE TO EXECUTE A FORWARD SEEK
* CYCLE TO "LC" "LT" "LS" FOLLOWED BY A REVERSE SEEK CYCLE TO
* "FC" "FT" "FS". AT THE COMPLETION OF EACH SEEK, THE PROPER
* INDICATORS ARE EXAMINED TO INSURE PROPER OPERATION.

```

1960				
1961				
1962				
1963				
1964				
1965				
1966				
1967				
1968				
1969	007156			
1970	007156	033737	001326	001234
1971	007164	001002		
1972	007166	000137	004314	
1973	007170	013737	001642	001206
1974	007172	012737	004262	001106
1975	007176	012737	004156	001110
1976	007174	012737	000001	001102
1977				
1978	007222	013777	001102	174712
1979	007230	012737	004312	001244
1980	007236	013700	001266	
1981	007242	112737	000011	001364
1982	007250	005037	001370	
1983	007254	113737	001652	001371
1984	007262	012706	001100	
1985	007266	013737	001644	001366
1986	007274	004737	014036	
1987	007300	013737	001646	001366
1988	007306	004737	014036	
1989	007312	000004		
1990				
1991				
1992				
1993				
1994				
1995				
1996				
1997				
1998				
1999				
2000				
2001				
2002				
2003				
2004	004314			
2005	004314	033737	001330	001234
2006	004322	001002		
2007	004324	000137	004506	
2008	004330	013737	001656	001206
2009	004336	012737	004420	001106
2010	004344	012737	004314	001110

```

*ST1:
      BIT      2#BITS+(1*2),TSTNMS ;DO THIS TEST*
      BNE     64$                    ;YES--BRANCH
      JMP     TST2                    ;NO--GO TO THE NEXT TEST
64$:  MOV      2#RPT1,$TIMES          ;GET THE ITERATION COUNT
      MOV      #TEST1,$SLPADR        ;SETUP THE ERROR LOOP ADDRESS
      MOV      #TST1,$SLPERR        ;SETUP TEST NUMBER AND
      MOV      #1,$TSTNM             ;CLEAR THE ERROR FLAG (SERFLG)
      MOV      $TSTNM,$DISPLAY       ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
      MOV      #EXIT1,$BYPASS        ;SETUP BYPASS ADDRESS
      MOV      #RPADR,$R0            ;RP11 ADDRESS
      MOV      #SEEK,$DPB            ;LOAD SEEK OPCODE
      CLR     DPB+4                  ;CLEAR SECTOR/TRACK ADDRESS
      MOV      TK1,DPB+5             ;LOAD USER SUPPLIED TRACK ADDRESS
TEST1: MOV      #STACK,SP           ;SET THE STACK POINTER
      MOV      FC1,DPB+2            ;STARTING CYLINDER
      JSR     PC,SEEKS              ;SEEK TO FC
      MOV      LC1,DPB+2            ;ENDING CYLINDER
      JSR     PC,SEEKS              ;SEEK TO LC
EXIT1: SCOPE                        ;LOOP

```

```

*****
*TEST 2      INCREMENTAL SEEK TEST

```

```

* THIS TEST WILL COMMAND FORWARD SEEK CYCLES TO ADVANCE THE
* CYLINDER ADDRESS FROM "FC" TO "LC" BY THE INCREMENT "IC".
* WHEN THE RESULTANT CYLINDER ADDRESS (NC) EXCEEDS
* "LC" REVERSE SEEK CYCLES ARE INITIATED, STARTING
* AT THE LAST LEGAL "NC" AND DECREMENTING BY "IC"
* UNTIL "NC" IS LESS THAN "FC". AT THE COMPLETION OF EACH
* SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO
* INSURE PROPER OPERATION.

```

2004	004314			
2005	004314	033737	001330	001234
2006	004322	001002		
2007	004324	000137	004506	
2008	004330	013737	001656	001206
2009	004336	012737	004420	001106
2010	004344	012737	004314	001110

```

*ST2:
      BIT      2#BITS+(2*2),TSTNMS ;DO THIS TEST*
      BNE     64$                    ;YES--BRANCH
      JMP     TST3                    ;NO--GO TO THE NEXT TEST
64$:  MOV      2#RPT2,$TIMES          ;GET THE ITERATION COUNT
      MOV      #TEST2,$SLPADR        ;SETUP THE ERROR LOOP ADDRESS
      MOV      #TST2,$SLPERR

```

E04

MO-11-DZRP2-C, RPI1E DRIVE POSITIONING TEST
DZRP2C.P11 06-SEP-77 16:08 T2

MACY1: 30(1046) 06-SEP-77 16:32 PAGE 44
INCREMENTAL SEEK TEST

SEG 0043

```

2011 004352 012737 000002 001102 MOV      #2, #STSTNM      ;SET UP TEST NUMBER AND
2012                                ;CLEAR THE ERROR FLAG (SERFLG)
2013 004360 013777 001102 174554 MOV      $STNM, $DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
2014 004366 012737 004504 001244 MOV      #EXIT2, BYPASS ;SETUP BYPASS ADDRESS
2015 004374 013700 001266 001364 MOV      RPAR, R0       ;RPI1 ADDRESS
2016 004380 112737 000011 001364 MOVVB   #SEEK, DPB      ;LOAD SEEK OPCODE
2017 004386 005037 001370 001364 CLR      DPB+4          ;CLEAR SECTOR/TRACK ADDRESS
2018 004392 113737 001666 001371 MOVVB   TK2, DPB+5     ;LOAD USER SUPPLIED TRACK ADDRESS
2019 004398 012706 001100 001366 TEST2:  MOV      #STACK, SP ;SET UP THE STACK POINTER
2020 004404 013737 001660 001366 MOV      FC2, DPB+2    ;STARTING CYLINDER
2021 004410 004737 014036 001366 INCSK:  JSR      PC, SEEKS ;SEEK TO FC
2022 004416 063737 001664 001366 ADD      IC2, DPB+2    ;MOVE TO NEXT CYLINDER
2023 004422 023737 001662 001366 CMP      LC2, DPB+2   ;OUT OF CYLINDERS?
2024 004428 002367 001662 001366 BGE     INCSK        ;NO--BRANCH
2025 004434 013737 001662 001366 MOV      LC2, DPB+2   ;LOAD LC
2026 004440 004737 014036 001366 DECSK:  JSR      PC, SEEKS ;SEEK TO LC
2027 004446 163737 001664 001366 SUB      IC2, DPB+2
2028 004452 023737 001660 001366 CMP      FC2, DPB+2
2029 004502 003767 001660 001366 BLE     DECSK
2030 004504 000004 000004 001366 EXIT2:  SCOPE          ;LOOP
2031
2032 *****
2033 :*TEST 3 STEPPING SEEK TEST
2034
2035 :* THIS TEST WILL COMMAND SEEK CYCLES TO CYLINDER 0,1,2,4,
2036 :* 8, 16, 32, 64, AND 128 (AND 256 IF HW RPO3) AT THE
2037 :* COMPLETION OF EACH SEEK COMMAND, THE PROPER INDICATORS ARE
2038 :* EXAMINED TO VERIFY PROPER OPERATION.
2039
2040 *****
2041 TEST3:
2042 004506 033737 001332 001234 BIT      #BITS+(3*2), TSTNMS ;DO THIS TEST?
2043 004514 001002 001332 001234 BNE     64$             ;YES--BRANCH
2044 004516 000137 004656 001234 JMP     TST4           ;NO--GO TO THE NEXT TEST
2045 004522 013737 001672 001206 64$:  MOV      #RPT3, $TIMES ;GET THE ITERATION COUNT
2046 004530 012737 004612 001106 MOV      #TEST3, #LPAOR ;SETUP THE ERROR LOOP ADDRESS
2047 004536 012737 004506 001110 MOV      #TST3, #LPERA  ;SET UP TEST NUMBER AND
2048 004544 012737 000003 001102 MOV      #3, #STSTNM   ;CLEAR THE ERROR FLAG (SERFLG)
2049
2050 004552 013777 001102 174362 MOV      $STNM, $DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
2051 004560 012737 004654 001244 MOV      #EXIT3, BYPASS ;SETUP BYPASS ADDRESS
2052 004566 013700 001266 001364 MOV      RPAR, R0       ;RPI1 ADDRESS
2053 004572 112737 000011 001364 MOVVB   #SEEK, DPB      ;LOAD SEEK OPCODE
2054 004600 005037 001370 001364 CLR      DPB+4          ;CLEAR SECTOR/TRACK ADDRESS
2055 004604 113737 001702 001371 MOVVB   TK3, DPB+5     ;LOAD USER SUPPLIED TRACK ADDRESS
2056 004612 012706 001100 001366 TEST3:  MOV      #STACK, SP ;SET UP THE STACK
2057 004616 013737 001674 001366 MOV      FC3, DPB+2    ;FC
2058 004624 004737 014036 001366 JSR      PC, SEEKS    ;SEEK TO FC
2059 004630 013701 001700 001366 MOV      IC3, R1       ;CYLINDER 1
2060 004634 010137 001366 1$:  MOV      R1, DPB+2    ;DESIRED CYLINDER
2061 004640 004737 014036 JSR      PC, SEEKS    ;SEEK TO NC
2062 004644 006301 001366 ASL     R1             ;MOVE TO NEXT CYLINDER
2063 004646 020137 001676 001366 CMP      R1, LC3      ;DONE?
2064 004652 003770 001366 BLE     1$            ;NO--LOOP
2065 004654 000004 000004 001366 EXIT3:  SCOPE
2066

```

F04

MD-11-DZRP2-C, RPIIE DRIVE POSITIONING TEST
DZRP2C.P11 06-SEP-77 16:08

MACY11 30(1046) 06-SEP-77 16:32 PAGE 45
OSCILLATING SEEK TEST

SEQ 0044

2067
2068
2069
2070
2071
2072
2073
2074
2075
2076
2077
2078
2079
2080
2081
2082
2083
2084
2085
2086
2087
2088
2089
2090
2091
2092
2093
2094
2095
2096
2097
2098
2099
2100
2101
2102
2103
2104
2105
2106
2107
2108
2109
2110
2111
2112
2113
2114
2115
2116
2117
2118
2119
2120
2121
2122

```

*****
*TEST 4      OSCILLATING SEEK TEST
*****
* THIS TEST WILL COMMAND SEEK CYCLES FROM "FC" TO "NC" AND BACK
* TO "FC". "NC" STARTS AT "FC" AND INCREMENTS BY "IC" UP TO CYLINDER
* "LC", THEN IS DECREMENTED BY "IC" BACK TO CYLINDER "FC". AT THE
* COMPLETION OF EVERY SEEK COMMAND THE PROPER INDICATORS ARE
* EXAMINED TO VERIFY PROPER OPERATION.
*****
↑ST4:
      BIT      28BITS+(4*2),TSTNMS ;DO THIS TEST?
      BNE      64$
      JMP      TST5
      MOV      28RPT4,STNMS ;GET THE ITERATION COUNT
      MOV      28TEST4,28SLPADR
      MOV      28TST4,28SLPERR ;SETUP THE ERROR LOOP ADDRESS
      MOV      28TSTN4,28TSTN4 ;SET UP TEST NUMBER AND
                               ;CLEAR THE ERROR FLAG (SERF LG)
      MOV      28STN4,28DISP4 ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
      MOV      28EXIT4,BYPASS ;SETUP BYPASS ADDRESS
      MOV      28PADR,28R0 ;RPII ADDRESS
      MOV      28SEEK,28DPB ;LOAD SEEK OPCODE
      CLR      28DPB+4 ;CLEAR SECTOR/TRACK ADDRESS
      MOV      28TK4,28DPB+5 ;LOAD USER SUPPLIED TRACK ADDRESS
      CLR      28R2 ;CLEAR STALL SWITCH (NO STALL)
      BIT      28SW1,28SWR ;STALL REQUIRED?
      BEQ      TEST4 ;NO--BRANCH
      COM      28R2 ;YES--SET SWITCH
      MOV      28STACK,28SP ;SET UP THE STACK POINTER
      MOV      28FC4,28R1 ;SET NC TO FC
      CLR      28STALLO ;START AT ZERO IF STALLS REQUIRED
      MOV      28R1,28DPB+2 ;NC
      JSR      28PC,28SEEKS ;SEEK TO NC
      TST      28R2 ;STALL?
      BEQ      28$ ;NO--BRANCH
      JSR      28R0,28STALL ;YES--GO TO STALL ROUTINE
      .WORD   28STALLO ;TIME POINTER
      MOV      28FC4,28DPB+2 ;FC
      JSR      28PC,28SEEKS ;SEEK TO FC
      TST      28R2 ;STALL?
      BEQ      28$ ;NO--BRANCH
      JSR      28R0,28STALL ;YES--GO TO STALL ROUTINE
      .WORD   28STALLO ;TIME POINTER
      INC      28STALLO ;UPDATE THE TIME
      CMP      28MXSTAL,28STALLO ;TIME TO BIG?
      BGT      1$ ;NO--BRANCH
      CLR      28STALLO ;YES--START OVER AT ZERO
      ADD      28IC4,28R1 ;MOVE TO NEXT CYLINDER
      CMP      28R1,28LC4 ;LAST CYLINDER COMPLETED?
      BLE     1$ ;NO--BRANCH
      MOV      28LC4,28R1 ;SET NC TO LC
      MOV      28R1,28DPB+2 ;NC
      JSR      28PC,28SEEKS ;SEEK TO NC
      TST      28R2 ;STALL?
      BEQ      28$ ;NO--BRANCH

```

```

123 005132 004037 015576 JSR RO STALL ;YES--GO TO STALL ROUTINE
124 005136 001274 .WORD STALLO ;TIME POINTER
125 005140 013737 001712 001366 55: MOV LC4,DPB+2 ;LC
126 005146 004737 014036 JSR PC,SEEKS ;SEEK TO LC
127 005152 005702 TST R2 ;STALL?
128 005158 001413 BFG 65 ;NO--BRANCH
129 005156 004037 015576 JSR RO STALL ;YES--GO TO STALL ROUTINE
130 005162 001274 .WORD STALLO ;TIME POINTER
131 005164 005237 001274 INC STALLO ;UPDATE STALL TIME
132 005170 023737 001302 001274 CMP MXSTAL,STALLO ;TIME TOO BIG?
133 005176 003347 BGT 48 ;NO--BRANCH
134 005200 005037 001274 CLR STALLO ;YES--SET STALL TIME BACK TO ZERO
135 005204 163701 001714 65: SUB IC4,R1 ;NEXT CYLINDER
136 005210 020137 001710 CMP R1,FC4 ;DONE?
137 005214 002373 BGE 65 ;NO--BRANCH
138 005216 000004 EXIT4: SCOPE ;LOOP

```

```

*****
*TEST 5 CONVERGING/DIVERGING SEEK TEST

```

```

* THIS TEST WILL CAUSE THE DRIVE TO EXECUTE FORWARD AND REVERSE
* SEEKS FROM "NC1" AND "NC2" RESPECTIVELY, "NC1" WILL BE INCREMENTED
* BY "IC" AND "NC2" WILL BE DECREMENTED BY "IC" UNTIL "NC1" IS
* GREATER THAN THE INITIAL VALUE OF "NC2" AND "NC2" IS
* LESS THAN THE INITIAL VALUE OF "NC1". AT THE COMPLETION OF
* EACH SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO
* VERIFY PROPER OPERATION. "NC1" AND "NC2" DEFAULT TO
* "FC" AND "LC" RESPECTIVELY.

```

```

154 005220 033737 001336 001234 TEST5: BIT 2#BITS+(5*2),TSTNMS ;DO THIS TEST?
155 005226 001002 BNE 645 ;YES--BRANCH
156 005230 000137 005406 JMP TST6 ;NO--GO TO THE NEXT TEST
157 005234 013737 001722 001206 645: MOV 2#RPTS,STNMS ;GET THE ITERATION COUNT
158 005242 012737 005324 001106 MOV #TEST5,#SLPADR
159 005250 012737 005220 001110 MOV #TEST5,#SLPERR ;SETUP THE ERROR LOOP ADDRESS
160 005256 012737 000005 001102 MOV #5,2#STSTNM ;SET UP TEST NUMBER AND
161 ;CLEAR THE ERROR FLAG (SERFLG)
162 005264 013777 001102 173650 MOV $STNM,2#DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
163 005272 012737 005404 001244 MOV #EXITS,BYPASS ;SETUP BYPASS ADDRESS
164 005300 013700 001266 MOV RPADR,RO ;RPLI ADDRESS
165 005304 112737 000011 001364 MOVB #SEEK,DPB ;LOAD SEEK OPCODE
166 005312 005037 001370 CLR DPB+4 ;CLEAR SECTOR TRACK ADDRESS
167 005316 113737 001732 001371 MOVB TKS,DPB+5 ;LOAD USER SUPPLIED TRACK ADDRESS
168 005324 012706 001100 TESTS: MOV #STACK,SP
169 005330 013701 001724 MOV FCS,R1 ;START NC1 AT FC
170 005334 013702 001726 MOV LCS,R2 ;START NC2 AT LC
171 005340 010137 001366 15: MOV R1,DPB+2 ;NC1
172 005344 004737 014036 JSR PC,SEEKS ;SEEK TO NC1
173 005350 010237 001366 MOV R2,DPB+2 ;NC2
174 005354 004737 014036 JSR PC,SEEKS ;SEEK TO NC1
175 005360 063701 001730 ADD ICS,R1 ;NEXT NC1
176 005364 163702 001730 SUB ICS,R2 ;NEXT NC2
177 005370 020137 001726 CMP R1,LCS ;DONE?
178 005374 003003 BGT EXITS ;YES--BRANCH

```

H04

MO-11-DZRP2-C. RP11E DRIVE POSITIONING TEST
DZRP2C.P11 06-SEP-77 16:08

MACY11 30(1046) 06-SEP-77 16:32 PAGE 47
CONVERGING DIVERGING SEEK TEST

SEG 004E

2179 005376 020237 001724
2180 005402 002356
2181 005404 000004

CMP R2,FC5 ;?
BGE 15 ;NO--BRANCH
EXITS: SCOPE ;LOOP

: *TEST 6 SERVO ADDRESSING LOGIC NOISE GENERATOR

: * IN THIS TEST A SEEK IS DONE TO CYL "NC" THEN A SEEK TO
: * NC+4 THEN NC+1 THEN NC+3 THEN NC+2 THEN NC+5. NOW "NC" IS UPDATED
: * BY "IC" AND THE ABOVE SEQUENCE IS REPEATED UNTIL "LC" IS
: * EXCEEDED BY ANY OF THE ABOVE VALUES. THE INITIAL VALUE OF "NC"
: * IS "FC" AT THE COMPLETION OF EACH SEEK COMMAND THE
: * PROPER INDICATORS ARE EXAMINED TO INSURE PROPER OPERATION.

2194 005406
2195 005406 033737 001340 001234
2196 005414 001002
2197 005416 000137 005640
2198 005422 013737 001736 001206
2199 005430 012737 005512 001106
2200 005436 012737 005406 001110
2201 005444 012737 000006 001102
2202
2203 005452 013777 001102 173462
2204 005460 012737 005636 001244
2205 005466 013700 001266
2206 005472 112737 000011 001364
2207 005500 005037 001370
2208 005504 113737 001746 001371
2209 005512 012706 001100
2210 005516 013701 001740
2211 005522 013702 001742
2212 005526 162702 000005
2213 005532 020102
2214 005534 003040
2215 005536 010137 001366
2216 005542 004737 014036
2217 005546 062737 000004 001366
2218 005554 004737 014036
2219 005560 162737 000003 001366
2220 005566 004737 014036
2221 005572 062737 000002 001366
2222 005600 004737 014036
2223 005604 162737 000001 001366
2224 005612 004737 014036
2225 005616 062737 000003 001366
2226 005624 004737 014036
2227 005630 063701 001744
2228 005634 000736
2229 005636 000204

TEST6: BIT 2#BITS+(6*2),TSTNMS ;DO THIS TEST?
BNE 64\$;YES--BRANCH
JMP TST7 ;NO--GO TO THE NEXT TEST
64\$: MOV 2#RPT6,\$TIMES ;GET THE ITERATION COUNT
MOV 2#TEST6,2#SLPADR
MOV 2#TST6,2#SLPERR ;SETUP THE ERROR LOOP ADDRESS
MOV 2#6,2#TSTNMS ;SET UP TEST NUMBER AND
;CLEAR THE ERROR FLAG (SERFLG)
MOV 2#TSTNMS,2#DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
;SETUP BYPASS ADDRESS
MOV 2#RPT6,2#RPT6 ;RP11 ADDRESS
MOV 2#SEEK,2#DPB ;LOAD SEEK OPCODE
CLR 2#DPB+4 ;CLEAR SECTOR/TRACK ADDRESS
MOV 2#TK6,2#DPB+5 ;LOAD USER SUPPLIED TRACK ADDRESS
TEST6: MOV 2#STACK,2#SP ;SETUP STACK
MOV 2#FC6,2#R1 ;PICKUP "FC"
MOV 2#LC6,2#R2 ;FORM LAST CYLINDER THAT
;IS AVAILABLE FOR TESTING
SUB 2#5,2#R2 ;LAST CYLINDER
CMP 2#R1,2#R2 ;YES--BRANCH
BGT 2#EXIT6 ;NO
MOV 2#R1,2#DPB+2 ;SEEK TO NC
JSR 2#PC,2#SEEKS ;NC+4
ADD 2#4,2#DPB+2 ;SEEK TO NC+4
JSR 2#PC,2#SEEKS ;SEEK TO NC+1
SUB 2#3,2#DPB+2 ;SEEK TO NC+1
JSR 2#PC,2#SEEKS ;NC+3
ADD 2#2,2#DPB+2 ;SEEK TO NC+3
JSR 2#PC,2#SEEKS ;NC+2
SUB 2#1,2#DPB+2 ;SEEK TO NC+2
JSR 2#PC,2#SEEKS ;NC+5
ADD 2#3,2#DPB+2 ;SEEK TO NC+5
JSR 2#PC,2#SEEKS ;SEEK TO NC+5
BR 2#15
EXIT6: SCOPE ;LOOP

: *TEST 7 CYLINDER ADDRESSING TEST

: * THIS TEST WILL CAUSE THE DRIVE TO SEEK FROM EACH CYLINDER TO EVERY

OTHER CYLINDER BETWEEN CYLINDERS "FC" AND "LC". SEEK CYCLES ARE
COMMANDED FROM CYLINDER "NC" TO CYLINDER "NC1" AND BACK TO CYLINDER
"NC". "NC" AND "NC1" START AT "FC". "NC1" IS INCREMENTED BY "IC"
UNTIL "NC1" IS EQUAL TO "LC". WHEN "NC1" IS EQUAL TO "LC", IT IS
RESET TO "FC" AND "NC" IS INCREMENTED BY "IC". THE CYCLE IS COMPLETE
WHEN "NC" AND "NC1" BOTH EQUAL "LC". AT THE COMPLETION OF EACH
SEEK COMMAND, THE INDICATORS ARE EXAMINED TO VERIFY PROPER OPERATION.

```

TST7: BIT 2#BITS+(7*2),TSTNMS ;DO THIS TEST?
      BNE 64$ ;YES--BRANCH
      JMP TST10 ;NO--GO TO THE NEXT TEST
64$: MOV 2#RPT7,$TIMES ;GET THE ITERATION COUNT
     MOV 2#TEST7,2#SLPADR
     MOV 2#TST7,2#SLPERR ;SETUP THE ERROR LOOP ADDRESS
     MOV 2#7,2#TSTNM ;SET UP TEST NUMBER AND
                        ;CLEAR THE ERROR FLAG (SERFLG)
     MOV $TSTNM,2#DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
     MOV #EXIT7,BYPASS ;SETUP BYPASS ADDRESS
     MOV RPADR,R0 ;RP11 ADDRESS
     MOVVB #SEEK,DPB ;SETUP FOR SEEKING
     CLR DPB+4 ;CLEAR TRACK/SECTOR STORAGE
     MOVVB TK7,DPB+5 ;LOAD USER SPECIFIED TRACK ADDRESS
TEST7: MOV #STACK,SP ;LOAD STACK POINTER
      MOV FC7,R1 ;START NC AT FC
      MOV FC7,R2 ;START NC1 AT FC
1$: MOV R1,DPB+2 ;NC
   JSR PC,SEEKS ;SEEK TO NC
   MOV R2,DPB+2 ;NC1
   JSR PC,SEEKS ;SEEK TO NC1
   ADD IC7,R2 ;INCREMENT NC1
   CMP LC7,R2 ;EXCEEDED LC?
   BGE 1$ ;BR IF NOT
   MOV FC7,R2 ;RESET NC1
   ADD IC7,R1 ;INCREMENT NC
   CMP LC7,R1 ;EXCEEDED LC?
   BGE 1$ ;BR IF NOT
EXIT7: SCOPE ;LOOP

```

TEST 10 ONE CYLINDER SEEK TIMER TEST
THIS TEST PERFORMS ONE CYLINDER SEEKS FROM CYLINDER 0 TO THE
MAXIMUM CYLINDER FOR THE DRIVE (E.G. 202 FOR RP02'S AND 405 FOR
RP03'S). THE SEEK TIMES ARE MEASURED RELATIVE TO THE SECTOR
PULSES FROM THE DRIVE. THE TEST DISPLAYS THE FORWARD AND REVERSE
TIMES.

```

TST10: BIT 2#BITS+(10*2),TSTNMS ;DO THIS TEST?
      BNE 64$ ;YES--BRANCH
      JMP TST11 ;NO--GO TO THE NEXT TEST
64$: MOV 2#RPT10,$TIMES ;GET THE ITERATION COUNT
     MOV 2#TEST10,2#SLPADR

```

005640	033737	001342	001234
005640	001002		
005646	000137	006032	
005650	013737	001752	001206
005654	012737	005744	001106
005662	012737	005640	001110
005670	012737	000007	001102
005676			
005704	013777	001102	173230
005712	012737	006030	001244
005720	013700	001266	
005724	112737	000011	001364
005732	005027	001370	
005736	113737	001762	001371
005744	012706	001100	
005750	013701	001754	
005754	013702	001754	
005760	010137	001366	
005764	004737	014036	
005770	010237	001366	
005774	004737	014036	
006000	063702	001760	
006004	023702	001756	
006010	002363		
006012	013702	001754	
006016	063701	001760	
006022	023701	001756	
006026	002354		
006030	000004		
006032			
006032	033737	001344	001234
006040	001002		
006042	000137	006306	
006046	013737	001766	001206
006054	012737	006130	001106

229	006062	012737	006032	001110
229A	006062	012737	000010	001102
229B	006070	012737	000010	001102
229C	006076	013777	001102	173036
229D	006104	012737	006304	001244
229E	006112	013700	001266	
229F	006116	112737	000011	001364
229G	006124	005037	00137C	

MOV	#TST10, J#SLPERR	: SETUP THE ERROR LOOP ADDRESS
MOV	#10, J#STSTNM	: SET UP TEST NUMBER AND
		: CLEAR THE ERROR FLAG (#SERFLG)
MOV	STSTNM, JDISPLAY	: LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
MOV	#EXIT10, BYPASS	: SETUP BYPASS ADDRESS
MOV	RPADR, R0	: RP11 ADDRESS
MOVB	#SEEK, DPB	: OP CODE FOR THE TEST
CLR	DPB+4	: TRACK ADDRESS

K04

MD-11-DZRPZ-C. RP11E DRIVE POSITIONING TEST
DZRPZC.P11 06-SEP-77 16:08 T10

MACY11 30(1046) 06-SEP-77 16:32 PAGE 50
ONE CYLINDER SEEK TIMER TEST

SEG 0049

2299 J06130 012706 00110C

TEST10: MOV #STACK.SP ;RESTORE THE STACK POINTER

```

2300 006134 004737 015314 JSR PC,RESTOR ;DO A HOME SEEK
2301 006140 012704 024040 MOV #FRWSTR,R4 ;FORWARD TIME STORAGE POINTER
2302 006144 012737 000001 001366 MOV #1,DPB+2 ;SEEK TO THIS CYLINDER
2303 006152 004737 016526 15: JSR PC,TIMSEK ;START THE SEEK, AND TIME IT
2304 006156 010324 MOV R3,(R4)+ ;STORE THE TIME
2305 006160 005237 001366 INC DPB+2 ;INCREMENT THE CYLINDER ADDRESS
2306 006164 023737 001366 001236 CMP DPB+2,MAXCYL ;AT THE MAXIMUM?
2307 006172 003767 BLE 15 ;BR IF NOT
2308 006174 013737 001236 001366 MOV MAXCYL,DPB+2 ;SETUP TO SEEK BACK TO MINIMUM
2309 006202 005337 001366 DEC DPB+2 ;SEEK TO CYLINDER
2310 006206 012704 025514 MOV #RVSTR,R4 ;REVERSE TIME STORAGE POINTER
2311 006212 004737 016526 25: JSR PC,TIMSEK ;START THE SEEK, AND TIME IT
2312 006216 010324 MOV R3,(R4)+ ;STORE THE TIME
2313 006220 005337 001366 DEC DPB+2 ;DECREMENT THE CYLINDER ADDRESS
2314 006224 100372 BPL 25 ;BR IF NOT AT MINIMUM CYLINDER
2315 006226 104401 006234 TYPE 655 ;TYPE ASCIZ STRING
2316 006232 000416 BR 645 ;GET OVER THE ASCIZ
2317 ;:655: .ASCIZ <15><12><12><ONE CYLINDER SEEK TIMES/
2318 006270 645: MOV MAXCYL,35 ;NUMBER OF SEEKS PERFORMED
2319 006270 013737 001236 006302 JSR R0,SORT ;SORT AND TYPE OUT THE TIMES
2320 006276 004037 01566C 35: .WORD 0 ;NUMBER OF TIMES GOES HERE
2321 006302 000000 EXIT10: SCOPE ;LOOP?
2322 006304 000004
2323
2324 ;:*****
2325 ;*TEST 11 SEEK-SEEK TIMER TEST
2326
2327
2328 ;* THIS TEST IS A GENERAL PURPOSE TIMING TEST WHICH PERFORMS 200
2329 ;* ITERATIONS BETWEEN THE CYLINDER IN 'FC' AND THE CYLINDER IN 'LC'.
2330 ;* BOTH FORWARD AND REVERSE SEEKS ARE TIMED AND DISPLAYED. THE
2331 ;* SEEK TIMES DISPLAYED ARE RELATIVE TO THE SECTOR COUNTER.
2332 ;* 'FC' DEFAULTS TO 0; 'LC' DEFAULTS TO 'MAXCYL' (202 IF RPO2'S OR
2333 ;* 405 IF RPO3'S).
2334 ;:*****
2335 ;*ST11:
2336 006306 033737 001346 001234 BIT @#BITS+<11*2>,TSTNMS ;DO THIS TEST?
2337 006314 001002 645: JMP TST12 ;YES--BRANCH
2338 006316 000137 006620 TST12 ;NO--GO TO THE NEXT TEST
2339 006322 013737 001772 001206 645: MOV @#RPT11,$TIMES ;GET THE ITERATION COUNT
2340 006330 012737 006404 001106 MOV #TEST11,@#SLPADR
2341 006336 012737 006306 001110 MOV #TST11,@#SLPERR ;SETUP THE ERROR LOOP ADDRESS
2342 006344 012737 000011 001102 MOV #11,@#STSTNM ;SET UP TEST NUMBER AND
2343 ;CLEAR THE ERROR FLAG ($ERFLG)
2344 006352 013777 001102 172562 MOV $STSTNM,@DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
2345 006360 012737 006616 001244 MOV #EXIT11,BYPASS ;SETUP BYPASS ADDRESS
2346 006366 013700 001266 MOV RPADR,R0 ;RP11 ADDRESS
2347 006372 012737 000011 001364 MOV #SEEK,DPB ;OPCODE FOR THE TEST
2348 006400 005037 001370 CLR DPB+4 ;CLEAR THE TRACK ADDRESS STORAGE
2349 006404 012706 001100 TEST11: MOV #STACK,SP ;RESTORE THE STACK POINTER
2350 006410 004737 015314 JSR PC,RESTOR ;DO A HOME SEEK
2351 006414 012701 000311 MOV #201,R1 ;ITERATION COUNT
2352 006420 012704 025514 MOV #RVSTR,R4 ;REVERSE TIME STORAGE POINTER
2353 006424 012705 024040 MOV #FRWSTR,R5 ;FORWARD TIME STORAGE POINTER
2354 006430 013737 001774 001366 MOV FC11,DPB+2 ;POSITION THE DISK TO THE FIRST CYLINDER
2355 00643E 004737 016526 JSR PC,TIMSEK ;DO THE SEEK

```

```

2356 006442 013737 001776 001366 18: MOV LC11,DPB+2 ;TIME TO THIS CYLINDER
2357 006450 004737 016526 JSR PC,TIMSEK ;START THE SEEK AND TIME IT
2358 006454 010325 MOV R3,(R5)+ ;STORE THE TIME
2359 006456 013737 001774 001366 MOV PC11,DPB+2 ;MINIMUM CYLINDER
2360 006464 004737 016526 JSR PC,TIMSEK ;START THE SEEK AND TIME IT
2361 006470 010324 MOV R3,(R4)+ ;STORE THE TIME
2362 006472 005301 DEC R1 ;DECREMENT THE ITERATION COUNTER
2363 006474 001362 BNE 18 ;BR IF NOT FINISHED
2364 006476 104401 006504 TYPE 65$ ;TYPE ASCIZ STRING
2365 006502 000421 BR 64$ ;GET OVER THE ASCIZ
2366 ;:65$: .ASCIZ <15><12><12>/SEEK TIMES BETWEEN CYLINDERS /
2367 006546 ;64$: MOV FC11,-(SP) ;PUT STARTING CYLINDER ADDRESS ON THE STACK
2368 006546 013746 001774 JSR PC,$S820 ;CONVERT IT TO DECIMAL
2369 006552 004737 013250 JSR PC,$SUPRS ;TYPE IT
2370 006556 004737 013500 TYPE 67$ ;TYPE ASCIZ STRING
2371 006562 104401 006570 BR 66$ ;GET OVER THE ASCIZ
2372 006566 000402 ;:67$: .ASCIZ / 8 /
2373 ;66$: MOV LC11,-(SP) ;PUT ENDING CYLINDER ADDRESS ON THE STACK
2374 006574 013746 001776 JSR PC,$S820 ;CONVERT IT TO DECIMAL
2375 006600 004737 013250 JSR PC,$SUPRS ;TYPE IT
2376 006604 004737 013500 JSR RO, SORT ;TYPE THE TIMES
2377 006610 004037 015660 .WORD 200.
2378 006614 000310 EXIT11: SCOPE ;LOOP ?
2379 006616 000004
2380
2381
2382
2383 ;:*****
2384 ;*TEST 12 SEEK TIME GRAPH TEST
2385
2386 ;* THIS TEST PRODUCES TWO SEEK TIME GRAPHS. THE FIRST GRAPH IS
2387 ;* TYPED IS SWITCH <04> IS 0. THIS GRAPH IS A PLOT OF SEEK TIME
2388 ;* AGAINST CYLINDERS SEEKED TO FROM CYLINDER 0. THE CYLINDERS
2389 ;* PLOTTED ARE: 0,1,2,3,4,6,8,10,12,14,16,18,20,25...100,105...MAXCYL.
2390 ;* THE OTHER GRAPH WHICH IS PRODUCED (SWITCH <04> SET) IS TIME TO
2391 ;* SEEK TO ALL CYLINDERS FROM CYLINDER 0.
2392 ;*
2393 ;* IN BOTH SEEK GRAPHS, ONLY THE FORWARD SEEK TIMES ARE MEASURED.
2394 ;*
2395 ;* THIS TEST USES THE SECTOR COUNTER ('SOT' IN THE RP11 AS THE
2396 ;* TIME BASE FOR THE MEASUREMENTS. USE OF THE 'SOT' PROVIDES A
2397 ;* RESOLUTION OF 2.5 MS.
2398
2399 ;:*****
2400 ;*ST12: BIT @#BITS+<12*2>,TSTNMS ;DO THIS TEST?
2401 006620 033737 001350 001234 BNE 64$ ;YES--BRANCH
2402 006626 001002 JMP $EOP ;NO--GO TO THE END OF THE PROGRAM
2403 006630 000137 007474 64$: MOV @#RPT12,$TIMES ;GET THE ITERATION COUNT
2404 006634 013737 002002 001206 MOV #TEST12,@#SLPADR
2405 006642 012737 006716 001106 MOV #TST12,@#SLPERR ;SETUP THE ERROR LOOP ADDRESS
2406 006650 012737 006620 001110 MOV #12,@#$TSTNM ;SET UP TEST NUMBER AND
2407 006656 012737 000012 001102 ;CLEAR THE ERROR FLAG ($ERFLG)
2408 ;:MOV $TSTNM,@DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
2409 006664 013777 001102 172250 MOV #EXIT12,BYPASS ;SETUP BYPASS ADDRESS
2410 006672 012737 007472 001244 MOV RPADR,RO ;RP11 ADDRESS
2411 006700 013700 001266

```

```

2412 006704 112737 000011 001364
2413 006712 005037 001370
2414 006716 012706 001100
2415 006722 004737 015314
2416 006726 012704 024040
2417 006732 005001
2418 006734 005002
2419 006736 010757 001366
2420 006742 004737 016526
2421 006746 010324
2422 006750 010137 001366
2423 006754 004737 015526
2424 006760 005202
2425 006762 023702 001236
2426 006766 002363
2427
2428
2429
2430
2431 006770
2432 006770 104401 006776
2433 006774 000412
2434
2435 007022
2436 007022 104401 007030
2437 007026 000421
2438
2439 007072
2440 007072 104401 007100
2441 007076 000423
2442
2443 007146
2444 007146 104401 021473
2445 007152 032777 000020 171760
2446 007160 001064
2447
2448
2449
2450
2451 007162 005000
2452 007164 005037 024040
2453 007170 104401 001217
2454 007174 010046
2455 007176 104405
2456 007200 104401 007206
2457 007204 000401
2458
2459 007210
2460 007210 010001
2461 007212 006301
2462 007214 016103 024040
2463 007220 004737 007432
2464 007224 022700 000004
2465 007230 003402
2466 007232 005200
2467 007234 000755

```

```

MOVW #SEEK,DPB ; OPCODE FOR THE TEST
CLR DPB+4 ; CLEAR THE TRACK ADDRESS STORAGE
TEST12: MOV #STACK,SP ; INITIALIZE THE STACK POINTER
JSR PC,RESTOR ; DO A HOME SEEK
MOV #FRWSTR,R4 ; STORE 'SEEK TIME' HERE
CLR R1 ; CLEAR 'FC' STORAGE
CLR R2 ; CLEAR 'NC' STORAGE
1S: MOV R2,DPB+2 ; ADDRESS OF NEW CYLINDER 'NC'
JSR PC,TIMSEK ; SEEK TO 'NC' AND TIME IT
MOV R3,(R4)+ ; STORE MEASURED SEEK TIME
MOV R1,DPB+2 ; 'FC' ADDRESS
JSR PC,TIMSEK ; RETURN TO 'FC'
INC R2 ; INCREMENT 'NC'
CMP MAXCYL,R2 ; IS 'NC' AT MAXIMUM ?
BGE 1S ; BR IF NOT

; PLOT A GRAPH USING MEASURED SEEK TIMES
PLOT:
TYPE 65S ; TYPE ASCIZ STRING
BR 64S ; GET OVER THE ASCIZ
65S: .ASCIZ '15<<12><12>/SEEK TIME GRAPH/'
64S:
TYPE 67S ; TYPE ASCIZ STRING
BR 66S ; GET OVER THE ASCIZ
67S: .ASCIZ '<15><12>/X AXIS - SEEK TIME - MILLI SECS'
66S:
TYPE 69S ; TYPE ASCIZ STRING
BR 68S ; GET OVER THE ASCIZ
69S: .ASCIZ '<15><12>/Y AXIS - CYLINDER SEEKED FROM 0/<15><12><12>'
68S:
TYPE GRAPH1 ; TYPE THE GRAPH HEADING
BIT #SW4,SWR ; TYPE COMPLETE GRAPH?
BNE CMPGRP ; YES BRANCH; IF NOT, TYPE SMALL GRAPH

; IN THE SMALL GRAPH, SEEK TIMES ARE PLOTTED ONLY FOR SELECTED CYLINDERS.
; THE CYLINDERS PLOTTED ARE: 0,1,2,3,4,6,8,10,12,14,16,18,20,25,30,
; 35,40...100,105...MAXCYL
SMGRP: CLR R0
CLR FRWSTR ; FORCE CYL 0 - CYL 0 SEEK TO ZERO TIME
1S: TYPE SCRLF ; CR-LF
MOV R0,-(SP) ; TYPE THE MARKERS
TYPDS
TYPE 65S ; TYPE ASCIZ STRING
BR 64S ; GET OVER THE ASCIZ
65S: .ASCIZ '/'
64S:
MOV R0,R1 ; FORM THE ADDRESS OF 'SEEK TIME'
ASL R1
MOV FRWSTR(R1),R3 ; GET THE SEEK TIME
JSR PC,PLTPT ; GO PLOT IT
CMP #4,R0 ; PLOTTED UPTO CYL 4?
BLE 2S ; YES
INC R0 ; INCREMENT BY 1
BR 1S

```

```

000024
000002
001236
000007
000005
001236
000312 001236
000002
000005
007472
007332 005000
007334 012701 177773
007340 012702 024040
007344 104401 001217
007350 000404
007354 005201
007356 012701 177773
007362 010046
007364 104405
007366 000402
007370 104401 002037
007374
007400 104401 007402
000401
007404
007406 012203
007408 004737 007432
007412 104401 001217
007416 005200
007420 022700 001236
007424 001352
007426 000137 007472
007432 010546
007434 012705 000031
007440 162703 000372
007444 002404

```

```

25:  CMP      R0,R0          :PAST CYLINDER 20 ?
      BNE     R0,R0          :BR IF PAST 20
      ADD     R0,R0          :INCREMENT BY 2
35:  MOV      MAXCYL, -(SP)  :CHECK FOR END
      BIC     R7, (SP)       :CLEAR LOWER CYLINDER BITS
      ADD     R0, (SP)+, R0  :ALMOST MAX CYL
      BNE     R0,R0          :BR IF ALMOST AT MAX
      ADD     R0,R0          :INCREMENT BY 5
45:  MOV      MAXCYL, R0     :PLOTTED ALL CYLS?
      BNE     R0,R0          :BR IF DONE
      MOV     R0, 202, MAXCYL :MAXCYL = 202. ?
      BNE     R0,R0          :BR IF NOT
      ADD     R0,R0          :INCREMENT TO CYLINDER 202
55:  MOV      R0,R0          :INCREMENT TO CYLINDER 405
65:  JMP      EXIT12         :GO TO THE NEXT TEST

```

:IF SW 4 IS SET THE COMPLETE GRAPH IS PRINTED OUT. IT GIVES TIMES FOR
:SEEKS FROM CYLINDER 0 TO ALL OTHER CYLINDERS (0,1,2,3...MAXCYL).

```

CMPGRP: CLR      R0          :INITIALIZE COUNT
        MOV     R5, R1       :INITIALIZE COUNT FOR Y-AXIS MARKER
        MOV     RFRASR, R2   :INITIALIZE POINTER TO SEEK TIMES
        TYPE   $CRLF
25:    INC     R1            :TYPE OUT Y-AXIS MARKER 'CYL #'
        BNE     R1,R1       :IF REQUIRED
        MOV     R5, R1       :RESET INDEX
35:    MOV     R0, -(SP)     :TYPE 'CYL #' ON Y-AXIS
        TYPE   $CRLF        :IN DECIMAL
45:    TYPE   $BLW$6        :6 BLANKS
55:    TYPE   $65$          :TYPE ASCIZ STRING
        BR     $64$         :GET OVER THE ASCIZ
65:    ASCIZ  $--
64:    MOV     (R2)+, R3      :GET SEEK TIME
        JSR    PC, PLTPT    :GO PLOT THE POINT
        TYPE   $CRLF
        INC    R0           :ALL DONE?
        CMP    MAXCYL, R0   :LAST CYLINDER ?
        BNE    R0,R0        :IF NOT, GO BACK
65:    JMP    EXIT12        :GO TO THE NEXT TEST

```

:ROUTINE TO PLOT THE SEEK TIME ON THE GRAPH. ENTER WITH R3 CONTAINING
:THE HORIZONTAL AXIS COORDINATE (I.E. SEEK TIME).

```

PLTPT:  MOV     R5, -(SP)    :STORE R5
        MOV     R5, R5      :HORIZONTAL AXIS INDEX
15:     SUB     R5, R3       :FIND OUT HOW MANY BLANKS TO
        BLT    R5, R3       :INSERT TO PLOT THE POINT
        :NOTE THE FIRST CELL = 0 MS

```

```

007446 104401 002044
007447 005305
007448 100371
007449 104401 007464
007450 000401
007466 012605
007467 000207
007472 000004
007474
007474 104401 007502
007500 000410
007522
007522 005737 001232
007526 001434
007530 104401 007536
007534 000405
007550
007550 013746 001246
007554 104403
007556 002
007557 000
007560 104401 007566
007564 000412
007612
007612 013746 001112
007616 104402
007620 005037 001112
007624 005037 001102
007630 005037 00120E
007634 005237 001100
007640 042737 100000 00110C
007646 005327
007650 000001
007652 003027
007654 012737
007656 000001
007660 007650
007662 104401 007670
007666 000407

```

```

TYPE BLNK51 ;: BLANK
DEC R5 ;: AT THE END OF THE HORIZONTAL AXIS ?
BPL 18 ;: BR IF NOT
25:
TYPE 658 ;: TYPE ASCIZ STRING
BR 648 ;: GET OVER THE ASCIZ
658: .ASCIZ X
648: MOV (SP)+,R5 ;: RESTORE R5
RTS PC
EXIT12: SCOPE ;: LOOP ?

.SBTTL END OF PASS ROUTINE

*****
* INCREMENT THE PASS NUMBER ($PASS)
* INDICATE END-OF-PROGRAM AFTER 1 PASSES THRU THE PROGRAM
* IF THERE'S A MONITOR GO TO IT
* IF THERE ISN'T JUMP TO RESTART

SEOP:
TYPE 658 ;: TYPE ASCIZ STRING
BR 648 ;: GET OVER THE ASCIZ
658: .ASCIZ '(15)<(12)<(12)<END OF PASS'
648:
TST 2#DRVSEL ;: ANY DRIVES SELECTED?
BEQ 18 ;: NO--BRANCH
TYPE 678 ;: TYPE ASCIZ STRING
BR 668 ;: GET OVER THE ASCIZ
678: .ASCIZ ' ON DRIVE'
668:
MOV 2#CHKDRV,-(SP) ;: SAVE 2#CHKDRV FOR TYPEOUT
TYP0S ;: GO TYPE--OCTAL ASCII
.BYTE 2 ;: TYPE 2 DIGIT(S)
.BYTE 0 ;: SUPPRESS LEADING ZEROS
TYPE 698 ;: TYPE ASCIZ STRING
BR 688 ;: GET OVER THE ASCIZ
698: .ASCIZ ' ERRORS DETECTED='
688:
MOV 2#SERTTL,-(SP) ;: SAVE 2#SERTTL FOR TYPEOUT
TYP0C ;: GO TYPE--OCTAL ASCII(ALL DIGITS)
18: CLR 2#SERTTL ;: ZERO ERROR TOTAL
CLR $STINM ;: ZERO THE TEST NUMBER
CLR $TIMES ;: ZERO THE NUMBER OF ITERATIONS
INC $PASS ;: INCREMENT THE PASS NUMBER
BIC #100000,$PASS ;: DON'T ALLOW A NEG. NUMBER
DEC (PC)+ ;: LOOP?
SEOPCT: .WORD 1 ;: YES
BGT $DOAGN ;: RESTORE COUNTER
MOV (PC)+,2(PC) +
SENDCT: .WORD 1
TYPE 658 ;: TYPE ASCIZ STRING
BR 648 ;: GET OVER THE ASCIZ

```

RC-11-DTRP2-C. RPLIE DRIVE POSITIONING TEST
06-SEP-77 16:08

END OF PASS ROUTINE

```

007706 104401 007736
007706 013700 000042
007712 001405
007716 000005
007720 004710
007722 000240
007724 000240
007726 000240
007728 000240
007730 000137
007732 003726
007734 377 000
007736 007742
007742 104407
007744 105237 001103
007746 001775
007750 013777 001102 171162
007752 032777 002000 171152
007754 001402
007756 104401 001212
007758 005237 001112
010000 011637 001116
010004 162737 000002 001116
010012 117737 171100 001114
010020 032777 020000 171112
010026 001004
010030 004737 010114
010034 104401 001217
010040
010044 005777 171074
010046 100002
010050 000000
010052 104407
010054 032777 001000 171060
010056 001402
010062 013716 001110
010066 005737 001210

```

```

655: .ASCIZ <15><12>/END OF TEST/
648:
$GET42: MOV $ENULL ;TYPE NULL CHARACTER
        BEQ $42,R0 ;GET MONITOR ADDRESS
        RESET $DOAGN ;BRANCH IF NO MONITOR
        ;CLEAR THE WORLD
SENDAD: JSR PC,(R0) ;GO TO MONITOR
        NOP ;SAVE ROOM
        NOP ;FOR
        NOP ;ACT11
$DOAGN: JMP $2(PC)+ ;RETURN
$RTNAD: .WORD RESTART
$ENULL: .BYTE -1,-1,0 ;NULL CHARACTER STRING
        .EVEN

.SBTTL *** SUBROUTINES ***
.SBTTL ERROR HANDLER ROUTINE

;*****
;THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT.
;SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
;AND GO TO TYPERR ON ERROR
;THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
;SW15=1 HALT ON ERROR
;SW13=1 INHIBIT ERROR TYPEOUTS
;SW10=1 BELL ON ERROR
;SW09=1 LOOP ON ERROR
;CALL ERROR N ;:ERROR=EMT AND N=ERROR ITEM NUMBER

$ERROR:
7$: CKSWR ;:TEST FOR CHANGE IN SOFT-SWR
   INCB $ERFLG ;:SET THE ERROR FLAG
   BEQ 7$ ;:DON'T LET THE FLAG GO TO ZERO
   MOV $STNM,$DISP ;:DISPLAY TEST NUMBER AND ERROR FLAG
   BIT $BIT10,$SWR ;:BELL ON ERROR?
   BEQ 1$ ;:NO - SKIP
   TYPE $BELL ;:RING BELL
1$: INC $ERTTL ;:COUNT THE NUMBER OF ERRORS
   MOV (SP),$ERRPC ;:GET ADDRESS OF ERROR INSTRUCTION
   SUB #2,$ERRPC
   MOVB $ERRPC,$ITEMB ;:STRIP AND SAVE THE ERROR ITEM CODE
   BIT $BIT13,$SWR ;:SKIP TYPEOUT IF SET
   BNE 20$ ;:SKIP TYPEOUTS
   JSR PC,TYPERR ;:GO TO USER ERROR ROUTINE
   TYPE $CRLF

20$:
2$: TST $SWR ;:HALT ON ERROR
   BPL 3$ ;:SKIP IF CONTINUE
   HALT ;:HALT ON ERROR!
   CKSWR ;:TEST FOR CHANGE IN SOFT-SWR
3$: BIT $BIT09,$SWR ;:LOOP ON ERROR SWITCH SET?
   BEQ 4$ ;:BR IF NO
   MOV $LPERR,SP ;:FUDGE RETURN FOR LOOPING
   TEST $ESCAPE ;:CHECK FOR AN ESCAPE ADDRESS

```



```

2636 010072 001402
2637 010074 013716 001210
2638 010100
2639 010100 023737 000042 000046
2640 010106 001001
2641 010110 000000
2642 010112 000002
2654 010114 104412
2655 010116 005037 001204
2656 010122 113737 001102 001204
2657 010130 005000
2658 010132 113700 001114
2659 010136 005300
2660 010140 006300
2661 010142 006300
2662 010144 006300
2663 010146 062700 002046
2664 010152 012037 010166
2665 010156 001412
2666 010160 104401 001217
2667 010164 104401
2668 010166 000000
2669 010170 032777 000100 170742
2671 010175 001402
2672 010200 012700 023532
2673 010204 012037 010220
2674 010210 001404
2675 010212 104401 001217
2676 010216 104401
2677 010220 000000
2678 010222 012001
2679 010224 001450
2680 010226 005005
2681 010230 012000
2682 010232 012002
2683 010234 001441
2684 010236 005105
2685 010240 104401 001217
2686 010244 112003
2687 010246 112004
2688 010250 006004
2689 010252 103403
2690 010254 013146
2691 010256 104402

```

```

BEG 5$
MOV $ESCAPE, SP
5$: CMP 2042, 2046
BNE 6$
HALT
6$: RTI

```

```

:: BR IF NONE
:: FUDGE RETURN ADDRESS FOR ESCAPE
:ACT11 AUTO MODE?
:NO RETURN
:HALT ON ERROR
:RETURN

```

```

*****
SATTI TYPERR - TYPE ERROR ROUTINE
*THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE
*WHICH ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR
*TABLE" ($ERRTB), AND REPORTS THE APPROPRIATE INFORMATION
*CONCERNING THE ERROR.
CALL

```

```

JSR PC, @TYPERR
RETURN

```

```

TYPERR: SAVREG
CLR $TMPD
MOV $STNM, $TMPD
CLR R0
MOV $ITEMB, R0
DEC R0
ASL R0
ASL R0
ASL R0
1$: ADD $ERRTB, R0
MOV (R0)+, 2$
BEG 3$
TYPE , $CRLF
2$: .WORD 0
BIT $SW06, $SWR
3$: BEG 3$
MOV $ETSP, R0
MOV (R0)+, 4$
BEG 5$
TYPE , $CRLF
4$: .WORD 0
5$: MOV (R0)+, R1
BEG 20$
CLR R5
MOV (R0)+, R0
MOV (R0)+, R2
BEG 17$
COM R5
TYPE , $CRLF
10$: MOVB (R0)+, R3
MOVB (R0)+, R4
11$: ROR R4
BCS 12$
MOV @R1+, - SP
TYPDC

```

```

:SAVE R0-R5
:CLEAR LOCATION FOR TEST NUMBER
:LOAD TEST NUMBER FOR TYPEOUT
:CLEAR R0 FOR ERROR NUMBER
:ERROR NUMBER
:FORM INDEX FOR ERROR TABLE
:FORM ADDRESS
:GET ERROR MESSAGE (EM) POINTER
:BRANCH IF THERE ISN'T ONE
:"CARRIAGE RETURN - LINE FEED
:"EM" POINTER GOES HERE
:TYPE THE REGISTERS INSTEAD OF THE NORMAL
:'DH' & 'DT' LINES
:BR IF NOT
:CHANGE MESSAGE BLOCK
:PICK UP DATA HEADER 'DH' POINTER
:BRANCH IF NONE
:CARRIAGE RETURN-LINE FEED
:"DH" POINTER GOES HERE
:PICKUP DATA TABLE (DT) POINTER
:BRANCH IF NONE
:SET INDENT SWITCH
:DATA FORMAT (DF) POINTER
:NUMBER OF DH'S TO TYPE
:BRANCH IF DH NUMBER IS 0
:NO INDENT
:CARRIAGE RETURN-LINE FEED
:NUMBER OF DATA WORDS TO TYPE
:AND HOW TO TYPE THEM
:"OCTAL OR DECIMAL"
:DECIMAL--BRANCH
:SAVE @R1+ FOR TYPEOUT
:GO TYPE--OCTAL ASCII ALL DIGITS

```

2732	010260	000402		BR	13\$		
2733	010262			12\$: MOV	2(R1)+, -(SP)	:: SAVE 2(R1)+ FOR TYPEOUT	
2734	010264	013146		TYPDS		:: GO TYPE--DECIMAL ASCII WITH SIGN	
2735	010266	104405		13\$: DEC	R3	MORE NUMBERS TO TYPE?	
2736	010270	005303		BEG	14\$	NO--BRANCH	
2737	010272	001403	002043	TYPE	BLNKS2	YES--TYPE SEPARATORS	
2738	010276	000764		BR	11\$	LOOP	
2739	010300	005302		14\$: DEC	R2	MORE DH'S?	
2740	010302	003421		BLE	20\$	NO--BRANCH	
2741	010304	104401	001217	TYPE	\$CRLF	YES--START A NEW LINE	
2742	010310	005105		COM	R5	INDENT?	
2743	010312	001002		BNE	15\$	NO--BRANCH	
2744	010314	104401	002043	TYPE	BLNKS2	YES--TYPE SPACES	
2745	010320	012037	010326	15\$: MOV	(R0)+, 16\$	GET NEXT DH	
2746	010324	104401		TYPE		AND TYPE IT	
2747	010326	000000		16\$: WORD	0	DH POINTER GOES HERE	
2748	010330	104401	001217	TYPE	\$CRLF	CARRIAGE RETURN-LINE FEED	
2749	010334	005705		TST	R5	INDENT?	
2750	010336	001342		BNE	10\$	NO--BRANCH	
2751	010340	104401	002043	17\$: TYPE	BLNKS2	YES--TYPE SPACES	
2752	010344	000737		BR	10\$	LOOP	
2753	010346	104413		20\$: RESREG		RESTORE R0-R5	
2754	010350	000207		RTS	PC	RETURN	

.SBTTL TYPE ROUTINE

```

*****
*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
*NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
*NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
*NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER
*

```

```

*CALL:
*1) USING A TRAP INSTRUCTION
*   TYPE .MESADR      ;; MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
*OR
*   TYPE
*   MESADR
*

```

2736	010352	105737	001157	\$TYPE: TSTB	\$TPFLG	:: IS THERE A TERMINAL?	
2737	010356	100002		BPL	1\$	BR IF YES	
2738	010360	000000		HALT		HALT HERE IF NO TERMINAL	
2739	010362	000407		BR	3\$	LEAVE	
2740	010364	010046		1\$: MOV	R0, -(SP)	SAVE R0	
2741	010366	017600	000002	MOV	22(SP), R0	GET ADDRESS OF ASCIZ STRING	
2742	010372	112046		2\$: MOV	(R0)+, -(SP)	PUSH CHARACTER TO BE TYPED ONTO STACK	
2743	010374	001005		BNE	4\$	BR IF IT ISN'T THE TERMINATOR	
2744	010376	005726		\$+	(SP)+	IF TERMINATOR POP IT OFF THE STACK	
2745	010400	012600		60\$: MOV	(SP)+, R0	RESTORE R0	
2746	010402	062716	000002	3\$: ADD	22(SP)	ADJUST RETURN PC	
2747	010406	000002		RTI		RETURN	

H05

```

: *STYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
: *STYPOS OR STYPOC
: *CALL:
: *   MOV      NUM.-(SP)      ;; NUMBER TO BE TYPED
: *   TYPON                      ;; CALL FOR TYPEOUT
: *
: *STYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
: *CALL:
: *   MOV      NUM.-(SP)      ;; NUMBER TO BE TYPED
: *   TYPOC                      ;; CALL FOR TYPEOUT
: *
2815 010572 017646 000000          STYPOS: MOV      2(SP),-(SP)      ;; PICKUP THE MODE
2816 010576 116637 000001 011015  MOVB  1(SP),SOFILL      ;; LOAD ZERO FILL SWITCH
2817 010604 112637 011017  MOVB  (SP)+,SOMODE+1    ;; NUMBER OF DIGITS TO TYPE
2818 010610 062716 000002  ADD    #2,(SP)          ;; ADJUST RETURN ADDRESS
2819 010614 000406          BR     STYPON
2820 010616 112737 000001 011015  STYPOC: MOVB  #1,SOFILL      ;; SET THE ZERO FILL SWITCH
2821 010624 112737 000006 011017  MOVB  #6,SOMODE+1      ;; SET FOR SIX(6) DIGITS
2822 010632 112737 000005 011014  STYPON: MOVB  #5,SOCNT      ;; SET THE ITERATION COUNT
2823 010640 010346  MOV    R3, -(SP)        ;; SAVE R3
2824 010642 010446  MOV    R4, -(SP)        ;; SAVE R4
2825 010644 010546  MOV    R5, -(SP)        ;; SAVE R5
2826 010646 113704 011017  MOVB  $SOMODE+1,R4      ;; GET THE NUMBER OF DIGITS TO TYPE
2827 010652 005404  NEG    R4
2828 010654 062704 000006  ADD    #6,R4           ;; SUBTRACT IT FOR MAX. ALLOWED
2829 010660 110437 011016  MOVB  R4,SOMODE        ;; SAVE IT FOR USE
2830 010664 113704 011015  MOVB  $SOFILL,R4       ;; GET THE ZERO FILL SWITCH
2831 010670 016605 000012  MOV    12(SP),R5      ;; PICKUP THE INPUT NUMBER
2832 010674 005003  CLR    R3             ;; CLEAR THE OUTPUT WORD
2833 010676 006105          1$  ROL    R3           ;; ROTATE MSB INTO "C"
2834 010700 000404          BR     2$
2835 010702 006105          2$  ROL    R3           ;; GO DO MSB
2836 010704 006105          ROL    R3           ;; FORM THIS DIGIT
2837 010706 006105          ROL    R3
2838 010710 010503          MOV    R5,R3
2839 010712 006103          3$  ROL    R3           ;; GET LSB OF THIS DIGIT
2840 010714 105337 011016  DECB  $SOMODE          ;; TYPE THIS DIGIT?
2841 010720 100016          BR     4$             ;; BR IF NO
2842 010722 042703 177770  BIC  #177770,R3       ;; GET RID OF JUNK
2843 010726 001002          4$  BNE    5$             ;; TEST FOR 0
2844 010730 005704          ST    R4             ;; SUPPRESS THIS 0?
2845 010732 001403          BEG  5$             ;; BR IF YES
2846 010734 005204          4$  INC    R4           ;; DON'T SUPPRESS ANYMORE 0'S
2847 010736 052703 000060  BIS  #'0,R3          ;; MAKE THIS DIGIT ASCII
2848 010742 052703 000040  5$  BIS  #' ,R3          ;; MAKE ASCII IF NOT ALREADY
2849 010746 110337 011012  MOVB  R3,#$          ;; SAVE FOR TYPING
2850 010752 104401 011012  TYPE  #$$           ;; GO TYPE THIS DIGIT
2851 010756 105337 011014  7$  DECB  $SOCNT        ;; COUNT BY 1
2852 010762 003347          BGT  2$             ;; BR IF MORE TO DO
2853 010764 002402          BLT  6$             ;; BR IF DONE
2854 010766 005204          INC  R4             ;; INSURE LAST DIGIT ISN'T A BLANK
2855 010770 000744          BR  2$             ;; GO DO THE LAST DIGIT
2856 010772 012605          6$  MOV  (SP)+,R5       ;; RESTORE R5
2857 010774 012604          MOV  (SP)+,R4       ;; RESTORE R4
2858 010776 012603          MOV  (SP)+,R3       ;; RESTORE R3
2859 011000 016666 000002 000004  MOV  2(SP),4(SP)     ;; SET THE STACK FOR RETURNING

```

```

2860 011006 012616
2861 011010 000002
2862 011012 000
2863 011013 000
2864 011014 000
2865 011015 000
2866 011016 000C0C
2867
2868
2869
2870
2871
2872
2873
2874
2875
2876
2877
2878
2879
2880 011020
2881 011020 010C46
2882 011022 01014E
2883 011024 010246
2884 011026 010346
2885 011030 010546
2886 011032 012746 020200
2887 011036 016605 00002C
2888 011042 100004
2889 011044 005405
2890 011046 112766 000055 000001
2891 011054 005000
2892 011056 012703 011234
2893 011062 112723 000040
2894 011066 005002
2895 011070 016001 011224
2896 011074 160105
2897 011076 002402
2898 011100 005202
2899 011102 000774
2900 011104 060105
2901 011106 005702
2902 011110 001002
2903 011112 105716
2904 011114 100407
2905 011116 106316
2906 011120 103003
2907 011122 116663 000001 177777
2908 011130 052702 000060
2909 011134 052702 000040
2910 011140 110223
2911 011142 005720
2912 011144 020027 000010
2913 011150 002746
2914 011152 003002
2915 011154 010502

```

```

MOV (SP)+,(SP)
RTI
;; RETURN
;; STORAGE FOR ASCII DIGIT
;; TERMINATOR FOR TYPE ROUTINE
;; OCTAL DIGIT COUNTER
;; ZERO FILL SWITCH
;; NUMBER OF DIGITS TO TYPE

$OCNT: .BYTE 0
$OFILL: .BYTE 0
$OMODE: .WORD 0

.SBTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
*REPLACED WITH SPACES.
*CALL:
* MOV NU1,-(SP) ;; PUT THE BINARY NUMBER ON THE STACK
* TYPDS ;; GO TO THE ROUTINE

$TYPDS:
MOV R0,-(SP) ;; PUSH R0 ON STACK
MOV R1,-(SP) ;; PUSH R1 ON STACK
MOV R2,-(SP) ;; PUSH R2 ON STACK
MOV R3,-(SP) ;; PUSH R3 ON STACK
MOV R5,-(SP) ;; PUSH R5 ON STACK
MOV #20200,-(SP) ;; SET BLANK SWITCH AND SIGN
MOV R0,(SP),R5 ;; GET THE INPUT NUMBER
BPL 1$ ;; BR IF INPUT IS POS.
NEG R5 ;; MAKE THE BINARY NUMBER POS.
MOVB #-1,(SP) ;; MAKE THE ASCII NUMBER NEG.
CLR R0 ;; ZERO THE CONSTANTS INDEX
MOV $DBLK,R3 ;; SETUP THE OUTPUT POINTER
MOVB #,(R3)+ ;; SET THE FIRST CHARACTER TO A BLANK
CLR R2 ;; CLEAR THE BCD NUMBER
MOV $DTBL(R0),R1 ;; GET THE CONSTANT
SUB R1,R5 ;; FORM THIS BCD DIGIT
BLT 4$ ;; BR IF DONE
INC R2 ;; INCREASE THE BCD DIGIT BY 1
BR 3$

4$:
ADD R1,R5 ;; ADD BACK THE CONSTANT
TST R2 ;; CHECK IF BCD DIGIT=0
BNE 5$ ;; FALL THROUGH IF 0
TSTB (SP) ;; STILL DOING LEADING 0'S?
BMI 7$ ;; BR IF YES
ASLB (SP) ;; MSD?
BCC 6$ ;; BR IF NO
MOVB 1(SP),-1(R3) ;; YES--SET THE SIGN
BIS #0,R2 ;; MAKE THE BCD DIGIT ASCII
BIS #1,R2 ;; MAKE IT A SPACE IF NOT ALREADY A DIGIT
MOV R2,(R3)+ ;; PUT THIS CHARACTER IN THE OUTPUT BUFFER
TST (R0)+ ;; JUST INCREMENTING
CMP R0,#10 ;; CHECK THE TABLE INDEX
BLT 2$ ;; GO DO THE NEXT DIGIT
BGT 8$ ;; GO TO EXIT
MOV R5,R2 ;; GET THE LSC

```

```

2916 011156 000764
2917 011160 105726
2918 011162 100003
2919 011164 116663 177777 177776
2920 011172 105013
2921 011174 012605
2922 011176 012603
2923 011200 012602
2924 011202 012601
2925 011204 012600
2926 011206 104401 011234
2927 011212 016666 000002 000004
2928 011220 012616
2929 011222 000002
2930 011224 023420
2931 011226 001750
2932 011230 000144
2933 011232 000012
2934 011234 000004
2935
2936
2937
2938
2939
2940 011244 00000C
2941 011246 000000
2942 011250 000000
2943 011252 000001
2944 011253
2945 011254
2946
2947
2948
2949
2950
2951
2952
2953
2954
2955 011254 005037 011244
2956 011260 012737 011252 011246
2957 011266 013737 011246 011250
2958 011274 012737 011324 000060
2959 011302 012737 000200 000062
2960 011310 005777 167632
2961 011314 012777 00010C 167622
2962 011322 000207
2963
2964
2965
2966
2967
2968
2969
2970
2971 011324 117746 167616

```

```

BR 6$ :: GO CHANGE TO ASCII
BS: TSTB (SP)+ :: WAS THE LSD THE FIRST NON-ZERO
BPL 9$ :: BR IF NO
MOV -1(SP),-2(R3) :: YES--SET THE SIGN FOR TYPING
9$: CLRB (R3) :: SET THE TERMINATOR
MOV (SP)+,R5 :: POP STACK INTO R5
MOV (SP)+,R3 :: POP STACK INTO R3
MOV (SP)+,R2 :: POP STACK INTO R2
MOV (SP)+,R1 :: POP STACK INTO R1
MOV (SP)+,R0 :: POP STACK INTO R0
TYPE $DBLK :: NOW TYPE THE NUMBER
MOV 2(SP),4(SP) :: ADJUST THE STACK
MOV (SP)+,(SP)
RTI :: RETURN TO USER

$DTBL: 10000.
1000.
100.
10.

$DBLK: .BLKW 4

.SBTTL TTY INPJT ROUTINE

:*****
ENABL LSB
$TKCNT: .WORD 0 :: NUMBER OF ITEMS IN QUEUE
$TKQIN: .WORD 0 :: INPUT POINTER
$TKQOUT: .WORD 0 :: OUTPUT POINTER
$TKQSRV: .BLKB 1 :: TTY KEYBOARD QUEUE
$TKQEND=.
.EVEN

: *TK INITIALIZE ROUTINE
: *THIS ROUTINE WILL INITIALIZE THE TTY KEYBOARD INPUT QUEUE
: *SETUP THE INTERRUPT VECTOR AND TURN ON THE KEYBOARD INTERRUPT
:
: *CALL:
: * JSR PC,$TKINT
: * RETURN
:
$TKINT: CLR $TKCNT :: CLEAR COUNT OF ITEMS IN QUEUE
MOV $TKQSRV,$TKQIN :: MOVE THE STARTING ADDRESS OF THE
MOV $TKQIN,$TKQOUT :: QUEUE INTO THE INPUT & OUTPUT POINTERS.
MOV $TKQSRV,$TKQVEC :: INITIALIZE THE KEYBOARD VECTOR
MOV #200,$TKQVEC+2 :: "BR" LEVEL 4
TST $TKB :: CLEAR DONE FLAG
MOV #100,$TKS :: ENABLE TTY KEYBOARD INTERRUPT
RTS PC :: RETURN TO CALLER

: *TK SERVICE ROUTINE
: *THIS ROUTINE WILL SERVICE THE TTY KEYBOARD INTERRUPT
: *BY READING THE CHARACTER FROM THE INPUT BUFFER AND PUTTING
: *IT IN THE QUEUE.
: *IF THE CHARACTER IS A "CONTROL-C" (1C) $TKINT IS CALLED AND
: *UPON RETURN EXIT IS MADE TO THE "CONTROL-C" RESTART ADDRESS (STARTS
:
$TKSRV: MOV $TKB,-(SP) :: PICKUP THE CHARACTER

```

```

2972 011330 042716 177600 BIC #1C177 (SP) :: STRIP THE JUNK
2973 011334 021627 000003 CMP (SP), #3 :: IS IT A CONTROL C?
2974 011340 001007 BNE 15 :: BRANCH IF NO
2975 011342 104401 012463 TYPE #CNTLC :: TYPE A CONTROL-C (+C)
2976 011346 004737 011254 JSR #STKINT :: INIT THE KEYBOARD
2977 011352 005726 TST (SP)+ :: CLEAN UP STACK
2978 011354 000137 002720 JMP STARTS :: CONTROL C RESTART
2979 011360 021627 000007 15: CMP (SP), #7 :: IS IT A CONTROL G?
2980 011364 001004 BNE 25 :: BRANCH IF NO
2981 011366 022737 000176 001140 CMP #SWREG, SWR :: IS SOFT-SWR SELECTED?
2982 011374 001500 BEQ 65 :: GO TO SWR CHANGE
2983
2984 011376
2985 011376 022737 000001 011244 25: CMP #1, STKCNT :: IS THE QUEUE FULL?
2986 011404 001004 BNE 35 :: BRANCH IF NO
2987 011406 104401 001212 TYPE #BELL :: RING THE TTY BELL
2988 011412 005726 TST (SP)+ :: CLEAN CHARACTER OFF OF STACK
2989 011414 000451 BR 55 :: EXIT
2990 011416 021627 000023 35: CMP (SP), #23 :: IS IT A CONTROL-S?
2991 011422 001021 BNE 325 :: BRANCH IF NO
2992 011424 005077 167514 CLR #STKS :: DISABLE TTY KEYBOARD INTERRUPTS
2993 011430 005726 TST (SP)+ :: CLEAN CHAR OFF STACK
2994 011432 105777 167506 315: TSTB #STKS :: WAIT FOR A CHAR
2995 011436 100375 BPL 315 :: LOOP UNTIL ITS THERE
2996 011440 117746 167502 MOVB #STKB, -(SP) :: GET THE CHARACTER
2997 011444 042716 177600 BIC #1C177 (SP) :: MAKE IT 7-BIT ASCII
2998 011450 022627 000021 CMP (SP)+, #21 :: IS IT A CONTROL-Q?
2999 011454 001366 BNE 315 :: BRANCH IF NO
3000 011456 012777 000100 167460 MOV #100, #STKS :: REENABLE TTY KEYBOARD INTERRUPTS
3001 011464 000002 RTI :: RETURN
3002 011466 005237 011244 325: INC STKCNT :: COUNT THIS CHARACTER
3003 011472 021627 000140 CMP (SP), #140 :: IS IT UPPER CASE?
3004 011476 002405 BLT 45 :: BRANCH IF YES
3005 011500 021627 000175 CMP (SP), #175 :: IS IT A SPECIAL CHAR?
3006 011504 003002 BGT 45 :: BRANCH IF YES
3007 011506 042716 000040 BIC #40 (SP) :: MAKE IT UPPER CASE
3008 011512 112677 177530 45: MOVB (SP)+, #STKQIN :: AND PUT IT IN QUEUE
3009 011516 005237 011246 INC STKQIN :: UPDATE THE POINTER
3010 011522 023727 011246 011253 CMP STKQIN, #STKQEND :: GO OFF THE END?
3011 011530 001003 BNE 55 :: BRANCH IF NO
3012 011532 012737 011252 011246 MOV #STKQSRT, STKQIN :: RESET THE POINTER
3013 011540 000002 55: RTI :: RETURN
3014
3015 :: *****
3016 :: *SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
3017 :: *ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
3018 :: *SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP
3019 :: *CALL WHEN OPERATING IN TTY INTERRUPT MODE.
3020 011542 022737 000176 001140 $CKSWR: CMP #SWREG, SWR :: IS THE SOFT-SWR SELECTED
3021 011550 001124 BNE 155 :: EXIT IF NOT
3022 011552 105777 167366 TSTB #STKS :: IS A CHAR WAITING?
3023 011556 100121 BPL 155 :: IF NOT, EXIT
3024 011560 117746 167362 MOVB #STKB, -(SP) :: YES
3025 011564 042716 177600 BIC #1C177 (SP) :: MAKE IT 7-BIT ASCII
3026 011570 021627 000007 CMP (SP), #7 :: IS IT A CONTROL-G?
3027 011574 001300 BNE 25 :: IF NOT, PUT IT IN THE TTY QUEUE

```

```

3028                                     ::AND EXIT
3029
3030                                     ::*****
3031                                     ::CONTROL IS PASSED TO THIS POINT FROM EITHER THE TTY INTERRUPT SERVICE
3032                                     ::ROUTINE OR FROM THE SOFTWARE SWITCH REGISTER TRAP CALL, AS A RESULT OF A
3033                                     ::CONTROL-G BEING TYPED, AND THE SOFTWARE SWITCH REGISTER BEING SELECTED.
3034 011576 123727 001134 000001 6$: CMPB $AUTOB, #1      ::ARE WE RUNNING IN AUTO-MODE?
3035 011604 001674          : BEQ 2$              ::BRANCH IF YES
3036 011606 005726          : TST (SP)+          ::CLEAR CONTROL-G OFF STACK
3037 011610 004737 011254   : JSR PC, $TKINT      ::FLUSH THE TTY INPUT QUEUE
3038 011614 005077 167324   : CLR $TKS          ::DISABLE TTY KEYBOARD INTERRUPTS
3039 011620 112737 000001 001135 : MOVB #1, $INTAG    ::SET INTERRUPT MODE INDICATOR
3040
3041 011626 104401 012475   : TYPE $CNTLG        ::ECHO THE CONTROL-G (↑G)
3042 011632 104401 012502   : TYPE $MSWR         ::TYPE CURRENT CONTENTS
3043 011636 013746 000176   : MOV $WREG, -(SP)   ::SAVE SWREG FOR TYPEOUT
3044 011642 104402          : TYPEOC            ::GO TYPE--OCTAL ASCII(ALL DIGITS.)
3045 011644 104401 012513   : TYPE $MNEW         ::PROMPT FOR NEW SWR
3046 011650 005046          : CLR -(SP)         ::CLEAR COUNTER
3047 011652 005046          : CLR -(SP)         ::THE NEW SWR
3048 011654 105777 167264   : TSTB $TKS         ::CHAR THERE?
3049 011660 100375          : BPL 7$            ::IF NOT TRY AGAIN
3050
3051 011662 117746 167260   : MOVB $TKB, -(SP)  ::PICK UP CHAR
3052 011666 042716 177600   : BIC #↑C177, (SP)  ::MAKE IT 7-BIT ASCII
3053
3054 011672 021627 000003   : CMP (SP), #3      ::IS IT A CONTROL-C?
3055 011676 001015          : BNE 9$            ::BRANCH IF NOT
3056 011700 104401 012463   : TYPE $CNTLC        ::YES, ECHO CONTROL-C (↑C)
3057 011704 062706 000006   : ADD #6, SP        ::CLEAN UP STACK
3058 011710 123727 001135 000001 : CMPB $INTAG, #1   ::REENABLE TTY KEYBOARD INTERRUPTS?
3059 011716 001003          : BNE 8$            ::BRANCH IF NO
3060 011720 012777 000100 167216 : MOV #100, $TKS    ::ALLOW TTY KEYBOARD INTERRUPTS
3061 011726 000137 002720 8$: JMP STARTS        ::CONTROL-C RESTART
3062
3063
3064 011732 021627 000025   : CMP (SP), #25     ::IS IT A CONTROL-U?
3065 011736 001005          : BNE 10$           ::BRANCH IF NOT
3066 011740 104401 012470   : TYPE $CNTLU        ::YES, ECHO CONTROL-U (↑U)
3067 011744 062706 000006 20$: ADD #6, SP        ::IGNORE PREVIOUS INPUT
3068 011750 000737          : BR 19$            ::LET'S TRY IT AGAIN
3069
3070
3071 011752 021627 000015   : CMP (SP), #15     ::IS IT A <CR>?
3072 011756 001022          : BNE 16$           ::BRANCH IF NO
3073 011760 005766 000004   : TST 4(SP)         ::YES, IS IT THE FIRST CHAR?
3074 011764 001403          : BEQ 11$           ::BRANCH IF YES
3075 011766 016677 000002 167144 : MOV 2(SP), $SWR    ::SAVE NEW SWR
3076 011774 062706 000006 11$: ADD #6, SP        ::CLEAN UP STACK
3077 012000 104401 001217 14$: TYPE $CRLF        ::ECHO <CR> AND <LF>
3078 012004 123727 001135 000001 : CMPB $INTAG, #1   ::RE-ENABLE TTY KBD INTERRUPTS?
3079 012012 001003          : BNE 15$           ::BRANCH IF NOT
3080 012014 012777 000100 167122 : MOV #100, $TKS    ::RE-ENABLE TTY KBD INTERRUPTS
3081 012022 000002          : RTI              ::RETURN
3082 012024 004737 010522 16$: JSR PC, $TYPEC    ::ECHO CHAR
3083 012030 021627 000060   : CMP (SP), #60     ::CHAR < 0?

```



```

3084 012034 002420          BLT      18$           ;; BRANCH IF YES
3085 012036 021627 000067   CMP      (SP),#67     ;; CHAR > ??
3086 012042 003015          BGT      18$           ;; BRANCH IF YES
3087 012044 042726 000060   BIC      #60,(SP)+    ;; STRIP-OFF ASCII
3088 012050 005766 000002   TST      2(SP)        ;; IS THIS THE FIRST CHAR
3089 012054 001403          BEQ      17$           ;; BRANCH IF YES
3090 012056 006316          ASL      (SP)         ;; NO, SHIFT PRESENT
3091 012060 006316          ASL      (SP)         ;; CHAR OVER TO MAKE
3092 012062 006316          ASL      (SP)         ;; ROOM FOR NEW ONE.
3093 012064 005266 000002   17$: INC      2(SP)        ;; KEEP COUNT OF CHAR
3094 012070 056616 177776   BIS      -2(SP),(SP)  ;; SET IN NEW CHAR
3095 012074 000667          BR       7$           ;; GET THE NEXT ONE
3096 012076 104401 001216   18$: TYPE   $QUES     ;; TYPE ?(CR)(LF)
3097 012102 000720          BR       20$         ;; SIMULATE CONTROL-U
3098
3099 .DSABL  LSB
3100
3101 ..*****
3102 ..*THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
3103 ..*CALL:
3104 ..*      RDCHR          ;; GET A CHARACTER FROM THE QUEUE
3105 ..*      RETURN HERE    ;; CHARACTER IS ON THE STACK
3106 ..*                    ;; WITH PARITY BIT STRIPPED OFF
3107 ..*
3108 ..*
3109 $RDCHR: MOV      (SP),-(SP) ;; PUSH DOWN THE PC AND
3110          MOV      4(SP),2(SP) ;; THE PS
3111          CLR      4(SP)        ;; GET READY FOR A CHARACTER
3112          CLR      -(SP)        ;; PUT NEW PS ON STACK
3113          MOV      #64$,-(SP)   ;; PUT NEW PC ON STACK
3114          RTI                    ;; POP NEW PC AND PS
3115
3116 64$: TST      $TKCNT          ;; WAIT ON A CHARACTER
3117 1$: BEQ      1$             ;;
3118          DEC      $TKCNT        ;; DECREMENT THE COUNTER
3119          MOVB    $STKQOUT,4(SP) ;; GET ONE CHARACTER
3120          INC      $TKQOUT        ;; UPDATE THE POINTER
3121          CMP      $TKQOUT,#$TKQEND ;; DID IT GO OFF OF THE END?
3122          BNE      2$           ;; BRANCH IF NO
3123          MOV      #$TKQSRT,$TKQOUT ;; RESET THE POINTER
3124 2$: RTI                    ;; RETURN
3125 ..*****
3126 ..*THIS ROUTINE WILL INPUT A STRING FROM THE TTY
3127 ..*CALL:
3128 ..*      RDLIN          ;; INPUT A STRING FROM THE TTY
3129 ..*      RETURN HERE    ;; ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
3130 ..*                    ;; TERMINATOR WILL BE A BYTE, OF ALL 0'S
3131 ..*
3132 $RDLIN: MOV      R3,-(SP)      ;; SAVE R3
3133          CLR      -(SP)        ;; CLEAR THE RUBOUT KEY
3134 1$: MOV      #$TTYIN,R3        ;; GET ADDRESS
3135 2$: CMP      #$TTYIN+27.,R3    ;; BUFFER FULL?
3136          BLOS    4$           ;; BR IF YES
3137          RDCHR          ;; GO READ ONE CHARACTER FROM THE TTY
3138          MOVB    (SP)+,(R3)    ;; GET CHARACTER
3139 10$: CMPB    #177,(R3)        ;; IS IT A RUBOUT

```

```

3140 012222 001022      BNE      5$          ;; BR IF NO
3141 012224 005716      TST      (SP)       ;; IS THIS THE FIRST RUBOUT?
3142 012226 001007      BNE      6$          ;; BR IF NO
3143 012230 112737 000124 012426  MOVB     #' \, 9$   ;; TYPE A BACK SLASH
3144 012236 104401 012426  TYPE     9$
3145 012242 012716 177777  MOV      #-1, (SP)  ;; SET THE RUBOUT KEY
3146 012246 005303      DEC      R3         ;; BACKUP BY ONE
3147 012250 020327 012430  CMP      R3, #STTYIN  ;; STACK EMPTY?
3148 012254 103434      BLO     4$          ;; BR IF YES
3149 012256 111337 012426  MOVB     (R3), 9$   ;; SETUP TO TYPEOUT THE DELETED CHAR.
3150 012262 104401 012426  TYPE     9$        ;; GO TYPE
3151 012266 000746      BR      2$          ;; GO READ ANOTHER CHAR.
3152 012270 005716      TST      (SP)       ;; RUBOUT KEY SET?
3153 012272 001406      BEQ     7$          ;; BR IF NO
3154 012274 112737 000134 012426  MOVB     #' \, 9$   ;; TYPE A BACK SLASH
3155 012302 104401 012426  TYPE     9$
3156 012306 005016      CLR     (SP)       ;; CLEAR THE RUBOUT KEY
3157 012310 122713 000025 7$:  CMPB     #25, (R3)  ;; IS CHARACTER A CTRL U?
3158 012314 001003      BNE     8$          ;; BR IF NO
3159 012316 104401 012470  TYPE     $CNTLU    ;; TYPE A CONTROL "U"
3160 012322 000726      BR      1$          ;; GO START OVER
3161 012324 122713 000022 8$:  CMPB     #22, (R3)  ;; IS CHARACTER A "r"?
3162 012330 001011      BNE     3$          ;; BRANCH IF NO
3163 012332 105013      CLRB   (R3)        ;; CLEAR THE CHARACTER
3164 012334 104401 001217  TYPE     $CRLF     ;; TYPE A "CR" & "LF"
3165 012340 104401 012430  TYPE     $TTYIN    ;; TYPE THE INPUT STRING
3166 012344 000717      BR      2$          ;; GO PICKUP ANOTHER CHARACTER
3167 012346 104401 001216 4$:  TYPE     $QUES    ;; TYPE A '?'
3168 012352 000712      BR      1$          ;; CLEAR THE BUFFER AND LOOP
3169 012354 111337 012426 3$:  MOVB     (R3), 9$   ;; ECHO THE CHARACTER
3170 012360 104401 012426  TYPE     9$
3171 012364 122723 000015  CMPB     #15, (R3)+ ;; CHECK FOR RETURN
3172 012370 001305      BNE     2$          ;; LOOP IF NOT RETURN
3173 012372 105063 177777  CLRB   -1(R3)      ;; CLEAR RETURN (THE 15)
3174 012376 104401 001220  TYPE     $LF       ;; TYPE A LINE FEED
3175 012402 005726      TST     (SP)+      ;; CLEAN RUBOUT KEY FROM THE STACK
3176 012404 012603      MOV     (SP)+, R3  ;; RESTORE R3
3177 012406 011646      MOV     (SP), -(SP) ;; ADJUST THE STACK AND PUT ADDRESS OF THE
3178 012410 016666 000004 000002  MOV     4(SP), 2(SP) ;; FIRST ASCII CHARACTER ON IT
3179 012416 012766 012430 000004  MOV     #STTYIN, 4(SP)
3180 012424 000002      RTI
3181 012426 000          9$:  .BYTE   0          ;; RETURN
3182 012427 000          .BYTE   0          ;; STORAGE FOR ASCII CHAR. TO TYPE
3183 012430 000033      $TTYIN: .BLKB   27. ;; TERMINATOR
3184 012463 136 006503 000012  $CNTLC: .ASCIZ  /tC/<15><12> ;; RESERVE 27 BYTES FOR TTY INPUT
3185 012470 052536 005015 000000  $CNTLU: .ASCIZ  /tU/<15><12> ;; CONTROL "C"
3186 012475 136 006507 000012  $CNTLG: .ASCIZ  /tG/<15><12> ;; CONTROL "U"
3187 012502 005015 053523 020122  $MSWR:  .ASCIZ  <15><12> 'SWR = / ;; CONTROL "G"
3188 012510 020075 000
3189 012513 040 047040 053505  $MNEW:  .ASCIZ  / NEW = /
3190 012520 036440 000040
3191
3192 .SBTTL SCOPE HANDLER ROUTINE
3193
3194 ;; *****
3195 *THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT

```

31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100

```

012748 104407
012749 032777 040000 166404
012750 001101
012751
012752
012753
012754
012755
012756 000416
012757
012758
012759
012760
012761
012762
012763
012764
012765
012766
012767
012768
012769
012770
012771
012772
012773
012774
012775
012776
012777
012778
012779
012780
012781
012782
012783
012784
012785
012786
012787
012788
012789
012790
012791
012792
012793
012794
012795
012796
012797
012798
012799
012800
012801
012802
012803
012804
012805
012806
012807
012808
012809
012810
012811
012812
012813
012814
012815
012816
012817
012818
012819
012820
012821
012822
012823
012824
012825
012826
012827
012828
012829
012830
012831
012832
012833
012834
012835
012836
012837
012838
012839
012840
012841
012842
012843
012844
012845
012846
012847
012848
012849
012850
012851
012852
012853
012854
012855
012856
012857
012858
012859
012860
012861
012862
012863
012864
012865
012866
012867
012868
012869
012870
012871
012872
012873
012874
012875
012876
012877
012878
012879
012880
012881
012882
012883
012884
012885
012886
012887
012888
012889
012890
012891
012892
012893
012894
012895
012896
012897
012898
012899
012900
012901
012902
012903
012904
012905
012906
012907
012908
012909
012910
012911
012912
012913
012914
012915
012916
012917
012918
012919
012920
012921
012922
012923
012924
012925
012926
012927
012928
012929
012930
012931
012932
012933
012934
012935
012936
012937
012938
012939
012940
012941
012942
012943
012944
012945
012946
012947
012948
012949
012950
012951
012952
012953
012954
012955
012956
012957
012958
012959
012960
012961
012962
012963
012964
012965
012966
012967
012968
012969
012970
012971
012972
012973
012974
012975
012976
012977
012978
012979
012980
012981
012982
012983
012984
012985
012986
012987
012988
012989
012990
012991
012992
012993
012994
012995
012996
012997
012998
012999
013000

```

```

:: AND LOAD THE TEST NUMBER (STSTNM) INTO THE DISPLAY REG. DISPLAY 7:C
:: AND LOAD THE ERROR FLAG (SERFLG) INTO DISPLAY 15:08
:: THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
:: SW14=1 LOOP ON TEST
:: SW11=1 INHIBIT ITERATIONS
:: SW09=1 LOOP ON ERROR
:: CALL SCOPE ;;SCOPE=10T
SSCOPE:
18: CKSWR BIT 14, 2SWR
BNE SOVER
:: START OF CODE FOR THE XOR TESTER
$XSTR: BR 65
MOV 2ERRVEC, -(SP)
MOV 2ERRVEC, 2ERRVEC
TST 2177060
MOV (SP)+, 2ERRVEC
BR $SVLAD
55: CMP (SP)+, (SP)+
MOV (SP)+, 2ERRVEC
BR 75
65: :: END OF CODE FOR THE XOR TESTER
25: TSTB SERFLG
BEQ 35
CMPB 2ERRMAX, SERFLG
BIT 101015
BIT 032777
BGE 45
MOV 21PERR, 2LPADR
BR SOVER
45: CLRB SERFLG
CLR 2TIMES
BR 15
35: BIT 11, 2SWR
BNE 15
TST 2PASS
BEQ 15
INC 2ICNT
CMP 2TIMES, 2ICNT
BGE SOVER
15: MOV 21, 2ICNT
MOV 2MXCNT, 2TIMES
$SVLAD: INCB 2STNM
MOV (SP), 2LPADR
MOV (SP), 2LPERR
CLR 2ESCAPE
MOVB 21, 2ERRMAX
$OVER: MOV 2STNM, 2DISPLAY
RTI 2LPADR, (SP)
$MXCNT: !

```

```

:: TEST FOR CHANGE IN SOFT-SWR
:: LOOP ON PRESENT TEST?
:: YES IF SW14=1
:: IF RUNNING ON THE "XOR" TESTER CHANGE
THIS INSTRUCTION TO A "NOP" (NOP=240).
SAVE THE CONTENTS OF THE ERROR VECTOR
SET FOR TIMEOUT
TIME OUT ON XOR?
RESTORE THE ERROR VECTOR
GO TO THE NEXT TEST
CLEAR THE STACK AFTER A TIME OUT
RESTORE THE ERROR VECTOR
LOOP ON THE PRESENT TEST
TESTER
HAS AN ERROR OCCURRED?
BR IF NO
MAX. ERRORS FOR THIS TEST OCCURRED?
BR IF NO
LOOP ON ERROR?
BR IF NO
SET LOOP ADDRESS TO LAST SCOPE
ZERO THE ERROR FLAG
CLEAR THE NUMBER OF ITERATIONS TO MAKE
ESCAPE TO THE NEXT TEST
INHIBIT ITERATIONS?
BR IF YES
IF FIRST PASS OF PROGRAM
INHIBIT ITERATIONS
INCREMENT ITERATION COUNT
CHECK THE NUMBER OF ITERATIONS MADE
BR IF MORE ITERATION REQUIRED
REINITIALIZE THE ITERATION COUNTER
SET NUMBER OF ITERATIONS TO DO
COUNT TEST NUMBERS
SAVE SCOPE LOOP ADDRESS
SAVE ERROR LOOP ADDRESS
CLEAR THE ESCAPE FROM ERROR ADDRESS
ONLY ALLOW ONE (1) ERROR ON NEXT TEST
DISPLAY TEST NUMBER
FUJGE RETURN ADDRESS
FIXES P5
MAX. NUMBER OF ITERATIONS

```

SBTL SAVE AND RESTORE PO-R5 ROUTINES

3270
3271
3272
3273
3274
3275
3276
3277
3278
3279
3280
3281
3282
3283
3284
3285
3286
3287
3288
3289
3290
3291
3292
3293
3294
3295
3296
3297
3298
3299
3300
3301
3302
3303
3304
3305
3306

012756 010046
012758 010146
012760 010246
012762 010346
012764 010446
012766 010546
012770 010546
012772 016646 000022
012774 016646 000022
012776 016646 000022
013002 016646 000022
013004 016646 000022
013012 000002

:SAVE RO-R5
:CALL: SAVREG
:UPON RETURN FROM \$SAVREG THE STACK WILL LOOK LIKE:
:TOP----(+16)
: +2----(+18)
: +4----R5
: +6----R4
: +8----R3
: +10---R2
: +12---R1
: +14---R0

\$SAVREG:
MOV RO, -(SP) : PUSH RO ON STACK
MOV R1, -(SP) : PUSH R1 ON STACK
MOV R2, -(SP) : PUSH R2 ON STACK
MOV R3, -(SP) : PUSH R3 ON STACK
MOV R4, -(SP) : PUSH R4 ON STACK
MOV R5, -(SP) : PUSH R5 ON STACK
MOV SP, SP, -(SP) : SAVE PC OF MAIN FLOW
MOV SP, SP, -(SP) : SAVE PC OF MAIN FLOW
MOV SP, SP, -(SP) : SAVE PC OF CALL
RTI

013014 012666 000022
013020 012666 000022
013026 012666 000022
013032 012666 000022
013038 012605
013040 012603
013042 012602
013044 012601
013046 012600
013050 000002

:RESTORE RO-R5
:CALL: RESREG
\$RESREG:
MOV (SP)+, SP, (SP) : RESTORE PC OF CALL
MOV (SP)+, SP, (SP) : RESTORE PC OF CALL
MOV (SP)+, SP, (SP) : RESTORE PC OF MAIN FLOW
MOV (SP)+, SP, (SP) : RESTORE PC OF MAIN FLOW
MOV (SP)+, R5 : POP STACK INTO R5
MOV (SP)+, R4 : POP STACK INTO R4
MOV (SP)+, R3 : POP STACK INTO R3
MOV (SP)+, R2 : POP STACK INTO R2
MOV (SP)+, R1 : POP STACK INTO R1
MOV (SP)+, R0 : POP STACK INTO R0
RTI

.SBTTL INTEGER MULTIPLY ROUTINE

:CALL
: MOV MULTIPLIER, -(SP)
: MOV MULTIPLICAND, -(SP)
: JSR PC, \$SMULT
: RETURN : PRODUCT IS ON THE STACK
: STACK PRODUCT
: -----

NO-11-CRPP2-C. RPLLE DRIVE POSITIONING TEST MACY111 30 (1046) INTEGER MULTIPLY ROUTINE

3308 013052 010046
3309 013052 010146
3310 013054 010246
3311 013056 010346
3312 013060 005046
3313 013062 016601 000012
3314 013064 100002
3315 013066 005216
3316 013070 005401
3317 013072 016602 000014
3318 013074 100002
3319 013100 005316
3320 013104 005402
3321 013106 012746 000021
3322 013108 005000
3323 013112 103001
3324 013114 060200
3325 013116 006000
3326 013120 006001
3327 013122 005316
3328 013124 001372
3329 013126 02261E
3330 013128 001403
3331 013130 005400
3332 013132 005401
3333 013134 005600
3334 013136 005726
3335 013140 010066 000012
3336 013142 010166 000010
3337 013144 012602
3338 013146 012601
3339 013148 012600
3340 013150 000207
3341 013152
3342 013154
3343 013156
3344 013160
3345 013162
3346 013164
3347 013166
3348 013172
3349 013174
3350 013176
3351 013200 010046 000002
3352 013166 016600
3353 013172 005740
3354 013174 111000
3355 013176 006300
3356 013200 016000 01322C
3357 013204 000200
3358
3359
3360

```

: * TOP LSB'S
: * +2 MSB'S
SMULT: MOV R0, -(SP)
MOV R1, -(SP)
MOV R2, -(SP)
CLR -(SP)
BPL 12(SP), R1
INC (SP)
NEG R1
MOV R1, 14(SP), R2
BPL 28(SP)
DEC R2
NEG R2
MOV R1, 17, -(SP)
CLR R0
BCC 48
ROR R0, R0
ROR R1
DEC (SP)
BNE 55
CLR (SP), +(SP)
NEG R0
NEG R1
SBC R0
ST (SP), +
MOV R1, 12(SP)
MOV R1, 10(SP)
MOV (SP), +, R2
MOV (SP), +, R1
MOV (SP), +, R0
RTS PC

.SBTL TRAP DECODER
: *****
: *THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
: *AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
: *OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
: *GO TO THAT ROUTINE.
STRAP: MOV R0, -(SP)
MOV 2(SP), R0
TST -(R0)
MOVB (R0), R0
ASL R0
MOV STRPAD(R0), PC
RTS R0

: *THIS IS USE TO HANDLE THE "GETPRI" MACRO

```

```

: PUSH R0 ON STACK
: PUSH R1 ON STACK
: PUSH R2 ON STACK
: CLEAR THE SIGN KEY
: GET THE MULTIPLICAND
: BR IF PLUS
: SET THE SIGN KEY
: MAKE THE MULTIPLICAND POSTIVE
: GET THE MULTIPLIER
: BR IF PLUS
: UPDATE THE SIGN KEY
: MAKE THE MULTIPLIER POSTIVE
: SET THE LOOP COUNT
: SETUP FOR THE MULTIPLY LOOP
: DON'T ADD IF MULTIPLICAND = 0
: POSITION THE PARTIAL PRODUCT AND
: THE MULTIPLICAND
: HAS ALL BITS OF THE MULTIPLICAND BEEN DONE?
: BR IF NO
: SHOULD PRODUCT BE NEGATIVE?
: GO TO EXIT IF NO
: YES--SO MAKE IT SC
: CLEAR SIGN INFO. OFF OF STACK
: PUT THE PRODUCT ON THE STACK MSB'S
: LSB'S
: POP STACK INTO R2
: POP STACK INTO R1
: POP STACK INTO R0

```

33764
33765
33766
33767
33768
33769
33770
33771
33772
33773
33774
33775
33776
33777
33778
33779
33780
33781
33782
33783
33784
33785
33786
33787
33788
33789
33790
33791
33792
33793
33794
33795
33796
33797
33798
33799
33800
33801
33802
33803
33804
33805
33806
33807
33808
33809
33810
33811
33812
33813
33814
33815
33816
33817
33818
33819
33820
33821
33822
33823
33824
33825
33826
33827
33828
33829
33830
33831
33832
33833
33834
33835
33836
33837
33838
33839
33840
33841
33842
33843
33844
33845
33846
33847
33848
33849
33850
33851
33852
33853
33854
33855
33856
33857
33858
33859
33860
33861
33862
33863
33864
33865
33866
33867
33868
33869
33870
33871
33872
33873
33874
33875
33876
33877
33878
33879
33880
33881
33882
33883
33884
33885
33886
33887
33888
33889
33890
33891
33892
33893
33894
33895
33896
33897
33898
33899
33900

```
STRAP2: MOV SP, -(SP)      ;; MOVE THE PC DOWN
          MOV 4(SP), 2(SP)   ;; MOVE THE PSW DOWN
          RTI                ;; RESTORE THE PSW
```

.SBTTL TRAP TABLE

;; THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
;; BY THE "TRAP" INSTRUCTION.

ROUTINE	STARTING ADDRESS	ROUTINE NAME
STRAP2	013206	TRAP+1(104401) TTY TYPEOUT ROUTINE
\$TYPE	013222	TRAP+2(104402) TYPE OCTAL NUMBER WITH LEADING ZEROS
\$TYPOC	013224	TRAP+3(104403) TYPE OCTAL NUMBER NO LEADING ZEROS
\$TYPOS	013226	TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL
\$TYPON	013230	TRAP+5(104405) TYPE DECIMAL NUMBER WITH SIGN
\$TYPDS	013232	
\$GTSWR	013234	TRAP+6(104406) GET SOFT-SWR SETTING
\$CKSWR	013236	TRAP+7(104407) TEST FOR CHANGE IN SOFT-SWR
\$ROCHR	013240	TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
\$ROLIN	013242	TRAP+11(104411) TTY TYPEIN STRING ROUTINE
\$SAVREG	013244	TRAP+12(104412) SAVE RO-R5 ROUTINE
\$RESREG	013246	TRAP+13(104413) RESTORE RO-R5 ROUTINE

.SBTTL SINGLE LENGTH BINARY TO DECIMAL ASCIZ ROUTINE

;; *****
;; THIS ROUTINE WILL CONVERT A 16-BIT UNSIGNED BINARY NUMBER TO AN
;; UNSIGNED DECIMAL ASCIZ NUMBER.

```
;; CALL
;; MOV NUMBER, -(SP)      ;; PUT BINARY NUMBER ON THE STACK
;; JSR PC, 2($SB2D)      ;; CALL
;; RETURN                ;; ADDRESS OF THE 1ST ASCIZ CHAR. IS ON THE STACK
```

013250 016637 000002 013300
013256 012746 013300
013262 004737 013304
013266 062716 000005
013272 012666 000002
013276 000207
013300 000000 000000

```
$SB2D: MOV 2(SP), 1$      ;; SAVE BINARY NUMBER
        MOV 1$, -(SP)   ;; SET POINTER
        JSR PC, 2($SB2D) ;; CALL DOUBLE LENGTH CONVERT
        ADD 5, (SP)     ;; ONLY ALLOW FIVE CHARACTERS
        MOV (SP)+, 2(SP) ;; PICKUP POINTER
        RTS PC         ;; RETURN
1$: .WORD 0,0
```

.SBTTL DOUBLE LENGTH BINARY TO DECIMAL ASCII CONVERT ROUTINE

;; *****
;; THIS ROUTINE WILL CONVERT A 32-BIT BINARY NUMBER TO AN UNSIGNED
;; DECIMAL (ASCII) NUMBER. THE SIGN OF THE BINARY NUMBER MUST BE
;; POSITIVE.

```
;; CALL
;; MOV #PNTR, -(SP)     ;; POINTER TO LOW WORD OF BINARY NUMBER
;; JSR PC, 2($DB2D)     ;; CALL
;; RETURN              ;; THE FIRST ADDRESS OF ASCII
;; IS ON THE STACK
```


0116
0117
0118
0119
0120
0121
0122
0123
0124
0125
0126
0127
0128
0129
0130
0131
0132
0133
0134
0135
0136
0137
0138
0139
0140
0141
0142
0143
0144
0145
0146
0147
0148
0149
0150
0151
0152
0153
0154
0155
0156
0157
0158
0159
0160
0161
0162
0163
0164
0165
0166
0167
0168
0169
0170
0171
0172
0173
0174
0175
0176
0177
0178
0179
0180
0181
0182
0183
0184
0185
0186
0187
0188
0189
0190
0191
0192
0193
0194
0195
0196
0197
0198
0199
0200

013500 010046
013502 016600 000004
013506 105710
013510 001403
013512 122720 000060
013516 001773
013520 005300
013522 010037 013530
013526 104401
013530 000000
013532 012600
013534 012616
013536 000207

```

;*LEADING NUMBERS.
;*CALL
;*      MOV      #NUMADR, -(SP)    ;; FIRST ADDRESS OF ASCII STRING
;*      JSR      PC, %SSUPRS
SSUPRS: MOV      RO, -(SP)          ;; SAVE RO
        MOV      4(SP), RO        ;; PICKUP THE POINTER
1$:     TSTB     (RO)              ;; TERMINATOR?
        BEQ     2$                ;; BR IF YES
        CMPB    #'0', (RO)+      ;; IS THIS AN ASCII "0" ?
        BEQ     1$                ;; BR IF YES
2$:     DEC     RO                ;; BACKUP BY "1"
        MOV     RO, 3$           ;; SAVE FOR TYPING
        TYPE    GO, 3$           ;; GO TYPE
3$:     .WORD   0                 ;; ASCII POINTER GOES HERE
        MOV     (SP)+, RO        ;; RESTORE RO
        MOV     (SP)+, (SP)      ;; RESTORE THE STACK
        RTS     PC               ;; RETURN

```

.SBTTL RANDOM NUMBER GENERATOR ROUTINE

```

;*****
;THIS ROUTINE IS A DOUBLE PRECISION PSEUDO RANDOM NUMBER GENERATOR
;WITH A RANGE OF 0 TO 2(+33)-1.
;*CALL:
;*      JSR      PC, $RAND        ;; CALL THE ROUTINE
;*      RETURN                      ;; RETURN HERE THE RANDOM
;*                                  ;; NUMBER WILL BE IN
;*                                  ;; $HINUM, $LONUM

```

013540 010046
013542 010146
013544 010246
013546 013700 013640
013552 013701 013636
013556 012702 177771
013562 006300
013564 006101
013566 005202
013570 001374
013572 063700 013640
013576 005501
013600 063701 013636
013604 062700 001057
013610 005501
013612 062701 047401
013616 010037 013640
013622 010177 013636
013626 012602
013630 012601
013632 012600
013634 000207
013636 176543
013640 12345E

```

$RAND:  MOV      RO, -(SP)          ;; PUSH RO ON STACK
        MOV      R1, -(SP)        ;; PUSH R1 ON STACK
        MOV      R2, -(SP)        ;; PUSH R2 ON STACK
        MOV      $LONUM, RO       ;; SET RO WITH LOW
        MOV      $HINUM, R1       ;; SET R1 WITH HIGH
        MOV      #-7, R2          ;; SET SHIFT COUNT
1$:     ASL     RO                ;; SHIFT RO LEFT AND
        ROL     R1                ;; ROTATE CARRY INTO R1 AND
        INC     R2                ;; CHECK FOR DONE
        BNE     1$               ;; CONTINUE SHIFT LOOP
        ADD     $LONUM, RO        ;; ADD NUMBER TO MAKE X 129
        ADC     R1                ;; PROPOGATE CARRY
        ADD     $HINUM, R1        ;; ADD NUMBER TO MAKE X 129
        ADC     #1057, RO         ;; ADD LOW CONSTANT
        ADC     R1                ;; PROPOGATE CARRY
        ADD     #47401, R1        ;; ADD HIGH CONSTANT
        MOV     RO, $LONUM        ;; SAVE RO
        MOV     R1, $HINUM        ;; SAVE R1
        MOV     (SP)+, R2        ;; POP STACK INTO R2
        MOV     (SP)+, R1        ;; POP STACK INTO R1
        MOV     (SP)+, RO        ;; POP STACK INTO RO
        RTS     PC               ;; RETURN
$HINUM: .WORD   176543
$LONUM: .WORD   12345E

```


3532
3533
3534
3535
3536
3537
3538
3539
3540
3541
3542
3543
3544
3545
3546
3547
3548
3549
3550
3551
3552
3553
3554
3555
3556
3557
3558
3559
3560
3561
3562
3563
3564
3565
3566
3567
3568
3569
3570
3571
3572
3573
3574
3575
3576
3577
3578
3579
3580
3581
3582
3583
3584
3585
3586
3587

013642 104412
013644 013701 001270
013650 005021
013652 013711 001272
013656 005037 001240
013662 005037 001304
013666 005037 001306
013672 005037 001310
013676 005037 001312
013702 013700 001266
013706 012760 000001 000004
013714 012760 000001 000004
013722 012701 000007
013726 110160 000005
013732 032760 001000 000000
013740 001404
013742 112761 177777 001304
013750 000417
013752 032760 040000 000000
013760 001422
013762 032760 004000 000000
013770 001004
013772 032760 100000 000000
014000 001412
014002 112761 000001 001304
014010 032760 020000 000000
014016 001403
014020 156137 001314 001240
014026 005301
014030 100336
014032 104413
014034 00020

:SBTTL RPINIT - INITIALIZE THE RPII & SEE WHICH DRIVES ARE AVAILABLE
:*THIS ROUTINE CLEARS THE RPII AND DETERMINES WHICH DRIVES ARE AVAILABLE.
:*THE TABLE 'DRVSTA' IS LOADED TO REFLECT THE SYSTEM STATUS.
:CALL

JSR PC, @RPINIT
RETURN
RPINIT: SAVREG
MOV RAVEC, R1 :SAVE R0-R5
CLR (R1)+ :VECTOR ADDRESS
MOV RPPRIO, (R1) :SET INTERRUPT ADDRESS TO ZERO
CLR DRVSTYP :RPII PRIORITY
CLR DRVSTA :CLEAR DRIVE TYPE STORAGE
CLR DRVSTA+2 :SET DRIVE STATUS TO OFFLINE
CLR DRVSTA+4 :SET DRIVE STATUS TO OFFLINE
CLR DRVSTA+6 :SET DRIVE STATUS TO OFFLINE
MOV RPAOR, R0 :PUT RPII ADDRESS INTO R0
MOV #CLEAR, RPCS(R0) :CLEAR THE RPII
MOV #CLEAR, RPCS(R0) :CLEAR THE RPII AGAIN
MOV #7, R1 :'DRVSTA' TABLE INDEX
1\$: MOVB R1, RPCS+1(R0) :SELECT DRIVE
BIT #SUFU, RPDS(R0) :SEE IF DRIVE UNSAFE
BEQ 2\$:BR IF NOT UNSAFE
MOVB #-1, DRVSTA(R1) :SET INDICATOR TO 'UNSAFE'
BR 4\$:EXIT
2\$: BIT #SUOL, RPDS(R0) :IS DRIVE ONLINE ?
BEQ 5\$:BR IF NOT
BIT #SUSI, RPDS(R0) :SEEK INCOMPLETE SET ?
BNE 3\$:BR IF SET
BIT #SUDY, RPDS(R0) :IS DRIVE READY ?
BEQ 5\$:BR IF NOT
3\$: MOVB #1, DRVSTA(R1) :SET DRIVE INDICATOR TO 'ONLINE'
4\$: BIT #SURPO3, RPDS(R0) :IS THE DRIVE AN RPO3 ?
BEQ 5\$:BR IF NOT
BISB #TABIT(R1), DRVSTYP :SET RPO3 INDICATOR
5\$: DEC R1 :DECREMENT THE TABLE INDEX
BPL 1\$:BR IF NOT FINISHED
RESREG :RESTORE R0-R5
R1S PC :RETURN

:SBTTL SEEKS - INITIATE A DIRECT SEEK (OR HOME SEEK) OPERATION
:*THIS ROUTINE INITIATES A SEEK OPERATION ON THE DRIVE ADDRESSED IN
:*THE SECOND BYTE OF 'DPB'. 1 SECOND IS ALLOWED FOR THE SEEK
:*TO COMPLETE; IF THE DRIVE HAS NOT INTERRUPTED, 'AIE' IS SET
:*WITHIN THAT TIME, THE SUBSYSTEM IS RESET AND THE TESTING FOR THE
:*DRIVE IS TERMINATED.
:CALL

JSR PC, @SEEKS
RETURN
SEEKS: SAVREG
MOV RPPRIC, PSW :SAVE R0-R5
MOV RPAOR, PC :RPII PRIORITY
 :RPII BUS ADDRESS

014036 104412
014040 013737 001272 177776
014046 013700 001266

3588	014052	013746	001110			MOV	\$LPERR, -(SP)	:SAVE OLD LOOP ON ERROR ADDRESS
3589	014056	012737	014064	001110		MOV	#SEEKS0, \$LPERR	:CHANGE LOOP ON ERROR ADDRESS
3590	014064	012760	000001	000004	SEEKS0:	MOV	#CLEAR, \$RPCS(RO)	:CLEAR THE CONTROLLER
3591	014072	012760	000001	000004		MOV	#CLEAR, \$RPCS(RO)	:CLEAR THE CONTROLLER
3592	014100	113760	001365	000005		MOVB	DPB+1, \$RPCS+1(RO)	:SELECT THE DRIVE
3593	014106	013737	001366	001262		MOV	DPB+2, CYL DS	:DESIRED CYLINDER
3594	014114	013760	001366	000012		MOV	DPB+2, \$PCA(RO)	:LOAD CYLINDER ADDRESS
3595	014122	013760	001370	000014		MOV	DPB+4, \$POA(RO)	:TRACK ADDRESS
3596	014130	012777	014314	165132		MOV	#SEEKS1, \$RPVEC	:INTERRUPT RETURN
3597	014136	013760	001364	000004		MOV	DPB, \$RPCS(RO)	:START THE COMMAND
3598	014144	152760	000040	000005		BISB	#40, \$RPCS+1(RO)	:SET ATTENTION INTERRUPT ENABLE
3599	014152	005037	177776			CLR	PS	:ALLOW RP11 INTERRUPTS
3600	014156	010637	001242			MOV	SP, \$PSAV	:SAVE THE CURRENT STACK POINTER
3601	014162	012737	004704	001300		MOV	#2500, \$STALLG	:SET STALL VALUE TO 2500MS
3602	014170	004037	015572			JSR	RO, \$STALL	:WAIT THE SPECIFIED VALUE
3603	014174	001300				.WORD	\$STALLG	:STALL VALUE STORAGE
3604	014176	004737	015164			JSR	PC, \$SAVRP	:OPERATION TIMED OUT, SAVE THE REGISTERS
3605	014202	032737	001000	002004		BIT	#SUFL, \$RPDS	:DRIVE UNSAFE ?
3606	014210	001403				BNE	1\$:BR IF NOT
3607	014212	104002				ERROR	2\$:DRIVE UNSAFE
3608	014214	000137	015272			JMP	DSELECT	:DESELECT THE DRIVE
3609	014220	032737	040000	002004	1\$:	BIT	#SUOL, \$RPDS	:DRIVE STILL ONLINE ?
3610	014226	001003				BNE	2\$:BR IF IT IS
3611	014230	104010				ERROR	10	:DRIVE OFFLINE AFTER POSITIONING
3612	014232	000137	015272			JMP	DSELECT	:DESELECT THE DRIVE
3613	014236	032737	100000	002004	2\$:	BIT	#SUDY, \$RPDS	:IS THE DRIVE READY ?
3614	014244	001003				BNE	3\$:BR IF THE DRIVE IS READY
3615	014246	104016				ERROR	16	:DRIVE NOT READY AFTER POSITIONING
3616	014250	000137	015272			JMP	DSELECT	:DESELECT THE DRIVE
3617	014254	104005			3\$:	ERROR	5	:NO INTERRUPT FROM POSITIONING AFTER 1 SECOND
3618	014256	032737	000200	002010		BIT	#RDY, \$RPCS	:IS THE CONTROLLER READY ?
3619	014264	001011				BNE	4\$:BR IF IT IS
3620	014266	012760	000001	000004		MOV	#CLEAR, \$RPCS(RO)	:CLEAR THE CONTROLLER
3621	014274	012760	000001	000004		MOV	#CLEAR, \$RPCS(RO)	:CLEAR THE CONTROLLER
3622	014302	012777	000100	164634		MOV	#BIT06, \$STKS	:RESTORE THE KEYBOARD INTERRUPT ENABLE
3623	014310	000177	164730		4\$:	JMP	\$BYPASS	:TERMINATE THE PRESENT TEST
3624	014314	005037	177776		SEEKS1:	CLR	PSW	:GO BACK TO PRIORITY 0
3625	014320	013706	001242			MOV	\$PSAV, SP	:RESTORE THE STACK POINTER
3626	014324	013700	001266			MOV	\$PADR, RO	:RP11 ADDRESS
3627	014330	004737	015164			JSR	PC, \$SAVRP	:SAVE THE RP11 REGISTERS
3628	014334	032737	004000	002004		BIT	#SUSI, \$RPDS	:SEEK INCOMPLETE ?
3629	014342	001416				BNE	SEEKS2	:BR IF NOT
3630	014344	012737	014354	001210		MOV	#1\$, \$ESCAPE	:ERROR 'ESCAPE' ADDRESS
3631	014352	104015				ERROR	15	:SEEK INCOMPLETE
3632	014354	005037	001210		1\$:	CLR	\$ESCAPE	:CLEAR THE ESCAPE ADDRESS
3633	014360	004737	015314			JSR	PC, \$RESTOR	:DO A HOME SEEK TO CLEAR THE DRIVE
3634	014364	032777	001000	164546		BIT	#SW09, \$SWR	:LOOPING ON ERROR ?
3635	014372	001452				BNE	SEEKS4	:BR IF NOT
3636	014374	000177	164510			JMP	\$LPERR	:LOOP ON THE OPERATION
3637	014400	032737	100000	002010	SEEKS2:	BIT	#ERR, \$RPCS	: 'ERROR' SET ?
3638	014406	001410				BNE	1\$:BR IF NOT
3639	014410	104006				ERROR	6	:DRIVE ERROR AFTER POSITIONING
3640	014412	012760	000001	000004		MOV	#CLEAR, \$RPCS(RO)	:CLEAR THE CONTROLLER
3641	014420	012760	000001	000004		MOV	#CLEAR, \$RPCS(RO)	:CLEAR THE CONTROLLER
3642	014426	000415				BR	SEEKS3	:CHECK THE DISK'S POSITION
3643	014430	005001			1\$:	CLR	R1	:CLEAR R1

J06

MD-11-DZRP2-C. RPIIE DRIVE POSITIONING TEST
 DZRP2C.P11 06-SEP-77 16:08

MACY11 30(1046) 06-SEP-77 16:32 PAGE 75
 SEEKS - INITIATE A DIRECT SEEK (OR HOME SEEK) OPERATION

SEQ 0074

```

3644 014432 113701 001365      MOVB   DPB+1,R1      :DRIVE ADDRESS
3645 014436 136137 001314 002004    BITB   ATABIT(R1),SRPDS :ATTENTION BIT SET FOR THE DRIVE
3646 014444 001001 001001 001001    BNE   2$            :BR IF IT IS
3647 014446 104007 001001 001001    ERROR 7            :ATTENTION BIT NOT SET AFTER POSITIONING
3648 014450 023737 001366 002024 2$:   CMP   DPB+2,$SUCA    :SUCA' CORRECT ?
3649 014456 001401 001401 001401    BEQ   SEEKS3        :BR IF IT IS
3650 014460 104011 001401 001401    ERROR 11           :SUCA' NOT CORRECT
3651 014462 004737 014554 000000    JSR   PC,VERIFY     :VERIFY THE DISK'S POSITION
3652 014466 000414 000414 000414    BR    SEEKS4        :AT THE CORRECT CYLINDER
3653 014470 122737 000015 001364    CMPB  #HOMSEK,DPB   :DOING A HOME SEEK ?
3654 014476 001410 001410 001410    BEQ   SEEKS4        :BR IF YES, NO SENSE DOING A HOME SEEK AGAIN
3655 014500 004737 015314 000000    JSR   PC,RESTOR     :DO A HOME SEEK
3656 014504 032777 001000 164426    BIT   #SW09,$SWR    :LOOP ON THE OPERATION ?
3657 014512 001402 001402 001402    BEQ   SEEKS4        :BR IF NOT
3658 014514 000177 164370 000000    JMP   $LPERR        :LOOP
3659 014520 032777 000010 164412  SEEKS4: BIT   #SW03,$SWR    :STALL ?
3660 014526 001403 001403 001403    BEQ   1$            :BR IF NOT
3661 014530 004037 015576 000000    JSR   RO,STALL      :STALL
3662 014534 001276 001276 001276    .WORD STALL1        :2SMS STALL
3663 014536 016037 000024 001254 1$:   MOV   SUCA(RO),CYL.CR :CURRENT CYLINDER ADDRESS
3664 014544 012637 00111C 00111C    MOV   (SP)+,$LPERR  :RESTORE THE LOOP ON ERROR ADDRESS
3665 014550 104413 000000 000000    RESREG              :RESTORE RO-R5
3666 014552 000201 000201 000201    RTS   PC            :RETURN
  
```

```

3667
3668
3669 *****
3670 *SBTTL VERIFY - ROUTINE TO VERIFY THE POSITION AFTER A SEEK
3671 *THIS ROUTINE VERIFIES THE POSITION OF THE DRIVE AFTER A SEEK
3672 *BY READING A HEADER AT THE DESTINATION CYLINDER. THE HEADER
3673 *READ IS FROM THE SECTOR WHICH IS 2 SECTORS FROM THE ADDRESS IN
3674 *THE 'SOT' COUNTER. THE CYLINDER FIELD FROM 'DPB+2' IS COMPARED
3675 *WITH THE CYLINDER FIELD FROM THE HEADER.
3676 :CALL
  
```

```

3677 JSR   PC,VERIFY
3678 RETURN :NORMAL RETURN
3679 ERROR RETURN :CYLINDER FIELDS DID NOT COMPARE
  
```

```

3680 014554 104412 001110 001110 001110  VERIFY: SAVREG      :SAVE RO-R5
3681 014556 013746 000001 164350 000001  MOV   $LPERR,-(SP)  :SAVE THE LOOP ON ERROR ADDRESS
3682 014562 032777 000001 164350 000001  BIT   #SW0,$SWR    :CHECK POSITION ?
3683 014570 001171 001171 001171  BNE   VERIFY1      :BR IF NOT
3684 014572 012737 014600 001110 001110  MOV   #VERIFY0,$LPERR :LOOP ON ERROR ADDRESS
3685 014600 012737 177777 027172 027172  VERFY0: MOV   #-1,BUFFER+2 :CLEAR CYLINDER STORAGE
3686 014606 013700 001266 001266 001266  MOV   RPAOR,RO     :LOAD RPII ADDRESS
3687 014612 016046 000014 000014 000014  MOV   RPOA(RO),-(SP) :GET THE 'SOT'
3688 014616 042716 177417 000000 000000  BIC   #1C360,(SP)  :SAVE THE 'SOT' BITS
3689 014622 006216 006216 006216 006216  ASR   (SP)         :RIGHT JUSTIFY THE BITS
3690 014624 006216 006216 006216 006216  ASR   (SP)         :RIGHT JUSTIFY THE BITS
3691 014626 006216 006216 006216 006216  ASR   (SP)         :RIGHT JUSTIFY THE BITS
3692 014630 006216 006216 006216 006216  ASR   (SP)         :RIGHT JUSTIFY THE BITS
3693 014632 062716 000002 000002 000002  ADD   #2,(SP)      :FORM SECTOR ADDRESS FOR CHECK
3694 014636 022716 000012 000012 000012  CMP   #10,(SP)     :SEE IF THE ADDRESS OVERFLOWED
3695 014642 101005 000000 000000 000000  BHI   2$            :BR IF NOT
3696 014644 103402 000000 000000 000000  BLO   1$            :BR IF ADDR IS 11
3697 014646 00501E 000000 000000 000000  CLR   (SP)         :SET SECTOR ADDRESS TO ZERO
3698 014650 000402 000000 000000 000000  BR    2$            :CONTINUE
3699 014652 01271E 000001 000001 000001 1$:   MOV   #1,(SP)     :SET SECTOR ADDRESS TO ONE
  
```

K06

```

3700 014656 012777 015026 164404 2$: MOV #45, RRPVEC ; INTERRUPT ADDRESS
3701 014664 112637 001370 MOVB (SP)+, DPB+4 ; PUT VALUE INTO THE DPB
3702 014670 113737 001370 001260 MOVB DPB+4, SEC.RO ; SELECTED SECTOR FOR ERROR MESSAGE
3703 014676 113737 001371 001256 MOVB DPB+5, TRK.RO ; TRACK FOR ERROR MESSAGE
3704 014704 013746 001364 MOV DPB-(SP) ; SETUP RPCS LOAD VALUE
3705 014710 112716 000017 MOVB #READ (SP) ; READ COMMAND CODE
3706 014714 052716 014100 BIS #MODE!HOR:IDE, (SP) ; SET BITS FOR HEADER REAC
3707 014720 012760 177775 000006 MOV #-3, RPWC(RO) ; LOAD WORD COUNT
3708 014726 012760 027170 000010 MOV #BUFFER RPBA(RO) ; BUFFER ADDRESS
3709 014734 013760 001370 000014 MOV DPB+4, RPDA(RO) ; SECTOR ADDRESS
3710 014742 012660 000004 MOV (SP)+, RPCS(RO) ; START THE ORDER
3711 014746 005037 177776 CLR PSW ; SET PRIORITY BACK TO ZERO
3712 014752 010637 001242 MOV SP, SPSAV ; SAVE THE CURRENT STACK POINTER
3713 014756 012737 004704 001300 MOV #2500, STALLG ; SET STALL VALUE TO 2500MS
3714 014764 004037 015572 JSR RO, STALLA ; WAIT THE SPECIFIED VALUE
3715 014770 001300 . WORD STALLG ; STALL VALUE STORAGE
3716 014772 004737 015164 JSR PC, SAVRP ; STORE THE RPII REGISTERS
3717 014776 104014 ERROR 14 ; NO INTERRUPT WITHIN 1 SECOND
3718 015000 012760 000001 000004 MOV #CLEAR, RPCS(RO) ; CLEAR THE CONTROLLER
3719 015006 012760 000001 000004 MOV #CLEAR, RPCS(RO) ; CLEAR THE CONTROLLER
3720 015014 012777 000100 164122 MOV #BIT 6, STKS ; SET TTY KEYBOARD INTERRUPT ENABLE
3721 015022 000177 164216 JMP #BYPASS ; TERMINATE THE PRESENT TEST
3722 015026 005037 177776 4$: CLR PSW ; SET PRIORITY TO ZERO
3723 015032 013706 001242 MOV SPSAV, SP ; RESTORE STACK POINTER
3724 015036 004737 015164 JSR PC, SAVRP ; STORE THE RPII REGISTERS
3725 015042 013700 001266 MOV RPADR, RO ; PUT RPII ADDRESS INTO RO
3726 015046 032737 100000 002010 BIT #ERR, $RPCS ; DID THE ORDER TERMINE WITH AN ERROR
3727 015054 001410 BEQ 6$ ; BR IF NOT
3728 015056 104012 ERROR 12 ; ERROR DURING POSITIONING VERIFICATION
3729 015060 012760 000001 000004 MOV #CLEAR, RPCS(RO) ; CLEAR THE ERROR
3730 015066 012760 000001 000004 MOV #CLEAR, RPCS(RO) ; CLEAR THE CONTROLLER
3731 015074 000427 BR VERIFY1 ; BYPASS POSITIONING CHECK
3732 015076 000006 6$:
3733 015076 006237 027172 ASR BUFFER+2 ; ALIGN CYLINDER ADDRESS FOR COMPARE
3734 015102 006237 027172 ASR BUFFER+2 ; ALIGN CYLINDER ADDRESS FOR COMPARE
3735 015106 006237 027172 ASR BUFFER+2 ; ALIGN CYLINDER ADDRESS FOR COMPARE
3736 015112 006237 027172 ASR BUFFER+2 ; ALIGN CYLINDER ADDRESS FOR COMPARE
3737 015116 006237 027172 ASR BUFFER+2 ; ALIGN CYLINDER ADDRESS FOR COMPARE
3738 015122 006237 027172 ASR BUFFER+2 ; ALIGN CYLINDER ADDRESS FOR COMPARE
3739 015126 023737 001366 027172 CMP DPB+2, BUFFER+2 ; SEE IF CYLINDER ADDR FROM HEADER IS CORRECT
3740 015134 001407 BEQ VERIFY1 ; BR IF OK
3741 015136 013737 027172 001126 MOV BUFFER+2, $BDDAT ; CYLINDER ADDRESS FROM HEADER
3742 015144 104013 ERROR 13 ; CYLINDER ADDRESS DOES NOT COMPARE
3743 015146 062766 000002 000002 ADD #2, 2(SP) ; RETURN+2
3744 015154 012637 001110 VERIFY1: MOV (SP)+, $LPERR ; RESTORE LOOP ON ERROR ADDRESS
3745 015160 104413 RESREG ; RESTORE RO-R5
3746 015162 000207 RTS PC ; RETURN
3747
3748
3749
3750
3751
3752
3753
3754
3755

```

```

*****
;SBTTL SAVRP - STORE THE RPIIE REGISTERS
;THIS ROUTINE STORES THE RPIIE REGISTERS FOR USE BY THE PROGRAM.
;THE PROGRAM DOES NOT USE THE 'LIVE' REGISTERS FOR ERROR DETERMINATION.
;CALL
; JSR PC, SAVRP
; RETURN

```

```

3756 015164 010046
3757 015166 013700 001266
3758 015172 016037 000000 002004
3759 015200 016037 000002 002006
3760 015206 016037 000004 002010
3761 015214 016037 000006 002012
3762 015222 016037 000010 002014
3763 015230 016037 000012 002016
3764 015236 016037 000014 002020
3765 015244 016037 000016 002022
3766 015252 016037 000024 002024
3767 015260 016037 000026 002026
3768 015266 012600
3769 015270 000207
3770
3771
3772
3773
3774
3775
3776
3777
3778
3779 015272 013701 001246
3780 015276 156137 001314 001252
3781
3782 015304 005037 177776
3783 01531C 000137 007474
3784
3785
3786
3787
3788
3789
3790
3791
3792
3793
3794 015314 104412
3795 015316 013746 001110
3796 015322 012737 015334 001110
3797 015330 013700 001266
3798 015334 012760 000001 000004
3799 015342 012760 000001 000004
3800 015350 012777 015530 163712
3801 015356 013746 001364
3802 015362 112716 000015
3803 015366 052716 020000
3804 015372 012660 000004
3805 015376 005037 177776
3806 015402 010637 001242
3807 015406 012737 004704 001300
3808 015414 004037 015572
3809 015420 001300
3810 015422 004737 015164
3811 015426 032737 001000 002004

```

```

SAVRP: MOV RO, -(SP) ;SAVE RO
MOV RPAOR, RO ;RPI1 ADDRESS
MOV RPDS(RO), $RPDS ;STORE RPDS
MOV RPER(RO), $RPER ;STORE RPER
MOV RPCS(RO), $RPCS ;STORE RPCS
MOV RPWC(RO), $RPWC ;STORE RPWC
MOV RPBA(RO), $RPBA ;STORE RPBA
MOV RPCA(RO), $RPCA ;STORE RPCA
MOV RPOA(RO), $RPOA ;STORE RPOA
MOV RPM1(RO), $RPM1 ;STORE RPM1
MOV SUCA(RO), $SUCA ;STORE SUCA
MOV SILO(RO), $SILO ;STORE SILO
MOV (SP)+, RO ;RESTORE RO
RTS PC ;RETURN

:*****
:SBTTL DSELECT - SETUP INDICATORS TO DEASSIGN AN UNSAFE/OFFLINE DRIVE
:*THIS ROUTINE SETS A BIT IN LOCATION 'DSELECT' WHICH IS USED TO DESELECT
:*AN UNSAFE/OFFLINE DRIVE WHICH WAS ASSIGNED BY THE OPERATOR FOR TESTING
:*OR WHICH WENT OFFLINE OR UNSAFE DURING TESTING.
:CALL
: JMP Q#DSELECT

DSELECT: MOV CHKDRV, R1 ;GET DRIVE NUMBER
BISB ATABIT(R1), DRVBAD ;USE AS INDEX TO LOAD ATA BIT FOR DRIVE
;IN DESELECT LOCATION.
CLR PSW ;SET PRIORITY BACK TO ZERO
JMP Q#SEOP ;FORCE END OF PASS FOR THE DRIVE

:*****
:SBTTL RESTOR - HOME SEEK ROUTINE
:*THIS ROUTINE PERFORMS A HOME SEEK ON THE SELECTED DRIVE. THE ROUTINE
:*IS CALLED AFTER THE PROGRAM DETERMINES THAT THE DRIVE IS POSITIONED
:*INCORRECTLY AFTER A SEEK OR A UTILITY HOME SEEK OPERATION IS REQUIRED.
:CALL
: JSR PC, RESTOR
: RETURN

RESTOR: SAVREG
MOV $LPERR, -(SP) ;SAVE R0-R5
MOV #15, $LPERR ;SAVE LOOP ON ERROR ADDRESS
MOV RPAOR, RO ;LOOP ON ERROR ADDRESS
;RPI1 ADDRESS
15: MOV #CLEAR, RPCS(RO) ;CLEAR THE RPI1
MOV #CLEAR, RPCS(RO) ;CLEAR THE CONTROLLER
MOV #RESTRI, $RVEC ;INTERRUPT RETURN
MOV DPB, -(SP) ;SETUP RPCS CONTENTS
MOV #HOMSEK, (SP) ;COMMAND CODE
BIS #AIE, (SP) ;ATTENTION INTERRUPT ENABLE
MOV (SP)+, RPCS(RO) ;START THE HOME SEEK
CLR PSW ;SET PRIORITY TO ZERO
MOV SP, SPSAV ;SAVE THE STACK POINTER
MOV #2500, STALLG ;SET STALL VALUE TO 2500MS
JSR RO, STALLA ;WAIT THE SPECIFIED VALUE
;WORD STALLG ;STALL VALUE STORAGE
JSR PC, SAVRP ;GET THE REGISTERS
BIT #SUFU, $RPDS ;DRIVE UNSAFE ?

```

```

3812 015434 001403 BEQ 2$ ; BR IF NOT
3813 015436 104002 ERROR 2$ ; DRIVE UNSAFE
3814 015440 000137 015272 JMP DSELCT ; DESELECT THE DRIVE
3815 015444 032737 040000 002004 2$: BIT #SUOL,SRPDS ; IS THE DRIVE STILL ONLINE ?
3816 015452 001003 BNE 3$ ; BR IF IT IS
3817 015454 104010 ERROR 10 ; DRIVE OFFLINE AFTER POSITIONING
3818 015456 000137 015272 JMP DSELCT ; DESELECT THE DRIVE
3819 015462 032737 100000 002004 3$: BIT #SURY,SRPDS ; IS THE DRIVE READY ?
3820 015470 001003 BNE 4$ ; BR IF IT IS
3821 015472 104016 ERROR 16 ; DRIVE NOT READY AFTER POSITIONING
3822 015474 000137 015272 JMP DSELCT ; DESELECT THE DRIVE
3823 015500 104005 ERROR 5 ; DRIVE HAS NOT INTERRUPTED WITHIN 1 SEC
3824 015502 012760 000001 000004 MOV #CLEAR,RPCS(RO) ; CLEAR THE CONTROLLER
3825 015510 012760 000001 000004 MOV #CLEAR,RPCS(RO) ; CLEAR THE CONTROLLER
3826 015516 012777 000100 163420 MOV #BIT6,STKS ; SET INTERRUPT ENABLE FOR TTY KEYBOARD
3827 015524 000177 163514 JMP JBYPASS ; TERMINATE THE PRESENT TEST
3828 015530 013706 001242 RESTR1: MOV SPSAV,SP ; RESTORE THE STACK POINTER
3829 015534 005037 177776 CLR PSW ; RESET THE PSW
3830 015540 004737 015164 JSR PC,SAVRP ; SAVE THE REGISTERS
3831 015544 032737 004000 002004 BIT #SUSI,SRPDS ; SEEK INCOMPLETE ?
3832 015552 001403 BEQ 2$ ; BR IF NOT
3833 015554 104015 ERROR 15 ; SEEK INCOMPLETE
3834 015556 000137 015272 JMP DSELCT ; DESELECT THE DRIVE
3835 015562 012637 001110 2$: MOV (SP)+,SLPERR ; RESTORE THE LOOP ON ERROR ADDRESS
3836 015566 104413 RESREG ; RESTORE RD-R5
3837 015570 000207 RTS PC ; RETURN
3838
3839
3840 ;*****
3841 ;SBTL STALL - USED TO STALL AFTER A DRIVE FUNCTION IS COMPLETE
3842 ;THIS ROUTINE WILL PROVIDE A STALL IN MILLISECONDS FOR A SPECIFIC
3843 ;AMOUNT OF TIME IF SWITCH 02 IS NOT SET OR A RANDOM AMOUNT OF TIME IF
3844 ;SWITCH 02 IS SET.
3845 ;STALL1 CONTAINS SPECIFIED TIME FOR TESTS 0-6.
3846 ;CALL
3847 ; JSR RD,#STALL ; WHERE TO FIND THE STALL TIME
3848 ; TIME POINTER
3849 ;
3850 ; JSR RD,#STALLA ; ENTER HERE TO BYPASS RANDOM STALL SELECTION
3851 ; TIME POINTER ; WHERE TO FIND THE STALL TIME
3852
3852 015572 013046 STALLA: MOV 2(RO)+,-(SP) ; PICKUP STALL TIME
3853 015574 000413 BR STALLB ; BYPASS RANDOM STALL CHECK
3854 015576 013046 STALL: MOV 2(RO)+,-(SP) ; PICKUP STALL TIME
3855 015600 032777 000004 163332 BIT #SW2,2$WR ; USE A RANDOM TIME?
3856 015606 001406 BEQ STALLB ; NO--BRANCH
3857 015610 004737 013540 JSR PC,2$RAND ; YES--FORM RANDOM NUMBER
3858 015614 013716 013640 MOV 2,$LONUM,(SP) ; AND USE IT FOR THE STALL TIME
3859 015620 042716 177700 BIC #C77,(SP) ; BUT NEVER > 64 MILLISECONDS
3860 015624 005046 STALLB: CLR -(SP) ; CLEAR TEMP. LOCATION
3861 015626 162766 000001 000002 2$: SUB #1,2(SP) ; MORE STALL REQUIRED?
3862 015634 103407 BLO 4$ ; NO--BRANCH
3863 015636 012716 000620 MOV #400.,(SP) ; STALL TIME CONSTANT
3864 015642 005700 3$: TST RO ; NOP TO KILL TIME
3865 015644 005366 000000 DEC 0(SP) ; COUNT
3866 015650 001374 BNE 3$ ; LOOP IF MORE COUNTS NEEDED
3867 015652 000765 BP 2$

```

```

3868 015654 022626
3869 015656 000200
3870
3871
3872
3873
3874
3875
3876
3877
3878
3879
3880
3881
3882
3883
3884 015660 012037 016126
3885 015664 104412
3886 015666 012705 177776
3887 015672 012737 024040 001162
3888 015700 012737 024042 001164
3889 015706 012737 023540 001166
3890 015714 012737 023620 001170
3891 015722 013700 001162
3892 015726 013701 001164
3893 015732 013702 016126
3894 015736 005003
3895 015740 021011
3896 015742 003404
3897 015744 011004
3898 015746 011110
3899 015750 010411
3900 015752 005203
3901 015754 005720
3902 015756 005721
3903 015760 005302
3904 015762 001366
3905 015764 005703
3906 015766 001355
3907 015770 013700 001162
3908 015774 013701 001166
3909 016000 013702 001170
3910 016004 010204
3911 016006 005024
3912 016010 005024
3913 016012 005024
3914 016014 005024
3915 016016 005024
3916 016020 012703 177773
3917 016024 011011
3918 016026 013703 016126
3919 016032 022011
3920 016034 001411
3921 016036 005721
3922 016040 016011 177776
3923 016044 005722

```

```

4$:  CMP      (SP)+,(SP)+ ;CLEAN OFF THE STACK
      RTS      RD          ;EXIT

*****
: SBTTL SORT - ROUTINE TO SORT & PRINT SEEK TIMES
: *THIS ROUTINE DETERMINES THE NUMBER OF TIMES A PARTICULAR FORWARD OR REVERSE
: *SEEK TIME WAS OBTAINED. THE SEEK TIMES ARE SORTED IN DECENDING SEQUENCE
: *AND THE NUMBER OF OCCURENCES OF A PARTICULAR SEEK TIME ARE TOTALED. THE
: *THE ROUTINE WILL TYPEOUT ONLY THE LONGEST 5 SEEK TIMES. FORWARD SEEK TIMES
: *ARE STORED IN A TABLE STARTING AT 'FRWSTR'; REVERSE SEEK TIMES ARE STORED
: *IN A TABLE STARTING AT 'RVSTR'.
: CALL
: JSR      RD SORT          ;SORT AND TYPE THE SEEK TIMES
:          NUMBER OF ITEMS ;NUMBER OF ITEMS IN THE TABLE (405 MAX)
:
SORT: MOV      (RD)+,7$     ;GET THE ENTRY COUNT
      SAVREG          ;SAVE RD-R5
      MOV      #-2,R5     ;COUNT FOR FORWARD & REVERSE
      MOV      #FRWSTR,$REGD ;INITIALIZE POINTER TO FORWARD SEEK TIMES
      MOV      #FRWSTR+2,$REG1 ;SECOND FORWARD SEEK TIME POINTER
      MOV      #BUFR4,$REG2
      MOV      #BUFR5,$REG3 ;INITIALIZE POINTER TO '# OF TIMES'
1$:   MOV      $REGD,RD    ;TYPE 'SEEK TIME'
      MOV      $REG1,R1
      MOV      7$,R2      ;NUMBER OF ITEMS IN THE TABLE
      CLR      R3
2$:   CMP      (RD),(R1)   ;SORT THE ITEMS & PUT THEM
      BLE      3$         ;IN DESCENDING ORDER
      MOV      (RD),R4     ;LARGER ITEMS AT TOP OF LIST.
      MOV      (R1),(RD)  ;SMALLER AT THE BOTTOM
      MOV      R4,(R1)
      INC      R3
3$:   TST      (RD)+
      TST      (R1)+
      DEC      R2
      BNE      2$
      TST      R3
      BNE      1$
      MOV      $REGD,RD   ;SORTED ALL ITEMS?
      MOV      $REG2,R1   ;IF NOT LOOP BACK
      MOV      $REG3,R2   ;PTR TO 'SEEK TIME'
      MOV      R2,R4      ;SAVE 'SEEK TIME' HERE
      CLR      (R4)+      ;SAVE '# OF TIMES' HERE
      CLR      (R4)+
      CLR      (R4)+
      CLR      (R4)+
      CLR      (R4)+
      MOV      #-5,R3     ;CLR OUT 5 WORDS OF
      MOV      (RD),(R1)  ;'# OF TIMES' BUFR
      MOV      7$,R3
4$:   CMP      (RD)+,(R1) ;SAVE ONLY 5 DIFFERENT 'SEEK TIMES'
      BEQ      5$         ;FIND OUT THE '# OF TIMES'
      TST      (R1)+     ;EACH 'SEEK TIME' WAS
      MOV      -2(RD),(R1) ;OBTAINED
      TST      (R2)+     ;SAVE 'SEEK TIME'

```

```

016104 012712 000001      MOV      R1,(R2)          ;KEEP '# OF TIMES'
016106 000000      DEC      R1
016108 000000      DEC      R1
01610A 000000      DEC      R1
58:      INC      (R2)          ;INCREMENT '# OF TIMES'
01610C 000000      DEC      R1          ;ALL DONE?
01610E 000000      DEC      R1          ;IF NOT, GO BACK
016110 000000      DEC      R1          ;SORTED, BOTH FORWARD & REVERSE
68:      DEC      R1          ;IF YES, TYPE THE VALUES
016112 000000      DEC      R1          ;IF NOT, INITIALIZE POINTER TO REVERSE SEEK TIMES
016114 000000      DEC      R1          ;SECOND REVERSE SEEK TIME POINTER
016116 000000      DEC      R1          ;SAVE 'SEEK TIME'
016118 000000      DEC      R1          ;SAVE '# OF TIMES' HERE
01611A 000000      DEC      R1          ;GO BACK & DO SORTING FOR REVERSE SEEK TIMES
01611C 000000      DEC      R1
01611E 000000      DEC      R1
016120 000000      DEC      R1
016122 000000      DEC      R1
016124 000000      DEC      R1
016126 000000      DEC      R1
78:      .WORD 0          ;ITEMS IN TABLE COUNT HERE

;TYPEOUT THE HEADER FOR THE SEEK TIME RESULTS
GOTYPE:
016130 104401 016136      TYPE     658          ;:TYPE ASCIZ STRING
016132 000421      BR       648          ;:GET OVER THE ASCIZ
;:658: .ASCIZ '<15><12>' (SEEK TIME IS IN MICRO SECONDS)
648:
016200 104401 016206      TYPE     678          ;:TYPE ASCIZ STRING
016202 000420      BR       668          ;:GET OVER THE ASCIZ
;:678: .ASCIZ '<15><12><12>' FORWARD REVERSE
668:
016246 104401 016254      TYPE     698          ;:TYPE ASCIZ STRING
016248 000420      BR       688          ;:GET OVER THE ASCIZ
;:698: .ASCIZ '<15><12>' # OF SEEK # OF SEEK
688:
016314 104401 016322      TYPE     718          ;:TYPE ASCIZ STRING
016316 000421      BR       708          ;:GET OVER THE ASCIZ
;:718: .ASCIZ '<15><12>' SEEKS TIME SEEKS TIME '<15><12>'
708:
;TYPEOUT THE '# OF SEEKS' & 'SEEK TIME' OBTAINED FOR EACH OF THOSE SEEKS
TYPTIM: CLR      R0
016364 005000      CLR      R5
016366 005005      TYPE     SCRLF
18:      MOV     BUFR5(R0),-(SP) ;GET '# OF SEEKS' IF NONE = 0
016370 104401 001217      BEG      38          ;SKIP TYPING (FRWD SEEK)
016372 016046 023620      TYPE     38          ;GO TYPE OUT DECIMAL '# OF SEEKS'
016400 001438      TYPOS
016402 104405      TYPE
016404 104401      TYPE
016406 002043      BLNK52
016410 016046 023540      MOV     BUFR4(R0),-(SP) ;GET 'SEEK TIME' FOR EACH OF
016412 104405      TYPOS          ;OF THAT '# OF SEEKS'. 'GO
;TYPE OUT IN DECIMAL
016416 104401 016424      TYPE     658          ;:TYPE ASCIZ STRING
016418 000401      BR       648          ;:GET OVER THE ASCIZ
;:658: .ASCIZ '0'
648:
016426 016046 023760      MOV     BUFR7(R0),-SP ;GET '# OF SEEKS' IF NONE = 0
016428 001424      BEG      48          ;SKIP TYPING REVERSE SEEK
48:

```



```

3980 016437 005705 TST R5 ; 'FORWARD' VALUE FOR THIS LINE ?
3981 016438 001404 BFO 68 ; BR IF YES
3982 016440 104401 002035 TYPE .BLMKS8 ; TYPE FILLER BLANKS
3983 016441 104401 002036 TYPE .BLMKS7
3984 016445 104405 55: TYPDS ; TYPE OUT IN DECIMAL
3985 016450 104401 002043 TYPE BLMKS2 ; 2 BLANKS
3986 016455 016046 023700 MOV BUF,R6(R0),-(SP) ; GET 'SEEK TIME' & TYPE IT
3987 016456 104405 TYPDS ; OUT IN DECIMAL
3988 016464 104401 016472 TYPE 678 ; TYPE ASCII STRING
3989 016470 000401 BR 668 ; GET OVER THE ASCII

```

```

3990 016474 000406 668: .ASCII '0'
3991 016477 000406
3992 016478 005726 35: TST (SP)+ ; POP STACK
3993 016479 005205 INC R5
3994 016500 000751 BR 258
3995 016504 005726 45: TST (SP)+ ; POP STACK
3996 016506 005705 TST R5
3997 016510 001004 BNE 758
3998 016512 005720 55: TST (R0)+ ; INCREMENT PTR TO TABLES
3999 016514 020027 000012 CTR R0,#10. ; ALL DONE?
4000 016520 001323 BNE 15 ; IF NOT GO BACK
4001 016522 104413 75: RESREG ; RESTORE R0-R5
4002 016524 000200 RTS R0 ; RETURN

```

```

*****
SBTTL SEEK TIME MEASUREMENT ROUTINE
*THIS ROUTINE MEASURES THE TIME REQUIRED TO SEEK TO THE SPECIFIED CYLINDER
*THE ROUTINE USES THE 'SOT' COUNTER IN THE CONTROLLER TO MEASURE THE SEEK
*TIME. THE SEEK TIME MEASUREMENT IS BASED ON THE NUMBER OF SECTORS
*OCCURRING BETWEEN SEEK START AND SEEK COMPLETE. THE RESOLUTION OF THIS
*MEASUREMENT METHOD IS + OR - 2.5 MS (ONE SECTOR TIME).
CALL

```

```

4003 JSR PC,TIMSEK ; TIME THE SEEK TO THE CYLINDER IN DPB+2
4004 RETURN ; SEEK TIME IS RETURNED IN R3

```

```

4017 016526 010046 TIMSEK: MOV R0,-(SP) ; SAVE R0
4018 016530 010246 MOV R2,-(SP) ; SAVE R2
4019 016532 013746 001110 MOV $LPERR,-(SP) ; SAVE CURRENT LOOP ON ERROR ADDRESS
4020 016536 012737 016550 001110 MOV #TIMSK1,$LPERR ; NEW LOOP ON ERROR ADDRESS
4021 016544 013700 001266 MOV RPADR,R0 ; RP11 BASE ADDRESS
4022 016550 005003 TIMSK1: CLR R3 ; R3 WILL BE USED TO COUNT THE DISK REVOLUTIONS
4023 016552 012737 000062 001300 MOV #50,STALLG ; SET STALL VALUE TO 50MS
4024 016560 004037 015572 JSR R0,STALLA ; WAIT THE SPECIFIED VALUE
4025 016564 001300 .WORD STALLG ; STALL VALUE STORAGE
4026 016566 016002 000014 15: MOV RPDA(R0),R2 ; READ THE SECTOR/TRACK REGISTER
4027 016572 032702 000200 BIT #BIT7,R2 ; WAIT FOR SECTOR 8, THEN START LOOKING
4028 016576 001773 .ORG $ ; FOR SECTOR 0
4029 016600 016002 000014 25: MOV RPDA(R0),R2 ; READ THE SECTOR REGISTER
4030 016604 026002 000014 CMP RPDA(R0),R2 ; WAS IT CHANGING ?
4031 016610 001373 BNE 25 ; BR IF IT WAS
4032 016612 032702 000360 BIT #360,R2 ; WAIT FOR SEC 0, INDEX MARK
4033 016616 001370 BNE 25 ; AS SOON AS IT IS AT SECTOR 0, START
4034 A SEEK & BEGIN TIMING
4035 016620 012777 017066 162442 MOV #TIMSK2,$PP.ED ; INTERRUPT ADDRESS

```

SEEK TIME MEASUREMENT ROUTINE

4036	016626	012760	000377	000000		MOV	#377,RPDS(R0)	:CLEAR ANY ATTENTION BITS
4037	016634	013760	001366	000012		MOV	DPB+2,RPCA(R0)	:LOAD CYLINDER ADDRESS
4038	016642	013746	001364			MOV	DPB-(SP)	:SETUP COMMAND
4039	016646	052716	020000			BIS	#ATE(SP)	:SET ATTENTION INTERRUPT ENABLE
4040	016652	012660	000004			MOV	(SP)+,RPCS(R0)	:ISSUE A SEEK, START TIMING
4041	016656	005037	177776			CLR	PSW	:SET PRIORITY TO ZERO
4042	016662	016002	000014		3\$:	MOV	RPDA(R0),R2	:READ THE SECTOR REGISTER
4043	016666	026002	000014			CMP	RPDA(R0),R2	:WAS IT CHANGING ?
4044	016672	001373				BNE	3\$:BR IF IT WAS
4045	016674	032702	000360			BIT	#360,R2	:WAIT FOR SEC CNTR TO MOVE
4046	016700	001770				BEQ	3\$:FROM 0 TO 1
4047	016702	016002	000014		4\$:	MOV	RPDA(R0),R2	:READ THE SECTOR REGISTER
4048	016706	026002	000014			CMP	RPDA(R0),R2	:WAS IT CHANGING ?
4049	016712	001373				BNE	4\$:BR IF IT WAS
4050	016714	032702	000360			BIT	#360,R2	:WAIT FOR SECTOR 0
4051	016720	001370				BNE	4\$:BR IF NOT AT 0
4052	016722	005203				INC	R3	:COUNT A DISK REVOLUTION (25MS
4053	016724	023703	00005C			CMP	#40.,R3	:1 SECOND ELAPSED
4054	016730	003354				BGT	3\$:BR IF NOT
4055	016732	004737	015164			JSR	PC,SAVRP	:SAVE THE REGISTERS
4056	016736	032737	001000	002004		BIT	#SUFU,RPDS	:FILE UNSAFE
4057	016744	001403				BEQ	5\$:BR IF NOT
4058	016746	104002				ERROR	2	:REPORT DRIVE UNSAFE
4059	016750	000137	015272			JMP	DSELECT	:SETUP TO DESELECT THE DRIVE
4060	016754				5\$:			
4061	016754	013737	002004	001126		MOV	\$RPDS,\$BDDAT	:GET CONTENTS OF RPDS
4062	016762	012737	000000	001122		MOV	\$RPDS,\$BDADR	:FORM REGISTER ADDRESS FOR ERROR MESSAGE
4063	016770	063737	001266	001122		ADD	RPADR,\$BDADR	:ADD RP11 BASE ADDRESS
4064	016776	012737	140000	001124		MOV	#SUDY!SUOL,\$CDDAT	:WHAT REGISTER SHOULD BE
4065	017004	013737	001126	001204		MOV	\$BDDAT,\$TMP0	:MOVE REGISTER CONTENTS TO '\$TMP0'
4066	017012	042737	037777	001204		BIC	#C14000,\$TMP0	:SAVE THE SPECIFIED BITS
4067	017020	023737	001124	001204		CMP	\$CDDAT,\$TMP0	:COMPARE THE BITS
4068	017026	001403				BEQ	6\$:BR IF OK
4069	017030	104017				ERROR	17	:NOT READY/OFFLINE DURING TIMING TEST
4070	017032	000137	015272			JMP	DSELECT	:DESELECT THE DRIVE
4071	017036	104005			6\$:	ERROR	5	:NO INTERRUPT AFTER 1 SECOND
4072	017040	012760	000001	000004		MOV	#CLEAR,RPDS(R0)	:CLEAR THE CONTROLLER
4073	017046	012760	000001	000004		MOV	#CLEAR,RPDS(R0)	:CLEAR THE CONTROLLER
4074	017054	012777	000100	162062		MOV	#BIT06,\$STKS	:SET KEYBOARD INTERRUPT ENABLE
4075	017062	000177	162156			JMP	\$BYPASS	:TERMINATE THE TEST
4076	017066	012626			TIMSK2:	MOV	(SP)+,(SP)+	:RESTORE THE STACK POINTER
4077	017070	016002	000014			MOV	RPDA(R0),R2	:SAVE RPDA
4078	017074	005037	177776			CLR	PSW	:SET PRIORITY TO ZERO
4079	017100	032702	000360			BIT	#360,R2	:AT SECTOR 0 ?
4080	017104	001001				BNE	1\$:BR IF NOT
4081	017106	005203				INC	R3	:INCREMENT THE REVOLUTION COUNTER
4082	017110	004737	015164		1\$:	JSR	PC,SAVRP	:STORE THE REGISTERS
4083	017114	032737	004000	002004		BIT	#SUSI,RPDS	:SEEK INCOMPLETE ?
4084	017122	001405				BEQ	2\$:BR IF NOT
4085	017124	104015				ERROR	15	:SEEK INCOMPLETE
4086	017126	004737	015314			JSR	PC,RESTOR	:DO A HOME SEEK
4087	017132	000177	162106			JMP	\$BYPASS	:TERMINATE THE PRESENT TEST
4088	017136	032737	100000	000004	2\$:	BIT	#ERR,RPDS	:OTHER ERRORS ?
4089	017144	001412				BEQ	\$K00N	:BR IF NOT
4090	017146	104004				ERROR	4	:REPORT ERROR DURING TIMING TEST
4091	017150	012760	000001	000004		MOV	#CLEAR,RPDS R0	:CLEAR THE CONTROLLER

```

017156 012760 000001 000004 MOV #CLEAR RPCS(R0) ;CLEAR THE CONTROLLER
017164 113760 001365 000005 MOVB DPB+1,RPCS+1(R0) ;RESELECT THE DRIVE
017172 042702 177417 SKDON: BIC #C360,R2 ;CLEAR SECTOR/TRACK BITS - LEAVE THE '50'
017179 006202 ASR R2 ;RIGHT JUSTIFY '50'
017187 006202 ASR R2 ;RIGHT JUSTIFY '50'
017195 006202 ASR R2 ;RIGHT JUSTIFY '50'
017203 006202 ASR R2 ;RIGHT JUSTIFY '50'
017211 012746 000010 MOV #10,-(SP) ;PUT THE MULTIPLIER ON THE STACK
017219 010346 MOV R3,-(SP) ;PUT THE MULTIPLICAND ON THE STACK
017227 004737 013052 JSR PC,28$MULT ;CALL THE MULTIPLY ROUTINE
017235 012616 MOV (SP)+,(SP) ;DISREGARD THE MSB'S
017243 012603 MOV (SP)+,R3 ;GET THE LSB'S OF THE PRODUCT
017251 060203 ADD R2,R3 ;ADD PARTIAL SECTOR COUNT
;NOTE THERE IS A SCALE FACTOR
017259 012746 000372 MOV #250,-(SP) ;PUT THE MULTIPLIER ON THE STACK
017267 010346 MOV R3,-(SP) ;PUT THE MULTIPLICAND ON THE STACK
017275 004737 013052 JSR PC,28$MULT ;CALL THE MULTIPLY ROUTINE
017283 012616 MOV (SP)+,(SP) ;DISREGARD THE MSB'S
017291 012603 MOV (SP)+,R3 ;GET THE LSB'S OF THE PRODUCT

```

```

*****
;SEEK TIME (IN US) = [(R3)X(10)+(R2)]X(250)X(10)
*****

```

```

017299 012637 001110 MOV (SP)+,$LPERR ;RESTORE THE LOOP ON ERROR ADDRESS
017307 012603 MOV (SP)+,R2 ;RESTORE R2
017315 012603 MOV (SP)+,R0 ;RESTORE R0
017323 000203 RTS PC ;RETURN

```

```

*****
;SMTL GETADR - GET BUS ADDRESS AND VECTOR ADDRESS
;THIS ROUTINE IS USED TO INSURE THE BUS ADDRESS
;OF THE RP11 IS SETUP TO READ THE PROPER VALUE.
;IT WILL ALSO READ THE ADDRESS FROM THE TTY IF
;REQUIRED.
;NOTE: THIS ROUTINE DESTROYS R0-R4
;CALL

```

```

; JSR PC,28$GETADR
; RETURN
GETADR: *ST 28$BUSADR ;INPUT FROM TTY REQUESTED*
; BEQ 7$ ;NO--BRANCH
; CLR 28$BUSADR ;YES--CLEAR THE REQUEST FLAG
; $: MOV #RPADR,R0 ;FIRST ADDRESS
; MOV #MRPCS,R3 ;"RPADR="
; MOV (R0),R4 ;PRESENT RP11 ADDRESS
; JSR R0,28$GETNUM ;GET NEW RP11 ADDRESS
; BR 2$ ;COMMA
; BR 1$ ;PERIOD
; BR 5$ ;DOUBLE PERIOD
; 2$: MOV R4,(R0)+ ;SAVE NEW RHCS1
; MOV #MAPVEC,R3 ;"RPVEC="
; MOV (R0),R4 ;PRESENT RP11 VECTOR ADDRESS
; JSR R0,28$GETNUM ;GET NEW RPVEC
; BR 3$ ;COMMA

```

```

4148 017332 000756 BR R4, R4 ; PERIOD
4149 017333 000417 BR R4, R4 ; DOUBLE PERIOD
4150 017336 010420 35: MOV R4, (R0)+ ; SAVE NEW RPVEC
4151 017340 012703 021461 MOV R4, @RPPRI, R3 ; "RPPRIO="
4152 017344 011004 MOV R4, (R0), R4 ; PRESENT RPI1 PRIORITY LEVEL
4153 017346 006304 ASL R4 ; POSITION FOR TYPEOUT
4154 017347 006304 ASL R4
4155 017348 006304 ASL R4
4156 017349 006304 ASL R4
4157 017355 000304 STAB R4
4158 017356 004037 017460 JSR R0, @GETNUM ; GET NEW RPPRIO
4159 017358 000402 ; COMMA
4160 017359 000401 ; PERIOD
4161 017366 000404 45: MOV R2, (R0) ; DOUBLE PERIOD
4162 017370 010210 ; SAVE NEW RPPRIO
4163 017372 000736 ; LOOP
4164 017374 010410 55: MOV R4, (R0) ; SAVE INPUT
4165 017376 000401 BR R4
4166 017400 010210 65: MOV R2, (R0) ; SAVE PRIORITY
4167 017402 013701 000004 MOV @ERRVEC, R1 ; SAVE THE ERROR VECTOR
4168 017404 012734 017426 000004 MOV @ERRVEC, R1 ; SETUP FOR TRAP
4169 017414 005777 161646 TST @RPAOR ; CHECK FOR RPI1
4170 017420 010137 000004 MOV R1, @ERRVEC ; RESTORE ERROR VECTOR
4171 017422 000207 RTS PC ; RETURN
4172 017426 010137 000004 85: MOV R1, @ERRVEC ; RESTORE ERROR VECTOR
4173 017434 022626 CMP (SP)+, (SP)+ ; CLEAN OFF THE STACK
4174 017436 104001 ERROR 1 ; REPORT THE ERROR
4175 017442 005737 000042 TST @42 ; IS THERE A MONITOR?
4176 017444 001712 BEQ IS ; NO--GO ASK FOR ADDRESS
4177 017444 005037 001232 CLR @DRVSEL ; YES--NO DRIVES SELECTED
4178 017450 005037 007650 CLR @SEOPCT ; NO PASSES
4179 017454 000137 007474 JMP @SEOP ; GO TO END OF PROGRAM

*****
;SBTTL GETNUM - ROUTINE TO GET A NUMBER
;THIS ROUTINE WILL TYPE AN ASCIZ MESSAGE AND THEN
;INPUT AN ASCIZ STRING AND CHANGE THE STRING TO OCTAL
;IF REQUIRED.
;NOTE: THIS ROUTINE DESTROYS R1
CALL
; MOV @ADR, R3 ; ADDRESS OF ASCIZ MESSAGE
; MOV @NUM, R4 ; OCTAL NUMBER
; JSR R0, @GETNUM
; RETURN1 ; INPUT TERMINATED WITH A COMMA
; RETURN2 ; WITH A PERIOD
; RETURN3 ; WITH A DOUBLE PERIOD
; ; R4=INPUT NUMBER AND
; ; R2=R4*32 FOR ALL
; ; THREE RETURNS

4197 017460 010337 017466 GETNUM: MOV R3, 25 ; SAVE MESSAGE POINTER
4198 017464 104401 15: TYPE ; TYPE THE MESSAGE
4199 017466 000000 25: .WORD 0 ; MESSAGE POINTER GOES HERE
4200 017470 010446 MOV R4, -1 SP ; SAVE R4 FOR TYPEOUT
4201 017472 104402 TYPCC ; GO TYPE--OCTAL ASCII, ALL DIGITS
4202 017474 104401 RDLIN ; READ AN ASCIZ STRING
4203 017476 012601 MOV (SP)+, R1 ; ADDRESS OF FIRST CHARACTER

```

```

4204 017500 004037 021044 JSR RO, @BCK.CHR :CHECK ONE CHARACTER
4205 017504 017464 :ILLEGAL CHARACTER
4206 017506 017464 :CARRIAGE RETURN
4207 017510 017520 :
4208 017512 017544 :
4209 017514 017552 :
4210 017516 017464 :DIGIT 0-9
4211 017520 004037 021300 JSR RO, @BCK.NUM :CHECK THE NUMBER
4212 017524 017464 :ILLEGAL INPUT
4213 017526 017540 :TERMINATED WITH A "."
4214 017528 017536 :TERMINATED WITH A " "
4215 017532 017536 :TERMINATED WITH A "..."
4216 017534 005720 45: TST (R0)+ :DOUBLE PERIOD
4217 017536 005720 55: TST (R0)+ :SINGLE PERIOD
4218 017540 010204 65: MOV R2, R4 :COMMA--SAVE INPUT NUMBER
4219 017542 000414 :GO TO EXIT
4220 017544 105711 75: TSTB (R1) :TERMINATOR AFTER A COMMA?
4221 017546 001346 :NO--LOOP
4222 017550 000411 :YES--EXIT
4223 017552 105711 85: TSTB (R1) :TERMINATOR AFTER A PERIOD?
4224 017554 001406 :YES--EXIT
4225 017556 122721 000056 CMPB #', (R1)+ :NO--DOUBLE PERIOD?
4226 017562 001340 :NO--LOOP
4227 017564 105711 :YES--TERMINATOR?
4228 017566 001336 :NO--LOOP
4229 017570 005720 :DOUBLE PERIOD
4230 017572 005720 95: TST (R0)+ :PERIOD
4231 017574 010402 105: MOV R4, R2 :COMMA--POSITION THE
4232 017576 000302 :NUMBER IN CASE IT
4233 017600 006202 :IS THE PRIORITY LEVEL
4234 017602 006202 :
4235 017604 006202 :
4236 017606 000200 :EXIT

```

```

*****
:SBTTL GT.PRM - GET PARAMETERS
:*THIS ROUTINE IS USED TO CHANGE OR MODIFY
:*THE TEST PARAMETERS. IT GIVES THE OPERATOR
:*THE CAPABILITY OF SPECIFYING WHICH DRIVES TO TEST, WHICH
:*TESTS TO RUN AND HOW MANY TIMES TO
:*REPEAT EACH TEST

```

```

4247 017610 104412 GT.PRM: SAVREG :SAVE R0-R5
4248 017612 005037 001232 GT.PRI: CLR DRSEL :NO DRIVE SELECTED
4249 017616 104401 017624 :TYPE 655 :TYPE ASCIZ STRING
4250 017622 000406 :BR 645 :GET OVER THE ASCIZ
4251 :655: .ASCIZ (<15>(<12> DRIVE S) =
4252 645: :
4253 017640 :ROLIN :READ TTY
4254 017642 104411 :MOV SP, +A1 :ADDRESS OF ASCIZ STRING
4255 017644 004037 021044 JSR RO, @BCK.CHR :CHECK ONE CHARACTER
4256 017650 017612 :GT.PRI :ILLEGAL CHARACTER
4257 017652 017612 :GT.PRI :CARRIAGE RETURN
4258 017654 017612 :GT.PRI :
4259 017656 017612 :GT.PRI :

```

4260	017660	017612				GT.PRI	:" "
4261	017662	017664				IS	:DIGIT 0-9
4262	017664	005301			1S:	DEC R1	
4263	017666				2S:		
4264	017666	012702	000007			MOV #7,R2	:UPPER LIMIT OF INPUT
4265	017672	004037	021120			JSR RD,CHK.DIG	:CHECK THE DIGIT(S)
4266	017676	017612				GT.PRI	:ILLEGAL INPUT
4267	017700	017612				GT.PRI	:INPUT TOO LARGE
4268	017702	017710				JS	:TERMINATED WITH A " "
4269	017704	017730				4S	:TERMINATED WITH A " "
4270	017706	017730				4S	:TERMINATED WITH A " "
4271	017710	156237	001314	001232	3S:	BISB ATABIT(R2),DRVSEL	:SET THE DRIVE SELECTED BIT
4272	017716	105741				TSTB -(R1)	:WAS THE LINE TERMINATED?
4273	017720	001362				BNE 2S	:NO-GET THE NEXT DRIVE
4274	017722	005037	001234			CLR #BTSTNMS	:DESELECT ALL TESTS
4275	017726	000405				BR GTTST1	:YES--SELECT TEST
4276	017730	156237	001314	001232	4S:	BISB ATABIT(R2),DRVSEL	:SET THE SELECTED DRIVE BITS
4277	017736	104413			GT.PR2:	RESREG	:RESTORE RD-R5
4278	017740	000207				RTS PC	:EXIT
4279							
4280	017742					GTTST1:	
4281	017742	104401	017750			TYPE 65S	:TYPE ASCIZ STRING
4282	017746	000403				BR 64S	:GET OVER THE ASCIZ
4283						65S:	.ASCIZ
4284	017756					64S:	TEST=
4285	017756	104411				ROLIN	:READ AN ASCIZ STRING
4286	017760	012601				MOV (SP)+,R1	:POINTER TO R1
4287	017762	122711	000056			CMPB #..(R1)	:DOUBLE PERIOD?
4288	017766	001007				BNE 1S	:NO--BRANCH
4289	017770	122761	000056	000001		CMPB #..1 R1	
4290	017776	001003				BNE 1S	
4291	020000	105761	000002			TSTB 2(R1)	: "CR"?
4292	020004	001754				BEO GT.PR2	:YES--EXIT
4293	020006	005037	001234		1S:	CLR TSTNMS	:NO TEST SELECTED
4294	020012	005003				CLR R3	:NO TEST TO BE OPENED
4295	020014	005004			GTTST2:	CLR R4	:NO TEST BITS SET
4296	020016	004037	020770			JSR RD,CHK.OCT	:OCTAL DIGIT?
4297	020022	000460				BR GTTST4	:NO--BRANCH
4298	020024	010205				MOV R2,R5	:YES--SAVE IT
4299	020026	005201				INC R1	:MOVE TO NEXT CHARACTER
4300	020030	004037	020770			JSR RD,CHK.OCT	:OCTAL DIGIT
4301	020034	000405				BR 1S	:NO--BRANCH
4302	020036	005201				INC R1	:MOVE TO NEXT CHARACTER
4303	020040	006305				ASL R5	:SCALE HIGH DIGIT
4304	020042	006305				ASL R5	
4305	020044	006305				ASL R5	
4306	020046	063502				ADD R5,R2	:COMBINE HIGH & LOW DIGITS
4307	020050	020227	000012		1S:	CMP R2,#STN-1	:LEGAL TEST NUMBER?
4308	020054	003332				BGT GTTST1	:NO--BRANCH
4309	020056	006302				ASL R2	
4310	020060	016204	001324			MOV BITS(R2),R4	:SELECT TEST
4311	020064	121127	000055			CMPB (R1),#'-	:TEST STRING?
4312	020070	001035				BNE GTTST4	:NO--BRANCH
4313	020072	005201				INC R1	:YES--MOVE TO NEXT CHARACTER
4314	020074	004037	020770			JSR RD,CHK.OCT	:OCTAL DIGIT?
4315	020100	000720				BR GTTST1	:NO--BRANCH

4316	020102	010205		MOV	R2,R5	:YES--SAVE IT
4317	020104	005201		INC	R1	:MOVE TO NEXT CHARACTER
4318	020106	004037	020770	JSR	R0,28CK.OCT	:OCTAL DIGIT?
4319	020112	000405		BRA	R0	:NO--BRANCH
4320	020114	005201		INC	R1	:YES--MOVE TO NEXT CHARACTER
4321	020116	006305		ASL	R5	:SCALE HIGH DIGIT
4322	020118	006305		ASL	R5	
4323	020120	006305		ASL	R5	
4324	020122	060502		ASL	R5	
4325	020126	020227	000012	AND	R2,R2	:COMBINE HIGH & LOW DIGIT
4326	020132	003303		CMP	R2,#STN-1	:LEGAL TEST NUMBER?
4327	020134	006302		BGT	R2,ST1	:NO--BRANCH
4328	020136	020462	001324	ASL	R2	
				CMF	R4,BITS,R2	:IS THE FIRST NUMBER OF THE

4329									: STRING SMALLER THAN THE LAST?
4330	020142	002277			BGE	GTTST1			: NO--BRANCH
4331	020144	056204	001324	3\$:	BIS	BITS(R2),R4			: YES--SET TEST SELECT BIT FOR SELECTED TESTS
4332	020150	005742			TST	-(R2)			: ADJUST POINTER
4333	020152	036204	001324		BIT	BITS(R2),R4			: DONE?
4334	020156	001772			BEG	3\$: NO--BRANCH
4335	020160	000401			BR	GTTST4			: SKIP THE INCREMENT
4336	020162	005201			GTTST3: INC	R1			: MOVE TO NEXT CHARACTER
4337	020164	050437	001234		GTTST4: BIS	R4,TSTNMS			: SET SELECTED TEST BITS INTO
4338									: TEST SELECT WORD
4339	020170	121127	000056		CMPB	(R1),#'			: "PERIOD"?
4340	020174	001420			BEG	GTTST5			: YES--BRANCH
4341	020176	005704			TST	R4			: ANY TEST SELECTED THIS CYCLE?
4342	020200	001660			BEG	GTTST1			: NO--BRANCH
4343	020202	121127	000057		CMPB	(R1),#'			: "OPEN"?
4344	020206	001002			BNE	1\$: NO--BRANCH
4345	020210	050403			BIS	R4,R3			: YES--SET BITS FOR TEST TO OPEN.


```

4346 020212 000403          BR      2$
4347 020214 121127 000054 1$: CMPB  (R1), #'
4348 020220 001250          BNE    GTTST1
4349 020220 005201          INC    R1
4350 020224 105711          TSTB  (R1)
4351 020226 001272          BNE    GTTST2
4352 020226 005703          TST   R3
4353 020230 001026          BNE    OPNTST
4354 020234 000642          BR     GTTST1
4355 020236 005201  GTTSTS: INC    R1
4356 020240 121127 000056 1$: CMPB  (R1), #'
4357 020244 001410          BEQ   GTTST6
4358 020246 105711          TSTB  (R1)
4359 020250 001402          BEQ   1$
4360 020252 000137 017742 1$: JMP    GTTST1
4361 020256 005703          TST   R3
4362 020260 001013          BNE    OPNTST
4363 020262 000137 017736 1$: JMP    GT.PR2
4364 020266 005201  GTTST6: INC    R1
4365 020270 105711          TSTB  (R1)
4366 020272 001402          BEQ   1$
4367 020274 000137 017742 1$: JMP    GTTST1
4368 020300 005703          TST   R3
4369 020302 001002          BNE    OPNTST
4370 020304 000137 017736 1$: JMP    GT.PR2
4371          : OPEN THE TEST FOR CHANGES
4372 020310 104412  OPNTST: SAVREG
4373 020312 005027          CLR   (PC)+
4374 020314 000000  OPN.CT: .WORD 0
4375 020316 000411          BR     OPN.2
4376 020320 005237 020314  OPN.1: INC    OPN.CT
4377 020324 022737 000012 020314  CMP    #STN-1, OPN.CT
4378 020332 002003          BGE   OPN.2
4379 020334 104413          RESREG
4380 020336 000137 017742 1$: JMP    GTTST1
4381 020342 013705 020314  OPN.2: MOV    OPN.CT, R5
4382 020346 006305          ASL   R5
4383 020350 036503 001324  BIT    BITS(R5), R3
4384 020354 001761          BEQ   OPN.1
4385 020356 104401 020364  TYPE  , 65$
4386 020362 000404          BR     64$
4387          ; 65$: .ASCIZ < TEST
4388          64$:
4389 020374 013746 020314  MOV    OPN.CT, -(SP)
4390          : SAVE OPN.CT FOR TYPEOUT
4391 020400 104403          TYPOS
4392 020402 002          .BYTE 2
4393 020403 000          .BYTE 0
4394 020404 104401 001217  TYPE  , SCRLF
4395 020410 016500 001406  MOV    PRMPT(R5), R0
4396 020414 011046          MOV    (R0), -(SP)
4397 020416 012702 001372  MOV    #PRM, R2
4398 020422 000405          BR     2$
4399 020424 006216 1$: ASR   (SP)
4400 020426 103403          BCS  2$
4401 020430 001404          BEG   OPNPRM

```

```

: "COMMA"?
: NO--BRANCH
: MOVE TO NEXT CHARACTER
: "CR"?
: NO--GO GET NEXT CHARACTER
: ANY TESTS TO OPEN?
: YES--BRANCH
: NO--START AGAIN
: MOVE TO NEXT CHARACTER
: "PERIOD"?
: YES--BRANCH
: "CR"?
: YES--BRANCH
: ANY TEST TO BE OPENED?
: YES--BRANCH
: NO--GO START TESTING
: MOVE TO NEXT CHARACTER
: "CR"?
: YES--BRANCH
: NO--GO ASK FOR TEST
: ANY TEST TO BE OPENED?
: YES--BRANCH
: NO--GO START TESTING
: SAVE R0-R5
: START WITH TEST 0
: COUNT STORED HERE
: SKIP THE INCREMENT
: MOVE TO THE NEXT TEST
: TEST NUMBER TO BIG?
: NO--OPEN THE NEXT TEST
: RESTORE R0-R5
: YES--GO ASK FOR MORE TESTS
: SETUP TO USE THE
: TEST NUMBER AS AN INDEX
: OPEN THIS TEST?
: NO--MOVE TO NEXT TEST
: TYPE ASCIZ STRING
: GET OVER THE ASCIZ
: SAVE OPN.CT FOR TYPEOUT
: TEST NUMBER
: GO TYPE--OCTAL ASCII
: TYPE 2 DIGIT(S)
: SUPPRESS LEADING ZEROS
: TYPE "CR" & "LF"
: PICKUP PARAMETER POINTER
: SAVE THE VARIABLE INDICATOR
: FIRST ADDRESS OF TABLE
: CHECK FOR A VARIABLE
: GO MOVE THIS ONE
: DONE

```

```

4402 020432 005722          TST      (R2)+          ;BUMP THE POINTER
4403 020434 000773          BR       1$            ;
4404 020436 012022          2$:     MOV      (R0)+,(R2)+ ;MOVE THIS VARIABLE INTO THE
4405 020440 000771          BR       1$            ;COMMON AREA
4406 020442 013716 001372  OPNPRM: MOV      @PRM,(SP) ;GET THE VARIABLE INDICATOR
4407 020446 005004          CLR      R4           ;ZERO THE INDEX
4408 020450 006216          1$:     ASR      (SP)    ;CHECK FOR A VARIABLE
4409 020452 103403          BCS     3$            ;GO GET IT
4410 020454 001772          BEQ     OPNPRM       ;OUT OF VARIABLES
4411 020456 005724          2$:     TST      (R4)+    ;UPDATE THE INDEX
4412 020460 000773          BR       1$            ;
4413 020462 104401 002043  3$:     TYPE     BLNKS2    ;TYPE SPACES
4414 020466 016437 001446  20476  MOV      PRMSG(R4),4$ ;TYPE THE NAME OF THIS VARIABLE
4415 020474 104401          TYPE     WORD        ;
4416 020476 000000          4$:     .WORD    0      ;
4417 020500 104401 021436          TYPE     MSG.EQ      ;TYPE "="
4418 020504 016446 001374          MOV      RPT(R4),-(SP) ;PUT RPT(R4) ON THE STACK
4419 020510 004737 013250          JSR     PC,$$SB20    ;CONVERT RPT(R4)
4420 020514 004737 013500          JSR     PC,$$SUPRS   ;TYPE RPT(R4)
4421 020520 104411          RDLIN   ;
4422 020522 012601          MOV      (SP)+,R1    ;READ AN ASCIZ STRING
4423 020524 004037 021044          JSR     RD,@CK.CHR  ;CHECK ONE CHARACTER
4424 020530 020462          3$:     ;ILLEGAL CHARACTER
4425 020532 020462          3$:     ;CARRIAGE RETURN
4426 020534 020600          3$:     ;
4427 020536 020544          5$:     ;
4428 020540 020552          6$:     ;
4429 020542 020462          3$:     ;DIGIT 0-9
4430 020544 105711          5$:     TSTB     (R1)    ;"CR"?
4431 020546 001345          3$:     BNE     2$            ;NO--STAY ON THIS VARIABLE
4432 020550 000742          BR       2$            ;YES--MOVE TO NEXT VARIABLE
4433 020552 105711          6$:     TSTB     (R1)    ;IS THERE A "CR" AFTER THE PERIOD?
4434 020554 001002          BNE     64$           ;NO
4435 020556 000137 020634          JMP     OPN.N2       ;YES--GO CLOSE THIS TEST
4436 020562 122721 000056          64$:    CMPB     #'',(R1)+ ;DOUBLE PERIOD?
4437 020566 001335          BNE     3$            ;NO--GO ASK FOR THIS VARIABLE
4438 020570 105711          TSTB     (R1)    ;YES--IS A "CR" AFTER THE DOUBLE PERIOD?
4439 020572 001333          BNE     3$            ;NO--ASK FOR THIS VARIABLE AGAIN
4440 020574 000137 020652          JMP     OPN.X2       ;YES--CLOSE ALL TEST
4441 020600          7$:     ;
4442 020600 016402 001434          MOV      PRMLT(R4),R2 ;UPPER LIMIT OF INPUT
4443 020604 004037 021120          JSR     RD,@CK.DIG  ;CHECK THE DIGIT(S)
4444 020610 020462          3$:     ;ILLEGAL INPUT
4445 020612 020462          3$:     ;INPUT TOO LARGE
4446 020614 020622          BS      ;TERMINATED WITH A "."
4447 020616 020630          OPN.N1 ;TERMINATED WITH A "."
4448 020620 020646          OPN.X1 ;TERMINATED WITH A "..."
4449 020622 010264 001374          8$:     MOV      R2,RPT(R4) ;SAVE THIS VARIABLE
4450 020626 000713          BR       2$            ;MOVE TO NEXT VARIABLE
4451 020630 010264 001374          OPN.N1: MOV      R2,RPT(R4) ;SAVE THIS VARIABLE
4452 020634 005726          OPN.N2: TST      (SP)+ ;CLEAN OFF THE STACK
4453 020636 004737 020710          JSR     PC,CLOSE    ;CLOSE THIS TEST
4454 020642 000137 020320          JMP     OPN.1        ;GO OPEN THE NEXT TEST
4455 020646 010264 001374          OPN.X1: MOV      R2,RPT(R4) ;SAVE THIS VARIABLE
4456 020652 005726          OPN.X2: TST      (SP)+ ;CLEAN OFF THE STACK
4457 020654 004737 020710          1$:     JSR     PC,CLOSE ;CLOSE THIS TEST

```

```

4458 020660 005725          2S:  TST      (R5)+          ;UPDATE THE INDEX
4459 020662 020527 000034    CMP      R5,#16*2        ;INDEX TO BIG?
4460 020666 002404          BLT      3S              ;NO--BRANCH
4461 020670 104413          RESREG   ;YES, RESTORE RO-R5
4462 020672 104413          RESREG   ;YES, RESTORE RO-R5
4463 020674 000137 017736    JMP      GT.PR2         ;GO TO EXIT
4464 020700 036503 001324    3S:  BIT      BITS(R5),R3  ;IS THIS TEST OPEN FOR CHANGE?
4465 020704 001363          BNE     1S              ;YES--GO CLOSE IT
4466 020706 000764          BR      2S              ;NO--MOVE TO NEXT TEST
4467 020710 104412          CLOSE: SAVREG          ;SAVE RO-R5
4468 020712 012700 001372    MOV     #PRM,RO         ;"FROM" ADDRESS
4469 020716 016501 001406    MOV     PRMP+(R5),R1   ;"TO" ADDRESS
4470 020722 012002          MOV     (R0)+,R2       ;"FROM" INDICATOR
4471 020724 012103          MOV     (R1)+,R3       ;"TO" INDICATOR
4472 020726 012704 000001    MOV     #1,R4          ;TEST BIT START A "RPT"
4473 020732 030402          1S:  BIT      R4,R2        ;PARAMETER TO BE MOVED?
4474 020734 001403          BEQ     2S              ;NO--BRANCH
4475 020736 030403          BIT      R4,R3         ;A PLACE TO PUT IT?
4476 020740 001404          BEQ     3S              ;NO--BRANCH
4477 020742 011011          MOV     (R0),(R1)      ;YES--MOVE "FROM" TO "TO"
4478 020744 030403          2S:  BIT      R4,R3         ;"TO" PARAMETER?
4479 020746 001401          BEQ     3S              ;NO--BRANCH
4480 020750 005721          TST     (R1)+          ;YES--UPDATE THE POIN ER
4481 020752 005720          3S:  TST     (R0)+          ;UPDATE FROM POINTER
4482 020754 006304          ASL     R4              ;POSITION THE TEST BIT
4483 020756 032704 002000    BIT     #BIT10,R4      ;DONE?
4484 020762 001763          BEQ     1S              ;NO--BRANCH
4485 020764 104413          RESREG   ;YES, RESTORE RO-R5
4486 020766 000207          RTS      PC            ;RETURN
4487
4488 *****
4489 SBTTL CK.OCT -- CHECK FOR OCTAL CHARACTER
4490 *THIS ROUTINE IS USED TO CHECK IF AN
4491 *ASCII CHARACTER IS A DIGIT BETWEEN 0 AND 7.
4492 :CALL
4493 :
4494 :
4495 :
4496 :
4497 :
4498 020770 121127 000060    CK.OCT: CMPB     (R1),#0      ;LESS THAN ZERO?
4499 020774 103407          BLO     1S              ;YES -- BRANCH
4500 020776 121127 000067    CMPB     (R1),#7      ;GREATER THAN SEVEN?
4501 021002 101004          BHI     1S              ;YES -- BRANCH
4502 021004 111102          MOVB    (R1),R2        ;GET THE CHARACTER
4503 021006 042702 17777C    BIC     #7,R2          ;STRIP AWAY THE ASCII
4504 021012 005720          TST     (R0)+          ;ADJUST FOR RETURN
4505 021014 000200          1S:  RTS      RO          ;RETURN
4506
4507 *****
4508 SBTTL CK.DEC -- CHECK FOR DECIMAL CHARACTER
4509 *THIS ROUTINE IS USED TO CHECK AN ASCII CHARACTER
4510 *AND DETERMINE IF IT IS A DIGIT BETWEEN 0 AND 9.
4511 :CALL
4512 :
4513 :
4514 :
4515 :

```

4514
4515
4516
4517
4518 021016 121127 000060
4519 021022 103407
4520 021024 121127 000071
4521 021030 101004
4522 021032 111102
4523 021034 042702 000060
4524 021040 005720
4525 021042 000200
4526
4527
4528
4529
4530
4531
4532
4533
4534
4535
4536
4537
4538
4539
4540
4541
4542 021044 105711
4543 021046 001420
4544 021050 121127 000057
4545 021054 001414
4546 021056 121127 000054
4547 021062 001410
4548 021064 121127 000056
4549 021070 001404
4550 021072 004037 021016
4551 021076 000406
4552 021100 005720
4553 021102 005720
4554 021104 005720
4555 021106 005720
4556 021110 005720
4557 021112 005201
4558 021114 011000
4559 021116 000200
4560
4561
4562
4563
4564
4565
4566
4567
4568
4569

```

: RETURN1 ;NOT BETWEEN 0 AND 9
: RETURN2 ;BETWEEN 0 AND 9
: ;R2 = DIGIT
CK.DEC: CMPB (R1),#'0 ;LESS THAN ZERO?
BLO 1$ ;YES -- BRANCH
CMPB (R1),#'9 ;GREATER THAN NINE?
BHI 1$ ;YES -- BRANCH
MOV (R1),R2 ;GET THE CHARACTER
BIC #'0,R2 ;STRIP AWAY THE ASCII
TST (R0)+ ;ADJUST FOR RETURN
1$: RTS RO ;RETURN
```

:SBTTL CK.CHR -- CHECK CHARACTER
: *THIS ROUTINE WILL CHECK AN ASCII CHARACTER TO
: *DETERMINE WHAT IT IS.

```

:CALL
: MOV #ADR,R1 ;ADDRESS OF ASCII CHARACTER
: JSR RO,CK.CHR ;CHECK CHARACTER
: RETURN ADR1 ;UNKNOWN CHARACTER
: RETURN ADR2 ;CARRIAGE RETURN * (R1)=ADR+1
: RETURN ADR3 ;SLASH * (R1)=ADR+1
: RETURN ADR4 ;COMMA * (R1)=ADR+1
: RETURN ADR5 ;PERIOD * (R1)=ADR+1
: RETURN ADR6 ;DIGIT BETWEEN 0 AND 9.
: ;R2 = DIGIT * (R1)=ADR+1
```

```

CK.CHR: TSTB (R1) ;"CARRIAGE RETURN"?
BEQ 4$ ;YES -- BRANCH
CMPB (R1),#' / ;"SLASH"?
BEQ 3$ ;YES -- BRANCH
CMPB (R1),#',' ;"COMMA"?
BEQ 2$ ;YES -- BRANCH
CMPB (R1),#'. ;"PERIOD"?
BEQ 1$ ;YES -- BRANCH
JSR RO,CK.DEC ;"DIGIT"?
BR 5$ ;NO -- BRANCH
TST (R0)+ ;DIGIT BETWEEN 0-9
1$: TST (R0)+ ;PERIOD
2$: TST (R0)+ ;COMMA
3$: TST (R0)+ ;SLASH
4$: TST (R0)+ ;CARRIAGE RETURN
5$: INC R1 ;MOVE POINTER TO NEXT CHARACTER
MOV (R0),RO ;UNKNOWN CHARACTER
RTS RO ;RETURN
```

:SBTTL CK.DIG - CHECK DIGIT
: *THIS ROUTINE CHECKS AN ASCII STRING FOR LEGAL
: *CHARACTERS AND FORMS A DECIMAL VALUE BINARY NUMBER IN R2.

```

:CALL
: MOV #ADR,R1 ;ADDRESS OF ASCII STRING
: MOV #NUM,R2 ;MAX. MAGNITUDE OF INPUT NUMBER
: JSR RO,CK.DIG ;CHECK DIGITS
: RETURN ADR1 ;ILLEGAL CHARACTER -- R2=?
```

```

021044      15:      RETURN R0,R2      : INPUT NUMBER TO LARGE -- R2 = ?
              RETURN R0,R3      : "COMMA" -- R2 = NUMBER
              RETURN R0,R4      : "PERIOD" -- R2 = NUMBER
              RETURN R0,R5      : "PERIOD-PERIOD" -- R2 = NUMBER

              CK.DIG: MOV R1,(SP)      : SAVE R4
              R0,R1              : SAVE R3
              R0,R2              : SAVE THE MAX. SIZE ON THE STACK
              R0,R3              : START WITH 0
              R0,R4              :
              R0,R5              :
              R0,BACK.CHR        : CHECK ONE CHARACTER
              R0,BACK.CHR        : ILLEGAL CHARACTER
              R0,BACK.CHR        : CARRIAGE RETURN
              R0,BACK.CHR        :
              R0,BACK.CHR        :
              R0,BACK.CHR        : DIGIT 0-9
              R0,BACK.CHR        : #2
              R0,BACK.CHR        : SAVE #2
              R0,BACK.CHR        : #4
              R0,BACK.CHR        : #8
              R0,BACK.CHR        : (#8)+(#2)=#10
              R0,BACK.CHR        : UPDATE THE INPUT NUMBER
              R0,BACK.CHR        : CHECK ONE CHARACTER
              R0,BACK.CHR        : ILLEGAL CHARACTER
              R0,BACK.CHR        : CARRIAGE RETURN
              R0,BACK.CHR        :
              R0,BACK.CHR        :
              R0,BACK.CHR        : DIGIT 0-9
              R0,BACK.CHR        : "PERIOD"
              R0,BACK.CHR        : "COMMA"
              R0,BACK.CHR        : CHECK ONE CHARACTER
              R0,BACK.CHR        : ILLEGAL CHARACTER
              R0,BACK.CHR        : CARRIAGE RETURN
              R0,BACK.CHR        :
              R0,BACK.CHR        :
              R0,BACK.CHR        : DIGIT 0-9
              R0,BACK.CHR        : "PERIOD-PERIOD"
              R0,BACK.CHR        : "CR"
              R0,BACK.CHR        : YES--BRANCH

              R0,BACK.CHR        : WAS CHARACTER BEFORE THE DIGIT A COMMA?
              R0,BACK.CHR        : NO--EXIT
              R0,BACK.CHR        : INPUT TO LARGE?
              R0,BACK.CHR        : YES -- BRANCH
              R0,BACK.CHR        : ADJUST RETURN ADDRESS

              R0,BACK.CHR        : NUMBER TO R2
              R0,BACK.CHR        : CLEAN MAX. SIZE OFF OF STACK
              R0,BACK.CHR        : RESTORE R3
              R0,BACK.CHR        : RESTORE R4
              R0,BACK.CHR        : GET RETURN ADDRESS
              R0,BACK.CHR        : RETURN

```


4680	021440	041511	000	
4681	021440	000113	000113	
4682	021440	000000		
4683	021440	005011	050122	030461
4684	021440	000000		
4685	021440	005011	050122	042526
4686	021440	000000		
4687	021440	015012	051012	050120
4688	021440	044522	036517	000
4689	021473	020040	020040	020040
4690	021500	020040	020040	020040
4691	021500	030061	020040	030062
4692	021500	020040	030063	020040
4693	021500	020040	020040	030065
4694	021500	020040	020040	020040
4695	021500	020040	020040	020040
4696	021500	020040	020040	020040
4697	021500	020040	020040	020040
4698	021500	020040	020040	020040
4699	021500	020040	020040	020040
4700	021500	020040	020040	020040
4701	021500	020040	020040	020040
4702	021500	020040	020040	020040
4703	021500	020040	020040	020040
4704	021500	020040	020040	020040
4705	021500	020040	020040	020040
4706	021500	020040	020040	020040
4707	021500	020040	020040	020040
4708	021500	020040	020040	020040
4709	021500	020040	020040	020040
4710	021500	020040	020040	020040
4711	021500	020040	020040	020040
4712	021500	020040	020040	020040
4713	021500	020040	020040	020040
4714	021500	020040	020040	020040
4715	021642	050122	030461	043040
4716	021650	044501	042514	020104
4717	021656	047524	051040	051505
4718	021664	047520	042116	052040
4719	021672	020117	042101	051104
4720	021700	051505	044523	043516
4721	021706	000		
4722	021707	000		
4723	021714	052440	044522	042526
4724	021722	000104	051516	043101
4725	021722	000104		
4726	021724	051104	053111	020105
4727	021732	043117	046106	047111
4728	021740	000105		
4729	021742	051104	053111	020105
4730	021750	051105	047522	020122
4731	021756	052504	044522	043516
4732	021764	052040	046511	047111
4733	021772	020107	042524	052123
4734	022000	000		
4735	022001	116	020117	047111
4736	022006	042524	051122	050125
4737	022014	020124	051106	046517
4738	022022	050040	051517	052111

MSG.IC: .ASCIZ IC
 MSG.IK: .ASCIZ IK
 MSG.EQ: .ASCIZ =
 MRPCS: .ASCIZ (15)(12) RP11=
 MRVVEC: .ASCIZ (15)(12) RPVEC=
 MRPPRI: .ASCIZ (15)(12) RPPRIO=
 GRPH1: .ASCII 0 10 20 30 40 50 60 70 80 90 100/15/12/
 .ASCIZ I---I---I---I---I---I---I---I---I---I/15/12
 .EVEN
 .SBTTL ERROR HEADER (EM) MESSAGES
 EM1: .ASCIZ @RP11 FAILED TO RESPOND TO ADDRESSING@
 EM2: .ASCIZ @DRIVE UNSAFE@
 EM3: .ASCIZ @DRIVE OFFLINE@
 EM4: .ASCIZ @DRIVE ERROR DURING TIMING TEST@
 EM5: .ASCIZ @NO INTERRUPT FROM POSITIONING AFTER 1 SECOND@

4806	022603	051105	051122	050040
4807	022603	051105	051122	050040
4808	022603	051105	051122	050040
4809	022603	051105	051122	050040
4810	022610	051103	051040	041520
4811	022616	0500123		
4812	022620	051105	052123	021440
4813	022626	051105	051105	020122
4814	022634	051105	051105	051105
4815	022642	051105	051105	020040
4816	022650	051105	051504	020040
4817	022656	051105	050122	051105
4818	022664	051105	020040	050122
4819	022672	051503	000	
4820	022678	051503	000	
4821	022702	051505	051505	020124
4822	022710	050043	042440	051122
4823	022716	050040	020103	042040
4824	022722	047522	042526	043040
4825	022728	047522	020115	054503
4826	022732	020114	042504	052123
4827	022740	041440	046131	051440
4828	022746	041520	020101	020040
4829	022754	051105	041520	000101
4830	022762	052123	052123	021440
4831	022770	020040	051105	020122
4832	022776	041520	020040	051105
4833	023004	053111	020105	020040
4834	023012	050122	051504	020040
4835	023020	020040	050122	051105
4836	023026	020040	020040	050122
4837	023034	051503	020040	020040
4838	023042	050122	040503	020040
4839	023050	020040	050122	040504
4840	023056	000		
4841	023057	124	051505	020124
4842	023064	020043	042440	051122
4843	023072	050040	020103	042040
4844	023100	044522	042526	043040
4845	023106	047522	020115	054503
4846	023114	020114	042504	052123
4847	023122	041440	046131	044040
4848	023130	051105	041440	046131
4849	023136	000		
4850	023137	122	041520	020124

EM17: .ASCIZ @DRIVE NOT READY/OFFLINE DURING TIMING TEST@

.SBTTL DATA HEADER (DH) MESSAGES

DH1: .ASCIZ @ERR PC RPCS@

DH2: .ASCIZ @TEST @ ERR PC DRIVE RPDS RPER RPCS@

DH11: .ASCIZ @TEST @ ERR PC DRIVE FROM CYL DEST CYL SUCA RPCA@

DH12: .ASCIZ @TEST @ ERR PC DRIVE RPDS RPER RPCS RPCA RPD@

DH13: .ASCIZ @TEST @ ERR PC DRIVE FROM CYL DEST CYL HOR CYL@

DH13A: .ASCIZ @PPCS @PCA @RPA @SUCA@

```

48850 0233144 020040 051040 041520
48851 0233152 020040 020040 051040
48852 0233160 020040 020040 020040
48853 0233168 020040 041520 000101
48854 0233176 020040 051100 021440
48855 0233184 020040 051100 020120
48856 0233192 020040 020040 051100
48857 0233200 020040 020040 020040
48858 0233208 020040 051504 020040
48859 0233216 020040 051504 020040
48860 0233224 020040 051504 020040
48861 0233232 020040 020040 050120
48862 0233240 020040 020040 020040
48863 0233248 051503 020040 020040
48864 0233256 050122 041527 000
48865 0233264 020040 051040 041520
48866 0233272 020101 020040 051040
48867 0233280 042120 020101 020040
48868 0233288 051040 046520 020061
48869 0233296 020040 051440 041525
48870 0233304 020101 020040 051440
48871 0233312 046111 000111
48872
48873
48874
48875
48876
48877 0233336 001116 001266
48878 0233342 001204 001116 001246
48879 0233350 002004 002006 002010
48880 0233356 001204 001116 001246
48881 0233364 001254 001262 002024
48882 0233372 002016
48883 0233374 001204 001116 001246
48884 0233402 002004 002006 002010
48885 023410 002016 002020
48886 023414 001204 001116 001246
48887 023422 001254 001262 001126
48888 023430 002010 002016 002020
48889 023436 002024
48890 023440 001204 001116 001246
48891 023446 002004 002006 002010
48892 023454 002012
48893 023456 002014 002016 002020
48894 023464 002022 002024 002026
48895
48896
48897
48898 023472 000001
48899 023474 002
48900 023475 000
48901
48902 023476 000001
48903 023500 006
48904 023500 000
48905

```

DHSP: .ASCIZ QTEST # ERR PC DRIVE RPDS RPER RPCS RPWCQ

DHSPA: .ASCIZ QRPBA RPCA RPDA RPM1 SUCA SILOQ

.EVEN

.SBTTL DATA TABLE (DT)

```

DT1: .WORD $ERRPC,RPADR
DT2: .WORD $TMPD,$ERRPC,CHKDRV,$RPDS,$RPER,$RPCS
DT11: .WORD $TMPD,$ERRPC,CHKDRV,CYL.CR,CYL.DS,$SUCA,$RPCA
DT12: .WORD $TMPD,$ERRPC,CHKDRV,$RPDS,$RPER,$RPCS,$RPCA,$RPDA
DT13: .WORD $TMPD,$ERRPC,CHKDRV,CYL.CR,CYL.DS,$BDDAT
DT13A: .WORD $RPCS,$RPCA,$RPDA,$SUCA
DTSP: .WORD $TMPD,$ERRPC,CHKDRV,$RPDS,$RPER,$RPCS,$RPWC
DTSPA: .WORD $RPBA,$RPCA,$RPDA,$RPM1,$SUCA,$SILO

```

.SBTTL DATA FORMAT (DF) TABLE

```

DF1: .WORD 1 ;NUMBER OF DATA HEADERS
      .BYTE 2 ;NUMBER OF WORDS IN DATA TABLE
      .BYTE 0 ;BOTH NUMBERS ARE OCTAL
DF2: .WORD 1
      .BYTE 6
      .BYTE 0

```

4906	023502	000001	DF11:	.WORD	1	
4907	023503	000		.BYTE	0	
4908	023505	000		.BYTE	0	
4909						
4910	023506	000001	DF12:	.WORD	1	
4911	023510	010		.BYTE	0	
4912	023511	000		.BYTE	0	
4913						
4914	023512	000002	DF13:	.WORD	2	: 2 DM'S TO BE TYPED
4915	023514	006		.BYTE	0	
4916	023515	000		.BYTE	0	
4917	023516	023137		.WORD	0	DM13A
4918	023520	004		.BYTE	0	
4919	023521	000		.BYTE	0	
4920						
4921	023522	000002	DFSP:	.WORD	2	
4922	023524	007		.BYTE	0	
4923	023525	000		.BYTE	0	
4924	023526	023261		.WORD	0	DHSPA
4925	023530	006		.BYTE	0	
4926	023531	000		.BYTE	0	
4927						
4928			.EVEN			
4929						
4930	023532	023174	ETSP:	.WORD	0	: MESSAGE BLOCK FOR SWITCH 6 TYPEOUTS
4931	023534	023440		.WORD	0	
4932	023536	023522		.WORD	0	
4933						
4934	023540	000030	BUFR4:	.BLKW	24.	: WORKING LOCATIONS FOR SEEK TIMER TEST
4935	023620	000030	BUFR5:	.BLKW	24.	
4936	023700	000030	BUFR6:	.BLKW	24.	
4937	023760	000030	BUFR7:	.BLKW	24.	
4938	024040	000626	FRWSTR:	.BLKW	406.	
4939	025514	000626	RVSTR:	.BLKW	406.	
4940		027170	BUFFER=			
4941						
4942		000000	.END			

020000
001314
001324
000001
000001
000002
000004
000010
000020
000040
000100
000200
000400
001000
000002
000002
002000
004000
010000
020000
040000
100000
000004
000010
000020
000040
000100
000200
000400
001000
002044
002043
002042
002041
002040
002037
002036
002035
002034
002033
002030
000014
027170
023540
023620
023700
023760
001224
001244
001246
104407
021044
021016
021120

CK.NUM 021300
CK.OCT 020770
CLEAR = 000001
CLOSE 020710
CMPGRP 007332
CNTRLC 001222
CR = 000015
CRLF = 000200
CSMC = 000040
CYL.CR 001254
CYL.DS = 001262
DISP = 177570
DECSK = 004462
DFLY 001460
DFSP 023522
DF1 023472
DF11 023502
DF12 023506
DF13 023512
DF2 023476
DHSP 023174
DHSPA 023261
DH1 023260
DH11 023267
DH12 023262
DH13 023057
DH13A 023137
DH2 022620
DISPLA 001142
DISPRE 000174
DPB 001364
DRVBAD 001252
DRVMSK 001250
DRVOK 003750
DRVSEL 001232
DRVSTA 001304
DRVSTY 001240
DSELECT 015272
DSKERR = 000001
DSWR = 177570
DTSP 023440
DTSPA 023456
DT1 023336
DT11 023356
DT12 023374
DT13 023414
DT13A 023430
DT2 023342
EMTVEC = 000030
EM1 021642
EM10 022166
EM11 022226
EM12 022272

M13 022337
M14 022240
M15 022244
M16 022246
M17 022246
M2 022170
M3 022172
M4 022174
M5 022200
M6 022205
M7 022113
MOP = 100000
RR = 100000
RVEVC = 000004
TSP 023532
XITO 004154
XIT1 004312
XIT10 006304
XIT11 006616
XIT12 007472
XIT2 004504
XIT3 004654
XIT4 005216
XIT5 005640
XIT6 005636
XIT7 006030
XC 001376
XC1 001644
XC11 001774
XC2 001660
XC3 001674
XC4 001710
XC5 001724
XC6 001740
XC7 001754
FMTE = 001000
FRWSTR = 024040
FUUV = 040000
GETADR 017256
GETNUM 017460
GOTYPE 016130
GRPH1 021473
GTSWR = 104406
GTTST1 017742
GTTST2 020014
GTTST3 020162
GTTST4 020164
GTTST5 020236
GTTST6 020266
GT.PRM 017610
GT.PR1 017612
GT.PR2 017736
HDR = 004000

HE = 040000
HNF 010000
HOMSEK = 000015
HT = 000011
IC = 001402
IC1 001650
IC2 001664
IC3 001700
IC4 001714
IC5 001730
IC6 001744
IC7 001760
IDE = 000100
INAOR 001226
INCSK = 004432
IOTVEC = 000020
LC 001400
LC1 001646
LC11 001776
LC2 001662
LC3 001676
LC4 001712
LC5 001726
LC6 001742
LC7 001756
LF = 000012
LPE = 000200
MAXCYL 001236
MODE = 010000
MODERR = 000400
MRPCS 021440
MRPPRI 021461
MRPVEC 021450
MSG.FD 021436
MSG.FC 021422
MSG.IC 021430
MSG.LC 021425
MSG.R 021420
MSG.TK 021433
MXSTAL 001302
NXC = 020000
NXME = 000004
NXS = 004000
NXT = 010000
OPNPRM 020442
OPNTST 020310
OPN.CT 020314
OPN.N1 020630
OPN.N2 020634
OPN.X1 020646
OPN.X2 020652
OPN.1 020320
OPN.2 020342

OUTADR 001230
PIRG 177772
PIRGVE = 000240
PLCT 006770
PLTPT 007432
PRM 001372
PRMLMT 001434
PRMSG 001446
PRMPT 001406
PRMO 001632
PRM1 001640
PRM10 001764
PRM11 001770
PRM12 002000
PRM2 001654
PRM3 001670
PRM4 001704
PRM5 001720
PRM6 001734
PRM7 001750
PROG = 002000
PR0 000000
PR1 000040
PR2 = 000100
PR3 = 000140
PR4 = 000200
PR5 = 000240
PR6 = 000300
PR7 = 000340
PS = 177776
PSW = 177776
PWAVEC = 000024
RDCHAR = 104410
ROLIN = 104411
RDSEK = 000005
ROY = 000200
REAC = 000017
RESREG = 104413
RESTAR = 003426
RESTOR = 015314
RESTR1 = 015530
RESVEC = 000010
RPADR = 001266
RPBA = 000010
RPCA = 000012
RPCS = 000004
RPDA = 000014
RPDS = 000000
RPER = 000002
RPINIT = 013642
RPM1 = 000016
RPM2 = 000020
RPM3 = 000022

RPPRI0	001272	STR2A	002274	TIMSK2	017066	SCM4	= 000001	\$REGAD	001160
RPT	001374	STR20X	001264	TK	001404	\$CNTLC	012463	\$REGO	001162
RPT0	001634	SUCA	= 000024	TKVEC	= 000060	\$CNTLC	012475	\$REG1	001164
RPT1	001642	SUFU	= 001000	TK0	001636	\$CNTLU	012470	\$REG10	001202
RPT10	001766	SUOL	= 040000	TK1	001652	\$CRLF	001217	\$REG2	001166
RPT11	001772	SURDY	= 100000	TK2	001666	\$DBLK	011234	\$REG3	001170
RPT12	002002	SURP03	= 020000	TK3	001702	\$DB2D	013304	\$REG4	001172
RPT2	001656	SUSI	= 004000	TK4	001716	\$DECVL	013464	\$REG5	001174
RPT3	001672	SUSU	= 002000	TK5	001732	\$DOAGN	007732	\$REG6	001176
RPT4	001706	SUWP	= 000400	TK6	001746	\$DTBL	011224	\$REG7	001200
RPT5	001722	SWR	001140	TK7	001762	\$ENDAD	007722	\$RESRE	013014
RPT6	001736	SWREG	000176	TPVEC	= 000064	\$ENDCT	007656	\$RPBA	002014
RPT7	001752	SW0	= 000001	TRAPVE	= 000034	\$ENULL	007736	\$RPCA	002016
RPVEC	001270	SW00	= 000001	TRK.RO	001256	\$EOP	007474	\$RPCS	002010
RPWC	= 000006	SW01	= 000002	TRTVEC	= 000014	\$EOPCT	007650	\$RPOA	002020
RSTRT1	003704	SW02	= 000004	TSTNMS	001234	\$ERFLG	001103	\$RPOS	002004
RSTRT2	003716	SW03	= 000010	TST0	004034	\$ERMAX	001115	\$RPER	002006
RSTRT3	003724	SW04	= 000020	TST1	004156	\$ERROR	007742	\$RPM1	002022
RVSTR	025514	SW05	= 000040	TST10	006032	\$ERRPC	001116	\$RPMC	002012
R6	= 000006	SW06	= 000100	TST11	006306	\$ERRTB	002046	\$RTNAD	007734
R7	= 000007	SW07	= 000200	TST12	006620	\$ERTTL	001112	\$SAVRE	012756
SAVREG	= 104412	SW08	= 000400	TST2	004314	\$ESCOP	001210	\$SB2D	013250
SAVRP	015164	SW09	= 001000	TST3	004506	\$FILLC	001156	\$SCOPE	C12524
SEC.RO	001260	SW1	= 000002	TST4	004656	\$FILLS	001155	\$SETUP	= 000107
SEEK	= 000011	SW10	= 002000	TST5	005220	\$GADR	001120	\$SILO	002026
SEEKS	014036	SW11	= 004000	TST6	005406	\$GODAT	001124	\$STUP	= 177777
SEEKSO	014064	SW12	= 010000	TST7	005640	\$GET42	007712	\$SUCA	002024
SEEKS1	014314	SW13	= 020000	TYPOS	= 104405	\$GTSWR	011632	\$SUPRS	013500
SEEKS2	014400	SW14	= 040000	TYPE	= 104401	\$HD	= 000000	\$SVLAD	012712
SEEKS3	014462	SW15	= 100000	TYPERR	010114	\$HINUM	013636	\$SVPC	= 000200
SEEKS4	014520	SW2	= 000004	TYPOC	= 104402	\$ICNT	001104	\$SWR	= 167000
SILO	= 000026	SW3	= 000010	TYPON	= 104404	\$INTAG	001135	\$SLRMK	= 000000
SKDON	017172	SW4	= 000020	TYPOS	= 104403	\$ITEMB	001114	\$TIMES	001206
SMGRP	007162	SW5	= 000040	TYPTIM	016364	\$LF	001220	\$TKB	001146
SORT	015660	SW6	= 000100	VERFY0	014600	\$LONUM	013640	\$TKCNT	011244
SPSAV	001242	SW7	= 000200	VERFY1	015154	\$LPADR	001106	\$TKINT	011254
SRTINT	002734	SW8	= 000400	VERIFY	014554	\$LPERR	001110	\$TKGEN	= 011253
STACK	= 001100	SW9	= 001000	WCE	= 000010	\$MNEW	012513	\$TKQIN	011246
STALL	015576	TBITVE	= 000014	WCKSEK	= 000007	\$MSWR	012502	\$TKQOU	011250
STALLA	015572	TEST0	004144	WPE	= 000100	\$MUL	= 000003	\$TKQSR	011252
STALLB	015624	TEST1	004262	WPV	= 100000	\$MULT	013052	\$TKS	001144
STALLG	001300	TEST10	006130	WRITE	= 000013	\$MXCNT	012754	\$TKSRV	011324
STALLO	001274	TEST11	006404	WRTSEK	= 000003	\$NULL	001154	\$TMP0	001204
STALL1	001276	TEST12	006716	\$AUTOB	001134	\$NWTST	= 000001	\$TN	= 000013
START	002302	TEST2	004420	\$BDADR	001122	\$OCNT	011014	\$TNPWR	013414
START1	002246	TEST3	004612	\$BDADR	001126	\$OMODE	011016	\$TPB	001152
START2	002270	TEST4	004776	\$BELL	001212	\$OVER	012740	\$TPFLG	001157
START3	002236	TEST5	005324	\$CHARC	010566	\$PASS	001100	\$TPS	001150
START4	002260	TEST6	005512	\$CKSWR	011542	\$QUES	001216	\$TRAP	013164
START5	002720	TEST7	005744	\$CMTAG	001100	\$RAND	013540	\$TRAP2	013206
START6	003442	TIMEE	= 000020	\$CM1	= 000011	\$RDCR	012104	\$TRP	= 000014
STKMT	= 177774	TIMSEK	016526	\$CM2	= 000022	\$ROLIN	012174	\$TRPAD	013220
STRT1A	002252	TIMSK1	016550	\$CM3	= 000011	\$RDSZ	= 000033	\$TSTNM	001102

K08

MD-11-DZRPZ-C, RPIIE DRIVE POSITIONING TEST MACY11 30(1046) 06-SEP-77 16:32 PAGE 103
DZRPZC.P11, 06-SEP-77 16:08 SYMBOL TABLE

SEG 0101

\$TYIN	012430	\$TYPEC	010522	\$TYPON	010632	\$SGET4	= 000000
\$TYPOS	011020	\$TYPEX	010570	\$TYPOS	010572	\$OFILL	= 011015
\$TYPE	010352	\$TYPOC	010616	\$XTSTR	012536	.	= 027170

. ABS. 027170 000

ERRORS DETECTED: 0

DSKW:DZRPZC, DSKW:DZRPZC/SOL=DSKW:SYSMAC.SML, DSKM:DZRPZC.P11
RUN-TIME: 14 19 .6 SECONDS
RUN-TIME RATIO: 144 34=4.1
CORE USED: 35k (.69 PAGES)

L08