

TM03/TE16

DATA RELIABILITY TEST
MD-11-DZTED-A

EP-DZTED-A-DL-A
COPYRIGHT © 1977
FICHE 1 OF 1

JUN 1977
digital
MADE IN USA

16

801

EOF1DZTECASEQ

00010000

770526

POP10 411

HDR1DZTEDASEQ

00010000

770526

.REM %

IDENTIFICATION

| | |
|----------------|------------------------------------|
| PRODUCT CODE: | MAINDEC-11-DZTED-A-D |
| PRODUCT TITLE: | TMO3/TE16 DATA RELIABILITY PROGRAM |
| DATE CREATED: | 21 FEB 1977 |
| MAINTAINER: | DIAGNOSTIC GROUP |
| AUTHOR: | J. G. ADAMS |

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (c) 1977, BY DIGITAL EQUIPMENT CORPORATION

TABLE OF CONTENTS

| PARAGRAPH | SUBJECT | PAGE |
|-----------|---------------------|------|
| 1. | ABSTRACT | 3 |
| 2. | REQUIREMENTS | 3 |
| 3. | LOADING PROCEDURE | 3 |
| 4. | STARTING PROCEDURE | 4 |
| 5. | DATA PATTERNS | 11 |
| 6. | RANDOMIZATION | 12 |
| 7. | DYNAMIC PARAMETERS | 13 |
| 8. | CONSOLE SWITCH | 14 |
| 9. | ERROR PRINTOUTS | 19 |
| 10. | STATISTICS PRINTOUT | 27 |
| 11. | AUTO SEQUENCE | 28 |
| 12. | TESTING PROCEDURES | 30 |
| 13. | LISTING | 32 |

1. ABSTRACT

THIS PROGRAM IS DESIGNED TO BE USED BY AN EXPERIENCED ENGINEER /TECHNICIAN FOR EVALUATION AND DEBUGGING OF MAG TAPE DRIVES. THE PROGRAM IS CAPABLE OF EXERCISING THE TE16 MAGNETIC ON A MASSBUS THROUGH THE TMD3 MAG TAPE CONTROLLER. ANY COMBINATION OF TMD3'S & TE16'S UP TO A MAXIMUM OF EIGHT (8), MAY BE TESTED BY A SINGLE EXECUTION OF THE PROGRAM. THIS FLEXIBILITY IS POSSIBLE BECAUSE THE PROGRAM HAS NO FIXED PARAMETERS OR TESTING SEQUENCE. THE ENTIRE TEST PLAN, INCLUDING PARAMETERS AND OPERATING SEQUENCE, IS DETERMINED BY THE OPERATOR THROUGH RESPONSES TO TELETYPE REQUESTS AND SETTING OF CONSOLE SWITCHES.

THE PROGRAM PROVIDES FOR TESTING OF ALL TAPE DRIVE FUNCTIONS SUCH AS WRITING, READING, REWINDING, TAPE POSITIONING, EOT - BOT SENSING AND ASSUMES A GOOD RH AND TMD3.

HOWEVER; THE RH AND TMD3 ARE TESTED SOMEWHAT INTRINSICALLY DURING THE TEST CYCLE IN ORDER TO PROVIDE FULL INFORMATION ABOUT ANY ERROR CONDITIONS DETECTED.

DURING A TEST CYCLE, CHECKS ARE MADE FOR STATUS ERRORS, DATA ERRORS, POSITION ERRORS, WORD COUNT AND CURRENT MEMORY ADDRESS ERRORS WHEREVER APPLICABLE AS DETECTED BY THE RH OR TMD3.

2. REQUIREMENTS (HARDWARE)

- A. ANY PDP-11 PROCESSOR
- B. 8K OF CORE
- C. TELETYPE
- D. TMD3 TAPE CONTROLLER
- E. 1 TO 8 MAG TAPE DRIVES
- F. MASSBUS CONTROLLER

3. LOADING PROCEDURE

USE STANDARD PROCEDURE FOR LOADING BINARY TAPES

4. STARTING PROCEDURE

THERE ARE FOUR (4) STARTING ADDRESSES THAT MAY BE USED;
200(8), 204(8), 210(8), AND 240(8):

- A. 200(8): THIS ADDRESS MUST BE USED ON INITIAL START FROM LOAD AS ALL PARAMETERS ARE ENTERED FROM HERE. REQUESTS ARE PRINTED ON THE TELETYPE FOR ENTRY OF RH STARTING ADDRESS, VECTOR ADDRESS, DRIVE NUMBER (TM03 ADDRESS), SLAVE NUMBER, DENSITY, PARITY, FORMAT, RECORD COUNT, CHARACTER COUNT, PATTERN NUMBER, TAPE MARK AND STALL FOR READ, WRITE, AND TURNAROUND. ALL RESPONSES SHOULD BE MADE IN OCTAL AND WITHIN THE LIMITS OF THE PARAMETER. A QUESTION MARK (?) WILL BE TYPED IF ANY CHARACTER ENTERED IS NOT BETWEEN 0 THRU 7 (OCTAL). THE CHARACTER MAY BE RETYPED FOLLOWING THE QUESTION MARK. IF THE RESPONSE IS NOT WITHIN ITS LIMITS. A QUESTION MARK (?) IS TYPED AND THE ENTIRE RESPONSE MAY BE REENTERED. SOME RESPONSES REQUIRE MORE THAN ONE (1) CHARACTER, BUT NONE REQUIRES MORE THAN SIX (6). RESPONSES OF MORE THAN ONE CHARACTER NEED NOT HAVE LEADING ZEROS AND SHOULD BE TERMINATED BY A CARRIAGE RETURN IF LESS THAN THE MAXIMUM NUMBER OF CHARACTERS IS INPUT.
- B. 204(8): THIS ADDRESS SHOULD BE USED ANYTIME A RESTART OF THE PROGRAM IS NECESSARY AND THE PARAMETERS ENTERED AT THE INITIAL START OF 200(8) NEED NOT BE CHANGED. ALSO NOTE THAT ANY DATA PATTERN WHICH HAD BEEN GENERATED BY SETTING THE RANDOM DATA SWITCH (CONSOLE SWITCH EIGHT) WILL NOT BE OVERWRITTEN AND THEREFORE IS HELD IN CORE FOR USE UNTIL CONSOLE SWITCH EIGHT(8) IS AGAIN SET AND THAT ALL STATISTICS WILL BE RETAINED.
- C. 210(8): THIS ADDRESS IS THE SAME AS USING 204(8) IN THAT THE PREVIOUSLY SET PARAMETERS ARE USED; HOWEVER, THE DATA PATTERN IS RETURNED TO THE FIXED PATTERN ORIGINALLY CALLED FOR AT THE 200(8) START AND ALL STATISTICS ARE CLEARED TO ZERO.
- D. 240(8): THIS IS A SPECIAL ADDRESS WHICH WILL CAUSE THE PROGRAM TO EXECUTE A PREDETERMINED TEST PLAN ON ALL AVAILABLE DRIVES AND SLAVES. THE ONLY INPUT REQUIRED BY THE OPERATOR IS A RESPONSE TO REQUESTS FOR THE RH ADDRESS, VECTOR ADDRESS, CONTINUOUS OPERATION OF THE SEQUENCE, AND NRZ ONLY.
- E. 300(8): THIS ADDRESS IS TO BE USED AS A RESTART ONLY AND WILL PERFORM JUST AS IN 200(8) EXCEPT THAT THE PARAMETER INPUT LIST IS SHORTENED. THE SHORT PARAMETER LIST CONSISTS OF DRIVE NUMBER, SLAVE NUMBER, DENSITY, PARITY, FORMAT, RECORD COUNT, CHARACTER COUNT, PATTERN, TAPE MARK, AND

INTERCHANGE READ.
**NOTE SEE ALSO SECTION 8-CONSOLE SWITCH SETTINGS

THE FOLLOWING IS AN EXPLANATION OF THE INITIAL
START (200 OCTAL) REQUESTS AND RESPONSES:

REGISTER START: THE RESPONSE REQUIRED FOR THIS REQUEST
IS TO ENTER THE ADDRESS OF THE FIRST RH
REGISTER (CS1) AS A SIX DIGIT UNIBUS ADDRESS.

VECTOR ADDRESS: THE RESPONSE FOR THIS REQUEST
IS TO ENTER THE INTERRUPT VECTOR ADDRESS
USED BY THE RH AS A THREE (3) DIGIT ADDRESS.

DRIVE NUMBER: THE DRIVE NUMBER (MASSBUS ADDRESS
OF THE TM03) IS ENTERED AS ONE (1)
OCTAL CHARACTER AND MUST BE WITHIN THE LIMITS
OF 0 THROUGH 7.

SLAVE NUMBER: THE SLAVE NUMBER IS ENTERED AS ONE
(1) OCTAL CHARACTER AND MUST BE
WITHIN THE LIMITS OF 0 THROUGH 7.
WHEN THE SLAVE NUMBER HAS BEEN
ENTERED AND IS LEGAL, THE PROGRAM TESTS
FOR THE PRESENCE OF A SLAVE OF THAT
NUMBER. IF THE SLAVE IS AVAILABLE
A PRINTOUT OF 7 CHANNEL, IF APPLICABLE,
AND ITS SERIAL NUMBER (IN BCD)
WILL BE MADE TO ASSIST THE OPERATOR
IN SETTING OF DENSITY, PARITY, AND FORMAT.
A CHECK IS MADE FOR THE PROPER SETTING
OF THE DRIVE TYPE REGISTER; IF WRONG, A
MESSAGE IS PRINTED FOR INFORMATION ONLY.
IF THE SLAVE IS NOT AVAILABLE,
A MESSAGE STATING SO WILL BE
PRINTED AND A NEW SLAVE NUMBER
REQUEST WILL BE ISSUED. WHEN A
GOOD SLAVE NUMBER HAS BEEN ENTERED,
REQUESTS FOR OPERATING DENSITY
PARITY AND FORMAT ARE MADE FOR THAT
SLAVE AND SHOULD BE RESPONDED TO
ACCORDING TO THAT PARTICULAR SLAVE'S
NEEDS. AS MANY AS EIGHT (8) SLAVE
NUMBER REQUESTS MAY BE USED, HOW-
EVER, AT LEAST ONE MUST BE USED.
THE SLAVE NUMBERS AND THEIR RESPECTIVE
DENSITY, PARITY AND FORMAT MAY BE ENTERED
IN ANY ORDER. THE INFORMATION FOR
EACH SLAVE ENTERED IS LOADED INTO A
TABLE FOR REFERENCE IN TESTING.
IF LESS THAN EIGHT(8) SLAVES ARE
REQUIRED, THEN RESPONDING TO THE
SLAVE NUMBER REQUEST WITH A CARRIAGE
RETURN WILL TERMINATE THE SLAVE
ENTRIES AND CONTINUE TO THE NEXT
PARAMETER. IT SHOULD BE REMEMBERED

H01

TMD3/TE16 DATA RELIABILITY PROGRAM
DZTEDA.P11 07-APR-77 13:36

MACY11 27(1006) 07-APR-77 13:36 PAGE 6

THAT AT LEAST ONE SLAVE NUMBER REQUEST
MUST BE ENTERED. IF THE FIRST
REQUEST IS RESPONDED TO BY A CARRIAGE
RETURN, THEN THE REQUEST WILL BE REPEATED.

4.1 AUTOMATIC MODE OPERATION

IF THE PROGRAM IS LOADED AND RUN IN AUTOMATIC (CHAIN) MODE
THE AUTO ACCEPT SEQUENCE TEST PLAN IS RUN. SEE SEC 11. BELOW;
THE SOFTWARE SWR IS INVOKED WITH A SWITCH SETTING OF 10000 (HALT
ON ERROR) IF LOADED VIA ACT11. NO OPERATOR INTERVENTION IS REQUIRED.

**EXCEPTION: IF THIS PROGRAM IS LOADED VIA TMDP CHAIN MODE THE
PROGRAM WILL TEST ALL SLAVES ON THE FIRST AVAILABLE
DRIVE EXCEPT SLAVE 0.

- DENSITY:** THE DENSITY REQUEST IS RESPONDED TO BY ONE (1) OCTAL CHARACTER AND MUST BE WITHIN THE LIMITS OF 0 THRU 4. AS EACH SLAVE NUMBER IS ENTERED, A REQUEST FOR THE OPERATING DENSITY FOR THAT SLAVE IS TYPED. THE RESPONSE MEANINGS ARE AS FOLLOWING:
- A. 3 = 800BPI, NRZI
 - B. 4 = 1600BPI, PE (9 CHANNEL ONLY)
- PARITY:** THE PARITY REQUEST IS RESPONDED TO BY ONE (1) OCTAL CHARACTER AND MUST BE EITHER 0 OR 1.
- A. 1 = EVEN PARITY
 - B. 0 = ODD PARITY
- FORMAT:** THE FORMAT REQUEST IS RESPONDED TO BY TWO (2) CHARACTERS AND SHOULD BE AS FOLLOWS
- A. 14 = 9 CHANNEL NORMAL (TWO FRAMES PER WORD)
 - B. 15 = CORE DUMP (FOUR FRAMES PER WORD)
 - C. 16 = PDP-15 OR IBM COMPATIBLE (TWO FRAMES PER WORD)
(DATA IS BYTE SWAPPED ON TAPE)
- RECORD COUNT:** THIS REQUEST IS RESPONDED TO BY A SIX (6) CHARACTER OCTAL NUMBER FROM 1 TO 177777. REMEMBER LEADING ZEROS ARE NOT REQUIRED AND IF LESS THAN SIX CHARACTERS ARE ENTERED, A CARRIAGE RETURN WILL TERMINATE THE RESPONSE. THE RECORD COUNT IS USED IN CONJUNCTION WITH THE CHARACTER COUNT TO ESTABLISH A BLOCKING FACTOR FOR USE IN READ OR WRITE CYCLES.
- CHARACTER COUNT:** THIS RESPONSE IS ENTERED AS FOUR (4) OCTAL CHARACTERS WITHIN THE LIMITS OF 20 THRU 4000. AGAIN LEADING ZEROS ARE NOT REQUIRED AND A CARRIAGE RETURN TERMINATES A LESS THAN FOUR (4) CHARACTER RESPONSE. THE CHARACTER COUNT IN CONJUNCTION WITH THE RECORD COUNT IS USED TO ESTABLISH THE BLOCK SIZE (CHARACTERS PER RECORD, AND RECORDS PER BLOCK) USED IN READ AND WRITE CYCLES. THE SAME BLOCKING IS USED ON ALL AVAILABLE UNITS.

PATTERN NUMBER: THIS RESPONSE IS A TWO (2) CHARACTER OCTAL NUMBER WITHIN THE LIMITS OF 0 THRU 15(8). THE NUMBER ENTERED WILL CAUSE A SPECIFIC DATA PATTERN TO BE USED FOR ALL READING AND WRITING. THIS DATA PATTERN IS NOT CHANGED UNLESS RANDOM DATA IS REQUESTED BY SETTING CONSOLE SWITCH EIGHT (8) TO A ONE. RESETTNG OF THE RANDOM DATA SWITCH DOES NOT CAUSE REVERSION TO THE FIXED PATTERN, BUT WILL HOLD THE LAST GENERATED PATTERN UNTIL A RESTART IS DONE FROM LOCATION 200(8), 210(8), OR 300(8). WHEN OPERATING IN NRZ MODE (DENSITY 0-3) THE PROGRAM CONSTRUCTS AND SAVES BOTH AN EXPECTED CRC CHARACTER AND AN LRC CHARACTER FOR COMPARISONS WITH THE HARDWARE GENERATED CHECK CHARACTER IN BOTH READ AND WRITE. THE SELECTION OF DATA PATTERN ZERO (0) HAS A SPECIAL USE. PATTERN NUMBER ZERO (0) WILL CAUSE TO BE READ IN AT THE HIGH SPEED PAPER TAPE READER ANY DATA PATTERN DESIRED. THE EXTERNAL INPUT DATA THROUGH THE READER IS DONE BY PREPARING A PAPER TAPE WITH A PROGRAM CALLED DTC. (MAINDEC-11-DZTUF-A-0) ANY CONFIGURATION OF BITS AND CHARACTERS MAY BE USED AND A LIMIT OF 377(8) CHARACTERS IS IMPOSED. WHEN EXTERNAL DATA IS INPUT, THE ENTIRE WRITE BUFFER IN CORE IS FILLED WITH THE PATTERN SO THAT ANY SIZE RECORD MAY BE USED. DATA PATTERN ZERO (0) EXTERNAL PAPER TAPE NEED ONLY BE READ ONCE AT INITIAL START OF 200(8), AND NEED NOT BE READ AGAIN UNLESS OVERWRITTEN BY RANDOM DATA. BE SURE TO LOAD THE READER BEFORE PRESSING START.

TAPE MARK: THE TAPE MARK REQUEST IS USED TO DETERMINE IF THE OPERATOR WISHES TO HAVE EACH DATA BLOCK SEPERATED BY A TAPE MARK. IF RESPONDED TO BY A ONE (1) THE TAPE MARK WILL BE WRITTEN AND WHEN READING WILL BE EXPECTED AT THE END OF DATA BLOCK. A ZERO (0) RESPONSE WILL DISALLOW TAPE MARK. PLEASE NOTE THAT THE TAPE MARK RECORD INCREASES THE BLOCK SIZE BY ONE (1) RECORD; IN OTHER WORDS, A BLOCK OF 100 RECORDS WILL HAVE THE TAPE MARK AS RECORD 101.

INTERCHANGE READ: THIS REQUEST IS RESPONDED TO BY A SINGLE CHARACTER INPUT OF EITHER ONE (1) OR ZERO (0). A RESPONSE OF ONE (1) WILL CAUSE ALL READING TO BE DONE IN THE INTERCHANGE MODE. A ZERO RESPONSE WILL CAUSE READING IN NORMAL MODE.

SINGLE PASS: THIS REQUEST IS RESPONDED TO BY EITHER A ONE (1) OR A ZERO (0). RESPONSE OF 1, WILL CAUSE THE TEST TO BE STOPPED AFTER THE LAST AVAILABLE DRIVE REACHES END OF TAPE. A RESPONSE OF 0, WILL ALLOW CONTINUOUS RUNNING THROUGH MULTIPLE PASSES. TO RESTART AT END OF PASS, PRESS CONTINUE, OR RESTART AT THE CONSOLE.

STALLS: THE STALL REQUESTS ARE RESPONDED TO BY A SIX (6) CHARACTER OCTAL NUMBER WITHIN THE LIMITS OF 1 THRU 177777. LEADING ZEROS ARE NOT REQUIRED AND AN ENTRY OF LESS THAN SIX (6) CHARACTERS SHOULD BE TERMINATED BY A CARRIAGE RETURN. EACH INCREMENT OF THE VALUE ADDS ABOUT 2.6 MICSEC TO THE DELAY.

READ: THE TIME DELAY BETWEEN EACH RECORD READ

WRITE: THE TIME DELAY BETWEEN EACH RECORD WRITTEN

TURN AROUND: TIME DELAY BETWEEN CHANGES OF TAPE DIRECTION (FORWARD, TO REVERSE, ETC.) AND BETWEEN BLOCKS.

FIXED PARAMETERS: IT SHOULD BE NOTED THAT ALL PARAMETERS EXCEPT FOR THE SLAVE DESCRIPTION VALUES (SLAVE NUMBER, DENSITY, PARITY, AND FORMAT) HAVE NOMINAL VALUES ALREADY STORED IN THE PROGRAM. COUNT, CHARACTER COUNT, TAPE MARK AND STALLS) IS TYPED. ITS PRESENT STORED VALUE IS ALSO PRINTED. IF THESE VALUES NEED NOT BE CHANGED, SIMPLY TYPE A CARRIAGE RETURN AS RESPONSE AND NO CHANGE WILL BE MADE. EACH START OF THE PROGRAM AT 200(8) WILL SHOW THE CURRENT VALUES OF THESE PARAMETERS AS PER THE LAST ENTRY. WHEN A FRESH LOAD OF THE PAPER TAPE IS DONE, THE PARAMETERS WILL REFLECT THE FIXED VALUES STORED IN THE PROGRAM.

A. RECORD COUNT = 100
B. CHARACTER COUNT = 200
C. PATTERN NUMBER = 1
D. TM=0
E. INTERCHANGE READ = 0
F. SINGLE PASS = 0
G. READ STALL = 1
H. WRITE STALL = 1
I. TURN AROUND STALL = 1

SAMPLE START AT 200(8):

THE FOLLOWING IS A SAMPLE OF THE
PRINTED REQUESTS AND THEIR RESPONSES.
RESPONSES ARE ENCLOSED IN PARENS FOR
CLARITY ONLY AND (CR) MEANS CARRIAGE RETURN

LOAD ADDRESS 200(8), SET CONSOLE SWITCHES, PRESS START SWITCH:

TE16 TAPE DRIVE TEST

REGISTER START=172440(172440)
VECTOR ADDRESS=224(CR)
DRIVE NUMBER (4)
SLAVE NUMBER=(5) SN: 5009
DENSITY=(3)
PARITY=(0)
FORMAT=(14)
SLAVE NUMBER=(2) 9 CHAN SN: 0022
DENSITY=(3)
PARITY=(1)
FORMAT=(15)
SLAVE NUMBER=(CR)
RECORD COUNT=100 (500)(CR)
CHARACTER COUNT=200 (38)?(7)(CR)
PATTERN NUMBER=1 (22)
?
(6)(CR)
TH=(0)
INTERCHANGE READ=(1)
SINGLE PASS=(0)

ENTER STALLS
READ=1 (CR)
WRITE=1 (CR)
TURN AROUND=1 (3000)(CR)

THE PROGRAM WILL NOW PERFORM THE TEST CYCLE SET IN
THE CONSOLE SWITCHES ON SLAVE FIVE (5) THEN TWO (2),
ONE BLOCK ON EACH UNIT PER CYCLE, USING DATA PATTERN
NUMBER SIX (6) WITH A BLOCKING FACTOR OF 37 CHARACTERS
PER RECORD AND 500 RECORDS PER BLOCK. THE DELAYS ARE SET
FOR MINIMUM ON READ AND WRITE, AND APPROXIMATELY .75
SECONDS ON TURN AROUND.

NO TAPE MARKS WILL BE WRITTEN AND ALL READING
WILL BE DONE IN INTERCHANGE MODE (MAINT MODE 0001).

5. DATA PATTERNS

THERE ARE FIFTEEN DATA PATTERN GENERATORS STORED IN CORE AND ANY ONE OF THESE MAY BE SELECTED. THE ONE UNIQUE CASE IS PATTERN ZERO(0); SELECTION OF PATTERN ZERO(0) REQUIRES THAT A PREVIOUSLY PREPARED PAPER TAPE BE ENTERED AT THE HIGH SPEED READER. THIS TAPE CONTAINS A DATA PATTERN OF NO MORE THAN 377 OCTAL CHARACTERS. THE FIRST CHARACTER READ IN IS THE NUMBER OF ACTUAL DATA CHARACTERS THAT ARE CONTAINED ON THE TAPE. EACH DATA CHARACTER MAY BE ANY COMBINATION OF BITS AND WILL BE LOADED INTO CORE AS THEY APPEAR ON THE TAPE. NO MATTER HOW MANY CHARACTERS ARE ON TAPE, THE ENTIRE WRITE BUFFER (4000 CHARACTERS) WILL BE FILLED WITH THE PATTERN ENTERED SO THAT ANY SIZE RECORD CAN BE USED. (SEE DTC MAINDEC-11-DZTUF-A-D) THE PROGRAM GENERATES A CYLIC REDUNDENCY CHECK CHARACTER (CRC) AND A LONGITUDINAL REDUNDENCY CHECK CHARACTER (LRC) FOR COMPARISONS AGAINST THE CRC AND LRC GENERATED BY THE HARDWARE IN NRZI READS OR WRITES.

THE FOLLOWING IS A LIST OF THE DATA PATTERNS AVAILABLE:

DATA0: EXTERNAL INPUT THRU HIGH SPEED READER (SEE DTC)
 DATA1: ALL ONE BITS IN ALL CHARACTERS
 DATA2: ALL ZERO BITS IN ALL CHARACTERS
 DATA3: A ONE BIT WALKING FROM RIGHT TO LEFT IN A FIELD OF ZEROS
 DATA4: A ZERO BIT WALKING FROM RIGHT TO LEFT IN A FIELD OF ONES.
 DATA5: ALTERNATING ONE AND ZERO BITS IN EACH CHARACTER
 DATA6: ALTERNATING ZERO AND ONE BITS IN EACH CHARACTER
 DATA7: SAME AS DATA5 BUT WITH EVERY OTHER CHARACTER COMPLEMENTED
 DATA10: WALKING ONE/ALL ONE IN ALTERNATING CHARACTERS
 DATA11: INCREMENTING CHARACTERS (000-377)
 DATA12: DECREMENTING CHARACTERS (377-000)
 DATA13: ALTERNATING CHARACTERS OF ALL ZERO AND ALL ONE BITS
 DATA14: WALKING ZERO/ALL ZERO IN ALTERNATING CHARACTERS
 DATA15: AUTO SEQUENCE PATTERN 0,0,-1,-1,-1,0,0

6. RANDOMIZATION

THERE ARE THREE (3) VALUES THAT MAY BE GENERATED RANDOMLY: DATA, CHARACTER COUNT, AND RECORD COUNT. THESE ARE NORMALLY SET TO SOME FIXED VALUE BUT MAY BE RANDOMIZED BY SETTING THE APPROPRIATE CONSOLE SWITCHES.

- A. **RANDOM DATA: (CONSOLE SWITCH 8)**
GENERATES AN ENTIRE BUFFER, CHARACTER BY CHARACTER, OF RANDOM DATA WHEN SWITCH 8 IS SET TO A ONE. ONCE SET, THE RESETTING OF SWITCH 8 CAUSES THE LAST GENERATED PATTERN TO BE RETAINED IN CORE. A RESTART AT LOCATION 200(8) OR 210(8) WILL CAUSE REVERSION OF THE DATA TO THE FIXED PATTERN REQUESTED INITIALLY. A RESTART AT LOCATION 204(8) WILL HOLD THE LAST GENERATED PATTERN IN CORE UNTIL SWITCH 8 IS AGAIN SET. ALTHOUGH THE DATA IS GENERATED AS RANDOM, THE PROGRESSION OF RANDOM CHARACTERS IS ALWAYS THE SAME FROM THE OUTSET OF RANDOMIZATION. THEREFORE IT IS POSSIBLE TO GENERATE ONE TAPE REEL OF RANDOM DATA ON ONE UNIT, RESTART THE PROGRAM TO RE-ESTABLISH THE OUTSET POINT, AND READ THE RANDOM TAPE REEL ON ANOTHER UNIT FOR COMPATABILITY TESTING. IN MULTIDRIVE SYSTEMS THE SAME BLOCK OF DATA, WHETHER RANDOM OR FIXED, IS WRITTEN OR READ ON EACH AVAILABLE UNIT IN THE ORDER THAT THEY WERE ENTERED, BEFORE BEING CHANGED.
- B. **RANDOM CHARACTER COUNT: (CONSOLE SWITCH 7)**
GENERATES A DIFFERENT NUMBER OF CHARACTERS PER RECORD TO BE WRITTEN ON EACH BLOCK CYCLE. THE SAME NUMBER OF CHARACTERS PER RECORD IS WRITTEN OR READ ON EACH AVAILABLE UNIT BEFORE BEING CHANGED. RESETTING SWITCH 7 HOLDS THE LAST VALUE GENERATED.
- C. **RANDOM RECORD COUNT: (CONSOLE SWITCH 6)**
GENERATES A DIFFERENT NUMBER OF RECORDS FOR EACH BLOCK OF DATA WRITTEN OR READ ON EACH BLOCK CYCLE. THE SAME NUMBER OF RECORDS IS WRITTEN OR READ ON EACH AVAILABLE UNIT BEFORE BEING CHANGED. RESETTING SWITCH 6 HOLDS LAST-VALUE GENERATED.

7. DYNAMIC PARAMETERS:

THE THREE (3) STALL VALUES ARE CONSIDERED TO BE DYNAMIC PARAMETERS AS THEY MAY BE CHANGED WHILE THE PROGRAM IS RUNNING BY TYPING A CONTROL B CHARACTER AT THE TELETYPE. AS SOON AS THE BUS IS RELEASED BY THE MAG TAPE OPERATION IN PROGRESS, THE PROGRAM WILL RESPOND TO THE CONTROL C INPUT BY TYPING A REQUEST FOR NEW STALL PARAMETERS. THE LAST VALUES THAT WERE ENTERED WILL BE PRINTED AS THE STORED VALUES AND MAY BE CHANGED BY ENTERING NEW VALUES OR LEFT UNCHANGED BY TYPING A CARRIAGE RETURN. THE YOZZLE STALL IS ALSO DYNAMIC AND CAN BE CHANGED BY TYPING A CONTROL B WHILE DOING A YOZZLE. A YOZZLE STALL REQUEST WILL BE PRINTED AND SHOULD BE RESPONDED TO WITH THE DESIRED VALUE.

B. CONSOLE SWITCH SETTINGS

CONTROL:

- 1) CONTROL G (↑G):
SELECTS SOFTWARE SWR AND ALLOWS USER TO SELECT NEW SWITCHES.
THE MACHINE WILL THEN TYPE: SWR=XXXXXXNEW=
WHERE: XXXXXX IS THE OCTAL CONTENTS OF THE SOFTWARE SWR.
AFTER THE 'NEW=' HAS BEEN TYPED THEN THE OPERATOR CAN DO ONE
OF THE FOLLOWING AT THE TTY:
A) TYPE A NUMBER TO BE LOADED INTO THE SOFTWARE SWR
B) IF A <CR> IS THE FIRST KEY DEPRESSED THE SOFTWARE SWR
CONTENTS WILL NOT BE CHANGED.
- 2) CONTROL A (↑A):
ALTERNATES USAGE OF THE SWR BETWEEN THE HARDWARE SWR & SOFTWARE SWR.
- 3) CONTROL B (↑B):
SEE SECTION 7 DYNAMIC PARAMETERS
- 4) CONTROL U (↑U):
DELETES ALL CHARACTERS TYPED IN RESPONSE TO A REQUEST.

THE CONSOLE SWITCHES ARE USED TO SET UP THE TEST CYCLE DESIRED, TO GENERATE RANDOM VALUES, AND TO CONTROL ERROR RESPONSES. THE SWITCHES SHOULD BE SET IN THE DESIRED MANNER BEFORE PRESSING THE START SWITCH BECAUSE THEY ARE ALL DYNAMIC AND WILL RUN THE PROGRAM IN ANY CONFIGURATION. ALL SWITCHES SET TO ZERO(0) IS NORMAL.

- SW15: 1=STOP ON ERROR
0=CONTINUE ON ERROR
- SW14: 1=PRINT READ/WRITE STATISTICS
0=DO NOT PRINT STATS
- SW13: 1=DO NOT CHECK DATA ERRORS
0=CHECK DATA ERRORS
- SW12: 1=DO NOT CHECK WRITE STATUS ERRORS (NOR CLEAR THEM IF THEY DO OCCUR)
0=CHECK WRITE STATUS ERRORS
- SW11: 1=DO NOT CHECK READ STATUS ERRORS (NOR CLEAR THEM IF THEY DO OCCUR)
0=CHECK READ STATUS ERRORS
- SW10: 1=DO NOT PRINT ANY ERRORS (EXCEPT CATASTROPHIC ERRORS)
0=PRINT ALL ERRORS
- SW9: 1=REWIND ALL AVAILABLE TAPES
0=DO NOT REWIND
- SW8: 1=GENERATE RANDOM DATA
0=USED FIXED DATA

SW7: 1=GENERATE RANDOM CHARACTER COUNT
0=USE FIXED CHARACTER COUNT

SW6: 1=GENERATE RANDOM RECORD COUNT
0=USED FIXED RECORD COUNT

SW5: 1=YOZZLE ON CURRENT RECORD
0=DO NOT YOZZLE ON RECORD

SW4: 1=DO WRITE/READ RETRIES
0=DO NOT RETRY

SW3: 1=DO NOT READ FORWARD
0=READ FORWARD

SW2: 1=DO NOT READ REVERSE
0=READ REVERSE

SW1: 1=READ FORWARD FIRST
0=READ REVERSE FIRST

SW0: 1=DO NOT WRITE
0=WRITE

SWITCH EXPLANATION AND EXAMPLES:

SWO-3:

THESE SWITCHES ARE USED TO CONTROL THE SEQUENCE OF MAG TAPE OPERATIONS PERFORMED ON EACH AVAILABLE UNIT. THE BLOCK OF DATA DESCRIBED THROUGH THE RESPONSES TO TELETYPE REQUESTS AT INITIAL START WILL BE EITHER WRITTEN OR READ FROM EACH AVAILABLE UNIT IN THE ORDER THAT THEY WERE ENTERED. THE SEQUENCE OF OPERATIONS IS CALLED A CYCLE, AND WILL BE PERFORMED CONTINUOUSLY UNTIL STOPPED BY THE OPERATOR. WHEN END OF TAPE IS REACHED, THE UNIT WILL BE REMOUND AND FLAGGED AS UNAVAILABLE FOR TEST UNTIL ALL UNITS HAVE REACH EOT, AT WHICH TIME TESTING IS RESUMED ON ALL AVAILABLE UNITS.

EXAMPLES: 0-3

- A. SWO=0, SW1=0, SW2=1, SW3=1
WRITE ONLY X RECORDS OF Y CHARACTERS
- B. SWO=0, SW1=0, SW2=1, SW3=0
WRITE THEN BACKSPACE AND READ FORWARD X RECORDS
- C. SWO=0, SW1=0, SW2=0, SW3=1
WRITE THEN READ REVERSE X RECORDS.
- D. SWO=0, SW1=0, SW2=0, SW3=0
WRITE THEN READ REVERSE AND READ FORWARD X RECORDS
- E. SWO=0, SW1=1, SW2=0, SW3=0
WRITE THEN BACKSPACE AND READ FORWARD THEN REVERSE
- F. SWO=1, SW1=0, SW2=1, SW3=0
READ TAPE FORWARD X RECORDS
- G. SWO=1, SW1=0, SW2=0, SW3=1
READ TAPE REVERSE X RECORDS
- H. SWO=1, SW1=0, SW2=0, SW3=0
READ TAPE REVERSE THEN FORWARD
- I. SWO=1, SW1=1, SW2=0, SW3=0
READ TAPE FORWARD THEN REVERSE

- SW4: SWITCH FOUR (4) WHEN SET TO A ONE (1) WILL CAUSE ANY DATA RELATED ERROR TO BE RETRIED. THE WRITE RETRY SCHEME CONSISTS OF REWRITING THE RECORD IN THE SAME SPOT ON TAPE FOUR (4) TIMES. IF ALL FOUR (4) REPEATS ARE SUCCESSFUL, THE RECORD IS CONSIDERED AS RECOVERED, AND A TAPE WRITE ERROR IS LOGGED. IF ANY OF THE FOUR (4) REPEATS IS UNSUCCESSFUL, A SKIP ERASE IS DONE, A SUSPECTED BAD TAPE SPOT IS LOGGED AT THIS BLOCK AND RECORD NUMBER, AND A SECOND RETRY OF FOUR REPEATS IS DONE. IF AFTER FOUR (4) RETRIES, THE RECORD CANNOT BE RECOVERED A NOTIFICATION IS PRINTED, AND TESTING IS RESUMED ON THE NEXT RECORD. IF 20(8) BAD TAPE SPOTS ARE FOUND, THE SLAVE WILL BE REMOVED AND REMOVED FROM TESTING WITH AN APPROPRIATE MESSAGE PRINTED. THE READ RETRY SCHEME CONSISTS OF REREADING THE RECORD UP TO EIGHT TIMES. IF ALL EIGHT REREADS ARE BAD, IT IS A HARD ERROR. IF ANY REREAD IS SUCCESSFUL, THIS IS A SOFT ERROR. IF THE ORIGINAL ERROR IS OF THE NON-RETRYABLE TYPE (IE: ILF, RMR, ILR, NEF, CBUSPE), THE RETRY SCHEME IS NOT ENTERED AND A MESSAGE IS PRINTED.
- SW5: SWITCH FIVE (5) WHEN SET DURING A READ FORWARD OR REVERSE WILL CAUSE THE TAPE TO CONTINUOUSLY READ THE CURRENT RECORD BY SPACING EITHER FORWARD OR REVERSE AND REREADING THAT RECORD. THIS TAPE MOVEMENT IS CALLED YOZZLING. THERE IS A SOFTWARE DELAY EXECUTED BETWEEN EACH SPACE/READ OF THE RECORD AND IT MAY BE VARIED BY TYPING CONTROL C ON THE TELETYPE DURING THE EXECUTION OF THE YOZZLE AND RESPONDING TO THE PRINTED REQUEST WITH A SIX (6) DIGIT VALUE. THE YOZZLE STALL IS PRESET TO A VALUE OF 3000 IN THE PROGRAM TO PREVENT EXCESSIVE TAPE WEAR, BUT MAY BE SET TO ANY VALUE THROUGH THE TELETYPE.
- SW6-8: THESE THREE (3) SWITCHES CONTROL THE RANDOMIZATION OF DATA AND BLOCK SIZE AND MAY BE SET AND RESET AT ANY TIME. THE ACTUAL CHANGE WILL TAKE PLACE BETWEEN BLOCK CYCLES.
- SW9: SWITCH NINE (9) WHEN SET WILL CAUSE ALL AVAILABLE TAPE UNITS TO BE REMOVED AT THE END OF THE CURRENT BLOCK CYCLE. TESTING WILL BE RESUMED AT A BLOCK COUNT OF ONE (1) WHEN ALL UNITS HAVE REACHED BOT.

- SW10-13: THESE SWITCHES ARE USED TO CONTROL THE ERROR HANDLING TO BE DONE ON THE TAPE OPERATION DESCRIBED BY SWITCHES 0-3.
- A. SWITCH TEN (10) WHEN SET TO A ONE WILL DISALLOW ANY ERROR PRINTOUTS MADE ON THE OPERATION IN PROGRESS. CATASTROPHIC FAILURES AND INFORMATION PRINTOUTS WILL STILL OCCUR. IE: UNIT NOT AVAILABLE, ILLEGAL BOT, DROP OR PICK OVERFLOW, AND EOT REWIND.
 - B. SWITCH ELEVEN (11) WHEN SET TO A ONE WILL DISALLOW THE CHECKING FOR STATUS ERRORS ON READ (FORWARD OR REVERSE) OPERATIONS.
 - C. SWITCH TWELVE (12) WHEN SET TO A ONE WILL DISALLOW THE CHECKING FOR STATUS ERRORS ON WRITE OPERATIONS.
 - D. SWITCH THIRTEEN (13) WHEN SET TO A ONE WILL DISALLOW THE CHECKING OF READ DATA. THIS SWITCH HAS NO EFFECT ON STATUS CHECKING.

***NOTE THAT WHEN SW11 OR 12 ARE SET, NOT ONLY ARE ERRORS NOT CHECKED, BUT THEY ARE NOT CLEARED EITHER.
***THEREFOR USE CAUTION TO ASSURE THAT OPERATIONS ARE NOT UNEXECUTED DUE TO UNCLEARED ERRORS.
***DO NOT SET SW 11 OR 12 TO A ONE (1), DURING A RETRY SEQUENCE.

SW14: SWITCH FOURTEEN (14) WHEN SET TO A ONE (1) WILL PRINT THE ACCUMULATED READ/WRITE STATISTICS FOR THE SELECTED SLAVE UNDER TEST AT THE END OF THE CURRENT BLOCK CYCLE. THE STATISTICS PRINTED ARE THE NUMBER OF BITS DROPPED OR PICKED, THE NUMBER OF RETRIES, WRITE ERRORS, READ ERRORS, AND DATA ERRORS.

SW15: SWITCH FIFTEEN (15) WHEN SET TO A ONE, WILL CAUSE THE PROGRAM TO HALT ON ANY ERROR DETECTED BY THE OPERATION IN PROGRESS. IF BOTH SWITCH TEN (10) AND FIFTEEN (15) ARE SET, THE ACTUAL ERROR DETECTED WILL NOT BE PRINTED BUT WILL CAUSE A HALT. IF SWITCH TEN (10) IS RESET BEFORE PRESSING CONTINUE, THE ERROR WHICH CAUSED THE HALT WILL BE PRINTED BEFORE TESTING IS RESUMED.

9. ERROR PRINTOUTS

THERE ARE THREE TYPES OF ERROR PRINTOUTS MADE BY THE PROGRAM: OPERATION ERRORS, DATA ERRORS, AND CONDITION ERRORS. EACH ERROR MESSAGE PRINTED IS PRECEDED BY A TWO LINE HEADER WHICH CONTAINS THE DRIVE NUMBER, SLAVE NUMBER, DENSITY, PARITY, AND FORMAT ON THE FIRST LINE, AND THE BLOCK NUMBER, RECORD NUMBER, RECORD SIZE, AND ERROR TYPE ON THE SECOND.

A. OPERATION ERRORS:

THESE ARE ERRORS WHICH CAN OCCUR AS A DIRECT RESULT OF A TAPE OPERATION.

1. READ/WRITE STATUS ERRORS: THESE ARE DETECTED BY EITHER THE TM03 ITSELF OR BY THE MASSBUS CONTROLLER. ALL STATUS ERRORS WILL BE REPORTED.
2. TAPE POSITION ERRORS: THESE ARE INDICATED BY AN INCORRECT SPACE OR REWIND OPERATION IN WHICH TAPE POSITION BECOMES UNRELIABLE.

B. DATA ERRORS:

DATA ERRORS WILL OCCUR WHEN TAPE IS BEING READ AND THE DATA FROM TAPE DOES NOT MATCH THE EXPECTED DATA. WHEN READING IN THE REVERSE DIRECTION, THE RECORD NUMBERS WILL BE COUNTED DOWN FROM LAST TO FIRST. THE CHARACTER NUMBERS IN REVERSE READS WILL ALSO BE COUNTED DOWN IN ORDER TO REFLECT TAPE POSITION RATHER THAN THE ORDER TRANSFERRED.

BECAUSE DATA RECORDS CAN BE UP TO FOUR THOUSAND CHARACTERS LONG, AN ERROR CONDITION WHICH WILL CAUSE THE ENTIRE RECORD TO READ INCORRECTLY COULD CAUSE A VERY LENGTHY PRINTOUT. THEREFORE, A COUNTER OF SUCCESSIVE BAD CHARACTERS IS EMPLOYED. IF TEN (10) CHARACTERS IN SUCCESSION ARE BAD, A NOTIFICATION IS PRINTED (BAD RECORD) AND THE NEXT TWENTY FIVE (25) CHARACTERS ARE SKIPPED BEFORE CHECKING IS RESUMED. IF THE BAD RECORD CONDITION OCCURS THREE (3) TIMES IN ONE RECORD, THE REST OF THE RECORD IS SKIPPED, DOWN TO THE LAST TEN (10) CHARACTERS WHICH WILL BE CHECKED. THE SKIPPING AND RESUMPTION OF CHECKING WILL ONLY BE DONE ON RECORDS WHICH ARE LONG ENOUGH TO ALLOW IT.

C. CONDITION ERRORS: (CATASTROPHIC)

THESE PRINTOUTS REFLECT THE STATE OF THE TAPE SYSTEM
EITHER BEFORE OR AFTER AN OPERATION

1. EOT: WHEN EOT (END OF TAPE) IS ENCOUNTERED DURING
EITHER A READ OR WRITE, THE CYCLE IS COMPLETED
ON THE SHORTENED BLOCK AFTER WHICH THE SLAVE
WILL BE REWOUND AND FLAGGED AS UNAVAILABLE
FOR TESTING UNTIL ALL SLAVES HAVE REACHED EOT AND
ARE REWOUND. WHEN THE LAST AVAILABLE SLAVE
HAS REACHED EOT AND BEEN REWOUND TO BOT,
TESTING WILL BE RESUMED ON ALL SLAVES.
2. ILLEGAL BOT: WHEN A SLAVE ENCOUNTERS BOT DURING
A READ, WRITE, OR SPACE OPERATION, AN ERROR
IS PRINTED AND THE PROGRAM HALTED. THIS IS
A CATASTROPHIC ERROR. TESTING MAY BE RESUMED
BY PRESSING CONTINUE; BUT A RESTART IS
SUGGESTED.
3. NO INTERRUPT RETURNED: EACH TAPE OPERATION SHOULD BE
TERMINATED BY THE SETTING OF AN INTERRUPT IN
THE CPU. IF NO INTERRUPT IS RETURNED WITHIN
THE APPROPRIATE TIME, AN ERROR IS PRINTED.
4. NO MEDIUM ON-LINE: BEFORE AN OPERATION IS ATTEMPTED,
THE TM03 IS CHECKED FOR MOL. IF IT IS NOT
SET, AN ERROR IS PRINTED, AND THE PROGRAM STOPPED.
TESTING MAY BE RESUMED BY PRESSING CONTINUE.
5. NO BOT ON REWIND: AS EACH SLAVE IS REWOUND A CHECK
IS MADE TO ASSURE THAT PROPER POSITION AT BOT
IS ESTABLISHED. IF BOT IS NOT SET UPON COMPLETION OF
A REWIND, AN ERROR IS PRINTED AND THE PROGRAM
WILL HALT. PRESS CONTINUE TO RESUME TESTING.
6. POSITION ERROR: IF POSITION IS LOST DURING A RETRY,
A MESSAGE IS PRINTED, THE TAPE REWOUND,
AND REMOVED FROM TESTING UNTIL ALL ARE
RESTARTED AT BLOCK ONE.
7. BAD TAPE OVERFLOW: IF 20(8) BAD TAPE SPOTS ARE FOUND,
A MESSAGE IS PRINTED, THE TAPE REWOUND,
AND REMOVED FROM TESTING UNTILL ARE
RESTARTED AT BLOCK ONE.
8. HARD READ ERROR: IF ANY HARD READ ERROR IS ENCOUNTERED
DURING A RETRY, A MESSAGE IS PRINTED
REGARDLESS OF THE SETTING OF SW10.
9. NON-RETRYABLE: IF ANY NON-RETRYABLE ERROR IS ENCOUNTERED, A
MESSAGE IS PRINTED REGARDLESS OF THE SETTING OF SW10.

D. EXAMPLES:

GLOSSARY:

BN = CURRENT BLOCK NUMBER
RN = CURRENT RECORD NUMBER
RS = RECORD SIZE IN FRAMES
WE = WRITE STATUS ERROR
RE = READ STATUS ERROR
SE = SPACE ERROR
TM = TAPE MARK
F = FORWARD
R = REVERSE
CS1 = RH/TE16 CONTROL REGISTER
MC = RH WORD COUNT
BA = RH BUS ADDRESS
FC = TE16 FRAME COUNT
CS2 = RH CONTROLLER STATUS
DS = TE16 DRIVE STATUS
ER = TE16 ERROR REGISTER
AS = ATTENTION SUMMARY
CK = TE16 CHECK CHARACTER
DB = RH DATA BUFFER
MR = TE16 MAINTENANCE REGISTER
DT = TE16 DRIVE TYPE
SN = TE16 SERIAL NUMBER
TC = TE16 TEST CONTROL
*F = DATA FORMAT
*P = PARITY
*D = DENSITY
*PATRN = DATA PATTERN NUMBER (R = RANDOM)

EXAMPLE 1: IN THIS EXAMPLE SLAVE 1 ON TM03 0 WAS OPERATING AT 1600 BPI IN ODD PARITY USING THE NINE CHANNEL NORMAL DATA FORMAT. A WRITE STATUS ERROR WAS DETECTED. THE BAD STATUS INDICATES THAT AN UNCORRECTABLE DATA ERROR (BIT 6 OF ER) AND A PE FORMAT ERROR (BIT 7 OF ER) OCCURED DURING THE WRITE OPERATION OF THE SIXTH (6) RECORD OF THE FIFTY (50) RECORDS IN BLOCK (2). THE SIZE OF THE RECORD WAS TWO HUNDRED (200) FRAMES. THE CHECK CHARACTER REFLECTS THE BAD TRACK.

DRIVE NO. 0 #SLAVE NO. 1 #D 4 #P 0 #F 14 #PATRN 1
#BN 2 #RN 6-50 #RS = 200 #WE
CS1 144260
CS2 100
DS 150640
ER 300
WC 0
CK 4

EXAMPLE 2: IN THIS EXAMPLE SLAVE 3 ON TM03 1 WAS OPERATING AT 800 BPI IN EVEN PARITY USING THE NINE CHANNEL NORMAL DATA FORMAT. A READ STATUS ERROR WAS DETECTED DURING THE REVERSE READ OF THE TENTH (10) RECORD OF THE 25 RECORDS IN THIS BLOCK (12). THE SIZE OF THE RECORD IS TWENTY (20) FRAMES. THE PRINTOUT INDICATES THE DETECTION OF A VERTICAL PARITY ERROR (VPE: BIT 6 OF ER) AND A CYCLIC REDUNDENCY ERROR (CRC: BIT 15 OF ER). THE CRC CHARACTER, AS RECEIVED, IS NOT AS EXPECTED AND IS PRINTED SHOWING BOTH THE ACTUAL (FIRST) AND THE EXPECTED (LAST).

DRIVE NO. 2 #SLAVE NO. 3 #D 3 #P 1 #F 14 #PATRN 3
#BN 12 #RN 10-25 #RS 20 #RE R
CS1 144276
CS2 100
DS 150600
ER 100100
WC 0
CRC 767-777

EXAMPLE 3: IN THIS EXAMPLE, THE HEADER IS THE SAME AS IN EXAMPLE TWO (2) EXCEPT THAT THE ERROR TYPE REFLECTS A READ ERROR IN THE FORWARD DIRECTION. IT IS NORMAL FOR THE SYSTEM TO DETECT AN ERROR IN THE FORWARD AND REVERSE DIRECTION AT THE SAME RECORD. REMEMBER THAT IN REVERSE OPERATIONS THE RECORD NUMBER IS COUNTED DOWN SO THAT RECORD NUMBER TEN (10) WILL SHOW IN THE PROPER POSITION IN BOTH FORWARD AND REVERSE.

DRIVE NO. 2 *SLAVE NO. 3 *D 3 *P 1 *F 14 *PATRN 2
*BN 12 *RN 10-25 *RS 20 *RE F
CS1 144270
CS2 100
DS 150600
ER 100100
WC 0
CRC 767-777

EXAMPLE 4: IN EXAMPLES 2 AND 3 THE READ OPERATION RESULTED IN BAD STATUS, HOWEVER THE DATA ASSOCIATED WITH THE OPERATION WAS NOT BAD (OR WAS NOT CHECKED: SW 13=1). THIS EXAMPLE (4) SHOWS A PRINTOUT REFLECTING A READ STATUS ERROR ACCOMPANIED BY BAD DATA IN CHARACTERS FOUR (4) AND SIX (6).

DRIVE NO. 2 *SLAVE NO. 3 *D 3 *P 1 *F 14 *PATRN 2
*BN 12 *RN 10-25 *RS 20 *RE F
CS1 144270
CS2 100
DS 150600
ER 100100
WC 0
CRC 767-777
CN 4
G 11111111
B 10111111
CN 6
G 11111111
B 10111111

EXAMPLE 5: THIS EXAMPLE SHOWS A READ DATA ERROR WHICH OCCURRED, WITHOUT AN ACCOMPANYING STATUS ERROR, WHICH RESULTED IN A BAD RECORD.

DRIVE NO. 3 *SLAVE NO. 1 *D 4 *P 0 *F 14 *PATRN R
*BN 100 *RN 66-200 *RS 2000 *DE F

CN 0
G 11111111
B 00000000
CN 1
G 11111111
B 00000000
CN 2
G 11111111
B 00000000
CN 3
G 11111111
B 00000000
CN 4
G 11111111
B 00000000
CN 5
G 11111111
B 00000000
CN 6
G 11111111
B 00000000
CN 7
G 11111111
B 00000000

BAD RECORD

EXAMPLE 6: THE FOLLOWING EXAMPLE SHOWS THE RESULT OF A SPACE OPERATION THAT SHOULD HAVE SPACED REVERSE OVER AN ENTIRE 100 RECORD BLOCK BUT WHICH TERMINATED AT THE END OF 40 RECORDS. LEAVING A POSITION ERROR OF 40

DRIVE NO. 2 *SLAVE NO. 6 *D 2 *P 0 *F 14
*BN 3 *RN 100-100 *RS 1000 *SE R
ERR AMT 40

EXAMPLE 7: THIS EXAMPLE REFLECTS AN ERROR DETECTED WHILE WRITING A TAPE MARK (TM) AT THE END OF THE CURRENT DATA BLOCK PER OPTION RESPONSE TM=1. NOTE THAT THE TM RECORD NUMBER IS ONE GREATER THAN THE TOTAL NUMBER OF DATA RECORDS IN THE CURRENT BLOCK.

DRIVE NO. 1 *SLAVE NO. 1 *D 2 *P 0 *F 14
*BN 67 *RN 101-100 *RS 36 *WE TM
CS1 144226
CS2 300
DS 150604
ER 1000
WC 0

EXAMPLE 8: THIS EXAMPLE SHOWS TWO (2) PRINTOUTS REFLECTING A WRITE RETRY WHICH WAS NOT SUCCESSFUL THE FIRST TIME, BUT WHICH DID RECOVER ON THE SECOND. THE UNSUCCESSFUL RETRY IS LOGGED AS A SUSPECTED BAD TAPE SPOT BY ITS BLOCK AND RECORD NUMBER.

DRIVE NO. 0 *SLAVE NO. 2 *D 4 *P 0 *F 14 *PATRN 6
*BN 2 *RN 12-20 *RS 667 *WE
CS1 144260
CS2 100
DS 150640
ER 100
WC 0
ORIGINAL ERROR

DRIVE NO. 0 SLAVE NO. 2 *D 4 *P 0 *F 14 *PATRN 6
*BN 2 *RN 12-20 *RS 667 *WE
CS1 144260
CS2 100
DS 150640
ER 100
WC 0
SUSPECT BAD TAPE
RETRY: 0
REPT: 0
RECOVERED
RETRY: 1

EXAMPLE 9: IF , DURING A WRITE RETRY THE BACKSPACE OR THE ERASE OPERATION RESULT IN AN ERROR, THE ERROR WILL BE PRINTED AND THE PROGRAM HALTED. THIS EXAMPLE SHOWS THE ERROR PRINT FOR A SPACE AND AN ERASE (2 EXAMPLES)

DRIVE NO. 1 #SLAVE NO. 1 #D 3 #P 0 #F 14
#BN 12 #RN 8-64 #RS 500 #SE RTRY
ERR AMT 1

DRIVE NO. 1 #SLAVE NO. 1 #D 3 #P 0 #F 14
#BN 12 #RN 8-64 #RS 500 #ERASE
CS1 144224
CS2 100
DS 150600
ER 400
WC 0

EXAMPLE 10: THIS EXAMPLE SHOWS THE PRINTOUT FROM A REWIND OPERATION WHICH DOES NOT HAVE BOT SET AT THE END.

DRIVE NO. 2 #SLAVE NO. 3 #D 3 #P 0 #F 14
#BN 66 #RN 15-20 #RS 1000
NOT BOT ON REWIND: HALT

EXAMPLE 11: THIS EXAMPLE SHOWS THE PRINTOUT MADE WHEN THERE IS NO INTERRUPT RETURNED AT THE END OF AN OPERATION.

DRIVE NO. 7 #SLAVE NO. 7 #D 2 #P 1 #F 14
#BN 1 #RN 25-26 #RS 1200
NO INTERRUPT

10. STATISTICS PRINTOUT

THE PROGRAM, THROUGH ITS ERROR CHECKING, IS ABLE TO GATHER CERTAIN STATISTICS ABOUT THE PERFORMANCE OF EACH UNIT UNDER TEST. THIS INFORMATION IS PRINTED OUT WHENEVER A UNIT IS REWOUND FROM END OF TAPE, OR BECAUSE IT IS TO BE REMOVED FROM TESTING DUE TO SOME CATASTROPHIC ERROR. (POSITION LOST, BAD TAPE OVERFLOW) THE STATISTICS MAY BE PRINTED AT ANY TIME BY SETTING SWITCH 14 TO A ONE (1). THIS PRESENTS A PICTURE OF PERFORMANCE UP TO THIS TIME. THE STATISTICS WILL BE CLEARED UPON REWIND OF THE UNIT; BUT NOT BY SETTING SW 14.

STATISTICS PRINT EXAMPLE (A HEADER WILL PRECEED THE STATS)

DROPS: 0 3 0 0 0 6 45 0
PICKS: 1 0 0 0 0 0 0 2
RETRY: 1
WTERR: 2
REFWD: 3
SOFT: 2
HARD: 1
DEFWD: 0
REREV: 4
SOFT: 1
HARD: 3
DEREV: 0
2 BAD TAPE SPOTS
0 #BN 1 #RN 2
1 #BN 15 #RN 100

** NOTE ** DROPS AND PICKS REFLECT CORE BIT POSITIONS.
THE FOLLOWING IS A TABLE OF CORE BITS TO TRACK NUMBER.

| | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|
| TRACK NO. | 7 | 6 | 5 | 3 | 9 | 1 | 8 | 2 |
| CORE BIT | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |

DROPS: NUMBER OF DATA BITS DROPPED: PER CORE BIT(SEE NOTE ABOVE)
PICKS: NUMBER OF DATA BITS PICKED UP: PER CORE BIT(SEE NOTE ABOVE)
RETRY: NUMBER OF WRITE RETRIES
WTERR: NUMBER OF WRITE ERRORS NOT ASSOCIATED WITH BAD TAPE
REFWD: NUMBER OF READ FORWARD STATUS ERRORS
REREV: NUMBER OF READ REVERSE STATUS ERRORS
SOFT: NUMBER OF RECOVERED READ ERRORS
HARD: NUMBER OF UNRECOVERED READ ERRORS
DEFWD: NUMBER OF FORWARD DATA ERRORS WITH NO ASSOCIATED STATUS ERROR
DEREV: NUMBER OF REVERSE DATA ERRORS WITH NO ASSOCIATED STATUS ERROR

11. AUTO SEQUENCE

THE AUTO SEQUENCE (START AT ADDRESS 240) WILL EXECUTE A PREDETERMINED TEST PLAN ON ALL AVAILABLE SLAVES ON EACH AVAILABLE TMD3. THE ONLY OPERATOR RESPONSE IS TO THE TYPED REQUESTS FOR THE RH ADDRESS, VECTOR, CONTINUOUS OR SINGLE CYCLE, AND NRZ ONLY. ALL SWITCHES REMAIN ACTIVE AND MAY BE USED NORMALLY; HOWEVER THE IDEA IS TO LEAVE ALL SWITCHES DOWN AND ALLOW FULL EXECUTION OF THE TEST PLAN FOR SYSTEM CHECKOUT.

SAMPLE START AT 240(8): AUTO SEQUENCE.

LOAD ADDRESS 240(8), SET SWITCHES TO ZERO, PRESS START:

TE16 AUTO SEQUENCE TEST
ENTER CONDITIONS IN OCTAL

REGISTER START = 172400(172440)
VECTOR ADDRESS = 224(CR)
NRZ ONLY: (0)
AUTO CONT: (1)

THIS EXAMPLE SHOWS AN AUTO SEQUENCE START WITH THE RH AT BUS ADDRESS 172440 AND A VECTOR OF 224. ALL AVAILABLE HARDWARE WILL BE TESTED CONTINUOUSLY IN BOTH NRZ AND PE MODE.

AS EACH TMD3 AND ITS SLAVES ARE FOUND, A DIVIDER LINE OF ASTERICKS WILL BE PRINTED FOLLOWED BY A PRINTOUT OF THE TMD3 AND ITS SLAVES BEING TESTED. AS EACH TMD3 AND ITS SLAVES ARE FINISHED, ANOTHER DIVIDER IS PRINTED BEFORE TESTING IS RESUMED ON THE NEXT AVAILABLE DRIVE.

WHEN ALL AVAILABLE HARDWARE HAS BEEN TESTED, A PRINTOUT OF END OF SEQUENCE WILL BE DONE AND THE PROGRAM WILL EITHER HALT (AUTO CONT = 0) OR RESTART WITH THE FIRST AVAILABLE UNIT (AUTO CONT = 1).

AUTO SEQUENCE TEST PLAN:

THE AUTO SEQUENCE WILL EXECUTE BOTH AN NRZ AND A PE CYCLE. EACH CYCLE WILL BE STARTED FROM BOT AND CONSIST OF VARIOUS DATA PATTERNS INTENDED TO BE WORST CASE FOR THAT PARTICULAR MODE.

1. NRZ CYCLE:

SIX (6) BLOCKS OF ONE HUNDRED (100) RECORDS OF FOUR THOUSAND (4000) CHARACTERS FOR EACH OF THE FOUR DATA PATTERNS.

PATTERN 1: ALL ONES DATA IN ALL BYTES
PATTERN 10: WALKING ONE/ALL ONE
PATTERN 14: WALKING ZERO/ALL ZERO
RANDOM DATA: RANDOM

2. PE CYCLE: (IF NRZ ONLY = 0)

SIX BLOCKS OF ONE HUNDRED (100) RECORDS OF FOUR THOUSAND (4000) CHARACTERS EACH FOR EACH OF THREE DATA PATTERNS, THEN RANDOM DATA BLOCKS TO END OF TAPE.

PATTERN 10: WALKING ONE/ALL ONE
PATTERN 14: WALKING ZERO/ALL ZERO
PATTERN 15: THREE (3) 0 CHARACTERS, TWO (2) ALL CHARACTERS, THREE 0 CHARACTERS, THEN COMPLIMENT PATTERN. REPEATED FOR A FULL BUFFER
RANDOM DATA: RANDOM

12. TESTING PROCEDURES

AS PREVIOUSLY STATED THIS PROGRAM CONTAINS NO FIXED TESTS. THE ENTIRE TEST CYCLE TO BE EXECUTED IS DESCRIBED BY THE OPERATOR THROUGH RESPONSES TO TELETYPE REQUESTS FOR PARAMETERS AND CONSOLE SWITCH SETTINGS FOR OPERATION. THE OPERATION SELECTED WILL BE EXECUTED WITH THE PARAMETERS ENTERED CONTINUOUSLY ON EACH AVAILABLE UNIT, ONE BLOCK AT A TIME, UNTIL STOPPED BY THE OPERATOR. THE OPERATION MAY BE CHANGED DYNAMICALLY BY CHANGING THE CONSOLE SWITCHES AT ANY TIME. THE PROGRAM WILL ATTEMPT TO PERFORM ANY OPERATION SET AND THEREFORE CAUTION SHOULD BE TAKEN TO ASSURE THAT THE UNIT IS CAPABLE OF PERFORMING AS REQUESTED. FOR INSTANCE, ONE SHOULD NOT ATTEMPT TO PERFORM READ OPERATIONS ON A TAPE WHICH HAS NOT BEEN WRITTEN AS THE DATA, IF ANY IS UNPREDICTABLE. HOWEVER, IF A TAPE HAS BEEN WRITTEN WITH THIS PROGRAM, IT CAN BE READ AS OFTEN AS DESIRED WITHOUT BEING REWRITTEN. THIS IS A GOOD PROCEDURE TO USE FOR TESTING TAPE COMPATABILITY. SCOPING OF TAPE UNITS BECOMES SIMPLE; BY SETTING THE DESIRED OPERATION AND ITS PARAMETER, A UNIT MAY BE CONTINUOUSLY EXERCISED IN ANY MANNER DESIRED. BY USING THE VARIOUS ERROR CONTROL SWITCHES AND ENTERING THE NEEDED STALL, ANY FUNCTION CAN BE SCOPED RATHER EASILY. RELIABILITY TESTING CAN BE PERFORMED BY USE OF THE RANDOMIZATION CAPABILITY. PERHAPS A CYCLE OF RANDOM TESTING MIGHT BE SET UP AND ALLOWED TO RUN FOR SOME PERIOD OF TIME, THE STATISTICAL COLLECTION OF DROPS AND PICKS IS THEN SIGNIFICANT. INTERMITTANT PROBLEMS CAN BE FOUND BY SETTING THE DESIRED OPERATION IN MOTION AND DISALLOWING ERROR PRINTOUTS WHILE ALLOWING A HALT ON ERROR. THE ERROR THAT CAUSED THE HALT CAN BE PRINTED BY RESETTING CONSOLE SWITCH TEN AND PRESSING CONTINUE. IF SOME PARTICULAR DATA PATTERN SHOULD BE CAUSING DATA ERROR, USE OF THE YOZZLE SWITCH AND ITS ASSOCIATED STALL WILL ALLOW SCOPING OF THIS PARTICULAR RECORD.

AS YOU SEE, THERE ARE MYRIAD TESTING PROCEDURES WHICH COULD BE PERFORMED. THE PARAMETERS, TAPE OPERATIONS, ERROR EXAMINATION AND REPORTING ARE ALL AT YOUR DISCRETION.

TRY IT, YOU'LL LIKE IT.

1308
1309
1310
1311
1312
1313
1314
1315

%

```
.LIST BIN,LOC,SEQ
.TITLE TM03/TE16 DATA RELIABILITY PROGRAM
;MAINDEC-!1-DZTED-A-D
;21 FEB 1977
;R. BARNES
.MCALL .SACT11,.SEOP,$SAVE,$RESTORE,$CHAIN
.NLIST MC
.LIST ME
```

1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352

```
.ENABLE ABS,AMA
;CONSOLE SWITCHES*****
;SW15: 1=STOP ON ERROR
;        0=CONTINUE ON ERROR
;SW14: 1=PRINT READ/WRITE STATS
;        0=DO NOT PRINT STATS
;SW13: 1=DO NOT CHECK DATA
;        0=CHECK DATA
;SW12: 1=DO NOT CHECK WRITE ERRORS
;        0=CHECK WRITE ERRORS
;SW11: 1=DO NOT CHECK READ ERRORS
;        0=CHECK READ ERRORS
;SW10: 1=DO NOT PRINT ERRORS
;        0=PRINT ERRORS
;SW9:  1=REWIND TAPE
;        0=DO NOT REWIND
;SW8:  1=USE RANDOM DATA
;        0=USE FIXED DATA PATTERN
;SW7:  1=USE RANDOM CHARACTER COUNT
;        0=USE FIXED CHAR COUNT
;SW6:  1=USE RANDOM RECORD COUNT
;        0=USE FIXED RECORD COUNT
;SW5:  1=YOZZLE ON CURRENT RECORD
;        0=DO NOT YOZZLE
;SW4:  1=DO BOTH READ AND WRITE RETRIES
;        0=INHIBIT RETRIES
;SW3:  1=DO NOT READ FORWARD
;        0=READ FORWARD
;SW2:  1=DO NOT READ REVERSE
;        0=READ REVERSE
;SW1:  1=READ FORWARD FIRST
;        0=READ REVERSE FIRST
;SW0:  1=DO NOT WRITE
;        0=WRITE
; IF SWR <15::00> = 177777 OR NOT AVAILABLE USE SOFTWARE SWITCH REGISTER
```



```

1399                                     ;REGISTER EQUIVS*****
1400
1401                                000000      R0=%0
1402                                000001      R1=%1
1403                                000002      R2=%2
1404                                000003      R3=%3
1405                                000004      R4=%4
1406                                000005      R5=%5
1407                                000006      SP=%6
1408                                000007      PC=%7
1409                                000240      NOP=240
1410
1411                                     ;TRAP CATCHERS*****
1412
1413                                .=20
1414    000020    023634      .WORD    TTOUT      ;SET IOT TRAP TO TTOUT ROUTINE
1415    000022    000340      .WORD    340        ;PRIORITY LEVEL 7
1416
1417                                000004      TYPE=IOT      ;EQUATE TYPE TO AN IOT INSTRUCTION
1418                                000034      .=34
1419    000034    024006      .WORD    OCTP      ;SET TRAP TRAP TO OCTP ROUTINE
1420    000036    000340      .WORD    340
1421                                104400      TYPOCT=TRAP      ;EQUATE TYPOCT TO TRAP INSTRUCTION
1422
1423    ;ACT11 HOOK *****
1424                                000040      $$VPC=.      ;SAVE CURRENT LOCATION CTR
1425                                000046      .=46
1426    000046    005022      .WORD    SENDAD    ;SET LOCATION 46
1427                                000052      .=52
1428    000052    000000      .WORD    0          ;SET LOCATION 52 = 0
1429                                000040      .=$$VPC      ;RESTORE LOCATION CTR
1430
1431                                     ;TTY INTERRUPT VECTOR*****
1432                                .=60
1433    000060    021466      .WORD    TTINT      ;TTY INTERRUPT HANDLER ADDRESS
1434    000062    000340      .WORD    340        ;PRIORITY LEVEL 7
1435
1436                                     ;SOFTWARE SWITCH REGISTER*****
1437    ;INVOKED IF SWR <15:00> = 177777 OR NOT AVAILABLE
1438                                .=176
1439    000176    000000      SWREG: .WORD    0
1440
1441                                     ;START ADDRESS*****
1442                                .=200
1443    000200    000137    003026      JMP     START      ;ENTER PARAMETERS VIA TTY
1444
1445                                .=204
1446    000204    000137    003152      JMP     STARTC     ;USE FIXED PARAMETERS; HOLD DATA
1447
1448                                .=210
1449    000210    005037    015022      CLR     RDFL
1450    000214    000137    003160      JMP     STARTA     ;USE FIXED PARAMETERS; NEW DATA
1451
1452                                     ;MAG TAPE INTERRUPT VECTOR*****
1453
1454                                .=224

```

1455 000224 021716
1456 000226 000340

MTINT
340

;MAG TAPE INTERRUPT HANDLER ADDRESS

1457
1458
1459

;AUTO SEQUENCE START*****

1460 000240 000240
1461 000240 005237 000736
1462 000244 000137 003136

=240
INC
JMP

ASEQF
STAUT

;SET AUTO SEQUENCE FLAG
;GO TO START OF AUTO SEQUENCE

```

1463                                     ;SHORT CONVERSATION RESTART*****
1464
1465                                     .=300
1466 000300 000300 014062                INC      SCVFL      ;SET SHORT CONVERSATION FLAG
1467 000304 000137 003026                JMP      START     ;ENTER SHORT PARAMETER LIST
1468
1469                                     .=510
1470                                     ;TU16 REGISTER EQUIVS*****
1471
1472 000510 172440                C1:      172440
1473 000512 172442                WC:      172442
1474 000514 172444                BA:      172444
1475 000516 172446                FC:      172446
1476 000520 172450                CS:      172450
1477 000522 172452                DS:      172452
1478 000524 172454                ER:      172454
1479 000526 172456                AS:      172456
1480 000530 172460                CC:      172460
1481 000532 172462                DB:      172462
1482 000534 172464                MR:      172464
1483 000536 172466                DT:      172466
1484 000540 172470                SN:      172470
1485 000542 172472                TC:      172472
1486
1487                                     ;CONSTANTS*****
1488
1489 000544 172440                REGS:    172440      ;STARTING REGISTER ADDRESS (CS1)
1490 000546 000224                VECT:    224        ;VECTOR ADDRESS (RH INTERRUPT)
1491 000550 000000                DVN:     0          ;DRIVE NUMBER
1492 000552 000000                UDES:    0          ;UNIT DESCRIPTION (PARITY,DENSITY,UNIT,FORMAT)
1493 000554 000100                RCNT:    100       ;RECORD COUNTER
1494 000556 177400                FACNT:   177400    ;NUMBER OF CHAR (4 - 4000) OCTAL IN TWOS COMPLEMENT
1495 000560 000001                PATRN:   1          ;DATA PATTERN SELECTOR (0 - 15) OCTAL
1496 000562 000002                RDCMD:   2          ;READ COMMAND
1497 000564 000001                TMEX:    1          ;TAPE MARK FLAG: 1=TM 0=NO TM
1498 000566 000000                CRCC:    0          ;CRC CORRECTION FLAG (YES=1,NO=0)
1499 000570 000000                INTRF:   0          ;INTERCHANGE READ 1=YES 0=NO
1500 000572 000000                SPFLG:   0          ;SINGLE PASS 1=YES 0=NO
1501 000574 000001                RSTAL:   1          ;READ STALL
1502 000576 000001                WSTAL:   1          ;WRITE STALL
1503 000600 000001                TSTAL:   1          ;TURN AROUND STAL
1504 000602 002000                YSTAL:   2000      ;YOZZLE STAL
1505 000604 000010                RETRY:   10         ;READ RETRY NUMBER
1506 000606 177776                PSW:     177776    ;PROCESSOR STATUS
1507 000610 177570                SWR:     177570    ;CONSOLE SWITCHES
1508 000612 177560                TKS:     177560    ;TTY READ STATUS REGISTER
1509 000614 177562                TKB:     177562    ;TTY READ BUFFER
1510 000616 177564                TPS:     177564    ;TTY PUNCH STATUS REGISTER
1511 000620 177566                TPB:     177566    ;TTY PUNCH OUTPUT REGISTER
1512 000622 177550                PRS:     177550    ;H/S READER STATUS REGISTER
1513 000624 177552                PRB:     177552    ;H/S READER BUFFER
1514 000626 153624                RANBAS:  153624    ;RANDOM NUMBER GENERATOR BASE
1515 000630 032561                RANSAV:  032561    ;RANDOM NUMBER BUFFER
1516 000632 000100                RCSAV:   100       ;RECORD COUNT SAVE
1517 000634 177400                FCSAV:   177400    ;FRAME COUNT SAVE

```

| | | | | | |
|------|--------|--------|---------|---|---------------------------------|
| 1518 | | | | | |
| 1519 | | | | | |
| 1520 | | | | | |
| 1521 | 000636 | 000000 | TINF: | 0 | ; TTY ENTRY FLAG |
| 1522 | 000640 | | STFLG: | | |
| 1523 | 000640 | 000000 | TOB: | 0 | ; TTY OUTPUT BUFFER |
| 1524 | 000642 | 000000 | TIB: | 0 | ; TTY INPUT BUFFER |
| 1525 | 000644 | 000000 | TEMP1: | 0 | ; TEMP STORAGE |
| 1526 | 000646 | 000000 | TEMP2: | 0 | ; TEMP STORAGE |
| 1527 | 000650 | 000000 | TEMP3: | 0 | ; TEMP STORAGE |
| 1528 | 000652 | 000000 | NRZOF: | 0 | ; NRZ ONLY FLAG |
| 1529 | 000654 | 000000 | EMADDR: | 0 | ; ERROR MSG ADDRESS STORAGE |
| 1530 | 000656 | 000000 | BLCNTR: | 0 | ; BLOCK COUNTER |
| 1531 | 000660 | 000000 | BBC: | 0 | ; BAD RECORD COUNTER |
| 1532 | 000662 | 000000 | EOTREC: | 0 | ; EOT FLAG |
| 1533 | 000664 | 000000 | RTRN: | 0 | ; INTERRUPT RETURN STORAGE |
| 1534 | 000666 | 000000 | HDRFL: | 0 | ; HEADER FLAG |
| 1535 | 000670 | 000000 | STAL: | 0 | ; DELAY STORAGE |
| 1536 | 000672 | 000000 | PFLG: | 0 | ; PRINT FLAG |
| 1537 | 000674 | 000000 | MTC1: | 0 | ; MAG TAPE CONT REGISTER BUFFER |
| 1538 | 000676 | 000000 | UNP: | 0 | ; UNIT TABLE POINTER |
| 1539 | 000700 | 000000 | TMFLG: | 0 | ; TAPE MARK FLAG |
| 1540 | 000702 | 000000 | RPCNT: | 0 | ; REPEAT COUNTER |
| 1541 | 000704 | 000000 | RTCNT: | 0 | ; RETRY COUNTER |
| 1542 | 000706 | 000000 | DERFL: | 0 | ; DATA ERROR FLAG |
| 1543 | 000710 | 000000 | SERFL: | 0 | ; STATUS ERROR FLAG |
| 1544 | 000712 | 000000 | BCNT: | 0 | ; BIT COUNTER |
| 1545 | 000714 | 000000 | RTYFL: | 0 | ; RETRY FLAG |
| 1546 | 000716 | 000000 | UPS: | 0 | ; UNIT POINTER SAVE |
| 1547 | 000720 | 000000 | BDPP: | 0 | ; BITS DROPPED POINTER |
| 1548 | 000722 | 000000 | BPKP: | 0 | ; BITS PICKED POINTER |
| 1549 | 000724 | 000000 | ERSAV: | 0 | ; ERROR SAVE LOC |
| 1550 | 000726 | 000000 | BTFLG: | 0 | ; BAD TAPE FLAG |
| 1551 | 000730 | 000000 | BTSTF: | 0 | ; STATISTIC PRINT FLAG |
| 1552 | 000732 | 000000 | BTPT: | 0 | ; BAD TAPE POINTER |
| 1553 | 000734 | 000000 | ERTFL: | 0 | ; ERASE FLAG |
| 1554 | 000736 | | ENDFLG: | | |
| 1555 | 000736 | 000000 | ASEGF: | 0 | ; AUTO SEQ FLAG |
| 1556 | 000740 | 000000 | ADRVN: | 0 | ; UTO SEQ DRIVE NUMBER |
| 1557 | 000742 | 000000 | ABLNT: | 0 | ; AUTO BLOCK COUNTER |
| 1558 | 000744 | 000001 | ASEGCF: | 1 | ; AUTO SEQ CONTINUOUS FLAG |

1559
 1560
 1561
 1562 000746 000000
 1563 000750 000000
 1564 000752 000000
 1565 000754 000000
 1566 000756 000000
 1567 000760 000000
 1568 000762 000000
 1569 000764 000000
 1570 000766 177777
 1571
 1572
 1573
 1574 000770 001210
 1575 000772 001230
 1576 000774 001250
 1577 000776 001270
 1578 001000 001310
 1579 001002 001330
 1580 001004 001350
 1581 001006 001370
 1582 001010 001410
 1583 001012 001430
 1584 001014 001450
 1585 001016 001470
 1586 001020 001510
 1587 001022 001530
 1588 001024 001550
 1589 001026 001570
 1590
 1591
 1592
 1593 001030 001610
 1594 001032 001714
 1595 001034 002020
 1596 001036 002124
 1597 001040 002230
 1598 001042 002334
 1599 001044 002440
 1600 001046 002544
 1601
 1602
 1603
 1604
 1605 001050
 1606 001050 000000
 1607 001052 000000
 1608 001054 000000
 1609 001056 000000
 1610 001060 000000
 1611 001062 000000
 1612 001064 000000
 1613 001066 000000
 1614

;UNIT ORDER AND DESCRIPTION TABLE *****

UN1: 0
 UN2: 0
 UN3: 0
 UN4: 0
 UN5: 0
 UN6: 0
 UN7: 0
 UN8: 0
 UNX: -1

; THIS TABLE IS LOADED
 ; WITH UNIT NUMBERS AND
 ; THEIR DESCRIPTIONS IN
 ; THE ORDER THAT THEY
 ; WILL BE TESTED

;UNIT DROPS AND PICKS POINTERS*****

PIK1: BP00
 PIK2: BP10
 PIK3: BP20
 PIK4: BP30
 PIK5: BP40
 PIK6: BP50
 PIK7: BP60
 PIK8: BP70
 DRP1: B000
 DRP2: B010
 DRP3: B020
 DRP4: B030
 DRP5: B040
 DRP6: B050
 DRP7: B060
 DRP8: B070

;UNIT BAD TAPE POINTERS*****

BTADDR: BT00
 BT01
 BT02
 BT03
 BT04
 BT05
 BT06
 BT07

;UNIT WRITE RETRY COUNTER*****

;SET START OF STATISTICS TABLE

STTBL:
 RTY1: 0
 RTY2: 0
 RTY3: 0
 RTY4: 0
 RTY5: 0
 RTY6: 0
 RTY7: 0
 RTY8: 0

```

1615
1616
1617 001070 000000
1618 001072 000000
1619 001074 000000
1620 001076 000000
1621 001100 000000
1622 001102 000000
1623 001104 000000
1624 001106 000000
1625
1626 ;
1627
1628 001110 000000
1629 001112 000000
1630 001114 000000
1631 001116 000000
1632 001120 000000
1633 001122 000000
1634 001124 000000
1635 001126 000000
1636
1637
1638
1639 001130 000000
1640 001132 000000
1641 001134 000000
1642 001136 000000
1643 001140 000000
1644 001142 000000
1645 001144 000000
1646 001146 000000
1647
1648
1649
1650 001150 000000
1651 001152 000000
1652 001154 000000
1653 001156 000000
1654 001160 000000
1655 001162 000000
1656 001164 000000
1657 001166 000000
1658
1659
1660
1661 001170 000000
1662 001172 000000
1663 001174 000000
1664 001176 000000
1665 001200 000000
1666 001202 000000
1667 001204 000000
1668 001206 000000

```

```

;UNIT WRITE ERRORS*****
WTER1: 0
WTER2: 0
WTER3: 0
WTER4: 0
WTER5: 0
WTER6: 0
WTER7: 0
WTER8: 0

;UNIT READ FORWARD ERRORS*****
RDER1: 0
RDER2: 0
RDER3: 0
RDER4: 0
RDER5: 0
RDER6: 0
RDER7: 0
RDER8: 0

;UNIT DATA ERRORS FORWARD*****
DATER1: 0
0
0
0
0
0
0
0
0

;UNIT READ REVERSE ERRORS*****
RDERR1: 0
0
0
0
0
0
0
0
0

;UNIT DATA ERRORS REVERSE*****
DEREV1: 0
0
0
0
0
0
0
0

```

```
1669 ;DROPS + PICKS PER CHANNEL PER UNIT*****
1670
1671 001210 000000 BP00: 0
1672 001230 001230 .=.+16
1673 001230 000000 BP10: 0
1674 001250 001250 .=.+16
1675 001250 000000 BP20: 0
1676 001270 001270 .=.+16
1677 001270 000000 BP30: 0
1678 001310 001310 .=.+16
1679 001310 000000 BP40: 0
1680 001330 001330 .=.+16
1681 001330 000000 BP50: 0
1682 001350 001350 .=.+16
1683 001350 000000 BP60: 0
1684 001370 001370 .=.+16
1685 001370 000000 BP70: 0
1686 001410 001410 .=.+16
1687 001410 000000 B000: 0
1688 001430 001430 .=.+16
1689 001430 000000 B010: 0
1690 001450 001450 .=.+16
1691 001450 000000 B020: 0
1692 001470 001470 .=.+16
1693 001470 000000 B030: 0
1694 001510 001510 .=.+16
1695 001510 000000 B040: 0
1696 001530 001530 .=.+16
1697 001530 000000 B050: 0
1698 001550 001550 .=.+16
1699 001550 000000 B060: 0
1700 001570 001570 .=.+16
1701 001570 000000 B070: 0
1702 001610 001610 .=.+16
1703
1704
```

1705
 1706
 1707
 1708 001610 000000
 1709 001714 001714
 1710 001714 000000
 1711 002020 002020
 1712 002020 000000
 1713 002124 002124
 1714 002124 000000
 1715 002230 002230
 1716 002230 000000
 1717 002334 002334
 1718 002334 000000
 1719 002440 002440
 1720 002440 000000
 1721 002544 002544
 1722 002544 000000
 1723 002650 002650
 1724
 1725
 1726
 1727 002650 000000
 1728 002652 000000
 1729 002654 000000
 1730 002656 000000
 1731 002660 000000
 1732 002662 000000
 1733 002664 000000
 1734 002666 000000
 1735
 1736
 1737
 1738 002670 000000
 1739 002672 000000
 1740 002674 000000
 1741 002676 000000
 1742 002700 000000
 1743 002702 000000
 1744 002704 000000
 1745 002706 000000
 1746
 1747
 1748
 1749 002710 000000
 1750 002712 000000
 1751 002714 000000
 1752 002716 000000
 1753 002720 000000
 1754 002722 000000
 1755 002724 000000
 1756 002726 000000
 1757

;UNIT BAD TAPE COUNTER:16 PER SLAVE*****

BT00: 0
 .=.+102
 BT01: 0
 .=.+102
 BT02: 0
 .=.+102
 BT03: 0
 .=.+102
 BT04: 0
 .=.+102
 BT05: 0
 .=.+102
 BT06: 0
 .=.+102
 BT07: 0
 .=.+102

;UNIT END OF TAPE COUNTERS 1 PER SLAVE*****

EOTCO: 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0

;UNIT READ FORWARD SOFT ERROR*****

RFSOFT: 0
 0
 0
 0
 0
 0
 0
 0
 0
 0

;UNIT READ REVERSE SOFT ERROR*****

RRSOFT: 0
 0
 0
 0
 0
 0
 0
 0
 0
 0

```

1758
1759
1760
1761 002730 000000
1762 002732 000000
1763 002734 000000
1764 002736 000000
1765 002740 000000
1766 002742 000000
1767 002744 000000
1768 002746 000000
1769
1770
1771
1772 002750 000000
1773 002752 000000
1774 002754 000000
1775 002756 000000
1776 002760 000000
1777 002762 000000
1778 002764 000000
1779 002766 000000
1780
1781 002770
1782
1783
1784
1785 002770 002770
1786 002772 014274
1787 002774 014434
1788 002776 014454
1789 003000 014460
1790 003002 014504
1791 003004 014514
1792 003006 014522
1793 003010 014530
1794 003012 014556
1795 003014 014606
1796 003016 014626
1797 003020 014650
1798 003022 014660
1799 003024 014710
1800

```

;UNIT READ FORWARD HARD ERROR*****

```

RFHARD: 0
         0
         0
         0
         0
         0
         0
         0

```

;UNIT READ REVERSE HARD ERROR*****

```

RRHARD: 0
         0
         0
         0
         0
         0
         0
         0

```

;SET END OF STATISTICS TABLE
ENDTBL:

;DATA PATTERN GENERATORS*****

```

DATBL: .
DATA0: DAT0
DATA1: DAT1
DATA2: DAT2
DATA3: DAT3
DATA4: DAT4
DATA5: DAT5
DATA6: DAT6
DATA7: DAT7
DATA10: DAT10
DATA11: DAT11
DATA12: DAT12
DATA13: DAT13
DATA14: DAT14
DATA15: DAT15

```

```

;ENTRY TABLE
;EXTERNAL INPUT FROM H/S READER(SEE MAINDEC-11-DZTUF)
;ALL ONES
;ALL ZEROS
;WALKING ONE
;WALKING ZERO
;ALTERNATING ONE/ZERO
;ALTERNATING ZERO/ONE
;ALTERNATING ONE/ZERO IN ALTERNATING CHARACTERS
;WALKING ONE/ALL ONE IN ALTERNATING CHARACTERS
;ALL BITS 0-377
;ALL BITS 377-0
;ALTERNATING CHARACTERS 0 AND 377
;WALKING ZERO/ALL ZERO IN ALTERNATING CHARACTERS
;AUTO SEQUENCE PATTERN 0,0,-1,-1,-1,0,0

```

1801
1802
1803
1804
1805
1806
1807
1808
1809
1810
1811
1812
1813
1814
1815
1816
1817
1818
1819
1820
1821
1822
1823
1824
1825
1826
1827
1828
1829
1830
1831
1832
1833
1834
1835
1836
1837
1838
1839
1840
1841
1842
1843
1844
1845
1846
1847
1848
1849
1850
1851
1852
1853
1854
1855
1856

.EVEN

PROGRAM START AND SEQUENCE FORMATTER:
THIS ROUTINE IS USED TO PERFORM ALL HOUSEKEEPING,
DECIDE WHICH TRANSPORT TO TEST AND ITS AVAILABILITY,
LOAD THE WRITE BUFFER WITH THE SELECTED DATA PATTERN,
GENERATE ANY RANDOM NUMBER AND THEN EXECUTE
THE TEST CYCLE REQUESTED BY THE SWITCH SETTING.
AT THE END OF THE TEST CYCLE THE NEXT UNIT IS SELECTED
AND CHECKED FOR AVAILABILITY AND THE TEST CYCLE IS
EXECUTED ON IT.
THE READ WRITE STATS MAY BE PRINTED AT THE END OF
EACH TEST CYCLE VIA CONSOLE SWITCH FOURTEEN (14).

```

;START 200, & 300*****
START:  MOV    #500,SP      ;SET STACK PTR
        CLR    ASEQF      ;CLEAR AUTO SEQUENCE FLAG
        CLR    (PC)+      ;CLEAR CHAIN INDICATOR
CHNFLG: .WORD  0          ;CHAIN MODE INDICATOR
                               ;1/0 = CHAIN/NOT CHAIN MODE
                               ;;BRANCH IF LOADED VIA ACT11 CHAIN MODE
        CMP    #SENDAD,2#42
        BEQ    50$
        TST   2#42        ;;BRANCH IF IN DUMP MODE
        BEQ    52$
        BR    51$
50$:   MOV    #SWREG,SWR   ;; INVOKE SOFTWARE SWR
        MOV    #100000,2SWR ;WITH HALT ON ERROR SET
51$:   INC    CHNFLG      ;SET CHNFLG = CHAIN MODE
        JMP   3$         ;;GO TO CHAIN ADDRESS
52$:   CMPB   #6,2#41     ;BRANCH IF LOADED VIA TMDP
        BNE   STAUT
        MOV   #MSG120,R4  ;ADVISE USER TO REMOVE TMDP FROM SLAVE
        TYPE
        BR    STAUT
3$:    INC    ASEQF      ;SET AUTO SEQUENCE FLAG
        JMP   ASEQ0     ;GO TO AUTO SEQUENCER

;START 240*****
STAUT:  MOV    #1,TINF    ;SET TTY ENTRY FLAG
        CLR    RDFL      ;CLEAR RANDOM DATA FLAG
        BR    STARTB

;START 204*****
STARTC: CLR    TINF      ;CLEAR TTY INPUT FLAG
        BR    STARTD

;START 210*****
STARTA: CLR    TINF      ;CLEAR TTY ENTRY FLAG
STARTB: MOV    #STFLG,R0  ;GET STARTING ADDRESS OF FLAGS
        MOV    #ENDFLG-STFLG,R1
1$:    CLRB   (R0)+      ;CLEAR FLAGS AND COUNTERS
        DEC   R1

```

| | | | | | | | | | |
|------|--------|--------|--------|--------|---------|------|--------------------|--------------------------------------|--|
| 1857 | 003200 | 001375 | | | | BNE | 1\$ | | |
| 1858 | 003202 | 012706 | 000500 | | | MOV | #500, SP | ; SET STACK POINTER | |
| 1859 | 003206 | 004737 | 004276 | | | JSR | PC, RANSET | ; GO RESET RANDOM BASE | |
| 1860 | 003212 | 012700 | 001050 | | | MOV | #STTB, R0 | ; GET STARTING ADDRESS OF STAT TABLE | |
| 1861 | 003216 | 012701 | 001720 | | | MOV | #ENDTBL - STTB, R1 | ; AND # OF BYTES IN TABLE | |
| 1862 | 003222 | 105020 | | | 2\$: | CLRB | (R0)+ | ; CLEAR STATISTIC COUNTERS | |
| 1863 | 003224 | 005301 | | | | DEC | R1 | | |
| 1864 | 003226 | 001375 | | | | BNE | 2\$ | | |
| 1865 | 003230 | 012737 | 177777 | 014270 | | MOV | #-1, PATS | ; PRESET PATTERN | |
| 1866 | 003236 | 012737 | 000001 | 000656 | STARTE: | MOV | #1, BLCNTR | ; PRESET BLOCK COUNTER | |
| 1867 | 003244 | 013746 | 000004 | | STARTD: | MOV | #4, -(SP) | ; SAVE ERROR TRAP VECTOR | |
| 1868 | 003250 | 013746 | 000006 | | | MOV | #6, -(SP) | | |
| 1869 | 003254 | 022737 | 000176 | 000610 | | CMP | #SWREG, SWR | ; BRANCH IF SOFTWARE SWR | |
| 1870 | 003262 | 001413 | | | | BEQ | 2\$ | ; ALREADY SELECTED | |
| 1871 | 003264 | 012737 | 003310 | 000004 | | MOV | #1\$, #4 | ; SET TIMEOUT TRAP TO 1\$ BELOW | |
| 1872 | 003272 | 005037 | 000006 | | | CLR | #6 | | |
| 1873 | 003276 | 022777 | 177777 | 175304 | | CMP | #177777, #SWR | ; BRANCH IF SWR = 177777 TRAP | |
| 1874 | 003304 | 001402 | | | | BEQ | 2\$ | ; IF NOT AVAIL (1\$) OTHERWISE | |
| 1875 | 003306 | 000404 | | | | BR | 3\$ | ; GO TO 3\$ | |
| 1876 | 003310 | 022626 | | | 1\$: | CMP | (SP)+, (SP)+ | ; RESET STACK | |
| 1877 | 003312 | 012737 | 000176 | 000610 | 2\$: | MOV | #SWREG, SWR | ; SET SWR = SOFTWARE SWR | |
| 1878 | 003320 | 012637 | 000006 | | 3\$: | MOV | (SP)+, #6 | ; RESTORE ERROR TRAP | |
| 1879 | 003324 | 012637 | 000004 | | | MOV | (SP)+, #4 | | |
| 1880 | 003330 | 012706 | 000500 | | | MOV | #500, SP | | |
| 1881 | 003334 | 004737 | 012212 | | | JSR | PC, T1NP | ; GO GET PARAMETERS FROM TTY | |
| 1882 | 003340 | 012777 | 000040 | 175152 | | MOV | #40, #CS | ; INITIALIZE | |
| 1883 | 003346 | 005000 | | | STAUTO: | CLR | R0 | ; POINT TO FIRST ENTRY | |
| 1884 | 003350 | 022760 | 177777 | 000746 | 1\$: | CMP | #-1, UN1(R0) | ; BRANCH IF LAST ENTRY | |
| 1885 | 003356 | 001406 | | | | BEQ | 2\$ | | |
| 1886 | 003360 | 042760 | 100000 | 000746 | | BIC | #100000, UN1(R0) | ; CLEAR EOT FLAG | |
| 1887 | 003366 | 062700 | 000002 | | | ADD | #2, R0 | ; POINT TO NEXT UNIT ENTRY | |
| 1888 | 003372 | 000766 | | | | BR | 1\$ | ; CONTINUE CLEARING | |
| 1889 | 003374 | 013703 | 005054 | | 2\$: | MOV | REOTC, R3 | | |
| 1890 | 003400 | 000303 | | | | SWAB | R3 | | |
| 1891 | 003402 | 110337 | 005054 | | | MOVB | R3, REOTC | ; RESTORE EOT CNTR | |
| 1892 | 003406 | 012777 | 000100 | 175176 | START1: | MOV | #100, #TKS | ; SET KEYBOARD IE BIT | |
| 1893 | 003414 | 013700 | 000676 | | | MOV | UNP, R0 | ; R0 = UNIT TABLE POINTER | |
| 1894 | 003420 | 022760 | 177777 | 000746 | STAR1A: | CMP | #-1, UN1(R0) | ; BRANCH IF LAST ENTRY | |
| 1895 | 003426 | 001404 | | | | BEQ | STAR1B | | |
| 1896 | 003430 | 016037 | 000746 | 000552 | | MOV | UN1(R0), UDES | ; LOAD NEXT UNIT DESCRIPTION | |
| 1897 | 003436 | 000446 | | | | BR | START4 | | |
| 1898 | 003440 | 005237 | 000656 | | STAR1B: | INC | BLCNTR | ; BUMP BLOCK COUNTER | |
| 1899 | 003444 | 005737 | 000736 | | | TST | ASEQF | ; SEE IF AUTO SEQ | |
| 1900 | 003450 | 001411 | | | | BEQ | STAR1C | ; IF NOT: BR | |
| 1901 | 003452 | 023737 | 000656 | 000742 | | CMP | BLCNTR, ABLCNT | ; SEE IF DONE SEQ | |
| 1902 | 003460 | 001005 | | | | BNE | STAR1C | ; IF NOT: BR | |
| 1903 | 003462 | 005037 | 000656 | | | CLR | BLCNTR | ; RESET BLOCK CNTR | |
| 1904 | 003466 | 005037 | 000676 | | | CLR | UNP | ; RESET UNIT POINTER | |
| 1905 | 003472 | 000207 | | | | RTS | PC | ; RETURN TO AUTO SEQ | |
| 1906 | 003474 | 005037 | 000676 | | STAR1C: | CLR | UNP | | |
| 1907 | 003500 | 005000 | | | | CLR | R0 | | |
| 1908 | 003502 | 016037 | 000746 | 000552 | | MOV | UN1(R0), UDES | ; LOAD FIRST UNIT DESCRIPTION | |
| 1909 | 003510 | 032777 | 000200 | 175072 | | BIT | #200, #SWR | ; SEE IF RANDOM RECORD SIZE | |
| 1910 | 003516 | 001402 | | | | BEQ | START2 | ; IF NOT: BR | |
| 1911 | 003520 | 004737 | 012126 | | | JSR | PC, CCNTR | ; GO GENERATE RANDOM RECORD SIZE | |
| 1912 | 003524 | 032777 | 000400 | 175056 | START2: | BIT | #400, #SWR | ; SEE IF RANDOM DATA | |

| | | | | | | | | |
|------|--------|--------|--------|--------|-------------|----------------|--|-----------------------------------|
| 1913 | 003532 | 001402 | | | BEQ | START3 | | ; IF NOT: BR |
| 1914 | 003534 | 004737 | 014760 | | JSR | PC, DATA | | ; GO GENERATE RANDOM DATA |
| 1915 | 003540 | 032777 | 000100 | 175042 | START3: BIT | #100, JSWR | | ; SEE IF RANDOM RECORD COUNT |
| 1916 | 003546 | 001402 | | | BEQ | START4 | | ; IF NOT: BR |
| 1917 | 003550 | 004737 | 012166 | | JSR | PC, RCNTR | | ; GO GENERATE RANDOM RECORD COUNT |
| 1918 | 003554 | 005760 | 000746 | | START4: TST | UN1(R0) | | ; SEE IF REACHED EOT |
| 1919 | 003560 | 100002 | | | BPL | STAR40 | | ; IF NOT: BR |
| 1920 | 003562 | 000137 | 004264 | | JMP | START7 | | ; ELSE GO TO NEXT UNIT |
| 1921 | 003566 | 013777 | 000550 | 174724 | STAR40: MOV | DVN, ACS | | ; SET DRIVE NUMBER |
| 1922 | 003574 | 013777 | 000552 | 174740 | MOV | UDES, JTC | | ; SET UNIT NUMBER |
| 1923 | 003602 | 105777 | 174714 | | TSTB | JDS | | ; SEE IF UNIT AVAIL |
| 1924 | 003606 | 100412 | | | BMI | STAR4A | | ; IF SO: BR |
| 1925 | 003610 | 005337 | 000670 | | DEC | STAL | | |
| 1926 | 003614 | 001357 | | | BNE | START4 | | ; AWAIT TUR |
| 1927 | 003616 | 004737 | 022570 | | JSR | PC, PAPRT | | ; PRINT HEADER |
| 1928 | 003622 | 012704 | 025731 | | MOV | #MSG49, R4 | | |
| 1929 | 003626 | 000004 | | | TYPE | | | ; TYPE MSG |
| 1930 | 003630 | 000000 | | | HALT | | | ; STOP |
| 1931 | 003632 | 000750 | | | BR | START4 | | ; RETRY |
| 1932 | 003634 | 004737 | 014110 | | STAR4A: JSR | PC, DSUP | | ; GO SET UP WRITE DATA |
| 1933 | 003640 | 004737 | 005426 | | JSR | PC, INIT | | ; INIT SLAVE |
| 1934 | 003644 | 004737 | 005056 | | JSR | PC, RIND | | ; REWIND |
| 1935 | 003650 | 004737 | 005534 | | JSR | PC, WRITE | | ; WRITE |
| 1936 | 003654 | 013737 | 000600 | 000670 | MOV | TSTAL, STAL | | ; SET TURN AROUND DELAY |
| 1937 | 003662 | 004737 | 012116 | | JSR | PC, STALL | | ; DELAY |
| 1938 | 003666 | 004737 | 007416 | | JSR | PC, RSEQ | | ; GO TO READ SEQUENCER |
| 1939 | 003672 | 013737 | 000600 | 000670 | MOV | TSTAL, STAL | | ; SET TURN AROUND DELAY |
| 1940 | 003700 | 004737 | 012116 | | JSR | PC, STALL | | ; DELAY |
| 1941 | 003704 | 032777 | 040000 | 174676 | BIT | #40000, JSWR | | ; SEE IF SHOULD PRINT STATISTICS |
| 1942 | 003712 | 001541 | | | BEQ | START5 | | ; IF NOT: BR |
| 1943 | 003714 | 012700 | 000001 | | MOV | #1, R0 | | ; SET RECORD COUNTER TO 1 |
| 1944 | 003720 | 004737 | 022570 | | JSR | PC, PAPRT | | ; PRINT CYCLE NUMBER |
| 1945 | 003724 | 004737 | 003734 | | JSR | PC, STP | | ; GO PRINT STATS |
| 1946 | 003730 | 000137 | 004202 | | JMP | STPX | | |
| 1947 | 003734 | 004737 | 017100 | | STAR4: JSR | PC, DPPRT | | ; PRINT DROPS AND PICKS |
| 1948 | 003740 | 012704 | 026143 | | MOV | #MSG65, R4 | | |
| 1949 | 003744 | 000004 | | | TYPE | | | ; TYPE MSG |
| 1950 | 003746 | 013704 | 000676 | | MOV | UNP, R4 | | |
| 1951 | 003752 | 016403 | 001050 | | MOV | RTY1(R4), R3 | | |
| 1952 | 003756 | 104400 | | | TYPOCT | | | ; PRINT RETRIES |
| 1953 | 003760 | 012704 | 026314 | | MOV | #MSG73, R4 | | |
| 1954 | 003764 | 000004 | | | TYPE | | | ; TYPE MSG |
| 1955 | 003766 | 013704 | 000676 | | MOV | UNP, R4 | | |
| 1956 | 003772 | 016403 | 001070 | | MOV | WTER1(R4), R3 | | |
| 1957 | 003776 | 104400 | | | TYPOCT | | | ; PRINT WRITE ERRORS |
| 1958 | 004000 | 012704 | 026303 | | MOV | #MSG72, R4 | | |
| 1959 | 004004 | 000004 | | | TYPE | | | ; TYPE MSG |
| 1960 | 004006 | 013704 | 000676 | | MOV | UNP, R4 | | |
| 1961 | 004012 | 016403 | 001110 | | MOV | RDER1(R4), R3 | | |
| 1962 | 004016 | 104400 | | | TYPOCT | | | ; PRINT READ FORWARD ERRORS |
| 1963 | 004020 | 012704 | 027107 | | MOV | #MSG113, R4 | | |
| 1964 | 004024 | 000004 | | | TYPE | | | ; TYPE MSG |
| 1965 | 004026 | 013704 | 000676 | | MOV | UNP, R4 | | |
| 1966 | 004032 | 016403 | 002670 | | MOV | RFSOFT(R4), R3 | | |
| 1967 | 004036 | 104400 | | | TYPOCT | | | ; PRINT FORWARD SOFT ERRORS |
| 1968 | 004040 | 012704 | 027120 | | MOV | #MSG114, R4 | | |

| | | | | | | | |
|------|--------|--------|--------|---------|---------|---------------|----------------------------------|
| 1969 | 004044 | 000004 | | | TYPE | | ;TYPE MSG |
| 1970 | 004046 | 013704 | 000676 | | MOV | UNP,R4 | |
| 1971 | 004052 | 016403 | 002730 | | MOV | RFHARD(R4),R3 | |
| 1972 | 004056 | 104400 | | | TYPOCT | | ;PRINT HARD FORWARE ERRORS |
| 1973 | 004060 | 012704 | 026374 | | MOV | #MSG77,R4 | |
| 1974 | 004064 | 000004 | | | TYPE | | ;TYPE MSG |
| 1975 | 004066 | 013704 | 000676 | | MOV | UNP,R4 | |
| 1976 | 004072 | 016403 | 001130 | | MOV | DATER1(R4),R3 | |
| 1977 | 004076 | 104400 | | | TYPOCT | | ;PRINT DATA ERROR FORWARD NUMBER |
| 1978 | 004100 | 012704 | 026177 | | MOV | #MSG68,R4 | |
| 1979 | 004104 | 000004 | | | TYPE | | ;TYPE MSG |
| 1980 | 004106 | 013704 | 000676 | | MOV | UNP,R4 | |
| 1981 | 004112 | 016403 | 001150 | | MOV | RDEAR1(R4),R3 | |
| 1982 | 004116 | 104400 | | | TYPOCT | | ;PRINT REVESE ERROR NUMBER |
| 1983 | 004120 | 012704 | 027107 | | MOV | #MSG113,R4 | |
| 1984 | 004124 | 000004 | | | TYPE | | ;TYPE MSG |
| 1985 | 004126 | 013704 | 000676 | | MOV | UNP,R4 | |
| 1986 | 004132 | 016403 | 002710 | | MOV | RRSOFT(R4),R3 | |
| 1987 | 004136 | 104400 | | | TYPOCT | | ;PRINT REVERSE SOFT ERROR |
| 1988 | 004140 | 012704 | 027120 | | MOV | #MSG114,R4 | |
| 1989 | 004144 | 000004 | | | TYPE | | ;TYPE MSG |
| 1990 | 004146 | 013704 | 000676 | | MOV | UNP,R4 | |
| 1991 | 004152 | 016403 | 002750 | | MOV | RRHARD(R4),R3 | |
| 1992 | 004156 | 104400 | | | TYPOCT | | |
| 1993 | 004160 | 012704 | 026363 | | MOV | #MSG76,R4 | |
| 1994 | 004164 | 000004 | | | TYPE | | ;TYPE MSG |
| 1995 | 004166 | 013704 | 000676 | | MOV | UNP,R4 | |
| 1996 | 004172 | 016403 | 001170 | | MOV | DEREV1(R4),R3 | |
| 1997 | 004176 | 104400 | | | TYPOCT | | ;PRINT DATA REVERSE ERROR NUMBER |
| 1998 | 004200 | 000207 | | | RTS | PC | ;RETURN |
| 1999 | 004202 | 005237 | 000730 | STPX: | INC | BTSTF | ;SET STAT ONLY PRINT |
| 2000 | 004206 | 004737 | 007326 | | JSR | PC,BTPRT | ;PRINT BAD TAPE STATS |
| 2001 | 004212 | 005037 | 000730 | | CLR | BTSTF | ;CLEAR FLAG |
| 2002 | 004216 | 017700 | 174366 | START5: | MOV | 2SMR,RO | ;LOAD SMR |
| 2003 | 004222 | 042700 | 177762 | | BIC | #177762,RO | ;MASK READ/WRITE SWITCHES |
| 2004 | 004226 | 022700 | 000015 | | CMP | #15,RO | ;SEE IF HAVE READ OR WRITE |
| 2005 | 004232 | 001417 | | | BEQ | START8 | ;IF NOT: BR |
| 2006 | 004234 | 105777 | 174262 | START6: | TSTB | 2DS | ;SEE IF HAVE UNIT READY |
| 2007 | 004240 | 100411 | | | BMI | START7 | ;IF SO: BR |
| 2008 | 004242 | 005337 | 000670 | | DEC | STAL | |
| 2009 | 004246 | 001372 | | | BNE | START6 | ;DELAY FOR TUR |
| 2010 | 004250 | 004737 | 022570 | | JSR | PC,PAPRT | ;PRINT HEADER |
| 2011 | 004254 | 012704 | 025731 | | MOV | #MSG49,R4 | |
| 2012 | 004260 | 000004 | | | TYPE | | ;TYPE MSG |
| 2013 | 004262 | 000000 | | | HALT | | ;STOP |
| 2014 | 004264 | 062737 | 000002 | 000676 | START7: | ADD | #2,UNP |
| 2015 | 004272 | 000137 | 003406 | | START8: | JMP | START1 |
| 2016 | | | | | | | |
| 2017 | | | | | | | |
| 2018 | | | | | | | |
| 2019 | 004276 | 012737 | 153624 | 000626 | RANSET: | MOV | #153624,RANBAS |
| 2020 | 004304 | 012737 | 032561 | 000630 | | MOV | #32561,RANSAV |
| 2021 | 004312 | 013737 | 000632 | 000554 | | MOV | RCSAV,RCNT |
| 2022 | 004320 | 013737 | 000634 | 000556 | | MOV | FCSAV,FMCNT |
| 2023 | 004326 | 000207 | | | RTS | PC | ;RESET FRAME COUNT |
| 2024 | | | | | | | |

;RANDOM BASE RESET*****

2025
2026
2027
2028
2029
2030
2031
2032
2033
2034
2035
2036
2037 004330 013777 000552 174204
2038 004336 012777 000011 174144
2039 004344 105777 174152
2040 004350 100375
2041 004352 012777 000007 174130
2042 004360 005737 000726
2043 004364 001004
2044 004366 013700 000662
2045 004372 042700 100000
2046 004376 005037 000662
2047 004402 004737 022570
2048 004406 022737 000002 000726
2049 004414 001003
2050 004416 012704 027000
2051 004422 000406
2052 004424 022737 000001 000726
2053 004432 001004
2054 004434 012704 026626
2055 004440 000004
2056 004442 000412
2057 004444 012704 024636
2058 004450 000004
2059 004452 013704 000676
2060 004456 005264 002650
2061 004462 016403 002650
2062 004466 104400
2063 004470 012704 026653
2064 004474 000004
2065 004476 005037 000726
2066 004502 004737 003734
2067 004506 004737 007326
2068 004512 105777 174004
2069 004516 100414
2070 004520 005337 000670
2071 004524 001372
2072 004526 012737 024475 000654
2073 004534 004737 022570
2074 004540 012704 026105
2075 004544 000004
2076 004546 000000
2077 004550 105337 005054
2078 004554 001410
2079 004556 013700 000676
2080 004562 052760 100000 000746

```

*****
:REWIND FROM EOT:
*****
:WHEN ANY TRANSPORT BEING TESTED REACHES END OF TAPE
:DURING A READ OR WRITE OPERATION, IT WILL BE REWOUND
:AND FLAGGED AS UNAVAILABLE UNTIL ALL AVAILABLE UNITS
:HAVE REACHED EOT AT WHICH TIME ALL TESTING WILL BE RESUMED
:AT A BLOCK COUNT OF ONE (1). A MESSAGE WILL BE
:PRINTED ON THE SUPERVISORS CONSOLE AS EACH UNIT REACHES
:EOT AND IS REWOUND.
*****
REOT:  MOV      UDES, JTC      ;LOAD TAPE CONTROL REGISTER
        MOV      #11, JCI     ;DRIVE CLEAR
IS:    TSTB     JDS          ;WAIT FOR DRY
        BPL     IS
        MOV      #7, JCI     ;START REWIND
        TST     BTFLG        ;SEE IF BAD TAPE OVERFLOW REWIND
        BNE     REOT1A       ;IF SO: BR
        MOV      EOTREC, RO
        BIC     #100000, RO   ;SET RECORD NUMBER OF EOT
REOT1A: CLR     EOTREC        ;CLEAR EOT INDICATOR & REC COUNT
        JSR     PC, PAPRT     ;PRINT HEADER
        CMP     #2, BTFLG    ;SEE IF POSITION ERROR
        BNE     REOT1B       ;IF NOT: BR
        MOV      #MSG109, R4  ;SET POSITION ERROR MSG
        BR     REOT1F
REOT1B: CMP     #1, BTFLG    ;SEE IF BAD TAPE OVERFLOW
        BNE     REOT1C       ;IF NOT: BR
        MOV      #MSG106, R4  ;SET BAD TAPE OVERFLOW MSG
REOT1F: TYPE
REOT1C: MOV     REOT1E
        TYPE
        MOV      #MSG20, R4   ;SET EOT MSG
        TYPE MSG
        MOV      UNP, R4
        INC     EOTCO(R4)    ;BUMP CNTR
        MOV      EOTCO(R4), R3
REOT1E: MOV     #MSG16A, R4   ;PRINT EOT CNTR
        TYPE MSG
        CLR     BTFLG        ;CLEAR BAD TAPE FLAG
        JSR     PC, STP       ;PRINT STATS
REOT2: JSR     PC, BTPRT     ;PRINT BAD TAPE STATS
        TSTB     JDS          ;BRANCH IF DRY SET
        BMI     REOT2A
        DEC     STAL
        BNE     REOT2
        MOV      #MSG6, EMADDR ;WAIT DRY
        JSR     PC, PAPRT     ;PRINT HEADER
        MOV      #MSG60, R4
        TYPE MSG
REOT2A: DECB    REOTC        ;SEE IF LAST UNIT TO REACH EOT
        BEQ     REOT3
        MOV      UNP, RO
        BIS     #100000, UN1(RO) ;SET EOT FLAG

```

| | | | | | | | | |
|------|--------|--------|--------|--------|---------|--------|------------------|------------------------------|
| 2081 | 004570 | 005726 | | | TST | (SP)+ | | ;RESET STACK POINTER |
| 2082 | 004572 | 000137 | 004264 | | JMP | START7 | | ;GO TO NEXT UNIT |
| 2083 | 004576 | 000337 | 005054 | | REOT3: | SWAB | REOTC | |
| 2084 | 004602 | 013700 | 005054 | | | MOV | REOTC,RO | |
| 2085 | 004606 | 000337 | 005054 | | | SWAB | REOTC | |
| 2086 | 004612 | 110037 | 005054 | | | MOVB | RO,REOTC | ;RESTORE EOT UNIT COUNTER |
| 2087 | 004616 | 005037 | 000676 | | | CLR | UNP | |
| 2088 | 004622 | 013700 | 000676 | | | MOV | UNP,RO | ;POINT TO FIRST UNIT |
| 2089 | 004626 | 016037 | 000746 | 000552 | REOT4: | MOV | UN1(RO), UDES | ;LOAD UNIT DESCRIPTION |
| 2090 | 004634 | 013777 | 000552 | 173700 | | MOV | UDES, JTC | ;LOAD COMMAND REGISTER |
| 2091 | 004642 | 032777 | 020000 | 173652 | REOT5: | BIT | #20000, JDS | |
| 2092 | 004650 | 001374 | | | | BNE | REOT5 | ;AWAIT PIP RESET |
| 2093 | 004652 | 032777 | 000002 | 173642 | | BIT | #2, JDS | ;SEE IF HAVE BOT |
| 2094 | 004660 | 001012 | | | | BNE | REOT6 | ;IF SO: BR |
| 2095 | 004662 | 012700 | 000001 | | | MOV | #1, RO | |
| 2096 | 004666 | 004737 | 022570 | | | JSR | PC, PAPRT | ;PRINT HEADER |
| 2097 | 004672 | 012704 | 025676 | | | MOV | #MSG48, R4 | |
| 2098 | 004676 | 000004 | | | | TYPE | | ;TYPE MSG |
| 2099 | 004700 | 000000 | | | | HALT | | |
| 2100 | 004702 | 013700 | 000676 | | | MOV | UNP, RO | |
| 2101 | 004706 | 042760 | 100000 | 000746 | REOT6: | BIC | #100000, UN1(RO) | ;CLEAR EOT FLAG |
| 2102 | 004714 | 062737 | 000002 | 000676 | | ADD | #2, UNP | |
| 2103 | 004722 | 013700 | 000676 | | | MOV | UNP, RO | ;POINT TO NEXT UNIT |
| 2104 | 004726 | 022760 | 177777 | 000746 | | CHP | #-1, UN1(RO) | ;BRANCH IF NOT LAST UNIT |
| 2105 | 004734 | 001334 | | | | BNE | REOT4 | |
| 2106 | 004736 | 005037 | 000676 | | REOT7: | CLR | UNP | ;CLEAR UNIT POINTER |
| 2107 | 004742 | 005037 | 000636 | | | CLR | TINF | ;CLEAR TTY INPUT FLAG |
| 2108 | 004746 | 005737 | 000736 | | | TST | ASEQF | ;SEE IF AUTO SEQ |
| 2109 | 004752 | 001402 | | | | BEQ | REOTX | ;IF NOT: BR |
| 2110 | 004754 | 005726 | | | | TST | (SP)+ | ;RESET STACK POINTER |
| 2111 | 004756 | 000207 | | | | RTS | PC | ;RETURN TO AUTO SEQ |
| 2112 | 004760 | 004737 | 004276 | | REOTX: | JSR | PC, RANSET | ;GO RESET RANDOM BASE |
| 2113 | 004764 | 012737 | 177777 | 014270 | | MOV | #-1, PATS | ;PRESET PATTERN |
| 2114 | 004772 | 005037 | 015022 | | | CLR | RDFL | ;CLEAR RANDOM FLAG |
| 2115 | 004776 | 005737 | 000572 | | | TST | SPFLG | ;SEE IF SINGLE PASS |
| 2116 | 005002 | 001422 | | | | BEQ | REOTXX | ;IF NOT: BR |
| 2117 | 005004 | 012704 | 026506 | | TEND: | MOV | #MSG100, R4 | |
| 2118 | 005010 | 000004 | | | | TYPE | | ;TYPE MSG |
| 2119 | 005012 | 013700 | 000042 | | | MOV | #42, RO | ;GET ACT11 RETURN ADDRESS |
| 2120 | 005016 | 001405 | | | | BEQ | HERE | ;BRANCH IF NOT ACT11 |
| 2121 | 005020 | 000005 | | | | RESET | | |
| 2122 | 005022 | 004710 | | | SENDAD: | JSR | PC, (RO) | |
| 2123 | 005024 | 000240 | | | | NOP | | |
| 2124 | 005026 | 000240 | | | | NOP | | |
| 2125 | 005030 | 000240 | | | | NOP | | |
| 2126 | 005032 | 000240 | | | HERE: | NOP | | |
| 2127 | 005034 | 005737 | 003040 | | | TST | CHNFLG | ;BRANCH IF NOT CHAIN MODE |
| 2128 | 005040 | 001402 | | | | BEQ | IS | |
| 2129 | 005042 | 000137 | 021766 | | | JMP | ASEQ0 | ;RETURN TO AUTO SEQUENCER |
| 2130 | 005046 | 000000 | | | IS: | HALT | | |
| 2131 | 005050 | 000137 | 003236 | | REOTXX: | JMP | STARTE | ;RESTART AT BLOCK NUMBER ONE |
| 2132 | 005054 | 000000 | | | REOTC: | 0 | | ;EOT UNIT COUNTER |

```

2133
2134
2135
2136
2137
2138
2139
2140
2141
2142 005056 032777 001000 173524 RWND: BIT #1000,2SWR ;SEE IF SHOULD REWIND
2143 005064 001001 BNE RWND4 ;IF SO: BR
2144 005066 000207 RTS PC ;ELSE EXIT
2145 005070 013737 000676 000716 RWND4: MOV UNP,UPS ;SAVE UNIT POINTER
2146 005076 005037 000676 CLR UNP ;CLEAR POINTER
2147 005102 005037 000662 CLR EOTREC ;CLEAR EDT FLAG
2148 005106 000337 005054 SWAB REOTC
2149 005112 013700 005054 MOV REOTC,RO
2150 005116 000337 005054 SWAB REOTC
2151 005122 110037 005054 MOV8 RO,REOTC ;RESTORE EOT UNIT COUNTER
2152 005126 013700 000676 RWND0: MOV UNP,RO ;POINT TO UNIT ENTRY
2153 005132 022760 177777 000746 CMP #-1,UN1(RO) ;BRANCH IF LAST ENTRY
2154 005140 001445 BEQ RWND2
2155 005142 005760 000746 TST UN1(RO) ;SEE IF ALREADY REWINDING
2156 005146 100433 BMI RWND1A ;IF SO: BR
2157 005150 016037 000746 000552 MOV UN1(RO), UDES ;SET UNIT DESCRIPTION
2158 005156 013777 000552 173356 MOV UDES,2TC ;LOAD COMMAND REGISTER
2159 005164 012777 000011 173316 MOV #11,2C1 ;DRIVE CLEAR
2160 005172 012777 000007 173310 MOV #7,2C1 ;START REWIND
2161 005200 105777 173316 1S: TSTB 2DS
2162 005204 100414 BMI RWND1A ;IF DRY: BR
2163 005206 005337 000670 DEC STAL
2164 005212 001372 BNE 1S ;AWAIT DRY
2165 005214 012737 024475 000654 MOV #MSG6,EMADDR
2166 005222 004737 022570 JSR PC,PAPRT ;PRINT HEADER
2167 005226 012704 026226 MOV #MSG70,R4
2168 005232 000004 TYPE ;TYPE MSG
2169 005234 000000 HALT
2170 005236 042760 100000 000746 RWND1A: BIC #100000,UN1(RO) ;CLEAR EOT FLAG
2171 005244 062737 000002 000676 ADD #2,UNP ;BUMP POINTER
2172 005252 000725 BR RWND0 ;DO NEXT UNIT
2173 005254 005037 000676 RWND2: CLR UNP ;CLEAR POINTER
2174 005260 013700 000676 RWND3: MOV UNP,RO ;POINT TO UNIT ENTRY
2175 005264 022760 177777 000746 CMP #-1,UN1(RO) ;BRANCH IF LAST ENTRY
2176 005272 001441 BEQ RWNDX
2177 005274 016037 000746 000552 MOV UN1(RO), UDES ;SET UNIT DESCRIPTION
2178 005302 013777 000552 173232 MOV UDES,2TC ;LOAD COMMAND REGISTER
2179 005310 032777 020000 173204 1S: BIT #20000,2DS
2180 005316 001374 BNE 1S ;AWAIT PIP RESET
2181 005320 013777 000552 173214 MOV UDES,2TC ;LOAD UNIT DESCRIPTION
2182 005326 032777 000002 173166 BIT #2,2DS ;SEE IF HAVE BOT
2183 005334 001407 BEQ RWND6 ;IF NOT: BR
2184 005336 062737 000002 000676 RWND5: ADD #2,UNP ;BUMP POINTER
2185 005344 012777 000011 173136 MOV #11,2C1 ;DRIVE CLEAR
2186 005352 000742 BR RWND3 ;DO NEXT UNIT
2187 005354 012700 000001 RWND6: MOV #1,RO
2188 005360 004737 022570 JSR PC,PAPRT ;PRINT HEADER

```

```

2189 005364 012704 025676      MOV      #MSG48,R4
2190 005370 000004              ;TYPE MSG
2191 005372 000000      HALT
2192 005374 000760      BR      RWND5      ;DO NEXT UNIT
2193 005376 013737 000716 000676 RWNDX: MOV      UPS,UNP      ;RESTORE UNIT POINTER
2194 005404 013700 000676      MOV      UNP,R0
2195 005410 016037 000746 000552      MOV      UNI(R0),UDES ;RESET UNIT DESCRIPTION
2196 005416 013777 000552 173116      MOV      UDES,ATC
2197 005424 000207      RTS      PC      ;RETURN TO TEST
2198
2199
2200
2201      ;*****
2202      ;INITIALIZE SELECTED SALVE
2203      ;THIS ROUTINE REMINDS AND SETS THE PROPER DENSITY IF
2204      ;THE DENSITY REQUIRED FOR THE TEST IS DIFFERENT FROM
2205      ;THE DENSITY AT WHICH THE SLAVE IS SELECTED.
2206      ;*****
2207 005426 013746 000552      INIT:  MOV      UDES,-(SP) ;GET UNIT DESCRIPTION
2208 005432 013777 000550 173060      MOV      DVN,ACS ;LOAD DRIVE #
2209 005440 011677 173076      MOV      (SP),ATC ;LOAD SLAVE # & SLAVE DESCRIPTION
2210 005444 042716 174377      BIC      #174377,(SP) ;CLEAR ALL BUT DENSITY BITS
2211 005450 022726 001400      CMP      #1400,(SP)+ ;BRANCH IF NOT NRZ
2212 005454 001005      BNE      1$
2213 005456 032777 000040 173036      BIT      #40,ADS ;BRANCH IF SLAVE IS IN PE MODE
2214 005464 001422      BEQ      4$ ;PES = 0
2215 005466 000404      BR      2$
2216 005470 032777 000040 173024 1$: BIT      #40,ADS ;BRANCH IF SLAVE IS IN PE MODE
2217 005476 001015      BNE      4$ ;PES = 1
2218 005500 012777 000007 173002 2$: MOV      #7,AC1 ;LOAD REWIND COMMAND
2219 005506 105777 173010 20$: TSTB    ADS ;WAIT FOR READY
2220 005512 100375      BPL      20$
2221 005514 032777 020000 173000 3$: BIT      #20000,ADS ;WAIT FOR PIP = 0
2222 005522 001374      BNE      3$
2223 005524 012777 000011 172756      MOV      #11,AC1 ;CLEAR DRIVE
2224 005532 000207      RTS      PC

```

2225
2226
2227
2228
2229
2230
2231
2232
2233
2234
2235
2236
2237
2238
2239
2240
2241
2242
2243
2244
2245
2246
2247
2248
2249
2250
2251
2252
2253
2254
2255
2256
2257
2258
2259
2260
2261
2262
2263
2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279
2280

```

*****
WRITE ROUTINE:
THIS ROUTINE IS USED TO WRITE ONTO TAPE THE BLOCK
OF DATA DESCRIBED BY THE OPERATOR AND SET UP
IN THE SEQUENCE FORMATTER. THE TAPE UNIT TO BE USED
HAS BEEN ASSIGNED BY THE SEQUENCE FORMATTER AND
ITS PARAMETERS SET IN A UNIT DESCRIPTION WORD.
AS EACH RECORD OF THE BLOCK IS WRITTEN, IT IS CHECKED
FOR STATUS ERRORS, WORD COUNT ZERO, AND CORRECT CURRENT
MEMORY ADDRESS. IF THE WRITE OPERATION RESULTS IN
ANY ERROR CONDITION, A WRITE RETRY OF THAT OPERATION
MAY BE DONE BY SETTING SWITCH FOUR (4) TO A ONE (1).
THE RETRY CONSISTS OF A BACKSPACE, ERASE FORWARD, AND
REWRITE OF THE RECORD. (SEE WRITE RETRY SUBROUTINE)
AFTER ALL DATA RECORDS IN THE BLOCK HAVE BEEN
WRITTEN, THE WRITE ROUTINE WILL EXECUTE A WRITE
TAPE MARK COMMAND IF THE TTY RESPONSE TM=1 WAS
MADE AT INITIAL START. THE TM IS COUNTED AS TOTAL
DATA RECORDS PLUS ONE (IE: IF 100 DATA RECORDS; TM=RECORD 101)
IF THE WRITE OPERATION (DATA OR TM) CAUSES THE SELECTED SLAVE
TO REACH END OF TAPE (EOT) AND THERE IS TO BE NO READING DONE,
(SM2 AND SM3 SET TO A 1) THEN THE SLAVE IS REWOUND AND
FLAGGED AS UNAVAILABLE FOR TESTING UNTIL ALL SLAVES HAVE
REACHED EOT AND BEEN REWOUND AT WHICH TIME TESTING IS
RESUMED ON ALL AVAILABLE SLAVES.
WRITE RETRY MAY BE ALLOWED VIA CONSOLE SWITCH FOUR (4).
ERROR CHECKING MAY BE DISALLOWED VIA CONSOLE SWITCH
TWELVE (12).
WRITING TO TAPE MAY BE DISALLOWED VIA CONSOLE SWITCH
ZERO (0).
*****

```

```

005534 032777 000001 173046 WRITE: BIT #1,JSWR ;SEE IF SHOULD WRITE
005542 001402 BEQ WRITE
005544 000137 006326 JMP WEX ;IF NOT: BR
005550 013700 000554 WRTE: MOV RCNT,RO ;RD=RECORD COUNT
005554 012737 024470 000654 WD: MOV #MSG5,EMADDR ;SET ERROR MSG ADDRESS
005562 013777 000556 172726 MOV FMCNT,3FC ;LOAD CHAR COUNT
005570 012777 027326 172716 MOV #MDATA,3BA ;SET DATA ADDR
005576 112737 000060 000674 MOVB #60,MTC1 ;SET WRITE OP COMMAND
005604 012737 005616 000664 MOV #W1,RTRN ;SET RETURN ADDRESS
005612 000137 021054 JMP TAPC ;GO EXECUTE COMMAND
005616 032777 002000 172676 W1: BIT #2000,3DS ;SEE IF EOT
005624 001412 BEQ W2 ;IF NOT AT EOT: BR
005626 005737 000662 TST EOTREC ;BRANCH IF WRITTEN PAST EOT
005632 100407 BMI W2
005634 010037 000662 MOV RO,EOTREC ;SAVE RECORD COUNT
005640 062737 100001 000662 ADD #100001,EOTREC ;SET EOT INDICATOR & ADD 1 TO # OF
;RECORDS WRITTEN
005646 012700 000002 MOV #2,RO ;SET TO WRITE 1 LAST RECORD
005652 032777 010000 172730 W2: BIT #10000,3SWR ;SEE IF SHOULD CHECK ERRORS
005660 001002 BNE W3 ;IF NOT: BR
005662 004737 017236 JSR PC,ERCHK ;GO CHECK ERRORS
005666 013737 000576 000670 W3: MOV WSTAL,STAL ;SET DELAY
005674 004737 012116 JSR PC,STALL ;DELAY

```

| | | | | | | | |
|------|--------|--------|--------|--------|------|---------------|-------------------------------|
| 2281 | 005700 | 005737 | 000714 | | TST | RTYFL | :SEE IF RETRY TIME |
| 2282 | 005704 | 001401 | | | BEQ | W3A | :IF NOT: BR |
| 2283 | 005706 | 000207 | | | RTS | PC | :ELSE RETURN |
| 2284 | 005710 | 005737 | 000710 | W3A: | TST | SERFL | :SEE IF WRITE ERROR |
| 2285 | 005714 | 001450 | | | BEQ | W5 | :IF NOT: BR |
| 2286 | 005716 | 013704 | 000676 | | MOV | UNP,R4 | |
| 2287 | 005722 | 005264 | 001070 | | INC | WTER1(R4) | :BUMP WRITE ERROR |
| 2288 | 005726 | 005037 | 000710 | | CLR | SERFL | :CLEAR STATUS ERROR FLAG |
| 2289 | 005732 | 032777 | 000020 | 172650 | BIT | #20,JSWR | :SEE IF RETRY |
| 2290 | 005740 | 001436 | | | BEQ | W5 | :IF NOT: BR |
| 2291 | 005742 | 013703 | 000724 | | MOV | ERSAV,R3 | |
| 2292 | 005746 | 042703 | 102700 | | BIC | #102700,R3 | :MASK UNRECOVERABLE ERROR |
| 2293 | 005752 | 001410 | | | BEQ | W4 | :IF SO: BR |
| 2294 | 005754 | 004737 | 022570 | | JSR | PC,PAPRT | :PRINT HEADER |
| 2295 | 005760 | 012704 | 026405 | | MOV | #MSG78,R4 | |
| 2296 | 005764 | 000004 | | | TYPE | | :TYPE MSG |
| 2297 | 005766 | 004737 | 011236 | | JSR | PC,NRTP | :PRINT ER FOR NON-RETRYABLE |
| 2298 | 005772 | 000421 | | | BR | W5 | |
| 2299 | 005774 | 013704 | 000676 | W4: | MOV | UNP,R4 | |
| 2300 | 006000 | 005264 | 001050 | | INC | RTY1(R4) | :BUMP RETRY CNTR |
| 2301 | 006004 | 032777 | 002000 | 172576 | BIT | #2000,JSWR | :SEE IF PRINT ERRORS |
| 2302 | 006012 | 001003 | | | BNE | W4A | :IF NOT: BR |
| 2303 | 006014 | 012704 | 026121 | | MOV | #MSG64,R4 | |
| 2304 | 006020 | 000004 | | | TYPE | | :TYPE MSG |
| 2305 | 006022 | 005037 | 000704 | W4A: | CLR | RTCNT | :CLEAR RETRY NUMBER |
| 2306 | 006026 | 005037 | 000702 | | CLR | RPCNT | :CLEAR REPEAT COUNTER |
| 2307 | 006032 | 004737 | 006370 | | JSR | PC,WRTY | :GO RETRY WRITE ERROR |
| 2308 | 006036 | 005037 | 000714 | W5: | CLR | RTYFL | :CLEAR RETRY COUNTER |
| 2309 | 006042 | 005300 | | | DEC | RO | :SEE IF DONE ALL |
| 2310 | 006044 | 001243 | | | BNE | W0 | :IF NOT: BR |
| 2311 | 006046 | 005737 | 000564 | W6: | TST | TMEX | :SEE IF TM |
| 2312 | 006052 | 001525 | | | BEQ | WEX | :IF NOT: BR |
| 2313 | 006054 | 005237 | 000700 | | INC | TMFLG | :SET TM FLAG |
| 2314 | 006060 | 012737 | 026026 | 000654 | MOV | #MSG54,EMADDR | :POINT TO TM ERROR MSG |
| 2315 | 006066 | 012737 | 000026 | 000674 | MOV | #26,MTC1 | :SET TM OP CODE |
| 2316 | 006074 | 012777 | 000000 | 172414 | MOV | #0,2FC | :LOAD FRAME COUNTER |
| 2317 | 006102 | 012777 | 027326 | 172404 | MOV | #WDATA,2BA | :LOAD BUS ADDRESS |
| 2318 | 006110 | 012737 | 006122 | 000664 | MOV | #WTMO,RTN | :SAVE RETURN ADDRESS |
| 2319 | 006116 | 000137 | 021054 | | JMP | TAPG | :WRITE TM |
| 2320 | 006122 | 032777 | 010000 | 172460 | BIT | #10000,JSWR | :SEE IF SHOULD CHECK ERRORS |
| 2321 | 006130 | 001076 | | | BNE | WEX | |
| 2322 | 006132 | 032777 | 000004 | 172362 | BIT | #4,2DS | :SEE IF TM STATUS |
| 2323 | 006140 | 001011 | | | BNE | WTM1 | :IF SO: BR |
| 2324 | 006142 | 012737 | 027326 | 020774 | MOV | #WDATA,CADER | :SET EXPT BUS ADDRESS |
| 2325 | 006150 | 012737 | 000001 | 021002 | MOV | #1,DRVER | :INDICATE ERROR |
| 2326 | 006156 | 004737 | 020056 | | JSR | PC,ERPT | :PRINT TM ERROR |
| 2327 | 006162 | 000404 | | | BR | WTM2 | |
| 2328 | 006164 | 012703 | 027326 | WTM1: | MOV | #WDATA,R3 | :SET EXPT ADDRESS |
| 2329 | 006170 | 004737 | 017332 | | JSR | PC,ER2 | :GO CHECK FOR OTHER ERRORS |
| 2330 | 006174 | 005737 | 000714 | WTM2: | TST | RTYFL | :SEE IF RETRY |
| 2331 | 006200 | 001401 | | | BEQ | WTM3 | :IF NOT: BR |
| 2332 | 006202 | 000207 | | | RTS | PC | :ELSE RETURN TO RETRY ROUTINE |
| 2333 | 006204 | 005737 | 000710 | WTM3: | TST | SERFL | :SEE IF WRITE ERROR |
| 2334 | 006210 | 001446 | | | BEQ | WEX | :IF NOT: BR |
| 2335 | 006212 | 013704 | 000676 | | MOV | UNP,R4 | |
| 2336 | 006216 | 005264 | 001070 | | INC | WTER1(R4) | :BUMP WRITE ERROR |

| | | | | | | | | |
|------|--------|--------|--------|--------|--------|------|------------|-----------------------------|
| 2337 | 006222 | 032777 | 000020 | 172360 | | BIT | #20,2SWR | :SEE IF SHOULD RETRY |
| 2338 | 006230 | 001436 | | | | BEQ | MEX | :IF NOT: BR |
| 2339 | 006232 | 013703 | 000724 | | | MOV | ERSAV,R3 | |
| 2340 | 006236 | 042703 | 102700 | | | BIC | #102700,R3 | :MASK UNRECOVERABLE ERROR |
| 2341 | 006242 | 001410 | | | | BEQ | WTM4 | :IF SO: BR |
| 2342 | 006244 | 004737 | 022570 | | | JSR | PC,PAPRT | :PRINT HEADER |
| 2343 | 006250 | 012704 | 026405 | | | MOV | #MSG78,R4 | |
| 2344 | 006254 | 000004 | | | | TYPE | | :TYPE MSG |
| 2345 | 006256 | 004737 | 011236 | | | JSR | PC,NRTP | :PRINT ER FOR NON-RETRYABLE |
| 2346 | 006262 | 000421 | | | | BR | MEX | |
| 2347 | 006264 | 005037 | 000702 | | WTM4: | CLR | RPCNT | :CLEAR REPEAT CNTR |
| 2348 | 006270 | 013704 | 000676 | | | MOV | UNP,R4 | |
| 2349 | 006274 | 005264 | 001050 | | | INC | RTY1(R4) | :BUMP RETRY CNTR |
| 2350 | 006300 | 005037 | 000704 | | | CLR | RTCNT | :CLEAR RETRY CNTR |
| 2351 | 006304 | 032777 | 002000 | 172276 | | BIT | #2000,2SWR | :SEE IF PRINT ERRORS |
| 2352 | 006312 | 001003 | | | | BNE | WTM4A | :IF NOT: BR |
| 2353 | 006314 | 012704 | 026121 | | | MOV | #MSG64,R4 | |
| 2354 | 006320 | 000004 | | | | TYPE | | :TYPE MSG |
| 2355 | 006322 | 004737 | 006370 | | WTM4A: | JSR | PC,WRTY | :GO DO RETRY |
| 2356 | 006326 | 005037 | 000714 | | MEX: | CLR | RTYFL | :CLEAR RETRY FLAG |
| 2357 | 006332 | 005037 | 000700 | | | CLR | TMFLG | :CLEAR TAPE MARK FLAG |
| 2358 | 006336 | 005737 | 000662 | | | TST | EOTREC | :BRANCH IF NOT AT EOT |
| 2359 | 006342 | 100011 | | | | BPL | WRWX | |
| 2360 | 006344 | 017703 | 172240 | | WRW: | MOV | 2SWR,R3 | |
| 2361 | 006350 | 042703 | 177763 | | | BIC | #177763,R3 | |
| 2362 | 006354 | 022703 | 000014 | | | CMP | #14,R3 | :SEE IF WRITE ONLY |
| 2363 | 006360 | 001002 | | | | BNE | WRWX | :IF NOT: BR |
| 2364 | 006362 | 000137 | 004330 | | | JMP | REOT | :ELSE REWIND |
| 2365 | 006366 | 000207 | | | WRWX: | RTS | PC | :EXIT |

```

2366                                     :*****
2367                                     :WRITE ERROR RETRY
2368                                     :*****
2369                                     :*****
2370                                     :*****
2371 006370 012737 000001 000714 WRTY:  MOV    #1,RTYFL      ;SET RETRY FLAG
2372 006376 004737 006772          WRTY0: JSR    PC,WRTSB    ;GO SPACE REVERSE FOR REPEAT
2373 006402 005737 000700          TST    TMFLG      ;SEE IF TAPE MARK TIME
2374 006406 001003          BNE    WRTYTM     ;IF SO: BR
2375 006410 004737 005554          JSR    PC,W0      ;REWRITE RECORD
2376 006414 000402          BR     WRTYR      ;GO ON
2377 006416 004737 006060          WRTYTM: JSR   PC,WTM    ;GO WRITE TAPE MARK AGAIN
2378 006422 005737 000710          WRTYR:  TST   SERFL   ;REWRITE GOOD
2379 006426 001024          BNE    WRTY2     ;IF NOT: BR
2380 006430 005237 000702          INC    RPCNT     ;BUMP REPEAT COUNTER
2381 006434 022737 000004 000702  CMP    #4,RPCNT  ;SEE IF FOUR GOOD REPEATS
2382 006442 001355          BNE    WRTY0     ;IF NOT: REPEAT
2383 006444 032777 002000 172136  BIT    #2000,JSWR ;SEE IF PRINT
2384 006452 001011          BNE    WRTY1     ;IF NOT: BR
2385 006454 012704 026613          MOV    #MSG105,R4
2386 006460 000004          TYPE                   ;TYPE MSG
2387 006462 012704 026143          MOV    #MSG65,R4
2388 006466 000004          TYPE                   ;TYPE MSG
2389 006470 013703 000704          MOV    RTCNT,R3
2390 006474 104400          TYPOCT                  ;PRINT RETRY NUMBER
2391 006476 000207          WRTY1:  RTS    PC      ;RESUME TESTING
2392 006500 013703 000724          WRTY2:  MOV    ERSR,R3 ;GET ER
2393 006504 005037 000650          CLR    TEMP3      ;CLEAR RECOVERABLE ERROR INDICATOR
2394 006510 042703 102700          BIC    #102700,R3 ;MASK RECOVERABLE BITS
2395 006514 001413          BEQ    WRTY2A     ;IF RECOVERABLE: BR
2396 006516 004737 022570          JSR    PC,PAPRT   ;PRINT HEADER
2397 006522 012704 026405          MOV    #MSG78,R4
2398 006526 000004          TYPE                   ;TYPE MSG
2399 006530 004737 011236          JSR    PC,NRTP    ;PRINT ER
2400 006534 012737 000001 000650  MOV    #1,TEMP3   ;SET FLAG
2401 006542 000407          BR     WRTY2B     ;SEE IF PRINT
2402 006544 032777 002000 172036  WRTY2A: BIT    #2000,JSWR ;IF NOT: BR
2403 006552 001025          BNE    WRTY3     ;SEE IF PRINT
2404 006554 012704 027032          MOV    #MSG110,R4 ;IF NOT: BR
2405 006560 000004          TYPE                   ;TYPE MSG
2406 006562 012704 026143          WRTY2B: MOV    #MSG65,R4 ;TYPE MSG
2407 006566 000004          TYPE                   ;TYPE MSG
2408 006570 013703 000704          MOV    RTCNT,R3
2409 006574 104400          TYPOCT                  ;PRINT RETRY NUMBER
2410 006576 012704 027054          MOV    #MSG111,R4 ;TYPE MSG
2411 006602 000004          TYPE                   ;TYPE MSG
2412 006604 013703 000702          MOV    RPCNT,R3
2413 006610 104430          TYPOCT                  ;PRINT REPEAT NUMBER
2414 006612 005737 000650          TST    TEMP3     ;SEE IF DID NON-RECOVERABLE
2415 006616 001403          BEQ    WRTY3     ;IF NOT: BR
2416 006620 005037 000650          CLR    TEMP3     ;CLEAR FLAG
2417 006624 000207          RTS    PC        ;EXIT
2418 006626 005737 000704          WRTY3:  TST   RTCNT   ;SEE IF FIRST RETRY
2419 006632 001004          BNE    WRTY3A    ;IF NOT: BR
2420 006634 013704 000676          MOV    UNP,R4
2421 006640 005364 001070          DEC    WTER1(R4)  ;DECREMENT WRITE ERROR CNTR

```

```

2422 006644 013704 000676      WRTY3A: MOV      UNP,R4      ;GET UNIT NUMBER
2423 006650 016437 001030 000732  MOV      BTADDR(R4),BTPT ;GET ADDRESS OF UNIT BAD TAPE CNTR
2424 006656 017704 172050      MOV      @BTPT,R4      ;GET COUNTER
2425 006662 005724      TST      (R4)+        ;SET POINTER OFFSET
2426 006664 010477 172042      MOV      R4,@BTPT
2427 006670 013703 000732      MOV      BTPT,R3
2428 006674 060304      ADD      R3,R4      ;SET ABSOLUTE POINTER
2429 006676 013714 000656      MOV      BLCNTR,(R4)  ;SET BLOCK NUMBER
2430 006702 062704 000040      ADD      @40,R4      ;ADD RCNT OFFSET
2431 006706 013714 000554      MOV      RCNT,(R4)
2432 006712 160014      SUB      R0,(R4)    ;SET RECORD NUMBER
2433 006714 005214      INC      (R4)        ;CORRECT RECORD NUMBER
2434 006716 022777 000040 172006  CMP      @40,@BTPT   ;SEE IF TOO MANY BAD SPOTS
2435 006724 001002      BNE      WRTY4      ;IF NOT: BR
2436 006726 000137 007166      JMP      BTOV      ;ELSE GO TO BAD TAPE OVERFLOW
2437 006732 005237 000704      WRTY4: INC      RTCNT   ;BUMP RETRY COUNTER
2438 006736 022737 000004 000704  CMP      @4,RTCNT   ;SEE IF DONE 4 RETRIES
2439 006744 001410      BEQ      WRTY5      ;IF SO: BR
2440 006746 013704 000676      MOV      UNP,R4
2441 006752 005264 001050      INC      RTY1(R4)   ;BUMP RETRY COUNTER
2442 006756 005237 000734      INC      ERTFL     ;SET ERASE FLAG
2443 006762 000137 006376      JMP      WRTYD     ;DO NEXT RETRY
2444 006766 000137 007402      WRTY5: JMP      BTUR     ;ELSE GO TO BAD TAPE UNRECOVERABLE

;WRITE RETRY BACKSPACE-ERASE SUBROUTINE*****
2446 006772 005037 000710      WRTSB: CLR      SERFL     ;CLEAR FLAG
2447 006776 013737 000600 000670  MOV      TSTAL,STAL
2448 007004 004737 012116      JSR      PC,STALL   ;DO TURN AROUND DELAY
2449 007010 012737 026154 000654  MOV      @MSG66,EMADDR ;SET ERROR CODE
2450 007016 012777 177777 171472  MOV      @-1,@FC    ;SET TO BACKSPACE 1 RECORD
2451 007024 012777 033334 171462  MOV      @RDATA,@BA ;SET BA
2452 007032 004737 012046      JSR      PC,BKRT   ;GO BACKSPACE
2453 007036 005737 000710      TST      SERFL     ;SEE IF ERROR
2454 007042 001406      BEQ      WRTSB1   ;IF NOT: BR
2455 007044 012737 000002 000726  WRTSB0: MOV      @2,BTFLG  ;SET FLAG
2456 007052 022626      CMP      (SP)+,(SP)+ ;RESET STACK
2457 007054 000137 004330      JMP      REOT      ;GO REWIND AND REMOVE FROM TESTING
2458 007060 005737 000734      WRTSB1: TST      ERTFL  ;SEE IF SHOULD ERASE
2459 007064 001001      BNE      WRTSB2   ;IF SO: BR
2460 007066 000207      RTS      PC        ;RETURN
2461 007070 005037 000734      WRTSB2: CLR      ERTFL   ;CLEAR ERASE FLAG
2462 007074 005037 000702      CLR      RPCNT    ;CLEAR REPEAT CNTR
2463 007100 005037 000710      CLR      SERFL   ;CLEAR FLAG
2464 007104 012737 026167 000654  MOV      @MSG67,EMADDR ;SET ERROR CODE
2465 007112 005077 171400      CLR      @FC     ;CLEAR FRAME COUNT
2466 007116 012737 000024 000674  MOV      @24,NTC1  ;SET ERASE OP-CODE
2467 007124 012777 027326 171362  MOV      @WDATA,@BA ;SET BA
2468 007132 012737 007144 000664  MOV      @WRTSB3,RTRN ;SET RETURN ADDRESS
2469 007140 000137 021054      JMP      TAPG     ;GO ERASE
2470 007144 012703 027326      WRTSB3: MOV      @WDATA,R3 ;SET EXPT BA
2471 007150 004737 017332      JSR      PC,ER2   ;GO CHECK ERRORS
2472 007154 005737 000710      TST      SERFL   ;SEE IF ERROR
2473 007160 001737      BEQ      WRTSB1   ;IF NOT: BR
2474 007162 000137 007044      JMP      WRTSB0

```

```

;BAD TAPE OVERFLOW SUBROUTINE*****
2478
2479
2480 007166 005037 000714          BTOV:  CLR  RTYFL          ;CLEAR RETRY FLAG
2481 007172 012737 000001 000726  MOV  #1,BTFLG          ;SET BAD TAPE OVERFLOW FLAG
2482 007200 000137 004330          JMP  REOT              ;GO REWIND AND REMOVE FROM TESTING
2483 007204 013701 000732          BTOV0: MOV  BTPT,R1          ;SET TABLE POINTER
2484 007210 005721                  TST  (R1)+
2485 007212 005000                  CLR  R0
2486 007214 010003          BTOV1: MOV  R0,R3
2487 007216 000241                  CLC
2488 007220 006003                  ROR  R3                ;R3=R3/2 FOR CORRECT NUMBER
2489 007222 104400          TYPOCT  ;PRINT ENTRY NUMBER
2490 007224 012704 024565          MOV  #MSG13+1,R4
2491 007230 000004          TYPE          ;TYPE MSG
2492 007232 011103          MOV  (R1),R3
2493 007234 104400          TYPOCT  ;PRINT BLOCK NUMBER
2494 007236 012704 024572          MOV  #MSG14,R4
2495 007242 000004          TYPE          ;TYPE MSG
2496 007244 062701 000040          ADD  #40,R1           ;SET POINTER OFFSET FOR RECOED NUMBER
2497 007250 012103          MOV  (R1)+,R3
2498 007252 104400          TYPOCT  ;PRINT RECORD NUMBER
2499 007254 162701 000040          SUB  #40,R1           ;RESET POINTER FOR BLOCK NUMBER
2500 007260 005720                  TST  (R0)+
2501 007262 020077 171444          CMP  R0,BTPT          ;SEE IF DONE
2502 007266 001404          BEQ  BTOV2            ;IF SO: BR
2503 007270 012704 025117          MOV  #MSG28,R4
2504 007274 000004          TYPE          ;TYPE MSG
2505 007276 000746          BR   BTOV1            ;CONTINUE
2506 007300 005737 000730          BTOV2: TST  BTSTF          ;SEE IF STAT ONLY PRINT
2507 007304 001007          BNE  BTOVX            ;IF SO: BR
2508 007306 012703 000041          MOV  #41,R3           ;SET SIZE OF TABLE
2509 007312 013704 000732          MOV  BTPT,R4          ;SET POINTER
2510 007316 005024          BTOV3: CLR  (R4)+      ;CLEAR TABLE
2511 007320 005303          DEC  R3                ;SEE IF DONE
2512 007322 001375          BNE  BTOV3            ;IF NOT: BR
2513 007324 000207          BTOVX: RTS             ;RETURN
2514

```

2515
2516
2517
2518 007326 012704 025117
2519 007332 000004
2520 007334 013704 000676
2521 007340 016437 001030 000732
2522 007346 017703 171360
2523 007352 000241
2524 007354 006003
2525 007356 104400
2526 007360 012704 027066
2527 007364 000004
2528 007366 005777 171340
2529 007372 001001
2530 007374 000207
2531 007376 000137 007204
2532
2533
2534
2535 007402 004737 022570
2536 007406 012704 026714
2537 007412 000004
2538 007414 000207
2539

```

;BAD TAPE STATISTIC PRINT*****
BTPRT:  MOV    #MSG28,R4
        TYPE                   ;TYPE MSG
        MOV    UNP,R4
        MOV    BTADDR(R4),BTPT ;SET TABLE POINTER
        MOV    @BTPT,R3
        CLC
        ROR    R3                ;CORRECT NUMBER
        TYPOCT                   ;PRINT NUMBER OF BAD SPOTS
        MOV    #MSG112,R4
        TYPE                   ;TYPE MSG
        TST    @BTPT              ;SEE IF ANY BAD SPOTS
        BNE    BTPRT1            ;IF SO: BR
        RTS    PC                ;ELSE RETURN
BTPRT1: JMP    BTOVO             ;PRINT STATS

;BAD TAPE UNRECOVERABLE SUBROUTINE*****
BTUR:   JSR    PC,PAPRT          ;PRINT HEADER
        MOV    #MSG107,R4
        TYPE                   ;TYPE MSG
        RTS    PC                ;RESUME TESTING
    
```

2540
2541
2542
2543
2544
2545
2546
2547
2548
2549
2550
2551
2552
2553
2554
2555
2556
2557
2558
2559
2560
2561
2562
2563
2564
2565
2566
2567
2568
2569
2570
2571
2572
2573
2574
2575
2576
2577
2578
2579
2580
2581
2582
2583
2584
2585
2586
2587
2588
2589
2590
2591
2592
2593
2594
2595

```

*****
:READ SEQUENCER:
:
:THIS ROUTINE IS USED TO DETERMINE THE SEQUENCE
:IN WHICH READ TAPE OPERATIONS ARE TO BE PERFORMED.
:THIS IS NECESSARY WHEN THE UNIT BEING TESTED IS
:CAPABLE OF READING DATA IN BOTH THE FORWARD AND
:REVERSE DIRECTIONS. CONSOLE SWITCHES ONE (1), TWO (2),
:AND THREE (3) ARE USED TO DETERMINE THE READ SEQUENCE.
:CONSOLE SWITCH ONE (1) DETERMINES WHETHER TO READ
:THE BLOCK OF DATA FORWARD FIRST OR REVERSE FIRST.
:SWITCH TWO (2) DISALLOWS READING IN THE REVERSE
:DIRECTION AND SWITCH THREE (3) DISALLOWS READING IN
:THE FORWARD DIRECTION.
*****
    
```

```

007416 012737 000002 000562 RSEQ: MOV #2,RDCMD
007424 017704 171160 MOV #2SWR,R4 ;READ SWITCHES
007430 042704 177763 BIC #177763,R4 ;MASK READ BITS & SEE IF BOTH READS
007434 001004 BNE RSR ;IF NOT: BR
007436 032777 000002 171144 BIT #2,2SWR ;SEE IF READ REVERSE FIRST
007444 001050 BNE RSFR ;IF NOT: BR
007446 032777 000004 171134 RSR: BIT #4,2SWR ;SEE IF SHOULD READ REVERSE
007454 001005 BNE RSF ;IF NOT: BR
007456 012737 010000 000562 MOV #10000,RDCMD ;LOAD READ REVERSE COMMAND
007464 004737 007730 JSR PC,READ ;GO READ REVERSE
007470 032777 000010 171112 RSF: BIT #10,2SWR ;SEE IF SHOULD READ FORWARD
007476 001025 BNE RSEX ;IF NOT: BR
007500 032737 010000 000562 BIT #10000,RDCMD ;SEE IF HAVE READ REVERSE
007506 001406 BEQ RSFO ;IF NOT: BR
007510 013737 000600 000670 MOV TSTAL,STAL
007516 004737 012116 JSR PC,STALL ;DO READ STALL
007522 000406 BR RSF1
007524 032777 000001 171056 RSFO: BIT #1,2SWR ;SEE IF WRITE
007532 001002 BNE RSF1 ;IF NOT: BR
007534 004737 011672 JSR PC,BKSP ;GO BACKSPACE
007540 012737 000002 000562 RSF1: MOV #2,RDCMD ;LOAD READ FORWARD COMMAND
007546 004737 007730 JSR PC,READ ;GO READ
007552 005737 000662 RSEX: TST EOTREC ;BRANCH IF NOT AT EOT
007556 100002 BPL IS ;ELSE GO TO REWIND
007560 000137 004330 JMP REOT
007564 000207 IS: RTS PC ;EXIT
007566 012737 010000 000562 RSFR: MOV #10000,RDCMD
007574 032777 000010 171006 BIT #10,2SWR ;SEE IF SHOULD READ FORWARD
007602 001013 BNE RSFR1 ;IF NOT: BR
007604 032777 000001 170776 BIT #1,2SWR ;SEE IF WRITE
007612 001002 BNE RSFRD ;IF NOT: BR
007614 004737 011672 JSR PC,BKSP ;GO BACKSPACE TO START
007620 012737 000002 000562 RSFRD: MOV #2,RDCMD ;LOAD READ FORWARD COMMAND
007626 004737 007730 JSR PC,READ ;GO READ FORWARD
007632 032777 000004 170750 RSFR1: BIT #4,2SWR ;SEE IF SHOULD READ REVERSE
007640 001344 BNE RSEX ;IF NOT: BR
007642 032737 010000 000562 BIT #10000,RDCMD
007650 001005 BNE RSFR2 ;IF READ REVERSE: BR
007652 013737 000600 000670 MOV TSTAL,STAL ;DO READ STALL
    
```

| | | | | | | | | |
|------|--------|--------|--------|--------|--------|-----|--------------|------------------------------|
| 2596 | 007660 | 004737 | 012116 | | | JSR | PC STALL | |
| 2597 | 007664 | 012737 | 010000 | 000562 | RSFR2: | MOV | #10000,RDCMD | ;LOAD READ REVERSE |
| 2598 | 007672 | 004737 | 007730 | | | JSR | PC,READ | ;GO READ REVERSE |
| 2599 | 007676 | 005737 | 000662 | | | TST | EOTREC | ;SEE IF AT END OF TAPE |
| 2600 | 007702 | 100011 | | | | BPL | RSFRX | ;IF NOT: BR |
| 2601 | 007704 | 163737 | 000554 | 000662 | | SUB | RCNT,EOTREC | |
| 2602 | 007712 | 005437 | 000662 | | | NEG | EOTREC | ;SET TO PROPER RECORD NUMBER |
| 2603 | 007716 | 005237 | 000662 | | | INC | EOTREC | |
| 2604 | 007722 | 000137 | 004330 | | | JMP | REOT | ;ELSE GO TO REWIND |
| 2605 | 007726 | 000207 | | | RSFRX: | RTS | PC | ;EXIT |
| 2606 | | | | | | | | |

2607
2608
2609
2610
2611
2612
2613
2614
2615
2616
2617
2618
2619
2620
2621
2622
2623
2624
2625
2626
2627
2628
2629
2630
2631
2632
2633
2634
2635
2636
2637
2638
2639
2640
2641
2642
2643
2644
2645
2646
2647
2648
2649
2650
2651
2652
2653
2654
2655
2656
2657
2658
2659
2660
2661
2662

```
*****  
: READ ROUTINE:  
: THIS ROUTINE PERFORMS THE READ OPERATION DETERMINED  
: BY THE READ SEQUENCE ROUTINE ONE RECORD AT A TIME.  
: AT THE END OF EACH READ OPERATION THE STATUS REGISTER  
: IS SCANNED FOR EITHER END OF TAPE OR BEGINNING OF TAPE.  
: IF EOT WAS REACHED, CONTROL WILL BE PASSED TO  
: THE EOT SUBROUTINE TO REWIND THE UNIT AND FLAG IT  
: UNAVAILABLE UNTIL ALL UNITS HAVE REACHED EOT.  
: IF BOT WAS REACHED AN ERROR IS PRINTED AND THE  
: PROGRAM WILL HALT. TESTING MAY BE RESUMED BY PRESSING  
: THE CONTINUE SWITCH.  
: IF A TAPE MARK IS EXPECTED (TM=1) THEN THE  
: READ ROUTINE EXPECTS THE FIRST RECORD OF A  
: READ REVERSE TO BE A TM, AND THE LAST RECORD  
: OF A READ FORWARD TO BE A TM. REMEMBER  
: THAT THE TM ADDS ONE (1) TO THE TOTAL NUMBER  
: OF RECORDS IN A BLOCK.  
: CONSOLE SWITCHES ELEVEN (11) AND THIRTEEN (13) DETERMINE WHETHER  
: OR NOT TO CHECK FOR STATUS ERRORS (11) OR DATA ERRORS (13),  
: CONSOLE SWITCH FIVE (5) IS USED TO CAUSE A CONTINUOUS  
: READ AND SPACE (FORWARD OR REVERSE) OF THE CURRENT  
: RECORD ON TAPE (YOZZLE).  
*****
```

```
007730 013700 000554  
007734 005737 000662  
007740 100013  
007742 032737 010000 000562  
007750 001407  
007752 042737 100000 000662  
007760 013703 000662  
007764 160300  
007766 005200  
007770 012737 024475 000654  
007776 005037 000700  
010002 032737 010000 000562  
010010 001406  
010012 005737 000564  
010016 001403  
010020 005237 000700  
010024 005200  
010026 013777 000556 170462  
010034 012777 033334 170452  
010042 032737 010000 000562  
010050 001417  
010052 013703 000556  
010056 005103  
010060 032737 000020 000552  
010066 001402  
010070 000241  
010072 006003  
010074 060377 170414  
010100 012737 000076 000674  
010106 000403
```

```
READ: MOV RCNT,R0 ;LOAD REC CNTR  
TST EOTREC ;SEE IF EOT  
BPL RDA ;IF NOT: BR  
BIT #10000,RDCMD ;SEE IF READ FORWARD  
BEQ RDA ;IF SO: BR  
BIC #10000,EOTREC ;CLEAR FLAG  
MOV EOTREC,R3 ;GET MODIFIED RECORD COUNT  
SUB R3,R0 ;SET RECORD AT  
INC R0 ;SET TO PROPER NUMBER OF RECORDS  
RDA: MOV #MSG6,EMADDR ;SET ERROR MSG ADDRESS  
CLR TMFLG  
BIT #10000,RDCMD  
BEQ R0 ;IF READ FORWARD: BR  
TST TMEX ;SEE IF TM  
BEQ R0 ;IF NOT: BR  
INC TMFLG ;SET TM FLAG  
INC R0  
R0: MOV FMCNT,2FC ;LOAD CHAR CNTR  
MOV #RDATA,2BA ;LOAD DATA ADDR  
BIT #10000,RDCMD ;SEE IF READ REVERSE  
BEQ R0A ;IF NOT: BR  
MOV FMCNT,R3  
COM R3  
BIT #20,UDES ;SEE IF CORE DUMP  
BEQ R01 ;IF NOT: BR  
CLC  
R0R R3 ;R3 = FC/2  
ADD R3,2BA ;SET REVERSE BUS ADDRESS  
MOV #76, MTC1 ;SET READ REVERSE  
BR R01B
```

| | | | | | | | | |
|------|--------|--------|--------|--------|--------|------|----------------|--------------------------------|
| 2663 | 010110 | 012737 | 000070 | 000674 | RD1A: | MOV | #70, MTC1 | ; SET READ FORWARD |
| 2664 | 010116 | 012737 | 010130 | 000664 | RD1B: | MOV | #RD2, RTRN | ; SET INTERRUPT RETURN ADDRESS |
| 2665 | 010124 | 000137 | 021054 | | RD1D: | JMP | TAPG | ; GO EXECUTE TAPE COMMAND |
| 2666 | 010130 | 032737 | 010000 | 000562 | RD2: | BIT | #10000, RDCMD | ; SEE IF READ REVERSE |
| 2667 | 010136 | 001014 | | | | BNE | RD3 | ; IF S0: BR |
| 2668 | 010140 | 032777 | 002000 | 170354 | | BIT | #2000, ADS | ; SEE IF EOT |
| 2669 | 010146 | 001410 | | | | BEQ | RD3 | ; IF NOT: BR |
| 2670 | 010150 | 005737 | 000700 | | | TST | TMFLG | ; SEE IF TM |
| 2671 | 010154 | 001005 | | | | BNE | RD3 | ; IF S0: BR |
| 2672 | 010156 | 010037 | 000662 | | | MOV | RD, EOTREC | |
| 2673 | 010162 | 052737 | 100000 | 000662 | | BIS | #10000, EOTREC | ; SET EOT FLAG |
| 2674 | 010170 | 032777 | 000002 | 170324 | RD3: | BIT | #2, ADS | ; SEE IF AT LOAD POINT |
| 2675 | 010176 | 001410 | | | | BEQ | RD4 | ; IF NOT: BR |
| 2676 | 010200 | 004737 | 022570 | | | JSR | PC, PAPRT | ; PRINT CYCLE NUMBER |
| 2677 | 010204 | 012704 | 024676 | | | MOV | #MSG22, R4 | |
| 2678 | 010210 | 000004 | | | | TYPE | | ; TYPE MSG |
| 2679 | 010212 | 000000 | | | | HALT | | |
| 2680 | 010214 | 000137 | 003160 | | | JMP | STARTA | ; RESTART |
| 2681 | 010220 | 032777 | 004000 | 170362 | RD4: | BIT | #4000, JSWR | ; SEE IF SHOULD CHECK ERRORS |
| 2682 | 010226 | 001121 | | | | BNE | RD5 | ; IF NOT: BR |
| 2683 | 010230 | 005737 | 000700 | | | TST | TMFLG | |
| 2684 | 010234 | 001472 | | | | BEQ | RD4B | ; IF NO TM EXPT: BR |
| 2685 | 010236 | 032777 | 000004 | 170256 | | BIT | #4, ADS | |
| 2686 | 010244 | 001024 | | | | BNE | RD4A | ; IF TM RECVD: BR |
| 2687 | 010246 | 012737 | 033334 | 020774 | | MOV | #RDATA, CADER | ; SAVE EXPT BUS ADDRESS |
| 2688 | 010254 | 012737 | 000002 | 021002 | | MOV | #2, DRIVER | ; SET TM STATUS ERROR FLAG |
| 2689 | 010262 | 004737 | 020056 | | | JSR | PC, ERPT | ; GO PRINT TM ERROR |
| 2690 | 010266 | 013704 | 000676 | | | MOV | UMP, R4 | |
| 2691 | 010272 | 032737 | 010000 | 000562 | | BIT | #10000, RDCMD | ; SEE IF READ REVERSE |
| 2692 | 010300 | 001403 | | | | BEQ | 15 | ; IF NOT: BR |
| 2693 | 010302 | 005264 | 001150 | | | INC | RDERR1(R4) | ; BUMP READ REVERSE ERROR |
| 2694 | 010306 | 000502 | | | | BR | RD6 | |
| 2695 | 010310 | 005264 | 001110 | | 15: | INC | RDER1(R4) | ; BUMP READ FORWARD ERROR |
| 2696 | 010314 | 000477 | | | | BR | RD6 | |
| 2697 | 010316 | 012703 | 033334 | | RD4A: | MOV | #RDATA, R3 | |
| 2698 | 010322 | 032737 | 010000 | 000562 | | BIT | #10000, RDCMD | ; SEE IF READ REVERSE |
| 2699 | 010330 | 001007 | | | | BNE | RD4A0 | ; IF S0: BR |
| 2700 | 010332 | 032737 | 002000 | 000552 | | BIT | #2000, UDES | ; SEE IF IN PE |
| 2701 | 010340 | 001025 | | | | BNE | RD4A2 | ; IF S0: BR |
| 2702 | 010342 | 062703 | 000002 | | | ADD | #2, R3 | |
| 2703 | 010346 | 000422 | | | | BR | RD4A2 | |
| 2704 | 010350 | 013704 | 000556 | | RD4A0: | MOV | FMCNT, R4 | |
| 2705 | 010354 | 005104 | | | | COM | R4 | |
| 2706 | 010356 | 032737 | 000020 | 000552 | | BIT | #20, UDES | ; SEE IF CORE DUMP |
| 2707 | 010364 | 001402 | | | | BEQ | RD4A1 | ; IF NOT: BR |
| 2708 | 010366 | 000241 | | | | CLC | | |
| 2709 | 010370 | 006004 | | | | ROR | R4 | ; SET TO FC/2 |
| 2710 | 010372 | 060403 | | | RD4A1: | ADD | R4, R3 | ; SET EXPT BUS ADDRESS |
| 2711 | 010374 | 042703 | 000001 | | | BIC | #1, R3 | ; MAKE EXPT ADDRESS EVEN |
| 2712 | 010400 | 032737 | 002000 | 000552 | | BIT | #2000, UDES | ; SEE IF IN PE |
| 2713 | 010406 | 001002 | | | | BNE | RD4A2 | ; IF S0: BR |
| 2714 | 010410 | 162703 | 000002 | | | SUB | #2, R3 | |
| 2715 | 010414 | 004737 | 017332 | | RD4A2: | JSR | PC, ER2 | |
| 2716 | 010420 | 000402 | | | | BR | RD4C | |
| 2717 | 010422 | 004737 | 017236 | | RD4B: | JSR | PC, ERCHK | ; GO CHECK ERRORS |
| 2718 | 010426 | 005737 | 000710 | | RD4C: | TST | SERFL | |

| | | | | | | | | |
|------|--------|--------|--------|--------|-------|---------------|---------------|-------------------------------|
| 2719 | 010432 | 001417 | | | BEQ | R05 | | ; IF NO ERROR: BR |
| 2720 | 010434 | 013704 | 000676 | | MOV | UNP, R4 | | |
| 2721 | 010440 | 032737 | 010000 | 000562 | BIT | #10000, RDCMD | | ; SEE IF READ REVERSE |
| 2722 | 010446 | 001003 | | | BNE | R04D | | ; IF SO: BR |
| 2723 | 010450 | 005264 | 001110 | | INC | RDER1(R4) | | ; BUMP READ FORWARD ERROR |
| 2724 | 010454 | 000402 | | | BR | R04E | | |
| 2725 | 010456 | 005264 | 001150 | | RD4D: | INC | RDER1(R4) | ; BUMP READ REVERSE ERROR |
| 2726 | 010462 | 004737 | 010664 | | RD4E: | JSR | PC, RDRTY | ; GO RETRY |
| 2727 | 010466 | 005037 | 000714 | | CLR | RTYFL | | ; CLEAR RETRY FLAG |
| 2728 | 010472 | 032777 | 020000 | 170110 | R05: | BIT | #20000, #SWR | ; SEE IF SHOULD DO DATA CHECK |
| 2729 | 010500 | 001005 | | | BNE | R06 | | ; IF NOT; BR |
| 2730 | 010502 | 005737 | 000700 | | TST | TMFLG | | |
| 2731 | 010506 | 001002 | | | BNE | R06 | | |
| 2732 | 010510 | 004737 | 015366 | | RD6: | JSR | PC, DCHK | ; GO CHECK DATA |
| 2733 | 010514 | 005037 | 000710 | | CLR | SEFL | | ; CLEAR STATUS ERROR FLAG |
| 2734 | 010520 | 004737 | 014232 | | JSR | PC, DS3 | | ; CLEAR BUFFER |
| 2735 | 010524 | 032777 | 000040 | 170056 | BIT | #40, #SWR | | ; SEE IF SHOULD YOZZLE |
| 2736 | 010532 | 001402 | | | BEQ | R07 | | ; IF NOT: BR |
| 2737 | 010534 | 004737 | 011252 | | JSR | PC, YOZ | | ; ELSE GO YOZZLE |
| 2738 | 010540 | 013737 | 000574 | 000670 | RD7: | MOV | RSTAL, STAL | ; SET DELAY |
| 2739 | 010546 | 004737 | 012116 | | JSR | PC, STALL | | ; STALL |
| 2740 | 010552 | 032737 | 010000 | 000562 | BIT | #10000, RDCMD | | ; SEE IF READ REVERSE |
| 2741 | 010560 | 001403 | | | BEQ | R07A | | ; IF NOT: BR |
| 2742 | 010562 | 005037 | 000700 | | CLR | TMFLG | | ; CLEAR TAPE MARK FLAG |
| 2743 | 010566 | 000405 | | | BR | R010 | | |
| 2744 | 010570 | 005737 | 000662 | | RD7A: | TST | EOTREC | ; SEE IF EOT FOUND |
| 2745 | 010574 | 100002 | | | BPL | R010 | | ; IF NOT: BR |
| 2746 | 010576 | 012700 | 000001 | | MOV | #1, R0 | | ; SET TO EOT |
| 2747 | 010602 | 005300 | | | RD10: | DEC | R0 | |
| 2748 | 010604 | 001402 | | | BEQ | R011 | | ; IF DONE ALL: BR |
| 2749 | 010606 | 000137 | 010026 | | JMP | R00 | | |
| 2750 | 010612 | 032737 | 010000 | 000562 | RD11: | BIT | #10000, RDCMD | ; SEE IF READ REVERSE |
| 2751 | 010620 | 001016 | | | BNE | RDEX | | ; IF SO: BR |
| 2752 | 010622 | 005737 | 000662 | | TST | EOTREC | | ; SEE IF FOUND EOT |
| 2753 | 010626 | 100413 | | | BMI | RDEX | | ; IF SO: BR |
| 2754 | 010630 | 005737 | 000564 | | TST | TMEX | | ; SEE IF TM EXPECTED |
| 2755 | 010634 | 001410 | | | BEQ | RDEX | | ; IF NOT: BR |
| 2756 | 010636 | 005737 | 000700 | | TST | TMFLG | | ; SEE IF TM FOUND |
| 2757 | 010642 | 001005 | | | BNE | RDEX | | ; IF SO: BR |
| 2758 | 010644 | 005237 | 000700 | | INC | TMFLG | | ; ELSE SET FLAG |
| 2759 | 010650 | 005200 | | | INC | R0 | | ; SET RECORD COUNT TO ONE |
| 2760 | 010652 | 000137 | 010026 | | JMP | R00 | | ; GO READ TM |
| 2761 | 010656 | 005037 | 000700 | | RD11: | CLR | TMFLG | |
| 2762 | 010662 | 000207 | | | RDX: | RTS | | ; EXIT |

```

2763
2764
2765
2766
2767
2768
2769
2770
2771
2772
2773
2774 010664 032777 000020 167716 RDRTY: BIT      #20,JSWR      ;SEE IF RETRY INHIBITED
2775 010672 001001          BNE      RDRT0      ;IF NOT: BR
2776 010674 000207          RTS      PC          ;ELSE RETURN
2777 010676 013703 000724          RDRT0: MOV      ERSAV,R3
2778 010702 042703 102700          BIC      #102700,R3 ;MARK NON-RECOVERABLE ERROR BITS
2779 010706 001410          BEQ      RDRT1      ;IF NOT: BR
2780 010710 004737 022570          JSR      PC,PAPRT   ;PRINT HEADER
2781 010714 012704 026446          MOV      #MSG79,R4
2782 010720 000004          TYPE
2783 010722 004737 011236          JSR      PC,NRTP    ;TYPE MSG
2784 010726 000207          RTS      PC          ;PRINT ER FOR NON-RETRYABLE ERROR
2785 010730 032777 002000 167652 RDRT1A: RTS      PC          ;RETURN
2786 010736 001003          RDRT1: BIT      #2000,JSWR ;SEE IF PRINT INHIBITED
2787 010740 012704 026121          BNE      RDRT1B     ;IF SO: BR
2788 010744 000004          MOV      #MSG64,R4
2789 010746 005037 000704          TYPE
2790 010752 005037 000710          RDRT1B: CLR      RTCNT ;CLEAR RETRY COUNTER
2791 010756 012737 000002 000714 RDRTG: CLR      SERFL  ;CLEAR STATUS ERROR FLAG
2792 010764 004737 011252          MOV      #2,RTYFL  ;SET READ RETRY FLAG
2793 010770 005737 000710          JSR      PC,YOZ    ;GO TO YOZZLE TO RETRY READ
2794 010774 001031          TST      SERFL     ;SEE IF RETRY ERROR
2795 010776 032777 002000 167604 BNE      RDRT5     ;IF SO: BR
2796 011004 001011          BIT      #2000,JSWR
2797 011006 012704 026613          BNE      RDRT2
2798 011012 000004          MOV      #MSG105,R4
2799 011014 012704 026143          TYPE
2800 011020 000004          MOV      #MSG65,R4 ;TYPE MSG
2801 011022 013703 000704          TYPE
2802 011026 104400          MOV      RTCNT,R3 ;TYPE MSG
2803 011030 013704 000676          MOV      TYPOCT
2804 011034 032737 010000 000562 RDRT2: MOV      UNP,R4 ;PRINT RETRY NUMBER
2805 011042 001003          BIT      #10000,RDCMD ;SEE IF READ REVERSE
2806 011044 005264 002670          BNE      RDRT3     ;IF SO: BR
2807 011050 000402          INC      RFSOFT(R4) ;ELSO BUMP FORWARD SOFT ERROR COUNTER
2808 011052 005264 002710          BR      RDRT4
2809 011056 000207          INC      RRSOFT(R4) ;BUMP ERRORS SOFT CNTR
2810 011060 013703 000724          RDRT3: RTS      PC          ;RETURN
2811 011064 005037 000650          RDRT4: MOV      ERSAV,R3 ;GET ER
2812 011070 042703 102700          CLR      TEMP3     ;CLEAR RECOVERABLE ERROR INDICATOR
2813 011074 001413          BIC      #102700,R3 ;MASK RECOVERABLE BITS
2814 011076 004737 022570          BEQ      RDRT5A    ;IF RECOVERABLE: BR
2815 011102 012704 026446          JSR      PC,PAPRT   ;PRINT HEADER
2816 011106 000004          MOV      #MSG79,R4
2817 011110 004737 011236          TYPE
2818 011114 012737 000001 000650          JSR      PC,NRTP    ;TYPE MSG
2819          MOV      #1,TEMP3 ;PRINT ER
2820          ;SET FLAG
  
```

| | | | | | | | | | |
|------|--------|--------|--------|--------|--|-------------|--------------|--|-------------------------------|
| 2819 | 011122 | 000404 | | | | BR | RDRT5B | | |
| 2820 | 011124 | 032777 | 002000 | 167456 | | RDRT5A: BIT | #2000,JSWR | | ;SEE IF PRINT INHIBITED |
| 2821 | 011132 | 001014 | | | | BNE | RDRT6 | | ;IF SO: BR |
| 2822 | 011134 | 012704 | 026143 | | | RDRT5B: MOV | #MSG65,R4 | | |
| 2823 | 011140 | 000004 | | | | TYPE | | | ;TYPE MSG |
| 2824 | 011142 | 013703 | 000704 | | | MOV | RTCNT,R3 | | |
| 2825 | 011146 | 104400 | | | | TYPOCT | | | ;PRINT RETRY NUMBER |
| 2826 | 011150 | 005737 | 000650 | | | TST | TEMP3 | | ;SEE IF DID NON-RECOVERABLE |
| 2827 | 011154 | 001403 | | | | BEQ | RDRT6 | | ;IF NOT: BR |
| 2828 | 011156 | 005037 | 000650 | | | CLR | TEMP3 | | ;CLEAR FLAG |
| 2829 | 011162 | 000207 | | | | RTS | PC | | ;EXIT |
| 2830 | 011164 | 005237 | 000704 | | | RDRT6: INC | RTCNT | | |
| 2831 | 011170 | 023737 | 000704 | 000604 | | CHP | RTCNT,RETRY | | ;SEE IF DONE 8 RETRIES |
| 2832 | 011176 | 001265 | | | | BNE | RDRTG | | ;IF NOT: BR |
| 2833 | 011200 | 012704 | 027131 | | | MOV | #MSG115,R4 | | |
| 2834 | 011204 | 000004 | | | | TYPE | | | ;TYPE MSG |
| 2835 | 011206 | 013704 | 000676 | | | MOV | UNP,R4 | | |
| 2836 | 011212 | 032737 | 010000 | 000562 | | BIT | #10000,RDCMD | | ;SEE IF READ REVERSE |
| 2837 | 011220 | 001003 | | | | BNE | RDRT7 | | ;IF SO: BR |
| 2838 | 011222 | 005264 | 002730 | | | INC | RFHARD(R4) | | ;BUMP FORWARD HARD ERROR CNTR |
| 2839 | 011226 | 000402 | | | | BR | RDRTX | | |
| 2840 | 011230 | 005264 | 002750 | | | RDRT7: INC | RFHARD(R4) | | ;BUMP REVERSE HARD ERROR CNTR |
| 2841 | 011234 | 000207 | | | | RDRTX: RTS | PC | | ;RETURN |
| 2842 | | | | | | | | | |
| 2843 | 011236 | 013703 | 000724 | | | NRTP: MOV | ERSAV,R3 | | ;GET ER REGISTER |
| 2844 | 011242 | 104400 | | | | TYPOCT | | | ;PRINT ER |
| 2845 | 011244 | 004737 | 021020 | | | JSR | PC,FRPRT | | ;PRINT F OR R |
| 2846 | 011250 | 000207 | | | | RTS | PC | | ;RETURN |

```

2847
2848
2849
2850
2851
2852
2853
2854
2855
2856
2857
2858
2859
2860 011252 013737 000602 000670 YOZ:
2861 011260 004737 012116 JSR
2862 011264 012777 177777 167224 YOZD: MOV
2863 011272 032737 010000 000562 BIT
2864 011300 001404 BEQ
2865 011302 112737 000030 000674 MOV
2866 011310 000403 BR
2867 011312 112737 000032 000674 YOZA: MOV
2868 011320 012737 011340 000664 YOZB: MOV
2869 011326 012737 177775 000670 MOV
2870 011334 000137 021054 JMP
2871 011340 005737 000700 YOZC: TST
2872 011344 001404 BEQ
2873 011346 012737 040000 000670 MOV
2874 011354 000403 BR
2875 011356 013737 000602 000670 1S: MOV
2876 011364 004737 012116 2S: JSR
2877 011370 012777 033334 167116 MOV
2878 011376 032737 010000 000562 BIT
2879 011404 001416 BEQ
2880 011406 013703 000556 MOV
2881 011412 005103 COM
2882 011414 032737 000020 000552 BIT
2883 011422 001401 BEQ
2884 011424 006203 ASR
2885 011426 060377 167062 YOZCO: ADD
2886 011432 012737 000076 000674 MOV
2887 011440 000403 BR
2888 011442 012737 000070 000674 YOZC1: MOV
2889 011450 013777 000556 167040 YOZC2: MOV
2890 011456 012737 011470 000664 MOV
2891 011464 000137 021054 JMP
2892 011470 032777 004000 167112 YOZD: BIT
2893 011476 001050 BNE
2894 011500 005737 000700 TST
2895 011504 001443 BEQ
2896 011506 032737 010000 000562 BIT
2897 011514 001425 BEQ
2898 011516 012703 033334 MOV
2899 011522 013704 000556 MOV
2900 011526 005104 COM
2901 011530 032737 000020 000552 BIT
2902 011536 001401 BEQ

```

```

*****
:YOZZLE SUBROUTINE:

```

```

:THIS SUBROUTINE, ENTERED VIA SWITCH FIVE (5), IS USED TO PERFORM
:A CONTINUOUS READ AND SPACE OVER OF THE CURRENT RECORD ON TAPE.
:FULL STATUS AND DATA CHECKING MAY BE PERFORMED
:OR NOT VIA CONSOLE SWITCHES ELEVEN (11) AND THIRTEEN (13).
:A SOFTWARE DELAY IS PERFORMED BETWEEN EACH READ
:AND SPACE OPERATION AND MAY BE VARIED BY TYPING
:CNTRL C ON THE TTY AND ENTERING A VALUE IN RESPONSE
:TO THE PRINTED REQUEST.

```

```

*****

```

```

:DO YOZZLE STALL
:SET TO 1 RECORD SPACING
:SEE IF READ REVERSE
:IF NOT: BR
:SET TO SPACE FORWARD
:SET TO SPACE REVERSE
:SET RETURN ADDRESS
:SET TIME MULTIPLIER
:GO YOZZLE
:SEE IF TM
:IF NOT: BR
:SET TM STALL
:DO YOZZLE STALL
:SET BUS ADDRESS
:SEE IF READ REVERSE
:IF NOT: BR
:SEE IF CORE DUMP
:IF NOT: BR
:R3 = FC/2
:SET REVERSE BUS ADDRESS
:SET READ REVERSE
:SET READ FORWARD
:SET CHARACTER COUNT
:SET RETURN ADDRESS
:GO READ
:SEE IF SHOULD CHECK ERRORS
:IF NOT: BR
:SEE IF TAPE MARK TIME
:IF NOT: BR
:SEE IF READ REVERSE
:IF NOT: BR
:SEE IF CORE DUMP
:IF NOT: BR

```

| | | | | | | | | |
|------|--------|--------|--------|--------|--------|-------------|-----------|--------------------------------|
| 2903 | 011540 | 006204 | | | ASR | R4 | | :SET TO FC/2 |
| 2904 | 011542 | 060403 | | | AOO | R4,R3 | | :SET EXPT BUS ADDRESS |
| 2905 | 011544 | 042703 | 000001 | | BIC | #1,R3 | | :MAKE EXPT ADDRESS EVEN |
| 2906 | 011550 | 032737 | 002000 | 000552 | BIT | #2000,UDES | | :SEE IF PE |
| 2907 | 011556 | 001001 | | | BNE | YOZD2 | | :IF SO: BR |
| 2908 | 011560 | 005743 | | | TST | -(R3) | | :SET EXPT BA |
| 2909 | 011562 | 004737 | 017332 | | JSR | PC,ER2 | | :GO CHECK ERRORS |
| 2910 | 011566 | 000430 | | | BR | YOZF | | |
| 2911 | 011570 | 012703 | 033334 | | YOZD0: | MOV | #RDATA,R3 | |
| 2912 | 011574 | 032737 | 002000 | 000552 | BIT | #2000,UDES | | :SEE IF PE |
| 2913 | 011602 | 001001 | | | BNE | YOZD3 | | :IF SO: BR |
| 2914 | 011604 | 005723 | | | TST | (R3)+ | | :SET EXPT BA |
| 2915 | 011606 | 004737 | 017332 | | YOZD3: | JSR | PC,ER2 | :GO CHECK ERRORS |
| 2916 | 011612 | 000416 | | | BR | YOZF | | |
| 2917 | 011614 | 004737 | 017236 | | YOZD1: | JSR | PC,ERCHK | :ELSE GO CHECK ERRORS |
| 2918 | 011620 | 005737 | 000714 | | YOZE: | TST | RTYFL | :SEE IF RETRY |
| 2919 | 011624 | 001013 | | | BNE | YOZG | | :IF SO: BR |
| 2920 | 011626 | 032777 | 020000 | 166754 | BIT | #20000,2SWR | | :SEE IF SHOULD CHECK DATA |
| 2921 | 011634 | 001005 | | | BNE | YOZF | | :IF NOT: BR |
| 2922 | 011636 | 005737 | 000700 | | TST | TMFLG | | :SEE IF TAPE MARK |
| 2923 | 011642 | 001002 | | | BNE | YOZF | | :IF SO: BR |
| 2924 | 011644 | 004737 | 015366 | | JSR | PC,DCHK | | :ELSE GO CHECK DATA |
| 2925 | 011650 | 004737 | 014232 | | YOZF: | JSR | PC,DS3 | :GO CLEAR DATA AREA |
| 2926 | 011654 | 032777 | 000040 | 166726 | YOZG: | BIT | #40,2SWR | :SEE IF SHOULD CONTINUE YOZZLE |
| 2927 | 011662 | 001402 | | | BEQ | YOZH | | :IF NOT: BR |
| 2928 | 011664 | 000137 | 011264 | | JMP | YOZO | | |
| 2929 | 011670 | 000207 | | | YOZH: | RTS | | :EXIT |
| 2930 | | | | | | | | |

2931
2932
2933
2934
2935
2936
2937
2938
2939
2940
2941
2942
2943
2944
2945
2946
2947
2948
2949
2950
2951
2952
2953
2954
2955
2956
2957
2958
2959
2960
2961
2962
2963
2964
2965
2966
2967
2968
2969
2970
2971
2972
2973
2974
2975
2976
2977
2978
2979
2980
2981

| | | | | |
|--------|--------|--------|--------|--------|
| 011672 | 013737 | 000600 | 000670 | BKSP: |
| 011700 | 004737 | 012116 | | |
| 011704 | 012737 | 024525 | 000654 | |
| 011712 | 012777 | 033334 | 166574 | |
| 011720 | 005737 | 000564 | | |
| 011724 | 001440 | | | |
| 011726 | 012777 | 177777 | 166562 | |
| 011734 | 012737 | 000032 | 000674 | |
| 011742 | 012737 | 011754 | 000664 | |
| 011750 | 000137 | 021054 | | |
| 011754 | 032777 | 010000 | 166626 | BKTM: |
| 011762 | 001021 | | | |
| 011764 | 012737 | 026035 | 000654 | |
| 011772 | 032777 | 000004 | 166522 | |
| 012000 | 001006 | | | |
| 012002 | 012737 | 033334 | 020774 | |
| 012010 | 004737 | 020056 | | |
| 012014 | 000404 | | | |
| 012016 | 012703 | 033334 | | BKTM0: |
| 012022 | 004737 | 017332 | | |
| 012026 | 013700 | 000554 | | B0: |
| 012032 | 005400 | | | |
| 012034 | 012737 | 024525 | 000654 | |
| 012042 | 010077 | 166450 | | |
| 012046 | 012737 | 000032 | 000674 | BKRT: |
| 012054 | 012737 | 012072 | 000664 | |
| 012062 | 010037 | 000670 | | |
| 012066 | 000137 | 021054 | | |
| 012072 | 012703 | 033334 | | B1: |
| 012076 | 004737 | 017332 | | |
| 012102 | 013737 | 000600 | 000670 | B2: |
| 012110 | 004737 | 012116 | | |
| 012114 | 000207 | | | |

```

*****
:BACKSPACE SUBROUTINE:
:
:THIS SUBROUTINE IS USED TO PERFORM THE
:BACKSPACE OPERATION REQUIRED BY THE READ
:ROUTINE FOR READ FORWARD AFTER WRITING.
:IF A TAPE MARK IS EXPECTED (TM=1) THEN THE SPACE
:ROUTINE ASSUMES THAT THE TM WILL BE FIRST WHEN
:BACKSPACING. THEREFORE TWO OPERATIONS ARE REQUIRED
:TO SPACE OVER A BLOCK. FIRST SPACE OVER THE TM, THEN
:SPACE OVER THE DATA RECORDS.
:A CHECK FOR RECORD COUNT ZERO IS MADE AT THE
:END OF THE SPACE OPERATION TO ASSURE THAT PROPER
:TAPE POSITIONING WAS DONE.
*****
BKSP:  MOV    TSTAL,STAL
      JSR    PC,STALL ;DO TURN AROUND STALL
      MOV    #MSG10,EMADDR
      MOV    #RDATA,2BA
      TST    TMEX ;SEE IF TM
      BEQ    B0 ;IF NOT: BR
      MOV    #-1,2FC
      MOV    #32,MTC1
      MOV    #BKM,RTRN
      JMP    TAPG ;SPACE TO TM
      BIT    #10000,2SWR ;SEE IF SHOULD CHECK ERROR
      BNE    B0 ;IF NOT: BR
      MOV    #MSG55,EMADDR
      BIT    #4,2OS ;SEE IF TM
      BNE    BKTMO ;IF SO: BR
      MOV    #RDATA,CADER
      JSR    PC,ERPT ;PRINT ERROR
      BR    B0
      MOV    #RDATA,R3
      JSR    PC,ER2
      MOV    RCNT,RO
      NEG    RO ;BUILD SPACE AMOUNT
      MOV    #MSG10,EMADDR ;SET ERROR MESSG ADDRESS
      MOV    RO,2FC
      MOV    #32,MTC1 ;SET SPACE REVERSE
      MOV    #B1,RTRN ;SET RETURN ADDRESS
      MOV    RO,STAL ;SET INTERRUPT TIME MULTIPLIER
      JMP    TAPG ;GO DO SPACE
      MOV    #RDATA,R3
      JSR    PC,ER2
      MOV    TSTAL,STAL ;DO STALL
      JSR    PC,STALL ;STALL
      RTS    PC ;EXIT

```

2982
2983
2984
2985
2986
2987
2988
2989
2990
2991
2992
2993
2994
2995
2996
2997
2998
2999
3000

```
*****  
:STALL ROUTINE:  
:THIS ROUTINE IS USED TO PROVIDE SOFTWARE DELAYS  
:DURING READ, WRITE, TURN AROUND, AND YOZZLE.  
:THE DELAY TIMES MAY BE SET BY THE OPERATOR AT  
:INITIAL START FROM 200(B) OR MAY BE MODIFIED  
:AT ANY TIME BY ENTERING CNTRL C ON THE TTY AND  
:INSERTING NEW VALUES IN RESPONSE TO THE REQUEST.  
:THE READ STALL AND THE WRITE STALL ARE DELAYS  
:EXECUTED BETWEEN EACH RECORD OF THE DATA BLOCK.  
:THE TURN AROUND STALL IS EXECUTED EACH TIME  
:THE DIRECTION OF TAPE MOVEMENT IS CHANGED AND  
:ALSO EACH TIME THE TAPE OPERATION CHANGES FROM  
:WRITE TO READ OR READ TO WRITE. THE YOZZLE  
:STALL IS EXECUTED ONLY DURING THE YOZZLE ROUTINE.  
*****
```

3001 012116 005337 000670
3002 012122 001375
3003 012124 000207

STALL: DEC STAL
BNE STALL ;DELAY
RTS PC ;EXIT

3004
3005
3006
3007
3008
3009
3010
3011
3012
3013
3014
3015
3016
3017
3018
3019
3020
3021
3022
3023
3024
3025
3026
3027
3028
3029
3030
3031
3032
3033
3034
3035
3036
3037
3038
3039
3040
3041

012126 012701 177760
012132 012702 175000
012136 004737 023152
012142 042737 000001 000630
012150 013737 000630 000556
012156 012737 177777 014270
012164 000207

012166 012702 000001
012172 012701 000500
012176 004737 023152
012202 013737 000630 000554
012210 000207

CCNTR:

```
MOV      #20,R1      ;SET HIGH LIMIT
MOV      #3000,R2    ;SET LOW LIMIT
JSR      PC,RANG     ;GO GENERATE NUMBER
BIC      #1,RANSV    ;
MOV      RANSV,FMcnt ;SET CHAR COUNT
MOV      #1,PATS     ;PRESET DATA PATTERN
RTS      PC          ;EXIT
```

```
*****
RANDOM CHARACTER COUNT GENERATOR:
THIS ROUTINE ENTERED VIA CONSOLE SWITCH
SEVEN (7) IS USED TO GENERATE A RANDOM
CHARACTER COUNT FOR EACH DATA BLOCK.
ALL RECORDS WITHIN A GIVEN BLOCK WILL BE
THE SAME, BUT EACH BLOCK WILL VARY.
THE LIMITS ARE TWENTY (20) TO FOUR THOUSAND
(4000) OCTAL CHARACTERS PER RECORD.
*****
```

RCNTR:

```
MOV      #1,R2      ;SET LOW LIMIT
MOV      #500,R1    ;SET HIGH LIMIT
JSR      PC,RANG     ;GO GENERATE NUMBER
MOV      RANSV,RCNT ;SET RECORD COUNT
RTS      PC          ;EXIT
```

```
*****
RANDOM RECORD COUNT GENERATOR:
THIS ROUTINE ENTERED VIA CONSOLE SWITCH SIX (6)
IS USED TO GENERATE A RANDOM NUMBER OF RECORDS
FOR EACH BLOCK OF DATA.
THE LIMITS ARE ONE (1) TO FIVE HUNDRED (500) OCTAL
RECORDS PER BLOCK.
*****
```

3042
3043
3044
3045
3046
3047
3048
3049
3050
3051
3052
3053
3054
3055
3056
3057
3058
3059
3060
3061
3062
3063
3064
3065
3066
3067
3068
3069
3070
3071
3072
3073
3074
3075
3076
3077
3078
3079
3080
3081
3082
3083
3084
3085
3086
3087
3088
3089
3090
3091
3092
3093
3094
3095
3096
3097

```

*****
:TEST CONDITION ENTRY ROUTINE:
:
:THIS ROUTINE IS USED TO ALLOW THE OPERATOR
:TO ENTER, AT THE TTY, THE NECESSARY PARAMETERS
:TO RUN THE PROGRAM AS HE WISHES. THE
:ROUTINE IS ONLY ENTERED UPON INITIAL STARTING
:FROM LOCATION 200(B).
:THE MAIN PURPOSE OF THIS ROUTINE IS TO ESTABLISH
:A TABLE OF DEVICES TO BE TESTED. THIS TABLE
:CONSISTS OF AN ENTRY FOR EACH OF ONE (1) TO
:EIGHT (8) DEVICES. EACH ENTRY CONTAINS THE
:SLAVE NUMBER, DENSITY, PARITY, AND
:FORMAT. THE INFORMATION IS ENTERED
:IN RESPONSE TO PRINTED REQUESTS AT THE TTY.
:SLAVES MAY BE ENTERED IN ANY ORDER. EACH
:PARAMETER IS CHECKED FOR LEGALITY BEFORE BEING
:SET INTO THE TABLE.
:THE DRIVE NUMBER REQUEST WILL ALSO CHECK THE MASSBUS
:FOR THE PRESENCE OF THE REQUESTED DRIVE. IF IT IS NOT FOUND,
:A NON-EXIST DRIVE MESSAGE WILL BE PRINTED AND ANOTHER DRIVE
:REQUEST MADE. WHEN THE DRIVE IS FOUND, THE RESPONSE IS STORED
:AND CONTROL PASSED TO THE SLAVE SELECT ROUTINE.
:THE SLAVE SELECT ROUTINE ALSO CHECKS FOR THE PRESENCE OF THE
:SLAVE. IF IT IS NOT PRESENT, A MESSAGE IS PRINTED AND ANOTHER
:REQUEST IS ISSUED. WHEN THE SELECTED SLAVE IS FOUND TO BE
:PRESENT, A MESSAGE IS PRINTED IF IT IS A 7 CHANNEL DRIVE
:TO ASSIST IN SELECTING DENSITY, PARITY, AND FORMAT.
:UPON COMPLETION OF THE DEVICE TABLE, REQUESTS
:ARE PRINTED FOR ENTRY OF THE NUMBER OF CHARACTERS
:PER RECORD AND THE NUMBER OF RECORDS PER BLOCK. THE
:NEXT REQUEST IS FOR A PATTERN NUMBER TO BE USED
:FOR WRITING AND CHECKING OF READ DATA.
:FOLLOWING THE PATTERN REQUEST IS THE TAPE MARK OPTION.
:RESPONDING TO THE REQUEST (TM=) WITH A ONE (1)
:WILL CAUSE THE PROGRAM TO WRITE A TM AT THE
:END OF EACH DATA BLOCK AND TO EXPECT THE
:TM TO BE DETECTED IN EITHER READ FORWARD AND REVERSE
:OR DURING SPACE OPERATION. A RESPONSE OF ZERO (TM=0)
:DISALLOWS WRITING OF THE TM AND CAUSES THE READ
:AND SPACE ROUTINES TO EXPECT NO TM TO BE PRESENT.
:THE LAST REQUESTS ARE FOR ENTRY OF THE DESIRED
:WRITE, READ, AND TURN AROUND STALLS.
*****

```

```

012212 005737 000636
012216 001002
012220 000137 013700
012224 005037 000676
012230 005037 005054
012234 012700 000010
012240 012701 000746
012244 005021
012246 005300
012250 001375

```

```

TINP: TST TINF ;SEE IF SHOULD INPUT FROM TTY
      BNE IS ;IF SO: BR
      JMP TINP4 ;GET SWITCHES
1S: CLR UNP ;CLEAR TABLE POINTER
     CLR REOTC ;CLEAR EOT UNIT COUNTER
     MOV #10,R0 ;SET SIZE OF TABLE
     MOV #UN1,R1 ;SET START OF TABLE
3S: CLR (R1)+ ;CLEAR TABLE
     DEC R0 ;SEE IF DONE
     BNE 3S ;IF NOT: BR

```

| | | | | | | | |
|------|--------|--------|--------|--------|--------|--------------|---|
| 3098 | 012252 | 012704 | 025161 | | MOV | #MSG31,R4 | |
| 3099 | 012256 | 005737 | 000736 | | TST | ASEQF | ; SEE IF AUTO SEQ |
| 3100 | 012262 | 001402 | | | BEQ | 4\$ | ; IF NOT: BR |
| 3101 | 012264 | 012704 | 025121 | | MOV | #MSG30,R4 | ; SET AUTO SEQ HDR |
| 3102 | 012270 | 010446 | | 4\$: | MOV | R4,-(SP) | ; SAVE ADDRESS OF MESSAGE |
| 3103 | 012272 | 000004 | | | TYPE | | ; TYPE MSG |
| 3104 | 012274 | 105036 | | | CLRB | 2(SP)+ | ; DO NOT TYPE TITLE ON RESTART |
| 3105 | 012276 | 012704 | 025236 | | MOV | #MSG31A,R4 | ; TYPE INSTRUCTION |
| 3106 | 012302 | 000004 | | | TYPE | | |
| 3107 | 012304 | 105037 | 025236 | | CLRB | MSG31A | ; DO NOT TYPE STARTUP INSTRUCTIONS ON RESTART |
| 3108 | 012310 | 005737 | 014062 | | TST | SCVFL | ; SEE IF SHORT CONVERSATION |
| 3109 | 012314 | 001067 | | | BNE | 6\$ | ; IF SO: BR |
| 3110 | 012316 | 012704 | 026325 | | MOV | #MSG74,R4 | |
| 3111 | 012322 | 000004 | | | TYPE | | ; TYPE MSG |
| 3112 | 012324 | 013703 | 000544 | | MOV | REGS,R3 | |
| 3113 | 012330 | 104400 | | | TYPOCT | | ; PRINT CURRENT REG START |
| 3114 | 012332 | 012705 | 000544 | | MOV | #REGS,R5 | ; SAVE ADDRESS LOCATION |
| 3115 | 012336 | 012701 | 000007 | | MOV | #7,R1 | ; SET SIZE OF ENTRY |
| 3116 | 012342 | 012702 | 176400 | | MOV | #176400,R2 | ; SET UPPER LIMIT |
| 3117 | 012346 | 012703 | 172300 | | MOV | #172300,R3 | ; SET LOWER LIMIT |
| 3118 | 012352 | 004737 | 023340 | | JSR | PC,TTR | ; GO GET RESPONSE |
| 3119 | 012356 | 012704 | 026350 | | MOV | #MSG75,R4 | |
| 3120 | 012362 | 000004 | | | TYPE | | ; TYPE MSG |
| 3121 | 012364 | 013703 | 000546 | | MOV | VECT,R3 | |
| 3122 | 012370 | 104400 | | | TYPOCT | | ; PRINT CURRENT VECTOR |
| 3123 | 012372 | 012705 | 000546 | | MOV | #VECT,R5 | ; SET SAVE LOCATION |
| 3124 | 012376 | 012701 | 000004 | | MOV | #4,R1 | ; SET SIZE OF ENTRY |
| 3125 | 012402 | 012702 | 000224 | | MOV | #224,R2 | ; SET UPPER LIMIT |
| 3126 | 012406 | 012703 | 000150 | | MOV | #150,R3 | ; SET LOWER LIMIT |
| 3127 | 012412 | 004737 | 023340 | | JSR | PC,TTR | ; GO GET RESPONSE |
| 3128 | 012416 | 013700 | 000546 | | MOV | VECT,R0 | ; GET VECTOR ADDRESS |
| 3129 | 012422 | 012720 | 021716 | | MOV | #MTINT,(R0)+ | ; LOAD VECTOR WITH HANDLER ADDRESS |
| 3130 | 012426 | 012710 | 000340 | | MOV | #340,(R0) | ; LOAD PRIORITY LEVEL |
| 3131 | 012432 | 013700 | 000544 | | MOV | REGS,R0 | ; GET STARTING REGISTER ADDRESS |
| 3132 | 012436 | 012701 | 000016 | | MOV | #16,R1 | ; SET NUMBER OF REGISTERS |
| 3133 | 012442 | 012702 | 000510 | | MOV | #C1,R2 | ; GET FIRST ADDRESS LOCATION |
| 3134 | 012446 | 010022 | | 5\$: | MOV | R0,(R2)+ | ; BUILD TABLE OF ADDRESSES |
| 3135 | 012450 | 062700 | 000002 | | ADD | #2,R0 | ; BUMP ADDRESS |
| 3136 | 012454 | 005301 | | | DEC | R1 | ; SEE IF DONE |
| 3137 | 012456 | 001373 | | | BNE | 5\$ | ; IF NOT: BR |
| 3138 | 012460 | 005737 | 000736 | | TST | ASEQF | ; SEE IF AUTO SEQ |
| 3139 | 012464 | 001403 | | | BEQ | 6\$ | ; IF NOT: BR |
| 3140 | 012466 | 005726 | | | TST | (SP)+ | ; RESET STACK POINTER |
| 3141 | 012470 | 000137 | 021734 | | JMP | ASEQ | ; GO TO AUTO SEQUENCE |
| 3142 | 012474 | 012777 | 000040 | 166016 | MOV | #40,2CS | ; INITIALIZE |
| 3143 | 012502 | 012704 | 025772 | | MOV | #MSG52,R4 | |
| 3144 | 012506 | 000004 | | | TYPE | | ; TYPE MSG |
| 3145 | 012510 | 012705 | 000550 | | MOV | #DVN,R5 | ; GET ADDRESS |
| 3146 | 012514 | 012701 | 000002 | | MOV | #2,R1 | ; SET SIZE OF RESPONSE |
| 3147 | 012520 | 012702 | 000007 | | MOV | #7,R2 | ; SET UPPER LIMIT |
| 3148 | 012524 | 012703 | 000000 | | MOV | #0,R3 | ; SET LOWER LIMIT |
| 3149 | 012530 | 004737 | 023340 | | JSR | PC,TTR | ; GO GET DRIVE NUMBER |
| 3150 | 012534 | 013777 | 000550 | 165756 | MOV | DVN,2CS | |
| 3151 | 012542 | 005777 | 165742 | | TST | 2C1 | ; ACCESS DRIVE |
| 3152 | 012546 | 032777 | 010000 | 165744 | BIT | #10000,2CS | ; SEE IF NED |
| 3153 | 012554 | 001411 | | | BEQ | TINPO | ; IF NOT: BR |

| | | | | | | | |
|------|--------|--------|--------|--------|---------|--------------|---|
| 3154 | 012556 | 012704 | 026262 | | MOV | #MSG71,R4 | |
| 3155 | 012562 | 000004 | | | TYPE | | ;TYPE MSG |
| 3156 | 012564 | 013704 | 000510 | | MOV | C1,R4 | |
| 3157 | 012570 | 005204 | | | INC | R4 | |
| 3158 | 012572 | 152714 | 000100 | | BISB | #100,(R4) | ;CLEAR TRE |
| 3159 | 012576 | 000736 | | | BR | 65 | ;RETRY DVN |
| 3160 | 012600 | 012704 | 025323 | TINPO: | MOV | #MSG32,R4 | |
| 3161 | 012604 | 000004 | | | TYPE | | ;TYPE MSG |
| 3162 | 012606 | 005037 | 000646 | | CLR | TEMP2 | ;CLEAR BUFFER |
| 3163 | 012612 | 012705 | 000646 | | MOV | #TEMP2,R5 | ;SET UNIT DESCRIPTION BUFFER ADDRESS |
| 3164 | 012616 | 012701 | 000002 | | MOV | #2,R1 | ;SET NUMBER OF CHARACTERS TO INPUT |
| 3165 | 012622 | 012702 | 000007 | | MOV | #7,R2 | ;SET MAXIMUM LIMIT |
| 3166 | 012626 | 012703 | 000000 | | MOV | #0,R3 | ;SET MINIMUM LIMIT |
| 3167 | 012632 | 004737 | 023340 | | JSR | PC,TTR | ;GO GET UNIT NUMBER |
| 3168 | 012636 | 005737 | 000644 | | TST | TEMP1 | ;SEE IF HAVE NEW PARAMETER |
| 3169 | 012642 | 001012 | | | BNE | TINPOB | ;IF SO: BR |
| 3170 | 012644 | 005737 | 000676 | | TST | UNP | ;SEE IF FIRST ENTRY |
| 3171 | 012650 | 001753 | | | BEQ | TINPO | |
| 3172 | 012652 | 013700 | 000676 | | MOV | UNP,R0 | |
| 3173 | 012656 | 012760 | 177777 | 000746 | MOV | #-1,UNI(R0) | ;SET END UNIT TABLE |
| 3174 | 012664 | 000137 | 013264 | | JMP | TINP2C | ;GO GET RECORD COUNT |
| 3175 | 012670 | 013700 | 000676 | | TINPOB: | MOV | UNP,R0 |
| 3176 | 012674 | 042760 | 000007 | 000746 | BIC | #7,(UNI(R0)) | ;CLEAR UNIT NUMBER |
| 3177 | 012702 | 004737 | 014074 | | JSR | PC,TPOS1 | ;GO LOAD UNIT NUMBER TO PROPER POSITION |
| 3178 | 012706 | 012777 | 000040 | 165604 | MOV | #40,ACS | |
| 3179 | 012714 | 013777 | 000550 | 165576 | MOV | DVN,ACS | |
| 3180 | 012722 | 016077 | 000746 | 165612 | MOV | UNI(R0),ATC | ;LOAD UNIT NUMBER |
| 3181 | 012730 | 032777 | 002000 | 165600 | TINPOC: | BIT | #2000,AT |
| 3182 | 012736 | 001004 | | | BNE | TINPOD | ;SEE IF SLAVE PRESENT |
| 3183 | 012740 | 012704 | 026050 | | MOV | #MSG57,R4 | ;IF SO: BR |
| 3184 | 012744 | 000004 | | | TYPE | | ;TYPE MSG |
| 3185 | 012746 | 000714 | | | BR | TINPO | ;REDO |
| 3186 | 012750 | 017703 | 165562 | | TINPOD: | MOV | AT,R3 |
| 3187 | 012754 | 042703 | 000007 | | BIC | #7,R3 | ;GET CONTENTS OF DT REG |
| 3188 | 012760 | 022703 | 142050 | | CMP | #142050,R3 | ;CLEAR DRIVE TYPE # |
| 3189 | 012764 | 001410 | | | BEQ | TINPOE | ;SEE IF 9TRK TM03,TE16 |
| 3190 | 012766 | 012704 | 025745 | | MOV | #MSG50,R4 | ;IF SO: BR |
| 3191 | 012772 | 000004 | | | TYPE | | ;ILLEGAL DRIVE TYPE |
| 3192 | 012774 | 017703 | 165536 | | MOV | AT,R3 | ;TYPE MSG |
| 3193 | 013000 | 042703 | 000007 | | BIC | #7,R3 | ;CLEAR SLAVE # |
| 3194 | 013004 | 104400 | | | TYPOCT | | ;PRINT DRIVE TYPE REGISTER |
| 3195 | 013006 | 012704 | 024517 | | TINPOE: | MOV | #MSG9,R4 |
| 3196 | 013012 | 000004 | | | TYPE | | ;TYPE MSG |
| 3197 | 013014 | 017703 | 165520 | | MOV | ASN,R3 | |
| 3198 | 013020 | 004737 | 024322 | | JSR | PC,SNPT | ;PRINT SERIAL NUMBER |
| 3199 | 013024 | 012704 | 025344 | | TINP1: | MOV | #MSG33,R4 |
| 3200 | 013030 | 000004 | | | TYPE | | ;TYPE MSG |
| 3201 | 013032 | 005037 | 000646 | | CLR | TEMP2 | ;CLEAR BUFFER |
| 3202 | 013036 | 012701 | 000002 | | MOV | #2,R1 | ;SET NUMBER OF CHARACTERS TO INPUT |
| 3203 | 013042 | 012702 | 000004 | | MOV | #4,R2 | ;SET MAXIMUM LIMIT |
| 3204 | 013046 | 012703 | 000003 | | MOV | #3,R3 | ;SET MINIMUM LIMIT |
| 3205 | 013052 | 004737 | 023340 | | JSR | PC,TTR | ;GO GET DENSITY |
| 3206 | 013056 | 005737 | 000644 | | TST | TEMP1 | ;SEE IF HAVE NEW PARAMETER |
| 3207 | 013062 | 001407 | | | BEQ | TINP2 | ;IF NOT: BR |
| 3208 | 013064 | 042737 | 003400 | 000552 | BIC | #3400,UDES | ;ELSE CLEAR OLD PARAMETER |
| 3209 | 013072 | 012703 | 000010 | | MOV | #10,R3 | ;SET POSITION FACTOR |

| | | | | | | | | | |
|------|--------|--------|--------|--------|---------|--------|--------------|--|---------------------------------------|
| 3210 | 013076 | 004737 | 014064 | | | | | | |
| 3211 | 013102 | 012704 | 025360 | | TINP2: | JSR | PC, TPOS | | ;GO LOAD DENSITY INTO PROPER POSITION |
| 3212 | 013106 | 000004 | | | | MOV | #MSG34, R4 | | |
| 3213 | 013110 | 005037 | 000646 | | | TYPE | | | ;TYPE MSG |
| 3214 | 013114 | 012701 | 000002 | | | CLR | TEMP2 | | ;CLR BUFFER |
| 3215 | 013120 | 012702 | 000001 | | | MOV | #2, R1 | | ;SET NUMBER OF CHARACTERS TO INPUT |
| 3216 | 013124 | 012703 | 000000 | | | MOV | #1, R2 | | ;SET MAXIMUM LIMIT |
| 3217 | 013130 | 004737 | 023340 | | | MOV | #0, R3 | | ;SET MINIMUM LIMIT |
| 3218 | 013134 | 005737 | 000644 | | | JSR | PC, TTR | | ;GO INPUT PARITY |
| 3219 | 013140 | 001407 | | | | TST | TEMP1 | | ;SEE IF HAVE NEW PARAMETER |
| 3220 | 013142 | 042737 | 000010 | 000552 | | BEQ | TINP2A | | ;IF NOT: BR |
| 3221 | 013150 | 012703 | 000003 | | | BIC | #10, UDES | | ;ELSE CLEAR OLD PARAMETER |
| 3222 | 013154 | 004737 | 014064 | | | MOV | #3, R3 | | ;SET POSITION FACTOR |
| 3223 | 013160 | 012704 | 026013 | | TINP2A: | JSR | PC, TPOS | | ;GO LOAD PARITY TO PROPER POSITION |
| 3224 | 013164 | 000004 | | | | MOV | #MSG53, R4 | | |
| 3225 | 013166 | 005037 | 000646 | | | TYPE | | | ;TYPE MSG |
| 3226 | 013172 | 012701 | 000003 | | | CLR | TEMP2 | | |
| 3227 | 013176 | 012702 | 000017 | | | MOV | #3, R1 | | |
| 3228 | 013202 | 012703 | 000000 | | | MOV | #17, R2 | | |
| 3229 | 013206 | 004737 | 023340 | | | MOV | #0, R3 | | |
| 3230 | 013212 | 005737 | 000644 | | | JSR | PC, TTR | | ;GO GET FORMAT |
| 3231 | 013216 | 001407 | | | | TST | TEMP1 | | ;SEE IF NEW PARAMETER |
| 3232 | 013220 | 042737 | 000170 | 000552 | | BEQ | TINP2B | | ;IF NOT: BR |
| 3233 | 013226 | 012703 | 000004 | | | BIC | #170, UDES | | |
| 3234 | 013232 | 004737 | 014064 | | | MOV | #4, R3 | | |
| 3235 | 013236 | 005237 | 005054 | | TINP2B: | JSR | PC, TPOS | | |
| 3236 | 013242 | 022737 | 000016 | 000676 | | INC | REOTC | | ;BUMP EOT UNIT COUNTER |
| 3237 | 013250 | 001405 | | | | CMP | #16, UNP | | ;SEE IF DONE UNITS |
| 3238 | 013252 | 062737 | 000002 | 000676 | | BEQ | TINP2C | | ;IF SO: BR |
| 3239 | 013260 | 000137 | 012600 | | | ADD | #2, UNP | | ;POINT TO NEXT UNIT |
| 3240 | 013264 | 005037 | 000676 | | TINP2C: | JMP | TINP0 | | ;ELSE LOOK FOR NEXT UNIT |
| 3241 | 013270 | 013700 | 005054 | | | CLR | UNP | | ;CLEAR UNIT POINTER |
| 3242 | 013274 | 000337 | 005054 | | | MOV | REOTC, RO | | |
| 3243 | 013300 | 110037 | 005054 | | | SWAB | REOTC | | |
| 3244 | 013304 | 012704 | 025373 | | TINP3: | MOVB | RO, REOTC | | ;SET UNIT EOT COUNTER |
| 3245 | 013310 | 000004 | | | | MOV | #MSG35, R4 | | |
| 3246 | 013312 | 013703 | 000554 | | | TYPE | | | ;TYPE MSG |
| 3247 | 013316 | 104400 | | | | MOV | RCNT, R3 | | |
| 3248 | 013320 | 012705 | 000554 | | | TYPOCT | | | ;PRINT RECORD COUNT |
| 3249 | 013324 | 012701 | 000007 | | | MOV | #RCNT, R5 | | ;SET RECORD COUNT ADDRESS |
| 3250 | 013330 | 012702 | 177777 | | | MOV | #7, R1 | | ;SET NUMBER OF CHARACTERS TO INPUT |
| 3251 | 013334 | 012703 | 000001 | | | MOV | #-1, R2 | | ;SET MAXIMUM LIMIT |
| 3252 | 013340 | 004737 | 023340 | | | MOV | #1, R3 | | ;SET MINIMUM LIMIT |
| 3253 | 013344 | 013737 | 000554 | 000632 | | JSR | PC, TTR | | ;GO GET RECORD COUNT |
| 3254 | 013352 | 012704 | 025414 | | | MOV | RCNT, RCSAV | | ;SAVE RECORD COUNT |
| 3255 | 013356 | 000004 | | | | MOV | #MSG36, R4 | | |
| 3256 | 013360 | 005437 | 000556 | | | TYPE | | | ;TYPE MSG |
| 3257 | 013364 | 013703 | 000556 | | | NEG | FMCNT | | |
| 3258 | 013370 | 104400 | | | | MOV | FMCNT, R3 | | |
| 3259 | 013372 | 012705 | 000556 | | | TYPOCT | | | ;PRINT CHAR COUNT |
| 3260 | 013376 | 012701 | 000007 | | | MOV | #FMCNT, R5 | | ;SET CHARACTER COUNT ADDRESS |
| 3261 | 013402 | 012702 | 004000 | | | MOV | #7, R1 | | ;SET NUMBER OF CHARACTERS TO INPUT |
| 3262 | 013406 | 012703 | 000004 | | | MOV | #4000, R2 | | ;SET MAXIMUM LIMIT |
| 3263 | 013412 | 004737 | 023340 | | | MOV | #4, R3 | | ;SET MINIMUM LIMIT |
| 3264 | 013416 | 005437 | 000556 | | | JSR | PC, TTR | | ;GO GET CHARACTER COUNT |
| 3265 | 013422 | 013737 | 000556 | 000634 | | NEG | FMCNT | | ;SET TO TWO'S COMPLIMENT |
| | | | | | | MOV | FMCNT, FCSAV | | ;SAVE FRAME COUNT |

| | | | | | | |
|------|--------|--------|--------|-------------|-----------|------------------------------------|
| 3266 | 013430 | 012704 | 025433 | MOV | #MSG37,R4 | ;PRINT PATTERN NUMBER REQUEST |
| 3267 | 013434 | 000004 | | TYPE | | ;TYPE MSG |
| 3268 | 013436 | 013703 | 000560 | MOV | PATRN,R3 | |
| 3269 | 013442 | 104400 | | TYPOCT | | ;PRINT PATTERN |
| 3270 | 013444 | 005037 | 014432 | CLR | DOFL | ;CLEAR EXTERNAL DATA FLAG |
| 3271 | 013450 | 012705 | 000560 | MOV | #PATRN,R5 | ;SET PATTERN NUMBER ADDRESS |
| 3272 | 013454 | 012701 | 000003 | MOV | #3,R1 | ;SET NUMBER OF CHARACTERS TO INPUT |
| 3273 | 013460 | 012702 | 000015 | MOV | #15,R2 | ;SET MAXIMUM LIMIT |
| 3274 | 013464 | 012703 | 000000 | MOV | #0,R3 | ;SET MINIMUM LIMIT |
| 3275 | 013470 | 004737 | 023340 | JSR | PC,TTR | ;GO GET PATTERN NUMBER |
| 3276 | 013474 | 012704 | 026210 | MOV | #MSG69,R4 | |
| 3277 | 013500 | 000004 | | TYPE | | ;TYPE MSG |
| 3278 | 013502 | 013703 | 000564 | MOV | TMEX,R3 | |
| 3279 | 013506 | 104400 | | TYPOCT | | ;PRINT CURRENT TM FLAG SETTING |
| 3280 | 013510 | 012705 | 000564 | MOV | #TMEX,R5 | ;GET TM FLAG ADDRESS |
| 3281 | 013514 | 012701 | 000002 | MOV | #2,R1 | ;SET SIZE OF RESPONSE |
| 3282 | 013520 | 012702 | 000001 | MOV | #1,R2 | ;SET UPPER LIMIT |
| 3283 | 013524 | 012703 | 000000 | MOV | #0,R3 | ;SET LOWER LIMIT |
| 3284 | 013530 | 004737 | 023340 | JSR | PC,TTR | ;TM 1=YES |
| 3285 | 013534 | 012704 | 024651 | MOV | #MSG21,R4 | |
| 3286 | 013540 | 000004 | | TYPE | | ;TYPE MSG |
| 3287 | 013542 | 013703 | 000570 | MOV | INTRF,R3 | |
| 3288 | 013546 | 104400 | | TYPOCT | | ;PRINT CURRENT SETTING |
| 3289 | 013550 | 012705 | 000570 | MOV | #INTRF,R5 | ;GET FLAG ADDRESS |
| 3290 | 013554 | 012701 | 000002 | MOV | #2,R1 | ;SET SIZE OF RESPONSE |
| 3291 | 013560 | 012702 | 000001 | MOV | #1,R2 | ;SET UPPER LIMIT |
| 3292 | 013564 | 012703 | 000000 | MOV | #0,R3 | ;SET LOWER LIMIT |
| 3293 | 013570 | 004737 | 023340 | JSR | PC,TTR | ;GO GET RESPONSE |
| 3294 | 013574 | 012704 | 025456 | MOV | #MSG38,R4 | |
| 3295 | 013600 | 000004 | | TYPE | | ;TYPE MSG |
| 3296 | 013602 | 013703 | 000572 | MOV | SPFLG,R3 | |
| 3297 | 013606 | 104400 | | TYPOCT | | ;PRINT CURRENT SETTING |
| 3298 | 013610 | 012705 | 000572 | MOV | #SPFLG,R5 | ;SET ADDRESS OF FLAG |
| 3299 | 013614 | 012701 | 000002 | MOV | #2,R1 | ;SET SIZE OF RESPONSE |
| 3300 | 013620 | 012702 | 000001 | MOV | #1,R2 | ;SET UPPER LIMIT |
| 3301 | 013624 | 012703 | 000000 | MOV | #0,R3 | ;SET LOWER LIMIT |
| 3302 | 013630 | 004737 | 023340 | JSR | PC,TTR | ;GO GET RESPONSE |
| 3303 | 013634 | 012704 | 025476 | TINP3A: MOV | #MSG39,R4 | |
| 3304 | 013640 | 000004 | | TYPE | | ;TYPE MSG |
| 3305 | 013642 | 013703 | 000566 | MOV | CRCC,R3 | |
| 3306 | 013646 | 104400 | | TYPOCT | | |
| 3307 | 013650 | 012705 | 000566 | MOV | #CRCC,R5 | |
| 3308 | 013654 | 012701 | 000002 | MOV | #2,R1 | |
| 3309 | 013660 | 012702 | 000001 | MOV | #1,R2 | |
| 3310 | 013664 | 012703 | 000000 | MOV | #0,R3 | |
| 3311 | 013670 | 004737 | 023340 | JSR | PC,TTR | |
| 3312 | 013674 | 004737 | 023204 | JSR | PC,GTSWR | ;GET SWITCHES |
| 3313 | 013700 | 005737 | 014062 | TINP4: TST | SCVFL | ;BRANCH IF SHORT CONVERSATION |
| 3314 | 013704 | 001063 | | BNE | TINPX | |
| 3315 | 013706 | 005737 | 000636 | 1S: TST | TINF | ;BRANCH IF NO TTY INPUT |
| 3316 | 013712 | 001460 | | BEQ | TINPX | |
| 3317 | 013714 | 012704 | 025536 | MOV | #MSG40,R4 | |
| 3318 | 013720 | 000004 | | TYPE | | ;TYPE MSG |
| 3319 | 013722 | 013703 | 000574 | MOV | RSTAL,R3 | |
| 3320 | 013726 | 104400 | | TYPOCT | | ;PRINT READ STALL |
| 3321 | 013730 | 012705 | 000574 | MOV | #RSTAL,R5 | ;SET READ STALL ADDRESS |

| | | | | | | | | |
|------|--------|--------|---------------|--------|--------|---------------|--|------------------------------------|
| 3322 | 013734 | 012701 | 000007 | | MOV | #7,R1 | | ;SET NUMBER OF CHARACTERS TO INPUT |
| 3323 | 013740 | 012702 | 177777 | | MOV | #-1,R2 | | ;SET MAXIMUM LIMIT |
| 3324 | 013744 | 012703 | 000001 | | MOV | #1,R3 | | ;SET MINIMUM LIMIT |
| 3325 | 013750 | 004737 | 023340 | | JSR | PC,TTR | | ;GO GET READ STALL |
| 3326 | 013754 | 012704 | 025565 | | MOV | #MSG41,R4 | | |
| 3327 | 013760 | 000004 | | | TYPE | | | ;TYPE MSG |
| 3328 | 013762 | 013703 | 000576 | | MOV | #WSTAL,R3 | | |
| 3329 | 013766 | 104400 | | | TYPOCT | | | ;PRINT READ STALL |
| 3330 | 013770 | 012705 | 000576 | | MOV | #WSTAL,R5 | | ;SET WRITE STALL ADDRESS |
| 3331 | 013774 | 012701 | 000007 | | MOV | #7,R1 | | ;SET NUMBER OF CHARACTERS TO INPUT |
| 3332 | 014000 | 012702 | 177777 | | MOV | #-1,R2 | | ;SET MAXIMUM LIMIT |
| 3333 | 014004 | 012703 | 000001 | | MOV | #1,R3 | | ;SET MINIMUM LIMIT |
| 3334 | 014010 | 004737 | 023340 | | JSR | PC,TTR | | ;GO GET WRITE STALL |
| 3335 | 014014 | 012704 | 025577 | | MOV | #MSG42,R4 | | |
| 3336 | 014020 | 000004 | | | TYPE | | | ;TYPE MSG |
| 3337 | 014022 | 013703 | 000600 | | MOV | #TSTAL,R3 | | |
| 3338 | 014026 | 104400 | | | TYPOCT | | | ;PRINT TA STALL |
| 3339 | 014030 | 012705 | 000600 | | MOV | #TSTAL,R5 | | ;SET TURN AROUND STALL ADDRESS |
| 3340 | 014034 | 012701 | 000007 | | MOV | #7,R1 | | ;SET NUMBER OF CHARACTERS TO INPUT |
| 3341 | 014040 | 012702 | 177777 | | MOV | #-1,R2 | | ;SET MAXIMUM LIMIT |
| 3342 | 014044 | 012703 | 000001 | | MOV | #1,R3 | | ;SET MINIMUM LIMIT |
| 3343 | 014050 | 004737 | 023340 | | JSR | PC,TTR | | ;GO GET TURN AROUND STALL |
| 3344 | 014054 | 005037 | 014062 | TINPX: | CLR | SCVFL | | ;CLEAR SHORT CONVERSATION FLAG |
| 3345 | 014060 | 000207 | | | RTS | PC | | ;EXIT |
| 3346 | 014062 | 000000 | | SCVFL: | 0 | | | ;SHORT CONVERSATION FLAG |
| 3347 | | | | | | | | |
| 3348 | | | | | | | | |
| 3349 | | | | | | | | |
| 3350 | 014064 | 006337 | 000646 | TPOS: | ASL | TEMP2 | | ;POSITION CHARACTER |
| 3351 | 014070 | 005303 | | | DEC | R3 | | ;SEE IF DONE |
| 3352 | 014072 | 001374 | | | BNE | TPOS | | ;IF NOT: BR |
| 3353 | 014074 | 013700 | 000676 | TPOS1: | MOV | UNP,R0 | | ;LOAD UNIT POINTER |
| 3354 | 014100 | 053760 | 000646 000746 | | BIS | TEMP2,UNI(R0) | | ;LOAD CHARACTER INTO UNI(R0) |
| 3355 | 014106 | 000207 | | | RTS | PC | | ;EXIT |
| 3356 | | | | | | | | |

;UNIT DESCRIPTION POSITIONING SUBROUTINE*****

3357
3358
3359
3360
3361
3362
3363
3364
3365
3366
3367
3368
3369
3370
3371
3372
3373
3374
3375
3376
3377
3378
3379
3380
3381
3382
3383
3384
3385
3386
3387
3388
3389
3390
3391
3392
3393
3394
3395
3396
3397
3398
3399
3400
3401
3402
3403
3404
3405
3406
3407
3408
3409
3410
3411

014110 005737 015022
014114 001044
014116 005737 000736
014122 001406
014124 005737 000560
014130 100003
014132 004737 014760
014136 000207
014140 023737 000560 014270
014146 001014
014150 013703 000552
014154 042703 177767
014160 023703 014272
014164 001404
014166 010337 014272
014172 004737 015024
014176 000207
014200 012703 027326
014204 013701 000560
014210 010137 014270
014214 062701 000001
014220 006301
014222 004771 002770
014226 004737 015024
014232 013702 000556
014236 006202
014240 012701 033334
014244 005021
014246 005202
014250 001375
014252 013737 000552 014272
014260 042737 177767 014272
014266 000207
014270 177777
014272 000000

DSUP: TST ROFL
BNE DS2A
DSO: TST ASEQF
BEQ DSOC
TST PATRN
BPL DSOC
JSR PC,DATR
RTS PC
DSOC: CMP PATRN,PATS
BNE DSOA
MOV UDES,R3
BIC #177767,R3
CMP PARS,R3
BEQ DSOB
MOV R3,PARS
JSR PC,CACLRC
DSOB: RTS PC
DSOA: MOV #MDATA,R3
MOV PATRN,R1
MOV R1,PATS
ADD #1,R1
ASL R1
JSR PC,@DATBL(R1)
DS2A: JSR PC,CACLRC
DS3: MOV FMCNT,R2
ASR R2
MOV #RDATA,R1
DS4: CLR (R1)+
INC R2
BNE DS4
MOV UDES,PARS
BIC #177767,PARS
RTS PC
PATS: -1
PARS: 0

```
*****  
:DATA SETUP ROUTINE:  
:THIS ROUTINE IS USED TO GENERATE INTO THE ENTIRE  
:WRITE BUFFER (4000 OCTAL CHARACTERS) THE DATA PATTERN  
:SELECTED BY THE OPERATOR. THERE ARE 15 (8) FIXED  
:DATA PATTERNS AVAILABLE AND ONE SELECTION (DATA PATTERN 0)  
:WHICH WILL READ ANY PATTERN PRESENTED AT THE  
:HIGH SPEED PAPER TAPE READER. THIS TAPE MUST BE PREPARED  
:BY USING THE PROGRAM CALLED DTC. (MAINDEC-11-DZTUF-A-D)  
:RANDOM DATA MAY ALSO BE USED VIA CONSOLE  
:SWITCH EIGHT (8).  
:THIS ROUTINE IS ALSO USED TO CLEAR OUT THE  
:READ BUFFER (4000 OCTAL CHARACTERS) BEFORE EACH  
:RECORD IS READ.  
*****  
:SEE IF DID RANDOM DATA  
:IF NOT: BR  
:SEE IF AUTO SEQ  
:IF NOT: BR  
:SEE IF AUTO RANDOM  
:IF NOT: BR  
:ELSE GO GENERATE RANDOM DATA  
:RETURN  
:SEE IF NEW PATTERN  
:IF SO: BR  
:GET UNIT DESCRIPTION  
:MASK EVEN PARITY  
:SEE IF SAME AS LAST TIME  
:IF SO: BR  
:SAVE PARITY  
:GO GENERATE EXPT CRC/LRC  
:R3 = ADDRS OF WRITE BUFFER  
:R1 = PATTERN SELECTOR  
:BUMP POINTER  
:MAKE PATTERN SELECTOR EVEN  
:GO GENERATE PATTERN  
:GO GENERATE EXPT CRC/LRC  
:R2=BUFFER SIZE  
:R2=FRAME CMT/2  
:R1=READ DATA START  
:CLEAR BUFFER  
:SEE IF DONE ALL  
:IF NOT: BR  
:GET UNIT DESCRIPTION  
:MASK PARITY  
:EXIT  
:PATTERN NUMBER SAVE
```

```

3412
3413
3414
3415 014274 005737 014432
3416 014300 001352
3417 014302 012737 000001 014432
3418 014310 005077 164306
3419 014314 005037 000644
3420 014320 052777 000001 164274
3421 014326 105777 164270
3422 014332 100375
3423 014334 005001
3424 014336 117701 164262
3425 014342 005737 000644
3426 014346 001011
3427 014350 105701
3428 014352 001762
3429 014354 012737 000001 000644
3430 014362 010137 000646
3431 014366 010102
3432 014370 000753
3433 014372 110123
3434 014374 005302
3435 014376 001350
3436 014400 012701 027326
3437 014404 013702 000646
3438 014410 112123
3439 014412 022703 033334
3440 014416 003002
3441 014420 000137 014226
3442 014424 005302
3443 014426 001370
3444 014430 000763
3445 014432 000000
3446

```

;EXTERNAL DATA INPUT FROM H/S READER (256 CHARACTER MAXIMUM)

```

DATO:  TST      DOFL      ;SEE IF SHOULD DO EXTERNAL INPUT
       BNE      DS2A      ;IF NOT: BR
       MOV      #1,DOFL   ;SET EXTERNAL FLAG
       CLR      @PRS      ;CLEAR READER STATUS
       CLR      TEMP1     ;CLEAR FOR USE AS CHARACTER FLAG
DATOA:  BIS      #1,@PRS   ;START READER
DATOB:  TSTB    @PRS      ;SEE IF DONE
       BPL      DATOB     ;IF NOT: BR
       CLR      R1        ;CLEAR SAVE LOCATION
       MOVB    @PRB,R1    ;SAVE CHARACTER
       TST     TEMP1     ;SEE IF HAVE FOUND START CHARACTER
       BNE     DATOC     ;IF SO: BR
       TSTB   R1         ;SEE IF CHARACTER IS 0
       BEQ    DATOA      ;IF SO: BR
       MOV    #1,TEMP1   ;ELSE SET CHARACTER FOUND FLAG
       MOV    R1,TEMP2   ;SAVE DATA SIZE
       MOV    R1,R2     ;SAVE DATA SIZE
       BR     DATOA      ;GO GET FIRST DATA CHAR
DATOC:  MOVB   R1,(R3)+  ;LOAD BUFFER
       DEC   R2         ;SEE IF READ ALL
       BNE  DATOA      ;IF NOT: BR
       MOV  #NDATA,R1   ;R1 = START OF WRITE BUFFER
       MOV  TEMP2,R2    ;R2 = SIZE OF DATA FIELD
DATOE:  MOVB  (R1)+(R3)+ ;REPEAT LOAD OF DATA FIELD
       CMP  #RDATA,R3  ;SEE IF DONE
       BGT  DATOF      ;IF NOT: BR
       JMP  DS2A       ;EXIT
DATOF:  DEC   R2        ;SEE IF AT END OF DATA FIELD
       BNE  DATOE     ;IF NOT: BR
       BR  DATOD      ;ELSE RESTART FILL
DOFL:   0             ;EXTERNAL DATA FLAG=1 IF ALREADY DONE

```

```

3447                                     ;ALL ONES*****
3448
3449 014434 012701 177777  DAT1:  MOV    #-1,R1      ;R1=DATA
3450 014440 012702 002002  DAT1A: MOV    #2002,R2     ;R2=WORD COUNT +2
3451 014444 010123          IS:   MOV    R1,(R3)+    ;LOAD BUFFER
3452 014446 005302          DEC    R2      ;SEE IF DONE
3453 014450 001375          BNE   $      ;IF NOT: BR
3454 014452 000207          RTS   PC
3455
3456                                     ;ALL ZEROS*****
3457
3458 014454 005001  DAT2:  CLR    R1      ;R1=DATA
3459 014456 000770  BR     DAT1A    ;LOAD BUFFER
3460
3461                                     ;WALKING ONE*****
3462
3463 014460 012701 000001  DAT3:  MOV    #1,R1      ;R1=DATA
3464 014464 000241          CLC
3465 014466 012702 004004  DAT3A: MOV    #4004,R2     ;R2=CHARACTER COUNT+4
3466 014472 110123          IS:   MOVB   R1,(R3)+    ;LOAD BUFFER
3467 014474 106101          ROLB   R1      ;SET NEXT CHARACTER
3468 014476 005302          DEC    R2      ;SEE IF DONE
3469 014500 001374          BNE   $      ;IF NOT: BR
3470 014502 000207          RTS   PC
3471
3472                                     ;WALKING ZERO*****
3473
3474 014504 012701 000376  DAT4:  MOV    #376,R1     ;R1=START OF DATA
3475 014510 000261          SEC
3476 014512 000765          BR     DAT3A    ;LOAD BUFFER
3477
3478                                     ;ALTERNATING ONE/ZERO*****
3479
3480
3481 014514 012701 052525  DAT5:  MOV    #52525,R1   ;R1=DATA
3482 014520 000747          BR     DAT1A    ;LOAD BUFFER
3483
3484                                     ;ALTERNATING ZERO/ONE*****
3485
3486 014522 012701 125252  DAT6:  MOV    #125252,R1  ;R1=DATA
3487 014526 000744          BR     DAT1A    ;LOAD BUFFER
3488
3489                                     ;ONE/ZERO IN ALTERNATING WORDS*****
3490
3491 014530 012701 125252  DAT7:  MOV    #125252,R1  ;SET WORD 1
3492 014534 012702 052525  MOV    #52525,R2      ;SET WORD 2
3493 014540 012704 001002  MOV    #1002,R4      ;SET NUMBER OF ENTRIES
3494 014544 010123          IS:   MOV    R1,(R3)+  ;LOAD WORD 1
3495 014546 010223          MOV    R2,(R3)+    ;LOAD WORD 2
3496 014550 005304          DEC    R4          ;SEE IF DONE
3497 014552 001374          BNE   $          ;IF NOT: BR
3498 014554 000207          RTS   PC
3499

```

```

3500
3501
3502 014556 012702 002002
3503 014557 012701 000001
3504 014558 000241
3505 014570 012713 177400
3506 014574 050123
3507 014576 106101
3508 014600 005302
3509 014602 001372
3510 014604 000207
3511
3512
3513
3514 014606 005001
3515 014610 012702 004004
3516 014614 110123
3517 014616 105201
3518 014620 005302
3519 014622 001374
3520 014624 000207
3521
3522
3523
3524 014626 012701 000377
3525 014632 012702 004004
3526 014636 110123
3527 014640 105301
3528 014642 005302
3529 014644 001374
3530 014646 000207
3531
3532
3533
3534 014650 012701 000377
3535 014654 000137 014440
3536
3537
3538
3539 014660 012702 002002
3540 014664 012701 000376
3541 014670 000261
3542 014672 010113
3543 014674 042723 177400
3544 014700 106101
3545 014702 005302
3546 014704 001372
3547 014706 000207
3548
    
```

;WALKING ONE/ALL ONE IN ALTERNATING CHARS****

```

DAT10: MOV #2002,R2 ;SET BUFFER SIZE
        MOV #1,R1 ;SET WALK BASE
        CLC
1$: MOV #177400,(R3) ;LOAD ALL ONE BYTE
    BIS R1,(R3)+ ;LOAD WALK BYTE
    ROLB R1 ;WALK ONE
    DEC R2
    BNE 1$ ;DO FULL BUFFER
    RTS PC
    
```

;ALL BITS 0-377*****

```

DAT11: CLR R1 ;R1=STARTING DATA
        MOV #4004,R2 ;R2=CHARACTER COUNT+4
1$: MOVB R1,(R3)+ ;LOAD BUFFER
    INCB R1 ;BUMP DATA
    DEC R2 ;SEE IF DONE
    BNE 1$ ;IF NOT: BR
    RTS PC ;RETURN
    
```

;ALL BITS 377-0*****

```

DAT12: MOV #377,R1 ;R1=STARTING DATA
        MOV #4004,R2 ;R2=CHARACTER COUNT+4
1$: MOVB R1,(R3)+ ;LOAD BUFFER
    DECB R1 ;BUMP DATA
    DEC R2 ;SEE IF DONE
    BNE 1$ ;IF NOT: BR
    RTS PC ;RETURN
    
```

;ALTERNATING CHARACTERS 0 AND 377*****

```

DAT13: MOV #377,R1 ;R1 = DATA
        JMP DAT1A ;LOAD BUFFER
    
```

;WALKING ZERO/ALL ZERO IN ALTERNATING CHARS*****

```

DAT14: MOV #2002,R2 ;SET BUFFER SIZE
        MOV #376,R1 ;SET WALK BASE
        SEC
1$: MOV R1,(R3) ;LOAD WALK BYTE
    BIC #177400,(R3)+ ;CLEAR HIGH BYTE
    ROLB R1 ;WALK ZERO BIT
    DEC R2
    BNE 1$ ;FILL BUFFER
    RTS PC ;RETURN
    
```

```

3549                                     ;AUTO SEQUENCE PATTERN*****
3550
3551 014710 012702 000200      DAT15: MOV      #200,R2          ;SET NUMBER OF ENTRIES
3552 014714 012701 014740      1$:  MOV      #APATS,R1        ;SET START OF PATTERN
3553 014720 012704 000010      2$:  MOV      #10,R4          ;SET SIZE OF PATTERN
3554 014724 012123              MOV      (R1)+,(R3)+        ;FILL BUFFER
3555 014726 005304              DEC      R4                ;SEE IF DONE PATTERN
3556 014730 001375              BNE     2$                 ;IF NOT: BR
3557 014732 005302              DEC      R2                ;SEE IF DONE BUFER
3558 014734 001367              BNE     1$                 ;IF NOT: BR
3559 014736 000207              RTS      PC                ;RETURN
3560
3561 014740 000000      APATS: 0
3562 014742 177400          177400
3563 014744 000377          377
3564 014746 000000          0
3565 014750 177777          -1
3566 014752 000377          377
3567 014754 177400          177400
3568 014756 177777          -1
3569
3570                                     ;RANDOM DATA GENERATOR SUBROUTINE*****
3571
3572 014760 013704 000556      DATR: MOV      FMCNT,R4        ;SET NUMBER OF FRAMES
3573 014764 012703 027326      MOV      #WDATA,R3        ;SET ADDRESS OF START OF BUFFER
3574 014770 012701 177777      MOV      #-1,R1          ;SET HIGH LIMIT
3575 014774 005002              CLR      R2                ;SET LOW LIMIT
3576 014776 004737 023152      1$:  JSR      PC,RANG        ;GO GENERATE NUMBER
3577 015002 013723 000630      MOV      RANSV,(R3)+      ;LOAD BUFFER
3578 015006 005204              INC      R4                ;SEE IF DONE WHOLE BUFFER
3579 015010 001372              BNE     1$                 ;IF NOT: BR
3580 015012 012737 000001 015022  MOV      #1,RDFL          ;SET RANDOM DATA FLAG
3581 015020 000207              RTS      PC                ;EXIT
3582 015022 000000      RDFL: 0                  ;RANDOM DATA SELECT FLAG

```

```

3583
3584
3585
3586
3587
3588
3589
3590
3591
3592 015024 013700 000556      CRCLRC: MOV      FMCNT,RO      ;SET RECORD SIZE
3593 015030 005400              NEG      RO
3594 015032 012701 027326      MOV      @MDATA,R1      ;SET START OF BUFFER
3595 015036 005037 015360      CLR      XORS
3596 015042 111104              CLO:    MOV      (R1),R4    ;GET CHARACTER
3597 015044 004737 015232      JSR      PC,CLP          ;GO GET PARITY OF CHARACTER
3598 015050 004737 015334      JSR      PC,XOR          ;XOR CHARACTER
3599 015054 000241              CLC
3600 015056 006004              ROR      R4              ;ROTATE 1 RIGHT
3601 015060 103014              BCC      CL2             ;IF NO CARRY: BR
3602 015062 052704 000400      BIS      @400,R4        ;SET BIT NINE
3603 015066 000241              CLC
3604 015070 010405              CL1:    MOV      R4,R5
3605 015072 042705 177703      BIC      @177703,R5     ;SAVE CHARACTER
3606 015076 005105              COM      R5
3607 015100 042705 177703      BIC      @177703,R5
3608 015104 042704 000074      BIC      @74,R4
3609 015110 050504              BIS      R5,R4          ;COMPLIMENT BITS 2,3,4,5
3610 015112 010437 015360      CL2:    MOV      R4,XORS
3611 015116 005300              DEC      RO
3612 015120 001350              BNE      CLO            ;BRANCH IF NOT LAST CHAR
3613 015122 013704 015360      CLLAST: MOV      XORS,R4
3614 015126 005137 015360      COM      XORS
3615 015132 042737 177050 015360  BIC      @177050,XORS
3616 015140 042704 177727      BIC      @177727,R4    ;COMPLIMENT ALL BUT BITS 3&5
3617 015144 050437 015360      BIS      R4,XORS
3618 015150 013737 015360 015362  MOV      XORS,EXCRC    ;SAVE EXPECTED CRC
3619 015156 013700 000556      MOV      FMCNT,RO
3620 015162 005400              NEG      RO
3621 015164 012701 027326      MOV      @MDATA,R1    ;DO EXPT LRC
3622 015170 005037 015360      CLR      XORS
3623 015174 111104              CL3:    MOV      (R1),R4
3624 015176 004737 015232      JSR      PC,CLP        ;GET PARITY
3625 015202 004737 015334      JSR      PC,XOR        ;XOR CHARACTER
3626 015206 005300              DEC      RO
3627 015210 001371              BNE      CL3           ;DO ALL FOR LRC
3628 015212 013704 015362      MOV      EXCRC,R4
3629 015216 004737 015334      JSR      PC,XOR        ;XOR CRC TO DATA
3630 015222 013737 015360 015364  MOV      XORS,EXLRC    ;SAVE EXPT LRC
3631 015230 000207              RTS      PC            ;RETURN
3632 015232 005704              CLP:    TST      R4
3633 015234 001010              BNE      CLPE          ;SEE IF 0 CHAR
3634 015236 032737 000010 000552  BIT      @10,UDES      ;IF NOT: BR
3635 015244 001404              BEQ      CLPE          ;SEE IF EVEN PARITY
3636 015246 012704 000420      MOV      @420,R4      ;IF NOT: BR
3637 015252 005201              INC      R1            ;SET 0 CHAR EVEN PARITY
3638 015254 000207              RTS      PC            ;BUMP POINTER
                          ;RETURN

```


3668
3669
3670
3671
3672
3673
3674
3675
3676
3677
3678
3679
3680
3681
3682
3683
3684
3685
3686
3687
3688
3689
3690
3691
3692
3693
3694
3695
3696
3697
3698
3699
3700
3701
3702
3703
3704
3705
3706
3707
3708
3709
3710
3711
3712
3713
3714
3715
3716
3717
3718
3719
3720
3721
3722
3723

015366 005037 000660
015372 005037 000706
015376 013705 000556
015402 032737 000020 000552
015410 001401
015412 006205
015414 012701 027326
015420 012702 033334
015424 032737 000010 000552
015432 001430
015434 032737 000020 000552
015442 001024
015444 032737 002000 000552
015452 001020
015454 105711
015456 001404
015460 005201
015462 005205
015464 001373
015466 000406
015470 112721 000020
015474 012737 177777 014270
015502 000767
015504 013705 000556
015510 012701 027326
015514 032737 010000 000562
015522 001462
015524 013704 000556
015530 005404
015532 032737 000020 000552
015540 001402
015542 000241
015544 006004
015546 060401
015550 060402
015552 032737 000001 000556
015560 001401
015562 105722
015564 032737 000020 000552
015572 001431
015574 000241

```

:*****
:DATA CHECK SUBROUTINE:
:THIS SUBROUTINE IS USED TO COMPARE EACH CHARACTER
:OF DATA READ FROM TAPE WITH THE EXPECTED CHARACTER.
:ANY ERROR DETECTED WILL CAUSE CONTROL TO BE
:PASSED TO AN ERROR PRINT SUBROUTINE AND A
:SUBROUTINE TO ACCUMULATE THE NUMBER OF BITS
:DROPPED AND PICKED UP FROM EACH CHARACTER.
:THE NUMBER OF READ ERRORS IS ALSO ACCUMULATED.
:DATA CHECKING MAY BE TERMINATED BY USE OF
:CONSOLE SWITCH THIRTEEN (13).
:*****

DCHK: CLR BBC ;CLEAR BAD RECORD CNTR
      CLR DERFL ;CLEAR DATA ERROR FLAG
      MOV FMCNT,RS ;LOAD CHAR COUNT
      BIT #20,UDES ;SEE IF CORE DUMP
      BEQ DCHK0 ;IF NOT: BR
      ASR RS ;RS = FC/2
DCHK0: MOV #WDATA,R1 ;SET WRITE DATA ADDR
      MOV #RDATA,R2 ;SET READ DATA ADDR
      BIT #10,UDES ;SEE IF EVEN PARITY
      BEQ DF0C0 ;IF NOT: BR
      BIT #20,UDES ;SEE IF CORE DUMP PARITY
      BNE DF0C0 ;IF SO: BR
      BIT #2000,UDES ;SEE IF PE MODE
      BNE DF0C0 ;IF SO: BR
DFOF: TSTB (R1) ;SEE IF 0 CHAR
      BEQ DF0D ;IF SO: BR
      INC R1 ;BUMP POINTER
DFOE: INC R5 ;SEE IF DONE
      BNE DF0F ;IF NOT: BR
      BR DF0C ;ELSE CONTINUE
DF0D: MOVB #20,(R1)+ ;SET 20 IN PLACE OF 0
      MOV #-1,PATS ;SET PATTERN GENERATE FLAG
      BR DF0E
DF0C: MOV FMCNT,RS ;RESET CHAR CNT
      MOV #WDATA,R1 ;RESET DATA ADDRESS
DF0C0: BIT #10000,RDCMD ;SEE IF READ REVERSE
      BEQ DF0 ;IF NOT: BR
DF0B: MOV FMCNT,R4 ;GET FRAME COUNT
      NEG R4 ;SET TO WHOLE NUMBER
      BIT #20,UDES ;SEE IF CORE DUMP
      BEQ DF0B0 ;IF NOT: BR
DF0B0: ROR R4 ;SET TO FC/2
      ADD R4,R1 ;POINT TO START OF WRITE DATA
      ADD R4,R2 ;POINT TO START OF READ DATA
      BIT #1,FMCNT ;SEE IF ODD FRAME COUNT
      BEQ DF0A ;IF NOT: BR
      TSTB (R2)+ ;BUMP POINTER
DF0A: BIT #20,UDES ;SEE IF CORE DUMP
      BEQ DF0A4 ;IF NOT: BR
      CLC

```


3772
3773
3774
3775
3776
3777
3778
3779
3780
3781
3782
3783
3784
3785
3786
3787
3788
3789
3790
3791
3792
3793
3794
3795
3796
3797
3798
3799

```

*****
: DATA ERROR SUBROUTINE:
:
: THIS SUBROUTINE IS USED TO PRINT OUT ANY
: ERRORS FOUND DURING THE DATA CHECK.
: EACH CHARACTER FOUND BAD WILL BE PRINTED
: IN BIT FORMAT ALONG WITH ITS EXPECTED CHARACTER.
: AN ERROR HEADER CONSISTING OF THE UNIT NUMBER,
: BLOCK NUMBER, RECORD NUMBER, SIZE OF RECORD, AND
: ERROR TYPE (READ FORWARD, READ REVERSE, WRITE, ETC)
: IS PRINTED ONLY ONCE FOR EACH RECORD FOUND BAD.
: A COUNT IS MADE OF THE NUMBER OF SUCCESSIVE BAD
: CHARACTERS, AND IF TEN (10) SUCCESSIVE BAD CHARACTERS
: ARE FOUND IN A SINGLE RECORD, A MESSAGE INDICATING
: A BAD RECORD CONDITION IS PRINTED AND THE NEXT
: TWENTY (20) CHARACTERS ARE SKIPPED BEFORE CHECKING
: IS RESUMED. IF THE BAD RECORD CONDITION IS FOUND
: THREE TIMES IN A RECORD, ALL REMAINING DATA IS
: SKIPPED EXCEPT THE FINAL TEN (10) CHARACTERS.
: THIS SKIPPING IS OF COURSE ONLY POSSIBLE IN
: RECORDS WHICH CONTAIN A SUFFICIENT NUMBER OF CHARACTERS.
: PRINTING OF ERRORS MAY BE DISALLOWED AT ANY TIME
: BY SETTING CONSOLE SWITCH TEN (10) TO A ONE.
: THE OPERATOR MAY CAUSE THE PROGRAM TO HALT ON ANY ERROR
: BY SETTING CONSOLE SWITCH FIFTEEN (15) TO A ONE.
*****

```

| | | | | | | | | |
|------|--------|--------|--------|--------|---------|--------|--------------|------------------------------|
| 3800 | 016000 | 032777 | 002000 | 162602 | DERR: | BIT | #2000,2SWR | : BRANCH IF NO ERROR |
| 3801 | 016006 | 001067 | | | | BNE | DERR4 | : PRINTOUT DESIRED |
| 3802 | 016010 | 005237 | 000672 | | DERRO: | INC | PFLG | : SET PRINT FLAG |
| 3803 | 016014 | 005737 | 000666 | | | TST | HDRFL | : SEE IF HAVE PRINTED HEADER |
| 3804 | 016020 | 001007 | | | | BNE | DERROA | : IF SO: BR |
| 3805 | 016022 | 004737 | 022570 | | | JSR | PC,PAPRT | : PRINT CYCLE NUMBER |
| 3806 | 016026 | 012704 | 024444 | | | MOV | #MSG1,R4 | : LOAD ERROR MSG ADDR |
| 3807 | 016032 | 000004 | | | | TYPE | | : TYPE MSG |
| 3808 | 016034 | 004737 | 021020 | | | JSR | PC,FRPRT | : PRINT F OR R |
| 3809 | 016040 | 012704 | 024463 | | DERROA: | MOV | #MSG4,R4 | |
| 3810 | 016044 | 000004 | | | | TYPE | | : TYPE MSG |
| 3811 | 016046 | 010203 | | | | MOV | R2,R3 | |
| 3812 | 016050 | 162703 | 033334 | | | SUB | #RDATA,R3 | : POINT TO CHAR |
| 3813 | 016054 | 005303 | | | | DEC | R3 | |
| 3814 | 016056 | 032737 | 010000 | 000562 | | BIT | #10000,RDCMD | : SEE IF READ REVERSE |
| 3815 | 016064 | 001402 | | | | BEQ | DERROB | : IF NOT: BR |
| 3816 | 016066 | 010503 | | | | MOV | R5,R3 | : GET CHAR NUMBER |
| 3817 | 016070 | 005103 | | | | COM | R3 | |
| 3818 | 016072 | 104400 | | | DERROB: | TYPOCT | | : PRINT CHAR NUMBER |
| 3819 | 016074 | 012704 | 024451 | | | MOV | #MSG2,R4 | |
| 3820 | 016100 | 000004 | | | | TYPE | | : TYPE MSG |
| 3821 | 016102 | 032737 | 010000 | 000562 | | BIT | #10000,RDCMD | : SEE IF READ REVERSE |
| 3822 | 016110 | 001402 | | | | BEQ | DERROC | : IF NOT: BR |
| 3823 | 016112 | 111103 | | | | MOVB | (R1),R3 | : GET CHAR |
| 3824 | 016114 | 000401 | | | | BR | DERROD | |
| 3825 | 016116 | 114103 | | | DERROC: | MOVB | -(R1),R3 | : LOAD EXPECTED DATA |
| 3826 | 016120 | 004737 | 024222 | | DERROD: | JSR | PC,DOUT | : GO PRINT CHAR |
| 3827 | 016124 | 012704 | 024456 | | | MOV | #MSG3,R4 | |

| Address | Offset | Hex | Dec | Hex | Dec | Label | Instruction | Comment | Message |
|---------|--------|--------|--------|--------|-----|---------|-------------|--------------|---------------------------------------|
| 3828 | 016130 | 000004 | | | | | TYPE | | :TYPE MSG |
| 3829 | 016132 | 032737 | 010000 | 000562 | | | BIT | #10000,RDCMD | :SEE IF READ REVERSE |
| 3830 | 016140 | 001402 | | | | | BEQ | DERR1 | :IF NOT: BR |
| 3831 | 016142 | 111203 | | | | | MOVB | (R2),R3 | :GET CHAR |
| 3832 | 016144 | 000401 | | | | | BR | DERR2 | |
| 3833 | 016146 | 114203 | | | | DERR1: | MOVB | -(R2),R3 | |
| 3834 | 016150 | 004737 | 024222 | | | DERR2: | JSR | PC,DOUT | :PRINT BAD CHAR |
| 3835 | 016154 | 032737 | 010000 | 000562 | | | BIT | #10000,RDCMD | :BRANCH IF NOT READ |
| 3836 | 016162 | 001001 | | | | | BNE | DERR4 | :REVERSE |
| 3837 | 016164 | 122122 | | | | DERR3: | CMPB | (R1)+,(R2)+ | :RESET POINTERS |
| 3838 | 016166 | 105237 | 000660 | | | DERR4: | INCB | BBC | :BUMP BAD RECORD CNTR |
| 3839 | 016172 | 122737 | 000010 | 000660 | | | CMPB | #10,BBC | :SEE IF ELD BTH |
| 3840 | 016200 | 001123 | | | | | BNE | DEREX | :IF NOT: BR |
| 3841 | 016202 | 032777 | 002000 | 162400 | | | BIT | #2000,JSWR | :SEE IF PRINT INHIBIT |
| 3842 | 016210 | 001003 | | | | | BNE | IS | :IF SO: BR |
| 3843 | 016212 | 012704 | 024577 | | | | MOV | #MSG15,R4 | |
| 3844 | 016216 | 000004 | | | | | TYPE | | :TYPE MSG |
| 3845 | 016220 | 105037 | 000660 | | | IS: | CLRB | BBC | :RESET BAD RECORD CNTR |
| 3846 | 016224 | 000337 | 000660 | | | | SWAB | BBC | :POSITION BLD BTH AMOUNT |
| 3847 | 016230 | 105237 | 000660 | | | | INCB | BBC | :BUMP AMOUNT |
| 3848 | 016234 | 122737 | 000003 | 000660 | | | CMPB | #3,BBC | :SEE IF HAD 3 BLD BTHS |
| 3849 | 016242 | 101054 | | | | | BHI | DERR4B | :IF NOT: BR |
| 3850 | 016244 | 000337 | 000660 | | | | SWAB | BBC | :REPOSITION BBC |
| 3851 | 016250 | 022705 | 177767 | | | | CMP | #177767,R5 | :SEE IF ON LAST EIGHT CHARS |
| 3852 | 016254 | 101473 | | | | | BLOS | DERR6 | :IF SO: BR |
| 3853 | 016256 | 012705 | 177767 | | | | MOV | #177767,R5 | :SET CHAR CNTR TO 8 |
| 3854 | 016262 | 032737 | 010000 | 000562 | | | BIT | #10000,RDCMD | :SEE IF READ REVERSE |
| 3855 | 016270 | 001416 | | | | | BEQ | DERR4A | :IF NOT: BR |
| 3856 | 016272 | 012701 | 027326 | | | | MOV | #WDATA,R1 | :GET START OF BUFFER |
| 3857 | 016276 | 012702 | 033334 | | | | MOV | #RDATA,R2 | :GET START OF BUFFER |
| 3858 | 016302 | 062701 | 000010 | | | | ADD | #10,R1 | |
| 3859 | 016306 | 062702 | 000010 | | | | ADD | #10,R2 | :POINT TO START +10 |
| 3860 | 016312 | 032737 | 000001 | 000556 | | | BIT | #1,FMCNT | :SEE IF ODD FRAME COUNT |
| 3861 | 016320 | 001453 | | | | | BEQ | DEREX | :IF NOT: BR |
| 3862 | 016322 | 105722 | | | | | TSTB | (R2)+ | :BUMP POINTER |
| 3863 | 016324 | 000451 | | | | | BR | DEREX | |
| 3864 | 016326 | 013737 | 000556 | 000644 | | DERR4A: | MOV | FMCNT,TEMP1 | :LOAD CHAR COUNT |
| 3865 | 016334 | 005137 | 000644 | | | | COM | TEMP1 | |
| 3866 | 016340 | 005237 | 000644 | | | | INC | TEMP1 | |
| 3867 | 016344 | 162737 | 000010 | 000644 | | | SUB | #10,TEMP1 | :POINT TO BUFFER -8 |
| 3868 | 016352 | 013701 | 000644 | | | | MOV | TEMP1,R1 | :POINT TO NEXT CHAR |
| 3869 | 016356 | 062701 | 027326 | | | | ADD | #WDATA,R1 | :POINT TO NEXT WRITE CHAR |
| 3870 | 016362 | 013702 | 000644 | | | | MOV | TEMP1,R2 | :POINT TO END OF READ DATA -8 FORWARD |
| 3871 | 016366 | 062702 | 033334 | | | | ADD | #RDATA,R2 | :POINT TO NEXT CHAR |
| 3872 | 016372 | 000426 | | | | | BR | DEREX | :EXIT |
| 3873 | 016374 | 000337 | 000660 | | | DERR4B: | SWAB | BBC | :REPOSITION BBC |
| 3874 | 016400 | 000241 | | | | | CLC | | |
| 3875 | 016402 | 062705 | 000024 | | | | ADD | #24,R5 | :SKIP 20 CHARS |
| 3876 | 016406 | 103416 | | | | | BCS | DERR6 | :IF EXCEED RECORD SIZE: BR |
| 3877 | 016410 | 032737 | 010000 | 000562 | | | BIT | #10000,RDCMD | :SEE IF READ REVERSE |
| 3878 | 016416 | 001405 | | | | | BEQ | DERR5 | :IF NOT: BR |
| 3879 | 016420 | 162701 | 000024 | | | | SUB | #24,R1 | |
| 3880 | 016424 | 162702 | 000024 | | | | SUB | #24,R2 | :RESET POINTERS |
| 3881 | 016430 | 000407 | | | | | BR | DEREX | |
| 3882 | 016432 | 062701 | 000024 | | | DERR5: | ADD | #24,R1 | :SKIP 20 CHARS |
| 3883 | 016436 | 062702 | 000024 | | | | ADD | #24,R2 | :SKIP FORWARD 20 CHARS |

| | | | | | | | |
|------|--------|--------|--------|--------|------|-----------|-------------------------------|
| 3884 | 016442 | 000402 | | | BR | DEREX | |
| 3885 | 016444 | 012705 | 177777 | | MOV | 8-1 RS | : SET TO EOR |
| 3886 | 016450 | 005777 | 162134 | | TST | SWR | : BRANCH IF NOT HALT ON ERROR |
| 3887 | 016454 | 100012 | | | BPL | DEREX1 | |
| 3888 | 016456 | 000000 | | | HALT | | |
| 3889 | 016460 | 005737 | 000672 | | TST | PFLG | : SEE IF PRINTED |
| 3890 | 016464 | 001006 | | | BNE | DEREX1 | : IF SO: BR |
| 3891 | 016466 | 032777 | 002000 | 162114 | BIT | #2000 SWR | : SEE IF SHOULD PRINT |
| 3892 | 016474 | 001002 | | | BNE | DEREX1 | : IF NOT: BR |
| 3893 | 016476 | 000137 | 016010 | | JMP | DERRO | : ELSE PRINT |
| 3894 | 016502 | 005037 | 000672 | | CLR | PFLG | : CLEAR FLAG |
| 3895 | 016506 | 005237 | 000706 | | INC | DERFL | : BUMP DATA ERROR FLAG |
| 3896 | 016512 | 000207 | | | RTS | PC | : RETURN |
| 3897 | | | | | | | |

```

3898
3899
3900
3901
3902
3903
3904
3905
3906
3907
3908
3909
3910
3911
3912
3913
3914
3915
3916 016514 005037 000644
3917 016520 005037 000646
3918 016524 005037 000650
3919 016530 111137 000644
3920 016534 111237 000646
3921 016540 013704 000676
3922 016544 016437 000770 000722
3923 016552 016437 001010 000720
3924 016560 032737 010000 000562
3925 016566 001005
3926 016570 124142
3927 016572 112137 000644
3928 016576 112237 000646
3929 016602 004737 016614
3930 016606 004737 017034
3931 016612 000207
3932 016614 113703 000644
3933 016620 113704 000646
3934 016624 140403
3935 016626 001001
3936 016630 000207
3937 016632 012737 000010 000712
3938 016640 132703 000001
3939 016644 001455
3940 016646 105737 000650
3941 016652 001016
3942 016654 005277 162040
3943 016660 005777 162034
3944 016664 100045
3945 016666 032777 002000 161714
3946 016674 001402
3947 016676 004737 022570
3948 016702 004737 017100
3949 016706 000415
3950 016710 005277 162006
3951 016714 005777 162002
3952 016720 100027
3953 016722 032777 002000 161660

```

```

*****
DROPS AND PICKS SUBROUTINE:
THIS SUBROUTINE IS USED TO ACCUMULATE FROM
EACH BAD DATA CHARACTER FOUND THE NUMBER
OF BITS WHICH WERE EITHER DROPPED OR PICKED UP.
TWO COUNTERS PER SLAVE ARE USED TO ACCUMULATE THIS
INFORMATION AND CAN STORE UP TO 32K DROPS
OR PICKS BEFORE OVERFLOWING. IF OVERFLOW IS
ABOUT TO OCCUR, THESE ACCUMULATORS ARE
PRINTED IN OCTAL AND RESET TO ZERO.
THE CONTENTS OF THE ACCUMULATORS MAY BE
DISPLAYED AT ANY TIME BY SETTING CONSOLE
SWITCH FOURTEEN TO A ONE (1). THE PRINTOUT WILL OCCUR
AT THE END OF THE CURRENT BLOCK CYCLE.
*****

```

```

DRPKF: CLR TEMP1
CLR TEMP2
CLR TEMP3
MOVB (R1),TEMP1 ;LOAD GOOD CHAR
MOVB (R2),TEMP2 ;LOAD BAD CHAR
MOV UNP R4
MOV PIK1(R4),BPKP
MOV DRP1(R4),BDPP
BIT #10000,RDCMD ;SEE IF READ REVERSE
BNE DRPK ;IF SO: BR
CMPB -(R1),-(R2) ;POINT TO CHAR
MOVB (R1)+,TEMP1 ;LOAD GOOD CHAR
MOVB (R2)+,TEMP2 ;LOAD BAD CHAR
DRPK: JSR PC,DRDP ;GET DROPS
JSR PC,PICK ;GET PICKS
RTS PC ;EXIT
DROP: MOVB TEMP1,R3 ;R3 = GOOD CHAR
MOVB TEMP2,R4 ;R4 = BAD CHAR
DPC: BICB R4,R3 ;GET DROPS/PICKS
BNE DPCG ;IF SOME: BR
RTS PC ;RETURN
DPCG: MOV #10,BCNT ;SET NUMBER TO CHECK
DPC0: BITB #1,R3 ;SEE IF DROPPED OR PICKED THIS BIT
BEQ DPC2 ;IF NOT: BR
TSTB TEMP3 ;SEE IF ON PICKS
BNE DPC1 ;IF SO: BR
INC @BDPP ;BUMP DROP CNTR
TST @BDPP
BPL DPC2 ;IF NO OVERFLOW: BR
BIT #2000,@SWR ;SEE IF HAVE PRINTED DATA
BEQ DPC0A ;IF SO: BR
DPC0A: JSR PC,PAPRT ;PRINT CYCLE NUMBER
JSR PC,DPPRT ;PRINT DROPS AND PICKS
BR DPC2A
DPC1: INC @BPKP ;BUMP PICK CNTR
TST @BPKP ;SEE IF OVERFLOW
BPL DPC2 ;IF NOT: BR
BIT #2000,@SWR ;SEE IF HAVE PRINTED DATA

```

| | | | | | | | | |
|------|--------|--------|--------|--------|-------------|----------------|--|---------------------------|
| 3954 | 016730 | 001402 | | | BEQ | DPC1A | | ; IF SO: BR |
| 3955 | 016732 | 004737 | 022570 | | JSR | PC, PAPRT | | ; PRINT CYCLE NUMBER |
| 3956 | 016736 | 004737 | 017100 | | DPC1A: JSR | PC, DPPRT | | ; PRINT DROPS AND PICKS |
| 3957 | 016742 | 013704 | 000676 | | DPC2A: MOV | UNP, R4 | | |
| 3958 | 016746 | 016403 | 001010 | | MOV | DRP1(R4), R3 | | ; SET DROP POINTER |
| 3959 | 016752 | 016404 | 000770 | | MOV | PIK1(R4), R4 | | ; SET PICK POINTER |
| 3960 | 016756 | 012737 | 000010 | 000712 | MOV | #10, BCNT | | ; SET NUMBER OF BITS |
| 3961 | 016764 | 005023 | | | DPC2B: CLR | (R3)+ | | ; CLEAR DROPS |
| 3962 | 016766 | 005024 | | | CLR | (R4)+ | | ; CLEAR PICK |
| 3963 | 016770 | 005337 | 000712 | | DEC | BCNT | | ; SEE IF DONE |
| 3964 | 016774 | 001373 | | | BNE | DPC2B | | ; IF NOT: BR |
| 3965 | 016776 | 000207 | | | RTS | PC | | ; EXIT |
| 3966 | 017000 | 000241 | | | DPC2: CLC | | | |
| 3967 | 017002 | 106003 | | | RORB | R3 | | ; GET NEXT BIT |
| 3968 | 017004 | 005337 | 000712 | | DEC | BCNT | | ; SEE IF DONE |
| 3969 | 017010 | 001410 | | | BEQ | DPC3 | | |
| 3970 | 017012 | 062737 | 000002 | 000722 | ADD | #2, BPKP | | |
| 3971 | 017020 | 062737 | 000002 | 000720 | ADD | #2, BDPP | | |
| 3972 | 017026 | 000137 | 016640 | | JMP | DPC0 | | ; CONTINUE |
| 3973 | 017032 | 000207 | | | DPC3: RTS | PC | | ; RETURN |
| 3974 | 017034 | 013704 | 000676 | | PICK: MOV | UNP, R4 | | ; GET UNIT POINTER |
| 3975 | 017040 | 016437 | 000770 | 000722 | MOV | PIK1(R4), BPKP | | ; SET PICK POINTER |
| 3976 | 017046 | 016437 | 001010 | 000720 | MOV | DRP1(R4), BDPP | | ; SET DROP POINTER |
| 3977 | 017054 | 113704 | 000644 | | MOVB | TEMP1, R4 | | ; R4 = GOOD CHAR |
| 3978 | 017060 | 113703 | 000646 | | MOVB | TEMP2, R3 | | ; R3 = BAD CHAR |
| 3979 | 017064 | 112737 | 000001 | 000650 | MOVB | #1, TEMP3 | | ; SET PICK FLAG |
| 3980 | 017072 | 004737 | 016624 | | JSR | PC, DPC | | ; GO CHECK PICKS |
| 3981 | 017076 | 000207 | | | RTS | PC | | ; EXIT |
| 3982 | 017100 | 012704 | 025075 | | DPPRT: MOV | #MSG26, R4 | | |
| 3983 | 017104 | 000004 | | | TYPE | | | ; TYPE MSG |
| 3984 | 017106 | 013704 | 000676 | | MOV | UNP, R4 | | |
| 3985 | 017112 | 016437 | 001010 | 000720 | MOV | DRP1(R4), BDPP | | ; SET DROP POINTER |
| 3986 | 017120 | 016437 | 000770 | 000722 | MOV | PIK1(R4), BPKP | | ; SET PICK POINTER |
| 3987 | 017126 | 062737 | 000016 | 000720 | ADD | #16, BDPP | | |
| 3988 | 017134 | 062737 | 000016 | 000722 | ADD | #16, BPKP | | |
| 3989 | 017142 | 012737 | 000010 | 000712 | MOV | #10, BCNT | | ; SET NUMBER TO PRINT |
| 3990 | 017150 | 017703 | 161544 | | DPPRTO: MOV | #BDPP, R3 | | |
| 3991 | 017154 | 104400 | | | TYPOCT | | | ; PRINT DROPS |
| 3992 | 017156 | 005337 | 000712 | | DEC | BCNT | | ; SEE IF DONE |
| 3993 | 017162 | 001404 | | | BEQ | DPPRT1 | | ; IF NOT: BR |
| 3994 | 017164 | 162737 | 000002 | 000720 | SUB | #2, BDPP | | ; BUMP POINTER |
| 3995 | 017172 | 000766 | | | BR | DPPRTO | | ; CONTINUE FOR ALL 8 BITS |
| 3996 | 017174 | 012737 | 000010 | 000712 | DPPRT1: MOV | #10, BCNT | | ; SET NUMBER TO PRINT |
| 3997 | 017202 | 012704 | 025106 | | MOV | #MSG27, R4 | | |
| 3998 | 017206 | 000004 | | | TYPE | | | ; TYPE MSG |
| 3999 | 017210 | 017703 | 161506 | | DPPRT2: MOV | #BPKP, R3 | | |
| 4000 | 017214 | 104400 | | | TYPOCT | | | ; PRINT PICKS |
| 4001 | 017216 | 005337 | 000712 | | DEC | BCNT | | ; SEE IF DONE |
| 4002 | 017222 | 001404 | | | BEQ | DPPRTX | | ; IF SO: BR |
| 4003 | 017224 | 162737 | 000002 | 000722 | SUB | #2, BPKP | | ; BUMP POINTER |
| 4004 | 017232 | 000766 | | | BR | DPPRT2 | | ; CONTINUE FOR ALL 8 BITS |
| 4005 | 017234 | 000207 | | | DPPRTX: RTS | PC | | ; RETURN |

4006
4007
4008
4009
4010
4011
4012
4013
4014
4015
4016
4017
4018
4019
4020
4021
4022
4023
4024
4025
4026
4027
4028
4029
4030
4031
4032
4033
4034
4035
4036
4037
4038
4039
4040
4041
4042
4043
4044
4045
4046
4047
4048
4049
4050
4051
4052
4053
4054
4055
4056
4057
4058
4059
4060
4061

017236 013703 000556
017242 032703 000001
017246 001401
017250 005303
017252 005403
017254 032737 000020 000552
017262 001401
017264 006203
017266 032737 000010 000674
017274 001414
017276 032737 010000 000562
017304 001405
017306 012703 033334
017312 162703 000002
017316 000405
017320 062703 033334
017324 000402
017326 062703 027326
017332 010337 020774
017336 012704 000007
017342 012701 020776
017346 005021
017350 005304
017352 001375
017354 020377 161134
017360 001402
017362 005237 020776
017366 032737 000010 000674
017374 001006
017376 005777 161114
017402 001441

```

*****
:STATUS CHECK SUBROUTINE:
:THIS SUBROUTINE IS USED TO PERFORM A CHECK OF
: BOTH THE MASSBUS CONTROLLER (RH11) AND THE TAPE
: CONTROLLER (TMD2). THE RH11 IS CHECKED FOR ERRORS
: AS REFLECTED IN REGISTERS CS1 AND CS2 AND ALSO THAT
: THE BUS ADDRESS (BA) AND WORD COUNT (WC) ARE
: CORRECT. THE TMD2 IS CHECKED FOR DRIVE STATUS (DS),
: DRIVE ERRORS (ER), AND PROPER FRAME COUNT. THE SPECIAL
: CHECK CHARACTERS (CRC+LRC) ARE ALSO CHECKED WHEN
: APPROPRIATE (IE: NRZ READ OR WRITE). CERTAIN TYPES
: OF DRIVE ERRORS IN PE OPERATION WILL BE ACCOMPANIED
: BY THE DISPLAY OF THE DEAD TRACK REGISTER (CC). THESE
: TYPES ARE ER BITS 15,10,7,6. THE PRINTOUTS OF BAD
: CRC,LRC,FC, AND BA WILL SHOW BOTH THE EXPECTED AND
: RECEIVED VALUES (IE: EXPT-RCVD). ONLY THOSE REGISTERS
: WHICH ARE IN ERROR WILL BE PRINTED AND ALL PRINTOUTS
: ARE IN OCTAL FORMAT WITH NO LEADING ZEROS. AS IN
: DATA ERRORS, STATUS ERRORS ARE PRECEDED BY HEADER
: DESCRIBING THE HARDWARE UNDER TEST, THE BLOCKING
: INFORMATION, AND THE ERROR TYPE.
*****
ERCHK: MOV FMCNT,R3 ;GET FRAME COUNT
      BIT #1,R3 ;SEE IF ODD
      BEQ ERO ;IF NOT: BR
      DEC R3 ;BUMP COUNT
      NEG R3
      BIT #20,UDES ;SEE IF CORE DUMP
      BEQ EROB ;IF NOT: BR
      ASR R3 ;SET TO FC/2
      BIT #10,MTC1 ;SEE IF WRITE OP
      BEQ ER1 ;IF SO: BR
      BIT #10000,RDCMD
      BEQ EROA
      MOV #RDATA,R3 ;SET POINTER
      SUB #2,R3
      BR ER2
      ADD #RDATA,R3 ;BUILD EXPT READ ADDRESS
      BR ER2
      ADD #WDATA,R3 ;BUILD EXPT WRITE ADDRESS
      ER1: MOV R3,CADR ;SAVE ADDRESS
      ER2: MOV #7,R4
      MOV #BAER,R1
      ER2A0: CLR (R1)+ ;CLEAR FLAGS
      DEC R4
      BNE ER2A0
      CMP R3,#BA ;SEE IF ADDRESS OK
      BEQ ER2A1 ;IF SO: BR
      INC BAER ;SET BUS ADDRESS ERROR
      ER2A1: BIT #10,MTC1 ;SEE IF WRITE OPER
      BNE ER2B ;IF NOT: BR
      ER2A: TST #FC ;SEE IF FC=0
      BEQ ER3 ;IF SO: BR

```

| | | | | | | | | | |
|------|--------|--------|--------|--------|--------|-----|--------------|--|--|
| 4062 | 017404 | 005237 | 021004 | | | INC | FCER | | ;SET FC ERROR |
| 4063 | 017410 | 000436 | | | | BR | ER3 | | |
| 4064 | 017412 | 032737 | 000040 | 000674 | ER2B: | BIT | #40,MTC1 | | ;SEE IF SPACE OPER |
| 4065 | 017420 | 001766 | | | | BEQ | ER2A | | ;IF SO: BR |
| 4066 | 017422 | 005737 | 000700 | | | TST | TMFLG | | ;SEE IF TM TIME |
| 4067 | 017426 | 001011 | | | | BNE | ER2D | | ;IF SO: BR |
| 4068 | 017430 | 013703 | 000556 | | | MOV | FMCNT,R3 | | |
| 4069 | 017434 | 005403 | | | | NEG | R3 | | ;R3 = EXPT RECORD SIZE |
| 4070 | 017436 | 020377 | 161054 | | ER2C: | CMP | R3,#FC | | ;SEE IF FC = EXPT |
| 4071 | 017442 | 001421 | | | | BEQ | ER3 | | ;IF SO: BR |
| 4072 | 017444 | 005237 | 021004 | | | INC | FCER | | ;SET FC ERROR FLAG |
| 4073 | 017450 | 000416 | | | | BR | ER3 | | |
| 4074 | 017452 | 032737 | 002000 | 000552 | ER2D: | BIT | #2000,UDES | | ;SEE IF PE |
| 4075 | 017460 | 001346 | | | | BNE | ER2A | | ;IF SO: BR |
| 4076 | 017462 | 032737 | 010000 | 000562 | | BIT | #10000,RDCMD | | ;SEE IF READ REVERSE |
| 4077 | 017470 | 001003 | | | | BNE | ER2E | | ;IF SO: BR |
| 4078 | 017472 | 012703 | 000002 | | | MOV | #2,R3 | | |
| 4079 | 017476 | 000757 | | | | BR | ER2C | | ;LOOK FOR EXPT = 2 |
| 4080 | 017500 | 012703 | 000001 | | ER2E: | MOV | #1,R3 | | |
| 4081 | 017504 | 000754 | | | | BR | ER2C | | ;GO CHECK FC FOR TM |
| 4082 | 017506 | 032777 | 160000 | 160774 | ER3: | BIT | #160000,#C1 | | ;SEE IF COUNT ERROR |
| 4083 | 017514 | 001437 | | | | BEQ | ER4 | | |
| 4084 | 017516 | 017703 | 160776 | | | MOV | #CS,R3 | | ;GET CONT STATUS REG |
| 4085 | 017522 | 042703 | 000307 | | | BIC | #307,R3 | | ;MASK OUT IR,OR,UNIT NO. & SEE IF OTHER ERRORS |
| 4086 | 017526 | 001406 | | | | BEQ | ER3A | | ;IF NOT: BR |
| 4087 | 017530 | 005737 | 000700 | | | TST | TMFLG | | ;SEE IF TAPE MARK TIME |
| 4088 | 017534 | 001425 | | | | BEQ | ER3B | | ;IF NOT: BR |
| 4089 | 017536 | 042703 | 001000 | | | BIC | #1000,R3 | | ;MASK MISSED TRANS & BR IF OTHER ERRORS |
| 4090 | 017542 | 001022 | | | | BNE | ER3B | | |
| 4091 | 017544 | 032777 | 060000 | 160736 | ER3A: | BIT | #60000,#C1 | | ;SEE IF EITHER TRE OR MCPE |
| 4092 | 017552 | 001420 | | | | BEQ | ER4 | | ;IF NOT: BR |
| 4093 | 017554 | 005737 | 000700 | | | TST | TMFLG | | ;SEE IF TM TIME |
| 4094 | 017560 | 001413 | | | | BEQ | ER3B | | ;IF NOT: BR |
| 4095 | 017562 | 017703 | 160736 | | | MOV | #ER,R3 | | ;GET ERROR REGISTER |
| 4096 | 017566 | 032737 | 000010 | 000552 | | BIT | #10,UDES | | ;SEE IF EVEN PARITY |
| 4097 | 017574 | 001402 | | | | BEQ | ER3A1 | | ;IF NOT: BR |
| 4098 | 017576 | 042703 | 000100 | | | BIC | #100,R3 | | ;MASK PAR |
| 4099 | 017602 | 042703 | 001000 | | ER3A1: | BIC | #1000,R3 | | ;MASK FCE |
| 4100 | 017606 | 001402 | | | | BEQ | ER4 | | ;IF NO ERRORS EXCEPT FCE: BR |
| 4101 | 017610 | 005237 | 021000 | | ER3B: | INC | CONER | | ;SET CONT ERROR FLAG |
| 4102 | 017614 | 032777 | 040000 | 160700 | ER4: | BIT | #40000,#DS | | ;SEE IF DRIVE ERROR |
| 4103 | 017622 | 001420 | | | | BEQ | ER6 | | ;IF NOT: BR |
| 4104 | 017624 | 005737 | 000700 | | | TST | TMFLG | | ;SEE IF TAPE MARK TIME |
| 4105 | 017630 | 001413 | | | | BEQ | ER4A | | ;IF NOT: BR |
| 4106 | 017632 | 017703 | 160666 | | | MOV | #ER,R3 | | ;GET ER |
| 4107 | 017636 | 032737 | 000010 | 000552 | | BIT | #10,UDES | | ;SEE IF EVEN PARITY |
| 4108 | 017644 | 001402 | | | | BEQ | ER4A1 | | ;IF NOT: BR |
| 4109 | 017646 | 042703 | 000100 | | | BIC | #100,R3 | | ;MASK PAR |
| 4110 | 017652 | 042703 | 001000 | | ER4A1: | BIC | #1000,R3 | | ;MASK OUT FCE & BRANCH IF |
| 4111 | 017656 | 001402 | | | | BEQ | ER6 | | ;NO OTHER ERRORS |
| 4112 | 017660 | 005237 | 021002 | | ER4A: | INC | DRVER | | ;SET DRIVER ERROR FLAG |
| 4113 | 017664 | 032737 | 002000 | 000552 | ER6: | BIT | #2000,UDES | | |
| 4114 | 017672 | 001071 | | | | BNE | ERPT | | ;IF IN PE MODE: BR |
| 4115 | 017674 | 032777 | 020000 | 160706 | | BIT | #20000,#SWR | | ;SEE IF NO DATA CHECK |
| 4116 | 017702 | 001065 | | | | BNE | ERPT | | ;IF NOT: BR (ALLOW READ OF UNKNOWN TAPES) |
| 4117 | 017704 | 032737 | 000040 | 000674 | | BIT | #40,MTC1 | | ;SEE IF WRITE OR READ OP |

| | | | | | | | |
|------|--------|--------|--------|--------|------|--------------|--------------------------|
| 4118 | 017712 | 001461 | | | BEQ | ERPT | : IF NOT: BR |
| 4119 | 017714 | 005737 | 000700 | | TST | TMFLG | : SEE IF TAPE MARK TIME |
| 4120 | 017720 | 001413 | | | BEQ | ER6A | : IF NOT: BR |
| 4121 | 017722 | 013737 | 015362 | 021016 | MOV | EXCRC,CRCSV | : SAVE CRC |
| 4122 | 017730 | 013737 | 015364 | 021014 | MOV | EXLRC,LRCV | : SAVE LRC |
| 4123 | 017736 | 005037 | 015362 | | CLR | EXCRC | |
| 4124 | 017742 | 012737 | 000023 | 015364 | MOV | #23,EXLRC | : SET CRC/LRC FOR TM |
| 4125 | 017750 | 032737 | 000060 | 000552 | BIT | #60,UDS | : SEE IF FORMAT i4 |
| 4126 | 017756 | 001037 | | | BNE | ERPT | : IF NOT: BR |
| 4127 | 017760 | 017703 | 160544 | | MOV | #CC,R3 | : GET CRC CHARACTER |
| 4128 | 017764 | 042703 | 177000 | | BIC | #177000,R3 | |
| 4129 | 017770 | 023703 | 015362 | | CMF | EXCRC,R3 | |
| 4130 | 017774 | 001402 | | | BEQ | ER7 | : IF CRC GOOD: BR |
| 4131 | 017776 | 005237 | 021010 | | INC | CRCR | : SET ERROR FLAG |
| 4132 | 020002 | 017703 | 160526 | | MOV | #MR,R3 | : GET LRC |
| 4133 | 020006 | 000303 | | | SWAB | R3 | |
| 4134 | 020010 | 005703 | | | TST | R3 | |
| 4135 | 020012 | 100002 | | | BPL | ER10 | |
| 4136 | 020014 | 052703 | 000400 | | BIS | #400,R3 | |
| 4137 | 020020 | 042703 | 177000 | | BIC | #177000,R3 | |
| 4138 | 020024 | 023703 | 015364 | | CMF | EXLRC,R3 | |
| 4139 | 020030 | 001412 | | | BEQ | ERPT | : IF LRC GOOD: BR |
| 4140 | 020032 | 010337 | 021012 | | MOV | R3,ACTLRC | : SAVE ACTUAL LRC |
| 4141 | 020036 | 005237 | 021006 | | INC | LRCR | : SET LRC ERROR FLAG |
| 4142 | 020042 | 032737 | 010000 | 000562 | BIT | #10000,RDCMD | : SEE IF READ REVERSE |
| 4143 | 020050 | 001402 | | | BEQ | ERPT | : IF NOT: BR |
| 4144 | 020052 | 005037 | 021006 | | CLR | LRCR | : ELSE CLEAR LRC ERROR |
| 4145 | 020056 | 012703 | 000006 | | MOV | #6,R3 | |
| 4146 | 020062 | 005037 | 000710 | | CLR | SERFL | : CLEAR ERROR FLAG |
| 4147 | 020066 | 005037 | 000724 | | CLR | ERSAV | |
| 4148 | 020072 | 012704 | 020776 | | MOV | #BAER,R4 | |
| 4149 | 020076 | 005724 | | | TST | (R4)+ | : SEE IF ANY ERROR |
| 4150 | 020100 | 001004 | | | BNE | ERPTG | : IF SO: BR |
| 4151 | 020102 | 005303 | | | DEC | R3 | |
| 4152 | 020104 | 001374 | | | BNE | ERPTT | |
| 4153 | 020106 | 000137 | 020740 | | JMP | ERPX1 | |
| 4154 | 020112 | 005237 | 000710 | | INC | SERFL | : SET ERROR FLAG |
| 4155 | 020116 | 017737 | 160402 | 000724 | MOV | #ER,ERSAV | : SAVE ERROR REGISTER |
| 4156 | 020124 | 032777 | 002000 | 160456 | BIT | #2000,#SWR | : SEE IF PRINT |
| 4157 | 020132 | 001420 | | | BEQ | ERPTO | : IF SO: BR |
| 4158 | 020134 | 022737 | 000002 | 000714 | CMF | #2,RTYFL | : SEE IF READ RETRY |
| 4159 | 020142 | 001006 | | | BNE | ERPTG1 | : IF NOT: BR |
| 4160 | 020144 | 013703 | 000704 | | MOV | RTCNT,R3 | |
| 4161 | 020150 | 005203 | | | INC | R3 | : BUMP RETRY COUNT |
| 4162 | 020152 | 020337 | 000604 | | CMF | R3,RETRY | : SEE IF LAST RETRY |
| 4163 | 020156 | 001406 | | | BEQ | ERPTO | : IF SO: BR |
| 4164 | 020160 | 022737 | 000002 | 021002 | CMF | #2,DRVER | : SEE IF TM STATUS ERROR |
| 4165 | 020166 | 001402 | | | BEQ | ERPTO | : IF SO: BR |
| 4166 | 020170 | 000137 | 020620 | | JMP | ERPX0 | |
| 4167 | 020174 | 005237 | 000672 | | INC | PFLG | |
| 4168 | 020200 | 004737 | 022570 | | JSR | PC,PAPRT | : PRINT HEADER |
| 4169 | 020204 | 013704 | 000654 | | MOV | EMADDR,R4 | |
| 4170 | 020210 | 000004 | | | TYPE | | : TYPE MSG |
| 4171 | 020212 | 004737 | 021020 | | JSR | PC,FRPRT | : PRINT F OR R |
| 4172 | 020216 | 005737 | 000700 | | TST | TMFLG | |
| 4173 | 020222 | 001407 | | | BEQ | ERPT1 | |

| | | | | | | | |
|------|--------|--------|--------|--------|-------------|---------------|-------------------------|
| 4174 | 020224 | 022737 | 026026 | 000654 | CMP | #MSG54,EMADDR | |
| 4175 | 020232 | 001403 | | | BEQ | ERPT1 | |
| 4176 | 020234 | 012704 | 026044 | | MOV | #MSG56,R4 | ;PRINT TM |
| 4177 | 020240 | 000004 | | | TYPE | | ;TYPE MSG |
| 4178 | 020242 | 005737 | 021000 | | ERPT1: TST | CONER | |
| 4179 | 020246 | 001414 | | | BEQ | ERPT2 | ;IF NO CONT ERROR: BR |
| 4180 | 020250 | 012704 | 024725 | | MOV | #MSG23,R4 | |
| 4181 | 020254 | 000004 | | | TYPE | | ;TYPE MSG |
| 4182 | 020256 | 017703 | 160226 | | MOV | @C1,R3 | |
| 4183 | 020262 | 104400 | | | TYPOCT | | ;PRINT CONTROL 1 |
| 4184 | 020264 | 012704 | 024752 | | MOV | #MSG23D,R4 | ;PRINT CS TAG |
| 4185 | 020270 | 000004 | | | TYPE | | ;TYPE MSG |
| 4186 | 020272 | 017703 | 160222 | | MOV | @CS,R3 | |
| 4187 | 020276 | 104400 | | | TYPOCT | | ;PRINT CONT STATUS |
| 4188 | 020300 | 005737 | 021002 | | ERPT2: TST | DRVER | |
| 4189 | 020304 | 001414 | | | BEQ | ERPT3 | ;IF SO DRIVE ERROR: BR |
| 4190 | 020306 | 012704 | 024760 | | MOV | #MSG23E,R4 | |
| 4191 | 020312 | 000004 | | | TYPE | | ;TYPE MSG |
| 4192 | 020314 | 017703 | 160202 | | MOV | @DS,R3 | |
| 4193 | 020320 | 104400 | | | TYPOCT | | ;PRINT DRIVE STATUS |
| 4194 | 020322 | 012704 | 024765 | | MOV | #MSG23F,R4 | |
| 4195 | 020326 | 000004 | | | TYPE | | ;TYPE MSG |
| 4196 | 020330 | 017703 | 160170 | | MOV | @ER,R3 | |
| 4197 | 020334 | 104400 | | | TYPOCT | | ;PRINT DRIVE ERROR |
| 4198 | 020336 | 005737 | 020776 | | ERPT3: TST | BAER | |
| 4199 | 020342 | 001416 | | | BEQ | ERPT4 | ;IF NO BA ERROR: BR |
| 4200 | 020344 | 012704 | 024740 | | MOV | #MSG23B,R4 | |
| 4201 | 020350 | 000004 | | | TYPE | | ;TYPE MSG |
| 4202 | 020352 | 017703 | 160136 | | MOV | @BA,R3 | |
| 4203 | 020356 | 104400 | | | TYPOCT | | ;PRINT BUS ADDRESS |
| 4204 | 020360 | 012737 | 000255 | 000640 | MOV | @255,T0B | |
| 4205 | 020366 | 004737 | 023744 | | JSR | PC,T0G | ;PRINT / |
| 4206 | 020372 | 013703 | 020774 | | MOV | CADER,R3 | |
| 4207 | 020376 | 104400 | | | TYPOCT | | ;PRINT EXPT BUS ADDRESS |
| 4208 | 020400 | 005737 | 021004 | | ERPT4: TST | FCER | |
| 4209 | 020404 | 001406 | | | BEQ | ERPT5 | ;IF NO FC ERROR: BR |
| 4210 | 020406 | 012704 | 024745 | | MOV | #MSG23C,R4 | |
| 4211 | 020412 | 000004 | | | TYPE | | ;TYPE MSG |
| 4212 | 020414 | 017703 | 160076 | | MOV | @FC,R3 | |
| 4213 | 020420 | 104400 | | | TYPOCT | | ;PRINT FRAME COUNT |
| 4214 | 020422 | 012704 | 024733 | | ERPT5: MOV | #MSG23A,R4 | |
| 4215 | 020426 | 000004 | | | TYPE | | ;TYPE MSG |
| 4216 | 020430 | 017703 | 160056 | | MOV | @WC,R3 | |
| 4217 | 020434 | 104400 | | | TYPOCT | | ;PRINT WORD COUNT |
| 4218 | 020436 | 005737 | 021010 | | TST | CRCER | |
| 4219 | 020442 | 001420 | | | BEQ | ERPT5A | ;IF NO CRC ERROR: BR |
| 4220 | 020444 | 012704 | 026071 | | MOV | #MSG58,R4 | |
| 4221 | 020450 | 000004 | | | TYPE | | ;TYPE MSG |
| 4222 | 020452 | 017703 | 160052 | | MOV | @CC,R3 | |
| 4223 | 020456 | 042703 | 177000 | | BIC | @177000,R3 | |
| 4224 | 020462 | 104400 | | | TYPOCT | | ;PRINT ACTUAL CRC |
| 4225 | 020464 | 012737 | 000255 | 000640 | MOV | @255,T0B | |
| 4226 | 020472 | 004737 | 023744 | | JSR | PC,T0G | |
| 4227 | 020476 | 013703 | 015362 | | MOV | EXCRC,R3 | |
| 4228 | 020502 | 104400 | | | TYPOCT | | ;PRINT EXPECTED CRC |
| 4229 | 020504 | 005737 | 021006 | | ERPT5A: TST | LRCER | |

| | | | | | | | | | |
|------|--------|--------|--------|--------|---------|--------|-------------|--|-----------------------------------|
| 4230 | 020510 | 001416 | | | | BEG | ERPT6 | | ; IF NO LRC ERROR: BR |
| 4231 | 020512 | 012704 | 026077 | | | MOV | #MSG59,R4 | | |
| 4232 | 020516 | 000004 | | | | TYPE | | | ; TYPE MSG |
| 4233 | 020520 | 013703 | 021012 | | | MOV | ACTLRC,R3 | | |
| 4234 | 020524 | 104400 | | | | TYPOCT | | | ; PRINT ACTUAL LRC |
| 4235 | 020526 | 012737 | 000255 | 000640 | | MOV | #255,T0B | | |
| 4236 | 020534 | 004737 | 023744 | | | JSR | PC,T0G | | |
| 4237 | 020540 | 013703 | 015364 | | | MOV | EXLRC,R3 | | |
| 4238 | 020544 | 104400 | | | | TYPOCT | | | ; PRINT EXPECTED LRC |
| 4239 | 020546 | 005737 | 021002 | | ERPT6: | TST | DRIVER | | |
| 4240 | 020552 | 001421 | | | | BEG | ERPT7 | | ; IF NO DRIVE ERROR: BR |
| 4241 | 020554 | 032737 | 002000 | 000552 | | BIT | #2000,UDES | | |
| 4242 | 020562 | 001415 | | | | BEG | ERPT7 | | ; IF NO FE: BR |
| 4243 | 020564 | 017704 | 157734 | | | MOV | ZER,R4 | | |
| 4244 | 020570 | 042704 | 075477 | | | BIC | #75477,R4 | | ; MASK OUT ALL BUT BITS 15,10,7,6 |
| 4245 | 020574 | 001410 | | | | BEG | ERPT7 | | ; IF NO CONDITIONALS SET: BR |
| 4246 | 020576 | 012704 | 024777 | | | MOV | #MSG23H,R4 | | |
| 4247 | 020602 | 000004 | | | | TYPE | | | ; TYPE MSG |
| 4248 | 020604 | 017703 | 157720 | | | MOV | ACC,R3 | | |
| 4249 | 020610 | 042703 | 177000 | | | BIC | #177000,R3 | | ; MASK CC |
| 4250 | 020614 | 104400 | | | | TYPOCT | | | ; PRINT CHECK CHARACTERS |
| 4251 | 020616 | 000240 | | | ERPT7: | NOP | | | |
| 4252 | 020620 | 005777 | 157764 | | ERPXD: | TST | ASWR | | ; BRANCH IF NOT HALT ON ERROR |
| 4253 | 020624 | 100012 | | | | BPL | ERPXD | | |
| 4254 | 020626 | 000000 | | | | HALT | | | |
| 4255 | 020630 | 005737 | 000672 | | | TST | PFLG | | ; SEE IF HAVE PRINTED |
| 4256 | 020634 | 001006 | | | | BNE | ERPXD | | ; IF SO: BR |
| 4257 | 020636 | 032777 | 002000 | 157744 | | BIT | #2000,ASWR | | ; SEE IF SHOULD PRINT |
| 4258 | 020644 | 001002 | | | | BNE | ERPXD | | ; IF NOT: BR |
| 4259 | 020646 | 000137 | 020174 | | | JMP | ERPT0 | | ; PRINT ERROR |
| 4260 | 020652 | 005037 | 000672 | | ERPXD: | CLR | PFLG | | |
| 4261 | 020656 | 005737 | 000566 | | | TST | CRCC | | ; BRANCH IF CRC ERROR |
| 4262 | 020662 | 001007 | | | | BNE | IS | | ; CORRECTION DESIRED |
| 4263 | 020664 | 012777 | 000040 | 157626 | | MOV | #40,ACS | | ; ELSE INIT |
| 4264 | 020672 | 013777 | 000550 | 157620 | | MOV | DVN,ACS | | ; RESET DRIVE NUMBER |
| 4265 | 020700 | 000414 | | | | BR | 2S | | |
| 4266 | 020702 | 012777 | 000011 | 157600 | 1S: | MOV | #11,AC1 | | ; DRIVE CLEAR |
| 4267 | 020710 | 017704 | 157612 | | | MOV | AS,R4 | | |
| 4268 | 020714 | 010477 | 157606 | | | MOV | R4,AS | | ; CLEAR AS |
| 4269 | 020720 | 013704 | 000510 | | | MOV | C1,R4 | | |
| 4270 | 020724 | 005204 | | | | INC | R4 | | |
| 4271 | 020726 | 152714 | 000100 | | | BISB | #100,(R4) | | ; RESET TRE |
| 4272 | 020732 | 013777 | 000552 | 157602 | 2S: | MOV | UDES,ATC | | ; RESET TC |
| 4273 | 020740 | 032737 | 000040 | 000674 | ERPXD1: | BIT | #40,ATC1 | | |
| 4274 | 020746 | 001411 | | | | BEG | ERPXD2 | | ; IF NOT READ/WRITE OP: BR |
| 4275 | 020750 | 005737 | 000700 | | | TST | TMFLG | | |
| 4276 | 020754 | 001406 | | | | BEG | ERPXD2 | | ; IF NOT TM TIME: BR |
| 4277 | 020756 | 013737 | 021016 | 015362 | | MOV | CRCSV,EXCRC | | ; RESTORE CRC |
| 4278 | 020764 | 013737 | 021014 | 015364 | | MOV | LRCNV,EXLRC | | ; RESTORE LRC |
| 4279 | 020772 | 000207 | | | ERPXD2: | RTS | PC | | ; EXIT |
| 4280 | 020774 | 000000 | | | CADER: | 0 | | | ; EXPT ADDRESS SAVE |
| 4281 | 020776 | 000000 | | | BAER: | 0 | | | |
| 4282 | 021000 | 000000 | | | CONER: | 0 | | | |
| 4283 | 021002 | 000000 | | | DRIVER: | 0 | | | |
| 4284 | 021004 | 000000 | | | FCER: | 0 | | | |
| 4285 | 021006 | 000000 | | | LRCER: | 0 | | | |

4286 021010 000000
4287 021012 000000
4288 021014 000000
4289 021016 000000

CRCER: 0
ACTLRC: 0
LRCSV: 0
CRCSV: 0

4290
4291
4292
4293
4294
4295
4296
4297
4298
4299

: F FOR FORWARD/R FOR REVERSE PRINT SUBROUTINE:
: THIS SUBROUTINE IS USED TO PRINT OUT THE
: TAPE DIRECTION USED WHEN ANY ERROR IS
: DETECTED IN STATUS OF READ OR WRITE, DATA, OR
: SPACING OPERATIONS.

4300 021020 032737 000010 000674
4301 021026 001411
4302 021030 012704 024633
4303 021034 032737 000002 000674
4304 021042 001002
4305 021044 012704 024630
4306 021050 000004
4307 021052 000207
4308

FRPRT: BIT #10,MTC1 ;SEE IF WRITE COMMAND
BEQ 25 ;IF SO: BR
MOV #MSG17,R4 ;SET TO TYPE REVERSE MSG
BIT #2,MTC1 ;BRANCH IF REVERSE
BNE 15
MOV #MSG16,R4 ;SET FORWARD MESSAGE
15: TYPE ;TYPE MSG
25: RTS PC ;EXIT

4309
 4310
 4311
 4312
 4313
 4314
 4315
 4316
 4317
 4318
 4319
 4320
 4321
 4322
 4323
 4324
 4325
 4326
 4327
 4328
 4329
 4330
 4331
 4332
 4333
 4334
 4335
 4336
 4337
 4338
 4339
 4340
 4341
 4342
 4343
 4344
 4345
 4346
 4347
 4348
 4349
 4350
 4351
 4352
 4353
 4354
 4355
 4356
 4357
 4358
 4359
 4360
 4361
 4362
 4363
 4364

021054 005037 000644
 021060 013777 000550 157432
 021066 032777 010000 157426
 021074 001026
 021076 005237 000644
 021102 001371
 021104 004737 022570
 021110 032737 000010 000674
 021116 001004
 021120 012704 024470
 021124 000004
 021126 000405
 021130 012704 024475
 021134 000004
 021136 004737 021020
 021142 012704 025055
 021146 000004
 021150 000000
 021152 032777 020000 157342
 021160 001411
 021162 004737 022570
 021166 012704 027154
 021172 000004
 021174 032777 020000 157320
 021202 001374
 021204 022737 000026 000674
 021212 001003

```

*****
TAPE COMMAND EXECUTE SUBROUTINE:
THIS SUBROUTINE IS USED TO EXECUTE THE
MAG TAPE COMMAND DESCRIBED BY THE READ
OR WRITE ROUTINE. THE FINAL COMMAND IS
SENT TO THE DEVICE REGISTER ALONG WITH THE
INTERRUPT ENABLE AND GO BITS.
ONCE THE COMMAND IS ISSUED, AN INTERRUPT
TIMER IS STARTED AND IF NO INTERRUPT IS RETURNED
BEFORE TIME OUT OCCURS, AN ERROR WILL BE
PRINTED AND THE PROGRAM STOPPED. TESTING MAY
BE RESUMED BY PRESSING THE CONTINUE SWITCH.
TWO INTERRUPT HANDLERS ARE USED, ONE FOR MAG TAPE
AND ANOTHER FOR TELETYPE (TTY).
UPON RECEIPT OF A MAG TAPE INTERRUPT, HOUSEKEEPING
IS PERFORMED AND CONTROL RETURNED TO THE CALLING
ROUTINE (READ,WRITE,ETC).
RECEIPT OF A TTY INTERRUPT WILL CAUSE THE
PROGRAM TO CHECK FOR ENTRY OF A CNTRL C CHARACTER.
IF NOT CNTRL C, THEN CONTINUATION OF WAIT FOR MAG
TAPE INTERRUPT IS RETURNED. IF HOWEVER, THE TTY
INTERRUPT WAS CAUSED BY ENTRY OF A CNTRL C,
THEN AT THIS TIME REQUESTS FOR NEW STALL VALUES
ARE PRINTED AND THE RESPONSES ENTERED. RESUMPTION
OF TAPE INTERRUPT WAIT IS THEN RESUMED.
*****
TAPG: CLR      TEMP1
      MOV      DVN, JCS      ;SET DRIVE NO.
TAPG0: BIT      #10000, JDS   ;SEE IF HAVE MOL
      BNE     TAPG3         ;IF SO: BR
      INC     TEMP1        ;SEE IF TIMED OUT
      BNE     TAPG0        ;WAIT FOR READY
      JSR    PC, PAPRT     ;PRINT CYCLE NUMBER
      BIT    #10, MTC1     ;SEE IF WRITE OP
      BNE     TAPG1        ;IF NOT: BR
      MOV    #MSG5, R4
      TYPE   ;TYPE MSG
      BR     TAPG2
TAPG1: MOV      #MSG6, R4
      TYPE   ;TYPE MSG
      JSR    PC, FRPRT     ;PRINT F OR R
TAPG2: MOV      #MSG25, R4
      TYPE   ;TYPE MSG
      HALT
TAPG3: BIT      #20000, JDS   ;SEE IF PIP RESET
      BEQ    TAPG3F       ;IF SO: BR
      JSR    PC, PAPRT     ;PRINT HEADER
      MOV    #MSG116, R4
      TYPE   ;TYPE MSG
      BIT    #20000, JDS
      BNE    15
TAPG3F: CMP     #26, MTC1
      BNE    TAPG3A       ;IF NOT: BR
    
```

| | | | | | | | |
|------|--------|--------|--------|--------|-------------|------------|-----------------------------------|
| 4365 | 021214 | 012704 | 177777 | | MOV | #-1,R4 | ;ELSE SET FC FOR -1 |
| 4366 | 021220 | 000406 | | | BR | TAPG3B | |
| 4367 | 021222 | 013704 | 000556 | | TAPG3A: MOV | FM CNT,R4 | |
| 4368 | 021226 | 032704 | 000001 | | BIT | #1,R4 | |
| 4369 | 021232 | 001401 | | | BEQ | TAPG3B | |
| 4370 | 021234 | 005304 | | | DEC | R4 | |
| 4371 | 021236 | 000261 | | | TAPG3B: SEC | | |
| 4372 | 021240 | 006004 | | | ROR | R4 | ;SET WC = FC/2 FOR NORMAL FORMAT |
| 4373 | 021242 | 032737 | 000020 | 000552 | BIT | #20,UDES | ;SEE IF CORE DUMP FORMAT |
| 4374 | 021250 | 001402 | | | BEQ | TAPG3C | ;IF NOT: BR |
| 4375 | 021252 | 000261 | | | SEC | | |
| 4376 | 021254 | 006004 | | | ROR | R4 | ;SET WC = FC/4 FOR CORE DUMP |
| 4377 | 021256 | 010477 | 157230 | | TAPG3C: MOV | R4,WC | ;SET WORD COUNT |
| 4378 | 021262 | 012777 | 000011 | 157220 | MOV | #11,WC | ;DRIVE CLEAR |
| 4379 | 021270 | 017777 | 157222 | 157220 | MOV | FC,FC | ;RESET FC LOADED |
| 4380 | 021276 | 005737 | 000570 | | TST | INTR | ;SEE IF INTERCHANGE READ |
| 4381 | 021302 | 001407 | | | BEQ | TAPG3D | ;IF NOT: BR |
| 4382 | 021304 | 032737 | 000040 | 000674 | BIT | #40,MTC1 | ;SEE IF READ OP |
| 4383 | 021312 | 001403 | | | BEQ | TAPG3D | ;IF NOT: BR |
| 4384 | 021314 | 012777 | 000003 | 157212 | MOV | #3,MR | ;SET INTERCHANGE READ MAINT. MODE |
| 4385 | 021322 | 013704 | 000674 | | TAPG3D: MOV | MTC1,R4 | ;GET COMMAND |
| 4386 | 021326 | 042704 | 177707 | | BIC | #177707,R4 | ;MASK OP CODE |
| 4387 | 021332 | 022704 | 000030 | | CMP | #30,R4 | ;SEE IF SPACE OP CODE |
| 4388 | 021336 | 001403 | | | BEQ | TAPG3E | ;IF SO: BR |
| 4389 | 021340 | 012737 | 177740 | 000670 | MOV | #-40,STAL | ;SET INTERRUPT DELAY MULT TO 40 |
| 4390 | 021346 | 052737 | 000101 | 000674 | TAPG3E: BIS | #101,MTC1 | ;SET INTERRUPT ENABLE AND GO |
| 4391 | 021354 | 000240 | | | NOP | | |
| 4392 | 021356 | 013777 | 000674 | 157124 | MOV | MTC1,WC | ;EXECUTE COMMAND |
| 4393 | 021364 | 005077 | 157216 | | CLR | PSW | ;CLEAR PRIORITY |
| 4394 | 021370 | 005037 | 000644 | | CLR | TEMP1 | |
| 4395 | 021374 | 005237 | 000644 | | TAPG4: INC | TEMP1 | ;SEE IF HAVE TIMED OUT |
| 4396 | 021400 | 001375 | | | BNE | TAPG4 | ;IF NOT: BR |
| 4397 | 021402 | 005237 | 000670 | | INC | STAL | |
| 4398 | 021406 | 001372 | | | BNE | TAPG4 | ;DO TIME DELAY MULTIPLIER |
| 4399 | 021410 | 012777 | 000340 | 157170 | TAPG5: MOV | #340,PSW | ;RESET PRIORITY |
| 4400 | 021416 | 032777 | 002000 | 157164 | BIT | #2000,SWR | ;SEE IF SHOULD PRINT ERRORS |
| 4401 | 021424 | 001012 | | | BNE | TAPG6 | ;IF NOT: BR |
| 4402 | 021426 | 004737 | 022570 | | JSR | PC,PAPRT | ;PRINT CYCLE NUMBER |
| 4403 | 021432 | 013704 | 000654 | | MOV | EMADDR,R4 | |
| 4404 | 021436 | 000004 | | | TYPE | | ;TYPE MSG |
| 4405 | 021440 | 004737 | 021020 | | JSR | PC,FRPRT | ;PRINT F OR R |
| 4406 | 021444 | 012704 | 025035 | | MOV | #MSG24,R4 | |
| 4407 | 021450 | 000004 | | | TYPE | | ;TYPE MSG |
| 4408 | 021452 | 005777 | 157132 | | TAPG6: TST | SWR | ;BRANCH IF NOT HALT ON ERROR |
| 4409 | 021456 | 100001 | | | BPL | TAPG7 | |
| 4410 | 021460 | 000000 | | | HALT | | |
| 4411 | 021462 | 000137 | 021720 | | TAPG7: JMP | MTINTA | ;RETURN TO CALLING ROUTINE |
| 4412 | | | | | | | |

```

4413
4414
4415 021466 017746 157122
4416 021472 042716 000200
4417 021476 122716 000003
4418 021502 001005
4419 021504 000005
4420 021506 005077 157074
4421 021512 000137 000200
4422 021516 122716 000001
4423 021522 001016
4424 021524 022737 000176 000610
4425 021532 001015
4426 021534 012737 177570 000610
4427 021542 004737 023274
4428 021546 012704 027300
4429 021552 000004
4430 021554 004737 023316
4431 021560 022716 000007
4432 021564 001005
4433 021566 012737 000176 000610
4434 021574 004737 023204
4435 021600 022716 000002
4436 021604 001042
4437 021606 004737 023274
4438 021612 005237 014062
4439 021616 004737 013634
4440 021622 032777 000040 156760
4441 021630 001426
4442 021632 012704 025623
4443 021636 000004
4444 021640 013703 000602
4445 021644 104400
4446 021646 012705 000602
4447 021652 012701 000007
4448 021656 012702 177777
4449 021662 012703 002000
4450 021666 004737 023340
4451 021672 004737 023316
4452 021676 005726
4453 021700 012716 011252
4454 021704 000002
4455 021706 004737 023316
4456 021712 005726
4457 021714 000002
4458
4459
4460 021716 000240
4461 021720 042777 000037 156606
4462 021726 013716 000664
4463 021732 000002

```

```

:TTY INTERRUPT HANDLER
TTINT: MOV @TKB,-(SP) ;GET CHARACTER
BIC #200,(SP) ;STRIP PARITY BIT
CMPB #3,(SP) ;BRANCH IF NOT +C
BNE IS
RESET ;RESET ALL I/O
CLR @PSW ;CLEAR PSW
JMP @#200 ;RESTART PROGRAM
IS: CMPB #1,(SP) ;BRANCH IF NOT +A
BNE 2$
CMP #SWREG,SWR ;BRANCH IF HARDWARE SWR IS INVOKED
BNE 3$
MOV #177570,SWR ;INVOKE HARDWARE SWR
JSR PC,SAVE ;SAVE REGISTERS ON THE STACK
MOV #MSG121,R4 ;TYPE 'HARDWARE SWR IN USE'
TYPE
JSR PC,RESTORE ;RESTORE REGISTERS
2$: CMP #7,(SP) ;BRANCH IF NOT +G
BNE 4$
3$: MOV #SWREG,SWR ;INVOKE SOFTWARE SWR
JSR PC,GTSWR ;GET SWITCHES
4$: CMP #2,(SP) ;BRANCH IF NOT +B
BNE 6$
JSR PC,SAVE ;SAVE REGISTERS ON THE STACK
INC SCVFL ;SET FLAG
JSR PC,TINP3A ;GO CHECK CRC CORRECTION
BIT #40,@SWR ;BRANCH IF NOT YOZZLING
BEQ 5$
MOV #MSG44,R4 ;REQUEST NEW YOZZLE STALL
TYPE ;TYPE MSG
MOV YSTAL,R3
TYOCT ;PRINT PRESENT STALL
MOV #YSTAL,R5 ;SET ADDRESS OF YSTL
MOV #7,R1 ;SET NUMBER OF CHAR TO INPUT
MOV #-1,R2 ;SET MAXIMUM LIMIT
MOV #2000,R3 ;SET MINIMUM LIMIT
JSR PC,TTR ;GO GET VALUE
JSR PC,RESTORE ;RESTORE REGISTERS
TST (SP)+ ;POP CHARACTER OF THE STACK
MOV #YOZ,(SP) ;RETURN TO 'YOZ'
RTI ;RETURN TO YOZ
5$: JSR PC,RESTORE ;RESTORE REGISTERS
6$: TST (SP)+ ;POP CHARACTER OFF THE STACK
RTI ;RETURN

:MAG TAPE INTERRUPT HANDLER
MTINT: NOP
MTINTA: BIC #37,@MR ;CLEAR MAINT MODE
MOV RTRN,(SP) ;SET RETURN TO (RTRN)
RTI ;RETURN

```

```

4464
4465
4466
4467
4468
4469
4470
4471
4472
4473 021734 012704 026576
4474 021740 000004
4475 021742 012705 000744
4476 021746 012701 000002
4477 021752 012702 000001
4478 021756 012703 000000
4479 021762 004737 023340
4480 021766 005037 000740
4481 021772 004737 022110
4482 021776 012704 026527
4483 022002 000004
4484 022004 012704 026556
4485 022010 000004
4486 022012 013703 000740
4487 022016 104400
4488 022020 012704 026565
4489 022024 000004
4490 022026 012700 000746
4491 022032 005710
4492 022034 100403
4493 022036 012003
4494 022040 104400
4495 022042 000773
4496 022044 004737 022274
4497 022050 004737 022434
4498 022054 022737 000007 000740
4499 022062 001403
4500 022064 005237 000740
4501 022070 000740
4502 022072 005737 000744
4503 022076 001003
4504 022100 000137 005004
4505 022104 000000
4506 022106 000727

```

```

*****
;AUTO SEQUENCE
;THIS ROUTINE ,ENTERED VIA STARTING ADDRESS 240
;WILL EXERCISE ALL AVAILABLE SLAVES ON ALL AVAILABLE
;DRIVES IN BOTH PE AND NRZ ACCORDING TO THE PRESELECTED
;TEST PLAN. IF NRZ ONLY, PE TESTING WILL NOT BE ATTEMPTED.
*****
ASEQ:  MOV      #MSG104,R4
      TYPE
      MOV      #ASEQCF,R5      ;TYPE MSG
      MOV      #2,R1          ;SET ADDRESS OF ENTRY
      MOV      #1,R2          ;SET SIZE OF ENTRY
      MOV      #0,R3          ;SET UPPER LIMIT
      MOV      #0,R3          ;SET LOWER LIMIT
      JSR      PC,TTR         ;GO GET INPUT
ASEQ0: CLR      ADRVN         ;CLEAR DRV NUM
ASEQ1: JSR      PC,HRDS       ;GO SELECT HARDWARE CONFIGURATION
      MOV      #MSG101,R4
      TYPE
      MOV      #MSG102,R4      ;TYPE MSG
      TYPE
      MOV      ADRVN,R3        ;TYPE MSG
      TYPOCT
      MOV      #MSG103,R4
      TYPE
      MOV      #UN1,R0        ;TYPE MSG
      TST      (R0)           ;POINT TO START OF SLAVE TABLE
      BMI     ASEQ3          ;SEE IF END
      MOV      (R0)+,R3      ;IF S0: BR
      TYPOCT
      BR      ASEQ2          ;PRINT SLAVE TABLE
      JSR      PC,AMOD1       ;DO ALL
      JSR      PC,AMOD2       ;GO DO MODE 1(NRZ)
ASEQ4: CMP      #7,ADRVN     ;GO DO MODE 2(PE)
      BEQ     ASEQX          ;SEE IF DONE ALL DRIVES
      INC     ADRVN         ;IF S0: BR
      BR      ASEQ1         ;BUMP DRIVE NUMBER
ASEQX: TST      ASEQCF       ;CONTINUE
      BNE     ASEQXX        ;SEE IF CONTINUOUS AUTO SEQ
      JMP     TEND          ;IF S0: BR
ASEQXX: BR      ASEQ0

```

```

4507
4508 ;SUBROUTINE TO SELECT AUTO SEQUENCE HARDWARE*****
4509
4510 022110 005037 005054 HRDS: CLR REOTC ;CLEAR EOT UNIT CNTR
4511 022114 005037 000644 CLR TEMP1
4512 022120 012777 000040 156372 MOV #40,ACS ;INIT
4513 022126 013777 000740 156364 MOV ADRVN,ACS ;SET DRIVE
4514 022134 032777 010000 156356 BIT #10000,ACS ;TEST FOR NON-EXISTANT DRIVE
4515 022142 001403 BEQ 2$ ;IF DRIVE AVAIL: BR
4516 022144 005726 1$: TST (SP)+ ;RESET STACK POINTER
4517 022146 000137 022054 JMP ASEQ4 ;GO SEE IF TRIED ALL DRIVES
4518 022152 005000 2$: CLR RO
4519 022154 012701 000746 MOV #UN1,R1 ;SET START OF SLAVE TABLE
4520 022160 005737 003040 TST CHNFLG ;BRANCH IF NOT IN CHAIN MODE
4521 022164 001410 BEQ 3$
4522 022166 122737 000006 000041 CMPB #6,#41 ;BRANCH IF NOT LOADED VIA TMDP
4523 022174 001004 BNE 3$
4524 022176 005737 000740 TST ADRVN ;BRANCH IF NOT DRIVE 0
4525 022202 001001 BNE 3$
4526 022204 005200 INC RO ;DO NOT TEST SLAVE 0
4527 022206 010077 156330 3$: MOV RO,ATC ;SELECT SLAVE
4528 022212 032777 010000 156302 BIT #10000,ADS ;SEE IF SLAVE AVAIL FOR TEST(MOL)
4529 022220 001403 BEQ 4$ ;IF NOT: BR
4530 022222 005237 000644 INC TEMP1 ;SET SLAVE FOUND FLAG
4531 022226 010021 MOV RO,(R1)+ ;LOAD SLAVE TABLE
4532 022230 005200 4$: INC RO ;STEP TO NEXT SLAVE
4533 022232 022700 000010 CMP #10,RO ;BRANCH IF ALL SLAVE NOT DONE
4534 022236 001363 BNE 3$
4535 022240 005737 000644 5$: TST TEMP1 ;SEE IF FOUND ANY SLAVES
4536 022244 001737 BEQ 1$ ;IF NOT: BR
4537 022246 013737 000644 005054 MOV TEMP1,REOTC ;SET NUMBER OF UNITS
4538 022254 000337 000644 SWAB TEMP1
4539 022260 053737 000644 005054 BIS TEMP1,REOTC ;SET EOT CNTR
4540 022266 012711 177777 MOV #-1,(R1) ;TERMINATE SLAVE TABLE
4541 022272 000207 RTS PC ;RETURN TO SEQ

```

```

4542
4543
4544
4545 022274 005037 000656
4546 022300 012701 000746
4547 022304 052721 001700
4548 022310 022711 177777
4549 022314 001373
4550 022316 004737 005070
4551 022322 012737 000006 000742
4552 022330 012737 174000 000556
4553 022336 012737 000100 000554
4554 022344 013737 000740 000550
4555 022352 012737 000001 000560
4556 022360 005037 000564
4557 022364 005037 000570
4558 022370 004737 003346
4559 022374 012737 000010 000560
4560 022402 004737 003346
4561 022406 012737 000014 000560
4562 022414 004737 003346
4563 022420 012737 177777 000560
4564 022426 004737 003346
4565 022432 000207

;SUBROUTINE TO SELECT NRZ AUTO TEST MODE*****
AMOD1: CLR BLCNTR ;ASSURE BLOCK COUNTER IS 0
MOV #UN1,R1 ;GET START OF SLAVE TABLE
15: BIS #1700,(R1)+ ;SET ALL SLAVE TO NRZ,NORM,ODD
CMP #-1,(R1) ;LOOP UNTIL REACHED END OF TABLE
BNE IS
JSR PC,AVAIL ;GO REWIND ALL AVAIL SLAVES
MOV #6,ABLCNT ;SET NUMBER OF BLOCKS FOR MODE 1
MOV #-4000,FMCNT ;SET FC = 4000
MOV #100,RCNT ;SET REC CNTR = 100
MOV ADRVN,DVN ;SELECT DRIVE
MOV #1,PATRN ;SELECT PATTERN 1
CLR TMEX ;ASSURE NO TMK
CLR INTRF ;ASSURE NORMAL READ
JSR PC,STAUTO ;GO DO AUTO MODE 1
MOV #10,PATRN ;SELECT PATTERN 10
JSR PC,STAUTO ;GO DO PATTERN 10
MOV #14,PATRN ;SELECT PATTERN 14
JSR PC,STAUTO
35: MOV #-1,PATRN ;SELECT AUTO RANDOM DATA
JSR PC,STAUTO
RTS PC ;RETURN TO SEQ

```

```

4566
4567
4568
4569 022434 005037 000656
4570 022440 012701 000746
4571 022444 042711 001700
4572 022450 052721 002300
4573 022454 022711 177777
4574 022460 001371
4575 022462 004737 005070
4576 022466 012737 000006 000742
4577 022474 012737 174000 000556
4578 022502 012737 000100 000554
4579 022510 012737 000010 000560
4580 022516 004737 003346
4581 022522 012737 000014 000560
4582 022530 004737 003346
4583 022534 012737 000015 000560
4584 022542 004737 003346
4585 022546 012737 177777 000742
4586 022554 012737 177777 000560
4587 022562 004737 003346
4588 022566 000207
4589
4590

```

```

;SUBROUTINE TO SELECT PE AUTO TEST MODE*****
AMOD2: CLR BLCNTR ;CLEAR BLOCK CNTR
MOV #UN1,R1 ;SET START OF SLAVE TABLE
15: BIC #1700,(R1) ;CLEAR NRZ
BIS #2300,(R1)+ ;SET TO PE NORM, ODD
CMP #-1,(R1) ;LOOP UNTIL END OF TABLE
BNE 15
JSR PC,RUNDA ;REWIND ALL SLAVES
MOV #6,ABLCNT ;SET AUTO BLOCK COUNT
MOV #-4000,FMCNT ;SET FC = 4000
MOV #100,RCNT ;SET REC CNTR TO 100
MOV #10,PATRN ;SELECT PATTERN 10
JSR PC,STAUTO ;GO DO AUTO SEQ
MOV #14,PATRN ;SELECT PATTERN 14
JSR PC,STAUTO
MOV #15,PATRN ;SELECT PATTERN 15
JSR PC,STAUTO
MOV #-1,ABLCNT ;FORCE TO END OF TAPE
MOV #-1,PATRN ;SELECT AUTO RANDOM DATA
JSR PC,STAUTO
35: RTS ;RETURN TO SEQ

```

```

4591
4592
4593
4594
4595
4596
4597
4598
4599
4600
4601
4602
4603
4604
4605
4606
4607 022570 012704 024546
4608 022574 000004
4609 022576 013703 000550
4610 022602 104400
4611 022604 012704 024532
4612 022610 000004
4613 022612 013703 000552
4614 022616 042703 177770
4615 022622 104400
4616 022624 012704 026105
4617 022630 000004
4618 022632 013703 000552
4619 022636 000303
4620 022640 042703 177770
4621 022644 104400
4622 022646 012704 026111
4623 022652 000004
4624 022654 005003
4625 022656 032737 000010 000552
4626 022664 001402
4627 022666 012703 000001
4628 022672 104400
4629 022674 012704 026115
4630 022700 000004
4631 022702 013703 000552
4632 022706 000241
4633 022710 006003
4634 022712 006003
4635 022714 006003
4636 022716 006003
4637 022720 042703 177760
4638 022724 104400
4639 022726 012704 024507
4640 022732 000004
4641 022734 032777 000400 155646
4642 022742 001406
4643 022744 012737 000122 000640
4644 022752 004737 023744
4645 022756 000411
4646 022760 005737 000736

```

```

*****
:ERROR HEADER PRINT SUBROUTINE:
:
:THIS ROUTINE IS USED TO PRINT OUT A HEADER
:WITH EACH ERROR MESSAGE. THE PRINT IS IN TWO
: LINES AND CONTAINS THE FOLLOWING INFORMATION.
:LINE 1: DRIVE NO. SLAVE NO. DENSITY PARITY FORMAT
:LINE 2: CURRENT BLOCK NUMBER, RECORD NUMBER IN
: WHICH THE ERROR OCCURED PLUS THE TOTAL NUMBER
: OF RECORDS IN THIS BLOCK, THE RECORD SIZE (NUMBER
: OF CHARACTERS), AND THE ERROR TYPE (READ WRITE, SPACE, ETC)
: PLUS THE TAPE DIRECTION (FORWARD OR REVERSE).
: ALL NUMBERS ARE IN OCTAL.
*****
PAPRT:  MOV    #MSG12,R4
        TYPE   ;TYPE MSG
        MOV    DVN,R3
        TYPOCT ;PRINT DRIVE NUMBER
        MOV    #MSG11,R4
        TYPE   ;TYPE MSG
        MOV    UDES,R3
        BIC    #177770,R3
        TYPOCT ;PRINT UNIT NUMBER
        MOV    #MSG60,R4
        TYPE   ;TYPE MSG
        MOV    UDES,R3
        SWAB   R3
        BIC    #177770,R3
        TYPOCT ;PRINT DENSITY
        MOV    #MSG61,R4
        TYPE   ;TYPE MSG
        CLR    R3
        BIT    #10,UDES
        BEQ    PAPRT0
        MOV    #1,R3
        PAPRT0:  TYPOCT ;PRINT PARITY
        MOV    #MSG62,R4
        TYPE   ;TYPE MSG
        MOV    UDES,R3
        CLC
        ROR    R3
        ROR    R3
        ROR    R3
        ROR    R3
        BIC    #177760,R3
        TYPOCT ;PRINT FORMAT
        MOV    #MSG8,R4
        TYPE   ;TYPE MSG
        BIT    #400,JSWR
        BEQ    PAPRTB
        PAPRTA:  MOV    #122,T08
        JSR    PC,T08
        BR     PAPRTD
        PAPRTB:  TST    ASEQF
                ;SEE IF AUTO SEQ

```



```

4685
4686
4687
4688
4689
4690
4691
4692
4693
4694 023152 063737 000630 000626 RANG: ADD RANSV,RANBS
4695 023160 063737 000626 000630 ADD RANBS,RANSV ;GET NEW NUMBER
4696 023166 023701 000630 CMP RANSV,R1 ;SEE IF NUMBER TOO BIG
4697 023172 101367 BHI RANG ;IF SO: BR
4698 023174 020237 000630 CMP R2,RANSV ;SEE IF NUMBER TOO SMALL
4699 023200 101364 BHI RANG ;IF SO: BR
4700 023202 000207 RTS PC ;EXIT
4701
4702 ;SUBROUTINE TO GET NEW SOFTWARE SWR
4703
4704 023204 022737 000176 000610 GTSWR: CMP #SWREG,SWR ;BRANCH IF SOFTWARE SWR
4705 023212 001027 BNE IS ;NOT INVOKED
4706 023214 004737 023274 JSR PC,SAVE ;SAVE REGISTERS ON THE STACK
4707 023220 012704 024424 MOV #SHSWR,R4 ;TYPE 'SWR = '
4708 023224 000004 TYPE ;TYPE MSG
4709 023226 017703 155356 MOV #SWR,R3 ;GET CURRENT SWR
4710 023232 104400 TYPOCT
4711 023234 012704 024434 MOV #SHNEW,R4 ;ASK FOR NEW SETTING
4712 023240 000004 TYPE ;TYPE MSG
4713 023242 013705 000610 MOV SWR,R5 ;TTR ROUTINE RETURNS VALUE TO (R5)
4714 023246 012701 000007 MOV #7,R1 ;LIMIT RESPONSE TO 7 CHARS
4715 023252 012702 177777 MOV #177777,R2 ;BETWEEN 0 AND 177777
4716 023256 012703 000000 MOV #0,R3
4717 023262 004737 023340 JSR PC,TTR ;GET RESPONSE
4718 023266 004737 023316 JSR PC,.RESTORE ;RESTORE REGISTERS
4719 023272 000207 IS: RTS PC ;RETURN
4720
4721 ;:ROUTINE TO SAVE REGISTERS ON THE STACK
4722 023274 010546 .SAVE: MOV %5,-(SP) ;;R5 IS SAVED AT 12(SP)
4723 023276 010446 MOV %4,-(SP) ;;R4 IS SAVED AT 10(SP)
4724 023300 010346 MOV %3,-(SP) ;;R3 IS SAVED AT 6(SP)
4725 023302 010246 MOV %2,-(SP) ;;R2 IS SAVED AT 4(SP)
4726 023304 010146 MOV %1,-(SP) ;;R1 IS SAVED AT 2(SP)
4727 023306 010046 MOV %0,-(SP) ;;R0 IS SAVED AT (SP)
4728 023310 016646 000014 MOV 14(SP),-(SP) ;;PUSH RETURN PC ON THE STACK
4729 023314 000207 RTS PC ;;RETURN TO CALLER
4730
4731 ;:ROUTINE TO RESTORE REGISTERS SAVED ON THE STACK
4732 023316 012666 000014 .RESTORE:MOV (SP)+,14(SP) ;;STORE RETURN PC ON STACK
4733 023322 012600 MOV (SP)+,%0
4734 023324 012601 MOV (SP)+,%1
4735 023326 012602 MOV (SP)+,%2
4736 023330 012603 MOV (SP)+,%3
4737 023332 012604 MOV (SP)+,%4
4738 023334 012605 MOV (SP)+,%5
4739 023336 000207 RTS PC ;;RETURN
4740

```

```

4741 :*****
4742 :TTY ENTRY SUBROUTINE:
4743 :
4744 :THIS SUBROUTINE IS USED BY THE TEST CONDITION
4745 :ENTRY ROUTINE TO READ THE RESPONSE ENTERED
4746 :AT THE TTY AND CHECK THEM FOR LEGALITY AND
4747 :LIMITS. ALL RESPONSE MUST BE TYPED IN OCTAL
4748 :(0-7) AND MUST FALL WITHIN THE LIMITS SET BY
4749 :THE CALLING ROUTINE.
4750 :IF AN ENTRY IS ILLEGAL OR OUTSIDE THE LIMITS,
4751 :A QUESTION MARK IS TYPED (?) AND THE RESPONSE
4752 :MAY BE REENTERED.
4753 :ENTRIES MAY NOT EXCEED SIX (6) CHARACTERS AND
4754 :MAY BE TERMINATED AT LESS THAN SIX BY TYPING A
4755 :CARRIAGE RETURN
4756 :*****
4757
4758 023340 010146 TTR: MOV R1, -(SP) ;SAVE CHAR COUNT
4759 023342 011601 10S: MOV (SP), R1 ;RESTORE CHAR COUNT (FOR ↑U)
4760 023344 005037 000644 CLR TEMP1 ;CLEAR FIRST CHARACTER FLAG
4761 023350 005000 CLR RO
4762 023352 004737 023572 1S: JSR PC, TTIN ;GO READ CHARACTER
4763 023356 122737 000003 000642 CMPB #3, TIB ;BRANCH IF NOT ↑C
4764 023364 001003 BNE 11$
4765 023366 000005 RESET
4766 023370 000137 000200 JMP #200 ;RESTART AT 200
4767 023374 122737 000015 000642 11S: CMPB #15, TIB ;SEE IF CR
4768 023402 001004 BNE 2$ ;IF NOT: BR
4769 023404 005737 000644 TST TEMP1 ;SEE IF FIRST CHARACTER
4770 023410 001457 BEQ 9$ ;IF SO: BR
4771 023412 000451 BR 6$ ;ELSE GO LOAD VALUE
4772 023414 122737 000025 000642 2S: CMPB #25, TIB ;BRANCH IF NOT CONTROL U
4773 023422 001004 BNE 21$
4774 023424 012704 025117 MOV #MSG28, R4 ;TYPE <CR><LF>
4775 023430 000004 TYPE ;TYPE MSG
4776 023432 000743 BR 10$
4777 023434 122737 000177 000642 21S: CMPB #177, TIB ;BRANCH IF NOT 'RUBOUT'
4778 023442 001011 BNE 3$
4779 023444 000241 CLC ;REMOVE LAST CHARACTER
4780 023446 006000 ROR RO
4781 023450 006200 ASR RO
4782 023452 006200 ASR RO
4783 023454 012704 027230 MOV #MSG118, R4 ;TYPE '\ '
4784 023460 000004 TYPE ;TYPE MSG
4785 023462 005201 INC R1 ;DEC CHAR RECEIVED COUNT
4786 023464 000732 BR 1$ ;GET NEXT CHARACTER
4787 023466 122737 000060 000642 3S: CMPB #60, TIB ;SEE IF CHAR IS LESS THAN 0
4788 023474 101027 BHI TINER
4789 023476 122737 000070 000642 4S: CMPB #70, TIB ;SEE IF CHAR IS GREATER THAN 7
4790 023504 101423 BLOS TINER
4791 023506 005237 000644 5S: INC TEMP1 ;SET FIRST CHARACTER FLAG
4792 023512 006300 ASL RO
4793 023514 006300 ASL RO ;SHIFT 3 LEFT
4794 023516 006300 ASL RO
4795 023520 042737 177770 000642 BIC #177770, TIB ;STRIP ASCII
4796 023526 053700 000642 BIS TIB, RO ;LOAD CHARACTER

```

| | | | |
|------|--------|--------|--------|
| 4797 | 023532 | 005301 | |
| 4798 | 023534 | 001306 | |
| 4799 | 023536 | 020002 | |
| 4800 | 023540 | 101005 | |
| 4801 | 023542 | 020300 | |
| 4802 | 023544 | 101003 | |
| 4803 | 023546 | 010015 | |
| 4804 | 023550 | 005726 | |
| 4805 | 023552 | 000207 | |
| 4806 | | | |
| 4807 | 023554 | 012704 | 025617 |
| 4808 | 023560 | 000004 | |
| 4809 | 023562 | 005726 | |
| 4810 | 023564 | 162716 | 000020 |
| 4811 | 023570 | 000207 | |

| | | | |
|--------|------|------------|--------------------------------------|
| | DEC | R1 | : SEE IE DONE |
| | BNE | IS | : IF NOT: BR |
| 6S: | CMP | RO, R2 | : SEE IF EXCEEDED MAXIMUM LIMIT |
| | BHI | TINER | |
| 7S: | CMP | R3, RO | : SEE IF BELOW MINIMUM LIMIT |
| | BHI | TINER | |
| 8S: | MOV | RO, (RS) | : LOAD VALUE |
| 9S: | TST | (SP)+ | : POP CHAR COUNT OFF STACK |
| | RTS | PC | : EXIT |
| TINER: | MOV | #MSG43, R4 | |
| | TYPE | | : TYPE MSG |
| | TST | (SP)+ | : POP CHAR COUNT OFF STACK |
| | SUB | #20, (SP) | : RESET SP TO START OF VALUE ROUTINE |
| | RTS | PC | : REDO VALUE ENTRY |

```

4812
4813
4814
4815 023572 005277 155014
4816 023576 105777 155010
4817 023602 100375
4818 023604 017737 155004 000642
4819 023612 042737 000200 000642
4820 023620 013737 000642 000640
4821 023626 004737 023744
4822 023632 000207
4823
4824
4825
4826 023634 112437 000640
4827 023640 105737 000640
4828 023644 001436
4829 023646 122737 000045 000640
4830 023654 001407
4831 023656 122737 000041 000640
4832 023664 001436
4833 023666 004737 023744
4834 023672 000760
4835 023674 112737 000015 000640
4836 023702 001737 023744
4837 023706 012703 000006
4838 023712 005037 000640
4839 023716 004737 023744
4840 023722 005303
4841 023724 001372
4842 023726 112737 000012 000640
4843 023734 004737 023744
4844 023740 000735
4845 023742 000002
4846
4847 023744 105777 154646
4848 023750 100375
4849 023752 113777 000640 154640
4850 023760 000207
4851
4852 023762 012703 000002
4853 023766 012737 000007 000640
4854 023774 004737 023744
4855 024000 005303
4856 024002 001371
4857 024004 000713
4858
4859

```

; TTY READ SUBROUTINE*****

```

TTIN: INC @TKS
1S: TSTB @TKS
BPL 1S
MOV @TKB, TIB
BIC #200, TIB
MOV TIB, TOB
JSR PC, TOG
RTS PC
; STRIP PARITY BIT
; MOVE CHAR TO TTY OUTPUT BFR
; ECHO CHARACTER

```

; TTY OUTPUT SUBROUTINE*****

```

TTOUT: MOVB (R4)+, TOB
TSTB TOB
BEQ 3S
CMPB #45, TOB
BEQ 1S
CMPB #41, TOB
BEQ TBELL
JSR PC, TOG
BR TTOUT
1S: MOVB #15, TOB
JSR PC, TOG
MOV #6, R3
2S: CLR TOB
JSR PC, TOG
DEC R3
BNE 2S
MOVB #12, TOB
JSR PC, TOG
BR TTOUT
3S: RTI
; DO BELL
; DO FILLERS
; RETURN
TOG: TSTB @TPS
BPL TOG
MOVB TOB, @TPB
RTS PC
; RETURN
TBELL: MOV #2, R3
1S: MOV #7, TOB
JSR PC, TOG
DEC R3
BNE 1S
BR TTOUT

```

```

;OCTAL OUTPUT SUBROUTINE*****
4860
4861
4862 024006 005037 024220 OCTP: CLR OFL ;CLEAR FLAG FOR LEADING ZERO
4863 024012 010304 MOV R3,R4 ;SEE IF NUMBER IS ZERO
4864 024014 001003 BNE OCTP0 ;IF NOT ZERO: BR
4865 024016 004737 024200 JSR PC,OCTPG1 ;ELSE PRINT ZERO
4866 024022 000447 BR OCTP3 ;SPACE AND EXIT
4867 024024 005704 OCTP0: TST R4 ;BRANCH IF MSD = 0
4868 024026 100006 BPL OCTP1
4869 024030 012704 000001 MOV #1,R4
4870 024034 004737 024156 JSR PC,OCTPG ;PRINT 1
4871 024040 000137 024052 JMP OCTP2
4872 024044 005004 OCTP1: CLR R4 ;PRINT 0
4873 024046 004737 024156 JSR PC,OCTPG
4874 024052 010304 OCTP2: MOV R3,R4
4875 024054 006004 ROR R4
4876 024056 006004 ROR R4
4877 024060 006004 ROR R4 ;POSITION DIGIT
4878 024062 006004 ROR R4
4879 024064 000304 SWAB R4
4880 024066 004737 024156 JSR PC,OCTPG ;PRINT DIGIT 2
4881 024072 010304 MOV R3,R4
4882 024074 006004 ROR R4
4883 024076 000304 SWAB R4
4884 024100 004737 024156 JSR PC,OCTPG ;PRINT DIGIT 3
4885 024104 010304 MOV R3,R4
4886 024106 006104 ROL R4
4887 024110 006104 ROL R4
4888 024112 000304 SWAB R4
4889 024114 004737 024156 JSR PC,OCTPG ;PRINT DIGIT 4
4890 024120 010304 MOV R3,R4
4891 024122 006004 ROR R4
4892 024124 006004 ROR R4
4893 024126 006004 ROR R4
4894 024130 004737 024156 JSR PC,OCTPG
4895 024134 010304 MOV R3,R4
4896 024136 004737 024156 JSR PC,OCTPG ;PRINT DIGIT 5
4897 024142 012737 000240 000640 OCTP3: MOV #240,TOB
4898 024150 004737 023744 JSR PC,TOB ;PRINT SPACE
4899 024154 000002 RTI ;EXIT
4900 024156 042704 177770 OCTPG: BIC #177770,R4
4901 024162 001004 BNE OCTPG0
4902 024164 005737 024220 TST OFL
4903 024170 001001 BNE OCTPG0
4904 024172 000207 RTS PC
4905
4906 024174 005237 024220 OCTPG0: INC OFL
4907 024200 052704 000260 OCTPG1: BIS #260,R4
4908 024204 010437 000640 MOV R4,TOB
4909 024210 004737 023744 JSR PC,TOB
4910 024214 010304 MOV R3,R4
4911 024216 000207 RTS PC
4912 024220 000000 OFL: 0 ;FIRST CHAR FLAG
4913

```

```

4914
4915
4916
4917 024222 012704 000010
4918 024226 110337 000640
4919 024232 105777 154360
4920 024236 100375
4921 024240 105737 000640
4922 024244 100004
4923 024246 012777 000061 154344
4924 024254 000403
4925 024256 012777 000060 154334
4926 024264 006337 000640
4927 024270 005304
4928 024272 001357
4929 024274 000207
4930
4931 024276 013703 000650
4932 024302 000303
4933 024304 004737 024222
4934 024310 013703 000650
4935 024314 004737 024222
4936 024320 000207
4937
4938
4939
4940 024322 010304
4941 024324 000304
4942 024326 006004
4943 024330 006004
4944 024332 006004
4945 024334 006004
4946 024336 004737 024400
4947 024342 010304
4948 024344 000304
4949 024346 004737 024400
4950 024352 010304
4951 024354 006004
4952 024356 006004
4953 024360 006004
4954 024362 006004
4955 024364 004737 024400
4956 024370 010304
4957 024372 004737 024400
4958 024376 000207
4959 024400 012737 000260 000640
4960 024406 042704 177760
4961 024412 050437 000640
4962 024416 004737 023744
4963 024422 000207
4964

;DATA CHARACTER OUTPUT SUBROUTINE*****
DOUT: MOV #10,R4 ;SET NUMBER TO PRINT
MOVVB R3,TOB
1$: TSTB #TPS
BPL 1$
TSTB TOB
BPL 2$
MOV #061,#TPB
BR 3$
2$: MOV #060,#TPB
3$: ASL TOB
DEC R4
BNE 1$
RTS PC

DOUTD: MOV TEMP3,R3
SWAB R3
JSR PC,DOUT
MOV TEMP3,R3
JSR PC,DOUT
RTS PC

;TU16 SERIAL NUMBER PRINT SUBROUTINE*****
SNPT: MOV R3,R4
SWAB R4
ROR R4
ROR R4
ROR R4
ROR R4
ROR R4
JSR PC,SNPG ;PRINT FIRST DIGIT
MOV R3,R4
SWAB R4
JSR PC,SNPG ;PRINT SECOND DIGIT
MOV R3,R4
ROR R4
ROR R4
ROR R4
ROR R4
JSR PC,SNPG ;PRINT THIRD DIGIT
MOV R3,R4
JSR PC,SNPG ;PRINT FOURTH DIGIT
RTS PC ;EXIT
MOV #260,TOB ;SET NUMBER BASE
BIC #177760,R4 ;MASK NUMBER
BIS R4,TOB ;BUILD DIGIT
JSR PC,TOG ;GO TYPE
RTS PC ;RETURN
    
```

```

4965
4966 ;ERROR MESSAGES*****
4967
4968 024424 051445 051127 036440 SMSWR: .ASCIZ /%SMR = /
4969 024432 000040
4970 024434 047040 093505 036440 SMNEW: .ASCIZ / NEW = /
4971 024442 000040
4972 024444 042052 020105 000 MSG1: .ASCIZ /%DE /
4973 024451 045 035507 000040 MSG2: .ASCIZ /%G; /
4974 024456 041045 020073 000 MSG3: .ASCIZ /%B; /
4975 024463 045 047103 000040 MSG4: .ASCIZ /%CN /
4976 024470 053452 020105 000 MSG5: .ASCIZ /%WE /
4977 024475 052 042522 000040 MSG6: .ASCIZ /%RE /
4978 024502 051052 020123 000 MSG7: .ASCIZ /%RS /
4979 024507 052 040520 051124 MSG8: .ASCIZ /%PATRN /
4980 024514 020116 000
4981 024517 045 047123 020072 MSG9: .ASCIZ /%SN: /
4982 024524 000
4983 024525 052 042523 000040 MSG10: .ASCIZ /%SE /
4984 024532 051452 040514 042526 MSG11: .ASCIZ /%SLAVE NO. /
4985 024540 047040 027117 000040
4986 024546 022445 042045 044522 MSG12: .ASCIZ /%X%DRIVE NO. /
4987 024554 042526 047040 027117
4988 024562 000040
4989 024564 025045 047102 000040 MSG13: .ASCIZ /%*BN /
4990 024572 051052 020116 000 MSG14: .ASCIZ /%*RN /
4991 024577 045 020041 020040 MSG15: .ASCIZ /%! BAD RECORD%%/
4992 024604 020040 020040 020040
4993 024612 041040 042101 051040
4994 024620 041505 051117 022504
4995 024626 000045
4996 024630 043040 000 MSG16: .ASCIZ / F/
4997 024633 040 000122 MSG17: .ASCIZ / R/
4998 024636 020041 047505 020124 MSG20: .ASCIZ /! EOT NO: /
4999 024644 047516 020072 000
5000
5001 024651 045 047111 042524 MSG21: .ASCIZ /%INTERCHANGE READ = /
5002 024656 041522 040510 043516
5003 024664 020105 042522 042101
5004 024672 036440 000040
5005 024676 020445 046111 042514 MSG22: .ASCIZ /%!ILLEGAL BOT: HALT%%%/
5006 024704 040507 020114 047502
5007 024712 035124 044040 046101
5008 024720 022524 022445 000
5009 024725 045 051503 020061 MSG23: .ASCIZ /%CS1 /
5010 024732 000
5011 024733 045 041527 000040 MSG23A: .ASCIZ /%MC /
5012 024740 041045 020101 000 MSG23B: .ASCIZ /%BA /
5013 024745 045 041506 000040 MSG23C: .ASCIZ /%FC /
5014 024752 041445 031123 000040 MSG23D: .ASCIZ /%CS2 /
5015 024760 042045 020123 000 MSG23E: .ASCIZ /%DS /
5016 024765 045 051105 000040 MSG23F: .ASCIZ /%ER /
5017 024772 040445 020123 000 MSG23G: .ASCIZ /%AS /
5018 024777 045 045503 000040 MSG23H: .ASCIZ /%CK /
5019 025004 042045 020102 000 MSG23I: .ASCIZ /%DB /
5020 025011 045 051115 000040 MSG23J: .ASCIZ /%MR /

```

| | | | | |
|------|--------|--------|--------|--------|
| 5021 | 025016 | 042045 | 020124 | 000 |
| 5022 | 025023 | 045 | 041524 | 000040 |
| 5023 | 025030 | 051445 | 020116 | 000 |
| 5024 | 025035 | 045 | 047041 | 020117 |
| 5025 | 025042 | 047111 | 042524 | 051122 |
| 5026 | 025050 | 050125 | 022524 | 000 |
| 5027 | 025055 | 045 | 047041 | 020117 |
| 5028 | 025062 | 047515 | 035114 | 044040 |
| 5029 | 025070 | 046101 | 022524 | 000 |
| 5030 | 025075 | 045 | 051104 | 050117 |
| 5031 | 025102 | 035123 | 000040 | |
| 5032 | 025106 | 050045 | 041511 | 051513 |
| 5033 | 025114 | 020072 | 000 | |
| 5034 | 025117 | 045 | 000 | |
| 5035 | 025121 | 045 | 052045 | 030505 |
| 5036 | 025126 | 020066 | 052501 | 047524 |
| 5037 | 025134 | 051440 | 050505 | 042525 |
| 5038 | 025142 | 041516 | 020105 | 042050 |
| 5039 | 025150 | 052132 | 042105 | 040455 |
| 5040 | 025156 | 022451 | 000 | |
| 5041 | 025161 | 045 | 052045 | 030115 |
| 5042 | 025166 | 026463 | 042524 | 033061 |
| 5043 | 025174 | 042040 | 052101 | 020101 |
| 5044 | 025202 | 042522 | 044514 | 041101 |
| 5045 | 025210 | 046111 | 052111 | 020131 |
| 5046 | 025216 | 042524 | 052123 | 024040 |
| 5047 | 025224 | 055104 | 042524 | 026504 |
| 5048 | 025232 | 024501 | 000045 | |
| 5049 | 025236 | 054524 | 042520 | 036040 |
| 5050 | 025244 | 051103 | 020076 | 047524 |
| 5051 | 025252 | 052040 | 051105 | 044515 |
| 5052 | 025260 | 040516 | 042524 | 040440 |
| 5053 | 025266 | 046114 | 051040 | 050505 |
| 5054 | 025274 | 042525 | 052123 | 020123 |
| 5055 | 025302 | 020046 | 041536 | 052040 |
| 5056 | 025310 | 020117 | 042522 | 052123 |
| 5057 | 025316 | 051101 | 022524 | 000 |
| 5058 | 025323 | 045 | 046123 | 053101 |
| 5059 | 025330 | 020105 | 052516 | 041115 |
| 5060 | 025336 | 051105 | 036440 | 000040 |
| 5061 | 025344 | 042045 | 047105 | 044523 |
| 5062 | 025352 | 054524 | 036440 | 000040 |
| 5063 | 025360 | 050045 | 051101 | 052111 |
| 5064 | 025366 | 020131 | 020075 | 000 |
| 5065 | 025373 | 045 | 042522 | 047503 |
| 5066 | 025400 | 042122 | 041440 | 052517 |
| 5067 | 025406 | 052116 | 036440 | 000040 |
| 5068 | 025414 | 041445 | 040510 | 020122 |
| 5069 | 025422 | 047503 | 047125 | 020124 |
| 5070 | 025430 | 020075 | 000 | |
| 5071 | 025433 | 045 | 040520 | 052124 |
| 5072 | 025440 | 051105 | 020116 | 052516 |
| 5073 | 025446 | 041115 | 051105 | 036440 |
| 5074 | 025454 | 000040 | | |
| 5075 | 025456 | 051445 | 047111 | 046107 |
| 5076 | 025464 | 020105 | 040520 | 051523 |

MSG23K: .ASCIZ /%DT /
 MSG23L: .ASCIZ /%TC /
 MSG23M: .ASCIZ /%SN /
 MSG24: .ASCIZ /%!NO INTERRUPT%/

MSG25: .ASCIZ /%!NO MOL: HALT%/

MSG26: .ASCIZ /%DROPS: /
 MSG27: .ASCIZ /%PICKS: /

MSG28: .ASCIZ /%/

MSG30: .ASCIZ /%XTE16 AUTO SEQUENCE (DZTED-A)%/

MSG31: .ASCIZ /%XTM03-TE16 DATA RELIABILITY TEST (DZTED-A)%/

MSG31A: .ASCIZ /TYPE <CR> TO TERMINATE ALL REQUESTS & ↑C TO RESTART%/

MSG32: .ASCIZ /%SLAVE NUMBER = /

MSG33: .ASCIZ /%DENSITY = /

MSG34: .ASCIZ /%PARITY = /

MSG35: .ASCIZ /%RECORD COUNT = /

MSG36: .ASCIZ /%CHAR COUNT = /

MSG37: .ASCIZ /%PATTERN NUMBER = /

MSG38: .ASCIZ /%SINGLE PASS = /

| | | | | | |
|------|--------|--------|--------|--------|---|
| 5077 | 025472 | 036440 | 000040 | | |
| 5078 | 025476 | 041445 | 041522 | 041440 | MSG39: .ASCIZ /%CRC CORRECTION (YES=1,NO=0) = / |
| 5079 | 025504 | 051117 | 042522 | 052103 | |
| 5080 | 025512 | 047511 | 020116 | 054450 | |
| 5081 | 025520 | 051505 | 030475 | 047054 | |
| 5082 | 025526 | 036517 | 024460 | 036440 | |
| 5083 | 025534 | 000040 | | | |
| 5084 | 025536 | 022445 | 047105 | 042524 | MSG40: .ASCIZ /%ENTER STALLS%READ = / |
| 5085 | 025544 | 020122 | 052123 | 046101 | |
| 5086 | 025552 | 051514 | 051045 | 040505 | |
| 5087 | 025560 | 020104 | 020075 | 000 | |
| 5088 | 025565 | 045 | 051127 | 052111 | MSG41: .ASCIZ /%WRITE = / |
| 5089 | 025572 | 020105 | 020075 | 000 | |
| 5090 | | | | | |
| 5091 | 025577 | 045 | 052524 | 047122 | MSG42: .ASCIZ /%TURN AROUND = / |
| 5092 | 025604 | 040440 | 047522 | 047125 | |
| 5093 | 025612 | 020104 | 020075 | 000 | |
| 5094 | 025617 | 045 | 022477 | 000 | MSG43: .ASCIZ /%?%/ |
| 5095 | 025623 | 045 | 047105 | 042524 | MSG44: .ASCIZ /%ENTER YOZZLE STALL = / |
| 5096 | 025630 | 020122 | 047531 | 055132 | |
| 5097 | 025636 | 042514 | 051440 | 040524 | |
| 5098 | 025644 | 046114 | 036440 | 000040 | |
| 5099 | 025652 | 042445 | 051122 | 040440 | MSG45: .ASCIZ /%ERR AMT / |
| 5100 | 025660 | 052115 | 000040 | | |
| 5101 | 025664 | 043045 | 020103 | 000 | MSG46: .ASCIZ /%FC / |
| 5102 | 025671 | 045 | 040503 | 000040 | MSG47: .ASCIZ /%CA / |
| 5103 | 025676 | 020445 | 047516 | 041040 | MSG48: .ASCIZ /%!NO BOT ON REWIND: HALT%/ |
| 5104 | 025704 | 052117 | 047440 | 020116 | |
| 5105 | 025712 | 042522 | 044527 | 042116 | |
| 5106 | 025720 | 020072 | 040510 | 052114 | |
| 5107 | 025726 | 022445 | 000 | | |
| 5108 | 025731 | 045 | 047516 | 020124 | MSG49: .ASCIZ /%NOT AVAIL / |
| 5109 | 025736 | 053101 | 044501 | 020114 | |
| 5110 | 025744 | 000 | | | |
| 5111 | 025745 | 045 | 046111 | 042514 | MSG50: .ASCIZ /%ILLEGAL DRIVE TYPE / |
| 5112 | 025752 | 040507 | 020114 | 051104 | |
| 5113 | 025760 | 053111 | 020105 | 054524 | |
| 5114 | 025766 | 042520 | 000040 | | |
| 5115 | 025772 | 042045 | 044522 | 042526 | MSG52: .ASCIZ /%DRIVE NUMBER = / |
| 5116 | 026000 | 047040 | 046525 | 042502 | |
| 5117 | 026006 | 020122 | 020075 | 000 | |
| 5118 | 026013 | 045 | 047506 | 046522 | MSG53: .ASCIZ /%FORMAT = / |
| 5119 | 026020 | 052101 | 036440 | 000040 | |
| 5120 | 026026 | 053452 | 020105 | 046524 | MSG54: .ASCIZ /*WE TM/ |
| 5121 | 026034 | 000 | | | |
| 5122 | 026035 | 052 | 042523 | 052040 | MSG55: .ASCIZ /*SE TM/ |
| 5123 | 026042 | 000115 | | | |
| 5124 | 026044 | 052040 | 000115 | | MSG56: .ASCIZ / TM/ |
| 5125 | 026050 | 047045 | 047117 | 042455 | MSG57: .ASCIZ /%NON-EXIST SLAVE/ |
| 5126 | 026056 | 044530 | 052123 | 051440 | |
| 5127 | 026064 | 040514 | 042526 | 000 | |
| 5128 | 026071 | 045 | 051103 | 020103 | MSG58: .ASCIZ /%CRC / |
| 5129 | 026076 | 000 | | | |
| 5130 | 026077 | 045 | 051114 | 020103 | MSG59: .ASCIZ /%LRC / |
| 5131 | 026104 | 000 | | | |
| 5132 | 026105 | 052 | 020104 | 000 | MSG60: .ASCIZ /*D / |

| | | | | | | | |
|------|--------|--------|--------|--------|---------|--------|-----------------------------------|
| 5133 | 026111 | 052 | 020120 | 000 | MSG61: | .ASCIZ | /*P / |
| 5134 | 026115 | 052 | 020106 | 000 | MSG62: | .ASCIZ | /*F / |
| 5135 | 026121 | 045 | 047452 | 044522 | MSG64: | .ASCIZ | /*ORIGINAL ERROR*/ |
| 5136 | 026126 | 044507 | 040516 | 020114 | | | |
| 5137 | 026134 | 051105 | 047522 | 025122 | | | |
| 5138 | 026142 | 000 | | | | | |
| 5139 | 026143 | 045 | 042522 | 051124 | MSG65: | .ASCIZ | /*RETRY: / |
| 5140 | 026150 | 035131 | 000040 | | | | |
| 5141 | 026154 | 020452 | 042523 | 051040 | MSG66: | .ASCIZ | /*SE RTRY / |
| 5142 | 026162 | 051124 | 020131 | 000 | | | |
| 5143 | 026167 | 052 | 042441 | 040522 | MSG67: | .ASCIZ | /*ERASE/ |
| 5144 | 026174 | 042523 | 000 | | | | |
| 5145 | 026177 | 045 | 042522 | 042522 | MSG68: | .ASCIZ | /*REREV: / |
| 5146 | 026204 | 035126 | 000040 | | | | |
| 5147 | 026210 | 052045 | 050101 | 020105 | MSG69: | .ASCIZ | /*TAPE MARK = / |
| 5148 | 026216 | 040515 | 045522 | 036440 | | | |
| 5149 | 026224 | 000040 | | | | | |
| 5150 | 026226 | 020445 | 047516 | 042040 | MSG70: | .ASCIZ | /*NO DRY FROM REWIND: HALT*/ |
| 5151 | 026234 | 054522 | 043040 | 047522 | | | |
| 5152 | 026242 | 020115 | 042522 | 044527 | | | |
| 5153 | 026250 | 042116 | 020072 | 040510 | | | |
| 5154 | 026256 | 052114 | 000045 | | | | |
| 5155 | 026262 | 047045 | 047117 | 042455 | MSG71: | .ASCIZ | /*NON-EXIST DRIVE/ |
| 5156 | 026270 | 044530 | 052123 | 042040 | | | |
| 5157 | 026276 | 044522 | 042526 | 000 | | | |
| 5158 | 026303 | 045 | 042522 | 053506 | MSG72: | .ASCIZ | /*REFWD: / |
| 5159 | 026310 | 035104 | 000040 | | | | |
| 5160 | 026314 | 053445 | 042524 | 051122 | MSG73: | .ASCIZ | /*WTERR: / |
| 5161 | 026322 | 020072 | 000 | | | | |
| 5162 | 026325 | 045 | 042522 | 044507 | MSG74: | .ASCIZ | /*REGISTER START = / |
| 5163 | 026332 | 052123 | 051105 | 051440 | | | |
| 5164 | 026340 | 040524 | 052122 | 036440 | | | |
| 5165 | 026346 | 000040 | | | | | |
| 5166 | 026350 | 053045 | 041505 | 047524 | MSG75: | .ASCIZ | /*VECTOR = / |
| 5167 | 026356 | 020122 | 020075 | 000 | | | |
| 5168 | 026363 | 045 | 042504 | 042522 | MSG76: | .ASCIZ | /*DEREV: / |
| 5169 | 026370 | 035126 | 000040 | | | | |
| 5170 | 026374 | 042045 | 043105 | 042127 | MSG77: | .ASCIZ | /*DEFWD: / |
| 5171 | 026402 | 020072 | 000 | | | | |
| 5172 | 026405 | 045 | 047041 | 047117 | MSG78: | .ASCIZ | /*NON-RETRYABLE WRITE ERROR: ER / |
| 5173 | 026412 | 051055 | 052105 | 054522 | | | |
| 5174 | 026420 | 041101 | 042514 | 053440 | | | |
| 5175 | 026426 | 044522 | 042524 | 042440 | | | |
| 5176 | 026434 | 051122 | 051117 | 020072 | | | |
| 5177 | 026442 | 051105 | 000040 | | | | |
| 5178 | 026446 | 020445 | 047516 | 026516 | MSG79: | .ASCIZ | /*NON-RETRYABLE READ ERROR: ER / |
| 5179 | 026454 | 042522 | 051124 | 040531 | | | |
| 5180 | 026462 | 046102 | 020105 | 042522 | | | |
| 5181 | 026470 | 042101 | 042440 | 051122 | | | |
| 5182 | 026476 | 051117 | 020072 | 051105 | | | |
| 5183 | 026504 | 000040 | | | | | |
| 5184 | 026506 | 020445 | 042441 | 042116 | MSG100: | .ASCIZ | /*!!END OF PASS %/ |
| 5185 | 026514 | 047440 | 020106 | 040520 | | | |
| 5186 | 026522 | 051523 | 022440 | 000 | | | |
| 5187 | 026527 | 045 | 025045 | 025052 | MSG101: | .ASCIZ | /****** |
| 5188 | 026534 | 025052 | 025052 | 025052 | | | |

| | | | | | |
|------|--------|--------|--------|--------|--|
| 5189 | 026542 | 025052 | 025052 | 025052 | |
| 5190 | 026550 | 025052 | 025052 | 000052 | |
| 5191 | 026556 | 052052 | 030115 | 020063 | MSG102: .ASCIZ /*TMO3 / |
| 5192 | 026564 | 000 | | | |
| 5193 | 026565 | 052 | 046123 | 053101 | MSG103: .ASCIZ /*SLAVES / |
| 5194 | 026572 | 051505 | 000040 | | |
| 5195 | 026576 | 040445 | 052125 | 020117 | MSG104: .ASCIZ /*AUTO CONT: / |
| 5196 | 026604 | 047503 | 052116 | 020072 | |
| 5197 | 026612 | 000 | | | |
| 5198 | 026613 | 045 | 042522 | 047503 | MSG105: .ASCIZ /*RECOVERED/ |
| 5199 | 026620 | 042526 | 042522 | 000104 | |
| 5200 | 026626 | 020452 | 041041 | 042101 | MSG106: .ASCIZ /*!!BAD TAPE OVERFLOW/ |
| 5201 | 026634 | 052040 | 050101 | 020105 | |
| 5202 | 026642 | 053117 | 051105 | 046106 | |
| 5203 | 026650 | 053517 | 000 | | |
| 5204 | 026653 | 045 | 042522 | 044527 | MSG16A: .ASCIZ /*REWIND TAPE; RESTART AT BLOCK 1/ |
| 5205 | 026660 | 042116 | 052040 | 050101 | |
| 5206 | 026666 | 035505 | 051040 | 051505 | |
| 5207 | 026674 | 040524 | 052122 | 040440 | |
| 5208 | 026702 | 020124 | 046102 | 041517 | |
| 5209 | 026710 | 020113 | 000061 | | |
| 5210 | 026714 | 020445 | 052441 | 051116 | MSG107: .ASCIZ /*!!UNRECOVERABLE BAD SPOT/ |
| 5211 | 026722 | 041505 | 053117 | 051105 | |
| 5212 | 026730 | 041101 | 042514 | 041040 | |
| 5213 | 026736 | 042101 | 051440 | 047520 | |
| 5214 | 026744 | 000124 | | | |
| 5215 | 026746 | 041045 | 042101 | 051040 | .ASCIZ /*BAD RECORD LEFT ON TAPE%/ |
| 5216 | 026754 | 041505 | 051117 | 020104 | |
| 5217 | 026762 | 042514 | 052106 | 047440 | |
| 5218 | 026770 | 020116 | 040524 | 042520 | |
| 5219 | 026776 | 000045 | | | |
| 5220 | 027000 | 020452 | 050041 | 051517 | MSG109: .ASCIZ /*!!POSITION LOST IN RETRY/ |
| 5221 | 027006 | 052111 | 047511 | 020116 | |
| 5222 | 027014 | 047514 | 052123 | 044440 | |
| 5223 | 027022 | 020116 | 042522 | 051124 | |
| 5224 | 027030 | 000131 | | | |
| 5225 | 027032 | 051445 | 051525 | 042520 | MSG110: .ASCIZ /*SUSPECT BAD TAPE/ |
| 5226 | 027040 | 052103 | 041040 | 042101 | |
| 5227 | 027046 | 052040 | 050101 | 000105 | |
| 5228 | 027054 | 051045 | 050105 | 040505 | MSG111: .ASCIZ /*REPEAT: / |
| 5229 | 027062 | 035124 | 000040 | | |
| 5230 | 027066 | 041040 | 042101 | 052040 | MSG112: .ASCIZ / BAD TAPE SPOTS%/ |
| 5231 | 027074 | 050101 | 020105 | 050123 | |
| 5232 | 027102 | 052117 | 022523 | 000 | |
| 5233 | | | | | |
| 5234 | 027107 | 045 | 051440 | 043117 | MSG113: .ASCIZ /* SOFT: / |
| 5235 | 027114 | 035124 | 000040 | | |
| 5236 | | | | | |
| 5237 | 027120 | 020045 | 040510 | 042122 | MSG114: .ASCIZ /* HARD: / |
| 5238 | 027126 | 020072 | 000 | | |
| 5239 | | | | | |
| 5240 | 027131 | 045 | 020441 | 040510 | MSG115: .ASCIZ /*!!HARD READ ERROR/ |
| 5241 | 027136 | 042122 | 051040 | 040505 | |
| 5242 | 027144 | 020104 | 051105 | 047522 | |
| 5243 | 027152 | 000122 | | | |
| 5244 | 027154 | 020445 | 047125 | 052111 | MSG116: .ASCIZ /*!UNIT IS REWINDING: TEST WILL START AT BOT/ |

| | | | | |
|------|--------|--------|--------|--------|
| 5245 | 027162 | 044440 | 020123 | 042522 |
| 5246 | 027170 | 044527 | 042116 | 047111 |
| 5247 | 027176 | 035107 | 052040 | 051505 |
| 5248 | 027204 | 020124 | 044527 | 046114 |
| 5249 | 027212 | 051440 | 040524 | 052122 |
| 5250 | 027220 | 040440 | 020124 | 047502 |
| 5251 | 027226 | 000124 | | |
| 5252 | 027230 | 000134 | | |
| 5253 | 027232 | 051045 | 046505 | 053117 |
| 5254 | 027240 | 020105 | 046524 | 050104 |
| 5255 | 027246 | 043040 | 047522 | 020115 |
| 5256 | 027254 | 046123 | 053101 | 020105 |
| 5257 | 027262 | 047524 | 041040 | 020105 |
| 5258 | 027270 | 042524 | 052123 | 042105 |
| 5259 | 027276 | 000045 | | |
| 5260 | 027300 | 044045 | 051101 | 053504 |
| 5261 | 027306 | 051101 | 020105 | 053523 |
| 5262 | 027314 | 020122 | 047111 | 052440 |
| 5263 | 027322 | 042523 | 000045 | |
| 5264 | | | | |
| 5265 | | | | |
| 5266 | 027326 | 000000 | | |
| 5267 | | | | |
| 5268 | | 033334 | | |
| 5269 | 033334 | 000000 | | |
| 5270 | | | | |
| 5271 | | 000001 | | |

MSG118: .ASCIZ /
MSG120: .ASCIZ /%REMOVE TMDP FROM SLAVE TO BE TESTED%/

MSG121: .ASCIZ /%HARDWARE SWR IN USE%/

WDATA: 0 .EVEN ;WRITE BUFFER
 RDATA: 0 .+.4004 ;READ BUFFER
 .END

| | | | | | | | | | |
|---------|--------|--------|--------|--------|--------|--------|--------|--------|--------|
| ABL CNT | 000742 | BTPT1 | 007376 | DAT0A | 014320 | DF0C0 | 015514 | EOTREC | 000662 |
| ACTLRC | 021012 | BTPT | 000732 | DAT0B | 014326 | DF0D | 015470 | ER | 000524 |
| ADRVN | 000740 | BTSTF | 000730 | DAT0C | 014372 | DF0E | 015462 | ERCHK | 017236 |
| AMOD1 | 022274 | BTUR | 007402 | DAT0D | 014400 | DF0F | 015454 | ERPT | 020056 |
| AMOD2 | 022434 | BT00 | 001610 | DAT0E | 014410 | DF1 | 015702 | ERPTG | 020112 |
| APATS | 014740 | BT01 | 001714 | DAT0F | 014424 | DF2 | 015712 | ERPTG1 | 020160 |
| AS | 000526 | BT02 | 002020 | DAT1 | 014434 | DF3 | 015730 | ERPTT | 020076 |
| ASEQ | 021734 | BT03 | 002124 | DAT1A | 014440 | DF4 | 015772 | ERPTO | 020174 |
| ASEQCF | 000744 | BT04 | 002230 | DAT10 | 014556 | DOUT | 024222 | ERPT1 | 020242 |
| ASEQF | 000736 | BT05 | 002334 | DAT11 | 014606 | DOUTD | 024276 | ERPT2 | 020300 |
| ASEQX | 022072 | BT06 | 002440 | DAT12 | 014626 | DPC | 016624 | ERPT3 | 020336 |
| ASEQXX | 022106 | BT07 | 002544 | DAT13 | 014650 | DPCG | 016632 | ERPT4 | 020400 |
| ASEQ0 | 021766 | B0 | 012026 | DAT14 | 014660 | DPC0 | 016640 | ERPT5 | 020422 |
| ASEQ1 | 021772 | B1 | 012072 | DAT15 | 014710 | DPC0A | 016702 | ERPT5A | 020504 |
| ASEQ2 | 022032 | B2 | 012102 | DAT2 | 014454 | DPC1 | 016710 | ERPT6 | 020546 |
| ASEQ3 | 022044 | CADER | 020774 | DAT3 | 014460 | DPC1A | 016736 | ERPT7 | 020616 |
| ASEQ4 | 022054 | CC | 000530 | DAT3A | 014466 | DPC2 | 017000 | ERPX | 020652 |
| BA | 000514 | CCNTR | 012126 | DAT4 | 014504 | DPC2A | 016742 | ERPX0 | 020620 |
| BAER | 020776 | CHNFLG | 003040 | DAT5 | 014514 | DPC2B | 016764 | ERPX1 | 020740 |
| BBC | 000660 | CLLAST | 015122 | DAT6 | 014522 | DPC3 | 017032 | ERPX2 | 020772 |
| BCNT | 000712 | CLP | 015232 | DAT7 | 014530 | DPPRT | 017100 | ERSAV | 000724 |
| BDPP | 000720 | CLPE | 015256 | DB | 000532 | DPPRTX | 017234 | ERTFL | 000734 |
| BD00 | 001410 | CLP2 | 015314 | DCHK | 015366 | DPPRT0 | 017150 | ERO | 017252 |
| BD10 | 001430 | CLP3 | 015326 | DCHKO | 015414 | DPPRT1 | 017174 | EROA | 017320 |
| BD20 | 001450 | CLO | 015042 | DEREV1 | 001170 | DPPRT2 | 017210 | EROB | 017266 |
| BD30 | 001470 | CL1 | 015070 | DEREX | 016450 | DROP | 016614 | ER1 | 017326 |
| BD40 | 001510 | CL2 | 015112 | DEREX1 | 016502 | DRPK | 016602 | ER10 | 020020 |
| BD50 | 001530 | CL3 | 015174 | DERFL | 000706 | DRPKF | 016514 | ER2 | 017332 |
| BD60 | 001550 | CONER | 021000 | DERR | 016000 | DRP1 | 001010 | ER2A | 017376 |
| BD70 | 001570 | CRCC | 000566 | DERR0 | 016010 | DRP2 | 001012 | ER2A0 | 017346 |
| BKRT | 012046 | CR CER | 021010 | DERR0A | 016040 | DRP3 | 001014 | ER2A1 | 017366 |
| BKSP | 011672 | CRCLRC | 015024 | DERR0B | 016072 | DRP4 | 001016 | ER2B | 017412 |
| BKTM | 011754 | CRCSV | 021016 | DERR0C | 016116 | DRP5 | 001020 | ER2C | 017436 |
| BKTM0 | 012016 | CS | 000520 | DERR0D | 016120 | DRP6 | 001022 | ER2D | 017452 |
| BLCNTR | 000656 | CI | 000510 | DERR1 | 016146 | DRP7 | 001024 | ER2E | 017500 |
| BPKP | 000722 | DAT0 | 002772 | DERR2 | 016150 | DRP8 | 001026 | ER3 | 017506 |
| BPO0 | 001210 | DAT01 | 002774 | DERR3 | 016164 | DRVER | 021002 | ER3A | 017544 |
| BP10 | 001230 | DAT010 | 003012 | DERR4 | 016166 | DS | 000522 | ER3A1 | 017602 |
| BP20 | 001250 | DAT011 | 003014 | DERR4A | 016326 | DSUP | 014110 | ER3B | 017610 |
| BP30 | 001270 | DAT012 | 003016 | DERR4B | 016374 | DS0 | 014116 | ER4 | 017614 |
| BP40 | 001310 | DAT013 | 003020 | DERR5 | 016432 | DS0A | 014200 | ER4A | 017660 |
| BP50 | 001330 | DAT014 | 003022 | DERR6 | 016444 | DS0B | 014176 | ER4A1 | 017652 |
| BP60 | 001350 | DAT015 | 003024 | DFX | 015776 | DSOC | 014140 | ER6 | 017664 |
| BP70 | 001370 | DAT02 | 002776 | DF0 | 015670 | DS2A | 014226 | ER6A | 017750 |
| BTADDR | 001030 | DAT03 | 003000 | DF0A | 015564 | DS3 | 014232 | ER7 | 020002 |
| BTFLG | 000726 | DAT04 | 003002 | DF0A0 | 015606 | DS4 | 014244 | EXCRC | 015362 |
| BT0V | 007166 | DAT05 | 003004 | DF0A1 | 015622 | DT | 000536 | EXLRC | 015364 |
| BT0VX | 007324 | DAT06 | 003006 | DF0A2 | 015636 | DVN | 000550 | FC | 000516 |
| BT0V0 | 007204 | DAT07 | 003010 | DF0A3 | 015652 | DOFL | 014432 | FCER | 021004 |
| BT0V1 | 007214 | DATBL | 002770 | DF0A4 | 015656 | EMADDR | 000654 | FCSAV | 000634 |
| BT0V2 | 007300 | DATER1 | 001130 | DF0B | 015524 | ENDFLG | 000736 | FMCNT | 000556 |
| BT0V3 | 007316 | DATR | 014760 | DF0B0 | 015546 | ENDTBL | 002770 | FRPRT | 021020 |
| BTPT | 007326 | DAT0 | 014274 | DF0C | 015504 | EOTCO | 002650 | GTSWR | 023204 |

| | | | | | | | | | |
|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|
| NRFL | 000666 | MSG23 | 025023 | MSG72 | 026303 | RANSAY | 000630 | ROS | 010472 |
| NERE | 005032 | MSG23M | 025030 | MSG73 | 026314 | RANSET | 004276 | RO6 | 010514 |
| NRDS | 022110 | MSG24 | 025035 | MSG74 | 026325 | RCNT | 000554 | RD7 | 010540 |
| INIT | 005426 | MSG25 | 025055 | MSG75 | 026350 | RCNTR | 012166 | RD7A | 010570 |
| INTRF | 000570 | MSG26 | 025075 | MSG76 | 026363 | RCSAV | 000632 | READ | 007730 |
| LACER | 021006 | MSG27 | 025106 | MSG77 | 026374 | RDA | 007770 | REGS | 000544 |
| LACSV | 021014 | MSG28 | 025117 | MSG78 | 026405 | RDATA | 033334 | REOT | 004330 |
| NR | 000534 | MSG3 | 024456 | MSG79 | 026446 | RDCMD | 000562 | REOTC | 005054 |
| MSG1 | 024444 | MSG30 | 025121 | MSG8 | 024507 | RDERR1 | 001150 | REOTX | 004760 |
| MSG10 | 024525 | MSG31 | 025161 | MSG9 | 024517 | RDER1 | 001110 | REOTXX | 005050 |
| MSG100 | 026506 | MSG31A | 025236 | MTCL | 000674 | RDER2 | 001112 | REOT1A | 004376 |
| MSG101 | 026527 | MSG32 | 025323 | MTINT | 021716 | RDER3 | 001114 | REOT1B | 004424 |
| MSG102 | 026536 | MSG33 | 025344 | MTINTA | 021720 | RDER4 | 001116 | REOT1C | 004444 |
| MSG103 | 026565 | MSG34 | 025360 | NOP | 000240 | RDER5 | 001120 | REOT1E | 004470 |
| MSG104 | 026576 | MSG35 | 025373 | NRTP | 011236 | RDER6 | 001122 | REOT1F | 004440 |
| MSG105 | 026613 | MSG36 | 025414 | NRZOF | 000652 | RDER7 | 001124 | REOT2 | 004512 |
| MSG106 | 026626 | MSG37 | 025433 | OCTP | 024006 | RDER8 | 001126 | REOT2A | 004550 |
| MSG107 | 026714 | MSG38 | 025456 | OCTPG | 024156 | RDEX | 010656 | REOT3 | 004576 |
| MSG109 | 027000 | MSG39 | 025476 | OCTPG0 | 024174 | RDFL | 015022 | REOT4 | 004626 |
| MSG11 | 024532 | MSG4 | 024463 | OCTPG1 | 024200 | RDRTG | 010752 | REOT5 | 004642 |
| MSG110 | 027032 | MSG40 | 025536 | OCTP0 | 024024 | RDRTX | 011234 | REOT6 | 004706 |
| MSG111 | 027054 | MSG41 | 025565 | OCTP1 | 024044 | RDRTY | 010664 | REOT7 | 004736 |
| MSG112 | 027066 | MSG42 | 025577 | OCTP2 | 024052 | RDRTO | 010676 | RETRY | 000604 |
| MSG113 | 027107 | MSG43 | 025617 | OCTP3 | 024142 | RDRT1 | 010730 | RFHARD | 002730 |
| MSG114 | 027120 | MSG44 | 025623 | OFL | 024220 | RDRT1A | 010726 | RFSOFT | 002670 |
| MSG115 | 027131 | MSG45 | 025652 | PAPRT | 022570 | RDRT1B | 010746 | RPCNT | 000702 |
| MSG116 | 027154 | MSG46 | 025664 | PAPRTA | 022744 | RDRT2 | 011030 | RRHARD | 002750 |
| MSG118 | 027230 | MSG47 | 025671 | PAPRTB | 022760 | RDRT3 | 011052 | RRSOFT | 002710 |
| MSG12 | 024546 | MSG48 | 025676 | PAPRTC | 022774 | RDRT4 | 011056 | RSEQ | 007416 |
| MSG120 | 027232 | MSG49 | 025731 | PAPRTD | 023002 | RDRT5 | 011060 | RSEX | 007552 |
| MSG121 | 027300 | MSG5 | 024470 | PAPRTY | 023076 | RDRT5A | 011124 | RSF | 007470 |
| MSG13 | 024564 | MSG50 | 025745 | PAPRT0 | 022672 | RDRT5B | 011134 | RSFR | 007566 |
| MSG14 | 024572 | MSG52 | 025772 | PAPRT1 | 023046 | RDRT6 | 011164 | RSFRX | 007726 |
| MSG15 | 024577 | MSG53 | 026013 | PAPRT2 | 023100 | RDRT7 | 011230 | RSFR0 | 007620 |
| MSG16 | 024630 | MSG54 | 026026 | PAPRT3 | 023102 | RDX | 010662 | RSFR1 | 007632 |
| MSG16A | 026653 | MSG55 | 026035 | PARS | 014272 | RDO | 010026 | RSFR2 | 007664 |
| MSG17 | 024633 | MSG56 | 026044 | PATRN | 000560 | RD1 | 010074 | RSFO | 007524 |
| MSG2 | 024451 | MSG57 | 026050 | PATS | 014270 | RD1A | 010110 | RSF1 | 007540 |
| MSG20 | 024636 | MSG58 | 026071 | PFLG | 000672 | RD1B | 010116 | RSR | 007446 |
| MSG21 | 024651 | MSG59 | 026077 | PICK | 017034 | RD1D | 010124 | RSTAL | 000574 |
| MSG22 | 024676 | MSG6 | 024475 | PIK1 | 000770 | RD10 | 010602 | RTCNT | 000704 |
| MSG23 | 024725 | MSG60 | 026105 | PIK2 | 000772 | RD11 | 010612 | RTRN | 000664 |
| MSG23A | 024733 | MSG61 | 026111 | PIK3 | 000774 | RD2 | 010130 | RTYFL | 000714 |
| MSG23B | 024740 | MSG62 | 026115 | PIK4 | 000776 | RD3 | 010170 | RTY1 | 001050 |
| MSG23C | 024745 | MSG64 | 026121 | PIK5 | 001000 | RD4 | 010220 | RTY2 | 001052 |
| MSG23D | 024752 | MSG65 | 026143 | PIK6 | 001002 | RD4A | 010316 | RTY3 | 001054 |
| MSG23E | 024760 | MSG66 | 026154 | PIK7 | 001004 | RD4A0 | 010350 | RTY4 | 001056 |
| MSG23F | 024765 | MSG67 | 026167 | PIK8 | 001006 | RD4A1 | 010372 | RTY5 | 001060 |
| MSG23G | 024772 | MSG68 | 026177 | PRB | 000624 | RD4A2 | 010414 | RTY6 | 001062 |
| MSG23H | 024777 | MSG69 | 026210 | PRS | 000622 | RD4B | 010422 | RTY7 | 001064 |
| MSG23I | 025004 | MSG7 | 024502 | PSW | 000606 | RD4C | 010426 | RTY8 | 001066 |
| MSG23J | 025011 | MSG70 | 026226 | RANBAS | 007626 | RD4D | 010456 | RWIND | 005056 |
| MSG23K | 025016 | MSG71 | 026262 | RANG | 023152 | RD4E | 010462 | RWINDA | 005070 |