

IDENTIFICATION

PRODUCT CODE: AC-E107A-MC
PRODUCT NAME: CZKCgAO KMC FREE RUNNING TEST
DATE: MAY 1978
MAINTAINER: DIAGNOSTICS
AUTHOR: Ed Badger

COPYRIGHT (C) 1978 BY DIGITAL EQUIPMENT CORPORATION
THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT
NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL
EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES
NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A
LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE
TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR
THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS
NOT SUPPLIED BY DIGITAL.

1. ABSTRACT

The function of the KMC11 diagnostics is to verify that the option operates according to specifications. The diagnostics verify that there are no malfunctions and the all operations of the KMC11 are correct in its environment.

Parameters must be set up to alert the diagnostics to the KMC11 configuration. These parameters are contained in the STATUS TABLE and are generated in two ways: 1) Manual Input - the operator answers questions. 2) Autosizing - the program determines the parameters automatically.

CZDMG tests the KMC11 micro-processor Free running tests are performed. A line unit (M8201 or M8202) must be installed. CZDMG can be used as a heat test diagnostic by manufacturing.

Currently there are five off line diagnostics that are to be run in sequence to insure that if an error should occur it will be detected at an early stage.

NOTE: Additional diagnostics may be added in the future.

The five diagnostics are:

1. DZKCA KMC-11 CPU Micro-Diagnostics
 2. DZKCC Basic W/R and Micro-Processor Tests
 3. DZKCD KMC-11 Low speed jump and memory tests
 4. DZKCE DDCMP mode line unit tests
 5. DZKCF Bitstuff mode line unit tests

2. REQUIREMENTS

2.1 EQUIPMENT

Any PDP11 family CPU (except an LSI-11) with minimum 8k memory
ASR 33 (or equivalent)
KMC11 or
M8201 or M8202 line unit

2.2 STORAGE

Program will use all 8K of memory except where ABL and BOOTSTRAP LOADER reside. Locations 1500 thru 1640; contain the 'STATUS TABLE' information which is generated at start of diagnostics by manual input (questions) or automatically (auto-sizing). This area is an overlay area and should not be altered by the operator.

3. LOADING PROCEEDURE

3.1 METHOD

All programs are in absolute format and are loaded using the ABSOLUTE LOADER. NOTE: if the diagnostics are on a media such as DISK ,MAGTAPE,DECTAPE, or CASSETTE; follow instructions for the monitor which has been provided on that specific media.

ABSOLUTE LOADER starting address *500

MEMORY * SIZE

4k	17
8k	37
12k	57
16k	77
20k	117
24k	137
28k	157

- 3.1.1 Place address of ABS Loader into switch register.
(also place 'HALT' SW up)
- 3.1.2 Depress 'LOAD ADDRESS' key on console and release.
- 3.1.3 Depress 'START KEY' on console and release (program should now be loading into CPU)

4. STARTING PROCEEDURE

- a. Set switch register to 000200
- b. Depress 'LOAD ADDRESS' key and release
- c. Set SWR to zero for 'AUTO SIZING' or SWR bit0=1 for manual input (questions) or SWR bit7=1 to use existing parameters set up by a previous start or a previously run DMC11 diagnostic.
- d. Depress 'START KEY' and release. The program will type Maindec Name and program name (if this was the first start up of the program) and also the following:

MAP OF DMC11 STATUS

PC	CSR	STAT1	STAT2	STAT3
--	--	-----	-----	-----
001500	160010	145310	177777	000000
001510	160020	145320	177777	000000

The program will type 'R' and proceed to run the diagnostic. The above is only an example. This would indicate the status table starting at add. 1500 in the program. In this example the table contains the information and status of two DMC11's. THE STATUS TABLE MUST BE VERIFIED BY THE USER IF AUTO SIZING IS DONE. For information of status table see section 8.4 for help.

If the diagnostic was started with SW00=1 indicating manual parameter input then the following shows an example of the questions asked and some example answers:

HOW MANY KMC11'S TO BE TESTED?1

```
01
CSR ADDRESS?160010
VECTOR ADDRESS?310
BR PRIORITY LEVEL? (4,5,6,7)?5
DOES MICRO-PROCESSOR HAVE CRAM? (Y OR N)N
WHICH LINE UNIT? IF NONE TYPE 'N', IF M8201 TYPE '1', IF
M8202 TYPE '2'?1
IS THE LOOP BACK CONNECTOR ON?Y
SWITCH PAC#1 (DDCMP LINE#)?377
SWITCH PAC#2 (BM873 BOOT ADD)?377
```

Following the questions the status map is printed out as described above, the information in the map reflects the answers to the questions. If the diagnostic was started with SW00=0 and SW07=0 (AUTO-SIZING) then no questions are asked and only the status-map is printed out. If AUTO-SIZING is used the status information must be verified to be correct (match the hardware). if it does not match the hardware the diagnostic must be restarted with SW00=1 and the questions answered.

4.1 CONTROL SWITCH SETTINGS

SW 15 Set: Halt on error
SW 14 Set: Loop on current test
SW 13 Set: Inhibit error print out
SW 12 Set: Inhibit type out/abell on error.
SW 11 Set: Inhibit iterations. (quick pass)
SW 10 Set: Escape to next test on error
SW 09 Set: Loop with current data
SW 08 Set: Catch error and loop on it
SW 07 Set: Use previous status table.
SW 06 Set: Halt in ROMCLK routine before clocking
 micro-processor
SW 05 Set: Reserved
SW 04 Set: Reserved
SW 03 Set: Reselect KMC11's desired active
SW 02 Set: Lock on selected test
SW 01 Set: Restart program at selected test
SW 00 Set: Build new status table from questions. (If SW07=0
 and SW00=0 a new status table is built by
 auto-sizing)

Switch 06 and 08-15 are dynamic and can be changed as needed
while the diagnostic is running. Switches 00-03 and switch 07
are static, and are used only on starting or restarting the
diagnostic.

4.1.2 SWITCH REGISTER OPTIONS (at start up)

- SW 01 RESTART PROGRAM AT SELECTED TEST. It is strongly suggested that at least one pass has been made before trying to select a test, the reason being is that the program has to clear areas and set up parameters. When this switch is used the diagnostic will ask TEST NO.? Answer by typing the number of the test desired and carriage return to begin execution at the selected test.
- SW 02 LOCK ON SELECTED TEST. This switch when used with SW01 will cause the program to constantly loop on the selected test. Hitting any key on the console will let it advance to the next test and loop until a key is hit again. If SW02=0 when SW01 is used. The program will begin at the selected test and continue normal operations.
- SW 03 RESELECT KMC11'S DESIRED ACTIVE. Please note that a message is typed out for setting the switch register equal to KMC11's active. this means if the system has four KMC11s; bits 00,01,02,03 will be set in loc 'DMACTV' from the switch register. Using this switch(SW00) alters that location; therefore if four DMC11s are in the system ***DO NOT*** set switches greater than SW 03 in the up position. this would be a fatal error. do not select more active DMC11s than there is information on in the status table.

METHOD:

- A: Load address 200
- B: Start with SW 00=1
- C: Program will type message
- D: Set a switch for each KMC desired active.
EXAMPLE: If you have 4 DMC's but only want to run the first and the last set SWR bits 0 and 3 = 1. PRESS CONTINUE
- E: Number (IF VALID) will be in data lights
(excluding 11/05)
- F: Set with any other switch settings desired.
PRESS CONTINUE.

4.1.3 DYNAMIC SWITCHES

ERROR SWITCHES

1. SW 12 Delete print out/bell on error.
2. SW 13 Delete error printout.
3. SW 15 Halt on the error.
4. SW 08 Goto beginning of the test(on error).
5. SW 10 Goto next test(on error).

SCOPE SWITCHES

1. SW06 Halt in ROMCLK routine before clocking micro-processor instruction. This allows the operator to scope a micro-processor instruction in the static state before it is clocked. Hit continue to resume running.
2. SW09 (if enabled by 'SCOP1') on an error; If an '*' is printed in front of the test no. (ex. *TEST NO. 10) SW09 is incorporated in that test and therefore SW09 is usually the best switch for the scope loop (SW14=0, SW10=0, SW09=1, SW08=0). If SW09 is not enabled; and there is a HARD error (constant); SW08 is best. (SW14=1,0, SW10=0, SW09=0, SW08=1). for intermittent errors; SW14=1 will loop on test regardless of error or not error. (SW14=1, SW10=0, SW09=0, SW08=1,0)
3. SW11 Inhibit interations.
4. SW14 Loop on current test.

4.2 STARTING ADDRESS

Starting address is at 000200 there are no other starting addresses for the KMC11 diagnostics. (See Section 4.0)

NOTE: If address 000042 is non-zero the program assumes it is under ACT11 or XDP control and will act accordingly after all available KMC11's are tested the program will return to 'XDP' or 'ACT-11'.

5. OPERATING PROCEDURE

When program is initially started messages as described in section 4.0 will be printed, and program will begin running the diagnostic

5.2 PROGRAM AND/OR OPERATOR ACTION

The typical approach should be

1. Halt on error (via SW 15=1) when ever an error occurs.
2. Clear SW 15.
3. Set SW 14: (loop on this test)
4. Set SW 13: (inhibit error print out)

The TEST NUMBER and PC will be typed out and possibly an error message (this depends on the test) to give the operator an idea as to the source of the problem. If it is necessary to know more information concerning the error report; LOOK IN THE LISTING for that TEST NUMBER which was typed out and then NOTE THE PC of the ERROR REPORT this way the EXACT FUNCTION of the test CAN BE DETERMINED.

6. ERRORS

As described previously there will always be a TEST NUMBER and PC typed out at the time of an error (providing SW 13=0 and SW 12=0). in most cases additional information will be supplied in the error message to give the operator an indication of the error.

6.2 ERROR RECOVERY

If for some reason the KMC11 should 'HANG THE BUS' (gain control of bus so that console manual functions are inhibited) an init or power down/up is necessary for operator to regain control of cpu. If this should happen; look in location 'TSTNO' (address 1226) for the number of the test that was running at the time of the catastrophic error. In this way the operator will have an idea as to what the DMC11 was doing at the time of the error.

7. RESTRICTIONS

7.1 STARTING RESTRICTIONS

See section 4. (PLEASE)

Status table should be verified regardless of how program was started. Also it is important to use this listing along with the information printed on the TTY to completely isolate problems.

7.2 OPERATING RESTRICTIONS

The first time a KMC11 diagnostic is loaded into core and run the STATUS TABLE must be set up. This is done by manual input (SW00=1) or by autosizing (SW00=0 and SW07=0). Thereafter however the status table need not be setup by subsequent restarts or even loading the next DMC diagnostic because the STATUS TABLE is overlayed. The current parameters in the STATUS TABLE are used when SW07=1 on start up.

7.3 HARDWARE CONFIGURATION RESTRICTIONS

KMC(M8204)- Jumper W1 must be in.

LINE UNIT(M8201)- Jumpers W1, W2, and W4 must be IN. Jumpers W3, and W5 must be OUT. SW8 of E26 must be in the ON POSITION.

LINE UNIT (M8202)- Jumper W1 must be in. SW8 of E26 must be in the OFF position.

8. MISCELLANEOUS

8.1 EXECUTION TIME

All KMC11 device diagnostics will give an 'END PASS' message (providing no errors and sw12=0) within 4 mins. This is assuming SW11=1 (DELETE ITERATIONS) is set to give the fastest possible execution. The actual execution time depends greatly on the PDP11 CPU configuration and the amount of memory in the system.

8.2 PASS COMPLETE

NOTE: EVERY time the program is started; the tests will run as if SW11 (delete iterations) was up (=1). This is to 'VERIFY NO HARD ERRORS' as soon as possible. Therefore the first pass -EACH TIME PROGRAM IS STARTED- will be a 'QUICK PASS' until all DMC11's in system are tested. When the diagnostic has completed a pass the following is an example of the print out to be expected.

ENC PASS DZDMG CSR: 175000 VEC: 0300 PASSES: 000001
ERRORS: 000000

NOTE: The pass count and error counts are cumulative for each KMC11 that is running, and are set to zero only when the diagnostic is started. Therefore after an overnight run for example, the total passes and errors for each DMC11 since the diagnostic was started are reflected in PASSES: and ERRORS:.

8.4 KEY LOCATIONS

RETURN (1214) Contains the address where program will return when iteration count is reached or if loop on test is asserted.

NEXT (1216) Contains the address of the next test to be performed.

TSTNO (1226) Contains the number of the test now being performed.

RUN (1316) The bit in 'RUN' always points to the KMC11 currently being tested. EXAMPLE: (RUN) 1302/0000000001000000 Means that KMC11 no.06 is the KMC11 now running.

DMCRO0-DMCR17
DMST00-DMST17
(1500)-(1640)

These locations contain the information needed to test up to 16 (decimal) KMC11's sequentially. They contain the CSR,VECTOR and STATUS concerning the configuration of each KMC11.

DMACTV (1306) Each bit set in this location indicates that the associated KMC11 will be tested in turn. EXAMPLE: (DMACTV) 1276/0000000000011111 means that KMC11 no. 00,01,02,03,04 will be tested. EXAMPLE: (DMACTV) 1276/000000000010001 Means that DMC11 no. 00,04 will be tested.

DMCSR (1404) Contains the CSR of the current KMC11 under test.

8.4A 'STATUS TABLE' (1500-1640)

The table is filled by AUTO SIZING or by the manual parameter input (questions) as described previously. Also if desired by user; the locations may be altered by hand (toggled in) to suit the specific configuration.

The example status map shown below contains information for two DMC11's. The table can contain up to 16 DMC11's. Following the map is a description of the bits for each map entry

MAP OF KMC11 STATUS

PC	CSR	STAT1	STAT2	STAT3
--	---	---	---	---
001500	160010	145310	177777	000000
001510	160020	016320	000000	000000

Each map entry contains 4 words which contain the status information for 1 KMC11. The PC shows where in core memory the first of the 4 words is. In the example above the first KMC'S status is in locations, 1500, 1502, 1504, and 1506. The second KMC status is located at 1510, 1512, 1514, and 1516. The information contained in each 4 word entry is defined as follows:

CSR: Contains KMC11 CSR address

STAT1: BITS 00-08 IS KMC11 VECTOR ADDRESS
BIT15=1 MICRO-PROCESSOR HAS CRAM
BIT15=0 MICRO-PROCESSOR HAS CROM
BIT14=1 TURNAROUND CONNECTOR IS ON
BIT14=0 NO TURNAROUND CONNECTOR
BIT13=0 LINE UNIT IS AN M8201
BIT13=1 LINE UNIT IS AN M8202
BIT12=1 NO LINE UNIT
BITS 09-11 IS KMC11 BR PRIORITY LEVEL

STAT2: LOW BYTE IS SWITCH PAC#1 (DDCMP LINE NUMBER)
HIGH BYTE IS SWITCH PAC#2 (BM873 BOOT ADD)

STAT3:
BIT1=0 KMC11-AR (LOW SPEED)
BIT1=1 KMC11-AL (HIGH SPEED)

8.5 METHOD OF AUTO SIZING

8.5.1 FINDING THE CONTROL STATUS REGISTER.

The auto-sizing routine finds a KMC11 as follows: It starts at address 160000 and tests all address in increments of 10 up to and including address 167760. If the address does not time out, the following is done, the first CROM address is written to a 125252 then it is read back. If it contains a -1 or 125252 or a 626 or 16520 a DMC11 or KMC11 has been found, if not, the address is updated by 10 and the search continues. A -1 indicates a DMC11 with no CROM, a 125252 indicates a KMC11 with CRAM, a 626 indicates a DMC11-AL and a 16520 indicates a DMC11-AR. Further tests are performed at this point to determine which line unit, if any, is installed, if a loop-back connector is installed and various switch settings on the line unit. THIS IS WHY THE STATUS TABLE MUST BE VERIFIED BY THE USER AND IF ANY OF THE INFORMATION DOES NOT AGREE WITH THE HARDWARE THE DIAGNOSTIC MUST BE RESTARTED AND THE QUESTIONS MUST BE ANSWERED. All DMC11's in the system will be found by the auto-sizer. If it does not find a DMC11 the diagnostic must be restarted and the questions answered.

8.5.2 FINDING THE VECTOR AND BR LEVEL

The vector area (address 300-776) is filled with the instruction IOT and '.+2' (next address). The processor status is started at 7 and the DMC is programmed to interrupt. The PS is lowered by 1 until the DMC interrupts, a delay is made and if no interrupt occurs at PS level 3 (because of a bad DMC11) the program assumes vector address 300 at BR level 5 and the problem should be fixed in the diagnostic. Once the problem is fixed; the program should be re-setup again to get correct vector. If an interrupt occurred; the address to which the DMC11 interrupted to is picked up and reported as the vector. NOTE: if the vector reported is not the vector set up by you; there is a problem and AUTO SIZING should not be done.

8.6 SOFTWARE SWITCH REGISTER

If the diagnostic is run on an 11/04 or other CPU without a switch register then a software switch register is used to allow user the same switch options as described previously. If the hardware switch register does not exist or if one does and it contains all ones (177777) this software switch register is used.

Control:

To obtain control at any allowable time during execution of the diagnostic the operator types a CTRL G on the console terminal keyboard. As soon as the CTRL G is recognized, by the diagnostic, the following message will be displayed:

SWR=XXXXXX NEW?

Where XXXXXX is the current contents of the software switch register in octal. The software control routine will then await operator action. At which time the operator is required to type one or more of the legal characters: 1) 0 - 7, 2) line feed(<LF>), 3) carriage return(<CR>), or 4) control-U (CTRL U). No check is made for legality. If the input character is not a <LF>, <CR>, or CTRL U it is assumed to be an octal digit.

To change the contents of the SSR the operator simply types the new desired value in octal - leading zeros need not be typed. And terminates the input string with a <CR> or <LF> depending on the program action desired as described below. The input value will be truncated to the last 6 digits typed. At least one digit must be typed on any given input string prior to the terminator before a change to the SSR will occur.

When the input string is terminated with a <CR> the diagnostic will continue execution from the point at which it was interrupted. If a <CR> is the only thing typed the program will continue without changing the SSR. The <LF> differs from the <CR> by restarting the program as if it were restarted at address 200.

If a CTRL U is typed at any point in the input string prior to the terminator the input value will be disregarded and the prompt displayed (SWR = XXXXXX NEW?).

To set the SSR for the starting switches, first load the diagnostic, then hit CTRL G, then start the diagnostic.

1 01200
2 01300
3 01400 :*****.SSCOPE *****
4 01500 .
5 01600 .\$.SCOPE IS USED TO HANDLE SCOPE LOOPS
6 01700 .
7 01800 .ARGUMENT:
8 01900 .
9 02000 .1) NUM ---- IF NON-BLANK DESIRED NUMBER OF ITERATIONS
10 02100 . IF BLANK 2000. ITERATIONS WILL BE MADE
11 02200 .
12 02300 .2) INSTR -- IF NON-BLANK WILL BE THE FIRST INSTRUCTION OF
13 02400 . THE SCOPE ROUTINE
14 02500 . EXAMPLES OF USE:
15 02600 .1) <<MOV R1,SAVR1 ;SAVE R1>>
16 02700 .2) <<MOV R1,SAVR1>,<MOV R2,SAVR2>>
17 02800 .3) AS A MACRO I.E. <<PUSH <R0,R1,R2,R3,R4,R5>>>
18 02900 .
19 03000 .3) NOLOOP - IF BLANK THE FIRST PASS THROUGH THE PROGRAM WILL
20 03100 . INHIBIT ITERATIONS.
21 03200 . IF NON-BLANK ITERATIONS WILL OCCUR ON THE FIRST PASS.
22 03300 .
23 03400 .4) INSTR2 - IF NON-BLANK WILL REPLACE THE LAST INSTRUCTION (RTI).
24 03500 . REFER TO ARGUMENT 2 (INSTR) FOR EXAMPLE OF USE.
25 03600 . REMEMBER YOU NEED AN RTI (OR RTS) FOR EXITING THE ROUTINE.
26 03700 .
27 03800 .5) TABLE - IF THIS ARGUMENT IS IDENTICAL TO THE WORD "SW08TBL"
28 03900 . AND THE SWITCH 8 (SW08) SCOPE OPTION IS TO BE USED
29 04000 . A DISPATCH TABLE WILL BE CREATED. IF SW08 IS ON A '1'
30 04100 . THE LOWER BYTE OF THE SWITCH REGISTER WILL BE USED TO
31 04200 . INDEX INTO THE DISPATCH TABLE AND SELECT THE STARTING
32 04300 . ADDRESS OF THE SPECIFIED TEST. THE TABLE IS OF THE FORM:
33 04400 .
34 04500 .
35 04600 .WORD TST1+2
36 04700 .WORD TST2+2
37 04800 .
38 04900 .
39 05000 .
40 05100 .WORD TSTN+2
41 05200 .
42 05300 .
43 05400 :NOTE: THIS ROUTINE IS CONDITIONALLY ASSEMBLE BY \$SWR
44 05500 :FOR SW14,SW11,SW09,\$SW08
45 05600 :SW14=1 LOOP ON TEST
46 05700 :SW11=1 INHIBIT ITERATIONS
47 05800 :SW09=1 LOOP ON ERROR
48 05900 :SW08=1 LOOP ON TEST IN SW<7:0>
49 06000 :
50 06100 :*****
51 06200 :

52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67 :*AC-E107A-MC CZKCGA0 KMC FREE RUNNING TEST
68 :*COPYRIGHT 1978, DIGITAL EQUIPMENT CORP., MAYNARD, MASS. 01754
69 :*-
70
71 :STARTING PROCEDURE
72 :LOAD PROGRAM
73 :LOAD ADDRESS 000200
74 :SWR=0 AUTOSIZE KMC11
75 :SW07=1 USE CURRENT KMC11 PARAMETERS
76 :SW00=1 INPUT NEW KMC11 PARAMETERS
77 :PRESS START
78 :PROGRAM WILL TYPE 'AC-E107A-MC CZKCGA0 KMC FREE RUNNING TEST'
79 :PROGRAM WILL TYPE STATUS MAP
80 :PROGRAM WILL TYPE 'R' TO INDICATE THAT TESTING HAS STARTED
81 :AT THE END OF A PASS, PROGRAM WILL TYPE PASS COMPLETE MESSAGE
82 :AND THEN RESUME TESTING
83 :SUBSEQUENT RESTARTS WILL NOT TYPE PROGRAM TITLE
84
85 .SBttl BASIC DEFINITIONS
86
87 001200 :*INITIAL ADDRESS OF THE STACK POINTER *** 1200 ***
88 STACK= 1200
89 :EQUIV EMT.ERROR ;:BASIC DEFINITION OF ERROR CALL
90 :EQUIV IOT,SCOPE ;:BASIC DEFINITION OF SCOPE CALL
91
92 000011 :*MISCELLANEOUS DEFINITIONS
93 HT= 11 ;:CODE FOR HORIZONTAL TAB
94 LF= 12 ;:CODE FOR LINE FEED
95 CR= 15 ;:CODE FOR CARRIAGE RETURN
96 000200 CRLF= 200 ;:CODE FOR CARRIAGE RETURN-LINE FEED
97 177776 PS= 177776 ;:PROCESSOR STATUS WORD
98 :EQUIV PS_PSW
99 177774 STKLMT= 177774 ;:STACK LIMIT REGISTER
100 177772 PIRQ= 177772 ;:PROGRAM INTERRUPT REQUEST REGISTER
101 177570 DSWR= 177570 ;:HARDWARE SWITCH REGISTER
102 177570 DDISP= 177570 ;:HARDWARE DISPLAY REGISTER
103
104 000000 :*GENERAL PURPOSE REGISTER DEFINITIONS
105 R0= %0 ;:GENERAL REGISTER
106 R1= %1 ;:GENERAL REGISTER
107 R2= %2 ;:GENERAL REGISTER

08-JUN-78 07:54 PAGE 4
ZKCGA.P11 08-JUN-78 07:53

D 2

PAGE: 0016C2

BASIC DEFINITIONS

108 000003 R3= %3 ;GENERAL REGISTER
109 000004 R4= %4 ;GENERAL REGISTER
110 000005 R5= %5 ;GENERAL REGISTER
111 000006 R6= %6 ;GENERAL REGISTER
112 000007 R7= %7 ;GENERAL REGISTER
113 000006 SP= %6 ;STACK POINTER
114 000007 PC= %7 ;PROGRAM COUNTER
115
116 :*PRIORITY LEVEL DEFINITIONS
117 000000 PR0= 0 ;PRIORITY LEVEL 0
118 000040 PR1= 40 ;PRIORITY LEVEL 1
119 000100 PR2= 100 ;PRIORITY LEVEL 2
120 000140 PR3= 140 ;PRIORITY LEVEL 3
121 000200 PR4= 200 ;PRIORITY LEVEL 4
122 000240 PR5= 240 ;PRIORITY LEVEL 5
123 000300 PR6= 300 ;PRIORITY LEVEL 6
124 000340 PR7= 340 ;PRIORITY LEVEL 7
125
126 :*''SWITCH REGISTER'' SWITCH DEFINITIONS
127 100000 SW15= 100000
128 040000 SW14= 40000
129 020000 SW13= 20000
130 010000 SW12= 10000
131 004000 SW11= 4000
132 002000 SW10= 2000
133 001000 SW09= 1000
134 000400 SW08= 400
135 000200 SW07= 200
136 000100 SW06= 100
137 000040 SW05= 40
138 000020 SW04= 20
139 000010 SW03= 10
140 000004 SW02= 4
141 000002 SW01= 2
142 000001 SW00= 1
143 .EQUIV SW09,SW9
144 .EQUIV SW08,SW8
145 .EQUIV SW07,SW7
146 .EQUIV SW06,SW6
147 .EQUIV SW05,SW5
148 .EQUIV SW04,SW4
149 .EQUIV SW03,SW3
150 .EQUIV SW02,SW2
151 .EQUIV SW01,SW1
152 .EQUIV SW00,SW0
153
154 :*DATA BIT DEFINITIONS (BIT00 TO BIT15)
155 100000 BIT15= 100000
156 040000 BIT14= 40000
157 020000 BIT13= 20000
158 010000 BIT12= 10000
159 004000 BIT11= 4000
160 002000 BIT10= 2000
161 001000 BIT09= 1000
162 000400 BIT08= 400
163 000200 BIT07= 200

BASIC DEFINITIONS

164 000100 BIT06= 100
165 000040 BIT05= 40
166 000020 BIT04= 20
167 000010 BIT03= 10
168 000004 BIT02= 4
169 000002 BIT01= 2
170 000001 BIT00= 1
171 .EQUIV BIT09,BIT9
172 .EQUIV BIT08,BIT8
173 .EQUIV BIT07,BIT7
174 .EQUIV BIT06,BIT6
175 .EQUIV BIT05,BIT5
176 .EQUIV BIT04,BIT4
177 .EQUIV BIT03,BIT3
178 .EQUIV BIT02,BIT2
179 .EQUIV BIT01,BIT1
180 .EQUIV BIT00,BIT0
181
182 :*BASIC "CPU" TRAP VECTOR ADDRESSES
183 000004 ERRVEC= 4 :TIME OUT AND OTHER ERRORS
184 000010 RESVEC= 10 :RESERVED AND ILLEGAL INSTRUCTIONS
185 000014 TBITVEC=14 :T' BIT
186 000014 TRTVEC= 14 :TRACE TRAP
187 000014 BPTVEC= 14 :BREAKPOINT TRAP (BPT)
188 000020 IOTVEC= 20 :INPUT/OUTPUT TRAP (IOT) **SCOPE**
189 000024 PWRVEC= 24 :POWER FAIL
190 000030 EMTVEC= 30 :EMULATOR TRAP (EMT) **ERROR**
191 000034 TRAPVEC=34 :"TRAP" TRAP
192 000060 TKVEC= 60 :TTY KEYBOARD VECTOR
193 000064 TPVEC= 64 :TTY PRINTER VECTOR
194 000240 IRQVEC=240 :PROGRAM INTERRUPT REQUEST VECTOR
195
196
197
198
199 :INSTRUCTION DEFINITIONS
200 :-----
201
202 005746 PUSH1SP=5746 :DECREMENT PROCESSOR STACK 1 WORD
203 005726 POP1SP=5726 :INCREMENT PROCESSOR STACK 1 WORD
204 010046 PUSHR0=10046 :SAVE R0 ON STACK
205 012600 POPR0=12600 :RESTORE R0 FROM STACK
206 024646 PUSH2SP=24646 :DECREMENT STACK TWICE
207 022626 POP2SP=22626 :INCREMENT STACK TWICE
208 .EQUIV EMT,HLT :BASIC DEFINITION OF ERROR CALL
209
210
211

TRAPCATCHER FOR UNEXPECTED INTERRUPTS

```
212
213
214
215 :TRAPCATCAER FOR ILLEGAL INTERRUPTS
216 :THE STANDARD 'TRAP CATCHER' IS PLACED
217 :BETWEEN ADDRESS 0 TO ADDRESS 776.
218 :IT LOOKS LIKE 'PC+2 HALT'.
219
220
221
222 000000 000000 000000 .=0 WORD 0,0
223 ;STANDARD INTERRUPT VECTORS
224
225
226
227 000020 .=20
228 000020 004134 $SCOPE : SCOPE LOOP HANDLER.
229 000022 000340 PR7 : SERVICE AT LEVEL 7.
230 000024 007122 $PWRDN :POWER FAIL HANDLER
231 000026 000340 PR7 :SERVICE AT LEVEL 7
232 000030 006506 $ERROR :ERROR HANDLER
233 000032 000340 PR7 :SERVICE AT LEVEL 7
234 000034 006410 $TRAP :GENERAL HANDLER DISPATCH SERVICE
235 000036 000340 PR7 :SERVICE AT LEVEL 7
236 .SBTTL ACT11 HOOKS
237
238 ;HOOKS REQUIRED BY ACT11
239
240 000040 $SVPC=. :SAVE PC
241 000046 .=46
242 000046 004070 $ENDAD :;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .$EOP
243 000052 .=52
244 000052 000000 .WORD 0 :;2)SET LOC.52 TO ZERO
245 000040 .=$SVPC :; RESTORE PC
246
247 000174 .=174
248 000174 000000 DISPREG:0 :SOFTWARE DISPLAY REGISTER
249 000176 000000 SWREG: 0 :SOFTWARE SWITCH REGISTER
250
251 000200 .=200
252 000200 000137 002402 JMP .START :GO TO START OF PROGRAM
253
254
255 001000 001000 .=1000
256 001000 005200 041501 042455 MTITLE: .ASCII <200><12>/AC-E107A-MC/<200>
(2) 001016 055103 041513 040507 .ASCIZ /CZKCGAO KMC FREE RUNNING TEST/<200>
(2)
257 177570 DSWR = 177570
258 177570 DDISP = 177570
```

COMMON TAGS

259
 260
 261
 262 ;*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
 263 ;*USED IN THE PROGRAM.
 264
 265 001200 .=1200
 266 001200 000000 \$CMTAG: ;START OF COMMON TAGS
 267 001200 000000 .WORD 0 ;CONTAINS THE TEST NUMBER
 268 001202 000 .STSTNM: .BYTE 0 ;CONTAINS ERROR FLAG
 269 001203 000 .SERFLG: .BYTE 0 ;CONTAINS SUBTEST ITERATION COUNT
 270 001204 000000 .SICNT: .WORD 0 ;CONTAINS SCOPE LOOP ADDRESS
 271 001206 000000 .SLPADR: .WORD 0 ;CONTAINS SCOPE RETURN FOR ERRORS
 272 001210 000000 .SLPERR: .WORD 0 ;CONTAINS TOTAL ERRORS DETECTED
 273 001212 000000 .SERTTL: .WORD 0 ;CONTAINS ITEM CONTROL BYTE
 274 001214 000 .SITEMB: .BYTE 0 ;CONTAINS MAX. ERRORS PER TEST
 275 001215 001 .SERMAX: .BYTE 1 ;CONTAINS PC OF LAST ERROR INSTRUCTION
 276 001216 000000 .SERRPC: .WORD 0 ;CONTAINS ADDRESS OF 'GOOD' DATA
 277 001220 000000 .SGDADR: .WORD 0 ;CONTAINS ADDRESS OF 'BAD' DATA
 278 001222 000000 .SBDADR: .WORD 0 ;CONTAINS 'GOOD' DATA
 279 001224 000000 .SGDDAT: .WORD 0 ;CONTAINS 'BAD' DATA
 280 001226 000000 .SBDDAT: .WORD 0 ;CONTAINS 'BAD' DATA
 281 001230 000000 .WORD 0 ;RESERVED--NOT TO BE USED
 282 001232 000000 .WORD 0
 283 001234 000 .SAUTOB: .BYTE 0 ;AUTOMATIC MODE INDICATOR
 284 001235 000 .SINTAG: .BYTE 0 ;INTERRUPT MODE INDICATOR
 285 001236 000000 .WORD 0
 286 001240 177570 SWR: .WORD DSWR ;ADDRESS OF SWITCH REGISTER
 287 001242 177570 DISPLAY: .WORD DDISP ;ADDRESS OF DISPLAY REGISTER
 288 001244 177560 \$TKS: 177560 ;TTY KBD STATUS
 289 001246 177562 \$TKB: 177562 ;TTY KBD BUFFER
 290 001250 177564 \$TPS: 177564 ;TTY PRINTER STATUS REG. ADDRESS
 291 001252 177566 \$TPB: 177566 ;TTY PRINTER BUFFER REG. ADDRESS
 292 001254 000 \$NULL: .BYTE 0 ;CONTAINS NULL CHARACTER FOR FILLS
 293 001255 002 \$FILLS: .BYTE 2 ;CONTAINS # OF FILLER CHARACTERS REQUIRED
 294 001256 012 \$FILLC: .BYTE 12 ;INSERT FILL CHARS. AFTER A 'LINE FEED'
 295 001257 000 \$TPFLG: .BYTE 0 ;'TERMINAL AVAILABLE' FLAG (BIT<07>=0=YES)
 296 001260 000000 \$REGAD: .WORD 0 ;CONTAINS THE ADDRESS FROM
 297 ;WHICH (\$REGO) WAS OBTAINED
 298 001262 000000 \$REGO: .WORD 0 ;CONTAINS ((SREGAD)+0)
 299 001264 000000 \$REG1: .WORD 0 ;CONTAINS ((SREGAD)+2)
 300 001266 000000 \$REG2: .WORD 0 ;CONTAINS ((SREGAD)+4)
 301 001270 000000 \$REG3: .WORD 0 ;CONTAINS ((SREGAD)+6)
 302 001272 000000 \$REG4: .WORD 0 ;CONTAINS ((SREGAD)+10)
 303 001274 000000 \$REG5: .WORD 0 ;CONTAINS ((SREGAD)+12)
 304 001276 000000 \$TMP0: .WORD 0 ;USER DEFINED
 305 001300 000000 \$TMP1: .WORD 0 ;USER DEFINED
 306 001302 000000 \$TMP2: .WORD 0 ;USER DEFINED
 307 001304 000000 \$TMP3: .WORD 0 ;USER DEFINED
 308 001306 000000 \$TMP4: .WORD 0 ;USER DEFINED
 309 001310 000000 \$TIMES: 0 ;MAX. NUMBER OF ITERATIONS
 310 001312 077 \$QUES: .ASCII /?/ ;QUESTION MARK
 311 001313 015 \$CRLF: .ASCII <15> ;CARRIAGE RETURN
 312 001314 000012 \$LF: .ASCIZ <12> ;LINE FEED
 313
 314 .SBTTL APT MAILBOX-ETABLE

APT MAILBOX-ETABLE

315
 316
 317
 318 001316 000000 .EVEN
 319 001316 000000 SMAIL: .WORD AMSGTY ;:APT MAILBOX
 320 001320 000000 \$FATAL: .WORD AFATAL ;:MESSAGE TYPE CODE
 321 001322 000000 \$TESTN: .WORD ATESN ;:FATAL ERROR NUMBER
 322 001324 000000 \$PASS: .WORD APASS ;:TEST NUMBER
 323 001326 000000 \$DEVCT: .WORD ADEVCT ;:PASS COUNT
 324 001330 000000 \$UNIT: .WORD AUNIT ;:DEVICE COUNT
 325 001332 000000 \$MSGAD: .WORD AMGAD ;:I/O UNIT NUMBER
 326 001334 000000 \$MSGLG: .WORD AMGLG ;:MESSAGE ADDRESS
 327 001336 002 SETABLE: .WORD ACPUOP ;:MESSAGE LENGTH
 328 001336 002 SENV: .BYTE AENV ;:APT ENVIRONMENT TABLE
 329 001337 000 SENVM: .BYTE AENVM ;:ENVIRONMENT MODE BITS
 330 001340 000000 \$SWREG: .WORD ASWREG ;:APT SWITCH REGISTER
 331 001342 000000 \$USR: .WORD AUSR ;:USER SWITCHES
 332 001344 000000 \$CPUOP: .WORD ACPUOP ;:CPU TYPE,OPTIONS
 333 :* ;:BITS 15-11=CPU TYPE
 334 :* 11/04=01,11/05=02,11/20=03,11/40-04,11/45-05
 335 :* 11/70=06,PDQ=07,Q=10
 336 :* BIT 10=REAL TIME CLOCK
 337 :* BIT 9=FLOATING POINT PROCESSOR
 338 :* BIT 8=MEMORY MANAGEMENT
 339 001346 000 SMAMS1: .BYTE AMAMS1 ;:HIGH ADDRESS,M.S. BYTE
 340 001347 000 SMTYP1: .BYTE AMTYP1 ;:MEM. TYPE,BLK#1
 341 :* MEM.TYPE BYTE -- (HIGH BYTE)
 342 :* 900 NSEC CORE=001
 343 :* 300 NSEC BIPOLAR=002
 344 :* 500 NSEC MOS=003
 345 001350 000000 SMADR1: .WORD AMADR1 ;:HIGH ADDRESS,BLK#1
 346 :* MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF 'TYPE' ABO
 347 001352 000 SMAMS2: .BYTE AMAMS2 ;:HIGH ADDRESS,M.S. BYTE
 348 001353 000 SMTYP2: .BYTE AMTYP2 ;:MEM. TYPE,BLK#2
 349 001354 000000 SMADR2: .WORD AMADR2 ;:MEM.LAST ADDRESS,BLK#2
 350 001356 000 SMAMS3: .BYTE AMAMS3 ;:HIGH ADDRESS,M.S.BYTE
 351 001357 000 SMTYP3: .BYTE AMTYP3 ;:MEM.TYPE,BLK#3
 352 001360 000000 SMADR3: .WORD AMADR3 ;:MEM.LAST ADDRESS,BLK#3
 353 001362 000 SMAMS4: .BYTE AMAMS4 ;:HIGH ADDRESS,M.S.BYTE
 354 001363 000 SMTYP4: .BYTE AMTYP4 ;:MEM.TYPE,BLK#4
 355 001364 000000 SMADR4: .WORD AMADR4 ;:MEM.LAST ADDRESS,BLK#4
 356 001366 000000 \$VECT1: .WORD AVECT1 ;:INTERRUPT VECTOR#1,BUS PRIORITY#1
 357 001370 000000 \$VECT2: .WORD AVECT2 ;:INTERRUPT VECTOR#2BUS PRIORITY#2
 358 001372 000000 \$BASE: .WORD ABASE ;:BASE ADDRESS OF EQUIPMENT UNDER TEST
 359 001374 000000 \$DEVM: .WORD ADEVM ;:DEVICE MAP
 360 001376 000000 \$CDW1: .WORD ACDW1 ;:CONTROLLER DESCRIPTION WORD#1
 361 001400 000000 \$CDW2: .WORD ACDW2 ;:CONTROLLER DESCRIPTION WORD#2
 362 001402 000000 \$DDW0: .WORD ADDW0 ;:DEVICE DESCRIPTOR WORD#0
 363 001404 000000 \$DDW1: .WORD ADDW1 ;:DEVICE DESCRIPTOR WORD#1
 364 001406 000000 \$DDW2: .WORD ADDW2 ;:DEVICE DESCRIPTOR WORD#2
 365 001410 000000 \$DDW3: .WORD ADDW3 ;:DEVICE DESCRIPTOR WORD#3
 366 001412 000000 \$DDW4: .WORD ADDW4 ;:DEVICE DESCRIPTOR WORD#4
 367 001414 000000 \$DDW5: .WORD ADDW5 ;:DEVICE DESCRIPTOR WORD#5
 368 001416 000000 \$DDW6: .WORD ADDW6 ;:DEVICE DESCRIPTOR WORD#6
 369 001420 000000 \$DDW7: .WORD ADDW7 ;:DEVICE DESCRIPTOR WORD#7
 370 001422 000000 \$DDW8: .WORD ADDW8 ;:DEVICE DESCRIPTOR WORD#8

08-JUN-78 07:54 PAGE 9
CZKCGA.P11 08-JUN-78 07:53

I 2

PAGE: 0021CZ

APT MAILBOX-ETABLE

371 001424 000000 \$DDW9: .WORD ADDW9 ;:DEVICE DESCRIPTOR WORD#9
372 001426 000000 \$DDW10: .WORD ADDW10 ;:DEVICE DESCRIPTOR WORD#10
373 001430 000000 \$DDW11: .WORD ADDW11 ;:DEVICE DESCRIPTOR WORD#11
374 001432 000000 \$DDW12: .WORD ADDW12 ;:DEVICE DESCRIPTOR WORD#12
375 001434 000000 \$DDW13: .WORD ADDW13 ;:DEVICE DESCRIPTOR WORD#13
376 001436 000000 \$DDW14: .WORD ADDW14 ;:DEVICE DESCRIPTOR WORD#14
377 001440 000000 \$DDW15: .WORD ADDW15 ;:DEVICE DESCRIPTOR WORD#15
378
379
380 001442
381
382
383 ; PROGRAM CONTROL PARAMETERS
384
385 001442 000000 NEXT: .WORD 0 ; ADDRESS OF NEXT TEST TO BE EXECUTED
386 001444 000000 LOCK: .WORD 0 ; ADDRESS FOR LOCK CURRENT DATA
387
388 ; PROGRAM VARIABLES
389
390 001446 000000 STRTSW: .WORD 0 ; SWITCHES AT START OF PROGRAM
391 001450 000000 STAT: .WORD 0 ; KM STATUS WORD STORAGE
392 001452 000000 CLKX: .WORD 0
393 001454 000000 MASKX: .WORD 0
394 001456 000000 SAVSP: .WORD 0 ; STACK POINTER STORAGE
395 001460 000000 SAVPC: .WORD 0 ; PROGRAM COUNTER STORAGE
396 001462 000000 ZERO: .WORD 0
397 001464 000001 ONE: .WORD 1
398 001466 000000 MEMLIM: .WORD 0 ; HIGHEST LOCATION FOR NPR'S
399 001470 000001 KMACTV: .BLKW 1 ; KMC11 SELECTED ACTIVE
400 001472 000001 KMINUM: .BLKW 1 ; OCTAL NUMBER OF KMC11'S
401 001474 000001 SAVACT: .BLKW 1 ; ORIGINAL ACTIVE DEVICES.
402 001476 000001 SAVNAM: .BLKW 1 ; WORKABLE NUMBER.
403 001500 000000 RUN: .WORD 0 ; POINTER TO RUNNING DEVICES
404
405 001502 002072 CREAM: .WORD KM.MAP-6 ; TABLE POINTER
406 001504 002276 MILK: .WORD CNT.MAP-4 ; TABLE POINTER
407
408 ; PROGRAM CONTROL FLAGS
409
410 001506 000 INIFLG: .BYTE 0 ; PROGRAM INITIALIZING FLAG
411 .EVEN
412 001510 000 LOKFLG: .BYTE 0 ; LOCK ON CURRENT TEST FLAG
413 001511 000 QV.FLG: .BYTE 0 ; QUICK VERIFY FLAG
414 .EVEN
415 ; ON FIRST PASS OF EACH KMC11 ITERATIONS WILL BE

ERROR POINTER TABLE

416 .SBTTL ERROR POINTER :ABLE
417
418 ;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
419 ;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
420 ;*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
421 ;*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
422 ;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
423
424 ;* EM :POINTS TO THE ERROR MESSAGE
425 ;* DH :POINTS TO THE DATA HEADER
426 ;* DT :POINTS TO THE DATA
427 ;* DF :POINTS TO THE DATA FORMAT
428
429
430 001512 \$ERRTB:
431 .EVEN
432 ;* DF :: DOES NOT APPLY IN THIS DIAGNOSTIC.
433 001512 000000 0
434 001514 000000 0
435 001516 000000 0
436 001520 034020 EM12
437 001522 034263 DH5 :ERROR 1
438 001524 000000 0
439 001526 033654 EM2
440 001530 034167 DH2 :ERROR 2
441 001532 034526 DT13
442 001534 033677 EM3
443 001536 000000 0 :ERROR 3
444 001540 000000 0
445 001542 033725 EM4
446 001544 000000 0 :ERROR 4
447 001546 000000 0
448 001550 033747 EM5
449 001552 000000 0 :ERROR 5
450 001554 000000 0
451 001556 033725 EM4
452 001560 034167 DH2 :ERROR 6
453 001562 034366 DT5
454 001564 033747 EM5
455 001566 034167 DH2 :ERROR 7
456 001570 034354 DT4
457 001572 000000 0
458 001574 034135 DH1 :ERROR 10
459 001576 034400 DT6
460 001600 000000 0
461 001602 034135 DH1 :ERROR 11
462 001604 034416 DT7
463 001606 000000 0
464 001610 034167 DH2 :ERROR 12
465 001612 034354 DT4
466 001614 033774 EM11
467 001616 034135 DH1 :ERROR 13
468 001620 034434 DT10
469 001622 034020 EM12
470 001624 000000 0 :ERROR 14
471 001626 000000 0

08-JUN-78 07:54 PAGE 11
CZKCGA.P11 08-JUN-78 07:53

K 2

PAGE: 0023C2

ERROR POINTER TABLE

472 001630 034020
473 001632 034167
474 001634 034366
475 001636 034044
476 001640 034210
477 001642 034452
478 001644 034067
479 001646 034231
480 001650 034464
481 002034
482
483
484
485
486
487 002034
488 000024
489 000024 000200
490 000044
491 000044 002034
492 002034
493
494
495
496
497 002034
498 002034 000000
499 002036 001316
500 002040 000132
501 002042 000137
502 002044 000137
503 002046 000052
504

EM12
DH2 ;ERROR 15
DT5
EM13
DH3 ;ERROR 16
DT11
EM14
DH4 ;ERROR 17
DT12
.=2034
.SBTTL APT PARAMETER BLOCK

;*****
;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
;*****
.SX=. ;SAVE CURRENT LOCATION
.=24 ;SET POWER FAIL TO POINT TO START OF PROGRAM
200 ;FOR APT START UP
.=44 ;POINT TO APT INDIRECT ADDRESS PTR.
\$APTHDR ;POINT TO APT HEADER BLOCK
.=\$X ;RESET LOCATION COUNTER

;*****
;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
;INTERFACE SPEC.

SAPTHD:
SHIBTS: .WORD 0 ;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
\$MBADR: .WORD \$MAIL ;ADDRESS OF APT MAILBOX (BITS 0-15)
STSTM: .WORD 90. ;RUN TIM OF LONGEST TEST
SPASTM: .WORD 95. ;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
SUNITM: .WORD 95. ;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITION
.WORD \$ETEND-\$MAIL/2 ;LENGTH MAILBOX-ETABLE(WORDS)

APT PARAMETER BLOCK

505
506 :KMC11 CONTROL INDICATORS FOR CURRENT KMC11 UNDER TEST
507 ;-----
508
509 002050 000000 STAT1: 0
510 002052 000000 STAT2: 0
511 002054 000000 STAT3: 0
512
513 :KMC11 VECTOR AND REGISTER INDIRECT POINTERS
514 ;-----
515
516 002056 000000 KMRVEC: 0 :POINTER TO KMC11 RECEIVER INTERRUPT VECTOR
517 002060 000000 KMRLVL: 0 :POINTER TO KMC11 RECEIVER INTERRUPT SERVICE PS
518 002062 000000 KMTVEC: 0 :POINTER TO KMC11 TRANSMITTER INTERRUPT VECTOR
519 002064 000000 KMTLVL: 0 :POINTER TO KMC11 TRANSMITTER INTERRUPT SERVICE PS
520 002066 000000 KMCSR: 0 :POINTER TO KMC11 CONTROL STATUS REGISTER
521 002070 000000 KMCSRH: 0 :POINTER TO KMC11 CONTROL STATUS REGISTER HIGH BYTE.
522 002072 000000 KMCTL: 0 :POINTER TO KMC11 CONTROL OUT REGISTER
523 002074 000000 KMP04: 0 :POINTER TO KMC11 PORT REGISTER(SEL 4)
524 002076 000000 KMP06: 0 :POINTER TO KMC11 PORT REGISTER(SEL 6)
525
526 :TEMP STORAGE
527 ;-----
528
529 :TEMP: 0
530 ;.=.+40
531
532 :KMC11 STATUS TABLE AND ADDRESS ASSIGNMENTS
533 ;-----
534
535 002100 .=2100
536 002100 KM.MAP:
537 002100 000001 KMCR00: .BLKW 1 :CONTROL STATUS REGISTER FOR KMC11 NUMBER 00
538 002102 000001 KMS100: .BLKW 1 :VECTOR FOR KMC11 NUMBER 00
539 002104 000001 KMS200: .BLKW 1 :DDCMP LINE# FOR KMC11 NUMBER 00
540 002106 000001 KMS300: .BLKW 1 :3RD STATUS WORD
541
542 002110 000001 KMCR01: .BLKW 1 :CONTROL STATUS REGISTER FOR KMC11 NUMBER 01
543 002112 000001 KMS101: .BLKW 1 :VECTOR FOR KMC11 NUMBER 01
544 002114 000001 KMS201: .BLKW 1 :DDCMP LINE# FOR KMC11 NUMBER 01
545 002116 000001 KMS301: .BLKW 1 :3RD STATUS WORD
546
547 002120 000001 KMCR02: .BLKW 1 :CONTROL STATUS REGISTER FOR KMC11 NUMBER 02
548 002122 000001 KMS102: .BLKW 1 :VECTOR FOR KMC11 NUMBER 02
549 002124 000001 KMS202: .BLKW 1 :DDCMP LINE# FOR KMC11 NUMBER 02
550 002126 000001 KMS302: .BLKW 1 :3RD STATUS WORD
551
552 002130 000001 KMCR03: .BLKW 1 :CONTROL STATUS REGISTER FOR KMC11 NUMBER 03
553 002132 000001 KMS103: .BLKW 1 :VECTOR FOR KMC11 NUMBER 03
554 002134 000001 KMS203: .BLKW 1 :DDCMP LINE# FOR KMC11 NUMBER 03
555 002136 000001 KMS303: .BLKW 1 :3RD STATUS WORD
556
557 002140 000001 KMCR04: .BLKW 1 :CONTROL STATUS REGISTER FOR KMC11 NUMBER 04
558 002142 000001 KMS104: .BLKW 1 :VECTOR FOR KMC11 NUMBER 04
559 002144 000001 KMS204: .BLKW 1 :DDCMP LINE# FOR KMC11 NUMBER 04
560 002146 000001 KMS304: .BLKW 1 :3RD STATUS WORD

08-JUN-78 07:54 PAGE 13
CZKCGA.P11 08-JUN-78 07:53

M 2

PAGE: 0025C2

APT PARAMETER BLOCK

561
562 002150 000001 KMCR05: .BLKW 1 ;CONTROL STATUS REGISTER FOR KMC11 NUMBER 05
563 002152 000001 KMS105: .BLKW 1 ;VECTOR FOR KMC11 NUMBER 05
564 002154 000001 KMS205: .BLKW 1 ;DDCMP LINE# FOR KMC11 NUMBER 05
565 002156 000001 KMS305: .BLKW 1 ;3RD STATUS WORD
566
567 002160 000001 KMCR06: .BLKW 1 ;CONTROL STATUS REGISTER FOR KMC11 NUMBER 06
568 002162 000001 KMS106: .BLKW 1 ;VECTOR FOR KMC11 NUMBER 06
569 002164 000001 KMS206: .BLKW 1 ;DDCMP LINE# FOR KMC11 NUMBER 06
570 002166 000001 KMS306: .BLKW 1 ;3RD STATUS WORD
571
572 002170 000001 KMCR07: .BLKW 1 ;CONTROL STATUS REGISTER FOR KMC11 NUMBER 07
573 002172 000001 KMS107: .BLKW 1 ;VECTOR FOR KMC11 NUMBER 07
574 002174 000001 KMS207: .BLKW 1 ;DDCMP LINE# FOR KMC11 NUMBER 07
575 002176 000001 KMS307: .BLKW 1 ;3RD STATUS WORD
576
577 002200 000001 KMCR10: .BLKW 1 ;CONTROL STATUS REGISTER FOR KMC11 NUMBER 10
578 002202 000001 KMS110: .BLKW 1 ;VECTOR FOR KMC11 NUMBER 10
579 002204 000001 KMS210: .BLKW 1 ;DDCMP LINE# FOR KMC11 NUMBER 10
580 002206 000001 KMS310: .BLKW 1 ;3RD STATUS WORD
581
582 002210 000001 KMCR11: .BLKW 1 ;CONTROL STATUS REGISTER FOR KMC11 NUMBER 11
583 002212 000001 KMS111: .BLKW 1 ;VECTOR FOR KMC11 NUMBER 11
584 002214 000001 KMS211: .BLKW 1 ;DDCMP LINE# FOR KMC11 NUMBER 11
585 002216 000001 KMS311: .BLKW 1 ;3RD STATUS WORD
586
587 002220 000001 KMCR12: .BLKW 1 ;CONTROL STATUS REGISTER FOR KMC11 NUMBER 12
588 002222 000001 KMS112: .BLKW 1 ;VECTOR FOR KMC11 NUMBER 12
589 002224 000001 KMS212: .BLKW 1 ;DDCMP LINE# FOR KMC11 NUMBER 12
590 002226 000001 KMS312: .BLKW 1 ;3RD STATUS WORD
591
592 002230 000001 KMCR13: .BLKW 1 ;CONTROL STATUS REGISTER FOR KMC11 NUMBER 13
593 002232 000001 KMS113: .BLKW 1 ;VECTOR FOR KMC11 NUMBER 13
594 002234 000001 KMS213: .BLKW 1 ;DDCMP LINE# FOR KMC11 NUMBER 13
595 002236 000001 KMS313: .BLKW 1 ;3RD STATUS WORD
596
597 002240 000001 KMCR14: .BLKW 1 ;CONTROL STATUS REGISTER FOR KMC11 NUMBER 14
598 002242 000001 KMS114: .BLKW 1 ;VECTOR FOR KMC11 NUMBER 14
599 002244 000001 KMS214: .BLKW 1 ;DDCMP LINE# FOR KMC11 NUMBER 14
600 002246 000001 KMS314: .BLKW 1 ;3RD STATUS WORD
601
602 002250 000001 KMCR15: .BLKW 1 ;CONTROL STATUS REGISTER FOR KMC11 NUMBER 15
603 002252 000001 KMS115: .BLKW 1 ;VECTOR FOR KMC11 NUMBER 15
604 002254 000001 KMS215: .BLKW 1 ;DDCMP LINE# FOR KMC11 NUMBER 15
605 002256 000001 KMS315: .BLKW 1 ;3RD STATUS WORD
606
607 002260 000001 KMCR16: .BLKW 1 ;CONTROL STATUS REGISTER FOR KMC11 NUMBER 16
608 002262 000001 KMS116: .BLKW 1 ;VECTOR FOR KMC11 NUMBER 16
609 002264 000001 KMS216: .BLKW 1 ;DDCMP LINE# FOR KMC11 NUMBER 16
610 002266 000001 KMS316: .BLKW 1 ;3RD STATUS WORD
611
612 002270 000001 KMCR17: .BLKW 1 ;CONTROL STATUS REGISTER FOR KMC11 NUMBER 17
613 002272 000001 KMS117: .BLKW 1 ;VECTOR FOR KMC11 NUMBER 17
614 002274 000001 KMS217: .BLKW 1 ;DDCMP LINE# FOR KMC11 NUMBER 17
615 002276 000001 KMS317: .BLKW 1 ;3RD STATUS WORD
616

08-JUN-78 07:54 PAGE 14
CZKCGA.P11 08-JUN-78 07:53

N 2

PAGE: 0026C2

617 002300 000000

APT PARAMETER BLOCK

KM.END: 000000

APT PARAMETER BLOCK

618
619 :KMC11 PASS COUNT AND ERROR COUNT TABLE
620 :-----
621
622 002302 CNT_MAP:
623 002302 000000 PACT00: 0 :PASS COUNT FOR KMC11 NUMBER 00
624 002304 000000 ERCT00: 0 :ERROR COUNT FOR KMC11 NUMBER 00
625
626 002306 000000 PACT01: 0 :PASS COUNT FOR KMC11 NUMBER 01
627 00231C 000000 ERCT01: 0 :ERROR COUNT FOR KMC11 NUMBER 01
628
629 002312 000000 PACT02: 0 :PASS COUNT FOR KMC11 NUMBER 02
630 002314 000000 ERCT02: 0 :ERROR COUNT FOR KMC11 NUMBER 02
631
632 002316 000000 PACT03: 0 :PASS COUNT FCR KMC11 NUMBER 03
633 002320 000000 ERCT03: 0 :ERROR COUNT FOR KMC11 NUMBER 03
634
635 002322 000000 PACT04: 0 :PASS COUNT FOR KMC11 NUMBER 04
636 002324 000000 ERCT04: 0 :ERROR COUNT FOR KMC11 NUMBER 04
637
638 002326 000000 PACT05: 0 :PASS COUNT FOR KMC11 NUMBER 05
639 002330 000000 ERCT05: 0 :ERROR COUNT FOR KMC11 NUMBER 05
640
641 002332 000000 PACT06: 0 :PASS COUNT FOR KMC11 NUMBER 06
642 002334 000000 ERCT06: 0 :ERROR COUNT FOR KMC11 NUMBER 06
643
644 002336 000000 PACT07: 0 :PASS COUNT FOR KMC11 NUMBER 07
645 002340 000000 ERCT07: 0 :ERROR COUNT FOR KMC11 NUMBER 07
646
647 002342 000000 PACT10: 0 :PASS COUNT FOR KMC11 NUMBER 10
648 002344 000000 ERCT10: 0 :ERROR COUNT FOR KMC11 NUMBER 10
649
650 002346 000000 PACT11: 0 :PASS COUNT FOR KMC11 NUMBER 11
651 002350 000000 ERCT11: 0 :ERROR COUNT FOR KMC11 NUMBER 11
652
653 002352 000000 PACT12: 0 :PASS COUNT FOR KMC11 NUMBER 12
654 002354 000000 ERCT12: 0 :ERROR COUNT FOR KMC11 NUMBER 12
655
656 002356 000000 PACT13: 0 :PASS COUNT FOR KMC11 NUMBER 13
657 002360 000000 ERCT13: 0 :ERROR COUNT FOR KMC11 NUMBER 13
658
659 002362 000000 PACT14: 0 :PASS COUNT FOR KMC11 NUMBER 14
660 002364 000000 ERCT14: 0 :ERROR COUNT FOR KMC11 NUMBER 14
661
662 002366 000000 PACT15: 0 :PASS COUNT FOR KMC11 NUMBER 15
663 002370 000000 ERCT15: 0 :ERROR COUNT FOR KMC11 NUMBER 15
664
665 002372 000000 PACT16: 0 :PASS COUNT FOR KMC11 NUMBER 16
666 002374 000000 ERCT16: 0 :ERROR COUNT FOR KMC11 NUMBER 16
667
668 002376 000000 PACT17: 0 :PASS COUNT FOR KMC11 NUMBER 17
669 002400 000000 ERCT17: 0 :ERROR COUNT FOR KMC11 NUMBER 17
670

08-JUN-78 07:54 PAGE 16
CZKCGA.P11 08-JUN-78 07:53

C 3

APT PARAMETER BLOCK

PAGE: 0028C2

671
672
673
674
675
676

FORMAT OF STATUS TABLE

15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
I	C	O	N	T	R	O	L	R	E	G	I	S	T	E	R
I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
I	*	*	*	*	*	*	*	*	V	E	C	T	O	R	*
I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
I	*	B	M	I	A	D	D	*	L	I	N	E	I	I	*
I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	*
I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I

CSR

STAT1

STAT2

STAT3

DEFINITION OF FORMAT

CSR: CONTAINS KMC11 CSR ADDRESS

STAT1: BITS 00-08 IS KMC11 VECTOR ADDRESS
BIT14=1 ???? TURNAROUND CONNECTOR IS ON
BIT14=0 NO TURNAROUND CONNECTOR
BIT13=0 LINE UNIT IS AN M8201
BIT13=1 LINE UNIT IS AN M8202
BIT12=1 NO LINE UNIT
BITS 09-11 IS KMC11 BR PRIORITY LEVEL

STAT2: LOW BYTE IS SWITCH PAC#1 (DDCMP LINE NUMBER)
HIGH BYTE IS SWITCH PAC#2 (BM873 BOOT ADD)

STAT3: BIT0=1 DO FREE RUNNING TESTS ON KMC
(MUST BE SET TO A ONE MANUALLY [PROGRAMS G AND H ONLY])

PROGRAM INITIALIZATION AND START UP.

725
 726 :PROGRAM INITIALIZATION
 727 :LOCK OUT INTERRUPTS
 728 :SET UP PROCESSOR STACK
 729 :SET UP POWER FAIL VECTOR
 730 :CLEAR PROGRAM CONTROL FLAGS AND COUNTS
 731 :TYPE TITLE MESSAGE
 732
 733 002402 012737 000340 177776 .START: MOV #340,PS ;LOCK OUT INTERRUPTS
 734 002410 012706 001200 000024 MOV #STACK,SP ;SET UP STACK
 735 002414 012737 007122 000024 MOV #SPWRDN, $\#24$;SET UP POWER FAIL VECTOR
 736 002422 013737 001472 001476 MOV KMNUM,SAVNUM ;SAVE NUMBER OF DEVICES IN SYSTEM.
 737 002430 005037 011432 CLR SWFLG ;CLEAR SOFT TYPEOUT FLAG
 738 002434 105037 001203 CLRB \$ERFLG ;CLEAR ERROR FLAG
 739 002440 105037 001511 CLRB QV,FLG ;ZERO QUICK VERIFY FLAG
 740 002444 012737 002070 001502 MOV #KM,MAP-10,CREAM ;GET MAP POINTER.
 741 002452 012737 002276 001504 MOV #CNT,MAP-4,MILK ;GET PASS COUNT MAP POINTER
 742 002460 012737 100000 001500 MOV #BIT15,RUN ;POINT POINTER TO FIRST DEVICE.
 743 002466 012700 002302 MOV #CNT,MAP,RO ;PASS COUNT POINTER TO RO
 744 002472 005020 CLR (RO)+ ;CLEAR TABLE
 745 002474 022700 002402 23\$: CMP #CNT,MAP+100,RO ;DONE YET?
 746 002500 001374 BNE 23\$;KEEP GOING
 747 002502 005037 001216 CLR \$ERRPC ;CLEAR LAST ERROR POINTER
 748 002506 012737 000001 001202 MOV #1,\$TSTNM ;SET UP FOR TEST 1
 749 002514 012737 002402 001206 MOV #.START,\$LPADR ;SET UP FOR POWER FAIL BEFORE
 750
 751 002522 132737 000001 001336 BITB #1,\$ENV ;IS IT RUNNING UNDER APT?
 752 002530 001404 BEQ 3\$;IF NOT CHECK FOR TYPE OF SWITCH REGISTER.
 753 002532 013737 001340 000176 MOV \$SWREG,SWREG ;LOAD SOFTWARE SWITCH REG.
 754 002540 000423 BR 6\$+2 ;GO SET UP SOFTWARE SWITCH REG.
 755 002542 013746 000006 3\$: MOV @#6,-(SP) ;SAVE CURRENT VECTORS
 756 002546 013746 000004 MOV @#4,-(SP)
 757 002552 012737 002606 000004 MOV #6\$,@#4 ;SET UP FOR TIMEOUT
 758 002560 012737 177570 001240 MOV #177570,SWR ;SET SWR TO HARD SWR ADDRESS
 759 002566 012737 177570 001242 MOV #177570,DISPLAY ;SET DISPLAY TO HARD SWR ADDRESS
 760 002574 022777 177777 176436 CMP #-1,@SWR ;REFERENCE HARDWARE SWITCH REGISTER
 761 002602 001402 BEQ 6\$+2 ;IF = -1 USE SOFT SWR ANYWAY
 762 002604 000407 BR 7\$;IF IT EXISTS AND NOT = -1 USE HARD SWR
 763 002606 022626 6\$: CMP (SP)+,(SP)+ ;ADJUST STACK
 764 002610 012737 000176 001240 MOV #SWREG,SWR ;pointer to soft swr
 765 002616 012737 000174 001242 MOV #DISPREG,DISPLAY ;pointer to soft display reg
 766 002624 012637 000004 7\$: MOV (SP)+,@#4 ;RESTORE VECTORS
 767 002630 012637 000006 MOV (SP)+,@#6
 768 002634 105737 001506 TSTB INIFLG ;HAS INITIALIZATION BEEN PERFORMED
 769 002640 001006 BNE 20\$;BR IF YES
 770 002642 022737 004070 000042 CMP #\$SENDAD, $\#42$;IF ACT-11 AUTOMATIC MODE, DON'T TYPE ID
 771 002650 001402 BEQ 20\$
 772 002652 104401 001000 TYPE ,MTITLE ;TYPE TITLE MESSAGE
 773 002656 004737 011226 JSR PC,CKSWR ;CHECK FOR SOFT SWR
 774 002662 017737 176352 001446 MOV @SWR,STRTSW ;STORE STARTING SWITCHES
 775 002670 005737 000042 TST @#42 ;IS IT RUNNING IN AUTO MODE?
 776 002674 C01402 BEQ .+6 ;BR IF NO
 777 002676 005037 001446 CLR STRTSW ;IF YES, CLEAR SWITCHES
 778 002702 032737 000001 001446 BIT #SW00,STRTSW ;IF SW00=1, QUESTIONS ARE ASKED.
 779 002710 001012 BNE 17\$;BR IF SW00=1
 780 002712 105737 001446 TSTB STRTSW ;BIT7=1??

08-JUN-78 07:54 PAGE 18
CZKCGA.P11 08-JUN-78 07:53

PAGE: 0030C2

PROGRAM INITIALIZATION AND START UP.

```

781 002716 100007          BPL   17$      ;BR IF SW07=0
782 002720 005737 001470    TST   KMACTV   ;ARE ANY DEVICES SELECTED?
783 002724 001027          BNE   16$      ;BR IF YES
784 002726 104401 010725    TYPE, NOACT   ;NO DEVICES SELECTED.
785 002732 000000          HALT
786 002734 000776          BR    -2       ;STOP THE SHOW
787 002736 105737 001336    17$: TSTB $ENV   ;DISQUALIFY CONTINUE SWITCH
788 002742 001405          BEQ   27$      ;IS IT UNDER APT DUMP MODE?
789 002744 132737 000001 001336    BITB #1,$ENV   ;YES, CHECK IF APT SIZED IT?
790 002752 001012          BNE   30$      ;IS IT UNDER Q,V OR RUN MODE?
791 002754 000406          BR    33$      ;YES, NEEDS ONLY APT SIZING.
792 002756 105737 001337    27$: TSTB $ENVVM  ;NO, NEEDS REGULAR AUTO.SIZE.
793 002762 100406          BMI   30$      ;IS IT SIZED BY APT?
794 002764 042737 000001 001446    BIC   #SW00,STRTSW  ;YES, NEEDS ONLY APT SIZING.
795 002772 004737 012124    33$: JSR  PC,AUTO.SIZE  ;SIZE ONLY IN AUTO MODE.
796 002776 000402          BR    16$      ;GO DO THE AUTO.SIZE.
797 003000 004737 013540    30$: JSR  PC,APT.SIZE  ;GO PRINT THE MAP.
798 003004 105737 001506    16$: TSTB INIFLG   ;GO DO THE APT SIZING.
799 003010 001410          BEQ   21$      ;FIRST TIME?
800 003012 105737 001446    TSTB STRTSW   ;BR IF YES
801 003016 100431          BMI   1$       ;IF USING SAME PARAMETERS DONT TYPE MAP
802 003020 032737 000006 001446    BIT   #BIT1!BIT2,STRTSW;IS TEST NO. OR LOCK SELECTED
803 003026 001403          BEQ   24$      ;IF NO THEN TYPE STATUS
804 003030 000424          BR    1$       ;IF YES DO NOT TYPE STATUS
805 003032 105137 001506    21$: COMB INIFLG   ;SET FLAG
806 003036 104401 010073    24$: TYPE XHEAD   ;TYPE HEADER
807 003042 012704 002100    MOV   #KM.MAP,R4   ;SET POINTER
808 003046 010437 001276    5$:  MOV  R4,$TMP0   ;SET ADDRESS
809 003052 012437 001300    MOV  (R4)+,$TMP1  ;SET CSR
810 003056 001411          BEQ   1$       ;ALL DONE IF ZERO
811 003060 012437 001302    MOV  (R4)+,$TMP2  ;SET STAT1
812 003064 012437 001304    MOV  (R4)+,$TMP3  ;SET STAT2
813 003070 012437 001306    MOV  (R4)+,$TMP4  ;SET STAT3
814 003074 104416          CONVRT
815 003076 011074          XSTATQ
816 003100 000762          BR    5$       ;TYPE OUT STATUS MAP
817 003102 012700 002100    1$:  MOV  #KM.MAP,RO   ;:
818                                     ;RO POINTS TO STATUS TABLE
819
820                                     ;*****AUTO SIZE TEST*****
821                                     ;THIS TEST VERIFY'S THAT THE KMC11S AND/OR KMC11S ARE AT THE CORRECT FLOATING
822                                     ;ADDRESSES FOR YOUR SYSTEM. IF THIS TEST FAILS, IT IS NOT A HARDWARE ERROR.
823                                     ;CHECK THE ADDRESSES OF ALL FLOATING DEVICES (DJ,DH,DQ,DU,DUP,LK,DMC,DZ,KMC).
824                                     ;IF THERE ARE NO OTHER FLOATING DEVICES BEFORE THE KMC11, THE FIRST
825                                     ;KMC11 IS 760110. NO DEVICE SHOULD EVER BE AT
826                                     ;ADDRESS 760000.
827                                     ;*****
828
829 003106 013746 000004          MOV   @#4,-(SP)  ;SAVE LOC 4
830 003112 013746 000006          MOV   @#6,-(SP)  ;SAVE LOC 6
831 003116 005037 000006          CLR   @#6      ;CLEAR VEC+2
832 003122 005037 001302          CLR   $TMP2   ;CLEAR FLAG
833 003126 011037 002066          AUSTRT: MOV  (R0),KMCSR ;GET NEXT KMC CSR
834 003132 001510          BEQ   AUDONE  ;BR IF DONE
835 003134 012737 003240 000004    2$:  MOV  #NODEV,@#4  ;SET UP FOR TIMEOUT
836 003142 012703 000010          3$:  MOV  #10,R3   ;R3 IS COUNT OF DEVICES BEFORE KMC

```

08-JUN-78 07:54 PAGE 19
CZKCGA.P11 08-JUN-78 07:53

F 3

PAGE : 0031C4

PROGRAM INITIALIZATION AND START UP.

837	003146	012702	003342		4\$:	MOV	#DEVTAB,R2	:R2 IS DEVICE TABLE PONTER
838	003152	012701	160010			MOV	#160010,R1	:START WITH ADDRESS 160010
839	003156	005711			FLOAT:	TST	(R1)	:CHECK ADDRESS IN R1
840	003160	111204				MOVB	(R2),R4	:IF NO TIMEOUT, GET NEXT ADDRESS
841	003162	060401				ADD	R4,R1	:IN R1
842	003164	005201				INC	R1	:
843	003166	040401				BIC	R4,R1	:
844	003170	005703				TST	R3	:ANY MORE DEVICES TO CHECK FOR?
845	003172	001371				BNE	FLOAT	:BR IF YES
846	003174	012737	003244	000004	FY:	MOV	#ERR,0#4	:OK ONLY KMC'S ARE LEFT, SET UP FOR TIMEOUT
847	003202	005711				TST	(R1)	:CHECK KMC ADDRESS
848	003204	020137	002066			CMP	R1,KMCSR	:DOES IT MATCH
849	003210	001403				BEQ	OK	:BR IF YES
850	003212	062701	000010			ADD	#10,R1	:GET NEXT KMC ADDRESS
851	003216	000771				BR	FY	:DO IT AGAIN
852	003220	062700	000010		OK:	ADD	#10,R0	:SKIP TO NEXT KMC CSR
853	003224	062701	000010			ADD	#10,R1	:GET NEXT KMC ADDRESS
854	003230	011037	002066			MOV	(R0),KMCSR	:GET NEXT KMC CSR
855	003234	001447				BEQ	AUDONE	:BRANCH IF ALL DONE.
856	003236	000761				BR	FY	:DO IT AGAIN.
857	003240	122243			NODEV:	CMPB	(R2)+,-(R3)	:ON TIMEOUT, INC R2, DEC R3
858	003242	000002				RTI		:\$LPADR
859	003244	005737	001302		ERR:	TST	\$TMP2	:CHECK FLAG IF = 0 TYPE HEADER
860	003250	001014				BNE	1\$:SKIP HEADER
861	003252	104401				TYPE		:TYPEOUT HEADER MESSAGE
862	003254	010756				CONERR		:CONFIGURATION ERROR!!!!
863	003256	012737	003244	001460		MOV	#ERR,SAVPC	:SAVE PC FOR TYPEOUT
864	003264	104417				CNVRT		:TYPE OUT ERROR PC
865	003266	003322				ERRPC		:
866	003270	104401				TYPE		:TYPE REST OF HEADER
867	003272	011023				CNERR		:
868	003274	012737	177777	001302		MOV	#-1,\$TMP2	:SET FLAG SO IT ONLY GETS TYPED ONCE
869	003302	010137	001264		1\$:	MOV	R1,\$REG1	:SAVE R1 FOR TYPEOUT
870	003306	104416				CONVRT		:
871	003310	003330				CONTAB		:TYPE CSR VALUES
872	003312	104401			3\$:	TYPE		
873	003314	011044				KMCM		
874	003316	022626			4\$:	CMP	(SP)+,(SP)+	:ADJUST STACK
875	003320	000737				BR	OK	:BR TO GET OUT
876	003322	000001			ERRPC:	1		
877	003324	006		002		.BYTE	6,2	
878	003326	001460				SAVPC		
879	003330	000002			CONTAB:	2		
880	003332	006		004		.BYTE	6,4	
881	003334	001264				\$REG1		
882	003336	006		002		.BYTE	6,2	
883	003340	002066				KMCSR		
884	003342	007			DEVTAB:	.BYTE	7	
885	003343	017				.BYTE	17	
886	003344	007				.BYTE	7	
887	003345	007				.BYTE	7	
888	003346	007				.BYTE	7	
889	003347	007				.BYTE	7	
890	003350	007				.BYTE	7	
891	003351	007				.BYTE	7	
892	003352	007				.BYTE	7	

08-JUN-78 07:54 PAGE 20
 CZKCGA.P11 08-JUN-78 07:53

PAGE: 0032C2

PROGRAM INITIALIZATION AND START UP.

893	003354			.EVEN		
894	003354			AUDONE:		
895	003354	012637	000006	1\$: MOV (SP)+, #6	; RESTORE LOC 6	
896	003360	012637	000004	MOV (SP)+, #4	; RESTORE LOC 4	
897	003364	032737	000010	BIT #SW03, STRTSW	; SELECT SPECIFIC DEVICES??	
898	003372	001422		BEQ 3\$; BR IF NO.	
899	003374	104401	010013	TYPE MNEW	; TYPE THE MESSAGE.	
900	003400	005000		CLR R0	; ZERO DATA LIGHTS	
901	003402	000000		HALT	; WAIT FOR USER TO TELL WHAT DEVICES TO RUN	
902	003404	027737	175630	CMP #SWR, SAVACT	; IS THE NUMBER VALID?	
903	003412	101404		BLOS 2\$; BR IF NUMBER IS OK.	
904	003414	104401	007666	TYPE ,MERR3	; TELL USER OF INVALID NUMBER.	
905	003420	000000		HALT	; STOP EVERY THING.	
906	003422	000776		BR .-2	; RESTART THE PROGRAM AGAIN.	
907	003424	017737	175610	001470	MOV #SWR, KMACTV	; GET NEW DEVICE PATTERN
908	003432	013700	001470	MOV KMACTV, R0	; SHOW THE USER WHAT HE SELECTED.	
909	003436	000000		HALT	; CONTINUE DYNAMIC SWITCHES.	
910	003440	012700	000300	MOV #300, R0	; PREPARE TO CLEAR THE FLOATING	
911	003444	012701	000302	MOV #302, R1	; VECTOR AREA. 300-776	
912	003450	010120		MOV R1, (R0)+	; START PUTTING 'PC+2 - HALT'	
913	003452	005021		CLR (R1)+	; IN VECTOR AREA.	
914	003454	022021		CMP (R0)+, (R1)+	; POP POINTERS	
915	003456	022700	001007	CMP #1000, R0	; ALL DONE??	
916	003462	001372		BNE 4\$; BR IF NO.	
917						
918				: TEST START AND RESTART		
919				-----		
920						
921	003464	012706	001200	.BEGIN: MOV #STACK, SP	; SET UP STACK	
922	003470	013746	000006	MOV #6, -(SP)	; SAVE LOC 6	
923	003474	013746	000004	MOV #4, -(SP)	; SAVE LOC 4	
924	003500	005000		CLR R0	; START AT 0	
925	003502	012737	003546	MOV #2\$, #4	; SET UP FOR TIME OUT	
926	003510	005037	000006	CLR #6	; TO AUTOSIZE MEMORY	
927	003514	005720		TST (R0)+	; CHECK ADDRESS IN R0	
928	003516	022700	157776	CMP #157776, R0	; IS IT AT LEAST 28K	
929	003522	001374		BNE 6\$; BR IF NO	
930	003524	162700	007776	SUB #7776, R0	; SAVE 2K FOR MONITORS	
931	003530	010037	001466	MOV R0, MEMLIM	; STORE MEMORY LIMIT	
932	003534	012637	000004	MOV (SP)+, #4	; RESTORE LOC 4	
933	003540	012637	000006	MOV (SP)+, #6	; RESTORE LOC 6	
934	003544	000413		BR 10\$; CONTINUE	
935	003546	022626		CMP (SP)+, (SP)+	; ADJUST STACK	
936	003550	162700	000004	SUB #4, R0	; GET LAST GOOD ADDRESS	
937	003554	162700	007776	SUB #7776, R0	; SAVE 2K FOR MONITORS	
938	003560	022700	030000	CMP #30000, R0	; IS IT 8K?	
939	003564	001361		BNE 7\$; BR IF NO	
940	003566	012700	037400	MOV #37400, R0	; IF 8K DON'T SAVE 2K	
941	003572	000756		BR 7\$		
942	003574	012737	000340	177776	.LOCK OUT INTERRUPTS	
943	003602	032737	000004	001446	; CHECK FOR LOCK ON TEST	
944	003610	001406		BIT #BIT2, STRTSW	; BR IF NO LOCK DESIRED.	
945	003612	104401	007712	BEQ 1\$; TYPE LOCK SELECTED.	
946	003616	012737	000240	004146	MOV ,MLOCK	
947	003624	000403		MOV #NOP, TTST	; SET UP TO LOCK	
948	003626	013737	004354	004146	BR 3\$; CONTINUE ALONG.
				MOV BRW, TTST	; PREPARE NORMAL SCOPE ROUTINE	

08-JUN-78 07:54 PAGE 21
CZKCGA.P11 08-JUN-78 07:53

H 3

PAGE: 0053C2

PROGRAM INITIALIZATION AND START UP.

949 003634 012737 011474 001206	3\$: MOV #CYCLE,\$LPADR	:START AT ''CYCLE'' FIND WHICH DEVICE TO TEST
950 003642 032737 000002 001446	4\$: BIT #SW01,STRTSW	:IS TEST NO. SELECTED?
951 003650 001002	BNE 5\$:BR IF YES
952 003652 104401 007636	TYPE ,MR	:TYPE R
953 003656 000177 175324	5\$: JMP @\$LPADR	:START TESTING

END OF PASS ROUTINE

954 ;END OF PASS
 955 ;TYPE NAME OF TEST
 956 ;UPDATE PASS COUNT
 957 ;CHECK FOR EXIT TO ACT-11
 958 ;RESTART TEST
 959

960 .SBTTL END OF PASS ROUTINE

961
 962 ;*****
 963 ;*INCREMENT THE PASS NUMBER (\$PASS)
 964 ;*IF THERE'S A MONITOR GO TO IT
 965 ;*IF THERE ISN'T JUMP TO CYCLE
 966

967 \$EOP:

RESET			
INC	\$PASS	INCREMENT THE PASS COUNT	
CLRB	\$ERFLG	CLEAR ERROR FLAG	
TYPE	,MEPASS	TYPE END PASS.	
TYPE	,MCSRX	TYPE 'CSR'	
CNVRT	,XCSR	SHOW IT.	
TYPE	,MVECX	TYPE VECTOR.	
CNVRT	,XVEC	SHOW IT.	
TYPE	,MPASSX	TYPE "PASSES "	
CNVRT	,XPASS	SHOW IT.	
TYPE	,MERRX	TYPE "ERRORS "	
CNVRT	,XERR	SHOW IT.	
MOV	MILK, R0	SET POINTER TO PASSCNT.	
MOV	\$PASS,(R0)+	SAVE THE PASS COUNT.	
MOV	SERTTL,(R0)+	SAVE ERROR COUNT	
MOV	KMRLVL, ^a KMRVEC	RESTORE THE RECEIVER INTERRUPT VECTOR.	
CLR	^a KMRLVL	RESTORE RECEIVER LEVEL	
MOV	KMTLVL, ^a KMTVEC	RESTORE THE TRANSMITTER INTERRUPT VECTOR.	
CLR	^a KMTLVL	RESTORE TRANSMITTER LEVEL	
DEC	SAVNUM	ALL DEVICE TESTED?	
BNE	\$DOAGN	BRANCH IF NO.	
MOVB	#377,QV,FLG	SET QUICK VERIFY FLAG.	
MOV	KNUM, SAVNUM	RESTORE DEVICE COUNT.	
CLR	SERRPC	CLEAR LAST ERROR PC	
CLR	STIMES	ZERO THE NUMBER OF ITERATIONS	
INC	\$PASS	INCREMENT THE PASS NUMBER	
BIC	#100000,\$PASS	DON'T ALLOW A NEG. NUMBER	
DEC	(PC)+	LOOP?	

996 \$EOPCT: .WORD

BGT	\$DOAGN	;;YES
MOV	(PC)+, ^a (PC)+	;;RESTORE COUNTER

998 \$ENDCT: .WORD

\$EOPCT

1000 \$GET42: MOV

^a #42,R0	;;GET MONITOR ADDRESS	
BEQ	\$DOAGN	;;BRANCH IF NO MONITOR

1002 \$SENDAD: RESET

1003 \$SENDAD: JSR

1004 NOP

1005 NOP

1006 NOP

1007 NOP

1008 \$DOAGN:

JMP

1009 ^a(PC)+

;;CLEAR THE WORLD

;;GO TO MONITOR

;;SAVE ROOM

;;FOR

;;ACT11

;;RETURN

END OF PASS ROUTINE

```

1010 004102 011474
1011 004104 000001
1012 004106 006      002
1013 004110 002066
1014 004112 000001
1015 004114 004      002
1016 004116 002056
1017 004120 000001
1018 004122 006      002
1019 004124 001324
1020 004126 000001
1021 004130 006      002
1022 004132 001212
1023
1024 :SCOPE LOOP AND INTERATION HANDLER
1025 ;-----
1026
1027 .SBTTL SCOPE HANDLER ROUTINE
1028
1029 ;*****
1030 ;*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
1031 ;*AND LOAD THE TEST NUMBER($STSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
1032 ;*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
1033 ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
1034 ;*SW14=1    LOOP ON TEST
1035 ;*SW11=1    INHIBIT ITERATIONS
1036 ;*CALL      SCOPE      ;:SCOPE=IOT
1037
1038
1039 004134
1040 004134 005037 001216
1041 004140 023716 013764
1042 004144 001413
1043 004146 000406
1044 004150 105777 175070
1045 004154 100065
1046 004156 017766 175064 177776
1047 004164 032777 040000 175046
1048 004172 001056
1049
1050 004174 000416
1051
1052 004176 013746 000004
1053 004202 012737 004222 000004
1054 004210 005737 177060
1055 004214 012637 000004
1056 004220 000436
1057 004222 022626
1058 004224 012637 000004
1059 004230 000437
1060 004232
1061 004232 105737 001203
1062 004236 001404
1063 004240 105037 001203
1064 004244 005037 001310
1065 004250 032777 004000 174762

$RTNAD: WORD CYCLE
XCSR: 1
        .BYTE 6,2
        KMCSR
XVEC: 1
        .BYTE 4,2
        KMRVEC
XPASS: 1
        .BYTE 6,2
        $PASS
XERR: 1
        .BYTE 6,2
        $ERTTL

:SCOPE LOOP AND INTERATION HANDLER
;-----

.SBTTL SCOPE HANDLER ROUTINE

;*****
;*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
;*AND LOAD THE TEST NUMBER($STSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
;*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
;*SW14=1    LOOP ON TEST
;*SW11=1    INHIBIT ITERATIONS
;*CALL      SCOPE      ;:SCOPE=IOT

$SCOPE:
        CLR    $ERRPC          ;: CLEAR LAST ERROR PC
        CMP    TST1+2,(SP)      ;: IS THIS TEST #1 ?
        BEQ    $XTSTR          ;: IF SO DON'T LOOP.
TTST:   BR    1$              ;:
        TSTB   @STKS           ;: KEYBOARD DONE ?
        BPL    $OVER            ;: IF NO DONT WAIT.
        MOV    @STKB,-2(SP)      ;:
1$:    BIT    #BIT14,@SWR          ;:LOOP ON PRESENT TEST?
        BNE    $OVER            ;:YES IF SW14=1
;:NNNNNNSTART OF CODE FOR THE XOR TESTERNNNNN
$XTSTR: BR    6$              ;:
        6$:    ;:IF RUNNING ON THE 'XOR' TESTER CHANGE
        ;:THIS INSTRUCTION TO A 'NOP' (NOP=240)
        MOV    @ERRVEC,-(SP)      ;:SAVE THE CONTENTS OF THE ERROR VECTOR
        MOV    #5$,@ERRVEC        ;:SET FOR TIMEOUT
        TST    @177060          ;:TIME OUT ON XOR?
        MOV    (SP)+,@ERRVEC      ;:RESTORE THE ERROR VECTOR
        BR    $SYLAD             ;:GO TO THE NEXT TEST
5$:    CMP    (SP)+,(SP)+        ;:CLEAR THE STACK AFTER A TIME OUT
        MOV    (SP)+,@ERRVEC      ;:RESTORE THE ERROR VECTOR
        BR    $OVER              ;:LOOP ON THE PRESENT TEST
6$:    ;:NNNNNNEND OF CODE FOR THE XOR TESTERNNNNN
2$:    TSTB   $ERFLG           ;:HAS AN ERROR OCCURRED
        BEQ    3$              ;:BR IF NO
4$:    CLRB   $ERFLG           ;:ZERO THE ERROR FLAG
        CLR    $TIMES            ;:CLEAR THE NUMBER OF ITERATIONS TO MAKE
3$:    BIT    #BIT11,@SWR          ;:INHIBIT ITERATIONS?

```

SCOPE HANDLER ROUTINE

```

1066 004256 001011
1067 004260 005737 001324
1068 004264 001406
1069 004266 005237 001204
1070 004272 023737 001310 001204
1071 004300 002013
1072 004302 012737 000001 001204
1073 004310 013737 004356 001310
1074 004316 113737 001202 001322
1075 004324 011637 001206
1077 004330 013777 001202 174704
1078 004336 013716 001206
1079 004342 005037 001444
1080 004346 013701 002066
1081 004352 000002
1082 004354 000406
1083 004356 000020
1084
1085
1086
1087
1088 004360 004737 011226
1089 004364 032777 001000 174646
1090 004372 001405
1091 004374 005737 001444
1092 004400 001402
1093 004402 013716 001444
1094 004406 000002
1095
1096
1097
1098
1099
1100
1101
1102
1103
1104
1105
1106
1107
1108
1109
1110
1111
1112
1113
1114
1115
1116 004410 105737 001257
1117 004414 100002
1118 004416 000000
1119 004420 000430
1120 004422 010046
1121 004424 017600 000002

      BNE    1$          ;:BR IF YES
      TST    $PSS          ;:IF FIRST PASS OF PROGRAM
      BEQ    1$          ;:INHIBIT ITERATIONS
      INC    $ICNT         ;:INCREMENT ITERATION COUNT
      CMP    $TIMES,$ICNT   ;:CHECK THE NUMBER OF ITERATIONS MADE
      BGE    $OVER          ;:BR IF MORE ITERATION REQUIRED
      1$:    MOV    #1,$ICNT   ;:REINITIALIZE THE ITERATION COUNTER
      MOV    $MXCNT,$TIMES   ;:SET NUMBER OF ITERATIONS TO DO
      $SVLAD: ;INC B      $TSTMN          ;:COUNT TEST NUMBERS
      MOV    $TSTMN,$TESTN    ;:SET TEST NUMBER IN APT MAILBOX
      MOV    (SP),$LPADR     ;:SAVE SCOPE LOOP ADDRESS
      $OVER:  MOV    $TSTMN,$DISPLAY   ;:DISPLAY TEST NUMBER
      MOV    $LPADR,(SP)      ;:FUDGE RETURN ADDRESS
      CLR    LOCK           ;:RESET LOCK ON DATA.
      MOV    KMCSR,R1        ;: R1 CONTAINS BASE KMC ADDRESS.

      RTI
      BRW    WORD 406
      $MXCNT: 20            ;:MAX. NUMBER OF ITERATIONS

      ;-----;CHECK FOR FREEZE ON CURRENT DATA
      ;-----;

      .SCOP1: JSR    PC,CKSWR      ;:CHECK FOR SOFT SWR
      BIT    #SW09,$SWR        ;:IS SW09=1(SET)?
      BEQ    1$          ;:BR IF NOT SET.
      TST    LOCK           ;:GOTO THE ADDRESS IN LOCK.
      BEQ    1$          ;:GO BACK.

      ;-----;TELETYPE OUTPUT ROUTINE
      ;-----;

      .SBTTL TYPE ROUTINE

      ****
      ;ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
      ;THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
      ;NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
      ;NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
      ;NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
      ;*
      ;CALL:
      ;1) USING A TRAP INSTRUCTION
      ;   TYPE ,MESADR          ;:MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
      ;OR
      ;*
      ;   TYPE
      ;   MESADR
      ;*
      ;TYPE
      ;MESADR

      $TYPE: TSTB $TPFLG       ;:IS THERE A TERMINAL?
      BPL    1$          ;:BR IF YES
      HALT
      BR    3$          ;:HALT HERE IF NO TERMINAL
      1$:    MOV    R0,-(SP)    ;:LEAVE
      MOV    @2(SP),R0      ;:SAVE R0
      ;GET ADDRESS OF ASCIZ STRING

```

08-JUN-78 07:54 PAGE 25
CZKCGA.P11 08-JUN-78 07:53

L 3

PAGE: 0037C2

TYPE ROUTINE

1122	004430	122737	000001	001336	CMPB	#APTEV,SENV	;;RUNNING IN APT MODE
1123	004436	001011			BNE	62\$;NO GO CHECK FOR APT CONSOLE
1124	004440	132737	000100	001337	BITB	#APTSPOOL,SENVM	;SPOOL MESSAGE TO APT
1125	004446	001405			BEQ	62\$;NO GO CHECK FOR CONSOLE
1126	004450	010037	004460		MOV	R0,61\$;SETUP MESSAGE ADDRESS FOR APT
1127	004454	004737	004700		JSR	PC,\$ATY3	;SPOOL MESSAGE TO APT
1128	004460	000000			61\$: WORD	0	;MESSAGE ADDRESS
1129	004462	132737	000040	001337	62\$: BITB	#APTCSP,SENVM	;APT CONSOLE SUPPRESSED
1130	004470	001003			2\$: BNE	60\$;YES, SKIP TYPE OUT
1131	004472	112046			MOV	(R0)+,-(SP)	;PUSH CHARACTER TO BE TYPED ONTO STACK
1132	004474	001005			BNE	4\$;BR IF IT ISN'T THE TERMINATOR
1133	004476	005726			TST	(SP)+	;IF TERMINATOR POP IT OFF THE STACK
1134	004500	012600			MOV	(SP)+,R0	;RESTORE R0
1135	004502	062716	000002		ADD	#2,(SP)	;ADJUST RETURN PC
1136	004506	000002			RTI		;RETURNS
1137	004510	122716	000011		CMPB	#HT,(SP)	;BRANCH IF <HT>
1138	004514	001430			BEQ	8\$	
1139	004516	122716	000200		CMPB	#(CRLF),(SP)	;BRANCH IF NOT <CRLF>
1140	004522	001006			BNE	5\$	
1141	004524	005726			TST	(SP)+	;POP <CR><LF> EQUIV
1142	004526	104401			TYPE		;TYPE A CR AND LF
1143	004530	001313			SCRFL		
1144	004532	105037	004666		CLRB	\$CHARCNT	;CLEAR CHARACTER COUNT
1145	004536	000755			BR	2\$;GET NEXT CHARACTER
1146	004540	004737	004622		JSR	PC,\$TYPEC	;GO TYPE THIS CHARACTER
1147	004544	123726	001256		6\$: CMPB	\$FILLC,(SP)+	;IS IT TIME FOR FILLER CHARS.?
1148	004550	001350			BNE	2\$;IF NO GO GET NEXT CHAR.
1149	004552	013746	001254		MOV	\$NULL,-(SP)	;GET # OF FILLER CHARS. NEEDED
1150							;AND THE NULL CHAR.
1151	004556	105366	000001		7\$: DECB	1(SP)	;DOES A NULL NEED TO BE TYPED?
1152	004562	002770			BLT	6\$;BR IF NO--GO POP THE NULL OFF OF STACK
1153	004564	004737	004622		JSR	PC,\$TYPEC	;GO TYPE A NULL
1154	004570	105337	004666		DECB	\$CHARCNT	;DO NOT COUNT AS A COUNT
1155	004574	000770			BR	7\$;LOOP
1156					;HORIZONTAL TAB PROCESSOR		
1158					8\$: MOV	" ,(SP)	;REPLACE TAB WITH SPACE
1159	004576	112716	000040		9\$: JSR	PC,\$TYPEC	;TYPE A SPACE
1160	004602	004737	004622		BITB	#7,\$CHARCNT	;BRANCH IF NOT AT
1161	004606	132737	000007	004666	BNE	9\$;TAB STOP
1162	004614	001372			TST	(SP)+	;POP SPACE OFF STACK
1163	004616	005726			BR	2\$;GET NEXT CHARACTER
1164	004620	000724			STYPEC	TSTB a\$TPS	;WAIT UNTIL PRINTER IS READY
1165	004622	105777	174422		BPL	\$TYPEC	
1166	004626	100375			MOV	2(SP),a\$TPB	;LOAD CHAR TO BE TYPED INTO DATA REG.
1167	004630	116677	000002	174414	CMPB	#(CR,2(SP))	;IS CHARACTER A CARRIAGE RETURN?
1168	004636	122766	000015	000002	BNE	1\$;BRANCH IF NO
1169	004644	001003			CLRB	\$CHARCNT	;YES--CLEAR CHARACTER COUNT
1170	004646	105037	004666		BR	STYPEX	;EXIT
1171	004652	000406			1\$: CMPB	#LF,2(SP)	;IS CHARACTER A LINE FEED?
1172	004654	122766	000012	000002	BEQ	STYPEX	;BRANCH IF YES
1173	004662	001402			INC	(PC)+	;COUNT THE CHARACTER
1174	004664	105227			\$CHARCNT:WORD	0	;CHARACTER COUNT STORAGE
1175	004666	000000			\$TYPEX: RTS	PC	
1176	004670	000207					
1177							

APT COMMUNICATIONS ROUTINE

```

1178          .SBTTL APT COMMUNICATIONS ROUTINE
1179
1180          ;*****
1181 004672 112737 000001 005136      $ATY1: MOVB #1,$FFLG    ;:TO REPORT FATAL ERROR
1182 004700 112737 000001 005134      $ATY3: MOVB #1,$MFLG    ;:TO TYPE A MESSAGE
1183 004706 000403
1184 004710 112737 000001 005136      $ATY4: MOVB #1,$FFLG    ;:TO ONLY REPORT FATAL ERROR
1185 004716
1186 004716 010046
1187 004720 010146
1188 004722 105737 005134
1189 004726 001450
1190 004730 122737 000001 001336      SATYC:             BR   SATYC
1191 004736 001031
1192 004740 132737 000100 001337      CMPB #APTEENV,$ENV
1193 004746 001425
1194 004750 017600 000004
1195 004754 062766 000002 000004      BNE 3$           ;:OPERATING UNDER APT?
1196 004762 005737 001316            BEQ 5$           ;:IF NOT: BR
1197 004766 001375            BEQ 3$           ;:IF NOT: BR
1198 004770 010037 001332            TSTB SMFLG      ;:SHOULD TYPE A MESSAGE?
1199 004774 105720
1200 004776 001376
1201 005000 163700 001332            MOV  R0,-(SP)   ;:PUSH R0 ON STACK
1202 005004 006200
1203 005006 010037 001334            MOV  R1,-(SP)   ;:PUSH R1 ON STACK
1204 005012 012737 000004 001316      TSTB SMFLG      ;:SHOULD TYPE A MESSAGE?
1205 005020 000413
1206 005022 017637 000004 005046      ADD  #2,4(SP)   ;:GET MESSAGE ADDR.
1207 005030 062766 000002 000004      ADD  #2,4(SP)   ;:BUMP RETURN ADDR.
1208 005036 013746 177776
1209 005042 004737 004410            MOV  177776,-(SP);:PUSH 177776 ON STACK
1210 005046 000000            JSR  PC,$TYPE   ;:CALL TYPE MACRO
1211 005050
1212 005050 105737 005136            SUB  $MSGAD,RO  ;:SUB START OF MESSAGE
1213 005054 001416            ASR  R0           ;:GET MESSAGE LENGTH IN WORDS
1214 005056 005737 001336            MOV  R0,$MSGLGT  ;:PUT LENGTH IN MAILBOX
1215 005062 001413            MOV  #4,$MSGTYPE ;:TELL APT TO TAKE MSG.
1216 005064 005737 001316            BR   5$           ;:FINISHED LAST MESSAGE?
1217 005070 001375
1218 005072 017637 000004 001320      10$: TSTB $FFLG    ;:SHOULD REPORT FATAL ERROR?
1219 005100 062766 000002 000004      BEQ 12$           ;:IF NOT: BR
1220 005106 005237 001316            TST  SENV        ;:RUNNING UNDER APT?
1221 005112 105037 005136            BEQ 12$           ;:IF NOT: BR
1222 005116 105037 005135            T11$: TST  $MSGTYPE ;:FINISHED LAST MESSAGE?
1223 005122 105037 005134            BNE 11$           ;:IF NOT: WAIT
1224 005126 012601
1225 005130 012600
1226 005132 000207
1227 005134 000
1228 005135 000
1229 005136 000            INC  $MSGTYPE  ;:TELL APT TO TAKE ERROR
1230          005140
1231          000200
1232          000001
1233          000100            CLR  $FFLG      ;:CLEAR FATAL FLAG
1234          .EVEN
1235          APTSIZE=200
1236          APTENV=001
1237          APTSPPOOL=100            CLR  $LFLG      ;:CLEAR LOG FLAG
1238          CLR  $MFLG      ;:CLEAR MESSAGE FLAG
1239          MOV  (SP)+,R1    ;:POP STACK INTO R1
1240          MOV  (SP)+,R0    ;:POP STACK INTO R0
1241          RTS  PC         ;:RETURN
1242          $MFLG: .BYTE 0   ;:MESSG. FLAG
1243          $LFLG: .BYTE 0   ;:LOG FLAG
1244          $FFLG: .BYTE 0   ;:FATAL FLAG

```

08-JUN-78 07:54 PAGE 27
CZKCGA.P11 08-JUN-78 07:53

PAGE: 0039C

APT COMMUNICATIONS ROUTINE

```

1234      000040          APTCSUP=040
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253 005140 011646
1254 005142 016666 000004 000002
1255 005150 105777 174070
1256 005154 100375
1257 005156 117766 174064 000004
1258 005164 042766 177600 000004
1259 005172 026627 000004 000023
1260 005200 001013
1261 005202 105777 174036
1262 005206 100375
1263 005210 117746 174032
1264 005214 042716 177600
1265 005220 022627 000021
1266 005224 001366
1267 005226 000750
1268 005230 026627 000004 000140
1269 005236 002407
1270 005240 026627 000004 000175
1271 005246 003003
1272 005250 042766 000040 000004
1273 005256 000002
1274
1275
1276
1277
1278
1279
1280
1281 005260 010346
1282 005262 005046
1283 005264 012703 005514
1284 005270 022703 005523
1285 005274 101456
1286 005276 104402
1287 005300 112613
1288 005302 122713 000177
1289 005306 001022

          ;-----  

          .SBTTL TTY INPUT ROUTINE  

          ;*****  

          .ENABL LSB  

          .DSABL LSB  

          ;*****  

          ;*THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY  

          ;*CALL:  

          ;*      RDCHR          ;:INPLT A SINGLE CHARACTER FROM THE TTY  

          ;*      RETURN HERE     ;:CHARACTER IS ON THE STACK  

          ;*                          ;:WITH PARITY BIT STRIPPED OFF  

          ;*  

          ;*  

          ;*SRDCHR: MOV      (SP),-(SP)      ;:PUSH DOWN THE PC  

          ;*      MOV      4(SP),2(SP)      ;:SAVE THE PS  

          ;*      1$:    TSTB    @STKS        ;:WAIT FOR  

          ;*              BPL     1$          ;:A CHARACTER  

          ;*              MOVB    @STKB,4(SP)    ;:READ THE TTY  

          ;*              BIC     #^C<177>,4(SP)  ;:GET RID OF JUNK IF ANY  

          ;*              CMP     4(SP),#23    ;:IS IT A CONTROL-S?  

          ;*              BNE     3$          ;:BRANCH IF NO  

          ;*              TSTB    @STKS        ;:WAIT FOR A CHARACTER  

          ;*              BPL     2$          ;:LOOP UNTIL ITS THERE  

          ;*              MOVB    @STKB,-(SP)    ;:GET CHARACTER  

          ;*              BIC     #^C177,(SP)   ;:MAKE IT 7-BIT ASCII  

          ;*              CMP     (SP)+,#21    ;:IS IT A CONTROL-Q?  

          ;*              BNE     2$          ;:IF NOT DISCARD IT  

          ;*              BR     1$          ;:YES, RESUME  

          ;*              CMP     4(SP),#140    ;:IS IT UPPER CASE?  

          ;*              BLT     4$          ;:BRANCH IF YES  

          ;*              CMP     4(SP),#175    ;:IS IT A SPECIAL CHAR?  

          ;*              BGT     4$          ;:BRANCH IF YES  

          ;*              BIC     #40,4(SP)    ;:MAKE IT UPPER CASE  

          ;*              RTI               ;:GO BACK TO USER  

          ;*  

          ;******  

          ;*THIS ROUTINE WILL INPUT A STRING FROM THE TTY  

          ;*CALL:  

          ;*      RDLIN          ;:INPUT A STRING FROM THE TTY  

          ;*      RETURN HERE     ;:ADDRESS OF FIRST CHARACTER WILL BE ON THE STAC  

          ;*                          ;:TERMINATOR WILL BE A BYTE OF ALL 0'S  

          ;*  

          ;*SRDLIN: MOV      R3,-(SP)      ;:SAVE R3  

          ;*      CLR      -(SP)        ;:CLEAR THE RUBOUT KEY  

          ;*      1$:    MOV      #$TTYIN,R3    ;:GET ADDRESS  

          ;*      2$:    CMP      #$TTYIN+7,R3  ;:BUFFER FULL?  

          ;*              BLOS    4$          ;:BR IF YES  

          ;*              RDCHR          ;:GO READ ONE CHARACTER FROM THE TTY  

          ;*              MOVB    (SP)+(R3)    ;:GET CHARACTER  

          ;*              CMPB    #177,(R3)   ;:IS IT A RUBOUT  

          ;*              BNE     5$          ;:BR IF NO

```

08-JUN-78 07:54 PAGE 28
CZKCGA.P11 08-JUN-78 07:53

PAGE: 0040C2

TTY INPUT ROUTINE

```

1290 005310 005716          TST   (SP)      ;:IS THIS THE FIRST RUBOUT?
1291 005312 001007          BNE   6$       ;:BR IF NO
1292 005314 112737 000134 005512        MOVB  #'\' ,9$    ;:TYPE A BACK SLASH
1293 005322 104401 005512          TYPE   ,9$       ;:SET THE RUBOUT KEY
1294 005326 012716 177777          MOV    #'-,(SP)  ;:BACKUP BY ONE
1295 005332 005303          DEC    R3       ;:STACK EMPTY?
1296 005334 020327 005514          CMP    R3,#$TTYIN  ;:BR IF YES
1297 005340 103434          BLO    4$       ;:SETUP TO TYPEOUT THE DELETED CHAR.
1298 005342 111337 005512          MOVB  (R3),9$    ;:GO TYPE
1299 005346 104401 005512          TYPE   ,9$       ;:GO READ ANOTHER CHAR.
1300 005352 000746          BR    2$       ;:RUBOUT KEY SET?
1301 005354 005716          TST   (SP)      ;:BR IF NO
1302 005356 001406          BEQ   7$       ;:TYPE A BACK SLASH
1303 005360 112737 000134 005512        MOVB  #'\' ,9$    ;:CLEAR THE RUBOUT KEY
1304 005366 104401 005512          TYPE   ,9$       ;:IS CHARACTER A CTRL U?
1305 005372 005016          CLR    (SP)      ;:BR IF NO
1306 005374 122713 000025          CMPB  #25,(R3)  ;:TYPE A CONTROL 'U'
1307 005400 001003          BNE   8$       ;:GO START OVER
1308 005402 104401 005523          TYPE   .$CNTLU   ;:IS CHARACTER A '^R'?
1309 005406 000726          BR    1$       ;:BRANCH IF NO
1310 005410 122713 000022          CMPB  #22,(R3)  ;:CLEAR THE CHARACTER
1311 005414 001011          BNE   3$       ;:TYPE A 'CR' & 'LF'
1312 005416 105013          CLR8   (R3)      ;:TYPE THE INPUT STRING
1313 005420 104401 001313          TYPE   .$CRLF    ;:GO PICKUP ANOTHER CHACTER
1314 005424 104401 005514          TYPE   .$TTYIN   ;:TYPE A '?'
1315 005430 000717          BR    2$       ;:CLEAR THE BUFFER AND LOOP
1316 005432 104401 001312          TYPE   $QUES    ;:ECHO THE CHARACTER
1317 005436 000712          BR    1$       ;:CHECK FOR RETURN
1318 005440 111337 005512          3$:   MOVB  (R3),9$    ;:LOOP IF NOT RETURN
1319 005444 104401 005512          TYPE   ,9$       ;:CLEAR RETURN (THE 15)
1320 005450 122723 000015          CMPB  #15,(R3)+  ;:TYPE A LINE FEED
1321 005454 001305          BNE   2$       ;:RESTORE R3
1322 005456 105063 177777          CLR8   -1(R3)   ;:ADJUST THE STACK AND PUT ADDRESS OF THE
1323 005462 104401 001314          TYPE   .$LF     ;:FIRST ASCII CHARACTER ON IT
1324 005466 005726          TST    (SP)+   ;:RETURN
1325 005470 012603          MOV    (SP)+,R3  ;:STORAGE FOR ASCII CHAR. TO TYPE
1326 005472 011646          MOV    (SP),-(SP) ;:TERMINATOR
1327 005474 016666 000004 000002        MOV    4(SP),2(SP) ;:RESERVE 7 BYTES FOR TTY INPUT
1328 005502 012766 005514 000004        MOV    #$.TTYIN,4(SP) ;:CONTROL 'U'
1329 005510 000002          RTI
1330 005512 000          9$:   .BYTE  0       ;:CONTROL 'G'
1331 005513 000          STTYIN: .BLKB  7       ;:SMNEW: .ASCIZ / NEW = /
1332 005514 000007          .BYTE  0       ;:RESERVE 7 BYTES FOR TTY INPUT
1333 005523 136 006525 000012          $CNTLU: .ASCIZ /^U/<15><12> ;:CHANG
1334 005530 043536 005015 000          $CNTLG: .ASCIZ /^G/<15><12> ;:THE INPUT CHARACTERS WILL BE CHECKED TO INSURED THEY ARE LEGAL
1335 005535 015 051412 C51127          $MSWR: .ASCIZ <15><12>/SWR = /
1336 005542 036440 000040
1337 005546 020040 042516 020127
1338 005554 020075 000
1339 005560
1340
1341
1342
1343
1344
1345

```

;*THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
;*CHANGE IT TO BINARY.
;*THE INPUT CHARACTERS WILL BE CHECKED TO INSURED THEY ARE LEGAL

08-JUN-78 07:54 PAGE 29
CZKCGA.P11 08-JUN-78 07:53

PAGE: 0041C2

READ AN OCTAL NUMBER FROM THE TTY

```

1346          ;*OCTAL DIGITS. IF AN ILLEGAL CHARACTER IS READ A '?' WILL BE TYPED
1347          ;*FOLLOWED BY A CARRIAGE RETURN-LINE FEED. THE COMPLETE NUMBER MUST
1348          ;*THEN BE RETYPED. THE INPUT IS TERMINATED BY TYPING A CARRIAGE RETURN.
1349          ;*CALL:
1350          ;*      RDOCT
1351          ;*      RETURN HERE
1352          ;*      $RDOCT: MOV      (SP),-(SP)      ;:READ AN OCTAL NUMBER
1353          ;*                  MOV      4(SP),2(SP)    ;:LOW ORDER BITS ARE ON TOP OF THE STACK
1354          ;*                  MOV      R0,-(SP)    ;:HIGH ORDER BITS ARE IN $HIOCT
1355          ;*                  MOV      R1,-(SP)
1356          ;*                  MOV      R2,-(SP)
1357          ;*      1$:      RDLIN     (SP)+,R0      ;:READ AN ASCIZ LINE
1358          ;*                  MOV      R0,5$       ;:GET ADDRESS OF 1ST CHARACTER
1359          ;*                  CLR      R1       ;:AND SAVE IT
1360          ;*                  CLR      R2       ;:CLEAR DATA WORD
1361          ;*      2$:      MOVB     (R0)+,-(SP)   ;:PICKUP THIS CHARACTER
1362          ;*                  BEQ      3$       ;:IF ZERO GET OUT
1363          ;*                  CMPB     #'0,(SP)    ;:MAKE SURE THIS CHARACTER
1364          ;*                  BGT      4$       ;:IS AN OCTAL DIGIT
1365          ;*                  CMPB     #'7,(SP)
1366          ;*                  BLT      4$       ;::*2
1367          ;*                  ASL      R1       ;::*4
1368          ;*                  ROL      R2       ;::*8
1369          ;*      3$:      ASL      R1       ;:STRIP THE ASCII JUNK
1370          ;*                  ROL      R2       ;:ADD IN THIS DIGIT
1371          ;*                  ASL      R1       ;:LOOP
1372          ;*                  ROL      R2
1373          ;*                  ASL      R1
1374          ;*                  ROL      R2
1375          ;*      4$:      BIC      #^C7,(SP)   ;:CLEAN TERMINATOR FROM STACK
1376          ;*                  ADD      (SP)+,R1    ;:SAVE THE RESULT
1377          ;*                  BR      2$       ;:POP STACK INTO R2
1378          ;*      5$:      TST      (SP)+     ;:POP STACK INTO R1
1379          ;*                  MOV      R1,12(SP)   ;:POP STACK INTO R0
1380          ;*                  MOV      R2,$HIOCT
1381          ;*                  MOV      (SP)+,R2
1382          ;*                  MOV      (SP)+,R1
1383          ;*                  MOV      (SP)+,R0
1384          ;*      RTI
1385          ;*      6$:      TST      (SP)+     ;:RETURN
1386          ;*                  CLR8     (R0)
1387          ;*                  TYPE
1388          ;*                  TYPE
1389          ;*      7$:      .WORD    0        ;:CLEAN PARTIAL FROM STACK
1390          ;*                  TYPE    '$UES'    ;:SET A TERMINATOR
1391          ;*                  BR      1$       ;:TYPE UP THRU THE BAD CHAR.
1392          ;*      $HIOCT: .WORD    0        ;:'?' 'CR' & 'LF'
1393          ;*                  .WORD    0        ;:TRY AGAIN
1394          ;*                  .WORD    0        ;:HIGH ORDER BITS GO HERE
1395          ;*      INPUT OCTAL NUMBER ROUTINE
1396          ;*-----
1397          ;*      $INPUT: MOV      R5,-(SP)    ;: SAVE REGISTER R5.
1398          ;*                  MOV      2(SP),R5    ;: GET FIRST PARAMETER ADDRESS.
1399          ;*                  MOV      (R5)+,WHAT   ;: GET MESSAGE ADDRESS.
1400          ;*                  MOV      (R5)+,LOLIM   ;: GET LOW LIMIT FOR THE #
1401          ;*                  MOV      (R5)+,HILIM   ;: GET HIGH LIMIT FOR THE #.

```

08-JUN-78 07:54 PAGE 30
CZKCGA.P11 08-JUN-78 07:53

PAGE: 0042C2

READ AN OCTAL NUMBER FROM THE TTY

```

1402 005742 012537 006050      MOV    (R5)+,WHERE      ; GET ADDRESS OF INBUFFER
1403 005746 112537 006052      MOVB   (R5)+,LOBITS   ; GET LOWMASK BITS.
1404 005752 112537 006053      MOVB   (R5)+,ADRCNT   ; GET # OF #'S TO BE GENERATED.
1405 005756 010566 000002      MOV    R5,2(SP)     ; SAVE THE RETURN ADDRESS.
1406 005762 104401             INLP1: TYPE    .WORD 0      ; TYPE THE MESSAGE.
1407 005764 000000             WHAT:  RDOCT   0          ; READ OCTAL # FROM KEYBOARD.
1408 005766 104404             CMP    (SP),HILIM   ; IS IT IN HIGH LIMIT?
1409 005770 021637 006046             BGT    2$          ; BRANCH IF NO.
1410 005774 003003             CMP    (SP),LOLIM   ; IS IT MORE THAN LOW LIMIT.
1411 005776 021637 006044             BGE    3$          ; BRANCH IF YES.
1412 006002 002005             2$:   TYPE    ,$QUES    ; TYPE '?''
1413 006004 104401 001312             TYPE    ,$CRLF   ; TYPE <CR>,<LF>
1414 006010 104401 001313             BR     INLP1
1415 006014 000762             3$:   MOV    WHERE,R5    ; GET BUFFER ADDRESS.
1416 006016 013705 006050             MOV    (SP),(R5)+  ; SAVE THE # IN RIGHT PLACE.
1417 006022 011625             4$:   ADD    #2,(SP)    ; NEXT SEQUENTIAL NUMBER.
1418 006024 062716 000002             DECB   ADRCNT    ; COUNT BY 1.
1419 006030 105337 006053             BNE    4$          ; BRANCH IF NOT DONE.
1420 006034 001372             TST    (SP)+    ; POP THE STACK POINTER.
1421 006036 005726             MOV    (SP)+,R5    ; POP THE REG.S
1422 006040 012605             RTI
1423 006042 000002             LOLIM: .WORD 0
1424 006044 000000             HILIM: .WORD 0
1425 006046 000000             WHERE: .WORD 0
1426 006050 000000             LOBITS: .BYTE 0
1427 006052 000             ADRCNT: .BYTE 0
1428 006053 000
1429
1430             ; ADVANCE TO NEXT TEST HANDLER
1431
1432
1433 006054 013716 001442             .ADVANCE: MOV    NEXT,(SP)  ; CRUNCH STACK WITH ADDRESSOF SC
1434 006060 005037 001444             CLR    LOCK      ; RESET TIGHT LOOP ADDRESS
1435 006064 000002             RTI    : CHECK TO SEE IF OLD TEST GETS REPEATED
1436
1437             ;SAVE PC OF TEST THAT FAILED AND R0-R5
1438
1439
1440 006066 016637 000004 001460             .SAV05: MOV    4(SP),SAVPC  ;SAVE R7 (PC)
1441
1442             ;SAVE R0-R5
1443
1444 006074 010537 001274             SV05:  MOV    R5,$REG5    ;SAVE R5
1445 006100 010437 001272             MOV    R4,$REG4    ;SAVE R4
1446 006104 010337 001270             MOV    R3,$REG3    ;SAVE R3
1447 006110 010237 001266             MOV    R2,$REG2    ;SAVE R2
1448 006114 010137 001264             MOV    R1,$REG1    ;SAVE R1
1449 006120 010037 001262             MOV    R0,$REG0    ;SAVE R0
1450 006124 000002             RTI    :LEAVE.
1451
1452             ;RESTORE R0-R5
1453
1454 006126 013700 001262             .RES05: MOV    $REG0,R0    ;RESTORE R0
1455 006132 013701 001264             MOV    $REG1,R1    ;RESTORE R1
1456 006136 013702 001266             MOV    $REG2,R2    ;RESTORE R2
1457 006142 013703 001270             MOV    $REG3,R3    ;RESTORE R3

```

08-JUN-78 07:54 PAGE 31
CZKCGA.P11 08-JUN-78 07:53

PAGE: 0043C2

READ AN OCTAL NUMBER FROM THE TTY

1458	006146	013704	001272		MOV \$REG4,R4 ;RESTORE R4
1459	006152	013705	001274		MOV \$REG5,R5 ;RESTORE R5
1460	006156	000002			RTI ;LEAVE
1461				:	;-----
1462				:	;CONVERT OCTAL NUMBER TO ASCII AND OUTPUT TO TELEPRINTER
1463				:	-----
1464				:	
1465	006160	104401	001313	.CONVR:	TYPE \$CRLF
1466	006164	010046		.CNVRT:	MOV R0,-(SP)
1467	006166	010146			MOV R1,-(SP)
1468	006170	010346			MOV R3,-(SP)
1469	006172	010446			MOV R4,-(SP)
1470	006174	010546			MOV R5,-(SP)
1471	006176	017601	000012		MOV @12(SP),R1
1472	006202	062766	000002		ADD #2,12(SP)
1473	006210	012137	006402		MOV (R1)+,WRDCNT
1474	006214	112137	006404	1\$:	MOV B (R1)+,CHRCNT
1475	006220	112137	006405		MOV B (R1)+,SPACNT
1476	006224	013137	006406		MOV A(R1)+,BINWRD
1477	006230	122737	000003		CMPB #3,CHRCNT
1478	006236	001003			BNE 2\$
1479	006240	042737	177400		BIC #177400,BINWRD
1480	006246	013704	006406	2\$:	MOV BINWRD,R4
1481	006252	113705	006404		MOV B CHRCNT,R5
1482	006256	012700	011122		MOV #TEMP,R0
1483	006262	010403		3\$:	MOV R4,R3
1484	006264	042703	177770		BIC #177770,R3
1485	006270	062703	000060		ADD #060,R3
1486	006274	110320			MOV B R3,(R0)+
1487	006276	000241			CLC
1488	006300	006004			ROR R4
1489	006302	000241			CLC
1490	006304	006004			ROR R4
1491	006306	000241			CLC
1492	006310	006004			ROR R4
1493	006312	005305			DEC R5
1494	006314	001362			BNE 3\$
1495	006316	012703	011164	4\$:	MOV #MDATA,R3
1496	006322	114023			MOV B -(R0),(R3)+
1497	006324	105337	006404		DEC B CHRCNT
1498	006330	001374			BNE 4\$
1499	006332	105737	006405		TSTB SPACNT
1500	006336	001405		5\$:	BEQ 6\$
1501	006340	112723	000040		MOV B #040,(R3)+
1502	006344	105337	006405		DEC B SPACNT
1503	006350	001373			BNE 5\$
1504	006352	105013		6\$:	CLR B (R3)
1505	006354	104401	011164		TYPE .MDATA
1506	006360	005337	006402		DEC WRDCNT
1507	006364	001313			BNE 1\$
1508	006366	012605			MOV (SP)+,R5
1509	006370	012604			MOV (SP)+,R4
1510	006372	012603			MOV (SP)+,R3
1511	006374	012601			MOV (SP)+,R1
1512	006376	012600			MOV (SP)+,R0
1513	006400	000002			RTI

08-JUN-78 07:54 PAGE 32
CZKCGA.P11 08-JUN-78 07:53

F 4

PAGE: 004402

READ AN OCTAL NUMBER FROM THE TTY

1514 006402 000000 WRDCNT: 0
1515 006404 000000 CHRCNT: 0
1516 006405 SPACNT=CHRCNT+1
1517 006406 000000 BINWRD: 0
1518
1519 :TRAP DISPATCH SERVICE
1520 :ARGUMENT OF TRAP IS EXTRACTED
1521 :AND USED AS OFFSET TO OBTAIN POINTER
1522 :TO SELECTED SUBROUTINE
1523
1524
1525 .SBTTL TRAP DECODER
1526
1527 :*****
1528 :*THIS ROUTINE WILL PICKUP THE LOWER EYTE OF THE 'TRAP' INSTRUCTION
1529 :*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
1530 :*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
1531 :*GO TO THAT ROUTINE.
1532 006410 010046
1534 006412 016600 000002 \$TRAP: MOV R0,-(SP) ;:SAVE R0
1535 006416 005740 MOV 2(SP),R0 ;:GET TRAP ADDRESS
1536 006420 111000 TST -(R0) ;:BACKUP BY 2
1537 006422 006300 MOVB (R0),R0 ;:GET RIGHT BYTE OF TRAP
1538 006424 016000 006444 ASL R0 ;:POSITION FOR INDEXING
1539 006430 000200 MOV \$TRPAD(R0),R0 ;:INDEX TO TABLE
RTS R0 ;:GO TO ROUTINE
1540
1541
1542 :THIS IS USE TO HANDLE THE 'GETPRI' MACRO
1543
1544 006432 011646
1545 006434 016666 000004 000002 \$TRAP2: MOV (SP),-(SP) ;:MOVE THE PC DOWN
1546 006442 000002 MCV 4(SP),2(SP) ;:MOVE THE PSW DOWN
RTI ;:RESTORE THE PSW
1547
1548 .SBTTL TRAP TABLE
1549
1550 :*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
1551 :*BY THE 'TRAP' INSTRUCTION.
1552
1553 : ROUTINE
1554 :-----
1555 006444 006432 \$TRPAD: WORD \$TRAP2
1556 006446 004410 \$TYPE ;:CALL=TYPE TRAP+1(104401) TTY TYPEOUT ROUTINE
1557
1558 006450 005140 SRDCHR ;:CALL=RDCHR TRAP+2(104402) TTY TYPEIN CHARACTER ROUTINE
006452 005260 SRDLIN ;:CALL=RDLIN TRAP+3(104403) TTY TYPEIN STRING ROUTINE
006454 005560 SRDOCT ;:CALL=RDOCT TRAP+4(104404) READ AN OCTAL NUMBER FROM TTY
006456 004360 SCOP1 ;:CALL=SCOP1 TRAP+5(104405) CALL TO LOOP ON CURRENT DATA HAN
006460 006066 SAV05 ;:CALL=SAV05 TRAP+6(104406) CALL TO REGISTER SAVE ROUTINE
006462 006126 RES05 ;:CALL=RES05 TRAP+7(104407) CALL TO REGISTER RESTORE ROUTINE
006464 007356 MSTCLR ;:CALL=MSTCLR TRAP+10(104410) CALL TO ISSUE A MASTER CLEAR
006466 007326 DELAY ;:CALL=DELAY TRAP+11(104411) CALL TO DELAY
006470 007374 ROMCLK ;:CALL=ROMCLK TRAP+12(104412) CALL TO CLOCK ROM ONCE
006472 007442 DATACLK ;:CALL=DATACLK TRAP+13(104413) CALL TO CLOCK DATA
006474 007506 TIMER ;:CALL=TIMER TRAP+14(104414) CALL TO DELAY A CLOCK TICK

08-JUN-78 07:54 PAGE 33
CZKCGA.P11 08-JUN-78 07:53

PAGE: 0045C2

TRAP TABLE

1570	006476	005720		\$INPUT ;:CALL=INPUT	TRAP+15(104415) CALL TO OCTAL # INPUT ROUTINE
1571	006500	006160		.CONVRT ;:CALL=CONVRT	TRAP+16(104416) CALL TO
1572	006502	006164		.CNVRT ;:CALL=CNVRT	TRAP+17(104417) CALL TO
1573	006504	006054		.ADVANCE ;:CALL=ADVANCE	TRAP+20(104420) CALL TO ADVANCE TO NEXT
1574				:	
1575				-----	
1576				*****	
1577				:ERROR HANDLER	
1578				-----	
1579					
1580	006506	004737	011226	\$ERROR: JSR PC,CKSWR	:CHECK FCR SOFT SWR
1581	006512	032777	010000	BIT #SW12,ASWR	:BELL ON ERROR?
1582	006520	001406		BEQ XBX	:BR IF NO BELL
1583	006522	105777	172522	TSTB \$TPS	:TTY READY.
1584	006526	100003		BPL XBX	:DON'T WAIT IF TTY NOT READY.
1585	006530	112777	000207	MOV#207,\$TPB	:PUSH A BELL AT THE TTY.
1586	006536	032777	020000	XBX: BIT #SW13,ASWR	:DELETE ERROR PRINT OUT?
1587	006544	001107		BNE HALTS	:BR IF NO PRINT OUT WANTED.
1588	006546	021637	001216	CMP (SP),\$ERRPC	:WAS THIS ERROR FOUND LAST TIME?
1589	006552	001404		BEQ 1\$:BR IF YES
1590	006554	011637	001216	MOV (SP),\$ERRPC	:RECORD BEING HERE
1591	006560	105037	001203	CLRB \$ERFLG	:PREPARE HEADER
1592	006564	104406		1\$: SAV05	:SAVE ALL PROC REGISTERS
1593	006566	011605		MOV (SP),R5	:GET THE PC OF ERROR
1594	006570	162705	000002	SUB #2,R5	:GET ADDRESS OF TRAP CALL
1595	006574	011504		MOV (R5),R4	:GET ERROR INSTRUCTION
1596	006576	110437	001214	MOV R4,\$ITEMB	:COPY ERROR # FOR APT HANDLING
1597	006602	006304		ASL R4	:MULT BY TWO
1598	006604	061504		ADD (R5),R4	:DOUBLE IT
1599	006606	006304		ASL R4	:MULT AGAIN
1600	006610	042704	177001	BIC #177001,R4	:CLEAR JUNK
1601	006614	062704	001512	ADD #\$ERRRTB,R4	:GET POINTER
1602	006620	012437	006734	MOV (R4)+,ERRMSG	:GET ERROR MESSAGE
1603	006624	012437	006746	MOV (R4)+,DATAHD	:GET DATA HEADER
1604	006630	011437	006760	MOV (R4),DATABP	:GET DATA TABLE
1605	006634	105737	001203	TSTB \$ERFLG	:TYPE HEADREER
1606	006640	001403		BEQ TYPMSG	:BR IF YES
1607	006642	005737	006760	TST DATABP	:DOES DATA TABLE EXIST?
1608	006646	001040		BNE TYPDAT	:BR IF YES.
1609	006650	104401	001313	TYPMSG: TYPE ,\$CRLF	
1610	006654	104401	001313	TYPE ,\$CRLF	
1611	006660	005737	001444	TST LOCK	
1612	006664	001402		BEQ 1\$	
1613	006666	104401	010011	TYPE ,MASTEK	
1614	006672	104401	007777	1\$: TYPE ,MTSTN	
1615	006676	104417	007114	CNVRT ,XTSTN	:SHOW IT
1616	006702	104401	010066	TYPE ,MERRPC	:TYPE PC.
1617	006706	104417	007106	CNVRT ,ERTABO	:SHOW IT
1618	006712	104401	001313	TYPE ,\$CRLF	:GIVE A CR/LF
1619	006716	112737	177777	MOV#-1,\$ERFLG	:NO MORE HEADER UNLESS NO DATA TABLE.
1620	006724	005737	006734	TST ERRMSG	:IS THERE AN ERROR MESSAGE?
1621	006730	001402		BEQ WRKO.FM	:BR IF NO.
1622	006732	104401		TYPE	:TYPE
1623	006734	000000		WRKO.FM:	: ERROR MESSAGE
1624	006736			TST DATAHD	:DATA HEADER?
1625	006736	005737	006746		

TRAP TABLE

1626	006742	001402			BEQ	TYPDAT	:BR IF NO
1627	006744	104401			TYPE		:TYPE
1628	006746	000000			DATAHD:	0	:DATA HEADER
1629	006750	005737	006760		TYPDAT:	TST	:DATA TABLE?
1630	006754	001402				BEQ	:BR IF NO.
1631	006756	104416				RESREG	:SHOW
1632	006760	000000				CONVRT	:DATA TABLE
1633	006762	104407				DATABP	:RESTORE PROC REGISTERS
1634	006764	122737	000001	001336		RESREG:	#APTENV,\$ENV
1635	006772	001007				HALTS:	CMPB
1636	006774	113737	001214	007006		BNE	3\$
1637	007002	004737	004710			MOVB	\$ITEMB,6\$
1638	007006	000000				JSR	PC,\$ATY4
1639	007010	000777				6\$:	.WORD
1640	007012	022737	004070	000042		9\$:	0
1641	007020	001403				3\$:	BR
1642	007022	005777	172212				9\$
1643	007026	100005					CMP
1644	007030	010046					#SENDAD,2#42
1645	007032	016600	000002				BEQ
1646	007036	000000					1\$
1647	007040	012600					TST
1648	007042	005237	001212				@SWR
1649	007046	032777	000400	172164			BPL
1650	007054	001007					EXITER
1651	007056	032777	002000	172154			PUSHRO
1652	007064	001407					MOV
1653	007066	013737	001442	001206			2(SP),R0
1654	007074	012706	001200				HALT
1655	007100	000177	172102				POPRO
1656	007104	000002					EXITER:
1657	007106	000001					INC
1658	007110	006	002				\$ERTTL
1659	007112	001460					BIT
1660	007114	000001					#SW08,@SWR
1661	007116	003	002				BNE
1662	007120	001202					1\$
1663							BIT
1664							#SW10,@SWR
1665							BEQ
1666							2\$
1667							MOV
1668							NEXT,\$LPADR
1669							1\$:
1670	007122	012737	007312	000024			MOV
1671	007130	012737	000340	000026			#\$ILLUP,2#PWRVEC
1672	007136	010046					;:SET FOR FAST UP
1673	007140	010146				MOV	#340,2#PWRVEC+2
1674	007142	010246					;:PRI0:7
1675	007144	010346				MOV	R0,-(SP)
1676	007146	010446					;:PUSH R0 ON STACK
1677	007150	010546				MOV	R1,-(SP)
1678	007152	017746	172062				;:PUSH R1 ON STACK
1679	007156	010637	007316			MOV	R2,-(SP)
1680	007162	012737	007174	000024			;:PUSH R2 ON STACK
1681	007170	000000				MOV	R3,-(SP)
							;:PUSH R3 ON STACK
						MOV	R4,-(SP)
							;:PUSH R4 ON STACK
						MOV	R5,-(SP)
							;:PUSH R5 ON STACK
						MOV	@SWR,-(SP)
							;:PUSH @SWR ON STACK
						MOV	SP,\$SAVR6
							;:SAVE SP
						MOV	#\$PWRUP,2#PWRVEC
							;:SET UP VECTOR
						HALT	

.SBttl POWER DOWN AND UP ROUTINES

*****POWER DOWN ROUTINE*****

\$PWRDN: MOV #SILLUP,2#PWRVEC ;:SET FOR FAST UP
 MOV #340,2#PWRVEC+2 ;:PRI0:7
 MOV R0,-(SP) ;:PUSH R0 ON STACK
 MOV R1,-(SP) ;:PUSH R1 ON STACK
 MOV R2,-(SP) ;:PUSH R2 ON STACK
 MOV R3,-(SP) ;:PUSH R3 ON STACK
 MOV R4,-(SP) ;:PUSH R4 ON STACK
 MOV R5,-(SP) ;:PUSH R5 ON STACK
 MOV @SWR,-(SP) ;:PUSH @SWR ON STACK
 MOV SP,\$SAVR6 ;:SAVE SP
 MOV #\$PWRUP,2#PWRVEC ;:SET UP VECTOR

08-JUN-78 07:54 PAGE 35
 ZKCGA.P11 08-JUN-78 07:53

PAGE: 0047C2

POWER DOWN AND UP ROUTINES

```

1682 007172 000776           BR   .-2      ;;HANG UP
1683
1684
1685
1686 007174 012737 007312 000024
1687 007202 013706 007316
1688 007206 005037 007316
1689 007212 005237 007316
1690 007216 001375
1691 007220 104401 007556
1692 007224 104417 007320
1693 007230 105037 001203
1694 007234 005037 001216
1695 007240 013701 002066
1696 007244 005011
1697 007246 104410
1698 007250 012677 171764
1699 007254 012605
1700 007256 012604
1701 007260 012603
1702 007262 012602
1703 007264 012601
1704 007266 012600
1705 007270 012737 007122 000024
1706 007276 012737 000340 000026
1707 007304 104401
1708 007306 007556
1709 007310 000002
1710 007312 000000
1711 007314 000776
1712 007316 000000
1713
1714 007320 000001
1715 007322 003     002
1716 007324 001202
1717
1718 007326
1719 007326 012777 000020 172540
1720 007334 104412
1721 007336 121111
1722 007340
1723 007340 104412
1724 007342 121224
1725 007344 032777 000020 172522
1726 007352 001772
1727 007354 000002
1728
1729 007356
1730 007356 152777 000100 172504
1731 007364 142777 000300 172476
1732 007372 000002
1733
1734 007374
1735 007374 152777 000002 172466
1736 007402 013677 172470
1737 007406 062746 000002

          BR   .-2      ;;HANG UP
          *****:POWER UP ROUTINE*****
          $PWRUP: MOV    #$ILLUP, @#PWRVFC ;:SET FOR FAST DOWN
          MOV    $SAVR6, SP   ;:GET SP
          CLR    $SAVR6       ;:WAIT LOOP FOR THE TTY
          1$:   INC    $SAVR6       ;:WAIT FOR THE INC
          BNE    1$           ;:OF WORD
          TYPE   ,MPFAIL
          CNVRT ,PFTAB
          CLR    $ERFLG        ;:CLEAR ERROR FLAG.
          CLR    $ERRPC        ;:CLEAR LAST ERROR PC
          MOV    KMCSR, R1     ;:RESTORE DEVICE ADDRESS.
          CLR    (R1)
          MSTCLR
          MOV    (SP)+, @SWR   ;:POP STACK INTO @SWR
          MOV    (SP)+, R5     ;:POP STACK INTO R5
          MOV    (SP)+, R4     ;:POP STACK INTO R4
          MOV    (SP)+, R3     ;:POP STACK INTO R3
          MOV    (SP)+, R2     ;:POP STACK INTO R2
          MOV    (SP)+, R1     ;:POP STACK INTO R1
          MOV    (SP)+, R0     ;:POP STACK INTO R0
          MOV    #$PWRDN, @#PWRVEC ;:SET UP THE POWER DOWN VECTOR
          MOV    #340, @#PWRVEC+2 ;:PRIO:7
          TYPE   ,WORD
          MPFAIL
          RTI
          $PWRMG: WORD
          MPFAIL
          :REPORT THE POWER FAILURE
          :POWER FAIL MESSAGE POINTER
          $ILLUP: HALT
          BR    .-2
          :THE POWER UP SEQUENCE WAS STARTED
          :BEFORE THE POWER DOWN WAS COMPLETE
          $SAVR6: 0
          :PUT THE SP HERE

          PFTAB: 1
          .BYTE 3,2
          $STSTM

          .DELAY:
          MOV    #20, @KMP04
          ROMCLK 121111
          :NEXT WORD IS INSTRUCTION. ROMCLK PC=5304
          :POKE CLOCK DELAY BIT
          1$:   ROMCLK 121224
          :NEXT WORD IS INSTRUCTION. ROMCLK PC=5304
          :PORT4, IBUS*11
          BIT    #BIT4, @KMP04
          BEQ    1$           ;IS CLOCK BIT SET?
          RTI
          :BR IF NO

          .MSTCLR:
          BISB   #BIT6, @KMCNRH ;:SET MASTER CLEAR
          BICB   #BIT6!BIT7, @KMCNRH ;:CLEAR MASTER CLEAR AND RUN
          RTI
          :RETURN

          .ROMCLK:
          BISB   #BIT1, @KMCNRH ;:SET ROMI
          MOV    @(SP)+, @KMP06 ;:LOAD INSTRUCTION IN SEL6
          ADD    #2, -(SP)      ;:ADJUST STACK

```

08-JUN-78 07:54 PAGE 36
CZKCGA.P11 08-JUN-78 07:53

POWER DOWN AND UP ROUTINES

1738	007412	032777	000100	171620		BIT	#SW06, ^a ASWR	:HALT IF SW06 -1
1739	007420	001401				BEQ	1\$:BR IF SW06 =0
1740	007422	000000				HALT		:HALT BEFORE CLOCKING INSTRUCTION
1741	007424	152777	000003	172436	1\$:	BISB	#BIT1!BIT0, ^a KMCSR _H	;CLOCK INSTRUCTION
1742	007432	142777	000007	172430		BICB	#BIT2!BIT1!BIT0, ^a KMCSR _H	;CLEAR ROM0, ROM1, STEP
1743	007440	000002				RTI		
1744								
1745	007442	013637	011122			.DATACLK:		
1746	007442	013637	011122			MOV	a(SP)+,TEMP	:PUT TICK COUNT IN TEMP
1747	007446	062746	000002	172410	1\$:	ADD	#2,-(SP)	:ADJUST STACK
1748	007452	152777	000020	172400		BISB	#BIT4, ^a KMCSR _H	:SET STEP LU
1749	007460	027777	172402	172400		CMP	AKMCSR, ^a KMCSR	:WASTE TIME
1750	007466	142777	000020	172374		BICB	#BIT4, ^a KMCSR _H	:CLEAR STEP LU
1751	007474	005337	011122			DEC	TEMP	:DEC TICK COUNT
1752	007500	001364				BNE	1\$:BR IF NOT DONE
1753	007502	000002				RTI		:RETURN
1754	007504	000001			3\$:	.BLKW 1		
1755								
1756	007506	013637	011122			.TIMER:		
1757	007506	013637	011122			MOV	a(SP)+,TEMP	:MOVE COUNT TO TEMP
1758	007512	062746	000002			ADD	#2,-(SP)	:ADJUST STACK
1759	007516				1\$:			
1760	007516	104412				ROMCLK		:NEXT WORD IS INSTRUCTION, ROMCLK PC 5304
1761	007520	021364				021364		:PORT4 IBUS* REG11
1762	007522	032777	000002	172344		BIT	#2, ^a KMPO4	:IS PG ^a CLOCK BIT CLEAR?
1763	007530	001772				BEQ	1\$:BR IF YES
1764	007532	104412			2\$:			
1766	007534	021364				ROMCLK		:NEXT WORD IS INSTRUCTION, ROMCLK PC 5304
1767	007536	032777	000002	172330		021364		:PORT4 IBUS* REG11
1768	007544	001372				BIT	#2, ^a KMPO4	:IS PG ^a CLOCK BIT SET?
1769	007546	005337	011122			BNE	2\$:BR IF YES
1770	007552	001361				DEC	TEMP	:DEC COUNT
1771	007554	000002				BNE	1\$:BR IF NOT DONE
1772						RTI		:RETURN
1773	007556	050200	051127	043040		MPFAIL:	.ASCIZ <200>/PWR FAILED. RESTART AT TEST /	
(2)	007614	042600	042116	050040		MEPASS:	.ASCIZ <200>/END PASS CZKCG /	
(2)	007636	051200	000			MR:	.ASCIZ <200>/R/	
(2)	007641	200	047516	042040		MERR2:	.ASCIZ <200>/NO DEVICES PRESENT./	
(2)	007666	044600	051516	043125		MERR3:	.ASCIZ <200>/INSUFFICIENT DATA!/	
(?)	007712	046200	041517	020113		MLOCK:	.ASCIZ <200>/LOCK ON SELECTED TEST/	
(2)	007741	103	051123	020072		MCSRX:	.ASCIZ /CSR: /	
(2)	007747	126	041505	020072		MVECX:	.ASCIZ /VEC: /	
(2)	007755	120	051501	042523		MPASSX:	.ASCIZ /PASSES: /	
(2)	007766	051105	047522	051522		MERRX:	.ASCIZ /ERRORS: /	
(2)	007777	124	051505	020124		MTSTN:	.ASCIZ /TEST NO: /	
(2)	010011	052	000			MASTEK:	.ASCIZ /*/	
(2)	010013	200	042523	020124		MNEW:	.ASCIZ <200>/SET SWITCH REG TO KMC11'S DESIRED ACTIVE./	
(2)	010066	041520	020072	000		MERRPC:	.ASCIZ /PC: /	
(2)	010073	200	020040	020040		XHEAD:	.ASCII <200>/----- MAP OF KMC11 STATUS/	
(2)	010132	020200	020040	020040		.ASCII	<200>/-----	
(2)	010171	200	020040	041520		.ASCII	<200>/ PC CSR STAT1 STAT2 STAT3/	
(2)	010243	200	026455	026455		.ASCII	<200>/-----	
(2)	010317	200	047510	020127		NUM:	.ASCIZ <200>/HOW MANY KMC11'S TO BE TESTED?/	
(2)	010357	200	051503	020122		CSR:	.ASCIZ <200>/CSR ADDRESS?/	
(2)	010375	200	042526	052103		VEC:	.ASCIZ <200>/VECTOR ADDRESS?/	

08-JUN-78 07:54 PAGE 37
CZKGGA.P11 08-JUN-78 07:53

PAGE: 0049C2

POWER DOWN AND UP ROUTINES

```

(2) 010416 041200 020122 051120      PRI0: .ASCIZ <200>/BR PRIORITY LEVEL? (4,5,6,7)?/
(2) 010455 200 044127 041511      MODU: .ASCIZ <200>/WHICH LINE UNIT? IF NONE TYPE 'N', IF M
(2) 010567 200 053523 052111      LINE: .ASCIZ <200>/SWITCH PAC#1 (DDCMP LINE #)?/
(2) 010625 200 053523 052111      BM: .ASCIZ <200>/SWITCH PAC#2 (BM873 BOOT ADD)?/
(2) 010665 200 051511 052040      CONN: .ASCIZ <200>/IS THE LOOP BACK CONNECTOR ON?/
(2) 010725 200 047516 042040      NOACT: .ASCIZ <200>/NO DEVICES ARE SELECTED/
(2) 010756 100200 046513 030503      CONERR: .ASCIZ <200><200>/KMC11 AT NONSTANDARD ADDRESS PC: /
(2) 011023 200 054105 042520      CNERR: .ASCIZ <200>/EXPECTED FOUND/
(2) 011044 024040 046513 024503      KMCM: .ASCIZ / (KMC) /
(2) 011054 046040 040517 044504      MLDER: .ASCIZ / LOADING ERROR /
(2)
(2) 011074 000005
1774 011076 006 003      .EVEN
1775 011100 001276      XSTATQ: 5
1776 011102 006 003      .BYTE 6,3
1777 011104 001300      $TMP0
1778 011106 006 003      .BYTE 6,3
1779 011110 001302      $TMP1
1780 011112 006 003      .BYTE 6,3
1781 011114 001304      $TMP2
1782 011116 006 002      .BYTE 6,3
1783 011120 001306      $TMP3
1784
1785
1786
1787
1788 011122 000000      .BYTE 6,2
1789 011164
1790 011164 000000      :BUFFERS FOR INPUT-OUTPUT
1791 011226
1792
1793
1794
1795
1796
1797
1798 011226 022737 000176 001240      CKSWR: CMP #SWREG,SWR      :IS THE SOFT SWR BEING USED?
1799 011234 001075      BNE CKSWR5      :BR IF NO
1800 011236 132737 000001 001336      BITB #1,SENV      :IS IT RUNNING UNDER APT?
1801 011244 001071      BNE CKSWR5      :EXIT IF YES.
1802 011246 022777 000007 167772      CMP #7,$STKB      :WAS CTRL G TYPED? (7 BIT ASCII)
1803 011254 001404      BEQ 1$      :BR IF YES
1804 011256 022777 000207 167762      CMP #207,$STKB      :WAS CTRL G TYPED? (8 BIT ASCII)
1805 011264 001061      BNE CKSWR5      :BR IF NO
1806 011266 010246      MOV R2,-(SP)      :STORE R2
1807 011270 010346      MOV R3,-(SP)      :STORE R3
1808 011272 010446      MOV R4,-(SP)      :STORE R4
1809 011274 012737 177777 011432      MOV #-1,SWFLG      :SET SOFT TYPE OUT FLAG
1810 011302 005002      CKSWR1: CLR R2      :CLEAR NEW SWR CONTENTS
1811 011304 012704 177777      MOV #-1,R4      :SET FLAG TO ALL ONES
1812 011310 104401 005535      TYPE ,SMSWR      :TYPE 'SWR='
1813 011314 104417      CKSWR2: CNVRT      :TYPE OUT PRESENT CONTENTS
1814 011316 011466      SOFTSW      :OF SOFT SWITCH REGISTER
1815 011320 104401 005546      CKSWR3: TYPE ,SMNEW      :TYPE 'NEW?'
1816 011324 004737 011434      CKSWR4: JSR PC,INCHAR      :GET RESPONSE
1817 011330 022703 000015      CMP #15,R3      :WAS IT A CR?

```

08-JUN-78 07:54 PAGE 38
CZKCGA.P11 - 08-JUN-78 07:53

L 4

PAGE: 0050C2

POWER DOWN AND UP ROUTINES

1818 011334 001424		BEQ	SS	:BR IF YES
1819 011336 022703 000012		CMP	#12,R3	:WAS IT A LF?
1820 011342 001416		BEQ	4\$:BR IF YES
1821 011344 022703 000025		CMP	#25,R3	:WAS IT CTRL U?
1822 011350 001754		BEQ	CKSWR1	:BR IF YES(START OVER)
1823 011352 022703 000007		CMP	#7,R3	:IF CNTL G GET NEXT CHAR
1824 011356 001762		BEQ	CKSWR4	
1825 011360 005004		CLR	R4	
1826 011362 042703 177770		BIC	#177770,R3	:IT MUST BE A DIGIT SO CLR FLAG
1827 011366 006302		ASL	R2	:ONLY 0-7 ARE LEGAL SO MASK OFF BITS
1828 011370 006302		ASL	R2	
1829 011372 006302		ASL	R2	
1830 011374 050302		BIS	R3,R2	:ADD LAST DIGIT
1831 011376 000752		BR	CKSWR4	:GET NEXT CHARACTER
1832 011400 012766 002402 000006	4\$:	MOV	#.START,6(SP)	:LF WAS TYPED SO GO TO START
1833 011406 005704	5\$:	TST	R4	:IS FLAG CLEAR?
1834 011410 001002		BNE	6\$:IF NOT DON'T CHANGE SOFT SWR
1835 011412 010277 167622		MOV	R2,ASTWR	:IF YES THEN WRITE NEW CONTENTS TO SOFT SWR
1836 011416 005037 011432	6\$:	CLR	SWFLG	:CLEAR TYPEOUT FLAG
1837 011422 012604		MOV	(SP)+,R4	:RESTORE R4
1838 011424 012603		MOV	(SP)+,R3	:RESTORE R3
1839 011426 012602		MOV	(SP)+,R2	:RESTORE R2
1840 011430 000207		CKSWR5:	RTS	:RETURN
1841		SWFLG:	0	
1842 011432 000000		INCHAR:	TSTB	ASTKS
1843			BPL	-4
1844 011434 105777 167604			MOV	ASTKB,R3
1845 011440 100375			TSTB	ASTPS
1846 011442 017703 167600			BPL	-4
1847 011446 105777 167576			MOV	R3,ASTPB
1848 011452 100375			BIC	#BIT7,R3
1849 011454 010377 167572			RTS	PC
1850 011460 042703 000200		SOFTSW:	1	
1851 011464 000207		.BYTE	6,2	
1852		SWREG		
1853 011466 000001				
1854 011470 006 002				
1855 011472 000176				

08-JUN-78 07:54 PAGE 39
 CZKCGA.P11 08-JUN-78 07:53

PAGE: 0051C2

POWER DOWN AND UP ROUTINES

```

1856
1857
1858 ;ROUTINE USED TO "CYCLE" THROUGH UP TO 16 KMC11'S
1859 ;THIS ROUTINE SETS UP THE CONTROL ADDRESS FOR THE DIAGNOSTIC
1860 ;AND RUNS THE SPECIFIED KMC11'S. THIS ROUTINE *MUST*
1861 ;BE RUN FIRST BEFORE ENTERING THE DIAGNOSTIC FOR THE
1862 ;SETUP NECESSARY.
1863 ;
1864
1865 011474 005737 001470 CYCLE: TST KMACTV ;ARE ANY KMC11'S TO BE TESTED?
1866 011500 001004 BNE 1$ ;BR IF OK.
1867 011502 104401 010725 TYPE ,NOACT ;NO KMC11'S SELECTED!!
1868 011506 000000 HALT ;STOP THE SHOW.
1869 011510 000776 BR .-2 ;DISQUALIFY CONT. SW.
1870 011512 000241 CLC ;CLEAR PROC. CARRY BIT.
1871 011514 006137 001500 ROL RUN ;UPDATE POINTER
1872 011520 005537 001500 ADC RUN ;CATCH CARRY FROM RUN
1873 011524 062737 000004 001504 ADD #4,MILK ;UPDATE POINTER
1874 011532 062737 000010 001502 ADD #10,CREAM ;UPDATE ADDRESS POINTER.
1875 011540 022737 002300 001502 CMP #KM.MAP+200,CREAM
1876 011546 001006 BNE 2$ ;KEEP GOING; NOT ALL TESTED FOR.
1877 011550 012737 002100 001502 MOV #KM.MAP,CREAM ;RESET ADDRESS POINTER.
1878 011556 012737 002302 001504 MOV #CNT.MAP,MILK ;RESET PASS COUNT POINTER
1879 011564 033737 001500 001470 2$: BIT RUN,KMACTV ;IS THIS ONE ACTIVE?
1880 011572 001747 BEQ 1$ ;BR IF NO
1881 011574 013700 001502 MOV CREAM,RO ;GET ADDRESS POINTER
1882 011600 013702 001504 MOV MILK,R2 ;GET PASS COUNT POINTER
1883 011604 012037 002066 MOV (R0)+,KMCSR ;LOAD SYSTEM CTRL. REG
1884 011610 011037 002056 MOV (R0),KMRVEC ;LOAD VECTOR
1885 011614 042737 177000 002056 BIC #177000,KMRVEC ;CLEAR UNWANTED BITS
1886 011622 012037 002050 MOV (R0)+,STAT1 ;LOAD STAT1
1887 011626 012037 002052 MCV (R0)+,STAT2 ;LOAD STAT2
1888 011632 012037 002054 MOV (R0)+,STAT3 ;LOAD STAT3
1889 011636 012237 001324 MOV (R2)+,SPASS ;LOAD PASS COUNT
1890 011642 012237 001212 MOV (R2)+,SERTTL ;LOAD ERROR COUNT
1891 011646 012700 000002 MOV #2,RO ;SAVE CORE THIS WAY!
1892 011652 013737 002066 002070 MOV KMCSR,KMCSRH
1893 011660 005237 002070 INC KMCSRH
1894 011664 013737 002070 002072 MOV KMCSRH,KMCTL
1895 011672 005237 002072 INC KMCTL
1896 011676 013737 002072 002074 MOV KMCTL,KMP04
1897 011704 060037 002074 ADD RO,KMP04
1898 011710 013737 002074 002076 MOV KMP04,KMP06
1899 011716 060037 002076 ADD RO,KMP06
1900
1901 011722 013737 002056 002060 MOV KMRVEC,KMRLVL ;PTY LVL
1902 011730 060037 002060 ADD RO,KMRLVL
1903 011734 013737 002060 002062 MOV KMRLVL,KMTVEC ;TX VEC
1904 011742 060037 002062 ADD RO,KMTVEC
1905 011746 013737 002062 002064 MOV KMTVEC,KMTLVL ;TX LVL
1906 011754 060037 002064 ADD RO,KMTLVL
1907
1908 011760 032737 000002 001446 4$: BIT #SW01,STRTSW ;IS TEST NO. SELECTED
1909 011766 001447 BEQ 7$ ;BR IF NO
1910 011770 005737 000042 TST @#42 ;RUNNING IN AUTO MODE?
1911 011770

```

08-JUN-78 07:54 PAGE 40
CZKCGA.P11 08-JUN-78 07:53

N 4

PAGE: 005202

POWER DOWN AND UP ROUTINES

1912 011774 001044
1913 011776 104401 001313
1914 012002 104415
1915 012004 007777
1916 012006 000001
1917 012010 001000
1918 012012 001202
1919 012014 000
1920 012015 001
1921 012016 012700 013762
1922 012022 022710
1923 012024 012737
1924 012026 001020
1925 012030 023760 001202 000002
1926 012036 001014
1927 012040 022760 001202 000004
1928 012046 001010
1929 012050 010037 001206
1930 012054 104401 007636
1931 012060 042737 000002 001446
1932 012066 000412
1933 012070 005720
1934 012072 020027 016400
1935 012076 001351
1936 012100 104401 001312
1937 012104 000731
1938
1939 012106 012737 013762 001206
1940 012114 013701 002066
1941 012120 000177 167062
1942
1943
1944 ;ROUTINE USED TO 'AUTO SIZE' THE KMC11
;CSR AND VECTOR.
1945 ;NOTE: THE CSR MAY BE ANY WHERE IN THE FLOATING
1946 ; ADDRESS RANGE (160000:164000)
1947 ;
1948 ;
1949 ;
1950 ;
1951
1952 012124
1953 012124 000005
1954 012126 012702 002100
1955 012132 005022
1956 012134 022702 002300
1957 012140 001374
1958 012142 005037 001472
1959 012146 012702 002100
1960 012152 005037 001470
1961 012156 032737 000001 001446
1962 012164 001002
1963 012166 000137 012554
1964 012172 012737 000001 001306
1965 012200 104415
1966 012202 010317
1967 012204 000001

BNE 7\$;BR IF YES
TYPE ,\$CRLF
INPUT
MTSTN
1
1000
\$TSTNM
.BYTE 0
.BYTE 1
MOV #TST1,R0
5\$: CMP (PC)+,(R0) ;CMP FIRST WORD TO 12737
MOV (PC)+,2(PC)+
BNE 6\$;BR IF NOT SAME
CMP \$TSTNM,2(R0) ;DOES \$TSTNM MATCH?
BNE 6\$;BR IF NO
CMP #\$TSTNM,4(R0) ;IS LAST WORD OK?
BNE 6\$;BR IF NO
MOV R0,\$LPADR ;IT IS A LEGAL TEST SO DO IT
TYPE ,MR
BIC #SW01,STRTSW
BR 8\$
6\$: TST (R0)+ ;POP R0
CMP R0,#TLAST+10 ;AT END YET?
BNE 5\$;BR IF NO
TYPE ,\$QUES ;YES ILLEGAL TEST NO.
BR 4\$;TRY AGAIN
7\$: MOV #TST1,\$LPADR ;PREPARE \$LPADR ADDRESS
8\$: MOV KMC11,R1 ;R1 = BASE KMC11 ADDRESS
JMP @SLPADR ;GO START TESTING.

AUTO.SIZE:
RESET
CSRMAP: MOV #KM.MAP,R2 ;INSURE A BUS INIT.
1\$: CLR (R2)+ ;LOAD MAP POINTER.
CLR #KM.END,R2 ;ZERO ENTIRE MAP
CMP #KM.END,R2 ;ALL DONE?
BNE 1\$;BR IF NO
CLR KMNUM ;SET OCTAL NUMBER OF KMC11'S TO 0
MOV #KM.MAP,R2 ;R2 POINTS TO KMC MAP
CLR KMACTV ;CLEAR ACTIVE
BIT #SW00,STRTSW ;QUESTIONS?
BNF ,+6 ;BR IF YES
JMP 7\$;IF NO SKIP QUESTIONS
MOV #1,\$TMP4 ;START WITH 1
INPUT
NUM
1

POWER DOWN AND UP ROUTINES

1968	012206	000020		16.		
1969	012210	001302		\$TMP2		
1970	012212	000		.BYTE	0	
1971	012213	001		.BYTE	1	
1972	012214	013737	001302	MOV	\$TMP2,KNUM	;KNUM - HOW MANY
1973	012222	104401	001313	TYPE	,\$CRLF	
1974	012226	104416		CONVRT		:TYPE WHICH KMC IS BEING DONE
1975	012230	013214		WHICH		:\$TMP4 IS WHICH KMC
1976	012232	005237	001306	INC	\$TMP4	
1977	012236	104415		INPUT		
1978	012240	010357		CSR		
1979	012242	160000		160000		
1980	012244	164000		164000		
1981	012246	001304		\$TMP3		
1982	012250	000		.BYTE	0	
1983	012251	001		.BYTE	1	
1984	012252	013722	001304	MOV	\$TMP3,(R2)+	;STORE CSR IN MAP
1985	012256	104415		INPUT		
1986	012260	010375		VEC		
1987	012262	000000		0		
1988	012264	000776		776		
1989	012266	001304		\$TMP3		
1990	012270	000		.BYTE	0	
1991	012271	001		.BYTE	1	
1992	012272	013712	001304	MOV	\$TMP3,(R2)	;STORE VECTOR IN MAP
1993	012276	104401		TYPE		
1994	012300	010416		PRI0		
1995	012302	004737	013506	JSR	PC,INTTY	;ASK WHAT BR LEVEL
1996	012306	022703	000024	CMP	#24,R3	;GET RESPONSE
1997	012312	101014		BHI	50\$;
1998	012314	022703	000027	CMP	#27,R3	;BR IF LESS THAN 4
1999	012320	103411		BLO	50\$;
2000	012322	012704	000011	MOV	#11,R4	;BR IF GREATER THAN 7
2001	012326	006303		ASL	R3	;R4 = NUMBER OF SHIFTS
2002	012330	005304		DEC	R4	;SHIFT R3 LEFT
2003	012332	001375		BNE	-.4	;DEC SHIFT COUNT
2004	012334	042703	170777	BIC	#170777,R3	;BR IF NOT DONE
2005	012340	050312		BIS	R3,(R2)	;BIC UNWANTED BITS
2006	012342	000403		BR	8\$;PUT BR LEVEL IN STATUS MAP
2007	012344	104401		TYPE		;CONTINUE
2008	012346	001312		SQUES		
2009	012350	000752		BR	10\$:RESPONSE IS OUT OF LIMITS
2010	012352					:TRY AGAIN
2011	012352					
2012	012352	104401				
2013	012354	010455				
2014	012356	004737	013506	16\$:	TYPE	
2015	012362	022703	000021	MODU		;ASK WHICH LINE UNIT
2016	012366	001422		JSR	PC,INTTY	;GET REPLY
2017	012370	022703	000022	CMP	#21,R3	:'1'
2018	012374	001412		BEQ	30\$:'2'
2019	012376	022703	000116	CMP	#22,R3	:'N'
2020	012402	001403		BEQ	31\$	
2021	012404	104401		CMP	#116,R3	
2022	012406	001312		BEQ	32\$	
2023	012410	000760		TYPE		:IF NOT A 1,2 OR N TYPE '??'
				SQUES		:TRY AGAIN
				BR	16\$	

08-JUN-78 07:54 PAGE 42
CZKCGA.P11 08-JUN-78 07:53

C 5

PAGE: 0054C2

POWER DOWN AND UP ROUTINES

2024	012412	052722	010000		32\$: BIS #BIT12,(R2)+ ;SET BIT 12 IN STAT2 IF NO LU
2025	012416	022222			CMP (R2)+,(R2)+ ;POP OVER STAT2 AND STAT3
2026	012420	000450			BR 33\$
2027	012422	052712	020000	31\$: BIS #BIT13,(R2) ;SET BIT 13 IN STAT2 IF M8202	
2028	012426	052762	000002	BIS #BIT1,4(R2) ;SET BIT1 IN STAT3 FOR HIGH SPEED MICRO-CODE.	
2029	012434	104401		30\$: TYPE	
2030	012436	010665		CONN	
2031	012440	004737	013506	JSR PC_INTTY ;ASK IF LOOP-BACK IS ON	
2032	012444	022703	000131	CMP #131,R3 ;GET REPLY	
2033	012450	001406		BEQ 17\$;Y	
2034	012452	022703	000116	CMP #116,R3 ;N	
2035	012456	001406		BEQ 18\$	
2036	012460	104401		TYPE	
2037	012462	001312		\$QUES	:IF NOT Y OR N TYPE '?'
2038	012464	000763		BR 30\$:TRY AGAIN
2039	012466	052722	040000	17\$: BIS #BIT14,(R2)+ ;TURNAROUND IS CONNECTED	
2040	012472	000402		BR 19\$	
2041	012474	042722	040000	18\$: BIC #BIT14,(R2)+ ;NO TURNAROUND	
2042	012500	104415		19\$: INPUT	
2043	012502	010567		LINE	
2045	012504	000000		0	
2046	012506	000377		377	
2047	012510	001304		\$TMP3	
2048	012512	000		.BYTE 0	
2049	012513	001		.BYTE 1	
2050	012514	113722	001304	MOV.B \$TMP3,(R2)+ ;STORE SWITCH PAC IN MAP	
2051	012520	104415		INPUT	
2052	012522	010625		BM	
2053	012524	000000		0	
2054	012526	000377		377	
2055	012530	001304		\$TMP3	
2056	012532	000		.BYTE 0	
2057	012533	001		.BYTE 1	
2058	012534	113722	001304	MOV.B \$TMP3,(R2)+ ;STORE SWITCH PAC IN MAP	
2059	012540	005722		TST (R2)+ ;POP OVER STAT3	
2060	012542	005337	001302	33\$: DEC \$TMP2 ;DEC KMC COUNT	
2061	012546	001225		BNE 12\$;BR IF MORE TO DO	
2062	012550	000137	013114	JMP 13\$;CONTINUE	
2063	012554	012701	160000	7\$: MOV #160000,R1 ;SET FOR FIRST ADDRESS TO BE TESTED	
2064	012560	012737	013206	000004	MOV #6\$,#4 ;SET FOR NON-EXISTANT DEVICE TIME OUT
2065	012566	005011		2\$: CLR (R1) ;CLEAR SEL0	
2066	012570	005711		TST (R1) ;IF KMC11 KMCsr S/B 0	
2067	012572	001140		BNE 3\$;IF NO DEV ; TRAP TO 4. IF NO BIT 8 THEN NO KMC1	
2068	012574	005061	000006	CLR 6(R1) ;CLEAR SEL6	
2069	012600	005761	000006	TST 6(R1) ;IF KMC11 THEN KMRIC S/B =0!	
2070	012604	001133		BNE 3\$;BR IF NOT KMC11	
2071	012606	012711	002000	MOV #BIT10,(R1) ;SET ROM0	
2072	012612	005061	000004	CLR 4(R1) ;CLEAR SEL4	
2073	012616	012761	125252	000006	MOV #125252,6(R1) ;WRITE THIS TO SEL6
2074	012624	052711	020000	BIS #BIT13,(R1) ;WRITE IT!	
2075	012630	022761	125252	000004	CMP #125252,4(R1) ;WAS IT WRITTEN?
2076	012636	001116		BNE 3\$;IF NO IT IS NOT CRAM	
2077	012640	010122		;AT THIS POINT IT IS ASSUMED THAT R1 HOLDS A KMC11 CSR ADDRESS.	
2078	012640			21\$: MOV R1,(R2)+ ;STORE CSR IN CORE TABLE.	
2079	012640			22\$: MOV R1,(R2)+ ;STORE CSR IN CORE TABLE.	

POWER DOWN AND UP ROUTINES

2080	012642	012711	001000		15\$:	MOV #BIT9,(R1)	:CLEAR LINE UNIT LOOP
2081	012646	005061	000004			CLR 4(R1)	:CLEAR PORT4
2082	012652	012761	122113	000006		MOV #122113,6(R1)	:LOAD INSTRUCTION (CLR DTR)
2083	012660	052711	000400			BIS #BIT8,(R1)	:CLOCK INSTRUCTION
2084	012664	012761	021264	000006		MOV #021264,6(R1)	:LOAD INSTRUCTION
2085	012672	052711	000400			BIS #BIT8,(R1)	:CLOCK INSTRUCTION
2086	012676	122761	000377	000004		CMPB #377,4(R1)	:IS IT ALL ONES?
2087	012704	001003				BNE .+10	:BR IF NO
2088	012706	052712	010000			BIS #BIT12,(R2)	:IF YES, NO LINE UNIT, SET STATUS BIT
2089	012712	000441				BR 20\$	
2090	012714	032761	000002	000004		BIT #BIT1,4(R1)	:IS SWITCH A ONE?
2091	012722	001406				BEQ .+16	:BR IF M8201
2092	012724	052712	060000			BIS #BIT13!BIT14,(R2)	:M8202 ASSUME CONNECTOR
2093	012730	052762	000002	000004		BIS #BIT1,4(R2)	:SET BIT1 IN STAT3 FOR HIGH SPEED MICRO-CODE...
2094	012736	000427				BR 20\$:CONNECTOR ON)
2095	012740	032761	000010	000004		BIT #BIT3,4(R1)	:IS MRDY SET
2096	012746	001023				BNE 20\$:BR IF M8201 NO CONNECTOR (ON LINE)
2097	012750	012761	000100	000004		MOV #BIT6,4(R1)	:LOAD PORT4
2098	012756	012761	122113	000006		MOV #122113,6(R1)	:LOAD INSTRUCTION
2099	012764	052711	000400			BIS #BIT8,(R1)	:CLOCK INSTRUCTION(SET DTR)
2100	012770	012761	021264	000006		MOV #021264,6(R1)	:LOAD INSTRUCTION
2101	012776	052711	000400			BIS #BIT8,(R1)	:CLOCK INSTRUCTION(READ MODEM REG)
2102	013002	032761	000010	000004		BIT #BIT3,4(R1)	:IS MRDY SET NOW?
2103	013010	001402				BEQ 20\$:BR IF NO CONNECTOR
2104	013012	052712	040000			BIS #BIT14,(R2)	:SET STATUS BIT FOR CONNECTOR
2105	013016	005722				TST (R2)+	:POP POINTER
2106	013020	012761	021324	000006		MOV #021324,6(R1)	:PUT INSTRUCTION IN PORT6
2107	013026	012711	001400			MOV #BIT9!BIT8,(R1)	:PORT4_LU 15
2108	013032	156122	000004			BISB 4(R1),(R2)+	:STORE DDCMP LINE # IN TABLE
2109	013036	012761	021344	000006		MOV #021344,6(R1)	:PORT6_INSTRUCTION
2110	013044	012711	001400			MOV #BIT8!BIT9,(R1)	:CLOCK INSTR.
2111	013050	156122	000004			BISB 4(R1),(R2)+	:STORE BM873 ADD IN TABLE
2112	013054	005722				TST (R2)+	:POP OVER STAT3
2113	013056	005011				CLR (R1)	:CLEAR ROMI
2114	013060	005237	001472			INC KMNUM	:UPDATE DEVICE COUNTER
2115	013064	022737	000020	001472		CMP #20,KMNUM	:ARE MAX. NO. OF DEV FOUND?
2116	013072	001410				BEQ 13\$:YES DON'T LOOK FOR ANY MORE.
2117	013074	005011				CLR (R1)	:CLEAR BIT 10
2118	013076	005061	000006			CLR 6(R1)	:CLEAR SEL 6
2119	013102	062701	000010			14\$: ADD #10,R1	:UPDATE CSR POINTER ADDRESS
2120	013106	022701	164000			CMP #164000,R1	
2121	013112	001225				BNE 2\$:BR IF MORE ADDRESS TO CHECK.
2122	013114	005037	001470			13\$: CLR KMACTV	
2123	013120	005737	001472			TST KMNUM	:WERE ANY KMC11'S FOUND AT ALL?
2124	013124	001423				BEQ 5\$:ERROR AUTO SIZER FOUND NO KMC11'S IN THIS SYS.
2125	013126	013701	001472			MOV KMNUM,R1	
2126	013132	010137	001476			MOV R1,SAVNUM	:SAVE NUMBER OF DEVICES
2127	013136	000241				4\$: CLC	
2128	013140	006137	001470			ROL KMACTV	:GENERATE ACTIVE REGISTER OF DEVICES.
2129	013144	005237	001470			INC KMACTV	:SET THE BIT
2130	013150	005301				DEC R1	
2131	013152	001371				BNE 4\$:BR IF MORE TO GENERATE
2132	013154	012737	000006	000004		MOV #6,2#4	:RESTORE TRAP VECTOR
2133	013162	013737	001470	001474		MOV KMACTV,SAVACT	:SAVE ACTIVE REGISTER
2134	013170	000137	013222			JMP VECMAP	:GO FIND THE VECTOR NOW.
2135	013174	104401	007641			TYPE ,MERR2	:NOTIFY OPR THAT NO KMC11'S FOUND.

08-JUN-78 07:54 PAGE 44
CZKCGA.P11 08-JUN-78 07:53

E 5

PAGE: 0056C2

POWER DOWN AND UP ROUTINES

2136 013200 005000			CLR R0	:MAKE DATA LIGHTS ZERO
2137 013202 000000			HALT	:STOP THE SHOW
2138 013204 000776			BR -2	:DISABLE CONT. SW.
2139 013206 012716	013102		6\$: MOV #14\$, (SP)	:ENTERED BY NON-EXISTANT TIME-OUT.
2140 013212 000002			RTI	:RETURN TO MAINSTREAM
2141				
2142 013214 000001			WHICH: 1	
2143 013216 002	002		.BYTE \$TMAP4	2.2
2144 013220 001306				
2145				
2146 013222 032737 000001 001446			VECMAP: BIT #SW00, STRTSW	
2147 013230 001114			BNE 5\$	
2148 013232 012737 000340 000022			MOV #340, @#22	:SET IOT TRAP PRIO TO 7
2149 013240 012737 013414 000020			MOV #4\$, @#20	:SET IOT TRAP VECTOR
2150 013246 012702 002100			MOV #KM.MAP, R2	:SET SOFTWARE POINTER
2151 013252 012700 000300			MOV #300, R0	:FLOATING VECTORS START HERE.
2152 013256 012701 000302			MOV #302, R1	:PC OF IOT INSTR.
2153 013262 010120			MOV R1, (R0)+	:START FILLING VECTOR AREA
2154 013264 012721 000004			MOV #4, (R1)+	:WITH .+2; IOT
2155 013270 022021			(CMP (R0)+, (R1)+	:ADD 2 TO R0 +R1
2156 013272 020127 001000			CMP R1, #1000	
2157 013276 101771			BLDS 1\$	
2158 013300 013737 001470 001276			MOV KMACTV, \$TMAP0	:BR IF MORE TO FILL
2159 013306 006037 001276			ROR \$TMAP0	:STORE TEMPORALLY
2160 013312 103063			BCC 5\$:BRING OUT A BIT
2161 013314 012704 000012			MOV #12, R4	:BR IF ALL DONE
2162 013320 016437 013472 177776			MOV BRLVL(R4), PS	:R4 IS INDEX REGISTER
2163 013326 011201			MOV (R2), R1	:SET PS TO 7
2164 013330 012761 000200 000004			MOV #200, 4(R1)	
2165 013336 012711 001000			MOV #BIT9, (R1)	:SET ROMI
2166 013342 012761 121111 000006			MOV #121111, 6(R1)	:PUT INSTRUCTION IN PORT6
2167 013350 012711 001400			MCV #BIT9:BIT8, (R1)	:FORCE AN INTERRUPT
2168 013354 105200			7\$: INCB R0	:STALL
2169 013356 001376			BNE -2	:FOR TIME TO INTERRUPT
2170 013360 162704 000002			SUB #2, R4	:GET NEXT LOWEST PS LEVEL
2171 013364 001404			BED 6\$:BR IF R4 = 0
2172 013366 016437 013472 177776			MOV BRLVL(R4), PS	:MOVE NEXT LOWER LEVEL IN PS
2173 013374 000767			BR 7\$:BR TO DELAY
2174 013376 052762 005300 000002			6\$: BIS #5300, 2(R2)	:NO INTERRUPT ASSUME 300 AT LEVEL 5 AND FIX KMC11
2175 013404 005011			3\$: CLR (R1)	:CLEAR ROMI
2176 013406 062702 000010			ADD #10, R2	:POP SOFTWARE POINTER
2177 013412 000735			BR 2\$:KEEP GOING
2178 013414 051662 000002			4\$: BIS (SP), 2(R2)	:GET VECTOR ADDRESS
2179 013420 042762 000007 000002	013474		BIC #7, 2(R2)	:CLEAR JUNK
2180 013426 016405 013474			MOV BRLVL+2(R4), R5	:GET BR LEVEL OF KMC11
2181 013432 006305			ASL R5	:SHIFT LEVEL 4 PLACES
2182 013434 006305			ASL R5	:TO THE LEFT FOR THE
2183 013436 006305			ASL R5	:STATUS TABLE
2184 013440 006305			ASL R5	
2185 013442 042705 170777			BIC #170777, R5	:CLEAR UNWANTED BITS
2186 013446 050562 000002			BIS R5, 2(R2)	:PUT BR LEVEL IN STATUS TABLE
2187 013452 022626			(CMP (SP)+, (SP)+	:POP IOT JUNK OFF STACK
2188 013454 012716 013404			MOV #3\$, (SP)	:SET FOR RETURN
2189 013460 000002			RTI	
2190 013462 012737 004134 000020			5\$: MOV ##\$SCOPE, @#20	: RESTORE SCOPE VECTOR
2191 013470 000207			RTS PC	:ALL DONE WITH 'AUTO SIZING'

POWER DOWN AND UP ROUTINES

2192				BRLVL:	PRO	:LEVEL 0	
2193	013472	000000			PRO	:LEVEL 0	
2194	013474	000000			PR4	:LEVEL 4	
2195	013476	000200			PR5	:LEVEL 5	
2196	013500	000240			PR6	:LEVEL 6	
2197	013502	000300			PR7	:LEVEL 7	
2198	013504	000340					
2199							
2200							
2201	013506	105777	165532	INTTY:	TSTB	@\$TKS	:WAIT FOR DONE
2202	013512	100375			BPL	.-4	
2203	013514	017703	165526		MOV	@\$TKB,R3	:PUT CHAR IN R3
2204	013520	105777	165524		TSTB	@\$TPS	:WAIT UNTIL PRINTER IS READY
2205	013524	100375			BPL	.-4	
2206	013526	010377	165520		MOV	R3,@\$TPB	:ECHO CHAR
2207	013532	042703	000240		BIC	#BIT7!BITS5,R3	:MASK OFF LOWER CASE
2208	013536	000207			RTS	PC	:RETURN
2209							
2210	013540			APT.SIZE:			
2211	013540	000005			RESET		
2212	013542	010046			MOV	R0,-(SP)	:;PUSH R0 ON STACK
2213	013544	010146			MOV	R1,-(SP)	:;PUSH R1 ON STACK
2214	013546	010246			MOV	R2,-(SP)	:;PUSH R2 ON STACK
2215	013550	010346			MOV	R3,-(SP)	:;PUSH R3 ON STACK
2216	013552	005037	013754		CLR	VECTR	:CLEAR THE LOCAL VARIABLE
2217	013556	005037	013760		CLR	PRIRTY	:CLEAN UP LOCAL VARIABLE
2218	013562	013700	001376		MOV	\$CDW1,R0	:GET THE DEVICE COUNT
2219	013566	010037	001476		MOV	R0,SAVNUM	:SAVE THE NO. OF DEVICES
2220	013572	012701	001346		MOV	#SMAMS1,R1	:GET EXTRA INFO, BITS POINTER
2221	013576	013737	001372	013756	MOV	SBASE,BASE	:GET BASE CSR ADDRESS
2222	013604	113737	001366	013754	MOV	SVECT1,VECTR	:GET THE VECTOR
2223	013612	113737	001367	013760	MCVB	SVECT1+1,PRIRTY	:GET THE PRIORITY
2224	013620	013737	001374	001470	MOV	\$DEVM,KMACTV	:SAVE THE KMC'S SELECTED ACTIVE
2225	013626	013737	001470	001474	MOV	KMACTV,SAVACT	:SAVE THE ACTIVE REGISTER
2226	013634	012702	001402		MOV	#\$DDW0,R2	:GET ADDRESS OF FIRST DEVICE DESCRIPTOR WORD
2227	013640	012703	002100		MOV	#KM.MAP,R3	:GET POINTER TO DEVICE MAP
2228	013644	005023			3\$:	CLR	:CLEAR DEVICE MAP
2229	013646	022703	002300			CMP	:IS WHOLE DEV.MAP CLEARED?
2230	013652	003374				BGT	:NO, THEN GO ON.
2231	013654	012703	002100			3\$:RESTORE DEV.MAP POINTER.
2232	013660	013723	013756		1\$:	MOV	LOAD CSR ADDRESS
2233	013664	112163	000001			BASE,(R3)+	
2234	013670	006213				MOVB	:GET EXTRA INFO. BITS
2235	013672	006213				(R1)+,1(R3)	
2236	013674	053713	013760			ASR	:SET IT IN RIGHT POSITION.
2237	013700	006313				(R3)	
2238	013702	006313				ASR	:SET IT IN RIGHT POSITION.
2239	013704	006313				(R3)	
2240	013706	006313				BIS	:GET PRIORITY IN STAT1
2241	013710	053723	013754			PRIRTY,(R3)	
2242	013714	012223				ASL	:SET THEM IN RIGHT POSITION
2243	013716	005723				(R3)	
2244	013720	005300				ASL	
2245	013722	001407				(R3)	
2246	013724	062737	000010	013756		BIS	:GET THE VECTOR IN STAT1.
2247	013732	062737	000010	013754		MOV	:GET THE STAT2 FROM DDWXX
						TST	:SKIP OVER STAT3
						DEC	:COUNT BY 1
						BEQ	:ALL DONE?
						ADD	:INCREMENT BASE CSR ADDRESS BY 10
						ADD	:INCREMENT VECTOR ADDRESS BY 10

08-JUN-78 07:54 PAGE 46
CZKCGA.P11 08-JUN-78 07:53

G 5

PAGE: 0058C

POWER DOWN AND UP ROUTINES

2248 013740 000747	BR	1\$; SET THE NEXT MAP ENTRY
2249 013742	2\$:	MOV (SP)+,R3	;;POP STACK INTO R3
2250 013742 012603		MOV (SP)+,R2	;;POP STACK INTO R2
2251 013744 012602		MOV (SP)+,R1	;;POP STACK INTO R1
2252 013746 012601		MOV (SP)+,R0	;;POP STACK INTO R0
2253 013750 012600		RTS PC	; RETURN
2254 013752 000207	VECTR:	.WORD 0	
2255 013754 000000	BASE:	.WORD 0	
2256 013756 000000	PRIORITY:	.WORD 0	
2257 013760 000000			

FREE RUNNING TESTS

2258
 2259
 2260
 2261
 2262
 2263
 2264
 2265
 2266
 2267
 2268
 2269
 2270
 2271
 2272
 2273

***** TEST 1 *****
 ;*FREE RUNNING FLAG MODE DATA TEST
 ;*TRANSMIT A MESSAGE AND VERIFY THE RECEIVED DATA
 ;*LINE UNIT LOOP IS SET FOR THIS TEST.
 ;*ALL FOLLOWING TESTS ARE FREE RUNNING AND ARE PERFORMED
 ;*ONLY ON KMC'S WITH LINE UNITS. IF YOU WISH TO PERFORM
 ;*THESE FREE RUNNING TESTS ON A KMC (NORMALLY THE FREE RUNNING TESTS
 ;*WILL RUN BY LOADING AND STARTING DZKCG
 ;* WITH SWITCH 7 = 1
 ;*****

: TEST 1

2274 013762 000004	2275 013764 012737 000001 001202	TST1: SCOPE	
2276 013772 012737 015006 001442		MOV #1,\$TSTM	; LOAD THE NO. OF THIS TEST
		MOV #TST2,NEXT	; POINT TO THE START OF NEXT TEST.
			;R1 CONTAINS BASE KMC11 ADDRESS
2278 014000 004737 022474	2279 014004 013700 021360	: \$SKIPT 14\$	
2280 014010 062700 000002	2281 014014 012702 021362	JSR PC,LDRVRF	;FIRST TEST LOAD & VERIFY.
2282 014020 105022	2283 014022 005300	MOV RCOUNT, R0	;CLEAR RECEIVER BUFFER
2284 014024 001375	2285 014026 005037 021306	ADD #2,R0	;CLEAR 2 MORE LOCATIONS
2286 014032 005037 021310	2287 014036 012711 040000	MOV #RBUF,R2	;CLEAR OUT RECEIVE BUFFER
		CLRB (R2)+	;CLEAR BUFFER
		DEC R0	;DONE YET!
		BNE 10\$;NO
		CLR TFLAG	;SET TFLAG TO 0
		CLR RFLAG	;SET RFLAG TO 0
		MOV #BIT14,(R1)	;MASTER CLEAR
		BIT #BIT15,STAT1	;CRAM?
		BEQ .+6	;BR IF NO
2291 014042 012711 100000	2292 014046 105227 000000	MOV #BIT15,(R1)	;IF CRAM SET RUN
2293 014052 001375	2294 014054 005037 011122	INC B #0	;DELAY
2295 014060 005711	2296 014062 100405	BNE .-4	;DELAY
2297 014064 005237 011122	2298 014070 001373	CLR TEMP	;GET SET TO DELAY
2299 014072 104014	2300 014074 000771	TST (R1)	;RUN SET?
2301 014076 052711 004043	2302 014102 005037 011122	BMI .+14	;BR IF YES
2303 014106 105711	2304 014110 100404	INC TEMP	;INC DELAY
2305 014112 005237 011122	2306 014116 001373	BNE 1\$;BR IF NOT DONE
2307 014120 104014	2308 014122 012761 021430 000004	ERROR 14	;ERROR RUN NOT SET
2309 014130 005061 000006	2310 014134 142711 000040	BR 1\$;TRY AGAIN
2311 014140 005037 011122	2312 014144 105711	BIS #4043,(R1)	;BASEMC I, LU LOOP
2313 014146 100020		CLR TEMP	;GET SET TO DELAY
		TSTB (R1)	;RDI SET?
		BMI .+12	;BR IF YES
		INC TEMP	;INC DELAY
		BNE 2\$;BR IF NOT DONE
		ERROR 14	;ERROR,RDI NOT SET
		MOV #BASEMC,4(R1)	;SET UP BASEMC ADDRESS
		CLR 6(R1)	;CLEAR COUNT
		BICB #40,(R1)	;CLEAR RQI
		CLR TEMP	;GET SET TO DELAY
		TSTB (R1)	;IS RDI GONE?
		BPL 8\$;BR IF YES

08-JUN-78 07:54 PAGE 48
CZKCGA.P11 08-JUN-78 07:53

I 5

PAGE: 0060C2

FREE RUNNING TESTS

2314 014150 005237 011122
2315 014154 001373
2316 014156 105761 000002
2317 014162 100011
2318 014164 016137 000004 001302
2319 014172 016137 000006 001304
2320 014200 104016
2321 014202 000137 015006
2322 014206 104014
2323 014210 152711 000041
2324 014214 105711
2325 014216 100376
2327 014220 005061 000006
2328 014224 142711 000040
2329 014230 105711
2330 014232 100776
2331 014234 152711 000044
2332 014240 005037 011122
2333 014244 105711
2334 014246 100404
2335 014250 005237 011122
2336 014254 001373
2337 014256 104014
2338 014260 012761 021362 000004
2339 014266 013761 021360 000006
2340 014274 142711 000040
2341 014300 005037 011122
2342 014304 105711
2343 014306 100004
2344 014310 005237 011122
2345 014314 001373
2346 014316 104014
2347 014320 152711 000040
2348 014324 005037 011122
2349 014330 105711
2350 014332 100404
2351 014334 005237 011122
2352 014340 001373
2353 014342 104014
2354 014344 012761 021314 000004
2355 014352 013761 021312 000006
2356 014360 142711 000040
2357 014364 005037 011122
2358 014370 105711
2359 014372 100004
2360 014374 005237 011122
2361 014400 001373
2362 014402 104014
2363 014404 005037 011122
2364 014410 012737 000022 001276
2365 014416 105761 000002
2366 014422 100407
2367 014424 005237 011122
2368 014430 001372 001276
2369 014432 005337 001276

INC TEMP :INC DELAY
BNE 3\$:BR IF NOT DONE
TSTB 2(R1) :IS THERE A CNTL O ERROR
BPL 18\$:BR IF NO
MOV 4(R1),\$TMP2 :SAVE SEL4 FOR TYPEOUT
MOV 6(R1),\$TMP3 :SAVE SEL6 FOR TYPEOUT
ERROR 16 :CNTL O ERROR
JMP 14\$:FATAL ERROR STOP
ERROR 14 :ERROR RDI STILL SET
8\$:
BISB #41,(R1) :ASK FOR CNTL I
TSTB (R1) :WAIT FOR RDI
BPL 64\$:BR IF NOT SETY
CLR 6(R1) :SET FULL DUPLEX
BICB #40,(R1) :CLEAR RQI
TSTB (R1) :RDI UP?
BMI 65\$:BR IF YES
BISB #44,(R1) :REC BA/CC
CLR TEMP :GET SET TO DELAY
TSTB (R1) :IS RDI SET?
BMI .+12 :BR IF YES
INC TEMP :INC DELAY
BNE 4\$:BR IF DELAY NOT DONE
ERROR 14 :ERROR RDI NOT SET
MOV #RBUF,4(R1) :LOAD REC BA
MOV RCOUNT,6(R1) :LOAD REC COUNT
BICB #40,(R1) :CLEAR RQI
CLR TEMP :GET SET TO DELAY
TSTB (R1) :RDI GONE?
BPL .+12 :BR IF YES
INC TEMP :INC DELAY
BNE 5\$:BR IF NO DONE
ERROR 14 :ERROR RDI STILL SET
BISB #40,(R1) :XMIT BA/CC
CLR TEMP :GET SET TO DELAY
TSTB (R1) :RDI SET?
BMI .+12 :BR IF YES
INC TEMP :INC DELAY
BNE 6\$:BR IF NOT DONE
ERROR 14 :ERROR RDI NOT SET
MOV #TBUF,4(R1) :LOAD XMIT BUFFER
MOV TCOUNT,6(R1) :LOAD COUNT
BICB #40,(R1) :CLEAR RQI
CLR TEMP :GET SET TO DELAY
TSTB (R1) :RDI GONE?
BPL .+12 :BR IF YES
INC TEMP :INC DELAY
BNE 7\$:BR IF NOT DONE DELAY
ERROR 14 :ERROR RDI STILL SET
CLR TEMP :GET SET TO DELAY
MOV #22,\$TMP0 :GET SET FOR LONG DELAY
TSTB 2(R1) :RDO SET?
BMI 17\$:BR IF YES
INC TEMP :INC DELAY
BNE 11\$:BR IF DELAY NOT DONE
DEC \$TMP0 :DEC DELAY COUNT

08-JUN-78 07:54 PAGE 49
CZKCGA.P11 08-JUN-78 07:53

J 5

PAGE: 0061C2

FREE RUNNING TESTS

2370 014436 001367
2371 014440 104014
2372 014442 016137 000002 001300 17\$: BNE 11\$;BR IF NOT DONE DELAY
2373 014450 001001
2374 014452 104014
2375 014454 032761 000004 000002
2376 014462 001032
2377 014464 005737 021306 12\$: BNE 14 ;ERROR RDO NOT SET
2378 014470 001401
2379 014472 104014
2380 014474 012737 177777 021306
2381 014502 132761 000001 000002
2382 014510 001401
2383 014512 104014
2384 014514 022761 021314 000004
2385 014522 001401
2386 014524 104014
2387 014526 023761 021312 000006
2388 014534 001401
2389 014536 104014
2390 014540 142761 000207 000002
2391 014546 000453
2392 014550 005737 021310 13\$: BNE 14 ;SAVE SEL2
2393 014554 001401
2394 014556 104014
2395 014560 012737 177777 021310
2396 014566 132761 000001 000002
2397 014574 001401
2398 014576 104014
2399 014600 022761 021362 000004
2400 014606 001401
2401 014610 104014
2402 014612 023761 021360 000006
2403 014620 001401
2404 014622 104014
2405 014624 013700 021360
2406 014630 012702 021314
2407 014634 012703 021362
2408 014640 010337 001302 9\$: BNE 14 ;BR IF OK
2409 014644 112205
2410 014646 112304
2411 014650 120504
2412 014652 001401
2413 014654 104013
2414 014656 005300
2415 014660 001367
2416 014662 005713
2417 014664 001401
2418 014666 104014
2419 014670 142761 000207 000002 15\$: BNE 14 ;ERROR!!! SEL2 = 0...
2420 014676 005737 021310
2421 014702 001640
2422 014704 005737 021306
2423 014710 001635
2424 014712 004737 022442
2425 014716 012700 014744
MOV 2(R1),\$TMP1 ;REC OR XMIT?
BNE .+4 ;BR IF REC
BIT #BIT2,2(R1) ;FIRST TIME HERE?
BNE 13\$;BR IF YES
TST TFLAG ;ERROR MULTIPLE XMIT DONES
BEQ .+4 ;SET TFLAG TO -1
ERROR 14 ;IS IT CONTROL 0
BEQ .+4 ;BR IF NO
ERROR 14 ;XMIT ERROR
CMP #TBUF,4(R1) ;XMIT BA CORRECT?
BEQ .+4 ;BR IF YES
ERROR 14 ;XMIT BA ERROR
CMP TCOUNT,6(R1) ;COUNT OK?
BEQ .+4 ;BR IF YES
ERROR 14 ;XMIT COUNT ERROR
BICB #207,2(R1) ;CLEAR RDO AND BITS 0-2
BR 15\$;CONTINUE
TST RFLAG ;FIRST TIME HERE?
BEQ .+4 ;BR IF YES
ERROR 14 ;ERROR MULTIPLE REC DONES
MOV #-1,RFLAG ;SET RFLAG TO -1
BITB #BIT0,2(R1) ;IS IT CNTL 0
BEQ .+4 ;BR IF NO
ERROR 14 ;RECEIVE ERROR
CMP #RBUF,4(R1) ;REC BA CORRECT?
BEQ .+4 ;BR IF YES
ERROR 14 ;REC BA ERROR
CMP RCOUNT,6(R1) ;COUNT OK?
BEQ .+4 ;BR IF YES
ERROR 14 ;REC COUNT ERROR
MOV RCOUNT,R0 ;GET SET TO CHECK DATA
MOV #TBUF,R2 ;R2 POINTS TO GOOD DATA
MOV #RBUF,R3 ;R3 POINTS TO RECEIVE DATA
MOV R3,\$TMP2 ;SAVE ADDRESS FOR TYPEOUT
MOV B (R2)+,R5 ;R5 = XMIT DATA
MOV B (R3)+,R4 ;R4 = RECIVE DATA
CMPB R5,R4 ;CHECK DATA
BEQ .+4 ;BR IF OK
ERROR 13 ;DATA ERROR
DEC R0 ;DEC COUNT
BNE 9\$;BR IF NOT DONE
TST (R3) ;THIS SHOULD BE 0, ELSE
BEQ .+4 ;IT RECEIVED TO MUCH!!
ERROR 14 ;ERROR
BICB #207,2(R1) ;CLEAR RDO AND BITS 0-2
TST RFLAG ;REC DONE?
BEQ 16\$;BR IF NO
TST TFLAG ;XMIT DONE?
BEQ 16\$;BR IF NO
JSR PC_SHUTDOWN ;SHUTDOWN KMC
MOV #25\$,R0 ;pointer to expected soft counts

08-JUN-78 07:54 PAGE 50
CZKCGA.P11 08-JUN-78 07:53

K 5

PAGE: 006202

FREE RUNNING TESTS

2426 014722 012701 021433 21\$: MOV #BASEMC+3,R1 ; POINTER TO ACTUAL COUNTS
2427 014726 012702 000010 20\$: MOV #10,R2 ; COUNT
2428 014732 122021 CMPB (R0)+,(R1)+ ; COMPARE SOFT ERROR COUNTS
2429 014734 001007 BNE 23\$; IF ERROR BR 23\$
2430 014736 005302 DEC R2 ; DEC COUNT
2431 014740 001374 BNE 22\$; CONTINUE CHECKING IF NOT DONE
2432 014742 000421 BR 24\$; ALL COUNTS OK, GET OUT
2433 014744 000 000 000 25\$: .BYTE 0,0,0,0,0,0,0,0 ; EXPECTED ERROR COUNTS
2434 014747 000 000 000
2435 014752 000 000
2436 014754 113737 021433 001300 23\$: MOVB BASEMC+3,\$TMP1
2437 014762 113737 021435 001302 MOVB BASEMC+5,\$TMP2
2438 014770 113737 021437 001304 MOVB BASEMC+7,\$TMP3
2439 014776 113737 021441 001306 MOVB BASEMC+11,\$TMP4
2440 015004 104017 ERROR 17
2441 015006
2442 015006 24\$: ;SCOPE
2443
2444
2445 ;***** TEST 2 *****
2446 ;OVERUN TEST
2447 ;IN FREE RUNNING MODE SEND MESSAGE WITH NO RECEIVE
2448 ;BUFFER AVAILABLE, VERIFY THAT AN OVERRUN ERROR OCCURS
2449 ;*****
2450
2451 ; TEST 2
2452 ;-----
2453 ;*****
2454 015006 000004 TST2: SCOPE ; LOAD THE NO. OF THIS TEST
2455 015010 012737 000002 001202 MOV #2,\$TSTMN ; POINT TO THE START OF NEXT TEST.
2456 015016 012737 015200 001442 MOV #TST3,NEXT ; R1 CONTAINS BASE KMC11 ADDRESS
2457
2458
2459 015024 004737 022030 :
2460 015030 004537 022410 JSR PC,BASELD ; LOAD KMC BASEMC ADDRESS
2461 015034 021314 JSR R5,XFRELD ; LOAD XMIT BA/CC
2462 015036 000044 TBUF ; BA
2463 015040 012700 000010 44 ; CC
2464 015044 012703 000015 MOV #10,R0 ; R0 = RETRANSMISSION COUNT
2465 015050 005037 011122 MOV #15,R3 ; DELAY COUNT
2466 015054 105761 000002 CLR TEMP ; CLEAR DELAY COUNTER
2467 015060 100407 1\$: TSTB 2(R1) ; IS RDY 0 SET?
2468 015062 005237 011122 BMI .+20 ; BR IF SET
2469 015066 001372 INC TEMP ; INC DELAY COUNTER
2470 015070 005303 BNE 1\$; BR IF NOT DONE DELAY
2471 015072 001370 DEC R3 ; DEC DELAY COUNT
2472 015074 104014 BNE 1\$; BR IF DELAY NOT DONE
2473 015076 000431 ERROR 14 ; ERROR, RDY 0 NOT SET
2474 015100 132761 000001 000002 BR 10\$; GET OUT
2475 015106 001002 BITB #BIT0,2(R1) ; IS IT CNTL 0?
2476 015110 104014 BNE 11\$; BR IF YES
2477 015112 000423 ERROR 14 ; ERROR, NOT CNTL 0
2478 015114 012705 000004 11\$: BR 10\$; CONTINUE
2479 015120 016104 000006 MOV #BIT2,R5 ; PUT 'EXPECTED' IN R5
2480 015124 020504 MOV 6(R1),R4 ; PUT 'FOUND' IN R4
2481 015126 001404 CMP R5,R4 ; IS ORUN SET?
BEQ 12\$; BR IF YES

08-JUN-78 07:54 PAGE 51
CZKCGA.P11 08-JUN-78 07:53

L 5

PAGE: 0063r2

FREE RUNNING TESTS

FREE RUNNING TESTS

```

2538 015336          10$: ;SCOPE           ;SCOPE THIS TEST
2539
2540
2541 ;***** TEST 4 *****
2542 ;*TRANSMIT NON-EXISTENT MEMORY TEST
2543 ;*IN FREE RUNNING MODE, LOAD A TRANSMIT BA THAT WILL TIME OUT
2544 ;*VERIFY THAT A NON-EXISTENT MEMORY ERROR OCCURS
2545 ;*****
2546
2547
2548
2549
2550 015336 000004      TST4: SCOPE
2551 015340 012737 000004 001202      MOV #4,$TSTMN      ; LOAD THE NO. OF THIS TEST
2552 015346 012737 015464 001442      MOV #TSTS,NEXT   ; POINT TO THE START OF NEXT TEST.
2553
2554 015354 104410      : MSTCLR
2555
2556 015356 004737 022030      : $SKIPT 10$      ;R1 CONTAINS BASE KMC11 ADDRESS
2557 015362 004537 022410      : JSR PC,BASELD   ;MASTER CLEAR KMC11
2558 015366 177320      : JSR R5,XFRELD   ;LOAD KMC BASEMC ADDRESS
2559 015370 140044      : 177320
2560 015372 012703 000015      : 140044
2561 015376 005037 011122      : MOV #15,R3      ;LOAD XMIT BA/CC
2562 015402 105761 000002      : CLR TEMP       ;BA
2563 015406 100407          : INC TEMP       ;CC
2564 015410 005237 011122      : TSTB 2(R1)     ;DELAY COUNT
2565 015414 001372          : BMI .+20       ;CLEAR DELAY COUNTER
2566 015416 005303          : INC TEMP       ;IS RDY 0 SET?
2567 015420 001370          : BNE 1$         ;BR IF SET
2568 015422 104014          : DEC R3         ;INC DELAY COUNTER
2569 015424 000417          : BNE 1$         ;BR IF NOT DONE DELAY
2570 015426 132761 000001 000002      : ERROR 14      ;DEC DELAY COUNT
2571 015434 001002          : BR 10$        ;BR IF DELAY NOT DONE
2572 015436 104014          : BNE 11$        ;ERROR, RDY 0 NOT SET
2573 015440 000411          : ERROR 14      ;GET OUT
2574 015442 012705 000400      : BR 10$        ;IS IT CNTL 0?
2575 015446 016104 000006      : BNE 11$        ;BR IF YES
2576 015452 020504          : ERROR 14      ;ERROR, NOT CNTL 0
2577 015454 001401          : BR 10$        ;CONTINUE
2578 015456 104015          : MOV #BIT8,R5   ;PUT 'EXPECTED' IN R5
2579 015460 004737 022442      : MOV 6(R1),R4   ;PUT 'FOUND' IN R4
2580 015464          11$: CMP R5,R4      ;IS NON-EX-MEM SET?
2581
2582
2583 ;***** TEST 5 *****
2584 ;*RECEIVE NON-EXISTENT MEMORY TEST
2585 ;*IN FREE RUNNING MODE, LOAD A RECEIVE BA THAT WILL TIME OUT
2586 ;*VERIFY THAT A NON-EXISTENT MEMORY ERROR OCCURS
2587 ;*****
2588
2589
2590
2591
2592 015464 000004      TST5: SCOPE
2593 015466 012737 000005 001202      MOV #5,$TSTMN   ; LOAD THE NO. OF THIS TEST

```

08-JUN-78 07:54 PAGE 53
(ZKCGA.P11 08-JUN-78 07:53

N 5

PAGE: 006502

FREE RUNNING TESTS

2594 015674 012737 015622 001442 MOV #TST6,NEXT ; POINT TO THE START OF NEXT TEST.
2595 015502 104410 MSTCLR \$SKIPT 10\$;R1 CONTAINS BASE KMC11 ADDRESS
2596 015504 004737 022030 JSR PC,BASELD ;MASTER CLEAR KMC11
2597 015510 004537 022356 JSR R5,RFRELD ;LOAD KMC BASEMC ADDRESS
2600 015514 177320 177320 ;LOAD RECEIVE BA/CC
2601 015516 140044 140044 ;BA
2602 015520 004537 022410 JSR R5,XFRELD ;CC
2603 015524 021314 TBUF ;LOAD XMIT BA/CC
2604 015526 000044 44 ;BA
2605 015530 012703 000015 MOV #15,R3 ;CC
2606 015534 005037 011122 CLR TEMP ;DELAY COUNT
2607 015540 105761 000002 1\$: TSTB 2(R1) ;CLEAR DELAY COUNTER
2608 015544 100407 BMI .+20 ;IS RDY 0 SET?
2609 015546 005237 011122 INC TEMP ;BR IF SET
2610 015552 001372 BNE 1\$;INC DELAY COUNTER
2611 015554 005303 DEC R3 ;BR IF NOT DONE DELAY
2612 015556 001370 BNE 1\$;DEC DELAY COUNT
2613 015560 104014 ERROR 14 ;BR IF DELAY NOT DONE
2614 015562 000417 BR 10\$;ERROR, RDY 0 NOT SET
2615 015564 132761 000001 000002 BITB #BIT0,2(R1) ;GET OUT
2616 015572 001002 BNE 11\$;IS IT CNTL 0?
2617 015574 104014 ERROR 14 ;BR IF YES
2618 015576 000411 BR 10\$;ERROR, NOT CNTL 0
2619 015600 012705 000400 11\$: MOV #BIT8,R5 ;CONTINUE
2620 015604 016104 000006 MOV 6(R1),R4 ;PUT 'EXPECTED' IN R5
2621 015610 020504 CMP R5,R4 ;PUT 'FOUND' IN R4
2622 015612 001401 BEQ .+4 ;IS NON-EX-MEM SET?
2623 015614 104015 ERROR 15 ;BR IF YES
2624 015616 004737 022442 JSR PC,SHUTDOWN ;ERROR NON-EX-MEM NOT SET
2625 015622 10\$: :SCOPE ;SHUTDOWN KMC
2626 :SCOPE THIS TEST
2627
2628 ;***** TEST 6 *****
2629 ;*PROCESSOR ERROR TEST
2630 ;*IN FREE RUNNING MODE, DO A BASEMC TRANSFER REQUEST AFTER A
2631 ;*BASEMC HAS BEEN SET UP, VERIFY THAT A PROCESSOR ERROR OCCURS.
2632 ;*****
2633
2634 ; TEST 6
2635 ;-----
2636 ;*****
2637 015622 000004 TST6: SCOPE ; LOAD THE NO. OF THIS TEST
2638 015624 012737 000006 001202 MOV #6,\$TSTNM ;POINT TO THE START OF NEXT TEST.
2639 015632 012737 015740 001442 MOV #TST7,NEXT ;R1 CONTAINS BASE KMC11 ADDRESS
2640
2641 015640 104410 MSTCLR \$SKIPT 10\$;MASTER CLEAR KMC11
2642
2643 015642 004737 022030 : JSR PC,BASELD ;LOAD BASEMC ADDRESS
2644 015646 152711 000043 '2\$: BISB #43,(R1) ;2ND BASEMC REQUEST
2645 015652 105711 TSTB (R1) ;RDI SET?
2646 015654 100376 BPL .-2 ;BR IF NO
2647 015656 142711 000040 BICB #40,(R1) ;CLEAR RQI
2648 015662 005037 011122 CLR TEMP ;GET SET TO DELAY
2649 015666 105761 000002 TSTB 2(R1) ;RDO SET?

08-JUN-78 07:54 PAGE 54
CZKCGA.P11 08-JUN-78 07:53

B 6

PAGE: 0066C2

FREE RUNNING TESTS

2650 015672 100405
2651 015674 005237 011122
2652 015700 001372
2653 015702 104014
2654 015704 000770
2655 015706 132761 000001 000002
2656 015714 001002
2657 015716 104014
2658 015720 000407
2659 015722 012705 001000
2660 015726 016104 000006
2661 015732 020504
2662 015734 001401
2663 015736 104015
2664 015740
2665
2666
2667 :***** TEST 7 *****
2668 ;PROCESSOR ERROR TEST
2669 ;IN FREE RUNNING MODE DO A RQI WITH AN ILLEGAL 10 CODE
2670 ;VERIFY THAT A PROCESSOR ERROR OCCURS
2671 :*****
2672
2673 : TEST 7
2674 :-----
2675
2676 015740 000004
2677 015742 012737 000007 001202
2678 015750 012737 016056 001442
2679
2680 015756 104410
2681
2682 015760 004737 022030
2683 015764 152711 000046
2684 015770 105711
2685 015772 100376
2686 015774 142711 000040
2687 016000 005037 011122
2688 016004 105761 000002
2689 016010 100405
2690 016012 005237 011122
2691 016016 001372
2692 016020 104014
2693 016022 000770
2694 016024 132761 000001 000002
2695 016032 001002
2696 016034 104014
2697 016036 000407
2698 016040 012705 001000
2699 016044 016104 000006
2700 016050 020504
2701 016052 001401
2702 016054 104015
2703 016056
2704
2705

BMI 14\$:BR IF YES
INC TEMP :INC DELAY
BNE 13\$:BR IF NOT DONE DELAY
ERROR 14 :ERROR, RDO NOT SET
BR 13\$:TRY AGAIN
BITB #BIT0,2(R1) :IS IS CNTL 0?
BNE 11\$:BR IF YES
ERROR 14 :ERROR NOT CNTL 0
BR 10\$:CONTINUE
MOV #BIT9,R5 :PUT 'EXPECTED' IN R5
MOV 6(R1),R4 :PUT 'FOUND' IN R4
CMP R5,R4 :IS PROC ERROR SET?
BEQ +4 :BR IF YES
ERROR 15 :ERROR, PROC ERROR NOT SET
;SCOPE :SCOPE THIS TEST

;***** TEST 7 *****
;PROCESSOR ERROR TEST
;IN FREE RUNNING MODE DO A RQI WITH AN ILLEGAL 10 CODE
;VERIFY THAT A PROCESSOR ERROR OCCURS
;*****

: TEST 7

:TST7: SCOPE
MOV #7,\$TSTMN : LOAD THE NO. OF THIS TEST
MOV #TST10,NEXT : POINT TO THE START OF NEXT TEST.
:R1 CONTAINS BASE KMC11 ADDRESS
:MASTER CLEAR KMC11
MSTCLR :
\$SKIPT 10\$:
JSR PC,BASELD :LOAD KMC BASEMC ADDRESS
BISB #46,(R1) :RQI AND ILLEGAL CODE
TSTB (R1) :WAIT FOR RDI
BPL -2 :BR IF NO RDI
BICB #40,(R1) :CLEAR RQI
CLR TEMP :CLEAR COUNTER
:RDY 0 SET?
TSTB 2(R1) :
BMI +14 :BR IF YES
INC TEMP :BUMP COUNTER DELAY
BNE 1\$:BR IF NOT DONE
ERROR 14 :ERROR NO RDY 0
BR 1\$:TRY AGAIN
BITB #BIT0,2(R1) :IS IT CNTL 0
BNE 11\$:BR IF YES
ERROR 14 :ERROR, NOT CNTL 0
BR 10\$:CONTINUE
MOV #BIT9,R5 :PUT 'EXPECTED' IN R5
MOV 6(R1),R4 :PUT 'FOUND' IN R4
CMP R5,R4 :IS PROC ERROR SET?
BEQ +4 :BR IF YES
ERROR 15 :ERROR, PROC ERROR NOT SET
;SCOPE :SCOPE THIS TEST

FREE RUNNING TESTS

```

2706
2707
2708
2709
2710
2711
2712
2713
2714
2715 016056 000004
2716 016060 012737 000010 001202
2717 016066 012737 016156 001442
2718
2719 016074 104410
2720
2721 016076 004737 022136
2722 016102 004537 022356
2723 016106 021362
2724 016110 000044
2725 016112 004537 022410
2726 016116 021314
2727 016120 000044
2728 016122 012703 000003
2729 016126 005037 011122
2730 016132 105761 000002
2731 016136 100406
2732 016140 005237 011122
2733 016144 001372
2734 016146 005303
2735 016150 001370
2736 016152 000401
2737 016154 104014
2738 016156
2739
2740
2741
2742
2743
2744
2745
2746
2747
2748
2749
2750
2751
2752 016156 000004
2753 016160 012737 000011 001202
2754 016166 012737 016370 001442
2755
2756 016174 104410
2757
2758 016176 005037 020050
2759 016202 005737 020050
2760 016206 001003
2761 016210 004737 022030

                                **** TEST 10 ****
                                ;HALF DUPLEX TEST
                                ;IN FREE RUNNING MODE, SET HALF DUPLEX AND L U LOOP
                                ;SEND A MESSAGE AND VERIFY THAT THERE ARE NO DONES
                                **** TEST 10 ****

TST10: SCOPE
       MOV    #10,$TSTNM          ; LOAD THE NO. OF THIS TEST
       MOV    #TST11,NEXT          ; POINT TO THE START OF NEXT TEST.
                               ;R1 CONTAINS BASE KMC11 ADDRESS
       MSTCLR
       $$KIPT 10$                ;MASTER CLEAR KMC11
       JSR    PC,BASELH           ;LOAD BASEMC AND HALF DUPLEX
       JSR    R5,RFRELD           ;LOAD RECEIVE BUFFER
       RBUF
       44
       JSR    R5,XFRELD           ;LOAD TRANSMIT BUFFER
       TBUF
       44
       MOV    #3,R3                ;LOAD DELAY COUNT
       CLR    TEMP                ;CLEAR DELAY
       4$:   TSTB    2(R1)          ;IS DONE SET?
       BMI    $$
       INC    TEMP                ;INC DELAY
       BNE    4$                ;BR IF DELAY NOT DONE
       DEC    R3                ;DEC DELAY COUNT
       BNE    4$                ;BR IF DELAY NOT DONE
       BR    10$                ;ERROR DONE WITH HALF-DUPLEX
       5$:   ERROR   14
       10$:

                                **** TEST 11 ****
                                ;RESUME TEST
                                ;THIS TEST SENDS AND RECEIVES A BUFFER AND SHUTS DOWN THE
                                ;KMC. THEN A MASTER CLEAR IS ISSUED AND A BASEMC WITH RESUME
                                ;BIT SET IS GIVEN, ANOTHER BUFFER IS SENT AND RECEIVED.
                                ;DATA IS CHECKED.
                                **** TEST 11 ****

TST11: SCOPE
       MOV    #11,$TSTNM          ; LOAD THE NO. OF THIS TEST
       MOV    #TST12,NEXT          ; POINT TO THE START OF NEXT TEST.
                               ;R1 CONTAINS BASE KMC11 ADDRESS
       MSTCLR
       $$KIPT 10$                ;MASTER CLEAR KMC11
       CLR    RESUME              ;CLR RESUME FLAG
       1$:   TST    RESUME          ;FIRST OR SECOND PASS?
       BNE    2$                ;BR IF SECOND
       JSR    PC,BASELD           ;BASEMC

```

08-JUN-78 07:54 PAGE 56
CZKCGA.P11 08-JUN-78 07:53

D 6

PAGE: 0068C2

FREE RUNNING TESTS

2762 016214 000402
2763 016216 004737 022246 2\$: BR 3\$: JSR PC,RESUM :CONTINUE
2764 016222 004537 022356 3\$: JSR R5,RFRELD :BASEMC WITH RESUME BIT
2765 016226 021362 RBUF :RECEIVE BUFFER
2766 016230 000044 44 :BA
2767 016232 004537 022410 JSR R5,XFRELD :CC
2768 016236 021314 TBUF :XMIT BUFFER
2769 016240 000044 44 :BA
2770 016242 012703 000030 MOV #30,R3 :CC
2771 016246 012700 000002 MOV #2,R0 :DELAY COUNT
2772 016252 005037 011122 CLR TEMP :NEED TWO DONES
2773 016256 105761 000002 4\$: TSTB 2(R1) :CLEAR DELAY COUNTER
2774 016262 100407 BMJ .+20 :IS RDY 0 SET?
2775 016264 005237 011122 INC TEMP :BR IF SET
2776 016270 001372 BNE 4\$:INC DELAY COUNTER
2777 016272 005303 DEC R3 :BR IF NOT DONE DELAY
2778 016274 001370 BNE 4\$:DEC DELAY COUNT
2779 016276 104014 ERROR 14 :BR IF DELAY NOT DONE
2780 016300 000433 BR 10\$:ERROR, RDY 0 NOT SET
2781 016302 042761 000207 000002 BIC #207,2(R1) :GET OUT
2782 016310 005300 DEC R0 :CLEAR DONE
2783 016312 001361 BNE 4\$:TWO DONES YET?
2784 016314 012702 021314 MOV #TBUF,R2 :BR IF NOT
2785 016320 012703 021362 MOV #RBUF,R3 :ADDRESS OF GOOD DATA
2786 016324 012700 000044 MOV #44,R0 :ADDRESS OF RECEIVED DATA
2787 016330 112205 6\$: MOVB (R2)+,R5 :COUNT
2788 016332 112304 MOVB (R3)+,R4 :LOAD GOOD DATA
2789 016334 120504 CMPB R5,R4 :LOAD FOUND DATA
2790 016336 001401 BEQ 7\$:COMPARE DATA
2791 016340 104012 ERROR 12 :BR IF OK
2792 016342 005300 7\$: DEC R0 :DATA ERROR
2793 016344 001371 BNE 6\$:DONE YET?
2794 016346 004737 022442 JSR PC,SHUTDOWN :BR IF NOT
2795 016352 005737 020050 TST RESUME :SHUTDOWN KMC
2796 016356 001004 BNE 8\$:
2797 016360 012737 177777 020050 MOV #-1,RESUME :BR IF ALL DONE
2798 016366 000705 BR 1\$:SET FLAG FOR SECOND PASS
2799 016370 8\$: :CONTINUE
2800 016370 10\$: ;SCOPE :SCOPE THIS TEST
2801
2802
2803 :***** TEST 12 *****
2804 ;FREE RUNNING DATA TEST (INTERRUPT DRIVEN EXERCISER)
2805 ;THIS TEST REPEATEDLY QUEUES UP 7 RECEIVE BUFFERS AND
2806 ;7 TRANSMIT BUFFERS AND CHECKS DATA WHEN ALL 7 BUFFERS
2807 ;ARE RECEIVED. TRANSMIT COUNTS RANGE FROM 2 TO 104.
2808 ;DATA IS A BINARY COUNT PATTERN. THE RESUME FUNCTION
2809 ;IS CHECKED IN THIS TEST. THIS TEST USES THE TURNAROUND CONNECTOR
2810 ;IF IT IS PRESENT, OTHERWISE LINE UNIT LOOP IS SET.
2811 ;*****
2812 ; TEST 12
2813 ;-----
2814 ;*****
2815 ;TST12: SCOPE
2816 016370 000004 MOV #12,\$TSTNM : LOAD THE NO. OF THIS TEST
2817 016372 012737 000012 001202

08-JUN-78 07:54 PAGE 57
CZKCGA.P11 08-JUN-78 07:53

FREE RUNNING TESTS

E 6

PAGE: 0069C2

```

2818 C16400 012737 003662 001442           MOV    #SEOP,NEXT      ; POINT TO THE START OF NEXT TEST.
2819 016406 104410                         : MSTCLR $SKIPT        ;R1 CONTAINS BASE KMC11 ADDRESS
2820 016410 012737 000340 177776          :         ENDEX1       ;MASTER CLEAR KMC11
2821 016416 013700 002050                 :         MOV #340,PS      ;LOCK OUT INTERRUPTS
2822 016422 006200                         :         MOV STAT1,R0     ;GET BR LEVEL
2823 016424 006200                         :         ASR R0          ;SHIFT RIGHT 4 TIMES
2824 016426 006200                         :         ASR R0          ;
2825 016430 006200                         :         ASR R0          ;
2826 016432 042700 177437                 :         BIC #177437,R0   ;PUT BR LEVEL IN R0
2827 016436 012777 017132 163412          :         MOV #IISR,AKMRVEC ;LOAD INPUT VECTOR
2828 016444 010077 163410                 :         MOV R0,AKMRLVL    ;LOAD LEVEL
2829 016450 012777 017422 163404          :         MOV #OISR,AKMTVEC ;LOAD OUTPUT VECTOR
2830 016456 010077 163402                 :         MOV R0,AKMTLVL    ;LOAD LEVEL
2831
2832
2833
2834 ;INITIALIZE ALL BUFFER LISTS AND COUNT LISTS
2835
2836 016462 012737 000104 021306          MOV    #104,TFLAG      ;TFLAG CONTAINS COUNT
2837 016470 012700 020054                 MOV    #XMITBA+2,R0    ;R0 POINTS TO BA LIST
2838 016474 012703 020346                 MOV    #RBUFF,R3       ;R3 CONTAINS BUFFER ADDRESS
2839 016500 010320                         1$:   MOV R3,(R0)+      ;LOAD BA LIST WITH REC BA
2840 016502 062703 000104                 ADD    #104,R3        ;UPDATE BUFFER ADDRESS
2841 016506 022700 020072                 CMP    #XMITBA+20,R0   ;END OF REC BUFFERS?
2842 016512 001372                         BNE    1$             ;NO LOAD NEXT ONE
2843 016514 012720 020110                 2$:   MOV #TBUFF,(R0)+   ;LOAD BA LIST WITH XMIT BA
2844 016520 022700 020110                 CMP    #XMITBA+36,R0   ;END OF XMIT BUFFERS?
2845 016524 001373                         BNE    2$             ;NO LOAD NEXT BUFFER
2846 016526 012700 020222                 MOV    #RCNTAB+2,R0    ;R0 POINTS TO COUNT LIST
2847 016532 013720 021306                 3$:   MOV TFLAG,(R0)+   ;LOAD COUNT OF 104
2848 016536 022700 020240                 CMP    #RCNTAB+20,R0   ;END OF REC COUNT LIST?
2849 016542 001373                         BNE    3$             ;BR IF NO
2850 016544 012737 090005 021304          MOV    #5,FLAG ;LOOP COUNT
2851 016552 012711 040000                 MOV    #BIT14,(R1)    ;SET MASTER CLEAR
2852
2853
2854 016556 012711 100000                 : BIT    #BIT15,STAT1   ;IOP?
2855 016562 012700 177777                 : BEQ    .+6            ;BR IF NO
2856 016566 005037 020050                 :         MOV #BIT15,(R1)   ;SET RUN ON IOP
2857 016572 012705 020256                 CLRTAB: CLR    RESUME        ;R0 IS INPUT DONE COUNTER
2858 016576 005025                         2$:   MOV #RDNTAB,R5     ;CLEAR RESUME FLAG
2859 016600 022705 021302                 CLR    (R5)+          ;GET READY TO CLEAR ALL RECEIVE
2860 016604 001374                         CMP    #RBUFFE,R5     ;BUFFERS
2861 016606 012704 020240                 BNE    2$             ;END OF BUFFER?
2862 016612 013724 021306                 4$:   MOV #XCNTAB,R4     ;BR IF NO
2863 016616 022704 020256                 MOV    TFLAG,(R4)+   ;R4 POINTS TO XMIT COUNT LIST
2864 016622 001373                         CMP    #XCNTAB+16,R4   ;LOAD XMIT CHAR COUNT
2865 016624 005002                         BNE    4$             ;DONE?
2866 016626 005004                         5$:   MOV CLR R2          ;BR IF NO
2867 016630 005711                         CLR    R4          ;R2 IS OUTPUT DONE COUNTER
2868 016632 100376                         TST    (R1)         ;R4 IS USED AS INDEX IN OISR
2869 016634 152761 000100 000002          BPL    .-2            ;IS RUN SET?
2870 016642 032737 040000 002050          BISB  #BIT6,2(R1)    ;WAIT FOR RUN
2871 016650 001002                         BIT    #BIT14,STAT1   ;SET IEO
2872 016652 052711 004000                 BNF    .+6            ;LOOP BACK CONNECTOR?
2873 016656 022737 000005 021304          BIS    #BIT11,(R1)    ;BR IF YES
2874
2875

```

08-JUN-78 07:54 PAGE 58
CZKCGA.P11 08-JUN-78 07:53

F 6

PAGE: 0070C2

FREE RUNNING TESTS

2874	016664	001003		BNE	1\$:BR IF NOT	
2875	016666	052711	000143	BIS	#143,(R1)	:SET IEI,RQI,BASEMC I	
2876	016672	000402		BR	3\$:CONTINUE	
2877	016674	052711	000144	1\$: BIS	#144,(R1)	:SET IEI, RQI, RFC BA/CC	
2878	016700	005037	011122	3\$: CLR	TEMP	:SET UP FOR DELAY COUNT	
2879	016704	012737	000022	MOV	#22,\$TMP1	:GET SET FOR DELAY	
2880	016712	005037	177776	CLR	PS	:ALLOW INTERRUPTS	
2881	016716	022700	000020	SCAN:	CMP #20,R0	:INPUT DONE?	
2882	016722	001402		BEQ	SCAN2	:BR IF YES	
2883	016724	000137	017102	JMP	SCAN1	:BR IF NO	
2884	016730	022702	000034	SCAN2:	CMP #34,R2	:XMIT DONE FOR ALL MESSAGES?	
2885	016734	001402		BEQ	8\$:BR IF YES	
2886	016736	000137	017102	JMP	SCAN1	:BR IF NO	
2887	016742	022704	000034	8\$: CMP	#34,R4	:REC DONE FOR ALL MESSAGES?	
2888	016746	001402		BEQ	9\$:BR IF YES	
2889	016750	000137	017102	JMP	SCAN1	:BR IF NO	
2890	016754			9\$:			
2891	016754	012700	020256	MOV	#RDNTAB,R0	:GET FIRST REC BUFFER	
2892	016760	012002		5\$: MOV	(R0)+,R2	:R2 POINTS TO BUFFER	
2893	016762	005005		CLR	R5	:R5=EXPECTED	
2894	016764	005003		CLR	R3	:R3 = COUNT	
2895	016766	010237	001302	6\$: MOV	R2,\$TMP2	:SAVE ADDRESS FOR TYPEOUT	
2896	016772	112204		MOVB	(R2)+,R4	:GET RECEIVE DATA	
2897	016774	120504		CMPB	R5,R4	:IS IT CORRECT?	
2898	016776	001401		BEQ	+4	:BR IF YES	
2899	017000	104013		ERROR	13	:DATA ERROR	
2900	017002	005205		INC	R5	:NEXT CHARACTER	
2901	017004	005203		INC	R3	:INC COUNT	
2902	017006	021003		CMP	(R0),R3	:DONE YET?	
2903	017010	001366		BNE	6\$:BR IF NO	
2904	017012	062700	000002	ADD	#2,R0	:GET NEXT REC BUFFER	
2905	017016	022700	020312	CMP	#RDNTAB+34,R0	:DONE YET?	
2906	017022	001356		BNE	5\$:BR IF NO	
2907	017024	012700	000001	MOV	#1,R0	:SET R0 TO 1	
2908	017030	032737	000001	021304	4\$: BIT	#BIT0,FLAG	:CHANGE CHAR COUNT FOR NEXT LOOP
2909	017036	001003		BNE	1\$:BR TO SUB 40	
2910	017040	005337	021306	DEC	TFLAG	:DEC BY ONE	
2911	017044	000403		BR	2\$:CONTINUE	
2912	017046	162737	000040	021306	1\$: SUB	#40,TFLAG	:SUBTRACT 40 FROM XMIT COUNT
2913	017054	005337	021304	2\$:	DEC	FLAG	:DEC LOOP COUNT
2914	017060	001242		BNE	CLRTAB	:GO DO IT AGAIN	
2915	017062	152711	000146	ENDEX:	BISB	#146,(R1)	:SHUT DOWN KMC
2916	017066	005737	021304	1\$:	TST	FLAG	:HAS INTERRUPT OCCURED?
2917	017072	001775		BEQ	1\$:BR IF NO	
2918	017074	000400		BR	ENDEX1	:ALL OK GET OUT	
2919	017076	000004		ENDEX1:	SCOPE	:SCOPE THIS TEST	
2920	017100	104420		ENDEX2:	ADVANCE		
2921	017102	005337	011122	SCAN1:	DEC	TEMP	:DECREMENT DELAY COUNTER
2922	017106	001402		BEQ	1\$:BR IF ZERO	
2923	017110	000137	016716	JMP	SCAN	:BR IF NOT DONE DELAY	
2924	017114	005337	001300	1\$:	DEC	\$TMP1	:DEC DELAY COUNT
2925	017120	001402		BEQ	2\$:BR IF DONE DELAY	
2926	017122	000137	016716	JMP	SCAN	:BR IF NOT DONE	
2927	017126	104001		2\$:	ERROR	1	:ERROR HUNG
2928	017130	000762		BR	ENDEX1	:GET OUT	
2929							

FREE RUNNING TESTS

2930
 2931 :INPUT INTERRUPT SERVICE ROUTINE
 2932 017132 022700 000017
 2933 017136 001421
 2934 017140 005737 020050
 2935 017144 001432
 2936 017146 032711 000002
 2937 017152 001407
 2938 017154 012761 021430 000004
 2939 017162 012761 010000 000006
 2940 017170 000404
 2941 017172 005061 000006
 2942 017176 005037 020050
 2943 017202 142711 000040
 2944 017206 105711
 2945 017210 100776
 2946 017212 005737 020050
 2947 017216 001403
 2948 017220 152711 000041
 2949 017224 000002
 2950 017226 105011
 2951 017230 000002
 2952 017232 005700
 2953 017234 100006
 2954 017236 012761 021430 000004
 2955 017244 005061 000006
 2956 017250 000434
 2957 017252 001003
 2958 017254 005061 000006
 2959 017260 000430
 2960 017262 032700 000010
 2961 017266 001013
 2962 017270 000241
 2963 017272 006100
 2964 017274 016061 020052 000004
 2965 017302 016061 020220 000006
 2966 017310 000241
 2967 017312 006000
 2968 017314 000412
 2969 017316 000241
 2970 017320 006100
 2971 017322 016061 020052 000004
 2972 017330 016061 020220 000006
 2973 017336 000241
 2974 017340 006000
 2975 017342 142711 000040
 2976 017346 105711
 2977 017350 100776
 2978 017352 005200
 2979 017354 001003
 2980 017356 152711 000041
 2981 017362 000002
 2982 017364 022700 000017
 2983 017370 001411
 2984 017372 032700 000010
 2985 017376 001003
 IISR: CMP #17,R0 ;PROC. ERROR DONE?
 BEQ 12\$;BR IF YES
 TST RESUME ;IS THIS A RESUME INTERRUPT
 BEQ 8\$;BR IF NO
 BIT #BIT1,(R1) ;CNTL OR BASEMC?
 BEQ 13\$;BR IF CNTL I
 MOV #BASEMC,4(R1) ;LOAD BASEMC ADDRESS
 MOV #BIT12,6(R1) ;WITH RESUME BIT SET
 BR 12\$;CONTINUE
 CLR 6(R1) ;SELECT FULL DUPLEX
 CLR RESUME ;CLEAR RESUME FLAG
 BICB #40,(R1) ;CLEAR RQI
 TSTB (R1) ;IS RLI GONE?
 BMI -2 ;BR IF NO
 TST RESUME ;BASEMC OR CNTL I?
 BEQ 14\$;BR IF IT WAS CNTL I
 BISB #41,(R1) ;ASK FOR CNTL I
 RTI ;RETURN
 CLR B (R1) ;CLEAR BSEL 0
 RTI ;RETURN
 14\$: TST R0 ;FIRST TIME HERE?
 BPL 7\$;LOAD BASEMC IF MINUS
 MOV #BASEMC,4(R1) ;SET UP BASEMC ADDRESS
 CLR 6(R1) ;CLEAR COUNT
 BR 3\$;CONTINUE
 7\$: BNE 1\$;CNTL I FULL DUPLEX IF 0
 CLR 6(R1) ;SELECT FULL DUPLEX
 BR 3\$;CONTINUE
 1\$: BIT #BIT3,R0 ;XMIT?
 BNE 2\$;BR IF YES
 CLC ;CLEAR CARRY
 ROL R0 ;MAKE R0 EVEN
 MOV RECBA(R0),4(R1) ;LOAD REC BUFFER
 MOV RCNTAB(R0),6(R1) ;LOAD COUNT
 CLC ;CLEAR CARRY
 ROR R0 ;GET R0 BACK
 BR 3\$;CONTINUE
 CLC ;CLEAR CARRY
 ROL R0 ;MAKE IT EVEN
 MOV XMITBA(R0),4(R1) ;LOAD XMIT BUFFER
 MOV RCNTAB(R0),6(R1) ;LOAD COUNT
 CLC ;CLEAR CARRY
 ROR R0 ;PUT IT BACK
 BICB #40,(R1) ;CLEAR RQI
 TSTB (R1) ;WAIT FOR
 BMI -2 ;RDI TO GO AWAY
 INC R0 ;INC COUNT
 BNE 6\$;IF 0 ASK FOR CNTL I
 BISB #41,(R1) ;ASK FOR CNTL I
 RTI ;RETURN
 6\$: CMP #17,R0 ;DONE YET?
 BEQ 4\$;BR IF YES
 BIT #BIT3,R0 ;XMIT?
 BNE 5\$;BR IF YES

08-JUN-78 07:54 PAGE 60
ZKCGA.P11 08-JUN-78 07:53

H 6

PAGE: 007202

FREE RUNNING TESTS

2986	017400	152711	000044		BISB	#44,(R1)	;ASK FOR REC BA/CC
2987	017404	000002			RTI		;RETURN
2988	017406	152711	000040	5\$:	BISB	#40,(R1)	;ASK FOR XMIT BA/CC
2989	017412	000002			RTI		;RETURN
2990	017414	152711	000046	4\$:	BISB	#46,(R1)	;FORCE PROC. ERROR
2991	017420	000002			RTI		;RETURN
2992							
2993						:OUTPUT INTERRUPT SERVICE ROUTINE	
2994							
2995	017422	032761	000001	000002	OISR:	BIT #BIT0,2(R1)	;IS THIS AN ERROR?
2996	017430	001463			BEQ 1\$;BR IF NO
2997	017432	005737	021304		TST FLAG		;IS THIS SHUT DOWN INTERRUPT?
2998	017436	001006			BNE 9\$;BR IF NO
2999	017440	005237	021304		INC FLAG		;YES MAKE FLAG NON-ZERO
3000	017444	022761	001000	000006	CMP #BIT9,6(R1)		;SHUT DOWN BIT SET?
3001	017452	001525			BEQ 10\$;YES ALL IS OK
3002	017454	022700	000017		CMP #17,R0		;RESUME INTERRUPT?
3003	017460	001035			BNE 11\$;BR IF NO
3004	017462	022761	001000	000006	CMP #BIT9,6(R1)		;PROC. ERROR BIT SET?
3005	017470	001031			BNE 11\$;BR IF NO
3006	017472	005200			INC R0		;BUMP COUNTER (TO 20)
3007	017474	012711	040000		MOV #BIT14,(R1)		;MASTER CLEAR DEVICE
3008					BIT #BIT15,STAT1		;KMC OR KMC?
3009					: BEQ .+14		;BR IF KMC
3010	017500	012711	100000		MOV #BIT15,(R1)		;SET RUN ON KMC
3011	017504	105227	000000		INC B	#0	;DELAY ON KMC
3012	017510	001375			BNE .-4		
3013	017512	012737	177777	020050	MOV #-1,RESUME	(R1)	;SET RESUME FLAG
3014	017520	005711			TST (R1)		;RUN SET?
3015	017522	100376			BPL .-2		;BR IF NO
3016	017524	012761	000100	000002	MOV #BIT6,2(R1)		;SET IEO
3017	017532	032737	040000	002050	BIT #BIT14,STAT1		;LOOP BACK CONNECTOR?
3018	017540	001002			BNE .+6		;BR IF YES
3019	017542	052711	004000		BIS #BIT11,(R1)		;SET LINE UNIT LOOP
3020	017546	052711	000143		BIS #143,(R1)		;ASK FOR PORT (BASEMC REQUEST)
3021	017552	000002			RTI		;RETURN
3022	017554	016137	000004	001302	11\$:	MOV 4(R1),\$TMP2	;SAVE FOR ERROR TYPEOUT
3023	017562	016137	000006	001304	MOV 6(R1),\$TMP3		;SAVE FOR ERROR TYPEOUT
3024	017570	104016			ERROR 16		;CNTL O ERROR
3025	017572	022626			CMP (SP)+,(SP)+		;ADJUST STACK
3026	017574	000137	017076		JMP ENDEX1		;GET OUT
3027	017600	032761	000004	000002	1\$:	BIT #BIT2,2(R1)	;RECEIVE?
3028	017606	001053			BNE 2\$;BR IF YES
3029	017610	022761	020110	000004	CMP #TBUFF,4(R1)		;IS XMIT BA CORRECT?
3030	017616	001412			BEQ 4\$;BR IF OK
3031	017620	022761	020111	000004	CMP #TBUFF+1,4(R1)		;IS XMIT BA CORRECT?
3032	017626	001406			BEQ 4\$;BR IF YES
3033	017630	012705	020110		MOV #TBUFF,R5		;R5 = EXPECTED
3034	017634	016137	000004	001302	MOV 4(R1),\$TMP2		;SAVE FOUND FOR TYPEOUT
3035	017642	104002			ERROR 2		;XMIT BA ERROR
3036	017644	005005			CLR R5		;R5 IS INDEX REG
3037	017646	026561	020240	000006	5\$:	CMP XCNTAB(R5),6(R1)	;IS CHAR COUNT OK?
3038	017654	001406			BEQ 6\$;BR IF YES
3039	017656	062705	000002		ADD #2,R5		;INC INDEX
3040	017662	022705	000016		CMP #16,R5		;DONE LIST YET?
3041	017666	001367			BNE 5\$;BR IF NO

FREE RUNNING TESTS

```

3042 017670 104003
3043 017672 016162 000004 020312       6$:   ERROR 3      ;XMIT COUNT ERROR
3044 017700 062702 000002               MOV 4(R1),XDNTAB(R2);STORE XMIT DONE BA
3045 017704 016162 000006 020312       ADD #2,R2    ;INC INDEX
3046 017712 062702 000002               MOV 6(R1),XDNTAB(R2);STORE XMIT DONE CC
3047 017716 142761 000207 000002       ADD #2,R2    ;INC INDEX
3048 017724 000002                   BICB #207,2(R1) ;CLEAR RDO
3049 017726 105011
3050 017730 105061 000002               RTI          ;RETURN
3051 017734 000002
3052 017736 012705 000002               10$:  CLR B (R1)   ;CLEAR SEL0
3053 017742 026561 020052 000004       CLR B 2(R1)   ;CLEAR SEL2
3054 017750 001406
3055 017752 062705 000002               RTI          ;RETURN
3056 017756 022705 000020               2$:   MOV #2,R5    ;SET UP R5 AS INDEX
3057 017762 001367
3058 017764 104004
3059 017766 005005               ERROR 4      ;REC BA ERROR
3060 017770 026561 020240 000006       3$:   CLR R5     ;R5 IS INDEX
3061 017776 001406               7$:   CMP XCNTAB(R5),6(R1);CHECK FOR CORRECT REC COUNT
3062 020000 062705 000002               BEQ 8$       ;BR IF YES
3063 020004 022705 000016               ADD #2,R5    ;INCREMENT R5
3064 020010 001367               CMP #16,R5   ;END OF LIST?
3065 020012 104005               BNE 7$       ;BR IF NOT
3066 020014 016164 000004 020256       8$:   ERROR 5      ;REC COUNT ERROR
3067 020022 062704 000002               MOV 4(R1),RDNTAB(R4);STORE REC BA
3068 020026 016164 000006 020256       ADD #2,R4    ;INC INDEX
3069 020034 062704 000002               MOV 6(R1),RDNTAB(R4);STORE REC DONE CC
3070 020040 142761 000207 000002       ADD #2,R4    ;INC INDEX
3071 020046 000002                   BICB #207,2(R1) ;CLEAR RDO
3072
3073
3074
3075
3076 020050 000000               RESUME: 0
3077 020052
3078 020052 000017               RECBA:
3079
3080 020110
3081 020110 000 001 002               XMITBA: .BLKW 17 ;REC & XMIT BA LIST
3082 020113 003 004 005
3083 020116 006 007
3084 020120 010 011 012               TBUFF: .BYTE 0,1,2,3,4,5,6,7 ;TRANSMIT DATA
3085 020123 013 014 015
3086 020126 016 017
3087 020130 020 021 022               .BYTE 10,11,12,13,14,15,16,17
3088 020133 023 024 025
3089 020136 026 027
3090 020140 030 031 032               .BYTE 20,21,22,23,24,25,26,27
3091 020143 033 034 035
3092 020146 036 037
3093 020150 040 041 042               .BYTE 30,31,32,33,34,35,36,37
3094 020153 043 044 045
3095 020156 046 047
3096 020160 050 051 052               .BYTE 40,41,42,43,44,45,46,47
3097 020163 053 054 055               .BYTE 50,51,52,53,54,55,56,57

```

08-JUN-78 07:54 PAGE 62
ZKCGA.P11 08-JUN-78 07:53

J 6

PAGE: 0074C2

FREE RUNNING TESTS

3098 020166 056 057 .BYTE 60,61,62,63,64,65,66,67
3099 020170 060 061 062 .BYTE 70,71,72,73,74,75,76,77
3100 020173 063 064 065
3101 020176 066 067
3102 020200 070 071 072
3103 020203 073 074 075
3104 020206 076 077
3105 020210 100 101 102 .BYTE 100,101,102,103,104,105,106,107
3106 020213 103 104 105
3107 020216 106 107
3108
3109 020220 000010 RCNTAB: .BLKW 10 ;RECEIVE COUNT TABLE
3110 020240 000007 XCNTAB: .BLKW 7 ;TRANSMIT COUNT TABLE
3111
3112 020256 000016 RDNTAB: .BLKW 16 ;RECEIVE DONE TABLE (BA/CC)
3113 020312 000016 XDNTAB: .BLKW 16 ;XMIT DONE TABLE (BA/CC)
3114
3115 020346 RBUFF: ;RECEIVER BUFFERS
3116 020346 000104 RBUFF1: .BLKB 104
3117 020452 000104 RBUFF2: .BLKB 104
3118 020556 000104 RBUFF3: .BLKB 104
3119 020662 000104 RBUFF4: .BLKB 104
3120 020766 000104 RBUFF5: .BLKB 104
3121 021072 000104 RBUFF6: .BLKB 104
3122 021176 000104 RBUFF7: .BLKB 104
3123 021302 000000 RBUFFE: 0 ;END OF RECEIVER BUFFERS
3124
3125
3126
3127 ;BUFFER AREA
3128 ;-----
3129
3130 021304 000000 FLAG: 0
3131 021306 000000 TFLAG: 0
3132 021310 000000 RFLAG: 0
3133 021312 000044 TCOUNT: 44
3134 021314 041101 042103 043105 TBUF: .ASCII/ABCDEFGHIJKLMNPQRSTUVWXYZ0123456789/
3135 021322 044107 045111 046113
3136 021330 047115 050117 051121
3137 021336 052123 053125 054127
3138 021344 055131 030460 031462
3139 021352 032464 033466 034470 .EVEN
3140
3141 021360 000044 RCOUNT: 44
3142 021362 021430 RBUF: .-.+46
3143 .EVEN
3144 021430 022030 BASEMC: .=.+256.
3145
3146
3147 ;SUBROUTINES
3148 ;-----
3149
3150
3151 022030 BASELD:
3152 ;THIS SUBROUTINE LOADS THE KMC WITH A BASEMC ADDRESS
3153 ;AND PUTS KMC INTO FULL-DUPLEX MODE

SUBROUTINES

3154
 3155 022030 012711 040000 :
 3156 : MOV #BIT14,(R1) ;MASTER CLEAR
 3157 : BIT #BIT15,STAT1 ;CRAM?
 3158 022034 012711 100000 :+6 ;BR IF NO
 3159 022040 105227 000000 :MOV #BIT15,(R1) ;IF CRAM SET RUN
 3160 022044 001375 :INC#0 ;DELAY
 3161 022046 005711 :BNE .-4 ;BR IF NOT DONE DELAY
 3162 022050 100376 :1\$: TST (R1) ;IS RUN SET?
 3163 022052 052711 004000 :BPL 1\$;BR IF NO
 3164 022056 152711 000043 :BIS #BIT11,(R1) ;SET LU LOOP
 3165 022062 105711 :2\$: TSTB (R1) ;BASEMC REQUEST
 3166 022064 100376 :BPL 2\$;RDY I SET?
 3167 022066 012761 021430 000004 :MOV #BASEMC,4(R1) ;LOAD BASEMC ADDRESS
 3168 022074 005061 000006 :CLR 6(R1) ;CLEAR CC
 3169 022100 142711 000040 :BICB #40,(R1) ;CLEAR RQI
 3170 022104 105711 :3\$: TSTB (R1) ;RDY I CLEAR?
 3171 022106 100776 :BMI 3\$;BR IF NO
 3172 022110 152711 000041 :BISB #41,(R1) ;ASK FOR CNTL I
 3173 022114 105711 :64\$: TSTB (R1) ;WAIT FOR RDI
 3174 022116 100376 :BPL 64\$;BR IF NOT SETY
 3175 022120 005061 000006 :CLR 6(R1) ;SET FULL DUPLEX
 3176 022124 142711 000040 :BICB #40,(R1) ;CLEAR RQI
 3177 022130 105711 :65\$: TSTB (R1) ;RDI UP?
 3178 022132 100776 :BMI 65\$;BR IF YES
 3179 022134 000207 :RTS PC ;RETURN
 3180
 3181 022136 :BASELH:
 3182 :THIS SUBROUTINE LOADS THE KMC WITH A BASEMC ADDRESS
 3183 ;AND PUTS KMC INTO HALF-DUPLEX MODE
 3184
 3185 022136 012711 040000 :
 3186 : MOV #BIT14,(R1) ;MASTER CLEAR
 3187 : BIT #BIT15,STAT1 ;CRAM?
 3188 022142 012711 100000 :+6 ;BR IF NO
 3189 022146 105227 000000 :MOV #BIT15,(R1) ;IF CRAM SET RUN
 3190 022152 001375 :INC#0 ;DELAY
 3191 022154 005711 :BNE .-4 ;BR IF NOT DONE DELAY
 3192 022156 100376 :1\$: TST (R1) ;IS RUN SET?
 3193 022160 052711 004000 :BPL 1\$;BR IF NO
 3194 022164 152711 000043 :BIS #BIT11,(R1) ;SET LU LOOP
 3195 022170 105711 :2\$: TSTB (R1) ;BASEMC REQUEST
 3196 022172 100376 :BPL 2\$;RDY I SET?
 3197 022174 012761 021430 000004 :MOV #BASEMC,4(R1) ;LOAD BASEMC ADDRESS
 3198 022202 005061 000006 :CLR 6(R1) ;CLEAR CC
 3199 022206 142711 000040 :BICB #40,(R1) ;CLEAR RQI
 3200 022212 105711 :3\$: TSTB (R1) ;RDY I CLEAR?
 3201 022214 100776 :BMI 3\$;BR IF NO
 3202 022216 152711 000041 :BISB #41,(R1) ;ASK FOR CNTL I
 3203 022222 105711 :64\$: TSTB (R1) ;WAIT FOR RDI
 3204 022224 100376 :BPL 64\$;BR IF NOT SETY
 3205 022226 012761 002000 000006 :MOV #BIT10,6(R1) ;SET HALF DUPLEX
 3206 022234 142711 000040 :BICB #40,(R1) ;CLEAR RQI
 3207 022240 105711 :65\$: TSTB (R1) ;RDI UP?
 3208 022242 100776 :BMI 65\$;BR IF YES
 3209 022244 000207 :RTS PC ;RETU

SUBROUTINES

3210
3211 022246
3212
3213
3214
3215 022246 012711 040000
3216
3217
3218 022252 012711 100000
3219 022256 105227 000000
3220 022262 001375
3221 022264 005711
3222 022266 100376
3223 022270 052711 004000
3224 022274 152711 000043
3225 022300 105711
3226 022302 100376
3227 022304 012761 021430 000004
3228 022312 012761 010000 000006
3229 022320 142711 000040
3230 022324 105711
3231 022326 100776
3232 022330 152711 000041
3233 022334 105711
3234 022336 100376
3235 022340 005061 000006
3236 022344 142711 000040
3237 022350 105711
3238 022352 100776
3239 022354 000207
3240
3241 022356

RESUM:
;THIS SUBROUTINE LOADS THE KMC WITH A BASEMC ADDRESS
;WITH RESUME BIT SET AND PUTS KMC INTO FULL-DUPLEX MODE
;
: MOV #BIT14,(R1) :MASTER CLEAR
: BIT #BIT15,STAT1 :CRAM?
: BEQ .+6 :BR IF NO
: MOV #BIT15,(R1) :IF CRAM SET RUN
: INCB #0 :DELAY
: BNE .-4 :BR IF NOT DONE DELAY
: 1\$: TST (R1) :IS RUN SET?
: BPL 1\$:BR IF NO
: BIS #BIT11,(R1) :SET LU LOOP
: BISB #43,(R1) :BASEMC REQUEST
: 2\$: TSTB (R1) :RDY I SET?
: BPL 2\$:BR IF NO
: MOV #BASEMC,4(R1) :LOAD BASEMC ADDRESS
: MOV #BIT12,6(R1) :SET RESUME BIT
: BICB #40,(R1) :CLEAR RQI
: 3\$: TSTB (R1) :RDY I CLEAR?
: BMI 3\$:BR IF NO
: BISB #41,(R1) :ASK FOR CNTL I
: 64\$: TSTB (R1) :WAIT FOR RDI
: BPL 64\$:BR IF NOT SETY
: CLR 6(R1) :SET FULL DUPLEX
: BICB #40,(R1) :CLEAR RQI
: 65\$: TSTB (R1) :RDI UP?
: BMI 65\$:BR IF YES
: RTS PC :RETURN

RFRELD:
;THIS SUBROUTINE LOADS THE KMC WITH A RECEIVE BA/CC
;
1\$: BISB #44,(R1) :REC BA/CC REQUEST
: TSTB (R1) :RDY I SET?
: BPL 1\$:BR IF NO
: MOV (R5)+,4(R1) :LOAD REC BA
: MOV (R5)+,6(R1) :LOAD REC CC
: BICB #40,(R1) :CLEAR RQI
: 2\$: TSTB (R1) :IS RDY I CLEAR
: BMI 2\$:BR IF NO
: RTS R5 :RETURN

XFRELD:
;THIS SUBROUTINE LOADS THE KMC WITH A TRANSMIT BA/CC
;
1\$: BISB #40,(R1) :XMIT BA/CC REQUEST
: TSTB (R1) :RDY I SET?
: BPL 1\$:BR IF NO
: MOV (R5)+,4(R1) :LOAD XMIT BA
: MOV (R5)+,6(R1) :LOAD XMIT CC
: BICB #40,(R1) :CLEAR RQI
: 2\$: TSTB (R1) :IS RDY I CLEAR
: BMI 2\$:BR IF NO
: RTS R5 :RETURN

SUBROUTINES

3266				
3267				
3268	022442			
3269				
3270				
3271	022442	042761	000207	000002
3272	022450	152711	000046	
3273	022454	105711		
3274	022456	100376		
3275	022460	142711	000040	
3276	022464	105761	000002	
3277	022470	100375		
3278	022472	000207		
3279	022474	012711	040000	
3280	022500	042711	140000	
3281	022504	005000		
3282	022506	004737	022614	
3283	022512	005011		
3284	022514	010061	000004	
3285	022520	012261	000006	
3286	022524	012711	002000	
3287	022530	012711	022000	
3288	022534	005200		
3289	022536	022700	002000	
3290	022542	003363		
3291	022544	004737	022614	
3292	022550	005000		
3293	022552	005011		
3294	022554	010061	000004	
3295	022560	012711	002000	
3296	022564	026122	000006	
3297	022570	001402		
3298	022572	104401	011054	
3299	022576	005200		
3300	022600	022700	002000	
3301	022604	003362		
3302	022606	012711	040000	
3303	022612	000207		
3304				
3305	022614	012702	023650	
3306	022620	032737	000002	002054
3307	022626	001402		
3308	022630	012702	027654	
3309	022634	000207		
3310				
3311	023650			
3312				

SHUTDOWN:

;THIS SUBROUTINE FORCES THE KMC TO UPDATE THE BASEMC TABLE

	BIC	#207,2(R1)	:CLEAR ANY OUTPUT DONES
	BISB	#46,(R1)	:ASK FOR ILLEGAL REQUEST
1\$:	TSTB	(R1)	:RDI SET?
	BPL	1\$:BR IF NO
	BICB	#40,(R1)	:CLEAR RQI
2\$:	TSTB	2(R1)	:OUTPUT DONE SET?
	BPL	2\$:BR IF NOT
	RTS	PC	:RETURN
LDRVRF:	MOV	#BIT14,(R1)	:MASTER CLEAR KMC-11.
	BIC	#BIT15!BIT14,(R1)	;AND SHUT IT DOWN.
	CLR	R0	:CLEAR UPC POINTER.
	JSR	PC,SETMAP	:SET MICRO-CODE POINTER IN R2.
3\$:	CLR	(R1)	:START WITH THE CLEAN WORLD.
	MOV	R0,4(R1)	:LOAD CRAM ADDRESS.
	MOV	(R2)+,6(R1)	:LOAD INSTRUCTION WORD.
	MOV	#BIT10,(R1)	:SET ROM 0.
	MOV	#BIT13!BIT10,(R1)	;WRITE IT...
	INC	R0	:UPDATE UPC POINTER.
	CMP	#2000,R0	:OVER FLOW?
	BGT	3\$:BR IF NO.
VERIFY:	JSR	PC,SETMAP	:SET MICRO-CODE POINTER IN R2.
	CLR	R0	:SET UPC POINTER.
6\$:	CLR	(R1)	:START WITH THE CLEAN WORLD.
	MOV	R0,4(R1)	:LOAD CRAM ADDRESS.
	MOV	#BIT10,(R1)	:SET ROM 0.
	CMP	6(R1),(R2)+	:CHECK IF RIGHT?
	BEQ	9\$:BR IF GOOD.
	TYPE	MILDER	:LOADING ERROR.
9\$:	INC	R0	:BUMP UPC POINTER.
	CMP	#2000,R0	:IS IT DONE?
	BGT	6\$:BR IF NO.
	MOV	#BIT14,(R1)	:MASTER CLEAR KMC-11.
	RTS	PC	:RETURN.
SETMAP:	MOV	#LOMAP,R2	:LOAD ADDRESS OF LOW SPEED.
	BIT	#BIT1,STAT3	:IS IT HIGH SPEED?
	BEQ	3\$:BR IF NO.
	MOV	#HIMAP,R2	:LOAD HIGH SPEED ADDRESS.
3\$:	RTS	PC	:RETURN TO CALLER.
LOMAP:			:LOW SPEED (REMOTE) MICRO-CODE.

08-JUN-78 07:54 PAGE 66
CZK(GA.P11 08-JUN-78 07:53

N 6

PAGE: 007802

SUBROUTINES

3313 027654
3314
3315 027654
3316

. 27654

HIMAP:

;HIGH SPEED (LOCAL) MICRO-CODE.

SUBROUTINES

3317

033654	052200	040522	051516	EM2:	.ASCIZ <200>/TRANSMIT BA ERROR/
033677	200	051124	047101	EM3:	.ASCIZ <200>/TRANSMIT COUNT ERROR/
033725	200	042522	042503	EM4:	.ASCIZ <200>/RECEIVE BA ERROR/
033747	200	042522	042503	EM5:	.ASCIZ <200>/RECEIVE COUNT ERROR/
033774	051200	041505	044505	EM11:	.ASCIZ <200>/RECEIVE DATA ERROR/
034020	043200	042522	020105	EM12:	.ASCIZ <200>/FREE RUNNING ERROR/
034044	041600	047117	051124	EM13:	.ASCIZ <200>/CONTROL OUT ERROR/
034067	200	047111	042524	EM14:	.ASCIZ <200>/INTERNAL DDCMP ERROR COUNTS NON ZERO/
034135	200	054105	042520	DH1:	.ASCIZ <200>/EXPECTED FOUND ADDRESS/
034167	200	054105	042520	DH2:	.ASCIZ <200>/EXPECTED FOUND/
034210	020200	042523	032114	DH3:	.ASCIZ <200>/ SEL4 SEL6/
034231	200	040502	042523	DH4:	.ASCIZ <200>/BASEMC+3 THRU BASEMC+12 /
034263	200	046513	030503	DH5:	.ASCIZ <200>/KMC11 IS HUNG/ .EVEN
034302	000003			DT1:	3
034304	006	004			.BYTE 6,4
034306	001266				\$REG2
034310	006	004			.BYTE 6,4
034312	001272				\$REG4
034314	004	002			.BYTE 4,2
034316	001262				\$REG0
034320	000003				3
034322	006	004			.BYTE 6,4
034324	001274				\$REG5
034326	006	004			.BYTE 6,4
034330	001272				\$REG4
034332	004	002			.BYTE 4,2
034334	001266				\$REG2
034336	000003				3
034340	006	004			.BYTE 6,4
034342	001274				\$REG5
034344	006	004			.BYTE 6,4
034346	001272				\$REG4
034350	004	002			.BYTE 4,2
034352	001302				\$TMP2
034354	000002				2
034356	003	007			.BYTE 3,7
034360	001274				\$REG5
034362	003	002			.BYTE 3,2
034364	001272				\$REG4
034366	000002				2
034370	006	004			.BYTE 6,4
034372	001274				\$REG5
034374	006	002			.BYTE 6,2
034376	001272				\$REG4
034400	000003				3
034402	003	010			.BYTE 3,10
034404	001274				\$REG5
034406	003	004			.BYTE 3,4
034410	001272				\$REG4
034412	004	002			.BYTE 4,2
034414	021304				FLAG
034416	000003				3

08-JUN-78 07:54 PAGE 68
7KRG.A.P11 08-JUN-78 07:53

C 7

PAGE: 0080C2

SUBROUTINES

034420	003	010	.BYTE 3,10
034422	001274		\$REG5
034424	003	004	.BYTE 3,4
034426	001272		\$REG4
034430	004	002	.BYTE 4,2
034432	001266		\$REG2
034434	000003		3
034436	003	007	.BYTE 3,7
034440	001274		\$REG5
034442	003	004	.BYTE 3,4
034444	001272		\$REG4
034446	006	002	.BYTE 6,2
034450	001302		\$TMP2
034452	000002		2
034454	006	004	.BYTE 6,4
034456	001302		\$TMP2
034460	006	002	.BYTE 6,2
034462	001304		\$TMP3
034464	000010		10
034466	003	002	.BYTE 3,2
034470	001300		\$TMP1
034472	003	002	.BYTE 3,2
034474	021434		BASEMC+4
034476	003	002	.BYTE 3,2
034500	001302		\$TMP2
034502	003	002	.BYTE 3,2
034504	021436		BASEMC+6
034506	003	002	.BYTE 3,2
034510	001304		\$TMP3
034512	003	002	.BYTE 3,2
034514	021440		BASEMC+10
034516	003	002	.BYTE 3,2
034520	001306		\$TMP4
034522	003	002	.BYTE 3,2
034524	021442		BASEMC+12
034526	000002		2
034530	006	004	.BYTE 6,4
034532	001274		\$REG5
034534	006	002	.BYTE 6,2
034536	001272		\$REG4
034540	000001		CORMAX: .END

SYMBOL TABLE

ABASE = 000000	AUSTRT 003126	CONN 010665	ERCT05 002330	KMNUM 001472
ACDW1 = 000000	AUSWR = 000000	CONTAB 003330	ERCT06 002334	KMP04 002074
ACDW2 = 000000	AUTO.S 012124	CONVRT= 104416	ERCT07 002340	KMP06 002076
ACPUOP= 000000	AVECT1= 000000	CORMAX 034540	ERCT10 002344	KMRLVL 002060
ADDW0 = 000000	AVECT2= 000000	CR = 000015	ERCT11 002350	KMRVEC 002056
ADDW1 = 000000	BASE 013756	CREAM 001502	ERCT12 002354	KMS100 002102
ADDW10= 000000	BASELD 022030	CRLF = 000200	ERCT13 002360	KMS101 002112
ADDW11= 000000	BASELH 022136	CSR 010357	ERCT14 002364	KMS102 002122
ADDW12= 000000	BASEMC 021430	CSRMAP 012126	ERCT15 002370	KMS103 002132
ADDW13= 000000	BINWRD 006406	CYCLE 011474	ERCT16 002374	KMS104 002142
ADDW14= 000000	BIT0 = 000001	DATABP 006760	ERCT17 002400	KMS105 002152
ADDW15= 000000	BIT00 = 000001	DATACL= 104413	ERR 003244	KMS106 002162
ADDW2 = 000000	BIT01 = 000002	DATAHD 006746	ERRMSG 006734	KMS107 002172
ADDW3 = 000000	BIT02 = 000004	DDISP = 177570	ERRPC 003322	KMS110 002202
ADDW4 = 000000	BIT03 = 000010	DELAY = 104411	ERRVEC= 000004	KMS111 002212
ADDW5 = 000000	BIT04 = 000020	DEVTAB 003342	ERTAB0 007106	KMS112 002222
ADDW6 = 000000	BIT05 = 000040	DH1 034135	EXIT = 000205	KMS113 002232
ADDW7 = 000000	BIT06 = 000100	DH2 034167	EXITER 007042	KMS114 002242
ADDW8 = 000000	BIT07 = 000200	DH3 034210	FLAG 021304	KMS115 002252
ADDW9 = 000000	BIT08 = 000400	DH4 034231	FLOAT 003156	KMS116 002262
ADEVCT= 000000	BIT09 = 001000	DH5 034263	FY 003202	KMS117 002272
ADEVVM = 000000	BIT1 = 000002	DISPLA 001242	HALTS 006764	KMS200 002104
ADRCNT 006053	BIT10 = 002000	DISPRE 000174	HILIM 006046	KMS201 002114
ADVANC= 104420	BIT11 = 004000	DSWR = 177570	HIMAP 027654	KMS202 002124
AENV = 000002	BIT12 = 010000	DT1 034302	HT = 000011	KMS203 002134
AENVM = 000000	BIT13 = 020000	DT10 034434	IISR 017132	KMS204 002144
AFATAL= 000000	BIT14 = 040000	DT11 034452	INCHAR 011434	KMS205 002154
AMADR1= 000000	BIT15 = 100000	DT12 034464	INIFLG 001506	KMS206 002164
AMADR2= 000000	BIT2 = 000004	DT13 034526	INLP1 005762	KMS207 002174
AMADR3= 000000	BIT3 = 000010	DT2 034320	INPUT - 104415	KMS210 002204
AMADR4= 000000	BIT4 = 000020	DT3 034336	INTTY 013506	KMS211 002214
AMAMS1= 000000	BIT5 = 000040	DT4 034354	IOTVEC= 000020	KMS212 002224
AMAMS2= 000000	BIT6 = 000100	DT5 034366	KMACTV 001470	KMS213 002234
AMAMS3= 000000	BIT7 = 000200	DT6 034400	KMCM 011044	KMS214 002244
AMAMS4= 000000	BIT8 = 000400	DT7 034416	KMCR00 002100	KMS215 002254
AMSGAD= 000000	BIT9 = 001000	DZDMH = 000000	KMCR01 002110	KMS216 002264
AMSGLG= 000000	BM 010625	EMTVEC= 000030	KMCR02 002120	KMS217 002274
AMSGTY= 000000	BPTVEC= 000014	EM11 033774	KMCR03 002130	KMS300 002106
AMTYP1= 000000	BRLVL 013472	EM12 034020	KMCR04 002140	KMS301 002116
AMTYP2= 000000	BRW 004354	EM13 034044	KMCR05 002150	KMS302 002126
AMTYP3= 000000	CHRCNT 006404	EM14 034067	KMCR06 002160	KMS303 002136
AMTYP4= 000000	CKSWR 011226	EM2 033654	KMCR07 002170	KMS304 002146
APASS = 000000	CKSWR1 011302	EM3 033677	KMCR10 002200	KMS305 002156
APRIOR= 000000	CKSWR2 011314	EM4 033725	KMCR11 002210	KMS306 002166
APTCSU= 000040	CKSWR3 011320	EM5 033747	KMCR12 002220	KMS307 002176
APTENV= 000001	CKSWR4 011324	ENDEX 017062	KMCR13 002230	KMS310 002206
APTSIZ= 000200	CKSWR5 011430	ENDEX1 017076	KMCR14 002240	KMS311 002216
APTSPO= 000100	CLKX 001452	ENDEX2 017100	KMCR15 002250	KMS312 002226
APT.SI 013540	CLR TAB 016566	ERCT00 002304	KMCR16 002260	KMS313 002236
ASWREG= 000000	CNERR 011023	ERCT01 002310	KMCR17 002270	KMS314 002246
ATESTN= 000000	CNT.MA 002302	ERCT02 002314	KMCSR 002066	KMS315 002256
AUDONE 003354	CNVRT = 104417	ERCT03 002320	KMCSRH 002070	KMS316 002266
AUNIT = 000000	CONERR 010756	ERCT04 002324	KMCTL 002072	KMS317 002276

SYMBOL TABLE

KMTVL	002064	PACT13	002356	RFRLED	022356	SW8	= 000400	X3	= 000103
KMTVEC	002062	PACT14	002362	ROMCLK=	104412	SW9	= 001000	X4	= 000104
KM-END	002300	PACT15	002366	RUN	001500	TBITVE=	000014	X5	= 000105
KM-MAP	002100	PACT16	002372	R6	=%000006	TBUF	021314	X6	= 000106
LDRVRF	022474	PACT17	002376	R7	=%000007	TBUFF	020110	X7	= 000107
LF	= 000012	PARBIT=	040000	SAVACT	001474	TCOUNT	021312	ZERO	001462
LINE	010567	PERFOR=	004537	SAVNFM	001476	TEMP	011122	SAPTHD	002034
LOBITS	006052	PFTAB	007320	SAVPC	001460	TFLAG	021306	SATYC	004716
LOCK	001444	PIRQ	= 177772	SAVSP	001456	TIMER	= 104414	SATY1	004672
LOKFLG	001510	PIRQVE=	000240	SAV05	= 104406	TKVEC	= 000060	SATY3	004700
LOLIM	006044	POPRO	= 012600	SCAN	016716	TLAST	= 016370	SATY4	004710
LOMAP	023650	POP1SP=	005726	SCAN1	017102	TPVEC	= 000064	SAUTOB	001234
MASKX	001454	POP2SP=	022626	SCAN2	016730	TRAPVE=	000034	SBASE	001372
MASTEK	010011	PRI0	010416	SCOP1	= 104405	TRTVEC=	000014	\$BDADR	001222
MCSRX	007741	PRIORITY	013760	SETMAP	022614	TST1	013762	\$BDDAT	001226
MDATA	011164	PRO	= 000000	SHUTDO	022442	TST10	016056	SCDW1	001376
MEMLIM	001466	PR1	= 000040	SOFTSW	011466	TST11	016156	SCDW2	001400
MEPASS	007614	PR2	= 000100	SPACNT=	006405	TST12	016370	SCHARC	004666
MERRPC	010066	PR3	= 000140	STACK	= 001200	TST2	015006	SCMTAG	001200
MERRX	007766	PR4	= 000200	STAT	001450	TST3	015200	SCM1	= 000006
MERR2	007641	PR5	= 000240	STAT1	002050	TST4	015336	SCM2	= 000014
MERR3	007666	PR6	= 000300	STAT2	002052	TST5	015464	SCM3	= 000006
MILK	001504	PR7	= 000340	STAT3	002054	TST6	015622	SCM4	= 000005
MILDER	011054	PS	- 177776	STKLMT=	177774	TST7	015740	SCNTLG	005530
MILOCK	007712	PSW	= 177776	STRTSW	001446	TTST	004146	SCNTLU	005523
MNEW	010013	PUSHRO=	010046	SV05	006074	TWOSYN=	010000	SCPUIOP	001344
MODU	010455	PUSH1S=	005746	SWFLG	011432	TYPDAT	006750	SCRAP	= 177777
MPASSX	007755	PUSH2S=	024646	SWR	001240	TYPE	= 104401	SCRLF	001313
MPFAIL	007556	PWRVEC=	000024	SWREG	000176	TYPMMSG	006650	SDDWO	001402
MR	007636	QV.FLG	001511	SW0	= 000001	VEC	010375	SDDW1	001404
MRESET=	004000	RBUF	021362	SW00	= 000001	VECMAP	013222	SDDW10	001426
MSTCLR=	104410	RBUFF	020346	SW01	= 000002	VECTR	013754	SDDW11	001430
MTITLE	001000	RBUFFE	021302	SW02	= 000004	VERFY	022544	SDDW12	001432
MTSTN	007777	RBUFF1	020346	SW03	= 000010	WHAT	005764	SDDW13	001434
MVECX	007747	RBUFF2	020452	SW04	= 000020	WHERE	006050	SDDW14	001436
NEXT	001442	RBUFF3	020556	SW05	= 000040	WHICH	013214	SDDW15	001440
NOACT	010725	RBUFF4	020662	SW06	= 000100	WRDCNT	006402	SDDW2	001406
NODEV	003240	RBUFF5	020766	SW07	= 000200	WRKO.F	006736	SDDW3	001410
NUM	010317	RBUFF6	021072	SW08	= 000400	XBX	006536	SDDW4	001412
OISR	017422	RBUFF7	021176	SW09	= 001000	XCNTAB	020240	SDDW5	001414
OK	003220	RCNTAB	020220	SW1	= 000002	XCSR	004104	SDDW6	001416
ONE	001464	RCOUNT	021360	SW10	= 002000	XDNTAB	020312	SDDW7	001420
PACT00	002302	RDCHR	= 104402	SW11	= 004000	XERR	004126	SDDW8	001422
PACT01	002306	RDLIN	= 104403	SW12	= 010000	XFRELD	022410	SDDW9	001424
PACT02	002312	RDNTAB	020256	SW13	= 020000	XHEAD	010073	SDEVCT	001326
PACT03	002316	RDOCT	= 104404	SW14	= 040000	XMITBA	020052	SDEVM	001374
PACT04	002322	RECBA	020052	SW15	= 100000	XPASS	004120	SDOAGN	004100
PACT05	002326	RESREG	006762	SW2	= 000004	XSTATQ	011074	SENDAD	004070
PACT06	002332	RESUM	022246	SW3	= 000010	XTSTN	007114	SENDCT	004054
PACT07	002336	RESUME	020050	SW4	= 000020	XVEC	004112	SENV	001336
PACT10	002342	RESVEC=	000010	SW5	= 000040	X0	= 0C0110	SENVM	001337
PACT11	002346	RES05	= 104407	SW6	= 000100	X1	= 000101	SEOP	003662
PACT12	002352	RFLAG	021310	SW7	= 000200	X2	= 000102	SEOPCT	004046

08-JUN-78 07:54 PAGE 72
CZKCGA.P11 08-JUN-78 07:53

F 7

PAGE: 0083C2

SYMBOL TABLE

SERFLG 001203	SLPADR 001206	\$NWTST= 000000	SSVPC - 000040	STYPEC 004622
SERMAX 001215	SLPERR 001210	SOVER 004330	SSWR = 164000	STYPFX 004670
SERROR 006506	SMADR1 001350	SPASS 001324	SSWREG 001340	SUNIT1 001330
SERRPC 001216	SMADR2 001354	SPASTM 002042	SSWRMK= 000000	SUNITM 002044
SERRTB 001512	SMADR3 001360	SPWRDN 007122	TESTN 001322	SUSRW 001342
SERTTL 001212	SMADR4 001364	SPWRMG 007306	STIMES 001310	SVEC1 001366
SETABL 001336	SMAIL 001316	SPWRUP 007174	STKB 001246	SVECT2 001370
SETEND 001442	SMAMS1 001346	SQUES 001312	STKS 001244	SXTSTR 004174
SFATAI 001320	SMAMS2 001352	SRDCHR 005140	STMP0 001276	SY = 000000
SFFLG 005136	SMAMS3 001356	SRDLIN 005260	STMP1 001300	\$\$GET4= 000000
SFIILC 001256	SMAMS4 001362	SRDOCT 005560	STMP2 001302	= 034540
SFIILS 001255	SMBADR 002036	SRDSZ = 000007	STMP3 001304	.ADVAN 006054
SGDADR 001220	SMFLG 005134	SREGAD 001260	STMP4 001306	.BEGIN 003464
SGDDAT 001224	SMNEW 005546	SREG0 001262	STN - 000013	.CNVRT 006164
SGET42 004060	SMSGAD 001332	SREG1 001264	STPB 001252	.CONVR 006160
SHD = 000000	SMSGLG 001334	SREG2 001266	STPFLG 001257	.DATAC 007442
SHIBTS 002034	SMSGTY 001316	SREG3 001270	STPS 001250	.DELAY 007326
SHIOCT 005716	SMSWR 005535	SREG4 001272	STRAP 006410	.MSTCL 007356
SICNT 001204	SMTYP1 001347	SREG5 001274	STRAP2 006432	.RES05 006126
SILLUP 007312	SMTYP2 001353	SRTNAD 004102	STRP = 000021	.ROMCL 007374
SINPUT 005720	SMTYP3 001357	SS = 000014	STRPAD 006444	.SAV05 006066
SINTAG 001235	SMTYP4 001363	SSAVR6 007316	STSTM 002040	.SCOP1 004360
SITEMB 001214	SMXCNT 004356	SSCOPE 004134	STSTNM 001202	.START 002402
SLF 001314	SN = 000012	\$\$SETUP= 000000	STTYIN 005514	.TIMER 007506
SLFLG 005135	NULL 001254	\$\$SVLAD 004316	STYPE 004410	.\$X - 002034

. ABS. 034540 000

ERRORS DETECTED: 0

DSKZ:CZKCGA,DSKZ:CZKCGA/SOL=CZKCGA.MAC,CZKCGA.P11/EQ:DZDMH
RUN-TIME: 29 18 .7 SECONDS
RUN-TIME RATIO: 122/48=2.5
CORE USED: 46K (91 PAGES)